


Operation & Installation Manual



Model 8331 Series Programmable Attenuator Units

This documentation may not be reproduced in any form, for any purpose unless authorized in writing by API / Weinschel, Inc.

api 
technologies corp.
> WEINSCHTEL

© API / Weinschel, Inc.
Frederick, Maryland
2012

SAFETY SUMMARY

DEFINITIONS.

The following definitions apply to WARNINGS, CAUTIONS, and NOTES found throughout this manual.



An operating or maintenance procedure, practice, statement, condition, etc., which, if not strictly observed, could result in injury and/or death of personnel. Do not proceed beyond a WARNING symbol until all the indicated conditions have been fully understood and/or met.



An operating or maintenance procedure, practice, statement, condition, etc., which, if not strictly observed, could result in damage or destruction of the equipment or long-term health hazards to personnel. Do not proceed beyond a CAUTION symbol until all the indicated conditions have been fully understood and/or met.

NOTE

An essential operating or maintenance procedure, condition, or statement that must be highlighted.

GENERAL PRECAUTIONS.

The following are general precautions that are not related to any specific procedure and, therefore, do not appear elsewhere in this publication. These are precautions that personnel must understand and apply during various phases of instrument operation or service.



- Potentially lethal voltages are present in this instrument. Serious shock hazards from voltages above 70 volts may exist in any connector, chassis, or circuit board. Observe the following precautions:


- To minimize shock hazard, the instrument chassis must be connected to an electrical ground. Using the supplied three-conductor power cable ensures that the instrument can be firmly connected to the ac power source and electrical ground at a grounded power outlet. If using a 3-2 wire adapter be sure to connect the ground lead to earth ground.
- Use the buddy system any time work involving active high voltage components is required. Turn OFF the power before making/breaking any electrical connection. Regard any exposed connector, terminal board, or circuit board as a possible shock hazard. DO NOT replace any component or module with power applied.
- If test conditions to live equipment are required, ground the test equipment before probing the voltage or signal to be tested.
- Personnel working with or near high voltage should be familiar with modern methods of resuscitation.
- DO NOT wear jewelry (rings, bracelets, metal watches, and/or neck chains) while working on exposed equipment. Be very cautious about using hand tools near exposed backplanes, bus bars, and/or power supply terminals. Use properly insulated tools. When making test connections to the power supply terminals and bus bars, use only insulated probe tips.
- Verify that the instrument is set to match the available line voltage and the correct fuse is installed.
- DO NOT install substitute parts or perform any unauthorized modification to this instrument. Contact Weinschel Corporation to acquire any information on replacement parts or returning the instrument for repair. Unauthorized modification can cause injury to personnel and/or destruction of the instrument.
- Operating personnel must not remove instrument covers. Component replacement or adjustments MUST BE performed by qualified service personnel.
- DO NOT operate the instrument near or in the presence of flammable gases or fumes.

DETAILED PRECAUTIONS.

The following WARNINGS, CAUTIONS and NOTES appear throughout the text of this manual and are repeated here for emphasis.



CAUTION

- All procedures and/or steps identified as  must be followed exactly as written and according to industry accepted ESDS device handling procedures. Failure to comply WILL RESULT in ESDS damage.
- DO NOT use a nylon bristle brush in the solvent as the bristles may dissolve and cause damage to the circuit card or component.
- DO NOT use ultrasonic cleaning on parts or assemblies containing electrical or electronic components.
- DO NOT bend pins of electrical connectors when using fiber-bristle brush.
- Compressed air used for cleaning and/or drying can create airborne particles that may enter the eye. Goggles/faceshields should be worn. DO NOT direct air stream towards self or other personnel. Pressure should be restricted to a maximum of 15 psi to avoid personal injury.
- Under no circumstances should a wire brush, steel wool, or abrasive compound be used on any surface. Using these items will cause extensive damage to the instruments surface.

NOTE

DO NOT return any instrument or component to Weinschel Corporation without receiving prior factory authorization.

SAFETY SYMBOLS.

The following symbols are used to identify safety hazards found throughout this publication and/or located on the instrument.





TABLE OF CONTENTS

| | |
|--|-------|
| 1. GENERAL INFORMATION | 4 |
| 1-1. PURPOSE | 4 |
| 1-2. SCOPE | 4 |
| 1-3. EQUIPMENT DESCRIPTION | 4 |
| 1-4. UNPACKING AND INSPECTION | 5 |
| 1-5. RESHIPMENT INSTRUCTIONS | 5 |
| 1-6. STORAGE INSTRUCTIONS | 5 |
| 1-7. RELATED MANUALS | 6 |
| 1-8. ELECTROSTATIC DISCHARGE SENSITIVE (ESD) | 6 |
| 1-9. ABBREVIATIONS & ACRONYMS | 6 |
| 1-10. SAFETY CONSIDERATIONS | 6 |
| 2. SPECIFICATIONS | 7-8 |
| 2-1. GENERAL SPECIFICATIONS | 7 |
| 2-2. CONFIGURATION MATRIX / RF SPECIFICATIONS | 8 |
| 3. INSTALLATION | 9-10 |
| 3-1. RACKMOUNTING | 9 |
| 3-2. INITIAL SETUP | 9 |
| 3-3. INPUT/OUTPUT OPTIONS | 9-10 |
| 3-3.1. POWER ENTRY MODULE ASSEMBLY | 10 |
| 3-3.2. CONTROL CONNECTORS | 10 |
| 3-3.3. RF PORT CONNECTORS | 10 |
| 4. OPERATION | 11-35 |
| 4-1. RS-232 SERIAL/CONSOLE PORT | 11 |
| 4-2. 10/100BASET ETHERNET | 11-12 |
| 4-3. COMMAND OPERATION | 12-13 |
| 4-4. COMMAND EXECUTION AND BUFFERING | 13 |
| 4-5. COMMAND REFERENCE | 13 |
| 4-6. APPLICATION SPECIFIC COMMANDS | 14-18 |
| 4-7. 488.2 COMMON COMMANDS | 19-20 |
| 4-8. SETUP AND CONFIGURATION COMMANDS | 21-25 |
| 4-8.1 SERIAL PORT COMMANDS | 21 |
| 4-8.2 NETWORK COMMANDS | 22-25 |
| 4-9. SHOW COMMANDS | 26-31 |
| 4-10. MISC COMMANDS | 32-33 |
| 4-11. MISC NETWORK COMMANDS | 33 |
| 4-12. UPDATING DEVICE FIRMWARE VIA SERIAL PORT | 34-35 |
| 5. MAINTENCE | 34-35 |
| 5-1. INSPECTION | 36 |
| 5-2. PREVENTIVE MAINTENANCE | 36 |
| 5-3. SPECIAL CLEANING INSTRUCTIONS | 36 |
| 5-3.1. MICROWAVE COAXIAL CABLE ASSEMBLIES | 36 |
| 5-3.2. MACHINED SURFACES AND HARDWARE | 37 |
| 5-3.3. CONNECTOR CLEANING | 37 |

5-4. LINE VOLTAGE FUSE REPLACEMENT 37

6. REPLACABLE PARTS LIST 37

 6-1 REPLACEABLE PARTS LIST (RPL)..... 37

 6-2 ASSEMBLY AND COMPONENT LOCATION 37

6.CONTACTING API / WEINSCHEL 38

6.API / WEINSCHEL WARRANTY 38

7. SPECIFICATION/ICD DRAWINGS

 ATTENUATOR UNIT, SMA THRU MECHANICAL SPECIFICATION, MODEL 8331 SERIES089-4312

 ATTENUATOR UNIT, SMA FRONT MECHANICAL SPECIFICATION, MODEL 8331 SERIES (TBD) ...089-4313

 ATTENUATOR UNIT, SMA REAR MECHANICAL SPECIFICATION, MODEL 8331 SERIES (TBD).....089-4314

 ATTENUATOR UNIT, N THRU MECHANICAL SPECIFICATION, MODEL 8331 SERIES (TBD).....089-4315

 ATTENUATOR UNIT, N FRONT MECHANICAL SPECIFICATION, MODEL 8331 SERIES (TBD)089-4316

 ATTENUATOR UNIT, N REAR MECHANICAL SPECIFICATION, MODEL 8331 SERIES (TBD).....089-4317

 ATTENUATOR UNIT ELECTRICAL SPECIFICATIONS (TBD)089-4318

1. GENERAL INFORMATION:

1-1 PURPOSE: This manual contains setup and operation information for the API / Weinschel's Model 8331 Series, Programmable Attenuator Unit, P/N 193-8300-XXX-X.

1-2 SCOPE: This manual is to be used in conjunction with the operation and installation of the Model 8331 Series. The manual also provides a description of the assembly; block diagrams; and general maintenance procedures to maintain the instrument.

1-3 EQUIPMENT DESCRIPTION: API / Weinschel's Model 8331 Series, Programmable Attenuator Units (Figure 1) is a multi-channel configuration which is designed to house and control various API / Weinschel Programmable Attenuator Models (3200-XE, 3400, 150T and 4200 Series) via ethernet, USB and Serial communications interfaces.

Most 8331 Series are multi-channel configurations where RF signal is routed through either the front or rear mounted Ports (labeled). This series can be configured for up to 12 independent channels of attenuation. Multiple programmable attenuators can be used in conjunction with other coaxial devices such as switches, power combiners, directional couplers, and filters creating various multichannel test configurations.




Figure 1. Model 8331 Simplified 12 Channel Block Diagram

1-4. UNPACKING AND INSPECTION: Upon unpacking the equipment, retain the shipping container and packing material for future shipment for recalibration. Perform the following initial inspection:

- a. Carefully look at the outside of the shipping container for discoloration, stains, charring, or other signs of exposure to excessive heat, moisture, or liquid chemicals. Check for any physical damage to the shipping container such as dents, snags, rips, crushed sections or areas, or similar signs of excessive shock or careless handling.
- b. With the equipment and any accessory package removed from the shipping container, check each item against the packing list or Items Supplied List. If any items are missing, contact the API / Weinschel Customer Service Department.
- c. Carefully inspect the equipment looking for dents, deep scratches, damaged or loose connector, or any other signs of physical abuse or careless handling. If damage is found, forward an immediate request to the delivering carrier to perform an inspection and prepare a concealed-damage report. DO NOT destroy any packing material until it has been examined by an agent of the carrier. Concurrently, report the nature and extent of damage to API / Weinschel, giving equipment model and serial numbers, so that necessary action can be taken. Under U.S. shipping regulations, damage claims must be collected by the consignee; DO NOT return the equipment to API / Weinschel until a claim for damages has been established.

2-5. RESHIPMENT: Use the best packaging materials available to protect the unit during storage or reshipment. When possible, use the original packing container and cushioning material. If the original packing materials are not available, use the following procedure:

- a. Wrap the storage cases in sturdy paper or plastic;
- b. Place the wrapped storage cases in a strong shipping container and place a layer of shock-absorbing material (3/4 inch minimum thickness) around all sides of the unit to provide a firm cushion and to prevent movement inside the container.
- c. If shipping the unit for service, attach a tag to indicate:
 1. model and serial numbers
 2. service required
 3. description of malfunction
 4. return address
 5. authorization to conduct repairs
 6. return authorization number
- d. Thoroughly seal the shipping container and mark it FRAGILE. Ship to:


API / Weinschel, Inc.
Attn: Customer Service Department
5305 Spectrum Drive
Frederick, MD 21703-7362
or to an authorized sales representative.

1-6. STORAGE: Storage of the Model 8331 is possible for extended periods without incurring damage to internal circuitry if the Model 8331 is packaged according to the instructions above. The safe limits for storage environment are as follows:

Temperature: -30°C to +70°C
Humidity: 5% to 85% (non-condensing)



1-7. RELATED MANUALS: The following manuals contain information that may be used in conjunction with this manual to operate, service, or calibrate this instrument.

| <u>Manual</u> | <u>Title</u> |
|---------------|---|
| IM-606 | Manual, Replaceable Parts List & Drawings, Model 8331Series |

1-8. ELECTROSTATIC DISCHARGE SENSITIVE: The equipment documented in this manual contains certain Electrostatic Discharge Sensitive (ESDS) components or parts. Therefore, certain procedures/steps are identified by the use of the symbol . This symbol is used in two ways:



All procedures and/or steps identified as must be followed exactly as written and according to accepted ESDS device handling procedures. Failure to comply **WILL RESULT** in ESDS damage.

- a. When the ESDS symbol is placed between a paragraph number and title  all of that paragraph, including all subparagraphs, is considered ESDS device handling procedure.
- b. When the ESDS symbol is placed between a procedure/step number and the text , all of that procedure is considered an ESDS device handling procedure.

1-9. ABBREVIATIONS AND ACRONYMS: The following list contains abbreviations used throughout this manual. Abbreviations and acronyms that are not listed conform to MIL-STD-12D.

| | |
|------|-----------------------------------|
| ESDS | Electrostatic Discharge Sensitive |
| TBD | To Be Determined |

1-10. SAFETY CONSIDERATIONS: The Model 8331 Series and all related documentation must be reviewed for familiarization with safety markings and procedures before any operation and/or service. Refer to the SAFETY SUMMARY located at the beginning of this manual for a summary of safety information and procedures. Following these simple safety precautions will ensure safe operation and service of the unit.

2. SPECIFICATIONS:

2-1. GENERAL SPECIFICATIONS:

| | |
|---|--|
| Input Power Requirements | AC 100 to 240 Vac, 50/60 Hz, 180 Watts |
| Environmental | Operating Temperature 0° to +50°C Storage Temperature: -67° to +167 °F (-55° to +75°C) Humidity: 96% (non-condensing) Altitude: 40,000' (12,192M) |
| RS-232 Bus ⁽¹⁾ Serial I/O | Connector: 9-pin male D Signals: TXD, RXD, RTS, CTS, GND Baud Rates: 9600 to 230400 Data Bits: 8 Handshaking: None, RTS/CTS Parity: None, Odd, Even |
| Ethernet TC/IP | 10/100 Base T Connector: Standard RJ45 |
| USB 2.0 | Connector: |
| RF Characteristics ⁽²⁾ | See Model Configuration Tables (pg 8) |

NOTES:

1. RS-232 can be used with standard PC serial port for short and medium distances (up to approximately 50 ft).
2. Refer to Individual data sheet (Appendix B) for detailed specifications on internal programmable attenuators.

2-2. CONFIGURATION MATRIX\RF SPECIFICATIONS:

8331 - XX - XX - XX

Basic Model Number Attenuator Designator (see below) Number of Channels (01 to 12)**

Connector Type
S = SMA Female
N = N Female*

Connector Location**
F = Front
R = Rear
T = Front - Rear

Example: 8331-M3-09-TS

* Not available for option DXX (152T Series)

** Up to 6 Channels for option F & R (Front or Rear)
Up to 10 Channels for option C & D (150T & 152T Series)
Up to 5 Channels for option C7 & D5

| Electro-mechanical | | | | | | | | |
|--------------------|------------------------|---|--------------------|------------|----------------|--------------------------|----------------|--------|
| Frequency Range | Attenuator Designation | | Attenuator Model | Range (dB) | Step Size (dB) | Insertion Loss (maximum) | VSWR (maximum) | ☑ RoHs |
| DC-3 GHz | A | 1 | 3205-1E | 70 | 10 | 4.75 dB | 1.4 | |
| | | 2 | 3205-2E | 55 | 5 | 4.75 dB | 1.4 | |
| | | 3 | 3205-3E | 1.5 | 0.1 | 4.75 dB | 1.4 | |
| | | 4 | 3201-1E | 31 | 1 | 5dB | 1.4 | |
| | | 5 | 3206-1E | 63 | 1 | 5.25 dB | 1.4 | |
| | | 6 | 3200-1E | 127 | 1 | 6dB | 1.4 | |
| | | 7 | 3200-2E | 63.75 | 0.25 | 6dB | 1.4 | |
| | | 8 | 3209-1E | 64.5 | 0.1 | 8dB | 1.4 | |
| DC-6 GHz | B | 1 | 3404-15 | 15 | 1 | 3.5 dB | 1.55 | |
| | | 2 | 3404-55 | 55 | 5 | 3.5 dB | 1.55 | |
| | | 3 | 3404-70 | 70 | 10 | 3.5 dB | 1.55 | |
| | | 4 | 3406-55 | 55 | 1 | 4.5 dB | 1.55 | |
| | | 5 | 3408-55.75 | 55.75 | 0.25 | 6 dB | 1.55 | |
| | | 6 | 3408-103 | 103 | 1 | 6 dB | 1.55 | |
| DC-18 GHz | C | 1 | 150T-70 | 70 | 10 | 3.25dB | 1.75 | ✓ |
| | | 2 | 150T-15 | 15 | 1 | 3.5dB | 1.95 | ✓ |
| | | 3 | 150T-75 | 75 | 5 | 3.5dB | 1.95 | ✓ |
| | | 4 | 150T-110 | 110 | 10 | 3.5dB | 1.95 | ✓ |
| | | 5 | 150T-31 | 31 | 1 | 3.75 dB | 1.95 | ✓ |
| | | 6 | 150T-62 | 62 | 2 | 3.75 dB | 1.95 | ✓ |
| | | 7 | 150T-15 & 150T-110 | 125 | 1 | 5.25 dB | 1.95 | ✓ |
| DC-26.5GHz | D | 1 | 152AT-70 | 70 | 10 | 4.75 dB | 1.95 | ✓ |
| | | 2 | 152T-15 | 15 | 1 | 5 dB | 1.95 | ✓ |
| | | 3 | 152T-75 | 75 | 5 | 5 dB | 1.95 | ✓ |
| | | 4 | 152T-90 | 90 | 10 | 5 dB | 1.95 | ✓ |
| | | 5 | 152T-90 & 152T-15 | 105 | 1 | 6.5 dB | 1.95 | ✓ |
| Solid State | | | | | | | | |
| 0.8 to 2.5/3 GHz | J | 1 | 4226-63 | 63 | 1 | 4.75 dB | 1.6 | |
| | | 2 | 4228-63.75 | 63.75 | 0.25 | 6 dB | 1.6 | |
| | | 3 | 4228-103 | 103 | 1 | 6 dB | 1.6 | |
| 0.01 to 2.5 GHz | K | 1 | 4238-63.75 | 63.75 | 0.25 | 10 dB | 1.75 | |
| | | 2 | 4238-103 | 103 | 1 | 10 dB | 1.75 | |
| 0.01 to 2.5 GHz | L | 1 | 4246-63 | 63 | 1 | 11 dB | 2.0 | |
| | | 2 | 4248-63.75 | 63.75 | 0.25 | 14 dB | 2.0 | |
| | | 3 | 4248-103 | 103 | 1 | 14 dB | 2.0 | |
| 0.2 to 6 GHz | M | 1 | 4205-31.5 | 31.5 | 0.5 | 4 dB | 1.8 | ✓ |
| | | 2 | 4205-63.5 | 63.5 | 0.5 | 6 dB | 1.8 | ✓ |
| | | 3 | 4205-95.5 | 95.5 | 0.5 | 8.5 dB | 2.0 | ✓ |

✓ RoHs compliance dependent on attenuator installed. Some attenuators are NOT compliant.

3. INSTALLATION:

3-1. RACKMOUNTING: The Model 8331 Series is shipped with front panel rack mounting ears that will allow the unit to be mounted in any rack or cabinet that is designed according to EIA RS-310 or MIL-STD-189.

3-2. INITIAL SETUP: The following initial setup procedures should be performed prior to operating the Model 8331 Series .

- a. Perform inspection per paragraph 1-4 prior to connecting the 8331 Series to any power source.
- b. Install the 8331 Series into a cabinet or rack, as required using customer supplied rack mount slides.
- c. Connect all power, RF and system cables as required to the Model 8331 Series.

3-3 INPUT/OUTPUT OPTIONS: The following paragraphs provide a description of the connections that can be made to the Model 8331 Series. Figure 2 shows the location of these connectors and switches.




Figure 2. Front/Rear Panel Connectors

3-3.1 POWER ENTRY MODULE ASSEMBLY: The Power Entry Module Assembly located on the rear panel contains a three-prong AC power input connector and a fuse drawer assembly (Figure 2). The **Fuse Drawer Assembly** contains the line voltage fuse (API / Weinschel P/N 052-1-1.5). The Model 8331 Series uses a T 1.5A, 250 Vac fuse which is 5 x 20 mm in size.

The **AC Power Connector**, located on the left side of XF1 (Figure 2), is a plug-type, prong insert connector with three conductors for connection of the power cord (P/N 068R-106) to the Power Supply Assembly located within the Unit. This connector also grounds the chassis of the Unit when the ac power cord is connected to a grounded wall outlet. If necessary, use a three prong to two-prong adapter and connect the adapter's ground lead to the outlet plate retaining screw.

The **Power ON/OFF Switch** is located on the front panel and in part of the Power Entry Module Assembly. Placing the POWER ON/OFF switch in the ON position applies power to the instrument.

**CAUTION**

All electrical rack or chassis and machine elements should be Earth Grounded in installations where high level of electrical noise can be expected. The rack or chassis should be grounded with a rod or attached to a nearby earth structure such as a steel beam support beam. Connect each apparatus to a single ground point in a star configuration with low impedance cable. Scrape away paint and other nonconductive material from the area where a chassis makes contact with the enclosure. In addition to the ground connection made through the mounting bolt or stud, use a one-inch metal braid or size #8 AWG wire to connect between each chassis and the enclosure at the mounting bolt or stud.

3-3.2. CONTROL CONNECTORS: These connectors are located on the middle of the rear panel and one is a standard 9 pin D connector and is identified as Serial and the other is a standard RJ45 female connector to provide LAN connectivity in support of 10/100baseT. For more details about these connectors and their Pin outs can be located in paragraph 3 (Operation).

**CAUTION**

When applying an RF signal to the RF INPUT connector, DO NOT exceed the maximum allowable power level specifications of the unit.


Do not over torque the SMA connectors more than 7 inch pounds. Damage may occur.

3-3.3. RF PORT CONNECTORS: A typical Model 8331 Series Attenuator Unit contains 12 standard D holes on the front and rear panel allowing for single or multichannel configurations. Standard Model 8331 are supplied with either SMA or Type N connectors that can be mounted on the front or rear panel. These connectors provide a input and output port where various types of RF signals can be applied to the devices internally mounted in the Model 8331 (Connector location specified by customer when ordering). These connectors are per MIL-STD-348 interface dimensions and mate nondestructively per MIL-STD-212.

4. OPERATION:

4-1. RS-232 SERIAL/CONSOLE PORT The RS-232 port is available on a DE9M connector and utilizes three signals: TXD, RXD and GND along with the optional RTS and CTS handshaking signals. The connector pinout is configured as a DTE device, so connections to an external DTE device (such as a PC) would require the use of a null-modem cable. The format is fixed at N81 (no parity, 8 data bits, 1 stop bit), and the baud rate is selectable via software command at rates of from 9600 to 230400. By default, the unit is shipped to operate at 115K baud, with Console mode non-volatile memory (NVM) setting enabled (see below).

The serial port has two modes of operation: console and raw mode. Console mode provides a command-line interface (CLI) and is useful for interactive control via a terminal emulator. Console mode sends command prompts ('>'), echoes received characters, supports the backspace key for simple editing, provides command line recall (CTRL-R), and issues error messages, while raw mode is more suitable for programming. Console mode may be enabled in one of two ways: either by setting the controller card CONF DIP switch S1-2 ON, or via the CONSOLE command. The CONSOLE command stores the enable parameter in non-volatile memory, and is recalled during power up. Setting switch S1-2 ON overrides the non-volatile setting for the baud rate and console mode parameters, allowing the user force the usage of default parameters, which is console mode ON and baudrate of 115200, if desired. The units are initially shipped with the DIP switch OFF, so console mode and baudrate settings are determined by the NVM setting.



RS-232 DE9M (DTE Pinout)

| Pin | Signal | Name | Direction |
|-----|--------|-----------------|-----------|
| 1 | | | |
| 2 | RXD | Receive Data | In |
| 3 | TXD | Transmit Data | Out |
| 4 | | | |
| 5 | GND | Signal Ground | |
| 6 | | | |
| 7 | RTS | Request To Send | Out |
| 8 | CTS | Clear To Send | In |
| 9 | | | |

4-2. 10/100BASET ETHERNET The Ethernet port supports 10/100BaseT operation, with auto-negotiation of the interface speed and duplex mode. LED indicators are provided to indicate network LINK status (green) and TX/RX activity (YELLOW). Supported network protocols include: IP, UDP, TCP, ICMP, ARP, DHCP, and AUTOIP. A TELNET server is provided for a command-line interface that implements many of the functions of the serial console CLI. Both TCP and UDP servers allow connections to be established for general programming purposes. Additionally, the Microchip Announce protocol is implemented to provide support for the Microchip Ethernet Discovery tool, which is a UDP-based protocol used to detect ethernet devices on the network.

IP addressing modes supported include the use of a statically assigned fixed address, or dynamic address assignment using either DHCP or AutoIP. The use of DHCP requires a DHCP server to reside on the network. AutoIP is an address mode that can be used when no DHCP server is available. It automatically allocates an address from the special block of addresses 169.254.1.0 to 169.254.254.255 reserved for link-local addressing. These addresses are only valid on the link that the host is connected to, such as a local network segment or point-to-point connection, and are unroutable. See the SET IPADDR, SET DHCP, SET AUTOIP, and SHOW IPADDR commands for more information.

The TELNET server communicates using the standard port 23 typically used by the TELNET protocol. The implementation is a reduced-functionality version and does not support the full protocol, but it should function properly with many clients. The server only supports a single connection, does not require any login, and does not support options negotiation except for the initial state of the echo setting. The server does support an inactivity timeout, and allows the use of TELNET NOP commands sent by the client to keep a session open. By default, the timeout is set for 300 seconds (5 minutes), after which the server will automatically close the session if no activity has occurred. Many of these features are configurable by the user (see SET TELNET in the command reference). The status of the server can be seen using the SHOW NET TELNET command. An active TELNET connection may be closed from the telnet application on the client using the 'QUIT' command.

The unit provides a TCP server that can be used for control and status of the unit using the same text-based messages used by the serial port. By default, the server is configured to listen on a single port (port 10001), and supports a single connection. The server can support multiple ports, each with multiple connections for multi-user environments, however this functionality must be configured by the factory. Server settings, such as the port number, keep alive timeout, inactivity close timer, and character echoing are programmable by the user (see SET TCP in the command reference). The status of the server(s) can be seen using the SHOW NET TCP command.

A UDP server is also provided that will accept command messages sent via UDP protocol using the same text-based messaging. UDP is a connection-less based protocol that is simpler and has less overhead than TCP. By default, the internal UDP server listens on port 20000, but this can be changed via the SET UDP SERVER command.

Various network events generate status messages shown on the serial Console port. These events include TCP and TELNET server connect/disconnect messages and DHCP/AUTOIP address assignment changes. The status messages may be disabled if desired (see SET NETSTAT), but are enabled by default.

For simple device discovery, the Microchip Announce protocol is used. The Microchip Announce protocol is a UDP-based scheme used to detect devices supporting the protocol. The protocol broadcasts UDP packets to port 30303 containing the message, "Discovery: Who is out there?", and supporting devices respond with a UDP packet which provides the device IP and MAC address, as well as other info such as the firmware version. A copy of the Ethernet Device Discoverer application for MS Windows-based systems is provided on the CD supplied with the unit, or can be downloaded from the Microchip website.

4-3. COMMAND OPERATION: Commands are comprised of text-based ASCII strings. The command parser is case-insensitive, so either upper or lower case characters are acceptable. Command parameters may be separated with either an ASCII SPACE char (0x20) or an ASCII COMMA char (0x2E), but the separator character used must be the same within an individual command string. Additional SPACE characters are ignored. Typically, input program messages may be terminated using either an ASCII CR character (0x0D) or an ASCII LF character (0x0A), however this can be changed by using the SET EOS command. Command message strings are limited to 128 characters total, including the terminator. Multiple commands can be included in one message by separating the individual commands with an ASCII SEMICOLON character ';' (0x3B), up to the 128 character message limit. Response messages are terminated differently depending on the source of the command. Response messages sent over the serial port default to using both a CR (0x0D) and LF (0x0A) to terminate the line, while messages sent via a network TCP or UDP connection default to using a single CR (0x0D) terminator. The output terminator sequence may be changed using the SET EOS command. A list of supported commands can be seen by typing 'HELP' or '?' at the Console prompt.

The command structure/operation is similar to that used in IEEE 488.2, and includes some of the 488.2 Common Commands such as *IDN?, *RST, *CLS, and *OPC?, in addition to device specific commands. In 488.2, programming commands take one of two forms: a Program message or a Query message. Program messages are used to send commands to the device, while Query messages are used to elicit a response. Query commands are those that contain a '?' character. In general, the device does not generate any response to a program message unless the message contains a valid Query command. (Note that this does not apply when operating in Console mode, or when using some commands such as SHOW which are designed to provide the user general information). You can use this feature to provide a method to synchronize command execution with the controller by appending a Query to the desired command, and waiting for the response. For example, sending "**CLS;*OPC?" will place a "1" in the output queue when the *CLS command has been executed. Query commands that return multiple values will have the values separated by an ASCII COMMA character (0x2E). If multiple Query commands are included in the same message, the individual query responses will be separated with an ASCII SEMICOLON character (0x3B).

An Error Queue is provided that logs the results of command/execution errors in a FIFO fashion. The queue entries can be read using the ERR? command, which returns both an error code and a descriptive text message, such as

101, "invalid command"

When the queue is empty, ERR? returns the message **0, "no error"**. The queue can be emptied by repeatedly sending ERR? until all entries are read from the queue, or via sending the *CLS message. Note: There is a single Error Queue shared by all the command interfaces, such as the network socket connections, TELNET, and the serial Console. Since the TELNET and serial Console interfaces operate in an interactive fashion, if you are using multiple interfaces simultaneously the error messages may not appear on the expected interface. For example, errors generated by messages sent to the TCP server port may be shown on the serial console if it is in active use.

Unless otherwise specified, commands revert to their default setting at system reset/poweron, with the exception of the system setup and configuration commands (see SET). The various SET commands are used to update the settings in non-volatile memory (NVM), and do not typically take effect until the next system reset event unless otherwise noted.

4-4. COMMAND EXECUTION AND BUFFERING: Typically, simple commands execute in 1-2 msecs, however certain commands such as switching an electromechanical relay-based attenuator may take significantly longer than this. During this time, input commands are buffered for later execution. Buffering typically provides space for approximately 20 commands, but this is command and interface dependent. When operating at fast communication rates it is possible to exceed the buffering ability causing commands to be missed. For interfaces such as RS232, you can use hardware flow control to prevent this from occurring. For other interfaces, you can use a command/query scheme as a synchronization method.

4-5. COMMAND REFERENCE: In the command descriptions that follow, argument types are described using the following additional conventions to indicate the relative size of the parameter:

| | |
|--------|--|
| byte | - used to indicate an 8-bit unsigned integer |
| word | - used to indicate a 16-bit unsigned integer |
| int8 | - 8-bit integer |
| int16 | - 16-bit integer |
| int32 | - 32-bit integer |
| string | - character data, including the max number of characters allowable. (ie string8 has a max of 8 chars) |

Numeric arguments default to decimal (base 10) notation, but may optionally be provided in hex or binary if appropriate by using a "0x" prefix for hex or "0b" for binary. In addition, commands that accept a '0' or '1' argument will also accept the text strings 'OFF' and 'ON' in place of the numeric parameter. For example, "CONSOLE 1" and "CONSOLE ON" are equivalent.

Required command keywords are shown in CAPITAL letters, and arguments are shown in *italics*. Square brackets '['] may be used to indicate an optional parameter, for example [*select*]. Optional parameters, if not supplied by the user, assume the default setting specified in the text

4-6. APPLICATION SPECIFIC COMMANDS: For the following attenuation control commands there are a number of methods for specifying the attenuator *select* parameter. In the simplest form, *select* specifies a single numeric channel number from 1 to *n*, where *n* is the maximum number of installed attenuation channels (i.e., 1-12). For users familiar with API 8210A-based controllers, the *select* parameter may also be specified using the string prefix 'AT' along with the channel number (ie AT1. See the ATTN command for more information). In addition to specifying single attenuators, multiple attenuators may be selected by placing them into a named group, and then using that group name as the *select* parameter. When using a group, all attenuators in the group will be set to the same dB value. Currently, the system allows for two groups: a user-defined group and a predefined group named ALL. See the GROUP command for more information.

Attenuation value settings are specified in dB, with up to 2 digits of precision after the decimal point for attenuators that support step sizes of < 1dB. When specifying integral dB values, usage of the decimal point format is strictly option (ie '10' is the same as '10.00'). The attenuation setting must be a multiple of the attenuators intrinsic step size or the command will generate an error. For example, an attenuator that has a stepsize of 0.25 dB will accept settings of 0.25 and 0.5, but will generate an error if set to 0.3. For responses, attenuation values will be formatted to the base precision of the attenuator.

Certain attenuator types, such as relay-based models, have switching speed and cycle rate limitations which must be accounted for when programming. Switching speed requirements are built into the command execution time and are always enforced such that if you execute a command sequence such as "ATTN 1 10;*OPC?" the response will not be sent until the attenuator has been programmed and has changed state. Typical switching speeds for these types of attenuators are in the 5-20 msec range, depending on the model. For relay-based attenuators, in addition to the switching speed there is also a maximum rate at which commands can be sent to an individual attenuator referred to as the cycling rate. This is a much longer period of time, and is typically in the 100-150msec range (6-10 operations/second). Note that this delay is on a per attenuator basis, and will only be seen if an attempt is made to reprogram an attenuator before this time limit expires. Solid-state attenuators do not have these limitations, and can be switched at the maximum rate that commands are executed, which is typically in the 1-2 ms range. You can use the RFCONFIG? ATTN command to view the parameters associated with the attenuator type installed in the system.

ATTN

Function: set attenuator

Syntax: ATTN *select setting*

Argument(s): *select* attenuator select 1-*n*, AT1-AT*n*, or a group name
setting attenuator setting, in dB. *setting*=0-max attenuation value, or MAX

Remarks: This command sets the specified RF attenuator(s) to the dB value provided by *setting*. If *setting* is MAX, then the maximum dB value for that attenuator will be used.

Return Value: none

Example(s):

```
ATTN 1 10           // sets attn 1 to 10 dB
ATTN ALL MAX        // sets all attenuators to their max value
ATTN AT1 15.75      // sets attn 1 to 15.75 dB (82 10A compatibility mode)
```

ATTN?

Function: read attenuator setting

Syntax: ATTN? *attnno*

Argument(s): *attnno* attenuator select 1-*n* or AT1-AT*n*

Remarks: This command returns the current setting of the specified attenuator

Return Value: attenuator setting, in dB

Example(s):

```
ATTN 1 10           // sets attn 1 to 10 dB
ATTN? 1             // read attn 1 setting
10                  // returns attn 1 setting (10 dB)
```


REF**Function:** set attenuator reference**Syntax:** REF *select***Argument(s):** *select* attenuator select 1-*n*, AT1-AT*n*, or a group name**Remarks:** This command sets a reference for the specified RF attenuator(s). The reference value is set to the attenuator's current setting. This command can be used with the RELATTN command.**Return Value:** none**Example(s):**

```
ATTN 1 10; REF 1    // sets attn 1 reference to the current setting (10 dB)
REF ALL             // sets reference for all attenuators to their current settings
```

REF?**Function:** read attenuator reference setting**Syntax:** REF? *attnno***Argument(s):** *attnno* attenuator select 1-*n* or AT1-AT*n***Remarks:** This command returns the current reference attenuation level of the specified attenuator**Return Value:** attenuator setting, in dB**Example(s):**

```
ATTN 1 10           // sets attn 1 to 10 dB
REF 1               // sets attn 1 ref (ref=10 dB)
REF? 1              // read reference setting
10                  // returns attn 1 reference setting (10dB)
```

RELATTN**Function:** set attenuator relative to ref**Syntax:** RELATTN *select setting***Argument(s):** *select* attenuator select 1-*n*, AT1-AT*n*, or a group name*setting* attenuator setting, in dB. *Setting* = +/- dB**Remarks:** This command sets the specified RF attenuator(s) to the specified dB value relative to the attenuator's reference setting.**Return Value:** none**Example(s):**

```
ATTN 1 10           // sets attn 1 to 10dB
REF 1               // sets attn 1 ref (ref=10dB)
RELATTN 1 5         // sets attn +5dB from the ref setting, (10dB + 5dB = 15dB absolute)
RELATTN 1 -5        // sets attn -5dB from the ref setting, (10dB - 5dB = 5dB absolute)
```

RELATTN?**Function:** read attenuator relative attenuation setting**Syntax:** RELATTN? *attnno***Argument(s):** *attnno* attenuator select 1-*n* or AT1-AT*n***Remarks:** This command returns the current relative attenuation setting of the specified attenuator**Return Value:** attenuator setting, in dB (+/-)**Example(s):**

```
RELATTN 1 10        // sets attn +5dB from the ref setting
RELATTN? 1          // read attn 1 relative attn setting
10                  // returns attn 1 relative setting (10dB)
```

STEPSIZE**Function:** set attenuator stepsize**Syntax:** STEPSIZE *select setting***Argument(s):** *select* attenuator select 1-*n*, AT1-AT*n*, or a group name
setting attenuator stepsize, in dB. *Setting*=0-max attenuation value**Remarks:** This command sets the attenuation stepsize for the specified RF attenuator(s). This command can be used with the INCR and DECR commands to change the step value. Specifying a *setting* of 0 sets the step size to the intrinsic step value for the attenuator, in effect removing any previous STEPSIZE command.**Return Value:** none**Example(s):**

```

STEPSIZE 1 10      // sets attn 1 stepsize to 10dB
STEPSIZE ALL 0     // sets the stepsize for all attenuators to their native value (typ 1dB)

```

STEPSIZE?**Function:** read attenuator stepsize setting**Syntax:** STEPSIZE? *attnno***Argument(s):** *attnno* attenuator select 1-*n* or AT1-AT*n***Remarks:** This command returns the current stepsize of the specified attenuator**Return Value:** attenuator setting, in dB**Example(s):**

```

STEPSIZE 1 10      // sets attn 1 stepsize to 10dB
STEPSIZE? 1        // read attn 1 stepsize setting
10                // returns attn 1 stepsize (10dB)

```

INCR**Function:** increment attenuator setting**Syntax:** INCR *select***Argument(s):** *select* attenuator select 1-*n*, AT1-AT*n*, or a group name**Remarks:** This command increments the current setting of the specified attenuator(s) by the attenuator's STEPSIZE setting.**Return Value:** none**Example(s):**

```

ATTN 1 5           // sets attn 1 to 5dB
STEPSIZE 1 10      // sets attn 1 stepsize to 10dB
INCR 1             // increments attn 1 by it's stepsize (5dB + 10dB = 15dB)

```

DECR**Function:** decrement attenuator setting**Syntax:** DECR *select***Argument(s):** *select* attenuator select 1-*n*, AT1-AT*n*, or a group name**Remarks:** This command decrements the current setting of the specified attenuator(s) by the attenuator's STEPSIZE setting.**Return Value:** none**Example(s):**

```

ATTN 1 15          // sets attn 1 to 15dB
STEPSIZE 1 10      // sets attn 1 stepsize to 10dB
DECR 1             // decrements attn 1 by it's stepsize (15dB - 10dB = 5dB)

```

GROUP**Function:** define an attenuator group**Syntax:** GROUP *name selectlist***Argument(s):** *name* string, up to 10 characters in length (case-insensitive)
selectlist list of attenuator channel numbers. Up to *n* entries max (number of installed channels)**Remarks:** This command creates a user-defined group of attenuators which allows most commands to operate on multiple attenuators. The group is referenced using the *name* parameter, and may contain a listing of 1 to the max number of attenuators supported. There is a single user-defined group, and defining a group removes any previous user group definition. In addition to the user-defined group, the system automatically creates a group named ALL and adds each attenuator to that group.**Return Value:** none**Example(s):**

```
GROUP mygroup 2 4 6 // define a group named 'mygroup' containing attenuators 2, 4, and 6
ATTN mygroup 10     // sets the group (attenuators 2 , 4, and 6) to 10dB
```

GROUP?**Function:** read user-defined attenuator group definition**Syntax:** GROUP?**Argument(s):** none**Remarks:** This command returns the current user-defined group definition, including the group name and member attenuator list.**Return Value:** *name selectlist***Example(s):**

```
GROUP mygroup 1 2 3 4 // define a group 'mygroup' containing attenuators 1, 2, 3 and 4
GROUP?               // read group definition
MYGROUP, 1, 2, 3, 4   // returns name and a list of attenuators in the group
```

SHOW STAT**Function:** displays current settings**Syntax:** SHOW STAT**Argument(s):** none**Remarks:** This command displays the current settings of the RF hardware**Example(s):**

```
>show stat

ATTN 1: 63
ATTN 2: 63
ATTN 3: 63
ATTN 4: 63
ATTN 5: 63
ATTN 6: 63
ATTN 7: 63
ATTN 8: 63
ATTN 9: 63
ATTN 10: 63
ATTN 11: 63
ATTN 12: 63
```

SHOW RFCONFIG**Function:** displays current RF configuration**Syntax:** SHOW RFCONFIG**Argument(s):** none**Remarks:** This command displays the current RF hardware configuration**Example(s):**

```
>show rfconfig
RF config
channel count: 12
attn config: 4202-63 (0-63/1dB, 0.4-6GHz)
```

SET DEFAULT**Function:** set the power on default settings for the RF hardware devices**Syntax:** SET DEFAULT ATTN *dbval***Remarks:** This command can be used to change the default power on attenuation settings to *dbval*. The parameter *dbval* may also be specified as MAX, in which case the maximum value for the attenuators will be used.**Return Value:** none**Example(s):**

```
SET DEFAULT ATTN 20 // sets attn default to 20dB
SET DEFAULT ATTN MAX // sets attn default to maximum setting
```

SET RFCONFIG**Function:** set rf hardware installation**Syntax:** SET RFCONFIG CHAN *numchannels* // set the number of installed attenuator channelsSET RFCONFIG ATTN *type* // sets the installed attenuator type**Remarks:** This command can be used to change the RF configuration to support different chassis configurations**Return Value:** none**Example(s):**

```
SET RFCONFIG CHAN 9 // sets number of installed attn channels to 9
```

RFCONFIG?**Function:** read chassis configuration items**Syntax:** RFCONFIG? CHAN // returns the number of installed attenuator channelsRFCONFIG? ATTN *n* // returns configuration info for attn *n* (model, range, etc)

RFCONFIG? LIST TYPE // returns a list of supported attenuator models

Remarks: These commands can be used to retrieve various chassis configuration settings. For RFCONFIG? ATTN, the command returns the attn type, max attenuation, stepsize, switching speed (msec), cycle rate (msec), and a descriptive string.

4-7. 488.2 COMMON COMMANDS***CLS**

Function: clears the error status
Syntax: *CLS
Argument(s): none
Remarks: This function is used to clear the Error Queue
Return Value: none
Example(s):
 *CLS

***IDN?**

Function: Reads the system identification information
Syntax: *IDN?
Argument(s): none
Remarks: This function is used to read the system identification info, which is a string consisting of the following data: manufacturer, model, serial number, and firmware version.
Return Value: *idstr* string id info
Example(s):
 *IDN?
 API Weinschel, 6990, 002, V1.00

***OPC?**

Function: Operation complete query
Syntax: *OPC?
Argument(s): none
Remarks: This function loads a '1' into the output queue when the Program Message Unit is executed. It's primary use is to provide an indication of command completion by including the command as the last one in a series of commands. It can be useful to synchronize operation and to prevent input buffer overflow.
Return Value: 1 integer constant command completed
Example(s):
 CMD1 1; CMD2 2; *OPC?
 1 // sends a '1' response when the three commands have been parsed and executed

***ESR?**

Function: Event Status Register query
Syntax: *ESR?
Argument(s): none
Remarks: This function reads the 488.2 Event Status Register. Reading the register also clears it.
Return Value: *int8* integer status register
Example(s):
 *ESR?
 32 // indicates a Command Error

***RST**

Function: Performs a device application level reset.
Syntax: *RST
Argument(s): none
Remarks: This function is used to reset the device application settings. For a full device reset, see the REBOOT command.
Return Value: none
Example(s):
 *RST

TST?*Function:** Self-test query**Syntax:** *TST?**Argument(s):** none**Remarks:** This function performs an internal self-test. Upon completion, the results of the test are loaded into the output queue.**Return Value:** *testresults* integer '0' indicates test passed. Non-zero indicates test failed.**Example(s):**

```
*TST?
0                // returns a '0' when the test completes successfully.
```

ERR?**Function:** Read the Error Queue**Syntax:** ERR?**Argument(s):** none**Remarks:** This function returns the last entry in the error status queue, and a string description of the error code. Repeating the command will return the next entry, until the error queue is empty and returns a zero. The error queue may be cleared via the *CLS command. Note that when using the command-line interface the Error Queue contents are automatically displayed after each command prior to issuing the CLI prompt.**Return Value:** error number, "error description"**Example(s):**

```
ERR?
101, "invalid command"
ERR?
0, "no error"
```

LLO**Function:** Local lockout**Syntax:** LLO *enable***Argument(s):** *enable* byte, 0-1 (or OFF/ON)**Remarks:** This command controls the local lockout function which can be used to disable front panel control. Setting local lockout ON disables local operation, while setting it OFF enables local use. By default, this parameter is OFF. **Return Value:** none**Example(s):**

```
LLO 1            // turns on local lockout, disabling front panel
LLO OFF          // turns off lockout, enabling front panel operation
```

LLO?**Function:** Local Lockout query**Syntax:** LLO?**Argument(s):** none**Remarks:** This function returns the current setting of the Local Lockout function.**Return Value:** integer '0' indicates lockout off. Non-zero indicates lockout is active.**Example(s):**

```
LLO OFF; LLO?
0                // returns a '0' indicating lockout is off
```

4-8. SETUP AND CONFIGURATION COMMANDS:

NOTE: The SET commands are used to update settings which are stored in non-volatile memory (NVM), and do not typically take effect until the next system restart event (see REBOOT) unless otherwise noted. The settings listed here are dependent on the installed hardware, so not all settings are available on some implementations, such as the LCD and CANbus interfaces.

SET EOS

Function: sets the Program Message Terminator and/or Response Message Terminator end of string characters

Syntax: SET EOS *interface inout val*

Argument(s): *interface* protocol selection SERIAL, TCP, UDP, or ALL
inout PMT (input) or RMT (output)
val word, eos characters

Remarks: This function sets the input Program Message Terminator (PMT) or the output Response Message Terminator (RMT) sequences. Each communications port/protocol can have separate definitions. The *val* parameter specifies the character sequence used, and can specify up to two characters, typically as a hex word high byte-low byte pair. Common definitions for the terminators include the ASCII CR (0x0D) and LF (0x0A) characters. A single character may be specified either by using 0 for the high byte, such as 0x000D, or by only specifying a single character (ie 0x0D). On input, the message will terminate when either of the two character codes are received, while for output the characters are sent low byte then high byte, unless it is specified as 0. Note that the serial CONSOLE and network TELNET servers are excluded from this selection and always use a fixed CRLF (0x0A0D) sequence. The current settings may be viewed using the SHOW EOS command.

Return Value: none

Example(s):

```
SET EOS SERIAL PMT 0x0A0D // set serial input to terminate on either CR or LF
SET EOS SERIAL RMT 0x0A0D // set serial output sequence as CR-LF
SET EOS TCP PMT 0x0A0D    // set tcp socket input to terminate on either CR or LF
SET EOS TCP RMT 0x0D      // set tcp output sequence as a single CR character
SET EOS UDP PMT 0x0A      // set udp socket input to terminate on Lf character only
SET EOS UDP RMT 0x0D      // set udp output sequence as a single LF character
```

4-8.1. Serial Port**SET SERIAL BAUDRATE**

Function: RS232 serial port baud rate setting

Syntax: SET SERIAL BAUDRATE *rate*

Argument(s): *rate* int32

Remarks: This function sets the baud rate for the RS232 serial port. The *rate* parameter may be any value from 9600 to 230400, with the standard rates being 9600, 19200, 38400, 57600, 115200, and 230400. This command will take effect immediately, and does not require a reboot. Note that this setting may be overridden by hardware DIP switches located on the controller assy.

Return Value: none

Example(s):

```
SET SERIAL BAUDRATE 115200
```

SET SERIAL FLOW

Function: RS232 flow control

Syntax: SET SERIAL FLOW *enable*

Argument(s): *enable* byte, 0-1 (or OFF/ON)

Remarks: This function can be used to selectively enable or disable the serial port hardware RTS/CTS flow control signals. A value of 0 (or OFF) disables flow control, while any other value (or ON) enables RTS/CTS handshaking. Flow control can be used to prevent loss of input data while the system is busy executing commands.

Return Value: none

Example(s):

```
SET SERIAL FLOW 1 // enable RTS/CTS flow control
```

4-8.2. Network

SET IPADDR

Function: Sets the network IP address/mode

Syntax: SET IPADDR [*ipaddr* | DHCP | AUTOIP]

Argument(s): *ipaddr* static IP address, in the form DDD.DDD.DDD.DDD
 DHCP selects DHCP address mode (default)
 AUTOIP selects AUTOIP mode

Remarks: This function sets the default IP address mode, allowing the choice between static or dynamic modes. There is some interaction between the various settings, but typically selecting one mode disables the others as follows:

Static IP

Setting a static fixed IP address automatically disables DHCP and AutoIP operation.

DHCP

Setting DHCP mode will enable both the DHCP and AutoIP modes. The existing static IP address (if any) will be erased. DHCP takes preference over any other selected mode. If the system is unable to obtain an address from a DHCP server on the network, it will switch over to AutoIP mode, where it will attempt to assign a link-local address.

AutoIP

Setting AUTOIP mode will enable the AutoIP function and disable DHCP operation for networks where a DHCP server is not available. The existing static IP address (if any) will be erased.

You can also use the SET DHCP and SET AUTOIP commands to combine modes and override the default addressing mode operation selected by this command. If doing so, you should use the SET IPADDR command prior to using SET DHCP or SET AUTOIP, as it has precedence. For example, you can use the SET IPADDR *ipaddr* to set a fixed IP, followed by SET DHCP ON to enable DHCP. The system would attempt to use DHCP, and if unable to obtain an address would use the static IP address *ipaddr*. Likewise, you can use SET IPADDR DHCP followed by SET AUTOIP OFF, in which case the system would only use DHCP and would never switch over to AutoIP mode. You can use the SHOW IPADDR command to view the current address in use, as well as the status of the DHCP and AUTOIP clients.

Return Value: none

Example(s):

```
SET IPADDR 10.0.0.2      // sets static IP, disables DHCP and AUTOIP
SET IPADDR DHCP          // enables DHCP (and AutoIP)
SET IPADDR AUTOIP        // enables AutoIP (disables DHCP)
```

SET DHCP

Function: DHCP client control

Syntax: SET DHCP *enable*

Argument(s): *enable* byte, 0-1 (or OFF/ON)

Remarks: This function can be used to selectively enable or disable the DHCP client. A value of 0 (or OFF) disables DHCP, while any other value (or ON) enables DHCP.

Return Value: none

Example(s):

```
SET DHCP 1              // enable DHCP
SET DHCP ON              // enable DHCP
SET DHCP OFF             // disables DHCP
```


SET AUTOIP**Function:** AutoIP client control**Syntax:** SET AUTOIP *enable***Argument(s):** *enable* byte, 0-1 (or OFF/ON)**Remarks:** This function can be used to selectively enable or disable the AutoIP client. A value of 0 (or OFF) disables AutoIP, while any other value (or ON) enables AutoIP.**Return Value:** none**Example(s):**

```

SET AUTOIP 1           // enable AutoIP
SET AUTOIP ON          // enable AutoIP
SET AUTOIP 0           // disables AutoIP

```

SET NETMASK**Function:** Sets the network IP address subnet mask**Syntax:** SET NETMASK *ipmask***Argument(s):** *ipmask* subnet mask, in the form DDD.DDD.DDD.DDD**Remarks:** This function sets the default IP subnet mask used when static IP addressing is selected. The default value is 255.255.255.0**Return Value:** none**Example(s):**

```

SET NETMASK 255.255.255.0

```

SET GATEWAY**Function:** Sets the network Gateway IP address**Syntax:** SET GATEWAY *ipaddr***Argument(s):** *ipaddr* IP address, in the form DDD.DDD.DDD.DDD**Remarks:** This function sets the default gateway/router IP address. Network packets that have a destination not reachable by the current IP configuration are sent to this address. The default value is 0.0.0.0, which disables the gateway function.**Return Value:** none**Example(s):**

```

SET GATEWAY 10.0.0.100

```

SET TCP SERVER**Function:** Sets the TCP server port number**Syntax:** SET TCP SERVER *portno***Argument(s):** *portno* initial server port, 1024-65530**Remarks:** This function sets the port number used to communicate with the internal TCP server(s). If multiple servers are installed then each server opens successive ports from this initial setting. For example, if 3 servers are installed, and *portno* = 10001, then server #1 opens port 10001, server #2 opens port 10002, and server #3 opens port 10003 (The system is set to use a single server by default. Consult the factory if multiple servers are required). The default port is 10001.**Return Value:** none**Example(s):**

```

SET TCP SERVER 1024           // sets the server to listen for connections on port 1024

```

SET TCP KEEPALIVE

Function: Sets the TCP keepalive rate

Syntax: SET TCP KEEPALIVE *tout*

Argument(s): *tout* keepalive timer value, in seconds (0, 10-7200)

Remarks: This function sets the value of the TCP keepalive timeout parameter. The TCP server uses this setting in order to keep a socket open by periodically sending keepalive packets during periods of inactivity. The value can be set for 10 to 7200 seconds (2 hours), or 0 to disable the keepalive function. The default is 30 seconds.

Return Value: none

Example(s):

```
SET TCP KEEPALIVE 60 // sets the keepalive timer to 60 seconds
```

SET TCP TIMEOUT

Function: Sets the TCP server inactivity timeout

Syntax: SET TCP TIMEOUT *tout*

Argument(s): *tout* inactivity timer value, in seconds (0 - 60)

Remarks: This function sets the value of the TCP server inactivity timeout parameter. The TCP server uses this setting in order to automatically close a connection if the client is inactive for a period of time. The value can be set for 0 to 60 seconds, with 0 (or OFF) disabling the inactivity timeout function. The default is 0 (inactivity timeout disabled).

Return Value: none

Example(s):

```
SET TCP TIMEOUT 10 // close connection if host is inactive for 10 seconds
```

SET TCP ECHO

Function: Sets the TCP server character echoing

Syntax: SET TCP ECHO *onoff*

Argument(s): *onoff* byte, 0-1 (or OFF/ON)

Remarks: This function controls the setting of character echoing for the TCP server(s). With echo on, the server echos each received character back to the sender on a character by character basis, while with the setting off no such echoing occurs. This is useful for testing connectivity, but can result in a large number of packets transactions and degrade performance. By default, TCP echo is OFF.

Return Value: none

Example(s):

```
SET TCP ECHO OFF // disables character echoing
SET TCP ECHO 1 // enables character echoing
```

SET UDP SERVER

Function: Sets the UDP server port number

Syntax: SET UDP SERVER *portno*

Argument(s): *portno* server port, 1024-65530

Remarks: This function sets the port number used to communicate with the internal UDP server. The default port is 20000.

Return Value: none

Example(s):

```
SET UDP SERVER 1024 // sets the server to listen for messages on port 1024
```

SET TELNET**Function:** Set TELNET server controls

Syntax: SET TELNET ECHO *onoff* // local server echo
 SET TELNET OPTNEG *onoff* // TELNET options negotiation
 SET TELNET KEEPALIVE *onoff* // TELNET NOP keepalive
 SET TELNET LOGIN *onoff* // require login
 SET TELNET TIMEOUT *secs* // session inactivity timeout

Argument(s): *onoff* byte, 0-1 (or OFF/ON)

Remarks: This function controls various settings of the TELNET server operation. The current settings can be viewed using the SHOW NET TELNET command. Note that there are two TELNET server implementations available, a full and a reduced-functionality version, and not all parameters are supported by the reduced version. The default settings are: echo on, optneg on, NOP keepalive on, logon off, and an inactivity timeout of 300 seconds.

Return Value: none**SET NETSTAT****Function:** network status message events control**Syntax:** SET NETSTAT *enable***Argument(s):** *enable* byte, 0-1 (or OFF/ON)

Remarks: This function can be used to control the display of network status messages on the serial console, including link up/down and port connect/disconnect messages. A value of 0 (or OFF) disables messages, while any other value (or ON) enables them. The default setting is on.

Return Value: none**Example(s):**

```
SET NETSTAT 1 // enables logging of network events to the console
```

Example NETSTAT messages:

```
**netstat: link up
**netstat: link down
**netstat: port 23: socket 2 connected to 10.0.0.101
**netstat: port 23: disconnected
```

IPCONFIG?**Function:** return network settings**Syntax:** IPCONFIG?**Argument(s):** none

Remarks: This query command returns the current network settings, including the IP address, subnet mask, gateway address, DHCP enable, AutoIP enable, TCP server port, and the UDP server port.

Return Value: IP addr, netmask, gateway, DHCP enable, AutoIP enable, TCP port, UDP port**Example(s):**

```
IPCONFIG?
10.100.103.80, 255.255.255.0, 0.0.0.0, 0, 0, 10001, 20000
```

4-9. SHOW COMMANDS: The SHOW commands provide a method to view a variety of system settings and information. They are primarily meant for CLI usage such as the console mode or telnet, as the contents are system dependent and may change depending on the current mode, settings, and installed implementation features.

SHOW EOS

Function: Shows a summary of the EOS PMT and RMT message terminator settings

Example(s):

```
>show eos
serial pmt: 0x0A0D
serial rmt: 0x0A0D
tcp pmt: 0x0A0D
tcp rmt: 0x000D
udp pmt: 0x0A0D
udp rmt: 0x000D
```

SHOW SET

Function: Shows a summary of various configuration SET command settings

Example(s):

```
>show set
serial baudrate: 115200
IP address = 10.0.0.2
subnet mask = 255.255.255.0
gateway = 0.0.0.0
addr_conf = 0x03 (DHCP)
tcp keepalive timeout = 30
server port = 10001
telnet_conf = 0x0F
telnet timeout = 300
hostname = core18
```

SHOW NET

Function: Shows general network settings

Example(s):

```
>show net
```

```
link status: up
phy speed: 100
phy duplex: full
```

```
MAC address: 00:04:A3:12:2D:45
IP address : 10.0.0.2
subnet mask: 255.255.255.0
gateway : 0.0.0.0
```

```
DHCP: enabled
```

SHOW IPADDR**Function:** Shows IP address mode and status**Example(s):**

// Example #1: SET IPADDR DHCP status: no DHCP server found, using AUTOIP
>show ipaddr

IP address : 169.254.127.57
subnet mask: 255.255.0.0
default IP : 0.0.0.0

DHCP client: enabled
server IP: none detected
addr stat: not bound

AutoIP client: enabled
addr stat: bound

// Example #2: SET IPADDR 10.0.0.2, SET DHCP ON status: no DHCP server found, using static IP
>show ipaddr

IP address : 10.0.0.2
subnet mask: 255.255.255.0
default IP : 10.0.0.2

DHCP client: enabled
server IP: none detected
addr stat: not bound

AutoIP client: disabled

// Example #2: SET IPADDR 10.0.0.2, SET DHCP ON status:, DHCP server detected, using DHCP
>show ipaddr

IP address : 192.168.0.2
subnet mask: 255.255.255.0
default IP : 10.0.0.2

DHCP client: enabled
server IP: 192.168.0.1
addr stat: bound

AutoIP client: disabled

SHOW NET TCP**Function:** Shows TCP server settings/status**Example(s):**

```
>show net tcp
```

```
tcp keepalive: 30
```

```
tcp echo: on
```

```
tcp server timeout: 0
```

```
tcp server port: 10001
```

```
number of servers: 1
```

```
connections per server: 1
```

```
port 10001: no connection
```

```
port 10001: socket 1 connected to 10.100.103.113
```

SHOW NET UDP**Function:** Shows UDP server settings/status**Example(s):**

```
>show net udp
```

```
udp server port: 20000
```

SHOW NET TELNET**Function:** Shows TELNET server settings/status**Example(s):**

```
>show net telnet
```

```
timeout: 300
```

```
flags
```

```
  echo: 1
```

```
  keepalive: 1
```

```
  neg options: 1
```

```
  login: 0
```

```
max connections: 1
```

```
port 23: no connection
```

SHOW NET TCP**Function:** Shows TCP server settings/status**Example(s):**

```
>show net tcp
```

```
tcp keepalive: 30
```

```
tcp echo: on
```

```
tcp server timeout: 0
```

```
tcp server port: 10001
```

```
number of servers: 1
```

```
connections per server: 1
```

```
port 10001: no connection
```

```
port 10001: socket 1 connected to 10.100.103.113
```

SHOW NET UDP

Function: Shows UDP server settings/status

Example(s):

>show net udp

udp server port: 20000

SHOW NET TELNET

Function: Shows TELNET server settings/status

Example(s):

>show net telnet

timeout: 300

flags

echo: 1

keepalive: 1

neg options: 1

login: 0

max connections: 1

port 23: no connection

SHOW CAN (optional)**Function:** Shows CANbus settings/status**Example(s):**

```
>show can
```

```
brgcon: 0x07 0xED 0x06
```

```
bit timing:
```

```
BRP: 7
```

```
Tq : 400ns
```

```
Total Tq: 20
```

```
SJW: 1
```

```
SyncSeg: 1
```

```
PropSeg: 6
```

```
PH1Seg : 6
```

```
PH2Seg : 7
```

```
sample mode: 3x
```

```
PH2 mode: 1 (free)
```

```
NBT: 8000ns
```

```
baud rate: 125k
```

```
canbus settings: nvm
```

```
filter : 0x000
```

```
mask : 0x000
```

```
baud : 125k
```

```
trace: 1
```

```
rx msgs: 0
```

```
tx msgs: 0
```

```
rx errs: 0
```

```
tx errs: 0
```

```
can tx errcnt: 0
```

```
can rx errcnt: 0
```


4-10. MISC COMMANDS

CONSOLE

Function: Console mode enable

Syntax: CONSOLE *mode*

Argument(s): *mode* byte 0, 1, 2, 3 or OFF, ON, ENABLE, DISABLE

Remarks: This function enables/disables the serial port console mode command-line interface and optionally updates the nvm setting. Setting *mode*=0 turns console off, *mode*=1 turns console on, *mode*=2 enables the console, and *mode*=3 disables the console. Modes 0 and 1 (OFF and ON) update the nvm setting, while modes 2 and 3 (ENABLE and DISABLE) do not. Note: This setting may be overridden by a hardware DIP switch located on the controller assembly.

Return Value: none

Example(s):

```
CONSOLE ON           // turns on the console and updates nvm setting
CONSOLE ENABLE       // turns on console for this session only
CONSOLE 0            // turns off the console and updates nvm setting
CONSOLE DISABLE      // turns off console for this session only
```

CONSOLE?

Function: Console mode query

Syntax: CONSOLE?

Argument(s): none

Remarks: This function returns the serial console mode nvm and DIP switch settings

Return Value: *nvm, dipsw* integer, integer

Example(s):

```
CONSOLE?
1, 0           // console nvm flag = 1, DIP switch = 0
```

DELAY

Function: Delays execution (Pause)

Syntax: DELAY *msecs*

Argument(s): *msecs* word, 0-65535 in msecs

Remarks: This command pauses execution for the specified time in msecs.

Return Value: none

Example(s):

```
ATTN 1 0; DELAY 100; ATTN 1 10    // waits 100 msecs between attn commands
```

REBOOT

Function: system reset

Syntax: REBOOT

Argument(s): none

Remarks: This command performs a system reboot, similar to a poweron reset.

Return Value: none

Example(s):

```
REBOOT
```

RUN

Function: run an auxiliary program function

Syntax: RUN *cmd*

Argument(s): *cmd* command function
LOADER

Remarks: This command runs an external function, such as the Flash Bootloader for downloading program updates

Return Value: none

Example(s):

```
RUN LOADER           // invokes the flash bootloader for update
```

LCD**Function:** Adjust LCD display (if installed)**Syntax:** LCD CONTRAST *n*
LCD BKLIGHT *n***Argument(s):** *n* byte, 0-255**Remarks:** This function can be used to adjust the viewing parameters of the LCD display. Default values are CONTRAST 128 and BKLIGHT 255.**Return Value:** none**Example(s):**LCD CONTRAST 128
LCD BKLIGHT 0 // turns off backlight**TEMP?****Function:** reads internal temperature sensor**Syntax:** TEMP? [*sensor*]**Argument(s):** *sensor* byte optional sensor number, 0-2. default=0 (internal)**Remarks:** This function returns the current temperature, in degrees C. Resolution is 0.5 degrees**Return Value:** degC**Example(s):**TEMP?
30.0**TIME?****Function:** reads execution time**Syntax:** TIME?**Argument(s):** none**Remarks:** This function returns the current execution time from the start of the command message, in msecs.**Return Value:** msecs integer32**Example(s):**CMDSTATS 0; TIME?; DELAY 10; TIME?
1;11**TICKS?****Function:** reads system tick counter**Syntax:** TICKS?**Argument(s):** none**Remarks:** This function returns the current system ticks. The tick counter is a 32-value, and will rollover when the max count is reached.**Return Value:** ticks integer32**Example(s):**CMDSTATS 0; TICKS?; DELAY 10; TICKS?
5065902;5065915**REPEAT****Function:** Enables command repetition/looping**Syntax:** REPEAT *count***Argument(s):** *count* word, 1-65535**Remarks:** This function causes the remainder of the current command message to be repeated count number of times. Any commands included prior to REPEAT are executed a single time.**Return Value:** none**Example(s):**

ATTN 1 0; REPEAT 50; INCR 1; DELAY 100 // repeats INCR and DELAY 50 times

SYSTEST**Function:** performs a low-level system test**Syntax:** SYSTEST *select***Argument(s):** *select* test select, varies by platform

WDT // test the watchdog timer function

STACK // test the stack over/underflow reset function

ALL // test aux hardware board

FP // front-panel (if installed)

Remarks: This command performs a low-level test on the selected hardware. NOTE: These tests should be used with great caution, and should typically NOT be performed with any attached RF devices/hardware, as they may exercise them in an invalid fashion. They are typically used in serial console mode only. Consult the factory prior to performing any of these tests.**Return Value:** various status messages**4-11. MISC NETWORK COMMANDS****PING****Function:** Sends ICMP ECHO packets**Syntax:** PING *ipaddr***Argument(s):** *ipaddr* destination IP address, in the form DDD.DDD.DDD.DDD**Remarks:** This function performs a ping of the specified network address. It is primarily for console usage**Example(s):**

>ping 10.100.103.113

pinging 10.100.103.113...

reply time: 1 ms

reply time: 1 ms

reply time: 1 ms

reply time: 1 ms

TCP SERVER**Function:** TCP server control**Syntax:** TCP SERVER *cmd*

INIT // reinitializes all server ports

CLOSE // closes all server ports

OPEN // reopens server ports

Remarks: This function allows control of the TCP server. It is primarily for testing/troubleshooting purposes

4-12. UPDATING DEVICE FIRMWARE VIA SERIAL PORT

Requirements:

- a terminal emulator that supports XMODEM-CRC transfer (such as Windows Hyperterm, or the open-source TeraTerm)
- hex programming file (19311459xxx.HEX), where 'xxx' represents the specific file/revision.

Note: any CRC and version numbers displayed will change depending on the actual data file used.

The internal bootloader allows for downloading and programming of the unit via an RS232 serial port. It features a simple command-line interface, and supports downloading of standard Intel HEX format files that contain application Program Code memory (flash), Configuration memory settings, and Data memory (EEPROM) initialization sections. The bootloader supports transfers using the XMODEM-CRC protocol, so it can be used with any standard terminal emulator software such as Windows Hyperterminal. By default, transfers are done with a serial rate/format of 115200 N81.

To get into bootloader mode, from the main application command prompt, use the command RUN LOADER.

API Weinschel Model xxxxx Vx.xx
firmware: 19311459xxx

>run loader

When the bootloader executes in 'loader' mode, you should see a sign-on message similar to

>run loader

Weinschel core18K loader V0.01
firmware: 19311459301x

osc stat: 00000011

:

The loader uses the ':' colon character as it's prompt. Because of program space constraints of the bootloader, there are minimal messages and responses to most commands. A '#' character indicates an error was detected. Other status messages are typically issued in the form

stat: 11000000

The commands to the bootloader are short two or three ASCII character sequences, and can be either upper or lower-case. A simple line-editor allows the use of the BACKSPACE key, and commands are executed when a carriage-return (CR) is detected. Commands include:

| | |
|-----|---|
| AC | allow Configuration word update |
| AD | allow Data Memory update |
| BL | blank check |
| DL | download and program HEX file |
| DLW | download and program with 10 second wait |
| ED | erase Data Memory |
| EP | erase Program Memory |
| RS | reset (reboot) |
| RN | run application in Program Memory |
| XS | checksum Program Memory (display only) |
| XSU | checksum Program Memory and update ID locations |

Since there is limited memory available to the microcontroller, there is only space for a single application. This requires the program memory to be erased prior to downloading a new file, and the programming must be performed as the HEX file is being transferred. Because of this, any failure in the download/programming process will leave the PIC without an application, and the process will have to be repeated. To simplify the operation, the DL download command performs all the steps typically required to reprogram an application. It performs a blank check, erases the ID checksum location (to signify that the program memory is invalid), erases the program code memory if necessary, downloads (and programs) the code, and, if successful, computes and updates the checksum IDLOC. A typical display of the DL operation looks like the following (note that the actual crc displayed will vary with the file downloaded)

```
:dl
blank check...*not blank*
erasing program...
begin download...CCCCCCCC <begin XMODEM-CRC file transfer on PC>
stat: 11000000
crc: B6E3
```

Here you see the resulting status warnings indicating that Config and Data memory updates were disabled, and that programming was successful. Any other status result should produce a **'fail'** message in place of the crc display.

After issuing the DL command, you will see the **'begin download...'** message and a series of **'C'** characters as the loader attempts to initiate an XMODEM download. At this point, send the HEX file via XMODEM-CRC using your terminal emulator program. Many terminal emulators will automatically detect the XMODEM transfer type, but if it gives a choice, select XMODEM-CRC. For example, using Windows Hyperterm you would use the **'Transfer | Send File...'** menu, enter the HEX file in the **'Filename'** box (19311459xxx.HEX), select **'Xmodem'** as the Protocol, and click **'Send'**. Hyperterm will detect that the loader is using CRC error checking (as opposed to checksum). If you need to abort the download operation, send a few CTRL-C characters, and the loader should terminate the download.

Use XS command to check the status of the Program memory, which will perform a CRC checksum on the program memory contents as compared to the IDLOC CRC contents, which should match.

```
:xs
crc: B6E3
idloc: B6E3
```

To exit the bootloader and run the main application, use the RN command (or cycle power). When the unit reboots, you should see the new version signon message.

```
:rn
running app...
API Weinschel Model xxxxx Vx.xx
firmware: 19311459xxx
```

5. MAINTENANCE:

The following paragraphs provide general inspection and maintenance guide-lines for the Model 8331 Series.

5-1. INSPECTION: Perform a visual inspection in conjunction with the maintenance activities schedule when a malfunction is suspected, or whenever an assembly is removed or replaced.

5-2. PREVENTIVE MAINTENANCE: While the 8331 Series requires very little preventive maintenance, it should not be subjected to physical abuse, severe mechanical shock, high humidity, or operating temperatures outside the specification range. The instrument should be kept free of excessive dirt and dust, since these can interfere with connector functions and with normal heat dissipation. The following paragraphs provide the preventive maintenance that is to be performed on the Unit.

Care should be taken to prevent strain on the interconnecting cables, since damage here may not always be apparent. Occasionally check the external cables and connectors for signs of cracked insulation and/or bent or worn pins. Tests show that connectors must be clean for accuracy and stability. This requires an inspection and cleaning of each connector immediately before use. For connector cleaning instructions, refer to paragraph 4-3. When cleaning precautions are observed regularly, connectors can maintain their stability for over several thousand connection cycles. Refer to Appendix A for more information about cables and connectors.

5-3. SPECIAL CLEANING INSTRUCTIONS: The cleaning procedures for 8331 Series are divided into five general groups: microwave coaxial cable assemblies, circuit card and modules; machined surfaces and hardware, chassis cleaning, and connector cleaning.

5-3.1. MICROWAVE COAXIAL CABLE ASSEMBLIES: Appendix A (located at the end of this manual) provides all the necessary procedures for care, cleaning, and handling of microwave coaxial cable assemblies.

5-3.2 MACHINED SURFACES AND HARDWARE: To remove light dirt and dust from mechanical parts such as castings, covers and other hardware proceed as follows:



WARNING

Compressed air used for cleaning and/or drying can create airborne particles that may enter the eye. Goggles/ face-shields should be worn. DO NOT direct air stream towards self or other personnel. Pressure should be restricted to a maximum 15 psi to avoid personal injury.



CAUTION

Under no circumstances use a wire brush, steel wool, or abrasive compound. Using these items will cause extensive damage to the instrument's surface.

DO NOT use a nylon bristle brush in solvent as the bristles may dissolve and cause damage to the circuit card or component.

- a. Use 5 psi of clean, moisture-free compressed air or preferably dry nitrogen to blow loose dirt and dust from surface of item.
- b. Briskly brush isopropyl alcohol onto area to be cleaned with a fiber-bristle brush.
- c. Remove residue with lint-free cloth and repeat step "b" as a rinse.
- d. When parts are thoroughly clean, dry parts using 5 psi of clean, moisture-free compressed air or preferably dry nitrogen.

- e. Clean smaller mechanical parts or hardware by dipping into a container of isopropyl alcohol. Remove dirt by brushing with fiber-bristle brush after parts have been immersed for several hours.
- f. Remove parts from isopropyl alcohol and rinse by immersing into a different container of isopropyl alcohol.
- g. When parts are thoroughly cleaned, dry parts using 5 psi of clean, moisture-free compressed air or preferably dry nitrogen.

4-3.3 CONNECTOR CLEANING: Where small amounts of rust, corrosion, and/or oxide deposits are present on connectors, clean externally with a soft-bristle brush, aluminum wool, or internally with an acid brush; then wash with a non-corrosive solvent. Exercise care to ensure no metal filing or residue remains inside the connector and the connector is thoroughly dry. Where rust, corrosion, and/or oxide deposits are present in large quantities, replace the connector.

4-4. LINE VOLTAGE FUSE REPLACEMENT: The following steps provide procedures to replace the line voltage Fuse Assembly. This unit accepts a F1.5A, 250 Vac fuse.

**WARNING**

Sufficient power levels are present at the Power Input Assembly to cause personal injury. Ensure that the instrument power cord is DISCONNECTED before attempting to change fuses.

**CAUTION**

DO NOT connect or apply power to this instrument until the Power Entry Module Assembly has been adjusted to the operational line voltage.

- a. Disconnect the power cord from the Power Entry Module Assembly.
- b. Use a small screwdriver to pry open the Fuse Drawer.
- c. Slide out Fuse Drawer located in the center of the Power Entry Module Assembly.
- d. Remove defective fuse and replace with the correct fuse listed in the parts list.
- e. Snap the Fuse Drawer shut and re-connect ac power cord.

6. REPLACEABLE PARTS LIST & DRAWINGS:

6-1 REPLACEABLE PARTS LIST (RPL): Refer to IM-606 for the Model 8331 Series RPL. The IM-606 manual contains a breakdown for the different configurations of the Model 8331 Series into its assemblies and detailed parts.

6-2 ASSEMBLY AND COMPONENT LOCATION: The assembly/component location and schematic diagrams for the Model 8331 Series is located in the IM-606 manual by the drawing number. Drawing find numbers have also been included in the manuals RPL to help locate components or hardware.

This manual can be downloaded from the API / Weinschel website at:

<http://www.API.com/weinschel/pdfs/IM-606.pdf>

7. CONTACTING API / WEINSCHEL:

In the event of a malfunction, contact API / Weinschel. An apparent malfunction of an instrument or component may be diagnosed over the phone by first contacting the Customer Service Department at API / Weinschel. DO NOT send the instrument or component back to the factory without prior authorization. When it is necessary to return an item, state the symptoms, catalog and type number of the instrument or component, and date of original purchase. Also write the Company name and your name and phone number on a card and tape the card to the item returned. Page provides further information regarding preparation of a unit for reshipment. Contact API / Weinschel Customer Service Department as follows:

Via mail: API / Weinschel, Inc. 5305
Spectrum Drive Frederick,
MD 21703-7362 U.S.A.

Via Telefax: 301-846-9116

Via Phone: Call TOLL FREE 800-638-2048
Toll call # 301-846-9222

Via Website: www.weinschel.apitech.com

Via e-mail: weinschel-sales@apitech.com

8. API / WEINSCHEL WARRANTY:

PRODUCTS - API / Weinschel warrants each product it manufactures to be free from defects in material and workmanship under normal use and service anywhere in the world. API / Weinschel's only obligation under this Warranty is to repair or replace, at its plant, any product or part thereof that is returned with transportation charges prepaid to API / Weinschel by the original purchaser within ONE YEAR from the date of shipment.

The foregoing Warranty does not apply in API / Weinschel's sole opinion to products that have been subject to improper or inadequate maintenance, unauthorized modifications, misuse, or operation outside the environmental specifications for the product.

SOFTWARE PRODUCTS- API / Weinschel software products are supplied without representation or Warranty of any kind. API / Weinschel, therefore, assume no responsibility and will not accept liability (consequential or otherwise) arising from the use of program materials, disk, or tape.

The Warranty period is controlled by the Warranty document furnished with each product and begins on the date of shipment. All Warranty returns must be authorized by API / Weinschel prior to their return.

API / Weinschel's Quality System Certified to:






Certificate No. 289j



| REVISION HISTORY | | | | |
|------------------|-----|-------------|--------|----------|
| ZONE | REV | DESCRIPTION | DATE | APPROVED |
| | A | ERN 12-174 | OCT 12 | R. SINNO |

- NOTES:
1. ALL DIMENSIONS GIVEN IN MM [INCHES].
 2. CONNECTORS AND HOLE PLUGS INSTALLED AS REQUIRED AND DETERMINED BY NUMBER OF CHANNELS IN UNIT. 8 CHANNEL UNIT SHOWN.
 3. ALL MATERIALS & PROCESSES ARE TO BE IN COMPLIANCE WITH THE EUROPEAN DIRECTIVE RESTRICTION OF HAZARDOUS SUBSTANCES (RoHS). (REF: A/W 080-638)
 4. SEE A/W DWG 089-4418 FOR ATTENUATOR RF SPECIFICATIONS.



INTERFACE CONTROL DRAWING

API / Weinschel

ICD, ATTEN UNIT, SMA THRU
MECH SPEC, MODEL 8331 SERIES

| | |
|--------------|---------------|
| 193-8300-X-X | 8331-XX-XX-TS |
| NEXT ASSY | USED ON |
| APPLICATION | |

| | |
|---|--|
| UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ±1/64 .XX ± .01 ± 1/2° .XXX ± .005 | |
| MATERIAL | |
| FINISH | |
| DO NOT SCALE DRAWING | |

| | |
|-----------------------|-----------|
| CONTRACT NO. | |
| APPROVALS | DATE |
| DRAWN R. SHOCK | 10/5/2012 |
| CHECKED A. HOPKINS | 10/8/2012 |
| ENGR. R. SINNO | 10/8/2012 |
| ISSUED | |

| | | | |
|-----------|-------------------|--------------------|----------|
| SIZE D | FSCM NO. 93459 | DWG NO 089-4412 | REV A |
| SCALE 1/2 | | SHEET 1 OF 1 | |

PROPRIETARY NOTICE
THIS DOCUMENT IS COMMERCIAL CONFIDENTIAL AND THE
INFORMATION CONTAINED THEREIN MAY NOT BE DISSEM-
NATED, NOR IS REPRODUCTION PERMITTED EXCEPT BY
WRITTEN AUTHORIZATION.

APPENDIX A

CARE AND HANDLING OF MICROWAVE COAXIAL CABLE ASSEMBLIES

A-1 CARE AND HANDLING OF ASSEMBLIES.

To ensure accurate measurements and optimal performance of Weinschel products, the microwave coaxial cable assemblies used in system and test setups must be properly used and maintained. Proper connections, routine inspection of all cables, and cleaning of the connectors are extremely important procedures which can prolong the longevity and accuracy of equipment.

A-2 CABLE INSPECTION.

Routinely check external cables for signs of cracked insulation, dents, twists, flattening, signs of jacket abrasion, or other signs of abuse. Wrinkles in the jacket indicate that the minimum bend radius has been exceeded. Most often, this occurs near the marker tubes and connectors.

Also inspect the connector interfaces for the following:

- Bent pins (male).
- Bent or missing tines (female).
- Worn or chipped plating.
- Damaged or displaced dielectric inserts.
- Thread damage.
- Folded or mushroomed outer interface rims.
- Mushroomed pin shoulders (male) or tine ends (female).
- Score lines on pins and outer interface rims visible to the unaided eye.
- Recessed or protruding pins.

It is advisable to clean the connectors prior to inspection to make subtle damage more apparent. If any of the above is noted, replace the assembly before its further use results in equipment damage. Also inspect the mating connectors for similar damage.

Inspect the connector interface for signs of debris. Debris may be in the form of:

- Plating chips or other metal particles.
- Dust or dirt.
- Oily films.
- Other miscellaneous foreign particles.

If signs of debris are present, clean the connector interface as directed in Paragraph A-6.

A-3 MAKING INITIAL CONNECTIONS.

Exercise caution when mating cables. Poor connections lead to poor system performance. They can also damage not only the cable assembly, but more significantly, front or rear panel connectors on the equipment itself which may be more difficult to repair.

A-3.1 ALIGNING CONNECTORS. Align the center lines of two connectors before actual mating. Male retaining nuts contain a small amount of necessary play which may make it possible to mate the threads without the pins being properly aligned. Pin misalignment can damage pins and dielectric inserts.

A-3.2 MATING CONNECTORS. Gently mate the connectors by hand, taking care not to force the coupling nut at the slightest resistance. It is often possible to feel whether or not the pins are mated. If the coupling nut is difficult to turn, either the pins are not mated, the coupling nut is cross-threaded, or one of the connectors has been damaged by excess torque.

Never hold a male connector coupling nut stationary while screwing a female connector into it. This rotation can erode the plating and damage both the outer interface rim as well as the pin. If the pins become locked, serious damage can result to both the equipment and the cable assembly.

A-4 ENSURING PROPER CONNECTOR TORQUE.

A-4.1 OVERTORQUING. Once connectors have been properly mated, apply only the proper amount of torque. Overtorquing damages both connectors involved. Also, a connector which has been damaged by overtorquing, in turn, damages every connector to which it is subsequently mated. It usually leads to poor system performance as well. Overtorque can cause:

- Bent pins.
- Recessed or protruding pins.
- Recessed or protruding dielectrics.
- Chipped plating.
- Damaged coupling threads.
- Coupling nut retaining ring damage.
- Mushroomed outer interface shells.
- Mushroomed pin shoulders.

A-4.2 HEX-NUT TYPES. To mate a connector of the hex-nut type, always use a torque wrench set to the correct torque value. Tighten the connector slowly until the wrench snaps. Tightening too quickly can cause the wrench to exceed its set limit. Do not snap the wrench more than once as this also causes overtorque.

A-4.3 KNURLED NUTS. Tighten connectors with knurled nuts by hand. If this does not provide sufficient tightness use a hex-nut connector and torque wrench instead. Never use pliers to tighten a connector. Table A-1 recommends torque specifications for the various types of connectors.

Table A-1. Recommended Torque Values

| Connector | Recommended Torque |
|--|-----------------------------|
| GPC-7 (7mm) w/hex nut | 14 in/lbs \pm 1 in/lbs |
| Type N w/hex nut | 14 in/lbs \pm 1 in/lbs |
| SMA, 2.92mm, 3.5mm 2.4mm, WPM, WPM-3 WPM-4 | 7.5 in/lbs \pm 0.5 in/lbs |
| Type N & TNC (knurled) | Hand-tight |
| BNC (knurled) | Hand-tight |

A-5 PROPER CABLE HANDLING.

Never exceed the minimum bend radius specified for a cable. Guard against tight bends at the end of connector strain relief tubing, or at the ends of marker tubing where they may be less noticeable. Although cable bend may seem slight, the actual radius of the bend at the point of angular departure may be far smaller than the acceptable radius.

Never pinch, crush or drop objects on cable assemblies. Also, do not drag a cable over sharp edges as this will pinch it and cause it to exceed the minimum bend radius.

Never use a cable assembly to pull a piece of equipment. Cables and connectors are not designed to support or move equipment.

A-5.1 SECURING CABLES. Use toothed, rubber-lined "P-clamps" to hold cables in place. If it is necessary to use tie-wraps, use the widest possible wrap and the lowest setting on the gun to ensure the minimum pressure on the cable.

A-5.2 STORING CABLES. When storing cables, minimize cable "set" by coiling them in large diameters (1 or 2 feet). Unroll the cable properly when it is ready to be used; do not pull the loops out hastily. Similarly, re-roll them when storing them away again.

A-6 CLEANING CONNECTOR INTERFACES.

Use the following guidelines in cleaning connector interfaces:

- a. Do not use chlorinated solvents including common tap water. These solvents are extremely penetrating and sometimes ruin otherwise good devices and assemblies.
- b. Moisten a cotton swab with isopropyl alcohol. Roll the swab on a paper towel to remove excess.
- c. Use the moistened cotton swab to wipe away debris. Do not try to dissolve the debris by overwetting the swab.
- d. Repeat the cleaning process using additional swabs as necessary. If metallic particles are embedded in the dielectric, use an eyeglass and a sharp pick in an attempt to dislodge them. Swab again.
- e. When satisfied that the interfaces are clean, blow them dry with dry compressed air, or preferably dry nitrogen (pressurized spray cans work well). Do not use breath.
- f. Clean the mating connectors. These may be the source of the debris.

Model 8331 Series (IM-600) Revision Record

| REVISION | DATE | DESCRIPTION | APPLICABLE SERIAL NUMBERS |
|----------|----------|-------------------------------|---------------------------------|
| - - - | 10-24-12 | ERN 12-XXX: Preliminary Issue | All Units |