When to replace components

The following table lists the replaceable components and what symptoms to look for when they need to be replaced.

Printer component	Average life*	Symptom
Toner cartridges		
Change the color toner soon.	8,000 pages (CMY)** 10,000 pages (Black)**	 Front panel message: <color>: low</color> Uneven, streaky or mottled color Faded or missing color in a single color. One or more straight and even, vertical, light or dark streaks in one color.
Change the color toner now.	-	■ Front panel message: Stopped: replace <color></color>
Imaging unit		■ Refer to the "% Used " gauge on the Test Print
Replace the imaging unit.	60,000 images or 15,000 full color pages	■ Dark, vertical streaks on the print.
		 Dark color spots and streaks in all colors. A wide, light, horizontal band in one place on the page. All colors are faded; fine line detail disappears.
		■ Front panel message: Imaging Unit: replace
Fuser		Refer to the "% Used" gauge on the Test Print
Change the fuser soon.	30,000 pages	■ Front panel message: Fuser: replace
Change the fuser now.	40,000 pages	■ Front panel message: Stopped: replace Fuser!
Transfer kit		■ Refer to the "% Used " gauge on the Test Print
	40,000 pages	■ Front panel message: Transfer Kit: replace

^{*} These figures are based on an average of 5% coverage of the printable area for any one color. The frequency of replacement will vary, depending on the complexity of the prints you are making.

For more detailed information and examples for diagnosing print quality problems, refer to Problem and Solution information in the main topic list.

^{**} The starter cartridges that are shipped with the printer have an average life of approximately 3,000 pages, based on an average of 5% coverage.