



Flash Photography



Use flash in cloudy weather or indoors. If the low light signal lamp (red) lights in the right side of the viewfinder when you press the Shutter Release Button halfway in, you will have to use flash to take pictures.

- 1** If the signal lamp lights, set the Weather Symbol Ring at “⚡”.

- 2** Turn on the Flash Switch.



3 As soon as the Flash Ready Lamp lights, you are ready to take your flash picture. Bring your subject inside the viewfinder frame and depress the Shutter Release Button.


Take flash pictures at a distance of about 1.5 to 3 m.

- If you operate the Shutter Release Button before the Flash Ready Lamp lights, the flash will not fire at all or it will fire with insufficient light so that your picture will turn out underexposed.
- If you are not taking flash pictures, be sure to turn off the Flash Switch.
- Take care not to cover the flash reflector with your fingers.



When taking pictures in the vertical format, hold the camera with the flash side up.

Film Rewinding



When the end of the film is reached, the Film Advance Lever will not turn any further. Do not use force to wind it any more, and rewind it into the cassette as follows:

1 Press in the Film Rewind Release Button.

2 Unfold the Film Rewind Crank and turn it in the direction of the arrow. Stop rewinding if you feel a sudden release of tension, then open the camera back and remove the cassette. Send the exposed film for processing as soon as possible.

Camera Care

- When the glass surfaces of the viewfinder or the lens are smudged with fingerprint stains or other marks, promptly clean them by lightly wiping them with some lens-cleaning tissue, moistened with lens-cleaning solution. Remove dirt and dust from these surfaces with a blower brush.
- In summer, do not leave the camera on a hot beach, in a hot car or its storage compartment, because not only the camera mechanism, but also the film and battery performance may be adversely affected.
- To clean the camera body, wipe it clean with a soft cloth. Never use benzine, thinner and other solvents.
- After using it at the seaside or in a dusty place, wipe the camera clean. Salt air will have a corrosive effect on the camera, and sand and dust will be harmful to the camera mechanism.

- The camera incorporates a high-voltage circuit which is dangerous. In case of malfunction, NEVER try to disassemble it by yourself for repair.
- If the Flash Unit is not used for a long period, test the flash occasionally to maintain the capacitor efficiency.

< Battery Precautions >

- If you are not likely to use the camera for a long period of time, remove the batteries to prevent possible damage by battery leakage.
- Generally, low temperatures will reduce the battery performance. If you are shooting in cold weather, warm the batteries in your pocket, for example, and always keep spare batteries on hand.
- Wipe both ends of the batteries clean before loading them. Soiled battery contacts may cause poor electrical contact.

Specifications

Type: 35 mm lens-shutter camera with built-in flash.

Lens: Yashica 38 mm f/3.5, 3 elements in 3 groups.

Shutter: Mechanical, with 1/125 sec. fixed speed.

Exposure Control: CdS sensor; aperture setting with weather symbols (f/4—f/22); in low light situations (EV 11 or under), warning lamp turns on in viewfinder by pressing shutter release halfway in.

Film Speed Settings: ISO 100, 200, 400, and 1000.

Viewfinder: Inverted-Galilean type, direct viewfinder; 0.5X magnification, 90% picture area; low-light warning signal in viewfinder.

Focusing: Fixed focus with 1.5 m— ∞ covering range.

Film Advance: Film advance lever.

Film Loading: Easy loading.

Film Rewind: Film rewind crank.

Exposure Counter: Auto-resetting, additive type.

Built-in Flash: Sliding ON/OFF switch; guide number 12 (ISO 100, meters); aperture setting with flash symbol ($\frac{1}{2}$); 1.5—3 m flash range; recycling time: about 5 sec. (with new alkaline batteries, at normal temperature); provided with flash ready lamp.

Power Source: Two 1.5 V AA-size penlight batteries (for flash and low-light warning); Ni-Cd batteries cannot be used.


Dimensions: 125.5 (W) \times 71.5 (H) \times 51.5 (D) mm.

Weight: 200 g (without batteries).

** Specifications and design are subject to change without notice.*

Attaching the Strap

Attach the Strap to the camera by passing its end through the Strap Lug as shown.



Using the Camera Case

Use the Camera Case with its strap attached as shown in the illustration.

