User's Manual

Model UP550 Program Controller



User's Manual for Cascade Control

IM 05E01C02-44E



<Toc> <Rev>

Introduction

Thank you for purchasing the UP550 program controller.

■ How to Use the Manuals

Purpose	Title	Description
Setup	1. Installation	Describes the tasks (installation, wiring, and others) required to make the controller ready for operations.
Basic operation	2. Initial Settings	Describes examples of setting PV input types and control output types. Making settings described herein and program creation in "3. Programming" allows you to carry out basic control.
Program creation	3. Programming	Describes examples of creating basic programs. The use of the program pattern setup charts included in the "3.7 Program Pattern Setup Charts" is recommended.
General understand- ing of programming operations	3.5 Program Parameter Map 3.6 Lists of Program Parameters	Contains a parameter map that serves as a guide to creating programs. Also includes a brief explanation of the functions of program parameters.
Operating procedures and troubleshooting	4. Operations	Describes key operation sequences. For operation control through external contact inputs, see "1.5 Terminal Wiring Diagrams".
Brief operation	6.1 Parameter Map	Contains the parameter map used as a guideline for setting parameters.
Function description and setpoint recording	6.2 Lists of Parameters	Briefly describes the functions of parameters. In addition, each parameter table has a User Setting column, where you can record your setpoints when setting them in the controller.

■ Controllers Applicable to Cascade Control

The specification codes of the UP550 applicable to cascade control are given in the table below.

UP550-01	UP550-11	UP550-21
----------	----------	----------

■ Regarding This User's Manual

- (1) This manual should be provided to the end user. Keep an extra copy or copies of the manual in a safe place.
- (2) Read this manual carefully to gain a thorough understanding of how to operate this product before starting operation.
- (3) This manual describes the functions of this product. Yokogawa Electric Corporation (hereinafter simply referred to as Yokogawa) does not guarantee the application of these functions for any particular purpose.
- (4) Under absolutely no circumstances may the contents of this manual, in part or in whole, be transcribed or copied without permission.
- (5) The contents of this manual are subject to change without prior notice.
- (6) Every effort has been made to ensure that the details of this manual are accurate. However, should any errors be found or important information be omitted, please contact your nearest Yokogawa representative or our sales office.

<Toc> <Rev>

■ Safety Precautions

The following symbol is indicated on the controller to ensure safe use.



This symbol on the controller indicates that the operator must refer to an explanation in the user's manual in order to avoid the risk of injury or death of personnel or damage to the instrument. The manual describes how the operator should exercise special care to avoid electric shock or other dangers that may result in injury or loss of life.

The following symbols are used in the hardcopy user's manuals and in the user's manual supplied on the CD-ROM.



NOTE

Indicates that operating the hardware or software in a particular manner may damage it or result in a system failure.



IMPORTANT

Draws attention to information that is essential for understanding the operation and/or features of the controller.

■ Force Majeure

- (1) Yokogawa assumes no liability to any party for any loss or damage, direct or indirect, caused by the use or any unpredictable defect of the product.
- (2) No portion of the software supplied by Yokogawa may be transferred, exchanged, leased or sublet for use by any third party without the prior permission of Yokogawa.
- (3) Be sure to use the spare parts approved by Yokogawa when replacing parts or consumables.
- (4) Use this software with one specified computer only. You must purchase another copy of the software for use on each additional computer.
- (5) Copying this software for purposes other than backup is strictly prohibited.
- (6) Store the floppy disk(s) (original medium or media) containing this software in a secure place.

<Toc> <Rev>

■ Regarding Protection, Safety, and Prohibition Against Unauthorized Modification

(1) In order to protect the product and the system controlled by it against damage and ensure its safe use, make certain that all of the instructions and precautions relating to safety contained in this document are strictly adhered to. Yokogawa does not guarantee safety if products are not handled according to these instructions.

- (2) Modification of the product is strictly prohibited.
- (3) Reverse engineering such as the disassembly or decompilation of software is strictly prohibited.

IM 05E01C02-44E 3rd Edition: May 31, 2006-00

Model UP550 Program Controller User's Manual for Cascade Control

IM 05E01C02-44E 3rd Edition

CONTENTS

Intro	oduction	۱ i
1.	Instal	llation 1-1
	1.1	Model and Suffix Codes 1-1
	1.2	How to Install 1-2
	1.3	How to Connect Wires 1-5
	1.4	Hardware Specifications 1-7
	1.5	Terminal Wiring Diagrams 1-13
2.	Initial	Settings 2-1
	2.1	Names and Functions of Front Panel Parts2-2
	2.2	Setting UP mode (Setting First at Power-on)2-3
	2.3	Changing UP mode2-4
	2.4	Setting Primary and Secondary PV Input Types 2-6
	2.5	Setting Control Output Type (except for a Position Proportional Controller) 2-10
	2.6	Calibrating Valve Position (for a Position Proportional Controller Only) 2-12
	2.7	Initializing Parameters 2-14
3.	Progi	ramming 3-1
	3.1	Overview of Program Patterns 3-1
	3.2	Example of Program Pattern Setup Charts
	3.3	Creating Program Patterns
	3.4	Changing Program Patterns3-11
	3.5	Program Parameter Map 3-14
	3.6	Lists of Program Parameters 3-16
	3.7	Program Pattern Setup Charts 3-21
	3.8	Explanation of Program Functions 3-24
4.	Opera	ations 4-1
	4.1	Monitoring-purpose Operating Displays Available during Operation 4-1
	4.2	Performing/Canceling Auto-tuning of Secondary-loop 4-10
	4.3	Performing/Canceling Auto-tuning of Primary-loop 4-12
	4.4	Setting PID of Secondary-loop Manually 4-13
	4.5	Setting PID of Primary-loop Manually 4-15
	4.6	Selecting Program Pattern Number (PT.No) 4-16
	4.7	Switching between RUN and RESET Modes 4-17
	4.8	Switching between Cascade (CAS) and Local (LSP) 4-18

	4.9	Switch	ing between AUTO and MAN of Secondary-loop	4-19
	4.10	Manipu	ulating Control Output during Manual Operation	4-20
	4.11	Enablir	ng/Disabling Hold Mode of Program Operation	4-23
	4.12	Changi	ing Program Setpoint when in Hold Mode	4-24
	4.13	Execut	ing "Advance" Function	4-25
	4.14	Switch	ing to Local-mode (LOCAL) of Primary-loop Operation	4-26
	4.15	Changi	ing Setpoint during Local-mode of Primary-loop Operation .	4-27
5.	Troubl	eshoot	ing and Maintenance	5-1
	5.1	Trouble	eshooting	5-1
	5.2	Mainte	nance	5-6
		5.2.1	Cleaning	5-6
		5.2.2	Replacing Brackets	5-6
		5.2.3	Attaching Terminal Cover	5-7
		5.2.4	Replacing Parts with a Limited Service Life	5-8
		5.2.5	Replacing Control Output Relays	5-9
6.	Param	eters		6-1
	6.1	Parame	eter Map	6-1
	6.2	Lists o	f Parameters	6-6
7.	Functi	on Bloc	ck Diagram and Descriptions	7-1
Revis			n	_

1. Installation

This chapter describes installation, wiring, and other tasks required to make the controller ready for operation.

1.1 Model and Suffix Codes

Before using the controller, check that the model and suffix codes match your order.

Model	Suffix C	Code	Description
UP550			Program controller (provided with retransmission output and 15 V DC loop power supply as standard)
	-0 Standard type		
Туре	-1		Position proportional type
	-2		Heating/cooling type
Ontional functions		0	None
Optional functions 1		1	With communication, auxiliary analog input, and 1 additional DI

Check that the following items are provided:

- Unit label...... 1

■ Correspondence between the Model and Suffix Codes, and the Contact Input/Output Terminals Provided

Check the model ordered and the presence/absence of contact inputs and outputs in the following table.

✓ indicate that the contacts are available.

Model and Suffix		Contact input terminals					Contact output terminals								
Codes	DI1	DI2	DI3	DI4	DI5	DI6	DI7	DI8	DO1	DO2	DO3	DO4	DO5	DO6	DO7
UP550-□ 0	1	1	1	1	1	1	1		1	1	1	1	1	1	1
UP550-□ 1	/	1	/	/	1	1	1	1	1	/	/	1	1	1	1

Note: For details on the functions of contact inputs/outputs, see "1.5 Terminal Wiring Diagrams."

1.2 How to Install



NOTE

To install the controller, select a location where:


- 1. no one may accidentally touch the terminals,
- 2. mechanical vibrations are minimal,
- 3. corrosive gas is minimal,
- 4. temperature can be maintained at about 23°C and the fluctuation is minimal.
- 5. no direct radiant heat is present,
- 6. no magnetic disturbances are caused,
- 7. no wind blows against the terminal board (reference junction compensation element),
- 8. no water is splashed,
- 9. no flammable materials are around,


Never place the controller directly on flammable items or equipment.

If the controller has to be installed close to flammable items or equipment, be sure to provide shielding panels all around the controller, at least 150 mm away from every side; the panels should be made of either 1.43 mm-thick metal-plated steel plates or 1.6 mm-thick uncoated steel plates.


Installation Position

Install the controller at an angle within 30° from horizontal with the front panel facing upward. Do not install it facing downward. The position of right and left sides should be horizontal.





■ External Dimensions and Panel Cutout Dimensions




■ How to Install



Turn off the power to the controller before installing it on the panel because there is a possibility of electric shock.

After opening the mounting hole on the panel, follow the procedures below to install the controller:

- 1. Insert the controller into the opening from the front of the panel so that the terminal board on the rear is at the far side.
- 2. Set the brackets in place on the top and bottom of the controller as shown in the figure below, then tighten the screws of the brackets. Take care not to overtighten them.



1.3 How to Connect Wires



 Before carrying out wiring, turn off the power to the controller and check that the cables to be connected are not alive with a tester or the like because there is a possibility of electric shock.

- 2) For the protection and safe use of the controller, be sure to place a circuit breaker (conforms with IEC60947, 5A, 100V or 220V AC) near the controller where the breaker can easily be operated. In addition, be sure to indicated that it is the instrument to cut the power supply of the controller.
- 3) Wiring must be carried out by personnel who have basic electrical knowledge and practical experience.




NOTE


- Provide power from a single-phase instrument power supply. If there is a lot of noise in the power line, insert an insulating transformer into the primary side of the line and use a line filter (recommended part: ZAC2205-00U from TDK) on the secondary side. As a countermeasures against noise, do not place the primary and secondary power cables close to each other.
- 2) For thermocouple input, use shielded compensating lead wires for wiring. For RTD input, use shielded wires that have low conductor resistance and cause no significant differences in resistance between the three wires.

 The cables to be used for wiring, terminal specifications, and recommended parts are as shown below.
- 3) Control output relays may be replaced. However, because they have a life of 100,000 times that of the resistance load, use auxiliary relays to turn on/off a load.
- 4) The use of inductance (L) loads such as auxiliary relays, motors and solenoid valves causes malfunction or relay failure; always insert a CR filter for use with alternating current or a diode for use with direct current, as a spark-removal surge suppression circuit, into the line in parallel with the load.
- 5) When there is a possibility of being struck by external lightning surge, use the arrester to protect the instrument.

■ For DC Relay Wiring




■ For AC Relay Wiring



Cable Specifications and Recommended Cables

Purpose	Name and Manufacturer
Power supply, grounding, relay contact outputs	600 V PVC insulated wires, JIS C 3307, 0.9 to 2.0 mm ²
Thermocouple	Shielded compensating lead wires, JIS C 1610, □X-□-□-□ (See Yokogawa Electric's GS 6B1U1-E.)
RTD	Shielded wires (three conductors), UL2482 (Hitachi Cable)
Other signals	Shielded wires

Recommended Terminal Lugs



Terminal Covers

Target Model	Part Number	Sales Unit
For UP550	T9115YD	1

1.4 Hardware Specifications

PV Input Signals (Primary PV Input)

- Number of inputs: 1 (terminals 11)-12-13)
- Input type: Universal input system. The input type can be selected with the software.
- Sampling period: Can be selected from 100, 200 and 500 ms. Initial value: 200 ms
- Burnout detection: Functions at TC, RTD, standard signal (0.4 to 2 V or 1 to 5 V)
 Upscale, downscale, and off can be specified.

 For standard signal, burnout is determined to have occurred if it is 0.1 V or less.
- Input bias current: 0.05 μA (for TC or RTD b-terminal)
- Measurement current (RTD): About 0.13 mA
- Input resistance: 1 M Ω or more for thermocouple or mV input About 1 M Ω for DC voltage input
- Allowable signal source resistance: 250 Ω or less for thermocouple or mV input Effects of signal source resistance: 0.1 μ V/ Ω or less 2 k Ω or less for DC voltage input Effects of signal source resistance: About 0.01%/100 Ω
- Allowable wiring resistance: for RTD input Maximum 150 Ω /wire: Conductor resistance between three wires should be equal However, 10 Ω /wire for a maximum range of -150.0 to 150.0°C. Wire resistance effect: \pm 0.1°C/10 Ω
- Allowable input voltage: ± 10 V DC for thermocouple, mV, or RTD input ± 20 V DC for DC voltage input
- Noise rejection ratio: 40 dB (50/60 Hz) or more in normal mode 120 dB (50/60 Hz) or more in common mode
- Reference junction compensation error: ±1.0°C (15 to 35°C)
 ±1.5°C (0 to 15°C, 35 to 50°C)
- Applicable standards: JIS, IEC, DIN (ITS-90) for thermocouples and RTD

Auxiliary Analog Input Signals (Secondary PV Input)

Available only for controllers with auxiliary analog input terminals.

- Number of inputs: 1 (terminals 21-22)
- Input type: Settable in a range of 0-2, 0-10, 0.4-2.0, or 1-5 V DC
- Sampling period: 100, 200 and 500 ms
 The sampling period of an auxiliary analog input signal is associated with the PV input's sampling period.
- Input resistance: About 1 M Ω
- Input accuracy: ±0.3% of input span ±1 digit for 0 to 2 V DC
 ±0.2% of input span ±1 digit for 0 to 10 V DC
 ±0.375% of input span ±1 digit for 0.4 to 2.0 V DC
 ±0.3% of input span ±1 digit for 1 to 5 V DC
 Under standard operating conditions (23±2°C, 55±10% RH, power frequency of 50/60 Hz)

Feedback Resistance Input

Provided for position proportional type only (terminals 45-46-47)

• Slide resistance value: 100 Ω to 2.5 k Ω of overall resistance (burnout detection for sliding wire provided)

• Measuring resolution: ±0.1% of overall resistance

Loop Power Supply

Power is supplied to a two-wire transmitter.

(15 V DC: terminals 14-15)

A resistor (10 to 250 Ω) connected between the controller and transmitter converts a current signal into a voltage signal, which is then read via the PV input terminal. Supply voltage: 14.5 to 18.0 V DC, max. 21 mA (provided with a protection circuit against a field short-circuit)

Retransmission Output

Either PV, program setpoint, or control output is output. Either the retransmission output or the loop power supply can be used with terminals (4)-(5).

- Number of outputs: 1 or 2 (terminals 4)-45, terminals 6-47)
- Output signal: 4-20, 0-20, 20-4, or 20-0 mA DC (where, outputting signal levels of less than 0 mA is not feasible)
- Load resistance: 600 Ω or less
- Output accuracy: ±0.1% of span (±5% of span for 1 mA or less.)
 Under standard operating conditions (23±2°C, 55±10% RH, power frequency of 50/60 Hz)

Control Output

Universal output system, The output type can be selected with the software. Relay contact output(s) for the position proportional type.

· Current output

(Standard type: terminals (6-(7); Heating/cooling type: heating-side output: terminals (6-(7), cooling-side output: terminals (6-(4))

Number of outputs	or 2 (two for heating/cooling type), switched between a voltage pulse output and current output.
Output signal	4-20, 0-20, 20-4, or 20-0 mA DC
Load resistance	600 Ω or less
Output accuracy	±0.1% of span (±5% of span for 1 mA or less) Under standard operating conditions (23±2°C, 55±10% RH, power frequency of 50/60 Hz)

Voltage pulse output

(Standard type: terminals (6-17); Heating/cooling type: heating-side output: terminals (6-17), cooling-side output: terminals (6-47)

Number of outputs	1 or 2 (two for heating/cooling type), switched between a voltage pulse output and current output.
Output signal	On-voltage = 12 V or more (load resistance: 600 Ω or more) Off-voltage = 0.1 V DC or less
Resolution	10 ms or 0.1% of output, whichever is larger

• Relay contact output (Standard type: terminals ①-②-③, Heating/cooling type: heating-side output: terminals ①-②-③, cooling-side output: terminals ④-④-⑤, position proportional type: terminals ④-④-⑤)

Number of outputs	1 or 2 (two for heating/cooling type)
Output signal	Three terminals (NC, NO, and common)
Contact rating	250 V AC or 30 V DC, 3 A (resistance load)
Resolution	10 ms or 0.1% of output, whichever is larger

Contact Inputs

- Purpose: Program pattern no. selection, and run/reset switching, and others
- Number of inputs: Differs with model and suffix codes as shown in the table below.

Model and Suffix Codes	Number of Inputs
UP550-□0	7
UP550-□1	8

- Input type: Non-voltage contact or transistor open collector input
- Input contact rating: 12 V DC, 10 mA or more
- On/off determination: For non-voltage contact input, contact resistance of 1 k Ω or less is determined as "on" and contact resistance of 20 k Ω or more as "off." For transistor open collector input, input voltage of 2 V or less is determined as "on" and leakage current must not exceed 100 μ A when "off."
- Minimum status detection hold time: PV input's sampling period ×3

Contact Outputs

- Purpose: Event output, FAIL output, and others
- Number of outputs: 7
- Relay contact rating: 240 V AC, 1 A, or 30 V DC, 1 A
- Transistor contact rating: 24 V DC, 50 mA

Display Specifications

- PV display: 5-digit, 7-segment, red LEDs, character height of 20 mm
- Setpoint display: 32×128 dot LCD with back lighting
- Status indicating lamps: LEDs

Safety and EMC Standards

Safety: Complies with IEC/EN61010-1 (CE), approved by C22.2 No.61010-1, approved by UL508.

Installation category: CAT. II Pollution degree: 2 (IEC/EN61010-1, C22.2 No.61010-1)

Measurement category: I (CAT. I: IEC/EN61010-1)

Rated measurement input voltage: 10V DC max.(across terminals), 300V AC

max.(across ground)


Rated transient overvoltage: 1500V (Note)

Note: It is a value on the safety standard which is assumed by IEC/EN61010-1 in Measurement category I, and is not the value which guarantees an apparatus performance.



This equipment has Measurement category I, therefore do not use the equipment for measurements within Measurement categories II, III and IV.

Measurement category		Description	Remarks
I	CAT. I	For measurements performed on circuits not directly connected to MAINS.	
П	CAT. II	For measurements performed on circuits directly connected to the low voltage installation.	Appliances, portable equipments, etc.
Ш	CAT. Ⅲ	For measurements performed in the building installation.	Distribution board, circuit breaker, etc.
IV	CAT.IV	For measurements performed at the source of the low-voltage installation.	Overhead wire, cable systems, etc.



EMC standards: Complies with EN61326, EN61000-3-2, EN61000-3-3 and EN55011 (CE).

AS/NZS 2064 compliant (C-Tick). Class A Group 1.

The instrument continues to operate at a measuring accuracy of within $\pm 20\%$ of the range during tests.

Construction, Installation, and Wiring

- Construction: Dust-proof and drip-proof pront panel conforming to IP55. For side-byside close installation the controller loses its dust-proof and drip-proof protection.
- · Material: ABS resin and polycarbonate
- Case color: Black
- Weight: About 1 kg or less
- Dimensions: 96 (W) \times 96 (H) \times 100 (depth from panel face) mm
- Installation: Panel-mounting type. With top and bottom mounting hardware (1 each)
- Panel cutout dimensions: $92^{+0.8}_{0}$ (W) \times $92^{+0.8}_{0}$ (H) mm

- Installation position: Up to 30° upward facing (not designed for facing downward)
- Wiring: M3.5 screw terminals (for signal wiring and power/ground wiring as well)

Power Supply Specifications

- Power supply: Rated voltage of 100 to 240 V AC (±10%), 50/60 Hz
- Power consumption: Max. 20 VA (8.0 W max.)
- Internal fuse rating: 250 V AC, 1.6A time-lug fuse
- Data backup: Lithium battery with life expectancy of 10 years
- Withstanding voltage
 - Between primary terminals* and secondary terminals**:
 At least 1500 V AC for 1 minute
 - Between primary terminals* and grounding terminal:
 At least 1500 V AC for 1 minute
 - Between grounding terminal and secondary terminals**:
 At least 1500 V AC for 1 minute
 - Between secondary terminals**:
 At least 500 V AC for 1 minute
 - * Primary terminals indicate power terminals and relay output terminals
 - ** Secondary terminals indicate analog I/O signal, voltage pulse output, and contact input terminals
- Insulation resistance: 20 $\text{M}\Omega$ or more at 500 V DC between power terminals and grounding terminal
- Grounding: Class D grounding (grounding resistance of 100 Ω or less)

Signal Isolations

- PV input (primary PV input) terminals: Isolated from other input/output terminals. Not isolated from the internal circuit.
- Auxiliary analog input (secondary PV input) terminals: Isolated from other input/output terminals and the internal circuit
- 15 V DC loop power supply terminals: Not isolated from analog current output and voltage pulse control output. Isolated from other input/output terminals and internal circuit.
- Analog current output terminals (for control output and retransmission): Not isolated between current outputs and from 15 V DC loop power supply and voltage pulse control output. Isolated from other input/output terminals and internal circuit.
- Voltage pulse control output terminals: Not isolated from current outputs and 15 V DC loop power supply. Isolated from other input/output terminals and internal circuit.
- Relay contact control output terminals: Isolated between contact output terminals and from other input/output terminals and internal circuit.
- Contact input terminals: Not isolated between contact input terminals and from communication terminals. Isolated from other input/output terminals and internal circuit.
- Relay contact output terminals: Not isolated between relay contact outputs. Isolated from other input/output terminals and internal circuit.
- Transistor contact output terminals: Not isolated between transistor contact outputs. Isolated from other input/output terminals and internal circuit.

• RS-485 communication terminals: Not isolated from contact input terminals. Isolated from other input/output terminals and internal circuit.

- Feedback slide resistance input terminals: Not isolated from analog current output terminals (control, retransmission), 15 V DC loop power supply, nor voltage pulse control outputs. Isolated from other input/output terminals and internal circuit.
- Power terminals: Isolated from other input/output terminals and internal circuit.
- Grounding terminals: Isolated from other input/output terminals and internal circuit.

Environmental Conditions

Normal operating conditions:

Ambient temperature: 0 to 50°C (40°C or less for side-by-side close installation)

Temperature change rate: 10°C/h or less

Ambient humidity: 20 to 90% RH (no condensation allowed)

Magnetic field: 400 A/m or less

Continuous vibration at 5 to 14 Hz: Full amplitude of 1.2 mm or less

Continuous vibration at 14 to 150 Hz: 4.9 m/s² or less Short-period vibration: 14.7 m/s², 15 seconds or less

Shock: 147 m/s² or less, 11 ms

Installation height: Height above sea level of 2000 m or less

Warm-up time: 30 minutes or more after power on

• Transportation and storage conditions:

Temperature: -25 to 70°C

Temperature change rate: 20°C/h or less

Humidity: 5 to 95% RH (no condensation allowed)

- Effects of changes in operating conditions
 - Effects from changes in ambient temperature:
 - On voltage or thermocouple input, $\pm 1~\mu\text{V/}^{\circ}\text{C}$ or $\pm 0.01\%$ of F.S./°C, whichever is larger
 - On auxiliary analog input, ±0.02% of F.S./°C
 - On RTD input, $\pm 0.05^{\circ}$ C/°C (ambient temperature) or less
 - On analog output, ±0.05% of F.S./°C or less
 - Effects from power supply fluctuation (within rated voltage range)
 - On analog input, $\pm 1~\mu\text{V}/10~\text{V}$ or $\pm 0.01\%$ of F.S./10 V, whichever is larger
 - On analog output, ±0.05% of F.S./10 V or less

1.5 Terminal Wiring Diagrams




Do not use unassigned terminals as relay terminals.

Terminal wiring diagrams are shown on and after the next page.

IM 05E01C02-44E 3rd Edition: May 31, 2006-00

■ UP550 Standard Type (Model UP550-0□), Cascade Control




IM 05E01C02

-44E

1-1

Installation>


■ UP550 Heating/Cooling Type (Model UP550-2□), Cascade Heating/Cooling Control



The types of control output, "relay output" and "voltage pulse output" shown in the table above refer to those of time proportional control.


To change to a relay output for on-off control, select "Relay Terminals" and change the setpoint of the proportional band to "0."

■ UP550 Position Proportional Type (Model UP550-1□), Cascade Position Proportional Control




2. Initial Settings

This chapter describes examples of setting PV input types, control output types. Carrying out settings described herein allows you to perform basic control. Refer to examples of various settings to understand how to set parameters required. Refer to "6.1 Parameter Map" for an easy to understand explanation of setting various parameters. If you cannot remember how to carry out an operation during setting, press the set you more than four times. This brings you to the display (operating display) that appears at power-on. After carrying out the settings described here, create programs in "3. Programming."



2.1 Names and Functions of Front Panel Parts



	Name of Part		Function		
1.	Indicator lamp for PV2 display		Is lit when secondary PV is displayed on PV display.		
			: Is lit (in green) when a program setpoint is increasing.		
2.	Program monitor	lamps	: Is lit (in green) when a program setpoint is constant.		
			: Is lit (in green) when a program setpoint is decreasing.		
			Display the statuses of PV events, time events and instrument alarm in orange.		
3.	Event indicator la	mps	PVE1 and PVE2 lamps: Come on when PV event 1 and PV event 2 turn on.		
			TME1 to TME4 lamps: Come on when time event 1 to time event 4 turn on.		
			AL1 lamp: Comes on when instrument alarm 1 turns on.		
	Status indicator lamps		Is lit (in green) to indicate the status of operation or control.		
			PRG:Is lit when in program mode.		
4.			RST:Is lit when in reset mode. HLD:Is lit when in hold mode.		
4.			LOC:Is lit when in local mode.		
			MAN: Is lit when in manual mode.		
			CAS:Is lit when in cascade mode.		
			Interface for an adapter cable used when setting and storing parameters from a PC.		
5.	Light-loader interface		This requires an optional parameter setting tool.		
	6. Process variable (PV)		Displays PV.		
6.			Displays an error code (in red) if an error occurs.		
	diopidy		Displays the name and value of a program setpoint (SP), output (OUT), deviation trend, valve		
7.	Setpoint display (I CD)	opening, or a parameter.		
٧.	Setpoint display (LOD)	Displays an error code if an error occurs.		
	Instrument alarm		The AL1 lamp comes on in orange if instrument alarm 1 occurs.		
8.	indicator lamp		The ALT lamp comes on in drange if instrument alarm 1 occurs.		
	marcator tamp	SET/ENT	Used to switch or register a parameter. Pressing the key for more than 3 seconds allows you to switch		
9.	SET/ENT key		between the operating display and the main menu for operating parameter setting display alternately.		
10.	MODE key	MODE	Presents a display for switching between the hold, advance, local, AUTO and MAN modes.		
			Used to switch between displays. Pressing this key while any operating display is shown		
			lets you switch to another prearranged operating display. Pressing this key while any		
11.	DISP key	DISP	display other than an operating display is shown lets you go one display back.		
			(One to four presses (maximum) of this key lets you return to the current operating display,		
			though the number of presses depends on the operating status.)		
			Used to change numerical values. On setting displays for various parameters, you can change target		
			setpoints, parameters, and output values (in manual operation). Pressing the ∇ key decreases a		
12.	$ abla$ and Δ keys		numerical value, while pressing the △ key causes it to increase. You can hold down a key to gradually		
			increase the speed of change. These keys also switch between menu displays when a main menu or		
			submenu of parameter setting display is shown.		
13.	PT.No key	▽PT.N	Use this key when the controller is at a reset to select a program pattern number on		
			an operating display.		
14.	RUN key	RUN	Pressing this key for more than 2 seconds while an operating display is shown starts the		
			controller.		
15	RESET key	RESET	Pressing this key for more than 2 seconds while an operating display is shown stops the		
			controller.		

2.2 Setting UP mode (Setting First at Power-on)




NOTE

The controller displays an operating display when the power is turned on. The submenu "IN" appears at this point if the type of PV input has not been defined yet. In this case, set a UP mode to "Cascade Control," following the operating procedure described below. Then, set PV input type, control output type and others.


The following operation describes a procedure of setting a UP mode to "Cascade Control". (set "4")

1. Bring the operating display into view (display appears at power-on).




In steps 2 and later, illustrations of the LCD are cited to explain the procedure.


2. Press the key once to display the submenu "MD".




3. Press the key once to display the parameter "UPM" (controller mode).



4. Press the △ or ▽ key to display the setpoint "4".



5. Press the key once to register the setpoint "4".




6. The controller re-starts (which is normal). Then, set PV input type. See "2.4 Setting Primary and Secondary PV Input Types."

2.3 Changing UP mode


The following operation describes a procedure of changing a UP mode to "Cascade Control". (set "4")

1. Bring the operating display into view (display appears at power-on).




In steps 2 and later, illustrations of the LCD are cited to explain the procedure.


2. Press the key for more than 3 seconds to call up the main menu "PROG".




3. Press the ▼ key once to display the main menu "STUP".




4. Press the key once to display the main menu "PARA".




5. Press the key once to display the main menu "UPMD".




6. Press the key once to display the submenu "MD".




7. Press the key once to display the parameter "UPM" (controller mode).



8. Press the or key to display the setpoint "4".



9. Press the key once to register the setpoint.



10. The controller re-starts (which is normal). Then, set PV input type. See "2.4 Setting Primary and Secondary PV Input Types."





How to return to a menu

Press the press


2.4 Setting Primary and Secondary PV Input Types

The following operating procedure describes an example of setting the primary-loop PV input type to K-type thermocouple (-200.0 to 500.0 °C) and a measurement range of 0.0 to 200.0 °C.

You can take the same steps for the socondary-loop PV input type (IN3) and scale (SH3, SL3) that are displayed after the primary-loop related parameters.

Primary PV input (Factory-set: undefined)

Secondary PV input (Factory-set: 1 to 5 V DC)






NOTE

The controller may automatically initialize the registered operating parameter setpoints if any change is made to the data item PV Input Type (IN1), Maximum Value of PV Input Range (RH1), Minimum Value of PV Input Range (RL1), PV Input Decimal Point Position (SDP1), Maximum Value of PV Input Scale (SH1) or Minimum Value of PV Input Scale (SL1). After a change has been made to any of these data items, be sure to verify the registered operating parameter setpoints to ensure that they are correct. If any data item has been changed to its default, set it to a required value.

1. Bring the operating display into view (display appears at power-on).

The PV display in the figure below shows the error code for input burnout (b.o.ll.t.) if PV input wiring is not yet complete. The error code disapears when you wire the PV input terminals correctly.



In steps 2 and later, illustrations of the LCD are cited to explain the procedure.

2. Press the key for more than 3 seconds to call up the main menu "PROG".






3. Press the veckey once to display the main menu "STUP".





4. Press the key once to display the main menu "PARA".






5. Press the veloce to display the main menu "UPMD".






6. Press the key once to display the submenu "MD".







7. Press the key once to display the submenu "IN".




8. Press the key once to display the parameter "IN1" (primary PV input type).




9. Press the △ or ▽ key to display the required setpoint. The figure below shows an example of setting the PV input type to a K-type thermocouple (-200.0°C to 500.0°C).




10. Press the key once to register the setpoint.




11. Press the key once to display the parameter "UNI1".




12. Press the key once to display the parameter "RH1" (maximum value of primary PV input range).




13. Press the △ or ▽ key to display the required setpoint. The figure below shows an example of setting the maximum value of the PV input range to 200.0°C.




14. Press the key once to register the setpoint.




15. Press the key once to display the parameter "RL1" (minimum value of primary PV input range).



16. Press the or key to display the required setpoint. The figure below shows an example of setting the minimum value of the PV input range to 0.0°C.




17. Press the key once to register the setpoint.



If the type of Input is voltage, also configure the Primary PV Input Decimal Point Position (SDP1), Maximum Value of Primary PV Input Scale (SH1), and Minimum Value of Primary PV Input Scale (SL1) parameters that follow this step.

18. Press the key for more than 3 seconds. This returns you to the display shown at power-on (figure below).



2-9 <Toc> <2. Initial Settings>

■ Instrument Input Range Codes

Input	Туре	Instrument Input Range Code	Instrument Input Range	Measurement Accuracy	
Unspecified		OFF (0)	Set the data item PV Input Type "IN1" to the OFF option to leave the PV input type undefined.		
	К	typeK1 (1)	-270.0 to 1370.0°C -450.0 to 2500.0°F	$\pm 0.1\%$ of instrument range ± 1 digit at 0°C or more $\pm 0.2\% \pm 1$ digit for temperatures below 0°C, where the accuracy is: $\pm 2\%$ of instrument range ± 1	
		typeK2 (2)	-270.0 to 1000.0°C -450.0 to 2300.0°F		
		typeK3 (3)	-200.0 to 500.0°C -200.0 to 1000.0°F		
	J	typeJ (4)	-200.0 to 1200.0°C -300.0 to 2300.0°F	digit for temperatures below -200.0 $^{\circ}$ C for a type-K thermocouple, or $\pm 1\%$ of instrument range ± 1 digit for	
	Т	typeT1 (5)	-270.0 to 400.0°C -450.0 to 750.0°F	temperatures below -200.0°C for a type-T thermocouple.	
	'	typeT2 (6)	0.0 to 400.0°C -200.0 to 750.0°F		
	В	typeB (7)	0.0 to 1800.0°C 32 to 3300°F	$\pm 0.15\%$ of instrument range ± 1 digit at 400°C or more $\pm 5\%$ of instrument range ± 1 digit at less than 400°C	
	S	typeS (8)	0.0 to 1700.0°C 32 to 3100°F	±0.150/ of instrument range ±1 digit	
	R	typeR (9)	0.0 to 1700.0°C 32 to 3100°F	±0.15% of instrument range ±1 digit	
Thermocouple	N	typeN (10)	-200.0 to 1300.0°C -300.0 to 2400.0°F	$\pm 0.1\%$ of instrument range ± 1 digit $\pm 0.25\%$ of instrument range ± 1 digit for temperatures below 0°C	
	E	typeE (11)	-270.0 to 1000.0°C -450.0 to 1800.0°F		
	L(DIN)	typeL (12)	-200.0 to 900.0°C -300.0 to 1600.0°F	$\pm 0.1\%$ of instrument range ± 1 digit at 0°C or more $\pm 0.2\% \pm 1$ digit for temperatures below 0°C, where the	
	11/5/11/	typeU1 (13)	-200.0 to 400.0°C -300.0 to 750.0°F	accuracy is:±1.5% of instrument range ±1 digit for temperatures below -200.0°C for a type-E thermocouple	
	U(DIN)	typeU2 (14)	0.0 to 400.0°C -200.0 to 1000.0°F		
	w	typeW (15)	0.0 to 2300.0°C 32 to 4200°F	±0.2% of instrument range ±1 digit	
	Platinel 2	Plati2 (16)	0.0 to 1390.0°C 32.0 to 2500.0°F	±0.1% of instrument range ±1 digit	
	PR20-40	PR2040 (17)	0.0 to 1900.0°C 32 to 3400°F	±0.5% of instrument range ±1 digit at 800°C or more No accuracy is guaranteed at less than 800°C	
	W97Re3- W75Re25	W97Re3 (18)	0.0 to 2000.0°C 32 to 3600°F	\pm 0.2% of instrument range \pm 1 digit	
	JPt100	JPt1 (30)	-200.0 to 500.0°C -300.0 to 1000.0°F	$\pm 0.1\%$ of instrument range ± 1 digit (Note 1) (Note 2)	
		JPt2 (31)	-150.00 to 150.00°C -200.0 to 300.0°F	±0.2% of instrument range ±1 digit (Note 1)	
RTD	Pt100	Pt1 (35)	-200.0 to 850.0°C -300.0 to 1560.0°F	$\pm 0.1\%$ of instrument range ± 1 digit (Note 1) (Note 2)	
		Pt2 (36)	-200.0 to 500.0°C -300.0 to 1000.0°F		
		Pt3 (37)	-150.00 to 150.00°C -200.0 to 300.0°F	±0.2% of instrument range ±1 digit (Note 1)	
Standard	0.4 to 2 V	0.4 to 2 V (40)	0.400 to 2.000 V		
signal	1 to 5 V	1 to 5 V (41)	1.000 to 5.000 V	±0.1% of instrument range ±1 digit	
	0 to 2 V	0 to 2 V (50)	0.000 to 2.000 V	Display range is scalable in a range of -19999 to 30000.	
DC voltage	0 to 10 V	0 to 10 V (51)	0.00 to 10.00 V	Display span is 30000 or less.	
20 voltage	-10 to 20 mV	mv 1 (55)	-10.00 to 20.00 mV	July Spain to 00000 or 1000.	
	0 to 100 mV	mv 2 (56)	0.0 to 100.0 mV		

Numbers in () are the setting value that apply when the communication is used.

Performance in the standard operating conditions (at 23±2°C, 55±10%RH, and 50/60 Hz power frequency)
 Note 1: The accuracy is ±0.3°C of instrument range ±1 digit for a temperature range from 0°C to 100°C.
 Note 2: The accuracy is ±0.5°C of instrument range ±1 digit for a temperature range from -100°C to 200°C.
 To receive a 4-20 mA DC signal, select a standard signal of 1 to 5 V DC and connect it to a 250 Ω resistor. This resistor is optional.
 Model: X010-250-2 (resistor with M3.5 crimp-on terminal lugs)


2.5 Setting Control Output Type (except for a Position

Proportional Controller)

The following operating procedure describes an example of changing time proportional PID relay output (0: factory-set default) to current output (2).


For details on the output terminals for heating/cooling control, see "1.5 Terminal Wiring Diagrams."

1. Bring the operating display into view (display appears at power-on).




In steps 2 and later, illustrations of the LCD are cited to explain the procedure.


2. Press the key for more than 3 seconds to call up the main menu "PROG".




3. Press the key once to display the main menu "STUP".




4. Press the key once to display the main menu "PARA".




5. Press the ▼ key once to display the main menu "UPMD".




6. Press the key once to display the submenu "MD".




7. Press the key twice to display the submenu "OUT".




8. Press the key once to display the parameter "OT2" (control output type).




9. Press the or key to display the required setpoint. The figure below shows an example of setting to current output (4 to 20 mA DC).



10. Press the key once to register the setpoint.



11. Press the key for more than 3 seconds. This returns you to the display shown at power-on (figure below).



● List of Control Output Types

Parameter Symbol	Name of Parameter	Setpoint	Control Output Types
		0	Time proportional PID relay contact output (terminals ① - ② - ③)
		1	Time proportional PID voltage pulse output (terminals (6) - (7))
		2	Current output (terminals 6 - 7)
		3	On/off control relay contact output (terminals ①- ②- ③)
_		The follo	owing 4 to 12 are displayed only for heating/cooling type controllers. Heating-side relay output (terminals ①-②-③), cooling-side relay output (terminals ®- ®- ®)
OT2	Control output type	5	Heating-side pulse output (terminals (6 - (7)), cooling-side relay output (terminals (8 - (9) - (50))
012		6	Heating-side current output (terminals (6) - (77), cooling-side relay output (terminals (8) - (90) - (50)
		7	Heating-side relay output (terminals ① - ② - ③), cooling-side pulse output (terminals ⑥ - ⑥)
		8	Heating-side pulse output (terminals (6 - (7)), cooling-side pulse output (terminals (6 - (9))
		9	Heating-side current output (terminals ® - ⑦), cooling-side pulse output (terminals ⑥ - ⑦)
		10	Heating-side relay output (terminals ① - ② - ③), cooling-side current output (terminals ⑥ - ⑩)
		11	Heating-side pulse output (terminals (6 - 17)), cooling-side current output (terminals (6 - 17))
		12	Heating-side current output (terminals (6 - (7)), cooling-side current output (terminals (6 - (7))

2.6 Calibrating Valve Position (for a Position Proportional

Controller Only)

The following operation describes a procedure of inputting a feedback signal from a control valve to calibrate the full closed and full open positions of the valve automatically. To calibrate the valve position, you need to carry out wire connections and bring the controller into manual mode. For connections, see "1.5 Terminal Wiring Diagrams" and for entering the manual mode, see "4.9 Switching between AUTO and MAN of Secondary-loop."


If the controller is in RESET mode, you need to bring the controller into program operation (RUN) or local operation (LOCAL). For entering the program operation, see "4.7 Switching between RUN and RESET Modes" and entering the local operation, see "4.14 Switching to Local-mode (LOCAL) of Primary-loop Operation."

1. Bring the operating display into view (display appears at power-on).




In steps 2 and later, illustrations of the LCD are cited to explain the procedure.


2. Press the key for more than 3 seconds to call up the main menu "PROG".




3. Press the key once to display the main menu "STUP".




4. Press the key once to display the main menu "PARA".




5. Press the key once to display the main menu "UPMD".



6. Press the key once to display the submenu "MD".




7. Press the very key three times to display the submenu "VALV".




<Toc> <2. Initial Settings> 2-13


8. Press the key once to display the parameter "V.AT".



9. Press the \(\triangle \) key to display "ON".



10. Press the key once. The controller automatically calibrates the valve position (fully open or closed).



11. Calibration has ended successfully when the indication changes from "ON" to "OFF".




Go to step 13.

12. Calibration has ended unsuccessfully if the indication changes from "ON" to "ERR". Check the feedback input wiring and carry out automatic calibration again.

MENU	:UPM	D/VALV	#1
valve a	auto tu		
		L	SETUP
V.AT	=	ERF	₹

13. Press the key for more than 3 seconds. This returns you to the display shown at power-on (figure below).



<Toc> <2. Initial Settings> 2-14


2.7 Initializing Parameters

Be sure to follow the steps below after a change of setting has been made to the data item PV Input Type, PV Input Range or PV Input Scale.




Initializing the above parameter setpoints may initialize the registered operating/setup paraemters. Check that they are correct. If any of them has been changed to its initial value, set it to a required value.

1. Bring the operating display into view (display appears at power-on).




In steps 2 and later, illustrations of the LCD are cited to explain the procedure.


2. Press the key for more than 3 seconds to call up the main menu "PROG".




3. Press the key once to display the main menu "STUP".




4. Press the key once to display the main menu "PARA".




5. Press the key once to display the main menu "UPMD".



6. Press the key once to display the submenu "MD".




7. Press the very key twice to display the submenu "INIT".




<Toc> <2. Initial Settings> 2-15


8. Press the key once to display the parameter "INI".




9. Press the key to display "ON".



10. Press the key once. The display momentarily becomes blank (which is normal), indicating the parameters have been initialized.



11. Press the key for more than 3 seconds. This returns you to the display shown at power-on (figure below).



3. Programming

This chapter explains how to create programs by citing specific examples. Create user programs by referring to the given programming examples. Use the parameter map included in "3.5 Program Parameter Map," in order to further familiarize yourself with the required operations.

Be sure to carry out the settings instructed in "2. Initial Settings" before beginning any of the tasks discussed in this chapter.

3.1 Overview of Program Patterns


■ Programming Overview

The programming example given here demonstrates how to do the tasks outlined below.

- 1. Program the controller to start program operation at 25°C and raise the temperature up to 80°C in 20 minutes.
- 2. When the temperature reaches 80°C, keep it at this level for 80 minutes.
- 3. Finally, lower the temperature to 0°C in 10 minutes.

Event output

- Set a deviation of 5°C on both the positive and negative sides of a program setpoint to allow the controller to output an event signal if the temperature goes beyond the deviation range.
- Let the controller output an event signal when the temperature stabilizes to 80°C.



3.2 Example of Program Pattern Setup Charts

Complete the following setup chart before setting programs in the controller. Filling in the chart makes it easier for you to input program data into the controller. See "3.7 Program Pattern Setup Charts."

In the following chart, fill in the fields with bold-face borders.

- 1. Maximum value of primary PV input range: Setpoint of the "Maximum Value of Primary PV Input Range (RH1)" setup parameter
- 2. Minimum value of primary PV input range: Setpoint of the "Minimum Value of Primary PV Input Range (RL1)" setup parameter
- 3. Primary PV input unit: Setpoint of the "Primary PV Input Unit (UNI1)" setup parameter
- 4. Program time unit: Setpoint of the "Program Time Unit (TMU)" setup parameter
- 5. Segment setting method: Setpoint of the "Segment Setting Method (SEG.T)" setup parameter
- 6. Starting target setpoint: Setpoint of the "Starting Target Setpoint (SSP1)" program parameter
- 7. Start code: Setpoint of the "Start Code (STC)" program parameter
- 8. Final target setpoint, Segment time, Events (PV event and Time event) and Junction code: Setpoint of each program parameter
- 9. Draw the program pattern.


Starting target setpoint 1 (SSP1)	6	2	5°C
Starting target setpoint 2 (SSP2)			
Start code (STC)	7		0
1st group of wait zones (1.WZ1)			
1st group of wait times (1.WTM)			
2nd group of wait zones (2.WZ1)			
2nd group of wait times (2.WTM)			
3rd group of wait zones (3.WZ1)			
3rd group of wait times (3.WTM)			
4th group of wait zones (4.WZ1)			
4th group of wait times (4.WTM)			
5th group of wait zones (5.WZ1)			
5th group of wait times (5.WTM)			
Number of repetitions (RCY)			
Start-of-repetition segment number (RST)			
End-of-repetition segment number (REN)			

Define this parameter when using the controller as a program pattern generator. See User's Manual (Reference) (CD-ROM version) for more information.

See User's

Manual (Reference)
(CD-ROM version)
for more information.

Program time unit (TMU)	4	Hour, minute
Segment setting method (SEG.T)	5	Time setting



Note: This parameter is shown for segment PID parameter when the setup parameter "ZON" is set to 0.

3.3 Creating Program Patterns

The following operating procedure describes an example of creating the program discussed in "3.1 Overview of Program Patterns."




NOTE

Before creating the program, reverify the Maximum Value of Primary PV Input Range (RH1), Minimum Value of Primary PV Input Range (RL1), Program Time Unit (TMU), and Segment Setting Method (SEG.T) parameters.

If the setting of the setup parameter "SEG.T" is changed, the program patterns created and stored so far will be all cleared (initialized)!! Be careful.


The programming example given in this section includes the following steps.

- Step 5 selects the program pattern number (PTN).
- Steps 7 to 9 configure the parameter Starting Target Setpoint (SSP1) (so that the program starts from 25°C).
- Steps 11 to 13 configure the Final Target Setpoint (TSP1) parameter for segment 1.
- Steps 14 to 16 configure the Segment Time (TIME) parameter for segment 1.
- Steps 17 to 25 configure the PV Event parameters (EV1, TY1 and PE1).
- Step 28 configures the Final Target Setpoint (TSP1) parameter for segment 2 (not changed in this example).
- Steps 29 to 31 configure the Segment Time (TIME) parameter for segment 2.
- Steps 32 to 40 configure the Time Event parameters (EV1, ON1 and OFF1).
- Steps 43 to 45 configure the Final Target Setpoint (TSP1) parameter for segment 3.
- Steps 46 to 48 configure the Segment Time (TIME) parameter for segment 3.
- 1. Bring the operating display into view (appears at power-on).




For steps 2 and later, illustrations of the LCD are cited to explain the procedure.


2. Press the key for more than 3 seconds to call up the main menu "PROG".




3. Press the key once to display the submenu "LOC".




4. Press the \(\triangle \) key once to display the submenu "PRG".




5. Press the key once to display the Pattern Number parameter "PTN". At this point, the PV display shows "01.00" (the first two digits denote the pattern number and the last two digits the segment number).



6. Press the key once to display the Segment Number parameter "SEG".



7. Press the key once to display the Starting Target Setpoint parameter "SSP1".




8. Press the △ or ▽ key to display the required setpoint.


The figure below shows an example of the parameter set to "25.0°C".




9. Press the key once to register the setpoint.



10. Press the key once to display the Start Code parameter "STC".




11. Press the key once to display the Target Setpoint parameter "TSP1" for segment 1. At this point, the PV display shows "01.01" (the first two digits denote the pattern number and the last two digits the segment number).




12. Press the △ or ▽ key to display the required setpoint.
The figure below shows an example of the parameter set to "80.0°C".



13. Press the key once to register the setpoint.




14. Press the key once to display the Segment Time parameter "TIME" for segment 1.




15. Press the △ or ▽ key to display the required setpoint.


The figure below shows an example of the parameter set to "20 min. (0h20)".



16. Press the key once to register the setpoint.




17. Press the key once to display the Event Number parameter "EV1".




18. Press the △ or ▽ key to display the required setpoint.


The figure below shows an example of t

MENU:PROG/PRG






19. Press the key once to register the setpoint.




20. Press the key once to display the PV Event Type parameter "TY1".




21. Press the \triangle or ∇ key to display the required setpoint.

The figure below shows an example of the parameter set to "Deviation high and low limits Alarm" (setpoint 7).






22. Press the key once to register the setpoint.



23. Press the key once to display the PV Event Setpoint parameter "PE1".




24. Press the \triangle or ∇ key to display the required setpoint.

The figure below shows an example of the parameter set to "5.0°C".






25. Press the key once to register the setpoint.




26. Press the key once to display the Event Number parameter "EV2".



27. Press the key once to display the Junction Code parameter "JC" for segment 1.


The setpoint of this parameter is not changed in this example.




28. Press the key once to display the Target Setpoint parameter "TSP1" for segment 2.

The setpoint of this parameter is not changed in this example.

At this point, the PV display shows "01.02" (the first two digits denote the pattern number and the last two digits the segment number).



29. Press the key once to display the Segment Time parameter "TIME" for segment 2.



30. Press the △ or ▽ key to display the required setpoint.

The figure below shows an example of the parameter set to "1 hr. and 20 min. (setpoint 1h20)".






31. Press the key once to register the setpoint.



32. Press the key once to display the Event Number parameter "EV1".




33. Press the △ or ▽ key to display the required setpoint.

The figure below shows an example of the parameter set to "time event 1 (setpoint 1)".






34. Press the key once to register the setpoint.




35. Press the key once to display the On Time of Time Event parameter "ON1".




36. Press the △ or ▽ key to display the required setpoint.


The figure below shows an example of the parameter set to "0 min. (setpoint 0h00)".



37. Press the key once to register the setpoint.




38. Press the key once to display the Off Time of Time Event parameter "OFF1".




39. Press the △ or ▽ key to display the required setpoint.

The figure below shows an example of the parameter set to "1 hr. and 20 min.






40. Press the key once to register the setpoint.




41. Press the key once to display the Event Number parameter "EV2".




42. Press the key once to display the Junction Code parameter "JC" for segment 2.

The setpoint of this parameter is not changed in this example.




43. Press the key once to display the Target Setpoint parameter for segment 3. At this point, the PV display shows "01.03" (the first two digits denote the pattern number and the last two digits the segment number).




44. Press the △ or ▽ key to display the required setpoint.


The figure below shows an example of the parameter set to "0.0°C".



45. Press the key once to register the setpoint.




46. Press the key once to display the Segment Time parameter "TIME" for segment 3.




47. Press the △ or ▽ key to display the required setpoint.


The figure below shows an example of the parameter set to "10 min. (setpoint 0h10)".



48. Press the key once to register the setpoint.




49. Programming is now complete. Press the key for more than 3 seconds. This returns you to the display shown at power-on (figure below).




3.4 Changing Program Patterns

The following operating procedure describes an example of changing the program pattern created in "3.3 Creating Program Patterns" to the program pattern shown in the figure below.




1. Bring the operating display into view (appears at power-on).




For steps 2 and later, illustrations of the LCD are cited to explain the procedure.


2. Press the key for more than 3 seconds to call up the main menu "PROG".




3. Press the key once to display the submenu "LOC".




4. Press the key once to display the submenu "PRG".




5. Press the key once to display the Pattern Number parameter "PTN".



6. Press the key once to display the Segment Number parameter "SEG".




7. Press the key twice to display the Start Code parameter "STC".




8. Press the △ or ▽ key to display the required setpoint.

The figure below shows an example of the parameter set to "time-prioritized PV start


(setpoint 2)".



9. Press the key once to register the setpoint.




10. Press the key once to display the Target Setpoint parameter "TSP1" for segment 1.




11. Press the key seven times to display the Target Setpoint parameter "TSP1" for segment 2.

At this point, the PV display shows "01.02" (the first two digits denote the pattern number and the last two digits the segment number).




12. Press the △ or ▽ key to display the required setpoint.


The figure below shows an example of the parameter set to "90.0°C".




13. Press the key once to register the setpoint.




14. Changing the program is now complete. Press the key for more than 3 seconds. This returns you to the display shown at power-on (figure below).



3.5 Program Parameter Map



Parameters of program pattern 1



3.6 Lists of Program Parameters

- * Parameters relating to PV or program setpoints should all be set in real numbers. For example, use temperature values to define program setpoints and PV event setpoints for temperature input.
- * The "User Setting" column in the table below is provided for the customer to record setpoints.
- * Number in () are the parameter setpoint that applies when the communication function is used. ex. OFF (0).

Local Setpoint Parameters

Located in: Main menu = PROG; Submenu = LOC

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
LSP1	Setpoint for local-mode operation of primary-loop	0.0 to 100.0% of primary PV input range	0.0% of primary PV input range	
LSP2	Setpoint for local-mode operation of secondary-loop	0.0 to 100.0% of secondary PV input range	0.0% of secondary PV input range	
PID	PID group number for local-mode operation	Shown for segment PID parameters when the setup parameter "ZON" is set to 0. This parameter is factory-set so as not to appear. 1: Uses the 1st group of PID parameters. 2: Uses the 2nd group of PID parameters. 3: Uses the 3rd group of PID parameters. 4: Uses the 4th group of PID parameters. 5 to 8: Likewise, selecting these numbers uses the 5th to 8th groups of PID parameters.	1	
E21A	Local event-21 type	OFF (0), 1 to 10, 28 to 31 1: PV high limit (energized, no stand-by action) 2: PV low limit (energized, no stand-by action) 3: Deviation high limit (energized, no stand-by action) 4: Deviation low limit (energized, no stand-by action) 5: Deviation high limit (de-energized, no stand-by action) 6: Deviation low limit (de-energized, no stand-by action) 7: Deviation high/low limits (energized, no stand-by action) 8: Deviation within high/low limits (energized, no stand-by action) 9: PV high limit (de-energized, no stand-by action) 10: PV low limit (de-energized, no stand-by action)	OFF (0)	
E21B	Local event-21 setpoint	PV/SP alarm: -100.0 to 100.0% of PV input range Deviation alarm: -100.0 to 100.0% of PV input range span Output value alarm: -5.0 to 105.0%	PV/SP high limit alarm: 100.0% of PV input range. Deviation alarm: 0.0% of PV input range span. Other PV/SP low limit alarms: 0.0% of PV input range. Output high limit alarm: 100.0% Output low limit alarm: 0.0%	

IM 05E01C02-44E 3rd Edition: May 31, 2006-00

Parameter Symbol	Name of Parameter	Setting Range and Description Initial Value		User Setting	
E22A	Local event-22 type	Same as the E21A parameter.			
E22B	Local event-22 setpoint	Same as the E21B parameter.			
E23A	Local event-23 type	Same as the E21A parameter.			
E23B	Local event-23 setpoint	Same as the E21B parameter.			
E24A	Local event-24 type	Same as the E21A parameter.	ame as the E21A parameter.		
E24B	Local event-24 setpoint	Same as the E21B parameter.			
E25A	Local event-25 type	Same as the E21A parameter.			
E25B	Local event-25 setpoint	Same as the E21B parameter.			
E26A	Local event-26 type	Same as the E21A parameter.			
E26B	Local event-26 setpoint	Same as the E21B parameter.			
E27A	Local event-27 type	Same as the E21A parameter.			
E27B	Local event-27 setpoint	Same as the E21B parameter.			
E28A	Local event-28 type	Same as the E21A parameter.			
E28B	Local event-28 setpoint	Same as the E21B parameter.			

Program Parameters (Parameters for Setting the Conditions of Program Operation Startup)

Use the program pattern setup chart discussed in "3.2 Example of Program Pattern Setup Charts" of this chapter, to record your setpoints of program parameters.

Located in: Main menu = PROG; Submenu = PRG

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
PTN	Pattern number	Program pattern 1 2: Program pattern 2 Program pattern 3 to 30: Likewise, specifying these numbers sets their corresponding program pattern numbers.		
SEG	Segment number	O: Shows parameters for setting the starting target setpoint, start code, etc. 1 to 99: Specify the corresponding segment numbers. Specify "0" when creating a program for the first time.	0	
SSP1	Starting target setpoint	0.0 to 100.0% of primary PV input range	0.0% of primary PV input range	
STC	Start code	-1: Shows parameters for setting the wait and repeat actions. 0: Program operation begins with the starting target setpoint. 1: Ramp-prioritized PV start (program operation begins with the PV value by giving priority to the ramp of segment 1) 2: Time-prioritized PV start (program operation begins with the PV value by giving priority to the time of segment 1) TIP: The option "-1" is not a setpoint.	0	

Program Parameters (Parameters for Setting the Wait and Repeat Actions)

The parameters listed below are shown when the Start Code (STC) parameter is set to "-1." **Located in: Main menu = PROG**; **Submenu = PRG**

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
1.WZ1	1st group of wait zones	OFF(0): No function 0.0 to 10.0% of primary PV input range span	OFF(0)	
1.WTM	1st group of wait times	OFF(0): No function 0.01 to 99.59 ("hour, minute" or "minute, second") Use the TMU setup parameter to set the time unit.	OFF(0)	
2.WZ1	2nd group of wait zones	Same as the 1st group of wait zones.		
2.WTM	2nd group of wait times	Same as the 1st group of wait times.		
3.WZ1	3rd group of wait zones	Same as the 1st group of wait zones.		
3.WTM	3rd group of wait times	Same as the 1st group of wait times.		
4.WZ1	4th group of wait zones	Same as the 1st group of wait zones.		
4.WTM	4th group of wait times	Same as the 1st group of wait times.		
5.WZ1	5th group of wait zones	Same as the 1st group of wait zones.		
5.WTM	5th group of wait times	Same as the 1st group of wait times.		
RCY	Number of repetitions	0 to 999: The controller repeats the segment specified by the RST and REN parameters as many times as defined by this parameter. CONT: The controller indefinitely repeats the segment specified by the RST and REN parameters.	0	
RST	Start-of-repetition segment number	1≤RST≤REN≤99	1	
REN	End-of-repetition segment number		1	

Program Parameters (Parameters for Setting the Final Target Setpoints and Segment Times)

Located in: Main menu = PROG; Submenu = PRG

Parameter Symbol	Name of Parameter	Setting Range and Description Initial Value		User Setting	
TSP1	Final target setpoint	The final target setpoint of each segment.			
TIME	Time-set segment time	Time setpoint: - (unregistered) 0.00 to 99.59 ("hour, minute" or "minute, second") Without a time setpoint, it is not possible to create programs.			
TM.RT	Ramp-set segment time	For ramp segments (ramp setpoint): - (unregistered), 0.0 to 100.0% of PV input range span per hour or minute For soak segments (time setpoint): 0.00 to 99.59 ("hour, minute" or "minute, second") Without a time setpoint or a ramp grade setpoint, it is not possible to create programs.			
PID	Segment PID group number	This parameter is shown for segment PID parameters when the setup parameter "ZON" is set to 0. This parameter is factory-set so as not to appear. 1 to 8			

IM 05E01C02-44E 3rd Edition: May 31, 2006-00

Program Prameters (Parameters for Setting the Event Action)

You can set a maximum of eight units each for the parameters listed below for each individual segment.

Located in: Main menu = PROG; Submenu = PRG

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
EVn	Event number	0: Unregistered. 1: Time event 1 (terminal numbers (39-(58)) 2: Time event 2 (terminal numbers (39-(58)) 3: Time event 3 (terminal numbers (39-(58)) 4: Time event 4 (terminal numbers (39-(58)) 5 to 16: Time events 5 to 16 (see the CD-ROM version user's manual for details on the terminal number) 21: PV event 1 (terminal numbers (69-(79)) 22: PV event 2 (terminal numbers (59-(79)) 23 to 28: PV events 3 to 8 (see the CD-ROM version user's manual for details on the terminal number)	0	
ONn	On time of time event	OFF(0): Unused. 0.00 to 99.59 ("hour, minute" or "minute, second")	OFF(0)	
OFFn	Off time of time event	OFF(0): Unused. 0.00 to 99.59 ("hour, minute" or "minute, second")	OFF(0)	
TYn	PV event type	OFF(0), 1 to 10, 28 to 31 1: PV high limit (energized, no stand-by action) 2: PV low limit (energized, no stand-by action) 3: Deviation high limit (energized, no stand-by action) 4: Deviation low limit (energized, no stand-by action) 5: Deviation high limit (de-energized, no stand-by action) 6: Deviation low limit (de-energized, no stand-by action) 7: Deviation high/low limits (energized, no stand-by action) 8: Deviation within high/low limits (energized, no stand-by action) 9: PV high limit (de-energized, no stand-by action) 10: PV low limit (de-energized, no stand-by action) 10: PV low limit (de-energized, no stand-by action) See the next page for details on other alarm types.	OFF(0)	
PEn	PV event setpoint	PV/SP alarm: -100.0 to 100.0% of primary PV input range Deviation alarm: -100.0 to 100.0% of primary PV input range span Output value alarm: -5.0 to 105.0%	PV/SP high limit alarm: 100.0% of primary PV input range. Deviation alarm: 0.0% of primary PV input range span. Other PV/SP low limit alarms: 0.0% of primary PV input range. Output high limit alarm: 100.0% Output low limit alarm: 0.0%	

• Program Parameters (Junction Code Parameter)

Located in: Main menu = PROG; Submenu = PRG

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
JC	Junction code	O: Switching for continuation 1: Hold-on switching (the controller holds the end-of-segment setpoint when the segment is completed, to perform control). 2: Local-mode end (the controller switches to a local setpoint when the segment is completed). 11 to 15: Wait during switching between segments (see the CD-ROM version user's manual). 21 to 25: Wait within a segment interval (see the CD-ROM version user's manual). INSERT: Allows a segment to be added to the end of a specified segment. DELETE: Allows a specified segment to be deleted. 101 to 130: Linked to patterns 1 to 30. For example, registering "102" for the end-of-segment JC allows the controller to start the pattern-2 operation after the end of pattern-1 operation. <notes -="" and="" are="" at="" available="" available.<="" event="" is="" not="" parameter="" pattern-links="" pv="" reset="" sst="" stc="" td="" time=""><td></td><td></td></notes>		

IM 05E01C02-44E 3rd Edition: May 31, 2006-00

List of PV Event and Local Event Types

The table below shows the types and actions of PV event and Local event.

	Alarm action	Alarm ty	pe code		Alarm action	Alarm ty	pe code
Alarm type	"Open/close" shows status of relay contact, and "lit" and "unlit" shows status of lamp	Contact closes if alarm occurs	Contact opens if alarm occurs	Alarm type	"Open/close" shows status of relay contact, and "lit" and "unlit" shows status of lamp	Contact closes if alarm occurs	Contact opens if alarm occurs
No alarm		O	FF		Hysteresis	/	
PV high limit	Open (unlit) Closed (lit)	1		De-energized on deviation low limit alarm	Open (lit) Deviation Setpoint Target SP Closed (unlit) Target SP		6
PV low limit	Closed (lit) Open (unlit) Alarm setpoint PV	2		Deviation high and low limits	Hysteresis Hysteresis Closed Open (lit) Deviation setpoint PV Target SP	7	
Deviation high limit	Open (unlit) PV Deviation setpoint Target SP	3		Deviation within high and low limits	Hysteresis Closed Hysteresis Open (unlit) Open (unlit) Deviation setpoint Target SP	8	
Deviation low limit	Hysteresis Closed (lit) Deviation setpoint Target SP	4		De-energized on PV high limit	Closed (unlit) Open (lit) PV Alarm setpoint		9
De-energized on deviation high limit alarm	Closed (unlit) PV		5	De-energized on PV low limit	Open (lit) Closed (unlit) Alarm setpoint PV		10
SP high limit	Hysteresis Closed (lit) Open (unlit) SP Alarm setpoint	28		Output high limit	Open (unlit) Output value Hysteresis Closed (lit) Alarm setpoint	30	
SP low limit	Hysteresis Closed (lit) Open (unlit) Alarm setpoint SP	29		Output low limit	Hysteresis Closed (lit) Open (unlit) Alarm setpoint Output value	31	

Program Parameters (Parameters for Editing Programs)

Located in: Main menu = **PROG**; Submenu = **EDIT**

Symbol on PV Display	Name of Parameter	Setting Range and Description	Initial Value	User Setting
(ALL.S)	Number of remaining unused segments.	Read-only		
PT. S	Number of segments within a pattern.			
ALL.E)	Number of remaining unused events.			
COPY)	Program pattern copying	Specify the numbers of the source-of-copying program pattern and target-of-copying program pattern. (1 to 30)		
CLEAR)	Program pattern clearance	Specify the number of the program pattern to be cleared. (1 to 30)		

3.7 Program Pattern Setup Charts

For details on how to use the program pattern setup chart, see "3.1 Overview of Program Patterns," and "3.2 Example of Program Pattern Setup Charts."

You can register as many as 30 program patterns with the UP550 controller. Create as many copies of the chart as necessary.

First fill in the fields with bold-face borders in the order from number 1 to number 9. Then, input the data into the controller.

IM 05E01C02-44E 3rd Edition: May 31, 2006-00

- 1. Maximum value of primary PV input range: Setpoint of the "Maximum Value of Primary PV Input Range (RH1)" setup parameter
- 2. Minimum value of primary PV input range: Setpoint of the "Minimum Value of Primary PV Input Range (RL1)" setup parameter
- 3. Primary PV input unit: Setpoint of the "Primary PV Input Unit (UNI1)" setup parameter
- 4. Program time unit: Setpoint of the "Program Time Unit (TMU)" setup parameter
- 5. Segment setting method: Setpoint of the "Segment Setting Method (SEG.T)" setup parameter6. Starting target setpoint: Setpoint of the "Starting Target Setpoint (SSP1)" program parameter
- 7. Start code: Setpoint of the "Start Code (STC)" program parameter
- 8. Final target setpoint, segment time, Events (PV event and Time event) and Junction code: Setpoint of each program parameter
- 9. Draw the program pattern.

	System name									
	Program No.			╽┌╴						
	Program name			Program time unit (TMU) 4					-	
	Model	UP550 -		Se	gment se	tting meth	od (SEG.	T) 5		
	Serial No.									
Maximum	value of primary PV		Unit 3							
		100%								
										ļ
										ļ

Define this parameter when using the controller as a program pattern generator. See User's Manual (Reference) (CD-ROM version) for more information.

Time setting (TIME) when the Segment Setting Method (SEG.T) parameter is set as SEG.T = 0; ramp setting (TM.RT) when the parameter is set as SEG.T = 1 Factory-set to Time setting (TIME).

Shown for segment PID parameters when the setup parameter "ZON" is set to 0.

8

Minimum value of primary PV input range (RL1) 2 0%						
Segment No.→	1	2	3	4	5	6
Final target setpoint 1 (TSP1)	-					
Final target setpoint 2 (TSP2)						
Segment time (TIME/TM.RT)						
PID number (PID)						
Tevent number (EV1)						
PV event type (TY1)/on time of time event (ON1)						
PV event setpoint (PE1)/off time of time event (OFF1)						
Event number (EV2)						
PV event type (TY2)/on time of time event (ON2)						
PV event setpoint (PE2)/off time of time event (OFF2)						
Event number (EV3)						
PV event type (TY3)/on time of time event (ON3)						
PV event setpoint (PE3)/off time of time event (OFF3)						
Event number (EV4)						
PV event type (TY4)/on time of time event (ON4)						
PV event setpoint (PE4)/off time of time event (OFF4)						
Event number (EV5)						
PV event type (TY5)/on time of time event (ON5)						
PV event setpoint (PE5)/off time of time event (OFF5)						
Event number (EV6)						
PV event type (TY6)/on time of time event (ON6)						
PV event setpoint (PE6)/off time of time event (OFF6)						
Event number (EV7)						
PV event type (TY7)/on time of time event (ON7)						
PV event setpoint (PE7)/off time of time event (OFF7)						
Event number (EV8)						
PV event type (TY8)/on time of time event (ON8)						
PV event setpoint (PE8)/off time of time event (OFF8)						
Junction code (JC)						

<3. Programming> <Toc>

Starting target setpoint 1 (SSP1) 6 Starting target setpoint 2 (SSP2) Start code (STC) 7 1st group of wait zones (1.WZ1) 1st group of wait times (1.WTM) 2nd group of wait zones (2.WZ1) 2nd group of wait times (2.WTM) 3rd group of wait zones (3.WZ1) 3rd group of wait times (3.WTM) 4th group of wait zones (4.WZ1) 4th group of wait times (4.WTM) 5th group of wait times (5.WZ1) 5th group of wait times (5.WZM) Number of repetitions (RCY) Start-of-repetition segment number (RST)		
Start code (STC) 1st group of wait zones (1.WZ1) 1st group of wait times (1.WTM) 2nd group of wait times (2.WZ1) 2nd group of wait times (2.WTM) 3rd group of wait zones (3.WZ1) 3rd group of wait zones (3.WZ1) 4th group of wait zones (4.WZ1) 4th group of wait times (4.WTM) 5th group of wait zones (5.WZ1) 5th group of wait times (5.WTM) Number of repetitions (RCY) Start-of-repetition segment number (RST)	Starting target setpoint 1 (SSP1)	6
1st group of wait zones (1.WZ1) 1st group of wait times (1.WTM) 2nd group of wait times (2.WZ1) 2nd group of wait times (2.WTM) 3rd group of wait zones (3.WZ1) 3rd group of wait times (3.WTM) 4th group of wait zones (4.WZ1) 4th group of wait times (4.WTM) 5th group of wait zones (5.WZ1) 5th group of wait times (5.WTM) Number of repetitions (RCY) Start-of-repetition segment number (RST)	Starting target setpoint 2 (SSP2)	
1st group of wait times (1.WTM) 2nd group of wait zones (2.WZ1) 2nd group of wait times (2.WTM) 3rd group of wait zones (3.WZ1) 3rd group of wait times (3.WTM) 4th group of wait zones (4.WZ1) 4th group of wait times (4.WTM) 5th group of wait zones (5.WZ1) 5th group of wait times (5.WTM) Number of repetitions (RCY) Start-of-repetition segment number (RST)	Start code (STC)	7
2nd group of wait zones (2.WZ1) 2nd group of wait times (2.WTM) 3rd group of wait zones (3.WZ1) 3rd group of wait times (3.WTM) 4th group of wait zones (4.WZ1) 4th group of wait times (4.WTM) 5th group of wait zones (5.WZ1) 5th group of wait times (5.WTM) Number of repetitions (RCY) Start-of-repetition segment number (RST)	1st group of wait zones (1.WZ1)	
2nd group of wait times (2.WTM) 3rd group of wait zones (3.WZ1) 3rd group of wait times (3.WTM) 4th group of wait zones (4.WZ1) 4th group of wait times (4.WTM) 5th group of wait zones (5.WZ1) 5th group of wait times (5.WTM) Number of repetitions (RCY) Start-of-repetition segment number (RST)	1st group of wait times (1.WTM)	
3rd group of wait zones (3.WZ1) 3rd group of wait times (3.WTM) 4th group of wait zones (4.WZ1) 4th group of wait times (4.WTM) 5th group of wait zones (5.WZ1) 5th group of wait times (5.WTM) Number of repetitions (RCY) Start-of-repetition segment number (RST)	2nd group of wait zones (2.WZ1)	
3rd group of wait times (3.WTM) 4th group of wait zones (4.WZ1) 4th group of wait times (4.WTM) 5th group of wait zones (5.WZ1) 5th group of wait times (5.WTM) Number of repetitions (RCY) Start-of-repetition segment number (RST)	2nd group of wait times (2.WTM)	
4th group of wait zones (4.WZ1) 4th group of wait times (4.WTM) 5th group of wait zones (5.WZ1) 5th group of wait times (5.WTM) Number of repetitions (RCY) Start-of-repetition segment number (RST)	3rd group of wait zones (3.WZ1)	
4th group of wait times (4.WTM) 5th group of wait zones (5.WZ1) 5th group of wait times (5.WTM) Number of repetitions (RCY) Start-of-repetition segment number (RST)	3rd group of wait times (3.WTM)	
5th group of wait zones (5.WZ1) 5th group of wait times (5.WTM) Number of repetitions (RCY) Start-of-repetition segment number (RST)	4th group of wait zones (4.WZ1)	
5th group of wait times (5.WTM) Number of repetitions (RCY) Start-of-repetition segment number (RST)	4th group of wait times (4.WTM)	
Number of repetitions (RCY) Start-of-repetition segment number (RST)	5th group of wait zones (5.WZ1)	
Start-of-repetition segment number (RST)	5th group of wait times (5.WTM)	
	Number of repetitions (RCY)	
End-of-repetition segment number (REN)	Start-of-repetition segment number (RST)	
End of repetition degineric fiderior (Fiz.14)	End-of-repetition segment number (REN)	

Define this parameter when using the controller as a program pattern generator.
See User's Manual (Reference) (CD-ROM version) for more information.

See User's Manual (Reference) (CD-ROM version) for more information.

7	8	9	10	11	12	13	14	15	16	17	18	19	20
										-			
										<u> </u>			
										<u> </u>			
			-			-		-	-	 			

3.8 Explanation of Program Functions

■ Programming

You can create programs using either method 1 or 2 described below.

The controller is factory-set to "method 1." To create programs using method 2, change the setpoint of the SEG.T (Segment Setting Method) setup parameter to "1."

Before you begin programming, determine whether your programs are created using the time unit of "hour and minute" or "minute and second." The controller is factory-set to the "hour and minute" time unit. To create programs using the "minute and second" time unit, change the setpoint of the TMU (Program Time Unit) setup parameter to "mm:ss."


<Controller Settings>

	Setpoint of SEG.T (Segment Setting Method) Setup Parameter
Time setting (method 1)	0 (factory-set default)
Ramp setting (method 2)	1

Choose the desired method and unit from the two programming methods and time unit options discussed above. Then, create programs according to the chosen options.

1. Creating programs by setting final target setpoint and segment time unit


As shown in the figure below, this method creates programs by setting a segment time and a final target setpoint on a segment-by-segment basis.



2. Creating programs by setting final target setpoint and ramp

As shown in the figure below, this method creates programs by setting a final target setpoint and a ramp grade on a segment-by-segment basis.

Define the ramp grade as the amount of change in the setpoint per hour or per minute.




<Controller Settings>


	Setpoint of TMU (Program Time Unit) Setup Parameter
When changing the setpoint linearly over an hour	hh:mm (factory-set default)
When changing the setpoint linearly over a minute	mm:ss

Note: The "Program Time Unit (TMU)" parameter is the time unit you use when creating programs.

When creating a soak segment during programming, set a time ("hour and minute" or "minute and second") rather than a ramp grade.



For example, configure segment 1 so the temperature rises in increments of 5° C per minute from 50° C to 100° C, as shown in the figure below.



To change the temperature linearly over a minute, set the TMU parameter to "mm:ss" (minute and second) before you begin programming.

When programming the controller, set the Segment Time (TM.RT) parameter for segment 1 to 5° C.


This allows the controller to raise the setpoint in increments of 5°C per minute during the interval of segment 1.

■ Controller Behavior at the Start of Program Operation

You can determine how the controller should behave at the start of program operation.

1. Letting the controller run from a starting target setpoint

A starting target setpoint refers to a setpoint from which program operation begins. The controller operates in such a manner that the setpoint changes to the final target setpoint over the segment time set for segment 1, irrespective of what the PV value is.




<Controller Settings>

Set the STC (Start Code) program parameter to "0".

2. Letting the controller start from the current setpoint and run according to time settings defined for segment 1

This method is not available if the SEG.T (Segment Setting Method) parameter is set to "ramp setting."

Starting Point of Operation	Controller Behavior
а	Begins to run from point a according to the time setting defined for segment 1.
b	Begins to run from point b according to the time setting defined for segment 1.
С	Begins to run from point c according to the time setting defined for segment 1.
d	Begins to run from point d according to the time setting defined for segment 1.
е	Begins to run from point e according to the time setting defined for segment 1.




<Controller Settings>

Set the STC (Start Code) program parameter to "2".

3. Letting the controller start from the current setpoint and run according to ramp settings defined for segment 1

Starting Point of Operation	Controller Behavior
а	Begins to run from point C1 (ignores the time setting defined for segment 1).
b	Begins to run from point C1 (ignores the time setting defined for segment 1).
С	Begins to run from point C1 (ignores the time setting defined for segment 1).
d	Begins to run from point D1 according to the preset ramp setting (the time setting defined for segment 1 is reduced).
е	Begins to run from point E1 according to the preset ramp setting.



<Controller Settings>


Set the STC (Start Code) program parameter to "1".

■ PID Switching (Zone PID)

The UP550 offers two methods of PID switching. One of the methods is to automatically switch between groups of PID constants according to the temperature zone. The other method is to automatically switch between groups of PID constants on a segment-by-segment basis. This paragraph explains the method of switching between groups of PID constants according to the temperature zone. You can set a maximum of seven temperature zones. When shipped from the factory, the UP550 is configured so that it operates in zone 1 only and uses only one group of PID constants.

When One Group of PID Constants is Used (factory-set default)

As shown in the figure below, the controller uses one group of PID constants over the range from the minimum value to the maximum value of the primary PV input range.




<Controller Settings>

- Configure the 1st group of PID constants (1.P, 1.I and 1.D operating parameters).

Selection of PID Constants when the Control Range is Split into Three Zones

As shown in the figure below, three zones are set for the controller to automatically switch from one group of PID constants to another. Two zones can also be set for the controller to switch between two groups of PID constants.

- [1] The controller uses the 1st group of PID constants if the PV input value is within the zone set off by the minimum value of the primary PV input range and reference point 1.
- [2] The controller uses the 2nd group of PID constants if the PV input value is within the zone set off by reference point 1 and reference point 2.
- [3] The controller uses the 3rd group of PID constants if the PV input value is within the zone set off by reference point 2 and the maximum value of the primary PV input range.



<Controller Settings>

- Splitting the control range into two zones
 - To split the control range into two zones, define reference point 1 (i.e., the 1.RP1 setup parameter).
 - Define the 1st and 2nd groups of PID constants (i.e., the 1.P, 1.I and 1.D operating parameters for the 1st group and the 2.P, 2.I and 2.D operating parameters for the 2nd group).
- · Splitting the control range into three zones
 - To split the control range into three zones, define reference points 1 and 2 (i.e., the 1.RP1 and 2.RP1 setup parameters).
 - Define the 1st, 2nd and 3rd groups of PID constants (i.e., the 1.P, 1.I and 1.D operating parameters for the 1st group, the 2.P, 2.I and 2.D operating parameters for the 2nd group and the 3.P, 3.I and 3.D operating parameters for the 3rd group).


Selecting PID Constants According to the Deviation

PID constants can be selected according to the deviation in two ways. One method is to select a group of PID constants only by a deviation from a program setpoint. The other method is to use a reference point, as discussed earlier, as well as a deviation from a program setpoint, to switch between groups of PID constants.

[Method 1]

As shown in the figure below, the controller selects the PID constants of the group number set in PID group number (GRP) if the PV input value goes beyond the given deviation from the program setpoint.


- [1] The controller uses the 1st group of PID constants.
- [2] The controller uses the PID constants of the group number set in PID group number (GRP).



[Method 2]

As shown in the figure below, the controller selects an appropriate group of PID constants for each zone and, if the PV input value goes beyond the given deviation from the program setpoint, selects the PID constants of the group number set in PID group number (GRP).

- [1] The controller uses the 1st group of PID constants if the PV input value is both within the zone set off by the minimum value of the primary PV input range and reference point 1 and within the given reference deviation bandwidth.
- [2] The controller uses the 2nd group of PID constants if the PV input value is both within the zone set off by reference points 1 and the maximum value of the primary PV input range, and within the given reference deviation bandwidth.
- [3] The controller uses the PID constants of the group number set in PID group number (GRP).




■ Retaining the End-of-Program State (Hold-mode End)

This function keeps the controller in the same state as when program operation was completed.

When in hold operation, the controller retains its states of control output and event output. To cancel hold operation, use either key operation or external contact input. When the hold operation is cancelled, the control output is set to 0% or OFF, and the event output is set to OFF.

To retain the end-of-program state, set the Junction Code program parameter of the segment in question to "1."



■ Suspending the Progress of a Program (Wait Function)

When a running program moves from one segment to another, the wait function places the program in a wait (stand-by) state, by using a wait zone and a wait time, until any deviation is cancelled.

A wait zone is a deviation bandwidth from which the degree of PV input tracking is judged.

A wait time is the length of time that elapses until the PV input enters the wait zone. The program progresses if the PV input fails to re-enter the wait zone within the wait time.

When the program is in wait state, the time setpoints of Segment Time and Time Event parameters temporarily cease to be passed. At this point, the output based on the Time Event parameter is retained.

IM 05E01C02-44E 3rd Edition: May 31, 2006-00

<Toc> <4. Operations> 4-1

4. Operations

This chapter describes key entries for operating the controller. For operations using external contact inputs, see "1.5 Terminal Wiring Diagrams." If you cannot remember how to carry out an operation during setting, press the [DEF] key no more than four times. This brings you to the display (operating display) that appears at power-on.

4.1 Monitoring-purpose Operating Displays Available during Operation

The monitoring-purpose operating displays available during operation include those for controllers of cascade and cascade position proportional control and those for controllers of cascade heating/cooling control.

Operating Displays for Cascade and Cascade Position Proportional Control

In Cascade and Program Operation

SP1 Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the current setpoint (SP1), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the remaining time of the segment for which operation is in progress (TM), the current number of repetitions (RCY), and the total sum of repetitions.

CSP2 Display (PV2 lamp ON)

The PV input value of the secondary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the cascade setpoint of the secondary-loop (CSP2), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the remaining time of the segment for which operation is in progress (TM), the current number of repetitions (RCY), and the total sum of repetitions.

Target SP1 Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the current setpoint (SP1) and final target setpoint (TSP), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the program pattern name (only displayed when setting the program pattern name using an optional parameter setting tool (model: LL100-E10)).

<Toc> <4. Operations> 4-2

PV2/SP/OUT2 Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the PV input value of the secondary-loop (PV2), the program setpoint of the primary-loop (SP1), the cascade setpoint of the secondary-loop (C.SP2), and the control output value of the secondary-loop (OUT2), however, the valve opening (0 to 100%) in position proportional control.

Deviation Trend Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the deviation trend.

Pattern Display

The PV input value of the primary-loop appears on the PV display.


On the Setpoint display (LCD), the controller displays the selected program pattern.

Event Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the event number for which an event has occurred.

IM 05E01C02-44E 3rd Edition: May 31, 2006-00



○ In Cascade and Local of Primary-loop Operation

LSP1 Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the current setpoint (LSP1), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the remaining time of the segment for which operation is in progress (TM), the current number of repetitions (RCY), and the total sum of repetitions.

CSP2 Display (PV2 lamp ON)

The PV input value of the secondary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the cascade setpoint of the secondary-loop (CSP2), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the remaining time of the segment for which operation is in progress (TM), the current number of repetitions (RCY), and the total sum of repetitions.

Target SP1 Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the current setpoint (SP1) and final target setpoint (TSP), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the program pattern name (only displayed when setting the program pattern name using an optional parameter setting tool (model: LL100-E10)).

PV2/SP/OUT2 Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the PV input value of the secondary-loop (PV2), the target setpoint of the primary-loop (SP1), the cascade setpoint of the secondary-loop (C.SP2), and the control output value of the secondary-loop (OUT2), however, the valve opening (0 to 100%) in position proportional control.

Deviation Trend Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the deviation trend.

Pattern Display


The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the selected program pattern.

Event Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the event number for which an event has occurred.



■ Operating Displays for Cascade Heating/Cooling Control

In Cascade and Program Operation

SP1 Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the current setpoint (SP1), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the remaining time of the segment (TM) for which operation is in progress (TM), the current number of repetitions (RCY), and the total sum of repetitions.

CSP2 Display (PV2 lamp ON)

The PV input value of the secondary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the cascade setpoint of the secondary-loop (CSP2), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the remaining time of the segment for which operation is in progress (TM), the current number of repetitions (RCY), and the total sum of repetitions.

Target SP1 Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the current setpoint (SP1) and final target setpoint (TSP), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the program pattern name (only displayed when setting the program pattern name using an optional parameter setting tool (model: LL100-E10).

Heating/Cooling PV2/SP/OUT2 Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the PV input value of the secondary-loop (PV2), the program setpoint of primary-loop (SP1), the cascade setpoint of the secondary-loop (C.SP2), and the heating-side control output value (H2) and cooling-side control output value (C2) of secondary-loop.

Deviation Trend Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the deviation trend.

Pattern Display


The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the selected program pattern.

Event Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the event number for which an event has occurred.



○ In Cascade and Local of Primary-loop Operation

LSP1 Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the current setpoint (LSP1), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the remaining time of the segment (TM) for which operation is in progress, the current number of repetitions (RCY), and the total sum of repetitions.

CSP2 Display (PV2 lamp on)

The PV input value of the secondary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the local setpoint of the secondary-loop (CSP2), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the remaining time of the segment for which operation is in progress (TM), the current number of repetitions (RCY), and the total sum of repetitions.

Target SP1 Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the current setpoint (SP1) and final target setpoint (TSP), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the program pattern name (only displayed when setting the program pattern name using an optional parameter setting tool (model: LL100-E10).

Heating/Cooling PV2/SP/OUT2 Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the PV input value of the secondary-loop (PV2), the program setpoint of primary-loop (SP1), the cascade setpoint of the secondary-loop (C.SP2), and the heating-side (HEAT) control output (H2) and cooling-side (COOL) control output (C2) of secondary-loop.

Deviation Trend Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the deviation trend.

Pattern Display


The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the selected program pattern.

Event Display

The PV input value of the primary-loop appears on the PV display.

On the Setpoint display (LCD), the controller displays the event number for which an event has occurred.



4.2 Performing/Canceling Auto-tuning of Secondary-loop

Perform auto-tuning when you have finished setting of local setpoint of secondary-loop. Make sure the controller is in program (RUN) mode, in local (LOCAL) mode and automatic (AUTO) mode for the secondary-loop before carrying out auto-tuning. See "4.7 Switching between RUN and RESET Modes" to change to RUN, "4.8 Switching between Cascade (CAS) and Local (LSP)" to change to LOCAL for the secondary-loop and "4.9 Switching between AUTO and MAN of Secondary-loop" to change to AUTO.


PID constants are obtained by using the current program setpoint value at the start of autotuning.



NOTE


When on-off control is being used, auto-tuning cannot be carried out. Moreover, do not perform auto-tuning when controlling any of the following processes.

- Control processes with quick response such as flow control or pressure control
- · Processes where even temporary output on/off results in inconvenience
- Processes where a large output change at control element results in inconvenience
- Processes where variations in PV may exceed an allowable range, adversely affecting product quality
- 1. Bring the operating display into view (display appears at power on).




In steps 2 and later, illustrations of the LCD are cited to explain the procedure.


2. Press the key for more than 3 seconds to call up the main menu "PROG".




3. Press the key three times to display the main menu "LP2".




4. Press the key to display the submenu "PAR".



5. Press the key once again to display the parameter "AT".




6. Press the △ or ▽ key to display the required setpoint. Tuning for 1st group of PID is AT = 1.




To cancel auto-tuning, set AT = OFF.

7. Press the key once to register the setpoint. (This starts auto-tuning.) If the key is pressed when AT = OFF, auto-tuning will be cancelled. In this case, PID contains the value existing before auto-tuning.



8. During auto-tuning, the panel indications become as shown below.



Auto-tuning is complete when the MAN lamp goes off.

4.3 Performing/Canceling Auto-tuning of Primaryloop

Perform auto-tuning when you have finished creating program patterns. Make sure the controller is in program (RUN) mode, and in cascade (CAS) mode, before carrying out auto-tuning. See "4.7 Switching between RUN and RESET Modes" to change to RUN and "4.8 Switching between Cascade (CAS) and Local (LSP)" to change to cascade (CAS).

PID constants are obtained by using the current program setpoint value at the start of autotuning.


* To perform auto-tuning of the primary-loop, PID of the secondary-loop should be the appropriate value.



NOTE


When on-off control is being used, auto-tuning cannot be carried out. Moreover, do not perform auto-tuning when controlling any of the following processes.

- Control processes with quick response such as flow control or pressure control
- Processes where even temporary output on/off results in inconvenience
- Processes where a large output change at control element results in inconvenience
- Processes where variations in PV may exceed an allowable range, adversely affecting product quality
- 1. Bring the operating display into view (display appears at power on).




In steps 2 and later, illustrations of the LCD are cited to explain the procedure.


2. Press the key for more than 3 seconds to call up the main menu "PROG".




3. Press the key twice to display the main menu "LP1".




4. Press the key to display the submenu "PAR".



5. Press the key once again to display the parameter "AT".




6. Press the △ or ▽ key to display the required setpoint. Tuning for 1st group of PID is AT = 1.




To cancel auto-tuning, set AT = OFF.

7. Press the key once to register the setpoint. (This starts auto-tuning.)
If the key is pressed when AT = OFF, auto-tuning will be cancelled. In this case, PID contains the value existing before auto-tuning.



8. During auto-tuning, the panel indications become as shown below.




Auto-tuning is complete when the MAN lamp goes off.

4.4 Setting PID of Secondary-loop Manually


If you know the values to be set or if suitable PID constants cannot be obtained by autotuning, follow the procedure below to set values.

1. Bring the operating display into view (display appears at power on).




In steps 2 and later, illustrations of the LCD are cited to explain the procedure.


2. Press the key for more than 3 seconds to call up the main menu "PROG".




3. Press the key three times to display the main menu "LP2".




4. Press the key once to display the submenu "PAR".




5. Press the key once to display the submenu "1.PID".




6. Press the key once to display the parameter "1.P".



7. Press the \(\triangle \) or \(\triangle \) key to display the required setpoint.




8. Press the key once to register the setpoint.



The same steps can be used for integral time (1.l) and derivative time (1.D) that are displayed after this.


9. Press the key for more than 3 seconds. This returns you to the display shown at power-on (figure below).



4.5 Setting PID of Primary-loop Manually


If you know the values to be set or if suitable PID constants cannot be obtained by autotuning, follow the procedure below to set values.

1. Bring the operating display into view (display appears at power on).




In steps 2 and later, illustrations of the LCD are cited to explain the procedure.


2. Press the key for more than 3 seconds to call up the main menu "PROG".




3. Press the key twice to display the main menu "LP1".




4. Press the key once to display the submenu "PAR".




5. Press the key once to display the submenu "1.PID".




6. Press the key once to display the parameter "1.P".



7. Press the or key to display the required setpoint.




8. Press the key once to register the setpoint.



The same steps can be used for integral time (1.1) and derivative time (1.D) that are displayed after this.

9. Press the key for more than 3 seconds. This returns you to the display shown at power-on (figure below).



4.6 Selecting Program Pattern Number (PT.No)


The following operating procedure selects program pattern 1. A program pattern number can only be selected when the controller is in a RESET mode.




NOTE

If contact input, which is used to select between program pattern numbers is on, any program pattern number cannot be selected by key operation.

1. Bring the operating display into view (appears at power-on).




2. Press the PT.No key. This selects the program pattern number.



4.7 Switching between RUN and RESET Modes

The following operating procedure switches the RUN mode and the RESET mode.

1. Brings the operating display into view (appears at power-on).



2. Press the key for <u>2 seconds</u>. The selected program pattern starts.



3. Press the RESET key for <u>2 seconds</u>. The running program stops.



When in the RESET mode, the controller provides the following input/output values.


PV input	Value of process variable
Control output	Preset output value (factory-set to 0%)
Event output	OFF, if there is any event.

4.8 Switching between Cascade (CAS) and Local (LSP)




If Cascade and Local have been switched using contact input, when the contact input is ON, switching between Cascade and Local cannot be achieved by keystroke.

1. Brings the operating display into view (appears at power-on).



2. Press the MODE: LSP mode parameter.

The figure below is an example of changing the CASCADE mode to the LOCAL mode.



3. Press the key once. The controller switches to local setpoint of secondary-loop. The figure below is an example of the display after a change from the CAS mode to the LSP mode.



* CAS lamp is ON in Cascade operation.


4.9 Switching between AUTO and MAN of Secondary-loop



NOTE

If AUTO and MAN have been switched using contact input, when the contact input is ON, switching between AUTO and MAN cannot be achieved by keystroke.

1. Brings the operating display into view (appears at power-on).




2. [To change from AUTO to MAN mode]

Press the key several times to display the MODE:MAN2 mode parameter.


[To change from MAN to AUTO mode]

Press the MODE key several times to display the MODE:AUTO2 mode parameter.

The figure below is an example of changing the AUTO mode to the MAN mode.



3. Press the key once. The controller switches to either MAN-mode or AUTO-mode operation. The figure below is an example of the display after a change from the AUTO mode to the MAN mode.



* MAN lamp is OFF in AUTO.

4.10 Manipulating Control Output during Manual Operation




NOTE


Control output cannot be changed if the controller is in the RESET mode. In this case, the preset output value (operating parameter PO) will be output.

A control output value is linked with a display value changed using the or key. Note that the control output changes as displayed without requiring the key.

1. Bring manual operating display into view. For switching to manual operation, see "4.9 Switching between AUTO and MAN of Secondary-loop."




2. Press the \triangle or \bigcirc key to change a control output value. You don't need to press the \bigcirc key.



■ Manipulating the Control Output during Heating/Cooling Control


Showing the Heating/Cooling OUT display.



Controller Behavior and Control Output Manipulation when the Dead Band is Positive

The following is an example when the DB parameter is set at 12.4%.


Inversely, if you hold down the \triangle key with the cooling-side output under manipulation (i.e., heating-side output H2 = 0.0%), the cooling-side output (C2 =) decreases. Consequently, both the heating-side and cooling-side outputs go to 0.0%. If you keep the \triangle key held down longer, you enter the state of manipulating the heating-side output, and its value begins to increase.



Change in manipulated output when the dead band is positive

Controller Behavior and Control Output Manipulation when the Dead Band is Negative

The following is an example when the DB parameter is set at -12.4%.




Change in manipulated output when the dead band is negative

■ Manipulating the Control Output during Position Proportional Control

The controller continues to provide control output <u>as long as the</u> <u>v or key is being pressed.</u>

✓ key: Closes the valve.△ key: Opens the valve.



Note: The output high limit (OH) and output low limit (OL) do not restrict the manual output of position proportional control.


IM 05E01C02-44E 3rd Edition: May 31, 2006-00

4.11 Enabling/Disabling Hold Mode of Program Operation

Enabling/disabling the hold mode of program operation should be done when the controller is in operation.

The following operating procedure is an example of setting program operation in the hold mode.

1. Bring the operating display into view (appears at power-on).




2. [To enable the hold mode of program operation]

Press the ||MODE| key once to display the HOLD:ON mode parameter.


[To disable the hold mode of program operation]

Press the MODE key once to display the HOLD:OFF mode parameter.

The figure below is an example of enabling the hold mode of program operation.



3. Press the key once. The controller switches to either hold mode or non-hold mode.




- * Other operating procedures for disabling the hold mode:
 - [1] Press the RUN key for two seconds during hold-mode operation. In this case, the controller resumes program operation.
 - [2] Execute the "advance" function during hold-mode operation. In this case, the segment is advanced.

4.12 Changing Program Setpoint when in Hold Mode


The following operating procedure changes program setpoint when program operation in soak segment is put in the hold mode.

When you have finished changing the setpoints, disable the hold mode of program operation as instructed in "4.11 Enabling/Disabling Hold Mode of Program Operation." The controller resumes program operation when the hold mode is disabled.


1. Set program operation in the hold mode. To do this, see "4.11 Enabling/Disabling Hold Mode of Program Operation".




2. Press the key once to display the symbol ">> ".



3. Press the △ or ▽ key to change the setpoint.



4. Press the key once to register the setpoint.



How to Change the Target Setpoint in the Segment being in Operation


- 1. Set the program operation in the hold mode.
- Change the target setpoint of the corresponding segment of operation program on the program parameter setting display.
- When the hold mode of program operation is disabled, the controller resumes the control toward the changed target setpoint.

Note: To perform the above, specify "programming by setting segment times" for segment setting method (SEG.T setup parameter), and do not change the hold SP and hold time on the operating display in HOLD mode.


4.13 Executing "Advance" Function

The following operating procedure advances the controller from segment 1 to segment 2. If you execute the "advance" function during hold-mode operation, the hold mode is disabled.


1. Bring the current operating display for program operation into view.



2. Press the MODE key twice to display the ADV:ON mode parameter.



3. Press the key once. The controller resumes operation from the target setpoint of segment 1.




4.14 Switching to Local-mode (LOCAL) of Primaryloop Operation


The controller can be switched to local-mode operation when it is in program operation or in a RESET mode.

The following operating procedure switches the controller to local-mode operation during program operation.


1. Bring the current display for program operation into view.



2. Press the key several times to display the LOC:ON mode parameter.




3. Press the key once. The controller begins running with a local setpoint (L.SP). The figure below is an example of operating the controller with the local setpoint of 50.0°C.




4.15 Changing Setpoint during Local-mode of Primary-loop Operation

The following operating procedure changes setpoint during local-mode operation.


1. Change the controller to local-mode operation. To do this, see "4.14 Switching to Local-mode (LOCAL) of Primary-loop Operation."



2. Press the \triangle or ∇ key to change the local setpoint.



3. Press the key once to register the setpoint.



<Toc>


5. Troubleshooting and Maintenance

5.1 Troubleshooting

■ Troubleshooting Flow

If the operating display does not appear after turning on the controller's power, follow the measures in the procedure below.

If a problem appears complicated, contact our sales representative.





IMPORTANT

Take note of the parameter settings when asking the vendor for repair.

■ Errors at Power on

The following table shows errors that may be detected by the fault diagnosis function when the power is turned on.

Display position (Note)	Error indication	Description of error	PV	Control output	Alarm output	Retransmission output	Communication	Remedy	
	E000	Faulty RAM	None Undefined		l n	055	00/		
	E001	Faulty ROM			0% or less or OFF	OFF	0% or less	Stopped	Faulty
1	E002	System data error		0. 0	Undefined	Undefined		Contact us	
	PV decimal point blinks.	Faulty calibration value	Normal action (out of accuracy)		for repair.				
2	Error code (See description below.)	Parameter error	Normal action	Normal action	Normal action	Normal action	Normal action	Check and set the initialized parameters.	

Note 1: PV display

2: Setpoint display


An error code is displayed in the event of an error, according to its type.

An error code is a two-digit figure in which a combination of 6 bits of on and off is converted into a decimal number.

The following shows the relationship between each bit and parameter to be checked for abnormality.

Bit No.	6	5	4	3	2	1	0
Parameter to be checked	Operation mode/output	Operating parameters	Setup parameters	Range data	UP mode	-	Calibration data

For example, if an error occurs with the operating parameter and calibration data, the error code will be as follows:



■ Possible Errors during Operation

The following shows possible errors occurring during operations.

Display position (Note)	Error indication	Description of error	PV	Control output	Alarm output	Retransmis- sion output	Commu- nication	Remedy	
	Displays "RJC" and PV alternately	RJC error	Measured with RJC=OFF	Normal action				Faulty	
	E300	ADC error	105%	In AUTO:				Contact us for repair.	
3	B.OUT	PV burnout error	Dependent on the BSL parameter Up-scale: 105% Down-scale: -5%	Preset value output In MAN: Normal action		Normal action		Check wires and sensor.	
	OVER or -OVER	Excessive PV Out of -5 to 105%	-5% or 105%	Normal action	N 1		Name	Check process.	
	E200	Auto-tuning failure (Time-out)		Action with PID existing before auto-tuning	Normal action		Normal action	Check process. Press any key to erase error indication.	
		Feedback resistor burnout	Normal action	Stopped		Stopped		Check the feedback resistor.	
2	Left end of Setpoint display unit blinks.	Faulty communication line		Normal action		Normal action		Check wires and communication parameters, and make resetting. Recovery at normal receipt	
1	Decimal point at right end lights.	Runaway (due to defective power or noise)	Undefined	0% or less or OFF	OFF	0% or less	Stopped	Faulty if power off/on does not reset start the unit. Contact us for repair.	
No display	All indications off	Power off	None					Check for abnormal power.	

Note 1: PV display

■ Remedies if Power Failure Occurs during Operations

The operation status and remedies after a power failure differ with the length of power failure time:

Instantaneous Power Failure of 20 ms or less

A power failure is not detected. Normal operation continues.

Power Failure of about 2 seconds or less

The following show effects caused in "settings" and "operation status."

Alarm action	Continues. Alarm with standby function will enter standby status.
Settig parameter	Set contents of each parameter are retained.
Auto-tuning	Cancelled.
Control action	Action before power failure continues.

^{2:} Setpoint display3: Display showing the PV of the corresponding loop

• Power Failure of more than about 2 seconds

The following show effects caused in "settings" and "operation status."

Alarm action	Continues. Alarm with standby function will enter standby status.			
Setting parameter	Set contents of each parameter are retained.			
Auto-tuning	Cancelled.			
Control action	Differs with se	tting of setup parameter "R.MD" (restart mode).		
	R.MD setting	Control action after recovery from power failure		
	CONT	Continues action before power failure. (Factory-set default) For position-proportional type, when V.MOD = Valve position estimating type, starts action from 0%.		
	MAN	Outputs preset output value (PO) as control output and continues action set before power failure in MAN mode. For position-proportional type, when V.MOD = Valve position feedback type, starts action from feedback input condition at recovery from power failure. When V.MOD = Valve position estimating type, starts action from 0%. For heating/cooling control, starts action from heating-side output value and cooling-side output value of 50% of control computation output.		
	AUTO	Outputs preset output value (PO) as control output and continues action set before power failure in AUTO mode. For position-proportional type, when V.MOD = Valve position feedback type, starts action from feedback input condition at recovery from power failure. When V.MOD = Valve position estimating type, starts action from 0%. For heating/cooling control, starts action from heating-side output value and cooling-side output value of 50% of control computation output.		

IM 05E01C02-44E 3rd Edition: May 31, 2006-00

■ Troubleshooting when the Controller Fails to Operate Correctly

If your control tasks are not successful, check the preset parameters and controller wiring before concluding the controller to be defective. The following show some examples of troubleshooting you should refer to in order to avoid the possibility of other problems.

The Controller does not Show the Correct Process Variable (PV).

The UP550 controllers have a universal input.

The type of PV input can be set/changed using the parameter "IN1". At this point, the controller must be wired correctly according to the selected type of PV input. Check the wiring first if the controller fails to show the correct PV value. To do this, refer to "2. Initial Settings."

With the parameters "RH1", "RL1", "SDP1", "SH1" and "SL1", it is possible to scale the input signal and change its number of decimal places. Also check that these parameters are configured correctly.

The Controller does not Provide any Control Output or the Control Output does not Change at all.

- The UP550 controllers have a universal output. The type of control output can be set/changed using the parameter "OT2". At this point, the controller must be wired correctly according to the selected type of control output. Check the wiring first if the controller provides no control output. To do this, refer to "1.5 Terminal Wiring Diagrams." With the parameters "OH" and "OL", it is possible to set/change the high and low limits of control output. The control output may not change at all, however, because of restrictions on these parameters. Also check the restrictions on these parameters.
- The control output can only be changed when the controller is in the MAN mode.
 If the MAN lamp is off (i.e., the controller is in the AUTO mode), you cannot change the control output using key operation.

The Control Output does not Change soon after the Target Setpoint SP has been Changed.

If this happens, check the setpoint of the parameter "MOD1". In cases where fixed-point control is selected as the PID control mode (MOD1 = 1), tracking based on the I-term works to prevent the control output from changing suddenly even if the target setpoint SP is varied.

The control output therefore may appear to be working incorrectly at first; however it gradually adapts itself to the new target setpoint.

5.2 Maintenance

This section describes the cleaning and maintenance of the UP550.

5.2.1 Cleaning

The front panel and operation keys should be gently wiped with a dry cloth.



NOTE

Do not use alcohol, benzine, or any other solvents.

5.2.2 Replacing Brackets

When the brackets are broken or lost, purchase the following brackets for replacement.

Target Model	Part No.	Sales Unit
UP550	T9115NL	A large bracket and small bracket in pair

SEE ALSO

"1.2 How to Install," for how to replace brackets.

5.2.3 Attaching Terminal Cover

When a terminal cover is necessary, purchase the following part.

Target Model	Part No.	Sales Unit
UP550	T9115YD	1

■ Attaching Terminal Cover


The procedure for attaching the terminal cover is as follows.



Do not touch the terminals on the rear panel when power is being supplied to the controller. Doing so may result in electric shock.

Before attaching the terminal cover, turn off the source circuit breaker and use a tester to check that the power cable is not conducting any electricity.

1. Before attaching the terminal cover, fold it once or twice so that the side which has the "Handle With Care" symbol (Λ) , is on the outside.




Folding Direction of Terminal Cover



NOTE

Do not fold the terminal cover the wrong way, doing so not only reduces the cover's strength but may also cause the hinge to crack, thereby disabling attachment.

2. With the cover properly folded, fit its top and bottom holes to the protrusions of the mounting brackets.



Attaching Terminal Cover

5.2.4 Replacing Parts with a Limited Service Life

The following UP550 parts have a limited service life.

The service life given in the table assume that the controller is used under normal operating conditions.

Part	Service life
Aluminum electrolytic condenser	About 10 years (rated)
Lithium battery for backup	About 10 years (rated)
Alarm output relays	About 100,000 more ON-OFF operations or with resistance load
Control output relays	About 100,000 more ON-OFF operations or with resistance load

If any of these parts, except control output relays, cause a controller failure due to deterioration, contact your dealer for replacement at your cost.

SEE ALSO

"5.2.5 Replacing Control Output Relays," for how to replace the control output relays.

5.2.5 Replacing Control Output Relays

This subsection describes how to replace the control output relays.

Since inspection is needed in case parts are replacement will be carried out by a YOKOGAWA engineer or an engineer certified by YOKOGAWA. When replacement is required, contact your nearest YOKOGAWA dealer.




Always turn off the power before starting the work in order to avoid electric shock.


Do not pull out the internal unit for any other purpose other than to replace the control output relays.

1. Insert a flat-blade screwdriver (tip width of 6 mm is recommended) into the opening with the tip in parallel with the front panel, and then turn the screwdriver gently. Take this procedure to four openings 1, 2, 3 and 4 (see the figure below) on the upper and lower parts of the bezel, in order.

The bezel slightly moves forward from the housing.




2. Push up the center of the bottom gasket of bezel by a finger to release the latch.




3. Insert the flat-blade screwdriver into the four openings and flip the tip forward to move the bezel more forward.


4. Hold the bezel and pull it along with the internal unit out of the housing. (Note) Be careful not to damage the RJC sensor.



5. The location and number of the relays differ depending on the model code of the UP550. Confirm the location of the control output relay to be replaced before pulling out the relay.



6. Pull out the relay to be replaced.
The control output relays are easy to remove and mount, since they are connected via a socket onto the print boards.




Insert the new relay in the socket. Use the following relay.

Manufacturer	OMRON
Model	G6B-2114P-FD-US-P6B
Power supply	12 V DC

7. Insert the internal unit into the housing.

Apply power to the controller and confirm that the initial operating display is shown. If the operating display is not shown properly, turn off the controller and pull out the internal unit. Then, insert it into the housing again.



This completes replacement of the control output relay.

6. Parameters


6.1 Parameter Map

This section contains "Operating Parameter Map" and "Setup Parameter Map" for UP550 as a guideline for setting parameters.

These maps are helpful in finding the positions of the displays when setting the parameters, and should be used as a quick reference for the entire range of parameter displays.

UP550 Operating Parameter Map

Operating Display



- *1 Not displayed for ON/OFF control
- *2 Not displayed for heating/cooling control or position proportional control
- *3 Displayed for heating/cooling control
- *4 Displayed for heating/cooling control or position proportional control

SET : Press the key once.


MODE : Press the losp key once.

DISP : Press the losp key once.


SET1S : Press the key for 1 second.

SET3S : Press the key for 3 seconds.

DISP key once.



- *5 Main menu LP2 is displayed when UP mode is "Cascade control."
- *6 Main menu USR is displayed when UP mode is "Loop control with PV switching" or "Loop control with PV auto-selector."
- *7 Main menu PYS2 is displayed when UP mode is "Cascade control," "Loop control with PV switching."




Pressing the DISP key once when a parameter setting display is shown retrieves the submenu of that parameter setting display.

SET : Press the key once.

□ISP : Press the □ISP key once.

□ Press the □ or ▼ key once.



Note: The parameter items shown on the [TEST] submenu of the setup parameter setting display are to be used by Yokogawa service personnel to check the controller functions. User cannot set or change these parameters.

- *1 Submenu R485 is displayed only for the controller with communication functions.
- *2 Submenu VALV is displayed only for the position proportional controller.

6.2 Lists of Parameters

This section describes the functions of parameters briefly. In addition, each parameter table has a "User Setting" column, where you can record your setpoints when setting them in the controller.

- * Parameters relating to PV or program setpoints should all be set in real numbers. For example, use temperature values to define program setpoints and PV event setpoints for temperature input.
- * The "User Setting" column in the table is provided for the customer to record setpoints.
- * Numbers in () are the parameter setpoints that apply when the communication function is used. ex. AUTO2 (0), MAN2 (1).

■ Operation Mode Parameters

Located in: MODE key (MODE key on the instrument's front panel)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
HOLD	Pause of program operation	Set as "HOLD = ON" to enable the hold mode of program operation.		
ADV	Advance of segment	Set as "ADV = ON" to advance from the current segment to the next segment.		
LOC	Local-mode operation	Set as "LOC = ON" to switch from program operation or RESET mode	e to local-mod	de operation.
A/M2	AUTO/MAN switching (secondary)	To switch between AUTO and MAN: To switch to AUTO mode, display "MODE: AUTO2 (0)", then press the key. To switch to MAN mode, display "MODE: MAN2 (1)", then press the key.		
LSP/ CAS	LSP/CAS switching	To switch between LSP and CAS: To switch to LSP mode, set as "MODE: LSP". To switch to CAS mode, set as "MODE: CAS".		
SST	Start-of-program segment number	1 to 99 Program operation begins with the segment whose number is specified by this parameter.	1	

■ Operating Parameters

• Instrument Alarm Setting Parameters

Located in: Main menu = AL

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	
A1	Instrument alarm-1 setpoint	Allows alarm action to be set irrespective of the program.	PV high limit/SP high limit alarm: 100.0% of PV input range		
A2	Instrument alarm-2 setpoint	PV alarm / SP alarm: -100.0 to 100.0% of PV input range	Deviation alarm: 0.0% of PV input range span Other PV/SP low limit		
A3	Instrument alarm-3 setpoint	input range span Output alarm: -5.0 to 105.0%	input range span Output alarm: -5.0 to 105.0% alarm: 0.0% of PV input range of PV i	alarm: 0.0% of PV input range Output high limit	
A4	Instrument alarm-4 setpoint		alarm: 100.0% Output low limit alarm: 0.0%	-	

The following parameters are that for Cascade Primary-loop.

Operation-related Parameters

Located in: Main menu = LP1; Submenu = PAR

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
AT	Auto-tuning	OFF (0): No auto-tuning 1: Auto-tuning for 1st group of PID 2: Auto-tuning for 2nd group of PID 3: Auto-tuning for 3rd group of PID 4: Auto-tuning for 4th group of PID 5 to 8: Perform auto-tuning on a group basis in the same way as 1 to 4 9: Performs auto-tuning to all groups 1 to 8.	OFF (0)	
SC	"SUPER" function	OFF (0): Disable 1: Overshoot suppressing function Suppresses overshoots generated by abrupt changes in the target setpoint or by disturbances. 2: Hunting suppressing function (Stable mode) Suitable to stabilize the state of control when the load varies greatly, or the target setpoint is changed. Enables to answer the wider characteristic changes compared with Response mode. 3: Hunting suppressing function (Response mode) Enables quick follow-up and short converging time of PV for the changed target setpoint. Note: Use "SUPER" function (SC) 2 or 3 in PID control or PI control. "SUPER" function 2 or 3 is not available in the following controls: 1) ON/OFF control 2) P control (control for proportional band only) 3) PD control (control for proportional band and derivative item only) 4) Heating/cooling control Do not use hunting suppressing function when control processes with response such as flow or pressure control.	OFF (0)	
BS	PV input bias	-100.0% to 100.0% of primary PV input range span Used to correct the PV input value.	0.0% of primary PV input range span	
FL	PV input filter	OFF (0), 1 to 120 sec. Used when the PV input value fluctuates.	OFF (0)	
ORB	ON/OFF rate detection band	0.0 to 100.0% of primary PV input range span	1.0% of primary PV input range span	
ORH	ON/OFF rate high limit	ORL + 1 digit to 105.0%	100.0%	
ORL	ON/OFF rate low limit	-5.0% to ORH - 1 digit	0.0%	
S.TM	Starting time of program pattern operation	0.00 to 99.59 ("hour, minute" or "minute, second") The controller begins control when the specified time has passed after power-on.	0.00	

The following parameters are that for Cascade Primary-loop.

PID-related Parameters

Located in: Main menu = LP1; Submenu = 1.PID

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
1.P	Proportional band	0.1 to 999.9% of primary PV input range	5.0%	
1.l	Integral time	OFF (0), 1 to 6000 sec.	240 sec.	
1.D	Derivative time	OFF (0), 1 to 6000 sec.	60 sec.	
1.OH	Output high limit	-5.0 to 105.0%	100%	
1.OL	Output low limit	-5.0 to 105.0% (1.OL < 1.OH) SD (shutdown): Set in manual operation in 4-20 mA control output. Output is 0 mA.	0.0%	
1.MR	Manual reset	-5.0 to 105.0% (enabled when integral time "1.1" is OFF) The manual reset value equals the output value when PV = SP is true. For example, if the manual reset value is 50%, the output value is 50% when PV = SP becomes true.	50.0%	
1.H	ON/OFF control hysteresis	In ON/OFF control: 0.0 to 100.0% of primary PV input range span Hysteresis can be set in the program setpoint when the controller is performing ON/OFF control. Point of ON/OFF action (Program setpoint) On Hysteresis PV value	ON/OFF control: 0.5% of primary PV input range span	
1.DR	Direct/reverse action switching	REVERSE (0): reverse action, DIRECT (1): direct action Control output 100% Direct action O% Deviation (PV-SP)	REVERSE (0)	
1.PO	Preset output	-5.0 to 105.0% In RESET mode, fixed control output can be generated.	0.0%	

If you are using two or more groups of PID parameters, use the following table to record their values.

Parameter	n=2	n=3	n=4	n=5	n=6	n=7	n=8
n.P							
n.l							
n.D							
n.OH							
n.OL							
n.MR							
n.H							
n.DR							
n.PO							

The following parameters are that for Cascade Secondary-loop.

Operation-related Parameters

$\textbf{Located in: Main menu} = \textbf{LP2} \; ; \; \textbf{Submenu} = \textbf{PAR}$

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
AT	Auto-tuning	OFF (0): No auto-tuning 1: Auto-tuning for 1st group of PID 2: Auto-tuning for 2nd group of PID 3: Auto-tuning for 3rd group of PID 4: Auto-tuning for 4th group of PID 5 to 8: Perform auto-tuning on a group basis in the same way as 1 to 4 9: Performs auto-tuning to all groups 1 to 8.	OFF (0)	
SC	"SUPER" function	OFF (0): Disable 1: Overshoot suppressing function Suppresses overshoots generated by abrupt changes in the target setpoint or by disturbances. 2: Hunting suppressing function (Stable mode) Suitable to stabilize the state of control when the load varies greatly, or the target setpoint is changed. Enables to answer the wider characteristic changes compared with Response mode. 3: Hunting suppressing function (Response mode) Enables quick follow-up and short converging time of PV for the changed target setpoint. Note: Use "SUPER" function (SC) 2 or 3 in PID control or PI control. "SUPER" function 2 or 3 is not available in the following controls: 1) ON/OFF control 2) P control (control for proportional band only) 3) PD control (control for proportional band and derivative item only) 4) Heating/cooling control Do not use hunting suppressing function when control processes with response such as flow or pressure control.	OFF (0)	
BS	PV input bias	-100.0% to 100.0% of secondary PV input range span Used to correct the PV input value.	0.0% of secondary PV input range span	
FL	PV input filter	OFF (0), 1 to 120 sec. Used when the PV input value fluctuates.	OFF (0)	
ORB	ON/OFF rate detection band	0.0 to 100.0% of secondary PV input range span	1.0% of secondary PV input range span	
ORH	ON/OFF rate high limit	ORL + 1 digit to 105.0%	100.0%	
ORL	ON/OFF rate low limit	-5.0% to (ORH - 1 digit)	0.0%	

PID-related Parameters

Located in: Main menu = LP2; Submenu = 1.PID

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
1.P	Proportional band/Heating- side proportional band (in heating/cooling control)	0.1 to 999.9% of secondary PV input range In heating/cooling control: 0.0 to 999.9% (heating-side on/off control applies when 0.0)	5.0%	
1.1	Integral time Heating-side integral time (in heating/cooling control)	OFF (0), 1 to 6000 sec.	240 sec.	
1.D	Derivative time Heating-side derivative time (in heating/cooling control)	OFF (0), 1 to 6000 sec.	60 sec.	
1.OH	Output high limit Heating-side output high limit (in heating/cooling control)	-5.0 to 105.0% Heating-side limiter in heating/cooling control: 0.0 to 105.0% (1.OL < 1.OH)	100% Heating/cooling control: 100.0%	
1.OL	Output low limit Cooling-side output high limit (in heating/cooling control)	-5.0 to 105.0% Cooling-side limiter in heating/cooling control: 0.0 to 105.0% (1.OL < 1.OH) SD (shutdown): Set in manual operation in 4-20 mA control output. Output is 0 mA.	0.0% Heating/cooling control: 100.0%	
1.MR	Manual reset	-5.0 to 105.0% (enabled when integral time "1.1" is OFF) The manual reset value equals the output value when PV = SP is true. For example, if the manual reset value is 50%, the output value is 50% when PV = SP becomes true.	50.0%	
1.H	ON/OFF control hysteresis Heating-side ON/OFF control hysteresis (in heating/cooling control)	In ON/OFF control: 0.0 to 100.0% of secondary PV input range span In position proportional PID control or heating/cooling control: 0.0 to 100.0% Hysteresis can be set in the local setpoint when the controller is performing ON/OFF control. Point of ON/OFF action (Local setpoint) On Hysteresis Off PV value	ON/OFF control: 0.5% of secondary PV input range span Position proportional PID control and heating/cooling control: 0.5%	
1.DR	Direct/reverse action switching	REVERSE (0): reverse action, DIRECT (1): direct action Control output 100% Reverse action O' Direct action Deviation (PV-SP)	REVERSE (0)	
1.Pc	Cooling-side proportional band	0.0 to 999.9% of secondary PV input range (Cooling-side ON/OFF control applies when 0.0)	5.0%	
1.lc	Cooling-side integral time	OFF, 1 to 6000 sec.	240 sec.	
1.Dc	Cooling-side derivative time	OFF, 1 to 6000 sec.	60 sec.	
1.Hc	Cooling-side ON/OFF	0.0 to 100.0%	0.5%	
1.DB	control hysteresis Dead band	In heating/cooling control: -100.0 to 50.0% In position proportional PID control: 1.0 to 10.0% In heating/cooling control: When setting any positive value, there is a region where none of the heating- and cooling-side output is presented; when setting any negative value, there is a region where both of the heating- and cooling-side outputs are presented. When setting a value of zero, either the heating- or cooling-side output is provided. In position proportional control: set the range so none of the outputs turn on.	3.0%	
1.PO	Preset output/Heating- side preset output (in heating/cooling control)	-5.0 to 105.0% In RESET mode, fixed control output can be generated. In heating/cooling control: Heating-side 0.0 to 105.0%	0.0%	
1.Oc	Cooling-side preset output	0.0 to 105.0% In RESET mode, cooling-side fixed control output can be generated.	0.0%	

If you are using two or more groups of PID parameters, use the following table to record their values.


Parameter	n=2	n=3	n=4	n=5	n=6	n=7	n=8
n.P							
n.l							
n.D							
n.OH							
n.OL							
n.MR							
n.H							
n.DR							
n.Pc							
n.lc							
n.Dc							
n.Hc							
n.DB							
n.PO							
n.Oc							

The following parameters are that for Cascade Primary-loop.

Ten-segment Linearizer 1 Parameters


Located in: Main menu = PYS1

· Ten-segment linearizer biasing (factory-set default)



-66.7% to 105.0% of primary PV input range

Ten-segment linearizer approximation




Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
1.a1	Ten-segment linearizer 1 input-1	-66.7% to 105.0% of primary PV input range	0.0% of primary PV input range	
1.b1	Ten-segment linearizer 1 output-1	-66.7% to 105.0% of primary PV input range span -66.7% to 105.0% of primary PV input range when in ten-segment linearizer approximation	0.0% of primary PV input range span 0.0% of primary PV input range when in ten-segment linearizer approximation	
1.a2	Ten-segment linearizer 1 input-2	-66.7% to 105.0% of primary PV input range	0.0% of primary PV input range	
1.b2	Ten-segment linearizer 1 output-2	-66.7% to 105.0% of primary PV input range span -66.7% to 105.0% of primary PV input range when in ten-segment linearizer approximation	0.0% of primary PV input range span 0.0% of primary PV input range when in ten-segment linearizer approximation	
1.a3	Ten-segment linearizer 1 input-3	-66.7% to 105.0% of primary PV input range	0.0% of primary PV input range	
1.b3	Ten-segment linearizer 1 output-3	-66.7% to 105.0% of primary PV input range span -66.7% to 105.0% of primary PV input range when in ten-segment linearizer approximation	0.0% of primary PV input range span 0.0% of primary PV input range when in ten-segment linearizer approximation	
1.a4	Ten-segment linearizer 1 input-4	-66.7% to 105.0% of primary PV input range	0.0% of primary PV input range	
1.b4	Ten-segment linearizer 1 output-4	-66.7% to 105.0% of primary PV input range span -66.7% to 105.0% of primary PV input range when in ten-segment linearizer approximation	0.0% of primary PV input range span 0.0% of primary PV input range when in ten-segment linearizer approximation	
1.a5	Ten-segment linearizer 1 input-5	-66.7% to 105.0% of primary PV input range	0.0% of primary PV input range	
1.b5	Ten-segment linearizer 1 output-5	-66.7% to 105.0% of primary PV input range span -66.7% to 105.0% of primary PV input range when in ten-segment linearizer approximation	0.0% of primary PV input range span 0.0% of primary PV input range when in ten-segment linearizer approximation	
1.a6	Ten-segment linearizer 1 input-6	-66.7% to 105.0% of primary PV input range	0.0% of primary PV input range	
1.b6	Ten-segment linearizer 1 output-6	-66.7% to 105.0% of primary PV input range span -66.7% to 105.0% of primary PV input range when in ten-segment linearizer approximation	0.0% of primary PV input range span 0.0% of primary PV input range when in ten-segment linearizer approximation	
1.a7	Ten-segment linearizer 1 input-7	-66.7% to 105.0% of primary PV input range	0.0% of primary PV input range	
1.b7	Ten-segment linearizer 1 output-7	-66.7% to 105.0% of primary PV input range span -66.7% to 105.0% of primary PV input range when in ten-segment linearizer approximation	0.0% of primary PV input range span 0.0% of primary PV input range when in ten-segment linearizer approximation	
1.a8	Ten-segment linearizer 1 input-8	-66.7% to 105.0% of primary PV input range	0.0% of primary PV input range	
1.b8	Ten-segment linearizer 1 output-8	-66.7% to 105.0% of primary PV input range span -66.7% to 105.0% of primary PV input range when in ten-segment linearizer approximation	0.0% of primary PV input range span 0.0% of primary PV input range when in ten-segment linearizer approximation	
1.a9	Ten-segment linearizer 1 input-9	-66.7% to 105.0% of primary PV input range	0.0% of primary PV input range	
1.b9	Ten-segment linearizer 1 output-9	-66.7% to 105.0% of primary PV input range span -66.7% to 105.0% of primary PV input range when in ten-segment linearizer approximation	0.0% of primary PV input range span 0.0% of primary PV input range when in ten-segment linearizer approximation	
1.a10	Ten-segment linearizer 1 input-10	-66.7% to 105.0% of primary PV input range	0.0% of primary PV input range	
1.b10	Ten-segment linearizer 1 output-10	-66.7% to 105.0% of primary PV input range span -66.7% to 105.0% of primary PV input range when in ten-segment linearizer approximation	0.0% of primary PV input range span 0.0% of primary PV input range when in ten-segment linearizer approximation	
1.a11	Ten-segment linearizer 1 input-11	-66.7% to 105.0% of primary PV input range	0.0% of primary PV input range	
1.b11	Ten-segment linearizer 1 output-11	-66.7% to 105.0% of primary PV input range span -66.7% to 105.0% of primary PV input range when in ten-segment linearizer approximation	0.0% of primary PV input range span 0.0% of primary PV input range when in ten-segment linearizer approximation	
1.PMD	Ten-segment linearizer 1 mode	Ten-segment linearizer biasing Ten-segment linearizer approximation	0	

The following parameters are that for Cascade Secondary-loop.

Ten-segment Linearizer 2 Parameters


Located in: Main menu = PYS2

· Ten-segment linearizer biasing (factory-set default)



-66.7% to 105.0% of secondary PV input range

Ten-segment linearizer approximation



Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
2.a1	Ten-segment linearizer 2 input-1	-66.7% to 105.0% of secondary PV input range	0.0% of secondary PV input range	
2.b1	Ten-segment linearizer 2 output-1	-66.7% to 105.0% of secondary PV input range span -66.7% to 105.0% of secondary PV input range when in ten-segment linearizer approximation	0.0% of secondary PV input range span 0.0% of secondary PV input range when in ten-segment linearizer approximation	
2.a2	Ten-segment linearizer 2 input-2	-66.7% to 105.0% of secondary PV input range	0.0% of secondary PV input range	
2.b2	Ten-segment linearizer 2 output-2	-66.7% to 105.0% of secondary PV input range span -66.7% to 105.0% of secondary PV input range when in ten-segment linearizer approximation	0.0% of secondary PV input range span 0.0% of secondary PV input range when in ten-segment linearizer approximation	
2.a3	Ten-segment linearizer 2 input-3	-66.7% to 105.0% of secondary PV input range	0.0% of secondary PV input range	
2.b3	Ten-segment linearizer 2 output-3	-66.7% to 105.0% of secondary PV input range span -66.7% to 105.0% of secondary PV input range when in ten-segment linearizer approximation	0.0% of secondary PV input range span 0.0% of secondary PV input range when in ten-segment linearizer approximation	
2.a4	Ten-segment linearizer 2 input-4	-66.7% to 105.0% of secondary PV input range	0.0% of secondary PV input range	
2.b4	Ten-segment linearizer 2 output-4	-66.7% to 105.0% of secondary PV input range span -66.7% to 105.0% of secondary PV input range when in ten-segment linearizer approximation	0.0% of secondary PV input range span 0.0% of secondary PV input range when in ten-segment linearizer approximation	
2.a5	Ten-segment linearizer 2 input-5	-66.7% to 105.0% of secondary PV input range	0.0% of secondary PV input range	
2.b5	Ten-segment linearizer 2 output-5	-66.7% to 105.0% of secondary PV input range span -66.7% to 105.0% of secondary PV input range when in ten-segment linearizer approximation	0.0% of secondary PV input range span 0.0% of secondary PV input range when in ten-segment linearizer approximation	
2.a6	Ten-segment linearizer 2 input-6	-66.7% to 105.0% of secondary PV input range	0.0% of secondary PV input range	
2.b6	Ten-segment linearizer 2 output-6	-66.7% to 105.0% of secondary PV input range span -66.7% to 105.0% of secondary PV input range when in ten-segment linearizer approximation	0.0% of secondary PV input range span 0.0% of secondary PV input range when in ten-segment linearizer approximation	
2.a7	Ten-segment linearizer 2 input-7	-66.7% to 105.0% of secondary PV input range	0.0% of secondary PV input range	
2.b7	Ten-segment linearizer 2 output-7	-66.7% to 105.0% of secondary PV input range span -66.7% to 105.0% of secondary PV input range when in ten-segment linearizer approximation	0.0% of secondary PV input range span 0.0% of secondary PV input range when in ten-segment linearizer approximation	
2.a8	Ten-segment linearizer 2 input-8	-66.7% to 105.0% of secondary PV input range	0.0% of secondary PV input range	
2.b8	Ten-segment linearizer 2 output-8	-66.7% to 105.0% of secondary PV input range span -66.7% to 105.0% of secondary PV input range when in ten-segment linearizer approximation	0.0% of secondary PV input range span 0.0% of secondary PV input range when in ten-segment linearizer approximation	
2.a9	Ten-segment linearizer 2 input-9	-66.7% to 105.0% of secondary PV input range	0.0% of secondary PV input range	
2.b9	Ten-segment linearizer 2 output-9	-66.7% to 105.0% of secondary PV input range span -66.7% to 105.0% of secondary PV input range when in ten-segment linearizer approximation	0.0% of secondary PV input range span 0.0% of secondary PV input range when in ten-segment linearizer approximation	
2.a10	Ten-segment linearizer 2 input-10	-66.7% to 105.0% of secondary PV input range	0.0% of secondary PV input range	
2.b10	Ten-segment linearizer 2 output-10	-66.7% to 105.0% of secondary PV input range span -66.7% to 105.0% of secondary PV input range when in ten-segment linearizer approximation	0.0% of secondary PV input range span 0.0% of secondary PV input range when in ten-segment linearizer approximation	
2.a11	Ten-segment linearizer 2 input-11	-66.7% to 105.0% of secondary PV input range	0.0% of secondary PV input range	
2.b11	Ten-segment linearizer 2 output-11	-66.7% to 105.0% of secondary PV input range span -66.7% to 105.0% of secondary PV input range when in ten-segment linearizer approximation	0.0% of secondary PV input range span 0.0% of secondary PV input range when in ten-segment linearizer approximation	
2.PMD	Ten-segment linearizer 2 mode	Ten-segment linearizer biasing Ten-segment linearizer approximation	0	

■ Setup Parameters

Program Setpoint-related Parameters

Located in: Main menu = PARA; Submenu = SP

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
SPT	SP tracking selection	OFF (0), ON (1) Tracking is performed when the mode changes from program to Local (The local setpoint keeps track of the program setpoint.)	OFF (0)	
TMU	Program time unit	Sets the time unit of a program. hh:mm (0): "hour, minute" mm:ss (1): "minute, second"	hh:mm (0)	
SEG.T	Segment setting method	Defines the method of programming. Note that changing the setpoint of this parameter deletes the program in question. 0: Programming by setting segment times 1: Programming by setting segment ramps	0	
PNC	Program pattern number clearance	The controller resets (clears) the program pattern number on the operating display to "0" at the end of program operation. OFF (0): Not cleared. ON (1): Cleared.	OFF (0)	
SPH1	Program setpoint-1 limiter upper limit	Place limits on the program setpoints when the controller is in program operation. 0.0% to 100.0% of primary PV input range.	100.0% of primary PV input range	
SPL1	Program setpoint-1 limiter lower limit	Note that SPL1 < SPH1	0.0% of primary PV input range	
SPH2	Program setpoint-2 limiter upper limit	Place limits on the local setpoints when the controller is in local operation. 0.0% to 100.0% of secondary PV input range.	100.0% of secondary PV input range	
SPL2	Program setpoint-2 limiter lower limit	Note that SPL2 < SPH2	0.0% of secondary PV input range	

Alarm-related Parameters

Located in: Main menu = PARA; Submenu = ALM

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
PEH1	PV event 1 hysteresis	Allows margins to be set for a PV event setpoint. With the hysteresis settings, it is possible to prevent relays from chattering.	0.5% of PV input range	
PEH2	PV event 2 hysteresis	Hysteresis for PV high limit alarm	span	
PEH3	PV event 3 hysteresis	Output Point of ON/OFF action (PV event setpoint)		
PEH4	PV event 4 hysteresis	On		
PEH5	PV event 5 hysteresis	Off		
PEH6	PV event 6 hysteresis	PV value 0.0 to 100.0% of PV input range span		
PEH7	PV event 7 hysteresis			
PEH8	PV event 8 hysteresis			
AL1	Instrument alarm-1 type	OFF (0), primary-side: 1 to 20, 25 to 31	1	
AL2	Instrument alarm-2 type	secondary-side: 41 to 60, 65 to 71 1: PV high limit (energized, no stand-by action) 2: PV low limit (energized, no stand-by action)	2	
AL3	Instrument alarm-3 type	3: Deviation high limit (energized, no stand-by action) 4: Deviation low limit (energized, no stand-by action) 5: Deviation high limit (de-energized, no stand-by action)	1	
AL4	Instrument alarm-4 type	Deviation high limit (de-energized, no stand-by action) For other alarm types, see the next page.	2	
HY1	Instrument alarm-1 hysteresis	0.0 to 100.0% of PV input range span Output alarm: 0.0 to 100.0% Allows margins to be set for an alarm setpoint.	0.5% of PV input range span Output	
HY2	Instrument alarm-2 hysteresis	·	alarm: 0.5%	
HY3	Instrument alarm-3 hysteresis			
HY4	Instrument alarm-4 hysteresis	Off Hysteresis PV value		
AMD	Alarm mode	Allows the instrument alarm function to be enabled or disabled according to the operating condition. 0: Always active 1: Not active when in RESET mode 2: Not active when in RESET mode or manual operation	0	

List of Instrument Alarm Types

The table below shows the types and actions of instrument alarm. In the table, codes 1 to 20, 28 to 31 are for primary-loop, codes 41 to 60, 68 to 71 are for secondary-loop, codes 1 to 10, 41 to 51 are not provided with stand-by actions, while codes 11 to 20, 51 to 60 are provided with stand-by actions.

	Alarm action	Alarm ty	pe code		Alarm action	Alarm ty	pe code
Alarm type	"Open/close" shows status of relay contact, and "lit" and "unlit" shows status of lamp	Contact closes if alarm occurs	Contact opens if alarm occurs	Alarm type	"Open/close" shows status of relay contact, and "lit" and "unlit" shows status of lamp	Contact closes if alarm occurs	Contact opens if alarm occurs
No alarm		O	FF		Hysteresis	/	
PV high limit	Open (unlit) Closed (lit)	1 11 41 51		De-energized on deviation low limit alarm	Open (lit) Deviation PV Setpoint Target SP		6 16 46 56
PV low limit	Closed (lit) Open (unlit) Alarm setpoint PV	2 12 42 52		Deviation high and low limits	Hysteresis Hysteresis Closed Open (lit) Deviation setpoint Target SP Closed (lit) PV	7 17 47 57	
Deviation high limit	Open (unlit) PV Deviation setpoint Target SP	3 13 43 53		Deviation within high and low limits	Hysteresis Closed Hysteresis Open (unlit) Open (unlit) Deviation setpoint PV Target SP	8 18 48 58	
Deviation low limit	Hysteresis Closed (lit) Deviation setpoint Target SP	4 14 44 54		De-energized on PV high limit	Closed (unlit) Open (lit) PV Alarm setpoint		9 19 49 59
De-energized on deviation high limit alarm	Closed (unlit) PV		5 15 45 55	De-energized on PV low limit	Open (lit) Closed (unlit) Alarm setpoint PV		10 20 50 60
SP high limit	Hysteresis Closed (lit) Open (unlit) SP Alarm setpoint	28 68		Output high limit	Open (unlit) Output value Hysteresis Closed (lit) Alarm setpoint	30 70	
SP low limit	Hysteresis Closed (lit) Open (unlit) Alarm setpoint SP	29 69		Output low limit	Hysteresis Closed (lit) Open (unlit) Alarm setpoint Output value	31 71	

The following alarm types are used only for "Instrument Alarm."


25, 65: Sensor grounding alarm

26, 66: Fault diagnosis output (Note 1)

27, 67: FAIL output (Note 2)

Note 1: The fault diagnosis output turns on in case of input burnout, A/D converter failure, or reference junction compensation (RJC) failure. For input burnout or A/D converter failure, the control output is set to the setpoint of the Preset Output Value operating parameter (PO).

Note 2: The FAIL output is on during normal operation and turns off in case of failure.



Control Action-related Parameters

Located in: Main menu = PARA; Submenu = CTL

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
OPR1	Primary output velocity limiter	OFF (0) 0.1 to 100.0%/sec. Can limit control output velocity	OFF (0)	
OPR2	Secondary output velocity limiter	OFF (0) 0.1 to 100.0%/sec. Can limit control output velocity	OFF (0)	
MOD1	Primary PID control mode	O: Standard PID control (with output bump at SP change) 1: Fixed Point control (without output bump at SP change) Choose "Fixed Point Control" when controlling pressure or flow rate.	0	
MOD2	Secondary PID control mode	O: Standard PID control (with output bump at SP change) 1: Fixed Point control (without output bump at SP change) Choose "Fixed Point Control" when controlling pressure or flow rate.	0	
AR1	Primary anti-reset windup (Excess integration prevention)	AUTO (0), 50.0 to 200.0% The larger Setting, the sooner PID computation (integral computation) stops. Used when the control output travels up to 100% or down to 0% and stays at this point.	AUTO (0)	
AR2	Secondary anti-reset windup (Excess integration prevention)	AUTO (0), 50.0 to 200.0% The larger Setting, the sooner PID computation (integral computation) stops. Used when the control output travels up to 100% or down to 0% and stays at this point.	AUTO (0)	
ZON	Zone PID selection	O: Segment PID 1: Zone PID If set to "Segment PID," allows PID constants to be selected for each segment. If set to "Zone PID," automatically selects PID constants according to the temperature range set in the given Reference Point parameter.	1	
R.MD	Restart mode	CONT (0): Continues action set before power failure. MAN (1): Starts from manual operation status RESET (2): Continues action set before power failure and starts computation from the preset output value.	CONT (0)	
R.TM	Restart timer	0 to 10 sec. Sets time between power on and the instant where controller starts computation.	0 sec.	
GRP	PID group number	Allows you to determine how many groups of setpoint, alarm and PID parameters the controller should show. 1: Show one set. 2: Show two sets. 3: Show three sets. 4: Show four sets. 5 to 8: Show as many groups of parameters as have been set.	8	
1.RP1	Primary zone PID reference point-1	0.0 to 100.0% of primary PV input range. Note that 1.RP1 ≤ 2.RP1 ≤ 3.RP1 ≤ 4.RP1 ≤ 5.RP1 ≤ 6.RP1. Sets reference points at which switching is carried out between groups of PID constants according to the given temperature zone. You can set	100.0% of primary PV input range	
2.RP1	Primary zone PID reference point-2	a maximum of six reference points and therefore a maximum of seven temperature zones.		
3.RP1	Primary zone PID reference point-3	The example below sets reference points 1 and 2 to provide 3 zones to switch PID constants automatically.		
4.RP1	Primary zone PID reference point-4	Maximum value of primary PV input range RH1 Setpoint Setpoint 2 Zone 3 The controller is operated with the 3rd group of PID constants.		
5.RP1	Primary zone PID reference point-5	2.RP1 Reference point 1 1.RP1 PV input Zone 2 The controller is operated with the 2nd group of PID constants.		
6.RP1	Primary zone PID reference point-6	Minimum value of primary PV input range RL1 The controller is operated with the 1st group of PID constants.		

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
RHY1	Primary zone switching hysteresis	0.0 to10.0% of primary PV input range span Allows hysteresis to be set for switching at a reference point.	0.5% of primary PV input range span	
RDV1	Primary reference deviation	Used to select a group of PID parameters according to a deviation from the given program setpoint. The controller uses the PID parameters of the number selected in PID group number (GRP) if the PV input falls outside the given deviation range. The following example shows a case when only the reference deviation is set without setting any reference point. The selected group of PID parameters is as follows. Since region 1 is within the deviation range, the controller uses the 1st group of PID parameters. Since region 2 is outside the deviation range, the controller uses the PID parameters of the number selected in PID group number (GRP). Maximum value of primary PV input range Reference deviation (RDV1) Maximum value of primary PV input range Reference deviation (RDV1) Minimum value of primary PV input range Reference deviation (RDV1) Target setpoint Target setpoint OFF (0): Disable 0.0% to 100.0% of primary PV input range span	OFF (0)	
1.RP2	Secondary zone PID reference point-1	0.0 to 100.0% of secondary PV input range. Note that 1.RP2 ≤ 2.RP2 ≤ 3.RP2 ≤ 4.RP2 ≤ 5.RP2 ≤ 6.RP2. Sets reference points at which switching is carried out between groups of PID constants according to the given temperature zone. You can set	100.0% of secondary PV input range	
2.RP2	Secondary zone PID reference point-2	a maximum of six reference points and therefore a maximum of seven temperature zones.		
3.RP2	Secondary zone PID reference point-3	The example below sets reference points 1 and 2 to provide 3 zones to switch PID constants automatically.		
4.RP2	Secondary zone PID reference point-4	Maximum value of secondary PV input scale SH3 Setpoint Reference point 2 Setpoint Setpoint		
5.RP2	Secondary zone PID reference point-5	2.RP2 Reference point 1 1.RP2 PV input 700.1		
6.RP2	Secondary zone PID reference point-6	Minimum value of secondary PV input scale SL3 Value The controller is operated with the 1st group of PID constants.		
RHY2	Secondary zone switching hysteresis	0.0 to10.0% of secondary PV input range span Allows hysteresis to be set for switching at a reference point.	0.5% of secondary PV input range span	
RDV2	Secondary reference deviation	Used to select a group of PID parameters according to a deviation from the given program setpoint. The controller uses the PID parameters of the number selected in PID group number (GRP) if the PV input falls outside the given deviation range. The following example shows a case when only the reference deviation is set without setting any reference point. The selected group of PID parameters is as follows. Since region 1 is within the deviation range, the controller uses the 1st group of PID parameters. Since region 2 is outside the deviation range, the controller uses the PID parameters of the number selected in PID group number (GRP). Maximum value of secondary PV input scale SH3 A slope is set to vary the program setpoint secondary PV input scale SL3 OFF (0): Disable 0.0% to 100.0% of secondary PV input range span	OFF (0)	

Analog Input Computation Parameters

Located in: Main menu = CMLP; Submenu = AIN

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
A.BS1	Analog input-1 bias (primary PV input)	Used to correct the primary PV input value beforehand. When in normal operation, use the PV Input Bias (BS) operating parameter. -100.0% to 100.0% of primary PV input range span	0.0% of primary PV input range span	
A.FL1	Analog input-1 filter (primary PV input)	OFF (0): Disable 1 to 120 sec.	OFF (0)	
A.SR1	Analog input-1 square-root computation (primary PV input)	Performs square-root computation for the primary PV input value. OFF (0): Do not compute the square root ON (1): Compute the square root	OFF (0)	
A.LC1	Analog input-1 low signal cutoff (primary PV input)	0.0% to 5.0% The slope equals "1" at levels below the low-signal cutoff point.	1.0%	
A.BS3	Analog input-3 bias (secondary PV input)	Used to correct the secondary PV input value beforehand100.0% to 100.0% of secondary PV input scale span	0.0% of secondary PV input scale span	
A.FL3	Analog input-3 filter (secondary PV input)	OFF (0): Disable 1 to 120 sec.	OFF (0)	
A.SR3	Analog input-3 square-root computation (secondary PV input)	Performs square-root computation for the secondary PV input value. OFF (0): Do not compute the square root ON (1): Compute the square root	OFF (0)	
A.LC3	Analog input-3 low signal cutoff (secondary PV input)	0.0% to 5.0% The slope equals "1" at levels below the low-signal cutoff point.	1.0%	

• Retransmission Output Parameters

Located in: Main menu = CMLP; Submenu = RET

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
RET1	Retransmission output-1 type	OFF (0): Disable 1: PV1, 2: SP1, 3: OUT1, 4: LPS loop power supply (15 V), 5: PV2, 6: SP2, 7: OUT2 Retransmission output 1 is always provided via terminals 14 and 15. In position proportional control, a valve opening signal (0% to 100%) is transmitted if setpoint "7" is selected. In heating/cooling control, an output value before allocation to heating/cooling control is transmitted if setpoint "7" is selected. (0% to 50%: Cooling-side output; 50% to 100%: Heating-side output)	1	
RTH1	Maximum value of retransmission output-1 scale	RET1=1, 2: RTL1 + 1 digit to 100.0% of PV input range	100.0% of PV input range	
RTL1	Minimum value of retransmission output-1 scale	RET1=1, 2: 0.0% of PV input range to RTH1 - 1 digit	0.0% of PV input range	
RET2	Retransmission output-2 type	Retransmission output-2 is available when the type of control output is not "current" or "voltage pulse." The output is provided via terminals 16 and 17. OFF (0): Disable 1: PV1, 2: SP1, 3: OUT1, 4: LPS loop power supply (15 V), 5: PV2, 6: SP2, 7: OUT2 In position proportional control, a valve opening signal (0% to 100%) is transmitted if setpoint "7" is selected. In heating/cooling control, an output value before allocation to heating/cooling control is transmitted if setpoint "7" is selected. (0% to 50%: Cooling-side output; 50% to 100%: Heating-side output)	OFF (0)	
RTH2	Maximum value of retransmission output-2 scale	RET2=1, 2: RTL2 + 1 digit to 100.0% of PV input range		
RTL2	Minimum value of retransmission output-2 scale	RET2=1, 2: 0.0% of PV input range to RTH2 - 1 digit		

Deviation Trend Parameters

Located in: Main menu = CMLP; Submenu = TRND

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
TSC1	Primary deviation trend scale	Allows the deviation axis of the Deviation Trend operating display to be rescaled. 0.1 to 100.0% of primary PV input range span	0.5% of primary PV input range span	
TSC2	Secondary deviation trend scale	Allows the deviation axis of the Deviation Trend operating display to be rescaled. 0.1 to 100.0% of secondary PV input range span	0.5% of secondary PV input range span	
TTM	Deviation trend time	Allows the time axis of the Deviation Trend operating display to be rescaled. 1 to 600 sec.	5 sec.	

Security-related Parameters

Located in: Main menu = CMLP; Submenu = LOCK

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
▼/▲	Locking of front panel up/down keys (▲and▼)	OFF (0): Unlock ON (1): Lock	OFF (0)	
PT.No	Locking of front panel PT.No key	OFF (0): Unlock ON (1): Lock	OFF (0)	
RUN	Locking of front panel RUN key	OFF (0): Unlock ON (1): Lock	OFF (0)	
MODE	Locking of front panel MODE key	OFF (0): Unlock ON (1): Lock	OFF (0)	
PROG	Locking of operating parameter main menu PROG display	OFF (0): Unlock ON (1): Lock	OFF (0)	
LP1	Operating parameter main menu [LP1] lock	OFF (0): Unlock ON (1): Lock	OFF (0)	
LP2	Operating parameter main menu [LP2] lock	OFF (0): Unlock ON (1): Lock	OFF (0)	
PID	Operating parameter submenu [PID] lock	OFF (0): Unlock ON (1): Lock	OFF (0)	
USR	Although not used in cas	scade control, it is shown on the display.		
PYS1	Operating parameter main menu [PYS1] lock	OFF (0): Unlock ON (1): Lock	OFF (0)	
PYS2	Operating parameter main menu [PYS2] lock	OFF (0): Unlock ON (1): Lock	OFF (0)	
PWD	Password setting	Password not set to 30000 Note: If a password is set, the setup parameters cannot be displayed without entering the correct password.	0	

SELECT Display Parameters

Located in: Main menu = CONF; Submenu = CSEL

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
C.S1	SELECT display-1 registration	OFF (0), 101 to 1023 Select the desired parameter from among the operating	OFF (0)	
C.S2	SELECT display-2 registration	and setup parameters, then register the number (D register No.) accompanying that parameter. For example, registering "231" for C.S1 allows you		
C.S3	SELECT display-3 registration	to change instrument alarm-1 setpoint in operating display. Numbers for registering instrument alarm SP parameter for operating display: Instrument alarm-1 setpoint: 231 Instrument alarm-2 setpoint: 232 Instrument alarm-3 setpoint: 233 Instrument alarm-4 setpoint: 234	e instrument alarm-1 setpoint in operating display. s for registering instrument alarm SP parameter sting display: ment alarm-1 setpoint: 231	
C.S4	SELECT display-4 registration			
C.S5	SELECT display-5 registration			

Contact Output Registration Parameters

Located in: Main menu = CONF; Submenu = DO

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
DO1	Relay output flag registration for DO1	The following setpoints are registration numbers for cascade control only.	5705	
DO2	Relay output flag registration for DO2	5705: PV event 1 output 0: No function 5706: PV event 2 output	5706	
DO3	Relay output flag registration for DO3	5689: Instrument alarm 1 output 5129: Time event 1 output	5689	
DO4	Open-collector transistor output flag registration for DO4	5130: Time event 2 output 5131: Time event 3 output 5133: Time event 4 output	5129	
DO5	Open-collector transistor output flag registration for DO5	See "External contact output" in "1.5 Terminal Wiring Diagrams."	5130	
DO6	Open-collector transistor output flag registration for DO6		5131	
DO7	Open-collector transistor output flag registration for DO7		5133	

Contact Input Registration Parameters

Located in: Main menu = CONF; Submenu = DI

Locateu	in: Main menu = CO	iti , Subinenu = Di		
Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
PROG	Start of program operation (When "DIn" changes from OFF to ON)	These parameters determine which contact input to use to make selections/switches listed on the left. DI1: 5161 No function: 0	5165	
RST	Stop of program operation (When "DIn" changes from OFF to ON)	DI2: 5162 DI3: 5163 DI4: 5164	5166	
LOC	Start of local-mode operation (When "DIn" changes from OFF to ON)	DI5: 5165 DI6: 5166 DI7: 5167	0	
HOLD	Start of hold-mode operation (When "DIn" changes from OFF to ON)	DI8: 5168 The contact inputs are factory-set as shown below. Contact inputs 1 to 4 (DI1 to DI4): Program pattern number	0	
ADV	Advance of segment (When "DIn" changes from OFF to ON)	selection (see below) Contact input 5 (DI5): Start of program operation Contact input 6 (DI6): Stop of program operation Contact input 7 (DI7): LSP/CAS switching	0	
A/M1	Loop-1 AUTO/MAN switching (AUTO when contact input is ON; MAN when contact input is OFF)	Contact input 8 (DI8): ON when using 16 or more of program patterns	0	
A/M2	Loop-2 AUTO/MAN switching	Program pattern number selection	0	
L/C	LOCAL/CASCADE switching	1 2 3 4 5 6 7 8 DI1 ON OFF ON OFF ON OFF ON OFF	5167	
PTN.0	Bit 0 of program pattern number	DI2 OFF ON ON OFF OFF ON ON OFF DI3 OFF OFF OFF ON ON ON ON OFF	5161	
PTN.1	Bit 1 of program pattern number	DI4 OFF OFF OFF OFF OFF OFF ON	5162	
PTN.2	Bit 2 of program pattern number	9 10 11 12 13 14 15 DI1 ON OFF ON OFF ON OFF ON	5163	
PTN.3	Bit 3 of program pattern number	DI2 OFF ON ON OFF OFF ON ON DI3 OFF OFF OFF ON ON ON ON	5164	
PTN.4	Bit 4 of program pattern number	DI4 ON ON ON ON ON ON	5168	
MG1	Interruptive message display 1	See "External contact input" in "1.5 Terminal Wiring Diagrams."	0	
MG2	Interruptive message display 2		0	
MG3	Interruptive message display 3		0	
MG4	Interruptive message display 4		0	

● UP Mode Parameters

Located in: Main menu = UPMD; Submenu = MD

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
UPM	Controller mode (UP mode)	4: Cascade control For another Controller mode, see User's Manual (Reference) (CD-ROM version).	1	
SMP	PV sampling period setting	100, 200 and 500 ms The controller restarts if any change is made to the PV sampling period; this does not affect other parameter settings at all, however.	200 ms	
SMEC	Sampling period error counter (reading only)	0 to 30000	Shows 0 at power-on.	

Input-related Parameters

$\label{eq:located_located} \textbf{Located in: Main menu} = \boldsymbol{UPMD} \; ; \; \textbf{Submenu} = \boldsymbol{IN}$

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
IN1	Primary PV input type (INPUT 1 terminals) Terminals ①, ② and ③	Specify the type of primary PV input as a range code. See "Instrument Input Range Codes" in "2. Initial Settings."	OFF (0)	
UNI1	Primary PV input unit	Select the unit of primary PV input. % (0): Percent - (2): No unit °C (1): Degree Celsius °F (5): Fahrenheit	Depends on the primary PV input type.	
RH1	Max. value of primary PV input range	Set the PV input range (RL1 < RH1). - For temperature input -	Depends on the primary PV input type.	
RL1	Min. value of primary PV input range	Set the range of temperature that is actually controlled For voltage input - Set the range of a voltage signal that is applied. The scale across which the voltage signal is actually controlled should be set using the parameters Maximum Value of primary PV Input Scale (SH1) and Minimum Value of primary PV Input Scale (SL1).		
SDP1	Primary PV input decimal point position (shown when in voltage-input mode)	Set the position of the decimal point of voltage-mode primary PV input. 0 to 4 0: No decimal place 1: One decimal place, 2 to 4: Two, three, four decimal places	Depends on the primary PV input type.	
SH1	Max. value of primary PV input scale (shown when in voltage-input mode)	Set the read-out scale of voltage-mode primary PV input19999 to 30000, where SL1 < SH1, SH1 - SL1 <= 30000	Depends on the primary PV input type.	
SL1	Min. value of primary PV input scale (shown when in voltage-input mode)			
BSL1	Selection of primary PV input burnout action	Allows the primary PV input value to be determined as shown below in case of primary PV input burnout. • 105% of PV input range if set to "Upscale" • -5.0% of PV input range if set to "Downscale" OFF (0): Disable UP (1): Upscale DOWN (2): Downscale	Depends on the primary PV input type.	
RJC1	Presence/absence of primary PV input reference junction compensation	Allows input compensation to be applied to thermocouple input. OFF (0): Absent ON (1): Present	ON (1)	

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
IN3	Secondary PV input type (INPUT 3 terminals) Terminals ②and ②	Specify the type of secondary PV input as a range code. See "Instrument Input Range Codes" in "2. Initial Settings."	1 to 5 V (41)	
UNI3	Secondary PV input unit	Select the unit of secondary PV input. % (0): Percent - (2): No unit °C (1): Degree Celsius °F (5): Fahrenheit	% (0)	
RH3	Max. value of secondary PV input range	Set the PV input range (RL3 < RH3). - For voltage input -	5.000	
RL3	Min. value of secondary PV input range	Set the range of a voltage signal that is applied. The scale across which the voltage signal is actually controlled should be set using the parameters Maximum Value of secondary PV Input Scale (SH3) and Minimum Value of secondary PV Input Scale (SL3).	0.000	
SDP3	Secondary PV input decimal point position	Set the position of the decimal point of voltage-mode primary PV input. 0 to 4 0: No decimal place 1: One decimal place, 2 to 4: Two, three, four decimal places	Same as the primary PV input decimal point position	
SH3	Max. value of secondary PV input scale	Set the read-out scale of voltage-mode secondary PV input19999 to 30000, where SL1 < SH1, SH1 - SL1 <= 30000	Same as the max. value of primary PV input scale	
SL3	Min. value of secondary PV input scale		Same as the min. value of primary PV input scale	
BSL3	Selection of secondary PV input burnout action	Allows the secondary PV input value to be determined as shown below in case of secondary PV input burnout. • 105% of PV input range if set to "Upscale" • -5.0% of PV input range if set to "Downscale" OFF (0): Disable UP (1): Upscale DOWN (2): Downscale	OFF (0)	
P.UN1	PV unit (primary)	Set the unit of PV. % (0): Percent - (2): No unit °C (1): Degree Celsius °F (5): Fahrenheit	Same as the unit of primary PV input	
P.DP1	PV decimal point position (primary)	Under normal operation, set the same value as in the PV Input Decimal Point Position (SDP1) parameter. To shift the decimal point for temperature input, use this parameter. For example, set as "P.DP1 = 0" to change a temperature reading of one decimal place to that of no decimal places. This involves reconfiguring the P.RH1 and P.RL1 parameters. 0 to 4	-	
P.RH1	Maximum value of PV range (primary)	Under normal operation, keep the values of these parameters between the maximum and minimum values of the PV input range19999 to 30000	Maximum value of primary PV input range or scale	
P.RL1	Minimum value of PV range (primary)	P.RL1 < P.RH1, where P.RH1-P.RL1 ≤ 30000	Minimum value of primary PV input range or scale	
P.UN2	PV unit (secondary)	Set the unit of PV. % (0): Percent - (2): No unit °C (1): Degree Celsius °F (5): Fahrenheit	Same as the unit of secondary PV input	
P.DP2	PV decimal point position (secondary)	Under normal operation, set the same value as in the PV Input Decimal Point Position (SDP3) parameter. To shift the decimal point for temperature input, use this parameter. For example, set as "P.DP2 = 0" to change a temperature reading of one decimal place to that of no decimal places. This involves reconfiguring the P.RH2 and P.RL2 parameters. 0 to 4	-	
P.RH2	Maximum value of PV range (secondary)	Under normal operation, keep the values of these parameters between the maximum and minimum values of the PV input range. -19999 to 30000	Maximum value of secondary PV input range or scale	
P.RL2	Minimum value of PV range (secondary)	P.RL2 < P.RH2, where P.RH2-P.RL2 ≤ 30000	Minimum value of secondary PV input range or scale	

Output-related Parameters

$\textbf{Located in: Main menu} = \boldsymbol{UPMD} \; ; \; \textbf{Submenu} = \boldsymbol{OUT}$

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
OT2	Control output type	Time proportional PID relay contact output (terminals ① - ② - ③) Time proportional PID voltage pulse output (terminals ⑥ - ⑦) Current output (terminals ⑥ - ⑦) ON/OFF control relay contact output (terminals ① - ② - ③) The following 4 to 12 are displayed only for heating/ cooling type controllers. Heating-side relay output (terminals ① - ② - ③), cooling-side relay output (terminals ⑧ - ④ - ⑥) Heating-side pulse output (terminals ⑥ - ⑦), cooling-side relay output (terminals ⑧ - ④ - ⑥) Heating-side current output (terminals ⑥ - ⑦), cooling-side relay output (terminals ⑧ - ④ - ⑥) Heating-side relay output (terminals ⑥ - ⑦), cooling-side relay output (terminals ⑥ - ⑥) Heating-side pulse output (terminals ⑥ - ⑦), cooling-side pulse output (terminals ⑥ - ⑥) Heating-side current output (terminals ⑥ - ⑦), cooling-side pulse output (terminals ⑥ - ⑥) Heating-side relay output (terminals ⑥ - ⑦), cooling-side current output (terminals ⑥ - ⑦), cooling-side current output (terminals ⑥ - ⑦) Heating-side relay output (terminals ⑥ - ⑦), cooling-side current output (terminals ⑥ - ⑦)	O Heating/cooling type: 4	
CT1	Control output cycle time Heating-side control output cycle time (in heating/cooling control)	1 to 1000 sec. On Off Cycle time Relay's Behavior when Cycle Time = 10 sec. For 20% of Control Output For 50% of Control Output For 80% of Control Output 10 sec. On-state duration: 2 sec. Off-state duration: 5 sec. Off-state duration: 8 sec. Off-state duration: 2 sec. Off-state duration: 2 sec.	30 sec.	
CTc1	Cooling-side control output cycle time	1 to 1000 sec.	30 sec.	
AO1	Analog output-1 type (OUTPUT 1: Terminals ® and ⑦)	Allows control output or retransmission output to be presented as one of the following current signals. 0: 4 to 20 mA	0	
AO2	Analog output-2 type (OUTPUT 2: Terminals (a) and (a))	1: 0 to 20 mA 2: 20 to 4 mA 3: 20 to 0 mA	0	
AO3	Analog output-3 type (OUTPUT 3: Terminals (4) and (5)		0	
A1H	Analog output-1 100% segmental point	Set the values of segmental points for the 0% and 100% output levels at which the values are presented via OUTPUT-1	100.0%	
A1L	Analog output-1 0% segmental point	(terminals ⑥ and ⑦). See "■ Performing Split Computations" below5.0% to 105.0%	0.0%	
A2H	Analog output-2 100% segmental point	Set the values of segmental points for the 0% and 100% output levels at which the values are presented via OUTPUT-2 (terminals ⑥ and ⑦). See ■ Performing Split Computations" below.	100.0%	
A2L	Analog output-2 0% segmental point	-5.0% to 105.0%	0.0%	
АЗН	Analog output-3 100% segmental point	Set the values of segmental points for the 0% and 100% output levels at which the values are presented via OUTPUT-3	100.0%	
A3L	Analog output-3 0% segmental point	(terminals (4) and (5)). See "■ Performing Split Computations" below5.0% to 105.0%	0.0%	

■ Performing Split Computations

[V-mode Output]


The following explains an example of letting "Analog OUTPUT-1 (terminals (6) and (7))" and "Analog OUTPUT-3 (terminals (4) and (5))" present the V-mode characteristics of split computations.

- [1] Set the Control Output Type (OT2) parameter to "2". This sets the control output to "current output."
- [2] Set the Retransmission Output 1 (RET1) parameter to "7".

 This sets the retransmission output to "control output retransmission."
- [3] Set the Analog Output-1 100% Segmental Point (A1H) parameter to "100%".
- [4] Set the Analog Output-1 0% Segmental Point (A1L) parameter to "25%".
- [5] Set the Analog Output-3 100% Segmental Point (A3H) parameter to "0%".
- [6] Set the Analog Output-3 0% Segmental Point (A3L) parameter to "75%".

The figure below shows an example where both analog outputs-1 and 3 are set to the current signal of 4 to 20 mA DC. The type of output signal can be determined separately for each of the analog outputs listed above, using the following three parameters.

Analog output-1: Analog output-1 type (AO1)
Analog output-2: Analog output-2 type (AO2)
Analog output-3: Analog output-3 type (AO3)



[Parallel-mode Output]


The following explains an example of letting "Analog OUTPUT-1 (terminals (6) and (7))" and "Analog OUTPUT-3 (terminals (4) and (5))" present the parallel-mode characteristics of split computations.

- [1] Set the Control Output Type (OT2) parameter to "2". This sets the control output to "current output."
- [2] Set the Retransmission Output 1 (RET1) parameter to "7".

 This sets the retransmission output to "control output retransmission."
- [3] Set the Analog Output-1 100% Segmental Point (A1H) parameter to "100%".
- [4] Set the Analog Output-1 0% Segmental Point (A1L) parameter to "25%".
- [5] Set the Analog Output-3 100% Segmental Point (A3H) parameter to "75%".
- [6] Set the Analog Output-3 0% Segmental Point (A3L) parameter to "0%".

The figure below shows an example where both analog outputs-1 and 3 are set to the current signal of 20 to 0 mA DC. The type of output signal can be determined separately for each of the analog outputs listed above, using the following three parameters.

Analog output-1: Analog output-1 type (AO1)
Analog output-2: Analog output-2 type (AO2)
Analog output-3: Analog output-3 type (AO3)



Communication Parameters

Located in: Main menu = UPMD; Submenu = R485

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
PSL1	Protocol selection	0: PC link communication 1: PC link communication (with sum check) 2: Ladder communication 3: Coordinated master station 7: MODBUS (ASCII) 8: MODBUS (RTU)	0	
BPS1	Baud rate	600 (0), 1200 (1), 2400 (2), 4800 (3), 9600 (4) (bps)	9600 (4)	
PRI1	Parity	NONE (0): None EVEN (1): Even ODD (2): Odd	EVEN (1)	
STP1	Stop bit	1, 2	1	
DLN1	Data length	7, 8; 7 is fixed for MODBUS (ASCII) 8 is fixed for MODBUS (RTU), Ladder	8	
ADR1	Address	1 to 99 However, the maximum number of stations connectable is 31.	1	
RP.T1	Minimum response time	0 to 10 (× 10 ms)	0	

Motor-driven Valve Calibration-related Parameters (Displayed for Position Proportional Controllers)

Located in: Main menu = **UPMD**; Submenu = **VALV**

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
V.AT	Automatic valve adjustment	Automatically adjusts the fully-closed and fully-opened positions of a valve. When this function is used, there is no need for adjustment using the parameters V.RS, V.L and V.H. OFF (0): - ON (1): Start automatic adjustment	OFF (0)	
V.RS	Valve position setting reset	The parameters V.RS, V.L and V.H are designed for manual adjustment of valve positions. Setting V.RS to 1 resets the valve adjustment settings and causes the indication "V.RS" to blink.	0	
V.L	Fully-closed valve position setting	Pressing the SET/ENT key with valve position set to the fully-closed position causes the adjusted value to be stored.	Undefined	
V.H	Fully-opened valve position setting	Pressing the SET/ENT key with valve position set to the fully-opened position causes the adjusted value to be stored. When V.H. adjustment is complete, V.H. stops blinking.	Undefined	
TR.T	Valve traveling time	5 to 300 sec. Used to operate a valve according to the estimated valve position. Set the time required for the valve to open fully from a state of being fully closed. Confirm the valve traveling time by consulting the datasheet of the valve's specifications. The valve traveling time is only effective when Valve Adjustment Mode (V.MD) is set to 1 or 2.	60 sec.	
V.MOD	Valve adjusting mode	O: Valve position feedback type 1: Valve position feedback type (moves to the estimating type if a feedback input error or burnout occurs.) 2: Valve position estimating type	0	

Parameter-initializing Parameters

Located in: Main menu = UPMD; Submenu = INIT


Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting
INI	Parameter initialization	OFF (0): - ON (1): Initialize parameters	OFF (0)	

■ Tips about Heating/Cooling Control (for heating/cooling controllers only)


In heating/cooling control, the controller outputs the result of computation after splitting it into heating-purpose and cooling-purpose signals. In addition, the controller can perform PID control or ON/OFF control on the heating and cooling sides separately. When performing ON/OFF control, set the proportional band to "0".

The controller splits the result of computation (0 to 100%) into heating-side and cooling-side signals, as described below.


- 0% to 50% of the computation result is presented as a 0% to 100% cooling-side output.
- 50% to 100% of the computation result is presented as a 0% to 100% heating-side output.



Heating/cooling control provides two methods in which either none of the heating- and cooling-side outputs are presented or both of the heating- and cooling-side outputs are presented, as shown in the following figures.



Value of control output before split into heating- and cooling-side outputs



Value of control output before split into heating- and cooling-side outputs

Precautions in Heating/Cooling Control

Keep the ratio of the heating-side proportional band (P) to the cooling-side proportional band (Pc) equal to or below 5.

If neither the heating-side nor the cooling-side is performing ON/OFF control, setting
the integral time (I or Ic) of one side to "0" results in the Integral Time parameters of
both sides being set to "OFF", irrespective of the integral time setting of the other side.

■ Tips about Position Proportional Control (for position proportional controllers only)


Position proportional control can be of either feedback type or estimating type.

In feedback-type position proportional control, the controller obtains a valve position signal from a feedback slide-wire resistor attached to a valve.

In estimating-type position proportional control, you set the operating time required for a valve to change from the fully-closed position to the fully-open position beforehand. With the preset operating time, the controller controls the valve by estimating its position. In the case of estimating-type position proportional control, there is no need for feedback input wiring.

Feedback-type position proportional control is superior to the estimating type in terms of control performance. When in manual operation, you can directly manipulate the controller's output terminals. Pressing the \triangle key sends the valve into opening motion while pressing the \bigcirc key sends it into closing motion.


The figure below shows a schematic representation of a loop configured for position proportional control.




7. Function Block Diagram and Descriptions

This chapter contains the function block diagrams for "Cascade control," "Heating/cooling cascade control," and "Position proportional cascade control." For details on these function block diagrams, refer to the descriptions mentioned later.


■ Function Block Diagram for Cascade Control



■ Function Block Diagram for Cascade Heating/Cooling Control



■ Function Block Diagram for Cascade Position Proportional Control



Functions and Parameters for "Cascade Control" in Initial State

Functions and parameters in initial state are given in the tables below. For details on each parameter, refer to "6.2 Lists of Parameters."

■ Primary-loop PV Input

PV input of the primary-loop (INPUT1) is a universal input, which can receive signals from thermocouple, RTD, or DC voltage signals. The controller is capable of biasing, square root extraction, first-order lag computation (filtering), ten-segment linearizer approximation, and ten-segment linearizer biasing on input signals.

Each function can be set by the following parameters.

Setup Parameters

Function	Parameter	Main menu	Submenu
Input selection	IN1	UPMD	IN
Unit selection	UNI1	UPMD	IN
Analog input range conversion	RH1, RL1 (SDP1, SH1, SL1)	UPMD	IN
Analog input bias	A.BS1	CMLP	AIN
Square root extraction	A.SR1, A.LC1	CMLP	AIN
Analog input filter	A.FL1	CMLP	AIN

Note: PV input bias (BS) and PV input filter (FL) among the operating parameters are used as bias and filter when normal operation. Analog input bias (A.BS1) and analog input filter (A.FL1) among the setup parameters are used when PV correction value is decided in advance.

Operating Parameters

Function	Function Parameter		Submenu
Ten-segment linearizer mode	1.PMD	PYS1	None
Ten-segment linearizer approximation/biasing	1.a1 to 1.a11, 1.b1 to 1.b11	PYS1	None

■ Secondary-loop PV Input

PV input of the secondary-loop (INPUT3) is a universal input, which can receive signals from DC voltage signals. The controller is capable of biasing, square root extraction, first-order lag computation (filtering), ten-segment linearizer approximation, and ten-segment linearizer biasing on input signals.

Each function can be set by the following parameters.

Setup Parameters

Function	Parameter	Main menu	Submenu
Input selection	IN3	UPMD	IN
Unit selection	UNI3	UPMD	IN
Analog input range conversion	RH3, RL3 (SDP3, SH3, SL3)	UPMD	IN
Analog input bias	A.BS3	CMLP	AIN
Square root extraction	A.SR3, A.LC3	CMLP	AIN
Analog input filter	A.FL3	CMLP	AIN

Note: PV input bias (BS) and PV input filter (FL) among the operating parameters are used as bias and filter when normal operation. Analog input bias (A.BS3) and analog input filter (A.FL3) among the setup parameters are used when PV correction value is decided in advance.

Operating Parameters

Function	Parameter	Main menu	Submenu
Ten-segment linearizer mode	2.PMD	PYS2	None
Ten-segment linearizer approximation/biasing	2.a1 to 2.a11, 2.b1 to 2.b11	PYS2	None

■ Selecting Program Pattern Using Contact Input

It is possible to select the program pattern by turning the four contact input signals ON or OFF. This function is assigned to DI1 (contact input 1) to DI4 (contact input 4). Note that the program pattern can be selected during RESET mode, can not during operation.

Contact				Pro	gram	patter	n num	ber to	be se	elected	l (PT.1	No)			
input	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
DI1	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON
DI2	OFF	ON	ON	OFF	OFF	ON	ON	OFF	OFF	ON	ON	OFF	OFF	ON	ON
DI3	OFF	OFF	OFF	ON	ON	ON	ON	OFF	OFF	OFF	OFF	ON	ON	ON	ON
DI4	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	ON	ON	ON	ON	ON	ON	ON

Note: If DI8 is set to ON, the program pattern of the number added 16 to the one selected by ON/OFF using DI1 to DI4, is selected.

For example, set contact input 2 (DI2) only to "ON" to change the program pattern 1 to the program pattern 2.

Set contact input 1 (DI1) and contact input 2 (DI2) to "ON" to select the program pattern 3.

■ Switching Operation Mode Using Contact Input

Program operation for the selected program pattern starts when DI5 (contact input 5) changes from OFF to ON.

Program operation stops when DI6 (contact input 6) changes from OFF to ON. Preset output value is outputted when the operation stops.

Cascade (OFF)/Local (ON) switching function is assigned to DI7 (contact input 7).

■ PID (Primary-loop)

It is possible to use a maximum of eight groups of PID parameters.

Operating Parameters

Function	Parameter	Main menu	Submenu
Proportional band (P)	n.P	LP1	n.PID
Integral time (I)	n.l	LP1	n.PID
Derivative time (D)	n.D	LP1	n.PID

■ PID (Secondary-loop)

It is possible to use a maximum of eight groups of PID parameters.

Operating Parameters

Function	Parameter	Main menu	Submenu
Proportional band (P)	n.P	LP2	n.PID
Integral time (I)	n.l	LP2	n.PID
Derivative time (D)	n.D	LP2	n.PID
Cooling-side proportional band (Pc)	n.Pc	LP2	n.PID
Cooling-side integral time (Ic)	n.lc	LP2	n.PID
Cooling-side derivative time (Dc)	n.Dc	LP2	n.PID

■ Control Output

Control output (OUTPUT1) selects the output type among the current output, voltage pulse output, and relay contact output signal.

Preset output value is output when the operation is stopped by key operation or contact input, which takes priority over the manual operation.

Each function can be set by the following parameters.

Setup Parameters

Function	Parameter	Main menu	Submenu
Control output type selection	OT2	UPMD	OUT
Control output cycle time	CT1	UPMD	OUT
Cooling-side control output cycle time	CTc1	UPMD	OUT
Analog output-1 type	AO1	UPMD	OUT
Analog output-2 type (cooling-side)	AO2	UPMD	OUT

Operating Parameters

Function	Parameter	Main menu	Submenu
Preset output	n.PO	LP1	n.PID
Cooling-side preset output	n.Oc	LP1	n.PID
Output limiter	n.OL, n.OH	LP1	n.PID

■ Contact Output

PV event 1 is outputted via DO1 (contact output 1).

PV event 2 is outputted via DO2 (contact output 2).

Instrument alarm 1 is outputted via DO3 (contact output 3).

Time event 1 is outputted via DO4 (contact output 4).

Time event 2 is outputted via DO5 (contact output 5).

Time event 3 is outputted via DO6 (contact output 6).

Time event 4 is outputted via DO7 (contact output 7).

■ Retransmission Output

PV, program setpoint, or control output can be output to retransmission output 1 (OUT-PUT3).

Retransmission output 2 (OUTPUT1) can be used when the control output is relay.

Each function can be set by the following parameters.

Setup Parameters

Function	Parameter	Main menu	Submenu
Retransmission output 1 type	RET1	CMLP	RET
Retransmission output 1 scale	RTH1, RTL1	CMLP	RET
Retransmission output 2 type	RET2	CMLP	RET
Retransmission output 2 scale	RTH2, RTL2	CMLP	RET

■ 15 V DC Loop Power Supply

The 15 V DC loop power supply (OUTPUT3) uses the same terminal of retransmission output 1 or 2. The 15 V DC loop power supply can not be used when retransmission output 1 or 2 is used. To use the 15 V DC loop power supply, set "4" in retransmission output type 1 (RET1) or 2 (RET2) selection parameter.

Each function can be set by the following parameters.

Setup Parameters

Function	Parameter	Main menu	Submenu
Retransmission output 1 type	RET1	CMLP	RET
Retransmission output 2 type	RET2	CMLP	RET

<Int> <Toc>

Revision Information

● Title : Model UP550 Program Controller User's Manual for Cascade Control

● Manual No. : IM 05E01C02-44E

May 2000/1st Edition

Newly published

Jul 2004/2nd Edition

Change of the company name

May 2006/3rd Edition

Revision by the change of safety standard description

Written by Yokogawa Electric Corporation

Published by Yokogawa Electric Corporation

2-9-32 Nakacho, Musashino-shi, Tokyo 180-8750, JAPAN

IM 05E01C02-44E 3rd Edition: May 31, 2006-00



Yokogawa Electric Corporation

YOKOGAWA ELECTRIC CORPORATION

Network Solutions Business Division 2-9-32, Nakacho, Musashino-shi, Tokyo, 180-8750 JAPAN Phone: +81-422-52-7179 Facsimile: +81-422-52-6793 Sales Branch Offices

Tokyo, Nagoya, Osaka, Hiroshima, Fukuoka

YOKOGAWA CORPORATION OF AMERICA

Headquaters

2 Dart Road, Newnan, GA. 30265-1094 U.S.A. Phone: +1-770-253-7000 Facsimile: +1-770-251-0928 Sales Branch Offices / Texas, Chicago, Detroit, San Jose

YOKOGAWA EUROPE B. V.

Headquaters

Databankweg 20, 3821 AL Amersfoort THE NETHERLANDS Phone: +31-334-64-1611 Facsimile: +31-334-64-1610

Sales Branch Offices / Houten (The Netherlands), Wien (Austria), Zaventem (Belgium), Ratingen (Germany), Madrid (Spain), Bratislava (Slovakia), Runcorn (United Kingdom), Milano (Italy), Velizy villacoublay(France), Johannesburg(Republic of South Africa)

YOKOGAWA AMERICA DO SUL S.A.

Headquarters & Plant

Praca Acapulco, 31-Santo Amaro, Sao Paulo/SP, BRAZIL CEP-04675-190

Phone: +55-11-5681-2400 Facsimile: +55-11-5681-4434

YOKOGAWA ENGINEERING ASIA PTE. LTD.

Head office

5 Bedok South Road, Singapore 469270 SINGAPORE Phone: +65-6241-9933 Facsimile: +65-6241-2606

YOKOGAWA ELECTRIC KOREA CO., LTD.

395-70, Shindaebang-dong, Dongjak-gu, Seoul,156-010, KOREA Phone: +82-2-3284-3000 Facsimile: +82-2-3284-3019

YOKOGAWA TAIWAN CORPORATION

Head office 17F, No.39, Sec. 1, Chung Hwa Road Taipei, 100 TAIWAN Phone: +886-2-2314-9166 Facsimile: +886-2-2314-9918

YOKOGAWA AUSTRALIA PTY. LTD.

Head office Centrecourt D1, 25-27 Paul Street North, North Ryde, N. S. W. 2113, AUSTRALIA Phone: +61-2-9805-0699 Facsimile: +61-2-9888-1844

YOKOGAWA INDIA LTD.

Head office

40/4 Lavelle Road, Bangalore, 560 001, INDIA Phone: +91-80-227-1513 Facsimile: +91-80-227-4270

LTD. YOKOGAWA ELECTRIC

Grokholskiy per. 13, Build. 2, 4th Floor, 129010, Moscow, RUSSIA FEDERATION

Phone: +7-095-737-7868 Facsimile: +7-095-737-7869