

User's Manual
AE5501 TrafficTesterMini
AS-84708Y

Yokogawa Electric Corporation

© 2004 Yokogawa Electric Corporation

AS-84708Y Rev, 2.1

[This page is intentionally left blank.]

Introduction

This manual describes the procedures for operating the AE5501 TrafficTesterMini.

This manual consists of five chapters:

Chapter 1 "Overview," Chapter 2 "Before Getting Started," Chapter 3 "Functions," Chapter 4 "Operation Instructions" and Chapter 5, which includes Appendixes such as "List of Error Messages," "List of Consumables," and the settings to configure for directly connecting this device to a PC.

September 2007: Rev 2.1

[This page is intentionally left blank.]

Notation Conventions

In this section, the meanings and usages of the following indications are defined.

1. DANGER, WARNING, CAUTION, NOTE and FOOTNOTE

(1) Level of Importance

According to the meanings defined in (2) below, the level of importance is DANGER > WARNING > CAUTION > NOTE > FOOTNOTE.

(2) Meaning

DANGER: This indicates a direct threat to human life. Ignoring this indication and performing an operation incorrectly could result in serious injury or death.

WARNING: This indicates a potential risk of a hazardous event. Ignoring this indication and performing an operation incorrectly could result in personal injury or property damage.

CAUTION: This indicates a potential risk to the device. It also advises the user that operation of the device could be interrupted.

NOTE: This indicates a supplementary explanation for exceptions, amendments and restrictions in this document and involves information that is outside the scope of DANGER, WARNING, CAUTION or FOOTNOTE.

FOOTNOTE: This indicates a supplementary explanation for technical terms, acronyms, abbreviations and marks in the body text. Footnotes are always located at the bottom of the related page. Footnotes can be referenced by an asterisk (*) or the combination of asterisk and numbers.

2. Reference Guide

Reference pages are indicated in the body text when applicable.

Linux is a registered trademark of Linus Torvals.

All other company names and product names are trademarks of the respective owners.




Company names and product names mentioned in this document are trademarks or registered trademarks of the respective companies.

Safety Notice

About the Symbols

In this instruction manual and on the product labeling, a number of symbols are used to ensure safe use of the product and proactively prevent any personal injury or property damage. The appearance and meanings of symbols are shown below.

Be sure that you fully understand the meanings of the symbols before reading this document.

| | | |
|---|----------------|---|
|  | DANGER | This symbol indicates that if you do not observe the safety instructions and subsequently operate the device incorrectly, there is a risk of creating a hazardous situation that may result in serious injury or death. |
|  | WARNING | This symbol indicates that if you do not observe the safety instructions and subsequently operate the device incorrectly, there is a risk of serious injury or death. |
|  | CAUTION | This symbol indicates that if you do not observe the safety instructions and subsequently operate the device incorrectly, there is a risk of personal injury or property damage or loss. |



This symbol indicates that improper operation of the device may result in injury or cause property loss or damage.



This indicates that the specific actions displayed by the symbols are prohibited and otherwise provides notification of general prohibitions.



This symbol indicates that improper operation/handling may result in a fire.



This symbol indicates that there is a risk of injuring yourself by pinching your fingers in the door, loading slot, etc.



This symbol indicates that under certain conditions the product may catch on fire from any flames that are present in the surrounding environment.



This symbol indicates that there is a risk of electric shock under certain conditions.



This symbol indicates instructions for the general user to follow.



This symbol indicates that an explosion may occur under certain conditions.



This is a prohibitive indication for a case in which there is a risk of electric shock or other risks if the user disassembles the device.



This instructs the user to unplug the power cord from the device in the case of equipment failure and/or when there is a risk of a lightning strike.



This is a prohibitive indication for a case in which injury may result if the user touches a certain part of the device under certain conditions.



This is a prohibitive indication for a case in which an electric leak may result in injury if a non-waterproofed device is used under wet conditions.



This symbol indicates that there is a risk of burn and other heat injuries under certain conditions.

Symbols concerned about the AC adapter for AE5501



AC; Alternating current



DC; Direct current



This symbol indicates polarities of electrodes of the AC adapter terminal.
Outer electrode polarity Positive, Inner electrode polarity Negative



This symbol indicates that the AC adapter is protected throughout by DOUBLE INSULATION or REINFORCED INSULATION.

Safety Concerns

For proper operation of this device, be sure that you fully understand the operation and safety instructions contained in this manual before using the product.

Carefully read this manual and the "Safety Concerns" before using this device.

Keep the documents in a location where you can readily refer to them when necessary.

1. Restrictions on Environment



Protect this device from water exposure and/or immersion.
Failure to do so may result in fire, electric shock or device failure.

2. Restrictions on Use Conditions



Do not use this device with any power supply voltages other than the designated voltage.
Doing so may result in fire, electric shock or device failure.



If you use this device with a commercial power source, connect it to an outlet for the exclusive use of the device.



Do not use an extension cable. Doing so may cause overheating of the cable and/or fire.

3. Installation

3.1 Advisory Notices for the Installer



Do not plug too many wires into a single socket.
Doing so may result in overheating of the cable and/or fire.



Securely insert the power plug into the outlet.
There is a risk of fire or electric shock if metal or other conducting material comes into contact with the power plug.

3.2 Restrictions and Prohibitions on the Installation Environment



Do not install this device in a moist and/or dusty area.
Doing so may result in electric shock or device failure.



Do not install this device on a shaky stand, slanted platform or any other unstable surface.
The device may fall off or slide down and result in injury and/or damage.



Do not install this device in an area where vibration or impact frequently occurs.
The device may fall off or slide down and result in injury and/or damage.



Do not insert or drop any metal or other foreign objects through any openings. Doing so may result in fire, electric shock or device failure.



Keep the power cord away from any heating devices. The coating on the cord may melt off and result in fire or electric shock.



Hold the power plug and pull it gently when you disconnect the power cord. Pulling the power cord itself may damage it and result in fire or electric shock.



Do not touch the power plug with wet hands. Doing so may result in electric shock.



Do not use this device with any power supply other than the one stipulated. Doing so may result in fire or electric shock.



Do not place this device in direct sunshine or in an area of high temperature. The interior temperature of the device will rise and may result in fire.

3.3 Prohibitions to the Installation Procedure



Be sure to disconnect the power plug and all external cables and wires before you move this device.

Failure to do so may result in a damaged cable or wire, which may cause a fire or electric shock.



Be careful not to damage, break or alter the power cord.

Placing a heavy load on the power cord, applying heat to it or pulling it forcefully may result in fire or electric shock.

4. Before Getting Started



Read the instruction manual carefully to ensure that you thoroughly understand the operation procedures and safety precautions for this device.

5. Operation Instructions



Use this device in accordance with the procedures described in the instruction manual.



If any one of the warning symbols (DANGER, WARNING, or CAUTION) is indicated, follow the instructions in this manual.



Do not cause any impact to this device when you move it.

Built-in precision instruments of this device may be damaged by impact.



Use a power supply of 100 V AC / 50–60 Hz.

There is a risk of fire or device failure if you use a power supply with specifications other than those stated above.



Use the 3-prong power cord attached to this device in order to prevent physical injury, damage to the interior of the device by abnormal voltage or problems caused by ground current.

Use a 3-prong/2-prong adapter if there is no 3-prong outlet installed in your environment.



Do not place any glass or vessel of water or any small metal body on top of or near by the device.

There is a risk of fire, electric shock or device failure if water spills out from the vessel and enters the device.



If there is lightning nearby, disconnect the power plug, measuring port and remote port of the device in order to avoid the risk of equipment failure caused by a lightning strike.



Do not alter, forcefully bend, twist or pull the power cord.

Doing so may result in fire or electric shock.



Do not disassemble or modify this device.

Doing so may result in fire, electric shock or device failure.



As a safety precaution, disconnect the power plug when the device will not be used for an extended period of time.



As a safety precaution, detach the battery from the device when it will not be used for an extended period of time.



Be careful not to pinch or injure your fingertips when replacing an optional module or other accessories.

6. Maintenance and Inspection



It is highly recommended that maintenance and inspection be conducted on a regular basis. Allowing dust to accumulate inside the device may result in fire or equipment failure. Please contact the sales representative indicated at the end of this manual.

7. Troubleshooting



Call your sales representative for the replacement of a damaged power cord.

There is a risk of fire or electric shock if you continue to use this device with a damaged power cord.



Turn off the power switch, unplug the power cord and call your sales representative if any foreign object enters this device.

There is a risk of fire, electric shock or failure if you continue to use this device with a foreign object left inside.



There is a risk of fire, electric shock or failure if you continue to use this device under abnormal conditions. If the device is emitting smoke or odor, immediately turn off the switch, unplug the power cord, make sure that smoke is no longer coming out of the device and then call your sales representative for repair. It is extremely dangerous to repair this device on your own and you should never attempt to do so.



Turn off the power switch and unplug the power cord if you drop and/or damage this device.

There is a risk of fire, electric shock or failure if you continue to use a damaged device.



Turn off the power switch first, then detach the battery and call your sales representative if any foreign object enters this device.

There is a risk of fire, electric shock or failure if you continue to use this device before it is repaired.



There is a risk of fire, electric shock or failure if you continue to use this device under abnormal conditions. If the device is emitting smoke or odor, turn off the switch immediately, detach the battery, make sure that smoke is no longer coming out of the device and then call your sales representative for repair. It is extremely dangerous to repair this device on your own and you should never attempt to do so.



Turn off the power switch and detach the battery if you drop and/or damage this device.

There is a risk of fire, electric shock or failure if you continue to use this device before it is repaired.



Never try to repair this device when it malfunctions.

Doing so may result in electric shock or injury. In addition, unauthorized attempts by the user to repair the device will invalidate our warranty.

Concerns about protection impairment

If this instrument is used in a manner not specified in this manual the protection provided by this instrument may be impaired.

It is recommended strongly to read sections designated as DANGER, WARNING, and CAUTION in this manual very carefully and to obey them.

[This page is intentionally left blank.]

Table of Contents

| | | |
|------------------|---------------------------------------|------------|
| Chapter 1 | Overview | 1-1 |
| 1.1 | Features | 1-1 |
| 1.2 | Specifications | 1-2 |
| 1.2.1 | Functional Specifications | 1-2 |
| 1.2.2 | Electrical Specifications | 1-4 |
| 1.3 | Configuration | 1-5 |
| 1.3.1 | Components of the Main Device | 1-5 |
| 1.3.2 | Lineup of Optional Accessories | 1-5 |
| 1.3.3 | Optional Accessories | 1-6 |
| Chapter 2 | Before Getting Started | 2-1 |
| 2.1 | Unpacking and Repacking | 2-1 |
| 2.1.1 | Unpacking | 2-1 |
| 2.1.2 | Checking the Package Contents | 2-1 |
| 2.1.3 | Mechanical Check | 2-1 |
| 2.1.4 | Operational Check | 2-1 |
| 2.1.5 | If Any Damage or Abnormality Is Found | 2-2 |
| 2.1.6 | Repacking | 2-2 |
| Chapter 3 | Functionality | 3-1 |
| 3.1 | Names and Functions of the Panels | 3-1 |
| 3.1.1 | Front Panel | 3-1 |
| 3.1.2 | Right Side Panel | 3-3 |
| 3.1.3 | Top Side Panel | 3-4 |
| 3.2 | Measuring Function | 3-5 |
| 3.2.1 | Traffic Generate Mode | 3-5 |
| 3.2.2 | Latency Check Mode | 3-7 |
| 3.2.3 | Loop Back Mode | 3-9 |
| 3.2.4 | Ping Test Mode | 3-11 |
| 3.2.5 | Reply Mode | 3-12 |
| 3.2.6 | DHCP/ARP function | 3-12 |
| 3.2.7 | MACRO function | 3-13 |
| 3.2.8 | Telnet remote control function | 3-14 |
| 3.2.9 | Remote Setup Function | 3-15 |
| 3.2.10 | Analytical Function | 3-15 |
| Chapter 4 | Operating Instructions | 4-1 |
| 4.1 | Preparation and Operation Check | 4-1 |
| 4.1.1 | Flow Chart of the Operating Procedure | 4-1 |
| 4.1.2 | Inserting Optional Modules | 4-2 |
| 4.1.3 | Preparing the Power Supply | 4-3 |
| 4.1.4 | Turning On the Power Supply | 4-5 |
| 4.1.5 | Connecting to an AE5730E-installed PC | 4-7 |
| 4.1.6 | Setting Up the Remote IP Address | 4-17 |
| 4.1.7 | Uploading the Setting | 4-17 |
| 4.1.8 | How to Use the Measuring Port | 4-18 |
| 4.1.9 | Measurement | 4-19 |
| 4.1.10 | Downloading Measurement Results | 4-19 |

| | | |
|------------------|--|--------------|
| 4.1.11 | Disconnecting the Power Supply | 4-20 |
| 4.2 | Details on Functions | 4-21 |
| 4.2.1 | Common Screen Elements | 4-21 |
| 4.2.2 | Schematic Diagram of Screens | 4-23 |
| 4.2.3 | Boot Screen | 4-26 |
| 4.2.4 | Mode Select Screen..... | 4-27 |
| 4.2.5 | Setup Select Screen | 4-29 |
| 4.2.6 | ONLINE Screen..... | 4-30 |
| 4.2.7 | Off Select Screen..... | 4-39 |
| 4.2.8 | File Select Screen | 4-40 |
| 4.2.9 | OFFLINE Screen..... | 4-42 |
| 4.2.10 | Setup Screen | 4-50 |
| 4.2.11 | Free Setup Screen..... | 4-63 |
| 4.2.12 | DHCP Screen | 4-72 |
| 4.2.13 | ARP Screen | 4-76 |
| 4.2.14 | MACRO Screen..... | 4-78 |
| 4.2.15 | LOG VIEW Screen..... | 4-90 |
| 4.2.16 | Remote Setup Screen..... | 4-93 |
| 4.2.17 | Self Test Screen..... | 4-100 |
| 4.2.18 | Time Set Screen | 4-102 |
| 4.2.19 | ALL DEFAULT Screen..... | 4-104 |
| 4.3 | TELNET remote control..... | 4-106 |
| 4.3.1 | TELNET Basic remote control procedure | 4-107 |
| 4.3.2 | TELNET commands | 4-117 |
| 4.3.3 | Script commands | 4-165 |
| 4.3.4 | Error messages | 4-171 |
| Chapter 5 | Appendix | 5-1 |
| 5.1 | List of Error Messages | 5-1 |
| 5.2 | Popup Messages | 5-2 |
| 5.3 | List of Consumables | 5-3 |
| 5.4 | The abbreviation of the TELNET command..... | 5-4 |
| 5.4.1 | The abbreviation list of the setup parameter of the SET command..... | 5-4 |
| 5.4.2 | The abbreviation list of the parameter of the result command | 5-8 |
| 5.5 | Connection Configuration for AE5730E-installed PC | 5-9 |
| 5.5.1 | Microsoft® Windows® XP | 5-10 |
| 5.6 | Other Cautionary Notes..... | 5-19 |
| 5.6.1 | Version Upgrading..... | 5-19 |
| 5.6.2 | Recovery Mode | 5-21 |
| 5.6.3 | Cleaning | 5-2123 |

Chapter 1 Overview

This chapter provides an outline of the specifications and configuration of the AE5501 TrafficTesterMini so that you may familiarize yourself with the product.

1.1 Features

This product is a portable low-cost tester that can be used for an Ethernet line connection test.

- 1 Lightweight and compact (H60 X W120 X D215 mm; Approx. 1 kg)
- 2 Can be operated by battery for about two hours (1.5 hours when measuring 1000BASE-T lines)
- 3 GBIC supported
- 4 Easy to operate
 - Primary settings can be made with PC setup software.
 - It is possible to remotely transfer the settings of this device.
 - Measurement results can be viewed using this device and a PC.
- 5 Settings and measurement results can be displayed on the 2.8" LCD.



WARNING

This is a tester capable of transmitting frames at a high intensity via its measuring port. Therefore, if the device is incorrectly operated, it may shut down and/or deteriorate network media and related equipment. Pay careful attention when connecting and using this device on a network that is in actual use. We are not responsible for any problems that may occur due to incorrect operation by the user.



1.2 Specifications

This section describes the functional and electrical specifications of the AE5501 TrafficTesterMini.

1.2.1 Functional Specifications

Table 1.2-1 shows the functional specifications of this device.

Table 1.2-1 Functional Specifications


| Item | Subitem | Description |
|-------------------------|----------------------------------|--|
| Transmitter function | Transmitting mode | Constant/Continue Burst/Continue |
| | | Constant/Count Burst/Count |
| | Transmitting packet Length | 26–9999 bytes |
| | Packet generation | Ethernet header edit (available for VLAN tags) MPLS label edit (available for label stack) IP header edit |
| Statistics function | Traffic statistics | Number of frames, bytes, frames per second, traffic rate |
| | Error statistics | Undersize errors, Oversize errors CRC errors, Alignment errors |
| | Others | Number of collisions, Number of PAUSE frames |
| Latency check | Delay time Idle time (jitter) | When 10 Mbps selected: Resolution = 1 μ s, Maximum tolerance = 3 μ s |
| | | When 100/1000 Mbps selected: Resolution = 100 ns, Maximum tolerance = 300 ns |
| Ping test | IP address, Packet | Manual setting, Packet length setting (64 to 1,518 bytes) |
| | Judgment results | Response time indication (in μ s) |
| Loop back Function | Loop back | This replaces the destination of a received frame with the MAC address of the sender and loops it back to the sender. The replacement may be selected as "MAC Address only" or "MAC Address+IP Address". |
| Measurement information | | Capable of registering 10 + 1 files at maximum. |
| Measurement results | | Capable of registering 100 files at maximum. Once the maximum number is exceeded, the oldest results will be automatically deleted. |
| Others | Auto-negotiation | AUTO or MANUAL (10/100 M). Fixed at full duplex for 1000 M. |
| | Flow control | Transmission will be suspended while receiving PAUSE packets. |
| | Filter function | 48-bit (6-byte) patterns x 2 (byte length and off-set value can be set up) |
| | Alarm function | Setting the threshold values for transmitting frames and receiving frames per second, and error counts. |
| | ARP Reply function | Processes ARP reply to the ARP request when AE5501 is working. |
| | DHCP / ARP function | The acquisition of address to use in the measurement port is done by DHCP and ARP. |
| | Remote control function | Enables remote control using Telnet. |
| | Macro function | Performs automatic measurement when a measurement operation is specified in advance. |

NOTE

With this device, it is possible to edit some of the measurement information set by the AE5730E TrafficTesterMini Setup Software.

The error reception priorities are as follows. When the device detects more than one error at the same time, errors of lower priority will not be counted.

| | |
|-----------------|------------------|
| Symbol Error | |
| Over Size Error | Under Size Error |
| Alignment Error | |
| CRC Error | |



1.2.2 Electrical Specifications

Table 1.2-2 shows the electrical specifications of this device.

Table 1.2-2 Electrical Specifications

| Item | Subitem | Description |
|-----------------------------|-------------------|--|
| Network interface | Measuring port | 10BASE-T 100BASE-TX 1000BASE-T When equipped with a GBIC, it can run on 1000BASE-SX/LX. |
| | Remote port | 10BASE-T HALF |
| Display and input interface | Display interface | 2.8" LCD (320 x 240 dot matrix) |
| | Input interface | Exclusive key-in |
| | LED | POWER (Power on/off indicator) RUN (in the measuring process), LINK (L1 link up/down) TX (Transmit), RX (Receive) |
| Power supply | AC power supply | Use the AC adapter attached to the device. Rated voltage: 100 -240 V AC Rated frequency: 50 - 60 Hz Maximam power consumption: 90 VA AC adapter output: 9 V DC, 4A |
| | Battery | Ni-MH rechargeable battery, AA-size 6cells, 1.2 V, 1900mAh per cell or more Capable of continuously operating for about two hours (about 1.5 hours when measuring 1000BASE-T lines) |
| Dimensions and weight | Dimensions | H60 x W120 x D215 mm |
| | Weight | About 1 kg (main body) (about 1.2 kg with battery and GBIC equipped) |
| Operating environment | Temperature range | 5–35°C |
| | Humidity range | 35–85% |

NOTE

Only those optional batteries, chargers and GBICs that the user has purchased from Our company may be used with this device.

Devices that are easily affected by noise may be affected by the conducted interference generated from the AC adapter cable that is connected to this product. In such case, the user is required to correct the interference.

1.3 Configuration

This section describes the configuration of the main device and optional accessories for the AE5501 TrafficTesterMini.

1.3.1 Components of the Main Device

The main device consists of the following components shown in Table 1.3-1.

Table 1.3-1 Components of the Main Device

| Item no. | Name | Quantity | Remarks |
|-------------|--------------------------|----------|---|
| 1 | AE5501 TrafficTesterMini | 1 | Main device |
| Accessories | | | |
| 2 | AC adapter | 1 | |
| 3 | Power cable | 1 | |
| 4 | AS-84708 | 1 | AE5501 TrafficTesterMini Instruction Manual |

1.3.2 Lineup of Optional Accessories

Table 1.3-2 shows the lineup of optional accessories.

Table 1.3-2 Lineup of Optional Accessories

| Item no. | Name | Quantity | Remarks |
|----------|------------------------------------|----------|--|
| 1 | 1000BASE-LX GBIC module for AE5501 | 1 | Only those optional batteries, chargers and GBICs that the user has purchased from Our company can be used with this device. |
| 2 | 1000BASE-SX GBIC module for AE5501 | 1 | |
| 3 | Rechargeable battery for AE5501 | 1 set | |
| 4 | Battery charger for AE5501 | 1 | |
| 5 | Soft case AZ8128 | 1 | |
| | | | Shoulder bag to carry this device. |

1.3.3 Optional Accessories

This section describes the optional accessories available for AE5501.

1 GBIC

Table 1.3-3 shows the manufacturers/suppliers and model names of GBICs.

Table 1.3-3 GBIC

| Product name | Manufacture/supplier | Model |
|------------------------------------|----------------------|-------------|
| 1000BASE-LX GBIC module for AE5501 | Agilent | HFCT-5611 |
| | JDS Uniphase | JGB-12LYAA |
| 1000BASE-SX GBIC module for AE5501 | Agilent | HFBR-5601 |
| | JDS Uniphase | JGB-12SYAA1 |

NOTE

The manufacturer/supplier and models of the GBIC are subject to change without prior notice.

2 Battery and Battery Charger

Table 1.3-4 shows the manufacturers/suppliers and model names of the battery and charger.

Table 1.3-4 Battery and Battery Charger

| Product name | Manufacture/supplier | Model |
|--|-----------------------------------|----------|
| Rechargeable battery (Nickel hydride battery) | Matsushita Electric Industrial | HHR-3XPS |
| Battery charger | Matsushita Electric Industrial | BQ-390 |

Pay careful attention to the following cautionary statements when using batteries.

Detach the battery when the device will not be used for an extended period of time. A small amount of current continues to flow even after you switch off the power supply.




Recycle used batteries.

Newly purchased batteries must be charged prior to use.

The operating time is shortened for new batteries and batteries left unused for an extended period of time. Repeating the cycle of recharging and discharging batteries two or three times will restore the operating time.

If you repeatedly recharge batteries before they are fully discharged, the operating time will be shortened. In this case, fully discharge the batteries by using the discharge button of the battery charger. Refer to the instruction manual of your battery charger for operating the discharge button.

Clean the battery electrodes on a regular basis to avoid voltage drop.

| | |
|---|--|
|  | WARNING |
| <p>Do not throw a battery into a fire. There is a dangerous risk that they may explode.</p> <p>Do not short-circuit battery terminals. Doing so may generate heat and/or explosion.</p> <p>Do not try to disassemble a battery. Electrolytes may leak out and/or the battery may generate heat and/or explode.</p> <p>Rinse your hands thoroughly with a large amount of water if battery electrolytes come into contact with your hands.</p> |   |

| | |
|---|--|
|  | CAUTION |
| <p>Use our optional battery charger only. Do not use other battery chargers.</p> |  |

| |
|---|
| NOTE |
| <p>The manufacturers/suppliers and models of the battery and/or battery charger are subject to change without prior notice.</p> |

Chapter 2 Before Getting Started

This chapter describes unpacking and repacking of the device, acceptance testing and general cautionary notes. Read this chapter before using the device to ensure proper handling and operation.

2.1 Unpacking and Repacking

This section describes the unpacking, repacking, package contents check, mechanical check and operational check for the device.

2.1.1 Unpacking

This product was checked for mechanical and electrical integrity prior to being shipped from our factory and is guaranteed for proper operation. Immediately after receiving this product, unpack it and check for any damage that may have occurred during transport.

We recommend that you not damage the cardboard box, buffer and other inner packing materials, except consumable packing materials such as wrapping paper, and keep them for repacking in case of future transfer.

2.1.2 Checking the Package Contents

Check to see if there are no package contents (components) of the device missing, referring to Table 1.3-1.

2.1.3 Mechanical Check

Check to see if any damage or deformity of the product's appearance occurred during transport or if there is any malfunction of the device's switches or connectors.

2.1.4 Operational Check

If no defects are found during the mechanical check, conduct an operations test to check the functionality. Confirm that the product operates properly according to the specifications.

2.1.5 If Any Damage or Abnormality Is Found

Call the Our company if you find any damage or malfunction as a result of checking the product.

2.1.6 Repacking

Use the original packing materials for repacking. Repack the product in the following manner if the original materials are not available:

- 1 Wrap the product with durable material such as duplex asphalt paper or vinyl sheeting. Protect any protruding portions by using buffering materials.
- 2 Prepare a wooden or cardboard box that is larger than the product by 10 cm or so in every direction and place the product as wrapped in (1) into the box.
- 3 Place polyurethane foam or other buffer materials into the gap between the box and the product. Use sufficient buffer materials to prevent any damage due to vibration or impact during transport.
- 4 Close the box lid and if the box is cardboard, seal it firmly with adhesive tape or other sealing material.
- 5 Indicate the contents, destination, shipper and other necessary information on a conspicuous area of the box.

Chapter 3 Functionality

This chapter describes the names and functions of the panels and the software's functionality.

3.1 Names and Functions of the Panels

This section describes the names and functions of the panels.

3.1.1 Front Panel

Figure 3.1-1 shows the front panel of this device.




Figure 3.1-1 Front panel

1 Display

This is the LCD for displaying settings and results.

| |
|---|
|  CAUTION |
| <p>The display is LCD (liquid crystal display) and is vulnerable to impact. Use caution when handling the display to avoid causing any damage.</p> <div style="float: right; text-align: center;">  </div> |

2 LED

Table 3.1-1 explains the functions of LEDs.

Table 3.1-1 LED Conditions

| Display | Color | Condition for displaying | Condition for disappearing |
|---------|-------|---|---|
| TX | Green | When transmitting frames | During idle |
| RX | | When receiving frames | During idle |
| LINK | | Connecting L1 link *1 | Disconnecting L1 link |
| RUN | | During measurement (during RUN process) | Waiting for measurement (during STOP process) |
| POWER | | When the power supply is on *2 | When the power supply is off |

1: It lights up when FULL is selected as the communication method and blinks when HALF is selected.

2: It blinks during the boot-up process and the termination process.

3 Keyboard

Table 3.1-2 explains the functions of the keys.

Table 3.1-2 Functions of Keys

| Indication | Function |
|------------|---|
| POWER | To turn on/off the power supply on *1 |
| RUN | To start measuring |
| STOP | To stop measuring |
| ENTER | To determine data, display a subitem or enter a subitem |
| DISP | To change the display or determine a item |
| UP | To choose a subitem |
| DOWN | |
| ↑ | To move the cursor/scroll the screen |
| ↓ | To move the cursor/scroll the screen |
| ← | To move the cursor |
| → | To move the cursor |

1: Press the key for one second to turn on the power supply and for two seconds to turn off the power supply.

3.1.2 Right Side Panel

Figure 3.1-2 shows the right side panel of this device.




Figure 3.1-2 Right side panel

1 LCD contrast control

This button is for controlling the contrast of the LCD. Moving it upwards increases the contrast and moving it downwards decreases the contrast.

2 Remote port

This is the port for 10BASE-T HALF, which is used in the remote mode.

3 Power inlet

This is the terminal for the AC adapter attached to the device.

3.1.3 Top Side Panel

Figure 3.1-3 shows the top side panel of this device.




Figure 3.1-3 Top side panel

- 1 Measuring port for 10/100/1000BASE-T
This port is for measuring 10BASE-T, 100BASE-TX and 1000BASE-T.
- 2 Measuring port for 1000BASE-SX/LX
This is the GBIC slot for measuring 1000BASE-SX and 1000BASE-LX. Mount the optional GBIC module here.
- 3 Battery cover
This is the cover for the battery housing.
- 4 Battery cover setscrew
This is the screw to fix the battery cover in position.

3.2 Measuring Function

This section outlines the measuring function of the device.

3.2.1 Traffic Generate Mode

By setting the device in the traffic generate mode, it is possible to generate the desired traffic on the line to be measured. The Receiver function can be used to measure the number of frames, frame bytes, and information on various errors and information on frame intervals.

Table 3.2-1 and Table 3.2-2 provide details on the traffic generate mode.

Table 3.2-1 Traffic generate Mode 1

| Item | Subitem | Description | |
|----------------------|---|---|---|
| Transmitter function | Transmission method | Constant, Burst (IFG, IDLE, Count setup) *2 | |
| | Specified number of transmissions | Continue, Count (IFG, Count setup) *2 | |
| | Transmission pattern | | Capable of setting up four patterns at maximum. |
| | | | Packet length setting (26 to 9,999 bytes) |
| | | | MAC address setting |
| | | | VLAN tag setting (up to Stack 4) |
| | | | LLC header setup/SNAP header setup *1 |
| | | | MPLS header setup (SIMM header Stack 4) *1 |
| | IPv4 header/IPv4 multicast/IPv6 header setup *1 | | |
| | Transmission time | Test time setup (0 to 1,440 min) | |
| Layer 1 setting | Auto-negotiation | Auto (available for 10BASE-T and 100BASE-TX) *3 | |
| | Flow control | Transmission control when receiving PAUSE frames | |
| | Connector specifications | To select the connector specification (CROSSOVER STATUS) of the measuring port for 10BASE-T, 100BASE-TX and 1000BASE-T. | |

1: In the case of IPv4, it is possible to edit SrcIP and DstIP. In the case of IPv4 Multicast, it is possible to edit SrcIP only. Editing of other fields is possible only with the AE5730E TrafficTesterMini Setup Software.

2: Setup units for IFG are μ sec, nsec, %, bit and frames per second.
Setup units for IDLE are sec, msec, μ sec and bit.

3: In the case of 1000BASE-T/SX/LX, the capability is fixed at 1,000 Mbps and full auto-negotiation can be used.

Table 3.2-2 Traffic generate Mode 2

| | | |
|---------------------|-----------------------|--|
| Receiver function | Filter function | Capable of setting up two filtering patterns of up to six bytes (in bits and "don't care" available). Offset is possible (0 to 58) |
| | Alarm function | Sets up the threshold for frames received per second. |
| | | Sets up the threshold for frames transmitted per second. |
| | | Sets up the threshold for receiving error counts. |
| Statistics function | Traffic | Tx/Rx rate (%), Number of Tx/Rx frames, Number of Tx/Rx bytes Tx/Rx frames per second, Tx/Rx bits per second |
| | Errors | CRC error, Oversize error, Undersize error, Alignment error |
| | Idle time measurement | Measures the time interval between certain frames. When 10 Mbps selected: Resolution = 1 μ s, Maximum tolerance = 3 μ s When 100/1000 Mbps selected: Resolution = 100 ns, Maximum tolerance = 300 ns |
| | Others | Number of collisions, Number of PAUSE frames |
| ARP reply function | | ARP reply to ARP request in Traffic Generation Test Mode. |

The details of the ARP reply function is shown in the bottom.

1 The condition that ARP reply is done

An ARP reply frame is transmitted when an ARP request frame is received when a setup of an ARP reply of the measurement condition chosen at present is on.

The length of the frame is 64byte.

A count isn't done as a receiving frame though an ARP reply frame is transmitted even if it faces the ARP request frame which is applicable to the filter condition.

2 The condition that ARP isn't done.

When the following ARP request frame is received, the transmission of the ARP reply frame isn't done.

The ARP request frame which VLAN tag is added to.

The ARP request frame which MPLS label is added to.

The ARP request frame counted as an error frame.

The ARP request frame that the length of the packet is less than 63byte.

The ARP request frame that the length of the frame is beyond 1519byte.

The ARP request frame that the length of the frame is beyond the setup value of the oversize

3.2.2 Latency Check Mode

By setting the device in the latency check mode, it is possible to transmit to the line to be measured at a specified traffic rate. If you use the loop back function to receive the frame that you have transmitted, it is possible to measure the delay time of the line to be measured.

You can use the Receiver function to measure the number of frames, frame bytes, information on various errors and information on frame intervals in a manner similar to that of traffic generate mode.

Table 3.2-3 provides details on the latency check mode.

Table 3.2-3 Latency check Mode

| Item | Subitem | Description | |
|------------------------|-----------------------------------|---|---|
| Transmitter function | Transmission method | Constant, Burst (IFG, IDLE, Count setup) *2 | |
| | Specified number of transmissions | Continue, Count (IFG, Count setup) *2 | |
| | Transmission pattern | | Capable of setting up four patterns at maximum. |
| | | | Packet length setup (64 to 9,999 bytes) |
| | | | MAC address setup |
| | | | VLAN tag setup (up to Stack 4) |
| | | | LLC header setup/SNAP header setup *1 |
| | | | MPLS header setup (SIMM header Stack 4) *1 |
| | | | IPv4 header/IPv4 multicast/IPv6 header setup *1 |
| | Transmission time | Test time setup (0 to 1,440 min) | |
| Layer1 setting | Auto-negotiation | Auto (available for 10BASE-T and 100BASE-TX) *3 | |
| | Flow control | Transmission control when receiving PAUSE frames | |
| | Connector specifications | To select the connector specification (CROSSOVER STATUS) of the measuring port for 10BASE-T, 100BASE-TX and 1000BASE-T. | |
| Receiver function | Filter function | It is possible to set up two filtering patterns of up to six bytes (in bits and "don't care" available). | |
| | | Offset is possible (0 to 58) | |
| Delay time measurement | Idle time measurement | When 10 Mbps selected: Resolution = 1 μ s , Maximum tolerance = 3 μ s When 100/1000 Mbps selected: Resolution = 100 ns, Maximum tolerance = 300 ns | |
| | Delay time | When 10 Mbps selected: Resolution = 1 μ s, Maximum tolerance = 3 μ s When 100/1000 Mbps selected: Resolution = 100 ns, Maximum tolerance = 300 ns | |
| ARP reply function | | ARP reply to ARP request in Traffic Generation Test Mode. | |

1: In the case of IPv4, it is possible to edit SrcIP and DstIP. In the case of IPv4 Multicast, it is possible to edit SrcIP only. Editing of other fields can be set up only with the AE5730E TrafficTesterMini Setup Software.

2: Available setup units for IFG are μ sec, nsec, %, bit and frames per second.

Available setup units for IDLE are sec, msec, μ sec and bit.

3: In the case of 1000BASE-T/SX/LX, the capability is fixed at 1,000 Mbps and full auto-negotiation can be used.

The details of the ARP reply function is shown in the bottom.

1 The condition that ARP reply is done

An ARP reply frame is transmitted when an ARP request frame is received when a setup of an ARP reply of the measurement condition chosen at present is on.

The length of the frame is 64byte.

A count isn't done as a receiving frame though an ARP reply frame is transmitted even if it faces the ARP request frame which is applicable to the filter condition.

2 The condition that ARP isn't done.

When the following ARP request frame is received, the transmission of the ARP reply frame isn't done.

The ARP request frame which VLAN tag is added to.

The ARP request frame which MPLS label is added to.

The ARP request frame counted as an error frame.

The ARP request frame that the length of the packet is less than 63byte.

The ARP request frame that the length of the frame is beyond 1519byte.

The ARP request frame that the length of the frame is beyond the setup value of the oversize

3.2.3 Loop Back Mode

In the loop back mode, you can loop back those frames received that have specific destination MAC addresses or IP addresses.

Table 3.2-4 provides details on the loop back mode.

Table 3.2-4 Loop Back Mode

| Item | Subitem | Description |
|---|--------------------------|---|
| Loop back function (Transmitter function) | MAC address | This replaces the destination of a received frame with the MAC address of the sender, recalculates the CRC and then loops it back to the sender. |
| | MAC address IP address | This replaces the destination of a received frame with the MAC and IP address of the sender, recalculates the CRC and then loops it back to the sender. |
| Layer1 setting | Auto-negotiation | Auto (available for 10BASE-T and 100BASE-TX) *1 |
| | Connector specifications | To select the connector specification (CROSSOVER STATUS) of the measuring port for 10BASE-T, 100BASE-TX and 1000BASE-T. |
| Receiver function | MAC address setting | MAC address setting for the measuring port |
| | IP address setting | IP address setting for measurement port |
| | Vlan setting | Setting for number of VLAN tag stacks in received frame |
| ARP reply function | | ARP reply to ARP request in Traffic Generation Test Mode. |

1: In the case of 1000BASE-T/SX/LX, the capability is fixed at 1000 Mbps and full auto-negotiation can be used.

The details of the ARP reply function is shown in the bottom.

1 The condition that ARP reply is done

An ARP reply frame is transmitted when an ARP request frame is received when a setup of an ARP reply of the measurement condition chosen at present is on.

The length of the frame is 64byte.

A count isn't done as a receiving frame though an ARP reply frame is transmitted even if it faces the ARP request frame which is applicable to the filter condition.

2 The condition that ARP isn't done.

When the following ARP request frame is received, the transmission of the ARP reply frame isn't done.

The ARP request frame which VLAN tag is added to.

The ARP request frame which MPLS label is added to.

The ARP request frame that the length of the packet is less than 63byte.

The ARP request frame that the length of the frame is beyond 1519byte.

The ARP request frame that the length of the frame is beyond the setup value of the oversize

NOTE

The following frames will not be looped back:

- Frames with a length of 63 bytes or less

- Broadcast frames

- Multicast frames

CRC error frames will be looped back as CRC error frames.

The flow control operation is not supported.

When a MAC address and an IP address are chosen as a loop back function, only the frame which has the following frame composition by the DIX format becomes a label object.

- (a) MAC + TYPE + IPv4

- (b) MAC + VLAN + TYPE + IPv4

3.2.4 Ping Test Mode

This function transmits Ping frames to specified IP addresses.
Table 3.2-5 provides details on the Ping test mode.

Table 3.2-5 Ping test Mode

| Item | Subitem | Description |
|--|--|---|
| Address setting for the measuring port | MAC address | Manual setting or Global MAC address setting |
| | IP address | Manual setting or IP address setting acquired by DHCP |
| Transmitter function | Transmission interval | You may choose 1 second, 5 seconds or 10 seconds. *1 |
| | Transmission pattern | Packet length setup (64 to 1,518 bytes) |
| | | MAC address setup |
| | | VLAN tag setup (up to Stack 4) |
| Number of transmitted frames | To set the number of Ping frames to be transmitted (1 to 4,294,267,295 frames) | |
| Layer1 setting | Auto-negotiation | Auto (available for 10BASE-T and 100BASE-TX) *2 |
| | Connector specifications | To select the connector specification (CROSSOVER STATUS) of the measuring port for 10BASE-T, 100BASE-TX and 1000BASE-T. |
| Reception judgment function | Response time | To determine acceptability or unacceptability and to measure the response time (in μ s) To display the maximum, minimum and average response times |

1: Some jitters may occur in the transmission interval time.

2: In the case of 1000BASE-T/SX/LX, the capability is fixed at 1000 Mbps and full auto-negotiation can be used.

3.2.5 Reply Mode

This mode is used to return a reply when a Ping or ARP frame is received. Table 3.2-6 provides details on the reply mode.

Table 3.2-6 Reply Mode

| Item | Subitem | Description |
|--|--------------------------|---|
| Address setting for the measuring port | MAC address | Manual setting/Global MAC address setting |
| | IP address | Manual setting/IP address setting acquired by DHCP |
| Transmitter function | | To transmit Ping/ARP response frames VLAN supported (up to Stack 4) |
| Receiver function | | To receive Ping/ARP request frames VLAN supported (up to Stack 4) |
| Layer 1 setting | Auto-negotiation | Auto (available for 10BASE-T and 100BASE-TX) *1 |
| | Connector specifications | To select the connector specification (CROSSOVER STATUS) of the measuring port for 10BASE-T, 100BASE-TX and 1000BASE-T. |
| Reception judgment function | Number of responses | Ping, ARP reply |

1: In the case of 1000BASE-T/SX/LX, the capability is fixed at 1,000 Mbps and full auto-negotiation can be used.

3.2.6 DHCP/ARP function

This function uses DHCP for measurement port IP address acquisition, and uses ARP for measurement target MAC address acquisition. Details pertaining to DHCP/ARP mode are presented in Table 3.2-7.

Table 3.2-7 DHCP Function Details

| Item | Subitem | Description |
|--|-----------------|--|
| Address setting for the measuring port | MAC address | Sets the MAC address of the measurement port. |
| | IP address | Sets the IP address of the measurement port. The IP address acquired using DHCP can also be set. |
| | Subnet mask | Sets the subnet mask of the measurement port. The subnet mask acquired using DHCP can also be set. |
| | Default gateway | Sets the default gateway of the measurement port. The default gateway acquired using DHCP can also be set. |
| Destination address setting | IP address | Sets the destination IP address manually. |
| | MAC address | Sets the MAC address acquired by ARP as the destination MAC address. |

3.2.7 MACRO function

With this function, an operation related to measurement is specified prior to measurement, and measurement is automatically performed as specified. Details pertaining to the MACRO function are presented in Table 3.2-8.

Table 3.2-8 MACRO Function Details

| Item | Subitem | Description |
|-------------------------|--------------|-------------------------------|
| MACRO function commands | RUN command | Starts measurement |
| | STOP command | Stops measurement |
| | WAIT command | Sets wait time |
| | SEL command | Selects measurement condition |
| | GOTO command | Goes to specified command |
| | END command | Ends macro operation |
| | ; | Command not entered |

3.2.8 Telnet remote control function

This function remotely controls the AE5501 through a PC or the like via Telnet. A list of TELNET functions is presented in Table 3.2-9.

Table 3.2-9 TELNET Remote Control Functions

| Function name | Overview |
|-------------------------------------|---|
| Super user | The authority change of the TELNET movement |
| Remote control stop | Stops TELNET remote control of AE5501 |
| Measurement start | Starts measurement |
| Measurement stop | Stops measurement |
| Status check | Checks AE5501 status |
| Change measurement condition | Selects setting file to be used during measurement |
| Display measurement conditions list | Displays list of setting files to be used during measurement |
| Change settings | Edits settings in setting file |
| Setting check | Displays settings in setting file |
| Display measurement results | Displays measurement results |
| Display results file list | Displays a list of measurement results |
| Delete results file | Deletes measurement results |
| Display version | Checks the AE5501 version information |
| Self test | Performs AE5501 self test |
| Set time/date | Sets the AE5501 calendar |
| Display time/date | Displays the AE5501 calendar |
| Set all defaults | Changes all AE5501 settings to their defaults |
| Version upgrade | Upgrades the AE5501 version |
| AE5730E remote control | Sends and receives setting files and measurement result files between AE5730E and AE5501 |
| Performs DHCP | An IP address is acquired by DHCP for the measurement port. |
| Performs ARP | The MAC address of the specified terminal is acquired by the ARP treatment. |
| Set prompt | The change of prompt indicated on the terminal screen. |
| Set password | The settlement of a password to use a command. |
| Command history list | The indication of the on history list of the character line inputted on the terminal screen |
| Help | TELNET command help |
| Register script command | Registers a script command |
| Display program | Displays registered script commands |
| Execute script | Executes a registered script command |
| Wait | Continues TELNET command |
| Repeat | Repeats TELNET command |

3.2.9 Remote Setup Function

Table 3.2-10 provides details on the remote setup function.

Table 3.2-10 Remote Setup Function

| Item | Subitem | Description |
|----------------|---------|--|
| Remote setting | Auto | DHCP ON |
| | Manual | DCHP OFF, IP address, Subnet mask setting, Default gateway setting |

3.2.10 Analytical Function

Table 3.2-11 provides details on the analytical function.

Table 3.2-11 Analytical Function

| Item | Subitem | Description |
|---------------------|---------------------|----------------------------------|
| Analytical function | Measurement results | To display measurement results. |
| | Setup validation | To display measurement settings. |

[This page is intentionally left blank.]

Chapter 4 Operating Instructions


This chapter describes the operating procedures for the AE5501 TrafficTesterMini.

4.1 Preparation and Operation Check

This section describes how to turn on/off the power supply and explains the basic operating procedure for this device.

4.1.1 Flow Chart of the Operating Procedure

The flow of the fundamental operating procedure is shown below.



CAUTION

Remove the GBIC when conducting measurement in 10BASE-T or 100BASE-TX.

The battery life decreases while the GBIC is connected because it consumes more electricity.

The message "PULL OUT GBIC" will be displayed on the LCD screen if the GBIC is connected to the device when you attempt to conduct measurement in 1000BASE-T.



4.1.2 Inserting Optional Modules

This section describes the procedure for inserting the GBIC module, which is used for measurement of 1000BASE-SX/LX.

Place the device with the side shown in Figure 4.1-1 facing upward and insert the GBIC into the measuring port for 1000BASE-SX/LX.

Move the lever in the direction of the arrow to pull out the GBIC module.




Figure 4.1-1 Agilent GBIC module





Figure 4.1-2 Inserting the GBIC module

| |
|---|
|  WARNING |
| <p>Do not attempt to peer into the measuring port when you mount the GBIC module. Doing so is a health hazard and may result in an injury.</p> <p>When replacing an optional module, make sure that the power LED is off.</p> |

4.1.3 Preparing the Power Supply

This device may be operated with either battery or AC power. The following subsections describe the procedures for preparing the power supplies.

1 AC power supply

Before using AC power

Ensure that the AC power supply (outlet) ratings conform to the requirements of the AC Adapter for AE5501.

Ensure that the POWER LED is Not lighting before connecting the AC power.

Method of connecting AC power (shown in Figure 4.1-3)

- (1) Connect **AC adapter power cord** to **AC adapter for AE5501**.
- (2) Connect **AC adapter power plug** to **AC power outlet**.
- (3) Connect **AC adapter terminal** to **Power inlet**.

AC power ratings

Voltage: 100-240 V AC, Voltage tolerance: 90-264 V AC
 Frequency: 50-60Hz, Frequency tolerance: 48-63 Hz
 Maximum power: 90 VA






Figure 4.1-3 How to connect the AC power supply

| |
|--|
|  CAUTION |
| <p>Use only the AC adapter attached to the device. Using a product other than the standard adapter may cause device failure.</p> |

2 Battery




Figure 4.1-4 shows the method of inserting the batteries and matching their polarities.





(a) Inserting batteries

(b) Matching batteries polarities

Figure 4.1-4 Inserting batteries and matching their polarities

| | |
|--|--|
|  WARNING | |
| Be sure that the batteries are inserted in the direction indicated in Figure 4.1-4(b). Failure to do so may cause the battery to generate heat and/or fire. Do not use a battery that is obviously damaged. |   |

| | |
|--|---|
|  CAUTION | |
| Inserting or detaching the battery should be done only after you disconnect the AC power supply. Ignoring this caution may result in a situation that causes device failure. |  |

4.1.4 Turning On the Power Supply

After the preparation of the power supply is completed, press the POWER key on the front panel (for 1 second) until the power LED lights up.

One of the following two indications will be displayed on the upper left of the LCD screen when you turn on the power, depending on the type of power supply in use.




Figure 4.1-5 Power indications

The meanings of the power indications are as follows:

| Indication | Description |
|------------|---|
| (a) | The remaining battery capacity is 50–100%. |
| (b) | The remaining battery capacity is 20–50%. |
| (c) | The remaining battery capacity is 0–20%. |
| (d) | No battery is inserted or the remaining battery capacity is very low. |
| (e) | AC power supply is in use. |



CAUTION

Make sure that the power indication is either (a) or (e) as shown in Figure 4.1-5 when you set the device in remote mode.

Wait at least 15 seconds from the time the device is powered off before attempting to restart it.

Power off and then restart the device at least 15 seconds later if the power LED is blinking and the LCD screen remains blank for more than one minute after turning on the device.

There is a possibility that a system file is corrupted if there is no change on the LCD screen but the BOOT screen logo remains on display for more than one minute after turning on the device. In this case, refer to the "System Recovery Screen" section of the instruction manual for the AE5730E TrafficTesterMini Setup Software to recover the damaged file.



NOTE

If you press the POWER key until the power LED lights up, the BOOT screen as shown in Figure 4.2-6 will be displayed about 15 seconds later. Conduct necessary operations when the Mode Select screen is subsequently displayed, as shown in Figure 4.2-7.

If (a) is not indicated even though the battery is fully charged, the battery is near the end of its life expectancy and must be replaced with a new one.

Upon receiving the device, check that the clock is set correctly. Incorrect settings may result in file handling problems.

Drop a power supply promptly, and use a battery after you charge it if a warning message is indicated.

Even if an AC adapter is used, the power is not expected to be on continuously for an extended length of time. (Operations have been verified under continuous power for approximately 72 hours.)

4.1.5 Connecting to an AE5730E-installed PC

This device is to be connected to a PC with the AE5730E TrafficTesterMini Setup Software installed. It can be connected either directly or through a LAN. Choose a PC that is equipped with a network interface card (NIC) and TCP/IP protocol installed.

1 Connecting through a LAN

Connect the device as shown in Figure 4.1-6




Figure 4.1-6 Connecting through a LAN

NOTE

The network setting for the remote port is as follows when shipped from the factory.

IP address: 192.168.0.1

Subnet: 255.255.255.0

Gateway: 0. 0. 0. 0

The network setting for the remote port is configured as mentioned above when you power on the device. Make sure that there is no adverse effect on the remote line in use.

You may alter the remote port settings by changing them on the Remote Setup screen.

2 Direct connection

Connect the device as shown in Figure 4.1-7




Figure 4.1-7 Direct connection

When you use a cross cable to connect the AE5501 TrafficTesterMini to a PC with the AE5730E TrafficTesterMini Setup Software installed, you must set up the PC as described below in (a) through (d). An AE5730E-installed PC with Microsoft® Windows® 2000 operating system is used as an example in this section. The setting methods for PCs with other OSs installed are explained in Section “5.5 Connection Configuration for AE5730E-installed PC”.

(a) On the Windows Start menu, select [Settings] → [Control Panel]. The dialog shown in Figure 4.1-8 will be displayed. Double-click [Network and Dial-up Connections].




Figure 4.1-8 [Control Panel] dialog

(b) After completing the operation in (a), the dialog shown in Figure 4.1-9 will be displayed. Double-click [Local Area Connection].




Figure 4.1-9 [Network and Dial-up Connections] dialog

(c) Double-clicking [Local Area Connections] on the dialog shown in Figure 4.1-9 displays a new dialog (Figure 4.1-10). Click [Properties].




Figure 4.1-10 [Local Area Connection Status] dialog

- (d) When the dialog shown in Figure 4.1-11 appears, select [Internet Protocol (TCP/IP)] and click [Properties].




Figure 4.1-11 [Local Area Connection Properties] dialog

NOTE

You should keep a copy of the network settings for your PC with the AE5730E TrafficTesterMini Setup Software installed in order to recover it if required.

(e) After you complete the operation described in (d), the [Internet Protocol (TCP/IP) Properties] dialog will appear. Set up the [Internet Protocol (TCP/IP) Properties] as shown in Figure 4.1-12 and click [Advanced]. The chart below shows sample values of the [IP Address] and [Subnet Mask]. If any values have been set up previously, it is not necessary to change them.




Figure 4.1-12 [Internet Protocol (TCP/IP) Properties] dialog

(f) When the [Advanced TCP/IP Settings] dialog appears, set it up as follows. Set [IP Settings] as follows.




Figure 4.1-13 Advanced TCP/IP Settings

Set [DNS] as follows.




Figure 4.1-14 DNS Setup

Set up [WINS] as shown in the following chart and then click [OK].




Figure 4.1-15 WINS Setup

- (g) Clicking [OK] on the dialog shown in Figure 4.1-15 displays a new dialog (Figure 4.1-12).
- (h) Click [OK] on the dialog shown in Figure 4.1-12. The dialog shown in Figure 4.1-11 will be displayed.
- (i) Clicking [OK] on the dialog shown in Figure 4.1-11 displays a new dialog (Figure 4.1-10). Clicking [OK] completes the setup procedure.

NOTE

Use a cross cable if you want to make a direct connection.
When connecting directly to a PC with the AE5730E TrafficTesterMini Setup Software installed, the device may not be able to communicate with the PC if it is left with the cross cable disconnected for an extended period of time. In this case, reboot the PC. Terminate all applications and resident programs that are running on other networks except the AE5730E and do not enable them if you are using the AE5730E TrafficTesterMini Setup Software.
Both the IP address for the remote port to be set using this device and the address to be set using the Network dialog, shown in Figure 4.1-9, in the PC with the AE5730E TrafficTesterMini Setup Software installed, must have the same network address number specified by the subnet mask.

Example

| | |
|--------------------------------|-------------------------------|
| AE5501 TrafficTesterMini | AE5730E TrafficTesterMini |
| IP ADDR SET <u>192.168.0.1</u> | Setup Software |
| SUBNET MASK | IP address <u>192.168.0.2</u> |
| | Subnet mask 255.255.255.0 |



CAUTION

Use the measuring port for 10BASE-T, 100BASE-TX and 1000BASE-T separately from the remote port. If the two ports are used at the same time, the network lines may be adversely affected.
The remote port is fixed for 10BASE-T half duplex.



4.1.6 Setting Up the Remote IP Address

Set up the IP address for the remote port. Refer to "4.2.16 Remote Setup Screen" for the detailed setup procedure.

4.1.7 Uploading the Setting

1 Upload standby

Pressing the OK button as shown in Figure 4.1-16(a) enables data communication with the PC with the AE5730E TrafficTesterMini Setup Software installed.




Figure 4.1-16 Upload standby mode

2 Uploading the settings

Upload the setup data by using the PC with AE5730E TrafficTesterMini Setup Software installed. For the uploading procedure, refer to the instruction manual for the AE5730E TrafficTesterMini Setup Software. Press the STOP button shown in Figure 4.1-16(b) when the setup data has completed uploading.

4.1.8 How to Use the Measuring Port

Use port (1) shown in Figure 3.1-3 to measure 10BASE-T, 100BASE-TX and 1000BASE-T lines. Use port (2) in Figure 3.1-3 to measure 1000BASE-SX/LX line.

To mount the GBIC module, refer to "4.1.2 Inserting Optional Modules."

Different types of connecting cables are required for 10BASE-T, 100BASE-TX and 1000BASE-T lines, respectively, depending on their crossover setup.

Use straight or cross cables to connect the TrafficTesterMini to a DTE (PC or hub). Choose either of the two cables according to the connector specifications of the device being connected.

The TrafficTesterMini accommodates connection to MDI, MDIX and AUTO and thus can flexibly connect to a variety of devices.

The following charts show sample connection configurations of each crossover setup and explain the difference between MDI and MDIX. The default crossover setup is MDI.




Figure 4.1-17 Relationship between connecting cable types and crossover setups




Figure 4.1-18 Measuring port interface

4.1.9 Measurement

Conduct measurement using the following procedure.

1 Starting measurement

Connect to the measuring port and the line to be measured, enter the settings on each screen, and press the RUN key on the front panel to start measurement. You can press the RUN key on any of the screens for Mode Select, Setup Select or Setup.




Figure 4.1-19 Starting measurement

2 Terminating measurement

Press the STOP key on the front panel to terminate measurement.

| |
|---|
| NOTE |
| Don't do plugging in and out of the cable being connected to the measurement port during the transmission of the frame and the reception because it has the possibility that the transmission of the frame and reception can't be done properly any more. |

4.1.10 Downloading Measurement Results

Download the measurement results using the AE5730E TrafficTesterMini Setup Software after checking the running condition on the Remote screen in the same manner as when uploading the setup. Press the STOP button on the Remote screen after the download is completed.

| |
|---|
| NOTE |
| When you download measurement results, the results file saved in the AE5501 main body is deleted. |
| When you upload the setup file, the results file is not deleted. |

4.1.11 Disconnecting the Power Supply

Disconnect the power supply using the following procedure only after ensuring that the device is not conducting measurement or operating by remote mode.

1 AC power supply

Press the POWER button on the front panel for 2 seconds. The power LED starts blinking. The power LED turns off when the power supply is disconnected. Pull out the power cable from the power inlet of the device.

2 Battery

Press the POWER button on the front panel for 2 seconds. The power LED starts blinking. The power LED turns off when the power supply is disconnected.

| | |
|--|---|
|  | CAUTION |
| Disconnect the power supply after ensuring that the device is not conducting measurement or operating by remote mode. Check that the message "Please Wait" is not displayed. Failure to check these items may result in device failure during the power-off procedure. | |
| |  |

4.2 Details on Functions

This section describes the screens. Section 4.2.2 shows a schematic diagram of the correlation among the device screens and also outlines each screen. The subsequent sections provide details on the functions and options of each screen.

4.2.1 Common Screen Elements

All screens shown on the device's LCD panel have the following elements in common.




Figure 4.2-1 Common screen elements

The meanings of the elements shown in Figure 4.2-1 are as follows.

- 1 Power indicator
An icon indicating the remaining battery capacity or AC power connection is displayed here.
- 2 Mode window
The name of the screen is indicated here.
- 3 Status window
The status of the measuring operation (running, stopped or remotely running) is indicated here.
- 4 Item window
Various display items are indicated here.
- 5 Scroll window
When you scroll through the display items, an arrow indicates the scroll direction.
- 6 Message bar
Messages are displayed here.

NOTE

When the device is running on battery power and the battery indicator displays only one bar, the following changes will occur on all screens other than the Online screen:

- (a) The battery indicator will be highlighted.
- (b) A warning message will be displayed.
- (c) The power LED will light up in orange.

If any of the above-mentioned status changes takes place, immediately press the POWER key for the time required to turn off the power.

Fully recharge the battery before reusing it.

When the battery indicator displays only one bar on the Online screen, a warning message will appear in the message bar.

4.2.2 Schematic Diagram of Screens

The following pages outline the correlation among screens displayed on the AE5501 LCD. Table 4.2-1 provides a description of each screen and the location where they are displayed.

Table 4.2-1 Brief Description of Screens

| Screen | Brief description | Item no. |
|------------------------|--|----------|
| Boot | Shows the boot status | 4.2.3 |
| Mode Select | Screen for selecting modes (the initial screen after the device is booted) | 4.2.4 |
| Setup Select | Screen for choosing setup items | 4.2.5 |
| OnLine | This screen is displayed while the device is running in a measuring mode | 4.2.6 |
| Off Select | Screen for selecting Offline | 4.2.7 |
| File Select | Screen for listing results files and performing edit operations | 4.2.8 |
| OffLine | Screen for showing the measurement results of all measuring modes | 4.2.9 |
| Setup | Screen for editing setups | 4.2.10 |
| Free Setup | Screen for setting up Ping/Reply/Loop Back modes | 4.2.11 |
| DHCP | The screen which does the setup of DHCP and practice | 4.2.12 |
| ARP | The screen which does the setup of ARP and practice | 4.2.13 |
| MACRO | The screen which does the setup of MACRO | 4.2.14 |
| MACRO function working | A screen during the MACRO movement | 4.2.14.5 |
| LOG VIEW | This screen is used to check the macro command operation history after macro operations are performed. | 4.2.15 |
| Remote | Screen for remote-mode operations | 4.2.16.1 |
| VerUp | Screen for operating in the system version upgrade mode | 4.2.16.2 |
| TELNET | The preparation screen of the remote control by TELNET | 4.3 |
| SelfTest | Screen for self-test operations | 4.2.17 |
| TimeSet | Screen for setting the time of AE5501 | 4.2.18 |
| ALL DEFAULT | Screen for conducting the CompactFlash check function | 0 |



CAUTION

Do not power off the device while the message "Please Wait" is being displayed. Doing so may result in device failure.



NOTE

In this manual, "button" refers to the options on the LCD panel and "key" represents the controls on the front panel of the main body.




Figure 4.2-2 Screen transition 1




Figure 4.2-3 Screen transition 2




Figure 4.2-4 Screen transition 3




Figure 4.2-5 Screen transition 4



4.2.3 Boot Screen

This screen displays the boot status. Figure 4.2-6 shows the Boot screen.

| | BOOT | STOP |
|---|------|------|
| AE5501 TrafficTesterMini VER : R03.01 BOOT1 : BOOT2 : BOOT3 : BOOT4 : | | |
| | | |

Figure 4.2-6 Boot screen

An error message is displayed when an error occurs during the boot process.

|  CAUTION | |
|---|---|
| <p>If the Remote and VerUP operations fail, check the network information on the System screen and retry the Remote and VerUP operations. The Link settings are as follows at the time of device boot-up: I/F.TX Speed.100M Duplex.FULL Flow Ctrl.ON Negotiation.AUTO</p> |  |

| NOTE |
|--|
| <p>If an error occurs during the boot-up process, an error message will be displayed and any input other than that from the POWER key will not be accepted. If the device enters this status, reboot and check it. Pressing the DISP key while the Boot screen is displayed enables access to the manual recovery mode. For further details, refer to the AE5730E TrafficTesterMini Setup Software Instruction Manual or Section 5.5.2 “About the Recovery Mode” of this manual.</p> |

4.2.4 Mode Select Screen

This screen is used for selecting modes (the initial screen). Figure 4.2-7 shows the Mode Select screen and Table 4.2-2 describes the functions of the keys.




Figure 4.2-7 Mode Select screen

Table 4.2-2 Key Functions (Mode Select screen)

| Key | Function |
|-------|---|
| POWER | Power On/Off |
| ↑ | To move the cursor |
| ↓ | To move the cursor |
| ← | NA |
| → | NA |
| RUN | Only (1) and (3) are available (to change to the Online screen) |
| STOP | NA |
| DISP | NA |
| ENTER | To change the screen mode |
| UP | NA |
| DOWN | NA |

1 Pressing the ENTER key changes any screen to the Setup Select screen while in the Generate/Latency mode.

2 Items chosen on the Setup Select screen will be displayed.

3 Pressing the ENTER key displays a Free Setup screen.

4 Mode (Ping, Reply and Loop Back) chosen on the Free Setup screen will be displayed.

5 Pressing the ENTER key displays a measurement results selection screen (Off Select screen).

6 Pressing the ENTER key display the DHCP screen.

7 Pressing the ENTER key display the MACRO screen.

8 Pressing the ENTER key displays the Remote screen.

9 Pressing the ENTER key displays the Self Test screen.

10 Pressing the ENTER key displays the Time Set screen.

11 Pressing the ENTER key displays the All Default screen.

12 Pressing the ENTER key display the Log View screen.

4.2.5 Setup Select Screen

This screen is used for selecting setup items. Selecting [GENERATE/LATENCY] on the Mode Select screen displays this screen.

Select the desired item and press the RUN key to start measuring. To edit the setup contents, select the desired item and press the ENTER key to change to the Setup screen. Figure 4.2-8 shows the Setup Select screen and Table 4.2-3 describes the functions of the keys.

| SETUP SELECT | |
|--------------|------------------------|
| 1 : | <u>GEN 1G-SX FULL</u> |
| 2 : | <u>LAT 100-TX FULL</u> |
| 3 : | <u>GEN 100-TX FULL</u> |
| 4 : | <u>GEN 10-T HALF</u> |
| 5 : | <u>LAT 1G-LX FULL</u> |
| 6 : | <u>LAT 100-TX HALF</u> |
| 7 : | <u>GEN 1G-SX FULL</u> |
| 8 : | <u>GEN 10-T HALF</u> |
| 9 : | <u>LAT 1G-SX FULL</u> |
| 10 : | <u>GEN 1G-LX FULL</u> |

Figure 4.2-8 Setup Select screen

Table 4.2-3 Key Functions (Setup Select screen)

| Key | Function |
|-------|-------------------------------------|
| POWER | Power On/Off |
| ↑ | To move the cursor |
| ↓ | To move the cursor |
| ← | NA |
| → | NA |
| RUN | To change to the Online screen |
| STOP | NA |
| DISP | To return to the Mode Select screen |
| ENTER | To change to the Setup screen |
| UP | NA |
| DOWN | NA |

NOTE

Strings shown in Figure 4.2-8 are specified for the AE5730E. These strings cannot be edited on the AE5501.

4.2.6 ONLINE Screen

This screen is displayed while the measurement operation is running. Figure 4.2-9, Figure 4.2-10, Figure 4.2-11 and Figure 4.2-12 show examples of the Online screen. For the location where the items are displayed, refer to Table 4.2-4. For the functions of the keys, refer to Table 4.2-9.

| | ONLINE | RUN |
|--|--|---|
| | <pre> SET: Setup No01 TEST MODE: GENERATE L1: 1000BASE-SX FULL FLOW CTRL: OFF NEGOTIATE: MANUAL LINK : DOWN CROSSOVER: MDIX RUN MODE: RX&TX STOP ACTION: OFF TX RATE: 0.000% RX RATE: 0.000% TX FRM/s: 0 RX FRM/s: 0 TX BIT/s: 0 RX BIT/s: 0 TX ERROR: 0 RX ERROR: 0 CRC ERROR: 0 UNDERSIZE: 0 OVER SIZE: 0 ALIGNMENT: 0 </pre> | <pre> COLLISION: 0 PAUSE Pkt: 0 TX BYTE: 0 RX BYTE: 0 TX FRAME: 0 RX FRAME: 0 IDLE MAX: 0.0µsec MIN: 0.0µsec AVG: 0.0µsec ALARM RX-FRAME/sec : DOWN RX-ERROR/CNT: UP TX-FRAME/CNT: UP </pre> |

Figure 4.2-9 Online screen 1 (Generate mode)

| | ONLINE | RUN |
|--|--|-----|
| | <pre> SET: Setup No01 TEST MODE: LATENCY L1: 1000BASE-SX FULL FLOW CTRL: OFF NEGOTIATE: MANUAL LINK : DOWN CROSSOVER: MDIX RUN MODE: RX&TX STOP ACTION: OFF TX RATE: 0.000% RX RATE: 0.000% TX FRM/s: 0 RX FRM/s: 0 TX BIT/s: 0 RX BIT/s: 0 TX ERROR: 0 RX ERROR: 0 CRC ERROR: 0 UNDERSIZE: 0 OVER SIZE: 0 </pre> | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

Figure 4.2-10 Online screen 2 (Latency mode)

Table 4.2-4 Item Display Location

| Item | Display location |
|--|------------------|
| Items common to all modes | Table 4.2-5 |
| Items common to the Generate and Latency modes | Table 4.2-6 |
| Ping mode item | Table 4.2-7 |
| Reply mode item | Table 4.2-8 |

Table 4.2-5 Display Contents Common to All Modes

| Display | Description |
|-----------|--|
| SET | Setup name used for measurement |
| TEST MODE | Test mode during measurement |
| L1 | Line type during measurement |
| FLOW CTRL | Transmission control on/off when receiving PAUSE frames |
| NEGOTIATE | Auto-negotiation on/off |
| LINK | Link status of Layer 1 during measurement |
| CROSSOVER | Indicates the current connector specification (CROSSOVER STATUS) of the measuring port for 10BASE-T, 100BASE-TX and 1000BASE-T as MDI (straight cable), MDIX (cross cable) and AUTO (auto-detect). For further details, see Section ***. |

NOTE

When the auto-negotiation operation is performed, FLOW CTRL is judged as follows.

10M/100M
FLOW CTRL support is determined only if the BaseLCW PAUSE bit is set to ON at either the local or remote end.

1000M
FLOW CTRL support is determined when the AE5501 judgment is "Symmetric" or "Asymmetric>Loac Device" as a result of negotiations.

Table 4.2-6 Items Common to the Generate and Latency Modes

| Display | Description |
|-------------|--|
| STOP ACTION | To indicate on/off of the test time setting |
| TX RATE | Transmitter's traffic rate per second |
| RX RATE | Receiver's traffic rate per second |
| TX FRM/S | Number of transmitted frames per second |
| RX FRM/S | Number of received frames per second |
| TX BIT/S | Number of transmitted bits per second |
| RX BIT/S | Number of received bits per second |
| TX ERROR | Total number of transmission errors |
| RX ERROR | Total number of reception errors |
| CRC ERROR | Number of received CRC errors |
| UNDERSIZE | Number of received undersize errors |
| OVERSIZE | Number of received oversize errors |
| ALIGNMENT | Number of received alignment errors Number of received symbol errors |
| COLLISION | Total number of collisions |
| PAUSE Pkt | Total number of received PAUSE packets |
| TX BYTE | Total number of transmitted bytes |
| RX BYTE | Total number of received bytes |
| TX FRAME | Total number of transmitted frames |
| RX FRAME | Total number of received frames |
| IDLE | Maximum/Minimum/Average idle time |
| ALARM | Alarm setting at the following values (applicable to Generate mode only) Received frames per second Number of transmitted frames Number of received error packets |
| DELAY | Delay time (applicable to Latency mode only) |

NOTE

A count isn't done as a receiving frame though an ARP reply frame is transmitted even if it faces the ARP request frame which is applicable to the filter condition. Don't do plugging in and out of the cable being connected to the measurement port during the transmission of the frame and the reception because it has the possibility that the transmission of the frame and reception can't be done properly any more.

Table 4.2-7 Ping Mode Items

| Display | Description |
|------------|---|
| SRC IP | IP address of the measuring port |
| DST IP | Transmitter IP address |
| SRC MAC | MAC address of the measuring port |
| TX MODE | Measurement termination condition |
| ARP RESULT | Displays the result of ARP processing |
| PING | Displays the latest 5 responses to Ping request |
| TX FRAME | Total number of transmitted frames |
| RX FRAME | Total number of received frames |
| LOSS CNT | Number of counts when there is no response to requests |
| LOSS RATE | LOSS CNT occurrence rate for the number of transmitted frames |

Table 4.2-8 Reply Mode Items

| Display | Description |
|------------------|--------------------------|
| PING REPLY TOTAL | Number of Ping responses |
| ARP REPLY TOTAL | Number of ARP responses |

Table 4.2-9 Key Functions (Online screen)

| Key | Description |
|-------|---------------------------------|
| POWER | Power on/off |
| ↑ | Screen scrolling |
| ↓ | |
| ← | Jump to the previous blank line |
| → | Jump to the next blank line |
| RUN | NA |
| STOP | Display the Offline screen |
| DISP | NA |
| ENTER | Pause and restart |
| UP | NA |
| DOWN | NA |

NOTE

The upper left display of the screen (shown as (3) in Figure 4.2-1) differs depending on the RUN modes. In the receive-only mode, "RUN" appears as a normal image and in the transmitting/receiving mode, "RUN" appears as a reversed image (light and shade are reversed).

When "RX->TX" is specified in the RUN mode, the chronological order of operations is as shown in the following chart:

R: Input by the RUN key
S: Input by the STOP key

```

    ---R---R-----S-----R----S-----S-----
    Reception and statistics +-----+
    Transmission           +-----+ +-----+
  
```

NOTE

OFFLINE statistical values of TX/RX RATE, FRM/S and BIT/S are as follows.

Operation before R03.10

When the measurement ends, the TX/RX Rate is registered. When the user operates PAUSE function while measuring, AE5501 registers the TX/RX Rate of that point in time.

- 1 When RUN and STOP occur within 1 second:


```
+-----+R---S--+-----+-----+-----+-----+
      All statistical values will be displayed as 0.
```
- 2 When there is one 1-second boundary between RUN and STOP:


```
+-----+R-----+S--+-----+-----+-----+-----+
      (1)          (2)
      All statistics will be registered with the values in (2).
```
- 3 When there is more than one 1-second boundary between RUN and STOP:


```
+-----+R-----+-----+-----+-----+S--+-----+
      (1)          (2)    (3)    (4)
      All statistics will be registered with the values in (4).
```

*TX/RX Rate, FRM/S, BIT/S are statistics of the same measurement interval.

Operation after R03.12

The peak TX/RX Rate while measuring are registered automatically.

| | | | | | | | |
|-----------|---|----|----|----|----|----|----|
| TxRate(%) | 0 | 20 | 80 | 80 | 80 | 30 | 10 |
| RxRate(%) | 0 | 40 | 30 | 50 | 70 | 40 | 50 |

As in the figure, when rate change, TX Rate, TX FRM/S, TX BIT/S are registered at the interval of 80%, RX Rate, RX FRM/S, RX BIT/S are registered at the interval of 70%.


Other operating conditions are as follows.

1. When link-speed is changed while measuring, the peak TX/RX rate which were registered are cleared. TX/RX rate which were registered by PAUSE function also cleared.
2. When Link-Down occurred while measuring, if link-speed is not changed after the Link-Up, the peak TX/RX rate which were registered are not cleared.

NOTE

Statistical data is added and displayed at 1-second intervals in the Generate and Latency modes.

If measurement is terminated using the STOP key, transmission/reception will end at the boundary of the next 1-second interval after keying in STOP. If a frame is not completely transmitted/received, transmission will be completed and measurement will end in the case of a transmission operation. The frame will be abandoned in the case of a receiving operation.



Transmission may start if the measurement operation is run before a link is fully established. Establish the link first and then run the measurement.

If the time exceeds that defined in TIME, an alarm will be generated and measurement will be automatically terminated.

If the number of counts is defined in the Ping mode, an alarm will be generated and measurement will be automatically terminated after the defined numbers of counts are transmitted and the time specified in INTERVAL TIME elapses.

If UP is selected in the alarm conditions, the alarm shall be effected at the point where the statistical value in question exceeds the threshold by ***. If DOWN is selected in the alarm conditions, the alarm shall be effected at the point where the statistical value in question falls below the threshold by ***.

Loop Back mode operations are based on the assumption that they are being used on full duplex lines.

NOTE

If a link is not established before you open the Online screen (or start measuring), the following message will be displayed. If you press OK, the measurement operation will begin without an established link.

Now Link Down
Continue?

CANCEL OK

If there are already 100 measurement results files at the time you open the Online screen (or start measuring), a delete confirmation screen will be displayed for the oldest file. If you press OK, the oldest file will be deleted and the measurement operation will begin.

File Count 100
Delete OK?

CANCEL OK

If measurement is completed within 1 second after starting, a new measurement results file will not be generated.

Measurement results will be saved as files at the time of measurement termination. Files will be named after the measurement termination time. (For example, if the measurement terminates at 12:34' 56" on June 30, 2002, the file name will be 020630123456.re).

NOTE

The ARP RESULT items shown on the PING screen are as follows.

| | | |
|--------------|---------|---|
| Acquired MAC | TARGET | Applies to equipment with IP address specified in DST IP |
| | GATEWAY | Applies to equipment with IP address specified in GATEWAY |
| MAC | | MAC address acquired by ARP process |

4.2.7 Off Select Screen

Choosing [FILE VIEW] on the Mode Select screen displays the Off Select screen. Up to 100 result files can be saved. Figure 4.2-13 shows the Off Select screen and Table 4.2-10 describes the functions of the keys.

| OFF SELECT | |
|------------|------------------|
| 1 | NEW FILE VIEW |
| | SETUP01: 10 FILE |
| | SETUP02: 15 FILE |
| | SETUP03: 20 FILE |
| | SETUP04: 10 FILE |
| | SETUP05: 15 FILE |
| 2 | SETUP06: 5 FILE |
| | SETUP07: 5 FILE |
| | SETUP08: 10 FILE |
| | SETUP09: 0 FILE |
| | SETUP10: 0 FILE |
| | FREE : 10 FILE |
| 3 | ALL DELETE |

Figure 4.2-13 Off Select screen

Table 4.2-10 Key Functions (Off Select Screen)

| Key | Description |
|-------|-------------------------------------|
| POWER | Power on/off |
| ↑ | To move the cursor |
| ↓ | To move the cursor |
| ← | NA |
| → | NA |
| RUN | NA |
| STOP | NA |
| DISP | To return to the Mode Select screen |
| ENTER | To change to the Setup screen |
| UP | NA |
| DOWN | NA |

- 1 Select [NEW FILE VIEW] and press the ENTER key to change to the Offline screen and display the latest results files.
- 2 Select FREE on Setup 01 and press the ENTER key to change to the File Select screen corresponding to the specified setup.
- 3 Press the ENTER key on [ALL DELETE] to delete all results files.

4.2.8 File Select Screen

This screen displays the results that have been measured under Setup Nos. 1–10 and the FREE settings. Figure 4.2.13 shows the File Select screen and Table 4.2-11 describes the functions of the keys.




Figure 4.2-14 File Select screen

- (a) This is the File Select initial screen.
- (b) This screen appears when you select [ALL DELETE] on (a).
- (c) This screen appears when you select [DELETE] on (a).

Table 4.2-11 Key functions (File Select screen)

| Key | Description |
|-------|--|
| POWER | Power on/off |
| ↑ | To move the cursor |
| ↓ | To move the cursor |
| ← | To move the cursor |
| → | To move the cursor |
| RUN | NA |
| STOP | NA |
| DISP | To return to the Off Select screen |
| ENTER | Pressing this key on a file name displays the Offline screen. Pressing this key on [ALL DELETE] or [DELETE] displays the respective screen. |
| UP | To change a display item. |
| DOWN | |

The following provides a description of the screen elements.

2 SETUP FILE

The name of the setup file is indicated. Any one of Setup Nos. 1–10 and the FREE settings will be displayed.

3 Number of files

The number of files of measurement results that were performed under a specified setup file name will be displayed in the form of “Current number of files/Total number of files.”

4 File name

The name of the results file will be displayed in the form of “Year (last 2 digits) / Month / Day / Hour / Minute / Second” when measurement is completed.

5 ALL DELETE button

Pressing this button will delete all results files generated under a specified setting.

6 DELETE button

Pressing this button will delete the currently specified results file.

4.2.9 OFFLINE Screen

This screen displays measurement results. Figure 4.2-15, Figure 4.2-16, Figure 4.2-17 and Figure 4.2-18 show examples of the Offline screen. For details of the display items, see Table 4.2-12. The functions of the keys are explained in Table 4.2-17.

An example of the Offline screen in the Generate mode is shown below.

| | OFFLINE | | STOP |
|---|---|--|------|
| <pre> VER:R02.04 NAME:020805195443.re SET:Setup_No01 TEST MODE:GENERATE L1:1000BASE-SX FULL FLOW CTRL:OFF NEGOTIATE:MANUAL LINK :DOWN CROSSOVER:MDIX RUN MODE:RX&TX STOP ACTION:OFF START TIME 2002/08/05 19:51:51 END TIME 2002/08/05 19:54:43 TX RATE: 0.000% RX RATE: 0.000% TX FRM/s:0 RX FRM/s:0 TX BIT/s:0 RX BIT/s:0 TX ERROR:0 RX ERROR:0 </pre> | <pre> CRC ERROR:0 UNDERSIZE:0 OVER SIZE:0 ALIGNMENT:0 COLLISION:0 PAUSE Pkt:0 TX BYTE: 0 RX BYTE: 0 TX FRAME: 0 RX FRAME: 0 IDLE MAX:0.0μsec MIN:0.0μsec AVG:0.0μsec ALARM RX-FRAME/sec :DOWN RX-ERROR/CNT:UP TX-FRAME/CNT:UP </pre> | | |

Figure 4.2-15 Offline screen 1 (Generate mode)

An example of the Offline screen in the Latency mode is shown below.

| | OFFLINE | STOP |
|----------------------|---------|-------------|
| VER:R02.04 | | |
| NAME:020805195443.re | | |
| SET:Setup_No01 | | |
| TEST MODE:LATENCY | | |
| L1:1000BASE-SX FULL | | |
| FLOW CTRL:OFF | | |
| NEGOTIATE:MANUAL | | |
| LINK :DOWN | | |
| CROSSOVER:MDIX | | |
| RUN MODE:RX&TX | | |
| STOP ACTION:OFF | | |
| START TIME | | |
| 2002/08/05 19:51:51 | | |
| END TIME | | |
| 2002/08/05 19:54:43 | | |
| TX RATE: 0.000% | | |
| RX RATE: 0.000% | | |
| TX FRM/s:0 | | |
| RX FRM/s:0 | | |
| TX BIT/s:0 | | |
| RX BIT/s:0 | | |
| TX ERROR:0 | | |
| RX ERROR:0 | | |
| | | CRC ERROR:0 |
| | | UNDERSIZE:0 |
| | | OVER SIZE:0 |
| | | ALIGNMENT:0 |
| | | COLLISION:0 |
| | | PAUSE Pkt:0 |
| | | TX BYTE: |
| | | 0 |
| | | RX BYTE: |
| | | 0 |
| | | TX FRAME: |
| | | 0 |
| | | RX FRAME: |
| | | 0 |
| | | IDLE |
| | | MAX:0.0μsec |
| | | MIN:0.0μsec |
| | | AVG:0.0μsec |
| | | DELAY |
| | | MAX:0.0μsec |
| | | MIN:0.0μsec |
| | | AVG:0.0μsec |

Figure 4.2-16 Offline screen 2 (Latency mode)

An example of the Offline screen in the Ping mode is shown below.

| | OFFLINE | STOP |
|--|---------|---|
| <pre> VER:R02.04 NAME:020805195443.re SET:FREE TEST MODE:PING L1:1000BASE-SX FULL FLOW CTRL:OFF NEGOTIATE:MANUAL LINK :DOWN CROSSOVER:MDIX START TIME 2002/08/05 19:51:51 END TIME 2002/08/05 19:54:43 SRC IP ADDR: 192.168.000.001 DST IP ADDR: 192.168.000.002 TX MODE:CONTINUE </pre> | | <pre> --- ARP Result --- Acquired MAC:TARGET 00-01-02-03-04-05 ----- TX FRAME :256 RX FRAME :254 LOSS CNT :2 LOSS RATE:0.673% ROUND TRIP TIME MAX:36083.0µsec MIN:76245.0µsec AVG:21233.4µsec </pre> |

Figure 4.2-17 Offline screen 3 (Ping mode)

Examples of the Offline screen in the Reply and Loop Back modes are shown below.

| | OFFLINE | STOP |
|---|---------|------|
| <pre> VER:R02.04 NAME:020805195443.re SET:FREE TEST MODE:REPLY L1:1000BASE-SX FULL FLOW CTRL:OFF NEGOTIATE:MANUAL LINK :DOWN CROSSOVER:MDIX START TIME 2002/08/05 19:51:51 END TIME 2002/08/05 19:54:43 PING REPLY TOTAL: 0 ARP REPLY TOTAL: 0 </pre> | | |

Reply mode

| | OFFLINE | STOP |
|--|---------|------|
| <pre> VER:R02.04 NAME:020805195443.re SET:FREE TEST MODE:LOOPBACK L1:1000BASE-SX FULL FLOW CTRL:OFF NEGOTIATE:MANUAL LINK :DOWN CROSSOVER:MDIX START TIME 2002/08/05 19:51:51 END TIME 2002/08/05 19:54:43 </pre> | | |

Loop Back mode

Figure 4.2-18 Offline screen 4 (Reply and Loop Back modes)

Table 4.2-12 Item Display Location

| Description | Display location |
|--|------------------|
| Items common to all modes | Table 4.2-13 |
| Items common to the Generate and Latency modes | Table 4.2-14 |
| Ping mode items | Table 4.2-15 |
| Reply mode item | Table 4.2-16 |

Table 4.2-13 Display Items Common to All Modes

| Display | Description |
|------------|--|
| VER | Current version information |
| NAME | Results file name |
| SET | Name of the setup used for measurement |
| TEST MODE | Test mode at the time of measurement |
| L1 | Line type when measurement ends (when the STOP key is pressed) |
| FLOW CTRL | Transmission control on/off when receiving PAUSE frames |
| NEGOTIATE | Auto-negotiation on/off |
| LINK | Status of Layer 1 link when measurement ends (when the STOP key is pressed) |
| CROSSOVER | Displays the connector specification (CROSSOVER STATUS) of the measuring port for 10BASE-T, 100BASE-TX and 1000BASE-T when measurement ends. |
| START TIME | Start time of measurement displayed in the form YY/MM/DD/HH/MM/SS. |
| END TIME | End time of measurement displayed in the form YY/MM/DD/HH/MM/SS. |

Table 4.2-14 Display Items Common to the Generate and Latency Modes

| Display | Description |
|-------------|---|
| STOP ACTION | To indicate on/off of the test time setting |
| TX RATE | Transmitter's traffic rate value at the time when measurement ends *1 |
| RX RATE | Receiver's traffic rate value at the time when measurement ends *1 |
| TX FRM/S | Number of transmitted frames at the time when measurement ends *1 |
| RX FRM/S | Number of received frames at the time when measurement ends *1 |
| TX BIT/S | Number of transmitted bits at the time when measurement ends *1 |
| RX BIT/S | Number of received bits at the time when measurement ends *1 |
| TX ERROR | Total number of transmission errors |
| RX ERROR | Total number of reception errors |
| CRC ERROR | Number of received CRC errors |
| UNDERSIZE | Number of received undersize errors |
| OVERSIZE | Number of received oversize errors |
| ALIGNMENT | Number of received alignment errors Number of received symbol errors |
| COLLISION | Total number of collisions |
| PAUSE Pkt | Total number of received PAUSE packets |
| TX BYTE | Total number of transmitted bytes |
| RX BYTE | Total number of received bytes |
| TX FRAME | Total number of transmitted frames |
| RX FRAME | Total number of received frames |
| IDLE | Maximum/Minimum/Average idle time |
| ALARM | Alarm setting at the following values (applicable to the Generate mode only) (1) Frames per second (2) Number of transmitted frames (3) Number of received error packets |
| DELAY | Delay time (applicable to the Latency mode only) |

*1: As an exception, however, statistical values at the time of PAUSE will be displayed if the PAUSE operation is run (input by ENTER key) while online.

NOTE

A count isn't done as a receiving frame though an ARP reply frame is transmitted even if it faces the ARP request frame which is applicable to the filter condition.

Table 4.2-15 Ping Mode Display Items

| Display | Description |
|-----------|---|
| SRC IP | IP address of the measuring port |
| DST IP | Transmitter IP address |
| SRC MAC | MAC address of the measuring port |
| TX MODE | Measurement termination condition |
| TX FRAME | Total number of transmitted frames |
| RX FRAME | Total number of received frames |
| LOSS CNT | Number of counts when there is no response to requests |
| LOSS RATE | LOSS CNT occurrence rate for the number of transmitted frames |

Table 4.2-16 Reply Mode Display Items

| Display | Description |
|------------------|--------------------------|
| PING REPLY TOTAL | Number of Ping responses |
| ARP REPLY TOTAL | Number of ARP responses |

Table 4.2-17 Key Functions (Offline screen)

| Key | Description |
|-------|-------------------------------------|
| POWER | Power on/off |
| ↑ | Screen scrolling |
| ↓ | |
| ← | To jump to the previous blank line |
| → | To jump to the next blank line |
| RUN | NA * |
| STOP | NA |
| DISP | To return to the File Select screen |
| ENTER | NA |
| UP | NA |
| DOWN | NA |

*If measurement is terminated, the Offline screen will be displayed. The RUN key is effective only on this particular Offline screen and measurement can be rerun immediately.


NOTE

OFFLINE statistical values of TX/RX RATE, FRM/S and BIT/S are as follows.

Operation before version R03.10


When the measurement ends, rate information is stored. When the user operated the PAUSE function while measuring, AE5501 store the rate information of that point in time.

1 When RUN and STOP occur within 1 second:



All statistical values will be displayed as 0.


2 When there is one 1-second boundary between RUN and STOP:



(1) (2)

All statistics will be registered with the values in (2).

3 When there is more than one 1-second boundary between RUN and STOP:



(1) (2) (3) (4)

All statistics will be registered with the values in (4).

*TX/RX Rate, FRM/S, BIT/S are become information of the same interval.

Operation since version R03.12

The peak rate information of TX and RX in while measuring is stored automatically.



As in the figure, when rate change, TX rate information is stored information at the time of 80%, RX rate information is stored information at the time of 70%.

Other operating conditions are as follows.

3. When circuit-speed is changed while measuring, AE5501 clears the peak rate information which was stored. AE5501 clears also the rate information which was stored by PAUSE function.
4. When Link-Down occurred while measuring, if circuit-speed after the Link-Up and circuit-speed before the Link-Down are same, AE5501 don't clear the peak rate information which is stored.

4.2.10 Setup Screen

This screen is used for editing the setup contents of the Generate and Latency modes. Press the ENTER key on an item that you want to edit on the Setup Select screen and the screen will be displayed. On this screen, you can edit items set up by the AE5730E TrafficTesterMini Setup Software.

Figure 4.2-19 shows a sample screen in the Generate mode and Figure 4.2-20 shows a sample screen in the Latency mode.




Figure 4.2-19 Setup screen in the Generate mode

| SETUP | |
|-----------------------------------|---------------------------------------|
| SET: Setup No10 | |
| TEST MODE: <u>LATENCY</u> | |
| <<<< RUN SETUP >>>> | |
| RUN MODE: <u>RX&TX</u> | |
| <<<< LINK SETUP >>>> | |
| L1: <u>1000BASE-SX FULL</u> | |
| FLOW CTRL: <u>OFF</u> | |
| NEGOTIATE: <u>MANUAL</u> | |
| CROSSOVER: <u>MDIX</u> | |
| <<<< TX SETUP >>>> | |
| TRANSMIT: <u>1000M</u> | |
| <u>Constant/Continue</u> | |
| IFG :% <u>100 00000</u> | |
| IDLE: bit <u>0000000000</u> | |
| CNT : frm <u>0000000001</u> | |
| STOP ACTION: <u>QN</u> | |
| TIME: <u>0001</u> min | |
| TX FRAME | |
| CNT: <u>4</u> | |
| FRM-PTN-1: | <input type="button" value="EDIT"/> |
| LEN: <u>0000</u> BYTE | |
| FRM-PTN-2: | <input type="button" value="EDIT"/> |
| LEN: <u>0000</u> BYTE | |
| FRM-PTN-3: | <input type="button" value="EDIT"/> |
| LEN: <u>0064</u> BYTE | |
| FRM-PTN-4: | <input type="button" value="EDIT"/> |
| LEN: <u>0100</u> BYTE | |
| <<<< RX SETUP >>>> | |
| FILTER1: <u>QN</u> | <input type="button" value="EDIT"/> |
| FILTER2: <u>QN</u> | <input type="button" value="EDIT"/> |
| FILTER INIT: <u>AND</u> | |
| OVERSIZE: <u>10000</u> | |
| ARP REPLY: <u>OFF</u> | |
| FIXED DELAY: <u>QN</u> | |
| <input type="button" value="OK"/> | <input type="button" value="CANCEL"/> |

Figure 4.2-20 Setup screen in the Latency mode

The following provides a description of the screen elements.

1 RUN SETUP

Select RX&TX or RX→TX as a measuring method when running the operation. Table 4.2-18 explains the display items and setup details. The upper left display of the screen (shown as (3) in Figure 4.2-1) differs depending on what mode it is running in. In the receive-only mode, “RUN” is displayed as a normal image and in the transmitting/receiving mode, “RUN” is displayed as a reversed image (light and shade are reversed).

Table 4.2-18 RUN Setting


| Display element | Description |
|-----------------|---|
| RUN MODE | Select RX&TX or RX->TX. RX&TX. When the RUN button is pressed, transmission and reception will start at the same time and when the STOP button is pressed, both will be terminated. RX→TX. When the RUN button is pressed once, only reception will start. When the button is pressed again, transmission will start also. When the STOP button is pressed once, transmission will end and when the button is pressed again, reception will terminate also. |

NOTE

When [RX→TX] is selected for the RUN mode, the chronological order of operations is as shown in the following chart:

R: Input by the RUN key

S: Input by the STOP key



2 LINK SETUP

This screen is used for setting up links. Table 4.2-19 explains the display items and setup details.

Table 4.2-19 Layer 1 Settings

| Display element | Description |
|-----------------|--|
| SET | Name of the setup used for measurement |
| TEST MODE | Indicates that it is in the test mode (the test mode cannot be changed) |
| L1 | Select the setup for line speed, communication method and interface from the following: 10BASE-T HALF, 10BASE-T FULL 100BASE-TX HALF, 100BASE-TX FULL 1000BASE-T/SX/LX FULL |
| FLOW CTRL | To select on/off of the flow control |
| NEGOTIATE | To select manual- or auto-negotiation |
| CROSSOVER | You can choose the connector specification (CROSSOVER STATUS) of the measuring port for 10BASE-T, 100BASE-TX and 1000BASE-T from MDI (straight cable), DIX (cross cable) and AUTO (auto-detect). For further details, see Section ***. |

**CAUTION**

If AUTO is selected, the line speed and duplex type you select will have the capability settings of auto-negotiation. For example, if you select AUTO for 100BASE-TX half duplex, the device will have three types of auto-negotiation capability such as 100BASE-TX half duplex, 10BASE-T half duplex and full duplex.

Interfaces to which you can switch from the auto-negotiation are as follows:

- 100BASE-TX.Full
- 100BASE-TX.Half
- 10BASE-T.Full
- 10BASE-T.Half

* Only 1,000 Mbps full duplex is available for all three 1000BASE-T, 1000BASE-SX and 1000BASE-LX.

If AUTO is selected for CROSSOVER, the connector specification (CROSSOVER STATUS) of the current measuring port for 10BASE-T, 100BASE-TX and 1000BASE-T will be displayed on the Setup DISP screen or Online screen.

Don't do plugging in and out of the cable being connected to the measurement port during the transmission of the frame and the reception because it has the possibility that the transmission of the frame and reception can't be done properly any more.



NOTE

If the following status is specified for L1 setting, you cannot save the setting. Check the currently implemented interface and settings.

| | |
|---------------|--|
| <L1 setting> | GBIC |
| 1 1000BASE-T | GBIC is implemented (SX or LX). |
| 2 1000BASE-SX | GBIC is not implemented or GBIC for LX is implemented. |
| 3 1000BASE-LX | GBIC is not implemented or GBIC for SX is implemented. |

<Messages to be displayed>

| | |
|--------------------------|-------------------------|
| When 1 is effected: | "Pull out GBIC module." |
| When 2 or 3 is effected: | "I/F mismatch" |

NOTE

Settings are made as follows when auto-negotiation=ON and FLOW CTRL=ON.

10M/100M electric interface

BaseLCW D10 is set to "1".

1000M electric interface

BaseLCW D10 and D11 are set to "1".

10M/100M optical interface (GBIC)

BasePage D7 and D8 are set to "1".

3 TX SETUP

This setting is the traffic condition (load factor) for the lines to be measured. The setup value will determine the load factor. For setup edits on the AE5501, IFG can be set up in bits and percentages and IDLE can be set up in bits only.

This is the setup for transmitting frames. Display items and setup details are as follows.

Table 4.2-20 Transmission Setup

| Display example | Description | |
|-----------------|--|--|
| TRANSMIT | To define the line speed for calculating IFG. Choose from 10 M, 100 M or 1000 M. | |
| Constant.Count | Choose the transmission method and the number of frames to transmit from the following: | |
| | Constant/Continue | This is a continuous transmission mode. Only the IFG setting is valid. |
| | Constant/Count | This is a continuous count transmission mode. Only IFG and Count settings are valid. |
| | Burst/Continue | This is a burst continuous transmission mode. Only IFG and IDLE settings are valid. |
| | Burst/Count | This is a burst count transmission mode. IFG, IDLE and Count settings are all valid. |
| IFG | To set up the value between frames. The setup range for IFG differs depending on the value of the line speed as shown below. In the case of 10 Mbps: 32 bits at minimum, 9999424 bits at maximum, the rate of change = 4 In the case of 100 Mbps: 32 bits at minimum, 99999424 bits at maximum, the rate of change = 4 In the case of 1000 Mbps: 32 bits at minimum, 999999424 bits at maximum, the rate of change = 32 | |
| IDLE | To set up the IDLE time. The setup range for IDLE differs depending on the value of the line speed as shown below. In the case of 10 Mbps: 32 bits at minimum, 2500000000 bits at maximum, the rate of change = 4 In the case of 100 Mbps: 32 bits at minimum, 2500000000 bits at maximum, the rate of change = 4 In the case of 1000 Mbps: 32 bits at minimum, 3125000000 bits at maximum, the rate of change = 32 | |
| CNT | The number of frames for transmission can be specified in the range from 1 to 4294967295 in decimal numbers. | |

NOTE

The receiver capability of this device cannot operate properly when the IFG value is specified below the following values:

- 10BASE-T.32 bits
- 100BASE-TX.48 bits
- 1000BASE-T.64 bits
- 1000BASE-LX/SX.32 bits

There are two kinds of IFG units: bit and percentage. The conversion formula between bit and percentage is as follows:

$$\% = (96 + 64 + \text{Average frame length (in bits)}) / (\text{IFG (in bits)} + 64 + \text{Average frame length (in bits)}) \times 100$$

The average frame length is defined as the average value of the number of registered frames.

4 STOP ACTION

This sets up the test time for the Generate and Latency modes. The setup items and details are as follows.

| Display item | Description |
|--------------|---|
| STOP ACTION | To select on/off of the test time setting |
| TIME | The test time can be specified in the range from 0001 to 1440 in decimal numbers. The unit is a "minute." |

5 TX FRAME

This sets up the frames to be transmitted. If you select the EDIT button displayed on the right of [FRM-PTN-1-4], the following screen will appear:

| | | |
|---------------------|-------|--------|
| | SETUP | STOP |
| LEN : 0064BYTE DIX | | |
| Dst MAC : MANUAL | | |
| 00-00-00-00-00-00 | | |
| Src MAC : MANUAL | | |
| 00-00-00-00-00-00 | | |
| VLAN Cnt : 1 | | |
| 1. TPID : 8100 UP:0 | | |
| CFI:0 ID : 0001 | | |
| L3 Type: IPv4 | | |
| Src IP: MANUAL | | |
| 000.000.000.000 | | |
| Dst IP: MANUAL | | |
| 000.000.000.000 | | |
| ToS: 000 | | |
| ERROR : NONE | | |
| OK | | CANCEL |

Figure 4.2-21 Frame Transmission Setup screen

The setup items and details are as follows.

Figure 4.2-22 TX FRAME SETUP 1

| Item | Subitem | Description |
|----------|---------|---|
| LEN | | To set up the frame length. This can be specified in the range from 26 to 9999 bytes. |
| Dst MAC | Address | Sets the address resolution results from the ARP process on the ARP screen. If the address is not resolved, "00-00-00-00-00-01" is set. |
| | MANUAL | This can be specified in the range from 0 to f in hexadecimal numbers. |
| | ARP | An address acquisition result by ARP on the ARP screen is established. |
| Src MAC | Address | To define the source MAC address. |
| | MANUAL | This can be specified in the range from 0 to f in hexadecimal numbers. |
| | GLOBAL | If GLOBAL is selected, a global MAC address that is specific to this device will be selected. |
| | DHCP | The SRC MAC value set on the DHCP screen is set. |
| VLAN Cnt | | Shows the number of stacks in VLAN tags. |
| TPID | | Shows the tag protocol ID in 4 hexadecimal numbers at maximum. |
| UP | | You can specify the user priority of each frame here. This can be specified in the range from 0 to 7 in decimal numbers. |
| CFI | | You can choose on/off of frame CFI. |
| ID | | You can specify the VLAN ID of each frame here. This can be specified in the range from 0 to 4095 in decimal numbers. |

Figure 4.2-23 TX FRAME SETUP 2

| Item | Subitem | Description |
|--------|---------|---|
| Type | | The kind of layer 3 protocol of the frame can be specified. It can be chosen only when it is made the one without MPLS and the one with IPHeader on the Frame builder of AE5730E. When a L3 protocol isn't established, it is indicated with "NONE", and it can't be chosen. |
| Src IP | Address | To define the source IP address. It can be edited only when the Type is IPv4 or IPv4 Multicast. |
| | MANUAL | This can be specified in the range from 0 to 10 in decimal numbers. |
| | DHCP | The SRC IP value set on the DHCP screen is set. If the address is not acquired by DHCP, 192.168.0.1 is set. |
| Dst IP | Address | This is the destination IP address. It can be edited only when the Type is IPv4. It will be fixed at "224.0.0.1" in the case of IPv4 Multicast. |
| | MANUAL | This can be specified in the range from 0 to 10 in decimal numbers. |
| | ARP | The Dst IP value set on the ARP screen is set. |
| ToS | | This is the ToS Field in IPv4 Header. It can be edited only when the Type is IPv4 or IPv4 Multicast. |
| ERROR | | You can select on/off of the CRC error addition. |
| OK | | Pressing OK saves the setup details and returns the display to the Setup initial screen (previous screen). |
| CANCEL | | Pressing CANCEL cancels the setup and returns the display to the Setup initial screen (previous screen). |

NOTE

Type indicates the type of L3 field (IP v4, IP v4-MC or IP v6) when there is an L3 field in the specified frame. However, "NONE" will be displayed in the following cases:

When there is no L3 field in the frame configuration even though IP v4, IP v4-MC or IP v6 is specified in the TYPE field (if the Auto Build is invalid).

For example, in the Frame Builder screen of the AE5730E shown as follows:

```
Frame Format. DIX
Auto Build. Invalid
TYPE. IPv4
```

It is indicated as follows though it can't be chosen when MPLS is specified with TYPE.

```
IPv4(MPLS)
IPv4-MC(MPLS)
IPv6(MPLS)
USER(MPLS)
```

6 RX SETUP

This is the field for setting received frames. Only those frames with a filter pattern defined here will be measured.

This is the field for setting the filter. Table 4.2-21 explains the display items and setting details.

Table 4.2-21 Filter Settings

| Display item | Description |
|--------------|---|
| FILTER1 | You can turn the setting of Filter 1 on or off. If you select ON, the EDIT button will appear to allow you to set the filter. |
| FILTER2 | You can turn the setting of Filter 2 on or off. If you select ON, the EDIT button will appear to allow you to set the filter. |
| FILTER INIT | You can select the operating condition for Filters 1 and 2 from AND or OR. |

If you select the EDIT button that appears when you choose ON for Filter 1 or 2, you can set the filter on the screen as shown in Figure 4.2-24.




Figure 4.2-24 Filter Setup screen

The meanings of the display items shown in Figure 4.2-24 are as follows.

Table 4.2-22 Filter Setting Details

| Display item | Description |
|--------------|--|
| OFFSET | The offset value can be specified in the range from 0 to 58 in decimal numbers. |
| LENGTH | The filter length can be specified in the range from 0 to 6. |
| PATTERN | Each digit of the filter pattern can be specified in the range from 0 to f in hexadecimal numbers. |
| MASK | Each digit of the mask pattern can be specified in the range from 0 to f in hexadecimal numbers. |
| OK | Pressing OK saves the setting details and returns the display to the Setup initial screen (previous screen). |
| CANCEL | Pressing CANCEL cancels the setting details and returns the display to the Setup initial screen (previous screen). |

7 OVER SIZE

This is the threshold value by which it is determined whether or not a received frame is oversized. Any received frame with a length exceeding the preset value will be determined as being oversized.

The threshold value can be specified in the range from 65 to 10000.

8 ARP REPLY

Selects ON/OFF for the ARP reply function. When an ARP request is received from a router or the like while the ONLINE screen is displayed, this function sends an ARP response without canceling measurement. The settings on the DHCP screen are used for the source MAC address and IP address required in the ARP response.

NOTE

A count isn't done as a receiving frame though an ARP reply frame is transmitted even if it faces the ARP request frame which is applicable to the filter condition.

When the following ARP request frame is received, the transmission of the ARP reply frame isn't done.

The ARP request frame which VLAN tag is added to.

The ARP request frame which MPLS label is added to.

The ARP request frame counted as an error frame.

The ARP request frame that length corresponds to either less than 63byte or beyond 1519byte, the setup value of the overcoat size.

9 ALARM (Generate mode only)

By defining the alarm condition for transmitted/received frames, you will be notified when a frame is transmitted and received by both a buzzer and screen display.

Conditions can be set for a specified threshold regarding the items described in Table 4.2-23.

Settings can also be made for the alarm. Display items and setup details are shown below.

Table 4.2-23 Alarm settings

| Item | Threshold | Conditions |
|------------|--|---|
| RX-FRM/S | The number of received frames per second can be specified in the range from 0 to 4294967295 (frames/s) in decimal numbers. | UP. Higher than the threshold DOWN. Lower than the threshold |
| ERROR CNT | The total number threshold of error counts in received frames can be specified in the range from 0 to 4294967295 in decimal numbers. | UP. Higher than the threshold *1 |
| TX-FRM CNT | The number of transmitted frames can be specified in the range from 0 to 4294967295 in decimal numbers. | UP. Higher than the threshold *1 |

1: Only UP can be specified.

10 FIXED DELAY

When AE5501 of the Latency mode and AE5501 of the Loop back mode are made to stand opposite to each other and an examination is done, it is set up whether the fixed delay time when Loop back treatment takes it is subtracted from delay statistics value on the AE5501 of the Latency mode and indicated.

OFF: The delay value indicated becomes value including the treatment time of Loop back.

ON: The delay value indicated becomes value except for the treatment time of Loop back.

4.2.11 Free Setup Screen

Press the ENTER key at PING, REPLY or LOOPBACK on the Mode Select screen to display the Free Setup screen. You can choose any one of Ping, Reply or Loop Back modes and make the settings for the selected mode.




Figure 4.2-25 Common Free Setup screens

The common items of the screens are shown below.

1 TEST MODE

Select a mode from PING, REPLY and LOOPBACK. When test mode is selected, the setting items for the respective test modes will be displayed.

2 L1

Select 10BASE-T, 100BASE-TX or 1000BASE-T/SX/LX and choose half duplex or full duplex. If you select 1000BASE-T/SX/LX as the interface, only full duplex can be used.

3 FLOW CTRL

Select On/Off for the flow control. The flow control is fixed to "OFF" in the Ping, Reply and Loop Back modes.

4 NEGOTIATE

Select manual- or auto-negotiation.

5 CROSSOVER

Select the connector specification (CROSSOVER STATUS) of the measuring port for 10BASE-T, 100BASE-TX and 1000BASE-T from MDI (straight cable), DIX (cross cable) and AUTO (auto-detect). For further details, see Section ***.

6 SRC MAC ADDR

Select GLOBAL or MANUAL for the MAC address of the measuring port.

If you select GLOBAL, a global MAC address that is specific to this device will be selected.

If you select MANUAL, each digit of the MAC address can be input from 0 to F in hexadecimal numbers.

If you select ALL, it copes with all MAC addresses. it can be chosen only at the time of the LOOPBACK mode.

If you select DHCP, the settings on the DHCP screen are applied.



CAUTION

If AUTO is selected, the line speed and duplex type you select will have the capability settings of auto-negotiation.

For example, if you select AUTO for 100BASE-TX half duplex, the device will have three types of auto-negotiation capability such as 100BASE-TX half duplex, 10BASE-T half duplex and full duplex.

Interfaces to which you can switch from the auto-negotiation are as follows:

100BASE-TX.Full
100BASE-TX.Half
10BASE-T.Full
10BASE-T.Half

* Only 1000 Mbps full duplex can be specified for all three 1000BASE-T, 1000BASE-SX and 1000BASE-LX.



NOTE

If the following status is specified for L1 setting, you cannot save the setting. Check the currently implemented interface and settings.

| | |
|---------------|--|
| <L1 setting> | GBIC |
| 1 1000BASE-T | GBIC is implemented (SX or LX). |
| 2 1000BASE-SX | GBIC is not implemented or GBIC for LX is implemented. |
| 3 1000BASE-LX | GBIC is not implemented or GBIC for SX is implemented. |

<Messages to be displayed>

| | |
|--------------------------|-------------------------|
| When 1 is effected: | "Pull out GBIC module." |
| When 2 or 3 is effected: | "I/F mismatch" |

4.2.11.1 When the TEST MODE is Ping

This function transmits Ping frames to specified IP addresses. This screen is used for specifying the settings of the Ping mode. Figure 4.2-26 shows the PING screen and Table 4.2-24 describes the functions of the keys.

| FREE SETUP | |
|------------|---------------------|
| | SETUP:FREE |
| | TEST MODE:PING |
| | L1:1000BASE-SX FULL |
| | FLOW CTRL:OFF |
| | NEGOTIATE:MANUAL |
| | CROSSOVER:MDIX |
| 1 | SRC MAC ADDR:MANUAL |
| | 01-02-03-04-05-06 |
| 2 | SRC IP: |
| | 192.168.000.001 |
| 3 | SUB NET MASK: |
| | 255.255.255.000 |
| | GATEWAY: |
| | 192.168.000.254 |
| | DST IP: |
| | 192.168.000.002 |
| | FRAME LEN:0064 |
| | INTERVAL:10SEC |
| | TX MODE:COUNT |
| | COUNT:0000000100 |
| | VLAN CNT:4 |
| | 1. TPID:8100 UP:3 |
| | CFI:0 ID:1000 |
| | 2. TPID:8100 UP:3 |
| | CFI:0 ID:1001 |
| | 3. TPID:8100 UP:3 |
| | CFI:0 ID:1002 |
| | 4. TPID:8100 UP:3 |
| | CFI:0 ID:1003 |
| | OK CANCEL |

Figure 4.2-26 PING screen

Table 4.2-24 Key Functions (PING screen)

| Key | Description |
|-------|--|
| POWER | Power on/off |
| ↑ | To move the cursor |
| ↓ | To move the cursor |
| ← | To move the cursor |
| → | To move the cursor |
| RUN | To change to the Online screen |
| STOP | NA |
| DISP | To return to the Mode Select screen |
| ENTER | 1 Displays the Mode Select screen when the cursor is pointing to [OK]. 2 Displays the Mode Select screen when the cursor is pointing to [CANCEL]. 3 With the exception of the above-mentioned two cases, it jumps to [OK]. |
| UP | To change numerical values and display items. |
| DOWN | |

The following provides a description of the screen elements.

1 SRC IP

Selects MANUAL or DHCP for the measurement port IP address.
 When MANUAL is selected, the measurement port IP address can be set with each digit in decimal notation in the range of 0 to 255.
 When DHCP is selected, the value set on the DHCP screen is displayed. If the IP address has not been acquired by DHCP, the display appears as follows.

| | |
|---------|----------------|
| SRC IP | 192.168. 0. 1 |
| SUBNET | 255.255.255. 0 |
| GATEWAY | 192.168. 0.254 |

2 SUBNET MASK

The measurement port subnet mask is displayed.
 When MANUAL is selected for SRC IP, the subnet mask can be set with each digit in decimal notation in the range of 0 to 255.
 When DHCP is selected for SRC IP, the value set on the DHCP screen is displayed. In this case, manual entry is not allowed.

3 GATEWAY

The measurement port gateway is displayed.
 When MANUAL is selected for SRC IP, the gateway can be set with each digit in decimal notation in the range of 0 to 255.
 When DHCP is selected for SRC IP, the value set on the DHCP screen is displayed. In this case, manual entry is not allowed.

4 DST IP

Each digit of the destination IP address can be specified in the range from 0 to 255 in decimal numbers.

5 FRAME LEN

The frame length can be specified in the range from 64 to 1518 (bytes) in decimal numbers. (The frame length can be specified up to 1534 bytes depending on the number of stacks of VLAN tags.)

6 INTERVAL

The transmission interval of pings can be specified at 1, 5 or 10 seconds.

7 TX MODE

Select Continue or Count for the transmission pattern of Ping signals. If you select Continue, Ping signals will be continuously transmitted. If you select Count, the number of transmitted Ping frames can be specified in the range from 1 to 4294967295. If the number of transmitted Ping frames reaches the specified value, measurement will be automatically terminated when the time specified at INTERVAL TIME elapses.

8 VLAN CNT

This indicates the number of stacks in VLAN tags. It can be specified between 0 and 4 and the VLAN setting increases or decreases depending on the value. TPID can be 0x0000 to 0x9999 in hexadecimal numbers, UP (User Priority) can be 0 to 7 in decimal numbers, CFI (Canonical Format Indicator) can be either 0 or 1 and ID (VLAN ID) can be 0 to 4095 in decimal numbers.

NOTE

IPv4 frames of DIX standards can be used in the Ping mode.

As shown below, the timeout value will be defined depending on the specified transmission interval of Ping frames. Jitter may occur in the transmission interval.

1 second: 800 msec

5 seconds: 4000 msec

10 seconds: 9000 msec

Fragmented ping and reply frames cannot be properly received.

4.2.11.2 When the TEST MODE is Reply

This screen is used for specifying the settings of the Reply mode. Figure 4.2-27 shows the Reply screen and Table 4.2-25 describes the functions of the keys.




Figure 4.2-27 Reply screen

Table 4.2-25 Key Functions (Reply screen)

| Key | Description |
|-------|--|
| POWER | Power on/off |
| ↑ | To move the cursor |
| ↓ | To move the cursor |
| ← | To move the cursor |
| → | To move the cursor |
| RUN | To return to the Online screen |
| STOP | NA |
| DISP | To change to the Mode Select screen |
| ENTER | 1 Displays the Mode Select screen when the cursor is pointing to [OK]. 2 Displays the Mode Select screen when the cursor is pointing to [CANCEL]. 3 With the exception of the above-mentioned two cases, it jumps to [OK]. |
| UP | To change numerical values and display items. |
| DOWN | |

The following provides a description of the screen elements.

1 SRC IP

Selects MANUAL or DHCP for the measurement port IP address.

If MANUAL is selected, the measurement port IP address can be set in the range of 0 to 255, with each digit in decimal notation.

If DHCP is selected, the settings on the DHCP screen are displayed. If an IP address has not been acquired using DHCP, "192.168.0.1" is displayed.

2 VLAN CNT

Specifies the number of VLAN stacks in the received PING. The maximum setting is four stacks.

3 CMP

Select the function of comparing of patterns of the VLAN tag field.

ON:comparison setting is enable.

OFF:comparison setting is disable.

4 VLAN Field

TPID can be 0x0000 to 0x9999 in hexadecimal numbers, and ID (VLAN ID) can be 0 to 4095 in decimal numbers.

NOTE

Only ARP and IPv4 frames of DIX standards can be handled in the Reply mode.

Ping frames for which the IP optional field is set as effective cannot be handled in the Reply mode.

It is not possible to correctly reply to fragmented Ping frames.

UP(UserPriority) and CFI(Canonical Format Indicator) is not included in the judgment condition to reply ping.

The reply process takes 10 to 60 msec.

4.2.11.3 When the TEST MODE is Loop Back

This screen is used to specify the settings for the Loop Back mode. Figure 4.2-28 shows the Loop Back screen and Table 4.2-26 describes the functions of the keys.




Figure 4.2-28 Loop Back screen

Table 4.2-26 Key Functions (Loop Back screen)

| Key | Description |
|-------|--|
| POWER | Power on/off |
| ↑ | To move the cursor |
| ↓ | To move the cursor |
| ← | To move the cursor |
| → | To move the cursor |
| RUN | To change to the Online screen |
| STOP | NA |
| DISP | To return to the Mode Select screen |
| ENTER | 1 Displays the Mode Select screen when the cursor is pointing to [OK]. 2 Displays the Mode Select screen when the cursor is pointing to [CANCEL]. 3 With the exception of the above-mentioned two cases, it jumps to [OK]. |
| UP | To change numerical values and display items. |
| DOWN | |

The screen contents are presented below.

1 LOOPBACK

Sets whether the received frame loopback operation is to check just the MAC address, or check both the MAC address and IP address. MAC or MAC+IP is selected. When MAC or MAC+IP is selected, "SRC IP", "VLAN CNT", and "ARP REPLY" are displayed.

NOTE

The following frames are not subject to the loop back function.

- Frames with a length of 63 bytes or less

- Broadcast frames

- Multicast frames

CRC error frames will be looped back as CRC error frames.

2 SRC IP

MANUAL or DHCP is selected. Details of both are presented below.

When MANUAL is set, the IP address is set in the range of 0 to 255 for each digit. If the destination IP address in the received frame matches this setting, the received frame is looped back.

When DHCP is set, the information set in the DHCP screen is displayed. If an IP address has not been acquired using DHCP, then "192.168.0.1" is displayed.

3 VLAN CNT

The number of VLAN tag stacks in the received frame is set in the range of 1 to 4.

4 ARP REPLY

The operating condition for an ARP REPLY to an ARP request in LOOPBACK mode is selected as ON or OFF.

NOTE

A count isn't done as a receiving frame though an ARP reply frame is transmitted even if it faces the ARP request frame which is applicable to the filter condition.

When the following ARP request frame is received, the transmission of the ARP reply frame isn't done.

- The ARP request frame which VLAN tag is added to.

- The ARP request frame which MPLS label is added to.

- The ARP request frame that length corresponds to either less than 63byte or beyond 1519byte, the setup value of the overcoat size.

4.2.12 DHCP Screen

This screen is used to enter settings required to acquire a measurement port IP address using DHCP. The screen is shown in Figure 4.2-29, and the key operations are shown in Table 4.2-29.

| | DHCP | STOP |
|--|------|------|
| <<<< LINK SETUP >>>> | | |
| L1:10BASE-T FULL | | |
| NEGOTIATE : <u>AUTO</u> | | |
| CROSSOVER : <u>AUTO</u> | | |
| <<<< ADDR INFO >>>> | | |
| SRC MAC: <u>MANUAL</u> | | |
| 00-00-00-00-00-01 | | |
| SRC IP: <u>AUTO</u> | | |
| 192.168.000.001 | | |
| SUBNET MASK: | | |
| 255.255.255.000 | | |
| GATEWAY: | | |
| 192.168.000.254 | | |
| <input type="checkbox"/> OK <input type="checkbox"/> CANCEL <input type="checkbox"/> DHCP <input type="checkbox"/> ARP | | |

Figure 4.2-29 DHCP Screen

The following provides a description of the screen elements.

1 LINK SETUP

Table 4.2-27 DHCP Screen Settings 1

| Display element | Description |
|-----------------|--|
| L1 | Select the setup for line speed, communication method and interface from the following: 10BASE-T HALF, 10BASE-T FULL 100BASE-TX HALF, 100BASE-TX FULL 1000BASE-T/SX/LX FULL |
| NEGOTIATE | To select manual- or auto-negotiation |
| CROSSOVER | You can choose the connector specification (CROSSOVER STATUS) of the measuring port for 10BASE-T, 100BASE-TX and 1000BASE-T from MDI (straight cable), DIX (cross cable) and AUTO (auto-detect). |

2 ADDR INFO Settings

Table 4.2-28 DHCP Screen Settings2

| Display | Display description |
|-------------|---|
| SRC MAC | Global or Manual is selected. If Global is selected, the Global MAC address unique to the measurement port on this instrument's side is set. If Manual is selected, the value can be set with each digit in HEX notation in the range of 00 to ff. |
| SRC IP | Manual or Auto is selected. If Manual is selected, the value can be set with each digit in decimal notation in the range of 0 to 255. If Auto is selected, the value acquired by DHCP is displayed. If no value has been acquired by DHCP, then "" is displayed. |
| SUBNET MASK | When MANUAL is selected for SRC IP, the value can be set with each digit in decimal notation in the range of 0 to 255. When Auto is selected for SRC IP, the value acquired by DHCP is displayed. If no value has been acquired by DHCP, then "" is displayed. |
| GATEWAY | When MANUAL is selected for SRC IP, the value can be set with each digit in decimal notation in the range of 0 to 255. When Auto is selected for SRC IP, the value acquired by DHCP is displayed. If no value has been acquired by DHCP, then "" is displayed. |

Table 4.2-29 Key Functions (DHCP Screen)

| Key | Description |
|-------|--|
| POWER | Power on/off |
| ↑ | To move the cursor |
| ↓ | To move the cursor |
| ← | To move the cursor |
| → | To move the cursor |
| RUN | NA |
| STOP | NA |
| DISP | Applies the changes to the ADDR INFO settings and returns to the Mode Select screen. |
| ENTER | <p>If the cursor is over [OK], pressing ENTER applies the changes to the ADDR INFO settings and displays the Mode Select screen.</p> <p>If the cursor is over [CANCEL], pressing ENTER cancels the changes to the ADDR INFO settings and displays the Mode Select screen.</p> <p>If the cursor is over [DHCP], the measurement port address is acquired using DHCP.</p> <p>If the cursor is over [ARP], the changes to the ADDR INFO settings are applied and the ARP screen is displayed.</p> |
| UP | To change numerical values and display items. |
| DOWN | |

NOTE

When IP address acquisition is performed using DHCP, the lease limit is not monitored. Requests from the DHCP server are not responded to except during DHCP protocol processing. Note that if an IP frame containing an IP address with an expired lease limit is sent to the network, a network failure may occur.

If "DHCP" is selected in the address settings on the SETUP screen or FREE screen without address acquisition by DHCP being completed on the DHCP screen, the following addresses will be selected.

| | |
|---------|----------------|
| SRC IP | 192.168. 0. 1 |
| SUBNET | 255.255.255. 0 |
| GATEWAY | 192.168. 0.254 |

The ARP button is displayed and can be selected under the following conditions:

- (a) When SRC IP is MANUAL
- (b) When SRC IP is AUTO and DHCP address acquisition is completed

If "ARP REPLY=ON" is set in the GENERATE/LATENCY mode measurement condition settings, the "SrcMAC" and "SrcIP" set on the DHCP screen will be used.

4.2.13 ARP Screen

This screen is used to enter settings for acquiring measurement target MAC addresses using ARP. It is shown in Figure 4.2-30.




Figure 4.2-30 ARP Screen

The following provides a description of the screen elements.

1 ARP SETUP

Table 4.2-30 ARP Screen Settings 1

| Display | Displayed item | Display description |
|---------|----------------|--|
| DST IP | Address | This is the location for setting the IP address of the target device whose MAC address is to be acquired. The value can be set in the range of 0 to 255, with each digit in decimal notation. |
| DST MAC | Address | The MAC address acquired using ARP is displayed. "*" is displayed prior to acquisition of the MAC address of the target device. |
| | TARGET | Indicates that ARP resolution to the target device has been performed in the same network. |
| | GATEWAY | Indicates that ARP resolution to the gateway has been performed because it was determined that the target device was not present in the same network. The displayed DSTMAC address is the gateway MAC address. |

Table 4.2-31 Key Function(ARP Screen)

| Key | Description |
|-------|--|
| POWER | Power on/off |
| ↑ | To move the cursor |
| ↓ | To move the cursor |
| ← | To move the cursor |
| → | To move the cursor |
| RUN | NA |
| STOP | NA |
| DISP | Applies the changes to the ARP Screen and returns to the Mode Select screen. |
| ENTER | <p>If the cursor is over [OK], pressing ENTER applies the ARP screen value and displays the Mode Select screen.</p> <p>If the cursor is over [CANCEL], pressing ENTER cancels the ARP screen value and displays the Mode Select screen.</p> <p>If the cursor is over [ARP], MAC address acquisition for the measurement target is performed using ARP.</p> |
| UP | To change numerical values and display items. |
| DOWN | |

NOTE

ARP operations are performed in the following sequence. Each broadcast is repeated three times. If there is no correct reply, the next process is performed.

Broadcast (destination IP is target terminal)

Broadcast (destination IP is gateway)

Time-out (ARP resolution failure)

4.2.14 MACRO Screen

4.2.14.1 Outline

With this function, a measurement operation is specified with a special command (macro command) prior to measurement, and measurement is performed automatically. The MACRO screen can be displayed by selecting [MACRO] on the MODE SELECT screen.

Figure 4.2-31 shows a sample screen.




Figure 4.2-31 MACRO Screen

Table 4.2-32 Key Function(MACRO Screen)

| Key | Description |
|-------|--|
| POWER | Power on/off |
| ↑ | To move the cursor |
| ↓ | To move the cursor |
| ← | To move the cursor |
| → | To move the cursor |
| RUN | NA |
| STOP | NA |
| DISP | Applies the changes to the MACRO Screen and returns to the Mode Select screen. |
| ENTER | Displays utility box |
| UP | Switches macro command and subparameters (numerical values and items) |
| DOWN | |

A macro command overview list is presented below.


Table 4.2-33 MACRO Function Commands

| Command | Command overview |
|---------|--|
| RUN | Equivalent to RUN key function. |
| STOP | Equivalent to STOP key function. |
| WAIT | Continues the command-preceding WAIT for the specified length of time. The value can be set in the range of 0001 and 3600 seconds. |
| SEL | Specifies the measurement condition file. SETUP01 through SETUP10 and FREE can be selected. |
| GOTO | Executes the command at the specified line. The value is set in the range of 00 to 49. |
| END | Ends the macro operation. |
| ; | Displays command non-entry status. Under the default setting, all command lines are set to semicolons. |

4.2.14.2 Macro command edit function

A macro command is entered by moving the cursor to the desired line with the UP/DOWN arrow keys, then selecting the required command with the UP/DOWN keys.

A maximum of 50 lines (0 to 49) can be entered. It is not always necessary for macro commands to be adjacent to each other.




In addition, some macro commands require sub-parameters. When sub-parameters are displayed, move the cursor and use the UP/DOWN keys to select an item or value.



4.2.14.3 Utility box operations

Utility operations can be selected on the MACRO screen.

The utility box is displayed when the ENTER key is pressed on the MACRO screen.



The utility box functions are presented below.

1 CANCEL

Cancels the utility box operation and returns to the MACRO screen.

2 LINE INSERT

Inserts a blank line at the line where the cursor is located. When this is done, all commands registered on the cursor line and following lines are moved downward. However, if the 49th line contains a macro command other than a semicolon, an error message ("Disable Insert") is displayed and the line is not inserted.

In addition, inserting a blank line updates the go-to line which is a sub-parameter of the GOTO command.

3 LINE DELETE

Deletes the line where the cursor is located. When this is done, all commands registered on the cursor line and following lines are moved upward. In addition, a semicolon is set on the 49th line. In addition, inserting a blank line updates the go-to line which is a sub-parameter of the GOTO command.

4 SAVE CLOSE

Saves all the currently edited macro commands (lines 0 through 49) and goes to the MODE SELECT screen.

This function is equivalent to the DISP key on the MACRO screen.

5 CANCEL CLOSE

Cancels all the currently edited macro commands (lines 0 through 49) and goes to the MODE SELECT screen.

6 ALL CLEAR

Clears all the currently edited macro commands (lines 0 through 49).

4.2.14.4 Executing macro operations

There are two methods for executing operations registered on the MACRO screen:
Input the RUN key on the MACRO screen.
Move the cursor to "MACRO" on the MODE SELECT screen and input the RUN key.

Immediately prior to operation execution, a WAIT command sub-parameter check is performed. If a value is out of range, calibration is performed automatically and the macro is executed.

Calibration is performed as follows:

- If the sub-parameter is set to 0, then it is calibrated to 1.
- If the sub-parameter exceeds 3600, then it is calibrated to 3600.

4.2.14.5 During macro operations

1 Screen Transition

During macro operations, the screen changes according to the MACRO command which is being executed.

The relationship between screen changes and MACRO commands during macro operations is shown below.




Figure 4.2-32 Screen changes during MACRO operations

2 Display

During macro operations, an icon indicating that a macro operation is being executed is displayed. The following figure shows the MODE SELECT screen during macro operations.




Figure 4.2-33 During MACRO operations

During macro execution, the macro command which is being executed is shown on the message bar. In addition, a MACRO FINISH message is displayed on the message bar when macro execution ends.

ONLINE RUN

TX RATE :100.000%

RX RATE :100.000%

TX FRM/s:148810

RX FRM/s:148810

TX BIT/s:

RX BIT/s:

TX ERROR:

RX ERROR:

MACRO EVENT:WAIT

Message bar

| Message | Description |
|------------------|------------------------|
| MACRO EVENT:RUN | Executing RUN command |
| MACRO EVENT:STOP | Executing STOP command |
| MACRO EVENT:WAIT | Executing WAIT command |
| MACRO EVENT:SEL | Executing SEL command |
| MACRO EVENT:GOTO | Executing GOTO command |
| MACRO EVENT: END | Executing END command |
| MACRO FINISH | End of macro operation |

3 Key Functions

The function of the key during macro operations screen is shown in the following.

Table 4.2-34 Key Function(during MACRO operations)

| Key | Description |
|-------|-----------------------------|
| POWER | NA |
| ↑↓←→ | To move the cursor |
| RUN | NA |
| STOP | Aborts the macro operation. |
| DISP | NA |
| ENTER | |
| UP | |
| DOWN | |

4.2.14.6 End of macro operations

Macro command operations end under the following conditions.

When the END command is executed.

When the STOP key is input during a macro operation.

When an I/F mismatch occurs at the start of measurement with the RUN command.

When macro operations end, a macro operation log can be viewed.

For details, see 4.2.15.

4.2.14.7 MACRO commands details

Macro command details are presented below.

1 RUN command

(a)Function

Performs an operation equivalent to inputting the RUN key.

(b)Format

RUN

There are no sub-parameters.

(c)Description of operation

The operation varies as shown below, depending on the current screen and RUN MODE.

| Screen | RX&TX | RX->TX Reception in progress | RX->TX Sending/reception in progress |
|-----------------------|--------------------|------------------------------------|--|
| ONLINE screen | Not valid | Starts sending | Not valid |
| MODE SELECT screen | Starts measurement | | |
| OFFLINE screen | Starts measurement | | |


For information on
RUN MODE, see
4.2.101.

When RUN MODE is RX&TX

When a RUN command is accepted while measurement is stopped, measurement is started.

When a RUN command is accepted during measurement, it is disabled and the command at the next line is executed.


The relationship between command acceptance and log message output is shown below.



When RUN MODE is RX→TX

When a RUN command is accepted while measurement is stopped, the statistics operation is started. When another RUN command is accepted during the statistics operation, the sending operation is started. When a RUN command is accepted during the sending operation, it is disabled and the command at the next line is executed.

The relationship between command acceptance and log message output is shown below.



At the start of measurement, the following check is performed. If there is a mismatch, the user is notified by a popup message. However, during macro operations the user is not notified; if a mismatch occurs, processes are performed automatically and a log of the results is output. The automatic processes performed when a mismatch occurs are shown below.

I/F check

If an I/F which cannot be executed is set, the macro operation is cancelled. The following combinations cannot be executed.

| L1 setting | I/F status |
|-------------|--------------------------------|
| 1000BASE-SX | 1000BASE-SX GBIC not installed |
| 1000BASE-LX | 1000BASE-LX GBIC not installed |
| 1000BASE-T | GBIC installed |

The log output is "@I/F-NG".

Result file count check

If there are already 100 result files, the oldest file is deleted and the RUN process is continued. The log output is "@100FILE".

Link status check

Even if the link is down in the link status check, the RUN process is continued. The log output when a link is down is "@LINK-DOWN". The log output when a link is up is "@LINK-UP".

(d)Screen display

If the RUN command is executed while measurement is stopped (MODE SELECT/OFFLINE screen), the screen changes to the ONLINE screen. If the ONLINE screen is already displayed, it remains displayed

2 Stop command

(a)Function

Performs an operation equivalent to inputting the STOP key.

(b)Format

STOP

There are no sub-parameters.

(c)Description of operation

The operation varies as shown below, depending on the current screen and RUN MODE.


| Screen | RX&TX | RX->TX Reception in progress | RX->TX Sending/reception in progress |
|--------------------|-------------------|------------------------------------|--|
| ONLINE screen | Stops measurement | Stops measurement | Stops sending |
| MODE SELECT screen | Not valid | | |
| OFFLINE screen | Not valid | | |

For information on RUN MODE, see 4.2.101.

When RUN MODE is RX&TX

When a STOP command is accepted while measurement is in progress, measurement is stopped. When a STOP command is accepted while measurement is stopped, it is disabled and the next command is executed.


The relationship between command acceptance and log message output is shown below.



When RUN MODE is RX→TX

When a STOP command is accepted during frame transmission, the transmission operation is stopped. When another STOP command is accepted while only the statistics operation is performed, measurement is stopped. When a STOP command is accepted while measurement is stopped, it is disabled and the next command is executed.

The relationship between command acceptance and log message output is shown below.



(d)Screen display

If the STOP command is executed while measurement is stopped (MODE SELECT/OFFLINE screen), the operation is not valid, so the screen does not change. If the ONLINE screen is displayed, it remains displayed when transmission is stopped, and changes to the OFFLINE screen when measurement is stopped.

3 WAIT command

(a)Function

Performs the wait process in increments of seconds.

(b)Format

WAITXXXX

XXXX takes a value in the range of 1 to 3600.

(c)Description of operation

Performs a wait process between macro commands.

The setting range is 1 to 3600 seconds.

A log is output when the WAIT command is executed.

The log message is "WAIT:XXXX" (where XXXX is a value equivalent to the setting).

Note that the maximum error for a setting of 3600 seconds is approximately ± 10 seconds.

(d)Screen display

The screen does not change even when the WAIT command is executed.

4 SEL command

- (a)Function
Loads the specified setting.
- (b)Format
SEL XXXX
XXXX is as follows.

| Selection | Description | Selection | Description |
|-----------|---------------------|-----------|-----------------------------|
| SETUP01 | SETUP No. 1 setting | SETUP07 | SETUP No. 7 setting |
| SETUP02 | SETUP No. 2 setting | SETUP08 | SETUP No. 8 setting |
| SETUP03 | SETUP No. 3 setting | SETUP09 | SETUP No. 9 setting |
| SETUP04 | SETUP No. 4 setting | SETUP10 | SETUP No. 10 setting |
| SETUP05 | SETUP No. 5 setting | FREE | PING/REPLY/LOOPBACK setting |
| SETUP06 | SETUP No. 6 setting | | |

SETUP Nos. 1 through 10 are setups in which GENERATE mode or LATENCY mode can be selected.
 FREE is a setup in which PING mode, REPLY mode, or LOOPBACK mode can be selected.

- (c)Description of operation
 This command is specified before the RUN command to select measurement conditions.
 A log is output when the SEL command is executed.
 The log message is "SEL:XX" (where XX is a value equivalent to the setting).
 Note that the SEL command is not valid in ONLINE. In such cases, the log message is "SEL:VOID".
- (d)Screen display
 The screen changes to the MODE SELECT screen only when the SEL command is executed on the OFFLINE screen. The screen does not change when the command is executed on other screens.

5 GOTO command

- (a)Function
Jumps to the specified line.
- (b)Format
GOTO XX
XX takes the range of 0 to 49.
- (c)Description of operation
Moves the execution position to the specified line.
The range is 0 to 49.
A log is output when the GOTO command is executed.
The log message is "GOTO:XX" (where XX is a value equivalent to the setting).
- (d)Screen display
The screen does not change even when the GOTO command is executed.

6 END command

- (a)Function
Ends the macro operation.
- (b)Format
END
There are no sub-parameters.
- (c)Description of operation
Ends the macro execution.
The macro operation ends when the END command is executed, even if another command is registered subsequent to the END command.
If there is no END command on the macro registration screen, the macro operation is ended when the 49th line ends. (This applies only in cases where the 49th line is not a GOTO command.)
A log is output when the GOTO command is executed.
The log message is "END". In addition, "MACRO FINISH" is displayed on the message bar, indicating that the macro operation has ended.
- (d)Screen display
The screen does not change even when the END command is executed.

7 ; command (NOP command)

- (a)Function
None
- (b)Format
;
- (c)Description of operation
The line is blank. The program advances to the next line.
- (d)Screen display
The screen does not change.

4.2.15 LOG VIEW Screen

4.2.15.1 Outline

This screen is used to check the macro command operation history after macro operations are performed. The currently saved log information is overwritten each time a macro operation is executed.

The LOG VIEW screen can be displayed by selecting [LOG VIEW] on the MODE SELECT screen. If there is no macro operation log, this screen cannot be displayed.

| | LOG VIEW | STOP |
|----------|------------|-------|
| 12:34:56 | SEL | :0001 |
| 12:34:58 | WAIT | :0002 |
| 12:34:59 | RUN | :RX |
| 12:35:10 | @LINK-DOWN | |
| 12:35:13 | @LINK-UP | |
| 12:35:20 | WAIT | :0010 |
| 12:35:21 | RUN | :TX |
| 12:35:31 | WAIT | :0010 |
| | | |

Figure 4.2-34 LOG VIEW Screen

Table 4.2-35 Key Function(LOG VIEW Screen)

| Key | Description |
|-------|-------------------------------------|
| POWER | Power on/off |
| ↑↓ | To move the cursor |
| ← → | |
| RUN | NA |
| STOP | |
| DISP | To return to the Mode Select screen |
| ENTER | |
| UP | NA |
| DOWN | |


4.2.15.2 Display

A description of the LOG VIEW screen display is presented below.

A single event corresponds to a single line. Individual events are divided into a macro command start time and a message.

The macro command execution time is the time at which macro command execution starts.

Messages may be a log based on a macro command or another type of log. See the next section for details.



4.2.15.3 Message types

1 A message toward the MACRO commands

An END command message is always displayed at the end of a log if there is no END command on the macro screen, or if the macro operation is aborted using the STOP key.

| Macro command | LOG output message | Output condition |
|---------------|--------------------|---|
| RUN | RUN:RX | Reception operation is started under the measurement condition RUN MODE = RX->TX. |
| | RUN:TX | Sending operation is started under the measurement condition RUN MODE = RX->TX. |
| | RUN:RX&TX | RUN command is executed under the measurement condition RUN MODE = RX&TX. |
| | RUN:VOID | Additional RUN command is executed while sending or reception is already under way. |
| STOP | STOP:RX | Reception operation is stopped under the measurement condition RUN MODE = RX->TX. |
| | STOP:TX | Sending operation is stopped under the measurement condition RUN MODE = RX->TX. |
| | STOP:RX&TX | Measurement is stopped under the measurement condition RUN MODE = RX&TX. |
| | STOP:VOID | STOP command is executed in state other than ONLINE. |
| WAIT | WAIT:XXXX | WAIT command is executed. XXXX is the setting (decimal notation). |
| SEL | SEL:XXXX | SEL command is executed. XXXX is 0001 to 0010 or FREE. |
| | SEL:VOID | SEL command is executed during ONLINE. |
| GOTO | GOTO:XX | GOTO command is executed. XX is 00 to 49. |
| END | END | END command is executed. |

2 Other messages

In addition to the above messages corresponding to macro commands, the following system messages represent measurement operations.

System messages always start with an at sign (@).

Table 4.2-36 System messages

| LOG output message | Output condition |
|--------------------|--|
| @CNT-TXEND | Completion of transmission of the specified number of frames with the transmission mode for GENERATE/LATENCY measurement set to [Constant/Count] or [Burst/Count]. |
| @LINK-DOWN | Link failure during ONLINE. |
| @LINK-UP | Link recovery during ONLINE. |
| @ARP-MISS | ARP processing during PING measurement not completed. |
| @I/F-NG | RUN command is executed with respect to a setting file that cannot be executed. Example: An attempt to execute a setting file in which "1000BASE-SX FULL" is set in "L1" without a GBIC inserted. |
| @100FILE | Measurement is executed using the RUN command while there are 100 result files. Indicates that the oldest result file has been deleted. |
| @LOAD ERR | Setting file loading error has occurred. |
| @STOP ACT | Completion of STOP ACTION operation during GENERATE/LATENCY measurement. |
| @ABORT END | Macro operation is manually aborted using STOP key. |

4.2.16 Remote Setup Screen

There are three different modes, depending on the usage objective:

Use in exchanging settings and measurement results with AE5730E →See 4.2.16.1

Use in upgrading the AE5501 system files →See 4.2.16.2

Remote control of AE5501 from PC using TELNET →See 4.2.16.3

The function of the key in the Setup screen is as mentioned in the following table.

| Key | Description |
|-------|---|
| POWER | Power on/off |
| ↑↓←→ | To move the cursor |
| RUN | NA |
| STOP | |
| DISP | Applies the changes and returns to the Mode Select screen. |
| ENTER | Pressing this key on a OK displays the Remote screen. Pressing CANCEL cancels the setup and returns the display to the Mode Select screen. Pressing this key on a GET ADDR, an IP address, a subnet mask, a gateway are acquired. |
| UP | To change numerical values and display items. |
| DOWN | |

4.2.16.1 Remote Screen

Press the OK button after selecting REMOTE for MODE and complete all settings. The device will be able to communicate data to the AE5730E-installed PC. Pressing the STOP button after completion of the remote operation returns the display to the Mode Select screen. Figure 4.2-35 shows an example of the Reply screen.




Figure 4.2-35 Remote screen

1 MODE

You can select the operation mode on the screen.

REMOTE: This mode is used for transferring setup files or measurement results files.

VERUP: This mode is used for upgrading the system version.

2 IP ADDR SET

This sets the IP address of the device's remote port as MANUAL or AUTO. You can specify the IP address yourself by choosing MANUAL. If AUTO is selected, (5) will appear.

3 SUBNET MASK

You can set each digit of the subnet mask value of the device's remote port in the range from 0 to 255 in decimal numbers by choosing MANUAL in (2). You cannot set the subnet mask if you select AUTO in (2).

4 GATEWAY

You can set each digit of the gateway value of the device's remote port in the range from 0 to 255 in decimal numbers by choosing MANUAL in (2).

5 GET ADDR

This will appear if you select AUTO in (2). Pressing the GET ADDR button while the device's remote port is connected to a LAN with its DHCP server running automatically sets up the IP address, subnet mask and gateway.

6 FTP

It is selection of the FTP data transmission port by the side of a FTP server (AE5501 side). "PASS" serves as a port number higher than 1024, and "ACT" performs FTP data transmission by No. 20 fixation.

NOTE

If an L1 link of the remote port cannot be established when the Remote screen is displayed, the following message will appear.

Specify the network settings after selecting OK. If AUTO is selected for IP ADDR SET, the request will be sent to the DHCP server immediately. Depending on the DHCP server setups, the IP address displayed on the Remote Setup screen may differ from that displayed on the Remote or VerUP screen. In this case, remotely connect to the IP address displayed on the Remote or VerUP screen.

It becomes 0.0.0.0 when GATEWAY address value can't reflect in the system.

Pressing the ENTER key on the following screen returns the display to the Remote Setup screen. Be sure to try displaying the Remote screen again when you have connected the cable to the remote port and the L1 link is established.

Set Remote Cable
[ENTER] & Retry
OK

4.2.16.2 VerUP Screen

MODE is made VERUP, and it becomes the condition that version upgrading is accepted by pushing OK button. Confirm that the following screen was indicated, and do upgrade work from AE5730E TrafficTesterMini Setup Software.

Be careful of the upgrade standing by screen because it varies in the version of the system. And, the one except for "POWER key" doesn't work with the key of the AE5501 TrafficTesterMini in the upgrade screen. Start AE5501 TrafficTesterMini in the following method again after you finish an upgrade.

- (a) A POWER key is pushed for more than one second, and (in the case of R02.01) PowerLED pushes a POWER key after it turns off the lights.
- (b) A POWER key is pushed after an AC adapter is plugged in and out once.
- (c) A POWER key is pushed in the case of the battery drive after it opens and closes a battery cover behind AE5501 once.




Figure 4.2-36 VerUP screen of R02.01 or earlier releases

- (a) This selection screen is used to run the device in the remote mode. Specify version-upgrade-related settings on this screen. Pressing the OK button displays (b). For setup details, see Section 4.2.12 "Remote Screen".
- (b) This screen is used to confirm the version upgrade. Pressing the CANCEL button returns the display to screen (a) and pressing the OK button changes the display to screen (c).
- (c) This screen is used to wait for the version upgrade. Version upgrading is possible only while this screen is displayed.
- (d) This screen is displayed when version upgrading is completed. When this screen appears, press the POWER key for the required time to power off the device.

2 VerUP screen of R02.04 or later releases




Figure 4.2-37 VerUP screen of R02.04 or later releases

- (a) This selection screen is used to run the device in the remote mode. Specify version-upgrade-related settings on this screen. Pressing the OK button displays (b). For setup details, see Section 4.2.12 "Remote Screen".
- (b) This screen is used to confirm the version upgrade. Pressing the CANCEL button returns the display to screen (a) and pressing the OK button changes the display to screen (c).

- (c) This screen is used to wait for the version upgrade. Version upgrading is possible only while this screen is displayed. Make sure that this screen is displayed and then upgrade the version of AE5730E TrafficTesterMini Setup Software.
- (d) This screen is used to confirm the progress of version upgrading. Do not attempt to turn off the power while this screen is displayed.
- (e) This screen is used to indicate that the version upgrade is completed. The system will automatically shut down about 12 seconds after this screen appears. When the shutdown procedure is completed, the Power LED will light up and the LCD will turn off. To reboot the device, unplug the AC adapter and then plug it in again if it is powered by AC supply. Open and close the battery housing cover on the reverse side of the main body if the power is supply by battery.

| | |
|--|---|
| NOTE | |
| <p>When the screen shown in Figure 4.2-36(d) appears after completion of the version upgrade, power off the device and then power it on again.</p> <p>If an L1 link of the remote port cannot be established when the Remote screen is displayed, the following message will appear.</p> <p>Pressing the ENTER key on the following screen returns to the Remote Setup screen. Be sure to try displaying the Remote screen again after you have connected the cable to the remote port and the L1 link is established.</p> | |
| <table border="1"><tr><td>Set Remote Cable [ENTER] & Retry OK</td></tr></table> | Set Remote Cable [ENTER] & Retry OK |
| Set Remote Cable [ENTER] & Retry OK | |

| |
|--|
| NOTE |
| <p>If an error occurs during version upgrading of R02.04 or later releases, an error message will be displayed for 5 seconds and the display will return to (c) of the VerUP screen as shown in Figure 4.2-37. After confirming that this screen is displayed, retry the version upgrading procedure.</p> <p>It is possible for the procedure to take the maximum 5 minutes at State 06 during version upgrading of R02.04 or later releases. Do not turn off the power.</p> |

4.2.16.3 TELNET Screen

Set the MODE to TELNET and press the OK button after entering the individual settings. The MODE SELECT screen will be displayed and operations can be controlled through TELNET. This section only describes operations on the AE5501 side. For details on TELNET remote control operations on the PC side, see 4.3 TELNET remote control.

When TELNET is chosen with MODE, the setup of PROMPT and PASSWD DELETE becomes possible.

A screen example is shown in Figure 4.2-38.




Figure 4.2-38 The condition that it waits for the control

1 PROMPT

When TELENET control is done from the outside terminal, it becomes the designation of PROMPT indicated in the terminal. When it is specified for off, PROMPT becomes only ">".

The length of the character line which can be specified as PROMPT is to eight characters.

Each character can use an English letter except for the space and a number. (A character from 0x21 of ASCII code to 0x7E.)

It can't be set up when the space is specified in PROMPT character line.

But, specify the space in the right end when you make the number of characters less than seven characters.

2 PASSWD DELETE

It is the function which erases the password which is necessary for the SU command of TELNET.

(The settlement of the password uses a passwd command.)

It is usually a setup of off. Turn it on, and choose an "OK" button only when you forget a password.

4.2.17 Self Test Screen

This screen is used to set up operation validation testing of the device. Figure 4.2-39 shows the Self Test screen and Table 4.2-37 describes the functions of the keys.

This device's self-testing function consists of the following three stages:

TEST1: Read/write check of the CompactFlash

TEST2: Transmitting memory check

TEST3: PHY operations check




Figure 4.2-39 Self Test screen

Each screen shown in Figure 4.2-39 is outlined below.

- (a) This is the Self Test standby screen.
- (b) This screen is displayed while the self-test is running.
- (c) This screen shows the results.
- (d) This screen shows the results.

Table 4.2-37 Key Functions (Self Test screen)

| Key | Description |
|-------|--|
| POWER | Power on/off |
| ↑ | NA |
| ↓ | NA |
| ← | To change items |
| → | To change items |
| RUN | NA |
| STOP | NA |
| DISP | To return to the Mode Select screen. |
| ENTER | 1 Runs self-testing when the cursor is pointing to [START]. 2 Displays the Mode Select screen when the cursor is pointing to [END]. |
| UP | NA |
| DOWN | NA |

The following provides a description of the screen elements.

2 Test result

The self-test results of the device will be shown here.

3 START button

This button is used to start the self-testing.

4 END button

This button is used to display the Mode Select screen.

5 STOP button

This is button is used to stop the self-testing.

NOTE

All LEDs blink while the self-test is running.



CAUTION

Ensure that the device is disconnected from any lines to be measured (or that no cables are connected to the measuring port) when you run self-testing. Failure to follow this caution may result in adverse affects to the lines to be measured.



4.2.18 Time Set Screen

The timer can be set on the Time Set screen. Figure 4.2-40 shows the Time Set screen and Table 4.2-38 describes the functions of the keys.




Figure 4.2-40 Time Set screen

Table 4.2-38 Key Functions (Time Set screen)

| Key | Description |
|-------|---|
| POWER | Power on/off |
| ↑ | To move the cursor |
| ↓ | To move the cursor |
| ← | To move the cursor |
| → | To move the cursor |
| RUN | NA |
| STOP | NA |
| DISP | Settings will be established and the display will return to the Mode Select screen. |
| ENTER | 1 Changes to the Mode Select screen after saving the setup details when the cursor is pointing to [OK]. 2 Changes to the Mode Select screen after canceling the setup details when the cursor is pointing to [CANCEL]. |
| UP | To change numerical values. |
| DOWN | |

The following provides a description of the screen elements.

1 Year

Input the last two digits of the year in decimal numbers. Table 4.2-39 shows the setting range.

2 Month

Input the month in decimal numbers. Table 4.2-39 shows the setting range.

3 Day

Input the day in decimal numbers. Table 4.2-39 shows the setting range.

4 Hour

Input the hour in decimal numbers. Table 4.2-39 shows the setting range.

5 Minute

Input the minute in decimal numbers. Table 4.2-39 shows the setting range.

6 Second

Input the second in decimal numbers. Table 4.2-39 shows the setting range.

Table 4.2-39 Setting Range

| Item | Range |
|--------|-------|
| Year | 00–19 |
| Month | 01–12 |
| Day | 01–31 |
| Hour | 00–23 |
| Minute | 00–59 |
| Second | 00–59 |

7 CANCEL button

Cancels the settings and changes the display to the Mode Select screen.

8 OK button

Establishes the settings and changes the display to the Mode Select screen.

NOTE

The Time Set items are retained by a built-in battery, which would be impossible to achieve if the battery is dead. When the battery life expires, call our Customer Service Division regarding replacement service, the cost of which is charged to the user. To replace the internal battery, the device itself must be sent to the division.

4.2.19 ALL DEFAULT Screen

This screen is used to check the disk for the CompactFlash built into the AE5501. After checking the disk, the setup files will be initialized and all result files will be deleted. Use this function if system errors frequently occur.




Figure 4.2-41 ALL DEFAULT screen

Table 4.2-40 Key functions (ALL DEFAULT screen)

| Key type | Description |
|----------|---|
| POWER | Power on/off |
| ↑ | NA |
| ↓ | NA |
| ← | To move the cursor |
| → | To move the cursor |
| RUN | NA |
| STOP | NA |
| DISP | To return to the Mode Select screen. |
| ENTER | 1 Runs the ALL DEFAULT function when the cursor is pointing to [OK]. 2 Changes the display to the Mode Select screen when the cursor is pointing to [END]. |
| UP | NA |
| DOWN | |

Each screen shown in Figure 4.2-41 is outlined below.

- (a) This is the initial screen. Point the cursor to [START] and press the ENTER key to run the ALL DEFAULT function.
- (b) This shows that the ALL DEFAULT function is running. Pressing the ENTER key stops the function.
- (c) This shows the processing results of the ALL DEFAULT function. To exit the screen, press the DISP key or point the cursor to [END] and press the ENTER key.

Items to be processed are described below.

FILE SYSTEM

This checks the file system of the CompactFlash. If a damaged file is found, it will be automatically deleted (including a system file).

If the AE5501 does not boot up after running the ALL DEFAULT function, perform the recovery operation. (For further details, see Section 5.5.2 "Recovery Mode.")

SETUP DEFAULT

This initializes the setup files.

RESULT DEFAULT

This deletes all result files.

Repeat this function several times if NG is indicated as a processing result.

4.3 TELNET remote control


This section describes AE5501 remote control using TELNET. TELNET remote control of the AE5501 is a function which allows the AE5501 to be remotely controlled through a PC or the like using TELNET. TELNET commands are used to control operations. A list of TELNET commands is shown in the table below.

Table 4.3-1 TELNET commands

| Function name | Commands | Details |
|------------------------------------|------------------|------------|
| Super user command | su | Page 4-119 |
| End remote control | quit or exit | Page 4-121 |
| Start measurement | run | Page 4-122 |
| Stop measurement | stop | Page 4-123 |
| Check status | status | Page 4-125 |
| Change measurement condition | select | Page 4-127 |
| Display measurement condition list | setlist | Page 4-128 |
| Change setting | set | Page 4-129 |
| Check setting | display | Page 4-136 |
| Display measurement results | result | Page 4-140 |
| Display result file list | list | Page 4-146 |
| Delete result file | delete or remove | Page 4-148 |
| Display version | version | Page 4-151 |
| Self test | selftest | Page 4-152 |
| Set date/time | datetime | Page 4-153 |
| Display date/time | datetime | Page 4-154 |
| Set all defaults | init | Page 4-155 |
| Upgrade version | versionup | Page 4-156 |
| AE5730 remote control | remote | Page 4-157 |
| Performs DHCP | dhcp | Page 4-158 |
| Performs ARP | arp | Page 4-159 |
| Set prompt | prompt | Page 4-161 |
| Set password | passwd | Page 4-160 |
| Command history list | history | Page 4-162 |
| Help | help or ? | Page 4-163 |
| Script commands | | Page 4-165 |

4.3.1 TELNET Basic remote control procedure

The basic flow of TELNET remote control operations is as follows.



4.3.1.1 Preparation

Prepare for remote control operations.

1 The confirmation of cable connections

Remote control operations may be performed in a variety of connection configurations. Check whether all of the cable connections are OK.

Remote control cannot be performed simply by connecting a remote line to the AE5501 measurement port. The remote line must be connected to the remote port located on the right side of the unit.




Figure 4.3-1 Basic illustration of connections for remote control

2 A setup of a network of AE5501 and the controller

See 4.1.5Connecting to an AE5730E-installed PC for information on various network settings.

3 Terminal software settings

Prepare the remote control terminal software on the controller. The “Hyperterminal” application or “TELNET” application is normally installed as a standard feature on Windows operating systems.

Select “VT100” as the terminal software emulation mode.

4.3.1.2 Starting remote control

The following procedure is required to start remote control.

1 Preparation for the TELNET connection

Select "TELNET" as the "MODE" item on the AE5501 REMOTE SETUP screen, then select "OK" or press the DISP key.

After this, the screen automatically changes to the MODE SELECT screen. On the MODE SELECT screen, the AE5501 is ready for a TELNET connection. At this time, all keys other than the UP/DOWN keys and the STOP key are disabled. (The STOP key is used to abort TELNET control.)




Figure 4.3-2 TELNET Connection Ready State

The item indicated on the TELNETMODE screen is shown in the following.

- (a) IP ADDR
The IP address of remote port confirmed on the REMOTE SETUP screen is indicated.
- (b) PROMPT
A REMOTESETUP screen or PROMPT set up with the PROMPT command during the TELNET control is indicated.

(c) CURRENT SETUP

SETUP chosen at present is indicated.

2 A TELNET connection from the controller which terminal software was used for

After confirming that the AE5501 is ready, start the TELNET connection through the terminal software on the controller.

Following is an example of a connection using the HyperTerminal that is provided as a standard feature in Windows 2000.

(a) Start terminal software

From the Windows Start menu, select "Run", then type "hypertrm.exe" and click "OK". The IP address indicated on the MODE SELECT screen of AE5501 is inputted to `***.***.***.***`.




Figure 4.3-3 Starting the terminal software (example)




Figure 4.3-4 Terminal software (TELNET) startup screen

(b) Specifying the destination IP address and Connection Settings
From the terminal software menu bar, select “File” → “Properties”.





Figure 4.3-5 Connection settings screen

For “Host address”, enter the IP address shown on the AE5501 MODE SELECT screen. Set “Connect using” to “TCP/IP [Winsock]”, and set “Emulation” to “VT100”.

4.3.1.3 Log in

When the TELNET connection is completed in the terminal connection, you will be prompted to enter a login name and password.




Figure 4.3-6 Log in screen

Enter "ttmini" in lower case for both the login name and password. If login is successful, the screen appears as shown below.




Figure 4.3-7 Log in complete screen

If the login or password is incorrect, you will be prompted to reenter them on this screen. Note that the TELNET connection will be disconnected if they are entered incorrectly three times in a row. If ttmini has already been used to login from another terminal, the following message appears and the TELNET connection is disconnected. (**Login from multiple terminals is not allowed**)




Figure 4.3-8 Message appearing when the same login name has already been used

NOTE

When the network is down during the fixed time, "AE5501" has the possibility to keep maintaining the TELNET session.

In case that, Enter "clear" in lower case for both the login name and password.
If login is successful, All Telnet session that AE5501 in keeping is released.

4.3.1.4 Remote control

The AE5501 is not remotely controlled as soon as login is completed. It is the condition (the USER mode) that only a setup and the indication of the result can be carried out. The current connection status can be determined using the “status” command.

To change to control status, enter the “su” command. This activates control status, making it possible to perform various actions, such as executing and stopping measurement, displaying and editing measurement conditions, and displaying and deleting measurement results. For information on command types, see 4.3.2 TELNET commands.

The following diagram shows the transition to control status using the su command.




Figure 4.3-9 Change to control mode

Please note the following points which pertain to TELNET command input.

- 1 The key which is effective in input of a TELNET command.
 - (a) Alphanumeric/symbol keys
 - (b) [Esc] key (used to stop a script which is in progress; the cancellation of the input when a script is not being executed)

2 A precaution in the case of input of a TELNET command.

The TELNET command input format is as follows.

[Command] [Sub-command] [Parameter]:[Sub-parameter]=[Value]

example) >set setup01 link:L1=10BASE-T_FULL

| | | | | | | | |
|-----|-----|-----|---------|-----|---------|-----|---------------|
| (a) | (b) | (c) | (d) | (e) | (f) | (g) | (h) |
| > | set | | setup01 | | link:L1 | = | 10BASE-T_FULL |

(a) This is the prompt display.

(b) This is the command.

(c) This is a space. Be sure to enter spaces between the command and sub-command, and between the command and parameter.

(d) Sub-command (may be omitted)

(e) This is a space. Be sure to enter spaces between the sub-command and parameter.

(f) Parameter and sub-parameter. The entry in this case means "Item L1 of LINK settings group".

(g) This is a symbol for entering a value.

(h) This is the value being registered. It may consist of a character string or a numerical value (DEC or HEX).

TELNET commands are also valid in abbreviated form.

Example >display setup03 tx_frame1:vlan1

>disp 3 tf1v1

There is no distinction between upper case and lower case in half-size alphanumeric characters entered for [Command], [Sub-command] and [Parameter].

>SET SetuP01 Link:L1=10Base-t_Full

>sEt sETUp01 liNK:l1=10baSE-T_fuLL

If a pound sign (#) is entered at the beginning, the line is treated as a comment line and no action is taken.

3 Input support function.

The following function is assigned to key input as a support function of input of a command.

| Key | Function |
|----------------------------------|--|
| ↑↓ | The history of the command is indicated. Maximum history for 50 lines can be kept. |
| PageUp,PageDown ctrl+N,ctrl+B | Item switching of the sub-command, the sub-parameter, the setup value. |

A PageUp/PageDown may not be able to be used by the terminal software.

Do item switching by using "ctrl+N", "ctrl+B" in that case.

4.3.1.5 Ending remote control

To end remote control, enter “quit” or “exit” at the prompt. Doing so automatically disconnects the TELNET connection. When this happens, the AE5501 is maintained in the TELNET connection ready state.

To start another TELNET connection, set the AE5501 to the TELNET mode reception state.




Figure 4.3-10 End remote control

NOTE

To finish remote control, use a completion command, or cut terminal software.

Try to do a connection again after it passes for about 10 seconds when you connect TELNET again.

Be sure to set up the AE5501's own TELNET mode again when remote cable comes out during the TELNET connection.

The re-setup of the TELNET mode is done with the following process.

- (a) Push the stop key of AE5501.
- (b) Change a screen on the REMOTE SETUP screen, and choose TELNET.
(Refer to 4.3.1.2 Starting remote control)

A TELNET session is cut when the re-setup of the TELNET mode is done during the TELNET connection.

4.3.2 TELNET commands

This section describes the TELNET commands used to remotely control the AE5501. The individual transmission contents may or may not be available for input depending on the conditions. Table 4.3-2 and Table Table 4.3-3 present lists of conditions under which each TELNET command may or may not be entered.

Table 4.3-2 Commands in normal input mode

| Function name | Commands | AE5501 and PC connected | | | | | | | |
|-------------------------------------|------------------------|---|-------------------|-----------------|--------|--|-------------------|-----------------|--------|
| | | As soon as login is completed - USER - | | | | After input of a su command - ADMIN - | | | |
| | | Condition of AE5501 | | | | Condition of AE5501 | | | |
| | | OFFLINE | ONLINE RX only | ONLINE RX&TX | REMOTE | OFFLINE | ONLINE RX only | ONLINE RX&TX | REMOTE |
| Super user | <u>su</u> | OK | OK | OK | OK | NO | NO | NO | NO |
| Remote control stop | <u>quit(exit)</u> | OK | OK | OK | OK | OK | OK | OK | OK |
| Measurement start | <u>run</u> | NO | NO | NO | NO | OK | OK | NO | NO |
| Measurement stop | <u>stop</u> | NO | NO | NO | NO | NO | OK | OK | OK |
| Status check | <u>status</u> | OK | OK | OK | OK | OK | OK | OK | OK |
| Change measurement condition | <u>select</u> | NO | NO | NO | NO | OK | NO | NO | NO |
| Display measurement conditions list | <u>set list</u> | OK | OK | OK | NO | OK | OK | OK | NO |
| Change settings | <u>set</u> | NO | NO | NO | NO | OK | NO | NO | NO |
| Setting check | <u>display</u> | OK | OK | OK | NO | OK | OK | OK | NO |
| Display measurement results | <u>result</u> | OK | OK | OK | NO | OK | OK | OK | NO |
| Display results file list | <u>list</u> | OK | OK | OK | NO | OK | OK | OK | NO |
| Delete results file | <u>delete (remove)</u> | NO | NO | NO | NO | OK | NO | NO | NO |
| Display version | <u>version</u> | OK | OK | OK | OK | OK | OK | OK | OK |
| Self test | <u>selftest</u> | NO | NO | NO | NO | OK | NO | NO | NO |
| Set time/date | <u>datetime</u> | NO | NO | NO | NO | OK | NO | NO | NO |
| Display time/date | <u>datetime</u> | OK | OK | OK | OK | OK | OK | OK | OK |
| Set all defaults | <u>init</u> | NO | NO | NO | NO | OK | NO | NO | NO |
| Version upgrade | <u>versionup</u> | NO | NO | NO | NO | OK | NO | NO | NO |
| AE5730E remote control | <u>remote</u> | NO | NO | NO | NO | OK | NO | NO | NO |
| Performs DHCP | <u>dhcp</u> | NO | NO | NO | NO | OK | NO | NO | NO |
| Performs ARP | <u>arp</u> | NO | NO | NO | NO | OK | NO | NO | NO |
| Set password | <u>passwd</u> | NO | NO | NO | NO | OK | OK | OK | NO |
| Set prompt | <u>prompt</u> | NO | NO | NO | NO | OK | OK | OK | NO |
| Command history list | <u>history</u> | OK | OK | OK | OK | OK | OK | OK | OK |
| Help | <u>help(?)</u> | OK | OK | OK | OK | OK | OK | OK | OK |

NO: Cannot be executed (Error message is displayed.)

OK: Execution is possible while connected or in the operating state. However, execution may not be possible depending on the combination of measurement conditions. If execution is not possible, an error message is displayed.

Table 4.3-3 Script commands

| Function name | | Commands | USER authority | ADMIN authority | | | |
|---------------|--------------------|-----------|----------------|---------------------|-----------|--------|--------|
| | | | | Condition of AE5501 | | | |
| | | | | OFFLINE | ONLINE RX | ONLINE | REMOTE |
| Script | Start registration | Shell | OK | OK | OK | OK | OK |
| | End registration | shellend | OK | OK | OK | OK | OK |
| | Display program | shellview | OK | OK | OK | OK | OK |
| | Execute script | shellgo | OK | OK | OK | OK | OK |
| | Wait | wait | OK | OK | OK | OK | OK |
| | Start loop | loop | OK | OK | OK | OK | OK |
| | End loop | loopend | OK | OK | OK | OK | OK |

NO: Cannot be executed (Error message is displayed.)

OK: Execution is possible while connected or in the operating state. However, execution may not be possible depending on the combination of measurement conditions. If execution is not possible, an error message is displayed.

4.3.2.1 Su (Super user) command

It is the command to change the authority of the TELNET movement.
Authority condition is as the following.


| | |
|-------|--|
| USER | The state immediately after login Only a setup and the indication of the result are possible. |
| ADMIN | Setup and the indication of the result. Change settings, measurement executive control, Delete results Self test, time setting, default AE5730E remote, version up setting |

A SU command is effective only in the case of USER authority. When a su command is accepted, authority is changed from USER to ADMIN. It can't be changed to USER authority from ADMIN authority. SETUP01 is chosen under the condition that a Su command is inputted as a measurement condition.

1 Command input

A password is inputted after the su command when settlement of a password of the ADMIN authority change is done.

The password of the authority change can be set up by inputting a PASSWD command under the ADMIN condition.



2 An effect effect-less condition with the command input

Refer to Table 4.3-2

3 Screen example

During normal operation, nothing is displayed and the system waits for the next command.

```
>su  
>
```

It is inputted as follows when a password is set up.


```
>su 12345  
>
```

If, when a password is forgotten, "PASSWD DELETE" of the AE5501's own REMOTE SETUP screen is set up in on, and a password can be erased.

4.3.2.2 QUIT (Remote control stop) command

This command is used to cancel remote control by a controller terminal and enable direct control on the AE5501 unit. When remote control is ended by the QUIT command, the TELNET command ready state on the AE5501 is also cleared. To start remote control again, set the AE5501 to the TELNET command ready state, then use the connect command.

1 Command input



2 An effect effect-less condition with the command input Refer to Table 4.3-2

4.3.2.3 RUN (Measurement start) command

The function of this command is like that of the [RUN] key on the AE5501.

The "RUN MODE" setting in the measurement conditions (see 4.2.101 on page 4-52 for details on "RUN MODE") determines the particular operation which is performed after the RUN command is entered.

"RUN MODE"=RX->TX

-> Only reception starts when ">run" is entered. When ">run" is entered again, transmission and reception start.


"RUN MODE"=RX&TX

-> When ">run" is entered, transmission and reception start.

Even if a link fails when measurement starts, the measurement is started anyway.

If measurement is started while there are more than 100 measurement result files, the oldest file is deleted before measurement starts.

1 Command input



2 An effect effect-less condition with the command input

Refer to Table 4.3-2

3 Screen example

During normal operation, nothing is displayed and the system waits for the next command.

```
>run
Please Wait...
>
```

4.3.2.4 STOP (Measurement stop) command

The function of this command is like that of the [STOP] key on the AE5501.

The "RUN MODE" setting in the measurement conditions (see 4.2.101 on page 4-52 for details on "RUN MODE") determines the particular operation which is performed after the STOP command is entered.

"RUN MODE"=RX->TX


-> Only transmission is stopped when ">stop" is entered while sending/reception is in progress. When ">stop" is entered again, measurement is stopped.

"RUN MODE"=RX&TX

-> When ">stop" is entered, measurement is stopped.

If this command is executed while an AE5730E control command (see 4.3.2.19) is being used, the AE5730E control command is cancelled.

1 Command input




2 An effect effect-less condition with the command input

Refer to Table 4.3-2

3 Screen example

During normal operation, nothing is displayed and the system waits for the next command.



The following screen is displayed if the command is executed while the AE5501 is OFFLINE.




The following screen is displayed while the AE5730 control command is being cancelled.

```
>stop  
>
```

4.3.2.5 STATUS (Status check) command

This command is used to display the current AE5501 operating status, the selected measurement conditions, etc.

1 Command input



2 An effect effect-less condition with the command input

Refer to Table 4.3-2

3 Screen example

The contents indicated by input of a command are as mentioned in the bottom table.

Table 4.3-4 Contents of indication 1/2

| Overview | Screen display | Description |
|---|-------------------|--|
| Connection statuses | USER (Read Only) | It is shown that it is USER authority. |
| | ADMIN (Ctrl+Read) | It is shown that it is ADMIN authority. |
| Operating statuses (MODE) | OFFLINE | Indicates that the AE5501 is OFFLINE. |
| | ONLINE | Indicates that the AE5501 is ONLINE (frame sending/reception in progress). |
| | ONLINE(Rx) | Indicates that the AE5501 is ONLINE (frame reception in progress). |
| | REMOTE | Indicates that an AE5730E control command is being executed. |
| Selected test mode (TEST MODE) | GENERATE | Indicates that the selected test mode is GENERATE. |
| | LATENCY | Indicates that the selected test mode is LATENCY. |
| | PING | Indicates that the selected test mode is PING. |
| | REPLY | Indicates that the selected test mode is REPLY. |
| | LOOPBACK | Indicates that the selected test mode is LOOPBACK. |
| Selected measurement condition (Setup01 to 10 FREE) | | Indicates the currently selected measurement condition and its name. Note that this is not displayed while an AE5730E control command is being executed. |
| Notification message (NOTIFY) | ARP MISS | Indicates that the status has changed to OFFLINE because the ARP process at the start of PING measurement failed. |
| | STOP ACTION | Indicates that STOP ACTION was successful and transmission has been stopped or measurement has been ended. |
| | I/F MISMATCH | Indicates that running is not possible due to an I/F mismatch. |
| | COUNT SEND OVER | Indicates that count transmission ended and transmission stopped. |

Table 4.3-5 Contents of indication 2/2

| Overview | Screen display | Description |
|--------------------------------|------------------|---|
| Power supply status (POWER) | AC_ADAPTER | Indicates that an AC adapter is being used. |
| | BATTERY_HIGH | Indicates that the battery level is HIGH. |
| | BATTERY_MIDDLE | Indicates that the battery level is MIDDLE. Quickly recharging the battery is recommended. |
| | BATTERY_LOW | Indicates that the battery level is LOW. The power must be turned off immediately and the battery must be recharged. |
| Interface | 10BASE-T HALF | It is shown that circuit is 10BASE-T HALF. |
| | 10BASE-T FULL | It is shown that circuit is 10BASE-T FULL. |
| | 100BASE-TX HALF | It is shown that circuit is 100BASE-T HALF. |
| | 100BASE-TX FULL | It is shown that circuit is 100BASE-T FULL. |
| | 1000BASE-T FULL | It is shown that circuit is 1000BASE-T FULL. |
| | 1000BASE-SX FULL | It is shown that circuit is 1000BASE-SX FULL. |
| | 1000BASE-LX FULL | It is shown that circuit is 1000BASE-LX FULL. |
| Link status | UP | It is shown that link is up. |
| | DOWN | It is shown that link is down. |

Following is an example of the screen display when the Check Status command is executed.

```

>status
<ADMIN(Ctrl+Read)>
MODE : OFFLINE
TEST MODE : GENERATE
SETUP01 : Setup_No01
NOTIFY :
POWER : AC_ADAPTER
LINK : 100BASE-TX FULL (UP)

```

4.3.2.6 SELECT (Change measurement condition) command

This command changes the currently selected measurement condition. When the measurement condition is changed using this command, it becomes valid when the sub-parameter is omitted in the following commands.

Condition for changing settings with the SET command

Condition for displaying settings with the DISP command

In addition to the above, the measurement condition also applies to starting measurement with the RUN command.

1 Command input

```
>select setup01
```

In the TELNET console window, enter “>select sub-command” (the abbreviated form is “>sel sub-command”), then press the [Enter] key.

2 Sub-command

Sub-command

Select a measurement condition as a sub-command. The table below presents a list of sub-commands that can be selected.

Table 4.3-6 Sub-command

| Sub-command | Abbreviated forms | Description |
|-------------|-------------------|---|
| setup01 | 1(s1) | Generate/Latency Measurement Condition 1 |
| setup02 | 2(s2) | Generate/Latency Measurement Condition 2 |
| setup03 | 3(s3) | Generate/Latency Measurement Condition 3 |
| setup04 | 4(s4) | Generate/Latency Measurement Condition 4 |
| setup05 | 5(s5) | Generate/Latency Measurement Condition 5 |
| setup06 | 6(s6) | Generate/Latency Measurement Condition 6 |
| setup07 | 7(s7) | Generate/Latency Measurement Condition 7 |
| setup08 | 8(s8) | Generate/Latency Measurement Condition 8 |
| setup09 | 9(s9) | Generate/Latency Measurement Condition 9 |
| setup10 | 10(s10) | Generate/Latency Measurement Condition 10 |
| Free | f(s11) | Ping/Reply/Loopback Measurement Condition |

3 An effect effect-less condition with the command input

Refer to Table 4.3-2

4 Screen example


During normal operation, nothing is displayed and the system waits for the next command.

```
>select setup01
>
```

4.3.2.7 SETLIST (Display measurement conditions list) command

This command displays a list of measurement conditions.

1 Command input



2 An effect effect-less condition with the command input

Refer to Table 4.3-2


3 Screen example

When the SETLIST command is executed, the following information is displayed.

Currently selected measurement condition

Test modes and names of all measurement conditions

Following is an example of the screen which is displayed during normal operations.



4.3.2.8 SET (Change settings) command

This command changes the individual settings in a measurement condition.

1 Command input

```
>set setup01 link:flow=on
```

In the TELNET console window, enter “>set sub-command parameter : sub-parameter = setup value”, then press the [Enter] key.

2 Sub-command / Parameter / Setup value

Sub-command

Select a measurement condition as a sub-command. The table below presents a list of sub-commands that can be selected. If a sub-command is omitted, the measurement condition selected with the Change Measurement Condition command is changed. Note that the sub-command cannot be omitted when setting DHCP and ARP.

Table 4.3-7 Sub-command

| Sub-command | Abbreviated forms | Description |
|-------------|-------------------|---|
| setup01 | 1(s1) | Generate/Latency Measurement Condition 1 |
| setup02 | 2(s2) | Generate/Latency Measurement Condition 2 |
| setup03 | 3(s3) | Generate/Latency Measurement Condition 3 |
| setup04 | 4(s4) | Generate/Latency Measurement Condition 4 |
| setup05 | 5(s5) | Generate/Latency Measurement Condition 5 |
| setup06 | 6(s6) | Generate/Latency Measurement Condition 6 |
| setup07 | 7(s7) | Generate/Latency Measurement Condition 7 |
| setup08 | 8(s8) | Generate/Latency Measurement Condition 8 |
| setup09 | 9(s9) | Generate/Latency Measurement Condition 9 |
| setup10 | 10(s10) | Generate/Latency Measurement Condition 10 |
| Free | f(s11) | Ping/Reply/Loopback Measurement Condition |
| DHCP | None | Applies to item on DHCP screen |
| ARP | None | Applies to item on ARP screen |

Parameters (sub-parameters)

Specify the setting to be changed using a parameter (sub-parameters).

With some settings, the parameter may be further divided into sub-parameters.

The relationships between the individual parameters (sub-parameters) and the set values and test modes are presented in Table 4.3-8 , Table 4.3-9 , Table 4.3-10 , Table 4.3-11 , Table 4.3-12.

Set values

Enter a new value for the setting which is being changed. The relationships between the individual parameters (sub-parameters) and the set values and test modes are presented in Table 4.3-8 , Table 4.3-9 , Table 4.3-10 , Table 4.3-11 , Table 4.3-12.

The relationships between the parameters (sub-parameters) and the set values and test modes are presented in the following tables. In cases where there are sub-parameters, the parameter entry appears as [Parameter: sub-parameter].

Table 4.3-8 Parameter / Setup value 1/5

| Parameter | Setup value | Measuring mode | | | | |
|-----------------------------------|------------------------------|----------------|---------|------|-------|--------------|
| | | Gene rate | Latency | Ping | Reply | Loop back |
| Name | Character | OK | OK | OK | OK | OK |
| test_mode(test) | Generate(gen) | OK | OK | NO | NO | NO |
| | Latency(lat) | OK | OK | NO | NO | NO |
| | Ping(pin) | NO | NO | OK | OK | OK |
| | Reply(rep) | NO | NO | OK | OK | OK |
| | Loopback(lb) | NO | NO | OK | OK | OK |
| run_mode(run) | rx&tx(r&t) | OK | OK | NO | NO | NO |
| | rx->tx(r-t) | OK | OK | NO | NO | NO |
| link:L1(L1) | 10BASE-T_FULL(10F) | OK | OK | OK | OK | OK |
| | 10BASE-T_HALF(10H) | OK | OK | OK | OK | OK |
| | 100BASE-TX_FULL(100F) | OK | OK | OK | OK | OK |
| | 100BASE-TX_HALF(100H) | OK | OK | OK | OK | OK |
| | 1000BASE-T_FULL(1000T) | OK | OK | OK | OK | OK |
| | 1000BASE-SX_FULL(1000S) | OK | OK | OK | OK | OK |
| | 1000BASE-LX_FULL(1000L) | OK | OK | OK | OK | OK |
| link:flow (flow) | On | OK | OK | NO | NO | NO |
| | Off | OK | OK | NO | NO | NO |
| link:negotiate (nego) | Auto(AT) | OK | OK | OK | OK | OK |
| | Manual(Man) | OK | OK | OK | OK | OK |
| link:crossover (cross) | Mdi | OK | OK | OK | OK | OK |
| | mdix | OK | OK | OK | OK | OK |
| | Auto(AT) | OK | OK | OK | OK | OK |
| tx_setup:transmit (trans) | 10M | OK | OK | NO | NO | NO |
| | 100M | OK | OK | NO | NO | NO |
| | 1G(1000M) | OK | OK | NO | NO | NO |
| tx_setup:tx-mode (txmode) | constant/count(c/cnt) | OK | OK | NO | NO | NO |
| | constant/continue(c/con) | OK | OK | NO | NO | NO |
| | burst/count(b/cnt) | OK | OK | NO | NO | NO |
| | burst/continue(b/con) | OK | OK | NO | NO | NO |
| tx_setup:ifg(ifg) | XXXbit | OK | OK | NO | NO | NO |
| | XXX.XXX% | OK | OK | NO | NO | NO |
| tx_setup:idle(idle) | XXXbit(bit can be omitted.) | OK | OK | NO | NO | NO |
| tx_setup:cnt(cnt) | XXX | OK | OK | NO | NO | NO |
| tx_setup:stop_action (stopact) | On | OK | OK | NO | NO | NO |
| | Off | OK | OK | NO | NO | NO |
| | XXXXmin(min can be omitted.) | OK | OK | NO | NO | NO |

Note: Parameters enclosed in parentheses are the abbreviated forms.

Table 4.3-9 Parameter / Setup value 2/5

| Parameter | Setup value | Measuring mode | | | | |
|-------------------------------------|-----------------------------|----------------|---------|------|-------|-----------|
| | | Generate | Latency | Ping | Reply | Loop back |
| tx_frame_count(frmcnt) | XXXX | OK | OK | NO | NO | NO |
| tx_frame?:length (tf?len) | XXXX | OK | OK | NO | NO | NO |
| tx_frame?:dst_mac (tf?dmac) | Manual(man) | OK | OK | NO | NO | NO |
| | ARP | OK | OK | NO | NO | NO |
| | XX-XX-XX-XX-XX-XX | OK | OK | NO | NO | NO |
| tx_frame?:src_mac (tf?smac) | Global | OK | OK | NO | NO | NO |
| | Manual(man) | OK | OK | NO | NO | NO |
| | DHCP | OK | OK | NO | NO | NO |
| | XX-XX-XX-XX-XX-XX | OK | OK | NO | NO | NO |
| tx_frame?:vlan_cnt (tf?vcnt) | X | OK | OK | NO | NO | NO |
| tx_frame?:vlan?:tpid (tf?v?tpid) | XXXX | OK | OK | NO | NO | NO |
| tx_frame?:vlan?:up (tf?v?up) | X | OK | OK | NO | NO | NO |
| tx_frame?:vlan?:cfi (tf?v?cfi) | On | OK | OK | NO | NO | NO |
| | Off | OK | OK | NO | NO | NO |
| tx_frame?:vlan?id (tf?v?id) | XXXX (decimal input) | OK | OK | NO | NO | NO |
| tx_frame?:type (tf?type) | IPv4 | OK | OK | NO | NO | NO |
| | IPv4-MC | OK | OK | NO | NO | NO |
| | IPv6 | OK | OK | NO | NO | NO |
| | USER | OK | OK | NO | NO | NO |
| | XXXX (hexadecimal input) | OK | OK | NO | NO | NO |
| tx_frame?:dst_IP (tf?dip) | ARP | OK | OK | NO | NO | NO |
| | Manual | OK | OK | NO | NO | NO |
| | XXX.XXX.XXX.XXX | OK | OK | NO | NO | NO |
| tx_frame?:src_IP (tf?sip) | DHCP | OK | OK | NO | NO | NO |
| | Manual | OK | OK | NO | NO | NO |
| | XXX.XXX.XXX.XXX | OK | OK | NO | NO | NO |
| tx_frame?:tos (tf?sip) | XXX (decimal input) | OK | OK | NO | NO | NO |
| tx_frame?:error (tf?err) | None | OK | OK | NO | NO | NO |
| | CRC | OK | OK | NO | NO | NO |

Note: Parameters enclosed in parentheses are the abbreviated forms.

Note: In MAC address entries, "XX" is in HEX notation.

Note: In IP address entries, "XXX" is in DEC notation.

Note: Enter a value in the range of 1 to 4 in place of question marks.

Note: Enter 1 or 2 in place of pound signs.

Note: The "XX" in filter patterns or filter masks is in HEX notation.

Table 4.3-10 Parameter / Setup value 3/5

| Parameter | Setup value | Measuring mode | | | | |
|---------------------------|-------------------------------|----------------|---------|------|-------|-----------|
| | | Generate | Latency | Ping | Reply | Loop back |
| Filter#:sel (f#sel) | On | OK | OK | NO | NO | NO |
| | Off | OK | OK | NO | NO | NO |
| Filter#:offset(f#off) | XX(decimal input) | OK | OK | NO | NO | NO |
| Filter#:length(f?len) | X | OK | OK | NO | NO | NO |
| Filter#:pattern(f?pat) | XX-XX-XX-XX-XX-XX | OK | OK | NO | NO | NO |
| Filter#:mask(f?msk) | XX-XX-XX-XX-XX-XX | OK | OK | NO | NO | NO |
| filter_init(finit) | And | OK | OK | NO | NO | NO |
| | Or | OK | OK | NO | NO | NO |
| over_size(OVSZ) | XXXXX(decimal input) | OK | OK | NO | NO | NO |
| alarm:rx_frame (almrx) | On | OK | NO | NO | NO | NO |
| | Off | OK | NO | NO | NO | NO |
| | Up | OK | NO | NO | NO | NO |
| | Down | OK | NO | NO | NO | NO |
| | XXXXXXXXXX (decimal input) | OK | NO | NO | NO | NO |
| alarm:err_cnt (almer) | On | OK | NO | NO | NO | NO |
| | off | OK | NO | NO | NO | NO |
| | XXXXXXXXXX (decimal input) | OK | NO | NO | NO | NO |
| alarm:tx_frame (almtx) | On | OK | NO | NO | NO | NO |
| | off | OK | NO | NO | NO | NO |
| | XXXXXXXXXX (decimal input) | NO | NO | NO | NO | NO |
| fixed_delay (delay) | On | NO | OK | NO | NO | NO |
| | off | NO | OK | NO | NO | NO |

Note: Parameters enclosed in parentheses are the abbreviated forms.

Note: In MAC address entries, "XX" is in HEX notation.

Note: In IP address entries, "XXX" is in DEC notation.

Note: Enter a value in the range of 1 to 4 in place of question marks.

Table 4.3-11 Parameter / Setup value 4/5

| Parameter | Setup value | Measuring mode | | | | |
|---------------------|-------------------------------|----------------|----------|------|-------|-----------|
| | | Gene rate | Laten cy | Ping | Reply | Loop back |
| src_mac (smac) | all | NO | NO | NO | NO | OK |
| | global | NO | NO | OK | OK | OK |
| | manual | NO | NO | OK | OK | OK |
| | XX-XX-XX-XX-XX-XX | NO | NO | OK | OK | OK |
| Loopback(lb) | MAC | NO | NO | NO | NO | OK |
| | MAC+IP | NO | NO | NO | NO | OK |
| Src_IP (sip) | Manual | NO | NO | OK | OK | OK |
| | Dhcp | NO | NO | OK | OK | OK |
| | XXX.XXX.XXX.XXX | NO | NO | OK | OK | OK |
| subnet_mask(subnet) | XXX.XXX.XXX.XXX | NO | NO | OK | NO | NO |
| Gateway(gw) | XXX.XXX.XXX.XXX | NO | NO | OK | NO | NO |
| Dst_IP(dip) | XXX.XXX.XXX.XXX | NO | NO | OK | NO | NO |
| frame_len(frmlen) | XXXX(decimal input) | NO | NO | OK | NO | NO |
| Interval | 1sec | NO | NO | OK | NO | NO |
| | 5sec | NO | NO | OK | NO | NO |
| | 10sec | NO | NO | OK | NO | NO |
| tx_mode (txmode) | continue | NO | NO | OK | NO | NO |
| | count | NO | NO | OK | NO | NO |
| | XXXXXXXXXX (decimal input) | NO | NO | OK | NO | NO |
| vlan_cnt(vcnt) | X | NO | NO | OK | OK | OK |
| vlan_cmp(vcmp) | On | NO | NO | NO | OK | NO |
| | Off | NO | NO | NO | OK | NO |
| vlan?:tpid(v?tpid) | XXXX(decimal input) | NO | NO | OK | OK | NO |
| vlan?:up(v?up) | X | NO | NO | OK | NO | NO |
| vlan?:cfi(v?cfi) | On | NO | NO | OK | NO | NO |
| | Off | NO | NO | OK | NO | NO |
| vlan?:id(v?id) | XXXX(hexadecimal input) | NO | NO | OK | OK | NO |
| arp_reply(ARPREP) | On | OK | OK | NO | NO | OK |
| | Off | OK | OK | NO | NO | OK |

Note: Parameters enclosed in parentheses are the abbreviated forms.

Note: In MAC address entries, "XX" is in HEX notation.

Note: In IP address entries, "XXX" is in DEC notation.

Table 4.3-12 Parameter / Setup value 5/5

| Sub-command + parameter | Setup value | Special mode | |
|-------------------------------------|-------------------------|--------------|-----|
| | | DHCP | ARP |
| dhcp link:L1 (dhcp L1) | 10BASE-T_FULL(10F) | OK | NO |
| | 10BASE-T_HALF(10H) | OK | NO |
| | 100BASE-TX_FULL(100F) | OK | NO |
| | 100BASE-TX_HALF(100H) | OK | NO |
| | 1000BASE-T_FULL(1000T) | OK | NO |
| | 1000BASE-SX_FULL(1000S) | OK | NO |
| | 1000BASE-LX_FULL(1000L) | OK | NO |
| dhcp link:negotiate (dhcp nego) | Auto(AT) | OK | NO |
| | Manual(Man) | OK | NO |
| dhcp link:crossover (dhcp cross) | Mdi | OK | NO |
| | mdix | OK | NO |
| | Auto(AT) | OK | NO |
| dhcp Src_IP (dhcp sip) | Manual | OK | NO |
| | Dhcp | OK | NO |
| | XXX.XXX.XXX.XXX | OK | NO |
| dhcp Subnet_mask (dhcp subnet) | XXX.XXX.XXX.XXX | OK | NO |
| dhcp Gateway (dhcp gw) | XXX.XXX.XXX.XXX | OK | NO |
| arp Dst_IP (arp dip) | XXX.XXX.XXX.XXX | NO | OK |

Note: Parameters enclosed in parentheses are the abbreviated forms.

Note: In MAC address entries, "XX" is in HEX notation.

Note: In IP address entries, "XXX" is in DEC notation.

3 An effect effect-less condition with the command input

Refer to Table 4.3-2

4 Screen example

During normal operation, nothing is displayed and the system waits for the next command.

```
>set setup01 flow=on
>
```


4.3.2.9 DISPLAY (Setting check) command

This command is used to check the specified set condition. Parameter settings can be used to check a single condition or multiple conditions. DHCP and ARP execution results can be checked with the DISPLAY command (not the RESULT command).

1 Command input

- >display Sub-command Individual parameter: Group parameter
- >disp Sub-command Individual parameter: Group parameter abbreviation allowed.

```
>display setup01 name
```

In the TELNET console window, enter ">display sub-command Individual parameter : group parameter (the abbreviated form is ">disp sub-command Individual parameter : group parameter")", then press the [Enter] key.

2 Sub-command / parameter

Sub-command

Select a measurement condition as a sub-command. The table below presents a list of sub-commands that can be selected. If the sub-command is omitted, the measurement condition selected by the Change Measurement Condition command is displayed. Note that the sub-command cannot be omitted when displaying DHCP and ARP settings.

Table 4.3-13 Sub-command

| Sub-command | Abbreviated forms | Description |
|-------------|-------------------|---|
| setup01 | 1(s1) | Generate/Latency Measurement Condition 1 |
| setup02 | 2(s2) | Generate/Latency Measurement Condition 2 |
| setup03 | 3(s3) | Generate/Latency Measurement Condition 3 |
| setup04 | 4(s4) | Generate/Latency Measurement Condition 4 |
| setup05 | 5(s5) | Generate/Latency Measurement Condition 5 |
| setup06 | 6(s6) | Generate/Latency Measurement Condition 6 |
| setup07 | 7(s7) | Generate/Latency Measurement Condition 7 |
| setup08 | 8(s8) | Generate/Latency Measurement Condition 8 |
| setup09 | 9(s9) | Generate/Latency Measurement Condition 9 |
| setup10 | 10(s10) | Generate/Latency Measurement Condition 10 |
| Free | f(s11) | Ping/Reply/Loopback Measurement Condition |
| DHCP | None | Applies to item on DHCP screen |
| ARP | None | Applies to item on ARP screen |

Parameters (group parameters)

Use parameters (group parameters) to specify the setting which is to be displayed. If a parameter is omitted, all settings specified by the sub-command (or for the currently selected measurement condition) will be displayed.

Parameters may be specified as a group or individually. When just a group is specified, all settings within it are displayed. When individual parameters are specified, only the specified settings are displayed.

The relationships between the group parameters and the individual parameters and test modes are presented in Table 4.3-14 , Table 4.3-15 and Table 4.3-16.

Table 4.3-14 Parameter 1/3

| Parameter | | Measuring mode | | | | |
|-------------------------|-----------------------|----------------|---------|------|-------|----------|
| Group | individual | Generate | Latency | Ping | Reply | Loopback |
| name | | OK | OK | OK | OK | OK |
| test_mode(test) | | OK | OK | OK | OK | OK |
| run_mode(run) | | OK | OK | NO | NO | NO |
| Link | L1 | OK | OK | OK | OK | OK |
| | Flow | OK | OK | NO | NO | NO |
| | Negotiate (nego) | OK | OK | OK | OK | OK |
| | Crossover (cross) | OK | OK | OK | OK | OK |
| tx_setup (txset) | Transmit (trans) | OK | OK | NO | NO | NO |
| | tx-mode (txmdoe) | OK | OK | NO | NO | NO |
| | lfg | OK | OK | NO | NO | NO |
| | Idle | OK | OK | NO | NO | NO |
| | Cnt | OK | OK | NO | NO | NO |
| | stop_action (stopact) | OK | OK | NO | NO | NO |
| tx_frame_count (frmcnt) | | OK | OK | NO | NO | NO |
| tx_frame1 (tf1) | Length | OK | OK | NO | NO | NO |
| | dst_mac | OK | OK | NO | NO | NO |
| tx_frame2 (tf2) | src_mac | OK | OK | NO | NO | NO |
| | vlan_cnt | OK | OK | NO | NO | NO |
| tx_frame3 (tf3) | vlan1(v1) | OK | OK | NO | NO | NO |
| | vlan2(v2) | OK | OK | NO | NO | NO |
| tx_frame4 (tf4) | vlan3(v3) | OK | OK | NO | NO | NO |
| | vlan4(v4) | OK | OK | NO | NO | NO |
| | dst_IP | OK | OK | NO | NO | NO |
| | src_IP | OK | OK | NO | NO | NO |
| | tos | OK | OK | NO | NO | NO |
| | error | OK | OK | NO | NO | NO |

Note 1: The settings [vlan1] to [vlan4] display all of the following: [TPID], [UP], [CFI], [ID].

Note 2: When tx_setup is specified, both [tx_frame_count] and [tx_frame] are displayed.
(all sending conditions are displayed)

Table 4.3-15 Parameter 2/3

| Parameter | | Measuring mode | | | | |
|---------------------|--------------|----------------|---------|------|-------|----------|
| Group | Individual | Generate | Latency | Ping | Reply | Loopback |
| filter1(f1) | | OK | OK | NO | NO | NO |
| filter2(f2) | | OK | OK | NO | NO | NO |
| filter_init(finit) | | OK | OK | NO | NO | NO |
| over_size(ovsz) | | OK | OK | NO | NO | NO |
| Alarm (alm) | rx_frame(rx) | OK | NO | NO | NO | NO |
| | err_cnt(er) | OK | NO | NO | NO | NO |
| | tx_frame(tx) | OK | NO | NO | NO | NO |
| Fixed_delay(delay) | | NO | OK | NO | NO | NO |
| src_mac(smac) | | NO | NO | OK | OK | OK |
| Loopback(lb) | | NO | NO | NO | NO | OK |
| src_ip(sip) | | NO | NO | OK | OK | NO |
| subnet_mask(subnet) | | NO | NO | OK | NO | NO |
| Gateway(gw) | | NO | NO | OK | NO | NO |
| dst_ip(dip) | | NO | NO | OK | NO | NO |
| frame_len(frmlen) | | NO | NO | OK | NO | NO |
| Interval | | NO | NO | OK | NO | NO |
| tx_mode(txmode) | | NO | NO | OK | NO | NO |
| vlan_cnt(vcnt) | | NO | NO | OK | OK | OK |
| vlan_cmp(vcmp) | | NO | NO | NO | OK | NO |
| vlan1(v1) | | NO | NO | OK | OK | NO |
| vlan2(v2) | | NO | NO | OK | OK | NO |
| vlan3(v3) | | NO | NO | OK | OK | NO |
| vlan4(v4) | | NO | NO | OK | OK | NO |
| arp_reply(arprep) | | OK | OK | NO | NO | OK |

Note 1: [filter1] or [filter2] can also be applied to group parameters only.

Note 2: The settings [vlan1] to [vlan4] display all of the following: [TPID], [UP], [CFI], [ID].

Table 4.3-16 Parameter 3/3

| Parameter | | Special mode | |
|---------------------|----------------------|--------------|-----|
| Group | Individual | DHCP | ARP |
| Link | L1 | OK | NO |
| | Negotiate (nego) | OK | NO |
| | Crossover (cross) | OK | NO |
| src_mac(smac) | | OK | NO |
| src_ip(sip) | | OK | NO |
| subnet_mask(subnet) | | OK | NO |
| Gateway(gw) | | OK | NO |
| dst_ip(dip) | | NO | OK |

- 3 An effect effect-less condition with the command input
Refer to Table 4.3-2

4 Screen example

The screen display varies depending on the parameter settings.

When group parameter is specified

```
>disp setup01 link
<< LINK >>
L1      : 10BASE-T FULL
FLOW    : ON
NEGOTIATE : AUTO
CROSSOVER : MDI
>
```

Individual parameter

```
>disp setup01 link:negotiate
LINK - NEGOTIATE : AUTO
>
```

NOTE

A list of disp command sub-parameter types can be displayed by entering “help disp” or “? disp” at the prompt.

The SET command, DISP command, and RESULT command have numerous sub-parameters, so input abbreviations are provided.

In the HELP which is displayed by TX_FRAME#:SRC_IP(TXFRM#:SRCIP,F#SIP) “? disp” in the above case, the following three input formats are available:

```
>disp tx_frame1:src_ip
>disp txfrm1:srcip
>disp t1sip
```

4.3.2.10 RESULT (Display measurement results) command

This command displays the AE5501 measurement results. Sub-commands and parameters can be used to select the ONLINE or OFFLINE screen and specify measurement items. (DHCP and ARP execution results can be checked with the DISPLAY command)

1 Command input

```
>result setup01 030821080448.re time
```

In the TELNET console window, enter ">result sub-command filename parameter" (the abbreviated form is ">res sub-command filename parameter") , then press the [Enter] key.

2 Sub-command / File name / Parameter

Sub-command

Select a measurement condition as a sub-command. The table below presents a list of sub-commands that can be selected. The displayed measurement results are different if the sub-command/file name is omitted. See Table 4.3-17.

Table 4.3-17 Sub-command

| Sub-command | Abbreviated forms | Description |
|-------------|-------------------|---|
| setup01 | 1(s1) | Generate/Latency Measurement Condition 1 |
| setup02 | 2(s2) | Generate/Latency Measurement Condition 2 |
| setup03 | 3(s3) | Generate/Latency Measurement Condition 3 |
| setup04 | 4(s4) | Generate/Latency Measurement Condition 4 |
| setup05 | 5(s5) | Generate/Latency Measurement Condition 5 |
| setup06 | 6(s6) | Generate/Latency Measurement Condition 6 |
| setup07 | 7(s7) | Generate/Latency Measurement Condition 7 |
| setup08 | 8(s8) | Generate/Latency Measurement Condition 8 |
| setup09 | 9(s9) | Generate/Latency Measurement Condition 9 |
| setup10 | 10(s10) | Generate/Latency Measurement Condition 10 |
| Free | f(s11) | Ping/Reply/Loopback Measurement Condition |

File name

Enter the file name for the measurement result file to be displayed. The result file name can be checked using the Display Measurement Result File List command.
The displayed information is different if the sub-command/file name is omitted. See Table 4.3-18.

Table 4.3-18 An applicable measurement result in the sub- command / file name omission

| Sub-command | File name | Measurement result |
|---------------|---------------|--|
| abbreviation | abbreviation | AE5501 is ONLINE : Present condition AE5501 is OFFLINE : Measurement result |
| specification | abbreviation | AE5501 is ONLINE : Error AE5501 is OFFLINE : Error |
| abbreviation | specification | AE5501 is ONLINE :Error AE5501 is OFFLINE : A designated measurement result file in the measurement condition specified with the select command.(File name) |
| specification | specification | AE5501 is ONLINE : Error AE5501 is OFFLINE : The designated measurement result file of the designated measurement condition (sub-command) |

Parameters

Use parameters to specify the settings which are to be displayed.

More than one parameter can be specified by dividing it with ",".

If parameters are omitted, the results for all measurement items are displayed. There are group parameters and individual parameters. The relationships between individual parameters and test modes are shown in Table 4.3-19. The relationships between group parameters and measurement items are shown in Table 4.3-20.

Measurement results are displayed following individual parameter input in the test modes with a OK.

Table 4.3-19 Individual parameter and measuring mode

| Individual parameter | Abbreviation | Measuring mode | | | | |
|----------------------|----------------|----------------|---------|------|-------|----------|
| | | Generate | Latency | Ping | Reply | Loopback |
| head | MD | OK | OK | OK | OK | OK |
| time | TM | OK | OK | OK | OK | OK |
| tx_rate | TRATE,TR | OK | OK | | | |
| rx_rate | RRATE,RR | OK | OK | | | |
| tx_frm/s | TFRMS,TFS | OK | OK | | | |
| rx_frm/s | RFRMS,RFS | OK | OK | | | |
| tx_bit/s | TBITS,TBS | OK | OK | | | |
| rx_bit/s | RBITS,RBS | OK | OK | | | |
| tx_error | TERR,TE | OK | OK | | | |
| rx_error | RERR,RE | OK | OK | | | |
| crc_error | CRC | OK | OK | | | |
| under_size | UNDER,UD | OK | OK | | | |
| over_size | OVER,OV | OK | OK | | | |
| alignment | ALIGN,AL | OK | OK | | | |
| collision | COLL,CL | OK | OK | | | |
| pause_pkt | PAUSE,PS | OK | OK | | | |
| tx_byte | TBYTE,TB | OK | OK | | | |
| rx_byte | RBYTE,RB | OK | OK | | | |
| tx_frame | TFRAME,TFRM,TF | OK | OK | OK | | |
| rx_frame | RFRAME,RFRM,RF | OK | OK | OK | | |
| Idle | IL | OK | OK | | | |
| alarm | ALM | OK | | | | |
| delay | DLY | | OK | | | |
| src_ip | SIP | | | OK | | |
| dst_ip | DIP | | | OK | | |
| tx_mode | TXMODE,TMD | | | OK | | |
| interval | | | | OK | | |
| loss_cnt | LCNT | | | OK | | |
| loss_rate | LRATE | | | OK | | |
| round_trip | ROUND | | | OK | | |
| ping | PIN | | | | OK | |
| arp | | | | | OK | |

Note 1: Displays some measurement conditions during measurement (RUN MODE / STOP ACTION) and LINK information.

Note 2: Valid only when offline measurement results are displayed. The measurement start time and measurement end time are displayed.

Note 3: "filter1" or "filter2" can also be applied to group parameters only.

Note 4: It is effective only during the online measurement.

When a group parameter is entered, the measurement items with a OK are displayed.

Table 4.3-20 Group parameter and measurement item

| Measurement item | Group parameter | | | | | | | |
|------------------|-----------------|----|------|-------------|--------------|-------------|------|-------------|
| | tx | rx | rate | frm/s (frm) | bit/s (bits) | error (err) | byte | frame (frm) |
| tx_rate | OK | | OK | | | | | |
| rx_rate | | OK | OK | | | | | |
| tx_frm/s | OK | | | OK | | | | |
| rx_frm/s | | OK | | OK | | | | |
| tx_bit/s | OK | | | | OK | | | |
| rx_bit/s | | OK | | | OK | | | |
| tx_error | OK | | | | | OK | | |
| rx_error | | OK | | | | OK | | |
| crc_error | | | | | | OK | | |
| under_size | | | | | | OK | | |
| over_size | | | | | | OK | | |
| alignment | | | | | | OK | | |
| collision | | | | | | OK | | |
| pause_pkt | | | | | | OK | | |
| tx_byte | OK | | | | | | OK | |
| rx_byte | | OK | | | | | OK | |
| tx_frame | OK | | | | | | | OK |
| rx_frame | | OK | | | | | | OK |
| idle | | | | | | | | |
| alarm | | | | | | | | |
| delay | | | | | | | | |
| src_ip | | | | | | | | |
| dst_ip | | | | | | | | |
| tx_mode | | | | | | | | |
| loss_cnt | | | | | | | | |
| loss_rate | | | | | | | | |
| round_trip | | | | | | | | |
| ping | | | | | | | | |
| arp | | | | | | | | |

3 An effect effect-less condition with the command input
Refer to Table 4.3-2

4 Screen example

Following is an example of the screen which is displayed when a group is specified while the AE5501 is OFFLINE. A file name is not specified, so the most recent measurement results are shown.

```
>result tx
TX RATE      : 0.000%
TX FRM/s     :0
TX BIT/s     :0
TX ERROR     :0
TX BYTE      :33984
TX FRAME     :531
>
```

NOTE

A list of result command sub-parameter types can be displayed by entering “help result” or “? result” at the prompt.

The SET command, DISP command, and RESULT command have numerous sub-parameters, so input abbreviations are provided.

For details on Result command abbreviations, see 5.4.2 The abbreviation list of the parameter of the result command.

The most recent measurement results are all displayed if the sub-command, file name, and parameter are omitted.

```
>result
VERSION      :R03.01
NAME         :030820093048.re
SETUP MODE   :Setup_No01
TEST MODE    :GENERATE

L1           :10BASE-T FULL
FLOW CTRL    :ON
NEGOTIATE    :AUTO
LINK         :UP
CROSSOVER    :MDI
RUM MODE     :RX->TX
STOP ACTION  :OFF
START TIME   :2003/08/20 09:29:16
END TIME     :2003/08/20 09:30:48
TX RATE      : 0.000%
TX RATE      : 0.000%
TX FRM/s     :0
TX FRM/s     :0
TX BIT/s     :0
RX BIT/s     :0
TX ERROR     :0
RX ERROR     :0
CRC ERROR    :0
UNDERSIZE    :0
OVER SIZE    :0
ALIGNMENT    :0
COLLISION    :0
PAUSE Pkt    :0
TX BYTE      :43392
RX BYTE      :43392
TX FRAME     :678
RX FRAME     :678
IDLE         :
MAX          :6704usec
MIN          :6704usec
AVG          :6704usec
TX FRAME     :678
RX FRAME     :678
>
```

4.3.2.11 LIST (Display results file list) command

This command displays a list of measurement result files for each measurement condition.

1 Command input

The diagram shows a rectangular box representing a console window. Inside the box, the text ">list setup01" is displayed. A callout box with a pointer pointing to the text in the console window contains the following text: "In the TELNET console window, enter ">list sub-command" (the abbreviated form is ">ls sub-command") , then press the [Enter] key."

2 Sub-command

Select a measurement condition as a sub-command. The table below presents a list of sub-commands that can be selected. If the sub-command is omitted, a list of the number of files for each measurement condition is presented.

Table 4.3-21 Sub-command

| Sub-command | Abbreviated forms | Description |
|-------------|-------------------|---|
| setup01 | 1(s1) | Generate/Latency Measurement Condition 1 |
| setup02 | 2(s2) | Generate/Latency Measurement Condition 2 |
| setup03 | 3(s3) | Generate/Latency Measurement Condition 3 |
| setup04 | 4(s4) | Generate/Latency Measurement Condition 4 |
| setup05 | 5(s5) | Generate/Latency Measurement Condition 5 |
| setup06 | 6(s6) | Generate/Latency Measurement Condition 6 |
| setup07 | 7(s7) | Generate/Latency Measurement Condition 7 |
| setup08 | 8(s8) | Generate/Latency Measurement Condition 8 |
| setup09 | 9(s9) | Generate/Latency Measurement Condition 9 |
| setup10 | 10(s10) | Generate/Latency Measurement Condition 10 |
| Free | f(s11) | Ping/Reply/Loopback Measurement Condition |

3 An effect effect-less condition with the command input

Refer to Table 4.3-2

4 Screen example

There are two different screen types. The type which is displayed depends on whether the sub-command is omitted, and the sub-command setting.

If the sub-command is omitted, the individual file counts for setup01 to setup10 and FREE, as well as the total number of measurement result files, are presented.

```
>list
SETUP01 : 18 Files
SETUP02 : 4 Files
SETUP03 : 0 Files
SETUP04 : 0 Files
SETUP05 : 0 Files
SETUP06 : 0 Files
SETUP07 : 0 Files
SETUP08 : 0 Files
SETUP09 : 0 Files
SETUP10 : 0 Files
FREE   : 0 Files
  Total : 22 Files
>
```

When a sub-command is specified, a list of file names for the specified measurement condition, and the file count for measurement result files under the specified measurement condition, are presented.

```
>list setup02
SETUP02(GENERATE) : Setup_No02
030819094808.re
030819102113.re
030819102344.re
030819102525.re
  Total : 4 Files.
>
```

4.3.2.12 REMOVE (REMOVE results file) command

This command removes measurement result files.

1 Command input

```
>remove setup 030821080448.re
```

In the TELNET console window, enter
 ">remove sub-command file name" (the abbreviated
 form is ">rm sub-command file name")
 ">delete sub-command file name" (the abbreviated
 form is ">del sub-command file name")
 , then press the [Enter] key.

2 Sub-command / File name

Sub-command

Select a measurement condition as a sub-command. The table below presents a list of sub-commands that can be selected. In cases where a sub-command is omitted, if a file name has been specified, a single specified measurement result file under the measurement condition specified by the Change Measurement Condition command is deleted.

Table 4.3-22 Sub-command

| Sub-command | Abbreviated forms | Description |
|-------------|-------------------|---|
| setup01 | 1(s1) | Generate/Latency Measurement Condition 1 |
| setup02 | 2(s2) | Generate/Latency Measurement Condition 2 |
| setup03 | 3(s3) | Generate/Latency Measurement Condition 3 |
| setup04 | 4(s4) | Generate/Latency Measurement Condition 4 |
| setup05 | 5(s5) | Generate/Latency Measurement Condition 5 |
| setup06 | 6(s6) | Generate/Latency Measurement Condition 6 |
| setup07 | 7(s7) | Generate/Latency Measurement Condition 7 |
| setup08 | 8(s8) | Generate/Latency Measurement Condition 8 |
| setup09 | 9(s9) | Generate/Latency Measurement Condition 9 |
| setup10 | 10(s10) | Generate/Latency Measurement Condition 10 |
| Free | f(s11) | Ping/Reply/Loopback Measurement Condition |

File name

Specify the name of the measurement result file which is to be removed, under the measurement condition.

If the file name is omitted, all measurement result files specified by the sub-command, under the measurement condition, will be removed.

The files which are removed when the sub-command/file name is omitted are presented in Table 4.3-23.

Table 4.3-23 Files removed when sub-command/file name is omitted

| Sub-command | File name | File to be removed |
|-------------|-----------|---|
| Omitted | Omitted | All measurement result files under all measurement conditions |
| Specified | Omitted | All measurement result files under the specified measurement condition (sub-command) |
| Omitted | Specified | One specified measurement result file (file name) under the measurement condition specified by the Change Measurement Condition command |
| Specified | Specified | One specified measurement result file (file name) under the specified measurement condition (sub-command) |

- 3 An effect effect-less condition with the command input
Refer to Table 4.3-2

4 Screen sample

The screen appears as shown below when all measurement result files are being removed. In response to the question, enter [y].

```
>remove
All Result File Delete OK ?
OK=[Y] / Cancel=[N] :y
Removed 4 Files.
>
```

The screen appears as shown below when all measurement result files under a specific measurement condition are being removed. In response to the question, enter [y].

```
>remove setup02
SETUP02 All Result File Delete OK ?
OK=[Y] / Cancel=[N] :y
Removed 5 Files.
>
```

Chapter 4 Operating Instructions

The screen appears as shown below when a specific measurement result file is being removed. In response to the question, enter [y].

```
>remove setup01 030814152525.re
030814152525.re Result File Delete OK ?
OK=[Y] / Cancel=[N] :y
Removed 030814152525.re Result File.
>
```


If [n] is entered in response to the question, the file removal process is cancelled.

```
>remove
All Result File Delete OK ?
OK=[Y] / Cancel=[N] :n
>
```

4.3.2.13 VERSION (Display version) command

This command is used to check the AE5501 version information.

1 Command input



2 An effect effect-less condition with the command input

Refer to Table 4.3-2


3 Screen sample

```
>version
AE5501 Traffic Tester Mini
Version : R03.01
Copyright ANDO ELECTRIC CO.,LTD.
>
```

4.3.2.14 SELFTEST (Self test) command

This command performs a self test on the AE5501.

1 Command input



2 An effect effect-less condition with the command input

Refer to Table 4.3-2

3 Screen sample

To perform a self test, enter [y] in response to the question. It takes approximately five seconds for the self test to complete once it starts.


After the self test ends, the results are displayed and the system waits for input.

```
>selftest
Execute SELFTEST OK ?
OK=[Y] / Cancel=[N] :y
Please Wait...
Test1 = OK
Test2 = OK
Test3 = OK
>
```


4.3.2.15 DATETIME (Set time/date) command

This command sets the AE5501 calendar.

1 Command input



The diagram consists of two rectangular boxes. The left box contains the command `>datetime 03/08/21 11:40:31`. A line from the right side of this box points to a larger box on the right. This right box contains the text: "In the TELNET console window, enter '>datetime time' (the abbreviated form is '>dt time') , then press the [Enter] key."


2 Time

Enter the new date/time in the following format: "Year/Month/Day Hours:Minutes:Seconds".
The AE5501 calendar is displayed if the date/time is omitted.

3 An effect effect-less condition with the command input

Refer to Table 4.3-2

4 Screen sample




The screen sample shows a rectangular box containing the command `>datetime 03/08/20 20:10:10` on the first line and the prompt `>` on the second line.

4.3.2.16 DATETIME (Display time/date) command

This command displays the AE5501 calendar.

1 Command input



The diagram shows a rectangular box on the left containing the text ">datetime". A line extends from the right side of this box and splits into two lines that point to a larger rectangular callout box on the right. The callout box contains the text: "In the TELNET console window, enter '>datetime' (the abbreviated form is '>dt') , then press the [Enter] key."

2 An effect effect-less condition with the command input

Refer to Table 4.3-2


3 Screen sample

```
>datetime
Date/Time = 03/08/20 20:10:18
>
```

4.3.2.17 INIT (Set all defaults) command

This command sets all AE5501 values to their defaults.

1 Command input



2 An effect effect-less condition with the command input

Refer to Table 4.3-2

3 Screen example

To set all values to their defaults, in response to the question, enter [y].

It takes approximately 15 seconds for the INIT command to complete once it starts.

After all of the values are set to their defaults, the system waits for input. To cancel the INIT command, enter [n] in response to the question.


```
>init
All Default OK ?
OK=[Y] / Cancel=[N] :y
Please Wait...
File = OK
Setup = OK
Result = OK
>
```

Be careful because a password for the SU command is erased, too, when an init command succeeds.

4.3.2.18 VERSIONUP (Version upgrade) command

This command is used to connect to AE5730 and change the AE5501 to version upgrade mode.

1 Command input



The diagram shows a rectangular box on the left containing the text ">versionup". A line extends from the right side of this box and splits into two lines that point to a larger rectangular callout box on the right. The callout box contains the following text:

In the TELNET console window, enter ">versionup" (the abbreviated form is ">verup"), then press the [Enter] key.

2 An effect effect-less condition with the command input

Refer to Table 4.3-2

3 Screen example

To change to version upgrade mode, enter [y] in response to the question.


```
>verup
Version Up OK ?
OK=[Y] / Cancel=[N] :y
<Now Verup Mode>. Can't receive any request.
>
```

| |
|---|
| <h2>NOTE</h2> |
| When the VERSIONUP command is executed, the AE5501 can no longer engage in TELNET communication. Upgrade the version from an AE5730E unit. |

4.3.2.19 REMOTE (AE5730E remote control) command

This command changes the mode to remote mode, in which uploads and downloads from the AE5730E can be received.

1 Command input



2 An effect effect-less condition with the command input

Refer to Table 4.3-2

3 Screen example

To change the mode to remote mode, enter [y] in response to the question. If the operation is executed properly, the system waits for the next input.

```
>remote
AE5730 Connect OK ?
OK=[Y] / Cancel=[N] :y
>
```

Make sure that the prompt is displayed, then perform upload/download control from the AE5730.

NOTE


The STATUS command is used to display the current AE5501 status (OFFLINE status/ONLINE status/REMOTE status).

Use the STOP command to end remote status. (The status changes to OFFLINE after the STOP command is used)

4.3.2.20 DHCP (Performs DHCP) command

This command is used to acquire an IP address on the measurement port using DHCP.

1 Command input



2 An effect effect-less condition with the command input


Refer to Table 4.3-2

3 Screen example

While the command is being executed, “Please Wait...” is displayed. When the command is completed, “Complete” is displayed. Check the DHCP acquisition results by entering “display dhcp”.

Note that if “SRC IP” is not set to AUTO in the DHCP settings, the DHCP operation will not work. (To change the setting, enter “>set dhcp sip=auto”. This enables the DHCP command.)


If the operation is executed properly, the system waits for the next input.



4.3.2.21 ARP (Performs ARP) command

This command is used to acquire the MAC address of a terminal with a specified IP address using the ARP process.

1 Command input



2 An effect effect-less condition with the command input


Refer to Table 4.3-2

3 Screen example

The IP address of the target terminal can be specified by entering ">set arp dip=XXX.XXX.XXX.XXX".

While the command is being executed, "Please Wait..." is displayed. When the command is completed, "Complete" is displayed. Check the ARP acquisition results by entering "display arp". The values set on the DHCP screen are used as the SRC address information (SRC MAC/SRC IP, etc.) or LINK setting information required by ARP.


If the operation is executed properly, the system waits for the next input.



4.3.2.22 PASSWD (Set password) command

The settlement of a password to use with the su command is done.

1 Command input



2 An effect effect-less condition with the command input

Refer to Table 4.3-2

3 Screen example


```
>passwd 12345
Re-enter New Password :12345
>
>
```

It becomes effective only when it has ADMIN authority. The character lines which can be specified as a password become only an English letter to eight characters and a number. It registers as a new password when the character line of the re-input corresponds to the sub-parameter of the passwd command. And, the password set up is erased in the case of the one without a sub-parameter. Input of a password in input of a su command is stopped by this inescapably. And, be careful of the password as well set up when an init command is carried out because it is erased.

4.3.2.23 PROMPT (Set prompt) command

It is the command which prompt indicated on the terminal screen is changed to.

1 Command input



2 An effect effect-less condition with the command input

Refer to Table 4.3-2

3 Screen example

```
>prompt 12345
12345>
12345>
12345>prompt
>
>
```


The character lines which can be specified as prompt become an English letter to eight characters, a number, a sign (ASCII character from 0x21 to 0x7E).
The space can't be inputted in the character line.

And, when there is no sub-parameter, prompt indication is returned to ">".

4.3.2.24 HISTORY (Command history list) command

The one's personal history list of the character line inputted on the terminal screen is indicated.

1 Command input



2 An effect effect-less condition with the command input

Refer to Table 4.3-2

3 Screen example

```
>history
01 : su 12345
02 : status
03 : ls
04 : disp
05 : set setup01 test=gen
>
```


There is a one's personal history number in the list indicated. When it is inputted "! one's personal history number", it is possible to specify its personal history directly and to indicate it. The character line inputted right before the front when it was inputted again "!!" is indicated.

| |
|---|
| NOTE |
| History holds a maximum for 50 cases. When it exceeds 50 cases, it is replaced one after another from its old personal History. |

4.3.2.25 HELP command

This command is used to display help on commands used in TELNET control.

1 Command input



2 Command name

Enter the command name which is to be displayed. If the command name is omitted, all command names and command overviews will be shown.

3 An effect effect-less condition with the command input

Refer to Table 4.3-2

4 Screen example

Following is the screen display which is shown when a command name is specified.

```
>help run
Run Command -- Start Measurement.
[Syntax]
>Run
>
```

As for the SET command, it is possible that the list of the setup value is indicated in every sub-parameter.

```
>? set nego
[Syntax]
>SET [setupXX,free,dhcp] LINK:NEGOTIATE=(Value)
Parameter : LINK:NEGOTIATE(NEGOTIATE,NEGO)
Value    : AUTO(AT)
          MANUAL(MAN)
>
```

NOTE

To display the sub-parameters for an individual command, enter ">HELP 'command name'" or ">? 'command name'".

The SET command, DISP command, and RESULT command have numerous sub-parameters. Input abbreviations are also provided.

The screen appears as shown below when the command name is omitted.

```

>help
AE5501 Remote Control Command Reference
CONnect -- Connecting for AE5501.
Quit -- Quit Telnet Remote Control(same eXit).
Run -- Start Measurement.
DHCP -- Get IP Address.
ARP -- Get Destination Terminal MAC Address.
SToP -- Stop Measurement or AE5730 Remote.
STatuS -- Display System Status.
SElect -- Select Measure Condition.
SetList -- Display Measure Condition List.
SET -- Change Measure Condition Setup.
DISPlay -- Display Measure Condition Setup.
RESult -- Display Measure Result.
LiSt -- Display Result File List.
DElete -- Deleted Result File(same ReMove).
VERsion -- Display System Version Information.
SELFtest -- Execute System Self Test.
DATETIME -- Change or Display Date,Time.
INIT -- System All Default.
VERsionUP -- Execute System Version Up.
ReMoTe -- Change AE5730 Remote Control Mode.
HELP -- Display Command Reference.
SHell -- Shell Command : Start Shell Command Entry.
shellEND -- Shell Command : Finish Shell Program Entry.
shellVIEW -- Shell Command : Display Entry Shell Program.
shellGO -- Shell Command : Execute Entry Shell Program.
WAIT -- Shell Command : Waiting for some Sec or Input Key.
LOOP -- Shell Command : Start Loop.
LOOPEND -- Shell Command : end of Loop.
History -- Display Command History.
>

```

| |
|---|
| <h1>NOTE</h1> |
| <p>In the Help which is displayed by entering ">help set" or ">help disp", character strings enclosed in parentheses and separated by commas are abbreviated forms.</p> |
| <p><u>TX_FRAME#:VLAN#:TPID(TXFRM#:VLAN#TPID,TF#V#TPID)</u></p> <p style="margin-left: 100px;">1 2 3</p> |
| <p>There are three different specifying methods:</p> <ul style="list-style-type: none"> (a)TX_FRAME1:VLAN1:TPID (b)TXFRM1:VLAN1TPID (abbreviation type 1) (c)TF1V1TPID (abbreviation type 2) |

4.3.3 Script commands

With this function, TELNET commands are registered as script commands in order to execute continuous operations. In addition to ordinary commands, there are special commands such as those shown in the table below, which may be registered as script commands.

Table 4.3-24 Script commands


| Name | Details |
|-------------------|------------|
| SHELL command | Page 4-165 |
| SHELLVIEW command | Page 4-166 |
| SHELLGO command | Page 4-167 |
| WAIT command | Page 4-169 |
| LOOP command | Page 4-170 |

4.3.3.1 SHELL (Register shell program) command

This command is used to register a shell program. TELNET commands registered between shell program registration commands are automatically executed by the SHELLGO command (see 4.3.3.3 for details).

1 Command input

The command format will now be explained with reference to an actual screen display example. Start with the ">shell" command and end with "@>shellend".



After the shell program is registered in the above format, the registered shell program is executed by entering the shell program execution command (see 4.3.3.3 for details). Only one shell program may be registered. If the shell command is used to register a program again, the previously registered program will be overwritten. Prompt changes in "@>" from ">" during shell program registration.


2 An effect effect-less condition with the command input

Refer to Table 4.3-2

4.3.3.2 SHELLVIEW (shell program indication) command

This command displays the registered shell program.

1 Command input



2 An effect effect-less condition with the command input

Refer to Table 4.3-2

3 Screen example

The screen appears as shown below if a shell program has been registered.

```
>shellview
select setup01
run
stop
shellend
>
```


The screen appears as shown below if a shell program has not been registered.

```
>shellview
(E)Shell Program No Registry
>
```

4.3.3.3 SHELLGO (shell program execution) command

The most recent registered shell program is executed. For information on shell command, see 4.3.3.1.

1 Command input




2 An effect effect-less condition with the command input


Refer to Table 4.3-2

3 Screen example

Following is an example of the screen which is displayed when a shell program has been registered.



The screen appears as shown below if a shell program has not been registered.



NOTE

When remote cable is pulled out after shell program is executed, the about 15 minutes shell program movements are continued. But, when TELNET control is done from TELNET console window again, you must set up the TELNET mode of AE5501 again. Prompt changes in "@>" from ">" during shell program registration.

Pressing the [Esc] key while the script command is being executed causes the command to abort. Following is an example screen.


```
>shellgo
@<run
Please Wait...
@<wait 50
^[(W)Shell Script Canceled!!
>
```

Esc key was inputted during the "@>wait 50" is executed.

4.3.3.4 WAIT command

This command is used during a shell program to continue the immediately preceding command for a specified length of time. This may be set in two different ways: continuing the previous command for a specified length of time, and continuing the previous command until the next key input.


1 Command input




2 Interrupt action

The interrupt action may be set in two different ways: interrupt at a specified time, and interrupt at the next key input.

To continue the Wait command for a specified length of time, enter the settings as follows.



To continue the Wait command until the next key input, enter the settings as follows.



3 An effect effect-less condition with the command input


Refer to Table 4.3-2

4.3.3.5 LOOP (Repetition) command

This command is used in a script program. Commands in a range enclosed by LOOP commands are repeated a specified number of times.

1 Command input

The command format will now be explained with reference to an actual screen display example. Start with the “@>loop” and end with “@>loopend”.



2 An effect effect-less condition with the command input

Refer to Table 4.3-2

4.3.4 Error messages

The following table presents a list of error messages displayed on the TELNET console screen when TELNET remote control is executed.

Table 4.3-25 List of TELNET remote control error messages

| Error messages | Description |
|---------------------------------|---|
| (E)Permission Error | It tried to carry out the command of the ADMIN authority with the USER authority. |
| (E)Already [ADMIN].. | It tried to carry out a SU command under the condition which was already ADMIN authority. |
| (E)Now Online... | A command which is invalid while ONLINE was executed. |
| (E)Now Offline... | A command which is invalid while OFFLINE was executed. |
| (E)Now Remoting... | A command which is invalid while REMOTE was executed. |
| (E)Invalid Parameter Key Word.. | The parameter which couldn't be specified was specified. |
| (E)Invalid Parameter Value.. | The value which couldn't be specified was specified. |
| (E)Can't Disp Parameter.. | The parameter which couldn't be indicated was specified. |
| (E)Not Telnet Mode | AE5501 is not the condition that it waits for the TELNET connection. |
| (W)Already Sending... | A RUN command was executed during transmission. |
| (E)System Error... | System error |
| (E)Can't Get Address... | Unable to acquire address during DHCP or ARP execution. |
| (E)Complete ! | Address acquisition completed during DHCP or ARP execution. |
| (E)Can't RUN.. I/F Mismatch.. | Unable to execute measurement due to I/F mismatch. |
| (E)Undefined Parameter Key Word | An undefined command parameter was specified. |
| (E)Undefined Command Key Word | An undefined command was specified. |
| (E)Over/Under Parameter Range | A value which is outside the range was specified. |

Chapter 4 Operating Instructions

[This page is intentionally left blank.]

Chapter 5 Appendix

5.1 List of Error Messages

The following is a list of error messages that may appear in the message window of this device along with possible solutions to the problems.

Table 5.1-1 List of Error Messages

| Error message | Error type | Remedy | |
|-------------------------|---|---|--|
| ERROR NO.1 | Boot processing error | Reboot the system. | |
| ERROR NO.2 | | | |
| ERROR NO.3 | | | |
| ERROR NO.4 | | | |
| ERROR NO.5 | | | |
| ERROR NO.6 | | | |
| ERROR NO.7 | Link setting error | | |
| ERROR NO.8 | File check error | | |
| ERROR NO.9 | FTP server operation error | | |
| ERROR NO.10 | File error | | |
| ERROR NO.11 | Other system errors | | |
| ERROR NO.12 | Setup details and GBIC implementation status do not match. | | |
| ERROR NO.13 | Network information registration error | | |
| ERROR NO.14 | | | |
| ERROR NO.15 | | | Remote initial processing error |
| ERROR NO.16 | | | Mismatch between data length and buffer write |
| ERROR NO.24 | Run processing error | | |
| ERROR NO.25 | | | |
| ERROR NO.26 | | | |
| ERROR NO.27 | | | |
| ERROR NO.32 | | | |
| ERROR NO.28 | Stop processing error | | |
| ERROR NO.29 | | | |
| ERROR NO.30 | Error during Ping processing | | |
| ERROR NO.31 | Error during reply processing | | |
| ERROR NO.33 | ARP timeout of Ping | | Try to rerun after checking the measuring port connection. |
| ERROR NO.34 | Overflow during running | | Reboot the system. |
| ERROR NO.36 | Error during self-test | | |
| Interface not supported | Cannot run because of interface mismatch | | Check the implementation status of the GBIC. |
| No Result File | There is no measurement results file | | Create a measurement results file. |
| Pull Out GBIC | GBIC is implemented and 1000BASE-T is selected for L1 setting | Pull out the GBIC. | |
| Remote Complete | Remote operation is completed | Exit the Remote screen. | |
| Prm Miss & Modify | Set value is outside the range and the target value is modified | Confirm the modified value when the cursor automatically moves to the modified portion. | |

5.2 Popup Messages

The following is a list of popup messages that may appear in various screen windows of this device.

Table 5.2-1 Popup Messages 1

| Popup message | Description | Remarks |
|---|--|--|
| File Delete? CANCEL OK | This screen is to confirm that you want to delete the result files on the File Select screen. | OK: Delete result files. CANCEL: Return to the File Select screen. |
| System Error Please Power Off | This will appear when a critical system error takes place. | Reboot the AE5501. |
| Set Remote Cable [ENTER] & Retry | This indicates that the measuring port's link is not established. | Connect the remote cable and press the ENTER key again. |
| I/F Mismatch OK | This indicates that the measurement information is different from the implemented interface configuration. | Implement GBIC and confirm the interface information in the measuring configuration. |
| Can't Detect DHCP server | This indicates that IP ADDR SET is set to AUTO on the Remote Setup screen and the remote port link is not established or a DHCP server is not detected on the network. | Recheck the remote network. |
| Init Error Please Retry CANCEL OK | This will appear when an error is detected in remote results. | Repeat the remote processing. |
| System Error Stop Init OK | This will appear when an error occurs during the initial processing of measurement. | Stop measurement and reboot the AE5501. |
| System Error Execute STOP OK | This will appear when an error occurs during measurement. | |
| ARP Miss Execute STOP OK | This will appear if ARP reply is not received during ARP processing in the Ping operation. | Check the line to be measured and retry measuring. |
| File Count 100 Delete OK? CANCEL OK | This will appear if there are already 100 measurement result files when measurement begins. | OK: Deletes the oldest file. CANCEL: Stops measuring. |
| Now Link Down Continue? CANCEL OK | This will appear if there is no link established when measurement begins. | OK: Measurement will continue without an established link. CANCEL: Stops measuring. |
| Rmt Miss Detect! Please Retry! OK | This will appear when an error occurs during remote processing. | Repeat the remote processing. |
| File loss Detec Please Remote OK | | |
| Pull Out Gbic Module! OK | This will appear if 1000BASE-TX measurement information is selected when the GBIC is implemented. | Turn off the power, pull out the GBIC and reboot the system. |
| Really? <VerUP Mode> CANCEL OK | This will appear as the final confirmation request before changing to the VerUP mode. | OK: Transfer to the VerUP mode. CANCEL: Cancel the transfer. |

5.3 List of Consumables

The following is a list of consumables used for this device.

Table 5.3-1 List of Consumables

| Item | Manufacture/supplier | Model | Remarks |
|----------------------|--------------------------------|------------|---|
| Rechargeable battery | Matsushita Electric Industrial | HHR 3XPS | Maximum number of recharging times: 500 |
| CompactFlash | Hagiwara Sys-Com Co., Ltd | CFI-128MDG | |

NOTE

Consumables are not covered by our free warranty service.
Refer to the paragraph of 4.1.3 "Preparing of Power Supply" - 2 "Battery" about replacing battery.
The AE5501 must be sent to our factory in order to replace the CompactFlash.
The manufacturers/suppliers and models of the consumables are subject to change without prior notice.

5.4 The abbreviation of the TELNET command.

5.4.1 The abbreviation list of the setup parameter of the SET command

| Sub-parameter | Basic setup item | Abbreviation1 | Abbreviation2 | Abbreviation3 |
|-------------------|-------------------|---------------|--------------------|---------------|
| test_mode | GENERATE | GEN | | |
| | LATENCY | LAT | | |
| | PING | PIN | | |
| | REPLY | REP | | |
| | LOOPBACK | LOOP | LB | |
| run_mode | RX->TX | R-T | | |
| | RX&TX | R&T | | |
| link:L1 | 10BASE-T_HALF | 10FULL | 10F | |
| | 10BASE-T_FULL | 10HALF | 10H | |
| | 100BASE-TX_HALF | 100FULL | 100F | |
| | 100BASE-TX_FULL | 100HALF | 100H | |
| | 1000BASE-T_FULL | 1000TFULL | 1000TF | 1000T |
| | 1000BASE-SX_FULL | 1000SFULL | 1000SF | 1000S |
| | 1000BASE-LX_FULL | 1000LFULL | 1000LF | 1000L |
| link:flow | OFF | | | |
| | ON | | | |
| link:negotiate | AUTO | AT | | |
| | MANUAL | MAN | | |
| link:crossover | MDI | | | |
| | MDIX | | | |
| | AUTO | AT | | |
| tx_setup:transmit | 10M | 10 | | |
| | 100M | 100 | | |
| | 1000M | 1000 | 1G | |
| tx_setup:tx-mode | constant/count | c/cnt | | |
| | constant/continue | c/con | | |
| | burst/count | b/cnt | | |
| | burst/continue | b/con | | |
| tx_setup:ifg | XXXbit XXX% | | A unit is omitted. | |
| tx_setup:idle | XXXbit | | A unit is omitted. | |
| tx_setup:cnt | XXXbit | | A unit is omitted. | |

| Sub-parameter | Basic setup item | Abbreviation1 | Abbreviation2 | Abbreviation3 |
|----------------------|-------------------|--------------------|--|---------------|
| tx_setup:stop_action | ON | | | |
| | OFF | | | |
| | XXXmin | A unit is omitted. | Action becomes ON automatically by input of value. | |
| tx_frame#:dst_mac | manual | man | | |
| | arp | | | |
| | XX-XX-XX-XX-XX-XX | | A setup becomes MANUAL by inputting address automatically. | |
| tx_frame#:src_mac | manual | man | | |
| | global | gl | | |
| | dhcp | | | |
| | XX-XX-XX-XX-XX-XX | | A setup becomes MANUAL by inputting address automatically. | |
| tx_frame#:dst_ip | manual | man | | |
| | arp | | | |
| | XXX.XXX.XXX.XXX | | A setup becomes MANUAL by inputting address automatically. | |
| tx_frame#:src_ip | manual | man | | |
| | dhcp | | | |
| | XXX.XXX.XXX.XXX | | A setup becomes MANUAL by inputting address automatically. | |
| tx_frame#:error | NONE | NO | | |
| | CRC | | | |
| filter%:sel | OFF | | | |
| | ON | | | |
| filter_init | OR | | | |
| | AND | | | |

| Sub-parameter | Basic setup item | Abbreviation1 | Abbreviation2 | Abbreviation3 |
|----------------|------------------|---------------|---|---------------|
| alarm:rx_frame | OFF | | | |
| | ON | | | |
| | DOWN | D | | |
| | UP | U | | |
| | XXXX | | It is set up in on automatically by input of value. | |
| alarm:err_cnt | OFF | | | |
| | ON | | | |
| | XXXX | | It is set up in on automatically by input of value. | |
| alarm:tx_frame | OFF | | | |
| | ON | | | |
| | XXXX | | It is set up in on automatically by input of value. | |
| arp_reply | OFF | | | |
| | ON | | | |

| Sub-parameter | Basic setup item | Abbreviation1 | Abbreviation2 | Abbreviation3 |
|--------------------------------------|-------------------|---------------|---|---|
| fixed_delay | OFF ON | | | |
| loopback (LATENCY, LOOPBACK) | MAC | | | |
| | MAC+IP | MACIP | | |
| src_mac (PING,REPLY, LOOPBACK) | MANUAL | man | | |
| | GLOBAL | gl | | |
| | ALL | | | |
| | DHCP | | | |
| src_ip (PING,REPLY, LOOPBACK) | manual | man | | |
| | dhcp | | | |
| | XXX.XXX.XXX.XXX | | | |
| subnet_mask | XXX.XXX.XXX.XXX | | When src_ip is specified in DHCP, it can't be set up. | |
| gateway | XXX.XXX.XXX.XXX | | When src_ip is specified in DHCP, it can't be set up. | |
| dst_ip | XXX.XXX.XXX.XXX | | | |
| interval (PING) | 1sec | 1 | | |
| | 5sec | 5 | | |
| | 10sec | 10 | | |
| tx_mode (PING) | continue | con | | |
| | count | cnt | | |
| | XXXX | | | A setup becomes count by inputting value automatically. |
| dhcp src_mac | manual | man | | |
| | global | gl | | |
| | XX-XX-XX-XX-XX-XX | | | A setup becomes count by inputting address automatically. |
| dhcp src_ip | manual | man | | |
| | auto | at | | |
| | XXX.XXX.XXX.XXX | | | A setup becomes count by inputting address automatically. |
| dhcp subnet_mask | XXX.XXX.XXX.XXX | | When src_ip is specified in AUTO, it can't be set up | |
| dhcp gateway | XXX.XXX.XXX.XXX | | When src_ip is specified in AUTO, it can't be set up | |
| arp dst_ip | XXX.XXX.XXX.XXX | | | |

5.4.2 The abbreviation list of the parameter of the result command

| Sub-parameter | Abbreviation1 | Abbreviation2 | Abbreviation3 |
|---------------|---------------|---------------|---------------|
| HEAD | HD | | |
| TIME | TM | | |
| TX_RATE | TRATE | TR | |
| RX_RATE | RRATE | RR | |
| TX_FRM/S | TFRMS | TFS | |
| RX_FRM/S | RFRMS | RFS | |
| TX_BIT/S | TBITS | TBS | |
| RX_BIT/S | RBITS | RBS | |
| TX_ERROR | TERR | TE | |
| RX_ERROR | RERR | RE | |
| CRC_ERROR | CRC | | |
| UNDER_SIZE | UNDER | UD | |
| OVER_SIZE | OVER | OV | |
| ALIGNMENT | ALIGN | AL | |
| COLLISION | COLL | CL | |
| PAUSE_PKT | PAUSE | PS | |
| TX_BYTE | TBYTE | TB | |
| RX_BYTE | RBYTE | RB | |
| TX_FRAME | TFRAME | TFRM | TF |
| RX_FRAME | RFRAME | RFRM | RF |
| IDLE | IL | | |
| ALARM | ALM | | |
| DELAY | DLY | | |
| SRC_IP | SIP | | |
| DST_IP | DIP | | |
| TX_MODE | TXMODE | TMD | |
| INTERVAL | | | |
| LOSS_CNT | LCNT | | |
| LOSS_RATE | LRATE | | |
| ROUND_TRIP | ROUND | | |
| PING | PIN | | |
| ARP | | | |
| TX | TX | | |
| RX | RX | | |
| RATE | RATE | | |
| FRM/S | FRMS | | |
| BIT/S | BITS | | |
| ERROR | ERR | | |
| BYTE | | | |
| FRAME | FRM | | |

5.5 Connection Configuration for AE5730E-installed PC

As mentioned in Section 4.1.5 “Connecting to an AE5730E-installed PC,” the device can be connected in two ways. If you connect the device directly to an AE5730E-installed PC by using a cross cable as shown in the chart below, you must change certain setting items for the PC.




Figure 5.5-1 Direct connection to AE5730E-installed PC

5.5.1 Microsoft® Windows® XP

This section describes the setup procedure for a PC with Microsoft® Windows® XP operating system.

- (a) On the Windows Start menu, select [Control Panel]. The dialog shown in Figure 5.5-2 will be displayed. Click [Network and Internet Connections].




Figure 5.5-2 [Control] dialog

(b) After completing the operation described in (a), the [Network and Internet Connections] dialog will be displayed. Click [Network Connections].




Figure 5.5-3 [Network and Internet Connections] dialog

NOTE

You should keep a copy of the network settings for your PC with the AE5730E TrafficTesterMini Setup Software installed in order to recover it if required.

(c) Double-click [Local Area Connection].




Figure 5.5-4 [Network Connections] dialog

(d) Click [Properties].




Figure 5.5-5 [Local Area Connections Status] dialog

(e) Select [Internet Protocol (TCP/IP)] and click [Properties].




Figure 5.5-6 [Local Area Connection Properties] dialog

- (f) After you complete the operation described in (e), the [Internet Protocol (TCP/IP) Properties] dialog will appear. Set up the [Internet Protocol (TCP/IP) Properties] as shown in Figure 5.5-7 and click [Advanced]. The chart below shows sample values of the [IP Address] and [Subnet Mask]. If any values have been set up previously, it is not necessary to change them.




Figure 5.5-7 [Internet Protocol (TCP/IP) Properties] dialog

(g) When the [Advanced TCP/IP Settings] dialog appears, set it up as follows. Set [IP Settings] as follows.




Figure 5.5-8 Advanced TCP/IP Settings

Set [DNS] as follows.




Figure 5.5-9 DNS Setup

Set up [WINS] as shown in the following chart and then click [OK].




Figure 5.5-10 WINS Setup

- (h) After you complete the settings in (g), click [OK].
- (i) Click [OK] on the dialog shown in Figure 5.5-7.
- (j) Clicking [OK] on the dialog shown in Figure 5.5-6 complete the setup procedure.

5.6 Other Cautionary Notes

5.6.1 Version Upgrading

5.6.1.1 Upgrading from R02.01 or earlier releases to R02.04 or later releases

To upgrade from R02.01 or an earlier release to R02.04 or a later release, it is necessary to reboot the system during the upgrade process.

However, if you use the AE5730E TrafficTesterMini Setup Software for version upgrading, the operation will be performed as an integrated part of the software procedure. In that case, conduct the version upgrade operation as prompted by the application.

The following is a conceptual diagram of the operation. For more information, see the sections related to version upgrade in the AE5730E TrafficTesterMini Setup Software Instruction Manual.




Figure 5.6-1 Conceptual diagram of version upgrade operation

5.6.1.2 Upgrading from R02.04 release to R02.04 or later releases

To upgrade from R02.04 release to R02.04 or a later release (e.g. from R02.04 to R02.05 in the future), set the AE5501 in the version upgrade mode and start the procedure from the AE5730E.

The AE5501 automatically shuts down the system when it determines that the version upgrade procedure is completed. The LCD display will turn off and the PowerLED will blink. The method used for rebooting the AE5501 differs depending on the power supply system.

When the system is powered via AC adapter:

Pull out and insert the AC adapter and press the POWER key for the time required to turn on the power.

When the system is powered by battery:

Open and close the battery cover on the reverse side of the device and press the POWER key for the time required to turn on the power.

5.6.2 Recovery Mode

If file transfer fails during the version upgrade process for any reason, the AE5501 TrafficTesterMini may not be activated even after rebooting the system.

The Recovery mode is a function mode used to reconfigure and correctly reboot the system in such a case.

5.6.2.1 If the System Freezes at the BOOT Logo

In this case, the PowerLED will blink continuously and the system will not be activated even after a minute or two.




Figure 5.6-2 Screen frozen at the BOOT logo

It may be possible to restore the system by conducting the recovery operation from the AE5730E TrafficTesterMini Setup Software.

5.6.2.2 Mode for Manual Recovery

It is possible to manually set the device in a mode that accepts the recovery operation if the device is halted by a system error even after using the ALL DEFAULT function and the boot-up procedure freezes at the AE5501 Boot screen.

Hold the DISP key down while the Boot screen is on until the following screen is displayed and the recovery process is accepted.




Figure 5.6-3 Screen displayed when the system is manually set in the recovery mode

5.6.2.3 Cautionary Note for Recovery Operation

Confirm the following points before conducting the recovery operation.

1 Checking remote lines

The network settings for the remote ports are defined as follows when the AE5501 is booted up.

| | |
|-------------|---------------|
| IP address | 192.168.0.1 |
| Subnet mask | 255.255.255.0 |

The remote port, however, must be connected to the remote network at the time of system boot-up.

It is recommended that the network connection be set as follows for the recovery operation.




Figure 5.6-4 Example of hub connection




Figure 5.6-5 Connection by cross cable

2 Recovery Operation

Perform the recovery operation from the AE5730E TrafficTesterMini Setup Software. For more information, refer to the AE5730E TrafficTesterMini Setup Software Instruction Manual.

3 Completion of Recovery Operation

When the AE5730E TrafficTesterMini Setup Software indicates that recovery is completed, the AE5501 will automatically shut down. Reboot the system using the following procedures.

When the system is powered via AC adapter:

Pull out and insert the AC adapter and press the POWER key for the time required to turn on the power.

When the system is powered by battery:

Open and close the battery cover on the reverse side of the device and press the POWER key for the time required to turn on the power.

It is recommended that the version upgrade process be repeated if the AE5501 is rebooted through the recovery operation (or when the Mode Select screen is displayed). (For more information on version upgrading, see Section 4.2.12.2 "VerUP Screen" or Section 5.5.1 "Version Upgrading.")

5.6.3 Cleaning

This device does not need periodic cleaning.

For remarkable contaminations on the enclosure, key tops and/or the LCD panel of the device, wipe those parts with a soft, clean, damp and tightly wrung cloth.

Ensure that water does not seep inside the device.

Do not use organic solvents such as thinner or benzine because they may deteriorate and/or may discolor those parts of the device.

Chapter 4 Operating Instructions

[This page is intentionally left blank.]

Reference No. AS-84708Y
Issued: September 2007
Rev, 2.1

Address : 2-9-32 Naka-cho, Musashino-shi,
Tokyo, 180-8750 Japan

Yokogawa Electric Corporation

(All rights reserved.)