

Instruction Manual


DL1100

Model 7001

DL1100

Digital Oscilloscope Instruction Manual

IM 7001 - 01E



FOREWORD

Thank you for purchasing this DL1100 digital oscilloscope.

Please read this operation manual through before operating the unit so that you will be able to use all of its functions efficiently and correctly. A thorough understanding of its functions and operations is essential if full justice is to be done to the unit's performance.

SAFETY STANDARDS

This equipment has been designed and tested in accordance with these safety standards mentioned below, and has been supplied in a safe condition.

The present instruction manual contains some information and warnings which have to be followed by the user to ensure safe operation and to retain the equipment in safe condition.

Dieses Gerät ist gemäß den folgenden Schutzmaßnahmen, gebaut und geprüft und hat das Werk in sicherheitstechnisch einwandfreiem Zustand verlassen.

Um diesen Zustand zu erhalten und einen gefahrlosen Betrieb sicherzustellen, muß der Anwender die Hinweise und Warnvermerke beachten, die in dieser Gebrauchsanweisung enthalten sind.

Cet appareil a été construit et essayé conformément aux susnommés règles de sécurité et a été fourni en bon état.

Le présent manuel d'instructions contient des textes d'information et d'avertissement qui doivent être respectés par l'utilisateur pour assurer un fonctionnement sûr de l'appareil et pour le maintenir en bon état en ce qui concerne la sécurité.

700110-1 (100-120VAC):

Certified by CSA

CSA C22.2 No. 231

700110-5 (220-240VAC):

Approved by TÜV Rheinland

DIN 57411 Teil 1/VDE0411 Teil 1

Comply with

HD 401/IEC Publication 348

IEC 1010-1:1990

(Installation Category II,

Überspannungskategorie II,

Categorie d'Installation II)

MACHINE NOISE

Machine Noise information Ordinance 3. GSGV, January 18, 1991: The sound pressure level maximum is equal or less than 70 dB(A) according to ISO 7779.

Maschinenlärminformationsverordnung 3. GSGV, 18.01.1991: Der höchste Schalldruckpegel beträgt 70 dB(A) oder weniger gemäß ISO 7779.

SAFETY PRECAUTIONS

This is a Safety Class I Instrument (provided with terminal for protective earthing).

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific WARNINGS given elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. YOKOGAWA Electric Corporation assumes no liability for the customer's failure to comply with these requirements.

General definitions of safety symbols used on equipment and in manuals.



Explanation: To avoid injury death of personnel or damage to the instrument, the operator must refer to an explanation in the instruction manual.



High voltage terminal: Indicates dangerous voltage (terminals fed from the interior by voltage exceeding 1000 volts must be so marked). Never touch it!



Protective Grounding Terminal: To protect against electrical shock in case of a fault. This symbol indicates that the terminal must be connected to ground before operation of equipment.



Laser radiation

This calls attention to a procedure, practice, condition or the like, which - if not correctly performed or adhered to - could result in loss of eyesight or injury to eyes of personnel.

(CLASS 3A)

Do not stare into this beam or VIEW directly with optical instruments.

(CLASS 3B)

Avoid exposure to this beam.

WARNING

A WARNING sign denotes a hazard. It calls attention to procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in injury or death of personnel.

CAUTION

A CAUTION sign denotes a hazard. It calls attention to procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product.

The numbers at some of the below mentioned warnings and cautions correspond to the numbers at warnings and cautions used throughout this manual.


WARNING

- **Power Supply**
Ensure the source voltage suits the voltage of the power supply before turning on the power.
- **Power Cord and Plug**
To prevent an electric shock or a fire, make sure to use power supply cord and 3 to 2 pin adapter supplied by YOKOGAWA. Main power plug must be plugged in an outlet with protective grounding terminal only. Do not use extension cord without protective grounding wire and invalidate protection.
- **Protective Grounding**
Make sure the protective grounding to prevent an electric shock before turning the power on. 3 pin power cable with grounding wire is used for this instrument. Please use 3 pin power outlet with protective grounding terminal.
When using 3 pin to 2 pin adapter, make sure to connect the grounding wire of the adapter to the protective grounding wire of the power outlet.
- **Necessity of Protective Grounding**
Never cut off the internal or external protective grounding wire or disconnect the wiring of protective grounding terminal. Doing so poses a potential shock hazard.
- **Defect of Protective Function**
Do not operate the instrument when protective grounding or fuse might be defective. Be careful not to operate without noticing the defect.
- 1 ● **Fuse**
To prevent a fire, make sure to use the fuse with specified standard (current, voltage, type). Before replacing fuse, turn off the power and unplug the power cord. Do not use a different fuse or short-circuit the fuse holder.
- **Do not Operate in an Explosive Atmosphere**
Do not operate the instrument in the presence of flammable liquids or vapors. Operation of any electrical instrument in such an environment constitutes a safety hazard.
- **Do not Remove any Covers**
There are some areas with high voltage. Do not remove the cover if the power supply is connected. The cover should be removed by qualified personnel only.
- **External Connection**
To ground securely, insert the main power plug before connecting to measurement or control unit.
- **Maintenance**
If the instrument does not operate normally, and repair is required, contact YOKOGAWA or YOKOGAWA'S sales representative.
- 2 ● **Handling the CRT**
This CRT is in conformity with the requirements specified in CSA and VDE standards. However please avoid rough handling or jarring of the instrument to prevent possible CRT implosion. Breakage of the CRT may cause a high velocity scattering of glass fragments.


3 • Operation Position

There is a ventilation opening in the rear panel. Do not operate the instrument with orientation of the rear panel downward as a possible fire hazard may exist in event of an internal fault.

When circumstances compel it, place a metal plate (or flame-resisting barrier graded UL 94V-1 or better) below the ventilation opening.



Acceptable



Not Acceptable

4 • Connection With Power Supply

- Make sure that the source voltage suits the voltage of the power supply before connecting.
- Before connecting the cord to the power connector, make sure that the power switch on the main unit has been set to OFF.
- To prevent an electric shock or a fire, use the power supply cord supplied by YOKOGAWA. Main power plug must be plugged in an outlet with protective grounding terminal only. Do not use extension cord without protective grounding wire and invalidate protection.
- To prevent a fire, make sure to use the fuse of specified standard (current, voltage, type). Please refer to **page 6 - 4**, clause **6.2.2 "Power Fuse Replacement"**.


CAUTION

5 • Input Terminals

The maximum input voltage for these input terminals is 250V (DC+ACpeak).

To prevent any breakdown in these input circuits, don't connect a higher voltage to the input terminals.

When using AC coupling with a 10M Ω , 10:1 probe, keep in mind that the voltage at the input connector will not be attenuated to 1/10 at the probe tip for DC levels or input signal components below 1Hz (the full DC level passes through to the input connector). Be careful not to let the input voltage at the probe tip exceed 250V (DC+ACpeak) for signal components below 1Hz.

**6 • AL Signal Output Terminal**

This is the CALIBRATION Signal Output Terminal which output a 1kHz, 0 to 1V square wave. It is used to adjust the probe.

7 • Connection with GND-side of Probe

The Low side of the measurement input terminal (BNC connector) is grounded. To prevent the breakdown of the probe, connect GND-side of the probe to the GND of measurement circuit correctly.

Furthermore, the below mentioned warnings can be found on the rear panel of the instrument.

WARNING

TO AVOID ELECTRIC SHOCK, PROTECTIVE GROUNDING CONDUCTOR IN THE POWER CORD MUST BE CONNECTED TO GROUND.

DO NOT REMOVE COVERS, REFER SERVICING TO QUALIFIED PERSONNEL ONLY.

DISCONNECT INPUT POWER BEFORE REPLACING FUSE.

TO AVOID FIRE HAZARD, REPLACE ONLY WITH SPECIFIED TYPE AND RATED FUSE.

TO AVOID FIRE HAZARD, DO NOT OPERATE THE INSTRUMENT WITH THE REAR PANEL FACING DOWNWARDS.

SICHERHEITSHINWEISE

Dieses Instrument ist ein Gerät der Schutzklasse I (mit Klemme zur Schutzerdung).

Die folgenden allgemeinen Sicherheitshinweise müssen jederzeit bei allen Bedienungs-, Wartungs- und Reparaturarbeiten an diesem Instrument beachtet und eingehalten werden. Wenn diese Sicherheitshinweise sowie die in diesem Handbuch ausgesprochenen Warnungen nicht eingehalten werden, stellt dies eine Verletzung der bei Konstruktion, Herstellung und beabsichtigtem Einsatz des Instruments zugrunde liegenden Sicherheitsstandards dar. YOKOGAWA übernimmt keinerlei Haftung für die Nichtbefolgung dieser Vorschriften.

Allgemeine Definition von Sicherheits-Symbolen auf Geräten und in Anleitungen.



Erklärung: Dieses Zeichen weist darauf hin, daß der Bediener eine Erklärung in der Bedienungsanleitung beachten muß, um Verletzungen, Lebensgefahr und / oder Schäden am Instrument zu vermeiden.



Hochspannung: Dieses Zeichen weist auf Hochspannung hin (Dieses Zeichen muß an Klemmen angebracht sein, die Spannungen von mehr als 1000V nach außen führen.) Berühren Sie diese Klemme unter Keinen Umständen.



Schutzerde: Dieses Zeichen kennzeichnet den Anschluß für die Schutzerde. Das Instrument muß geerdet werden, um einen Schutz gegen elektrische Schläge bei Fehlern im Gerät sicherzustellen.



Laserstrahlung

Dieses Zeichen lenkt die Aufmerksamkeit auf Bedienungsabläufe, Eingriffe, Bedingungen oder ähnliches, die, wenn nicht korrekt ausgeführt und beachtet, zum Verlust des Augenlichts oder zu Augenverletzungen führen können.

(Klasse 3A)

Schauen Sie nicht in den Strahl und betrachten Sie den Strahl nicht direkt mit optischen Instrumenten.

(Klasse 3B)

Vermeiden Sie jegliche Berührung mit dem Strahl.

WARNUNG

Eine WARNUNG weist auf eine Gefahr hin und lenkt die Aufmerksamkeit auf Bedienungsabläufe, Eingriffe, Bedingungen oder ähnliches, die, wenn nicht korrekt ausgeführt und beachtet zu Verletzungen oder sogar zum Tode führen können.

VORSICHT

Mit VORSICHT gekennzeichnete Abschnitte weisen auf eine Gefahr hin und lenken die Aufmerksamkeit auf Bedienungsabläufe, Eingriffe, Bedingungen oder ähnliches, die, wenn nicht korrekt ausgeführt und beachtet zu Schäden oder zur Zerstörung des Gerätes oder von Geräteteilen führen können.

Die Nummer die bei den Warnungen angegeben sind, korrespondieren mit den englischen die durchaus diesem Handbuch verwendet sind.

WARNUNG


- **Netzteil**
Vergewissern Sie sich, daß die lokale Netzspannung gleich der angegebenen Betriebsspannung des Geräts ist, bevor Sie das Gerät an die Netzspannung anschließen und einschalten.
- **Netzleitung und -stecker**
Um elektrische Schläge oder Feuer zu verhindern, verwenden Sie ausschließlich das von YOKOGAWA gelieferte Netzkabel.
Verwenden Sie nur Verlängerungskabel, die mit einem Schutzleiter versehen sind.
- **Schutzerde**
Für dieses Instrument wird ein 3-adriges Netzkabel mit Erdleiter verwendet.
- 1 ● **Sicherung**
Um die Entstehung von Feuer zu verhindern, dürfen nur Sicherungen mit den angegebenen Kennwerten eingesetzt werden (d. h. Strom, Spannung und Typ). Vor dem Austausch der Sicherung muß das Instrument ausgeschaltet werden, weiterhin muß der Netzstecker aus der Steckdose herausgezogen werden. Verwenden Sie keine Sicherungen mit anderen als den angegebenen Kennwerten. Insbesondere darf die Sicherung nicht durch eine Kurzschlußstrecke (z.B. Drahtbrücke) ersetzt werden.
- **Instrument nicht in explosiven Atmosphären betreiben**
Betreiben Sie das Instrument nicht in der Gegenwart von brennbaren Flüssigkeiten, Dämpfen oder Gasen. Der Betrieb elektrischer Geräte in derartigen Umgebungen bildet eine Gefahr.
- **Nehmen Sie keine Abdeckungen ab**
In einigen Bereichen des Instruments liegen Hochspannungen an. Nehmen Sie keine Abdeckungen ab, sondern lassen Sie derartige Arbeiten durch einen Servicetechniker ausführen.
- **Externe Anschlüsse**
Um eine sichere Erdung zu gewährleisten, stecken Sie den Netzstecker in eine geeignete Steckdose ein, bevor Sie das Gerät an Meßobjekte oder Steuerungseinheiten anschließen.
- **Wartung**
Wenn das Instrument nicht wie normalerweise funktioniert, und eine Reparatur notwendig ist, benachrichtigen Sie bitte YOKOGAWA oder einen YOKOGAWA-Verkaufsrepräsentanten.
- 2 ● **Bildschirm**
Der Bildschirm entspricht den in den CSA- und VDE-Vorschriften spezifizierten Standards. Bitte beachten Sie jedoch, daß ein unvorsichtiger Umgang mit dem Gerät zur Implosion der Bildröhre führen kann, bei der Glassplitter mit hoher Geschwindigkeit herumfliegen und zu Verletzungen führen können.

3 • Bedienungslage


Das Meßinstrument besitzt eine Belüftungsöffnung in der Rückwand. Durch Befestigen des Meßinstruments mit der Rückwand nach unten kann es bei einem Versagen des Meßinstruments zu einem Brand kommen.

Das Meßinstrument deshalb niemals mit der Rückwand nach unten anbringen.

Wenn das Meßinstrument dennoch in dieser Position angebracht werden muß, eine Metallplatte oder eine unbrennbare Trennwand (Entflammbarkeitsstufe UL 94V-1 oder darüber) unter dem Meßinstrument plazieren.



Genehmigt



Nicht Genehmigt

4 • Anschluß an das Netz

- Überprüfen, ob die Netzspannung der vorgeschriebenen Betriebsspannung entspricht, erst dann das Netzkabel anschließen.
- Vor dem Anschluß an das Netz sicherstellen, daß der Geräteschalter des Meßinstruments ausgeschaltet ist.
- Um einem Stromschlag oder Brand vorzubeugen, nur Netzkabel von YOKOGAWA verwenden.
- Um einem Brand vorzubeugen, nur die vorgeschriebenen Spannungs- und Stromwerte sowie Bauteile bei diesem Meßinstrument verwenden. Für das Auswechseln der Sicherung muß auf den Abschnitt **6.2.2 "Auswechseln der Netzsicherung"** auf Seite 6-4 Bezug genommen werden.


VORSICHT

5 • Eingangsanschluß

Die maximale Eingangsspannung des Eingangsanschlusses weist eine Spitzenspannung von 250V (Gleich- / Wechselspannung) auf.

Wenn Wechselstromkopplung vorliegt, schwächt der 10:1-Tastkopf ein Signal von 1Hz oder darunter selbst bei 10M Ω nicht auf 1/10 am Eingangsanschluß ab.

Deshalb darf ein 1-Hz-Signal (oder darunter) selbst an der Spitze des Tastkopfes 250V Gleich- / Wechsel- Spitzenspannung nicht überschreiten (wechselstromgekoppelter Eingang).



6 • CAL-Signal-Ausgangsanschluß

Hier handelt es sich um den Abgleichsignal- Ausgangsanschluß, an welchem eine Rechteckwelle von 1kHz, 0 bis 1V vorliegt.

Der Anschluß dient zur Einstellung des Tastkopfes.

7 • Anschluß des Tastkopfes am Erdungsanschluß

Die Unten (LOW) -Seite des Meßinstrument-Eingangsanschlusses (BNC-Stecker) ist geerdet. Um eine Fehlfunktion des Tastkopfes zu vermeiden, muß die Prüfspitzen-Masse korrekt am Erdungsanschluß des Meßschaltkreises angeschlossen werden.

Weiterhin gibt es den folgenden Warnungen in English an der Rückseite des Instruments.

WARNUNG

GEHÄUSE BZW. ABDECKUNGEN NICHT ENTFERNEN.
HIERZU NUR QUALIFIZIERTES FACHPERSONAL
HERANZIEHEN.

VOR DEM ERSETZEN DER NETZSICHERUNG
NETZANSCHLUß VOM STROMNETZ TRENNEN.

UM BRANDGEFAHR ZU VERMEIDEN, NUR DEN
ANGEGEBENEN TYP VON SICHERUNG UND
SCHUTZWERT EINSETZEN.

UM BRANDGEFAHR ZU VERMEIDEN, NIEMALS DAS
INSTRUMENT MIT DER RÜCKSEITE NACH UNTEN
VERWENDEN.

UTILISATION EN TOUTE SECURITE

Cet appareil est un instrument de Classe 1, livré avec une borne de mise à la terre.

Les précautions suivantes doivent être prises pendant l'exploitation, la maintenance et les réparations. YOKOGAWA ne pourra en rien être déclaré responsable si ces précautions ne sont pas respectées par l'utilisateur.

Symboles utilisés sur les appareils et dans les manuels d'instruction.



Explication: ce symbole indique que l'opérateur doit se reporter à une explication donnée par le manuel d'instruction afin d'éviter un accident au personnel ou de protéger l'appareil.



Haute tension: tension supérieure à 1000 volts. Ne pas toucher!



Borne de terre: destinée à protéger des chocs électriques en cas de défaut. Ce symbole indique que la borne doit être reliée à la terre avant l'exploitation.



Rayon laser

Ce signe attire l'attention sur une procédure, une manipulation qui pourrait être dangereuse pour les yeux si elle n'est pas effectuée correctement.

(Classe 3A)

Ne pas fixer le rayon ou l'observer avec un instrument d'optique.

(Classe 3B)

Eviter toute exposition à ce rayon.

AVERTISSEMENT

Indique un danger. Attire l'attention sur une utilisation, sur une procédure qui pourrait être dangereuse pour le personnel.

ATTENTION

Indique un danger. Attire l'attention sur une utilisation, sur une procédure qui pourrait être préjudiciable au produit.

Les numéros aux avertissements et aux attentions correspondent avec les numéros d'avertissement et d'attentions dans cette manual d'instruction d'anglais.

AVERTISSEMENT


- **Alimentation**
Vérifier que la tension de l'alimentation est bien la tension requise par l'appareil.
- **Câble d'alimentation et prise**
Afin d'empêcher un choc électrique ou un incendie, utiliser le câble et l'adaptateur à deux ou trois broches fourni par YOKOGAWA. La prise d'alimentation ne doit être branchée que sur une sortie équipée d'une prise de terre.
Ne pas utiliser de rallonge qui ne serait pas équipée de mise à la terre.
- **Mise à la terre**
La vérifier avant de mettre l'appareil sous tension. Si on utilise un adaptateur à deux ou trois broches, introduire la broche de terre de l'adaptateur dans la sortie de terre.
- **Nécessité absolue de la mise à la terre**
Ne jamais sectionner le câble de mise à la terre, qu'il soit interne ou externe, ne jamais le déconnecter.
- **Défaut de protection**
Ne jamais utiliser un instrument dont la mise à la terre ou dont le fusible pourrait être défectueux.
- 1 ● **Fusible**
S'assurer que le type de fusible utilisé est le bon (courant, tension, type). Avant de remplacer un fusible, mettre l'appareil sous tension et enlever la prise.
- **Ne pas utiliser l'appareil en atmosphère déflagrante**
Ne pas faire fonctionner l'appareil à proximité de liquides ou de vapeurs inflammables.
- **Ne pas enlever la protection**
Dans les zones à haute tension, ne pas enlever de boîtier. Seul notre agent est habilité à le faire.
- **Raccord externe**
Pour effectuer une mise à la terre en toute sécurité, raccorder d'abord à la prise d'alimentation secteur avant de raccorder au circuit de mesure ou de contrôle.
- **Maintenance**
Lorsque cet appareil ne fonctionne pas normalement, ou doit être réparé, prenez contact avec YOKOGAWA.
- 2 ● **Précautions concernant l'écran CRT**
Il est conforme aux spécifications CSA et VDE. Eviter les manipulations brusques afin de prévenir les implosions. Le bris d'écran peut entraîner des projections de verre extrêmement rapides.

3 • Position d'opération


L'instrument présente une ouverture d'aération sur sa face arrière. Le fait de mettre l'instrument en appui sur sa face arrière pourrait provoquer un début d'incendie si l'instrument tombait en panne.

Ne pas placer l'instrument en appui sur sa face arrière.

Si l'instrument doit être posé de cette manière, placer une plaque métallique (ou une plaque réfractaire ayant une résistance au feu de UL 94V-1 ou plus) sous l'instrument.



Acceptable



Inacceptable

4 • Brancher l'alimentation électrique


- Vérifier que la tension de l'alimentation électrique est conforme aux spécifications et ne brancher qu'ensuite le cordon d'alimentation.
- Avant de brancher le cordon d'alimentation, s'assurer que l'interrupteur principal est désactivé (OFF).
- Pour prévenir toutes possibilités de choc électrique ou de feu, toujours utiliser le cordon d'alimentation fourni par YOKOGAWA. Brancher le cordon d'alimentation à une prise ayant une borne de mise à la terre. Lorsque le cordon d'alimentation est branché à l'aide de l'adaptateur tripolaire/bipolaire fourni, toujours relier le fil de terre de l'adaptateur à la terre externe pour assurer la protection. Toujours utiliser l'adaptateur tripolaire/bipolaire fourni par YOKOGAWA. Ne jamais utiliser un cordon prolongateur sans fil de terre car ceci n'assurerait pas la protection.
- Pour prévenir toutes possibilités du feu, n'utiliser que des fusibles conformes aux spécifications de l'instrument (intensité, tension et type). Pour le remplacement d'un fusible voir "6.2.2. Remplacement des fusibles" à la page 6-4.

ATTENTION

5 • Borne d'entrée

La tension d'entrée maximale de la borne d'entrée est de 250V (CC+crête CA). Pour prévenir toute panne du circuit d'entrée, ne jamais appliquer une tension supérieure à ce maximum.

Lorsque CA est couplé, même une sonde 10:1 sous $10M\Omega$ n'atténuera pas le signal de 1Hz ou moins à 1/10 de la borne d'entrée. Ainsi, un signal de 1Hz ou moins ne doit pas dépasser 250V(CC+crête CA), et ce même au bout de la sonde pour l'entrée couplée CA.



6 • Borne de sortie CAL signal

Cette borne est la borne de sortie du signal d'étalonnage qui sort une onde carrée de 1kHz, 0 à 1V. Cette borne est utilisée pour le réglage de la sonde.

7 • Brancher la probe à la borne de terre

Le côté bas (LOW) de la borne d'entrée de mesure de l'instrument (connecteur BNC) est mis à la terre. Pour prévenir toutes possibilités de panne de la sonde, relier correctement la terre (GND) de la probe à la borne de terre (GND) du circuit de mesure.

Il y a les sousnommées attentions d'anglais au derrière cette appareil.

ATTENTION ⚠

POUR ÉVITER LES CHOCS ÉLECTRIQUES, RELIER À TERRE LE CONDUCTEUR DE MASSE DU CORDON D'ALIMENTATION.

NE PAS ENLEVER LE BOÎTIER OU COUVERCLES.
CONFIER LE DÉPANNAGE À DU PERSONNEL QUALIFIÉ.

DÉBRANCHER DE L'ALIMENTATION AVANT DE REMPLACER LE FUSIBLE.

POUR ÉVITER LES RISQUES D'INCENDIE, REMPLACER PAR UN FUSIBLE DU MÊME TYPE ET CARACTÉRISTIQUES.

POUR ÉVITER LES RISQUES D'INCENDIE, NE JAMAIS EMPLOYER CETTE APPAREIL AVEC LE DERRIÈRE EN BAS.








OVERVIEW & FEATURES

The DL1100 is a digital oscilloscope with a basic maximum performance of 25MS/s when using 2 channels, and a vertical resolution of 8bits and a repeated frequency of 100MHz.

Features

1. Full range : 2 channels
2. Memory : 32kW / CH
3. A4-size personal use digital oscilloscope
4. Real-time high-speed update rate of 60 displays/sec.

CONTENTS

FOREWORD	1	
SAFETY PRECAUTIONS	2	
OVERVIEW & FEATURES	14	
Chapter 1. BEFORE OPERATION		
1.1 When the Instrument Arrives	1-1	
Chapter 2. COMPONENT NAMES AND CRT DISPLAYS		
2.1 Component Names and Functions	2-1	
2.2 CRT Display	2-8	
2.3 Hierarchical Structure of Menus	2-11	
Chapter 3. OPERATION		
3.1 Vertical Axis Operation	3-1	
3.2 Time Axis Operation (Time / div)	3-12	
3.3 Level Trigger Setup	3-15	
3.4 How to Set Television Trigger	3-26	
3.5 Display Setup 	3-30	
3.6 Accumulate Mode Setting	3-36	
3.7 Data Processing Function ( ACQUISITION Envelope / Averaging / Smoothing / Decimation Setting)	3-37	
3.8 Computation Functions	3-45	
3.9 Cursor Measurement and Waveform Parameter Measurement	3-49	
3.10 X-Y Mode Setting	3-61	
3.11 Window Setting	3-65	
3.12 Waveform Data / Setting Panel Condition Save / Load	3-78	
3.13 Extended Functions 	3-83	
3.14  Key Function	3-103	
3.15  Key Function	3-104	
3.16  Key Function	3-105	
3.17  Key Function	3-106	
Chapter 4. PRINTER (OPTION)		
4.1 Installing and Replacing the Printer Paper Roll	4-1	
4.2 The Built-in Printer (Optional) Use	4-4	
Chapter 5. HP-GL DIRECT PLOTTING		
5.1 Direct Plotter Function	5-1	
5.2 Use of HP-GL Feature	5-2	

1

2

3

3.1

3.2

3.3

3.4

3.5

3.6

3.7

3.8

3.9

3.10

3.11

3.12

3.13

3.14

3.15

3.16

3.17

4

5

6

7

Appendix

Chapter 6. PROBE ADJUSTMENT, INSPECTION AND MAINTENANCE

6.1	Probe Adjustment	6-1
6.2	Inspection and Maintenance	6-2

Chapter 7. SPECIFICATIONS

7.1	Input Section Specifications	7-1
7.2	Trigger Section Specifications	7-2
7.3	Time Axis Specifications	7-3
7.4	Communications	7-3
7.5	Printer	7-3
7.6	Others	7-4
7.7	General Specifications	7-5
7.8	External Dimensional Drawings	7-6

APPENDIX

Appendix A.	Messages	A-1
A.1	Error Messages	A-1
A.2	Messages	A-2

Appendix B.	Relation between Time/div, Sampling Rate, and Memory Length	B-1
B.1	Normal Mode	B-1
B.2	Equivalent Time Sampling Mode	B-2
B.3	At Single Mode (Long)	B-3

1
2
3
3.1
3.2
3.3
3.4
3.5
3.6
3.7
3.8
3.9
3.10
3.11
3.12
3.13
3.14
3.15
3.16
3.17
4
5
6
7
Appendix

Chapter 1. BEFORE OPERATION

This chapter describes preparations to be made before starting the operation of this instrument.

Anyone who has not used this unit before is urged to read this chapter before commencing operation.

◆◆◆◆◆◆◆◆◆◆ ITEMS ◆◆◆◆◆◆◆◆◆◆

Chapter 1. BEFORE OPERATION

1.1	When the Instrument Arrives	1-1
1.1.1	Accessories	1-1
1.1.2	Precautions for Operation	1-2
1.1.3	Connection with Power Supply	1-6
1.1.4	Turning the Power Switch ON and OFF	1-7

1.1 When the Instrument Arrives

When you receive the unit, check that all the accessories are accounted for, and that it has sustained no damage.

1.1.1 Accessories

This instrument comes with accessories shown in Figure 1.1 and listed in Table 1.1. Check to see that they are all properly included. If some are found to be missing or there is a problem with their operation, contact your dealer or nearest YOKOGAWA service center. (See back cover.)




Figure 1.1 Accessories

Table 1.1 Accessories

Number	Item	Part Number	Quantity	Remarks
①	Fuse (7001□□ - 1)	B9858HV	1	250V 4A Medium - Time - Lag UL Listed, CSA Certified
	Fuse (7001□□ - 5)	A1350EF	1	250V 2.5A Time-Lag VDE Approval
②	10 : 1 Voltage probe (10MΩ 1.5m)	700952	2	Refer to operating instructions provided.
③	Instruction manual			Manual for this unit, and communication manual
④	Power cord	A1006WD	1	UL standard
⑤	Power cord	A1009WD	1	VDE standard
⑥	Power cord	A1023WD	1	BS standard
⑦	Power cord	A1024WD	1	SAA standard
⑧	Adapter	A1253JZ	1	JIS standard

Note: When a printer (option) is added to the unit, a roll of printing paper will be provided as an accessory.
If JIS standard grounded cable was specified, UL power code ④ with 3 pin to 2 pin adapter ⑧ would be supplied.

1.1.2 Precautions for Operation

The following items must be complied with if correct and safe operation of this unit is to be ensured.

(1) General Precautions

(a) Keep the top of the unit free from objects.

Do not place any object containing water on top of the unit. In the event that water has seeped into the unit, disconnect it immediately from the power outlet and contact your dealer or nearest service center. Also, do not place any heavy or large objects on the unit.

(b) Before carrying or moving this unit

Ensure that it has been disconnected from the power outlet and that its external connecting cables have also been disconnected.

(c) Maintenance

Do not use benzene, paint thinner or a chemically treated duster to clean the unit's cabinet or control panel since these parts are composed mainly of plastic materials. Instead, use a soft cloth and gently wipe away any dirt or dust.
With stubborn dirt, soak a cloth in a diluted solution of neutral detergent, wring it out and clean. Then take up any remaining moisture with a dry cloth.

(d) Static electricity

Do not bring any object charged with static electricity near the input connectors.

(e) Insecticide sprays

Do not spray the cabinet or control panel with insecticides or other such volatile substances. Do not allow rubber or vinyl products to remain in contact with them for long periods.

(f) After use

Ensure that the power switch is set to the OFF position.

(g) **Long-term suspension of use**

Keep the unit disconnected from the power outlet.

(h) **Avoid shocks to input connectors and probe.**

If a shock is sustained by the input connectors or other such parts, it may be converted into electrical noise and observed as such. Be sure not to administer any shocks while the unit is operating.

(2) **Safety Precautions**

(a) **Do not touch the inside parts.**

Do not remove the unit's upper cabinet. Inside are high-voltage areas and any contact with these parts is not only dangerous but could cause malfunction.

Contact your dealer or nearest service center for all servicing and adjustments.

(b) **In case of malfunction**

It is dangerous to continue using the unit if it emits smoke, abnormal noises or odors or otherwise shows any symptoms of malfunction. Disconnect it immediately from the power outlet and discontinue its use. Contact your dealer or nearest service center.

(c) **Fan**

Fan is mounted at the rear of the unit to reduce the internal temperature rise. Take care not to obstruct the ventilation openings provided on the rear, right and left sides of the cabinet.

(d) **Grounding**

To ensure safety, ground the unit before use. The low sides of the input connectors on the front panel have the same potential as the cabinet.

(e) **Power cord**

Avoid placing heavy objects on the power cord and allowing it to touch any heating device. If the cord is damaged, contact your dealer. The part number of the power cord should be specified. (See page 1-2.)

When disconnecting the power cord plug from a power outlet, do not tug at the cord but take a firm hold of the plug instead and pull.

(f) **Probe**

The Low side of the measurement input terminal (BNC connector) is grounded. To prevent the breakdown of the probe, connect GND-side to the GND of measurement circuit correctly.

(3) **Installation Location**

Avoid installing this unit in the following locations.

(a) **Poor ventilation**

Ventilation openings are provided in the cabinet to prevent the temperature inside the unit from rising too high. Do not install the unit where it will be poorly ventilated.

(b) Exposure to direct sunlight or near heaters

The cabinet and internals will be adversely affected if the unit is exposed to direct sunlight or installed near a heater.

Choose a location where the temperature changes minimally and where it is as close to 23°C as possible.

(c) Excessive soot, steam, moisture, dust, corrosive gases, etc.

Soot, steam, moisture, dust, corrosive gasses, etc. will adversely affect the unit. Avoid locations where they are present.

(d) Near electromagnetic fields

Use of this unit near strong electromagnetic fields may cause distortion in the CRT display. Do not bring magnets or any other device that generates magnetic fields near this unit.

(e) Mechanical vibration

Installing this unit in a location susceptible to a great deal of mechanical vibration will adversely affect the mechanical parts of the unit. It may also prevent the printer (option) from recording properly. Select a location characterized by minimal mechanical vibration.

(f) Unstable surfaces

Choose a flat, stable surface to install this unit. Using the unit at an angle or on an unstable surface will adversely affect the recording results. If the unit falls from a height or is dropped, it will be damaged.

(4) Carrying Instructions

Use the handle on the top of the main body when carrying the instrument.




Figure 1.2

(5) CRT Filter Protective Film

The CRT filter surface was covered with a protective film prior to shipment. Be sure to remove the film before use.

(6) Operating position



3

WARNING

There is a ventilation opening in the rear panel. Do not operate the instrument with orientation of the rear panel downward as a possible fire hazard may exist in event of an internal fault.

When circumstances compel it, lay a metal plate (or flame-resisting barrier graded UL 94V - 1 or better) below the ventilation opening.




Figure 1.3

1.1.3 Connection with Power Supply

Please be sure to read "For the safety use" mentioned in the beginning pages of this instruction manual before using this instrument.

Once the installation location has been determined, connect the accessory power cord to the power connector on the rear panel of the unit as shown in the figure below.




Figure 1.4 Connection with Power Supply

4

WARNING

- Make sure whether the source voltage suits the voltage of the power supply before connecting.
- Before connecting the cord to the power connector, make sure that the power switch on the main unit has been set to OFF.
- To prevent an electric shock or a fire, please use the power supply cord supplied by YOKOGAWA. Main power plug must be plugged in an outlet with protective grounding terminal only. Do not use extension cord without protective grounding wire and invalidate protection.
- To prevent a fire, make sure to use the fuse with specified standard (current, voltage, type).

1.1.4 Turning the Power Switch ON and OFF

The main power switch is located at the rear panel and the power switch is located at the bottom left of the front panel, as shown in the figure below. When the main power switch is set to ON (refer to Figure 1.5), the front panel power switch can be activated. Pressing the power switch firmly once turns power ON, and pressing it again turns power STANDBY (See Figure 1.6).

Once the power has been turned ON, waveforms will appear on the screen within 40 seconds, provided that the unit is functioning properly.




Figure 1.5 Main Power Switch of the Rear Panel




Figure 1.6 Power Switch of the Front Panel

If power to the unit is interrupted, the panel setup parameters including date, time, GP-IB address and saved waveform data immediately before the power failure will be retained in the main unit memory by the battery back-up function. When the power is subsequently restored, measurement will commence under the same panel setup parameters as were immediately before the power failure. If you wish to start measurement with parameters of the initialized status, turn power ON while pressing the **INITIALIZE** key. Note: The unit is shipped from the factory in the initialized status.

Battery backup is provided by a built-in lithium battery which has a service life of approximately 10 years (when used at an ambient temperature of 23°C). When battery voltage falls below normal, "Battery failure" is displayed on the CRT.

For battery replacement, contact us or your nearest YOKOGAWA service shop.

Chapter 2. COMPONENT NAMES AND CRT DISPLAYS

ITEMS

Chapter 2 COMPONENT NAMES AND CRT DISPLAYS

2.1	Component Names and Functions	2-1
2.1.1	Front Panel	2-1
2.1.2	Rear Panel	2-5
2.2	CRT Display	2-8
2.2.1	CRT Display	2-8
2.2.2	Window Display	2-9
2.2.3	CRT Brightness Levels	2-10
2.3	Hierarchical Structure of Menus	2-11

2.1 Component Names and Functions

2.1.1 Front Panel




Figure 2.1 Front Panel Components

① Vertical Range Setting Keys

- ON CH1** : Displays Channel 1 waveform. (Green lamp lights up when Channel 1 is measured.)
- V / DIV** : Enables setting of vertical axis range in Channel 1 by turning the rotary knob.
- ◊ POSITION** : Enables setting of vertical position on Channel 1 by turning the rotary knob.
- INPUT** : Enables setting of Channel 1 input (Coupling, invert, and probe).
- ON CH2** : Displays Channel 2 waveform. (Green lamp lights up when Channel 2 is being measured.)
- V / DIV** : Enables setting of vertical axis range on Channel 2 by turning the rotary knob.
- ◊ POSITION** : Enables setting of vertical position on Channel 2 by turning the rotary knob.
- INPUT** : Enables setting of Channel 2 input (Coupling, invert, and probe).
- ◊ POSITION** : Enables setting of vertical position on waveform 3, computation waveform position, and CH1 expanded waveform position by turning the rotary knob.
- ◊ POSITION** : Enables setting of vertical position on waveform 4 and CH2 expanded waveform by turning the rotary knob.


② Rotary Knob

Rotary knob is used for the settings below.

V / DV (CH1, CH2), TIME / DIV, ◊ POSITION, TRIGGER LEVEL, ZOOM, CURSOR, <>POSITION, TRIGGER DELAY, HOLD OFF TIME, etc.

③ Soft Keys

These select the soft key menu items indicated above the soft keys. The items associated with the soft keys change depending on which menu key is pressed.



④ Horizontal Range Setting Key

- TIME / DIV** : Time axis setting

⑤ Trigger Setting Keys

MODE	:	Sets the trigger mode (AUTO, AT-LVL, NORM, SGL (S), SGL (L)).
SOURCE	:	Sets the trigger source (CH1, CH2, EXT, LINE) and slope (\uparrow , \downarrow , $\uparrow\downarrow$).
COUPLING	:	Sets the trigger coupling (AC, DC, HF-REJ, TV).
LEVEL	:	Sets the trigger level.
<> DELAY	:	Sets the trigger delay.
HOLD OFF	:	Sets the hold-off time.
EXT INPUT	:	Sets the external trigger range.

⑥ Menu Keys

MENU OFF	:	Erases the menu display. The soft key menu is displayed by pressing the menu key.
DISPLAY	:	Sets the display format, controls display brightness, and selects the grid.
ACQUISITION	:	Sets the envelope, averaging, smoothing, decimation, and normal.
X-Y	:	Sets the X-Y display.
ACCUMULATE	:	Sets the afterglow display (Dynamic accumulation).
MATH	:	Sets computation between channels.
MEASURE	:	Sets waveform parameter items and cursor measurement.


⑦ Window Function Setting Keys

MODE	:	Sets the window mode.
<> POSITION	:	Sets the expanded section. (Sets the position desired to be seen through the window.)
SEARCH	:	Sets pattern search.
ZOOM	:	Sets expansion ratio (Window range setting).

⑧ Function Keys


LOCAL / REMOTE	:	Switches the GP-IB remote mode to the local mode. In the local mode, the LOCAL / REMOTE (green) lamp goes OFF.
BW (20MHz)	:	Sets a band limit of 20MHz. (The green lamp on the left side of the key lights up during execution.)
START / STOP	:	Controls the starting and stopping of the measurement operations. (While the data is being acquired, the START / STOP (green) lamp will be ON, and will go out when acquisition stops.)
AUTO SETUP	:	Automatically sets the instrument for optimum.
COPY	:	Enables hard copies to be made simply.
SAVE / LOAD	:	Stores and reads display panel data and stores and calls up the front panel setting status.
MISC	:	Extension functions <ul style="list-style-type: none"> ● Sets communication (GP-IB, RS-232C [Optional]). ● Sets date and time. ● Sets GO / NO-GO (PASS / FAIL) test. ● Self-test, etc. ● Comment.
INITIALIZE	:	Sets all the settings to the initialized status.

- ⑨ **Power Switch (POWER)** : Power ON / STANDBY switch. The power switch is activated while the main power switch is ON.
- ⑩ **CAL Signal Output Terminals** : This normally outputs a 1kHz, 0 to 1V square wave. It is used for probe adjustments.


5  **CAUTION**


The maximum input voltage for these input terminals is 250V (DC+ACpeak).
To prevent any breakdown in these input circuits, don't connect a higher voltage to the input terminals.

When using AC coupling with a 10M Ω , 10 : 1 probe, keep in mind that the voltage at the input connector will not be attenuated to 1/10 at the probe tip for DC levels or input signal components below 1Hz (the full DC level passes through to the input connector). Be careful not to let the input voltage at the probe tip exceed 250V (DC+ACpeak) for signal components below 1Hz.




- ⑪ **CH1, CH2 Input Terminals** : These are all input terminals with signal input impedance 1M Ω . Their frequency bands are DC to 100MHz (When the accessory 10 : 1 probe is used).



6  **CAUTION**

This is the CALIBRATION Signal Output Terminal which output a 1kHz, 0 to 1V square wave. It is used to adjust the probe.

- ⑫ **7-inch CRT** : This CRT has a resolution of 540×432 dots. The waveform display area has 501×401 dots.
- ⑬ **LOCAL REMOTE Lamp** : Lights to indicate that the unit is in the GP-IB remote mode.
- BW (20MHz) Lamp** : Indicates that the band is limited to 20MHz when the lamp is lit.
- TRIG'D Lamp** : Lights up when a trigger is issued.
- START/STOP Lamp** : Lights to indicate that data is being acquired.
- ⑭ **Built-in Printer (Option)** : A hard copy of the CRT screen can be obtained by pressing the front panel  key.
(Top part of main unit)

2.1.2 Rear Panel





Figure 2.2 Rear Panel Components


① TRIGGER OUT

Trigger output terminals. The trigger is output from “H” to “L” TTL level. The output section circuit diagram is shown below.



Timing chart of trigger output is shown below.

Trigger out will be generated at the edge of “H” to “L”.




Trigger delay- t_{dHL} :

$$t_{dHL} \text{ max.} = 300\text{ns}$$

“L” retaining time t_{TL} and “H” retaining time t_{TH} :

$$t_{TL} \text{ min.} = 3\mu\text{s}$$


$$t_{TH} \text{ min.} = 1\text{ms}$$




② **GO/NO-GO (PASS/FAIL) Test Output**

The GO/NO-GO determination result is output in the TTL level.

The output level changes to "L" from "H" when NO-GO is determined. The output section circuit diagram is shown below.



Timing chart of GO/NO-GO test output is shown below.



The time from test start to the occurrence of NO-GO pulse will be random according to test standard.

③ **GP-IB Connector**

24-pin connector for GP-IB (IEEE Standard 488-1978) interface.

④ **RS-232C Connector (Option)**

25-pin connector for RS-232C (EIA RS-232C standard) interface connections.

⑤ **Power Connector**

Connect the accessory power cord to this connector.

⑥ **Main Power Switch**


This is the main power ON / OFF switch. (Even if the power switch is ON, the mainframe does not operate if the front panel power switch is not turned ON.)

⑦ **Power Fuse**

Power fuse (4A, 250V, Medium-Time-Lag) is installed.

2.2 CRT Display


2.2.1 CRT Display



* The rotary knob menu display is shown automatically by pressing the setting and soft menu keys.

2.2.2 Window Display

Part of the waveform captured in the memory can be expanded and displayed by using the window mode. The expansion varies in accordance with the Time/div value. When memory is 10kW, the expansion can be from twice to 1000 times the original size.



In this diagram, the brightness-modulated section on channel 1 is displayed as an expanded waveform on Trace 3.

The expanded waveform on channel 2 is displayed on Trace 4.

- * Only channels 1 and 2 can be used to observe expanded and original waveforms in the window mode. (Refer to pages 3-67 to 3-68.)

2.2.3 CRT Brightness Levels

There are two levels of brightness as shown in Table 2.1. (The afterglow of the waveform display in the accumulate mode can be varied in up to 7 steps. This section describes cases other than those.)

Table 2.1 Waveform Brightness


Brightness	Type of Waveform Display
Bright	<ul style="list-style-type: none"> ● Expanded section of standard waveform ● Waveform loaded from memory ● Waveform subject to measurement
Normal	<ul style="list-style-type: none"> ● Usual waveform display ● Expanded waveform




* When a waveform is printed (optional), a bright waveform is printed out in dark color.




2.3 Hierarchical Structure of Menus




This section describes the hierarchical structure of the menus for each menu key. We suggest that you use this information as an index to Chapter 3, which details the unit's operations.

How to Read the Hierarchical Menu Structures

















< TRIGGER >









<WINDOW>




The menu keys marked by an * are not displayed when the window mode is OFF.













To next page To next page





This hierarchical structure is activated when the MANUAL menu key is selected during X-Y mode execution.













From previous page



To next page

From previous page






Chapter 3. OPERATION







3

This chapter gives detailed descriptions of the instrument's operating procedures. We suggest that you read this chapter carefully in order to exploit to the fullest the functions of the instrument.

ITEMS

Chapter 3. OPERATION

3.1	Vertical Axis Operation	3-1
3.1.1	How to Display Each Channel's Input Waveform	3-2
3.1.2	How to Set Coupling (Coupling)	3-3
3.1.3	Matching Read-Out Value and Probe Attenuation (Probe)	3-5
3.1.4	Vertical Axis Sensitivity Setting (Volt/div)	3-6
3.1.5	To Change Vertical Axis Sensitivity Continuously (Variable)	3-7
3.1.6	How to Move the Waveform Position (Position)	3-8
3.1.7	How to Invert Waveform Polarity (Invert)	3-9
3.1.8	How to Display the Waveform Amplitude in Half Size	3-10
3.1.9	How to Add DC Voltage to Input Signals	3-11
3.2	Time Axis Operation (Time/div)	3-12
3.2.1	Time Axis Settings (Time/div)	3-12
3.3	Level Trigger Setup	3-15
3.3.1	Trigger Source Selection for Level Trigger (Source)	3-16
3.3.2	Trigger Mode Selection for Level Trigger (Mode)	3-17
3.3.3	How to Set Level Trigger Coupling (Coupling)	3-19
3.3.4	Level Trigger Slope Selection (Edge)	3-21
3.3.5	Level Trigger Level Setting (Level)	3-22
3.3.6	How to Set Hold-Off Time	3-23
3.3.7	Trigger Delay Setting (Delay)	3-24
3.3.8	How to Set Range and Probe Attenuation of External Trigger ...	3-25
3.4	How to Set Television Trigger	3-26
3.5	Display Setup 	3-30
3.5.1	Interpolation (Dot Connection/Interpolation)	3-31
3.5.2	Grid Setting	3-33
3.5.3	Screen Intensity of Brightness Adjustment	3-35
3.6	Accumulate Mode Setting	3-36
3.6.1	How to Overwrite Waveforms (Accumulate)	3-36

3.7	Data Processing Function	
	(^{ACQUISITION}  ACQUISITION Envelope / Averaging / Smoothing	
	/ Decimation Setting)	3 - 37
3.7.1	How to Display in Normal Mode (NORM)	3 - 38
3.7.2	Displaying in Envelope Mode (ENV)	3 - 39
3.7.3	Averaging (Average)	3 - 41
3.7.4	Performing the Smoothing Function (SMOOTH)	3 - 42
3.7.5	Waveform Decimation and Display	3 - 43
3.8	Computation Functions	3 - 45
3.8.1	To Display Computed Waveform between Channels	3 - 46
3.8.2	How to Shift CH2 Phase	3 - 48
3.9	Cursor Measurement and Waveform Parameter Measurement	3 - 49
3.9.1	Waveform Parameter Auto Measurements	3 - 50
3.9.2	How to Set the Read-Out Cursor	3 - 55
3.9.3	Voltage Axis Cursor Setting	3 - 57
3.9.4	Time Axis Cursor Setting	3 - 59
3.10	X-Y Mode Setting	3 - 61
3.10.1	How to Observe Waveforms in the X-Y Mode	3 - 61
3.10.2	How to Operate the Cursor in the X-Y Mode	3 - 62
3.11	Window Setting	3 - 65
3.11.1	How to Expand and Display Waveform	3 - 67
3.11.2	How to Use the Search Function	3 - 71
3.11.3	How to Use the Window in the Long Single Mode	3 - 76
3.12	Waveform Data / Setting Panel Condition Save / Load	3 - 78
3.12.1	How to Save Waveform Data to Built-in Memory	3 - 79
3.12.2	How to Load Waveform Data from Built-in Memory	3 - 80
3.12.3	Saving Panel Setup Parameters	3 - 81
3.12.4	How to Load Panel-Setting Conditions	3 - 82
3.13	Extended Functions (^{MISC} )	3 - 83
3.13.1	Date and Time Settings	3 - 84
3.13.2	To Turn Off Read Out Value Display	3 - 86
3.13.3	GO / NO-GO (PASS / FAIL) Test Function	3 - 87
3.13.4	Self-Test	3 - 98
3.13.5	Display Comment on CRT	3 - 101
3.14	(^{BW} ) Key Function	3 - 103
3.15	(^{AUTO SETUP} ) Key Function	3 - 104
3.16	(^{START STOP} ) Key Function	3 - 105
3.17	(^{INITIALIZE} ) Key Function	3 - 106

NOTES

※ The following explains how to read this operation section.

Soft key menu

Operations are described here.


3 - 42

3.7.3 Averaging (Average)

The averaging functions are used to eliminate noise (random noise affecting repetitive waveforms) superimposed on the input signals.

The highest weighting is given to the newest data by the assigned time constant, and the weighting is reduced exponentially and averaged for the past data in sequence.

[Soft key operations]




[Description]

- ① Press the **ACQUISITION** key.
- ② Select **AVG** in Acquisition set menu.
- ③ Set the time constant by turning the rotary knob. The time constant can be varied in the increment of 2^n steps from 2 to 256.

Rotary knob menu display

Soft key menu

Soft Keys



Rotary knob

MEMO

(1) Algorithm of Exponential Averaging
The exponential averaging algorithm is:

$$A_n = \frac{1}{N} \{ (N-1) A_{n-1} + X_n \}$$



Where A_n : Average value on nth cycle
 X_n : Input value on nth cycle


Soft keys

The MEMO area states restrictions and detailed descriptions for individual items.

EXAMPLE

※ The keys are indicated by the symbols shown below.

 : Menu keys, function keys  : Rotary knob


 : Soft keys

※ This instruction manual uses the values in the table below so as to be easily understood.

No. of points described	500	1k	2k	2.5k	4k	5k	8k	10k	20k	25k	50k	100k
Actual No. of points	501	1,002	2,004	2,505	4,008	5,010	8,016	10,020	20,040	25,050	50,100	100,200

3.1 Vertical Axis Operation


The procedure for vertical axis operations is as follows :

**3.1**

3.1.1 How to Display Each Channel's Input Waveform

The measured waveform of each channel is displayed after measurement of the signal entering through each channel's input terminal is started.

[Soft key operations]




[Description]

Depending on the channel to be measured, press the **ON CH1** or **ON CH2** keys.

The LED lamp on the left side of the pressed key lights up and then the input waveform is captured for display.

Soft Keys

The lamp lights up when the signal is captured (ON status).



MEMO







- (1) Up to 4 waveforms can be displayed at the same time.
CHs 1 and 2 can be always displayed, and Traces 3 and 4 may be substitute-displayed for other waveforms by* various operations or not displayed at all.
* Waveform computation, window, X-Y display, etc.
- (2) The maximum sample rate varies with the number of LEDs lit (number of channels in use). ----- Refer to page 3-13.


3.1.2 How to Set Coupling (Coupling)





There are 4 kinds of couplings in each channel : DC, AC, DC-ADD and GND.

[Soft key operations]

[Description]

- ①  Press the **INPUT** key of the channel to be set.
- ②  Set the coupling by pressing the soft key on the soft key menu Coupling.
There are 4 kinds of coupling ; , ,  and .



- ③  When DC-ADD is selected, DC voltage can be added to the input signal. The voltage is set by turning the rotary knob. Also, when  is selected by the soft key after DC-ADD is selected, 1 div DC voltage per click is applied. Detailed settings can be made with the  key. (Pressing the  key returns the present display panel to the previous menu.) The applied voltage range is as shown in Table 3.1.1.




Table 3.1.1 Applied DC Voltage Range

Voltage Range (Volt/DIV)	Applied DC Voltage Range
2mV 5mV 10mV 20mV	-500mV to +500mV
50mV 100mV 200mV	-5V to +5V
500mV 1V 2V 5V	-20V to +20V

Note : This table is for a 1 to 1 probe. When a 10 to 1 probe is used, both the voltage range and the applied DC voltage range increase tenfold. When a 100 to 1 probe is used, the above two increase 100 times.

MEMO

The coupling is set up according to the probe used and the signals to be observed.

- 1. DC (1M Ω)** All the frequency components of the input signal are coupled to the vertical axis. The signal input impedance is 1M Ω with respect to ground, and the frequency characteristic is as shown on the right. Frequency bandwidth is DC to 100MHz (-3dB point) when the standard accessory probe is used.





Figure 3.1.1 Frequency Characteristic for DC Coupling

- 2. DC-ADD** DC voltage can be added to the input signal. Other information is the same as for DC coupling.







Figure 3.1.2 Frequency Characteristic for AC Coupling

- 3. AC** The input signal is coupled to the vertical axis through a capacitor. The lower frequency characteristics give -3dB at or below 10Hz when a 1:1 probe is used, and -3dB at 1Hz or below when the standard accessory 10:1 probe is used.




- 4. GND** The vertical axis circuit is coupled to ground, and the ground level appears on CRT. (If the normal trigger mode is used, triggering does not occur and the display is not updated.)



NOTE


At AC coupling, even if measurement is done with the 10M Ω 10 to 1 probe, an input signal of less than 1Hz is not attenuated to 1/10 at the oscilloscope's input terminals. Therefore, make sure that a signal component of less than 1Hz does not exceed the maximum input voltage of $\pm 250V$ (DC+AC peak) at the tip of the probe.



3.1.3 Matching Read-Out Value and Probe Attenuation (Probe)

Using the soft keys, set up the instrument for the attenuation ratio of the probe used. Selection can be made: 1 : 1, 10 : 1, 100 : 1


[Soft key operations]



[Description]


- ① Press the key of the channel to be set.
- ② Use the soft key to select the probe value corresponding to the attenuation ratio of the probe to be used. Every time the soft key is pressed, the attenuation ratios of , and change cyclically.

This setting ensures that the screen read-out values match the input value.









MEMO

The following oscilloscope probes are available.




- The probe value in the menu is selected according to the attenuation ratio of the probe to be used. (When connecting the accessory probe to the input connector, set the probe value to 10 : 1.) Refer to the accessory operation manuals for details on other probes.

3.1.4 Vertical Axis Sensitivity Setting (Volt/div)






[Soft key operations]	[Description]
① 	① Press the  key according to which channel is to be set up.
② 	② Use the soft key to select  , when  is selected in the V/DIV menu.
③ 	③ The vertical axis sensitivity can be changed by turning rotary knob 1. The sensitivity ranges are 2mV/div to 5V/div. Sensitivity changes cyclically in increments of 1, 2 or 5. (If the probe is set to 10 to 1 or 100 to 1, the V/div value increases by a factor of 10 or 100, respectively.)

Note: When the HALF Size (1/2 Size) is ON, the sensitivity ranges are 4mV/div to 10V/div and the sensitivity changes cyclically in increments of 1, 2, and 4.




3.1.5 To Change Vertical Axis Sensitivity Continuously (Variable)

The vertical axis sensitivity varies in 1-2-5 steps, although the step intervals can be changed continuously.

[Soft key operations]	[Description]
<p>① </p> <p>② </p> <p>③ </p>	<p>① Press the  key of the channel to be set.</p> <p>② Select the  soft key on the soft key menu V / DIV to enter the Variable mode.</p> <p>③ Change vertical axis sensitivity by turning the rotary knob. Note that the rotary click feeling becomes less noticeable.</p> <p>Variable range are from 1 / 2.5 to 2.5 times for each range.</p>


MEMO

- (1) When the VAR setting is ON, the CH display in the upper part of the waveform display area is as follows to show that the value is not the calibrated voltage value.
Example :
CH1 > 1V ... When a VARIABLE value is larger than the range value.
CH1 = 1V ... When a VARIABLE value is equal to the range value.
CH1 < 1V ... When a VARIABLE value is smaller than the range value.
- (2) The value measured by the measuring function in the VARIABLE mode becomes the calibrated value.
- (3) When the trigger mode is long single mode, if there is no size expansion on the window, VAR setting is invalid.








3.1.6 How to Move the Waveform Position (Position)

[Soft key operations]



[Description]


- ① Press the  key of the channel to be set.
- ② Enter the Step by pressing the soft key.
 When  is selected, the waveform moves 1div on the CRT corresponding to one step of the rotary knob.
 When  is selected, the waveform can be moved continuously by turning the rotary knob.
 The moving span is $\pm 8\text{div}$ from the center of the CRT. However, the moving span becomes $\pm 4\text{div}$ when 1/2 Size is ON.



3.1.7 How to Invert Waveform Polarity (Invert)


The input signal can be inverted to the GND position.

[Soft key operations]



[Description]

- ① Press the key of the channel to be set.
- ② Press the soft key on the invert soft key menu to activate . Pressing the key again turns it . When the invert is turned ON, the channel display on the right side of the waveform display area inverts (1 → **1**).



MEMO

- (1) Channel waveform computation and measurement with the invert ON are performed with respect to an inverted waveform. When the trigger mode is the Single Mode (Long), no inverse is used after waveform data has been captured. The same applies after the measurement is stopped in the equivalent-time sampling mode.

Example :

MEASURE value CH1 → Invert ON → -CH1



Computation value CH1+CH2 → CH1 Invert ON → -CH1+CH2 waveform

- (2) The waveform which is not within $\pm 5\text{div}$ from the center of the CRT can not correctly be inverted.



3.1.8 How to Display the Waveform Amplitude in Half Size


The half-size function displays the waveform shown on the CRT in half size. Waveform display resolution on the CRT can be changed from the usual 25 LSB/div to a higher resolution of 50 LSB/div.

[Soft key operations]

- ① 
- ② 


[Description]

- ① Press the  for any channel.
- ② Select the  soft key on the 1/2 Size soft key menu.



MEMO

(1) Half-size function



The usual waveform is displayed at a resolution of 25 LSB/div*. Since CRT waveform display is made at 8 div in this case, the actual display will be 200 LSB. As the resolution of the A-D converter of the instrument is 8 bits, the input signal is output by the 256 LSB level digital value. Therefore, except for the waveform display, 56 levels exist. When a waveform is desired to be displayed including this range, the half-size function is used. When the half-size key is ON, the waveform is displayed at a resolution of 50 LSB/div, then within the range of approximately 5 div. Thus, the waveform can be observed by effectively using A-D converter resolution.

When the half-size key is ON, the voltage range becomes twice as large.

*: LSB (Least Significant Bit) ... A-D converter resolution

3.1.9 How to Add DC Voltage to Input Signals

When DC-ADD is selected at coupling setting, the offset voltage can be added to the input signal.

Refer to this item when setting the coupling.

MEMO

When the offset voltage is changed, the trigger may be off, the measure value corresponding to the offset amount may vary, and the computed waveform may change.


3.2 Time Axis Operation (Time / div)

The time axis is operated by the $\overset{TIME/DIV}{\text{key}}$ key.


3.2.1 Time Axis Settings (Time / div)

[Soft key operations]


[Description]



- ① Press the $\overset{TIME/DIV}{\text{key}}$ key.
 ② Set the time axis by turning rotary knob. The time can be switched in the range from 10ns/div to 50s/div.



The sampling mode (Refer to MEMO.) changes with Time/div value.



- * When the Time/div value is smaller than 100ms/div, the sampling mode is determined by the trigger mode.
 When the trigger mode is auto, auto-level or single (short), the sampling is in the roll mode, and the trigger mode, normal. When the trigger mode is single (long), the sampling mode is normal.

Figure 3.2.1 Time/div Value and Sampling Mode

MEMO

Each sampling mode is described below.

1. Real-time Sampling Mode (Normal Mode)

The analog input signals are converted into digital data and displayed on the screen. Single and repeated signals can be observed up to a 1 / 2.5 sampling rate.



3.2

Table 3.2.1 Relationship between Time/div Value, Data Length and Sampling Rate at Normal Sampling (Other than in the Single Trigger Mode)

Time / div value No. of channels in use	50s to 100μs	50μs	20μs	10μs	5μs	2μs
1, 2	10kW sampling rate changing in steps of 1-2-5 in accordance with Time/div values from 20S/s to 10MS/s.	10kW 20MS/s	4kW 20MS/s	2kW 20MS/s	1kW 20MS/s	500W 25MS/s

Note: Data length / sample rate

Note that all the data lengths of each sampling rate are P-P compressed and displayed on the CRT. (For details, refer to Appendix B-1.)

2. Equivalent Time Sampling Mode (Repetitive Mode)

When the input signal is a repetitive signal, a single display waveform is built up from a number of repeat waveforms. (This mode cannot be used for one-shot waveforms.) Repetitive signals can be observed up to 100MHz (-3dB point).

For the relationship between the sampling rate and the data length when equivalent time sampling is used, refer to Appendix B-2.


Note : When equivalent-time sampling is used, no window operation, computation, or inverse are available while measurement is stopped (START / STOP LED is OFF).

If they are executed, the waveform is eliminated although the data remains in memory.


3. Roll Mode

The roll mode can be used when the time axis is slow. The roll mode is used when the Time/div value is 100ms to 50s and the trigger mode is automatic or auto-level. If a trigger is issued with the single mode shorted (after 10kW of data is captured), the roll mode stops.

Regardless of the trigger, the waveform is displayed as a moving waveform in the roll mode.



In the roll mode, the screen appears like a scroll being turned.



In the roll mode, the screen appears like a scroll being turned. Data captured in Step ① is displayed from the rightmost of the screen. Note that the data previously captured remains on ①.

The sampling rate changes with a memory of 10kW in the roll mode. (As in the normal mode).


The following is the restriction in the roll mode.

Averaging functions can not be used.

3.3 Level Trigger Setup


The following describes the procedure for the level trigger setup.

A level trigger is a signal which becomes a trigger source. It is triggered by determining its level and slope.


3.3


3.3.1 Trigger Source Selection for Level Trigger (Source)

[Soft key operations]




[Description]

- ① Press the SOURCE key.
- ② Select the trigger source from CH1, CH2, EXT, and LINE using the soft keys. Trigger signals are extracted from a commercial power frequency (50Hz or 60Hz) by selecting the LINE soft key.










3.3.2 Trigger Mode Selection for Level Trigger (Mode)

[Soft key operations]



[Description]

- ① Press the  key.
- ② Select the trigger mode from , , ,  and  using the soft keys.



MEMO

(1) Auto Mode

If the trigger signal occurs within a fixed time (called the “time-out” time), the waveforms are displayed in synchronization with the trigger signal, and after the time-out time (approx. 1 / 60s ($\approx 16.6\text{ms}$)) they are acquired and displayed automatically. Since it is not possible in the Auto mode to trigger waveforms which have a period in excess of the time-out time, they should be measured in the Normal mode.

(2) AT-LVL (Auto-Level) Mode

When there is a trigger signal, trigger level setting is the same as the auto mode, but if no trigger signal is available, the signal's center value is detected by the input signal and then the trigger level is automatically set to the center value.

Therefore, if there is enough amplitude in the input signal to be triggered, the trigger can be issued without setting the trigger level.

When Time/div value is less than 100ms, the mode becomes the roll mode.


When two or more channel waveforms are being observed, no auto-level trigger is functional.

(3) Normal

Waveforms are acquired and displayed only if a trigger signal is present. Nothing is updated if there is no trigger signal.

(4) SGL (L), SGL (S) (Single)

As in the Normal mode, waveforms are acquired and displayed only if a trigger signal is present. However, the trigger signal is accepted only once.

To resume acquisition and display, press the  key and reset the trigger ready status. In the trigger ready status, a message of “Waiting for Trigger” is displayed in the screen.

There are 2 modes in the single mode, short and long, and the data length applied to the data varies with the mode.

- **Long Single Mode (SGL (L))**

When the long single mode is provided, the data length is 32kW and No. of display points is 20kW or 25kW.

It is described in Table 3.3.1. (For the relationship to Time/div, refer to Appendix B-3.) The long single mode operating Time/div is between 50s to 100 μ s.

Table 3.3.1 Relationship Between the Number of Channels in Use, Data Length and Display Points When the Long Single Mode is Provided

No. of Channels in Use	Data Length	No. of Display Points
1, 2	32kW	20kW or 25 kW

Note: Data other than that shown on the display can be extracted through a GP-IB communication interface. (No display is shown.)

- **Short Single Mode (SGL (S))**

When the short single mode is provided, the data length can be displayed by capturing only 10kW waveforms in the same way as normal capturing. Since display and computation processing can be performed only by hardware in the short single mode, it can display and process faster than in the long single mode.

For 100ms/div to 50s/div: It is in the roll mode until a trigger is applied.










Note: When the sampling mode is the equivalent time sampling mode (REP), SGL (L) and SGL (S) cannot be executed.


3.3.3 How to Set Level Trigger Coupling (Coupling)

Coupling between the input signal and trigger circuit is set.

[Soft key operations]

[Description]

- | | |
|---|---|
| <p>① </p> <p>②   </p> | <p>① Press the  key.</p> <p>② Set trigger coupling with the soft key. Trigger coupling is selected from ,  and . ( means television trigger. Refer to page 3-26.)</p> |
|---|---|



MEMO

Trigger Coupling




Figure 3.3.1 Trigger Coupling

Trigger coupling connects the input signal and the trigger circuit in the configuration as shown above.

The frequency features of each type of trigger coupling are shown in Figure 3.3.2.

(1) DC Coupling

To be triggered by the trigger source signal's DC level. Difficult to trigger when the DC level fluctuates.

(2) AC Coupling

The trigger source signal is coupled to the trigger circuit through a large capacitor. When AC is coupled, set the trigger level to 0V since the DC component is omitted. If there is enough amplitude in the input signal, the trigger is applied without fail.

(3) HF-REJ

The input signal is coupled to the trigger circuit via a large capacitor and resistor. The high frequency component of the input signal is eliminated and then the signal is input to the trigger circuit.






Figure 3.3.2 Frequency Characteristics of Trigger Coupling


3.3.4 Level Trigger Slope Selection (Edge)

Rise, Fall and Both are available as trigger slope settings.

[Soft key operations]

[Description]


- | | |
|---|--|
| <p>① </p> <p>② </p> | <p>① Press the ^{SOURCE} key.</p> <p>② Select \uparrow \rightarrow \downarrow \rightarrow \uparrow \downarrow (Rise, Fall or Both) as the trigger slope by turning a rotary knob.
In \uparrow \downarrow (Both), triggering occurs on both rising and falling edges.</p> |
|---|--|





Note : When the trigger slope is \uparrow \downarrow , a trigger may not be issued at both slopes.
In that case, adjust the hold-off time.


3.3.5 Level Trigger Level Setting (Level)

[Soft key operations]




[Description]

- ① Press the  key.
 - ② Set the level with a rotary knob.
- The setting range for the trigger level is $\pm 8\text{div}$. The trigger level resolution is 0.02div . The trigger level is displayed in the left side of waveform displaying area by  .



MEMO

Trigger level is set $\pm 8\text{div}$ from the center of the CRT.




The set-point is stored even if V / div is changed, although voltage to be input to the trigger comparator is restricted to 8div from the center of the CRT.



3.3.6 How to Set Hold-Off Time


The time required to hold off the trigger circuit can be set between the trigger point and the next valid trigger point.

[Soft key operations]




[Description]

- ① Press the  key.
- ② Select the  soft key on Hold off soft key menu.
- ③ Set the hold-off time by turning the rotary knob.
The hold-off time can be set to up at approximately 160ns to 80ms.



MEMO

Hold-Off Time




For the usual data display routine, the next routine runs by the first trigger pulse generated after the routine is captured, processed and displayed. However, if hold-off time is set, the trigger generated within the specified time is ignored, so when hold off time is set as shown in the figure, the waveform whose time is different from the usual data display routine is shown. (When the Hold off is set to OFF, the hold-off time becomes approximately 300 μ s.)



Note: In equivalent-time sampling, the waveform display may delay depending on the hold-off time setting. In that case, set the Hold-off time to OFF or reset as required.


3.3.7 Trigger Delay Setting (Delay)

[Soft key operations]



[Description]

- ① Press the  key.
- ② Select the delay with a rotary knob.
 Trigger delay is displayed with a mark () in the upper part of the waveform display area.



MEMO

Trigger Delay

The trigger delay determines where the memory starting point is positioned relative to the trigger point.







Figure 3.3.3 Trigger Delay



Pre-trigger section is a waveform data prior to the trigger point in the acquisition memory. Post-trigger section is a waveform data after the trigger point in the acquisition memory.

Since the instrument displays data in entire data length on the CRT (except for Single Mode (long)), the left side data from the trigger point with the mark () is a pre-trigger and the right side, a post-trigger. Post-trigger and pre-trigger data volume can be changed by changing the trigger delay. The pre-trigger can be set from 0 up to 100% of data length using the trigger delay. When ONLY is selected in the window mode, the trigger position may be out of the display range of the CRT. In this case, the  or  mark is displayed on the outside of the upper left or right part of the waveform display frame when the trigger position is on the left or right side of the CRT, respectively.


Note: When trigger mode is captured by the SGL (L), the trigger delay value can be set only by using the data displayed on the CRT.


3.3.8 How to Set Range and Probe Attenuation of External Trigger

[Softkey Operations]



[Description]

- ① Press the  key.
- ② Select the EXT trigger range by soft key.
 The EXT trigger range changed by probe attenuation.
 1:1 → ±0.5V / ±5V
 10:1 → ±5V / ±50V
 100:1 → ±50V / ±500V
- ③ Select the EXT trigger probe attenuation by soft key.
 The EXT trigger range changed by probe attenuation.
 1:1 → ±0.5V / ±5V
 10:1 → ±5V / ±50V
 100:1 → ±50V / ±500V



3.4 How to Set Television Trigger

(1) Outline

The video signal structures two fields for one display panel (one frame). In the NTSC system, for example, one field is composed of 262.5 lines.

Therefore selecting either even or odd numbered fields and specifying the line number makes it possible to observe the signal scanning from left to right on the display panel.

In the instrument's television trigger function, the required section's video signal can be observed by setting either the even or odd numbered field and specifying the line number to issue a stable trigger.

The video signal to be observed by the instrument's television trigger function corresponds to each of the M, B, G, H, I, D, K and N broadcasting methods.


Table 3.4.1 Broadcasting Method with a Video Signal Corresponding to a TV Trigger

Method	Contents of Method	Method	Contents of Method
M/NTSC	Method M 525 lines/60-field method Image band width 4.5MHz Image modulation method VSB negative modulation Voice carrier frequency Image +4.5MHz Voice modulation method FM Channel band width 6MHz Upper/lower wave band width +4.2 / - 0.75MHz	I/PAL	Method I 625 lines/50-field method Image band width 5.5MHz Image modulation method VSB negative modulation Voice carrier frequency Image +6MHz Voice modulation method FM Channel band width 8MHz Upper/lower wave band width + 5.5 / - 1.25MHz
B, G, H /PAL	Method B 625 lines/50-field method Image band width 5MHz Image modulation method VSB negative modulation Voice carrier frequency Image +5.5MHz Voice modulation method FM Channel band width 7MHz Upper/lower wave band width +5 / - 0.75MHz Method C Channel band width differs from that of method B. Channel band width 8MHz The others are the same as method B. Method H Lower wave band width differs from that of method G. Upper/lower wave band width + 5 / - 1.25MHz The others are the same as method G.	D, K /PAL	Method D 625 lines/50-field method Image band width 6MHz Voice carrier frequency Image +6.5MHz Upper/lower wave band width +6 / - 0.75MHz Method K With regard to a image synchronous signal, the same as method D.
		M/PAL	Refer to M / NTSC.
		N/PAL	Method M band 625 lines/50-field version.

(2) Operation Procedure

[Soft key operations]

[Description]






- ① Press the SOURCE key.
- ② Select the trigger source by pressing the soft key. (When TV is selected by trigger coupling after LINE are selected, the trigger source is automatically changed to CH1.)




- ③ Set trigger polarity to \uparrow (rise) or \downarrow (fall) by turning the rotary knob, then match the input synchronous video signal polarity. When the signal is as shown in the figure below and positive or negative, the trigger polarity is set to \uparrow or to \downarrow respectively.

Note : If trigger coupling is set to TV, SLOPE is changed to POLARITY, although the polarity set does not change.

3.4










- ④ Press the MODE key.
- ⑤ Set the trigger mode by pressing the soft key.





[Soft key operations]

[Description]



- ⑥ Press the  key.
- ⑦ Select the  soft key on the Trigger Coupling soft key menu.
- ⑧ TV field items are shown on the soft key menu. Select soft key  or  . When  or  is selected, synchronization is made in the even or odd numbered field, respectively. (Refer to MEMO.)
- ⑨ Set the line number in the field by turning the rotary knob. The line number can be set from 0 to 1023. (No trigger may be enabled if the line number exceeds the number of lines in the field.)



Note : When necessary, the waveform's horizontal position can be changed for observation by pressing the  key.

MEMO

DL1100 TV Trigger Circuit Operation

In the instrument's TV trigger, the odd field (1) and the even field (2) are detected as follows.

Odd field "1" detection

The field in which vertical synchronous start time and line start time are the same is detected as "1".

Even field "0" detection

The field in which the vertical synchronous start time delay by $1/2H$ from the line time is detected as "0".

(H: The time required to scan from the beginning of a line to the start of the next scanning line.)


Also, the 0th line is detected and a trigger is issued as follows.

Line 0

The vertical synchronous pulse start or the 3rd line that starts after that is detected as 0. (See the following diagrams.)

A trigger is issued by the selected line start.

Odd-numbered field "1"



Even-numbered field "0"






Figure 3.4.1 Video Signal Detection

3.5 Display Setup

The  key is used for the setup related to the waveform display.




3.5.1 Interpolation (Dot Connection / Interpolation)

There are three types of interpolation : Dot, Line and Sine (Dot only, in the X-Y mode).

[Soft key operations]

[Description]



① Press the key.


② Select or in the Dot connection soft menu using the soft keys. If is selected, the dots of the waveform data are connected by straight lines such as described in the following "MEMO". If is selected, waveform data is displayed with dots alone.



③ Select or in the Interpolation soft menu using the soft keys.

Note: The interpolation function is available only when the zoomed waveform display data numbers are less than 500 dots.

3.5




MEMO

Dot Connection and Interpolation :


- When the number of displayed waveform data samples is 500 or more :
 For this example we will assume that the number of data samples is 2,000 dots.
 Since the displayed data samples number 2000, and 2000 divided by 500 is 4, the maximum and minimum values at every 4 dots are displayed on the same vertical line. (The horizontal resolution of the CRT display is 500 dots.)
 Dot connection OFF : Waveform data is displayed with dots alone.
 Dot connection ON : Connects dots on the vertical line.
 If none of the next vertical line's data is connected this time, the centers of the back and forth data maximum / minimum values are connected as shown in the figure on the next page.

Note : No interpolation function is operated.




3.5.2 Grid Setting


When necessary, grid can be used as follows in addition to the usual display. It can also be displayed by attaching scales in the horizontal/vertical directions and at the 0 and 100% positions.




A. Frame




B. Grid 1



C. Grid 2



D. Tick ON (Scale)




E. % Marker ON


[Soft key operations]

[Description]

- ① ^{DISPLAY}
- ② ^{GRID SELECT}
- ① Press the ^{DISPLAY} key.
- ② Select ^{GRID SELECT} using the soft key.



- ③ ^{FRAME} ^{GRID1} ^{GRID2}
- ④ ^{Tick ON} ^{%Marker ON}
- ③ Select ^{FRAME}, ^{GRID1} or ^{GRID2} in the Grid Pattern soft menu according to the purpose using the soft keys.
- ④ Set Tick and % Marker ON/OFF using the soft keys. Their ^{ON}, ^{OFF} is alternately set every time the soft key is pressed. (The menu hierarchy is returned to the previous level by pressing the ^{RETURN MENU} key.)






3.5.3 Screen Intensity of Brightness Adjustment


The Intensity of brightness of displayed waveforms, characters and grid in the screen can be varied respectively.


[Soft key operations]


[Description]

- ①  Press the **DISPLAY** key.
- ②  Select **INT ADJUST** using the soft key.



- ③  Select **W-FORM**, **SCALE**, **READOUT** or **ALL** in the Intensity soft menu using the soft keys.
 - W-FORM**: varies the intensity of brightness of waveforms.
 - SCALE**: varies the intensity of brightness of grid and %Marker.
 - READOUT**: varies the intensity of brightness of letters, numbers and characters.
 - ALL**: varies the intensity of brightness of the screen.

- ④  The intensity of brightness can be varied using a rotary knob. (The menu hierarchy is returned to the previous level by pressing the **RETURN MENU** key.)




Note: The intensity of brightness of accumulated waveforms can not be varied.

3.6 Accumulate Mode Setting

3.6.1 How to Overwrite Waveforms (Accumulate)


Specified time waveforms (afterglow display) can be overwritten by using the accumulate mode. The accumulate display is shown by varying the brightness so as to make the latest waveform data bright and old data dark.

[Soft key operations]



[Description]

- ① Press the **ACCUMULATE** key.
- ② Press the **ON** soft key on the Accumulate soft key menu.
- ③ Set the afterglow time by turning the rotary knob. After the waveform data is captured, the waveform of the above set time is displayed. Setting time is 0.1 to 50s and infinity.




MEMO

- (1) Only the latest waveform data is stored in memory in the accumulate mode. Therefore, reading out the data by using the cursor, waveform parameter measuring, and saving data to the IC card or internal memory are accomplished only for the latest data. Also, the dot connection function is enabled only for the latest data; the old data is displayed by dots.
- (2) When the accumulated mode is set to ON, the previously accumulated waveform may be displayed. If it is necessary to clear the previous waveform, turn the rotary knob, set the setting time to the minimum value (0.1 sec.), and then set the time. When you wish to stop accumulation while setting, press the **START STOP** key to stop capturing the waveform. Overwriting is re-started by pressing the **START STOP** key again.
- (3) If you specify the X-Y & V-T mode in X-Y mode, only X-Y waveform will be accumulated.

3.7 Data Processing Function

(ACQUISITION Envelope / Averaging / Smoothing / Decimation Setting)

The DL1100 is equipped with the following data processing functions.







3.6
3.7


3.7.1 How to Display in Normal Mode (NORM)

The input waveform is normally displayed as it is. However, when data length is more than 1k in points, it is displayed in P-P suppression.

[Soft key operations]

[Description]

- | | |
|---|--|
| <p>① </p> <p>② </p> | <p>① Press the  key.</p> <p>② Select the  soft key on the Acquisition soft key menu.</p> |
|---|--|



MEMO

When A-D converted data length is more than 1k in the normal mode, the data is P-P suppressed and displayed.





For the relationships between Time / div to sample rate and data length, refer to Appendix B.


3.7.2 Displaying in Envelope Mode (ENV)

The input waveform envelope is displayed, and the envelope mode is activated with the Time/div range between 50s/div and 100μs/div.

[Soft key operations]

[Description]

- | | |
|---|--|
| <p>① </p> <p>② </p> | <p>① Press the  key.</p> <p>② Select the  soft key on the Acquisition soft key menu.</p> |
|---|--|




MEMO

Envelope Mode

In order to observe signals lasting for a long time, and because of the limited data length, the entire waveform is not stored if sampling clock frequency is not decreased.


On the other hand, since the distance between sampling points becomes wider at a low clock frequency, an event occurring in that range cannot be captured. In the envelope mode, sampling is always made at 20MS/s and the maximum and minimum values of the sampling section in the normal mode are stored in memory. (Refer to Figure 3.7.1.) Therefore, even if Time/div is slow, a high speed event can be captured.



- A-D converted sampling point
- ☆ } Maximum value
- 1 }
- ☆ } Minimum value
- 2 }

Stores the sample point of ☆ to acquisition memory.

Figure 3.7.1 Sampling in Envelope Mode



With regard to the waveform in Figure A, if sampling is made in the normal mode, the waveform is shown as a straight line, while if the envelope mode is used as shown in Figure B, the envelope is detectable. When sampling is performed in the normal mode, there is only one sampling point for some sampling times. However, when sampling is conducted in the envelope mode, there are 2 maximum / minimum values between sampling points. The Time / div value and maximum / minimum value section time displayed in the envelope mode are described in the table below.

Time / div Value	~2ms / div *	1ms / div	500 μ s / div	200 μ s / div	100 μ s / div
Section time obtaining maximum / minimum value *	~5 μ s	2 μ s	1 μ s	500ns	200ns
No. of data points **	4 k-points	5 k-points	5 k-points	4 k-points	5 k-points

* For Time / div of less than 2 ms, refer to Appendix B.

The section time required for obtaining max. / min. values :

$$\text{The section time required for obtaining max. / min. values} = \frac{\text{Time / div value}}{\text{Data points (data length)} \times \frac{1}{10\text{div}}}$$

** Corresponding to 1 point at the maximum / minimum values.

When suppression display is made in the envelope mode, the largest and smallest values in the waveform peak of the suppressed section are displayed on the same vertical line on the CRT.

Note: When the window is expanded for use in the envelope mode, the number of display data points is increased to 500.


3.7.3 Averaging (Average)



The averaging functions are used to eliminate noise (random noise affecting repetitive waveforms) superimposed on the input signals.


The highest weighting is given to the newest data by the assigned time constant, and the weighting is reduced exponentially and averaged for the past data in sequence.

[Soft key operations]

[Description]



- ① Press the ^{ACQUISITION}  key.
- ② Select  in Acquisition set menu.
- ③ Set the time constant by turning the rotary knob. The time constant can be varied in the increment of 2^n steps from 2 to 256.



MEMO

(1) Algorithm of Exponential Averaging


The exponential averaging algorithm is:

$$A_n = \frac{1}{N} \{ (N-1) A_{n-1} + X_n \}$$

Where, A_n : Average value on nth cycle

X_n : Measurement value on nth cycle

N : Time constant

Averaging can be stopped at any time by pressing the  key. Pressing the same key again clears the waveforms and causes the operation to be repeated from the first.

(2) Precautions for Averaging

Averaging is effective in countering noise of an irregular nature. Since the measurement values used in averaging are spaced out in time, this reduces the correlation between them and enables them to be treated as virtually independent entities. Thus averaging can also be applied to correlative noise.

However, averaging is only effective for repetitive waveforms, and signal waveforms tend to be distorted when measurements are not completely synchronized. To conduct averaging properly, it is necessary to set the trigger mode to normal and supply a sync input signal from another channel to synchronize the measurements.

(3) Averaging and Data Length

The averaged result data is stored by 2 bytes. For the relationships between Time/div when averaging is executed and sampling rate and data length, refer to Appendix B.





(4) No averaging is made when the trigger mode is in the single mode.


3.7.4 Performing the Smoothing Function (SMOOTH)

Smoothing is used to remove noise added to the input signal. Averaging can be used only in a repetition signal but smoothing can be also used in a single shot signal.

[Soft key operations]

[Description]

- | | |
|---|--|
| <p>① </p> <p>② </p> | <p>① Press the  key.</p> <p>② Select the  soft key on the Acquisition soft key menu.</p> |
|---|--|



MEMO

(1) In the DL1100's smoothing function, the average data value of some sections is obtained and then displayed on the CRT as a representative value.

Example : Averaging of 4-point sections



Each waveform data

a ₁	a ₂	a ₃	a ₄	b ₁	b ₂	b ₃	b ₄	c ₁	c ₂	c ₃	c ₄	d ₁	d ₂	d ₃	d ₄	e ₁	e ₂	e ₃	e ₄	f ₁	f ₂	f ₃	f ₄	f ₅
----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------

$$A = \frac{1}{4} \sum_{k=1}^4 a_k \quad B = \frac{1}{4} \sum_{k=1}^4 b_k \quad C = \frac{1}{4} \sum_{k=1}^4 c_k \quad D = \frac{1}{4} \sum_{k=1}^4 d_k \quad E = \frac{1}{4} \sum_{k=1}^4 e_k$$

The value of each point A, B, C, D and E is displayed on the CRT.

The points used to obtain section-averaging vary with displayed data length.

The figures obtained are shown in the table.

Display data length *	10kW	5 kW	4 kW	2.5 kW	2 kW	1 kW
Section averaging points	16**	8**	8	4	4	2

* If the displayed data length is 100kW, 50kW, 20kW and less than 1kW, no smoothing can be done.



** When the displayed data length is 10kW, there are 20-point data in the section used to perform section averaging. The averaging is performed to obtain the average value from the head to 16-point data. (For a displayed data length of 5kW, the average value is obtained from the first 8-point data.)

(2) No smoothing function can be used when the window mode is BOTH. (For the decimation function.)



3.7.5 Waveform Decimation and Display


When Decimation is selected the waveform is "thinned out" for display.

[Soft key operations]

- ① 
- ② 

[Description]



- ① Press the  key.
- ② Select  in the Acquisition soft menu using the soft key.




MEMO

In the decimation function, the data captured in memory is decimated, and then displayed. In the normal display (Acquisition Normal), the maximum / minimum values in each suppressed section of Table 3.7.1 are displayed, while in the decimation display, every point in the suppressed section is simply displayed.

Example : When data length is 2kW



Usual suppressed display
(max./min. values of every 4-points are displayed.)



Decimation display
(Displayed every 4-points)

Therefore, for the decimation display, the displayed waveform sampling rate will be as follows.

$$\frac{f_s}{\text{Suppressed section points}} \text{ (S/s) } \quad f_s: \text{ A-D converter sampling rate (S/s)}$$

Displayed waveform may differ from the actual waveform.

Table 3.7.1 Relationships between Display Data Length and Suppressed Section Points

Display data length	25kW	20kW	10kW	5kW	4kW	2.5kW	2kW	1kW
Suppressed section points	50	40	20	10	8	5	4	2

3.8 Computation Functions

DL1100 can be used to perform 4 types of computation functions as shown below.

CH1 - CH2

CH1 + CH2

CH1 * CH2

CH2 phase shift

The computed result is displayed as a 3: waveform.

When CH1 and 2 zoom waveforms are displayed, no zoom waveform is displayed, but the computed waveform is displayed.

* CH2 phase shift becomes valid when computation (+, - and *) is performed.

Note 1: When computation between channels is performed with CHs 1 and 2 OFF, both channels automatically turn ON at computation setting. (Beware that the sampling rate may change.)



Note 2: No computation is done when measurement is stopped in the equivalent time sampling mode.









Note 3: When computation is performed with the large memory in use, it takes a long time to compute and display.



3.8.1 To Display Computed Waveform between Channels


[Soft key operations]


[Description]



- ① 
- ② 


- ① Press the  key.
- ② Select ,  or  in the Mathematics soft menu using the soft key.
 displays the CH1-CH2 waveform, , the CH1+CH2 waveform and , the CH1 * CH2 (Multiplication) waveform as the CH3 waveform, respectively. (Computation is canceled by pressing the  key.)


- ③  For CH3


- ③ The computation waveform is moved vertically by pressing the  key and turning the rotary knob.



- ④ 


- ④ When  key is selected, the waveform size can be changed and observed by selecting the ON soft key on the Sens (Sensitivity) soft key menu and turning the rotary knob. (Return to the original size by pressing the OFF key.)
 The sensitivity is variable from 1/2.5 to 2.5 times.



1/2.5 times 1 time 2.5 times

MEMO

How to Display Computation

(1) For CH1+CH2 and CH1-CH2

Computation between channels is performed by the waveform displayed on the CRT.

- ① If the same range is provided for both channels 1 and 2, waveform measurement by cursor and waveform parameter measurement are calculated and displayed in steps of V.
- ② If the voltage ranges in channels 1 and 2 differ, waveform measurement by cursor and waveform parameter measurement are calculated and displayed in steps of div.

(2) For CH1 * CH2

When CHs 1 and 2 waveform sizes from GND level are X div and Y div, respectively, the computed waveform is displayed in 1/2 XY div

- ① Waveform measurement by cursor and waveform parameter measurement are calculated in steps of V².
- ② If computation waveform size is changed by sensitivity, only the size on the CRT changes, i.e., the computed read out value does not change.
If the sensitivity becomes too large, the computed result may overflow and the waveform may become abnormal.

- (3) When inversion is turned ON by pressing the ^{INPUT} key
When inversion is turned ON by pressing the ^{INPUT} key, inverted data computation is performed as it is.

(4) When Variable is used in V/div :

When Variable is used in V/div and the displayed waveform differs from the input waveform, the computation is performed by using a different waveform size.

(5) When Envelope mode is used as Acquisition mode





When magnifying factor is 1, the computation is performed by each maximum value.


3.8.2 How to Shift CH2 Phase



CH2 phase can be shifted.


[Soft key operations]

[Description]

- | | |
|---|--|
| <p>① </p> <p>② </p> | <p>① Press the  key.</p> <p>② Press the  soft key.</p> |
|---|--|



- | | |
|--|---|
| <p>③ </p> | <p>③ Select the  soft key on the Phase soft key menu and shift the CH2 phase by turning the rotary knob. The phase can be shifted within a range of $\pm 5\text{div}$ from the left side of the CRT with a resolution of $1/50\text{div}$.</p> |
|--|---|




Note: Data other than that on the CRT is displayed when the phase is shifted, but this data has no relation to the actual waveform data.

MEMO

- (1) Computation can be performed with the phase shifted. Shift the phase after the computation setting. The setting becomes invalid when setting is performed with the computation OFF.
- (2) No phase is shifted in the long single mode.
- (3) The quantity of phase shift is saved on a CRT position basis. If you change the Time/div value, the quantity of phase shift changes accordingly.
- (4) You cannot shift the phase while waveform is displayed in interpolation mode.


3.9 Cursor Measurement and Waveform Parameter Measurement

By using the measure function it is possible to read out the waveform data and automatically measure waveform parameter.



3.9.1 Waveform Parameter Auto Measurements

The waveform parameters are measured in terms of the items listed below. Set the section to be a parameter as measured by the start cursor and the end cursor.





Voltage Axis Items

- ① P-P (Peak-to-peak)
- ② Max (Maximum voltage)
- ③ Min (Minimum voltage)
- ④ RMS (rms voltage)
- ⑤ AVG (Average voltage)
- ⑥ Overshoot (Overshoot value%)
- ⑦ Undershoot (Undershoot value%)



Time Axis Items


- ⑧ Rise (Rise time)
- ⑨ Fall (Fall time)
- ⑩ Freq (Frequency)
- ⑪ Period (Period)
- ⑫ + Width (Waveform width (+))
- ⑬ - Width (Waveform width (-))

[Soft key operations]

- ① 
- ② 


[Description]

- ① Press the  key.
- ② Select  in the Measure function soft menu using the soft key.







[Soft key operations]


[Description]






③ Select a waveform to be measured by the W-form. Every time the W-form soft key is pressed, the menu alternates between $\boxed{1} \rightarrow \boxed{2} \rightarrow \boxed{3} \rightarrow \boxed{4}$. Select the waveform by displaying the corresponding number.








④ Set the start cursor. Select the  soft key. Every time  is pressed, the menu alternates between $\boxed{\text{CURSOR START}} \leftrightarrow \boxed{\text{CURSOR END}}$. Set the start cursor in the  mode. Shift the start cursor by turning the rotary knob, then set the parameter to the start of the section to be measured. (The cursor appears if the rotary knob is moved slightly.)




⑤ Press the  soft key to change the menu to . Shift the end cursor by turning the rotary knob, then set the waveform parameter to the end of the section to be measured.




⑥ Press the  soft key. Select the waveform parameter soft key for the voltage axis to be measured from the soft key menu, then turn it . (Pressing the key again turns  the parameter.) Pressing  shifts the present item to the next item. Pressing  returns from the present display to the original menu.

Note: Undersht : Abbreviation for Undershoot
Oversht : Abbreviation for Overshoot



[Soft key operations]

[Description]





⑦

T-Item
SELECT


⑦

Press the soft key .
 Select the waveform parameter soft key for the time axis to be measured on the soft key menu, then turn it ^{ON} . (Pressing the key again turns the parameter ^{OFF} .)
 Pressing moves to the next item.
 Pressing moves to the original menu.



MEMO 1

- (1) The top (100%) and base (0%) which serve as the references for the waveform parameter measurements are obtained via a histogram; the points having the highest frequency of occurrence are treated as the top and base. (The mesial is midway (50%) between the top and base.)



The proximal and distal lines can be set anywhere between 10% and 90% as referenced to a base of 0% and top of 100%.

- (2) Overshoot and undershoot are expressed in terms of percentages of the voltage between the top and base.


$$\text{Overshoot (\%)} = \frac{V_{\text{MAX}} - V_{\text{TOP}}}{V_{\text{TOP}} - V_{\text{BASE}}} \times 100$$

$$\text{Undershoot (\%)} = \frac{V_{\text{BASE}} - V_{\text{MIN}}}{V_{\text{TOP}} - V_{\text{BASE}}} \times 100$$

V_{TOP} ... Top voltage value V_{MAX} ... Maximum voltage value
 V_{BASE} ... Base voltage value V_{MIN} ... Minimum voltage value

- (3) Calculate Rms and Avg as follows.

Calculated Rms and Avg within the range specified by the cursor.




$$\text{Rms} = \left[\frac{1}{(m_n - m_1 + 1)} \sum_{j=m_1}^{m_n} V(j)^2 \right]^{\frac{1}{2}}$$

$$\text{Avg} = \frac{1}{(m_n - m_1 + 1)} \sum_{j=m_1}^{m_n} V(j)$$


$V(j)$: Voltage value
 m_1 : No. of points corresponding to cursor 1 time
 m_n : No. of points corresponding to cursor 2 time

Display at Waveform Parameter Measurement



MEMO 2

- (1) If there are two or more waveform cycles between the cursors, the parameters of the first will be measured.








- (2) "----" appears when the parameter cannot be measured or when there is an error-data point between the cursors.
- (3) It may not be possible to determine the waveform parameters properly if the waveform has a low amplitude.
- (4) Since the time axis items are measured from sampled digital data, they will not necessarily be measured exactly at the true distal, proximal and mesial points. The Rise, Fall and Period values may be slightly on the high side while the Freq value may be slightly on the low side.
- (5) In order to obtain Freq (frequency), about two periods of data is indispensable between cursors.
- (6) Even when Variable is used in V/div to change the display size, there is no effect on the measurement result of the waveform parameter.
- (7) Since the waveform parameter automatic measurement feature applies to waveform data displayed on CRT, the time axis resolution depends on the Time/div value due to zooming.









3.9.2 How to Set the Read-Out Cursor








[Soft key operations]


[Description]


- ①  Press the  key.
- ②  Select the  soft key.




- ③  Select the  soft key on the Cursor soft key menu.
- ④  Select the waveform to be measured on the W-form soft key menu. Every time the W-form soft key is pressed, the menu changes in the order of  →  →  →  → . Measurement is conducted for the channel waveform corresponding to the menu No. ALL displays all of the waveform cursor read-out values. The selected waveform is displayed brightly. (However, ALL is excluded.)

- ⑤    Select the cursor to be shifted by moving the cursor soft key menu.  can shift the measure cursor, and  the reference cursor. Also if  are set, the measure and reference cursors shift together. (If  is selected in item ④, only one cursor becomes available.)

- ⑥  Turn the rotary knob to shift the cursor. The read-out value is displayed below each channel's setting status.



V-T



- * If REF is selected by moving the soft key menu Cursor, the voltage value and time value on the REF cursor are displayed as Vr and Tr. If MES is selected, the voltage and time values on the MES cursor are displayed as Vm and Tm.





MEMO


- (1) If W-form corresponds to ALL, the MES cursor can display the measured values in all channels.
- (2) Even when Variable is used in V/div to change the display size, there is no effect on the read-out value.


















3.9.3 Voltage Axis Cursor Setting


[Soft key operations]

[Description]


- | | |
|---|---|
| <p>① </p> <p>② </p> | <p>① Press the  key.</p> <p>② Select  using the soft key.</p> |
|---|---|



- | | |
|---|---|
| <p>③ </p> <p>④ </p> <p>⑤   </p> <p>⑥ </p> | <p>③ Select  in the Cursor function soft menu using the soft keys.</p> <p>④ Select a waveform to be measured on the W-form soft key menu. Every time the soft key is pressed, the menu changes in the order of  →  →  →  . The menu No. corresponds to the channel of the relevant waveform to be cursor-measured. The waveform thus selected becomes bright.</p> <p>⑤ Set the cursor to be shifted by pressing the cursor soft key. Every time the soft key is pressed, the menu changes in the order of  →  →  .
  enables the reference cursor to be shifted, and
  enables the measure cursor to be shifted.
  shifts both the measure and reference cursors together.</p> <p>⑥ Shift the cursor by turning the rotary knob.</p> |
|---|---|







ΔV













3.9.4 Time Axis Cursor Setting


[Soft key operations]

[Description]


- | | |
|---|--|
| <p>① </p> <p>② </p> | <p>① Press the  key.</p> <p>② Selct  using the soft key.</p> |
|---|--|



- | | |
|--|---|
| <p>③ </p> <p>④   </p> <p>⑤ </p> | <p>③ Select  in the Cursor function soft key.</p> <p>④ Press the cursor soft key to set the cursor to be shifted. Every time the soft key is pressed, the menu changes in the order of  →  → .</p> <p>⑤ Set the cursor by turning the rotary knob.</p> |
|--|---|



ΔT




3.10 X-Y Mode Setting

A waveform can be observed in the X-Y mode with CH1 and CH2 set to the X-axis and Y-axis, respectively.





Note: If CH1 and CH2 are turned OFF when the X-Y mode is being used, they are turned ON automatically at the X-Y mode setting.


3.10.1 How to Observe Waveforms in the X-Y Mode

[Soft key operations]



[Description]

- ① Press the  key.
- ② Select the  or  soft key on the soft key menu.
- If  is selected, waveforms in the X-Y and V-T modes can be observed simultaneously. (In the X-Y mode, a dot display is shown. The X-axis is displayed as CH1 and the Y-axis, CH2.)






















3.10


MEMO

- (1) When waveform data is P-P suppressed-displayed on the X-Y display, the X and Y axes are obtained and displayed by using the mean value $\left(\frac{P_1+P_2}{2}\right)$ of the maximum (P_1) and minimum data values on each time axis. Therefore, it may differ from the X-Y display obtained from the waveform data displayed.
- (2) Automatic waveform parameter measurement is carried out for each waveform (CHs 1 or 2) in the X-Y mode.

3.10.2 How to Operate the Cursor in the X-Y Mode

The ΔX , ΔY and X-Y cursors can be used in the X-Y mode.

[Soft key operations]	[Description]
① 	① Press the  key.
② 	② Select  ,  or  on the cursor soft key menu. If  is selected, the cursor on the waveform shifts to read out the point on the waveform. If  is selected, the difference between the reference and measure cursors in the X-axis direction is displayed. If  is selected, the difference between the reference and measure cursors in the Y-axis direction is displayed.
③ 	③ When  or  is selected, select the cursor to be moved by the soft key menu Cursor. Every time the soft key is pressed, the menu changes in the order of  →  →  .  denotes the measure cursor, and  denotes the reference cursor. If  is selected, the measure and reference cursors move together.
④ 	④ Shift the respective cursor by turning the rotary knob.




MEMO

Even when Variable is used in V/div, selecting X-Y cursor to change the display size, there is no effect on the read-out value.


(1) ΔX Cursor

The voltage value on the X-axis of the REF and MES cursors is displayed.




(2) ΔY Cursor

The voltage value of the Y-axis of the REF and MES cursors is displayed.




(3) X-Y Cursor No. 1



(4) X-Y Cursor No. 2 (For Simultaneous Display of V-T and X-Y)


The cursor which indicates the time position at V-T display by the X-Y cursor.



3.11 Window Setting

The instrument usually displays all the data captured to the memory on the CRT, but it can also be used to check a partial-data extension.

The function is called a "window".



3.11

(The section which is brightness modulated can be expanded and displayed at the bottom.)


The window is like a window through which the memory inside can be seen, and the window size (multiplying factor) and position set the waveform displayed on the CRT.

Up to 4 waveform traces can be displayed on the CRT. Therefore, the following 3 modes are available for displaying 4 traces by using the window function.


Note: No window operation can be performed when measurement has stopped in the equivalent time sampling mode. (This operation may lose the waveform.)

If the Time/div value is changed during an expanded waveform display using the window while measurement has stopped, the window Time/div value changes, but the waveform does not. Pressing the  key starts measurement at the Time/div value set.


1. **INTEN** Expanded sections on channels 1 to 2 are displayed in high brightness.



2. **BOTH** Waveforms on channels 1 and 2 are expanded and then displayed on traces 3 and 4.



3. **ONLY** Only expanded waveforms on channels 1 to 2 are displayed.








3.11.1 How to Expand and Display Waveform




1. **BOTH** An expanded waveform can be displayed along with the usual waveform display on channels 1 and 2.


[Soft key operations]

[Description]

- | | |
|---|--|
| <p>① </p> <p>② </p> | <p>① Press the WINDOW  key.</p> <p>② On selecting the  soft key in the Window Mode soft key menu, the expanded waveform is displayed. The expanded waveform on channel 1 is displayed on 3: and that on channel 2 is on 4:.</p> |
|---|--|




- | | |
|---|---|
| <p>③ 
</p> | <p>③ Press the  key and set a multiplying factor by turning the rotary knob. The Time / div value of the expanded waveform is displayed as the Time / div. (Refer to page 2-9.)</p> |
|---|---|





Note: No expanded waveform is displayed during computation execution.

[Soft key operations]


[Description]



④ Set the **<> POSITION** key, then set the waveform section to be expanded by turning the rotary knob.



⑤ **◇ POSITION** in 3: and 4:. When the expanded vertical waveform direction needs to be changed, set it by pressing the **◇ POSITION** key in 3: and 4:. Set the CH1, 3: or CH2 expanded waveform by pressing 4:. Set the vertical position by turning the rotary knob after the key is pressed.



The maximum multiplying factor becomes as shown in Table 3.11.1 depending on the data length.

Table 3.11.1 Data Length vs. Maximum Multiplying Factor

At Normal Sampling

Data length	25kW	20kW	10kW	5kW	4kW	2.5kW	2kW	1kW	500W*
Maximum multiplying factor	1,000	1,000	1,000	500	400	250	200	100	50

* Up to 40 times when the sampling rate is 25MS/s.





At Equivalent Time Sampling


Data length	5kW	4kW	2.5kW	2kW	1kW	500
Maximum multiplying factor	10	4	5	4	2	1




2. ONLY Up to 4 waveform traces can be displayed on the CRT. Therefore, select ONLY in MODE if the expanded waveforms in all channels need to be displayed.


[Soft key operations]

[Description]

- | | |
|---|--|
| <p>① </p> <p>② </p> | <p>① Press the  key selected on the window key menu.</p> <p>② Select the  soft key on the Window Mode soft key menu. Waveforms expanded from CH1 to CH2 are displayed.</p> |
|---|--|





- | | |
|---|---|
| <p>③ </p> <p></p> | <p>③ Press the  key and set the multiplying factor by turning the rotary knob.</p> |
|---|---|








[Soft key operations]


[Description]



④ Press the  key.
The expanded section position can be changed by turning the rotary knob.



⑤ When it is necessary to check the expanded waveform position in the entire waveform, press the  key to select the  soft key in the window mode soft key menu. The expanded section is displayed brightly after intensity-modulation. (If the image is not clear, use INT ADJUST to select  in the  soft key menu and adjust the waveform intensity.



3.11.2 How to Use the Search Function


(1) Outline

The search function can be used when the window mode is BOTH or ONLY or measurement has stopped. (When the START/STOP LEDs are off.)

The search function sets the search level for 1st-time waveform data more than the search level is treated as H and less than the level is treated as L. The memory is searched for in the section in which the combined pattern between each channel is or is not established.

Also, if a channel is set to the clock channel, the search can be carried out in synchronization with the clock.

Example: Condition of each channel




The above shows an example of the pattern establishment position when the clock channel is set to channel 2 rise edge and CH1 patterns, to H.

The search function displays a signal when this pattern is established in the vicinity of the center of the CRT. (However, when the window is at the right or left end of the memory, the position may deviate.)

(2) Pattern Search Setting Flow


(The numerals in the ○ relate to the setting procedure numbers on the following pages.)



Note : For pattern search, press the ^{START}/_{STOP} key to stop measurement.



(3) Pattern Search Setting
[Soft key operations]


[Description]


① WINDOW 


① Press the WINDOW  key.


②  

② Select the  or  soft key on the soft key menu in the Window Mode.




③ 

③ Expand the waveform to the required size by pressing the  key.




④ 


④ Press the  key.


⑤ 

⑤ Set SEARCH EVENT COUNT (1 to 255) by turning the rotary knob. Search for the position where the same patterns to be searched occur the number of set times.




⑥ 

⑥ Select the  key on the Select soft key menu.




[Soft key operations]



[Description]





- ⑦ Select a channel to which the level needs to be set on the Search Level soft key menu.
- ⑧ Set the search level by turning the rotary knob. (Hereafter, do ⑦ and ⑧ for each channel.)



- ⑨ Press the RETURN MENU key.
- ⑩ Select the STATE soft key on the Select soft key menu.




- ⑪ Specify a clock channel by pressing the CLK-CH soft key a few times. When NO is specified, the search is done by the pattern in channel 2. Every time CLK-CH is pressed, the menu changes in the order of 1 → 2 → NO.








- ⑫ Set each channel condition (H, L, X) with the soft key. Each channel also changes in the order of L → H → X every time the soft key is pressed. In the channel specified as the clock channel, \uparrow and \downarrow change alternately. When NO is specified by CLK-CH, set STATE POLARITY by turning the rotary knob. ENTER searches for the section in which the pattern is established, and EXIT searches for the section in which the pattern is not established.

[Soft key operations]



[Description]



- ⑬  Press the  soft key.
- ⑭  Press the  soft key to execute.



MEMO





- (1) If 1 is set to SEARCH EVENT COUNT in accordance with procedure ⑤, a search is conducted on the CRT from the left when the  key is pressed to display the first established section. Pressing the  key again starts the search for the section in which search has been established again, thereby disabling search for the next established section. Therefore, if it is necessary to search for the next established section, set 2 to SEARCH EVENT COUNT. (The same applies even if 3 or more are set to count the section searched once before.)
- (2) A search is conducted using data in the acquisition memory. Depending on the multiplying factor and since peak-peak suppressed data is displayed on the CRT, the searched section may differ from the actually displayed waveform.
- (3) A search starts from the left end of the current window. If search has been conducted, the searched point is displayed near the center of the CRT. However, depending on the value set by SEARCH EVENT COUNT the window may not move.
 - A search is conducted by the SEARCH EVENT COUNT value, and the window does not move if the section to be established is in the front half of the window. Also, the established point is near the center.
 - A search is conducted using the SEARCH EVENT COUNT value and the window moves so that the established point is at the center of the CRT when the section to be established is at the back half of the window.


3.11.3 How to Use the Window in the Long Single Mode








In the long single mode, displays of 20kW (or 25kW) are shown. At this time, the expanded waveform can be displayed by the window.


[Soft key operations]



[Description]

- | | |
|---|---|
| <p>① </p> <p>② </p> | <p>① Press the TRIGGER  key.</p> <p>② Select the soft key menu  in the trigger mode soft key menu. ("Waiting for Trigger" is displayed in the upper left part of the CRT.)
Data is displayed if a trigger is issued.</p> |
|---|---|



- | | |
|---|--|
| <p>③ </p> <p>④  </p> | <p>③ Press the WINDOW  key.</p> <p>④ Select  or  by pressing the soft key in the window mode soft key menu. If INTEN is selected, the expanded waveform section on the displayed waveform is shown brightly. If ONLY is selected, the enlarged waveform is displayed. ( cannot be selected.)</p> |
|---|--|



- | | |
|--|---|
| <p>⑤ </p> | <p>⑤ Press the  key, then set the multiplying factor by turning the rotary knob. The Time/div value on the window changes irregularly when the ZOOM rotary knob is turned first, but then changes in steps of 1-2-5, with the exceptions given in Table 3.11.4. (Refer to the next page.) The Time/div value which changes irregularly the first time is shown in Table 3.11.2 on the next page.</p> |
|--|---|

Note: A little time (about 2 sec.) is required to display 20kW (or 25kW). "Processing" appears during display processing, and "Completed" at the end of processing.




Table 3.11.2 Time/div Value from the First Zoom in Long Memory


Time/div	Time/div Value Display on the Window using WINDOW ZOOM
	When one or two channels are used.
50s	5s
20s	10s
10s	5s
5s	500ms
2s	1s
1s	500ms
500ms	10ms
200ms	100ms
100ms	50ms
50ms	500 μ s
20ms	10ms
10ms	5ms
5ms	100 μ s
2ms	1ms
1ms	500 μ s
500 μ s	200 μ s
200 μ s	100 μ s
100 μ s	50 μ s

Table 3.11.3 Time/div Value at which the ZOOM Value does not change in Steps of 1-2-5 when three or four channels are used

Time/div	Time/div Value Display on the Window using WINDOW ZOOM				
50s	5s	1s	500ms	100ms	50ms
5s	500ms	100ms	50ms	10ms	5ms
500ms	50ms	10ms	5ms	1ms	500 μ s
50ms	5ms	1ms	500 μ s	100 μ s	50 μ s
5ms	500 μ s	100 μ s	50 μ s	10 μ s	5 μ s


3.12 Waveform Data / Setting Panel Condition Save / Load

Waveform data and the setting panel can be stored using the memory built into the mainframe.



MEMO

When the waveform is loaded from memory, the channel display becomes as follows.




























3.12.1 How to Save Waveform Data to Built-in Memory

Up to 8 waveforms can be saved to the built-in Memory.

[Soft key operations]

[Description]

- | | |
|---|---|
| <p>① </p> <p>② </p> <p>③ </p> <p>④ </p> <p>⑤ </p> <p>⑥ </p> | <p>① Press the  key.</p> <p>② Select  in the soft key menu mode. (When  is displayed, pressing this soft key changes it to .)</p> <p>③ Select  in the Func soft key menu. (When  is displayed, pressing this soft key changes it to .)</p> <p>④ Select the waveform No. to be saved in the W-form soft key menu. Every time the soft key is pressed, the waveform No. changes in the order of  →  →  → . When the CH1 expanded and computed waveforms need to be saved, set , since "3 : trace" is displayed. Set , since the CH2 expanded waveform is displayed as 4:.</p> <p>⑤ Specify the memory No. in the Mem soft key menu. Every time the soft key is pressed, the memory No. changes in the order of  →  →  → ... → . Up to 8 traces can be entered since there is a maximum of 8 memory Nos.</p> <p>⑥ Press the  soft key.
The "Completed" message appears to show the end of data save.</p> |
|---|---|



3.12

MEMO





- (1) Only displayed waveform data are saved to built-in memory. Therefore, only P-P suppressed or section-average-suppressed data is displayed on the CRT so that the built-in memory size becomes 1002 points.
- (2) Data Saving is restricted by $\pm 5\text{div}$ from the ground mark center and by $\pm 5\text{div}$ from the center of the CRT.

3.12.2 How to Load Waveform Data from Built-in Memory




[Soft key operations]

[Description]












① Press the  key.
 ② Select  in the mode soft key menu. (When  is displayed, pressing the soft key once changes it to .)











③ Select  in the Func soft key menu. (When  is displayed, press this soft key once to change it to .)





④ Specify the memory No. which stores the waveform to be loaded in the Mem soft key menu. Every time the soft key is pressed, the memory No. changes in the order of  →  →  → ... →  →  →  → . ( to  : Save NO / GO determined waveforms.)




⑤ Set the trace No. of the waveform which needs to be displayed. Every time the soft key is pressed, the memory No. changes in the order of  →  →  → . ( displays the channel 1 waveform,  displays the channel 2 waveform,  the 3: waveform and  the 4: waveform.)



⑥ Press the  key.
 A "Completed!" message is displayed to show that data load is complete. Waveform data is displayed by the channel trace set in ⑤ from the memory using the No. specified in ④. (The already displayed trace waveform disappears to be replaced by the waveform in the memory.)




















Note: Pressing the  soft key cancels the waveform loaded from built-in memory.


MEMO

- (1) Waveforms which can be loaded from memory and displayed correspond to only one trace. When a waveform from memory has been displayed and the waveform loaded from memory is forced to be displayed to another channel, the waveform previously displayed is canceled and the display returns to the previous waveform. At this time, the data most recently loaded is displayed.
- (2) No data processing is performed for a waveform loaded from memory (smoothing, decimation, computation, etc.), and no expansion can be made using the window.

3.12.3 Saving Panel Setup Parameters

Setting conditions corresponding to up to 4 panels can be stored.

[Soft key operations]	[Description]
① 	① Press the  key.
② 	② Select  in Mode menu using the soft keys. (When  is displayed, press this soft key to display  .)
③ 	③ Select  in Function menu using the soft keys. (When  is displayed, pressing this soft key changes to it  .)
④ 	④ Specify the memory No. on the Mem soft key menu. Every time the soft key is pressed, the memory No. changes in the order of  →  →  →  (Panel conditions can be saved independently of #1, #2, #3 and #4.)
⑤ 	⑤ Press the  soft key to execute the operation. A "Completed!" message appears to indicate the end of a save-execution.





















Note: The panel condition just before automatic set-up is stored to the #1 memory. Therefore, pay attention to the use of #1 memory.

3.12.4 How to Load Panel-Setting Conditions

[Soft key operations]


[Description]

- | | |
|--|--|
| <p>① </p> <p>② </p> <p>③ </p> <p>④ </p> <p>⑤ </p> | <p>① Press the  key.</p> <p>② Select  on the mode soft key menu. (When  is displayed, press this soft key once to show .)</p> <p>③ Select  on the Func soft key menu. (When  is displayed, pressing the soft key once changes it to .)</p> <p>④ Specify the memory No. or the soft key menu. Every time the soft key is pressed, memory No. changes in the order of  →  →  → .</p> <p>⑤ Press the  key for execution. A “Completed!” message appears to show that panel condition load is complete.</p> |
|--|--|



3.13 Extended Functions MISC

The items set by the MISC key as the enhanced function are as shown below :



3.13


3.13.1 Date and Time Settings

The date and time displayed at the top right of the CRT are set.


[Soft key operations]


[Description]





① Press the  key.






② Select the  soft key in the Miscellaneous select menu.




③ Select  using the soft keys in the Clock menu.





④ Select the , , and  soft keys on the Date soft key menu and turn the rotary knob to set the year, month, and day.



⑤ Press the  soft key to register the date, while making sure that the year, month, and day data at the top left of the CRT change.






⑥ Press the  key. This causes the display to return to the original menu.






[Soft Key Operations]







[Description]



- ⑦  ⑦ Select the CLOCK soft key  on the Miscellaneous select soft key menu.




- ⑧  ⑧ Select the  soft key on the Clock soft key menu.





- ⑨    ⑨ Select and press the , , and  soft keys on the Time soft key menu to set the hour, minute and second, respectively. The 24 hour system is used.

- ⑩  ⑩ Press the SET TIME soft key  to register the time. At the same time, check to see if the time displayed at the top right of the CRT changes.



MEMO





The date and time displays at the top right of the CRT can be turned ON/OFF by using the  and  keys on the Display clock soft key menu.


3.13.2 To Turn Off Read Out Value Display




The Read Out Value displayed on the CRT (e.g. Panel Settings of CH1 to 4, manual cursor, auto-measured value) can be turned off.


[Soft Key Operations]

[Description]

- | | | |
|---|---|---|
| ① |  | ① Press the  key. |
| ② |  | ② Press the  soft key. |



- | | | |
|---|---|--|
| ③ |  | ③ Press the  key in the Readout soft key menu. (When  is pressed, the set items are displayed.) |
|---|---|--|




3.13.3 GO / NO-GO (PASS / FAIL) Test Function

(1) Outline


The GO / NO-GO (PASS / FAIL) test function determines whether the measured waveform falls within the standard and if the determination results in NO-GO (FAIL), the function allows you to save data to the reference memory, hard copy data from the built-in printer, or output a TTL level* signal from the GO / NO-GO (PASS / FAIL) test output terminal.

There are two ways of using the test function; one is based on waveform amplitude range and the other, the results of waveform parameter measurement. The former method measures the reference waveform to set the upper and lower boundaries and, if the measured waveform exceeds a boundary, the waveform is determined to be NO-GO (FAIL). The latter method gives a NO-GO (FAIL) determination if the automatically set waveform parameter exceeds the predetermined limit value.



* TTL output changes from the high to low level when NO-GO (FAIL) is determined.

(2) GO / NO-GO (PASS / FAIL) Test Flow Chart








* The reference memory can store up to three waveforms. After storing three waveforms, the GO / NO-GO (PASS / FAIL) test stops.



** A printout is executed until the roll chart runs out. When the roll chart runs out, the GO / NO-GO (PASS / FAIL) test function stops.


*** A TTL signal is always output while the NO-GO (FAIL) test function is used.









(3) To Execute GO/NO-GO (PASS/FAIL) Test on the Basis of Waveform Parameters
 [Soft Key Operations] [Description]


- ①  Press the  key.
- ②  Press the  soft key.



- ③  Select  on the NO-GO (FAIL) Mode soft key menu.




- ④     Press the soft key on the Source soft key menu to set the channel to be GO/NO-GO (PASS/FAIL) test. Every time the soft key is pressed, a channel changes in the order of , , , and .




[Soft Key Operations]


[Description]




⑤ Press the soft key on the Cursor soft key menu to select . Use the rotary knob to set the start point at which waveform parameter is obtained for GO / NO-GO (PASS / FAIL) test. Then, press the soft key on the Cursor soft key menu again to select . Use the rotary knob to set the end point of obtaining waveform parameter.



⑥ Set AND or OR of Select1, Select2 and Select3 to be set in and after step <8>. Set the or soft key on the soft key menu And / or. Whenever, the soft key is pressed, or is displayed alternately. When AND is set, NO-GO (FAIL) is established when all the conditions set in Select1 to Select3 are met. When OR is set, NO-GO (FAIL) is established when any one of the conditions set in Select1 to Select3 is met.




⑦ Press the soft key.
 ⑧ Use the Select1 soft key menu to select the waveform parameter item to be determined. Every time the soft key is pressed, the parameter item changes in the order of →, →, →, →, →, →, →, →, →, →, →, →, →, →, →, → and . For the waveform parameters, see page 3-50.



⑨ Press the soft key on the Upper soft key menu to activate . Turn the rotary knob to set the upper limit of the test area. Press the soft key on the Lower soft key menu to activate . Turn the rotary knob to set the lower limit of the test area. When is set for both limits, no determination is carried out. Waveform parameter setting range and resolution are given in the table below. The relationship between the set and measured values is as shown below.

Lower limit set-value < Measured value < Upper limit set value



[Soft Key Operations]

[Description]


GO/NO-GO (PASS/FAIL) Test Parameter Setting Range

	Upper Limit Setting Range	Lower Limit Setting Range	Resolution
P-P	} ±8div	} ±8div	At COARSE : 0.4 div At FINE : 0.04 div
MAX			
MIN			
RMS			
AVG			
UNDRSHT (UNDERSHOOT)	} 0 to 200%	} 0 to 200%	COARSE 10% FINE 1%
OVRSHT (OVERSHOOT)			
RISE	} 0 to 10div	} 0 to 10div	At COARSE : 0.1 div At FINE : 0.01 div
FALL			
FREQ*	*	*	*
PERIOD	} 0 to 10div	} 0 to 10div	At COARSE : 0.1 div At FINE : 0.01 div
+WIDTH			
-WIDTH			

* For FREQ (frequency), both the upper and lower set values are as shown below.

$$\frac{1}{10} \times \frac{1}{\text{Time/div value}} \text{ (Hz)} \text{ to } 50 \times \frac{1}{\text{Time/div value}} \text{ (Hz)}$$

Further, a setting step is the value obtained by dividing $10 \times \frac{1}{\text{Time/div value}}$ by a value of 0.2 to 100 (0.2 step for FINE and 1 step for COARSE).



Setting the soft key on the Step soft key menu to COARSE causes the setting step to be coarse, while setting the soft key to FINE causes the setting step to be fine.

⑩ Press the NEXT MENU soft key to proceed to the next setting. Set the waveform parameter condition value of Select2 and Select3 in the same way. After setting the 3rd waveform parameter condition value, press the RETURN MENU soft key.

⑪ Press the soft key on the Condit soft key menu to set IN or OUT. IN NO-GO (FAIL) results when the measured value falls within the set range, while OUT causes NO-GO (FAIL) when the measured value is out of the set range. (This is common to Select1 through Select3.)

IN and OUT are alternately displayed whenever the soft key is pressed.

⑫ Press the soft key on the Act soft key menu to set the operation when NO-GO (FAIL) is established.

When SAVE is selected, NO-GO (FAIL) waveform data is saved to the built-in reference memory.

When COPY is selected, NO-GO (FAIL) waveform data is output to the built-in printer.

When STOP is selected, the acquisition are stoped at NO-GO.

When NONE is selected, no operations are executed.

Every time the soft key is pressed, the operation mode changes in the order of SAVE → COPY → STOP and NONE.

[Soft Key Operations]

[Description]



⑬ Use the Seq soft key menu to set the sequence in which the GO / NO-GO (PASS / FAIL) test is executed.

When SINGLE is selected, the GO / NO-GO (PASS / FAIL) test function stops once NO-GO (FAIL) is determined.


CONT causes GO / NO-GO (PASS / FAIL) test to be carried out continuously.

SINGLE and CONT are alternately displayed whenever the soft key is pressed.

Note: When the Seq soft key menu is set to CONT, even though the EXEC key is pressed during measurement stop (while START / STOP LED is OFF), it is invalid and NO-GO (FAIL) test is not executed.







⑭ Press the EXEC soft key to execute GO / NO-GO (PASS / FAIL) test.






(4) To Carry Out GO / NO-GO (PASS / FAIL) Test on the Basis of Waveform Amplitude Range


[Soft Key Operations]







[Description]















- ①  ① Press the  key.
- ②  ② Select the soft key  on the Miscellaneous Select soft key menu.




- ③  ③ Select the  soft key on the NO-GO (FAIL) Mode soft key menu.



- ④    ④ Press the soft key on the Source soft key menu to set the channel number for GO / NO-GO (PASS / FAIL) test. Whenever the soft key is pressed, the channel number changes in the order of  →,  → and  →. (4 : cannot be selected.)

- ⑤  to  ⑤ Press the soft key on the Base soft key menu to set the base waveform for GO / NO-GO (PASS / FAIL) test. Each channel waveform and the waveforms saved in the built-in memory can be used as the base waveform. Whenever the soft key is pressed, the base waveform changes in the order of  →,  →,  →,  →,  →,  →,  →,  →,  →,  →,  → and  →.




[Soft key operations]

[Description]

⑥ START



⑥ Use the Edit soft key menu to set the base waveform voltage range. Press the soft key to activate . (This causes the 4: waveform to be extinguished.)




⑦ UPPER LOWER START END

⑦ The Move soft key menu is displayed. Turn the rotary knob to set the base waveform. The upper boundary is set when the Move soft key menu is set to UPPER, while the lower boundary is set when it is set to LOWER. When the setting is complete, press the START soft key on the Edit soft key menu to activate END. Note: When 1/2 SIZE is ON, this setting is not available.

Base waveform



Set the upper boundary




Set the lower boundary

⑧ NEXT MENU



⑧ Press the NEXT MENU key.

[Soft key operations]


[Description]




⑨ Use the Condit soft key menu to set IN or OUT . IN causes NO-GO (FAIL) when a waveform falls within the set range, while OUT causes NO-GO (FAIL) when it is out of the set range. Every time the soft key is pressed, IN and OUT are displayed alternately.



Waveform which results in NO-GO (FAIL) when Condit is set to Out




Waveform which results in NO-GO (FAIL) when Condit is set to In



⑩ Use the soft key on the Act soft key menu to set the operation carried out when a waveform results in NO-GO (FAIL).

- SAVE saves data to the built-in reference memory.
- COPY outputs NO-GO (FAIL) waveforms to the built-in printer.
- STOP the acquisition are stopped at NO-GO.
- NONE executes no operation.

Whenever the soft key is pressed, the operation mode changes in the order of SAVE → COPY → STOP and NONE .



⑪ Select CONT or SINGLE on the Seq soft key menu. When SINGLE is selected, GO / NO-GO (PASS / FAIL) test is stopped once NO-GO (FAIL) is determined. To execute the test again, press the EXEC soft key.







When CONT is selected, the test is executed continuously. Whenever the soft key is pressed, CONT and SINGLE are displayed alternately.


Note: When the Seq soft key menu is set to CONT, even though the EXEC key is pressed during measurement stop (while the START / STOP LED is OFF), it is invalid and NO-GO (FAIL) test is not executed.



⑫ Press the EXEC soft key to execute GO / NO-GO (PASS / FAIL) test.




(5) Notes to be Taken into Consideration when using the GO / NO-GO (PASS / FAIL) Test Function

- ① The maximum number of waveforms saved to the built-in reference memory is 3. When GO / NO-GO (PASS / FAIL) test is executed by selecting on the Act soft key menu and CONT on the Seq. soft key menu, the test function stops if NO-GO (FAIL) is determined three times.
To observe a waveform by calling data from the memory, use the  key to call that data.
Data is stored in the order of NO-GO (FAIL) occurrence in memories  to .
- ② When operations after NO-GO (FAIL) are output from the printer, NO-GO (FAIL) is executed until the printer chart runs out. If you wish to cancel a printout, press the  key to stop measurement.
- ③ To cancel NO-GO (FAIL), use the NO-GO (FAIL) soft key menu Mode to select the  soft key.
- ④ The cursor-setting area for the GO / NO-GO (PASS / FAIL) test based on waveform parameters and that for automatic waveform-parameter measurement carried out by the  key are set individually. Further, measuring time may also be different. Therefore, the waveform-parameter values may not be the same between GO / NO-GO (PASS / FAIL) test and measurement. Further, GO / NO-GO (PASS / FAIL) test is not always executed for captured waveform data.
- ⑤ When GO / NO-GO (PASS / FAIL) test is executed on the basis of waveform amplitude range, setting a waveform with a sharp rise as the base waveform may lead to insufficient data in the rise section so that there is not a big enough zone to be set for the determination.



The setting is inadequate due to a lack of data in the rise section.

- ⑥ When GO / NO-GO (PASS / FAIL) test is executed on the basis of waveform amplitude range, 4 : measurement is not available. (The waveform in which the zone has been set is the 4 : waveform.)
- ⑦ When AUTO or AT-LVL is selected as trigger mode, GO / NO-GO test is executed approximately every 300 ms asynchronously with the trigger signal.
In case of either NORMAL, SGL (S) or SGL (L) trigger mode, the test is executed at the time the trigger is set to occur.
- ⑧ GO / NO-GO (PASS / FAIL) is tested on waveform displayed on the screen every 70 to 80ms, asynchronously with the trigger. If the trigger mode is NORMAL, SGL (S), or SGL (L), a waveform is to be tested several times if an interval at which trigger signal arises is longer than the testing interval; if the result of testing is NO-GO (FAIL), a tested number of operations after testing will be executed.
If the trigger mode is NORMAL, SGL (S), or SGL (L), follow these steps to test GO / NO-GO (PASS / FAIL)


1. Set the Seq soft key menu to  .
2. Press the  key to capture a waveform in the single mode.
3. Press the  soft key to execute GO / NO-GO (PASS / FAIL).

3.13.4 Self-Test

Self-test functions include :


1. Calibration
2. Check of panel condition
3. Functions and memory test

Pressing the key and then the soft key causes the following soft key menu to appear.



CALEXEC Executes a calibration.

OVERVIEW Displays the setting report and system status. When the soft key is pressed, the setting report (condition report) is displayed. (See page 4-6.) Then, pressing any key displays the system status.



When any other key is pressed, the panel returns to the self-test panel.

KEY & CRT TEST This test is performed in the following order.


1. Key Test
2. Text Display Test
3. Graphic Display Test

Each test is performed by turning the rotary knob or pushing the key switches.

(1) Key Test

Performs the operation checks of all key switches on the front panel.

If it proves OK, the function corresponding to the key switch is displayed.



(2) Text Display Test

In normal condition, alphabetic characters (A to Z) are displayed as shown below. The text display test performs a device test of the buffer memory simultaneously.

Please push any key ! 29-MAY-1989 13 05

AA
 BB
 CC
 DDD
 EEE
 FF
 GGG
 HH
 III
 JJJ
 KKK
 LLL
 MMM
 NNN
 OOO
 PP
 QQQ
 RRR
 SSS
 TT
 UUU
 VVV
 WWW
 XXX
 YY
 ZZZ

(3) Graphics Display Test

Performs the operation checks of the memory for a graphic display and peripheral devices by 3 steps of the painting out display, the stripe 1 and the stripe 2.

It is OK if there is no dot error, neat painting out display and neat stripe display.

Each test is performed by turning the rotary knob or pushing the key switches.

ROM & RAM TEST This test performs a read / write check for the memories below.

1. System ROM (384Kbyte)
2. System RAM (256Kbyte)
3. Acquisition RAM (128Kbyte)

If no error occurs, "OK" is displayed after each test is finished, and "Completed!" is displayed after all tests are finished.

If any error occurs, the ROM & RAM test is stopped on the spot and the current address and data are displayed.





≒ ADJ. By setting the " ≒ ADJ." to ON/OFF, you can control whether adjustment is be carried out or not (when the coupling is set to GND).


3.13.5 Display Comment on CRT

With this command, comment is input and displayed on the upper left of the CRT. The comment can be printed out later using the internal printer or, plotters which support HP-GL command.

[Soft key operations]


[Description]

- | | |
|---|--|
| <p>① </p> <p>② </p> | <p>① Press the  key.</p> <p>② Press the  soft key.</p> |
|---|--|




③ ON

③ Press the ON key to display comment on the upper left of the CRT. (Press the OFF key to clear the comment.)




④ FULLKEY BOARD

④ Press the FULLKEY BOARD to input comment.






Full-Keyboard Operation on CRT Display

- File name or comment is entered on the full-keyboard display.
- Full-keyboard display.



© How to use the full keyboard on a CRT display


1. Pressing the ^{FULLKEY}_{BOARD}  softkey, display turns to the full-keyboard display.
2. Select a key on the full keyboard by pressing the KEY SELECT \uparrow and \downarrow softkeys and the rotary knob KEY SELECT \leftarrow and \rightarrow . The position of the character selected with the KEY SELECT \uparrow and \downarrow soft keys moves up and down, and to the left and right on the keyboard with rotary knob KEY SELECT \leftarrow and \rightarrow . The selected character is inversely displayed. (In the above figure, A is selected.) For entry of a character in the lower part of the key displayed on the CRT, first press the SHIFT key. Thus, the symbol \downarrow is displayed in the lower right of the location written as SHIFT to enable entry of the character displayed in the lower part of the key. Pressing the SHIFT key again deletes \downarrow to enable entry of the character in the upper part of the key.
3. After the character is selected, press ^{ENTRY} .
4. Similarly, enter the 2nd character.
For a comment up to 27 characters can be entered.

5. Pressing ENTRY displays the character selected in the key-in filed (space below the key-in on the CRT).
6. The character-entry position in the key-in field can be changed with the Key-in CURSOR ← and → soft keys. The following keys are used for editing characters in the key-in filed :
 - BS : Deletes one character to the left of the inversely displayed character.
 - INS : Enables characters to be inserted to the left of the inversely displayed character. When this mode is selected, \ appears in the lower right of INS. The selection of INS again deletes \ to be set to the overwrite mode.
 - DEL : Deletes characters to the right including those inversely displayed.
 - HOME : Deletes all the characters in the key-in field.
7. After entry of all the characters is completed, press the softkey  .

MEMO



- The comment length is from 1 to 27 characters. The following characters can be used for a comment :
Numerics (0 to 9) and alphabetic characters (distinction between upper and lower case characters).
Space ! \$ % & # & ' () * + , - . / : ; < = > ? @ [] \ ^ _ { } | \
- The comment may disappear from the display if the “Waiting for trigger” or any other message is displayed during that time. If this should occur, press the “Comment ON” soft key again and the input comment will reappear on the display.

3.14 Key Function

When the  key is pressed, all channels are band-limited to 20MHz. When a band limit is used, the LED beside the BW indication lights up. When a high-frequency noise overlaps the input waveform, the use of a band limit suppresses the noise component, making it easier to obtain an easy-to-see waveform.

3.14

3.15 Key Function





Pressing the  key and then the  soft key starts auto set-up.











When the input signal is a repetitive signal, this function automatically sets up the instrument so as to provide the optimal waveform display.

This function is usable only with repetitive waveforms having frequencies ranging from 40Hz to 100MHz and input level of more than 5mV. Normally the channel operated on by Auto Setup is all channels.

Auto Setup works by changing the parameters in Table 3.15.1. (The panel-setting status immediately before auto set-up is stored in built-in memory #1.)

Table 3.15.1

Item CH1 to CH2	Details of Change	
	Auto set-up is valid only for channels set to ON. However, if all channels are set to OFF, all channels change to ON.	
	Value which is about ± 1 div CAL 1/2 OFF	
	Numbers of channel turned ON	Position on CRT
	1	At the center of the CRT
	2	Upper-and-lower-equally-dividing position
	Coupling AC \rightarrow AC DC GND } \rightarrow DC DC - ADD Invert OFF	

Item	Details of Change	Item	Details of Change
	AUTO		OFF
	Channel set to ON and with the smaller number		OFF
	At the center of CRT		NORM
	OFF		OFF
	Auto set-up is set to the channel set to ON and with the highest frequency. If a signal is not input, 1 ms/div is used.		OFF

Note: The auto set-up function is not available for any waveform, as it may fail if the waveform is complicated.

3.16 Key Function

The start / stop key is in the measurement status while the LED is lit, and in the measurement stop status when the LED is OFF.

Operating Mode \ Key		When Pushing the STOP Key	When Pushing the START Key
Averaging		Stop	Start from the beginning
Accumulate		Halt	Resume
Other operations than averaging and accumulate	Trigger mode Single (L) Single (S)	—	One-time measurement
	Trigger mode Auto AT-LEVEL Normal	Halt	Resume



MEMO


- (1) If, in NORM, SGL (S), or SGL (L) trigger mode, you press the STOP key while the message "Waiting for trigger" appears, and do any waveform operations using MATH, WINDOW, the waveform may be corrupted.

3.15

3.16

3.17 Key Function

Pressing and holding the  key and then pressing the  key returns the instrument to its initial condition. The setting for each parameter is indicated below.

To activate an initialization when the power is turned ON, turn the power supply ON with the  key held down.

Parameter		Initial Status
Menu	Function	
CH1 CH2	ON	ON
	V/DIV	CAL
	V/DIV Value	50V/div
	1/2 Size	OFF
	Position Step	COARSE
	Coupling	AC
	Invert	OFF
	DC-ADD	FINE
	DC-ADD	0.0V
	Probe	10 : 1
SAVE / LOAD	Mode	DATA
	Func	SAVE
	DATA Save W-form	1
	DATA Save Mem	#1
	DATA Load W-form	1
	DATA Load Mem	#1
	PANEL Save Mem	#1
	PANEL Load Mem	#1
BW		OFF
ACCUMU- LATE	Mode	OFF
	Accumulate Time	0.1sec

Parameter		Initial Status
Menu	Function	
DISPLAY	Interpolation	SINE
	Dot Connection	ON
	Grid Pattern	GRID2
	Tick	ON
	% Marker	OFF
	Intensity	W-FORM
	ACQUI- SITION	Mode
WINDOW	Mode	OFF
	Position	Left End
	ZOOM	×1 (1ms/div)
WINDOW SEARCH	SELECT	LEVEL
	Level CH	CH1
	↓ CH1 to CH4 Level	0V
	State CLK-CH	CH1
	↓ CH1 to CH4 Pattern	L
	↓ CLK-CH Pattern	
	↓ CLK NO POLARITY	ENTER
X-Y	Mode	OFF
TIME/DIV		1ms/div

Parameter		Initial Status
Menu	Function	
TRIGGER	Mode	AUTO
	Source	CH1
	CH1 to CH2 Level Edge	\uparrow
	Coupling	AC
	TV Field	0
	TV Line	1
	CH1 to CH2 Level	Same as Each CH Initial Position
	Level CH	CH1
	Delay	Center of the CRT
	Hold off	OFF
	Ext range	$\pm 50V$
	Ext probe	10 : 1
	COPY	Condition
Trace		SHORT
Feed		LINE
Cursor Select when Using Long Mode		START
Start Cursor Position		A Quarter of the CRT Position
End Cursor Position	Three Quarter of the CRT Position	
MATH	Mode	OFF
	Phase	OFF
Start/Stop		START

Parameter		Initial Status	
Menu	Function		
MISC	Mode	OFF	
	Zone Source	CH1	
	Base	CH1	
	Edit	END	
	Move	UPPER	
	Condition	OUT	
	Act	NONE	
	Seq	SINGLE	
	Para Source	CH1	
	Cursor	START	
	And/or	OR	
	Select 1 to 3	P-P	
	Upper	OFF (*)	
	Lower	OFF (*)	
	Step	COARSE	
	Start Cursor	A Quarter of the CRT Position	
	End Cursor	Three Quarter of the CRT Position	
	MEASURE	Select	OFF
		V-T Cursor	MES
		W-Form	CH1
		Mes Cursor Position	Three Quarter of the CRT Position
		Ref Cursor Position	A Quarter of the CRT Position
		ΔV Cursor	MES
W-Form		CH1	
Mes Cursor Position		Three Quarter of the CRT Position	
Mes Cursor Position		A Quarter of the CRT Position	
ΔT Cursor		MES	

3.17

Parameter		Initial Status
Menu	Function	
MEASURE	Mes Cursor Position	Three Quarter of the CRT Position
	Ref Cursor Position	A Quarter of the CRT Position
	X-Y Cursor Position	t = -5msec Data Position on the Waveform
	ΔX Cursor	MES
	Mes Cursor Position	Three Quarter of the CRT Position
	Ref Cursor Position	A Quarter of the CRT Position
	ΔY Cursor	MES
	Mes Cursor Position	Three Quarter of the CRT Position
	Ref Cursor Position	A Quarter of the CRT Position
	Auto Measure Cursor	START
	Start Position	A Quarter of the CRT Position
	End Position	Three Quarter of the CRT Position
	V-Item P-P	ON
	Max	ON
	Min	ON
	Rms	ON
	Avg	ON
	UnderSht	ON
	OverSht	ON
	T-Item Rise	ON
	Fall	ON
	Freq	ON
	Period	ON
+ Width	ON	
-Width	ON	

Parameter		Initial Status
Menu	Function	
MISC*	Mode	COMM
	Comm	GB-IB
	Clock	DATE
	Date	YEAR
	Time	HOUR

* Settings of communication and date remain unchanged by INITIAL keys. The settings are changed when the unit is shipped from the manufacturing plant and the battery cannot be backed up by built-in lithium cell.

Chapter 4. PRINTER (OPTION)


The built-in printer (option) can be used to make hard copies of the display easily. This chapter describes its use.

ITEMS


Chapter 4. PRINTER (OPTION)

4.1	Installing and Replacing the Printer Paper Roll	4-1
4.2	The Built-in Printer (Optional) Use	4-4
4.2.1	How to Print Out the Condition Report	4-5
4.2.2	To Provide Waveform Hard Copy	4-8


4.1 Installing and Replacing the Printer Paper Roll




- 1 Press the area marked PUSH on the printer cover.




- 2 Open the printer cover.




- 3 Move the release arm from the Hold position to the Free position.




- 4 Set the printer paper roll so that the end of the paper is facing you. Press the movable boss (circular projection) on the left side to expand the space between it and the fixed boss on the right side and insert the paper roll into the printer. The boss on the left side is spring loaded. Use the force of the spring to locate the head of the boss in the hole of the paper roll core. Then, insert the head of the boss on the right side into the right hole of the paper roll core. This completes the loading of the paper roll.




- 5 Insert the paper into the front slit as shown in the figure. Insert it so that about 1cm will emerge from the gap between the main unit and printer section. Further, pull out the paper and check to make sure that the right and left edges of the paper feed straight into the printer. (This prevents the paper from shifting and jamming.)




- 6 Move the release arm from the Free position to the Hold position. Note that leaving the release arm in the free position causes the "300 Illegal Printer Head" error message to appear at the top of the CRT when an attempt is made to print out a hard copy, and it cannot be done.



7 Thread the paper through the opening provided in the printer cover.



8 Press the area marked PUSH again to close the printer cover. Make sure that the printer cover is firmly closed.



9 Select the ^{COPY} menu key. Press the soft key on the soft key menu PRINTER. Then press the soft key on the soft key menu FEED EXEC to make sure that the paper is fed correctly. (When the Feed soft key menu is set to LINE, the paper is fed line by line and when the soft key menu is set to FORM, it is fed page by page.)

4.2 The Built-in Printer (Optional) Use

The built-in printer is used to make hard copies of CRT displays.

The built-in printer is provided with the following functions:





1. Condition report Prints out the measurement status.
2. Hard copy short mode Prints out the waveform on the CRT just as it appears.
3. Hard copy long mode Hard-copies the waveform of the range specified by the cursor at the expansion rate specified by the Window Zoom.


4.2.1 How to Print Out the Condition Report







The condition report shows the channel's setting conditions and trigger condition sampling, etc.


[Soft key operations]

[Description]

- | | |
|---|---|
| <p>① </p> <p>② </p> | <p>① Press the  key.</p> <p>② Press the soft key on the Copy menu to select .</p> |
|---|---|



- | | |
|---|--|
| <p>③ </p> <p>④ </p> | <p>③ Press the soft key on the Condit soft key menu to select .</p> <p>Every time the soft key is pressed,  and  are displayed alternately.</p> <p>④ Press the  key to print out a condition report.</p> |
|---|--|



MEMO

When the hard copy of waveform data with the Condition Report is executed while Condit is ON and Trace is Short in the accumulate ON mode, the accumulated waveform may have a trace of the color-reversed outline of the condition report out. To eliminate such a trace, it is recommended to execute hard copy of the condition report and the waveform data separately.

With Condit set to OFF and Trace to Short, first execute the hard copy of the waveform alone without condition report.

Then output only the condition reports while Condit is ON and Trace is OFF.

The condition report is output as shown below :

1. Vertical Axis Setting and Per-Input Channel Measurement Conditions

- ① Voltage range
The "=" symbol indicates a calibrated value.
The "<>" symbol indicates that the vernier scale is used.
- ② Input coupling
- ③ Offset voltage value
- ④ Probe setting
- ⑤ Inverse ON/OFF
- ⑥ Band width FULL/20MHz

2. Time Axis and Sampling Rate

(The A-D converter is operating at 10MS/s when equivalent time sampling is used.)

3. Trigger Mode

- ① Trigger mode
- ② Trigger source
- ③ Trigger coupling

4. Input Data Capturing Method

- NORMAL : Normal
- ENV : Envelope
- AVG : Average
- SMOOTH : Smoothing
- DECIM : Decimation

5. Sampling Mode

- NORMAL : Normal sampling
- REPEAT : Equivalent time sampling

6. Data Length

28-FEB-1991 17:44

DL1100 CONDITION REPORT Ver. 1.00-20H

1. INPUTS			
⑥ BW=FULL	CH1	CH2	EXT
① V/div	= 2V	= 5V	±50V
② Coupling	AC	AC	
③ (DC add)			
④ Probe	10:1	10:1	10:1
⑤ Invert	OFF	OFF	

2. TIME/div SAMPLE RATE

3. TRIGGER

① Mode	AUTO
② Source	CH1
③ Coupling	AC

4. ACQUISITION

5. SAMPLING

6. DATA LENGTH

Note: When a pattern or TV trigger is used, each item is printed out as shown on the next page.

When a TV Trigger is Selected

22-FEB-1991 17:45

DL1100 CONDITION REPORT Ver. 1.00-20H

1. INPUTS

EW=FULL	CH1	CH2	EXT
V/div	= 2V	= 5V	±50V
Coupling	AC	AC	
(DC add)			
Probe	10:1	10:1	10:1
Invert	OFF	OFF	

2. TIME/div SAMPLE RATE

3. TRIGGER

Mode	AUTO	Field	Line
Source	CH1	EVEN	1
Coupling	TV		

4. ACQUISITION

5. SAMPLING

6. DATA LENGTH





* Field : ODD ; Odd number field
 EVEN ; Even number field
 Line : Line No.


4.2.2 To Provide Waveform Hard Copy










Hard copy is easily provided by using the built-in printer.


[Soft key operations]

[Description]





- ①  ① Press the  key.
- ②  ② Press the soft key on the Copy menu to select .








- ③   ③ Press the soft key on the Trace soft key menu to select  or .
- Whenever, the soft key is pressed, the hard copy mode changes in the order of ,  and . (When  is selected, no hard copy is made.)
- When the  soft key is pressed with SHORT selected, what you see on the CRT is printed out. When LONG is selected, the waveform within the range specified by the cursor is printed out at the expansion rate set by the ZOOM. This requires that the following operations be carried out:



Note: See page 4-10.

- ④  ④ Press the WINDOW  key.
- ⑤  ⑤ Select the  soft key on the Window Mode soft key menu.








- ⑥  ⑥ Press the  key. Use the rotary knob to set the expansion rate.
- ⑦  ⑦ Press the  key.


[Soft key operations]

[Description]



⑧ Use the Cursor soft key menu to set the  soft key, and the rotary knob to set the cursor's starting point. Use the Cursor soft key menu to set the  soft key. Whenever the soft key on the Cursor soft key menu is pressed,  and  are alternately displayed.



⑨ Press the  soft key to execute a print out while the expanded waveform is being displayed.





Figure A

Expansion rate is obtained by Time / div value. The area enclosed by the START and END cursors as shown in Figure A is output, as shown in Figure B, at the expansion rate set by the windows.




Figure B






Paper-Feed Function


The following describes the printer's paper feed function.

Two paper-feed function modes are available.

1. LINE feed Feeds the paper line by line.
2. FORM feed Feeds the paper page by page.





Setting Method

After pressing the  key, press the soft key on the soft key menu Feed to select  or . (Every time the soft key is pressed,  and  are displayed alternately.)

Press the  key to feed the paper.

Note: Setting both the condition report output and waveform print-out functions to ON in the copying function causes a condition report to be output first, followed by waveform print-out.

MEMO

- (1) The short mode enables a hard copy to be made while waveform data is being captured.
- (2) When a print-out is made in the long mode, first press the  key to stop measurement, then make a hard copy. If a print-out is made during measurement, the waveform to be copied may be irregular.
- (3) Making a long copy when the trigger mode is set to the long single mode may cause the hard-copied-waveform to be disordered. When this happens, use the  key to adjust magnification, then make a hard copy.
- (4) In order to stop printing in the LONG mode, press the  key.
- (5) Long Copy is not available in the following window magnifying factor encircled by  mark.
In case Long Copy is executed in the factor, the message "Cannot copy" is displayed.

t/div	window mag								
	20s	10	5	2	1	500ms	200	100	50ms
50s	20s	10	5	2	1	500ms	200	100	50ms
20	10s	5	2	1	500ms	200	100	50	20ms
10	5s	2	1	500ms	200	100	50	20	10ms
5	2s	1	500ms	200	100	50	20	10	5ms
2	1s	500ms	200	100	50	20	10	5	2ms
1	500ms	200	100	50	20	10	5	2	1ms
500ms	200ms	100	50	20	10	5	2	1	500µs
200	100ms	50	20	10	5	2	1	500µs	200µs
100	50ms	20	10	5	2	1	500µs	200	100µs
50	20ms	10	5	2	1	500µs	200	100	50µs
20	10ms	5	2	1	500µs	200	100	50	20µs
10	5ms	2	1	500µs	200	100	50	20	10µs
5	2ms	1	500µs	200	100	50	20	10	5µs
2	1ms	500µs	200	100	50	20	10	5	2µs
1	500µs	200	100	50	20	10	5	2	1µs
500µs	200µs	100	50	20	10	5	2	1	500ns
200	100µs	50	20	10	5	2	1	500ns	200ns
100	50µs	20	10	5	2	1	500ns	200	100ns
50	20µs	10	5	2	1	500ns	200	100	50ns
20	10µs	5	2	1	500ns	200	100	50	20ns
10	5µs	2	1	500ns	200	100	50	20	10ns
5	2µs	1	500ns	200	100	50	20	10ns	
2	1µs	500ns	200	100	50	20	10ns		
1	500ns	200	100	50	20	10ns			
500ns	200ns	100	50	20	10ns				
200	100ns	50							
100	50ns	20	10ns						
50	20ns	10ns							
20	10ns								
10									

Chapter 5. HP-GL DIRECT PLOTTING

Hard copies of the display can be plotted using plotters which support HP-GL command. This chapter describes its use.

ITEMS

Chapter 5. HP-GL DIRECT PLOTTING

5.1 Direct Plotter Function	5-1
5.2 Use of HP-GL Feature	5-2

5.1 Direct Plotter Function

Hard Copy can be directly output using plotters shown below (Other plotters which support HP-GL command are also valid for the Hard Copy, however, as area available for plotting varies according to model, a part of the hard copy may be lost).

Plotter


Maker and Type Name	Paper Size			
	A3	A4	A5 Upper	A5 Lower
HP 7475A, 7550A	○	○	○	○
EPSON HI-80	/	○	○ Note 2	○ Note 2
HITACHI 672-XD	○ Note 1	○ Note 1	○ Note 1	○ Note 1
GRAPHTEC MS8603 (HP-GL mode)	○ Note 3	○	○ Note 3	○

Note 1 : Used in small scale mode.


Note 2 : No. of waveform and measured value of the auto measure mode are not printed out.

Note 3 : When the auto measure mode is not used, upper half of comment, date, time and trigger delay mark will be missed.










• Types of plotting form



















Note : If A5 Upper and A5 Lower are used, plot two pictures on one piece of A4 size paper.




5.2 Use of HP-GL Feature

[Soft key operations]	[Description]
① 	① Select  (TALKONLY) in the GP-IB mode. (Refer Chapter 1.3 in the GP-IB / RS-232C (option) Interface Manual) Note:  is accepted, in case direct plotting is executed by GP-IB command. (Refer ECOPY command in the Interface Manual).
② 	② Press the  key and stop measurement.
③ 	③ Press the  key.
④ 	④ Select the  soft key.




⑤ 	⑤ Use the Form soft key to choose the output form.
	A4-WAVE : Outputs waveforms in A4 size.
	A4-COND : Outputs conditional reports in A4 size.
	 : Outputs waveforms in A5 size on upper half of a A4 size paper.
	 : Outputs conditional report in A5 size on upper half of a A4 size paper.
	 : Outputs waveforms in A5 size on lower half of a A4 size paper.
	 : Outputs conditional report in A5 size on lower half of a A4 size paper.
	 : Outputs waveforms in A3 size.
	 : Outputs conditional report in A3 size.

Note: Output forms vary when auto-measure is activated.



- ⑥ NORM SLOW ⑥ Use the Speed soft key to select pen speed.
- NORM : Print out in a default pen speed of a plotter.
- SLOW : Set pen speed of a plotter to 10cm/s.



- ⑦ AUTO MANUAL ⑦ Use the Pen Select soft key to designate which pen to use.
- AUTO : By choosing number of pens to use, the pen number is automatically assigned to each item as shown in the following table.

Installed Pens	Grid	Ch1	Ch2	3:	4:
1	1	1	1	1	1
2	1	2	1	1	2
3	1	2	3	1	2
4	1	2	3	4	1
5	1	2	3	4	5

- MANUAL : This mode is used to assign pens for Grid / CH1 / CH2 / 3 : / 4 :. Pen number is chosen from 1 to 12. The item is not plotted in case the pen number is chosen to be 0.
- The following are explanation of each item.

- Grid Condition report
 - Grid
 - % Marker
 - Tick
 - Comment
 - Read out value
 - Trigger delay mark
 - Cursor or measured value to which no corresponding channel exist.
 - e.g. $\left\{ \begin{array}{l} \Delta T \\ V-T \text{ (when ALL is selected)} \\ X-Y \\ \Delta X \\ \Delta Y \end{array} \right.$
- Ch1 Ch1 waveform
 - Trigger level mark (when Ch1 is designated)
 - Cursor or measured value to which Ch1 corresponds.
 - e.g. $\left\{ \begin{array}{l} \Delta V \\ V-T \\ \text{Auto parameter measurement} \\ \text{value.} \end{array} \right.$
- Ch2 Same as Ch1
- 3: Same as Ch1
- 4: Same as Ch1

Note: When the window (BOTH / INTEN) is open, expanded section is plotted in different color.

- <INTEN> ● The expanded section is plotted in the Grid color.
- <BOTH> ● The expanded section of Ch1 is plotted in 3: color.
- The expanded section of Ch2 is plotted in 4: color.

⑧



⑧




Press the




soft key.

[Soft key operations]

[Description]

- ⑨  ⑨ Press the  key to start plotting. The plotting is aborted next time,  key is Pressed.

Note: Once the output is started, measurement can be resumed.



MEMO

- Plotting process differs depending on the following condition.

① Acquisition Mode

	Data Points	Plotting Process
Normal	1002W	Outputs contents of the display buffer as they are.
Envelope	501W x 2	Contents of the display buffer are aligned to max. and min. value and shown separately.
Averaging	501W	$\frac{D_0 + D_1}{2}$ is obtained and the result is plotted.
Smoothing	501W	$\frac{D_0 + D_1}{2}$ is obtained and the result is plotted.
Decimation	501W	Every other point is plotted.
Refer 3-98 of 1M7006-11		

- ② Depending on Dot Connection ON/OFF, output image of T-Y waveform varies
 Dot Connection ON : Dots are interpolated and plotted.
 Dot Connection OFF : Waveforms are expressed in dots.
- ③ X-Y waveforms are expressed only in dots. Irrespective of acquisition mode, both X and Y value are represented by $\frac{D_0 + D_1}{2}$.
- ④ Zone waveform used in GO/NO-GO decision function is expressed by upper waveform and lower waveform.
- ⑤ The following items are turned ON/OFF by soft key operation.
 - Clock CLOCK in the MISC menu.
 - Comment COMMENT in the MISC menu.
 - Read Out Value READ OUT in the MISC menu.

Chapter 6. PROBE ADJUSTMENT, INSPECTION AND MAINTENANCE

This chapter describes how to adjust the probe and perform other routine maintenance and checks.

Read through the details on how to adjust the probe before using the accessory 10:1 probe, and read the section on maintenance to ensure that the equipment will be kept in peak working order.

ITEMS

Chapter 6. PROBE ADJUSTMENT, INSPECTION AND MAINTENANCE

6.1	Probe Adjustment	6 - 1
6.2	Inspection and Maintenance	6 - 2
6.2.1	CRT Filter Cleaning	6 - 2
6.2.2	Power Fuse Replacement	6 - 4

6.1 Probe Adjustment

When using the accessory 10 : 1 probe, first use the signal from the calibration output terminal (1kHz square wave, 0 to 1V) to adjust the capacitance in the voltage probe by following the procedure below before proceeding with measurement operations. Make sure that these steps are taken prior to measurement.

7

CAUTION

The Low side of the measurement input terminal (BNC connector) is grounded. To prevent the breakdown of the probe, connect GND-side to the GND of measurement circuit correctly.

- (1) Connect the accessory 10 : 1 probe to input connector executes measurement.
- (2) Connect the tip of the probe to the CAL output connector.
- (3) Set all channels except the channel connected the probe to OFF.








Figure 6.1 Probe Adjustment


- (4) Press the  key and  key to produce an optimal display.
- (5) Obtain the correct waveform as shown below by turning the variable capacitor in the phase adjustment hole with a screwdriver or other suitable tool.



Insufficient compensation



Correct waveform




Excessive compensation

Note : Do not connect the probe once calibrated to the input terminal of other channel. When connecting to the other channel, adjust the probe at the channel once again.


6.2 Inspection and Maintenance

6.2.1 CRT Filter Cleaning


When the CRT filter is dirty, remove it as outlined below to clear away the dirt.




- 1 Prize the filter frame forward by putting your fingernail or a five minus driver to the notches on the left edge (indicated by the arrows) of the filter frame.



- 2 The right edge of the filter frame will now pop up.



- 3 Remove the filter frame and the filter. Since there is a special coating on the CRT filter surfaces, we recommend the use of a special CRT cleaner (sold separately) to preserve this coating.



- 4 Procedure of re-attaching the filter and frame. Reverse the procedure to re-attach the filter and frame. Re-attach the filter frame by pressing as shown in the upper right figure on the left. In such a case of the lower left figures with × mark, attachment is not completed. It might cause falling or breakage of the filter. In that case, remove filter frame and re-attach it.

2

WARNING

This CRT is in conformity with the requirements specified in CSA and TÜV standards. However please avoid rough handling or jarring of instrument to prevent possible CRT implosion. Breakage of the CRT may cause a high velocity scattering of glass fragments.

6.2.2 Power Fuse Replacement

1

WARNING

To prevent a fire, make sure to use the fuse with specified standard (current, voltage, type).

Before replacing fuse, turn the power off and unplug the power cord. Don't use different fuse or short-circuit the fuse holder.

Follow the steps below to replace the power fuse which is located at the rear of the instrument.


- ① Turn off the instrument power.
- ② Turn the fuse holder counterclockwise with a screwdriver to remove the fuse. Replace with a new fuse and screw back the fuse holder back by turning it clockwise.

Fuse used: 7001□□ - 1 ... 250V, 4A, Medium-Time-Lag, UL Listed, CSA Certified.

(Part number : B9858HV)

7001□□ - 5 ... 250V, 2.5A, Time-Lag, VDE Approval.

(Part number : A1350EF)



Chapter 7. SPECIFICATIONS

This chapter contains instrument specifications (input section, trigger section, time axis, other, and general specifications) and outline drawings.

ITEMS

Chapter 7. SPECIFICATIONS

7.1	Input Section Specifications	7-1
7.2	Trigger Section Specifications	7-2
7.3	Time Axis Specifications	7-3
7.4	Communications	7-3
7.5	Printer	7-3
7.6	Others	7-4
7.7	General Specifications	7-5
7.8	External Dimensional Drawings	7-6

7.1 Input Section Specifications

Item	Specifications
Input channel	CH1 to 2: Analog input BNC connector 1M Ω
Input impedance	CH1 to 2: 1M Ω \pm 1.5% Approx. 27pF
Input sensitivity	CH1 to 2: 2mV/div to 5V/div (1, 2, 5 steps)
Maximum input voltage	250V DC+AC peak 1kHz
Input DC offset range	2mV/div to 20mV/div : \pm 0.5V (max.) 50mV/div to 200mV/div : \pm 5V (max.) 500mV/div to 5V/div : \pm 20V (max.) (when using 1:1 probe)
Accuracy (channels 1 to 2, DC after self-calibration)*	100mV/div \pm (2.5% of Full Scale+1 LSB) Other ranges \pm (3.5% of Full Scale+1 LSB+0.5mV)
Temperature coefficient	2mV/div : \pm 50 μ V/ $^{\circ}$ C (Typ.) Other ranges : \pm 0.03 div/ $^{\circ}$ C (Typ.)
Frequency response * for sine-wave signal input equivalent to \pm 4div	For equivalent-time sampling (repeating event) DC to 100MHz ($-$ 3dB band) For normal sampling (one-shot event) DC to 8MHz ($-$ 3dB band) 1/2 ch events simultaneous
Lower cutoff when AC-coupled ($-$ 3dB point)	10Hz maximum (1Hz maximum when using 10:1 probe)
Channel to channel skew	2ns maximum
Residual noise level Data length 10kW, normal mode, without average or accumulate, input shorted	Whichever is the larger of \pm 0.5 mV and \pm 0.1 div (Typ.)
Channel to channel isolation	$-$ 40dB (Typ.) in same range (DC to 100MHz)
A-D converter resolution	8 bit (25 LSB/div)
Maximum sampling rate	25MS/s One/two events simultaneously
Maximum data length	32kW/CH (20kW) ... For one/two event single shot long 10kW/CH For normal sampling Figures in parentheses shows record length displayed on the CRT.

* Under reference operating conditions

7.2 Trigger Section Specifications

Item	Specifications
Trigger source	CH1, CH2, EXT, LINE
Trigger mode	Normal, Auto, Auto level, Single (Short memory, long memory)
Trigger slope	Rise, Fall, Rise and Fall
Trigger coupling	DC, AC, HFrej, TV
Trigger level setting range	± 8 div (Based on the center of CRT)
Trigger level setting resolution	1 / 50div
Triggering sensitivity	1div p-p (DC to 100MHz)
Trigger delay	0 div to 10 div on the screen
Trigger level accuracy *	$\pm (1.0 \text{ div} + 10 \% \text{ of trigger level})$ For $\pm 60 \%$ trigger level and trigger signal of ± 5 div max with rate-of-change not exceeding 10 div / μs , at normal mode.
Channel to channel trigger skew* (on 50mV/div range, for 5div p-p pulse with 1ns rise)	CH1 to CH2 : 5ns max on same range
External trigger Input impedance	$1\text{M}\Omega \pm 1.5\%$ Approx. 27pF
External trigger Input range	$\pm 0.5\text{V}$, $\pm 5\text{V}$ (FULL)
External trigger Maximum input voltage	250V DC + AC peak
External trigger Frequency response	DC to 50MHZ (-3dB band)
External triggering sensitivity	10% of Full range (DC to 50MHz) 100mV or 1V

* Under reference operating conditions

7.3 Time Axis Specifications

Item	Specifications
Sweep time	10ns/div to 50s/div
Time axis accuracy *	± (0.01 %)

* Under reference operating conditions

7.4 Communications

Item	Specifications
GP-IB	Conforms to IEEE St'd 488-1978 (JISC1901-1987) Functional specifications: SH1, AH1, T5, L4, SR1, RL1, PP0, DC1, DT0, C0
RS-232C (option)	Conforms to EIA RS-232C Transmission rate: 75, 150, 300, 600, 1200, 2400, 4800, 9600 bit/s

7.5 Printer

Item	Specifications
Printing technique	Thermal line dot technique
Dot density	6 dot/mm
Paper width	112mm (4.41-inch)

7.6 Others


Item	Specifications
CRT	Size : 7-inch, Display technique : Raster-scan, Phosphor color : Amber
Signal output	TRIGGER OUT : TTL levels, Negative logic, Hold time $3\mu\text{s}$ minimum GO/NO-GO (PASS/FAIL) test output : TTL levels, Negative logic, Hold time 1ms minimum
Calibrator output	1 kHz Approx. 1Vp-p
Input signal amplitude to obtain stable synchronization for TV trigger	1.5div

7.7 General Specifications




Item	Specifications
Reference operating conditions	Ambient temperature $23 \pm 2^{\circ}\text{C}$, Humidity $55 \pm 10\% \text{R.H.}$, Power supply voltage and Frequency error $\pm 1\%$ of rating maximum
Warmup time	30 minutes minimum
Operating temperature range	5 to 40°C
Storage temperature range	-20 to 60°C
Operating humidity range	20 to 85%R.H. (except printer), 35 to 85%R.H. (when printer used)
Power consumption	150VA (MAX) (7001□□-1) 200VA (MAX) (7001□□-5)
Supply power requirements	Rated Supply Voltage Range 100-120Vac ($\pm 10\%$) (7001□□-1) 200-240Vac (-10% , $+5\%$) (7001□□-5) Rated Supply Frequency Range 50/60Hz (Operating Frequency Range 48 to 63Hz)
Dielectric strength	1.5kV AC 1 minute
Insulation resistance	500V DC 10M Ω minimum
Size	Approx. 204 (8.03) W \times 295 (11.61) H \times 333 (13.11) D mm (inch)
Weight	Approx. 8kg (main unit only, no options)
Cooling	Forced-air cooling
Operating orientation	Horizontal
Battery back-up	The setting contents are protected by a built-in lithium battery. (Battery life: About 10 years at an ambient temperature of 23°C)

7.8 External Dimensional Drawings

Unit : mm
(Approx. inch)



Rear Panel



APPENDIX

ITEMS

Appendix A. Messages	A - 1
A.1 Error Messages	A - 1
A.2 Messages	A - 2
Appendix B. Relationship between Time/div, Sampling Rate, and Memory Length	B - 1
B.1 Normal Mode	B - 1
B.2 Equivalent Time Sampling Mode	B - 2
B.3 At Single Mode (Long)	B - 3

Appendix A. Messages

A.1 Error Messages

Error No.	Message	Meaning
001	Printer does not exist	Printer not installed
002	RS - 232C board does not exist	RS-232C not installed
003	Mc-unit does not exist	No IC memory card is installed in the slot.
010	Calibration error	No calibration has been made.
150	Invalid date/time	Date/time setting error
180	All 'x' not allowed	Attempted to set Xs for all channels CH1 to CH4 in parallel pattern setup.
183	Accumulate OFF	Accumulate goes OFF when BOTH or ONLY is selected for the window mode while equivalent-time sampling is being executed with accumulate set to ON.
185	Illegal data	Entry-data error
186	Illegal channel selection	A channel set to OFF at NO-GO determination or a channel displaying load waveform was selected.
187	clock channel does not exist	Indicates that the specified clock channel data does not exist. Select a channel with data as a clock channel.
188	Zone area does not exist	Zone area is not defined correctly.
189	Illegal W-form selection	W-form selection is not proper.
200	Invalid command	Communication command error
201	Invalid parameter	Communication parameter error
202	Transmission aborted	Transmission was aborted (communication parameters modified while transmission in progress). Also occurs if next command received.
204	Command is not executable	Unable to execute communication command.
205	Transmission time out	Transmission time-out occurred.
300	Illegal printer head position or no paper	No paper, or printer head is up.
301	Printer head is over heated	Printer head overheated (or overcooled).
302	Copy aborted	Aborted during printout.
303	Printer time out	Timeout occurred.
304	Printer failure	Printer abnormal
305	Paper end	No paper
500	Memory card does not exist	No IC card.
501	Memory card full	Insufficient free capacity on IC card.
502	File not found	Target file not present.
503	Data not found	Target data not present.
504	File is protected	File is a protected file.
505	Invalid data points	Invalid range specified for save.
506	Memory card failure	Abnormality detected in IC card.
507	Directory not found	Unable to read directory.
508	Invalid file name	Input error in file name specification.
509	File failure	Error found in target file.
510	Data cannot be reloaded	Unable to reload data. (When, as a result of writing to an in-use IC card with MEM1 or MEM2, an error occurs in the file in use.)
511	File already exists	In Save or Copy, file with same name as specified file name already exists.
512	Memory card is protected	Card being operated on is protected (when attempt is made to write to card).
900	Combination error	Executing combination is not proper. (When saving into IC card, etc.)

A.2 Messages (1 / 2)

Message	Description
Deleting ...	Indicates that a file is being deleted.
Copying ...	Indicates that a file is being copied.
Formatting ...	Indicates that formatting is being executed.
Protecting ...	Indicates that a file is being protected.
Battery failure!	Indicates that the battery has failed (when the battery is low).
Cannot be executed while NO-GO	Indicates that no operation is available because of NO-GO (FAIL) determination.
Cannot be executed while MEASURE	Indicates that no operation is available because measurement is being carried out.
Cannot be executed while SETUP	Indicates that no operation is available because auto setup is being executed.
Pattern found	Indicates that the pattern specified by the window search has been found.
Pattern not found	Indicates that the pattern specified by the window search cannot be found.
A-D not stopped	Window search is available only when A-D is stopped, so execute a window search only after stopping A-D.
Cannot zoom!	The window mode cannot be set to BOTH when phase shift is set to ON. Set the window mode to an item other than BOTH. When the interpolation display is activated due to a large expansion rate, the phase cannot be shifted.
Please set window function	When a copy (long mode) is made, copy long is not available if the window mode is set to an item other than INTEN or if the X-Y mode is set to item other than OFF. Set the window mode to INTEN and X-Y mode to OFF.
Cannot copy	Displayed when EXEC is pressed with the window mode other than INTEN, the X-Y mode other than OFF or the accumulation mode other than OFF, in the copy long mode set the window to INTEN, the X-Y mode to OFF and the accumulation mode to OFF.
Cannot copy while transmitting	Indicates the operation is disabled, because the data is being transmitted.
Please half size off	Editing is not available if HALF SIZE is ON when the NO-GO (FAIL) mode is set to ZONE, so set the HALF SIZE to OFF.
Initializing ...	Indicates that an initialization is being executed.
Auto setup ...	Indicates auto setup is under execution.
Testing ...	Indicates that self-testing is being carried out.
System ROM OK	Indicates that the self-test ROM test results are correct.
System ROM failed	Indicates that the self-test ROM test resulted in an error.
System RAM OK	Indicates that the self-test RAM test results are correct.
System RAM failed	Indicates that the self-test RAM test resulted in an error.
Display RAM OK	Indicates that the self-test display RAM test results are correct.
Display RAM failed	Indicates that the self-test display RAM test resulted in an error.
Graphic RAM OK	Indicates that the self-test graphic RAM test results are correct.
Graphic RAM failed	Indicates that the self-test graphic RAM test resulted in an error.
Acquisition RAM OK	Indicates that the self-test acquisition RAM test results are correct.
Acquisition RAM failed	Indicates that the self-test acquisition RAM test resulted in an error.
Cannot be executed while A-D	Indicates that the operation is not possible due to A-D start.
Please push any key!	Press any key when the operation is moved to the next operation during the self-test.
Please phase shift off!	The window mode cannot be set to BOTH when the phase is being shifted. Set phase shift to OFF.
Please set another window mode!	Phase shift cannot be executed when the window mode is set to BOTH. Set the window mode to a mode other than BOTH.
Please set another trig source	Transaction can't be done at the present trigger source. Set another trigger source.

A.2 Messages (2/2)

Message	Description
Please X-Y mode off	Transaction can't be done because X-Y mode is ON. Turn the X-Y mode to OFF.
Cannot accumulate on!	Accumulate cannot be set to ON when the window mode is set to BOTH or ONLY and equivalent time sampling is being executed. Set the window mode to OFF or INTEN.
NO-GO ended	Indicates the NO-GO transaction is ended.
Rotate knob to end test	When self-test is executed, rotating the rotary knob or moving to the next operation disables proceeding to the next operation.
Single (long) T/D is 50s - 100 μ s	Measurement cannot be executed in the single mode unless Time/div is between 50s and 100 μ s. Set Time/div to 50s through 100 μ s.
Calibration	Indicates that calibration is being executed.
Please set another trigger mode!	A single long cannot be executed when the window mode is set to BOTH. Set the window mode to an item other than BOTH or the trigger mode to an item other than long.
Cannot phase shift on	Phase shift does not apply to interpolated data. If you wish to do so, set WINDOW mode to OFF, or decrease the scale of zooming.
GP-IB mode must be talk only	GP-IB mode is not talk only. Set the mode to talk only. (When outputs plotter, etc.)

Appendix B. Relationship between Time / div, Sampling Rate, and Memory Length

B.1 Normal Mode

Acquisition Mode Time / div	Normal		Envelope		Averaging	
	Sample Rate (S/s)	Data Length (W)	Sample Rate (S/s)	Data * Length (W)	Sample Rate (S/s)	Data Length (W)
50s	20	10k	20M	5k(10k)	10	5k
20s	50	10k	20M	4k (8k)	20	4k
10s	100	10k	20M	5k (10k)	50	5k
5s	200	10k	20M	5k (10k)	100	5k
2s	500	10k	20M	4k (8k)	200	4k
1s	1k	10k	20M	5k (10k)	500	5k
500ms	2k	10k	20M	5k (10k)	1k	5k
200ms	5k	10k	20M	4k (8k)	2k	4k
100ms	10k	10k	20M	5k (10k)	5k	5k
50ms	20k	10k	20M	5k (10k)	10k	5k
20ms	50k	10k	20M	4k (8k)	20k	4k
10ms	100k	10k	20M	5k (10k)	50k	5k
5ms	200k	10k	20M	5k (10k)	100k	5k
2ms	500k	10k	20M	4k (8k)	200k	4k
1ms	1M	10k	20M	5k (10k)	500k	5k
500 μ s	2M	10k	20M	5k (10k)	1M	5k
200 μ s	5M	10k	20M	2k (4k)	2M	4k
100 μ s	10M	10k	20M	5k (10k)	5M	5k
50 μ s	20M	10k			10M	5k
20 μ s	20M	4k	(Same operation as in the normal mode)		20M	4k
10 μ s	20M	2k			20M	2k
5 μ s	20M	1k			20M	1k
2 μ s	25M	500			25M	500
1 μ s						
500ns						
200ns						
100ns	Equivalent-time sampling (See Appendix B-2, Table B.2.)					
50ns						
20ns						
10ns						

* In the envelope mode, 2 data express 1 point so the actual data length is two times longer. The amount of data is found inside of the ().

B.2 Equivalent Time Sampling Mode

Acquisition Mode Time / div	Normal		Envelope		Averaging	
	Sample Rate (S/s)	Data * Length (W)	Sample Rate (S/s)	Data Length (W)	Sample Rate (S/s)	Data Length (W)
50s						
20s						
10s						
5s						
2s						
1s						
500ms						
200ms						
100ms						
50ms						
20ms						
10ms						
5ms	Normal mode operation					
2ms						
1ms						
500µs						
200µs						
100µs						
50µs						
20µs						
10µs						
5µs						
2µs						
1µs	500M (50M)	5k (500)*			500M (50M)	5k
500ns	1G (100M)	5k (500)*			1G (100M)	5k
200ns	2G (250M)	4k (500)*			2G (250M)	4k
100ns	5G (500M)	5k (500)*			5G (500M)	5k
50ns	5G (1G)	2.5k (500)*			5G (1G)	2.5k
20ns	5G (2.5G)	1k (500)*			5G (2.5G)	1k
10ns	5G (5G)	500 (500)*			5G (5G)	500

* Values in parentheses are used when the ACCUMULATE mode is set to ON.

Note: The sampling rate of this mode is expressed by the equivalent-sampling rate obtained by converting the maximum time-resolution.

B.3 At Single Mode (Long)

Time / div	One or Two Channels are used	
	Sample Rate (S/s)	Data Length (W)
50s	40	32k (20k)*
20s	100	32k (20k)*
10s	200	32k (20k)*
5s	400	32k (20k)*
2s	1k	32k (20k)*
1s	2k	32k (20k)*
500ms	4k	32k (20k)*
200ms	10k	32k (20k)*
100ms	20k	32k (20k)*
50ms	40k	32k (20k)*
20ms	100k	32k (20k)*
10ms	200k	32k (20k)*
5ms	400k	32k (20k)*
2ms	1M	32k (20k)*
1ms	2M	32k (20k)*
500 μ s	5M	32k (25k)*
200 μ s	10M	32k (20k)*
100 μ s	20M	32k (20k)*

* Values in parentheses indicate the data length displayable on the CRT.

YOKOGAWA

YOKOGAWA ELECTRIC CORPORATION

Headquarters

9-32, Nakacho 2-chome, Musashino-shi, Tokyo, 180 JAPAN
Telex : 02822-327 YEW MT J

Tokyo Office

Shinjuku Center Bldg. (50F)
25-1, Nishi-shinjuku 1-chome, Shinjuku-ku, Tokyo, 163 JAPAN
Phone : 03-3349-0611 Fax : 03-3348-3705
Telex : J27584 YEW TOK

Branch Sales Offices

Nagoya, Osaka, Hiroshima, Fukuoka, Sapporo, Sendai, Omiya,
Ichiyama, Kawasaki, Toyoda, Kanazawa, Kobe, Takamatsu,
Okayama, and Kitakyusyu.

Overseas Representative Offices / Service Centers

Beijing, Shanghai (The People's Republic of China), Jakarta
(Indonesia)

YOKOGAWA CORPORATION OF AMERICA

Headquarters

2 Dart Road, Shenandoah Industrial Park, Newnan, Ga. 30265-1094,
U.S.A.

Phone : 1-404-253-7000 Fax : 1-404-251-2088
Telex : 230-244880 YCA

Branch Sales Offices / Holliston, Chagrin Falls, Santa Fe
Springs

JOHNSON YOKOGAWA CORPORATION

Headquarters

4 Dart Road, Shenandoah Industrial Park, Newnan, Ga. 30265-1040,
U.S.A.

Phone : 1-404-254-0400 Fax : 1-404-254-0928

Branch Sales Offices / Anaheim, Elmhurst, Rutherford, Houston

YOKOGAWA EUROPE B. V.

Headquarters

Radiumweg 30, 3812 RA Amersfoort, NETHERLANDS

Phone : 31-33-641611 Fax : 31-33-631202

Telex : 44-79118 YEF NL

Branch Sales Offices / Maarssen (Netherlands), Wien (Austria),
Zaventem (Belgium), Meylan (France), Ratingen (Germany), Madrid
(Spain), Manchester (United Kingdom), Milano (Italy)

YOKOGAWA ELECTRICA DO BRASIL IND. E COM. LTDA.

Praca Acapulco, No.31 Parque Industrial Jurubatuba CEP 04675
Santo Amaro - Sao Paulo, SP BRAZIL

Phone : 55-11-548-2666 Telex : 38-1157755 YOKO BR

Fax : 55-11-522-5231

YOKOGAWA ELECTRIC ASIA PTE. LTD.

11 Tampines Street 92, Singapore 1852,

SINGAPORE

Phone : 65-783-9537 Fax : 65-786-2606

Telex : RS87-26137 YASSIN

HANKUK YOKOGAWA ELECTRIC CO., LTD.

K.P.O.Box : 1481, Korean Reinsurance Bldg. 205,

80 Susong-Dong, Chongro-ku, Seoul, KOREA

Phone : 82-2-733-0771 to-0775 Fax : 82-2-739-3987

YOKOGAWA AUSTRALIA PTY. LTD.

Head Office

Private mail bag 24, Centre Court D3, 25-27 Paul Street
North, North Ryde, N.S.W.2113, AUSTRALIA

Phone : 61-2-805-0699 Fax : 61-2-888-1844

YOKOGAWA KEONICS LTD.

Headquarters

40 / 4 Lavelle Road Bangalore 560 001, INDIA

Phone : 91-812-211513 Fax : 91-812-214270

Telex : 81-8458702 YKCO IN

YOKOGAWA CONTROLE BAILEY S. A.

5, avenue Newton, 92140 Clamart, FRANCE

Phone : 33-1-46-29-10-00 Fax : 33-1-46-32-70-72

Telex : 33-1-631 251

Sep. '92