

---

**User's  
Manual**

***DX*Advanced®**

**Model DX2004/DX2008/DX2010/DX2020/  
DX2030/DX2040/DX2048  
Daqstation DX2000**

---

**vigilantplant®**

---

## Foreword

Thank you for purchasing the Daqstation DX2000 (hereafter referred to as "DX"). This User's Manual explains how to use the useful functions of the DX2000. To ensure correct use, please read this manual thoroughly before operation. The following five manuals are provided as DX2000 manuals.

### • Paper Manual

Manual Title	Manual No.	Description
DX2000 Operation Guide	IM 04L42B01-02E	Explains the basic operations of the DX2000. It is also provided in the CD-ROM.
Control of Pollution Caused by the Product	IM 04L41B01-91C	Gives a description of pollution control.

### • Electronic Manuals Provided on the Accompanying CD-ROM

Manual Title	Manual No.	Description
DX2000 Operation Guide	IM 04L42B01-02E	This is the electronic version of the paper manual.
DX2000 User's Manual	IM 04L42B01-01E	Describes how to use the application functions. Communication and network functions are not covered.
DX1000/DX1000N/DX2000 Communication Interface User's Manual	IM 04L41B01-17E	Describes how to use the communication functions using the Ethernet and serial interfaces.
DAQSTANDARD User's Manual	IM 04L41B01-61E	Describes how to use the accompanying software program, DAQSTANDARD.

## Notes

- The contents of this manual are subject to change without prior notice as a result of continuing improvements to the instrument's performance and functions.
- Every effort has been made in the preparation of this manual to ensure the accuracy of its contents. However, should you have any questions or find any errors, please contact your nearest YOKOGAWA dealer.
- Copying or reproducing all or any part of the contents of this manual without YOKOGAWA's permission is strictly prohibited.
- The TCP/IP software of this product and the document concerning the TCP/IP software have been developed/created by YOKOGAWA based on the BSD Networking Software, Release 1 that has been licensed from the Regents of the University of California.

## Trademarks

- All the brands or names of Yokogawa Electric's products used in this manual are either trademarks or registered trademarks of Yokogawa Electric Corporation.
- Microsoft, MS-DOS, Windows, Windows XP, and Windows NT are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Adobe, Acrobat, and PostScript are trademarks of Adobe Systems Incorporated (Adobe Systems).
- CompactFlash and CF are trademarks of SanDisk Corporation.
- For purposes of this manual, the ™ and ® symbols do not accompany their respective trademark names or registered trademark names.
- Company and product names that appear in this manual are trademarks or registered trademarks of their respective holders.

## Revisions

First edition: December 2005      Third edition: April 2007  
Second edition: October 2006

# DX's Version and Functions Described in This Manual

The contents of this manual corresponds to the DX with release number 2 and style number 2.

## DX's Version and Functions

For the procedure to check the version, see section 2.5.

Edition	DX	Suffix code	Addition and change to functions	Refer to
2	Version 1.11	-	(Added) German, French, and Chinese as display language	Section 2.6
		-	(Added) Modbus client connection retry interval: 10 s, 20 s, and 30 s	Communication manual
	Version 1.21	/P1	(Added) 24 VDC/AC power supply (/P1 option)	Operation Guide
		/USB1	(Added) Tab key on the USB keyboard corresponds to arrow keys.	Section 2.11
		-	(Added) Operations to request and release network information	Section 2.11
		-	(Changed) Modbus client: Function to connect a server with a unit number is changed.	Communication manual
		-	(Added) Modbus client: Connection timeout value	Communication manual
		-	(Added) Modbus registers (floating point type for communication input data)	Communication manual
-	(Added) A data output format (Skip or OFF channel data not output)	Communication manual		
-	(Changed) Error messages 105, 221, and 222 are added. Error messages 215, 218, 536 and 536 are changed.	Section 11.1		
3	Release number 2 (Version 2.0x)	-	(Added) Improvement to the operability on the historical trend display.	Section 4.3
		-	(Changed) Displaying the date in the grid time of the trend display when the trend interval is greater than or equal to 1 h/div.	Sections 1.3 and 2.4
		-	(Added) Improvement to the display group setup operation.	Section 5.1
		-	(Added) Addition of the Upper and Lower settings to the bar graph base position.	Section 5.11
		-	(Added) Addition of the relay action when alarm ACK is executed to the alarm output relay settings.	Sections 1.2, 3.5, and 3.8
		/M1, /PM1	(Added) Ability to reset the computed value during computation.	Section 9.4
		-	(Changed) Changes to how the data files are named.	Section 1.4
		-	(Added) Sorting the files by the update date/time.	Sections 6.7, 6.8, and 6.9
		-	(Added) Storage method for constantly retaining the most recent data files in the CF card (Media FIFO).	Sections 1.4 and 6.2
		-	(Added) Progress display when saving all data of the internal memory.	Sections 4.8
		-	(Changed) Changing the initial display selection menu.	Sections 4.8 and 5.18
		/USB1	(Changed) Improvement to the data save operation to the USB flash memory.	Sections 2.12 and 5.18
		/USB1	(Changed) Retaining the state of the CapsLock and NumLock keys on the USB keyboard	Section 2.11
		/MC1	(Added) Function for automatically assigning MW100s to the Modbus client.	Communication manual
		-	(Changed) Changing the default setting of the web server function.	Operation Guide
	-	(Added) Error messages, 129, 131, 132, 133, 134, 135, 136, 137, 513, 514, 515, and 516 have been added.	Section 11.1	
Style number 2	-	(Added) The waterproof construction of the DX front panel complies with the NEMA4 standard	Section 13.6	

---

# How to Use This Manual

## Structure of the Manual

Read the Operation Guide first to familiarize yourself with the basic operation, and then read this manual. For a description of the communication function and the accompanying software program, DAQSTANDARD, read the respective manual.

This user's manual consists of the following sections.

Chapter	Title and Contents
1	<b>Overview of Functions</b> Describes the functions of the DX.
2	<b>Common Operations</b> Describes the procedure to set the time and the operating procedure using the remote control terminal (/KB1 or /KB2 option) and keyboard (/USB1 option).
3	<b>Measurement Channels and Alarms</b> Describes how to set the measurement conditions and alarms.
4	<b>Switching Operation Screens</b> Describes the operations on the operation screen.
5	<b>Operations for Changing the Displayed Contents</b> Describes how to change the displayed contents on the operation screen and how to write messages.
6	<b>Saving and Loading Data</b> Describes how to acquire and store the data. Also describes the procedure to load measured data/setup data on the CF card or the USB flash memory (/USB1 option).
7	<b>Customizing the Action (Event Action)</b> Describes how to carry out specific actions when a given event occurs, when a remote control signal is applied, and when the USER key is pressed.
8	<b>Using the Security Function</b> Describes how to use the key lock function and the function that allows only registered users to operate the DX.
9	<b>Computation and Report Functions (/M1 and /PM1 Options)</b> Describes how to use computation channels and how to create reports such as hourly, daily, weekly, and monthly reports.
10	<b>External Input Channels (/MC1 Option)</b> Describes how to use external input channels.
11	<b>Troubleshooting</b> Describes error messages and troubleshooting.
12	<b>Maintenance</b> Describes periodic inspection and calibration.
13	<b>Specifications</b> Lists the specifications of the DX.
Appendix	Describes how to estimate the file size, the types of data that the DX can generate and how to use them, the data format of ASCII files, etc.
Index	

### Note

- This user's manual covers information regarding DX2000s that have a suffix code for language "-2" (English).
- For details on setting the display language, see section 2.6, "Changing the Displayed Language."



## Conventions Used in This Manual

Unit	
K	Denotes 1024. Example: 768 KB (file size)
k	Denotes 1000.

### Markings



*Improper handling or use can lead to injury to the user or damage to the instrument.* This symbol appears on the instrument to indicate that the user must refer to the user's manual for special instructions. The same symbol appears in the corresponding place in the user's manual to identify those instructions. In the manual, the symbol is used in conjunction with the word "WARNING" or "CAUTION."

**WARNING** Calls attention to actions or conditions that could cause serious or fatal injury to the user, and precautions that can be taken to prevent such occurrences.

**CAUTION** Calls attentions to actions or conditions that could cause light injury to the user or damage to the instrument or user's data, and precautions that can be taken to prevent such occurrences.

**Note** Calls attention to information that is important for proper operation of the instrument.

### Subheadings

**Bold characters** Denotes key or character strings that appear on the screen. Example: **Volt**

**Aa#1** Indicates character types that can be used. **A** Uppercase alphabet, **a** lowercase alphabet, **#** symbols, **1** numbers.

**Procedure** Carry out the procedure according to the step numbers. All procedures are written with inexperienced users in mind; depending on the operation, not all steps need to be taken. **Explanation** gives information such as limitations related the procedure.

**Setup Screen** Indicates the setup screen and explains the settings. A detailed description of the function is not provided in this section. For details on the function, see chapter 1. **Setup Items**

# Contents

Foreword.....	i
DX's Version and Functions Described in This Manual.....	ii
How to Use This Manual.....	iii
<b>Chapter 1 Overview of Functions</b>	
1.1 Input Section.....	1-1
1.2 Alarms.....	1-4
1.3 Display.....	1-7
1.4 Data Storage Function.....	1-23
1.5 Batch Function.....	1-33
1.6 Event Action Function.....	1-34
1.7 Security Function.....	1-37
1.8 Computation and Report Function (/M1 and /PM1 Options).....	1-39
1.9 FAIL/Status Output Function (/F1 and /F2 Options).....	1-45
1.10 Other Functions.....	1-47
<b>Chapter 2 Common Operations</b>	
2.1 Setting the Date/Time.....	2-1
2.2 Setting the Time Difference from GMT.....	2-2
2.3 Setting the Time Correction Operation during Memory Sampling.....	2-3
2.4 Setting the Date Format.....	2-4
2.5 Viewing the DX Information.....	2-5
2.6 Changing the Displayed Language.....	2-6
2.7 Setting the LCD Brightness and Backlight Saver.....	2-7
2.8 Initializing Settings and Clearing the Internal Memory.....	2-8
2.9 Outputting the DX Status via the Relay Contact (/F1 and /F2 Options).....	2-9
2.10 Controlling the DX with the Remote Control Terminal (/KB1 and /KB2 Options).....	2-10
2.11 Controlling the DX with a Keyboard (/USB1 Option).....	2-15
2.12 Using the USB Flash Memory (/USB1 Option).....	2-17
<b>Chapter 3 Measurement Channels and Alarms</b>	
3.1 Setting the Scan Interval and the Integration Time of the A/D Converter.....	3-1
3.2 Setting the Burnout Detection and the Reference Junction Compensation of the Thermocouple Input.....	3-2
3.3 Setting the Input Range.....	3-3
3.4 Setting the Moving Average of the Input.....	3-6
3.5 Setting the Auxiliary Alarm Function.....	3-7
3.6 Hiding the Alarm Indication.....	3-10
3.7 Setting Alarms on Channels.....	3-11
3.8 Releasing the Alarm Output (Alarm ACK Operation).....	3-14
3.9 Performing Calibration Correction (/CC1 Option).....	3-15
3.10 Counting Pulses (/PM1 Option).....	3-16
3.11 Setting the Method of Detecting Over-Range Values of Linearly Scaled Measurement Channels.....	3-19
<b>Chapter 4 Switching Operation Screens</b>	
4.1 Operations in Operation Mode.....	4-1
4.2 Displaying the Measured Data as Waveforms, Values, or Bar Graphs.....	4-3
4.3 Displaying Past Measured Data (Historical Trend Display).....	4-5

4.4	Display the Statuses of All Channels on One Screen (Overview Display).....	4-10
4.5	Displaying Various Information.....	4-11
4.6	Using the Alarm Summary .....	4-13
4.7	Using the Message Summary.....	4-14
4.8	Using the Memory Summary.....	4-15
4.9	Displaying a List of Operation Logs .....	4-18
4.10	Showing the Four Panel Display .....	4-22

## Chapter 5 Operations for Changing the Displayed Contents

5.1	Setting Display Groups .....	5-1
5.2	Displaying Tags or Channel Numbers.....	5-3
5.3	Setting the Trend Interval and Switching to the Secondary Trend Interval .....	5-4
5.4	Writing Messages.....	5-6
5.5	Changing the Channel Display Colors .....	5-9
5.6	Displaying Channels in Display Zones.....	5-10
5.7	Displaying a Scale on the Trend Display.....	5-11
5.8	Displaying Alarm Point Marks and Color Scale Band on the Scale .....	5-15
5.9	Partially Expanding the Waveform .....	5-17
5.10	Changing the Display Layout, Clearing of the Waveform at Start, Message Display Direction, Waveform Line Width, and Grid.....	5-19
5.11	Changing the Bar Graph Display Method .....	5-20
5.12	Using the Circular Display.....	5-23
5.13	Changing the Background Color of the Display .....	5-30
5.14	Automatically Switching Display Groups.....	5-31
5.15	Automatically Reverting to the Specified Display.....	5-32
5.16	Registering the Favorite Display .....	5-33
5.17	Writing a Message When the DX Recovers from a Power Failure .....	5-34
5.18	Changing the FUNC Key Menu and Display Selection Menu.....	5-35

## Chapter 6 Saving and Loading Data

6.1	Setting the Recording Conditions of the Measured Data .....	6-1
6.2	Setting the Method for Saving the Data .....	6-4
6.3	Using the Batch Function .....	6-6
6.4	Starting/Stopping the Recording and Saving the Measured data .....	6-8
6.5	Manually Saving the Measured Data (Manual Sample).....	6-11
6.6	Saving the Screen Image Data (Snapshot).....	6-12
6.7	Managing the Files on the Storage Medium .....	6-13
6.8	Loading and Displaying the Measured Data in the Storage Medium .....	6-15
6.9	Saving/Loading the Setup Data .....	6-16

## Chapter 7 Customizing the Action (Event Action)

7.1	Setting the Event Action Function (Including Remote Control (/R Option) and USER Key).....	7-1
7.2	Setup Examples of Event Action .....	7-5

## Chapter 8 Using the Security Function

8.1	Disabling the Key Operation (Key Lock Function) .....	8-1
8.2	Enabling Only Registered Users to Operate the DX (Login Function).....	8-3
8.3	Logging in and Logging Out.....	8-6

**Chapter 9 Computation and Report Functions (/M1 and /PM1 Options)**

9.1	Setting the Expression, Measurement Range, Alarm, Tag, and Data Storage on Computation Channels.....	9-1
9.2	Writing Expressions .....	9-5
9.3	Displaying the Computation Channels .....	9-11
9.4	Starting/Stopping Computation, Resetting Computation, and Releasing Computation Data Dropout Display .....	9-13
9.5	Creating Reports .....	9-15

**Chapter 10 Using External Input Channels (/MC1 Option)**

10.1	Setting External Input Channels.....	10-1
10.2	Displaying the External Input Channels .....	10-3

**Chapter 11 Troubleshooting**

11.1	A List of Messages .....	11-1
11.2	Troubleshooting.....	11-15

**Chapter 12 Maintenance**

12.1	Periodic Inspection.....	12-1
12.2	Calibrating the DX .....	12-2

**Chapter 13 Specifications**

13.1	Signal Input and Alarm .....	13-1
13.2	Display Function.....	13-3
13.3	Data Saving Function.....	13-5
13.4	Other Standard Functions .....	13-7
13.5	Options.....	13-9
13.6	General Specifications .....	13-14
13.7	External Dimensions .....	13-18

**Appendix**

Appendix 1	File Size of Display Data and Event Data .....	App-1
Appendix 2	Types of Data That the DX Can Create and Their Application.....	App-4
Appendix 3	Data Format of ASCII Files .....	App-5

**Index**

# 1.1 Input Section

## Measurement Channel

### • Number of Measurement Channels and Scan Interval

The DX samples the input signals on the measurement channels at the scan interval to obtain the measured values. The table below shows the relationship between the number of measurement channels and the scan interval.

Model	Number of Measurement Channels	Scan Interval		
		Normal Mode		Fast Sampling Mode
DX2004	4	125 ms 250 ms		25 ms
DX2008	8			
DX2010	10	1 s	2 s, 5 s	125 ms
DX2020	20			
DX2030	30			
DX2040	40			
DX2048	48			
Integration time of the A/D converter		60 Hz/50 Hz	60 Hz/50 Hz/100 ms	600 Hz (fixed)

For the setting procedure, see section 3.1.

### • Integration Time of the A/D Converter

The DX uses an A/D converter to convert the sampled analog signal to a digital signal. By setting the integration time of the A/D converter to match the time period corresponding to one cycle of the power supply or an integer multiple of one cycle, the power supply frequency noise can be effectively eliminated.

- Because 100 ms is an integer multiple of 16.7 ms and 20 ms, this setting can be used to eliminate the power frequency noise for both frequency, 50 Hz and 60 Hz.
- In fast sampling mode, the performance of eliminating power frequency noise is worse than in normal mode. We recommend that you use normal mode when making measurements in an environment affected by power frequency noise.

For the setting procedure, see section 3.1.

## Input Type and Computation

You can make measurements using the following input types.

Input Type	Description
DC voltage	Measures a DC voltage in the range of $\pm 20$ mV to $\pm 50$ V.
DC current	A shunt resistor*1 is attached to the input terminal. The current signal is converted to a voltage signal and measured. The measurable range is the range equivalent to the "DC voltage" range indicated above after converting the current to the voltage signal.
Thermocouple	Measures temperature corresponding to each type: R, S, B, K, E, J, T, N, W, L, U, and WRe3-25. Measurement is possible on other thermocouples such as PR40-20 and PLATINEL*2.
RTD	Measures temperature corresponding to each type: Pt100 and JPt100. Measurement is possible on other RTDs such as Cu10 or Cu25*3 and Pt50 or Ni100*2.
ON/OFF input	Displays the contact input or voltage input signals by correlating them to 0% or 100% of the display range. Contact input: Closed contact is ON (1). Open contact is OFF (0). Voltage input: Less than 2.4 V is OFF (0). Greater than or equal to 2.4 V is ON (1).
Pulse input*4	Counts the pulses.

\*1 Item sold separately. For example, a 250- $\Omega$  shunt resistor is used to convert the signal to 1 to 5 V for 4-20 mA input.


\*2 /N3 option.

\*3 /N1 option.

\*4 /PM1 option.

# 1.1 Input Section

The following input processing and computation are available.



Reference Junction Compensation	Burnout Detection																																							
<p>Performs reference junction compensation on the thermocouple.</p> <p>For the setting procedure, see section 3.2.</p>	<p>Detects and indicates a burnout in the sensor.</p> <p><b>Burnout</b>             Indicated as Burnout.</p> <p><b>Burnout</b>             Indicated as Burnout.</p> <p>For the setting procedure, see section 3.2.</p>																																							
Moving Average																																								
<p>Eliminates noise.</p> <p>Operation example when the number of moving average data points is 3</p> <table border="0" style="width: 100%;"> <tr> <td style="text-align: center;"> <p>Sampling data in the buffer</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 20px;">1</td><td style="width: 100px;">10.0 mV</td></tr> <tr><td style="width: 20px;">2</td><td style="width: 100px;">5.0 mV</td></tr> <tr><td style="width: 20px;">3</td><td style="width: 100px;">0.0 mV</td></tr> </table> </td> <td style="text-align: center; vertical-align: middle;"> <p>↓</p> <p>↓</p> <p>↓</p> <p>Clear</p> </td> <td style="text-align: center;"> <p>New sampled data</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 20px;">1</td><td style="width: 100px;">15.0 mV</td></tr> <tr><td style="width: 20px;">2</td><td style="width: 100px;">10.0 mV</td></tr> <tr><td style="width: 20px;">3</td><td style="width: 100px;">5.0 mV</td></tr> </table> </td> <td style="text-align: center; vertical-align: middle;"> <p>↓</p> <p>↓</p> <p>↓</p> <p>Clear</p> </td> <td style="text-align: center;"> <p>New sampled data</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 20px;">1</td><td style="width: 100px;">10.0 mV</td></tr> <tr><td style="width: 20px;">2</td><td style="width: 100px;">15.0 mV</td></tr> <tr><td style="width: 20px;">3</td><td style="width: 100px;">10.0 mV</td></tr> </table> </td> <td style="vertical-align: middle; padding-left: 20px;"> <p><b>Number of moving average data points: 2 to 400</b></p> </td> </tr> <tr> <td style="text-align: center;"> <p>Measured value (Moving average)</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 100px;">5.0 mV</td></tr> </table> </td> <td></td> <td style="text-align: center;"> <p>Measured value</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 100px;">10.0 mV</td></tr> </table> </td> <td></td> <td style="text-align: center;"> <p>Measured value</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 100px;">11.7 mV</td></tr> </table> </td> <td></td> </tr> <tr> <td style="text-align: center;"> <p>Sampling</p> </td> <td style="text-align: center;"> <p><math>n^{\text{th}}</math> time</p> </td> <td style="text-align: center;"> <p><math>n + 1^{\text{th}}</math> time</p> </td> <td style="text-align: center;"> <p><math>n + 2^{\text{th}}</math> time</p> </td> <td></td> <td></td> </tr> </table> <p>For the setting procedure, see section 3.4.</p>		<p>Sampling data in the buffer</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 20px;">1</td><td style="width: 100px;">10.0 mV</td></tr> <tr><td style="width: 20px;">2</td><td style="width: 100px;">5.0 mV</td></tr> <tr><td style="width: 20px;">3</td><td style="width: 100px;">0.0 mV</td></tr> </table>	1	10.0 mV	2	5.0 mV	3	0.0 mV	<p>↓</p> <p>↓</p> <p>↓</p> <p>Clear</p>	<p>New sampled data</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 20px;">1</td><td style="width: 100px;">15.0 mV</td></tr> <tr><td style="width: 20px;">2</td><td style="width: 100px;">10.0 mV</td></tr> <tr><td style="width: 20px;">3</td><td style="width: 100px;">5.0 mV</td></tr> </table>	1	15.0 mV	2	10.0 mV	3	5.0 mV	<p>↓</p> <p>↓</p> <p>↓</p> <p>Clear</p>	<p>New sampled data</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 20px;">1</td><td style="width: 100px;">10.0 mV</td></tr> <tr><td style="width: 20px;">2</td><td style="width: 100px;">15.0 mV</td></tr> <tr><td style="width: 20px;">3</td><td style="width: 100px;">10.0 mV</td></tr> </table>	1	10.0 mV	2	15.0 mV	3	10.0 mV	<p><b>Number of moving average data points: 2 to 400</b></p>	<p>Measured value (Moving average)</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 100px;">5.0 mV</td></tr> </table>	5.0 mV		<p>Measured value</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 100px;">10.0 mV</td></tr> </table>	10.0 mV		<p>Measured value</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 100px;">11.7 mV</td></tr> </table>	11.7 mV		<p>Sampling</p>	<p><math>n^{\text{th}}</math> time</p>	<p><math>n + 1^{\text{th}}</math> time</p>	<p><math>n + 2^{\text{th}}</math> time</p>		
<p>Sampling data in the buffer</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 20px;">1</td><td style="width: 100px;">10.0 mV</td></tr> <tr><td style="width: 20px;">2</td><td style="width: 100px;">5.0 mV</td></tr> <tr><td style="width: 20px;">3</td><td style="width: 100px;">0.0 mV</td></tr> </table>	1	10.0 mV	2	5.0 mV	3	0.0 mV	<p>↓</p> <p>↓</p> <p>↓</p> <p>Clear</p>	<p>New sampled data</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 20px;">1</td><td style="width: 100px;">15.0 mV</td></tr> <tr><td style="width: 20px;">2</td><td style="width: 100px;">10.0 mV</td></tr> <tr><td style="width: 20px;">3</td><td style="width: 100px;">5.0 mV</td></tr> </table>	1	15.0 mV	2	10.0 mV	3	5.0 mV	<p>↓</p> <p>↓</p> <p>↓</p> <p>Clear</p>	<p>New sampled data</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 20px;">1</td><td style="width: 100px;">10.0 mV</td></tr> <tr><td style="width: 20px;">2</td><td style="width: 100px;">15.0 mV</td></tr> <tr><td style="width: 20px;">3</td><td style="width: 100px;">10.0 mV</td></tr> </table>	1	10.0 mV	2	15.0 mV	3	10.0 mV	<p><b>Number of moving average data points: 2 to 400</b></p>																	
1	10.0 mV																																							
2	5.0 mV																																							
3	0.0 mV																																							
1	15.0 mV																																							
2	10.0 mV																																							
3	5.0 mV																																							
1	10.0 mV																																							
2	15.0 mV																																							
3	10.0 mV																																							
<p>Measured value (Moving average)</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 100px;">5.0 mV</td></tr> </table>	5.0 mV		<p>Measured value</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 100px;">10.0 mV</td></tr> </table>	10.0 mV		<p>Measured value</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td style="width: 100px;">11.7 mV</td></tr> </table>	11.7 mV																																	
5.0 mV																																								
10.0 mV																																								
11.7 mV																																								
<p>Sampling</p>	<p><math>n^{\text{th}}</math> time</p>	<p><math>n + 1^{\text{th}}</math> time</p>	<p><math>n + 2^{\text{th}}</math> time</p>																																					

Square Root Computation	Linear Scaling
<p>Takes the square root of the input value and converts the unit to obtain the measured value.</p> $X = (B - A) \sqrt{\frac{x - a}{b - a}} + A$ <p>For the setting procedure, see section 3.3.</p>	<p>Converts the unit to obtain the measured value.</p> <p>For the setting procedure, see section 3.3.</p>
Calibration Correction (/CC1 Option)	Low-cut
<p>Corrects the input value with the characteristics specified by segments to obtain the measured value.</p> <p>For the setting procedure, see section 3.9.</p>	<p>For square root computation, measured values below the specified value are cut. For 1-5 V input, values below 0 % are cut.</p> <p>For the setting procedure, see section 3.3.</p>
Difference computation	Pulse Input (/PM1 Option)
<p>The measured value of the channel is set to the difference with respect to the measured value of the reference channel.</p> <p>For the setting procedure, see section 3.3.</p>	<p><b>Pulse that can be counted</b>      <b>Input to the DX</b></p> <p><b>Count on the DX</b>  <b>The contact changes from open to close.</b>  <b>The signal level at the input terminal changes from high to low.</b></p> <p>For the setting procedure, see section 3.10.</p>

**Note**

Difference computation is executed even if the input type or range is not the same between the difference computation channel and the reference channel. The difference is computed discarding the decimal place and unit, and the decimal place and unit of the difference computation channel are applied.

Example 1: If the input value of the difference computation channel is 10.00 and the measured value of the reference channel is 100.0, the computed result is 10.00 - 100.0 = -90.00.

Example 2: If the input value of the difference computation channel is 10.00 V and the measured value of the reference channel is 5.00 mV, the computed result is 10.00 V - 5.00 mV = 5.00 V.


## 1.2 Alarms

This function generates an alarm when the measured data meets a certain condition. Up to four alarms can be set for each channel.

### Alarm Type

You can use the alarms shown below. The character inside the parentheses is the symbol denoting each alarm.

For the alarm setting procedure, see section 3.7.



- **Alarm Hysteresis**

You can set a width (hysteresis) to the value used to activate and release alarms.

- **Delay High Limit Alarm and Delay Low Limit Alarm**

An alarm occurs when the measured value remains above or below the alarm value for a specified time period (delay period).

- **High Limit on Rate-of-Change Alarm and Low Limit on Rate-of-Change Alarm**

The rate-of-change of the measured values is checked over a certain time (interval). An alarm occurs if the rate-of-change of the measured value in the rising/falling direction is greater than or equal to the specified value.

The alarm value of the rate-of-change alarm is set using an absolute value. The interval is derived using the following equation and set using the number of samples.

$$\text{Interval} = \text{the scan interval} \times \text{the number of samples}$$

For the setting procedure, see section 3.5.

- **Difference Upper Limit Alarm and Difference Lower Limit Alarm**

An alarm occurs when the difference in the values of two channels is greater/less than or equal to the specified value. These alarms can be specified on measurement channels set to difference computation.



## Alarm Indication

The alarm conditions are displayed as alarm icons in the status display section and on the operation screen such as the trend, digital, bar graph, overview displays. Detailed information about the alarms is displayed in the alarm summary.

- **Hold/Non-hold of Indications**

The alarm indication can be set to operate in the following fashion when the condition is no longer met.

- Clear the alarm indication (non-hold).
- Hold the alarm indication until the alarm ACK operation is executed (hold).

The default setting is non-hold.

For the setting procedure, see section 3.5.

- **Alarm Hide Function**


The alarm setting is displayed, but no indication is made when an alarm occurs. The alarm is also not recorded in the alarm summary. The alarm is output to the relay (/A[ ] option) or internal switch. This function can be set for each channel and each alarm.

For the setting procedure, see section 3.6.

## Alarm Output Relay Operation

Contact signals can be generated from alarm output relays (/A\_ option) when alarms occur. The alarm output relay operation can be changed.

For the setting procedure, see section 3.5.



- **Reflash**

When multiple alarms are assigned to one alarm output relay, this function notifies the occurrence of subsequent alarms after the relay is activated by the first alarm. When subsequent alarms occur, the output relay is released temporarily (approximately 500 ms). The reflash function is set on the first three output relays.\*

\* I01 to I03 or I11 to I13. I01 and I02 for the /A1 option.

**Note**

---

When reflash is enabled, the first three output relays are used exclusively as reflash relays. The first three output relays are set to OR logic and de-energize operation regardless of the AND/OR and energize/de-energize settings explained below.

---

- **AND/OR**

When multiple alarms are assigned to one alarm output relay, the condition for activating the output relay can be selected from the following: You can select AND operation also for the internal switch.

- AND: Activated when all assigned alarms are occurring simultaneously.
- OR: Activated when any of the specified alarms is occurring.

- **Energize or De-energize Operation**

You can select whether the alarm output relay is energized or de-energized when an alarm occurs. If de-energized is selected, the status of the alarm output relay when an alarm occurs is the same as the status that results when the DX power is shut down. The setting applies to all alarm output relays.

- **Non-Hold/Hold**

The alarm output relay can be set to operate in the following fashion when the alarm condition is no longer met.

- Turn OFF the relay output (non-hold).
- Hold the relay at ON until the alarm ACK operation is executed (hold).

The setting applies to all alarm output relays.

- **Alarm ACK Operation**

The alarm acknowledge (alarm ACK) operation releases all alarm indications and relay outputs. For the action of alarm indication and alarm output relay when you carried out the alarm ACK operation, see the previous page.

**Note**


---

When you enter the basic setting mode, the hold/non-hold condition of the alarm output relay immediately before is retained. In the basic setting mode, alarms are not detected, and you cannot acknowledge alarms.

---

## Internal Switch

The alarm status can be output to software switches (30 internal switches). The values of the internal switch are shown below. Like the alarm output relay, you can specify AND/OR operation (see the previous page).




The internal switches can be used events of the event action function (see section 1.6). In addition, the internal switches can be written in calculation expressions of computation channels (/M1 or /PM1 option).

## 1.3 Display

### Common Items Related to the Display

- **10.4 TFT Color LCD and the Screen Configuration**

The DX has a 10.4-inch TFT color LCD (480 × 640 dot resolution). The screen consists of the status display section and the data display section.



- **Status Display Section**

The status display section shows the display name, date/time, batch name (when using the batch function), user name (when using the login function), usage of the internal memory or CF card, alarm occurrence, computation status (/M1 or /PM1 option), and usage of key lock or e-mail transmission.

- **Data Display Section**

The data display section shows the measured data using numeric values, waveforms, and bar graphs. It also shows the setup screen when setting functions.

- **Group Display**

On the trend, digital, and bar graph displays, the data of channels is displayed by groups that are set in advance. Up to 36 groups can be registered, and up to 10 channels can be assigned to each group. Groups are common to the trend, digital, and bar graph displays.

The displayed group can be switched automatically at a specified time interval (5 s to 1 min). For the setting procedure, see section 5.1.

- **Channel Number Display and Tag Name Display**

Channels can be displayed as tags or channel numbers. The setting applies to all channels.

For the setting procedure, see section 5.2.

- **Update Interval of Measured Values**

The values are updated every second. However, if the scan interval is greater than 1 s, the values are updated at the scan interval.

For the setting procedure, see section 5.3.

- **Alarm Indication**

Alarms that are set for each channel are checked at all times and are indicated with the symbol representing the alarm type on each display.


Alarm Type	Symbol	Alarm Type	Symbol
High limit alarm	H	High limit on rate-of-change alarm	R
Low limit alarm	L	Low limit on rate-of-change alarm	r
Difference high limit alarm	h	Delay high limit alarm	T
Difference low limit alarm	l	Delay low limit alarm	t



## Status Display Section


The following information is displayed in the status display section during operation mode or setting mode.


**Memory sampling status**

**Data type**  
 Display data  
 Event data

**Memory sampling stopped** 

**Memory sampling in progress**  


**Memory sampling icon** 

**Memory sampling progress**  
 Displays the progress using a green bar graph. The frame indicates the file save interval (display data) or the data length (event data).  
 Error in internal memory.  
 Contact your nearest YOKOGAWA dealer for repairs.  
 Displays the remaining memory sampling time for the left bar graph.


  


**Display name or group name**  
 For all channel display on the trend display, "All" is displayed.

**Date and time**  
 Displayed in yellow while the time is being corrected.



**When using the batch function**  
 **Batch name and the display name are shown alternately.**  
 Date and time


If the "batch number-lot number" exceeds 20 characters, the "date and time" position is used to display the "batch number-lot number."



**When using the login function**  
 **Name of the user logged in**  
 Display name  
 Date and time



**When using the login and batch functions**  
 **Name of the user logged in**  
 Batch name and the display name are shown alternately.  
 Date and time





  

**Alarm icon**  
 (Red) Displayed when any alarm is activated. Blinks when there are alarms that are occurring but have not been acknowledged.  
 (Green) All alarms have been released after they have occurred, but there are alarms that have not been acknowledged.

**Status icon**  
 The status assigned to the status output relay (/F1 option) is occurring.

 Keys are locked.  
 E-mail transmission is enabled.

**Computation icon (/M1 option)**  
 White icon: Computation started  
 Yellow icon: Computation data dropout occurred

**CF card icon**  
 CF card is being accessed.  
 Waiting.  
 Light blue icon: CF card in the slot is not recognized. Remove and reset it.  
 CF card error.  
 Carry out the procedure below to reset the CF card icon to normal.  

- Replace the CF card with a normal one.
- Format the CF card on the DX (the data on the CF card will be erased).

The green level display indicates the amount of CF card used. If Media FIFO\* is not enabled and the free space on the CF card falls below 10%, the level indicator changes to red.


\* See section 1.4, in the DX1000/DX1000N User's Manual. Media FIFO is a function available on release number 2 or later.

### Bar Graph

When a pretrigger is configured in the event data recording and you press the START key causing the DX to enter the trigger wait condition, the data in the pretrigger section is recorded. During this time, the bar is displayed in orange. After the pretrigger time elapses, the length of the bar fixed at that point. However, the relevant data is updated until the trigger condition is met. When the trigger condition is met, the bar turns green, and data is recorded after the data in the pretrigger section.





### Trend Display (T-Y)

Waveform data is displayed in a waveform. For the operating procedure, see section 4.2.



Displays the maximum and minimum values of the data sampled within the time corresponding to 1 dot.

Display layout See section 5.10.



• **Updating of the Waveform**

On the screen, 30 dots along the time axis is represented by a unit called division (see the figure on the previous page). The displayed waveform is updated at an interval corresponding to one dot. This interval is determined by the time corresponding to one division (referred to as the trend interval). The relationship between the trend interval and the speed of movement of waveforms on the screen is as follows:

<b>Trend interval [/DIV]</b>	<b>15 s*</b>	<b>30 s</b>	<b>1 min</b>	<b>2 min</b>	<b>5 min</b>
<b>Time (s) corresponding to 1 dot</b>	0.5	1	2	4	10
<b>Speed of movement of waveforms (approximate value, mm/h)</b>	2500	1250	625	312	156
<b>Trend interval [/DIV]</b>	<b>10 min</b>	<b>15 min</b>	<b>20 min</b>	<b>30 min</b>	<b>1 h</b>
<b>Time (s) corresponding to 1 dot</b>	20	30	40	60	120
<b>Speed of movement of waveforms (approximate value, mm/h)</b>	78	42	31	21	10
<b>Trend interval [/DIV]</b>	<b>2 h</b>	<b>4 h</b>	<b>10 h</b>		
<b>Time (s) corresponding to 1 dot</b>	240	480	1200		
<b>Speed of movement of waveforms (approximate value, mm/h)</b>	5.2	2.6	1.0		

\* Selectable on the DX2004 and DX2008

**Switching the Trend Interval**


You can switch from the normal trend interval to the secondary trend interval during memory sampling and vice versa. For the operating procedure, see section 5.3.

• **Writing Messages**

**Preset messages**

1	Start
2	Material 1
3	
4	

**Trend display**



**Free message**

Set the message when writing the message

**Preset Messages**

Preset messages are recalled and written.

The number of messages that you can use are 100 (message 1 to 10 are shared with free messages). For the operating procedure, see section 5.4

**Free Messages**


Messages are entered when you need to enter them. The number of messages that you can use are 10. For the operating procedure, see section 5.4.

**Automatic Message Writing**

- A message is written when the trend interval is switched during memory sampling. For the setting procedure, see section 5.3.
- A message is written when the power recovers from a power failure during memory sampling. For the operating procedure, see section 5.17.

**Message display method**


- Except for the vertical display, you can set the direction in which messages are displayed to horizontal or vertical. For the setting procedure, see section 5.10.
- Messages can be displayed consolidated at the upper left of the screen (list display). For the operating procedure, see section 4.2.



• **Zone Display**

You can display channels in specified zones. This function can be used to keep the waveforms from overlapping for easier view.

In the example below, channel 1 is displayed in the 0 to 30% zone, channel 2 in the 30 to 60% zone, and channel 3 in the 60 to 100% zone.




For the setting procedure, see section 5.6.

• **Partial Expanded Display**

By compressing a section of the waveform display range, the rest of the section is expanded.

In the example below, 0 V (boundary value) is moved to the 30% position of the display range (new boundary position). The 30% area below the boundary corresponds to “-6 V to 0 V” and 70% area above the boundary corresponds to “0 V to 6 V.”



For the setting procedure, see section 5.9.

• **Alarm Indication**


Alarm mark, alarm type, and measured value are displayed as follows according to the alarm status.

Alarm	Occurrence	When indication is set to non-hold				When indication is set to hold						
		Release	Alarm ACK	Alarm ACK	Alarm ACK	Alarm ACK	Alarm ACK	Alarm ACK	Alarm ACK	Alarm ACK	Alarm ACK	
Alarm mark	Green	Red	Green	Green	Blinking red	Blinking green	Green	Green	Blinking red	Red	Green	
Alarm type	None	Red	None	None	Red	None	None	None	Red	Red	None	
Measured value	Blue	Red	Blue	Blue	Red	Blue	Blue	Blue	Red	Red	Blue	



## Digital Display

Displays the measured data numerically using large numbers. For the operating procedure, see section 4.2.



### Note

- Numeric display of measurement channels**

If a measured value of a measurement channel is over range (see below), the measured value is indicated as “+Over” or “-Over.” If a burnout is detected on a channel whose burnout detection function is enabled, the word “Burnout” is indicated. Otherwise, a numeric value is displayed.

- Over range of measurement channels**

- For DC voltage input, over range occurs when the measured value of the measurement channel exceeds  $\pm 5\%$  of the measurable range. For example, the measurable range when the measurement range is 2 V is  $-2.000$  to  $2.000$  V. If the measured value exceeds  $2.200$  V, + over range occurs; if the measured value falls below  $-2.200$  V, - over range occurs.
- For thermocouple or RTD input, over range occurs when the measured value exceeds approximately  $\pm 10^\circ\text{C}$  of the measurable range. For example, the measurable range when the measurement range is R is  $0.0$  to  $1760.0^\circ\text{C}$ . If the measured value exceeds approximately  $1770.0^\circ\text{C}$ , + over range occurs; if the measured value falls below approximately  $-10.0^\circ\text{C}$ , - over range occurs.
- For channels that are linearly scaled, + over range occurs when the value exceeds 30000 excluding the decimal point; - over range occurs when the value falls below  $-30000$ . However, + over range can be changed to greater than or equal to 105% of the scale width and - over range to less than or equal to  $-5\%$  of the scale width within  $\pm 30000$ . For the setting procedure, see section 3.11.

- Numeric display of computation channels**

See section 1.8, “Computation and Report Function (/M1 and /PM1 Options)

- Numeric display of external input channels (/MC1 option)**

The numeric range that can be displayed is  $-30000$  to  $30000$  excluding the decimal point. The decimal place corresponds to the decimal place of the lower limit of span of the external input channel. On the numeric display, values are displayed if the value is within the  $-30000$  to  $30000$  range regardless of the upper and lower limits of span.

If the value exceeds 30000, + over range occurs; if the value falls below  $-30000$ , - over range occurs.

- Alarm Indication**

Alarm mark and measured value are displayed as follows according to the alarm status.


Alarm	Occurrence	When indication is set to non-hold				When indication is set to hold						
		Release				Alarm ACK				Alarm ACK		
Alarm mark	Green	Red	Green	Green	Blinking red	Blinking green	Green	Green	Blinking red	Red	Green	
Measured value	Blue	Red	Blue	Blue	Red	Blue	Blue	Blue	Red	Red	Blue	



## Bar Graph Display


Waveform data is displayed in a bar graph. For the operating procedure, see section 4.2.

### Vertical



Bar graph base position is set to Center  
See section 5.11.

### Horizontal See section 5.10.



- **Updating of the Bar Graph**

The bar graph is updated at the same interval as numeric values.

- **Alarm Indication**

Alarm mark, alarm point mark, and measured value are displayed as follows according to the alarm status.

Alarm	Occurrence	When indication is set to non-hold					When indication is set to hold					
		Release	Green	Red	Green	Green	Blinking red	Blinking green	Green	Green	Blinking red	Red
Alarm mark	Green	Red	Green	Green	Green	Blinking red	Blinking green	Green	Green	Blinking red	Red	Green
Point mark	Green	Red	Green	Green	Green	Red	Green	Green	Green	Red	Red	Green
Measured value	Blue	Red	Blue	Blue	Blue	Red	Blue	Blue	Blue	Red	Red	Blue

### Historical Trend Display

The waveform of the past measured data (display or event data) in the internal memory or external storage medium can be displayed. This function is called *Historical trend*.


- **Methods of Displaying the Historical Trend**

There are four methods to display the historical trend of the measured data in the internal memory.


- Display from the alarm summary. For the operating procedure, see section 4.6.
- Display from the message summary. For the operating procedure, see section 4.7.
- Display from the memory summary. For the operating procedure, see section 4.8.
- Recall from the display selection menu. For the operating procedure, see section 4.3.

Measured data on an external storage medium can also be displayed as historical trend. For the operating procedure, see section 6.8.

- **Displayed Contents**



**Half screen display**






Item	Description
Alarm summary	Displays an alarm summary of the displayed data.
Message summary	Displays a message summary of the displayed data.
Data information	Shows information about the displayed data (file name, sample start time, end time, etc.).

- **Added Messages**

Added messages can be written. For the operating procedure, see section 5.4.


### Circular Display

The circular display shows the measured data on a circular time axis in place of the trend display (T-Y). The time per revolution can be set in the range of 20 minutes to 4 weeks. For the operating procedure, see section 5.12.



- Historical Trend Display**

Displays the past data for each time of revolution. The displayed contents and operating procedure are the same as the historical trend of the T-Y display. Half screen display is not possible.




### Overview Display

Displays a list of the statuses of all channels.

You can move the cursor to select a channel and display the trend, digital, or bar graph of the group containing the selected channel.

For the operating procedure, see section 4.4.



- Alarm Indication**

Channel display area, tag name/channel number, alarm type, and measured value are displayed as follows according to the alarm status.

Alarm	When indication is set to non-hold					When indication is set to hold					
	Occurrence	Release	Alarm ACK	Alarm ACK	Alarm ACK	Alarm ACK	Alarm ACK	Alarm ACK	Alarm ACK	Alarm ACK	Alarm ACK
Tag/Channel	Black	White	Black	Black	Blinking white	Blinking black	Black	Black	Blinking white	White	Black
Channel area	Green	Red	Green	Green	Red	Green	Green	Green	Red	Red	Green
Alarm type	None	White	None	None	White	None	None	None	White	White	None
Measured value	Black	White	Black	Black	White	Black	Black	Black	White	White	Black

## Alarm Summary

Displays a list of the most recent alarms.

- Up to 1000 alarms can be displayed.
- You can select arbitrary alarm information and recall the historical trend of the display data or event data that contains the alarm information.

For the setting procedure, see section 4.6.

	Channel	Type	Alarm Time
▲ ON	TI-101	2L	2005/10/01 09:02:41
▲ ON	AC-307	2L	2005/10/01 09:01:18
▲ ON	AC-307	1L	2005/10/01 08:59:42
▼ OFF	PI-206	1H	2005/10/01 08:59:21
▼ OFF	TI-101	1H	2005/10/01 08:57:40
▼ OFF	OUT-102	1T	2005/10/01 08:56:15
● ACK			2005/10/01 08:55:49
▲ ON	OUT-102	1T	2005/10/01 08:55:13
▲ ON	TI-101	1H	2005/10/01 08:53:40
▲ ON	PI-206	1H	2005/10/01 08:52:53
▼ OFF	AC-307	1L	2005/10/01 08:52:37
▼ OFF	VA-204	1R	2005/10/01 08:52:36
▲ ON	VA-204	1R	2005/10/01 08:52:35
▼ OFF	VA-204	1R	2005/10/01 08:52:34
▲ ON	VA-204	1R	2005/10/01 08:52:33
▼ OFF	VA-204	1R	2005/10/01 08:52:28
▲ ON	VA-204	1R	2005/10/01 08:52:27
▼ OFF	VA-204	1R	2005/10/01 08:52:21
▲ ON	VA-204	1R	2005/10/01 08:52:20
▼ OFF	VA-204	1R	2005/10/01 08:52:15

To the historical trend display

Date/Time of alarm occurrence/release

Alarm No. (1, 2, 3, 4)/type (H, L, h, l, R, r, T, t)

Channels on which alarms are occurring

▲ ON : Alarm occurrence  
( ▲ blinks until the alarm ACK operation is carried out if "Indicator" is set to "Hold.")

▼ OFF : Alarm release

● ACK : Alarm acknowledge  
(when blinking is cleared through the alarm ACK operation)

Cursor (selects the alarm)

Number of the alarm information displayed on the bottom line/number of alarm information in the internal memory

### Message Summary

Displays a list of written messages and the time the messages were written.

- Up to 450 messages can be displayed.
- Up to 50 messages that are added to the past data section (added messages) can be displayed.
- You can select arbitrary message information and recall the historical trend of the display data or event data that contains the message.

For the setting procedure, see section 4.7.

Message	Time	Group
Pressure	2005/10/01 09:03:33	All
Temperature	2005/10/01 09:03:18	All
<b>HOLD</b>	2005/10/01 08:51:31	All
START	2005/10/01 08:48:49	All
START	2005/09/30 18:47:36	All

Annotations:

- Message: Added message (displayed in blue)
- Cursor (selects the message)
- Date/Time when the message was written
- Destination group to write the message: All groups or a group number
- To the historical trend display

Number of the message displayed on the bottom line/number of messages in the internal memory

#### • Switching of the Display Items

You can switch between two sets of display contents.

- Message, time when the message was written, and group to which the message was written
- Message, user name that wrote the message

## Memory Summary

Displays the information pertaining to the display data and event data in the internal memory.

- By selecting the display data or event data, the historical trend display can be recalled.
- The number of manual sampled data and report data (/M1 and /PM1 options) in the internal memory is displayed.

For the setting procedure, see section 4.8.

M. SAMPLE DATA	(04/400)	:2005/10/01 08:57:28
REPORT DATA	(03/100)	:2005/10/01 09:00:00
SAMPLE DATA	DISPLAY DATA	
Start Time	End Time	Data Factor
2005/10/01 08:50:56	2005/10/01 09:04:06	370 Sampling
2005/10/01 08:30:56	2005/10/01 08:50:54	600 Auto Save
2005/10/01 08:10:56	2005/10/01 08:30:54	600 Auto Save
2005/09/30 18:41:00	2005/09/30 18:48:28	225 Stop

- **Switching of the Display Items**

You can switch between two display methods.

- Display the start and end times
- Display the file name

- **Saving the Data**

The data in the internal memory can be saved to a CF card or USB flash memory (/USB1 option).

### Report Data (/M1 and /PM1 Options)

Report data residing in the internal memory can be displayed.  
For the operating procedure, see section 4.5.

**REPORT DATA**  
2005/10/01 09:04:22 DISP 7min  
Start: 2005/10/01 08:10:56 Timeup: 2005/10/01 09:00:00

Channel	Unit	Sts	Ave	Max	Min	Sum
TI-101	°C	----	114.5	259.9	-60.0	3.311867E+05
OUT-102	V	----	0.065	0.727	-0.727	1.904140E+02
FI-103	m3/h	----	265.1	416.6	83.3	7.660835E+05
WA-204	%	----	52.4	76.7	23.3	1.516377E+05
TI-205	°C	----	414.5	559.9	240.0	1.199832E+06
PI-206	kPa	----	102.90	131.90	60.00	2.376761E+05
AC-307	%	----	9.75	16.35	1.01	2.019540E+04
PUMP-308	V	----	183.13	196.35	167.26	5.297996E+05
WA-409	%	----	57.6	61.7	52.6	1.665101E+05
WA-410	%	----	43.3	47.4	38.3	1.251785E+05

**Start:** Start date/time  
**Timeup:** Report date/time

**Report data status**  
Indicates that the following occurred between the report interval.  
E: Error data  
O: Over data  
P: Power failure  
C: Time change  
B: Burnout

**Unit**  
**Report type**  
**Tag name or channel number**  
**Number of the displayed report data/number of report data in the internal memory**

**Average, maximum, minimum, sum, or instantaneous value**

### Status Display

The following displays available.  
For the operating procedure, see section 4.5.

- **Relay Status Display**  
Displays the status of the alarm output relay and internal switch.
- **Modbus Client Status Display and Modbus Master Status Display**  
Displays the command status.

### Log Display

Displays various logs (operation log).  
For the operating procedure, see section 4.9.


Log Type	Description
Login	Log of login/logout, log of time setting, and log of power failure
Error	Log of error messages
Communications	Log of communication commands
FTP transfer	Log of FTP transfers
WEB	Log of Web operations
E-mail transmission	Log of e-mail transmissions
SNTP	Log of accesses to the SNTP server
DHCP	Log of accesses to the DHCP server
MODBUS	Log of communications using Modbus client or Modbus master



## Four Panel Display

Displays four different display formats on a single screen. Because the size of each screen is reduced to 1/4, there are limitations in the format, content, and operation of the display.

For the operating procedure, see section 4.10.



Displayable Screen	Limitation
Trend	No auto switching of groups. No all channel display and message display. Number of displayed scales is 6 or less.
Digital	No auto switching of groups.
Bar graph display	No auto switching of groups. No numeric display. Displays one representative alarm character.
Overview	No operation. No numeric display when there are more than 261 channels.
Alarm summary	No operation using the cursor.
Message summary	
Memory summary	
Modbus client status display	
Modbus master status display	
Relay Status Display	-
Report display	No operation using the cursor.

### • Registering Screens

You can assign a display name to the display condition of the four panel display (up to four configurations) and register it. A registered configuration can be recalled by its display name and displayed.

The default values are as follows:

Display Name	Displays Shown
MIX	Trend (group 1), digital (group 1), bar graph (group 1), and overview
ALL TREND	All trend displays (groups 1 through 4)
ALL DIGITAL	All digital displays (groups 1 through 4)
ALL BAR	All bar graph displays (groups 1 through 4)

### Other Useful Functions

- **Automatically Reverting to the Specified Display**  
Show a preset display when there is no operation for a specific time.  
For the setting procedure, see section 5.15.
- **Favorite Key**  
Register a frequently used display to the Favorite key and enable the display to be shown through simple operation.  
For the setting procedure, see section 5.16.
- **Customizing the Menus**  
Change the FUNC key menu that appears when the FUNC key is pressed and the screen menu that appears when the DISP/ENTER key is pressed.  
For the setting procedure, see section 5.18.

### Setting the Display Conditions of the LCD

The display conditions of the LCD can be configured.

Display Attribute	Setting
Background color of the operation display	The background color of the display can be set to white or black. The default value is <b>White</b> . For the setting procedure, see section 5.13.
Background color of the historical trend screen	You can select white, cream, black, or light gray for the background color of the screen. The default value is <b>Black</b> . For the setting procedure, see section 5.13.
LCD brightness	The brightness of the LCD can be set among six levels. The default brightness is <b>2</b> . For the setting procedure, see section 2.7.
Backlight saver	The lifetime of the LCD backlight can be extended by automatically turning OFF or dimming the light when there is no key operation for a specified amount of time. The display returns to the original brightness with a key operation or an alarm occurrence. By default, the backlight saver is disabled. For the setting procedure, see section 2.7.

## 1.4 Data Storage Function

This section explains the types of data that the DX can record and how to store them.


### Data Types

The types of data that the DX can record are as follows:

Data Type	Description
Display data	<ul style="list-style-type: none"> <li>Waveform data displayed on the trend display. The measured data is recorded as a specified sampling interval. The sampling interval is specified using the trend interval.</li> <li>The minimum and maximum values among the measured data within the sampling interval are saved.</li> <li>A header string (common to other files) can be written in the file.</li> <li>The display data contains alarm and message information.</li> <li>Data format: Binary (Undisclosed)</li> </ul>
Event data	<ul style="list-style-type: none"> <li>Measured data that is recorded at a specified sampling interval. There are two modes. One mode starts recording when a trigger event occurs. The other mode records at all times.</li> <li>A header string (common to other files) can be written in the file.</li> <li>The event data contains alarm and message information.</li> <li>Data format: Binary (Undisclosed)</li> </ul>
Manual sampled data	<ul style="list-style-type: none"> <li>Instantaneous value of the measured data when a manual sample operation is executed.</li> <li>A header string (common to other files) can be written in the file.</li> <li>Data format: ASCII</li> </ul>
Report data (/M1 and /PM1 options)	<ul style="list-style-type: none"> <li>Hourly, daily, weekly, and monthly report data. Report data is created at an interval that is determined by the report type (one hour for hourly reports, one day for daily reports, and so on).</li> <li>A header string (common to other files) can be written in the file.</li> <li>Data format: ASCII</li> </ul>
Snapshot data (screen image data)	<ul style="list-style-type: none"> <li>The image data of the DX screen when the snapshot operation is executed.</li> <li>The data can be saved to a CF card.</li> <li>Data format: PNG</li> </ul>
Setup data	<ul style="list-style-type: none"> <li>The setup data of the DX.</li> <li>Data format: Binary (Undisclosed)</li> </ul>


#### • Display data and event data

Display data can be likened to the conventional recording on the chart sheet and are useful for long-term recording. Event data is useful when you wish to record the measured data in detail.




### Flow of Data Recording and Storage

Measured data is recorded once to the internal memory and then saved to the external storage medium.



### Internal Memory

Display data and event data are held in files in the internal memory. The data area also stored on the external storage medium in files.



## Recording Method of Display Data and Event Data

For the setting procedure, see section 6.1.

### • Types of Data to Be Acquired

Select display data only, display data and event data, or event data only.

### Deciding the Data to Be Recorded

Record the data that suits your application. Refer to the following examples.

Example 1: Continuously record the waveform data as with the conventional chart recorder.

Record the display data.

Example 2: Record waveform data under normal conditions but record details around the point of alarm occurrence when alarms occur.

Continuously record display data and record event data when alarms occur.

Example 3: Only record the most-detailed data at all times.

Record event data by specifying the sampling interval.

Example 4: No need to continuously record data. Record data only when alarms occur.


Record event data only when alarms occur.

### • Internal Memory

The recorded measured data is divided at a specific time interval and saved to files.

The size of the internal memory that holds the files is 80 MB or 200 MB (expansion memory). If this size is exceeded or if the number of display data files and event data files exceeds 400, files are overwritten from the oldest file.

### • Recording Conditions of Display Data

Item	Description
Source channels	Select from measurement channels, computation channels, and external input channels.
Sampling interval	Specify the sampling interval with the trend interval (see the table below). You cannot specify a sampling interval that is faster than the scan interval.
File creation	Files are created at the specified file save interval  <p>Files are also created in the following cases.</p> <ul style="list-style-type: none"> <li>• When a file is created manually.</li> <li>• When the memory sampling is stopped.</li> <li>• When file creation is executed with the event action function.</li> </ul>
Memory start/stop	Press the START key to start recording (memory start) and the STOP key to stop the recording (memory stop).

Trend interval and the sampling interval of display data

<b>Trend interval [DIV]</b>	<b>15 s*</b>	<b>30 s</b>	<b>1 min</b>	<b>2 min</b>	<b>5 min</b>
<b>Sampling interval of displayed data (s)</b>	0.5	1	2	4	10
<b>Trend interval [DIV]</b>	<b>10 min</b>	<b>15 min</b>	<b>20 min</b>	<b>30 min</b>	<b>1 h</b>
<b>Sampling interval of displayed data (s)</b>	20	30	40	60	120
<b>Trend interval [DIV]</b>	<b>2 h</b>	<b>4 h</b>	<b>10 h</b>		
<b>Sampling interval of displayed data (s)</b>	240	480	1200		


\* DX2004 and DX2008 only

• **Recording Conditions of Event Data**


Item	Description
Source channels	Same as the display data.
Sampling interval	Select from the available settings between 25 ms to 600 s. However, you cannot specify an interval that is faster than the scan interval.
File creation	A file is created when the specified data length is reached. Files are also created in the following cases. <ul style="list-style-type: none"> <li>• When a file is created manually.</li> <li>• When the memory sampling is stopped.</li> <li>• When file creation is executed with the event action function.</li> </ul>

**Mode**  
The available modes are **Free** (continuously record), **Single**, and **Repeat**. The recording operation varies depending on the mode as follows:


**Free**  
Press the START key to start recording (memory start) and the STOP key to stop the recording (memory stop) .



**Single**  
Pressing the START key places the DX in the trigger-wait state. When the trigger condition is met, the DX records data for a specified time (data length) and stops. From this point, the DX does not record even if the trigger condition is met.




**Repeat**  
Pressing the START key places the DX in the trigger-wait state. When the trigger condition is met, the DX records data for a specified time (data length) and stops. The DX enters the trigger-wait state again and keeps recording the data for a specified time (data length) each time the trigger condition is met. To stop the recording of the event data, press the STOP key.



**Pretrigger of Event Data**

The pretrigger can be specified in trigger mode. This function is used to save the data before the point where the trigger condition is met as event data. This function is convenient when you wish to record the data before the occurrence of a certain event such as when an alarm occurs. Specify the pretrigger as a percentage (0, 5, 25, 50, 75, 95, or 100%) of the recording time (data length) of the event data. If set to 0%, the data after the trigger condition is met is recorded.




**Trigger for Starting the Event Data Recording**

When set to trigger mode, you can set various conditions for starting the recording. Example: Key operation, alarm occurrence, specific time, or remote control


- **Creating Files through Key Operation**

Files can be created using keys.




### Manual Sampled Data

Manual sampled data is recorded to the internal memory. When the number of manual sampled data exceeds 400, the data is overwritten from the oldest data.



### Report Data

Report data is recorded to the internal memory. When the number of report data exceeds 100, the data is overwritten from the oldest data.



## Saving Data to the External Storage Medium

For the setting and operating procedure, see sections 6.2 and 6.4 respectively.

- **Type of External Storage Medium**

- CF card (32 MB or more)
- USB flash memory (/USB1 option)

- **Auto Save**

Have the CF card inserted in the slot at all times. The data in the internal memory is automatically saved to the CF card.

### Auto Save Timing

Data Type	Description
Display data	The file is saved when the file is created.

Event data	Same as the display data.
Manual sampled data	The first time manual sample is executed, a manual sampled data file is created on the CF card. The data is appended to this file for each subsequent manual sample operation.
Report data	The first time report data is generated, a report data file is created on the CF card and report data is stored. The report data is appended to this file every time of report.

#### Dividing of the report files

The appending of the report data to the file is stopped at a specified time, and subsequent reports are saved to a new file. The file is divided in the unit shown in the table below.

Report Type	Report File	
	One File	File for Each Type
Hourly report	<input type="checkbox"/> hourly reports of a day	<input type="checkbox"/> a file for each daily report
Daily report	<input type="checkbox"/> daily reports for a month	
Hourly and daily reports	<input type="checkbox"/> hourly reports for a day and a daily report	<input type="checkbox"/> hourly reports of a day
Daily and weekly reports	<input type="checkbox"/> daily reports for a week and a weekly report	<input type="checkbox"/> a file for each weekly report <input type="checkbox"/> daily reports for a month
Daily and monthly reports	<input type="checkbox"/> daily reports for a month and a monthly report	<input type="checkbox"/> a file for each monthly report <input type="checkbox"/> daily reports for a month

### Save Destination

CF card.

### Data Save Destination Directory

You can set the data save destination directory name (DATA0 by default). The specified directory is created on the CF card, and the data is saved in the directory.

### Save Operation (If Media FIFO Is Disabled)


The data in the internal memory can be saved only if there is sufficient free space on the CF card. Replace the CF card and save the data before the data in the internal memory is overwritten.

### Save Operation (Constantly Retaining the Most Recent Data Files Using Media FIFO) (Release Number 2 or Later)

When saving the data files automatically, you can save the data so that the most recent data files are constantly retained in the CF card. This method allow you to use the DX continuously without having to replace the CF card.



- **Operation**




If not enough free space is available when saving a new data file to the CF card, files are deleted in order from the oldest data update date/time to save the new file. This operation is referred to as FIFO (First In First Out).

- The FIFO operation is carried out only when saving the following files automatically. It is not carried out when saving files to the save destination directory using another method. Display data files, event data files, report data files, manual sample data files, and snapshot files
- Files that are deleted  
All the files in the save destination directory are applicable to be deleted. However, the following files are excluded. Hidden files, read-only files, files in the subdirectory within the save destination directory
- The most recent 1000 files are retained. If the number of files in the save destination directory exceeds 1000, the number of files is held at 1000 by deleting old files even if there is enough free space.
- If there are more than 1000 files already in the save destination directory, one or more files are always deleted before saving the new file. The number of files is not kept within 1000 in this case.

- **Manual Save (Collectively Storing Unsaved Data)**

Unsaved data in the internal memory is stored in unit of files to the external storage medium when an external storage medium is inserted and a given operation is carried out.



When using manual save, it is important that you save the data in the internal memory to the external storage medium before the data is overwritten. Determine the usage condition of the internal memory and save the data to the external storage medium at appropriate times.

### Save Destination

You can select a CF card or USB flash memory (/USB1 option).

### Data Save Destination Directory

You can set the data save destination directory name (DATA0 by default).

1.4 Data Storage Function

• File Name

You can select the file name configuration from three types.

Structure	Description	
Date	Display data Event data Manual sampled data Snapshot data	<div style="border: 1px solid black; padding: 2px;"> <span style="border: 1px solid black; padding: 0 5px;">7-digit</span> <span style="border: 1px solid black; padding: 0 5px;">Specified string</span> <span style="border: 1px solid black; padding: 0 5px;">Date</span> <span style="border: 1px solid black; padding: 0 5px;">. Extension</span> </div> Ex.: 000123_AAAAAAAAAAA050928_174633.DAD
	Report data	<div style="border: 1px solid black; padding: 2px;"> <span style="border: 1px solid black; padding: 0 5px;">7-digit</span> <span style="border: 1px solid black; padding: 0 5px;">Specified string</span> <span style="border: 1px solid black; padding: 0 5px;">Date</span> <span style="border: 1px solid black; padding: 0 5px;">Type</span> <span style="border: 1px solid black; padding: 0 5px;">. Extension</span> </div> Ex.: 000123_AAAAAAAAAAA050928_174633HD.DAR
Sequence	Display data Event data Manual sampled data Snapshot data	<div style="border: 1px solid black; padding: 2px;"> <span style="border: 1px solid black; padding: 0 5px;">7-digit</span> <span style="border: 1px solid black; padding: 0 5px;">Specified string</span> <span style="border: 1px solid black; padding: 0 5px;">. Extension</span> </div> Ex.: 000123_AAAAAAAAAAA.DAD
	Report data	<div style="border: 1px solid black; padding: 2px;"> <span style="border: 1px solid black; padding: 0 5px;">7-digit</span> <span style="border: 1px solid black; padding: 0 5px;">Specified string</span> <span style="border: 1px solid black; padding: 0 5px;">Type</span> <span style="border: 1px solid black; padding: 0 5px;">. Extension</span> </div> Ex.: 000123_AAAAAAAAAAA0HD.DAR
Batch name	Display data Event data	<div style="border: 1px solid black; padding: 2px;"> <span style="border: 1px solid black; padding: 0 5px;">7-digit</span> <span style="border: 1px solid black; padding: 0 5px;">Batch name</span> <span style="border: 1px solid black; padding: 0 5px;">. Extension</span> </div> Ex.: 000123_BBBBBBBBBBBBBBBBBBBBBB.DAD
	Report data	<div style="border: 1px solid black; padding: 2px;"> <span style="border: 1px solid black; padding: 0 5px;">7-digit</span> <span style="border: 1px solid black; padding: 0 5px;">Date</span> <span style="border: 1px solid black; padding: 0 5px;">Type</span> <span style="border: 1px solid black; padding: 0 5px;">. Extension</span> </div> Ex.: 000123_050928_174633HD.DAR
	Manual sampled data Snapshot data	<div style="border: 1px solid black; padding: 2px;"> <span style="border: 1px solid black; padding: 0 5px;">7-digit</span> <span style="border: 1px solid black; padding: 0 5px;">Date</span> <span style="border: 1px solid black; padding: 0 5px;">. Extension</span> </div> Ex.: 000123_050928_174633.DAM

Item	Description	
7-digit	Consists of a 6-digit number and 1-character delimiter.	
	6-digit number	A sequence number in the order of occurrence. The number ranges from 000001 to 999999. If the number reaches 999999, it returns to 000001.
	1-character delimiter	Starts with ‘_’ and takes on the following values: A to Z and 0 to 9. If a file with the same name exists in the specified directory, the file is saved by changing the delimiter to prevent overwriting. Example: If a file named “000123_AAAAAAAAAAA.DAD” already exists, the file is saved to the name “000123AAAAAAAAAAAA.DAD.”
Date	YYMMDD_hhmmss	YY: Year (lower two digits), MM: Month, DD: Day hh: Hour, mm: Minute, ss: Second
Specified string	AAAAAAAAA***A	Up to 16 alphanumeric characters can be used
Batch name	BBBBBBBBBB***B	Up to 40 alphanumeric characters can be used
Type	H_, D_, W_, M_, HD, DW, DM	Report data type H_: Hourly, D_: Daily, W_: Weekly, M_: Monthly, HD: Hourly and daily, DW: Daily and weekly, DM: Daily and monthly
Extension	Display data	:DAD
	Event data	:DAE
	Manual sampled data	:DAM
	Report data Snapshot data Setup data	:DAR :PNG :PDL


**Note**

Differences from the File Names up to Now

- The “ID” item at the end of the file name is deleted and its functionality is included in the “Separator” of the 7-digit sequence.

**Example**

DXs before release number 2: 000123\_AAAAAAAAAAA050928\_1746330.DAD



DXs with release number 2 or later: 000123\_AAAAAAAAAAA050928\_174633.DAD

- The sequence section of the display data and event data file names is changed to 7 digits, and the “ID” function is included in the “Separator” when using the “Batch name.”

## File Names on DXs before Release Number 2

The table below shows the file name that is assigned when the measured data is saved to the CF card.

Structure	Description	
Date	Display data Event data Manual sampled data Snapshot data	<div style="border: 1px solid black; padding: 2px; display: inline-block;"> <span style="border: 1px solid black; padding: 0 2px;">7-digit</span> <span style="border: 1px solid black; padding: 0 2px;">Specified string</span> <span style="border: 1px solid black; padding: 0 2px;">Date</span> <span style="border: 1px solid black; padding: 0 2px;">ID</span> . <span style="border: 1px solid black; padding: 0 2px;">Extension</span> </div> Ex.: 000123_AAAAAAAAAAA050928_1746330.DAD
	Report data	<div style="border: 1px solid black; padding: 2px; display: inline-block;"> <span style="border: 1px solid black; padding: 0 2px;">7-digit</span> <span style="border: 1px solid black; padding: 0 2px;">Specified string</span> <span style="border: 1px solid black; padding: 0 2px;">Date</span> <span style="border: 1px solid black; padding: 0 2px;">Type</span> <span style="border: 1px solid black; padding: 0 2px;">ID</span> . <span style="border: 1px solid black; padding: 0 2px;">Extension</span> </div> Ex.: 000123_AAAAAAAAAAA050928_174633DH0.DAR
Sequence	Display data Event data Manual sampled data Snapshot data	<div style="border: 1px solid black; padding: 2px; display: inline-block;"> <span style="border: 1px solid black; padding: 0 2px;">7-digit</span> <span style="border: 1px solid black; padding: 0 2px;">Specified string</span> <span style="border: 1px solid black; padding: 0 2px;">ID</span> . <span style="border: 1px solid black; padding: 0 2px;">Extension</span> </div> Ex.: 000123_AAAAAAAAAAA0.DAD
	Report data	<div style="border: 1px solid black; padding: 2px; display: inline-block;"> <span style="border: 1px solid black; padding: 0 2px;">7-digit</span> <span style="border: 1px solid black; padding: 0 2px;">Specified string</span> <span style="border: 1px solid black; padding: 0 2px;">Type</span> <span style="border: 1px solid black; padding: 0 2px;">ID</span> . <span style="border: 1px solid black; padding: 0 2px;">Extension</span> </div> Ex.: 000123_AAAAAAAAAAAHD0.DAR
Batch name	Display data Event data	<div style="border: 1px solid black; padding: 2px; display: inline-block;"> <span style="border: 1px solid black; padding: 0 2px;">3-digit</span> <span style="border: 1px solid black; padding: 0 2px;">Batch name</span> <span style="border: 1px solid black; padding: 0 2px;">ID</span> . <span style="border: 1px solid black; padding: 0 2px;">Extension</span> </div> Ex.: 123BBBBBBBBBBBBBBBBBBBB0.DAD
	Report data	<div style="border: 1px solid black; padding: 2px; display: inline-block;"> <span style="border: 1px solid black; padding: 0 2px;">7-digit</span> <span style="border: 1px solid black; padding: 0 2px;">Date</span> <span style="border: 1px solid black; padding: 0 2px;">Type</span> <span style="border: 1px solid black; padding: 0 2px;">ID</span> . <span style="border: 1px solid black; padding: 0 2px;">Extension</span> </div> Ex.: 000123_050928_174633HD0.DAR
	Manual sampled data Snapshot data	<div style="border: 1px solid black; padding: 2px; display: inline-block;"> <span style="border: 1px solid black; padding: 0 2px;">7-digit</span> <span style="border: 1px solid black; padding: 0 2px;">Date</span> <span style="border: 1px solid black; padding: 0 2px;">ID</span> . <span style="border: 1px solid black; padding: 0 2px;">Extension</span> </div> Ex.: 000123_050928_1746330.DAM

Item	Description	
Date	YYMMDD_hhmmss	Same as release number 2 and later.
7-digit sequence	000001 to 999999	Consists of a 6-digit number and an underscore as a separator. A sequence number in the order of occurrence.
3-digit sequence	001 to 999	A sequence number in the order of occurrence.
Type	H_, D_, W_, M_, HD, DW, DM	Report data type Same as release number 2 and later.
ID	0 to 9, A to Z	When a file with the same name exists in the specified directory, the file is saved by changing the ID character to prevent overwriting. Example: If a file named "000123_AAAAA050907_1036480.DAD" already exists, the file is saved to the name "000123_AAAAA050907_1036481.DAD."
Extension	Same as release number 2 and later.	

## 1.4 Data Storage Function

- **Saving Data through Key Operation**

You can carry out the following data save operations regardless of whether auto save or manual save is used.

Data Storage	Description
All save	Collectively saves all the data in the internal memory.
Selective save	Saves the specified display data or event data file.
Manual sampled data save	Collectively saves all the manual sampled data in the internal memory.
Report data save	Collectively saves all the report data in the internal memory.

### Save Destination

You can select a CF card or USB flash memory (/USB1 option).

### Data Save Destination Directory

Creates a directory with the name of the data save destination directory name with the date/time added and saves the data.

Directory name: "Specified string"\_YYMMDD\_HHMMSS

Example: If the data is saved at 17 hours 6 minutes 42 seconds on September 30, 2005, the data is saved to a directory named "DATA0\_050930\_170642." "DATA0" is the specified string.

### Note

The number of directories that you can create on the external storage medium varies depending on the length of the directory names. If the length of the "specified string" is 5 characters, approximately 170 directories can be created. If it is 20 characters, approximately 120 directories can be created. An error occurs, if you try to create directories exceeding this limit.

## Other Types of Data That Can Be Stored


- **Setup Data**

The setup data of the DX is saved to a CF card or USB flash memory (/USB1 option). The setup data is saved to the root directory.

Name of the setup data file	Specified . PDL Example: ABCD10005.PDL
-----------------------------	-------------------------------------------

- **Snapshot Data**

The screen that the DX displays is saved to a CF card in PNG format. The data is saved to the same directory as the display data and event data. For the file name, see the previous page.



## Saving Data via the Ethernet Network

Display data, event data, report data (/M1 or /PM1 option), and screen image data can be automatically transferred and saved to an FTP server via the Ethernet network by using the FTP client function. Conversely, the DX can function as an FTP server. The DX can be accessed from a PC and the data files in the internal memory or the external storage medium can be retrieved to be stored on the PC.

See the *Communication Interface User's Manual IM 04L41B01-17E*.

## 1.5 Batch Function

You can add batch information to the display data and event data files. The files can be managed using the batch information.

For the setting and operating procedure, see section 6.3.

### Batch Information

- **Batch Number and Lot Number**

A file can be identified by its “batch number-lot number.” The lot number does not have to be specified.

- Batch number (up to 32 characters).
- Lot number (up to 8 digits)

- **Automatic Increment of the Lot Number**

The lot number can be automatically incremented when the memory sampling is stopped.

- **Text Field**

Eight sets of arbitrary text can be entered in a file. Each text field consists of the following:

- Field title (up to 20 characters)
- Field string (up to 30 characters)

The text field can be shown on the DX screen through key operation.


- **Batch Comment**

Three arbitrary comments can be entered in a file. A single comment can be entered while memory sample is in progress.

- Comment 1, Comment 2, and Comment 3 (up to 50 characters each)

### Using the Batch Function

See the figure below. For example, enter the operator and administrator in the text field.



## 1.6 Event Action Function

A specified action is carried out when an event occurs. This function is called *event action*.

For the setting procedure, see section 7.1.

### Events

- **Events**

Select from the following events.

Event	Level/Edge*	Description
Remote	Level/Edge	ON/OFF of the remote control input.
Output relay	Level/Edge	Activated/Deactivated condition of the alarm output relay.
Internal switch	Level/Edge	The value 0 and 1 of the internal switch.
Timer	Edge	Timer timeout.
Match time timer	Edge	When the time matches.
Alarm	Level/Edge	The state in which any alarm is occurring and the state in which no alarm is occurring.
USER key	Edge	The operation of pressing the USER key.


\* For a description of level and edge, see "Miscellaneous" in this section.

- **Timers**


Four timers are available.

#### Timer Type

##### Absolute timer



##### Relative timer



- **Absolute Time Mode**

The timer expires at the times determined by the reference time and the interval.

The reference time is set on the hour (00 to 23).

Example: Reference time: 00:00

Interval: 10 min

The timer expires at 0 hour, 0 hour 10 min, 0 hour 20 min, ... 23 hour 40 min, and 23 hour 50 min. For example, if the timer is set at 9 hour 36 min, the timer expires at 09 hour 40 min, 09 hour 50 min, 10 hour, and so on.

- **Relative Time Mode**

The timer is started when the timer is set, and the timer expires every specified interval. In this mode, the timer stops when a power failure occurs.

Example: Interval: 00:15

The timer expires every 15 minutes.

- **Match Time**

You can set the time matching conditions for the four match time timers. Specify the date/time using the method described below. For each condition, you can select whether to use the condition once or continuously.

Specified Date/Time	Description
Y hour of the X day	The condition is met once a month.
Y hour of the X day of the week	The condition is met once a week.
Y hour	The condition is met once a day.

## Action

### • Actions

Select from the following actions.

Action	Level/Edge*	Description
Memory start/stop	Level	Starts/stops memory sampling.
Memory start	Edge	Starts the memory sampling.
Memory stop	Edge	Stops the memory sampling.
Event trigger	Edge	Applies a trigger for starting the event data recording. This is valid when recording event data in trigger mode. See the next page.
Alarm acknowledge	Edge	Releases the alarm output. This is valid when the use of the alarm ACK operation is enabled.
Computation start/stop**	Level	It is used to start/stop the computation.
Computation start**	Edge	Starts the computation.
Computation stop**	Edge	Stops the computation.
Computation reset**	Edge	Resets the computed values on all computation channels.
Save display data	Edge	The display data being recorded is saved to the internal memory as a file. This is the same function as the data save operation using the FUNC key.
Save event data	Edge	The event data being recorded is saved to the internal memory as a file. This is the same function as the data save operation using the FUNC key.
Message	Edge	Writes a message. This action can be executed while memory sampling is in progress.
Snapshot	Edge	Saves the screen image data.
Switch the display rate	Level	Toggles between the trend interval and the secondary trend interval. This action is valid when the DX is configured to use trend interval switching.
Manual sample	Edge	Executes manual sampling.
Reset the relative timer	Edge	Resets the relative timer. The timer restarts from that point.
Switch the display group	Edge	Switches the display group when the trend, digital, or bar graph is displayed.
Flag**	Level	The flag is zero for normal conditions and 1 when an event occurs. The flag can be written in a calculation expression of a computation channel.
Load the setup	Edge	Loads the setup data file in the root directory of the CF card into the DX and updates the DX settings. See below.
Adjust the time	Edge	Synchronizes the time to the nearest hour. See the next page.

\* For a description of level and edge, see "Miscellaneous" in this section.

\*\* An option.

### Resetting the Relative Timer

If the event is set to output relay, internal switch, match time timer, or alarm, the resetting of the timer is not considered a timeout. (The action is not executed even if the timer is used as an event.)

### Loading the Setup

Can be specified as an action only when the event is set to remote control input. Loads the setup data file, LOAD1.PDL, LOAD2.PDL, or LOAD3.PDL, in the root directory of the CF card into the DX and updates the DX settings. You must create a setup file and save it to the CF card in advance.

**Event Trigger Operation**

When the event is set to output relay, internal switch, or alarm

If the output relay is activated, the internal switch is 1, or the alarm is occurring during memory sampling, the event trigger is always activated. However, the number of times the trigger is activated depends on the event data mode (single or repeat).

**Time Adjustment**

Time adjustment can be specified as an action only when the event is set to remote control input. The internal clock of the DX is adjusted to the nearest hour through remote control input.

• **Operation When Memory Sampling Is Stopped**

Difference from the Nearest Hour	Operation
00 min 00 s to 01 min to 59 s	Truncates the minutes and seconds. Example: 10 hours 01 min 50 s becomes 10 hours 00 min 00 s.
02 min 00 s to 57 min to 59 s	The time is not changed.
58 min 00 s to 59 min to 59 s	Rounds up the minutes and seconds. Example: 10 hours 59 min 50 s becomes 11 hours 00 min 00 s.

• **Operation during Memory Sampling**

If the time difference between the time the remote control signal is applied and the nearest hour is within the preset time, the time is gradually corrected. Otherwise, the time is corrected immediately. For details, see section 10.1.

**Miscellaneous**

• **Limitations on the Combinations of Events and Actions**

The combinations that are checked in the table below can be used.

Action \ Event	Remote	Output Relay	Internal Switch	Timer	Match Timer	Alarm	User Key
Alarm ACK	✓			✓	✓		✓
Reset the relative timer	✓	✓	✓		✓	✓	✓
Load the setup	✓						
Adjust the time	✓						
Other actions	✓	✓	✓	✓	✓	✓	✓

• **Level and Edge**

The combinations of events and actions are summarized in the figure below.

Type	Operation	
Event	Edge	Edge
	Level	
Action	Level	Edge
		Operation executed

Additional labels in the diagram: Status 1, Status 2, Operation executed.

**Level and Edge of the Remote Control Input Signal**



For contact inputs, the remote signal rises when the contact switches from open to closed and falls when the contact switches from closed to open. For open collector signals, the remote signal rises when the collector signal (voltage level of the remote terminal) goes from high to low and falls when the collector signal goes low to high.



## 1.7 Security Function

### Key Lock Function

Key lock is a function that prohibits key operations. You enter a password to release the key lock.

For the setting procedure, see section 8.1.

Key Lock Items	Description
Keys	The following keys can be locked independently. START key, STOP key, MENU key, USER key, DISP/ ENTER key (prohibits switching the operation screen), and Favorite key.
Access to the storage medium	Prohibits all operations listed below. <ul style="list-style-type: none"> <li>• Manually save the data</li> <li>• Load the display data and event data files</li> <li>• Save/Load setup data files</li> <li>• List the files on the storage medium</li> <li>• Delete the files on the storage medium</li> <li>• Format the storage medium</li> </ul>
Function operation	The following FUNC key operations can be locked independently. <ul style="list-style-type: none"> <li>• [Alarm ACK]</li> <li>• [Message], [Free message], [Batch], [Add Message], [Add Free Message] [Text field]</li> <li>• [Math start], [Math stop], [Math reset], [Math ACK]</li> <li>• [Save display], [Save event], [Manual sample], [Trigger], [Snap shot], [Timer reset], [Save stop]</li> <li>• [E-Mail start], [E-Mail stop], [FTP test], Operations to [Request] or [Release] network information</li> <li>• [SNTP], time setting (operation in the setting mode)</li> <li>• [Favorite regist], [4panel], [Standard display], [Second speed], [Normal speed]</li> </ul>

## Login Function

Only registered users can operate the DX. Access from communication functions can also be limited to users registered here.

For the setting and operating procedure, see sections 8.2 and 8.3 respectively.

- **Login and Logout**

You enter your user name and password to log into the DX in the following cases.

Method of Accessing the DX	Login Required
Keys	<ul style="list-style-type: none"> <li>• When the power is turned ON</li> <li>• When logging in after exiting the basic setting mode</li> <li>• When logging in after logging out</li> </ul>
Communication	When accessing the setting/measurement server, FTP server, maintenance/test server, or Web server.

### Auto Logout (When Logged in Using Keys)

When logged in using keys, you are automatically logged out when there is no key operation for a specified time. If you are automatically logged out from the setting mode, the setting changes are cancelled. You are not automatically logged out during basic setting mode.

### Operations That Can Be Carried Out When Logged Out

When logged out, you can switch the operation screen using the DISP/ENTER key, arrow keys and Favorite key.

- **User Levels**

A user can be an “administrator” or a “user.”

#### Administrator

Administrators can perform all operations on the DX. At least one administrator must be registered to use the login function.

Item	Description
Number of users that can be registered	5
Range of operations	All operations.
Login method	Select key operation, via communication, or Web server login.
ID information	User name and password

#### User

Item	Description														
Number of users that can be registered	30														
Range of operations	<table border="1"> <thead> <tr> <th colspan="2">Key operations</th> <th>Limitation</th> </tr> </thead> <tbody> <tr> <td colspan="2">Basic setting mode</td> <td>Not allowed</td> </tr> <tr> <td rowspan="2">Setting mode</td> <td>Customize menus</td> <td>Not allowed</td> </tr> <tr> <td>Other</td> <td>Specified by user privileges</td> </tr> <tr> <td>Operation mode</td> <td>Key operation</td> <td>Specified by user privileges</td> </tr> </tbody> </table>	Key operations		Limitation	Basic setting mode		Not allowed	Setting mode	Customize menus	Not allowed	Other	Specified by user privileges	Operation mode	Key operation	Specified by user privileges
Key operations		Limitation													
Basic setting mode		Not allowed													
Setting mode	Customize menus	Not allowed													
	Other	Specified by user privileges													
Operation mode	Key operation	Specified by user privileges													

- **User privileges**

You can set operation privileges for each user. The privileges are the same as with the key lock function.

#### Operations via communication

See the *Communications Interface User's Manual*.

Login method	Select key operation, via communication, or Web server login.
ID information	User name and password

## 1.8 Computation and Report Function (/M1 and /PM1 Options)

### Computation Function

Equations can be defined in computation channels by using the measured data or computed data as variables. The result of the computation can be displayed or stored. For the setting procedure, see section 9.1.

- **Channels Dedicated to Computations**

Model	Number of Channels	Channel Numbers
DX2004, DX2008	12	101 to 112
DX2010, DX2020, DX2030, DX2040, DX2048	60	101 to 160

- **Computation Types**

In the table below, [001] represents the measured value of channel 001.

Type	Example	Description of the Example
Four arithmetic operation	001+002	Determines the sum of [001] and [002].
	001-002	Determines the difference between [001] and [002].
	001*002	Determines the product of [001] and [002].
	001/002	Divides [001] by [002].
Power	001**002	Determines [001] to the power of [002]. $y = X^n$
Square root	SQR(001)	Determines the square root of [001].
Absolute value	ABS(001)	Determines the absolute value of [001].
Common logarithm	LOG(001)	Determines the common logarithm of [001]. $y = \log_{10}x$
Natural logarithm	LN(001)	Determines the natural logarithm of [001]. $y = \ln x$
Exponent	EXP(001)	Determines e to the power of [001]. $y = e^x$
Relational computation	001.LT.002	The result is 1 when [001] is less than [002] or 0 otherwise.
	001.LE.002	The result is 1 when [001] is less than equal to [002] or 0 otherwise.
	001.GT.002	The result is 1 when [001] is greater than [002] or 0 otherwise.
	001.GE.002	The result is 1 when [001] is greater than equal to [002] or 0 otherwise.
	001.EQ.002	The result is 1 when [001] is equal to [002] or 0 otherwise.
	001.NE.002	The result is 1 when [001] is not equal to [002] or 0 otherwise.
Logical computation	001AND002	The result is 1 when [001] and [002] are nonzero or 0 otherwise.
	001OR002	The result is 1 when [001] or [002] or both are nonzero or 0 otherwise.
	001XOR002	The result is 0 when [001] and [002] are nonzero or 1 otherwise.
	NOT001	The result is 1 when [001] is zero or 0 otherwise.
TLOG computation*	TLOG.SUM(001)	Determines the sum of [001].
	TLOG.MAX(001)	Determines the maximum value of [001].
	TLOG.MIN(001)	Determines the minimum value of [001].
	TLOG.AVE(001)	Determines the average value of [001].
	TLOG.P-P(001)	Determines the difference between the maximum value and minimum value of [001].

\* Usage is explained on page 1-42.

## 1.8 Computation and Report Function (/M1 and /PM1 Options)

Type	Example	Description of the Example
CLOG computation	CLOG.SUM(001.002.003)	Determines the sum of [001], [002], and [003].
	CLOG.MAX(001.002.003)	Determines the maximum value among [001], [002], and [003].
	CLOG.MIN(001.002.003)	Determines the minimum value among [001], [002], and [003].
	CLOG.AVE(001.002.003)	Determines the average value of [001], [002], and [003].
	CLOG.P-P(001.002.003)	Determines the difference between the maximum value and the minimum value among [001], [002], and [003].
	Special computation	PRE(001)
101=HOLD(001.GT.K01):TLOG.SUM(001)		Under normal conditions, TLOG.SUM(001) is carried out to derive the computed value. When [001] exceeds K01, the previous computed value is held.
Description		HOLD(a):b When a is zero, b is carried out to derive the computed value. Otherwise, the previous computed value is held.
	RESET(101.GT.K01):TLOG.SUM(001)	Under normal conditions, TLOG.SUM(001) is carried out to derive the computed value. When [101] exceeds K01, the previous computed value is reset, and TLOG.SUM(001) is carried out.
Description	RESET(a):b When a is zero, b is carried out to derive the computed value. Otherwise, the previous computed value is reset, and b is carried out to derive the computed value.	
	CARRY(K01):TLOG.SUM(001)	Under normal conditions, TLOG.SUM(001) is carried out to derive the computed value. When the computed value is greater than or equal to K01, the computed result is the excess (computed value - K01).
Description	CARRY(a):b Only TLOG.SUM can be specified for b. If the computed value X of b is less than a, the computed result is X. If X is greater than or equal to a, the computed result is the excess (X - a).	
Conditional equation	[001.GT.K01?001:001+002]	When [001] is greater than K01, the computed value is set to the value of [001]. Otherwise, the computed value is set to the value of [001] + [002].
Description	[a?b:c]	If the computed result of a is nonzero, b is carried out. Otherwise, c is carried out.

- **Data That Can Be Used in Equations**

The data listed below can be used.

Data	Notation	Description
Measurement channel data	001, etc.	Specify the computed data using a channel number.
Computation Channel data*	101, etc.	Specify the computed data using a channel number.
External input channel data*	201, etc.	Specify the computed data using a channel number.
Constant	K01 to K60	A value.
Communication input data	C01 to C60	Data set through communications.
Status of the remote control* input	D01 to D08**	The value is 1 when the remote control input is ON or 0 when it is OFF.
Pulse input*	P01 to P08**	Counts the number of pulses per scan interval.
	Q01 to Q08**	Counts the number of pulses per second.
Internal switch status	S01 to S30	1 or 0.
Alarm output relay* status	I01 to I36	The value is 1 when activated or 0 when deactivated.
Flag	F01 to F08	1 or 0. Set the flag using the event action function (see section 1.6).

\* An option. \*\* Values such as 01 are terminal numbers.

Only the data that are checked in the table below can be used in TLOG, CLOG, and PRE.

Comp. Type \ Data	Meas. CH	Comp. CH	Ext. Input CH	Constant	Comm. Input	Remote	Pulse	Internal Switch	Relay	Flag
TLOG	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
CLOG	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
PRE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Other computations	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

Example: TLOG.SUM(S01), CLOG.AVE(001.002.K01), and PRE(S01) are not allowed.

- **Processing Order of Computation**

Computation is processed in order from the smallest event action number for each scan interval.

Example: If you specify  $102 = 101 + 103$ , the value of the previous scan interval is used for the 103 value.

- **Handing of the Unit in Computations**

In computations, measured values are handled as values without units. For example, if the measured data from channel 001 is 20 mV and the measured data from channel 002 is 20 V, the computed result of  $001 + 002$  is 40.

- **Displaying the Computed Data**

The computed data is displayed by setting a measurement span for each computation channel. Computation channels can be displayed on various operation screens in the same fashion as the measurement channels.

For the setting procedure, see section 9.3.

- **Alarm**

Up to 4 alarms can be assigned to each computation channel. The alarm types are high limit alarm (H), low limit alarm (L), delay high limit alarm (T), and delay low limit alarm (t).

- **Saving Computed Data**

As with the measured data, the computed data can be saved to display data, event data, manual sampled data, and report data.

- **Computation Data Dropout**

A computation data dropout occurs if the computation is not completed within the scan interval. For the operating procedure, see section 9.4.

- The computation icon in the status display section turns yellow.
- When a computation data dropout occurs, the computed data of the scan interval in which the dropout occurred is set to the data immediately before the dropout.
- If computation data dropout occurs frequently, lessen the load on the CPU by reducing the number of computation channels or setting a longer scan interval.

## 1.8 Computation and Report Function (/M1 and /PM1 Options)

- **Numeric Display and Recording**

The range of displayed values of computed data is from –9999999 to 99999999 excluding the decimal point. The decimal place corresponds to the decimal place of the lower limit span of the computation channel. On the numeric display, values are displayed if the computed result is within the above range regardless of the upper and lower limits of span. The following table indicates special displays.

Display/Recording	Computed Data Status
+Over	<ul style="list-style-type: none"> <li>• +Display over: When the computed result exceeds 99999999</li> <li>• +Computation over: When the value exceeds approximately <math>3.4 \times 10^{38}</math> in the middle of the computation</li> <li>• When a computation error* occurs (select +Over or –Over.)</li> </ul>
–Over	<ul style="list-style-type: none"> <li>• –Display over: When the computed result is less than –9999999</li> <li>• –Computation over: When the value is less than approximately <math>-3.4 \times 10^{38}</math> in the middle of the computation</li> <li>• When a computation error* occurs (select +Over or –Over.)</li> </ul>

\* Computation error occurs when the following computation is carried out.

- $X/0$ ,  $SQR(-X)$ , or  $LOG(-X)$
- If a channel number set to skip or Off is used in the equation

- **Rolling Average**

The rolling average of the computed result of the equation specified for the computation channel is determined, and the result is the computed data for that channel. The number of samples and the sampling interval can be specified for each computation channel. The rolling average is applied over the time corresponding to “the number of data samples  $\times$  the sampling interval.” The maximum sampling interval is 1 hour, and the maximum number of samples is 1500.

- **Starting the Computation**

You can configure the DX to start the computation when you press the START key.

- **Usage of TLOG Computations**

TLOG computation determines the sum, maximum, minimum, average, or the difference between the maximum and minimum of a specific channel for each interval determined by a timer.

### Timers That Are Used

The timer that is used is assigned to each channel.

### Unit of Sum Computation


Set the sum scale when using sum computation (TLOG.SUM).

Select Off, /s, /min, or /h. For details, see the next page.

### Resetting the TLOG Computed Value

You can select whether to reset the TLOG computed value at each interval. The figure below illustrates the reset operation for sum computation (TLOG.SUM).

Example: Result of the TLOG.SUM computation



When reset is On, the sum value is calculated over each interval. When set to Off, the sum value from computation start is calculated.

### Power Failure Operation, Handling of Error Data, and Handling of Overflow Data

See page 1-42.

## Report Function

This function is used to create hourly, daily, weekly, and monthly reports.

- **Report Data Types**

You can select from four types among maximum value, minimum value, average value, sum value, and instantaneous value.

- **Report Type**

Type	Description
Hourly report	Creates report data every hour on the hour for the previous one hour.
Daily report	Creates report data every day at a specified time for the previous one day.
Weekly report	Creates report data every week at a specified time at a specified day of the week for the previous one week.
Monthly report	Creates report data every month at a specified time at a specified day for the previous one month.

- **Combinations of Reports That Can Be Created**

You can select from hourly reports only, daily reports only, hourly and daily reports, daily and weekly reports, and daily and monthly reports.

- **Source Channels**

You can select from measurement channels, computation channels, and external input channels. The report data are not created for channels that are set to **Skip** or **Off**.

Model	Number of Report Channels
DX2004 and DX2008	12
DX2010, DX2020, DX2030, DX2040, and DX2048	60

- **Unit of Sum Computation**

In the sum computation, data are summed over the scan interval. However, for flow values that have units /s, /min, /h, or /day a simple summation results in the actual value not matching the computed result, because the scan interval and the unit of the input values are different. In such cases, set the sum scale to match the unit of the input value. In effect, the sum value with the same unit as that of the input value is calculated.

For example, if the scan interval is 2 s, and the input value is 100 m<sup>3</sup>/min, a simple summation would add 100 every 2 s resulting in 3000 after one minute. However, if the sum scale is set to /min, then 2 s/60 s is multiplied every scan interval before the value is added giving a result that has an m<sup>3</sup>/min unit.

The following converting equations are used to compute the sum. The unit of the scan interval is seconds.

Off:  $\Sigma(\text{measured data every scan interval})$   
 /s:  $\Sigma(\text{measured data every scan interval}) \times \text{scan interval}$   
 /min:  $\Sigma(\text{measured data every scan interval}) \times \text{scan interval}/60$   
 /h:  $\Sigma(\text{measured data every scan interval}) \times \text{scan interval}/3600$   
 /day:  $\Sigma(\text{measured data every scan interval}) \times \text{scan interval}/86400$

- **Displaying the Report Data**

You can display the report data using keys.  
 For the operating procedure, see section 4.5.

- **Saving the Report Data**

See section 1.4, "Data Storage Function."

- **Numeric Display and Recording**

The numeric range of the report data is from -9999999 to 99999999 excluding the decimal point.

For the data handling of special cases, see page 1-42.

For details on the report file format, see appendix 3.

## Special Data Handling

This section explains the handling of special data in TLOG computation, CLOG computation, and reports.

- **Power Failure Operation (TLOG and Reports)**

If a power failure occurs when the report function is enabled or in the middle of the TLOG computation, the report operation and TLOG computation resume when the DX recovers from the power failure. The operation varies depending on whether the DX recovers from the power failure before or after the time to create a report or TLOG data.

Time of Recovery	Operation
After the time to create the data	The report or TLOG data is created immediately after the DX recovers. The measured data up to the time of the power failure is used. At the time the next report or TLOG data is created, the data after the recovery is used.
Before the time to create the data	After the DX recovers, report or TLOG data is created at the normal time to create the data. The measured data excluding the power failure period is used.

- **Error Data Handling (TLOG, CLOG, and Reports)**

If an error occurs in the channel data, the error data is discarded, and the computation continues. If all the data are in error, an error results.

The following types of data are considered error data.

- Channels set to skip or Off.
- The measured result on a measurement channels is error (A/D converter failure, etc.).
- The computed result on a computation channel is error.
- The input of the measurement channel is in a burnout condition.
- The external input channel is Off or there is no data (communication failure, etc.)

- **Handling of Overflow Data\***

\* Refers to over range on a measurement channel, computation overflow on a computation channel, and over range of an external input channel.

### For TLOG, CLOG, and Reports

When the channel data is overflow data, the DX handles the data as follows:

Computation Type	Description
Average value or sum value	Set the handling to ERROR, SKIP, or LIMIT. ERROR: Considers the data to be a computation error. SKIP: Discards the overflow data and continues the computation. LIMIT: Replaces the data with the limit value and continues the computation. The limit value is the span upper or lower limit or the scale upper or lower limit of the channel.
Maximum, minimum, Maximum – minimum	Set the handling to OVER or SKIP. OVER: Computes by using the overflow data. SKIP: Discards the overflow data and continues the computation.

### For Multiplication and Relation Computation EQ and NE

Computation Type	Computation	Computed Result
Multiplication	0*(+Over)	0
	0*(-Over)	0
	(+Over)*0	0
	(-Over)*0	0
.EQ.	(+Over).EQ.(+Over)	0
	(-Over).EQ.(-Over)	0
.NE.	(+Over).NE.(+Over)	1
	(-Over).NE.(-Over)	1




## 1.9 FAIL/Status Output Function (/F1 and /F2 Options)

### FAIL Output

When a failure occurs in the CPU of the DX, a relay contact signal (1 signal) is output. The relay is energized when the CPU is normal and de-energizes when a CPU failure occurs. Therefore, relay output is carried out also when the power is turned OFF (including a power failure). You cannot change this behavior.

#### Relay Operation



If a failure occurs, contact your nearest YOKOGAWA dealer for repairs.

## 1.9 FAIL/Status Output Function (/F1 and /F2 Options)

### Status Output

Outputs the status below with a relay contact signal (1 relay). You can select whether each status is output to the relay. The relay is energized when the status occurs. You cannot change this behavior.


For the setting procedure, see section 2.9.

Status	Description	Corrective Action
Status of the internal memory or CF card	Error in the internal memory.	Contact your nearest YOKOGAWA dealer for repairs.
	<b>When the auto save function to the CF card is On.</b>	
	<ul style="list-style-type: none"> <li>The free space on the CF card dropped to 10% of the total size (only when the media FIFO (see section 1.4) is disabled).</li> <li>Error in the CF card.</li> </ul>	<ul style="list-style-type: none"> <li>Replace the CF card.</li> <li>Replace the CF card with a normal one.</li> <li>Format the CF card on the DX (the data on the CF card will be erased).</li> </ul>
	<p>However, the status of the internal memory is output when the CF card is not inserted.</p> <ul style="list-style-type: none"> <li>10 MB or less of available space* remaining in internal memory.</li> <li>The number of files in internal memory for which Auto Save to the CF card has not been completed has exceeded 390.</li> </ul>	Insert a CF card.
	<b>When the auto save function to the CF card is Off.</b>	
	<ul style="list-style-type: none"> <li>10 MB or less of available space* remaining in internal memory.</li> <li>The number of files in internal memory for which Manual Save has not been completed has exceeded 390.</li> </ul>	Save the data in the internal memory to the CF card.
Measurement error	Error in the A/D converter. Burnout is detected.	Contact your nearest YOKOGAWA dealer for repairs. Replace the thermocouple that has burned out.
Communication error	A Modbus master or Modbus client communication error occurred.	Check the error in the Modbus master or Modbus client screen and carry out the corrective action.
	Failed the FTP file transmission.	Check the FTP log and carry out the corrective action.
Memory stop	When the memory sampling is stopped.	Start the data acquisition.

\* The internal memory's "available space" refers to the following quantities.

- Unused regions
- Regions of data for which Auto Save or Manual Save (see page 1-26) has been completed.

### Relay Operation



During normal operation      When specified status occurs      When power is turned OFF

## 1.10 Other Functions

### Time Related Functions

- **Time Correction**

The DX internal clock can be changed in the following manner.

Method	Description
Key operation	Sets the DX internal clock to the specified time.
Event action function	Synchronizes the DX internal clock to the nearest hour.
SNTP client function	Sets the DX internal clock to the time retrieved from an SNTP server.


#### Time Correction Operation

The time correction operation varies depending on whether the memory sampling is in progress or not.

Status	Operation
Memory sampling stopped	The DX internal clock is changed immediately.
Memory sampling	The DX internal clock is gradually corrected. While the time is being gradually adjusted, the date/time in the status display section is displayed in yellow.

#### Operation of Gradually Correcting the Internal Clock

If the time deviation between the time of the DX internal clock and the correct time (the specified time) is within a specified value, the DX clock is adjusted gradually at 40 ms for each second. Otherwise, the clock is corrected immediately. The maximum value of time deviation ( $t_m$  in the figure below) can be selected in the range of 10 s to 5 min.



Example: When changing the time to 12 hours 55 minutes 35 seconds when the internal clock is 12 hours 55 minutes 32 seconds  
The time deviation of 3 seconds is adjusted 40 ms per second. The internal clock will be synchronized to the specified time 75 seconds later.

- **Date Format**

You can select the display format of the data from "2005/09/28," "09/28/2005," "28/09/2005," and "28.09.2005."

For the setting procedure, see section 2.4.

- **Time Zone**

Set the time difference between the location where the DX is used and GMT.

For the setting procedure, see section 2.2.

- **DST**

If the DX is used in a region that has DST, the time is switched automatically between DST and standard time by setting the date/time when switching from the standard time to DST and the date/time when switching back from DST to standard time.

For the setting procedure, see section 2.1.

## System Display

Displays the total number of inputs on the DX, the size of the internal memory, the communication functions, the external storage drive, the options, the remote controller ID, the MAC address, and the firmware version number.

For the operating procedure, see section 2.5.

## Language

The displayed language can be set to English, Japanese, German, French, or, Chinese.


For the setting procedure, see section 2.6.

## VGA Output Terminal (/D5 Option)

Shows the DX display on a monitor through the RGB output.

## 24 VDC Power Supply for Transmitter (/TPS4 or /TPS8 Option)

Provides 24-VDC power supply to up to four (/TPS4) or eight (/TPS8) two-wire system transmitters. The measured values of the transmitter correspond to a current signal of 4 to 20 mA on the same cable. Therefore, the signal can be connected to the DX input terminal and displayed.




## Easy Text Entry Option (/KB1 and /KB2 Options)

You can control the DX using the keys on the remote control terminal.

- Set the remote controller ID on the DX and the ID number on the remote control terminal to the same value.
- You can set a value between 0 and 31 for the remote controller ID and ID number.
- By changing the ID number on the remote control terminal, you can control DXs with different remote controller IDs from a single remote control terminal.

For the operating procedure, see section 2.10.



## USB Interface (/USB1)

You can connect a keyboard or USB flash memory to the USB port on the front and rear panels of the DX.

- You can use a keyboard to control the DX.
- You can save measured data and setup data to the USB flash memory and also load from it.

Connectable devices: 109/104 keyboard and USB flash memory

For the operating procedure, see sections 2.11 and 2.12.

## External Input Channels (/MC1)

These channels handle measured data of other devices that is read with the communication function. There are 240 channels available. As with measurement channels, the data of these channels can be displayed and saved.

For the setting procedure, see sections 10.1 and 10.2.

## Temperature Unit

You can set unit when measuring temperature with the thermocouple or RTD to °C or °F.

For the setting procedure, see section 3.3.


# 2.1 Setting the Date/Time

Set the date/time. If you are using the DX in a region that uses DST, specify the date/time for switching between DST and standard time.

## Setup Screen


- Date/Time**

Press **MENU** (switch to the setting mode) and select **Date/Time > Date & Time**



- DST**

Press **MENU** (switch to the setting mode) and select **Date/Time > Daylight Saving Time**



## Setup Items

- Time set**

Enter the date and time and press **DISP/ENTER**.

- Daylight savings time > Use/Not**

To switch between DST and standard time, select **Use**.

- Daylight savings time > Start time**

Specify the date/time to switch from standard time to DST. Set the month, the nth week, the day of the week, and the time.

- Daylight savings time > End time**


Specify the date/time to switch from DST to standard time. Set the month, the nth week, the day of the week, and the time.

## 2.2 Setting the Time Difference from GMT

Set the time zone of the region in which the DX will be used. Make sure to set this value if you are using the Internet network functions or the DST function.

### Setup Screen

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Time settings**



### Setup Items

- **Date & Time > Time zone**

Set the time zone of the region in which the DX will be used in terms of the time difference from GMT. Specify a value in the range of -1300 to 1300 (where the first two digits denote the hour and the last two digits denote the minute). A negative value indicates that the local time is behind the GMT.

Example: The standard time in Japan is ahead of the GMT by 9 hours. In this case, enter "900."


## 2.3 Setting the Time Correction Operation during Memory Sampling

This function gradually corrects the time when the time is changed while Memory Sampling is in progress.

For a description of the time correction operation, see section 1.10.


### Setup Screen

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Time settings**



### Setup Items

- Time deviation limit



When the time deviation between the time on the DX and the specified time is within  $\pm$ (the value specified here), the time on the DX is gradually corrected. Otherwise, the clock is corrected immediately.

Settings	Description
10 s to 5 min	The time deviation limit.
Off	Disables the function that gradually corrects the time.

Example: If **Time deviation limit** is set to **10s** and the time on the DX is 10 hours 21 minutes 15 seconds, the time on the DX is gradually corrected if the specified time is between 10 hours 21 minutes 5 seconds and 10 hours 21 minutes 25 seconds.




## 2.4 Setting the Date Format

Select the display format of the date.

### Setup Screen

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Time settings**



### Setup Items

- **Date format**

Settings	Display Example	
	Dates other than the grid time of the trend display	Time at the grid position in the trend display (example: 8 O'clock on Nov. 30)*
Y/M/D	2005/11/30	11/30 08
M/D/Y	11/30/2005	11/30 08
D/M/Y	30/11/2005	30/11 08
D.M.Y	30.11.2005	30.11 08

\* Only if the trend interval is set greater than or equal to 1 h/div. A function available on DXs with release number 2 or later.

### Applied Range

The format is applied to the date displayed on the screen. It does not change the date format on the setup screen of the date/time, the date in the output data via communications, the date saved along with the data, and the date used in the data file names.

## 2.5 Viewing the DX Information

Show the DX information on the system information screen and the network information screen.

### Procedure

- **Displaying System Information Screen**

1. In the operation mode, press **FUNC**.  
The FUNC key menu appears.
2. Press the **System info soft key**.  
The system information screen is displayed.

- **Displaying Network Information Screen**

1. In the operation mode, press **FUNC**.  
The FUNC key menu appears.
2. Press the **Network info soft key**.  
The network information screen is displayed.

### Explanation

- **System Information Screen**

The screenshot shows the 'SYSTEM INFO.' screen with the following data points highlighted by red lines:

- ANALOG**: 48(C) → Number of measurement channels (C denotes the clamped input terminals (/H2 option))
- MATH**: 60 → Number of computation channels (/M1 and /PM1 options)
- EXTCH**: 240 → Number of external input channels (/MC1 option)
- MEMORY**: 80MB → Internal memory size
- OPTIONS**: A list of options including ETHERNET, RS-422A/485, ALARM 0.6.0.0, REMOTE, PULSE, CF, USB, CUT0, SPECIAL INPUT, and CAL CORRECT.
- Remote controller ID**: 2 → (/KB1 and /KB2 options)
- MAC address**: 00:00:64:88:25:F4 →
- Version**: 1.01 → Firmware version

- **Network Information Screen**

The following values set on the DX are displayed.

IP address, MAC address, DNS server, host name, and domain name

The screenshot shows the 'NETWORK INFO.' screen with the following configuration details:

```

NETWORK INFO.
2005/10/28 18:26:46
IP address   : 0. 0. 0. 0
Subnet mask  : 0. 0. 0. 0
Default gateway : 0. 0. 0. 0

MAC address  : 00:00:64:88:25:F4

DNS server
Primary      : 0. 0. 0. 0
Secondary    : 0. 0. 0. 0

Host name
XXXXXXXX-XX


Domain name
XX.XXXX.net
  
```

## 2.6 Changing the Displayed Language

Set the displayed language.

### Setup Screen

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > Operating Environment**



### Setup Items


- **Operating environment > Language**  
Set the displayed language to **English, Japanese, German, French, or Chinese**

## 2.7 Setting the LCD Brightness and Backlight Saver

Change the LCD brightness. In addition, set the backlight saver function to prolong the service life of the LCD backlight.

### Setup Screen

Press **MENU** (switch to the setting mode) and select **Display > Trend, Bar graph, LCD, Monitor**



### Setup Items

- **LCD > Brightness**

Select a value from 1 to 6 (2 by default). Larger the value, brighter the display becomes.

- **LCD > Backlight saver > Mode**

Settings	Description
Off	Disables the backlight saver
Dimmer	Dims the display if there is no operation for a given time.
Timeoff	Turns the backlight OFF if there is no operation for a given time.

- **LCD > Backlight saver > Saver time**

Select a value from 1 min to 1 h. If the specified time elapses without any key operation or alarm occurrence, the LCD backlight switches to the specified mode.

- **LCD > Backlight saver > Restore**

Settings	Description
Key	The backlight returns to the original brightness when a key is pressed.
Key+Alm	The backlight returns to the original brightness when a key is pressed or when an alarm occurs.

### Note


- If the backlight is dimmed or turned OFF by the backlight saver function, pressing any key on the DX causes the backlight to return to the original brightness. In this operation, the key does not perform its intended function.
- The degradation of the brightness and the discoloration of the screen (become yellowish) tend to progress faster as the brightness is set higher. Extended use at an unnecessary high setting should be avoided. It is also recommended that you use the backlight saver function.

## 2.8 Initializing Settings and Clearing the Internal Memory

Initialize the settings to default values. In addition, clear the data in the internal memory. For the default settings, see the *DX2000 Operation Guide (IM04L42B01-02E)*.

### Setup Screen

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Load settings, Initialize > Initialize**



### Setup Items

- **Initialize**

Settings	Description
Clear 1	Initializes the settings of the basic setting mode and setting mode and clears the data in the internal memory.
Clear 2	Initializes the settings of the setting mode and clears the data in the internal memory.
Clear 3	Clears the data in the internal memory.

- **Data in the Internal Memory That Is Cleared**

Display data, event data, manual sampled data, report data (/M1 and /PM1 options), and log information.

### Procedure


1. Press the **Clear 1**, **Clear 2**, or **Clear 3** soft key.
2. Press **DISP/ENTER**.  
A confirmation window opens.
3. Select **Yes** and press **DISP/ENTER**.  
The specified operation is executed, and the DX returns to the operation mode.  
If you do not want to initialize, select **No** and press **DISP/ENTER**.

## 2.9 Outputting the DX Status via the Relay Contact (/F1 and /F2 Options)

A signal is output to a dedicated relay when an error occurs in the DX CPU. In addition, a signal is output to a different relay when the a specified status occurs. For a description of the FAIL/status output function, see section 1.7.

### Setup Screen

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Status relay**



### Setup Items

- **Memory/Media status**  
On: Outputs the internal memory and CF card statuses to the relay.
- **Measurement error**  
On: Outputs a relay signal when a measurement error occurs.
- **Communication error**  
On: Outputs a relay signal when a communication error occurs.
- **Memory stop**  
On: Outputs to the relay when the memory sampling is stopped.

### Procedure

- **FAIL Output**  
There are no settings or operations that are required. A signal is output to the relay contact when a CPU error is detected. A signal is also output to the relay contact when the DX is turned OFF.
- **Status Relay**  
A signal is output to the relay contact when a specified status occurs.

## 2.10 Controlling the DX with the Remote Control Terminal (/KB1 and /KB2 Options)

### Handling Precautions


- If the infrared signal output section of the remote control terminal or the light-receiving section on the DX becomes dirty or receives scratches, it can hinder the transmission/reception of the infrared signal. Clean the infrared signal output section of the remote control terminal or the light-receiving section on the DX.
- When cleaning, wipe using a dry soft cloth. Do not use chemicals such as benzene or thinner, since these may cause discoloring and deformation.
- Do not apply shock to the remote control terminal.
- Do not operate the remote control terminal with wet hands.
- The transmission/reception sensitivity of the infrared signal may deteriorate if used in the following types of locations.
  - Location where the receiver of the DX is exposed to direct sunlight or fluorescent lamp.
  - Near magnetic field sources such as a transceiver.
- If you carry the remote control unit in your pocket, for example, keys may be pressed unintentionally and cause the DX to be controlled. Handle the remote control terminal properly so that keys are not pressed inadvertently.
- When you are near the DX, press the keys on the remote control terminal only when controlling the DX. If you are going to press the keys on the remote control terminal but do not wish to control the DX, take measures so that the signal does not reach the DX such as by covering the infrared signal output section of the remote control terminal.
- The distance at which the DX can be controlled using the remote control terminal varies depending on the operating environment such as the battery voltage and the presence or absence of external light.
- There is a possibility that DXs with the same remote controller ID be controlled simultaneously. It is recommended that different remote controller IDs be set on each DX.

### Preparing the DX

Set the remote controller ID.

- **Setup Screen**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > Operating Environment**



- **Remote Controller ID**


Select the remote controller ID from **0** to **31**. When not using the remote control terminal, select **Off**.

- **Checking the Remote Controller ID**

You can check the DX remote controller ID on the system information screen. See section 2.5.

## Preparing the Remote Control Terminal


### Names of Parts



### Loading Batteries

1. While pressing the projection on the battery cover, open the cover.


2. Load the batteries.  
3. Close the battery cover.



### Setting the ID Number

Set the ID number of the remote control terminal to match the remote controller ID of the DX that you are to operate.

The ID number of the remote control terminal is not displayed anywhere. If you are not sure which ID number the remote control terminal is set to, set the appropriate ID number according to the following procedure.



1. Press ID.

2. Enter the ID number (0 to 31) by pressing the keys from 1 (A1) to 0 (N0).

Example For ID number "16"

Operation: Press 1 (A1) and 6 (G6).


3. Press ID.

### Note

- If you enter an ID number other than 0 through 31, the ID number retains the original setting.
- Pressing the ID key once causes the remote control terminal to enter the ID number setup mode. If none of the keys on the remote control terminal is pressed for 8 s, the remote control terminal automatically exits from the ID number setup mode. In this case, the ID number of the remote control terminal retains the original setting.
- If you remove the batteries, the ID number is reset to 0. After loading the batteries, set the appropriate ID number again.

### Affixing the ID Number Label

If you are using the remote control terminal with a fixed ID number (such as when there is a one-to-one correspondence between the DX to be controlled and the remote control terminal), you can enter the ID number on the label and affix the label on the remote control terminal.



Affix the ID number label on the battery cover of the remote control terminal.




### Controlling the DX

Control the DX by pointing the infrared output section of the remote control terminal to the light-receiving section on the DX. Control the DX while checking the results on the DX screen.

**Note**


- The remote control terminal cannot be used to control the Favorite key.
- When a specific key operation is possible on the DX, the corresponding key on the remote control terminal is activated. For example, the operation for entering a character string is activated when a window for entering a character string is displayed on the DX screen.
- You cannot control the DX using the remote control terminal, if the remote control terminal is in the ID number setup mode.

• **Correspondence with the DX Keys**



• **Entering Strings**

When a character input window is displayed on the DX screen, pressing the A/a1 key switches the character type assigned to the character input keys as shown in the following figure.




• **Uppercase Alphabet Characters and Symbols/Lowercase Alphabet Characters and Symbols**

Alphabet (A to Z or a to z)

Each time the MARK key is pressed, the displayed symbol switches in the following order. The display switches in a cyclic pattern.

Number of times the key is pressed	1	2	3	4	5	6	7	8	9	10
Symbol	%	#	°	@	-	( )	+	*	/	

• Numbers




Number (1 to 9 and 0)

Decimal point

However, when setting a constant to be used in the computation on the DX with the /M1 or /PM1 option, the display switches in the order “.”, “+”, and “E” each time the key is pressed. The display switches in a cyclic pattern.

Minus sign

When a window for entering an equation is displayed on the DX with the /M1 math option, the character strings of computing elements are assigned to each key as shown in the following figure.



The character string switches in the following order each time the key is pressed. The display switches in a cyclic pattern.

key	Number of times the key is pressed								
	1	2	3	4	5	6	7	8	9
A1	1	(	)						
B2	2	K	C	D	P	Q	I	S	F
C3	3	+	-	*	/	.			
E4	4	[	]	?	:				
F5	5	.EQ.	.NE.	.GT.	.LT.	.GE.	.LE.		
G6	6	AND	NOT	XOR	OR				
I7	7	SQR(	ABS(	LOG(	EXP(	LN(			
J8	8	PRE(	RESET(	CARRY(	HOLD(				
K9	9	TLOG.AVE(	TLOG.MAX(	TLOG.MIN(	TLOG.SUM(	TLOG.P-P(			
N0	0	CLOG.AVE(	CLOG.MAX(	CLOG.MIN(	CLOG.SUM(	CLOG.P-P(			

### Troubleshooting

The DX does not react when you try to control it using the remote control terminal.

- **Are the correct batteries loaded in the remote control terminal?**  
Check the voltage and polarity of the batteries.
- **Are the batteries flat?**  
Replace the batteries with new ones.
- **Does the ID number of the remote control terminal match the remote controller ID of the DX that you are trying to control?**  
Check the remote controller ID on the DX, and set the ID number of the remote control terminal to the same value.
- **Is the remote control terminal in ID number setup mode (condition in which the ID key is pressed once)?**  
Wait 8 seconds without pressing any keys to exit from ID number setup mode.
- **Is the remote control terminal too far away from the DX?**  
Get closer to the DX. Control from as close to the front of the DX as possible.
- **Is a strong light hitting the light-receiving section of the DX?**  
Take measures to prevent strong light from hitting the light-receiving section of the DX.
- **Is there a magnetic field source such as a transceiver nearby?**  
Move the magnetic field source away from the DX.
- **Is the infrared output section of the remote control terminal or the light-receiving section on the DX dirty?**  
Clean them.
- **Is the DX in a condition that allows the relevant key operation?**  
Check the condition of the DX, and start from an operation that is possible.


## 2.11 Controlling the DX with a Keyboard (/USB1 Option)

### Connecting/Removing a Keyboard

- **Connecting a Keyboard**

Connect the keyboard connector to the USB port on the DX.

The message “USB device has been connected” appears on the screen, and the keyboard is ready for use.



- **Removing the Keyboard**

Remove the keyboard connector from the USB port on the DX.

#### **Note**

- You can connect or remove the keyboard regardless of the DX status (power ON/OFF or displayed screen).
- One keyboard can be connected.
- Use a keyboard appropriate for the language setting on the DX.
- The state of the CapsLock and NumLock keys is retained even if you disconnect the USB keyboard. A function available on DXs with release number 2 or later.

## Operating from the Keyboard

Use the keyboard while watching the DX screen. An operation that can be carried out on the DX can be carried out from the keyboard.

### Example: Switch to setting mode

When the DX is in the operation mode, press Ctrl+M.

The DX switches to setting mode, and the setting menu appears.

- **Mapping of the Keys on the DX to the Keys on the Keyboard**

Keys on the Keyboard 104 Keyboard (US)for the PC	Keys on the DX
Enter	DISP/ENTER
←	Left arrow key
↑	Up arrow key
↓	Down arrow key
→	Right arrow key
Num Enter	DISP/ENTER
Esc	ESC
F1 to 7	Soft key 1 to soft key 7
F9	FUNC
F12	Hold down FUNC for 3 seconds
Left-Windows	MENU
Right-Windows	MENU
Application	Favorite key
Ctrl+S	START
Ctrl+P	STOP
Ctrl+U	USER
Ctrl+M	MENU
Ctrl+F	Favorite key
Tab, Shift+Tab	Arrow keys*

\* Press **Tab** to move the cursor to the next item, or **Shift+Tab** to move to the previous item. However, this does not work in the following screens:

Operation screens, Menu screens for Setting mode and Basic setting mode, screens for entering values and characters, "Menu customize" and "Save/Load" screens in Setting mode, and "Load setting, Initialize" screen in Basic setting mode

- **Entering Alphabets, Numbers, and Symbols**

When alphabets, numbers, and symbols can be entered on the DX, you can enter them from the keyboard. The operation is the same as with normal keys. However, symbols that cannot be used on the DX are invalid.

### Symbols That Can Be Entered Using the Keyboard

The symbols below can be entered. However, symbols that cannot be used on the DX are invalid. For example, the characters &, \*, /, :, and ? cannot be used in the data save destination directory name.


# % & ( ) \* + - . / : ? @ [ ] ^ \_

\* Press "A" on the keyboard to enter the temperature degree symbol.

- **Invalid Keys**

Keys enclosed in frames are invalid.

### The 104 Keyboard for a PC (US)




## 2.12 Using the USB Flash Memory (/USB1 Option)

### Connecting/Removing a USB Flash Memory


- **Connecting a USB Flash Memory**

1. Connect a USB flash memory to the USB port on the DX.
2. In operation mode, possible operations are shown. Select the desired operation using the **arrow keys** and press **DISP/ENTER**.

When set to auto save



When set to manual save



Setting	Description
Save Manual	Saves unsaved data in the internal memory to the USB flash memory.
Save data	Moves to the memory summary display. For the procedure to save the internal memory data, see section 4.8. Save data is displayed only when a flash memory is connected to the USB port and is usable* in the operation mode (Release Number 2 or Later). * If DX is configured so that any of the items below is shown in the display selection menu, Save data can be executed. You can change the items shown in the display selection menu using the MENU CUSTOMIZE function. SELECT SAVE, M.SAMPLE SAVE, REPORT SAVE, or ALL SAVE
Load Settings	Moves to the setup load display of the setting mode. For the procedure to load the setup data, see section 6.9.
Cancel	Closes the operation selection window.

## 2.12 Using the USB Flash Memory (/USB1 Option)

---

- **Removing the USB Flash Memory**

1. In the operation mode, press **FUNC**.  
The FUNC key menu appears.
2. Press the **Media eject** soft key and then the **USB** soft key.  
A message "Media can be removed safely." appears.
3. Remove the USB flash memory.

**Note**

---

- One USB flash memory can be connected.
  - Be sure to carry out the procedure above when removing the USB flash memory.
- 

## Saving and Loading Data

The following data save/load and file operations can be carried out.

Save/Load setup data files (see section 6.9).

Save display data and event data files (see sections 4.8 and 6.4).

Load display data and event data files (see section 6.8).

List files and delete files (see section 6.7).

Format (see section 6.7).


## 3.1 Setting the Scan Interval and the Integration Time of the A/D Converter

Select the scan interval and the integration time of the A/D converter.

For a description of the scan interval and the integration time of the A/D converter, see section 1.1.

### Setup Screen

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **A/D, Memory**



### Setup Items

- **Scan interval > Scan mode**  
Normal: Measures at the normal mode scan interval.  
FAST: Measures at a scan interval of 25 ms (DX2004 and DX2008) or 125 ms (DX2010, DX2020, DX2030, DX2040, and DX2048).
- **Scan interval > Scan interval**  
The selectable settings appear.
- **Scan interval > A/D integrate**  
When the scan mode is set to **Normal**, select the A/D integration time as necessary. Only the selectable settings are displayed.

Settings	Description
Auto	The DX automatically detects the power supply frequency and sets the integration time to 16.7 ms and 20 ms for 60 Hz and 50 Hz, respectively. Fixed to 20 ms on /P1 models that use the 24 VDC power supply.
50Hz	Sets the integration time to 20 ms.
60Hz	Sets the integration time to 16.7 ms.
100ms	Sets the integration time to 100 ms (when the scan interval is 2 s or 5 s).
600Hz	The A/D integration time for fast sampling mode. You cannot change this value.




## 3.2 Setting the Burnout Detection and the Reference Junction Compensation of the Thermocouple Input

Set the function that detects burnouts in the sensor for thermocouple input and 1-5V input and the reference junction compensation method of the thermocouple.

### Setup Screen

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Burnout, RJC**



### Setup Items

- **First-CH/Last-CH**  
Select the target channels.

- **Burnout set > Mode**

#### Thermocouple Input

Settings	Description
Off	Does not detect burnouts in the sensor.
Up	When the sensor burns out, the measured result is set to +over range. The measured value displays "Burnout." For 1-5V input, the DX assumes that the sensor has burned out when the measured value exceeds the scale upper limit by 10% of the scale width. (Example: When the measured value is greater than 110 when the scale is from 0 to 100)
Down	When the sensor burns out, the measured result is set to –over range. The measured value displays "Burnout." For 1-5V input, the DX assumes that the sensor has burned out when the measured value falls below the scale upper limit by 5% of the scale width. (Example: When the measured value is less than –5 when the scale is from 0 to 100)

- **RJC > Mode**

Sets the reference junction compensation method of the thermocouple input. Select **Internal** or **External**.

Settings	Description
Internal	Uses the reference junction compensation function of the DX.
External	Uses an external reference junction compensation function. When set to <b>External</b> , <b>Volt</b> is displayed.

- **RJC > Volt**

The compensation voltage to be added to the input. Set the value in the range of –20000  $\mu$ V to 20000  $\mu$ V.


## 3.3 Setting the Input Range

Set the input range for each channel.

### Setup Screen


- **Temperature Unit**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > Operating Environment**



- **Input Range for Each Channel**

Press **MENU** (switch to the setting mode) and select **Meas Channel > Range, Alarm**



### Setup Items

- **Temperature**

Select the temperature unit. The setting is applied to all temperature measurement channels.

Settings	Description
C	Use Celsius
F	Use Fahrenheit

### 3.3 Setting the Input Range

- **First-CH/Last-CH**  
Select the target channels.

- **Range > Mode**

Settings	Description
Skip	Not measured.
Volt, TC, RTD, DI, 1-5V	Input type. Represents DC voltage, thermocouple, RTD, ON/OFF input, and 1-5V inputs, respectively.
Delta, Scale, Sqrt	Difference computation, linear scaling, and square root computation.

Set the items with check marks in the table below according to the mode value.

Setup Item	Mode								
	Volt	TC	RTD	DI	Delta	Scale	Sqrt	1-5V	Skip
Type					✓	✓			
Range	✓	✓	✓	✓	✓	✓	✓	✓	
Span Lower	✓	✓	✓	✓	✓	✓	✓	✓	
Span Upper	✓	✓	✓	✓	✓	✓	✓	✓	
Scale Lower						✓	✓	✓	
Scale Upper						✓	✓	✓	
Unit						✓	✓	✓	
Ref. CH					✓				
Low-cut							✓	✓	
Low-cut value							✓		

- **Range > Type**  
Input type when **Mode** is **Delta** or **Scale**. See the description on Mode above.

- **Range > Range**

Input type details.

Setting	Input Type	Notes
20mV	-20.000 mV to 20.000 mVDC	Standard
60mV	-60.00 mV to 60.00 mVDC	
200mV	-200.00 mV to 200.00 mVDC	
2V	-2.000 V to 2.000 VDC	
6V	-6.000 V to 6.000 VDC	
20V	-20.000 V to 20.000 VDC	
20V	-50.00 V to 60.00 VDC	
Pt	Pt100	
JPt	JPt100	
Level	ON/OFF(Voltage)	
Contact	ON/OFF(Contact)	
1-5V	0.800V to 5.200V	

Setting	Input Type	Notes
R	Type R	Standard
S	Type S	
B	Type B	
K	Type K	
E	Type E	
J	Type J	
T	Type T	
N	Type N	
W	Type W	
L	Type L	
U	Type U	
WRe	type WRe	

Setting	Input Type	Notes
Kp	Kp vs Au7Fe	/N3 option
PLATI	PLATINEL	
PR	PR40-20	
NiMo	NiNiMo	
W/WRe	W/WRe26	
N2	Type N (AWG14)	
Pt50	Pt50	
Ni1	Ni100 (SAMA)	
Ni2	Ni100 (DIN)	
Ni3	Ni120	
J263	J263*B	
Cu53	Cu53	
Cu100	Cu100: a = 0.00425 at 0°C	
Pt25	Pt25	

Setting	Input Type	Notes
Cu1	Cu10 (GE)	/N1 option
Cu2	Cu10 (L&N)	
Cu3	Cu10 (WEED)	
Cu4	Cu10 (BAILEY)	
Cu5	Cu10: a = 0.00392 at 20°C	
Cu6	Cu10: a = 0.00393 at 20°C	
Cu25	Cu25: a = 0.00425 at 0°C	

- **Range > Span Lower, Span Upper**

Input range. The selectable range is displayed on the screen.

**Note**

- You cannot set the same value to **Span Lower** and **Span Upper**.
- When the **Mode** is **1-5V** or **Sqrt**, **Span Lower** must be less than **Span Upper**.

- **Range > Scale Lower, Scale Upper**

Input range after converting the unit.

The selectable range is from -30000 to 30000. The decimal place is determined by the **Scale Lower** setting. It can be set to the following positions: "X.XXXX," "XX.XXX," "XXX.XX," "XXXX.X," or "XXXXX."

**Note**

- The DX converts the measured value to a value obtained by removing the decimal point from the value span specified by **Scale Lower** and **Scale Upper**. For example, if the scale setting is "-5 to 5," the value is converted to a value within the span of "10"; if the scale setting is "-5.0 to 5.0," the value is converted to a value within a span of "100." In this case, the resolution of the value converted to a span of "10" is lower than the value converted to a span of "100." To prevent the display from becoming rough, it is recommended that the scale be set so that this value is greater than 100.
- You cannot set the same value to **Scale Lower** and **Scale Upper**.
- When the **Mode** is **1-5V** or **Sqrt**, **Scale Lower** must be less than **Scale Upper**.

- **Range > Unit**

Sets the unit (up to 6 characters,  $[A|a|\#|1]$ ).

- **Range > Ref. CH**

The reference channel for difference computation.


- **Range > Low-cut**

Select **On** to use the low-cut function.

\* The low-cut value for 1 to 5 V input is fixed to 0% value of the input span.

- **Range > Low-cut value**

On a square root computation channel, set the low-cut value in the range of 0.0% to 5.0% of the input span.




## 3.4 Setting the Moving Average of the Input

Set the moving average function of the measurement channel. This function suppresses the effects of noise.


For a description of the function, see section 1.1.

### Setup Screen

Press **MENU** (switch to the setting mode) and select **Meas Channel > Moving average**



### Setup Items



- **First-CH/Last-CH**  
Select the target channels.
- **On/Off**  
To use moving average, select **On**.
- **Count**  
Set the number of data points of the moving average in the range of 2 to 400.

## 3.5 Setting the Auxiliary Alarm Function

### Setup Screen

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Alarm**

### Setup Items

- **Basic setting > Reflash**

To set the reflash operation on the alarm output relay, select **On**. The reflash function is set on the first three output relays.

- **Basic setting > Rate of change**

- **Decrease**

Set the interval for the rate-of-change calculation of the low limit on rate-of-change alarm in terms of the number of sampled data points (1 to 32). The actual interval is obtained by multiplying the value specified here by the scan interval.

- **Increase**

Set the interval for the rate-of-change calculation of the high limit on rate-of-change alarm in the same manner as the interval for the low limit on rate-of-change alarm.

- **Basic setting > Indicator**

Select the alarm indication behavior from the following:

Settings	Description
Nonhold	Clears the alarm indication when the alarm condition is released (returns to normal condition).
Hold	Holds the alarm indication until an alarm acknowledge operation is performed.

### 3.5 Setting the Auxiliary Alarm Function

- **Switch, Relay**

- **Internal Switch > AND**

Select the internal switches that are to operate using AND logic. Set the range of internal switches (from the first internal switch) to take the AND logic. All subsequent switches will be set to OR logic.

- **Relay > AND**

Select the relays that are to operate using AND logic. Set the range of relays (from the first alarm relay) to take the AND logic. All subsequent relays will be set to OR logic. Available settings are **None**, **I01** (I01 only), **I01-I02** (I01 and I02), **I01-I03** (I01 to I03), etc. Only alarm output relays that are installed are valid.

**Note**

When reflash is turned ON, the operation of the first three output relays is fixed to OR logic. Specifying **AND** produces no effect.

- **Relay > Action**

Select whether the alarm output relay is energized or de-energized when an alarm occurs. The setting applies to all alarm output relays.

- **Relay > Hold**

Select the alarm output relay behavior from below: The setting applies to all relays.

Settings	Description
Nonhold	Turns the output relay OFF when the alarm condition is released (returns to normal condition).
Hold	Holds the output relay at ON until an alarm acknowledge operation is performed.

**Note**

When reflash is turned ON, the operation of the first three output relays is set to nonhold. Specifying **Hold** produces no effect.


- **Relay > Relay Action on Ack**

You can select the relay output status that is enabled after the alarm ACK operation from the following two settings.


Settings	Description
Normal	The relay output is deactivated when the alarm ACK operation is executed. If the condition for activating the alarm output relay is met in the next scan interval, the relay output is activated. This operation is valid only when the alarm output relay is set to <b>Hold</b> .
Reset	The relay output is deactivated when the alarm ACK operation is executed. If a new condition for activating the alarm output relay is met, the relay is activated.

An example of the relay action when alarm ACK is executed is shown below. This example is for the case when the output relay **AND** item is set to **OR**.

**Normal**



## Reset



- **Hysteresis > Meas CH**
  - **High/Low**  
Sets the hysteresis width of the alarm occurrence/release of the high/low limit alarm specified on measurement channels.  
Selectable range: 0.0% to 5.0% of the span or scaling width
  - **Delta High/Low**  
Sets the hysteresis width of the alarm occurrence/release of the difference high/low limit alarm specified on measurement channels.  
Selectable range: 0.0% to 5.0% of the span
- **Hysteresis > Math CH (/M1 and /PM1 options) and Ext. CH (/MC1 option)**  
Sets the hysteresis width of the alarm occurrence/release of the high/low limit alarm specified on computation and external input channels.  
Selectable range: 0.0% to 5.0% of the measurement span



## 3.6 Hiding the Alarm Indication

Select whether to enable the alarm hide function.

### Setup Screen

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > View, Message, Input, Alarm**

The screenshot shows the 'Basic Settings Mode' interface. At the top, it says 'Basic Settings Mode' and 'Ethernet Link'. Below that, the navigation path is 'Environment > View, Message, Input, Alarm'. The screen is divided into several sections: 'View' with settings for Trend type (T-V), Partial (Off), and Trend rate switching (Off); 'Input' with 'Value on over-range' set to 'Over'; 'Message' with 'Write group' set to 'Common', 'Power-fail message' set to 'Off', and 'Change message' set to 'Off'; and 'Alarm' with 'Detect' set to 'Off'. At the bottom, there are 'On' and 'Off' buttons.

### Setup Items

- **Alarm > Detect**

To enable the function that turns off the alarm indicator and logging, select **On**. The **Detect** setup item is displayed in the alarm setting screen (see section 3.7).

This function disables the alarm indicator and the logging of the alarm event to the alarm summary even when an alarm occurs.

- **Settings for Each Channel and Each Alarm**

See section 3.7.

## 3.7 Setting Alarms on Channels

Set the alarms after setting the range. All alarm settings of a channel are cancelled in the following cases.

- When the input type (**Volt**, **TC**, etc.) is changed.
- When the input range is changed.
- When the upper or lower limit of the span or scale is changed on channels that are set to linear scale, square root computation, or 1-5 V (including changes in the decimal point position).

### Setup Screen

#### Alarms for Each Channel

Press **MENU** (switch to the setting mode) and select **Meas. Channel > Range, Alarm**

Mode	Range	Span Lower	Span Upper
Volt	2V	-2.0000	2.0000

	Type	Value	Relay On/Off	Number	Detect	
1	On	H	0.0000	On	101	On
2	Off	H	0.0000	On	101	On
3	Off	H	0.0000	On	101	On
4	Off	H	0.0000	On	101	On

#### Alarm Delay Time

Press **MENU** (switch to the setting mode) and select **Meas. Channel > Tag, Memory sample, Alarm delay**

### Setup Items

#### First-CH/Last-CH

Select the target channels. The target channels are common with the other items that are displayed on the screen.

#### Alarm > 1, 2, 3, and 4

For each alarm, 1 to 4, select **On** to enable it.


### 3.7 Setting Alarms on Channels

- **Alarm > Type**

Select the alarm type.

Settings Name	Description
H High limit alarm	–
L Low limit alarm	–
h Difference high limit alarm	Can be specified on channels set to difference computation.
l Difference low limit alarm	Can be specified on channels set to difference computation.
R High limit on rate-of-change alarm	–
r Low limit on rate-of-change alarm	–
T Delay high limit alarm	–
t Delay low limit alarm	–

Alarms on channels set to difference computation are inserted at the following positions.



- **Alarm > Value**

Set the alarm value for the selected alarm type.

#### When the Mode of the Channel Is Set to Volt, TC, RTD, or DI

Type	Value	Example of a Range of Alarm Values
H, L	Value in the measurable range	–2.0000 to 2.0000 V for 2 V range
R, r	1 digit to the upper limit of the width of the measurable range However, less than or equal to 30000 excluding the decimal point.	0.0001 to 3.0000 V for 2 V range 0.1 to 1760.0°C for thermocouple type R
T, t	Same as H and L.	Same as H and L.

#### When the Mode of the Channel Is Set to Delta

Type	Value	Example of a Range of Alarm Values
H, L	Value in the measurable range	–2.0000 to 2.0000 V for 2 V range
h, l	Value in the measurable range	–1760.0 to 1760.0°C for thermocouple type R
R, r	1 digit to the width of the measurable range However, less than or equal to 30000 excluding the decimal point.	0.0001 to 3.0000 V for 2 V range 0.1 to 1760.0°C for thermocouple type R
T, t	Same as H and L.	Same as H and L.

#### When the Mode of the Channel Is Set to Scale, Sqrt, or 1-5V

Type	Value	Example of a Range of Alarm Values
H, L	–5% to 105% of the scale width. However, within –30000 to 30000 excluding the decimal point.	–5.0 to 105.0 when the scale is 0.0 to 100.0 –120.00 to 300.00 when the scale is –100.00 to 300.00
R, r	Within 1 to 30000 excluding the decimal point.	0.1 to 3000.0 when the scale is 0.0 to 100.0 0.01 to 300.00 when the scale is –100.00 to 300.00
T, t	Same as H and L.	Same as H and L.

- **Alarm > Relay**

Select whether to turn **On** or **Off** the relay output.

- **Alarm > Number**

Set the output relay number or internal switch number when performing relay output.

- **Alarm > Detect**

This item appears when the alarm hide function (see section 3.6) is turned **On**. Select whether to show or hide the alarm indication when an alarm occurs. If set to **Off**, a signal is output to the alarm output relay or internal switch when an alarm occurs, but it is not indicated on the screen. The alarm is also not recorded in the alarm summary.

- **Alarm delay > Time (for delay high/low limit alarms)**

Set the alarm delay time using an integer in the range of 1 to 3600 s.

**Note**

- The alarm delay time takes on a value that is an integer multiple of the scan interval. For example, if the alarm delay time is set to 5 s when the scan interval is 2 s, the actual delay time is 6 s.
- The delay alarm has the following special operations.
  - If the computation is stopped in a condition in which the computed value is exceeding the alarm setting when a delay alarm is set on a computation channel, the alarm is turned On after the specified period (delay period) elapses.
  - The alarm detection operation is reset if a power failure occurs. The operation restarts after the power recovers.
  - If the alarm setting of the delay high limit alarm is changed when an alarm is already activated and the input is greater than or equal to the new setting, the alarm continues. For all other cases, the alarm detection operation starts at the new setting. This is also true for the delay lower limit alarm.

---

## 3.8 Releasing the Alarm Output (Alarm ACK Operation)

This operation is valid when the DX is set as follows:

### **DX with release number 2 or later**

- When **Indicator** is set to **Hold** in the basic setting mode.
- When **Relay Hold** is set to **Hold** and **Relay action on ACK** is set to **Normal** in the basic setting mode.
- When **Relay action on ACK** is set to **Reset** in the basic setting mode.

### **DX before release number 2**

- When **Indicator** is set to **Hold** in the basic setting mode.
- When **Relay Hold** is set to **Hold** in the basic setting mode.

For the procedure to set the relay action, see section 3.5.

### Procedure

This operation is carried out after an alarm occurs.

- 1.** In the operation mode, press **FUNC**.  
The FUNC key menu appears.
- 2.** Press the **AlarmACK** soft key.  
The alarm output is released.

### Explanation

- **Alarm Acknowledge (ACK) Operation**


When an alarm acknowledge operation is carried out, the indications and outputs (relays and switches) of all activated alarms are cleared.

## 3.9 Performing Calibration Correction (/CC1 Option)


The input value is corrected using segments, and the result is used as a measured value. For a description of the function, see section 1.1.

### Setup Screen

Press **MENU** (switch to the setting mode) and select **Meas Channel > Calibration correction**



### Setup Items



- **First-CH/Last-CH**  
Select the target channels. You can set consecutive channels whose range is set to the same value as the first channel.
- **Calibration correction > Number of set points**  
Select the number of points that make up the segments (including the start and end points) in the range of 2 to 16.  
To disable calibration correction, select **Off**.

- **Calibration correction > MES val, True val**

Press the **Input** soft key and enter the value.

For the MES value, set a value that is greater than the previous value.

Press the **Measure** soft key to set the measured value at that point to MES val. If you press the **Measure** soft key when setting multiple channels simultaneously, the measured value of the first channel are set to the MES val of all channels.

#### Selectable Range of MES and True Values

- **Channels on which linear scaling is specified**

–30000 to 30000 (the decimal place is the same setting as the scale value)

- **Other channels**

Value in the measurable range of the selected range

Example: –2.0000 to 2.0000 for 2 V range

#### Note


- The calibration correction setting is set to Off if you change the **Mode** or **Range** setting.
- Calibration correction cannot be specified on channels set to **Skip**.

## 3.10 Counting Pulses (/PM1 Option)

The pulses applied to the pulse input terminal are counted on a computation channel. For a description of the function, see section 1.1.

### Setup Screen

Press **MENU** (switch to the setting mode) and select **Math Channel > Calculation expression, Alarm**




### Setup Items

- **First-CH/Last-CH**  
Select the target computation channels.
- **Math range > Math On/Off**  
Select **On**.
- **Math range > Calculation expression**  
Enter the equation using symbols.  
Q01 to Q08: Displays the number of pulses per second.  
P01 to P08: Displays the number of pulses per scan interval.  
\* The numbers 01 to 08 correspond to the pulse input terminal numbers.  
For the procedure to set the computation channels, see section 9.1.

The procedure is explained below using an example.

- **Example 1: Pulse Sum Value**  
Display the sum value of the pulse signal applied to pulse input terminal number 6.




### Expression

Assign the computation channel and set the expression. Set the span lower/upper limit and unit according to the application.

Channel	Equation	Description
101	TLOG.SUM(P6)	Sum of the number of pulses per scan interval

• **Example 2: Number of Pulses per Minute**

Count the pulse signal applied to pulse input terminal number 6 on the DX2004 (scan interval set to 250 ms), and calculate and display the number of pulses per minute.



**Expression**

Assign the computation channel as shown below and set the expressions. Set the span lower/upper limit and unit according to the application.

Channel	Equation	Description
101	Q6	Number of pulses per second
102	101*K01	Number of pulses per minute

Constant	Value	Description
K01	60	Coefficient for converting the number of pulses per second to the number of pulses per minute

Channel	Rolling average	Description
101	Sampling interval: 1s Number of samples: 60	Moving average over a minute

**Channels**

The computation is performed in order from the channel with the smallest channel number in one scan interval.

Use a channel of a channel number larger than that of the channel counting the number of pulses per second for the computation channel that is to calculate the number of pulses per minute.

• **Example 3: Reset When the Pulse Sum Value Exceeds a Certain Value**

Reset the sum value when the pulse sum value exceeds a specified value (reset value) and carry over the value exceeding the reset value to the sum after the reset. Count the number of resets and calculate the total sum value up to that point.

**Expression**

Assign expressions to the computation channels as shown below and set the constants.


Channel	Expression	Application
101	((102+P01).GE.K01)+101	Pulse sum value reset count
102	CARRY(K01):TLOG.SUM(P01)	Pulse sum value
103	K01*101+102	Total sum value

Symbol	Description
P01	Counts the number of pulses per scan interval.
K01	Constant. The reset value. The sum value is reset when this value is exceeded.



### 3.10 Counting Pulses (/PM1 Option)



#### Channel 101: Reset Count

Calculates the number of times the pulse sum value is reset.

The expression “((102+P01).GE.K01)” is set to 1 when “the previous pulse sum value (102) + the current pulse count (P01)” is greater than the reset value (K01). Otherwise, the expression is set to 0. The value of channel 101 is incremented when the pulse sum value exceeds the reset value.

#### Channel 102: Pulse Sum Value

Calculates the pulse sum value.

Under normal conditions, the pulse sum value TLOG.SUM (P01) is calculated. When the pulse sum value is greater than or equal to the reset value (K01), the pulse sum value is set to the amount exceeding K01.

#### Channel 103: Total Sum Value

Multiplies the reset value (K01) by the reset count (101) and adds the pulse sum value (102) to derive the total sum value.


#### Note

- The computation is performed in order from the channel with the smallest channel number in one scan interval. If the channel number in the expression is greater than or equal to the channel number in which the expression is assigned, the previous computed result (previous value) is used for the channel in the expression.
- Because the accuracy of the computation function is single-precision floating point, we recommend a reset value less than or equal to  $10^7$ .
- If the pulse input value of the scan interval is greater than the reset value, correct computation cannot be achieved.

## 3.11 Setting the Method of Detecting Over-Range Values of Linearly Scaled Measurement Channels

### Setup Screen

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > View, Message, Input, Alarm**



### Setup Items

- **Input > Value on over-range**

Settings	Description
Free	The value is set to -over range if the value is less than -30000 and +over range if the value is greater than 30000 excluding the decimal point. The value is displayed as -Over and +Over, respectively.
Over	The value is set to -over range if the value is less than -5% of the scale and +over range if the value is greater than 105%. The value is displayed as -Over and +Over, respectively. Example: If the scale is 0.0 to 200.0, the value is set to -over range if the value is less than -10.0 of the scale and +over range if the value is greater than 210.0.


### Note

For computations such as TLOG, CLOG, and report, the handling of the scale over-range value can be set in advance.  
See section 9.1.


# 4.1 Operations in Operation Mode

## Switching the Screen with the DISP/ENTER Key and Arrow Keys

Press DISP/ENTER and arrow keys to show the display selection menu and sub menu to switch the display. The flow of operation is indicated below.




### Operations Using Other Keys



### Operation Using the FUNC Key

Press **FUNC** to display the FUNC key menu at the bottom of the screen. Press the **Next** soft key to switch the menu. Press the desired soft key.



**FUNC key menu (Select using the soft keys)**

AlarmACK	Message	Free message	Media eject	Snap shot	Manual sample	Trigger
Sec. 3.8	Sec. 5.4	Sec. 5.4	Sec. 6.4 Sec. 2.12	Sec. 6.6	Sec. 6.5	Sec. 6.4
Save display	Save event	Save stop	Math start	Math reset	Math ACK	Timer reset
Sec. 6.4	Sec. 6.4	Sec. 4.8/6.4	Sec. 9.4	Sec. 9.4	Sec. 9.4	Sec. 7.1
Keylock	Logout	Password change	Second speed	Batch	Text field	Favorite regist
Sec. 8.1	Sec. 8.3	Sec. 8.2	Sec. 5.3	Sec. 6.3	Sec. 6.3	Sec. 5.16
4Panel	Standard display	System info	Network info	SNTP	E-Mail start	E-Mail test
Sec. 4.10	Sec. 5.15	Sec. 2.5	Sec. 2.5	Comm.*	Comm.*	Comm.*
FTP test	* Communication Interface User's Manual.					
Comm.*						

### Customizing the Menus

The display selection menu that appears when the DISP/ENTER key is pressed and the FUNC key menu that appears when the FUNC key is pressed can be changed. See section 5.18

# 4.2 Displaying the Measured Data as Waveforms, Values, or Bar Graphs

This section explains how to use the trend, digital, and bar graph displays. For a description of the function, see section 1.3.


### Procedure

- **Showing the Display**
  1. Press **DISP/ENTER** to show the display selection menu.
  2. Press the **arrow keys** to select **TREND**, **DIGITAL**, or **BAR**, and press **DISP/ENTER**.

The selected display appears.


- **Changing the Displayed Contents**
  1. Press **DISP/ENTER** to show the display selection menu.
  2. Press the **right arrow key** to display the sub menu.
  3. Press the **up and down arrow keys** to select the sub menu item.

#### Sub menu of the trend display



- Group name:** Displays the group
  - ALL CHANNEL:** Displays the waveforms of all channels
  - GROUP CHANNEL:** Displays the waveforms of the channels registered to groups
  - SCALE ON:** Displays the scale
  - SCALE OFF:** Clears the scale
  - DIGITAL OFF:** Clears the numeric display section
  - DIGITAL ON:** Displays the numeric display section
  - MESSAGE DISP1:** Displays the messages using display method 1
  - MESSAGE DISP2:** Displays the messages using display method 2
  - TREND SPACE ON:** Inserts a space at the right edge (horizontal display) or the top edge (vertical display) in the waveform display section
  - TREND SPACE OFF:** Does not insert a space
- (To show these items on the menu, see section 5.18.)
- AUTO SCROLL ON:** Automatically switches the displayed groups
  - AUTO SCROLL OFF:** Does not automatically switch the displayed groups


#### Sub menu of the digital display



- Group name:** Displays the group
- AUTO SCROLL ON:** Automatically switches the displayed groups
- AUTO SCROLL OFF:** Does not automatically switch the displayed groups

## 4.2 Displaying the Measured Data as Waveforms, Values, or Bar Graphs

Sub menu of the bar graph display



4. Press **DISP/ENTER** to change the displayed contents.

To close the menu without changing the displayed contents, press the **ESC** key.

- **Starting the Waveform Display of the Trend Display/Stopping the Waveform Updating**

Press **START** to start the waveform display of the trend display. Press **STOP** to stop the waveform updating.

- **Writing Messages**

See section 5.4.

- **Switching the Displayed Group Using Arrow Keys**

Press the **right arrow key** to switch the displayed group in ascending order. Press the **left arrow key** to switch the displayed group in reverse.

- **Switching the Trend, Digital, and Bar Graph Displays Using the Arrow Keys**

Press the **down arrow key** while showing the trend, digital, or bar graph display to switch the display in the order trend, digital, bar graph, trend, and so on. Press the **up arrow key** to switch the display in reverse order.

### Explanation

- **ALL CHANNEL\*/GROUP CHANNEL on the Trend Display**

On the group display, the channels that are assigned to the group are displayed. In all channel display, the waveforms of all channels that are configured to record data are displayed on the current group display.

\* All channel display is disabled when the trend interval is 30 s/div on the DX2010, DX2020, DX2030, DX2040, or DX2048 with the external input function (/MC1 option).

- **SCALE ON/OFF and DIGITAL ON/OFF on the Trend Display**

Select whether to show or hide the scale and numeric display sections.

- **AUTO SCROLL ON/OFF**

The displayed groups can be automatically switched at a specified interval by selecting **AUTO SCROLL ON**. The display switches in ascending group order. For the procedure to set the auto scroll interval of groups, see section 5.14.

- **MESSAGE DISP 1 and MESSAGE DISP 2 on the Trend Display**

Switches the message display method.

## 4.3 Displaying Past Measured Data (Historical Trend Display)

There are five methods to display the past measured data.

For a description of the function, see section 1.3.

Recall from the display selection menu (see this section).

Display from the alarm summary (see section 4.6).

Display from the message summary (see section 4.7).

Display from the memory summary (see section 4.8).

Show the measured data stored on an external storage medium (see section 6.8).

### Procedure

#### • Showing the Display


Carry out the procedure below while memory sampling is in progress.

1. Press **DISP/ENTER** to show the display selection menu.
2. Press the **arrow keys** to select **TREND HISTORY**, and press **DISP/ENTER**.  
The display appears.

#### • Changing the Displayed Contents

1. Press **DISP/ENTER** to show the display selection menu.
2. Press the **right arrow key** to display the sub menu.
3. Press the **up and down arrow keys** to select the sub menu item.

##### Sub menu of the historical trend display



**Group name:** Displays the group.

**ALL CHANNEL:** Display the waveforms of all channels.

**GROUP CHANNEL:** Displays the waveforms of the channels registered to groups.

**SCALE ON:** Displays the scale.


**SCALE OFF:** Clears the scale.

**MESSAGE DISP2:** Switches to message display 2.

**MESSAGE DISP1:** Switches to message display 1.


**CURSOR TIME ON:** Displays the time at the cursor position at the lower right.

**CURSOR TIME OFF:** Displays the date/time of the data at the right edge.



Switches to the specified display.


Return to the display that was shown before the historical trend.



Displays the alarm summary in the loaded data file.

Displays the message summary in the loaded data file.

Displays the information of the loaded data file.





Expands/Reduces the time axis.

4. Press **DISP/ENTER** to change the displayed contents.

To close the menu without changing the displayed contents, press the **ESC** key.


### 4.3 Displaying Past Measured Data (Historical Trend Display)

- **Moving the Cursor and Scrolling the Waveform**



- **Displaying the Continuing Data**

Approximately one screen of data is shown on the historical trend display. The continuing data can be shown as follows:



Move the cursor to the end of the waveform and press the arrow key yet again to shift a half a page and display the continuing data.

Move the cursor to the end of the waveform and press the arrow key yet again to shift a half a page and display the continuing data.


\* Use the up and down arrow keys on the vertical trend display.

- **Specifying the Display Range**

Specify the display range. Items inside the parentheses are for the vertical trend display.

1. Press the **up (right) arrow key**.

The waveform of the entire data range is displayed at the top (right) section of the screen.



**All data display (all of the data in the display memory)**  
Loads as much of the continuous data as the display memory can hold and shows the data when switching to the all data display.

**Frame indicating the display range**

**Displayed highlighted.**  
These icons are not displayed if the scale is displayed.

2. Press the **left and right (up and down) arrow keys** to set the display position by moving the frame that indicates the display range.

3. Press the **down (left) arrow key**.

The specified range is displayed.




### 4.3 Displaying Past Measured Data (Historical Trend Display)

- **If the Data Does Not Fit in the All Data Display (Release Number 2 or Later)**  
Specify the range to be displayed in the all data display.  
Below is the procedure to display data that is older than the data displayed currently.  
Items inside the parentheses are for the horizontal trend display.

**1. Press the up (right) arrow key.**

The waveform of all the data in the display memory is displayed at the top (right) of the screen. At the same time, the data area in the internal memory that can be loaded is displayed. In addition, the data position of 8 MB that is displayed in the all data display is indicated using a rectangular frame in the loadable data area.



- 2. Press the left (down) arrow key** to move the frame indicating the display range to the edge of the all data display. If you press the **left (down) arrow key** again, the message "Overwrite old data?" appears.
- 3. Select Yes** and press **DISP/ENTER** to replace 4 MB of data in the display memory.
- 4. Press the left/right (up/down) arrow key** to move the frame indicating the display range to specify the range you want to display.
- 5. Press the down (left) arrow key.**  
The specified range is displayed.

### 4.3 Displaying Past Measured Data (Historical Trend Display)


- **Dividing the Screen into Halves and Displaying the Current Trend and Historical Trend Simultaneously**

This operation is possible only when the historical trend of the display data is being displayed. Items inside the parentheses are for the vertical trend display.

\* This operation is not possible when the scale is displayed.

Press the **down (left) arrow key**.

The current trend is displayed in the right half (top half), and the historical trend is displayed in the left half (bottom half) of the screen.



To revert to the original screen, press the **up (right) arrow key**.

- **Writing Add Messages**

For the operating procedure, see section 5.4.

### Explanation

- **ALL CHANNEL/GROUP CHANNEL**

The waveforms of channels assigned to the group or waveforms of all channels that are configured to record data are displayed on the current group display.

- **SCALE ON/OFF**

Select whether to display the scale. The current value mark of the scale indicates the value at the cursor position.

- **MESSAGE DISP 1 and MESSAGE DISP 2**

Switches the message display method.

- **TIME AXIS > ZOOM+ and ZOOM-**

The time axis can be expanded or reduced around the cursor position.


- Display data: 2 times the trend display to 1/60 minimum

- Event data: Reduction only, up to 1/60 minimum

The minimum magnification and the factor by which the display can be expanded or reduced with one operation vary depending on the trend interval for the display data and on the sampling interval for the event data. To expand or reduce further, repeat the procedure.

• **INFORMATION (Information on the Displayed Measured Data)**

The following information is displayed.



**Page switch mark**  
 Comment and text field are displayed on the second and third pages when using the batch function.  
 Use the left and right arrow keys to switch the page.

Display	Description
File name	Data in the internal memory is displayed as "Memory." For a file on the external storage medium, the file name is displayed.
Data type	<b>Display</b> corresponds to display data, and <b>Event</b> corresponds to event data.
Serial number	The serial number of the DX that was used.
Batch number, Lot number	Displayed when the file is created using the batch function.
Start time and End time	The start time and end time of recording.
User name	Name of the user who performed the operation. Displayed when the login function was used.

**Note**

When measured data on the external storage medium is displayed, the serial number corresponds to that of the DX that was used to save the data.

• **Background Color of the Historical Trend**

You can change the background color of the historical trend.

For the procedure to change the background color of the historical trend, see section 5.13.

## 4.4 Display the Statuses of All Channels on One Screen (Overview Display)

This section explains how to use the overview display.  
For a description of the function, see section 1.3.

### Procedure

- **Showing the Display**

1. Press **DISP/ENTER** to show the display selection menu.
2. Press the **arrow keys** to select **OVERVIEW**, and press **DISP/ENTER**.  
The display appears.

- **Changing the Displayed Contents**

1. Press **DISP/ENTER** to show the display selection menu.
2. Press the **right arrow key** to display the sub menu.
3. Press the **up and down arrow keys** to select the sub menu item.

**Sub menu of the overview display**

**CURSOR OFF:** Clears the cursor.  
**CURSOR ON:** Displays the cursor.

**JUMP TO ALM SUM:** Switches to the alarm summary.

**JUMP TO TREND:** Switches to the trend display of the smallest group number that includes the channel selected with the cursor.

**JUMP TO DIGITAL:** Switches to the digital display of the smallest group number that includes the channel selected with the cursor.

**JUMP TO BAR:** Switches to the bar graph display of the smallest group number that includes the channel selected with the cursor.

(To show these items on the menu, see section 5.18.)

4. Press **DISP/ENTER** to change the displayed contents.  
To close the menu without changing the displayed contents, press the **ESC** key.

- **Showing the Trend, Digital, Bar Graph Display Containing the Specified Channel**

1. Press the **arrow keys** to move the cursor, and select a channel.

**Cursor (white Frame)**

2. Switch to the trend, digital, or bar graph display according to the procedure described in "Changing the Displayed Contents."

# 4.5 Displaying Various Information

This section explains how to display reports (/M1 and /PM1 options) and how to use the status display.


For a description of the function, see section 1.3.

## Procedure

### Showing the Display

1. Press **DISP/ENTER** to show the display selection menu.
2. Press the **up and down arrow keys** to select **INFORMATION**.
3. Press the **right arrow key** to display the sub menu.
4. Press the **up and down arrow keys** to select the sub menu item.  
To close the menu without changing the displayed contents, press the **ESC** key.

#### Sub menu of the information display



**ALARM SUMMARY:** Displays alarm summary. ▶ See section 4.6.

**MESSAGE SUMMARY:** Displays message summary. ▶ See section 4.7.

**MEMORY SUMMARY:** Displays memory summary. ▶ See section 4.8.

**MODBUS CLIENT:** Displays Modbus client status.

**MODBUS MATER:** Displays Modbus master status.

**RELAY:** Displays relay status.

(To show these items on the menu, see section 5.18.)

**REPORT DATA:** Displays report data.

5. Press **DISP/ENTER**.  
The display appears.

### Displaying the Report

#### Switching the Displayed Report Data

The **Index** item on the report display shows “the number of the report data being displayed/the number of report data saved in the internal memory.” The largest report data number corresponds to the most recent report data.

#### Number of the report data being displayed

#### Number of report data saved to the internal memory

Channel	Unit	Sts	Ave	Max	Min	Sum
TI-101	°C	----	114.5	259.9	-60.0	3.311807E+05
OUT-102	V	----	0.066	0.727	-0.727	1.904148E+02
FI-103	m3/h	----	205.1	416.6	33.3	7.668395E+05
VA-204	%	----	52.4	76.7	23.3	1.516377E+05
TI-205	°C	----	414.5	559.9	240.0	1.199082E+06
PI-206	MPa	----	102.90	131.90	68.00	2.976761E+05
AC-307	%	----	9.75	16.36	1.01	2.019564E+04
PUMP-308	V	----	183.13	196.35	167.26	5.297996E+05
HA-409	%	----	57.6	61.7	52.6	1.665101E+05
HA-410	%	----	43.3	47.4	38.3	1.251785E+05

## 4.5 Displaying Various Information

Carry out the procedure below to switch the displayed report data.

- Up arrow key:** Report data being displayed + 1.
- Down arrow key:** Report data being displayed – 1.
- Left arrow key:** Report data being displayed + 10.
- Right arrow key:** Report data being displayed – 10.

### Note

The display is not updated even if a new report is created while displaying the report data. Perform either of the operations below to display the most recent report data.

- Hold down the left arrow key until the latest report data is displayed.
- Press DISP/ENTER and display the report data again from the display selection menu.

### Switching the Report Channels

Up to 30 report channels can be shown on one screen. If there are more than 30 report channels, you can switch the displayed report channels.

1. Press **DISP/ENTER** to show the display selection menu.
2. Press the **right arrow key** to display the sub menu.
3. Press the **up and down arrow keys** to select **CHANGE REPORT CH.**
4. Press **DISP/ENTER**.  
The displayed report channels are switched.

### Relay Status Display

Lists the statuses of the alarm output relays and internal switches. You cannot change the settings on this display.

RELAY STATUS			
2005/10/28 18:32:16			
DISP 3min			
■ I01	■ I21	■ S01	■ S16
■ I02	■ I22	■ S02	■ S17
■ I03	■ I23	■ S03	■ S18
■ I04	■ I24	■ S04	■ S19
■ I05	■ I25	■ S05	■ S20
■ I06	■ I26	■ S06	■ S21
		■ S07	■ S22
		■ S08	■ S23
		■ S09	■ S24
■ I11	■ I31	■ S10	■ S25
■ I12	■ I32	■ S11	■ S26
■ I13	■ I33	■ S12	■ S27
■ I14	■ I34	■ S13	■ S28
■ I15	■ I35	■ S14	■ S29
■ I16	■ I36	■ S15	■ S30

Red: ON  
Green: OFF

### Modbus Status Display

Lists the statuses of the Modbus client or Modbus master commands.

For the operating procedure, see the *Communication Interface User's Manual (IM04L41B01-17E)*.

MODBUS CLIENT						
2005/10/28 18:32:37						
DISP 3min						
Read cycle : 1s						
Connect.retry : 10min						
No.	Status	Comm. Data	First	Last	Server name	Registers
1	READ	Good	201	- 201	10.0.233.90	30001
2	READ	Good	202	- 202	10.0.233.90	30002
3	READ	Good	203	- 203	10.0.233.90	30003
4						
5						
6						
7						
8						
9						
10						
11						
12						
13						
14						
15						
16						

Communication conditions

Communication destination  
DX channels  
Status  
Command

## 4.6 Using the Alarm Summary

This section explains how to use the alarm summary.  
For a description of the function, see section 1.3.

### Procedure

- **Changing the Displayed Contents**
  1. Press **DISP/ENTER** to show the display selection menu.
  2. Press the **right arrow key** to display the sub menu.
  3. Press the **up and down arrow keys** to select the sub menu item.

Channel	Type	Alarm Time
TI-101	1H	2005/10/01 09:22:19
PI-206	1H	2005/10/01 09:21:38
AC-307	1L	2005/10/01 09:21:32
AC-307	2L	2005/10/01 09:21:15
TI-101		2005/10/01 09:19:41

Sort symbol  
▲ Ascending sort  
▼ Descending sort

**Display name:** Switches to the specified display

**TO HISTORY(DISP):** Switches to the historical trend display


**TO OVERVIEW:** Switches to the overview display

**CHANGE SORT KEY:** Sort the alarm information by channel or alarm time

**ASCENDING ORDER:** Sort in ascending order  
**DESCENDING ORDER:** Sort in descending order

4. Press **DISP/ENTER** to change the displayed contents.  
To close the menu without changing the displayed contents, press the **ESC** key.

- **Moving the Cursor (→) and Scrolling the Alarms**



- **Recalling the Historical Trend Display at the Point When the Alarm Occurred**

1. Select an alarm with the cursor.
2. Display the historical trend according to the procedure described in "Changing the Displayed Contents."

### Explanation

- **CHANGE SORT KEY, ASCENDING ORDER, and DESCENDING ORDER**  
The alarms are sorted in ascending or descending order by the following keys. The sort symbol is displayed next the sort item (see the figure above).
  - Channel number: Sorts the alarms by channel number even if tags are being used. Alarms in a channel are sorted by the alarm number.
  - Time of alarm occurrence/release

## 4.7 Using the Message Summary

This section explains how to use the message summary.  
For a description of the function, see section 1.3.

### Procedure

- **Changing the Displayed Contents**

1. Press **DISP/ENTER** to show the display selection menu.
2. Press the **right arrow key** to display the sub menu.
3. Press the **up and down arrow keys** to select the sub menu item.

**Sort symbol**  
▲ Ascending sort  
▼ Descending sort

**Display name:** Switches to the specified display

**TO HISTORY(DISP):** Switches to the historical trend display


**CHANGE SORT KEY:** Sort the messages by channel, time, group, or user name

**ASCENDING ORDER:** Sort in ascending order  
**DESCENDING ORDER:** Sort in descending order

**CHANGE DISP ITEM:** Switches between "time and group" and "user name"

4. Press **DISP/ENTER** to change the displayed contents.  
To close the menu without changing the displayed contents, press the **ESC** key.

- **Moving the Cursor (➡) and Scrolling the Messages**



- **Recalling the Historical Trend Display at the Point When the Message Was Written**

1. Select a message with the cursor.
2. Display the historical trend according to the procedure described in "Changing the Displayed Contents."

### Explanation

- **CHANGE DISP ITEM**

Switches between the following two message display methods.

- Message, time, and group
- Message, user name

- **CHANGE SORT KEY, ASCENDING ORDER, and DESCENDING ORDER**

The messages are sorted in ascending or descending order by the respective key.  
The sort symbol is displayed next to the sort item (see the figure above).



## 4.8 Using the Memory Summary

This section explains how to use the memory summary.  
For a description of the function, see section 1.3.

### Procedure

- **Changing the Displayed Contents**

1. Press **DISP/ENTER** to show the display selection menu.
2. Press the **right arrow key** to display the sub menu.
3. Press the **up and down arrow keys** to select the sub menu item.

The screenshot shows the MEMORY SUMMARY menu with the following options and annotations:

- ESC**: (001/400) : 2005/12/03 12:56:21  
(015/100) : 2005/12/03 12:45:10
- TREND**:  DISPLAY DATA  EVENT DATA
- TREND HISTORY**: Start Time End Time Data Factor
- DIGITAL**: /03 13:04:18 2005  
/03 12:44:54 2005  
/03 12:44:02 2005
- ALARM SUMMARY**
- MESSAGE SUMMARY**
- MEMORY SUMMARY**
- MODBUS CLIENT**
- RELAY**
- REPORT DATA**
- TO HISTORY**
- SELECT SAVE**
- M.SAMPLE SAVE**
- REPORT SAVE**
- ALL SAVE**
- CHANGE DATA KIND**
- FILENAME DISPLAY**

The displayed data type is indicated with a green mark.

**Display name:** Switches to the specified display

**TO HISTORY:** Switches to the historical trend display.

**SELECT SAVE:** Saves a selected file.

**M.SAMPLE SAVE:** Saves all manual sampled data.

**REPORT SAVE:** Saves all report data.  
(To show these items on the menu, see section 5.18.)

**ALL SAVE:** Saves all data.


**CHANGE DATA KIND:** Switch between display data and event data.

**FILENAME DISPLAY:** Displays the file name.  
For a description of file names, see section 1.4.

**TIME DISPLAY:** Displays the times of the first and last data in the file.

4. Press **DISP/ENTER** to change the displayed contents.  
To close the menu without changing the displayed contents, press the **ESC** key.

- **Moving the Cursor (→) and Scrolling the Memory Information**



- **Displaying the Historical Trend for the Data Specified by Memory Summary**

1. Select the data with the cursor.
2. Display the historical trend according to the procedure described in "Changing the Displayed Contents."


## 4.8 Using the Memory Summary

- **Saving the Data**

Save the data in the internal memory to the CF card or the USB flash memory (/USB1 option).

For a description of the function, see section 1.4.

1. To save by selecting the file, select the desired data file with the cursor. This operation is not necessary for other cases.



2. Press **DISP/ENTER** to show the display selection menu.
3. Press the **right arrow key** to display the sub menu.
4. Select the sub menu item using the **up and down arrow keys**.  
Sub menu items are **SELECT SAVE**, **M.SAMPLE SAVE**, **REPORT SAVE** (/M1 and /PM1 options), and **ALL SAVE**.
5. Press **DISP/ENTER**.  
\* If you are using a CF card and a USB flash memory (/USB1 option), the message "Which media do you want save to?" appears. Select the destination medium using the **arrow keys**, and press **DISP/ENTER**.  
The measured data is saved.

### Note


To abort the data saving operation in progress, carry out the procedure below.

Press **FUNC** and press the **Save Stop** soft key.

### Progress Display When Saving All Data of the Internal Memory (Release Number 2 or Later)

If you carry out All Save\* on the memory summary screen, a pop-up window appears showing the progress of the save operation.

\* Function for saving all data in the internal memory to a CF card or USB flash memory.



**Note**

- The pop-up window appears only when the memory summary display is showing.
- If you press the ESC key, the pop-up window clears temporarily and reappears approximately 10 seconds later.
- The time estimate for saving all data is indicated in the table below (when the memory is full of data). It may take longer depending on the operating conditions of the DX.

Save Destination	Time to Save All Data (Estimate)	
	CF Card	USB Flash Memory
Standard memory (internal memory size suffix code -1)	4 minutes	5 minutes (16 minutes)*
Large memory (internal memory size suffix code -2)	10 minutes	15 minutes (40 minutes)*


\* Values for the DXs with firmware version 2.02 or later. Values inside the parentheses are for the DXs with firmware version 2.01 or earlier.

- To abort the data saving operation in progress, carry out the procedure below. Press **FUNC** and press the **Save Stop** soft key.

**Explanation**

- **Save directory**

- The data is saved by creating a directory each time the save operation is carried out. Directory name: Specified string\_YYMMDD\_HHMMSS (where YY to SS is the date of operation)



- Display data or event data that is in the process of adding data cannot be saved.
- The save operation explained here merely copies the data in the internal memory. It does not save the unsaved data in the internal memory (see section 1.4).
- Data saving is aborted when there is insufficient free space on the storage medium. Use a storage medium with sufficient free space when saving data.

## 4.9 Displaying a List of Operation Logs

Displays the following operation logs.

Login log, error log, communication log, FTP log, Web log, e-mail log, SNTP log, DHCP log, and Modbus status log

### Procedure

#### • Displaying the Log

1. Press **DISP/ENTER** to show the display selection menu.
2. Press the **up and down arrow keys** to select **LOG**.
  - \* To show **LOG** on the menu, see section 5.18.
3. Press the **right arrow key** to display the sub menu.
4. Press the **up and down arrow keys** to select the sub menu item.  
To close the menu without changing the displayed contents, press the **ESC** key.  
Sub menu items are **LOGIN, ERROR, COMMUNICATION, FTP, MAIL, WEB, SNTP, DHCP, and MODBUS**.
5. Press **DISP/ENTER**.  
The display appears.

### Explanation

#### • Login Log

The log number of the last line and the total number of logs

Time	Action	Factor	Username
2005/10/27 17:12:08	NewTime	KEY	
2005/10/27 13:28:49	NewTime	KEY	
2005/10/27 13:28:52	TimeChg	KEY	
2005/10/27 13:28:48	NewTime	KEY	
2005/01/01 00:47:04	TimeChg	KEY	


User name  
Operation method (see the table below)  
Operation (see the table below)  
Date/time

Action	Description
Login	Login
Logout	Logout
NewTime	Time change while memory is stopped
TimeChg	Time change through key operation
PowerOff	Power OFF (power failure occurred)
PowerOn	Power ON (recovered from a power failure)
TrevStart	Start the operation of gradually adjusting the time
TRevEnd	End the operation of gradually adjusting the time
TimeDST	Switch the daylight savings time
SNTPtimset	Time change by SNTP

Factor	Description
KEY	Key operation
COM	Operations via communication
REM	Operation through the remote control function
ACT	Operation through event action
SYS	Operation by the system

• **Error Log**


Time	No.	Message
2005/10/27 16:00:00	290	SNTP access failure.
2005/10/27 14:36:38	232	There is no available data.
2005/10/27 14:36:18	232	There is no available data.
2005/10/27 14:36:15	232	There is no available data.
2005/10/27 13:48:09	601	Measured data have been initialized.



\* See section 11.1, "A List of Messages."

• **Communication Log**


Time	ID	Username	I/O	Message	Link
2005/10/07 15:10:12	1	Admin1	<	(18050 byte)	
2005/10/07 15:10:12	1	Admin1	>	SA?	
2005/10/07 15:09:39	1	Admin1	<	(58 byte)	
2005/10/07 15:09:39	1	Admin1	>	sr001?	



\* See the *Communication Interface User's Manual (IM04L41B01-17E)*.

• **FTP Log**


Time	No.	Code	Flag	Filename
2005/10/27 17:51:33			P	051027_1730000.DAD
2005/10/27 17:29:03			P	051027_1722500.DAD
2005/10/27 17:21:01			P	FTP_TEST.TXT
2005/10/07 11:36:02	282	HOSTNAME	P	051006_1509400.DAD



\* See section 11.1, "A List of Messages."

• **Web Log**

Time	Request	No.	Parameter
2005/10/27 17:31:19	Key		DISP/ENTER
2005/10/27 17:31:15	Key		DOWN
2005/10/27 17:31:13	Key		RIGHT
2005/10/27 17:30:59	Key		DISP/ENTER
2005/10/27 17:30:48	Screen		TREND GROUP=1



\* See section 11.1, "A List of Messages."


Request	Description
Screen	Screen switch
Key	Key operation
Message	Message assignment/write

## 4.9 Displaying a List of Operation Logs

Parameter	Description
TREND	Trend display
DIGIT	Digital display
BAR	Bar graph display
HIST	Historical trend display
OV	Overview display
DISP	DISP/ENTER key
UP	Up arrow key
DOWN	Down arrow key
LEFT	Left arrow key
RIGHT	Right arrow key
FAVOR	Favorite Key
Messages	Character strings that are written.

### • E-mail Log

(005/005) Time	Type	No.	Recipient / Error
2005/10/27 17:23:49	Test	266	1 Ethernet cable is not connected.
2005/10/27 17:22:39	Alarm	1	1 Haruo.Saitou
2005/10/27 17:22:18	Alarm	1	1 Haruo.Saitou
2005/10/27 17:21:54	Alarm	1	1 Haruo.Saitou




\* See section 11.1, "A List of Messages."

Type	Description
Alarm	Alarm mail
Time	Scheduled mail
Report	Report timeout mail
Fail	Power failure recovery mail
Full	Memory full mail
Test	Test mail
Error	Error message mail

### • SNMP Log


(002/002) Time	No.	Code
2005/10/27 17:22:08		SUCCESS
2005/10/27 16:00:00	290	LINK



\* See section 11.1, "A List of Messages."

• DHCP Log


DHCP LOG		
2005/10/27 17:54:36	DISP	1h:59min
(017/017) Time	No.	Code
2005/10/27 17:54:29	566	NOREQUEST
2005/10/27 17:54:29	565	IPCONFIG
2005/10/27 17:54:29	564	RENEWED
2005/10/27 17:54:29	565	IPCONFIG



\* See section 11.1, "A List of Messages."

• Modbus Status Log

MODBUS LOG				
2005/10/27 17:52:58	DISP	1h:59min		
(020/102) Time	Kind	Factor	Command	
2005/10/27 17:52:05	C	GOOD	02	R
2005/10/27 17:52:05	C	GOOD	01	R
2005/10/27 17:52:04	C	GOOD	02	R
2005/10/27 17:52:04	C	GOOD	01	R



\* See the *Communication Interface User's Manual (IM04L41B01-17E)*.

## 4.10 Showing the Four Panel Display

This section explains how to use the four panel display.  
For a description of the function, see section 1.3.

### Procedure

- **Showing the Display**

1. Press **DISP/ENTER** to show the display selection menu.
2. Press the **arrow keys** to select **4 PANEL**. Then, select the desired four panel name, and press **DISP/ENTER**.  
The display appears.

- **Switching the Display**

Press the **right arrow key** to change the display in the order “four panel 1,” “four panel 2,” “four panel 3,” “four panel 4,” “four panel 1,” and so on. Press the **left arrow key** to switch the display in reverse order.


- **Changing the Displays Assigned to the Four Panel Display**

Carry out the procedure below on the four panel display.

1. Press **DISP/ENTER**.

The title bar of one of the four panels turns dark blue.

2. Select the panel you wish to change the display using the **arrow keys** (the panel of which the title bar is dark blue is the selected panel).



The title section of the selected quadrant displayed in dark blue.


3. Press **DISP/ENTER** to show the display selection menu.
  4. Press the **arrow keys** to select the display to be assigned.
  5. Press **DISP/ENTER** to assign the specified display to the selected panel.  
To close the menu without assigning the display, press **ESC**.
- **Registering the Four Panel Display with a New Combination of Screens**  
Operate as described in “Changing the Name of the Four Panel Display” on next page.  
\* If you switch to other screens and return to the four panel display without registering the display, the new combination of four panels returns to the original.



• Expanding One the Panels to Full Screen

1. Press **DISP/ENTER**.  
The title bar of one of the panels turns dark blue.
2. Select the panel you wish to expand using the **arrow keys** (the panel of which the title bar is dark blue is the selected panel).
3. Press **DISP/ENTER** to show the display selection menu.
4. Press the **right arrow key** to show the sub menu.
5. Press the **up and down arrow keys** to select **EXPAND**.

\* To show **EXPAND** on the screen menu, see section 5.18.



This **EXPAND** is not shown under the initial conditions. To show, operate as follows:  
Press **MENU** and select **Menu customize > Display menu**. Set **EXPAND** on the display menu to **View**.  
For the operating procedure, see section 5.18.


6. Press **DISP/ENTER** to expand the specified panel.  
To close the menu without expanding the screen, press **ESC**.

• Changing the Name of the Four Panel Display

If you change the name of a four panel display, the specified name appears in the display menu.

Carry out the following procedure when the four panel display is shown.

1. Press **FUNC** to display the **FUNC** key menu.
2. Press the **4Panel** soft key to display a list of four panel names.




3. Press any of the **4Panel 1** to **4panel 4** soft keys to display a window used to enter the display name.
4. Enter the display name (up to 16 characters, **[A]a#[1]**)
5. Press **DISP/ENTER** to activate the specified display name and return to the four panel display.  
To cancel the change, press **ESC**.

# 5.1 Setting Display Groups

Assign channels and set the group name for each display group. Set lines at specified positions in the waveform display range on the Trend display.

**Setup Screen**

Press **MENU** (switch to the setting mode) and select **Group set, Trip line**



**Setup Items**

- **Group number**  
Select the target group number (1 to 36).
- **Group set**
  - **On/Off**  
Turn **On** the groups you want to use.
  - **Group name**  
Set the group name. (up to 16 characters, **Aa#1**)
  - **CH set**  
Set up to 10 channels from measurement channels, computation channels (/M1 and /PM1 options), and external input channels (/MC1 option).
    - Enter the channel number using two or three digits.
    - Separate each channel with a period.
    - To specify a range of consecutive channels numbers, use a hyphen.  
Example: To assign channels 1 and 5 to 8, enter "001.005-008."


**Note**

- The trend, digital, and bar graph displays are shown in the specified order.
- A channel can be assigned to multiple groups.
- The same channel cannot be assigned multiple times in a group.

## 5.1 Setting Display Groups

### Note

The channel settings of a display group can be copied to another group on a DX with release number 2 or later.



### Procedure

1. Select the copy source channel settings.
2. Press the **Copy** soft key.
3. Select the copy destination channel settings.
4. Press the **Paste** soft key. The channel settings are copied.

- **Trip line**

Set lines at specified positions in the waveform display range on the Trend display.

- **On/Off**

Turn **On** the trip lines you want to display.

- **Position**

Set the position in the range of 0 to 100% of the display width.

- **Color**

The default colors are red, green, blue, and yellow. If you want to change the color, select from the 24 available colors.

- **Line width**

Set the line width of the trip line in dots (1 to 3).


## 5.2 Displaying Tags or Channel Numbers

Display the channels using tags or channel numbers.

### Setup Screen


- **Tag/Channel**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > Operating Environment**



- **Tag**

Press **MENU** (switch to the setting mode) and select **Meas Channel > Tag, Memory sample, Alarm delay**



### Setup Items

- **Operating environment > Tag/Channel**

Settings	Description
Tag	Displays tags. Channel numbers are displayed for channels that do not have tags assigned.
Channel	Displays channel numbers.

- **First-CH/Last-CH**

Set the target channels. The target channels are common with the other items that are displayed on the screen.

- **Tag > Tag**

Set the tag. (up to 16 characters, **Aa#1**)

## 5.3 Setting the Trend Interval and Switching to the Secondary Trend Interval


Set the trend interval. Switch the trend interval to the secondary trend interval while the memory sampling is in progress. Automatically write messages when the trend interval is switched.

For a description of the function, see section 1.3.

### Setup Screen


- **Switching the Trend Interval and Writing Messages (When Using the Secondary Trend Interval)**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > View, Message, Input, Alarm**



- **Trend interval [/div] and Secondary interval [/div]**

Press **MENU** (switch to the setting mode) and select **Display > Trend/Save interval**



### Setup Items

- **View > Trend rate switching**

On: Enables the function that switches the trend interval while the memory sampling is in progress. The “Second interval [/div]” item is displayed in the setting mode.

\* When the trend rate switching function is **On**, the DX cannot be configured to record both the display and event data (see section 6.1).

- **Message > Change message**

On: Writes the time the interval is switched and the new trend interval as a message when the trend interval is switched.

### 5.3 Setting the Trend Interval and Switching to the Secondary Trend Interval

- **Trend interval [div] and Second interval [div]**


Select the time corresponding to 1 division of the time axis on the trend display from below: You cannot specify a trend interval that is faster than the scan interval.

15s\*, 30s, 1min, 2min, 5min, 10min, 15min, 20min, 30min, 1h, 2h, 4h, and 10h

\* Can be set on the DX2004 and DX2008.

#### **Note**

If the trend interval is set greater than or equal to 1h/div on a DX with release number 2 or later, the month, day, and hour at the grid position are displayed on the screen. The display format can be changed by setting the date format.



#### **Procedure**

- **Switching the Trend Interval**

1. In the operation mode, press **FUNC**.  
The FUNC key menu appears.
2. Press the **Normal speed** soft key or **Second speed** soft key.  
The trend interval is switched. A message is written on the trend display (when the change message is turned ON).  
Display example: 10:53 1min/div

## 5.4 Writing Messages

Write messages.

### Setup Screen

- **Message Write Group**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > View, Message, Input, Alarm**

- **Setting the Messages**

Press **MENU** (switch to the setting mode) and select **Message**

### Setup Items

- **Message**

- **Write group**

This setting applies only for messages that are written using keys.

Settings	Description
Common	Write the message to all groups.
Separate	Write the message to the displayed group.

- **Power-fail message**

See section 5.17.

- **Change message**

See section 5.3.

- **Message No.**

Select the message number (1 to 100). Messages 1 to 10 are common with free messages.\* If a message is changed as a free message, the old message is overwritten.

\* Messages that are written by creating the message on the spot.

- **Message > Characters**

Set the message. (up to 32 characters, **Aa#1**)

## Procedure

- **Writing Messages**

Messages cannot be written when the memory sampling is stopped.

1. Display the group to write the message.

- If a screen unrelated to a group such as the overview is displayed, messages are written to all groups even when **Write group** is set to **Separate**. For the four panel display, messages are written to the displayed groups.
- Messages are written to all groups regardless of the displayed screen when **Write group** is set to **Common**.


2. Press **FUNC**.

The FUNC key menu appears.

3. Press the **Message** soft key.


4. Press the soft key corresponding to the desired message number range (example: [1-10]).

A list of message is displayed.



5. Press the soft key corresponding to the number of the message you want to write.

A message mark, time, and message are shown on the trend display.





## 5.4 Writing Messages

- **Writing Free Messages**

Create a message on the spot and write it.

1. Display the group to write the message.
2. Press **FUNC**.  
The FUNC key menu appears.
3. Press the **Free message** soft key.
4. Press a message number soft key.  
The message entry window appears.
5. Enter the message. (up to 32 characters, **[Ala#1]**)
6. Press **DISP/ENTER**.

A message mark, time, and message are shown on the trend display.


- **Writing Add Messages**

Add messages to the past data positions. This operation can be carried out on the past section of the data that is currently being memory sampled.

1. Carry out the procedure below to show the historical trend of the data that is currently being memory sampled.

**Press DISP/ENTER and select TREND HISTORY > (group name) > DISP/ENTER**

2. Press the arrow keys to move the cursor to the position you want to write the message.
3. Write the message according to the procedure given in “Writing Messages” or “Writing Free Messages.” Use the **Add Message** or **Add Free Message** soft key.



Add message

Cursor (yellow line)

### Explanation

- **Display Color of Messages**

The message colors on the trend display are shown below. You cannot change them.

No.	1	2	3	4	5	6	7	8	9	10
Color	Red	Green	Blue	Blue violet	Brown	Orange	Yellow-green	Light blue	Violet	Gray

The colors for messages 11 to 100 are repetitions of the colors above.

- **Add Message**

- The message timestamp is the time that the message is written. It is not the time stamp of the data at the position where the message is written.

Message	Time	Group
→ HOLD	2005/10/27 13:44:56	All

Display example on the message summary

Add message (displayed in blue)


- Up to 50 messages can be written.
- Messages cannot be added to data in the internal memory that has already been saved to a file or data that has been loaded from the external storage medium.

## 5.5 Changing the Channel Display Colors

Change the channel display colors. The settings are applied to the trend and bar graph displays.

### Setup Screen

Press **MENU** (switch to the setting mode) and select **Meas Channel > Color**



### Setup Items


- **Group of channel**  
Select the target channels.
- **Color**  
To change the color, select from the following 24 colors.  
Red, green, blue, blue violet, brown, orange, yellow-green, light blue, violet, gray, lime, cyan, dark blue, yellow, light gray, purple, black, pink, light brown, light green, dark gray, olive, dark cyan, and spring green

## 5.6 Displaying Channels in Display Zones

Specify a waveform display zone for each channel so that waveforms do not overlap.  
For a description of the function, see section 1.3.

### Setup Screen

Press **MENU** (switch to the setting mode) and select **Meas Channel > Zone, Scale, Bar graph**



### Setup Items

- **First-CH/Last-CH**  
Select the target channels. The target channels are common with the other items that are displayed on the screen.
- **Zone > Lower, Zone > Upper**  
Sets the zone in which the waveform is displayed. You can set **Lower** and **Upper** as a position (%) when taking the maximum display width to be 100%. Set **Upper** greater than **Lower**, and the zone width (**Upper – Lower**) greater than or equal to 5%.  
Lower: 0 to 95%  
Upper: 5 to 100%

## 5.7 Displaying a Scale on the Trend Display


Display a scale on the trend display.

For a description of the function, see section 1.3.

### Setup Screen


- **Scale Position and Number of Scale Divisions**

Press **MENU** (switch to the setting mode) and select **Meas Channel > Zone, Scale, Bar graph**



- **Number of Displayed Scale Digits and Current Value Indicator**

Press **MENU** (switch to the setting mode) and select **Display > Trend, Bar graph, LCD, Monitor**



- **Showing the Scales**

To show scales on the trend display, press **DISP/ENTER** (show the display selection menu) > the **right arrow key** (show the sub menu), and select **SCALE ON** (see section 4.2).

### Setup Items

- **First-CH/Last-CH**

Select the target channels. The target channels are common with the other items that are displayed on the screen.

- **Scale > Position**

Select the scale display position on the trend display from 1 to 10. Select **Off** if you do not wish to display the scale.


## 5.7 Displaying a Scale on the Trend Display

- **Scale > Division**


Select the number of main scale marks on the trend display from **4 to 12** and **C10**.  
 C10: The scale is equally divided into 10 sections by main scale marks, and scale values are indicated at 0, 30, 50, 70, and 100% positions on the trend display.

The figure below is an example in which each scale is displayed with the position shifted.

### Horizontal Trend Display



### Vertical Trend Display




**Note**

- If the scales of multiple channels are set to the same position, the scale of the channel assigned first to the group is displayed.  
Example: If the order of assignment of a group is **003.002.001**, and the scale display position of all channels is set to **1**, the scale of channel 3 is displayed at display position 1.
- Even if some of the scale display positions are skipped, the scale is packed towards display position 1.  
Example: Suppose the assignment of channels to a group is **001.002.003**, and the display positions of the scales are set to 1, 3, and 6, respectively. The scales are actually displayed at positions 1, 2, and 3, respectively.
- The scale is divided into 4 to 12 sections by the main scale marks. The section between the main scale marks is divided into 10 subsections by medium and small scale marks. However, small scale marks are not displayed in the following cases.
  - When the resolution of the input range is smaller than the total number of small scale marks.
  - When zone display is used.
  - When partial expanded display is used.
- The scale values are displayed according to the following rules.
  - If the number of scale divisions is 4 to 7 for the vertical trend display, values are displayed at all main scale marks. If the number of scale divisions is greater, the values are displayed at every other main scale marks.
  - Scale upper and lower limits are displayed at the ends of the scale.
  - Scale values are displayed up to 3 digits excluding the minus sign. However, if the integer part of values at the ends of the scale is both 1 digit or the integer part is zero, 2 digits are displayed.  
Example: If the scale is  $-0.05$  to  $0.50$ , the lower limit is  $-0.0$  and the upper limit is  $0.5$ .
  - If the integer part of either end of the scale is 2 or 3 digits, the fractional part is truncated.  
Example: If the scale is  $0.1$  to  $100.0$ , the lower limit is  $0$  and the upper limit is  $100$ .
  - If the integer part of either end of the scale is 4 or more digits, the value is displayed using a 3-digit mantissa and exponent like  $\times 10$  or  $\times 10^2$ .  
Example: If the scale is  $10$  to  $2000$ , the lower limit is  $1$  and the upper limit is  $200 \times 10$ .
- The unit is displayed near the center of the scale. If partial expanded display is used, the display position is offset from the center. For the vertical trend display, the number of characters that can be displayed is up to six. For the horizontal trend display, the number of characters that can be displayed is up to four.

- **Trend > Scale > Digit**


Fine: If the scale value is two-digit display, it can be changed to three digits. For example, if the scale range is  $49.0$  to  $51.0$ , the scale values are displayed using 3 digits as shown below.



## 5.7 Displaying a Scale on the Trend Display

- Trend > Scale > Value indicator

The current value is displayed as a mark or a bar graph.




## 5.8 Displaying Alarm Point Marks and Color Scale Band on the Scale


Display alarm point marks on the scale. Display the specified range with a color band. For a description of the function, see section 1.3.

### Setup Screen

Press **MENU** (switch to the setting mode) and select **Meas Channel > Alarm mark, Color scale band**



### Setup Items



- **First-CH/Last-CH**  
Select the target channels. The target channels are common with the other items that are displayed on the screen.
- **Alarm Mark Indication**  
Displays marks indicating the values of the high and low limit alarms, delay high and low limit alarms, and difference high and low limit alarms. This setting is common with the bar graph display.
  - **Alarm mark > Mark kind**

Settings	Description	Mark
Alarm	Indicates green under normal conditions and red when an alarm is activated.	▲ or ▼
Fixed	Displays a fixed color.	◀

  - **Alarm mark > Indicate on Scale**  
To display alarm point marks, select **On**.
  - **Alarm mark > Alarm mark color > Alarm 1, Alarm 2, Alarm 3, and Alarm 4**  
If the **Mark kind** is set to **Fixed**, specify the color of the alarm point marks.



## 5.8 Displaying Alarm Point Marks and Color Scale Band on the Scale

---

- **Color Scale Band**

Displays a specified section of the measurement range using a color band on the scale. This setting is common with the bar graph display.

- **Color scale band > Band area**

Settings	Description
In	Displays the area inside using the color band.
Out	Displays the area outside using the color band.
Off	Disables the function.

- **Color scale band > Color**

Set the display color.

- **Color scale band > Display position > Lower and Upper**

Specify the display position. Set a value within the span or scale range.

Lower: Lower limit of the area.

Upper: Upper limit of the area.


## 5.9 Partially Expanding the Waveform

Partially expand a waveform (reduce the other sections) on the display.  
For a description of the function, see section 1.3.

### Setup Screen

- **Turning ON/OFF the Partial Expanded Display Function**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > View, Message, Input, Alarm**



- **Partially Expanded Display Method**

Press **MENU** (switch to the setting mode) and select **Meas Channel > Partial**



### Setup Items

- **View > Partial**

If you select **On**, the **Partial** setup item appears in the setting mode.

- **First-CH/Last-CH**

Select the target channels.

- **Partial > On/Off**

To enable partial expanded display, select **On**.

- **Partial > Expand**

Set the position where the value specified by **Boundary** is to be displayed within the display span in the range of 1 to 99.

## 5.9 Partially Expanding the Waveform

---

- **Partial > Boundary**

Set the value that is to be the boundary between the reduced section and the expanded section in the range of “minimum span value + 1 digit to maximum span value – 1 digit.” For channels that are set to scaling, the selectable range is “minimum scale value + 1 digit to maximum scale value – 1 digit.”

Example: Input range: –6 V to 6V. Expand: 30. Boundary: 0

The –6 V to 0 V range is displayed in the 0% to 30% range, and the 0 V to 6 V range is displayed in the 30% to 100% range.


## 5.10 Changing the Display Layout, Clearing of the Waveform at Start, Message Display Direction, Waveform Line Width, and Grid

Change the display layout, clearing of the waveform at start, waveform line width, and grid.

For a description of the function, see section 1.3.

### Setup Screen

Press **MENU** (switch to the setting mode) and select **Display > Trend, Bar graph, LCD, Monitor**



### Setup Items

- **Trend > Direction**

Set the display direction of the trends to **Horizontal**, **Vertical**, **Wide**, or **Split**.

- **Trend > Trend clear**

Settings	Description
On	Clears the displayed waveform when the memory sampling is started.
Off	Does not clear the waveform when the memory sampling is started.

- **Trend > Message direction**

Set the display direction of messages to **Horizontal** or **Vertical**. When the trend is set to **Vertical**, the message direction is fixed to **Horizontal**.

- **Trend > Trend line**

Set the line width of the trend in dots (1 to 3).

- **Trend > Grid**

Select the number of grids to be displayed in the waveform display area of the trend display.

Settings	Description
4 to 12	Displays a grid that divides the display width into 4 to 12 sections.
Auto	Displays the same number of grids as the number of scale divisions of the first assigned channel of the group.

## 5.11 Changing the Bar Graph Display Method

Change the bar graph display method.

For a description of the function, see section 1.3.

### Setup Screen

- **Display Direction**

Press **MENU** (switch to the setting mode) and select **Display > Trend, Bar graph, LCD, Monitor**

Trend	
Direction	Horizontal
Trend clear	Off
Message direction	Horizontal
Scale	
Digit	Normal
Value indicator	Mark
Trend line	2 dot
Grid	Auto div

Bar graph	
Direction	Vertical

LCD	
Brightness	2
Backlight saver	Off
Mode	Off

Monitor	
Background	White
Display	Black
Historical trend	10s
Scroll time	10s
Jump default display	Off

- **Base Position and the Number of Scale Divisions**

Press **MENU** (switch to the setting mode) and select **Meas Channel > Zone, Scale, Bar graph**

Zone	
Lower	0 %
Upper	100 %

Scale	
Position	1
Division	10

Bar graph	
Base position	Normal
Division	10

### Setup Items

- **Bar graph > Direction**

Set the display direction of bar graphs to **Horizontal** or **Vertical**.

- **First-CH/Last-CH**

Set the target channels. The target channels are common with the other items that are displayed on the screen.

- **Bar graph > Base position**


Set the base position of bar graphs to **Normal**, **Center**, **Lower**,\* or **Upper**.\*

The setting is applied when displaying the bar graph and when displaying the current value on the scale using the bar graph.


\* You can select Lower and Upper on DXs with release number 2 or later.

**When the Display Direction of the Bar Graph Is Vertical**

- Normal  
 Value at the bottom of the bar graph: Span lower limit or span upper limit (or scale lower limit or scale upper limit), whichever is less  
 Value at the top of the bar graph: Span lower limit or span upper limit (or scale lower limit or scale upper limit), whichever is greater  
 Starting point of the bar: Bottom edge
- Center  
 Value at the bottom of the bar graph: Same as with Normal.  
 Value at the top of the bar graph: Same as with Normal.  
 Starting point of the bar: Center
- Lower  
 Value at the bottom of the bar graph: Span lower limit (or scale lower limit)  
 Value at the top of the bar graph: Span upper limit (or scale upper limit)  
 Starting point of the bar: Bottom edge
- Upper  
 Value at the bottom of the bar graph: Same as with Lower.  
 Value at the top of the bar graph: Same as with Lower.  
 Starting point of the bar: Top edge



Vupper: Span upper limit (or scale upper limit)  
 Vlower: Span lower limit (or scale lower limit)  
 VL: Vlower or Vupper, whichever is greater  
 VS: Vlower or Vupper, whichever is less  
 ←: Starting point of the bar




5.11 Changing the Bar Graph Display Method

**When the Display Direction of the Bar Graph Is Horizontal**

The span lower limit (or scale lower limit) becomes the left edge of the bar graph, and the span upper limit (or scale upper limit) becomes the right edge of the bar graph.

- Starting point of the bar
  - Normal: Left edge or right edge, whichever is less
  - Center: Center
  - Lower: Left edge
  - Upper: Right edge



V<sub>upper</sub>: Span upper limit (or scale upper limit)  
 V<sub>lower</sub>: Span lower limit (or scale lower limit)  
 ▲: Starting point of the bar

Example: When the span lower and upper limits of the input range are 0.0 and -100.0, respectively


Normal:

Center:

Lower:

Upper:

**When Displaying the Current Value on the Scale Using the Bar Graph**



- Bar graph > Division**  
 Select the number of main scale marks from 4 to 12.


## 5.12 Using the Circular Display

Use a circular display in place of the trend display.  
For a description of the function, see section 1.3.

### Setup Screen


- **Circular Display**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > View, Message, Input, Alarm**




- **Time per Revolution**

Press **MENU** (switch to the setting mode) and select **Display > Circular/Save interval**



- **Operation at One Cycle**


Press **MENU** (switch to the setting mode) and select **Display > Circular, Bar graph, LCD, Monitor**





**Setup Items**

- **View > Trend type**  
Select **Circular**.
- **Circular/Save interval > Time per revolution [/rev]**  
Select the time of revolution from **20min\*** to **4week**.  
\* Selectable on DX2004 and DX2008.
- **Circular/Save interval > Save interval (when recording display data)**  
Select the size of a record data file. The recorded data is divided by the file size specified here. The available settings vary in the range of **10min** to **31day** depending on the **Time per revolution** setting.  
\* For the setting procedure to record the event data, see section 6.1.
- **Circular/Save interval > Offset time**  
The time at the reference position on the circle can be offset in unit of an hour. The available settings vary depending on the time of revolution setting. The figure below is an example in which the time per revolution is **6h** and indicates the time positions when the offset time is **Off** and **1h**.



Time per Revolution	Selectable Offset Times
20min, 30min, 1h	–
2h	1h
6h	1h to 5h
8h	1h to 7h
12h	1h to 11h
16h	1h to 15h
1day, 2day, 1week, 2week, 4week	1h to 23h

- **Circular > Full circle action**
- | Settings | Description                                                                                                                                     |
|----------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| Allclear | Clears the entire waveform when one revolution of waveform is recorded and continues the recording of the next revolution.                      |
| Divclear | Clears one division of the old waveform when the remaining amount of waveform to be recorded falls to one division and continues the recording. |


## Procedure

### • Circular Display

1. Press **DISP/ENTER** to show the display selection menu.
2. Select **TREND** using the arrow keys and press **DISP/ENTER**.  
The display appears.

### • Changing the Displayed Contents

1. Press **DISP/ENTER** to show the display selection menu.
2. Press the **right arrow key** to display the sub menu.
3. Select the sub menu item using the **up and down arrow keys**.



**Group name:** Displays the group.

**1/4 CIRCLE:** Displays a quarter of the cycle.

**FULL CIRCLE:** Displays the full cycle.

**SCALE ON:** Displays the scale.

**SCALE OFF:** Clears the scale.

**DIGITAL OFF:** Clears the numeric display section.

**DIGITAL ON:** Displays the numeric display section.


**AUTO SCROLL ON:** Automatically switches the displayed groups.

**AUTO SCROLL OFF:** Does not automatically switch the displayed groups.

4. Press **DISP/ENTER** to change the displayed contents.  
To close the menu without changing the displayed contents, press **ESC**.

### • Displaying the Quarter Cycle Display


Select **1/4 CIRCLE** as described in the “Changing the Displayed Contents.” The most recent quarter cycle is displayed expanded.




## 5.12 Using the Circular Display

- **Simplified Historical Trend**

Press the up arrow key while showing the quarter cycle to show the historical trend of the displayed quarter cycle.



Carry out the procedure below to switch the display in unit of quarter cycle.




- **Historical Trend**

- There are five methods to display the past measured data.
- For a description of the function, see section 1.3.
  - For the procedure to recall from the display selection menu, see below.
  - For the procedure to display from the alarm summary, see section 4.6.
  - For the procedure to display from the message summary, see section 4.7.
  - For the procedure to display from the memory summary, see section 4.8.
  - To show the measured data stored on an external storage medium, see section 6.8.

- **Showing the Display**

Carry out the procedure below while memory sampling is in progress.



1. Press **DISP/ENTER** to show the display selection menu.
2. Select **TREND HISTORY** using the **arrow keys** and press **DISP/ENTER**.  
One screen of data is displayed.



Cursor (yellow line)


• **Changing the Displayed Contents**

1. Press **DISP/ENTER** to show the display selection menu.
2. Press the **right arrow key** to display the sub menu.
3. Select the sub menu item using the **up and down arrow keys**.




4. Press **DISP/ENTER** to change the displayed contents.  
 To close the menu without changing the displayed contents, press **ESC**.

• **Moving the Cursor**



• **Displaying the Continuing Data (Loading Data to the Display Memory)**

Approximately one screen of data is shown on the historical trend display. The continuing data can be shown as follows:




## 5.12 Using the Circular Display

- **Specifying the Display Range**


Select the display range.

1. Press the **up arrow key**.

The waveform of the entire data range is displayed at the top section of the screen. The white frame indicates the data range that is currently displayed. The yellow horizontal line is the cursor.



2. Press the **left and right arrow keys** to move the cursor.



3. Press the **down arrow key**.

The specified range is displayed.

- **Selecting Another File**

To display data from another file, select the file from the memory summary.

- **Message**

On the historical trend, up to eight newest messages that exist before the cursor position can be displayed.

**Explanation**

- **Scale Marks**

The number of scale marks varies depending on the time corresponding to one cycle. Scale marks consist of main scale marks and subscale marks. Main scale marks are used to divide the cycle into sections; subscale marks are used to divide between the main scale marks. The number of divisions created by main scale marks and subscale marks are as follows:

Time/rev	Number of Divisions Created by Main Scale Marks	Number of Divisions Created by Subscale Marks	Time per Scale Mark	Display Update Rate
20min	5	4	1 min	0.5 s
30min	5	4	1 min 30 s	1 s
1h	12	2	2 min 30 s	2 s
2h	12	2	5 min	4 s
6h	12	2	15 min	10 s
8h	8	2	30 min	20 s
12h	12	2	30 min	20 s
16h	8	2	1 h	40 s
1day	12	2	1 h	1 min
2day	12	2	2 h	2 min
1week	7	4	6 h	4 min
2week	7	4	12 h	8 min
4week	4	7	24 h	20 min

- **Event Data**

When displaying event data using the historical trend, the time corresponding to one cycle is automatically determined from the sampling interval (Sample rate) of the event data to be displayed as follows:

Sample rate	Time/rev	Number of Divisions Created by Main Scale Marks	Number of Divisions Created by Subscale Marks
25 ms	1min/rev	6	4
125 ms	5 min/rev	5	4
250 ms	10 min/rev	5	4
500 ms	20 min/rev	5	4
1 s	30 min/rev	5	4
2 s	1 h/rev	12	2
5 s	2 h/rev	12	2
10 s	6 h/rev	12	2
30 s	12 h/rev	12	2
60 s	1 day/rev	12	2
120 s	2 day/rev	12	2
300 s	1 week/rev	7	4
600s	2 week/rev	7	4

## 5.13 Changing the Background Color of the Display

Change the background color of the display. This setting is applied to the operation screens.

### Setup Screen

Press **MENU** (switch to the setting mode) and select **Display > Trend, Bar graph, LCD, Monitor**



### Setup Items


- **Monitor > Background > Display**  
Set the background color of the operation screen to **White** (default setting) or **Black**.
- **Monitor > Background > Historical trend**  
Select the background color of the historical trend display from the following:  
Settings: **White**, **Black** (default setting), **Cream**, and **Lightgray**

## 5.14 Automatically Switching Display Groups

Automatically switch the displayed group at a specified interval.

### Setup Screen

Press **MENU** (switch to the setting mode) and select **Display > Trend, Bar graph, LCD, Monitor**



### Setup Items

- **Monitor > Scroll time**  
Set the switching interval from the available settings between 5 s and 1 min. The groups switch in ascending order.  
Select whether to automatically switch on the operation display.  
See section 4.2




## 5.15 Automatically Reverting to the Specified Display

Show a preset display when there is no operation for a specific time.

### Setup Screen

Press **MENU** (switch to the setting mode) and select **Display > Trend, Bar graph, LCD, Monitor**



### Setup Items

- **Monitor > Jump default display**

Returns to a preset display if there is no key operation for a specific time.

Settings	Description
1min to 1h	Time until switching the display.
Off	Disables the function.


### Procedure

- **Specifying the Display to be Shown**

1. Show the operation display you want to designate.
2. In the operation mode, press **FUNC**.  
The FUNC key menu appears.
3. Press the **Standard display** soft key.  
The display is registered.

## 5.16 Registering the Favorite Display

Register a frequently used display to the Favorite key and enable the display to be shown through simple operation.



### Procedure

- **Registering the Display**

Up to 8 displays can be registered.

1. In the operation mode, show the display you want to register.
2. Press **FUNC**.  
The FUNC key menu appears.
3. Press the **Favorite regist** soft key. Then, press a registration number soft key.
4. Press the **Regist** soft key.  
A window appears for you to enter the display name.  
\* To delete a registration, press the Delete soft key.
5. Enter the display name (using up to 16 characters, **Aa#1**).
6. Press **DISP/ENTER**.  
The display is registered.

- **Switching the Display**

The display switches in the registration order each time you press the Favorite key.

## 5.17 Writing a Message When the DX Recovers from a Power Failure

A message is written to the trend display when the DX recovers from a power failure while memory sampling is in progress.

### Setup Screen

- **Power-fail message**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > View, Message, Input, Alarm**

The screenshot shows the 'Basic Setting Mode' interface. The title bar reads 'Basic Setting Mode' and 'Ethernet Link'. The breadcrumb path is 'Environment > View, Message, Input, Alarm'. The screen is organized into several sections:

- View:** Trend type (T-Y), Partial (Off), Trend rate switching (Off).
- Input:** Value on over-range (Over).
- Alarm:** Detect (Off).
- Message:** Write group (Common), Power-fail message (Off), Change message (Off).

At the bottom of the screen, there are two buttons: 'On' and 'Off'.

### Setup Items

- **Message > Power-fail message**

Settings	Description
On	A message is written when the DX recovers from a power failure while memory sampling is in progress. Display example: 15:12 Power Off 2005/10/25 15:12:57
Off	Disables the function.

## 5.18 Changing the FUNC Key Menu and Display Selection Menu


Change the FUNC key menu that appears when the FUNC key is pressed and the display selection menu that appears when the DISP/ENTER key is pressed.

### Setup Screen

- **FUNC Key Menu**

Press **MENU** (switch to the setting mode) and select **Menu customize >**

#### Function menu



Number indicating the display order




Menu name  
White: Used  
Gray: Not used

- **Display Menu**

Press **MENU** (switch to the setting mode) and select **Menu customize >**

#### Display menu



Separator

### Setup Items

- **Enabling/Disabling the FUNC Key Menu**

Items whose menu name is white are shown.

1. Press the **arrow keys** to select a menu item.
2. Press the **View** or **Hide** soft key.

If you press the Hide soft key, the menu name is displayed in gray, and does not appear in the FUNC key menu.

- **Changing the Display Order of the FUNC Key Menu**

Menu items are displayed in order by number. In addition, menu items appear when the corresponding function can be used.

1. Press the **arrow keys** to select a menu item.
2. Press the **Select** soft key.  
The menu item is enclosed in a red frame.
3. Press the **arrow keys** to select the destination.
4. Press the **Transfer** soft key.

The menu item moves to the selected number position.

## 5.18 Changing the FUNC Key Menu and Display Selection Menu

- **Description of the FUNC Key Menus**

For a description of each item, see the respective section.

AlarmACK	Message	Free message	Media eject	Snap shot	Manual sample	Trigger
Sec. 3.8	Sec. 5.4	Sec. 5.4	Sec. 6.4 Sec. 2.12	Sec. 6.6	Sec. 6.5	Sec. 6.4
Save display	Save event	Save stop	Math start	Math reset	Math ACK	Timer reset
Sec. 6.4	Sec. 6.4	Sec. 4.8	Sec. 9.4	Sec. 9.4	Sec. 9.4	Sec. 7.1
Key lock	Logout	Password change	Second speed	Batch	Text field	Favorite regist
Sec. 8.1	Sec. 8.3	Sec. 8.3	Sec. 5.3	Sec. 6.3	Sec. 6.3	Sec. 5.16
4Panel	Standard display	System info	Network info	Sntp	E-Mail start	E-Mail test
Sec. 4.10	Sec. 5.15	Sec. 2.5	Sec. 2.5	Comm.*	Comm.*	Comm.*

FTP test

\* *Communication Interface User's Manual*

Comm.\*

- **Enabling/Disabling the Display Menu and Sub Menu**

Items whose menu name is white are shown.

1. Press the **arrow keys** to select a menu item.
2. Press the **View** or **Hide** soft key.  
If you press the Hide soft key, the menu name is displayed in gray, and does not appear in the display selection menu.

- **Changing the Display Menu/Sub Menu Positions**

1. Press the **arrow keys** to select a menu item.
2. Press the **Select** soft key.  
The menu item is enclosed in a red frame.
3. Press the **arrow keys** to select the destination.
4. Press the **Transfer** soft key.  
The menu item moves to the selected position.

- **Showing/Hiding Separators**

1. Press the **arrow keys** to select a menu item.
2. Press the **Separate** soft key.  
A separator (line) is displayed between the current item and the lower item.  
If you select a menu item whose separator is already shown, this operation hides the separator.  
You can set up to three separators in the display selection menu and each sub menu.

- **Description of the Display Selection Menus and Sub Menus**

Items with asterisk (\*) are set to **Hide** by default.

Display Selection Menu	Sub Menu	Reference Section
TREND	GROUP 1 to GROUP 36	Sections 4.2 and 5.12
	1/4 CIRCLE	Section 5.12
	ALL CHANNEL/GROUP CHANNEL	Sections 4.2 and 5.12
	SCALE ON/OFF	Sections 4.2 and 5.12
	DIGITAL OFF/ON	Sections 4.2 and 5.12
	MESSAGE DISP2/1	Section 4.2
	* TREND SPACE ON/OFF	See sections 4.2 and 5.12.
	AUTO SCROLL ON/OFF	See sections 4.2 and 5.12.
	EXPAND	Section 4.10
	TREND HISTORY	GROUP 1 to GROUP 36
DIGITAL	GROUP 1 to GROUP 36	Section 4.2
	AUTO SCROLL ON/OFF	Section 4.2
	EXPAND	Section 4.10
BAR	GROUP 1 to GROUP 36	Section 4.2
	AUTO SCROLL ON/OFF	Section 4.2
	EXPAND	Section 4.10
OVERVIEW	CURSOR OFF/ON	Section 4.4
	JUMP TO ALM SUM	Section 4.4
	JUMP TO TREND	Section 4.4
	* JUMP TO DIGITAL	Section 4.4
	* JUMP TO BAR	Section 4.4
	EXPAND	Section 4.10
INFORMATION	ALARM SUMMARY	Section 4.5
	MESSAGE SUMMARY	Section 4.5
	MEMORY SUMMARY	Section 4.5
	* MODBUS CLIENT	Section 4.5
	* MODBUS MASTER	Section 4.5
	* RELAY	Section 4.5
	REPORT DATA	Section 4.5
	TO HISTORY	Sections 4.6, 4.7, and 4.8
	TO HISTORY(DISP)	Sections 4.6, 4.7, and 4.8
	TO HISTORY(EV)	Sections 4.6, 4.7, and 4.8
	TO OVERVIEW	Section 4.6
	CHANGE SORT KEY	Sections 4.6 and 4.7
	ASCENDING ORDER/ DESCENDING ORDER	Sections 4.6 and 4.7
	SELECT SAVE <sup>1</sup>	Section 4.8
	* M.SAMPLE SAVE	Section 4.8
	* REPORT SAVE	Section 4.8
	ALL SAVE <sup>1</sup>	Section 4.8
	CHANGE DISP ITEM	Section 4.7
	CHANGE DATA KIND	Section 4.8
	FILENAME DISPLAY/TIME DISPLAY	Section 4.8
CHANGE REPORT CH	Section 4.5	
EXPAND	Section 4.10	

1: The default setting is Hide on DXs before release number 2.

## 5.18 Changing the FUNC Key Menu and Display Selection Menu

---

Display Selection Menu	Sub Menu	Reference Section
* Log	LOGIN	Section 4.9
	ERROR	Section 4.9
	COMMUNICATION	Section 4.9
	FTP	Section 4.9
	MAIL	Section 4.9
	WEB	Section 4.9
	SNTP	Section 4.9
	DHCP	Section 4.9
	MODBUS	Section 4.9
4 PANEL	MIX	Section 4.10
	ALL TREND	Section 4.10
	ALL DIGITAL	Section 4.10
	ALL BAR	Section 4.10
* EXPAND		Section 4.10

# 6.1 Setting the Recording Conditions of the Measured Data

Set the method for recording the measured data.  
 For a description of the function, see section 1.4.

## Setup Screen


- Data Type**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **A/D, Memory**





- Measurement Channels**

Press **MENU** (switch to the setting mode) and select **Meas Channel > Tag, Memory sample, Alarm delay**



- File Save Interval (Display Data)**

Press **MENU** (switch to the setting mode) and select **Display > Trend/Save interval or Circular/Save interval**






## 6.1 Setting the Recording Conditions of the Measured Data

- **Recording Conditions of Event Data**

Press **MENU** (switch to the setting mode) and select **Data save > Event data**



### Setup Items

- **Memory > Data kind**

Settings	Description
Display	Records display data.
E+D	Records display data and event data.
Event	Records event data.

- **Memory sample > On/Off**

Turn **On** the target channels.

- **Trend/Save interval > Save interval (when recording display data)**

Select the size of a record data file. The recorded data is divided by the file size specified here. The available settings vary depending on the **Trend interval** setting.

<b>Trend interval</b>	<b>15 s*</b>	<b>30 s</b>	<b>1 min</b>	<b>2 min</b>	<b>5 min</b>
<b>Selectable range of auto save interval</b>	10 min to 3 days	10 min to 7 days	10 min to 14 days	10 min to 14 days	10 min to 31 days
<b>Trend interval</b>	<b>10 min</b>	<b>15 min</b>	<b>20 min</b>	<b>30 min</b>	<b>1 h</b>
<b>Selectable range of auto save interval</b>	10 min to 31 days	10 min to 31 days	1 hour to 31 days	1 hour to 31 days	1 hour to 31 days
<b>Trend interval</b>	<b>2 h</b>	<b>4 h</b>	<b>10 h</b>		
<b>Selectable range of auto save interval</b>	2 hours to 31 days	4 hours to 31 days	8 hours to 31 days		

\* Selectable on the DX2004 and DX2008

- **Trend/Save interval > Second interval [/div]**

See section 5.3.

- **Circular/Save interval**

See section 5.12.

- **Event data (when recording event data)**

- **Sample rate**

Select the data recording interval from the available settings.

- **Mode**

Settings	Description
Free	Records data continuously.
Single	Records data when the trigger condition is met.
Repeat	Records data each time the trigger condition is met.

- **Data length**

Select the size of a record data file. The recorded data is divided by the file size specified here. The available data lengths vary depending on the **Sample rate** setting.

<b>Sample rate</b>	<b>25 ms*</b>	<b>25 ms</b>	<b>250 ms</b>	<b>500 ms</b>	<b>1 s</b>
<b>Selectable range of data length</b>	10 min to 4 hours	10 min to 1 day	10 min to 2 days	10 min to 3 days	10 min to 7 days
<b>Sample rate</b>	<b>2 s</b>	<b>5 s</b>	<b>10 s</b>	<b>30 s</b>	<b>1 min</b>
<b>Selectable range of data length</b>	10 min to 14 days	10 min to 31 days	10 min to 31 days	1 hour to 31 days	1 hour to 31 days
<b>Sample rate</b>	<b>2 min</b>	<b>5 min</b>	<b>10 min</b>		
<b>Selectable range of data length</b>	1 hour to 31 days	1 hour to 31 days	1 hour to 31 days		

\* Selectable on the DX2004 and DX2008

- **Pre-trigger**

Specify the range when recording data before the trigger condition is met. Select the range as a percentage of the data length from **0, 5, 25, 50, 75, 95, and 100%**. If you do not want to record the data existing before the trigger condition is met, select **0%**.

- **Trigger signal > Key**

Select **On** if you want to activate the trigger using key operation.

**Note**

- Triggers can be applied using event action (see section 7.1).
- If the trigger condition is already met when you press START, recording starts.

## 6.2 Setting the Method for Saving the Data

Set the method for recording the measured data to the storage medium.  
For a description of the function, see section 1.4.

### Setup Screen

- **Auto save**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > Security, Media save, Batch**

The screenshot shows the 'Basic Setting Mode' interface. At the top, it says 'Basic Setting Mode' and 'Ethernet Link'. Below that, the navigation path is 'Environment > Security, Media save, Batch'. The screen is divided into three sections: 'Security', 'Save', and 'Batch'. Under 'Security', 'Key Communication' is set to 'Off'. Under 'Save', 'Auto save' is set to 'On' (highlighted in blue) and 'Media FIFO' is set to 'Off'. Under 'Batch', 'On/Off' is set to 'Off'. At the bottom, there are 'On' and 'Off' buttons.

- **File header, Data file name**

Press **MENU** (switch to the setting mode) and select **Data save > File header, Data file name**

The screenshot shows the 'Data save > File header, Data file name' screen. At the top, it displays 'GROUP 1', '2005/09/30 11:14:46', 'EVENT', and 'Ethernet Link'. The navigation path is 'Data save > File header, Data file name'. The screen has two main sections: 'File header' and 'Data file name'. Under 'File header', there is a 'Characters' field with a blue highlight. Under 'Data file name', there is a 'Structure' field set to 'Date' and an 'Identified strings' field. At the bottom, there are 'Input', 'Clear', and 'Copy' buttons.

- **Save directory**

Press **MENU** (switch to the setting mode) and select **Data save > Save directory**

The screenshot shows the 'Data save > Save directory' screen. At the top, it displays 'GROUP 1', '2005/10/28 18:17:31', 'DISP', '18min', and 'Ethernet Link'. The navigation path is 'Data save > Save directory'. The screen has a 'Save directory' section with a 'Directory name' field set to 'DATA0'. At the bottom, there are 'Input', 'Clear', and 'Copy' buttons.

## Setup Items

- **Save > Auto save**

Settings	Description
On	Automatically saves the measured data to the CF card. Specify On to enable the media FIFO function.
Off	Does not automatically save the data. Save the measured data manually to the CF card or USB flash memory (/USB1 option).

- **Save > Media FIFO (Release Number 2 or Later)**

This item appears if Auto save is set to On.

Settings	Description
On	Enable media FIFO. Constantly retains the most recent data files in the CF card.
Off	Disable media FIFO. Replace the CF card if the free space on the CF card drops low.

- **File header > Characters**

Set the header comment to be written to the data file. (Up to 50 characters,  $\overline{\text{Aa\#1}}$ )

- **Data file name > Structure**

Sets the structure of the file name when saving data.

Settings	Description
Date	Serial number + user-assigned character string + date
Serial	Serial number + user-assigned character string
Batch	Serial number + batch name (when using the batch function)

- **Data file name > Identified strings**

Set the user-assigned section of the file name. (Up to 16 characters,  $\overline{\text{Aa\#1}}$ )

Symbols that can be used: #, %, (, ), +, -, ., @, °, and \_.

For details on the data file name, see section 1.4.

- **Save directory > Directory name**

Set the name of the directory on the storage medium for saving the data on the external storage medium. (Up to 20 characters,  $\overline{\text{Aa\#1}}$ )

Symbols that can be used: #, %, (, ), +, -, ., @, °, and \_.

Strings that cannot be used: AUX, CON, PRN, NUL, CLOCK, COM1 to COM9, and LPT1 to LPT9.

## 6.3 Using the Batch Function

Set the batch function.

For a description of the function, see section 1.5.

### Setup Screen

- **Batch Function**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > Security, Media save, Batch**

The screenshot shows the 'Basic Setting Mode' interface. At the top, it says 'Basic Setting Mode' and 'Ethernet Link'. Below that, the navigation path is 'Environment > Security, Media save, Batch'. The main area is divided into three sections: 'Security', 'Save', and 'Batch'. Under 'Security', 'Key Communication' is set to 'Off'. Under 'Save', 'Auto save' is 'On' and 'Media FIFO' is 'Off'. Under 'Batch', 'On/Off' is 'On', 'Lot-No. digit' is '6', and 'Auto increment' is 'On'. At the bottom, there are 'On' and 'Off' buttons.

- **Data file name**

Press **MENU** (switch to the setting mode) and select **Data save > File header, Data file name**

The screenshot shows the 'Data save > File header, Data file name' screen. At the top, it displays 'GROUP 1', '2005/09/30 11:18:05', 'EVENT', and a signal strength indicator. The main area has two sections: 'File header' with a 'Characters' input field, and 'Data file name' with a 'Structure' dropdown menu set to 'Batch'. At the bottom, there are 'Date', 'Serial', and 'Batch' buttons.

- **Text Field**

Press **MENU** (switch to the setting mode) and select **Data save > Batch text**

The screenshot shows the 'Data save > Batch text' screen. At the top, it displays 'GROUP 1', '2005/09/30 11:18:30', 'EVENT', and a signal strength indicator. The main area has two sections: 'Text field number' with a value of '1', and 'Text field' with a 'Title of field' input field and a 'Characters' input field. At the bottom, there are 'Input', 'Clear', and 'Copy' buttons.

## Setup Items

- **Batch > On/Off**  
Select **On** to use the batch function.
- **Batch > Lot-No. digit**  
Select the number of digits of the lot number from 4, 6, or 8. Select **Off** to disable the lot number.

- **Batch > Auto increment**

Settings	Description
On	Automatically sets the lot number of the next measurement to “the lot number of the current measurement + 1.”
Off	Disables the operation described above.

- **Data file name > Structure**

Batch: Sets the name of the display data files or event data files to “batch name + serial number.”

For details on the data file name, see section 1.4.

- **Text field number**

Select a number from 1 to 8.

- **Text field > Title of field, Text field > Characters**

Set the string.

Title of field: (Up to 20 characters,  $\boxed{\text{Aa}\#\text{1}}$ ), Characters: (Up to 30 characters,  $\boxed{\text{Aa}\#\text{1}}$ )

## Procedure

- **Setting the Batch name and Comment**

1. In the operation mode, press **FUNC**.  
The FUNC key menu appears.
2. Press the **Batch** soft key.  
A window appears for you to enter the batch name and comment.
3. Set the batch number. (Up to 32 characters,  $\boxed{\text{Aa}\#\text{1}}$ )  
Symbols that can be used: #, %, (, ), +, -, ., @, °, and \_.  
  
If you are using the lot number, set the lot number.
4. Set batch comments 1, 2, and 3. (Up to 50 characters each,  $\boxed{\text{Aa}\#\text{1}}$ )
5. Press **DISP/ENTER**.

### Note

- Batch numbers and lot numbers cannot be changed after memory start.
- You can change the comment as many times as you wish before executing memory start. After memory start, only the comments that are not specified can be entered. You can change the comment as many times as you wish while the window for setting the comment is displayed. The last specified comment is valid.
- The comment is cleared when memory stop is executed.
- The batch number, lot number, and comments are saved to the display data file or event data file. They are not saved to the setup file.

- **Displaying the Text Field Settings**

1. In the operation mode, press **FUNC**.  
The FUNC key menu appears.
2. Press the **Text field** soft key.  
The text field settings are displayed.

## 6.4 Starting/Stopping the Recording and Saving the Measured data

Start the recording and save the measured data to the external storage medium.  
For a description of the function, see section 1.4.

### Procedure

- **Starting the Recording (Memory Start)**

Press **START**. The internal memory icon in the status display section changes from the stop icon to memory sampling icon.

- When recording display data or event data in free mode, recording starts.
- When recording event data in trigger mode, the DX enters the trigger-wait condition.

- **Applying a Trigger to Start the Recording**

Carry out the procedure below when the DX is waiting for a trigger.

#### Trigger through Key Operation

The procedure below can be carried out when recording event data in trigger mode and the DX is configured so that the start trigger is applied through key operation.

1. Press **FUNC**.  
The FUNC key menu appears.
2. Press the **Trigger** soft key.  
The recording starts.

#### Trigger by an Event (Event action function must be configured. See section 7.1.)

Recording starts when an event occurs.

- **Automatically Saving Measured Data**

The save destination is the CF card.

Have the CF card inserted in the slot at all times. While the memory sampling is in progress, the measured data recorded in the internal memory is automatically saved to the CF card.

Action when Media FIFO is not enabled: If data storage to the storage medium is not complete such as due to insufficient free space, the unsaved data is saved the next time the data is automatically saved.


#### Saving the Display Data or Event Data during Memory Sampling through Key Operation

The save destination is the CF card.

This operation can be carried out when recording display data or when recording event data in **Free** mode. Unsaved measured data is saved to the CF card.

\* If this operation is carried out when auto save is Off, the data in the internal memory is divided, and a file is created.

1. In the operation mode, press **FUNC**.  
The FUNC key menu appears.
2. Press the **Save display** or **Save event** soft key.  
The display data or event data is saved to the CF card.



- **Saving Measured Data Manually (Collectively Storing Unsaved Data)**

The save destination is the CF card or USB flash memory (/USB1 option).  
For the procedure to save data to the USB flash memory, see section 2.12.

1. Insert the storage medium.

A confirmation window containing the message “There is data which is not saved to media. Do you want to store to media?” appears.

2. Select **Yes** and press **DISP/ENTER**.

Unsaved data in the internal memory is saved to the storage medium.

3. Carry out the procedure below to remove the storage medium.

**Press FUNC (display the FUNC key menu) > Media eject soft key > CF soft key**


When the message “Media can be removed safely” appears, remove the storage medium.

**Note**

- If there is not enough free space on the storage medium, the message “Not enough free space on media” appears, and the data is not saved. If this message appears, replace the storage medium. Then, carry out the procedure again.
- You cannot abort the data save operation while it is in progress.

- **Stopping the Recording (Memory Stop)**

1. Press **STOP**. A confirmation window is displayed.



2. Select **Yes** using the arrow keys and press **DISP/ENTER**.

On models with the computation function (/M1 or /PM1 option), select **Mem+Math** or **Memory**, and press **DISP/ENTER**.

The internal memory icon in the status display section changes to the stop icon.

- **Saving the Data in the Internal Memory Collectively or Selectively through Key Operation**

See section 4.8.



### Explanation

- **Operations That Start Simultaneously with Memory Start**

- Waveform display updating on the trend display.
- Report (/M1 and /PM1 options)
- The computation function (/M1 and /PM1 options) can be configured to start simultaneously with memory start.  
See section 9.4.

- **Operations That Stop Simultaneously with Memory Stop**

- Waveform display updating on the trend display.
- Report (/M1 and /PM1 options)
- Computation function (/M1 and /PM1 options): When selected in the procedure described above.

- **Performance While Data Is Being Saved**

If the internal memory or external storage medium is continuously accessed, the following phenomena may occur. When such phenomena occur, the storage medium access indicator frequently illuminates.

- Files being saved to the external storage medium drop out.
- Accessing the DX through communications takes a long time

In such case, take the following measures.

- If you are creating data files at short intervals consecutively using the event action function, increase the data file save interval.
- If you are creating numerous files in a single directory on the external storage medium, change the destination directory name at approximately every 1000 files.

## 6.5 Manually Saving the Measured Data (Manual Sample)


Save the instantaneous values of all channels (excluding those set to Skip or Off) through key operation. On models with the external input channels (/MC1 option), the instantaneous values of specified channels (among 120 channels) are saved. For a description of the function, see section 1.4.

### Setup Screen

- **Channel to be Manual Sampled**

This setting applies to models with the external input channels (/MC1 option).

Press **MENU** (switch to the setting mode) and select **Data save > Manual sample**



### Setup Items

- **Manual sample number**

Select a number from 001 to 120. The instantaneous values are output in this order.

- **ManualSample**

- **On/Off**

Select **On** when assigning a channel to the manual sample number.

- **Channel**

Enter a channel number of a measurement channel, computation channel (/M1 and /PM1 options), or external input channel (/MC1 option).

### Procedure

1. In the operation mode, press **FUNC**.  
The FUNC key menu appears.
2. Press the **Manual sample** soft key.  
Manual sampling is executed.

### Explanation

- **Number of Manual Sampled Data Set in the Internal Memory**

The number of manual sampled data set in the internal memory is displayed on the memory summary display (see section 1.9)

- **Saving Measured Data to the CF Card**

- If auto save is **On**, the manual sampled data is saved to the CF card when you carry out manual sampling.
- If auto save is **Off**, save the manual sampled data to the CF card according to the procedure for manually saving the data (see section 6.4).
- The manual sampled data can be saved manually to a CF card or USB flash memory (/USB1 option) regardless of whether the auto save function is set to On/Off. For the manual save operation, see section 4.8.

---

## 6.6 Saving the Screen Image Data (Snapshot)

Save the current screen image data to the CF card. This operation is called *snapshot*, and the screen image data file is called *snapshot data file*.  
For a description of the function, see section 1.4.

### Procedure

1. In the operation mode, press **FUNC**.  
The FUNC key menu appears.
2. Press the **Snap shot** soft key.  
The snapshot data file is saved to the CF card.  
Image of the soft keys and the message window are not saved.

### Note

---

If you assign the snapshot function to the USER key, you can carry out snapshots in all modes (operation mode, setting mode, and basic setting mode). However, error messages are not saved.

---

### Explanation

- **File Format and Size**  
The snapshot data file is in PNG format.  
The maximum size of a snapshot data file is approximately 15 KB.
- **File Name**  
See section 1.4.

## 6.7 Managing the Files on the Storage Medium

This section explains how to display a list of files on the storage medium, check the free space, delete files and directories, and format the storage medium.

### Procedure

- **Displaying a List of Files on the Storage Medium, Deleting Files, and Checking the Free Space**

Carry out the procedure below to show the display.

Press **MENU** (switch to the setting mode); select **Save/Load > File list**, **delete**; press the **CF** or **USB** soft key\*; and press **DISP/ENTER**.

\* When a CF card and a USB flash memory (/USB1 option) are being used.



### Displaying a List of Files in a Directory and Checking the Free Space

Press the **arrow keys** to select a directory, and press **DISP/ENTER**. The files in the directory are displayed. The root directory is denoted by [/].



### Sorting Files and Directories (Release Number 2 or Later)

The files and directories can be sorted by the update date/time.

Each time you press the **Sort** soft key, the files and directories are sorted in order from the oldest or the latest update date/time. A mark indicating the sort order is displayed by Date/Time.

## 6.7 Managing the Files on the Storage Medium

### Deleting a File

Press the **arrow keys** to select the file to be deleted, and press the **Delete** soft key. A confirmation window appears. Select **Yes**, and press **DISP/ENTER**. The file is deleted.

### Deleting a Directory

First, delete all the files in the directory. Select the directory you want to delete. The rest of the procedure is the same as deleting a file.

### Checking the Free Space


The free space on the storage medium is shown at the lower right of the screen.

### • Formatting the Storage Medium

1. Carry out the procedure below to show the display.

Press **MENU** (switch to the setting mode); select **Save/Load >Format**; press the **CF** or **USB** soft key\*; and press **DISP/ENTER**.

\* When a CF card and a USB flash memory (/USB1 option) are being used.



2. Enter the volume name and press **DISP/ENTER**. (Up to 11 characters, **A1**)  
A confirmation window opens.
3. Select **Yes** and press **DISP/ENTER**.  
The storage media is formatted.

### Explanation

### • Format Type

Size	Type
Storage medium smaller than or equal to 512 MB	FAT16
Storage medium greater than 512 MB	FAT32

## 6.8 Loading and Displaying the Measured Data in the Storage Medium

Load the display or event data file saved on the external storage medium and display the waveform. The loaded data is shown on the historical trend display. For the operations on the historical trend display, see section 4.3.


### Procedure

#### • Loading a File


1. Carry out the procedure below to show the display.

Press **MENU** (switch to the setting mode); select **Save/Load >Load display** or **Load event data**; press the **CF** or **USB** soft key\*; and press **DISP/ENTER**.

\* When a CF card and a USB flash memory (/USB1 option) are being used.



2. Press the **arrow keys** to select a directory, and press **DISP/ENTER**. The files in the directory are displayed. The root directory is denoted by [/].
3. Press the **arrow keys** to select a file, and press **DISP/ENTER**. The file is loaded, and the waveform is displayed in the historical trend.



### Note

- The display data extension is .dad; the event data extension is .dae.
- For details on how to use the Sort key, see section 6.7.

## 6.9 Saving/Loading the Setup Data

Save the setup data to the external storage medium or load the setup data from the external storage medium.


### Procedure

#### • Saving the Setup Data

1. Carry out the procedure below to show the display.

Press **MENU** (switch to the setting mode); select **Save/Load > Save settings**; press the **CF** or **USB** soft key\*; and press **DISP/ENTER**.

\* When a CF card and a USB flash memory (/USB1 option) are being used.




2. Set the file name. (Up to 32 characters, **Aa#1**)  
Symbols that can be used: #, %, (, ), +, -, ., @, °, and \_.  
Strings that cannot be used: AUX, CON, PRN, NUL, CLOCK, COM1 to COM9, and LPT1 to LPT9.  
To cancel the operation, press **ESC**.
3. Press **DISP/ENTER**.  
The setup data is saved.

#### • Loading the Setup Data for the Setting Mode

1. Carry out the procedure below to show the display.

Press **MENU** (switch to the setting mode); select **Save/Load > Load settings**; press the **CF** or **USB** soft key; and press **DISP/ENTER**



2. Use **DISP/ENTER** and **arrow keys** to select the setup file to be loaded.  
\* Setup data files are stored in the root directory [ / ].  
To cancel the operation, press **ESC**.
3. Press **DISP/ENTER**.  
The setup data is loaded.

### Note

For details on how to use the Sort key, see section 6.7.






# 7.1 Setting the Event Action Function (Including Remote Control (/R Option) and USER Key)

A specified action is carried out when an event occurs. This function is called event action. The remote control function (/R1 option) and the USER key are set by the event action. For a description of the function, see section 1.6.

## Setup Screen

- **Event and Action**

Press **MENU** (switch to the setting mode) and select **Timer, Event action > Event action**




- **Timer**

Press **MENU** (switch to the setting mode) and select **Timer, Event action > Timer**

- When set to absolute time




- When set to relative time



- **Match Time**

Press **MENU** (switch to the setting mode) and select **Timer, Event action > Match time timer**



## 7.1 Setting the Event Action Function (Including Remote Control (/R Option) and USER Key)

### Setup Items

- **Logic box number**

You can set up to 40.

- **Event-Action > Event**

The condition to execute the action.

Settings	Description
None	Not use.
Remote	Select the remote control input terminal number.
Relay	Select the alarm output relay number.
Switch	Select the internal switch number.
Timer	Select the timer number.
Matchtime	Select the match timer number.
Alarm	-
USER-Key	-

- **Event-Action > Action**

The action to be executed when an event occurs.

Settings	Description
Memory	-
Start	-
Stop	-
Trigger	Can be specified when the DX is configured to record event data.
AlarmACK	Cannot be specified when the event is set to <b>Relay</b> , <b>Switch</b> , or <b>Alarm</b> .
Math	Can be specified on /M1 and /PM1 options.
MathStart	Can be specified on /M1 and /PM1 options.
MathStop	Can be specified on /M1 and /PM1 options.
Math rst	Can be specified on /M1 and /PM1 options.
SaveDisp	Can be specified when the DX is configured to record display data.
SaveEvent	Can be specified when the DX is configured to record event data.
Message	Set the message number to write the message and the destination. Set the message destination to all groups (All) or a group number.
Snapshot	-
Rate1/2	Can be specified when the function for switching between the trend interval and the secondary trend interval is enabled.
M.sample	-
TimerRst	Cannot be specified when the event is set to <b>Timer</b> .
Group	Specify the number of the group to be displayed.
Flag	Can be specified on /M1 and /PM1 options.
Time adj	Can be specified only when the event is set to <b>Remote</b> .
PnlLoad	Can be specified only when the event is set to <b>Remote</b> .

- **Timer**

Timer used by event action. Used also in the TLOG computation of the computation function.

\* The timer cannot be changed while memory sampling or computation is in progress.

- **Timer No.**

Up to four timers (1 to 4) can be set.

**When Using an Absolute Timer**

- **Mode**

Select **Absolute**.

- **Interval**

Select the interval from the available settings between 1min to 24h.

- **Ref.time**

Set the time in the range of hour 0 to hour 23.

**When Using a Relative Timer**

- **Mode**

Select **Relative**.

- **Interval**

Set the interval in the range of 00:01 (1 min) to 24:00 (24 hours).

- **Reset at Math Start**

On: Resets the timer when computation is started. The resetting of the timer is not considered to be a timeout. Even if the timer is used as an event, the action is not executed.

- **Match Time Timer**

Set the time match condition used in event action.

\* The condition cannot be changed while memory sampling or computation is in progress.

- **Timer number**

You can set up to four match time conditions (1 to 4).

- **Kind**

Settings	Description
Day	Set the time match condition of a day.
Week	Set the time match condition of a week.
Month	Set the time match condition of a month.

Set the items with check marks in the following table depending on the Kind setting.

Setup Item	Kind		
	Day	Week	Month
Day			✓
Day of week		✓	
Hour:Minute	✓	✓	✓

- **Day**

Set the day.

- **Weekday**

Set the day of the week.

- **Hour:Minute**

Set the time in the range of 00:00 to 23:59.

- **Timer action**

Settings	Description
Single	Executes the action once when the condition is met.
Repeat	Executes the action at every specified time.

### Procedure

- **Resetting the Relative Timer**
  1. In the operation mode, press **FUNC**.  
The FUNC key menu appears.
  2. Press the **Timer reset** soft key.
  3. Press the soft key corresponding to timer you want to reset. Select **All** to reset all timers.  
The relative timer is reset.

### Explanation

- **Resetting the Relative Timer**

Restarts the timer.

  - The resetting of the timer is considered to be a timeout. (If the timer is used as an event, the action is executed.)
  - If the timer is used in TLOG computation on the /M1 or /PM1 math option and mathreset is specified, the computed result is reset.

## 7.2 Setup Examples of Event Action

### Example 1: Starting/Stopping the Memory Sampling through Remote Control (/R1 Option)

Starts/Stops the memory sampling when a signal is applied to remote control input terminal 2. Use logic box number 1.

- **Setup Screen and Setup Items**

Press **MENU** (switch to the setting mode) and select **Timer, Event action >**

**Event action**

GROUP 1	2005/09/30 11:28:47	DISP	20min
Timer. Event action > Event action			
Logic box number	1		
Event-Action			
Event	Remote		
Remote number	2		
Action	MemoryStart/Stop		
1 2 3 4 5 6 Next 1/7			

**<Operation>**

If the input to the remote control input terminal 2 is turned ON when memory sampling is stopped, memory sampling starts. If the remote control input is turned OFF when memory sampling is in progress, memory sampling stops.

### Example 2: Writing a Message When an Alarm Occurs

Write the message "Channel 1 Alarm" to group 1 when an alarm occurs on channel 1. Use logic box number 2.

- **Setup Screen and Setup Items**

Press **MENU** (switch to the setting mode) and select **Timer, Event action >**

**Event action**

GROUP 1	2005/09/30 11:29:42	DISP	20min
Timer. Event action > Event action			
Logic box number	2		
Event-Action			
Event	Switch		
Switch No.	S03		
Action	Message		
Message No.	4		
Write to	Select		
Group number	1		
1 2 3 4 5 6 Next 1/7			

**<Other Settings>**

- Set an alarm to channel 1 and output to internal switch 3.
- Register "Channel 1 alarm" in message number 4.

For the procedure to set the alarm, see section 3.7.

For the procedure to set the message, see section 5.4.

### Example 3: Saving the Data Every Day at Hour 17


Save the recorded data to the CF card every day at hour 17. Use logic box number 3. Use match time condition 1.

- **Setup Screen and Setup Items**

#### Logic box number 3

Press **MENU** (switch to the setting mode) and select **Timer, Event action >**


#### Event action



#### Match Time Condition

Press **MENU** (switch to the setting mode) and select **Timer, Event action >**

#### Match time timer



#### <Other Settings>

Set the display data to be saved automatically. Set the file save interval to **1day** or longer. If a file save interval shorter than **1day** is specified, the data is also saved at the file save interval.

For the procedure to set the recording conditions of the display data, see section 6.1.

### Example 4: Releasing the Alarm Output Using the USER Key (Alarm Acknowledge Operation)

Release the activated alarm output by pressing the USER key. Use logic box number 4.

- **Setup Screen and Setup Items**

Press **MENU** (switch to the setting mode) and select **Timer, Event action >**

#### Event action

The screenshot displays the 'Event action' configuration interface. At the top, a status bar shows 'GROUP 1', the date and time '2005/10/28 18:13:42', 'DISP', and a timer '20min'. Below this, the title 'Timer. Event action > Event action' is visible. The main area contains a 'Logic box number' field with the value '4'. Under the 'Event-Action' section, there are two input fields: 'Event' with the value 'UserKey' and 'Action' with the value 'AlarmACK'. At the bottom, a navigation bar includes buttons numbered 1 to 6 and a 'Next 1/7' button.

#### <Operation>

Press the USER key to release the activated alarm indication and relay output.

#### <Related Settings>

Set the alarm indication and alarm output relay operation to **Hold**.

For the procedure to set the alarm indication operation and alarm output relay operation, see section 3.5.


# 8.1 Disabling the Key Operation (Key Lock Function)

Disable the key operation.  
 For a description of the function, see section 1.7.

## Setup Screen


- **Selecting the Key Lock Function**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > Security, Media save, Batch**



- **Key Operation to Be Disabled**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Keylock**



## Setup Items

- **Security > Key**

Select **Keylock**.

Settings	Description
Keylock	Enables the key lock function. The <b>Keylock</b> item is displayed in the basic setting mode menu.
Login	Enables the login function. See section 8.2.

- **Keylock > Password**

The password used to release the key lock. (Up to 8 characters, **Aa#1**)

- **Keylock > Key action, Media/USB, Action of Function**

Select whether to lock each item.

Settings	Description
Free	Key lock not applied.
Lock	Disables the operation.



## 8.1 Disabling the Key Operation (Key Lock Function)


### Procedure

- **Locking the Keys**

1. In the operation mode, press **FUNC**.  
The FUNC key menu appears.
2. Press the **Keylock** soft key.  
The key lock is activated. The key lock icon appears in the status display section.

- **Releasing the Key Lock**

1. In the operation mode, press **FUNC**.  
The FUNC key menu appears.
2. Press the **Keylock** soft key.  
A window appears for you to enter the password.



3. Enter the password and press **DISP/ENTER**.  
The key lock is released. The key lock icon in the status display section disappears.

## 8.2 Enabling Only Registered Users to Operate the DX (Login Function)

Only registered users can operate the DX.  
For a description of the function, see section 1.7.

### Setup Screen


- **Login Function**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > Security, Media save, Batch**




- **Logout Method**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Login > Basic settings**



- **Registering Administrators**


Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Login > Admin settings**



## 8.2 Enabling Only Registered Users to Operate the DX (Login Function)

- **Registering Users**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Login > User settings**



- **User Privileges**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Login > Authority of user**



### Setup Items

The login function can be set separately for login through keys and login through communications.

- **Security > Key**

Select **Login**.

Settings	Description
Login	Enables only registered users to operate the DX using keys. The <b>Login</b> item is displayed in the basic setting mode menu.
Keylock	Enables the key lock function. See section 8.1.
Off	Disables the security functions.

- **Security > Communication**

Settings	Description
Login	Enables only registered users to operate the DX via communications. The <b>Login</b> item is displayed in the basic setting mode menu.
Off	Disables the security functions.

- **User basic settings > Auto logout**

Settings	Description
Off	Does not log out until the logout operation is executed.
1min to 10min	Automatically logs out when there is no key operation for a specified time.

- **User basic settings > Operation without login**

Sets the operation that the user can carry out when logged out.

Settings	Description
Off	Only login operation is available.
Display	Allows the user to switch the operation screen in addition to the login operation.

- **Admin number**

Up to five administrators can be registered. Be sure to register at least one administrator. At least one administrator must be registered to use the login function.

- **Admin settings > Mode**

The available settings vary depending on the **Security** setting.

Settings	Description
Off	Not register.
Key	Log into the DX using keys.
Comm	Log into the DX via communications.
Web	Log into the operator page and monitor page of the DX using a Web browser.
Key+Comm	Log into the DX using keys and via communications.

- **Admin settings > User name**

Set the user name. (Up to 20 characters, **[Aa#1]**)

- You cannot register user names that are already registered.
- You cannot register “quit” or a user name containing all spaces.

- **Admin settings > Password**

Set the password. (Up to 8 characters, **[Aa#1]**)

Unregistered password is displayed as “????????”. An entered password is displayed as “\*\*\*\*\*”.

- You cannot register “quit” or a password containing all spaces.

- **User number**

Up to 30 users can be registered.

- **User settings > Mode**

The available settings vary depending on the **Security** setting.

Settings	Description
Off	Not register.
Key	Log into the DX using keys.
Comm	Log into the DX via communications.
Web	Log into the monitor page of the DX using a Web browser.
Key+Comm	Log into the DX using keys and via communications.

- **User settings > User name, Password**

Same as the administrator settings.

- **Authority of user**

Settings	Description
Off	No limitations on the operation.
1 to 10	Registration number of the operation limitation.

- **Authority of user > Key action, Media/USB, Action of Function**

See section 8.1.

## 8.3 Logging in and Logging Out


This section explains the procedure to log into the DX using keys. For the procedure to log into the DX via communications, see the *Communication Interface User's Manual (IM04L41A01-17E)*.

### Procedure

#### • Logging In


1. In the operation mode, press **FUNC**.

A list of registered user names appears.



2. Press the **arrow keys** to select a user name, and press **DISP/ENTER**.

A window appears for you to enter the password.



3. Enter the password\* and press **DISP/ENTER**.

The DX is ready to be operated using keys. The name of the user that is logged in is displayed in the status display section.

\* The password that you enter is displayed as "\*\*\*\*\*."

#### • Logging Out

##### Using Keys

1. In the operation mode, press **FUNC**.

The FUNC key menu appears.

2. Press the **Logout** soft key.

You are logged out from the DX. The user name in the status indication section disappears.

##### Auto Logout

If auto logout is enabled, you are automatically logged out if there is no key operation for a specified time.

- **Changing the Password Using Keys**


- 1.** In the operation mode, press **FUNC**.  
The FUNC key menu appears.
- 2.** Press the **Password change** soft key.  
A window appears for you to enter the current password.
- 3.** Enter the current password and press **DISP/ENTER**.  
A window appears for you to enter the new password.
- 4.** Enter the new password and press **DISP/ENTER**.  
A window appears for you to enter the new password again.
- 5.** Enter the new password and press **DISP/ENTER**.  
The window closes, and the new password is activated.

# 9.1 Setting the Expression, Measurement Range, Alarm, Tag, and Data Storage on Computation Channels


Set the computation details, measurement range, tag, and alarm. You cannot set expressions or constants while memory sampling or computation is in progress. For a description of the function, see section 1.8.

## Setup Screen

- **Expression and Alarm**  
Press **MENU** (switch to the setting mode) and select **Math Channel > Calculation expression, Alarm**



- **Constants Used in Expressions**  
Press **MENU** (switch to the setting mode) and select **Math Channel > Constant**



- **Tag and Alarm Delay Time of Computation Channels**  
Press **MENU** (switch to the setting mode) and select **Math Channel > Tag, Memory sample, Alarm delay**



**9.1 Setting the Expression, Measurement Range, Alarm, Tag, and Data Storage on Measurement Channels**

- **Conditions of TLOG Computation and Rolling Average**  
Press **MENU** (switch to the setting mode) and select **Math Channel > TLOG, Rolling average**




- **Display for Computation Errors and Handling of Overflow Data in Statistical Computation**  
Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > Math, Report**



**Setup Items**

- **First-CH/Last-CH**  
Set the target channels.
- **Calculation expression and Span**
  - **Math On/Off**  
Select **On** for channels to be used.
  - **Calculation expression**  
Enter the expression using up to 120 characters.  
Pressing the **Input** soft key displays a window used to enter the expression. Use the numeric keys to enter numbers and operators.



For details on how to write expressions, see section 9.2.

**Note**

You cannot use both the USB keyboard (/USB1 option) and the DX keys to enter the equation. If you press a DX soft key, for example, while you are entering an equation from the USB keyboard, the entered equation is cleared.



## 9.1 Setting the Expression, Measurement Range, Alarm, Tag, and Data Storage on Measurement Channels

- **Span Lower, Span Upper**  
Set the measurement range.  
Selectable range of values: -9999999 to 99999999  
Selectable decimal places: X.XXXX, XX.XXX, XXX.XX, XXXX.X
- **Unit**  
Set the unit of the computed value. (Up to 6 characters, **Aa#1**)
- **Alarm**  
The available alarm types are high limit alarm, low limit alarm, delay high limit alarm, and delay low limit alarm.  
The range of alarm values is as follows:

Type	Value
H, L, T, t	Within -9999999 to 99999999 excluding the decimal point

For details on setting alarms, see section 3.7.

\* If the Math On/Off or calculation expression is changed, the alarms for that channel are turned **Off**.

- **Alarm delay > Time**  
Set the alarm delay time using an integer in the range of 1 to 3600 s.
- **Tag > Tag**  
Set the tag. (Up to 16 characters, **Aa#1**)
- **Constant**
  - **Number of constant**  
Select the constant (K01 to K60) to set.
  - **Value**  
The selectable range is as follows:  
-9.9999E+29 to -1.0000E-30, 0, 1.0000E-30 to 9.9999E+29  
The number of significant digits of a constant is five. When specifying the constant using exponential notation, set the mantissa less than or equal to 5 digits and the exponent less than or equal to 2 digits.
- **TLOG**
  - **Timer No.**  
Select the timer number to use.  
For details on setting the timer, see section 7.1.
  - **Sum scale**  
Set the sum scale to **/s** to **/h** to match the unit of the measured value.  
Example: If the unit of the measured value is "m<sup>3</sup>/min," select **/min**.  
Off: Sums as-is the measured data per scan interval.
  - **Reset**  
To reset the TLOG computed value at each interval, select **On**.

## 9.1 Setting the Expression, Measurement Range, Alarm, Tag, and Data Storage on Measurement Channels

- **Rolling average**
  - **On/Off**

To take the rolling average of the measured results, select **On**.
  - **Interval**

Select the sampling interval when taking the rolling average from the following:  
The sampling interval takes on a value that is an integer multiple of the scan interval. For example, if the sampling interval is set to 5 s when the scan interval is 2 s, the actual sampling interval is 6 s.
  - **Number of samples**

Set the number of samples for the rolling average using an integer between 1 and 1500.  
The rolling average time is equal to the sampling interval × the number of samples.

### Note

- If the number of data points to be averaged has not reached the specified number of samples immediately after computation is started, the average of the available data is calculated.
- Computation error data is excluded from the rolling average computation.
- If the computed data exceeds the upper or lower limit, the data is clipped at the upper or lower limit, and the rolling average is computed. The upper and lower limit is “±100000000” excluding the decimal point. The decimal place is the same as that of the span lower limit.

- **Memory sample > On/Off**

Turn On the target channels.

- **Math**

- **Value on Error**

Specify whether to set the display for a computation error to **+Over** or **–Over**.
- **Value on Overflow > SUM, AVE**

Specify how to handle overflow data when it is detected in the SUM or AVE computation of TLOG or CLOG. This setting is also applied to report generation.

Settings	Description
Error	Sets the computed result to computation error.
Skip	Discards the overflow data and continues the computation.
Limit	Uses a limit value in place of the overflow data and continues the computation.

- **Value on Overflow > MAX, MIN, P-P**

Specify how to handle overflow data when it is detected in the MAX, MIN, or P-P computation of TLOG or CLOG. This setting is also applied to report generation.

Settings	Description
Over	Uses the overflow data as-is.
Skip	Discards the overflow data and continues the computation.

## 9.2 Writing Expressions

This section explains the meaning and how to write expressions.

### Common Items

Follow the rules below when writing expressions.

- Use up to 120 characters to write expressions.
- The precedence of computing terms can be specified using parentheses.
- Specify the channels in the expression using channel numbers.  
Example: 1, 12, 101, and 201
- The one-digit number of constants (K), communication input data (C), remote input terminal status (D), pulse input (P, Q), internal switch (S), alarm output relay status (I), and flag (F) in the expression can be denoted as in "01" and "1."  
Example: K01, K1, C01, C1, D01, D1, P01, P1, Q01, Q1, S01, S1, I01, I1, F01, and F1.
- The data of the previous scan is used in the computation for its own channel number and channel numbers greater than its own channel number in the expression.
- Special computation (HOLD, RESET, and CARRY) and conditional expressions are written at the beginning of the expression.

### Order of Precedence in Computations

The order of precedence of computation in expressions is as follows:

Type	Computing Element
	(high order of precedence)
Function	ABS(), SQR(), LOG(), LN(), EXP(), TLOG.MAX(), TLOG.MIN(), TLOG.AVE(), TLOG.SUM(), TLOG.P-P(), CLOG.MAX(), CLOG.MIN(), CLOG.AVE(), CLOG.SUM(), CLOG.P-P()
Special computation and conditional expression	PRE, HOLD, RESET, CARRY, [a?b:c]
Power	**
Logical negation	NOT
Multiplication and division	*, /
Addition and subtraction	+, -
Greater than and less than	.GT., .LT., GE., LE.
Equal and not equal	.EQ., .NE.
Logical product	AND
Logical sum and exclusive logical sum	OR, XOR
	(low order of precedence)

### Limitations

The following limitations exist in writing expressions.

Type	Limitations
TLOG computation	A computing element cannot be written inside the parentheses. Only one TLOG computation can be specified in a single expression.
CLOG computation	Number of channels that can be written in the parentheses is 30 channels or less. A computing element cannot be written inside the parentheses. Only one CLOG computation can be specified in a single expression.
PRE	A computing element cannot be written inside the parentheses.
HOLD(a):b	Can only be written at the beginning of an expression. Only one HOLD computation can be specified in a single expression.
RESET(a):b	Can only be written at the beginning of an expression. Only one RESET computation can be specified in a single expression.
CARRY(a):b	Can only be written at the beginning of an expression. Only one CARRY computation can be specified in a single expression. Only TLOG.SUM can be written in "b."
Conditional equation [a?b:c]	RESET, CARRY, or HOLD cannot be written to "a," "b," or "c." Other computing elements cannot be combined (example: [a?b:c]+001). However, conditional equations can be specified for a, b, and c.

### Four Arithmetic Operation

**Expression Example**

- Addition 001+002  
(Determines the sum of the measured values of channel 1 and channel 2.)
- Subtraction 001-002  
(Determines the difference of the measured values of channel 1 and channel 2.)
- Multiplication 001\*K03  
(Multiplies constant K03 to the measured value of channel 1.)
- Division 001/K02  
(Divides the measured value of channel 1 by constant K02.)

### Power and Other Computations

**Expression Example**

- Power 001\*\*002  
(Determines the measured value of channel 1 to the power of the measured value of channel 2.)
- Square root SQR(002)  
(Determines the square root of the measured value of channel 2.)
- Absolute value ABS(002)  
(Determines the absolute value of the measured value of channel 2.)
- Common logarithm LOG(001)  
(Determines the common logarithm (log10) of the measured value of channel 1.)
- Natural logarithm LN(001)  
(Determines the natural logarithm of the measured value of channel 1.)
- Exponent EXP(001)  
(Determines e to the power of the measured value of channel 1.)

### Relational Computation

**Expression Example**

**002.LT.003**

If the measured value of channel 2 is less than the measured value of channel 3, the computed result is "1." Otherwise, the result is "0."

**002.GT.003**

If the measured value of channel 2 is greater than the measured value of channel 3, the computed result is "1." Otherwise, the result is "0."

**002.EQ.003**

If the measured value of channel 2 is equal to the measured value of channel 3, the computed result is "1." Otherwise, the result is "0."

**002.NE.003**

If the measured value of channel 2 is not equal to the measured value of channel 3, the computed result is "1." Otherwise, the result is "0."

**002.GE.003**

If the measured value of channel 2 is greater than or equal to the measured value of channel 3, the computed result is "1." Otherwise, the result is "0."

**002.LE.003**

If the measured value of channel 2 is less than or equal to the measured value of channel 3, the computed result is "1." Otherwise, the result is "0."

## Logical Computation

Checks whether the two data values, e1 and e2 (e1 only for NOT), are zeroes or non-zeroes, and computes according to the conditions.

### AND

Logical product

(Syntax) e1ANDe2

(Condition) If the two data values e1 and e2 are both non-zeroes, the computed result is "1." Otherwise, it is "0."

(Explanation)

e1 = 0, e2 = 0	→	e1ANDe2 = 0
e1 ≠ 0, e2 = 0	→	e1ANDe2 = 0
e1 = 0, e2 ≠ 0	→	e1ANDe2 = 0
e1 ≠ 0, e2 ≠ 0	→	e1ANDe2 = 1

### OR

Logical sum

(Syntax) e1ORe2

(Condition) If the two data values e1 and e2 are both zeroes, the computed result is "0." Otherwise, it is "1."

(Explanation)

e1 = 0, e2 = 0	→	e1ORe2 = 0
e1 ≠ 0, e2 = 0	→	e1ORe2 = 1
e1 = 0, e2 ≠ 0	→	e1ORe2 = 1
e1 ≠ 0, e2 ≠ 0	→	e1ORe2 = 1

### XOR

Exclusive OR

(Syntax) e1XORe2

(Condition) If the two data values e1 and e2 are zero and non-zero or non-zero and zero, the computed result is "1." Otherwise, it is "0."

(Explanation)

e1 = 0, e2 = 0	→	e1XORe2 = 0
e1 ≠ 0, e2 = 0	→	e1XORe2 = 1
e1 = 0, e2 ≠ 0	→	e1XORe2 = 1
e1 ≠ 0, e2 ≠ 0	→	e1XORe2 = 0

### NOT

Logical negation

(Syntax) NOTe1

(Condition) The result is the inverse of the status of data e1 (zero or non-zero).

(Explanation)

e1 = 0	→	NOTe1 = 1
e1 ≠ 0	→	NOTe1 = 0

### Expression Example

01-02OR03.GT.04

Determines the OR of the computed results of "01-02" and "03.GT.04".

## TLOG Computation

In the explanation below, an expression containing a computing element in e1, an internal switch (S), a relay (I), or flag (F) cannot be written. In addition, only one TLOG computation can be specified in a single computing equation.

### TLOG.MAX( )

Maximum value

(Syntax) TLOG.MAX(e1)

(Condition) Determines the maximum value of channel e1.

### TLOG.MIN( )

Minimum value

(Syntax) TLOG.MIN(e1)

(Condition) Determines the minimum value of channel e1.

### TLOG.AVE( )

Average value

(Syntax) TLOG.AVE(e1)

(Condition) Determines the average value of channel e1.

### TLOG.SUM( )

Sum value

(Syntax) TLOG.SUM(e1)

(Condition) Determines the sum of channel e1.

### TLOG.P-P( )

Maximum - minimum value

(Syntax) TLOG.P-P(e1)

(Condition) Determines the maximum - minimum value of channel e1.

### Expression Example

TLOG.MAX(01)+K01\*SQR(02)

### Examples of Equations That Are Not Allowed

TLOG.AVE(01)+TLOG.AVE(02)

Reason: TLOG appears twice in one equation.

TLOG.AVE(ABS(01))

Reason: A computing element is used inside the parentheses.

## CLOG Computation

Only data of measurement channels, computation channels, and external input channels can be used in the CLOG computation. Up to 30 channels can be written in the parentheses.

In the explanation below, an expression containing a computing element cannot be written to e1, etc. In addition, only one CLOG computation can be specified in a single computing equation.

### CLOG.SUM( )

Sum value

(Syntax) CLOG.SUM(e1.e2.e4-e6)

(Condition) Determines the sum of the data of channels e1, e2, e4, e5, and e6 that are measured at the same time.

### CLOG.MAX( )

Maximum value

(Syntax) CLOG.MAX(e1.e2.e4-e6)

(Condition) Determines the maximum value among the data of channels e1, e2, e4, e5, and e6 that are measured at the same time.

### CLOG.MIN( )

Minimum value

(Syntax) CLOG.MIN(e1.e2.e5.e7)

(Condition) Determines the minimum value among the data of channels e1, e2, e5, and e7 that are measured at the same time.

### CLOG.AVE( )

Average value

(Syntax) CLOG.AVE(e1-e6)

(Condition) Determines the average value among the data of channels e1 to e6 that are measured at the same time.

### CLOG.P-P( )

Maximum - minimum value

(Syntax) CLOG.P-P(e1.e2.e5.e7)

(Condition) Determines the difference between the maximum and minimum values among the data of channels e1, e2, e5, and e7 that are measured at the same time.

### Expression Example

CLOG.MAX(001.002.I04-I06)+K01\*SQR(002)

### Examples of Equations That Are Not Allowed

CLOG.AVE(001.003.005)+CLOG.AVE(002.004.006)

Reason: CLOG appears twice in one equation.

CLOG.AVE(001.ABS(001))

Reason: A computing element is used inside the parentheses.

## Special Computation

### PRE( )

(Syntax) PRE(e1)  
 (Condition) Determines the previous value of e1.

### HOLD(a):b

(Syntax) HOLD(a):b  
 (Condition) When a is zero, b is carried out to derive the computed value. Otherwise, the previous computed value is held.

### RESET(a):b

(Syntax) RESET(a):b  
 (Condition) When a is zero, b is carried out to derive the computed value. Otherwise, the previous computed value of b is reset, and b is carried out to derive the computed value.

### CARRY(a):b

(Syntax) CARRY(a):b  
 (Condition) Only TLOG.SUM can be specified for b. If the computed value X of b is less than a, the computed result is X. If X is greater than or equal to a, the computed result is the excess (X – a).  
 (Description) When a value such as the flow rate is summed and the threshold value is reached or exceeded, the sum value is reset while carrying over the amount that exceeded the threshold value.

### Expression Example

Expression that sums the values of channel 1 and resets the value when it reaches or exceeds 10000  
 K01 = 10000  
 CARRY(K01):TLOG.SUM(001)

### Examples of Equations That Are Not Allowed

002+HOLD(K01):TLOS.SUM(001)  
 Reason: HOLD is not at the beginning of the expression.

RESET(101.GT.K01):TLOG.SUM(001)+RESET(101.GT.K01):002  
 Reason: RESET appears twice in one equation.

## Conditional Expression

### [a?b:c]

(Syntax) [001.GT.K01?002:003]  
 (Condition) If the measured value of channel 1 is greater than constant K01, the computed result is the measured value of channel 2. Otherwise, the computed result is the measured value of channel 3.

### Examples of Equations That Are Not Allowed

[001.GT.K01?002:003]\*K02  
 Reason: Used in combination with another computing element.

### Nested Conditional Expressions

A conditional expression can be written to Expression<sub>1</sub>, Expression<sub>2</sub>, and Expression<sub>3</sub> in the equation [Expression<sub>1</sub>?Expression<sub>2</sub>:Expression<sub>3</sub>]. For example, the following expression is allowed: [Equation<sub>1</sub>?[Equation<sub>2-1</sub>?Equation<sub>2-2</sub>:Equation<sub>2-3</sub>]:[Equation<sub>3-1</sub>?Equation<sub>3-2</sub>:Equation<sub>3-3</sub>]]  
 Expressions can be nested as long as the number of characters of the expression does not exceed 120 characters.



## 9.3 Displaying the Computation Channels


Computation channels can be assigned to groups and displayed in a similar manner to measurement channels.

For a description of the function, see section 1.8.

### Setup Screen


- **Color**

Press **MENU** (switch to the setting mode) and select **Math Channel > Color**




- **Zone Display, Scale Display, and Bar Graph Display**

Press **MENU** (switch to the setting mode) and select **Math Channel > Zone, Scale, Bar graph**



- **Partial Expanded Display**


Press **MENU** (switch to the setting mode) and select **Math Channel > Partial**



### 9.3 Displaying the Computation Channels

- **Alarm Marks and Color Scale Band**

Press **MENU** (switch to the setting mode) and select **Math Channel > Alarm mark, Color scale band**



#### Setup Items


- **Channel Numbers, First-CH, and Last-CH**  
Select the target channel range.
- **Channel Display Color**  
See section 5.5.
- **Zone Display**  
See section 5.6.
- **Partial Expanded Display**  
See section 5.9.
- **Bar Graph Display Method**  
See section 5.11.
- **Scale**  
See section 5.7.
- **Alarm Marks and Color Scale Band**  
See section 5.8.

## 9.4 Starting/Stopping Computation, Resetting Computation, and Releasing Computation Data Dropout Display

### Setup Screen

- **Action Taken When the START Key Is Pressed**

Press **MENU** (switch to the setting mode) and select **Math Channel > Math start action**



### Setup Items

- **Math start action > Math start**

Settings	Description
Off	Does not start the computation even when the START key is pressed.
Start	Starts the computation when the START key is pressed.
Rst+St	Resets the computed result up to then and starts the computation when the START key is pressed.

### Procedure

- **Starting the Computation**

- **Starting the Computation Simultaneously with the Memory Sampling**

Press **START**. Computation starts simultaneously with the start of the memory sampling. The computation icon appears in the status display section.

\* **Math start** must be set to **Start** or **Rst+St**.

- **Starting Only the Computation**

1. In the operation mode, press **FUNC**.

The FUNC key menu appears.

2. Press the **Math start** soft key.


Computation starts, and the computation icon is displayed in the status display section.

## 9.4 Starting/Stopping Computation, Resetting Computation, and Releasing Computation Data Dropout Display

- **Stopping the Computation**
  - **Stopping the Computation Simultaneously with the Memory Sampling**

1. Press **STOP**.

A confirmation dialog box appears.



2. Select **Mem+Math** and press **DISP/ENTER**.

The memory sampling and computation stop, and the computation icon in the status display section disappears.

- **Stopping Only the Computation**

1. In the operation mode, press **FUNC**.

The FUNC key menu appears.

2. Press the **Math stop** soft key.

The computation stops, and the computation icon in the status display section disappears.

### Note

When the computation is stopped, the computed data of the computation channel is held at the value that existed immediately before the computation is stopped. When memory sampling is in progress, the held value is recorded.

- **Resetting the Computed Results on All Computation Channels**

This operation can be carried out when the computation is stopped. You can carry out this operation even while the computation is in progress on DXs with release number 2 or later.

1. In the operation mode, press **FUNC**.

The FUNC key menu appears.

2. Press the **Math reset** soft key.

The computed results of all computation channels are reset.

- **Releasing the Computation Data Dropout Display**

This operation can be carried out when a computation data dropout occurs. When a computation data dropout occurs, the computation icon turns yellow.

1. In the operation mode, press **FUNC**.

The FUNC key menu appears.

2. Press the **Math ACK** soft key.

The computation icon returns to white.

\* **Math ACK** is displayed in the FUNC key menu only when a computation data dropout occurs.

### Note

A computation data dropout occurs when the computation process cannot be completed within the scan interval. If computation data dropout occurs frequently, lessen the load on the CPU by reducing the number of computation channels or setting a longer scan interval. If a computation data dropout occurs during memory sampling, the data immediately before the dropout is recorded as the computed data of the scan interval in which the dropout occurred.

## 9.5 Creating Reports

Set how the reports are created.

For a description of the function, see section 1.8.

### Setup Screen

- **Report Computation Type**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Environment > Math, Report**

The screenshot shows the 'Basic Setting Mode' interface. At the top, it says 'Basic Setting Mode' and 'Ethernet Link'. Below that, the navigation path is 'Environment > Math, Report'. The main area is divided into two sections: 'Math' and 'Report'.  
 In the 'Math' section, there are three rows of settings:  
 - 'Value on Error' is set to '+Over'.  
 - 'Value on Overflow' is set to 'Skip'.  
 - 'MAX, MIN, P-P' is set to 'Over'.  
 In the 'Report' section, there are four rows:  
 - 'Report select' has a dropdown menu with 'Ave' selected.  
 - '1' is set to 'Ave'.  
 - '2' is set to 'Max'.  
 - '3' is set to 'Min'.  
 - '4' is set to 'Sum'.  
 - 'File type' is set to 'Separate'.  
 At the bottom, there is a row of buttons: Max, Min, Ave, Sum, and Inst.

- **Report Type and Time of Creation**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Report > Basic settings**

The screenshot shows the 'Basic Setting Mode' interface. At the top, it says 'Basic Setting Mode' and 'Ethernet Link'. Below that, the navigation path is 'Report > Basic settings'. The main area is titled 'Report set' and contains three rows:  
 - 'Report kind' is set to 'Hour+Day'.  
 - 'Date' is set to '1'.  
 - 'Time (hour)' is set to '0 :00'.  
 At the bottom, there is a row of buttons: Off, Hour, Day, Hour+Day, Day+Week, and Day+Month.

- **Source Channels**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Report > Report settings**

The screenshot shows the 'Basic Setting Mode' interface. At the top, it says 'Basic Setting Mode' and 'Ethernet Link'. Below that, the navigation path is 'Report > Report settings'. The main area contains:  
 - 'Report Channel number' is set to 'R01'.  
 - A section titled 'Report CH' with three rows:  
 - 'On/Off' is set to 'On'.  
 - 'Channel' is set to '1'.  
 - 'Sum scale' is set to '/s'.  
 At the bottom, there is a row of buttons: R01, R02, R03, R04, R05, R06, and Next 1/10.

**Setup Items**

- **Report > Report select > 1, 2, 3, and 4**

Select the type of data to output as reports.

Settings	Description
Off	Does not output reports.
Ave	Outputs the average value.
Max	Outputs the maximum value.
Min	Outputs the minimum value.
Sum	Outputs the sum value.
Inst	Outputs the instantaneous value.

- **Report > File type**

Set this item when creating two types of reports such as daily report and monthly report.

Settings	Description
Separate	Saves each type of report to a separate file.
Combine	Saves the report data of two types in a single file.

- **Report set > Report kind**

Select the type of report to be created.

Settings	Description
Hour	Creates hourly reports.
Day	Creates daily reports.
Hour+Day	Creates hourly and daily reports.
Day+Week	Creates daily and weekly reports.
Day+Month	Creates daily and monthly reports.

- **Report set > Date/Day of the week and Time (hour)**

Set the date or day of the week and the time when the report is to be created. The specified date/time is when the report file is divided. Set the values in the range indicated below. Items with a dash are invalid.

Report Type	Date	Day of Week	Time
Hour	-	-	0 to 23
Day	1 to 28*	-	0 to 23
Hour+Day	-	-	0 to 23
Day+Week	-	SUN to SAT	0 to 23
Day+Month	1 to 28*	-	0 to 23

\* You cannot specify 29, 30, or 31.

**Report Time and Date/Time When the Report File Is Divided**

Example: When the Date of a daily report is set to 1 and the Time (hour) is set to 18:00

A daily report is created every day at hour 18.

The file storing the report is divided at 18:00 on day 1 of each month.

- **Report Channel number**  
The report is output in order by this number.
- **Report CH > On/Off**  
Select **On** for the report channels to be used.
- **Report CH > Channel**  
Set the channel to assign to the report channel. All channels can be assigned, but reports are not created for channels set to **Skip** or **Off** even if they are assigned.
- **Report CH > Sum scale**  
Set the sum scale to **/s** to **/day** to match the unit of the measured value.  
Example: If the unit of the measured value is “m<sup>3</sup>/min,” select **/min**.  
Off: Sums as-is the measured data per scan interval.
- **Handling of Overflow Data**  
See section 9.1.

### Procedure

- **Starting/Stopping the Report Function**  
Starting the memory sampling starts the report function. Likewise, stopping the memory sampling stops the report function.
- **Displaying the Reports**  
See section 4.5.
- **Saving the Reports**  
See section 1.4.


# 10.1 Setting External Input Channels

External input channels can be used on the DX2010, DX2020, DX2030, DX2040, and DX2048. The data of other devices loaded using the communication function can be displayed on the DX and saved.

## Setup Screen

- **Setting the Input**

Press **MENU** (switch to the setting mode), hold down **FUNC** for 3 s (switch to the basic setting mode), and select **Communication (Ethernet)** or **Communication (Serial) > Modbus client or Modbus master > Command settings**




- **Input Range and Alarm**

Press **MENU** (switch to the setting mode) and select **Ext. Channel > Range, Alarm**



- **Tag, Memory Sample, and Alarm Delay Time**

Press **MENU** (switch to the setting mode) and select **Ext. Channel > Tag, Memory sample, Alarm delay**





**Setup Items**

- **Channels to Manual Sample**

See section 6.5.

- **Setting the Input**

The measured values of external instruments are loaded using the Modbus client or Modbus master function to be used as external input channel inputs.

For the setup procedure, see the *Communication Interface User's Manual (IM04L41B01-17E)*.

- **First-CH/Last-CH**

Select the target channels. Channel numbers are 201 to 440.

- **Ext. range > On/Off**

Select **On** to use the external input channel.

- **Ext. range > Span Lower and Span Upper**

Measurement range.

Selectable range of values: -30000 to 30000

Decimal place: Down to four digits to the left of the decimal point

- **Ext. range > Unit**

Set the unit. (Up to 6 characters, **Aa#1**)

- **Alarm**

The available alarm types are high limit alarm, low limit alarm, delay high limit alarm, and delay low limit alarm.

The range of alarm values is as follows:

Type	Value	Example of a Range of Alarm Values
H, L	Within -30000 to 30000 excluding the decimal point.	Within -3000.0 to 3000.0 when the span is 0.0 to 100.0.
T, t	Same as H and L	Same as H and L

For details on setting alarms, see section 3.7.

\* If the external input channel On/Off or span setting is changed, the alarms for that channel are turned **Off**.

- **Alarm delay > Time**

For details on setting the alarm delay time, see section 3.7.

- **Tag**

For details on setting tags, see section 5.2.

- **Memory sample > On/Off**

Turn **On** the target channels.


## 10.2 Displaying the External Input Channels

External input channels can be assigned to groups and displayed in a similar manner to measurement channels. See chapter 5.

### Setup Screen


- **Channel Display Color**

Press **MENU** (switch to the setting mode) and select **Ext. Channel > Color**




- **Zone Display, Scale Display, and Bar Graph Display**

Press **MENU** (switch to the setting mode) and select **Ext. Channel > Zone, Scale, Bar graph**



- **Partial Expanded Display**


Press **MENU** (switch to the setting mode) and select **Ext. Channel > Partial**



## 10.2 Displaying the External Input Channels

- **Alarm Marks and Color Scale Band**

Press **MENU** (switch to the setting mode) and select **Ext. Channel > Alarm mark, Color scale band**



### Setup Items

- **First-CH/Last-CH**  
Select the target channel range. Channel numbers are 201 to 440.
- **Channel Display Color**  
See section 5.5.
- **Zone Display**  
See section 5.6.
- **Partial Expanded Display**  
See section 5.9.
- **Bar Graph Display Method**  
See section 5.11.
- **Scale**  
See section 5.7.
- **Alarm Marks and Color Scale Band**  
See section 5.8.

## 11.1 A List of Messages

There are cases in which error codes and messages are displayed on the screen during operation. A list of the possible error codes and messages are given in the table below. Communication error codes and messages are also listed.

Error responses to communication commands are output in English.

### Errors Related to Parameter Settings

#### • Setting Errors

Code	Message	Explanation/Countermeasures/Ref. section
1	System error.	Contact your nearest YOKOGAWA dealer.
2	Incorrect date or time setting.	Enter a correct value.
3	A disabled channel is selected.	Specify a channel that is not set to Skip or Off. Specify a channel that is installed.
4	Incorrect function parameter.	See Communication Interface User's Manual.
5	The input numerical value exceeds the set range.	Enter a proper value.
6	Incorrect input character string.	Enter a proper character string.
7	Too many characters.	Enter the correct number of characters.
8	Incorrect input mode.	Specify a correct mode. See section 3.3.
9	Incorrect input range code.	Specify a correct range code. See section 3.3.
11	Range settings are not same within the selected channels.	Specify channels with the same range setting. See section 3.9.
21	Cannot set an alarm for a skipped channel.	Cannot be specified on channels set to Skip. See section 3.7.
22	The upper and lower span limits are equal.	Cannot be set to the same value. See section 3.3.
23	The upper and lower scale limits are equal.	Cannot be set to the same value. See section 3.3.
24	The lower limit of the span band is greater than the upper limit.	Set the lower limit less than the upper limit. See section 3.3.
25	The lower limit of the scale band is greater than the upper limit.	Set the lower limit less than the upper limit. See section 3.3.
30	The partial boundary value exceeds the range of the span.	See section 5.9.
31	Partial-expansion display is set ON for a SKIPPED channel.	Cannot be specified on channels set to Skip.
35	The upper and lower limits of the display band are equal.	Set the upper limit greater than the lower limit + 5. See section 5.6.
36	The lower limit of the display band is greater than the upper limit.	Set the upper limit greater than the lower limit + 5. See section 5.6.
37	The display band is narrower than 4% of the entire display.	Set the upper limit greater than the lower limit + 5. See section 5.6.
40	Incorrect group set character string.	See section 5.1.
41	There is no specified input channel.	Specify a channel that is installed.
42	Exceeded the number of channels which can be set.	Up to 10 channels per group.
43	A channel number cannot repeat in a group.	See section 5.1.
45	There is no character string saved in the clipboard.	Copy a character string to the clipboard.
46	The character string saved in the clipboard is too long.	Paste a character string with the specified number of characters.
47	Start and end time cannot match.	See section 2.1.
48	Invalid or missing DST time settings.	See section 2.1.
61	There is no channel specified by the MATH expression.	See section 9.1.

## 11.1 A List of Messages

Code	Message	Explanation/Countermeasures/Ref. section
62	MATH expression grammar is incorrect.	See section 9.2.
63	MATH expression sequence is incorrect.	See section 9.2.
64	MATH upper and lower span values are equal.	Set the upper limit not equal to the lower limit.
65	Too many operators for MATH expression.	See section 9.2.
70	Nonexistent constant specified in MATH expression.	See section 9.2.
71	Set range of the MATH constant is exceeded.	See section 9.1.
80	This username is already registered.	See section 8.2.
81	All space or 'quit' string cannot be specified.	See section 8.2.
84	The login password has not been set up.	See section 8.2.
85	The login password is incorrect.	See section 8.3.
86	The key-lock release password is incorrect.	See section 8.1.
87	This key is locked.	See section 8.1.
88	This function is locked.	See section 8.1.
89	Press [FUNC] key to login.	See section 8.3.
90	No permission to enter to the SETUP mode.	See sections 8.2 and 8.3.
91	Password is incorrect.	See sections 8.2 and 8.3.
92	Press [ESC] key to change to the operation mode.	Press the ESC key.
93	String including space or all space cannot be specified.	Spaces are not allowed in the Web browser user name and password.
94	More than one address cannot be specified.	Only a single sender is allowed.
95	Number entered exceeds channel number range. Use another command.	Check the syntax of the Modbus command. See Communication Interface User's Manual.
100	IP address doesn't belong to class A, B, or C.	See Communication Interface User's Manual.
101	The result of the masked IP address is all 0s or 1s.	See Communication Interface User's Manual.
102	SUBNET mask is incorrect.	See Communication Interface User's Manual.
103	The net part of default gateway is not equal to that of IP address.	See Communication Interface User's Manual.
105	This port number is already in use. Please enter a different number.	Enter a different port number for each function.
113	Password entered is incorrect.	Enter the correct password.
119	This user name is unable to use this mode.	Check the user privileges on the operation. See section 8.2.
120	Measured value is incorrect. (in ascending order)	See section 3.9.
122	Measured value exceeds the range setting.	See section 3.9.
125	Character entry cannot be performed.	The DX is not showing a display used to enter character strings.
126	You cannot use the same password.	Specify a different password.
127	Report kind overlaps and cannot be set up.	See section 9.5.
129	IP address is not set.	Set the IP address of the DX.
131	You have exceeded the available channel capacity.	You cannot connect more than 240 channels.
132	You have exceeded the available number of commands.	The maximum number of commands that can be sent is 16. The modules that can be set with a single command are consecutive modules that can be automatically set. Change the MW100 module configuration so that there are no empty slots.
133	External I/O auto setting information is not available.	Below are the possible causes. Check them. <ul style="list-style-type: none"> <li>• The MW100 is in calibration mode. Change to the setting mode or measurement mode.</li> <li>• The measurement module may not have been detected. Perform system reconfiguration.</li> <li>• There are no modules that can be automatically set. Check the modules.</li> <li>• An IP address has not been assigned to the MW100. Set the IP address.</li> <li>• The Modbus server of the MW100 is turned OFF. Turn ON the server.</li> </ul>
134	Auto setting has already been executed.	You cannot set an MW100 that has been automatically set.
135	External I/O cannot be found.	Check the Ethernet connection.
136	External I/O start cannot be executed.	The current MW100 settings do not allow the measurement to be started. Check the settings.
137	DNS for this device is not set.	Set the DNS of the DX.

- **Execution Errors**

Code	Message	Explanation/Countermeasures/Ref. section
150	This action is not possible because sampling is in progress.	Stop the memory sampling and then execute.
151	This action is not possible during sampling or calculating.	Stop the memory sampling and then execute.
152	This action is not possible because saving is in progress.	Wait until the saving is complete.
153	This action is not possible because formatting is in progress.	Wait until the formatting is complete.
154	Message not accepted because message limit was reached.	The limit is 50 messages.
155	The message is not written while sampling is stopped.	Start the memory sampling and then execute.
156	There are no channels to be saved to the memory.	Set the channels to be saved.
157	This function is not possible at this time.	Check the DX status.
158	Exceeds time deviation setting.	See section 2.3.
159	It is outside the postscript message write-in range.	See section 5.4.

## Operation Errors

- **Errors Related to the External Storage Medium**

Code	Message	Explanation/Countermeasures/Ref. section
200	Operation aborted because an error was found in media.	Use another storage medium or format it.
201	Not enough free space on media.	There is not enough free space on media or the number of directories exceeded the limit. Use another storage medium. See section 1.4.
202	Media is read-only.	Make it writable.
210	Media has not been inserted.	Insert a storage medium into the drive.
211	Media is damaged or not formatted.	Use another storage medium or format it.
212	Format error.	Try formatting again.
213	The file is read-only.	Access another file or make the file writable.
214	There is no file or directory.	Specified a file in which data is being added. Tried to save a file which does not exist in the internal memory.
215	Exceeded the allowable number of directories or files.	Replace a storage medium. Delete unneeded files and directories.
216	The file or directory name is incorrect.	Use alphanumeric characters and symbols.
217	Unknown file type.	Specify another file.
218	This directory or file now exists. Delete it or change the name.	See section 6.2.
219	Invalid file or directory operation.	Tried to delete multiple directory levels. Or, tried to delete a directory containing files. Delete the files and directories in the directory first before executing the operation.
220	The file is already in use. Try again later.	Wait until the file is accessible.
221	This action is not possible because FTP transmission is in progress.	Execute after FTP data transfer is complete.
222	Media is not recognized.	Remove and reset the storage medium.
230	There is no setting file.	Specify another file.
231	Abnormal setting exists in file.	Specify another file.

## 11.1 A List of Messages

---

### • Errors Related to the Historical Trend

232	There is no available data.	Appears when displaying historical trends. Specify another file.
233	The specified historical data do not exist.	Appears when switching to historical trend from information display. See section 4.5.
234	The specified channel is not assigned to the display group.	Appears when switching to trend, digital, or bar graph from overview. See sections 4.4 and 7.6.

---

### • Errors Related to E-mail and Web Server

260	IP address is not set or ethernet function is not available.	The IP address is not specified. Check the IP address.
261	SMTP server is not found.	Occurs when the SMTP server is specified by name. <ul style="list-style-type: none"><li>• Check the DNS setting.</li><li>• Check the SMTP server name.</li></ul>
262	Cannot initiate E-mail transmission.	<ul style="list-style-type: none"><li>• The host name of the DX is not correct. Check the host name.</li><li>• The port number of the SMTP server is not correct. Check the port number.</li></ul>
263	Sender's address rejected by the server.	Check the sender's address.
264	Some recipients' addresses are invalid.	Check the recipients' addresses.
265	SMTP protocol error.	May occur if a network failure (cable problems, duplicate addresses, network device failure, and so on) occurs in the middle of the e-mail transmission.
266	Ethernet cable is not connected.	Check the cable connection.
267	Could not connect to SMTP server.	<ul style="list-style-type: none"><li>• Check to see that the SMTP server is connected to the network.</li><li>• If the SMTP server name is specified using an IP address, check to see that the IP address is correct.</li></ul>
268	E-mail transmission request failed.	Contact your nearest YOKOGAWA dealer.
269	E-mail transfer error.	May occur if a network failure (cable problems, duplicate addresses, network device failure, and so on) occurs in the middle of the e-mail transmission.
275	The current image cannot be output to the Web.	The setup display cannot be output to the Web browser. This message is displayed on the Web browser.
276	Image data currently being created. Unable to perform key operation.	Try again a little later. This message is displayed on the Web browser.
277	Could not output screen to Web.	Failed to create the image. This message is displayed on the Web browser.

---

- **Errors Related to FTP Client**

For a description of the FTP client function of the DX, see the *Communication Interface User's Manual (IM 04L41B01-17E)*. The detail code does not appear in the error message on the screen. You can view the code on the FTP log display of the DX or using the FTP log output via communications.

Code	Message
280	<p>IP address is not set or FTP function is not available.</p> <p>Further details are provided by the character string that appears after error code 280.</p> <p><b>Character String and Details</b></p> <p><b>HOSTADDR</b> An IP address has not been assigned to the DX. Check the IP address.</p> <p><b>DORMANT</b> Internal processing error.*1</p> <p><b>LINK</b> Data link is disconnected. Check the cable connection.</p>
281	<p>FTP mail box operation error.</p> <p>Further details are provided by the character string that appears after error code 281.</p> <p><b>Character String and Details</b></p> <p><b>MAIL</b> Internal processing error.*1</p> <p><b>STATUS</b> Internal processing error.*1</p> <p><b>TIMEOUT</b> Internal processing error.*1</p> <p><b>PRIORITY</b> Internal processing error.*1</p> <p><b>NVRAM</b> Internal processing error.*1</p>
282	<p>FTP control connection error.</p> <p>Further details are provided by the character string that appears after error code 282.</p> <p><b>Character String and Details</b></p> <p><b>HOSTNAME</b> Failed the DNS lookup (search the IP address corresponding to the host name). Check the DNS setting and the destination host name.</p> <p><b>TCPIP</b> Internal processing error.*1</p> <p><b>UNREACH</b> Failed to connect to a control connection server. Check the address setting and that the server is running.</p> <p><b>OOBINLINE</b> Internal processing error.*1</p> <p><b>NAME</b> Internal processing error.*1</p> <p><b>CTRL</b> The control connection does not exist. Check that the server does not drop the connection and that it responds within the proper time period.</p> <p><b>IAC</b> Failed to respond in the TELNET sequence. Check that the server does not drop the connection and that it responds within the proper time period.</p> <p><b>ECHO</b> Failed to transmit data on the control connection. Check that the server does not drop the connection and that it responds within the proper time period.</p> <p><b>REPLY</b> Failed to receive data on the control connection. Check that the server does not drop the connection and that it responds within the proper time period.</p>



## 11.1 A List of Messages

---

---

### Character String and Details

---

#### SERVER

The server is not in a condition to provide the service.

Check that the server is in a condition in which service can be provided.

---

---

Code	Message
------	---------

---

283	FTP command was not accepted.
-----	-------------------------------

Further details are provided by the character string that appears after error code 283.

---

#### Character String and Details

---

##### USER

Failed to verify the user name.

Check the user name setting.

##### PASS

Failed to verify the password.

Check the password setting.

##### ACCT

Failed to verify the account.

Check the account setting.

##### TYPE

Failed to change the transfer type.

Check that the server supports the binary transfer mode.

##### CWD

Failed to change the directory.

Check the initial path setting.

##### PORT

Failed to set the transfer connection.

Check that the security function is disabled.

##### PASV

Failed to set the transfer connection.

Check that the server supports PASV commands.

##### SCAN

Failed to read the transfer connection settings.

Check that proper response to the PASV command is received from the server.

---

284	FTP transfer setting error.
-----	-----------------------------

Further details are provided by the character string that appears after error code 284.

---

#### Character String and Details

---

##### MODE

Internal processing error.\*1

##### LOCAL

Internal processing error.\*1

##### REMOTE

The destination file name is not correct.

Check that you have the authority to create or overwrite files.

##### ABORT

File transfer abort was requested by the server.

Check the server for the reason for the abort request.

---

Code	Message
285	<p>FTP data connection error.</p> <p>Further details are provided by the character string that appears after error code 285.</p> <p><b>Character String and Details</b></p> <p><b>SOCKET</b> Failed to create a socket for the transfer connection.<sup>*2</sup></p> <p><b>BIND</b> Failed the transfer connection command.<sup>*2</sup></p> <p><b>CONNECT</b> Failed the transfer connection.<sup>*2</sup></p> <p><b>LISTEN</b> Failed the transfer connection reception.<sup>*2</sup></p> <p><b>ACCEPT</b> Failed to accept the transfer connection.<sup>*2</sup></p> <p><b>SOCKNAME</b> Internal processing error.<sup>*1</sup></p> <p><b>RCV</b> Failed to receive data over the transfer connection.<sup>*2</sup></p> <p><b>SEND</b> Failed to send data over the transfer connection.<sup>*2</sup></p>
286	FTP file transfer error.
290	<p>SNTP access failure.</p> <p>Further details are provided by the character string that appears after error code 290.</p> <p><b>Character String and Details</b></p> <p><b>DORMANT</b> Internal processing error.<sup>*1</sup></p> <p><b>LINK</b> Data link is disconnected. Check the cable connection.</p>
291	<p>SNTP server does not respond.</p> <p>Further details are provided by the character string that appears after error code 291.</p> <p><b>Character String and Details</b></p> <p><b>TIMEOUT</b> Check that the server is running.<sup>*2</sup></p>
292	<p>Incorrect SNTP server setting.</p> <p>Further details are provided by the character string that appears after error code 292.</p> <p><b>Character String and Details</b></p> <p><b>HOSTNAME</b> Failed the DNS lookup (search the IP address corresponding to the host name). Check the DNS setting and the SNTP server name.</p> <p><b>TCPIP</b> Internal processing error.<sup>*1</sup></p>
293	<p>Invalid SNTP server reply.</p> <p>Further details are provided by the character string that appears after error code 293.</p> <p><b>Character String and Details</b></p> <p><b>SEND</b> A correct IP address has not been assigned to the DX. Check the IP address.</p> <p><b>BROKEN</b> There is a problem with the SNTP server. If this error occurs even after executing SNTP manually several times, check the SNTP server.</p>

## 11.1 A List of Messages

Code	Message
294	<p>No time correction because excess time deviation with SNTP server.</p> <p>Further details are provided by the character string that appears after error code 294.</p> <p><b>Character String and Details</b></p> <p><b>OVER</b></p> <p>This error occurs when periodic SNTP is executed by the auto setting of the clock and the clock is not adjusted because the time difference between the DX and the SNTP server is greater than or equal to 10 minutes.</p> <p>Check the time on the DX and the SNTP server.</p>
295	<p>IP address was released because DHCP setting is invalid.</p> <p>Further details are provided by the character string that appears after error code 295.</p> <p><b>Character String and Details</b></p> <p><b>REJECT</b></p> <p>Address obtained by DHCP is inappropriate.</p>
296	<p>DHCP access failure.</p> <p>Further details are provided by the character string that appears after error code 296.</p> <p><b>Character String and Details</b></p> <p><b>ESEND</b></p> <p>Failed to transmit to the DHCP.</p> <p><b>ESERVER</b></p> <p>DHCP server not found.</p> <p><b>ESERVFAIL</b></p> <p>No response from the DHCP server.</p> <p><b>ERENEWED</b></p> <p>Address renewal rejected.</p> <p><b>EEXTENDED</b></p> <p>Address lease extension rejected.</p> <p><b>EEXPIRED</b></p> <p>Address lease period expired.</p>
297	<p>Registration of the hostname to the DNS server failed.</p> <p>Further details are provided by the character string that appears after error code 297.</p> <p><b>Character String and Details</b></p> <p><b>INTERNAL</b></p> <p>Failed to register the host name (transmission error, reception timeout, etc.).</p> <p><b>FORMERR</b></p> <p>Failed to register the host name (format error: DNS message syntax error).</p> <p><b>SERVFAIL</b></p> <p>Failed to register the host name (server failure: DNS server processing error).</p> <p><b>NXDOMAIN</b></p> <p>Failed to register the host name (non-existent domain).</p> <p><b>NOTIMP</b></p> <p>Failed to register the host name (not implemented).</p> <p><b>REFUSED</b></p> <p>Failed to register the host name (operation refused).</p> <p><b>YXDOMAIN</b></p> <p>Failed to register the host name (name exists).</p> <p><b>YXRRSET</b></p> <p>Failed to register the host name (RR set exists).</p> <p><b>NXRRSET</b></p> <p>Failed to register the host name (RR set does not exist).</p> <p><b>NOTAUTH</b></p> <p>Failed to register the host name (not authoritative for zone).</p> <p><b>NOTZONE</b></p> <p>Failed to register the host name (different from zone section).</p> <p><b>NONAME</b></p> <p>Host name not entered on the DX.</p>

Code	Message
298	<p>Deletion of the hostname to the DNS server failed.</p> <p>Further details are provided by the character string that appears after error code 298.</p> <p><b>Character String and Details</b></p> <hr/> <p>INTERNAL Failed to delete the host name (transmission error, reception timeout, etc.).</p> <p>FORMERR Failed to delete the host name (format error: DNS message syntax error).</p> <p>SERVFAIL Failed to delete the host name (server failure: DNS server processing error).</p> <p>NXDOMAIN Failed to delete the host name (non existent domain).</p> <p>NOTIMP Failed to delete the host name (not implemented).</p> <p>REFUSED Failed to delete the host name (operation refused).</p> <p>YXDOMAIN Failed to delete the host name (name exists).</p> <p>YXRRSET Failed to delete the host name (RR set exists).</p> <p>NXRRSET Failed to delete the host name (RR set does not exist).</p> <p>NOTAUTH Failed to delete the host name (not authoritative for zone).</p> <p>NOTZONE Failed to delete the host name (different from zone section).</p> <p>NOTLINKED 4Physical layer was disconnected when removing the host name.</p>

\*1 Contact your nearest YOKOGAWA dealer.

\*2 These errors may occur if the network experiences trouble during the data transmission (bad cable connection, duplicate addresses, network equipment failure).

### **Note**

- The FTP client function on the DX has a timer function that drops the connection if there is no data transfer for two minutes. If the server does not respond within this time period, the transfer fails.
- The FTP client function on the DX overwrites files without a warning if files with the same name exist at the transfer destination unless the server returns a negative response.

### Communication Errors

For information regarding the communication function of the DX, see the *Communication Interface User's Manual (IM 04L41B01-17E)*.

- **Errors during Setting and Basic Setting Modes, Output Communication Command Execution, and Setup Data Loading**

Code	Message
300	Command is too long.
301	Too many number of commands delimited with ';'.
302	This command has not been defined.
303	Data request command can not be enumerated with sub-delimiter.
350	Command is not permitted to the current user level.
351	This command cannot be specified in the current mode.
352	The option is not installed.
353	This command cannot be specified in the current setting.
354	This command is not available during sampling or calculating.

- **Memory Access Errors during Setting and Basic Setting Modes and Output Communication Command Execution**

An English error message is returned via the communication interface. It is not displayed on the screen.

Code	Message
362	There are no data to send 'NEXT' or 'RESEND'.
363	All data have already been transferred.

- **Maintenance and Test Communication Command Errors**

An English error message is returned via the communication interface. It is not displayed on the screen.

Code	Message
390	Command error.
391	Delimiter error.
392	Parameter error.
393	No permission.
394	No such connection.
395	Use 'quit' to close this connection.
396	Failed to disconnect.
397	No TCP control block.
398	Format error.

- **Other Communication Errors**

An English error message is returned via the communication interface. It is not displayed on the screen.

Code	Message
400	Input username.
401	Input password.
402	Select username from 'admin' or 'user'.
403	Login incorrect, try again!
404	No more login at the specified level is acceptable.
410	Login successful. (The special user level)
411	Login successful. (The general user level)
420	Connection has been lost.
421	The number of simultaneous connection has been exceeded.
422	Communication has timed-out.

## 11.1 A List of Messages

---

### Status Messages

Code	Message
500	Execution is complete.
501	Please wait a moment...
503	Data are being saved to media...
504	File is being loaded from media...
505	Formatting...
506	Memory save to media was interrupted.
508	There is no file or directory.
509	Press [DISP/ENTER] key to display file name.
510	Range cannot be changed during sampling or calculating.
511	MATH expression cannot be changed during sampling or calculating.
513	Post process in progress.
514	Now loading historical data.
515	Data save is completed.
516	Files are now being sorted.
520	Connecting to the line...
521	The data file is being transferred.
530	Media can be removed safely.
531	Media was removed compulsorily.
532	USB device has been connected.
533	USB device cannot be recognized.
534	There was no data which is not saved to media.
535	Media was recognized.
536	Media is not recognized.
542	Media read error.
543	Flash write error.
550	The A/D calibration is being executed...
551	FTP test is being executed...
552	E-mail test is being executed...
560	Now connecting to SNTP server...
561	Now adjusting the time.

Code	Message
562	<p>Ethernet cable is disconnected.</p> <p>Further details are provided by the character string that appears after error code 562.</p> <p><b>Character String and Details</b></p> <p><b>ON</b> Detected that an Ethernet cable was connected.</p> <p><b>OFF</b> Detected that an Ethernet cable was disconnected.</p>
563	<p>The command is sent to DHCP.</p> <p>Further details are provided by the character string that appears after error code 563.</p> <p><b>Character String and Details</b></p> <p><b>RENEW</b> Requesting address renewal to the DHCP server.</p>
564	<p>The response was received from DHCP.</p> <p>Further details are provided by the character string that appears after error code 564.</p> <p><b>Character String and Details</b></p> <p><b>RENEWED</b> Address renewal complete.</p> <p><b>EXTENDED</b> Address release extension request complete.</p> <p><b>RELEASED</b> Address release complete.</p>
565	<p>IP address was set.</p> <p>Further details are provided by the character string that appears after error code 565.</p> <p><b>Character String and Details</b></p> <p><b>IPCONFIG</b> Assigned the IP address.</p>
566	<p>It is a setting that doesn't register hostname to the DNS server.</p> <p>Further details are provided by the character string that appears after error code 566.</p> <p><b>Character String and Details</b></p> <p><b>NOREQUEST</b> Configured not to register the host name.</p>
567	<p>The hostname was registered to DNS server.</p> <p>Further details are provided by the character string that appears after error code 567.</p> <p><b>Character String and Details</b></p> <p><b>UPDATE</b> Registered the host name to the DNS server.</p>
568	<p>The hostname was deleted from DNS server.</p> <p>Further details are provided by the character string that appears after error code 568.</p> <p><b>Character String and Details</b></p> <p><b>REMOVE</b> Assigned the IP address.</p> <p><b>OFF</b> Removed the host name from the DNS server.</p>



## 11.1 A List of Messages

---

### Warning Messages


Code	Message	Ref. Section
600	Measured data and Settings have been initialized.	–
601	Measured data have been initialized.	–
610	This user name is already registered.	See section 8.2.
614	Calibration settings are reset because of range setting change.	See section 3.9
615	Noise may influence measurement in test mode.	See section 3.1

### System Errors

Servicing is required when a system error occurs. If this happens, contact your nearest YOKOGAWA dealer for repairs.


Code	Message
901	ROM failure.
902	RAM failure.
910	A/D memory failure for all input channels.
911	Channel 1 A/D memory failure.
912	Channel 2 A/D memory failure.
913	Channel 3 A/D memory failure.
914	Channel 4 A/D memory failure.
921	Channel 1 A/D calibration value error.
922	Channel 2 A/D calibration value error.
923	Channel 3 A/D calibration value error.
924	Channel 4 A/D calibration value error.
930	Memory acquisition failure.
940	The Ethernet module is down.

## 11.2 Troubleshooting




11.2 Troubleshooting

- The error is large.
- The trend or digital values fluctuate.
- The trend is off the scale on either the 0% or 100% side.




O.G.: Operation Guide

Display and other functions do not work properly.



Some items on the display selection menu or FUNC key menu are not displayed.



## 12.1 Periodic Inspection

Check the operation periodically to keep the DX in good working order.

Perform the following checks and replace worn parts as needed.

- Is the display and storage functioning properly?  
If not, see chapter 11, “Troubleshooting” in the DX2000 User’s Manual.
- Has the brightness of the LCD backlight deteriorated?  
If replacement is necessary, see “Recommended Replacement Periods for Worn Parts.”

## 12.2 Calibrating the DX

It is recommended that the DX be calibrated once a year to assure its measurement accuracy.

Calibration service is also provided by YOKOGAWA dealers.

For details, contact your nearest YOKOGAWA dealer.

### Required Instruments

Calibration instruments with the following resolution are required for calibrating the DX.

#### Recommended Instruments

- DC voltage standard: 5520A by FLUKE or equivalent  
Main specifications  
Output accuracy:  $\pm(0.005\% + 1 \mu\text{V})$
- Decade resistance box: Yokogawa Meters & Instruments Model 2793-01 or equivalent  
Main specifications  
Accuracy of output range 0.1 to 500  $\Omega$ :  $\pm(0.01\% + 2 \text{ m}\Omega)$   
Resolution: 0.001  $\Omega$
- 0°C standard temperature device: ZC-114/ZA-10 by Coper Electronics or equivalent  
Main specifications  
Standard temperature stability accuracy:  $\pm 0.05^\circ\text{C}$

For information on purchasing the calibration instruments, contact your nearest YOKOGAWA dealer.


### Calibration Procedure

1. Wire the DX and the calibration instrument as shown in the following figure, and adequately warm up the instruments (the warm-up time of the DX is at least 30 minutes).
2. Check that the operating environment such as ambient temperature and humidity is within the standard operating conditions (see section 13.6).
3. Apply appropriate input signals corresponding to 0, 50, and 100% of the input range and calculate the errors from the readings.  
If the error does not fall within the accuracy range of the specifications, contact your nearest YOKOGAWA dealer.


#### Note

For thermocouple inputs, you must measure the temperature of the input terminal and apply a voltage taking into account the reference junction temperature.


#### DC Voltage Measurement (Example for the DX2010)



### Temperature Measurement When Using an RTD (Example for the DX2010)



### Temperature Measurement When Using a Thermocouple (Example for the DX2010)



(0°C standard temperature device ZC-114/ZA-10 by Coper Electronics)

#### RJC of TC Input

As the measurement terminal of the DX is generally at room temperature, the actual output of the thermocouple is different from the values given on the thermoelectromotive force table based on 0°C. The DX performs compensation by measuring the temperature at the input terminal and adding the corresponding thermoelectromotive force to the actual output of the thermocouple. Therefore, when the measurement terminal is shorted (equivalent to the case when the detector tip is 0°C), the measured value indicates the temperature of the input terminal.

When calibrating the DX, this compensation voltage (thermoelectromotive force of 0°C reference corresponding to the input terminal temperature) must be subtracted from the output of the standard generator before application. As shown in the figure, by using the 0°C standard temperature device to compensate the reference junction at 0°C, you can input the thermoelectromotive force of 0°C reference from the DC voltage standard and perform the calibration.

## 13.1 Signal Input and Alarm

### Measurement Input

#### Item Specifications

Number of inputs, scan interval, and A/D integration time

Model	Number of inputs	Scan interval		
		Normal mode		Fast sampling mode
DX2004	4	125 ms, 250 ms		25 ms
DX2008	8			
DX2010	10	1 s	2 s, 5 s	125 ms
DX2020	20			
DX2030	30			
DX2040	40			
DX2048	48			
Integration time of the A/D converter		60 Hz/50 Hz	60 Hz/50 Hz/100 ms	600 Hz (fixed)

Input Type DC voltage, 1-5V, thermocouple (TC), resistance temperature detector (RTD), ON/OFF input (DI), and DC current (by adding an external shut resistor)

Measurement range and measurable range

Input Type	Range	Measurable Range	
DC voltage	20 mV	-20.000 to 20.000 mV	
	60 mV	-60.00 to 60.00 mV	
	200 mV	-200.00 to 200.00 mV	
	2 V	-2.0000 to 2.0000 V	
	6 V	-6.000 to 6.000 V	
	20 V	-20.000 to 20.000 V	
	50 V	-50.00 to 50.00 V	
1-5V	1-5 V	0.800 to 5.200 V	
Thermocouple	R <sup>*1</sup>	0.0 to 1760.0°C	32 to 3200°F
	S <sup>*1</sup>	0.0 to 1760.0°C	32 to 3200°F
	B <sup>*1</sup>	0.0 to 1820.0°C	32 to 3308°F
	K <sup>*1</sup>	-200.0 to 1370.0°C	-328 to 2498°F
	E <sup>*1</sup>	-200.0 to 800.0°C	-328.0 to 1472.0°F
	J <sup>*1</sup>	-200.0 to 1100.0°C	-328.0 to 2012.0°F
	T <sup>*1</sup>	-200.0 to 400.0°C	-328.0 to 752.0°F
	N <sup>*1</sup>	0.0 to 1300.0°C	32 to 2372°F
	W <sup>*2</sup>	0.0 to 2315.0°C	32 to 4199°F
	L <sup>*3</sup>	-200.0 to 900.0°C	-328.0 to 1652.0°F
	U <sup>*3</sup>	-200.0 to 400.0°C	-328.0 to 752.0°F
	WRe <sup>*4</sup>	0.0 to 2400.0°C	32 to 4352°F
RTD	Pt (Pt100) <sup>*5</sup>	-200.0 to 600.0°C	-328.0 to 1112.0°F
	JPt (JPt100) <sup>*5</sup>	-200.0 to 550.0°C	-328.0 to 1022.0°F
DI	Level	0: Less than 2.4 V. 1: 2.4 V or higher (judged at the 6 V range)	
	Contact	0: Open. 1: Closed (parallel capacitance of 0.01 μF or less)	

\*1: R, S, B, K, E, J, T, N: IEC584-1 (1995), DIN IEC584, JIS C1602-1995

\*2: W: W-5%Re/W-26%Re (Hoskins Mfg. Co.), ASTM E988

\*3: L: Fe-CuNi, DIN43710, U: Cu-CuNi, DIN43710

\*4: WRe: W-3%Re/W-25%Re (Hoskins Mfg. Co.)

\*5: Pt100: JIS C1604-1997, IEC751-1995, DIN IEC751-1996

JPt100: JIS C1604-1989, JIS C1606-1989

Measuring current:  $i = 1\text{mA}$  (Pt100, JPt100)

Thermocouple burnout\* Burnout upscale/downscale selectable (for each channel).  
Normal: 2 kΩ or less., Burnout: 100 kΩ or more (parallel capacitance of 0.01 μF or less)  
Detection current: Approx. 10 μA

1-5 range burnout\* Burnout upscale/downscale selectable (for each channel).  
Burnout detection: Greater than "scale upper limit + 10% of scale width" or "scale lower limit - less than 5% of scale width"

TC reference junction compensation  
Internal reference junction compensation or external reference junction compensation

Moving average function Takes the moving average of the input values (for each channel). Moving average data points: 2 to 400

\* In fast sampling mode, burnouts on all measurement channels cannot be detected within a scan interval. Burnout may not be detected until the number of measurements indicated below is carried out if measurement is started in a burnout condition or after a burnout occurs.

DX2004 and DX2008: Up to 4 measurements. DX2010, DX2020, DX2030, DX2040, and DX2048: Up to 2 measurements



## 13.1 Signal Input and Alarm

Item	Specifications
Computation	
Difference computation	Computable range: DC voltage, TC, RTD, and DI
Linear scaling	Computable range: DC voltage, TC, RTD, and DI Scalable range: -30000 to 30000. The decimal place is within 4 digits to the right of the decimal point. Unit: 6 digits or less Over value detection: The value can be set to over value when $\pm 5\%$ of the scale range is exceeded.
Square root computation	Computable type: DC voltage Scalable range and unit: Same as linear scaling Low-cut: Set the low-cut value in the range of 0.0% to 5.0% of the span. Over value detection: Same as linear scaling
1-5V	Computable range: 1-5 Scalable range and unit: Same as linear scaling Low-cut: The low-cut point is fixed to the span lower limit. Over value detection: Same as linear scaling

## Alarms

Item	Specifications
Number of alarms	Up to four alarms (level) for each measurement channels
Alarm type	High limit, low limit, difference high limit, difference low limit, high limit on rate-of-change alarm, low limit on rate-of-change alarm, delay high limit, and delay low limit
Alarm delay time	1 to 3600 s (for each channel)
Rate-of-change calculation interval of rate-of-change alarms	1 to 32 times the scan interval (common to all channels)
Alarm output	Output to the internal switch Number of internal switches: 30 Internal switch operation: AND/OR operation selectable
Hysteresis	High and low limit alarm: 0.0 to 5.0% of the span (common to all channels) Difference high and low limit alarms: 0.0 to 5.0% of the span (common to all channels)
Display	Displays the status on the respective operation screen and an alarm icon on the status display section when an alarm occurs. Display operation: Hold or not hold the display until the alarm acknowledge operation.
Alarm hide function (alarm no logging function)	Not display alarms nor record to the alarm summary (for each channel)
Alarm information	Displays a log of alarm occurrences on the alarm summary.

## 13.2 Display Function

### Display

Item	Specifications
Display*	10.4-inch TFT color LCD (640 × 480 dots)
Brightness	6 levels
Backlight saver function	Dim or turn off the LCD backlight if there is no key operation for a specified time.

\* A section of the LCD monitor may contain pixels that are always on or off. The brightness of the LCD may also not be uniform due to the characteristics of the LCD. This is not a malfunction.

### Displayed Information

Item	Specifications
Display groups	Assign channels to groups on the trend display, digital display, and bar graph display and display.
Number of groups	36
Number of channels that can be assigned to each group	Up to 10
Display color	Channel: Select from 24 colors Background: Select white or black
Trend display (T-Y display)	
Waveform line width	Select from 1, 2, and 3 dots
Display method	Orthogonal axis display with time axis (T) and measured value axis (Y) Layout: Vertical, horizontal, wide, or split Trend interval: Select from 15 s/div (DX2004/DX2008 only) and available settings between 30 s/div and 10 h/div. Switchable to the secondary trend interval.
Scale	Display a scale for each channel. Current value bar graph, color scale band, and alarm point marks can be displayed on the scale.
Others	Grid (divisions: 4 to 12), trip line (line width: 1, 2, or 3 dots), message, zone display, and partial expanded display
Trend display (circular display)	
Display method	Time axis: Circle, Measured value axis: Perimeter Time per revolution: Select from the available settings between 20 min and 4 weeks (20 min available only on the DX2004 or DX2008).
Digital Display	Displays measured values numerically
Update rate	1 s (scan interval if the scan interval is greater than 1 s)
Bar graph display	
Direction	Vertical or horizontal
Base position	End or center
Update rate	1 s (scan interval if the scan interval is greater than 1 s)
Scale	Display a scale for each channel Color scale band, and alarm point marks can be displayed on the scale.
Historical trend display (T-Y display)	
	Redisplays the display data or event data in the internal memory or external storage medium.
Display format	All screen or half screen (only when the display data is being redisplayed)
Time axis operation	Reduce/expand and continuous data display possible.
Add message	Messages can be added.
Background color	Select from white, cream, black, or light gray.
Historical display (circular display)	
Display format	Full circle display and quarter cycle display
Others	Same as the historical trend display (T-Y display)
Overview Display	Displays the measured values of all channels and the alarm statuses (if the number of channels exceeds 261, the measured values are not displayed.)

## 13.2 Display Function

Item	Specifications
Information display	
Alarm summary display	Displays a log of up to 1000 alarms. Specify an alarm with the cursor and jump to the corresponding section on the trend display.
Message summary display	Time and content of up to 450 messages (including 50 add messages) Specify a message with the cursor and jump to the corresponding section on the trend display.
Memory summary display	Displays the information of the data in the memory. Specify a file with the cursor and jump to the corresponding section on the trend display. Save the data in the internal memory to the external storage medium using keys.
Report	Displays the report data residing in the internal memory.
Status Display	Relay status display: Displays the ON/OFF status of the alarm output relay and internal switch. Modbus client status: Displays the communication status on the Modbus client Modbus master condition: Displays the communication status on the Modbus master
Log display	Displays the login log, error log, communication log, FTP log, Web log, e-mail log, SNTP log, DHCP log, and Modbus log.
Four panel display	Divides the screen into four sections and displays four different display formats. Four combinations of screens can be registered.

## Other Displayed Information

Item	Specifications
Tag display	Up to 16 alphanumeric characters
Message	Write messages to the trend display.
Number of messages	100
Character	Up to 32 alphanumeric characters
Write method	Write a preset message or write an arbitrary message on the spot.
Write destination	Select only the displayed group or all groups.
Auto message	Write a message when the DX recovers from a power failure while memory sampling is in progress. Write a message when the trend interval is switched during memory sampling.
Add message	Write messages to the past data positions.
Number of messages	50
Status display section	Displays the DX status at the upper section of the display.
Displayed contents	Year, month, day, time, displayed group name/display name, user name (when using the login function), batch name (when using the batch function), internal memory status, external storage medium status, alarm status, and function usage status (key lock , computation function, and e-mail)
Auto switching of displayed groups	Switches the display group at a given interval. Interval: Select from the available settings between 5 s and 1 min.
Auto recovery display	Specify the display to be shown automatically when keys are not operated. Time until the display switches: Select from the available settings between 1 min and 1 h.
Favorite display	Register frequently used displays to the Favorite key and show them through simple operation. Up 8 displays can be registered.
Language	Select English, Japanese, German, French, or, Chinese.
System information display	Displays the number of measurement, computation, and external input channels, options, remote controller ID, MAC address, firmware version, and internal memory capacity.
Network information display	Displays the DX network setup information.
Display selection menu customization	Show/hide and change the positions of each item in the display selection menus and sub menus Insert/delete separators.
FUNC key menu customization	Show/hide and change the display positions of each item.

## 13.3 Data Saving Function

### Configuration

Item	Specifications
Internal memory	Temporarily saves various types of data.
Medium	Flash memory
External storage medium	
Medium	CF card (up to 2 GB)
Format	FAT32 or FAT16

### Data Type

Name	Description
Data type (file name extension)	Display data (.dad), event data (.dae), and manual sampled data (.dam) Screen image data (.png), setup data (.pdl), report data (.dar) (M1)

### Display Data and Event Data

Item	Specifications
Internal memory	
File storage capacity	80 MB (standard memory) or 200 MB (large memory)
Number of files	Up to 400
Operation	FIFO (First In First Out)
Display data	
Target	Measurement/computation/external input channel
Sampling interval	Synchronized to the trend interval.
Description	Maximum or minimum value per sampling interval
Data size	Measurement/External input channel data: 4 bytes/data value. Computation channel data: 8 bytes/data value.
File size	Up to 8 MB
Data format	Binary
Recording	Records data at all times.
Event data	
Target	Measurement/computation/external input channel.
Sampling interval	Select from the available settings between 25 ms to 600 s.
Description	Data per sampling interval
Data size	Measurement/External input channel data: 2 bytes/data value. Computation channel data: 4 bytes/data value.
File size	Up to 8 MB
Data format	Binary
Mode	Free: Records data at all times. Trigger: Starts recording data when a certain event occurs and records for the specified interval.
Combinations of saved data	Display data only, event data only, or display data and event data
File size	See appendix 1.

### 13.3 Data Saving Function

#### Manual Sampled Data

Item	Specifications
Item	Measured value at an arbitrary time Specify up to 120 channels when external input channels (/MC1) are used.
Data format	ASCII
Maximum number of data values that the internal memory can store	400

#### Report Data (/M1)

Item	Specifications
Item	Report at each scheduled time of report
Data format	ASCII
Maximum number of reports that the internal memory can store	100

#### Saving Data to the External Storage Medium

Item	Specifications
Data Saving	Saves the data in the internal memory to the external storage medium.
Manual save	Saves when the external storage medium is inserted with a key operation.
Auto save	Display data: Every file save interval Event data: Every data length Manual sampled data: When manual sampling is executed. Report data: When report is created.
Auto save operation	Select "save data only if there is sufficient free space on the CF card" or "constantly retain the most recent data files in the CF card (media FIFO)" (release number 2 or later).
File name	Select from "sequence number+user-assigned string+date," "sequence number+user-assigned string," or "sequence number+batch name."
Save destination	Auto save: CF card. Manual save: CF card or USB flash memory (/USB1) Directory name: Specify using up to 20 characters.

#### Snapshot Data

Item	Specifications
Item	Displayed screen image data
Data format	PNG
Output destination	CF card or communication output

#### Setup Data

Item	Specifications
Item	DX setup data
Data format	Binary
File name	Specify using up to 32 characters.
Output destination	CF card or USB flash memory (/USB1)
Load	Loadable from a CF card or USB flash memory (/USB1)

#### Data File Loading

Item	Specifications
Function	Load and show the display data or event data in a CF card or USB flash memory (/USB1).

#### Miscellaneous

Item	Specifications
Header comment	Add up to 50 characters of comment to display data, event data, manual sampled data, or report data file.

## 13.4 Other Standard Functions

### Event Action Function

Item	Specifications
Event action	Execute a specified operation when a given event occurs.
Number of settings	40
Events	Remote control input, etc.
Timer	Number of timers: 4
Match time timer	Number of timers: 4
Action	Specify memory start/stop, alarm ACK, etc.
	There are limitations on the combinations of events and actions.

### Security Function

Item	Specifications
Key lock function	Limitations to key operation, access to the external storage medium, and various operations
Login function	Allow DX operation to registered users.
System administrators	5 administrators
Users	30 users

### Time Related Functions

Item	Specifications
Clock	With a calendar function
Accuracy	$\pm 10$ ppm (0 to 50°C), excluding a delay (of 1 second, maximum) caused each time the power is turned on.
Time setting	Using key operation, communication command, event action function, or SNTP client function
Time adjustment method	
While memory sampling	Corrects the time by 40 ms for each second. Limit in which the time is gradually adjusted: Select from the available settings between 10 s and 5 min. If the time is outside the limit, the time is immediately corrected. Cannot be used after hour 0 on January 1st, 2038.
While memory is stopped	Immediately change the time.
DST	The date/time for switching between standard time and DST can be specified.
Time zone	Sets the time difference from GMT.
Date format	Select YYYY/MM/DD, MM/DD/YYYY, DD/MM/YYYY, or DD.MM.YYYY.

### Types of Characters That Can Be Handled

Item	Specifications
Characters	Alphabet characters, numbers, and symbols (limitation exists)

## 13.4 Other Standard Functions

### Communication Functions

Item	Specifications
Electrical and mechanical specifications	Conforms to IEEE 802.3 (Ethernet frames conform to the DIX specification).
Medium	Ethernet (10BASE-T)
Implemented protocols	TCP, IP, UDP, ICMP, ARP, DHCP, HTTP, FTP, SMTP, SNTP, Modbus, and DX-dedicated protocols
E-mail client	Automatically send e-mail at specified times.
FTP client	Automatically transfer data files to the FTP server. Applicable files: Display data, event data, screen image data, and report data
FTP Server	Transfer files, delete files, manipulate directories, and output file lists of the DX.
Web server	Shows the DX display on a Web browser.
SNTP client	Inquires the time to the SNTP server and sets the DX. Cannot be used after hour 0 on January 1st, 2036.
SNTP server	Outputs the DX time. Time resolution: 5 ms Cannot be used after hour 0 on January 1st, 2036.
DHCP client	Automatically obtain the network address settings from the DHCP server.
Modbus client	Reads data from another device and writes to the registers.
Modbus server	Outputs the DX data.
Setting/Measurement server	Operate, set, and output data of the DX using a dedicated protocol.
Maintenance/test server	Outputs connection information and network information.
Instrument information server	Outputs information (serial number, model name, etc.) of the connected DX.

### Batch Function

Item	Specifications
Function	Data management using batch names. Enter text fields and batch comments in the data file.
Batch name	Added to the file name of the display data and event data.
Structure	Batch number (up to 32 characters) + lot number (up to 8 digits)
Text field	Adds text to the display data and event data.
Batch comment	Adds text to the display data and event data.

## 13.5 Options

### Alarm Output Relay (/A1, /A2, /A3, /A4, and /A5)

Item	Specifications
Action	Outputs relay contact signals from the terminals on the rear panel when alarms occur.
Number of outputs	2 outputs (/A1), 4 outputs (/A2), 6 outputs (/A3), 12 outputs (/A4), and 24 outputs (/A5)
Relay contact rating	250 VAC (50/60 Hz)/3 A, 250 VDC/0.1 A (for resistance load)
Output format	NO-C-NC
Relay operation	Energized/deenergized, AND/OR, hold/non-hold, and reflash settings are selectable.

### RS-232 Interface (/C2) and RS-422A/485 Interface (/C3)

Item	Specifications
Connection	EIA RS-232(/C2) or EIA RS-422A/485(/C3)
Protocol	Dedicated protocol or Modbus protocol
Synchronization	Start-stop synchronization
Transmission mode (RS-422A/485)	Four-wire half-duplex multi-drop connection (1:N (N = 1 to 32))
Data rate	1200, 2400, 4800, 9600, 19200, or 38400 bps
Data length	7 or 8 bits
Stop bit	1 bit
Parity	Odd, even, or none
Handshaking	Off:Off, XON:XON, XON:RS, and CS:RS
Communication distance (RS-422A/485)	1200 m
Modbus communication	Operation modes: Master or slave

### VGA Output (/D5)

Item	Specifications
External display	Resolution: 640 × 480 dots (VGA) Connector: 15-pin D-Sub

### FAIL/Status Output Relay (/F1)

Item	Specifications
FAIL output	Relay contact output on CPU error
Relay operation	Energized during normal operation and de-energized on system error.
Status output	Output a relay contact signal when a selected condition occurs.
Relay operation	Relay is energized when a condition occurs.
Relay contact rating	250 VAC (50/60 Hz)/3 A, 250 VDC/0.1 A (for resistance load)

### FAIL/Alarm Output Relay 22 Outputs (/F2)

Item	Specifications
FAIL/status output	Same as /F1
Alarm output relay	Number of outputs: 22. Same as /A[ ] for other specifications.

### Clamped Input Terminal (Detachable) (/H2)

Item	Specifications
Input terminal	Make the input section clamp input terminals (detachable). Recommended wire size: 0.08 to 1.5 mm <sup>2</sup> (AWG 28 to 16)



## 13.5 Options

### Desktop Type (/H5[ ]) ---

Item	Specifications
Construction	With carrying handle. /H5D, /H5F, /H5R, /H5J, /H5H: Power Inlet connector. With a power cord. /H5: Can only be specified when /P1 is simultaneously specified. Screw type power terminal. Without power cord.

### Computation Function (including the report function) (/M1) ---

Item	Specifications
Number of computation channels	DX2004 and DX2008: 12 channels (101 to 112) DX2010, DX2020, DX2030, DX2040, and DX2048: 60 channels (101 to 160)
Operation	General arithmetic operations: Four arithmetic operations, square root, absolute, common logarithm, natural logarithm, exponential, and power Relational operations: <, ≤, >, ≥, =, and ≠ Logic operations: AND, OR, NOT, and XOR Statistical operations: TLOG or CLOG Special operations: PRE, HOLD, RESET, and CARRY Conditional operation: [a?b:c]
Computation accuracy	Double-precision floating point for TLOG.SUM and single-precision floating point for all other computations
Data that can be used	
Channel data	Measurement, computation, and external input channels (/MC1)
Constants	60 constants
Communication input data	60
Remote control input status	0/1 (/R1)
Pulse input	Counts the number of pulses (/PM1)
Status input	Internal switch, alarm output relay (/A[ ]), and flags
Rolling average	Performs moving average on the computed results.
Measurement range	–9999999 to 99999999 Decimal place: 0 to 4 digits to the right of the decimal point
Alarms	High limit, low limit, delay high limit, and delay low limit Hysteresis: High and low limit alarm: 0.0% to 5.0% of the span.
Display	Same as the measurement channels
Data saving	Same as the measurement channels
Report function	Number of report channels DX2004 and DX2008: 12 DX2010, DX2020, DX2030, DX2040, and DX2048: 60 Computation types: Average, maximum, minimum, sum, or instantaneous value Report types: Hourly, daily, hourly + daily, daily + weekly, daily + monthly

### Cu10, Cu25 RTD Input/3 Leg Isolated RTD Input (/N1) ---

Item	Specifications
Measurement/display accuracy	Under standard operating conditions

Input Type	Measurement Range	Accuracy Guaranteed Range	Measurement Accuracy		Max. Resolution
			A/D integration time: 16.7 ms or more	A/D integration time: 1.67 ms	
Cu10 (GE)	–200 to 300°C –328 to 572°F	–70 to 170°C	(0.4% of rdg + 1.0°C)	(0.8% of rdg + 5.0°C)	0.1°C
Cu10 (L&N)		–75 to 150°C			
Cu10 (WEED)		–200 to 260°C			
Cu10 (BAILEY)		–200 to 300°C			
Cu10: a = 0.00392 at 20°C					
Cu10: a = 0.00393 at 20°C		(0.3% of rdg + 0.8°C)	(0.5% of rdg + 2.0°C)		
Cu25: a = 0.00425 at 0°C					

\* Measuring current i = 1 mA

Input source resistance	1 Ω or less per wire (The resistance of all three wires must be equal).
Ambient temperature influence	(applies when the A/D integration time is 16.67 ms or greater) ±(0.2% of range + 2 digits) or less
Input source resistance	With variation of 1 Ω per wire (resistance of all three wires must be equal): ±(0.1% of rdg + 1 digit) or less With maximum difference of 40 mΩ between wires: Approx. 1 °C

### 3 Leg Isolated RTD Input (/N2)

Item	Specifications
Input terminal	Isolated on each channel. Applies to DX2010, DX2020, DX2030, DX2040, and DX2048

### Extended Input Type (/N3)

Item	Specifications
Measurement/display accuracy	Under standard operating conditions

Input Type		Measurement Range		Measurement Accuracy			Max. Resolution
				A/D integration time: 16.7 ms or more		A/D integration time: 1.67 ms	
TC	Kp vs Au7Fe	0.0 to 300.0 K		0 to 20 K	Within 4.5 K	Within 13.5 K	0.1 K
				20 to 300 K	Within 2.5 K	Within 7.5 K	
	PLATINEL	0.0 to 1400.0°C	32 to 2552°F	(0.25% of rdg + 2.3°C)		(0.25% of rdg + 8.0°C)	0.1°C
	PR40-20	0.0 to 1900.0°C	32 to 3452°F	0 to 450°C	Accuracy not guaranteed	Accuracy not guaranteed	
				450 to 750°C	(0.9% of rdg + 3.2°C)	(0.9% of rdg + 15.0°C)	
				750 to 1100°C	(0.9% of rdg + 1.3°C)	(0.9% of rdg + 6.0°C)	
				1100 to 1900°C	(0.9% of rdg + 0.4°C)	(0.9% of rdg + 3.0°C)	
	NiNiMo	0.0 to 1310.0°C	32 to 2390°F	(0.25% of rdg + 0.7°C)		(0.5% of rdg + 3.5°C)	
W/WRe26	0.0 to 2400.0°C	32 to 4352°F	0 to 400°C	15.0°C	30.0°C		
			400 to 2400°C	(0.2% of rdg + 2.0°C)	(0.4% of rdg + 4.0°C)		
Type N (AWG14)	0.0 to 1300.0°C	32 to 2372°F	(0.2% of rdg + 1.3°C)		(0.5% of rdg + 7.0°C)		
RTD*	Pt50	-200.0 to 550.0°C	-328.0 to 1112.0°F	(0.3% of rdg + 0.6°C)		(0.6% of rdg + 3.0°C)	
	Ni100 (SAMA)	-200.0 to 250.0°C	-328.0 to 482.0°F	(0.15% of rdg + 0.4°C)		(0.3% of rdg + 2.0°C)	
	Ni100 (DIN)	-60.0 to 180.0°C	-76.0 to 356.0°F	(0.15% of rdg + 0.4°C)		(0.3% of rdg + 2.0°C)	
	Ni120	-70.0 to 200.0°C	-94.0 to 392.0°F	(0.15% of rdg + 0.4°C)		(0.3% of rdg + 2.0°C)	
	J263*B	0.0 to 300.0 K		0 to 40 K	Within 3.0 K	Within 9.0 K	
				40 to 300 K	Within 1.0 K	Within 3.0 K	
	Cu53	-50.0 to 150.0°C	-58.0 to 302.0°F	(0.15% of rdg + 0.8°C)		(0.3% of rdg + 4.0°C)	
	Cu100	-50.0 to 150.0°C	-58.0 to 302.0°F	(0.2% of rdg + 1.0°C)		(0.4% of rdg + 5.0°C)	
Pt25	-200.0 to 550.0°C	-328.0 to 1022.0°F	(0.15% of rdg + 0.6°C)		(0.3% of rdg + 3.0°C)		

\* Measuring current  $i = 1$  mA

Input source resistance	Thermocouple input: 2 k $\Omega$ or less RTD input: 1 $\Omega$ or less per wire (The resistance of all three wires must be equal).
Ambient temperature influence (applies when the A/D integration time is 16.67 ms or greater)	
TC input	$\pm(0.1\%$ of rdg + 0.05% of range) or less, excluding the error of reference junction compensation
RTD input	$\pm(0.2\%$ of range + 2 digits) or less
Input source resistance	
TC input	With variation of +1 k $\Omega$ : $\pm 10$ $\mu$ V or less
RTD input	With variation of 1 $\Omega$ per wire (resistance of all three wires must be equal): $\pm(0.1\%$ of rdg + 1 digit) or less
	With maximum difference of 100 m $\Omega$ between wires: Approx. 1 °C

### Remote Control (/R1)

Item	Specifications
Number of input terminals	8
Input type	Isolated from the main circuitry through a photocoupler, built-in isolated power supply for the input terminals, and shared common.
Input type and signal level	
Voltage-free contact	Contact closed at 200 $\Omega$ or less and contact open at 100 k $\Omega$ or greater.
Open collector	ON voltage: 0.5 V or less (sink current 30 mA or more), leakage current when OFF: 0.25 mA or less
Allowable input voltage	5 VDC
Signal type	Level or edge (250 ms or more)
Action	Executes a specified action by applying a given signal to the remote signal input terminal. Action type: Action of the event action function

## 13.5 Options

### 24 VDC Transmitter Power Supply (/TPS4 and /TPS8)


Item	Specifications
Number of loops	4 (/TPS4) or 8 (/TPS8)
Output voltage	22.8 to 25.2 VDC (under rated load current)
Rated output current	4 to 20 mADC
Max. output current	25 mADC (overcurrent protection operation current: approx. 68 mADC)
Allowable conductor resistance	$RL \leq (17.8 - \text{minimum transmitter operation voltage})/0.02 \text{ A}$ where 17.8 V is the result obtained by subtracting the maximum drop voltage of 5 V when the load shunt resistance is 250 $\Omega$ from the minimum output voltage of 22.8 V
Max. length of wiring	2 km (when using the CEV cable)
Insulation resistance	20 M $\Omega$ or more at 500 VDC between output terminal and ground
Dielectric strength	500 VAC (50/60 Hz, I = 10mA) for one minute between output terminal and ground 500 VAC (50/60 Hz, I = 10mA) for one minute between output terminals

### Easy Text Entry (/KB1 and /KB2)

Item	Specifications
Remote control terminal (438227)	
Operating temperature range	0 to 40°C
Operation humidity range	20% to 80% RH (at 5 to 40°C no condensation)
Power supply	3 VDC AA dry batteries $\times$ 2
Weight	Approx. 60 g (excluding the batteries)
External dimensions	170 (H) $\times$ 50 (W) $\times$ 23.7 (D) mm
Signal	Infrared
Combination with the DX	
Number of units that can be controlled individually	Up to 32 units by setting the ID number
Communication distance	Up to 8 m from the front of the light receiving section of the DX (reference value)*
Directional characteristics	See the figure below (reference characteristics)* * Varies depending on the operating environment such as the battery voltage and the presence or absence of external light.

#### Standard accessories (/KB1)

Remote control unit, two alkaline dry batteries, and ID number label



### USB Interface (/USB1)

Item	Specifications
USB port	Complies with Rev. 1.1 and host function
Number of ports	2 (one each on the front panel and rear panel)
Power supply	5 V $\pm$ 10% , 500 mA (per port) Devices which need more than 500 mA total bus power for 2 ports can not be connected at the same time.
Connectable devices	Only connect the devices listed below to prevent damage to the devices.
Keyboard	Complies with HID Class Ver. 1.1 104 keyboard (US) and 109 keyboard (Japanese) Number connectable units: 1
External medium	USB flash memory (up to 2 GB) Does not guarantee the operation of all USB flash memories. External medium such as a hard disk, ZIP, MO, and optical discs are not supported. Number connectable units: 1

**Pulse Input (/PM1)**

Item	Specifications
Pulse input	
Number of inputs	3 (8 when using the remote control input terminals)
Input type	Isolated from the main circuitry through a photocoupler and built-in isolated power supply for the input terminals. Shared common for pulse inputs.
Input type and signal level	Voltage-free contact Contact closed at 200 $\Omega$ or less and contact open at 100 k $\Omega$ or greater Open collector ON voltage: 0.5 V or less (sink current 30 mA or more), leakage current when OFF: 0.25 mA or less
Counting	Counts the rising edges of pulses. For voltage-free contact input: Contact open to contact close For open collector: Voltage level of the terminal H from high to low
Allowable input voltage	30 VDC
Max. sampling pulse period	100 Hz
Minimum detected pulse width	5 ms or more for both low (closed) and high (open)
Pulse detection period	Approx. 3.9 ms (256 Hz)
Pulse measuring accuracy	$\pm 1$ pulse
Remote control	Number of inputs: 5. Same as remote control (/R1) for the other specifications
Computation function	Same as the computation function (/M1)

**Calibration Correction (/CC1)**

Item	Specifications
Calibration correction method	Corrects the measured value of each channel using segment linearizer approximation. Number of segment points: 2 to 16 (including the start and end points)

**External Input Function (/MC1)**

Item	Specifications
Function	Loads data from other instruments using the Modbus client or Modbus master function and displays, records, and saves the data.
Number of channels	240 channels (201 to 440)
Display	Same as the measurement channels
Data saving	Same as the measurement channels
Manual sample	Specify up to 120 channels from measurement, computation, and external input channels.

**DC/AC 24 V power supply (/P1)**

Item	Specifications
Rated supply voltage	24 VDC and 24 VAC (50/60Hz)
Allowable power supply voltage range	21.6V to 26.4 VDC/AC
Insulation resistance	Between power terminal and earth: 20 M $\Omega$ or greater at 500 VDC.
Withstand voltage	Between power terminal and earth: 500 VAC at 50/60 Hz for one minute
Rated power supply frequency (for AC)	50/60 Hz
Allowable power supply frequency range (for AC)	50 Hz $\pm 2\%$ , 60 Hz $\pm 2\%$
Power supply fluctuation (for AC)	With variation within 21.6 to 26.4 VDC/AC: $\pm 1$ digit or less With variation of $\pm 2$ Hz from rated power supply frequency (at 24 VAC): $\pm (0.1\%$ of rdg+1 digit) or less
Rated power consumption	45 VA (for DC), 70 VA (for AC)
Power consumption	

Supply voltage	LCD backlight off	Normal	Maximum
24 VDC	12 VA	20 VA	45 VA
24 VAC (50/60Hz)	20 VA	34 VA	70 VA

## 13.6 General Specifications

### Construction

Item	Specifications
Mounting	Flush panel mounting (on a vertical plane) (excluding the desktop type)
Mounting angle	Inclined backward up to 30 degrees from a horizontal plane.
Allowable panel thickness	2 to 26 mm
Material	Case: Metal plate Bezel and display cover: Polycarbonate
Color	Case: Grayish blue green (Munsell 2.0B5.0/1.7 or equivalent) Bezel: Charcoal gray light (Munsell 10B3.6/0.3 or equivalent)
Front panel	Water and dust proof. Complies with IEC529-IP65 and NEMA No.250 TYPE 4 (except External Icing Test) (Style number 2 or later), except for side-by-side mounting
External dimensions	288(W) × 288(H) × 226(D) mm (D: depth from the panel mounting plane)
Weight	DX2004 and DX2010: Approx. 6 kg. DX2008 and DX2020: Approx. 6.3 kg. DX2030: Approx. 6.9 kg, DX2040 and DX2048: Approx. 7.3 kg excluding options

### Normal Operating Conditions

Item	Specifications
Supply voltage	90 to 132, 180 to 250 VAC
Power supply frequency	50 Hz ± 2%, 60 Hz ± 2%
Ambient temperature	0 to 50°C
Ambient humidity	20 to 80%RH (at 5 to 40°C), 10 to 50% (at 40 to 50°C)
Vibration	10 to 60 Hz, 0.2 m/s <sup>2</sup>
Shock	Not allowed
Magnetic field	400 A/m or less (DC and 50/60 Hz)
Noise	Normal mode (50/60 Hz)
DC voltage	The peak value including the signal must be less than 1.2 times the measuring range.
Thermocouple	The peak value including the signal must be less than 1.2 times the measuring thermal electromotive force.
RTD	50 mV or less
Common mode noise	250 VACrms or less for all ranges (50/60 Hz)
Maximum noise voltage between channels	250 VACrms (50/60 Hz) or less
Mounting position	Can be inclined up to 30 degrees backward. Left and right horizontal.
Warm-up time	At least 30 minutes after power on
Installation location	Indoors
Operating altitude	2000 m or less

### Power Supply

Item	Specifications												
Rated supply voltage	100 to 240 VAC												
Allowable power supply voltage range	90 to 132, 180 to 264 VAC												
Rated power supply frequency	50 Hz to 60 Hz												
Power consumption	<table border="1"> <thead> <tr> <th>Supply voltage</th> <th>LCD backlight off</th> <th>Normal</th> <th>Maximum</th> </tr> </thead> <tbody> <tr> <td>100 VAC</td> <td>28 VA</td> <td>42 VA</td> <td>74 VA</td> </tr> <tr> <td>240 VAC</td> <td>38 VA</td> <td>54 VA</td> <td>100 VA</td> </tr> </tbody> </table>	Supply voltage	LCD backlight off	Normal	Maximum	100 VAC	28 VA	42 VA	74 VA	240 VAC	38 VA	54 VA	100 VA
Supply voltage	LCD backlight off	Normal	Maximum										
100 VAC	28 VA	42 VA	74 VA										
240 VAC	38 VA	54 VA	100 VA										
Allowable interruption time	Less than 1 cycle of the power supply frequency												

### Isolation

Item	Specifications
Insulation resistance	Between the Ethernet, RS-422A/485, and insulation terminals and earth: 20 MΩ or greater at 500 VDC
Withstand voltage	Between the power terminal and earth: 2300 VAC at 50/60 Hz for one minute Between the contact output terminal and earth: 1600 VAC at 50/60 Hz for one minute Between the measurement input terminal and earth: 1500 VAC at 50/60 Hz for one minute Mutually between measurement input terminals: 1000 VAC (50/60 Hz) for one minute (excluding the RTD input terminal of DX2010, DX2020, DX2030, DX2040, and DX2048) Between the remote input terminal and earth: 1000 VDC for one minute Between the pulse input terminal and earth: 1000 VDC for one minute
Ground	Grounding resistance: 100 Ω or less

## Transport and Storage Conditions

Item	Specifications
Ambient temperature	-25 to 60°C
Ambient humidity	5 to 95%RH (no condensation)
Vibration	10 to 60 Hz, 4.9 m/s <sup>2</sup> maximum
Shock	392 m/s <sup>2</sup> maximum (in packaged condition)

## Supported Standards

Item	Specifications
CSA	CSA22.2 No.61010.1, installation category II <sup>*1</sup> , and pollution degree 2 <sup>*2</sup>
UL	UL61010B-1 (CSA NRTL/C)
CE	
EMC directive	EN61326 compliance (Emission: Class A, Immunity: Annex A) EN61000-3-2 compliance EN61000-3-3 compliance EN55011 Class A Group 1
Low voltage directive	EN61010-1, measurement category II <sup>*3</sup> , pollution degree 2
C-Tick	AS/NZS CISPR11 compliance, Class A Group 1

\*1 Installation category (overvoltage category) II: Describes a number which defines a transient overvoltage condition. Implies the regulation for impulse withstand voltage. "II" applies to electrical equipment which is supplied from the fixed installation like a distribution board.

\*2 Pollution degree 2: Describes the degree to which a solid, liquid, or gas which deteriorates dielectric strength or surface resistivity is adhering. "2" applies to normal indoor atmosphere. Normally, only non-conductive pollution occurs.

\*3 Measurement category II: Applies to measuring circuits connected to low voltage installation, and electrical instruments supplied with power from fixed equipment such as electric switchboards.

## Standard Performance

Item	Specifications
Measurement/display accuracy	Standard operating conditions: Temperature: 23 ± 2°C Humidity: 55% ± 10%RH Power supply voltage: 90 to 132 or 180 to 250 VAC Power supply frequency: 50/60 Hz ± 1% Warm-up time: At least 30 minutes. Other ambient conditions such as vibration should not adversely affect the operation.

Input Type	Range	Measurement Accuracy (Digital Display)		Max. Resolution of Digital Display
		A/D integration time: 16.7 ms or more	A/D integration time: 1.67 ms	
DC voltage	20 mV	(0.05% of rdg + 12 digits)	(0.1% of rdg + 40 digits)	1 µV
	60 mV	(0.05% of rdg + 3 digits)	(0.1% of rdg + 15 digits)	10 µV
	200 mV			10 µV
	2 V	(0.05% of rdg + 12 digits)	(0.1% of rdg + 40 digits)	100 µV
	1-5 V	(0.05% of rdg + 3 digits)	(0.1% of rdg + 15 digits)	1 mV
	6 V			1 mV
	20 V			1 mV
	50 V			10 mV
Thermocouple (excluding RJC accuracy)	R	(0.15% of rdg + 1°C)	(0.2% of rdg + 4°C)	0.1°C
	S	R, S 0 to 100°C: 3.7°C, 100 to 300°C: 1.5°C	R, S 0 to 100°C: 10°C, 100 to 300°C: 5°C	
	B	B 400 to 600°C: 2°C, Accuracy not guaranteed for values less than 400°C	B 400 to 600°C: 7°C, Accuracy not guaranteed for values less than 400°C	
	K	(0.15% of rdg + 0.7°C)	(0.2% of rdg + 3.5°C)	
	E	-200 to -100°C: (0.15% of rdg + 1°C)	-200 to -100°C: (0.15% of rdg + 6°C)	
	J	(0.15% of rdg + 0.5°C)	(0.2% of rdg + 2.5°C)	
	T	-200 to -100°C: (0.15% of rdg + 0.7°C)	-200 to -100°C: (0.2% of rdg + 5°C)	
	N	(0.15% of rdg + 0.7°C)	(0.3% of rdg + 3.5°C)	
	W	(0.15% of rdg + 1°C)	(0.3% of rdg + 7°C)	
	L	(0.15% of rdg + 0.5°C)	(0.2% of rdg + 2.5°C)	
	U	-200 to -100°C: (0.15% of rdg + 0.7°C)	-200 to -100°C: (0.2% of rdg + 5°C)	
RTD	WRe	(0.2% of rdg + 2.5°C) 0 to 200°C: 4.0°C	(0.3% of rdg + 10°C) 0 to 200°C: 18.0°C	
	Pt100	(0.15% of rdg + 0.3°C)	(0.3% of rdg + 1.5°C)	
JPt100				

## 13.6 General Specifications

Item	Specifications
Measuring accuracy in case of scaling	<p>Accuracy during scaling (digits) = measurement accuracy (digits) × multiplier + 2 digits (rounded up)</p> <p>* Fractions rounded up            where the multiplier = scaling span (digits)/measuring span (digits).</p> <p>Example For 1-5 V range (A/D integration time is 16.7 ms or more), measurement span of 1.000 to 5.000 V, and scaling span of 0.000 to 2.000            The measuring accuracy for 5 V input is as follows.            Measuring accuracy (1-5 V range) = <math>\pm(0.05\% \times 5 \text{ V} + 3 \text{ digits}) = \pm(0.0025 \text{ V [3 digits]} + 3 \text{ digits}) = \pm 6 \text{ digits}</math>            Multiplier = <math>\{2000 \text{ digits (0.000 to 2.000)}\} / 4000 \text{ digits (1.000 to 5.000)} = 0.5</math>            Thus, accuracy during scaling = <math>\pm(6 \times 0.5 + 2) \text{ digits} = 5 \text{ digits (rounded up)}</math></p>
Reference junction compensation accuracy	<p>When measuring temperature greater than or equal to 0 °C and when input terminal temperature is balanced</p> <p>Type R, S, B, W, WRe: <math>\pm 1.0^\circ\text{C}</math>            Type K, J, E, T, N, L, and U: <math>\pm 0.5^\circ\text{C}</math>. Type B: Internal reference compensation is fixed to 0 °C</p>
Maximum input voltage	$\pm 60 \text{ VDC (continuous)}$
Input resistance	<p>200 mV range or less and TC: 10 M<math>\Omega</math> or more            2 V range or higher: Approx. 1 M<math>\Omega</math></p>
Input source resistance	
Volt, TC	2 k $\Omega$ or less
RTD input	10 $\Omega$ or less per wire (The resistance of all three wires must be equal).
Bias current	10 nA or less (except when burnout detection function is enabled)
Maximum common mode noise voltage	250 VACrms (50 Hz/60 Hz)
Maximum noise voltage between channels	250 VACrms (50 Hz/60 Hz)
Interference across channels	120 dB (when the input source resistance is 500 $\Omega$ and the input to other channels is 60 VDC)
Common mode rejection ratio	
When the A/D integration time is 20 ms	120 dB (50 Hz $\pm 0.1\%$ , 500 $\Omega$ unbalanced, between the minus terminal and ground)
When the A/D integration time is 16.7 ms	120 dB (60 Hz $\pm 0.1\%$ , 500 $\Omega$ unbalanced, between the minus terminal and ground)
When the A/D integration time is 1.67 ms	80 dB or higher (50/60 Hz $\pm 0.1\%$ , 500 $\Omega$ unbalanced, between the minus terminal and ground)
Normal mode rejection ratio	
When the A/D integration time is 20 ms	40 dB or more (50/60 Hz $\pm 0.1\%$ )
When the A/D integration time is 16.7 ms	40 dB or more (60 Hz $\pm 0.1\%$ )
When the A/D integration time is 1.67 ms	Not reject 50/60 Hz

## Effects of Operating Conditions

Item	Specifications
Ambient temperature (applies when the A/D integration time is 16.7 ms or greater)	
DC voltage, TC range	With temperature variation of 10°C: $\pm(0.1\%$ of rdg + 0.05% of range) or less * Excluding the error of reference junction compensation
RTD range	$\pm(0.1\%$ of rdg + 2 digits) or less
Power supply fluctuation	With variation within 90 to 132 V and 180 to 250 VAC (50/60 Hz): Accuracy specifications are satisfied. With variation of $\pm 2$ Hz from rated power frequency (power supply voltage 100 VAC): Accuracy specifications are satisfied.
Magnetic field	AC (50/60 Hz) and DC 400 A/m fields: $\pm(0.1\%$ of rdg + 10 digits) or less
Input source resistance	
DC voltage range	With variation of +1 k $\Omega$ : 200 mV range or less: $\pm 10$ $\mu$ V or less 2 V range or higher: $\pm 0.15\%$ of rdg or less
TC range	With variation of +1 k $\Omega$ : $\pm 10$ $\mu$ V or less
RTD range (Pt100)	With variation of 10 $\Omega$ per wire (resistance of all three wires must be equal): $\pm(0.1\%$ of rdg + 1 digits) or less With maximum difference of 40 m $\Omega$ between wires: Approx. 0.1 °C
Effects of vibration	Effects from a sinusoidal vibration along all three axis at a frequency between 10 to 60 Hz and an acceleration of 0.2 m/s <sup>2</sup> : $\pm(0.1\%$ of rdg + 1 digit) or less

## Miscellaneous

Item	Specifications
Memory backup	A built-in lithium battery backs up the settings and runs the clock Battery life: Approximately 10 years (at room temperature)



---

## 13.7 External Dimensions

See the *DX2000 Operation Guide (IM04L42B01-02E)*.

# Appendix 1 File Size of Display Data and Event Data

This section explains how to calculate the file size of display data files and event data files. The calculation examples are given for the display data only and event data only cases. If you are recording both display and event data, calculate the data size of each and add them together.

Use the calculated file size as a rough guide.

## File Size

A file consists of the following data.

**Information other than the sampled data + the sampled data**

### Size of Information Other Than the Sampled Data

Item	Size [Bytes]
File header	216
Channel information	$88 \times N + 28$
Group information	$96 \times 36 + 28 = 3,484$
Message information	$104 \times 50 + 28$ (an add message area is reserved by default)
Batch information	832
Sampled data header	$80 + 32 + N \times 4 + 2 + 18$
Message information	Up to $104 \times 1050$ (varies depending on the number of messages)
Alarm information	Up to $32 \times 5000$ (varies depending on the number of alarms)
N is the number of channels (measurement channels + external input channels + computation channels).	

**Example 1:** If display data of 12 measurement channels and 24 computation channels is recorded. There are no messages or alarms.

$$216 + (88 \times 280 + 28) + 3,484 + (104 \times 50 + 28) + 832 + (80 + 32 + 280 \times 4 + 2 + 18) = 34,894 \text{ bytes}$$

### Sampled Data Size

#### • Data Size of Display Data and Event Data

Channel	Display Data	Event Data
Measurement channel	4 bytes/channel	2 bytes/channel
External input channel	4 bytes/channel	2 bytes/channel
Computation channel	8 bytes/channel	4 bytes/channel

Time data common to all channels is added for each sample.

Time data	8 bytes/sample
-----------	----------------

#### • Data Size per Sample

##### Display Data

(Number of measurement channels  $\times$  4 bytes) + (Number of external input channels  $\times$  4 bytes) + (number of computation channels  $\times$  8 bytes) + 8 bytes (time data)

##### Event Data

(Number of measurement channels  $\times$  2 bytes) + (Number of external input channels  $\times$  2 bytes) + (number of computation channels  $\times$  4 bytes) + 8 bytes (time data)

- **Sampled Data Size per File**

**Display Data**

Data size per sample×file save interval/sampling interval

The sampling interval is determined by trend interval (s)/30.

**Example 2:** If the display data of 30 measurement channels, 240 external input channels, and 10 computation channels is recorded with a trend interval of 30 min/div (the sampling interval of display data is 60 s) and a file save interval of 1 day (24 h)

$$\begin{aligned} & (30 \times 4 \text{ bytes} + 240 \times 4 \text{ bytes} + 10 \times 8 \text{ bytes} + 8 \text{ bytes}) \times 24 \text{ h} \times 60 \times 60 / 60 \text{ s} \\ & = 1,168 \text{ bytes} \times 24 \text{ h} \times 60 \times 60 / 60 \text{ s} \\ & = 1,681,920 \text{ bytes} \end{aligned}$$

**Event Data**

Data size per sample×data length/sample rate

**Example 3:** If the display data of 30 measurement channels, 240 external input channels, and 10 computation channels is recorded with a sample rate of 1 s and data length of 2 h

$$\begin{aligned} & (30 \times 2 \text{ bytes} + 240 \times 2 \text{ bytes} + 10 \times 4 \text{ bytes} + 8 \text{ bytes}) \times 2 \text{ h} \times 60 \times 60 / 1 \text{ s} \\ & = 588 \text{ bytes} \times 2 \text{ h} \times 60 \times 60 / 1 \text{ s} \\ & = 4,233,600 \text{ bytes} \end{aligned}$$

**Size per File**

The size per file is the sum of the size of information other than the sampled data and the size of the sampled data.

**Display Data**

**Example 4:** If recording under the conditions of examples 1 and 2

From examples 1 and 2, we obtain  $34,894 + 1,681,920 = 1,716,8144 \text{ bytes} = 1.637 \text{ M bytes}$

**Event Data**

**Example 5:** If recording under the conditions of examples 1 and 3

From examples 1 and 3, we obtain  $34,894 + 4,233,600 = 4,268,494 \text{ bytes} = 4.071 \text{ M bytes}$

## Save Duration to the CF Card

We will estimate the duration over which measured data can be saved to a CF card when measured data is being saved automatically.

### Display Data

Save duration to the CF card (estimate) = (Size of the CF card/size of a file)×[file save interval]

**Example 6:** We will estimate the save duration to the CF card under the conditions of examples 1 and 2. In this example, the size of the CF card is assumed to be 256 M bytes.

$$\begin{aligned} & 256 \text{ M bytes}/1.637 \text{ M bytes} \times 24 \text{ h} \\ & = 3.753 \text{ h} \\ & = 156 \text{ days} \end{aligned}$$

### Event Data

Save duration to the CF card (estimate) = (Size of the CF card/size of a file)×[data length]

**Example 7:** We will estimate the time until the CF card needs to be replaced under the conditions of examples 1 and 3. In this example, the size of the CF card is assumed to be 256 M bytes.

$$\begin{aligned} & 256 \text{ M bytes}/4.071 \text{ M bytes} \times 2 \text{ h} \\ & = 125 \text{ h} \\ & = 5.2 \text{ days} \end{aligned}$$

## Time until the Internal Memory Becomes Full

If you are manually saving the measured data in the internal memory, old data is overwritten when the internal memory is full. You must save the measured data to the CF card before the data is overwritten.

### Display Data

Time until the internal memory becomes full (estimate) = (Size of the internal memory/size of a file)×[file save interval]

**Example 8:** We will estimate the time until the internal memory becomes full under the conditions of examples 1 and 2. In this example, the internal memory is assumed to be of a standard type (80 M bytes).

$$\begin{aligned} & 80 \text{ MB}/1.637 \text{ MB} \times 24 \text{ h} \\ & = 1,172 \text{ h} \\ & = 48 \text{ days} \end{aligned}$$

### Event Data

Time until the internal memory becomes full (estimate) = (Size of the internal memory/size of a file)×[data length]

**Example 9:** We will estimate the time until the internal memory becomes full under the conditions of examples 1 and 3. In this example, the internal memory is assumed to be of a standard type (80 M bytes).

$$\begin{aligned} & 80 \text{ MB}/4.071 \text{ MB} \times 2 \text{ h} \\ & = 39 \text{ h} \\ & = 1.63 \text{ days} \end{aligned}$$

## Appendix 2 Types of Data That the DX Can Create and Their Application

This section explains the types of data that the DX can create and their application.

Data Type	In the DX	Extension	Format	Display Method <sup>1</sup>		
				DX	DAQ	Application
Display data	Yes	DAD	Binary (undisclosed)	Yes	Yes	Yes <sup>2,3</sup>
Event data	Yes	DAE	Binary (undisclosed)	Yes	Yes	Yes <sup>2,3</sup>
Report data	Yes	DAR	ASCII (see appendix 3)	Yes	Yes	Yes
Manual sampled data	Yes	DAM	ASCII (see appendix 3)	-	-	Yes
Setup data	Yes	PDL	Binary (undisclosed)	Yes	Yes	-
Snapshot data	None	PNG	PNG (general format)	-	-	Yes

1 DX: DX main unit, DAQ: DAQSTANDARD, Application: Software application

2 The data format can be converted on DAQSTANDARD and displayed on a software application such as Microsoft Excel.

3 The data can be retrieved from the DX using the communication function and displayed on a software application.

## Appendix 3 Data Format of ASCII Files

This section explains the format of ASCII files. The ASCII files that the DX can create are manual sampled data files and report files.

In the explanation below, CRLF represents a terminator.

### Format of the Manual Sample Data File

- The manual sampled data is output using numerical values and strings in ASCII format delimited by tabs.
- Values of measurement channels set to **Skip** and computation and external input channels set to **Off** are not output.
- The data is appended to the file each time manual sample operation is performed.

#### Format

```

YRECCRLF
Manual Sample Data  Version 1.00.00      CRLF
Model              DX2000      CRLF
Language Code      shift-JIS  CRLF
File Status        ffffffff  CRLF
Serial No.         III•••I   CRLF
File Header        HHH•••H   CRLF
Ch                ccccc    ccccc    •••    ccccc    CRLF
Tag               ttt•••t   ttt•••t   •••    ttt•••t   CRLF
Unit              uuuuuu    uuuuuu    •••    uuuuuu    CRLF
yyy/mo/dd hh:mi:ss  nnn•••n   nnn•••n   •••    nnn•••n   CRLF
  
```

fffffff

File status (8 characters)

Complete    Completed  
 Progress    Data being added  
 Decrease    Defective

III•••I

Serial number of the DX (16 characters)

HHH•••H

File header (50 characters)

ccccc

Channel number (5 characters)

ttt•••t

Tag (16 characters)

uuuuuu

Unit (6 characters)

yyy/mo/dd hh:mi:ss

Sampling year, month, day, and time (19 characters)

nnn•••n

Measured value (13 characters)

**File Output Example**

Below is a manual sample data example of channels 1, 2, 3, and 4.

```

YREC
Manual Sample Data  Version 1.00.00
Model                DX2000
Language Code        shift-JIS
File Status          Progress
Serial No.           S5E701600
File Header
Ch                   CH001      CH002      CH003      CH004
Tag                  TI-101      OUT-102     FI-103     VA-204
Unit                  ^C          V           m3/h       %
2005/10/01 08:57:22  213.8      0.517      368.4      68.9
2005/10/01 08:57:28  208.6      0.494      363.0      68.1
    
```

**Note**

- Output when error data, overrange data, or computation overflow data is detected

Channel	Data	Output
Measurement channels,	Error	(Space)
external input channel	+over range (includes burnout detection)	99999
	-over range (includes burnout detection)	-99999
Computation channel	Error	999999999
	Positive computation overflow (when the value exceeds 3.4E + 38)	999999999
	Negative computation overflow (when the value falls below -3.4E + 38)	-999999999

- A new manual sampled data file is created in the following cases.
  - A measurement channel is changed to **Skip** from a range other than **Skip**.
  - A measurement channel is changed from **Skip** to a range other than **Skip**.
  - A computation or external input channel is changed from **On** to **Off** or **Off** to **On**.
  - The unit is changed.

## Report File Format

- The hourly, daily, weekly, and monthly reports are output using numeric values and strings in ASCII format delimited by tabs.
- Values of measurement channels set to **Skip** and computation and external input channels set to **Off** are not output.
- The data is appended to this file every time a report is created.

### Format

```

YRECCRLF
Report Data          Version 1.00.00      CRLF
Model                DX2000             CRLF
Language Code        shift-JIS          CRLF
File Status          ffffffff           CRLF
Serial No.           III•••I           CRLF
File Header          HHH•••H           CRLF
Report Set           RRR•••R           CRLF
File Data            rrr•••r           CRLF
Math Set             MMM             MMM             MMM             MMMM           CRLF
Start Time           YYYY/MO/DD HH:MI:SS CRLF
Ch                   ccccc           ccccc           •••             ccccc           CRLF
Tag                  ttt•••t           ttt•••t           •••             ttt•••t         CRLF
Unit                 uuuuuu           uuuuuu           •••             uuuuuu           CRLF
Data Type            sss•••s           CRLF
Time                 yyyy/mo/dd hh:mi:ss CRLF
Status               eeeeeeeeeee      CRLF
Ave                  nnn•••n           nnn•••n           •••             nnn•••n         CRLF
Max                  nnn•••n           nnn•••n           •••             nnn•••n         CRLF
Min                  nnn•••n           nnn•••n           •••             nnn•••n         CRLF
Sum                  nnn•••n           nnn•••n           •••             nnn•••n         CRLF

```

```

ffffffffff           File status (8 characters)
Complete  Completed
Progress  Data being added
Decrease  Defective

III•••I             Serial number of the DX (16 characters)
HHH•••H             File header (50 characters)
RRR•••R             Report setting (setting on the DX) (13 characters)
Hourly
Daily
Hourly+Daily
Daily+Weekly
Daily+Monthly

rrr•••r             Contents of the report file (13 characters)
Hourly
Daily
Hourly+Daily
Daily+Weekly
Daily+Monthly

```

Example: When the DX is set to **Hourly+Daily** and **Combine**, **Hourly+Daily** is output.  
 When the DX is set to **Hourly+Daily** and **Separate**, the hourly report is output as **Hourly**, and the daily report as **Daily**.



### Appendix 3 Data Format of ASCII Files

MMMM	Report items (16 characters (including tabs that are counted as one character each), up to four types) Ave Max Min Sum Inst      Instantaneous value
YYYY/MO/DD HH:MI:SS	Report start year, month, day, and time (19 characters)
ccccc	Channel number (5 characters)
ttt•••t	Tag (16 characters)
uuuuuu	Unit (6 characters)
eeeeeeeeee	Status (output the events that occurred while creating report data) (10 characters) Bo      Burn out detected Er      Error (error detection) Ov      Over (overrange/computation overflow detection) Pw      Power failure (power failure occurrence) Cg      Change (time change present)
SSS•••S	Report type (7 characters) Hourly Daily Weekly Monthly
yyyy/mo/dd hh:mi:ss	Report year, month, day, and time (19 characters)
nnn•••n	Average, maximum, minimum, sum, or instantaneous value (13 characters)

#### File Output Example

Below is an example of an hourly report of 4 channels while creating hourly and daily reports and saving each type of report to a separate file.

```

YREC
Report Data      Version 1.00.00
Model           DX2000
Language Code   shift-JIS
File Status     Complete
Serial No.     S5E701600
File Header
Report Set      Hourly+Daily
File Data       Hourly
Math Set        Ave           Max           Min           Sum
Start Time     2005/10/01 08:10:56
Ch             CH001          CH002          CH003          CH004
Tag            TI-101         OUT-102        FI-103         VA-204
Unit           ^C            V             m3/h          %
Data Type      Hourly
Time           2005/10/01 09:00:00
Status
Ave            91.5          -0.039         241.1         48.6
Max            259.8         0.726          416.5         76.6
Min            -59.9         -0.727         83.4          23.3
Sum            3.293636E+05 -1.392980E+02 8.680871E+05 1.748983E+05

```

**Note**

- When the channel data is in the condition shown in the table below, the *Er*, *Ov*, or *Bo* status is output to a report.

Data Condition	Status
Error	Er
Measurement and external input channels	
Positive over range	Ov
Negative over range	Ov
Burn out detection	Bo
Computation channels	
Positive computation overflow (when the value exceeds 3.4E + 38)	Ov
Negative computation overflow (when the value falls below -3.4E + 38)	Ov

- The report output value of *Ave*, *Max*, *Min*, *Sum*, and *Inst* varies depending on the channel data condition as shown in the table below.

Item	Data Condition of Measurement/ External Input Channels	Report Output Value
<i>Ave</i>	When all of the data are errors or over range	(Space)
<i>Max</i> ,	• When all of the data are errors	(Space)
<i>Min</i> ,	• For +over range (includes burnout detection)	99999
<i>Inst</i>	• For -over range (includes burnout detection)	-99999
<i>Sum</i>	• When all of the data are errors or over range	(Space)
	• When the sum value exceeds approx. 3.4E + 38	9.999999E+99
	• When the sum value is below approx. -3.4E + 38	-9.999999E+99

Item	Data Condition of Computation Channels	Report Output Value
<i>Ave</i>	When all of the data are errors or computation overflow	(Space)
<i>Max</i> ,	• When all of the data are errors	(Space)
<i>Min</i> ,	• When the maximum value or instantaneous value exceeds 99999999	99999999
<i>Inst</i>	• When the minimum value or instantaneous value is less than -99999999	-99999999
<i>Sum</i>	• When all of the data are errors or computation overflow	(Space)
	• When the sum value exceeds approx. 3.4E + 38	9.999999E+99
	• When the sum value is below approx. -3.4E + 38	-9.999999E+99

\* The decimal place that was specified when the span for the channel was specified applies to the maximum and minimum values or the instantaneous values. For example, if the span setting of the channel is "200.0," then "99999999" is output when the value exceeds "9999999.9" and "-99999999" is output when the value is below "-9999999.9."

# Index

## Symbol

**	9-6
+Over	1-12
-Over	1-12
[a?b:c]	9-10
1/4 circle	5-25
24 VDC transmitter power supply	13-12
3 leg isolated RTD input	13-11

## A

A/D integration time	3-1
ABS	9-6
absolute time mode	1-34
action	1-35
added messages	1-14
administrator	1-38, 8-5
alarm	1-4, 13-2
alarm ACK	1-6, 3-14
alarm acknowledge	1-6
alarm acknowledge operation	3-14
alarm delay time	3-13, 9-3
alarm hide function	1-5
alarm indication	1-5, 3-7
alarm mark indication	5-15
alarm output relay	1-5, 3-8, 13-9
alarm settings	3-11
alarm summary	1-17, 4-13
alarm value	3-12
all channel display	4-4
all data display	4-7
AND	9-7
AND/OR	1-6
auto increment	6-7
auto logout	1-38, 8-4, 8-6
automatic message writing	1-10
auto save	1-28, 6-5

## B

background color	1-22, 5-30
background color (historical trend)	4-9
backlight saver	1-22, 2-7
bar graph display	1-13, 4-3
base position (bar graphs)	5-20
batch comment	1-33, 6-7
batch function	6-7, 13-8
batch name	6-7
batch number	1-33
brightness	1-22, 2-7
burnout	1-12, 3-2
burnout detection	1-2

## C

calculate the file size	App-1
calibration	12-2, 12-3
calibration correction	1-3, 3-15, 13-13
CARRY	9-10
change message	5-4
channel (computation)	1-39
channel display colors	5-9
channel number	5-3
circular display	1-15, 5-23
clamped input terminal	13-9

clears the entire waveform (circular)	5-24
CLOG computation	9-9
color scale band	5-16
communication errors	11-10
communication functions	13-8
communication log	4-19
computation channel	9-1
computation data dropout	1-41, 9-14
computation error	9-4
computation function	1-39, 13-10
computation types	1-39
conditional expression	9-10
configuration (storage)	13-5
construction (DX)	13-14
continuing data	4-6
count (moving average)	3-6
Cu10, Cu25 RTD input	13-10
current value display	5-14
cursor (circular)	5-27
cursor (historical trend)	4-6
customizing the display selection menu	5-35
customizing the FUNK key menus	5-35
customizing the menus	1-22, 4-2

## D

data display section	1-7
data kind	6-2
data length	6-3
data that can be used in equations	1-41
data that the DX can create	App-4
data type	13-5
data types	1-23
date/time	2-1
date format	1-47, 2-4
daylight savings time	2-1
de-energize	1-6
delay high limit alarm	1-4
delay low limit alarm	1-4
deleting a file	6-14
desktop type	13-10
detect (alarm hide function)	3-10, 3-13
DHCP log	4-21
difference computation	1-3
difference lower limit alarm	1-4
difference upper limit alarm	1-4
digit (scale value)	5-13
digital display	1-12, 4-3
directory (data save)	1-28
display (LCD)	13-3
display color (channels)	5-9
display color (messages)	5-8
display data	1-231-49, 1-25, 13-5
display direction (bar graphs)	5-20
display direction (messages)	5-19
display direction (trend)	5-19
displayed information	13-3
displayed language	1-48
display group	5-1
display menu	4-1, 5-37
display selection menu	4-1, 5-37
display zone	5-10
divided (report file)	9-16
division (scale)	5-12

## Index

---

DNS server ..... 2-5  
domain name ..... 2-5  
DST (daylight saving time) ..... 1-47, 2-1

## E

---

e-mail log ..... 4-20  
easy text entry ..... 1-48, 13-12  
effects of operating conditions ..... 13-17  
energize ..... 1-6  
EQ ..... 9-6  
error codes ..... 11-1  
error data ..... 1-44  
error log ..... 4-19  
error messages ..... 11-1  
errors related to parameter settings ..... 11-1  
event ..... 1-34  
event action ..... 1-34, 7-1, 13-7  
event data ..... 1-23, 1-25, 13-5  
event data (circular) ..... 5-29  
EXP ..... 9-6  
expanding ..... 4-23  
expressions (computation) ..... 9-5  
extended input type ..... 13-11  
external dimensions ..... 13-18  
external input channels ..... 1-49, 10-1  
external input function ..... 13-13

## F

---

FAIL/alarm output relay 22 outputs ..... 13-9  
FAIL/status output relay ..... 13-9  
FAIL output ..... 1-45, 2-9  
fast sampling mode ..... 1-1  
favorite key ..... 1-22, 5-33  
file header ..... 6-5  
file name ..... 1-30  
file size ..... App-1  
firmware version ..... 2-5  
fixed (alarm mark) ..... 5-15  
flag ..... 1-41  
flow of data recording and storage ..... 1-24  
format of ASCII files ..... App-5  
formatting ..... 6-14  
format type ..... 6-14  
four arithmetic operation ..... 9-6  
four panel display ..... 1-21, 4-22  
free (event data) ..... 1-26, 6-2  
free messages ..... 1-10, 5-8  
free space ..... 6-14  
FTP log ..... 4-19  
full circle action ..... 5-24  
FUNC key menu ..... 4-2, 5-36

## G

---

GE ..... 9-6  
gradually correcting the internal clock ..... 1-47  
graph display ..... 1-7  
grid ..... 5-19  
groups ..... 5-1  
group set ..... 5-1  
GT ..... 9-6

## H

---

historical trend display ..... 1-14, 4-5  
HOLD ..... 9-10  
hold (alarm indication) ..... 1-5  
hold (alarm output relay) ..... 1-6

host name ..... 2-5  
hysteresis ..... 1-4, 3-9

## I

---

identified strings ..... 6-5  
ID number ..... 2-11  
indicator ..... 3-7  
information on the displayed measured data ..... 4-9  
initialize ..... 2-8  
input processing ..... 1-2  
input range ..... 3-3  
input type ..... 1-1, 3-4  
integration time ..... 1-1  
internal memory ..... 1-24  
internal switch ..... 1-34, 3-8  
interval (rate-of-change alarm) ..... 1-4, 3-7  
invalid keys ..... 2-16  
IP address ..... 2-5  
isolation ..... 13-14

## J

---

jump default display ..... 5-32

## K

---

keyboard ..... 2-15  
key lock ..... 1-37, 8-1

## L

---

LE ..... 9-6  
limitations (expressions) ..... 9-5  
linear scaling ..... 1-3  
line width of the trend ..... 5-19  
list of files ..... 6-13  
LN ..... 9-6  
loading a file ..... 6-15  
loading setup data ..... 6-17  
LOG ..... 9-6  
log ..... 4-18  
log display ..... 1-20  
logging out ..... 8-6  
logical computation ..... 9-7  
login function ..... 1-38, 8-4  
login log ..... 4-18  
log into the DX ..... 8-6  
lot-No. digit ..... 6-7  
lot number ..... 1-33  
low-cut ..... 1-3, 3-5  
LT ..... 9-6

## M

---

MAC address ..... 2-5  
maintenance ..... 12-1  
manuals ..... i  
manual sampled data ..... 1-23, 1-27, 13-6  
manual sampled data (format) ..... App-5  
manual save ..... 1-29  
match time timer ..... 1-34, 7-3  
math start action ..... 9-13  
measurement channel ..... 1-1  
measurement input ..... 13-1  
measure soft key ..... 3-15  
media FIFO ..... 1-28, 6-5  
memory backup ..... 13-17  
memory sample ..... 6-2  
memory start ..... 6-8

memory stop ..... 6-9  
 memory summary ..... 1-19, 4-15  
 message colors ..... 5-8  
 message display methods ..... 4-14  
 messages ..... 1-10, 5-6  
 messages (errors, status, etc) ..... 11-1  
 message summary ..... 1-18, 4-14  
 modbus client status display ..... 1-20  
 modbus master status display ..... 1-20  
 modbus status display ..... 4-12  
 modbus status log ..... 4-21  
 mode (input range) ..... 3-4  
 moving average ..... 1-2, 3-6

## N

name of a four panel display ..... 4-23  
 NE ..... 9-6  
 network information ..... 2-5  
 next soft key ..... 4-2  
 non-hold (alarm indication) ..... 1-5  
 non-hold (alarm output relay) ..... 1-6  
 normal operating conditions ..... 13-14  
 NOT ..... 9-7  
 number of pulses per minute ..... 3-17  
 numeric display ..... 1-12

## O

offset time ..... 5-24  
 operation errors ..... 11-3  
 operation logs ..... 4-18  
 operations that can be carried out when logged out ..... 1-38  
 OR ..... 9-7  
 order of precedence (computation) ..... 9-5  
 overflow data ..... 1-44, 9-4  
 overview display ..... 1-16, 4-10

## P

partial expanded display ..... 1-11, 5-17  
 parts replacement ..... 12-1  
 password (key lock) ..... 8-1  
 password (login function) ..... 8-5  
 password change ..... 8-7  
 power-fail message ..... 5-34  
 power computations ..... 9-6  
 power failure operation ..... 1-44  
 power supply ..... 13-14  
 power supply for transmitter ..... 1-48  
 PRE ..... 9-10  
 preset display ..... 5-32  
 pretrigger ..... 1-26  
 processing order of computation ..... 1-41  
 progress of the save operation ..... 4-16  
 pulse input ..... 1-3, 13-13  
 pulse sum value ..... 3-16

## Q

quarter cycle display ..... 5-25

## R

range (input range) ..... 3-4  
 rate-of-change alarm ..... 1-4  
 recommended replacement periods for worn parts ..... 12-1  
 recording conditions (display data) ..... 1-25  
 recording conditions (event data) ..... 1-26  
 ref. CH ..... 3-5

reference channel ..... 3-5  
 reference junction compensation ..... 1-2, 3-2  
 reflash ..... 1-6, 3-7  
 relational computation ..... 9-6  
 relative time mode ..... 1-34  
 relay action on alarm ACK ..... 3-8  
 relay status display ..... 1-20, 4-12  
 releasing the key lock ..... 8-2  
 remote control ..... 1-34, 7-1, 13-11  
 remote control function ..... 7-1  
 remote controller ID ..... 2-5, 2-10  
 remote control terminal ..... 2-11  
 repeat (event data) ..... 1-26  
 report ..... 9-15  
 report data ..... 1-20, 1-23, 1-27, 13-6  
 report display ..... 4-11  
 report file (format) ..... App-7  
 report function ..... 1-43  
 RESET ..... 9-10  
 reset (TLOG) ..... 1-42  
 resets the computed result (Rst+St) ..... 9-13  
 reset the sum value ..... 3-17  
 resetting the computed results ..... 9-14  
 resetting the relative timer ..... 7-4  
 revisions ..... i  
 rolling average ..... 1-42, 9-4  
 RS-232 interface ..... 13-9  
 RS-422A/485 interface ..... 13-9

## S

sample rate ..... 6-2  
 save directory ..... 6-5  
 save duration to the CF card ..... App-3  
 save interval ..... 6-2  
 save interval (circular) ..... 5-24  
 saving data to the external storage medium ..... 1-28  
 saving measured data (automatically) ..... 6-8  
 saving measured data (manually) ..... 6-9  
 saving setup data ..... 6-16  
 saving the data ..... 4-16  
 scale ..... 5-11  
 scale lower ..... 3-5  
 scale marks (circular) ..... 5-29  
 scale upper ..... 3-5  
 scan interval ..... 1-1, 3-1  
 screen image data ..... 1-23, 6-12  
 scroll time ..... 5-31  
 second interval ..... 5-5, 6-2  
 security ..... 8-4  
 security function ..... 13-7  
 separators ..... 5-36  
 setup data ..... 1-23, 1-32, 13-6  
 simplified historical trend ..... 5-26  
 single (event data) ..... 1-26  
 size of the internal memory ..... 1-25  
 snapshot ..... 6-12, 13-6  
 snapshot data ..... 1-23, 1-32  
 SNMP log ..... 4-20  
 sort item ..... 4-13, 4-14  
 span lower ..... 3-4  
 span upper ..... 3-4  
 Special computation ..... 9-10  
 special data ..... 1-44  
 SQR ..... 9-6  
 square root computation ..... 1-3  
 standard display soft key ..... 5-32  
 standard performance ..... 13-15

## Index

---

standards ..... 13-15  
standard temperature device ..... 12-2  
starting the computation ..... 9-13  
start the recording ..... 6-8  
status display section ..... 1-8  
status messages ..... 11-12  
status output ..... 1-46, 2-9  
status relay ..... 2-9  
stopping the recording ..... 6-9  
structure of the file name ..... 6-5  
sub menu ..... 4-1, 5-37  
sum scale ..... 1-43  
symbols that can be entered ..... 2-16  
system errors ..... 11-14  
system information ..... 2-5

## T

---

tag ..... 5-3  
tag display ..... 4-1  
temperature unit ..... 1-49, 3-3  
text field ..... 1-33, 6-7  
time at the grid position ..... 1-9, 2-4, 5-5  
time axis ..... 4-8  
time correction operation ..... 1-47  
time deviation limit ..... 2-3  
time per revolution ..... 5-24  
timer ..... 1-34, 7-3  
timer action ..... 7-3  
time related functions ..... 13-7  
time set ..... 2-1  
time until the internal memory becomes full ..... App-3  
time zone ..... 1-47, 2-2  
TLOG ..... 9-3  
TLOG computation ..... 1-42, 9-8  
trademarks ..... i  
transport and storage conditions ..... 13-15  
trend display ..... 4-3  
trend display (T-Y) ..... 1-9  
trend history ..... 4-5  
trend interval ..... 1-10, 5-4  
trend rate switching ..... 5-4  
trigger ..... 6-8  
trigger signal ..... 6-3  
trip line ..... 5-2  
troubleshooting ..... 11-15

## U

---

unit ..... 3-5  
unit in computations ..... 1-41  
unsaved data ..... 1-29  
update interval (measured values) ..... 1-7  
updating of the waveform ..... 1-10  
USB interface ..... 1-49, 13-12  
user ..... 1-38, 8-5  
USER key ..... 1-34, 7-1

## V

---

value indicator ..... 5-14  
value on over-range ..... 3-19  
VGA output ..... 13-9  
VGA output terminal ..... 1-48

## W

---

warning messages ..... 11-14  
web log ..... 4-19

## X

---

XOR ..... 9-7

## Z

---

zone display ..... 1-11