

---

**User's  
Manual**



**MW100  
Communication Command  
Manual**

---

---

## Foreword

Thank you for purchasing the MW100 Data Acquisition Unit. This user's manual describes MW100 communication commands and responses. To ensure correct use, please read this manual thoroughly before beginning operation. The six manuals below relating to the MW100 are provided in addition to this one. Read them along with this manual. Like this manual, the MW100 Data Acquisition Unit User's Manual, MW100 Data Acquisition Unit Operation Guide, and MW100 Viewer Software User's Manual are included on the MW100 Manual CD-ROM.

Manual Title	Manual No.	Description
MW100 Data Acquisition Unit User's Manual	IM MW100-01E	Explains MW100 Data Acquisition Unit functions, settings and wiring, handling precautions, and browser operation.
MW100 Data Acquisition Unit Operation Guide	IM MW100-02E	Gives an overview of the handling and Unit operation of the MW100 Data Acquisition Unit and the Viewer Software.
MX100/MW100 Usage Precautions	IM MX100-71E	Explains precautions to be taken during use of the MW100 Data Acquisition Unit.
MX100/MW100 Data Acquisition Unit Installation and Connection Guide	IM MX100-72E	Gives an overview of the installation and wiring procedures of the MW100 Data Acquisition Unit.
Control of pollution caused by MX100/MW100 products	IM MX100-91C	Describes control of pollution caused by the product.
MW100 Viewer Software User's Manual	IM MW180-01E	Explains the functions and operations of the Viewer software that comes standard with the MW100 Main Module.

## Notes

- This manual describes style number S3 of the MW100 Data Acquisition Unit.
- The contents of this manual are subject to change without prior notice as a result of improvements in the software's performance and functions. Display contents illustrated in this manual may differ slightly from what actually appears on your screen.
- Every effort has been made in the preparation of this manual to ensure the accuracy of its contents. However, should you have any questions or find any errors, please contact your nearest YOKOGAWA representative, dealer, or sales office.
- Copying or reproducing all or any part of the contents of this manual without the permission of Yokogawa Electric Corporation is strictly prohibited.
- The TCP/IP software and related documentation for this product was developed and created by Yokogawa based on BSD Networking Software Release 1, licensed from the University of California.

## Trademarks

- DAQMASTER is a registered trademarks of Yokogawa Electric Corporation.
- Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Adobe and Acrobat are registered trademarks or trademarks of Adobe Systems Incorporated.
- Company and product names that appear in this manual are registered trademarks or trademarks of their respective holders.
- The company and product names used in this manual are not accompanied by the registered trademark or trademark symbols (® and ™).

## Revisions

1st Edition June, 2005  
2nd Edition October, 2006  
3rd Edition October, 2007

---

# How to Use This Manual

## Structure of the Manual

This user's manual contains the following chapters.

---

<b>Chapter 1</b>	<b>Commands</b> Explains all available commands, one-by-one.
<b>Chapter 2</b>	<b>Responses</b> Describes the format of settings and measured or computed data output by this instrument.
<b>Appendix</b>	Provides serial interface specifications, a table of ASCII character codes, and other information.
<b>Index</b>	An alphabetical index of this manual.

---

## Symbols Used in This Manual

### Unit

- k: Denotes 1000. Example: 5 kg, 100 kHz
- K: Denotes 1024. Example: 10 KB

### Safety Markings

The following safety markings are used in this manual.



Refer to corresponding location on the instrument. This symbol appears on dangerous locations on the instrument which require special instructions for proper handling or use. The same symbol appears in the corresponding place in the manual to identify those instructions.

### **WARNING**

Calls attention to actions or conditions that could cause serious injury or death to the user, and precautions that can be taken to prevent such occurrences.

### **CAUTION**

Calls attentions to actions or conditions that could cause light injury to the user or damage to the instrument or user's data, and precautions that can be taken to prevent such occurrences.

### **Note**

Calls attention to information that is important for proper operation of the instrument.

# Contents

	How to Use This Manual .....	ii
<b>Chapter 1</b>	<b>Commands</b>	
1.1	Command Format .....	1-1
	Command Format .....	1-1
	Response .....	1-2
1.2	List of Commands .....	1-3
	Setting Commands (System Related) .....	1-3
	Setting Commands (Display Related) .....	1-4
	Setting Commands (Communication Related) .....	1-4
	Control Commands .....	1-4
	Control Commands (Cont.) .....	1-5
	Output Commands .....	1-5
	Output Commands (RS-422A/485 Specific Commands) .....	1-5
	List of Commands Valid When Option Functions Are Installed .....	1-5
1.3	Parameters .....	1-6
	Channel Numbers and Channel Ranges .....	1-6
	Upper and Lower Limit of Span (Measurement Channels) .....	1-6
	Upper and Lower Limit of Span (MATH Channels) .....	1-9
	Upper and Lower Limit of Scaling .....	1-9
	Alarm Types .....	1-9
	Alarm Value Setting Range .....	1-9
	Hysteresis Value Setting Range .....	1-9
	MATH Constants and Communication Input Values .....	1-10
	Channel Structure .....	1-10
	Point Structure .....	1-10
	Action Types .....	1-11
	Byte Output Order .....	1-14
	Measurement Interval and MATH Interval .....	1-14
	User Specified Strings .....	1-14
	Password String .....	1-14
	Host Name and Domain Name String .....	1-15
	File Name and Folder Name String .....	1-15
1.4	Setting Commands (System Related) .....	1-16
1.5	Setting Commands (Display Related) .....	1-30
1.6	Setting Commands (Communication Related) .....	1-32
1.7	Control Commands .....	1-37
1.8	Output Commands .....	1-40

**Chapter 2 Response**

2.1	Response Format.....	2-1
	Affirmative Responses .....	2-1
	Single Negative Response.....	2-1
	Multiple Negative Response .....	2-2
	ASCII Output.....	2-2
	Binary Output .....	2-2
	RS-422A/485 Specific Commands/Responses.....	2-4
2.2	ASCII Output.....	2-5
	Responses to Queries.....	2-5
	Output of the Latest Measured/Computed Data .....	2-6
	Output of the Latest Output Data .....	2-7
	Output of Setting Data.....	2-8
	Output of Decimal Place and Units .....	2-9
	Output of Operation Error Logs (FL0, ERROR) .....	2-10
	Output of Recording Logs (FL0, RECORD).....	2-10
	Output of Recording Status Logs (FL0, RECSTATUS).....	2-12
	Output of Alarm Summaries (FL0, ALARM) .....	2-14
	Output of Message Summaries (FL0, MESSAGE).....	2-15
	Output of Communication Logs (FL0, COM).....	2-16
	Output of FTP Client Logs (FL0, FTP_C).....	2-17
	Output of Mail Client Logs (FL0, SMTP) .....	2-19
	Output of DHCP Client Logs (FL0, DHCP) .....	2-20
	Output of Time Synchronization Logs (FL0, SNTP).....	2-22
	Output of FTP Server Logs (FL0, FTP_S) .....	2-23
	Output of HTTP Server Logs (FL0, HTTP).....	2-24
	Output of Modbus Master Logs (FL0, MODBUS_M) .....	2-25
	Output of Modbus Master Command Status (FL1, MODBUS_MC).....	2-26
	Output of Modbus Master Connection Status (FL1, MODBUS_MS) .....	2-27
	Output of Modbus Slave Log (FL0, MODBUS_S).....	2-28
	Output of Modbus Client Logs (FL0, MODBUS_C).....	2-30
	Output of Modbus Client Command Status (FL1, MODBUS_CC).....	2-30
	Output of Modbus Client Connection Status (FL1, MODBUS_CS).....	2-31
	Output of Modbus Server Log (FL0, MODBUS_T) .....	2-32
	Output of MATH Status (FL0, MATH).....	2-33
	Output of Operation Logs (FL0, CMD).....	2-34
	Output of Strain Input Initial Balancing Result (FL1, BALANCE) .....	2-35
	Output of Status Information (IS) .....	2-35
	Output of Relay Status (VF).....	2-36
	Output of System Recognition Status (CF).....	2-37
	Output of Media Free Space (ME0) .....	2-38
	Output of File Information (ME1).....	2-38
2.3	Binary Output .....	2-39
	Output of the Latest Measured/Computed Data .....	2-39
	Output of the Latest Output Data .....	2-40
	Output of FIFO Data.....	2-41
	FIFO Read Range.....	2-43

**Appendix**

Appendix 1	Serial Interface (Optional) Specifications.....	App-1
	RS-232 Specifications .....	App-1
	RS-422A/485 Specifications .....	App-1
Appendix 2	Modbus Protocol.....	App-2
	Modbus Protocol Specifications.....	App-2
	Modbus Protocol Function Code .....	App-2
	Register Assignments (Modbus Slave).....	App-3
	Register Assignments (Modbus Slave).....	App-4
Appendix 3	Modbus Communication Timeout .....	App-5
Appendix 4	Bit Structure of Status Information .....	App-6
	Status Information 1 (Task Complete 1) .....	App-6
	Status Information 2 (Task Complete 2) .....	App-6
	Status Information 3 (Abnormality) .....	App-6
	Status Information 4 (Event).....	App-7
	Status Information 5 (Mode) .....	App-7
	Status Information 6 (Mode) .....	App-7
Appendix 5	ASCII Character Codes .....	App-8
Appendix 6	Maintenance/Diagnostic Server .....	App-9
	Connection between the Main Module and PC .....	App-9
	Terminal Emulator Settings.....	App-9
	List of Maintenance/Diagnostic Commands .....	App-9
	Main Specifications of the Maintenance/Diagnostic Server.....	App-9
Appendix 7	Error Display on the 7-Segment LED and Corrective Actions .....	App-14
	Errors upon Startup .....	App-14
	System Errors .....	App-14
	Module Errors .....	App-14
	Communication Errors .....	App-15
	Setting Errors.....	App-15
	Execution Error .....	App-18
	Execution Errors .....	App-18
	Communication Command Error .....	App-19
	Communication Error.....	App-20
	System Errors .....	App-20

**Index**

1

2


App

Index


# 1.1 Command Format

## Command Format

The format for MW100 commands is described below. ASCII character codes (see Appendix 5) are used.



### Example command



### Command Name

Consists of two alphabetic characters.

### Parameters

- The arguments of the command.
- Set using alphanumeric characters.
- A delimiter (comma) is inserted between parameters.
- If the parameter is a numerical value, the valid setting range varies depending on the command.
- Spaces before, after, or inside of a parameter are ignored (except for parameters (units) set as user-specified strings which allow spaces).
- Parameters can be omitted unless a change from a current setting is required. However, the delimiter cannot be omitted.

Example `SR01,,2V<terminator>`

If multiple parameters are omitted, and delimiters are continuous until the terminator, those delimiters can be omitted.

Example `SR01,VOLT,,, <terminator>` -> `SR01,VOLT<terminator>`

- The maximum length for a single parameter is 512 bytes.

### Queries

- Question marks (?) are used for queries.
- You can place a query after a command or parameter to query the setting of that command. There are commands for which queries cannot be made. See section 1.4 to 1.8 for the queries for each command.

Ex. 1 `SR[p1]?` Execute SR? or SRp1?.

Ex. 2 `SA[p1[p2]]?` Execute SA?, SAp1?, or SAp1,p2?.

### Delimiters

- Commas (,) are used as delimiters.
- A delimiter is inserted between parameters.

### Sub-Delimiters

- Semicolons ( ; ) are used as sub-delimiters.
- You can enumerate up to 99 commands by connecting them one-by-one with the sub-delimiter. However, the following commands and queries cannot be enumerated. Use them solitarily.
  - Control commands
  - Output commands
  - Queries

### Terminator

You can use one of the following as the terminator.

- CR + LF (or 0x0d 0x0a in base 16 ASCII code. )
- LF (or 0x0a in base 16 ASCII code.)

### **Note**

---

- Commands must be kept within 2047 bytes from the first character to the terminator.
  - Except for user-specified strings, commands are not case-sensitive.
  - Even if a command enumerated with other commands experiences an error, the other commands are all executed.
- 

## Response

The instrument receives a single response (affirmative or negative) for every command delimited with a terminator.\* Please maintain a 1-to-1 command-response ratio on the controller side as well. If this command-response format is not upheld, correct operation cannot be guaranteed. For the format of responses, see section 2.1.

\* There are exceptions with RS-422A/485 specific commands (see section 2.1).



## 1.2 List of Commands

### Setting Commands (System Related)

Command Name	Functions	Operation Mode	Administrator	User	Page
SR	Input Range Settings	Setting	Yes	No	1-16
SF	Filter Settings	Setting	Yes	No	1-17
XB	Burnot Settings	Setting	Yes	No	1-17
XJ	Reference Junction Compensation Settings	Setting	Yes	No	1-17
PF	Pulse Input Module Chattering Filter Settings	Setting	Yes	No	1-17
SA	Alarm Settings	All modes	Yes	No	1-18
VA	Alarm Hysteresis Settings	All modes	Yes	No	1-18
XA	Settings Related to Alarm	Setting	Yes	No	1-18
BD	Delay Alarm Settings	Setting	Yes	No	1-19
XD	Relay Settings	Setting	Yes	No	1-19
SO	Expression Settings	Setting	Yes	No	1-19
SK	MATH Constant Settings	Setting	Yes	No	1-19
MG	MATH Group Settings	Setting	Yes	No	1-20
RO	Report Operation and Creation Time Settings	Setting	Yes	No	1-20
RM	Report Execution Channel Settings	Setting	Yes	No	1-20
VL	Broken-Line Input Channel Settings	Setting	Yes	No	1-21
AO	Output Range Settings	Setting	Yes	No	1-21
AP	Preset Operation Settings	Setting	Yes	No	1-22
SL	Event/Action Settings	Setting	Yes	No	1-22
SI	Timer Settings	Setting	Yes	No	1-24
SQ	Match Time Settings	Setting	Yes	No	1-24
XV	Measurement Interval Settings	Setting	Yes	No	1-25
XI	Measurement Groups and A/D Integration Time Settings	Setting	Yes	No	1-25
VM	MATH Interval Settings	Setting	Yes	No	1-25
XG	Settings of Operation upon MATH Error	Setting	Yes	No	1-25
MC	File Message Settings	Setting	Yes	No	1-26
MD	Data Save Folder Settings	Setting	Yes	No	1-26
MH	Recording Channel Settings	Setting	Yes	No	1-27
MW	Recording Operation Settings	Setting	Yes	No	1-27
ML	Recording Data Length Settings	Setting	Yes	No	1-28
MR	Recording Free Space Settings	Setting	Yes	No	1-28
MX	Thinning Recording Operation Settings	Setting	Yes	No	1-28
MU	Setting Save Operation Settings	Setting	Yes	No	1-28
XK	Key Lock Settings	All modes	Yes	No	1-28
XT	Temperature Unit Settings	Setting	Yes	No	1-28
SW	Daylight Saving Time Settings	Setting	Yes	No	1-29
SS	Daylight Saving Time Operation Settings	Setting	Yes	No	1-29
BA	Settings of Strain Input Initial Balancing	Setting	Yes	No	1-29
UN	Unit Number Settings	Setting	Yes	No	1-29
SV	Rolling Average Settings	Setting	Yes	No	1-29

Yes: Permitted to use command, No: Not permitted to use command

### Note

- The instrument has two operation modes. If a command intended for use in one mode is executed while in a different mode, an error results. Switch to the proper mode before executing the command. Queries can be used regardless of the mode.
  - Setting Mode**  
In this mode, measurement, computation, and recording is stopped, and settings can be changed.
  - Measurement Mode**  
Computation and recording can be executed during measurement.
- The administrator and user distinction shows the user level specified on the instrument's communication login function. For details, see the main unit manual (IM MW100-01E).
- Queries can be executed by both administrator and users.

## 1.2 List of Commands

### Setting Commands (Display Related)

Command Name	Functions	Operation Mode	Administrator	User	Page
ST	Tag Settings	Setting	Yes	No	1-30
SZ	Zone Settings	Setting	Yes	No	1-30
SC	Display Color Settings	Setting	Yes	No	1-30
SB	Display Scale Settings	Setting	Yes	No	1-30
SX	Display Group Settings	Setting	Yes	No	1-31
TL	Trip Line Settings	Setting	Yes	No	1-31
XR	Channel and Tag Display Switching	Setting	Yes	No	1-31
SG	Message Settings	All modes*	Yes	No	1-31

\* Available for certain messages

Yes: Permitted to use command, No: Not permitted to use command

### Setting Commands (Communication Related)

Command Name	Functions	Operation Mode	Administrator	User	Page
UA	User Settings	Setting	Yes	No	1-32
YS	Serial Communication Settings	Setting	Yes	No	1-32
YA	IP Address Settings	Setting	Yes	No	1-32
YD	Host Name and Domain Name Settings	Setting	Yes	No	1-32
YN	DNS Client Settings	Setting	Yes	No	1-33
YH	DHCP Client Settings	Setting	Yes	No	1-33
YF	FTP Client Settings	Setting	Yes	No	1-33
YG	FTP Client Operation Settings	Setting	Yes	No	1-33
YM	Mail Client Settings	Setting	Yes	No	1-33
YV	Mail Sender and Recipient Settings	Setting	Yes	No	1-33
YU	Mail Contents Settings	Setting	Yes	No	1-34
YC	E-Mail Alarm Transmission Settings	Setting	Yes	No	1-34
YT	Time Synchronization Settings	Setting	Yes	No	1-34
WD	Modbus Client Operation Settings	Setting	Yes	No	1-34
WE	Modbus Client Connection Settings	Setting	Yes	No	1-35
WF	Modbus Client Command Settings	Setting	Yes	No	1-35
WA	Modbus Master Settings	Setting	Yes	No	1-35
WB	Modbus Master Command Settings	Setting	Yes	No	1-35
UL	Validation of Login Function	Setting	Yes	No	1-36
WC	Validation of Client Function	Setting	Yes	No	1-36
WS	Validation of Server Function	Setting	Yes	No	1-36
YQ	Communication Timeout Settings	Setting	Yes	No	1-36

Yes: Permitted to use command, No: Not permitted to use command

### Control Commands

Command Name	Functions	Operation Mode	Administrator	User	Page
DS	Operation Mode Switching	All modes	Yes	No	1-37
EX	Computation Start/Stop/Reset/Clear	Measurement	Yes	No	1-37
PS	Recording Start/Stop	Measurement	Yes	No	1-37
MV	Setting File Save/Write	Setting	Yes	No	1-37
MQ	Measured, Computed, and Thinned File Division	Measurement	Yes	No	1-37
MS	Message Writing	Measurement	Yes	No	1-37
MP	Execution of Manual Sample	Measurement	Yes	No	1-37
KI	Main Unit Key Operation	All modes	Yes	No	1-38
CE	Error Display Clear	All modes	Yes	No	1-38
AK	Alarm Acknowledgment	All modes	Yes	No	1-38
IR	Timer Reset	Measurement	Yes	No	1-38
CM	Communication Input Data Settings	All modes	Yes	No	1-38
VD	Relay ON/OFF	All modes	Yes	No	1-38

Yes: Permitted to use command, No: Not permitted to use command

**Control Commands (Cont.)**

Command Name	Functions	Operation Mode	Administrator	User	Page
SD	Date and Time Settings	Setting	Yes	No	1-38
RC	Initialization of Settings	Setting	Yes	No	1-38
RS	Reconfiguration	Setting	Yes	No	1-39
MF	Media Preparations	Setting	Yes	No	1-39
BL	Execution of Strain Input Initial Balancing	Setting	Yes	No	1-39
PV	Transmission Output Control	Measurement	Yes	No	1-39
SP	User Output Settings	Measurement	Yes	No	1-39
EC	Execution of Communication	Setting	Yes	No	1-39
TC	Communication Test	All mode	Yes	No	1-39
CC	Communication Open/Close	All mode	Yes	Yes	1-39
BO	Byte Output Order Settings	All mode	Yes	Yes	1-40
CS	Checksum Settings	All mode	Yes	Yes	1-40
GR	Resetting of the MATH Channels Specified by the MATH Group	Measurement	Yes	No	1-40

Yes: Permitted to use command, No: Not permitted to use command

**Output Commands**

Command Name	Functions	Operation Mode	Administrator	User	Page
FD	Output of Latest Measured/Computed Data	All mode	Yes	Yes	1-40
FO	Output of Latest Output Data	All mode	Yes	Yes	1-40
FE	Output of Decimal Place, Units, and Setting Data	All mode	Yes	Yes	1-41
FF	Output of Measured/Computed FIFO Data	All mode	Yes	Yes	1-41
FL	Output of Logs, Alarm Summaries, and Status	All mode	Yes	Yes	1-41
IS	Output of Status Information	All mode	Yes	Yes	1-42
VF	Output of Relay Status	All mode	Yes	Yes	1-42
CF	Output of System Recognition Status	All mode	Yes	Yes	1-42
ME	Output of Media Information	All mode	Yes	Yes	1-42

Yes: Permitted to use command, No: Not permitted to use command

**Output Commands (RS-422A/485 Specific Commands)**

Command Name	Functions	Operation Mode	Administrator	User	Page
Esc O	Instrument Open	All mode	Yes	Yes	2-4
Esc C	Instrument Close	All mode	Yes	Yes	2-4

Yes: Permitted to use command, No: Not permitted to use command

**List of Commands Valid When Option Functions Are Installed**

Option	Command Name
/C2 or /C3	YS
/M1	SO/SK/MG/VL/VM/XG/EX/WD/WE/WF/SV/GR
/C2 and /M1 or /C3 and /M1	WA/WB
/M3	RO/RM

## 1.3 Parameters

The numerical value and string parameters of commands have restrictions on format. The following describes commands whose parameters are restricted.

### Channel Numbers and Channel Ranges

Channel Type	Setting Range and Command Setting Parameters
Measurement channels	001-060
Output channels	001-060
Relay	001-060
Channels (type not specified)	001-060
MATH channels	A001-A300
MATH constants	K01-K60
Communication input channels	C001-C300
Flag input channels	F01-F60
Broken-line input channels	P01-P03

- In addition to individual channel numbers, you can specify channel ranges. Use a hyphen between the first and last channel in the range.
- Channel numbers outside of the range specified above are considered invalid and result in errors.
- For channels starting with numbers, if you omit the "0" on the front, the channel is still accepted as long as it lies within the range.
- For channels starting with characters, if you omit a "0" when it is the second or later character, the channel is still accepted as long as it lies within the range.  
Ex.: 1 is recognized as 001, and A1 is recognized as A001.
- If some channels that do not exist are specified in the channel numbers or range, the specification is considered invalid and an error results. An error also occurs when existing channels are specified but their corresponding modules are not installed. However, an error does not occur if all specified channels exist and at least one channel's corresponding module is installed (even if one or more channels' module is not installed).
- Multiple channel ranges cannot be specified at the same time.
- Depending on the installed modules, channels numbers and ranges in setting commands (display related), control commands, and output commands may not be recognized.

### Upper and Lower Limit of Span (Measurement Channels)

#### Decimal Point

The decimal place is determined for both input and output. The upper and lower limit values are set without a decimal point, but with the decimal place taken into account.

#### • DC Voltage

Input Type	String	Measuring Range		Setting Range for Lower/Upper Limit of Span	
			String		Difference Computation
Voltage	VOLT	20 mV	20mV	-20.000 to 20.000 mV	±20.000 mV
		60 mV	60mV	-60.00 to 60.00 mV	±60.00 mV
		200 mV	200mV	-200.00 to 200.00 mV	±200.00 mV
		2 V	2V	-2.0000 to 2.0000 V	±2.0000 V
		6 V	6V	-6.000 to 6.000 V	±6.000 V
		20 V	20V	-20.000 to 20.000 V	±20.000 V
		100 V	100V	-100.00 to 100.00 V	±100.00 V
		60 mV (high resolution)	60mVH	0.000 to 60.000 mV	0.000 to 60.000 mV
		1 V	1V	-1.0000 to 1.0000 V	±1.0000 V
		6 V (high resolution)	6VH	0.0000 to 6.0000 V	0.0000 to 6.0000 V

## • Contact

Input Type	String	Measuring Range		Setting Range for Lower/Upper	
			String	Limit of Span	Difference Computation
Contact	DI	Level	LEVEL	0 or 1 (0 for less than 24 V, 1 for 24 V or more)	-1, 0, 1
		Contact	CONTACT	0 or 1 (0 for contact OFF, 1 for contact ON)	-1, 0, 1

## • Thermocouple

Input Type	String	Measuring Range		Setting Range for Lower/Upper	
			String	Limit of Span	Differential Computation
Thermo-couple	TC	Type R	R	0.0 to 1760.0 °C	±1760.0 °C
		Type S	S	0.0 to 1760.0 °C	±1760.0 °C
		Type B	B	0.0 to 1820.0 °C	±1820.0 °C
		Type K	K	-200.0 to 1370.0 °C	±1570.0 °C
		Type E	E	-200.0 to 800.0 °C	±1100.0 °C
		Type J	J	-200.0 to 1100.0 °C	±1300.0 °C
		Type T	T	-200.0 to 400.0 °C	±600.0 °C
		Type N	N	0.0 to 1300.0 °C	±1300.0 °C
		Type W	W	0.0 to 2315.0 °C	±2315.0 °C
		Type L	L	-200.0 to 900.0 °C	±1100.0 °C
		Type U	U	-200.0 to 400.0 °C	±600.0 °C
		KPvsAu7Fe	KPvsAu7Fe	0.0 to 300.0 K	±300.0 K
		PLATINEL	PLATINEL	0.0 to 1400.0 °C	±1400.0 °C
		PR40-20	PR40-20	0.0 to 1900.0 °C	±1900.0 °C
		NiNiMo	NiNiMo	0.0 to 1310.0 °C	±1310.0 °C
		WRe3-25	WRe3-25	0.0 to 2400.0 °C	±2400.0 °C
		W/WRe26	WWRe26	0.0 to 2400.0 °C	±2400.0 °C
Type N (AWG14)	N14	0.0 to 1300.0 °C	±1300.0 °C		
Type XK GOST	XK	-200.0 to 600.0 °C	±800.0 °C		

## • RTD

Input Type	String	Measuring Range		Setting Range for Lower/Upper Limit	
			String	of Span	Differential Computation
RTD	RTD	Pt100	[1] Pt100-1	-200.0 to 600.0 °C	±800.0 °C
			[2] Pt100-2	-200.0 to 250.0 °C	±450.0 °C
		JPt100	[1] JPt100-1	-200.0 to 550.0 °C	±750.0 °C
			[2] JPt100-2	-200.0 to 250.0 °C	±450.0 °C
		Pt100 (high [2] resolution)	[1] Pt100-1H	-140.00 to 150.00 °C	±290.00 °C
			Pt100-2H		
		JPt100 (high [2] resolution)	[1] JPt100-1H	-140.00 to 150.00 °C	±290.00 °C
			[2] JPt100-2H		
		Ni100 SAMA	Ni100SAMA	-200.0 to 250.0 °C	±450.0 °C
		Ni100 DIN	Ni100DIN	-60.0 to 180.0 °C	±240.0 °C
		Ni120	Ni120	-70.0 to 200.0 °C	±270.0 °C
		Pt50	Pt50	-200.0 to 550.0 °C	±750.0 °C
		Cu10 GE	Cu10GE	-200.0 to 300.0 °C	±500.0 °C
		Cu10 L&N	Cu10LN	-200.0 to 300.0 °C	±500.0 °C
		Cu10 WEED	Cu10WEED	-200.0 to 300.0 °C	±500.0 °C
		Cu10 BAILEY	Cu10BAILEY	-200.0 to 300.0 °C	±500.0 °C
		J263B	J263B	0.0 to 300.0 K	±300.0 K
		Cu10 at 20°C a=0.00392	Cu10a392	-200.0 to 300.0 °C	±500.0 °C
		Cu10 at 20°C a=0.00393	Cu10a393	-200.0 to 300.0 °C	±500.0 °C
Cu25 at 0°C a=0.00425	Cu25	-200.0 to 300.0 °C	±500.0 °C		

The number in brackets for the setting range is the RTD measurement current (mA). If no number is given, 1 mA, 2 mA, or both are supported.

### 1.3 Parameters

- RTD (cont.)

Input Type		Measuring Range		Setting Range for Lower/Upper Limit	
	String		String	of Span	Differential Computation
RTD	RTD	Cu53 at 0°C a=0.00426035	Cu53	-50.0 to 150.0 °C	±200.0°C
		Cu100 at 0°C a=0.00425	Cu100	-50.0 to 150.0 °C	±200.0°C
		Pt25	Pt25	-200.0 to 550.0 °C	±750.0°C
		Cu10 GE (high resolution)	Cu10GEH	-200.0 to 300.0 °C	±500.0°C
		Cu10 L&N (high resolution)	Cu10LNH	-200.0 to 300.0 °C	±500.0°C
		Cu10 WEED (high resolution)	Cu10WEEDH	-200.0 to 300.0 °C	±500.0°C
		Cu10 BAILEY (high resolution)	Cu10BAILEYH	-200.0 to 300.0 °C	±500.0°C
		Pt100 [1] (Anti noise) [2]	Pt100-1R	-200.0 to 600.0 °C	±800.0°C
			Pt100-2R	-200.0 to 250.0 °C	±450.0°C
		JPt100 [1] (Anti noise) [2]	JPt100-1R	-200.0 to 550.0 °C	±750.0°C
			JPt100-2R	-200.0 to 250.0 °C	±450.0°C
		Pt100 GOST	Pt100G	-200.0 to 600.0 °C	±800.0°C
		Cu100 GOST	Cu100G	-200.0 to 200.0 °C	±400.0°C
		Cu50 GOST	Cu50G	-200.0 to 200.0 °C	±400.0°C
		Cu10 GOST	Cu10G	-200.0 to 200.0 °C	±400.0°C
		Pt500	Pt500	-200.0 to 600.0 °C	±800.0°C
Pt1000	Pt1000	-200.0 to 600.0 °C	±800.0°C		

The number in brackets for the setting range is the RTD measurement current (mA). If no number is given, 1 mA, 2 mA, or both are supported.

- Resistance

Input Type		Measuring Range		Setting Range for Lower/Upper Limit	
	String		String	of Span	Differential Computation
Resis- tance	OHM	20 Ω	20ohm	0.000 to 20.000 Ω	±20.000 Ω
		200 Ω	200ohm	0.00 to 200.00 Ω	±200.00 Ω
		2 kΩ	2000ohm	0.0 to 2000.0 Ω	±2000.0 Ω

- Strain

Input Type		Measuring Range		Setting Range for Lower/Upper	
	String		String	Limit of Span	Differential Computation
Strain	STR	2000 μSTR	2000uSTR	-2000.0 to 2000.0 μSTR	±2000.0 μSTR
		20000 μSTR	20000uSTR	-20000 to 20000 μSTR	±20000 μSTR
		200000 μSTR	200000uSTR	-20000 to 20000 μSTR	±200000 μSTR

The 200000 μSTR measuring range is 20000 (minimum resolution of 10 μSTR) on the instrument's setting/output data.

- Pulse

Input Type		Measuring Range		Setting Range for Lower/Upper Limit	
	String		String	of Span	Differential Computation
Pulse	PULSE	LEVEL	LEVEL	0 to 30000	±30000
		CONTACT	CONTACT	0 to 30000	±30000

- Analog Output

Output Type		Output Range		Setting Range for Lower/Upper Limit	
	String		String	of Span	Available output range
Volt Current	AO	Volt output (V)	10V	-10.000 to 10.000 V	±11.000 V
		Current output (mA)	20mA	0.000 to 20.000 mA	0.000 to 22.000 mA

- **PWM Output**

Output Type	Output Range		Pulse Interval Range*	Span Setting Range
	String	String		
PMW	PMW	PMW output (1ms)	1mS	0.000 to 100.000%
		PMW output (10ms)	10mS	

\* Settings of 1 to 30000 ms (1 ms range) and 10 to 30000 ms (10 ms range) are allowed, but the setting command is specified as a multiple of the output range. Refer to the AO command in section 1.4.

### Note

For information on the measurement accuracy at each measuring range, see the main unit manual (IM MW100-01E).

## Upper and Lower Limit of Span (MATH Channels)

Set the mantissa between –9999999 and 99999999. Set the decimal place in the range from 0 to 4.

## Upper and Lower Limit of Scaling

Set between –30000 and 30000. Set the decimal place in the range from 0 to 4.

## Alarm Types

The following shows alarm types that can be set by channel and input type.

Channel Type	Input Type	MATH Type	Alarm Type			
			Hi/Lo lim (H/L)	Diff. H/L lim (DH/DL)	RoC lim. on inc/dec (RH/RL)	Delay on inc/dec (TH/TL)
Meas channels	SKIP	-	No	No	No	No
	VOLT/TC/	OFF	Yes	No	Yes	Yes
	RTD/DI/OHM/	Scale	Yes	No	Yes	Yes
	STR/PULSE	Diff. comp	Yes	Yes	Yes	Yes
	RRJC	-	Yes	No	Yes	Yes
MATH channels	-	OFF	No	No	No	No
		ON	Yes	No	No	Yes

Yes: Can be set, No: Cannot be set

## Alarm Value Setting Range

The following shows the setting ranges for alarm values.

### Measurement Channels

Alarm Type	Computation Type	Alarm Value Setting Range
H/L	OFF/DELTA/RRJC	Normal mode span setting range
	SCALE	Scale Low to High limit (low limit < high limit) Scale High to Low limit (high limit < low limit)
DH/DL	DELTA	Difference mode span setting range
RH/RL	OFF/DELTA/RRJC	1 to width of normal mode span setting range
	SCALE	1 to width of scale upper/lower limit values
TH/TL	OFF/DELTA/RRJC	Normal mode span setting range
	SCALE	Scale Low to High limit (low limit < high limit) Scale High to Low limit (high limit < low limit)

### MATH Channels

Within the MATH channels span range (–9999999 to 99999999 (mantissa))

## Hysteresis Value Setting Range


The following shows the setting ranges for hysteresis values. The set hysteresis does not apply to the high/low limit on rate-of-change alarm.

Alarm Type	Hysteresis Value Setting Range
H/DH/TH	0 to (alarm value – alarm value setting range lower limit)
L/DL/TL	0 to (alarm value setting range upper limit – alarm value)

### MATH Constants and Communication Input Values

The following shows the allowable setting range and notation methods for MATH constants and communication input values.

#### Setting Range for MATH Constants and Communication Input Values



Allowed Setting Range

- (1) Negative number ( $-9.9999 \times 10^{+29}$  to  $-1.0000 \times 10^{-30}$ )
- (2) Zero (0)
- (3) Positive number ( $1.0000 \times 10^{-30}$  to  $9.9999 \times 10^{+29}$ )

#### Notation for MATH Constants and Communication Input Values

Notation	Format	General Example
Real number notation	<Mantissa>	+0.12, -1.3, 2.456, 78
Exponential notation	<Mantissa>E<Exponent>	-1.23E-21
	<Mantissa>: =<symbol><numerical value> [.<numerical value>] <Mantissa>: =<symbol><numerical value> <numerical value>: =0 to 9 (1 or more) <symbol>: = "+", "-", or blank	

- The maximum number of digits for the mantissa is 5. Values having 6 or more digits are rounded to the 5th digit.
- If the symbol is blank, the next numerical value is treated as a positive number.

### Channel Structure


Individual measurement and MATH channels (001-060 or A001-300) can be separated by periods, or a consecutive range of channels can be specified using a hyphen.

Example To specify A001 and A003, A001.A003. To specify A001 through A003, A001-003. To specify A001 through A003 and A005, A001-A003.A005.

### Point Structure

This is the point structure of broken-line input channels. Each point represents a time of up to thirty-two points (x: integer between 0 and 86400) and an output value (y: integer between -30000 and 30000).

#### Point Structure of Broken-Line Input Channels.




#### Example of Broken-Line Input Channel Setting

The points of the broken-line input channel consist of only those specified as parameters of the UL command. The last point must be set to a terminator of point (-1.0).

VL commands of three types can be selected: OFF, SINGLE, and REPEAT.

(Example) VLP01, SINGLE, (0.100), (60.200), (120.200), (121.100), (180.100), (-1.0)





## Action Types

The following shows the action types available for Event/Action settings (SL commands).

### Action Types

Action Types	Description
MEMORY_START	Starts recording
MEMORY_STOP	Stops recording
MEMORY_SAVE	Divides and Saves the measured/computed data file
MEMORY_SAVE_T	Divides and saves the thinned data file
MATH_START	Starts computation
MATH_STOP	Stops computation
MATH_CLEAR	Clears the computation
MATH_RESET	Resets computation
MATH_RST_GRP1	Resets computation on MATH group 1
MATH_RST_GRP2	Resets computation on MATH group 2
MATH_RST_GRP3	Resets computation on MATH group 3
MATH_RST_GRP4	Resets computation on MATH group 4
MATH_RST_GRP5	Resets computation on MATH group 5
MATH_RST_GRP6	Resets computation on MATH group 6
MATH_RST_GRP7	Resets computation on MATH group 7
TRIGGER1	Activates trigger 1
TRIGGER2	Activates trigger 2
TRIGGER3	Activates trigger 3
ALARM_ACK	Checks the alarm status
FLAG	Sets the flag to a value
TIMER1_RESET	Resets timer 1
TIMER2_RESET	Resets timer 2
TIMER3_RESET	Resets timer 3
TIMER4_RESET	Resets timer 4
TIMER5_RESET	Resets timer 5
TIMER6_RESET	Resets timer 6
MESSAGE0	Writes message 0 (Free message) in the data file being acquired
MESSAGE1	Writes message 1 in the data file being acquired
MESSAGE2	Writes message 2 in the data file being acquired
MESSAGE3	Writes message 3 in the data file being acquired
MESSAGE4	Writes message 4 in the data file being acquired
MESSAGE5	Writes message 5 in the data file being acquired
FILE_SAVE	Saves settings files
FILE_LOAD	Loads settings files
MANUAL_SAMPLE	Executes manual sample recording
MANUAL_DIVIDE	Divides manual sample files

- You cannot set same action type for EDGE and LEVEL.
  - \* The following action types are judged as being the same.
    - MEMORY\_START and MEMORY\_STOP
    - MATH\_START and MATH\_STOP
    - FLAG of the same flag number
- You cannot set same action type for multiple LEVELs.
  - \* The following action types are judged as being the same.
    - MEMORY\_START and MEMORY\_STOP
    - MATH\_START and MATH\_STOP
    - FLAG of the same flag number

The above setting errors occur when transitioning from Setting mode to Measurement mode.

Action Types That Can Be Set (When Event Detection Method Is EDGE)

Action Type	Event Type							
	DI	ALARM	MEMORY	ALARM_CH	RELAY	TIMER	MATH_TIME	USER_KEY
MEMORY_START	✓	✓		✓	✓	✓	✓	✓
MEMORY_STOP	✓	✓		✓	✓	✓	✓	✓
MEMORY_SAVE	✓	✓		✓	✓	✓	✓	✓
MEMORY_SAVE_T	✓	✓		✓	✓	✓	✓	✓
MATH_START	✓	✓	✓	✓	✓	✓	✓	✓
MATH_STOP	✓	✓	✓	✓	✓	✓	✓	✓
MATH_CLEAR	✓	✓	✓	✓	✓	✓	✓	✓
MATH_RESET	✓	✓	✓	✓	✓	✓	✓	✓
MATH_RST_GR1	✓	✓	✓	✓	✓	✓	✓	✓
MATH_RST_GR2	✓	✓	✓	✓	✓	✓	✓	✓
MATH_RST_GR3	✓	✓	✓	✓	✓	✓	✓	✓
MATH_RST_GR4	✓	✓	✓	✓	✓	✓	✓	✓
MATH_RST_GR5	✓	✓	✓	✓	✓	✓	✓	✓
MATH_RST_GR6	✓	✓	✓	✓	✓	✓	✓	✓
MATH_RST_GR7	✓	✓	✓	✓	✓	✓	✓	✓
TRIGGER1	✓	✓	✓	✓	✓	✓	✓	✓
TRIGGER2	✓	✓	✓	✓	✓	✓	✓	✓
TRIGGER3	✓	✓	✓	✓	✓	✓	✓	✓
ALARM_ACK	✓	✓	✓	✓	✓	✓	✓	✓
FLAG	✓	✓	✓	✓	✓	✓	✓	✓
TIMER1_RESET	✓	✓	✓	✓	✓	✓	✓	✓
TIMER2_RESET	✓	✓	✓	✓	✓	✓	✓	✓
TIMER3_RESET	✓	✓	✓	✓	✓	✓	✓	✓
TIMER4_RESET	✓	✓	✓	✓	✓	✓	✓	✓
TIMER5_RESET	✓	✓	✓	✓	✓	✓	✓	✓
TIMER6_RESET	✓	✓	✓	✓	✓	✓	✓	✓
MESSAGE0	✓	✓	✓	✓	✓	✓	✓	✓
MESSAGE1	✓	✓	✓	✓	✓	✓	✓	✓
MESSAGE2	✓	✓	✓	✓	✓	✓	✓	✓
MESSAGE3	✓	✓	✓	✓	✓	✓	✓	✓
MESSAGE4	✓	✓	✓	✓	✓	✓	✓	✓
MESSAGE5	✓	✓	✓	✓	✓	✓	✓	✓
FILE_SAVE								✓
FILE_LOAD								✓
MANUAL_SAMPLE	✓	✓		✓	✓	✓	✓	✓
MANUAL_DIVIDE	✓	✓		✓	✓	✓	✓	✓

✓: Can be set, Blank: Cannot be set

## Action Types That Can Be Set (When Event Detection Method Is LEVEL)

Action Type	Event Type							
	DI	ALARM	MEMORY	ALARM_CH	RELAY	TIMER	MATH_TIME	USER_KEY
MEMORY_START	✓	✓		✓	✓	✓	✓	✓
MEMORY_STOP								
MEMORY_SAVE								
MEMORY_SAVE_T								
MATH_START	✓	✓	✓	✓	✓	✓	✓	✓
MATH_STOP								
MATH_CLEAR								
MATH_RESET								
MATH_RST_GR1								
MATH_RST_GR2								
MATH_RST_GR3								
MATH_RST_GR4								
MATH_RST_GR5								
MATH_RST_GR6								
MATH_RST_GR7								
TRIGGER1								
TRIGGER2								
TRIGGER3								
ALARM_ACK								
FLAG	✓	✓	✓	✓	✓	✓	✓	✓
TIMER1_RESET								
TIMER2_RESET								
TIMER3_RESET								
TIMER4_RESET								
TIMER5_RESET								
TIMER6_RESET								
MESSAGE0								
MESSAGE1								
MESSAGE2								
MESSAGE3								
MESSAGE4								
MESSAGE5								
FILE_SAVE								
FILE_LOAD								
MANUAL_SAMPLE								
MANUAL_DIVIDE								

✓: Can be set, Blank: Cannot be set

### Byte Output Order

The following explains the output order for 2 bytes, 4 bytes, and 8 bytes when the byte output order is set to MSB (most significant byte) first or LSB (least significant byte) first.

**Example of storage of 2 bytes of data Data = 0x 01 23 (hexadecimal notation)**

byte	0	1	
Byte array (stored with MSB)	0x 01	0x 23	
Byte array (stored with LSB)	0x 23	0x 01	

**Example of storage of 4 bytes of data Data = 0x 01 23 45 67 (hexadecimal notation)**

byte	0	1	2	3	
Byte array (stored with MSB)	0x 01	0x 23	0x 45	0x 67	
Byte array (stored with LSB)	0x 67	0x 45	0x 23	0x 01	

**Example of storage of 8 bytes of data Data = 0x 01 23 45 67 89 ab cd ef (hexadecimal notation)**

byte	0	1	2	3	4	5	6	7	
Byte array (stored with MSB)	0x 01	0x 23	0x 45	0x 67	0x 89	0x ab	0x cd	0x ef	
Byte array (stored with LSB)	0x ef	0x cd	0x ab	0x 89	0x 67	0x 45	0x 23	0x 01	

### Measurement Interval and MATH Interval

The following setting errors occur when transitioning from Setting mode to Measurement mode.

- Make sure measurement groups 1, 2, and 3 satisfy the following relationship.  
Measurement groups turned OFF are ignored.  
Meas. gr 1 ≤ meas gr 2 ≤ meas gr 3
- When using a 10 ms measurement interval, the maximum number of measurement channels is 10.
- When using a 50 ms measurement interval, the maximum number of measurement channels is 30.
- Set an interval of 100 ms or more for the measurement and MATH intervals of the modules with shortest measurement intervals of 100 ms.
- Set an interval of 500 ms or more for the measurement and MATH intervals of the modules with shortest measurement intervals of 500 ms.

The following setting error occurs when computation starts.

- Set a MATH interval is 100 ms or higher.

### User Specified Strings

Alphanumeric English characters and symbols can be entered (see appendix 5, "ASCII Character Codes."

However, the following characters may not be used.

- [ " ] (double-quote), [ ' ] (single quote), [ , ] (comma), [ : ] (colon), [ ; ] (semicolon), [ ? ] (question mark)

### Password String

Alphanumeric English characters and symbols can be entered (see appendix 5, "ASCII Character Codes."

However, the following characters may not be used.

- [ ] (space), [ " ] (double-quote), [ ' ] (single quote), [ \* ] (asterisk), [ , ] (comma), [ : ] (colon), [ ; ] (semicolon), [ ? ] (question mark)

## Host Name and Domain Name String

Alphanumeric English characters and hyphens [ - ], periods [ . ], and underscores [ \_ ] can be used.

## File Name and Folder Name String

Alphanumeric English characters and pound signs [ # ], percentage symbols [ % ], parentheses [ ( ) ], hyphens [ - ], at marks [ @ ], and underscores [ \_ ] can be used. However, the following character strings cannot be entered.

AUX, CON, PRN, NUL, COM1 to COM9, LPT1 to LPT9

## 1.4 Setting Commands (System Related)

### SR Input Range Settings

**Setting** When p2=SKIP  
 SRp1,p2<terminator>  
 When p2=RRJC  
 SRp1,p2,p3,p4,p5,p6<terminator>  
 When p2=VOLT, TC, RTD, DI, OHM, STR, or PULSE  
 When p6=OFF  
 SRp1,p2,p3,p4,p5,p6<terminator>  
 When p6=DELTA  
 SRp1,p2,p3,p4,p5,p6,p7<terminator>  
 When p6=SCALE  
 SRp1,p2,p3,p4,p5,p6,p7,p8,p9,p10  
 <terminator>

#### When Setting SKIP

**Setting** SRp1,p2<terminator>  
 p1 Channel range (001 to 060)  
 p2 Input type (SKIP)

**Query** SR[p1]?

**Example** Skip channel 1.  
 SR001,SKIP

**Explanation**

- Channels set to SKIP are not measured.
- Specify measurement channels for p1.

#### When Setting RRJC

**Setting** SRp1,p2,p3,p4,p5,p6<terminator>  
 p1 Channel range (001 to 060)  
 p2 Input type (RRJC)  
 RRJC Remote RJC  
 p3 Measuring range (specify thermocouple range)  
 p4 Lower limit of span  
 p5 Upper limit of span  
 p6 Reference channel number (001 to 060)

**Query** SR[p1]?

**Example** Set the measuring range on channel 2 to K, lower limit of span to 0.0°C, upper limit of span to 500.0°C, and set channel 1 (reference channel) as the remote RJC reference channel.  
 SR002,RRJC,K,0,5000,001

**Explanation**

- Set the p3, p4, and p5 setting parameters according to the table in section 1.3.
- The decimal place is fixed as shown in the table in section 1.3.
- Specify measurement channels on p1.

### When Setting Voltage, TC, RTD, Contact, Resistance, Strain Input, and Pulse

#### • With no MATH

**Setting** SRp1,p2,p3,p4,p5,p6<terminator>  
 p1 Channel range (001 to 060)  
 p2 Input type  
 VOLT DC voltage  
 TC Thermocouple  
 RTD Resistance temperature detector  
 DI Contact  
 OHM Resistance  
 STR Strain  
 PULSE Pulse  
 p3 Measuring range  
 p4 Lower limit of span  
 p5 Upper limit of span  
 p6 MATH type (OFF)

**Query** SR[p1]?

**Example** Set the input type for channels 1 to 4 to TC type R, the lower limit span to 0.0°C, and the upper limit of span to 1760.0°C.  
 SR001-004,TC,R,0,17600,OFF

**Explanation** Specify measurement channels for p1.

#### • When Setting Difference Computation between Channels

**Setting** SRp1,p2,p3,p4,p5,p6,p7<terminator>  
 p1 Channel range (001 to 060)  
 p2 Input type  
 VOLT DC voltage  
 TC Thermocouple  
 RTD Resistance temperature detector  
 DI Contact input  
 OHM Resistance input  
 STR Strain input  
 PULSE Pulse  
 p3 Measuring range  
 p4 Lower limit of span  
 p5 Upper limit of span  
 p6 MATH type (DELTA)  
 p7 Reference channel numbers (001 to 060)

**Query** SR[p1]?

**Example** Set the MATH type for channel 10 to difference computation between channels with channel 1 (the reference channel), set the input type to TC, measuring range to R, the lower limit span to 10.0°C, and the upper limit of span to 100.0°C.  
 SR010,TC,R,100,1000,DELTA,001

**Explanation** Specify measurement channels on p1.

**When Setting Scaling**

Setting SRp1,p2,p3,p4,p5,p6,p7,p8,p9,p10  
<terminator>

p1 Channel range (001 to 060)

p2 Input type

VOLT	DC voltage
TC	Thermocouple
RTD	Resistance temperature detector
DI	Contact input
OHM	Resistance input
STR	Strain input
PULSE	Pulse

p3 Measuring range

p4 Lower limit of span

p5 Upper limit of span

p6 MATH type (SCALE)

p7 Scaling lower limit (-30000 to 30000)

p8 Scaling upper limit (-30000 to 30000)

p9 Decimal place (0 to 4)

p10 Unit (max 6 characters)

Query SR[p1]?

Example Convert the DC voltage measured on channel 2 to DC current. Set the measuring range to 6V (high resolution), lower limit of span to 1 V, upper limit of span to 5 V, lower limit of scaling to 0.00A, and upper limit of scaling to 5.00A.

SR002,VOLT,6VH,10000,50000,SCALE,0,500,2,A

Explanation

- Set the p3, p4, and p5 setting parameters according to the table in section 1.3.
- Specify measurement channels on p1.
- For the characters that can be used for p10, see user specified characters in section 1.3.

**SF Filter Settings**

Setting SFp1,p2<terminator>

p1 Channel range (001 to 060)

p2 Filter coefficient (0, 5, 10, 20, 25, 40, 50, 100)

Query SF[p1]?

Example Set the filter coefficient for channel 2 to 5.

SF002,5

Explanation Specify measurement channels on p1. However, do not set this on the channels of the digital input module.

**XB Burnout Settings**

Setting XBp1,p2<terminator>

p1 Channel range (001 to 060)

p2 Burnout processing (OFF, UP, DOWN)

Query XB[p1]?

Example Set UP (+OVER) when burnout occurs on channel 1.

XB001,UP

Explanation Specify measurement channels that can accept TC input for p1.

**XJ Reference Junction Compensation Settings**

Setting

When p2=INT  
XJp1,p2<terminator>

When p2=EXT  
XJp1,p2,p3<terminator>

**For an Internal Compensation Circuit**

Setting XJp1,p2<terminator>

p1 Channel range (001 to 060)

p2 Reference junction compensation selection (INT)

Query XJ[p1]?

Example Set RJC on channel 1 to internal compensation circuit.

XJ001,INT

Explanation Specify measurement channels that can accept TC input for p1

**For External RJC**

Setting XJp1,p2,p3<terminator>

p1 Channel range (001 to 060)

p2 Reference junction compensation selection (EXT)

p3 External RJC value (-20000 to 20000)

Query XJ[p1]?

Example Set RJC on channel 2 to external RJC, and the compensation value to 0  $\mu$ V.

XJ002,EXT,0

Explanation

- Units of p3 are  $\mu$ V.
- Specify measurement channels that can accept TC input for p1.

**PF Pulse Input Module Chattering Filter Settings**

Setting PFp1,p2

p1 Channel range (001 to 060)

p2 Chattering filtering (OFF/ON)

Query PF[p1]?

Example Turn on the chattering filter on channel 23.

PF23,ON

Explanation For p1, specify channels included on the pulse input module.

## 1.4 Setting Commands (System Related)

### SA Alarm Settings

Setting When p3=OFF  
 SAp1,p2,p3<terminator>  
 When p3 is not OFF  
 SAp1,p2,p3,p4,p5<terminator>

#### When Alarms are OFF

Setting SAp1,p2,p3<terminator>  
 p1 Channel range (001 to 060 and A001 to A300)  
 p2 Alarm number (1 to 4)  
 p3 Alarm type (OFF)

Query SA[p1[p2]]?

Example Turn OFF alarm number 1 on channel 10.

SA10,1,OFF

Explanation

- If the /M1 MATH function option is not included, MATH channel settings cannot be performed (including queries).
- Specify measurement channels on 001 to 060 of p1.

#### With Alarms

Setting SAp1,p2,p3,p4,p5<terminator>  
 p1 Channel range (001 to 060 and A001 to A300)  
 p2 Alarm number (1 to 4)  
 p3 Alarm type  
 H Upper limit alarm  
 L Lower limit alarm  
 DH Difference upper limit alarm  
 DL Difference lower limit alarm  
 RH High limit on rate-of-change alarm  
 RL Low limit on rate-of-change alarm  
 TH Delay upper limit alarm  
 TL Delay lower limit alarm  
 p4 Alarm value  
 p5 Relay number  
 OFF No relay setting  
 001 to 060 Relay number

Query SA[p1[p2]]?

Example Set alarm number 1 on channel 2 to upper limit alarm (alarm value 100.0), and set relay number 12 to operate upon alarm occurrence.

SA002,1,H,1000,012

Explanation

- If the /M1 MATH function option is not included, MATH channels (A001 to A300) cannot be set (including queries). However, if the pulse input module is installed, MATH channels (A001 to A060) can be set (including queries).
- Specify measurement channels on 001 to 060 of p1.
- When the input range setting (SR command) is SKIP, p3 cannot be set to anything other than OFF.

- In the following case, all alarm settings for the channel are OFF.
  - Changing the input type, measuring range, and MATH type
  - When scaling, changing the scaling values (including changing the decimal place).
  - Turning MATH channels ON/OFF and changing expressions.
- The p3 DH and DL setting are only valid when the MATH type is difference between channels.
- If p3 is set to RH or RL, set the interval time for high limit/low on rate of change using the XA command.
- If p3 is set to TH or TL, set the delay time using the BD command.
- See the table in section 1.3 for the alarm value setting range for p4.
- For information on how to add relay numbers, see the main manual.
- For MATH channels, the alarm types that can be set are H (high limit alarm), TH (delay upper limit), TL (delay lower limit), and L (low limit alarm) only.
- Set the output type for relays to alarm using the XD command, and set the relay numbers to p5.
- p3 and p5 cannot be changed while recording.

### VA Alarm Hysteresis Settings

Setting VAp1,p2,p3<terminator>  
 p1 Channel range (001 to 060)  
 p2 Alarm number (1 to 4)  
 p3 Hysteresis value

Query VA[p1[p2]]?

Example Set alarm number 1 on channel 2 to hysteresis value 100.

VA002,1,100

Explanation

- Specify measurement channels on 001 to 060 of p1.
- If the alarm type is high limit/low limit on rate-of-change alarm, the hysteresis setting is invalid.
- See section 1.3 for the setting ranges for hysteresis values.
- If the alarm setting is no alarms, this cannot be set.

### XA Settings Related to Alarm

Setting XAp1,p2,p3<terminator>  
 p1 Rate-of-change limit on increase interval (1 to 32)  
 p2 Rate-of-change limit on decrease interval (1 to 32)  
 p3 Alarm status hold (OFF/ON)

Query XA?

Example Set the rate-of-change limit on increase interval to 10 and the rate-of-change limit on decrease to 12. Hold the alarm status.

XA10,12,ON

Explanation Interval is set using the units of the measurement interval. The measurement interval is set using the XV command.



## 1.4 Setting Commands (System Related)

### **BD** Delay Alarm Settings

- Setting** BDp1,p2<terminator>  
 p1 Channel number (001 to 060 or A001 to A300)  
 p2 Alarm delay (1 to 3600 s)
- Query** BD[p1]?
- Example** Set the alarm delay of channel 1 to 20 s.  
 BD001,20
- Explanation** Set the delay time to an integer multiple of the measurement or MATH interval.

### **XD** Relay Settings

- Setting** When p2=MEDIA, FAIL, or ERROR  
 XDp1,p2<terminator>  
 When p2=COM  
 XDp1,p2,p3<terminator>  
 When p2=ALARM, p4=ON, or p5=AND  
 XDp1,p2,p3,p4,p5<terminator>  
 When p2=ALARM, p4=OFF, or p5=OR  
 XDp1,p2,p3,p4,p5,p6<terminator>
- p1 Relay range (001 to 060)  
 p2 Relay output type  
 ALARM Alarm  
 COM Communication input  
 MEDIA Media free space  
 FAIL FAIL output  
 ERROR Error output
- p3 Relay energized/de-energized  
 ENERG Energize  
 DE\_EN De-energize
- p4 Relay status hold (OFF/ON)  
 p5 Relay operation conditions  
 AND Operate when all specified alarms are on alarm status.  
 OR Operate when at least one of the specified alarms is alarm status.
- p6 Reflash function (OFF/ON)
- Query** XD[p1]?
- Example** Set relay number 11 to energize, relay status hold to OFF, relay operation condition to OR, and reflash function to ON.  
 XD11,ALARM,ENERG,OFF,OR,ON
- Explanation**
- Specify relay on p1.
  - If the relay on p1 is set to the relay number of the SA command, if you change the output type the SA command's relay number turns OFF.
  - The relay output type and affirmative/negative of the parameter settings are shown below.

Relay Output Type	Energize/De-energize	Hold/Non-Hold	AND/OR	Reflash Function
ALARM	Yes	Yes	Yes	Yes
COM	Yes	No (fixed to non-hold)	No (fixed to OR)	No (fixed to OFF)
MEDIA	No (fixed to energize)	No (fixed to non-hold)	No (fixed to OR)	No (fixed to OFF)
FAIL	No (fixed to de-energize)	No (fixed to non-hold)	No (fixed to OR)	No (fixed to OFF)
ERROR	No (fixed to energize)	No (fixed to non-hold)	No (fixed to OR)	No (fixed to OFF)

- The reflash alarm can only be used when the relay status is non-hold (OFF) and the relay operation condition is OR.

### **SO** Expression Settings

- Setting** When p2=OFF  
 SOp1,p2<terminator>  
 When p2=ON  
 SO p1,p2,p3,p4,p5,p6,p7<terminator>  
 p1 MATH channel range (A001 to A300)  
 p2 MATH ON/OFF  
 p3 Expression (A001 to A060: max. 120 characters, A061 to A300: max. 8 characters)  
 p4 Lower limit of span (-9999999 to 99999999)  
 p5 Upper limit of span (-9999999 to 99999999)  
 p6 Span decimal place (0 to 4)  
 p7 Units (max 6 characters)
- Query** SO[p1]?
- Example** Turn MATH on MATH channel number 31 ON, set the expression to the sum of channels 1 and 2, set lower limit of span to 1.0000, upper limit of span to 5.0000, and units to V.  
 SOA031,ON,001+002,10000,50000,4,V
- Explanation**
- You can set this command on products with the /M1 MATH function option, or when the pulse input module is installed. The MATH channel range when the pulse input module is installed is (A001 to A060).
  - For expressions, see the main unit manual.
  - Enter setting parameters for p4, p5 excluding the decimal place.
  - If p1 is set to a MATH channel between A061 and A300, you can specify four arithmetic operations or MATH constants in p3 in addition to a communication input channel between C001 and C300.
  - For the characters that can be used for p7, see user specified characters in section 1.3.

### **SK** MATH Constant Settings

- Setting** SKp1,p2<terminator>  
 p1 Channel range (K01 to K60)  
 p2 MATH constants
- Query** SK[p1]?
- Example** Set MATH constant K01 to 1.0000E-10.  
 SKK01,1.0000E-10
- Explanation**
- You can set this command on products with the /M1 MATH function option.
  - See section 1.3 for the setting range for MATH constants.

## 1.4 Setting Commands (System Related)

### MG MATH Group Settings

Setting	MGp1,p2<terminator> p1 MATH group number (1 to 7) p2 Channel structure (up to 36 characters) (A001 to A060)
Query	MG[p1]?
Example	Set MATH group number 1 to channels A001 to A003. MG1,A001-A003
Explanation	<ul style="list-style-type: none"> <li>You can set this command on products with the /M1 MATH function option, or when the pulse input module is installed.</li> <li>See section 1.3 for the channel setting method.</li> </ul> <p>Note that the channels that can be input are A001 to A060.</p>

### RO Report Operation and Creation Time Settings

Setting	When p1=OFF ROp1<terminator> When p1=ON ROp1,p2,p3,p4,p5,p6,p7<terminator> p1 Report operation (OFF/ON) p2 Reset data when recording starts ON Reset OFF Do not reset p3 Time to create daily, weekly, and monthly reports hh Hour (00 to 23) p4 Day of week to create weekly report SUN Sunday MON Monday TUE Tuesday WED Wednesday THU Thursday FRI Friday SAT Saturday p5 Date to create monthly report dd Date (1 to 28) p6 Handling of abnormal input values for maximum, minimum, integral, or average values ERROR The report data is "Error" SKIP Ignore the abnormal input value and use the previous value p7 Handling of overflow values for integral/average values ERROR The report data is "Error" SKIP Ignore the overflow value and use the previous value LIMIT*1 The overflow value is replaced with the upper or lower limit
---------	---

\*1 The lower/upper limit value replaced differs depending on the channel's setting condition.

Measurement input channel	Measurement range upper and lower limit
Scaled measurement input channel	Upper and lower limit of scaling
MATH channel	Upper/lower limit of span

Query	RO?
Example	Set the following: Resetting upon recording start and report operation: ON; daily, weekly, and monthly reports: hour = 0 am; weekly reports: Monday; create monthly reports on the 1st; abnormal input value: ERROR; overflow values: ERROR. ROON,ON,00,MON,01,ERROR,ERROR
Explanation	<ul style="list-style-type: none"> <li>You can set this command on products with the /M3 report function option.</li> <li>The hour on which daily, weekly, and monthly reports are created is the same for all.</li> </ul>

### RM Report Execution Channel Settings

Setting	When p2=OFF RMp1,p2<terminator> When p2=ON RMp1,p2,p3,p4,p5<terminator> p1 Box number (01 to 60) p2 Use/do not use box (OFF/ON) p3 Channel range (001 to 060 and A001 to A300) p4 Unit of time for integration OFF The integral value of the data from each measurement or MATH interval SEC The integral value of data from each measurement or MATH interval ÷ computations per second MIN The integral value of data from each measurement or MATH interval ÷ computations per minute HOUR The integral value of data from each measurement or MATH interval ÷ computations per hour DAY The integral value of data from each measurement or MATH interval ÷ computations per day p5 Displayed unit string for integration (max 6 characters)
Query	RM[p1]?
Example	Turn ON box number 1, set the channel to 002, set the integration unit of time to hourly, and the unit string to kg/h. RM01,ON,HOUR,kg/h

- Explanation
- You can set this command on products with the /M3 report function option.
  - If the /M1 MATH function option is not included, MATH channels (A001 to A300) cannot be set (including queries). However, if the pulse input module is installed, MATH channels (A001 to A060) can be set (including queries).
  - For the characters that can be used for p5, see "User Specified Strings" in section 1.3.

## VL Broken-Line Input Channel Settings

- Setting
- When not using broken line  
VLp1,p2<terminator>
- When using broken line  
VLp1,p2,p3,p4,...p33,p34<terminator>
- p1 Sets broken-line input channels (P01 to P03)
- p2 Use/do not use broken line
- |        |                    |
|--------|--------------------|
| OFF    | Do not use         |
| SINGLE | Execute 1 cycle    |
| REPEAT | Execute repeatedly |
- p3-p34 Point structure (point notation (xx.yy))
- |    |  |
|----|--|
| xx | Break point time (0 to 86400 (sec.))       |
| yy | Break point output value (-30000 to 30000) |
- Query VL[p1]?
- Example Set broken line input channel p1 to a point structure of 0:100, 60:200, 120:200, 180:100.  
VLP01,SINGLE,(0.100),(60.200),(120.200),(180.100),(-1.0)
- Explanation
- You can set this command on products with the /M1 MATH function option.
  - The p3 of break point time is fixed at 0 seconds.
  - Set the break point time in ascending order. You cannot set multiple output values to the same time.
  - You must set the end of the point structure to (-1.0).
  - When broken line usage is SINGLE or REPEAT, and there is not even 1 point set for the point structure, this cannot be set.

## AO Output Range Settings

- Setting
- When p2=SKIP  
AOp1,p2<terminator>
- When p2=AO  
When p3=COM  
AOp1,p2,p3,p4,p5,p6,p7<terminator>
- When p3=TRANS  
AOp1,p2,p3,p4,p5,p6,p7,p8<terminator>
- When p2=PWM  
When p3=COM  
AOp1,p2,p3,p4,p5,p6,p7,p8<terminator>
- When p3=TRANS  
AOp1,p2,p3,p4,p5,p6,p7,p8,p9<terminator>

### When Setting SKIP

- Setting AOp1,p2<terminator>
- p1 Channel range (001 to 060)
- p2 Output type (SKIP)
- Query AO[p1]?
- Example Skip channel 1.  
A0001,SKIP

Explanation Specify output channels on p1.

### When Setting AO Channels

- Setting
- When using communication command output  
AOp1,p2,p3,p4,p5,p6.p7<terminator>
- When using transmission output  
AOp1,p2,p3,p4,p5,p6,p7,p8<terminator>
- p1 Channel range (001 to 060)
- p2 Output type (AO)
- p3 Output method
- |       |                              |
|-------|------------------------------|
| TRANS | Transmission output          |
| COM   | Communication command output |
- p4 Output range
- |      |                |
|------|----------------|
| 10V  | Voltage output |
| 20mA | Current output |
- p5 Lower limit of span (specify using mV or  $\mu$ A)
- |                 |                         |
|-----------------|-------------------------|
| -10000 to 10000 | (when p4 is 10 V)       |
| 0 to 20000      | (when p4 is 20 $\mu$ A) |
- p6 Lower limit of span (specify using mV or  $\mu$ A)
- |                 |                    |
|-----------------|--------------------|
| -10000 to 10000 | (when p4 is 10 V)  |
| 0 to 20000      | (when p4 is 20 mA) |
- p7 Preset value (specify using mV or  $\mu$ A)
- |                 |                      |
|-----------------|----------------------|
| -11000 to 11000 | (for voltage output) |
| 0 to 22000      | (for current output) |
- p8 Reference channel  
001 to 060 or A001 to A300
- Query AO[p1]?
- Example Set transmission output on channel 11 to 4-20 mA relative to the measured values on channel 1.  
A0011,AO,TRANS,20mA,4000,20000,0,001

- Explanation
- Specify output channels on p1.
  - When entering the setting parameters of p5, p6, and p7, exclude the decimal point.
  - If the /M1 MATH function option is not included, MATH channels (A001 to A300) cannot be set (including queries) on p8. However, if the pulse input module is installed, MATH channels (A001 to A060) can be set (including queries).

## 1.4 Setting Commands (System Related)

### When Setting PWM Channels

Setting	When using arbitrary output AOp1,p2,p3,p4,p5,p6,p7,p8<terminator> When using transmission output AOp1,p2,p3,p4,p5,p6,p7,p8,p9<terminator>
p1	Channel range (001 to 060)
p2	Output type (PWM)
p3	Output method TRANS   Transmission output COM      arbitrary output
p4	Output range 1 mS     1 ms interval output 10 mS    10 ms interval output
p5	Lower limit of span (0.001% units, 0 to 100000)
p6	Upper limit of span (0.001% units, 0 to 100000)
p7	Pulse interval (specify as a multiple) 1 to 30000 (both p4:1mS and 10mS same range)
p8	Preset value (0.001% units, 0 to 100000)
p9	Reference channel 001 to 060 or A001 to A300
Query	AO[p1]?
Example	Set output on channel 12 to arbitrary output. AO012,PWM,COM,1mS,0,100000,10,100000
Explanation	<ul style="list-style-type: none"> <li>Specify output channels on p1.</li> <li>Channels set to SKIP are not output.</li> <li>If the /M1 MATH function option is not included, MATH channels (A001 to A300) cannot be set (including queries) on p9. However, if the pulse input module is installed, MATH channels (A001 to A060) can be set (including queries).</li> <li>When p4=10ms, p7=10, the pulse interval is 10 x 10 = 100 ms.</li> </ul>

### AP Preset Operation Settings

Setting	APp1,p2,p3<terminator>
p1	Channel range (001 to 060)
p2	Operation upon startup LAST     Hold previous value PRESET   Output preset value
p3	Operation upon errors LAST     Hold previous value PRESET   Output preset value
Query	AP[p1]?
Example	Set the operation upon startup for channel 1 to PRESET, and operation upon errors to LAST. AP001,PRESET,LAST
Explanation	Specify output channels on p1.

### SL Event Action Settings

Setting	When p2=OFF SLp1,p2<terminator> When p2=DI SLp1,p2,p3,p4,p5,p6<terminator> When p2=ALARM SLp1,p2,p3,p4,p5<terminator> When p2=MEMORY SLp1,p2,p3,p4,p5<terminator> When p2=ALARM_CH SLp1,p2,p3,p4,p5,p6,p7<terminator> When p2=RELAY SLp1,p2,p3,p4,p5,p6<terminator> When p2=TIMER SLp1,p2,p3,p4,p5,p6<terminator> When p2=MATCH_TIME SLp1,p2,p3,p4,p5,p6<terminator> When p2=USER_KEY SLp1,p2,p3,p4,p5,p6<terminator>
---------	--

### When Action Does Not Occur

Setting	SLp1,p2<terminator> p1 Box number (01 to 30) p2 Event type (OFF)
Query	SL[p1]?
Example	Set box number 01 to no action. SL01,OFF

### When Action Occurs on Digital Input

Setting	SLp1,p2,p3,p4,p5,p6<terminator> p1 Box number (01 to 30) p2 Event type (DI) p3 Channel numbers (001 to 060) p4 Event detection method EDGE     Edge start LEVEL    Level start
p5	Action types
p6	Flag numbers (F01 to F60)
Query	SL[p1]?
Example	Set box number 02 to computation start action. SL02,DI,001,EDGE,MATH_START
Explanation	<ul style="list-style-type: none"> <li>The p6 setting is only valid when p5 is FLAG. For the action types, see section 1.3.</li> <li>Specify a measurement channel number for p3 that allows contact input.</li> </ul>

**When Action Occurs on Alarm Output**

Setting	SLp1,p2,p3,p4,p5<terminator> p1 Box number (01 to 30) p2 Event type (ALARM) p3 Event detection method EDGE Edge start LEVEL Level start p4 Action types p5 Flag numbers (F01 to F60)
Query	SL[p1]?
Example	Set box number 3 to recording start action on alarm occurrence. SL03,ALARM,LEVEL,MEMORY_START
Explanation	The p5 setting is only valid when p4 is FLAG. For the action types, see section 1.3.

**When Action Occurs on Recording Start**

Setting	SLp1,p2,p3,p4,p5<terminator> p1 Box number (01 to 30) p2 Event type (MEMORY) p3 Event detection method EDGE Edge start LEVEL Level start p4 Action types p5 Flag numbers (F01 to F60)
Query	SL[p1]?
Example	Set box number 4 to the alarm acknowledge action. SL04,MEMORY,EDGE,ALARM_ACK
Explanation	The p5 setting is only valid when p4 is FLAG. For the action types, see section 1.3.

**When Action Occurs on Occurrence of Alarm on Certain Channel**

Setting	SLp1,p2,p3,p4,p5,p6.p7<terminator> p1 Box number (01 to 30) p2 Event type (ALARM_CH) p3 Channel numbers (001 to 060 and A001 to A300) p4 Alarm number (1 to 4) p5 Event detection method EDGE Edge start LEVEL Level start p6 Action types p7 Flag numbers (F01 to F60)
Query	SL[p1]?
Example	Set box number 5 to recording start/stop action on occurrence of alarm on channel 1. SL05,ALARM_CH,001,1,LEVEL,MEMORY_START
Explanation	<ul style="list-style-type: none"> <li>The p7 setting is only valid when p6 is FLAG. For the action types, see section 1.3.</li> <li>Specify measurement channels on 001 to 060 of p3.</li> <li>If the /M1 MATH function option is not included, MATH channels (A001 to A300) cannot be set (including queries). However, if the pulse input module is installed, MATH channels (A001 to A060) can be set (including queries).</li> </ul>

**When Action Occurs on Relay Operation**

Setting	SLp1,p2,p3,p4,p5,p6<terminator> p1 Box number (01 to 30) p2 Event type (RELAY) p3 Relay numbers (001 to 060) p4 Event detection method EDGE Edge start LEVEL Level start p5 Action types p6 Flag numbers (F01 to F60)
Query	SL[p1]?
Example	Set box number 5 to an action of activation of trigger 1 upon change in status of relay 1. SL06,RELAY,001,EDGE,TRIGGER1
Explanation	<ul style="list-style-type: none"> <li>The p6 setting is only valid when p5 is FLAG. For the action types, see section 1.3.</li> <li>Specify relay number on p3.</li> </ul>

**When Action Occurs on Timer**

Setting	SLp1,p2,p3,p4,p5,p6<terminator> p1 Box number (01 to 30) p2 Event type (TIMER) p3 Timer number (1 to 6) p4 Event detection method EDGE Edge start LEVEL Level start p5 Action types p6 Flag numbers (F01 to F60)
Query	SL[p1]?
Example	Set box number 6 to an action in which computation starts every time specified for timer 1. SL06,TIMER,1,EDGE,MATH_START
Explanation	The p6 setting is only valid when p5 is FLAG. For the action types, see section 1.3.

**When Action Occurs on Match Time**

Setting	SLp1,p2,p3,p4,p5,p6<terminator> p1 Box number (01 to 30) p2 Event type (MATCH_TIME) p3 Match time number (1 to 3) p4 Event detection method EDGE Edge start LEVEL Level start p5 Action types p6 Flag numbers (F01 to F60)
Query	SL[p1]?
Example	Set box number 7 to an action in which recording starts at the time specified for match time 1. SL07,MATCH_TIME,1,EDGE,MEMORY_START
Explanation	The p6 setting is only valid when p5 is FLAG. For the action types, see section 1.3.

## 1.4 Setting Commands (System Related)

### When Action Occurs on USER Key

Setting SLp1,p2,p3,p4,p5,p6<terminator>

p1 Box number (01 to 30)

p2 Event type (USER\_KEY)

p3 Key number (1, 2)

p4 Event detection method

EDGE Edge start

LEVEL Level start

p5 Action types

p6 Flag numbers (F01 to F60)

Query SI[p1]?

Example Set box number 8 to an action in which the specified file is saved upon pressing of USER key 1.

SL08,USER\_KEY,1,EDGE,FILE\_SAVE

Explanation The p6 setting is only valid when p5 is FLAG. For the action types, see section 1.3.

### SI Timer Settings

Setting When p2=OFF

SIp1,p2<terminator>

When p2=RELATIVE

SIp1,p2,p3,p4<terminator>

When p2=ABSOLUTE

SIp1,p2,p3,p4<terminator>

#### When Not Using the Timer

Setting SIp1,p2<terminator>

p1 Timer number (1 to 6)

p2 Timer type (OFF)

Query SI[p1]?

Example Set timer number 1 to OFF.

SI1,OFF

#### When Using the Relative Timer

Setting SIp1,p2,p3,p4<terminator>

p1 Timer number (1 to 6)

p2 Timer type (RELATIVE)

p3 Time interval-days (0 to 31)

p4 Time interval-time (HH:MM)

HH hours (00 to 23)

MM Minute (00 to 59)

(However, when p3 is 0, 00:00 cannot be set.)

Query SI[p1]?

Example Set a relative time of 3 hours and 30 minutes on timer number 1.

SI1,RELATIVE,0,03:30

#### When Using the Absolute Timer

Setting SIp1,p2,p3,p4<terminator>

p1 Timer number (1 to 6)

p2 Timer type (ABSOLUTE)

p3 Time interval

1M/2M/3M/4M/5M/6M/10M/12M/15M/20M/30M

(minutes)

1H/2H/3H/4H/6H/8H/12H/24H (hours)

p4 Reference time (HH:MM)

HH hours (00 to 23)

MM Minute (00 to 59)

Query SI[p1]?

Example Set a time interval of 30 minutes and a reference time of 17 hours and 15 minutes on timer number 1.

SI1,ABSOLUTE,30M,17:15

### SQ Match Time Settings

Setting When p2=OFF

SQp1,p2<terminator>

When p2=MONTH

SQp1,p2,p3,p4<terminator>

When p2=WEEK

SQp1,p2,p3,p4<terminator>

When p2=DAY

SQp1,p2,p3<terminator>

#### When Not Using the Match Time

Setting SQp1,p2<terminator>

p1 Match time number (1 to 3)

p2 Start type (OFF)

Query SQ[p1]?

Example Set match timer number 1 to OFF.

SQ1,OFF

#### When Starting Match Time in Units of Months

Setting SQp1,p2,p3,p4<terminator>

p1 Match time number (1 to 3)

p2 Start type (MONTH)

p3 Start date/time-day (1 to 31)

p4 Start date/time-time (HH:MM)

HH hours (00 to 23)

MM Minute (00 to 59)

Query SQ[p1]?

Example Set match time number 1 to 1 day, 8 hours 30 minutes.

SQ1,MONTH,1,08:30

#### When Starting Match Time in Units of Weeks

Setting SQp1,p2,p3,p4<terminator>

p1 Match time number (1 to 3)

p2 Start type (WEEK)

p3 Start Date/time-day of week

SUN Sunday

MON Monday

TUE Tuesday

WED Wednesday

THU Thursday

FRI Friday

SAT Saturday

p4 Start date/time-time (HH:MM)

HH hours (00 to 23)

MM Minute (00 to 59)

Query SQ[p1]?

Example Set match time number 1 to Friday, 17 hours 30 minutes.

SQ1,WEEK,FRI,17:30

## 1.4 Setting Commands (System Related)

### When Starting Match Time in Units of One Day

**Setting**    SQp1,p2,p3<terminator>  
               p1 Match time number (1 to 3)  
               p2 Start type (DAY)  
               p3 Start date/time-time (HH:MM)  
                   HH    hours (00 to 23)  
                   MM    Minute (00 to 59)

**Query**        SQ[p1]?

**Example**      Set match time number 1 to 17 hours 30 minutes.  
 SQ1,DAY,17:30

### XV Measurement Interval Settings

**Setting**        XVp1,p2<terminator>  
               p1 Measurement group number (1 to 3)  
               p2 Measurement interval  
                   OFF  
                   10mS/50mS/100mS/200mS/500mS  
                   (miliseconds)  
                   1S/2S/5S/10S/20S/30S/60S (seconds)

**Query**        XV[p1]?

**Example**      Set measurement group number 1 to a measurement interval of 1 second.  
 XV1,1S

### XI Measurement Groups and A/D Integration Time Settings

**Setting**        XIp1,p2,p3<terminator>  
               p1 Module number (0 to 5)  
               p2 Measurement group number (OFF, 1 to 3)  
               p3 A/D integration time  
                   (AUTO, 50 Hz, 60 Hz)

**Query**        XI[p1]?

**Example**      Set module number 0 to measurement group 1 and A/D integration time to automatic detection.  
 XI0,1,AUTO

**Explanation**

- If the module specified in p1 has a shortest measurement interval of 100 ms, you cannot set measurement group numbers having measurement intervals of 10 ms or 50 ms. Also, if the module has a shortest measurement interval of 500 ms, you cannot set measurement group numbers having measurement intervals of 10 ms, 50 ms, or 100 ms.
- Measurement group numbers cannot be specified for output modules and unmounted modules.
- For the 30-CH Medium Speed DCV/TC/DI Input Module, enter the same settings for the three measurement groups and A/D integral times.

### VM MATH Interval Settings

**Setting**        VMp1<terminator>  
               p1 Measurement group number  
                   (OFF, 1 to 3)

**Query**        VM?

**Example**      Set MATH interval to measurement group number 1.  
 VM1

**Explanation**

- You can set this command on products with the /M1 MATH function option, and when the pulse input module is installed.
- Measurement group numbers of measurement interval 10 ms or 50 ms cannot be set.

### XG Settings of Operation upon MATH Error

**Setting**        XGp1,p2,p3,p4,p5,p6,p7<terminator>  
               p1 Operation upon Math Error  
                   +OVER    Set computed value to +Over  
                   -OVER    Set computed value to -Over  
               p2 Special MATH processing when the input value of the measurement input channel is in error in a computation other than TLOG and CLOG.  
                   ERROR    Sets the computed value to MATH error.  
                   SKIP     Continue the computation using the previous value for channels with an error in the input value.  
               p3 Special MATH processing when the input value of the measurement input channel is overflow in a computation other than TLOG and CLOG.  
                   ERROR    Compute using the overflow value  
                   SKIP     Continue the computation using the previous value for channels with an overflow value  
                   LIMIT\*1 Continue the computation by replacing the overflow value with upper or lower limit value

\*1 The upper or lower limit value that is replaced for the measurement input channel varies depending on the MATH type.

Measurement input channel	Upper/lower limit of the measuring range
Scaled measurement input channel	Upper/lower limit of scaling

## 1.4 Setting Commands (System Related)

p4	Sum scale of the TLOG.SUM computation						
OFF	Sum value of the data for each measurement interval						
SEC	Sum value of the data for each measurement interval/number of computations per second						
MIN	Sum value of the data for each measurement interval/number of computations per minute						
HOUR	Sum value of the data for each measurement interval/number of computations per hour						
p5	Special MATH processing when the input value of the measurement input channel is in error in a TLOG or CLOG computation <sup>*2</sup>						
ERROR	Sets the computed value to MATH error.						
SKIP	Continue the computation using the previous value ignoring the input value in error						
p6	Special MATH processing when the input value of the measurement input channel is overflow in a TLOG or CLOG computation <sup>*2</sup>						
ERROR	Sets the computed value to MATH error.						
SKIP	Computed value is ignored and computation continues						
LIMIT <sup>*3</sup>	Apply input to upper or lower limit value and continue computation						
*2 For details, see the MW100 Data Acquisition Unit User's Manual (IM MW100-01E).							
*3 The upper or lower limit value that is replaced for the reference channel varies depending on the MATH type.							
	<table border="1"> <tr> <td>Measurement input channel</td> <td>Upper/lower limit of the measuring range</td> </tr> <tr> <td>Scaled measurement input channel</td> <td>Upper/lower limit of scaling</td> </tr> <tr> <td>MATH channel</td> <td>Upper/lower limit of span</td> </tr> </table>	Measurement input channel	Upper/lower limit of the measuring range	Scaled measurement input channel	Upper/lower limit of scaling	MATH channel	Upper/lower limit of span
Measurement input channel	Upper/lower limit of the measuring range						
Scaled measurement input channel	Upper/lower limit of scaling						
MATH channel	Upper/lower limit of span						
p7	Overflow processing of TLOG.PSUM computation						
OVER	Stop the computation as overflow when 99999999 is exceeded						
ROTATE	Continue the computation by resetting the count to 0 when 99999999 is exceeded						
Query	XG?						

**Example** Set operation upon MATH error to +OVER, operation upon abnormality in computation other than CLOG/TLOG to SKIP, overflow operation for other than CLOG/TLOG to SKIP, time scaling for TLOG.SUM computation to units of minutes, operation upon abnormal input from CLOG/TLOG computation to ERROR, operation upon CLOG/TLOG computation overflow to LIMIT, and operation upon TLOG.PSUM computation over to OVER.

XG+OVER, SKIP, SKIP, MIN, ERROR, LIMIT, OVER

**Explanation** You can set this command on products with the /M1 MATH function option, and when the pulse input module is installed.

## MC File Message Settings

**Setting** MCp1,p2<terminator>

p1 File message type

MESSAGE For recording

MESSAGE\_T For thinning recording

p2 Message string (up to 120 characters)

**Query** MC?

**Explanation**

- This command sets a common message to all files in the recording interval (between record start to record stop).
- There are two message types: recording and thinning recording. The recorded message is common to measurement groups 1 to 3 and MATH and does not depend on the record start timing.
- For the characters that can be used for the messages, see "User Specified Strings" in section 1.3.
- You cannot change the settings while recording.

## MD Data Save Folder Settings

**Setting** MDp1,p2,p3<terminator>

p1 Type

AUTO Auto generation

PARTIAL Partial setting

FREE Arbitrary string

DATE Date and time

p2 Folder name (1 to 8 characters)

p3 Start number (0 TO 9999)

**Query** MD?

**Example** Create the folder automatically.

MDAUTO

Set the folder name to XXX100.

MDPARTIAL,XXX,100

Set the folder name to ZZZZZZ.

MDFREE,ZZZZZZ

Set the folder name to the date/time when the recording is started.

MDDATE



## 1.4 Setting Commands (System Related)

Explanation • Folder type and format

Type	Naming convention	Format	Handling of duplicate folder names
AUTO	DATAAnnn	DATA: Fixed nnnn: Sequence number 0000 to 9999, automatic update	Available Sequence number updating
PARTIAL	xxxxnnnn	xxxx: Any 1 to 4 alphanumeric characters nnnn: Sequence number 0000 to 9999, automatic update	None
FREE	xxxxxxx	xxxxxxx: Any 1 to 8 alphanumeric characters	None
DATE	mddhhmmn	mddhhmm: Month, day, hour, minute m: 1 to 9, X (October), Y (November), Z (December) dd: 01 to 31 hh: 00 to 23 mm: 00 to 59 n: Sequence number (0 to 9, A to Z)	Available Sequence number updating

- The sequence number is managed by setting type. You can set the starting sequence number for the PARTIAL setting. You cannot set the starting sequence number of AUTO and DATE settings.
- The folder name cannot be blank (only spaces). Enter at least one character.
- If the number of characters of the folder name is 1 to 3 for the PARTIAL setting, the sequence number is moved forward immediately after the folder name. If the folder name is more than 4 characters, characters after the 4th character are ignored. If the folder name is set to DATA, consistency with the auto setting is not maintained.
- In the FREE setting, the data is saved to the same folder until the folder name is changed. The recording log and alarm summary files are overwritten when recorded to the same name. When the recording stop action is set to Rotate, previous old files are deleted.
- Commands can be sent or received with p2 and p3 attached regardless of the type (p1).
- For the character strings that can be used for the folder name, see "File and Folder Name Strings" in section 1.3.

## MH Recording Channel Settings

Setting

MHp1,p2,p3,p4<terminator>  
p1 Channel range (001 to 060 and A001 to A300)  
p2 Recording OFF/ON  
p3 Thinning recording OFF/ON  
p4 Manual sample recording OFF/ON

Query

MH[p1]?

Example

Set recording on channel 1 OFF, thinning recording ON, and manual sample recording ON.  
MH001,OFF,ON,ON

Explanation • Specify measurement channels on 001 to 060 of p1.

- If the /M1 MATH function option is not included, MATH channels (A001 to A300) cannot be set (including queries). However, if the pulse input module is installed, MATH channels (A001 to A060) can be set (including queries).

## MW Recording Operation Settings

Setting

When p2=OFF  
MWp1,p2<terminator>  
When p2=ON and p3=DIRECT  
MWp1,p2,p3,p4,p5<terminator>  
When p2=ON and p3=TRIGGER  
MWp1,p2,p3,p4,p5,p6,p7<terminator>  
p1 Measurement group number (1 to 3)  
p2 Recording OFF/ON  
p3 Record start timing  
DIRECT Record starts on record start  
TRIGGER Record starts on trigger activation  
p4 Recording stop action  
SINGLE Recording stops after creating one file  
FULLSTOP Recording stops when file is full  
ROTATE Continue recording by deleting the old data  
p5 Recording interval [measurement/times] (1, 2, 4, 5, 10)  
p6 Recording data length  
10M/20M/30M (units of minutes)  
1H/2H/3H/4H/6H/8H/12H (units of hours)  
1D/2D/3D/5D/7D/10D (units of days)  
p7 Pretrigger length[%] (0/10/20/30/40/50/60/70/80/90/100)

Query

MW[p1]?

Example

Turn recording of measurement group 1 ON, set the record start timing to DIRECT, set the recording stop action to SINGLE, and set the recording interval to 2.  
MW1,ON,DIRECT,SINGLE,2

Explanation • Set p5 (recording interval) to an integer multiple of the measurement interval.

- The recording interval can be set to 1, 2, 4, or 10 if the measurement interval is 50 mS, 500 mS, or 5 S. The recording interval can be set to 1, 5, or 10 if the measurement interval is 200 mS. The recording interval can be set to 1, 2, 5, or 10 for all other measurement intervals.

## 1.4 Setting Commands (System Related)

### ML Recording Data Length Settings

**Setting** MLp1<terminator>  
 p1 Data length when the recording start timing is set to DIRECT under recording operation  
 30 M (units of minutes)  
 1H/2H/3H/4H/6H/8H/12H (units of hours)  
 1D/2D/3D/5D/7D/10D/14D/31D (units of days)

**Query** ML?

**Example** Set the recording start time data length to 1 hour.  
 ML1H

### MR Recording Free Space Settings

**Setting** MRp1<terminator>  
 p1 Recording time remaining on media set for small media free space  
 1H/2H/3H/4H/5H (units of hours)

**Query** MR?

**Example** Set media free space to 2 hours.  
 MR2H

### MX Thinning Recording Operation Settings

**Setting** When p1=OFF  
 MXp1<terminator>  
 When p1 is not OFF  
 MXp1,p2,p3<terminator>  
 p1 Recording interval:  
 OFF (do not record)  
 4S/5S/10S/20S/30S (units of seconds)  
 1M/2M/3M/4M/5M/10M/20M/30M (units of minutes)  
 1H (units of hours)

p2 Recording stop action  
 SINGLE Recording stops after creating one file  
 FULLSTOP Recording stops when file is full  
 ROTATE Continue recording by deleting the old data

p3 Recording data length  
 30 M (units of minutes)  
 1H/2H/3H/4H/6H/8H/12H (units of hours)  
 1D/2D/3D/5D/7D/10D/14D/31D (units of days)

**Query** MX?

**Example** Set recording interval to 1H, recording operation to FULLSTOP, and recording data length to 2D.  
 MX1H, FULLSTOP, 2D

**Explanation**

- p3 cannot be set to a time less than the p1 interval.
- The relationship between the measurement and MATH intervals set on the input module and the allowed thinning recording interval setting is shown in the table below.

Thinning Recording Interval	Measurement Interval (Measurement Group/MATH Interval)						
	10ms, 50ms, 100ms 200ms, 500ms, 1s	2s	5s	10s	20s	30s	60s
4S	✓	✓					
5S	✓		✓				
10S	✓	✓	✓	✓			
20S	✓	✓	✓	✓	✓		
30S	✓	✓	✓	✓		✓	
1M	✓	✓	✓	✓	✓	✓	✓
2M	✓	✓	✓	✓	✓	✓	✓
3M	✓	✓	✓	✓	✓	✓	✓
4M	✓	✓	✓	✓	✓	✓	✓
5M	✓	✓	✓	✓	✓	✓	✓
10M	✓	✓	✓	✓	✓	✓	✓
20M	✓	✓	✓	✓	✓	✓	✓
30M	✓	✓	✓	✓	✓	✓	✓
1H	✓	✓	✓	✓	✓	✓	✓

✓: Can be set, Blank: Cannot be set

### MU Setting Save Operation Settings

**Setting** MUp1,p2,p3,p4<terminator>  
 p1 Saving of channel related settings  
 OFF/ON  
 p2 Saving of recording related settings  
 OFF/ON  
 p3 Saving of communication related settings  
 OFF/ON  
 p4 Saving of other settings  
 OFF/ON

**Query** MU?

**Example** Set so that all settings are saved.  
 MHON, ON, ON, ON

### XK Key Lock Settings

**Setting** XKp1<terminator>  
 p1 Key lock OFF/ON

**Query** XK?

**Example** Key lock settings.  
 XKON

**Explanation** The setting is valid in Setting mode or Measurement mode.

### XT Temperature Unit Settings

**Setting** XTp1<terminator>  
 p1 Units of temperature  
 DEG\_C Temperature calculated in °C  
 DEG\_F Temperature calculated in °F

**Query** XT?

**Example** Temperature units set in °F  
 XTDEG\_F

**Explanation** When the temperature units are changed, the settings of the SR, SF, XB, XJ, XD, AO, AP, and ST commands are initialized.

## 1.4 Setting Commands (System Related)

**SW Daylight Saving Time Settings**

Setting	SWp1,p2,p3,p4,p5<terminator>
p1	Starts/stops date/time type
	START Start date/time
	END Exit date/time
p2	Date/time-month
	JAN January
	FEB February
	MAR March
	APR April
	MAY May
	JUN June
	JUL July
	AUG August
	SEP September
	OCT October
	NOV November
	DEC December
p3	Date/time-week
	1st First week
	2nd Second week
	3rd Third week
	4th Fourth week
	LAST Final week
p4	Date/time-day of week
	SUN Sunday
	MON Monday
	TUE Tuesday
	WED Wednesday
	THU Thursday
	FRI Friday
	SAT Saturday
p5	Date/time-hour (0 to 23)
Query	SW[p1]?
Example	Star Daylight Saving time on April, first week, Sunday, 2 hours. SWSTART,APR,1st,SUN,2

**SS Daylight Saving Time Operation Settings**

Setting	SSp1<terminator>
p1	Summer time operation valid/invalid ON/OFF
Query	SS?
Example	Enables Daylight Saving time. SSON

**BA Settings of Strain Input Initial Balancing**

Setting	BAp1,p2<terminator>
p1	Channel range (001 to 060)
p2	Initial balancing valid/invalid (ON/OFF)
Query	BA[p1]?
Example	Enable strain input initial balance operation on channel 1. BA001,ON
Explanation	Specify measurement channels on p1.

**UN Unit Number Settings**

Setting	UNp1<terminator>
p1	Unit number (00 to 89)
Query	UN?
Example	Set unit number to 5. UN05

**SV Rolling Average Settings**

Setting	When p2=OFF SVp1,p2<terminator>
p1	MATH channel number (A001 to A060)
p2	Rolling average ON/OFF (OFF)
	When p2=ON SVp1,p2,p3,p4<terminator>
p1	MATH channel number (A001 to A060)
p2	Rolling average ON/OFF (ON)
p3	Sampling interval (1 to 6S, 10S, 12S, 15S, 20S, 30S, 1M to 6M, 10M, 12M, 15M, 20M, 30M, or 1H)
	_S: Interval setting in unit of seconds
	_M: Interval setting in unit of minutes
	_H: Interval setting in unit of hours
p4	Number of samples (1 to 1500)
Query	SV[p1]?
Example	Set the sampling interval to 1 minute and the number of samples to 360 on MATH channel A001. SVA001,ON,1M,360
Explanation	<ul style="list-style-type: none"> <li>This command can be used on models with the /M1 math option.</li> <li>Set the sampling interval to an integer multiple of the MATH interval.</li> </ul>

## 1.5 Setting Commands (Display Related)

### ST Tag Settings

**Setting** STp1,p2<terminator>  
 p1 Channel range (001 to 060 and A001 to A300)  
 p2 Tags (max 15 characters)

**Query** ST[p1]?

**Example** Set the tag of channel 2 to TAG2.  
 ST002,TAG2

**Explanation**

- For the characters that can be used for tags, see user specified characters in section 1.3.
- If the /M1 MATH function option is not included, MATH channels (A001 to A300) cannot be set (including queries). However, if the pulse input module is installed, MATH channels (A001 to A060) can be set (including queries).

### SZ Zone Settings

**Setting** SZp1,p2,p3<terminator>  
 p1 Channel range (001 to 060 and A001 to A300)  
 p2 Zone lower limit value (0 to 95) [%]  
 p3 Zone upper limit value (5 to 100) [%]

**Query** SZ[p1]?

**Example** Zone display channel 2 between 30 and 50%  
 SZ002,30,50

**Explanation**

- If the /M1 MATH function option is not included, MATH channels (A001 to A300) cannot be set (including queries). However, if the pulse input module is installed, MATH channels (A001 to A060) can be set (including queries).
- Set total display width of amplitude direction of waveform display area to 100%.
- A Zone width of less than 5% cannot be set.
- Set the upper and lower zone parameters so that the upper is greater than the lower.

### SC Display Color Settings

**Setting** SCp1,p2<terminator>  
 p1 Channel range (001 to 060 and A001 to A300)  
 p2 Display color (rrr.ggg.bbb)  
 rrr RGB R value (0 to 255)  
 ggg RGB G value (0 to 255)  
 bbb RGB B value (0 to 255)

**Query** SC[p1]?

**Example** Set display color of channel 2 to Yellow.  
 SC002,255.255.0

**Explanation** If the /M1 MATH function option is not included, MATH channels (A001 to A300) cannot be set (including queries). However, if the pulse input module is installed, MATH channels (A001 to A060) can be set (including queries).

### SB Display Scale Settings

**Setting** SBp1,p2,p3,p4<terminator>  
 p1 Channel range (001 to 060 and A001 to A300)  
 p2 Scale type  
 LINEAR Linear display  
 LOG Logarithmic display  
 p3 Number of scale divisions (1 to 12, AUTO)  
 p4 Bar graph display reference position (NORMAL, CENTER)

**Query** SB[p1]?

**Example** Set the display scale type on channel 2 to LINEAR, the number of scale divisions to 5, and the reference position of the bar graph display to NORMAL.  
 SB002,LINEAR,5,NORMAL

**Explanation**

- If the /M1 MATH function option is not included, MATH channels (A001 to A300) cannot be set (including queries). However, if the pulse input module is installed, MATH channels (A001 to A060) can be set (including queries).
- If AUTO is specified for p3, the number of divisions is automatically determined from the upper and lower limit (If scaling is turned ON in the range settings, it is determined from the upper and lower limit of scaling).
- If CENTER is set for p4, the center of the bar graph is drawn in the reference point.

## 1.5 Setting Commands (Display Related)

**SX Display Group Settings**

Setting	SXp1,p2,p3<terminator> p1 Display group number (01 to 18) p2 Display group name (up to 16 characters) p3 Channel structure (up to 100 characters, up to 20 channels)
Query	SX[p1]?
Example	Channel 1 and channels 3 to 6 are given a group name of GROUP1 and set to group 1. SX1,GROUP1,001.003-006  Set the channel structure by delimiting individual channels with a period (.), and specifying ranges of channels with a hyphen (-).
Explanation	<ul style="list-style-type: none"> <li>For the characters that can be used for group names, see user specified characters in section 1.3.</li> <li>See section 1.3 for the channel structure.</li> </ul>

**TL Trip Line Settings**

Setting	When p3=OFF TLp1,p2,p3<terminator>  When p3=ON TLp1,p2,p3,p4,p5<terminator> p1 Display group number (01 to 18) p2 Trip line number (1 to 4) p3 Trip line display ON/OFF p4 Display color (rrr.ggg.bbb) rrr RGB R value (0 to 255) ggg RGB G value (0 to 255) bbb RGB B value (0 to 255) p5 Display position (0 to 100) [%]
Query	TL[p1[,p2]]?
Example	Display trip line 1 in group one in red at 10% position. Set the top of the graph to 100% and the bottom to 0%. TL1,1,ON,255.0.0,10

**XR Channel and Tag Display Switching**

Setting	XRp1<terminator> p1 Display type CHANNEL Channel number display TAG Tag display
Query	XR?
Example	Set tag display. XR TAG

**SG Message Settings**

Setting	SGp1,p2<terminator> p1 Message number (0 to 5) p2 Message string (up to 15 characters)
Query	SG[p1]?
Example	Set the MESSAGE1 string to message number 1. SG1,MESSAGE1
Explanation	<ul style="list-style-type: none"> <li>For the characters that can be used for messages, see user specified characters in section 1.3.</li> <li>The message number 0 setting is valid in Setting mode and Measurement mode.</li> </ul>

## 1.6 Setting Commands (Communication Related)

### UA User Settings

**Setting** When p2=OFF  
 UA p1,p2<terminator>  
 When p2 is not OFF  
 UA p1,p2,p3,p4<terminator>  
 p1 User number (01 to 10)  
 p2 User level  
     OFF Do not use  
     ADMIN Administrator level  
     USER User level  
 p3 User name (up to 16 characters)  
 p4 Password (up to 8 characters)

**Query** UA[p1]?

**Example** Set User number 01 to an account with user name YOKOGAWA at the administrator level. Set the password to 1234.  
 UA01,ADMIN,YOKOGAWA,1234

**Explanation**

- For the characters that can be used for user names, see user specified characters in section 1.3.
- For the characters that can be used for passwords, see password strings in section 1.3.
- The password is output encrypted during a query.

### YS Serial Communication Settings

**Setting** When p1=NORMAL  
 YSp1,p2,p3,p4,p5,p6,p7<terminator>  
 When p1=MODBUS\_M or p1=MODBUS\_S  
 YSp1,p2,p3,p4,p5<terminator>

#### When Using as a General Purpose Communication Server

**Setting** YSp1,p2,p3,p4,p5,p6,p7<terminator>  
 p1 Function (NORMAL)  
 p2 Address (01 to 32)  
 p3 Baud rate [bps]  
     (1200/2400/4800/9600/19200/  
     38400/57600/115200)  
 p4 Parity  
     NONE No parity  
     EVEN Even  
     ODD Odd  
 p5 Stop bit [bit] (1, 2)  
 p6 Data length [bit] (7, 8)  
 p7 Handshaking  
     (OFF:OFF,XON:XON,XON:RS,CS:RS)

**Example** Set the address to 01, baud rate to 9600 bps, parity to even, stop bit to 1, data length to 8 bits, and handshaking to XON:RS.  
 YSNORMAL,01,9600,EVEN,8,1,XON:RS

#### When using as a Modbus master or Modbus slave

**Setting** YSp1,p2,p3,p4,p5<terminator>  
 p1 Function  
     MODBUS\_M Modbus master  
     MODBUS\_S Modbus slave  
 p2 Address (1 to 247)  
 p3 Baud rate [bps]  
     (1200/2400/4800/9600/19200/  
     38400/57600/115200)  
 p4 Parity  
     NONE No parity  
     EVEN Even  
     ODD Odd  
 p5 Stop bit [bit] (1, 2)

**Example** Set Address1 to the Modbus master, the baud rate to 9600 bps, parity to even, and stop bit to 1.

YSMODBUS\_M,1,9600,EVEN,1

**Explanation** MODBUS\_M of p1 can be set with the /M1 MATH function option.

### YA IP Address Settings

**Setting** YAp1,p2,p3<terminator>  
 p1 IP address  
     (0.0.0.0 to 255.255.255.255)  
 p2 Subnet Mask  
     (0.0.0.0 to 255.255.255.255)  
 p3 Default Gateway  
     (0.0.0.0 to 255.255.255.255)

**Query** YA?

**Example** Set the IP address to 192.168.111.24, the subnet mask to 255.255.255.0, and the default gateway to 0.0.0.0.  
 YA192.168.111.24,255.255.255.0,0.0.0.0

**Explanation** The settings updated with this command are enabled when the MW100's power is turned OFF, then turned back ON again.

### YD Host Name and Domain Name Settings

**Setting** YDp1,p2<terminator>  
 p1 Host name (up to 63 characters)  
 p2 Domain name (up to 63 characters)

**Query** YD?

**Example** Sets the host name "some\_host" and domain name "abc.com"  
 YDsome\_host,abc.com

**Explanation** For the characters that can be used for the host and domain names, see host and domain name strings in section 1.3.

## 1.6 Setting Commands (Communication Related)

**YN DNS Client Settings**

Setting	YNp1,p2,p3,p4<terminator>
	p1 DNS server primary (0.0.0.0 to 255.255.255.255)
	p2 DNS server secondary (0.0.0.0 to 255.255.255.255)
	p3 Domain suffix-primary (up to 63 characters)
	p4 Domain suffix-secondary (up to 63 characters)
Query	YN?
Example	Set the primary and secondary DNS server. YN192.168.0.1,192.168.0.2
Explanation	For the characters that can be used for domain suffixes, see host and domain name strings in section 1.3.

**YH DHCP Client Settings**

Setting	YHp1,p2<terminator>
	p1 Getting DNS information OFF/ON
	p2 Host name registration OFF/ON
Query	YH?
Example	Get DNS server information and turn ON host name registration. YHON,ON
Explanation	The settings updated with this command are enabled when the MW100's power is turned OFF, then turned back ON again.

**YF FTP Client Settings**

Setting	YFp1,p2,p3,p4,p5,p6,p7<terminator>
	p1 Connection type 1 Primary server 2 Secondary server
	p2 FTP server (up to 64 characters)
	p3 Port number (1 to 65535)
	p4 User name (up to 32 characters)
	p5 Password (up to 32 characters)
	p6 Directory (up to 32 characters)
	p7 Use passive mode (OFF/ON)
Query	YF[p1]?
Example	Transfer file to primary server. YF1,192.168.1.1,21,YOKOGAWA,1234,MW_DATA, OFF
Explanation	<ul style="list-style-type: none"> <li>For the characters that can be used for the FTP server, see host and domain name strings in section 1.3.</li> <li>For the characters that can be used for user names and directories, see user specified characters in section 1.3.</li> <li>For the characters that can be used for passwords, see password strings in section 1.3.</li> <li>The password is output encrypted during a query.</li> </ul>

**YG FTP Client Operation Settings**

Setting	YGp1<terminator>
	p1 Transfer time shift (0 to 120)[min]
Query	YG?
Example	Set to 3 minutes YG3

**YM Mail Client Settings**

Setting	When p5=OFF YMp1,p2,p3,p4,p5<terminator>
	When p5=POP3 YMp1,p2,p3,p4,p5,p6,p7<terminator>
	p1 SMTP server name (up to 64 characters)
	p2 SMTP port number (1 to 65535)
	p3 POP3 server name (up to 64 characters)
	p4 POP3 port number (1-65535)
	p5 Use POP before SMTP (OFF/POP3)
	p6 User name (up to 32 characters)
	p7 Password (up to 32 characters)
Query	YM?
Example	Enable POP3 before SMTP in the mail client settings. YMsmtplibserver.abc.com,25, pop3libserver.abc.com,110,POP3, YOKOGAWA,1234
Explanation	<ul style="list-style-type: none"> <li>For the characters that can be used for the SMTP server and POP3 server, see host and domain name strings in section 1.3.</li> <li>For the characters that can be used for passwords, see password strings in section 1.3.</li> <li>The password is output encrypted during a query.</li> </ul>

**YV Mail Sender and Recipient Settings**

Setting	YVp1,p2,p3,p4<terminator>
	p1 Characters added to [Subject] (up to 32 characters)
	p2 Recipient address 1 (up to 150 characters)
	p3 Recipient address 2 (up to 150 characters)
	p4 Sender address (up to 64 characters)
Query	YV?
Example	Set a mail recipient 1 and 2, and the sender. YVALARM,kofu@abc.com, mitaka@abc.com,tokyo@abc.com
Explanation	For the characters that can be used for the subject, recipients, and sender, see user specified characters in section 1.3.

## 1.6 Setting Commands (Communication Related)

### **YU Mail Contents Settings**

**Setting** When p1=TIME  
 YUp1,p2,p3,p4,p5<terminator>  
 When p1=ALARM  
 YUp1,p2,p3<terminator>  
 When p1 is neither TIME, ALARM, nor REPORT  
 YUp1,p2<terminator>

#### **For other than report notification**

**Setting** YUp1,p2,p3,p4,p5<terminator>  
 p1 Send contents  
 ALARM Alarm notification  
 FILE File creation notification  
 MEDIA Media free space notification  
 POWER Startup notification  
 SYSTEM Setting error notification  
 TIME Periodic report  
 p2 Recipient  
 OFF Do not send  
 1 Send to recipient address 1  
 2 Send to recipient address 2  
 1\_2 Send to recipient addresses 1 and 2  
 p3 Add instantaneous value data ON/OFF  
 p4 Send interval (1/2/3/4/6/8/12/24) [hours]  
 p5 Reference time (HH:MM)  
 HH hours (00 to 23)  
 MM Minute (00 to 59)

**Query** YU?

**Example** Set mail to recipients 1 and 2 daily at 18:00 with an instantaneous value data attachment.  
 YUTIME,1\_2,ON,24,18:00

#### **For report notification**

**Setting** YUp1,p2,p3,p4,p5,p6,p7,p8,p9,p10,p11<terminator>  
 p1 Sent contents  
 REPORT Notification of report results  
 p2 Recipient  
 OFF Do not send  
 1 Send to recipient address 1  
 2 Send to recipient address 2  
 1\_2 Send to recipient addresses 1 and 2  
 p3 Send when creating hourly report (OFF/ON)  
 p4 Send when creating daily report (OFF/ON)  
 p5 Send when creating weekly report (OFF/ON)  
 p6 Send when creating monthly report (OFF/ON)  
 p7 Add maximum value data (OFF/ON)  
 p8 Add minimum value data (OFF/ON)  
 p9 Add average value data (OFF/ON)  
 p10 Add integral value data (OFF/ON)

p11 Add instantaneous value data (OFF/ON)  
 YU?

**Query**

**Example** Add maximum and integral values when daily report is created and send to recipient 1  
 YUREPORT,1,OFF,ON,OFF,OFF,ON,OFF,OFF,ON,OFF

**Explanation** You cannot enter REPORT settings on products without the /M3 report function option.

### **YC E-Mail Alarm Transmission Settings**

**Setting** YCp1<terminator>  
 p1 Channel structure (up to 100 characters)

**Query** YC?

**Example** Set the channels for mail alarm transmission judgement to A001 to A005.  
 YCA001-A005

**Explanation**

- See section 1.3 for the channel structure.
- You can specify measurement and MATH channels (only with the /M1 MATH function option and when the pulse input module is installed).

### **YT Time Synchronization Settings**

**Setting** YTp1,p2,p3,p4<terminator>  
 p1 SNTP server name (up to 64 characters)  
 p2 Port number (1 to 65535)  
 p3 Reference time (HH:MM)  
 HH hours (00 to 23)  
 MM Minute (00 to 59)  
 p4 Query interval (3H/12H/24H) [hours]

**Query** YT?

**Example** Set time synchronization for once daily at 5:00.  
 YTsntp\_server.abc.com,123,05:00,24H

### **WD Modbus Client Operation Settings**

**Setting** WUp1,p2,p3<terminator>  
 p1 Communication interval  
 100mS/200mS/250mS/500mS  
 1S/2S/5S/10S/20S/30S/40S/50S/60S/90S/120S  
 p2 Communication recovery wait (0 to 60) [sec]  
 p3 Connection wait (0 to 10, FOREVER) [sec]

**Query** WD?

**Example** Set communication interval to 10 sec., communication recovery wait to 1 sec., and connection hold to 0 sec.  
 WD10S,1,0

**Explanation** You can set this command on products with the /M1 MATH function option.



## 1.6 Setting Commands (Communication Related)

### WE Modbus Client Connection Settings

Setting	WEp1,p2,p3,p4<terminator> p1 Server number (01 to 10) p2 Modbus server name (up to 64 characters) p3 Port number (1 to 65535) p4 Unit number (0 to 255)
Query	WE[p1]?
Example	Set server number 1, Modbus server name to Yokogawa, port number to 502, and unit number 1. WE1,Yokogawa,502,1
Explanation	<ul style="list-style-type: none"> <li>You can set this command on products with the /M1 MATH function option.</li> <li>For the characters that can be used for Modbus server names, see user specified characters in section 1.3.</li> </ul>

### WF Modbus Client Command Settings

Setting	When p2=OFF WFp1,p2<terminator> When p2=ON WFp1,p2,p3,p4,p5,p6,p7,p8<terminator> p1 Command number (001 to 100) p2 Command valid/invalid (ON/OFF) p3 Command types READ Load value from Modbus register of other instrument. WRITE Write value to Modbus register of other instrument p4 Server number (1 to 10) p5 Register address For p3=READ 30001 to 39999 300001 to 365535 40001 to 49999 400001 to 465535 For p3=WRITE 40001 to 49999 400001 to 465535 p6 Data Types INT16 Signed 16-bit integer UINT16 Unsigned 16-bit integer INT32_B Signed 32-bit integer (from upper to lower) INT32_L Signed 32-bit integer (from lower to upper) UINT32_B Unsigned 32-bit integer (from upper to lower. ) UINT32_L Unsigned 32-bit integer (from lower to upper) FLOAT_B 32-bit floating decimal (from upper to lower) FLOAT_L 32-bit floating decimal (from lower to upper)
---------	---

p7 First channel (001 to 060, A001 to A300, C001 to C300)  
p8 Last channel (001 to 060, A001 to A300, C001 to C300)

Query	WF[p1]?
Example	Set command number to 003, command to valid, command type to READ, server number to 1, register address to 30001, data type to INT16, first channel to C001, and last channel to C005. WF003,ON,READ,1,30001,INT16,C001,C005
Explanation	<ul style="list-style-type: none"> <li>You can set this command on products with the /M1 MATH function option.</li> <li>When p3 is READ, p7 and p8 can only be set to C001 to C003.</li> <li>p7 and p8 can only be set to the same type of channel.</li> <li>If the data type is INT16 or UNIT16, the maximum number of channels that can be set from first to last channel is 127. For other data types, the maximum is 63.</li> </ul>

### WA Modbus Master Settings

Setting	WAp1,p2,p3,p4,p5<terminator> p1 Communication interval 100mS/200mS/250mS/500mS 1S/2S/5S/10S/20S/30S/40S/50S/60S/90S/120S p2 Communication timeout 100mS/200mS/250mS/500mS/1S p3 Retry count (OFF/1 to 5) p4 Communication recovery wait (0 to 120) [sec] p5 Wait between commands (OFF/10 mS/20 mS/50 mS/100 mS)
Query	WA?
Example	Set the communication interval to 500 ms, the communication timeout to 250 ms, number of retries to 2, communication recovery wait to 30 seconds, and the gap between commands to 50 ms. WA500mS,250mS,2,30,50mS
Explanation	You can set this command on products with the /M1 MATH function option.

### WB Modbus Master Command Settings

Setting	When p2=OFF WBp1,p2<terminator> When p2=ON WBp1,p2,p3,p4,p5,p6,p7,p8<terminator> p1 Command number (001 to 100) p2 Command valid/invalid (ON/OFF)
---------	--

## 1.6 Setting Commands (Communication Related)

p3	Command types
READ	Load value from Modbus register of other instrument.
WRITE	Write value to Modbus register of other instrument
p4	Slave address (1 to 247)
p5	Register address
	For p3=READ
	30001 to 39999
	300001 to 365535
	40001 to 49999
	400001 to 465535
	For p3=WRITE
	40001 to 49999
	400001 to 465535
p6	Data Types
INT16	Signed 16-bit integer
UINT16	Unsigned 16-bit integer
INT32_B	Signed 32-bit integer (from upper to lower)
INT32_L	Signed 32-bit integer (from lower to upper)
UINT32_B	Unsigned 32-bit integer (from upper to lower. )
UINT32_L	Unsigned 32-bit integer (from lower to upper)
FLOAT_B	32-bit floating decimal (from upper to lower)
FLOAT_L	32-bit floating decimal (from lower to upper)
p7	First channel (001 to 060, A001 to A300, C001 to C300)
p8	Last channel (001 to 060, A001 to A300, C001 to C300)
Query	WB[p1]?
Example	Set command number to 003, command to valid, command type to READ, slave address to 1, register address to 30001, data type to INT16, first channel to C001, and last channel to C005. WB003,ON,READ,1,30001,INT16,C001,C005
Explanation	<ul style="list-style-type: none"> <li>You can set this command on products with the /M1 MATH function option.</li> <li>When p3 is READ, p7 and p8 can only be set to C001 to C300.</li> <li>p7 and p8 can only be set to the same type of channel.</li> <li>If the data type is INT16 or UNIT16, the maximum number of channels that can be set from first to last channel is 127. For other data types, the maximum is 63.</li> </ul>

### UL Validation of Login Function

Setting	ULp1<terminator>
	p1 Login function ON/OFF
Query	UL[p1]?
Example	Enables the login function. ULON

### WC Validation of Client Function

Setting	WCp1,p2<terminator>
	p1 Client type
	DHCP DHCP client
	FTP FTP client
	SMTP SMTP client
	SNTP SNTP client
	MODBUS_M Modbus master
	MODBUS_C Modbus client
	p2 Enable client function (ON/OFF)
Query	WC[p1]?
Example	Enable the FTP client. WCFTP,ON
Explanation	<ul style="list-style-type: none"> <li>The MODBUS_C of p1 can only be set with the /M1 MATH function option.</li> <li>The MODBUS_M of p1 can be set with the serial interface option /C2 or /C3, or with the MATH function option /M1.</li> </ul>

### WS Validation of Server Function

Setting	WSp1,p2,p3<terminator>
	p1 Server type
	MODBUS Modbus server
	FTP FTP server
	HTTP HTTP server
	SNTP SNTP server
	GENE MW100 dedicated protocol server
	DIAG Maintenance/diagnostics server
	p2 Enable server function (ON/OFF)
	p3 Port number (1 to 65535)
Query	WS[p1]?
Example	Enables FTP server on port number 21. WSFTP,ON,21

### YQ Communication Timeout Settings

Setting	YQp1,p2<terminator>
	p1 TCP keep alive (OFF/30 s)
	p2 Timeout time (OFF, 1 to 120) [min]
Query	YQ?
Example	Set TCP keep alive to 30 seconds and communication timeout time to 3 minutes. YQ30S,3

## 1.7 Control Commands

### DS Operation Mode Switching

Setting DSpl<terminator>  
 p1 Mode type  
     0 Measurement Mode  
     1 Setting Mode

Example Sets the mode to Setting mode.  
 DS1

Explanation The operation mode cannot be changed during recording or computation operations.

### EX Computation Start/Stop/Reset/Clear

Setting EXpl<terminator>  
 p1 Operation  
     0 Computation start  
     1 Computation stop  
     2 Reset computation  
     3 Clear computation

Example Starts computation.  
 EX0

Explanation

- You can set this command on products with the /M1 MATH function option, or when the pulse input module is installed.
- Computation cannot be started or stopped during recording.
- You cannot start computation if MATH is not turned ON on at least one MATH channel using SO command.
- Computation cannot be started if the MATH interval is OFF, 10 ms, or 50 ms.

### PS Recording Start/Stop

Setting PSp1<terminator>  
 p1 Recording start/stop  
     0 Start  
     1 Stop

Example Starts recording.  
 PS0

Explanation

- When recording is started, measured data is saved to the CF card.
- If the allowed size of a created measured value file, computed value file, or thinned value file is exceeded due to the combination of the recording channel, recording interval, and recording data length, recording will not be started.
- If the thinning recording interval is shorter than the measurement or MATH interval, recording will not start.

### MV Setting File Save/Write

Setting MVp1,p2<terminator>  
 p1 Operation  
     0 Save settings file  
     1 Load settings file  
 p2 File name (up to 8 characters)

Example Loads settings file "SETFILE1."

MV1,SETFILE1

Explanation

- Specify the file name without the extension.
- For the characters that can be used for file names, see "File Name and Folder Name String" in section 1.3.

### MQ Measured, Computed, and Thinned File Division

Setting MQp1<terminator>  
 p1 Operation  
     SAVE\_M Execute division and saving of measurement / computation file  
     SAVE\_T Execute division and saving of thinned file

Example Divides measurement files.

MQSAVE\_M

Explanation After dividing a file, the next file division is enabled 10 minutes later.

### MS Message Writing

Setting MSpl<terminator>  
 p1 Message Number (0 to 5)

Example Write message number 1.

MS1

### MP Execution of Manual Sample

Setting MPp1<terminator>  
 p1 Operation  
     SAMPLE Perform manual sample  
     DIVIDE Divide manual sample file

Example Perform a manual sample.

MPSAMPLE

Explanation A new manual sample cannot be performed while a manual sample file is being written (approximately 2 seconds).

## 1.7 Control Commands

### **KI** Main Unit Key Operation

**Setting** KIp1<terminator>  
p1 Key type  
START1 START key  
START2 START key (equivalent to holding down for 2 sec)  
STOP1 STOP key  
STOP2 STOP key (equivalent to holding down for 2 sec)  
USER1 USER1 key  
USER2 USER2 key

**Example** Executes the START key.  
KISTART1

### **CE** Error Display Clear

**Setting** CEp1<terminator>  
p1 Clears the error display (0)

**Example** Clears the error on the 7SEG display.  
CE0

### **AK** Alarm Acknowledgment

**Setting** AKp1<terminator>  
p1 Check alarm status, and make notification (0) of output clear command for alarm relay output hold status

**Example** Check alarm status, and make notification of output clear command for alarm relay output hold status.  
AK0

### **IR** Timer Reset

**Setting** IRp1<terminator>  
p1 Number of timer  
0 Reset all timers  
1-6 Reset the specified timer

**Example** Reset all timers.  
IR0

### **CM** Communication Input Data Settings

**Setting** CMp1,p2<terminator>  
p1 Communication input channel range (C001 to C300)  
p2 Communication input value  
+INT (-∞)  
-INF (+∞)  
NAN (Not a Number)  
-9.9999E+29 to -1.0000E-30  
0  
1.0000E-30 to 9.9999E+29

**Query** CM[p1]?

**Example** Set a communication input value of 1.0000E-10 to communication input channel C001.  
CMC001,1.0000E-10

**Explanation** See section 1.3 for the communication input value.

### **VD** Relay ON/OFF

**Setting** VDp1,p2<terminator>  
p1 Relay range (001 to 060)  
p2 Relay status (OFF/ON)

**Example** Turns the channel 1 relay ON.  
VD001,ON

**Explanation** Valid only for the relay whose relay output type is set to manual DO (COM) with the XD command.

### **SD** Date and Time Settings

**Setting** SDp1,p2,p3<terminator>  
p1 Date (YY/MM/DD)  
YY Year (80 to 99, 00 to 35)  
MM Month (01 to 12)  
DD Day (01 to 31)  
p2 Time (HH:MM:SS)  
HH hours (00 to 23)  
MM Minute (00 to 59)  
SS Seconds (00 to 59)  
p3 Timezone (SHH:MM)  
S Symbol (+/-)  
HH hours (00 to 23)  
MM Minute (00 to 59)

**Query** SD?

**Example** Sets the MW100's internal time to April 1, 2005, 13:00:00. The time zone is 9:00.  
SD05/04/01,13:00:00,+09:00

**Explanation** The positive time zone symbol can be omitted.

### **RC** Initialization of Settings

**Setting** RCp1<terminator>  
p1 Initialization level  
0 Initialize all settings except the module recognition  
1 Initialize settings excluding the following items  
· IP address, host name, subnet mask, default gateway  
· Items relating to DHCP  
· Items relating to DNS  
· Items relating to communication timeout  
· Items relating to login function  
· Baud rate, parity bit, stop bit, data length, handshaking, and module recognition information

**Example** Initialize all settings.  
RC0

**Explanation** The communication settings are the parameters set using YS, YA, YD, YN, YH, UA, and YQ.

**RS Reconfiguration**

**Setting** RSpl<terminator>  
 p1 System reconfiguration (0)

**Example** Perform system reconfiguration (re-detect the modules).  
 RS0

**MF Media Preparations**

**Setting** MFpl<terminator>  
 p1 Media initialization (0)

**Example** Initialize external media (CF card).  
 MF0

**BL Execution of Strain Input Initial Balancing**

**Setting** BLpl<terminator>  
 p1 Operation  
     0 Reset initial balance value  
     1 Execute initial balancing

**Example** Executes initial balancing.  
 BL1

**Explanation** Valid only for channels on strain input modules on which initial balancing is enabled (ON) with the BA command.

**PV Transmission Output Control**

**Setting** PVp1,p2<terminator>  
 p1 Channel range (001 to 060)  
 p2 Transmission output OFF/ON  
     OFF No transmission output  
     ON Perform transmission output

**Example** Turn OFF transmission output on channels 1-8.  
 PV001-008,OFF

**Explanation** Valid only for channels whose output method is set to transmission output (TRANS) with the AO command.

**SP User Output Settings**

**Setting** SPp1,p2<terminator>  
 p1 Channel range (001 to 060)  
 p2 User output value (within the output range's upper and lower limits of span)

**Example** Sets the user output value on channel 1 to 3 V.  
 SP001,3000

**Explanation**

- Set the output range using the AO command.
- Valid only for channels whose output method is set to arbitrary output (COM) with the AO command.
- Enter setting parameters for p2 excluding the decimal place.

**EC Execution of Communication**

**Setting** ECpl<terminator>  
 p1 Operation  
     0 Gets the time (queries the time on the SNTP server)

**Example** Get the time.  
 EC0

**Explanation** Valid if the SNTP client function is ON.

**TC Communication Test**

**Setting** TCpl<terminator>  
 p1 Operation  
     FTP\_C FTP client test  
     SMTP SMTP client test  
 p2 Connection (1, 2)

**Example** Execute the FTP client test.  
 TCFTP\_C,1

**Explanation**

- The FTP client test is valid if the FTP client function is ON.
- The SMTP client test is valid if the SMTP client function is ON.

**CC Communication Open/Close**

**Setting** When p1=0  
 CCp1<terminator>  
 When p1=1  
 CCp1,p2,p3<terminator>

**When Closing the Connection**

**Setting** CCp1<terminator>  
 p1 Closes the connection (0)

**Example** Close the connection.  
 CC0

**When Opening the Connection**

**Setting** CCp1,p2,p3<terminator>  
 p1 Opens the connection (1)  
 p2 User name (up to 16 characters)  
 p3 Password (max 8 characters)

**Example** Try to open a connection using user name "ABC" and password "123456."  
 CC1,ABC,123456

**Explanation**

- For the characters that can be used for user names, see user specified characters in section 1.3.
- For the characters that can be used for passwords, see password strings in section 1.3.

## **BO** Byte Output Order Settings

**Setting** BOp1<terminator>  
 p1 Byte output order  
     0 Outputs in order from MSB (most significant byte)  
     1 Outputs in order from LSB (least significant byte)

**Query** BO?  
**Example** Output from the top byte.  
 BO0

**Explanation** This command operates per the byte order of the numerical data during BINARY output.

## **CS** Checksum Settings

**Setting** CSp1<terminator>  
 p1 Checksum ON/OFF  
     0 None (do not calculate sum)  
     1 ON (calculate sum)

**Query** CS?  
**Example** Turn checksum ON.  
 CS1

## **GR** Resetting of the MATH Channels Specified by the MATH Group

**Setting** GRp1<terminator>  
 p1 MATH group number  
     1 to 7 Reset the MATH channels of the specified MATH group

**Example** Reset the MATH channels of MATH group 1.  
 GR1

**Explanation**

- You can set this command on products with the /M1 MATH function option, or when the pulse input module is installed.
- Resets the MATH channels assigned to a MATH group using the MG command.

## 1.8 Output Commands

### **FD** Output of Latest Measured/Computed Data

**Setting** FDp1,p2,p3<terminator>  
 p1 Output data type  
     0 Outputs the latest measured/computed data in ASCII  
     1 Outputs the latest measured/computed data in BINARY  
 p2 First channel (001 to 060 and A001 to A300)  
 p3 Last channel (001 to 060 and A001 to A300)

**Example** Output the most recent measured/computed data from the instrument on channels 1 to 5 in ASCII format.  
 FD0,001,005

**Explanation**

- The "latest measured/computed data," refers to the data most recently received into in the MW100's internal memory.
- If the first channel is 001 and the last channel is A300, the data output is in the range 001 to 060 and A001 to A300.
- Set a first and last channel so that the first is less than or equal to the last.

### **FO** Output of Latest Output Data

**Setting** FOp1,p2,p3<terminator>  
 p1 Output data type  
     0 Outputs the latest output channel data in ASCII  
     1 Outputs the latest output channel data in BINARY  
 p2 First channel (001 to 060)  
 p3 Last channel (001 to 060)

**Example** Output the most recent output data from the instrument on channels 1 to 5 in ASCII format.  
 FO0,001,005

**Explanation** Set a first and last channel so that the first is less than or equal to the last.

**FE** Output of Decimal Place, Units, and Setting Data

Setting	FEp1,p2,p3<terminator>
p1	Output type
0	Outputs the setting command query
1	Outputs the decimal place and units
p2	First channel (001 to 060 and A001 to A300)
p3	Last channel (001 to 060 and A001 to A300)

**Example** Output the decimal place and units of the channels 1 to 5.

FE1,001,005

**Explanation** Set a first and last channel number so that the first is less than or equal to the last.

**FF** Output of Measured/Computed FIFO Data

Setting	When p1=0 FFp1,p2,p3,p4,p5,p6,p7<terminator> When p1=1 FFp1,p2<terminator>
p1	Output type
0	Outputs the FIFO data
1	Outputs the FIFO read range
p2	Measurement groups
1	Data from measurement groups 1
2	Data from measurement groups 2
3	Data from measurement groups 3
p3	First channel (001 to 060 and A001 to A300)
p4	Last channel (001 to 060 and A001 to A300)
p5	Read out start position (-1, 1 to 9999999999)
-1	Latest read position
p6	Read out end position (-1, 1 to 9999999999)
-1	Latest read position
p7	Max. number of read blocks (1 to 9999)

**Example** Output the FIFO read range for measurement group 1.  
FF1,1

- Explanation**
- The oldest FIFO buffer data is overwritten with the newest data in a cyclical manner.
  - The output value of p1=1 (output FIFO read range) is the allowable read range for p1=0 (FIFO data output).
  - Set a first and last channel number so that the first is less than or equal to the last.

**FL** Output of Logs, Alarm Summaries, and Status

Setting	When p1=0 FLp1,p2,p3<terminator> When p1=1 FLp1,p2,p3,p4<terminator>
---------	---

**When Outputting Logs**

Setting	FLp1,p2,p3<terminator>
p1	Output type (0)
0	Log output
p2	Data type
ERROR	Operation error log
RECORD	Recording log
ALARM	Alarm summary
MESSAGE	Message summary
COM	General purpose communication log
FTP_C	FTP client log
SMTP	Mail client log
DHCP	DHCP client log
SNTP	Time synchronization client log
FTP_S	FTP server log
HTTP	HTTP server log
MODBUS_M	Modbus master log
MODBUS_C	Modbus client log
MODBUS_S	Modbus slave log
MODBUS_T	Modbus server log
MATH	Computation status
CMD	Operation log
RECSTATUS	Recording status
p3	Max. number of read blocks
ERROR	1 to 50
RECORD	1 to 1024
ALARM	1 to 256
MESSAGE	1 to 50
COM	1 to 200
FTP_C	1 to 50
SMTP	1 to 50
DHCP	1 to 50
SNTP	1 to 50
FTP_S	1 to 50
HTTP	1 to 50
MODBUS_M	1 to 50
MODBUS_C	1 to 50
MODBUS_S	1 to 50
MODBUS_T	1 to 50
MATH	1
CMD	1 to 256
RECSTATUS	1

**Example** Output 10 blocs of the operation error log.

FLO,ERROR,10

**Explanation** Outputs the log (records) saved to the instrument.

## 1.8 Output Commands

### When Outputting Status

Setting FLp1,p2,p3,p4<terminator>

p1 Output type (1)

1 Outputs status

p2 Data type

MODBUS\_MC Modbus master command status

MODBUS\_MC Modbus master connection status

MODBUS\_CC Modbus client command status

MODBUS\_CS Modbus client connection status

BALANCE Strain input initial balance

p3 First data number

MODBUS\_MC 1 to 100

MODBUS\_MS 1 to 247

MODBUS\_CC 1 to 100

MODBUS\_CS 1 to 10

BALANCE 1 to 60

p4 Last data number

MODBUS\_MC 1 to 100

MODBUS\_MS 1 to 247

MODBUS\_CC 1 to 100

MODBUS\_CS 1 to 10

BALANCE 1 to 60

Example Output the Modbus master connection status of data number 1 to 10.

FL1,MODBUS\_MS,1,10

### IS Output of Status Information

Setting ISp1<terminator>

p1 Outputs status information (0)

Example Output status information.

IS0

### VF Output of Relay Status

Setting VFp1<terminator>

p1 Outputs relay status (0)

Example Output relay status.

VF0

### CF Output of System Recognition Status

Setting CFp1<terminator>

p1 Outputs system recognition status (0)

Example Output the system recognition status

CF0

### ME Output of Media Information

Setting MEp1,p2<terminator>

p1 Output type

0 Outputs media free space

1 Outputs file information

p2 User name (up to 63 characters)

Enter using the full path.

Example

- Output file information.  
ME0
- Output the information of MW100.txt in the DATA0 directory.  
ME1,/DATA0/MW100.txt
- Output root directory information.  
ME1,/



## 2.1 Response Format

For each of the commands in the previous chapter, there are the response types shown in the table below.

The instrument receives a single response (affirmative or negative) for every command delimited with a terminator.

Command Type	Description	Response Type	
		Affirmative Response	Negative Response
Setting commands	A command that sets the operation of the instrument, and whose setting is stored in the setting file	Affirmative Response	Single negative response or Multiple negative response
Control commands	A command that sets the operation of the instrument, but whose setting is not stored in the setting file		
Output commands	Command for outputting data measured and computed on the instrument	ASCII or binary output	
Queries	Command for outputting the current settings of the setting and control commands	ASCII output	
Commands common across instruments	Command for outputting in format determined for Yokogawa recorders	Responses common across instruments	

### Note

In this section, *CRLF* means "carriage return/line feed."

### Affirmative Responses

If a command is successfully executed, an affirmative response is returned. The response consists of E0, followed by CRLF, totalling 4 bytes.

#### Syntax

```
E0CRLF
```

#### Example

```
E0
```

### Single Negative Response

If a command was not successfully executed, a single negative response is returned. The response consists of E1 followed by an error number, an error message, and CRLF, on one line.

#### Syntax

```
E1_nnn_mmm...mCRLF
```

nnn Error number (001 to 999)

mmm...m Message (variable length, 1 line)

\_ Blank (space)

#### Example

```
E1 001 Fatal system error.
```

### Multiple Negative Response

If one of several commands delimited with a sub-delimiter results in an error, a multiple negative response is returned. The response consists of E2 followed by the error position, error number, and CRLF, on one line.

- It is only output for the portion of the command that was erroneous. If multiple commands resulted in errors, the responses are delimited with commas.
- The position of the error is indicated by a 1 for the first command, 2 for the second command, and so on.

**Syntax**

E2\_ee:nnnCRLF (if only one error occurred)

E2\_ee:nnn,ee:nnn,...,ee:nnnCRLF (if multiple errors occurred)

ee Error position (01 to 99)  
 nnn Error number (001 to 999)  
 \_ Blank

**Example**

E2 03:123,07:456

### ASCII Output


For the format of each, see section 2.2.

**Syntax**

EACRLF  
 .....CRLF  
 :  
 .....CRLF  
 .....CRLF  
 ENCRLF

### Binary Output

**Overview Diagram**



**EBCRLF**

Indicates that data is in binary.

**Data Length**

The number of bytes equalling flag + identifier + header sum + binary data + data sum.

**Header Sum**

Sum value of data length + flag + identifier.

**Binary Data**

For the output format of each data, see section 2.3.

**Data Sum**

Sum value of binary data.

- Sum value is calculated only when “calculate sum” is set in the CS command. The value “0” is stored in the sum value domain when “do not calculate sum” is set.

**Flag**

Bits	Notation	Flag value		Flag Meaning
		0	1	
7	BO	MSB	LSB	Byte order
6	CS	None	Y	Checksum
5		-	-	-
4		-	-	-
3		-	-	-
2		-	-	-
1		-	-	-
0		-	-	-

- The byte order is the data order of 2 or more bytes including the binary data portion. It indicates that data is stored in the MSB (top byte) first or LSB (bottom byte) first.
- Checksum indicates whether a sum value is in the header sum and data sum domains, and if the checksum value (CS) is 0, then 0 is stored in those domains.
- If a dash ( - ) is located in the notation or flag column, the bit is not used. The value is indefinite.

**Identifier**

Identifier	Binary Data Type	Format
0	Unspecified data	File
128	Unspecified data	Data
129	FIFO data	Data
130	The latest measured/computed data	Data
131	Latest output data	Data
132	FIFO read range	Data

### RS-422A/485 Specific Commands/Responses

Commands specific to the RS-422A/485 interface and their responses are shown in the table below.

Command Syntax	Command Meaning	Responses
<i>ESC Oxx CRLF</i>	Instrument open	<ul style="list-style-type: none"><li>• Response from instrument address specified by command: <i>ESC O xx CRLF</i></li><li>• No response when instrument address specified by command does not exist *</li></ul>
<i>ESC Cxx CRLF</i>	Instrument close	<ul style="list-style-type: none"><li>• Response from instrument address specified by command: <i>ESC C xx CRLF</i></li><li>• No response when instrument address specified by command does not exist *</li></ul>

\* The reasons that an instrument of the specified address might not exist include a command error, the specification does not match the address set on the instrument, the power to the instrument is not turned ON, or the instrument is not connected by serial interface.

- The xx in the table indicates the address of the instrument. An address from 01 to 32 can be set, in the range of addresses set on the target instrument.
- Only one instrument can be open at a time.
- If an instrument is opened using the ESC 0 command, commands and responses with that instrument are enabled.
- If one instrument is opened using the ESC 0 command, any other instrument that is already opened is automatically closed.
- Most commands can use CR+LF or LF as a terminator, but these commands can only use CF+LF.

**Note**

---

ESC is expressed as 0x1b in ASCII code. See appendix 5.

---

## 2.2 ASCII Output

ASCII data can be of the following types. The following explains the various formats.

- Response to query
- Output of the latest measured/computed data
- Output of the latest output data
- Output of setting data
- Output of the decimal place and units
- Output of logs and alarm summaries
- Output of status information
- Output of the relay status
- Output of the system recognition status
- Output of the media free space
- Output of file information
- Output of the strain input initial balance result

### **Note**

In this section, *CRLF* means "carriage return/line feed."

### Responses to Queries

Following the format, the current command settings stored in ASCII are output.

#### **Syntax**

```
EACRLF
ttsss...sCRLF
.....
ENCRLF
```

#### **Example 1: (SR?) parameter specified: No, relevant settings: Yes**

```
EA
SR001,VOLT,2V
SR001,VOLT,2V
.....
SR060,VOLT,2V
EN
```

#### **Example 2: (SR?) parameter specified: No, relevant settings: No**

```
EA
EN
```

#### **Example 3: (SR 001 ?) parameter specified: Yes**

```
EA
SR001,VOLT,2V
EN
```

## Output of the Latest Measured/Computed Data

- Output using the FD command.

### Syntax

```
EACRLF
DATE_YY/mo/ddCRLF
TIME_hh:mm:ssCRLF
s_ccccaaaauuuuufdddddEfppCRLF
.....
s_ccccaaaauuuuufeeeeeeeEfppCRLF
.....
ENCRLF
```

YY	Year (00 to 99)
mo	Month (01 to 12)
dd	Day (01 to 31)
hh	Hour (00 to 23)
mm	Minute (00 to 59)
ss	Seconds (00 to 59)
s	Data status (N, D, S, O, E) N: Normal, D: Differential input, S:Skip, O: Over, E: Error
_	Blank
cccc	Channel number (001 to 060 or A001 to A300)
aaaa	Alarm status (H, L, h, l, R, r, T, t, blank x 4 characters) H (upper limit alarm), L (lower limit alarm), h (differential upper limit alarm), l (differential lower limit alarm), R (high limit on rate of change alarm), r (lower limit on rate of change alarm), T (delay upper limit alarm), t (delay lower limit alarm), blank character (no alarm)
uuuuuu	Unit information (output using 6 chars., left justified) mV____: mV V____: V ^C____: °C xxxxxx: (user specified char. string)
f	Data and exponent symbols (+, -)
dddd	Data mantissa (measurement channel, 00000 to 99999) -32767 to +65535: Normally allowed output range +99999: +over, error (measurement error occurs), or indefinite -99999: -OVER
eeeeeeee	Data mantissa (computation channel, 00000000 to 99999999) -99999999 to +99999999: Normally allowed output range +99999999: +OVER -99999999: -OVER
pp	Exponent (00 to 04)

**Example**

```
EA
DATE 05/04/01
TIME 19:56:32
N 001 hhllmV +12345E-01
N 002      mV -67890E-01
N 003      mV +12345E-02
N 004      mV +12345E-02
N 005      mV +12345E-02
N 006      mV +12345E-02
N 007      mV +12345E-02
N 008      mV +12345E-02
N 009      mV +12345E-02
S 010
EN
```

**Note**

- Data of nonexistent channels, including the channel number, are not output.
- In the case of SKIP channels, all values from alarm status to exponent become spaces.

**Output of the Latest Output Data**

- Output using the FO command.

**Syntax**

```
EACRLF
DATE_yy/mo/ddCRLF
TIME_hh:mm:ssCRLF
s_ccccuuuuufdddddEfpCRLF
.....
ENCRLF
```

yy	Year (00 to 99)
mo	Month (01 to 12)
dd	Day (01 to 31)
hh	Hour (00 to 23)
mm	Minute (00 to 59)
ss	Seconds (00 to 59)
s	Data status (N, S) N: Normal, S: Skip
cccc	Channel number (001 to 060)
uuuuuu	Unit information (output using 6 chars., left justified)
f	Data and exponent symbols (+, -)
ddddd	Data mantissa (output channel, 000000 to 999999)
pp	Exponent (00 to 04)
_	Blank

**Example**

```
EA
DATE 05/04/01
TIME 19:56:32
N 001 mA +123456E-01
N 002 mA +123456E-01
N 003 mA +123456E-01
N 004 mA +123456E-01
N 005 mA +123456E-01
N 006 mA +123456E-01
N 007 mA +123456E-01
N 008 mA +123456E-01
N 009 mA +123456E-01
N 010 mA +123456E-01
EN
```

**Output of Setting Data**

- Output using the FE0 command.

**Syntax**

```
EACRLF
ttsss...sCRLF
.....
ENCRLF
```

tt Command name (SR, SA..., XA, XI...)  
sss...s Setting data (variable length, 1 line)

**Example**

```
EA
SR001,VOLT,2V,-20000,20000
SR002,SKIP
SA001,1,OFF
SA001,2,OFF
.....
EN
```



## Output of Decimal Place and Units

- Output using the FE1 command.

### Syntax

EA*CRLF*

s\_ccccuuuuuu, fpp*CRLF*

.....

EN*CRLF*

s Data status (N, D, S)

N: Normal

D: Differential input

S: Skip

\_ Blank

cccc Channel numbers (001 to 060 or A001 to A300)

uuuuuu Unit information (output using 6 chars., left justified)

f Decimal place symbol (+/-)

pp Decimal place (00 to 04)

When f is (+)

When 00, no decimal point is added (00000).

When 01, the decimal point is added after the first digit (0000.0).

When 02, the decimal point is added after the second digit (000.00).

When 03, the decimal point is added after the third digit (00.000).

When 04, the decimal point is added after the fourth digit (0.0000).

When f is (-)

When 01, the value is multiplied by 10.

### Example

EA

N 001 mV ,+03

N 002 mV ,+03

N 003 mV ,+03

N 004 mV ,+03

N 005 mV ,+03

N 006 mV ,+03

N 007 mV ,+03

N 008 mV ,+03

N 008 mV ,+03

N 010 mV ,+03

EN

### Output of Operation Error Logs (FL0, ERROR)

- Output using the FL command.
- The operation error log (records) is output. Up to 50 past operation error logs are retained. If that number is exceeded, old logs are overwritten with new ones.
- For information on the meanings of error codes, see the main unit manual (IM MW100-01E).

**Syntax**

```
EACRLF
yy/mo/dd_hh:mm:ss_nnn_mmm...mCRLF
.....
ENCRLF
```

yy	Year (00 to 99)
mo	Month (01 to 12)
dd	Day (01 to 31)
hh	Hour (00 to 23)
mm	Minute (00 to 59)
ss	Seconds (00 to 59)
nnn	Error code (001 to 999)
mmm...m	Error message (up to 80 characters)
_	Blank

**Example**

```
EA
05/04/01 12:20:00 123 Range setting error.
05/04/01 12:30:00 456 Media access error.
EN
```

### Output of Recording Logs (FL0, RECORD)

- Output using the FL command.
- The data acquisition log is output. Up to 1021 past data acquisition logs are retained. If that number is exceeded, old logs are overwritten with new ones.
- 1 line, 40 characters (fixed length).
- For information on the meanings of error codes, see the main unit manual (IM MW100-01E).

**Syntax**

```
EACRLF
yy/mo/dd_hh:mm:ss_ffffff_mmm...mCRLF
.....
ENCRLF
```

yy	Year (00 to 99)
mo	Month (01 to 12)
dd	Day (01 to 31)
hh	Hour (00 to 23)
mm	Minute (00 to 59)
ss	Seconds (00 to 59)
ffffff	Status ((Power, Card, Format, Record, Mode, Create, Trigger, Delete, Recover, Error, Code, Time, Save)
mmm...m	Message
_	Blank

**Data Acquisition Message Types**

Status	Message	Description
Power	on	Power ON
	off	Power OFF
Card	in	CF card inserted
	out	CF card ejected
	Code	CF card error detected
Format	Ok	CF card formatted successfully
	Code	CF card formatting concluded abnormally
Record	start <i>i</i>	Record start (i=1, 2, 3, M, T: file number)
	stop <i>i</i>	Record stop (i=1, 2, 3, M, T: file number)
	request	Record request accepted (recording conditions not valid)
Mode	rotate -#-	ROTATE recording operation (#=D, T: DIRECT, TRIGGER)
	fullstop -#-	FULLSTOP recording operation (#=D, T: DIRECT, TRIGGER)
	single -#-	SINGLE recording operation (#=D, T: DIRECT, TRIGGER)
(rec. interval)	Recording operation	Recording interval, recording operation, (recording data length/number of writing divisions)
Number of ch	File size	Recording channels, file size
Create	ALARMLG	Alarm log file creation
	RECORDLG	Recording log file creation
	Folder name	Create folder (folder name, /DATAxxxx)
	File name	Create measurement, computation, thinned file (file name: MDDIxxxx)
		Create manual sample file (file name: MDDSxxxx) Create report file (file name: DYYMMDDx (daily report), WYYMMDDx (weekly report), MYYMMDDx (monthly report))
Trigger	exec <i>i</i>	Record start through trigger output (i=1, 2, 3, M: file number)
Delete	(--)	File deletion (for ROTATE)
	File name	File deletion (file name, MDDIxxxx)
Recover	done <i>i</i>	Add remaining data (i=1, 2, 3, M, T: file number)
	none <i>i</i>	Do not add remaining data (i=1, 2, 3, M, T: file number)
	error <i>i</i>	Failed to add remaining data (i=1, 2, 3, M, T: file number)
Error	Error number	Error occurrence
Code	Code	File System Error Code
Time	collect	Time adjustment
Save	exec <i>i</i>	Recording division (i=1, 2, 3, M, or T: file number)

**File numbers**

1, 2, 3: Measurement groups 1 to 3  
M: Computation  
T: Thinning  
S: Manual sample  
R: Report (with the /M3 report function option)

**File size display**

Under 1 KB: \*\*\*\*bytes  
1 to 10 KB: \*.KB  
10 KB or more: \*\*\*\*\*KB

**Period after Time**

Period added: time of request, time request accepted  
No period: time of request, time operation completed

**Example**

```
EA
05/04/01 12:20:00 Power on
05/04/01 12:30:00 Card in
05/04/01 12:30:00.Record start 1
EN
```

## Output of Recording Status Logs (FL0, RECSTATUS)

- Output using the FL command.

### Syntax

```

EACRLF
Record StatusCRLF
n=_ssss_____next=_aaaaa_YY/MM/DD_hh:mm:ssCRLF
.....
CRLF
Data FileCRLF
Folder=_DATA/dddddddCRLF
n=_fffffff.MXD_ _ _ _ bbbbbbb_ccccccc_(iiii)_eeeCHs_LLL/
GGGcells_qqqquuuuuCRLF
.....
CRLF
Report FileCRLF
rrrrrrr=_REPORT/fffffff.DARCRLF
.....
CRLF
Manual Sample FileCRLF
MANUAL/fffffff.DAMCRLF
ENCRLF

```

] With the /M3 report function option

n	Measurement group number
1	Measurement group 1
2	Measurement group 2
3	Measurement group 3
M	MATH (with the /M1 MATH function option)
T	Thinning recording
R	Report (with the /M3 report function option)
ssss	Recording status
stop	No recording or stopped
run	Recording
wait	Recording (trigger wait state)
aaaaaa	Next recording operation (when recording status something other than stopped)
create	File creation
write	Data writing
YY	Year (00 to 99)
MM	Month (01 to 12)
DD	Day (01 to 31)
hh	Hour (00 to 23)
mm	Minute (00 to 59)
ss	Second (00 to 59)
ddddddd	Folder name
fffffff	File name
bbbbbbb	Recording start operation
direct	direct
trigger	trigger

```

ccccccc Recording stop action
          single          single
          fullstop       full stop
          rotate         rotate

iiiiii  Recording interval (10 ms to 1 H)
eee      No. of recording channels (1 to 360)
LLL      Data length (10 M to 31 D)
GGG      No. of times to divide/write
qqqqq   Size of completed file
uuuuu   Units (bytes/KB)
rrrrrrr Report type identifier
          Daily          Daily
          Weekly         Weekly
          Monthly        Monthly
_        Blank

```

**Example**

EA

Record Status

```

1 = wait    next = write  07/04/19 19:58:00
2 = run     next = create  07/04/19 20:00:00
3 = stop
M = stop
T = stop
R = stop

```

Data File

Folder = DATA/DATA0000

```

1 = 41920005.MXD  trigger rotate (100mS) 30CHS 30M/ 5cells 2117KB
2 = 41930006.MXD  direct  rotate (200mS) 10CHS 30M/ 5cells 355KB

```

Report File

```

Daily   = REPORT/D0704180.DAR
Weekly  = REPORT/W0704150.DAR
Monthly = REPORT/M0704010.DAR

```

Manual Sample File

MANUAL/419S0015.DAM

EN

### Output of Alarm Summaries (FL0, ALARM)

- Output using the FL command.
- Alarm summaries are output. Up to 256 past alarms are retained. If that number is exceeded, old alarms are overwritten with new ones.

#### Syntax

EACRLF

yy/mo/dd\_hh:mm:ss.ttt\_cccc\_ls\_aaa..CRLF

.....

ENCRLF

YY	Year (00 to 99)
mo	Month (01 to 12)
dd	Day (01 to 31)
hh	Hour (00 to 23)
mm	Minute (00 to 59)
ss	Seconds (00 to 59)
ttt	Miliseconds (000 to 999)
cccc	Channel numbers (001 to 060 or A001 to A300)
l	Alarm level (1 to 4)
s	Alarm type (H, h, L, l, R, r, T, t)
	H: Upper limit alarm
	h: Difference upper limit alarm
	L: Lower limit alarm
	l: Difference lower limit alarm
	R: High limit on rate-of-change alarm
	r: Low limit on rate-of-change alarm
	T: Delay upper limit alarm
	t: Delay lower limit alarm
aaa..	Alarm status (off,on)
	off: Alarm clear
	on: alarm occurs
_	Blank

(Note) When acknowledging alarm, AlarmAck is output in a position on and after the cccc channel number.

#### Example

EA

05/04/01 12:20:00.000 001 1L on

05/04/01 12:20:00.000 A001 3t off

05/04/01 13:00:00.000 AlarmAck

EN

## Output of Message Summaries (FL0, MESSAGE)

- Output using the FL command.
- Message summaries are output. Up to 50 past messages are retained. If that number is exceeded, old messages are overwritten with new ones.

### Syntax

*EACRLF*

*yy/mo/dd\_hh:mm:ss\_n\_ffffff\_eee\_mmm...mCRLF*

.....

*ENCRLF*

<i>yy</i>	Year (00 to 99)
<i>mo</i>	Month (01 to 12)
<i>dd</i>	Day (01 to 31)
<i>hh</i>	Hour (00 to 23)
<i>mm</i>	Minute (00 to 59)
<i>ss</i>	Seconds (00 to 59)
<i>n</i>	Message number (0 to 5)
<i>ffffff</i>	File name
<i>eee</i>	Extension
<i>mmm...m</i>	Message strings (15 characters, blanks if fewer than that).
<i>_</i>	Blank

### Example

*EA*

05/04/01 12:20:00 1 60110001 MXD message1

05/04/01 12:20:00 2 60110001 MXD message2

*EN*

## Output of Communication Logs (FL0, COM)

- Output using the FL command.
- The communication information log is output. Up to 200 past logs are retained. If that number is exceeded, old logs are overwritten with new ones.

### Syntax

```
EACRLF
yy/mo/dd_hh:mm:ss_nn_uuu...u_d:_mmm...mCRLF
.....
ENCRLF
```

yy	Year (00 to 99)
mo	Month (01 to 12)
dd	Day (01 to 31)
hh	hour (00 to 23)
mm	Minute (00 to 59)
ss	Seconds (00 to 59)
nn	Connection type (s0, e0 to e3)
	s0: General purpose communications (serial)
	e0 to e3: General purpose communication (Ethernet)
uuu...u	User name (16 characters)
d:	Command/response (C/R)
	C: Command
	R: Response
mmm...m	Message (command/response)
_	Blank

### Example

```
EA
99/05/11 12:20:30 s0 admin          C: FF0,001,010
99/05/11 12:20:31 s0 admin          R: (Output)
99/05/11 12:31:10 s0 admin          C: SR001,VOLT
99/05/11 12:31:11 s0 admin          R: E1 123 System error
EN
```



## Output of FTP Client Logs (FL0, FTP\_C)

- Output using the FL command.
- FTP client logs are output. Up to 50 past file transfer logs are retained. If that number is exceeded, old logs are overwritten with new ones.

### Syntax

*EACRLF*

*yy/mo/dd\_hh:mm:ss\_k\_ffffffff\_eee\_mmm...mCRLF*

.....

*ENCRLF*

<i>yy</i>	Year (00 to 99)
<i>mo</i>	Month (01 to 12)
<i>dd</i>	Day (01 to 31)
<i>hh</i>	hour (00 to 23)
<i>mm</i>	Minute (00 to 59)
<i>ss</i>	Seconds (00 to 59)
<i>k</i>	Server type (P, S)
	P: Primary
	S: Secondary
<i>ffffffff</i>	File name (8 characters)
<i>eee</i>	Extension (3 characters)
<i>mmm...m</i>	Error message (only upon error occurrence)
<i>_</i>	Blank

### Example

EA

99/05/11 12:20:00 P 01010000 mxd

99/05/11 12:30:00 P 01010000 mxd

99/05/11 12:40:00 P 01010000 mxd EUNREACH

EN

### FTP Client Error Messages

Error Code	Description	Corrective Action
EHOSTADDR	IP address on the main unit not set.	Set the IP address on the MW100.
EDORMANT	Internal processing error	Servicing required.
ELINK	Ethernet not powered	Check cable connections and power of HUB
EMAIL	Internal processing error	Servicing required.
ESTATUS	Internal processing error	Servicing required.
ETIMEOUT	Internal processing error	Servicing required.
EPRIORITY	Internal processing error	Servicing required.
ENVRAM	Internal processing error	Servicing required.
EHOSTNAME	FTP server name not correct	Check whether destination server name is set correctly. Check the DNS server address setting.
ETCPIP	Internal processing error	Servicing required.
EUNREACH	FTP server not found	Check whether destination FTP server is running. Check the destination server address.
EOOBINLINE	Internal processing error	Servicing required.
ENAME	Internal processing error	Servicing required.
ECTRL	No response from FTP server	Check whether destination FTP server is functioning correctly.
EIAC	Command/response with FTP server failed	Check whether destination FTP server is functioning correctly
EEHC	Command/response with FTP server failed	Check whether destination FTP server is functioning correctly.
EREPLY	Command/response with FTP server failed	Check whether destination FTP server is functioning correctly.
EUSER	Failed to user name input	Check whether user name is allowed on FTP server.
EPASS	Failed to password input	Check whether user name and password are allowed on FTP server.
EACCT	Requested account input	Clear FTP server account function.
ETYPE	Failed to specify transfer mode	Check whether the FTP server supports BINARY transfer.
ECWD	Failed to specify directory	Check whether write permissions granted on the specified directory of the FTP server.
EPORT	Port command communication failed	Check whether a security function is working on the FTP server
EPASV	PASV command com. failed	Check whether the FTP server supports PASV.
ESCAN	PASV command com failed	Check whether PASV on FTP server is working correctly.
EMODE	Internal processing error	Servicing required.
ELOCAL	Internal processing error	Servicing required.

## Output of Mail Client Logs (FL0, SMTP)

- Output using the FL command.
- Mail client logs are output. Up to 50 past logs are retained. If that number is exceeded, old logs are overwritten with new ones.

### Syntax

EACRLF

yy/mo/dd\_hh:mm:ss\_ffffff\_n\_uuu...u\_mmm...mCRLF

.....

ENCRLF

yy	Year (00 to 99)
mo	Month (01 to 12)
dd	Day (01 to 31)
hh	Hour (00 to 23)
mm	Minute (00 to 59)
ss	Seconds (00 to 59)
ffffff	Cause
	ALARM: Alarm mail
	TIME: Time mail
	POWER: Power failure recovery mail
	SYSTEM: Setting error mail
	FILE: File creation mail
	MEDIA: Media free space
	TEST: Test mail
	REPORT: Report mail
n	Recipient list
	1: Recipient 1 only
	2: Recipient 2 only
	+: Both recipients 1 and 2
uuu...u	Recipient mail address (delimited with blanks, 30 characters) (Domain name not output.)
mmm...m	Error message (only upon errors)
-	Blank

### Example

```
EA
01/05/11 12:20:30 ALARM 1 tom
01/05/11 12:20:31 TIME 2 joe ken          EHOSTNAME
EN
```

### Mail Client Error Messages

Error Code	Description	Corrective Action
EHOSTNAME	SMTP server name not correct	Check whether destination server name is set correctly.
ETIMEOUT	Communication with the SMTP power server timed out.	Check cable connections and of HUB.
ELINK	Ethernet not powered	Check cable connections and power of HUB.
EUNREACH	SMTP server not found	Check whether destination SMTP server address is set correctly. Check whether the server is running.

**Mail Client Error Messages (cont.)**

<b>Error Code</b>	<b>Description</b>	<b>Corrective Action</b>
EHELO	HELO command com failed	Check whether SMTP server is functioning correctly.
EMAILFROM	MAILFROM command com failed	Check whether SMTP server is correctly.
ERCPTTO	RCPTTO command com failed	Check whether SMTP server is functioning correctly.
EDATA	Data communication failed	Check whether SMTP server is functioning correctly.
ETCPIP	Internal processing error	Servicing required.
EINVAL	Internal processing error	Servicing required.
EPOP3HOSTNAME	SMTP server name not correct	Check whether destination server name is set correctly.
EPOP3UNREACH	POP3 server not found	Check whether destination POP3 server is running.
EPOP3TIMEOUT	Communication with the POP3 server timed out.	Check cable connections and power of HUB.
EPOP3AUTH	Authorization on POP3 server failed	Check whether user name and server name are allowed on server.

**Output of DHCP Client Logs (FL0, DHCP)**

- Output using the FL command.
- DHCP information logs are output. Up to 50 past logs are retained. If that number is exceeded, old logs are overwritten with new ones.

**Syntax**

```
EACRLF
yy/mo/dd_hh:mm:ss_kkk...k_mmm...mCRLF
.....
ENCRLF
```

```
yy      Year (00 to 99)
mo      Month (01 to 12)
dd      Day (01 to 31)
hh      Hour (00 to 23)
mm      Minute (00 to 59)
ss      Seconds (00 to 59)
kkk...k Message type (15 characters)
mmm...m Message
_       Blank
```

**Example**

```
EA
99/05/11 12:20:30 link      on
99/05/11 12:20:31 apply    192.168.1.1
EN
```

**DHCP Client Message Type**

Message Type	Message	Description
link	off	Ethernet power supply blocked (disconnected)
	on	Ethernet power supply open (connected)
apply	Address	Ethernet I/F address setting
dhcp	off	Disable DHCP function
	on	Enable DHCP function
	renew	Renew lease address
	release	Release lease address
	reject	Reject lease address*
dhcp event	RENEWED	Lease address renewal complete
	EXTENDED	Lease address extension request complete
	RELEASED	Lease address release complete
dhcp error	ESEND	DHCP message send failed
	ESERVER	Failed to find DHCP server
	ESERVFAIL	Response from DHCP server failed (communication timeout)
	ERENEWED	Lease address renewal failed
	EEXTENDED	Lease address extension request failed
	EEXPIRED	Lease address release failed
update	Host name	Registration of host name on DNS server (successful)
	Error Code	Registration of host name on DNS server (failed)
	(no host name)	MW100 main unit host name not set
	(no request)	MW100 main unit DNS Update function not enabled
remove	Host name	Deletion of host name registered on DNS server (successful)
	Error Code	Deletion of host name registered on DNS server (failed)
	(no linked)	Ethernet power supply not open(connected)

\* If the addresses leased from the DHCP server could not be received by the MW100 main unit, the addresses are rejected and the addresses are immediately returned to the DHCP server.

**Error Codes upon DNS Update/Remove Failure**

Location	Error Code	Description
MW100 Main unit	INTERNAL	Query failure (transmission error, receive timeout, other)
DNS Server	FORMERR	Query failure (DNS message format error)
	SERVFAIL	Query failure (DNS server processing error)
	NXDOMAIN	Query rejection (domain does not exist)
	REFUSED	Query rejection (process not allowed)
	YXDOMAIN	Query rejection (record exists)
	YXRRESET	Query rejection (record exists)
	NXRRESET	Query rejection (record does not exist)
	NOTAUTH	Query rejection (not authorized)
NOTZONE	Query rejection (mistaken query destination)	

### Output of Time Synchronization Logs (FL0, SNTP)

- Output using the FL command.
- SNTP client logs are output. Up to 50 past logs are retained. If that number is exceeded, old logs are overwritten with new ones.

#### Syntax

```
EACRLF
yy/mo/dd_hh:mm:ss_kkkkkkkkkk_mmm...mCRLF
.....
ENCRLF
```

YY	Year (00 to 99)
mo	Month (01 to 12)
dd	Day (01 to 31)
hh	Hour (00 to 23)
mm	Minute (00 to 59)
ss	Seconds (00 to 59)
kkk...k	Description
	error : Error
	report : Report of the execution results (no errors)
mmm...m	Error message (only upon error occurrence) or ADJUST (if no error)
-	Blank

#### Example

```
EA
99/05/11 12:20:30 error EBROKEN
99/05/11 12:30:00 report
EN
```

### Time Synchronization Client Error Messages

Error Code	Description	Corrective Action
EDORMANT	Internal processing error	Servicing required.
ENOTACTIVE	Internal processing error	Servicing required.
EACTIVE	Internal processing error	Servicing required.
ELINK	Ethernet not powered	Check cable connections and power of HUB
EHOSTNAME	SNTP server name not correct	Check whether destination server name is set correctly.
ETCPIP	Internal processing error	Servicing required.
EINVAL	Internal processing error	Servicing required.
ESEND	Queries the time on the server failed	Check the IP address of the MW100.
ETIMEOUT	Failed to receive response from server	Check whether destination SNTP server is running.
EBROKEN	Received time information corrupted	Check whether destination SNTP server is functioning correctly

## Output of FTP Server Logs (FL0, FTP\_S)

- Output using the FL command.
- FTP server logs are output. Up to 50 past logs are retained. If that number is exceeded, old logs are overwritten with new ones.

### Syntax

*EACRLF*

*yy/mo/dd\_hh:mm:ss\_d:\_mmm...mCRLF*

.....

*ENCRLF*

<i>yy</i>	Year (00 to 99)
<i>mo</i>	Month (01 to 12)
<i>dd</i>	Day (01 to 31)
<i>hh</i>	Hour (00 to 23)
<i>mm</i>	Minute (00 to 59)
<i>ss</i>	Seconds (00 to 59)
<i>d:</i>	Command/response (C/R)
	C: Command
	R: Response
<i>mmm...m</i>	Message (FTP command/response)
<i>_</i>	Blank

### Example

*EA*

*99/07/26 12:20:30 C: CWD/data*

*99/07/26 12:20:31 R: 200 Command successful*

*99/07/26 12:21:10 C: GET 00100011.MXD*

*99/07/26 12:21:11 R: 550 File is unavailable.*

*EN*

### Output of HTTP Server Logs (FL0, HTTP)

- Output using the FL command.
- HTTP server logs are output. Up to 50 past logs are retained. If that number is exceeded, old logs are overwritten with new ones.

#### Syntax

```
EACRLF
yy/mo/dd_hh:mm:ss_d:_mmm...mCRLF
.....
ENCRLF
```

yy	Year (00 to 99)
mo	Month (01 to 12)
dd	Day (01 to 31)
hh	Hour (00 to 23)
mm	Minute (00 to 59)
ss	Seconds (00 to 59)
d:	Command/response (C/R)
	C: Command
	R: Response
mmm...m	Message (command/response of HTTP)
_	Blank

#### Example

```
EA
99/07/26 12:20:30 C: GET/HTTP/1.1
99/07/26 12:20:31 R: HTTP/1.1 500 Bad Request.
99/07/26 12:31:10 C: GET/index.htm HTTP/1.1
99/07/26 12:31:11 R: HTTP/1.1 200 OK.
EN
```



## Output of Modbus Master Logs (FL0, MODBUS\_M)

- Output using the FL command.
- Modbus master information logs are output.

### Syntax

*EACRLF*

*yy/mo/dd\_hh:mm:ss\_xxx\_mmm...mCRLF*

.....

*ENCRLF*

<i>yy</i>	Year (00 to 99)
<i>mo</i>	Month (01 to 12)
<i>dd</i>	Day (01 to 31)
<i>hh</i>	Hour (00 to 23)
<i>mm</i>	Minute (00 to 59)
<i>ss</i>	Seconds (00 to 59)
<i>xxx</i>	Command number (001 to 100, ---)
<i>mmm...m</i>	Command status
<i>_</i>	Blank

### Example

EA

99/05/11 12:20:30 --- START

99/05/11 12:20:31 001 CONNECTING

99/05/11 12:20:32 001 VALID

EN

### List of Character Codes Showing Modbus Master Command Statuses

The table below also includes character codes that are only used by either the Modbus master or Modbus client.

Command Status	Meaning
SKIP	Command not set
INVALID	Cannot execute command
NO_DATA	Data could not yet be acquired
VALID	Data successfully acquired
STALE	Data became old (acquisition error)
WAITING	Server/slave communication recovery waiting
CLOSED	Connection with server/slave closed
RESOLVING	Establishing connection with server/slave (address being resolved)
CONNECTING	Establishing connection with server/slave (requesting connection)
UNREACH	Failed to connect to server/slave (not found)
TIMEDOUT	Failed to connect to server/slave (time out occurred)
BROKEN	Response message damaged (CRC error)
ERROR	Response message was an error message
BAD_SLAVE	Slave address of response message invalid (does not match command)
BAD_FC	Response message function code invalid (does not match command)
BAD_ADDR	Response message address invalid (does not match command)
BAD_NUM	Response message register invalid (does not match command)
BAD_CNT	Number of response message registers invalid (does not match command)
BAD_DATA	Conversion of response message data failed

### Output of Modbus Master Command Status (FL1, MODBUS\_MC)

- Output using the FL command.
- Modbus master information command status is output.

#### Syntax

EACRLF

SCAN = x, time = y msCRLF

xxx\_mmm...mCRLF

.....

ENCRLF

- x           Number of successfully executed commands (0 to 100)
- y           Time required to execute commands [ms] (0 to
- xxx         Command number (001 to 100)
- mmm...m    Command status  
(See "List of Character Codes Showing Modbus Master Command Statuses" on  
page 2-25).
- \_           Blank

#### Example

EA

scan = 100, time = 10 ms

001 NO\_DATA

002 VALID

003 SKIP

004 SKIP

005 SKIP

006 SKIP

007 SKIP

008 SKIP

009 SKIP

010 SKIP

EN

## Output of Modbus Master Connection Status (FL1, MODBUS\_MS)

- Output using the FL command.
- Modbus master connection status is output.

### Syntax

```
EACRLF
xxx_mmm...mCRLF
.....
ENCRLF
```

```
xxx      Modbus slave address (001 to 247)
mmm...m  Status of connection to Modbus slave
_        Blank
```

### Example

```
EA
001 OPENED
002 FAILED
003 CLOSED
004 CLOSED
005 CLOSED
006 CLOSED
007 CLOSED
008 CLOSED
009 CLOSED
010 CLOSED
EN
```

### List of Character Codes Showing Status of Connections with Modbus Server/Slave

The table below also includes character codes that are only used by either the Modbus master or Modbus slave.

Connection Status	Meaning
FAILED	Connection failed. Recovery wait status.
CLOSED	Connection closed (connection not needed)
OPENED	Connection opened (message could be transmitted)
RESOLVING	Resolving the address
CONNECTING	Requesting connection
CLOSING	Closing connection

## Output of Modbus Slave Log (FL0, MODBUS\_S)

- Output using the FL command.
- The Modbus slave information is output.

### Syntax

EACRLF

yy/mo/dd\_hh:mm:ss\_d:\_aaa\_FC\_nnn\_mmm...m

ENCRLF

YY	Year (00 to 99)
mo	Month (01 to 12)
dd	Day (01 to 31)
hh	Hour (00 to 23)
mm	Minute (00 to 59)
ss	Second (00 to 59)
d	Command/response (C/R)
aaa	Slave address (1 to 247)
nnn	Function code (1 to 127)
mmm...m	Message (see the output format of the command/response)
_	Blank

### Message Output Format (Command)

FC No.	Message Output
1	"(Read_Coil)_" + register number (absolute address) + "+_" + number of registers
2	"(Read_Input)_" + register number (absolute address) + "+_" + number of registers
3	"(Read_Register)_" + register number (absolute address) + "+_" + number of registers
4	"(Read_Register)_" + register number (absolute address) + "+_" + number of registers
5	"(Write_Coil)_" + register number (absolute address) + "+_" + number of registers
6	"(Write_Register)_" + register number (absolute address) + "+_" + number of registers
7	"(Read_Exception)"
8	"(Diagnostics)"
9	"(Program_484)"
10	"(Poll_484)"
11	"(Fetch_Event_Counter)"
12	"(Fetch_Event_Log)"
13	"(Program_584/984)"
14	"(Poll_584/984)"
15	"(Write_Coil)_" + register number (absolute address) + "+_" + number of registers
16	"(Write_Register)_" + register number (absolute address) + "+_" + number of registers
Others	"(???)"

**Message Output Format (Response)**

Response	Exception Code	Message Output
Normal response	None	""
Error response	1	"_ _ Illegal_function"
	2	"_ _ Illegal_data_address"
	3	"_ _ Illegal_data_value"
	4	"_ _ Illegal_response_length"
	5	"_ _ Acknowledge"
	6	"_ _ Slave_device_busy"
	7	"_ _ Negative_acknowledge"
	8	"_ _ Memory_parity_error"
	10	"_ _ Gateway_path_unavailable"
	11	"_ _ Gateway_device_failed_to_respond"
	Others	"_ _ ???"

**Example**

```
EA
06/01/23 16:59:17 C: 1 FC 16 (Write Register) 40011 + 2
06/01/23 16:59:17 R: 1 FC 16
06/01/23 16:59:17 C: 1 FC 3 (Read Register) 40011 + 2
06/01/23 16:59:17 R: 1 FC 3 - Illegal data value
EN
```

### Output of Modbus Client Logs (FL0, MODBUS\_C)

- Output using the FL command.
- Modbus client information logs are output.

#### Syntax

```
EACRLF
yy/mo/dd_hh:mm:ss_xxx_mmm...mCRLF
.....
ENCRLF
YY      Year (00 to 99)
mo      Month (01 to 12)
dd      Day (01 to 31)
hh      Hour (00 to 23)
mm      Minute (00 to 59)
ss      Seconds (00 to 59)
xxx     Command number (001 to 100, ---)
mmm...m Command status
        (See "List of Character Codes Showing Modbus Master Command Statuses" on
        page 2-25).
_      Blank
```

#### Example

```
EA
99/05/11 12:20:30 --- START
99/05/11 12:20:31 001 CONNECTING
99/05/11 12:20:32 001 VALID
EN
```

### Output of Modbus Client Command Status (FL1, MODBUS\_CC)

- Output using the FL command.
- Modbus client command status is output.

#### Syntax

```
EACRLF
SCAN = x, time = y msCRLF
xxx_mmm...mCRLF
.....
ENCRLF
x      Number of successfully executed commands (0 to 100)
y      Time required to execute commands [ms] (0 to)
xxx   Command number (001 to 100)
mmm...m Command status
        (See "List of Character Codes Showing Modbus Master Command Statuses" on
        page 2-25).
_      Blank
```

**Example**

```
EA
scan = 100, time = 10 ms
001 NO_DATA
002 VALID
003 SKIP
004 SKIP
005 SKIP
006 SKIP
007 SKIP
008 SKIP
009 SKIP
010 SKIP
EN
```

**Output of Modbus Client Connection Status (FL1, MODBUS\_CS)**

- Output using the FL command.
- Modbus master connection status is output.

**Syntax**

```
EACRLF
xxx_mmm...mCRLF
.....
ENCRLF
```

xxx	Modbus server number (001 to 247)
mmm...m	Status of connection to Modbus server (See page 2-27, "List of Character Codes Showing Status of Connections with Modbus Server/Slave.")
_	Blank

**Example**

```
EA
001 OPENED
002 CONNECTING
003 FAILED
004 CLOSED
005 CLOSED
006 CLOSED
007 CLOSED
008 CLOSED
009 CLOSED
010 CLOSED
EN
```

### Output of Modbus Server Log (FL0, MODBUS\_T)

- Output using the FL command.
- The Modbus server information is output.

#### Syntax

EACRLF

yy/mo/dd\_hh:mm:ss\_d:\_aaa\_FC\_nnn\_mmm...m

ENCRLF

yy	Year (00 to 99)
mo	Month (01 to 12)
dd	Day (01 to 31)
hh	Hour (00 to 23)
mm	Minute (00 to 59)
ss	Second (00 to 59)
d	Command/response (C/R)
aaa	Slave address (1 to 247)
nnn	Function code (1 to 127)
mmm...m	Message (see the output syntax of the command/response)
_	Blank

#### Message Output Format (Command)

FC No.	Message Output
1	"(Read_Coil)_" + register number (absolute address) + "+_" + number of registers
2	"(Read_Input)_" + register number (absolute address) + "+_" + number of registers
3	"(Read_Register)_" + register number (absolute address) + "+_" + number of registers
4	"(Read_Register)_" + register number (absolute address) + "+_" + number of registers
5	"(Write_Coil)_" + register number (absolute address) + "+_" + number of registers
6	"(Write_Register)_" + register number (absolute address) + "+_" + number of registers
7	"(Read_Exception)"
8	"(Diagnostics)"
9	"(Program_484)"
10	"(Poll_484)"
11	"(Fetch_Event_Counter)"
12	"(Fetch_Event_Log)"
13	"(Program_584/984)"
14	"(Poll_584/984)"
15	"(Write_Coil)_" + register number (absolute address) + "+_" + number of registers
16	"(Write_Register)_" + register number (absolute address) + "+_" + number of registers
Others	"(???)"



**Message Output Format (Response)**

Response	Exception Code	Message Output
Normal response	None	""
Error response	1	"_ _ _Illegal_function"
	2	"_ _ _Illegal_data_address"
	3	"_ _ _Illegal_data_value"
	4	"_ _ _Illegal_response_length"
	5	"_ _ _Acknowledge"
	6	"_ _ _Slave_device_busy"
	7	"_ _ _Negative_acknowledge"
	8	"_ _ _Memory_parity_error"
	10	"_ _ _Gateway_path_unavailable"
	11	"_ _ _Gateway_device_failed_to_respond"
	Others	"_ _ _???"

**Example**

```
EA
06/01/23 16:59:17 C: 1 FC 16 (Write Register) 40011 + 2
06/01/23 16:59:17 R: 1 FC 16
06/01/23 16:59:17 C: 1 FC 3 (Read Register) 40011 + 2
06/01/23 16:59:17 R: 1 FC 3 - Illegal data value
E
```

**Output of MATH Status (FLO, MATH)**

- Output using the FL command.
- Computation information is output (specified MATH interval and actually required computation time).

**Syntax**

```
EACRLF
math_interval = _aaa.bbb_sCRLF
math_time ____ = _aaa.bbb_sCRLF
.....
ENCRLF

math interval    Specified MATH interval
math time        Actually required computation time
aaa              Seconds (0 to 999)
bbb              Milliseconds (000 to 999)
_                Blank
```

**Example**

```
EA
math interval = 1.000 s
math time     = 0.800 s
EN
```

### Output of Operation Logs (FL0, CMD)

- Output using the FL command.
- Operation logs are output. Up to 50 past logs are retained. If that number is exceeded, old logs are overwritten with new ones.

#### Syntax

```
EACRLF
yy/mo/dd_hh:mm:ss_mmm...mCRLF
.....
ENCRLF
```

yy	Year (00 to 99)
mo	Month (01 to 12)
dd	Day (01 to 31)
hh	Hour (00 to 23)
mm	Minute (00 to 59)
ss	Seconds (00 to 59)
mmm...m	Contents of operation (...)
	MeasStart            Measurement start
	MeasStop:           Measurement stop
	MemStart:            Recording start
	MemStop:             Recording stop
	MathStart:           Computation start
	MathStop:            Computation stop
	MathReset:           Reset MATH values
	MathClear:           Clear MATH values
	AlarmAck:            Check alarm status
	ManualSample:        Perform manual sampling
	ManualDivide:        Divide manual sample file
	Message0-5:          Write message 0 to 5
	MemorySave:          Divide measurement/computation file
	MemorySave_T:        Divide thinned file
	NewTime:             Time change
	Clear0:              Initialize measurement (RC 0)
	Clear1:              Initialize measurement (RC 1)
	Construct:            Reconfigures the system
	TimeReset1-6:        Reset timers 1-6
	BaranceReset:        Initialize balance value
	BaranceExec:         Execute initial balancing
	PowerOn:             Power ON
	PowerOff:            Power OFF
-	Blank

#### Example

```
EA
99/05/11 12:20:30 PowerOn
99/05/11 12:20:31 PowerOff
EN
```

## Output of Strain Input Initial Balancing Result (FL1, BALANCE)

Output using the FL1 command.

### Syntax

```
EACRLF
s_cccc_uuCRLF
.....
ENCRLF
```

```

s          Status (A, F, S)
           A: Executing initial balancing
           F: Exit initial balancing
           S: Skip
cccc      Channel number (001-060)
uu        Initial balancing result (OK, NG)
           OK: Reset or initial balance successful
           NG: Reset or initial balance failed
_         Blank
```

### Example

```
EA
F 001 OK
F 002 OK
S 003
EN
```

## Output of Status Information (IS)

- Output using the IS command.
- Outputs the operational status of the instrument.
- For details on the status information, see appendix 4, “Bit Structure of Status Information.”

### Syntax

```
EACRLF
aaa.bbb.ccc.ddd.fff.ggg.hhhCRLF
ENCRLF
```

```

aaa      Status information (000 to 255)
bbb      Status information 1 (000 to 255)
ccc      Status information 3 (000 to 255)
ddd      Status information 4 (000 to 255)
eee      Status information 5 (000 to 255)
fff      Status information 6 (000 to 255)
ggg      Status information 7 (000 to 255)
hhh      Status information 8 (000 to 255)
```

### Example

```
EA
000.000.002.000.000.000.000.000
EN
```

### Output of Relay Status (VF)

- Output using the VF command.
- Regardless of the base unit type, 6 slots of module information is always output.

#### Syntax

```
EACRLF  
n_aaaaaaaaCRLF  
n_aaaaaaaaCRLF  
n_aaaaaaaaCRLF  
n_aaaaaaaaCRLF  
n_aaaaaaaaCRLF  
n_aaaaaaaaCRLF  
ENCRLF
```

n	Module number (0 to 5)
aaaaaaaa	Relay status (from the left, corresponds to module relay numbers 01 to 10)
1:	Relay output ON
0:	Relay output OFF
-	Blank

#### Example

```
EA  
0 1111100000  
1 1110000000  
2 -----  
3 -----  
4 -----  
5 -----  
EN
```

## Output of System Recognition Status (CF)

- Output using the CF command.
- Regardless of the base unit type, 6 slots of module information is always output.

### Syntax

EACRLF

n\_S=aaa-bbb-ccc\_R=aaa-bbb-ccc\_mmm...mCRLF

n\_S=aaa-bbb-ccc\_R=aaa-bbb-ccc\_mmm...mCRLF

n\_S=aaa-bbb-ccc\_R=aaa-bbb-ccc\_mmm...mCRLF

n\_S=aaa-bbb-ccc\_R=aaa-bbb-ccc\_mmm...mCRLF

n\_S=aaa-bbb-ccc\_R=aaa-bbb-ccc\_mmm...mCRLF

n\_S=aaa-bbb-ccc\_R=aaa-bbb-ccc\_mmm...mCRLF

ENCRLF

n	Module number (0 to 5)
S=	Status of modules set on the system
R=	Status of modules actually installed
aaa:	Module model
bbb:	Module basic specifications code (input/output type)
ccc:	Module basic specifications code (measuring interval, no. of channels)
mmm...m	Module error status (10 characters)
RomError:	EEPROM damaged
CalError:	Calibration value damaged
SlotError:	30-CH Medium Speed DCV/TC/DI Input Module installed in invalid slot.
_	Blank: Normalize without error

### Example

EA

0 S=MX110-UNV-H04 R=MX110-UNV-H04

1 S=MX110-UNV-M10 R=MX110-UNV-M10 CalError

2 S=MX110-UNV-M10 R=MX110-UNV-H04

3 S=MX115-D05-H10 R=MX115-D05-H10

4 S=MX125-MKC-M10 R=-----

5 S=----- R=-----

EN

### Output of Media Free Space (ME0)

- Output using the ME command.

#### Syntax

```
EACRLF
aaaaaaa/_bbbbbbb_K byte freeCRLF
ENCRLF

      aaaaaaa           Media free space [KB] (0 to 9999999)
      bbbbbbb           Media total capacity [KB] (0 to 9999999)
```

#### Example

```
EA
      5000 /   16000 K byte free
EN
```

### Output of File Information (ME1)

- Output using the ME command.

#### Syntax

```
EACRLF
fffffff_eee_ssssssss_yy/mo/dd_hh:mm:ssCRLF
.....
aaaaaaa/_bbbbbbb_K byte freeCRLF
ENCRLF

      ffffffff           File or folder name (8 characters)
      eee                 Extension (3 characters)
      ssssssss           File data size (0 to 99999999) [byte(s)]
      YY                 Year (00 to 99)
      mo                 Month (01 to 12)
      dd                 Day (01 to 31)
      hh                 hour (00 to 23)
      mm                 Minute (00 to 59)
      ss                 Seconds (00 to 59)
      aaaaaaa           Media free space [KB] (0 to 9999999)
      bbbbbbb           Media total capacity [KB] (0 to 9999999)
      -                   Blank
```

#### Example

```
EA
10000000 MXD           1204 05/02/24 20:07:12
10000001 MXD           1204 05/03/19 01:52:37
DATA <DIR>             05/01/19 01:23:64
      7523 /   16000 K byte free
EN
```

## 2.3 Binary Output


### Note

In this section, *CRLF* means "carriage return/line feed."


### Output of the Latest Measured/Computed Data

- Output using the FD1 command.

#### Format of Response to FD1 Command



#### Data Block Structure



#### Data Block Member Values

Member Name	Value
Year	00 to 99 (70 to 99: 1970 to 1999, 00 to 69: 2000 to 2069)
Month	1 to 12
Day	1 to 31
Hour	0 to 23
Minute	0 to 59
Second	0 to 59
Channel number	1 to 60: Measurement Channel 101 to 400: MATH channels
Alarm value	0: Alarm OFF 1: Upper limit alarm occurs 2: Lower limit alarm occurs 3: Differential upper limit alarm occurs 4: Differential lower limit alarm occurs 5: High limit on rate-of-change alarm occurs 6: Lower limit on rate-of-change alarm occurs 7: Delay upper limit alarm occurs 8: Delay lower limit alarm occurs
Data values	-32767 to 65535 -9999999 to 99999999
Reserved	Undefined

## 2.3 Binary Output

### Special Data Values

During special statuses, measured and computed values are as shown in the table below.

Special Data Value Type	Value
+OVER	0x7fff 0x7fff
-OVER	0x8001 0x8001
Measurement SKIP/computation OFF	0x8002 0x8002
Error	0x8004 0x8004
Uncertain	0x8005 0x8005


### Note

- With output of the latest measured or computed data (FD1), a time stamp is added not according to the time the data was created, but rather the time the command was issued.
- Measured/computed data values are stored as 32-bit integers.
- Alarm statuses are output without regard to the byte order specified in the BO command.

## Output of the Latest Output Data

- Output using the FO1 command.

### Format of Response to FO1 Command



### Data Block Structure

8 bytes						
Year	Month	Day	Hours	Minute	Second	(Reserved)
(Reserved)						
Channel number		(Reserved)		Data value		
Channel number		(Reserved)		Data value		
Channel number		(Reserved)		Data value		

### Data Block Member Values


Member Name	Value
Year	00 to 99 (70 to 99: 1970 to 1999, 00 to 69: 2000 to 2069)
Month	1 to 12
Day	1 to 31
Hours	0 to 23
Minute	0 to 59
Second	0 to 59
Channel number	1 to 60: Output channel
Data value	-32767 to 100000
Unused	Undefined




### Output of FIFO Data

- Output using the FF0 command.


#### Format of Response to FF0 Command




#### Data Block Structure



#### • Structure of Added Information



#### • Structure of Alarm Statuses



## 2.3 Binary Output

### Data Block Member Values

Member Name	Value
Year	00 to 99 (70 to 99: 1970 to 1999, 00 to 69: 2000 to 2069)
Month	1 to 12
Day	1 to 31
Hours	0 to 23
Minute	0 to 59
Second	0 to 59
Milliseconds	0 to 990
Computation start	0, 1
Message information	Bits 0:0, 1 Bits 1:0, 1 • •
Setting key	0x0000 to 0xffff
Channel number	1 to 60: Measurement Channel 101 to 400: MATH channels
Alarm Status	0: No specification 1: Upper limit alarm setting 2: Lower limit alarm setting 3: Differential upper limit alarm setting 4: Differential lower limit alarm setting 5: Rate of change upper limit alarm setting 6: Rate of change lower limit alarm setting 7: Delay upper limit alarm setting 8: Delay lower limit alarm setting
Data value	-32767 to 65535 -99999999 to 99999999
Unused	Undefined

### Special Data Values

During special statuses, measured and computed values are as shown in the table below.

Special Data Value Type	Value
+OVER	0x7fff 0x7fff
-OVER	0x8001 0x8001
Error	0x8004 0x8004


### Note

- Added information and alarm statuses are output without regard to the byte order specified in the BO command.
- Messages inside added information is uncertain.


## FIFO Read Range

- Output using the FF1 command.

### Format of Response to FF1 Command



### Read Range Block Structure



### Note

- Added information is output without regard to the byte order specified in the BO command.
- Messages inside added information is uncertain.

# Appendix 1 Serial Interface (Optional) Specifications

The following are the specifications for both types of serial interface (optional) for the main unit, RS-232 and RS-422A/485.

## RS-232 Specifications

Connector Type	D-Sub, 9-pin, Plug
Electrical and mechanical spec.	Conforms with EIA-574 (EIA-232 (RS-232) standard for 9-pin)
Connection method	Point-to-point
Synchronization method	Start-stop (asynchronous) system
Baud rate	Select from 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200
Start bit	1 bit, fixed
Data length (When outputting data in binary format, you must use 8 bits.)	Select either 7 or 8 bits
Parity	Select Odd, Even, or None
Stop bit	Select either 1 or 2 bits
Hardware handshaking	For RS and CS signals, select always TRUE, or to use as a control line.
Software handshaking	Select to control send using X-ON and X-OFF signals, or to use X-ON and X-OFF signals with send/receive signals. X-ON(ASCII 11H), X-OFF(ASCII 13H)
Receive buffer length	2047 bytes

## RS-422A/485 Specifications

Terminal Type	Six terminals; clamp, 0.14 to 1.5mm <sup>2</sup> (AWG26 to 16)
Electrical and mechanical spec.	Complies with EIA-422A (RS-422A) and EIA-485 (RS-485)
Connection method	Multidrop: 4-wire: 1:32 2-wire: 1:31
Communication mode	Half-duplex
Synchronization method	Start-stop (asynchronous) system
Baud rate	Select from 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200
Start bit	1 bit, fixed
Data length	Select either 7 or 8 bits
Parity	Select Odd, Even, or None
Stop bit	Select either 1 or 2 bits
Receive buffer length	2047 bytes
Electrical characteristics	6 points: FG, SG, SDB, SDA, RDB, RDA SG, SDB, SDA, RDB, and RDA terminals are functionally isolated from the internal circuitry of the main unit. The FG terminal is frame ground.
Communication Distance	1.2 km maximum
Termination Resistance	Built-in (with switch) 120 Ω, 1/2 W

# Appendix 2 Modbus Protocol

## Modbus Protocol Specifications

The following are the Modbus specifications of the MW100.

Specifications	Description
Communication media	Ethernet, RS-232, or RS-422A/485
Control method	Ethernet RS-232: None only RS-422A/485: None only
Baud rate	Select 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200 bps
Start bit	1 bit, fixed
Data length	Select either 7 or 8 bits
Parity	Select Odd, Even, or None
Stop bit	Select either 1 or 2 bits
Data interval	24 bit time or less
Error detection	CRC-16
Transmission mode	RTU (remote terminal unit) mode only
Slave address	1~247

## Modbus Protocol Function Code

### Slave/Server Functions

The slave function of the main unit does not support broadcasted commands.

Function Code	Functions	Action
3	Read hold registers (4xxxx)	Master/client instrument can load communication input data of the MW100 written with function code 6 or 16.
4	Read input registers (3xxxx)	Master/client instrument reads the MW100's measured, computed, and time data.
6	Write to hold a register (4XXXX)	Master/client instrument writes to the MW100's communication input data.
8	Loop back test	Master/client instrument performs the loop back test of the MW100. The MW100 only supports message return (diagnostic code (0x00*))
16	Write to hold registers (4xxxx)	Master/client instrument writes to the MW100's communication input data.

\* 00 hexadecimal display.

### Master Function/Client Function

Function Code	Functions	Action
3	Read hold registers (4XXXX, 4xxxxx),	The MW100 loads the hold register data of another instrument to the communication input data (Cxx).
4	Read input registers (3XXXX, 4xxxxx),	The MW100 loads the input register data of another instrument to the communication input data (Cxx).
6	Write to hold a register (4XXXX, 4xxxxx)	The MW100 writes to hold a register of another instrument
16	Write to hold registers (4XXXX, 4xxxxx)	The MW100 writes to the hold registers of another instrument

## Register Assignments (Modbus Slave)

The following are the Modbus slave register assignments.

### Input Registers

Absolute Address	Relative Address	Allocation	Data Type
30001	0000	Lower byte of data from measurement channel 001	INT32
30002	0001	Upper byte of data from measurement channel 001	
:	:	:	:
30119	0118	Lower byte of data from measurement channel 060	INT32
30120	0119	Upper byte of data from measurement channel 060	
31001	1000	Lower byte of data from measurement channel 001	FLOAT
31002	1001	Upper byte of data from measurement channel 001	
:	:	:	:
31119	1118	Lower byte of data from measurement channel 060	FLOAT
31120	1119	Upper byte of data from measurement channel 060	
32001	2000	Alarm status of measurement channel 001	BIT16
:	:	:	:
32060	2059	Alarm status of measurement channel 060	BIT16
• Registers corresponding to products with the /M1 MATH function option.			
33001	3000	Lower byte of data from MATH channel A001	INT32
33002	3001	Upper byte of data from MATH channel A001	
:	:	:	:
33599	3598	Lower byte of data from MATH channel A300	INT32
33600	3599	Upper byte of data from MATH channel A300	
34001	4000	Lower byte of data from MATH channel A001	FLOAT
34002	4001	Upper byte of data from MATH channel A001	
:	:	:	:
34599	4598	Lower byte of data from MATH channel A300	FLOAT
34600	4599	Upper byte of data from MATH channel A300	
35001	5000	Alarm status of MATH channel A001	BIT16
:	:	:	:
35300	5290	Alarm status of MATH channel A300	BIT16
39001	9000	Year (4 digits) (1900 to )	INT16
39002	9001	Month (1 to 12)	
39003	9002	Day (1 to 31)	
39004	9003	Hours (0 to 23)	
39005	9004	Minute (0 to 59)	
39006	9005	Second (0 to 59)	
39007	9006	Milliseconds (0 to 999)	
39008	9007	DST(0,1)	

### Note

- For INT32, only the mantissa of the measured/computed data can be acquired. The decimal place must be obtained separately.
- For FLOAT, the measured/computed data including the decimal place can be acquired.
- The FLOAT and INT32 data domains are set so that they can only be accessed (read/write) by the unit of two registers.
- Alarm statuses are output in the same format as those described in section 2.3, "Binary Output."

**Hold Registers**

Absolute Address	Relative Address	Allocation	Data Type
40001	0000	Lower byte of data from communication input channel C001	FLOAT
40002	0001	Upper byte of data from communication input channel C001	
⋮	⋮	⋮	⋮
40599	0598	Lower byte of data from communication input channel C300	FLOAT
40600	0599	Upper byte of data from communication input channel C300	

**Register Assignments (Modbus Slave)**

When using the Modbus slave function, the instrument returns the following error codes to the master device.

Code	Meaning	Cause
1	Function code invalid	Requested non-supported function
2	Invalid register number	Attempted to read/write registers with no corresponding channel.
3	Invalid number of registers	The specified number of registers was zero.
7	Could not be executed	Attempted to read MATH registers from MW100 without the MATH function option.


However, there is no response in the following cases.

- CRC Error
- Error other than in the table above

# Appendix 3 Modbus Communication Timeout

This MW100 has a function in which, communication with Modbus slave devices that could not receive a response after the number of retries or more is dropped every communication interval by access sequence. Communication with Modbus slave devices dropped in sequence is retried after the communication wait time has elapsed.

## Modbus Master Timer Function



## Timeout Types

Timeout	Description
Communication cycle	Modbus master command list (communication sequence) execution interval
Retransmission	When fails to receive response message, maximum number of retries until communication recovery wait status.
Wait time	Wait time until the next command message is sent to instruments that entered the communication recovery wait status.



## Appendix 4 Bit Structure of Status Information

The following status information is output upon request by the IS command.

### Status Information 1 (Task Complete 1)

Bit	Name	Description
0	A/D conversion cmplt'd 1	Set to 1 when A/D conversion on meas group 1 is completed.
1	A/D conversion cmplt'd 2	Set to 1 when A/D conversion on meas group 2 is completed.
2	A/D conversion cmplt'd 3	Set to 1 when A/D conversion on meas group 3 is completed.
3	Media access cmplt'd	Set to 1 when saving of recorded data to ext media is completed.
4	Report file creation cmplt'd	Set to 1 when saving of report data to ext media is completed.
5	Manual sample file creation cmplt'd	Set to 1 when saving of manual sample data to ext media is completed.
6	-	-
7	-	-

### Status Information 2 (Task Complete 2)

Bit	Name	Description
0	Computation reset	Set to 1 when the computation reset command (EX2) is received, or the MATH_RESET action of the Event/Action function occurs.
1	Reset MATH group 1	Set to 1 when the MATH_RST_GR1 action of the Event/Action function occurs.
2	Reset MATH group 2	Set to 1 when the MATH_RST_GR2 action of the Event/Action function occurs.
3	Reset MATH group 3	Set to 1 when the MATH_RST_GR3 action of the Event/Action function occurs.
4	Reset MATH group 4	Set to 1 when the MATH_RST_GR4 action of the Event/Action function occurs.
5	Reset MATH group 5	Set to 1 when the MATH_RST_GR5 action of the Event/Action function occurs.
6	Reset MATH group 6	Set to 1 when the MATH_RST_GR6 action of the Event/Action function occurs.
7	Reset MATH group 7	Set to 1 when the MATH_RST_GR7 action of the Event/Action function occurs.

### Status Information 3 (Abnormality)

Bit	Name	Description
1	Decimal place/units change	Set to 1 when the decimal place or units are changed.
2	Computation omitted	Set to 1 when timing of the MATH channel processing failed.
3	-	-
4	-	-
5	-	-
6	-	-
7	-	-

**Status Information 4 (Event)**

Bit	Name	Description
0	-	-
1	-	-
2	Low free space on media	Set to 1 when there is only a small amount of remaining free space on the medium.
3	-	-
4	-	-
5	-	-
6	-	-
7	-	-

**Status Information 5 (Mode)**

Bit	Name	Description
0	Setting	Set to 1 when transitioning to Setting mode.
1	Recording	Set to 1 when transitioning to Recording mode.
2	Computing	Set to 1 when computation starts.
3	Alarm occurrence	Set to 1 when alarm occurs.
4	Wait for alarm	Set to 1 when waiting for alarm acknowledgment (AK acknowledgment command).
5	Saving/loading settings	Set to 1 when saving or loading settings.
6	-	-
7	-	-

**Status Information 6 (Mode)**

Bit	Name	Description
0	Transmitting	Set to 1 during transmission output.
1	-	-
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-
7	-	-

# Appendix 5 ASCII Character Codes

		Top 4 bits															
		0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
Bottom 4 bits	0			SP	0	@	P	'	p								
	1			!	1	A	Q	a	q								
	2			”	2	B	R	b	r								
	3			#	3	C	S	c	s								
	4			\$	4	D	T	d	t								
	5			%	5	E	U	e	u								
	6			&	6	F	V	f	v								
	7			'	7	G	W	g	w								
	8			(	8	H	X	h	x								
	9			)	9	I	Y	i	y								
	A	LF		*	:	J	Z	j	z								
	B		ESC	+	;	K	[	k	{								
	C			,	<	L		l									
	D	CR		-	=	M	]	m	}								
	E			.	>	N	^	n	~								
	F			/	?	O	_	o									

**Note**

- Delimiter (,), sub delimiter (;), query symbol (?), and terminator (CR, LF) cannot be used for parameters.

# Appendix 6 Maintenance/Diagnostic Server

The maintenance/diagnostic server function investigates the MW100 communication status. The MW100 main module is connected to a PC using an Ethernet cable, then using Telnet or some other terminal emulator, communication commands can be used from the PC to perform maintenance/diagnostics on the MW100. Commands are sent from the PC to the MW100, and the MW100 performs a command/response type communication with the PC. Only one PC can be connected to one MW100.

## Connection between the Main Module and PC

See the MW100 Data Acquisition Unit User's Manual (IM MW100-01E).

## Terminal Emulator Settings

Set up the terminal emulator as follows to perform MW100 maintenance/diagnostics using communication commands. The terminal emulator is set to connect using the MW100's IP address. The port number is 34317.

- Local echo: ON
- Line feed code of the transmit data: CR+LF

## List of Maintenance/Diagnostic Commands

Command Name	Functions
con	Output TCP connection information
eth	Output Ethernet information
help	Output command help
login	Login
logout	Log out
net	Output network information
uart	Outputs UART I/F information

## Main Specifications of the Maintenance/Diagnostic Server

Port number	34317/tcp
Transfer data	ASCII character string
Command	A string on a single line ending with the CR+LR terminator
Responses	Strings on multiple lines ending with the CR+LR terminator
Keep alive	Always enabled
Receive timeout	10 minutes
Maximum number of simultaneous connections	1

**con**

**Output Connection Information**

Function Outputs a list of devices connected to the MW100.  
 Setting con  
 Example con

```
EA
Active Connections

ProtoLocal Address      Foreign Address State
TCP    10.0.233.126 : 3431710.0.232.194 : 1382 ESTABLISHED
TCP    0.0.0.0:34317  0.0.0.0:0        LISTEN
TCP    0.0.0.0:502    0.0.0.0:0        LISTEN
TCP    0.0.0.0:80     0.0.0.0:0        LISTEN
TCP    0.0.0.0:34318  0.0.0.0:0        LISTEN
TCP    0.0.0.0:34316  0.0.0.0:0        LISTEN
TCP    0.0.0.0:123   0.0.0.0:0        LISTEN
TCP    0.0.0.0:34323  0.0.0.0:0        LISTEN
EN
```

Explanation Outputs a list of connections in a form enclosed by EA and EN.

```
Proto:          Protocol used
Local Address:  Address and port number of the MW100
Foreign Address:Address and port number on the PC
State:  Connection status

CLOSED          No connection
LISTEN          Waiting (SYN wait)
SYN_SENT        SYN sent (SYN+ACK wait)
SYN_RCVD        SYN received (wait for ACK to SYN)
ESTABLISHED     Connection established
CLOSE_WAIT      Close request (FIN wait)
FIN_WAIT_1      Close request wait-1 (FIN wait)
CLOSING         Closing (waiting ACK to FIN)
LAST_ACK        Remote close check waiting (ACK wait)
FIN_WAIT_2      Close request wait-2 (FIN wait)
TIME_WAIT       Time wait
```

**eth**

**Output of Ethernet Information**

Function Outputs statistics on packets flowing on the MW100 Ethernet interface.  
 Values output with this function are those that are accumulated starting when the MW100 power is turned ON.

Setting eth  
 Example eth

```
EA
Ethernet Statistics

Name  In Pkt  In Err  Out Pkt  Out Err  16 Coll
sn0   917     1       51       0        0
lo0   0       0       0        0        0
EN
```

**Explanation** Outputs statistical information of the packets that flowed through the interface in a form enclosed by EA and EN.

```
Name      : Interface name (sn: Ethernet, lo: loop back)
in Pkt    : Number of received packets
In Err    : Number of packets that generated receive errors
Out Pkt   : Number of sent packets
Out Err   : Number of packets that generated send errors
16 Coll   : Number of 16 collision occurrences
```

**help**

**Command Help Output**

**Function** Outputs a list of currently available maintenance/diagnostic commands.

**Setting** help

**Example** help

```
EA
Diagnostic command list

con      - echo active connections
eth      - echo ethernet statistics
help     - echo command list
login    - login or re-login
logout   - logout
net      - echo network statistics
uart     - echo UART statistics
EN
```

**Explanation** Outputs a list of currently available commands in a form enclosed by EA and EN.

**login**

**Login**

**Function** Authorizes users connected for maintenance/diagnostic services.

**Setting** login p1 p2  
(p1: user name, p2: password)

**Example** E1 501 Login first.  
login admin abc  
E0

**Explanation** Notifies success or failure of login using EO or E1.  
If the login function is not used, the password can be omitted.

**logout**

**Logout**

Function Closes the maintenance/diagnostic session and closes currently used TCP connections from the MW100 side.

Setting `logout`

Example `logout`

E0

Explanation After returning E0, the MW100 issues a close TCP/IP connection request (FIN).

**net**

**Output Network Information**

Function Outputs general network information related to the MW100 communication stack.

Setting `net`

Example `net`

EA

Network Statistics

TCP: connects = 1

TCP: closed = 0

TCP: timeoutdrop = 0

TCP: keepdrops = 0

TCP: sndtotal = 12

TCP: sndbyte = 25

TCP: sndrexitpack = 0

TCP: sndrexitbyte = 0

TCP: rcvtotal = 15

TCP: rcvbyte = 18

DLC: speed mode = 10 Mbps

DLC: duplex mode = half

DLC: link state = on

EN

Explanation Outputs general network information related to the MW100 communication stack in a form enclosed by EA and EN.

**uart****Outputs UART I/F Information**

Function Outputs statistics on the MW100 UART I/F (serial port).

Setting **uart**

Example `uart`

`EA`

`UART Statistics`

`uart[]=`

`{`

`break err = 0`

`parity err = 0`

`frame err = 0`

`under-run = 0`

`over-run = 0`

`RX bytes = 0`

`TX bytes = 0`

`}`

`{`

`break err = 0`

`parity err = 0`

`frame err = 0`

`under-run = 0`

`over-run = 0`

`RX bytes = 0`

`TX bytes = 0`

`}`

`EN`

Explanation Outputs statistics related to UART /IF in a form enclosed by EA and EN.



## Appendix 7 Error Display on the 7-Segment LED and Corrective Actions

The main module has a two-digit 7-segment LED. The 7-segment LED displays the system status. This section describes the displays on the 7-segment LED when errors occur on the system and their corrective actions.

If servicing is necessary, or if the instrument is not operating correctly after performing the corrective actions below, contact your nearest YOKOGAWA dealer.

### Errors upon Startup

The left and right digits of the 7-segment LED display “b” and an error code, respectively. The LED illuminates.

Display	Possible Problem	Corrective Action
b* (where * is any character other than F).	The dipswitch settings are not correct.	Turn OFF the power, remove the CF card, turn ON all dip switches and power up again. If the situation does not change servicing is required.
bF	The dipswitch settings are not correct.	Power up in setup reset mode. Turn OFF the power, turn ON all dipswitches, and power up again. Since all settings such as the IP address are initialized, reconfiguration is necessary.

### System Errors

The left and right digits of the 7-segment LED display “F” and an error code, respectively. The LED illuminates.

Display	Possible Problem	Corrective Action
F0	System ROM error.	Service required.
F1	SRAM error	Service required.
F2	EEPROM error	Service required.
F3	Error in the internal battery of the main module.	Service required. However, this error is also displayed immediately after the battery is replaced. If this happens, power-cycle the MW100.
F4	Ethernet controller error	Service required.
F6	Web file load error	Service required.
FF	Error in writing unit information.	Service required.

### Module Errors

The left and right digits of the 7-segment LED display are U and an error code, respectively. The LED illuminates.

In the case of module errors, the error number and the corresponding module number are displayed alternately as shown in the figure below.

Error number    Module number  
 U1 → n1

Display	Possible Problem	Corrective Action
U0	Range information error.	Service required.
U1	Calibration value error.	Check the module's installation status, then recalibrate the module. If the error occurs even after recalibrating, servicing is required.
U2	Calibration reference voltage is not correct. (during calibration)	Check whether the correct calibration reference voltage is or being applied or whether the channel to which the voltage is applied is correct.
U3	Error in writing the calibration value.	Service required.
U4	The installed module cannot be used.	Replace the module with one that can be used.

## Communication Errors

The left and right digits of the 7-segment LED display “C” and an error code, respectively. The LED blinks.

Display	Possible Problem	Corrective Action
C0	DHCP address acquisition error	Check network connections. Use a fixed IP address. Check with your network administrator whether your environment supports acquisition of addresses by DHCP.
C1	DNS name error	Check network connections. Check with your network manager to determine whether your environment supports host name registration.

## Setting Errors

The code is divided into two parts which are displayed alternately on the 7-segment LED; in the first part, the letter E appears in the left digit with the hundreds digit of the error code to the right, and the second part consists of the last two digits of the error code.

Display	Possible Problem	Corrective Action
E001	Invalid function parameter.	Enter correct parameters.
E002	Value exceeds the setting range.	Set a value within the allowable range.
E003	Incorrect real number format.	Enter the correct real number format.
E004	Real number value exceeds the setting range.	Set a real number within the allowable range.
E005	Incorrect character string.	Set an allowable character string.
E006	Character string too long.	Set a character string within the allowable length.
E007	Incorrect display color format.	Specify a display color using the correct format.
E008	Incorrect date format.	Enter the date using the correct format.
E009	Date value exceeds the setting range.	Set a date within the allowable range.
E010	Incorrect time format.	Enter the time using the correct format.
E011	Time value exceeds the setting range.	Set a time within the allowable range.
E012	Incorrect time zone format.	Specify a time zone using the correct format.
E013	Time zone value exceeds the setting range.	Set a time zone within the allowable range.
E014	Incorrect IP address format.	Enter an IP address using the correct format.
E020	Invalid channel number.	Enter the correct channel number.
E021	Invalid sequence of first and last channel.	Set a value for the last channel that is greater or equal to than the first channel.
E022	Invalid alarm number.	Enter the correct alarm number.
E023	Invalid relay number.	Enter a correct relay number.
E024	Invalid sequence of first and last relay.	Set a value for the last relay that is greater or equal to than the first relay.
E025	Invalid MATH group number.	Enter a correct MATH group number.
E026	Invalid box number.	Enter the correct box number.
E027	Invalid timer number.	Enter the correct timer number.
E028	Invalid match time number.	Enter the correct match time number.
E029	Invalid measurement group number.	Enter a correct measurement group number.
E030	Invalid module number.	Enter a correct module number.
E031	Invalid start and end time of DST.	Enter a correct start and end time.
E032	Invalid display group number.	Enter a correct display group number.
E033	Invalid tripline number.	Enter a correct tripline number.
E034	Invalid message number.	Enter a correct message number.
E035	Invalid user number.	Enter a correct user number.
E036	Invalid server type.	Enter a correct destination type.
E037	Invalid e-mail contents.	Enter valid a correct send destination.
E038	Invalid server number.	Enter a correct server number.
E039	nvalid command number.	Enter a correct command number.

## Appendix 7 Error Display on the 7-Segment LED and Corrective Actions

Display	Possible Problem	Corrective Action
E040	Invalid client type.	Enter a correct client type.
E041	Invalid server type.	Enter a correct server type.
E050	Invalid input type.	Enter an input type that can be selected for the module specified by the channel number.
E051	Module of an invalid input type found in the range of specified channels.	Enter an input type that can be selected for all modules specified by the channel range.
E052	Invalid measuring range.	Enter a measurement range that can be selected for the modules specified by the channel number.
E053	Module of an invalid measuring range found in the range of specified channels.	Enter a measurement range that can be selected for all modules specified by the channel range.
E054	Upper and lower limits of span cannot be equal.	Set a different value for the upper and lower limits of span.
E055	Upper and lower limits of scale cannot be equal.	Set a different value for the upper and lower limits of scale.
E056	Invalid reference channel number.	Set channels other than the input module's own channel.
E060	Cannot set an alarm for a skipped channel.	Set a type for the channel number setting other than SKIP.
E061	Cannot set an alarm for a channel on which MATH function is turned OFF.	Set the ON/OFF setting for expressions on the channel number to ON.
E062	Invalid alarm type.	Enter an allowed alarm type.
E063	Invalid alarm relay number.	Set a relay number for alarm output relays.
E065	Cannot set hysteresis for a channel on which alarm are turned OFF	Set the channel number alarm type to something other than OFF.
E070	Nonexistent channel specified in MATH expression.	Check whether a channel number outside of the allowable range was specified in the expression.
E071	Nonexistent constant specified in MATH expression.	Check whether a MATH constant outside of the allowable range was specified in the expression.
E072	Invalid syntax found in MATH expression.	Check whether the syntax of the expression is correct.
E073	Too many operators for MATH expression.	Reduce the number of operators.
E074	Invalid order of operators.	Check whether the relationship between the operators used in the expression satisfies proper syntax.
E075	Upper and lower limits of MATH span cannot be equal.	Set a different value for the upper and lower limits of the MATH span.
E080	Incorrect MATH group format.	Check whether the MATH group format is correct.
E081	Incorrect channels for MATH group.	Check whether there are any channels outside the allowable range specified in the MATH group.
E082	Too many channels for MATH group.	Reduce the number of channels specified in the MATH group.
E090	Incorrect break point format.	Use the correct break point format.
E091	Time value of break point exceeds the setting range.	Set a time within the allowable range.
E092	Output value of break point exceeds the setting range.	Set an output value within the allowable range.
E093	No break point found.	Set one or more break points.
E094	Invalid time value of first break point.	Set the time of break point 1 to zero.
E095	Invalid time sequence found in break points.	Set the times of break points in ascending order.
E100	Invalid output type.	Enter an output type that can be selected for the module specified by the channel number.
E101	Module of an invalid output type found in the range of specified channels.	Enter an output type that can be selected for all modules specified by the channel range.
E102	Invalid output range.	Enter an output range that can be selected for the module specified by the channel number.
E103	Module of an invalid output range found in the range of specified channels.	Enter an output type that can be selected for all modules specified by the channel range.
E104	Upper and lower limits of output span cannot be equal.	Set a different value for the upper and lower limits of output span.
E105	Invalid transmission reference channel.	Set a channel number of the input module or a MATH channel number.
E110	Invalid channel number for contact input event.	Set the channel number for the universal input module or DI module.

## Appendix 7 Error Display on the 7-Segment LED and Corrective Actions

Display	Possible Problem	Corrective Action
E111	Invalid channel number for alarm event.	Set an input module or MATH channel number.
E112	Invalid relay number for relay event.	Set the channel number for the DO module.
E113	Invalid action type.	Enter a correct action type.
E114	Invalid combination of edge and level detection actions.	Set the edge and level detection types to something different.
E115	Invalid combination of level detection actions.	Set events of different types to different actions in level detection.
E116	Invalid flag number.	Enter a correct flag number.
E120	Invalid measurement group number.	Set the measurement interval so that meas. gr 1 ≤ meas. gr 2 ≤ meas. gr 3. The maximum allowable ch for 10 ms measurement is 10, and for 50 ms, 30.
E121	Invalid measurement group number for MATH interval.	Set MATH interval to a measurement group of 100 ms or longer.
E130	Size of data file for measurement group 1 exceeds the upper limit.	Set the number of saved channels, recording interval, and recording data length so that the data file of measurement group 1 does not exceed 10 MB.
E131	Size of data file for measurement group 2 exceeds the upper limit.	Set the number of saved channels, recording interval, and recording data length so that the data file of measurement group 2 does not exceed 10 MB.
E132	Size of data file for measurement group 3 exceeds the upper limit.	Set the number of saved channels, recording interval, and recording data length so that the data file of measurement group 3 does not exceed 10 MB.
E133	Size of MATH data file exceeds the upper limit.	Set the number of saved channels, recording interval, and recording data length so that the MATH data file does not exceed 10 MB.
E134	Size of thinned data file exceeds the upper limit.	Set the number of saved channels, recording interval, and recording data length so that the thinned data file does not exceed 10 MB.
E135	Cannot set smaller value for thinning recording interval than measuring or MATH interval.	Set a value for the thinning recording interval higher than the measurement and MATH interval.
E136	Invalid combination of thinning recording, measuring and MATH interval.	Set a value for the thinning recording interval that is a common multiple of the measurement and MATH intervals.
E137	The combination of the thinning recording interval and the thinning recording data length is not correct.	Set the thinning recording data length to an integer multiple of the thinning recording interval.
E138	Cannot set recording operation for measurement group with no measuring interval.	Set the measurement interval of the measurement group number to something other than OFF.
E139	Invalid recording interval.	Set a recording interval allowed for the measurement interval of the measurement group.
E140	Upper and lower limits of the display zone cannot be equal.	Set the upper and lower limits of display zone to a different value.
E141	Cannot set smaller value than lower limit of display zone for upper limit.	Set a larger value for the upper limit than that of the lower limit.
E142	Width of display zone must be 5% of that of the entire display or more.	Set the upper and lower limits so that the difference between them is 5% or more.
E145	Incorrect display group format.	Enter a display group of the correct format.
E150	IP address must belong to class A, B, or C.	Set an IP address belonging to class A, B, or C.
E151	Net or host part of IP address is all 0's or 1's.	Set a valid combination of IP address and subnet mask.
E152	Invalid subnet mask.	Enter a setting according to your network.
E153	Invalid gateway address.	Make sure that the network part of the IP address and default gateway match.
E160	Incorrect alarm e-mail channel format.	Specify a channel using the correct format.
E165	Invalid channel number for Modbus command.	Enter a correct channel.
E166	Invalid combination of start and end channel for Modbus command.	Set a first and last channel of the same type.
E167	Invalid sequence of start and end channel for Modbus command.	Set the last channel equal or greater than the first channel.
E168	Too many channels for command number.	Set a valid number of channels for the data type.
E170	Invalid channel number for report.	Set the channel included on the input module.

## Execution Error

The code is divided into two parts which are displayed alternately on the 7-segment LED; in the first part, the letter E appears in the left digit with the hundreds digit of the error code to the right, and the second part consists of the last two digits of the error code.

Display	Possible Problem	Corrective Action
E201	Cannot execute due to different operation mode.	Confirm the operation mode.
E202	Cannot execute when in setting mode.	Change the mode before execution.
E203	Cannot execute when in measurement mode.	Change the mode before execution.
E204	Cannot change or execute during memory sampling.	Stop the save operation before executing.
E205	Cannot execute during MATH operation.	Stop the save MATH operation before executing.
E206	Cannot change or execute during MATH operation.	Stop the save MATH operation before executing.
E207	Cannot change or execute while saving/loading settings.	Execute after the settings are saved or loaded.
E209	Cannot execute while memory sample is stopped.	Change the mode before execution.
E211	No relays for communication input found.	Check installation of relays and the relay output types.
E212	Initial balance failed.	Check the settings and wiring.
E213	No channels for initial balance found.	Check the target channels.
E214	No channels for transmission output found.	Specify channels for transmission output.
E215	No channels for arbitrary output found.	Specify channels for arbitrary output.
E221	No measurement channels found.	Check the measurement module, measurement group number, measurement interval, and other settings.
E222	Invalid measurement interval.	Set the measurement interval so that: Meas. gr 1 $\leq$ meas. gr 2 $\leq$ meas. gr 3
E223	Too many measurement channels.	The number of measurable channels during 10 ms measurement is 10, and for 50 ms measurement, 30.
E224	No MATH channels found.	Check the MATH channel settings.
E225	Invalid MATH interval.	Set the MATH interval to measurement groups of 100 ms or more. When measuring with measurement modules, set the measurement group numbers on which to perform measurement.
E226	Cannot start/stop MATH operation.	Cannot execute because MATH start is set for the level detection action.
E227	Cannot start/stop recording.	Cannot execute because recording start is set for the level detection action.

## Execution Errors

The code is divided into two parts which are displayed alternately on the 7-segment LED; in the first part, the letter E appears in the left digit with the hundreds digit of the error code to the right, and the second part consists of the last two digits of the error code.

Display	Possible Problem	Corrective Action
E301	CF card error detected.	Do not eject or otherwise disturb the card while it is being accessed.
E302	No enough free space on CF card.	Delete unneeded files to free up some space. Replace the CF card.
E303	CF card is write-protected.	Check write permissions.
E311	CF card not inserted.	Insert the CF card correctly.
E312	CF card format damaged.	Check the CF card. Please reformat the CF card.
E313	CF card damaged or not formatted.	The file may be damaged. Format or replace the CF card.

## Appendix 7 Error Display on the 7-Segment LED and Corrective Actions

Display	Possible Problem	Corrective Action
E314	File is write-protected.	Check write permissions.
E315	No such file or directory.	Check the files and folders. *
E316	Number of files exceeds the upper limit.	Delete unneeded files to reduce the number of files.
E317	Invalid file or directory name.	Check the files and folders. *
E318	Unknown file type.	Check the files.
E319	Same name of file or directory already exists.	Check the files and folders. *
E320	Invalid file or directory operation.	Check the files and folders. *
E321	File is in use.	Wait until access is finished.
E331	Setting file not found.	Check the name of the setting file.
E332	Setting file is broken.	Could not load setting file because it is corrupted.
E341	FIFO buffer overflow.	You must reduce the time required to store files. Delete unneeded files to free up space.
E342	Data to be saved to file not found.	Check the settings.
E343	Power failed while opening file.	Files may have been damaged. Take appropriate action for power failure.
E344	Some or all data prior to power outage could not be recovered.	Do not change the CF card during a power failure.
E345	Could not restart recording after recovery from power failure.	Perform the record start operation.
E346	Recording could not be started due to power outage.	Perform the re-recording start operation. Take appropriate action for power failure.

\* May occur in the MW100 internal processing. (during an abnormality)

### Communication Command Error

The code is divided into two parts which are displayed alternately on the 7-segment LED; in the first part, the letter E appears in the left digit with the hundreds digit of the error code to the right, and the second part consists of the last two digits of the error code.

Display	Possible Problem	Corrective Action
E401	Command string too long.	Keep the command within 2047 characters from first character to terminator.
E402	Too many commands enumerated.	Set the number of enumerated commands within 99.
E403	Invalid type of commands enumerated.	Send the commands without enumerating them.
E404	Invalid command.	Confirm the command name.
E405	Not allowed to execute this command.	Login at a level that allows execution of this command.
E406	Cannot execute due to different operation mode.	Switch to a mode that allows execution of this command.
E407	Invalid number of parameters.	Check the number of parameters.
E408	Parameter string too long.	Keep the length of individual parameters within 512 Bytes.
E411	Daylight saving time function not available.	Not available with the current model.
E412	Temperature unit selection not available.	Not available with the current model.
E413	MATH option not available.	Not available with the current model.
E414	Serial communication interface option not available.	Not available with the current model.
E415	Report option not available.	Not available with the current model.

## Communication Error

The code is divided into two parts which are displayed alternately on the 7-segment LED; in the first part, the letter E appears in the left digit with the hundreds digit of the error code to the right, and the second part consists of the last two digits of the error code.

Display	Possible Problem	Corrective Action
E501	Login first.	First, finish logging in.
E502	Login failed, try again.	Enter the correct user name and password.
E503	Connection count exceeded the upper limit.	Close unneeded connections and reconnect.
E504	Connection has been lost.	Try to make a new connection.
E505	Connection has time out.	Try to make a new connection.
E520	FTP function not available.	Enable the function.
E521	FTP control connection failed.	Check the FTP server address and the main unit address setting. Also check the Ethernet cable connection.
E530	SMTP function not available.	Enable the function.
E531	SMTP connection failed.	Check the SMTP server address and the main unit address settings. Also check the Ethernet cable connection.
E532	POP3 connection failed.	Check the POP3 server address and the main unit address settings. Also check the Ethernet cable connection.
E550	SNTP function not available.	Enable the function.
E551	SNTP command/response failed.	Check the SNTP server address and the main unit address settings. Also check the Ethernet cable connection.

## System Errors

The code is divided into two parts which are displayed alternately on the 7-segment LED; in the first part, the letter E appears in the left digit with the hundreds digit of the error code to the right, and the second part consists of the last two digits of the error code.

Display	Possible Problem	Corrective Action
E999	System error.	Servicing required.

# Index

## A

Action Types.....	1-11
Affirmative Responses.....	2-1
AK.....	1-38
Alarm Types.....	1-9
Alarm Value Setting Range.....	1-9
AO.....	1-21
AP.....	1-22
ASCII Character Codes.....	App-8
ASCII Output.....	2-2

## B

BA.....	1-29
BD.....	1-19
Binary Data.....	2-2
Binary Output.....	2-2, 2-39
Bit Structure of Status Information.....	App-6
BL.....	1-39
BO.....	1-40
Byte Output Order.....	1-14

## C

CC.....	1-39
CE.....	1-38
CF.....	1-42
Channel Numbers.....	1-6
Channel Ranges.....	1-6
Channel Structure.....	1-10
CM.....	1-38
command	
AK.....	1-38
AO.....	1-21
AP.....	1-22
BA.....	1-29
BD.....	1-19
BL.....	1-39
BO.....	1-40
CC.....	1-39
CE.....	1-38
CF.....	1-42
CM.....	1-38
CS.....	1-40
DS.....	1-37
EC.....	1-39
EX.....	1-37
FD.....	1-40
FE.....	1-41
FF.....	1-41
FL.....	1-41
FO.....	1-40
GR.....	1-40
IR.....	1-38
IS.....	1-42
KI.....	1-38
MC.....	1-26
MD.....	1-26
ME.....	1-42
MF.....	1-39
MG.....	1-20
MH.....	1-27
ML.....	1-28
MP.....	1-37

MQ.....	1-37
MR.....	1-28
MS.....	1-37
MU.....	1-28
MV.....	1-37
MW.....	1-27
MX.....	1-28
PF.....	1-17
PS.....	1-37
PV.....	1-39
RC.....	1-38
RM.....	1-20
RO.....	1-20
RS.....	1-39
SA.....	1-18
SB.....	1-30
SC.....	1-30
SD.....	1-38
SF.....	1-17
SG.....	1-31
SI.....	1-24
SK.....	1-19
SL.....	1-22
SO.....	1-19
SP.....	1-39
SQ.....	1-24
SR.....	1-16
SS.....	1-29
ST.....	1-30
SV.....	1-29
SW.....	1-29
SX.....	1-31
SZ.....	1-30
TC.....	1-39
TL.....	1-31
UA.....	1-32
UL.....	1-36
UN.....	1-29
VA.....	1-18
VD.....	1-38
VF.....	1-42
VL.....	1-21
VM.....	1-25
WA.....	1-35
WB.....	1-35
WC.....	1-36
WD.....	1-34
WE.....	1-35
WF.....	1-35
WS.....	1-36
XA.....	1-18
XB.....	1-17
XD.....	1-19
XG.....	1-25
XI.....	1-25
XJ.....	1-17
XK.....	1-28
XR.....	1-31
XT.....	1-28
XV.....	1-25
YA.....	1-32
YC.....	1-34
YD.....	1-32
YF.....	1-33



## Index

YG	1-33
YH	1-33
YM	1-33
YN	1-33
YQ	1-36
YS	1-32
YT	1-34
YU	1-34
YV	1-33
command-response	1-2
Command Format	1-1
Command Help Output	App-11
Command Name	1-1
Communication Command Error	App-19
Communication Distance	App-1
Communication Error	App-20
Communication Errors	App-15
Communication Input Values	1-10
Control Commands	1-4, 1-37
CR + LF	1-2
CS	1-40

## D

Data Sum	2-3
DS	1-37

## E

EB<I>CRLF	2-2
EC	1-39
Error Display on the 7-Segment LED	App-14
Errors upon Startup	App-14
EX	1-37
Execution Error	App-18
Execution Errors	App-18

## F

FD	1-40
FE	1-41
FF	1-41
FIFO Read Range	2-43
FL	1-41
Flag	2-3
FO	1-40

## G

GR	1-40
----	------

## H

Header Sum	2-2
Hold Registers	App-3
Host Name and Domain Name String	1-15
Hysteresis Value Setting Range	1-9

## I

Input Registers	App-3
IR	1-38
IS	1-42

## K

KI	1-38
----	------

## L

LF	1-2
List of Commands	1-3
Login	App-11
Logout	App-12

## M

Maintenance/Diagnostic Server	App-9
Master Function/Client Function	App-2
MATH Constants	1-10
MATH Interval	1-14
MC	1-26
MD	1-26
ME	1-42
Measurement Interval	1-14
Measurement Mode	1-3
MF	1-39
MG	1-20
MH	1-27
ML	1-28
Modbus Communication Timeout	App-5
Modbus Master Timer Function	App-5
Modbus Protocol Specifications	App-2
Module Errors	App-14
MP	1-37
MQ	1-37
MR	1-28
MS	1-37
MU	1-28
Multiple Negative Response	2-2
MV	1-37
MW	1-27
MX	1-28

## O

Operation Mode	1-3, 1-4, 1-5
Output Commands	1-5, 1-40
Output Commands (RS-422A/485 Specific Commands)	1-5
Output Connection Information	App-10
Output of Alarm Summaries	2-14
Output of Communication Logs	2-16
Output of Data Acquisition Logs	2-10
Output of Decimal Place and Units	2-9
Output of DHCP Client Logs	2-20
Output of Ethernet Information	App-10
Output of FIFO Data	2-41
Output of File Information	2-38
Output of FTP Client Logs	2-17
Output of FTP Server Logs	2-23
Output of HTTP Server Logs	2-24
Output of Mail Client Logs	2-19
Output of MATH Status	2-33
Output of Media Free Space	2-38
Output of Message Summaries	2-15
Output of Modbus Client Command Status	2-30
Output of Modbus Client Connection Status	2-31
Output of Modbus Client Logs	2-30
Output of Modbus Master Command Status	2-26
Output of Modbus Master Connection Status	2-27
Output of Modbus Master Logs	2-25
Output of Modbus Server Log	2-32
Output of Modbus Slave Log	2-28
Output of Operation Error Logs	2-10
Output of Operation Logs	2-34
Output of Recording Status Logs	2-12
Output of Relay Status	2-36
Output of Setting Data	2-8

Output of Status Information.....	2-35
Output of Strain Input Initial Balancing Result.....	2-35
Output of System Recognition Status.....	2-37
Output of the Latest Measured/Computed Data.....	2-6, 2-39
Output of the Latest Output Data.....	2-7, 2-40
Output of Time Synchronization Logs.....	2-22

**P**

Parameters.....	1-1, 1-6
Password String.....	1-14
PF.....	1-17
Point Structure.....	1-10
PS.....	1-37
PV.....	1-39

**Q**

Queries.....	1-1
--------------	-----

**R**

RC.....	1-38
register assignments.....	App-3
Response.....	1-2
Response Format.....	2-1
Responses to Queries.....	2-5
RM.....	1-20
RO.....	1-20
RS.....	1-39
RS-232 Specifications.....	App-1
RS-422A/485 Specifications.....	App-1
RS-422A/485 Specific Commands/Responses.....	2-4

**S**

SA.....	1-18
SB.....	1-30
SC.....	1-30
SD.....	1-38
Serial Interface (Optional) Specifications.....	App-1
Setting Commands (Communication Related).....	1-4, 1-32
Setting Commands (Display Related).....	1-4, 1-30
Setting Commands (System Related).....	1-3, 1-16
Setting Mode.....	1-3
Settings Errors.....	App-15
SF.....	1-17
SG.....	1-31
SI.....	1-24
Single Negative Response.....	2-1
single negative response.....	2-1
SK.....	1-19
SL.....	1-22
Slave/Server Functions.....	App-2
SO.....	1-19
SP.....	1-39
Special Data Values.....	2-40, 2-42
SQ.....	1-24
SR.....	1-16
SS.....	1-29
ST.....	1-30
Sub-Delimiters.....	1-2
SV.....	1-29
SW.....	1-29
SX.....	1-31
System Errors.....	App-14
SZ.....	1-30

**T**

TC.....	1-39
Termination Resistance.....	App-1
Timeout Types.....	App-5
TL.....	1-31

**U**

UA.....	1-32
UL.....	1-36
UN.....	1-29
Upper and Lower Limit of Scaling.....	1-9
Upper and Lower Limit of Span (MATH Channels).....	1-9
Upper and Lower Limit of Span (Measurement Channels)2.....	1-6
User Specified Strings.....	1-14

**V**

VA.....	1-18
VD.....	1-38
VF.....	1-42
VL.....	1-21
VM.....	1-25

**W**

WA.....	1-35
WB.....	1-35
WC.....	1-36
WD.....	1-34
WE.....	1-35
WF.....	1-35
WS.....	1-36

**X**

XA.....	1-18
XB.....	1-17
XD.....	1-19
XG.....	1-25
XI.....	1-25
XJ.....	1-17
XK.....	1-28
XR.....	1-31
XT.....	1-28
XV.....	1-25

**Y**

YA.....	1-32
YC.....	1-34
YD.....	1-32
YF.....	1-33
YG.....	1-33
YH.....	1-33
YM.....	1-33
YN.....	1-33
YQ.....	1-36
YS.....	1-32
YT.....	1-34
YU.....	1-34
YV.....	1-33