

User's Manual

Model UP351 Program Controller with Active Color PV Display User's Manual Installation



IM 05E01D12-01E

YOKOGAWA
Yokogawa Electric Corporation

3rd Edition: Sep 30, 2004

This manual describes installation, wiring, and other tasks required to make the controller ready for operation.

Contents

1. Safety Precautions
2. Model and Suffix Codes
3. How to Install
4. How to Connect Wires
5. Hardware Specifications
6. Terminal Wiring Diagrams

Introduction

Thank you for purchasing the UP351 program controller. The controller is shipped from the factory with 5 hardcopy user's manuals (A2 and A3 size) and 1 user's manual on CD-ROM. The 5 user's manuals in hardcopy format describe the operating procedures required for basic use. It is recommended that you refer to these user's manuals to understand [1] installation, [2] initial settings, [3] program settings, and [4] operating procedures of the controller.

The CD-ROM contains an User's Manual (Reference) with descriptions of various functions and setting ranges that can be set as necessary. Moreover, the use of an optional parameter setting tool (model: LL100-E10) allows you to easily perform settings and adjustments with a PC.

How to Use the Manuals

Purpose	Manual Title	Description	Media
Setup	Installation	Describes the tasks (installation, wiring, and others) required to make the controller ready for operations.	A2-size paper, front
Basic operation	Initial Settings	Describes examples of setting PV input types, and control output types. Making settings described herein and program creation in Programming User's Manual allow you to carry out basic control.	A2-size paper, front
Program creation	Programming	Describes examples of creating basic programs. See Program Pattern Setup Charts on the back of Installation User's Manual and program functions.	A2-size paper back and front
Operating procedures and troubleshooting	Operations	Describes key operation sequences. For operation control through external contact inputs, see the back of Installation User's Manual.	A2-size paper, back
Brief operation and pinpoint recording	Parameters	Contains the parameter map used as a guideline for setting parameters and lists of parameters for recording User Settings.	A2-size paper, back and front
Basic operation of Active Color PV Display	Setting / explanation of Active Color PV Display	Describes the setting/explanation of Active Color PV Display.	A3-size paper, back and front
Detailed description of functions	User's Manual (Reference)	Explains more advanced applications than those found in the 4 hardcopy user's manuals (A2 size).	CD-ROM

1. Safety Precautions

The following symbol is indicated on the controller to ensure safe use.

CAUTION

This symbol on the controller indicates that the operator must refer to an explanation in the user's manual in order to avoid the risk of injury or death of personnel or damage to the instrument. The manual describes how the operator should exercise special care to avoid electric shock or other dangers that may result in injury or loss of life.

The following symbols are used in the hardcopy user's manuals and in the user's manual supplied on the CD-ROM.

NOTE

Indicates that operating the hardware or software in a particular manner may damage it or result in a system failure.

IMPORTANT

Draws attention to information that is essential for understanding the operation and/or features of the controller.

Exemption from Responsibility

Make sure that all of the precautions are strictly adhered to. Yokogawa Electric Corporation assumes no liability for any damage resulting from use of the instrument in contradiction to the precautions. Also, Yokogawa Electric Corporation assumes no liability to any party for any loss or damage, direct or indirect, caused by the use of any unpredictable defect of the instrument.

Regarding Protection, Safety, and Prohibition Against Unauthorized Modification

- (1) In order to protect the product and the system controlled by it against damage and ensure its safe use, make certain that all of the instructions and precautions relating to safety contained in this document are strictly adhered to. Yokogawa does not guarantee safety if products are not handled according to these instructions.
- (2) Modification of the product is strictly prohibited.

2. Model and Suffix Codes

Before using the controller, check that the model and suffix codes match your order.

Model	Suffix Code	Description
UP351		Program controller (provided with retransmission output and 15V DC loop power supply as standard)
Type	-0	Standard type
Optional functions	0 1	None With communication


Check that the following items are provided:

- Program controller (of ordered model):
- Brackets (mounting hardware): 1 pair
- Unit label:
- User's Manuals: 4 (A2 size)
- User's Manuals "Setting/Explanation of Active Color PV Display": 1 (A3 size)
- User's Manual (Reference) (CD-ROM version): 1

3. How to Install


Installation Position

Install the controller at an angle within 30° from horizontal with the front panel facing upward. Do not install it facing downward. The position of right and left sides should be horizontal.



NOTE

- To install the controller, select a location where:
 - (1) no one may accidentally touch the terminals,
 - (2) mechanical vibrations are minimal,
 - (3) corrosive gas is minimal,
 - (4) temperature can be maintained at about 23°C and the fluctuation is minimal,
 - (5) no direct radiant heat is present,
 - (6) no magnetic disturbances are caused,
 - (7) no wind blows against the terminal board (reference junction compensation element),
 - (8) no water is splashed,
 - (9) no flammable materials are around.




Never place the controller directly on flammable items or equipment. If the controller has to be installed close to flammable items or equipment, be sure to provide shielding panels all around the controller, at least 150mm away from every side; the panels should be made of either 1.43mm-thick metal-plated steel plates or 1.6mm-thick uncoated steel plates.

NOTE

Never touch the opening at the bottom of the case. It is to be used in the factory at shipping.


External Dimensions and Panel Cutout Dimensions



How to Install

CAUTION

Turn off the power to the controller before installing it on the panel because there is a possibility of electric shock.



4. How to Connect Wires


CAUTION

- 1) Before carrying out wiring, turn off the power to the controller and check that the cables to be connected are not alive with a tester or the like because there is a possibility of electric shock.
- 2) For the protection and safe use of the controller, be sure to place a circuit breaker (conforms with IEC60947, 5A, 100V or 220V AC) near the controller where the breaker can easily be operated. In addition, be sure to indicated that it is the instrument to cut the power supply of the controller.
- 3) Wiring must be carried out by personnel who have basic electrical knowledge and practical experience.


NOTE

- 1) Provide power from a single-phase instrument power supply. If there is a lot of noise in the power line, insert an insulating transformer into the primary side of the line and use a line filter (recommended part: ZAC220S-00U from TDK) on the secondary side.
- 2) As a countermeasure against noise, do not place the primary and secondary power cables close to each other.
- 3) For thermocouple input, use shielded compensating lead wires for wiring. For RTD input, use shielded wires that have low conductor resistance and cause no significant differences in resistance between the three wires. The cables to be used for wiring, terminal specifications, and recommended parts are as shown below.
- 4) Control output relays may be replaced. However, because they have a life of 100,000 times that of the resistance load, use auxiliary relays to turn on/off a load.
- 5) The use of inductance (L) loads such as auxiliary relays, motors and solenoid valves causes malfunction or relay failure; always insert a CR filter for use with alternating current or a diode for use with direct current, as a spark-removal surge suppression circuit, into the line in parallel with the load.
- 6) When there is possibility of being struck by external lightning surge, use the arrester to protect the instrument.

For DC Relay Wiring




For AC Relay Wiring



Cable Specifications and Recommended Cables

Purpose	Name and Manufacturer
Power supply, grounding, relay contact outputs	600 V PVC insulated wires, JIS C 3307, 0.9 to 2.0 mm²
Thermocouple	Shielded compensating lead wires, JIS C 1610, □×□□□□ (See Yokogawa Electric's GS 6B1U1-E.)
RTD	Shielded wires (three conductors), UL2482 (Hitachi Cable)
Other signals	Shielded wires

Recommended Terminal Lugs



Terminal Covers (Optional parts)

Target Model	Part Number	Sales Unit
UP351	T9115YD	1

5. Hardware Specifications

PV Input Signals

- Number of inputs: 1 (terminals ①-③)
- Input type: Universal input system. The input type can be selected with the software.
- Sampling period: 250 ms
- Burnout detection: Functions at TC, RTD, standard signal (0.4 to 2 V or 1 to 5 V)
Upscale, downscale, and off can be specified. For standard signal, burnout is determined to have occurred if it is 0.1 V or less.
- Input bias current: 0.05 μA (for TC or RTD b-terminal)
- Measurement current (RTD): About 0.13 mA
- Input resistance: 1 MΩ or more for thermocouple or mV input
About 1 MΩ for DC voltage input
- Allowable signal source resistance: 250 Ω or less for thermocouple or mV input
Effects of signal source resistance: 0.1 μV/Ω or less 2 kΩ or less for DC voltage input
Effects of signal source resistance: About 0.01%/100 Ω
- Allowable wiring resistance: for RTD input
Maximum 150 Ω/wire: Conductor resistance between three wires should be equal
However, 10 Ω/wire for a maximum range of -150.0 to 1500.0°C
Wire resistance effect: ±0.1°C/10 Ω
- Allowable input voltage: ±10 V DC for thermocouple, mV, or RTD input
±20 V DC for DC voltage input
- Noise rejection ratio: 40 dB (50/60 Hz) or more in normal mode 120 dB (50/60 Hz) or more in common mode
- Reference junction compensation error: ±1.0°C (15 to 35°C) ±1.5°C (0 to 15°C, 35 to 50°C)
- Applicable standards: JIS, IEC, DIN (ITS-90) for thermocouples and RTD

Loop Power Supply

- Power is supplied to a two-wire transmitter. (15 V DC; terminals ⑭-⑮)
- A resistor (10 to 250 Ω) connected between the controller and transmitter converts a current signal into a voltage signal, which is then read via the PV input terminal.
- Supply voltage: 14.5 to 18.0 V DC, max. 21 mA (provided with a protection circuit against a field short-circuit)


Retransmission Output

- Either PV, program setpoint, or control output is output. Either the retransmission output or the loop power supply can be used with terminals ⑭-⑮.

6. Terminal Wiring Diagrams

△ NOTE
Do not use unassigned terminals as relay terminals.

UP351 Standard Type (Model UP351-0)



Contact Outputs

- Purpose: PV event outputs (2) and time event output (1)
- Number of outputs: 3 points
- Relay contact rating: 240 V AC, 1 A, or 30 V DC, 1 A

Display Specifications

- PV display: 4-digit, 7-segment green or red LED display, character height of 20 mm
- Setpoint display: 4-digit, 7-segment red LED display character height of 9.3 mm
- Status indicating lamps: LEDs


Safety and EMC Standards

- Safety: Compliant with IEC/EN61010-1: 2001, approved by CSA1010, approved by UL508.
Installation category : CAT. II (IEC/EN61010, CSA1010)
Pollution degree : 2 (IEC/EN61010, CSA1010)
Measurement category : I (CAT. I : IEC/EN61010)
Rated measurement input voltage : 10V DC max.(across terminals), 300V AC max.(across ground)
Rated transient overvoltage : 1500V (Note)
Note : It is a value on the safety standard which is assumed by IEC/EN61010-1 in measurement category I, and is not the value which guarantees an apparatus performance.

CAUTION

This equipment has Measurement category I, therefore do not use the equipment for measurements within measurement categories II, III and IV.

Measurement category	Description	Remarks
I	CAT. I For measurements performed on circuits not directly connected to Mains.	
II	CAT. II For measurements performed on circuits directly connected to the low voltage installation.	Appliances, portable equipments, etc.
III	CAT. III For measurements performed in the building installation.	Distribution board, circuit breaker, etc.
IV	CAT. IV For measurements performed at the source of the low-voltage installation.	Overhead wire, cable systems, etc.



EMC standards: Complies with EN61326.

The instrument continues to operate at a measuring accuracy of within ±20% of the range during tests.

Construction, Installation, and Wiring

- Construction: Only the front panel is dust-proof and drip-proof (protection class IP55)
For side-by-side close installation the controller loses its dust-proof and drip-proof protection.
- Material: ABS resin and polycarbonate
- Case color: Black
- Weight: About 1 kg or less
- Dimensions: 96 (W) × 96 (H) × 100 (depth from panel face) mm
- Installation: Panel-mounting type. With top and bottom mounting hardware (1 each)
- Panel cutout dimensions: 92^{+0.8} (W) × 92^{+0.8} (H) mm
- Installation position: Up to 30° upward facing (not designed for facing downward)
- Wiring: M3.5 screw terminals (for signal wiring and power/ground wiring as well)

Power Supply Specifications

- Power supply: Rated voltage of 100 to 240V AC (±10%), 50/60 Hz
- Power consumption: Max. 20 VA (8.0 W max.)
- Internal fuse rating: 250 V AC, 1.6 A time-lag fuse
- Data backup: Non-volatile memory (can be written to up to 100,000 times)

- Withstanding voltage
 - Between primary terminals* and secondary terminals**:
 - At least 1500 V AC for 1 minute
 - Between primary terminals* and grounding terminal:
 - At least 1500 V AC for 1 minute
 - Between grounding terminal and secondary terminals**:
 - At least 1500 V AC for 1 minute
 - Between secondary terminals**:
 - At least 500 V AC for 1 minute
- * Primary terminals indicate power terminals and relay output terminals
- ** Secondary terminals indicate analog I/O signal, voltage pulse output, and contact input terminals
- Insulation resistance: 20 MΩ or more at 500 V DC between power terminals and grounding terminal
- Grounding resistance: Class D grounding (grounding resistance of 100 Ω or less)




Signal Isolations

- PV input terminals: Isolated from other input/output terminals. Not isolated from the internal circuit.
- 15 V DC loop power supply terminals: Not isolated from 4-20 mA analog output and voltage pulse control output. Isolated from other input/output terminals and internal circuit.
- 4-20 mA analog output terminals (for control output and retransmission): Not isolated between 4-20 mA outputs and from 15 V DC loop power supply and voltage pulse control output. Isolated from other input/output terminals and internal circuit.
- Voltage pulse control output terminals: Not isolated from 4-20 mA outputs and 15 V DC loop power supply. Isolated from other input/output terminals and internal circuit.
- Relay contact control output terminals: Isolated between contact output terminals and from other input/output terminals and internal circuit.
- Contact input terminals: Not isolated between contact input terminals and from communication terminals. Isolated from other input/output terminals and internal circuit.
- Relay contact event output terminal: Not isolated from each other; isolated from other input/output terminals and the internal circuit.
- RS-485 communication terminals: Not isolated from contact input terminals. Isolated from other input/output terminals and internal circuit.
- Power terminals: Isolated from other input/output terminals and internal circuit.
- Grounding terminals: Isolated from other input/output terminals and internal circuit.

Environmental Conditions

- Normal operating conditions:
 - Ambient temperature: 0 to 50°C (40°C or less for side-by-side close installation)
 - Temperature change rate: 10°C/h or less
 - Ambient humidity: 20 to 90% RH (no condensation allowed)
 - Magnetic field: 400 A/m or less
 - Continuous vibration at 5 to 14 Hz: Full amplitude of 1.2 mm or less
 - Continuous vibration at 14 to 150 Hz: 4.9 m/s² or less
 - Short-period vibration: 14.7 m/s², 15 seconds or less
 - Shock: 147 m/s² or less, 11 ms
 - Installation height: Height above sea level of 2000 m or less
 - Warm-up time: 30 minutes or more after power on
- Transportation and storage conditions:
 - Temperature: -25 to 70°C
 - Temperature change rate: 20°C/h or less
 - Humidity: 5 to 95% RH (no condensation allowed)
- Effects of changes in operating conditions:
 - Effects from changes in ambient temperature:
 - On voltage or thermocouple input, ±1 μV/°C or ±0.01% of F.S./°C, whichever is larger
 - On RTD input, ±0.05°C/°C (ambient temperature) or less
 - On analog output, ±0.05% of F.S./°C or less
 - Effects from power supply fluctuation (within rated voltage range)
 - On analog input, ±1 μV/10 V or ±0.01% of F.S./10 V, whichever is larger
 - On analog output, ±0.05% of F.S./10 V or less

Receiving 4-20 mA DC Current Signals with the Controller



Program Pattern Setup Charts


See "1. Overview of Program Patterns" and "2. Example of Program Pattern Setup Charts" in the **Programming User's Manual** for details on how to use the setting charts.

There are two identical charts shown below because two programs can be registered with the UP351.

Fill in the fields with bold-face borders in the order of steps 1 to 10, as shown below. Then, input these setup data items to the UP351.


1. Maximum value of PV input range: Setpoint of the setup parameter "Maximum Value of PV Input Range (RH)"
2. Minimum value of PV input range: Setpoint of the setup parameter "Minimum Value of PV Input Range (RL)"
3. PV input unit: Setpoint of the setup parameter "PV Input Unit (UNIT)"
4. Program time unit: Setpoint of the setup parameter "Program Time Unit (TMU)"
5. Segment setting method: Setpoint of the setup parameter "Segment Setting Method (SEG.T)"
6. Starting target setpoint: Setpoint of the program parameter "Starting Target Setpoint (SSP)"
7. Start code: Setpoint of the program parameter "Start Code (STC)"
8. Junction code: Setpoint of the program parameter "Junction Code (JC)"
9. Target setpoint, Segment time, PV events 1 and 2, and Time event: Setpoint of each program parameter
10. Draw the program pattern.

System name		Program time unit (TMU)	4	Starting target setpoint (SSP)	6
Program No.		Segment setting method (SEG.T)	5	Start code (STC)	7
Program name				Junction code (JC)	8
Model	UP351 -				
Serial No.					



Segment No.		1	2	3	4	5	6	7	8	9	10
Target setpoint (SP)											
Segment time (TM)											
PV event 1	Event type (AL1)										
	Event setpoint (A1)										
PV event 2	Event type (AL2)										
	Event setpoint (A2)										
Time event	On time of time event (EON)										
	Off time of time event (EOF)										

System name		Program time unit (TMU)	4	Starting target setpoint (SSP)	6
Program No.		Segment setting method (SEG.T)	5	Start code (STC)	7
Program name				Junction code (JC)	8
Model	UP351 -				
Serial No.					




Segment No.		1	2	3	4	5	6	7	8	9	10
Target setpoint (SP)											
Segment time (TM)											
PV event 1	Event type (AL1)										
	Event setpoint (A1)										
PV event 2	Event type (AL2)										
	Event setpoint (A2)										
Time event	On time of time event(EON)										
	Off time of time event(EOF)										

This manual describes examples of setting PV input types, and control output types. Carrying out settings described herein allows you to perform basic control. Refer to examples of various settings to understand how to set parameters required. Refer to "1. Parameter Map" in **Parameters User's Manual** for an easy to understand explanation of setting various parameters. If you cannot remember how to carry out an operation during setting, press the **RESET** key for more than 3 seconds. This brings you to the display (operating display) that appears at power-on. When you have finished configuring the initial settings discussed in this manual, create operation programs as explained in **Programming User's Manual**.

Contents

- Names and Functions of Front Panel Parts
- Setting PV Input Type (Setting First at Power-on)
- Changing PV Input Type
- Setting Control Output Type

1. Names and Functions of Front Panel Parts



Name of Part	Function
1. Process variable (PV) display	<ul style="list-style-type: none"> Displays PV during operation. Displays a parameter symbol when you set a parameter. Displays an error code in red if the controller fails.
2. Setpoint display	<ul style="list-style-type: none"> Displays such data items as the program setpoint and control output value (OUT), as shown below, during operation. Program setpoint Segment number for which operation is in progress Remaining segment time Program setpoint at the time of hold (shown when program operation is at a pause) Control output value Displays the setpoint of a parameter when it is configured.
3. Status indicator lamps	<ul style="list-style-type: none"> Remain lit during operation. PRG1: Program-1 operation PRG2: Program-2 operation HLD: Hold operation (lit when program operation is paused)
4. Event indicator lamps	<ul style="list-style-type: none"> Come on when PV event 1 or 2, or a time event occurs. PVE1: PV event 1 PVE2: PV event 2 TME: Time event
5. Light-loader interface	<ul style="list-style-type: none"> A communication interface for connection with an adapter cable when setting and storing parameters from a PC. Use of this interface requires an optional parameter setting tool. Used to start program operation or set a program. Operation with program pattern 1: With the operating display shown, hold down the PRG1 key for more than 2 seconds. Operation with program pattern 2: With the operating display shown, hold down the PRG2 key for more than 2 seconds.
6. PRG1 and PRG2 keys	<ul style="list-style-type: none"> Setting of program pattern 1: With the operating parameter setting display shown, press the PRG1 key to show the relevant program setting parameter. Setting of program pattern 2: With the operating parameter setting display shown, press the PRG2 key to show the relevant program setting parameter.
7. RESET key	<ul style="list-style-type: none"> Press this key for more than 2 seconds during normal operation or hold operation to stop the operation. When stopped, the controller outputs a fixed value (preset output value). The output is factory-set to 0.0% or OFF.
8. SET/ENT key	<ul style="list-style-type: none"> Used to switch or register parameters. Press this key for more than 3 seconds to alternate between the operating display and the menu for operating parameter setting display.
9. Up and Down arrow keys	<ul style="list-style-type: none"> Used to change numerical values. On setting displays for various parameters, you can change the program setpoints, and parameters values. Pressing the Up key increases a numerical value, while pressing the Down key causes it to decrease. You can hold down either key to gradually increase the speed of change.


IMPORTANT
The controller automatically returns to the display at the time of power-on (i.e., operating display) if no key is operated for at least one minute.

Factory-set Values of Main Parameters

Item	Factory-set default of standard type controller
Control output	Time proportional PID relay output (variable)
Control action	Reverse action (variable)
PID parameters	P = 5.0%, I = 240 seconds, D = 60 seconds

2. Setting PV Input Type (Setting First at Power-on)

NOTE
The controller displays the operating display when the power is turned on. However, if PV input type has not been set, "IN" appears. In this case, first use the **SET/ENT** key to display the input range code to use, then press the **UP** key to register it. Then, set the maximum value (RH) and minimum value (RL) of the PV input range (for voltage input, set the maximum value (SH) and minimum value (SL) of the PV input scale).
The controller is configured to the initial value of each parameter at the factory before shipment. First check the initial values shown in 2. Lists of Parameters, in **Parameters User's Manual** and change parameter values as necessary.



The following operating procedure describes an example of setting a K-type thermocouple (-199.9°C to 500.0°C) and a measurement range of 0.0°C to 200.0°C.

- Display screen at power-on. The parameter "IN" for setting the PV input type appears.
- Press the **UP** or **DOWN** key to display the required setpoint. The figure below is an example of the controller setting a K-type thermocouple (-199.9 to 500.0°C). See "Instrument Input Range Codes."
- Press the **UP** key once to register the required setpoint.
- Press the **UP** key once to display the parameter "UNIT" (PV input unit).
- Press the **UP** key once to display the parameter "RH" (maximum value of PV input range).
- Press the **UP** or **DOWN** key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the **UP** key once to register the setpoint.
- Press the **UP** or **DOWN** key to display the required setpoint. The figure below shows an example of setting the minimum value of PV input range to 0.0°C.
- Press the **UP** key once to register the setpoint.
- Press the **UP** key once to display the parameter "UNIT" (PV input unit).
- Press the **UP** key once to register the setpoint.
- To set the type of control output, see steps 7 and later in "4 Setting Control Output Type." To finish settings, press the **UP** key for more than 3 seconds. This returns you to the display shown at power-on (figure below).
- Press the **UP** or **DOWN** key to display the required setpoint. The figure below shows the error code for input burnout (b.o.u.t) if PV input wiring is not yet complete. The error code disappears when you wire the PV input terminals correctly.

Instrument Input Range Codes

Input	Type	Instrument Input Range Code	Instrument Input Range	Measurement Accuracy			
Unspecified		OFF	Set the data item PV Input Type "IN" to the OFF option to leave the PV input type undefined.				
K		1	-200 to 1370°C -300 to 2500°F	±0.1% of instrument range ±1 digit for temperatures equal to or higher than 0°C ±0.2% of instrument range ±1 digit for temperatures below 0°C			
		2	-199.9 to 999.9°C 0 to 2300°F				
		3	-199.9 to 500.0°C -199.9 to 999.9°F				
		4	-199.9 to 999.9°C -300 to 2300°F				
		5	-199.9 to 400.0°C -300 to 750°F				
		6	0.0 to 400.0°C -199.9 to 750.0°F				
Thermocouple		7	0 to 1800°C 32 to 3300°F	±0.15% of instrument range ±1 digit for temperatures equal to or higher than 400°C ±5% of instrument range ±1 digit for temperatures below 400°C			
		8	0 to 1700°C 32 to 3100°F				
		9	0 to 1700°C 32 to 3100°F				
		10	-200 to 1300°C -300 to 2400°F				
		11	-199.9 to 999.9°C -300 to 1800°F				
		L(DIN)	12		-199.9 to 900.0°C -300 to 1300°F	±0.1% of instrument range ±1 digit for temperatures equal to or higher than 0°C	
		U(DIN)	13		-199.9 to 400.0°C -300 to 750°F		
		RTD			14	0.0 to 400.0°C -199.9 to 750.0°F	±0.1% of instrument range ±1 digit ±0.25% of instrument range ±1 digit for temperatures below 0°C
					15	0 to 2300°C 32 to 4200°F	
					16	0 to 1390°C 32 to 2500°F	
17	0 to 1900°C 32 to 3400°F						
18	0 to 2000°C 32 to 3600°F						
19	-199.9 to 999.9°C -199.9 to 999.9°F			±0.1% of instrument range ±1 digit (Note1) (Note2)			
20	-150.0 to 150.0°C -199.9 to 300.0°F						
21	-199.9 to 850.0°C -300 to 1560°F			±0.1% of instrument range ±1 digit (Note1) (Note2)			
22	-199.9 to 500.0°C -199.9 to 999.9°F						
23	-150.0 to 150.0°C -199.9 to 300.0°F			±0.2% of instrument range ±1 digit (Note1)			
24	0.4 to 2 V 1 to 5 V 0 to 2 V 0 to 10 V -10 to 20 mV 0 to 100 mV						
Standard signal				40	0.400 to 2.000 V	±0.1% of instrument range ±1 digit (Note)	
				41	1.000 to 5.000 V		
DC voltage				50	0.000 to 2.000 V	The read-out range can be scaled between -1999 and 9999.	
		51	0.00 to 10.00 V				
		55	-10.00 to 20.00 mV				
		56	0.0 to 100.0 mV				

* Performance in the standard operating condition (at 23±2°C, 55±10%RH, and 50/60 Hz power frequency)
Note1: The accuracy is ±0.3°C of instrument range ±1 digit for a temperature range from 0°C to 100°C.
Note2: The accuracy is ±0.5°C of instrument range ±1 digit for a temperature ranges from -100°C to 0°C and 100°C to 200°C.
* To receive a 4-20 mA DC signal, select a standard signal of 1 to 5 V DC and connect it to a 250Ω resistor. This resistor is optional.
Model: X010-250-2 (resistor with M3.5 crimp-on terminal lugs)

NOTE
The controller may automatically initialize the registered operating parameter setpoints if any change is made to the data item PV Input Type (IN), Maximum Value of PV Input Range (RH), Minimum Value of PV Input Range (RL), PV Input Decimal Point Position (SDP), Maximum Value of PV Input Scale (SH) or Minimum Value of PV Input Scale (SL). After a change has been made to any of these data items, be sure to verify the registered operating parameter setpoints to ensure that they are correct. If any data item has been changed to its default, set it to a required value.

3. Changing PV Input Type

The following operating procedure describes an example of changing the setting of K-type thermocouple (-199.9 to 500.0°C) to RTD Pt100 (-199.9 to 500.0°C) and a measurement range of 0.0 to 200.0°C.

- Bring the operating display into view (display appears at power on).
- Press the **UP** key for more than 3 seconds to call up the menu "OP.PA".
- Press the **UP** key once to display the menu "STUP".
- Press the **UP** key once to display the parameter "PWD".
- Press the **UP** key once to display the menu "FUNC".
- Press the **UP** key once to display the menu "I/O".
- Press the **UP** key once to display the parameter "STUP".
- Press the **UP** key once to display the menu "IN" (PV input type).
- Press the **UP** or **DOWN** key to display the required setpoint. The figure below shows an example of changing to RTD Pt100 (-199.9 to 500.0°C).
- Press the **UP** key once to display the menu "I/O".
- Press the **UP** key once to display the menu "STUP".
- Press the **UP** key once to display the parameter "IN" (PV input type).
- Press the **UP** or **DOWN** key to display the required setpoint. The figure below shows an example of changing to RTD Pt100 (-199.9 to 500.0°C).

- Press the **UP** key once to register the setpoint.
- Press the **UP** key once to display the parameter "UNIT" (PV input unit).
- Press the **UP** key once to display the parameter "RH" (maximum value of PV input range).
- Press the **UP** or **DOWN** key to display the required setpoint. The figure below shows an example of setting the maximum value of PV input range to 200.0°C.
- Press the **UP** key once to register the setpoint.
- Press the **UP** key for more than 3 seconds. This returns you to the display shown at power-on (figure below).
- Press the **UP** key once to register the setpoint.
- * If the type of input is voltage, also configure the PV Input Decimal Point Position (SDP), Maximum Value of PV Input Scale (SH) and Minimum Value of PV Input Scale (SL) parameters that are displayed after parameter RL.

4. Setting Control Output Type

The following operating procedure describes an example of changing time proportional PID relay (0) on-off(3) output to current output (2).
Control output terminal Values in parentheses are setpoints
Time proportional PID relay (0) on-off(3) output..... ①-②-③
Current (2) time proportional PID voltage pulse (1) output..... ④-⑤

- Bring the operating display into view (display appears at power-on).
- Press the **UP** key for more than 3 seconds to call up the menu "OP.PA".
- Press the **UP** key once to display the menu "STUP".
- Press the **UP** key once to display the parameter "PWD".
- Press the **UP** key once to display the menu "FUNC".
- Press the **UP** key several times to display the parameter "OT" (control output type).
- Press the **UP** or **DOWN** key to display the required setpoint. The figure below shows an example of setting to current output (4 to 20 mA DC).
- Press the **UP** key once to register the setpoint.
- Press the **UP** key once to display the menu "FUNC".
- Press the **UP** key for more than 3 seconds. This returns you to the display shown at power-on (figure below).

List of Control Output Types

Parameter Symbol	Parameter Name	Setpoint	Control Output Type
ot (OT)	Control output type	0	Time proportional PID relay contact output (terminals ①-②-③)
		1	Time proportional PID voltage pulse output (terminals ④-⑤)
		2	Current output (terminals ⑥-⑦)
		3	On-off control relay contact output (terminals ①-②-③)

This manual describes key entries for operating the controller. For operations using external contact inputs, see "6. Terminal Wiring Diagrams," in **Installation User's Manual**. If you cannot remember how to carry out an operation during setting, press the **RESET** key for more than 3 seconds. This brings you to the display (operating display) that appears at power-on.

Contents

1. Performing/Canceling Auto-tuning
2. Setting PID Manually
3. Starting (PRG)/Stopping (RESET) the Controller
4. Enabling/Disabling Hold Mode of Program Operation
5. Changing Program Setpoints when in Hold Mode
6. Executing "Advance" Function
7. Troubleshooting

NOTE
 Do not use the instrument generating strong magnetic field such as radio equipment and the like near the controller. This may cause the fluctuation of the PV value.

1. Performing/Canceling Auto-tuning

Perform auto-tuning when you have finished creating program patterns. Make sure the controller is in Run state (PRG) before carrying out auto-tuning. See "3. Starting (PRG)/Stopping (RESET) the Controller," to change to PRG. PID constants are obtained by using the current program setpoint value at the start of auto-tuning.

NOTE
 When on-off control is being used, auto-tuning cannot be carried out. Moreover, do not perform auto-tuning when controlling any of the following processes.

- Control processes with quick response such as flow control or pressure control
- Processes where even temporary output on/off results in inconvenience
- Processes where a large output change at control element results in inconvenience
- Processes where variations in PV may exceed an allowable range, adversely affecting product quality

1. Bring the operating display into view (display appears at power on).
2. Press the **1** key for more than 3 seconds to call up the menu "OP.PA".
3. Press the **1** key several times to display the parameter "AT".
4. Press the **1** or **2** key to display the required setpoint. Set "AT = 1" to perform auto-tuning for the first group of PID constants.
5. Press the **1** key once to register the setpoint. (This starts auto-tuning.)
6. During auto-tuning, the panel indications become as shown below.

To cancel auto-tuning, set AT = OFF.

Auto-tuning is complete when the PRG2 lamp goes out.

2. Setting PID Manually

If you know the values to be set or if suitable PID constants cannot be obtained by auto-tuning, follow the procedure below to set values.


1. Bring the operating display into view (display appears at power on).
2. Press the **1** key for more than 3 seconds to call up the menu "OP.PA".
3. Press the **1** key several times to display the parameter "PID".
4. Press the **1** key once to display "1.P".
5. Press the **1** key once to register the setpoints.
6. Press the **1** key once to display the parameter "1.P".

7. Press the **1** or **2** key to display the required setpoint.
8. Press the **1** key once to register the setpoint.
9. Press the **1** key for more than 3 seconds. This returns you to the display shown at power-on (figure below).

The same steps can be used for integral time (1.I) and derivative time (1.D) that are displayed after this.

[TIP]
 The PID parameter numbers set in step 4, should be set as follows:
 In case of PID group 1, PID = 1Gr
 In case of PID group 2, PID = 2Gr
 In case of PID group 3, PID = 3Gr
 In case of PID group 4, PID = 4Gr

Diagram of Operating State Transition



3. Starting (PRG)/Stopping (RESET) the Controller

The following operating procedure starts program operation.

1. Bring the operating display into view (appears at power-on).
2. Press the **1** key for more than 2 seconds to start program pattern 1.
3. To stop program operation, press the **RESET** key for more than 2 seconds.

Press **1** key for 2 seconds. Program pattern 1 starts running.
 Press **2** key for 2 seconds. Program pattern 2 starts running.

When in the RESET state, the controller provides the following input/output values.

PV input	Value of process variable
Control output	Preset output value (factory-set to 0%)
Event output	OFF

4. Enabling/Disabling Hold Mode of Program Operation

The following operating procedure brings program pattern 1 into a pause during operation. This procedure also applies to program pattern 2.

NOTE
 If a contact input is on (hold mode is set) when the hold mode is enabled and disabled with the input, the mode cannot be cancelled by key operation.

1. Bring the operating display into view (appears at power-on).
2. Press the **1** key for more than 3 seconds to call up the menu "OP.PA".
3. Press the **1** key three times to display the parameter "HOLD".
4. Press the **1** key once to display "1".
5. Press the **1** key once to register the setpoint. The HLD lamp ON and the controller under program operation comes to a pause.

To cancel the hold mode, set as "HOLD = 0".

The controller automatically returns to the display shown at power-on (figure below).

HOLD state
 PV display: Displays the PV input value.
 SP display: Displays the setpoint of a program that is paused.
 LED lamps: The HLD lamp ON.
 Control output: Provides a value based on computation.

If you have cancelled the hold mode, press the **1** key for more than 3 seconds to return to the display shown at power-on.

5. Changing Program Setpoints when in Hold Mode

The following operating procedure changes program setpoints when program operation is put in hold mode. Before changing program setpoints, enable the hold mode of program operation as instructed in "4. Enabling/Disabling the Hold Mode of Program Operation." When you have finished changing the setpoints, cancel the hold mode. The controller continues program operation using the new setpoints. Note however, that the new setpoints are not incorporated in any previously created program pattern.

NOTE
 Program setpoints that can be changed during the hold mode are limited only to those of a soak segment (i.e., a segment with invariable program setpoints). It is not possible to change the program setpoints of any ramp segment (a segment whose program setpoints vary with time).

1. Bring the Hold-mode operating display into view (appears at power-on).
2. Press the **1** key twice to display HOLD SP display.
3. Press the **1** or **2** key to display the required setpoint.
4. Press the **1** key once to register the setpoint.

6. Executing "Advance" Function

The following operating procedure advances a segment or segments during program operation.


1. Bring the operating display into view (appears at power-on).
2. Press the **1** key for more than 3 seconds to call up the menu "OP.PA".
3. Press the **1** key twice to display the parameter "ADV".
4. Press the **1** key once to display "1".
5. Press the **1** key once to register the setpoint.

The controller automatically returns to the display shown at power-on (figure below).

7. Troubleshooting

Troubleshooting Flow

If the operating display does not appear after turning on the controller's power, follow the measures in the procedure below. If a problem appears complicated, contact our sales representative.



IMPORTANT

Take note of the parameter settings when asking the vendor for repair.

Errors at Power On

The following table shows errors that may be detected by the fault diagnosis function when the power is turned on.

Error indication (on PV display unit)	Description of error	PV	Control output	Alarm output	Retransmission output	Communication	Remedy
E000 (E000)	Faulty RAM	None	0% or less or OFF	OFF	0% or less	Stopped	Faulty Contact us for repair.
E001 (E001)	Faulty ROM	0%	Normal action (out of accuracy)	Normal action (out of accuracy)	Normal action (out of accuracy)	Normal action	
E002 (E002)	System data error	0%	Normal action (out of accuracy)	Normal action (out of accuracy)	Normal action (out of accuracy)	Normal action	
PV decimal point blinks.	Faulty calibration value	Normal action (out of accuracy)	Normal action (out of accuracy)	Normal action (out of accuracy)	Normal action (out of accuracy)	Normal action	Check and set the parameters, as they have been set to the limited values.
E400 (E400)	Parameter error	0%	Preset value	OFF	0%	0%	

Possible Errors during Operation

The following shows possible errors occurring during operations.

Error indication (on PV display unit)	Description of error	PV	Control output	Event output	Retransmission output	Communication	Remedy
Displays "RJC" and PV alternately	RJC error	Measured with RJC-OFF	Normal action	Normal action	Normal action	Normal action	Faulty Contact us for repair.
PV value blinks	EEPROM error	Normal action	Normal action	Normal action	Normal action	Normal action	Faulty Contact us for repair.
E300 (E300)	A/D error	105%	Preset value	Normal action	Normal action	Normal action	
boUt (B.OUT)	PV burnout error	Dependent on the BSL parameter Up-scale: 105% Down-scale: -5%	Preset value	Normal action	Normal action	Normal action	Check wires and sensor.
oBr (OVER) or -oBr (-OVER)	Excessive PV	-5% or 105%	Normal action	Normal action	Normal action	Normal action	Check process.
E200 (E200)	Auto-tuning failure (Time-out)	Normal action	Normal action	Normal action	Normal action	Normal action	Check process. Press any key to erase error indication.
Decimal point on setpoint display blinks.	Faulty communication line	Normal action	Normal action	Normal action	Normal action	Normal action	Check wires and communication parameters, and make resetting. Recovery at normal receipt
All indications off	Runaway (due to defective power or noise)	None	0% or less or OFF	OFF	0% or less	Stopped	Faulty if power off/on does not reset start the unit. Contact us for repair.
All indications off	Power off	None	0%	OFF	0%	Stopped	Check for abnormal power.

If a Power Failure Occurs during Operation

- Momentary power failures shorter than 20 ms
 The controller is not affected at all and continues normal operation.
- Power failures of 20 ms or longer
 • Setting parameters that have already been configured retain their settings.
 • Auto-tuning is cancelled.
 • After recovery from a power failure, program operation is stopped. The control output begins with the preset output value.
 • Event output is OFF.

This manual explains how to create programs by citing specific examples. Create user programs by referring to the given programming examples. Programming is not possible when the controller is set in Run mode (PRG). Place the controller in Stop (RESET) mode before you start programming.
Be sure to carry out the settings instructed in **Initial Settings User's Manual** before beginning any of the tasks discussed in this manual.

Contents

1. Overview of Program Patterns
2. Example of Program Pattern Setup Charts
3. Creating Program patterns
4. Changing Program Patterns
5. Lists of Program Parameters
6. Explanation of Program Functions

1. Overview of Program Patterns


■ Programming Overview

The programming example given here demonstrates how to do the tasks outlined below.

1. Program the controller to start program operation at 25°C and raise the temperature up to 80°C in 20 minutes.
2. When the temperature reaches 80°C, keep it at this level for 80 minutes.
3. Finally, lower the temperature to 0°C in 10 minutes.

Event output

- Set a deviation of 5°C on both the positive and negative sides of a program setpoint to let the controller output an event signal if the temperature goes beyond the deviation range.
- Let the controller output an event signal when the temperature stabilizes to 80°C.



2. Example of Program Pattern Setup Charts

Complete the following setup chart before setting programs in the controller. Filling in the chart makes it easier for you to input program data into the controller. See the back of **Installation User's Manual** for more details. In the following chart, fill in the fields with bold-face borders.

1. Maximum value of PV input range: Setpoint of the "Maximum Value of PV Input Range (RH)" setup parameter
2. Minimum value of PV input range: Setpoint of the "Minimum Value of PV Input Range (RL)" setup parameter
3. PV input unit: Setpoint of the "PV Input Unit (UNIT)" setup parameter
4. Program time unit: Setpoint of the "Program Time Unit (TMU)" setup parameter
5. Segment setting method: Setpoint of the "Segment Setting Method (SEG.T)" setup parameter
6. Starting target setpoint: Setpoint of the "Starting Target Setpoint (SSP)" program parameter
7. Start code: Setpoint of the "Start Code (STC)" program parameter
8. Junction code: Setpoint of the "Junction Code (JC)" program parameter
9. Target setpoint, Segment time, PV events 1 and 2, and Time event: Setpoint of each program parameter
10. Draw the program pattern.

Example of Chart Entries

Program time unit (TMU)	4	Hour, minute
Segment setting method (SEG.T)	5	Time setting
Starting target setpoint (SSP)	25.0°C	
Start code (STC)	7	0
Junction code (JC)	8	0

Unit	3	°C
Maximum value of PV input range (RH)	100%	
Minimum value of PV input range (RL)	0%	

Segment No.	1	2	3	4	5	6	7	8	9	10
Target setpoint (SP)	80.0°C	80.0°C	0.0°C	Not used in this example						
Segment time (TM)	20 min	1 hr and 20 min	10 min	Not used in this example						
Event type (AL1)	Deviation upper/lower-limit alarm (setpoint: "7")									
Event setpoint (A1)	Deviation bandwidth (setpoint: 5°C)									
Event type (AL2)	Not used in this example									
Event setpoint (A2)	Not used in this example									
Time event	ON	Not used in this example								
On time of time event (EON)	The event output turns on 20 minutes after the start of program operation. (setpoint: "20 min")									
Off time of time event (EOFF)	The event output turns off 100 minutes after the start of program operation. (setpoint: "1 hr and 40 min")									

3. Creating Program Patterns

The following operating procedure describes an example of creating the program discussed in "1. Overview of Program Patterns."

NOTE

Before creating the program, verify the Maximum Value of PV Input Range (RH), Minimum Value of PV Input Range (RL), Program Time Unit (TMU), and Segment Setting Method (SEG.T) parameters.
If the setting of the setup parameter "SEG.T" is changed, the program patterns created and stored so far will be all cleared (Initialized) !! Be careful.


The programming example given in this manual includes the following steps.
Steps 4 to 9 configure the PV Event 1 parameter (i.e., a procedure for outputting an alarm if the temperature goes beyond the range "program setpoint ±5°C".)
Step 10 configures the PV Event 2 parameter (not configured here).
Steps 11 to 13 configure the On time of Time Event (1.EON) parameter.
Steps 14 to 16 configure the Off Time of Time Event (1.EOF) parameter.
Steps 17 to 19 configure the Starting Target Setpoint (1.SSP) parameter.
Step 20 configures the Start Code (1.STC) parameter (not configured here).
Steps 21 to 23 configure the Segment-1 Target Setpoint (1.SP1) parameter.
Steps 24 to 26 configure the Segment-1 Segment Time (1.TM1) parameter.
Step 27 configures the Segment-2 Target Setpoint (1.SP2) parameter.
Steps 28 to 30 configure the Segment-2 Segment Time (1.TM2) parameter.
Steps 31 to 33 configure the Segment-3 Target Setpoint (1.SP3) parameter.
Steps 34 to 36 configure the Segment-3 Segment Time (1.TM3) parameter.

1. Bring the operating display into view (appears at power-on). 	10. Press the [F] key once to display the parameter "1.AL2". The setpoint of this parameter is not changed in this example.
2. Press the [F] key for more than 3 seconds to call up the menu "OP.PA". 	11. Press the [F] key once to display the parameter "1.EON".
3. Press the [F] key once to display the parameter "LL". 	12. Press the [F] or [V] key to display the required setpoint. The figure below shows an example of the parameter set to "20 min".
4. Press the [F] key once to display the parameter "1.AL1". 	13. Press the [F] key once to register the setpoint.
5. Press the [F] or [V] key to display the required setpoint. The figure below shows an example of the parameter set to "Deviation high and low limit Alarm" (setpoint 7). 	14. Press the [F] or [V] key to display the parameter "1.EOF".
6. Press the [F] key once to register the setpoint. 	15. Press the [F] or [V] key to display the required setpoint. The figure below shows an example of the parameter set to "1 hr and 40 min".
7. Press the [F] key once to display the parameter "1.A1". 	16. Press the [F] key once to register the setpoint.
8. Press the [F] or [V] key to display the required setpoint. The figure below shows an example of the parameter set to "5.0°C". 	17. Press the [F] key once to display the parameter "1.SSP".
9. Press the [F] key once to register the setpoint. 	18. Press the [F] or [V] key to display the required setpoint. The figure below shows an example of the parameter set to "25.0°C".

19. Press the [F] key once to register the setpoint. 	29. Press the [F] key once to register the setpoint.
20. Press the [F] key once to display the parameter "1.STC". 	30. Press the [F] key once to display the parameter "1.TM2".
21. Press the [F] key once to display the parameter "1.SP1". 	31. Press the [F] or [V] key to display the required setpoint. The figure below shows an example of the parameter set to "1 hr and 20 min".
22. Press the [F] or [V] key to display the required setpoint. The figure below shows an example of the parameter set to "80.0°C". 	32. Press the [F] key once to register the setpoint.
23. Press the [F] key once to register the setpoint. 	33. Press the [F] key once to display the parameter "1.SP3". The setpoint of this parameter is not changed in this example.
24. Press the [F] key once to display the parameter "1.TM1". 	34. Press the [F] key once to display the parameter "1.TM3".
25. Press the [F] or [V] key to display the required setpoint. The figure below shows an example of the parameter set to "20 min" (0.20). 	35. Press the [F] or [V] key to display the required setpoint. The figure below shows an example of the parameter set to "10 min" (0.10).
26. Press the [F] key once to register the setpoint. 	36. Press the [F] key once to register the setpoint.
27. Press the [F] key once to display the parameter "1.SP2". 	37. Now programming is complete. Press the [F] key for more than 3 seconds. This returns you to the display shown at power-on (figure below).

4. Changing Program Patterns

The following operating procedure describes an example of changing the program pattern created in "3. Creating Program Patterns," as shown in the figure below.



■ Details of the Change

- Before change: Program operation begins with the starting target setpoint (1.SSP).
After change: Program operation begins with the current PV value. The time setpoints of segment 1 precede others.
- Before change: The program parameter Segment-2 Target (1.SP2) was set to "80.0°C".
After change: The Segment-2 Target Setpoint (1.SP2) program parameter is set to "90.0°C".

1. Bring the operating display into view (appears at power-on). 	7. Press the [F] key once to register the setpoint.
2. Press the [F] key for more than 3 seconds to call up the menu "OP.PA". 	8. Press the [F] key several times to display the parameter "1.SP2".
3. Press the [F] key once to display the parameter "LL". 	9. Press the [F] or [V] key to display the required setpoint. The figure below shows an example of the parameter set to "90.0°C".
4. Press the [F] key once to display the parameter "1.AL1". 	10. Press the [F] key once to register the setpoint.
5. Press the [F] key several times to display the parameter "1.STC". 	11. Changing the program is now complete. Press the [F] key for more than 3 seconds. This returns you to the display shown at power-on (figure below).
6. Press the [F] or [V] key to display the required setpoint. The figure below shows an example of the parameter set to "2" (time-prioritized PV start). 	

5. Lists of Program Parameters

● Program-1 Parameters

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM							
IRL1 (1.AL1)	PV event-1 type	OFF, 1 to 10 1: PV high limit (energized, no stand-by action) 2: PV low limit (energized, no stand-by action) 3: Deviation high limit (energized, no stand-by action) 4: Deviation low limit (energized, no stand-by action) 5: Deviation high limit (de-energized, no stand-by action) 6: Deviation low limit (de-energized, no stand-by action) 7: Deviation high and low limits (energized, no stand-by action) 8: Deviation within high and low limits (energized, no stand-by action) 9: PV high limit (de-energized, no stand-by action) 10: PV low limit (de-energized, no stand-by action)	OFF									
		IR1 (1.A1)	PV event-1 setpoint PV alarm: -100.0 to 100.0% of PV input range Deviation alarm: -100.0 to 100.0% of PV input range span Use the "HY1" setup parameter to set the hysteresis of PV event 1.	PV high limit: 0.0% of PV input range Deviation alarm: 0.0% of PV input range span. Other PV alarms: 0.0% of PV input range.								
		IRL2 (1.AL2)	PV event-2 type	OFF, 1 to 10 1: PV high limit (energized, no stand-by action) 2: PV low limit (energized, no stand-by action) 3: Deviation high limit (energized, no stand-by action) 4: Deviation low limit (energized, no stand-by action) 5: Deviation high limit (de-energized, no stand-by action) 6: Deviation low limit (de-energized, no stand-by action) 7: Deviation high and low limits (energized, no stand-by action) 8: Deviation within high and low limits (energized, no stand-by action) 9: PV high limit (de-energized, no stand-by action) 10: PV low limit (de-energized, no stand-by action)	OFF		Ref.3.4(5)					
				IR2 (1.A2)	PV event-2 setpoint PV alarm: -100.0 to 100.0% of PV input range Deviation alarm: -100.0 to 100.0% of PV input range span Use the "HY2" setup parameter to set the hysteresis of PV event 2.	PV high limit: 0.0% of PV input range Deviation alarm: 0.0% of PV input range span. Other PV alarms: 0.0% of PV input range.						
				IRLON (1.EON)	On time of Time Event	OFF, 0.00 to 99.59 (hour and minute or minute and second) Use the TMU setup parameter to set the time unit. The time unit is the same as that of the program.	OFF					
						IRLOF (1.EOF)	Off time of Time Event OFF, 0.00 to 99.59 (hour and minute or minute and second) Use the TMU setup parameter to set the time unit. The time unit is the same as that of the program.	OFF		Ref.3.4(6)		
						ISSP (1.SSP)	Starting target setpoint 0.0 to 100.0% of PV input range	0.0% of PV input range				
						ISL (1.STC)	Start code	0: Operation begins with the starting target setpoint (1.SSP). 1: Ramp-prioritized PV start 2: Time-prioritized PV start	0		Ref.5.2(1)	
								ISP1 (1.SP1)	Segment-1 target setpoint	0.0 to 100.0% of PV input range	0.0% of PV input range	
										ITn1 (1.TM1)	Segment-1 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min) Use the TMU setup parameter to set the time unit. The "hour and minute" option in ramp setting means "per hour" and the "minute and second" option means "per minute."
ISP2 (1.SP2)	Segment-2 target setpoint							0.0 to 100.0% of PV input range	0.0% of PV input range			
								ITn2 (1.TM2)	Segment-2 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF	
ISP3 (1.SP3)	Segment-3 target setpoint	0.0 to 100.0% of PV input range	0.0% of PV input range									
		ITn3 (1.TM3)	Segment-3 segment time					OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF			
ISP4 (1.SP4)	Segment-4 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITn4 (1.TM4)	Segment-4 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF							
ISP5 (1.SP5)	Segment-5 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITn5 (1.TM5)	Segment-5 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF	Ref.5.1(1)						
ISP6 (1.SP6)	Segment-6 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITn6 (1.TM6)	Segment-6 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF							
ISP7 (1.SP7)	Segment-7 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITn7 (1.TM7)	Segment-7 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF							
ISP8 (1.SP8)	Segment-8 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITn8 (1.TM8)	Segment-8 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF							
ISP9 (1.SP9)	Segment-9 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITn9 (1.TM9)	Segment-9 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF							
ISPA (1.SPA)	Segment-10 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITnA (1.TMA)	Segment-10 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF							
WJC (1.JC)	Junction code 0: End of resetting 1: End of hold 2: Pattern 1 startup 3: Pattern 2 startup			0		Ref.5.2(3)						

* Parameters relating to PV or program setpoints should all be set in real numbers. For example, use temperature values to define program setpoints and PV event setpoints for temperature input.

* The "User Setting" column in the table below is provided for the customer to record setpoints.
* The "Target Item in CD-ROM" column in the table below provides references from User's Manual (Reference) (CD-ROM version) which describes items in more detail and items that are not contained in this manual.

● Program-2 Parameters

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM							
IRL1 (2.AL1)	PV event-1 type	OFF, 1 to 10 1: PV high limit (energized, no stand-by action) 2: PV low limit (energized, no stand-by action) 3: Deviation high limit (energized, no stand-by action) 4: Deviation low limit (energized, no stand-by action) 5: Deviation high limit (de-energized, no stand-by action) 6: Deviation low limit (de-energized, no stand-by action) 7: Deviation high and low limits (energized, no stand-by action) 8: Deviation within high and low limits (energized, no stand-by action) 9: PV high limit (de-energized, no stand-by action) 10: PV low limit (de-energized, no stand-by action)	OFF									
		IR2 (2.A1)	PV event-1 setpoint PV alarm: -100.0 to 100.0% of PV input range Deviation alarm: -100.0 to 100.0% of PV input range span Use the "HY1" setup parameter to set the hysteresis of PV event 1.	PV high limit: 0.0% of PV input range Deviation alarm: 0.0% of PV input range span. Other PV alarms: 0.0% of PV input range.								
		IRL2 (2.AL2)	PV event-2 type	OFF, 1 to 10 1: PV high limit (energized, no stand-by action) 2: PV low limit (energized, no stand-by action) 3: Deviation high limit (energized, no stand-by action) 4: Deviation low limit (energized, no stand-by action) 5: Deviation high limit (de-energized, no stand-by action) 6: Deviation low limit (de-energized, no stand-by action) 7: Deviation high and low limits (energized, no stand-by action) 8: Deviation within high and low limits (energized, no stand-by action) 9: PV high limit (de-energized, no stand-by action) 10: PV low limit (de-energized, no stand-by action)	OFF		Ref.3.4(5)					
				IR2 (2.A2)	PV event-2 setpoint PV alarm: -100.0 to 100.0% of PV input range Deviation alarm: -100.0 to 100.0% of PV input range span Use the "HY2" setup parameter to set the hysteresis of PV event 2.	PV high limit: 0.0% of PV input range Deviation alarm: 0.0% of PV input range span. Other PV alarms: 0.0% of PV input range.						
				IRLON (2.EON)	On time of Time Event	OFF, 0.00 to 99.59 (hour and minute or minute and second) Use the TMU setup parameter to set the time unit. The time unit is the same as that of the program.	OFF					
						IRLOF (2.EOF)	Off time of Time Event OFF, 0.00 to 99.59 (hour and minute or minute and second) Use the setup parameter TMU to set the time unit. The time unit is the same as that of the program.	OFF		Ref.3.4(6)		
						ISSP (2.SSP)	Starting target setpoint 0.0 to 100.0% of PV input range	0.0% of PV input range				
						ISL (2.STC)	Start code	0: Operation begins with the starting target setpoint (2.SSP). 1: Ramp-prioritized PV start 2: Time-prioritized PV start	0		Ref.5.2(1)	
								ISP1 (2.SP1)	Segment-1 target setpoint	0.0 to 100.0% of PV input range	0.0% of PV input range	
										ITn1 (2.TM1)	Segment-1 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min) Use the TMU setup parameter to set the time unit. The "hour and minute" option in ramp setting means "per hour" and the "minute and second" option means "per minute."
ISP2 (2.SP2)	Segment-2 target setpoint							0.0 to 100.0% of PV input range	0.0% of PV input range			
								ITn2 (2.TM2)	Segment-2 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF	
ISP3 (2.SP3)	Segment-3 target setpoint	0.0 to 100.0% of PV input range	0.0% of PV input range									
		ITn3 (2.TM3)	Segment-3 segment time					OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF			
ISP4 (2.SP4)	Segment-4 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITn4 (2.TM4)	Segment-4 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF							
ISP5 (2.SP5)	Segment-5 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITn5 (2.TM5)	Segment-5 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF	Ref.5.1(1)						
ISP6 (2.SP6)	Segment-6 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITn6 (2.TM6)	Segment-6 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF							
ISP7 (2.SP7)	Segment-7 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITn7 (2.TM7)	Segment-7 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF							
ISP8 (2.SP8)	Segment-8 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITn8 (2.TM8)	Segment-8 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF							
ISP9 (2.SP9)	Segment-9 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITn9 (2.TM9)	Segment-9 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF							
ISPA (2.SPA)	Segment-10 target setpoint			0.0 to 100.0% of PV input range	0.0% of PV input range							
		ITnA (2.TMA)	Segment-10 segment time	OFF, 0.00 to 99.59 (hour and minute or minute and second) Ramp setting: OFF, 0.0 to 100.0% of PV input range span (1 hr or 1 min)	OFF							
WJC (2.JC)	Junction code 0: End of resetting 1: End of hold 2: Pattern 1 startup 3: Pattern 2 startup			0		Ref.5.2(3)						

6. Explanation of Program Functions

■ Programming

You can create programs using either method 1 or 2 described below. The controller is factory-set to "method 1". To create programs using method 2, change the setpoint of the SEG.T (Segment Setting Method) setup parameter to "1". Before you begin programming, determine whether your programs are created using the time unit of "hour and minute" or "minute and second." The controller is factory-set to the "hour and minute" time unit. To create programs using the "minute and second" time unit, change the setpoint of the TMU (Time Unit of Program) setup parameter to "1".


Controller Settings

	Setpoint of SEG.T (Segment Setting Method) Setup Parameter
Time setting (method 1)	0 (factory-set default)
Ramp setting (method 2)	1

Choose the desired method and unit from the two programming methods and time unit options discussed above. Then, create programs according to the chosen options.


1. Creating programs by setting target setpoint and segment time

As shown in the figure on the right, this method creates programs by setting a segment time and a target setpoint on a segment-by-segment basis.



2. Creating programs by setting target setpoint and ramp

As shown in the figure on the right, this method creates programs by setting a target setpoint and a ramp grade on a segment-by-segment basis. Define the ramp grade as the amount of change in the setpoint per hour or per minute.




Controller Settings


	Setpoint of TMU (Time Unit of Program) Setup Parameter
When changing the setpoint linearly over an hour	0 (factory-set default)
When changing the setpoint linearly over a minute	1

Note: The "Time Unit of Program (TMU)" parameter is the time unit you use when creating programs.

When creating a soak segment during programming, set a time ("hour and minute" or "minute and second") rather than a ramp grade.



For example, configure segment 1 so the temperature rises in increments of 5°C per minute from 50°C to 100°C, as shown in the figure on the right.




To change the temperature linearly over a minute, set the TMU parameter to "1" (minute and second) before you begin programming. When programming the controller, set the Segment-1 Segment Time (1.TM1) parameter to 5°C. This allows the controller to raise the setpoint in increments of 5°C per minute during the interval of segment 1.

■ Controller Behavior at the Start of Program Operation

You can determine how the controller should behave at the start of program operation.

1. Letting the controller run from a starting target setpoint

A starting target setpoint refers to a setpoint from which program operation begins. The controller operates in such a manner that the setpoint changes to the target setpoint over the segment time set for segment 1, irrespective of what the PV value is.




Controller Settings

Set the STC (Start Code) program parameter to "0".

2. Letting the controller start from the current PV and run according to time settings defined for segment 1

This method is not available if the SEG.T (Segment Setting Method) parameter is set to "ramp setting."

Starting Point of Operation	Controller Behavior
a	Begins to run from point a according to the time setting defined for segment 1.
b	Begins to run from point b according to the time setting defined for segment 1.
c	Begins to run from point c according to the time setting defined for segment 1.
d	Begins to run from point d according to the time setting defined for segment 1.
e	Begins to run from point e according to the time setting defined for segment 1.




Controller Settings

Set the STC (Start Code) program parameter to "2".

3. Letting the controller start from the current PV and run according to ramp settings defined for segment 1.

Starting Point of Operation	Controller Behavior
a	Begins to run from point C1 (ignores the time setting defined for segment 1).
b	Begins to run from point C1 (ignores the time setting defined for segment 1).
c	Begins to run from point C1 (ignores the time setting defined for segment 1).
d	Begins to run from point D1 according to the preset ramp setting (the time setting defined for segment 1 is reduced).
e	Begins to run from point E1 according to the preset ramp setting.



Controller Settings

Set the STC (Start Code) program parameter to "1".

■ Program-based Selection of PID Constants

See "■ PID Switching (Zone PID)" in the back of **Parameters User's Manual**.

■ Program Repetition

Set a program you want to run repeatedly in the Junction Code parameter of a program pattern for which the controller is operated.

For example, if you want to run program pattern 1 repeatedly, set the Junction Code parameter to "2". This lets the controller repeat program pattern 1 indefinitely.

Controller Settings

	Setpoint of JC (Junction Code) Program Parameter
Repetition of program pattern 1	Set the parameter Program Pattern-1 Junction Code (1.JC) to "2".
Repetition of program pattern 2	Set the parameter Program Pattern-2 Junction Code (2.JC) to "3".

■ Program Linking

Use this function to append program pattern 2 to program pattern 1 so the controller runs according to the resulting single program pattern. You can also append program pattern 2 to program pattern 1.

Precautions when Linking Programs

There may be a case that a difference exists between the target setpoint defined for the final segment of a program pattern to be run first and the starting target setpoint of a program pattern to be combined with. If this is the case, a deviation may occur and therefore a derivative action may take place, causing the control output to travel up to 100% or down to 0% and stay at this point.

If program linking is assumed, care must be taken to prevent any significant deviation from arising between the setpoints to be linked when creating programs.


Controller Settings

	Setpoint of JC (Junction Code) Program Parameter
To append program pattern 2 to program pattern 1	Set the parameter Program Pattern-1 Junction Code (1.JC) to "3".
To append program pattern 1 to program pattern 2	Set the parameter Program Pattern-2 Junction Code (2.JC) to "2".

■ Retaining the End-of-Program State (End of Hold)

This function keeps the controller in the same state as when the program operation was completed. When in hold operation, the controller retains its states of control output and event output. To cancel hold operation, use either key operation or external contact input. When the hold operation is cancelled, the control output is set to 0% or OFF, and the event output is set to OFF.

To retain the end-of-program state, set a Junction Code program parameter to "1". For example, if you want the controller to run according to program pattern 1 and retain the same state as when the program ended, set the Program Pattern-1 Junction Code (1.JC) parameter to "1".



Controller Settings

	Setpoint of JC (Junction Code) Program Parameter
To quit hold operation in program pattern 1	Set the parameter Program Pattern-1 Junction Code (1.JC) to "1".
To quit hold operation in program pattern 2	Set the parameter Program Pattern-2 Junction Code (2.JC) to "1".


■ Suspending the Progress of a Program (Wait Function)

When a running program moves from one segment to another, the wait function places the program in a wait (stand-by) state, by using a wait zone and a wait time, until any deviation is cancelled. The wait function works only when the program moves from a ramp segment (either upgrade or downgrade) to a soak segment (where the setpoint is kept constant). A wait zone is a deviation bandwidth from which the degree of PV input tracking is judged. A wait time is the length of time that elapses until the PV input enters the wait zone. The program progresses if the PV input fails to re-enter the wait zone within the wait time.

When the program is in the wait state, the time setpoints of Segment Time and Time Event parameters temporarily cease to be passed. At this point, the output based on the Time Event parameter is retained.

● If the PV input reaches the wait zone before the wait time expires

If the PV input re-enters the wait zone after the start of wait action and before the expiry of the wait time, the program changes from a wait state to a run state and begins to progress.




This manual contains a parameter map as a guideline for setting parameters, and lists of parameters for recording User Settings.

Contents


1. Basic Key Operation Sequence and Parameter Map
2. Lists of Parameters

1. Basic Key Operation Sequence and Parameter Map

- Basic Key Operation Sequence**
- Setting display can be switched (moved) using the **[M]** key.
 - A numerical value is changed by:
 - Using the **[V]** or **[A]** key to change a displayed value (decimal point blinking) and
 - Pressing the **[R]** key to register it.
 - Pressing the **[M]** key on an operating display (for more than 3 seconds) brings you to the operating parameter setting display.
 - Pressing the **[M]** key on the operating parameter setting display (for more than 3 seconds) returns you to the operating display.
 - Pressing the **[M]** key on the setup parameter setting display (for more than 3 seconds) returns you to the operating display. You cannot return to the operating parameter setting display from the setup parameter setting display.



NOTE
 Changing the registered value of a setup parameter may cause the registered value of an operating parameter to be initialized automatically. Thus, when you have changed a setup parameter, always check that the registered value of the operating parameter is appropriate. If it is initialized to default, reset it to the required value.



If you become unsure of key operation during parameter setting, hold down the **[M]** key for more than 3 seconds. This returns you to the display at power-on (i.e., operating display).

List of PV Event Types

Alarm type	Alarm action	Alarm type code	Alarm type	Alarm action	Alarm type code
No alarm	"Open/close" shows status of relay contact, and "lit" and "unlit" shows status of lamp	OFF	No alarm	"Open/close" shows status of relay contact, and "lit" and "unlit" shows status of lamp	OFF
PV high limit	Hysteresis Open (unlit) → Closed (lit) PV Alarm setpoint	1	De-energized on deviation low limit alarm	Hysteresis Open (lit) → Closed (unlit) Deviation setpoint Target SP	6
PV low limit	Hysteresis Closed (lit) → Open (unlit) Alarm setpoint PV	2	Deviation high and low limits	Hysteresis Closed (unlit) → Open (unlit) → Closed (lit) Deviation setpoint Target SP	7
Deviation high limit	Hysteresis Open (unlit) → Closed (lit) PV Target SP	3	Deviation within high and low limits	Hysteresis Open (unlit) → Open (lit) → Open (unlit) Deviation setpoint Target SP	8
Deviation low limit	Hysteresis Closed (lit) → Open (unlit) Deviation setpoint Target SP	4	De-energized on PV high limit	Hysteresis Closed (unlit) → Open (lit) PV Alarm setpoint	9
De-energized on deviation high limit alarm	Hysteresis Closed (unlit) → Open (lit) PV Deviation setpoint Target SP	5	De-energized on PV low limit	Hysteresis Open (lit) → Closed (unlit) PV Alarm setpoint	10


Instrument Input Range Codes

Input	Type	Instrument Input Range Code	Instrument Input Range
Unspecified	K	OFF	"N" to the OFF option to leave the PV input type undefined.
		1	-200 to 1370°C
		2	-199.9 to 999.9°C
		3	-199.9 to 500.0°C
		4	-199.9 to 999.9°C
		5	-199.9 to 400.0°C
		6	0.0 to 400.0°C
		7	0 to 1800°C
		8	0 to 1700°C
		9	0 to 1700°C
Thermocouple	J	10	-200 to 1300°C
		11	-199.9 to 999.9°C
		12	-199.9 to 900.0°C
		13	-199.9 to 400.0°C
		14	0.0 to 400.0°C
		15	0 to 2300°C
		16	0 to 1390°C
		17	0 to 1900°C
		18	0 to 2000°C
		RTD	Pt100
31	-150.0 to 150.0°C		
35	-199.9 to 850.0°C		
36	-199.9 to 500.0°C		
37	-150.0 to 150.0°C		
Standard signal	DC voltage	40	0.00 to 2.000V
		41	1.000 to 5.000V
		50	0.00 to 2.000V
		51	0.00 to 10.00V
		55	-10 to 20 mV
56	0.0 to 100.0mV		

Control Output Type
 See the setup parameter OT (control output type) on the back of this manual.

Program Setting Display

Program	Code	Description
Program1	IRL1	PV event-1 type
	IRA1	PV event-1 setpoint
	IRL2	PV event-2 type
	IRA2	PV event-2 setpoint
	IEon	On time of time event
	IEoF	Off time of time event
	ISSP	Starting target setpoint
	ISLc	Start code
	ISP1	Segment-1 target setpoint
	ISP2	Segment-2 target setpoint
Program2	2AR1	PV event-1 type
	2RA2	PV event-2 type
	2AR2	PV event-2 setpoint
	2Eon	On time of time event
	2EoF	Off time of time event
	2SSP	Starting target setpoint
	2SLc	Start code
	2SP1	Segment-1 target setpoint
	2SP2	Segment-2 target setpoint
	2SP3	Segment-3 target setpoint
Program3	3AR1	PV event-1 type
	3RA2	PV event-2 type
	3AR2	PV event-2 setpoint
	3Eon	On time of time event
	3EoF	Off time of time event
	3SSP	Starting target setpoint
	3SLc	Start code
	3SP1	Segment-1 target setpoint
	3SP2	Segment-2 target setpoint
	3SP3	Segment-3 target setpoint
Program4	4AR1	PV event-1 type
	4RA2	PV event-2 type
	4AR2	PV event-2 setpoint
	4Eon	On time of time event
	4EoF	Off time of time event
	4SSP	Starting target setpoint
	4SLc	Start code
	4SP1	Segment-1 target setpoint
	4SP2	Segment-2 target setpoint
	4SP3	Segment-3 target setpoint
Program5	5AR1	PV event-1 type
	5RA2	PV event-2 type
	5AR2	PV event-2 setpoint
	5Eon	On time of time event
	5EoF	Off time of time event
	5SSP	Starting target setpoint
	5SLc	Start code
	5SP1	Segment-1 target setpoint
	5SP2	Segment-2 target setpoint
	5SP3	Segment-3 target setpoint
Program6	6AR1	PV event-1 type
	6RA2	PV event-2 type
	6AR2	PV event-2 setpoint
	6Eon	On time of time event
	6EoF	Off time of time event
	6SSP	Starting target setpoint
	6SLc	Start code
	6SP1	Segment-1 target setpoint
	6SP2	Segment-2 target setpoint
	6SP3	Segment-3 target setpoint
Program7	7AR1	PV event-1 type
	7RA2	PV event-2 type
	7AR2	PV event-2 setpoint
	7Eon	On time of time event
	7EoF	Off time of time event
	7SSP	Starting target setpoint
	7SLc	Start code
	7SP1	Segment-1 target setpoint
	7SP2	Segment-2 target setpoint
	7SP3	Segment-3 target setpoint
Program8	8AR1	PV event-1 type
	8RA2	PV event-2 type
	8AR2	PV event-2 setpoint
	8Eon	On time of time event
	8EoF	Off time of time event
	8SSP	Starting target setpoint
	8SLc	Start code
	8SP1	Segment-1 target setpoint
	8SP2	Segment-2 target setpoint
	8SP3	Segment-3 target setpoint
Program9	9AR1	PV event-1 type
	9RA2	PV event-2 type
	9AR2	PV event-2 setpoint
	9Eon	On time of time event
	9EoF	Off time of time event
	9SSP	Starting target setpoint
	9SLc	Start code
	9SP1	Segment-1 target setpoint
	9SP2	Segment-2 target setpoint
	9SP3	Segment-3 target setpoint
Program10	10AR1	PV event-1 type
	10RA2	PV event-2 type
	10AR2	PV event-2 setpoint
	10Eon	On time of time event
	10EoF	Off time of time event
	10SSP	Starting target setpoint
	10SLc	Start code
	10SP1	Segment-1 target setpoint
	10SP2	Segment-2 target setpoint
	10SP3	Segment-3 target setpoint
Junction code	Jc	Junction code



2. Lists of Parameters

■ Operating Parameters

* Parameters relating to PV or program setpoints should all be set in real numbers. For example, use temperature values to define program setpoints and PV event setpoints for temperature input.

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
LL (LL)	LL communication interface selection	OFF: Communication is carried out via the RS485 communication terminals. ON: Communication is carried out via the light-loader adapter.	with communication: OFF without communication: ON		
Adv (ADV)	Advance of segment	This parameter appears during program operation. 0: OFF 1: Enable "Advance" (segments are skipped) These options appear during program operation.	0		Ref. 5.2(7)
Hold (HOLD)	Hold of program operation	This parameter appears during program operation. 0: OFF 1: Pause (Hold) These options appear during program operation.	0		Ref. 5.2(3) Ref. 5.2(5)
At (AT)	Auto-tuning	OFF: No auto-tuning 1: Auto-tuning for PID group 1 2: Auto-tuning for PID group 2 3: Auto-tuning for PID group 3 4: Auto-tuning for PID group 4 AUTO Performs auto-tuning to all groups 1 to 4.	OFF		
SC (SC)	"Super" function	OFF: Disable 1: Overload suppressing function Suppresses overshoots generated by abrupt changes in the target setpoint or by disturbances. 2: Hunting suppressing function (Stable mode) Suitable to stabilize the state of control when the load varies greatly, or the target setpoint is changed. Enables to answer the wider characteristic changes compared with Response mode. 3: Hunting suppressing function (Response mode) Enables quick follow-up and short converging time of PV for the changed target setpoint. Note: Use "SUPER" function (SC) 2 or 3 in PID control or PI control. "SUPER" function 2 or 3 is not available in the following control: 1) ON/OFF control 2) P control (control for proportional band only) 3) PD control (control for proportional band and derivative item only) Do not use hunting suppressing function when control processes with response such as flow or pressure control.	OFF		Ref. 2.1(5) Ref. 2.1(6)
PID (PID)	PID parameter display number	MENU: Move to FL parameter display 1Gr to 4Gr: Display of each PID parameter	MENU		Ref. 5.1(2)
FL (FL)	PV input filter	OFF, 1 to 120 second Used when the PV input range fluctuates.	OFF		
BS (BS)	PV input bias	-100.0% to 100.0% of PV input range span Used to correct the PV input range.	0.0% of PV input range span		Ref. 1.1(1)
OH (OH)	Output high limit	-5.0 to 105.0% (OL < OH)	100%		
OL (OL)	Output low limit	-5.0 to 105.0% (OL < OH)	0.0%		Ref. 2.1(3)
H (H)	ON/OFF control hysteresis	In ON/OFF control: 0.0 to 100.0% of PV input range span ON/OFF control: 0.5% of PV input range span			
DR (DR)	Direct/reverse action switching	0: reverse action, 1: direct action Control output	0		Ref. 2.1(1)
PCCH (PCCH)	High limit for PV color change	When PCMD (PV color mode parameter) = 6 or 7: -100.0 to 100.0% of PV input range When PCMD (PV color mode parameter) = 8 or 9: -100.0 to 100.0% of PV input range span When PCMD = 6 or 7: PCCH = 100.0%, PCCL = 0.0 % When PCMD = 8 or 9: PCCH and PCCL = 1.0 %			
PCCL (PCCL)	Low limit for PV color change	When PCMD (PV color mode parameter) = 6 or 7: -100.0 to 100.0% of PV input range When PCMD (PV color mode parameter) = 8 or 9: -100.0 to 100.0% of PV input range span When PCMD = 6 or 7: PCCH = 100.0%, PCCL = 0.0 % When PCMD = 8 or 9: PCCH and PCCL = 1.0 %			
WIZ (WIZ)	Wait zone	OFF, 1.0 to 10.0% of PV input range span	OFF		
WIT (WIT)	Wait time	0.00 to 99.59 ("hour and minute" or "minute and second") The unit is the same as that set in the Time Unit of Program (TMU) parameter.	0.00		Ref. 5.2(4)

■ PID-related Parameters

The following parameters are displayed when "1Gr" is set to PID parameter display number (PID). To set PID corresponding to target setpoint 2 to 4, set "2Gr", "3Gr", or "4Gr" to PID. The relevant parameters will then be displayed.

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
IP (1.P)	Proportional band	0.1 to 999.9%	5.0%		
I (1.I)	Integral time	OFF, 1 to 6000 second	240 second		
Id (1.D)	Derivative time	OFF, 1 to 6000 second	60 second		
Inr (1.MR)	Manual reset	-5.0 to 105.0% (enabled when integral time "1.I" is OFF) The manual reset value equals the output value when PV = SP is true. For example, if the manual reset value is 50%, the output value is 50% when PV = SP becomes true.	50.0%		
IRP (1.RP)	Zone PID reference point-1	0 to 100% of PV input range. Note that 1.RP ≤ 2.RP.	100% value of PV input range		Ref. 5.1(2)

Refer to the table below for recording setpoints when two sets or more of PID parameters are used.

Parameter	n=2	n=3	n=4
n.P			
n.I			
n.D			
n.MR			
n.RP	None	None	

rdb (RDV)	Reference deviation	OFF, 0.0 to 100.0% of PV input range span Used to select PID constants according to a deviation from the setpoint. The 4th group of PID constants is used when the controller fails to keep track of the deviation.	OFF	
-----------	---------------------	--	-----	--

■ Setup Parameters

■ Control Function-related Parameters

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
PCMD (PCMD)	PV color mode	0: Fixed in green 1: Fixed in red 2: Link to PV event 1 (Alarm OFF: green, Alarm ON: red) 3: Link to PV event 1 (Alarm OFF: red, Alarm ON: green) 4: Link to PV event 1 and 2 (Alarm OFF: green, Alarm ON: red) 5: Link to PV event 1 and 2 (Alarm ON: red, Alarm OFF: green) 6: PV limit (Within PV range: green, Out of PV range: red) 7: PV limit (Within PV range: red, Out of PV range: green) 8: SP deviation (Within deviation: green, Out of deviation: red) 9: SP deviation (Within deviation: red, Out of deviation: green)	1		
HY1 (HY1)	PV event-1 hysteresis	0.0 to 100.0% of PV input range span	0.5% of PV input range span		Ref. 3.4(5)
HY2 (HY2)	PV event-2 hysteresis				

* The "User Setting" column in the table below is provided for the customer to record setpoints.
* The column "Target Item in CD-ROM" in the table below provides references from User's Manual (Reference) (CD-ROM Version) which describes items in more detail and items that are not contained in this manual.


CT (CT)	Control output cycle time	1 to 1000 second	30 second		
PO (PO)	Preset output	-5.0 to 105.0% In Stop mode, fixed control output can be generated.	0.0%		Ref. 2.1(8)
CMD (CMD)	PID control mode	0: Standard PID control (with output bump at SP change) 1: Fixed point control (without output bump at SP change) Choose "fixed point control" when controlling pressure or flow rate.	0		Ref. 2.1(2)
AR (AR)	Anti-reset windup (Excess integration prevention)	AUTO (0), 50.0 to 200.0% Used when the control output travels up to 100% or down to 0% and stays at this point. The larger SP, the sooner PID computation (integral computation) stops.	AUTO		Ref. 2.1(4)
TU (TMU)	Program time unit	0: Hour and minute; 1: Minute and second Time unit used when setting a program pattern or a wait time.	0		
SEG (SEG.T)	Segment setting method	0: Time setting 1: Ramp setting If the setting of the setup parameter "SEG.T" is changed, the program patterns created and stored so far will be all cleared (initialized)!! Be beautiful.	0		Ref. 5.1(1)
PSL (P.SL)	Protocol selection	0: PC link communication 1: PC link communication (with sum check) 2: Ladder communication 3: Coordinated master station 7: MODBUS (ASCII) 8: MODBUS (RTU)	0		
bPS (BPS)	Baud rate	0:600, 1:1200, 2:2400, 3:4800, 4:9600 (bps)	4		
PR (PR)	Parity	0: None 1: Even 2: Odd	1		
STP (STP)	Stop bit	1, 2	1		Communication function
DLn (DLN)	Data length	7, 8 Fixed at 7, when the P.SL parameter is set to MODBUS (ASCII). Fixed at 8, when the P.SL parameter is set to MODBUS (RTU) or Ladder Communication.	8		
ADR (ADR)	Address	1 to 99 However, the maximum number of stations connectable is 31.	1		
rPt (RP.T)	Minimum response time	0 to 10 (× 10 ms)	0		
TEST (TEST)		If this parameter symbol appears, press the SET/ENT key to return to the FUNC menu. Caution: Do not change the setpoint of the TEST parameter, otherwise the indicator will be disabled.			

■ Input-/Output-related Parameters

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
IN (IN)	PV input type (PV INPUT terminals) ①②③ terminals	OFF, 1 to 18, 30, 31, 35 to 37, 40, 41, 50, 51, 55, 56 See Instrument Input Range Codes in Initial Settings User's Manual .	OFF		
UNIT (UNIT)	PV input unit	°C: degree Celsius °F: Fahrenheit (This parameter is not shown for voltage input.)	°C		
rH (RH)	Max. value of PV input range	Set the PV input range, however RL < RH. -Temperature input Set the range of temperature that is actually controlled. -Voltage input Set the range of a voltage signal that is applied. The scale across which the voltage signal is actually controlled should be set using the parameters Maximum Value of PV Input Scale (SH) and Minimum Value of PV Input Scale (SL).	Max. value of instrument input range		
rL (RL)	Min. value of PV input range	Set the range of a voltage signal that is applied. The scale across which the voltage signal is actually controlled should be set using the parameters Maximum Value of PV Input Scale (SH) and Minimum Value of PV Input Scale (SL).	Min. value of instrument input range		
SDP (SDP)	PV input decimal point position (displayed at voltage input)	0 to 3 Set the position of the decimal point of voltage-mode PV input. 0: No decimal place 1: One decimal place 2, 3: Two, three decimal places	1		
SH (SH)	Max. value of PV input scale (displayed at voltage input)	-1999 to 9999, however SL < SH Set the read-out scale of voltage-mode PV input.	100.0		
SL (SL)	Min. value of PV input scale (displayed at voltage input)	-1999 to 9999, however SL < SH Set the read-out scale of voltage-mode PV input.	0.0		
rJC (RJC)	Presence/absence of PV input reference junction compensation	OFF, ON	ON		
ERJC (ERJC)	External RJC setpoint	-50.0 to 50.0 °C -58.0 to 122.0 °F	0.0 °C 32.0 °F		
bSL (BSL)	Selection of PV input burnout action	OFF 1: Up scale 2: Down scale	1		
OT (OT)	Control output type	0 Time proportional PID relay contact output (terminals ①-②-③) 1 Time proportional PID voltage pulse output (terminals ④-⑦) 2 Current output (terminals ⑧-⑪) 3 ON/OFF control relay contact output (terminals ①-②-③)	0		
rRE (RET)	Retransmission output type	1: PV, 2: SP, 3: OUT, 4: Loop power supply for sensor (15 V)	1		
rTH (RTH)	Max. value of retransmission output scale	RET=1, 2: RTL + 1 digit to 100% of PV input range	100% of PV input range		Ref. 2.2(1)
rTL (RTL)	Min. value of retransmission output scale	RET=1, 2: 0% of PV input range to RTH - 1 digit	0% of PV input range		
DIS (DIS)	DI function selection	OFF Disables the external contact input. 1: D1: Starts (on)/stops (off) program-1 operation. D2: Starts (on)/stops (off) program-2 operation. 2: D1: Hides (on)/shows (off) the LOCK setup parameter. D2: Unused. 3: D1: Starts (on)/stops (off) program-1 operation. D2: Enables (on)/disables (off) the hold mode of program-1 operation.	OFF		Ref. 3.1(5)
C.S1 (C.S1)	SELECT display-1 registration	OFF, 201 to 1015 Select the desired parameter from among the operating and setup parameters, then register the number (D register No.) accompanying that parameter. For example, registering "306" for C.S1 allows you to change proportional band (1.P) in operating display. See User's Manual (Reference) (CD-ROM).	OFF		Ref. 6.1(1)
C.S2 (C.S2)	SELECT display-2 registration				
C.S3 (C.S3)	SELECT display-3 registration				
C.S4 (C.S4)	SELECT display-4 registration				
LOCK (LOCK)	Key lock	OFF: No key lock 1: Change to any parameter prohibited Prohibits any operating parameter or setup parameter from being changed. The setpoint of the LOCK parameter itself can be changed, however. 2: Change to and display of operating parameters prohibited Turns off the display for setting operating parameters, thus prohibiting any change to the parameter settings. (Hold down the SET/ENT key for more than 3 seconds to show the password check display.) 3: Disables the RESET key on the instrument's front panel. 4: Disables the PRG1 key on the instrument's front panel. 5: Disables the PRG2 key on the instrument's front panel. 6: Disables both the PRG1 and PRG2 keys on the instrument's front panel. 7: Prohibits the parameter settings of program pattern 1 from being changed. 8: Prohibits the parameter settings of program pattern 2 from being changed. 9: Prohibits the parameter settings of both program pattern 1 and program pattern 2 from being changed.	OFF		Ref. 7.1(2) Ref. 7.1(1)
PWD (PWD)	Password setting	0: Password not set 1 to 9999	0		

■ Auto-tuning

Auto-tuning is a function with which the controller automatically measures the process characteristics to automatically set the optimum PID constants. This function does not work when the controller is performing on-off control. The UP351 employs the "Limit Cycle Method." As shown in the figure on the right, the controller temporarily changes its control output in a step-waveform manner. Then, it calculates the optimum proportional band (P), integral time (I) and derivative time (D) from the resulting response to set them in their respective parameters. If the Output High Limit (OH) and Output Low Limit (OL) parameters are already configured, the control output turns on and off only between the output's high and low limits during auto-tuning.



■ When One Group of PID Constants is Used (factory-set default)

Setting of AT Parameter	Auto-tuned Setpoint	Remarks
OFF	-	Auto-tuning is turned off (disabled).
1	The setpoints when auto-tuning is started	Determines the values of 1.P, 1.I and 1.D parameters by auto-tuning.

■ When Two Groups of PID Constants are Used (See "■ PID Switching (Zone PID)" below)

Setting of AT Parameter	Auto-tuned Setpoint	Remarks
OFF	-	Auto-tuning is turned off (disabled).
1	The setpoints when auto-tuning is started	Determines the values of 1.P, 1.I and 1.D parameters by auto-tuning.
2	The setpoints when auto-tuning is started	Determines the values of 2.P, 2.I and 2.D parameters by auto-tuning.
AUTO	Median value of each zone width	Determines the values of all PID parameters in use by auto-tuning.

■ When Three Groups of PID Constants are Used (See "■ PID Switching (Zone PID)" below)

Setting of AT Parameter	Auto-tuned Setpoint	Remarks
OFF	-	Auto-tuning is turned off (disabled).
1	The setpoints when auto-tuning is started	Determines the values of 1.P, 1.I and 1.D parameters by auto-tuning.
2	The setpoints when auto-tuning is started	Determines the values of 2.P, 2.I and 2.D parameters by auto-tuning.
3	The setpoints when auto-tuning is started	Determines the values of 3.P, 3.I and 3.D parameters by auto-tuning.
AUTO	Median value of each zone width	Determines the values of all PID parameters in use by auto-tuning.

■ When PID Constants are Selected According to the Deviation (See "■ PID Switching (Zone PID)" below)

Setting of AT Parameter	Auto-tuned Setpoint	Remarks
OFF	-	Auto-tuning is turned off (disabled).
1	The setpoints when auto-tuning is started	Determines the values of 1.P, 1.I and 1.D parameters by auto-tuning.
2	The setpoints when auto-tuning is started	Determines the values of 2.P, 2.I and 2.D parameters by auto-tuning.
4	The setpoints when auto-tuning is started	Determines the values of 4.P, 4.I and 4.D parameters by auto-tuning.


Note: Set the maximum and minimum values, as close as possible to those of the actual range to be controlled, in the Maximum Value of PV Input Range (RH) and Minimum Value of PV Input Range (RL) parameters. Otherwise, the controller may fail to determine the optimum values when auto-tuning is carried out.

■ PID Switching (Zone PID)

The UP351 carries out control by automatically switching between groups of PID constants according to the temperature zone. You can set a maximum of three temperature zones. When shipped from the factory, the UP351 is configured so that it operates in zone 1 only and using only one group of PID constants.


■ When One Group of PID Constants is Used (factory-set default)

As shown in the figure on the right, the controller uses one group of PID constants over the range from the minimum value to the maximum value of the PV input range.



■ Selection of PID Constants when the Control Range is Split into Three Zones

As shown in the figure on the right, three zones are set for the controller to automatically switch from one group of PID constants to another. Two zones can also be set for the controller to select between two groups of PID constants.



- The controller uses the 1st group of PID constants if the PV input value is within the zone set off by the minimum value of the PV input range and reference point 1.
- The controller uses the 2nd group of PID constants if the PV input value is within the zone set off by reference point 1 and reference point 2.
- The controller uses the 3rd group of PID constants if the PV input value is within the zone set off by reference point 2 and the maximum value of the PV input range.

Controller Settings


- Splitting the control range into two zones
 - To split the control range into two zones, define reference point 1 (i.e., the 1.RP operating parameter).
 - Define the 1st and 2nd groups of PID constants (i.e., the 1.P, 1.I and 1.D operating parameters for the 1st group and the 2.P, 2.I and 2.D operating parameters for the 2nd group).
- Splitting the control range into three zones
 - To split the control range into three zones, define reference points 1 and 2 (i.e., the 1.RP and 2.RP operating parameters).
 - Define the 1st, 2nd and 3rd groups of PID constants (i.e., the 1.P, 1.I and 1.D operating parameters for the 1st group, the 2.P, 2.I and 2.D operating parameters for the 2nd group and the 3.P, 3.I and 3.D operating parameters for the 3rd group).

■ Selecting PID Constants According to the Deviation

PID constants can be selected according to the deviation in two ways. One method is to select a group of PID constants only by a deviation from a program setpoint. The other method is to use a reference point, as discussed earlier, as well as a deviation from a program setpoint, to switch between groups of PID constants. Deviation-based switching has priority over switching based on a reference point.


Method 1:

As shown in the figure on the right, the controller selects the 4th group of PID constants if the PV input value goes beyond the given deviation from the program setpoint.



Method 2:

As shown in the figure on the right, the controller selects an appropriate group of PID constants for each zone and, if the PV input value goes beyond the given deviation from the program setpoint, selects the 4th group of PID constants.




- The controller uses the 2nd group of PID constants if the PV input value is both within the zone set off by reference point 1 and the maximum value of the PV input range and within the given reference deviation bandwidth.
- The controller uses the 4th group of PID constants if the PV input value goes beyond the given reference deviation bandwidth.

Controller Settings

- Splitting the control range into two zones
 - To split the control range into two zones, define reference point 1 (i.e., the 1.RP operating parameter).
 - Define the 1st and 2nd groups of PID constants (i.e., the 1.P, 1.I and 1.D operating parameters for the 1st group and the 2.P, 2.I and 2.D operating parameters for the 2nd group).
 - Define the reference deviation (i.e., the RDV operating parameter).
 - The RDV parameter appears after the 4th group of PID parameters.
- Splitting the control range into three zones
 - To split the control range into three zones, define reference points 1 and 2 (i.e., the 1.RP and 2.RP operating parameters).
 - Define the 1st, 2nd and 3rd groups of PID constants (i.e., the 1.P, 1.I and 1.D operating parameters for the 1st group, the 2.P, 2.I and 2.D operating parameters for the 2nd group and the 3.P, 3.I and 3.D operating parameters for the 3rd group).
 - Define the reference deviation (i.e., the RDV operating parameter).
 - The RDV parameter appears after the 4th group of PID parameters.

■ Hysteresis for PID switching (if Zone PID is used)


Hysteresis is set for PID switching at reference point 1, as shown in the figure on the right. The hysteresis bandwidth is fixed at 0.5% of the span of the PV input range. Reference point 2 behaves in the same way as reference point 1, though the figure shows reference point 1 only.




■ Hysteresis (Setpoints for On-Off Control and PV Event Setpoints)

Hysteresis can be set in on-off control setpoints and PV event setpoints as well. With the hysteresis settings, it is possible to prevent relays from chattering.

■ When hysteresis is set in an on-off control setpoint




■ When hysteresis is set in a PV event setpoint



■ Useful Operating Display (SELECT display)


Registering frequently changed parameters in the SELECT display after ordinary operating displays will allow you to change settings easily. A maximum of four ordinary displays can be registered.



Setting Method

Set the numbers of parameters (D



















This manual describes the PV display color changing function "Active Color PV Display."

Carry out settings according to the following procedures after referring to "Functions of Active Color PV Display" on the back of this manual. Use "Parameter Map" of Parameters User's Manual to understand the required parameters. If you cannot remember how to carry out an operation during setting, press the  key for more than 3 seconds. This brings you to the display (operating display) that appears at power-on.

■ Setting the PV display color changing function "Active Color PV Display"

The following operating procedure describes an example of changing PV color mode (factory-set default: Fixed in red mode) to Link to PV event 1 mode.













Parameter Symbol	Name of Parameter	Setting Range	Initial Value
PCMD (PCMD)	PV color mode	0 : Fixed in green 1 : Fixed in red 2 : Link to PV event 1 (Alarm OFF:green, Alarm ON: red) 3 : Link to PV event 1 (Alarm OFF:red, Alarm ON:green) 4 : Link to PV event 1 and 2 (Alarm OFF:green, Alarm ON:red) 5 : Link to PV event 1 and 2 (Alarm OFF:red, Alarm ON:green) 6 : PV limit (Within PV range:green, Out of range:red) 7 : PV limit (Within PV range:red, Out of range:green) 8 : SP deviation (Within deviation:green, Out of deviation:red) 9 : SP deviation (Within deviation:red, Out of deviation:green)	1

<p>(1) Bring the operating display into view (appears at power on). Stop state(RESET)  Displays PV</p>	<p>(6) Press the  key several times to display the menu "PCMD" (PV color mode).  Displays parameter "PCMD"</p>
<p>(2) Press the  key for more than 3 seconds to call up the menu "OP.PA."  Displays menu "OP.PA"</p>	<p>(7) Press the  key or  key to display the required setpoint. The figure below shows an example of setting Link to alarm 1 mode.  Blinks during change</p>
<p>(3) Press the  key once to display the menu "STUP."  Displays menu "STUP"</p>	<p>(8) Press the  key once to register the setpoint.  If PCMD = 6, 7, 8 or 9, also set the relating parameters PCCH (High limit for PV color change) and PCCL (Low limit for PC color change).</p>
<p>(4) Press the  key once to display the parameter "PWD."  Displays parameter "PWD."</p>	<p>(9) Press the  key for more than 3 seconds. This returns you to the display shown at power-on (figure blow). Stop state(RESET)  Displays PV</p>
<p>(5) Press the  key once to display the menu "FUNC."  Displays menu "FUNC"</p>	

■ Setting the High Limit and Low limit for PV Color change

The following operating procedure describes an example of changing PV display color by linking to PV. Set High limit and Low limit for PV color change. Setting for both of High limit and Low limit is required.

Parameter Symbol	Name of Parameter	Setting Range	Initial Value
PCCH (PCCH)	High limit for PV color change	When PCMC (PV color mode parameter) = 6 or 7: -100.0 to 100.0 % of PV input range.	When PCMD = 6 or 7: PCCH:100.0 %, PCCL:0.0 %
PCCL (PCCL)	Low limit for PV color change	When PCMC (PV color mode parameter) = 8 or 9: -100.0 to 100.0 % of PV input range span.	When PCMD = 8 or 9: PCCH and PCCL:1.0 %

<p>(1) Bring the operating display into view (appears at power-on). Stop state (RESET)  Displays PV.</p>	<p>(4) Press the  key or  key to display the required setpoint.  Blinks during change.</p>
<p>(2) Press the  key for more than 3 seconds to call up the menu "OP.PA."  Displays menu "OP.PA"</p>	<p>(5) Press the  key once to register the setpoint.  PCCL (Low limit for PV color change parameter) that is displayed after this can be</p>
<p>(3) Press the  key several times to display the parameter "PCCH."  Displays parameter "PCCH."</p>	<p>(6) Press the  key for more than 3 seconds. This returns you to the display shown at power-on (figure below). Stop state (RESET)  Displays PV.</p>

Functions of Active Color PV Display

This part describes the functions of "Active Color PV Display." PV display color is changed by the following four actions.

PV display is selectable from red-to-green or green-to-red changing action, or fixed color.

Link to PV event 1 mode (when PCMD = 2, 3) (Setting example-1)

Link to PV event 1 and 2 mode (when PCMD = 4, 5) is the same. When either of the alarms occurs, the display color is changed.

SP deviation mode (when PCMD = 8, 9) (Setting example-2)

PV limit mode (when PCMD = 6, 7) (Setting example-3)

Fixed color mode (when PCMD = 0, 1) (Setting example-4)

Setting Example-1 : Link to PV event

Works linked to PV event 1.

Set "PV high limit alarm" for alarm 1 type, and "80°C" for PV event 1 setpoint.

If PCMD (PV color mode parameter) = 2, PV display color is changed from green to red when PV input value exceeds PV event 1 setpoint.

The red-to-green changing action is selectable.

Setting parameters


PCMD (PV color mode parameter) = 2

n.AL1 (PV event 1 type parameter) = 1

n.A1 (PV event 1 setpoint parameter) = 80°C

HY1 (PV event 1 hysteresis parameter) = 5°C

n=1,2



Setting Example-3 : Link to PV

Set high limit "70°C" for PCCH, and low limit "20°C" for PCCL.

PV display color is changed from green to red when PV input value is out of the range.

The red-to-green changing action is selectable.

Setting parameters


PCMD (PV color mode parameter) = 6

PCCH (High limit for PV color change parameter) = 70°C

PCCL (Low limit for PV color change parameter) = 20°C

Hysteresis fixed to 0.25% is inserted where PV display color is changed.

In the example blow, where changed from red to green.



Setting Example-2 : Change by Deviation

Set high limit deviation band "10°C" for PCCH, and low limit deviation band "5°C" for PCCL against current setpoint "50°C."

PV display color is changed from green to red when PV input value is out of the deviation.

The red-to-green changing action is selectable.

Setting parameters


PCMD (PV color mode parameter) = 8

PCCH (High limit for PV color change parameter) = 10°C

PCCL (Low limit for PV color change parameter) = 5°C

Hysteresis fixed to 0.25% is inserted where PV display color is changed.

In the example blow, where changed from red to green.




Setting Example-4 : Fixed in Red or Green

Set the PV display color or Fixed in green mode, Setting of Fixed to red mode is also possible.

Setting parameter

PCMD (PV color mode parameter) = 0



External RJC

External RJC is not a compensation function built in a controller but a compensation function working outside the controller.

External RJC is used when input is thermocouple, and RJC=OFF.

Using External RJC makes the accuracy of RJC higher and shortens the compensating wire.

Parameter Symbol	Name of Parameter	Setting Range	Initial Value
ERJC (ERJC)	External RJC setpoint	-50.0 to 50.0°C, -58.0 to 122.0°F For thermocouple input, temperature compensation value outside the controller can be set. Available only when RJC=OFF.	0.0°C 32.0°F

