

TECHNICAL MANUAL
 DIRECT SUPPORT AND
 GENERAL SUPPORT
 MAINTENANCE MANUAL INCLUDING
 REPAIR PARTS AND
 SPECIAL TOOLS LIST
 (INCLUDING DEPOT MAINTENANCE
 REPAIR PARTS)

VOLUME I - TROUBLESHOOTING

VOLUME II - MAINTENANCE

BALLISTIC DRIVE: M15
 (1220-00-071-5330)

VOLUME I TROUBLESHOOTING	CHAPTER 1	
	INTRODUCTION	1-1
	CHAPTER 2	
	TROUBLESHOOTING	2-1

	CHAPTER 1	
	INTRODUCTION	1-1
	CHAPTER 2	
	GENERAL MAINTENANCE INFORMATION	2-1
	CHAPTER 3	
	INSPECTION UPON RECEIPT	3-1
	CHAPTER 4	
	MAINTENANCE PROCEDURES	4-1
	CHAPTER 5	
	FINAL INSPECTION	5-1
	CHAPTER 6	
	PACKAGING	6-1
VOLUME II MAINTENANCE	APPENDIX A	
	EXPENDABLE SUPPLIES AND MATERIALS LIST	A-1
	APPENDIX B	
	MAINTENANCE TASK INDEX	B-1
	APPENDIX C	
	FABRICATED TOOL	C-1
	APPENDIX D	
	REPAIR PARTS AND SPECIAL TOOLS LIST	D-1

WARNING

Be careful when removing ballistics drive, it is heavy and hard to handle. Do not drop as it may hurt someone or damage equipment.

TECHNICAL MANUAL }
No.9-1220-231-34P }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, *25 November 1983*

**Direct Support And
General Support
Maintenance Manual Including
Repair Parts and Special
Tools List (Including Depot
Maintenance Repair Parts)**

**BALLISTICS DRIVE: M15
(1220-00-071-5330)**

Current as of 25 May 1983 for APPENDIX D.

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual directly to: Commander, US Army Ament Materiel Readiness Command, ATTN: DRSAR-MAS, Rock Island, IL 61299.
A reply will be furnished direct to you.

*This manual supersedes TM 9-1220-1-35, 27 September 1965 and TM 9-1220-231-34P, 11 April 1972.

		Paragraph	Page
HOW TO USE THIS MANUAL			v
VOLUME I TROUBLESHOOTING			
CHAPTER 1.	INTRODUCTION		1-1
	Scope	1-1	1-1
	Organization	1-2	1-1
	How to Troubleshoot	1-3	1-2
2.	TROUBLESHOOTING		2-1
	Scope	2-1	2-1
	Performance Test	2-2	2-1
VOLUME II MAINTENANCE			
CHAPTER 1.	INTRODUCTION		1-1
Section 1.	General		1-1
	Scope	1-1	1-1
	Organization	1-2	1-1
2.	Description and Data		1-1
	Description	1-3	1-1
	Tabulated Data	1-4	1-2
CHAPTER 2.	GENERAL MAINTENANCE INFORMATION		2-1
Section 1.	General		2-1
	Scope	2-1	2-1
2.	Reference Documents		2-1
	General Maintenance	2-2	2-1
	Cleating	2-3	2-1
	Painting	2-4	2-1
	Sealing	2-5	2-1
	Lubrication	2-6	2-1
3.	Safety Procedures		2-1
	General Procedure	2-7	2-1
4.	Special Tools and Test Equipment		2-2
	Tools and Test Equipment	2-8	2-2
CHAPTER 3.	INSPECTION UPON RECEIPT		3-1
	Scope	3-1	3-1
	Inspection Upon Receipt	3-2	3-1
4.	MAINTENANCE PROCEDURES		4-1

LIST OF EFFECTIVE PAGES

INSERT LATEST CHANGED PAGES. DESTROY SUPERSEDED PAGES.

NOTE: The portions of the text affected by the changes are indicated in the outer margins of the page. Changes to illustrations are indicated by miniature pointing hands. Changes to wiring diagrams are indicated by shaded areas.

Dates of issue for original and changed pages are:

Original 0

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 94 CONSISTING OF THE FOLLOWING:

Page No.	*Change No.	Page No.	*Change No.
Cover	0	2-1 - 2-2	0
Warning	0	3-1 - 3-7.	0
A	0	4-0 - 4-31	0
B Blank	0	4-32 Blank	0
i - v	0	5-1 - 5-2	0
vi Blank	0	6-1	0
		6-2 Blank.	0
VOLUME I		A-1 - A-2	0
TROUBLESHOOTING		B-1 - B-2.	0
Title.	0	C-1.	0
Reverse Blank.	0	C-2 Blank	0
1-1 - 1-3	0	D-1 - D-5.	0
1-4 Blank	0	D-6 Blank.	0
2- 1- 2-2	0	D-7 - D-13.	0
		D-14 Blank	0
VOLUME II		D-15 - D-18.	0
MAINTENANCE		Metric Conversion Chart.	0
Title.	0	Cover.	0
Reverse Blank	0		
1-1 - 1-2	0		

*Zero in this column indicates an original page.

	Paragraph	Page
Section 1.	General	4-1
	Scope	4-1
	List of Ballistics Drive Items Contained in This Chapter	4-2
2.	Ballistics Drive	4-2
	Ballistics Drive Maintenance Procedures Index	4-3
	Ballistics Drive Removal	4-4
	Ballistics Drive Installation	4-5
3.	Trunnion Link	4-17
	Trunnion Link Maintenance Procedures Index	4-6
	Trunnion Link Disassembly	4-7
	Trunnion Link Assembly	4-8
4.	Temperature Compensating Rod	4-20
	Temperature Compensating Rod Maintenance Procedures Index	4-9
	Temperature Compensating Rod Removal	4-10
	Temperature Compensating Rod Installation	4-11
5.	Fire Control Level	4-23
	Fire Control Level Maintenance Procedures Index	4-12
	Fire Control Level Removal	4-13
	Fire Control Level Disassembly	4-14
	Fire Control Level Assembly	4-15
	Fire Control Level Installation	4-16
CHAPTER 5.	FINAL INSPECTION	5-1
	Scope	5-1
	Final Inspection	5-2
6.	PACKAGING	6-1
	Scope	6-1
	Packaging of Assemblies	6-2
APPENDIX A.	EXPENDABLE SUPPLIES AND MATERIALS LIST	A-1
Section 1.	Introduction	A-1
	Scope	A-1
	Explanation of Columns	A-2
2.	Expendable Supplies and Materials List	A-1
APPENDIX B.	MAINTENANCE TASK INDEX	B-1
	Scope	B-1
	Maintenance Task Index	B-2

	Paragraph	Page	Figure
APPENDIX C. FABRICATED TOOL.....		C-1	
D. DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS)		D-1	
Section I. Introduction		D-1	
II. Repair Parts List		D-7	
Group 00 Ballistic Drive M15 10516375		D-9	D-1
0001 Link Assembly 8620208.		D-9	D-1
0002 Shaft Assembly 10516381		D-11	D-2
000201 Fire Control Level 8585560.....		D-12	D-3
000202 Coupling Assembly 8620124.....		D-13	D-4
III. Special Tools List.....		D-16	D-5
IV. National Stock Number and Part Number Index.		D-17	

HOW TO USE THIS MANUAL

This manual has two volumes of maintenance information you will need to repair and service the M15 Ballistics Drive.

- Volume I - Troubleshooting
- Volume II - Maintenance

The organization paragraph in each volume tells you what information you can find in each chapter and appendix.

There are four ways to find any maintenance information you need:

- Index on the front cover which tells what information is contained in each chapter
- Table of contents located at the front of the manual which has a complete listing by paragraph number and page number
- Performance test (Vol I, Chap 2)
- Maintenance task index (Vol II, App. B) which lists major assemblies, subassemblies and paragraph numbers of all maintenance procedures

Before doing any maintenance, you should read and understand HOW TO TROUBLESHOOT on page 1-2. If you do not know the equipment well, you should read the section on description and data (Vol II, Chap 1).

Throughout the manual reference is made to a Job Performance Guide 113-091-9000R (JPG 41C) which helps you to develop skills in doing the maintenance tasks.

TECHNICAL MANUAL

DIRECT SUPPORT AND
GENERAL SUPPORT
MAINTENANCE MANUAL INCLUDING
REPAIR PARTS AND SPECIAL
TOOLS LIST (INCLUDING DEPOT
MAINTENANCE REPAIR PARTS)

VOLUME I - TROUBLESHOOTING

BALLISTICS DRIVE: M15

CHAPTER 1

INTRODUCTION

1-1. SCOPE

This volume contains troubleshooting requirements for direct support and general support maintenance of the M15 Ballistics Drive.

1-2. ORGANIZATION


All troubleshooting requirements for checking out the ballistics drive and finding fault symptoms are given in Chapter 2. See paragraph 1-3 for how to do troubleshooting.

1-3. HOW TO TROUBLESHOOT

The following steps tell you how to troubleshoot. A diagram of these steps is on page 1-3.

- Ⓐ Do a visual check and list any faults on DA Form 2404 before making repairs. See Vol II, Chap 3 for what to check for.
- Ⓑ If you see any faults that may affect the checkout procedure, fix them now. This does not mean small things like painting scratches.
- Ⓒ Do the performance test in Vol I, Chap 2 from the beginning until you find a fault symptom.
- Ⓓ When a fault symptom is found, do the maintenance action required to correct the fault symptom (Vol II, Chap 4),
- Ⓔ After the fault symptom has been corrected, do the performance test in Chapter 2 again. This is to make sure all fault symptoms have been corrected.
- Ⓕ If all the fault symptoms are now corrected, do the remaining maintenance tasks on DA Form 2404.
- Ⓖ Do the final inspection given in Vol II, Chap 5.
- Ⓗ The job is over and the good assembly is sent back to service.
- Ⓘ If all fault symptoms were not corrected after step E, the bad assembly is sent back to the depot for repair.

1-3. HOW TO TROUBLESHOOT (CONT)



CHAPTER 2 TROUBLESHOOTING

2-1. SCOPE

Troubleshooting of the M 15 Ballistics Drive is done by using the following performance test. If you find any symptom, look in the maintenance action column to correct it.

2-2. PERFORMANCE TEST


PERSONNEL: One

REFERENCE: TM 9-2350-222-20-2-1 for synchronization check

EQUIPMENT CONDITION: Ballistics drive mounted in vehicle


FRAME 1

Step	Procedure	Symptom	Maintenance Action
1.	Do synchronization check (PM-20-2-1). Check ballistics drive (1) is in synchronization. GO TO FRAME 2	Ballistics drive out of alignment.	Send unit to depot for repair.



2-2. PERFORMANCE TEST (CONT)

FRAME 2			
Step	Procedure	Symptom	Maintenance Action
1.	Disconnect trunnion link (1) (Vol II, para 4-4, frame 2, steps 1 thru 3).	...	Send unit to depot for repair.
2.	Turn cross shaft (2) all the way in both directions. Check shaft (2) turns smoothly without binding. NOTE Correct remaining faults listed on DA Form 2404. Do final inspection (Vol II, para 5-2). END OF TASK	Cross shaft does not turn smoothly.	



TECHNICAL MANUAL

DIRECT SUPPORT AND
GENERAL SUPPORT
MAINTENANCE MANUAL INCLUDING
REPAIR PARTS AND SPECIAL
TOOLS LIST (INCLUDING DEPOT
MAINTENANCE REPAIR PARTS)

VOLUME II - MAINTENANCE

BALLISTICS DRIVE: M15

CHAPTER 1

INTRODUCTION

Section 1. GENERAL

1-1. SCOPE

This volume contains maintenance requirements for direct support and general support maintenance of the M15 Ballistics Drive. See Volume 1 for troubleshooting information.

1-2. ORGANIZATION

a. Chapter 2. General Maintenance Information lists maintenance items and references general procedures that are necessary to do the maintenance procedures in this volume.

b. Chapter 3. Inspection Upon Receipt gives the faults to look for when the unit is returned to DS/GS. A complete inspection should be made and faults listed on DA Form 2404 before any repairs are made.

c. Chapter 4. Maintenance Procedures give step-by-step procedures to repair faults found during inspection or troubleshooting.

d. Chapter 5. Final Inspection gives procedures to be done after repair to make sure that the ballistics drive works and ready for packaging or installation.

e. Chapter 6. Packaging gives procedures for packaging the ballistics drive for storage or shipment.

f. Appendix A. Expendable Supplies and Materials List gives supplies and materials, with specification or NSN, needed to repair the ballistics drive.

g. Appendix B. Maintenance Task Index helps you find maintenance tasks for the ballistics drive.

h. Appendix C. Fabricated Tools contains information that you will need to have these tools made.

i. Appendix D. Repair Parts and Special Tools List, gives a listing of repair parts, special tools, and support equipment required for the performance of direct support and general support maintenance of the periscope.

Section 2. DESCRIPTION AND DATA

1-3. DESCRIPTION

The M15 ballistics drive is part of the primary direct sighting and fire control system of the 165-mm gun, full tracked, combat engineer vehicle M728.


The ballistics drive causes a corresponding movement of the line of sight of the M32C periscope when the gun is elevated or depressed.

1-3. DESCRIPTION (CONT)

The ballistics drive has a cross shaft assembly (1) with support assemblies (2) and (3) which are fastened to mounting pads on the turret roof. A temperature compensating rod (4) with rod mounting bracket (5) is fastened to a pad inside the turret wall. A trunnion link (6) is connected to the gun trunnion. A fire control level (7) is mounted on the connecting arm (8). A coupling assembly (9) connects the ballistics drive to the elevation arm wedge of the M32C periscope.

1-4. TABULATED DATA

Length 36 in.
 Width 45 in.
 Height 31 in.
 Weight 100 lbs.



CHAPTER 2

GENERAL MAINTENANCE INFORMATION

Section 1. GENERAL

2-1. SCOPE

This chapter tells you where to find general information and what special tools and test equipment are needed to do the maintenance procedures in this volume.

Section 2. REFERENCE DOCUMENTS

2-2. GENERAL MAINTENANCE

General maintenance procedures for fire control materiel are in TM 9-254 and Job Performance Guide 113-091-9000R (JPG 41C).

2-3. CLEANING

General cleaning procedures are in JPG 41C.

2-4. PAINTING

General painting procedures are in TM 43-0139.

2-5. SEALING

General instructions for using sealing compounds are in JPG 41C.

2-6. LUBRICATION

General instructions on how to use lubricants are in JPG 41C.

Section 3. SAFETY PROCEDURES

2-7. GENERAL PROCEDURE

General safety procedures are found in AR 385-40 Safety: Accident Reporting and Records.

Section 4. SPECIAL TOOLS AND TEST EQUIPMENT

2-8. TOOLS AND TEST EQUIPMENT

Item	National Stock Number	Part Number (FSCM)	Use
Gage, Spacer	4931-00-065-0538	. . .	Setting distance between ballistics drive and M32C periscope.
Modified screw key 5/16 socket head.	Fabricated tool	. . .	Removing screws in support assembly.

CHAPTER 3

INSPECTION UPON RECEIPT

3-1. SCOPE

This chapter gives procedures to check the ballistics drive for faults you can see when received in DS/GS shop. Maintenance procedures are referenced for repair of the assembly. A complete inspection should be made and all faults listed on DA Form 2404 before taking any maintenance actions.

3-2. INSPECTION UPON RECEIPT

TOOLS: 5/16" modified socket head screw key (fabricated Allen wrench, see App. C)
1/2", 9/16", 3/4", 15/16" box end wrench

PERSONNEL: One

REFERENCES: TM 43-0139 for painting
TM 9-254 for general maintenance
JPG 4IC for Completing DA Form 2404
Installing lead seals

EQUIPMENT CONDITION: Ballistics drive mounted in vehicle.


NOTE

Once the ballistic drive is removed from vehicle DS/GS does not have the tools to accurately set the fire control level if the level is tampered with. If the fire control level needs to be repaired, repair before removing ballistic drive from vehicle.

3-2. INSPECTION UPON RECEIPT (CONT)

FRAME 1			
Step	Procedure	Maintenance Action	Reference
1.	Clean exterior of ballistic drive and check for cracks or dents.	If cracks or dents are found, tell your supervisor.	. . .
2.	Check ballistics drive for dirt and corrosion.	Clean	TM 9-254
3.	Check ballistic drive for free movement of cross shaft assembly (1) in left and right support assemblies (2) while operating manual elevation hand pump (3).	Send ballistics drive to depot for repair.	. . .
4.	Check surface (4) of left and right mounting supports (2) for damage.	Send ballistics drive to depot.	. . .
5.	Using fabricated Allen wrench, check four screws (5) are tight.	Tighten. Replace if missing.	. . .
6.	Using fabricated Allen wrench, check four screws (6) are tight.	Tighten. Replace if missing.	. . .
7.	Check two lead seals (7 and 8) are installed.	Install lead seals.	JPG 41C
8.	Check fire control level (9) is not damaged. GO TO FRAME 2	Repair level	Para 4-12


3-2. INSPECTION UPON RECEIPT (CONT)



3-2. INSPECTION UPON RECEIPT (CONT)

FRAME 2			
Step	Procedure	Maintenance Action	Reference
1.	Using 1/2" wrench, check four screws (1) are tight.	Tighten. Replace if missing.	...
2.	Check index mark on two eccentric caps (2) is clear.	a. Do maintenance procedures. b. Replace caps if damaged.	a. TM 9-254 b. Para 4-4, Frame 2 c. Para 4-5, Frame 5
3.	Check two scales (3) on eccentric (4) can be read.	Do maintenance procedures, if still not able to read, tell your supervisor.	TM 9-254
4.	Using 15/ 16" wrench, check two screws (5) are tight.	Tighten. Replace if missing.	...
5.	Using 15/ 16" wrench, check nut (6) is tight.	Tighten. Replace if missing.	...
6.	Using 9/16" wrench, check two screws (7) are tight.	Tighten. Replace if missing.	...
7.	Check two pins (8) are installed. GO TO FRAME 3	Install pins	Para 4-10


3-2. INSPECTION UPON RECEIPT (CONT)




3-2. INSPECTION UPON RECEIPT (CONT)

FRAME 3			
Step	Procedure	Maintenance Action	Reference
1.	Using 3/4" wrench, check two screws (1) are tight.	Tighten. Replace if	. . .
2.	Check nut (2) and cotter pin are not missing.	Tell your supervisor.	. . .
3.	Check threads on adjuster (3) are not damaged.	Replace adjuster.	Para 4-9
4.	Check washer (4) and cotter pin (5) are not missing on link pin (6).	Tell your supervisor.	. . .
5.	Check rubber boot (7) for damage, and two wires (8) are not missing.	Tell your supervisor.	. . .
6.	Check ballistic drive for chipped or scratched paint.	Paint chipped or scratched area.	TM 43-0139
	NOTE		
	FOLLOW-ON MAINTENANCE		
	Correct faults listed on DA Form 2404 that may affect performance test.		
	Do Performance Test (Vol I, para 2-2).		
	END OF TASK		

3-2. INSPECTION UPON RECEIPT (CONT)





CHAPTER 4

MAINTENANCE PROCEDURES

Section 1. GENERAL

4-1. SCOPE

This chapter gives maintenance procedures for the M15 Ballistics Drive.

4-2. LIST OF BALLISTICS DRIVE ITEMS CONTAINED IN THIS CHAPTER

Item	Figure Index No.	Reference (para)
Ballistics Drive	1	4-3
Trunnion Link	2	4-6
Temperature Compensating Rod	3	4-9
Fire Control Level	4	4-12

Section 2. BALLISTICS DRIVE

4-3. BALLISTICS DRIVE MAINTENANCE PROCEDURES INDEX

Task	Reference (para)
Removal	4-4
Installation	4-5

4-4. BALLISTICS DRIVE REMOVAL

TOOLS: 7/16", 15/16", 1/2", 9/16", 3/4" box end wrenches
 5/16" modified socket head screw key (fabricated Allen wrench,
 see App. C)
 1-1 / 16" open end wrench
 Wire cutters
 Pry bar
 #2 cross tip screwdriver (Phillips type)
 1/4" flat tip screwdriver

PERSONNEL: Two
 Repairman A: Holds ballistics drive
 Repairman B: Removes hardware

REFERENCES: TM 9-2350-222-10 for removing M32C periscope

EQUIPMENT CONDITION: Ballistics drive mounted in vehicle

PRELIMINARY PROCEDURES: Remove gunner's periscope M32C (TM 9-2350-222-10)


4-4. BALLISTICS DRIVE REMOVAL (CONT)

FRAME 1	
Step	Procedure
<ol style="list-style-type: none"> 1. Disconnect electrical plugs (1) from electrical connectors (2). 2. Using Phillips screwdriver, remove two screws (3) and two lockwashers (4) holding bracket (5) to ballistics drive. 3. Remove bracket (5) and attached switch. 4. Using 7/16" wrench, remove one screw (6) and one lockwasher (7), holding clamp assembly (8) to cross shaft assembly (9). 	<p style="text-align: center;">NOTE</p> <p style="text-align: center;">Clamp assembly (8) should remain in vehicle. Clamp assembly is not part of ballistics drive.</p>
<ol style="list-style-type: none"> 5. Remove clamp assembly (8) with limit stop attached. <p>GO TO FRAME 2</p>	

4-4. BALLISTICS DRIVE REMOVAL (CONT)

FRAME 2


Step	Procedure
1.	Using 1/2" wrench, remove four screws (1), four washers (2) and two caps (3) from connecting arm (4).
2.	Lower trunnion link (5) from connecting arm (4).
3.	Loosely put four screws (1), four washers (2) and two caps (3) on connecting arm (4) to prevent loss.
4.	Using 15/16" wrench, remove nut (6) and washer (7).
5.	Remove trunnion link (5) from gun trunnion (8).
6.	Loosely put washer (7) and nut (6) on trunnion link (5) to prevent loss.
GO TO FRAME 3	



4-4. BALLISTICS DRIVE REMOVAL (CONT)

FRAME 3	
Step	Procedure
<p>1.</p> <p>2.</p> <p>3.</p> <p>4.</p>	<p>Using 9/16" box end wrench, remove two screws (1), two lockwashers (2), and two flat washers (3) holding temperature compensating rod and bracket (4) to turret pad (5).</p> <p style="text-align: center;">CAUTION</p> <p style="text-align: center;">Be careful when using pry bar. Damage to two pins (6) may result.</p> <p>Using pry bar, remove bracket (7) from turret pad (5).</p> <p style="text-align: center;">NOTE</p> <p style="text-align: center;">Do steps 3 and 4 only if temperature compensating rod (4) is being removed for repair.</p> <p>Using 3/4" open end wrench, loosen two screws (8). Using wire cutter, remove wire seal (9) from adjuster (10).</p> <p>Using 1-1/16" wrench, remove adjuster (10) from ballistics drive (11).</p> <p>GO TO FRAME 4</p>

4-4. BALLISTICS DRIVE REMOVAL (CONT)

FRAME 4	Step Procedure
	<div style="text-align: center; border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p>WARNING</p> </div> <p style="text-align: center;">Be careful when removing ballistics drive, it is heavy and hard to handle. Do not drop as it may hurt someone or damage equipment.</p> <ol style="list-style-type: none"> 1. Repairman B, using fabricated Allen wrench, loosen, but do not remove eight screws (1). 2. Repairman A holds ballistics drive, Repairman B removes eight screws (1) and eight lockwashers (2). 3. Repairmen A and B, using pry bar, carefully pry and lower ballistics drive from turret roof. 4. Repairman A, inside vehicle, carefully hand ballistics drive through loader's hatch to Repairman B outside vehicle. 5. Using flat tip screwdriver, check that three screws (3) are tight and not missing. If loose, tighten and tell your supervisor. If missing send ballistic drive to depot for repair. <p>END OF TASK</p>
	 <p>The diagram illustrates the turret assembly with a ballistics drive mounted on top. Callout 1 points to screws on the turret housing. Callout 2 points to lockwashers. Callout 3 points to screws on the turret housing. The diagram shows the drive being held by a repairman and being lowered from the turret roof.</p>

4-5. BALLISTICS DRIVE INSTALLATION

TOOLS: 5/16" modified socket head screw key (fabricated Allen wrench,
see App. C)
Spacer gage
Electric drill
1/4" pin drive punch
15/64" drill bit
1/4" reamer
8 oz ball peen hammer
9/16", 7/16", and 3/4" box end wrench
1-1/16" and 15/16" open end wrench
#2 cross tip screwdriver (Phillips type)

SUPPLIES: Rags, clean (item 1, App. A)
Alcohol (item 2, App. A)

PERSONNEL: Two
Repairman A: Holds ballistic drive
Repairman B: Installs hardware

REFERENCES: JPG 41C for cleaning with alcohol

EQUIPMENT CONDITION: Ballistic drive in clean area next to parked vehicle


4-5. BALLISTICS DRIVE INSTALLATION (CONT)

FRAME 1	
Step	Procedure
<ol style="list-style-type: none"> 1. Using rags and alcohol, clean mounting pads on turret roof for right and left support assemblies (1) and (2) (JPG). 2. Check two pins (3) in left mounting pad are not damaged. If damaged, replace with good pin(s). 3. Repairman B, outside turret, carefully hand ballistics drive through loader's hatch to repairman A inside vehicle. <p>GO TO FRAME 2</p>	

4-5. BALLISTICS DRIVE INSTALLATION (CONT)

FRAME 2


Step	Procedure
1.	<p>Repairman A, lift ballistics drive (1) to put left support assembly (2) and right support assembly (3) on turret mounting pads.</p> <p style="text-align: center;">NOTE</p> <p style="text-align: center;">Make sure locating key (4) in right support assembly (3) is in line with keyway in turret mounting pad.</p>
2.	<p>Repairman B, loosely install eight washers (5) and eight screws (6) in left and right support assemblies (2) and (3) to hold support assemblies on turret mounting pads.</p> <p style="text-align: center;">NOTE</p> <p style="text-align: center;">Do not tighten screws (6) if installing a replacement ballistics drive.</p> <p>GO TO FRAME 3</p>



4-5. BALLISTICS DRIVE INSTALLATION (CONT)

FRAME 3	
Step	Procedure
	NOTE
	The oversize screw holes in right support assembly (1) lets right support assembly move back and forth from right to left to set the correct distance from M32C periscope. While moving right support assembly back and forth, cross shaft (2) slides inside bearing of left support assembly (3).
1.	Using spacer gage (4), set correct distance between V-shaped output coupling (5) and left outer machined surface of periscope mount by sliding cross shaft assembly (6) left or right.
	NOTE
	While tightening screws (7) keep checking distance with spacer gage (4) to make sure distance stays the same.
2.	Using fabricated Allen wrench, alternately tighten eight screws (7) in right and left support assemblies (1) and (3).
	NOTE
	Do step 3 only if new pins (8) are to be installed.
3.	Use holes in left or right support assemblies as guide and using drill and bit, drill new holes in turret pads.
4.	Using punch and hammer, install pins (8).
	GO TO FRAME 4


4-5. BALLISTICS DRIVE INSTALLATION (CONT)



4-5. BALLISTICS DRIVE INSTALLATION (CONT)

FRAME 4	
Step	Procedure
1.	Using rag and alcohol, clean turret mounting pad (1) (JPG).
	<div style="border: 1px dashed black; padding: 2px; width: fit-content; margin: 0 auto;">CAUTION</div> <p style="text-align: center;">Place gun tube at maximum elevation to prevent injury and to provide easier access to component.</p>
2.	Repairman A, position adjuster (2) into support arm (3). Turn adjuster (2) by hand to mesh threads.
3.	Repairman A, using 1-1/16" wrench, screw adjuster (2) into support arm (3) and rod (4) until clearance is enough to mount bracket (5) onto turret mounting pad (1). Make sure pin holes in bracket (5) are lined up with pins (6).
4.	Repairman A, guide bracket (5) onto turret mounting pad pins (6) while repairman B turns adjuster (2) clockwise to lengthen rod (4).
5.	Repairman B, using 9/16" wrench, install two screws (7), two lockwashers (3), and two flat washers (9) into mounting bracket (5) and mounting pad (1).
6.	Repairman A, using 3/4" wrench, tighten two screws (10) to support arm (3) and rod (4).
	GO TO FRAME 5


4-5. BALLISTICS DRIVE INSTALLATION (CONT)



4-5. BALLISTICS DRIVE INSTALLATION (CONT)

FRAME 5	
Step	Procedure
1.	Using hands, turn cross shaft (1) in both directions. Be sure cross shaft (1) turns freely.
2.	Using rag and alcohol, clean mounting hole on gun trunnion (2) for installing end of trunnion link (3) (JPG).
3.	Install stud end of trunnion link (3) in gun trunnion (2) and using 15/16" wrench, install washer (4) and nut (5).
4.	Remove four screws (6), four washers (7), and two caps (8) from connecting arm (9).
5.	Using 15/16" wrench, loosen two screws (10) on trunnion link (3).
6.	Raise free end of trunnion link (3) and put spindle (11) in bearing slot of connecting arm (9). Turn link tube (3) to lengthen or shorten the trunnion link (3) to make spindle (11) fit easily in the bearing slot of connecting arm (9) if necessary.
7.	Put two caps (8) on end of connecting arm (9) to hold end of trunnion link (3).
8.	Using 1/2" wrench, install four washers (7) and four screws (6) to hold two caps (8).
	GO TO FRAME 6



4-5. BALLISTICS DRIVE INSTALLATION (CONT)



4-5. BALLISTICS DRIVE INSTALLATION (CONT)

FRAME 6

Step	Procedure
1.	Using 7/16" wrench, install clamp assembly (1) (limit stop attached), using one screw (2) and one lockwasher (3).
2.	Using screwdriver, install bracket (4), switch (5) (attached) using two screws (6) and two lockwashers (7).
3.	Connect electrical plugs (8) to electrical connectors (9).
<p>NOTE</p> <p>FOLLOW-ON MAINTENANCE</p> <p>Do performance test (Vol I, para 2-2).</p> <p>END OF TASK</p>	



Section 3. TRUNNION LINK**4-6. TRUNNION LINK MAINTENANCE PROCEDURES INDEX**

Task	Reference (para)
Removal	4-4, Frame 2
Disassembly	4-7
Assembly	4-8
Installation	4-5, Frame 5

4-7. TRUNNION LINK DISASSEMBLY

TOOLS: 15/16" box end wrench
Wire cutters
Vise

PERSONNEL: One

EQUIPMENT CONDITION: Trunnion link on work bench

PRELIMINARY PROCEDURES: Remove trunnion link (para 4-4, Frame 2)

4-7. TRUNNION LINK DISASSEMBLY (CONT)


FRAME 1	
Step	Procedure
<ol style="list-style-type: none"> 1. Clamp tube (1) in vise. 2. Using wire cutter, cut and remove seal (2). 3. Using wrench, loosen screw (3). 4. Turn drive connector (4) clockwise until it comes off of tube (1). 5. Using wrench, loosen screw (5). 6. Turn link connector assembly (6) until it comes off of tube (1). <p>END OF TASK</p>	

4-8. TRUNNION LINK ASSEMBLY

TOOLS: 15/16" box end wrench
 Vise

PERSONNEL: One

EQUIPMENT CONDITION: Trunnion link on work bench

FRAME 1	
Step	Procedure
<ol style="list-style-type: none"> 1. Clamp tube (1) in vise. 2. Screw link connector assembly (2) on tube (1). 3. Using wrench, lightly tighten screw (3). 4. Screw drive connector assembly (4) counterclockwise on tube (1). 5. Using wrench, lightly tighten screw (5). 	<p>NOTE</p> <p>FOLLOW-ON MAINTENANCE</p> <p>Install trunnion link (para 4-5, Frame 5). Do performance test (Vol I, para 2-2).</p> <p>END OF TASK</p>
 <p>The diagram illustrates the assembly of a trunnion link. It shows a central tube (1) being clamped in a vise. On the left end, a link connector assembly (2) is being attached to the tube. A screw (3) is used to secure this assembly. On the right end, a screw drive connector assembly (4) is being attached to the tube. A screw (5) is used to secure this assembly. The diagram uses numbered callouts (1-5) to identify the tube, the left connector assembly, the left screw, the right connector assembly, and the right screw, respectively.</p>	

Section 4. TEMPERATURE COMPENSATING ROD

4-9. TEMPERATURE COMPENSATING ROD MAINTENANCE PROCEDURES INDEX

Task	Reference (para)
Removal	4-10
Installation	4-11

4-10. TEMPERATURE COMPENSATING ROD REMOVAL

TOOLS: 8 oz ball peen hammer
1/8" punch
1/2" brass drift pin
3/4" box end wrench
1-1/16" open end wrench

PERSONNEL: One

EQUIPMENT CONDITION: Temperature compensating rod and related parts on work bench

PRELIMINARY PROCEDURES: Remove temperature compensating rod and related parts (para 4-4, Frame 3)

4-10. TEMPERATURE COMPENSATING ROD REMOVAL (CONT)

FRAME 1	
Step	Procedure
<ol style="list-style-type: none"> 1. 2. 3. 4. 	<p>Using punch and hammer, drive out tapered pin (1) from smaller diameter end of tapered pin (1).</p> <p>Using brass drift pin and hammer, drive out straight pin (2) and remove bracket (3) from rod (4).</p> <p>Using wrench, remove screw (5) and lockwasher (6).</p> <p>Using 1-1/16" wrench, remove adjuster (7) from rod (4).</p> <p>END OF TASK</p>

4-11. TEMPERATURE COMPENSATING ROD INSTALLATION

TOOLS: 3/4" box end wrench
8 oz ball peen hammer

PERSONNEL: One

EQUIPMENT CONDITION: Temperature compensating rod and related parts on work bench

FRAME 1	
Step	Procedure
1.	Screw left hand thread end of adjuster (1) four turns counterclockwise into rod (2).
2.	Line up holes in mounting bracket (3) with hole in rod (2).
3.	Install pin (4) into bracket (3) and rod (2).
4.	Using hammer, install tapered pin (5).
5.	Using wrench, install, do not tighten, washer (6) and screw (7).
NOTE	
FOLLOW-ON MAINTENANCE:	
Install temperature compensating rod and related parts (para 4-5, Frame 4). Do performance test (Vol I, para 2-2).	
END OF TASK	

Section 5. FIRE CONTROL LEVEL

4-12. FIRE CONTROL LEVEL MAINTENANCE PROCEDURES INDEX

Task	Reference (para)
Removal	4-13
Disassembly	4-14
Assembly	4-15
Installation	4-16

4-13. FIRE CONTROL LEVEL REMOVAL

TOOLS: 1/4" flat tip screwdriver, offset
Soft face hammer

PERSONNEL: One

EQUIPMENT CONDITION: Ballistic drive mounted in vehicle

NOTE


Once the ballistic drive is removed from the vehicle DS/GS does not have the tools to accurately set the fire control level if removed from drive. If the fire control level needs to be repaired, repair before removing ballistic drive from vehicle.

4-13. FIRE CONTROL LEVEL REMOVAL (CONT)

FRAME 1

Step	Procedure
1.	Using screwdriver, remove two screws (1) and two lockwashers (2). NOTE Fire control level is mounted on two pins. It may require prying to remove it from ballistic drive. Pins should not be removed in normal removal or assembly.
2.	Using hammer, tap lightly on edge of fire control level (3) while pulling straight off.
3.	Remove fire control level (3) from pins (4) and ballistic drive (5).
END OF TASK	

4-13. FIRE CONTROL LEVEL REMOVAL (CONT)



4-14. FIRE CONTROL LEVEL DISASSEMBLY

TOOLS: 0.055 to 0.060 adjustable face spanner wrench
 4 oz ball peen hammer
 1/16" drive pin punch
 Machinist's scriber
 0.055 jeweler's screwdriver
 1/4" flat tip screwdriver

PERSONNEL: One

EQUIPMENT CONDITION: Fire control level on work bench

PRELIMINARY PROCEDURES: Remove fire control level from ballistic drive (para 4-13)

FRAME 1	
Step	Procedure
<ol style="list-style-type: none"> 1. 2. 3. 4. 	<p>Using spanner wrench, remove threaded ring (1) from housing (2).</p> <p>Remove eccentric (3) from end of housing (2).</p> <p>Slide level vial tube (4) through cover (5) and housing (2).</p> <p>Remove cover (5) from housing (2).</p> <p style="text-align: center;">NOTE</p> <p style="text-align: center;">Do step 5 only if pin (6) is damaged.</p> <p>5. Using hammer and punch, drive pin (6) from housing (2).</p> <p>END OF TASK</p>

4-15. FIRE CONTROL LEVEL ASSEMBLY

TOOLS: 0.055 to 0.060 adjustable face spanner wrench
 4 oz. ballpeen hammer
 1/16" drive pin punch
 0.055 jeweler's screwdriver
 1/4" flat tip screwdriver

PERSONNEL: One

EQUIPMENT CONDITION: Fire control level on work bench

FRAME 1	
Step	Procedure
	<p>NOTE</p> <p>Do step 1 only if pin (1) was removed.</p> <ol style="list-style-type: none"> 1. Using hammer and punch, install pin (1) in housing (2). 2. Position cover (3) on housing (2) and hold in place while installing level vial tube (4). Make sure level vial tube (4) is lined up with pin (1) in housing (2). 3. Place eccentric (5) into threaded ring (6). 4. Using spanner wrench, install threaded ring (6) with eccentric (5). Do not tighten. 5. Install and adjust fire control level (para 4-16). <p>END OF TASK</p>

4-16. FIRE CONTROL LEVEL INSTALLATION

TOOLS: 1/4" flat tip screwdriver, offset
 Soft face hammer
 M1A1 gunner's quadrant


PERSONNEL: One

REFERENCES: TM 9-2350-222-10 for Elevating and depressing gun
 Using M1A1 gunner's quadrant

EQUIPMENT CONDITION: Ballistic drive mounted in vehicle; vehicle on level ground

FRAME 1	
Step	Procedure
	<p>NOTE</p> <p>If pins were removed or are being replaced, start with step 1. If not, go to step 3.</p>
1.	Place two pins (1) in holes in ballistic drive (2).
2.	Using hammer, tap pins (1) gently until they are in place.
3.	Position fire control level (3) on pins (1) evenly.
4.	Using hammer, tap fire control level (3) gently to install on pins (1).
5.	Using 1/4" offset screwdriver, install two washers (4) and two screws (5).
6.	Place gunner's quadrant on breech (6) leveling pads (TM-10).
7.	Elevate or depress gun until level bubble in gunner's quadrant is centered (TM-10).
	GO TO FRAME 2


4-16. FIRE CONTROL LEVEL INSTALLATION (CONT)



4-16. FIRE CONTROL LEVEL INSTALLATION (CONT)

FRAME 2	
Step	Procedure
1.	<p>Check ballistic drive fire control level bubble (1) is centered.</p> <p style="text-align: center;">NOTE</p> <p style="text-align: center;">If bubble is centered, go to step 4; if not, continue with step 2.</p>
2.	Using spanner wrench, loosen ring (2) slightly.
3.	Using 3/16" screwdriver, turn eccentric (3) left or right until level vial assembly bubble (1) is centered.
	<p>NOTE</p> <p>Eccentric (2) may have to be held in position with 3/16" screwdriver to prevent it from turning when doing next step.</p>
4.	Using spanner wrench, tighten ring (2).
5.	Check level vial assembly bubble (1) remains centered. If not, repeat steps 2 through 5.
6.	Remove gunner's quadrant.
	<p>NOTE</p> <p>FOLLOW-ON MAINTENANCE</p> <p>Do performance test (Vol I, Chap 2)</p> <p>END OF TASK</p>

4-16. FIRE CONTROL LEVEL INSTALLATION (CONT)



CHAPTER 5

FINAL INSPECTION

5-1. SCOPE

This chapter gives final inspection procedures to be done after repairing the ballistics drive.

5-2. FINAL INSPECTION

PERSONNEL: One


REFERENCES: JPG 41C for cleaning
TM 9-2350-222-10 for elevating and depressing gun.

EQUIPMENT CONDITION: Ballistics drive installed in vehicle

NOTE

If you find a fault, tell your supervisor. If you do not find a fault, send the good ballistics drive back to service.

5-2. FINAL INSPECTION (CONT)

FRAME 1	
Step	Procedure
<ol style="list-style-type: none"> 1. Check ballistics drive for loose or missing parts. 2. Check ballistics drive is free of dirt and corrosion. If ballistic drive has dirt or corrosion, clear (JPG). 3. Elevate and depress gun (TM-10). Check movement of ballistics drive is smooth with no binding (TM-10). 4. Check two seals (1 and 2) are installed. <p>END OF TASK</p>	
	

CHAPTER 6

PACKAGING

6-1. SCOPE

This chapter provides information on packaging of the ballistics drive for storage or shipment.

6-2. PACKAGING OF ASSEMBLIES

Package and pack the ballistics drive in accordance with MIL-P-11G, AR 700-15, TM 9-200, and MIL-P-14232/P10516375.

APPENDIX A

EXPENDABLE SUPPLIES AND MATERIALS LIST

Section 1. INTRODUCTION

A-1. SCOPE

This appendix lists expendable supplies and materials you will need to repair the ballistics drive. These items are authorized to you by CTA 50-970, Expendable Items (Except Medical, Class V, Repair Parts, and Heraldic Items).

A-2. EXPLANATION OF COLUMNS

a. Column 1 - Item number. This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the material, e.g., cotton flannel cloth (item 1, App. A).

b. Column 2- Level. This column identifies the lowest level of maintenance that requires the listed items.

F - Direct Support Maintenance

H - General Support Maintenance

c. Column 3 - National Stock Number. This is the National stock number assigned to the item; use it to request or requisition the item.

d. Column 4 - Description. Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the part number followed by the Federal Supply Code for Manufacturer (FSCM) in parentheses, if applicable.

e. Column 5 - Unit of Measure (U/M). Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr). If the unit of measure differs from the unit of issue, requisition the lowest of issue that will satisfy your requirements.

Section 2. EXPENDABLE SUPPLIES AND MATERIALS

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
1	F	7920-00-205-1711	Rags, Clean 50 lbs	LB
2	F	6810-00-264-5906	Alcohol, Ethyl 0-C-265 16 oz bottle	BT

APPENDIX B
MAINTENANCE TASK INDEX

B-1. SCOPE

This appendix helps you find maintenance tasks for the ballistics drive by giving you references to the procedures.

APPENDIX C


FABRICATED TOOL

C-1. SCOPE

This section gives the procedure to modify the 5/16" socket head screw key (Allen wrench or equivalent) for use on the M15 ballistics drive.

C-2. PROCEDURE

- a. Get a standard 5/16" socket head screw key.
- b. Cut 3/4" off short end of wrench.



APPENDIX D

DIRECT SUPPORT AND

GENERAL SUPPORT MAINTENANCE

REPAIR PARTS AND SPECIAL TOOLS LIST

(INCLUDING DEPOT MAINTENANCE REPAIR PARTS

AND SPECIAL TOOLS)

Section I. INTRODUCTION

D-1. SCOPE

This appendix lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of direct support, and general support and depot maintenance of the Ballistic Drive M15. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

equipment authorized for the performance of maintenance.

c. Section IV. National Stock Number and Part Number Index. A list in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list in alphameric sequence of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

D-2. GENERAL

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. A list of special-tools, special TMDE, and other special support

D-3. EXPLANATION OF COLUMNS

a. Illustration. This column is divided as follows:

(1) Figure Number. Indicates the figure number of the illustration on which the item is shown.

(2) Item Number. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source Code. Source codes indicate the manner of acquiring

support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

Code	Definition
PA	-Item procured and stocked for anticipated or known usage.
PB	-Item procured and stocked for insurance purpose because essentiality dictates that a minimum quantity be available in the supply system.
PC	-Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD	-Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	-Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF	-Support equipment which will not be stocked but which will be centrally procured on demand.
PG	-Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown

of production facilities, would prove uneconomical to reproduce at a later time.

KD	-An item of a depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF	-An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance.
KB	-Item included in both a depot overhaul/repair kit and a maintenance kit.
MO	-Item to be manufactured or fabricated at organizational level.
MF	-Item to be manufactured or fabricated at the direct support maintenance level.
MH	-Item to be manufactured or fabricated at the general support maintenance level.
MD	-Item to be manufactured or fabricated at the depot maintenance level.
AO	-Item to be assembled at organizational level.
AF	-Item to be assembled at direct support maintenance level.
AH	-Item to be assembled at general support maintenance level.

		Code	Application/Explanation
AD	-Item to be assembled at depot maintenance level.		
XA	-Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.	C	-Crew or operator maintenance performed within organizational maintenance.
		O	-Support item is removed, replaced, used at the organizational level.
XB	-Item is not procured or stocked. If not available through salvage, requisition.	F	-Support item is removed, replaced, used at the direct support level.
XC	-Installation drawing, diagram, instruction sheet, field service drawing, that is identified by manufacturer's part number.	H	-Support item is removed, replaced, used at the general support level.
XD	-A support item that is not stocked. When required, item will be procured through normal supply channels.	D	-Support items that are removed, replaced, used at depot, mobile depot, or specialized repair activity only.

NOTE : Cannibalization or salvage may be used as a source of supply for any items coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes.

(2) Maintenance Code.
Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code	Application/Explanation
O	-The lowest maintenance level capable of complete repair of the support item is the organizational level.
F	-The lowest maintenance level capable of complete repair of the support item is the direct support level.
H	-The lowest maintenance level capable of complete repair of the support item is the general support level.

- D -The lowest maintenance level capable of complete repair of the support item is the depot level.
- L -Repair restricted to Specialized Repair Activity. (Not Applicable).
- Z -Nonreparable. No repair is authorized.
- B -No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item.

(3) Recoverability Code.

Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recover-
ability
Codes

Definition

- Z -Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
- O -Reparable item. When uneconomically reparable, condemn and dispose at organizational level.
- F -Reparable item. When uneconomically reparable, condemn and dispose at the direct support level.
- H Repairable item. When uneconomically reparable, condemn and dispose at the general support level.

- D -Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
- L -Reparable item. Repair, condemnation, and disposal not authorized below depot/specialized repair activity level.
- A -Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material). Refer to appropriate manuals/directives for specific instructions.

c. National Stock Number.

Indicates the National stock number assigned to the item and which will be used for requisitioning.

d. Federal Supply Code for Manufacturer (FSCM). The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.

e. Part Number. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE: When a stock numbered item is requisitioned, the item received may have a different part number than the part being replaced.

f. Description. Indicates the Federal item name and, if required, a minimum description to identify the item. In the Special Tools List, the initial basis of issue (BOI) appears as the last line in the entry for each special tool, special TMDE, and other special support equipment. When density of equipments supported exceeds density spread indicated in the basis of issue, the total authorization is increased accordingly.

g. Unit of Measure (U/M). Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. Quantity Incorporated in Unit. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of a quantity indicates that no specific quantity is applicable, (e.g., shims, spacers, etc).

D-4. SPECIAL INFORMATION

(Not Applicable)

D-5. HOW TO LOCATE REPAIR PARTS

a. When National Stock Number or Part Number is Unknown:

(1) First. Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups, and listings are divided into the same groups.

(2) Second. Find the illustration covering the functional group to which the item belongs.

(3) Third. Identify the item on the illustration and note the illustration figure and item number of the item.

(4) Fourth. Using the Repair Parts Listing, find the figure and item number noted on the illustration.

b. When National Stock Number or Part Number is Known:

(1) First. Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphameric sequence, cross-referenced to the illustration figure number and item number.

(2) Second. After finding the figure and item number, locate the figure and item number in the repair parts list.

D-6. ABBREVIATIONS

(Not Applicable)

Section II

REPAIR PARTS LIST





Figure D-1. Ballistic drive M15 10516375 including Link assembly 8620208

(1) ILLUSTRATION (a) FIG NO	(2) (b) ITEM NO	SMR CODE	TM9-1220-231-34&P (3) NATIONAL STOCK NUMBER	(4) FSCM	(5) PART NUMBER	(6) DESCRIPTION	USABLE ON CODE	(7) U/M	(8) QTY INC IN UNIT
GROUP OO BALLISTIC DRIVE M15 10516375									
INCLUDING									
GROUP 0001 LINK ASSEMBLY 8620208									
D-1	1	PAFZZ	5340-00-491-7632	96906	MS51938-5	SEAL,ANTIPIRFERAGE		EA	2
D-1	2	PAFZZ	5310-00-169-9779	19200	10516551	NUT,PLAIN,SLOTTED		EA	1
D-1	3	PAFZZ	3120-00-661-3201	19200	8201215	BEARING,WASHER		EA	1
D-1	4	AFFFF		19200	8620208	LINK ASSEMBLY		EA	1
D-1	5	PAFZZ	1220-00-144-5490	19200	10516116	.CONNECTOR,DRIVE		EA	1
D-1	6	PAFZZ	1220-00-432-1358	19200	8620092	.LINK,CONNECTOR		EA	1
D-1	7	PAFZZ	1220-00-432-1356	19200	8620209	.TUBE DRIVE		EA	1
D-1	8	PAFZZ	5305-00-995-6311	96906	MS35207-271	SCREW,MACHINE		EA	2
D-1	9	PAFZZ	5310-00-926-5877	96906	MS35338-160	WASHER,LOCK		EA	10
D-1	10	PAFZZ	5310-00-990-0700	19200	8620134	WASHER,FLAT		EA	2
D-1	11	PAFZZ	5315-00-901-2190	96906	MS16556-648	PIN,STRAIGHT		EA	2
D-1	12	PAFZZ	5315-00-083-0432	96906	MS35672-31	PIN,GROOVED		EA	1
D-1	13	PAFZZ	5315-00-046-6292	19200	10516092	PIN,STRAIGHT		EA	1
D-1	14	XDFZZ		19200	10516093	BRACKET		EA	1
D-1	15	PAFZZ	5305-00-702-4524	96906	MS35308-413	SCREW,CAP,HEXAGON HEAD		EA	2
D-1	16	PAFZZ	5310-00-933-8778	96906	MS35338-143	WASHER,LOCK		EA	2
D-1	17	PAFZZ	1220-01-091-3591	19200	8620212	ROD,BALLISTIC DRIVE		EA	1
D-1	18	PAFZZ	1220-00-477-9910	19200	8620110	ADJUSTER,DRIVE		EA	1
D-1	19	PADZZ	5305-00-051-4078	96906	MS90727-36	SCREW,CAP,HEXAGON HEAD		EA	4
D-1	20	PADZZ	5310-00-974-6623	96906	MS35338-140	WASHER,LOCK		EA	4
D-1	21	PADZZ	9905-00-432-1357	19200	10516380	PLATE, IDENTIFICATION		EA	1
D-1	22	PAFZZ	5305-00-978-9395	96906	MS16997-100	SCREW,CAP		EA	8
D-1	23	PAFZZ	5310-00-903-2612	96906	MS9321-12	WASHER,FLAT		EA	4
D-1	24	PAFZZ	1220-00-712-8397	19200	8620113	PIN		EA	2
D-1	25	PAFZZ	5315-00-663-1284	96906	MS35675-40	PIN,GROOVED		EA	1
D-1	26	XDDDD		19200	10516381	SHAFT ASSEMBLY		EA	1

(1) ILLUSTRATION (a) FIG NO	(b) ITEM NO	(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) FSCM	(5) PART NUMBER	TM9-1220-231-34&P (6) DESCRIPTION	(7) U/M	(8) QTY INC IN UNIT
						GROUP 0002 SHAFT ASSEMBLY 10516381	USABLE ON CODE	
D-2	1	PAFZZ	5305-00-912-4818	96906	MS35276-261	SCREW,MACHINE	EA	2
D-2	2	PAFZZ	5310-00-933-8119	96906	MS35338-137	WASHER,LOCK	EA	2
D-2	3	PAFFF	1290-00-432-1355	19200	8585560	LEVEL,FIRE CONTROL	EA	1
D-2	4	PAFZZ	5315-00-905-8431	96906	MS16556-626	PIN,STRAIGHT	EA	2
D-2	5	PAFZZ	5305-00-051-4078	96906	MS90727-36	SCREW,CAP HEXAGON HEAD	EA	4
D-2	6	PAFZZ	5310-00-974-6623	96906	MS35338-140	WASHER,LOCK	EA	4
D-2	7	PAFZZ	1220-00-676-2185	19200	8620112	CAP,DRIVE	EA	2
D-2	8	PADZZ	5310-00-108-9654	19200	10516552	NUT,PLAIN,SLOTTED	EA	1
D-2	9	PADZZ	5310-00-595-5818	19200	8201146	WASHER,FLAT	EA	1
D-2	10	PADZZ	5315-00-144-8218	96906	MS24692-375	PIN,TAPERED,PLAIN	EA	2
D-2	11	XDDZZ		19200	10516274	ARM	EA	1
D-2	12	PADZZ	5305-00-054-6668	96906	MS51957-43	SCREW,MACHINE	EA	3
D-2	13	PADZZ	5310-00-933-8119	96906	MS35338-137	WASHER,LOCK	EA	3
D-2	14	PADZZ	5365-01-091-3683	19200	8201244	SPACER,RING	EA	1
D-2	15	XDDZZ		19204	8201231	SEAL RETAINER ASSY	EA	1
D-2	16	PADZZ	5365-00-419-0750	96906	MS16626-4156	RING,RETAINING	EA	2
D-2	17	PADZZ	3110-00-277-0313	19200	8201542	BEARING,BALL	EA	1
D-2	18	XDDZZ		19200	10516383	SUPPORT ASSEMBLY	EA	1
D-2	19	PADZZ	5305-00-582-8184	19200	8605989	SCREW,SELF-LOCKING	EA	4
D-2	20	ADDDD		19200	8620124	COUPLING ASSEMBLY	EA	1
D-2	21	PADZZ	1220-00-357-6124	19200	11727429	CLAMP,REUSUABLE	EA	2
D-2	22	PADZZ	1220-00-357-6136	19200	11727433	BOOT,DUST AND MOISTURE SEAL	EA	1
D-2	23	PADZZ	5360-00-584-0168	19200	8229116	SPRING,HELICAL	EA	1
D-2	24	PADZZ	1220-00-612-1434	19200	8229115	PLUNGER,DETENT	EA	2
D-2	25	PADZZ	5360-00-584-0166	19200	8298370	SPRING,HELICAL	EA	4
D-2	26	PADZZ	1220-00-612-1437	19200	8298369	PLUNGER,DETENT	EA	4
D-2	27	PADZZ	1240-00-933-9627	19200	8298358	SLIDER	EA	1
D-2	28	PADZZ	5305-00-225-7774	96906	MS16996-24	SCREW,CAP,SOCKET HEAD	EA	2
D-2	29	PADZZ	5310-00-143-6272	96906	MS51848-10	WASHER,LOCK	EA	2
D-2	30	XDDZZ		19200	8621087	ADAPTER	EA	1
D-2	31	PADZZ	5310-00-950-2666	19200	8620153	NUT,PLAIN,ROUND	EA	1
D-2	32	PADZZ	5305-00-281-3118	96906	MS51021-32	SETSCREW	EA	1
D-2	33	PADZZ	5340-00-685-0831	19200	8620013	DISK,SOLID,PLAIN	EA	1
D-2	34	XDDZZ		19200	8620146	RING,EXTERNALLY	EA	1
D-2	35	PADZZ	3110-00-142-7049	19200	8620150	BEARING,BALL	EA	1
D-2	36	XDDZZ		19200	8620148	SUPPORT	EA	1
D-2	37	XDDZZ		19200	10516370	SHAFT 4	EA	1



AR 924453

Figure D-3. Fire control level 8585560

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
FIG NO	ITEM NO	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	USABLE ON CODE	QTY INC IN UNIT
D-3	1	PAFZZ	5365-00-692-149	19200	8202181	RING, EXTERNALLY.....		1
D-3	2	PAFZZ	1290-00-896-225	19200	8202177	ECCENTRIC.....		
D-3	3	PAFZZ	5315-00-817-088	96906	MS16555-601	PIN, STRAIGHT.....		
D-3	4	PAFZZ	1290-00-692-149	19200	8202183	LEVEL, FIRE CONTROL.....		
D-3	5	PAFZZ	1290-00-896-223	19200	8215835	COVER, LEVEL VIAL.....		
D-3	6	XDFZZ		19200	8585561	HOUSING, LEVEL VIAL.....		
GROUP 000201 FIRE CONTROL LEVEL 8585560.								





Figure D-4. Coupling assembly 8620124

ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
FIG NO.	FEM NO.	SMR CODE	NATIONAL STOCK NUMBER	FSCM	PART NUMBER	DESCRIPTION	USABLE ON CODE	QTY INC IN UNIT
GROUP 000202 COUPLING ASSEMBLY 8620124								
D-4	1	PADZZ	5305-00-954-8427	16905	MS 16978-1 B	SCREW, CAP.....		EA 1
D-4	2	PADZZ	5310-00-953-8114	96908	MS33058-137	WASHER, LOCK.....		EA 1
D-4	3	PADZZ	5305-00-753-4441	19200	8620147	SCREW, SHOULDER.....		EA 1
D-4	4	PADZZ	5310-00-660-3381	96906	MS21083N5	NUT, SELF-LOCKING.....		EA 1
D-4	5	PADZZ	5360-00-753-3985	19200	8620125	SPRING, HELICAL.....		EA 1
D-4	6	PADZZ	1240-00-933-9271	19200	8620151	LEVER.....		EA 1
D-4	7	PADZZ	1240-00-933-9272	19200	8620152	COUPLING.....		EA 1

Section III

SPECIAL TOOLS LIST



AR 924455

Figure D-5. Special Tools

(1) ILLUSTRATION		(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) FSCM	(5) PART NUMBER	(6) DESCRIPTION	(7) J.M.	(8) QTY INC IN UNIT
FIG NO	REV NO					USABLE ON CODE		
D-3		PEFZZ	4931-00-065-0538	192C	8566947	GROUP 95 SPECIAL TDCLS GAGE, SPACER..... BOI 1 AUTH PER BN HQ WHEN BN HAS A SVC COMPANY		EA

Section IV

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
5315-00-046-6292	D-1	13	5315-00-663-1284	D-1	25
5305-00-051-4078	D-1	19	1220-00-676-2185	D-2	7
5305-00-051-4078	D-2	5	5340-00-685-0831	D-2	33
5305-00-054-6668	D-2	12	5365-00-692-1492	D-3	1
4931-00-065-0538	D-5	1	1290-00-692-1493	D-3	4
5315-00-083-0432	D-1	12	5305-00-702-4524	D-1	15
5310-00-108-9654	D-2	8	1220-00-712-8397	D-1	24
3110-00-142-7049	D-2	35	5360-00-753-3985	D-4	5
5310-00-143-6272	D-2	29	5305-00-753-4444	D-4	3
1220-00-144-5490	D-1	5	5315-00-817-0889	D-3	3
5315-00-144-8218	D-2	10	1290-00-896-2239	D-3	5
5310-00-169-9779	D-1	2	1290-00-896-2251	D-3	2
5305-00-225-7774	D-2	28	5315-00-901-2190	D-1	11
3110-00-277-0313	D-2	17	5310-00-903-2612	D-1	23
5305-00-281-3118	D-2	32	5315-00-905-8431	D-2	4
1220-00-357-6124	D-2	21	5305-00-912-4818	D-2	1
1220-00-357-6136	D-2	22	5310-00-926-5877	D-1	9
5365-00-419-0750	D-2	16	5310-00-933-8119	D-2	2
1290-00-432-1355	D-2	3	5310-00-933-8119	D-2	13
1220-00-432-1356	D-1	7	5310-00-933-8119	D-4	2
9905-00-432-1357	D-1	21	5310-00-933-8778	D-1	16
1220-00-432-1358	D-1	6	1240-00-933-9271	D-4	6
1220-00-477-9910	D-1	18	1240-00-933-9272	D-4	7
5340-00-491-7632	D-1	1	1240-00-933-9627	D-2	27
5305-00-582-8184	D-2	19	5310-00-950-2666	D-2	31
5360-00-584-0166	D-2	25	5305-00-954-8424	D-4	1
5360-00-584-0168	D-2	23	5310-00-974-6623	D-1	20
5310-00-595-5818	D-2	9	5310-00-974-6623	D-2	6
1220-00-612-1434	D-2	24	5305-00-978-9395	D-1	22
1220-00-612-1437	D-2	26	5310-00-990-0700	D-1	10
5310-00-660-3381	D-4	4	5305-00-995-6311	D-1	8
3120-00-661-3201	D-1	3	1220-01-091-3591	D-1	17
			5365-01-091-3683	D-2	14

FSCM	PART NUMBER	FIGURE NO.	ITEM NO.	FSCM	PART NUMBER	FIGURE NO.	ITEM NO.
96906	MS16555-601	D-3	3	19200	11727433	D-2	22
96906	MS16556-626	D-2	4	19200	8201146	D-2	9
96906	MS16556-648	D-1	11	19200	8201215	D-1	3
96906	MS16626-4156	D-2	16	19204	8201231	D-2	15
96906	MS16996-24	D-2	28	19200	8201244	D-2	14
96906	MS16997-100	D-1	22	19200	8201542	D-2	17
96906	MS16998-18	D-4	1	19200	8202177	D-3	2
96906	MS21083N5	D-4	4	19200	8202181	D-3	1
96906	MS24692-375	D-2	10	19200	8202183	D-3	4
96906	MS35207-271	D-1	8	19200	8215835	D-3	5
96906	MS35276-261	D-2	1	19200	8229115	D-2	24
96906	MS35308-413	D-1	15	19200	8229116	D-2	23
96906	MS35338-137	D-2	2	19200	8298358	D-2	27
96906	MS35338-137	D-2	13	19200	8298369	D-2	26
96906	MS35338-137	D-4	2	19200	8298370	D-2	25
96906	MS35338-140	D-1	20	19200	8566947	D-5	1
96906	MS35338-140	D-2	6	19200	8585560	D-2	3
96906	MS35338-143	D-1	16	19200	8585561	D-3	6
96906	MS35338-160	D-1	9	19200	8605989	D-2	19
96906	MS35672-31	D-1	12	19200	8620013	D-2	33
96906	MS35675-40	D-1	25	19200	8620092	D-1	6
96906	MS51021-32	D-2	32	19200	8620110	D-1	18
96906	MS51848-10	D-2	29	19200	8620112	D-2	7
96906	MS51938-5	D-1	1	19200	8620113	D-1	24
96906	MS51957-43	D-2	12	19200	8620124	D-2	20
96906	MS90727-36	D-1	19	19200	8620125	D-4	5
96906	MS90727-36	D-2	5	19200	8620134	D-1	10
96906	MS9321-12	D-1	23	19200	8620146	D-2	34
19200	10516092	D-1	13	19200	8620147	D-4	3
19200	10516093	D-1	14	19200	8620148	D-2	36
19200	10516116	D-1	5	19200	8620150	D-2	35
19200	10516274	D-2	11	19200	8620151	D-4	6
19200	10516370	D-2	37	19200	8620152	D-4	7
19200	10516380	D-1	21	19200	8620153	D-2	31
19200	10516381	D-1	26	19200	8620203	D-1	4
19200	10516383	D-2	18	19200	8620209	D-1	7
19200	10516551	D-1	2	19200	8620212	D-1	17
19200	10516552	D-2	8	19200	8621087	D-2	30
19200	11727429	D-2	21				

By Order of the Secretary of the Army:

JOHN A. WICKHAM, JR.
General, United States Army
Chief of Staff

Official:

ROBERT M. JOYCE
Major General, United States Army
The Adjutant General

DISTRIBUTION :

To be distributed in accordance with DA Form 12-41, Direct and General Support Maintenance requirements for Ballistic Drive.

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

Your mailing address

DATE SENT

Date you send in form

PUBLICATION NUMBER

TM 9-1220-231-34&P

PUBLICATION DATE

25 Nov 83

PUBLICATION TITLE

Ballistic Drive: M15

BE EXACT... PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.
3		2	
109		51	
2-8			2-1
12	1-6a		

Item 10. Change illustration. Reason: Tube end shown assembled on wrong side of lever cam.

Item 3. The NSN and P/N are not listed on the AMDF nor the MGRL. Request correct NSN and P/N furnished.

Preventive Maintenance Checks and Services. Item 7 under "Items to be inspected" should be changed to read as follows: Firing linkage and firing mechanism pawl.

Since there are both 20- and 30- round magazines for this rifle, data on both should be listed.

SAMPLE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

JOHN SMITH SP/3 XXX-XXXX

SIGN HERE:

John Smith

DA FORM 2028-2 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.

IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

TEAR ALONG DOTTED LINE

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



TEAR ALONG PERFORATED LINE

Commander
US Army Armament, Munitions and Chemical Command
ATTN: DRSMC-MAS
Rock Island, IL 61299

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



TEAR ALONG PERFORATED LINE

Commander
US Army Armament, Munitions and Chemical Command
ATTN: DRSMC-MAS
Rock Island, IL 61299

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 9-1220-231-34&P

PUBLICATION DATE

25 Nov 83

PUBLICATION TITLE

Ballistic Drive: M15

BE EXACT... PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PAGE NO.

PARA-GRAPH

FIGURE NO.

TABLE NO.

TEAR ALONG DOTTED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



TEAR ALONG THIS LINE

Commander
US Army Armament, Munitions and Chemical Command
ATTN: DRSMC-MAS
Rock Island, IL 61299

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 9-1220-231-34&P

PUBLICATION DATE

25 Nov 83

PUBLICATION TITLE

Ballistic Drive: M15

BE EXACT... PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PAGE NO.

PARA-GRAPH

FIGURE NO.

TABLE NO.

TEAR ALONG DASHED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314



Commander
US Army Armament, Munitions and Chemical Command
ATTN: DRSMC -MAS
Rock Island, IL 61299

TEAR ALONG PERFORATED LINE

THE METRIC SYSTEM AND EQUIVALENTS

LINEAR MEASURE

1 Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
 1 Kilometer = 1000 Meters = 0.621 Miles

SQUARE MEASURE

1 Sq Centimeter = 100 Sq Millimeters = 0.155 Sq Inches
 1 Sq Meter = 10,000 Sq Centimeters = 10.76 Sq Feet
 1 Sq Kilometer = 1,000,000 Sq Meters = 0.386 Sq Miles

WEIGHTS

1 Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces
 1 Kilogram = 1000 Grams = 2.2 Lb
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

CUBIC MEASURE

1 Cu Centimeter = 1000 Cu Millimeters = 0.06 Cu Inches
 1 Cu Meter = 1,000,000 Cu Centimeters = 35.31 Cu Feet

LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces


TEMPERATURE

$5/9 (^{\circ}\text{F} - 32) = ^{\circ}\text{C}$
 212^o Fahrenheit is equivalent to 100^o Celsius
 90^o Fahrenheit is equivalent to 32.2^o Celsius
 32^o Fahrenheit is equivalent to 0^o Celsius
 $9/5 \text{ C}^{\circ} + 32 = \text{F}^{\circ}$

APPROXIMATE CONVERSION FACTORS

<u>TO CHANGE</u>	<u>TO</u>	<u>MULTIPLY BY</u>
Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	0.914
Miles	Kilometers	1.609
Square Inches	Square Centimeters	6.451
Square Feet	Square Meters	0.093
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	0.405
Cubic Feet	Cubic Meters	0.028
Cubic Yards	Cubic Meters	0.765
Fluid Ounces	Milliliters	29.573
Pints	Liters	0.473
Quarts	Liters	0.946
Gallons	Liters	3.785
Ounces	Grams	28.349
Pounds	Kilograms	0.454
Short Tons	Metric Tons	0.907
Pound-Feet	Newton-Meters	1.356
Pounds per Square Inch	Kilopascals	6.895
Miles per Gallon	Kilometers per Liter	0.425
Miles per Hour	Kilometers per Hour	1.609

<u>TO CHANGE</u>	<u>TO</u>	<u>MULTIPLY BY</u>
Centimeters	Inches	0.394
Meters	Feet	3.280
Meters	Yards	1.094
Kilometers	Miles	0.621
Square Centimeters	Square Inches	0.155
Square Meters	Square Feet	10.764
Square Meters	Square Yards	1.196
Square Kilometers	Square Miles	0.386
Square Hectometers	Acres	2.471
Cubic Meters	Cubic Feet	35.315
Cubic Meters	Cubic Yards	1.308
Milliliters	Fluid Ounces	0.034
Liters	Pints	2.113
Liters	Quarts	1.057
Liters	Gallons	0.264
Grams	Ounces	0.035
Kilograms	Pounds	2.205
Metric Tons	Short Tons	1.102
Newton-Meters	Pound-Feet	0.738
Kilopascals	Pounds per Square Inch	0.145
Kilometers per Liter	Miles per Gallon	2.354
Kilometers per Hour	Miles per Hour	0.621



DEPARTMENT OF THE ARMY
US ARMY AG PUBLICATIONS CENTER
1655 WOODSON ROAD
ST. LOUIS, MISSOURI 63114

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY

G-5
SPECIAL FOURTH
CLASS BOOK RATE

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE, \$300

CDR
LSA DARCCM MAT READ SPT
ACTV ATTN DRXMD-MF
LEXINGTON
MC497
KY 40511

DA PUBLICATION/FORM NUMBER			CHG OR DATE	
TM 9-1220-231-342F				
LOCATION	QUANTITY	UNIT OF ISSUE	ACTION	RON DATE
B1	2	INITIAL-DIST.		
PKG SIZE	ITEM NO.	BULK/RCPT DATE	SLAGPC CONTROL NO.	
3786			IC-3333-65806	

TAGO FORM 4-26a, 1 SEP 78

PREVIOUS EDITION OF THIS FORM IS OBSOLETE