

TM 9-1240-375-34&P

TECHNICAL MANUAL

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST) FOR

QUADRANT, FIRE CONTROL: M17 (1290-01-037-3883)

AND M17A1 (1290-01-515-8260);

QUADRANT, FIRE CONTROL: M18 (1290-01-037-7289)

AND M18A1 (1290-01-515-8262);

MOUNT, TELESCOPE AND QUADRANT: M171 (1240-01-039-7273)

AND M171A1 (1240-01-515-8265);

MOUNT, TELESCOPE AND QUADRANT: M172 (1240-01-037-7290)

AND M172A1 (1240-01-517-2171);


TELESCOPE, PANORAMIC: M137 (1240-01-038-0531),

M137A2 (1240-01-483-6103),


AND M137A3 (1240-01-483-6100); AND

TELESCOPE, ELBOW: M138 (1240-01-038-0530)


AND 138A1 (1240-01-515-8264)




M17




M18




M171




M171A1



M17A1




M18A1




M172/M172A1




M138




M138A1



M137



M137A2



M137A3

1fc001

SUPERSEDURE NOTICE—Supersedes TM 9-1240-375-34 dated 26 September 1980, including all changes, and TM 9-1240-375-34P dated 19 September 1980, including all changes.

DISTRIBUTION STATEMENT A—Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY
MARCH 2005

WARNING SUMMARY

WARNING



RADIATION

HAZARD

TRITIUM GAS (H₃)

This item contains radioactive material. All personnel that operate and/or maintain fire control equipment containing tritium must be aware of the following special precautions and requirements:

Immediately report any suspected lost or damaged tritium fire control equipment to your unit/mission Radiation Safety Officer (RSO). If your RSO cannot be reached, contact the TACOM-RI RSO (DSN 793-2965/6228, Commercial (309) 782-2965/6228) during regular duty hours; or call the Rock Island Police Office at DSN 793-6135 after duty hours.

Unit/mission RSO: _____

Telephone: _____

A. RULES AND REGULATIONS. NRC Form 3 - Notice to Employees and Energy Reorganization Act of 1974 Section 206 must be posted and the following regulations and licenses must be available for review at a location frequented by all employees or at the installation Safety Office:

- (1) 10 CFR Part 19 - Notices, Instructions and Reports to Workers; Inspections.
- (2) 10 CFR Part 20 - Standards for Protection Against Radiation.
- (3) 10 CFR Part 21 - Reporting of Defects and Noncompliance.
- (4) NRC license and license application.

Copies may be requested or information obtained by contacting the TACOM-RI Safety Office, DSN 793-2965/6228, Commercial (309) 782-2965/6228, or by visiting TACOM-RI web site at <http://tri.army.mil>.

B. SAFETY PRECAUTIONS. The radioactive material used in this instrument is tritium gas (H₃) sealed in glass vials. These sources illuminate the instrumentation during night operations. Federal law prohibits tampering with or removal of the sources in the field. In the event there is no illumination, notify the local RSO or TACOM-RI RSO. If skin contact is made with any area contaminated with tritium, wash immediately with soap and water. Notification of the RSO is required.

The beta radiation emitted by tritium is a hazard only if the vial or source is broken. Tritium can be taken into the body by inhalation, ingestion, or skin absorption/injection. If the vial is broken, the tritium gas will dissipate into the surrounding air. If released into a confined space such as a storage locker, container, unventilated room, or military vehicle, the tritium will be absorbed by lungs from inhalation or by skin through contact with contaminated surfaces. However, the body naturally eliminates absorbed tritium. If exposed, notification of the RSO is required.

C. IDENTIFICATION. Instruments containing radioactive self-luminous vials are identified by means of radioactive warning label (see above). The radioactive material used in this instrument is tritium gas (H₃) sealed in glass vials. These sources illuminate the instrumentation for night operations.

WARNING SUMMARY - Continued

D. CONTROL. Federal law mandates control of this radioactive material. Tampering with or removal of the sources in the field is prohibited.

E. HAZARDS. The beta radiation emitted by tritium is a hazard only if the vial or source is broken. Tritium can be taken into the body by inhalation, ingestion, or skin absorption. If the vial is broken, the tritium gas will dissipate into the surrounding air. However, if released inside a confined space such as a storage locker, unventilated room, or military vehicle, tritium oxide will form, which is readily absorbed by lungs from air or by skin from contact with contaminated surfaces.

F. STORAGE. Federal law requires secured storage of these items. It is recommended a well-ventilated arms room or unoccupied building be used to store tritium fire control devices.

G. DISPOSAL. Non-illuminated or broken instruments will be turned into the unit/mission RSO. The unit/mission RSO will properly secure the material in an area designated for low-level radioactive waste. The unit/mission RSO must contact the Army Field Support Command for further disposition at DSN 793-0338/1883, Commercial (309) 782-0338/1883.

H. SHIPPING. Shipping of radioactive devices must be in accordance with 49 CFR, Part 173.423 or International Air Transport Association (45th ed). Broken or non-illuminated and repaired devices must be wipe tested by the unit/mission RSO prior to shipment. The unit/mission RSO or Transportation Officer (TO) will authorize the shipment. New or unused tritium devices do not require a wipe test prior to shipment if new shipping package is used. A material movement form (MMF) must accompany the shipment. The MMF can be obtained at the TACOM-RI web site: <http://tri.army.mil> under safety office/radiation safety/forms.

I. EMERGENCY PROCEDURES. If the tritium fire control device is not illuminated or broken, contact your unit/mission RSO immediately. If skin contact is made with any broken device or surface potentially contaminated with tritium, wash immediately with nonabrasive soap and cold water. The following acronym "SWIMN" will help you remember what to do if a tritium device breaks or is not illuminated:

Stop - and think.

Warn - nearby personnel of situation to exit room/vehicle/immediate area.

Isolate - use gloves (or turn plastic bag inside out over your hand) and place item in plastic bag (item 5, WP 0152 00) (if bag not immediately available, wrap in plastic). Do not handle broken tritium devices with bare hands.

Minimize - contamination by opening doors/windows/hatches to ventilate the area. Leave area if possible and wash hands and arms after handling broken items.

Notify - call the unit/mission Radiation Safety Officer (RSO).

Before any tritium-illuminated device is purged, ensure that all radioactive light sources are fully illuminated. If not fully illuminated, send to depot for maintenance.

To avoid injury to personnel and damage to equipment, ensure that tritium-illuminated counters are fully illuminated before cover of fire control device is removed.

BATTERY WARNINGS

Lithium – Thionyl Chloride (Li-SOCl₂) batteries present a fire, explosion and severe burn hazard. Do not recharge, disassemble, heat above 212 °F (100 °C), incinerate, or expose contents to water.

Lithium – Thionyl Chloride (Li-SOCl₂) batteries contain liquid Thionyl Chloride (SOCl₂), which fumes upon exposure to air. The vapor is highly toxic, and the battery must not be abused in any way that may cause it to rupture.

WARNING SUMMARY - Continued

Immediately turn off equipment if battery or battery enclosure shows signs of overheating or becomes hot to the touch. Allow the battery to cool (at least 60 minutes) before removing it.

If you hear a hissing sound (battery venting), or smell irritating gas, immediately turn off the equipment, and leave the area until any smell or signs of leaking gas have been cleared from the area.

Halon fire extinguishers shall not be used to combat fires involving batteries. Use a class D fire extinguisher to extinguish lithium or a carbon dioxide fire extinguisher to cool surrounding batteries.

Do not package any battery if it is hot/warm. Package batteries only when they are cool to the touch.

Lithium – Thionyl Chloride (Li-SOCl₂) batteries must be disposed of as hazardous waste (EPA HW Number D001 (IGNITABILITY), D003 (REACTIVITY) and D007 (CHROMIUM)). Coordinate with installation environmental office to ensure compliance with local, state, and federal regulations and dispose of batteries through DRMO.

Do not accumulate or store waste batteries for disposal for more than 90 days.

Do not mix hazardous and non-hazardous solid waste in the same package.

When handling batteries that show signs of leaking, bulging, swelling, or deformity, personal protective equipment meeting ANSI or NIOSH/MSHA requirements must be used.

GENERAL WARNINGS

Do not drop tank of compressed nitrogen gas. When using in confined areas, use extreme care; gas could cause asphyxiation.

HAZARDOUS MATERIALS DESCRIPTION

WARNING



ADHESIVES, CLEANING SOLVENTS, AND SEALING COMPOUNDS

Use adhesives, cleaning solvents, and sealing compounds in well-ventilated area away from open flame. Adhesives, cleaning solvents, and sealing compounds are harmful to skin and clothing and may give off harmful vapor.

FIRST AID

For further information on first aid, see FM 4-25.11.

LIST OF EFFECTIVE PAGES/WORK PACKAGES

Dates of issue for original and updated pages/work packages are:

Original..... 015 March 2005

TOTAL NUMBER OF PAGES FOR FRONT AND REAR MATTER IS 40 AND TOTAL NUMBER OF WORK PACKAGES IS 152 CONSISTING OF THE FOLLOWING:

Page/WP No.	*Change No.
Cover	0
a – c	0
d blank	0
A	0
B blank.....	0
i – viii	0
WP 0001 00 – WP 0152 00.....	0
Index-1 – Index 12.....	0

*Zero in this column indicates an original page or work package.

HEADQUARTERS, DEPARTMENT OF THE ARMY
Washington, D.C., 15 MARCH 2005

TECHNICAL MANUAL

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE MANUAL (INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST)

FOR

QUADRANT, FIRE CONTROL: M17 (1290-01-037-3883)

AND M17A1 (1290-01-515-8260);

QUADRANT, FIRE CONTROL: M18 (1290-01-037-7289)

AND M18A1 (1290-01-515-8262);

MOUNT, TELESCOPE AND QUADRANT: M171 (1240-01-039-7273)

AND M171A1 (1240-01-515-8265);

MOUNT, TELESCOPE AND QUADRANT: M172 (1240-01-037-7290)

AND M172A1 (1240-01-517-2171);

TELESCOPE, PANORAMIC: M137 (1240-01-038-0531),

M137A2 (1240-02-483-6103),

AND M137A3 (1240-01-483-6100); AND,

TELESCOPE, ELBOW: M138 (1240-01-038-0530)

AND M138A1 (1240-01-515-8264)

Current as of 1 October 2004 for RPSTL WP 0110 00 to WP 0151 00

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028 (Recommended Changes to Publications and Blank Forms), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <https://aeps.ria.army.mil>. If you need a password, scroll down and click on "ACCESS REQUEST FORM". The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax, or e-mail your letter or DA Form 2028 direct to: AMSTA-LC-LMIT / TECH PUBS, TACOM-RI, 1 Rock Island Arsenal, Rock Island, IL 61299-7630. The e-mail address is TACOM-TECH-PUBS@ria.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

DISTRIBUTION STATEMENT A. Approved for public release; distribution is unlimited.

*This manual supersedes TM 9-1240-375-34 dated 26 September 1980, including all changes, and TM 9-1240-375-34P dated 19 September 1980, including all changes.

TABLE OF CONTENTS

	<u>WP Sequence No.</u>
WARNING SUMMARY	
HOW TO USE THIS MANUAL	
GENERAL INFORMATION	0001 00
CHAPTER 1 - DESCRIPTION AND THEORY OF OPERATION	
Equipment Description and Data	0002 00
Theory of Operation	0003 00
CHAPTER 2 - DIRECT SUPPORT TROUBLESHOOTING PROCEDURES FOR M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT	
Troubleshooting Index	0004 00
Troubleshooting Procedures for Fire Control Level Assembly (M17/M18).....	0005 00
Troubleshooting Procedures for Fire Control Level Assembly (M17A1/M18A1)	0006 00
Troubleshooting Procedures for Cover Assembly	0007 00
CHAPTER 3 - GENERAL SUPPORT TROUBLESHOOTING PROCEDURES FOR M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT	
Troubleshooting Index	0008 00
Troubleshooting Procedures for Fire Control Level Assemblies	0009 00
Troubleshooting Procedures for Cover Assembly	0010 00
Troubleshooting Procedures for Correction Knob Assembly	0011 00
Troubleshooting Procedures for Counter Assembly	0012 00
Troubleshooting Procedures for Worm Shaft Assembly.....	0013 00
CHAPTER 4 - DIRECT SUPPORT TROUBLESHOOTING PROCEDURES FOR M171/M171A1 TELESCOPE AND QUADRANT MOUNT	
Troubleshooting Index	0014 00
Troubleshooting Procedures for Optical Instrument Support	0015 00
Troubleshooting Procedures for Bearing Housing Assembly (M171)	0016 00
Troubleshooting Procedures for Bearing Housing Assembly (M171A1).....	0017 00
CHAPTER 5 - GENERAL SUPPORT TROUBLESHOOTING PROCEDURES FOR M171/M171A1 TELESCOPE AND QUADRANT MOUNT	
Troubleshooting Index	0018 00
Troubleshooting Procedures for Bearing Housing Assembly (M171)	0019 00
Troubleshooting Procedures for Bearing Housing Assembly (M171A1).....	0020 00
Troubleshooting Procedures for Housing Assembly	0021 00
Troubleshooting Procedures for Optical Instrument Rocker Assembly.....	0022 00
CHAPTER 6 - DIRECT SUPPORT TROUBLESHOOTING PROCEDURES FOR M172/M172A1 TELESCOPE AND QUADRANT MOUNT	
Troubleshooting Index	0023 00
Troubleshooting Procedures for Adapter Assembly	0024 00
Troubleshooting Procedures for Quadrant Adapter	0025 00
CHAPTER 7 - GENERAL SUPPORT TROUBLESHOOTING PROCEDURES FOR M172/M172A1 TELESCOPE AND QUADRANT MOUNT	
Troubleshooting Index	0026 00
Troubleshooting Procedures for M172/M172A1 Telescope and Quadrant Mount	0027 00
Troubleshooting Procedures for Telescope Mounting Bracket	0028 00

TABLE OF CONTENTS - Continued

WP Sequence No.

**CHAPTER 8 - DIRECT SUPPORT TROUBLESHOOTING PROCEDURES
FOR M137/M137A2/M137A3 PANORAMIC TELESCOPE**

Troubleshooting Index	0029 00
Troubleshooting Procedures for Head Assembly	0030 00
Troubleshooting Procedures for Cover Assembly (Head).....	0031 00
Troubleshooting Procedures for Knob Assembly (Azimuth).....	0032 00
Troubleshooting Procedures for Elbow Assembly	0033 00
Troubleshooting Procedures for Counter Box Assembly (M137).....	0034 00
Troubleshooting Procedures for Counter Box Assembly (M137A2/M137A3)	0035 00
Troubleshooting Procedures for Optical Elements.....	0036 00

**CHAPTER 9 - GENERAL SUPPORT TROUBLESHOOTING PROCEDURES
FOR M137/M137A2/M137A3 PANORAMIC TELESCOPE**

Troubleshooting Index	0037 00
Troubleshooting Procedures for Body Assembly	0038 00
Troubleshooting Procedures for Counter Box Assembly.....	0039 00
Troubleshooting Procedures for Optical Elements.....	0040 00

**CHAPTER 10 - DIRECT SUPPORT TROUBLESHOOTING PROCEDURES
FOR M138/M138A1 ELBOW TELESCOPE**

Troubleshooting Index	0041 00
Troubleshooting Procedures for M138 Telescope	0042 00
Troubleshooting Procedures for M138A1 Telescope.....	0043 00
Troubleshooting Procedures for Optical Instrument Latch Set	0044 00

**CHAPTER 11 - DIRECT SUPPORT MAINTENANCE INSTRUCTIONS
FOR M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT**

Service Upon Receipt.....	0045 00
M17/M18 Fire Control Quadrant Maintenance.....	0046 00
M17A1/M18A1 Fire Control Quadrant Maintenance	0047 00
Fire Control Level Assembly Maintenance (M17/M17A1).....	0048 00

**CHAPTER 12 - GENERAL SUPPORT MAINTENANCE INSTRUCTIONS
FOR M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT**

M17/M18 Fire Control Quadrant Maintenance.....	0049 00
M17A1/M18A1 Fire Control Quadrant Maintenance	0050 00
Fire Control Level Assembly (Elevation Level Vial Assembly) Maintenance	0051 00
Cover Assembly Maintenance (M17/M18)	0052 00
Cover Assembly Maintenance (M17A1/M18A1)	0053 00
Counter Assembly Maintenance	0054 00
Worm Shaft Assembly Maintenance	0055 00
Fire Control Level Assembly (Cross Level Vial Assembly) Maintenance (M18/M18A1)	0056 00

**CHAPTER 13 - GENERAL SUPPORT FINAL INSPECTION INSTRUCTIONS
FOR M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT**

Final Inspection Instructions.....	0057 00
------------------------------------	---------

TABLE OF CONTENTS - Continued

WP Sequence No.

CHAPTER 14 - DIRECT SUPPORT MAINTENANCE INSTRUCTIONS
FOR M171/M171A1 TELESCOPE AND QUADRANT MOUNT

Service Upon Receipt.....	0058 00
M171/M171A1 Mount Maintenance	0059 00
Optical Instrument Support Maintenance (M171).....	0060 00
Optical Instrument Support Maintenance (M171A1)	0061 00
Optical Instrument Rocker Assembly Maintenance (M171).....	0062 00
Optical Instrument Rocker Assembly Maintenance (M171A1).....	0063 00
Bearing Housing Assembly Maintenance	0064 00

CHAPTER 15 - GENERAL SUPPORT MAINTENANCE INSTRUCTIONS
FOR M171/M171A1 TELESCOPE AND QUADRANT MOUNT

M171/M171A1 Mount Maintenance	0065 00
Optical Instrument Support Maintenance.....	0066 00
Optical Instrument Rocker Assembly Maintenance	0067 00
Optical Instrument Rocker Maintenance.....	0068 00
Worm Shaft Assembly Maintenance	0069 00
Housing Assembly Maintenance.....	0070 00
Plunger Assembly Maintenance	0071 00
Mounting Adapter Maintenance.....	0072 00

CHAPTER 16 - GENERAL SUPPORT FINAL INSPECTION INSTRUCTIONS
FOR M171/M171A1 TELESCOPE AND QUADRANT MOUNT

Final Inspection Instructions.....	0073 00
------------------------------------	---------

CHAPTER 17 - DIRECT SUPPORT MAINTENANCE INSTRUCTIONS
FOR M172/M172A1 TELESCOPE AND QUADRANT MOUNT

Service Upon Receipt.....	0074 00
M172/M172A1 Mount Maintenance	0075 00
Adapter Assembly Maintenance	0076 00

CHAPTER 18 - GENERAL SUPPORT MAINTENANCE INSTRUCTIONS
FOR M172/M172A1 TELESCOPE AND QUADRANT MOUNT

M172/M172A1 Mount Maintenance	0077 00
Telescope Mounting Bracket Maintenance.....	0078 00
Access Cover Maintenance.....	0079 00
Adapter Assembly Maintenance	0080 00
Quadrant Adapter Maintenance.....	0081 00

CHAPTER 19 - GENERAL SUPPORT FINAL INSPECTION INSTRUCTIONS
FOR M172/M172A1 TELESCOPE AND QUADRANT MOUNT

Final Inspection Instructions.....	0082 00
------------------------------------	---------

TABLE OF CONTENTS - Continued

WP Sequence No.

CHAPTER 20 - DIRECT SUPPORT MAINTENANCE INSTRUCTIONS
FOR M137/M137A2/M137A3 PANORAMIC TELESCOPE

Service Upon Receipt.....	0083 00
M137/M137A2/M137A3 Panoramic Telescope Maintenance.....	0084 00
Head Assembly Maintenance.....	0085 00
Cover Assembly (Head) Maintenance	0086 00
Body Assembly Maintenance	0087 00
Elbow Assembly Maintenance	0088 00
Optical Cell Assembly Maintenance.....	0089 00
Counter Box Assembly Maintenance	0090 00
Cover Assembly (Azimuth Counter) Maintenance	0091 00

CHAPTER 21 - GENERAL SUPPORT MAINTENANCE INSTRUCTIONS
FOR M137/M137A2/M137A3 PANORAMIC TELESCOPE

M137/M137A2/M137A3 Panoramic Telescope Maintenance.....	0092 00
Head Assembly Maintenance.....	0093 00
Optical Element Spacer Maintenance	0094 00
Body Assembly Maintenance	0095 00
Elbow Assembly Maintenance	0096 00
Optical Cell Assembly.....	0097 00
Counter Box Assembly (External Parts) Maintenance	0098 00
Counter Box Assembly (Parts) Maintenance	0099 00

CHAPTER 22 - GENERAL SUPPORT FINAL INSPECTION INSTRUCTIONS
FOR M137/M137A2/M137A3 PANORAMIC TELESCOPE

Final Inspection Instructions.....	0100 00
------------------------------------	---------

CHAPTER 23 - DIRECT SUPPORT MAINTENANCE INSTRUCTIONS
FOR M138/M138A1 ELBOW TELESCOPE

Service Upon Receipt.....	0101 00
M138 Telescope Maintenance	0102 00
M138A1 Telescope Maintenance	0103 00
Optical Instrument Latch Set Maintenance	0104 00
Optical Instrument Latch Maintenance.....	0105 00

CHAPTER 24 - DIRECT SUPPORT FINAL INSPECTION INSTRUCTIONS
FOR M138/M138A1 ELBOW TELESCOPE

Final Inspection Instructions.....	0106 00
------------------------------------	---------

CHAPTER 25 – PREEMBARKATION INSTRUCTIONS

Preembarkation Inspection of Material	0107 00
---	---------

TABLE OF CONTENTS - Continued

		<u>WP Sequence No.</u>
CHAPTER 26 – SUPPORTING INFORMATION		
	References	0108 00
	Introduction to Repair Parts and Special Tools List (RPSTL)	0109 00
Group	06 Quadrant, Fire Control, M17, 11729530; Quadrant, Fire Control, M17A1, 13005101; Quadrant, Fire Control, M18, 11729525; and Quadrant, Fire Control, M18A1, 13005102 repair parts list.....	0110 00
	06001 Quadrant, Fire Control, M17, 11729530; Quadrant, Fire Control, M17A1, 13005101; Quadrant, Fire Control, M18, 11729525; and Quadrant, Fire Control, M18A1, 13005102, External Parts repair parts list	0111 00
	06002 Quadrant, Fire Control, M17, 11729530; Quadrant, Fire Control, M17A1, 13005101; Quadrant, Fire Control, M18, 11729525; and Quadrant, Fire Control, M18A1, 13005102, Internal Parts repair parts list	0112 00
	0601 Level Assembly, Fire Control (Elevation Level Vial Assembly), 10554827/13005080 repair parts list	0113 00
	0602 Cover, Access, 11729532/13005079 repair parts list.....	0114 00
	0603 Counter Assembly, 11729529 repair parts list.....	0115 00
	0604 Level Assembly, Fire Control (Cross Level Vial Assembly), 11729551/13005081 repair parts list	0116 00
Group	08 Mount, Telescope and Quadrant, M171, 11727800, and Mount, Telescope and Quadrant, M171A1, 13005103 repair parts list	0117 00
	08001 Mount, Telescope and Quadrant, M171, 11727800, and Mount, Telescope and Quadrant, M171A1, 13005103, Upper Internal Mount Parts repair parts list	0118 00
	08002 Mount, Telescope and Quadrant, M171, 11727800, and Mount, Telescope and Quadrant, M171A1, 13005103, Lower Internal Mount Parts repair parts list	0119 00
	08003 Mount, Telescope and Quadrant, M171, 11727800, and Mount, Telescope and Quadrant, M171A1, 13005103, External Parts Including Level Vials repair parts list	0120 00
	0801 Support, Optical Instrument, 11727822/13005037 repair parts list	0121 00
	0802 Rocker Assembly, Optical Instrument, 11727801 repair parts list	0122 00
	0803 Housing Assembly, 11727804 repair parts list	0123 00
	0805 Mount Subassembly, 11727824 repair parts list	0124 00
	080501 Adapter, Mounting, 11727821, and Actuator, Mechanical, 11727803 repair parts list	0125 00
	0806 Bearing Unit, Ball, 11727802/13005082 repair parts list	0126 00
Group	09 Mount, Telescope and Quadrant, M172, 10554823, and Mount, Telescope and Quadrant, M172A1, 13005089 repair parts list.....	0127 00
	09001 Mount, Telescope and Quadrant, M172, 10554823, and Mount, Telescope and Quadrant, M172A1, 13005089, Parts repair parts list.....	0128 00
	09002 Mount, Telescope and Quadrant, M172, 10554823, and Mount, Telescope and Quadrant, M172A1, 13005089, Parts (Lower Right) repair parts list	0129 00
	0901 Bracket, Telescope Mounting, 10554685 repair parts list.....	0130 00
	0903 Adapter Assembly, 13005091 repair parts list.....	0131 00

TABLE OF CONTENTS - Continued

		<u>WP Sequence No.</u>
Group 10	Telescope, Panoramic, M137, 11741101; Telescope, Panoramic, M137A2, 12984713; and Telescope, Panoramic, M137A3, 12984775 repair parts list	0132 00
	10001 Telescope, Panoramic, M137, 11741101; Telescope, Panoramic, M137A2, 12984713; and Telescope, Panoramic, M137A3, 12984775, Parts repair parts list	0133 00
	1001 Head Assembly, 11741105 repair parts list.....	0134 00
	100101 Cover Assembly, 11741126 repair parts list	0135 00
	1002 Spacer, Optical Element, 10554778 repair parts list.....	0136 00
	1003 Telescope Subassembly, M137, 11741202, and Telescope Subassembly, M137A2/M137A3, 12961438 repair parts list	0137 00
	100301 Objective and Reticle Assembly, M137, 11741200, and Objective and Reticle Assembly, M137A2/M137A3, 12961437 repair parts list	0138 00
	1004 Elbow Telescope, M137, 11741201, and Elbow Telescope, M137A2/M137A3, 12984733 repair parts list	0139 00
	100401 Cell Assembly, Optical, 11741137 repair parts list.....	0140 00
	1005 Counter Box Assembly, M137, 11741102-1, and Counter Box Assembly, M137A2/M137A3, 12984734, External Parts repair parts list	0141 00
	1005001 Counter Box Assembly, M137, 11741102-1, and Counter Box Assembly, M137A2/M137A3, 12984734, Parts repair parts list	0142 00
	1005002 Counter Box Assembly, M137, 11741102-1, and Counter Box Assembly, M137A2/M137A3, 12984734, Internal Parts repair parts list	0143 00
	100501 Cover Assembly, 11741163 repair parts list	0144 00
Group 11	Telescope, Elbow, M138, 11741626, and Telescope, Elbow, M138A1, 13005104, Parts repair parts list.....	0145 00
	11001 Telescope, Elbow, M138/M138A1, 11741626/13005104, Parts repair parts list	0146 00
	1101 Latch Set, Optical Instrument, 10549272 repair parts list.....	0147 00
	110101 Latch, Optical Instrument, 10549277 repair parts list.....	0148 00
Group 9500	Special Tools.....	0149 00
	National Stock Number Index	0150 00
	Part Number Index.....	0151 00
	Expendable and Durable Items List	0152 00
	Index.....	Index-1

HOW TO USE THIS MANUAL

GENERAL

References in the manual are to work packages and other technical manuals.

INDEXES

This manual is organized to help the user quickly find the information needed. There are several useful indexes.

Table of Contents. Lists all work packages in numeric order.

Nomenclature Cross-Reference List. Gives an alphabetical list of common item names used in the manual. Official nomenclature is given for each item (WP 0001 00).

List of Abbreviations/Acronyms. Is an alphabetical list of uncommon abbreviations/acronyms used in the manual (WP 0001 00).

Malfunction/Symptom Index. Is an alphabetical list of parts with possible malfunctions. References work package number of the troubleshooting table.

Alphabetical Index. Located at the end of the manual. An extensive subject index for everything in the manual. Gives work package number.

DIRECT SUPPORT AND GENERAL SUPPORT

GENERAL INFORMATION

SCOPE**Type of Manual**

Direct and general support maintenance.

Model Numbers and Equipment Names

1. M17 Fire Control Quadrant/M17A1 Fire Control Quadrant.
2. M18 Fire Control Quadrant/M18A1 Fire Control Quadrant.
3. M171 Telescope and Quadrant Mount/M171A1 Telescope and Quadrant Mount.
4. M172 Telescope and Quadrant Mount/M172A1 Telescope and Quadrant Mount.
5. M137 Panoramic Telescope/M137A2 Panoramic Telescope/M137A3 Panoramic Telescope.
6. M138 Elbow Telescope/M138A1 Elbow Telescope.

Purpose of Equipment

1. **M17/M17A1 Quadrant:** Measures cannon elevation during one-person operation.
2. **M18/M18A1 Quadrant:** Measures cannon elevation during two-person operation.
3. **M171/M171A1 Mount:** Provides a mount for the M17/M17A1 quadrant and M137/M137A2/M137A3 telescope.
4. **M172/M172A1 Mount:** Provides a mount for the M18/M18A1 quadrant and M138/M138A1 telescope.
5. **M137/M137A2/M137A3 Telescope:** Provides a means of measuring horizontal direction in the indirect fire operation.
6. **M138/M138A1 Telescope:** Provides direction in the direct fire operation.

MAINTENANCE FORMS, RECORDS, AND REPORTS

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 738-750, Functional Users Manual for The Army Maintenance Management System (TAMMS).

REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR)

If your equipment needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design or performance. Put it on an SF 368 (Product Quality Deficiency Report). Mail it to us at ATTN: AMSTA-AR-QAW-C, TACOM-ARDEC, 1 Rock Island Arsenal, Rock Island, IL 61299-7300 (Fax: DSN 793-6653, Commercial (309) 782-6653) (E-mail: qawqdrs@ria.army.mil). We will send you a reply.

CORROSION PREVENTION AND CONTROL (CPC)

Corrosion Prevention and Control (CPC) of Army material is a continuing concern. It is important that any corrosion problems with this item be reported so that the problem can be corrected and improvements can be made to prevent the problem in future items.

While corrosion is typically associated with rusting of metals, it can also include deterioration of other materials, such as rubber and plastic. Unusual cracking, softening, swelling, or breaking of these materials may be a corrosion problem.

If a corrosion problem is identified, it can be reported using SF 368, Product Quality Deficiency Report. Use of key words such as "corrosion," "rust," "deterioration", or "cracking" will ensure that the information is identified as a CPC problem.

The form should be submitted to:

ATTN: AMSTA-AR-QAW-C
TACOM-ARDEC
1 Rock Island Arsenal
Rock Island, IL 61299-7300

Fax: DSN 793-6653, Commercial (309) 782-6653
E-Mail: qawqdrs@ria.army.mil

DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE

Refer to TM 9-1025-211-20&P or TM 9-1025-215-25&P.

PREPARATION FOR STORAGE OR SHIPMENT

Refer to TM 9-1025-211-20&P or TM 9-1025-215-25&P.

Battery Storage and Shipment

Store batteries in original packaging until ready for use. Examine packages/batteries for bulging, cracking, or signs of leakage before putting the batteries into equipment. Remove any damaged batteries from service and dispose of in accordance with local regulations. NOTE: When handling batteries that show signs of leaking, bulging, swelling, or deformity, personal protective equipment meeting ANSI or NIOSH/MSHA requirements must be used.

Store in cool, dry, well-ventilated areas separated from other combustible and hazardous materials. Storage of batteries over 100 °F (38 °C) will cause rapid loss of power.

Do not accumulate or store waste batteries for disposal for more than 90 days.

Do not mix hazardous and non-hazardous waste in the same package.

Do not package any battery if it is hot/warm. Package batteries only when they are cool to the touch.

Batteries for disposal shall be collected, transported, and disposed of in a manner that will prevent short-circuit (isolate by taping metal poles/terminals), compacting, or mutilation to destroy their physical integrity.

Non-usable batteries shall be disposed of in accordance with local regulations. Contact your local environmental office for instructions. Li-SOCl₂ batteries are classified as hazardous waste.

NOTE

A flashing LED light indicates a low battery condition on the M137A2 panel (counter box). The LED may continue to flash for up to 12 hours. Replace the batteries as soon as possible after encountering this condition.

1.5V alkaline or NiCad batteries may be used in place of the 3.6V Lithium-Thionyl Chloride (Li-SOCl₂) batteries for **emergency short-term use only**. Using the 1.5V batteries will severely reduce the battery life and they will not work below 32 °F (0 °C).

NOMENCLATURE CROSS-REFERENCE LIST

Common Name	Official Nomenclature
Adapter	Quadrant testing fire control maintenance final inspection fixture
Azimuth counter	Rotating counter
Azimuth counter cover	Counter cover
Azimuth counter eccentric	Eccentric
Azimuth knob	Knob
Azimuth knob assembly	Knob assembly
Azimuth test fixture	Telescope test fixture
Battery	Lithium – Thionyl Chloride (Li-SOCl ₂) 3V size AA or C
Bracket	Rotating eye bracket
Collimator telescope	M1A1 infinity aiming reference collimator
Correction counter	Rotating counter
Correction knob	Knob
Correction knob assembly	Knob assembly
Counter window	Optical instrument window
Cross level knob	Knob
Cross level vial	Fire control level vial
Deflection counter	Rotating counter
Deflection counter eccentric	Eccentric
Elevation counter	Rotating counter
Elevation knob	Knob assembly
Elevation knob	Shouldered knob
Elevation knob assembly	Knob assembly
Elevation level vial	Fire control level vial
Eyeshield	Optical eyeshield
Eyeshield	Optical instrument eyeshield
Felt	Mechanical preformed felt
Felt holder	Felt mechanical holder
Grease	Aircraft grease (aircraft instrument)
Grease	Aircraft grease (corrosion-resistant)

NOMENCLATURE CROSS-REFERENCE LIST - Continued

Common Name	Official Nomenclature
Housing	Worm gear housing
Housing	Worm housing body
Latch	Lock-release latch
Lever	Lock-release lever
Lever	Plunger-release lever
Locking ring	Ring
Lock wire	Nonelectrical wire
M17 quadrant	M17 fire control quadrant
M17A1 quadrant	M17A1 fire control quadrant
M18 quadrant	M18 fire control quadrant
M18A1 quadrant	M18A1 fire control quadrant
M137 telescope	M137 panoramic telescope
M137A2 telescope	M137A2 panoramic telescope
M137A3 telescope	M137A3 panoramic telescope
M138 telescope	M138 elbow telescope
M138A1 telescope	M138A1 elbow telescope
M171 mount	M171 telescope and quadrant mount
M171A1 mount	M171A1 telescope and quadrant mount
M172 mount	M172 telescope and quadrant mount
M172A1 mount	M172A1 telescope and quadrant mount
Packing	Preformed packing
Plunger	Detent plunger
Radioactive material caution plate	Instruction plate
Support assembly	Quadrant support assembly
Telescope head spacer	Optical element spacer

LIST OF ABBREVIATIONS/ACRONYMS

Abbreviation/Acronym	Definition
cm/sec	Centimeters per second
fpm	Feet per minute
ft-lb	Foot-pound
in.-lb	Inch-pound
in.-oz	Inch-ounce
N-m	Newton/meter
RSO	Radiation Safety Officer
WP	Work Package

SAFETY, CARE, AND HANDLING

1. Observe all warnings, safety precautions, and safety regulations in this manual.
2. Safety precautions to be observed during training are prescribed in AR 385-63 and local range regulations.
3. Safety precautions given in this manual must be followed for storing, handling, and repairing fire control equipment and for returning equipment with broken tritium (H₃) components.

END OF WORK PACKAGE

CHAPTER 1

DESCRIPTION AND THEORY OF OPERATION

DIRECT SUPPORT AND GENERAL SUPPORT

EQUIPMENT DESCRIPTION AND DATA

EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES

M17/M17A1 and M18/M18A1 Fire Control Quadrants: The dual fire control quadrants are identical with the following exceptions. The M17/M17A1 quadrant contains a left-hand worm shaft assembly and gear, and the M18/M18A1 quadrant contains a right-hand worm shaft assembly and gear. Also, the M18/M18A1 quadrant features a cross level vial, which is not present on the M17/M17A1 quadrant. Both quadrants have the capability of measuring elevation to 1433 mils. The dual equipment permits either the assistant gunner or the gunner to lay the cannon in elevation. The counters and level vials are self-illuminated with radioactive tritium H₃ in the M17 and M18 quadrants and illuminated by battery power in the M17A1 and M18A1 quadrants.

M171/M171A1 Telescope and Quadrant Mount: The M171/M171A1 mount supports the M137/M137A2/M137A3 telescope and the M17/M17A1 quadrant. The M171/M171A1 mount is installed on the left trunnion of the howitzer. It provides an adjustable base for leveling the M137/M137A2/M137A3 telescope and the M17/M17A1 quadrant. The adjustable base compensates for azimuth and elevation errors introduced by cant when the weapon is elevated. The M171 level vials are illuminated by tritium H₃ and the M171A1 level vials are illuminated by battery power.

M172/M172A1 Telescope and Quadrant Mount: The M172/M172A1 mount supports and provides an adjustable base for leveling and boresighting the M138/M138A1 telescope and the M18/M18A1 quadrant. The M172/M172A1 mount is installed on the right trunnion of the 155-mm howitzer.

M137 Panoramic Telescope: The M137 telescope is a 4-power, 10-degree field of view instrument with digital counters. All counters and the reticle of the M137 telescope are self-illuminated by radioactive isotopes. The M137 telescope is the basic instrument used in laying the M198 howitzer in azimuth. The M137 telescope is mounted to the upper part of the M171 mount. This instrument is hermetically sealed and can be purged with dry nitrogen.

M137A2/M137A3 Panoramic Telescope: The M137A2/M137A3 telescope is a 4-power, 10-degree field of view instrument with digital counters. All counters and the reticle of the M137A2/M137A3 telescope are self-illuminated by lithium batteries. The M137A2/M137A3 telescope is the basic instrument used in laying the howitzer in azimuth. The M137A2/M137A3 telescope is mounted to the upper part of the M171/M171A1 mount. This instrument is hermetically sealed and can be purged with dry nitrogen.

EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES - Continued


M138/M138A1 Elbow Telescope: The elbow telescope is an 8-power, 8-degree field of view instrument. A self-illuminated elevation reticle is provided for direct fire. The M138/M138A1 telescope also has a mil scale reticle that is inscribed in meters for range and is self-illuminated. The M138 is illuminated by tritium H₃ and the M138A1 is illuminated by lithium batteries.

The optical system is composed of the following:

- A two-component objective lens system
- An amici prism
- A flat reticle
- A reticle lens
- A field lens
- A center lens
- An eye lens

LOCATION AND DESCRIPTION OF MAJOR COMPONENTS


M17 Fire Control Quadrant




M17

1fc006

1. Fire Control Elevation Level Assembly (1). The fire control level assembly consists of an elevation level vial in a vial holder. The fire control level assembly is used in checking the M199 cannon in elevation.
2. Cover Assembly (2). The cover assembly of the M17 includes the counter windows, the radioactive sources that illuminate the dials, the identification plate, and the instruction plate.
3. Correction Knob Assembly (3). The correction knob assembly is located on the left side of the M17 quadrant. It is used to set elevation correction increments on the correction counter.
4. Counter Assembly (4). The counter assembly consists of the elevation counter and the correction counter. The counters are mounted in the housing assembly.
5. Base Assembly (5). The base assembly provides the mounting surface of the M17 quadrant. It also contains a bearing necessary for accurate rotation when setting elevation.
6. Worm Shaft Assembly (6). The worm shaft assembly is located internally and is controlled by the elevation knob. The worm shaft assembly is used to level the M17 quadrant in elevation by moving the elevation and correction counters.
7. Housing Assembly (7). The housing assembly for the M17 quadrant contains an elevation knob assembly, correction knob assembly, counter assembly, fire control level assembly, and a worm shaft assembly.

LOCATION AND DESCRIPTION OF MAJOR COMPONENTS - Continued**M17A1 Fire Control Quadrant**


1. Fire Control Elevation Level Assembly (1). The fire control level assembly consists of an elevation level vial in a vial holder. The fire control level assembly is used in checking the cannon in elevation.
2. Cover Assembly (2). The cover assembly of the M17A1 includes the counter windows, the light-emitting diode (LED) light sources that illuminate the dials, and the battery enclosure assembly with power switch.
3. Correction Knob Assembly (3). The correction knob assembly is located on the left side of the M17A1 quadrant. It is used to set elevation correction increments on the correction counter.
4. Counter Assembly (4). The counter assembly consists of the elevation counter and the correction counter. The counters are mounted in the housing assembly.
5. Base Assembly (5). The base assembly provides the mounting surface for the M17A1 quadrant. It also contains a bearing necessary for accurate rotation when setting elevation.
6. Worm Shaft Assembly (6). The worm shaft assembly is located internally and is controlled by the elevation knob. The worm shaft assembly is used to level the M17A1 quadrant in elevation by moving the elevation and correction counters.
7. Housing Assembly (7). The housing assembly for the M17A1 quadrant contains an elevation knob assembly, correction knob assembly, counter assembly, fire control level assembly, and a worm shaft assembly.
8. Battery Enclosure Assembly (8). The battery enclosure is located on the left front side of the M17A1 cover. It is used to hold the batteries and is equipped with a power switch.
9. Battery Power Switch (9). The power switch is located on the left side of the battery enclosure assembly. It is used to cycle the battery power on and off. The power switch has a three-second delay.

M18 Fire Control Quadrant

1. Fire Control Elevation Level Assembly (1). The fire control level assembly consists of an elevation level vial in a vial holder. The fire control level assembly is used in checking the M199 cannon in elevation.
2. Fire Control Cross Level Assembly (2). The fire control cross level is located on the upper right side of the M18 quadrant. The fire control level consists of a cross level vial in a vial holder, and is used in checking the howitzer for cross level.
3. Cover Assembly (3). The cover assembly of the M18 quadrant includes the counter windows, the radioactive sources that illuminate the dials, the identification plate, and the instruction plate.
4. Correction Knob Assembly (4). The correction knob assembly is located on the left side of the M18 quadrant. It is used to set elevation correction increments on the correction counter.
5. Counter Assembly (5). The counter assembly consists of the elevation counter and the correction counter. The counters are mounted in the housing assembly.
6. Base Assembly (6). The base assembly provides the mounting surface for the M18 quadrant. It also contains a bearing necessary for accurate rotation when setting elevation.
7. Worm Shaft Assembly (7). The worm shaft assembly is located internally and is controlled by the elevation knob. The worm shaft assembly is used to level the M18 quadrant in elevation by moving the elevation and correction counters.
8. Housing Assembly (8). The housing assembly for the M18 quadrant contains an elevation knob assembly, correction knob assembly, counter assembly, level assembly, fire control level assembly, and a worm shaft assembly.

LOCATION AND DESCRIPTION OF MAJOR COMPONENTS - Continued

M18A1 Fire Control Quadrant




M18A1

1fc009

1. Fire Control Elevation Level Assembly (1). The fire control level assembly consists of an elevation level vial in a vial holder. The fire control level assembly is used in checking the cannon in elevation.
2. Cross Level Assembly (2). The cross level assembly is located on the upper right side of the M18A1 quadrant. The level assembly consists of a cross level vial in a vial holder, and is used in checking the howitzer for cross level.
3. Cover Assembly (3). The cover assembly of the M18A1 quadrant includes the counter windows, the LED light sources that illuminate the dials, and the battery enclosure assembly with power switch.
4. Correction Knob Assembly (4). The correction knob assembly is located on the left side of the M18A1 quadrant. It is used to set elevation correction increments on the correction counter.
5. Counter Assembly (5). The counter assembly consists of the elevation counter and the correction counter. The counters are mounted in the housing assembly.
6. Base Assembly (6). The base assembly provides the mounting surface for the M18A1 quadrant. It also contains a bearing necessary for accurate rotation when setting elevation.
7. Worm Shaft Assembly (7). The worm shaft assembly is located internally and is controlled by the elevation knob. The worm shaft assembly is used to level the M18A1 quadrant in elevation by moving the elevation and correction counters.
8. Housing Assembly (8). The housing assembly for the M18A1 quadrant contains an elevation knob assembly, correction knob assembly, counter assembly, level assembly, fire control level assembly, and a worm shaft assembly.
9. Battery Enclosure Assembly (9). The battery enclosure is located on the left front side of the M18A1 cover. It is used to hold the batteries and is equipped with a power switch.
10. Battery Power Switch (10). The power switch is located on the left front side of the battery enclosure assembly. It is used to cycle the battery power on and off. The power switch has a three-second delay.

M171 Telescope and Quadrant Mount




1fc010

1. Optical Instrument Support (1). The optical instrument support, located at the top of the M171 mount, seats the M137/M137A2/M137A3 telescope.
2. Optical Instrument Rocker Assembly (2). The optical instrument rocker assembly houses the cross-leveling mechanism. In conjunction with the elevation-leveling mechanism located on the housing assembly, the optical instrument rocker assembly establishes the vertical axis reference for azimuth compensation.
3. Worm Shaft Assembly (Cross Level) (3). The worm shaft assembly is located in the optical instrument rocker assembly. The worm shaft assembly is actuated by a cross level knob. This assembly controls the cant of the M171 mount.
4. Housing Assembly (4). The housing assembly houses the elevation-leveling mechanism and supports the plunger assembly. The plunger assembly secures the M171 mount in an upright position on the weapon. A spring-loaded guide is provided to prevent damage to the M171 mount if the elevation limit of the instrument is exceeded.
5. Worm Shaft Assembly (Elevation) (5). The worm shaft assembly is located in the housing assembly. It is actuated by the elevation knob.
6. Arm and Adapter Assembly (6). The arm and adapter assembly is located on the face of the arm assembly, and supports the M17 quadrant. The mounting adapter provides the keyed interface for assembling the M171 mount to the pre-qualified mounting adapter on the weapon trunnion. This adapter also houses the bar. It serves as a reference about which the M171 mount is adjusted to compensate in azimuth and elevation for the effects of trunnion cant.
7. Bearing Housing Assembly (7). The bearing housing assembly houses the bearings which permit the smooth, compensating motion when the weapon is elevated. The stem holds the optical instrument support, which seats the M137 telescope. It also provides the bearing in which the M171 mount is cross and elevation leveled. Located at the base of the stem are the cross level vial and elevation level vial.

LOCATION AND DESCRIPTION OF MAJOR COMPONENTS - Continued

M171A1 Telescope and Quadrant Mount




M171A1

1fc011

1. Optical Instrument Support (1). The optical instrument support, located at the top of the M171A1 mount, seats the M137/M137A2/M137A3 telescope.
2. Optical Instrument Rocker Assembly (2). The optical instrument rocker assembly houses the cross-leveling mechanism. In conjunction with the elevation-leveling mechanism located on the housing assembly, the optical instrument rocker assembly establishes the vertical axis reference for azimuth compensation.
3. Worm Shaft Assembly (Cross Level) (3). The worm shaft assembly is located in the optical instrument rocker assembly. The worm shaft assembly is actuated by a cross level knob. This assembly controls the cant of the M171A1 mount.
4. Housing Assembly (4). The housing assembly houses the elevation-leveling mechanism and supports the plunger assembly. The plunger assembly secures the M171A1 mount in an upright position on the weapon. A spring-loaded guide is provided to prevent damage to the M171A1 mount if the elevation limit of the instrument is exceeded.
5. Worm Shaft Assembly (Elevation) (5). The worm shaft assembly is located in the housing assembly. It is actuated by the elevation knob.
6. Arm and Adapter Assembly (6). The arm and adapter assembly is located on the face of the arm assembly, and supports the M17A1 quadrant. The mounting adapter provides the keyed interface for assembling the M171A1 mount to the pre-qualified mounting adapter on the weapon trunnion. This adapter also houses the bar. It serves as a reference about which the M171A1 mount is adjusted to compensate in azimuth and elevation for the effects of trunnion cant.

7. Bearing Housing Assembly (7). The bearing housing assembly houses the bearings which permit the smooth, compensating motion when the weapon is elevated. The stem holds the optical instrument support, which seats the M137/M137A2/M137A3 telescope. It also provides the bearing in which the M171A1 mount is cross and elevation leveled. Located at the base of the stem are the cross level vial and elevation level vial.
8. Battery Enclosure Assembly (8). The battery enclosure is located on the optical instrument rocker assembly. It is used to hold the battery.


M172/M172A1 Telescope and Quadrant Mount



M172/M172A1

1fc012


1. Telescope Mounting Bracket (1). The telescope mounting bracket, attached to the top portion of the adapter assembly, supports the M138/M138A1 telescope. Seats are included to support a M1A2 gunner's quadrant when fine elevation settings are required.
2. Access Cover (2). The access cover is located on top of the housing on the quadrant support assembly. The purpose of the access cover is to protect and aid in alignment of the worm wheel gear sector.
3. Adapter Assembly (3). The adapter assembly supports the M18/M18A1 quadrant. This assembly pivots about an axis, parallel to the weapon bore, to facilitate cross leveling.
4. Quadrant Support Assembly (4). The support assembly provides the keyed interface for assembling the M172/M172A1 mount to the weapon mounting adapter. It also includes the cross-leveling mechanism for the M172/M172A1 mount.
5. Worm Shaft Assembly (5). The worm shaft assembly is located in the housing on the support assembly and is operated using the cross level knob. The worm shaft assembly is used to actuate the adapter assembly.

LOCATION AND DESCRIPTION OF MAJOR COMPONENTS - Continued
M137 Panoramic Telescope**M137**

1fc013

1. Head Assembly (1). The head assembly is capable of 360-degree (6400 mil) revolution. The amount of azimuth travel is indicated by a counter box assembly. The head assembly is adjustable in elevation (± 300 mils) by means of an elevation knob. An entrance window protects the prism and the rest of the M137 telescope against moisture, dirt, and other foreign particles. A window cover, when in the closed position, forms a parallax shield to reduce parallax when viewing a close target.
2. Optical Element Spacer (2). The optical element spacer couples the head assembly to the body assembly at a sufficient height so the line of sight has minimum obstructions.
3. Body Assembly (3). The body assembly includes the main M137 telescope tube and housing and the radioactive sources that illuminate the reticles. This assembly also includes the azimuth knob assembly and associated gearing that rotates the head assembly and drives the counter box assembly. One rotation of the azimuth knob assembly rotates the head assembly 100 mils.
4. Knob Assembly (4). The knob assembly is located on the body assembly. It is used to activate the worm shaft assembly which rotates the head assembly.
5. Elbow Assembly (5). The elbow assembly is located on the bottom of the M137 telescope. The elbow assembly contains the optical cell assembly and adapter assembly.
6. Counter Box Assembly (6). The counter box assembly contains the 6400-mil azimuth counter, the 6400-mil deflection counter, and the 95-mil correction counter. It also contains the associated gearing for driving and setting the counters.
 - a. The azimuth counter indicates the azimuth angle of the M137 telescope head assembly with respect to the weapon bore.
 - b. The deflection counter indicates the azimuth angle in mils. It enables an operator to quickly lay the weapon on a desired deflection setting with respect to the aiming posts or collimator.
 - c. The correction counter indicates relatively constant deflection correction.


M137A2/M137A3 Panoramic Telescope



1. Head Assembly (1). The head assembly is capable of 360-degree (6400 mil) revolution. The amount of azimuth travel is indicated by a counter box assembly. The head assembly is adjustable in elevation (± 300 mils) by means of an elevation knob. An entrance window protects the prism and the rest of the M137A2/M137A3 telescope against moisture, dirt, and other foreign particles. A window cover, when in the closed position, forms a parallax shield to reduce parallax when viewing a close target.
2. Optical Element Spacer (2). The optical element spacer couples the head assembly to the body assembly at a sufficient height so the line of sight has minimum obstructions.
3. Body Assembly (3). The body assembly includes the main M137A2/M137A3 telescope tube and housing and the LED light sources that illuminate the reticles. This assembly also includes the azimuth knob assembly and associated gearing that rotates the head assembly and drives the counter box assembly. One rotation of the azimuth knob assembly rotates the head assembly 100 mils.
4. Knob Assembly (4). The knob assembly is located on the body assembly. It is used to activate the worm shaft assembly which rotates the head assembly.
5. Elbow Assembly (5). The elbow assembly is located on the bottom of the M137A2/M137A3 telescope. The elbow assembly contains the optical cell assembly and adapter assembly.
6. Counter Box Assembly (6). The counter box assembly contains the 6400-mil azimuth counter, the 6400-mil deflection counter, and the 95-mil correction counter. It also contains the associated gearing for driving and setting the counters.
 - a. The azimuth counter indicates the azimuth angle of the M137A2/M137A3 telescope head assembly with respect to the weapon bore.
 - b. The deflection counter indicates the azimuth angle in mils. It enables an operator to quickly lay the weapon on a desired deflection setting with respect to the aiming posts or collimator.
 - c. The correction counter indicates relatively constant deflection correction.

LOCATION AND DESCRIPTION OF MAJOR COMPONENTS - Continued**M137A2/M137A3 Panoramic Telescope - Continued**


7. Battery Enclosure Assembly (7). The battery enclosure is located on the counter box assembly. It is used to hold the batteries and is equipped with a power switch.
8. Battery Power Switch (8). The power switch is located on the left side of the battery enclosure assembly. It is used to cycle the battery power on and off. The power switch has a three-second delay.
9. Battery Enclosure Assembly (9). The battery enclosure is located on the elbow telescope. It is used to hold the battery.

M138 Elbow Telescope**M138**

1fc015

1. Optical Instrument Latch Set (1). The optical instrument latch set is attached to the eyepiece end of the M138 telescope. The optical instrument latch set is used for mounting the telescope to the M172 mount.
2. Eyepiece Cell Assembly (2). The eyepiece cell assembly is inside the dipter adapter assembly, which is attached to the telescope. The eyepiece cell assembly consists of a series of lenses and spacers.
3. Reticle Cell Assembly (3). The reticle cell assembly is inside the rear of the dipter adapter assembly. The reticle cell assembly consists of an optical element cell, and a nuclear lamp for reticle illumination.
4. Objective Cell Assembly (4). The objective cell assembly is located inside the optical instrument housing. The objective cell assembly consists of an optical element cell and an optical instrument lens. An optical instrument eyeshield is attached to the dipter adapter assembly.

M138A1 Elbow Telescope



1. Optical Instrument Latch Set (1). The optical instrument latch set is attached to the eyepiece end of the M138A1 telescope. The optical instrument latch set is used for mounting the telescope to the M172/M172A1 mount.
2. Eyepiece Cell Assembly (2). The eyepiece cell assembly is inside the diopter adapter assembly, which is attached to the telescope. The eyepiece cell assembly consists of a series of lenses and spacers.
3. Reticle Cell Assembly (3). The reticle cell assembly is inside the rear of the diopter adapter assembly. The reticle cell assembly consists of an optical element cell and battery powered LEDs for reticle illumination.
4. Objective Cell Assembly (4). The objective cell assembly is located inside the optical instrument housing. The objective cell assembly consists of an optical element cell and an optical instrument lens. An optical instrument eyeshield is attached to the diopter adapter assembly.
5. Battery Enclosure Assembly (5). The battery enclosure is located on the telescope. It is used to hold the battery.
6. Eye Piece Extension (6). The M138A1 telescope is equipped with an eye piece extension for use on the M777 lightweight howitzer.

EQUIPMENT DATA

	US CUSTOMARY	METRIC
M17 Fire Control Quadrant		
Correction	±95 mils	
Depression	-280 mils	
Elevation	+1433 mils	
Least increment reading (counters)	1 mil	
Radioactive material:		
Max surface radiation	0 millirad per hour	
Tritium H ₃	1.86 curies	
Weight	7.5 lb	3.40 kg

EQUIPMENT DATA - Continued

	US CUSTOMARY	METRIC
M17A1 Fire Control Quadrant		
Correction	±95 mils	
Depression	-280 mils	
Elevation	+1433 mils	
Least increment reading (counters)	1 mil	
Batteries:		
Quantity/Cell Size	2 each/size "C"	
Voltage	3 volts (each)	
Weight	8.5 lb	3.86 kg
M18 Fire Control Quadrant		
Correction	±95 mils	
Depression	-280 mils	
Elevation	+1433 mils	
Least increment reading (counters)	1 mil	
Radioactive material:		
Max surface radiation	0 millirad per hour	
Tritium H ₃	1.95 curies	
Weight	7.5 lb	3.40 kg
M18A1 Fire Control Quadrant		
Correction	±95 mils	
Depression	-280 mils	
Elevation	+1433 mils	
Least increment reading (counters)	1 mil	
Batteries:		
Quantity/Cell Size	2 each/size "C"	
Voltage	3 volts (each)	
Weight	8.5 lb	3.86 kg
M171 Telescope and Quadrant Mount		
Cross level adjustment:		
Left	178 mils	
Right	178 mils	
Depression	-270 mils	
Elevation	+1333 mils	
Pitch level adjustment:		
Aft	178 mils	
Fore	178 mils	
Radioactive material:		
Max surface radiation	0 millirad per hour	
Tritium H ₃	0.15 curies	
Weight:		
Adapter assembly	3.25 lb	1.47 kg
Mount	75 lb	34.02 kg
Optical instrument support	2 lb	0.91 kg

	US CUSTOMARY	METRIC
M171A1 Telescope and Quadrant Mount		
Cross level adjustment:		
Left.....	178 mils	
Right	178 mils	
Depression	-270 mils	
Elevation	+1333 mils	
Pitch level adjustment:		
Aft	178 mils	
Fore	178 mils	
Batteries:		
Quantity/Cell Size	1 each/size "C"	
Voltage	3 volts (each)	
Weight:		
Adapter assembly	3.25 lb	1.47 kg
Mount	75 lb	34.02 kg
Optical instrument support	2 lb	0.91 kg
M172/M172A1 Telescope and Quadrant Mount		
Boresighting:		
Azimuth	±18 mils	
Elevation	±15 mils	
Cross level adjustment	±34 degrees	
Weight:		
Adapter assembly	4.75 lb	2.15 kg
Mount	27.5 lb	12.47 kg
M137 Panoramic Telescope		
Field of view	10 degrees	
Movement:		
Azimuth counter	6400 mils*	
Azimuth (deflection)	6400 mils	
Correction (AZ).....	±95 mils	
Elevation	±300 mils	
Least increment reading (AZ).....	1.0 mils	
Optical characteristics:		
Clear eye distance.....	0.88 in.	2.24 cm
Effective focal length:		
Eyeshield	1.00 in.	2.54 cm
Objective	4.00 in.	10.16 cm
Exit pupil diameter.....		7 mm
Field of view	10 degrees	
Power	4X	
Radioactive material:		
Max surface radiation	0 millirad per hour	
Tritium H ₃	5.1 curies	
Weight.....	19 lb	8.62 kg

*Increasing counterclockwise.

EQUIPMENT DATA - Continued

	US CUSTOMARY	METRIC
M137A2/M137A3 Panoramic Telescope		
Field of view	10 degrees	
Movement:		
Azimuth counter	6400 mils*	
Azimuth (deflection)	6400 mils	
Correction (AZ).....	±95 mils	
Elevation	±300 mils	
Least increment reading (AZ).....	1.0 mils	
Optical characteristics:		
Clear eye distance.....	0.88 in.	2.24 cm
Effective focal length:		
Eyeshield	1.00 in.	2.54 cm
Objective	4.00 in.	10.16 cm
Exit pupil diameter.....		7 mm
Field of view	10 degrees	
Power	4X	
Batteries:		
Quantity/Cell Size	3 each/size "C"	
Voltage	3 volts (each)	
Weight.....	19 lb	8.62 kg
M138 Elbow Telescope		
Elevation	60 mils	
Field of view	8 degrees	
Optical characteristics:		
Diopter adjustment.....	±4 diopters	
Effective focal length:		
Clear eye distance	6.6 in.	16.76 cm
Eyeshield	1.5 in.	3.81 cm
Objective	10 in.	25.40 cm
Exit pupil diameter		7 mm
Field of view	8 degrees	
Power	8X	
Radioactive material:		
Max surface radiation	0 millirad per hour	
Tritium H ₃	4.4 curies	
Weight	8 lb	3.63 kg

*Increasing counterclockwise.

	US CUSTOMARY	METRIC
M138A1 Elbow Telescope		
Elevation	60 mils	
Field of view	8 degrees	
Optical characteristics:		
Diopter adjustment.....	±4 diopters	
Effective focal length:		
Clear eye distance	6.6 in.	16.76 cm
Eyeshield	1.5 in.	3.81 cm
Objective	10 in.	25.40 cm
Exit pupil diameter		7 mm
Field of view	8 degrees	
Power	8X	
Batteries:		
Quantity/Cell Size	1 each/size "C"	
Voltage	3 volts (each)	
Weight	9 lb	4.08 kg

END OF WORK PACKAGE

DIRECT SUPPORT AND GENERAL SUPPORT**THEORY OF OPERATION**

PURPOSE

The fire control equipment instruments provide radioactive and battery-powered sighting capability for the 155-mm howitzer. The M17/M17A1 and M18/M18A1 fire control quadrants measure elevation of the cannon. The M137/M137A2/M137A3 and M138/M138A1 telescopes provide a means of measuring horizontal direction in indirect or direct fire operations. The M171/M171A1 and M172/M172A1 mounts provide a mount for the fire control quadrants and the telescopes.

END OF WORK PACKAGE

CHAPTER 2

**DIRECT SUPPORT
TROUBLESHOOTING PROCEDURES
FOR
M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT**

DIRECT SUPPORT

M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)

TROUBLESHOOTING INDEX

INTRODUCTION

a. The troubleshooting procedures are limited to those listed in the troubleshooting symptom index. The table lists the common malfunctions, which you may find during the operation of maintenance of the M17/M17A1 and M18/M18A1 Fire Control Quadrant. You should perform the tests/inspections and corrective actions in the order listed.

b. This manual cannot list all malfunctions that may occur, or all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

c. Each work package is headed by an initial setup. This setup outlines what is needed as well as certain conditions, which must be met before starting the task. **DON'T START A TASK UNTIL:**

You understand the task;

You understand what you are to do;

You understand what is needed to do the work;

You have the things you need.

MALFUNCTION/SYMPTOM INDEX

a. The malfunction/symptom index is a quick reference index for finding troubleshooting procedures. Associated with each symptom name is a work package sequence number representing the starting point in a troubleshooting sequence. Should any one symptom require more than one troubleshooting sequence to arrive at the most likely area of investigation, the additional starting point numbers are presented.

b. As the troubleshooting activity progresses to the conclusion of a particular sequence, a reference is made to the next logical troubleshooting sequence by work package sequence number or by referring to the malfunction/symptom index to locate the next failure symptom work package. This type of activity continues until successful fault isolation is achieved.

MALFUNCTION/SYMPTOM INDEX - Continued

<u>Malfunction/Symptom</u>	<u>Work Package</u>
COVER ASSEMBLY	
1. Counter windows are fogged or have condensation.....	WP 0007 00
FIRE CONTROL LEVEL ASSEMBLY	
1. Bubble in elevation level vial is not synchronized with M198 howitzer tube (M17/M18).....	WP 0005 00
2. Bubble in elevation level vial is not synchronized with M198/M777 howitzer tube (M17A1/M18A1)	WP 0006 00
3. Elevation level vial and cross level vial cannot be read clearly in mirror (M17/M18).....	WP 0005 00
4. Elevation level vial and cross level vial cannot be read clearly in mirror (M17A1/M18A1)	WP 0006 00
5. Elevation level vial and cross level vial have no bubble and are not illuminated (M17/M18).....	WP 0005 00
6. Elevation level vial and cross level vial have no bubble, but are still illuminated (M17/M18)	WP 0005 00
7. Elevation level vial and cross level vial have no bubble, but are still illuminated (M17A1/M18A1).....	WP 0006 00
8. Elevation level vial, cross level vial, and counter dials have no illumination (M17A1/M18A1)	WP 0006 00
9. Elevation level vial, cross level vial, and counter dials have uneven or no illumination (M17/M18).....	WP 0005 00

END OF WORK PACKAGE

DIRECT SUPPORT

**M17/M18 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-037-7289)**

**TROUBLESHOOTING PROCEDURES
FIRE CONTROL LEVEL ASSEMBLY**

INITIAL SETUP:

Materials/Parts

Optical lens cleaning compound (item 11, WP 0152 00)
Plastic bag (item 5, WP 0152 00)
Tape (item 20, WP 0152 00)
Wiping rag (item 18, WP 0152 00)

References

TM 9-1025-211-34

FIRE CONTROL LEVEL ASSEMBLY

Table 1. Direct Support Troubleshooting Procedures.





MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>WARNING</p>		
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>RADIATION</p>  </div> <div style="text-align: center;">  <p>TRITIUM GAS (H₃)</p> </div> </div> <p>When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.</p>		
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  <p>1fc019</p> </div> <div style="text-align: center;">  <p>1fc020</p> </div> </div>		
<p style="text-align: center;">M17 Quadrant</p> <ol style="list-style-type: none"> 1. ELEVATION LEVEL VIAL (1), CROSS LEVEL VIAL (2), AND COUNTER DIALS (3) HAVE UNEVEN OR NO ILLUMINATION. 2. ELEVATION LEVEL VIAL (1) AND CROSS LEVEL VIAL (2) HAVE NO BUBBLE, BUT ARE STILL ILLUMINATED. 	<p>Observe visually in darkened area.</p> <p>Observe visually.</p>	<p style="text-align: center;">M18 Quadrant</p> <ol style="list-style-type: none"> 1. Contact RSO immediately. 2. Perform wipe test under RSO supervision. 3. Remove, bag, and secure device under RSO direction and await wipe test results. 4. If contaminated, dispose of device per RSO instructions. 5. If device is not contaminated, evacuate to next higher level of maintenance. 1. Contact RSO immediately. 2. Perform wipe test under RSO supervision. 3. Remove, bag, and secure device under RSO direction and await wipe test results.

Table 1. Direct Support Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>3. ELEVATION LEVEL VIAL (1) AND CROSS LEVEL VIAL (2) HAVE NO BUBBLE AND ARE NOT ILLUMINATED.</p>	<p>Observe visually.</p>	<p>4. If contaminated, dispose of device per RSO instructions.</p> <p>5. If device is not contaminated, evacuate to next higher level of maintenance.</p> <p>1. Contact RSO immediately.</p> <p>2. Perform wipe test under RSO supervision.</p> <p>3. Remove, bag, and secure device under RSO direction and await wipe test results.</p> <p>4. Howitzer should be secured until wipe test results show howitzer is not contaminated.</p> <p>5. If contaminated, dispose of device per RSO instructions.</p> <p>6. If device is not contaminated, evacuate to next higher level of maintenance.</p>
<p>4. BUBBLE IN ELEVATION LEVEL VIAL (1) IS NOT SYNCHRONIZED WITH M198 HOWITZER TUBE.</p>	<p>Observe visually.</p>	<p>1. Perform the cannon tube synchronization procedure (TM 9-1025-211-34).</p> <p>2. If unable to complete synchronization procedure, notify next higher level of maintenance.</p>
<p>5. ELEVATION LEVEL VIAL (1) AND CROSS LEVEL VIAL (2) CANNOT BE READ CLEARLY IN MIRROR.</p>	<p>Observe visually.</p>	<p style="text-align: center;">WARNING</p> <p>Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.</p> <p>Clean mirror with optical lens cleaning compound (item 11, WP 0152 00). Wipe dry.</p>

END OF WORK PACKAGE

DIRECT SUPPORT**M17A1/M18A1 FIRE CONTROL QUADRANT
(1290-01-515-8260/1290-01-515-8262)****TROUBLESHOOTING PROCEDURES
FIRE CONTROL LEVEL ASSEMBLY**

INITIAL SETUP:**Materials/Parts**

Battery (2) (item 8, WP 0152 00)
Optical lens cleaning compound (item 11, WP 0152 00)
Wiping rag (item 18, WP 0152 00)

References

TM 9-1025-211-34
TM 9-1025-215-25&P
WP 0047 00

FIRE CONTROL LEVEL ASSEMBLY**WARNING**

Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries.

FIRE CONTROL LEVEL ASSEMBLY - Continued

Table 1. Direct Support Troubleshooting Procedures.



MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<div style="text-align: center;">  <p>1fc021</p> <p>M17A1 Quadrant</p> <p>1. ELEVATION LEVEL VIAL (1), CROSS LEVEL VIAL (2), AND COUNTER DIALS (3) HAVE NO ILLUMINATION.</p> </div>	<p>Observe visually in darkened area.</p>	<div style="text-align: center;">  <p>1fc022</p> <p>M18A1 Quadrant</p> <p>1. Cycle ON/OFF pushbutton switch.</p> <p>a. Press red push-button switch on battery enclosure.</p> <p style="text-align: center;">NOTE</p> <p>Switch has an approximate three-second delay.</p> <p>b. Wait approximately three seconds and check if light-emitting diode (LED) light sources are ON/OFF.</p> <p>c. Repeat above steps until assured of correct operation.</p> <p>2. Check for proper battery installation (same as diagram on battery enclosure).</p> </div>

Table 1. Direct Support Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>2. ELEVATION LEVEL VIAL (1) AND CROSS LEVEL VIAL (2) HAVE NO BUBBLE, BUT ARE STILL ILLUMINATED.</p>	<p>Observe visually.</p>	<p>3. Replace batteries (item 8, WP 0152 00).</p> <ul style="list-style-type: none"> a. Unscrew battery caps. b. Remove batteries using magnet in battery cap. c. Install new batteries in same direction as diagram on battery enclosure. d. Replace battery caps. <p>4. Replace battery enclosure assembly (4) (WP 0047 00).</p> <p>5. Notify next higher level of maintenance.</p> <p>Notify next higher level of maintenance.</p>
<p>3. BUBBLE IN ELEVATION LEVEL VIAL (1) IS NOT SYNCHRONIZED WITH M198/M777 HOWITZER TUBE.</p>	<p>Observe visually.</p>	<p>1. Perform the cannon tube synchronization procedure (TM 9-1025-211-34/TM 9-1025-215-25&P).</p> <p>2. If unable to complete synchronization procedure, notify next higher level of maintenance.</p>
<p>4. ELEVATION LEVEL VIAL (1) AND CROSS LEVEL VIAL (2) CANNOT BE READ CLEARLY IN MIRROR.</p>	<p>Observe visually.</p>	<p style="text-align: center;">WARNING</p> <p>Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.</p> <p>Clean mirror with optical lens cleaning compound (item 11, WP 0152 00). Wipe dry.</p>

END OF WORK PACKAGE

DIRECT SUPPORT

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)**

**TROUBLESHOOTING PROCEDURES
COVER ASSEMBLY**

INITIAL SETUP:

Materials/Parts

Soap (item 19, WP 0152 00)

References

TM 750-116
WP 0046 00

COVER ASSEMBLY

Table 1. Direct Support Troubleshooting Procedures.

NOTE

The following steps are written and illustrated for the M17/M18 quadrant but also apply to the M17A1/M18A1 quadrant.





MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>WARNING</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>RADIATION</p>  </div> <div style="text-align: center;">  <p>TRITIUM GAS (H₃)</p> </div> </div> <p>When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.</p>		
 <p style="text-align: right; margin-right: 50px;">1fc023</p>		
<p>M17 Quadrant</p>  <p style="text-align: right; margin-right: 50px;">1fc024</p>		
<p>M18 Quadrant</p>		

Table 1. Direct Support Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. COUNTER WINDOWS (1) ARE FOGGED OR HAVE CONDENSATION.</p>	<p style="text-align: center;">NOTE</p> <p>Charge nitrogen pressure to 7 psi (48 kPa). Remove hose. Put soap suds (item 19, WP 0152 00) on valve openings to check for leakage.</p> <p>1. Check for loose or defective valves (2).</p>	<p>1. Tighten or replace valves (WP 0046 00).</p> <p>2. Purge and charge M17/M18 quadrant with dry nitrogen (TM 750-116).</p> <p>3. If counter windows (1) are still fogged, evacuate to next higher level of maintenance.</p>

END OF WORK PACKAGE

CHAPTER 3

**GENERAL SUPPORT
TROUBLESHOOTING PROCEDURES
FOR
M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT**

GENERAL SUPPORT**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)****TROUBLESHOOTING INDEX**

INTRODUCTION

a. The troubleshooting procedures are limited to those listed in the troubleshooting symptom index. The table lists the common malfunctions, which you may find during the operation of maintenance of the M17/M17A1 and M18/M18A1 Fire Control Quadrant. You should perform the tests/inspections and corrective actions in the order listed.

b. This manual cannot list all malfunctions that may occur, or all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

c. Each work package is headed by an initial setup. This setup outlines what is needed as well as certain conditions, which must be met before starting the task. **DON'T START A TASK UNTIL:**

You understand the task;

You understand what you are to do;

You understand what is needed to do the work;

You have the things you need.

MALFUNCTION/SYMPTOM INDEX

a. The malfunction/symptom index is a quick reference index for finding troubleshooting procedures. Associated with each symptom name is a work package sequence number representing the starting point in a troubleshooting sequence. Should any one symptom require more than one troubleshooting sequence to arrive at the most likely area of investigation, the additional starting point numbers are presented.

b. As the troubleshooting activity progresses to the conclusion of a particular sequence, a reference is made to the next logical troubleshooting sequence by work package sequence number or by referring to the malfunction/symptom index to locate the next failure symptom work package. This type of activity continues until successful fault isolation is achieved.

MALFUNCTION/SYMPTOM INDEX - Continued

<u>Malfunction/Symptom</u>	<u>Work Package</u>
CORRECTION KNOB ASSEMBLY (M17/M17A1/M18/M18A1)	
1. Correction knob binds	WP 0011 00
COUNTER ASSEMBLY (M17/M17A1/M18/M18A1)	
1. Correction counter fails to allow +95 to +99 mils max or -95 to -99 mils max.....	WP 0012 00
2. Counter numbers are not in horizontal alignment.....	WP 0012 00
3. Elevation counter fails to allow 1433 or 9720 mils.....	WP 0012 00
COVER ASSEMBLY (M17/M17A1/M18/M18A1)	
1. Counter windows are fogged or have condensation.....	WP 0010 00
FIRE CONTROL LEVEL ASSEMBLIES (M17/M18)	
1. Bubble in elevation level vial is not level	WP 0009 00
2. Bubble in elevation level vial is not synchronized with M198 howitzer tube.....	WP 0009 00
3. Elevation level vial and cross level vial have no bubble and are not illuminated.....	WP 0009 00
4. Elevation level vial and cross level vial have no bubble, but are still illuminated ...	WP 0009 00
5. Elevation level vial, cross level vial, and counter dials have uneven or no illumination.....	WP 0009 00
WORM SHAFT ASSEMBLY (M17/M17A1/M18/M18A1)	
1. Elevation knob exceeds 0.7-mil backlash	WP 0013 00

END OF WORK PACKAGE

GENERAL SUPPORT

**M17/M18 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-037-7289)**

**TROUBLESHOOTING PROCEDURES
FIRE CONTROL LEVEL ASSEMBLIES**

INITIAL SETUP:

Materials/Parts

Plastic bag (item 5, WP 0152 00)

Tape (item 20, WP 0152 00)

References

WP 0051 00

WP 0056 00

WP 0057 00

FIRE CONTROL LEVEL ASSEMBLIES

Table 1. Troubleshooting Procedures.





MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
 <p style="text-align: center;">M17 Quadrant</p> <p style="text-align: right;"><small>1fc025</small></p>	 <p style="text-align: center;">M18 Quadrant</p> <p style="text-align: right;"><small>1fc026</small></p>	<p style="text-align: center;">WARNING</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>RADIATION</p>  </div> <div style="text-align: center;"> <p>TRITIUM GAS (H₃)</p>  </div> </div> <p style="text-align: center;">When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.</p>
<p>1. BUBBLE IN ELEVATION LEVEL VIAL (1) IS NOT SYNCHRONIZED WITH M198 HOWITZER TUBE.</p>	<p>Observe visually.</p>	<p>Synchronize elevation level bubble and cannon tube (WP 0057 00).</p>

Table 1. Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>2. ELEVATION LEVEL VIAL (1), CROSS LEVEL VIAL (2), AND COUNTER DIALS (3) HAVE UNEVEN OR NO ILLUMINATION.</p>	<p>Observe visually in darkened area.</p>	<ol style="list-style-type: none"> 1. Contact RSO immediately. 2. Perform wipe test under RSO supervision. 3. Remove, bag, and secure device under RSO direction and await wipe test results. 4. If contaminated, dispose of device per RSO instructions. 5. If device is not contaminated, replace elevation level vial (WP 0051 00). 6. If device is not contaminated, replace cross level vial (WP 0056 00). 7. If device is not contaminated, send to depot for replacement of tritium that illuminates the counter. 8. Dispose of replaced vial per RSO instructions.
<p>3. ELEVATION LEVEL VIAL (1) AND CROSS LEVEL VIAL (2) HAVE NO BUBBLE, BUT ARE STILL ILLUMINATED.</p>	<p>Observe visually.</p>	<ol style="list-style-type: none"> 1. Contact RSO immediately. 2. Perform wipe test under RSO supervision. 3. Remove, bag, and secure device under RSO direction and await wipe test results. 4. If contaminated, dispose of device per RSO instructions. 5. If device is not contaminated, replace elevation level vial (WP 0051 00). 6. If device is not contaminated, replace cross level vial (WP 0056 00). 7. Dispose of replaced vial per RSO instructions.

FIRE CONTROL LEVEL ASSEMBLIES - Continued

Table 1. Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>4. ELEVATION LEVEL VIAL (1) AND CROSS LEVEL VIAL (2) HAVE NO BUBBLE AND ARE NOT ILLUMINATED.</p>	<p>Observe visually.</p>	<ol style="list-style-type: none"> 1. Contact RSO immediately. 2. Perform wipe test under RSO supervision. 3. Remove, bag, and secure device under RSO direction and await wipe test results. 4. Howitzer should be secured until wipe test results show howitzer is not contaminated. 5. If contaminated, dispose of device per RSO instructions. 6. If device is not contaminated, replace elevation level vial (WP 0051 00). 7. If device is not contaminated, replace cross level vial (WP 0056 00). 8. Dispose of replaced vial per RSO instructions.
<p>5. BUBBLE IN ELEVATION LEVEL VIAL (1) IS NOT LEVEL.</p>	<p>Observe visually.</p>	<p>Adjust eccentric (WP 0051 00).</p>

END OF WORK PACKAGE

GENERAL SUPPORT

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)**

**TROUBLESHOOTING PROCEDURES
COVER ASSEMBLY**

INITIAL SETUP:

References





TM 750-116
WP 0052 00
WP 0053 00

COVER ASSEMBLY

Table 1. Troubleshooting Procedures.

NOTE

The following steps are written and illustrated for the M17/M18 quadrant but also apply to the M17A1/M18A1 quadrant.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<div style="text-align: center;">  <p>M17/M17A1 Quadrant</p> </div>	<div style="text-align: center;">  <p>M18/M18A1 Quadrant</p> </div>	<div style="text-align: center;"> <p>WARNING</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>RADIATION</p>  </div> <div style="text-align: center;">  <p>TRITIUM GAS (H₃)</p> </div> </div> <p>When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.</p> </div>
<p>1. COUNTER WINDOWS (1) ARE FOGGED OR HAVE CONDENSATION.</p>	<p>Check for damaged glass or defective or missing parts.</p>	<ol style="list-style-type: none"> 1. Replace glass if required (WP 0052 00, WP 0053 00). 2. Replace defective or missing parts as required and authorized (WP 0052 00, WP 0053 00). 3. Purge and charge quadrant with dry nitrogen (TM 750-116).

END OF WORK PACKAGE

GENERAL SUPPORT

M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)

TROUBLESHOOTING PROCEDURES
CORRECTION KNOB ASSEMBLY

INITIAL SETUP:

References





WP 0049 00
WP 0050 00
WP 0054 00

CORRECTION KNOB ASSEMBLY

Table 1. Troubleshooting Procedures.

NOTE

The following steps are written and illustrated for the M17/M18 quadrant but also apply to the M17A1/M18A1 quadrant.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>M17/M17A1 Quadrant</p> </div> <div style="text-align: center;">  <p>M18/M18A1 Quadrant</p> </div> </div>		
<p>WARNING</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>RADIATION</p>  </div> <div style="text-align: center;">  <p>TRITIUM GAS (H₃)</p> </div> </div> <p>When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.</p>		
<p>1. CORRECTION KNOB (1) BINDS.</p>	<p>1. Check for defective correction knob assembly.</p> <p>2. Check for defective correction counter.</p>	<p>Replace correction knob assembly (WP 0049 00, WP 0050 00).</p> <p>Replace correction counter (WP 0054 00).</p>

END OF WORK PACKAGE

GENERAL SUPPORT

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)**

**TROUBLESHOOTING PROCEDURES
COUNTER ASSEMBLY**

INITIAL SETUP:

References

WP 0049 00

WP 0050 00

WP 0054 00


COUNTER ASSEMBLY

Table 1. Troubleshooting Procedures.


NOTE

The following steps are written and illustrated for the M17/M18 quadrant but also apply to the M17A1/M18A1 quadrant.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------



M17/M17A1 Quadrant



M18/M18A1 Quadrant

WARNING

RADIATION



TRITIUM
GAS (H₃)

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

COUNTER ASSEMBLY - Continued

Table 1. Troubleshooting Procedures – Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
1. CORRECTION COUNTER (1) FAILS TO ALLOW +95 to +99 MILS MAX OR -95 TO -99 MILS MAX.	Check for worn or damaged correction knob assembly (2).	Replace correction knob assembly (WP 0049 00, WP 0050 00).
2. COUNTER NUMBERS (3) ARE NOT IN HORIZONTAL ALIGNMENT.	1. Observe visually for defective counters. 2. Check for incorrectly installed counter assembly.	Replace counter assembly (WP 0054 00). Reinstall counter assembly correctly (WP 0054 00).
3. ELEVATION COUNTER (4) FAILS TO ALLOW 1433 OR 9720 MILS.	1. Observe visually for defective counter assembly. 2. Check for incorrectly installed counter assembly. 3. Check for incorrectly installed elevation counter.	Replace counter assembly (WP 0054 00). Reinstall counter assembly correctly (WP 0054 00). Reinstall counter correctly (WP 0054 00).

END OF WORK PACKAGE

GENERAL SUPPORT

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)**

**TROUBLESHOOTING PROCEDURES
WORM SHAFT ASSEMBLY**

INITIAL SETUP:

References





WP 0055 00

WORM SHAFT ASSEMBLY

Table 1. Troubleshooting Procedures.

NOTE

The following steps are written and illustrated for the M17/M18 quadrant but also apply to the M17A1/M18A1 quadrant.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>M17/M17A1 Quadrant</p> </div> <div style="text-align: center;">  <p>M18/M18A1 Quadrant</p> </div> </div> <div style="text-align: center; margin-top: 20px;"> <p>WARNING</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>RADIATION</p>  </div> <div style="text-align: center;">  <p>TRITIUM GAS (H₃)</p> </div> </div> <p>When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.</p> </div>	<ol style="list-style-type: none"> 1. Check for incorrectly adjusted retainers. 2. Check for worn or damaged parts. 	<p>Adjust retainers (WP 0055 00).</p> <p>Replace worm shaft assembly and replace parts as required and authorized (WP 0055 00).</p>

END OF WORK PACKAGE

CHAPTER 4

DIRECT SUPPORT
TROUBLESHOOTING PROCEDURES
FOR
M171/M171A1 TELESCOPE AND QUADRANT MOUNT

DIRECT SUPPORT**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)****TROUBLESHOOTING INDEX**

INTRODUCTION

a. The troubleshooting procedures are limited to those listed in the troubleshooting symptom index. The table lists the common malfunctions, which you may find during the operation or maintenance of the M171/M171A1 Telescope and Quadrant Mount. You should perform the tests/inspections and corrective actions in the order listed.

b. This manual cannot list all malfunctions that may occur, or all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

c. Each work package is headed by an initial setup. This setup outlines what is needed as well as certain conditions, which must be met before starting the task. **DON'T START A TASK UNTIL:**

You understand the task;

You understand what you are to do;

You understand what is needed to do the work;

You have the things you need.

MALFUNCTION/SYMPTOM INDEX

a. The malfunction/symptom index is a quick reference index for finding troubleshooting procedures. Associated with each symptom name is a work package sequence number representing the starting point in the troubleshooting sequence. Should any one symptom require more than one troubleshooting sequence to arrive at the most likely area of investigation, the additional starting point numbers are presented.

b. As the troubleshooting activity progresses to the conclusion of a particular sequence, a reference is made to the next logical troubleshooting sequence by work package sequence number or by referring to the malfunction/symptom index to locate the next failure symptom work package. This type of activity continues until successful fault isolation is achieved.

MALFUNCTION/SYMPTOM INDEX - Continued

<u>Malfunction/Symptom</u>	<u>Work Package</u>
BEARING HOUSING ASSEMBLY	
1. Cross level vial or elevation level vial has no illumination (M171A1).....	WP 0017 00
2. Cross level vial or elevation level vial has uneven or no illumination (M171).....	WP 0016 00
3. Cross level vial or elevation level vial is cracked or bubble is elongated and not illuminated (M171).....	WP 0016 00
4. Cross level vial or elevation level vial is cracked or bubble is elongated but still illuminated (M171)	WP 0016 00
5. Optical instrument mirror does not clearly reflect images of cross level vial and elevation level vial (M171).....	WP 0016 00
6. Optical instrument mirror does not clearly reflect images of cross level vial and elevation level vial (M171A1)	WP 0017 00
OPTICAL INSTRUMENT SUPPORT	
1. Optical instrument support does not seat M137/M137A2/M137A3 telescope correctly	WP 0015 00
2. Thumbscrews do not secure M137/M137A2/M137A3 telescope correctly (M171)	WP 0015 00
3. Latches do not secure M137/M137A2/M137A3 telescope correctly (M171A1).....	WP 0015 00

END OF WORK PACKAGE

DIRECT SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**TROUBLESHOOTING PROCEDURES
OPTICAL INSTRUMENT SUPPORT**

INITIAL SETUP:

Materials/Parts



- Abrasive cloth (item 9, WP 0152 00)
- Cleaning compound (item 12, WP 0152 00)
- Wiping rag (item 18, WP 0152 00)

References

- WP 0060 00
- WP 0061 00

OPTICAL INSTRUMENT SUPPORT

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>WARNING</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>RADIATION</p>  </div> <div style="text-align: center;">  <p>TRITIUM GAS (H₃)</p> </div> </div> <p>When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.</p>		

OPTICAL INSTRUMENT SUPPORT - Continued

Table 1. Troubleshooting Procedures - Continued.



MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
 <p style="text-align: center;">M171</p>	 <p style="text-align: center;">M171A1</p> <p style="text-align: right; font-size: small;">1fc032</p>	
<p>1. OPTICAL INSTRUMENT SUPPORT (1) DOES NOT SEAT M137/M137A2/M137A3 TELESCOPE CORRECTLY.</p>	<p>Check mounting surfaces for dirt and burrs.</p>	<p style="text-align: center;">WARNING</p> <p>Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.</p> <ol style="list-style-type: none"> 1. Clean mounting surface with cleaning compound (item 12, WP 0152 00). 2. Remove burrs on mounting surface with abrasive cloth (item 9, WP 0152 00) dipped in cleaning compound (item 12, WP 0152 00).
<p>2. THUMBSCREWS (2) DO NOT SECURE M137/M137A2/M137A3 TELESCOPE CORRECTLY (M171).</p>	<p>Check for serviceability of helicoil inserts on M137/M137A2/M137A3 telescope (pantel).</p> <p>Check for bent or damaged thumbscrews or damaged thumbscrew threads.</p>	<p>Replace thumbscrews (WP 0060 00), if pantel inserts have passed serviceability check.</p>

Table 1. Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>3. LATCHES (3) DO NOT SECURE M137/M137A2/M137A3 TELESCOPE CORRECTLY (M171A1).</p>	<p>Check for serviceability of pins on M137/M137A2/M137A3 telescope (pantel). Check for bent or damaged latches.</p>	<p>Replace latches (WP 0061 00), if pantel pins have passed serviceability check.</p>

END OF WORK PACKAGE

DIRECT SUPPORT

**M171 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273)**

**TROUBLESHOOTING PROCEDURES
BEARING HOUSING ASSEMBLY**

INITIAL SETUP:

Materials/Parts

- Optical lens cleaning compound (item 11, WP 0152 00)
- Plastic bag (item 5, WP 0152 00)
- Tape (item 20, WP 0152 00)
- Wiping rag (item 18, WP 0152 00)

References

- WP 0064 00
-

BEARING HOUSING ASSEMBLY

Table 1. Troubleshooting Procedures.


MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. OPTICAL INSTRUMENT MIRROR (1) DOES NOT CLEARLY REFLECT IMAGES OF CROSS LEVEL VIAL (2) AND ELEVATION LEVEL VIAL (3).</p> <p>2. CROSS LEVEL VIAL (2) OR ELEVATION LEVEL VIAL (3) HAS UNEVEN OR NO ILLUMINATION.</p>	<div style="text-align: center;">  <p style="text-align: right; font-size: small;">1fc033</p> </div> <p>Check mirror for dirt, damage, and scars.</p> <p>Observe visually in darkened area.</p>	<p style="text-align: center;">WARNING</p> <p>Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.</p> <ol style="list-style-type: none"> 1. Clean with cleaning compound (item 11, WP 0152 00). 2. Replace mirror (WP 0064 00). <ol style="list-style-type: none"> 1. Contact RSO immediately. 2. Perform wipe test under RSO supervision. 3. Remove, bag, and secure device under RSO direction and await wipe test results. 4. If contaminated, dispose of device per RSO instructions.

Table 1. Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>3. CROSS LEVEL VIAL (2) OR ELEVATION LEVEL VIAL (3) IS CRACKED OR BUBBLE IS ELONGATED BUT STILL ILLUMINATED.</p>	<p>Observe visually in darkened area.</p>	<ol style="list-style-type: none"> 5. If device is not contaminated, evacuate to next higher level of maintenance. 1. Contact RSO immediately. 2. Perform wipe test under RSO supervision. 3. Remove, bag, and secure device under RSO direction and await wipe test results. 4. Howitzer should be secured until wipe test results show howitzer is not contaminated. 5. If contaminated, dispose of device per RSO instructions. 6. If device is not contaminated, evacuate to next higher level of maintenance.
<p>4. CROSS LEVEL VIAL (2) OR ELEVATION LEVEL VIAL (3) IS CRACKED OR BUBBLE IS ELONGATED AND NOT ILLUMINATED.</p>	<p>Observe visually in darkened area.</p>	<ol style="list-style-type: none"> 1. Contact RSO immediately. 2. Perform wipe test under RSO supervision. 3. Remove, bag, and secure device under RSO direction and await wipe test results. 4. If contaminated, dispose of device per RSO instructions. 5. If device is not contaminated, evacuate to next higher level of maintenance.

END OF WORK PACKAGE

DIRECT SUPPORT**M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-515-8265)****TROUBLESHOOTING PROCEDURES
BEARING HOUSING ASSEMBLY**

INITIAL SETUP:**Materials/Parts**

Battery (item 8, WP 0152 00)
Cleaning compound (item 12, WP 0152 00)
Optical lens cleaning compound (item 11, WP 0152 00)
Wiping rag (item 18, WP 0152 00)

References

WP 0063 00
WP 0064 00

BEARING HOUSING ASSEMBLY**WARNING**

Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries.

BEARING HOUSING ASSEMBLY - Continued

Table 1. Troubleshooting Procedures.


MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. CROSS LEVEL VIAL (1) OR ELEVATION LEVEL VIAL (2) HAS NO ILLUMINATION.</p>	<div style="text-align: center;">  </div> <p>Observe visually in darkened area.</p>	<ol style="list-style-type: none"> 1. Check for proper battery installation (same as diagram on battery enclosure). 2. Replace battery (item 8, WP 0152 00). <ol style="list-style-type: none"> a. Unscrew battery cap. b. Remove battery using magnet in battery cap. c. Install new battery in same direction as diagram on battery enclosure. d. Replace battery cap. 3. Replace battery enclosure assembly (3) (WP 0063 00). 4. Notify next higher level of maintenance.

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>2. OPTICAL INSTRUMENT MIRROR (4) DOES NOT CLEARLY REFLECT IMAGES OF CROSS LEVEL VIAL (1) AND ELEVATION LEVEL VIAL (2).</p>	<p>Check mirror for dirt, damage, and scars.</p>	<p style="text-align: center;">WARNING</p> <p>Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.</p> <ol style="list-style-type: none"> 1. Clean with optical lens cleaning compound (item 11, WP 0152 00). 2. Replace mirror (WP 0064 00).

END OF WORK PACKAGE

CHAPTER 5

**GENERAL SUPPORT
TROUBLESHOOTING PROCEDURES
FOR
M171/M171A1 TELESCOPE AND QUADRANT MOUNT**

GENERAL SUPPORT**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)****TROUBLESHOOTING INDEX**

INTRODUCTION

a. The troubleshooting procedures are limited to those listed in the troubleshooting symptom index. The table lists the common malfunctions, which you may find during the operation or maintenance of the M171/M171A1 Telescope and Quadrant Mount. You should perform the tests/inspections and corrective actions in the order listed.

b. This manual cannot list all malfunctions that may occur, or all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

c. Each work package is headed by an initial setup. This setup outlines what is needed as well as certain conditions, which must be met before starting the task. **DON'T START A TASK UNTIL:**

You understand the task;

You understand what you are to do;

You understand what is needed to do the work;

You have the things you need.

MALFUNCTION/SYMPTOM INDEX

a. The malfunction/symptom index is a quick reference index for finding troubleshooting procedures. Associated with each symptom name is a work package sequence number representing the starting point in the troubleshooting sequence. Should any one symptom require more than one troubleshooting sequence to arrive at the most likely area of investigation, the additional starting point numbers are presented.

b. As the troubleshooting activity progresses to the conclusion of a particular sequence, a reference is made to the next logical troubleshooting sequence by work package sequence number or by referring to the malfunction/symptom index to locate the next failure symptom work package. This type of activity continues until successful fault isolation is achieved.

MALFUNCTION/SYMPTOM INDEX - Continued

<u>Malfunction/Symptom</u>	<u>Work Package</u>
BEARING HOUSING ASSEMBLY	
1. Bubble in cross level vial or bubble in elevation level vial does not center within one graduation line (M171).....	WP 0019 00
2. Bubble in cross level vial or bubble in elevation level vial does not center within one graduation line (M171A1)	WP 0020 00
3. Cross level vial or elevation level vial has no illumination (M171A1).....	WP 0020 00
4. Cross level vial or elevation level vial has uneven or no illumination (M171).....	WP 0019 00
5. Cross level vial or elevation level vial is cracked or broken (M171A1)	WP 0020 00
6. Cross level vial or elevation level vial is cracked or bubble is elongated but still illuminated (M171)	WP 0019 00
7. Cross level vial or elevation level vial is cracked or bubble is elongated and not illuminated (M171).....	WP 0019 00
8. M17/M17A1 quadrant does not mount correctly (M171)	WP 0019 00
9. M17/M17A1 quadrant does not mount correctly (M171A1).....	WP 0020 00
10. Plunger assembly binds (M171).....	WP 0019 00
11. Plunger assembly binds (M171A1)	WP 0020 00
HOUSING ASSEMBLY	
1. Elevation control is erratic and rough during movement	WP 0021 00
2. Elevation knob exceeds 1.5-mil backlash	WP 0021 00
3. Elevation knob requires torque in excess of 12.00 in.-lb (1.36 N-m) to rotate.....	WP 0021 00
OPTICAL INSTRUMENT ROCKER ASSEMBLY	
1. Cross level control is erratic and rough during movement	WP 0022 00
2. Cross level knob exceeds 1.5-mil backlash	WP 0022 00
3. Cross level knob requires torque in excess of 12.00 in.-lb (1.36 N-m) to rotate.....	WP 0022 00

END OF WORK PACKAGE

GENERAL SUPPORT**M171 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273)****TROUBLESHOOTING PROCEDURES
BEARING HOUSING ASSEMBLY**

INITIAL SETUP:**Materials/Parts**

Cleaning compound (item 12, WP 0152 00)
Plastic bag (item 5, WP 0152 00)
Tape (item 20, WP 0152 00)
Wiping rag (item 18, WP 0152 00)

References

WP 0065 00
WP 0072 00
WP 0073 00

BEARING HOUSING ASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

BEARING HOUSING ASSEMBLY - Continued

Table 1. Troubleshooting Procedures.


MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. BUBBLE IN CROSS LEVEL VIAL (1) OR BUBBLE IN ELEVATION LEVEL VIAL (2) DOES NOT CENTER WITHIN ONE GRADUATION LINE.</p> <p>2. CROSS LEVEL VIAL (1) OR ELEVATION LEVEL VIAL (2) HAS UNEVEN OR NO ILLUMINATION.</p>	 <p>Check for incorrect adjustment (WP 0073 00).</p> <p>1. Check cross level vial (1) or elevation level vial (2) for illumination.</p>	<p>Adjust bubble in cross level vial (1) or bubble in elevation level vial (2) correctly (WP 0073 00).</p> <p>1. Contact RSO immediately.</p> <p>2. Perform wipe test under RSO supervision.</p> <p>3. Remove, bag, and secure device under RSO direction and await wipe test results.</p> <p>4. If contaminated, dispose of device per RSO instructions.</p> <p>5. If device is not contaminated, replace cross level vial (1) or elevation level vial (2) (WP 0065 00).</p> <p>6. Dispose of replaced vial per RSO instructions.</p>

Table 1. Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>3. CROSS LEVEL VIAL (1) OR ELEVATION LEVEL VIAL (2) IS CRACKED OR BUBBLE IS ELONGATED BUT STILL ILLUMINATED.</p>	<p>Check cross level vial (1) or elevation level vial (2) for cracks.</p>	<ol style="list-style-type: none"> 1. Contact RSO immediately. 2. Perform wipe test under RSO supervision. 3. Remove, bag, and secure device under RSO direction and await wipe test results. 4. Howitzer should be secured until wipe test results show howitzer is not contaminated. 5. If contaminated, dispose of device per RSO instructions. 6. If device is not contaminated, replace cross level vial (1) or elevation level vial (2) (WP 0065 00). 7. Dispose of replaced vial per RSO instructions.
<p>4. CROSS LEVEL VIAL (1) OR ELEVATION LEVEL VIAL (2) IS CRACKED OR BUBBLE IS ELONGATED AND NOT ILLUMINATED.</p>	<p>Check cross level vial (1) or elevation level vial (2) for cracks.</p>	<ol style="list-style-type: none"> 1. Contact RSO immediately. 2. Perform wipe test under RSO supervision. 3. Remove, bag, and secure device under RSO direction and await wipe test results. 4. If contaminated, dispose of device per RSO instructions. 5. If device is not contaminated, replace cross level vial (1) or elevation level vial (2) (WP 0065 00). 6. Dispose of replaced vial per RSO instructions.
<p>5. M17/M17A1 QUADRANT DOES NOT MOUNT CORRECTLY.</p>	<ol style="list-style-type: none"> 1. Check for worn or defective keys (3). 2. Check for bent or damaged mounting adapter (4). 	<p>If worn or defective, replace keys (3) (WP 0072 00).</p> <p>If bent or damaged, replace mounting adapter (WP 0072 00).</p>

BEARING HOUSING ASSEMBLY - Continued

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>6. PLUNGER ASSEMBLY (5) BINDS.</p>	<p>Check for dirt or foreign material.</p>	<p style="text-align: center;">WARNING</p> <p>Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.</p> <p>Clean with cleaning compound (item 12, WP 0152 00).</p>

END OF WORK PACKAGE

GENERAL SUPPORT**M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-515-8265)****TROUBLESHOOTING PROCEDURES
BEARING HOUSING ASSEMBLY**

INITIAL SETUP:**Materials/Parts**

- Battery (item 8, WP 0152 00)
- Cleaning compound (item 12, WP 0152 00)
- Wiping rag (item 18, WP 0152 00)

References

- WP 0063 00
 - WP 0065 00
 - WP 0072 00
 - WP 0073 00
-


BEARING HOUSING ASSEMBLY**WARNING**

Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries.

BEARING HOUSING ASSEMBLY - Continued

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. BUBBLE IN CROSS LEVEL VIAL (1) OR BUBBLE IN ELEVATION LEVEL VIAL (2) DOES NOT CENTER WITHIN ONE GRADUATION LINE.</p> <p>2. CROSS LEVEL VIAL (1) OR ELEVATION LEVEL VIAL (2) HAS NO ILLUMINATION.</p>	<p>Check for incorrect adjustment (WP 0073 00).</p> <p>Observe visually.</p>	<p>Adjust bubble in cross level vial (1) or bubble in elevation level vial (2) correctly (WP 0073 00).</p> <p>1. Check for proper battery installation (same as diagram on battery enclosure).</p> <p>2. Replace battery (item 8, WP 0152 00).</p> <p>a. Unscrew battery cap.</p> <p>b. Remove battery using magnet in battery cap.</p> <p>c. Install new battery in same direction as diagram on battery enclosure.</p> <p>d. Replace battery cap.</p>



1fc035a

Table 1. Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>3. CROSS LEVEL VIAL (1) OR ELEVATION LEVEL VIAL (2) IS CRACKED OR BROKEN.</p> <p>4. M17/M17A1 QUADRANT DOES NOT MOUNT CORRECTLY.</p> <p>5. PLUNGER ASSEMBLY (6) BINDS.</p>	<p>Visually check for cracks or breaks.</p> <p>1. Check for worn or defective keys (4).</p> <p>2. Check for bent or damaged mounting adapter (5).</p> <p>Check for dirt or foreign material.</p>	<p>3. Replace battery enclosure assembly (3) (WP 0063 00).</p> <p style="text-align: center;">CAUTION</p> <p>To prevent equipment damage, ensure that elevation level vial and cross level vial are positioned correctly.</p> <p>Replace vials (WP 0065 00).</p> <p>If worn or defective, replace keys (4) (WP 0072 00).</p> <p>If bent or damaged, replace mounting adapter (WP 0072 00).</p> <p style="text-align: center;">WARNING</p> <p>Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.</p> <p>Clean with cleaning compound (item 12, WP 0152 00).</p>

END OF WORK PACKAGE

GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**TROUBLESHOOTING PROCEDURES
HOUSING ASSEMBLY**


INITIAL SETUP:

References

WP 0070 00

HOUSING ASSEMBLY

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. ELEVATION CONTROL IS ERRATIC AND ROUGH DURING MOVEMENT.</p> <p>2. ELEVATION KNOB (1) EXCEEDS 1.5-MIL BACKLASH.</p> <p>3. ELEVATION KNOB (1) REQUIRES TORQUE IN EXCESS OF 12.00 IN.-LB (1.36 N-M) TO ROTATE.</p>	 <p>1fc036</p> <p>1. Check for worn or defective worm shaft assembly.</p> <p>2. Check for worn or defective gears in gear sector.</p> <p>1. Check for loose or worn V-bearing or plain bearing.</p> <p>2. Check for worn or defective worm shaft assembly.</p> <p>1. Check V-bearing tightness.</p> <p>2. Check for defective worm shaft assembly, plain bearing, or V-bearing.</p>	<p>If worn or defective, replace worm shaft assembly (WP 0070 00).</p> <p>If worn or defective, replace gear sector (WP 0070 00).</p> <p>Replace V-bearing or plain bearing (WP 0070 00).</p> <p>If worn or defective, replace worm shaft assembly (WP 0070 00).</p> <p>Loosen plug, and adjust torque (WP 0070 00).</p> <p>Replace worm shaft assembly, plain bearing, or V-bearing (WP 0070 00).</p>

END OF WORK PACKAGE

GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**TROUBLESHOOTING PROCEDURES
OPTICAL INSTRUMENT ROCKER ASSEMBLY**

INITIAL SETUP:


References

WP 0069 00

WP 0070 00

OPTICAL INSTRUMENT ROCKER ASSEMBLY

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. CROSS LEVEL CONTROL IS ERRATIC AND ROUGH DURING MOVEMENT.</p> <p>2. CROSS LEVEL KNOB (1) EXCEEDS 1.5-MIL BACKLASH.</p> <p>3. CROSS LEVEL KNOB (1) REQUIRES TORQUE IN EXCESS OF 12.00 IN.-LB (1.36 N-M) TO ROTATE.</p>	 <p>1. Check for worn or defective worm shaft assembly.</p> <p>2. Check for worn or defective gears in gear sector.</p> <p>1. Check for loose or worn V-bearing or plain bearing.</p> <p>2. Check for worn or defective worm shaft assembly.</p> <p>1. Check V-bearing tightness.</p> <p>2. Check for defective worm shaft assembly, plain bearing, or V-bearing.</p>	<p>Replace worm shaft assembly (WP 0069 00).</p> <p>Replace gear sector (WP 0070 00).</p> <p>Replace V-bearing or plain bearing (WP 0069 00).</p> <p>Replace worm shaft assembly (WP 0069 00).</p> <p>Loosen plug, and adjust torque (WP 0069 00).</p> <p>Replace worm shaft assembly, plain bearing, or V-bearing (WP 0069 00).</p>

END OF WORK PACKAGE

CHAPTER 6

DIRECT SUPPORT
TROUBLESHOOTING PROCEDURES
FOR
M172/M172A1 TELESCOPE AND QUADRANT MOUNT

DIRECT SUPPORT**M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)****TROUBLESHOOTING INDEX**

INTRODUCTION

a. The troubleshooting procedures are limited to those listed in the troubleshooting symptom index. The table lists the common malfunctions, which you may find during the operation or maintenance of the M172/M172A1 Telescope and Quadrant Mount. You should perform the tests/inspections and corrective actions in the order listed.

b. This manual cannot list all malfunctions that may occur, or all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

c. Each work package is headed by an initial setup. This setup outlines what is needed as well as certain conditions, which must be met before starting the task. **DON'T START A TASK UNTIL:**

You understand the task;

You understand what you are to do;

You understand what is needed to do the work;

You have the things you need.

MALFUNCTION/SYMPTOM INDEX

a. The malfunction/symptom index is a quick reference index for finding troubleshooting procedures. Associated with each symptom name is a work package sequence number representing the starting point in the troubleshooting sequence. Should any one symptom require more than one troubleshooting sequence to arrive at the most likely area of investigation, the additional starting point numbers are presented.

b. As the troubleshooting activity progresses to the conclusion of a particular sequence, a reference is made to the next logical troubleshooting sequence by work package sequence number or by referring to the malfunction/symptom index to locate the next failure symptom work package. This type of activity continues until successful fault isolation is achieved.

MALFUNCTION/SYMPTOM INDEX - Continued

<u>Malfunction/Symptom</u>	<u>Work Package</u>
ADAPTER ASSEMBLY	
1. Telescope mounting bracket difficult to level.....	WP 0024 00
QUADRANT ADAPTER	
1. M18/M18A1 quadrant does not mount correctly	WP 0025 00

END OF WORK PACKAGE

DIRECT SUPPORT

M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)

TROUBLESHOOTING PROCEDURES
ADAPTER ASSEMBLY

INITIAL SETUP:


References

WP 0076 00

ADAPTER ASSEMBLY

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. TELESCOPE MOUNTING BRACKET (1) DIFFICULT TO LEVEL.</p>	<p>Check for defective eccentric stud assembly.</p>	<p>Replace eccentric stud assembly (WP 0076 00).</p>



END OF WORK PACKAGE

DIRECT SUPPORT

M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)

TROUBLESHOOTING PROCEDURES
QUADRANT ADAPTER


INITIAL SETUP:

Materials/Parts

- Abrasive cloth (item 9, WP 0152 00)
- Cleaning compound (item 12, WP 0152 00)
- Wiping rag (item 18, WP 0152 00)

QUADRANT ADAPTER

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. M18/M18A1 QUADRANT DOES NOT MOUNT CORRECTLY.</p>	<div style="text-align: center;">  <p>1fc039</p> </div> <p>Check mounting surface (1) for dirt or burrs.</p>	<p style="text-align: center;">WARNING</p> <p>Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever cleaning compound is used.</p> <p>1. Clean mounting surface with cleaning compound (item 12, WP 0152 00).</p>

QUADRANT ADAPTER - Continued**Table 1. Troubleshooting Procedures.**

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
1. M18/M18A1 QUADRANT DOES NOT MOUNT CORRECTLY - Continued.		2. Remove burrs on mounting surface with abrasive cloth (item 9, WP 0152 00) dipped in cleaning compound (item 12, WP 0152 00).

END OF WORK PACKAGE

CHAPTER 7

**GENERAL SUPPORT
TROUBLESHOOTING PROCEDURES
FOR
M172/M172A1 TELESCOPE AND QUADRANT MOUNT**

GENERAL SUPPORT**M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)****TROUBLESHOOTING INDEX**

INTRODUCTION

a. The troubleshooting procedures are limited to those listed in the troubleshooting symptom index. The table lists the common malfunctions, which you may find during the operation or maintenance of the M172/M172A1 Telescope and Quadrant Mount. You should perform the tests/inspections and corrective actions in the order listed.

b. This manual cannot list all malfunctions that may occur, or all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

c. Each work package is headed by an initial setup. This setup outlines what is needed as well as certain conditions, which must be met before starting the task. **DON'T START A TASK UNTIL:**

You understand the task;

You understand what you are to do;

You understand what is needed to do the work;

You have the things you need.

MALFUNCTION/SYMPTOM INDEX

a. The malfunction/symptom index is a quick reference index for finding troubleshooting procedures. Associated with each symptom name is a work package sequence number representing the starting point in the troubleshooting sequence. Should any one symptom require more than one troubleshooting sequence to arrive at the most likely area of investigation, the additional starting point numbers are presented.

b. As the troubleshooting activity progresses to the conclusion of a particular sequence, a reference is made to the next logical troubleshooting sequence by work package sequence number or by referring to the malfunction/symptom index to locate the next failure symptom work package. This type of activity continues until successful fault isolation is achieved.

MALFUNCTION/SYMPTOM INDEX - Continued

<u>Malfunction/Symptom</u>	<u>Work Package</u>
M172/M172A1 TELESCOPE AND QUADRANT MOUNT	
1. Cross level control is erratic and rough during movement	WP 0027 00
2. Cross level knob exceeds 1.5-mil backlash	WP 0027 00
3. Cross level knob requires torque in excess of 12.00 in.-lb (1.36 N-m) to rotate.....	WP 0027 00
TELESCOPE MOUNTING BRACKET	
1. Telescope mounting bracket does not seat M138/M138A1 telescope correctly.....	WP 0028 00
2. Shaft does not seat correctly in M138/M138A1 telescope latch assembly	WP 0028 00

END OF WORK PACKAGE

GENERAL SUPPORT

**M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)**

**TROUBLESHOOTING PROCEDURES
M172/M172A1 TELESCOPE AND QUADRANT MOUNT**

INITIAL SETUP:


References

WP 0077 00

WP 0080 00

M172/M172A1 TELESCOPE AND QUADRANT MOUNT

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. CROSS LEVEL CONTROL IS ERRATIC AND ROUGH DURING MOVEMENT.</p> <p>2. CROSS LEVEL KNOB (1) EXCEEDS 1.5-MIL BACKLASH.</p> <p>3. CROSS LEVEL KNOB (1) REQUIRES TORQUE IN EXCESS OF 12.00 IN.-LB (1.36 N-M) TO ROTATE.</p>	 <p>1fc039a</p> <p>1. Check for worn or defective worm shaft assembly.</p> <p>2. Check for worn or defective gears in gear sector.</p> <p>1. Check for loose or worn V-bearing or plain bearing.</p> <p>2. Check for worn or defective worm shaft assembly.</p> <p>1. Check V-bearing tightness.</p> <p>2. Check for defective worm shaft assembly, plain bearing, or V-bearing.</p>	<p>Replace worm shaft assembly (WP 0077 00).</p> <p>Replace gear sector (WP 0080 00).</p> <p>Replace V-bearing or plain bearing (WP 0077 00).</p> <p>Replace worm shaft assembly (WP 0077 00).</p> <p>Loosen plug, and adjust torque (WP 0077 00).</p> <p>Replace worm shaft assembly, plain bearing, or V-bearing (WP 0077 00).</p>

END OF WORK PACKAGE

GENERAL SUPPORT

**M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)**

**TROUBLESHOOTING PROCEDURES
TELESCOPE MOUNTING BRACKET**

INITIAL SETUP:

Materials/Parts

- Abrasive cloth (item 9, WP 0152 00)
- Cleaning compound (item 12, WP 0152 00)
- Wiping rag (item 18, WP 0152 00)

References

- WP 0078 00
-

CHAPTER 8

DIRECT SUPPORT
TROUBLESHOOTING PROCEDURES
FOR
M137/M137A2/M137A3 PANORAMIC TELESCOPE

DIRECT SUPPORT**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)****TROUBLESHOOTING INDEX**

INTRODUCTION

a. The troubleshooting procedures are limited to those listed in the troubleshooting symptom index. The table lists the common malfunctions, which you may find during the operation or maintenance of the M137/M137A2/M137A3 Panoramic Telescope. You should perform the tests/inspections and corrective actions in the order listed.

b. This manual cannot list all malfunctions that may occur, or all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

c. Each work package is headed by an initial setup. This setup outlines what is needed as well as certain conditions, which must be met before starting the task. **DON'T START A TASK UNTIL:**

You understand the task;

You understand what you are to do;

You understand what is needed to do the work;

You have the things you need.

MALFUNCTION/SYMPTOM INDEX

a. The malfunction/symptom index is a quick reference index for finding troubleshooting procedures. Associated with each symptom name is a work package sequence number representing the starting point in the troubleshooting sequence. Should any one symptom require more than one troubleshooting sequence to arrive at the most likely area of investigation, the additional starting point numbers are presented.

b. As the troubleshooting activity progresses to the conclusion of a particular sequence, a reference is made to the next logical troubleshooting sequence by work package sequence number or by referring to the malfunction/symptom index to locate the next failure symptom work package. This type of activity continues until successful fault isolation is achieved.

MALFUNCTION/SYMPTOM INDEX - Continued

<u>Malfunction/Symptom</u>	<u>Work Package</u>
COUNTER BOX ASSEMBLY	
1. Azimuth counter cover does not remain open or closed (M137).....	WP 0034 00
2. Azimuth counter cover does not remain open or closed (M137A2/M137A3).....	WP 0035 00
3. Counter box windows are fogged or have condensation (M137)	WP 0034 00
4. Counter box windows are fogged or have condensation (M137A2/M137A3)	WP 0035 00
5. Counter dials have uneven or no illumination (M137).....	WP 0034 00
6. Counter dials have no illumination (M137A2/M137A3).....	WP 0035 00
COVER ASSEMBLY (HEAD)	
1. Cover plate does not latch correctly	WP 0031 00
ELBOW ASSEMBLY	
1. Elbow assembly does not latch correctly	WP 0033 00
HEAD ASSEMBLY	
1. Head assembly elevation knob binds	WP 0030 00
KNOB ASSEMBLY (AZIMUTH)	
1. Azimuth knob does not function properly	WP 0032 00
OPTICAL ELEMENTS	
1. Internal optics are fogged or have condensation.....	WP 0036 00
2. Reticle and image have parallax.....	WP 0036 00
3. Reticle does not illuminate (M137A2/M137A3)	WP 0036 00
4. Reticle does not illuminate or has uneven illumination (M137).....	WP 0036 00

END OF WORK PACKAGE

DIRECT SUPPORT

M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)

TROUBLESHOOTING PROCEDURES
HEAD ASSEMBLY

INITIAL SETUP:

None


HEAD ASSEMBLY

Table 1. Troubleshooting Procedures.

NOTE

The following steps are written and illustrated for the M137 telescope but also apply to the M137A2/M137A3 telescope.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. HEAD ASSEMBLY ELEVATION KNOB (1) BINDS.</p>	<p>Check for bent actuator.</p>	<p>Notify general support maintenance.</p>



END OF WORK PACKAGE

DIRECT SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**TROUBLESHOOTING PROCEDURES
COVER ASSEMBLY (HEAD)**

INITIAL SETUP:

References

WP 0086 00


COVER ASSEMBLY (HEAD)

Table 1. Troubleshooting Procedures.

NOTE

The following steps are written and illustrated for the M137 telescope but also apply to the M137A2/M137A3 telescope.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. COVER PLATE (1) DOES NOT LATCH CORRECTLY.</p>	<p>Check latch for correct operation.</p>	<p>Repair cover assembly (WP 0086 00).</p>



END OF WORK PACKAGE

DIRECT SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**TROUBLESHOOTING PROCEDURES
KNOB ASSEMBLY (AZIMUTH)**

INITIAL SETUP:

References

WP 0084 00


KNOB ASSEMBLY (AZIMUTH)

Table 1. Troubleshooting Procedures.

NOTE

The following steps are written and illustrated for the M137 telescope but also apply to the M137A2/M137A3 telescope.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. AZIMUTH KNOB (1) DOES NOT FUNCTION PROPERLY.</p>	<p>Check azimuth knob assembly for correct operation.</p>	<p>Replace azimuth knob assembly (WP 0084 00).</p>



END OF WORK PACKAGE

DIRECT SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**TROUBLESHOOTING PROCEDURES
ELBOW ASSEMBLY**

INITIAL SETUP:

References

WP 0088 00


ELBOW ASSEMBLY

Table 1. Troubleshooting Procedures.

NOTE

The following steps are written and illustrated for the M137 telescope but also apply to the M137A2/M137A3 telescope.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. ELBOW ASSEMBLY (1) DOES NOT LATCH CORRECTLY.</p>	<p>Check latch for correct operation.</p>	<p>Repair plunger (WP 0088 00).</p>



END OF WORK PACKAGE

DIRECT SUPPORT**M137 PANORAMIC TELESCOPE
(1240-01-038-0531)****TROUBLESHOOTING PROCEDURES
COUNTER BOX ASSEMBLY**

INITIAL SETUP:**Materials/Parts**

Plastic bag (item 5, WP 0152 00)

Tape (item 20, WP 0152 00)

References

TM 750-116

WP 0091 00

COUNTER BOX ASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

COUNTER BOX ASSEMBLY - Continued

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. AZIMUTH COUNTER COVER (1) DOES NOT REMAIN OPEN OR CLOSED.</p> <p>2. COUNTER BOX WINDOWS (2) ARE FOGGED OR HAVE CONDENSATION.</p> <p>3. COUNTER DIALS (3) HAVE UNEVEN OR NO ILLUMINATION.</p>	<div data-bbox="592 415 998 1228" data-label="Image"> </div> <p>Check cover assembly.</p> <p>1. Check for moisture in counter box.</p> <p>2. Check for loose purging valve stem or relief valve on counter box.</p> <p>Observe visually in darkened area.</p>	<p>Repair cover assembly (WP 0091 00).</p> <p>Purge and charge with dry nitrogen. Refer to TM 750-116.</p> <p>Tighten purging valve stem or relief valve.</p> <p>1. Contact RSO immediately.</p> <p>2. Perform wipe test under RSO supervision.</p>

Table 1. Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
		3. Remove, bag, and secure device under RSO direction and await wipe test results. 4. If contaminated, dispose of device per RSO instructions. 5. If device is not contaminated, evacuate to depot for maintenance.

END OF WORK PACKAGE

DIRECT SUPPORT**M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-483-6103/1240-01-483-6100)****TROUBLESHOOTING PROCEDURES
COUNTER BOX ASSEMBLY**

INITIAL SETUP:**Materials/Parts**

Battery (2) (item 8, WP 0152 00)

References

TM 750-116

WP 0084 00

WP 0091 00

COUNTER BOX ASSEMBLY**WARNING**

Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries.

COUNTER BOX ASSEMBLY - Continued

Table 1. Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<div data-bbox="402 403 1205 966" data-label="Image"> </div> <p data-bbox="1156 940 1205 961">1fc046</p> <p data-bbox="159 1033 552 1285"> 1. AZIMUTH COUNTER COVER (1) DOES NOT REMAIN OPEN OR CLOSED. 2. COUNTER BOX WINDOWS (2) ARE FOGGED OR HAVE CONDENSATION. </p>	<p data-bbox="604 1033 880 1064">Check cover assembly.</p> <p data-bbox="604 1192 1006 1411"> 1. Check for moisture in counter box. 2. Check for loose purging valve stem or relief valve on counter box. </p>	<p data-bbox="1049 1033 1383 1096">Repair cover assembly (WP 0091 00).</p> <p data-bbox="1049 1192 1380 1285">Purge and charge with dry nitrogen. Refer to TM 750-116.</p> <p data-bbox="1049 1318 1425 1381">Tighten purging valve stem or relief valve.</p>

Table 1. Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>3. COUNTER DIALS (3) HAVE NO ILLUMINATION.</p>	<p>Observe visually in darkened area.</p>	<ol style="list-style-type: none"> 1. Check for proper battery installation (same as diagram on battery enclosure). 2. Replace batteries (item 8, WP 0152 00). <ol style="list-style-type: none"> a. Unscrew battery caps. b. Remove batteries using magnet in battery cap. c. Install new batteries in same direction as diagram on battery enclosure. d. Replace battery caps. 3. Replace battery enclosure assembly (4) (WP 0084 00). 4. Notify next higher level of maintenance.

END OF WORK PACKAGE

DIRECT SUPPORT

M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)

TROUBLESHOOTING PROCEDURES
OPTICAL ELEMENTS

INITIAL SETUP:

Materials/Parts

- Battery (2) (item 8, WP 0152 00)
- Plastic bag (item 5, WP 0152 00)
- Tape (item 20, WP 0152 00)

References

- WP 0084 00

OPTICAL ELEMENTS

Table 1. Troubleshooting Procedures.

WARNING

RADIATION



TRITIUM
GAS (H₃)

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
1. RETICLE DOES NOT ILLUMINATE OR HAS UNEVEN ILLUMINATION (M137).	Visually inspect in darkened area.	<ol style="list-style-type: none"> 1. Contact RSO immediately. 2. Perform wipe test under RSO supervision. 3. Remove, bag, and secure device under RSO direction and await wipe test results. 4. If contaminated, dispose of device per RSO instructions. 5. If device is not contaminated, evacuate to depot for maintenance.

OPTICAL ELEMENTS - Continued

Table 1. Troubleshooting Procedures - Continued.

WARNING



Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>2. RETICLE DOES NOT ILLUMINATE (M137A2/ M137A3).</p>	<p>Observe visually in darkened area.</p>	<p>1. Replace batteries (item 8, WP 0152 00) in panoramic telescope.</p> <ul style="list-style-type: none"> a. Unscrew battery caps. b. Remove batteries using magnet in battery cap. c. Install new batteries in same direction as diagram on battery enclosure. d. Replace battery caps. <p>2. Replace battery enclosure assembly (4) (WP 0084 00).</p> <p>3. Replace light source adapter assembly (WP 0084 00).</p> <p>4. Notify general support maintenance.</p>
<p>3. RETICLE AND IMAGE HAVE PARALLAX.</p>	<p>Visually inspect.</p>	<p>Notify general support maintenance.</p>
<p>4. INTERNAL OPTICS ARE FOGGED OR HAVE CONDENSATION.</p>	<ul style="list-style-type: none"> 1. Inspect seal between head assembly and body assembly. 2. Inspect seal between body assembly and elbow assembly. 	<p>Notify general support maintenance.</p> <p>Notify general support maintenance.</p>

END OF WORK PACKAGE

CHAPTER 9

**GENERAL SUPPORT
TROUBLESHOOTING PROCEDURES
FOR
M137/M137A2/M137A3 PANORAMIC TELESCOPE**

GENERAL SUPPORT**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)****TROUBLESHOOTING INDEX**

INTRODUCTION

a. The troubleshooting procedures are limited to those listed in the troubleshooting symptom index. The table lists the common malfunctions, which you may find during the operation or maintenance of the M137/M137A2/M137A3 Panoramic Telescope. You should perform the tests/inspections and corrective actions in the order listed.

b. This manual cannot list all malfunctions that may occur, or all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

c. Each work package is headed by an initial setup. This setup outlines what is needed as well as certain conditions, which must be met before starting the task. **DON'T START A TASK UNTIL:**

You understand the task;

You understand what you are to do;

You understand what is needed to do the work;

You have the things you need.

MALFUNCTION/SYMPTOM INDEX

a. The malfunction/symptom index is a quick reference index for finding troubleshooting procedures. Associated with each symptom name is a work package sequence number representing the starting point in the troubleshooting sequence. Should any one symptom require more than one troubleshooting sequence to arrive at the most likely area of investigation, the additional starting point numbers are presented.

b. As the troubleshooting activity progresses to the conclusion of a particular sequence, a reference is made to the next logical troubleshooting sequence by work package sequence number or by referring to the malfunction/symptom index to locate the next failure symptom work package. This type of activity continues until successful fault isolation is achieved.

MALFUNCTION/SYMPTOM INDEX - Continued

<u>Malfunction/Symptom</u>	<u>Work Package</u>
BODY ASSEMBLY	
1. Azimuth mechanism body assembly is loose or binding.....	WP 0038 00
2. Reticle and image have parallax.....	WP 0038 00
COUNTER BOX ASSEMBLY	
1. Counters have excessive backlash	WP 0039 00
2. Correction knob binds	WP 0039 00
3. Counter numbers are not in horizontal alignment.....	WP 0039 00
4. Counter windows are fogged or have condensation.....	WP 0039 00
OPTICAL ELEMENTS	
1. Internal optics are fogged or have condensation.....	WP 0040 00

END OF WORK PACKAGE

GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**TROUBLESHOOTING PROCEDURES
BODY ASSEMBLY**

INITIAL SETUP:

References

WP 0095 00

BODY ASSEMBLY

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
1. RETICLE AND IMAGE HAVE PARALLAX. 2. AZIMUTH MECHANISM BODY ASSEMBLY IS LOOSE OR BINDING.	Observe visually. Check azimuth mechanism for worn, bent, broken, or damaged parts.	Turn in instrument. Replace defective parts (WP 0095 00).

END OF WORK PACKAGE

GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**TROUBLESHOOTING PROCEDURES
COUNTER BOX ASSEMBLY**

INITIAL SETUP:


References

WP 0098 00

WP 0099 00

COUNTER BOX ASSEMBLY

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. CORRECTION KNOB (1) BINDS.</p> <p>2. COUNTER NUMBERS (2) ARE NOT IN HORIZONTAL ALIGNMENT.</p> <p>3. COUNTERS (3) HAVE EXCESSIVE BACKLASH.</p> <p>4. COUNTER WINDOWS ARE FOGGED OR HAVE CONDENSATION.</p>	 <p>1fc047</p> <p>Check correction knob assembly for correct operation.</p> <p>Check counters for correct operation.</p> <p>1. Check for loose counter mechanism mounting screws.</p> <p>2. Check for worn or damaged counters.</p> <p>Check for defective seals.</p>	<p>Replace correction knob assembly (WP 0098 00).</p> <p>Replace counters (WP 0099 00).</p> <p>Tighten mounting screws (WP 0099 00).</p> <p>Replace counters (WP 0099 00).</p> <p>Replace defective seals (WP 0098 00).</p>

END OF WORK PACKAGE

GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**TROUBLESHOOTING PROCEDURES
OPTICAL ELEMENTS**

INITIAL SETUP:

References

- WP 0092 00
- WP 0093 00

OPTICAL ELEMENTS

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. INTERNAL OPTICS ARE FOGGED OR HAVE CONDENSATION.</p>	<p>1. Inspect seal between head assembly and body assembly.</p> <p>2. Inspect seal between body assembly and elbow assembly.</p> <p>3. Inspect seal in head assembly between cover assembly and window.</p>	<p>1. Replace defective seal (WP 0092 00).</p> <p>2. Replace defective seal (WP 0092 00).</p> <p>3. Replace defective seal (WP 0093 00).</p>

END OF WORK PACKAGE

CHAPTER 10

**DIRECT SUPPORT
TROUBLESHOOTING PROCEDURES
FOR
M138/M138A1 ELBOW TELESCOPE**

DIRECT SUPPORT**M138/M138A1 ELBOW TELESCOPE
(1240-01-038-0530/1240-01-515-8264)****TROUBLESHOOTING INDEX**

INTRODUCTION

a. The troubleshooting procedures are limited to those listed in the troubleshooting symptom index. The table lists the common malfunctions, which you may find during the operation or maintenance of the M138/M138A1 Elbow Telescope. You should perform the tests/inspections and corrective actions in the order listed.

b. This manual cannot list all malfunctions that may occur, or all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

c. Each work package is headed by an initial setup. This setup outlines what is needed as well as certain conditions, which must be met before starting the task. **DON'T START A TASK UNTIL:**

You understand the task;

You understand what you are to do;

You understand what is needed to do the work;

You have the things you need.

MALFUNCTION/SYMPTOM INDEX

a. The malfunction/symptom index is a quick reference index for finding troubleshooting procedures. Associated with each symptom name is a work package sequence number representing the starting point in the troubleshooting sequence. Should any one symptom require more than one troubleshooting sequence to arrive at the most likely area of investigation, the additional starting point numbers are presented.

b. As the troubleshooting activity progresses to the conclusion of a particular sequence, a reference is made to the next logical troubleshooting sequence by work package sequence number or by referring to the malfunction/symptom index to locate the next failure symptom work package. This type of activity continues until successful fault isolation is achieved.

MALFUNCTION/SYMPTOM INDEX - Continued

<u>Malfunction/Symptom</u>	<u>Work Package</u>
M138 TELESCOPE	
1. Reticle has uneven or no illumination	WP 0042 00
2. Reticle is fogged or has condensation	WP 0042 00
M138A1 TELESCOPE	
1. Reticle has no illumination.....	WP 0043 00
2. Reticle is fogged or has condensation	WP 0043 00
OPTICAL INSTRUMENT LATCH SET	
1. Optical instrument latch set does not operate correctly	WP 0044 00

END OF WORK PACKAGE

DIRECT SUPPORT

M138 ELBOW TELESCOPE
(1240-01-038-0530)

TROUBLESHOOTING PROCEDURES
M138 TELESCOPE

INITIAL SETUP:

Materials/Parts

- Plastic bag (item 5, WP 0152 00)
- Tape (item 20, WP 0152 00)

References

- TM 750-116

M138 TELESCOPE

WARNING

RADIATION




TRITIUM
GAS (H₃)

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. RETICLE (1) HAS UNEVEN OR NO ILLUMINATION.</p>	<p>Observe visually in darkened area.</p>	<p>1. Contact RSO immediately. 2. Perform wipe test under RSO supervision.</p>



M138 TELESCOPE - Continued

Table 1. Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. RETICLE (1) HAS UNEVEN OR NO ILLUMINATION - Continued.</p> <p>2. RETICLE (1) IS FOGGED OR HAS CONDENSATION.</p>	<p>Check for moisture in telescope.</p>	<p>3. Remove, bag, and secure device under RSO direction and await wipe test results.</p> <p>4. If contaminated, dispose of device per RSO instructions.</p> <p>5. If device is not contaminated, evacuate to depot maintenance.</p> <p>Purge and charge with dry nitrogen. Refer to TM 750-116.</p>

END OF WORK PACKAGE

DIRECT SUPPORT

M138A1 ELBOW TELESCOPE
(1240-01-515-8264)

TROUBLESHOOTING PROCEDURES
M138A1 TELESCOPE

INITIAL SETUP:

Materials/Parts

Battery (item 8, WP 0152 00)

References

TM 750-116

WP 0103 00

M138A1 TELESCOPE


WARNING



Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries.

Table 1. Troubleshooting Procedures.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. RETICLE (1) HAS NO ILLUMINATION.</p>	<p>Check for illumination in reticle.</p>	<p>1. Check for proper battery installation (same as diagram on battery enclosure).</p>



M138A1 TELESCOPE - Continued

Table 1. Troubleshooting Procedures - Continued.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. RETICLE (1) HAS NO ILLUMINATION- Continued.</p>		<p>2. Replace battery (item 8, WP 0152 00).</p> <ul style="list-style-type: none"> a. Unscrew battery cap. b. Remove battery using magnet in battery cap. c. Install new battery in same direction as diagram on battery enclosure. d. Replace battery cap. <p>3. Replace battery enclosure assembly (2) (WP 0103 00).</p> <p>4. Notify next higher level of maintenance.</p>
<p>2. RETICLE (1) IS FOGGED OR HAS CONDENSATION.</p>	<p>Check for moisture in telescope.</p>	<p>Purge and charge with dry nitrogen. Refer to TM 750-116.</p>

END OF WORK PACKAGE

DIRECT SUPPORT

**M138/M138A1 ELBOW TELESCOPE
(1240-01-038-0530/1240-01-515-8264)**

**TROUBLESHOOTING PROCEDURES
OPTICAL INSTRUMENT LATCH SET**

INITIAL SETUP:

References


WP 0104 00

OPTICAL INSTRUMENT LATCH SET

Table 1. Troubleshooting Procedures.

NOTE

The following steps apply to both the M138 and M138A1 elbow telescopes.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
<p>1. OPTICAL INSTRUMENT LATCH SET (1) DOES NOT OPERATE CORRECTLY.</p>	 <p>1. Check for incorrectly assembled optical instrument latch set.</p> <p>2. Check for worn, damaged, or missing parts.</p>	<p>Reassemble optical instrument latch set correctly (WP 0104 00).</p> <p>Replace parts (WP 0104 00) as required and authorized.</p>

END OF WORK PACKAGE

CHAPTER 11

DIRECT SUPPORT MAINTENANCE INSTRUCTIONS
FOR
M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT

DIRECT SUPPORT

**M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-037-7289 AND 1290-01-515-8260/1290-01-515-8262)**

**SERVICE UPON RECEIPT
SERVICE UPON RECEIPT OF MATERIEL**


SERVICE UPON RECEIPT OF MATERIEL

Unpacking

When a new or reconditioned M17/M18 or M17A1/M18A1 Fire Control Quadrant is received, be aware of any shipping damage to packaging materiel. Report any damage on SF 364, Report of Discrepancy (ROD), as prescribed in AR 735-11-2. Retain packaging materiel for future use.


Checking Unpacked Equipment

1. Inspect the equipment for damage incurred during shipment. If the equipment has been damaged, report the damage on SF 361, Transportation Discrepancy Report.
2. Check the equipment against the packing slip to see if the shipment is complete. Report all discrepancies in accordance with applicable service instructions (e.g., for Army instructions, see DA PAM 738-750).
3. Check to see whether the equipment has been modified.



1fc051

M17 Quadrant




1fc052


M18 Quadrant

4. Check M17/M18 or M17A1/M18A1 quadrant (1) for dents, scuff marks, bare spots, missing parts, and missing lock wire. Inspect M17/M17A1 quadrant for cleanness. Check for missing or illegible instruction plates or identification plates.
5. Check counter windows (2) for moisture. Look for broken, cracked, or chipped glass.
6. Operate correction knob (3). Check that operation is smooth without binding or rough motion.

SERVICE UPON RECEIPT OF MATERIEL - Continued



M17A1 Quadrant



M18A1 Quadrant

1fc053

7. Operate elevation knob (4). Check that operation is smooth without binding or rough motion.

WARNING

RADIATION

TRITIUM
GAS (H₃)

When inspecting radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

8. Check radioactive (M17/M18) or LED (M17A1/M18A1) light sources.
- Check that light is present and even throughout the elevation level vial (5). Check that elevation level vial graduations are present and legible.
 - Check that light is present and even throughout the correction counter (6). Check that correction counter numbers are clear and legible.
 - Check that light is present and even throughout the elevation counter (7). Check that elevation counter numbers are clear and legible.
 - Check that light is present and even throughout the cross level vial (8). Check that cross level vial graduations are present and legible (M18/M18A1 only).

NOTE

Switch has an approximate three-second delay. Press red push-button switch; then wait approximately three seconds and check if LED light sources are ON/OFF. Repeat until assured of correct operation.

9. For M17A1/M18A1 only, check operation of red push-button ON/OFF switch (9) on battery enclosure assembly (10).

END OF WORK PACKAGE

DIRECT SUPPORT

M17/M18 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-037-7289)

M17/M18 FIRE CONTROL QUADRANT MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY

INITIAL SETUP:

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

- Lockwasher (6) (item 4, WP 0111 00)
- Lockwasher (2) (item 9, WP 0111 00) (M18)
- Lockwasher (6) (item 13, WP 0111 00)
- Lock wire (item 21, WP 0152 00)
- Sealing compound (item 13, WP 0152 00)
- Solvent cleaning compound (item 12, WP 0152 00)
- Wiping rag (item 18, WP 0152 00)

References

- TM 750-116
- WP 0048 00
- WP 0111 00
- WP 0114 00

DISASSEMBLY


WARNING

RADIATION




TRITIUM
GAS (H₃)

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.




M17 Quadrant




M18 Quadrant

DISASSEMBLY - Continued

1. If damaged, remove four machine screws (1), four lockwashers (2), and two instruction plates (3 and 4) from side of quadrant (5). Discard lockwashers.
2. If damaged, remove two machine screws (6), two lockwashers (7), and identification plate (8) from quadrant (5). Discard lockwashers.
3. If damaged or illegible, remove instruction plate (9) from quadrant (5).





1fc057



1fc058


M17 Quadrant




1fc059

M18 Quadrant

4. Remove two machine screws (10), two lockwashers (11), and reflector (12). Discard lockwashers.
5. Remove two machine screws (13), two lockwashers (14), and reflector (15) (M18 only). Discard lockwashers.
6. Remove lock wire (16), four machine screws (17), and four lockwashers (18). Discard lock wire and lockwashers.



M17 Quadrant




M18 Quadrant

7. Loosen, but do not remove, setscrew (19) and cushioning pad (20) from fire control level assembly (21).
8. Remove machine screw (22) from adjusting plate (23).


NOTE

The following steps are written and illustrated for the M17 quadrant but also apply to the M18 quadrant.



M17/M18 Quadrant

9. Remove adjusting plate (23).
10. If damaged, remove setscrew (19) and cushioning pad (20).
11. Loosen setscrew (24) and cushioning pad (25) from adjusting plate (23). If damaged, remove.
12. Loosen setscrew (26) from adjusting plate (23). If damaged, remove.

DISASSEMBLY - Continued

1fc063

M17/M18 Quadrant

13. Unscrew air valve cap (27) from purging valve stem (28) and remove from valve cap strap (29).
14. Remove purging valve stem (28).
15. Remove valve cap strap (29) and valve core (30) from purging valve stem (28).
16. Remove safety relief valve (31).

CLEANING**WARNING**

Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.


Clean all parts with cleaning compound (item 12, WP 0152 00). Wipe off excess cleaning compound with a clean wiping rag (item 18, WP 0152 00).

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0111 00 and WP 0114 00.

ASSEMBLY**NOTE**

The following steps are written and illustrated for the M17 quadrant but also apply to the M18 quadrant.



1fc064

M17/M18 Quadrant


1. Install valve core (1) in purging valve stem (2).
2. Place valve cap strap (3) on purging valve stem (2) and air valve cap (4).

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.


3. Apply sealing compound (item 13, WP 0152 00) to purging valve stem (2) and install.
4. Install air valve cap (4) on purging valve stem (2).
5. Apply sealing compound (item 13, WP 0152 00) to safety relief valve (5) and install.

ASSEMBLY - Continued




M17/M18 Quadrant

6. If removed, install new setscrew (6). Do not tighten setscrew.
7. If removed, install new cushioning pad (7) and new setscrew (8) in adjusting plate (9). Do not tighten setscrew.




1fc066

M17 Quadrant




1fc067




1fc068

M18 Quadrant

8. If removed, install new cushioning pad (10) and new setscrew (11) to fire control level assembly (12). Do not tighten setscrew.
9. Install adjusting plate (9) on fire control level assembly (12).
10. Install four new lockwashers (13) (item 4, WP 0111 00) and four machine screws (14). Tighten machine screws and fill heads with sealing compound (item 13, WP 0152 00).
11. Start screw (15) into adjusting plate (9) but do not tighten. Screw will be tightened and locked with setscrew (11) during adjustment (WP 0048 00).
12. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (16).
13. Install reflector (17) with two new lockwashers (18) (item 4, WP 0111 00) and two machine screws (16). Tighten machine screws.
14. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (19).
15. Install reflector (20) with two new lockwashers (21) (item 9, WP 0111 00) and two machine screws (19). Tighten machine screws (M18 only).



M17 Quadrant



M18 Quadrant

16. If removed, apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (22).
17. If removed, install identification plate (23), two new lockwashers (24) (item 13, WP 0111 00), and two machine screws (22) on quadrant (25).
18. If removed, install new instruction plate (26) on quadrant (25).
19. If removed, apply sealing compound (item 13, WP 0152 00) to threads of four machine screws (27).
20. If removed, install two new instruction plates (28 and 29) on side of quadrant (25) using four new lockwashers (30) (item 13, WP 0111 00) and four machine screws (27).
21. Perform fire control level assembly adjustment maintenance (WP 0048 00).
22. Purge and charge M17/M18 fire control quadrant (TM 750-116).

END OF WORK PACKAGE

DIRECT SUPPORT**M17A1/M18A1 FIRE CONTROL QUADRANT
(1290-01-515-8260/1290-01-515-8262)****M17A1/M18A1 FIRE CONTROL QUADRANT MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Gasket (item 26, WP 0111 00)
Lockwasher (6) (item 4, WP 0111 00)
Lockwasher (2) (item 9, WP 0111 00) (M18A1)
Lockwasher (2) (item 13, WP 0111 00)
Lockwasher (item 20, WP 0111 00)
Lockwasher (4) (item 24, WP 0111 00)
Lock wire (item 21, WP 0152 00)
Sealing compound (item 13, WP 0152 00)
Solvent cleaning compound (item 12, WP 0152 00)
Wiping rag (item 18, WP 0152 00)


References

TM 750-116
WP 0048 00
WP 0111 00


DISASSEMBLY**WARNING**

Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries.

DISASSEMBLY - Continued



M17A1 Quadrant



M18A1 Quadrant

1. Remove machine screw (1), lockwasher (2), cap and retainer assembly (3), and two batteries (4) from battery enclosure assembly (5). Discard lockwasher.
2. Remove four machine screws (6) and four lockwashers (7). Discard lockwashers.

CAUTION


Use extreme care when removing battery enclosure assembly. A short wire harness and connector on battery enclosure assembly are connected to a connector on a short wire harness that passes through adapter plate on quadrant assembly. These connectors and wire harnesses are easily damaged.

3. Carefully disconnect connector (8) from connector (9) and remove battery enclosure assembly (5).

CAUTION


Do not attempt to remove adapter plate between battery enclosure assembly and cover assembly. The wire harness passing through adapter plate cannot be removed without damaging the equipment. The adapter plate can only be removed or installed by the manufacturer.

4. Remove gasket (10) from adapter plate (11) on quadrant (12). Discard gasket.



1fc073


M17A1 Quadrant



1fc074


M18A1 Quadrant

5. If damaged, remove two machine screws (13), two lockwashers (14), and identification plate (15) from quadrant (12). Discard lockwashers.





1fc075

M17A1 Quadrant



1fc076




1fc077


M18A1 Quadrant

6. Remove two machine screws (16), two lockwashers (17), and reflector (18). Discard lockwashers.
7. Remove two machine screws (19), two lockwashers (20), and reflector (21) (M18A1 only). Discard lockwashers.
8. Remove lock wire (22), four machine screws (23), and four lockwashers (24). Discard lock wire and lockwashers.

DISASSEMBLY - Continued



M17A1 Quadrant




M18A1 Quadrant

9. Loosen, but do not remove, setscrew (25) and cushioning pad (26) from fire control level assembly (27).
10. Remove machine screw (28) from adjusting plate (29).


NOTE

The following steps are written and illustrated for the M17A1 quadrant but also apply to the M18A1 quadrant.



M17A1/M18A1 Quadrant

11. Remove adjusting plate (29).
12. If damaged, remove setscrew (25) and cushioning pad (26).
13. Loosen setscrew (30) and cushioning pad (31) from adjusting plate (29). If damaged, remove.
14. Loosen setscrew (32) from adjusting plate (29). If damaged, remove.



1fc081

M17A1/M18A1 Quadrant

15. Unscrew air valve cap (33) from purging valve stem (34) and remove from valve cap strap (35).
16. Remove purging valve stem (34).
17. Remove valve cap strap (35) and valve core (36) from purging valve stem (34).
18. Remove safety relief valve (37).

CLEANING

WARNING



Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.

Clean all parts with cleaning compound (item 12, WP 0152 00). Wipe off excess cleaning compound with a clean wiping rag (item 18, WP 0152 00).


REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0111 00.

ASSEMBLY

NOTE

The following steps are written and illustrated for the M17A1 quadrant but also apply to the M18A1 quadrant.



1fc082

M17A1/M18A1 Quadrant


1. Install valve core (1) in purging valve stem (2).
2. Place valve cap strap (3) on purging valve stem (2) and air valve cap (4).

WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.


3. Apply sealing compound (item 13, WP 0152 00) to purging valve stem (2) and install.
4. Install air valve cap (4) on purging valve stem (2).
5. Apply sealing compound (item 13, WP 0152 00) to safety relief valve (5) and install.



1fc083


M17A1/M18A1 Quadrant

6. If removed, install new setscrew (6). Do not tighten setscrew.
7. If removed, install new cushioning pad (7) and new setscrew (8) in adjusting plate (9). Do not tighten setscrew.





1fc084

M17A1 Quadrant



1fc085





1fc086



M18A1 Quadrant

ASSEMBLY - Continued

8. If removed, install new cushioning pad (10) and new setscrew (11) to fire control level assembly (12). Do not tighten setscrew.
9. Install adjusting plate (9) on fire control level assembly (12).
10. Install four new lockwashers (13) (item 4, WP 0111 00) and four machine screws (14). Tighten machine screws and fill heads with sealing compound (item 13, WP 0152 00).
11. Start screw (15) into adjusting plate (9) but do not tighten. Screw will be tightened and locked with setscrew (11) during adjustment.
12. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (16).
13. Install reflector (17) with two new lockwashers (18) (item 4, WP 0111 00) and two machine screws (16). Tighten machine screws.
14. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (19).
15. Install reflector (20) with two new lockwashers (21) (item 9, WP 0111 00) and two machine screws (19). Tighten machine screws (M18A1 only).



16. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (22).
17. Install identification plate (23), two new lockwashers (24) (item 13, WP 0111 00), and two machine screws (22) on side of quadrant (25).



18. Install new gasket (26) (item 26, WP 0111 00) onto adapter plate (27) on quadrant (25).
19. Carefully connect connector (28) on adapter plate (27) to connector (29) on battery enclosure assembly (30).

CAUTION

Be careful when assembling components. Do not pinch wire leads or connectors between parts.

20. Apply sealing compound (item 13, WP 0152 00) to threads of four machine screws (31).
21. Install four new lockwashers (32) and four machine screws (31) to secure battery enclosure assembly (30) and gasket (26) to adapter plate (27) on quadrant (25).

WARNING



Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries.

CAUTION

Do not install batteries backwards. Severe equipment damage may result. Pay careful attention to diagram on battery enclosure.

22. Install two batteries (33) into battery enclosure assembly (30).
23. Install cap and retainer assembly (34) and secure on battery enclosure assembly (30) with new lockwasher (35) (item 20, WP 0111 00) and machine screw (36).

ASSEMBLY - Continued

24. Perform fire control level assembly adjustment maintenance (WP 0048 00).
25. Purge and charge M17A1/M18A1 fire control quadrant (TM 750-116).

END OF WORK PACKAGE

DIRECT SUPPORT

**M17/M17A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260)**

**FIRE CONTROL LEVEL ASSEMBLY MAINTENANCE
DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY, ADJUSTMENT**

INITIAL SETUP:

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Lock wire (item 21, WP 0152 00)

Sealing compound (item 13, WP 0152 00)

References

WP 0113 00

Equipment Conditions


M17/M17A1 fire control quadrant mounted on M198 howitzer with cannon at zero elevation
(TM 9-1025-211-10)

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

NOTE

The following steps are written and illustrated for the M17 quadrant but also apply to the M17A1 quadrant.

**M17/M17A1 Quadrant**

Remove sealing compound and remove externally threaded ring (1) and eccentric (2) from vial holder (3).

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0113 00.

ASSEMBLY**WARNING**


Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

Apply sealing compound (item 13, WP 0152 00) to eccentric (2) and externally threaded ring (1) and install into vial holder (3). Proceed to Adjustment.

ADJUSTMENT

NOTE


Correction and elevation counters must be set at zero.



1fc092

M17/M17A1 Quadrant

1. Remove and discard lock wire (1).
2. Loosen two setscrews (2 and 3).



1fc093


M17/M17A1 Quadrant

3. Turn setscrew (4) and machine screw (5) until bubble in elevation level (6) levels.
4. Tighten setscrews (2 and 3). Fill heads of setscrews (2, 3, and 4) with sealing compound (item 13, WP 0152 00) after final adjustment.

ADJUSTMENT - Continued**NOTE**

If bubble in elevation level cannot be adjusted within one graduation, more adjustment is required. Perform steps 6 through 11. Otherwise, perform step 5.

5. Install new lock wire (7) (item 21, WP 0152 00).

**M17 Quadrant**

6. Remove externally threaded ring (8) and eccentric (9).
7. Place a dab of sealing compound (item 13, WP 0152 00) on slotted end of eccentric (9) and to threads of externally threaded ring (8).
8. Reinstall eccentric (9) and externally threaded ring (8) and turn eccentric until bubble in elevation level (6) centers.
9. Tighten externally threaded ring (8).
10. Apply sealing compound (item 13, WP 0152 00) to outside of externally threaded ring (8).
11. Install new lock wire (item 21, WP 0152 00).

END OF WORK PACKAGE

CHAPTER 12

**GENERAL SUPPORT
MAINTENANCE INSTRUCTIONS
FOR
M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT**

GENERAL SUPPORT**M17/M18 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-037-7289)****M17/M18 FIRE CONTROL QUADRANT MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Grease (item 15, WP 0152 00)
Grease (item 16, WP 0152 00)
Lockwasher (4) (item 4, WP 0111 00)
Lockwasher (9) (item 18, WP 0111 00)
Lockwasher (3) (item 19, WP 0112 00)
Lock wire (item 21, WP 0152 00)
O-ring (item 17, WP 0111 00)
O-ring (item 36, WP 0111 00)
O-ring (item 14, WP 0112 00)
O-ring (item 17, WP 0112 00)
O-ring (item 22, WP 0112 00)
Sealing compound (item 13, WP 0152 00)
Solvent cleaning compound (item 12, WP 0152 00)
Spring tension washer (item 12, WP 0112 00)
Wiping rag (item 18, WP 0152 00)

References

WP 0048 00
WP 0056 00
WP 0111 00
WP 0112 00

Equipment Conditions

M17/M18 fire control quadrant removed from howitzer (TM 9-1025-211-20&P/TM 9-1025-215-25&P)

DISASSEMBLY

WARNING

RADIATION




**TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.


NOTE

The following steps are written and illustrated for the M17 quadrant but also apply to the M18 quadrant.



M17/M18 Quadrant

1. Set counters (1) at zero. Scribe a line on base assembly (2) and housing assembly (3) to facilitate correct counter installation.




M17/M18 Quadrant

WARNING

To avoid injury to personnel and damage to equipment, cover assembly will only be removed if counters are fully illuminated. Place cover assembly in secure area and exercise caution to avoid breakage of nuclear lamps.


- Remove seven machine screws (4) and seven lockwashers (5) from cover assembly (6). Discard lockwashers.



1fc097

M17/M18 Quadrant


- Remove cover assembly (6) and O-ring (7) from housing assembly (3). Discard O-ring.




1fc098

M17/M18 Quadrant

- Remove and discard lock wire (8).
- Remove four machine screws (9) and four lockwashers (10). Discard lockwashers.
- Loosen setscrew (11) and cushioning pad (12).
- Remove machine screw (13).


DISASSEMBLY - Continued**M17/M18 Quadrant**

8. Remove adjusting plate (14).
9. Loosen setscrew (15) and cushioning pad (16).
10. Loosen setscrew (17).


**M17/M18 Quadrant****NOTE**

Replacement of fire control level assembly parts can be done without removing fire control level assembly from M17/M18 quadrant.

11. Drive out headless straight pin (18).
12. Lift off fire control level assembly (19) and remove sealing compound.

**M17/M18 Quadrant**


13. Remove two machine screws (20) and two lockwashers (21) from correction knob assembly (22). Discard lockwashers.

**M17/M18 Quadrant****CAUTION**

Correction knob assembly must be removed carefully, or internal M17/M18 quadrant parts could be damaged.


14. Remove correction knob assembly (22) and O-ring (23). Discard O-ring.

DISASSEMBLY - Continued




M17/M18 Quadrant

- Remove three machine screws (24), three lockwashers (25), and counter assembly (26) from housing assembly (3). Discard lockwashers.



M17/M18 Quadrant

- Straighten locking ear (27) on key washer (28).




M17/M18 Quadrant

17. Unscrew and remove spring plug retainer (29) from housing assembly (3).
18. Remove O-ring (30) and key washer (28) from spring plug retainer (29). Discard O-ring.
19. Remove compression helical spring (31) and V-type bearing (32) from housing assembly (3).


CAUTION

Support elevation knob in V block on solid surface to prevent damage to worm shaft assembly.



M17/M18 Quadrant


20. Remove headless straight pin (33) and elevation knob assembly (34) from worm shaft assembly (35).



M17/M18 Quadrant


21. Remove spring tension washer (36), packing retainer (37), and O-ring (38) from worm shaft assembly (35). Discard O-ring and spring tension washer.

DISASSEMBLY - Continued



M17/M18 Quadrant


22. Straighten locking ear (39) on key washer (40).



M17/M18 Quadrant

23. Remove elevation retainer (41) with O-ring (42) and key washer (40) from worm shaft assembly (35).

24. Remove O-ring (42) and key washer (40) from elevation retainer (41). Discard O-ring.



M17/M18 Quadrant

NOTE

Note position of flat (43) on worm shaft assembly (35) in relationship to housing assembly (3).

25. Rotate and remove worm shaft assembly (35) from housing assembly (3).

NOTE

For maintenance of the fire control level (cross level vial) on the M18 quadrant, refer to WP 0056 00.

CLEANING**WARNING**

Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.


Clean all parts with cleaning compound (item 12, WP 0152 00). Wipe off excess cleaning compound with a clean wiping rag (item 18, WP 0152 00).

REPAIR OR REPLACEMENT

1. Inspect gears for missing teeth and stripped gears.
2. Inspect bearing surfaces for nicks and burrs.
3. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0111 00 and WP 0112 00.

ASSEMBLY**NOTE**

The following steps are written and illustrated for the M17 quadrant but also apply to the M18 quadrant.




M17/M18 Quadrant

1. Apply a light coat of grease (item 15, WP 0152 00) to worm shaft assembly (1).


ASSEMBLY - Continued**NOTE**

Ensure flat on worm shaft assembly is in proper position for counter assembly clearance (as noted during disassembly).


2. Install worm shaft assembly (1) in housing assembly (2) by turning shaft.

**M17/M18 Quadrant**

3. Install key washer (3) on elevation retainer (4).
4. Apply a light coat of grease (item 16, WP 0152 00) to new O-ring (5) (item 17, WP 0112 00) and install on elevation retainer (4).
5. Screw elevation retainer (4) in housing assembly (2) until tight.


**M17/M18 Quadrant**

6. Bend locking ear (6) to secure key washer (3) to housing assembly (2).




M17/M18 Quadrant

7. Apply a light coat of grease (item 15, WP 0152 00) to V-type bearing (7), and install in housing assembly (2).
8. Install compression helical spring (8) in housing assembly (2).
9. Place key washer (9) on spring plug retainer (10).
10. Apply a light coat of grease (item 16, WP 0152 00) on new O-ring (11) (item 22, WP 0112 00), and install on spring plug retainer (10).




M17/M18 Quadrant

11. Screw spring plug retainer (10) into housing assembly (2) until tight.
12. Bend locking ear (12) on key washer (9) to secure spring plug retainer (10) to housing assembly (2).

ASSEMBLY - Continued**M17/M18 Quadrant**

13. Apply a light coat of grease (item 16, WP 0152 00) to new O-ring (13) (item 14, WP 0112 00). Install O-ring, packing retainer (14), and new spring tension washer (15) over worm shaft assembly (1).

**M17/M18 Quadrant****NOTE**


Perform steps 14 and 15, and continue with step 17, if new worm shaft assembly has been installed. Perform step 16 if previously-installed components are used.

14. Install elevation knob assembly (16) on worm shaft assembly (1) and secure with setscrew, NSN 5305-00-282-8902. Using the pilot hole located on the knob, drill hole through worm shaft assembly.
15. Remove setscrew from elevation knob assembly (16).
16. Install elevation knob assembly (16) on worm shaft assembly (1).

CAUTION

Support elevation assembly knob in V block on solid surface to prevent damage to worm shaft assembly.

17. Install headless straight pin (17) in elevation knob assembly (16) and worm shaft assembly (1).



M17/M18 Quadrant

WARNING




Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

NOTE

Ensure counters are set to zero and scribe lines on M17/M18 quadrant housing assembly are aligned.


- 18. Apply sealing compound (item 13, WP 0152 00) to threads of three machine screws (18).
- 19. Position counter assembly (19) in housing assembly (2) and secure with three new lockwashers (20) (item 19, WP 0112 00) and three machine screws (18).



M17/M18 Quadrant

- 20. Check to ensure counters (21) are zeroed, with scribe lines on base assembly (22) and housing assembly (2) aligned.


ASSEMBLY - Continued



1fc120

M17/M18 Quadrant


21. Place new O-ring (23) (item 36, WP 0111 00) on correction knob assembly (24). Apply grease (item 16, WP 0152 00).



1fc121


M17/M18 Quadrant

22. Ensure rotation of knob (25) is smooth through 19-1/4 revolutions.
- Turn knob (25) clockwise until it stops.
 - Then turn counterclockwise 9-1/2 turns.
23. Install correction knob assembly (24) and align slot (26) with headless straight pin (27).
24. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (28).
25. Install two new lockwashers (29) (item 18, WP 0111 00) and two machine screws (28).



M17/M18 Quadrant


26. Turn knob (25) and ensure correction counter (30) indicates reading from +95 to +99 mils and -95 to -99 mils.
27. Return correction counter (30) to 00.



M17/M18 Quadrant


28. Place fire control level assembly (31) in bracket (32) and install headless straight pin (33).

ASSEMBLY - Continued



M17/M18 Quadrant

29. Apply sealing compound (item 13, WP 0152 00) to threads of four machine screws (34).
30. Place adjusting plate (35) on top of bracket (32) and install with four new lockwashers (36) (item 4, WP 0111 00) and four machine screws (34). Tighten machine screws. Install new lock wire (item 21, WP 0152 00).
31. Apply sealing compound (item 13, WP 0152 00) to threads of machine screw (37) and install, but do not tighten.



M17/M18 Quadrant

32. Apply light coat of grease (item 16, WP 0152 00) on new O-ring (38) (item 17, WP 0111 00). Place cover assembly (39) with new O-ring on housing assembly (2).
33. Apply sealing compound (item 13, WP 0152 00) to threads of seven machine screws (40).
34. Install cover assembly (39) and O-ring (38) on housing assembly (2) with seven new lockwashers (41) (item 18, WP 0111 00) and seven machine screws (40).
35. Perform adjustment of fire control level assembly. Refer to WP 0048 00.

END OF WORK PACKAGE

GENERAL SUPPORT**M17A1/M18A1 FIRE CONTROL QUADRANT
(1290-01-515-8260/1290-01-515-8262)****M17A1/M18A1 FIRE CONTROL QUADRANT MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Grease (item 15, WP 0152 00)
Grease (item 16, WP 0152 00)
Lockwasher (4) (item 4, WP 0111 00)
Lockwasher (9) (item 18, WP 0111 00)
Lockwasher (3) (item 19, WP 0112 00)
Lock wire (item 21, WP 0152 00)
O-ring (item 17, WP 0111 00)
O-ring (item 36, WP 0111 00)
O-ring (item 14, WP 0112 00)
O-ring (item 17, WP 0112 00)
O-ring (item 22, WP 0112 00)
Sealing compound (item 13, WP 0152 00)
Solvent cleaning compound (item 12, WP 0152 00)
Spring tension washer (item 12, WP 0112 00)
Wiping rag (item 18, WP 0152 00)

References


TM 750-116
WP 0047 00
WP 0048 00
WP 0111 00
WP 0112 00

Equipment Conditions

M17A1/M18A1 fire control quadrant removed from howitzer (TM 9-1025-211-20&P/TM 9-1025-215-25&P)
Battery enclosure and gasket removed from M17A1/M18A1 fire control quadrant (WP 0047 00)


DISASSEMBLY**NOTE**

The following steps are written and illustrated for the M17A1 quadrant but also apply to the M18A1 quadrant.



M17A1/M18A1 Quadrant

1. Set counters (1) at zero. Scribe a line on base assembly (2) and housing assembly (3) to facilitate correct counter installation.




M17A1/M18A1 Quadrant

CAUTION

Do not attempt to remove adapter plate (4) from cover assembly (5). A short wire harness passing through adapter plate cannot be removed without damaging equipment. Adapter plate can only be removed or installed by the manufacturer. Two access holes are provided in adapter plate to allow cover assembly removal.

2. Remove seven machine screws (6) and seven lockwashers (7) from cover assembly (5). Discard lockwashers.
3. Remove plug (8) from adapter plate (4).




M17A1/M18A1 Quadrant

CAUTION


Use extreme care when removing cover assembly. A connector on a short wire harness on cover is connected to a connector on a short wire harness on quadrant. These connectors and wire harnesses are easily damaged.

4. Carefully pull cover assembly (5) and O-ring (9) away from housing assembly (3) and disconnect connector (10) from connector (11). Remove cover assembly and O-ring. Discard O-ring.




M17A1/M18A1 Quadrant

5. Remove and discard lock wire (12).
6. Remove four machine screws (13) and four lockwashers (14). Discard lockwashers.
7. Loosen setscrew (15) and cushioning pad (16).
8. Remove machine screw (17).


DISASSEMBLY - Continued**M17A1/M18A1 Quadrant**

9. Remove adjusting plate (18).
10. Loosen setscrew (19) and cushioning pad (20).
11. Loosen setscrew (21).


**M17A1/M18A1 Quadrant****NOTE**

Replacement of fire control level assembly parts can be done without removing fire control level assembly from M17A1/M18A1 quadrant.

12. Drive out headless straight pin (22).
13. Lift off fire control level assembly (23) and remove sealing compound.

**M17A1/M18A1 Quadrant**


14. Remove two machine screws (24) and two lockwashers (25) from correction knob assembly (26). Discard lockwashers.

**M17A1/M18A1 Quadrant****CAUTION**

Correction knob assembly must be removed carefully, or internal M17A1/M18A1 quadrant parts could be damaged.


15. Remove correction knob assembly (26) and O-ring (27). Discard O-ring.

DISASSEMBLY - Continued




M17A1/M18A1 Quadrant

- Remove three machine screws (28), three lockwashers (29), and counter assembly (30) from housing assembly (3). Discard lockwashers.



M17A1/M18A1 Quadrant

- Straighten locking ear (31) on key washer (32).




M17A1/M18A1 Quadrant

18. Unscrew and remove spring plug retainer (33) from housing assembly (3).
19. Remove O-ring (34) and key washer (32) from spring plug retainer (33). Discard O-ring.
20. Remove compression helical spring (35) and V-type bearing (36) from housing assembly (3).


CAUTION

Support elevation knob in V block on solid surface to prevent damage to worm shaft assembly.



M17A1/M18A1 Quadrant


21. Remove headless straight pin (37) and elevation knob assembly (38) from worm shaft assembly (39).



M17A1/M18A1 Quadrant


22. Remove spring tension washer (40), packing retainer (41), and O-ring (42) from worm shaft assembly (39). Discard O-ring and spring tension washer.

DISASSEMBLY - Continued




M17A1/M18A1 Quadrant

23. Straighten locking ear (43) on key washer (44).



M17A1/M18A1 Quadrant

24. Remove elevation retainer (45) with O-ring (46) and key washer (44) from worm shaft assembly (39).
25. Remove O-ring (46) and key washer (44) from elevation retainer (45). Discard O-ring.



M17A1/M18A1 Quadrant

NOTE

Note position of flat (47) on worm shaft assembly (39) in relationship to housing assembly (3).

26. Rotate and remove worm shaft assembly (39) from housing assembly (3).

CLEANING**WARNING**

Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.


Clean all parts with cleaning compound (item 12, WP 0152 00). Wipe off excess cleaning compound with a clean wiping rag (item 18, WP 0152 00).

REPAIR OR REPLACEMENT

1. Inspect gears for missing teeth and stripped gears.
2. Inspect bearing surfaces for nicks and burrs.
3. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0111 00 and WP 0112 00.

ASSEMBLY**NOTE**

The following steps are written and illustrated for the M17A1 quadrant but also apply to the M18A1 quadrant.



M17A1/M18A1 Quadrant


1. Apply a light coat of grease (item 15, WP 0152 00) to worm shaft assembly (1).

ASSEMBLY - Continued

NOTE


Ensure flat on worm shaft assembly is in proper position for counter assembly clearance (as noted during disassembly).

2. Install worm shaft assembly (1) in housing assembly (2) by turning shaft.




M17A1/M18A1 Quadrant

3. Install key washer (3) on elevation retainer (4).
4. Apply a light coat of grease (item 16, WP 0152 00) to new O-ring (5) (item 17, WP 0112 00) and install on elevation retainer (4).
5. Screw elevation retainer (4) in housing assembly (2) until tight.




M17A1/M18A1 Quadrant

6. Bend locking ear (6) to secure key washer (3) to housing assembly (2).




M17A1/M18A1 Quadrant

7. Apply a light coat of grease (item 15, WP 0152 00) to V-type bearing (7), and install in housing assembly (2).
8. Install compression helical spring (8) in housing assembly (2).
9. Place key washer (9) on spring plug retainer (10).
10. Apply a light coat of grease (item 16, WP 0152 00) on new O-ring (11) (item 22, WP 0112 00), and install on spring plug retainer (10).




M17A1/M18A1 Quadrant

11. Screw spring plug retainer (10) into housing assembly (2) until tight.
12. Bend locking ear (12) on key washer (9) to secure spring plug retainer (10) to housing assembly (2).

ASSEMBLY - Continued**M17A1/M18A1 Quadrant**

13. Apply a light coat of grease (item 16, WP 0152 00) to new O-ring (13) (item 14, WP 0112 00). Install O-ring, packing retainer (14), and new spring tension washer (15) over worm shaft assembly (1).

**M17A1/M18A1 Quadrant****NOTE**


Perform steps 14 and 15, and continue with step 17, if new worm shaft assembly has been installed. Perform step 16 if previously-installed components are used.

14. Install elevation knob assembly (16) on worm shaft assembly (1) and secure with setscrew, NSN 5305-00-282-8902. Using the pilot hole located on the knob, drill hole through worm shaft assembly.
15. Remove setscrew from elevation knob assembly (16).
16. Install elevation knob assembly (16) on worm shaft assembly (1).

CAUTION

Support elevation assembly knob in V block on solid surface to prevent damage to worm shaft assembly.

17. Install headless straight pin (17) in elevation knob assembly (16) and worm shaft assembly (1).



M17A1/M18A1 Quadrant

WARNING




Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

NOTE

Ensure counters are set to zero and scribe lines on M17A1/M18A1 quadrant housing assembly are aligned.


- 18. Apply sealing compound (item 13, WP 0152 00) to threads of three machine screws (18).
- 19. Position counter assembly (19) in housing assembly (2) and secure with three new lockwashers (20) (item 19, WP 0112 00) and three machine screws (18).



M17A1/M18A1 Quadrant


- 20. Check to ensure counters (21) are zeroed, with scribe lines on base assembly (22) and housing assembly (2) aligned.

ASSEMBLY - Continued




M17A1/M18A1 Quadrant

21. Place new O-ring (23) (item 36, WP 0111 00) on correction knob assembly (24). Apply grease (item 16, WP 0152 00).




M17A1/M18A1 Quadrant

22. Ensure rotation of knob (25) is smooth through 19-1/4 revolutions.
- Turn knob (25) clockwise until it stops.
 - Then turn counterclockwise 9-1/2 turns.
23. Install correction knob assembly (24) and align slot (26) with headless straight pin (27).
24. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (28).
25. Install two new lockwashers (29) (item 18, WP 0111 00) and two machine screws (28).



M17A1/M18A1 Quadrant


26. Turn knob (25) and ensure correction counter (30) indicates reading from +95 to +99 mils and -95 to -99 mils.
27. Return correction counter (30) to 00.



M17A1/M18A1 Quadrant


28. Place fire control level assembly (31) in bracket (32) and install headless straight pin (33).

ASSEMBLY - Continued



M17A1/M18A1 Quadrant

29. Apply sealing compound (item 13, WP 0152 00) to threads of four machine screws (34).
30. Place adjusting plate (35) on top of bracket (32) and install with four new lockwashers (36) (item 4, WP 0111 00) and four machine screws (34). Tighten machine screws. Install new lock wire (item 21, WP 0152 00).
31. Apply sealing compound (item 13, WP 0152 00) to threads of machine screw (37) and install, but do not tighten.



M17A1/M18A1 Quadrant

32. Apply light coat of grease (item 16, WP 0152 00) on new O-ring (38) (item 17, WP 0111 00). Place O-ring on cover assembly (39).

33. Connect connector (40) on cover assembly (39) to connector (41) on housing assembly (2).
34. Apply sealing compound (item 13, WP 0152 00) to threads of seven machine screws (42).

CAUTION

Use extreme care during assembly. Do not pinch wires or connectors between parts.

35. Install cover assembly (39) and O-ring (38) on housing assembly (2) with seven new lockwashers (43) (item 18, WP 0111 00) and seven machine screws (42).
36. Install plug (44) to cover assembly (39).
37. Install battery enclosure and gasket. Refer to WP 0047 00.
38. Purge and charge with dry nitrogen. Refer to TM 750-116.
39. Perform adjustment of fire control level assembly. Refer to WP 0048 00.

END OF WORK PACKAGE

GENERAL SUPPORT**M17/M18 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-037-7289)****FIRE CONTROL LEVEL ASSEMBLY (ELEVATION LEVEL VIAL ASSEMBLY) MAINTENANCE
REMOVAL, DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY, INSTALLATION, ADJUSTMENT**

INITIAL SETUP:**Test Equipment**

Mounting bracket (item 2, WP 0149 00)
Optical equipment test fixture (item 8, WP 0149 00)
Plate-mounted level (item 12, WP 0149 00)

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Lockwasher (4) (item 4, WP 0111 00)
Lock wire (item 21, WP 0152 00)
Plastic bag (item 5, WP 0152 00)
Sealing compound (item 13, WP 0152 00)
Tape (item 20, WP 0152 00)

References


WP 0111 00
WP 0113 00

REMOVAL**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

NOTE


General support maintenance instructions for the M18 quadrant fire control level assembly are identical to the M17 quadrant fire control level assembly.

REMOVAL - Continued

1fc157

M17/M18 Quadrant


1. Remove and discard lock wire (1).
2. Loosen, but do not remove, setscrew (2) and cushioning pad (3).
3. Remove machine screw (4).
4. Remove four machine screws (5) and four lockwashers (6). Discard lockwashers.



1fc158

M17/M18 Quadrant

5. Remove adjusting plate (7).



1fc159


M17/M18 Quadrant

NOTE

Removal of fire control level assembly parts can be done without removing fire control level assembly from M17/M18 quadrant.

6. Drive out headless straight pin (8). Lift fire control level assembly (9) and remove sealing compound.

DISASSEMBLY




1fc160

M17/M18 Quadrant


1. Remove externally threaded ring (1) from vial holder (2).
2. Remove eccentric (3).
3. Slide fire control level (4) and remove from vial holder (2).
4. Lift level cover (5) from vial holder (2).
5. If damaged, remove headless straight pin (6).

REPAIR OR REPLACEMENT

1. Replace fire control level assembly if any threads are stripped or vial holder is damaged.
2. Fire control level may be replaced if it is cracked but still illuminated. Dispose of broken fire control level in accordance with RSO instructions. If fire control level is cracked and not illuminated, notify RSO. Perform wipe test under RSO supervision. Remove, bag, and secure assembly under RSO direction and await wipe test results. If contaminated, dispose of assembly per RSO instructions. If assembly is not contaminated, replace fire control level. Dispose of replaced fire control level per RSO instructions.
3. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0111 00 and WP 0113 00.

ASSEMBLY**M17/M18 Quadrant**

1. If removed, install new headless straight pin (1).
2. Place level cover (2) in vial holder (3).
3. Slide fire control level (4) into vial holder (3) and secure with eccentric (5) and externally threaded ring (6).


INSTALLATION

1fc162

M17/M18 Quadrant

1. Install fire control level assembly (1) in bracket (2) and secure with headless straight pin (3).

INSTALLATION - Continued




1fc163

2. Install adjusting plate (4) on top of bracket (2).

WARNING


Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

3. Apply sealing compound (item 13, WP 0152 00) to threads of four machine screws (5).
4. Install four new lockwashers (6) (item 4, WP 0111 00) and four machine screws (5). Tighten machine screws.
5. Apply sealing compound (item 13, WP 0152 00) to threads of machine screw (7). Install machine screw into adjusting plate (4) but do not tighten. Screw will be tightened and locked during adjustment.

ADJUSTMENT


1fc164

1. Secure optical equipment test fixture (1) on test bench.




1fc165

2. Place plate-mounted level (2) on block (3), perpendicular to axis of rotation.
3. Cross-level the optical equipment test fixture (1).

ADJUSTMENT - Continued

1fc166

4. Set cant vernier scale (4) and elevation vernier scale (5) to zero.




1fc167

NOTE

Ensure precision ground surfaces are free of nicks and burrs.

When installing mounting bracket (6), ensure precision ground surface (7) is parallel to top of block within 0.1 mil.

5. Install mounting bracket (6) on end of cross-leveling shaft (8).
6. Hand tighten six setscrews (9).




1fc168

7. Place plate-mounted level (2) on precision ground surface (7) of mounting bracket (6).
8. Check that bubble in plate-mounted level (2) is level.
9. Tighten setscrews (9). Recheck optical equipment test fixture (1), plate-mounted level (2), and precision ground surface (7).
10. Rotate plate-mounted level (2) 180 degrees from original position, and check again that bubble in plate-mounted level (2) is centered.

NOTE

Check to make sure that optical equipment test fixture is still level in elevation and cant.



1fc169

M17/M18 Quadrant


11. Install M17/M18 quadrant (10) on mounting bracket (6) of optical equipment test fixture (1).

ADJUSTMENT - Continued

NOTE

Correction and elevation counters must be set at zero when adjusting fire control level.

A combination of adjustment procedures in steps 12 through 17 is necessary to center bubble in fire control level.



1fc170


M17/M18 Quadrant

12. Turn setscrew (11) and machine screw (12) until bubble (13) centers.

NOTE

If elevation level bubble can be adjusted within one graduation, perform steps 13, 18, and 19 only. Otherwise, perform steps 13 through 19.

If eccentric adjustment is required on M18 quadrant, the level assembly (cross level) must be removed.



1fc171

M17/M18 Quadrant

13. Tighten setscrews (14 and 15).
14. Remove externally threaded ring (16) and eccentric (17).
15. Place a dab of sealing compound (item 13, WP 0152 00) on slotted end of eccentric (17) and to threads of externally threaded ring (16).
16. Reinstall eccentric (17) and externally threaded ring (16) and turn eccentric until bubble (13) centers.
17. Tighten externally threaded ring (16).
18. Apply sealing compound (item 13, WP 0152 00) to outside of externally threaded ring (16).
19. Install new lock wire (18) (item 21, WP 0152 00).

END OF WORK PACKAGE

GENERAL SUPPORT**M17/M18 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-037-7289)****COVER ASSEMBLY MAINTENANCE
REMOVAL, DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY, INSTALLATION**

INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/PartsGrease (item 16, WP 0152 00)
Lockwasher (7) (item 18, WP 0111 00)
Lockwasher (4) (item 2, WP 0114 00)
Lockwasher (4) (item 8, WP 0114 00)
O-ring (item 17, WP 0111 00)
Sealing compound (item 13, WP 0152 00)
Wiping rag (item 18, WP 0152 00)**References**TM 750-116
WP 0111 00
WP 0114 00

REMOVAL

WARNING

RADIATION




**TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

NOTE

General support maintenance instructions for the M18 quadrant cover assembly are identical to the M17 quadrant cover assembly.



1fc172

1fc173

M17/M18 Quadrant

WARNING


To avoid injury to personnel and damage to equipment, cover assembly will only be removed if counters are fully illuminated. Place cover assembly in secure area and exercise caution to avoid breakage of nuclear lamps.

Remove seven machine screws (1), seven lockwashers (2), cover assembly (3), and O-ring (4) from housing assembly (5). Discard lockwashers and O-ring.

DISASSEMBLY


CAUTION

Exercise special care when removing optical instrument windows to ensure that tritium vials are not damaged.



M17/M18 Quadrant

1. Remove two machine screws (1), two lockwashers (2), and window plate (3) from quadrant cover (4). Discard lockwashers.
2. Remove sealing compound from edge of optical instrument window (5) and remove window.




M17/M18 Quadrant

3. Remove two machine screws (6), two lockwashers (7), and window plate (8) from quadrant cover (4). Discard lockwashers.
4. Remove sealing compound from edge of optical instrument window (9) and remove window.

REPAIR OR REPLACEMENT

1. Replace entire cover assembly if cracked, broken, or damaged in any way that would allow foreign matter to enter interior of the M17/M18 quadrant.
2. Repair by replacing authorized parts that do not meet inspection criteria. Refer to WP 0111 00 and WP 0114 00.

ASSEMBLY



M17/M18 Quadrant


1. Install optical instrument window (1) in quadrant cover (2).

WARNING




Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

2. Apply a light coat of sealing compound (item 13, WP 0152 00) in channel around optical instrument window (1) and to threads of two machine screws (3).
3. Install window plate (4), two new lockwashers (5) (item 8, WP 0114 00), and two machine screws (3). Tighten machine screws.



M17/M18 Quadrant

4. Install optical instrument window (6) in quadrant cover (2).
5. Apply a light coat of sealing compound (item 13, WP 0152 00) in channel around optical instrument window (6) and to threads of two machine screws (7).
6. Install window plate (8), two new lockwashers (9) (item 8, WP 0114 00), and two machine screws (7). Tighten machine screws.

INSTALLATION

1fc178

M17/M18 Quadrant

1. Apply light coat of grease (item 16, WP 0152 00) on new O-ring (1) (item 17, WP 0111 00) and place cover assembly (2) with new O-ring on housing assembly (3).
2. Apply sealing compound (item 13, WP 0152 00) to threads of seven machine screws (4).
3. Install seven new lockwashers (5) (item 18, WP 0111 00) and seven machine screws (4).
4. Purge and charge M17/M18 quadrant (TM 750-116).

END OF WORK PACKAGE

GENERAL SUPPORT**M17A1/M18A1 FIRE CONTROL QUADRANT
(1290-01-515-8260/1290-01-515-8262)****COVER ASSEMBLY MAINTENANCE
REMOVAL, DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY, INSTALLATION**

INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Grease (item 15, WP 0152 00)
Lockwasher (7) (item 18, WP 0111 00)
Lockwasher (4) (item 8, WP 0114 00)
O-ring (item 17, WP 0111 00)
Sealing compound (item 13, WP 0152 00)
Wiping rag (item 18, WP 0152 00)

References

TM 750-116
WP 0047 00
WP 0111 00
WP 0114 00

Equipment Conditions

Battery enclosure and gasket removed (WP 0047 00)


REMOVAL**NOTE**

General support maintenance instructions for the M18A1 quadrant cover assembly are identical to the M17A1 quadrant cover assembly.

REMOVAL - Continued


CAUTION

Do not attempt to remove adapter plate from cover assembly. A short wire harness passing through adapter plate cannot be removed without damaging equipment. Adapter plate can only be removed or installed by the manufacturer. Two access holes are provided in adapter plate to allow cover assembly removal.



M17A1/M18A1 Quadrant

1. Remove seven machine screws (1) and seven lockwashers (2) from cover assembly (3). Discard lockwashers.



M17A1/M18A1 Quadrant


2. Remove plug (4) from cover assembly (3).

CAUTION

Use extreme care when removing cover assembly. A connector on a short wire harness on cover is connected to a connector on a short wire harness on quadrant. These connectors and wire harnesses are easily damaged.


- Carefully pull cover assembly (3) and O-ring (5) away from housing assembly (6) and disconnect connector (7) from connector (8). Remove cover assembly and O-ring. Discard O-ring.

DISASSEMBLY



M17A1/M18A1 Quadrant

- Remove two machine screws (1), two lockwashers (2), window plate (3), and optical instrument window (4). Discard lockwashers.




M17A1/M18A1 Quadrant

- Remove two machine screws (5), two lockwashers (6), window plate (7), and optical instrument window (8). Discard lockwashers.

REPAIR OR REPLACEMENT

- Replace entire cover assembly if cracked, broken, or damaged in any way that would allow foreign matter to enter interior of the M17A1/M18A1 quadrant.
- Repair by replacing authorized parts that do not meet inspection criteria. Refer to WP 0111 00 and WP 0114 00.

ASSEMBLY



M17A1/M18A1 Quadrant


1. Install optical instrument window (1) in quadrant cover (2).

WARNING




Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

2. Apply a light coat of sealing compound (item 13, WP 0152 00) in channel around optical instrument window (1) and to threads of two machine screws (3).
3. Install window plate (4), two new lockwashers (5) (item 8, WP 0114 00), and two machine screws (3).



M17A1/M18A1 Quadrant

4. Install optical instrument window (6) in quadrant cover (2).
5. Apply a light coat of sealing compound (item 13, WP 0152 00) in channel around optical instrument window (6) and to threads of two machine screws (7).
6. Install window plate (8), two new lockwashers (9) (item 8, WP 0114 00), and two machine screws (7).

INSTALLATION

1fc185

M17A1/M18A1 Quadrant

1. Apply light coat of grease (item 15, WP 0152 00) on new O-ring (1) (item 17, WP 0111 00) and place on cover assembly (2).
2. Connect connector (3) on cover assembly (2) to connector (4) on housing assembly (5).

CAUTION

Use extreme care during assembly. Do not pinch wires or connectors between parts.

3. Apply sealing compound (item 13, WP 0152 00) to threads of seven machine screws (6).
4. Install cover assembly (2) and O-ring (1) on housing assembly (5) with seven new lockwashers (7) (item 18, WP 0111 00) and seven machine screws (6).
5. Install plug (8) in cover assembly (2).
6. Install battery enclosure and gasket. Refer to WP 0047 00.
7. Purge and charge with dry nitrogen. Refer to TM 750-116.

END OF WORK PACKAGE

GENERAL SUPPORT
**M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-037-7289 AND 1290-01-515-8260/1290-01-515-8262)**
**COUNTER ASSEMBLY MAINTENANCE
REMOVAL, DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY, INSTALLATION**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
 Tool Kit, Electronic System Maintenance (SC 5180-95-B29)
 Torque wrench adapter (item 15, WP 0149 00)

Materials/Parts

Grease (item 16, WP 0152 00)
 Lockwasher (3) (item 19, WP 0112 00)
 Lockwasher (4) (item 19, WP 0115 00)
 Sealing compound (item 13, WP 0152 00)
 Solvent cleaning compound (item 12, WP 0152 00)
 Spring pin (item 8, WP 0115 00)
 Wiping rag (item 18, WP 0152 00)

References

WP 0049 00
 WP 0050 00
 WP 0112 00
 WP 0115 00

Equipment Conditions

Cover assembly removed (WP 0049 00, WP 0050 00)
 Correction knob assembly removed (WP 0049 00, WP 0050 00)


REMOVAL**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

NOTE

General support maintenance instructions for the M18/M18A1 quadrant counter assembly are identical to those for the M17/M17A1 quadrant counter assembly.


REMOVAL - Continued



1fc186

M17/M17A1 and M18/M18A1 Quadrant

1. Set counters (1) at zero. Scribe line on base assembly (2) and housing assembly (3).




1fc187


M17/M17A1 and M18/M18A1 Quadrant

2. Remove three machine screws (4), three lockwashers (5), and counter assembly (6) from housing assembly (3). Discard lockwashers.

DISASSEMBLY




Bottom View




Top View

1. Remove four machine screws (1), four lockwashers (2), and correction counter (3). Discard lockwashers.



Top View

2. Remove detent plunger (4) and compression helical spring (5) from support (6).



CAUTION


Support spur gear in V block on solid surface to prevent damage to shaft.

3. Remove headless straight pin (7) and spur gear (8).


DISASSEMBLY - Continued

CAUTION

Support counter detent in V block on solid surface to prevent damage to shaft.




4. Remove headless straight pin (9), counter detent (10), and headless straight pin (11) from correction counter (3).




Bottom View

5. Remove four machine screws (12) and four flat washers (13).



Top View


6. Remove elevation counter (14) from support (6).
7. Remove spring pin (15) and internal gear (16) from elevation counter (14). Discard spring pin.



1fc195

Top View

8. Remove spider assembly (17) from support (6).



1fc196

Top View

9. Remove retaining ring (18) and spur gearshaft (19) from support (6).

CLEANING

WARNING



Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.

CAUTION


Do not clean correction counter or elevation counter with cleaning compound.

Clean all parts except correction counter and elevation counter with cleaning compound (item 12, WP 0152 00). Wipe off excess cleaning compound with a clean wiping rag (item 18, WP 0152 00).

REPAIR OR REPLACEMENT


1. Replace counter assembly if counters cannot be adjusted. This condition will affect accuracy of the sighting procedures.
2. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0112 00 and WP 0115 00.

ASSEMBLY




1fc197

1. Apply a light coat of grease (item 16, WP 0152 00) to spur gearshaft (1) and install. Secure with retaining ring (2).




1fc198

3. Apply a light coat of grease (item 16, WP 0152 00) to spider assembly (3) and place in support (4).



1fc199

4. Place internal gear (5) on elevation counter (6) and secure with new spring pin (7) (item 8, WP 0115 00).
5. Place elevation counter (6) on support (4) and slide onto spider assembly (3).



1fc200


Bottom View

WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

6. Apply a thin coat of sealing compound (item 13, WP 0152 00) to four flat washers (8) and four machine screws (9) and install.




1fc201

CAUTION

Support spur gear in V block on solid surface to prevent damage to shaft.


7. Install spur gear (10) and headless straight pin (11) on correction counter (12).

ASSEMBLY - Continued




1fc202

8. Install headless straight pin (13) in counter detent (14).
9. Slide counter detent (14) onto counter shaft (15).




1fc203

10. Apply a light coat of grease (item 16, WP 0152 00) to detent plunger (16). Install compression helical spring (17) and detent plunger in support (4).




1fc204

11. Apply sealing compound (item 13, WP 0152 00) to threads of four machine screws (18).
12. Position correction counter (12) on support (4) and fasten in place using four new lockwashers (19) (item 19, WP 0115 00) and four machine screws (18). Zero correction counter.



13. Apply a light coat of grease (item 16, WP 0152 00) to counter detent (14) and align with detent plunger (16), making sure headless straight pin (13) is in uppermost position.

ASSEMBLY - Continued



NOTE


Perform step 14 only if correction counter or counter detent has been replaced.

14. Install and tighten screw (20) (No. 2X56) in counter detent (14). Drill and ream 0.0625 in. diameter hole through counter detent and counter shaft (15).

CAUTION

Support counter detent in V block on solid surface to prevent damage to shaft.

15. Install headless straight pin (21) and remove screw (20), if present.



Top View


Bottom View

16. Check elevation counter (6) and correction counter (12) for smooth rotation. If movement is not smooth, loosen four machine screws (9) and four machine screws (19), and reposition counters.

INSTALLATION


NOTE

Check that correction and elevation counters are set at zero before installation of counter assembly. Ensure scribe lines are aligned on M17/M18 quadrant housing assembly.




1fc209

1. Apply sealing compound (item 13, WP 0152 00) to threads of three machine screws (1).
2. Place counter assembly (2) in housing assembly (3) and secure with three new lockwashers (4) (item 19, WP 0112 00) and three machine screws (1).



1fc210

3. Install correction knob assembly (5) and cover assembly (6). Refer to WP 0049 00 or WP 0050 00.
4. Turn elevation knob (7) in one direction to 1433 mils.
5. Turn elevation knob (7) in opposite direction to 9720 mils.

INSTALLATION - Continued

1fc211

NOTE

Starting torque should be no greater than 10 in.-lb. (1.13 N-m) or less than 3 in.-lb. (0.34 N-m).

6. Apply torque wrench (8) with torque wrench adapter (9) to elevation knob (7).
7. Measure torque. If torque cannot be met, remove and reinstall spring plug retainer. Refer to WP 0049 00 or WP 0050 00.

END OF WORK PACKAGE

GENERAL SUPPORT

**M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-037-7289 and 1290-01-515-8260/1290-01-515-8262)**

**WORM SHAFT ASSEMBLY MAINTENANCE
REMOVAL, CLEANING, REPAIR OR REPLACEMENT, INSTALLATION, ADJUSTMENT**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Grease (item 15, WP 0152 00)
Grease (item 16, WP 0152 00)
O-ring (item 14, WP 0112 00)
O-ring (item 17, WP 0112 00)
O-ring (item 22, WP 0112 00)
Solvent cleaning compound (item 12, WP 0152 00)
Spring tension washer (item 12, WP 0112 00)
Wiping rag (item 18, WP 0152 00)

References

WP 0049 00
WP 0050 00
WP 0054 00
WP 0057 00
WP 0112 00

Equipment Conditions

Cover assembly removed (WP 0049 00, WP 0050 00)
Counter assembly removed (WP 0054 00)


REMOVAL

WARNING

RADIATION


TRITIUM
GAS (H₃)

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.




1fc212

1. Straighten locking ear (1) on key washer (2).



1fc213

2. Unscrew spring plug retainer (3) from housing assembly (4).
3. Remove O-ring (5) and key washer (2) from spring plug retainer (3). Discard O-ring.
4. Remove compression helical spring (6) from housing assembly (4).
5. Remove V-type bearing (7) from housing assembly (4).




1fc214

CAUTION


Support elevation knob in V block on solid surface to prevent damage to worm shaft.

6. Remove headless straight pin (8) from worm shaft assembly (9).
7. Remove elevation knob assembly (10) from worm shaft assembly (9).




1fc215

8. Remove spring tension washer (11), packing retainer (12), and O-ring (13) from worm shaft assembly (9). Discard O-ring and spring tension washer.




1fc216

9. Straighten locking ear (14) on key washer (15).

REMOVAL - Continued

10. Remove elevation retainer (16) from worm shaft assembly (9).
11. Remove O-ring (17) and key washer (15) from elevation retainer (16). Discard O-ring.

**NOTE**

Check position of flat (18) on worm shaft assembly (9) in relationship to housing assembly (4).

12. Rotate worm shaft assembly (9) and remove.

CLEANING**WARNING**

Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.


Clean all parts with cleaning compound (item 12, WP 0152 00). Wipe off excess cleaning compound with a clean wiping rag (item 18, WP 0152 00).

REPAIR OR REPLACEMENT

1. Inspect gears for missing teeth or stripped gears.
2. Inspect bearing surfaces for nicks or burrs.
3. Replace worm shaft assembly if bent or damaged in a way that would affect the accuracy of the elevation adjustments.
4. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0112 00.

INSTALLATION**NOTE**


Ensure flat on worm shaft assembly is in proper position for counter assembly clearance.



1fc219


1. Apply light coat of grease (item 15, WP 0152 00) to worm shaft assembly (1).
2. Insert worm shaft assembly (1) in housing assembly (2) by turning shaft.

INSTALLATION - Continued




1fc220

3. Install key washer (3) on elevation retainer (4).
4. Apply light coat of grease (item 16, WP 0152 00) to new O-ring (5) (item 17, WP 0112 00), and install on elevation retainer (4).




1fc221

5. Screw elevation retainer (4) into housing assembly (2) until tight.
6. Bend locking ear (6) to secure key washer (3) to housing assembly (2).



1fc222

7. Apply a light coat of grease (item 16, WP 0152 00) to new O-ring (7) (item 14, WP 0112 00).
8. Install O-ring (7), packing retainer (8), and new spring tension washer (9) (item 12, WP 0112 00) over worm shaft assembly (1).



1fc223

NOTE

Perform steps 9 and 10, and continue with step 12, if new worm shaft assembly has been installed. Perform step 11 if previously-installed components are used.


9. Install elevation knob assembly (10) on worm shaft assembly (1) and secure with setscrew, NSN 5305-00-282-8902. Using the pilot hole located on the knob, drill hole through worm shaft assembly.
10. Remove setscrew from elevation knob assembly (10).
11. Install elevation knob assembly (10) on worm shaft assembly (1).

CAUTION

Support elevation knob assembly in V block on solid surface to prevent damage to worm shaft.


12. Install headless straight pin (11) in elevation knob assembly (10) and worm shaft assembly (1).

INSTALLATION - Continued




1fc224

13. Apply a light coat of grease (item 15, WP 0152 00) to V-type bearing (12), and install in housing assembly (2).
14. Install compression helical spring (13) in housing assembly (2).
15. Place key washer (14) on spring plug retainer (15).
16. Apply a light coat of grease (item 16, WP 0152 00) to new O-ring (16) (item 22, WP 0112 00), and install on spring plug retainer (15).
17. Screw spring plug retainer (15) into housing assembly (2) until tight.




1fc225

18. Bend locking ear (17) on key washer (14) to secure spring plug retainer (15) to housing assembly (2).



1fc226


19. Install counter assembly (18) (WP 0054 00).




1fc227

20. Install correction knob assembly (19) and cover assembly (20) (WP 0049 00 or WP 0050 00).

ADJUSTMENT



1. Using torque wrench (1) with torque wrench adapter (2), measure torque. Torque reading required to start elevation knob assembly (3) should be no greater than 10 in.-lb (1.13 N-m) or less than 3 in.-lb (0.34 N-m).



2. If torque readings are not as specified, remove elevation knob assembly (3) and straighten locking ears (4 and 5).
3. Tighten elevation retainer (6) and spring plug retainer (7) to increase torque, or loosen retainers to decrease torque.
4. Check for backlash (WP 0057 00).

END OF WORK PACKAGE

GENERAL SUPPORT**M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-7289/1290-01-515-8262)****FIRE CONTROL LEVEL ASSEMBLY (CROSS LEVEL VIAL ASSEMBLY) MAINTENANCE
REMOVAL, DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY, INSTALLATION, ADJUSTMENT**

INITIAL SETUP:**Test Equipment**

Mounting bracket (item 2, WP 0149 00)
Optical equipment test fixture (item 8, WP 0149 00)

Tools and Special Tools

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Lockwasher (2) (item 9, WP 0111 00)
Lockwasher (item 11, WP 0111 00)
Plastic bag (item 5, WP 0152 00)
Sealing compound (item 13, WP 0152 00)
Tape (item 20, WP 0152 00)

References

WP 0111 00
WP 0116 00

Equipment Conditions

Optical equipment test fixture set up and adjusted (WP 0057 00)

REMOVAL

WARNING

RADIATION




**TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

NOTE

Replacement of level assembly parts can be done without removing level assembly from M18 quadrant.



1fc231


1. Remove three machine screws (1), three lockwashers (2), and reflector (3) from level assembly (4). Discard lockwashers.

NOTE

Level assembly of M18A1 quadrant is hardwired to housing assembly and cannot be removed by General Support maintenance but components of level assembly can be replaced.

2. Remove level assembly (4) from housing assembly (5) (M18 only).

DISASSEMBLY




1fc232

1. Remove sealing compound and loosen setscrew (1).
2. Remove sealing compound from level assembly and remove externally threaded ring (2).
3. Remove eccentric (3).
4. Slide fire control level (4) from vial bracket (5), and lift out level cover (6).
5. If damaged, remove setscrew (1).
6. If damaged, remove headless straight pin (7).


REPAIR OR REPLACEMENT

1. Replace fire control level assembly if any threads are stripped or vial bracket is damaged.
2. Fire control level may be replaced if it is cracked but still illuminated. Dispose of broken fire control level in accordance with RSO instructions. If fire control level is cracked and not illuminated, notify RSO. Perform wipe test under RSO supervision. Remove, bag, and secure assembly under RSO direction and await wipe test results. If contaminated, dispose of assembly per RSO instructions. If assembly is not contaminated, replace fire control level. Dispose of replaced fire control level per RSO instructions.
3. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0111 00 and WP 0116 00.

ASSEMBLY



1. If removed, install new headless straight pin (1).
2. If removed, install, but do not tighten, new setscrew (2).
3. Place level cover (3) in vial bracket (4).
4. Slide fire control level (5) into vial bracket (4) and level cover (3).
5. Install eccentric (6), and screw in externally threaded ring (7).

INSTALLATION


1fc234

1. Place level assembly (1) on housing assembly (2).
2. Place reflector (3) on level assembly (1).

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

3. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (4) and machine screw (5), and install three new lockwashers (6) (items 9 and 11, WP 0111 00) and three machine screws in housing assembly (2).

ADJUSTMENT

1fc235

1. Install M18 quadrant (1) on adapter (2).
2. Recheck level of optical equipment test fixture (3).
3. Remove externally threaded ring (4) and eccentric (5).
4. Place a dab of sealing compound (item 13, WP 0152 00) on slotted end of eccentric (5) and to threads of externally threaded ring (4).
5. Reinstall eccentric (5) and externally threaded ring (4) and turn eccentric until bubble (6) in level assembly (7) centers.
6. Tighten externally threaded ring (4) and setscrew (8).
7. Apply sealing compound (item 13, WP 0152 00) to outside of externally threaded ring (4) and setscrew (8).

END OF WORK PACKAGE

CHAPTER 13

GENERAL SUPPORT
FINAL INSPECTION INSTRUCTIONS
FOR
M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT

GENERAL SUPPORT

**M17/M18 AND M17A1/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-037-7289 AND 1290-01-515-8260/1290-01-515-8262)**

**FINAL INSPECTION INSTRUCTIONS
TEST AND INSPECTION**

INITIAL SETUP:**Test Equipment**

Extension adapter (item 3, WP 0149 00)
Fire control quadrant (item 10, WP 0149 00)
Mounting bracket (item 2, WP 0149 00)
Optical equipment test fixture (item 8, WP 0149 00)
Plate-mounted level (item 12, WP 0149 00)
Torque wrench adapter (item 14, WP 0149 00)
Torque wrench adapter (item 15, WP 0149 00)

Tools and Special Tools

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

References

TM 750-116
TM 9-1025-211-10
TM 9-1025-211-20&P
TM 9-1025-211-34
TM 9-1025-215-10
TM 9-1025-215-25&P
WP 0048 00
WP 0049 00

Equipment Conditions

M17/M18 or M17A1/M18A1 quadrant removed from M198/M777 howitzer
(TM 9-1025-211-20&P/TM 9-1025-215-25&P)

Special Environmental Conditions

Ambient temperature of +60 °F (+16 °C) to +90 °F (+32 °C)


TEST AND INSPECTION**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When testing or inspecting radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

TEST AND INSPECTION - Continued**NOTE**


If the M17/M18 or M17A1/M18A1 quadrant being inspected fails to meet the required standards, ensure all maintenance authorized at the applicable level has been performed correctly. Then send the M17/M18 or M17A1/M18A1 quadrant to depot maintenance.

A final inspection will be performed prior to returning a M17/M18 or M17A1/M18A1 quadrant to the using unit or the supply system.

Setting Up and Adjusting the Optical Equipment Test Fixture and Adapter


1fc236

1. Secure optical equipment test fixture (1) on test bench.




1fc237

2. Place plate-mounted level (2) on block (3), perpendicular to axis of rotation.
3. Cross-level the optical equipment test fixture (1).



1fc238

4. Set cant vernier scale (4) and elevation vernier scale (5) to zero.




1fc239

NOTE

Ensure precision ground surfaces are free of nicks and burrs.

When installing mounting bracket (6), ensure precision ground surface (7) is parallel to top of block within 0.1 mil.

5. Install mounting bracket (6) on end of cross-leveling shaft (8).
6. Lightly tighten six setscrews (9).

TEST AND INSPECTION - Continued**Setting Up and Adjusting the Optical Equipment Test Fixture and Adapter - Continued**

7. Place plate-mounted level (2) on precision ground surface (7) of mounting bracket (6).
8. Check that bubble (10) in plate-mounted level (2) is level.
9. Tighten setscrews (9). Recheck optical equipment test fixture (1), plate-mounted level (2), and precision ground surface (7).


NOTE

Adjust bubble in plate-mounted level, if not centered.

10. Rotate plate-mounted level (2) 180 degrees from original position, and check again that bubble (10) in plate-mounted level is level.


Visual Inspection**NOTE**

Check to make sure that optical equipment test fixture is still level in elevation and cant.




1fc241

1. All machine screws (1) and lockwashers (2) must be present and tight.
2. Mounting surface (3) must be clean and free of nicks and burrs.
3. M17/M18 or M17A1/M18A1 quadrant (4) must be free of dirt, rust, and foreign matter. All parts must be present.
4. Counter windows (5) must be free of condensation.
5. Counter numbers (6) must be in horizontal alignment.

TEST AND INSPECTION - Continued**Mounting M17/M18 or M17A1/M18A1 Quadrant on Optical Equipment Test Fixture**


1fc242

1. Position M17/M18 or M17A1/M18A1 quadrant (1) on adapter (2) of optical equipment test fixture (3).
2. Install and tighten four machine bolts (4).




1fc243

3. Place plate-mounted level (5) parallel to block (6) of optical equipment test fixture (3).
4. Rotate cant handwheel (7) until bubble (8) in plate-mounted level (5) centers.



1fc244

5. Place plate-mounted level (5) at 90 degree angle to block (6) of optical equipment test fixture (3).
6. Turn elevation handwheel (9) until bubble (8) in plate-mounted level (5) centers.



1fc245


7. Using correction knob (10), set correction counter (11) at zero mils.
8. Using elevation knob (12), set elevation counter (13) at zero mils.
9. Ensure that bubble in elevation level (14) is centered. If not centered, adjust. Refer to WP 0048 00.

TEST AND INSPECTION - Continued

Backlash Inspection

NOTE


Ensure adapter mounting surfaces and M17/M18 or M17A1/M18A1 quadrant mounting surfaces are clean and free of nicks and burrs.



1. Mount M17/M18 or M17A1/M18A1 quadrant (1) on optical equipment test fixture (2). Refer to Mounting M17/M18 or M17A1/M18A1 Quadrant on Optical Equipment Test Fixture.

NOTE


Turn elevation knob clockwise. Do not overtravel zero.



2. Zero correction counter (3) and elevation counter (4) of M17/M18 or M17A1/M18A1 quadrant (1).


NOTE

Ensure optical equipment test fixture is level in elevation and cant.



1fc248


3. Scribe index line (5) on M17/M18 or M17A1/M18A1 quadrant (1) near elevation knob (6).



1fc249


NOTE

An index pointer may be made from 1/16 in. diameter rod with a sharp point on one end. The index pointer may be held in place using a small C-clamp (7).




1fc250

4. Place index pointer (8) on the elevation knob (6) directly opposite the scribed index line (5). The index pointer may have to be moved for each elevation setting.
5. Place fire control quadrant (9) on top of mounting bracket (10) and level bubble in fire control quadrant level (11) using micrometer knob (12) and record reading.


TEST AND INSPECTION - Continued**Backlash Inspection - Continued****NOTE**

Do not go past scribed line when turning counterclockwise. Ensure scribed index line and index pointer are in perfect alignment.

6. Rotate elevation knob (6) at least 1/2-turn clockwise. Then turn counterclockwise until index pointer (8) aligns with scribed index line (5).



7. Rotate elevation handwheel (13) until bubble in M17/M18 or M17A1/M18A1 quadrant elevation level (14) is centered.



1fc253

8. Using micrometer knob (12) on fire control quadrant (9), center bubble in fire control quadrant level (11) and record reading.


NOTE

The difference between the readings recorded in steps 5 and 8 will give the amount of backlash.

Backlash shall not exceed 0.7 mil at any elevation or depression setting.

9. Repeat steps 4 through 8 at elevation settings of 150-mil depression, 200-mil elevation, 800-mil elevation, and 1400-mil elevation. Use fire control quadrant set on optical equipment test fixture adapter to initially set elevations.

Elevation Counter and Correction Counter Excursion Range Inspection




1fc254

1. Turn elevation knob (1) clockwise as far as possible. Elevation counter (2) must read 1433 mils or greater.


TEST AND INSPECTION - Continued**Elevation Counter and Correction Counter Excursion Range Inspection - Continued**

- Turn elevation knob (1) counterclockwise as far as possible. Elevation counter (2) must read 9720 mils or less.



1fc255

- Turn correction knob (3) clockwise as far as possible. Correction counter (4) must read on or between -95 mils and -99 mils.
- Turn correction knob (3) counterclockwise as far as possible. Correction counter (4) must read on or between +95 mils and +99 mils.


Elevation Accuracy Inspection (200-Mil Increments)

1fc256

NOTE


When installing mounting bracket (1), ensure precision ground surface (2) is parallel to top of block within 0.1 mil.

- Install mounting bracket (1) on end of cross-leveling shaft (3).
- Lightly tighten six setscrews (4).



1fc257

3. Place plate-mounted level (5) on precision ground surface (2) of mounting bracket (1).




1fc258

4. Check that bubble (6) in plate-mounted level (5) is level.
5. Tighten setscrews (4). Recheck optical equipment test fixture (7), plate-mounted level (5), and precision ground surface (2).
6. Rotate plate-mounted level (5) 180 degrees from original position, and check again that bubble (6) in plate-mounted level is level.


TEST AND INSPECTION - Continued

Elevation Accuracy Inspection (200-Mil Increments) - Continued




1fc259

7. Mount M17/M18 or M17A1/M18A1 quadrant (8) on optical equipment test fixture (7). Refer to Mounting M17/M18 or M17A1/M18A1 Quadrant on Optical Equipment Test Fixture.



1fc260

8. Turn elevation knob (9) until elevation counter (10) reads 200 mils.
9. Turn elevation handwheel (11) until bubble in elevation level (12) centers.



1fc261


10. Set fire control quadrant (13) to 200 mils. Place on top of mounting bracket (1) and zero using micrometer knob (14).

NOTE

Micrometer dial will indicate any error. Error should not exceed 0.5 mil (1.0-mil total spread).

11. Repeat steps 1 through 10 with fire control quadrant set at elevations of 400, 600, 800, 1000, 1200, and 1400 mils. Error should not exceed 0.5 mil.

Checking the Effect of the Correction Counter Setting on the Elevation Counter and Level Bubble



1. Mount M17/M18 or M17A1/M18A1 quadrant (1) on optical equipment test fixture (2). Refer to Mounting M17/M18 or M17A1/M18A1 Quadrant on Optical Equipment Test Fixture.


NOTE

Observe bubble in elevation level (3) during steps 2 through 5. It must remain centered within one vial graduation.

2. Turn correction knob (4) clockwise to -50 mils.
3. Check that elevation counter (5) reads 50 ± 0.5 mils.
4. Turn correction knob (4) counterclockwise to 50 mils.
5. Check that elevation counter (5) reads 9950 ± 0.5 mils.

TEST AND INSPECTION - Continued

Torque Inspection




1. Place torque wrench adapter (1) (item 14, WP 0149 00) over correction knob (2).
2. Place torque wrench (3) on torque wrench adapter (1).
3. Measure torque.

NOTE

Torque required for continuous turning should be between 1 in.-lb (0.11 N-m) and 4 in.-lb (0.45 N-m).

4. If torque cannot be met, remove correction knob (2) (WP 0049 00) and check for possible bent shaft.



5. Place torque wrench adapter (1) (item 15, WP 0149 00) and torque wrench (3) over elevation knob (4).
6. Measure torque.

NOTE

Torque required for continuous turning should be between 3 in.-lb (0.34 N-m) and 10 in.-lb (1.13 N-m).

7. If torque cannot be met, remove and reinstall spring plug retainer (WP 0049 00).

Illumination Inspection


WARNING

RADIATION



TRITIUM
GAS (H₃)

When inspecting radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.



1fc265

1. Take M17 quadrant (1) or M18 quadrant (2) into dark area, and wait 15 minutes.
2. Take M17A1 quadrant (1) or M18A1 quadrant (2) into dark area, and turn on switch.

NOTE

Bubble in cross level (3) applies to M18/M18A1 quadrant only.

3. Check that bubble in cross level (3), bubble in elevation level (4), elevation counter (5), and correction counter (6) are clearly visible with even illumination.

Purging

Purge and charge M17/M18 or M17A1/M18A1 quadrant (TM 750-116).

M17/M18 or M17A1/M18A1 Quadrant and Cannon Tube Synchronization Procedure

1. Mount quadrant to howitzer (TM 9-1025-211-20&P/TM 9-1025-215-25&P). Then perform synchronization procedure (TM 9-1025-211-34/TM 9-1025-215-25&P).


TEST AND INSPECTION - Continued**M17/M18 or M17A1/M18A1 Quadrant and Cannon Tube Synchronization Procedure - Continued****NOTE**

M18/M18A1 quadrant is required for proper cannon tube synchronization.

Perform the following synchronization procedure whenever a cannon assembly or tube is removed.

Before beginning synchronization procedure, cannon tube must be depressed to zero mils and trunnions leveled (TM 9-1025-211-10/TM 9-1025-215-10).

Whenever the M17/M18 or M17A1/M18A1 quadrants are replaced, the following synchronization procedure should be performed.



1fc266

NOTE


Before using cannon leveling pad (1), check for cleanness.

The fire control quadrant should be set on the higher cannon leveling pad when leveling the cannon tube.

2. Test fire control quadrant (2) before using.
3. Place fire control quadrant (2) on cannon leveling pad (1) with LINE OF FIRE arrow (3) pointed toward the muzzle.
4. Depress or elevate the cannon tube with the elevating handwheel until bubble (4) in fire control quadrant level (2) centers.


NOTE

Elevation counter of M17/M18 and M17A1/M18A1 quadrants shall reflect tube elevation and shall not exceed 1.0-mil deviation, excluding backlash.



1fc267

5. Level elevation and cross level vials (5) of M171/M171A1 mount (6).



1fc268


NOTE

In the following steps, eliminate backlash by always making the last movement in the counter mechanisms a low-number-to-high-number movement.

6. Cross-level M18/M18A1 quadrant (7) using M172/M172A1 mount cross level knob (8).


TEST AND INSPECTION - Continued

M17/M18 or M17A1/M18A1 Quadrant and Cannon Tube Synchronization Procedure - Continued



1fc269

7. Center bubbles in elevation level (9) on M17/M17A1 quadrant (10) and M18/M18A1 quadrant (7) using elevation knob (11).
8. Elevation counter (12) in both quadrants should be zero. If not zero, turn elevation knob (11) to set counter at zero and adjust bubbles in elevation level (9) as necessary (WP 0048 00).



1fc270

9. Place fire control quadrant (2) on seats on M172/M172A1 mount. Bubble (4) in fire control quadrant level should center.
10. If bubble (4) in fire control quadrant level (2) is not centered, adjust eccentric stud assembly (13).
11. Loosen eccentric stud assembly (13) to disengage from spline plate (14).
12. Turn and engage spline plate (14). Tighten eccentric stud assembly (13).
13. Repeat step 10. If bubble (4) in fire control quadrant level (2) does not center, repeat steps 11 and 12 until centered.

END OF WORK PACKAGE

CHAPTER 14

**DIRECT SUPPORT
MAINTENANCE INSTRUCTIONS
FOR
M171/M171A1 TELESCOPE AND QUADRANT MOUNT**

DIRECT SUPPORT**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)****SERVICE UPON RECEIPT
SERVICE UPON RECEIPT OF MATERIEL**

SERVICE UPON RECEIPT OF MATERIEL**WARNING**

Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries.

Unpacking

When a new or reconditioned M171/M171A1 Telescope and Quadrant Mount is received, be aware of any shipping damage to packaging materiel. Report any damage on SF 364, Report of Discrepancy (ROD), as prescribed in AR 735-11-2. Retain packaging materiel for future use.

Checking Unpacked Equipment

1. Inspect the equipment for damage incurred during shipment. If the equipment has been damaged, report the damage on SF 361, Transportation Discrepancy Report.
2. Check the equipment against the packing slip to see if the shipment is complete. Report all discrepancies in accordance with applicable service instructions (e.g., for Army instructions, see DA PAM 738-750).


SERVICE UPON RECEIPT - Continued**Checking Unpacked Equipment - Continued**

3. Check to see whether the equipment has been modified.
4. Check M171 mount (1) for bare spots, dents, scuff marks, and damaged parts. Inspect M171 mount for cleanliness.
5. Operate cross level knob (2). Check that operation is smooth without binding or rough motion.
6. Operate elevation knob (3). Check that operation is smooth without binding or rough motion.

WARNING**RADIATION****TRITIUM
GAS (H₃)**

When inspecting radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M171 only).

7. Check cross level vial (4). Bubble must move freely. Glass must not be broken or cracked. Light must be present and even throughout the cross level vial.
8. Check elevation level vial (5). Bubble must move freely. Glass must not be broken or cracked. Light must be present and even throughout the elevation level vial.



1fc271

END OF WORK PACKAGE

DIRECT SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**M171/M171A1 MOUNT MAINTENANCE
DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:

Tools and Special Tools

- Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
- Tool Kit, Artillery and Turret Mechanic's: Ordnance (SC 5180-95-A12)
- Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

- Lockwasher (2) (item 7, WP 0120 00)
- Sealing compound (item 13, WP 0152 00)

References

- WP 0120 00

DISASSEMBLY

WARNING

RADIATION



**TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.


WARNING



Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries.

DISASSEMBLY - Continued

Remove two machine screws (1), two lockwashers (2), and instruction plate (3) from bearing housing assembly (4). Discard lockwashers. Illustration shows M171 only.


**REPAIR OR REPLACEMENT**

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0120 00.

ASSEMBLY**WARNING**

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

1. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (1).
2. Position instruction plate (2) on bearing housing assembly (3) and secure with two new lockwashers (4) (item 7, WP 0120 00) and two machine screws (1).



1fc275

END OF WORK PACKAGE

DIRECT SUPPORT

**M171 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273)**

**OPTICAL INSTRUMENT SUPPORT MAINTENANCE
DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Lockwasher (4) (item 5, WP 0121 00)

Lockwasher (2) (item 8, WP 0121 00)

Sealing compound (item 13, WP 0152 00)

Wiping rag (item 18, WP 0152 00)

References


WP 0121 00

Equipment Conditions

M171 mount removed from M198 howitzer (TM 9-1025-211-34)

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.




1fc278

1. Remove two socket cap screws (1) and two lockwashers (2). Discard lockwashers.
2. Pry two machine keys (3) out of grooves in optical instrument support (4).
3. Remove four socket cap screws (5), four lockwashers (6), two thumbscrews (7), and two thumbscrew assemblies (8). Discard lockwashers.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0121 00.

ASSEMBLY



1fc279

1. Install two thumbscrew assemblies (1) and two thumbscrews (2).

WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

2. Apply a light coat of sealing compound (item 13, WP 0152 00) to threads of four socket cap screws (3). Install four new lockwashers (4) (item 5, WP 0121 00) and four socket cap screws.
3. Install two machine keys (5) in grooves of optical instrument support (6).
4. Apply a light coat of sealing compound (item 13, WP 0152 00) to threads of two socket cap screws (7). Wipe off excess sealing compound with clean wiping rag (item 18, WP 0152 00). Install two new lockwashers (8) (item 8, WP 0121 00) and two socket cap screws.

END OF WORK PACKAGE

DIRECT SUPPORT

**M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-515-8265)**

**OPTICAL INSTRUMENT SUPPORT MAINTENANCE
DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Lockwasher (2) (item 8, WP 0121 00)

Sealing compound (item 13, WP 0152 00)

Wiping rag (item 18, WP 0152 00)

References


WP 0121 00

Equipment Conditions

M171A1 mount removed from M198/M777 howitzer (TM 9-1025-211-34/TM 9-1025-215-25&P)

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.




1fc280

1. Loosen two setscrews (1).
2. Remove two socket head capscrews (2), two spring tension washers (3), left manual control handle (4), and right manual control handle (5). Discard spring tension washers, if unserviceable.
3. Remove sealing compound and remove two setscrews (6). Remove two detent plungers (7).
4. Remove two socket head capscrews (8) and two lockwashers (9). Discard lockwashers.
5. Pry two machine keys (10) out of grooves in optical instrument support (11).

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0121 00.

ASSEMBLY



1fc281

1. Install two machine keys (1) in grooves of optical instrument support (2).

WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

2. Apply a light coat of sealing compound (item 13, WP 0152 00) to threads of two socket cap screws (3). Install two new lockwashers (4) (item 8, WP 0121 00) and two socket cap screws.
3. Apply a light coat of sealing compound (item 13, WP 0152 00) to threads of two socket head cap screws (5). Wipe off excess sealing compound with a clean wiping rag. Install two spring tension washers (6), bevel down, and two socket head cap screws onto left manual control handle (7) and right manual control handle (8). Tighten cap screws until snug.
4. Install two detent plungers (9). Tighten to positive stop and turn back one-half turn.
5. Install two setscrews (10) and apply sealing compound (item 13, WP 0152 00).
6. Loosen two socket head cap screws (5) one-quarter turn. If properly adjusted, latch will feel slightly loose.
7. Apply sealing compound (item 13, WP 0152 00) to threads of two setscrews (11). Install setscrews and tighten. Cover heads with sealing compound.

END OF WORK PACKAGE

DIRECT SUPPORT

**M171 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273)**

**OPTICAL INSTRUMENT ROCKER ASSEMBLY MAINTENANCE
DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Lockwasher (2) (item 8, WP 0122 00)

Sealing compound (item 13, WP 0152 00)

References


WP 0122 00

Equipment Conditions

M171 mount removed from M198 howitzer (TM 9-1025-211-34)

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M171 only).




1fc282

Remove two machine screws (1), two lockwashers (2), and identification plate (3) from optical instrument rocker (4). Discard lockwashers.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0122 00.

ASSEMBLY

1fc283

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

1. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (1).
2. Position identification plate (2) on optical instrument rocker (3) and secure with two new lockwashers (4) (item 8, WP 0122 00) and two machine screws (1).

END OF WORK PACKAGE

DIRECT SUPPORT**M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-515-8265)****OPTICAL INSTRUMENT ROCKER ASSEMBLY MAINTENANCE
DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Gasket (item 25, WP 0118 00)

Lockwasher (3) (item 27, WP 0118 00)

Lockwasher (2) (item 8, WP 0122 00)

References

WP 0118 00

WP 0122 00


Equipment Conditions

M171A1 mount removed from M198/M777 howitzer (TM 9-1025-211-34/TM 9-1025-215-25&P)

DISASSEMBLY**WARNING**


Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries.

DISASSEMBLY - Continued



1fc284

1. Remove two machine screws (1), two lockwashers (2), and identification plate (3) from optical instrument rocker (4). Discard lockwashers.



1fc285

2. Remove three screws (5), three lockwashers (6), cap and retainer assembly (7), and battery (8) from battery enclosure (9). Support battery enclosure. Discard lockwashers.

CAUTION


Use extreme care when removing battery enclosure. A short wire harness and connector on the battery enclosure is connected to a short wire harness and connector on the plate assembly. These connectors and wire harnesses are easily damaged.

- Carefully disconnect battery enclosure connector (10) from plate assembly connector (11) and remove battery enclosure (9) and gasket (12) from plate assembly (13). Discard gasket.
- Remove two socket capscrews (14) and plate assembly (13) from spacer (15).


REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0118 00 and WP 0122 00.

ASSEMBLY



- Position identification plate (1) on optical instrument rocker (2) and secure with two new lockwashers (3) (item 8, WP 0122 00) and two machine screws (4).

ASSEMBLY - Continued

1fc287

2. Install plate assembly (5) on spacer (6) and secure with two socket cap screws (7).
3. Position new gasket (8) (item 25, WP 0118 00) on battery enclosure (9).
4. Carefully connect plate assembly connector (10) to battery enclosure connector (11).

CAUTION

Be careful when assembling components. Do not pinch wire leads or connectors between parts.

5. Install battery enclosure (9) on plate assembly (5) with two new lockwashers (12) (item 27, WP 0118 00) and two screws (13).
6. Install cap and retainer assembly (14) on battery enclosure (9), using new lockwasher (15) (item 27, WP 0118 00) and screw (16).
7. Install battery (17) into battery enclosure (9) and secure with cap and retainer assembly (14).

END OF WORK PACKAGE

DIRECT SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**BEARING HOUSING ASSEMBLY MAINTENANCE
DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Lockwasher (2) (item 9, WP 0126 00)

Sealing compound (item 13, WP 0152 00)

Wiping rag (item 18, WP 0152 00)

References

WP 0126 00

Equipment Conditions

M171/M171A1 mount removed from M198/M777 howitzer (TM 9-1025-211-34/TM 9-1025-215-25&P)

DISASSEMBLY


WARNING

RADIATION



**TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M171 only).




1fc288

Remove two machine screws (1), two lockwashers (2), and optical instrument mirror (3) from bearing housing assembly (4). Discard lockwashers.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0126 00.

ASSEMBLY

1fc289

1. Position optical instrument mirror (1) on bearing housing assembly (2).

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

2. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (3). Wipe off excess sealing compound with a clean wiping rag (item 18, WP 0152 00). Install two new lockwashers (4) (item 9, WP 0126 00) and two machine screws. Tighten machine screws.

END OF WORK PACKAGE

CHAPTER 15

**GENERAL SUPPORT
MAINTENANCE INSTRUCTIONS
FOR
M171/M171A1 TELESCOPE AND QUADRANT MOUNT**

GENERAL SUPPORT**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)****M171/M171A1 MOUNT MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Gasket (item 25, WP 0118 00)
Gasket (item 9, WP 0119 00)
Grease (item 15, WP 0152 00)
Grease (item 16, WP 0152 00)
Lockwasher (item 5, WP 0118 00)
Lockwasher (12) (item 10, WP 0118 00)
Lockwasher (6) (item 14, WP 0118 00)
Lockwasher (3) (item 27, WP 0118 00)
Lockwasher (4) (item 2, WP 0119 00)
Lockwasher (5) (item 5, WP 0119 00)
Lockwasher (4) (item 7, WP 0119 00)
Lockwasher (4) (item 2, WP 0124 00)
Lockwasher (2) (item 6, WP 0126 00)
Lock wire (item 21, WP 0152 00)
Lock wire (item 22, WP 0152 00)
O-ring (item 10, WP 0119 00)
O-ring (item 12, WP 0119 00)
O-ring (item 13, WP 0119 00)
Plastic bag (item 5, WP 0152 00)
Sealing compound (item 13, WP 0152 00)
Solvent cleaning compound (item 12, WP 0152 00)
Tape (item 20, WP 0152 00)
Wiping rag (item 18, WP 0152 00)

References


WP 0118 00
WP 0119 00
WP 0120 00
WP 0124 00
WP 0126 00

DISASSEMBLY


WARNING




When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.




1. Remove and discard lock wire (1) (M171 only).



2. Remove hexagon capscrew (2) and lockwasher (3). Discard lockwasher (M171 only).
3. Remove setscrew (4) (M171A1 only).
4. If damaged, remove straight pin (5) (M171A1 only).
5. Drive out plain tapered pin(s) (6) (M171 and M171A1).
6. Remove optical instrument support (7) from bearing housing assembly (8).




7. Remove and discard lock wire (9).
8. Remove six machine screws (10) and six lockwashers (11). Discard lockwashers.
9. Remove retaining ring (12), protection bellows (13), and retaining ring (14).




10. Remove and discard lock wire (15).
11. Remove six machine screws (16) and six lockwashers (17). Discard lockwashers.


DISASSEMBLY - Continued




12. Remove and discard lock wire (18).
13. Remove three socket capscrews (19), three lockwashers (20), and shoulder pin (21).




14. Remove three screws (22), three lockwashers (23), and cap and retainer assembly (24) from battery box cover (25) (M171A1 only). Discard lockwashers.
15. Remove and discard gasket (26) (M171A1 only).
16. Remove two socket capscrews (27) and plate (28) from plate spacer (29) (M171A1 only).



17. Remove and discard lock wire (30).
18. Remove three socket capscrews (31), three lockwashers (32), plate spacer (29), and shoulder pin (33). Discard lockwashers.




19. Remove optical instrument rocker assembly (34) from bearing housing assembly (8).




20. Remove retaining ring (35) and protection bellows (36).

DISASSEMBLY - Continued



1fc298

21. Remove and discard lock wire (37) from machine thread plug (38).




1fc299

22. Loosen setscrew (39).
23. Remove machine thread plug (38), helical compression spring (40), and V bearing (41).


CAUTION

Support cross level knob in V block on solid surface to prevent damage to worm shaft.



1fc300


24. Drive out headless straight pin (42).
25. Remove knob (43).
26. Remove and discard lock wire (44).



1fc301


27. Remove flat washer (45), mechanical felt (46), and flat washer (47).

DISASSEMBLY - Continued




1fc302

- 28. Loosen setscrew (48).
- 29. Remove externally threaded ring (49).




1fc303

- 30. Partially remove worm shaft assembly (50).
- 31. Remove plain bearing (51).
- 32. Remove worm shaft assembly (50).




33. Remove and discard lock wire (52).
34. Remove four socket cap screws (53) and four lockwashers (54). Discard lockwashers.
35. Lift mounting adapter (55) clear of straight pins (56), and remove.




36. Remove plain encased seal (57) from mounting adapter (55).


DISASSEMBLY - Continued




37. Remove and discard lock wire (58).
38. Remove two socket head cap screws (59), two lockwashers (60), and locking dog (61). Discard lockwashers.
39. Remove inner round plain nut (62).
40. Remove bearing housing assembly (8) from arm assembly (63).
41. Remove and discard lock wire (64).
42. Remove two socket head cap screws (65), two lockwashers (66), and locking dog (67). Discard lockwashers.
43. Remove outer externally threaded ring (68).
44. Remove duplex ball bearing (69) from bearing housing assembly (8).



45. Remove four shoulder screws (70), four lockwashers (71), and retaining plate (72). Discard lockwashers.




46. Remove and discard lock wire (73).
47. Remove five socket head capscrews (74), five lockwashers (75), two socket capscrews (76), and two lockwashers (77). Discard lockwashers.




48. Remove access cover (78), O-ring (79), and gasket (80). Discard O-ring and gasket.

DISASSEMBLY - Continued




49. Loosen setscrew (81).




50. Remove close tolerance screw (82) and pawl (83).

51. Remove O-ring (84), retaining plate (85), and O-ring (86). Discard O-rings.



52. Remove sealing compound from two setscrews (87). Loosen two setscrews.



53. Remove two externally threaded rings (88), two eccentrics (89), cross level vial (90), elevation level vial (91), and two level covers (92).

CLEANING

WARNING



Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.

Clean all parts with cleaning compound (item 12, WP 0152 00). Wipe off excess cleaning compound with a clean wiping rag (item 18, WP 0152 00).

REPAIR OR REPLACEMENT


1. Replace fire control level assembly if any threads are stripped or vial holder is damaged.
2. Fire control level may be replaced if it is cracked but still illuminated. Dispose of broken fire control level in accordance with RSO instructions. If fire control level is cracked and not illuminated, notify RSO. Perform wipe test under RSO supervision. Remove, bag, and secure assembly under RSO direction and await wipe test results. If contaminated, dispose of assembly per RSO instructions. If assembly is not contaminated, replace fire control level. Dispose of replaced fire control level per RSO instructions.
3. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0118 00, WP 0119 00, WP 0120 00, WP 0124 00, and WP 0126 00.

ASSEMBLY

NOTE

Apply light coat of grease (item 15, WP 0152 00) to all machined surfaces.

Apply light coat of grease (item 16, WP 0152 00) to all O-rings.



1fc313

CAUTION

To prevent equipment damage of M171A1 mount, ensure that elevation level vial and cross level vial are positioned correctly. Visually check for special slot in elevation level vial.


1. Install two level covers (1), elevation level vial (2), cross level vial (3), two eccentrics (4), and two externally threaded rings (5) in bearing housing assembly (6).

WARNING




Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.


2. Apply sealing compound (item 13, WP 0152 00) to threads of two setscrews (7). Wipe off excess sealing compound with a clean wiping rag (item 18, WP 0152 00) and tighten setscrews.
3. Cover two setscrews (7) with sealing compound (item 13, WP 0152 00).



4. Install new O-ring (8) (item 12, WP 0119 00), retaining plate (9), and new O-ring (10) (item 10, WP 0119 00).




5. Apply sealing compound (item 13, WP 0152 00) to threads of close tolerance screw (11). Wipe off excess sealing compound with a clean wiping rag (item 18, WP 0152 00). Install pawl (12) and close tolerance screw.




6. Apply sealing compound (item 13, WP 0152 00) to setscrew (13). Wipe off excess sealing compound with a clean wiping rag (item 18, WP 0152 00). Tighten setscrew.


ASSEMBLY - Continued




7. Install new gasket (14) (item 9, WP 0119 00) and access cover (15) with new O-ring (16) (item 13, WP 0119 00).



8. Apply sealing compound (item 13, WP 0152 00) to threads of five socket cap screws (17) and two socket cap screws (18).
9. Install five new lockwashers (19) (item 5, WP 0119 00), five socket cap screws (17), two new lockwashers (20) (item 7, WP 0119 00), and two socket cap screws (18).
10. Install new lock wire (21) (item 21, WP 0152 00).




11. Apply sealing compound (item 13, WP 0152 00) to threads of four shoulder screws (22). Wipe off excess sealing compound with a clean wiping rag (item 18, WP 0152 00).
12. Install four new lockwashers (23) (item 2, WP 0119 00) and four shoulder screws (22) on retaining plate (24) to secure on M171 mount. Tighten shoulder screws.




13. Install duplex ball bearing (25) into bearing housing assembly (6).
14. Apply sealing compound (item 13, WP 0152 00) to threads of two socket head capscrews (26).
15. Align outer externally threaded ring (27) and secure with locking dog (28), two new lockwashers (29) (item 6, WP 0126 00), and two socket head capscrews (26).
16. Install new lock wire (30) (item 21, WP 0152 00).
17. Install bearing housing assembly (6) on arm assembly (31).
18. Apply sealing compound (item 13, WP 0152 00) to threads of two socket head capscrews (32).
19. Align inner plain round nut (33) and secure with locking dog (34), two new lockwashers (35) (item 7, WP 0119 00), and two socket head capscrews (32).
20. Install new lock wire (36) (item 21, WP 0152 00).


ASSEMBLY - Continued




21. Install plain encased seal (37) on mounting adapter (38) and lubricate with grease (item 15, WP 0152 00).




22. Install mounting adapter (38) on bearing housing assembly (6) over straight pins (39).
23. Apply sealing compound (item 13, WP 0152 00) to threads of four socket cap screws (40). Install four new lockwashers (41) (item 2, WP 0124 00) and four socket cap screws. Tighten socket cap screws.
24. Install new lock wire (42) (item 22, WP 0152 00).



25. Install protection bellows (43) and retaining ring (44) on bearing housing assembly (6).




26. Install optical instrument rocker assembly (45) on bearing housing assembly (6).




27. Apply sealing compound (item 13, WP 0152 00) to threads of three socket capscrews (46).
28. Install shoulder pin (47), plate spacer (48), three new lockwashers (49) (item 14, WP 0118 00), and three socket capscrews (46).
29. Install new lock wire (50) (item 22, WP 0152 00).

ASSEMBLY - Continued




30. Apply sealing compound (item 13, WP 0152 00) to threads of two socket cap screws (51) (M171A1 only).
31. Install plate (52) on plate spacer (48) and secure with two socket cap screws (51) (M171A1 only).
32. Install new gasket (53) (item 25, WP 0118 00) (M171A1 only).
33. Apply sealing compound (item 13, WP 0152 00) to two screws (54) and install battery box cover (55) on plate (52) with two new lockwashers (56) (item 27, WP 0118 00) and two screws (M171A1 only).
34. Apply sealing compound (item 13, WP 0152 00) to screw (57) and install cap and retainer assembly (58) with new lockwasher (59) (item 27, WP 0118 00) and screw (M171A1 only).




35. Apply sealing compound (item 13, WP 0152 00) to threads of three socket cap screws (60).
36. Install shoulder pin (61), three new lockwashers (62) (item 14, WP 0118 00), and three socket cap screws (60).
37. Install new lock wire (63) (item 22, WP 0152 00).

NOTE


Make sure slot in plain bearing aligns with guide pin in housing assembly.




38. Install worm shaft assembly (64).
39. Install plain bearing (65) on worm shaft assembly (64).



40. Install externally threaded ring (66) in optical instrument rocker assembly (45) and tighten until worm shaft assembly (64) rotates with a drag.
41. Apply sealing compound (item 13, WP 0152 00) on setscrew (67). Wipe off excess sealing compound with a clean wiping rag (item 18, WP 0152 00). Tighten setscrew.

ASSEMBLY - Continued

42. Install flat washer (68), mechanical felt (69), and flat washer (70).



43. Install new lock wire (71) (item 21, WP 0152 00).

NOTE


Perform steps 44 and 45, and continue with step 47, if new worm shaft assembly has been installed. Perform step 46 if previously-installed components are used.

44. Install knob (72) on worm shaft assembly (64) and secure with setscrew, NSN 5305-00-655-9246. Using the pilot hole located on the knob, drill hole through worm shaft assembly.
45. Remove setscrew from knob (72).
46. Install knob (72).

CAUTION


Support knob in V block on solid surface to prevent damage to worm shaft.

47. Drive in headless straight pin (73).



1fc330


48. Install V bearing (74), helical compression spring (75), and machine thread plug (76).
49. Tighten machine thread plug (76) until V bearing (74) bottoms on worm shaft assembly (64), and then back off 1/4 turn.
50. Apply sealing compound (item 13, WP 0152 00) on setscrew (77). Wipe off excess sealing compound with a clean wiping rag (item 18, WP 0152 00). Tighten setscrew.
51. Install new lock wire (78) (item 22, WP 0152 00) in machine thread plug (76).




1fc331

52. Apply sealing compound (item 13, WP 0152 00) to threads of six machine screws (79).
53. Install six new lockwashers (80) (item 10, WP 0118 00) and six machine screws (79).
54. Install new lock wire (81) (item 22, WP 0152 00).

ASSEMBLY - Continued




55. Install retaining ring (82), protection bellows (83), and retaining ring (84).
56. Apply sealing compound (item 13, WP 0152 00) to threads of six machine screws (85).
57. Install six new lockwashers (86) (item 10, WP 0118 00) and six machine screws (85).
58. Install new lock wire (87) (item 22, WP 0152 00).



59. Install optical instrument support (88) on bearing housing assembly (6).
60. Apply sealing compound (item 13, WP 0152 00) to setscrew (89) and install to align optical instrument support (88) (M171A1 only).
61. If removed or missing, install straight pin (90) (M171A1 only).
62. Align plain tapered pin(s) (91) on pin holes and drive in.

63. Apply sealing compound (item 13, WP 0152 00) to threads of hexagon capscrew (92) (M171 only).
64. Install new lockwasher (93) (item 5, WP 0118 00) and hexagon capscrew (92) and tighten (M171 only).



65. Install new lock wire (94) (item 22, WP 0152 00) (M171 only).

END OF WORK PACKAGE

GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**OPTICAL INSTRUMENT SUPPORT MAINTENANCE
REMOVAL, REPAIR OR REPLACEMENT, INSTALLATION**

INITIAL SETUP:

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

- Lockwasher (item 5, WP 0118 00)
- Lock wire (item 22, WP 0152 00)
- Sealing compound (item 13, WP 0152 00)

References

WP 0121 00

Equipment Conditions

M171/M171A1 mount removed from M198/M777 howitzer (TM 9-1025-211-34/TM 9-1025-215-25&P)

REMOVAL

WARNING

RADIATION




**TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.


WARNING



When maintaining battery illuminated fire control equipment follow battery warnings in warning summary.

REMOVAL - Continued

1. Remove and discard lock wire (1) (M171 only).




2. Remove hexagon capscrew (2) and lockwasher (3). Discard lockwasher (M171 only).
3. Remove setscrew (4) (M171A1 only).
4. If damaged, remove straight pin (5) (M171A1 only).
5. Drive out plain tapered pin (6) (M171 only).
6. Drive out two plain tapered pins (6) (M171A1 only).
7. Remove optical instrument support (7) from bearing housing assembly (8).

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0121 00.

INSTALLATION



1. Place optical instrument support (1) on bearing housing assembly (2).
2. Align hole (3) in optical instrument support (1) with hole (4) in bearing housing assembly (2).
3. Install plain tapered pin (5) (M171 only).
4. Install two plain tapered pins (5) (M171A1 only).

WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

5. Apply sealing compound (item 13, WP 0152 00) to threads of setscrew (6) (M171A1 only).
6. Install setscrew (6) to align optical instrument support (1) (M171A1 only).
7. If removed or missing, install straight pin (7) (M171A1 only).
8. Apply sealing compound (item 13, WP 0152 00) to threads of hexagon cap screw (8) (M171 only).
9. Install new lockwasher (9) (item 5, WP 0118 00) and hexagon cap screw (8) and tighten (M171 only).
10. Install new lock wire (10) (item 22, WP 0152 00) (M171 only).

END OF WORK PACKAGE

GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**OPTICAL INSTRUMENT ROCKER ASSEMBLY MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:

Tools and Special Tools

- Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
- Tool Kit, Electronic System Maintenance (SC 5180-95-B29)
- Torque adapter (item 19, WP 0149 00)

Materials/Parts

- Grease (item 15, WP 0152 00)
- Sealing compound (item 13, WP 0152 00)
- Solvent cleaning compound (item 12, WP 0152 00)
- Wiping rag (item 18, WP 0152 00)

References

- WP 0122 00

DISASSEMBLY

WARNING

RADIATION



**TRITIUM
GAS (H₃)**


When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

WARNING



When maintaining battery illuminated fire control equipment follow battery warnings in warning summary.

DISASSEMBLY - Continued




1fc338

NOTE

Scribe a line across key washer (1) and optical instrument rocker assembly (2) for reference during installation.

1. Remove two machine screws (3) and key washer (1) from optical instrument rocker assembly (2).



OLD CONFIGURATION

NEW CONFIGURATION

1fc339

2. Remove bearing seat (4), plain bearing (5), and bearing seat (6) from optical instrument rocker (7).

NOTE

Replace optical instrument rocker if it has been damaged to the extent that it can no longer perform its intended function.


CLEANING**WARNING**

Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.

Clean all parts with cleaning compound (item 12, WP 0152 00).

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0122 00.


ASSEMBLY**OLD CONFIGURATION****NEW CONFIGURATION**

1fc340

NOTE

The old configuration bearing parts can be cleaned and repacked but, if replacement is necessary, bearing parts will be replaced with new configuration items.

1. Apply light coat of grease (item 15, WP 0152 00) to bearing seat (1) and plain bearing (2). Install bearing seat and plain bearing in optical instrument rocker (3).
2. Apply light coat of grease (item 15, WP 0152 00) to bearing seat (4).
3. Install bearing seat (4) and tighten. Torque to 16 to 18 in.-lb (1.80 to 2.03 N-m) for M171 mount or 150 in.-lb (17.06 N-m) for M171A1 mount using torque adapter.

ASSEMBLY - Continued

4. Position key washer (5) on optical instrument rocker (3).
5. Align reference line on key washer (5) with reference line on optical instrument rocker assembly (3).

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

6. Apply sealing compound (item 13, WP 0152 00) to two machine screws (6). Wipe off excess sealing compound with a clean wiping rag. Install machine screws.
7. Bend tang (7) to fit notch in bearing seat (4).

END OF WORK PACKAGE

GENERAL SUPPORT**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)****OPTICAL INSTRUMENT ROCKER MAINTENANCE
DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

References


WP 0122 00
WP 0123 00

Equipment Conditions

M171/M171A1 mount removed from M198/M777 howitzer (TM 9-1025-211-34/TM 9-1025-215-25&P)
Cross level knob and worm shaft assembly removed (WP 0065 00)

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

DISASSEMBLY - Continued

Remove two headless straight pins (1) from rocker (2).

NOTE

Replace entire optical instrument rocker if damaged, causing the cross level control to be erratic or rough during movement.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0122 00 and WP 0123 00.

ASSEMBLY

Install two headless straight pins (1) in rocker (2).

END OF WORK PACKAGE

GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**WORM SHAFT ASSEMBLY MAINTENANCE
REMOVAL, CLEANING, REPAIR OR REPLACEMENT, INSTALLATION**

INITIAL SETUP:

Tools and Special Tools

- Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
- Tool Kit, Electronic System Maintenance (SC 5180-95-B29)
- Torque wrench adapter (item 18, WP 0149 00)

Materials/Parts

- Grease (item 15, WP 0152 00)
- Lock wire (item 21, WP 0152 00)
- Sealing compound (item 13, WP 0152 00)
- Solvent cleaning compound (item 12, WP 0152 00)
- Wiping rag (item 18, WP 0152 00)

References

- WP 0123 00

Equipment Conditions

- M171/M171A1 mount removed from M198/M777 howitzer (TM 9-1025-211-34/TM 9-1025-215-25&P)

REMOVAL

WARNING

RADIATION



**TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

WARNING




When maintaining battery illuminated fire control equipment follow battery warnings in warning summary.


NOTE

The following procedures are applicable to both the elevating and cross level worm shafts.


REMOVAL - Continued



1. Remove and discard lock wire (1) from machine thread plug (2).



2. Loosen setscrew (3).
3. Remove machine thread plug (2), helical compression spring (4), and V bearing (5).




CAUTION

Support cross level knob in V block on solid surface to prevent damage to worm shaft.


4. Drive headless straight pin (6) out.

5. Remove knob (7).
6. Remove and discard lock wire (8).




1fc346

7. Remove flat washer (9), mechanical felt (10), and flat washer (11).



1fc347

8. Loosen setscrew (12).
9. Unscrew and remove externally threaded ring (13).

REMOVAL - Continued

10. Partially remove worm shaft assembly (14).
11. Remove plain bearing (15).
12. Remove worm shaft assembly (14).

NOTE

Replace entire worm shaft assembly if knob has excessive backlash or rough movement caused by damaged worm shaft assembly.

CLEANING**WARNING**


Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.

Clean all parts with cleaning compound (item 12, WP 0152 00).


REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0123 00.


INSTALLATION



1. Apply light coat of grease (item 15, WP 0152 00) on plain bearing (1) and install on worm shaft assembly (2).




2. Apply light coat of grease (item 15, WP 0152 00) on worm shaft assembly (2) and install in optical instrument rocker assembly (3).
3. Align slot in plain bearing (1) with guide pin in optical instrument rocker assembly (3).




4. Install externally threaded ring (4) and tighten until worm shaft assembly (2) rotates with a drag.


INSTALLATION - Continued



5. Tighten setscrew (5).



6. Install flat washer (6), mechanical felt (7), and flat washer (8) in order.



NOTE

Perform steps 7 and 8, and continue with step 10, if new worm shaft assembly has been installed. Perform step 9 if previously-installed components are used.


7. Install knob (9) on worm shaft assembly (2) and secure with setscrew, NSN 5305-00-655-9246. Using the pilot hole located on the knob, drill hole through worm shaft assembly.

8. Remove setscrew from knob (9).
9. Install knob (9).

CAUTION

Support knob in V block on solid surface to prevent damage to worm shaft.


10. Install headless straight pin (10).



NOTE


After replacement of V bearing (11) and helical compression spring (12), screw machine thread plug (13) until V bearing bottoms on worm shaft assembly, and then back off 1/4 turn.

11. Apply light coat of grease (item 15, WP 0152 00) on V bearing (11) and install.
12. Install helical compression spring (12) and machine thread plug (13).
13. Tighten setscrew (14).




14. Rotate knob (9) and worm shaft assembly (2) through full travel of gear. Check for binding.

INSTALLATION - Continued



1fc357

15. Install torque wrench adapter (15) on knob (9).
16. Attach torque wrench (16) to torque wrench adapter (15).



1fc358

17. Measure torque. If torque does not read between 4 in.-lb (0.45 N-m) and 12 in.-lb (1.35 N-m), loosen two setscrews (14 and 5). Tighten or loosen externally threaded ring (4) or machine thread plug (13).

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

18. Apply sealing compound (item 13, WP 0152 00) to two setscrews (14 and 5). Wipe off excess sealing compound with a clean wiping rag (item 18, WP 0152 00). Tighten setscrews.
19. Install new lock wires (17 and 18) (item 21, WP 0152 00).

END OF WORK PACKAGE

GENERAL SUPPORT**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)****HOUSING ASSEMBLY MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)
Torque wrench adapter (item 18, WP 0149 00)

Materials/Parts

Grease (item 15, WP 0152 00)
Grease (item 16, WP 0152 00)
Lockwasher (2) (item 21, WP 0123 00)
Lockwasher (5) (item 24, WP 0123 00)
Lockwasher (8) (item 27, WP 0123 00)
Lock wire (item 21, WP 0152 00)
Lock wire (item 22, WP 0152 00)
Preformed mechanical felt (item 14, WP 0123 00)
Preformed mechanical felt (4) (item 29, WP 0123 00)
Sealing compound (item 13, WP 0152 00)
Solvent cleaning compound (item 12, WP 0152 00)
Wiping rag (item 18, WP 0152 00)


References

WP 0065 00
WP 0123 00


Equipment Conditions

M171/M171A1 mount removed from M198/M777 howitzer (TM 9-1025-211-34/TM 9-1025-215-25&P)
Optical instrument support removed (WP 0065 00)
Optical instrument rocker assembly removed (WP 0065 00)
Retaining plates, access cover, gasket, and pawl removed (WP 0065 00)


DISASSEMBLY




1. Remove and discard lock wire (1).
2. Remove five socket head capscrews (2) and five lockwashers (3). Discard lockwashers.




3. Bend tang (4) of key washer (5) from groove of round plain nut (6).
4. Unscrew and remove round plain nut (6).




5. Remove key washer (5) and flat washer (7).
6. Drive out camshaft (8) and remove.



7. Remove sector gear cluster (9) from worm wheel housing (10).




8. Remove two headless straight pins (11) and headless straight pin (12) from sector gear cluster (9).




9. Remove and discard lock wire (13).


DISASSEMBLY - Continued




10. Remove two socket cap screws (14) and two lock washers (15) from worm wheel housing (10). Discard lockwashers.
11. Remove rotating eye bracket (16) and plunger assembly (17).
12. Remove two headless straight pins (18).




13. Remove and discard two lock wires (19).
14. Remove four socket head cap screws (20) and four lock washers (21). Discard lockwashers.
15. Remove two mechanical felt holders (22) and two preformed mechanical felts (23). Discard preformed mechanical felts.



16. Remove two machine screws (24) only if damaged or loose.




17. Remove and discard two lock wires (25).
18. Remove four socket head capscrews (26) and four lockwashers (27). Discard lockwashers.
19. Remove two mechanical felt holders (28) and two preformed mechanical felts (29). Discard preformed mechanical felts.




20. Remove two machine screws (30) only if damaged or loose.


DISASSEMBLY - Continued




21. Remove and discard lock wire (31) from machine thread plug (32).



22. Loosen setscrew (33).




23. Remove machine thread plug (32), compression helical spring (34), and V bearing (35).



CAUTION


Support elevation knob in V block on solid surface to prevent damage to worm shaft.

24. Drive headless straight pin (36) out.




25. Remove knob (37).
 26. Remove and discard lock wire (38).

DISASSEMBLY - Continued




1fc375

27. Remove flat washer (39), preformed mechanical felt (40), and flat washer (41). Discard preformed mechanical felt.



1fc376


28. Loosen setscrew (42).
29. Remove externally threaded ring (43).



1fc377

30. Partially remove worm shaft assembly (44) from worm wheel housing (10).

31. Remove plain bearing (45) from worm shaft assembly (44).



32. Remove worm shaft assembly (44).

CLEANING

WARNING



Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.

Clean all parts with cleaning compound (item 12, WP 0152 00).


REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0123 00.

ASSEMBLY

NOTE

Apply light coat of grease (item 15, WP 0152 00) on all machined surfaces and preformed mechanical felts.




WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.


1. Apply sealing compound (item 13, WP 0152 00) to two machine screws (1). Wipe off excess sealing compound with a clean wiping rag. Install and tighten machine screws.



NOTE


Two preformed mechanical felts and two mechanical felt holders must be installed in exact alignment with end of gear sector (elevation).

2. Position two new preformed mechanical felts (2) (item 29, WP 0123 00) and two mechanical felt holders (3) on end of gear sector (elevation) (4).
3. Apply sealing compound (item 13, WP 0152 00) to threads of four socket head capscrews (5).
4. Install four new lockwashers (6) (item 27, WP 0123 00) and four socket head capscrews (5). Tighten socket head capscrews.
5. Install two new lock wires (7) (item 21, WP 0152 00).



6. Apply sealing compound (item 13, WP 0152 00) to two machine screws (8). Wipe off excess sealing compound with a clean wiping rag (item 18, WP 0152 00). Install and tighten machine screws.

ASSEMBLY - Continued




1fc383

NOTE


Two preformed mechanical felts and two mechanical felt holders must be installed in exact alignment with the end of gear sector (cant).

7. Position two new preformed mechanical felts (9) (item 29, WP 0123 00) and two mechanical felt holders (10) on end of gear sector (cant) (11).
8. Apply sealing compound (item 13, WP 0152 00) to threads of four socket head cap screws (12).
9. Install four new lockwashers (13) (item 27, WP 0123 00) and four socket head cap screws (12). Tighten socket head cap screws.
10. Install two new lock wires (14) (item 21, WP 0152 00).




1fc384

11. Install two headless straight pins (15).
12. Position plunger assembly (16) and rotating eye bracket (17) over two headless straight pins (15) on worm wheel housing (18).




13. Apply sealing compound (item 13, WP 0152 00) to threads of two socket cap screws (19).
14. Install two new lockwashers (20) (item 21, WP 0123 00) and two socket cap screws (19). Tighten socket cap screws.
15. Install new lock wire (21) (item 22, WP 0152 00).




16. Install headless straight pin (22) and two headless straight pins (23) in sector gear cluster (24).


ASSEMBLY - Continued




17. Position sector gear cluster (24) on worm wheel housing (18).



18. Apply light coat of grease (item 15, WP 0152 00) to camshaft (25) and install.
19. Install flat washer (26) and key washer (27).
20. Install plain round nut (28). Tighten to torque of 6 in.-lb (0.68 N-m) to 12 in.-lb (1.35 N-m). Bend tang on key washer (27) into groove of plain round nut.




21. Apply sealing compound (item 13, WP 0152 00) to threads of five socket head capscrews (29).
22. Install five new lockwashers (30) (item 24, WP 0123 00) and five socket head capscrews (29).
23. Install new lock wire (31) (item 22, WP 0152 00).



24. Install gasket (32). Refer to WP 0065 00.
25. Apply sealing compound (item 13, WP 0152 00) to threads of tolerance screw (33). Wipe off excess sealing compound with a clean wiping rag. Install pawl (34) and close tolerance screw. Refer to WP 0065 00.
26. Install access cover (35) and retaining plate (36). Refer to WP 0065 00.


ASSEMBLY - Continued




27. Place worm shaft assembly (37) in worm wheel housing (18).
28. Apply grease (item 15, WP 0152 00) on plain bearing (38) and install on worm shaft assembly (37).

NOTE

Make sure slot in plain bearing aligns with guide pin in worm wheel housing.




29. Install externally threaded ring (39) and tighten until worm shaft assembly (37) rotates with a drag.
30. Tighten setscrew (40).



1fc393

31. Install flat washer (41), new preformed mechanical felt (42) (item 14, WP 0123 00), and flat washer (43) in order.



1fc394

NOTE

Perform steps 32 and 33, and continue with step 35, if new worm shaft assembly has been installed. Perform step 34 if previously-installed components are used.


32. Install knob (44) on worm shaft assembly (37) and secure with setscrew, NSN 5305-00-655-9246. Using the pilot hole located on the knob, drill hole through worm shaft assembly.
33. Remove setscrew from knob (44).
34. Install knob (44).

CAUTION


Support knob in V block on solid surface to prevent damage to worm shaft.

35. Install headless straight pin (45).


ASSEMBLY - Continued




36. Apply grease (item 15, WP 0152 00) to V bearing (46) and install.



37. Install compression helical spring (47) and machine thread plug (48).
38. Screw machine thread plug (48) until V bearing (46) bottoms on worm shaft assembly, and then back off 1/4 turn.




39. Tighten setscrew (49).




40. Rotate knob (44) and worm shaft assembly (37) through full travel of gear. Check for binding.

ASSEMBLY - Continued



41. Install torque wrench adapter (50) on knob (44).
42. Attach torque wrench (51) to torque wrench adapter (50), and measure torque required to turn worm shaft assembly (37). If torque does not read between 4 in.-lb (0.45 N-m) and 12 in.-lb (1.35 N-m), loosen two setscrews (49 and 40). Tighten or loosen externally threaded ring (39) or machine thread plug (48).



43. Apply sealing compound (item 13, WP 0152 00) to two setscrews (49 and 40). Tighten setscrews.
44. Install new lock wires (52 and 53) (item 22, WP 0152 00).

END OF WORK PACKAGE

GENERAL SUPPORT

M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)PLUNGER ASSEMBLY MAINTENANCE
REMOVAL, REPAIR OR REPLACEMENT, INSTALLATION

INITIAL SETUP:

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC5180-95-B29)

Materials/Parts

Grease (item 16, WP 0152 00)
 Lockwasher (2) (item 21, WP 0123 00)
 Lock wire (item 21, WP 0152 00)
 Sealing compound (item 13, WP 0152 00)

References

WP 0123 00

Equipment Conditions

M171/M171A1 mount removed from M198/M777 howitzer (TM 9-1025-211-34/TM 9-1025-215-25&P)


REMOVAL

WARNING

RADIATION

TRITIUM
GAS (H₃)


When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.




1fc401

1. Remove and discard lock wire (1).
2. Remove two socket cap screws (2) and two lockwashers (3). Discard lockwashers.

REMOVAL - Continued



3. Pry rotating eye bracket (4) from two headless straight pins (5) and plunger stud (6).




4. Remove plunger assembly (7) from housing assembly (8).


REPAIR OR REPLACEMENT

1. Replace plunger assembly if damaged to the extent that improper tension is applied to the M171/M171A1 mount.
2. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0123 00.


INSTALLATION



1. Apply light coat of grease (item 15, WP 0152 00) to mating surfaces of plunger assembly (1) and install in housing assembly (2).



2. Install rotating eye bracket (3) on two headless straight pins (4) and plunger stud (5).



WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

3. Apply sealing compound (item 13, WP 0152 00) to threads of two socket capscrews (6).
4. Install two new lockwashers (7) (item 21, WP 0123 00) and two socket capscrews (6).
5. Install new lock wire (8) (item 21, WP 0152 00).

END OF WORK PACKAGE

GENERAL SUPPORT**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)****MOUNTING ADAPTER MAINTENANCE
REMOVAL, DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY, INSTALLATION**

INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Lock wire (item 22, WP 0152 00)

Lockwasher (4) (item 2, WP 0124 00)

Lockwasher (2) (item 3, WP 0125 00)


References

WP 0124 00


WP 0125 00

REMOVAL**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

REMOVAL - Continued

1. Remove and discard lock wire (1).
2. Remove four socket cap screws (2) and four lockwashers (3). Discard lockwashers.
3. Lift mounting adapter (4) clear of two straight pins (5), and remove.
4. Remove two straight pins (5).


DISASSEMBLY

Remove two socket cap screws (1), two lockwashers (2), and two machine keys (3) from adapter (4). Discard lockwashers.

REPAIR OR REPLACEMENT**NOTE**


Replace adapter if bent or otherwise damaged causing M17 quadrant to mount incorrectly.

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0124 00 and WP 0125 00.

ASSEMBLY**WARNING**

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

1. Apply sealing compound (item 13, WP 0152 00) to two socket capscrews (1).
2. Position two machine keys (2) on adapter (3) and secure using two new lockwashers (4) (item 3, WP 0125 00) and two socket capscrews (1).

INSTALLATION

1. Install two straight pins (1).

NOTE

Ensure mounting adapter is positioned with flat side on top.

2. Install mounting adapter (2) on bearing housing assembly (3) over two straight pins (1).
3. Apply sealing compound (item 13, WP 0152 00) to four socket cap screws (4).
4. Install four new lockwashers (5) (item 2, WP 0124 00) and four socket cap screws (4) and tighten.
5. Install new lock wire (6) (item 22, WP 0152 00).

END OF WORK PACKAGE

CHAPTER 16

GENERAL SUPPORT
FINAL INSPECTION INSTRUCTIONS
FOR
M171/M171A1 TELESCOPE AND QUADRANT MOUNT

GENERAL SUPPORT**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)****FINAL INSPECTION INSTRUCTIONS
TEST AND INSPECTION**

INITIAL SETUP:**Test Equipment**

Cross-leveling fixture (item 8, WP 0149 00)
Fire control quadrant (item 10, WP 0149 00)
Inspection fixture (item 11, WP 0149 00)
Mechanical adapter (item 4, WP 0149 00)
Sighting device (item 6, WP 0149 00)
Spring resiliency tester (item 9, WP 0149 00)
Torque adapter (item 19, WP 0149 00)

Tools and Special Tools

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Artillery and Turret Mechanic's: Ordnance (SC 5180-95-A12)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Sealing compound (item 13, WP 0152 00)

References

WP 0021 00
WP 0022 00

Special Environmental Conditions

Ambient temperature +60 °F (+16 °C) to +90 °F (+32 °C)

TEST AND INSPECTION**WARNING****RADIATION****TRITIUM
GAS (H₃)**


When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

TEST AND INSPECTION - Continued**NOTE**


If the M171/M171A1 mount being inspected fails to meet the required standards, ensure all maintenance authorized at the applicable level has been performed correctly. Then send the M171/M171A1 mount to the next level of maintenance.

For testing of M171A1 mount, a M198 damper must be installed.


For testing of M171A1 mount, sighting device (item 6, WP 0149 00) must have four quick release pins (item 5A, WP 0133 00) installed.

Setting Up and Adjusting the Cross-Leveling Fixture

1. Secure cross-leveling fixture (1) on test bench.




2. Install test fixture adapter (2) on cross-leveling shaft end (3).




3. Tighten setscrew (4). Test fixture adapter face should be approximately 11/16 in. (1.75 cm) from block (5).

NOTE

The mechanical adapter (P/N 10555619) illustrated below is for use with the M198 howitzer.




4. Assemble four screws (6), block (5), and two pins (7) on adapter plate (8).



5. Place adapter plate (8) on cant position of cross-leveling fixture (1).
6. Lightly clamp adapter plate (8).


TEST AND INSPECTION - Continued

Setting Up and Adjusting the Cross-Leveling Fixture - Continued



1fc414

7. Install four lockwashers (9), four screws (10), four posts (11), and two plates (12) on adapter plate (8). Tighten screws.




1fc415

8. Place precision level (13) on block (14), perpendicular to axis of rotation.
9. Level the cross-leveling fixture (1) in both cant and elevation.

NOTE


When installing test fixture adapter (2), ensure adapter keys (15) are parallel to top of block within 0.1 mil.




10. Place precision level (13) on adapter keys (15).
11. Check that bubble (16) precision level (13) is level.
12. Tighten test fixture adapter (2) securely and recheck for level.

NOTE

Ensure that adapter keys (15) and block (14) are parallel within 0.1 mil while performing steps 13 through 17.




13. Secure alignment tool (17) to test fixture adapter (2) with four screws (18).


TEST AND INSPECTION - Continued**Setting Up and Adjusting the Cross-Leveling Fixture - Continued****NOTE**

It may be necessary to shim adapter plate (8) for proper alignment of pin (19).


14. Align block assembly (20) with alignment tool (17) so that pin (19) will guide fit through both bores (21) without binding.
15. Secure adapter plate (8) in position.
16. Recheck pin alignment.
17. Remove alignment tool (17).




18. Set cant vernier scale (22) and elevation vernier scale (23) to zero.



19. Place collimator telescope (24) in V portion (25) of test fixture adapter (2).




20. Position plumbline (26) approximately 10 feet (3.0 m) from collimator telescope.
21. Check that plumbline (26) is in view of the collimator telescope line of sight.



22. Rotate elevation handwheel (27) and observe parallel between optical axis of collimator telescope and plumbline.
23. If optical axis is not parallel with plumbline, adjust using shims (28).

TEST AND INSPECTION - Continued


Setting Up and Adjusting the Cross-Leveling Fixture - Continued




24. Reset cant vernier scale (22) to zero, if necessary.
25. Return elevation vernier scale (23) to zero elevation, if necessary.

NOTE


Check to make sure that cross-leveling fixture is still level in elevation and cant.



26. Assemble inspection aid support assembly (29) to elevation shaft (30) on the elevation vernier scale side of the cross-leveling fixture (1). Set fire control quadrant (31) on inspection aid support assembly, set at zero, and level inspection aid support assembly in elevation.




27. Place leveling bar (32) on seat of inspection aid support assembly (29).



28. Place leveling bar (33) across leveling bar (32).
29. Level inspection aid support assembly (29) in cant using leveling bars (32 and 33) and fire control quadrant (31).
30. Center level bubble (34) in inspection aid support assembly (29) by rotating eccentric (35), if not already centered.
31. Rotate elevation handwheel until elevation vernier scale reads 60 degrees or 1066 mils. Check that level bubble (34) in inspection aid support assembly (29) stays centered.
32. Repeat steps 30 and 31, checking that level bubble (34) in inspection aid support assembly (29) stays centered at 0 and 1066 mils elevation. If necessary, adjust eccentric (35).

TEST AND INSPECTION - Continued


Setting Up and Adjusting the Cross-Leveling Fixture - Continued



33. Return cross-leveling fixture (1) to zero elevation and securely tighten inspection aid support assembly (29) to elevation shaft (30).
34. Turn knob (36) on inspection aid support assembly (29) to either limit stop; back off approximately 7-3/4 turns. Level bubble (34) of inspection aid support assembly should be in approximate center of level vial.
35. Ensure all mounting surfaces are level and adjusted correctly by visually inspecting mount mating surfaces.


Visual Inspection

1. Check that all screws and lockwashers are present and tight.
2. Check that lock wire is secure.




3. Check that mounting surface (1) for M17/M17A1 quadrant mounting surface, (2) for M137/M137A2/M137A3 telescope, and mounting surface (3) for M171/M171A1 mount are clean and free of nicks and burrs.
4. Check mirrors (4) for clear reflection of vials.


Mounting the M171/M171A1 Mount on Cross-Leveling Fixture




1. Position M171/M171A1 mount (1) on adapter keys (2) of test fixture adapter (3).




2. Install four hexagon capscrews (4) and pin (5).




3. Fasten adapter plate (6) to optical instrument support (7).

TEST AND INSPECTION - Continued**Mounting the M171/M171A1 Mount on Cross-Leveling Fixture - Continued**


4. Place precision level (8) parallel to block (9).



5. Rotate cant handwheel (10) until bubble (11) in precision level (8) centers.




6. Place precision level (8) perpendicular to block (9) of shaft on cross-leveling fixture (12).




7. Rotate elevation handwheel (13) until bubble (11) in precision level (8) centers.

TEST AND INSPECTION - Continued**Mounting the M171/M171A1 Mount on Cross-Leveling Fixture - Continued****NOTE**


If new elevation or cross level vials were installed, do not perform steps 8 and 9. Instead, proceed to step 10.



8. Turn elevation knob (14) until bubble in elevation level vial (15) centers.



9. Turn cross level knob (16) until bubble in cross level vial (17) centers.




10. Set fire control quadrant (18) at zero mils plus correction factor, if any, and place on adapter plate (6).

NOTE

Fire control quadrant line of fire arrow should be toward cant vernier scale for pitch level check and toward elevation vernier scale for cross level check.

11. Level bubble (19) in fire control quadrant (18) should center in both cant and elevation. If not, center level bubble using either the elevation knob or cross level knob as required.




12. If bubble in elevation level vial (15) and bubble in cross level vial (17) do not center, adjust by performing the following steps.

TEST AND INSPECTION - Continued


Mounting the M171/M171A1 Mount on Cross-Leveling Fixture - Continued

NOTE


The procedures for adjustment of the cross level vial and elevation level vial are the same.



- 13. Remove sealing compound from the end of elevation level vial (15).



- 14. Loosen setscrew (20).




- 15. Remove externally threaded ring (21) using a spanner wrench and remove eccentric (22).


WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

16. Place a dab of sealing compound (item 13, WP 0152 00) on slotted end of eccentric (22) and to threads of externally threaded ring (21).
17. Reinstall eccentric (22) and externally threaded ring (21) and turn eccentric until bubble in elevation level vial (15) centers.
18. Tighten externally threaded ring (21).
19. Ensure bubble in elevation level vial (15) is centered.




20. Apply sealing compound (item 13, WP 0152 00) to setscrew (20). Tighten setscrew.



21. Apply sealing compound (item 13, WP 0152 00) to outside of externally threaded ring (21) and to end of elevation level vial (15).

TEST AND INSPECTION - Continued


Elevation Travel and Travel Deviation Inspection




1. Set fire control quadrant (1) to 1333 mils for elevation check, and place on inspection aid support assembly (2). Turn elevation handwheel (3) clockwise until level bubble (4) in fire control quadrant centers.
2. Set fire control quadrant (1) to 270 mils for depression and place on inspection aid support assembly (2). Turn elevation handwheel (3) counterclockwise until level bubble (4) in fire control quadrant centers.

NOTE

If level bubble in fire control quadrant does not center in either step 1 or 2, the M171/M171A1 mount does not have sufficient travel. Return to depot maintenance.



- Set fire control quadrant (1) to zero and place on inspection aid support assembly (2). Turn elevation handwheel (3) clockwise until level bubble (4) in fire control quadrant centers.




NOTE: Mil size = $\frac{\text{Target distance (inches)}}{1000}$

1fc447

- Use any suitable material to locally fabricate targets (5 and 6).

NOTE

Target and plumbline should be positioned at a minimum of 40 feet (12.2 m) from cross-leveling fixture and aligned to M137A2/M137A3 telescope set at 4800 mils. The line of sight of the M137A2/M137A3 telescope will be across the elevation vernier scale of cross-leveling fixture.




1fc448

- Secure M137A2/M137A3 telescope (7) to optical instrument support (8).
- Ensure cross-leveling fixture and M171/M171A1 mount are cross leveled.
- Turn azimuth knob (9) clockwise to 4800 mils. Align plumbline and target to the M137A2/M137A3 telescope reticle.

TEST AND INSPECTION - Continued**Elevation Travel and Travel Deviation Inspection - Continued****NOTE**

If testing M171A1 mount, four quick release pins (item 5A, WP 0133 00) must be installed on M137 panoramic telescope used for testing.

To ensure accuracy of travel deviation inspection, two maintenance personnel may be required.




8. Rotate elevation handwheel (3) from 270 mils depression through 800 mils elevation (line of sight must not deviate more than 0.25 mil); rotate from 801 mils elevation through 1333 mils elevation (line of sight must not deviate more than 0.50 mil).


NOTE

Use fire control quadrant on adapter plate to ensure that optical instrument support is parallel and perpendicular to mounting surface of M171/M171A1 mount within 0.5 mil.

If deviation exceeds 0.25 mil from -270 to 800 mils or 0.50 mil from 801 to 1333 mils, the M137/M137A2/M137A3 telescope reticle line must be brought in coincidence with center line of wall target. To accomplish this, perform the following steps.




9. Rotate cross level knob (10) clockwise and stop when coincidence is obtained.




10. Return cross-leveling fixture (11) to zero elevation.
11. Re-center bubble in cross level vial (12). Refer to Mounting the M171/M171A1 Mount on Cross-Leveling Fixture, steps 13 through 20.
12. Sight on target and repeat step 8 above until deviation is less than 0.25 mil for -270 to 800 mils elevation and 0.50 mil for 801 through 1333 mils elevation. If either deviation cannot be eliminated, the M171/M171A1 mount is defective. Return M171/M171A1 mount to depot maintenance.

TEST AND INSPECTION - Continued


Cant Travel Inspection




1. Mount adapter plate (1) on optical instrument support (2).



2. Center bubble in cross level vial (3) and bubble in elevation level vial (4).




3. Set fire control quadrant (5) to 178 mils and place on adapter plate (1).



4. Turn cross level knob (6) until level bubble (7) in fire control quadrant (5) centers. If bubble does not center, M171/M171A1 mount is defective.
5. Reverse fire control quadrant (5).
6. Turn cross level knob (6) until level bubble (7) in fire control quadrant (5) centers. If level bubble does not center, M171/M171A1 mount is defective.


Cant Backlash Inspection




1. Fasten adapter plate (1) to optical instrument support (2).

TEST AND INSPECTION - Continued**Cant Backlash Inspection - Continued****NOTE**

When centering cross level vial and elevation level vial, final movement of cross level knob and elevation knob should be a clockwise motion.




2. Center bubble in cross level vial (3) and bubble in elevation level vial (4) using cross level knob (5) and elevation knob (6).



3. Set fire control quadrant (7) to zero, and place on adapter plate (1).
4. Check that level bubble (8) in fire control quadrant (7) is centered.
5. If level bubble (8) in fire control quadrant (7) is not centered, use micrometer knob (9) to center.
6. Record reading of micrometer (10).

NOTE


While performing backlash check, a C-clamp and pointer may be used instead of a scribed line on cross level knob.



7. Scribe one line across both cross level knob (5) and optical instrument rocker assembly (11).

NOTE


Do not go past the scribed line when turning cross level knob counterclockwise.
Ensure scribed lines are in perfect alignment.



8. Turn cross level knob (5) at least 1/2 turn clockwise.
9. Turn cross level knob (5) counterclockwise until scribed lines are aligned.

TEST AND INSPECTION - Continued

Cant Backlash Inspection - Continued




10. With scribed lines aligned, recenter level bubble (8) in fire control quadrant (7) if necessary, using micrometer knob (9).
11. Record reading of micrometer (10).
12. Compare reading with reading recorded in step 6.
13. If readings differ over 1.5 mils, backlash is excessive. Refer to WP 0022 00 for troubleshooting. If backlash is still excessive, return to depot maintenance.


Pitch Level Backlash Inspection

NOTE

Final movement of cross level knob and elevation knob should be a clockwise motion when centering cross level vial and elevation level vial.




- Center bubble in elevation level vial (1) and bubble in cross level vial (2) using cross level knob (3) and elevation knob (4).



- Set fire control quadrant (5) at zero, and place on adapter plate (6).
- Level bubble (7) in fire control quadrant (5) should be centered. If level bubble is not centered, use micrometer knob (8) to center.
- Record reading on micrometer (9).

NOTE


A C-clamp and pointer may be used instead of a scribed line on elevation knob while performing backlash check.




- Scribe one line across both elevation knob (4) and housing assembly (10).

TEST AND INSPECTION - Continued**Pitch Level Backlash Inspection - Continued****NOTE**

Do not go past scribed line when turning elevation knob counterclockwise. Ensure scribed lines are in perfect alignment.




6. Turn elevation knob (4) at least 1/2 turn clockwise.
7. Turn elevation knob (4) counterclockwise until scribed lines are aligned.




8. With scribed lines aligned, re-center level bubble (7) in fire control quadrant (5) if necessary using micrometer knob (8).
9. Record reading of micrometer (9).
10. Compare reading with reading recorded in step 4.
11. If readings differ over 1.5 mils, backlash is excessive. Refer to WP 0021 00 for troubleshooting. If backlash is still excessive, return to depot maintenance.

Pitch Level and Plumb Travel Inspection




1. Mount adapter plate (1) on optical instrument support (2).




2. Center bubble in cross level vial (3) and bubble in elevation level vial (4), using elevation knob (5) and cross level knob (6).

TEST AND INSPECTION - Continued


Pitch Level and Plumb Travel Inspection - Continued



3. Set fire control quadrant (7) to 178 mils and place on adapter plate (1).
4. Turn elevation knob (5) until level bubble (8) in fire control quadrant (7) centers. If level bubble does not center, M171/M171A1 mount is defective.
5. Reverse fire control quadrant (7).
6. Turn elevation knob (5) until level bubble (8) in fire control quadrant (7) centers. If level bubble does not center, M171/M171A1 mount is defective.




7. Secure M137/M137A2/M137A3 telescope (9) to optical instrument support (2).
8. Level cross-leveling fixture (10) and re-center the bubble in cross level vial and bubble in elevation level vial. Refer to Mounting the M171/M171A1 Mount on Cross-Leveling Fixture, steps 13 through 20.
9. Rotate azimuth knob (11) clockwise to 0000 mils. Align plumbline to M137/M137A2/M137A3 telescope reticle.



10. Turn elevation knob (5) clockwise until it stops.
11. Turn elevation knob (5) counterclockwise until it stops.
12. Line of sight on M171/M171A1 mount (12) must not deviate over 0.5 mil (total spread). If deviation is in excess of 0.5 mil, return to depot maintenance.

TEST AND INSPECTION - Continued


Mount Rigidity Inspection




1. Set fire control quadrant (1) to zero mil.
2. Place fire control quadrant (1) on inspection aid support assembly (2) and turn elevation handwheel (3) until level bubble (4) in fire control quadrant centers.

NOTE


Cross-leveling fixture should be re-leveled in elevation and cant before checking zero setting on elevation vernier scale.



3. Center bubble in cross level vial (5) and bubble in elevation level vial (6).



4. Rotate azimuth knob (7) clockwise to 4800 mils on azimuth counter (8). Align target to reticle line.



5. While sighting optical instrument support (9) on target, use push-pull gage (10), and apply 20-lb (9.07 kg) load on right side, 2.3 in. (5.84 cm) from center of optical instrument support.
6. Release load and record amount of movement.
7. Place push-pull gage (10) on left side of optical instrument support (9), and apply 20-lb (9.07 kg) load, 2.3 in. (5.84 cm) from center of optical instrument support.
8. Release load and record amount of movement.
9. Total of steps 6 and 8 must not exceed total movement listed in Table 1.

NOTE

If movement exceeds amount allowed in Table 1, recheck M171/M171A1 mount for proper assembly. If movement still exceeds amount allowed in Table 1, return to depot maintenance.

10. Repeat steps 1 through 9 using elevations listed in Table 1.


TEST AND INSPECTION - Continued

Mount Rigidity Inspection - Continued

Table 1. Mount Rigidity Inspection—Elevation, Cant, and Total Movement Data.

Elevation (mils)	Elevation (degrees and minutes)	Cant angle (mils)	Total movement (mils)
0	0°	0	0.25
800	44° 54'	0	0.75
1100	51° 53'	0	1.75
1333	74° 59'	0	3.50

Azimuth Correction Inspection




1. Secure M137/M137A2/M137A3 telescope (1) to optical instrument support (2).
2. Level the cross-leveling fixture in elevation and cant.

NOTE

Ensure bubble in cross level vial and bubble in elevation level vial on M171/M171A1 mount are centered.

3. Set azimuth counter (3) at 4800 mils.
4. Release azimuth counter eccentric (4), align M137/M137A2/M137A3 telescope reticle line on wall target, and engage azimuth counter eccentric.




5. Set fire control quadrant (5) at 88.9 mils and place on block (6).
6. Turn cant handwheel (7) until level bubble (8) in fire control quadrant (5) centers.
7. Turn cross level knob (9) to recenter bubble in cross level (10).

NOTE

After cant is set into the cross-leveling fixture, recenter level bubble in inspection aid support assembly when elevation settings are applied.

If test fixture is not equipped with inspection aid support assembly, set vernier scale at $16^{\circ} 56'$ elevation.




8. Turn elevation handwheel (11) until fire control quadrant (5), set at 300 mils, on inspection aid support assembly (12) reads level.

TEST AND INSPECTION - Continued**Azimuth Correction Inspection - Continued****NOTE**

After each elevation setting, recenter bubble in elevation level vial.

When M137/M137A2/M137A3 telescope is aligned on target, final movement of azimuth knob should be in a clockwise direction.



9. Look through eyeshield (13) of M137 telescope (1) and align M137/M137A2/M137A3 telescope reticle line on wall target.

NOTE

The variance in readings is dependent upon which way the 88.9 mils is applied to the fixture. The 27 ± 0.3 mils would be subtracted from the 4800-mil reading.

10. Azimuth counter (3) should read 4837 ± 0.3 mils or 4773 ± 0.3 mils.
11. Repeat steps 5 through 10 using elevations, cant angles, azimuth corrections, and tolerances in Table 2.
12. Repeat steps 5 through 10, setting cant in opposite direction.

NOTE

If azimuth counter readings cannot be obtained, check to ensure proper maintenance procedures were followed when the M171/M171A1 mount was reassembled. If azimuth correction readings are still unobtainable, there is a possibility of excessively worn or bent depot parts. Return the M171/M171A1 mount to depot maintenance.


Table 2. Azimuth Correction Data.

Reference elevation (mils)	Cant angle (mils)	Azimuth correction (mils)	Tolerance (mils)
300	88.9	27.0	0.3
600	88.9	59.6	0.7
900	88.9	108.8	1.5
1200	88.9	216.8	1.8
300	177.8	54.5	0.6
600	177.8	120.3	1.0
1100	177.8	342.4	2.0


NOTE

When M171/M171A1 mount is canted 88.9 and 177.8 mils below zero, the azimuth corrections will be added to the 4800-mil azimuth counter reading. When M171/M171A1 mount is canted 88.9 and 177.8 mils above zero, the azimuth corrections will be subtracted from the 4800-mil azimuth counter reading.

Torque Inspection




1. Place torque adapter (1) on torque wrench (2).



2. Place torque wrench (2) with torque adapter (1) over cross level knob (3). Torque required for continuous movement (running torque) must be between 4 in.-lb (0.45 N-m) and 12 in.-lb (1.35 N-m).


TEST AND INSPECTION - Continued

Torque Inspection - Continued



1fc482

- Place torque wrench (2) with torque adapter (1) over elevation knob (4). Torque required for continuous movement (running torque) must be between 4 in.-lb (0.45 N-m) and 12 in.-lb (1.35 N-m).




1fc483


- If torque is not met for cross level knob (3) or elevation knob (4), loosen setscrews (5 and 6). Tighten or loosen externally threaded ring (7) or machine thread plug (8).

Illumination Inspection**WARNING**

When inspecting radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.



1. Take M171 mount (1) inside dark room and wait 15 minutes.



2. Check bubble in cross level vial (2) and bubble in elevation level vial (3) for even illumination and sufficient illumination to see bubbles and vial graduations.

END OF WORK PACKAGE

CHAPTER 17

**DIRECT SUPPORT
MAINTENANCE INSTRUCTIONS
FOR
M172/M172A1 TELESCOPE AND QUADRANT MOUNT**


DIRECT SUPPORT**M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)****SERVICE UPON RECEIPT
SERVICE UPON RECEIPT OF MATERIEL**

SERVICE UPON RECEIPT OF MATERIEL**Unpacking**

When a new or reconditioned M172/M172A1 Telescope and Quadrant Mount is received, be aware of any shipping damage to packaging materiel. Report any damage on SF 364, Report of Discrepancy (ROD), as prescribed in AR 735-11-2. Retain packaging materiel for future use.

Checking Unpacked Equipment

1. Inspect the equipment for damage incurred during shipment. If the equipment has been damaged, report the damage on SF 361, Transportation Discrepancy Report.
2. Check the equipment against the packing slip to see if the shipment is complete. Report all discrepancies in accordance with applicable service instructions (e.g., for Army instructions, see DA PAM 738-750).
3. Check to see whether the equipment has been modified.
4. Check M172/M172A1 mount (1) for bare spots, dents, scuff marks, and damaged parts. Inspect M172/M172A1 mount for cleanliness.
5. Operate cross level knob (2). Check that rotation is free and smooth without binding or rough motion.



1fc486

END OF WORK PACKAGE

DIRECT SUPPORT

**M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)**
**M172/M172A1 MOUNT MAINTENANCE
DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY**
INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Artillery and Turret Mechanic's: Ordnance (SC 5180-95-A12)

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)


Materials/Parts

Lockwashers (2) (item 2, WP 0129 00)

Sealing compound (item 13, WP 0152 00)

References


WP 0129 00

DISASSEMBLY

1. Inspect oil cup (1). If damaged, remove oil cup from M172/M172A1 mount (2).
2. Inspect identification plate (3). If damaged, remove two machine screws (4), two lockwashers (5), and identification plate from M172/M172A1 mount (2). Discard lockwashers.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0129 00.

ASSEMBLY**WARNING**

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

1. If removed, apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (1).
2. If removed, install new identification plate (2) using two new lockwashers (3) (item 2, WP 0129 00) and two machine screws (1) on M172/M172A1 mount (4).
3. If removed, install new oil cup (5) on M172/M172A1 mount (4).

END OF WORK PACKAGE

DIRECT SUPPORT

**M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)**

**ADAPTER ASSEMBLY MAINTENANCE
DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Fire control quadrant (item 10, WP 0149 00)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Grease (item 16, WP 0152 00)
Lockwasher (6) (item 2, WP 0131 00)
Lock wire (item 21, WP 0152 00)
Sealing compound (item 13, WP 0152 00)


References

TM 9-1025-211-10
TM 9-1025-215-10
WP 0131 00

Equipment Conditions

M172/M172A1 mount removed from M198/M777 howitzer (TM 9-1025-211-34/TM 9-1025-215-25&P)

DISASSEMBLY





1. Remove two socket head capscrews (1) and two lockwashers (2) from quadrant adapter (3). Discard lockwashers.
2. Remove two machine keys (4).
3. Remove and discard lock wire (5).
4. Remove two socket head capscrews (6) and two lockwashers (7) from quadrant adapter (3). Discard lockwashers.
5. Remove spline plate (8).
6. Remove two headless straight pins (9).
7. Remove and discard lock wire (10).
8. Remove two socket head capscrews (11) and two lockwashers (12) from quadrant adapter (3). Discard lockwashers.
9. Remove spline plate (13).
10. Remove eccentric stud assembly (14).
11. Remove two headless straight pins (15).

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0131 00.


ASSEMBLY



1fc492

1. Install two headless straight pins (1) in quadrant adapter (2).
2. Apply light coat of grease (item 16, WP 0152 00) to eccentric stud assembly (3) and install.
3. Install spline plate (4), two new lockwashers (5) (item 2, WP 0131 00), and two socket head capscrews (6).
4. Install new lock wire (7) (item 21, WP 0152 00).
5. Install two headless straight pins (8) in quadrant adapter (2).
6. Install spline plate (9), two new lockwashers (10) (item 2, WP 0131 00), and two socket head capscrews (11).
7. Install new lock wire (12) (item 21, WP 0152 00).

ASSEMBLY - Continued



1fc493

8. Position two machine keys (13) on quadrant adapter (2).

WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

9. Apply sealing compound (item 13, WP 0152 00) to two socket head capscrews (15).
10. Install two new lockwashers (14) (item 2, WP 0131 00) and two socket head capscrews (15) and tighten.

NOTE

To adjust eccentric stud assembly the M172/M172A1 mount and M18/M18A1 quadrant must be installed on the M198/M777 howitzer (TM 9-1025-211-10/TM 9-1025-215-10). Also, the cannon tube must be set to zero elevation and the M18/M18A1 quadrant level assembly leveled (TM 9-1025-211-10/TM 9-1025-215-10).

11. Place fire control quadrant (16) on seats (17) of M172/M172A1 mount. Fire control quadrant level bubble should center.
12. If bubble is not centered, adjust eccentric stud assembly (3).
 - a. Loosen eccentric stud assembly (3) to disengage spline plate (4).
 - b. Turn eccentric stud assembly (3) and engage spline plate (4); tighten eccentric stud assembly.
13. Repeat step 11. If fire control quadrant level bubble is still not centered, repeat step 12 above until bubble is centered.

END OF WORK PACKAGE

CHAPTER 18

**GENERAL SUPPORT
MAINTENANCE INSTRUCTIONS
FOR
M172/M172A1 TELESCOPE AND QUADRANT MOUNT**

GENERAL SUPPORT**M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)****M172/M172A1 MOUNT MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Grease (item 16, WP 0152 00)
Lockwasher (3) (item 6, WP 0128 00)
Lockwasher (6) (item 9, WP 0128 00)
Lock wire (item 21, WP 0152 00)
Mechanical felt (item 7, WP 0129 00)
Sealing compound (item 13, WP 0152 00)
Solvent cleaning compound (item 12, WP 0152 00)
Wiping rag (item 18, WP 0152 00)


References

WP 0127 00
WP 0128 00
WP 0129 00

Equipment Conditions


M172/M172A1 telescope and quadrant mount removed from M198/M777 howitzer (TM 9-1025-211-34/
TM 9-1025-215-25&P)

DISASSEMBLY



1fc494

1. Remove and discard lock wire (1).
2. Remove three socket head capscrews (2) and three lockwashers (3). Discard lockwashers.
3. Remove pin pivot (4) from quadrant support housing (5).



1fc495


4. Remove and discard lock wire (6).
5. Remove two socket head capscrews (7), two socket head capscrews (8), and four lockwashers (9) from access cover (10). Discard lockwashers.
6. Remove two socket head capscrews (11), two lockwashers (12), and access cover (10). Discard lockwashers.

7. Loosen setscrew (13).
8. Remove and discard lock wire (14).

NOTE

Scribe a line across machine thread plug and housing, and V bearing and housing for reference during reassembly.


9. Remove machine thread plug (15), compression helical spring (16), and V bearing (17) from quadrant support housing (5).



1fc496

10. Loosen setscrew (18).
11. Remove and discard lock wire (19).

DISASSEMBLY - Continued



1fc497

CAUTION

Support cross level knob in V block on solid surface to prevent damage to worm shaft.

NOTE

Scribe a line across cross level knob and worm shaft assembly for reference during reassembly.

12. Drive out headless straight pin (20).
13. Remove knob (21), flat washer (22), mechanical felt (23), and flat washer (24). Discard mechanical felt.
14. Remove externally threaded ring (25) and spherical plain bearing (26) from worm shaft assembly (27).
15. Remove worm shaft assembly (27) from quadrant support housing (5).

CLEANING**WARNING**

Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.


Clean all parts with cleaning compound (item 12, WP 0152 00). Wipe off excess cleaning compound with clean wiping rag (item 18, WP 0152 00).

REPAIR OR REPLACEMENT**NOTE**

Replace M172/M172A1 telescope and quadrant mount when damaged to the extent that the M18/M18A1 fire control quadrant will not function properly.

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0127 00, WP 0128 00, and WP 0129 00.

ASSEMBLY



1fc498

1. Apply a light coat of grease (item 16, WP 0152 00) to worm shaft assembly (1) and install in quadrant support housing (2) ensuring that slot in bearing (3) is aligned with guide pin in quadrant support housing.
2. Install spherical plain bearing (4), ensuring that slot is aligned with guide pin in quadrant support housing (2). Install externally threaded ring (5) on worm shaft assembly (1). Tighten externally threaded ring.
3. Apply a light coat of grease (item 16, WP 0152 00) to flat washer (6), new mechanical felt (7) (item 7, WP 0129 00), and flat washer (8), and install on worm shaft assembly (1).

NOTE



Perform steps 4 and 5, and continue with step 7, if new worm shaft assembly has been installed. Perform step 6 if previously-installed components are used.

4. Install knob (9) on worm shaft assembly (1) and secure with setscrew, NSN 5305-00-655-9246. Using the pilot hole located on the knob, drill hole through worm shaft assembly.
5. Remove setscrew from knob (9).
6. Align reference marks and install knob (9) on worm shaft assembly (1).

CAUTION

Support cross level knob in V block on solid surface to prevent damage to worm shaft.

7. Install headless straight pin (10).



8. Tighten setscrew (11).
9. Apply a light coat of grease (item 16, WP 0152 00) to V bearing (12). Align reference marks and install in quadrant support housing (2).

NOTE


When installing machine thread plug, ensure reference marks are aligned.

10. Install compression helical spring (13) and machine thread plug (14) in quadrant support housing (2). Tighten machine thread plug until reference marks are aligned.

NOTE

After installing V bearing and compression helical spring, screw machine thread plug in until V bearing bottoms on worm shaft assembly, and then back off machine thread plug 1/4 turn.

ASSEMBLY - Continued



1fc501

1fc502


11. Apply a light coat of grease (item 16, WP 0152 00) to sleeve of pin pivot (15).

WARNING




Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

12. Apply a light coat of sealing compound (item 13, WP 0152 00) to mating surface of pin pivot (15).
13. Install pin pivot (15) through quadrant support housing (2) and into shaft of adapter assembly (16).
14. Apply sealing compound (item 13, WP 0152 00) to mating surfaces of access cover (17) and install on quadrant support housing (2).
15. Apply sealing compound (item 13, WP 0152 00) to threads of two socket head cap screws (18).
16. Install two new lockwashers (19) (item 9, WP 0128 00) and two socket head cap screws (18).



17. Apply sealing compound (item 13, WP 0152 00) to threads of two socket head capscrews (20) and two socket head capscrews (21).
18. Install four new lockwashers (22) (item 9, WP 0128 00), two socket head capscrews (20), and two socket head capscrews (21), making sure the two longer socket head capscrews are installed in the center of the access cover (17).
19. Install two new lock wires (23) (item 21, WP 0152 00) by bending sharp ends into tops of four socket head capscrews (20 and 21).
20. Cover heads of four socket head capscrews (20 and 21) with sealing compound (item 13, WP 0152 00).



21. Apply sealing compound (item 13, WP 0152 00) to threads of three socket head capscrews (24).
22. Install three new lockwashers (25) (item 6, WP 0128 00) and three socket capscrews (24).

ASSEMBLY - Continued

23. Install new lock wire (26) (item 21, WP 0152 00) by bending sharp ends into tops of three socket head capscrews (24).
24. Cover heads of three socket head capscrews (24) with sealing compound (item 13, WP 0152 00).

END OF WORK PACKAGE

GENERAL SUPPORT**M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)****TELESCOPE MOUNTING BRACKET MAINTENANCE
REMOVAL, REPAIR OR REPLACEMENT, INSTALLATION**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts


Grease (item 16, WP 0152 00)
Sealing compound (item 13, WP 0152 00)

References

WP 0127 00
WP 0128 00

Equipment Conditions

M172/M172A1 telescope and quadrant mount removed from M198/M777 howitzer (TM 9-1025-211-34/
TM 9-1025-215-25&P)

REMOVAL


1fc505

1. Loosen socket head capscrew (1) to relieve tension on telescope mounting bracket (2).
2. Remove four socket capscrews (3) and four flat washers (4).
3. Lift up and remove telescope mounting bracket (2) from adapter assembly (5).

REPAIR OR REPLACEMENT**NOTE**

Replace telescope mounting bracket when it will not permit the M138/M138A1 telescope to seat and operate correctly.

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0127 00 and WP 0128 00.

INSTALLATION

1. Coat mating surfaces of telescope mounting bracket (1) with a thin coat of grease (item 16, WP 0152 00).

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

2. Apply a light coat of sealing compound (item 13, WP 0152 00) to mating surface of four socket cap screws (2).
3. Install telescope mounting bracket (1) on adapter assembly (3) and secure using four flat washers (4) and four socket cap screws (2).
4. Tighten socket head cap screw (5).

END OF WORK PACKAGE

GENERAL SUPPORT

M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)ACCESS COVER MAINTENANCE
REMOVAL, REPAIR OR REPLACEMENT, INSTALLATION

INITIAL SETUP:

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Lockwasher (6) (item 9, WP 0128 00)

Lock wire (item 21, WP 0152 00)

Sealing compound (item 13, WP 0152 00)

References



WP 0127 00

WP 0128 00


Equipment Conditions

M172/M172A1 telescope and quadrant mount removed from M198/M777 howitzer (TM 9-1025-211-34/
TM 9-1025-215-25&P)

REMOVAL




1. Remove and discard lock wire (1).
2. Remove two socket head capscrews (2), two socket head capscrews (3), and four lockwashers (4) from access cover (5). Discard lockwashers.
3. Remove two socket head capscrews (6), two lockwashers (7), and access cover (5). Discard lockwashers.

REPAIR OR REPLACEMENT

1fc509

1. If damaged, remove two screw thread inserts (1) from cover (2).
2. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0127 00 and WP 0128 00.
3. If removed, install two new screw thread inserts (1) in cover (2).


INSTALLATION

1fc510

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

1. Apply sealing compound (item 13, WP 0152 00) to mating surfaces of access cover (1) and install on quadrant support housing (2).
2. Apply sealing compound (item 13, WP 0152 00) to threads of two socket head capscrews (3).
3. Install two new lockwashers (4) (item 9, WP 0128 00) and two socket head capscrews (3).



1fc511

4. Apply sealing compound (item 13, WP 0152 00) to threads of two socket head capscrews (5) and two socket head capscrews (6).
5. Install four new lockwashers (7) (item 9, WP 0128 00), two socket head capscrews (5), and two socket head capscrews (6), making sure the two longer socket head capscrews are installed in the center of the access cover (1).
6. Install two new lock wires (8) (item 21, WP 0152 00) by bending sharp ends into tops of four socket head capscrews (5 and 6).
7. Cover heads of four socket head capscrews (5 and 6) with sealing compound (item 13, WP 0152 00).

END OF WORK PACKAGE

GENERAL SUPPORT**M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)****ADAPTER ASSEMBLY MAINTENANCE
REMOVAL, DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY, INSTALLATION**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Grease (item 16, WP 0152 00)
Lockwasher (3) (item 6, WP 0128 00)
Lockwasher (5) (item 4B, WP 0128 00)
Lockwasher (6) (item 9, WP 0128 00)
Lock wire (item 21, WP 0152 00)
Mechanical felt (item 11, WP 0128 00)
Sealing compound (item 13, WP 0152 00)
Solvent cleaning compound (item 12, WP 0152 00)
Wiping rag (item 18, WP 0152 00)


References

WP 0077 00
WP 0128 00
WP 0131 00


Equipment Conditions

M172/M172A1 telescope and quadrant mount removed from M198/M777 howitzer (TM 9-1025-211-34/
TM 9-1025-215-25&P)
Worm shaft assembly removed (WP 0077 00)

REMOVAL




1fc512




1fc513

1. Remove and discard lock wire (1).
2. Remove three socket head capscrews (2) and three lockwashers (3). Discard lockwashers.
3. Remove and discard lock wire (4).
4. Remove two socket head capscrews (5), two socket head capscrews (6), and four lockwashers (7) from access cover (8). Discard lockwashers.



1fc514


5. Remove two socket head capscrews (9), two lockwashers (10), and access cover (8). Discard lockwashers.
6. Remove pin pivot (11) from quadrant support housing (12).



1fc518

7. Remove and discard lock wire (13) from five socket head capscrews (14).
8. Remove five socket head capscrews (14) and five lockwashers (15). Discard lockwashers.
9. Remove housing cover (16).

DISASSEMBLY



1fc519

1. Remove two machine screws (1) from worm wheel gear sector (2).
2. Remove mechanical felt (3) from worm wheel gear sector (2). Discard mechanical felt.

CLEANING

WARNING




Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.

Clean all parts with cleaning compound (item 12, WP 0152 00). Wipe off excess cleaning compound with clean wiping rag (item 18, WP 0152 00).

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0128 00 and WP 0131 00.

ASSEMBLY

1fc520



1. Saturate new mechanical felt (1) (item 11, WP 0128 00) with grease (item 16, WP 0152 00) and install on worm wheel gear sector (2).

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.


2. Apply a light coat of sealing compound (item 13, WP 0152 00) to two machine screws (3) and install on worm wheel gear sector (2).

INSTALLATION




1. Position housing cover (1).
2. Apply sealing compound (item 13, WP 0152 00) to threads of five socket head capscrews (2).
3. Install five new lockwashers (3) (item 4B, WP 0128 00) and five socket head capscrews (2).
4. Install new lock wire (4) (item 21, WP 0152 00).
5. Apply a light coat of grease (item 16, WP 0152 00) to sleeve of pin pivot (5).
6. Apply a light coat of sealing compound (item 13, WP 0152 00) to mating surface of pin pivot (5).
7. Install pin pivot (5) through quadrant support housing (6) and into shaft of adapter assembly (7).
8. Install worm shaft assembly (WP 0077 00).

INSTALLATION - Continued




1fc523




1fc524

9. Apply sealing compound (item 13, WP 0152 00) to mating surfaces of access cover (8) and install on quadrant support housing (6).
10. Apply sealing compound (item 13, WP 0152 00) to threads of two socket head capscrews (9).
11. Install two new lockwashers (10) (item 9, WP 0128 00) and two socket head capscrews (9).



1fc525



1fc526

12. Apply sealing compound (item 13, WP 0152 00) to threads of two socket head capscrews (11) and two socket head capscrews (12).
13. Install four new lockwashers (13) (item 9, WP 0128 00), two socket head capscrews (11), and two socket head capscrews (12), making sure the two longer socket head capscrews are installed in the center of the access cover (8).

14. Install two new lock wires (14) (item 21, WP 0152 00) by bending sharp ends into tops of four socket head capscrews (11 and 12).
15. Cover heads of four socket head capscrews (11 and 12) with sealing compound (item 13, WP 0152 00).
16. Apply sealing compound (item 13, WP 0152 00) to threads of three socket head capscrews (15).
17. Install three new lockwashers (16) (item 6, WP 0128 00) and three socket head capscrews (15).
18. Install new lock wire (17) (item 21, WP 0152 00) by bending sharp ends into tops of three socket head capscrews (15).
19. Cover heads of three socket head capscrews (15) with sealing compound (item 13, WP 0152 00).

END OF WORK PACKAGE

GENERAL SUPPORT**M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)****QUADRANT ADAPTER MAINTENANCE
REPAIR OR REPLACEMENT**

INITIAL SETUP:**Tools and Special Tools**


Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

References

WP 0131 00

Equipment Conditions

M172/M172A1 telescope and quadrant mount removed from M198/M777 howitzer (TM 9-1025-211-34/
TM 9-1025-215-25&P)

REPAIR OR REPLACEMENT

1. If damaged, remove four screw thread inserts (1) from quadrant adapter (2).
2. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0131 00.
3. If removed, install four new screw thread inserts (1) in quadrant adapter (2).

END OF WORK PACKAGE

CHAPTER 19

GENERAL SUPPORT
FINAL INSPECTION INSTRUCTIONS
FOR
M172/M172A1 TELESCOPE AND QUADRANT MOUNT

GENERAL SUPPORT**M172/M172A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-037-7290/1240-01-517-2171)****FINAL INSPECTION INSTRUCTIONS
TEST AND INSPECTION**

INITIAL SETUP:**Test Equipment**

- Fire control quadrant (item 10, WP 0149 00)
- Mechanical adapter (item 4, WP 0149 00)
- Mounting bracket (item 1, WP 0149 00)
- Optical equipment test fixture (item 8, WP 0149 00)
- Plate-mounted level (item 12, WP 0149 00)
- Torque wrench adapter (item 18, WP 0149 00)

Tools and Special Tools

- Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
- Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

- Lock wire (item 21, WP 0152 00)
- Sealing compound (item 13, WP 0152 00)

Special Environmental Conditions




- Ambient temperature +60 °F (+16 °C) to +90 °F (+32 °C)
-

TEST AND INSPECTION

NOTE

If the M172/M172A1 mount being inspected fails to meet the required standards, ensure all maintenance authorized at the applicable level has been performed correctly. Then send the M172/M172A1 mount to the next higher level of maintenance.


Setting Up and Adjusting Optical Equipment Test Fixture



1fc535


1fc536

1. Secure optical equipment test fixture (1) on solid stand bolted to floor.
2. Place plate-mounted level (2) on block (3), perpendicular to axis of rotation.
3. Level optical equipment test fixture (1) in cant and elevation.
4. Set cant vernier scale (4) and elevation vernier scale (5) to 0 for both cant and elevation.




1fc537

5. Install mechanical adapter (6) on cross-leveling shaft end (7). Ensure that adapter keys (8) are parallel with top of block (3), within 0.1 mil.
6. Tighten setscrew (9) lightly.



7. Place plate-mounted level (2) on adapter keys (8).
8. Check that bubble (10) in plate-mounted level (2) is centered.
9. Tighten setscrew (9); recheck cross level and adapter keys.
10. Rotate plate-mounted level (2) 180 degrees from original position, and check again that bubble (10) is centered.


Visual Inspection



1. Check that all screws (1) and lockwashers (2) are present and tight.
2. Ensure that all lock wires (3) are present and secure.

TEST AND INSPECTION - Continued


Visual Inspection - Continued




1fc540

3. Ensure that all mounting surfaces (4) are clean and free of nicks and burrs.
4. Check that M172/M172A1 mount (5) is free of dirt, rust, and foreign matter.
5. Check M172/M172A1 mount (5) to ensure that paint is not chipped.
6. Check M172/M172A1 mount (5) to ensure that all parts are present.

Mounting M172/M172A1 Mount on Optical Equipment Test Fixture





1fc541





1fc542

1. Position M172/M172A1 mount (1) on adapter keys (2) of mechanical adapter (3).
2. Install four hexagon cap screws (4) and tighten.




3. Position mounting bracket (5) on M172/M172A1 mount (1).
4. Install four bolts (6) to secure mounting bracket (5) to M172/M172A1 mount (1).
5. Place plate-mounted level (7) parallel to block (8) of shaft on optical equipment test fixture (9).



6. Turn cant handwheel (10) until bubble (11) in plate-mounted level (7) centers.
7. Place plate-mounted level (7) 90 degrees to block (8) on optical equipment test fixture (9).
8. Turn elevation handwheel (12) until bubble (11) in plate-mounted level (7) centers.

TEST AND INSPECTION - Continued

Cross Level Mechanism Backlash Inspection




1fc547

1. Set fire control quadrant (1) at 0.
2. Place fire control quadrant (1) on mounting bracket (2).

NOTE


When bringing M172/M172A1 mount level with fire control quadrant, rotate cross level knob in clockwise direction to center fire control quadrant level bubble. Do not overtravel when centering fire control quadrant level bubble.

3. Center level bubble (3) in fire control quadrant (1) using cross level knob (4).



1fc548

4. Scribe index line (5) on M172/M172A1 mount casting nearest to the cross level knob (4).



1fc549

NOTE


An index pointer may be made from 1/16 inch diameter rod with sharp point on end. The index pointer may be held in place mechanically by a small C-clamp (6).

5. Place index pointer (7) on the cross level knob (4) directly opposite scribed index line (5).

NOTE

Do not go past scribed index line when turning counterclockwise. Ensure scribed index line and index pointer are in perfect alignment.

6. Rotate cross level knob (4) at least 1/2 turn clockwise. Turn counterclockwise until index pointer (7) aligns with scribed line (5).



1fc550


7. Check fire control quadrant (1) to ensure that level bubble (3) is centered when index pointer is aligned with scribed index line. If not centered, use micrometer knob (7) to center.
8. Take reading from micrometer. If the reading has changed more than 1.5 mils, the backlash is excessive.

NOTE


Repeat steps 1 through 8 as necessary with readings of 150, 300, and 450 mils set on fire control quadrant. This backlash procedure will be repeated at 0, 150, 300, and 450 mils in the opposite direction of cant, performed in steps 1 through 8.

TEST AND INSPECTION - Continued

Cross Level Mechanism Travel Inspection




1fc551




1fc552

1. Place plate-mounted level (1) on block (2), perpendicular to axis of rotation.
2. Level optical equipment test fixture (3) in cant and elevation.
3. Set fire control quadrant (4) at 600 mils.





1fc553




1fc554

4. Turn cross level knob (5) until level bubble (6) in fire control quadrant (4) centers.
5. If cross level knob (5) stops before level bubble (6) in fire control quadrant (4) centers, M172/M172A1 mount is defective.
6. Reverse fire control quadrant (4).
7. Turn cross level knob (5) until level bubble (6) in fire control quadrant (4) centers.
8. If cross level knob (5) stops before level bubble (6) in fire control quadrant (4) is centered, M172/M172A1 mount is defective.
9. Set fire control quadrant (4) to zero and relevel mounting bracket (7).

Eccentric Stud Assembly Adjustment




1. Place plate-mounted level (1) parallel to block (2) on shaft of optical equipment test fixture (3).
2. Turn cant handwheel (4) until bubble (5) in plate-mounted level (1) centers.
3. Place plate-mounted level (1) 90 degrees to block (2) on optical equipment test fixture (3).
4. Turn elevation handwheel (6) until bubble (5) in plate-mounted level (1) centers.



5. Place fire control quadrant (7) on seats on M172/M172A1 mount. Level bubble (8) in fire control quadrant should center.
6. If level bubble (8) is not centered, adjust eccentric stud assembly (9).
 - a. Loosen eccentric stud assembly (9) to disengage from spline plate (10).
 - b. Turn eccentric stud assembly (9) and engage spline plate (10). Tighten eccentric stud assembly.
7. Repeat step 5. If level bubble in fire control quadrant does not center, repeat step 6 until centered.


TEST AND INSPECTION - Continued

Boresight Adjustment Inspection




Turn boresight screw (1) on bracket assembly (2) and observe shaft (3). When boresight screw is turned, shaft should also turn.

Torque Inspection




1. Place torque wrench adapter (1) on torque wrench (2).
2. Place torque wrench adapter (1) and torque wrench (2) over cross level knob (3).
3. Measure torque.
4. Torque required to start cross level knob (3) moving (starting torque) must not exceed 18 in.-lb (2.03 N-m).
5. Torque required to keep cross level knob (3) turning (running torque) must be between 4 in.-lb (0.45 N-m) and 12 in.-lb (1.35 N-m).

6. If torque requirements cannot be met, loosen two setscrews (4 and 5). Tighten or loosen externally threaded ring (6) or machine thread plug (7).



1fc561



1fc562

7. Install new lock wire (8) (item 21, WP 00 0152 00) and setscrew (4) and tighten setscrew, making sure lock wire is attached so that tension is applied if machine thread plug (7) attempts to loosen.

WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

8. Apply sealing compound (item 13, WP 00 0152 00) and tighten setscrew (4).
9. Apply sealing compound (item 13, WP 00 0152 00) to sharp ends of lock wire (8).
10. Install new lock wire (9) (item 21, WP 00 0152 00) and setscrew (5), making sure lock wire is attached so that tension is applied if externally threaded ring (6) attempts to loosen.
11. Apply sealing compound (item 13, WP 00 0152 00) and tighten setscrew (5).
12. Apply sealing compound (item 13, WP 00 0152 00) to sharp ends of lock wire (9).

END OF WORK PACKAGE

CHAPTER 20


**DIRECT SUPPORT
MAINTENANCE INSTRUCTIONS
FOR
M137/M137A2/M137A3 PANORAMIC TELESCOPE**

DIRECT SUPPORT**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)****SERVICE UPON RECEIPT
SERVICE UPON RECEIPT OF MATERIEL****SERVICE UPON RECEIPT OF MATERIEL****Unpacking**

When a new or reconditioned M137/M137A2/M137A3 Panoramic Telescope is received, be aware of any shipping damage to packaging materiel. Report any damage on SF 364, Report of Discrepancy (ROD), as prescribed in AR 735-11-2. Retain packaging materiel for future use.

Checking Unpacked Equipment


1. Inspect the equipment for damage incurred during shipment. If the equipment has been damaged, report the damage on SF 361, Transportation Discrepancy Report.
2. Check the equipment against the packing slip to see if the shipment is complete. Report all discrepancies in accordance with applicable service instructions (e.g., for Army instructions, see DA PAM 738-750).
3. Check to see whether the equipment has been modified.



4. Check M137/M137A2/M137A3 telescope (1) for bare spots, dents, scuff marks, and damaged parts. Inspect M137/ M137A2/M137A3 telescope for cleanness.
5. Check mounting surface (2). Mounting surface must be clean and free of nicks and burrs.
6. Instruction plate (3), identification plate (4), and instruction plate (5) must be present and readable.

SERVICE UPON RECEIPT OF MATERIEL - Continued

Checking Unpacked Equipment - Continued



7. Eyeshield (6) must not be torn or missing.
8. Rotate azimuth knob assembly (7). It must turn smoothly and rotate the head assembly and azimuth counter.
9. Rotate azimuth knob assembly (7) in DIRECT mode. Counter should move 5 mils for each click.
10. Rotate the correction knob assembly (8). It must turn smoothly and turn the correction counter.
11. Check window (9) and lenses (10) for dirt or condensation.

WARNING

RADIATION



**TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

12. Check reticle (11) for dirt or condensation. Inspect reticle for illumination. Illumination must be present and even.
13. Inspect counter box windows (12) for illumination. Illumination must be present and even.

END OF WORK PACKAGE

DIRECT SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**M137/M137A2/M137A3 PANORAMIC TELESCOPE MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Gasket (item 19, WP 0134 00)
Lockwasher (4) (item 11, WP 0133 00)
Lockwasher (3) (item 15, WP 0133 00)
Lockwasher (2) (item 23, WP 0133 00)
Sealing compound (item 13, WP 0152 00)

References

TM 9-254
WP 0132 00
WP 0133 00

DISASSEMBLY

WARNING

RADIATION

TRITIUM
GAS (H₃)


When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. If damaged, remove two machine screws (1), two lockwashers (2), and identification plate (3) from panoramic telescope (4) (M137 only). If damaged, remove two machine screws (5), two lockwashers (6), and identification plate (3) from panoramic telescope (M137A2/M137A3 only).
2. If damaged, remove two machine screws (7), two lockwashers (8), and instruction plate (9) from panoramic telescope (4) (M137 only).
3. Remove optical eyeshield (10) from panoramic telescope (4).

CAUTION


Support azimuth knob assembly in V block on solid surface to prevent damage to worm shaft.

4. Drive out headless straight pin (11) and remove knob assembly (12) from panoramic telescope (4).



1fc565

M137



M137A2/M137A3

5. Remove screw (13) and lockwasher (14) from wire rope assembly (15) on battery box cover (16). Discard lockwasher (M137A2/M137A3 only).

WARNING



Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries (M137A2/M137A3 only).

6. Remove protective cap-plug (17) and battery (18). If damaged, remove protective cap-plug from wire rope assembly (15) (M137A2/M137A3 only).
7. Remove top two screws (19) and top two lockwashers (20) from battery box cover (16). Discard lockwashers (M137A2/M137A3 only).

CAUTION

Use extreme care when removing battery box cover. A short wire harness and connector on the battery box cover is connected to a connector on a short wire harness on the electrical bracket. These connectors and wire harnesses are easily damaged (M137A2/M137A3 only).

8. Carefully remove battery box cover (16) and disconnect connector (21) from connector (22) on electrical bracket (23) (M137A2/M137A3 only).

DISASSEMBLY - Continued

9. Remove and discard gasket (24) from electrical bracket (23) (M137A2/M137A3 only).
10. Remove two machine screws (25) from electrical bracket (23) and remove electrical bracket from elbow of panoramic telescope (4) (M137A2/M137A3 only).

CLEANING

Clean all parts per TM 9-254.

REPAIR OR REPLACEMENT

1. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0132 00 and WP 0133 00.
2. Stamp M137/M137A2/M137A3 panoramic telescope serial number on new identification plate.

ASSEMBLY**RADIATION****WARNING****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

CAUTION

Support azimuth knob assembly in V block on solid surface to prevent damage to worm shaft.


1. Install knob assembly (1) on panoramic telescope (2) and secure with headless straight pin (3).
2. Install optical eyeshield (4) on panoramic telescope (2).

WARNING


Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

3. If removed, apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (5) (M137 only).
4. If removed, install identification plate (6) on side of counter box of panoramic telescope (2) and secure with two new lockwashers (7) (item 11, WP 0133 00) and two machine screws (5) (M137 only).

5. If removed, apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (8) (M137A2/M137A3 only).
6. If removed, install identification plate (6) on back of counter box of panoramic telescope (2). Secure with two new lockwashers (9) (item 23, WP 0133 00) and two machine screws (8) (M137A2/M137A3 only).
7. If removed, apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (10) (M137 only).
8. If removed, install instruction plate (11) on panoramic telescope (2) and secure with two new lockwashers (12) (item 11, WP 0133 00) and two machine screws (10) (M137 only).



M137



M137A2/M137A3

ASSEMBLY - Continued

9. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (13) (M137A2/M137A3 only).
10. Install two machine screws (13) through electrical bracket (14) and into elbow of panoramic telescope (2) (M137A2/M137A3 only).
11. Install new gasket (15) (item 19, WP 0133 00) on mating surface of battery box cover (16) with cutout aligned for wire (M137A2/M137A3 only).
12. Carefully connect connector (17) on battery box cover (16) to connector (18) on electrical bracket (14) (M137A2/M137A3 only).
13. Apply sealing compound (item 13, WP 0152 00) to threads of three machine screws (19 and 20) (M137A2/M137A3 only).

CAUTION

Be careful when assembling components. Do not pinch wire leads or connectors between parts (M137A2/M137A3 only).

14. Install battery box cover (16) with top two machine screws (19) and top two new lockwashers (21) (item 15, WP 0133 00) (M137A2/M137A3 only).
15. If removed, install new protective cap-plug (22) on wire rope assembly (23).
16. Install machine screw (20) with new lockwasher (24) (item 15, WP 0133 00) through wire rope assembly (23) into bottom mounting hole of battery box cover (16) (M137A2/M137A3 only).

WARNING

Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries (M137A2/M137A3 only).

CAUTION

Do not install batteries backwards. Severe equipment damage may result. Pay careful attention to polarity diagram on battery holder.

17. Install battery (25) into battery box cover (16) and secure with protective cap-plug (22).

END OF WORK PACKAGE

DIRECT SUPPORT**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)****HEAD ASSEMBLY MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Grease (item 15, WP 0152 00)

O-ring (item 8, WP 0134 00)

Sealing compound (item 13, WP 0152 00)


References

TM 9-254

WP 0134 00

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).



1. Unscrew and remove safety relief valve (1) from head housing (2).
2. Remove two setscrews (3) and shouldered knob (4).
3. Remove and discard O-ring (5) from inside of machine threaded bushing (6).

CLEANING


Clean all parts per TM 9-254.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0134 00.

ASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).



1. Apply a light coat of grease (item 15, WP 0152 00) to new O-ring (1) and install in machine threaded bushing (2).
2. Install shouldered knob (3) using two setscrews (4) which have been coated with sealing compound (item 13, WP 0152 00).

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

3. Apply a light coat of sealing compound (item 13, WP 0152 00) to safety relief valve (5) and install on head housing (6).

END OF WORK PACKAGE

DIRECT SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**COVER ASSEMBLY (HEAD) MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Grease (item 16, WP 0152 00)
Sealing compound (item 14, WP 0152 00)

References

TM 9-254
WP 0135 00



DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).



CAUTION

Support cover plate in V block on solid surface to prevent damage to shaft.

DISASSEMBLY - Continued



1. Remove headless straight pin (1) and headless straight pin (2) from cover plate (3).
2. Remove torsion helical spring (4) and cover plate (3) from optical element retainer (5).



3. Depress and hold detent plate (6). Unscrew post (7) and release detent plate. Remove detent plate and compression helical spring (8) from cover plate (3).

CLEANING

Clean all parts per TM 9-254.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0135 00.



ASSEMBLY

WARNING

RADIATION

TRITIUM
GAS (H₃)

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).





1. Apply a light coat of grease (item 16, WP 0152 00) to compression helical spring (1) and detent plate (2) and install in cover plate (3).

WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

2. Apply a light coat of sealing compound (item 14, WP 0152 00) to threads of post (4).
3. Align threaded hole in detent plate (1) with slot in cover plate (3) and install post (4).

ASSEMBLY - Continued

4. Install long end of torsion helical spring (5) in cover plate (3) and short end in optical element retainer (6).
5. Install headless straight pin (7) through optical element retainer (6) and cover plate (3).
6. Install headless straight pin (8) to secure headless straight pin (7) in optical element retainer (6).

END OF WORK PACKAGE

DIRECT SUPPORT**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)****BODY ASSEMBLY MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY****INITIAL SETUP:****Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Sealing compound (item 13, WP 0152 00)

References

TM 9-254


WP 0137 00

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

NOTE

M137 panoramic telescope is illustrated but procedure also applies to M137A2 and M137A3 panoramic telescopes.



1fc579

Remove safety relief valve (1) from telescope subassembly body (2).

CLEANING

Clean all parts per TM 9-254.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0137 00.

ASSEMBLY

WARNING

RADIATION




**TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

Apply a light coat of sealing compound (item 13, WP 0152 00) to threads of safety relief valve (1) and install in telescope subassembly body (2).



1fc580

END OF WORK PACKAGE

DIRECT SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**ELBOW ASSEMBLY MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Grease (item 16, WP 0152 00)

Sealing compound (item 13, WP 0152 00)

References

TM 9-254


WP 0139 00

Equipment Conditions

Battery enclosure assembly removed from elbow assembly (WP 0084 00)

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).



1. Remove air valve cap (1), valve core (2), fluid valve stem (3), and retaining strap (4) from telescope elbow (5).
2. Remove setscrew (6).
3. Depress detent plunger (7) and unscrew and remove plunger release lever (8).
4. Carefully remove detent plunger (7) and compression helical spring (9) from telescope elbow (5).

CLEANING

Clean all parts per TM 9-254.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0139 00.


ASSEMBLY

WARNING

RADIATION

TRITIUM
GAS (H₃)

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).



1. Apply a light coat of grease (item 16, WP 0152 00) to compression helical spring (1) and detent plunger (2), and install in telescope elbow (3).
2. Depress and hold detent plunger (2), and align threaded hole in detent plunger with slot in telescope elbow (3).
3. Install plunger release lever (4) and tighten.
4. Install setscrew (5). Tighten and apply light coat of sealing compound (item 13, WP 0152 00) over setscrew.

WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

5. Apply a light coat of sealing compound (item 13, WP 0152 00) to threads of fluid valve stem (6). Install valve core (7).

ASSEMBLY - Continued

6. Install one end of retaining strap (8) over threaded end of fluid valve stem (6) and install fluid valve stem in telescope elbow (3).
7. Install free end of retaining strap (8) on air valve cap (9), and install air valve cap on fluid valve stem (6).

END OF WORK PACKAGE

DIRECT SUPPORT

M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)

OPTICAL CELL ASSEMBLY MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY

INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Sealing compound (item 13, WP 0152 00)


References

TM 9-254

WP 0140 00

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).



Remove safety relief valve (1) from optical element cell (2).

CLEANING

Clean all parts per TM 9-254.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0140 00.


ASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

Apply a light coat of sealing compound (item 13, WP 0152 00) to threads of safety relief valve (1) and install in optical element cell (2).



1fc583

END OF WORK PACKAGE

DIRECT SUPPORT**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)****COUNTER BOX ASSEMBLY MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Adhesive (item 2, WP 0152 00)
Lockwasher (4) (item 15, WP 0141 00)
Lockwasher (2) (item 33, WP 0141 00)
Lockwasher (2) (item 36, WP 0141 00)
Lockwasher (5) (item 42, WP 0141 00)
Sealing compound (item 13, WP 0152 00)
Soap (item 19, WP 0152 00)

References

TM 9-254
WP 0141 00

Equipment Conditions

Counter box assembly partially disassembled (WP 0084 00)

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**


When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

NOTE

Charge nitrogen pressure to 7 psi (0.49 kg/cm²). Remove hose. Put soap suds (item 19, WP 0152 00) on valve opening to check for leakage. If valve leaks, replace valve stem and/or valve core.


DISASSEMBLY - Continued

1. Remove air valve cap (1), valve core (2), fluid valve stem (3), and retaining strap (4) from counter box assembly (5).
2. Remove two machine screws (6), two lockwashers (7), and cover assembly (8). Discard lockwashers.
3. If damaged, remove two machine screws (9), two lockwashers (10), and instruction plate (11). Discard lockwashers (M137 only).
4. Remove four machine screws (12), four lockwashers (13), and stop plate (14). Discard lockwashers (M137A2/M137A3 only).
5. If loose or damaged, remove two headless straight pins (15) (M137A2/M137A3 only).



1fc584

M137




1fc585

M137A2/M137A3

CAUTION

Support knob in V block on solid surface to prevent damage to shaft.

6. Drive headless straight pin (16) from knob (17), and remove knob from counter box assembly (5).



1fc586

DISASSEMBLY - Continued**WARNING**

Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries (M137A2/M137A3 only).

7. Remove machine screw (18), lockwasher (19), retaining strap (20), two protective cap-plugs (21), and two batteries (22) from battery box (23). If damaged, remove retaining strap from protective cap-plugs (M137A2/M137A3 only).
8. Remove four machine screws (24) and four lockwashers (25) (M137A2/M137A3 only).

CAUTION


Use extreme care when removing battery box. A short wire harness and connector on the battery box are connected to a connector on a short wire harness that passes through the adapter plate on the counter box assembly. These connectors and wire harnesses are easily damaged (M137A2/M137A3 only).

9. Carefully remove battery box (23) and disconnect connector (26) from connector (27) (M137A2/M137A3 only).

CAUTION

Do not attempt to remove adapter plate between the battery box and the counter box assembly. The wire harness passing through the adapter plate cannot be removed without damaging the equipment. The adapter plate can only be removed or installed by the manufacturer (M137A2/M137A3 only).

10. Remove gasket (28) from adapter plate (29) on counter box assembly (5). Discard gasket (M137A2/M137A3 only).



1fc587

M137A2/M137A3

CLEANING

Clean all parts per TM 9-254.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0141 00.

ASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**


When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. If instruction plate (1) is to be replaced, stamp 2.7 curies blank and stamp month and year light source was manufactured on new instruction plate. Install instruction plate (1) with two new lockwashers (2) (item 33, WP 0141 00) and two machine screws (3) (M137 only).


WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

2. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (4).
3. Install cover assembly (5), two new lockwashers (6) (item 36, WP 0141 00), and two machine screws (4).
4. Apply sealing compound (item 13, WP 0152 00) to fluid valve stem (7).
5. Install one end of retaining strap (8) on fluid valve stem (7) and install in counter box assembly (9).
6. Install valve core (10).
7. Install the other end of retaining strap (8) on air valve cap (11) and install.
8. If removed, install two headless straight pins (12) in bottom of counter box assembly (9). If headless straight pins are loose, ream holes for next larger size headless straight pins and install (M137A2/M137A3 only).
9. Apply sealing compound (item 13, WP 0152 00) to threads of four machine screws (13) (M137A2/M137A3 only).
10. Position stop plate (14) on counter box assembly (9) and secure in place with four new lockwashers (15) (item 15, WP 0141 00) and four machine screws (13) (M137A2/M137A3 only).



M137




M137A2/M137A3

ASSEMBLY - Continued**CAUTION**

Support knob in V block on solid surface to prevent damage to shaft.

11. Position knob (14) on eccentric (15) and secure with headless straight pin (16).

**WARNING**

Use adhesive in well-ventilated area away from open flame. Adhesive is harmful to skin and clothing and may give off harmful vapor.

NOTE

Apply a thin layer of adhesive (item 2, WP 0152 00) on edges of battery box to keep gasket in place.

12. Install new gasket (17) (item 44, WP 0141 00) on battery box (18) (M137A2/M137A3 only).

CAUTION

Be careful when assembling components. Do not pinch wire leads or connectors between parts (M137A2/M137A3 only).

13. Carefully connect connector (19) on adapter plate (20) to connector (21) on battery box (18) (M137A2/M137A3 only).
14. Apply sealing compound (item 13, WP 0152 00) to threads of four machine screws (22) (M137A2/M137A3 only).
15. Install four new lockwashers (23) (item 42, WP 0141 00) and four machine screws (22) to secure battery box (18) and gasket (17) to adapter plate (20) on counter box assembly (9) (M137A2/M137A3 only).


WARNING

Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries (M137A2/M137A3 only).

CAUTION

Do not install batteries backwards. Severe equipment damage may result. Pay careful attention to diagram on battery holder.

16. If removed, install new retaining strap (24) on two protective cap-plugs (25) (M137A2/M137A3 only).
17. Install two batteries (26) into battery box (18) and secure with two protective cap-plugs (25) and retaining strap (24) (M137A2/M137A3 only).
18. Secure retaining strap (24) with new lockwasher (27) (item 42, WP 0141 00) and machine screw (28) (M137A2/M137A3 only).



1fc591

M137A2/M137A3**END OF WORK PACKAGE****0090 00-9/10 blank**

DIRECT SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**COVER ASSEMBLY (AZIMUTH COUNTER) MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Cleaning compound (item 10, WP 0152 00)

Grease (item 16, WP 0152 00)

References

WP 0144 00

Equipment Conditions

Cover assembly removed from counter box assembly (WP 0090 00)

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**


When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. Remove two headless straight pins (1) from cover bracket (2).

NOTE

Use pressure against ball and spring to prevent loss.

2. Remove counter cover (3) from cover bracket (2).
3. Remove bearing ball (4) and compression helical spring (5) from counter cover (3).



1fc592

CLEANING

Clean all parts with cleaning compound (item 10, WP 0152 00).

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0144 00.

ASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. Apply a light coat of grease (item 16, WP 0152 00) to compression helical spring (5) and bearing ball (4). Install in counter cover (3) and hold in place with finger.
2. Position cover bracket (2) on counter cover (3).
3. Install two headless straight pins (1) in cover bracket (2).

END OF WORK PACKAGE

CHAPTER 21

**GENERAL SUPPORT
MAINTENANCE INSTRUCTIONS
FOR
M137/M137A2/M137A3 PANORAMIC TELESCOPE**

GENERAL SUPPORT**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)****M137/M137A2/M137A3 PANORAMIC TELESCOPE MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**


Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/PartsGrease (item 15, WP 0152 00)
Lens paper (item 17, WP 0152 00)
Lockwasher (9) (item 2, WP 0133 00)
Optical lens cleaning compound (item 11, WP 0152 00)
O-ring (item 3, WP 0133 00)
O-ring (item 6, WP 0133 00)
Seal (item 4, WP 0141 00)
Sealing compound (item 14, WP 0152 00)
Wiping rag (item 18, WP 0152 00)**References**TM 9-254
WP 0132 00
WP 0133 00
WP 0141 00**Equipment Conditions**Identification plate and instruction plate removed (WP 0084 00)
Eyeshield removed (WP 0084 00)


DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

DISASSEMBLY - Continued



1. Remove four socket head capscrews (1), four lockwashers (2), and head assembly (3). Discard lockwashers.
2. Remove O-ring (4) from head assembly (3). Discard O-ring.




3. Rotate elbow assembly (5) to the left position.

WARNING

Elbow assembly will only be removed from counter box assembly if radioactive light sources are fully illuminated. If not fully illuminated, send device to depot for maintenance.

4. Remove five machine screws (6) and five lockwashers (7). Pull counter box assembly (8) downward and remove. Discard lockwashers.
5. Remove headless straight pin (9) and knob assembly (10) from body assembly (11).

**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

CAUTION

When removing body assembly from elbow assembly, ensure that radioactive light sources are not damaged or removed.


- Remove four machine screws (12) and two elbow retainers (13) from body assembly (11). Carefully separate body assembly from elbow assembly (5), and remove O-ring (14). Discard O-ring.

CLEANING

Clean lenses per TM 9-254.

REPAIR OR REPLACEMENT

1. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0132 00 and WP 0133 00.



2. If counter box assembly (1) is replaced, remove three machine screws (2), three lockwashers (3), access cover (4), and seal (5) from the new counter box assembly. Install access cover, lockwashers, and machine screws on discarded counter box assembly. Forward discarded counter box assembly to depot maintenance.
3. Apply a light coat of grease (item 15, WP 0152 00) to new seal (5) (item 4, WP 0141 00) and install on the new counter box assembly (1).

ASSEMBLY

WARNING

RADIATION




**TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

CAUTION

When installing body assembly on elbow assembly, ensure that radioactive light sources are not damaged (M137 only).



1. Apply light coat of grease (item 15, WP 0152 00) on new O-ring (1) (item 6, WP 0133 00). Install body assembly (2) and O-ring on elbow assembly (3).



WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

2. Apply light coat of sealing compound (item 14, WP 0152 00) to threads of four machine screws (4). Position two elbow retainers (5) on elbow assembly (3) and secure with four machine screws.



ASSEMBLY - Continued



CAUTION

Ensure gears are meshed correctly while installing counter box assembly.

3. Apply light coat of sealing compound (item 14, WP 0152 00) to threads of five machine screws (6).
4. Push counter box assembly (7) upward against body assembly (2), and secure with five new lockwashers (8) (item 2, WP 0133 00) and five machine screws (6).
5. Install knob assembly (9) and headless straight pin (10) on body assembly (2).



6. Apply light coat of grease (item 15, WP 0152 00) to new O-ring (11) (item 3, WP 0133 00) and install in head assembly (12).
7. Apply light coat of sealing compound (item 14, WP 0152 00) to threads of four socket head cap screws (13).
8. Install head assembly (12), four new lockwashers (14) (item 2, WP 0133 00), and four socket head cap screws (13).

END OF WORK PACKAGE

GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**HEAD ASSEMBLY MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Cleaning compound (item 10, WP 0152 00)
Denatured alcohol (item 3, WP 0152 00)
Grease (item 15, WP 0152 00)
Grease (item 16, WP 0152 00)
Lens paper (item 17, WP 0152 00)
O-ring (item 8, WP 0134 00)
O-ring (2) (item 14, WP 0134 00)
Sealing compound (item 13, WP 0152 00)
Technical acetone (item 1, WP 0152 00)

References

TM 9-254
WP 0134 00

Equipment Conditions

Telescope head assembly removed from body assembly (WP 0092 00)

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. Remove safety relief valve (1) from head housing (2).
2. Remove two setscrews (3) and knob (4).
3. Remove sealing compound and setscrew (5).
4. Unscrew machine threaded bushing (6) and remove.
5. Remove O-ring (7) from inside of machine threaded bushing (6) and discard.
6. Remove external screw (8).
7. Remove telescope actuator (9), plunger (10), and flat washer (11) from head housing (2).
8. Unscrew plunger (10) from telescope actuator (9).
9. Unscrew machine threaded plug (12).
10. Remove compression helical spring (13), detent plunger (14), and O-ring (15). Discard O-ring.
11. Remove four machine screws (16) and cover assembly (17) from head housing (2).
12. Carefully remove nonmetallic round seal (18).

CAUTION

Glass can be damaged and scratched if handled carelessly and excessively.


13. Remove sealing compound and remove optical instrument window (19).
14. Remove sealing compound and unscrew prism pivot (20).
15. Remove three machine screws (21) and plate cover (22).

NOTE

Check position of prism pivot before removing four setscrews.

16. Remove sealing compound and four setscrews (23).
17. Pull prism pivot (24) from head housing (2).
18. Remove O-ring (25) from prism pivot (24). Discard O-ring.

19. If damaged, remove quick release plunger (26).
20. Remove optical instrument prism (27) from head housing (2).



1fc601

CLEANING

WARNING



Use cleaning compounds in well-ventilated area away from open flame. Cleaning compounds are harmful to skin and clothing and may give off harmful vapor.

1. Remove rust, corrosion, dirt, and grease from metal parts. Remove dirt and grease using cleaning compound (item 10, WP 0152 00).
2. Clean optical instrument prism using technical acetone (item 1, WP 0152 00) or denatured alcohol (item 3, WP 0152 00) and lens paper (item 17, WP 0152 00).

NOTE

General procedures for cleaning metal parts and optics, removing corrosion, staking pins, and other procedures are contained in TM 9-254.

REPAIR OR REPLACEMENT

1. Refer to TM 9-254 for general repair instructions.
2. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0134 00.

ASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. Position optical instrument prism (1) in head housing (2).
2. Apply a light coat of grease (item 15, WP 0152 00) to new O-ring (3) (item 14, WP 0134 00) and install in prism pivot (4).
3. If removed, screw quick release plunger (5) into prism pivot (4) until edge of quick release plunger thread is tangent to prism pivot diameter.
4. Install optical instrument prism (1) with bearing aligned over the hole for prism pivot (6).

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

5. Apply sealing compound (item 13, WP 0152 00) to threads of prism pivot (6).
6. Install prism pivot (6) in head housing (2) and align with bearings in optical instrument prism (1).

NOTE

The flats on prism pivot should be properly oriented in head housing.


7. Shift optical instrument prism (1) to align bearings with pivot hole for prism pivot (4) and install prism pivot.
8. Install plate cover (7) and secure with three machine screws (8).

9. Install four setscrews (9) in head housing (2).

NOTE


Sealing compound should not be applied to setscrews (9) until prism pivot (4) has been checked for plumb.

10. Fill holes for four setscrews (9) and three machine screws (8) with sealing compound (item 13, WP 0152 00).



ASSEMBLY - Continued

11. Apply 0.063 in. (1.600 mm) bead of sealing compound (item 13, WP 0152 00) around entire rim of optical instrument window (10). Place optical instrument window in head housing (2).
12. Apply a light coat of grease (item 15, WP 0152 00) to nonmetallic round seal (11) and install over optical instrument window (10).
13. Place cover assembly (12) in position on head housing (2).
14. Apply a coat of sealing compound (item 13, WP 0152 00) to threads of four machine screws (13) and install to secure cover assembly (12).
15. Apply a coat of grease (item 15, WP 0152 00) to new O-ring (14) (item 14, WP 0134 00) and install on threaded machine plug (15).
16. Apply a light coat of grease (item 16, WP 0152 00) to detent plunger (16) and install in head housing (2).
17. Apply sealing compound (item 13, WP 0152 00) to threads of machine threaded plug (15).
18. Install compression helical spring (17) and machine threaded plug (15).
19. Apply a coat of grease (item 16, WP 0152 00) to flat washer (18) and install in head housing (2).
20. Apply a light coat of grease (item 16, WP 0152 00) to plunger (19) and screw into telescope actuator (20). Install assembled plunger and telescope actuator into head housing (2).
21. Apply a coat of grease (item 15, WP 0152 00) to new O-ring (21) (item 8, WP 0134 00) and install in machine threaded bushing (22).
22. Screw machine threaded bushing (22) into head housing (2).
23. Apply sealing compound (item 13, WP 0152 00) to threads of external screw (23) and install.
24. Apply sealing compound (item 13, WP 0152 00) to setscrew (24) and install to prevent machine threaded bushing (22) from turning.
25. Position knob (25) on telescope actuator (20) and secure in place using two setscrews (26) which have been coated with sealing compound (item 13, WP 0152 00).
26. Apply a coat of sealing compound (item 13, WP 0152 00) to threads of safety relief valve (27) and install.



1f6603

END OF WORK PACKAGE

GENERAL SUPPORT

**M137/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6100)**

**OPTICAL ELEMENT SPACER MAINTENANCE
REMOVAL, DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY, INSTALLATION**

INITIAL SETUP:

Tools and Special Tools

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)

Materials/Parts

Grease (item 16, WP 0152 00)
Lockwasher (4) (item 2, WP 0133 00)
O-ring (item 3, WP 0133 00)
Wiping rag (item 18, WP 0152 00)

References

WP 0133 00
WP 0136 00

Equipment Conditions

Head assembly removed (WP 0092 00)

REMOVAL


WARNING

RADIATION



**TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).




1fc605

1. Remove four socket head capscrews (1) and four lockwashers (2). Lift optical element spacer (3) from straight pin (4) on body assembly (5). Discard lockwashers.
2. Remove O-ring (6) from body assembly (5). Discard O-ring.

DISASSEMBLY

NOTE

Replace telescope head spacer if bent or damaged and will not keep the head assembly in alignment with the elbow assembly.




1fc606

Remove straight pin (1) from telescope head spacer (2).

REPAIR OR REPLACEMENT


Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0133 00 and WP 0136 00.

ASSEMBLY



Install straight pin (1) in telescope head spacer (2).

INSTALLATION



1. Apply light coat of grease (item 16, WP 0152 00) to new O-ring (1) (item 3, WP 0133 00) and install in body assembly (2).
2. Place optical element spacer (3) over straight pin (4) on body assembly (2), and secure with four new lockwashers (5) (item 2, WP 0133 00) and four socket capscrews (6).
3. Install head assembly (WP 0092 00).

END OF WORK PACKAGE

GENERAL SUPPORT**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)****BODY ASSEMBLY MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Cleaning compound (item 10, WP 0152 00)
Grease (item 15, WP 0152 00)
Grease (item 16, WP 0152 00)
Lens paper (item 17, WP 0152 00)
Lockwasher (11) (item 2, WP 0137 00)
Optical lens cleaning compound (item 11, WP 0152 00)
O-ring (item 5, WP 0137 00)
O-ring (item 10, WP 0137 00)
O-ring (item 13, WP 0137 00)
O-ring (item 15, WP 0137 00)
O-ring (item 25, WP 0137 00)
Plastic bag (item 5, WP 0152 00)
Seal (item 6, WP 0137 00)
Seal (item 7, WP 0137 00)
Sealing compound (item 13, WP 0152 00)
Spring tension washer (item 17, WP 0137 00)
Tape (item 20, WP 0152 00)
Wiping rag (item 18, WP 0152 00)

References

WP 0137 00
WP 0138 00

Equipment Conditions

Body assembly removed from panoramic telescope (WP 0092 00)
Knob assembly removed from body assembly (WP 0092 00)

DISASSEMBLY


WARNING

RADIATION


TRITIUM
GAS (H₃)

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. Remove two machine screws (1), two lockwashers (2), and gear assembly (3) from worm gear housing body (4). Discard lockwashers.
2. If damaged, remove two headless straight pins (5) from gear assembly (3).
3. If damaged, remove two headless straight pins (6) from worm gear housing body (4).



4. Remove machine threaded plug (7), O-ring (8), compression helical spring (9), and detent plunger (10) from worm gear housing body (4). Discard O-ring.
5. Remove three machine screws (11), three lockwashers (12), plate (13), spring tension washer (14), recessed washer (15), and O-ring (16) from worm gear housing body (4). Discard lockwashers, spring tension washer, and O-ring.
6. Remove wormshaft cap (17) from worm gear housing body (4). Remove O-ring (18) from wormshaft cap. Discard O-ring.




1fc610

NOTE


To avoid bottoming in housing, drive pin partially out. Turn worm shaft assembly 180 degrees to remove pin.

7. Remove headless straight pin (19) from underside of worm gear housing body (4).



1fc611


8. Remove spur gear (20) from worm shaft assembly (21).
9. Remove sealing compound and loosen setscrew (22).
10. Unscrew seat (23) and remove worm shaft assembly (21) from worm gear housing body (4).



1fc611a

DISASSEMBLY - Continued

11. If damaged, remove two retaining rings (24) and cell assembly coupling (25).
12. Remove sealing compound from four machine screws (26) and remove four machine screws.
13. Remove objective and reticle assembly (27).
14. Remove six machine screws (28), six lockwashers (29), and packing retainer (30) from worm gear housing body (4). Discard lockwashers.
15. Remove O-ring (31) and seal (32) from packing retainer (30). Discard O-ring and seal.
16. If damaged, remove headless straight pin (33) from worm gear (34).
17. Remove worm gear (34).
18. Remove seal (35) from worm gear (34). Discard seal.
19. Remove O-ring (36) from worm gear housing body (4). Discard O-ring.
20. If damaged, remove two headless straight pins (37) from worm gear housing body (4).



1fc612

CLEANING

WARNING



Use cleaning compounds in well-ventilated area away from open flame. Cleaning compounds are harmful to skin and clothing and may give off harmful vapor.

1. Clean lenses with optical lens cleaning compound (item 11, WP 0152 00) and lens paper (item 17, WP 0152 00).
2. Clean all other parts with cleaning compound (item 10, WP 0152 00).

REPAIR OR REPLACEMENT

1. Check for cracks or loss of illumination (M137 only).
2. If no cracks are observed and light sources are illuminated, proceed with maintenance actions (M137 only).
3. If cracks are observed but light sources are still illuminated, remove body assembly and notify local Radiation Safety Officer (RSO). Perform wipe test under RSO supervision. Seal body assembly in a double plastic bag (item 5, WP 0152 00), secure with tape (item 20, WP 0152 00), and await wipe test results. If contaminated, dispose of assembly per RSO instructions. If assembly is not contaminated, replace parts as authorized (M137 only).
4. If no illumination is observed, check for illumination in a dark room. Notify RSO of results and follow procedure in step 3 above (M137 only).
5. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0137 00 and WP 0138 00.

ASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. Apply a light coat of grease (item 15, WP 0152 00) to new O-ring (1) (item 15, WP 0137 00). Install in worm gear housing body (2).
2. If removed, install two new headless straight pins (3) in worm gear housing body (2).
3. Apply a light coat of grease (item 15, WP 0152 00) to new seal (4) (item 7, WP 0137 00). Install seal in worm gear (5).

NOTE

Grease (item 16, WP 0152 00) should be applied to worm gear and bearing surfaces of worm gear and worm gear housing body.


4. Install worm gear (5) in worm gear housing body (2).
5. If removed, install headless straight pin (6) in worm gear (5).
6. Apply a light coat of grease (item 15, WP 0152 00) to new O-ring (7) (item 10, WP 0137 00) and new seal (8) (item 6, WP 0137 00) and install in packing retainer (9).

WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.


7. Apply sealing compound (item 13, WP 0152 00) to threads of six machine screws (10).
8. Install packing retainer (9), six new lockwashers (11) (item 2, WP 0137 00), and six machine screws (10) to worm gear housing body (2).
9. Install objective and reticle assembly (12).
10. Install four machine screws (13) to secure objective and reticle assembly (12) to worm gear (5).
11. Tighten four machine screws (13) and fill heads flush with sealing compound (item 13, WP 0152 00).



1fc613


ASSEMBLY - Continued

12. If parts were removed, apply a light coat of grease (item 16, WP 0152 00) to cell assembly coupling (14) and install cell assembly coupling and two retaining rings (15).
13. Apply a light coat of grease (item 16, WP 0152 00) to worm shaft assembly (16) and install in worm gear housing body (2).
14. Screw seat (17) into worm gear housing body (2) and tighten.
15. Tighten setscrew (18) and cover with sealing compound (item 13, WP 0152 00).
16. Install spur gear (19) on worm shaft assembly (16).
17. Install headless straight pin (20).




1fc614

18. If removed, install two headless straight pins (21).
19. If removed, install two headless straight pins (22).
20. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (23).
21. Install gear assembly (24), two new lockwashers (25) (item 2, WP 0137 00), and two machine screws (23) on worm gear housing body (2).



1fc615

22. Apply a light coat of grease (item 15, WP 0152 00) to new O-ring (26) (item 5, WP 0137 00) and install in wormshaft cap (27). Install wormshaft cap in worm gear housing body (2).
23. Apply sealing compound (item 13, WP 0152 00) to threads of three machine screws (28).
24. Apply a light coat of grease (item 15, WP 0152 00) to new O-ring (29) (item 13, WP 0137 00). Install O-ring, recessed washer (30), new spring tension washer (31) (item 17, WP 0137 00), plate (32), three new lockwashers (33) (item 2, WP 0137 00), and three machine screws (28) to worm gear housing body (2).
25. Apply a light coat of grease (item 15, WP 0152 00) to new O-ring (34) (item 25, WP 0137 00). Install new O-ring on machine threaded plug (35).
26. Apply a light coat of grease (item 16, WP 0152 00) to detent plunger (36) and place detent plunger and compression helical spring (37) in worm gear housing body (2).
27. Apply a coat of sealing compound (item 13, WP 0152 00) to threads of machine threaded plug (35) and install in worm gear housing body (2).



1fc616

ASSEMBLY - Continued**NOTE**

Perform steps 28 and 29 if new worm shaft assembly has been installed.

28. Install knob on worm shaft assembly (16) (WP 0092 00). Secure with setscrew, NSN 5305-00-728-1478. Using the pilot hole located on the knob, drill hole through worm shaft assembly.
29. Remove setscrew from knob and remove knob (WP 0092 00).

END OF WORK PACKAGE

GENERAL SUPPORT

M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)

ELBOW ASSEMBLY MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY, ADJUSTMENT

INITIAL SETUP:**Tools and Special Tools**

Dioptrometer (item 13, WP 0149 00)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Cleaning compound (item 10, WP 0152 00)
Denatured alcohol (item 3, WP 0152 00)
Grease (item 15, WP 0152 00)
Lens paper (item 17, WP 0152 00)
Lockwasher (8) (item 4, WP 0139 00)
O-ring (item 2, WP 0139 00)
O-ring (item 15, WP 0139 00)
Sealing compound (item 13, WP 0152 00)
Technical acetone (item 1, WP 0152 00)
Wiping rag (item 18, WP 0152 00)

References

TM 9-254
WP 0139 00

Equipment Conditions

Panoramic telescope elbow assembly partially disassembled (WP 0088 00)

DISASSEMBLY


WARNING

RADIATION

TRITIUM
GAS (H₃)

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. Remove four machine screws (1), four lockwashers (2), and elbow access cover (3). Discard lockwashers.
2. Remove O-ring (4) from elbow access cover (3). Discard O-ring.
3. Remove four socket head capscrews (5) and four lockwashers (6). Discard lockwashers.
4. Pull optical cell assembly (adapter) (7) from elbow telescope (8).
5. Remove sealing compound from two setscrews (9) and remove setscrews from elbow telescope.
6. Remove optical cell assembly (10) and O-ring (11) from elbow telescope (8). Discard O-ring.



1fc617

CLEANING**WARNING**

Use cleaning compounds in well-ventilated area away from open flame. Cleaning compounds are harmful to skin and clothing and may give off harmful vapor.

1. Remove rust, corrosion, dirt, and grease from metal parts. Remove dirt and grease using cleaning compound (item 10, WP 0152 00).
2. Clean optical lenses and prisms using technical acetone (item 1, WP 0152 00) or denatured alcohol (item 3, WP 0152 00) and lens paper (item 17, WP 0152 00).

NOTE

General procedures for cleaning metal parts and optics, removing corrosion, staking pins, and other procedures are contained in TM 9-254.

REPAIR OR REPLACEMENT

1. Refer to TM 9-254 for general repair instructions.
2. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0139 00.

ASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. Apply a light coat of grease (item 15, WP 0152 00) to new O-ring (1) (item 2, WP 0139 00) and install 1.80 in. (45.72 mm) inside elbow telescope (2).
2. Place optical cell assembly (3) inside elbow telescope (2).
3. Install two setscrews (4) to retain optical cell assembly (3).


ASSEMBLY - Continued

WARNING



Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.


4. Fill holes of two setscrews (4) with sealing compound (item 13, WP 0152 00).
5. Place optical cell assembly (adapter) (5) in elbow telescope (2). Align slot in optical cell assembly (adapter) over locating pin in elbow telescope.
6. Apply sealing compound (item 13, WP 0152 00) to threads of four socket head capscrews (6).
7. Install four new lockwashers (7) (item 4, WP 0139 00) and four socket head capscrews (6) to hold optical cell assembly (adapter) (5).
8. Apply a coat of grease (item 15, WP 0152 00) to new O-ring (8) (item 15, WP 0139 00) and install in elbow access cover (9).
9. Apply sealing compound (item 13, WP 0152 00) to threads of four machine screws (10).
10. Position elbow access cover (9) on elbow telescope (2) and secure in place using four new lockwashers (11) (item 4, WP 0139 00) and four machine screws (10).



1fc618

ADJUSTMENT**Eyepiece Focus**

Viewing a crossbar target placed in the focal plane as shown, the eyepiece focus of the crossbar image should lie between -0.5 and -1.0 diopters, measured at the eyepiece using a diptometer.

**END OF WORK PACKAGE**

GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**OPTICAL CELL ASSEMBLY MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:

Tools and Special Tools

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Lens paper (item 17, WP 0152 00)

Optical lens cleaning compound (item 11, WP 0152 00)

Sealing compound (item 13, WP 0152 00)

Wiping rag (item 18, WP 0152 00)


References

TM 9-254

WP 0140 00

DISASSEMBLY

1. Remove safety relief valve (1) from optical element cell (2).
2. Remove externally threaded ring (3) from optical element cell (2).
3. Carefully remove sealing compound from optical instrument lens (4) and remove from optical element cell (2).
4. Remove spacer (5) and optical instrument lens (6) from optical element cell (2).

**CLEANING**

Clean all parts per TM 9-254.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0140 00.

ASSEMBLY

1. Position optical instrument lens (6), spacer (5), and optical instrument lens (4) in optical element cell (2).
2. Install and tighten externally threaded ring (3) in optical element cell (2).

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

3. Inject sealing compound (item 13, WP 0152 00) into two drilled holes in optical element cell (2) to secure optical instrument lens (4) and externally threaded ring (3).
4. Apply a light coat of sealing compound (item 13, WP 0152 00) to safety relief valve (1) and install in optical element cell (2).

WARNING

Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.

5. Clean optical instrument lens (4) with optical lens cleaning compound (item 11, WP 0152 00) and lens paper (item 17, WP 0152 00).

END OF WORK PACKAGE

GENERAL SUPPORT**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)****COUNTER BOX ASSEMBLY (EXTERNAL PARTS) MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Cleaning compound (item 10, WP 0152 00)
Gasket (item 10, WP 0141 00)
Grease (item 15, WP 0152 00)
Lens paper (item 17, WP 0152 00)
Lockwasher (12) (item 12, WP 0141 00)
Lockwasher (4) (item 15, WP 0141 00)
Lockwasher (4) (item 19, WP 0141 00)
Nonmetallic seal (item 4, WP 0141 00)
Optical lens cleaning compound (item 11, WP 0152 00)
O-ring (item 21, WP 0141 00)
Sealing compound (item 13, WP 0152 00)
Wiping rag (item 18, WP 0152 00)

References

TM 9-254
WP 0141 00


Equipment Conditions

Counter box assembly removed from panoramic telescope (WP 0092 00)
Fluid valve stem, valve core, retaining strap, and air valve cap removed from counter
box assembly (WP 0090 00)
Battery enclosure assembly removed from M137A2/M137A3 counter box assembly (WP 0090 00)
Stop plate removed from M137A2/M137A3 counter box assembly (WP 0090 00)

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**


When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. Remove headless straight pin (1) from knob (2) and remove knob.
2. Remove nonmetallic seal (3) from counter box assembly (4). Discard nonmetallic seal.
3. Remove two machine screws (5) and window retaining plate (6).
4. Carefully remove sealing compound from edge of optical instrument window (7). Remove optical instrument window and window mask (8).
5. Remove two machine screws (9) and window retaining plate (10).
6. Carefully remove sealing compound from edge of optical instrument window (11). Remove optical instrument window and window mask (12).
7. Remove two machine screws (13) and window retaining plate (14).
8. Carefully remove sealing compound from edge of optical instrument window (15). Remove optical instrument window.
9. Remove two externally relieved screws (16), two lockwashers (17), and access cover (18). Discard lockwashers.
10. Remove 12 machine screws (19), 12 lockwashers (20), and counter housing cover (21). Discard lockwashers.
11. If damaged, remove two machine screws (22) and spacer (23) from counter housing cover (21) (M137A2/M137A3 only).
12. Remove and discard gasket (24).
13. Remove two machine screws (25), two lockwashers (26), and knob assembly (27). Discard lockwashers.
14. Remove O-ring (28) from knob assembly (27). Discard O-ring.
15. Remove four machine screws (29), four lockwashers (30), and stop plate (31) (M137 only). Discard lockwashers.
16. If loose or damaged, remove two headless straight pins (32) (M137 only).



1fc621

M137A2/M137A3 Counter Box Assembly



1fc622

M137 Counter Box Assembly

CLEANING**WARNING**

Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever cleaning compound is used.

Remove rust, corrosion, dirt, and grease from metal parts. Remove dirt and grease using cleaning compound (item 10, WP 0152 00).

NOTE

General procedures for cleaning metal parts and optics, removing corrosion, staking pins, and other procedures are contained in TM 9-254.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0141 00.

ASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. If removed, install two headless straight pins (1) in bottom of counter box assembly (2). If headless straight pins are loose, ream holes for next larger standard size headless straight pins and install (M137 only).

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.


2. Apply sealing compound (item 13, WP 0152 00) to threads of four machine screws (3) (M137 only).
3. Position stop plate (4) on counter box assembly (2) and secure in place with four new lockwashers (5) (item 15, WP 0141 00) and four machine screws (3) (M137 only).

4. Apply a light coat of grease (item 15, WP 0152 00) to new O-ring (6) (item 21, WP 0141 00) and install on knob assembly (7).
5. Turn knob assembly (7) clockwise until it stops.

NOTE


Correction counter should read ON or between R-95 and R-99.

6. Install knob assembly (7) and be sure that the shaft of knob assembly engages coupling pin of correction counter.
7. Turn knob assembly (7) counterclockwise until it stops. The corners of the correction counter should read L-95 to L-99. If it does not, adjust the knob assembly accordingly.



1fc623

M137 Counter Box Assembly


ASSEMBLY - Continued

1fc624

M137A2/M137A3 Counter Box Assembly


8. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (8).
9. Install two new lockwashers (9) (item 19, WP 0141 00) and two machine screws (8). Tighten screws.
10. Apply a light coat of grease (item 15, WP 0152 00) to new gasket (10) (item 10, WP 0141 00).
11. Install new gasket (10) into counter box assembly (2).
12. If removed, apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (11) (M137A2/M137A3 only).
13. If removed, install spacer (12) on counter housing cover (13) and secure with two machine screws (11). Countersink machine screws (M137A2/M137A3 only).
14. Apply sealing compound (item 13, WP 0152 00) to threads of 12 machine screws (14).
15. Install counter housing cover (13), 12 new lockwashers (15) (item 12, WP 0141 00), and 12 machine screws (14).
16. Apply sealing compound (item 13, WP 0152 00) to threads of two externally relieved screws (16).
17. Place access cover (17) on counter box assembly (2) and secure in place with two new lockwashers (18) (item 19, WP 0141 00) and two externally relieved screws (16).
18. Apply a light coat of sealing compound (item 13, WP 0152 00) around edge of optical instrument window (19) and install.
19. Apply a light coat of sealing compound (item 13, WP 0152 00) to threads of two machine screws (20).
20. Install window retaining plate (21) and two machine screws (20).

21. Install window masks (22 and 23).
22. Apply a light coat of sealing compound (item 13, WP 0152 00) around edge of optical instrument windows (24 and 25) and install.
23. Install window retaining plates (26 and 27).
24. Apply a light coat of sealing compound (item 13, WP 0152 00) to threads of four machine screws (28 and 29) and install.
25. Apply a light coat of grease (item 15, WP 0152 00) to new nonmetallic seal (30) (item 4, WP 0141 00) and install in top of counter box assembly (2).



1fc625

M137 Counter Box Assembly



1fc626

M137A2/M137A3 Counter Box Assembly

ASSEMBLY - Continued

26. Install knob (31) and secure with headless straight pin (32). If headless straight pin is loose, ream hole for the next larger size of headless straight pin and install.
27. Carefully remove all fingerprints from counter windows using optical lens cleaning compound (item 11, WP 0152 00) and lens paper (item 17, WP 0152 00).

END OF WORK PACKAGE

GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**COUNTER BOX ASSEMBLY (PARTS) MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Cleaning compound (item 10, WP 0152 00)
Epoxy adhesive (item 4, WP 0152 00)
Grease (item 15, WP 0152 00)
Lockwasher (15) (item 4, WP 0142 00)
Lockwasher (3) (item 21, WP 0142 00)
O-ring (2) (item 16, WP 0142 00)
Sealing compound (item 13, WP 0152 00)
Wiping rag (item 18, WP 0152 00)

References

TM 9-254
WP 0142 00

Equipment Conditions

Counter box assembly removed from panoramic telescope (WP 0092 00)
Counter box assembly partially disassembled (WP 0098 00)

DISASSEMBLY**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. Remove two machine screws (1) and two lockwashers (2). Discard lockwashers.

NOTE

Scribe lines on stop and on counter box assembly to aid in proper realignment during assembly.


2. Lift up and remove stop (3) from counter box assembly (4).
3. Remove pantel eccentric (5).
4. Remove O-ring (6) from pantel eccentric (5). Discard O-ring.
5. Remove two machine screws (7), two lockwashers (8), stop (9), and pantel eccentric (10). Discard lockwashers.
6. Remove O-ring (11) from pantel eccentric (10). Discard O-ring.

NOTE

Rotating counters (12 and 13) are not interchangeable. Mark rotating counters to identify for assembly.

7. Remove two machine screws (14) and two lockwashers (15). Discard lockwashers.
8. Remove two machine screws (16) and two lockwashers (17). Discard lockwashers.
9. Rotate lower counter shaft of optical element gear block assembly (18) so that slot in lower counter shaft is in upright position.
10. Rotate upper counter shaft of optical element gear block assembly (18) so that slot in upper counter shaft is in upright position.
11. Remove rotating counters (12 and 13) with bracing plate (19).
12. If either rotating counter (12 and/or 13) is damaged or is being replaced, replace both rotating counters but first remove two headless straight pins (20 and 21) and two couplings (22 and 23).
13. If damaged, discard both rotating counters (12 and 13) with bracing plate (19).
14. Remove three socket head capscrews (24), three lockwashers (25), and rotating counter (26) with counter mount (27). Discard lockwashers.
15. Remove four socket head capscrews (28), four lockwashers (29), and counter mount (27) from rotating counter (26). Discard lockwashers.

16. If damaged or if rotating counter (26) is being replaced, remove headless straight pin (30) and reset coupling (31).
17. Remove three machine screws (32), three lockwashers (33), and optical element gear block assembly (18). Discard lockwashers.



1fc627

CLEANING

WARNING



Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.

Remove rust, corrosion, dirt, and grease from metal parts. Remove dirt and grease using cleaning compound (item 10, WP 0152 00).

NOTE

General procedures for cleaning metal parts and optics, removing corrosion, staking pins, and other procedures are contained in TM 9-254.

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0142 00.

ASSEMBLY**RADIATION****WARNING****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).

1. Place optical element gear block assembly (1) in counter box assembly (2).

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

2. Apply sealing compound (item 13, WP 0152 00) to threads of three machine screws (3).
3. Install three new lockwashers (4) (item 13, WP 0142 00) and three machine screws (3). Tighten screws.
4. Place counter mount (5) on rotating counter (6).
5. Apply sealing compound (item 13, WP 0152 00) to threads of four socket head capscrews (7).
6. Install four new lockwashers (8) (item 4, WP 0142 00) and four socket head capscrews (7). Tighten capscrews.


NOTE

If new rotating counter or reset coupling is required, timing must be maintained. To accomplish this, follow steps 7 through 14.

If original rotating counter or reset coupling is to be reassembled in counter box assembly, proceed to step 15.

7. Position reset coupling (9) on shaft of rotating counter (6). Install a 0.112-48 thread setscrew in reset coupling; do not tighten at this time.
8. Temporarily install rotating counter (6) and counter mount (5) in counter box assembly (2).
9. Temporarily install knob assembly (WP 0098 00). Set rotating counter so that numbers are aligned as seen through the optical instrument window.

10. Set reset coupling (9) so that setscrew is accessible and tighten.
11. Turn knob to be sure that rotating counter numbers are in correct alignment. If not, loosen setscrew and realign rotating counter (6) until numbers are aligned as seen through optical instrument window. Tighten setscrew.
12. Remove rotating counter (6) with counter mount (5) from counter box assembly (2).
13. Drill pin hole in reset coupling (9) and shaft of rotating counter (6). Install headless straight pin (10).
14. Remove setscrew from reset coupling (9).
15. If using original parts, install reset coupling (9) and secure with headless straight pin (10).
16. Set rotating counter (6) to 00 and install.
17. Apply sealing compound (item 13, WP 0152 00) to threads of three socket head capscrews (11).
18. Install three new lockwashers (12) (item 4, WP 0142 00) and three socket head capscrews (11) to secure counter mount (5) to counter box assembly (2).



ASSEMBLY - Continued

19. Position coupling (13) on shaft of rotating counter (14) and install headless straight pin (15). If headless straight pin is loose, ream hole for next larger size headless straight pin and install.
20. Position rotating counter (14) in counter box assembly (2).

NOTE


Be sure that headless straight pin (15) in coupling (13) is in slot of upper counter shaft.

21. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (16).
22. Install two new lockwashers (17) (item 4, WP 0142 00) and two machine screws (16).
23. Position coupling (18) on shaft of rotating counter (19) and install headless straight pin (20). If headless straight pin is loose, ream hole for next larger size headless straight pin and install.
24. Position rotating counter (19) in counter box assembly (2).
25. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (21).
26. Install two new lockwashers (22) (item 4, WP 0142 00) and two machine screws (21).

WARNING

Use adhesive in well-ventilated area away from open flame. Adhesive is harmful to skin and clothing and may give off harmful vapor.

27. Apply epoxy adhesive (item 4, WP 0152 00) carefully to two rotating counters (14 and 19), ensuring that no epoxy gets onto number wheels of rotating counters.
28. Place bracing plate (23) onto rotating counters (14 and 19), ensuring that no epoxy gets onto number wheels of rotating counters.
29. Place small weight on bracing plate (23) and allow to cure for 24 hours.




1fc629

30. Apply a light coat of grease (item 15, WP 0152 00) to new O-ring (24) (item 16, WP 0142 00) and install on pantel eccentric (25).
31. Install pantel eccentric (25) in counter box assembly (2) with lug in downward position.
32. Install stop (26) on pantel eccentric (25) with scribed line aligned with scribed line on counter box assembly (2).

ASSEMBLY - Continued

33. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (27).
34. Install two new lockwashers (28) (item 4, WP 0142 00) and two machine screws (27). Tighten screws.
35. Apply a light coat of grease (item 15, WP 0152 00) to new O-ring (29) (item 16, WP 0142 00) and install on pantel eccentric (30).
36. Install pantel eccentric (30) in counter box assembly (2) with lug in downward position.
37. Install stop (31) on pantel eccentric (30) with scribed line aligned with scribed line on counter box assembly (2).
38. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (32).
39. Install two new lockwashers (33) (item 4, WP 0142 00) and two machine screws (32). Tighten screws.

**END OF WORK PACKAGE**

CHAPTER 22

GENERAL SUPPORT
FINAL INSPECTION INSTRUCTIONS
FOR
M137/M137A2/M137A3 PANORAMIC TELESCOPE

GENERAL SUPPORT**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)****FINAL INSPECTION INSTRUCTIONS
TEST AND INSPECTION**

INITIAL SETUP:**Test Equipment**

Azimuth test fixture (item 7, WP 0149 00)
Dioptometer (item 13, WP 0149 00)
Extension adapter (item 3, WP 0149 00)
Fixture adapter (item 5, WP 0149 00)
Infinity aiming reference collimator (item 23, WP 0149 00)
Plate-mounted level (item 12, WP 0149 00)
Surface gage (item 21, WP 0149 00)
Telescope mount holder (item 22, WP 0149 00)

Tools and Special Tools

Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

References

TM 750-116

Special Environmental Conditions

Ambient temperature +60 °F (+16 °C) to +90 °F (+32 °C)

TEST AND INSPECTION**WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M137 only).



NOTE

Procedure is written and illustrated for the M137 panoramic telescope but also applies to the M137A2 and M137A3 panoramic telescopes.



For testing of any M137 model with quick release pins, pins must be removed to fit azimuth test fixture.

TEST AND INSPECTION - Continued


Setting Up and Adjusting Azimuth Test Fixture



1. Secure azimuth test fixture (1) on test stand (2) at a height suitable for operation.
2. Position fixture adapter (3) on adapter support plate (4) and lightly clamp to hold in place.




3. Place plate-mounted level (5) on fixture adapter (3) and turn adapter support plate (4).
4. Check that adapter support plate (4) remains level through full rotation of azimuth test fixture scale (6).




1fc637

5. Place M137 telescope (7) on fixture adapter (3) and adjust collimator height. Remove M137 telescope from fixture adapter after adjustment.
6. Set azimuth test fixture scale (6) to 0 graduation. Align with 0 graduation on vernier scale. Lock in this position.




1fc638

7. Position surface gage (telescope holder) (8), with telescope mount holder (9), on fixture adapter (3).
8. Place dioptrometer (collimator telescope) (10) on surface gage (telescope holder) (8) and adjust for proper height.




1fc639


9. Suspend plumblines (11) to one side of the infinity aiming reference collimator (12).

TEST AND INSPECTION - Continued**Setting Up and Adjusting Azimuth Test Fixture - Continued**

10. Turn azimuth ring (13) until the reticle cross line intersection point of dioptrometer (collimator telescope) (10) is centered on plumbline.
11. Rotate dioptrometer (collimator telescope) (10) until vertical reticle line is superimposed on plumbline.



12. Turn azimuth ring (13) back until line of sight of dioptometer (collimator telescope) (10) aligns with line of sight of infinity aiming reference collimator (12).
13. Revolve infinity aiming reference collimator (12) until vertical reticle line coincides with vertical line of dioptometer (collimator telescope) (10).
14. Remove surface gage (telescope holder) (8) from fixture adapter (3).




NOTE

Extension adapter is used only when testing M137 or M137A3 panoramic telescope. When testing M137A2 panoramic telescope, position reflecting mirror assembly on fixture adapter.

15. Place extension adapter (14) on fixture adapter (3).
16. Position reflecting mirror assembly (15) on extension adapter (14).

TEST AND INSPECTION - Continued


Setting Up and Adjusting Azimuth Test Fixture - Continued




17. Relocate infinity aiming reference collimator light (16) to lower position.

NOTE

Ensure that locating keys and related keyways are kept in proper contact to ensure correct azimuth autocollimation.




18. Look through infinity aiming reference collimator (12) and focus.
19. Tilt infinity aiming reference collimator (12) in both elevation and depression, using holder screws (17), until test reticle is reflected in reflecting mirror assembly (15) and is superimposed upon itself.
20. If reflected image is not superimposed in azimuth, slightly shift fixture adapter (3) to correct.




1fc645

21. When autocollimation is finished, clamp fixture adapter (3) securely to azimuth test fixture (1) with three cam lock screws (18).
22. Recheck autocollimation. Repeat steps above if necessary.




1fc646

23. Remove reflecting mirror assembly (15) from extension adapter (14).
24. Remove extension adapter (14) from fixture adapter (3).




1fc647


25. Set parallax distance of infinity aiming reference collimator (12) to 130 ± 10 meters by rotating objective end (19).

TEST AND INSPECTION - Continued**Visual Inspection**

1. Check that all screws and lockwashers on M137/M137A2/M137A3 telescope (1) are present and secure.
2. Check that mounting surface is clean and free of nicks and burrs.
3. Inspect M137/M137A2/M137A3 telescope (1) for the following: rust, dirt, and foreign matter; missing parts; and chipped paint.




4. Depress detent (2) to open cover assembly (3). Check that cover assembly stays open.
5. Close cover assembly (3). Check that detent (2) holds cover closed.




1fc650

6. Open azimuth counter cover (4). Check that it stays open.
7. Close azimuth counter cover (4). Check that it stays closed.



1fc651


8. Depress lever (5) and move elbow assembly (6) horizontally. Check that elbow assembly moves freely without binding, and that lever stops elbow assembly at different positions during movement.
9. Look through eyeshield (7). Check that no dirt or moisture is present on lenses (8).

TEST AND INSPECTION - Continued**Mounting Telescope to Azimuth Test Fixture**


1. Place M137/M137A2/M137A3 telescope (1) on fixture adapter (2).
2. Install four bolts (3) to secure M137/M137A2/M137A3 telescope (1) to fixture adapter (2).

Boresight Retention Inspection**NOTE**


The cover plate on the head assembly should be closed to help eliminate parallax between the M137/M137A2/M137A3 telescope and the collimator projector, wall targets, and plumbines.




1. Mount M137/M137A2/M137A3 telescope (1) on azimuth test fixture (2). Refer to Mounting Telescope to Azimuth Test Fixture.
2. Set azimuth test fixture scale (3) to 4800 mils.
3. Turn correction knob (4) until correction counter (5) reads zero.



4. Turn azimuth knob (6) until 3200 mils appears on deflection counter (7).
5. Release deflection counter eccentric (8).
6. Turn azimuth knob (6) until 3200 mils appears on azimuth counter (9).
7. Engage deflection counter eccentric (8).




8. Looking through eyeshield (10), turn elevation knob (11) until horizontal reticle line is centered on collimator reticle target.
9. Check that vertical reticle line is centered on collimator reticle target. If not centered, turn azimuth counter to 3200 mils with backlash eliminated and release azimuth counter eccentric (12).
10. Turn azimuth knob (6) until vertical reticle line is centered on collimator reticle target and engage azimuth counter eccentric (12).

TEST AND INSPECTION - Continued**Boresight Retention Inspection - Continued**

1fc656

11. Turn azimuth knob (6) until head assembly (13) makes one complete revolution.
12. Check that 3200 appears on azimuth counter (9).
13. Check that vertical reticle line is centered on collimator reticle target or within ± 0.25 mil.
14. Check that reading on deflection counter (7) is within ± 0.25 mil of reading on azimuth counter (9).
15. Rotate azimuth test fixture scale (3) to 1600 mils.
16. Repeat steps 4 through 14 with 0000 on deflection counter (7) and azimuth counter (9).

Azimuth Knob Backlash Inspection

1fc657

1. Mount M137/M137A2/M137A3 telescope (1) on azimuth test fixture (2). Refer to Mounting Telescope to Azimuth Test Fixture.

- Set azimuth test fixture scale (3) to read 4800 mils.

NOTE


When checked at 3200 and 0000 mils, backlash in the azimuth mechanism shall not exceed 0.5 mil as read on the azimuth counter and 0.75 mil as read on the deflection counter.

- Turn azimuth knob (4) clockwise until vertical reticle line is centered with collimator reticle target. Record reading.
- Turn azimuth knob (4) clockwise one complete turn.

NOTE

When turning azimuth knob counterclockwise, be careful not to go past the center of target.


- Turn azimuth knob (4) counterclockwise until vertical reticle line is centered on collimator reticle target. Record readings on azimuth counter (5) and deflection counter (6).
- Compare with reading recorded in step 3. Difference must not exceed readings stated in note following step 2.




- Rotate azimuth test fixture scale (3) to 1600 mils and repeat steps 3 through 6.

TEST AND INSPECTION - Continued


Head Assembly Excursion and Plumblines Travel Inspection



1. Mount M137/M137A2/M137A3 telescope (1) on azimuth test fixture (2). Refer to Mounting Telescope to Azimuth Test Fixture.




2. Turn elevation knob (3) until horizontal reticle line (4) is in center of travel.



**TARGET DISTANCE 8' (FROM OBJECTIVE LENS)
BLACK LINES ON WHITE BACKGROUND
LINE THK-3/16**

1fc661

3. Mount test target (5) on wall 8 feet (2.44 m) from azimuth test fixture (2).
4. Rotate azimuth test fixture (2) and sight on test target (5).
5. Check that horizontal reticle line of M137/M137A2/M137A3 telescope (1) is aligned with centered test target (5); if not, adjust target.



6. Rotate azimuth knob (6) until vertical reticle line is aligned with center of test target and plumbline.


NOTE

Starting with line of sight in coincidence with a vertical target line, the line of sight shall track the plumbline within 0.5 mil.

7. While looking through eyeshield (7), turn elevation knob (3) clockwise as far as possible. Check that horizontal reticle line reaches 300 mils on test target.
8. Turn elevation knob (3) counterclockwise as far as possible. Check that horizontal reticle line reaches 300 mils on test target.


TEST AND INSPECTION - Continued

Azimuth Mechanism 800-mil Steps and Level Travel Inspection




1fc663

1. Mount M137/M137A2/M137A3 telescope (1) on azimuth test fixture (2). Refer to Mounting Telescope to Azimuth Test Fixture.




1fc664

2. Set azimuth test fixture scale (3) to 4800 mils.



1fc665

3. Turn azimuth knob (4) until deflection counter (5) reads 3200 mils.
4. Disengage deflection counter eccentric (6).
5. Turn azimuth knob (4) until azimuth counter (7) reads 3200 mils.
6. Disengage azimuth counter eccentric (8).
7. Turn azimuth knob (4) until vertical reticle line is centered on collimator reticle target.
8. Engage deflection counter eccentric (6) and azimuth counter eccentric (8).



1fc666

9. Turn elevation knob (9) until horizontal reticle line is centered on collimator reticle target.

TEST AND INSPECTION - Continued

Azimuth Mechanism 800-mil Steps and Level Travel Inspection - Continued

NOTE

The following data is required to do steps 10, 11, and 13.

Columns one and two give the required settings, in 800-mil increments, to be used in steps 10 and 11.


Column three (step 13) gives the reading that should appear on the deflection counter after doing steps 10 and 11.

Table 1. Azimuth Mechanism Inspection - Settings and Readings.



AZIMUTH KNOB SETTING (MILS)	AZIMUTH TEST STAND SETTING (MILS)	DEFLECTION COUNTER READING (MILS)
4000	5600	4000
4800	0000	4800
5600	0800	5600
0000	1600	0000
0800	2400	0800
1600	3200	1600
2400	4000	2400
3200	4800	3200

NOTE


When doing the next step, be careful not to turn azimuth knob past the specified counter setting.



10. Turn azimuth knob (4) clockwise until azimuth counter (7) is set at 4000 mils.



11. Rotate azimuth test fixture (2) until azimuth test fixture scale (3) reads 5600 mils.




NOTE


The total spread through two full revolutions between the greatest positive error and greatest negative error shall not exceed 1 mil including backlash.

TEST AND INSPECTION - Continued**Azimuth Mechanism 800-mil Steps and Level Travel Inspection - Continued**

12. Looking through eyeshield (10), check the following:
 - a. Vertical reticle line must be centered on collimator reticle target within ± 1 mil.
 - b. Horizontal reticle line must be centered on collimator reticle target within ± 1 mil (2-mil total spread).
 - c. Record readings taken in steps a and b above for two full revolutions and compare readings. Ensure total spread does not exceed specified tolerances for level travel and azimuth error.




13. Check that reading on deflection counter (5) is 4000 ± 0.25 mil.
14. Repeat steps 10 through 13 using the settings in Table 1, until each reading obtained is verified two times.




15. Repeat entire test turning azimuth knob (4) counterclockwise.

Azimuth Mechanism 15-mil Steps Inspection



1fc672

1. Mount M137/M137A2/M137A3 telescope (1) on azimuth test fixture (2). Refer to Mounting Telescope to Azimuth Test Fixture.




1fc673


2. Set azimuth test fixture scale (3) to 4800 mils.

TEST AND INSPECTION - Continued**Azimuth Mechanism 15-mil Steps Inspection - Continued****NOTE**

Eliminate backlash. In steps 3, 5, and 7, azimuth knob must be turned clockwise.




3. Turn azimuth knob (4) until deflection counter (5) reads 3200 mils.
4. Release deflection counter eccentric (6).
5. Turn azimuth knob (4) until azimuth counter (7) reads 3200 mils.
6. Release azimuth counter eccentric (8).
7. Turn azimuth knob (4) until vertical reticle line and horizontal reticle line are centered on collimator reticle target.
8. Engage azimuth counter eccentric (8).
9. Engage deflection counter eccentric (6).



1fc675

10. Set correction counter (9) at L-15.
11. Sighting through eyeshield (10), turn azimuth knob (4) clockwise to deflect line of sight 15 mils, as seen on reticle. Check that deflection counter (5) returns to 3200 ± 0.25 mils.
12. Repeat step 2 with settings of 0000, 1600, and 3200 mils, and azimuth counter settings of 4800, 0000, and 1600 mils respectively. Then repeat step 11.
13. Repeat steps 2 through 11 in counterclockwise rotation with backlash eliminated and correction counter set at R-15.
14. Repeat step 2 with settings of 3200, 1600, and 0000 mils, and azimuth counter settings of 1600, 0000, and 4800 mils respectively. Then repeat step 11.

Azimuth Mechanism Lift Inspection




1fc676


1. Mount M137/M137A2/M137A3 telescope (1) on azimuth test fixture (2). Refer to Mounting Telescope to Azimuth Test Fixture.
2. Verify boresight. Refer to Boresight Retention Inspection.

TEST AND INSPECTION - Continued**Azimuth Mechanism Lift Inspection - Continued**


3. Turn azimuth knob (3) clockwise and then counterclockwise.
4. Observe horizontal reticle line. Vertical displacement of the horizontal reticle line must not be more than 0.5 mil.




5. Repeat steps 2, 3, and 4 with settings of 4800, 0000, and 1600 mils on azimuth counter (4).

Azimuth Knob 5-mil Click Lead Mechanism Inspection


1. Mount M137/M137A2/M137A3 telescope (1) on azimuth test fixture (2). Refer to Mounting Telescope to Azimuth Test Fixture.
2. Verify boresight. Refer to Boresight Retention Inspection.



3. Set azimuth knob (3) to DIRECT. Turn clockwise slowly until detent engages. Be careful not to pass beyond detent engagement point.
4. Note location of vertical reticle line (4) relative to center of collimator reticle target.
5. Record reading on deflection counter (5) with detent engaged.
6. Slowly turn azimuth knob (3) clockwise until detent engages again.
7. Record reading on deflection counter (5). Compare with reading recorded in step 5. Readings must record increase of 5.0 ± 0.5 mils.
8. Check that vertical reticle line (4) has moved 5 mils from setting in step 4.




9. Repeat steps 3 through 8, using settings of 4800, 0000, and 1600 mils on azimuth counter (6).

TEST AND INSPECTION - Continued**Azimuth Knob 5-mil Click Lead Mechanism Inspection - Continued**

10. Slowly turn azimuth knob (3) through one complete revolution. Check that detent can be heard and felt each 5 mils.
11. Return azimuth knob (3) to INDIRECT.


Deflection Counter Setting Inspection**NOTE**

Watch all deflection counter numbers and azimuth counter numbers. Ensure each is legible and all settings between 0000 and 6399 can be made.




1. Turn azimuth knob (1) until reading of 0000 appears on deflection counter (2).
2. Turn azimuth knob (1) until reading of 6399 appears on deflection counter (2).

Correction Counter Setting and Excursion Range Inspection




1. Mount M137/M137A2/M137A3 telescope (1) on azimuth test fixture (2). Refer to Mounting Telescope to Azimuth Test Fixture.




2. Align vertical reticle line (3) on center of collimator reticle target and record reading on azimuth counter (4) to nearest 0.25 mil.

NOTE

Ensure movement of azimuth counter (4) during steps 3 and 5 is not over 0.25 mil.

TEST AND INSPECTION - Continued**Correction Counter Setting and Excursion Range Inspection - Continued**


3. Turn correction knob (5) clockwise as far as possible. Check that correction counter (6) reads on or between R-95 and R-99.
4. Check that vertical reticle line (3) is centered on collimator reticle target within ± 0.1 mil.
5. Turn correction knob (5) counterclockwise as far as possible. Check that correction counter (6) reads on or between L-95 and L-99.
6. Repeat step 4.
7. Turn correction knob (5) to set correction counter (6) at 00.

Checking Effect of Correction Counter Setting on Deflection Counter


1. Record reading on deflection counter (1) closest to 0.25 mil.
2. Turn correction knob (2) until correction counter (3) reads R-95.

3. Record reading on deflection counter (1).
4. Compare reading on deflection counter (1) recorded in step 1 with this reading. Reading of deflection counter should have increased 95 ± 0.5 mils.
5. Repeat steps 2, 3, and 4 using the L-95 setting on correction counter (3).
6. Check that reading on deflection counter (1) has decreased 95 ± 0.5 mils.

Torque Inspection




1. Place torque wrench adapter (1) on torque wrench (2). Place over azimuth knob (3).
2. Move torque wrench (2) and observe readings. Torque must be between 3 in.-lb (0.34 N-m) and 8 in.-lb (0.90 N-m). If torque cannot be met, tighten or loosen retainer (4).



3. Place torque wrench adapter (5) on torque wrench (6). Place over correction knob (7).
4. Move torque wrench (6) and observe readings. Torque must be between 10 in.-oz (0.07 N-m) and 20 in.-oz (0.14 N-m). If torque cannot be met, return M137/M137A2/M137A3 telescope to depot maintenance.


TEST AND INSPECTION - Continued

Torque Inspection - Continued



5. Place torque wrench adapter (8) on torque wrench (6). Place over elevation knob (9).
6. Move torque wrench (6) and observe readings. Torque must be between 5 in.-oz (0.03 N-m) and 40 in.-oz (0.28 N-m). If torque cannot be met, return M137/M137A2/M137A3 telescope to depot maintenance.
7. If torque requirements cannot be met, turn in M137/M137A2/M137A3 panoramic telescope.

Illumination Inspection



1. Take M137 telescope (1) into darkened area and wait 5 minutes, while eyes adjust to the darkness.

WARNING


RADIATION



**TRITIUM
GAS (H₃)**

If not illuminated, follow radioactive safety precautions in warning summary.

2. Turn on switch if testing M137A2/M137A3 telescope.
3. Ensure vertical reticle line (2) is clearly visible and illuminated.



4. Ensure deflection counter (3), azimuth counter (4), and correction counter (5) are clearly visible with even illumination.

PURGING


WARNING

RADIATION



**TRITIUM
GAS (H₃)**

Do not purge or charge any instrument that has a damaged or inoperative radioactive light source, to avoid possible radioactive contamination (M137 only).



Purge and charge M137 telescope (1) (refer to TM 750-116).

END OF WORK PACKAGE

CHAPTER 23

**DIRECT SUPPORT
MAINTENANCE INSTRUCTIONS
FOR
M138/M138A1 ELBOW TELESCOPE**

DIRECT SUPPORT

**M138/M138A1 ELBOW TELESCOPE
(1240-01-038-0530/1240-01-515-8264)**

**SERVICE UPON RECEIPT
SERVICE UPON RECEIPT OF MATERIEL**



SERVICE UPON RECEIPT OF MATERIEL

Unpacking

When a new or reconditioned M138/M138A1 elbow telescope is received, be aware of any shipping damage to packaging materiel. Report any damage on SF 364, Report of Discrepancy (ROD), as prescribed in AR 735-11-2. Retain packaging materiel for future use.

Checking Unpacked Equipment

1. Inspect the equipment for damage incurred during shipment. If the equipment has been damaged, report the damage on SF 361, Transportation Discrepancy Report.
2. Check the equipment against the packing slip to see if the shipment is complete. Report all discrepancies in accordance with applicable service instructions (e.g., for Army instructions, see DA PAM 738-750).
3. Check to see whether the equipment has been modified.



4. Check M138/M138A1 elbow telescope (1) for chipped paint, scuff marks, damaged or missing parts, cleanness, and smooth operation.
5. Inspect lenses (2). Lenses must be free of scratches, pits, and moisture.

SERVICE UPON RECEIPT OF MATERIEL - Continued**Checking Unpacked Equipment - Continued****WARNING****RADIATION****TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.

WARNING

Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries.

6. Check light sources (3). Light must be present and even throughout reticle cell assembly.

END OF WORK PACKAGE

DIRECT SUPPORT**M138 ELBOW TELESCOPE
(1240-01-038-0530)****M138 ELBOW TELESCOPE MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Grease (item 15, WP 0152 00)
Lens paper (item 17, WP 0152 00)
Lockwasher (4) (item 6, WP 0145 00)
Lockwasher (4) (item 9, WP 0145 00)
Lockwasher (8) (item 10, WP 0146 00)
O-ring (item 12A, WP 0146 00)
Optical lens cleaning compound (item 11, WP 0152 00)
Plastic bag (item 5, WP 0152 00)
Sealing compound (item 13, WP 0152 00)
Solvent cleaning compound (item 12, WP 0152 00)
Tape (item 20, WP 0152 00)
Wiping rag (item 18, WP 0152 00)

References

WP 0106 00
WP 0145 00
WP 0146 00


DISASSEMBLY

WARNING

RADIATION


TRITIUM
GAS (H₃)

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary.




1f694

1. Unscrew and remove safety relief valve (1).



1f695

2. Unscrew air valve cap (2) from fluid valve stem (3).
3. Remove valve core (4) from fluid valve stem (3).
4. Remove fluid valve stem (3).
5. Remove retaining strap (5) from fluid valve stem (3).




6. Remove four machine screws (6) and four lockwashers (7) from optical instrument latch set (8). Discard lockwashers.
7. Remove optical instrument latch set (8).

WARNING

If reticle cell assembly is not illuminated, do not perform any maintenance. Notify Radiation Safety Officer (RSO). Perform wipe test. If wipe test passes, place M138 elbow telescope in plastic bag (item 5, WP 0152 00), seal with tape (item 20, WP 0152 00), and send to depot maintenance.


NOTE

Diopter adapter assembly may be disassembled while installed on M138 elbow telescope.




8. Remove eight machine screws (9) and eight lockwashers (10). Discard lockwashers.
9. Lift diopter adapter assembly (11) and O-ring (12) from optical instrument housing (13) being careful not to damage locating pins in optical instrument housing. Remove and discard O-ring.


DISASSEMBLY - Continued



10. Remove sealing compound and loosen two setscrews (14).
11. Lift off dial pointer (15).
12. Loosen three setscrews (16).
13. Remove diopter scale (17) from knob (18).
14. Remove sealing compound and loosen setscrew (19).
15. Unscrew and remove sleeve nut (20).



16. Remove knob (18) from eyepiece cell assembly (21).
17. Remove telescope mount stop (22) by lifting off.



18. Remove two machine screws (23) and two lockwashers (24). Discard lockwashers.
19. Remove identification plate (25).
20. Remove two machine screws (26) and two lockwashers (27). Discard lockwashers.
21. Remove instruction plate (28).
22. If damaged, remove decal (29).

CLEANING

WARNING




Use cleaning compounds in well-ventilated area away from open flame. Cleaning compounds are harmful to skin and clothing and may give off harmful vapor. Exercise care whenever cleaning compounds are used.

1. Clean all parts with cleaning compound (item 12, WP 0152 00).
2. Wipe off excess cleaning compound with a clean wiping rag (item 18, WP 0152 00).
3. Clean reticle cell assembly and eyepiece cell assembly with lens paper (item 17, WP 0152 00) and optical lens cleaning compound (item 11, WP 0152 00).

REPAIR OR REPLACEMENT

1. If cracks are observed but light sources are still illuminated, remove body assembly and notify local Radiation Safety Officer (RSO). Perform wipe test under RSO supervision. Seal body assembly in a double plastic bag (item 5, WP 0152 00), secure with tape (item 20, WP 0152 00), and await wipe test results. If contaminated, dispose of assembly per RSO instructions. If assembly is not contaminated, replace parts as authorized (M138 only).
2. Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0145 00 and WP 0146 00.

ASSEMBLY




1. Position instruction plate (1) on optical instrument housing (2).

WARNING




Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.


2. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (3).
3. Install two new lockwashers (4) (item 9, WP 0145 00) and two machine screws (3).
4. Position identification plate (5) on optical instrument housing (2).
5. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (6).
6. Install two new lockwashers (7) (item 9, WP 0145 00) and two machine screws (6).
7. If removed, install new decal (8).



8. Place telescope mount stop (9) in slot on eyepiece cell assembly (10).
9. Apply grease (item 15, WP 0152 00) in knob (11) and install on eyepiece cell assembly (10).
10. Screw sleeve nut (12) on tight.
11. Tighten setscrew (13) and apply sealing compound (item 13, WP 0152 00).




12. Place dipter scale (14) over knob (11).
13. Tighten three setscrews (15).



14. Install dial pointer (16) and set in uppermost position perpendicular to mounting surface.



ASSEMBLY - Continued




15. Tighten two setscrews (17) and apply sealing compound (item 13, WP 0152 00).

NOTE


Before installing diopter adapter assembly, ensure that locating pins in optical instrument housing are not damaged.



16. Install new O-ring (18) (item 12A, WP 0146 00) in optical instrument housing (2).
17. Place diopter adapter assembly (19) over locating pins in optical instrument housing (2).
18. Apply sealing compound (item 13, WP 0152 00) to threads of eight machine screws (20).
19. Install and tighten eight new lockwashers (21) (item 10, WP 0146 00) and eight machine screws (20) and perform final inspection (WP 0106 00).



20. Apply sealing compound (item 13, WP 0152 00) to four machine screws (22). Install four new lockwashers (23) (item 6, WP 0145 00) and four machine screws to secure optical instrument latch set (24) to optical instrument housing (2).



21. Install retaining strap (25) on fluid valve stem (26).
22. Apply sealing compound (item 13, WP 0152 00) on fluid valve stem (26) and install.
23. Install valve core (27) and air valve cap (28).
24. Apply sealing compound (item 13, WP 0152 00) on safety relief valve (29) and install.
25. Clean lens with lens paper (item 17, WP 0152 00) and optical lens cleaning compound (item 11, WP 0152 00) after all maintenance and servicing.

END OF WORK PACKAGE

DIRECT SUPPORT**M138A1 ELBOW TELESCOPE
(1240-01-515-8264)****M138A1 ELBOW TELESCOPE MAINTENANCE
DISASSEMBLY, CLEANING, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Gasket (item 28, WP 0146 00)
Grease (item 15, WP 0152 00)
Lens paper (item 17, WP 0152 00)
Lockwasher (4) (item 6, WP 0145 00)
Lockwasher (2) (item 9, WP 0145 00)
Lockwasher (8) (item 10, WP 0146 00)
Lockwasher (3) (item 30, WP 0146 00)
Optical lens cleaning compound (item 11, WP 0152 00)
O-ring (item 12A, WP 0146 00)
Sealing compound (item 13, WP 0152 00)
Solvent cleaning compound (item 12, WP 0152 00)


References

WP 0106 00
WP 0145 00
WP 0146 00

DISASSEMBLY**WARNING**

Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries.

DISASSEMBLY - Continued



1fc716

NOTE


Cap and wire rope assembly can be procured separately (WP 0146 00).

1. Remove three machine screws (1), three lockwashers (2), cap and wire rope assembly (3), and battery (4) from battery enclosure (5). Discard lockwashers.


CAUTION

Use extreme care when removing battery enclosure. A short wire harness and connector on the battery enclosure is connected to a connector on a short wire harness on the fire control cover. These connectors and wire harnesses are easily damaged.

2. Carefully disconnect battery enclosure connector (6) from mounting bracket connector (7) and remove battery enclosure (5).
3. Remove gasket (8) from mounting bracket (9). Discard gasket.




4. Unscrew and remove safety relief valve (10).




5. Unscrew air valve cap (11) from fluid valve stem (12).
6. Remove valve core (13) from fluid valve stem (12).
7. Remove fluid valve stem (12).
8. Remove retaining strap (14) from fluid valve stem (12).

DISASSEMBLY - Continued




9. Remove four machine screws (15) and four lockwashers (16) from optical instrument latch set (17). Discard lockwashers.
10. Remove optical instrument latch set (17).




NOTE

Diopter adapter assembly may be disassembled while installed on M138A1 elbow telescope.


11. Remove eight machine screws (18) and eight lockwashers (19). Discard lockwashers.
12. Lift diopter adapter assembly (20) and O-ring (21) from optical instrument extension (22) of M138A1 elbow telescope being careful not to damage locating pins in optical instrument extension. Remove and discard O-ring.



13. Remove sealing compound and loosen two setscrews (23).
14. Lift off dial pointer (24).
15. Loosen three setscrews (25).
16. Remove diopter scale (26) from knob (27).
17. Remove sealing compound and loosen setscrew (28).
18. Unscrew and remove sleeve nut (29).



19. Remove knob (27) from eyepiece cell assembly (30).
20. Remove telescope mount stop (31) by lifting off.

DISASSEMBLY - Continued

1fc726

21. Remove two machine screws (32) and two lockwashers (33). Discard lockwashers.
22. Remove identification plate (34).

CLEANING**WARNING**


Use cleaning compounds in well-ventilated area away from open flame. Cleaning compounds are harmful to skin and clothing and may give off harmful vapor. Exercise care whenever cleaning compounds are used.

1. Clean all parts with cleaning compound (item 12, WP 0152 00).
2. Wipe off excess cleaning compound with a clean wiping rag (item 18, WP 0152 00).
3. Clean reticle cell assembly and eyepiece cell assembly with lens paper (item 17, WP 0152 00) and optical lens cleaning compound (item 11, WP 0152 00).

REPAIR OR REPLACEMENT

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0145 00 and WP 0146 00.

ASSEMBLY






1. Position identification plate (1) on optical instrument extension (2).

WARNING




Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

2. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (3).
3. Install two new lockwashers (4) (item 9, WP 0145 00) and two machine screws (3).




4. Place telescope mount stop (5) in slot on eyepiece cell assembly (6).
5. Apply grease (item 15, WP 0152 00) in knob (7) and install on eyepiece cell assembly (6).
6. Screw sleeve nut (8) on tight.
7. Tighten setscrew (9) and apply sealing compound (item 13, WP 0152 00).

ASSEMBLY - Continued




1fc733

8. Place diopter scale (10) over knob (7).
9. Tighten three setscrews (11).




1fc734

10. Install dial pointer (12) and set in uppermost position perpendicular to mounting surface.



1fc735


11. Tighten two setscrews (13) and apply sealing compound (item 13, WP 0152 00).



NOTE


Before installing diopter adapter assembly, ensure that locating pins in eyepiece extension are not damaged.

12. Install new O-ring (14) (item 12A, WP 0146 00) in optical instrument extension (2).
13. Place diopter adapter assembly (15) over locating pins in optical instrument extension (2).
14. Apply sealing compound (item 13, WP 0152 00) to threads of eight machine screws (16).
15. Install and tighten eight new lockwashers (17) (item 10, WP 0146 00) and eight machine screws (16) and perform final inspection (WP 0106 00).




16. Apply sealing compound (item 13, WP 0152 00) to four machine screws (18). Install four new lockwashers (19) (item 6, WP 0145 00) and four machine screws to secure optical instrument latch set (20) to optical instrument housing (21).

ASSEMBLY - Continued



17. Install retaining strap (22) on fluid valve stem (23).
18. Apply sealing compound (item 13, WP 0152 00) on fluid valve stem (23) and install.
19. Install valve core (24) and air valve cap (25).



20. Install new gasket (26) (item 28, WP 0146 00) on mounting bracket (27).
21. Carefully connect battery enclosure connector (28) to mounting bracket connector (29).

CAUTION


Be careful when assembling components. Do not pinch wire leads or connectors between parts.

22. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (30).
23. Install battery enclosure (31) on mounting bracket (27) with two new lockwashers (32) (item 30, WP 0146 00) and two machine screws (30).
24. Apply sealing compound (item 13, WP 0152 00) to threads of machine screw (33).

NOTE

If cap or wire rope assembly has been replaced, connect the two components.

25. Install new lockwasher (34) (item 30, WP 0146 00) and machine screw (33) through cap and wire rope assembly (35) into battery enclosure (31).
26. Install battery (36) in battery enclosure (31) and secure with cap and wire rope assembly (35).



27. Apply sealing compound (item 13, WP 0152 00) on safety relief valve (37) and install.
28. Clean lens with lens paper (item 17, WP 0152 00) and optical lens cleaning compound (item 11, WP 0152 00) after all maintenance and servicing.

END OF WORK PACKAGE

DIRECT SUPPORT**M138/M138A1 ELBOW TELESCOPE
(1240-01-038-0530/1240-01-515-8264)****OPTICAL INSTRUMENT LATCH SET MAINTENANCE
REMOVAL, DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY, INSTALLATION**

INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

Grease (item 15, WP 0152 00)


Lockwasher (4) (item 6, WP 0145 00)

Sealing compound (item 13, WP 0152 00)


References

WP 0145 00

WP 0147 00

REMOVAL

1. Remove four machine screws (1) and four lockwashers (2) from optical instrument latch set (3). Discard lockwashers.
2. Remove optical instrument latch set (3).


DISASSEMBLY

1. Remove headless straight pin (1).
2. Remove optical instrument latch (2) from latch holder (3).

REPAIR OR REPLACEMENT**NOTE**

Replace entire optical instrument latch set if damaged to the extent that the M138/M138A1 telescope does not lock securely in position.

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0145 00 and WP 0147 00.


ASSEMBLY

1. Apply light coat of grease (item 15, WP 0152 00) to optical instrument latch (1) and position in latch holder (2).

NOTE

Ensure headless straight pin is below surface of latch holder on both sides.

2. Install headless straight pin (3).

INSTALLATION**WARNING**

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

Apply sealing compound (item 13, WP 0152 00) to four machine screws (1). Install four new lockwashers (2) (item 6, WP 0145 00) and four machine screws to secure optical instrument latch set (3) to M138/M138A1 telescope.

END OF WORK PACKAGE

DIRECT SUPPORT**M138/M138A1 ELBOW TELESCOPE
(1240-01-038-0530/1240-01-515-8264)****OPTICAL INSTRUMENT LATCH MAINTENANCE
DISASSEMBLY, REPAIR OR REPLACEMENT, ASSEMBLY**

INITIAL SETUP:**Tools and Special Tools**

Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts



Grease (item 15, WP 0152 00)
Retaining ring (item 4, WP 0148 00)
Sealing compound (item 13, WP 0152 00)
Spring pin (item 6, WP 0148 00)

References



WP 0148 00

Equipment Conditions


Optical instrument latch set removed from M138/M138A1 elbow telescope (WP 0104 00)
Optical instrument latch removed from optical instrument latch set (WP 0104 00)

DISASSEMBLY

1. Remove two machine screws (1) from access cover (2).
2. Remove access cover (2) from lock-release latch (3).
3. Lift off helical extension spring (4).

DISASSEMBLY - Continued

4. Remove and discard retaining ring (5).
5. Remove headed shoulder pin (6) from lock-release lever (7).
6. Remove lock-release lever (7) from lock-release latch (3).




7. Remove spring pin (8) from headed shoulder pin (6). Discard spring pin.

REPAIR OR REPLACEMENT**NOTE**


Replace entire optical instrument latch if damaged to the extent that it will not hold the M138/M138A1 elbow telescope in proper position.

Repair is by replacement of authorized parts that do not meet inspection criteria. Refer to WP 0148 00.


ASSEMBLY



1. Install new spring pin (1) (item 6, WP 0148 00) in headed shoulder pin (2).
2. Apply light coat of grease (item 15, WP 0152 00) in lock-release lever (3) and place on lock-release latch (4).
3. Install headed shoulder pin (2) in lock-release lever (3).



4. Install new retaining ring (5) (item 4, WP 0148 00).
5. Install two ends of helical extension spring (6) in holes of lock-release latch (4) and headed shoulder pin (2).

ASSEMBLY - Continued

6. Place access cover (7) on lock-release latch (4).

WARNING

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor. Exercise care whenever sealing compound is used.

7. Apply sealing compound (item 13, WP 0152 00) to threads of two machine screws (8) and install to secure access cover (7).

END OF WORK PACKAGE

CHAPTER 24

DIRECT SUPPORT
FINAL INSPECTION INSTRUCTIONS
FOR
M138/M138A1 ELBOW TELESCOPE

DIRECT SUPPORT

**M138/M138A1 ELBOW TELESCOPE
(1240-01-038-0530/1240-01-515-8264)**

**FINAL INSPECTION INSTRUCTIONS
TEST AND INSPECTION**

INITIAL SETUP:

Test Equipment

- Dioptometer (item 13, WP 0149 00)
- Torque wrench adapter (item 17, WP 0149 00)

Tools and Special Tools

- Shop Set, Instrument and Fire Control: Field Maintenance, Basic Less Power (SC 4931-95-A07)
- Tool Kit, Electronic System Maintenance (SC 5180-95-B29)

Materials/Parts

- Grease (item 16, WP 0152 00)
- Sealing compound (item 13, WP 0152 00)
- Solvent cleaning compound (item 12, WP 0152 00)

References

- TM 750-116

Special Environmental Conditions

- Ambient temperature +60 °F (+16 °C) to +90 °F (+32 °C)

TASK AND INSPECTION

RADIATION



WARNING



**TRITIUM
GAS (H₃)**

When maintaining radioactively illuminated fire control equipment, follow radiation hazard procedures in warning summary (M138 only).

WARNING



Read and follow all WARNINGS in the WARNING SUMMARY in the front of this manual. Pay careful attention to those concerning batteries (M138A1 only).


TEST AND INSPECTION - Continued

NOTE

If the M138/M138A1 telescope being inspected fails to meet the required standards, ensure all maintenance authorized at the applicable level has been performed correctly. Then send the M138/M138A1 elbow telescope to the next level of maintenance.



Illustrations show the M138 telescope but also apply to the M138A1 telescope.

Visual Inspection




1. Check that all screws and lockwashers are present and tight.
2. Check that mounting surfaces (1) are clean and free of nicks and burrs.
3. Check that M138/M138A1 elbow telescope (2) is free of dirt, rust, and foreign matter; paint is not chipped; and all parts are present.



Eyepiece Focus Inspection




1. Place M138/M138A1 elbow telescope (1) on flat surface (2).
2. Place M138/M138A1 elbow telescope lens (3) close to any light-colored surface (4).



3. Adjust dioptrometer eyepiece (5) until the reticle is brought to its sharpest focus.



4. Set dioptrometer range scale (6) to 0.
5. Place dioptrometer (7) over M138/M138A1 elbow telescope eyepiece (8).
6. Turn knob (9) until pattern of reticle is sharpest and darkest.


TEST AND INSPECTION - Continued**Eyepiece Focus Inspection - Continued****WARNING**

Use sealing compound in well-ventilated area away from open flame. Sealing compound is harmful to skin and clothing and may give off harmful vapor.

- If diopter scale (10) does not read 0, loosen three setscrews (11), adjust diopter scale to read 0, and align dial pointer (12) with 0. Retighten setscrews and apply sealing compound (item 13, WP 0152 00).


NOTE

Observe focus of the reticle image during step 8. The focus should change over a minimum range of +3 diopters to -3 diopters.



- Rotate knob (9) clockwise as far as possible and note diopter scale setting. Diopter scale must read -3 diopters or greater. Rotate counterclockwise as far as possible and note diopter scale setting. Diopter scale must read +3 diopters or greater. If readings of -3 through +3 diopters cannot be achieved, repeat steps 3 through 7. If proper readings are still not obtained, return to depot maintenance.

Torque Inspection



1. Place torque wrench adapter (1) on torque wrench (2) and place over knob (3).
2. Measure torque. Torque required to move diopter scale should be between 2 in.-lb (0.23 N-m) and 5 in.-lb (0.57 N-m).

WARNING



Use cleaning compound in well-ventilated area away from open flame. Cleaning compound is harmful to skin and clothing and may give off harmful vapor.

3. If above torque cannot be obtained, apply coat of grease (item 16, WP 0152 00) to threads to increase torque or clean threads with cleaning compound (item 12, WP 0152 00) to decrease torque as necessary. If torque still cannot be obtained, return M138/M138A1 elbow telescope to depot maintenance.

Illumination Inspection - M138 Elbow Telescope

WARNING

RADIATION



TRITIUM
GAS (H₃)

If not illuminated, follow radioactive safety precautions in warning summary.

Take M138 elbow telescope into dark area and wait 15 minutes. Look through eyepiece and check that illumination is present and even.

TEST AND INSPECTION - Continued**Illumination Inspection - M138A1 Elbow Telescope**

Take M138A1 elbow telescope into dark area and look through eyepiece to check that illumination is present.

Purging**WARNING**

Before any tritium-illuminated device is purged, ensure that all radioactive light sources are fully illuminated. If not fully illuminated, send to depot for maintenance.

Purge and charge M138/M138A1 elbow telescope (TM 750-116).

END OF WORK PACKAGE

CHAPTER 25
PREEMBARKATION INSPECTION
OF MATERIAL

**DIRECT SUPPORT AND GENERAL SUPPORT
PREEMBARKATION INSPECTION OF MATERIAL
PREPARATION FOR STORAGE OR SHIPMENT**

PREPARATION FOR STORAGE OR SHIPMENT

General Instructions

Fire control instruments must be inspected for outward appearance, mechanical condition, and proper operation.

Instruments must approach new equipment standards of operation and appearance. The workmanship and quality must reflect the highest standards attainable.

Specific Instructions

Fire control instruments must conform to the following specifications for overseas shipment:

1. Condition of optical element. Lenses, prisms, reticles, and windows must be free from scratches, pits, and chips that will affect optical performance of the instrument.
2. Functioning of mechanical parts. Mechanical parts must operate smoothly without binding or rough motion. Parts must be free from grit and must be properly lubricated.
3. Illumination of radioactive parts. The level vials, reticles, and counter dials must illuminate properly.
4. General appearance and condition of the instruments.
 - a. All parts of the instruments must be present and free from defects.
 - b. Paint must cover all specified surfaces. Repaint if painted surfaces show signs of damage.
 - c. All optics must be free from any internal dirt and moisture. Excessive dirt or moisture indicates a breakdown in sealing and is cause for rejection of the instrument.
 - d. All scales must be read easily. All numbers and divisions must be clearly defined.
 - e. Any fire control instrument failing to meet the requirements of the final inspection is unsatisfactory for overseas shipment.
 - f. All warning labels must be present and legible.

END OF WORK PACKAGE

CHAPTER 26
SUPPORTING INFORMATION

DIRECT SUPPORT AND GENERAL SUPPORT
REFERENCES

SCOPE

This work package lists all field manuals, forms, miscellaneous publications, and technical manuals referenced in this manual.

FIELD MANUALS

FM 4-25.11 First Aid

FORMS

DA Form 2028 Recommended Changes to Publications and Blank Forms

MISCELLANEOUS PUBLICATIONS

AR 750-1 Army Materiel Maintenance Policy

CTA 8-100 Army Medical Department Expendable/Durable Items

CTA 50-970 Expendable/Durable Items (Except Medical, Class V, Repair Parts, and Heraldic Items)

DA PAM 738-750 Functional Users Manual for The Army Maintenance Management System (TAMMS)

NRC Form 3 Notice to Employees

10CFR Part 19 Notices, Instructions and Reports to Workers; Inspections

AR 385-63 Policies and Procedures for Firing Ammunition for Training, Target Practice and Combat

SF 368 Product Quality Deficiency Report

SF 364 Report of Discrepancy

10CFR Part 21 Reporting of Defects and Noncompliance

AR 735-11-2 Reporting of Item and Packaging Discrepancies

10CFR Part 20 Standards for Protection against Radiation

SF 361 Transportation Discrepancy Report

TECHNICAL MANUALS

TM 9-1025-211-34 Direct Support and General Support Maintenance Manual for Howitzer, Medium, Towed: 155-MM, M198 (1025-01-026-6648)

TM 9-254 General Maintenance Procedures for Fire Control Materiel

TM 750-116 General Procedures for Purging and Charging of Fire Control

TM 9-1025-211-10 Operator's Manual for Howitzer, Medium, Towed: 155-MM, M198 (1025-01-026-6648)

TM 9-1025-215-10/TM-10407A-10/1 Operator's Manual for Howitzer, Medium, Towed: 155-MM, M777 (NSN 1025-01-445-0991) and Howitzer, Medium, Towed: 155-MM, M777A1 (NSN TBD)

TM 9-1025-211-20&P Organizational Maintenance Manual (Including Repair Parts and Special Tools List) for Howitzer, Medium, Towed: 155-MM, M198 (1025-01-026-6648)

TM 9-1025-215-25&P/
TM-10407A-25&P Unit, Direct Support, and General Support Maintenance Manual (Including Repair Parts and Special Tools List) for Howitzer, Medium, Towed: 155-MM, M777 (NSN 1025-01-445-0991) and Howitzer, Medium, Towed: 155-MM, M777A1 (NSN TBD)

END OF WORK PACKAGE

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE**M198/M777 HOWITZER FIRE CONTROL
(NSN 1025-01-026-6648/1025-01-445-0991)****INTRODUCTION TO REPAIR PARTS AND SPECIAL TOOLS LIST (RPSTL)**

SCOPE

This RPSTL lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for performance of direct support and general support maintenance of the M198/M777 Howitzer Fire Control. It authorizes the requisitioning, issue, and disposition of spares, repair parts, and special tools as indicated by the source, maintenance, and recoverability (SMR) codes.

GENERAL

In addition to the Introduction work package, this RPSTL is divided into the following work packages.

1. **Repair Parts List Work Packages.** Work packages containing lists of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. These work packages also include parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Sending units, brackets, filters, and bolts are listed with the component they mount on. Bulk materials are listed by item name in FIG. BULK at the end of the work packages. Repair parts kits are listed separately in their own functional group and work package. Repair parts for reparable special tools are also listed in a separate work package. Items listed are shown on the associated illustrations.
2. **Special Tools List Work Package.** Work packages containing lists of special tools, special TMDE, and special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in the DESCRIPTION AND USABLE ON CODE (UOC) column). Tools that are components of common tool sets and/or Class VII are not listed.
3. **Cross-Reference Indexes Work Packages.** There are two cross-reference index work packages in this RPSTL: the National Stock Number (NSN) Index work package and the Part Number (P/N) Index work package. Both of the work packages refer you to the figure and item number.

EXPLANATION OF COLUMNS IN THE REPAIR PARTS LIST AND SPECIAL TOOLS LIST WORK PACKAGES

ITEM NO. (Column (1)). Indicates the number used to identify items called out in the illustration.

SMR CODE (Column (2)). The SMR code containing supply/requisitioning information, maintenance level authorization criteria, and disposition instruction, as shown in the following breakout:

EXPLANATION OF COLUMNS IN THE REPAIR PARTS LIST AND SPECIAL TOOLS LIST WORK PACKAGES - Continued

<u>Source Code</u>	<u>Maintenance Code</u>	<u>Recoverability Code</u>
— xx —	— xx —	— x —
1st two positions: How to get an item.	3rd position: Who can install, replace, or use the item.	4th position: Who can do complete repair* on the item.
		5th position: Who determines disposition action on unserviceable items.

*Complete Repair: Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "Repair" function in a use/user environment in order to restore serviceability to a failed item.

Source Code. The source code tells you how to get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follow:

Source Code

Application/Explanation

PA
PB
PC
PD
PE
PF
PG

Stock items; use the applicable NSN to requisition/request items with these source codes. They are authorized to the level indicated by the code entered in the 3rd position of the SMR code.

NOTE: Items coded PC are subject to deterioration.

KD
KF
KB

Items with these codes are not to be requested/requisitioned individually. They are part of a kit which is authorized to the maintenance level indicated in the 3rd position of the SMR code. The complete kit must be requisitioned and applied.

MO-	Made at unit/ AVUM level	Items with these codes are not to be requisitioned/requested individually. They must be made from bulk material which is identified by the P/N in the DESCRIPTION AND USABLE ON CODE (UOC) column and listed in the bulk material group work package of the RPSTL. If the item is authorized to you by the 3rd position code of the SMR code, but the source code indicates it is made at higher level, order the item from the higher level of maintenance.
MF-	Made at DS/ AVIM level	
MH-	Made at GS level	
ML-	Made at SRA	
MD-	Made at depot	
AO-	Assembled by unit/AVUM level	Items with these codes are not to be requested/requisitioned individually. The parts that make up the assembled item must be requisitioned or fabricated and assembled at the level of maintenance indicated by the source code. If the 3rd position code of the SMR code authorizes you to replace the item, but the source code indicates the item is assembled at a higher level, order the item from the higher level of maintenance.
AF-	Assembled by DS/AVIM level	
AH-	Assembled by GS level	
AL-	Assembled by SRA	
AD-	Assembled by Depot	
XA		Do not requisition an XA-coded item. Order the next higher assembly. (Refer to NOTE below.)
XB		If an item is not available from salvage, order it using the CAGEC and P/N.
XC		Installation drawings, diagrams, instruction sheets, field service drawings; identified by manufacturer's P/N.
XD		Item is not stocked. Order an XD-coded item through normal supply channels using the CAGEC and P/N given, if no NSN is available.

NOTE

Cannibalization or controlled exchange, when authorized, may be used as a source of supply for items with the above source codes, except for those source coded "XA" or those aircraft support items restricted by requirements of AR 750-1.

Maintenance Code. Maintenance codes tell you the level(s) of maintenance authorized to use and repair support items. The maintenance codes are entered in the third and fourth positions of the SMR code as follows:

Third Position. The maintenance code entered in the third position tells you the lowest maintenance level authorized to remove, replace, and use an item. The maintenance code entered in the third position will indicate authorization to the following levels of maintenance:

EXPLANATION OF COLUMNS IN THE REPAIR PARTS LIST AND SPECIAL TOOLS LIST WORK PACKAGES - Continued

<u>Maintenance Code</u>	<u>Application/Explanation</u>
C -	Crew or operator maintenance done within unit/AVUM maintenance.
O -	Unit level/AVUM maintenance can remove, replace, and use the item.
F -	Direct support/AVIM maintenance can remove, replace, and use the item.
H -	General support maintenance can remove, replace, and use the item.
L -	Specialized repair activity can remove, replace, and use the item.
D -	Depot can remove, replace, and use the item.

Fourth Position. The maintenance code entered in the fourth position tells you whether or not the item is to be repaired and identifies the lowest maintenance level with the capability to do complete repair (perform all authorized repair functions).

NOTE

Some limited repair may be done on the item at a lower level of maintenance, if authorized by the Maintenance Allocation Chart (MAC) and SMR codes.

<u>Maintenance Code</u>	<u>Application/Explanation</u>
O -	Unit/AVUM is the lowest level that can do complete repair of the item.
F -	Direct support/AVIM is the lowest level that can do complete repair of the item.
H -	General support is the lowest level that can do complete repair of the item.
L -	Specialized repair activity is the lowest level that can do complete repair of the item.
D -	Depot is the lowest level that can do complete repair of the item.
Z -	Nonreparable. No repair is authorized.
B -	No repair is authorized. No parts or special tools are authorized for the maintenance of "B" coded item. However, the item may be reconditioned by adjusting, lubricating, etc., at the user level.

Recoverability Code. Recoverability codes are assigned to items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the SMR code as follows:

**Recoverability
Code**

Application/Explanation

Z	-	Nonreparable item. When unserviceable, condemn and dispose of the item at the level of maintenance shown in the third position of the SMR code.
O	-	Reparable item. When uneconomically reparable, condemn and dispose of the item at the unit level.
F	-	Reparable item. When uneconomically reparable, condemn and dispose of the item at the direct support level.
H	-	Reparable item. When uneconomically reparable, condemn and dispose of the item at the general support level.
D	-	Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal of item are not authorized below depot level.
L	-	Reparable item. Condemnation and disposal not authorized below Specialized Repair Activity (SRA).
A	-	Item requires special handling or condemnation procedures because of specific reasons (such as precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals/directives for specific instructions.

NSN (Column (3)). The NSN for the item is listed in this column.

CAGEC (Column (4)). The Commercial and Government Entity Code (CAGEC) is a five-digit code which is used to identify the manufacturer, distributor, or Government agency/activity that supplies the item.

PART NUMBER (Column (5)). Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When you use an NSN to requisition an item, the item you receive may have a different P/N from the number listed.

DESCRIPTION AND USABLE ON CODE (UOC) (Column (6)). This column includes the following information:

1. The federal item name and, when required, a minimum description to identify the item.
2. P/Ns of bulk materials are referenced in this column in the line entry to be manufactured or fabricated.

EXPLANATION OF COLUMNS IN THE REPAIR PARTS LIST AND SPECIAL TOOLS LIST WORK PACKAGES - Continued

3. Hardness Critical Item (HCI). A support item that provides the equipment with special protection from electromagnetic pulse (EMP) damage during a nuclear attack.
4. The statement END OF FIGURE appears just below the last item description in column (6) for a given figure in both the repair parts list and special tools list work packages.

QTY (Column (7)). The QTY (quantity per figure) column indicates the quantity of the item used in the breakout shown on the illustration/figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column instead of a quantity indicates that the quantity is variable and quantity may change from application to application. Shims are a good example.

EXPLANATION OF CROSS-REFERENCE INDEXES WORK PACKAGE FORMAT AND COLUMNS

1. National Stock Number (NSN) Index Work Package.

STOCK NUMBER Column. This column lists the NSN in National item identification number (NIIN) sequence. The NIIN consists of the last nine digits of the NSN.

$$\frac{\text{NSN}}{\text{NIIN}}$$
 (e.g., $\frac{5385-01-574-1476}{\text{NIIN}}$)

When using this column to locate an item, ignore the first four digits of the NSN. However, the complete NSN should be used when ordering items by stock number.

FIG. Column. This column lists the number of the figure where the item is identified/located. The figures are in numerical order in the repair parts list and special tools list work packages.

ITEM Column. The item number identifies the item associated with the figure listed in the adjacent FIG. column. This item is also identified by the NSN listed on the same line.

2. Part Number (P/N) Index Work Package. P/Ns in this index are listed in ascending alphanumeric sequence (vertical arrangement of letter and number combinations which places the first letter or digit of each group in order A through Z, followed by the numbers 0 through 9 and each following letter or digit in like order).

PART NUMBER Column. Indicates the P/N assigned to the item.

FIG. Column. This column lists the number of the figure where the item is identified/located in the repair parts list and special tools list work packages.

ITEM Column. The item number is the number assigned to the item as it appears in the figure referenced in the adjacent figure number column.

SPECIAL INFORMATION

UOC. The UOC appears in the lower left corner of the Description Column heading. Usable on codes are shown as "UOC:..." in the Description column (justified left) on the first line under the applicable item/nomenclature. Uncoded items are applicable to all models. Identification of the UOCs used in the RPSTL are:

<u>Code</u>	<u>Used on</u>
F39	M17 Fire Control Quadrant
BM3	M17A1 Fire Control Quadrant
F40	M18 Fire Control Quadrant
BM6	M18A1 Fire Control Quadrant
F41	M138 Elbow Telescope
BM5	M138A1 Elbow Telescope
F42	M137 Panoramic Telescope
BH6	M137A2 Panoramic Telescope
BH5	M137A3 Panoramic Telescope
F43	M172 Telescope and Quadrant Mount
BN3	M172A1 Telescope and Quadrant Mount
F44	M171 Telescope and Quadrant Mount
BM4	M171A1 Telescope and Quadrant Mount

Fabrication Instructions. Bulk materials required to manufacture items are listed in the bulk material functional group of this RPSTL. Part numbers for bulk materials are also referenced in the Description Column of the line item entry for the item to be manufactured/fabricated. Detailed fabrication instructions for items source coded to be manufactured or fabricated are found in the appropriate maintenance work packages of this manual.

Index Numbers. Items which have the word BULK in the figure column will have an index number shown in the item number column. This index number is a cross-reference between the NSN / P/N work packages and the bulk material list in the repair parts list work package.

Illustrations List. The illustrations in this RPSTL contain unit authorization items. Illustrations published in the maintenance portion of this manual that contain unit authorized items also appear in this RPSTL.

HOW TO LOCATE REPAIR PARTS

1. When NSN or P/Ns Are Not Known.

First. Using the table of contents, determine the assembly group to which the item belongs. This is necessary since figures are prepared for assembly groups and subassembly groups, and lists are divided into the same groups.

Second. Find the figure covering the functional group to which the item belongs.

Third. Identify the item on the figure and note the item number(s).

Fourth. Look in the repair parts list work package for the figure and item numbers. The NSNs and part numbers are on the same line as the associated item numbers.

2. When NSN Is Known.

First. If you have the NSN, look in the STOCK NUMBER column of the NSN index. The NSN is arranged in NIIN sequence. Note the figure and item number next to the NSN.

Second. Turn to the figure and locate the item number. Verify that the item is the one you are looking for.

HOW TO LOCATE REPAIR PARTS - Continued

3. When P/N Is Known.

First. If you have the P/N and not the NSN, look in the PART NUMBER column of the P/N index work package. Identify the figure and item number.

Second. Look up the item on the figure in the repair parts list work package.

END OF WORK PACKAGE

DIRECT SUPPORT AND GENERAL SUPPORT

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)**

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
11729530/13005101/11729525/13005102**

REPAIR PARTS LIST




Figure 1. M17 Fire Control Quadrant, 11729530; M17A1 Fire Control Quadrant, 13005101;
M18 Fire Control Quadrant, 11729525; and M18A1 Fire Control Quadrant, 13005102.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 1. QUADRANTS, FIRE CONTROL M17, PN 11729530; M18, PN 11729525; M17A1, PN 13005101; M18A1, PN 13005102	
1	XAHZZ		19200	11729578	BASE ASSEMBLY USED ON M17,M18, M17A1,M18A1.....	1
2	XAHZZ		19200	11729542	HOUSING ASSEMBLY USED ON M17,M18, M17A1,M18A1.....	1
3	PAHZZ	1290010449857	19200	11729546	WORM SHAFT ASSEMBLY USED ON THE M17 AND M17A1.....	1
					UOC:BM3,F39	
3	PAHZZ	1290010463777	19200	11729548	WORM SHAFT ASSEMBLY USED ON THE M18 AND M18A1.....	1
					UOC:BM6,F40	
4	PAHHH	1290010437490	19200	11729529	COUNTER ASSEMBLY, ROTATING USED ON M17,M18,M17A1,M18A1 SEE FIG 6 FOR ASSY BREAKDOWN.....	1
5	XAHHA		19200	11729532	COVER,ACCESS USED ON M17 AND M18 ONLY SEE FIG 5 FOR ASSY BREAKDOWN.....	1
					UOC:F39,F40	
5	PAHHD	5340015176141	19200	13005079	COVER,ACCESS USED ON M17A1,M18A1 ONLY SEE FIG 5 FOR ASSY BREAKDOWN.....	1
					UOC:BM3,BM6	
6	PAHZZ	1290010437491	19200	11729543	KNOB ASSEMBLY,CORRE CTION USED ON M17,M18,M17A1,M18A1.....	1
7	PCHHA	1290010480193	19200	10554827	LEVEL ASSEMBLY,FIRE CONTROL (ELEVATION LEVEL VIAL ASSY) USED ON M17 AND M18 ONLY SEE FIG 4 FOR ASSY BREAKDOWN.....	1
					UOC:F39,F40	
7	PAHHH	1290015172169	19200	13005080	LEVEL ASSEMBLY,FIRE CONTROL (ELEVATION LEVEL VIAL ASSY) USED ON M17A1,M18A1 ONLY SEE FIG 4 FOR ASSY BREAKDOWN.....	1
					UOC:BM3,BM6	
8	PCHHA	1290010463687	19200	11729551	LEVEL,FIRE CONTROL USED ON M18 (CROSS LEVEL VIAL ASSY) SEE FIG 7 FOR ASSY BREAKDOWN.....	1
					UOC:F40	
8	PADDD	1290015172170	19200	13005081	LEVEL,FIRE CONTROL CONTROL (CROSS LEVEL VIAL ASSY) USED ON M18A1 SEE FIG 7 FOR ASSY BREAKDOWN.....	1
					UOC:BM6	

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)**

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
11729530/13005101/11729525/13005102
EXTERNAL PARTS**

REPAIR PARTS LIST




Figure 2. M17 Fire Control Quadrant, 11729530; M17A1 Fire Control Quadrant, 13005101; M18 Fire Control Quadrant, 11729525; and M18A1 Fire Control Quadrant, 13005102, External Parts.

SECTION II			TM9-1240-375-34&P		(6)	(7)
(1)	(2)	(3)	(4)	(5)		
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 2. QUADRANTS, FIRE CONTROL M17, PN 11729530; M18, PN 11729525; M17A1, PN 13005101; M18A1, PN 13005102, EXTERNAL PARTS	
1	PAOZZ	5305007243478	80205	MS51031-37	SETSCREW USED ON M17,M18,M17A1, M18A1.....	1
2	PAOZZ	5305009127281	96906	MS35276-247	SCREW,MACHINE USED ON M17,M18, M17A1,M18A1.....	1
3	PAFZZ	5305000546670	96906	MS51957-45	SCREW,MACHINE USED ON M17,M18, M17A1,M18A1.....	4
4	PAFZZ	5310009338119	80205	MS35338-137	WASHER,LOCK USED ON M17,M18,M17A1, M18A1.....	6
5	PAFZZ	1290010449858	19200	10556192	REFLECTOR USED ON M17,M18,M17A1, M18A1.....	1
6	PAFZZ	5305000546651	96906	MS51957-27	SCREW,MACHINE USED ON M17,M18, M17A1,M18A1.....	2
7	PAFZZ	1290010446912	19200	10556191	REFLECTOR USED ON M18,M18A1.....	1
8	PAFZZ	5305000546653	96906	MS51957-29	UOC:BM6,F40 SCREW,MACHINE USED ON M18,M18A1....	2
9	PAFZZ	5310009296395	80205	MS35338-136	UOC:BM6,F40 WASHER,LOCK USED ON M18,M18A1.....	2
10	PAHZZ	5305000546653	96906	MS51957-29	UOC:BM6,F40 SCREW,MACHINE USED ON M18,M18A1....	1
11	PAHZZ	5310009296395	80205	MS35338-136	UOC:BM6,F40 WASHER,LOCK USED ON M18,M18A1.....	1
12	PAFZZ	5305000546636	96906	MS51957-2	UOC:BM6,F40 SCREW,MACHINE USED ON M17,M18.....	4
13	PAFZZ	5310009282690	80205	MS35338-134	UOC:F39,F40 WASHER,LOCK USED ON M17,M18.....	4
14	PAFZZ	9905002572751	19200	11729581	UOC:F39,F40 PLATE,INSTRUCTION CURIES QTY LEVEL VIALS USED ON M17,M18.....	1
15	PAFZZ	9905002572750	19200	11729582	UOC:F39,F40 PLATE,INSTRUCTION CURIES QTY COUNTER USED ON M17,M18.....	1
16	PAFZZ	5315008340745	96906	MS16555-631	UOC:F39,F40 PIN,STRAIGHT,HEADLE USED ON M17, M18,M17A1,M18A1.....	1
17	PAHZZ	5331001498859	96906	MS9021-046	O-RING USED ON M17,M18,M17A1,M18A1.	1
18	PAHZZ	5310009296395	80205	MS35338-136	WASHER,LOCK USED ON M17,M18,M17A1, M18A1.....	9
19	PAHZZ	5305000546654	96906	MS51957-30	SCREW,MACHINE USED ON M17,M18, M17A1,M18A1.....	7
20	PAOZZ	5310009296395	80205	MS35338-136	WASHER,LOCK USED ON M17A1,M18A1....	1
21	PAOZZ	5305000546650	96906	MS51957-26	UOC:BM3,BM6 SCREW,MACHINE USED ON M17A1,M18A1..	1
22	PAOZZ	5340014857535	19200	12984751	UOC:BM3,BM6 STRAP,RETAINING USED ON M17A1,M18A1	1
					UOC:BM3,BM6	

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
23	PAOZZ	5305009591082	80205	MS16995-18	SCREW,MACHINE USED ON M17A1,M18A1.. UOC:BM3,BM6	4
24	PAOZZ	5310009296395	80205	MS35338-136	WASHER,LOCK USED ON M17A1,M18A1.... UOC:BM3,BM6	4
25	PAOZZ	6160014857533	19200	12984725	BATTERY BOX USED ON M17A1,M18A1.... UOC:BM3,BM6	1
26	PAOZZ	5330014858715	19200	12984723	GASKET USED ON M17A1,M18A1..... UOC:BM3,BM6	1
27	PAFZZ	5305000545635	96906	MS51957-1	SCREW,MACHINE USED ON M17,M18, M17A1,M18A1.....	2
28	PAFZZ	5310009282690	80205	MS35338-134	WASHER,LOCK USED ON M17,M18,M17A1, M18A1.....	2
29	PAFZZ	9905010686443	19200	11729593	PLATE,IDENTIFICATIO MODEL AND SERIAL NUMBER M17 ONLY.....	1
29	PAFZZ	9905010482788	19200	11729588	UOC:F39 PLATE,IDENTIFICATIO MODEL AND SERIAL NUMBER M18 ONLY.....	1
29	PAFZZ	9905015172173	19200	13005107	UOC:F40 PLATE,IDENTIFICATIO MODEL AND SERIAL NUMBER M17A1 ONLY.....	1
29	PAFZZ	9905015172172	19200	13005108	UOC:BM3 PLATE,IDENTIFICATIO MODEL AND SERIAL NUMBER M18A1 ONLY.....	1
30	PAFZZ	4820012109568	19200	9360120	UOC:BM6 VALVE,SAFETY RELIEF USED ON M17, M18,M17A1,M18A1.....	1
31	PAFZZ	4820001141096	96906	MS51607-1	STEM,FLUID VALVE USED ON M17,M18, M17A1,M18A1.....	1
32	PAOZZ	2640000603543	96906	MS51377-2	VALVE CORE.....	1
33	PAFZZ	5340004644792	19200	10516567	STRAP,RETAINING USED ON M17,M18, M17A1,M18A1.....	1
34	PAOZZ	4820012350223	19200	8200055	CAP,AIR VALVE USED ON M17,M18, M17A1,M18A1.....	1
35	PAHZZ	5305000546652	96906	MS51957-28	SCREW,MACHINE USED ON M17,M18, M17A1,M18A1.....	2
36	PAHZZ	5331005519573	81343	AS3578-017	O-RING USED ON M17,M18,M17A1,M18A1.	1
37	PAOZZ	5305007243454	80205	MS51031-35	SETSCREW USED ON M17,M18,M17A1, M18A1.....	2
38	PAOZZ	5340010463649	19200	10554828	PAD,CUSHIONING USED ON M17,M18, M17A1,M18A1.....	2
39	PAFZZ	1290010437476	19200	10554825	PLATE,ADJUSTING USED ON M17,M18, M17A1,M18A1.....	1
40	PAOZZ	5310009746623	80205	MS35338-140	WASHER,LOCK USED ON M17,M18,M17A1, M18A1.....	4
41	PAOZZ	5306008174989	96906	MS35307-333	BOLT,MACHINE USED ON M17,M17A1..... UOC:BM3,F39	4
41	PAOZZ	5306006387719	80205	MS35308-333	BOLT,MACHINE USED ON M18,M18A1..... UOC:BM6,F40	4

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)**

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
11729530/13005101/11729525/13005102
INTERNAL PARTS**

REPAIR PARTS LIST




Figure 3. M17 Fire Control Quadrant, 11729530; M17A1 Fire Control Quadrant, 13005101; M18 Fire Control Quadrant, 11729525; and M18A1 Fire Control Quadrant, 13005102, Internal Parts.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 3. QUADRANTS, FIRE CONTROL M17, PN 11729530; M18, PN 11729525; M17A1, PN 13005101; M18A1, PN 13005102, INTERNAL PARTS	
1	PADZZ	5305007015061	96906	MS51958-45	SCREW,MACHINE USED ON M17,M18, M17A1,M18A1.....	8
2	PADZZ	5310009338119	80205	MS35338-137	WASHER,LOCK USED ON M17,M18,M17A1, M18A1.....	17
3	PADZZ	5330013416762	19200	9360585	SEAL,PLAIN USED ON M17,M18,M17A1, M18A1.....	1
4	XADZZ		19200	11729536	GEAR SECTOR,WORM WHEEL USED ON M17,M17A1.....	1
4	XADZZ		19200	11729535	GEAR SECTOR,WORM WHEEL USED ON M18,M18A1.....	1
5	PADZZ	5315006821727	80205	MS16555-625	PIN,STRAIGHT,HEADLE USED ON M17, M18,M17A1,M18A1.....	1
6	PADZZ	5305000546668	96906	MS51957-43	SCREW,MACHINE USED ON M17,M18, M17A1,M18A1.....	9
7	XADZZ		19200	11729553	INSERT,HOUSING USED ON M17,M18, M17A1,M18A1.....	1
8	XADZZ		96906	MS29513-044	O-RING USED ON M17,M18,M17A1,M18A1.	1
9	XADZZ		19200	11729552	RING USED ON M17,M18,M17A1,M18A1...	1
10	PAHZZ	5315008340745	96906	MS16555-631	PIN,STRAIGHT,HEADLE USED ON M17, M18,M17A1,M18A1.....	1
11	PAHZZ	5355010470490	19200	11729580	KNOB USED ON M17,M18,M17A1,M18A1...	1
12	PAHZZ	5310010470433	19200	11741635	WASHER,SPRING TENS USED ON M17, M18,M17A1,M18A1.....	1
13	PAHZZ	5330010501549	19200	11741636	RETAINER,PACKING USED ON M17,M18, M17A1,M18A1.....	1
14	PAHZZ	5331002483836	81343	MS29513-12	O-RING USED ON M17,M18,M17A1,M18A1.	1
15	PAHZZ	1290010437493	19200	11729540	RETAINER,ELEVATION USED ON M17,M18, M17A1,M18A1.....	1
16	PAHZZ	5310010459594	19200	11729586	WASHER,KEY USED ON M17,M18,M17A1, M18A1.....	1
17	PAHZZ	5331005506617	81343	AS3578-221	O-RING USED ON M17,M18,M17A1,M18A1.	1
18	PAHZZ	5305000546652	96906	MS51957-28	SCREW,MACHINE USED ON M17,M18, M17A1,M18A1.....	3
19	PAHZZ	5310009338118	80205	MS35338-135	WASHER,LOCK USED ON M17,M18,M17A1, M18A1.....	3
20	PAHZZ	1290010437494	19200	11729558	RETAINER,SPRING PLU USED ON M17, M18,M17A1,M18A1.....	1
21	PAHZZ	5310010459595	19200	11729587	WASHER,KEY USED ON M17,M18,M17A1, M18A1.....	1
22	PAHZZ	5331005582310	81343	AS3578-013	O-RING USED ON M17,M18,M17A1,M18A1.	1
23	PAHZZ	5360009789584	19200	8587557	SPRING,HELICAL,COMP USED ON M17, M18,M17A1,M18A1.....	1
24	PAHZZ	3120009837313	19200	8215750	BEARING,V USED ON M17,M18,M17A1, M18A1.....	1
25	PADZZ	5305000545647	96906	MS51957-13	SCREW,MACHINE USED ON M17,M18, M17A1,M18A1.....	2

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
26	PADZZ	1290010449856	19200	11746330	STOP,SECTOR GEAR USED ON M17,M18, M17A1,M18A1.....	2

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)**

**FIRE CONTROL LEVEL ASSEMBLY
(ELEVATION LEVEL VIAL ASSEMBLY)
10554827/13005080**

REPAIR PARTS LIST




Figure 4. Fire Control Level Assembly (Elevation Level Vial Assembly), 10554827/13005080.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 4. LEVEL ASSEMBLY, FIRE CONTROL (ELEVATION LEVEL VIAL ASSY) M17 AND M18 PN 10554827; M17A1 AND M18A1 PN 13005080	
1	PAHZZ	5340007597626	19200	7597626	COVER,ACCESS USED ON M17,M18,M17A1, M18A1.....	1
2	XAHZZ		19200	10554826	HOLDER,LEVEL VIAL USED ON M17,M18, M17A1,M18A1.....	1
3	PCHZA	1290002572769	19200	11729512	LEVEL,FIRE CONTROL USED ON M17,M18. UOC:F39,F40	1
3	PAHZZ	1290006921493	19200	8202183	LEVEL,FIRE CONTROL USED ON M17A1, M18A1.....	1
					UOC:BM3,BM6	
4	PAFZZ	5365008962251	19200	8202177	BUSHING,ECCENTRIC USED ON M17,M18, M17A1,M18A1.....	1
5	PAFZZ	5365006921492	19200	8202181	RING,EXTERNALLY THR USED ON M17, M18,M17A1,M18A1.....	1
6	PAHZZ	5315008170889	96906	MS16555-601	PIN,STRAIGHT,HEADLE USED ON M17, M18,M17A1,M18A1.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)**

**ACCESS COVER
11729532/13005079**

REPAIR PARTS LIST




Figure 5. Access Cover, 11729532/13005079.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 5. COVER, ACCESS M17 AND M18 PN 11729532; M17A1 AND M18A1 PN 13005079	
1	PADZZ	5305000545636	96906	MS51957-2	SCREW,MACHINE USED ON M17,M18..... UOC:F39,F40	4
2	PADZZ	5310009282690	80205	MS35338-134	WASHER,LOCK USED ON M17,M18..... UOC:F39,F40	4
3	XDDZZ		19200	11729570	CLAMP,BRIDGE USED ON M17,M18..... UOC:F39,F40	4
4	PCDZA	6240010438209	19200	11729559	LAMP,NUCLEAR,ASSEMB USED ON M17,M18 UOC:F39,F40	4
5	XAHZZ		19200	11729528	COVER,QUADRANT USED ON M17,M18, M17A1,M18A1.....	1
6	PAHZZ	6650000664999	19200	8626400	WINDOW,OPTICAL INST USED ON M17, M18,M17A1,M18A1.....	1
7	XAHZZ		19200	11729556	PLATE,WINDOW USED ON M17,M18,M17A1, M18A1.....	1
8	PAHZZ	5310009282690	80205	MS35338-134	WASHER,LOCK USED ON M17,M18,M17A1, M18A1.....	4
9	PAHZZ	5305000545636	96906	MS51957-2	SCREW,MACHINE USED ON M17,M18, M17A1,M18A1.....	4
10	XAHZZ		19200	11729557	PLATE,WINDOW USED ON M17,M18,M17A1, M18A1.....	1
11	PAHZZ	6650000664998	19200	8626399	WINDOW,OPTICAL INST USED ON M17, M18,M17A1,M18A1.....	1
12	PAOZZ	7690002572746	19200	11731011	DECAL RADIOACTIVE INSTRUMENT DISPOSAL M17,M18.....	1
13	PADZZ	5340015221643	19200	12984757	PLATE,MOUNTING USED ON M17A1,M18A1. UOC:BM3,BM6	1
14	PADZZ	5305007640066	96906	MS51959-44	SCREW,MACHINE USED ON M17A1,M18A1.. UOC:BM3,BM6	3
15	PAHZZ	5340015220777	19200	12984828	PLUG,PROTECTIVE,DUS T AND MOISTURE SEAL USED ON M17A1,M18A1.....	1
					UOC:BM3,BM6	

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)**

**COUNTER ASSEMBLY
11729529**

REPAIR PARTS LIST




Figure 6. Counter Assembly, 11729529.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 6. COUNTER ASSEMBLY, CORRECTION M17, M18, M17A1, M18A1 PN 11729529						
1	PAHZZ	5315006821726	96906	MS16555-617	PIN, STRAIGHT, HEADLE USED ON M17, M18, M17A1, M18A1.....	1
2	PAHZZ	1290010437499	19200	11729561	DETENT, COUNTER USED ON M17, M18, M17A1, M18A1.....	1
3	PAHZZ	5315008067039	96906	MS16555-604	PIN, STRAIGHT, HEADLE USED ON M17, M18, M17A1, M18A1.....	4
4	PAHZZ	6680010507647	19200	11748021	COUNTER, ROTATING USED ON M17, M18, M17A1, M18A1.....	1
5	PAHZZ	3020010453970	19200	11729576	GEAR, SPUR USED ON M17, M18, M17A1, M18A1.....	1
6	PAHZZ	6680010495151	19200	11729591	COUNTER, ROTATING USED ON M17, M18, M17A1, M18A1.....	1
7	PAHZZ	3020010479114	19200	11729554	GEAR, INTERNAL USED ON M17, M18, M17A1, M18A1.....	1
8	PAHZZ	5315006231761	80205	MS51923-159	PIN, SPRING USED ON M17, M18, M17A1, M18A1.....	1
9	PAHZZ	1290010449859	19200	11729544	SPIDER ASSEMBLY USED ON M17, M18, M17A1, M18A1.....	1
10	PAHZZ	3020010495234	19200	11729555	GEAR CLUSTER USED ON M17, M18, M17A1, M18A1.....	1
11	PAHZZ	3020010486275	19200	11729575	GEAR, SPUR USED ON M17, M18, M17A1, M18A1.....	1
12	PAHZZ	5325005981840	96906	MS16633-4015	RING, RETAINING USED ON M17, M18, M17A1, M18A1.....	1
13	PAHZZ	5315010457806	19200	11729589	PIN, STRAIGHT, HEADLE USED ON M17, M18, M17A1, M18A1.....	1
14	PAHZZ	3020010479116	19200	11729574	GEAR CLUSTER USED ON M17, M18, M17A1, M18A1.....	1
15	XAHZZ		19200	11729560	SUPPORT USED ON M17, M18, M17A1, M18A1	1
16	PAHZZ	3040010483741	19200	11729577	GEARSHAFT, SPUR USED ON M17, M18, M17A1, M18A1.....	1
17	PAHZZ	5310005505009	80205	MS15795-704	WASHER, FLAT USED ON M17, M18, M17A1, M18A1.....	4
18	PAHZZ	5305000545649	96906	MS51957-15	SCREW, MACHINE USED ON M17, M18, M17A1, M18A1.....	8
19	PAHZZ	5310009338118	80205	MS35338-135	WASHER, LOCK USED ON M17, M18, M17A1, M18A1.....	4
20	PAHZZ	5360010465865	19200	11729598	SPRING, HELICAL, COMP USED ON M17, M18, M17A1, M18A1.....	1
21	PAHZZ	5340010437511	19200	11729572	PLUNGER, DETENT USED ON M17, M18, M17A1, M18A1.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M17/M17A1/M18/M18A1 FIRE CONTROL QUADRANT
(1290-01-037-3883/1290-01-515-8260/1290-01-037-7289/1290-01-515-8262)**

**FIRE CONTROL LEVEL ASSEMBLY
(CROSS LEVEL VIAL ASSEMBLY)
11729551/13005081**

REPAIR PARTS LIST




Figure 7. Fire Control Level Assembly (Cross Level Vial Assembly), 11729551/13005081.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 7. LEVEL ASSEMBLY, FIRE CONTROL (CROSS LEVEL VIAL ASSY) M18 PN 11729551, M18A1 PN 13005081	
1	PAHZZ	5365006921492	19200	8202181	RING,EXTERNALLY THR USED ON M18, M18A1.....	1
					UOC:BM6,F40	
2	PAHZZ	5365008962251	19200	8202177	BUSHING,ECCENTRIC USED ON M18,M18A1	1
					UOC:BM6,F40	
3	PCHZA	1290002572769	19200	11729512	LEVEL,FIRE CONTROL USED ON M18 ONLY	1
					UOC:F40	
3	PAHZZ	1290006921493	19200	8202183	LEVEL,FIRE CONTROL USED ON M18A1 ONLY.....	1
					UOC:BM6	
4	XADZZ		19200	11729538	BRACKET,VIAL USED ON M18,M18A1.....	1
					UOC:BM6,F40	
5	PAHZZ	5305007176955	96906	MS51963-1	SETSCREW USED ON M18,M18A1.....	1
					UOC:BM6,F40	
6	PAHZZ	5340007597626	19200	7597626	COVER,ACCESS USED ON M18,M18A1.....	1
					UOC:BM6,F40	
7	PAHZZ	5315008067039	96906	MS16555-604	PIN,STRAIGHT,HEADLE USED ON M18, M18A1.....	1
					UOC:BM6,F40	

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
11727800/13005103**

REPAIR PARTS LIST




Figure 8. M171 Telescope and Quadrant Mount, 11727800, and M171A1 Telescope and Quadrant Mount, 13005103.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 8. MOUNT, TELESCOPE AND QUADRANT, M171, PN 11727800, M171A1, PN 13005103	
1	PAHHH	1240015210009	19200	13005037	SUPPORT,OPTICAL INS TRUMENT M171A1 SEE FIG 12 FOR BREAKDOWN.....	1
					UOC:BM4	
1	PAHHD	1240010449852	19200	11727822	SUPPORT,OPTICAL INS TRUMENT M171 SEE FIG 12 FOR BREAKDOWN.....	1
					UOC:F44	
2	XDHHH		19200	11727801	ROCKER ASSEMBLY,OPT ICAL INSTRUMENT M171 AND M171A1 SEE FIG 13 FOR BREAKDOWN.....	1
3	XAHHH		19200	11727804	HOUSING ASSEMBLY M171 AND M171A1 SEE FIG 14 FOR BREAKDOWN.....	1
4	PAHDD	3130015179273	19200	13005082	BEARING UNIT,BALL M171A1 SEE FIG 17 FOR BREAKDOWN.....	1
					UOC:BM4	
4	PAHDD	3130014973341	19200	11727802	BEARING UNIT,BALL M171 SEE FIG 17 FOR BREAKDOWN.....	1
					UOC:F44	
5	PAHDD	1240014989029	19200	11727824	MOUNT SUBASSEMBLY M171 AND M171A1 SEE FIG 15 FOR BREAKDOWN.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
11727800/13005103
UPPER INTERNAL MOUNT PARTS**

REPAIR PARTS LIST




Figure 9. M171 Telescope and Quadrant Mount, 11727800, and M171A1 Telescope and Quadrant Mount, 13005103, Upper Internal Mount Parts.

SECTION II			TM9-1240-375-34&P		(6)	(7)
(1)	(2)	(3)	(4)	(5)		
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 9. MOUNT, TELESCOPE AND QUADRANT, M171, PN 11727800, M171A1, PN 13005103, UPPER INTERNAL MOUNT PARTS						
1	PAHZZ	5365010506765	19200	11727887	PLUG,MACHINE THREAD USED ON M171 AND M171A1.....	1
2	PAHZZ	5360009789584	19200	8587557	SPRING,HELICAL,COMP USED ON M171 AND M171A1.....	1
3	PAHZZ	3120010506190	19200	11727886	BEARING,V USED ON M171 AND M171A1..	1
4	PAHZZ	5305011167366	96906	MS51099-115	SCREW,CAP,HEXAGON H USED ON M171 ONLY.....	1
5	PAHZZ	5310009338778	80205	MS35338-143	UOC:F44 WASHER,LOCK USED ON M171 ONLY.....	1
6	PAHZZ	5315001880240	80205	MS24692-339	UOC:F44 PIN,TAPERED,PLAIN USED ON M171 ONLY	1
6	PAHZZ	5315015179274	19200	12999465	UOC:F44 PIN,TAPERED,PLAIN USED ON M171A1 ONLY.....	2
6A	PAHZZ	5315013362450	81349	M21143/1-50	UOC:BM4 PIN,STRAIGHT,HEADLE USED ON M171A1 OPTICAL SUPPORT.....	1
6B	PAHZZ	5305012065456	80205	MS18064-91	UOC:BM4 SETSCREW USED ON M171A1 OPTICAL SUPPORT.....	1
7	PAHZZ	5325010540133	96906	MS90708-4150	UOC:BM4 RING,RETAINING USED ON M171 AND M171A1.....	3
8	PAHZZ	5330010491290	19200	11727871-1	SEAL,PLAIN ENCASED USED ON M171 AND M171A1.....	2
9	PAHZZ	9390010519545	19200	11727844	BELLOWS,PROTECTION USED ON M171 AND M171A1.....	2
10	PAHZZ	5310009338119	80205	MS35338-137	WASHER,LOCK USED ON M171 AND M171A1	12
11	PAHZZ	5305009226286	80205	MS35275-228	SCREW,MACHINE USED ON M171 AND M171A1.....	12
12	PAHZZ	5305009954659	96906	MS24674-14	SCREW,CAP,SOCKET HE USED ON M171 ONLY.....	6
13	PAHZZ	5315010530237	19200	11727868	PIN,SHOULDER,HEADED USED ON M171 AND M171A1.....	2
14	PAHZZ	5310009338120	80205	MS35338-138	WASHER,LOCK USED ON M171 AND M171A1	6
15	PAHZZ	5365010465869	19200	11727882	RING,EXTERNALLY THR USED ON M171 AND M171A1.....	1
16	PAHZZ	5330010444883	19200	11727883	FELT,MECHANICAL,PRE USED ON M171 AND M171A1.....	1
17	PAHZZ	5310010499175	19200	11727884	WASHER,FLAT USED ON M171 AND M171A1	2
18	PAHZZ	5355010460732	19200	11727885	KNOB USED ON M171 AND M171A1.....	1
19	PAHZZ	5315008100505	80205	MS16555-628	PIN,STRAIGHT,HEADLE USED ON M171 AND M171A1.....	1
20	PAHZZ	3120010501574	19200	11727880	BEARING,PLAIN,SPHER USED ON M171 AND M171A1.....	1
21	PAHZZ	1240010439459	19200	13005085	WORM SHAFT ASSEMBLY USED ON M171 AND M171A1.....	1

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
22	PAHZZ	5305002813120	96906	MS51023-48	SETSCREW USED ON M171 AND M171A1...	2
23	PAHZZ	5365015178451	19200	12984744	SPACER,PLATE USED ON M171A1 ONLY...	1
					UOC:BM4	
24	PAHZZ	5305000679917	96906	MS24674-15	SCREW,CAP,SOCKET HE USED ON M171A1	
					ONLY.....	6
					UOC:BM4	
24A	PAOZZ	5305007640068	80205	MS51959-45	SCREW,MACHINE USED ON M171A1 ONLY..	2
					UOC:BM4	
25	PAOZZ	5330014853480	11934	SLB10377	GASKET USED ON M171A1 ONLY.....	1
					UOC:BM4	
26	PAOZZ	6160014851914	19200	12984693	COVER,BATTERY BOX USED ON M171A1	
					ONLY.....	1
					UOC:BM4	
27	PAOZZ	5310009296395	80205	MS35338-136	WASHER,LOCK USED ON M171A1 ONLY....	3
					UOC:BM4	
28	PAOZZ	5305009591082	80205	MS16995-18	SCREW,MACHINE USED ON M171A1 ONLY..	3
					UOC:BM4	
29	PAOZZ	4010014643142	19200	12984664	WIRE ROPE ASSEMBLY, USED ON M171A1	
					ONLY.....	1
					UOC:BM4	
30	PAOZZ	5340014643141	19200	12984661	CAP-PLUG,PROTECTIVE DUST AND	
					MOISTURE SEAL	
					USED ON M171A1 ONLY.....	1
					UOC:BM4	

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
11727800/13005103
LOWER INTERNAL MOUNT PARTS**

REPAIR PARTS LIST




Figure 10. M171 Telescope and Quadrant Mount, 11727800, and M171A1 Telescope and Quadrant Mount, 13005103, Lower Internal Mount Parts.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 10. MOUNT, TELESCOPE AND QUADRANT, M171, PN 11727800, M171A1, PN 13005103, LOWER INTERNAL MOUNT PARTS						
1	PAHZZ	5305001465701	19200	11727876-1	SCREW,SHOULDER USED ON M171 AND M171A1.....	4
2	PAHZZ	5310009338121	96906	MS35338-139	WASHER,LOCK USED ON M171 AND M171A1	4
3	PAHZZ	3040015179270	19200	13005070	PLATE,RETAINING,SHA USED ON M171 AND M171A1.....	1
4	PAHZZ	5305008489282	80205	NAS1352C06H8	SCREW,CAP,SOCKET HE USED ON M171 AND M171A1.....	5
5	PAHZZ	5310009338119	80205	MS35338-137	WASHER,LOCK USED ON M171 AND M171A1	5
6	PAHZZ	5340010439313	19200	11727814	COVER,ACCESS USED ON M171 AND M171A1.....	1
7	PAHZZ	5310009338119	80205	MS35338-137	WASHER,LOCK USED ON M171 AND M171A1	2
8	PAHZZ	5305009931612	96906	MS24674-8	SCREW,CAP,SOCKET HE USED ON M171 AND M171A1.....	2
9	PAHZZ	5330010468020	19200	11727833	GASKET USED ON M171 AND M171A1.....	1
10	PAHZZ	5331002483850	81343	AS29513-116	O-RING USED ON M171 AND M171A1.....	1
11	PAHZZ	3040010452059	19200	11727839	PLATE,RETAINING,SHA USED ON M171 AND M171A1.....	1
12	PAHZZ	5331009359226	81343	AS29513-151	O-RING USED ON M171 AND M171A1.....	1
13	PAHZZ	5331005841229	81343	AS3578-118	O-RING USED ON M171 AND M171A1.....	1
14	PAHZZ	3040010468372	19200	11727857	PAWL USED ON M171 AND M171A1.....	1
15	PAHZZ	5305010485367	19200	11727866	SCREW,CLOSE TOLERAN USED ON M171 AND M171A1.....	1
16	PAHZZ	5305002723533	80205	MS51023-49	SETSCREW USED ON M171 AND M171A1...	1
17	PAHZZ	5305009939175	96906	MS24674-16	SCREW,CAP,SOCKET HE USED ON M171 AND M171A1.....	8
18	PAHZZ	5310009338120	96906	MS35338-138	WASHER,LOCK USED ON M171 AND M171A1	8
19	PAHZZ	3040010938922	19200	11727834	COLLAR,SHAFT USED ON M171 AND M171A1.....	1
20	PAHZZ	5330010498676	19200	11727872-1	SEAL,PLAIN ENCASED USED ON M171 AND M171A1.....	1
21	PAFZZ	5310009338778	96906	MS35338-143	WASHER,LOCK USED ON M171 AND M171A1	4
22	PAHZA	5305010623346	96906	MS51100-120	SCREW,CAP,HEXAGON H USED ON M171 AND M171A1.....	4
23	PAHZZ	5330010480563	19200	11727871-2	SEAL,PLAIN ENCASED USED ON M171 AND M171A1.....	2
24	PAHZZ	5310010494071	19200	11727838	NUT,PLAIN,ROUND USED ON M171 AND M171A1.....	1
25	PAHZZ	1240010449854	19200	11727854	DOG,LOCKING USED ON M171 AND M171A1	1
26	PAHZZ	5305000679914	96906	MS24674-7	SCREW,CAP,SOCKET HE USED ON M171 AND M171A1.....	2
27	PAHZZ	5330010480564	19200	11727871-3	SEAL,PLAIN ENCASED USED ON M171 AND M171A1.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
11727800/13005103
EXTERNAL PARTS INCLUDING LEVEL VIALS**

REPAIR PARTS LIST




Figure 11. M171 Telescope and Quadrant Mount, 11727800, and M171A1 Telescope and Quadrant Mount, 13005103, External Parts Including Level Vials.

SECTION II			TM9-1240-375-34&P		(6)	(7)
(1)	(2)	(3)	(4)	(5)		
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 11. MOUNT, TELESCOPE AND QUADRANT, M171, PN 11727800, M171A1, PN 13005103 EXTERNAL PARTS INCLUDING LEVEL VIALS	
1	PAHZZ	5340007597626	19200	7597626	COVER,ACCESS USED ON M171 AND M171A1.....	2
2	PCHZA	1290002572769	19200	11729512	LEVEL,FIRE CONTROL USED ON M171 ONLY.....	2
					UOC:F44	
2A	PAHZZ	1240015179275	19200	12984745	LEVEL,FIRE CONTROL USED ON M171A1 ONLY	
					ELEVATION LEVEL VIAL.....	1
					UOC:BM4	
2B	PAHZZ	1290006921493	19200	8202183	LEVEL,FIRE CONTROL USED ON M171A1 ONLY	
					CROSS LEVEL VIAL.....	1
					UOC:BM4	
3	PAHZZ	5365008962251	19200	8202177	BUSHING,ECCENTRIC USED ON M171 AND M171A1.....	2
4	PAHZZ	5365006921492	19200	8202181	RING,EXTERNALLY THR USED ON M171 AND M171A1.....	2
5	PAHZZ	5305008007261	80205	MS51021-9	SETSCREW USED ON M171 AND M171A1...	2
6	PAFZZ	9905002572751	19200	11729581	PLATE,INSTRUCTION RADIOACTIVE CURIES M171.....	1
					UOC:F44	
7	PAFZZ	5310005434652	96906	MS35333-69	WASHER,LOCK USED ON M171 ONLY.....	2
					UOC:F44	
8	PAFZZ	5305000545636	96906	MS51957-2	SCREW,MACHINE USED ON M171 ONLY....	2
					UOC:F44	

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**OPTICAL INSTRUMENT SUPPORT
11727822/13005037**

REPAIR PARTS LIST




Figure 12. Optical Instrument Support, 11727822/13005037.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 12. SUPPORT, OPTICAL INSTRUMENT M171 PN 11727822, M171A1, PN 13005037						
1	PAFZZ	5315004921962	19200	11727888	KEY,MACHINE USED ON M171 AND M171A1	2
2	XAHZZ		19200	13005038	SUPPORT USED ON M171A1 ONLY.....	1
					UOC:BM4	
2	XAHZZ		19200	11727818	SUPPORT USED ON M171 ONLY.....	1
					UOC:F44	
3	PAFZZ	5305010476150	19200	11727842-2	THUMBSCREW ASSY USED ON M171 ONLY..	2
					UOC:F44	
4	PAFZZ	5305000685276	80205	MS16995-9	SCREW,CAP,SOCKET HE USED ON M171 ONLY.....	4
					UOC:F44	
5	PAFZZ	5310009338118	80205	MS35338-135	WASHER,LOCK USED ON M171 ONLY.....	4
					UOC:F44	
6	PAFZZ	5305010476149	19200	11727842-1	THUMBSCREW USED ON M171 ONLY.....	2
					UOC:F44	
7	PAFZZ	5305009887601	96906	MS16995-25	SCREW,CAP,SOCKET HE USED ON M171 ONLY.....	2
					UOC:F44	
8	PAFZZ	5310009338119	80205	MS35338-137	WASHER,LOCK USED ON M171 AND M171A1	2
9	PAFZZ	5305009887604	80205	MS16995-28	SCREW,CAP,SOCKET HE USED ON M171A1 ONLY.....	2
					UOC:BM4	
10	PAOZZ	5305009887838	80205	MS16995-64	SCREW,CAP,SOCKET HE USED ON M171A1 ONLY.....	2
					UOC:BM4	
11	PAOZZ	5340015179271	19200	13005040	HANDLE,MANUAL CONTR OL LEFT HAND USED ON M171A1 ONLY.....	1
					UOC:BM4	
12	PAOZZ	5310015213097	19200	13005045	WASHER,SPRING TENSIL USED ON M171A1 ONLY.....	2
					UOC:BM4	
13	PAOZZ	5340015212989	19200	13005043	PLUNGER,DETENT USED ON M171A1 ONLY.	2
					UOC:BM4	
14	PAOZZ	5305015219231	19200	13005044	SETSCREW USED ON M171A1 ONLY.....	2
					UOC:BM4	
15	PAOZZ	5340015178450	19200	13005039	HANDLE,MANUAL CONTR OL RIGHT HAND USED ON M171A1 ONLY.....	1
					UOC:BM4	
16	PAOZZ	5305008659516	80205	MS51029-48	SETSCREW USED ON M171A1 ONLY.....	2
					UOC:BM4	

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**OPTICAL INSTRUMENT ROCKER ASSEMBLY
11727801**

REPAIR PARTS LIST




Figure 13. Optical Instrument Rocker Assembly, 11727801.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 13. ROCKER ASSEMBLY, OPTICAL INSTRUMENT 11727801						
1	PAHZZ	5305007702533	96906	MS51959-13	SCREW,MACHINE USED ON M171 AND M171A1.....	2
2	PAHZA	5310010465392	19200	11727851	WASHER,KEY USED ON M171 AND M171A1.	1
3	PAHZZ	3110015183219	19200	13005099	SEAT,BEARING NEW SEAT REPLACES PN 11727835 MUST ALSO ORDER NEW BEARING PN 13005100 AND NEW SEAT PN 13005098 USED ON M171 AND M171A1	1
4	PAHZZ	3120015183221	19200	13005100	TORQUE TO 150 INCH POUNDS..... BEARING,PLAIN,SPHER NEW BEARING REPLACES PN 11727875. MUST ALSO ORDER NEW SEATS PN 13005098 AND 13005099.	1
5	PAHZZ	3110015183217	19200	13005098	USED ON M171 AND M171A1..... SEAT,BEARING NEW SEAT REPLACES PN 11727861 MUST ALSO ORDER NEW BEARING PN 13005100 AND SEAT PN 13005099	1
6	XAHZZ		19200	11727806	USED ON M171 AND M171A1.....	1
7	PAFZZ	9905010480646	19200	11727863	ROCKER,OPTICAL INST USED ON M171 AND M171A1.....	1
7	PAFZZ	9905015211615	19200	13005105	PLATE,IDENTIFICATIO USED ON M171 ONLY.....	1
					UOC:F44	
8	PAFZZ	5310005434652	96906	MS35333-69	PLATE,IDENTIFICATIO USED ON M171A1 ONLY.....	1
					UOC:BM4	
9	PAFZZ	5305000545636	96906	MS51957-2	WASHER,LOCK USED ON M171 AND M171A1	2
					SCREW,MACHINE USED ON M171 AND M171A1.....	2

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**HOUSING ASSEMBLY
11727804**

REPAIR PARTS LIST




Figure 14. Housing Assembly, 11727804.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 14. HOUSING ASSEMBLY 11727804						
1	PAHZZ	5305009409488	96906	MS35275-226	SCREW,MACHINE USED ON M171 AND M171A1.....	4
2	PAHZZ	3020015178452	19200	13005083	GEAR CLUSTER USED ON M171 AND M171A1.....	1
3	XAHZZ		19200	11727817	HOUSING,WORM WHEEL USED ON M171 AND M171A1.....	1
4	PAHZZ	5310010465395	19200	11727897	WASHER,FLAT USED ON M171 AND M171A1	1
5	PAHZZ	5310001861009	96906	MS19070-063	WASHER,KEY USED ON M171 AND M171A1.	1
6	PAHZZ	5310004505946	96906	MS19068-063	NUT,PLAIN,ROUND USED ON M171 AND M171A1.....	1
7	PAHZZ	5365010506765	19200	11727887	PLUG,MACHINE THREAD USED ON M171 AND M171A1.....	1
8	PAHZZ	5360009789584	19200	8587557	SPRING,HELICAL,COMP USED ON M171 AND M171A1.....	1
9	PAHZZ	3120010506190	19200	11727886	BEARING,V USED ON M171 AND M171A1..	1
10	PAHZZ	5305002813120	96906	MS51023-48	SETSCREW USED ON M171 AND M171A1...	2
11	PAHZZ	1240010439459	19200	13005085	WORM SHAFT ASSEMBLY USED ON M171 AND M171A1.....	1
12	PAHZZ	5365010465869	19200	11727882	RING,EXTERNALLY THR USED ON M171 AND M171A1.....	1
13	PAHZZ	5310010499175	19200	11727884	WASHER,FLAT USED ON M171 AND M171A1	2
14	PAHZZ	5330010444883	19200	11727883	FELT,MECHANICAL,PRE USED ON M171 AND M171A1.....	1
15	PAHZZ	5355010460732	19200	11727885	KNOB USED ON M171 AND M171A1.....	1
16	PAHZZ	5315008100505	96906	MS16555-628	PIN,STRAIGHT,HEADLE USED ON M171 AND M171A1.....	1
17	PAHZZ	3120010501574	19200	11727880	BEARING,PLAIN,SPHER USED ON M171 AND M171A1.....	1
18	PAHZZ	3040010480767	19200	11727867	BRACKET,EYE,ROTATIN USED ON M171 AND M171A1.....	1
19	PAHZZ	5315006821733	96906	MS16555-646	PIN,STRAIGHT,HEADLE USED ON M171 AND M171A1.....	4
20	PAHZZ	5305006853492	96906	MS24674-25	SCREW,CAP,SOCKET HE USED ON M171 AND M171A1.....	2
21	PAHZZ	5310009338121	96906	MS35338-139	WASHER,LOCK USED ON M171 AND M171A1	2
22	PAHZZ	5315010439369	19200	11727892	PIN,STRAIGHT,HEADLE USED ON M171 AND M171A1.....	1
23	PAHZZ	5305009939175	96906	MS24674-16	SCREW,CAP,SOCKET HE USED ON M171 AND M171A1.....	5
24	PAHZZ	5310009338120	96906	MS35338-138	WASHER,LOCK USED ON M171 AND M171A1	5
25	PAHZZ	3040015178453	19200	13005084	CAMSHAFT USED ON M171 AND M171A1...	1
26	PAHZZ	5305008489282	96906	MS24674-3	SCREW,CAP,SOCKET HE USED ON M171 AND M171A1.....	8
27	PAHZZ	5310009338119	80205	MS35338-137	WASHER,LOCK USED ON M171 AND M171A1	8
28	PAHZZ	1240010478183	19200	11727850	HOLDER,FELT MECHANI USED ON M171 AND M171A1.....	4
29	PAHZZ	5330010439288	19200	11727895	FELT,MECHANICAL,PRE USED ON M171 AND M171A1.....	4

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**MOUNT SUBASSEMBLY
11727824**

REPAIR PARTS LIST




Figure 15. Mount Subassembly, 11727824.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 15. MOUNT SUBASSEMBLY, PN 11727824	
1	PAHZZ	5305002259891	96906	MS24674-35	SCREW,CAP,SOCKET HE USED ON M171 AND M171A1.....	4
2	PAHZZ	5310009746623	96906	MS35338-140	WASHER,LOCK USED ON M171 AND M171A1	4
3	PAHHD	1240010467106	19200	11727821	ADAPTER MOUNTING USED ON M171 AND M171A1	
4	PADDD	3040014934172	19200	11727803	SEE FIG 16 FOR BREAKDOWN..... ACTUATOR,MECHANICAL USED ON M171 AND M171A1	1
5	PAHZZ	5315006821733	96906	MS16555-646	SEE FIG 16 FOR BREAKDOWN..... PIN,STRAIGHT,HEADLE USED ON M171 AND M171A1.....	1 2

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**MOUNTING ADAPTER, 11727821
AND
MECHANICAL ACTUATOR, 11727803**

REPAIR PARTS LIST




Figure 16. Mounting Adapter, 11727821, and Mechanical Actuator, 11727803.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 16. ADAPTER, MOUNTING, PN 11727821 AND ACTUATOR, MECHANICAL, PN 11727803	
1	PAHZZ	5306010488749	19200	11727870	BOLT, SHOULDER USED ON M171 AND M171A1.....	1
2	PAHZZ	5305009590382	80205	MS16995-17	SCREW,CAP, SOCKET HE USED ON M171 AND M171A1.....	2
3	PAHZZ	5310009338119	80205	MS35338-137	WASHER, LOCK USED ON M171 AND M171A1	2
4	PAHZZ	5315010437428	19200	11727890	KEY, MACHINE USED ON M171 AND M171A1	2
5	XAHZZ		19200	11727819	ADAPTER USED ON M171 AND M171A1....	1
6	PAHZZ	5315000788711	80205	MS24692-225	PIN, TAPERED, PLAIN USED ON M171 AND M171A1.....	1
7	PAHZZ	1240010449849	19200	11727808	RING ASSEMBLY USED ON M171 AND M171A1.....	1
8	PAHZZ	5305002724123	80205	MS51021-23	SETSCREW USED ON M171 AND M171A1...	2
9	PAHZZ	3040014947940	19200	11727816	HUB, BODY USED ON M171 AND M171A1...	1
10	PAHZZ	3040010438405	19200	13005088	SHAFT, SHOULDERED USED ON M171 AND M171A1.....	1
11	PAHZZ	5310000895966	19200	8626152	WASHER, FLAT USED ON M171 AND M171A1	2
12	PAHZZ	5310007969592	19200	8626125	WASHER, SHOULDERED USED ON M171 AND M171A1.....	2
13	PAHZZ	3110001567513	58536	FF B 171B	BEARING, BALL, ANNULA USED ON M171 AND M171A1.....	2
14	PAHZZ	5365000655319	19200	8626126	PLUG, MACHINE THREAD USED ON M171 AND M171A1.....	2

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M171/M171A1 TELESCOPE AND QUADRANT MOUNT
(1240-01-039-7273/1240-01-515-8265)**

**BALL BEARING UNIT
11727802/13005082**

REPAIR PARTS LIST




Figure 17. Ball Bearing Unit, 11727802/13005082.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 17. BEARING UNIT, BALL M171, PN 11727802, M171A1, PN 13005082	
1	XAHZZ		19200	11727812	STEM M171 USED ON M171 ONLY.....	1
					UOC:F44	
1	XAHZZ		19200	13005087	STEM M171A1 USED ON M171A1 ONLY....	1
					UOC:BM4	
2	PAOZZ	9905002572746	19200	11731011	PLATE,INSTRUCTION RADIATION INFORMATION.....	1
					UOC:F44	
3	PAHZZ	3110001655922	19200	11727864	BEARING,BALL,DUPLEX USED ON M171 AND M171A1.....	1
4	PAHZZ	5365010483048	19200	11727837	RING,EXTERNALLY THR USED ON M171 AND M171A1.....	1
5	PAHZZ	1240010460895	19200	11727853	DOG,LOCKING USED ON M171 AND M171A1	1
6	PAHZZ	5310009338119	80205	MS35338-137	WASHER,LOCK USED ON M171 AND M171A1	2
7	PAHZZ	5305000679914	96906	MS24674-7	SCREW,CAP,SOCKET HE USED ON M171 AND M171A1.....	2
8	PAFZZ	5305000546651	96906	MS51957-27	SCREW,MACHINE USED ON M171 AND M171A1.....	2
9	PAFZZ	5310006163555	80205	MS35333-71	WASHER,LOCK USED ON M171 AND M171A1	2
10	PAFZZ	6650010478283	19200	11727865	MIRROR,OPTICAL INST USED ON M171 AND M171A1.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M172/M172A1 TELESCOPE AND QUADRANT
(1240-01-037-7290/1240-01-517-2171)**

**M172/M172A1 TELESCOPE AND QUADRANT
10554823/13005089**

REPAIR PARTS LIST




Figure 18. M172 Telescope and Quadrant Mount, 10554823, and M172A1 Telescope and Quadrant Mount, 13005089.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 18. MOUNT, TELESCOPE AND QUADRANT, M172 10554823; M172A1, 13005089	
1	PAHHD	1240010438198	19200	10554685	BRACKET TELESCOPE SEE FIG 21 FOR ASSY BRKDN	
					USED ON BOTH M172 AND M172A1.....	1
2	XAHHH		19200	13005091	ADAPTER ASSEMBLY SEE FIG 22 FOR ASSY BRKDN	
					USED ON BOTH THE M172 AND M172A1....	1
3	XAHZZ		19200	13005090	SUPPORT, QUADRANT USED ON BOTH THE M172 AND M172A1.....	1
4	PAHHH	5340010444892	19200	10554811	COVER, ACCESS USED ON BOTH THE M172 AND M172A1.....	1
5	PAHZZ	5325005973302	96906	MS124695	INSERT, SCREW THREAD.....	2

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M172/M172A1 TELESCOPE AND QUADRANT
(1240-01-037-7290/1240-01-517-2171)**

**M172/M172A1 TELESCOPE AND QUADRANT
10554823/13005089
PARTS**

REPAIR PARTS LIST




Figure 19. M172 Telescope and Quadrant Mount, 10554823, and M172A1 Telescope and Quadrant Mount, 13005089, Parts.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR		PART			
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 19. MOUNT, TELESCOPE AND QUADRANT, M172, 10554823; M172A1, 13005089 PARTS						
1	PAHZZ	5310010499174	19200	10554820	WASHER,FLAT.....	4
2	PAHZZ	5305008343385	80205	MS24673-17	SCREW,CAP, SOCKET HE.....	4
3	XAHZZ		96906	MS27955-4	NUT,PLAIN,ROUND.....	1
4	XAHZZ		19200	10554813	SETSCREW.....	1
4A	PAHZZ	5305008343388	80205	MS24673-16	SCREW,CAP, SOCKET HE.....	2
4B	PAHZZ	5310009746623	80205	MS35338-140	WASHER, LOCK.....	6
4C	PAHZZ	5305008343385	80205	MS24673-17	SCREW,CAP, SOCKET HE.....	2
4D	PAHZZ	5305002353528	80205	MS24673-18	SCREW,CAP, SOCKET HE.....	1
5	PAHZZ	5305009894609	96906	MS24674-9	SCREW,CAP, SOCKET HE.....	3
6	PAHZZ	5310009338119	80205	MS35338-137	WASHER, LOCK.....	3
7	PAHZZ	5315010544904	19200	11732205	PIVOT,PIN.....	1
8	PAHZZ	5305009885308	80205	MS24673-3	SCREW,CAP, SOCKET HE.....	4
9	PAHZZ	5310009338120	96906	MS35338-138	WASHER, LOCK.....	6
10	PAHZZ	5305006827753	80205	MS24673-7	SCREW,CAP, SOCKET HE.....	2
11	PAHZZ	5330010499865	19200	11732207	FELT,MECHANICAL,PRE.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M172/M172A1 TELESCOPE AND QUADRANT
(1240-01-037-7290/1240-01-517-2171)**

**M172/M172A1 TELESCOPE AND QUADRANT
10554823/13005089
PARTS (LOWER RIGHT)**

REPAIR PARTS LIST




Figure 20. M172 Telescope and Quadrant Mount, 10554823, and M172A1 Telescope and Quadrant Mount, 13005089, Parts (Lower Right).

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 20. MOUNT, TELESCOPE AND QUADRANT, M172 10554823; M172A1, 13005089 PARTS CONTINUED	
1	PAFZZ	9905010455843	19200	10554829	PLATE, IDENTIFICATIO USED ON M172 ONLY.....	1
					UOC:F43	
1	PAFZZ	9905015184505	19200	13005095	PLATE, IDENTIFICATIO USED ON M172A1 ONLY.....	1
					UOC:BN3	
2	PAFZZ	5310009282690	80205	MS35338-134	WASHER, LOCK.....	2
3	PAFZZ	5305000545636	96906	MS51957-2	SCREW, MACHINE.....	2
4	PAHZZ	5355010460732	19200	11727885	KNOB.....	1
5	PAHZZ	5315008100505	96906	MS16555-628	PIN, STRAIGHT, HEADLE.....	1
6	PAHZZ	5310010499175	19200	11727884	WASHER, FLAT.....	2
7	PAHZZ	5330010444883	19200	11727883	FELT, MECHANICAL, PRE.....	1
8	PAHZZ	5365010465869	19200	11727882	RING, EXTERNALLY THR.....	1
9	PAHZZ	3120010501574	19200	11727880	BEARING, PLAIN, SPHER.....	1
10	PAHZZ	1240010439459	19200	13005085	WORM SHAFT ASSEMBLY USED ON BOTH THE M172 AND M172A1.....	1
11	PAHZZ	5305002813120	96906	MS51023-48	SETSCREW.....	2
12	PAFZZ	5340010519968	19200	10554514	CAP, PROTECTIVE, DUST.....	1
13	PAHZZ	5365010506765	19200	11727887	PLUG, MACHINE THREAD.....	1
14	PAHZZ	5360009789584	19200	8587557	SPRING, HELICAL, COMP.....	1
15	PAHZZ	3120010506190	19200	11727886	BEARING, V.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M172/M172A1 TELESCOPE AND QUADRANT
(1240-01-037-7290/1240-01-517-2171)**

**TELESCOPE MOUNTING BRACKET
10554685**

REPAIR PARTS LIST




Figure 21. Telescope Mounting Bracket, 10554685.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 21. BRACKET, TELESCOPE MOUNTING 10554685	
1	PAHZZ	3110010470624	19200	11727757	PLATE,RETAINING,BEA.....	1
2	PAHZZ	5315009887409	96906	MS16555-634	PIN,STRAIGHT,HEADLE.....	1
3	PAHZZ	5360010376448	96906	MS24585-1025	SPRING,HELICAL,COMP.....	1
4	PAHZZ	3040010438293	19200	11727758	GEARSHAFT,HELICAL.....	1
5	PAHZZ	5305008343385	80205	MS24673-17	SCREW,CAP,SOCKET HE.....	2
6	XAHZZ		19200	10549069	BRACKET,EYE,NONROTA.....	1
7	PAHZZ	5305006559246	80205	MS51021-10	SETSCREW.....	2
8	PAHZZ	5305010437326	19200	10554692	SCREW,SHOULDER.....	2
9	PAHZZ	5340010437501	19200	10549286	LEVER,LOCK-RELEASE.....	1
10	PAHZZ	5360009934647	96906	MS24585C75	SPRING,HELICAL,COMP.....	2
11	PAHZZ	5340010439453	19200	10549278	LEVER,LOCK-RELEASE.....	1
12	PAHZZ	3040015184504	19200	13005086	WORM SHAFT USED ON BOTH THE M172 AND M172A1.....	1
13	PAHZZ	5365010561804	19200	10549070	RING,EXTERNALLY THR.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M172/M172A1 TELESCOPE AND QUADRANT
(1240-01-037-7290/1240-01-517-2171)**

**ADAPTER ASSEMBLY
13005091**

REPAIR PARTS LIST




Figure 22. Adapter Assembly, 13005091.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 22. ADAPTER ASSEMBLY 13005091						
1	PAFZZ	5305008489282	96906	MS24674-3	SCREW,CAP,SOCKET HE.....	6
2	PAFZZ	5310009338119	80205	MS35338-137	WASHER,LOCK.....	6
3	PAFZZ	5315008100505	96906	MS16555-628	PIN,STRAIGHT,HEADLE.....	4
4	PAFZZ	1240010438210	19200	10554818	PLATE,SPLINE.....	1
5	PAFZZ	1240010521979	19200	10554821	STUD ASSEMBLY,ECCEN.....	1
6	PAFZZ	1240010438197	19200	10554815	PLATE,SPLINE.....	1
7	XAHZZ		19200	13005093	ADAPTER,QUADRANT.....	1
8	PAHZZ	5305009575897	96906	MS24673-11	SCREW,CAP,SOCKET HE.....	2
9	PAHZZ	5310009338121	96906	MS35338-139	WASHER,LOCK.....	2
10	PAHZZ	5325002913495	96906	MS124697	INSERT,SCREW THREAD USED ONLY ON THE M172 ADAPTER PN 11729607.....	4
					UOC:BN3	
11	PAFZZ	5315010437428	19200	11727890	KEY,MACHINE.....	2
12	XAHZZ		19200	11732206	PIN,GROOVED,HEADED.....	1
13	XAHZZ		19200	13005092	GEAR SECTOR,WORM WH.....	1
14	PAHZZ	5305009409487	96906	MS35275-225	SCREW,MACHINE.....	2
15	XAHZZ		96906	MS16555-646	PIN,STRAIGHT,HEADLE.....	2
16	PAHZZ	5325002904480	96906	MS124735	INSERT,SCREW THREAD USED ONLY ON THE M172 ADAPTER PN 11729607.....	1
					UOC:BN3	

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
11741101/12984713/12984775**

REPAIR PARTS LIST




Figure 23. M137 Panoramic Telescope, 11741101; M137A2 Panoramic Telescope, 12984713; and M137A3 Panoramic Telescope, 12984775.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 23. TELESCOPE, PANORAMIC, M137 11741101; M137A2, 12984713; M137A3, 12984775	
1	PAHDD	1240010444561	19200	11741105	HEAD ASSEMBLY,TELES USED ON M137, M137A2,M137A3	
1A	PAHHH	6650010926476	19200	10554778	SEE FIG 25 FOR ASSY BREAKDOWN..... SPACER,OPTICAL ELEM SEE FIG 27 FOR ASSY BREAKDOWN.....	1 1
2	PCHHL	1240010628264	19200	11741202	TELESCOPE SUBASSEMB USED ON M137 ONLY SEE FIG 28 FOR ASSY BREAKDOWN..... UOC:F42	1
2	PAHDD	1240014861345	19200	12961438	TELESCOPE SUBASSEMB USED ON M137A2 AND M137A3 ONLY SEE FIG 28 FOR ASSY BREAKDOWN..... UOC:BH5,BH6	1
3	PAFZZ	5355008986791	19200	8587348	KNOB ASSEMBLY.....	1
4	PCHDL	1240010446915	19200	11741102-1	COUNTER BOX ASSEMBL USED ON M137 ONLY SEE FIG 32,33 AND 34 FOR ASSY BREAKDOWN..... UOC:F42	1
4	PAHDD	1240014860293	19200	12984734	COUNTER BOX ASSEMBL USED ON M137A2 AND M137A3 ONLY SEE FIGS 32,33 AND 34 FOR ASSY BREAKDOWN..... UOC:BH5,BH6	1
5	PAHDD	1240010439462	19200	11741201	ELBOW ASSEMBLY,PAN USED ON M137 ONLY SEE FIG 30 FOR ASSY BREAKDOWN..... UOC:F42	1
5	PAHDD	1240014862738	19200	12984733	ELBOW ASSEMBLY,PANT USED ON M137A2 AND M137A3 ONLY SEE FIG 30 FOR ASSY BREAKDOWN..... UOC:BH5,BH6	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
11741101/12984713/12984775
PARTS**

REPAIR PARTS LIST




Figure 24. M137 Panoramic Telescope, 11741101; M137A2 Panoramic Telescope, 12984713; and M137A3 Panoramic Telescope, 12984775, Parts (Sheet 1 of 3).




Figure 24. M137 Panoramic Telescope, 11741101; M137A2 Panoramic Telescope, 12984713; and M137A3 Panoramic Telescope, 12984775, Parts (Sheet 2 of 3).




Figure 24. M137 Panoramic Telescope, 11741101; M137A2 Panoramic Telescope, 12984713; and M137A3 Panoramic Telescope, 12984775, Parts (Sheet 3 of 3).

SECTION II		TM9-1240-375-34&P			(6)	(7)
(1)	(2)	(3)	(4)	(5)		
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 24. TELESCOPE, PANORAMIC, M137 11741101; M137A2, 12984713; M137A3, 12984775 PARTS						
1	PAHZZ	5305009887604	80205	MS16995-28	SCREW,CAP,SOCKET HE.....	4
1A	PAHZZ	5305009887602	80205	MS16995-26	SCREW,CAP,SOCKET HE USED ON M137 AND M137A3 ONLY.....	4
2	PAHZZ	5310009338119	80205	MS35338-137	UOC: BH5, F42	
3	PCHZZ	5331005841582	81343	AS3578-130	WASHER, LOCK.....	13
3	PCHZZ	5331005841582	81343	AS3578-130	O-RING.....	1
3	PCHZZ	5331005841582	81343	AS3578-130	UOC: BH6	
4	PAHZZ	5305000546670	96906	MS51957-45	O-RING.....	2
5	PAFZZ	5315008159366	80205	MS16555-622	UOC: BH5, F42	
5A	PAOZZ	5315015240124	19200	13005041	SCREW, MACHINE.....	5
6	PCHZZ	5331014650909	81343	AS3578-134	PIN, STRAIGHT, HEADLE.....	1
7	PAHZZ	1240010439465	19200	11741182	PIN, QUICK RELEASE.....	4
8	PAHZZ	5305007015078	96906	MS51959-65	UOC: BH5, BH6	
9	PAOZZ	1240010464258	19200	10554773	O-RING.....	1
10	PAFZZ	9905002572756	19200	11741194	RETAINER, ELBOW.....	2
11	PAFZZ	5310009282690	80205	MS35338-134	SCREW, MACHINE.....	4
12	PAFZZ	5305000545635	96906	MS51957-1	UOC: F42	
13	PAFZZ	9905010495129	19200	11741171	SCREW, MACHINE.....	4
13	PAFZZ	9905014857528	19200	12984738	UOC: F42	
13	PAFZZ	9905014857527	19200	12984776	PLATE, IDENTIFICATIO.....	1
14	PAOZZ	5305009591082	80205	MS16995-18	UOC: F42	
15	PAOZZ	5310009296395	80205	MS35338-136	PLATE, IDENTIFICATIO.....	1
16	PAOZZ	4010014643142	19200	12984664	UOC: BH6	
17	PAOZZ	5340014643141	19200	12984661	PLATE, IDENTIFICATIO.....	1
18	PAOZZ	6160014851914	19200	12984693	UOC: BH5	
19	PAOZZ	5330014853480	19200	12984698	SCREW, MACHINE.....	7
20	PAOZZ	5305007640071	80205	MS51959-47	UOC: BH5, BH6	
21	PAOZZ	5935014857531	19200	12984719	WASHER, LOCK.....	7
22	PAFZZ	5305000545636	96906	MS51957-2	UOC: BH5, BH6	
23	PAFZZ	5310009282690	80205	MS35338-134	WIRE ROPE ASSEMBLY.....	1
					UOC: BH5, BH6	
					CAP-PLUG, PROTECTIVE.....	1
					UOC: BH5, BH6	
					COVER, BATTERY BOX.....	1
					UOC: BH5, BH6	
					GASKET.....	1
					UOC: BH5, BH6	
					SCREW, MACHINE.....	2
					UOC: BH5, BH6	
					BRACKET, ELECTRICAL.....	1
					UOC: BH5, BH6	
					SCREW, MACHINE.....	2
					UOC: BH5, BH6	
					WASHER, LOCK.....	2
					UOC: BH5, BH6	

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**HEAD ASSEMBLY
11741105**

REPAIR PARTS LIST




Figure 25. Head Assembly, 11741105.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 25. HEAD ASSEMBLY 11741105						
1	PAHZZ	5305010468323	19200	10556183	SCREW, EXTERNALLY RE.....	1
2	PAHZZ	5305008432841	80205	MS51021-1	SETSCREW.....	1
3	PAFZZ	4820010530223	19200	10556186	VALVE, SAFETY RELIEF.....	1
4	PAHZZ	5310011402500	19200	8626196	WASHER, FLAT.....	1
5	XBHZZ		19200	10554774	PLUNGER.....	1
6	XBHZZ		19200	8626201	ACTUATOR, TELESCOPE.....	1
7	XBHZZ		19200	8626199	BUSHING, MACHINE THR.....	1
8	PAFZZ	5331005582310	81343	AS3578-013	O-RING.....	1
9	PAFZZ	5355010836241	19200	8626195	KNOB.....	1
10	PAFZZ	5305005767266	80205	MS51021-22	SETSCREW.....	2
11	PAHZZ	5365010521298	19200	11741236	PLUG, MACHINE THREAD.....	1
12	PAHZZ	5360010455461	96906	MS24585-1067	SPRING, HELICAL, COMP.....	1
13	XBHZZ		19200	11741235	PLUNGER.....	1
14	PAHZZ	5331002483836	81343	AS29513-12	O-RING.....	2
15	PAHZZ	5305005435832	80205	MS51021-11	SETSCREW.....	4
16	XAHZZ		19200	11741106	HOUSING, HEAD.....	1
17	XBHZZ		19200	11741174	PIVOT, PRISM.....	1
18	PAHZZ	9905014511585	19200	11741234	COVER, PLATE.....	1
19	PAHZZ	5305007702533	96906	MS51959-13	SCREW, MACHINE.....	3
20	PAHZZ	5340010480791	19200	10549273-3	PLUNGER, QUICK RELEA.....	1
21	PAHZZ	6650010478287	19200	11741121	PRISM, OPTICAL INSTR.....	1
22	PAHZZ	1240000699363	19200	8626291	WINDOW, OPTICAL INST.....	1
23	PAHZZ	5330000699361	19200	8626228	SEAL, NONMETALLIC RO.....	1
24	PAHHH	1240010444560	19200	11741126	COVER ASSEMBLY SEE FIG 26 FOR ASSY BREAKDOWN.....	1
25	PAHZZ	5305007637822	96906	MS51959-14	SCREW, MACHINE.....	4
26	XBHZZ		19200	11741233	PIVOT, PRISM.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**COVER ASSEMBLY
11741126**

REPAIR PARTS LIST




Figure 26. Cover Assembly, 11741126.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 26. COVER ASSEMBLY 11741126						
1	PAFZZ	5315010491390	19200	8626226	PIN, STRAIGHT, HEADLE.....	1
2	PAFZZ	5315008475677	96906	MS16555-626	PIN, STRAIGHT, HEADLE.....	1
3	PAFZZ	5360009336573	19200	8626227	SPRING, HELICAL, TORS.....	1
4	XAFZZ		19200	11741173	RETAINER.....	1
5	PAFZZ	3040009378289	19200	8626297	DETENT PLATE.....	1
6	PAFZZ	5360008936095	19200	8262100	SPRING, HELICAL, COMP.....	1
7	XAFZZ		19200	11741120	COVER PLATE.....	1
8	PAFZZ	5340007641669	19200	8262098	POST, ELECTRICAL-MEC.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**OPTICAL ELEMENT SPACER
10554778**

REPAIR PARTS LIST




Figure 27. Optical Element Spacer, 10554778.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 27. SPACER, OPTICAL ELEMENT 10554778	
1	PAHZZ	5315009887409	96906	MS16555-634	PIN, STRAIGHT, HEADLE.....	1
					UOC: BH5, F42	
2	XAHZZ		19200	10554778-1	SPACER, TELESCOPE HEAD.....	1
					UOC: BH5, F42	

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**TELESCOPE SUBASSEMBLY, M137
11741202
AND
TELESCOPE SUBASSEMBLY, M137A2/M137A3
12961438**

REPAIR PARTS LIST




Figure 28. Telescope Subassembly, M137, 11741202, and Telescope Subassembly, M137A2/M137A3, 12961438.

SECTION II		TM9-1240-375-34&P			(6)	(7)
(1)	(2)	(3)	(4)	(5)		
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 28. TELESCOPE SUBASSEMBLY						
M137, 11741202; M137A2 AND M137A3,						
12961438						
1	PAHZZ	5305000546654	96906	MS51957-30	SCREW,MACHINE.....	9
2	PAHZZ	5310009296395	80205	MS35338-136	WASHER,LOCK.....	11
3	PAHZZ	5315008251207	80205	MS16555-627	PIN,STRAIGHT,HEADLE.....	2
4	PAHZZ	5330010475724	19200	11741123	RETAINER,PACKING.....	1
5	PCHZZ	5331008511020	19200	8615998	O-RING.....	1
6	PCHZZ	5330015232319	19200	13005078	SEAL,NONMETALLIC RO.....	1
7	PCHZZ	5330015232320	19200	13005077	SEAL,NONMETALLIC RO.....	1
8	PAHZZ	5315001766116	96906	MS16555-636	PIN,STRAIGHT,HEADLE.....	1
9	PAHZZ	3020015094226	19200	11741203	GEAR,WORM WHEEL.....	1
10	PCHZZ	5331010078595	81343	MS28775-130	O-RING.....	1
11	XAHZZ		19200	11741107	HOUSING BODY, WORM GEAR.....	1
12	PAHZZ	1240010460896	19200	11741186	WORM SHAFT ASSEMBLY.....	1
13	PCHZZ	5331005313714	81343	AS3578-216	O-RING.....	1
14	XBHZZ		19200	11741652	CAP, WORM SHAFT.....	1
15	PCHZZ	5331005802278	81343	AS3578-010	O-RING.....	1
16	PAHZZ	5310001503792	19200	10553927	WASHER,RECESSED.....	1
17	PAHZZ	5310001503708	19200	10553928	WASHER,SPRING TENS.....	1
18	PAHZZ	1240010446917	19200	10554781	PLATE,M137 TEL PAN.....	1
19	PAHZZ	5305000546652	96906	MS51957-28	SCREW,MACHINE.....	2
20	PAHZZ	5315007029651	96906	MS16555-618	PIN,STRAIGHT,HEADLE.....	2
21	PAHZZ	1240010439464	19200	11741191	GEAR ASSEMBLY.....	1
22	PAHZZ	5315000569386	96906	MS16555-640	PIN,STRAIGHT,HEADLE.....	2
23	PAHZZ	5305010437710	80205	MS51021-101	SETSCREW.....	1
24	PAHZZ	5365010502177	19200	10555110	PLUG,MACHINE THREAD.....	1
25	PCHZZ	5331014493292	81343	AS3578-016	O-RING.....	1
26	PAHZZ	5360010468830	19200	11741160	SPRING,HELICAL,COMP.....	1
27	PAHZZ	5340009277290	19200	8587432	PLUNGER,DETENT.....	1
28	PAFZZ	4820010530223	19200	10556186	VALVE,SAFETY RELIEF.....	1
29	PCHDD	1240010439463	19200	11741200	OBJECTIVE AND RETIC USED ON M137 ONLY	
					SEE FIG 29 FOR ASSY BREAKDOWN.....	1
					UOC:F42	
29	PAHDD	1240014860296	19200	12961437	OBJECTIVE AND RETIC USED ON M137A2 AND M137A3 ONLY	
					SEE FIG 29 FOR ASSY BREAKDOWN.....	1
					UOC:BH5,BH6	
30	PAHZZ	5305007640068	80205	MS51959-45	SCREW,MACHINE.....	4

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**OBJECTIVE AND RETICLE ASSEMBLY, M137
11741200
AND
OBJECTIVE AND RETICLE ASSEMBLY, M137A2/M137A3
12961437**

REPAIR PARTS LIST





Figure 29. Objective and Reticle Assembly, M137, 11741200, and Objective and Reticle Assembly, M137A2/M137A3, 12961437 (Sheet 1 of 2).



M137A2/M137A3

Figure 29. Objective and Reticle Assembly, M137, 11741200, and Objective and Reticle Assembly, M137A2/M137A3, 12961437 (Sheet 2 of 2).

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 29. OBJECTIVE AND RETICLE ASSEMBLY M137, 11741200; M137A2 AND M137A3, 12961437	
1	XADZZ		19200	11741108	ADAPTER,CELL.....	1
2	PADZZ	9905010695632	19200	10556184	PLATE,IDENTIFICATIO USED ON M137 ONLY.....	1
					UOC:F42	
3	PCDZA	6260010519606	19200	11729515	LAMP,NUCLEAR USED ON M137 ONLY.....	4
					UOC:F42	
4	PADZZ	5365010447070	19200	11741240	BUSHING,NONMETALLIC USED ON M137 ONLY.....	1
					UOC:F42	
5	PADZZ	5305008007261	80205	MS51021-9	SETSCREW.....	1
6	PAHZZ	5325005433981	96906	MS16633-4009	RING,RETAINING.....	2
7	PADZZ	5315010480650	19200	11741207	PIN,GROOVED,HEADLES.....	2
8	PAHZZ	1240010444557	19200	11741178	COUPLING,CELL ASSEM.....	1
9	PADZZ	1240010468377	19200	11741208	RETAINER,OPTICAL EL.....	1
10	PADZZ	6650010479214	19200	11741180	RETICLE,OPTICAL INS.....	1
11	XADZZ		19200	11741188	CELL, OPTICAL ELEMENT.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**ELBOW TELESCOPE, M137
11741201
AND
ELBOW TELESCOPE, M137A2/M137A3
12984733**

REPAIR PARTS LIST




Figure 30. Elbow Assembly, M137, 11741201, and Elbow Assembly, M137A2/M137A3, 12984733 (Sheet 1 of 2).




Figure 30. Elbow Assembly, M137, 11741201, and Elbow Assembly, M137A2/M137A3, 12984733 (Sheet 2 of 2).

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 30. ELBOW ASSEMBLY M137, 11741201; M137A2 AND M137A3, 12984733	
1	XAHZZ		19200	11741110	CELL ASSEMBLY,OPTIC (ADAPTER).....	1
2	PCHZZ	5331014712403	81343	AS3578-140	O-RING.....	1
3	PAHZZ	5340012449855	19200	11741179	COVER,ACCESS ELBOW.....	1
4	PAHZZ	5310009296395	80205	MS35338-136	WASHER,LOCK.....	8
5	PAHZZ	5305000546653	96906	MS51957-29	SCREW,MACHINE.....	4
6	PAHZZ	5305009591082	80205	MS16995-18	SCREW,MACHINE.....	4
7	XAHZZ		19200	11741135	ELBOW TELESCOPE USED ON M137 ONLY..	1
					UOC:F42	
7	XAHZZ		19200	12961441	ELBOW TELESCOPE USED ON M137A2 AND M137A3 ONLY.....	1
					UOC:BH5,BH6	
8	PAOZZ	4820012350223	19200	8200055	CAP,AIR VALVE.....	1
9	PAFZZ	5340004644792	19200	10516567	STRAP,RETAINING.....	1
10	PAOZZ	2640000603543	96906	MS51377-2	VALVE CORE.....	1
11	PAFZZ	4820001141096	96906	MS51607-1	STEM,FLUID VALVE.....	1
12	PAFZZ	1240010444556	19200	11741196	LEVER,PLUNGER RELEA.....	1
13	PAHZZ	5305008007261	80205	MS51021-9	SETSCREW.....	2
14	PAFZZ	5305008205433	96906	MS51023-10	SETSCREW.....	1
15	PAHZZ	5331002526050	81343	AS29513-138	O-RING.....	1
16	PAHHD	6650012642348	19200	11741137	CELL ASSEMBLY,OPTIC SEE FIG 31 FOR ASSY BREAKDOWN.....	1
17	PAFZZ	5360010439541	19200	11741198	SPRING,HELICAL,COMP.....	1
18	PAFZZ	5340010439476	19200	11741197	PLUNGER,DETENT.....	1
19	PADZZ	1240014857536	19200	12984716	WINDOW,OPTICAL INST.....	1
					UOC:BH5,BH6	
20	PADZZ	1240014857530	19200	12984717	RETAINER,OPTICAL EL.....	1
					UOC:BH5,BH6	

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**OPTICAL CELL ASSEMBLY
11741137**

REPAIR PARTS LIST




Figure 31. Optical Cell Assembly, 11741137.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 31. CELL ASSEMBLY, OPTICAL	
					11741137	
1	PAFZZ	4820010530223	19200	10556186	VALVE,SAFETY RELIEF.....	1
2	XAHZZ		19200	11741133	CELL, OPTICAL ELEMENT.....	1
3	PAHZZ	6650005049915	19200	5049915	LENS,OPTICAL INSTRU.....	1
4	XBHZZ		19200	8626233	SPACER,OPTICAL ELEM.....	1
5	PAHZZ	6650005049914	19200	5049914	LENS,OPTICAL INSTRU.....	1
6	PAHZZ	5365001773931	19200	8626258	RING,EXTERNALLY THR.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

COUNTER BOX ASSEMBLY, M137

11741102-1

AND

COUNTER BOX ASSEMBLY, M137A2/M137A3

12984734

EXTERNAL PARTS

REPAIR PARTS LIST




Figure 32. Counter Box Assembly, M137, 11741102-1, and Counter Box Assembly, M137A2/M137A3, 12984734, External Parts.

SECTION II		TM9-1240-375-34&P			(6)	(7)
(1)	(2)	(3)	(4)	(5)		
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 32. COUNTER BOX ASSEMBLY M137 11741102; M137A2 AND M137A3, 12984734, EXTERNAL PARTS						
1	PAHZZ	5305000546670	96906	MS51957-45	SCREW,MACHINE (FOR SHIPPING ONLY)..	3
2	PAHZZ	5310009338119	80205	MS35338-137	WASHER,LOCK (FOR SHIPPING ONLY)....	3
3	PAHZZ	5340010439312	19200	11741230	COVER,ACCESS (FOR SHIPPING ONLY)...	1
4	PCHZZ	5330010520009	19200	11741209	SEAL,NONMETALLIC SP (FOR SHIPPING ONLY).....	1
5	PAFZZ	4820001141096	96906	MS51607-1	STEM,FLUID VALVE.....	1
6	PAOZZ	2640000603543	96906	MS51377-2	VALVE CORE.....	1
7	PAOZZ	4820012350223	19200	8200055	CAP,AIR VALVE.....	1
8	PAFZZ	5340004644792	19200	10516567	STRAP,RETAINING.....	1
9	PAOZZ	7690002572746	19200	11731011	DECAL USED ON M137 ONLY DISPOSAL INSTRUCTIONS TRITIUM INSTRUMENTS.....	1
10	PAHZZ	5330010450718	19200	11741172	UOC:F42 GASKET.....	1
11	XBHZZ		19200	11741161	COVER, COUNTER HOUSING.....	1
12	PAHZZ	5310009296395	80205	MS35338-136	WASHER,LOCK.....	12
13	PAHZZ	5305000546651	96906	MS51957-27	SCREW,MACHINE.....	12
14	PAHZZ	5305000546651	96906	MS51957-27	SCREW,MACHINE USED AT GS LEVEL FOR M137.....	16
14	PAFZZ	5305000546651	96906	MS51957-27	UOC:F42 SCREW,MACHINE USED AT DS LEVEL FOR M137A2 AND M137A3.....	4
15	PAHZZ	5310009296395	80205	MS35338-136	UOC:BH5,BH6 WASHER,LOCK USED AT GS LEVEL FOR M137.....	4
15	PAFZZ	5310009296395	80205	MS35338-136	UOC:F42 WASHER,LOCK USED AT DS LEVEL FOR M137A2 AND M137A3.....	4
16	PAHZZ	5315009408033	81343	MS9390-290	UOC:BH5,BH6 PIN,STRAIGHT,HEADLE USED AT GS LEVEL FOR M137.....	2
16	PAFZZ	5315009408033	81343	MS9390-290	UOC:F42 PIN,STRAIGHT,HEADLE USED AT DS LEVEL FOR M137A2 AND M137A3.....	2
17	PBFZZ	5340014857534	19200	12961439	UOC:BH5,BH6 STOP,MECHANICAL USED AT DS LEVEL FOR M137A2 AND M137A3.....	1
17	PBHZZ	5340010468343	19200	10554777	UOC:BH5,BH6 PLATE,STOP USED AT GS LEVEL FOR M137.....	1
18	PAHZZ	5305000545647	96906	MS51957-13	UOC:F42 SCREW,MACHINE.....	4
19	PAHZZ	5310009338118	80205	MS35338-135	WASHER,LOCK.....	4
20	PAHZZ	1240010444558	19200	11741164	KNOB ASSEMBLY.....	1
21	PAHZZ	5331005841222	81343	AS3578-015	O-RING.....	1
22	PAFZZ	5315008067040	96906	MS16555-620	PIN,STRAIGHT,HEADLE.....	1
23	PAFZZ	5355010463761	19200	11741146	KNOB.....	1
24	PAHZZ	5340010437380	19200	10556190	COVER,ACCESS.....	1

SECTION II		TM9-1240-375-34&P			(6)	(7)
(1)	(2)	(3)	(4)	(5)		
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
25	PAHZZ	6650000664999	19200	8626400	WINDOW,OPTICAL INST.....	1
26	PAHZZ	5340010496190	19200	11741155	PLATE,RETAINING,WIN.....	1
27	PAHZZ	5305010718747	96906	MS90402-1	SCREW,EXTERNALLY RE.....	2
28	PAHZZ	5305007776039	96906	MS51959-12	SCREW,MACHINE.....	6
29	PAHZZ	1240010467104	19200	10555186	MASK,WINDOW.....	2
30	PAHZZ	1240010447056	19200	10555155	WINDOW,OPTICAL INST.....	2
31	PAHZZ	5340010447069	19200	11741154	PLATE,RETAINING,WIN.....	2
32	PAFZZ	5305000545635	96906	MS51957-1	SCREW,MACHINE USED ON M137 ONLY.... UOC:F42	2
33	PAFZZ	5310009282690	80205	MS35338-134	WASHER,LOCK USED ON M137 ONLY..... UOC:F42	2
34	PAFZZ	9905002572750	19200	11729582	PLATE,INSTRUCTION USED ON M137 ONLY UOC:F42	1
35	PAFZZ	5305000546652	96906	MS51957-28	SCREW,MACHINE.....	2
36	PAFZZ	5310009296395	80205	MS35338-136	WASHER,LOCK.....	2
37	PAFFF	1240010444559	19200	11741163	COVER ASSEMBLY SEE FIG 35 FOR ASSY BREAKDOWN.....	1
38	PAOZZ	5305000546650	96906	MS51957-26	SCREW,MACHINE USED ON M137A2 AND M137A3 ONLY.....	1
39	PAOZZ	5340014643141	19200	12984661	CAP-PLUG,PROTECTIVE USED ON M137A2 AND M137A3 ONLY.....	2
40	PAOZZ	5340014857535	19200	12984751	STRAP,RETAINING USED ON M137A2 AND M137A3 ONLY.....	1
41	PAOZZ	6160014857533	19200	12984725	BATTERY BOX USED ON M137A2 AND M137A3 ONLY.....	1
42	PAOZZ	5310009296395	80205	MS35338-136	WASHER,LOCK USED ON M137A2 AND M137A3 ONLY.....	5
43	PAOZZ	5305009591082	80205	MS16995-18	SCREW,MACHINE USED ON M137A2 AND M137A3 ONLY.....	4
44	PAOZZ	5330014858715	19200	12984723	GASKET USED ON M137A2 AND M137A3 ONLY.....	1
45	PAHZZ	5365015172168	19200	13005052	SPACER,PLATE USED ON M137A2 AND M137A3 ONLY.....	1
46	PAHZZ	5305007702533	80205	MS51959-13	SCREW,MACHINE USED ON M137A2 AND M137A3 ONLY.....	2
47	PADZZ	5340015232317	19200	12984726	PLATE,MOUNTING USED ON M137A2, M137A3.....	1
48	PADZZ	5305007640066	96906	MS51959-44	SCREW,MACHINE USED ON M137A2,M137A3 UOC:BH5,BH6	2

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**COUNTER BOX ASSEMBLY, M137
11741102-1
AND
COUNTER BOX ASSEMBLY, M137A2/M137A3
12984734
PARTS**

REPAIR PARTS LIST




Figure 33. Counter Box Assembly, M137, 11741102-1, and Counter Box Assembly, M137A2/M137A3, 12984734, Parts.

SECTION II		TM9-1240-375-34&P				
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 33. COUNTER BOX ASSEMBLY M137						
11741102; M137A2 AND M137A3,						
12984734, PARTS						
1	PAHZZ	5315007029651	96906	MS16555-618	PIN, STRAIGHT, HEADLE.....	2
2	XBHZZ		19200	11741229	COUPLING.....	2
3	PAHZZ	6680010518404	19200	11741118-1	COUNTER, ROTATING.....	1
4	PAHZZ	5310009338118	80205	MS35338-135	WASHER, LOCK.....	15
5	PAHZZ	5305000545649	96906	MS51957-15	SCREW, MACHINE.....	4
6	PAHZZ	6680011000775	19200	11741118-2	COUNTER, ROTATING.....	1
7	PAHZZ	5305009590379	80205	MS16995-10	SCREW, CAP, SOCKET HE.....	7
8	XBHZZ		19200	11741111	MOUNT, COUNTER.....	1
9	PAHZZ	6680010492865	19200	11741119	COUNTER, ROTATING.....	1
10	PAHZZ	5315008067039	96906	MS16555-604	PIN, STRAIGHT, HEADLE.....	1
11	XBHZZ		19200	11741228	COUPLING, RESET.....	1
12	PAHZZ	5305000546653	96906	MS51957-29	SCREW, MACHINE.....	3
13	PAHZZ	9530015220697	19200	12999464	BAR, METAL.....	1
UOC: BH5, BH6						
14	PAHZZ	3020010444562	19200	11741103	GEAR, BLOCK ASSEMBLY OPTICAL ELEMENT	1
15	PAHZZ	1240010439460	19200	11741224	ECCENTRIC, PAN TEL.....	1
16	PCHZZ	5331005840265	81343	MS28775-012	O-RING.....	2
17	PAHZZ	1240010659829	19200	11741147	STOP.....	1
18	PAHZZ	5305000545647	96906	MS51957-13	SCREW, MACHINE.....	1
19	PAHZZ	1240010659826	19200	10556189	STOP.....	1
20	PAHZZ	1240010439461	19200	11741223	ECCENTRIC, PAN TEL.....	1
21	PAHZZ	5310009296395	80205	MS35338-136	WASHER, LOCK.....	3

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**COUNTER BOX ASSEMBLY, M137
11741102-1**

**AND
COUNTER BOX ASSEMBLY, M137A2/M137A3
12984734
INTERNAL PARTS**

REPAIR PARTS LIST





Figure 34. Counter Box Assembly, M137, 11741102-1, and Counter Box Assembly, M137A2/M137A3, 12984734, Internal Parts (Sheet 1 of 2).



M137A2/M137A3

Figure 34. Counter Box Assembly, M137, 11741102-1, and Counter Box Assembly, M137A2/M137A3, 12984734, Internal Parts (Sheet 2 of 2).

SECTION II			TM9-1240-375-34&P		(6)	(7)
(1)	(2)	(3)	(4)	(5)		
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 34. COUNTER BOX ASSEMBLY M137 11741102; M137A2 AND M137A3, 12984734, INTERNAL PARTS						
1	XADZZ		19200	12961440	HOUSING ASSEMBLY USED ON M137A2 AND M137A3 ONLY.....	1
					UOC: BH5, BH6	
1	XADZZ		19200	11741104	HOUSING ASSEMBLY USED ON M137 ONLY. UOC: F42	1
2	PBDZZ	5355010498955	19200	11741195	POINTER, DIAL.....	1
3	PBDZZ	5305000685409	80205	MS16995-1	SCREW, CAP, SOCKET HE.....	7
4	PCDZA	6240010438209	19200	11729559	LAMP, NUCLEAR, ASSEMB USED ON M137 ONLY.....	6
					UOC: F42	
5	PADZZ	1240010467105	19200	11741170	ADAPTER, COUNTER ASS USED ON M137 ONLY.....	1
					UOC: F42	
6	PADZZ	5340010464277	19200	11741158	CLIP, SPRING TENSION USED ON M137 ONLY.....	3
					UOC: F42	
7	PADZZ	5310009338118	80205	MS35338-135	WASHER, LOCK USED ON M137 ONLY.....	10
					UOC: F42	
8	PADZZ	5305000545646	96906	MS51957-12	SCREW, MACHINE USED ON M137 ONLY....	10
					UOC: F42	
9	PADZZ	5340010520011	19200	11741157	CLIP, SPRING TENSION USED ON M137 ONLY.....	3
					UOC: F42	
10	PBDZZ	5355010439292	19200	11741248	POINTER, DIAL.....	1
11	PBDZZ	5305007642966	96906	MS51959-2	SCREW, MACHINE.....	2
12	XBDZZ		19200	11741211	TAB USED ON M137 ONLY.....	1
					UOC: F42	
13	PADZZ	5340010546588	19200	11741159	CLAMP, SYNCHRO USED ON M137 ONLY....	2
					UOC: F42	

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M137/M137A2/M137A3 PANORAMIC TELESCOPE
(1240-01-038-0531/1240-01-483-6103/1240-01-483-6100)**

**COVER ASSEMBLY
11741163**

REPAIR PARTS LIST




Figure 35. Cover Assembly, 11741163.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR		PART			
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 35. COVER ASSEMBLY 11741163						
1	PAFZZ	5315000824858	96906	MS16556-621	PIN, STRAIGHT, HEADLE.....	2
2	XAFZZ		19200	10555147	BRACKET, COVER.....	1
3	XAFZZ		19200	11741156	COVER, COUNTER.....	1
4	PAFZZ	5360010462460	19200	10555178	SPRING, HELICAL, COMP.....	1
5	PAFZZ	3110009900475	96906	MS19060-1006	BALL, BEARING.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M138/M138A1 ELBOW TELESCOPE
(1240-01-038-0530/1240-01-515-8264)**

**ELBOW TELESCOPE, M138
11741626
AND
ELBOW TELESCOPE, M138A1
13005104
PARTS**

REPAIR PARTS LIST




Figure 36. Elbow Telescope, M138, 11741626, and Elbow Telescope, M138A1, 13005104, Parts.

SECTION II			TM9-1240-375-34&P		(6)	(7)
(1)	(2)	(3)	(4)	(5)		
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 36. TELESCOPE, ELBOW, M138 11741626, M138A1 13005104 PARTS						
1	PAOZZ	5305000570523	96906	MS51958-27	SCREW,MACHINE.....	1
2	PAOZZ	1240010437547	19200	11748011	EYESHIELD,OPTICAL I.....	1
3	PAOZZ	5340001710757	19200	8587448-3	CLAMP,LOOP.....	1
4	PAFFF	1240010438248	19200	10549272	LATCH SET,OPTICAL I INSTRUMENT	
					SEE FIG 38 FOR ASSY BREAKDOWN.....	1
5	PADZZ	5315007226591	96906	MS35672-16	PIN,GROOVED,HEADLES.....	2
6	PAFZZ	5310009338120	96906	MS35338-138	WASHER,LOCK.....	4
7	PAFZZ	5305000509229	96906	MS51957-63	SCREW,MACHINE.....	4
8	PAOZZ	9905002572746	19200	11731011	DECAL USED ON M138 ONLY	
					DISPOSAL INSTRUCTIONS	
					TRITIUM INSTRUMENTS.....	1
					UOC:F41	
9	PAFZZ	5310009282690	80205	MS35338-134	WASHER,LOCK.....	4
10	PAFZZ	5305000545636	96906	MS51957-2	SCREW,MACHINE.....	4
11	PAFZZ	9905010468337	19200	10549270	PLATE,IDENTIFICATIO N M138.....	1
					UOC:F41	
11	PAFZZ	9905015193056	19200	13005106	PLATE,IDENTIFICATIO N M138A1.....	1
					UOC:BM5	
12	PAFZZ	9905002572756	19200	11741194	PLATE,INSTRUCTION USED ON M138 ONLY	1
					UOC:F41	
13	PAFZZ	4820001141096	96906	MS51607-1	STEM,FLUID VALVE.....	1
14	PAOZZ	2640000603543	96906	MS51377-2	VALVE CORE.....	1
15	PAFZZ	5340004644792	19200	10516567	STRAP,RETAINING.....	1
16	PAOZZ	4820012350223	19200	8200055	CAP,AIR VALVE.....	1
17	PAOZZ	1240000840280	19200	10549868	COVER,FIRE CONTROL.....	1
18	PAFZZ	4820010530223	19200	10556186	VALVE,SAFETY RELIEF.....	1
19	PADZZ	5305005767266	80205	MS51021-22	SETSCREW.....	1
20	PADZZ	5315010483354	96906	MS16555-686	PIN,STRAIGHT,HEADLE.....	1
21	PADZZ	5315008414442	80205	MS16562-224	PIN,SPRING.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M138/M138A1 ELBOW TELESCOPE
(1240-01-038-0530/1240-01-515-8264)**

**M138/M138A1 ELBOW TELESCOPE
11741626/13005104
PARTS**

REPAIR PARTS LIST




Figure 37. M138/M138A1 Elbow Telescope, 11741626/13005104, Parts.

SECTION II		TM9-1240-375-34&P			(6)	(7)
(1)	(2)	(3)	(4)	(5)		
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 37. TELESCOPE, ELBOW, M138 11741626, M138A1 13005104 PARTS CONTINUED						
1	PAFZZ	5305008432841	80205	MS51021-1	SETSCREW.....	5
2	PAFZZ	5355010499238	19200	11748009	POINTER,DIAL.....	1
3	PAFZZ	5305000812651	96906	MS51038-15	SETSCREW.....	1
4	PAFZZ	5310010500478	19200	11748003	NUT,SLEEVE.....	1
5	PAFZZ	1240010434768	19200	11748010	SCALE,DIOPTER.....	1
6	XAFZZ		19200	8626451	STOP,MT TELESCOPE.....	1
7	PADZZ	5305010473997	80205	MS51021-103	SETSCREW.....	3
8	PAFZZ	1240012066341	19200	9386960	DIOPTER ADAPTER.....	1
9	PAFZZ	5305000546651	96906	MS51957-27	SCREW,MACHINE.....	8
10	PAFZZ	5310009338119	80205	MS35338-137	WASHER,LOCK.....	8
11	PADZZ	5315007226591	96906	MS35672-16	PIN,GROOVED,HEADLES.....	4
12	PADZZ	1240010480778	19200	11741627	CELL ASSEMBLY,OPTIC AL INSTRUMENT EYEPiece M138,M138A1.....	1
12A	PAFZZ	5331005293723	81343	AS29513-155	O-RING.....	1
13	PADZZ	6650015205989	19200	13005033	SPACER,OPTICAL ELEM NSTRUMENT M138A1.....	1
					UOC:BM5	
14	PADZZ	5305000546655	96906	MS51957-31	SCREW,MACHINE USED ON M138A1 ONLY..	8
					UOC:BM5	
15	PADZZ	5310009338119	80205	MS35338-137	WASHER,LOCK USED ON M138A1 ONLY....	8
					UOC:BM5	
16	PADZZ	5315008253748	80205	MS35672-18	PIN,GROOVED,HEADLES USED ON M138A1 ONLY.....	2
					UOC:BM5	
17	PADZZ	5331011182080	81343	M83461/1-332	O-RING.....	1
18	PADZZ	5331005293723	81343	AS29513-155	O-RING.....	1
					UOC:BM5	
19	PADZZ	1240015193054	19200	12984785	CELL ASSEMBLY,OPTIC AL INSTRUMENT RETICLE M138A1.....	1
					UOC:BM5	
19	PCDZA	1240010480779	19200	11729516	CELL ASSEMBLY,OPTIC AL INSTRUMENT RETICLE M138.....	1
					UOC:F41	
20	PADZZ	5305007261241	96906	MS21090-0412	SCREW,CAP,SOCKET HE.....	2
21	PADZZ	5305000546654	96906	MS51957-30	SCREW,MACHINE.....	4
22	PADZZ	6650010570054	19200	10554936	PRISM,OPTICAL INSTRUMENT.....	1
23	PADZZ	5305005767266	80205	MS51021-22	SETSCREW.....	2
24	PADZZ	1240010449851	19200	10549268	HOUSING,OPTICAL INSTRUMENT.....	1
25	PADZZ	1240015193052	19200	12984837	CELL ASSEMBLY,OPTIC AL INSTRUMENT OBJECTIVE M138A1.....	1
					UOC:BM5	
25	PADZD	1240010480777	19200	11741629	CELL ASSEMBLY,OPTIC AL INSTRUMENT OBJECTIVE M138.....	1
					UOC:F41	
26	PADZZ	5340015193055	19200	12984783	BRACKET,MOUNTING USED ON M138A1 ONLY.....	1
					UOC:BM5	
27	PADZZ	5305007640066	96906	MS51959-44	SCREW,MACHINE USED ON M138A1 ONLY..	3
					UOC:BM5	

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
28	PAOZZ	5330014853480	19200	12984698	GASKET USED ON M138A1 ONLY.....	1
					UOC:BM5	
29	PAOZZ	6160014851914	19200	12984693	COVER,BATTERY BOX USED ON M138A1	
					ONLY.....	1
					UOC:BM5	
30	PAOZZ	5310009296395	80205	MS35338-136	WASHER,LOCK USED ON M138A1 ONLY....	3
					UOC:BM5	
31	PAOZZ	5305009591082	80205	MS16995-18	SCREW,MACHINE USED ON M138A1 ONLY..	3
					UOC:BM5	
32	PAOZZ	5340014643141	19200	12984661	CAP-PLUG,PROTECTIVE USED ON M138A1	
					ONLY.....	1
					UOC:BM5	
33	PAOZZ	4010014643142	19200	12984664	WIRE ROPE ASSEMBLY USED ON M138A1	
					ONLY.....	1
					UOC:BM5	

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M138/M138A1 ELBOW TELESCOPE
(1240-01-038-0530/1240-01-515-8264)**

**OPTICAL INSTRUMENT LATCH SET
10549272**

REPAIR PARTS LIST




Figure 38. Optical Instrument Latch Set, 10549272.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
					FIGURE 38. LATCH SET, OPTICAL INSTRUMENT 10549272	
1	PAFZZ	5315005433986	96906	MS16555-651	PIN, STRAIGHT, HEADLE.....	1
2	PAFFF	5340010437489	19200	10549277	LATCH, OPTICAL INSTR SEE FIG 39 FOR ASSY BREAKDOWN.....	1
3	XAFZZ		19200	10549260	HOLDER, LATCH.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

**M138/M138A1 ELBOW TELESCOPE
(1240-01-038-0530/1240-01-515-8264)**

**OPTICAL INSTRUMENT LATCH
10549277**

REPAIR PARTS LIST




Figure 39. Optical Instrument Latch, 10549277.

SECTION II			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR		PART			
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 39. LATCH, OPTICAL INSTRUMENT 10549277						
1	PAFZZ	5305008290105	96906	MS51960-6	SCREW,MACHINE.....	2
2	PAFZZ	5340010434440	19200	10549265	COVER,ACCESS.....	1
3	XAFZZ		19200	10549262	LATCH,LOCK-RELEASE.....	1
4	PAFZZ	5325001879033	96906	MS16624-5015-1	RING,RETAINING.....	1
5	PAFZZ	5340010432209	19200	10549259	LEVER,LOCK-RELEASE.....	1
6	PAFZZ	5315006164736	80205	MS51923-190	PIN,SPRING.....	1
7	PAFZZ	5315010437434	19200	10549264	PIN,SHOULDER,HEADED.....	1
8	PAFZZ	5360010505307	19200	10549263	SPRING,HELICAL,EXTE.....	1

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

QUADRANT, FIRE CONTROL: M17 (1290-01-037-3883);
QUADRANT, FIRE CONTROL: M17A1 (1290-01-515-8260);
QUADRANT, FIRE CONTROL: M18 (1290-01-037-7289);
QUADRANT, FIRE CONTROL: M18A1 (1290-01-515-8262);
MOUNT, TELESCOPE AND QUADRANT: M171 (1240-01-039-7273);
MOUNT, TELESCOPE AND QUADRANT: M171A1 (1240-01-515-8265);
MOUNT, TELESCOPE AND QUADRANT: M172 (1240-01-037-7290);
MOUNT, TELESCOPE AND QUADRANT: M172A1 (1240-01-517-2171);
TELESCOPE, PANORAMIC: M137 (1240-01-038-0531);
TELESCOPE, PANORAMIC: M137A2 (1240-01-483-6103);
TELESCOPE, PANORAMIC: M137A3 (1240-01-483-6100);
TELESCOPE, ELBOW: M138 (1240-01-038-0530); AND
TELESCOPE, ELBOW: M138A1 (1240-01-515-8264)

SPECIAL TOOLS

REPAIR PARTS LIST




Figure 40. Special Tools (Sheet 1 of 3).




Figure 40. Special Tools (Sheet 2 of 3).




Figure 40. Special Tools (Sheet 3 of 3).

SECTION III			TM9-1240-375-34&P		(6)	(7)
(1)	(2)	(3)	(4)	(5)		
ITEM NO	SMR CODE	NSN	CAGEC	PART NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
FIGURE 40. SPECIAL TOOLS AND EQUIPMENT						
1	PEHZZ	5340010620275	19200	10558253-11	BRACKET,MOUNTING USED ON M171,M172, ALL MODELS.....	
2	PEHZZ	5340010620274	19200	12008990	BRACKET,MOUNTING (ATTACHMENT FOR LEVELING FIXTURE) USED ON M17 AND M18 ALL MODELS.....	
3	PEHZZ	4931010624255	19200	9327721	ADAPTER,EXTENSION USED WITH M137 AND M137A3 ONLY.....	
4	PAHZZ	4940001919215	19200	10555619	UOC:BH5,F42 ADAPTER,MECHANICAL USED ON M171, M172 ALL MODELS.....	
5	PEHZZ	4931008016861	19200	8213899	ADAPTER,FIXTURE USED WITH M137 ALL MODELS.....	
6	PAHZZ	1240011347103	19200	10555620	SIGHTING,DEVICE USED ON M171 ALL MODELS.....	
7	PEHZA	4931007691596	19200	7691596	FIXTURE,TELESCOPE T USED WITH M137 ALL MODELS.....	
8	PAHHD	6650006523553	19200	6523553	FIXTURE,TEST,OPTICAL EQUIPMENT (MEASURED IN MILS) USED ON M17,M18,M171,M172, ALL MODELS.....	
9	PAHZZ	6635007900733	11710	719-20MRP	TESTER,SPRING RESIL USED ON M171 ALL MODELS.....	
10	PACHH	1290008919999	19200	7197156	QUADRANT,FIRE CONTR OL USED ON M17,M18,M171,M172 ALL MODELS SEE TM9-1290-200-14&P FOR REPAIR PARTS.....	
11	PEHZZ	4931011285862	19200	10553898	INSPECTION FIXTURE USED ON M171 ALL MODELS.....	
12	PEHZZ	5210005466362	19200	7686087	LEVEL,PLATE MOUNTED USED WITH M17, M18,M137,M171,M172 ALL MODELS.....	
13	PAHZZ	1240005365557	19200	7680631	EYEPIECE ASSEMBLY,OPTICAL INSTRUMENT (DIOPTOMETER) USED WITH M137 AND M138 ALL MODELS.....	
14	PAHZZ	5120011518820	19200	11785506	ADAPTER,TORQUE WREN CH (FOR CORRECTION KNOB) USED ON M17 AND M18 ALL MODELS.....	
15	PAHZZ	5120011518817	19200	11785502	ADAPTER,TORQUE WREN CH (FOR ELEVATION KNOB) USED ON M17 AND M18 ALL MODELS.....	
16	PAHZZ	TBD	19200	11747955	ADAPTER,TORQUE WREN USED ON M137 ALL MODELS USED ON CLUTCH RELEASE KNOB.....	
17	PAHZZ	5120011518819	19200	11785507	ADAPTER,TORQUE WREN USE ON DIOPTER SCALE USED ON M138 ALL MODELS.....	
18	PAHZZ	3040009473044	19200	10512992	ADAPTER,HOUSING USED ON M171 ALL MODELS FOR CROSS LEVEL AND PITCH KNOBS.....	

SECTION III			TM9-1240-375-34&P			
(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR			PART		
NO	CODE	NSN	CAGEC	NUMBER	DESCRIPTION AND USABLE ON CODES(UOC)	QTY
19	PEHZZ	4931011320654	19200	9357947	ADAPTER,TORQUE USED ON M171 ALL MODELS USED ON COLLAR.....	
20	PEHZZ	4931005085434	19200	7197944	TEST FIXTURE,TELESC USE ON M138 ALL MODELS.....	
21	PAHZZ	5210002211842	08871	5033-012	GAGE,SURFACE USED WITH M137 ALL MODELS.....	
22	PAHZZ	1240001911379	19200	11738294	HOLDER,TELESCOPE MO.....	
23	PAHZZ	1240007573291	19200	7573291	COLLIMATOR,INFINITY.....	

END OF FIGURE

DIRECT SUPPORT AND GENERAL SUPPORT

QUADRANT, FIRE CONTROL: M17 (1290-01-037-3883);
QUADRANT, FIRE CONTROL: M17A1 (1290-01-515-8260);
QUADRANT, FIRE CONTROL: M18 (1290-01-037-7289);
QUADRANT, FIRE CONTROL: M18A1 (1290-01-515-8262);
MOUNT, TELESCOPE AND QUADRANT: M171 (1240-01-039-7273);
MOUNT, TELESCOPE AND QUADRANT: M171A1 (1240-01-515-8265);
MOUNT, TELESCOPE AND QUADRANT: M172 (1240-01-037-7290);
MOUNT, TELESCOPE AND QUADRANT: M172A1 (1240-01-517-2171);
TELESCOPE, PANORAMIC: M137 (1240-01-038-0531);
TELESCOPE, PANORAMIC: M137A2 (1240-01-483-6103);
TELESCOPE, PANORAMIC: M137A3 (1240-01-483-6100);
TELESCOPE, ELBOW: M138 (1240-01-038-0530); AND
TELESCOPE, ELBOW: M138A1 (1240-01-515-8264)

NATIONAL STOCK NUMBER INDEX

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5305-00-050-9229	36	7	6650-00-066-4999	5	6
5305-00-054-5635	2	27		32	25
	24	12	5305-00-067-9914	10	26
	32	32		17	7
5305-00-054-5636	2	12	5305-00-067-9917	9	24
	5	1	5305-00-068-5276	12	4
	5	9	5305-00-068-5409	34	3
	11	8	5330-00-069-9361	25	23
	13	9	1240-00-069-9363	25	22
	20	3	5315-00-078-8711	16	6
	24	22	5305-00-081-2651	37	3
	36	10	5315-00-082-4858	35	1
5305-00-054-5646	34	8	1240-00-084-0280	36	17
5305-00-054-5647	3	25	5310-00-089-5966	16	11
	32	18	4820-00-114-1096	2	31
	33	18		30	11
5305-00-054-5649	6	18		32	5
	33	5		36	13
5305-00-054-6650	2	21	5305-00-146-5701	10	1
	32	38	5331-00-149-8859	2	17
5305-00-054-6651	2	6	5310-00-150-3708	28	17
	17	8	5310-00-150-3792	28	16
	32	13	3110-00-156-7513	16	13
	32	14	3110-00-165-5922	17	3
	32	14	5340-00-171-0757	36	3
	37	9	5315-00-176-6116	28	8
5305-00-054-6652	2	35	5365-00-177-3931	31	6
	3	18	5310-00-186-1009	14	5
	28	19	5325-00-187-9033	39	4
	32	35	5315-00-188-0240	9	6
5305-00-054-6653	2	8	1240-00-191-1379	40	22
	2	10	4940-00-191-9215	40	4
	30	5	5210-00-221-1842	40	21
	33	12	5305-00-225-9891	15	1
5305-00-054-6654	2	19	5305-00-235-3528	19	4D
	28	1	5331-00-248-3836	3	14
	37	21	5331-00-248-3850	10	10
5305-00-054-6655	37	14	5331-00-252-6050	30	15
5305-00-054-6668	3	6	7690-00-257-2746	5	12
5305-00-054-6670	2	3		17	2
	24	4		32	9
	32	1		36	8
5315-00-056-9386	28	22	9905-00-257-2750	2	15
5305-00-057-0523	36	1		32	34
2640-00-060-3543	2	32	9905-00-257-2751	2	14
	30	10		11	6
	32	6	9905-00-257-2756	24	10
	36	14		36	12
5365-00-065-5319	16	14	1290-00-257-2769	4	3
6650-00-066-4998	5	11		7	3

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX

STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
1290-00-257-2769	11	2	5315-00-682-1727	3	5
5305-00-272-3533	10	16	5315-00-682-1733	14	19
5305-00-272-4123	16	8		15	5
5305-00-281-3120	9	22	5305-00-682-7753	19	10
	14	10	5305-00-685-3492	14	20
	20	11	5365-00-692-1492	4	5
5325-00-290-4480	22	16		7	1
5325-00-291-3495	22	10		11	4
5310-00-450-5946	14	6	1290-00-692-1493	4	3
5340-00-464-4792	2	33		7	3
	30	9		11	2B
	32	8	5305-00-701-5061	3	1
	36	15	5305-00-701-5078	24	8
5315-00-492-1962	12	1	5315-00-702-9651	28	20
6650-00-504-9914	31	5		33	1
6650-00-504-9915	31	3	5305-00-717-6955	7	5
4931-00-508-5434	40	20	5315-00-722-6591	36	5
5331-00-529-3723	37	12A		37	11
	37	18	5305-00-724-3454	2	37
5331-00-531-3714	28	13	5305-00-724-3478	2	1
1240-00-536-5557	40	13	5305-00-726-1241	37	20
5325-00-543-3981	29	6	1240-00-757-3291	40	23
5315-00-543-3986	38	1	5340-00-759-7626	4	1
5310-00-543-4652	11	7		7	6
	13	8		11	1
5305-00-543-5832	25	15	5305-00-763-7822	25	25
5210-00-546-6362	40	12	5305-00-764-0066	5	14
5310-00-550-5009	6	17		32	48
5331-00-550-6617	3	17		37	27
5331-00-551-9573	2	36	5305-00-764-0068	9	24A
5331-00-558-2310	3	22		28	30
	25	8	5305-00-764-0071	24	20
5305-00-576-7266	25	10	5340-00-764-1669	26	8
	36	19	5305-00-764-2966	34	11
	37	23	4931-00-769-1596	40	7
5331-00-580-2278	28	15	5305-00-770-2533	13	1
5331-00-584-0265	33	16		25	19
5331-00-584-1222	32	21		32	46
5331-00-584-1229	10	13	5305-00-777-6039	32	28
5331-00-584-1582	24	3	6635-00-790-0733	40	9
	24	3	5310-00-796-9592	16	12
5325-00-597-3302	18	5	5305-00-800-7261	11	5
5325-00-598-1840	6	12		29	5
5310-00-616-3555	17	9		30	13
5315-00-616-4736	39	6	4931-00-801-6861	40	5
5315-00-623-1761	6	8	5315-00-806-7039	6	3
5306-00-638-7719	2	41		7	7
6650-00-652-3553	40	8		33	10
5305-00-655-9246	21	7	5315-00-806-7040	32	22
5315-00-682-1726	6	1	5315-00-810-0505	9	19

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5315-00-810-0505	14	16	5310-00-929-6395	28	2
	20	5		30	4
	22	3		32	12
5315-00-815-9366	24	5	32	15	
5315-00-817-0889	4	6	32	15	
5306-00-817-4989	2	41	32	36	
5305-00-820-5433	30	14	32	42	
5315-00-825-1207	28	3	33	21	
5315-00-825-3748	37	16	37	30	
5305-00-829-0105	39	1	5360-00-933-6573	26	3
5315-00-834-0745	2	16	5310-00-933-8118	3	19
	3	10		6	19
5305-00-834-3385	19	2	12	5	
	19	4C	32	19	
	21	5	33	4	
5305-00-834-3388	19	4A	34	7	
5315-00-841-4442	36	21	5310-00-933-8119	2	4
5305-00-843-2841	25	2	3	2	
	37	1	9	10	
5315-00-847-5677	26	2	10	5	
5305-00-848-9282	10	4	10	7	
	14	26	12	8	
	22	1	14	27	
	28	5	16	3	
5331-00-851-1020	12	16	17	6	
5305-00-865-9516	40	10	19	6	
5360-00-893-6095	26	6	22	2	
5365-00-896-2251	4	4	24	2	
	7	2	32	2	
	11	3	37	10	
5355-00-898-6791	23	3	37	15	
5305-00-912-7281	2	2	5310-00-933-8120	9	14
5305-00-922-6286	9	11	10	18	
5340-00-927-7290	28	27	14	24	
5310-00-928-2690	2	13	19	9	
	2	28	36	6	
	5	2	5310-00-933-8121	10	2
	5	8	14	21	
	20	2	22	9	
24	11	5310-00-933-8778	9	5	
24	23	10	21		
32	33	5331-00-935-9226	10	12	
36	9	3040-00-937-8289	26	5	
5310-00-929-6395	2	9	5315-00-940-8033	32	16
	2	11	32	16	
	2	18	5305-00-940-9487	22	14
	2	20	5305-00-940-9488	14	1
	2	24	3040-00-947-3044	40	18
	9	27	5305-00-957-5897	22	8
	24	15	5305-00-959-0379	33	7

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX

STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5305-00-959-0382	16	2	5305-01-043-7710	28	23
5305-00-959-1082	2	23	1240-01-043-8197	22	6
	9	28	1240-01-043-8198	18	1
	24	14	6240-01-043-8209	5	4
	30	6		34	4
	32	43	1240-01-043-8210	22	4
	37	31	1240-01-043-8248	36	4
5310-00-974-6623	2	40	3040-01-043-8293	21	4
	15	2	3040-01-043-8405	16	10
	19	4B	5330-01-043-9288	14	29
5360-00-978-9584	3	23	5355-01-043-9292	34	10
	9	2	5340-01-043-9312	32	3
	14	8	5340-01-043-9313	10	6
	20	14	5315-01-043-9369	14	22
3120-00-983-7313	3	24	5340-01-043-9453	21	11
5305-00-988-5308	19	8	1240-01-043-9459	9	21
5315-00-988-7409	21	2		14	11
	27	1		20	10
5305-00-988-7601	12	7	1240-01-043-9460	33	15
5305-00-988-7602	24	1A	1240-01-043-9461	33	20
5305-00-988-7604	12	9	1240-01-043-9462	23	5
	24	1	1240-01-043-9463	28	29
5305-00-988-7838	12	10	1240-01-043-9464	28	21
5305-00-989-4609	19	5	1240-01-043-9465	24	7
3110-00-990-0475	35	5	5340-01-043-9476	30	18
5305-00-993-1612	10	8	5360-01-043-9541	30	17
5360-00-993-4647	21	10	1240-01-044-4556	30	12
5305-00-993-9175	10	17	1240-01-044-4557	29	8
	14	23	1240-01-044-4558	32	20
5305-00-995-4659	9	12	1240-01-044-4559	32	37
5331-01-007-8595	28	10	1240-01-044-4560	25	24
5360-01-037-6448	21	3	1240-01-044-4561	23	1
5340-01-043-2209	39	5	3020-01-044-4562	33	14
5340-01-043-4440	39	2	5330-01-044-4883	9	16
1240-01-043-4768	37	5		14	14
5305-01-043-7326	21	8		20	7
5340-01-043-7380	32	24	5340-01-044-4892	18	4
5315-01-043-7428	16	4	1290-01-044-6912	2	7
	22	11	1240-01-044-6915	23	4
5315-01-043-7434	39	7	1240-01-044-6917	28	18
1290-01-043-7476	2	39	1240-01-044-7056	32	30
5340-01-043-7489	38	2	5340-01-044-7069	32	31
1290-01-043-7490	1	4	5365-01-044-7070	29	4
1290-01-043-7491	1	6	1240-01-044-9849	16	7
1290-01-043-7493	3	15	1240-01-044-9851	37	24
1290-01-043-7494	3	20	1240-01-044-9852	8	1
1290-01-043-7499	6	2	1240-01-044-9854	10	25
5340-01-043-7501	21	9	1290-01-044-9856	3	26
5340-01-043-7511	6	21	1290-01-044-9857	1	3
1240-01-043-7547	36	2	1290-01-044-9858	2	5

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX

STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
1290-01-044-9859	6	9	1290-01-048-0193	1	7
5330-01-045-0718	32	10	5330-01-048-0563	10	23
3040-01-045-2059	10	11	5330-01-048-0564	10	27
3020-01-045-3970	6	5	9905-01-048-0646	13	7
5360-01-045-5461	25	12	5315-01-048-0650	29	7
9905-01-045-5843	20	1	3040-01-048-0767	14	18
5315-01-045-7806	6	13	1240-01-048-0777	37	25
5310-01-045-9594	3	16	1240-01-048-0778	37	12
5310-01-045-9595	3	21	1240-01-048-0779	37	19
5355-01-046-0732	9	18	5340-01-048-0791	25	20
	14	15	9905-01-048-2788	2	29
	20	4	5365-01-048-3048	17	4
1240-01-046-0895	17	5	5315-01-048-3354	36	20
1240-01-046-0896	28	12	3040-01-048-3741	6	16
5360-01-046-2460	35	4	5305-01-048-5367	10	15
5340-01-046-3649	2	38	3020-01-048-6275	6	11
1290-01-046-3687	1	8	5306-01-048-8749	16	1
5355-01-046-3761	32	23	5330-01-049-1290	9	8
1290-01-046-3777	1	3	5315-01-049-1390	26	1
1240-01-046-4258	24	9	6680-01-049-2865	33	9
5340-01-046-4277	34	6	5310-01-049-4071	10	24
5310-01-046-5392	13	2	9905-01-049-5129	24	13
5310-01-046-5395	14	4	6680-01-049-5151	6	6
5360-01-046-5865	6	20	3020-01-049-5234	6	10
5365-01-046-5869	9	15	5340-01-049-6190	32	26
	14	12	5330-01-049-8676	10	20
	20	8	5355-01-049-8955	34	2
1240-01-046-7104	32	29	5310-01-049-9174	19	1
1240-01-046-7105	34	5	5310-01-049-9175	9	17
1240-01-046-7106	15	3		14	13
5330-01-046-8020	10	9		20	6
5305-01-046-8323	25	1	5355-01-049-9238	37	2
9905-01-046-8337	36	11	5330-01-049-9865	19	11
5340-01-046-8343	32	17	5310-01-050-0478	37	4
3040-01-046-8372	10	14	5330-01-050-1549	3	13
1240-01-046-8377	29	9	3120-01-050-1574	9	20
5360-01-046-8830	28	26		14	17
5310-01-047-0433	3	12		20	9
5355-01-047-0490	3	11	5365-01-050-2177	28	24
3110-01-047-0624	21	1	5360-01-050-5307	39	8
5305-01-047-3997	37	7	3120-01-050-6190	9	3
5330-01-047-5724	28	4		14	9
5305-01-047-6149	12	6		20	15
5305-01-047-6150	12	3	5365-01-050-6765	9	1
1240-01-047-8183	14	28		14	7
6650-01-047-8283	17	10		20	13
6650-01-047-8287	25	21	6680-01-050-7647	6	4
3020-01-047-9114	6	7	6680-01-051-8404	33	3
3020-01-047-9116	6	14	9390-01-051-9545	9	9
6650-01-047-9214	29	10	6260-01-051-9606	29	3

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX

STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5340-01-051-9968	20	12	9905-01-451-1585	25	18
5330-01-052-0009	32	4	5340-01-464-3141	9	30
5340-01-052-0011	34	9		24	17
5365-01-052-1298	25	11		32	39
1240-01-052-1979	22	5		37	32
4820-01-053-0223	25	3	4010-01-464-3142	9	29
	28	28		24	16
	31	1		37	33
	36	18	5331-01-465-0909	24	6
5315-01-053-0237	9	13	5331-01-471-2403	30	2
5325-01-054-0133	9	7	6160-01-485-1914	9	26
5315-01-054-4904	19	7		24	18
5340-01-054-6588	34	13		37	29
5365-01-056-1804	21	13	5330-01-485-3480	9	25
6650-01-057-0054	37	22		24	19
5340-01-062-0274	40	2		37	28
5340-01-062-0275	40	1	9905-01-485-7527	24	13
5305-01-062-3346	10	22	9905-01-485-7528	24	13
4931-01-062-4255	40	3	1240-01-485-7530	30	20
1240-01-062-8264	23	2	5935-01-485-7531	24	21
1240-01-065-9826	33	19	6160-01-485-7533	2	25
1240-01-065-9829	33	17		32	41
9905-01-068-6443	2	29	5340-01-485-7534	32	17
9905-01-069-5632	29	2	5340-01-485-7535	2	22
5305-01-071-8747	32	27		32	40
5355-01-083-6241	25	9	1240-01-485-7536	30	19
6650-01-092-6476	23	1A	5330-01-485-8715	2	26
3040-01-093-8922	10	19		32	44
6680-01-100-0775	33	6	1240-01-486-0293	23	4
5305-01-116-7366	9	4	1240-01-486-0296	28	29
5331-01-118-2080	37	17	1240-01-486-1345	23	2
4931-01-128-5862	40	11	1240-01-486-2738	23	5
4931-01-132-0654	40	19	3040-01-493-4172	15	4
1240-01-134-7103	40	6	3040-01-494-7940	16	9
5310-01-140-2500	25	4	3130-01-497-3341	8	4
5120-01-151-8817	40	15	1240-01-498-9029	8	5
5120-01-151-8819	40	17	3020-01-509-4226	28	9
5120-01-151-8820	40	14	5365-01-517-2168	32	45
5305-01-206-5456	9	6B	1290-01-517-2169	1	7
1240-01-206-6341	37	8	1290-01-517-2170	1	8
4820-01-210-9568	2	30	9905-01-517-2172	2	29
4820-01-235-0223	2	34	9905-01-517-2173	2	29
	30	8	5340-01-517-6141	1	5
	32	7	5340-01-517-8450	12	15
	36	16	5365-01-517-8451	9	23
5340-01-244-9855	30	3	3020-01-517-8452	14	2
6650-01-264-2348	30	16	3040-01-517-8453	14	25
5315-01-336-2450	9	6A	3040-01-517-9270	10	3
5330-01-341-6762	3	3	5340-01-517-9271	12	11
5331-01-449-3292	28	25	3130-01-517-9273	8	4

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

STOCK NUMBER	NATIONAL STOCK NUMBER INDEX		STOCK NUMBER	FIG.	ITEM
	FIG.	ITEM			
5315-01-517-9274	9	6			
1240-01-517-9275	11	2A			
3110-01-518-3217	13	5			
3110-01-518-3219	13	3			
3120-01-518-3221	13	4			
3040-01-518-4504	21	12			
9905-01-518-4505	20	1			
1240-01-519-3052	37	25			
1240-01-519-3054	37	19			
5340-01-519-3055	37	26			
9905-01-519-3056	36	11			
6650-01-520-5989	37	13			
1240-01-521-0009	8	1			
9905-01-521-1615	13	7			
5340-01-521-2989	12	13			
5310-01-521-3097	12	12			
5305-01-521-9231	12	14			
9530-01-522-0697	33	13			
5340-01-522-0777	5	15			
5340-01-522-1643	5	13			
5340-01-523-2317	32	47			
5330-01-523-2319	28	6			
5330-01-523-2320	28	7			
5315-01-524-0124	24	5A			

END OF WORK PACKAGE

DIRECT SUPPORT AND GENERAL SUPPORT

QUADRANT, FIRE CONTROL: M17 (1290-01-037-3883);
QUADRANT, FIRE CONTROL: M17A1 (1290-01-515-8260);
QUADRANT, FIRE CONTROL: M18 (1290-01-037-7289);
QUADRANT, FIRE CONTROL: M18A1 (1290-01-515-8262);
MOUNT, TELESCOPE AND QUADRANT: M171 (1240-01-039-7273);
MOUNT, TELESCOPE AND QUADRANT: M171A1 (1240-01-515-8265);
MOUNT, TELESCOPE AND QUADRANT: M172 (1240-01-037-7290);
MOUNT, TELESCOPE AND QUADRANT: M172A1 (1240-01-517-2171);
TELESCOPE, PANORAMIC: M137 (1240-01-038-0531);
TELESCOPE, PANORAMIC: M137A2 (1240-01-483-6103);
TELESCOPE, PANORAMIC: M137A3 (1240-01-483-6100);
TELESCOPE, ELBOW: M138 (1240-01-038-0530); AND
TELESCOPE, ELBOW: M138A1 (1240-01-515-8264)

PART NUMBER INDEX

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
81343	AS29513-116		5331-00-248-3850	10	10
81343	AS29513-12			25	14
81343	AS29513-138		5331-00-252-6050	30	15
81343	AS29513-151		5331-00-935-9226	10	12
81343	AS29513-155		5331-00-529-3723	37	12A
				37	18
81343	AS3578-010		5331-00-580-2278	28	15
81343	AS3578-013		5331-00-558-2310	3	22
				25	8
81343	AS3578-015		5331-00-584-1222	32	21
81343	AS3578-016		5331-01-449-3292	28	25
81343	AS3578-017		5331-00-551-9573	2	36
81343	AS3578-118		5331-00-584-1229	10	13
81343	AS3578-130		5331-00-584-1582	24	3
				24	3
81343	AS3578-134		5331-01-465-0909	24	6
81343	AS3578-140		5331-01-471-2403	30	2
81343	AS3578-216		5331-00-531-3714	28	13
81343	AS3578-221		5331-00-550-6617	3	17
58536	FF B 171B		3110-00-156-7513	16	13
96906	MS124695		5325-00-597-3302	18	5
96906	MS124697		5325-00-291-3495	22	10
96906	MS124735		5325-00-290-4480	22	16
80205	MS15795-704		5310-00-550-5009	6	17
96906	MS16555-601		5315-00-817-0889	4	6
96906	MS16555-604		5315-00-806-7039	6	3
				7	7
				33	10
96906	MS16555-617		5315-00-682-1726	6	1
96906	MS16555-618		5315-00-702-9651	28	20
				33	1
96906	MS16555-620		5315-00-806-7040	32	22
80205	MS16555-622		5315-00-815-9366	24	5
80205	MS16555-625		5315-00-682-1727	3	5
96906	MS16555-626		5315-00-847-5677	26	2
80205	MS16555-627		5315-00-825-1207	28	3
80205	MS16555-628		5315-00-810-0505	9	19
				14	16
				20	5
				22	3
96906	MS16555-631		5315-00-834-0745	2	16
				3	10
96906	MS16555-634		5315-00-988-7409	21	2
				27	1
96906	MS16555-636		5315-00-176-6116	28	8
96906	MS16555-640		5315-00-056-9386	28	22
96906	MS16555-646		5315-00-682-1733	14	19
				15	5
				22	15
96906	MS16555-651		5315-00-543-3986	38	1
96906	MS16555-686		5315-01-048-3354	36	20

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
96906	MS16556-621		5315-00-082-4858	35	1
80205	MS16562-224		5315-00-841-4442	36	21
96906	MS16624-5015-1		5325-00-187-9033	39	4
96906	MS16633-4009		5325-00-543-3981	29	6
96906	MS16633-4015		5325-00-598-1840	6	12
80205	MS16995-1		5305-00-068-5409	34	3
80205	MS16995-10		5305-00-959-0379	33	7
80205	MS16995-17		5305-00-959-0382	16	2
80205	MS16995-18		5305-00-959-1082	2	23
				9	28
				24	14
				30	6
				32	43
				37	31
96906	MS16995-25		5305-00-988-7601	12	7
80205	MS16995-26		5305-00-988-7602	24	1A
80205	MS16995-28		5305-00-988-7604	12	9
				24	1
80205	MS16995-64		5305-00-988-7838	12	10
80205	MS16995-9		5305-00-068-5276	12	4
80205	MS18064-91		5305-01-206-5456	9	6B
96906	MS19060-1006		3110-00-990-0475	35	5
96906	MS19068-063		5310-00-450-5946	14	6
96906	MS19070-063		5310-00-186-1009	14	5
96906	MS21090-0412		5305-00-726-1241	37	20
96906	MS24585-1025		5360-01-037-6448	21	3
96906	MS24585-1067		5360-01-045-5461	25	12
96906	MS24585C75		5360-00-993-4647	21	10
96906	MS24673-11		5305-00-957-5897	22	8
80205	MS24673-16		5305-00-834-3388	19	4A
80205	MS24673-17		5305-00-834-3385	19	2
				19	4C
				21	5
80205	MS24673-18		5305-00-235-3528	19	4D
80205	MS24673-3		5305-00-988-5308	19	8
80205	MS24673-7		5305-00-682-7753	19	10
96906	MS24674-14		5305-00-995-4659	9	12
96906	MS24674-15		5305-00-067-9917	9	24
96906	MS24674-16		5305-00-993-9175	10	17
				14	23
96906	MS24674-25		5305-00-685-3492	14	20
96906	MS24674-3		5305-00-848-9282	14	26
				22	1
96906	MS24674-35		5305-00-225-9891	15	1
96906	MS24674-7		5305-00-067-9914	10	26
				17	7
96906	MS24674-8		5305-00-993-1612	10	8
96906	MS24674-9		5305-00-989-4609	19	5
80205	MS24692-225		5315-00-078-8711	16	6
80205	MS24692-339		5315-00-188-0240	9	6
96906	MS27955-4			19	3

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
81343	MS28775-012		5331-00-584-0265	33	16
81343	MS28775-130		5331-01-007-8595	28	10
96906	MS29513-044			3	8
81343	MS29513-12		5331-00-248-3836	3	14
96906	MS35275-225		5305-00-940-9487	22	14
96906	MS35275-226		5305-00-940-9488	14	1
80205	MS35275-228		5305-00-922-6286	9	11
96906	MS35276-247		5305-00-912-7281	2	2
96906	MS35307-333		5306-00-817-4989	2	41
80205	MS35308-333		5306-00-638-7719	2	41
96906	MS35333-69		5310-00-543-4652	11	7
				13	8
80205	MS35333-71		5310-00-616-3555	17	9
80205	MS35338-134		5310-00-928-2690	2	13
				2	28
				5	2
				5	8
				20	2
				24	11
				24	23
				32	33
				36	9
80205	MS35338-135		5310-00-933-8118	3	19
				6	19
				12	5
				32	19
				33	4
				34	7
80205	MS35338-136		5310-00-929-6395	2	9
				2	11
				2	18
				2	20
				2	24
				9	27
				24	15
				28	2
				30	4
				32	12
				32	15
				32	15
				32	36
				32	42
				33	21
				37	30
80205	MS35338-137		5310-00-933-8119	2	4
				3	2
				9	10
				10	5
				10	7
				12	8
				14	27

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
80205	MS35338-137		5310-00-933-8119	16	3
				17	6
				19	6
				22	2
				24	2
				32	2
				37	10
				37	15
80205	MS35338-138		5310-00-933-8120	9	14
				10	18
				14	24
				19	9
96906	MS35338-139		5310-00-933-8121	36	6
				10	2
				14	21
80205	MS35338-140		5310-00-974-6623	22	9
				2	40
				15	2
80205	MS35338-143		5310-00-933-8778	19	4B
				9	5
96906	MS35672-16		5315-00-722-6591	10	21
				36	5
80205	MS35672-18		5315-00-825-3748	37	11
				37	16
80205	MS51021-1		5305-00-843-2841	25	2
80205	MS51021-10		5305-00-655-9246	37	1
				21	7
				28	23
				37	7
				25	15
				25	10
				36	19
				37	23
				16	8
				11	5
80205	MS51021-23		5305-00-272-4123	29	5
				30	13
96906	MS51021-9		5305-00-800-7261	30	14
96906	MS51023-10		5305-00-820-5433	9	22
				14	10
				20	11
				10	16
				12	16
80205	MS51023-48		5305-00-281-3120	2	37
				2	1
80205	MS51023-49		5305-00-272-3533	37	3
80205	MS51029-48		5305-00-865-9516	9	4
80205	MS51031-35		5305-00-724-3454	10	22
80205	MS51031-37		5305-00-724-3478	2	32
96906	MS51038-15		5305-00-081-2651	30	10
96906	MS51099-115		5305-01-116-7366	32	6
96906	MS51100-120		5305-01-062-3346		
96906	MS51377-2		2640-00-060-3543		

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
96906	MS51377-2		2640-00-060-3543	36	14
96906	MS51607-1		4820-00-114-1096	2	31
				30	11
				32	5
				36	13
80205	MS51923-159		5315-00-623-1761	6	8
80205	MS51923-190		5315-00-616-4736	39	6
96906	MS51957-1		5305-00-054-5635	2	27
				24	12
				32	32
96906	MS51957-12		5305-00-054-5646	34	8
96906	MS51957-13		5305-00-054-5647	3	25
				32	18
				33	18
96906	MS51957-15		5305-00-054-5649	6	18
				33	5
96906	MS51957-2		5305-00-054-5636	2	12
				5	1
				5	9
				11	8
				13	9
				20	3
				24	22
				36	10
96906	MS51957-26		5305-00-054-6650	2	21
				32	38
96906	MS51957-27		5305-00-054-6651	2	6
				17	8
				32	13
				32	14
				32	14
				37	9
96906	MS51957-28		5305-00-054-6652	2	35
				3	18
				28	19
				32	35
96906	MS51957-29		5305-00-054-6653	2	8
				2	10
				30	5
				33	12
96906	MS51957-30		5305-00-054-6654	2	19
				28	1
				37	21
96906	MS51957-31		5305-00-054-6655	37	14
96906	MS51957-43		5305-00-054-6668	3	6
96906	MS51957-45		5305-00-054-6670	2	3
				24	4
				32	1
96906	MS51957-63		5305-00-050-9229	36	7
96906	MS51958-27		5305-00-057-0523	36	1
96906	MS51958-45		5305-00-701-5061	3	1

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
96906	MS51959-12		5305-00-777-6039	32	28
96906	MS51959-13		5305-00-770-2533	13	1
				25	19
				32	46
96906	MS51959-14		5305-00-763-7822	25	25
96906	MS51959-2		5305-00-764-2966	34	11
96906	MS51959-44		5305-00-764-0066	5	14
				32	48
				37	27
80205	MS51959-45		5305-00-764-0068	9	24A
				28	30
80205	MS51959-47		5305-00-764-0071	24	20
96906	MS51959-65		5305-00-701-5078	24	8
96906	MS51960-6		5305-00-829-0105	39	1
96906	MS51963-1		5305-00-717-6955	7	5
96906	MS9021-046		5331-00-149-8859	2	17
96906	MS90402-1		5305-01-071-8747	32	27
96906	MS90708-4150		5325-01-054-0133	9	7
81343	MS9390-290		5315-00-940-8033	32	16
				32	16
81349	M21143/1-50		5315-01-336-2450	9	6A
81343	M83461/1-332		5331-01-118-2080	37	17
80205	NAS1352C06H8		5305-00-848-9282	10	4
11934	SLB10377		5330-01-485-3480	9	25
19200	10512992		3040-00-947-3044	40	18
19200	10516567		5340-00-464-4792	2	33
				30	9
				32	8
				36	15
19200	10549069			21	6
19200	10549070		5365-01-056-1804	21	13
19200	10549259		5340-01-043-2209	39	5
19200	10549260			38	3
19200	10549262			39	3
19200	10549263		5360-01-050-5307	39	8
19200	10549264		5315-01-043-7434	39	7
19200	10549265		5340-01-043-4440	39	2
19200	10549268		1240-01-044-9851	37	24
19200	10549270		9905-01-046-8337	36	11
19200	10549272		1240-01-043-8248	36	4
19200	10549273-3		5340-01-048-0791	25	20
19200	10549277		5340-01-043-7489	38	2
19200	10549278		5340-01-043-9453	21	11
19200	10549286		5340-01-043-7501	21	9
19200	10549868		1240-00-084-0280	36	17
19200	10553898		4931-01-128-5862	40	11
19200	10553927		5310-00-150-3792	28	16
19200	10553928		5310-00-150-3708	28	17
19200	10554514		5340-01-051-9968	20	12
19200	10554685		1240-01-043-8198	18	1
19200	10554692		5305-01-043-7326	21	8

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
19200	10554773		1240-01-046-4258	24	9
19200	10554774			25	5
19200	10554777		5340-01-046-8343	32	17
19200	10554778		6650-01-092-6476	23	1A
19200	10554778-1			27	2
19200	10554781		1240-01-044-6917	28	18
19200	10554811		5340-01-044-4892	18	4
19200	10554813			19	4
19200	10554815		1240-01-043-8197	22	6
19200	10554818		1240-01-043-8210	22	4
19200	10554820		5310-01-049-9174	19	1
19200	10554821		1240-01-052-1979	22	5
19200	10554825		1290-01-043-7476	2	39
19200	10554826			4	2
19200	10554827		1290-01-048-0193	1	7
19200	10554828		5340-01-046-3649	2	38
19200	10554829		9905-01-045-5843	20	1
19200	10554936		6650-01-057-0054	37	22
19200	10555110		5365-01-050-2177	28	24
19200	10555147			35	2
19200	10555155		1240-01-044-7056	32	30
19200	10555178		5360-01-046-2460	35	4
19200	10555186		1240-01-046-7104	32	29
19200	10555619		4940-00-191-9215	40	4
19200	10555620		1240-01-134-7103	40	6
19200	10556183		5305-01-046-8323	25	1
19200	10556184		9905-01-069-5632	29	2
19200	10556186		4820-01-053-0223	25	3
				28	28
				31	1
				36	18
19200	10556189		1240-01-065-9826	33	19
19200	10556190		5340-01-043-7380	32	24
19200	10556191		1290-01-044-6912	2	7
19200	10556192		1290-01-044-9858	2	5
19200	10558253-11		5340-01-062-0275	40	1
19200	11727757		3110-01-047-0624	21	1
19200	11727758		3040-01-043-8293	21	4
19200	11727801			8	2
19200	11727802		3130-01-497-3341	8	4
19200	11727803		3040-01-493-4172	15	4
19200	11727804			8	3
19200	11727806			13	6
19200	11727808		1240-01-044-9849	16	7
19200	11727812			17	1
19200	11727814		5340-01-043-9313	10	6
19200	11727816		3040-01-494-7940	16	9
19200	11727817			14	3
19200	11727818			12	2
19200	11727819			16	5
19200	11727821		1240-01-046-7106	15	3

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
19200	11727822		1240-01-044-9852	8	1
19200	11727824		1240-01-498-9029	8	5
19200	11727833		5330-01-046-8020	10	9
19200	11727834		3040-01-093-8922	10	19
19200	11727837		5365-01-048-3048	17	4
19200	11727838		5310-01-049-4071	10	24
19200	11727839		3040-01-045-2059	10	11
19200	11727842-1		5305-01-047-6149	12	6
19200	11727842-2		5305-01-047-6150	12	3
19200	11727844		9390-01-051-9545	9	9
19200	11727850		1240-01-047-8183	14	28
19200	11727851		5310-01-046-5392	13	2
19200	11727853		1240-01-046-0895	17	5
19200	11727854		1240-01-044-9854	10	25
19200	11727857		3040-01-046-8372	10	14
19200	11727863		9905-01-048-0646	13	7
19200	11727864		3110-00-165-5922	17	3
19200	11727865		6650-01-047-8283	17	10
19200	11727866		5305-01-048-5367	10	15
19200	11727867		3040-01-048-0767	14	18
19200	11727868		5315-01-053-0237	9	13
19200	11727870		5306-01-048-8749	16	1
19200	11727871-1		5330-01-049-1290	9	8
19200	11727871-2		5330-01-048-0563	10	23
19200	11727871-3		5330-01-048-0564	10	27
19200	11727872-1		5330-01-049-8676	10	20
19200	11727876-1		5305-00-146-5701	10	1
19200	11727880		3120-01-050-1574	9	20
				14	17
				20	9
19200	11727882		5365-01-046-5869	9	15
				14	12
				20	8
19200	11727883		5330-01-044-4883	9	16
				14	14
				20	7
19200	11727884		5310-01-049-9175	9	17
				14	13
				20	6
19200	11727885		5355-01-046-0732	9	18
				14	15
				20	4
19200	11727886		3120-01-050-6190	9	3
				14	9
				20	15
19200	11727887		5365-01-050-6765	9	1
				14	7
				20	13
19200	11727888		5315-00-492-1962	12	1
19200	11727890		5315-01-043-7428	16	4
				22	11

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
19200	11727892		5315-01-043-9369	14	22
19200	11727895		5330-01-043-9288	14	29
19200	11727897		5310-01-046-5395	14	4
19200	11729512		1290-00-257-2769	4	3
				7	3
				11	2
19200	11729515		6260-01-051-9606	29	3
19200	11729516		1240-01-048-0779	37	19
19200	11729528			5	5
19200	11729529		1290-01-043-7490	1	4
19200	11729532			1	5
19200	11729535			3	4
19200	11729536			3	4
19200	11729538			7	4
19200	11729540		1290-01-043-7493	3	15
19200	11729542			1	2
19200	11729543		1290-01-043-7491	1	6
19200	11729544		1290-01-044-9859	6	9
19200	11729546		1290-01-044-9857	1	3
19200	11729548		1290-01-046-3777	1	3
19200	11729551		1290-01-046-3687	1	8
19200	11729552			3	9
19200	11729553			3	7
19200	11729554		3020-01-047-9114	6	7
19200	11729555		3020-01-049-5234	6	10
19200	11729556			5	7
19200	11729557			5	10
19200	11729558		1290-01-043-7494	3	20
19200	11729559		6240-01-043-8209	5	4
				34	4
19200	11729560			6	15
19200	11729561		1290-01-043-7499	6	2
19200	11729570			5	3
19200	11729572		5340-01-043-7511	6	21
19200	11729574		3020-01-047-9116	6	14
19200	11729575		3020-01-048-6275	6	11
19200	11729576		3020-01-045-3970	6	5
19200	11729577		3040-01-048-3741	6	16
19200	11729578			1	1
19200	11729580		5355-01-047-0490	3	11
19200	11729581		9905-00-257-2751	2	14
				11	6
19200	11729582		9905-00-257-2750	2	15
				32	34
19200	11729586		5310-01-045-9594	3	16
19200	11729587		5310-01-045-9595	3	21
19200	11729588		9905-01-048-2788	2	29
19200	11729589		5315-01-045-7806	6	13
19200	11729591		6680-01-049-5151	6	6
19200	11729593		9905-01-068-6443	2	29
19200	11729598		5360-01-046-5865	6	20

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
19200	11731011		7690-00-257-2746	5	12
				17	2
				32	9
				36	8
19200	11732205		5315-01-054-4904	19	7
19200	11732206			22	12
19200	11732207		5330-01-049-9865	19	11
19200	11738294		1240-00-191-1379	40	22
19200	11741102-1		1240-01-044-6915	23	4
19200	11741103		3020-01-044-4562	33	14
19200	11741104			34	1
19200	11741105		1240-01-044-4561	23	1
19200	11741106			25	16
19200	11741107			28	11
19200	11741108			29	1
19200	11741110			30	1
19200	11741111			33	8
19200	11741118-1		6680-01-051-8404	33	3
19200	11741118-2		6680-01-100-0775	33	6
19200	11741119		6680-01-049-2865	33	9
19200	11741120			26	7
19200	11741121		6650-01-047-8287	25	21
19200	11741123		5330-01-047-5724	28	4
19200	11741126		1240-01-044-4560	25	24
19200	11741133			31	2
19200	11741135			30	7
19200	11741137		6650-01-264-2348	30	16
19200	11741146		5355-01-046-3761	32	23
19200	11741147		1240-01-065-9829	33	17
19200	11741154		5340-01-044-7069	32	31
19200	11741155		5340-01-049-6190	32	26
19200	11741156			35	3
19200	11741157		5340-01-052-0011	34	9
19200	11741158		5340-01-046-4277	34	6
19200	11741159		5340-01-054-6588	34	13
19200	11741160		5360-01-046-8830	28	26
19200	11741161			32	11
19200	11741163		1240-01-044-4559	32	37
19200	11741164		1240-01-044-4558	32	20
19200	11741170		1240-01-046-7105	34	5
19200	11741171		9905-01-049-5129	24	13
19200	11741172		5330-01-045-0718	32	10
19200	11741173			26	4
19200	11741174			25	17
19200	11741178		1240-01-044-4557	29	8
19200	11741179		5340-01-244-9855	30	3
19200	11741180		6650-01-047-9214	29	10
19200	11741182		1240-01-043-9465	24	7
19200	11741186		1240-01-046-0896	28	12
19200	11741188			29	11
19200	11741191		1240-01-043-9464	28	21

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
19200	11741194		9905-00-257-2756	24	10
				36	12
19200	11741195		5355-01-049-8955	34	2
19200	11741196		1240-01-044-4556	30	12
19200	11741197		5340-01-043-9476	30	18
19200	11741198		5360-01-043-9541	30	17
19200	11741200		1240-01-043-9463	28	29
19200	11741201		1240-01-043-9462	23	5
19200	11741202		1240-01-062-8264	23	2
19200	11741203		3020-01-509-4226	28	9
19200	11741207		5315-01-048-0650	29	7
19200	11741208		1240-01-046-8377	29	9
19200	11741209		5330-01-052-0009	32	4
19200	11741211			34	12
19200	11741223		1240-01-043-9461	33	20
19200	11741224		1240-01-043-9460	33	15
19200	11741228			33	11
19200	11741229			33	2
19200	11741230		5340-01-043-9312	32	3
19200	11741233			25	26
19200	11741234		9905-01-451-1585	25	18
19200	11741235			25	13
19200	11741236		5365-01-052-1298	25	11
19200	11741240		5365-01-044-7070	29	4
19200	11741248		5355-01-043-9292	34	10
19200	11741627		1240-01-048-0778	37	12
19200	11741629		1240-01-048-0777	37	25
19200	11741635		5310-01-047-0433	3	12
19200	11741636		5330-01-050-1549	3	13
19200	11741652			28	14
19200	11746330		1290-01-044-9856	3	26
19200	11747955		5120-01-525-1891	40	16
19200	11748003		5310-01-050-0478	37	4
19200	11748009		5355-01-049-9238	37	2
19200	11748010		1240-01-043-4768	37	5
19200	11748011		1240-01-043-7547	36	2
19200	11748021		6680-01-050-7647	6	4
19200	11785502		5120-01-151-8817	40	15
19200	11785506		5120-01-151-8820	40	14
19200	11785507		5120-01-151-8819	40	17
19200	12008990		5340-01-062-0274	40	2
19200	12961437		1240-01-486-0296	28	29
19200	12961438		1240-01-486-1345	23	2
19200	12961439		5340-01-485-7534	32	17
19200	12961440			34	1
19200	12961441			30	7
19200	12984661		5340-01-464-3141	9	30
				24	17
				32	39
				37	32
19200	12984664		4010-01-464-3142	9	29

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
19200	12984664		4010-01-464-3142	24	16
				37	33
19200	12984693		6160-01-485-1914	9	26
				24	18
				37	29
19200	12984698		5330-01-485-3480	24	19
				37	28
19200	12984716		1240-01-485-7536	30	19
19200	12984717		1240-01-485-7530	30	20
19200	12984719		5935-01-485-7531	24	21
19200	12984723		5330-01-485-8715	2	26
				32	44
19200	12984725		6160-01-485-7533	2	25
				32	41
19200	12984726		5340-01-523-2317	32	47
19200	12984733		1240-01-486-2738	23	5
19200	12984734		1240-01-486-0293	23	4
19200	12984738		9905-01-485-7528	24	13
19200	12984744		5365-01-517-8451	9	23
19200	12984745		1240-01-517-9275	11	2A
19200	12984751		5340-01-485-7535	2	22
				32	40
19200	12984757		5340-01-522-1643	5	13
19200	12984776		9905-01-485-7527	24	13
19200	12984783		5340-01-519-3055	37	26
19200	12984785		1240-01-519-3054	37	19
19200	12984828		5340-01-522-0777	5	15
19200	12984837		1240-01-519-3052	37	25
19200	12999464		9530-01-522-0697	33	13
19200	12999465		5315-01-517-9274	9	6
19200	13005033		6650-01-520-5989	37	13
19200	13005037		1240-01-521-0009	8	1
19200	13005038			12	2
19200	13005039		5340-01-517-8450	12	15
19200	13005040		5340-01-517-9271	12	11
19200	13005041		5315-01-524-0124	24	5A
19200	13005043		5340-01-521-2989	12	13
19200	13005044		5305-01-521-9231	12	14
19200	13005045		5310-01-521-3097	12	12
19200	13005052		5365-01-517-2168	32	45
19200	13005070		3040-01-517-9270	10	3
19200	13005077		5330-01-523-2320	28	7
19200	13005078		5330-01-523-2319	28	6
19200	13005079		5340-01-517-6141	1	5
19200	13005080		1290-01-517-2169	1	7
19200	13005081		1290-01-517-2170	1	8
19200	13005082		3130-01-517-9273	8	4
19200	13005083		3020-01-517-8452	14	2
19200	13005084		3040-01-517-8453	14	25
19200	13005085		1240-01-043-9459	9	21
				14	11

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
19200	13005085		1240-01-043-9459	20	10
19200	13005086		3040-01-518-4504	21	12
19200	13005087			17	1
19200	13005088		3040-01-043-8405	16	10
19200	13005090			18	3
19200	13005091			18	2
19200	13005092			22	13
19200	13005093			22	7
19200	13005095		9905-01-518-4505	20	1
19200	13005098		3110-01-518-3217	13	5
19200	13005099		3110-01-518-3219	13	3
19200	13005100		3120-01-518-3221	13	4
19200	13005105		9905-01-521-1615	13	7
19200	13005106		9905-01-519-3056	36	11
19200	13005107		9905-01-517-2173	2	29
19200	13005108		9905-01-517-2172	2	29
08871	5033-012		5210-00-221-1842	40	21
19200	5049914		6650-00-504-9914	31	5
19200	5049915		6650-00-504-9915	31	3
19200	6523553		6650-00-652-3553	40	8
11710	719-20MRP		6635-00-790-0733	40	9
19200	7197156		1290-00-891-9999	40	10
19200	7197944		4931-00-508-5434	40	20
19200	7573291		1240-00-757-3291	40	23
19200	7597626		5340-00-759-7626	4	1
				7	6
				11	1
19200	7680631		1240-00-536-5557	40	13
19200	7686087		5210-00-546-6362	40	12
19200	7691596		4931-00-769-1596	40	7
19200	8200055		4820-01-235-0223	2	34
				30	8
				32	7
				36	16
19200	8202177		5365-00-896-2251	4	4
				7	2
				11	3
19200	8202181		5365-00-692-1492	4	5
				7	1
				11	4
19200	8202183		1290-00-692-1493	4	3
				7	3
				11	2B
19200	8213899		4931-00-801-6861	40	5
19200	8215750		3120-00-983-7313	3	24
19200	8262098		5340-00-764-1669	26	8
19200	8262100		5360-00-893-6095	26	6
19200	8587348		5355-00-898-6791	23	3
19200	8587432		5340-00-927-7290	28	27
19200	8587448-3		5340-00-171-0757	36	3
19200	8587557		5360-00-978-9584	3	23

SECTION IV

TM9-1240-375-34&P

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
19200	8587557		5360-00-978-9584	9	2
				14	8
				20	14
				28	5
19200	8615998		5331-00-851-1020	16	12
19200	8626125		5310-00-796-9592	16	14
19200	8626126		5365-00-065-5319	16	11
19200	8626152		5310-00-089-5966	25	9
19200	8626195		5355-01-083-6241	25	4
19200	8626196		5310-01-140-2500	25	7
19200	8626199			25	6
19200	8626201			26	1
19200	8626226		5315-01-049-1390	26	3
19200	8626227		5360-00-933-6573	25	23
19200	8626228		5330-00-069-9361	31	4
19200	8626233			31	6
19200	8626258		5365-00-177-3931	25	22
19200	8626291		1240-00-069-9363	26	5
19200	8626297		3040-00-937-8289	5	11
19200	8626399		6650-00-066-4998	5	6
19200	8626400		6650-00-066-4999	32	25
19200	8626451			37	6
19200	9327721		4931-01-062-4255	40	3
19200	9357947		4931-01-132-0654	40	19
19200	9360120		4820-01-210-9568	2	30
19200	9360585		5330-01-341-6762	3	3
19200	9386960		1240-01-206-6341	37	8

END OF WORK PACKAGE

DIRECT SUPPORT AND GENERAL SUPPORT

EXPENDABLE AND DURABLE ITEMS LIST

INTRODUCTION

Scope

This work package lists expendable and durable items that you will need to operate and maintain the M198/M777 fire control equipment. This list is for informational purposes only and is not authority to requisition the listed items. These items are authorized to you by CTA 50-970, Expendable/Durable Items (Except Medical, Class V, Repair Parts, and Heraldic Items), or CTA 8-100, Army Medical Department Expendable/Durable Items.

Explanation of Columns in the Expendable/Durable Items List

Column (1) - Item Number. This number is assigned to the entry in the list and is referenced in the narrative instructions to identify the item (e.g., "Apply sealing compound (item 13, WP 0152 00).").

Column (2) - Level. This column identifies the lowest level of maintenance that requires the listed item (O = Unit, F = Direct Support, H = General Support).

Column (3) - National Stock Number (NSN). This is the NSN assigned to the item which you can use to requisition it.

Column (4) - Item Name, Description, Commercial and Government Entity Code (CAGEC), and Part Number (P/N). This column provides the other information you need to identify the item.

Column (5) - Unit of Measure (U/M). This code shows the physical measurement or count of an item, such as gallon, dozen, gross, etc.

EXPENDABLE AND DURABLE ITEMS LIST

Table 1. Expendable and Durable Items List.

(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) ITEM NAME, DESCRIPTION, CAGEC, AND PART NUMBER	(5) U/M
1	F	6810-00-184-4796	ACETONE, TECHNICAL (81346) ASTM 0329 5 gal (18.927 l) can, liquid	CN
2	O	8040-00-851-0211	ADHESIVE: 732 Black (81349) MIL-A-46106 5 oz (142 g) kit	KT
3	F	6810-00-205-6790	ALCOHOL, DENATURED (OMU53) 27 CFR 20.113	BT

EXPENDABLE AND DURABLE ITEMS LIST - Continued

Table 1. Expendable and Durable Items List - Continued.

(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) ITEM NAME, DESCRIPTION, CAGEC, AND PART NUMBER	(5) U/M
4	H		ADHESIVE, EPOXY Loctite Hysol E-120 HP	QT
5	F	8105-00-269-4662	BAG, PLASTIC: waterproof and greaseproof (81349) MIL-B-117 20x25, std pkg 25	PG
6	O	8115-00-190-5020	BOX, SHIPPING (81346) ASTM-D 1974	BD
7	O	6135-01-456-2924	BATTERY, "C" SIZE: lithium (standard) (4J947) TL-2200	EA
8	O	6135-01-493-2736	BATTERY, "C" SIZE: lithium (high capacity) (4J947) TL-5920/S	EA
9	F	5350-00-268-3116	CLOTH, ABRASIVE: crocus (80204) ANSI B74.18 2 in. wide x 50 yd (45.72 m)	RO
10	F	6850-01-377-1809	COMPOUND, CLEANING (58536) A-A-59601	GL
11	F	6850-00-227-1887	COMPOUND, CLEANING: optical lens (58536) AA59199-I 1 qt (0.95 l)	QT
12	F	6850-00-597-9765	COMPOUND, CLEANING, SOLVENT (80063) 6G236-6 1 gal (3.79 l) can	GL
13	F	8030-00-837-9935	COMPOUND, SEALING: black, semi-solid (58536) A-A-59293 1 pt (0.473 l) base compound with catalyst	KT
14	O	8030-00-081-2329	COMPOUND, SEALING: locking and retaining (81349) MIL-S-22473 0.053 qt (55cc)	BT
15	F	9150-00-269-8255	GREASE, AIRCRAFT: corrosion-resistant grease (81343) AMS-G-4343 1.75 lb (0.79 kg) can	CN

Table 1. Expendable and Durable Items List - Continued.

(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) ITEM NAME, DESCRIPTION, CAGEC, AND PART NUMBER	(5) U/M
16	F	9150-00-985-7246	GREASE, AIRCRAFT: grease, aircraft instrument, corrosion and water-resistant (81349) MIL-PRF-23827 TYPE I 1.75 lb (0.79 kg) can	CN
17	F	6640-00-663-0832	PAPER, LENS: tissue sheet, type 1 (81348) NNN-P-40 50 sheets per pkg	BK
18	F	7920-00-205-1711	RAG, WIPING (80244) 7920-00-205-7511 50 lb (22.68 kg) package	BE
19	F	8520-00-228-0598	SOAP: liquid (81348) P-S-264 6 gal (22.71 l)	CN
20	F	7510-00-266-6707	TAPE, PRESSURE SENSITIVE ADHESIVE (81346) ASTM D-6123 3 in. wide x 60 yd (54.86 m)	RO
21	H	9505-00-293-4208	WIRE, NONELECTRICAL: annealed corrosion-resistant steel, 0.032-in. (0.085 cm) dia. (80205) MS20995C32 1 lb (0.45 kg)	LB
22	H	9505-00-076-8640	WIRE, NONELECTRICAL: 0.041-in. (0.104 cm) dia. (80205) MS20995C41 1 lb (0.45 kg)	LB

END OF WORK PACKAGE

INDEX

<u>Subject</u>	<u>WP Sequence No. - Page No.</u>
A	
Abbreviation/Acronym	0001 00-4
C	
Corrosion Prevention and Control (CPC)	0001 00-2
D	
Destruction of Army Materiel to Prevent Enemy Use	0001 00-2
E	
Equipment Characteristics, Capabilities, and Features	0002 00-1
Equipment Data	0002 00-13
Expendable and Durable Items List	0152 00-1
F	
Field Manuals	0108 00-1
Forms	0108 00-1
H	
How To Use This Manual	viii
I	
Introduction to Repair Parts and Special Tools List (RPSTL)	0109 00-1
L	
List of Abbreviations/Acronyms	0001 00-4
List of Effective Pages/Work Packages	A
Location and Description of Major Components	0002 00-3
M	
Maintenance Forms, Records, and Reports	0001 00-1
Malfunction/Symptom Index - Direct Support for M17/M17A1/M18/M18A1	
Fire Control Quadrant	0004 00-1
Malfunction/Symptom Index - General Support for M17/M17A1/M18/M18A1	
Fire Control Quadrant	0008 00-1
Malfunction/Symptom Index - Direct Support for M137/M137A2/M137A3	
Panoramic Telescope	0029 00-1
Malfunction/Symptom Index - General Support for M137/M137A2/M137A3	
Panoramic Telescope	0037 00-1

INDEX - Continued

<u>Subject</u>	<u>WP Sequence No. - Page No.</u>
M - Continued	
Malfunction/Symptom Index - Direct Support for M138/M38A1	
Elbow Telescope	0041 00-1
Malfunction/Symptom Index - Direct Support for M171/M171A1 Telescope and Quadrant Mount	0014 00-1
Malfunction/Symptom Index - General Support for M171/M171A1 Telescope and Quadrant Mount	0018 00-1
Malfunction/Symptom Index - Direct Support for M172/M172A1 Telescope and Quadrant Mount	0023 00-1
Malfunction/Symptom Index - General Support for M172/M172A1 Telescope and Quadrant Mount	0026 00-1
Miscellaneous Publications	0108 00-1
Model Numbers and Equipment Names	0001 00-1
 M17/M17A1 Fire Control Quadrant - Direct Support Maintenance	
Fire Control Level Assembly	
Adjustment	0048 00-3
Assembly	0048 00-2
Disassembly	0048 00-2
Repair or Replacement	0048 00-2
 M17/M17A1/M18/M18A1 Fire Control Quadrant - Direct Support Maintenance	
Cover Assembly	
Troubleshooting	0007 00-1
 M17/M17A1/M18/M18A1 Fire Control Quadrant - General Support Maintenance	
Correction Knob Assembly	
Troubleshooting	0011 00-1
Counter Assembly	
Troubleshooting	0012 00-1
Cover Assembly	
Troubleshooting	0010 00-1
Worm Shaft Assembly	
Troubleshooting	0013 00-1
 M17/M18 and M17A1/M18A1 Fire Control Quadrant - General Support Final	
Inspection Instructions	0057 00-1
 M17/M18 and M17A1/M18A1 Fire Control Quadrant - General Support Maintenance	
Counter Assembly	
Assembly	0054 00-6
Cleaning	0054 00-5
Disassembly	0054 00-3
Installation	0054 00-11
Removal	0054 00-1
Repair or Replacement	0054 00-6

INDEX - Continued

Subject WP Sequence No. - Page No.

M - Continued

M17/M18 and M17A1/M18A1 Fire Control Quadrant - General Support Maintenance (Continued)

Worm Shaft Assembly

Adjustment	0055 00-10
Cleaning	0055 00-5
Installation	0055 00-5
Removal	0055 00-2
Repair or Replacement	0055 00-5

M17/M18 Fire Control Quadrant - Direct Support Maintenance

Fire Control Level Assembly

Troubleshooting	0005 00-1
-----------------------	-----------

M17/M18 Fire Control Quadrant

Assembly	0046 00-5
Cleaning	0046 00-4
Disassembly	0046 00-1
Repair or Replacement	0046 00-4

M17/M18 Fire Control Quadrant - General Support Maintenance

Cover Assembly

Assembly	0052 00-3
Disassembly	0052 00-2
Installation	0052 00-4
Removal	0052 00-2
Repair or Replacement	0052 00-3

Fire Control Level Assembly (Cross Level Vial Assembly) (M18/M18A1)

Adjustment	0056 00-5
Assembly	0056 00-3
Disassembly	0056 00-2
Installation	0056 00-4
Removal	0056 00-2
Repair or Replacement	0056 00-3

Fire Control Level Assembly (Elevation Level Vial Assembly)

Adjustment	0051 00-7
Assembly	0051 00-4
Disassembly	0051 00-3
Installation	0051 00-5
Removal	0051 00-1
Repair or Replacement	0051 00-4
Troubleshooting	0009 00-1

M17/M18 Fire Control Quadrant

Assembly	0049 00-9
Cleaning	0049 00-9
Disassembly	0049 00-2
Repair or Replacement	0049 00-9

INDEX - Continued

Subject WP Sequence No. - Page No.

M - Continued

M17A1/M18A1 Fire Control Quadrant - Direct Support Maintenance	
M17A1/M18A1 Fire Control Quadrant	
Assembly	0047 00-6
Cleaning	0047 00-5
Disassembly	0047 00-1
Repair or Replacement	0047 00-5
M17A1/M18A1 Fire Control Quadrant - General Support Maintenance	
Cover Assembly	
Assembly	0053 00-4
Disassembly	0053 00-3
Installation	0053 00-5
Removal	0053 00-1
Repair or Replacement	0053 00-3
M17A1/M18A1 Fire Control Quadrant	
Assembly	0050 00-9
Cleaning	0050 00-9
Disassembly	0050 00-2
Repair or Replacement	0050 00-9
M137 Panoramic Telescope - Direct Support Maintenance	
Counter Box Assembly	
Troubleshooting	0034 00-1
M137/M137A2/M137A3 Panoramic Telescope - Direct Support Maintenance	
Body Assembly	
Assembly	0087 00-2
Cleaning	0087 00-2
Disassembly	0087 00-1
Repair or Replacement	0087 00-2
Counter Box Assembly	
Assembly	0090 00-6
Cleaning	0090 00-5
Disassembly	0090 00-1
Repair or Replacement	0090 00-5
Cover Assembly (Azimuth Counter)	
Assembly	0091 00-3
Cleaning	0091 00-2
Disassembly	0091 00-2
Repair or Replacement	0091 00-2
Cover Assembly (Head)	
Assembly	0086 00-3
Cleaning	0086 00-2
Disassembly	0086 00-1
Repair or Replacement	0086 00-2
Troubleshooting	0031 00-1

INDEX - Continued

Subject WP Sequence No. - Page No.

M - Continued

M137/M137A2/M137A3 Panoramic Telescope - Direct Support Maintenance (Continued)

Elbow Assembly	
Assembly	0088 00-3
Cleaning	0088 00-2
Disassembly	0088 00-2
Repair or Replacement	0088 00-2
Troubleshooting	0033 00-1

Head Assembly	
Assembly	0085 00-2
Cleaning	0085 00-2
Disassembly	0085 00-1
Repair or Replacement	0085 00-2
Troubleshooting	0030 00-1

Knob Assembly (Azimuth)	
Troubleshooting	0032 00-1

M137/M137A2/M137A3 Panoramic Telescope	
Assembly	0084 00-4
Cleaning.....	0084 00-4
Disassembly	0084 00-2
Repair or Replacement	0084 00-4

Optical Cell Assembly	
Assembly	0089 00-2
Cleaning	0089 00-1
Disassembly	0089 00-1
Repair or Replacement	0089 00-1

Optical Elements	
Troubleshooting.....	0036 00-1

M137/M137A2/M137A3 Panoramic Telescope - General Support Final	
Inspection Instructions	0100 00-1

M137/M137A2/M137A3 Panoramic Telescope - General Support Maintenance

Body Assembly	
Assembly	0095 00-6
Cleaning	0095 00-5
Disassembly	0095 00-2
Repair or Replacement	0095 00-6
Troubleshooting	0038 00-1

Counter Box Assembly (External Parts)	
Assembly	0098 00-4
Cleaning	0098-00-4
Disassembly	0098 00-2
Repair or Replacement	0098 00-4
Troubleshooting	0039 00-1

INDEX - Continued

Subject WP Sequence No. - Page No.

M - Continued

M137/M137A2/M137A3 Panoramic Telescope - General Support Maintenance (Continued)

Counter Box Assembly (Parts)

Assembly	0099 00-4
Cleaning	0099 00-3
Disassembly	0099 00-2
Repair or Replacement	0099 00-4

Elbow Assembly

Adjustment	0096 00-5
Assembly	0096 00-3
Cleaning	0096 00-3
Disassembly	0096 00-2
Repair or Replacement	0096 00-3

Head Assembly

Assembly	0093 00-4
Cleaning	0093 00-3
Disassembly	0093 00-2
Repair or Replacement	0093 00-4

M137/M137A2/M137A3 Panoramic Telescope

Assembly	0092 00-4
Cleaning	0092 00-3
Disassembly	0092 00-1
Repair or Replacement	0092 00-4

Optical Cell Assembly

Assembly	0097 00-2
Cleaning	0097 00-2
Disassembly	0097 00-2
Repair or Replacement	0097 00-2

Optical Element Spacer

Assembly	0094 00-3
Disassembly	0094 00-2
Installation	0094 00-3
Removal	0094 00-2
Repair or Replacement	0094 00-3

Optical Elements

Troubleshooting	0040 00-1
-----------------------	-----------

M137A2/M137A3 Panoramic Telescope - Direct Support Maintenance

Counter Box Assembly

Troubleshooting.....	0035 00-1
----------------------	-----------

M138 Elbow Telescope - Direct Support Maintenance

M138 Elbow Telescope

Assembly	0102 00-6
Cleaning	0102 00-5
Disassembly	0102 00-2
Repair or Replacement	0102 00-5
Troubleshooting	0042 00-1

INDEX - Continued

<u>Subject</u>	<u>WP Sequence No. - Page No.</u>
M - Continued	
M138/M138A1 Elbow Telescope - Direct Support Final Inspection	
Instructions	0106 00-1
M138/M138A1 Elbow Telescope - Direct Support Maintenance	
Optical Instrument Latch	
Assembly	0105 00-3
Disassembly	0105 00-1
Repair or Replacement	0105 00-2
Optical Instrument Latch Set	
Assembly	0104 00-2
Disassembly	0104 00-2
Installation	0104 00-3
Removal	0104 00-1
Repair or Replacement	0104 00-2
Troubleshooting	0044 00-1
M138A1 Elbow Telescope - Direct Support Maintenance	
M138A1 Elbow Telescope	
Assembly	0103 00-7
Cleaning	0103 00-6
Disassembly	0103 00-1
Repair or Replacement	0103 00-6
Troubleshooting.....	0043 00-1
M171 Telescope and Quadrant Mount - Direct Support Maintenance	
Bearing Housing Assembly	
Troubleshooting	0016 00-1
Optical Instrument Rocker Assembly	
Assembly	0062 00-3
Disassembly	0062 00-2
Repair or Replacement	0062 00-2
Optical Instrument Support	
Assembly	0060 00-3
Disassembly	0060 00-2
Repair or Replacement	0060 00-2
M171/M171A1 Telescope and Quadrant Mount - Direct Support Maintenance	
Bearing Housing Assembly	
Assembly	0064 00-3
Disassembly	0064 00-2
Repair or Replacement	0064 00-2
M171/M171A1 Mount	
Assembly	0059 00-3
Disassembly	0059 00-1
Repair or Replacement	0059 00-2

INDEX - Continued

<u>Subject</u>	<u>WP Sequence No. - Page No.</u>
M - Continued	
M171/M171A1 Telescope and Quadrant Mount - Direct Support Maintenance (Continued)	
Optical Instrument Support	
Troubleshooting	0015 00-1
M171/M171A1 Telescope and Quadrant Mount - General Support Final	
Inspection Instructions	0073 00-1
M171/M171A1 Telescope and Quadrant Mount - General Support Maintenance	
Bearing Housing Assembly	
Troubleshooting	0019 00-1, 0020 00-1
Housing Assembly	
Assembly	0070 00-10
Cleaning	0070 00-9
Disassembly	0070 00-2
Repair or Replacement	0070 00-9
Troubleshooting	0021 00-1
Mounting Adapter	
Assembly	0072 00-3
Disassembly	0072 00-2
Installation	0072 00-4
Removal	0072 00-1
Repair or Replacement	0072 00-3
M171/M171A1 Mount	
Assembly	0065 00-14
Cleaning	0065 00-13
Disassembly	0065 00-2
Repair or Replacement	0065 00-13
Optical Instrument Rocker Assembly	
Assembly	0067 00-3
Cleaning	0067 00-3
Disassembly	0067 00-1
Repair or Replacement	0067 00-3
Troubleshooting	0022 00-1
Optical Instrument Rocker	
Assembly	0068 00-2
Disassembly	0068 00-1
Repair or Replacement	0068 00-2
Optical Instrument Support	
Installation	0066 00-3
Removal	0066 00-1
Repair or Replacement	0066 00-2
Plunger Assembly	
Installation	0071 00-2
Removal	0071 00-1
Repair or Replacement	0071 00-2

INDEX - Continued

Subject WP Sequence No. - Page No.

M - Continued

M171/M171A1 Telescope and Quadrant Mount - General Support Maintenance (Continued)

Worm Shaft Assembly	
Cleaning	0069 00-4
Installation	0069 00-5
Removal	0069 00-1
Repair or Replacement	0069 00-4

M171A1 Telescope and Quadrant Mount - Direct Support Maintenance

Bearing Housing Assembly	
Troubleshooting	0017 00-1
Optical Instrument Rocker Assembly	
Assembly	0063 00-3
Disassembly	0063 00-1
Repair or Replacement	0063 00-3
Optical Instrument Support	
Assembly	0061 00-3
Disassembly	0061 00-2
Repair or Replacement	0061 00-2

M172/M172A1 Telescope and Quadrant Mount - Direct Support Maintenance

Adapter Assembly	
Assembly	0076 00-3
Disassembly	0076 00-2
Repair or Replacement	0076 00-2
Troubleshooting	0024 00-1
M172/M172A1 Mount	
Assembly	0075 00-2
Disassembly	0075 00-1
Repair or Replacement	0075 00-2
Quadrant Adapter	
Troubleshooting	0025 00-1

M172/M172A1 Telescope and Quadrant Mount - General Support Final

Inspection Instructions	0082 00-1
-------------------------------	-----------

M172/M172A1 Telescope and Quadrant Mount - General Support Maintenance

Access Cover	
Installation	0079 00-2
Removal	0079 00-1
Repair or Replacement	0079 00-2
Adapter Assembly	
Assembly	0080 00-4
Cleaning	0080 00-3
Disassembly	0080 00-3
Installation	0080 00-5
Removal	0080 00-2
Repair or Replacement	0080 00-4

INDEX - Continued

Subject WP Sequence No. - Page No.

M - Continued

M172/M172A1 Telescope and Quadrant Mount - General Support Maintenance (Continued)

M172/M172A1 Mount	
Assembly	0077 00-6
Cleaning	0077 00-5
Disassembly	0077 00-2
Repair or Replacement	0077 00-5
Troubleshooting	0027 00-1
Quadrant Adapter	
Repair or Replacement	0081 00-1
Telescope Mounting Bracket	
Installation	0078 00-2
Removal	0078 00-1
Repair or Replacement	0078 00-2
Troubleshooting	0028 00-1

N

National Stock Number Index	0150 00-1
Nomenclature Cross-Reference List	0001 00-3

P

Part Number Index	0151 00-1
Preembarkation Inspection	0107 00-1
Preparation for Storage or Shipment	0001 00-2, 0107 00-1
Purpose of Equipment	0001 00-1

R

References	0108 00-1
Repair Parts List	0110 00-1 through 0149 00-1
Reporting Equipment Improvement Recommendations (EIR)	0001 00-2

S

Safety, Care, and Handling	0001 00-4
Scope - General Information	0001 00-1
Scope - References	0108 00-1
Service upon Receipt of Materiel - M17/M18 and M17A1/M18A1	
Fire Control Quadrant	0045 00-1
Service upon Receipt of Materiel - M137/M137A2/M137A3	
Panoramic Telescope	0083 00-1

INDEX - Continued

<u>Subject</u>	<u>WP Sequence No. - Page No.</u>
S - Continued	
Service upon Receipt of Materiel - M138/M138A1 Elbow Telescope	0101 00-1
Service upon Receipt of Materiel - M171/M171A Telescope and Quadrant Mount	0058 00-1
Service upon Receipt of Materiel - M172/M172A1 Telescope and Quadrant Mount	0074 00-1
T	
Table of Contents	ii
Technical Manuals	0108 00-2
Theory of Operation	0003 00-1
Troubleshooting Procedures - Direct Support for M17/M18 Fire Control Quadrant	0005 00-1
Troubleshooting Procedures - Direct Support for M17/M17A1/M18/M18A1 Fire Control Quadrant.....	0007 00-1
Troubleshooting Procedures - Direct Support for M17A1/M18A1 Fire Control Quadrant	0006 00-1
Troubleshooting Procedures - General Support for M17/M17A1/M18/M18A1 Fire Control Quadrant	0010 00-1, 0011 00-1, 0012 00-1, 0013 00-1
Troubleshooting Procedures - General Support for M17/M18 Fire Control Quadrant	0009 00-1
Troubleshooting Procedures - Direct Support for M137 Panoramic Telescope	0034 00-1
Troubleshooting Procedures - Direct Support for M137/M137A2/M137A3 Panoramic Telescope	0030 00-1, 0031 00-1, 0032 00-1, 0033 00-1, 0036 00-1
Troubleshooting Procedures - Direct Support for M137A2/M137A3 Panoramic Telescope	0035 00-1
Troubleshooting Procedures - General Support for M137/M137A2/M137A3 Panoramic Telescope	0038 00-1, 0039 00-1, 0040 00-1
Troubleshooting Procedures - Direct Support for M138 Elbow Telescope	0042 00-1
Troubleshooting Procedures - Direct Support for M138/M138A1 Elbow Telescope	0044 00-1
Troubleshooting Procedures - Direct Support for M138A1 Elbow Telescope	0043 00-1
Troubleshooting Procedures - Direct Support for M171 Telescope and Quadrant Mount	0016 00-1
Troubleshooting Procedures - Direct Support for M171/M171A1 Telescope and Quadrant Mount	0015 00-1
Troubleshooting Procedures - Direct Support for M171A1 Telescope and Quadrant Mount	0017 00-1
Troubleshooting Procedures - General Support for M171 Telescope and Quadrant Mount	0019 00-1

INDEX - Continued

Subject WP Sequence No. - Page No.

T - Continued

Troubleshooting Procedures - General Support for M171/M171A1 Telescope and Quadrant Mount	0021 00-1, 0022 00-1, 0023 00-1
Troubleshooting Procedures - General Support for M171A1 Telescope and Quadrant Mount	0020 00-1
Troubleshooting Procedures - Direct Support for M172/M172A1 Telescope and Quadrant Mount	0024 00-1, 0025 00-1
Troubleshooting Procedures - General Support for M172/M172A1 Telescope and Quadrant Mount	0027 00-1, 0028 00-1
Type of Manual	0001 00-1

W

Warning Summary	a
-----------------------	---

<p>RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS</p> <p>For use of this form, see AR 25-30; the proponent agency is ODISC4.</p>	<p>Use Part II (reverse) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).</p>	<p>DATE</p> <p>Date you filled out this form</p>
--	--	---

<p>TO: (Forward to proponent of publication or form) (Include ZIP Code) AMSTA-LC-LMIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630</p>	<p>FROM: (Activity and location) (Include ZIP Code) Your mailing address</p>
--	--

PART I – ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS

<p>PUBLICATION/FORM NUMBER TM 9-1240-375-34&P</p>	<p>DATE 15 March 2005</p>	<p>TITLE DS and GS Maint. for Quadrant, Fire Control: M17/M17A1/M18/M18A1; Mount, Telescope and Quadrant: M171/M171A1/M172/M172A1; Telescope, Panoramic: M137/M137A2/M137A3; and Telescope, Elbow: M138/M138A1</p>
--	--	---

ITEM NO.	PAGE NO.	PARA-GRAPH	LINE NO.*	FIGURE NO.	TABLE NO.	RECOMMENDED CHANGES AND REASON <i>(Provide exact wording of recommended changes, if possible).</i>
	0061 00-7	0061 00				<p>Illustration shows wrong design for packing retainer.</p> <div style="border: 1px solid black; padding: 20px; text-align: center; font-size: 4em; font-weight: bold; transform: rotate(-15deg); opacity: 0.5;"> SAMPLE </div>

**Reference to line numbers within the paragraph or subparagraph.*

<p>TYPED NAME, GRADE OR TITLE</p> <p>Your Name</p>	<p>TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION</p>	<p>SIGNATURE</p> <p>Your Signature</p>
--	---	--

TO: <i>(Forward direct to addressee listed in publication)</i> AMSTA-LC-LMIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630	FROM: <i>(Activity and location) (Include ZIP Code)</i> Your address	DATE Date you filled out this form
---	--	--

PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER TM 9-1240-375-34&P	DATE 15 March 2005	TITLE DS and GS Maint. for Quadrant, Fire Control: M17/M17A1/M18/M18A1; Mount, Telescope and Quadrant: M171/M171A1/M172/M172A1; Telescope, Panoramic: M137/M137A2/M137A3; and Telescope, Elbow: M138/M138A1
--	-----------------------	--

PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

PART III - REMARKS *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE Your Name	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE Your Signature
---	--	---------------------------------

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS For use of this form, see AR 25-30; the proponent agency is ODISC4.						Use Part II (reverse) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE
TO: (Forward to proponent of publication or form) (Include ZIP Code) AMSTA-LC-LMIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630						FROM: (Activity and location) (Include ZIP Code)	
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER TM 9-1240-375-34&P						DATE 15 March 2005	TITLE DS and GS Maint. for Quadrant, Fire Control: M17/M17A1/M18/M18A1; Mount, Telescope and Quadrant: M171/M171A1/M172/M172A1; Telescope, Panoramic: M137/M137A2/M137A3; and Telescope, Elbow: M138/M138A1
ITEM NO.	PAGE NO.	PARA-GRAPH	LINE NO. *	FIGURE NO.	TABLE NO.	RECOMMENDED CHANGES AND REASON <i>(Provide exact wording of recommended changes, if possible).</i>	
<i>*Reference to line numbers within the paragraph or subparagraph.</i>							
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE	

TO: <i>(Forward direct to addressee listed in publication)</i> AMSTA-LC-LMIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630	FROM: <i>(Activity and location) (Include ZIP Code)</i>	DATE
---	--	-------------

PART II – REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER TM 9-1240-375-34&P	DATE 15 March 2005	TITLE DS and GS Maint. for Quadrant, Fire Control: M17/M17A1/M18/M18A1; Mount, Telescope and Quadrant: M171/M171A1/M172/M172A1; Telescope, Panoramic: M137/M137A2/M137A3; and Telescope, Elbow: M138/M138A1
--	-----------------------	--

PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

PART III – REMARKS *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE
----------------------------	--	-----------

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS For use of this form, see AR 25-30; the proponent agency is ODISC4.						Use Part II (reverse) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE
TO: (Forward to proponent of publication or form) (Include ZIP Code) AMSTA-LC-LMIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630						FROM: (Activity and location) (Include ZIP Code)	
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER TM 9-1240-375-34&P						DATE 15 March 2005	TITLE DS and GS Maint. for Quadrant, Fire Control: M17/M17A1/M18/M18A1; Mount, Telescope and Quadrant: M171/M171A1/M172/M172A1; Telescope, Panoramic: M137/M137A2/M137A3; and Telescope, Elbow: M138/M138A1
ITEM NO.	PAGE NO.	PARA-GRAPH	LINE NO. *	FIGURE NO.	TABLE NO.	RECOMMENDED CHANGES AND REASON <i>(Provide exact wording of recommended changes, if possible).</i>	
<i>*Reference to line numbers within the paragraph or subparagraph.</i>							
TYPED NAME, GRADE OR TITLE						TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE

TO: <i>(Forward direct to addressee listed in publication)</i> AMSTA-LC-LMIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630	FROM: <i>(Activity and location) (Include ZIP Code)</i>	DATE
---	--	-------------

PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER TM 9-1240-375-34&P	DATE 15 March 2005	TITLE DS and GS Maint. for Quadrant, Fire Control: M17/M17A1/M18/M18A1; Mount, Telescope and Quadrant: M171/M171A1/M172/M172A1; Telescope, Panoramic: M137/M137A2/M137A3; and Telescope, Elbow: M138/M138A1
--	-----------------------	--

PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

PART III - REMARKS *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE
----------------------------	--	-----------

By Order of the Secretary of the Army:

PETER J. SCHOOMAKER
General, United States Army
Chief of Staff

Official:



SANDRA R. RILEY

Administrative Assistant to the
Secretary of the Army

0433101

DISTRIBUTION: To be stocked and distributed by the proponent.

THE METRIC SYSTEM AND EQUIVALENTS

LINEAR MEASURE

1 Centimeter = 10 Millimeters = 0.01 Meter = 0.3937 Inch
 1 Decimeter = 10 Centimeters = 3.94 Inches
 1 Meter = 10 Decimeters = 100 Centimeters
 = 1000 Millimeters = 39.37 Inches.
 1 Dekameter = 10 Meters = 32.8 Feet
 1 Hectometer = 10 Dekameters = 328.08 Feet
 1 Kilometer = 10 Hectometers = 1000 Meters
 = 0.621 Mile = 3,280.8 Feet
 Millimeters = Inches times 25.4
 Inches = Millimeters divided by 25.4

WEIGHTS

1 Centigram = 10 Milligrams = 0.154 Grain
 1 Decigram = 10 Centigrams = 1.543 Grains
 1 Gram = 0.001 Kilogram = 10 Decigrams
 = 1000 Milligrams = 0.035 Ounce
 1 Dekagram = 10 Grams = 0.353 Ounce
 1 Hectogram = 10 Dekagrams = 3.527 Ounces
 1 Kilogram = 10 Hectograms = 1000 Grams = 2.205 Pounds
 1 Quintal = 100 Kilograms = 220.46 Pounds
 1 Metric Ton = 10 Quintals = 1000 Kilograms
 = 1.1 Short Tons

LIQUID MEASURE

1 Milliliter = 0.001 Liter = 0.034 Fluid Ounce
 1 Centiliter = 10 Milliliters = 0.34 Fluid Ounce
 1 Deciliter = 10 Centiliters = 3.38 Fluid Ounces
 1 Liter = 10 Deciliters = 1000 Milliliters
 = 33.82 Fluid Ounces
 1 Dekaliter = 10 Liters = 2.64 Gallons
 1 Hectoliter = 10 Dekaliters = 26.42 Gallons
 1 Kiloliter = 10 Hectoliters = 264.18 Gallons

SQUARE MEASURE

1 Sq Centimeter = 100 Sq Millimeters = 0.155 Sq Inch
 1 Sq Decimeter = 100 Sq Centimeters = 15.5 Sq Inches
 1 Sq Meter (Centare) = 10 Sq Decimeters
 = 10,000 Sq Centimeters = 10.764 Sq Feet
 1 Sq Dekameter (Are) = 100 Sq Meters = 1,076.4 Sq Feet
 1 Sq Hectometer (Hectare) = 100 Sq Dekameters
 = 2.471 Acres
 1 Sq Kilometer = 100 Sq Hectometers
 = 1,000,000 Sq Meters = 0.386 Sq Mile

CUBIC MEASURE

1 Cu Centimeter = 1000 Cu Millimeters = 0.061 Cu Inch
 1 Cu Decimeter = 1000 Cu Centimeters = 61.02 Cu Inches
 1 Cu Meter = 1000 Cu Decimeters
 = 1,000,000 Cu Centimeters = 35.31 Cu Feet

TEMPERATURE

$5/9 (°F - 32°) = °C$
 $9/5 (°C + 32°) = °F$
 -35° Fahrenheit is equivalent to -37° Celsius
 0° Fahrenheit is equivalent to -18° Celsius
 32° Fahrenheit is equivalent to 0° Celsius
 90° Fahrenheit is equivalent to 32.2° Celsius
 100° Fahrenheit is equivalent to 38° Celsius
 212° Fahrenheit is equivalent to 100° Celsius

APPROXIMATE CONVERSION FACTORS

<u>TO CHANGE</u>	<u>TO</u>	<u>MULTIPLY BY</u>	<u>TO CHANGE</u>	<u>TO</u>	<u>MULTIPLY BY</u>
Inches.....	Centimeters.....	2.540	Centimeters	Inches	0.394
Feet	Meters.....	0.305	Meters	Feet	3.280
Yards.....	Meters.....	0.914	Meters	Yards	1.094
Miles.....	Kilometers	1.609	Kilometers.....	Miles	0.621
Square Inches	Square Centimeters	6.451	Square Centimeters.....	Square Inches.....	0.155
Square Feet.....	Square Meters	0.093	Square Meters.....	Square Feet.....	10.764
Square Yards	Square Meters	0.836	Square Meters.....	Square Yards.....	1.196
Square Miles	Square Kilometers.....	2.590	Square Kilometers.....	Square Miles.....	0.386
Acres	Square Hectometers.....	0.405	Square Hectometers....	Acres.....	2.471
Cubic Feet.....	Cubic Meters.....	0.028	Cubic Meters.....	Cubic Feet	35.315
Cubic Yards.....	Cubic Meters.....	0.765	Cubic Meters.....	Cubic Yards.....	1.308
Fluid Ounces	Milliliters.....	29.573	Milliliters.....	Fluid Ounces.....	0.034
Pints.....	Liters.....	0.473	Liters	Pints.....	2.113
Quarts.....	Liters.....	0.946	Liters	Quarts	1.057
Gallons.....	Liters.....	3.785	Liters	Gallons	0.264
Ounces	Grams.....	28.349	Grams.....	Ounces.....	0.035
Pounds.....	Kilograms	0.454	Kilograms.....	Pounds.....	2.205
Short Tons	Metric Tons	0.907	Metric Tons	Short Tons	1.102
Pound-Feet	Newton-Meters.....	1.356	Newton-Meters.....	Pound-Feet.....	0.738
Pounds-Inches	Newton-Meters.....	0.11375	Kilopascals	Pounds per Square Inch....	0.145
Pounds per Square Inch..	Kilopascals.....	6.895	Kilometers per Liter ...	Miles per Gallon.....	2.354
Ounce-Inches	Newton-Meters.....	0.007062	Kilometers per Hour ...	Miles per Hour	0.621
Miles per Gallon.....	Kilometers per Liter.....	0.425	°Fahrenheit.....	°Celsius	$°C = (°F-32) \times 5/9$
Miles per Hour	Kilometers per Hour	1.609	°Celsius	°Fahrenheit.....	$°F = (9/5 \times °C) + 32$

PIN: 082036-000