

OPERATOR'S MANUAL



**INTRODUCTION
PAGE 1-1**

**OPERATING INSTRUCTIONS
PAGE 2-1**

**MAINTENANCE INSTRUCTIONS
PAGE 3-1**

**REFERENCES
PAGE A-1**

**BASIC ISSUE ITEMS LIST
PAGE B-1**

**EXPENDABLE SUPPLIES AND
MATERIALS LIST
PAGE C-1**

**This copy is a reprint which includes current
pages from Change 1.**

**BOAT, BRIDGE ERECTION,
TWIN JET, ALUMINUM HULL
MODEL USCSBMK 1
(1940-01-105-5728)
MODEL USCSBMK 2
(1940-01-218-9165)**

Distribution Statement A: Approved for public release; distribution is unlimited

This manual supersedes TM 5-1940-277-10, Dated 16 December 1981

CHANGE

HEADQUARTERS, DEPARTMENT OF THE ARMY
AND HEADQUARTERS, U.S. MARINE CORPS
WASHINGTON, D.C., 19 August 1996

No. 2

Operator's Manual

**BOAT, BRIDGE ERECTION, TWIN JET, ALUMINUM HULL,
MODELS USCSBMK 1 (1940-01-105-5728) AND
USCSBMK 2 (1940-01-218-9165)**

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 5-1940-277-10, 15 September 1993, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.


Remove pages
B-3 and B-4
B-5/(B-6 blank)

Insert pages
B-3 and B-4

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretaries of the Army and Navy (Including the Marine Corps):

Official:



*Administrative Assistant to the
Secretary of the Army*
02721

DENNIS J. REIMER
*General, United States Army
Chief of Staff*

J. E. BUFFINGTON
*Rear Admiral, CEC, US Navy
Commander
Navy Facilities Engineering
Command*

D. R. BLOOMER
*Colonel, USMC
Director, Program Support
Marine Corps Systems Command*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25-E, block no. 0262, requirements for TM 5-1940-277-10.

CHANGE
NO. 1

HEADQUARTERS DEPARTMENT OF THE ARMY
HEADQUARTERS, U.S. MARINE CORPS
WASHINGTON, D.C., 28 FEBRUARY 1994

Operator's Manual

BOAT, BRIDGE ERECTION, TWIN JET, ALUMINUM HULL,
MODELS USCSBMK 1 (1940-01-105-5728) AND
USCSBMK 2 (1940-01-218-9165)

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 5-1940-277-10, 15 September 1993 is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

1-21 and 1-22
2-21 and 2-22
2-25 and 2-26

Insert pages


1-21 and 1-22
2-21 and 2-22
2-25 and 2-26

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretaries of the Army and Navy (Including the Marine Corps):

GORDON R. SULLIVAN
General, United States Army
Chief of Staff

Official:


MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army
08631

DAVID E BOTTORFF
Rear Admiral, CEC, US Navy
Commander
Navy Facilities Engineering
Command

D. R. BLOOMER
Colonel, USMC
Director, Program Support
Marine Corps Systems Command

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25-E, block no. 0262, requirements for TM 5-1940-277-10.

WARNING

SERIOUS INJURY OR DEATH

may result if personnel fail to observe the following safety precautions:

It is critical for SAFETY purposes to keep the engine hatch covers closed when engines are running, except when engine maintenance is being performed.

Engine hatch covers must be dosed to allow fire extinguisher to extinguish fire.

Batteries give off explosive hydrogen gas. Do not smoke around batteries.

Do not operate engines in an enclosed area without adequate ventilation as carbon monoxide, an invisible poisonous gas, is generated. Symptoms of exposure to carbon monoxide are headache, dizziness, drowsiness, loss of muscular control and coma. Severe exposure can cause permanent brain damage.

Wear life preservers (work vest) at all times when aboard the boat.

Do not allow personnel between boats during slave starting.

Diesel fuel is flammable. Do not allow smoking or any open flames near the boat when you're refueling. Wipe up spilled fuel.

Engines must be shut down during fueling operations. Fire or explosion may result.

Do not turn panel lights on during blackout condition as a lit panel could make you an easy target.

For Artificial Respiration, refer to FM 21-11.

Ear protection (ear plugs) must be worn when operating this boat.

Minimize boat maneuvering against bay until all roadway connectors are in place. Personnel injury could result.

When working near mast assembly, avoid striking head on protruding parts of mast assembly. To avoid injury be aware of mast assembly position when working below mast.

The boat is only to be used for towing when the quick-disconnect towing hook is installed and operational.

Operator's Manual
BOAT, BRIDGE ERECTION,
TWIN JET, ALUMINUM HULL,
MODELS USCSBMK 1 (1940-01-105-5728) AND
USCSBMK 2 (1940-01-218-9165)

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes, or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, Headquarters, U. S. Army Aviation and Troop Command, ATTN: AMSAT-I-MP, 4300 Goodfellow Boulevard, St. Louis MO 63120-1798. A reply will be furnished you.

Marine Corps users shall submit NAVMC Form 10772, Recommended Changes to Technical Publications. Send to: Commanding General, Marine Corps Logistics Base (Code 850), Albany, GA 31704-5000.

Distribution Statement A: Approved for release; distribution is unlimited

CHAPTER 1	INTRODUCTION.....	1-1
Section I	General Information	1-1
Section II	Equipment Description	1-2
Section III	Technical Principles of Operation.....	1-13
CHAPTER 2	OPERATING INSTRUCTIONS	
Section I	Description and Use of Operator's Controls and Indicators	2-1
Section II	Preventive Maintenance Checks and Services (PMCS).....	2-14
Section III	Operation Under Usual Conditions	2-48
Section IV	Operation Under Unusual Conditions.....	2-103
CHAPTER 3	MAINTENANCE INSTRUCTIONS.....	3-1
Section I	Lubrication Instructions.....	3-1
Section II	Troubleshooting Procedures.....	3-1
Section III	Maintenance Procedures.....	3-12
APPENDIX A	REFERENCES.....	A-1
APPENDIX B	COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LISTS.....	B-1
APPENDIX C	EXPENDABLE SUPPLIES AND MATERIALS LIST.....	C-1
	ALPHABETICAL INDEX	Index-1

* This manual supersedes TM 5-1940-277-10, dated 16 December 1981

CHAPTER 1

INTRODUCTION

Section I. GENERAL INFORMATION

1-1. SCOPE

- a. Type of Manual: Operator's Manual.
- b. Model Number and Equipment Name: Bridge Erection Boat. Twin Jet, Aluminum Hull. The model numbers assigned to this equipment are USCSBMK1 and USCSBMK2.
- c. Purpose of Equipment: Support bridging an amphibious operations. May also be used as general purpose workboat in support of diving operations and maritime projects, for inland water patrols. and as a safety boat for amphibious river crossings.

WARNING

The boat is only to be used for towing when the quick-disconnect towing hook is installed and operational.

- d. Special Limitations on Equipment: When used to ferry troops or cargo, the safe carrying capacity is limited to a maximum of 12 fully equipped troops, plus three crew members or 4400 pounds (2000 kilograms) plus three crew members. When the boat is used for towing, the towing capacity is 4,000 pounds (2000 kilograms), plus three crew members.
- e. Special Inclusions in Manual: This manual contains instructions for bridging and rafting.

1-2. MAINTENANCE FORMS AND RECORDS. Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 738-750, The Army Maintenance Management System (TAMMS). Marine Corps personnel will prepare and maintain records and report forms as prescribed by TM 4700-15/1, Equipment Record Procedures.

1-3. HAND RECEIPT (-HR) MANUALS. This manual has a companion document with a TM number followed by "-HR" (which stands for Hand Receipt). The TM 5-1940-277-10-HR consists of preprinted hand receipts (DA Form 2062) that list end item related equipment (i. e. . COEIL, BII, and AAL) you must account for. As an aid to property accountability, additional -HR manuals may be requisitioned from the following source in accordance with procedures in Chapter 3, AR 310-2:

U. S. Army Adjutant General Publications Center
2800 Eastern Blvd.
Baltimore, MD 21220-2896

1-4. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS. If your boat needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design or performance. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at Commander, Headquarters, U. S. Army Aviation and Troop Command, ATTN: AMSAT-I-MDO, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798. U. S. Marine Corps users are encouraged to submit EIRs in accordance with MCO 1650. 17. or submit Quality Deficiency Reports in accordance with MCO 4855. 10. Mail it to us at Commanding General (P840), Marine Corps Logistics Base, Albany, GA 31704-5000. We'll send you a reply.

1-5. WARRANTY INFORMATION. The Bridge Erection Boat, USCSBMK1, is warranted by Fairey Allday Marine Limited for 12 months. The Bridge Erection Boat USCSBMK2 is warranted by American Development Corporation for 12 months. The warranty starts on the date found in block 23 of DA Form 2408-9 in the logbook. Report all defects in material or workmanship to your supervisor, who will take appropriate action through your organizational maintenance supervisor.

1-6. GLOSSARY


Berth	Place at dock where boat is tied up or anchored.
Capstan	Manually rotated vertical cylinder for winding rope or cable.
Hydrojet	Propelling system that uses water.
MK1 (USCSBMK1)	Combat Support Boat, Mark 1. Original model of Bridge Erection Boat.
MK2 (USCSBMK2)	Combat Support Boat, Mark 2. Modified model of Bridge Erection Boat.
Raw water	River water.
Rub rail	Rubber bumper strip around boat hull.
Scoop	Movable metal cover that directs water stream that comes from hydrojets.
Thermostarter	Glow plug used to preheat intake air for cold starting.
Vdc	Volts direct current.

Section II. EQUIPMENT DESCRIPTION

1-7. PURPOSE OF BRIDGE ERECTION BOAT. A transportable, hydrojet propelled, aluminum hull boat designed to maneuver components of floating bridges. The boat can also be used to propel rafts, support diving operations, assist in maritime construction projects, serve as a troop and cargo carrier, and patrol inland waters.


1-8. CAPABILITIES AND FEATURES.

- a. Can rotate on its own axis at low engine speeds.
- b. All weather operational.
- c. Transportable by rail, road, sea, and air. (See TB 55-46-1).
- d. Positive Flotation.



1-9. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS

- a. Removable Cab (1). An aluminum frame with windows and aluminum roof that can be attached to the boat to provide protection for the crew during bad weather. The cab is provided with windshield wiper and a place for attaching searchlight.
- b. Control Console (2). Contains all the controls and indicators required for operation of the boat. In addition, it contains a hand operated bilge pump, a stowage compartment for technical manuals, and a stowage compartment for life preservers and other gear.




- c. Batteries (3). Provide electrical power for the operation of the boat.
- d. Removable Mast (4). Contains the navigation lights, towing lights, and anchor lights. May be lowered to rest on capstan or removed from the boat when lights are not required.
- e. Hydrojets (5). Consist of diesel engine driven hydrojet propulsion units with directional nozzles and scoops. The propulsion units propel the boat and steer it.
- f. Capstan and Towing Hook (6). Provides the boat with a safe towing capability of 4000 pounds. The hook is of the quick-release lanyard-operated type.
- g. Davit Tube (7) (MK1 only). Allows the attachment of a davit (small crane) to the boat for use in diving operations. Not used in U. S. Army operations.
- h. Beaching Legs (8). Support the boat in an upright position when on a hard surface and not in cradle. The beaching legs are retractable.
- i. Engines (9). Provide power for driving hydrojet units.
- j. Fuel Tank (10). Provides fuel storage capacity for operation of boat.
- k. Pushknees (11). Provides the front of the boat with a flat vertical surface for pushing barges or maneuvering bridge components. The pushknees can be removed.



CAUTION

Do not beach boat on rock shores. Damage to keel and keel cooler may result.

- l. Kee Coolers (12) (MK2 only). Provide cooling for the engine, transmission, oil, and turbocharged air. Located on the bottom of the boat.
- m. Tow Hook (13). Provides towing capability for pulling disabled boats. The tow hook has a quick-release mechanism for disengaging a dangerous load.




1-10. LOCATION AND DESCRIPTION OF FORWARD COCKPIT AND CONTROL CONSOLE. The console is located at the forward end of the boat and contains the controls necessary to operate the boat, the manual bilge pump, and stowage compartments.






- a. Transmission Selector Lever (1). Allows operator to place individual gears in forward-neutral-reverse position.
- b. Engine Instrument Panel (2). Contains oil pressure gages, engine water temperature gages, engine tachometers, battery condition meter, ignition switches, and warning lights.
- c. Engine Alarm Mute Switches (3). Allows operator to turn off engine audible alarm. (Indicates low engine oil pressure or high water temperature.)
- d. Engine Throttle Controls (4). Allows operator to control the revolutions per minute (rpm) of each engine.
- e. Cab Electrical Connector (5). Provides electrical connection for cab windshield wipers and searchlight.
- f. Scoop Control (6). Allows operator to control direction of output from hydrojets to obtain forward and reverse direction of boat. May also be used to assist in turning boat and controlling speed.
- g. Searchlight Socket (7). Provides electrical connection for searchlight when cab is removed.
- h. Searchlight Mounting (8). Provides mounting for searchlight when cab is removed.
- i. Handrail (9). Provides a safety rail.
- j. Map Locker (10). Provides stowage space for technical manuals.
- k. Bilge Pump, Hand Operated (11). Provides manual means of pumping water from bilge (MK1).
- l. Pump Handle (12). Removable handle for hand operated bilge pump (MK1) stowed on starboard bulkhead under the console.
- m. Storage locker (13). Provides a lockable stowage compartment for life jackets and other equipment.
- n. Engine Stop Control, Starboard (14). Stops the starboard engine when pulled out.
- o. Engine Stop Control, Port (15). Stops the port engine when pulled out.
- p. Scoop Position Indicator (16). Provides a means for the operator to position the scoops for straight ahead movement of the boat. (Located on steering column directly behind steering wheel.)
- q. Steering Wheel (17). Used to steer the boat.
- r. Warning Decal (18). Indicates to the operator that caution should be taken (MK-1).
- s. Switch Panel Unit 1 (19). 12-circuit power panel contains electrical switches for cabin lights, inspection light, mast light, wipers (port and starboard), emergency battery link, and searchlight.
- t. Switch Panel Unit 2 (20). 6-circuit power panel contains electrical switches for forward and aft bilge pumps, auto control of bilge pumps and hom. Engine room blower is not used.
- u. Caution Plate (21). Indicates to operator that hearing protection is required for noise pollution (MK2 only).
- v. Hatchet Bracket (22). To secure hatchet for emergency use (MK2 only).

1-11. DIFFERENCES BETWEEN MODELS. There are two models of the Bridge Erection Boat, the MK1, and MK2. The two models have different engine cooling systems.

- a. The MK1 version uses two closed fresh water systems. Raw water is also drawn from the hydrojet unit to pass through a remote heat exchanger unit which cools the fresh water flowing through the remote unit's coil. The exhaust system expels exhaust gases and raw water via port and starboard wet exhaust outlets.



- b. MK2. Each MK2 engine uses two closed cooling systems which share a common reservoir. The MK2 uses a wet exhaust system similar to the MK1. The hydrojet forces raw water into the exhaust system and out the exhaust port on the side of the boat.



**CLOSED COOLING SYSTEM
(FRESH WATER)**

EQUIPMENT DATA

WEIGHTS AND DIMENSIONS

Operating	
Weight, w/ crew, equipment and fuel (Gross Weight)	8800 lbs (4000 kg)
Length	322.8 in (820 cm)
Beam	98.0 in (249 cm)
Height	
w/o cab or mast	77.9 in (198 cm)
w/ cab	109.8 in (279 cm)
w/ cab and mast	177.9 in (452 cm)
Draft	
w/ crew, equipment and fuel	22.0 in (56 cm)
fully loaded	26.0 in (66 cm)
Transported, w/ cradle	
Weight	10800 lbs (4909 kg)
Length	326.4 in (826 cm)
Height w/o cab	96.3 in (244 cm)
Width	116.3 in (294 cm)
Shipping Weight	11100 lbs (2448 kg)

PERFORMANCE

Speed, w/ crew, equipment and fuel	21.6 mph (40 km/rhr)
Speed, fully loaded	16.2 mph (30 km/hr)
Maximum load carrying capacity	4400 lbs (2000 kg)
Towing hook	4400 lbs (2000 kg)
Turning radius (with scoops at maximum thrust)	
Full speed ahead	2 boat lengths in 15 seconds
Full speed astern	2 boat lengths in 25 seconds
One scoop forward and one scoop in reverse	Standing circle
Fuel consumption (approximate)	
1750 rpm	2.8 gallons/hour (11 liters/hour)
2000 rpm	4.2 gallons/hour (16 liters/hour)
2250 rpm	6.0 gallons/hour (23 liters/hour)
2450 rpm	10.8 gallons/hour (40 liters/hour)
Maximum forward thrust	3600 pounds (16 kN)
Maximum reverse thrust	2200 pounds (9.8 kN)
Maximum safe engine operating speed (No load governing setting)	2800 rpm

CAPACITY

Fuel	75 gallons (280 liters)
------	----------------------------

ENGINE INSTRUMENT PANEL GAGE READINGS

Tachometer	
Idle speed	650 to 750 rpm
Operating speed	1000 to 2000 rpm
Maximum speed (under load)	2500 rpm
Engine oil pressure gage	
Idle speed	20 to 30 lb/in ² (1.4 to 2.1 Kp/cm ²)
Operating speed	40 lb/in ² or above (2.8 Kp/cm ²)
Coolant temperature gage (fresh water system)	
Normal	Below 195°F (90°C)
Overheating	Above 195°F (90°C)
Battery condition meter (engine not running, no electrical load)	
Battery fully charged	25.4 volts or above
Battery half charged	24.6 to 25.4 volts
Battery fully discharged	23.7 volts or below

NOTE


The above readings are most reliable if the batteries have stood for at least 8 hours with out charge or discharge.

Battery condition meter (engine running about 1500 rpm and no electrical load)	
Battery near to fully charged	27.0 to 28.0 volts
Battery partially discharged	24.0 to 27.0 volts
Battery charge low	Below 24.0 volts
Battery condition meter (normal operation)	
Above 24 volt	Alternator output matching or greater than electrical load
Below 24 volts	Load in excess of alternator output

Section III. TECHNICAL PRINCIPLES OF OPERATION

1-12. PROPULSION SYSTEM

- a. Engines are 363 cubic inches (5.95 liter), 212 horsepower, 6-cylinder, water-cooled, diesel engines. Engine speed is adjusted by the throttle control mounted on the control console. Fuel is provided by an external fuel system.
- b. Transmissions are 3-position, direct drive, hydraulically operated, oil-cooled units that transmit power from each engine to its respective drive shaft.
- c. Drive-Neutral-Reverse position of each transmission is separately and mechanically adjusted by the transmission selector lever located on the control panel.
- d. Drive Shafts transfer power from engines to hydrojet units.
- e. Hydrojet Units are hydrojet propulsion units that provide the thrust to move and steer the boat. Water is drawn in through grilles in the underside of the boat and expelled through nozzles mounted beyond the back of the boat. The force with which the water is expelled depends on the speed of the engine.
- f. Scoops are movable metal shields that fit over the nozzles of the propulsion units and direct the flow of water from the nozzle. The position of the scoops is mechanically adjusted by the steering wheel and the scoop control levers mounted on the control panel. The steering wheel controls the port-starboard directional movement of the boat. The scoop control levers control the forward-reverse motion of the boat. At low speeds, the scoop control can be used to turn the boat by having one scoop in reverse position and the other in neutral or forward position.



1-13. MK1 ENGINE COOLING SYSTEM

a. Flow During Engine Warm Up

During this type of operation the system is divided into two principal circuits (1) and (2), which are almost independent of each other with a third circuit (3) providing de-aeration.

- (1) **Thermostatically Controlled Cylinder Block Circuit** In this circuit, water is circulated by the conventional engine mounted water pump 'A', which directs water into the block and then to the cylinder head. From there, the water is taken by duct 'B' to the water jacket around the exhaust manifold. A small pipe 'C' connects to the header tank to allow air to escape during filling, also providing a small flow when the engine is running so that continuous de-aeration takes place. From the exhaust manifold jacket, the water flows through pipe 'D' to the full flow bypass thermostat. If the water temperature is below the thermostat opening temperature, the flow passes through pipes 'E' and 'F' to the engine oil cooler, and then through pipe 'I' to the pump 'A', thus completing the circuit.

(2) Low Temperature Circuit


A pump 'H' directs water through pipe 'J' to the gearbox oil cooler, and then through pipe 'K' to the charge air cooler. The water then flows through pipes 'L', 'M' and 'N' to the 'remote cooler'. From the 'remote cooler' the water returns to the pump 'H' via pipe 'P'. A small pipe 'Q' allows air to escape from the circuit when filling, and provides continuous de-aeration when the engine is running.

- (3) **Header Tank Circuit** The header tank receives a small flow of water through pipes 'Q' and 'C', and returns make-up water through pipe 'R', close to the inlet to pump 'A'.



b. Flow When Engine Coolant Is Up To Normal Operating Temperature

In this condition the flows described in a (1), 1 (2) and a (3) continue, but an additional flow circuit is set up which connects the two circuits (1) and (2) together:

- (1) **Low Temperature Flow Diluting Thermostatically Controlled Cylinder Block Circuit** When the engine thermostat valve opens, water flows through pipe 'S' and then into pipe 'N' leading to the remote cooler. The water lost from the engine cylinder block circuit is replaced by water from the low temperature circuit, passing through pipe 'T' and diluting the 'by-pass' water flowing from 'E' and 'F'. By these means the temperature in the cylinder block circuit is controlled by the thermostat.




REMOTE COOLER





MK-1 FRESH WATER ENGINE COOLING SYSTEM

1-14. MK2 ENGINE COOLING SYSTEM

- a. Primary Engine Cooling System. The primary engine cooling system is identical for both port and starboard engines. Coolant flows from the primary water pump through the engine block to the header and through the exhaust manifold to the thermostat where it is diverted to the keel cooler or to the primary water pump. The coolant diverted to the keel cooler flows through the keel cooler to the oil cooler and back to the primary water pump.
- (1) Primary Water Pump circulates coolant through the primary cooling system.
 - (2) Header (Expansion Tank) acts as a reservoir for both primary and secondary engine cooling systems. The cap is fitted with a relief valve to prevent damage to the system by overpressurization.
 - (3) Exhaust Manifold serves as a heat exchanger where coolant flowing through the exhaust manifold cools the exhaust gases from the engine.
 - (4) Thermostat operates as a heat sensitive valve, diverting coolant either to the keel cooler or to the primary water pump.
 - (5) Keel Cooler serves as a heat exchanger where coolant from the primary cooling system is circulated through the rear keel cooler and is cooled by raw water under the hull.
 - (6) Oil Cooler serves as a heat exchanger where oil from the engine is circulated through the oil cooler and is cooled by the coolant.
- b. Secondary Engine Cooling System. The port and starboard engines have their own separate secondary engine cooling systems. Coolant flows from the secondary water pump to the transmission oil cooler to the intercooler, and from the intercooler to the keel cooler. The coolant flows from the keel cooler back to the secondary water pump, picking up coolant as needed from the header.
- (1) Secondary Water Pump circulates the coolant through the secondary engine cooling system.
 - (2) Transmission Oil Cooler serves as a heat exchanger where fluid from the transmission is circulated through the transmission oil cooler and is cooled by coolant.
 - (3) Intercooler serves as a heat exchanger where coolant is used to cool engine intake air that has been heated by compression in the turbocharger.
 - (4) Keel Cooler serves as a heat exchanger where coolant from the secondary engine cooling system is circulated through the front keel cooler and is cooled by the water under the hull.
 - (5) Header (Expansion Tank) acts as a reservoir for both primary and secondary engine cooling systems. The cap is fitted with a relief valve to prevent damage to the system by overpressurization.




MK-2 PRIMARY ENGINE COOLING SYSTEM




MK-2 SECONDARY ENGINE COOLING SYSTEM

1-15. FUEL SYSTEM. Each engine has its own fuel system except that fuel is drawn from a common tank. The fuel systems are identical. The fuel flows from the tank through fuel water separators to the fuel lift pump mounted on the engine. The fuel is pumped through a fuel filter to the fuel injection pump and then to the injectors. From the fuel filter fuel also goes through a filter/reservoir to the thermostarter. Excess fuel from the fuel filter is returned to the tank. Excess fuel from the fuel injectors and the filter/reservoir is returned to the fuel tank through a collector.



- a. Fuel Tank is located on the centerline of the boat between the battery compartments and slightly forward of the engines. The tank is provided with a vent that vents fumes to the atmosphere and a filler cap for filling the tank. The filler cap has a dipstick for determining the exact amount of fuel in the tank. The tank is designed to prevent an explosion if the tank is penetrated by a bullet.
- b. Isolating Valve is located at the bottom of the tank and is used to isolate the fuel tank from both engines.
- c. Shutoff Valve is located near the top of the fuel tank and is used to isolate the engine from the fuel tank.
- d. Fuel Water Separator is located near the top of the fuel tank and is used to remove water and coarse particles from the fuel.
- e. Fuel Tank Vent is located next to the filler cap on the tank and extends over to the port side of the boat.
- f. Feed and Return Lines are the nylon tubing that connect the engines to the fuel tank. The feed line supplies fuel to the engine. The return lines return excess fuel back to the tank.
- g. Fuel Lift Pump is located on the right side of the engine near the rear mounting brackets. The fuel lift pump supplies fuel to the injection pump during start-up and operation.
- h. Fuel Filters are the double bowl arrangement above the fuel lift pump. These filters remove particles from the fuel that could dog the injection pump or the injectors.
- i. Injectors inject fuel into the engine cylinders.
- j. Filter/Reservoir is located on the left side of the engine near the intercooler and has a small screened knob on top.
- k. Thermostarter is located on the left side near the bottom of the air intake manifold. The thermostarter is used to heat the incoming air when the engine is started at temperatures below 50°F (10°C). The thermostarter operates by electrically igniting a small amount of fuel in the air intake manifold.
- l. Collector is located near the fuel lift pump and is a collecting point for excess fuel from the filter/reservoir and leak-off from the injectors.
- m. Injection Pump is located on the right forward side of the engine. It delivers an accurately measured quantity of diesel oil, under pressure, to the injector through which the fuel is injected into the engine cylinder.



1-16. AIR-EXHAUST SYSTEM. The port engine and the starboard engine have individual air-exhaust systems. The systems are identical except that the port engine discharges exhaust gases to port side and the starboard engine discharges exhaust gases to starboard side. Each port and starboard exhaust system is cooled by raw water from the hydrojet.


- a. Air Intake draws air for combustion from the engine compartment. The air intake contains filters that remove particles from the air that could cause engine damage.
- b. Turbocharger draws a large amount of air (approximately 360 cubic feet per minute) and supplies it to the intercooler where it is cooled before entering the intake manifold. The turbocharger is driven by exhaust gas expanding through a turbine wheel.
- c. Heat Shield encloses the turbocharger's turbine housing which operates at high temperature. The heat shield contains insulation, but may cause burns if touched during, or immediately after extensive operation of the engine.
- d. Exhaust Pipe carries the exhaust gases to the flexible connection and on to the exhaust port on the side of the boat at water level. The exhaust gases are cooled by raw water from the raw water cooling system. The raw water enters the exhaust pipe just after the point where gases leave the turbine housing.
- e. Flexible Connection is a short piece of bellows-type rubber tubing used to isolate the engine from the hull.

1-17. FIRE EXTINGUISHING SYSTEM

WARNING

Engine hatch covers must be closed to allow fire extinguishers to extinguish fire.
Death or personal injury could result from failure to observe precaution.

HAND-HELD EXTINGUISHER




1-18. ELECTRICAL SYSTEM. The boat electrical system is 24vdc. Two 12 volt batteries are connected in series. There are two sets of batteries for power. An alternator is fitted to each engine for charging the batteries. The circuits are arranged so that EITHER alternator can charge EITHER set of batteries automatically. Power is drawn from the batteries by two separate circuits. The batteries on the port side power the starter motor of both engines and the port engine instruments. The batteries on the starboard side power the starboard engine instruments and the auxiliary circuits.


- a. Searchlight can be located on either the top of the cab (as shown) or on the console when the cab is removed. The searchlight can be used as both a floodlight and spotlight.
- b. Horn is located under the console (MK1) or on the front of the forward cockpit (MK2). The horn may be sounded by pressing a button switch on the console.
- c. Wiper Motors are located on the inside of the cab above the windshield. The motor operates the windshield wipers in a back-and-forth motion.
- d. Engine Audible Alarms are located under the console. These alarms are activated by low engine oil pressure or high water temperature. They may be turned off by the engine alarm mute switches located on the control panel.
- e. Anchor Light is located on top of the mast and is to be lit when boat is anchored. The light is white.
- f. Towing Lights are to be lit when the boat has a load under tow. There are two towing lights. One towing light is a white light located on the forward side of the mast below the steaming light. The other towing light is a yellow light on the aft side of the mast just below the anchor light.
- g. Steaming Lights are located on the lower part of the mast and are to be lit when the boat is underway. Both lights are white.
- h. Navigation Lights are located on both sides of the mast. The starboard light is green and the port light is red.

NOTE



The anchor, towing, steaming and navigation lights are not intended for use under combat conditions. They are intended for use in waters subject to boat traffic.

- i. Electric Bilge Pumps are for pumping out water that has collected inside the hull. One pump is located in the engine compartment and one pump is located in the hydrojet compartment.
- j. Inspection Light is an extension light located in the engine compartment.
- k. Batteries are located in the battery compartment and supply the electrical power.
- l. Hour Meters are located in the battery compartment and record the number of hours the engines are operated.
- m. Emergency Link Solenoid is located in the battery compartment and is used to connect both pairs of batteries in parallel when additional power is required to start the engines.
- n. Slave Receptacle is located on the starboard side on the outside of the battery compartment. It is used when it is necessary to slave start the boat.
- o. Master Battery Switch is located next to the slave receptacle and turns ON and OFF all electrical power on the boat.
- p. Mast Receptacle and Mast Plug are located on the starboard side of the boat and supply power to the mast lights.





1-19. ENGINE BREATHING SYSTEM. Each engine is equipped with a breathing tube located on top of the rocker arm cover. A flexible tube from each engine goes to a central point (trap) where condensed vapors are collected. Non-condensed vapors are vented overboard on the starboard side.



CHAPTER 2

OPERATING INSTRUCTIONS

Section I. DESCRIPTION AND USE OF OPERATOR'S CONTROLS AND INDICATORS

NOTE



For instructions on launching and retrieving the Bridge Erection Boat refer to TM 5-2090-202-12&P.

CAUTION

The reverse position is used only to clean debris from the grille and is not to be used to control the boat.

2-1. The TRANSMISSION CONTROL is a dual lever action control located to the left of the steering wheel. The left lever controls the port transmission and the right lever controls the starboard transmission. Pushing the levers all the way forward engages the transmission to drive the hydrojet units so that water is ejected through the nozzles at the back of the boat. Putting the levers upright disengages the transmission. Pulling the levers all the way back engages the transmission to drive the hydrojet units but in a reverse direction so that water enters the nozzles and is ejected through the intake grilles at the bottom of the boat. The reverse position is used only to clean debris from the grille and is not to be used to control the boat. These levers should be placed in only three positions: all the way forward, all the way back, or in the center. There are stops at these positions.


2-2. The ENGINE THROTTLE CONTROL is a dual lever action control located to the right of the steering wheel. The left lever controls the port engine rpm and the right lever controls the starboard engine rpm. Pulling the levers all the way back puts the engines at idle speed. Pushing the levers forward increases the engine speed until maximum speed is reached when levers are all the way forward.



2-3. The SCOOP CONTROL is the large dual lever action control located to the right of the engine throttle control. The left lever controls the port scoop and the right lever controls the starboard scoop. Putting the levers in the center positions the scoops so that the thrust from the hydrojets is deflected downwards and the boat remains stationary. Pushing the levers forward raises the scoops. This increases the forward thrust and the boat moves forward. Pushing the levers all the way forward allows full forward thrust. Pulling the levers back lowers the scoops and the thrust from the hydrojets is / deflected forward and the boat moves backwards. Pulling the levers all the way back allows full backward thrust. The levers can be set at any position from full forward to full back. Levers can be operated independently of each other for effective steering at low engine rpm.

CAUTION

Scoop Control Levers should not be moved at high engine rpm. Linkage damage may result.




CAUTION



Care must be taken when loosening the adjustment knob, not to unscrew it. Disassembly of the steering wheel assembly may be required to get the knob back in position.

2-4. The STEERING WHEEL and SCOOP POSITION INDICATOR are located on the left side of the control panel. Turning the wheel to port (counterclockwise) tilts the nozzles and scoops to port and the boat turns to port. Turning the wheel to starboard (clockwise) tilts the nozzles and scoops to starboard and the boat turns to starboard. When the wheel is centered, the nozzles and scoops are centered and the boat goes straight ahead. The scoop position indicator is directly behind the hub of the steering wheel. The indicator has a centermark and a scale starting with 0 in the center. When the wheel is turned the scale moves under the centering mark. When the wheel is centered, 0 appears under the mark. The scale is used to determine the approximate position (port-center-starboard) of the scoops. Directly below the scoop position indicator is a steering damper adjustment knob. Tightening or loosening this knob adjusts a brake on the steering wheel shaft. This adjustment makes the steering wheel harder or easier to turn. The operator may choose the exact adjustment. Care must be taken when loosening the adjustment knob not to unscrew it. Disassembly of the steering wheel assembly may be required to get the knob back in position.


2-5. The ENGINE INSTRUMENT PANEL is located directly in front of the steering wheel and contains the following switches, gages, and lights necessary to start and monitor the engines:



- a. Engine Coolant Warning Lights (1 and 4) Glow orange when the temperature of the fresh water engine cooling system on the MK1 or the primary engine cooling system on the MK2 rises to an unacceptable level. Number 1 is connected to the port engine and number 4 is connected to the starboard engine.
- b. Coolant Temperature Gage (2 and 3) Indicates the temperature in degrees Fahrenheit and Celsius of the fresh water engine cooling system on the MK1 and of the primary engine cooling system on the MK2. Number 2 is connected to the port engine and number 3 to the starboard engine.
- c. Emergency Link Warning Light (5) Glows red when the emergency link switch on auxiliary switch panel no. 1 is turned on.
- d. Instrument Light Switch (6) A switch which controls the gage lights. Center position turns gage lights off. Down position turns gage lights on bright. Up position turns gage lights on dim.
- e. Bilge Water Warning Lights (7 and 8) Located above the instrument light switch. These lights glow green when accumulated water in the bilge reaches a level that requires pumping out. Number 7 indicates water level in the hydrojet compartment and number 8 indicates water level in the engine compartment.
- f. Low Fuel Warning Light (9) Glows red when there is 12 gallons (45 liters) or less fuel remaining in the fuel tank.
- g. Engine Low Oil Pressure Warning Light (10 and 13) Glows amber when the oil pressure in the engine is unacceptably low. Number 10 is connected to the port engine and number 13 is connected to the starboard engine.
- h. Engine Oil Pressure Gage (11 and 12) Indicates the oil pressure of the engine in pounds force per square inch (lb_f/in^2) and kilopascals per square centimeter (Kp/cm^2). Number 11 is connected to the port engine and number 12 is connected to the starboard engine.
- h. Alternator Warning Light (14 and 25) Glows red when the alternator on the engine is not working. Number 14 is connected to the starboard engine and number 25 is connected to the port engine.
- j. Battery Condition Meter (15 and 24) Indicates the state of charge in volts of the batteries. Number 15 is connected to the two batteries on the starboard side and number 24 is connected to the two batteries on the port side.
- k. Engine Circuit Switch (16 and 21) Turns on the engine circuits. Up position is OFF, down position is ON.
- l. Starter Switch (17 and 22) When pressed the switch activates the starting motor to start the engine. Switch functions as long as it is pressed. Number 21 is for the port engine and number 17 is for the starboard engine.
- m. Heat Switch (18 and 23) When pressed the switch activates the thermostat unit used for engine starting at temperatures below 50°F (10°C). Switch functions as long as it is pressed. Number 23 is for the port thermostat unit and number 18 is for the starboard thermostat unit.
- n. Tachometer (19 and 20) Indicates the speed of the engine crankshaft in rpm. Actual speed is scale reading times 100. Number 19 is for the starboard engine and number 20 is for the port engine.




2-6. The ENGINE STOP CONTROLS are the two T-handle controls located below the auxiliary switch panels. When pushed in the engines will run. When pulled out the engines will stop. The left control is for the port engine and the right control is for the starboard engine. Pulling the engine stop controls out stops the flow of fuel from the injection pump to the injectors.




2-7. SWITCH PANEL UNIT 1 Bank of twelve switches located to the right of the steering wheel. This panel incorporates miniature circuit breakers that control electrical services in the boat. The switches include a large button, a small button and a miniature light above the large button. The large button is pushed to turn on the electrical circuit. When the circuit is on, the miniature light is lit. The small button is pushed to turn off the circuit. When a circuit breaker is tripped, pushing the large button will reset the breaker.


- a. Cabin Lights. Not used in U.S. Army operations.
- b. Inspection Lights. Turns the inspection extension light located in the battery compartment ON and OFF.
- c. Anchor Light. Turns the anchor lights located on the mast ON and OFF.
- d. Towing Light. Turns the towing lights located on the mast ON and OFF.
- e. Navigation Light. Turns the navigation light ON and OFF.
- f. Auxiliary 1. Not used in U.S. Army operations.
- g. Wiper Port. Turns the port windshield wiper ON and OFF.
- h. Wiper Starboard. Turns the starboard windshield wiper ON and OFF.
- i. Emergency Link Connects both banks of batteries in parallel for starting each engine.
- j. Ranger. Not used in U.S. Army operations (dead switch).
- k. Searchlight. Turns the searchlight ON and OFF.
- l. Auxiliary 2. Not used in U.S. Army operations (dead switch).
- m. Engine Audible Alarm Mute Switch. Allows operator to turn off engine audible alarms that indicate low engine oil pressure or high water temperature.



2-8. SWITCH PANEL UNIT 2. Bank of six switches located to the left of the steering wheel. The switches are identified and control the following:



- a. Forward Bilge Pump. Turns on the forward bilge pump.
- b. Auto Control. Automatically turns on the forward bilge pump at predetermined float level, requiring the forward bilge pump to be pushed on.
- c. AFT Bilge Pump. Turns on the aft bilge pump.
- d. Auto Control. Automatically turns on the aft bilge pump at predetermined float level, requiring the aft bilge pump to be pushed on.
- e. Engine Room Blower. Not used in U. S. Army operations.
- f. Horn. Pressing the large button sounds the horn. As long as the button is depressed the horn will sound, releasing the button stops the horn.



Section II. PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)

General

1. To ensure that the bridge erection boat is ready for operation at all times, inspect it systematically for defects. Correct defects discovered during operation of the unit as soon as operation has ceased. Stop any operation which would damage the unit. Record deficiencies and corrective action taken on DA form 2404, Equipment Inspection and Maintenance Worksheet, at the earliest opportunity.
2. Before you operate. Always keep in mind the CAUTIONS and WARNINGS. Perform BEFORE (B) PMCS.
3. While you operate. Always keep in mind the CAUTIONS and WARNINGS. Perform DURING (D) PMCS.
4. After you operate. Be sure to perform AFTER (A) PMCS.
5. Weekly PMCS is for items whose condition should be checked on a regular basis to insure satisfactory condition or performance.
6. If your equipment fails to operate, perform authorized troubleshooting procedures. Report any deficiencies to unit maintenance using the proper forms. See DA PAM 738-750.
7. There are some items that need to be checked, but they are common in all parts of the boat and are not listed separately in the PMCS tables. They are listed here. Remember to check them all each time you do your PMCS.

WARNING

Dry cleaning solvent (P-D-680) vapor is harmful. Don't breathe in the fumes. Use plenty of ventilation. Avoid repeated contact with your skin.

A. Keep the boat dean: Dirt, grease, oil, and debris only get in the way and may cover up a serious problem. Clean as you work and as needed. Use dry cleaning solvent (P-D-680) on all metal deck surfaces. Use soap and water when you dean rubber or plastic material.

B. Bolts, nuts, and screws: Check them all visually for looseness, missing, bent, or broken condition. Look for chipped paint, bare metal, or rust around bolt heads. If you find one you think is loose, report it to unit maintenance.

C. Welds: Look for loose or chipped paint, rust, or gaps where parts are welded together. If you find a broken weld, report it to unit maintenance.

D. Electric wires and connectors: Look for cracked or broken insulation,

E. Hoses and fluid lines: Look for wear, damage, and leaks, and make sure clamps and fittings are tight. Wet spots show leaks and a stain around a fitting or connector can mean a leak. Report broken or leaking hoses or lines to unit maintenance.

F. Control cables and linkage: Look for frayed or broken cable. Look for bent or broken rods and loose connections. Report damaged or broken cables, bent or broken rods and loose connections to unit maintenance.

G. Hatches: When opening battery, engine, or hydrojet compartment, inspect the hatches for missing fasteners, hinges, stays. Report any missing or broken components to unit maintenance.

8. Purpose of inspection is to verify visually that all parts and items are in good condition and operational.

PMCS PROCEDURE

1. Every mission begins and ends with paperwork. There isn't much of it, but you have to keep it up to date. The forms and records you fill out have several uses. They are a permanent record of the services, repairs, and modifications made on your boat. They are reports to unit maintenance and to your commander. And they are a checklist for you when you want to know what is wrong with your boat after its last use, and whether those faults have been fixed. For information you need on forms and records, see DA PAM 738-750.

2. Comments under "Equipment is Not Ready/Available If" column of the PMCS table tell you when the boat should not be operated.

3. During your PMCS, if you run across a condition where the boat is operational, don't stop your PMCS. Complete all PMCS so that if any other conditions exist, they can be corrected at one time.
4. The PMCS table will tell you what corrections you can do. Do not attempt any other corrections. Conditions listed under "Equipment is Not Ready/Available If column should be reported to unit maintenance. See DA PAM 738-750 for form and records required to report these conditions.

Special Instructions

1. Leakage definitions for operator/crew PMCS are as follows:

Class I - Seepage of fluid (as indicated by wetness or discoloration) not great enough to form drops.

Class II - Leakage of fluid great enough to form drops but not great enough to cause drops to drip from item being checked/inspected.

Class III Leakage of fluid great enough to form drops that fall from the item being checked/inspected.



CAUTION

Equipment operation is allowable with minor leakages (Class I or II). Of course, consideration must be given to the fluid capacity on the item/system being checked/inspected. When in doubt notify your supervisor.

When operating with Class I or II leaks, continue to check fluid levels as required in your PMCS.

Class III leaks should be reported to your supervisor or organization. Boat should not be operated with Class III leaks.


2. When operating with Class I or Class II leaks, continue to check fluid levels as required in your PMCS. Check the leaks to see that they have not become Class III leaks.
3. Class III leaks should be reported to your supervisor or unit maintenance. Boat should not be operated with Class III leaks.



PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly





ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY / AVAILABLE IF
	B	D	A	W		
1	•		•		<u>Hull Surface (1)</u> . Check the hull for cracks, tears, holes, and cracked welds and leaks. Report damage to unit maintenance.	Hull surface has holes, cracks, tears, or cracked welds.
1.1	•		•		<u>Keel Coolers (MKP only) (1.1)</u> . Check keel coolers for plant growth and debris. Clean as required. Also check for punctures, corrosion, and other damage. Report any damage to unit maintenance.	Keel coolers are punctured or extremely corroded.
2	•		•		<u>Drains (2)</u> . <u>Vents (2.1)</u> and <u>Exhaust Ports (2.2)</u> . Check that drains, vents, and exhaust ports are not clogged. Clean as required. Report excessive damage to unit maintenance.	Drains, vents, or exhaust ports corroded or cracked.
3	•		•		<u>Pushknees (3)</u> . Check pushknees for missing or tom pads, broken welds, and missing or loose fasteners. Report damage to unit maintenance.	Pushknees cracked, broken welds, tom pads, or attaching hardware is missing.



PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly


ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY / AVAILABLE IF
	B	D	A	W		
4	•	•	•		<u>Scoop Controls (4)</u> . Operate scoop control levers all the way forward and back. Scoop controls should operate freely but not loosely and within full range. Scoops should move with controls. Report problems to unit maintenance.	Scoop control levers do not operate. Scoops do not move.
5	•	•	•		<u>Transmission (5)</u> . Operate transmission levers all the way forward and back. Levers should operate freely and through the full range. Report problems to unit maintenance.	Transmission control levers do not operate.
6	•	•			<u>Engine Throttle Controls (6)</u> . Operate engine throttle controls all the way forward and back. Levers should operate freely and within full range. Report problems to unit maintenance.	Engine throttle control levers do not operate, are hard to operate, or do not operate within full range. Levers damaged or broken.
7	•	•	•		<u>Steering Wheel (7)</u> . Turn steering wheel to full port and full starboard. Verify that scoops tilt as wheel is turned. Steering wheel should turn freely through the full range. Report problems to unit maintenance.	Steering wheel won't turn or is hard to turn. Scoops do not tilt.



PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly


ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY / AVAILABLE IF
	B	D	A	W		
8	•	•	•		<p>WARNING Engine must be off and transmission must be in neutral during operational check. Injury to personnel may result.</p> <p>WARNING When any hatch cover is open, be sure that it is secured in place. Injury to personnel may result.</p> <p><u>Hydrojet Grille.</u> Open hatch cover on hydrojet compartment and secure in place. Loosen hand nuts (8), remove cover (9). Check grille (10) for secure mounting, loose or damaged components and water passage for debris. Clean if required. Report problems to unit maintenance.</p>	Any debris cannot be removed by hand. Grille missing, loose, or damaged.
9	•				<p>NOTE Grease is not considered a contaminate in the forward bearing reservoir.</p> <p><u>Forward (11) and Aft (12) Grease Caps.</u> Grease the forward and aft bearings by turning each cap clockwise one-half turn for each 5 hours of operation. If the cap cannot be turned the full amount it should be removed and repacked with the correct grease (refer to LO 5-1940-277-1 2/LI 1940-12). Report problems to unit maintenance.</p>	Grease cap will not turn or any grease cap missing.
10	•				<p><u>Steering Control Shaft Grease Cap (13).</u> Grease control shaft by turning cap clockwise three-quarters to one turn. If the cap cannot be turned the full amount it should be removed and repacked with the correct grease (refer to LO 5-1940-277-12/LI 1940-12). Report problems to unit maintenance.</p>	Grease cap will not turn or any grease cap missing.



PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly


ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY / AVAILABLE IF
	B	D	A	W		
11	•				<p><u>Scoop Control Shaft Grease Cap (14)</u>. Grease scoop control shaft by turning cap dockwise three-quarters to one turn. If the cap cannot be turned the full amount, it should be removed and repacked with the correct grease (refer to LO 5-1940-277-12/LI 1940-12). Report problems to unit maintenance.</p>	Grease cap will not turn.
12	•	•			<p><u>Forward Bearing Oil Reservoir (15)</u>. Visually check that oil reservoir is at least half full and not contaminated. If not, fill with correct grade of oil (refer to LO 5-1940-277-12/L 1940-12). Report problems to unit maintenance.</p> <p style="text-align: center;">NOTE</p> <p>Grease is not considered a contaminate in the forward bearing reservoir.</p> <p style="text-align: center;">WARNING</p> <p>Keep fingers and head out of the way when closing hatch covers. Injury to personnel may result.</p> <p style="text-align: center;">CAUTION</p> <p>Ensure four drain holes are clear of foreign debris. Damage to equipment could result.</p>	Oil reservoir is less than half full or contaminated.
13	•	•		•	<p><u>Capstan (16) and Tow Hook (17)</u>. Check for presence of handle (17.1). Check that capstan (16) rotates freely. Check that drain holes are clear of foreign debris. Check that tow hook (17) moves freely. Oil pins (17.2) if sticking. Check that spring (17.3) is not rusted or weak. Check that lanyard (17.4) is not worn or frayed. Check that tow hook is not bent or cracked. Report problems to unit maintenance.</p>	Handle is missing or does not rotate capstan properly. Capstan does not rotate freely. Drain holes are not clear. Tow hook sticks, spring is rusted or weak lanyard is worn or frayed, or tow hook assembly is bent or cracked.



PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly


ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY / AVAILABLE IF
	B	D	A	W		
14	•			•	<p>WARNING</p> <p>When any hatch cover is open, be sure that it is secured. Injury to personnel may result.</p> <p><u>Batteries.</u> Turn master switch (18) ON by turning clockwise until it stops. Turn engine circuit switch (19) ON. Low oil pressure (20), alternator warning lights (21) and engine audible alarms (22) come on. Battery condition voltmeter (23) will indicate 25.4 vdc for fully charged battery. A reading below 24 vdc indicates a discharged battery. Check batteries for low electrolyte level, corrosion, and damage. Check battery cables for damage and loose connections. Report problems to unit maintenance.</p>	One or more batteries are damaged, corroded, or missing. Electrolyte level is low. Battery cables are damaged, loose, or missing.
15	•				<p><u>Engine Audible Alarm and Alarm Mute Switch.</u> Turn master switch (18) ON by turning clockwise until it stops. Turn engine circuit switch (19) ON. Engine audible alarm (22) should come on. Turn alarm mute switch (24) OFF. Audible alarm should go off.</p>	Engine audible alarm does not sound. Alarm mute switch does not turn off audible alarm.
16		•			<p><u>Hour Meters.</u> Be sure hour meters (25) are operational. Report broken meter to unit maintenance.</p> <p>WARNING</p> <p>Diesel fuel is flammable. Do not allow smoking or any open flame near the boat when you're refueling. Wipe up spilled fuel.</p>	Hour meters do not function.



PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly



ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY / AVAILABLE IF
	B	D	A	W		
16.1	•	•			<p style="text-align: center;">CAUTION</p> <p>Do not let fuel tank get any lower than 1/4 full.</p> <p style="text-align: center;">WARNING</p> <p>Engines must be shut down during fueling operations. Fire or explosion may result.</p> <p style="text-align: center;">CAUTION</p> <p>Do not drag hose and nozzle across fuel sediment bowl. Damage may result.</p> <p><u>Fuel Tank.</u> Check level in fuel tank (26) with dipstick (27). Add fuel to full mark on dipstick.</p>	Fuel tank is empty.
17	•				<p style="text-align: center;">CAUTION</p> <p>Gently lower engine hatch covers to avoid damaging glass tubes in fire extinguishers.</p> <p>Fire Extinguishers (28). Check that all three fire extinguishers are in place. Glass tube on engine extinguishers must not be broken. Check hand extinguishers according to instructions on extinguisher. Report problems to unit maintenance.</p>	Extinguishers missing or discharged.




PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly

ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY/ AVAILABLE IF:
	B	D	A	W		
18	•				<u>Engine Breather System</u> . Check engine breather trap (29) for presence of oil and water. If oil in trap, report to unit maintenance. If water in trap, drain as required.	If oil in trap, equipment is not ready.
19	•		•		<u>Fuel Water Separators (30)</u> . Check the fuel water separators for presence of in bottom of water separator. Report presence of water to unit maintenance.	If H ₂ O is in water bottom of separator, equipment is not ready.
20	•			•	<u>Drive Belts (31)</u> . Check condition of drive belts. Check belt tension midway between the alternator and water pump pulley. Report to Organizational Maintenance if free play is more than 1/8-inch, or broken, frayed, or missing.	Drive belt is loose, missing, damaged, or deteriorated.





PREVENTIVE MAINTENANCE CHECKS AND SERVICES



B - Before Operation D - During Operation A - After Operation W - Weekly


ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY/ AVAILABLE IF:
	B	D	A	W		
20.1			•		<u>Intake Strainer MK1</u> . Unclip retaining clamp (32), remove lid (33). Pull out strainer (34). Clean as required. Check O-rings (35) are not damaged.	Strainer is missing or damaged. Seals are missing- or damaged.
20.2			•		Drain Down Valve (36) MK1. Check if valve (36) is open. Handle (37) is parallel with pipe (38) when valve is open.	Raw water drain down valve open.

PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly


ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY/ AVAILABLE IF:
	B	D	A	W		
					<u>CAUTION</u>	
21	•				<p>Remove and replace dipsticks slowly, so they won't bend.</p> <p><u>Note:</u> The transmission dipstick is released by turning the T-handle counterclockwise and then pulling it from the filler tube. The dipstick is replaced by turning the T-handle clockwise until the dipstick is firmly in place and does not move under moderate pulling.</p> <p><u>Oil Level. Transmission.</u> Check oil level of the transmission. The dipstick (39) should show oil at or above the mark on a cold check. Add oil as required.</p>	Transmission oil level is low.
22	•				<p><u>Oil Level. Engine.</u> Check oil level of engine. The dipstick (40) should show enough oil for operation. Oil level at SAFE mark or above is OK on a cold check Add oil to full mark</p>	Engine oil level is low or dipstick is missing.








PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly

ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY/ AVAILABLE IF:
	B	D	A	W		
23	•				<p><u>Water Level, Fresh Water Cooling System(s)</u>. Remove header tank cap (41) and check that water level is approximately 1 inch below opening. If low, fill to correct level with coolant. Report problems to unit maintenance.</p> <p style="text-align: center;">NOTE</p> <p>Turn master battery switch ON for testing mast lights. The anchor, towing, steaming, and navigation lights are not intended for use during combat conditions.</p>	Water level is low.
24	•		•		<p><u>Mast Lights (42)</u>. Push the ON button for the various mast lights. Push the OFF button. If the lights don't come on or go off or the colors are wrong, report it to unit maintenance.</p> 	<p>Lights don't come on or go off. Colors are wrong.</p> <p style="text-align: center;">NOTE</p> <p>Lights will not be cause for "Not Ready" under combat conditions.</p>





HORN



PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly


ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY/ AVAILABLE IF:
	B	D	A	W		
25	•	•			<u>Horn (43)</u> . Press the large button and keep your finger on the button. The horn should continue to sound. Take your finger off the button and the horn should stop. If horn does not stop, turn off master switch and report it to unit maintenance.	
26				•	<u>Rub Rail (44)</u> . Check port and starboard rub rails for missing or tom sections. Report problems to unit maintenance.	



PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly





ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY/ AVAILABLE IF:
	B	D	A	W		
27					<ul style="list-style-type: none"> <u>Lifting Eyes (45)</u>. Check lifting eyes for tom or cracked welds and deformed or missing parts. Report problems to unit maintenance. 	
28					<ul style="list-style-type: none"> <u>Anchor and Line Assembly (46)</u>. Check anchor for missing or broken parts. Inspect line for frayed spots and breaks. Inspect shackles for worn pin. Inspect chain links for excessive wear or cracks. Replace as required. (Refer to page 3-20). 	
29	•	•			<ul style="list-style-type: none"> <u>Lines (47)</u>. Check lines for frayed spots and breaks. Replace lines as required. 	Lines are frayed, broken or missing.
30	•				<ul style="list-style-type: none"> <u>Bollards (48)</u>. Check bollards for cracked welds, sharp edges that could cut lines, and deformation. Report problems to unit maintenance. 	Bollards missing or have broken welds.
31	•				<ul style="list-style-type: none"> <u>Aft Cleats (49)</u>. Check for secure mounting to deck and broken parts. 	Aft cleats missing or have broken welds.
32	•				<ul style="list-style-type: none"> <u>Boat Hook (50)</u>. Check for cracked or broken handle and hook. Replace if broken or missing. 	
32.1					<ul style="list-style-type: none"> Boat Hook Holder (51). (MK-2) Check for cracked or broken hooks. Report problems to unit maintenance. 	



PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly


ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY/ AVAILABLE IF:
	B	D	A	W		
33					<p style="text-align: center;"><u>CAUTION</u></p> <p>When mast is in stowed position, do not sir or place weight on mast. Damage to equipment could result.</p> <p style="text-align: center;"><u>NOTE</u></p> <p>The anchor, towing steaming, and navigation lights are not intended for use under combat conditions. They are intended for use in waters subject to boat traffic or as mission requires.</p> <ul style="list-style-type: none"> • <u>Mast (52)</u>. Inspect mast for damage, i.e., broken welds and missing hardware. 	Mast damaged.



PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly

ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY/ AVAILABLE IF:
	B	D	A	W		
34					<p style="text-align: center;"><u>CAUTION</u></p> <p>Gently lower engine hatch compartment cover to avoid damaging glass tubes in fire extinguisher.</p> <ul style="list-style-type: none"> • <u>Hatches (53)</u>. Inspect all hatches and hinges for fit and damage. Check support braces and attaching hardware for damage. Report problems to unit maintenance. missing or damaged. 	<p>Hatches not functional. Braces and hardware</p>
35		•			<ul style="list-style-type: none"> • <u>Instrument Panel (54)</u>. Check for presence of all gauges. Inspect instrument panel for broken glass, physical damage and observe for functional operation. Check for damage to rubber boots and check switches for function. 	<p>Engine oil pressure or temperature gauge broken, missing, or not operating.</p>



PREVENTIVE MAINTENANCE CHECKS AND SERVICES

B - Before Operation D - During Operation A - After Operation W - Weekly

ITEM NO.	INTERVAL				ITEM TO BE INSPECTED PROCEDURE	EQUIPMENT IS NOT READY/ AVAILABLE IF:
	B	D	A	W		
36	•		•		<p><u>Bilge Drain Plug (55)</u>. Before launch install bilge drain plug (56) and tighten securely. Loosen bilge drain plug (56) and allow accumulated water to drain out after boat and cradle are on transporter. Inspect the plug itself for serviceability of threads, fit, etc. Report problems to unit maintenance.</p>	<p>Equipment not ready if plug is missing or damaged and if cradle NSN 2090-01-106-9789 is not ready/available in accordance with TM 5-2090-202-12&P.</p>
37			•		<p>Check all motor mounts, insure nuts are tight. Report problems to unit maintenance.</p>	<p>Equipment not ready if motor mount nuts are not tight.</p>

Section III. OPERATION UNDER USUAL CONDITIONS

2-9. STARTING ENGINES (NORMAL)

WARNING

It is critical for SAFETY purposes to keep the engine hatch covers closed when engines are running, except when engine maintenance is being performed.

CAUTION


The engines must not be operated out of the water nor operated in the water with the water jets disengaged for more than 20 minutes at idle speed. Ensure the engine temperature does not rise above 194°F. Serious engine damage could result if this caution is not observed.

Do not use the electric bilge pumps for longer than one minute unless the engines are running. Without the engines running, the bilge pumps will soon run down the batteries.


NOTE

On the MK2, the master battery switch is mounted inside the battery box. The battery box hatch must be opened to gain access to the master battery switch. Switch operating procedure is the same for MK1 and MK2.


a. Turn master battery switch (1) ON by turning handle (2) clockwise until it stops.




- b. Set the throttle controls (3) for half speed (approximately in the middle).



- c. Set the transmission control levers (4) in neutral position (center stop).




- d. Push engine stop controls (5) all the way in.



CAUTION

Do not start both engines at the same time as this will run down the batteries.


- e. Set engine circuit switches (6) ON. Engine audible alarm (7), generator warning light (8) and low oil pressure warning light (9) should come on. Voltmeter (10) should read 25 vdc or more. Turn engine alarm mute switch OFF (11) to stop audible alarm.



CAUTION

If engine fails to start after 30 seconds release switch and let starter motor cool for two minutes.

- f. Press start button (12) and hold in this position until engine starts (approximately 10 seconds).




NOTE

After engine starts, engine audible alarm will activate again when oil pressure reaches 20 lb/in² (1.5 Kp/cm²) pressure. Turn engine alarm mute switch OFF to stop audible alarm.

CAUTION

After engine starts, observe oil pressure gauge. If gauge does not register 20 lb/in² (1.5 Kp/cm²) pressure within 10 seconds shut down engine.

- g. After engine starts, take finger off the start switch (12).
h. Pull back on throttle control levers (3) until engine is idling smoothly (650-750 rpm as indicated on tachometer (13)).



- i. Start the other engine using the same procedure.
- j. After both engines have been started, move away from mooring as soon as possible. If you can, run the engines at 1800 to 2000 rpm under load until water temperature reads 140° -158°F (60°- 70°C) as shown on temperature gauges (14).

2-11. STARTING ENGINE (COLD TEMPERATURE)**WARNING**

It is critical for SAFETY purposes to keep the engine hatch covers closed when engines are running, except when engine maintenance is being performed.

CAUTION


The engines must not be operated out of water nor operated in the water with the water jets disengaged for more than 20 minutes at idle speed. Serious engine damage could result if this caution is not observed.

Do not use the electric bilge pumps for longer than one minute unless the engines are running. Without the engines running, the bilge pumps will soon run down the batteries.


NOTE

On the MK2, the master battery switch is mounted inside the battery box. The battery box hatch must be opened to gain access to the master battery switch. Switch operating procedure is the same for MK1 and MK2.


- a. Turn master battery switch (1) ON by turning handle (2) clockwise until it stops.




- b. Set the throttle controls (3) for half speed (approximately in the middle).



- c. Set the transmission control levers (4) in neutral position (center stop).




- d. Push engine stop controls (5) all the way in.




CAUTION

Do not start both engines at the same time as this will run down the batteries.

- e. Set engine circuit switches (6) ON. Engine audible alarm (7), generator warning light (8) and low oil pressure warning light (9) should come on. Voltmeter (10) should read 25 vdc or more. Turn engine alarm mute switch OFF (11) to stop audible alarm.



- f. Press heat switch (12) and hold for 20 seconds.



CAUTION

Do not start both engines at same time as this will run down the batteries.

CAUTION

If engine fails to start after 30 seconds release both switches and let starter motor cool for two minutes.

- g. While still pressing on heat switch (12) press start switch (13) and hold until engine starts (approximately 10 seconds). Then release start switch.


NOTE

After engine starts, engine audible alarm will activate again when oil pressure reaches 20 lb/in² (1.5 Kp/cm²) pressure. Turn engine alarm mute switch OFF to stop audible alarm.

CAUTION


After engine starts observe oil pressure gauge. If gauge does not register 20 lb/in² (1.5 Kp/cm²) pressure within 10 seconds shut down engine.

- h. After engine starts continue to press heat switch (12) until engine is running smoothly.
- i. After engine is running smoothly take finger off heat switch.
- j. Pull back on throttle control levers (3) until engine is idling smoothly (650- 750 rpm as indicated on tachometer (14)).



k. Start the other engine using the same procedure.

l. After both engines have been started, move away from mooring as soon as possible. If you can, run the engines at 1800 to 2000 rpm under load until water temperature reads 140°- 158°F (60° -70°C) as shown on temperature gauges (15).



2-12. STARTING ENGINE (AFTER 4 WEEKS OR MORE OF NOT BEING USED)

WARNING

It is critical for SAFETY purposes to keep the engine hatch covers dosed when engines are running, except when engine maintenance is being performed.

CAUTION


The MK1 engines must not be operated out of water nor operated in the water with the water jets disengaged for more than 20 minutes at idle speed. Serious engine damage could result if this caution is not observed.

Do not use the electric bilge pumps for longer than one minute unless the engines are running. Without the engines running, the bilge pumps will soon run down the batteries.


NOTE

On the MK2, the master battery switch is mounted inside the battery box. The battery box hatch must be opened to gain access to the master battery switch. Switch operating procedure is the same for MK1 and MK2.


- a. Turn master battery switch (1) ON by turning handle (2) clockwise until it stops.




- b. Set the throttle controls (3) for half speed (approximately in the middle).



- c. Set the transmission control levers (4) in neutral position (center stop).




- d. Pull engine stop controls (5) all the way out.




CAUTION

Do not start both engines at the same time as this will run down the batteries.


- e. Set engine circuit switches (6) ON. Engine audible alarm (7), generator warning light (8) and low oil pressure warning light (9) should come on. Voltmeter (10) should read 25 vdc or more. Turn engine alarm mute switch OFF (11) to stop audible alarm.



- f. Press start switch (12) and crank engine until oil pressure starts to register on the oil pressure gage (13) (approximately 10 seconds). Release start switch.




- g. Push in the engine stop controls (14).



CAUTION

Do not start both engines at the same time as this will run down the batteries.

- h. Press heat switch (15) and hold for at least 20 seconds.



CAUTION

If engine fails to start after 30 seconds release key switch and let starter motor cool for two minutes.

- i. While pressing heat switch (15) press start switch (12) and hold in this position until engine starts (approximately 10 seconds). Take finger off start switch (12).

NOTE


After engine starts, engine audible alarm will activate again when oil pressure reaches 20 lb/in² (1.5 Kp/cm²) pressure. Turn engine alarm mute switch OFF to stop audible alarm.

CAUTION

After engine starts observe oil pressure gage. If gage does not register 20 lb/in² (1.5 Kp/cm²) pressure within 10 seconds shut down engine.




- j. After engine starts continue to press heat switch (15) and hold in this position until engine is running smoothly.
k. After engine is running smoothly take finger off heat switch (15).

- I. Pull back on throttle control levers (3) until engine is idling smoothly (650 - 750 rpm as indicated on tachometers (14)).





- m. Start the other engine using same procedure.

- n. After both engines have been started, move away from mooring as soon as possible. If you can, run the engines at 1800 to 2000 rpm under load until water temperature reads 140° - 158°F (60° - 70°C) as shown on temperature gages (16).



2-12. FORWARD MOVEMENT

- a. Start engines (see page 2-42).
- b. Position scoop control levers (1) in neutral position (levers in the center or upright position).
- c. Cast off any mooring lines



WARNING

It is critical for **SAFETY** purposes to keep the engine hatch covers dosed when engines are running, except when engine maintenance is being performed.

CAUTION

When under way, the transmission control levers should not be touched. Transmission damage may result.

- f. Increase engine speed to 1000 rpm by moving both throttle control levers (5) slightly forward.
- g. Slowly push the scoop control levers (1) fully forward.
- h. To increase forward motion, increase engine speed by moving throttle control levers (5) forward.


NOTE

Any mismatch in engine speed or scoop control position will cause the boat to steer to the port or starboard direction when steering wheel (3) is centered.


- i. Adjust throttle control levers (5) until tachometers (6) for both engines read the same.

2-14. REVERSE MOVEMENT


- a. Start engines (see page 2-42).
- b. Position scoop control levers (1) in neutral position (levers in the center or upright position).
- c. Cast off any mooring lines.



- d. Position transmission control levers (2) in the forward position to start the hydrojets.



- e. Center steering wheel (3) ("0" on scoop position indicator (4)).



CAUTION


When under way, the transmission control levers should not be touched. Transmission damage may result..

- f. Increase engine speed to 1000 rpm by moving both throttle control levers (5) slightly forward.
- g. Slowly pull the scoop control levers (1) fully backward.
- h. To increase reverse motion, increase engine speed by moving throttle control levers (5) forward.

NOTE


Any mismatch in engine speed or scoop control position will cause the boat to steer to the port or starboard direction when steering wheel is centered.

- i. Adjust throttle control levers (5) until tachometers (6) for both engines read the same.




2-15. STEERING, USING STEERING WHEEL


- a. To make a starboard turn while going forward, turn the steering wheel clockwise.




- b. To make a port turn while going forward, turn the steering wheel counterclockwise.



c. To make a starboard turn while going backward, turn the steering wheel clockwise.



d. To make a port turn while going backward, turn the steering wheel counterclockwise.




2-16. STEERING, USING STEERING WHEEL AND SCOOP CONTROL


CAUTION

Do not attempt to make turns at high engine rpm using the scoop control.
Steering linkage damage could result


- a. To make a tight turn to starboard while going forward, turn the steering wheel (1) all the way clockwise and pull the starboard scoop control lever (2) all the way back. Leave port scoop control lever (3) in forward position.






- b. To make a tight turn to port while going forward, turn the steering wheel (1) all the way counterclockwise and pull the port scoop control lever (3) all the way back. Leave starboard scoop control lever (2) in forward position.




- c. To recover from a tight turn while going forward, reduce engine rpm and just before the turn is completed, put back scoop control levers (2 and 3) in forward position and put the steering wheel (1) at "0" on the scoop position indicator (4).




- d. To make a tight turn to starboard while going backward, turn the steering wheel (1) all the way clockwise and push the port scoop control lever (3) all the way forward. Leave the starboard scoop control lever (2) back.



- e. To make a tight turn to port while going backward, turn the steering wheel (1) all the way counterclockwise and push the starboard scoop control lever (2) all the way forward. Leave port scoop control lever (3) back



- f. To recover from a tight turn while going backward, reduce engine rpm and just before the turn is completed pull both scoop control levers (2 and 3) back and put the steering wheel (1) at "0" on the scoop position indicator (4).



NOTE

Using both steering wee and scoop controls, you can make the boat turn within its own length.

2-17. STEERING, USING SCOOP CONTROLS.

CAUTION

Do not attempt to make turns at high engine rpm using scoop control. Steering linkage damage could result.

NOTE

This method of steering is used at low (about 1000 rpm) engine rpm to make slow and fine adjustments to heading. Commonly called "inching into position".

- a. When moving slowly ahead a slight starboard turn can be made by moving starboard scoop control lever slightly back toward neutral position. Increasing the amount that the lever is moved back increases amount of turn.
- b. When moving slowly ahead a slight port turn can be made by moving port scoop control lever slightly back toward neutral position. Increasing the amount that the lever is moved back, increases amount of turn.
- c. When moving slowly backward a slight starboard turn can be made by moving the starboard scoop control lever slightly forward toward the neutral position. Moving lever further toward neutral increases amount of turn.
- d. When moving slowly astern a slight port turn can be made by moving the port scoop control lever slightly forward toward the neutral position. Moving lever further toward neutral increases amount of turn.

2-18. REDUCING SPEED

CAUTION

Do not reverse position of scoops at high engine rpm. Damage to scoop control linkage could result.


- a. To reduce speed slowly, reduce engine rpm and pull back on both scoop control levers.
- b. To reduce speed quickly, reduce engine rpm and pull back on both scoop control levers. After both scoop control levers have been pulled back, increase engine rpm.

2-19. STOPPING ENGINES.


CAUTION

The engine must be allowed to idle for at least one minute before it is shut off.
Damage to the turbocharger could result.


- a. Allow the engine to idle for at least one minute.
- b. Pull out stop control (1).




c. Turn engine circuit switch (2) OFF.



d. Turn battery master switch (3) to OFF by pulling out the handle (4) and turning counterclockwise until it stops.





2-20. CLEARING GRILLES (WATER JET INTAKE).

CAUTION

The following procedure is to be used only for clearing the hydrojet intake grilles. It is not to be used to maneuver the boat. Damage to hydrojets could occur.

- a. Decrease engine speed to 1000 rpm or less.
- b. Push scoop control levers (1) all the way forward.
- c. Pull transmission control levers (2) all the way back. Stop control levers at neutral position (3) for brief period.
- d. Increase engine speed (4) to high rpm for 2 to 3 seconds and then return engine speed to 1000 rpm or less.
- e. Push transmission control levers to neutral position (straight up) or all the way forward (5).

2-21. GETTING UNDER WAY FORWARD FROM BERTH.


CAUTION

Ropes and mooring lines can be sucked into hydrojets. Avoid running over ropes or lines.

NOTE

Use the following instructions if the portside of the boat is toward the berth. If the starboard side of the boat is toward the berth, the procedures are the same except the opposite controls are used.

- a. Start engines (see page 2-42).
- b. Position scoop control levers in neutral position (levers in center or upright position).
- c. Cast off all mooring lines.



- d. Push transmission control levers (1) all the way forward.
- e. Push port scoop control lever (2) all the way forward leaving the starboard scoop control lever (3) in neutral.
- f. Push the port throttle control lever (4) slowly forward leaving the starboard throttle control lever (5) at idle speed.
- g. When the boat is clear of the berth, push the starboard scoop control lever (6) and the starboard throttle control lever (7) forward until they are in the same position as the port control levers (2) (4).

2-22. GETTING UNDER WAY ASTERN FROM BERTH.

WARNING

It is critical for **SAFETY** purposes to keep the engine hatch covers closed when engines are running, except when engine maintenance is being performed.


CAUTION

Ropes and mooring lines can be sucked into hydrojets. Avoid running over ropes or lines.

NOTE

The following instructions are based on the assumption the boat has its port side toward the berth. If the boat has its starboard side toward the berth, the procedures are the same except the opposite controls are used.

- a. Start engines (see page 2-42).
- b. Position scoop control levers in neutral position (levers in center or upright position).
- c. Cast off all mooring lines.



- d. Push transmission control levers (1) all the way forward.
- e. Pull port scoop control lever (2) all the way back leaving the starboard scoop control lever (3) in neutral.
- f. Push the port throttle control lever (4) slowly forward leaving the starboard throttle control lever (5) at idle speed.
- g. When the boat is clear of the berth, pull the starboard scoop control lever (6) back and push the starboard throttle control lever (7) forward until they are in the same position as the port control levers.
- h. When ready to go forward, cut engine rpm to 750 - 800, push both scoop controls (8) forward and increase engine rpm to desired speed.

2-23. INSTRUCTIONS FOR BOAT OPERATOR AND CREW DURING LAUNCH AND RETRIEVAL.



WARNING

It is critical for **SAFETY** purposes to keep the engine hatch covers dosed when engines are running, except when engine maintenance is being performed.


CAUTION

Prior to launch the bilge plug must be installed. Water will enter boat and cause damage. If the MK-2 boat audible alarm sounds during a controlled launch, shut engine down immediately. Engine oil may flow aft, leaving oil pump pick-up exposed, resulting in complete loss of engine oil pressure. Restart MK-2 engine after boat stern is floating but before disconnecting cable from lifting point shackles.

- a. Controlled launch (0 - 5 feet per second).
 - (1) Operator and crew will help prepare the boat for launch by:
 - (a) Releasing the tie downs (1) from cab (2).
 - (b) Positioning cab (2) over forward compartment using lifting handles (3).
 - (c) Aligning and closing cab damp fasteners (4).
 - (d) Connecting windshield wiper electrical plug (5) to receptacle at center of control panel.



- (e) Removing six tiedowns (6) and placing them on transporter walkway.
- (f) Removing down stream aft stanchion (7) by pulling retaining pin (8) out and lifting stanchion out of socket. Placing stanchion on transporter walkway and reinstalling retaining pin.



(2) When cradle is lowered and boat stem is floating operator will:

- (a) Start engine (refer to page 2-42).
- (b) Place transmission in forward (refer to page 2-1).

CAUTION

Do not apply too much power and overrun saddle. Cables will retension and cannot be released. Also damage to boat or cradle could result.

NOTE

Under some wind and current conditions turning wheel to one side or the other while powering ahead will provide additional slack in cable to ease its release.

- (c) Advance throttles slightly to cause boat to advance just enough to slacken restraining cables (9).

(3) The crew will:

- (a) Disconnect the cable hooks from the lifting point shackles when cable tension is released.
- (b) Place cable hooks in forward stanchion eyes (10).

(4) The boat operator will:

- (a) Place scoops in reverse position and back boat out of cradle.


CAUTION

Insure cable is on inside of rear stanchions to prevent damage to forward stanchions.

- (b) Raise mast to upright position and pin in place, ensure the electrical connector is properly connected.

WARNING

It is critical for SAFETY purposes to keep the engine hatch covers closed when engines are running, except when engine maintenance is being performed.



b. Free launch (above 5 feet per second).

(1) Operator and crew will help prepare the boat for launch by:

- (a) Install cab (refer to page 2-81).
- (b) Removing six tiedowns (6) and placing them on the transporter walkways.
- (c) Removing two aft stanchions (7) by pulling the retaining pins (8) and lifting stanchions out of sockets.
- (d) Placing stanchions on transporter walkways and replacing retaining pins.
- (e) Removing shackle from cradle lifting point (11) and installing in the 1-3/8 inch hole in keel towing place (12).
- (f) Removing dolly cable guide (latch book) (13) by pulling the pin retainer then removing pin and block.
- (g) Disconnecting winch connection from cradle dolly and connecting to shackle in boat keel.

NOTE


The transporter operator will take a series of actions to position the transporter and boat before next step.

- (h) When transporter operator gives the signal, the boat operator and crew will remove the shackle pins (14) from the retaining cable shackles (15).
- (i) Shackles will be removed from cable hooks and reinstalled to lifting points.
- (j) Restraining cable hooks will be hung from stanchion eyes (10).

NOTE

Prior to launch, the transporter will disconnect the winch cable from the shackle on boat keel, put shackle back on cradle lifting point and position winch cable on truck cab to prevent snagging on launch.

- (k) Start engine as soon as boat enters water (MK1) (refer to page 2-42).
- (l) Raise mast to upright position and pin in place, ensure the electrical connector is properly connected.



c. Boat retrieval.

- (1) During retrieval the following action will be taken:
 - (a) Remove pin (16) and lower and secure mast (16.1).
 - (b) Boat operator will guide the boat into saddle (16.2) and push saddle forward keeping boat straight.
 - (c) Crew will remove cable hooks (17) from stanchion eyes (10) and hook them to shackles (15) at forward boat lift points (one each side of boat).
 - (d) When restraining cables (9) are hooked up, the boat operator will tension the cables by using scoops in the astern position at idle engine speed.

CAUTION

Do not operate engines with boat out of water. Damage to raw water pump and engine will result. (MK1 only).

- (e) As retrieval starts, the boat operator will hold boat centered in the cradle by using engine power and steering controls.
- (f) Boat operator will shut down engines as boat dears water.

CAUTION

Scoop control levers must be fully forward or damage to scoops or cradle may result.

- (g) After boat is secured on transporter disconnect windshield wiper electrical plug (5) from receptacle at center of control panel.
- (h) Release six cab clamp fasteners (4) which secure cab to deck.
- (i) Using four cab lifting handles (3) lift cab to clear engine, transmission and scoop controls. Remove cab from boat.
- (J) Place cab in forward compartment.
- (k) Tie cab from forward handrail (18) to port tiedown eye (19) and starboard tiedown eye (20).
- (l) Tie cab from rear handrail (21) to rear tiedown eye (22).

NOTE

Upon retrieval, the bilge plug should be removed to drain water from boat.

2-24. COMING INTO BERTH.

CAUTION

Ropes and mooring lines can be sucked into hydrojets. Avoid running over ropes or lines.

NOTE

Use following instructions if port side berthing is planned. For starboard side use opposite controls.

- a. Approach berth against current at slight angle to berth.
- b. Decrease engine speed to about 1,000 rpm.
- c. Pull scoop control levers back toward neutral until boat is moving ahead slowly.
- d. Assistant boat operator stands by side of cab holding onto safety rail on top of cab. If cab removed, assistant operator kneels at side of cockpit holding onto safety rail inside cockpit area e. Move starboard scoop control lever ahead slightly to swing bow to port.
- f. Move both scoop controls toward neutral until boat is moving ahead very slowly.
- g. When bow touches move scoop controls to neutral.
- h. Assistant boat operator secures line to appropriate tie-up on berth and to bow bollard on berth side of boat.
- i. Reduce engine rpm to 750 800.
- j. Turn steering wheel to starboard to swing stem of boat against berth.
- k. Secure line to appropriate tie-up on berth and to stem bollard on berth side of boat.
- l. Put transmission control in neutral.
- m. Stop engines (refer to page 2-75).

CAUTION

Do not beach boat on rock shores. Damage to keel and keel cooler may result.

2-25. BERTHING THE BOAT. A ramp bay connected to an interior bay may be used for berthing when a boat dock is unavailable; proceed as follows:

- a. Launch ramp and interior bays (TM 5-5420-209-12).
- b. Connect bays (TM 5-5420-209-12).
- c. Anchor connected bays to shore (TM 5-5420-209-12).

CAUTION

Do not operate boat in water less than 26 inches deep. Damage to keel and keel cooler may result

- d. Follow procedures in para. 2-24 when approaching dock.
- e. Retrieve bays when dock is no longer needed (TM 5-5420-209-12).

RIBBON BRIDGE RATING CHART

Rating	Velocity (ft/sec)							
	0-3	4	5	6	7	8	9	10
NORMAL								
(Track Wheel)	<u>75</u> 96	<u>75</u> 96	<u>70</u> 96	<u>70</u> 96	<u>70</u> 82	<u>60</u> 65	<u>45</u> 45	<u>30</u> 30
CAUTION								
(Track Wheel)	<u>85</u> 105	<u>85</u> 105	<u>80</u> 100	<u>80</u> 100	<u>80</u> 96	<u>65</u> 75	<u>50</u> 50	<u>35</u> 35
RISK								
(Track Wheel)	<u>100</u> 110	<u>95</u> 110	<u>90</u> 105	<u>90</u> 105	<u>90</u> 100	<u>75</u> 82	<u>65</u> 65	<u>40</u> 40

NOTES

1. These ratings apply for a bridge held in place with bridge erection boats. In currents up to 6 ft/sec, one boat is required per six bays. In 8 ft/sec, one boat is required every three bays. In 9 ft/sec,, one boat is required every two bays. In currents above 9 ft/sec, or if the bridge is to remain in place for long periods of time, bridle lines should be used (150° vertical angle).

2. Vehicle spacing criteria:

Rating

Normal 100 feet (Front-To-Back)

Caution 150 feet (Front-To-Back)

Risk One vehicle only on bridge

3. Maximum Speeds for Normal Crossings:

On Ramps Class 0 to Class 40 -15 mph

Over Class 40 5 mph

On Bridge Class 0 to Class 40 25 mph

Over Class 40 15 mph

2-26. RETRIEVING A FREE LAUNCHED RIBBON BRIDGE BAY (PUSHER TECHNIQUE).

NOTE

The Bridge transporter operator is responsible for launching Ribbon Bridge Ramp and Interior Bays. (Refer to TM 5-5420-209-12)

NOTE

Retrieving a free launched Ribbon Bay requires at least one boat operator and two assistant boat operators per boat.

- a. Boat operator. Position the boat 3 to 5 meters downstream from the Ribbon Bay launching site with the boat facing upstream.

WARNING

Do not allow the bay to open up on top of the bow of the boat. Personnel may be thrown into the water. Severe damage to boat could result.

WARNING

Hold on to safety rail. You could be thrown overboard when the boat bumps the bay.

- b. Boat operator. After the bay is completely open, maneuver the boat until the pushknees are in contact with the downstream side of the bay.

WARNING

Do not get any part of body between bay and boat. Injury to personnel could result.

- c. Assistant boat operators. Stand on side of cab, holding onto safety rail on cab top until the pushknees touch the Ribbon Bay. Stand well aft of the operator's forward field of vision. If cab is removed, assistant operators will kneel at side of cockpit and hold onto safety rails inside cockpit area until pushknees touch Ribbon Bay.

WARNING


Minimize boat maneuvering against bay until all roadway connectors are in place. Personnel injury could result.

- d. Boat operator. Keep the pushknees of the boat in constant contact with the Ribbon bay. Use enough power to prevent the bay from pushing the boat downstream or into shallow water.

WARNING

Make sure that each tieline is tight and the bay is held firmly against the pushknees or the bay will tend to pull off to the side of the boat.

- e. Assistant boat operators. Secure one tieline to each of the anchoring pins on the downstream side of the bow ponton of the Ribbon Bay. Pull each tieline tight and secure it to the bow bollard on its respective side of the boat.



WARNING

Minimize boat maneuvering against bay until all roadway connectors are in place. Personnel injury could result.

WARNING

Do not step, kneel, or lay down over the joint between roadway pontons.

- f. Assistant boat operators. Secure all roadway to roadway ponton connectors and roadway ponton to bow ponton connectors. Rotate travel latches down. Raise the hand rails. (Refer to TM 5-5420-209-12.)
- g. Boat operator. Maneuver bay into position for raft or bridge construction.
- h. Assistant boat operators. Stand by to assist in raft or bridge construction.

2-27. RECOVERY OF RIBBON BRIDGE BAY (PUSHER TECHNIQUE).

NOTE

Recovery of a Ribbon Bay requires at least one boat operator and two assistant boat operators per boat.

CAUTION

Be sure to keep the boat downstream of the bay during recovery operations. Ribbon Bay may drift downstream.

- a. Boat operator. Maneuver the boat until the pushknees are in contact with the downstream side of the bay.

WARNING

Hold on to safety rails. You could be thrown overboard when the boat bumps the bay.

WARNING

Do not get any part of body between bay and boat. Personnel injury could result.

- b. Assistant boat operators. Stand on side of cab holding onto safety rail on top of cab until pushknees contact the Ribbon Bay. If cab is removed assistant operators will kneel at side of cockpit and hold onto safety rails inside of cockpit area until pushknees touch Ribbon Bay.
- c. Boat operator. Keep the pushknees of the boat in constant contact with the Ribbon Bay.

CAUTION


Make sure that each tieline is tight and the bay is held firmly against the pushknees or the bay will tend to pull off to the side of the boat.

- d. Assistant boat operators. Secure one tieline to each of the anchoring pins on the downstream bow ponton of the Ribbon Bay. Pull each tieline tight and secure it to the bow bollard on its respective side of the boat.

WARNING

Do not step, kneel, or lay down on the joint between roadway pontoons.

- e. Boat operator. Maneuver the Ribbon Bay to recovery site. Place the Ribbon Bay close enough to the transporter so that the assistant boat operator can hook the winch cable hook onto the bay lifting eye. The centerline of the bay should be in line with the transporter.
- f. Assistant boat operators. Lower hand rails. Rotate travel latches down. Rotate all fold lock latches up. Open all roadway to bow ponton latches. Rotate both roadway to roadway connectors.
- g. Assistant boat operators. Hook the winch cable hook to the bay lifting eye with the open end of the hook facing the bay. Remove the tielines from the bay and stow them on the boat. Remain on boat.
- h. Boat operator. Maneuver the boat to the rear downstream bow ponton and push on the ponton as required to keep the bay in line with the transporter.



2-28. ANCHORING A RIBBON BRIDGE .

NOTE

Anchoring a Ribbon Bridge will require one boat for each 3 bays of bridge and not less than one boat operator and two assistant boat operators per boat.

- a. Boat operator. Maneuver the boat into position until the pushknees are in contact with the downstream bow ponton of the bridge.

NOTE

When more than one boat is required, boats should be evenly spaced along the bridge.

WARNING

Hold on to safety rails. You could be thrown overboard when the boat bumps the bay.

- b. Assistant boat operators. Wait on or near the bow of the boat without blocking the boat operator's view until the pushknees touch the bridge.
- c. Boat operator. Keep the pushknees of the boat in constant contact with the bridge.


WARNING

Do not get any part of body between bay and boat. Injury to personnel could result.

WARNING

Make sure that each tieline is tight and the bay is held firmly against the pushknees or the bridge will tend to pull off to the side of the boat.

- d. Assistant boat operators. Secure one tieline to the nearest bow ponton anchoring pin on the bridge to port and starboard of the boat. Pull each tieline tight and secure it to the bow bollard on its respective side of the boat.
- e. Boat operator. Maintain bridge on centerline by adjusting the scoop controls and throttles. Follow directions of the bridge commander.



2-29. RAFTING ASSEMBLY.

CAUTION

Rafting in debris-laden streams is extremely dangerous because floating logs, trees, brush, and ice may puncture and sink pontoons and boats and foul boat hydrojet intakes and jets.

NOTE

Not less than two boats are required for rafting. Each boat will require one boat operator and at least two assistant boat operators.

- a. Boat operator. After launched bay has been retrieved in accordance with retrieving operations (see page 2-88) maneuver the Ribbon Bay into position on the raft centerline and within boat hook length of the bay to be connected to. Maintain bay on raft centerline until assistant boat operators have secured bay to bay/bays on centerline.

LONGITUDINAL RAFT RATING CHART

Raft Size	Raft Velocity (ft/sec)							
	0-3	4	5	6	7	8	9	10
3-bay	45	45	45	40	40	35	30	25
4-bay	70	70	70	60	60	60	55	45
5-bay	75	75	75	70	70	70	60	60
6-bay	80	80	80	70	70	70	70	70
(Track Wheel)	96	96	96	96	96	96	70	70


NOTES:

Table shows load (MLC) capacity based on one vehicle positioned on the raft centerline and centered on the deck. The values shown for 3-14-15-bay rafts apply for wheeled or tracked vehicles. The values shown for a 6-bay raft apply for track/wheel vehicles as shown.

Two bridge erection boats are required for propulsion with any raft in the table.


This configuration is to be used only where current velocities in loading and unloading areas are 5 fps or less.

Ratings apply only with bottom of ramp ends raised 1 foot clear of water. Ramps raised for loading must be lowered before raft is underway.




2 30. RAFTING-LONGITUDINAL METHOD .

- a. Assistant boat operators. Secure rafting brackets in the two anchoring pin slots closest to the center of the raft on each side of the assembled raft.




- b. Boat operator (downstream boat) Position bow against outboard interior bay and hold raft perpendicular to river current.



- c. Boat operator (upstream boat). Ease boat against upstream bow ponton rafting brackets so that the bow is facing away from the bank.
- d. Assistant boat operators (upstream boat). Secure bow line to the anchor pin farthest from the bow of the boat on the interior bay next to the ramp bay. Tighten the bow line and secure it to the bow bollard on the same side of the boat as the raft. (Use 3/4-inch line.)
- e. Boat operator (upstream boat). When line is secured, put all controls in neutral.
- f. Assistant boat operators (upstream boat). Secure stem line to the bridge anchor pin farthest from the stern of the boat on the interior bay next to the ramp bay. Pull the stern line tight and wrap it twice around the capstan. Crank the capstan until all slack is out of the stern and bow lines. Secure free end of the stem line to the stem bollard on the opposite side of the boat from the raft. (Use 3/4-inch line.) 2-98

- g. Boat operator (upstream boat). When the bow and stern lines are tight, place both scoop control levers in reverse to hold the raft against the bank



- h. Boat operator (downstream boat). When the upstream boat is secured in place and holding the raft against the bank, pivot the boat against the downstream rafting brackets so that the bow is facing away from the bank.
- i. Assistant boat operators (downstream boat). Secure bow line to the bridge anchor pin farthest from the bow of the boat on the interior bay next to the ramp bay. Tighten the bow line and secure it to the bow bollard on the same side of the boat as the raft.
- j. Boat operator (downstream boat). When the bow line is secured, put the downstream scoop control lever in reverse to pull the bow line tight.
- k. Assistant boat operators (downstream boat). Secure stern line to the bridge anchor pin farthest from the stem of the boat on the interior bay next to the ramp bay. Pull the stern line tight and wrap it twice around the capstan. Crank the capstan until all slack is out of the stem and bow lines. Secure free end of the stern line to the stem bollard on the opposite side of the boat from the raft.
- l. Boat operator (downstream boat). When the bow and stem lines are tight, place both scoop control levers in forward, turn helm into the current and idle to help hold the raft against the bank m. Assistant boat operators (both boats). Operate ramp pumps and approach ramps. Secure and cast off approach guys. Check traffic. Check and tighten bow and stem lines as needed.
- n. Boat operators (both boats). Maneuver boats in accordance with signals from raft commander.

CAUTION

Always position scoop control levers so that boats push raft against the shore during loading and off loading of traffic. Bridge or equipment damage could result.

Always secure raft to bank with approach guys during loading and off loading of traffic. Raft could be pushed away from shore causing vehicle loading/off loading to dump into water.

NOTE

Rafts operating in a river crossing with more than one raft using same loading and unloading sites will follow a figure eight traffic pattern.

CONVENTIONAL RAFT RATING CHART


Raft Size	Raft Velocity (ft/sec)							
	0-3	4	5	6	7	8	9	10
3-bay	45	45	35	25	15	10	0	0
4bay	60	60	60	55	40	30	15	0
5-bay	75	70	70	70	60	50	25	0
6-bay (Trade	75	70	70	70	70	55	30	0
Wheel)	96	96	96	70	70	55	30	0

NOTES

Table shows load (MLC) capacity based on one vehicle positioned on the raft centerline and centered on the deck. The values shown for 3-/4/5-bay rafts apply for wheeled or tracked vehicles. The values shown for a 6-bay raft apply for track/wheel vehicles as shown.

Ratings apply only with bottom of ramp ends just clear of water. Ramps raised for loading must be lowered before raft is underway.

Raft commander must observe leading edge of raft and decrease speed or halt operations as necessary if water coming over bow exceeds 1 inch.




CONVENTIONAL RAFTING

General raft attitudes to the river current and maneuvers in using the conventional method of rafting.

2-31. RAFTING CONVENTIONAL METHOD.

- a. Boat operator (both boats). Position boats on downstream side of raft centered on interior bays next to ramp bays.
- b. Assistant boat operators (both boats). Secure steering lines between anchor pins on bay and bollards at stern of boat. Steering lines can be tightened up by using the capstan to tension one of the lines. Secure bow lines between cleats on bay and bow bollards on boat. (Use 1 -inch manila line for steering lines.)



- c. Assistant boat operators (both boats). Operate ramp pumps and approach ramps. Secure and cast off approach guys. Check traffic. Check and tighten bow and steering lines as needed.
- d. Boat operators (both boats). Maneuver boats in accordance with signals from raft commander.

CAUTION

Always position controls so that boats push raft against the shore during loading and off-loading of traffic. Bridge or equipment damage could result.

Always secure raft to bank with approach guys during loading and off-loading of traffic. Raft could be pushed away from shore causing vehicle loading/off loading to dump into water.

NOTE

Rafts operating in a river crossing with more than one raft using the same loading and unloading sites will follow a figure eight traffic pattern.

Section IV. OPERATION UNDER UNUSUAL CONDITIONS

2-32. OPERATION WITH ONE ENGINE

WARNING

It is critical for SAFETY purposes to keep the engine hatch covers dosed when engines are running except when engine maintenance is being performed.

CAUTION

Exceeding 2000 rpm with one engine running makes the boat difficult to maneuver.

There may be times when you will be required to operate the boat with only one engine running. If this should happen, do not operate the running engine over 2000 rpm. Adjustments will have to be made in your steering procedures to allow for the tendency of the boat to turn. Upon completion of your task or mission, head for shore and immediately report your problem to organizational maintenance.

2-33. OPERATION IN EXTREME COLD.

WARNING

It is critical for SAFETY purposes to keep the engine hatch covers dosed when engines are running, except when engine maintenance is being performed.

- a. Inspect hull frequently for ice damage.

CAUTION

Do not run the engines in neutral to charge the batteries as it could cause valves to stick.

- b. Check bilge pumps frequently to see that pumps and outlets are free of ice. If necessary, use hot air or hot water to thaw the pumps.
- c. Operate scoop controls and steering wheel frequently.

2-34. OPERATION IN EXTREME HEAT.

- a. Keep engine coolant at recommended level.
- b. Do not fill the fuel tank above full mark on dipstick Allow room for expansion of fuel.
- c. Increase battery PMCS. Distilled water or a good grade drinking water (excluding mineral waters) may be used to bring electrolytes to proper levels.

2-35. OPERATION IN SALT WATER.

- a. Always keep hatch covers closed.
- b. If available, wash down engines and engine accessories with fresh water. Wipe dry the exteriors of engines and engine accessories after each operation.
- c. Keep engine and hydrojet compartments as dry as possible.
- d. Check hull frequently for signs of corrosion. Corrosion is likely to occur at exhaust, vent, and drain openings, and areas subject to wear. Signs of corrosion and bare spots on painted surfaces should be taken care of as soon as possible.
- e. Frequently inspect the lights, bilge pumps, fire extinguishers, electrical connections, and lines for signs of corrosion or salt accumulator. Wipe items frequently.

CHAPTER 3

MAINTENANCE INSTRUCTIONS

Section I. LUBRICATION INSTRUCTIONS

For safer, more trouble-free operation, see to it that your boat is serviced when it needs it. For the proper lubricant and service intervals, see LO 5-1940-277-12.

Section II. TROUBLESHOOTING PROCEDURES

The table lists the common malfunctions which you may find during the operation or maintenance of the boat or its components. You should perform the tests/inspections and corrective actions in the order listed.

This manual cannot list all malfunctions that may occur, nor all tests or inspections and corrective actions. If a malfunction is not listed or if one listed is not corrected by the given corrective actions, notify your supervisor.





Table 3-1. Troubleshooting

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
1. ENGINE FAILS TO START, STARTS WITH DIFFICULTY AND RUNS BADLY.		
	Step 1. Check to see if there is fuel in the fuel tank (see page 2-23).	Add fuel.
	Step 2. Check to see that fuel valves (1) are open.	Open valves by turning counterclockwise
	Step 3. Check to see if there is water in fuel water separators (see page 2-25).	Notify unit maintenance.
	Step 4. Check to see if fuel system is functioning normally by holding one of the injector tubes between thumb and forefinger and feeling for a pulsing when engine is turned over by starter.	Notify unit maintenance.
	Step 5. Check to see if reading on battery condition meter (2) is 24.0 vdc or less when engine circuit switch is turned to ON.	Notify unit maintenance.
	Step 6. Check to see if reading on battery condition meter (2) is more than 24.0 vdc but less than 25.4 vdc.	Use emergency link Press emergency link switch (3) to parallel batteries. Restart engines. Release emergency link switch (3).
	Step 7. Check to see if thermostarter (4) is working by holding the hexagon portion of the unit and feeling for a warming when heat switch is pressed.	Notify unit maintenance.







Table 3-1. Troubleshooting

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
2. SUDDEN LOSS OF POWER (NO BLACK SMOKE).		
	Step 1. Check to see if engine stop control (1) is pushed all the way in. Push in control.	
	Step 2. Check to see if fuel system is functioning normally by holding one of the injector tubes (2) between thumb and forefinger and feeling for a pulsing. Notify unit maintenance.	
	Step 3. Check fuel water separators for water in fuel (see page 2-25). Notify unit maintenance.	
3. SUDDEN LOSS OF POWER (HEAVY BLACK SMOKE).		
	Step 1. Look to see if air inlet (3) is blocked. Notify unit maintenance.	





Table 3-1. Troubleshooting

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

4. OVERHEATING (ENGINE AUDIBLE ALARMS WILL COME ON) (ENGINE COOLANT WARNING LIGHT COMES ON).

- Step 1. Turn OFF engine by pulling out the engine stop control (1) for affected engine.
- Step 2. Turn OFF alarm mute switch (4) for effective engine to stop audible alarm.
- Step 3. Check intake strainer on Turn for effective engine (see PMCS, item 22).

WARNING

If cooling system is hot, open coolant hirer cap slowly until all pressure is gone. Do not touch the cap with your bare hand. Never take off cap while engine is overheated. Allow it to cool down first

- Step 4. Remove filler cap (5) for affected engine by turning clockwise. Check to see that water level is not more then 1 inch below bottom of neck (6).
Add coolant.
- Step 5. Check belt tension for affected engine (see page 3-18).
- Step 6. Check for leaks around hose connections and water pumps for effective engine.
Notify unit maintenance.
- Step 7. Check keel coolers on MK2 (see PMCS, item 1.1).

5. CHARGE WARNING LIGHT (7) COMES ON (NORMAL OPERATION).

- Step 1. Check appropriate instrument panel voltmeter (8) for reading at alternator output. If output reading is 24 vdc or above the warning light is malfunctioning. If reading is 0 vdc or slightly above the alternator or voltage regulator is malfunctioning.
Mission may be completed. unit maintenance must be notified of problem.




Table 3-1. Troubleshooting

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

6. LOW OIL PRESSURE (ENGINE AUDIBLE ALARMS WILL COME ON) (OIL WARNING LIGHT COMES ON) (NORMAL OPERATION)

- Step 1. Turn OFF alarm mute switch (1) to turn off audible alarm.
- Step 2. Check oil pressure gage (2) for pressure reading of 20 psi (1.5 kp/cm²) or above.
If not, reduce engine speed to idle (650 750 rpm) for one minute and stop engine (see page 2-75).
- Step 3. Check engine oil level (see page 2-28).
Fill to proper level (see page 2-28).
- Step 4. Notify unit maintenance.




Table 3-1. Troubleshooting - Continued

MALFUNCTION
TEST OR INSPECTION
CORRECTIVE ACTION

7. ENGINE AUDIBLE ALARMS COME ON (NORMAL OPERATION)

Step 1. Turn OFF alarm mute switch (1) to turn off audible alarms.

Step 2. Check instrument panel low oil pressure warning lights (2) and high water temperature warning lights (3) for appropriate engine to determine malfunction. Read appropriate gage. Oil pressure gage (4) should be above 20 psi (1.5 Kp/cm²). Water temperature gage (5) should be below 194°F (90°C).

a. If problem is high water temperature, see Malfunction No. 4.


b. If problem is low oil pressure, see Malfunction No. 6.

Section III. MAINTENANCE PROCEDURES

ACCESS HATCHES OPENING AND SECURING INSTRUCTIONS

- Battery Hatch
- Engine Hatch (Port and Starboard)
- Hydrojet Hatch (Port and Starboard)
- Control Console Access Hatch

BATTERY HATCH




Opening and Securing:

1. Lift up front edge of battery hatch (1).
2. Swing securing brace (2) into grooved slot (3) on hatch (located on starboard side).

Closing:

1. Grasp front edge of battery hatch (1) and lift to open position to clear brace (2).
2. Remove securing brace (2) from grooved slot (3) and lower into stored position.
3. Close battery hatch by lowering to closed position.

ENGINE HATCHES (Port and Starboard)



Opening and Securing:

1. Open port engine hatch (1).
2. Swing securing brace (2) upward into grooved slot (3) on hatch.
3. Place pin (4) through retaining bolt (5).
4. Open starboard engine hatch (6).
5. Swing securing brace (2) upward into grooved slot (3) on hatch.
6. Place pin (4) thru retaining bolt (5).


NOTE

When both engine hatches are open the starboard hatch must be closed first.

Closing:

1. Grasp edge of engine hatch [starboard (6) or port (1)].
2. Remove pin (4) from retaining bolt (5) and securing brace (2). Push hatch (6 or 1) open to dear brace (2).
3. Remove securing brace (2) from grooved slot (3).
4. Swing securing brace (2) down into stored position.
5. Close engine hatch by lowering to closed position.

HYDROJET HATCH (Port and Starboard)




Opening and Securing:

1. Open hydrojet hatch (1) (port or starboard).
2. Swing securing brace (2) upward into grooved slot (3) on hatch

Closing:

1. Grasp edge of hydrojet hatch (1) (port or starboard) and push open to clear securing brace (2).
2. Remove securing brace (2) from grooved slot (3) on hatch (1).
3. Swing securing brace (2) down into stored position.
4. Close hydrojet hatch (1) by lowering to closed position.

CONTROL CONSOLE ACCESS HATCH



Opening:

Open access hatch (1) under control console by removing two wing nuts (2) and swinging hatch (1) down.

Closing:


Close access hatch (1) and install two wing nuts (2). Tighten finger tight.

REFUELING

WARNING

Diesel fuel is flammable. Do not allow smoking or any open flames near the boat when you are refueling.


1. Shut off engines.
2. Clean off any dirt that could get into the tank
3. Unscrew the filler cap and remove.
4. Fill up tank Make sure you have metal-to-metal contact between the fuel nozzle and the tank
5. Do not fill fuel tank above the full mark on the dipstick
6. When you're through refueling, remove the nozzle and screw on the filler cap.
7. Wipe up any spilled fuel.



FRESH WATER COOLANT LEVEL

WARNING

If cooling system is hot, open coolant filler cap slowly until all pressure is gone. Do not touch the hot cap with your bare hand. Never take the cap off while the engine is overheated. Allow it to cool down first.




Remove the filler cap (1) and check the level of coolant in the header. You should see coolant approximately one inch (25 cm) below the bottom of the filler neck. Add coolant to fill the header if the coolant level is low.

NOTE

Normally the fresh water coolant will stabilize at this level, and it should not be necessary to top off frequently. If it does become necessary to frequently add coolant, report it to organizational maintenance.

CHECKING AND ADJUSTING V-BELT.



LOOSEN TENSION INCREASE TENSION


1. Check the V-belt tension by pressing down or pulling up on the belt halfway between the water pump pulley and the alternator pulley. If the belt has more than 1/4 inch free play, the belt needs to be tightened.
2. To adjust the belt tension, lift up the adjuster assembly lock and turn the adjuster nut clockwise to loosen tension and counterclockwise to increase tension. Position the adjuster nut so that it can be locked in position with the adjuster assembly lock.

CLEANING CAB WINDSHIELD PANELS

CAUTION

Windshield panels are plastics and should not be cleaned with abrasive or chemical cleaning compound or solution.



Clean windshield panels using a soft cloth and mild soap and water (item 2, Appendix C).



REMOVE SHACKLES FROM ANCHOR AND LINE ASSEMBLY.

REMOVE SHACKLE

1. Insert shackle removal tool (1) into eyelet of shackle.





2. Turn shackle removal tool (1) with both hands in counterclockwise direction (3) until shackle pin (2) is free.
3. Remove shackle removal tool (1) from shackle pin (2).
4. Remove shackle (4) from chain.

REMOVE SHACKLES FROM ANCHOR AND LINE ASSEMBLY - (Continued).

INSTALL SHACKLE

1. Install shackle (1) through last link of chain.



2. Insert shackle pin (2) through unthreaded end of shackle (3) and eyelet of anchor line (4) or anchor.
3. With fingers turn shackle pin in clockwise direction (5) until tight.
4. Insert shackle tool (6) into eyelet (7) and with both hands continue tightening shackle pin (2).
5. Remove shackle removal tool (6).

APPENDIX A

REFERENCES

A-1. SCOPE

This appendix lists all forms, field manuals, and technical manuals and miscellaneous publications referenced in this manual.

A-2. FIELD MANUALS

First Aid for Soldiers FM 21-11

A-3. TECHNICAL MANUALS

Operator and Organizational Maintenance Manual (Including Repair Parts and Special Tools List)
for Bridge Erection Boat Cradle TM 5-2090-202-12&P

Operator and Organizational Maintenance Manual for Ribbon Bridge TM 5-5420-209-12

The Army Maintenance Management Systems (TAMMS) DA Pam 738-750

Hand Receipt Covering Boat, Bridge Erection, Twin Jet, Aluminum Hull TM 5-1940-277-10-HR

Equipment Record Procedures (Marine Corps) TM 4700-15/1

Procedures for Destruction of Equipment to Prevent Enemy Use TM 750-244-3

A-4 FORMS

Recommended Changes to Publications and Blank Forms DA Form 2028

Recommended Changes to Equipment Technical Publications DA Form 2028-2

Recommended Changes to Technical Publications NAVMC Form 10772

Hand Receipt DA Form 2062

Equipment Control Record DA Form 2408-9

Quality Deficiency Report SF 368

Quality Deficiency Report for MC users MCO 4855.10

Marine Corps Military Incentive Awards Program MCO 1650.17

A-5 MISCELLANEOUS PUBLICATIONS

Lubrication Order LO 5-1940-277-12, LI 1940-12

Expendable/Durable Items (Except: Medical, Class V, Repair Parts, and Heraldic Items) CTA 50-970

Identification and Distribution of DA Publications and Issue of Agency and Command Administrative
Publications AR 310-2

Standard Characteristics (Dimensions, Weight, and Cube) for Transportability of Military
Vehicles and Other Outsize/Overweight Equipment TB 55-46-1

APPENDIX B

COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LISTS

Section I. INTRODUCTION

B-1. SCOPE

This appendix lists components of end item and basic issue items for the bridge erection boat to help you inventory items required for safe and efficient operation.

B-2. GENERAL

The components of End Item and Basic Issue Items Lists are divided into the following sections:

a. Section II. Components of End Item. This listing is for informational purposes only, and is not authority to requisition replacements. These items are part of the end item, but are removed and separately packaged for transportation or shipment. As part of the end item, these items must be with the end item whenever it is issued or transferred between property accounts. Illustrations are furnished to assist you in identifying the items.

b. Section III. Basic Issue Items (BII). These are the minimum essential items required to place the bridge erection boat in operation, to operate it, and to perform emergency repairs. Although shipped separately packaged, BII must be with the bridge erection boat during operation and whenever it is transferred between property accounts. The illustrations will assist you with hard-to-identify items. This manual is your authority to request/requisition replacement BII, based on TOE/MTOE authorization of the end item.

B-3. EXPLANATION OF COLUMNS


The following provides an explanation of columns found in the tabular listings:

- a. Column (1) Illustration Number (Illus Number). This column indicates the number of the illustration in which the item is shown.
- b. Column (2) National Stock Number. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.
- c. Column (3) Description. Indicates the Federal item name and, if required, a minimum description to identify and locate the item. The last line for each item indicates the Federal Supply Code for Manufacturer (FSCM) in parentheses followed by the part number. If item needed differs for different models of this equipment, the model is shown under the "Usable On" heading in this column. DLF is the MKI and DVU is the MKII.
- d. Column (4) Unit of Measure (U/M). Indicates the measure used in performing the actual operational/maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e. g. , ea, in, pr).
- e. Column (5) Quantity Required (Qty Rqr). Indicates the quantity of the item authorized to be used with/on the equipment.


Section II. COMPONENTS OF END ITEM

There is no Components of End Item list for the bridge erection boat.

Section III. BASIC ISSUE ITEMS





Section III. BASIC ISSUE ITEMS (Continued)



Folded over side cover
closes opening
Main flap seats both pockets
and snaps on side cover.



Section A-A
(Two pockets with side
cover and main flap
closed)



(1) ILLUS NUMBER	(2) NATIONAL STOCK NUMBER	(3) DESCRIPTION FSCM AND PART NUMBER	USABLE ON CODE	(4) U/M	(5) QTY RQD
1	5420-01-257-5746	Line ,Bow Stern Tow (97403) 13226E0591		EA	1
2		Ring, Buoy, MIL-R-16847 (97403) 13226E0573		EA	1
3		Line, Mooring (97403) 13226E0585		EA	4
4		Hook, Boat (97403) 13226E0570		EA	1
5		Line, Steering (97403)13226E0584		EA	2
6	5110-00-555-8868	Hatchet, Broad Type F (81348) GGG-H-131TYF		EA	1
7	5120-01-110-0319	Tool, Shackle Removal (97403) 13226E0571		EA	1
8		Anchor and Anchor Line Assembly (97403) 13226E0586		EA	1
9		Line, Anchor, 100 ft min (97403) 13213E5512		EA	1
10		Shackle (81348) RR-C-271 CL1 TY4 7/16		EA	2
11		Chain, Welded, 3/8 nom dia 83-85 in. (81348) RR-C-271 TY1 GRC CL1		EA	1
12		Anchor, 24 lb (97403) 13216E6808		EA	1
13	4210-01-270-4512	Extinguisher, Fire (33525) 896990		EA	1
14	7520-00-559-9618	Case, Maintenance, Canvas with 2 Pockets (81349) MIL-C-11743		EA	1
15	4730-01-258-2647	Adapter, Hose (97403) 13226E0280	DLF	EA	1
16	4730-01-280-0068	Reducer, Hose, 1 NH est. thd. 3/4 (97403) 13218E0470-35		EA	1
17	4730-01-203-3912	Hose Assembly Rubber, water service, with 3/4 - 1-1/2 NH couplings, type optional, 3/4 IDX, 50 ft .long, Grade A, Class 1	DLF DLF	EA	1

APPENDIX C

EXPENDABLE SUPPLIES AND MATERIALS LIST

Section I. INTRODUCTION

C-1. SCOPE

This appendix lists expendable supplies and materials you will need to operate and maintain the bridge erection boat. These items are authorized to you by CTA 50-970, Expendable Items (Except Medical, Class V, Repair Parts, and Heraldic Items).

C-2. EXPLANATION OF COLUMNS

a. Column (1) - Item number. This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the material (e g., "Use cleaning compound, Item 5, App. C").

b. Column (2) - Level. This column identifies the lowest level of maintenance that requires the listed item. (enter as applicable)

- C - Operator/Crew
- O - Organizational Maintenance
- F - Direct Support Maintenance
- H - General Support Maintenance

c. Column (3) - National Stock Number. This is the National stock number assigned to the item; use it to request or requisition the item.

d. Column (4) Description. Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the Federal Supply Code for Manufacturer (FSCM) in parentheses followed by the part number.

e. Column (5) Unit of Measure (U/M). Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e. g, ea, in, pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST

(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) DESCRIPTION	(5) U/M
1	C	9150-00-190-0907	Grease, Automotive and Artillery (GAA), (81349), MIL-G-10924	LB
2	C	7930-00-249-8036	Detergent, General Purpose (81348) P-D-220	
3	C	9150-00-186-6681	Oil, Engine, OE/HDO-30 MIL-L-2104	QT
4	C	9150-00-177-3988	Oil, Engine, OE/HDO-10 MIL-L-2104	QT
5	C	9140-00-286-5297	Fuel, Diesel, DF-2 VV-F-800	GL
6	C		Dry Cleaning Solvent SD-2	GL
7	C	4020-00-968-1356	Rope, Nylon (MIL-R-1 7343)	RL

C-1/(C-2 blank)

ALPHABETICAL INDEX

Subject, Page No.

A

Access hatches, opening and securing, 3-12
Aft bilge pump switch, 1-7, 2-12
Aft grease cap, 2-21
Air intake, 1-25
Air-exhaust system, 1-25
Alternator warning light, 2-5
Anchor, 2-41
Anchor light, 1-27
Anchor light switch, 2-9
Anchoring ribbon bridge, 2-98
Automatic operated fire extinguishers, 1-26
Auxiliary switch panel No. 1, (MK1), 1-7, 2-7
Auxiliary switch panel No. 2, (MK1), 1-7, 2-9

B

Basic issue items list, B-1
Batteries, 1-4, 1-27, 2-25
Battery condition meter, 2-5
Battery hatch, 3-12
Beaching legs, 1-4
Bilge drain plug, 2-47
Bilge pump, electric, 1-27
Bilge pump, hand operated, 1-7
Bilge pump, switch, aft, 1-7, 2-12
Bilge pump, switch, forward, 1-7, 2-12
Bilge water warning lights, 2-5
Boat launch, 2-87
Boat retrieval, 2-91
Bollards, 2-41

C

Cab, 1-4
Cab, electrical connector, 1-7
Cabin lights switch, 2-9
Capabilities and features, 1-2
Capstan, 1-4, 2-23
Clearing grilles, water jet intake, 2-84
Collector, 1-23
Coming into berth, 2-92
Components of end item list, B-1
Components, major, 1-4
Control console, 1-4, 1-6
Control console access hatch, 3-15
Control engine stop, 1-7, 2-8
Control, engine throttle, 1-7, 2-2, 2-19
Control, scoop, 1-7, 2-3, 2-19

Subject, Page No.

C

Coolant level, fresh water, 3-16
Coolant temperature gage, 2-5
Cooling system MK1 engine, raw water, 1-15
Cooling system, fresh water, 1-8, 1-10, 1-15, 2-37, 3-16
Cooling system, MK1 (Modified), 1-18
Cooling system, MK1 engine, 1-15
Cooling system, primary engine, 1-20
Cooling system, secondary engine, 1-20

D

Data, equipment, 1-11
Davit tube, 1-4
Differences between models, 1-8
Dimensions and weights, 1-11
Drain plug, bilge, 2-47
Drain, 2-47
Drains, 2-17
Drive belts, 2-31
Drive shafts, 1-13

E

Electric bilge pumps, 1-27
Electrical system, 1-27
Emergency link solenoid, 1-27
Emergency link switch, 2-7
Emergency link warning light, 2-5
Engine alarm, mute switch, 1-7, 2-7
Engine audible alarm, 1-27
Engine blower switch, 2-13
Engine breathing system, 1-30, 2-29
Engine circuit switch, 2-5
Engine coolant warning light, 2-4
Engine hatches, 3-13
Engine instrument panel, 1-7, 2-4, 2-45
Engine lower oil pressure warning light, 2-5
Engine oil level, 2-35
Engine oil pressure gage, 2-5
Engine stop control, 1-7, 2-8
Engine throttle control, 1-7, 2-2, 2-19
Engines, 1-4, 1-13
Exhaust manifold, 1-15, 1-20
Exhaust pipe, 1-25
Exhaust pipe assembly, 1-25
Exhaust ports, 2-17
Expansion tank, 1-15, 1-20
Expendable supplies and materials list, C-1

ALPHABETICAL INDEX - Continued

Subject, Page No.

Subject, Page No.

F

Fast water launch, 2-89
Features and capabilities, 1-2
Feed and return lines, 1-23
Filter/reservoir, 1-23
Fire extinguishing system, 1-26, 2-27
Flexible connection, 1-25
Forms, 1-1
Forward bearing oil reservoir, 2-23
Forward bilge pump switch, 1-7, 2-12
Forward grease cap, 2-21
Forward movement, 2-69
Fresh water coolant level, 3-16
Fresh water engine cooling system, 1-15, 2-37
Fresh water pump, 1-15
Fuel consumption, 1-11
Fuel filters, 1-23
Fuel lift pump, 1-23
Fuel system, 1-22
Fuel tank, 1-4, 1-23, 2-27
Fuel tank vent, 1-23
Fuel water separator, 1-23, 2-29

G

Gage, coolant temperature, 2-5
Gage, engine oil pressure, 2-5
Gage, engine oil pressure, 2-5
Getting under way, aster, 2-86
Getting under way, forward, 2-84
Glossary, 1-2
Grease cap, aft, 2-21
Grease cap, forward, 2-21
Grease cap, scoop control shaft, 2-23
Grease cap, steering control shaft, 2-21
Grille, hydrojet, 2-21
Grilles, clearing, water jet intake, 2-84

H

Hand held fire extinguishers, 1-26
Handrail, 1-7
Hatches, 2-45, 3-12
Header, 1-15, 1-20
Heat exchangers, 1-15
Heat shield, 1-25
Heat shield, turbocharger, 1-25
Heat switch, 2-5
Horn, 1-27, 2-39
Horn switch, 1-7, 2-13
Hour meters, 1-27, 2-25

H

Hull, 2-17
Hydrojet grille, 2-21
Hydrojet hatch, 3-14
Hydrojets, 1-4, 1-13

I

Injection pump, 1-23
Injectors, 1-23
Inspection light, 1-27
Inspection light switch, 2-9
Instructions, operating, 2-1
Instrument light switch, 2-5
Instrument panel, engine, 1-7, 2-4, 2-45
Intercoolers, 1-15, 1-20
Isolating valve, 1-23

K

Keel coolers, 1-5, 2-17

L

Launching, 2-87
Leakage, 2-15
Lifting eyes, 2-41
Light, alternator warning, 2-5
Light, anchor, 1-27
Light, bilge water warning, 2-5
Light, emergency ink warning, 2-5
Light, emergency link warning, 2-5
Light, engine coolant warning, 2-4
Light, inspection, 1-27
Light, low engine oil pressure warning, 2-5
Light, low fuel warning, 2-5
Lights, mast, 2-37
Lights, navigation, 1-27
Lights, steaming, 1-27
Lights, towing, 1-27
Lines, anchor, 2-41
Low fuel warning light, 2-5
Lubrication instructions, 3-1

M

Maintenance instructions, 3-1
Map locker, 1-7
Mast, 1-4, 2-43
Mast lights, 2-37
Mast plug, 1-27
Mast receptacle, 1-27
Master battery switch, 1-27
Meter, battery condition, 2-5
Meter, hour, 1-27, 2-25
Movement, forward, 2-69
Movement, reverse, 2-71

ALPHABETICAL INDEX - Continued

Subject, Page No.

N

Navigation lights, 1-27
Navigation lights switch, 2-9
Rub rail, 2-39

O

Oil cooler, 1-15, 1-20
Oil level, engine, 2-35
Oil level, transmission, 2-35
Oil reservoir, forward bearing, 2-23
Operating, instructions, 2-1
Operation, in extreme cold, 2-109
Operation, in extreme heat, 2-109
Operation, in salt water, 2-109
Operation, under unusual conditions, 2-109
Operation, under usual conditions, 2-48
Operation, with one engine, 2-109
Operator controls, 2-1

P

Performance, 1-11
Preventive maintenance checks and services, 2-14
Primary engine cooling system, 1-20
Primary water pump, 1-20
Propulsion system, 1-13
Pump handle, 1-7
Pump, electric, bilge, 1-27
Pump, fresh water, 1-15
Pump, injection, 1-23
Pump, primary water, 1-20
Pump, primary water, 1-15
Pump, secondary water, 1-15
Pump, secondary water, 1-20
Pushknees, 1-4, 2-17

R

Raw watercooling system, 2-100
Raw water cooling system, 1-15
Raw water intake 1-15, 2-31
Raw water pump, 1-15
Readings, engine instrument panel gage, 1-12
Receptacle, slave, 1-27
Recovery of ribbon bridge bay (pusher technique), 2-96
Reducing speed, 2-80
References, A-1
Refueling, 3-16
Removable mast, 1-4
Retrieving boat, 2-91
Retrieving free launched ribbon bridge bay (pusher technique), 2-94

Subject, Page No.

R

Reverse movement, 2-71
Ribbon bridge, anchoring, 2-98

S

Scoop control, 1-7, 2-3, 2-19
Scoop control shaft grease cap, 2-23
Scoop position indicator, 1-7, 2-4
Scoops, 1-13
Searchlight, 1-27
Searchlight mounting, 1-7
Searchlight socket, 1-7
Searchlight switch, 2-7
Secondary engine cooling system, 1-20, 1-21
Secondary water pump, 1-20
Shutoff valve, 1-23
Slave receptacle, 1-27
Slow water launch, 2-87
Solenoid, emergency link, 1-27
Speed, 1-11
Starter switch, 2-5
Starting procedure, after lay up, 2-61
Starting procedure, cold, 2-54
Starting procedure, normal, 2-48
Steaming lights, 1-27
Steering control shaft grease cap, 2-21
Steering wheel, 1-7, 2-4, 2-19
Steering, using scoop controls, 2-80
Steering, using wheel, 2-74
Steering, using wheel and scoop controls, 2-76
Stop Control, 1-7, 2-8
Stopping engines, 2-81
Storage locker, 1-7
Storage locker, 1-7
Switch, alarm mute, 1-7
Switch, anchor lights, 2-9
Switch, auxiliary panel No. 1, 1-7, 2-7
Switch, auxiliary panel No. 2, 1-7, 2-9

Switch, bilge pump, aft, 1-7, 2-12
Switch, bilge pump, forward, 1-7, 2-12
Switch, cabin lights, 2-9
Switch, emergency link, 2-7
Switch, engine blower, 2-13
Switch, engine circuit, 2-5
Switch, heat, 2-5
Switch, horn, 2-13
Switch, inspection lights, 2-9
Switch, instrument light, 2-5
Switch, master battery, 1-27
Switch, navigation lights, 2-9

ALPHABETICAL INDEX - Continued

Subject, Page No.

S

Switch, panel unit 1 MK1 (Modified) and MK2, 1-7, 2-10
Switch, panel unit 2 MK1 (Modified) and MK2, 1-7, 2-11
Switch, searchlight, 2-7
Switch, starter, 2-5
Switch, towing lights, 2-9
Switch, wipers, 2-7

T

Tachometer, 2-5
Thermostarter, 1-23
Thermostat, 1-15, 1-20
Throttle control, engine, 1-7, 2-2, 2-19
Thrust, 1-11
Towing lights, 1-27
Towing lights switch, 2-9
Transmission, 1-13, 2-19
Transmission control, 2-1
Transmission oil cooler, 1-15, 1-20
Transmission oil level, 2-35
Transmission selector lever, 1-7, 2-1
Troubleshooting procedures, 3-1
Turbocharger, 1-25
Turbocharger heat shield, 1-25
Turning radius, 1-11

V

V-belt, 3-18
Valve, isolating, 1-23
Valve, shutoff, 1-23
Vent, fuel tank, 2-17


W

Warning decal, 1-7
Warranty information, 1-2
Water jet intake grilles, clearing, 2-84
Water level, fresh water cooling system, 2-37
Weights and dimensions, 1-11
Windshield panels, cab, 3-19
Wiper motors, 1-27
Wiper switches, 2-7

Warranty information, 1-2
Water jet intake grilles, clearing, 2-79
Water level, fresh water cooling system, 2-33
Weights and dimensions, 1-8
Windshield panels, cab, 3-19
Windshield wipers, 2-39
Wiper motors, 1-23
Wiper switches, 2-8

By Order of the Secretaries of the Army and Navy (Including the Marine Corps):

Official:



MILTON H. HAMILTON
Administrative Assistant to the
Secretary of the Army
05366

GORDON R. SULLIVAN
General, United States Army
Chief of Staff

DAVID E. BOTTORFF
Rear Admiral, CEC, US Navy
Commander
Navy Facilities Engineering
Command

RONALD D. ELLIOTT
Executive Director
Marine Corps Systems Command

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25-E, block no. 0262, requirements for TM 5-1940-277-10.

*U.S. GOVERNMENT PRINTING OFFICE: 1996 - 406-421 (51163)

The Metric System and Equivalents

Linear Measure

1 centimeter = 10 millimeters = .39 inch
 1 decimeter = 10 centimeters = 3.94 inches
 1 meter = 10 decimeters = 39.37 inches
 1 dekameter = 10 meters = 32.8 feet
 1 hectometer = 10 dekameters = 328.08 feet
 1 kilometer = 10 hectometers = 3,280.8 feet

Weights

1 centigram = 10 milligrams = .15 grain
 1 decigram = 10 centigrams = 1.54 grains
 1 gram = 10 decigram = .035 ounce
 1 decagram = 10 grams = .35 ounce
 acres
 1 hectogram = 10 decagrams = 3.52 ounces
 1 kilogram = 10 hectograms = 2.2 pounds
 1 quintal = 100 kilograms = 220.46 pounds
 1 metric ton = 10 quintals = 1.1 short tons

Liquid Measure

1 centiliter = 10 milliliters = .34 fl. ounce
 1 deciliter = 10 centiliters = 3.38 fl. ounces
 1 liter = 10 deciliters = 33.81 fl. ounces
 1 dekaliter = 10 liters = 2.64 gallons
 1 hectoliter = 10 dekaliters = 26.42 gallons
 1 kiloliter = 10 hectoliters = 264.18 gallons

Square Measure

1 sq. centimeter = 100 sq. millimeters = .155 sq. inch
 1 sq. decimeter = 100 sq. centimeters = 15.5 sq. inches
 1 sq. meter (centare) = 100 sq. decimeters = 10.76 sq. feet
 1 sq. dekameter (are) = 100 sq. meters = 1,076.4 sq. feet
 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47
 1 sq. kilometer = 100 sq. hectometers = .386 sq. mile

Cubic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch
 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches
 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

Approximate Conversion Factors

<i>To change</i>	<i>To</i>	<i>Multiply by</i>	<i>To change</i>	<i>To</i>	<i>Multiply by</i>
inches	centimeters	2.540	ounce-inches	Newton-meters	.007062
feet	meters	.305	centimeters	inches	.394
yards	meters	.914	meters	feet	3.280
miles	kilometers	1.609	meters	yards	1.094
square inches	square centimeters	6.451	kilometers	miles	.621
square feet	square meters	.093	square centimeters	square inches	.155
square yards	square meters	.836	square meters	square feet	10.764
square miles	square kilometers	2.590	square meters	square yards	1.196
acres	square hectometers	.405	square kilometers	square miles	.386
cubic feet	cubic meters	.028	square hectometers	acres	2.471
cubic yards	cubic meters	.765	cubic meters	cubic feet	35.315
fluid ounces	milliliters	29,573	cubic meters	cubic yards	1.308
pints	liters	.473	milliliters	fluid ounces	.034
quarts	liters	.946	liters	pints	2.113
gallons	liters	3.785	liters	quarts	1.057
ounces	grams	28.349	liters	gallons	.264
pounds	kilograms	.454	grams	ounces	.035
short tons	metric tons	.907	kilograms	pounds	2.205
pound-feet	Newton-meters	1.356	metric tons	short tons	1.102
pound-inches	Newton-meters	.11296			

Temperature (Exact)

°F	Fahrenheit	5/9 (after	Celsius	°C
	temperature	subtracting 32)	temperature	

PIN: 050248-000