

TECHNICAL MANUAL
MAINTENANCE INSTRUCTIONS
UNIT MAINTENANCE
M1083 SERIES, 5-TON, 6 X 6,
MEDIUM TACTICAL VEHICLES (MTV)
VOLUME NO. 2 OF 5

MODEL	NSN	EIC	HOW TO USE THIS MANUAL
TRK, CAR., MTV, M1083 W/WN W/O WN	2320-01-360-1895 2320-01-354-3386	BT3 BR2	PAGE iv
TRK, CAR., MTV, W/MATL HDLG EQPT (MHE), M1084	2320-01-354-3387	BR3	ELECTRICAL SYSTEM TROUBLESHOOTING (CONT) PAGE 2-943
TRK, CAR., MTV, LWB, M1085 W/WN W/O WN	2320-01-360-1897 2320-01-354-4530	BT5 BR7	TRANSMISSION SYSTEM TROUBLESHOOTING PAGE 2-1581
TRK, CAR., MTV, LWB, W/MATL HDLG EQPT (MHE), M1086	2320-01-354-4531	BR8	PROPELLER SHAFT TROUBLESHOOTING PAGE 2-1823
TRK, TRACTOR, MTV, M1088 W/WN W/O WN	2320-01-360-1892 2320-01-355-4332	BTY BTJ	POWER TAKE-OFF (PTO) TROUBLESHOOTING PAGE 2-1831
TRK, WKR, MTV, M1089	2320-01-354-4528	BR4	
TRK, DUMP, MTV, M1090 W/WN W/O WN	2320-01-360-1893 2320-01-354-4529	BTZ BR5	BRAKE SYSTEM TROUBLESHOOTING PAGE 2-1835
TRK, CHAS, MTV, M1092	2320-01-354-3382	BRZ	
TRK, CAR., MTV, AIR DROP, M1093 W/WN W/O WN	2320-01-360-1896 2320-01-355-3063	BT4 BR9	AIR SYSTEM TROUBLESHOOTING PAGE 2-1947
TRK, DUMP, MTV, AIR DROP, M1094 W/WN W/O WN	2320-01-360-1984 2320-01-355-3062	BT2 BTK	WHEEL TROUBLESHOOTING PAGE 2-1989
TRK, CHAS, MTV, LWB, M1096	2320-01-354-4527	BR6	HYDRAULIC SYSTEM TROUBLESHOOTING PAGE 2-1997

DISTRIBUTION STATEMENT A. Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENTS OF THE ARMY AND THE AIR FORCE

SEPTEMBER 1998

WARNING SUMMARY

WARNING

EXHAUST GASES CAN KILL

1. **DO NOT** operate your vehicle engine in an enclosed area.
2. **DO NOT** idle vehicle engine with cab windows closed.
3. **DO NOT** drive vehicle with inspection plates or covers removed.
4. **BE ALERT** at all times for exhaust odors.
5. **BE ALERT** for exhaust poisoning symptoms, they are:
 - Headache
 - Dizziness
 - Sleepiness
 - Loss of Muscular Control
6. **IF YOU SEE** another person with exhaust poisoning symptoms:
 - Remove person from area.
 - Expose to open air.
 - Keep person warm.
 - Do not permit person to move.
 - Administer cardiopulmonary resuscitation, if necessary.*

* For cardiopulmonary resuscitation, refer to FM 4-25.11.

WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock. Batteries can explode from a spark. Battery acid is harmful to skin and eyes. Always wear eye protection and rubber gloves when working with batteries. Failure to comply may result in injury to personnel.

WARNING

Do not work on fuel system when engine is hot; fuel can be ignited by a hot engine.

WARNING SUMMARY (CONT)

WARNING

Battery acid (electrolyte) is extremely harmful. Always wear safety goggles and rubber gloves, and do not smoke when performing maintenance on batteries. Injury will result if acid contacts skin or eyes. Wear rubber apron to prevent clothing being damaged. Failure to comply may result in injury to personnel.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. Keep away from open fire and use in a well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water. Failure to comply may result in injury to personnel.

WARNING

Dry Cleaning Solvent (P-D-680) is TOXIC and flammable. Wear protective goggles and gloves; use only in well ventilated area; avoid contact with skin, eyes, and clothes, and do not breathe vapors. Keep away from heat or flame. Never smoke when using solvent; the flashpoint for Type I Dry Cleaning Solvent is 100°F (38°C) and for Type II is 130°F (50°C). Failure to comply may result in serious injury or death to personnel.

If personnel become dizzy while using Dry Cleaning Solvent, immediately get fresh air and medical help. If Dry Cleaning Solvent contacts skin or clothes, flush with cold water. If Dry Cleaning Solvent contacts eyes, immediately flush eyes with water and get immediate medical attention. Failure to comply may result in injury to personnel.

WARNING

Diesel fuel is flammable. If fuel is spilled, clean it up immediately. Failure to comply may result in serious injury or death to personnel.

WARNING

Diesel fuel is flammable. Do not fill fuel tank with engine running, while smoking, or when near an open flame. Never overfill the tank or spill fuel. If fuel is spilled, clean it up immediately. Failure to comply may result in serious injury or death to personnel.

WARNING

Use care when removing/installing springs. Springs are under tension and can act as projectiles when being removed. Failure to comply can cause injury to personnel.

WARNING

Adhesive sealant MIL-S-46163 can damage your eyes. Wear safety goggles/glasses when using; avoid contact with eyes. If sealant contacts eyes, flush eyes with water and get immediate medical attention. Failure to comply may result in injury to personnel.

WARNING

After Nuclear, Biological, or Chemical (NBC) exposure of vehicle, all air filters shall be handled with extreme caution. Unprotected personnel may experience serious injury or death if residual toxic agents or radioactive material are present. If vehicle is exposed to chemical or biological agents, servicing personnel shall wear protective mask, hood, protective overgarments, and chemical protective gloves and boots in accordance with FM-3-4. All contaminated air filters shall be placed in double-lined plastic bags and moved swiftly to a segregation area away from the worksite. The same procedure applies for radioactive dust contamination. The Company NBC team should measure radiation prior to filter removal to determine extent of safety procedures required per the NBC Annex to the unit Standard Operating Procedures (SOP). The segregation area in which the contaminated air filters are temporarily stored shall be marked with appropriate NBC placards. Final disposal of contaminated air filters shall be in accordance with local SOP. Decontamination operation shall be in accordance with FM-3-5 and local SOP. Failure to comply may result in serious injury or death to personnel.

WARNING

Ensure exhaust system is cool before performing maintenance. Failure to comply may result in injury to personnel.

WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

WARNING

Post signs that read "NO SMOKING WITHIN 50 FEET" when working with open fuel, fuel lines or fuel tanks. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Do not operate vehicle with muffler removed. Toxic exhaust fumes may enter cab, resulting in serious injury or death to personnel.

WARNING SUMMARY (CONT)

WARNING

Exhaust pipe, transmission oil lines, and transmission scavenge pump hose may be hot to the touch. Extreme care should be taken when checking exhaust pipe, transmission oil lines, and transmission scavenge pump hose for leaks. Failure to comply may result in injury to personnel.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment (goggles/shield, gloves, etc). Failure to comply may result in injury to personnel.

WARNING

Wheel drum weighs approximately 90 lbs (41 kgs). Use the aid of an assistant to help remove wheel drum. Failure to comply may result in injury to personnel.

WARNING

Wheel drum weighs approximately 90 lbs (41 kgs). Use the aid of an assistant to help install wheel drum. Failure to comply may result in injury to personnel.

WARNING

Brake shoes may be covered with dust. Breathing this dust may be harmful to your health. Do not use compressed air to clean brake shoes. Wear a filter mask approved for use against brake dust. Failure to comply may result in injury to personnel.

WARNING

Cage spring brake before air chamber is removed or severe injury to personnel will occur.

WARNING

Ensure air chamber is caged prior to installation. Failure to comply may result in injury to personnel.

WARNING

Ensure that tire is totally deflated before removing self-locking nuts. Failure to comply may result in serious injury or death to personnel.

WARNING

Spring brakes must be caged before attempting replacement of a rear axle wheel stud. Failure to comply may result in severe injury to personnel.

WARNING

Wear protective goggles to protect against possible injury from release of high pressure air. Failure to comply may result in injury to personnel.

WARNING

Prolonged contact with lubricating oil (MIL-L-2104) may cause a skin rash. Skin and clothing that come in contact with lubricating oil should be thoroughly washed immediately. Saturated clothing should be removed immediately. Areas in which lubricating oil is used should be well ventilated to keep fumes to a minimum. Failure to comply may result in injury to personnel.

WARNING

Hydraulic fluid (MIL-H-5606) is TOXIC. Wear protective goggles and gloves; use only in well ventilated area; avoid contact with skin, eyes, and clothes. Skin and clothing that come in contact with hydraulic oil should be washed immediately. Saturated clothing should be removed immediately. Failure to comply may result in injury to personnel.

WARNING

Never let moving wire rope slide through hands, even when wearing gloves. A broken wire could cut through gloves and cut hands. Failure to comply may result in injury to personnel.

WARNING

Wear appropriate eye protection when removing rivets. Failure to comply may result in injury to personnel.

WARNING

Wear appropriate eye protection when drilling holes. Failure to comply may result in injury to personnel.

WARNING

Wear leather gloves at all times when handling winch cable. Do not allow cable to slide through hands even with gloves on. Broken wires may cause injury.

WARNING SUMMARY (CONT)

WARNING

Use extreme caution when working around moving cable. Failure to do so may result in serious injury to personnel.

WARNING

Caution must be exercised while cab is raised. Ensure that locking mechanism is functioning properly before proceeding. Failure to comply may result in death or serious injury to personnel and damage to equipment.

WARNING

Coolant may be very hot and under pressure from engine operation. Ensure engine is cool before performing maintenance. Failure to comply may result in injury to personnel.

WARNING

Light Material Handling Crane (LMHC) weighs approximately 250 lbs (114 kgs). Attach a suitable lifting device prior to removal. Failure to comply may result in injury to personnel.

WARNING

Light Material Handling Crane (LMHC) mast weighs approximately 110 lbs (50 kgs). Attach a suitable lifting device prior to installation. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Light Material Handling Crane (LMHC) boom assembly weighs approximately 150 lbs (68 kgs). Use an assistant when removing boom assembly. Failure to comply may result in injury to personnel.

WARNING

Light Material Handling Crane (LMHC) boom weighs approximately 60 lbs (27 kgs). Attach a suitable lifting device prior to installation. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Machine gun ring assembly weighs approximately 350 pounds (159 kgs). Attach a suitable lifting device prior to removal. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Ensure vehicle is on level ground prior to installation/removal of collapsible drums. Failure to comply may result in serious injury or death to personnel or damage to equipment.

WARNING

Ensure cargo bed is free of equipment and debris and not warped or damaged in any way. Failure to comply may result in serious injury or death to personnel or damage to equipment.

WARNING

Both collapsible drums weigh approximately 235 lbs (107 kgs) empty and 3800 lbs (1725 kgs) full. Attach a suitable lifting device prior to installation. Failure to comply may result in serious injury or death to personnel or damage to equipment.

WARNING

S-280 shelter weighs approximately 1500 lbs (680 kgs) empty. Attach a suitable lifting device prior to installation. Failure to comply may result in serious injury or death to personnel or damage to equipment.

WARNING

Ensure vehicle is on level ground prior to installation or removal of tank and pump unit. Failure to comply may result in serious injury or death to personnel or damage to equipment.

WARNING

Tank weighs approximately 500 lbs (227 kgs) empty or 4000 lbs (1816 kgs) full. Attach a suitable lifting device prior to installation. Failure to comply may result in serious injury or death to personnel or damage to equipment.

WARNING SUMMARY (CONT)

WARNING

Pump unit weighs approximately 870 lbs (395 kgs). Attach a suitable lifting device prior to installation. Failure to comply may result in serious injury or death to personnel or damage to equipment.

WARNING

Do not remove oil filter while engine is hot. Failure to comply may result in injury to personnel.

WARNING

Starting fluid is toxic and highly flammable. Container is pressurized. NEVER heat container and NEVER discharge starting fluid in confined areas or near open flame. Failure to comply may cause serious injury or death to personnel.

WARNING

Tab of HAND THROTTLE lever must be positioned above throttle pivot bar. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Use extreme care when opening cab door with cab raised. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Do not operate vehicle with exhaust pipe removed. Toxic exhaust fumes may enter cab, resulting in serious injury or death to personnel.

WARNING

Radiator and charge air cooler assembly weigh approximately 160 lbs (73 kgs). Attach a suitable lifting device prior to removal. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Cargo sling must be placed under charge air cooler inlet and outlet ports. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Alternator weighs approximately 50 lbs (23 kgs). The aid of an assistant is required to remove alternator. Failure to comply may result in injury to personnel.

WARNING

Starting motor weighs approximately 60 lbs (27 kgs). Attach a suitable lifting device prior to removal. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Negative battery terminals must be connected last. Failure to comply may result in serious injury or death to personnel.

WARNING

Negative battery terminals and battery tester negative terminal lug must be disconnected first. Failure to comply may result in serious injury or death to personnel.

WARNING

Battery box weighs approximately 70 lbs (32 kgs). The aid of two assistants is required to remove battery box from vehicle frame. Failure to comply may result in injury to personnel.

WARNING

Battery box weighs approximately 70 lbs (32 kgs). The aid of two assistants is required to position battery box on vehicle frame. Failure to comply may result in injury to personnel.

WARNING

Ensure WTEC III cab transmission harness does not interfere with throttle linkage. Failure to comply may result in injury to personnel.

WARNING

Self-adjusting brakes will not self-adjust without applying brake pedal. Failure to comply may result in injury to personnel.

WARNING SUMMARY (CONT)

WARNING

Ensure air hoses are connected to correct fittings. Failure to comply may result in serious injury or death to personnel.

WARNING

Proper adjustment of load sensing valve may only be accomplished with vehicle unloaded. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Always use an inflation safety cage to inflate tires mounted on multipiece rims, and tire/rim assemblies not mounted on a tire changing machine that has a positive lock down device designed to hold the assembly during inflation (TM 9-2610-200-14). When using a tire changing machine, always follow manufacturer's mounting and safety instructions. Failure to comply may result in serious injury or death to personnel. Always inflate tires that are mounted on rims with demountable side ring flanges or lockrings in an inflation safety cage or serious injury or death may result.

WARNING

Tire weighs approximately 350 lbs (159 kgs). Use extreme care when handling tire. Failure to comply may result in injury to personnel.

WARNING

Wheel drum weighs approximately 92 lbs (42 kgs). Use the aid of an assistant to help remove wheel drum from axle. Failure to comply may result in injury to personnel.

WARNING

The sudden release of high pressure air can cause damage to eyes. Wear appropriate eye protection when working near pressurized air. Failure to comply may result in injury to personnel.

WARNING

Leave shackles installed in front bumper to support front bumper until ready to remove. Failure to comply may result in injury to personnel.

WARNING

Front bumper weighs approximately 100 lbs (45 kgs). Use the aid of an assistant to remove front bumper. Failure to comply may result in injury to personnel.

WARNING

Tractor platform weighs approximately 550 lbs (250 kgs). Attach a suitable lifting device prior to removal. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Spare tire retainer weighs approximately 150 lbs (68 kgs). The aid of two assistants is required to remove spare tire retainer from vehicle. Failure to comply may result in injury to personnel.

WARNING

Rear stabilizer bar weighs approximately 50 lbs (22 kgs). Attach a suitable lifting device prior to removal. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Cab roof weighs approximately 110 lbs (50 kgs). Attach a suitable lifting device prior to removal. Failure to comply may result in injury to personnel.

WARNING

Use care when removing/installing window. Do not force window, or window may shatter. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Tailgate assembly weighs approximately 130 lbs (59 kgs). Attach a suitable lifting device prior to removal. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Tow bar weighs approximately 150 lbs (68 kgs). Attach a suitable lifting device prior to removal. Failure to comply may result in injury to personnel or damage to equipment.

WARNING SUMMARY (CONT)

WARNING

Rear tool box weighs approximately 75 lbs (34 Kgs) empty. Attach a suitable lifting device prior to removal. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Cable can become frayed or contain broken wires. Wear heavy leather-palmed gloves when handling cable. Frayed or broken wires can injure hands. Failure to comply may result in injury to personnel.

WARNING

Remote control must be used to operate 30K winch while breaking in cables. Failure to comply may result in injury to personnel.

WARNING

Cab weighs approximately 3000 lbs (1362 kgs) attach a suitable lifting device prior to raising cab. Failure to comply may result in injury to personnel.

WARNING

Hydraulic tank weighs approximately 190 lbs (86 kgs). Attach a suitable lifting device prior to removal. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Extreme care must be taken when lowering gravel deflector. Coolant hoses could be pulled loose. Failure to comply could result in serious eye injury.

WARNING

Retaining rings are under tension and can act as projectiles when released causing severe eye injury. Use care when installing retaining rings. Failure to comply may result in injury to personnel.

WARNING

Do not open coolant fill cap if temperature reads above 110 degrees F (43 degrees C). Steam or hot coolant is under pressure. Failure to comply may result in injury to personnel.

WARNING

Pressure in reservoir tank must be released before removing cap. Failure to comply may result in injury to personnel.

WARNING

200 amp alternator weighs approximately 72 lbs (33 kgs). The aid of an assistant is required to install 200 amp alternator. Failure to comply may result in injury to personnel.

WARNING

100 amp alternator weighs approximately 70 lbs (32 kgs). Attach a suitable lifting device prior to removal. Failure to comply may result in injury to personnel.

WARNING

Both collapsible drums weigh approximately 235 lbs (107 kgs) empty and 3800 lbs (1725 kgs) full each. Attach a suitable lifting device prior to removal. Failure to comply may result in serious injury or death to personnel or damage to equipment.

WARNING

Air dryer may contain air pressure. Loosen input air hose connector slowly to vent off air pressure. Failure to comply may result in injury to personnel.

WARNING

Radiator and charge air cooler assembly weigh approximately 160 lbs (73 Kgs). Attach a suitable lifting device prior to installation. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Tractor platform weighs approximately 550 lbs (250 kgs). Attach a suitable lifting device prior to installation. Failure to comply may result in injury to personnel or damage to equipment.

WARNING SUMMARY (CONT)

WARNING

Spare tire retainer weighs approximately 150 lbs (68 kgs). The aid of two assistants is required to install spare tire retainer on vehicle. Failure to comply may result in injury to personnel.

WARNING

Rear stabilizer bar weighs approximately 50 lbs (22 kgs). Attach a suitable lifting device prior to installation. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Cab roof weighs approximately 110 lbs (50 kgs). Attach a suitable lifting device prior to installation. Failure to comply may result in injury to personnel.

WARNING

Do not remove radiator cap when the engine is hot; steam and hot coolant can escape and burn skin. Failure to comply may result in injury to personnel.

WARNING

Wear appropriate eye protection when removing spring rings. Spring rings are under tension and can act as projectiles when being removed. Failure to comply may result in injury to personnel.

WARNING

Wear appropriate eye protection when installing spring rings. Spring rings are under tension and can act as projectiles when being installed. Failure to comply may result in injury to personnel.

CHANGE
NO. 3

HEADQUARTERS
DEPARTMENTS OF THE ARMY
AND THE AIR FORCE
Washington, D.C., 10 February 2006

TECHNICAL MANUAL
MAINTENANCE INSTRUCTIONS
UNIT MAINTENANCE
M1083 SERIES, 5-TON, 6x6,
MEDIUM TACTICAL VEHICLE
(MTV)

VOLUME NO. 2 OF 5

TM 9-2320-366-20-2, 15 September 1998, is changed as follows:

1. Remove old pages and insert new pages as indicated below.
2. New or changed material is indicated by a vertical bar in the out margin of the page.
3. Added or revised illustrations are indicated by a vertical bar adjacent to the illustration.

Remove Pages

None
A thru C/(D Blank)
i thru ii
B1 thru B-29/(B-30 Blank)

Insert Pages

Change 3 Transmittal/ Change 3 Authentication
A thru C/(D Blank)
i thru ii
B1 thru B-29/(B-30 Blank)

Place this change sheet in the front of the publication for reference purposes.

By Order of the Secretary of the Army:

PETER J. SCHOOMAKER
General, United States Army
Chief of Staff

Official:



SANDRA R. RILEY
Administrative Assistant to the
Secretary of the Army
0601914

By Order of the Secretary of the Air Force:

JOHN J. JUMPER
General, United States Air Force
Chief of Staff

Official:

GREGORY S. MARTIN
General, United States Air Force
Commander, Air Force Materiel Command

Distribution:

To be distributed in accordance with the initial distribution number (IDN) 380940, requirements for Family of Medium Tactical Vehicles TM 9-2320-366-20-2.

**CHANGE
NO. 2**

**TECHNICAL MANUAL
MAINTENANCE INSTRUCTIONS
UNIT MAINTENANCE
M1083 SERIES, 5-TON, 6x6,
MEDIUM TACTICAL VEHICLE
(MTV)**

VOLUME NO. 2 OF 5

TM 9-2320-366-20-2, 15 September 1998, is changed as follows:

1. Remove old pages and insert new pages as indicated below.
2. New or changed material is indicated by a vertical bar in the out margin of the page.
3. Added or revised illustrations are indicated by a vertical bar adjacent to the illustration.

Remove Pages	Insert Pages
e and f	e and f
none	Change 2 Authentication Sheet
A and B	A and B
none	C/(D Blank)
iii and iv	iii and iv
2-945 thru 2-958.6	2-945 thru 2-958.6
none	2-958.7 thru 2-958.20
2-959 and 2-960	2-959 and 2-960
2-1161 thru 2-1170	2-1161 thru 2-1170
2-1445 thru 2-1446.2	2-1445 thru 2-1446.2
2-1446.3 and 2-1446.4	2-1446.3 and 2-1446.12
2-1446.5 thru 2-1446.12	none
2-1479 thru 2-1502.6	2-1479 thru 2-1502.6
2-1581 and 2-1582	2-1581 and 2-1582
2-1623 thru 2-1626	2-1623 thru 2-1626
2-1665 and 2-1666	2-1665 and 2-1666
2-1747 thru 2-1752	2-1747 thru 2-1752
2-1877 thru 2-1898	2-1877 thru 2-1898
B-5 thru B-8	B-5 thru B-8
B-27 thru B-29/ (B-30 Blank)	B-27 thru B-29/ (B-30 Blank)
C-1 thru C-4	C-1 thru C-4
D-1 thru D-6	D-1 thru D-6
G-1 thru G-12	G-1 thru G-12
H-1 thru H-32	H-1 thru H-32
K-1 thru K-4	K-1 thru K-4
INDEX-1 thru INDEX-4	INDEX-1 thru INDEX-4
INDEX-9 thru INDEX-12	INDEX-9 thru INDEX-12
FO-1 FP-69/(FP-70 Blank)	FO-1 FP-69/(FP-70 Blank)
Metric Conversion Chart /PIN	Metric Conversion Chart /PIN

Place this change sheet in the front of the publication for reference purposes.

By Order of the Secretary of the Army:

PETER J. SCHOOMAKER
General, United States Army
Chief of Staff

Official:



SANDRA R. RILEY
Administrative Assistant to the
Secretary of the Army
0401514

By Order of the Secretary of the Air Force:

JOHN P. JUMPER
General, United States Air Force
Chief of Staff

Official:

GREGORY S. MARTIN
General, United States Air Force
Commander, Air Force Materiel Command

Distribution:

To be distributed in accordance with the initial distribution number (IDN) 380940,
requirements for TM 9-2320-366-20-2.

Washington, D.C., 1 July 2003

**CHANGE
NO. 1**

**TECHNICAL MANUAL
MAINTENANCE INSTRUCTIONS
UNIT MAINTENANCE
M1083 SERIES, 5-TON, 6x6,
MEDIUM TACTICAL VEHICLE
(MTV)**

VOLUME NO. 2 OF 5

TM 9-2320-366-20-2, 15 September 1998, is changed as follows:

1. Remove old pages and insert new pages as indicated below.
2. New or changed material is indicated by a vertical bar in the out margin of the page.
3. Added or revised illustrations are indicated by a vertical bar adjacent to the illustration.

Remove Pages	Insert Pages	Remove Pages	Insert Pages
m and n	m and n	2-1707 thru 2-1710	2-1707 thru 2-1710
none	A and B	none	2-1710.1 thru 2-1701.4
i thru iv	i thru iv	2-1711 thru 2-1734	2-1711 thru 2-1734
none	v and vi	none	2-1734.1 and 2-1734.2
none	2-942.1/(2-942.2 Blank)	2-1735 thru 2-1794	2-1735 thru 2-1794
2-943 thru 2-958	2-943 thru 2-958	none	2-1794.1 and 2-1794.2
none	2-958.1 thru 2-958.6	2-1795 thru 2-1821/(2-1822 Blank)	2-1795 thru 2-1822
2-959 and 2-960	2-959 and 2-960	none	2-1822.1 thru
2-1049 thru 2-1056	2-1049 thru 2-1056		2-1822.29/(2-1822.30 Blank)
none	2-1056.1 thru 2-1056.10	2-1823 thru	2-1823 thru
2-1057 and 2-1058	2-1057 and 2-1058	2-1829/(2-1830 Blank)	2-1829/(2-1830 Blank)
2-1445 and 2-1446	2-1445 and 2-1446	2-1835 and 2-1836	2-1835 and 2-1836
none	2-1446.1 thru 2-1446.12	2-1877 thru 2-1898	2-1877 thru 2-1898
2-1447 thru 2-1450	2-1447 thru 2-1450	2-1899 and 2-1900	2-1899/(2-1900 Blank)
none	2-1450.1 thru 2-1450.28	2-1901 and 2-1902	none
2-1451 thru 2-1456	2-1451 thru 2-1456	2-1903 and 2-1904	(2-1903 Blank)/2-1904
none	2-1456.1 thru 2-1456.22	2-1905 thru 2-1930	2-1905 thru 2-1930
2-1457 and 2-1458	2-1457 and 2-1458	2-1931 and 2-1932	2-1931/(2-1932 Blank)
2-1467 thru 2-1478	2-1467 thru 2-1478	2-1933 and 2-1934	(2-1933 Blank)/2-1934
none	2-1478.1 and 2-1478.2	2-1945/(2-1946 Blank)	2-1945 and 2-1946
2-1479 thru 2-1490	2-1479 thru 2-1490	none	2-1946.1/(2-1946.2 Blank)
none	2-1490.1 thru 2-1490.6	2-1947 thru 2-1964	2-1947 thru 2-1964
2-1491 thru 2-1502	2-1491 thru 2-1502	2-1971 thru 2-1976	2-1971 thru 2-1976
none	2-1502.1 thru 2-1502.6	none	2-1976.1 thru 2-1976.64
2-1503 and 2-1504	2-1503 and 2-1504	2-1977 thru 2-1982	2-1977 thru 2-1982
2-1539 thru 2-1558	2-1539 thru 2-1558	2-1987/(2-1988 Blank)	2-1987 and 2-1988
2-1581 and 2-1582	2-1581 and 2-1582	none	2-1988.1 thru
2-1585 thru 2-1612	2-1585 thru 2-1612		2-1988.7/(2-1988.8 Blank)
none	2-1612.1 and 2-1612.2	A-1 thru A-4	A-1 thru A-4
2-1613 thru 2-1686	2-1613 thru 2-1686	B-3 and B-4	B-3 and B-4
none	2-1686.1 and 2-1686.2	B-23 thru B-30	B-23 thru B-29/(B-30 Blank)
2-1687 thru 2-1706	2-1687 thru 2-1706	C-1 thru C-4	C-1 thru C-4
none	2-1706.1 thru 2-1706.42	D-1 thru D-5/(D-6 Blank)	D-1 thru D-6

Place this change sheet in the front of the publication for reference purposes.

Remove Pages

Insert Pages

Remove Pages

Insert Pages


None	D-7/(D-8 Blank)
E-1 thru E-6	E-1 thru E-6
E-15 and E-16	E-15 and E-16
none	E-27 thru E-31/(E-32 Blank)
G-1 thru G-11(G-12 Blank)	G-1 thru G-12
H-1 thru H-12	H-1 thru H-12
H-21 and H-22	H-21 and H-22
H-25 thru H-28	H-25 thru H-28
H-31 and H-32	H-31 and H-32
none	K-1 thru K-4
INDEX-1 thru INDEX-12	INDEX-1 thru INDEX-12
none	INDEX-13/(INDEX-14 Blank)
FO-1 PF-1/(FP-2 Blank) thru PF-21/(FP-22 Blank)	FO-1 PF-1/(FP-2 Blank) thru PF-21/(FP-22 Blank)
FO-1 FP-25/(FP-26 Blank)	FO-1 FP-25/(FP-26 Blank)
FO-1 FP-29/(FP-30 Blank) thru FP-67/(FP-68 Blank)	FO-1 FP-29/(FP-30 Blank) thru FP-67/(FP-68 Blank)
FO-1 PF-75/(FP-76 Blank) thru FP-79/(FP-80 Blank)	FO-1 FP-75/(FP-76 Blank) thru FP-79/(FP-80 Blank)
DA FORM 2028-2 Sample	DA FORM 2028-2 Sample
DA FORM 2028-2	DA FORM 2028-2
DA FORM 2028-2	DA FORM 2028-2
DA FORM 2028-2	DA FORM 2028-2
Metric Conversion Chart Cover	Metric Conversion Chart Cover

Place this change sheet in the front of the publication for reference purposes.

By Order of the Secretary of the Army:

JOHN M. KEANE
General, United States Army
Chief of Staff

Official:


JOEL B. HUDSON
Administrative Assistant to the
Secretary of the Army
0110110

DISTRIBUTION: To be distributed in accordance with the Initial Distribution Number (IDN) 380940, requirements for TM 9-2320-366-20-2.

LIST OF EFFECTIVE PAGES

Insert latest changed pages. Destroy superseded pages.

NOTE: New or changed material is indicated by a vertical bar in the outer margin of the page.

Dates of issue for original and changed pages are:
 Original0 15 September 1998
 Change1 1 July 2003
 Change220 August 2005
 Change3 10 February 2006

THE TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 1612, CONSISTING OF THE FOLLOWING:

Page No.	*Change No.	Page No.	*Change No.	Page No.	*Change No.
Cover	1	2-1478.1 and 2-1478.2		2-1583 Blank.....	0
Blank	0	Added	1	2-1584 and 2-1585	0
a thru e.....	0	2-1479	1	2-1586 thru 2-1612	1
f.....	2	2-1480	2	2-1612.1 and 2-1612.2 Added....	1
g thru l.....	0	2-1481	1	2-1613 thru 2-1623	1
m and n.....	1	2-1482 thru 2-1484.....	2	2-1624.....	2
A and C.....	3	2-1485	1	2-1625.....	1
D Blank Added.....	2	2-1486	2	2-1626.....	2
i and ii	1	2-1487	1	2-1627 thru 2-1664	1
iii.....	2	2-1488	2	2-1665.....	2
iv	1	2-1489	1	2-1666 thru 2-1686	1
v and vi	1	2-1490	2	2-1686.1 and 2-1686.2 Added....	1
2-942.1 Added	1	2-1490.1 Added.....	1	2-1687 thru 2-1706	1
2-942.2 Blank Added	1	2-1490.2	2	2-1706.1 thru 2-1706.42 Added..	1
2-943.....	0	2-1490.3 Added.....	1	2-1707	1
2-944 and 2-945	1	2-1490.4	2	2-1708 and 2-1709	0
2-946 thru 2-958.6	2	2-1490.5 Added.....	1	2-1710	1
2-958.7 thru 2-958.20 Added....	2	2-1490.6	2	2-1710.1 thru 2-1710.4 Added....	1
2-959.....	2	2-1491	1	2-1711 thru 2-1734	1
2-960 thru 2-1049	0	2-1492	2	2-1734.1 and 2-1734.2 Added....	1
2-1050 thru 2-1056	1	2-1493	1	2-1735 thru 2-1747	1
2-1056.1 thru 2-1056.10		2-1494 thru 2-1496.....	2	2-1748 thru 2-1751	2
Added	1	2-1497	1	2-1752 thru 2-1794	1
2-1057.....	1	2-1498	2	2-1794.1 and 2-1794.2 Added....	1
2-1058 thru 2-1161	0	2-1499	1	2-1795 thru 2-1819	1
2-1162 thru 2-1169	2	2-1500	2	2-1820 and 2-1821	0
2-1170 thru 2-1445	0	2-1501	1	2-1822.....	1
2-1446 thru 2-1446.3	2	2-1502	2	2-1822.1 thru 2-1822.29 Added..	1
2-1446.4 thru 2-1446.11		2-1502.1 Added.....	1	2-1822.30 Blank Added	1
Deleted	2	2-1502.2	2	2-1823 thru 2-1829	1
2-1446.12 Added	1	2-1502.3 Added.....	1	2-1830 Blank.....	0
2-1447 thru 2-1450	1	2-1502.4	2	2-1831 thru 2-1833	0
2-1450.1 thru 2-1450.28		2-1502.5 Added.....	1	2-1834 Blank	0
Added	1	2-1502.6	2	2-1835.....	1
2-1451 thru 2-1456	1	2-1503	1	2-1836 thru 2-1877	0
2-1456.1 thru 2-1456.22		2-1504 thru 2-1539.....	0	2-1878.....	2
Added	1	2-1540 thru 2-1557.....	1	2-1879.....	1
2-1457.....	1	2-1558 thru 2-1579.....	0	2-1880.....	2
2-1458 thru 2-1467	0	2-1580 Blank	0	2-1881.....	1
2-1468 thru 2-1478	1	2-1581 and 2-1582.....	2		

* Zero in this column indicates an original page.

LIST OF EFFECTIVE PAGES (CONT)

Insert latest changed pages. Destroy superseded pages.

Page No.	*Change No.	Page No.	*Change No.	Page No.	*Change No.
2-1882	2	C-1	0	INDEX-4 thru INDEX-8	1
2-1883	1	C2- thru C-4	2	INDEX-9	2
2-1884	2	D-1	1	INDEX-10	1
2-1885	1	D-2 and D-3	2	INDEX-11 and INDEX-12	2
2-1886	2	D-4 and D-5	1	INDEX-13 Added	1
2-1887	1	D-6	2	INDEX-14 Blank Added	1
2-1888	2	D-7 Added	1	Glossary-1 and Glossary-2	0
2-1889	1	D-8 Blank Added	1	FO-1 FP-1	1
2-1890	2	E-1	1	FO-1 FP-2 Blank	0
2-1891	1	E-2 and E-3	0	FO-1 FP-3	1
2-1892	2	E-4 and E-5	1	FO-1 FP-4 Blank	0
2-1893	1	E-6 thru E-14	0	FO-1 FP-5	1
2-1894	2	E-15	1	FO-1 FP-6 Blank	0
2-1895	1	E-16 thru E-26	0	FO-1 FP-7	1
2-1896	2	E-27 thru E-31 Added	1	FO-1 FP-8 Blank	0
2-1897	1	E-32 Blank Added	1	FO-1 FP-9	1
2-1898	2	F-1 thru F-8	0	FO-1 FP-10 Blank	0
2-1899	1	G-1	2	FO-1 FP-11	1
2-1900 Blank	1	G-2	1	FO-1 FP-12 Blank	0
2-1901 and 2-1902 Deleted	1	G-3 thru G-6	2	FO-1 FP-13	1
2-1903 Blank	1	G-7	1	FO-1 FP-14 Blank	0
2-1904 thru 2-1931	1	G-8	2	FO-1 FP-15	1
2-1932 Blank	1	G-9	1	FO-1 FP-16 Blank	0
2-1933 Blank	1	G-10 thru G12	2	FO-1 FP-17	1
2-1934	1	H-1 thru H-6	2	FO-1 FP-18 Blank	0
2-1935 thru 2-1944	0	H-7	0	FO-1 FP-19	1
2-1945 and 2-1946	1	H-8	2	FO-1 FP-20 Blank	0
2-1946.1 Added	1	H-9	0	FO-1 FP-21	1
2-1946.2 Blank Added	1	H-10	2	FO-1 FP-22 Blank	0
2-1947 thru 2-1963	1	H-11	1	FO-1 FP-23	0
2-1964 thru 2-1971	0	H-12 thru H-14	2	FO-1 FP-24 Blank	0
2-1972 thru 1976	1	H-15	0	FO-1 FP-25	1
2-1976.1 thru 2-1976.64 Added	1	H-16	2	FO-1 FP-26 Blank	0
2-1977 thru 2-1981	1	H-17	0	FO-1 FP-27	0
2-1982 thru 2-1987	0	H-18 thru H-20	2	FO-1 FP-28 Blank	0
2-1988	1	H-21	1	FO-1 FP-29	1
2-1988.1 thru 2-1988.7 Added	1	H-22	2	FO-1 FP-30 Blank	0
2-1988.8 Blank Added	1	H-23	0	FO-1 FP-31	1
2-1989 thru 2-1995	0	H-24	2	FO-1 FP-32 Blank	0
2-1996 Blank	0	H-25	0	FO-1 FP-33	1
2-1997 thru 2-2005	0	H-26 thru H-28	2	FO-1 FP-34 Blank	0
2-2006 Blank	0	H-29	0	FO-1 FP-35	1
A-1	0	H-30 thru H-32	2	FO-1 FP-36 Blank	0
A-2 and A-3	1	J-1	0	FO-1 FP-37	1
A-4	0	J-2 Blank	0		
B-1	3	K-1 Added	1		
B-2	0	K-2 and K-3	2		
B-3 thru B-29 (B-30 Blank)	3	K-4 Added	1		
		INDEX-1	1		
		INDEX-2 and INDEX-3	2		

* Zero in this column indicates an original page.

LIST OF EFFECTIVE PAGES (CONT)

Insert latest changed pages. Destroy superseded pages.

Page No.	*Change No.	Page No.	*Change No.	Page No.	*Change No.
FO-1 FP-38 Blank	0	FO-2 FP-8 Blank	0		
FO-1 FP-39	1	FO-3 FP-1	0		
FO-1 FP-40 Blank	0	FO-3 FP-2 Blank	0		
FO-1 FP-41	1	FO-3 FP-3	0		
FO-1 FP-42 Blank	0	FO-3 FP-4 Blank	0		
FO-1 FP-43	1	FO-3 FP-5	0		
FO-1 FP-44 Blank	0	FO-3 FP-6 Blank	0		
FO-1 FP-45	1	FO-3 FP-7	0		
FO-1 FP-46 Blank	0	FO-3 FP-8 Blank	0		
FO-1 FP-47	1	FO-3 FP-9	0		
FO-1 FP-48 Blank	0	FO-3 FP-10 Blank	0		
FO-1 FP-49	1	FO-3 FP-11	0		
FO-1 FP-50 Blank	0	FO-3 FP-12 Blank	0		
FO-1 FP-51	1	FO-3 FP-13	0		
FO-1 FP-52 Blank	0	FO-3 FP-14 Blank	0		
FO-1 FP-53	1	FO-3 FP-15	0		
FO-1 FP-54 Blank	0	FO-3 FP-16 Blank	0		
FO-1 FP-55	1	FO-4 FP-1	0		
FO-1 FP-56 Blank	0	FO-4 FP-2 Blank	0		
FO-1 FP-57	1	FO-4 FP-3	0		
FO-1 FP-58 Blank	0	FO-4 FP-4 Blank	0		
FO-1 FP-59	1	FO-5 FP-1	0		
FO-1 FP-60 Blank	0	FO-5 FP-2 Blank	0		
FO-1 FP-61	1	FO-5 FP-3	0		
FO-1 FP-62 Blank	0	FO-5 FP-4 Blank	0		
FO-1 FP-63	1	FO-5 FP-5	0		
FO-1 FP-64 Blank	0	FO-5 FP-6 Blank	0		
FO-1 FP-65	1				
FO-1 FP-66 Blank	0				
FO-1 FP-67	1				
FO-1 FP-68 Blank	0				
FO-1 FP-69	2				
FO-1 FP-70 Blank	0				
FO-1 FP-71	0				
FO-1 FP-72 Blank	0				
FO-1 FP-73	0				
FO-1 FP-74 Blank	0				
FO-1 FP-75	1				
FO-1 FP-76 Blank	0				
FO-1 FP-77	1				
FO-1 FP-78 Blank	0				
FO-1 FP-79	1				
FO-1 FP-80 Blank	0				
FO-2 FP-1	0				
FO-2 FP-2 Blank	0				
FO-2 FP-3	0				
FO-2 FP-4 Blank	0				
FO-2 FP-5	0				
FO-2 FP-6 Blank	0				
FO-2 FP-7	0				

* Zero in this column indicates an original page.

TECHNICAL MANUAL
NO. 9-2320-366-20-2

TECHNICAL ORDER
NO. 36A12-1C-1102-2

HEADQUARTERS
DEPARTMENTS OF THE ARMY
AND THE AIR FORCE
Washington, D.C., 15 September 1998

Unit Maintenance Manual
M1083 SERIES, 5-TON, 6 x 6,
MEDIUM TACTICAL VEHICLES (MTV)
VOLUME NO. 2 OF 5

MODEL	NSN	EIC
TRK, CAR., MTV, M1083 W/WN W/O WN	2320-01-360-1895 2320-01-354-3386	BT3 BR2
TRK, CAR., MTV, W/MATL HDLG EQPT (MHE), M1084	2320-01-354-3387	BR3
TRK, CAR., MTV, LWB, M1085 W/WN W/O WN	2320-01-360-1897 2320-01-354-4530	BT5 BR7
TRK, CAR., MTV, LWB, W/MATL HDLG EQPT (MHE), M1086	2320-01-354-4531	BR8
TRK, TRACTOR, MTV, M1088 W/WN W/O WN	2320-01-360-1892 2320-01-355-4332	BTY BTJ
TRK, WKR, MTV, M1089	2320-01-354-4528	BR4
TRK, DUMP, MTV, M1090 W/WN W/O WN	2320-01-360-1893 2320-01-354-4529	BTZ BR5
TRK, CHAS, MTV, M1092	2320-01-354-3382	BRZ
TRK, CAR., MTV, AIR DROP, M1093 W/WN W/O WN	2320-01-360-1896 2320-01-355-3063	BT4 BR9
TRK, DUMP, MTV, AIR DROP, M1094 W/WN W/O WN	2320-01-360-1984 2320-01-355-3062	BT2 BTK
TRK, CHAS, MTV, LWB, M1096	2320-01-354-4527	BR6

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028 (Recommended Changes to Equipment Technical Publications), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <http://aeeps.ria.army.mil>. If you need a password, scroll down and click on "ACCESS REQUEST FORM". The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax or Email your letter or DA Form 2028 direct to: AMSTA-LC-CI/TECH PUBS, TACOM-RI, 1 Rock Island Arsenal, Rock Island, IL 61299-7630. The email address is TACOM-TECH-PUBS@ria.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

DISTRIBUTION STATEMENT A. Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

	Page
HOW TO USE THIS MANUAL	ii
ELECTRICAL SYSTEM TROUBLESHOOTING (CONT)	2-943
TRANSMISSION SYSTEM TROUBLESHOOTING	2-1581
PROPELLER SHAFT TROUBLESHOOTING	2-1823
POWER TAKE-OFF (PTO) TROUBLESHOOTING	2-1831
BRAKE SYSTEM TROUBLESHOOTING	2-1835
AIR SYSTEM TROUBLESHOOTING	2-1947
WHEEL TROUBLESHOOTING	2-1989
HYDRAULIC SYSTEM TROUBLESHOOTING	2-1997
APPENDIXES	
A. REFERENCES	A-1
B. MAINTENANCE ALLOCATION CHART	B-1
C. TOOLS IDENTIFICATION LIST	C-1
D. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST	D-1
E. ILLUSTRATED LIST OF MANUFACTURED ITEMS	E-1
F. TORQUE LIMITS	F-1
G. MANDATORY REPLACEMENT PARTS	G-1
H. LUBRICATION ORDER	H-1
J. ADDITIONAL AUTHORIZATION LIST (AAL)	H-1
K. TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART	K-1
SUBJECT INDEX	Index-1
GLOSSARY	Glossary-1

LIST OF ILLUSTRATIONS

Figure No.	Figure Title	Page
E-1.	Brake Adjusting Tool Support	E-5
E-2.	Brake Plunger Seal Driver	E-6
E-3.	Cab Support Tool Strut and Cab Rest	E-7
E-4.	Cab Support Tool Seat	E-8
E-5.	Cab Support Tool Seat Layout	E-9

Figure No.	Figure Title	Page
E-6.	Cab Support Tool Assembly	E-10
E-7.	Dump Body Lifting Bracket	E-11
E-8.	Rear, Top, and Guide Plate	E-12
E-9.	Front and Mounting Plate	E-13
E-10.	Headlight Adjustment Screen	E-14
E-11.	M1089 30K Winch Test Adapter	E-15
E-12.	M1089 Solenoid Test Adapter	E-16
E-13.	Not Used
E-14.	Lanyard Assembly	E-23
E-15.	CTIS Seal Driver	E-25
E-16.	Wheel Hub Grease Seal Driver	E-26
E-17.	Purge Valve Tool	E-28
E-18.	M1089 30K Winch Pneumatic Test Adapter	E-31

LIST OF TABLES

Table No.	Table Title	Page
2-12.2	Main Winch LH/RH Freespool Switch Terminal Blocks	2-1446.3
2-13.	Actuator Voltage Test	2-1459
2-14.	Actuator Solenoid Resistance Test	2-1461
2-15.	Remote Control Box Continuity Test	2-1463
2-16.	Remote Control Box Switch Continuity Test	2-1465
2-17.	Remote Control Box Switch Continuity Test	2-1467
2-18.	Transmission System Fault Index	2-1581
2-19.	Transmission Sump Oil Temperature Sensor Resistance Readings	2-1619
2-20.	WTEC II Cab Transmission Harness Transmission Solenoid Test Points	2-1625
2-21.	Connector P119 Transmission Solenoid Resistance Test Points	2-1627
2-22.	Transmission Solenoid Resistance Readings	2-1627
2-23.	Main Code 43 Sub Code 21 and 26 High Side Test Points	2-1629
2-24.	Main Code 43 Sub Code 21 and 26 Low Side Test Points	2-1631
2-25.	Transmission Solenoid F and G Resistance Test Points	2-1633
2-26.	Sub Code Range	2-1641
2-27.	WTEC II Cab Transmission Harness Continuity Check	2-1665
2-28.	Off-Going Clutch Pressure Tap	2-1671
2-29.	Clutch Pressure Tap	2-1675
2-30.	Off-Going Clutch Pressure Tap	2-1679
2-31.	Clutch Pressure Tap	2-1685
2-32.	Clutch Pressure Tap	2-1691
2-33.	Clutch Pressure Tap	2-1697
2-34.	Transmission Sump Oil Temperature Sensor Resistance Readings	2-1741
2-35.	WTEC III Cab Transmission Harness Transmission Solenoid Test Points	2-1749
2-36.	Connector P119 Transmission Solenoid Resistance Test Points	2-1751
2-37.	Transmission Solenoid Resistance Readings	2-1751
2-38.	Sub Code Range	2-1759
2-39.	WTEC III Cab Transmission Harness Continuity Check	2-1773
2-40.	Off-Going Clutch Pressure Tap	2-1779
2-41.	Clutch Pressure Tap	2-1783
2-42.	Off-Going Clutch Pressure Tap	2-1787
2-43.	Clutch Pressure Tap	2-1793
2-44.	Clutch Pressure Tap	2-1799

LIST OF TABLES (CONT)

Table No.	Table Title	Page
2-45.	Clutch Pressure Tap	2-1805
2-46.	Propeller Shaft Fault Index	2-1823
2-47.	PTO Fault Index	2-1831
2-48.	Brake System Fault Index	2-1835
2-48.1.	Air Hose Numbers	2-1889
2-48.2.	Air Hose Numbers	2-1891
2-48.3.	Air Hose Numbers	2-1893
2-49.	Air System Fault Index	2-1947
2-49.1.	Emergency Gladhand Hose Numbers	2-1976.1
2-49.2.	Emergency Gladhand Hose Numbers	2-1976.3
2-49.3.	Air Brake Protecting Valve Control Hose Numbers	2-1976.5
2-49.4.	Air Brake Protecting Valve Control Hose Numbers	2-1976.7
2-49.5.	Service Gladhand Hose Numbers	2-1976.15
2-49.6.	Service Gladhand Hose Numbers	2-1976.17
2-49.7.	Air Brake Protecting Valve Supply Hose Numbers	2-1976.19
2-49.8.	Load Sensing Valve Control Port Hose Numbers	2-1976.25
2-49.9.	Booster Valve Delivery Hose Numbers	2-1976.27
2-49.10.	Inversion Valve Control Port Hose Numbers	2-1976.35
2-50.	Wheel Fault Index	2-1989
2-51.	Hydraulic System Fault Index	2-1997
E-1.	Pneumatic Tube Lengths	E-17
E-2.	Non-Metallic Electrical Cable Conduit Lengths	E-21
E-3.	M1089 30K Air Hose Lengths and Fittings	E-29
F-1.	Dry Torque Limits for SAE and ANSI Screws and Free Spinning Nuts	F-2
F-2.	Dry Torque Limits for SAE and ANSI Prevailing Torque Nuts	F-4
F-3.	Dry Torque Limits for Metric Screws and Free Spinning Nuts	F-5
F-4.	Dry Torque Limits for Metric Prevailing Torque Nuts	F-6
F-5.	Wet Torque Limits for SAE and ANSI Screws and Free Spinning Nuts	F-7

HOW TO USE THIS MANUAL

OVERVIEW

This Technical Manual (TM) is provided to help you maintain the MTV at the Unit Maintenance level. Because of its size, it is divided into five volumes. Volume 2 contains the following major sections in order of appearance:

- **WARNING SUMMARY.** Provides a summary of the most important warnings that apply throughout the manual.
- **CHAPTER 2, VEHICLE MAINTENANCE.** This chapter contains the continuation of the troubleshooting tables.
- **APPENDIX A, REFERENCES.** Lists publications used with the MTV.
- **APPENDIX B, MAINTENANCE ALLOCATION CHART.** The maintenance allocation chart denotes the level of maintenance which performs specific maintenance tasks and the time required. It also lists tools and special tools required for each task.

- **APPENDIX C, TOOLS IDENTIFICATION LIST.** Lists equipment used in the performance of maintenance and references publications which contain information regarding the equipment.
- **APPENDIX D, EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST.** Lists expendable and durable items used in the performance of maintenance.
- **APPENDIX E, ILLUSTRATED LIST OF MANUFACTURED ITEMS.** Illustrates and describes items that must be fabricated from bulk materials for repair of the MTV.
- **APPENDIX F, TORQUE LIMITS.** Lists the standard torque values for specific attaching hardware.
- **APPENDIX G, MANDATORY REPLACEMENT PARTS.**
- **APPENDIX H, LUBRICATION ORDER.**
- **APPENDIX J, ADDITIONAL AUTHORIZATION LIST (AAL).**
- **APPENDIX K, TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART.** Lists actions required to mate different transmission configurations with WTEC II or WTEC III controls.
- **SUBJECT INDEX.** Lists important subjects contained in volume 2 in alphabetical order and gives the associated paragraph number.

FINDING INFORMATION

There are several ways to find the information you need in this manual. They are as follows:

- **FRONT COVER INDEX.** The front cover index contains a list of the most important topics contained in each volume. It features a black box at the right edge of the cover which corresponds with a black box on the page containing the topic. The topics listed on the front cover are highlighted in the table of contents with a box.
- **TABLE OF CONTENTS.** Lists chapters, sections, appendixes, and indexes with page numbers in order of appearance.
- **CHAPTER INDEXES.** List paragraphs contained in the individual chapters with paragraph and page numbers in order of appearance.
- **SYMPTOM INDEX.** Lists malfunctions contained in the troubleshooting table with page numbers in order of appearance.

TROUBLESHOOTING

Troubleshooting is contained in chapter 2. When a malfunction occurs, look at the symptom index for the vehicle troubleshooting table in chapter 2. Find the malfunction in the index. Turn to the page number listed for the malfunction in the troubleshooting table. Perform the steps required to correct the malfunction. If you can't find the malfunction, or the malfunction is not corrected, notify your supervisor.

MAINTENANCE

- **SCHEDULED MAINTENANCE.** Your scheduled maintenance is located in table 2-1, PMCS. These checks and services are mandatory at the intervals listed. Always follow the WARNINGS and CAUTIONS.

MAINTENANCE (CONT)

- **UNSCHEDULED MAINTENANCE.** Unscheduled maintenance is located in chapters 3 through 24. The PMCS and troubleshooting tables often reference you to these procedures. When you perform maintenance, look over the entire procedure before starting. Make sure you have the necessary tools and materials at hand. Always follow the **WARNINGS** and **CAUTIONS**.

FOLLOW THESE GUIDELINES WHEN USING THIS MANUAL:

- Become familiar with the entire maintenance procedure before beginning a maintenance task.
- Read all **WARNINGS** and **CAUTIONS** before performing any procedures.

CHAPTER 2 VEHICLE MAINTENANCE (CONT)

2-16. ELECTRICAL SYSTEM TROUBLESHOOTING (CONT)	2-943
2-17. TRANSMISSION SYSTEM TROUBLESHOOTING	2-1581
2-18. PROPELLER SHAFT TROUBLESHOOTING	2-1823
2-19. POWER TAKE-OFF (PTO) TROUBLESHOOTING	2-1831
2-20. BRAKE SYSTEM TROUBLESHOOTING	2-1835
2-21. AIR SYSTEM TROUBLESHOOTING	2-1947
2-22. WHEEL TROUBLESHOOTING	2-1989
2-23. HYDRAULIC SYSTEM TROUBLESHOOTING	2-1997

Volume 3

2-24. CENTRAL TIRE INFLATION SYSTEM (CTIS) TROUBLESHOOTING	2-2007
2-25. AXLE TROUBLESHOOTING	2-2143
2-26. STEERING TROUBLESHOOTING	2-2151
2-27. FIFTH WHEEL TROUBLESHOOTING	2-2173
2-28. SUSPENSION SYSTEM TROUBLESHOOTING	2-2189
2-29. 15K SELF-RECOVERY WINCH (SRW) SYSTEM TROUBLESHOOTING	2-2205
2-30. STEERING HYDRAULIC SYSTEM TROUBLESHOOTING	2-2213
2-31. AIR TRANSPORT TROUBLESHOOTING	2-2219
2-32. DUMP BODY HYDRAULIC SYSTEM TROUBLESHOOTING	2-2237
2-33. WRECKER HYDRAULIC SYSTEM TROUBLESHOOTING	2-2243
2-34. SPECIAL PURPOSE KIT TROUBLESHOOTING	2-2271
2-35. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HYDRAULIC TROUBLESHOOTING	2-2409
2-36. CAB TILT AND SPARE TIRE RETAINER TROUBLESHOOTING	2-2413
2-37. M1089 AIR SYSTEM TROUBLESHOOTING	2-2419
2-38. FRAME TROUBLESHOOTING	2-2435
 Section V. MAINTENANCE PROCEDURES	 2-2441
2-39. MAINTENANCE INTRODUCTION	2-2441
2-40. GROUND HANDLING	2-2441
2-41. GENERAL REMOVAL INSTRUCTIONS	2-2441
2-42. GENERAL DISASSEMBLY INSTRUCTIONS	2-2442
2-43. GENERAL CLEANING INSTRUCTIONS	2-2443
2-44. GENERAL INSPECTION INSTRUCTIONS	2-2446
2-45. GENERAL REPAIR INSTRUCTIONS	2-2446
2-46. GENERAL ASSEMBLY INSTRUCTIONS	2-2447
2-47. GENERAL INSTALLATION INSTRUCTIONS	2-2448
2-48. PREPARATION FOR STORAGE OR SHIPMENT INTRODUCTION	2-2448
2-49. PREPARATION FOR STORAGE OR SHIPMENT	2-2448
2-50. STORAGE MAINTENANCE PROCEDURES	2-2449

2-16. ELECTRICAL SYSTEM TROUBLESHOOTING (CONT)

Table 2-7. Electrical System Fault Index (Cont)

Fault No.	Description	Page
e85.	Central Tire Inflation System (CTIS) Does Not Operate	2-946
e86.	Central Tire Inflation System (CTIS) Does Not Inflate Tires	2-960
e87.	Central Tire Inflation System (CTIS) Does Not Deflate Tires	2-970
e88.	15K Self-Recovery Winch (SRW) Does Not Reel In or Pay Out	2-980
e89.	15K Self-Recovery Winch (SRW) Does Not Reel In	2-986
e90.	15K Self-Recovery Winch (SRW) Does Not Pay Out	2-998
e91.	Power Take-Off (PTO) Does Not Operate	2-1010
e92.	Electrical System Does Not Maintain a Charge	2-1050
e93.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Illumination Does Not Dim	2-1058
e94.	Differential Lock Solenoid Does Not Operate	2-1068
e95.	Engine Fan Runs Constantly	2-1094
e96.	Engine Fan Does Not Turn Off Using Radiator Fan Off Switch	2-1102
e97.	Ether Start Does Not Operate	2-1110
e98.	Excessive Condensation in Fuel	2-1126
e99.	Radio Does Not Operate	2-1130
e100.	Start Inhibit Pushbutton Does Not Operate	2-1136
e101.	Air Dryer Does Not Operate (All Models Except M1090/M1094)	2-1142
e102.	M1090/M1094 Air Dryer Does Not Operate	2-1148
e103.	Battery Tester Does Not Operate	2-1158
e104.	M1084/M1086 Material Handling Crane (MHC) Does Not Operate	2-1162
e105.	M1084/M1086 Material Handling Crane (MHC) Does Not Operate From Remote Control	2-1170
e106.	M1084/M1086 Material Handling Crane (MHC) Hoist Up Does Not Operate From Remote Station	2-1176
e107.	M1084/M1086 Material Handling Crane (MHC) Hoist Down Does Not Operate From Remote Station	2-1188
e108.	M1084/M1086 Material Handling Crane (MHC) Boom Up Does Not Operate From Remote Station	2-1200
e109.	M1084/M1086 Material Handling Crane (MHC) Boom Down Does Not Operate From Remote Station	2-1212
e110.	M1084/M1086 Material Handling Crane (MHC) Telescope In Does Not Operate From Remote Station	2-1224
e111.	M1084/M1086 Material Handling Crane (MHC) Telescope Out Does Not Operate From Remote Station	2-1236
e112.	M1084/M1086 Material Handling Crane (MHC) Swing CW Does Not Operate From Remote Station	2-1248
e113.	M1084/M1086 Material Handling Crane (MHC) Swing CCW Does Not Operate From Remote Station	2-1260
e114.	M1084/M1086 Material Handling Crane (MHC) Overload Shutdown System Does Not Activate	2-1272
e115.	M1084/M1086 Material Handling Crane (MHC) Overload Shutdown System Stays Activated	2-1274
e116.	M1084/M1086 Material Handling Crane (MHC) Hoist Up Lockout Does Not Activate	2-1276

2-16. ELECTRICAL SYSTEM TROUBLESHOOTING (CONT)

Table 2-7. Electrical System Fault Index (Cont)

Fault No.	Description	Page
e117.	M1084/M1086 Material Handling Crane (MHC) Boom Down Lockout Does Not Activate	2-1280
e118.	M1084/M1086 Material Handling Crane (MHC) Boom Up Lockout Does Not Activate	2-1284
e119.	M1084/M1086 Material Handling Crane (MHC) Telescope Out Lockout Does Not Activate	2-1288
e120.	M1089 Material Handling Crane (MHC) Does Not Operate	2-1292
e121.	M1089 Material Handling Crane (MHC) Does Not Operate From Remote Control	2-1300
e122.	M1089 Material Handling Crane (MHC) Hoist Up Does Not Operate From Remote Station	2-1306
e123.	M1089 Material Handling Crane (MHC) Hoist Down Does Not Operate From Remote Station	2-1318
e124.	M1089 Material Handling Crane (MHC) Boom Up Does Not Operate From Remote Station	2-1330
e125.	M1089 Material Handling Crane (MHC) Boom Down Does Not Operate From Remote Station	2-1342
e126.	M1089 Material Handling Crane (MHC) Telescope In Does Not Operate From Remote Station	2-1354
e127.	M1089 Material Handling Crane (MHC) Telescope Out Does Not Operate From Remote Station	2-1366
e128.	M1089 Material Handling Crane (MHC) Swing CW Does Not Operate From Remote Station	2-1378
e129.	M1089 Material Handling Crane (MHC) Swing CCW Does Not Operate From Remote Station	2-1390
e130.	M1089 Material Handling Crane (MHC) Hoist Up Lockout Does Not Activate	2-1402
e131.	M1089 Material Handling Crane (MHC) Boom Down Lockout Does Not Activate	2-1406
e132.	M1089 Material Handling Crane (MHC) Boom Up Lockout Does Not Activate	2-1410
e133.	M1089 Material Handling Crane (MHC) Telescope Out Lockout Does Not Activate	2-1414
e134.	M1089 Material Handling Crane (MHC) Overload Shutdown System Does Not Activate	2-1418
e135.	M1089 Material Handling Crane (MHC) Overload Shutdown System Stays Activated	2-1420
e136.	All M1089 Control Functions Do Not Operate From Wrecker Control Panel and Wrecker Remote Control	2-1422
e137.	All Wrecker Functions Do Not Operate From Wrecker Remote Control	2-1436
e138.	All Wrecker Functions Do Not Operate From Wrecker Control Panel	2-1442
e138A.	M1089 LH or RH 30K Winch Does Not Pay In	2-1446
e139.	Main Winch LH or RH Speed Switch Does Not Operate From Wrecker Control Panel	2-1446.12
e140.	Main Winch LH or RH Freespool Switch Does Not Operate From Wrecker Control Panel	2-1452
e141.	One Wrecker Function Does Not Operate From Wrecker Remote Control	2-1458
e142.	M1090/M1094 Tailgate Release Does Not Operate	2-1468
e143.	M1090/M1094 Dump Body Does Not Raise	2-1480
e144.	M1090/M1094 Dump Body Does Not Lower	2-1492
e145.	Transmission Auxiliary Oil Cooler Fan(s) Runs Constantly	2-1504

Table 2-7. Electrical System Fault Index (Cont)

Fault No.	Description	Page
e146.	Transmission Auxiliary Oil Cooler Fan Does Not Operate (All Models Except M1088/M1089)	2-1508
e147.	M1088/M1089 Transmission Auxiliary Oil Cooler Fan Does Not Operate	2-1526
e148.	M1088/M1089 Worklights Do Not Illuminate	2-1540
e149.	M1088/M1089 (LH) Worklights Do Not Illuminate	2-1558
e150.	M1088/M1089 (RH) Worklights Do Not Illuminate	2-1562
e151.	M1088/M1089 Worklights Do Not Illuminate in Blackout Mode With Blackout Override Switch On	2-1566
e152.	M1084/M1086 Worklights Do Not Illuminate	2-1576

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Materials/Parts
 Wire, Elect, 50 ft (Item 71, Appendix D)


Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)

Personnel Required
 (2)

References
 TM 9-4910-571-12&P

NOTE

Perform Electrical System Troubleshooting e1. Circuit Breaker Does Not Operate on circuit breaker CB40 prior to beginning this task.



CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST


- (1) Start engine (TM 9-2320-366-10-1).
- (2) Allow air pressure to build until FRONT BRAKEAIR and REAR BRAKE AIR pressure gages read approximately 120 PSI.
- (3) Shut down engine (TM 9-2320-366-10-1).
- (4) Disconnect connector P110 from CTIS ECU.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector P110 socket T.
- (7) Connect negative (-) probe of multimeter to known good ground and note reading on multimeter.
- (8) If continuity is not present, go to step 21 of this fault.



XBE82011

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)

KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty manifold valve assembly. Faulty CTIS ECU. Faulty WTEC II / WTEC III dashboard cable assembly. Faulty CTIS cable assembly.




TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.

WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Position master power switch to on (TM 9-2320-366-10-1).
- (2) Set multimeter to volts DC.
- (3) Connect positive (+) probe of multimeter to connector P110 socket H.
- (4) Connect negative (-) probe of multimeter to known good ground and note reading on multimeter.
- (5) If 24 VDC is not present, go to step 25 of this fault.
- (6) Position master power switch to off (TM 9-2320-366-10-1).




P110

XBE82021

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)


KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty manifold valve assembly. Faulty CTIS ECU. Faulty WTEC II / WTEC III dashboard cable assembly. Faulty CTIS cable assembly.



TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.

CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P110 socket F.
- (3) Connect negative (-) probe of multimeter to known good ground and note reading on multimeter.
- (4) If continuity is not present, go to step 26 of this fault.




XBE82031

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)

KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty manifold valve assembly. Faulty CTIS ECU. Faulty CTIS cable assembly.



KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty manifold valve assembly. Faulty CTIS ECU. Faulty CTIS cable assembly.




TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.

CONTINUITY TEST
<ol style="list-style-type: none"> (1) Remove kick panel (para 16-3). (2) Disconnect connector P112 from pneumatic controller connector. (3) Disconnect connector J111 from connector P111. (4) Set multimeter to ohms. (5) Connect positive (+) probe of multimeter to connector P111 pin A. (6) Connect negative (-) probe of multimeter to connector P112 socket A and note reading on multimeter. (7) If continuity is not present, replace CTIS cable assembly (para 7-60).



CONTINUITY TEST
<ol style="list-style-type: none"> (1) Set multimeter to ohms. (2) Connect positive (+) probe of multimeter to connector P111 pin A. (3) Connect negative (-) probe of multimeter to connector P112 socket B and note reading on multimeter. (4) If continuity is not present, replace CTIS cable assembly (para 7-60). (5) Connect connector J111 from connector P111.




XBE82041

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)


KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty manifold valve assembly. Faulty CTIS ECU. Faulty CTIS cable assembly.

KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty manifold valve assembly. Faulty CTIS ECU. Faulty CTIS cable assembly.




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P110 socket R.
- (3) Connect negative (-) probe of multimeter to connector P112 socket D and note reading on multimeter.
- (4) If continuity is not present, replace CTIS cable assembly (para 7-60).



P110



P112

XBE82051


CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P110 socket B.
- (3) Connect negative (-) probe of multimeter to connector P112 socket F and note reading on multimeter.
- (4) If continuity is not present, replace CTIS cable assembly (para 7-60).



e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)

KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty manifold valve assembly. Faulty CTIS ECU. Faulty CTIS cable assembly.


KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty manifold valve assembly. Faulty CTIS ECU. Faulty CTIS cable assembly.



- | CONTINUITY TEST |
|--|
| <ol style="list-style-type: none"> (1) Set multimeter to ohms. (2) Connect positive (+) probe of multimeter to connector P110 socket C. (3) Connect negative (-) probe of multimeter to connector P112 socket E and note reading on multimeter. (4) If continuity is not present, replace CTIS cable assembly (para 7-60). |



- | CONTINUITY TEST |
|---|
| <ol style="list-style-type: none"> (1) Set multimeter to ohms. (2) Connect positive (+) probe of multimeter to connector P110 socket P. (3) Connect negative (-) probe of multimeter to terminal lug TL50 and note reading on multimeter. (4) If continuity is not present, replace CTIS cable assembly (para 7-60). (5) Connect connector P110 to CTIS ECU. |



XBE8206A


e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)

KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty manifold valve assembly. Faulty CTIS ECU. Faulty CTIS cable assembly.

10.

Is 30-80 ohms resistance present from pneumatic controller connector pin D to pin B?

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If 30-80 ohms resistance is not present, manifold valve assembly is faulty.




KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty manifold valve assembly. Faulty CTIS ECU. Faulty CTIS cable assembly.



11.

Is 30-80 ohms resistance present from pneumatic controller connector pin F to pin A?

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If 30-80 ohms resistance is not present, manifold valve assembly is faulty.



RESISTANCE TEST
<ol style="list-style-type: none"> (1) Set multimeter to ohms. (2) Connect positive (+) probe of multimeter to pneumatic controller connector pin D. (3) Connect negative (-) probe of multimeter to pneumatic controller connector pin B and note reading on multimeter. (4) If 30-80 ohms resistance is not present, replace manifold valve assembly (para 12-7).



PNEUMATIC
CONTROLLER
CONNECTOR

RESISTANCE TEST
<ol style="list-style-type: none"> (1) Set multimeter to ohms. (2) Connect positive (+) probe of multimeter to pneumatic controller connector pin F. (3) Connect negative (-) probe of multimeter to pneumatic controller connector pin A and note reading on multimeter. (4) If 30-80 ohms resistance is not present, replace manifold valve assembly (para 12-7).


XBE8207A

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)

KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty manifold valve assembly. Faulty CTIS ECU. Faulty CTIS cable assembly.


12.
Is 30-80 ohms resistance present from pneumatic controller connector pin E to pin A?

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If 30-80 ohms resistance is not present, manifold valve assembly is faulty.




RESISTANCE TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to pneumatic controller connector pin E.
- (3) Connect negative (-) probe of multimeter to pneumatic controller connector pin A and note reading on multimeter.
- (4) If 30-80 ohms resistance is not present, repair manifold valve assembly (para 12-7).
- (5) Connect connector P112 to pneumatic controller connector.



**PNEUMATIC
CONTROLLER
CONNECTOR**




XBE82081

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)

KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK. Manifold valve assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty CTIS ECU. Faulty CTIS cable assembly.

KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK. Manifold valve assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty CTIS ECU. Faulty CTIS cable assembly.




TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If 1-50 ohms resistance is not present, pressure transducer is faulty.


TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If 1-50 ohms resistance is not present, pressure transducer is faulty.

RESISTANCE TEST

- (1) Disconnect connector P113 from pressure transducer connector.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to pressure transducer connector pin A.
- (4) Connect negative (-) probe of multimeter to pressure transducer connector pin B and note reading on multimeter.
- (5) If 1-50 ohms resistance is not present, replace pressure transducer (para 12-7).



**PRESSURE
TRANSDUCER
CONNECTOR**




RESISTANCE TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to pressure transducer connector pin B.
- (3) Connect negative (-) probe of multimeter to pressure transducer connector pin C and note reading on multimeter.
- (4) If 1-50 ohms resistance is not present, replace pressure transducer (para 12-7).

xbe82091

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)


KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK. Manifold valve assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty CTIS ECU. Faulty CTIS cable assembly.




TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If 1-50 ohms resistance is not present, pressure transducer is faulty.

RESISTANCE TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to pressure transducer connector pin C.
- (3) Connect negative (-) probe of multimeter to pressure transducer connector pin A and note reading on multimeter.
- (4) If 1-50 ohms resistance is not present, replace pressure transducer (para 12-7).



**PRESSURE
TRANSDUCER
CONNECTOR**




xbe82101

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)

KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK. Manifold valve assembly OK. Air pressure transducer OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty CTIS ECU. Faulty CTIS cable assembly.


KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK. Manifold valve assembly OK. Air pressure transducer OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty CTIS ECU. Faulty CTIS cable assembly.



TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.

CONTINUITY TEST
<ol style="list-style-type: none"> (1) Disconnect connector P110 from CTIS ECU. (2) Set multimeter to ohms. (3) Connect positive (+) probe of multimeter to connector P110 socket c. (4) Connect negative (-) probe of multimeter to connector P113 socket C and note reading on multimeter. (5) If continuity is not present, replace CTIS cable assembly (para 7-60).




XBE82111

CONTINUITY TEST
<ol style="list-style-type: none"> (1) Set multimeter to ohms. (2) Connect positive (+) probe of multimeter to connector P110 socket b. (3) Connect negative (-) probe of multimeter to connector P113 socket B and note reading on multimeter. (4) If continuity is not present, replace CTIS cable assembly (para 7-60).

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)


KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK. Manifold valve assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty CTIS ECU. Faulty CTIS cable assembly.

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.





KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK. WTEC II / WTEC III dashboard cable assembly OK. Manifold valve assembly OK.
POSSIBLE PROBLEMS
Faulty air pressure transducer. Faulty CTIS ECU. Faulty CTIS cable assembly.

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If connector P113 is short circuited, CTIS cable assembly is faulty.



CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P110 socket j.
- (3) Connect negative (-) probe of multimeter to connector P113 socket A and note reading on multimeter.
- (4) If continuity is not present, replace CTIS cable assembly (para 7-60).





XBE82121

CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P113 socket A.
- (3) Connect negative (-) probe of multimeter to known good ground and note reading on multimeter.
- (4) Connect negative (-) probe of multimeter to all other sockets on connector P113 and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter to connector P113 socket B.
- (6) Connect negative (-) probe of multimeter to known good ground and note reading on multimeter.
- (7) Connect negative (-) probe of multimeter to all other sockets on connector P113 and note reading on multimeter.
- (8) Connect positive (+) probe of multimeter to connector P113 socket C.
- (9) Connect negative (-) probe of multimeter to known good ground and note reading on multimeter.
- (10) Connect negative (-) probe of multimeter to all other sockets on connector P113 and note reading on multimeter.
- (11) If continuity not present is steps 3, 4, 6, 7, 9, and 10, go to step 20 of this fault.
- (12) If continuity present is steps 3, 4, 6, 7, 9, or 10, replace CTIS cable assembly (para 7-60).

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Connect connector P110 from CTIS ECU.
- (2) Position master power switch to on (TM 9-2320-366-10-1).
- (3) Set multimeter to volts DC.
- (4) Connect positive (+) probe of multimeter to connector P113 socket B.
- (5) Connect negative (-) probe of multimeter to known good ground and note reading on multimeter.
- (6) Position master power switch to off (TM 9-2320-366-10-1).
- (7) If 4.9-5.1 VDC is not present, replace CTIS ECU (para 12-6).
- (8) If 4.9-5.1 VDC is present, replace air pressure transducer (para 12-7).


NOTE

Perform steps (9) and (10) if 4.9-5.1 VDC is not present.


- (9) Connect connector P113 to air pressure transducer connector.
- (10) Install kick panel (para 16-3).

CONTINUITY TEST

- (1) Connect connector P110 to CTIS ECU.
- (2) Disconnect connector P84 from air pressure switch.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to air pressure switch pin A.
- (5) Connect negative (-) probe of multimeter to air pressure switch pin B and note reading on multimeter.
- (6) If continuity is not present, replace air pressure switch (para 23-13).



xbe82131




XBE82141

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)


KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK.
POSSIBLE PROBLEMS
Faulty start and charging cable assembly. Faulty WTEC II / WTEC III dashboard cable assembly. Faulty CTIS cable assembly.

KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK.
POSSIBLE PROBLEMS
Faulty start and charging cable assembly. Faulty WTEC II / WTEC III dashboard cable assembly. Faulty CTIS cable assembly.



CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P84 socket A.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3032 from connector P84 socket A to terminal lug TL85 (para 2-45) or replace start and charging cable assembly (para 7-132).
- (5) Connect connector P84 to air pressure switch.



xbe82151


CONTINUITY TEST

- (1) Disconnect connector P110 from CTIS ECU.
- (2) Remove kick panel (para 16-3).
- (3) Disconnect connector P111 from connector J111.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to connector P111 pin F.
- (6) Connect negative (-) probe of multimeter to connector P110 socket T and note reading on multimeter.
- (7) If continuity is not present, replace CTIS cable assembly (para 7-60).







XBE82161

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)



CONTINUITY TEST

- (1) Connect connector P110 to CTIS ECU.
- (2) Remove instrument panel assembly for access (para 7-15).
- (3) Disconnect connector J43 from connector P43.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to connector J43 socket 2.
- (6) Connect negative (-) probe of multimeter to connector J111 socket F and note reading on multimeter.
- (7) If continuity is not present, repair wire 1790 from connector J43 socket 2 to connector J111 socket F (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (8) If continuity is present, repair wire 1790 from connector P43 pin 2 to connector P84 socket B (para 2-45) or replace start and charging cable assembly (para 7-132).
- (9) Connect connector P43 to connector J43.
- (10) Install instrument panel assembly (para 7-15).
- (11) Connect connector J111 to connector P111.
- (112) Install kick panel (para 16-3).




XBE82171

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)

KNOWN INFO
VOLTS gage registers in green zone with engine running. Circuit breaker CB40 OK. FRONT BRAKE AIR and REAR BRAKE AIR pressure gages read normal. Air pressure switch OK. Start and charging cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC II / WTEC III dashboard cable assembly. Faulty CTIS cable assembly.


25.
Is continuity present from connector J111 socket E to circuit breaker CB40 socket 7?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, wire 1911 from connector J111 socket E to circuit breaker CB40 socket 7 is faulty. If continuity is present, CTIS cable assembly is faulty.




CONTINUITY TEST

- (1) Connect connector P110 to CTIS ECU.
- (2) Remove kick panel (para 16-3).
- (3) Remove circuit breaker CB40 from PDP.
- (4) Disconnect connector P111 from connector J111.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector J111 socket E.
- (7) Connect negative (-) probe of multimeter to circuit breaker CB40 socket 7 and note reading on multimeter.
- (8) If continuity is not present, repair wire 1911 from connector J111 socket E to circuit breaker CB40 socket 7 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (9) If continuity is present, replace CTIS cable assembly (para 7-60).
- (10) Install circuit breaker CB40 on PDP.
- (11) Connect connector J111 to connector P111.
- (12) Install kick panel (para 16-3).




XBE82181

e85. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT OPERATE (CONT)



- CONTINUITY TEST**
- (1) Remove kick panel (para 16-3).
 - (2) Disconnect connector J111 from connector P111.
 - (3) Set multimeter to ohms.
 - (4) Connect positive (+) probe of multimeter to connector P110 socket F.
 - (5) Connect negative (-) probe of multimeter to connector P111 pin A and note reading on multimeter.
 - (6) If continuity is not present replace CTIS cable assembly (para 7-60).
 - (7) If continuity is present, repair wire 3031 from connector J111 socket A to terminal board TB2 position 35 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
 - (8) Connect connector J111 to connector P111.
 - (9) Install kick panel (para 16-3).
 - (10) Connect connector P110 to CTIS ECU.



XBE82191

e86. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT INFLATE TIRES

INITIAL SETUP

Equipment Condition

Engine shut down (TM 9-2320-366-10-1).

Personnel Required

(2)

References

TM 9-4910-571-12&P

Tools and Special Tools


Tool Kit, Genl Mech (Item 46, Appendix C)

STE/ICE-R (Item 41, Appendix C)

Multimeter, Digital (Item 22, Appendix C)


Materials/Parts

Wire, Elect, 50 ft (Item 71, Appendix D)



OPERATIONAL TEST

- (1) Disconnect connector P110 from CTIS ECU.
- (2) Connect connector P110 to a known-good CTIS ECU.
- (3) Start vehicle (TM 9-2320-366-10-1).
- (4) Allow air pressure to reach 85 psi.
- (5) Deflate tires (TM 9-2320-366-10-1).
- (6) If tires do not inflate, go to step 2 of this fault.
- (7) If tires inflate, replace CTIS ECU (para 12-6).
- (8) Shut down vehicle (TM 9-2320-366-10-1).
- (9) Disconnect connector P110 from known-good CTIS ECU.



STEERING WHEEL
REMOVED FOR
CLARITY


X2E8601A

ø86. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT INFLATE TIRES (CONT)

KNOWN INFO
CTIS deflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.

2.
Is continuity present between connector P110-B and connector P112-F?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.




KNOWN INFO
CTIS deflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.

3.
Is continuity present between connector P110-F and connector P112-A?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.



- | CONTINUITY TEST | |
|-----------------|--|
| (1) | Remove kick panel (para 16-3). |
| (2) | Disconnect connector P112 from manifold valve assembly. |
| (3) | Set multimeter to ohms. |
| (4) | Connect positive (+) probe of multimeter to connector P110-B. |
| (5) | Connect negative (-) probe of multimeter to connector P112-F and note reading on multimeter. |
| (6) | If continuity is not present, replace CTIS cable assembly (para 7-60). |



- | CONTINUITY TEST | |
|-----------------|--|
| (1) | Set multimeter to ohms. |
| (2) | Connect positive (+) probe of multimeter to connector P110-F. |
| (3) | Connect negative (-) probe of multimeter to connector P112-A and note reading on multimeter. |
| (4) | If continuity is not present, replace CTIS cable assembly (para 7-60). |




42E8602A

ø86. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT INFLATE TIRES (CONT)

KNOWN INFO
CTIS deflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.

4.
Is continuity present between connector P110-R and connector P112-D?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.




KNOWN INFO
CTIS deflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.

5.
Is continuity present between connector P110-F and connector P112-B?

TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.



CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter to connector P110-R.
	(3) Connect negative (-) probe of multimeter to connector P112-D and note reading on multimeter.
	(4) If continuity is not present, replace CTIS cable assembly (para 7-60).



CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter to connector P110-F.
	(3) Connect negative (-) probe of multimeter to connector P112-B and note reading on multimeter.
	(4) If continuity is not present, replace CTIS cable assembly (para 7-60).
	(5) Connect connector P112 to manifold valve assembly.


42E8603A

ø86. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT INFLATE TIRES (CONT)

KNOWN INFO
CTIS deflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.

6.
Is continuity present between connector P110-b and connector P113-B?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.



KNOWN INFO
CTIS deflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.


7.
Is continuity present between connector P110-c and connector P113-C?

TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.




CONTINUITY TEST	
	(1) Disconnect connector P113 from manifold valve assembly.
	(2) Set multimeter to ohms.
	(3) Connect positive (+) probe of multimeter to connector P110-b.
	(4) Connect negative (-) probe of multimeter to connector P113-B and note reading on multimeter.
	(5) If continuity is not present, replace CTIS cable assembly (para 7-60).


MANIFOLD VALVE ASSEMBLY



CONNECTOR P113



P113




P110

42E8604A

CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter to connector P110-c.
	(3) Connect negative (-) probe of multimeter to connector P113-C and note reading on multimeter.
	(4) If continuity is not present, replace CTIS cable assembly (para 7-60).

ø86. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT INFLATE TIRES (CONT)


KNOWN INFO
CTIS deflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.




TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty. If continuity is present, manifold valve assembly is faulty.



- | CONTINUITY TEST | |
|-----------------|--|
| (1) | Set multimeter to ohms. |
| (2) | Connect positive (+) probe of multimeter to connector P110-J. |
| (3) | Connect negative (-) probe of multimeter to connector P113-A and note reading on multimeter. |
| (4) | If continuity is not present, replace CTIS cable assembly (para 7-60). |
| (5) | If continuity is present, replace manifold valve assembly (para 12-7). |
| (6) | Connect connector P113 to manifold valve assembly. |
| (7) | Install kick panel (para 16-3). |
| (8) | Connect connector P110 to CTIS ECU. |




e87. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT DEFLATE TIRES	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	Materials/Parts Wire, Elect, 50 ft (Item 71, Appendix D)
References TM 9-4910-571-12&P	



OPERATIONAL TEST

- (1) Disconnect connector P110 from CTIS ECU.
- (2) Connect connector P110 to a known-good CTIS ECU.
- (3) Start vehicle (TM 9-2320-366-10-1).
- (4) Allow air pressure to reach 85 psi.
- (5) Deflate tires (TM 9-2320-366-10-1).
- (6) If tires do not deflate, go to step 2 of this fault.
- (7) If tires deflate, replace CTIS ECU (para 12-6).
- (8) Shut down vehicle (TM 9-2320-366-10-1).
- (9) Disconnect connector P110 from known-good CTIS ECU.



STEERING WHEEL
REMOVED FOR
CLARITY


X2E8701A

ø87. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT DEFLATE TIRES (CONT)

KNOWN INFO
CTIS inflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.

2.
Is continuity present between connector P110-C and connector P112-E?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.



KNOWN INFO
CTIS inflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.



3.
Is continuity present between connector P110-F and connector P112-A?

TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.



CONTINUITY TEST

- (1) Remove kick panel (para 16-3).
- (2) Disconnect connector P112 from manifold valve assembly.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector P110-C.
- (5) Connect negative (-) probe of multimeter to connector P112-E and note reading on multimeter.
- (6) If continuity is not present, replace CTIS cable assembly (para 7-60).



CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P110-F.
- (3) Connect negative (-) probe of multimeter to connector P112-A and note reading on multimeter.
- (4) If continuity is not present, replace CTIS cable assembly (para 7-60).

ø87. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT DEFLATE TIRES (CONT)

KNOWN INFO
CTIS inflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.

4.
Is continuity present between connector P110-R and connector P112-D?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.




KNOWN INFO
CTIS inflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.

5.
Is continuity present between connector P110-F and connector P112-B?

TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.



- | CONTINUITY TEST | |
|-----------------|--|
| | (1) Set multimeter to ohms. |
| | (2) Connect positive (+) probe of multimeter to connector P110-R. |
| | (3) Connect negative (-) probe of multimeter to connector P112-D and note reading on multimeter. |
| | (4) If continuity is not present, replace CTIS cable assembly (para 7-60). |




- | CONTINUITY TEST | |
|-----------------|--|
| | (1) Set multimeter to ohms. |
| | (2) Connect positive (+) probe of multimeter to connector P110-F. |
| | (3) Connect negative (-) probe of multimeter to connector P112-B and note reading on multimeter. |
| | (4) If continuity is not present, replace CTIS cable assembly (para 7-60). |
| | (5) Connect connector P112 to manifold valve assembly. |

87. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT DEFLATE TIRES (CONT)

KNOWN INFO
CTIS inflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.

6.
Is continuity present between connector P110-b and connector P113-B?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.



KNOWN INFO
CTIS inflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.



7.
Is continuity present between connector P110-c and connector P113-C?

TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty.



CONTINUITY TEST

- (1) Disconnect connector P113 from manifold valve assembly.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector P110-b.
- (4) Connect negative (-) probe of multimeter to connector P113-B and note reading on multimeter.
- (5) If continuity is not present, replace CTIS cable assembly (para 7-60).




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P110-c.
- (3) Connect negative (-) probe of multimeter to connector P113-C and note reading on multimeter.
- (4) If continuity is not present, replace CTIS cable assembly (para 7-60).

87. CENTRAL TIRE INFLATION SYSTEM (CTIS) DOES NOT DEFLATE TIRES (CONT)




KNOWN INFO
CTIS inflates tires. CTIS ECU OK.
POSSIBLE PROBLEMS
Faulty CTIS cable assembly. Faulty manifold valve assembly.



TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, CTIS cable assembly is faulty. If continuity is present, manifold valve assembly is faulty.




- | CONTINUITY TEST |
|--|
| (1) Set multimeter to ohms. |
| (2) Connect positive (+) probe of multimeter to connector P110-J. |
| (3) Connect negative (-) probe of multimeter to connector P113-A and note reading on multimeter. |
| (4) If continuity is not present, replace CTIS cable assembly (para 7-60). |
| (5) If continuity is present, replace manifold valve assembly (para 12-7). |
| (6) Connect connector P113 to manifold valve assembly. |
| (7) Install kick panel (para 16-3). |
| (8) Connect connector P110 to CTIS ECU. |



42E8705A

e88. 15K SELF-RECOVERY WINCH (SRW) DOES NOT REEL IN OR PAY OUT	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P
Materials/Parts Wire, Elect, 50 ft (Item 71, Appendix D)	






WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Remove auxiliary panel and tilt back. Do not disconnect connectors (para 7-8).
- (2) Disconnect connector P902 from winch power switch.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to connector P902 terminal 6.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1).
- (7) Position PTO switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If 24 vdc is not present, repair wire 1904 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (9) Position PTO switch to off (TM 9-2320-366-10-1).
- (10) Position master power switch to off (TM 9-2320-366-10-1).



X2E8801A


ø88. 15K SELF-RECOVERY WINCH (SRW) DOES NOT REEL IN OR PAY OUT (CONT)

KNOWN INFO
Circuit breaker OK. PTO OK.
POSSIBLE PROBLEMS
Faulty winch power switch. Faulty auxiliary panel cable assembly. Faulty WINCH IN/OUT switch.





TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, winch power switch is faulty.






- | CONTINUITY TEST | |
|-----------------|--|
| (1) | Set multimeter to ohms. |
| (2) | Connect positive (+) probe of multimeter to winch power switch terminal 6. |
| (3) | Connect negative (-) probe of multimeter to winch power switch terminal 2. |
| (4) | Position winch power switch to on (TM 9-2320-366-10-1) and note reading on multimeter. |
| (5) | If continuity is not present, replace winch power switch (para 7-18). |
| (6) | Position winch power switch to off (TM 9-2320-366-10-1). |
| (7) | Connect connector P902 to winch power switch. |



X2E8802A

ø88. 15K SELF-RECOVERY WINCH (SRW) DOES NOT REEL IN OR PAY OUT (CONT)





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Disconnect connector P903 from WINCH IN/OUT switch.
- (2) Set multimeter to volts dc.
- (3) Connect positive (+) probe of multimeter to connector P903 terminal 3.
- (4) Connect negative (-) probe of multimeter to ground.
- (5) Position master power switch to on (TM 9-2320-366-10-1).
- (6) Position PTO switch to on (TM 9-2320-366-10-1).
- (7) Position winch power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If 24 vdc is not present, repair wire 1924 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (9) Position winch power switch to off (TM 9-2320-366-10-1).
- (10) Position PTO switch to off (TM 9-2320-366-10-1).
- (11) Position master power switch to off (TM 9-2320-366-10-1).

STEERING WHEEL
REMOVED FOR
CLARITY



CONNECTOR P903




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to WINCH IN/OUT switch terminal 3.
- (3) Connect negative (-) probe of multimeter to WINCH IN/OUT switch terminal 1.
- (4) Position WINCH IN/OUT switch to in (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If continuity is not present, replace WINCH IN/OUT switch (para 7-18).
- (6) If continuity is present, fault not corrected. Notify DS Maintenance.
- (7) Connect connector P903 to WINCH IN/OUT switch.
- (8) Install auxiliary panel (para 7-8).

X2E8803A

e89. 15K SELF-RECOVERY WINCH (SRW) DOES NOT REEL IN	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C) Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
Personnel Required (2)	Materials/Parts Wire, Elect, 50 ft (Item 71, Appendix D)
References TM 9-4910-571-12&P	





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Remove four nuts, washers, solenoid bracket, washers, and screws.
- (2) Loosen screw and disconnect winch in solenoid L4 connector from solenoid L4.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to winch in solenoid L4 connector terminal 1.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1).
- (7) Position PTO switch to on (TM 9-2320-366-10-1).
- (8) Position winch power switch to on (TM 9-2320-366-10-1).
- (9) Position WINCH IN/OUT switch to IN (TM 9-2320-366-10-1) and note reading on multimeter.
- (10) If 24 vdc is not present, go to step 3 of this fault.
- (11) Position winch power switch to off (TM 9-2320-366-10-1).
- (12) Position PTO switch to off (TM 9-2320-366-10-1).
- (13) Position master power switch to off (TM 9-2320-366-10-1).




WINCH IN SOLENOID L4

SCREW




TERMINAL 1



WINCH IN SOLENOID L4 CONECTOR


42E8901A

ø89. 15K SELF-RECOVERY WINCH (SRW) DOES NOT REEL IN (CONT)




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to winch in solenoid L4 terminal 2.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3069 (para 2-45) or replace winch control valve cable assembly (para 7-135).
- (5) If continuity is present, replace winch control valve assembly (para 17-25).
- (6) Connect winch in solenoid L4 connector on solenoid L4 and tighten screw.



ø89. 15K SELF-RECOVERY WINCH (SRW) DOES NOT REEL IN (CONT)

KNOWN INFO
Circuit breaker OK. 15K SRW pays out. Winch control valve assembly OK.
POSSIBLE PROBLEMS
Faulty winch in/out switch. Faulty winch control valve cable assembly. Faulty PTO cable assembly. Faulty auxiliary panel cable assembly.





TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, WINCH IN/OUT switch is faulty.



CONTINUITY TEST


- (1) Remove six screws from auxiliary panel.
- (2) Lift auxiliary panel from auxiliary panel housing to gain access.
- (3) Disconnect connector P903 from WINCH IN/OUT switch.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to WINCH IN/OUT switch terminal 3.
- (6) Connect negative (-) probe of multimeter to WINCH IN/OUT switch terminal 1.
- (7) Position WINCH IN/OUT switch to in (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If continuity is not present, replace WINCH IN/OUT switch (para 7-18).



X2E8903A

ø89. 15K SELF-RECOVERY WINCH (SRW) DOES NOT REEL IN (CONT)


KNOWN INFO
Circuit breaker OK. 15K SRW pays out. Winch control valve assembly OK. WINCH IN/OUT switch OK.
POSSIBLE PROBLEMS
Faulty winch control valve cable assembly. Faulty PTO cable assembly. Faulty auxiliary panel cable assembly.



TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 2005 is faulty.




- | CONTINUITY TEST | |
|-----------------|---|
| (1) | Remove kick panel (para 16-3). |
| (2) | Disconnect connector P210 from connector J210. |
| (3) | Set multimeter to ohms. |
| (4) | Connect positive (+) probe of multimeter to connector P903-1. |
| (5) | Connect negative (-) probe of multimeter to connector P210-14 and note reading on multimeter. |
| (6) | If continuity is not present, repair wire 2005 (para 2-45) or replace auxiliary panel cable assembly (para 7-58). |
| (7) | Connect connector P903 to WINCH IN/OUT switch. |
| (8) | Position auxiliary panel on auxiliary panel housing with six screws. |
| (9) | Tighten six screws to 24 lb-in. (3 N·m). |



42E8904A

ø89. 15K SELF-RECOVERY WINCH (SRW) DOES NOT REEL IN (CONT)





KNOWN INFO
Circuit breaker OK. 15K SRW pays out. Winch control valve assembly OK. WINCH IN/OUT switch OK. Auxiliary panel cable assembly OK.
POSSIBLE PROBLEMS
Faulty winch control valve cable assembly. Faulty PTO cable assembly.



TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 2005 is faulty.









- | CONTINUITY TEST | |
|-----------------|--|
| (1) | Disconnect connector P215 from connector J215. |
| (2) | Set multimeter to ohms. |
| (3) | Connect positive (+) probe of multimeter to connector J210-14. |
| (4) | Connect negative (-) probe of multimeter to connector P215-2 and note reading on multimeter. |
| (5) | If continuity is not present, repair wire 2005 (para 2-45) or replace PTO cable assembly (para 7-127). |
| (6) | Connect connector P210 to connector J210. |
| (7) | Install kick panel (para 16-3). |



42E8806A

ø89. 15K SELF-RECOVERY WINCH (SRW) DOES NOT REEL IN (CONT)






WINCH IN SOLENOID L4 CONNETOR

- | CONTINUITY TEST | |
|-----------------|--|
| (1) | Set multimeter to ohms. |
| (2) | Connect positive (+) probe of multimeter to connector J215-2. |
| (3) | Connect negative (-) probe of multimeter to winch in solenoid L4 connector terminal 1 and note reading on multimeter. |
| (4) | If continuity is not present, repair wire 2005 (para 2-45) or replace winch control valve cable assembly (para 7-135). |
| (5) | If continuity is present, notify DS Maintenance. |
| (6) | Connect connector P215 to connector J215. |
| (7) | Connect winch in solenoid L4 connector to solenoid L4 and tighten screw. |

42E8807A

e90. 15K SELF-RECOVERY WINCH (SRW) DOES NOT PAY OUT	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C) Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
Personnel Required (2)	Materials/Parts Wire, Elect, 50 ft (Item 67, Appendix D)
References TM 9-4910-571-12&P	





WARNING


Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Remove four nuts, washers, solenoid bracket, washers, and screws.
- (2) Loosen screw and disconnect winch out solenoid L5 connector from solenoid L5.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to winch out solenoid L5 connector terminal 1.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1).
- (7) Position PTO switch to on (TM 9-2320-366-10-1).
- (8) Position winch power switch to on (TM 9-2320-366-10-1).
- (9) Position WINCH IN/OUT switch to OUT (TM 9-2320-366-10-1) and note reading on multimeter.
- (10) If 24 vdc is not present, go to step 3 of this fault.
- (11) Position winch power switch to off (TM 9-2320-366-10-1).
- (12) Position PTO switch to off (TM 9-2320-366-10-1).
- (13) Position master power switch to off (TM 9-2320-366-10-1).




WINCH OUT SOLENOID L5 CONNECTOR





42E9001A

e90. 15K SELF-RECOVERY WINCH (SRW) DOES NOT PAY OUT (CONT)




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to winch out solenoid L5 terminal 2.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3070 (para 2-45) or replace winch control valve cable assembly (para 7-135).
- (5) If continuity is present, replace winch control valve assembly (para 17-25).
- (6) Connect winch out solenoid L5 connector on solenoid L5 and tighten screw.



ø90. 15K SELF-RECOVERY WINCH (SRW) DOES NOT PAY OUT (CONT)

KNOWN INFO
Circuit breaker OK. 15K SRW reels in OK. Winch control valve assembly OK.
POSSIBLE PROBLEMS
Faulty winch in/out switch. Faulty winch control valve cable assembly. Faulty PTO cable assembly. Faulty auxiliary panel cable assembly.





TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, WINCH IN/OUT switch is faulty.




CONTINUITY TEST

- (1) Remove six screws from auxiliary panel.
- (2) Lift auxiliary panel from auxiliary panel housing to gain access.
- (3) Disconnect connector P903 from WINCH IN/OUT switch.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to WINCH IN/OUT switch terminal 3.
- (6) Connect negative (-) probe of multimeter to WINCH IN/OUT switch terminal 7.
- (7) Position WINCH IN/OUT switch to out (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If continuity is not present, replace WINCH IN/OUT switch (para 7-18).



¶90. 15K SELF-RECOVERY WINCH (SRW) DOES NOT PAY OUT (CONT)


KNOWN INFO
Circuit breaker OK. 15K SRW reels in OK. Winch control valve assembly OK. WINCH IN/OUT switch OK.
POSSIBLE PROBLEMS
Faulty winch control valve cable assembly. Faulty PTO cable assembly. Faulty auxiliary panel cable assembly.



TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 2008 is faulty.




- | CONTINUITY TEST | |
|-----------------|---|
| (1) | Remove kick panel (para 16-3). |
| (2) | Disconnect connector P210 from connector J210. |
| (3) | Set multimeter to ohms. |
| (4) | Connect positive (+) probe of multimeter to connector P903-7. |
| (5) | Connect negative (-) probe of multimeter to connector P210-8 and note reading on multimeter. |
| (6) | If continuity is not present, repair wire 2008 (para 2-45) or replace auxiliary panel cable assembly (para 7-58). |
| (7) | Connect connector P903 to WINCH IN/OUT switch. |
| (8) | Position auxiliary panel on auxiliary panel housing with six screws. |
| (9) | Tighten six screws to 24 lb-in. (3 N·m). |



42E8904A

¶90. 15K SELF-RECOVERY WINCH (SRW) DOES NOT PAY OUT (CONT)

KNOWN INFO
Circuit breaker OK. 15K SRW reels in OK. Winch control valve assembly OK. WINCH IN/OUT switch OK. Auxiliary panel cable assembly OK.
POSSIBLE PROBLEMS
Faulty winch control valve cable assembly. Faulty PTO cable assembly.




TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 2008 is faulty.









CONTINUITY TEST

- (1) Disconnect connector P215 from connector J215.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector J210-8.
- (4) Connect negative (-) probe of multimeter to connector P215-1 and note reading on multimeter.
- (5) If continuity is not present, repair wire 2008 (para 2-45) or replace PTO cable assembly (para 7-127).
- (6) Connect connector P210 to connector J210.
- (7) Install kick panel (para 16-3).



¶90. 15K SELF-RECOVERY WINCH (SRW) DOES NOT PAY OUT (CONT)






- | CONTINUITY TEST | |
|-----------------|--|
| (1) | Set multimeter to ohms. |
| (2) | Connect positive (+) probe of multimeter to connector J215-1. |
| (3) | Connect negative (-) probe of multimeter to winch out solenoid L5 connector terminal 1 and note reading on multimeter. |
| (4) | If continuity is not present, repair wire 2008 (para 2-45) or replace winch control valve cable assembly (para 7-135). |
| (5) | If continuity is present, notify DS Maintenance. |
| (6) | Connect connector P215 to connector J215. |
| (7) | Connect winch out solenoid L5 connector to solenoid L5 and tighten screw. |

WINCH OUT SOLENOID L5 CONNECTOR

42E8906A

e91. POWER TAKE-OFF (PTO) DOES NOT OPERATE	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C) Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
Personnel Required (2)	Materials/Parts Wire, Elect, 50 ft (Item 71, Appendix D) Wire, Relay Test (Item E-9, Appendix E)
References TM 9-4910-571-12&P	






WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Disconnect connector P217 from PTO.
- (2) Set multimeter to volts dc.
- (3) Connect positive (+) probe of multimeter to connector P217-B.
- (4) Connect negative (-) probe of multimeter to ground.
- (5) Start engine (TM 9-2320-366-10-1).
- (6) Position PTO switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 24 vdc is not present, go to step 3 of this fault.
- (8) Position PTO switch to off (TM 9-2320-366-10-1).
- (9) Shut down engine (TM 9-2320-366-10-1).




X2E91011

ø91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter to connector P217-A.
	(3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
	(4) If continuity is not present, repair wire 3068 (para 2-45) or replace PTO cable assembly (para 7-127).
	(5) If continuity is present, notify DS Maintenance.
	(6) Connect connector P217 to PTO.



X2E91021

ø91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Remove six screws from auxiliary panel.
- (2) Lift auxiliary panel from auxiliary panel housing to gain access.
- (3) Disconnect connector P904 from PTO switch.
- (4) Set multimeter to volts dc.
- (5) Connect positive (+) probe of multimeter to connector P904-5.
- (6) Connect negative (-) probe of multimeter to ground.
- (7) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If 24 vdc is not present, repair wire 1925 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (9) Position master power switch to off (TM 9-2320-366-10-1).



X2E91031

91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)

KNOWN INFO
Circuit breaker OK. Vehicle starts. PTO OK.
POSSIBLE PROBLEMS
Faulty PTO switch. Faulty auxiliary panel cable assembly. Faulty dashboard cable assembly. Faulty PTO cable assembly. Faulty WTEC II VIM. Faulty WTEC II relay SF02. Faulty WTEC III relay K37. Faulty WTEC III transmission ECU.





TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, PTO switch is faulty.



CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to PTO switch terminal 5.
- (3) Connect negative (-) probe of multimeter to PTO switch terminal 1.
- (4) Position PTO switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If continuity is not present, replace PTO switch (para 7-18).
- (6) Position PTO switch to off (TM 9-2320-366-10-1).



X2E91041

91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)

KNOWN INFO
Circuit breaker OK. Vehicle starts. PTO OK. PTO switch OK.
POSSIBLE PROBLEMS
Faulty PTO cable assembly. Faulty WTEC II VIM. Faulty dashboard cable assembly. Faulty auxiliary panel cable assembly. Faulty WTEC II relay SF02. Faulty WTEC III relay K37. Faulty WTEC III transmission ECU.





TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 2019 is faulty.




CONTINUITY TEST

- (1) Remove kick panel (para 16-3).
- (2) Disconnect connector P210 from connector J210.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector P210-4.
- (5) Disconnect connector P217 from PTO.
- (6) Connect negative (-) probe of multimeter to connector P217-B and note reading on multimeter.
- (7) If continuity is not present, repair wire 2019 (para 2-45) or replace PTO cable assembly (para 7-127).
- (8) Connect connector P217 to PTO.
- (9) Connect connector P210 to connector J210.




3	2	1	0
6	5	4	0
9	8	7	0
12	11	10	0
15	14	13	0
17	16	1	0



X2E9110A


91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)

KNOWN INFO
Circuit breaker OK. Vehicle starts. PTO OK. PTO switch OK. PTO cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC II VIM. Faulty dashboard cable assembly. Faulty auxiliary panel cable assembly. Faulty WTEC II relay SF02. Faulty WTEC III relay K37. Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.





TEST OPTIONS
Visual inspection
REASON FOR QUESTION
This question helps eliminate possible problems and determines where troubleshooting continues.






- (1) Check if vehicle is equipped with WTEC II TEPSS.
- (2) If transmission pushbutton shift selector is not mounted with four screws and does not have a filter cover, go to step 13.



e91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)

KNOWN INFO
Circuit breaker OK. Vehicle starts. PTO OK. PTO switch OK. PTO cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC II VIM. Faulty WTEC II dashboard cable assembly. Faulty auxiliary panel cable assembly. Faulty WTEC II relay SF02.




TEST OPTIONS
Operational Test
REASON FOR QUESTION
If PTO operates after replacing WTEC II relay SF02, WTEC II relay SF02 is faulty. If PTO does not operate after replacing WTEC II relay SF02, WTEC II VIM is faulty.



OPERATIONAL TEST

- (1) Remove WTEC II relay SF02 (para 8-6).
- (2) Install new WTEC II relay SF02 (para 8-6).
- (3) Start engine (TM 9-2320-366-10-1).
- (4) Position PTO switch to on
(TM 9-2320-366-10-1).
- (5) If PTO operates, replace WTEC II relay SF02
(para 8-6).
- (6) If PTO does not operate, replace WTEC II VIM
(para 8-6).

ø91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Remove personnel heater for access (para 18-9).
- (2) Disconnect connector J913 from connector P913.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to connector J913-5.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 24 vdc is not present, repair wire 1925 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).
- (8) Position master power switch to off (TM 9-2320-366-10-1).



X2E91071

91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)




KNOWN INFO
Circuit breaker OK. Vehicle starts. PTO OK. PTO switch OK. PTO cable assembly OK. WTEC II VIM OK.
POSSIBLE PROBLEMS
Faulty auxiliary panel cable assembly. Faulty WTEC II dashboard cable assembly. Faulty WTEC II relay SF02.



TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 1904 is faulty.



CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter to connector P904-1.
	(3) Connect negative (-) probe of multimeter to connector P913-15 and note reading on multimeter.
	(4) If continuity is not present, repair wire 1904 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).




X2E91081

e91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)

KNOWN INFO
Circuit breaker OK. Vehicle starts. PTO OK. PTO switch OK. PTO cable assembly OK. WTEC II VIM OK.
POSSIBLE PROBLEMS
Faulty WTEC II dashboard cable assembly. Faulty auxiliary panel cable assembly. Faulty WTEC II relay SF02.

10.
Is continuity present from connector J913-15 to connector PX33-E3?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 1904 is faulty.



KNOWN INFO
Circuit breaker OK. Vehicle starts. PTO OK. PTO switch OK. PTO cable assembly OK. WTEC II VIM OK.
POSSIBLE PROBLEMS
Faulty WTEC II dashboard cable assembly. Faulty auxiliary panel cable assembly. Faulty WTEC II relay SF02.

11.
Is continuity present from connector PX33-E2 to connector J913-14?

TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 2019 is faulty.




CONTINUITY TEST

- (1) Loosen screw in connector PX33.
- (2) Disconnect connector PX33 from WTEC II VIM.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector J913-15.
- (5) Connect negative (-) probe of multimeter to connector PX33-E3 and note reading on multimeter.
- (6) If continuity is not present, repair wire 1904 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).


CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector PX33-E2.
- (3) Connect negative (-) probe of multimeter to connector J913-14 and note reading on multimeter.
- (4) If continuity is not present, repair wire 2019 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).
- (5) Connect connector PX33 to WTEC II VIM.
- (6) Tighten screw in connector PX33.




42e91091

ø91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)




CONTINUITY TEST

- (1) Disconnect connector P210 from connector J210.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector P913-14.
- (4) Connect negative (-) probe of multimeter to connector J210-4 and note reading on multimeter.
- (5) If continuity is not present, repair wire 2019 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (6) If continuity is present, replace WTEC II relay SF02 (para 8-6).
- (7) Connect connector P913 to connector J913.
- (8) Connect connector J210 to connector P210.
- (9) Install personnel heater (para 18-9).



X2E9109A

e91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Remove personnel heater for access (para 18-9).
- (2) Disconnect connector J913 from connector P913.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to connector J913-5.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 24 vdc is not present, repair wire 1925 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (8) Position master power switch to off (TM 9-2320-366-10-1).



X2E9103A

e91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)



KNOWN INFO
Circuit breaker OK. Vehicle starts. PTO OK. PTO switch OK. PTO cable assembly OK.
POSSIBLE PROBLEMS
Faulty auxiliary panel cable assembly. Faulty WTEC III dashboard cable assembly. Faulty WTEC III relay K37. Faulty WTEC III transmission ECU.



TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 1904 is faulty.




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter to connector P904-1.
	(3) Connect negative (-) probe of multimeter to connector P913-15 and note reading on multimeter.
	(4) If continuity is not present, repair wire 1904 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).




X2E91121

ø91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)




CONTINUITY TEST

- (1) Remove WTEC III relay K37 from PDP.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector J913-15.
- (4) Connect negative (-) probe of multimeter to PDP, terminal 30, where WTEC III relay K37 was removed, and note reading on multimeter.
- (5) If continuity is not present, repair wire 1904 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (6) Install WTEC III relay K37 in PDP.



X2E91131

e91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)




WARNING


Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Install personnel heater hoses (para 18-9).
- (2) Remove PTO switch from auxiliary panel.
- (3) Install PTO switch on connector P904.
- (4) Remove WTEC III relay K37 from PDP.
- (5) Insert relay test wire in PDP terminal 87, where WTEC III relay K37 was removed.
- (6) Install WTEC III relay K37 in PDP.
- (7) Set multimeter to volts dc.
- (8) Connect positive (+) probe of multimeter to relay test wire.
- (9) Connect negative (-) probe of multimeter to ground.
- (10) Start engine (TM 9-2320-366-10-1).
- (11) Position PTO switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (12) If 24 vdc is not present, go to step 18 of this faulty.
- (13) Position PTO switch to off (TM 9-2320-366-10-1).
- (14) Shut down engine (TM 9-2320-366-10-1).
- (15) Remove WTEC III relay K37 from PDP.
- (16) Remove relay test wire from PDP.
- (17) Install WTEC III relay K37 in PDP.



WTEC III RELAY K37




WTEC III RELAY K37 CAVITY




CONNECTOR P904

X2E91141

e91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)




CONTINUITY TEST	
	(1) Disconnect connector P210 from connector J210.
	(2) Set multimeter to ohms.
	(3) Connect positive (+) probe of multimeter to connector P913-14.
	(4) Connect negative (-) probe of multimeter to connector J210-4 and note reading on multimeter.
	(5) If continuity is not present, repair wire 2019 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
	(6) If continuity is present, repair wire 2019 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
	(7) Connect connector P913 to connector J913.
	(8) Remove PTO switch from connector P904.
	(9) Install personnel heater (para 18-9).



ø91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)

KNOWN INFO
Circuit breaker OK.
Vehicle starts.
PTO OK.
PTO switch OK.
PTO cable assembly OK.

POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly.
Faulty WTEC III relay K37.
Faulty WTEC III transmission ECU.




TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 3101 faulty.




CONTINUITY TEST

- (1) Remove WTEC III relay K37 from PDP.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to PDP, where WTEC III relay K37 terminal 85 was removed.
- (4) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (5) If continuity is not present, repair wire 3101 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).




**WTEC III
RELAY K37**



**WTEC III
RELAY K37**

X2E91161

91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Disconnect connector clamp from connector P115.
- (2) Disconnect connector P115 from WTEC III transmission ECU.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to connector P115-13.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1).
- (7) Position PTO switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If 24 vdc is not present, repair wire 118 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (9) Position PTO switch to off (TM 9-2320-366-10-1).
- (10) Position master power switch to off (TM 9-2320-366-10-1).



X2E91171

91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)


KNOWN INFO
Circuit breaker OK. Vehicle starts. PTO OK. PTO cable assembly OK. Auxiliary panel cable assembly OK. PTO switch OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty WTEC III relay K37. Faulty WTEC III transmission ECU.



TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 112 is faulty.




- | CONTINUITY TEST | |
|-----------------|--|
| | (1) Set multimeter to ohms. |
| | (2) Connect positive (+) probe of multimeter to connector P115-22. |
| | (3) Connect negative (-) probe of multimeter to PDP, where WTEC III relay K37 terminal 86 was removed, and note reading on multimeter. |
| | (4) If continuity is not present, repair wire 112 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11). |
| | (5) Connect connector P115 to WTEC III transmission ECU. |
| | (6) Connect connector clamp on connector P115. |



X2E91181

e91. POWER TAKE-OFF (PTO) DOES NOT OPERATE (CONT)




WARNING


Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Set multimeter to volts dc.
- (2) Connect positive (+) probe of multimeter to PDP, where WTEC III relay K37 terminal 86 was removed.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If 24 vdc is not present, replace WTEC III transmission ECU (para 8-7).
- (5) If 24 vdc is present, replace WTEC III relay K37 (para 7-9).
- (6) Install WTEC III relay K37 on PDP.
- (7) Remove PTO switch from connector P904.
- (8) Install personnel heater (para 18-9).



WTEC III
RELAY K37




WTEC III
RELAY K37
CAVITY



X2E91191

e92. ELECTRICAL SYSTEM DOES NOT MAINTAIN A CHARGE	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C) Apron, Rubber (Item 3, Appendix C) Gloves, Rubber (Item 13, Appendix C) Goggles, Industrial (Item 15, Appendix C) Tester, Antifreeze and Battery (Item 42, Appendix C) Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
Materials/Parts Wire, Elect, 50 ft (Item 71, Appendix D) Wire, Relay Test (Item 9, Appendix E) Nut, Self-Locking (Item 144.1, Appendix G) (100 AMP) Nut, Self-Locking (Item 143.1, Appendix G) (200 AMP)	Personnel Required (2)
References TM 9-6140-200-14 TM 9-4910-571-12&P	



WARNING


Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock. Batteries can explode from a spark. Battery acid is harmful to skin and eyes. Always wear eye protection and rubber gloves when working with batteries.

BATTERY SPECIFIC GRAVITY TEST

- (1) Remove battery box cover from battery box (TM 9-2320-366-10-2).
- (2) Remove four batteries from battery box (para 7-55).
- (3) Test batteries for serviceability (TM 9-6140-200-14).
- (4) Replace battery(ies) if unserviceable (TM 9-6140-200-14).
- (5) Install four batteries in battery box (para 7-55).
- (6) Install battery box cover on battery box (TM 9-2320-366-10-2).

e92. ELECTRICAL SYSTEM DOES NOT MAINTAIN A CHARGE (CONT)


KNOWN INFO
Engine oil pressure indicator light illuminates. OIL PRESS gage operates. Engine starts. Alternator belts OK. Battery(ies) OK.
POSSIBLE PROBLEMS
Faulty engine oil pressure switch. Faulty relay K11. Faulty dashboard cable assembly. Faulty engine control cable assembly. Faulty alternator ground strap. Faulty alternator. Faulty voltage regulator. Faulty 100 AMP alternator to reverse polarity relay 12 VDC cable. Faulty 200 AMP alternator to terminal block 12 VDC cable. Faulty 100 AMP alternator to reverse polarity relay 24 VDC cable. Faulty 200 AMP alternator to terminal block 24 VDC cable.




TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
If oil pressure indicator light remains illuminated, oil pressure switch is faulty.



STEERING WHEEL
REMOVED FOR
CLARITY




- (1) Start engine (TM 9-2320-366-10-1).
- (2) If engine oil pressure indicator light remains on after OIL PRESS gage reaches 20 PSI, replace engine oil pressure switch (para 7-48).
- (3) Shut down engine (TM 9-2320-366-10-1).



XBE9201B



e92. ELECTRICAL SYSTEM DOES NOT MAINTAIN A CHARGE (CONT)

KNOWN INFO
Engine oil pressure indicator light illuminates. OIL PRESS gage operates. Engine starts. Alternator belts OK. Battery(ies) OK. Engine oil pressure switch OK.
POSSIBLE PROBLEMS
Faulty relay K11. Faulty dashboard cable assembly. Faulty engine control cable assembly. Faulty alternator ground strap. Faulty alternator. Faulty voltage regulator. Faulty 100 AMP alternator to reverse polarity relay 12 VDC cable. Faulty 200 AMP alternator to terminal block 12 VDC cable. Faulty 100 AMP alternator to reverse polarity relay 24 VDC cable. Faulty 200 AMP alternator to terminal block 24 VDC cable.



CONTINUITY TEST

- (1) Disconnect batteries (para 7-57).
- (2) Remove power distribution panel (PDP) cover (para 16-2).
- (3) Remove relay K11 from power distribution panel (PDP).
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to relay K11 terminal 30.
- (6) Connect negative (-) probe of multimeter to relay K11 terminal 87A and note reading on multimeter.
- (7) If continuity is not present, replace relay K11 (para 7-9).




RELAY K11

XBE9202B


e92. ELECTRICAL SYSTEM DOES NOT MAINTAIN A CHARGE (CONT)

KNOWN INFO
Engine oil pressure indicator light illuminates. OIL PRESS gage operates. Engine starts. Alternator belts OK. Battery(ies) OK. Engine oil pressure switch OK. Relay K11 OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty engine control cable assembly. Faulty alternator ground strap. Faulty alternator. Faulty voltage regulator. Faulty 100 AMP alternator to reverse polarity relay 12 VDC cable. Faulty 200 AMP alternator to terminal block 12 VDC cable. Faulty 100 AMP alternator to reverse polarity relay 24 VDC cable. Faulty 200 AMP alternator to terminal block 24 VDC cable.





TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.





RELAY K11
CAVITY


- CONTINUITY TEST**
- (1) Set multimeter to ohms.
 - (2) Connect positive (+) probe of multimeter to relay K11 socket 87A on PDP.
 - (3) Raise cab (TM 9-2320-366-10-1).
 - (4) Lift dust boot on terminal lug TL35.
 - (5) Remove self-locking nut, washer, and terminal lug TL35 from voltage regulator. Discard self-locking nut.
 - (6) Connect negative (-) probe of multimeter to terminal lug TL35 and note reading on multimeter.
 - (7) If continuity is not present, go to step 9 of this fault.
 - (8) Position terminal lug TL35 on voltage regulator with washer and self-locking nut.
 - (9) Tighten self-locking nut to 23-27 lb-in. (3 N.m).
 - (10) Position dust boot on terminal lug TL35.



XBE9203B



e92. ELECTRICAL SYSTEM DOES NOT MAINTAIN A CHARGE (CONT)

KNOWN INFO
Engine oil pressure indicator light illuminates. OIL PRESS gage operates. Engine starts. Alternator belts OK. Battery(ies) OK. Engine oil pressure switch OK. Relay K11 OK. Dashboard cable assembly OK. Engine control cable assembly OK.
POSSIBLE PROBLEMS
Faulty alternator ground strap. Faulty alternator. Faulty voltage regulator. Faulty 100 AMP alternator to reverse polarity relay 12 VDC cable. Faulty 200 AMP alternator to terminal block 12 VDC cable. Faulty 100 AMP alternator to reverse polarity relay 24 VDC cable. Faulty 200 AMP alternator to terminal block 24 VDC cable.



CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to terminal lug TL58.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, replace alternator ground strap (para 7-71).
- (5) Connect batteries (para 7-57).



Xbe9204b

e92. ELECTRICAL SYSTEM DOES NOT MAINTAIN A CHARGE (CONT)

KNOWN INFO
Engine oil pressure indicator light illuminates. OIL PRESS gage operates. Engine starts. Alternator belts OK. Battery(ies) OK. Engine oil pressure switch OK. Relay K11 OK. Dashboard cable assembly OK. Engine control cable assembly OK. Alternator ground strap OK.
POSSIBLE PROBLEMS
Faulty alternator. Faulty voltage regulator. Faulty 100 AMP alternator to reverse polarity relay 12 VDC cable. Faulty 200 AMP alternator to terminal block 12 VDC cable. Faulty 100 AMP alternator to reverse polarity relay 24 VDC cable. Faulty 200 AMP alternator to terminal block 24 VDC cable.





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Raise cab (TM 9-2320-366-10-1).
- (2) Lift dust boot from terminal lug TL60.
- (3) Set multimeter to volts DC.
- (4) Connect positive (+) probe of multimeter to terminal lug TL60.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) If 12 VDC is not present, replace 100 AMP alternator to reverse polarity relay 12 VDC cable (para 7-72) or replace 200 AMP alternator to terminal block 12 VDC cable (para 20-48).
- (7) Position dust boot on terminal lug TL60.



XBE9205B

e92. ELECTRICAL SYSTEM DOES NOT MAINTAIN A CHARGE (CONT)

KNOWN INFO
Engine oil pressure indicator light illuminates. OIL PRESS gage operates. Engine starts. Alternator belts OK. Battery(ies) OK. Engine oil pressure switch OK. Relay K11 OK. Dashboard cable assembly OK. Engine control cable assembly OK. Alternator ground strap OK. 100 AMP alternator to reverse polarity relay 12 VDC cable OK. 200 AMP alternator to terminal block 12 VDC cable OK.
POSSIBLE PROBLEMS
Faulty alternator. Faulty voltage regulator. Faulty 100 AMP alternator to reverse polarity relay 24 VDC cable. Faulty 200 AMP alternator to terminal block 24 VDC cable.





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Lift dust boot from terminal lug TL2.
- (2) Set multimeter to volts DC.
- (3) Connect positive (+) probe of multimeter to terminal lug TL2.
- (4) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (5) If 24 VDC is not present, replace 100 AMP alternator to reverse polarity relay 24 VDC cable (para 7-73) or replace 200 AMP alternator to terminal block 12 VDC cable (para 20-50).
- (6) Position dust boot on terminal lug TL2.
- (7) Disconnect batteries (para 7-57).
- (8) Lower cab (TM9-2320-366-10-1).
- (9) Install relay K11 in PDP.
- (10) Install PDP cover (para 16-2).
- (11) Connect batteries (para 7-57).



xbe9206b

e92. ELECTRICAL SYSTEM DOES NOT MAINTAIN A CHARGE (CONT)





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Replace 100 AMP voltage regulator (para 7-5) or 200 AMP voltage regulator (para 20-46) with a known good voltage regulator.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Raise cab (TM 9-2320-366-10-1).
- (4) Lift dust boot from alternator 12 VDC terminal stud.
- (5) Set multimeter to volts DC.
- (6) Connect positive (+) probe of multimeter to alternator 12 VDC terminal stud.
- (7) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (8) If 13.25 -14.75V is not present, replace 100 AMP alternator (para 7-2) or 200 AMP alternator (para 20-45).
- (9) If 13.25-14.75V is present, replace 100 AMP voltage regulator (para 7-5) or 200 AMP voltage regulator (para 20-46).
- (10) Position dust boot on alternator 12 VDC terminal stud.
- (11) Lift dust boot from alternator 24 VDC terminal stud.
- (12) Connect positive (+) probe of multimeter to alternator 24 VDC terminal stud.
- (13) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (14) If 27.25 -28.75V is not present, replace 100 AMP alternator (para 7-2) or 200 AMP alternator (para 20-45).
- (15) If 27.25-28.75V is present, replace 100 AMP voltage regulator (para 7-5) or 200 AMP voltage regulator (para 20-46).
- (16) Position dust boot on alternator 24 VDC terminal stud.
- (17) Lower cab (TM 9-2320-366-10-1).
- (18) Shut down engine (TM 9-2320-366-10-1).



XBe9207B

e92. ELECTRICAL SYSTEM DOES NOT MAINTAIN A CHARGE (CONT)







CAUTION

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back or not capable of making good contact.



RELAY K11 CAVITY

CONTINUITY TEST

- (1) Lower cab (TM 9-2320-366-10-1).
- (2) Remove instrument panel for access (para 7-15).
- (3) Disconnect connector J31 from connector P31.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to relay K11 terminal 87A on PDP.
- (6) Connect negative (-) probe of multimeter to connector J31 pin 1 and note reading on multimeter.
- (7) If continuity is not present, repair wire 568A from connector J31 pin 1 to relay K11 terminal 87A (para 2-45) on PDP or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (8) If continuity is present, repair wire 568A from connector P31 socket 1 to terminal lug TL35 (para 2-45) or replace engine control cable assembly (para 7-80).
- (9) Connect connector J31 to connector P31.
- (10) Install instrument panel (para 7-15).
- (11) Install relay K11 in PDP.
- (12) Install PDP cover (para 16-2).
- (13) Connect batteries (para 7-57).

XBE9208B

e93. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) ILLUMINATION DOES NOT DIM

INITIAL SETUP


Equipment Condition
Engine shut down (TM 9-2320-366-10-1).

Personnel Required
(2)

References
TM 9-4910-571-12&P



Tools and Special Tools
Tool Kit, Genl Mech (Item 46, Appendix C)
STE/ICE-R (Item 41, Appendix C)
Multimeter, Digital (Item 22, Appendix C)

Materials/Parts
Wire, Elect, 50 ft (Item 71, Appendix D)



CONTINUITY TEST


- (1) Remove kick panel (para 16-3).
- (2) Disconnect connector J116 from WTEC II VIM.
- (3) Remove instrument panel assembly for access (para 7-15).
- (4) Disconnect connector J115 (top connector) from WTEC II TEPSS.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector J115-24.
- (7) Connect negative (-) probe of multimeter to connector J116C3.
- (8) If continuity is not present, repair wire 158 (para 2-45) or replace WTEC II cab transmission harness (para 7-137).
- (9) Connect connector J115 to WTEC II TEPSS.
- (10) Install instrument panel assembly (para 7-15).



X2E93011

e93. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) ILLUMINATION DOES NOT DIM (CONT)


KNOWN INFO
Marker lights illuminate. Blackout lights illuminate. WTEC II TEPSS illuminates. WTEC II cab transmission harness OK.
POSSIBLE PROBLEMS
Faulty WTEC II VIM. Faulty WTEC II dashboard cable assembly. Faulty WTEC II TEPSS dimmer module.



TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, WTEC II VIM is faulty.




- | CONTINUITY TEST | |
|-----------------|---|
| (1) | Loosen screw and disconnect connector PX33 from WTEC II VIM. |
| (2) | Set multimeter to ohms. |
| (3) | Connect positive (+) probe of multimeter to WTEC II VIM connector J116C3. |
| (4) | Connect negative (-) probe of multimeter to WTEC II VIM connector terminal J3 and note reading on multimeter. |
| (5) | If continuity is not present, replace WTEC II VIM (para 8-6). |
| (6) | Connect connector J116 to WTEC II VIM. |
| (7) | Connect connector PX33 to WTEC II VIM and tighten screw. |



X2E93021

e93. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) ILLUMINATION DOES NOT DIM (CONT)

KNOWN INFO
Marker lights illuminate. Blackout lights illuminate. WTEC II TEPSS illuminates. WTEC II VIM OK. WTEC II cab transmission harness OK.
POSSIBLE PROBLEMS
Faulty WTEC II dashboard cable assembly. Faulty WTEC II TEPSS dimmer module.




TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 158 is faulty.



CONTINUITY TEST

- (1) Remove three screws and washers from PDP.
- (2) Remove three screws from PDP.
- (3) Lift PDP outward to gain access.
- (4) Disconnect connector J7 from WTEC II TEPS dimmer module.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector J7-4.
- (7) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (8) If continuity is not present, repair wire 158 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).




e93. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) ILLUMINATION DOES NOT DIM (CONT)

KNOWN INFO
Marker lights illuminate. Blackout lights illuminate. WTEC II TEPSS illuminates. WTEC II cab transmission harness OK. WTEC II VIM OK.
POSSIBLE PROBLEMS
Faulty WTEC II dashboard cable assembly. Faulty WTEC II TEPSS dimmer module.

4.
Is continuity present between connector J7-1 and a known good ground?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 1426 is faulty.




KNOWN INFO
Marker lights illuminate. Blackout lights illuminate. WTEC II TEPSS illuminates. WTEC II cab transmission harness OK. WTEC II VIM OK.
POSSIBLE PROBLEMS
Faulty WTEC II dashboard cable assembly. Faulty WTEC II TEPSS dimmer module.

5.
Is continuity present between connector J7-2 and a known good ground?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 1408 is faulty.




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter to connector J7-1.
	(3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
	(4) If continuity is not present, repair wire 1426 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).



CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter to connector J7-2.
	(3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
	(4) If continuity is not present, repair wire 1408 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).




e93. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) ILLUMINATION DOES NOT DIM (CONT)




CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector J7-3.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3099 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).
- (5) If continuity is present, replace WTEC II TEPSS dimmer module (para 7-13).
- (6) Connect connector J7 to WTEC II TEPSS dimmer module.
- (7) Install PDP on dashboard with three screws.
- (8) Install three washers and screws in PDP.
- (9) Install kick panel (para 16-3).



e94. DIFFERENTIAL LOCK SOLENOID DOES NOT OPERATE	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P




- | CONTINUITY TEST | |
|-----------------|---|
| | (1) Remove kick panel (para 16-3). |
| | (2) Disconnect connector PX50 from differential lock solenoid connector. |
| | (3) Set multimeter to ohms. |
| | (4) Connect positive (+) probe of multimeter to differential lock solenoid connector pin 1. |
| | (5) Connect negative (-) probe of multimeter to differential lock solenoid connector socket 2 and note reading on multimeter. |
| | (6) If continuity is not present, replace differential lock solenoid (para 7-24). |



42E94011

ø94. DIFFERENTIAL LOCK SOLENOID DOES NOT OPERATE (CONT)

KNOWN INFO
Vehicle runs. Backup light OK. Differential lock solenoid OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty relay SF04 in WTEC II VIM. Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS. Faulty WTEC III relay K34. Faulty WTEC III transmission ECU. Faulty WTEC III TPSS.




TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 3008 is faulty.



CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector PX50-1.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3008 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).




PX50

42E94021


ø94. DIFFERENTIAL LOCK SOLENOID DOES NOT OPERATE (CONT)






- (1) Check if vehicle is equipped with WTEC II TEPS.
- (2) If transmission pushbutton shift selector is not mounted with four screws and does not have a filter cover, go to step 9 of this fault.

WTEC II
TRANSMISSION
ECU PUSHBUTTON
SHIFT SELECTOR




WTEC III
TRANSMISSION
PUSHBUTTON
SHIFT SELECTOR



42E 94031

¶94. DIFFERENTIAL LOCK SOLENOID DOES NOT OPERATE (CONT)





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Loosen screw in connector PX33.
- (2) Disconnect connector PX33 from WTEC II VIM.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to connector PX33-E1.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 24 vdc is not present, repair wire 1692 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).
- (8) Position master power switch to off (TM 9-2320-366-10-1).




42E94041

ø94. DIFFERENTIAL LOCK SOLENOID DOES NOT OPERATE (CONT)

KNOWN INFO
Vehicle runs. Backup light OK. Differential lock solenoid OK. Vehicle is equipped with WTEC II transmission controls.
POSSIBLE PROBLEMS
Faulty WTEC II dashboard cable assembly. Faulty relay SF04 in WTEC II VIM. Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.


5.
Is continuity present from connector PX33-D1 to connector PX50-2?

TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 1697 is faulty.



CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector PX33-D1.
- (3) Connect negative (-) probe of multimeter to connector PX50-2 and note reading on multimeter.
- (4) If continuity is not present, repair wire 1697 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).
- (5) Connect connector PX33 to WTEC II VIM.
- (6) Tighten screw in connector PX33.
- (7) Connect connector PX50 to differential lock solenoid connector.




42E94051

ø94. DIFFERENTIAL LOCK SOLENOID DOES NOT OPERATE (CONT)

KNOWN INFO
Vehicle runs. Backup light OK. Differential lock solenoid OK. Vehicle is equipped with WTEC II transmission controls. WTEC II dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty relay SF04 in WTEC II VIM. Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

6.
Is continuity present from WTEC II VIM relay SF04-30 to SF04-87a?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, relay SF04 in WTEC II VIM is faulty.



KNOWN INFO
Vehicle runs. Backup light OK. Differential lock solenoid OK. Vehicle is equipped with WTEC II transmission controls. WTEC II dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty relay SF04 in WTEC II VIM. Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.


7.
Is continuity present from WTEC II VIM relay SF04-86 to SF04-85?

TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, relay SF04 in WTEC II VIM is faulty.




CONTINUITY TEST

- (1) Remove seven screws and washers from cover.
- (2) Remove screw, washer, cover, and nut from WTEC II VIM.
- (3) Remove relay SF04 from WTEC II VIM.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to relay SF04 terminal 30.
- (6) Connect negative (-) probe of multimeter to relay SF04 terminal 87a and note reading on multimeter.
- (7) If continuity is not present, replace relay SF04 in WTEC II VIM (para 8-6).



CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to relay SF04 terminal 86.
- (3) Connect negative (-) probe of multimeter to relay SF04 terminal 85 and note reading on multimeter.
- (4) If continuity is not present, replace relay SF04 in WTEC II VIM (para 8-6).
- (5) Install relay SF04 in WTEC II VIM.
- (6) Install cover on WTEC II VIM with nut, washer, and screw.
- (7) Install seven washers and screws in cover.




42E94061

ø94. DIFFERENTIAL LOCK SOLENOID DOES NOT OPERATE (CONT)

KNOWN INFO
Vehicle runs. Backup light OK. Differential lock solenoid OK. Vehicle is equipped with WTEC II transmission controls. WTEC II dashboard cable assembly OK. Relay SF04 in WTEC II VIM OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.


8.
Is continuity present from connector J116-C2 to connector J114-25?

TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, WTEC II cab transmission harness is faulty. If continuity is present, WTEC II TEPSS is faulty.




CONTINUITY TEST

- (1) Remove instrument panel assembly for access (para 7-15).
- (2) Disconnect connector J114 from WTEC II TEPSS.
- (3) Loosen screw in connector J116.
- (4) Disconnect connector J116 from WTEC II VIM.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector J116-C2.
- (7) Connect negative (-) probe of multimeter to connector J114-25 and note reading on multimeter.
- (8) If continuity is not present, replace WTEC II cab transmission harness (para 7-137).
- (9) If continuity is present, replace WTEC II TEPSS (para 8-2).
- (10) Connect connector J114 to WTEC II TEPSS.
- (11) Install instrument panel assembly (para 7-15).
- (12) Connect connector J116 to WTEC II VIM.
- (13) Tighten screw in connector J116.
- (14) Install kick panel (para 16-3).



42E94071

994. DIFFERENTIAL LOCK SOLENOID DOES NOT OPERATE (CONT)





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Remove WTEC III relay K34 from PDP.
- (2) Set multimeter to volts dc.
- (3) Connect positive (+) probe of multimeter to PDP, terminal 30, where WTEC III relay K34 was removed.
- (4) Connect negative (-) probe of multimeter to ground.
- (5) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (6) If 24 vdc is not present, repair wire 1692 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (7) Position master power switch to off (TM 9-2320-366-10-1).



**WTEC III
RELAY K34
CAVITY**


42E94081

ø94. DIFFERENTIAL LOCK SOLENOID DOES NOT OPERATE (CONT)

KNOWN INFO
Vehicle runs. Backup light OK. Differential lock solenoid OK. Vehicle is equipped with WTEC III transmission controls.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty WTEC III relay K34. Faulty WTEC III transmission ECU. Faulty WTEC III TPSS.



10.
Is continuity present from PDP relay K34 terminal 87a to connector PX50-2?

TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 1697 is faulty.




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to PDP, terminal 87a, where WTEC III relay K34 was removed.
- (3) Connect negative (-) probe of multimeter to connector PX50-2 and note reading on multimeter.
- (4) If continuity is not present, repair wire 1697 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (5) Connect connector PX50 to differential lock solenoid connector.




WTEC III
RELAY K34
CAVITY



CONNECTOR PX50


DIFFERENTIAL
LOCK SOLENOID
CONNECTOR



42E94091


ø94. DIFFERENTIAL LOCK SOLENOID DOES NOT OPERATE (CONT)

KNOWN INFO
Vehicle runs. Backup light OK. Differential lock solenoid OK. Vehicle is equipped with WTEC III transmission controls.
POSSIBLE PROBLEMS
Faulty WTEC III relay K34. Faulty WTEC III dashboard cable assembly. Faulty WTEC III transmission ECU. Faulty WTEC III TPSS.




TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, WTEC III relay K34 is faulty.

KNOWN INFO
Vehicle runs. Backup light OK. Differential lock solenoid OK. Vehicle is equipped with WTEC III transmission controls.
POSSIBLE PROBLEMS
Faulty WTEC III relay K34. Faulty WTEC III dashboard cable assembly. Faulty WTEC III transmission ECU. Faulty WTEC III TPSS.



TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, WTEC III relay K34 is faulty.

CONTINUITY TEST
(1) Set multimeter to ohms.
(2) Connect positive (+) probe of multimeter to WTEC III relay K34 terminal 30.
(3) Connect negative (-) probe of multimeter to WTEC III relay K34 terminal 87a and note reading on multimeter.
(4) If continuity is not present, replace WTEC III relay K34 (para 7-9).



WTEC III
RELAY K34

42E94101

CONTINUITY TEST
(1) Set multimeter to ohms.
(2) Connect positive (+) probe of multimeter to WTEC III relay K34 terminal 86.
(3) Connect negative (-) probe of multimeter to WTEC III relay K34 terminal 85 and note reading on multimeter.
(4) If continuity is not present, replace WTEC III relay K34 (para 7-9).


¶94. DIFFERENTIAL LOCK SOLENOID DOES NOT OPERATE (CONT)

KNOWN INFO
Vehicle runs.
Backup light OK.
Differential lock solenoid OK.
Vehicle is equipped with WTEC III transmission controls.
WTEC III relay K34 OK.

POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly.
Faulty WTEC III transmission ECU.
Faulty WTEC III TPSS.


13.
Is continuity present from PDP relay K34 terminal 85 to connector P115-18?

TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 125 is faulty.




CONTINUITY TEST


- (1) Disconnect connector clamp from connector P115.
- (2) Disconnect connector P115 from WTEC III transmission ECU.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector P115-18.
- (5) Connect negative (-) probe of multimeter to PDP, terminal 85, where WTEC III relay K34 was removed, and note reading on multimeter.
- (6) If continuity is not present, repair wire 125 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (7) Connect connector P115 to WTEC III transmission ECU.
- (8) Connect connector clamp on connector P115.
- (9) Install WTEC III relay K34 on PDP.



POWER DISTRIBUTION PANEL




WTEC III RELAY K34 CAVITY



WTEC III TRANSMISSION ECU

CONNECTOR P115

CONNECTOR CLAMP




P115

42E94111

e94. DIFFERENTIAL LOCK SOLENOID DOES NOT OPERATE (CONT)

KNOWN INFO
Vehicle runs.
Backup light OK.
Differential lock solenoid OK.
Vehicle is equipped with WTEC III transmission controls.
WTEC III relay K34 OK.




POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly.
Faulty WTEC III transmission ECU.
Faulty WTEC III TPSS.




TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 143 is faulty.

CONTINUITY TEST

- (1) Remove instrument panel assembly for access (para 7-15).
- (2) Disconnect connector PX33 from WTEC III TPSS.
- (3) Disconnect connector clamp from connector P116.
- (4) Disconnect connector P116 from WTEC III transmission ECU.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector P116-32.
- (7) Connect negative (-) probe of multimeter to connector PX33-P and note reading on multimeter.
- (8) If continuity is not present, repair wire 143 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (9) Connect connector PX33 to WTEC III TPSS.
- (10) Install instrument panel assembly (para 7-15).
- (11) Connect connector P116 to WTEC III transmission ECU.
- (12) Connect connector clamp on connector P116.



WTEC III TRANSMISSION
PUSHBUTTON
SHIFT SELECTOR



CONNECTOR
PX33


42E94121


ø94. DIFFERENTIAL LOCK SOLENOID DOES NOT OPERATE (CONT)

KNOWN INFO
Vehicle runs. Backup light OK. Differential lock solenoid OK. Vehicle is equipped with WTEC III transmission controls. WTEC III relay K34 OK. WTEC III dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC III transmission ECU. Faulty WTEC III TPSS.


15.
Does differential lock solenoid operate with replacement WTEC III transmission ECU installed?

TEST OPTIONS
WTEC III Transmission ECU Replacement Check
REASON FOR QUESTION
If differential lock solenoid operates with replacement WTEC III transmission ECU installed, WTEC III transmission ECU is faulty. If differential lock solenoid does not operate with replacement WTEC III transmission ECU installed, WTEC III TPSS is faulty.



- 
- (1) Remove original WTEC III transmission ECU (para 8-7).
 - (2) Install replacement WTEC III transmission ECU (para 8-7).
 - (3) Start engine (TM 9-2320-366-10-1).
 - (4) Select MODE on WTEC III transmission TPSS (TM 9-2320- 366-10-1) and listen for operation of differential lock solenoid.
 - (5) If differential lock solenoid operates, replace WTEC III transmission ECU (para 8-7).
 - (6) If differential lock solenoid does not operate, replace WTEC III TPSS (para 8-3).
 - (7) Shut down engine (TM 9-2320-366-10-1).
 - (8) Install original WTEC III transmission ECU (para 8-7).

e95. ENGINE FAN RUNS CONSTANTLY	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P




CONTINUITY TEST

NOTE


Engine must be cool during test.

- (1) Raise cab (TM 9-2320-366-10-1).
- (2) Disconnect connector clamp from water temperature switch connector.
- (3) Disconnect connector P36 from water temperature switch connector.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to water temperature switch connector terminal 1.
- (6) Connect negative (-) probe of multimeter to water temperature switch connector terminal 2 and note reading on multimeter.
- (7) If continuity is not present, replace water temperature switch (para 7-50).



X2E9501A

e95. ENGINE FAN RUNS CONSTANTLY (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Set multimeter to volts dc.
- (2) Connect positive (+) probe of multimeter to connector P36-2.
- (3) Connect negative (-) probe of multimeter to ground.
- (4) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 24 vdc is not present, go to step 4 of this fault.
- (6) Position master power switch to off (TM 9-2320-366-10-1).




X2E9502A

CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P36-1.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, go to step 5 of this fault.
- (5) If continuity is present, fault corrected.
- (6) Connect connector P36 to water temperature switch connector.
- (7) Connect connector clamp on water temperature switch connector.

95. ENGINE FAN RUNS CONSTANTLY (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Lower cab (TM 9-2320-366-10-1).
- (2) Remove instrument panel assembly for access (para 7-15).
- (3) Disconnect connector J31 from connector P31.
- (4) Set multimeter to volts dc.
- (5) Connect positive (+) probe of multimeter to connector J31-3.
- (6) Connect negative (-) probe of multimeter to ground.
- (7) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If 24 vdc is not present, repair wire 1807 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (9) If 24 vdc is present, repair wire 1807 (para 2-45) or replace engine control cable assembly (para 7-80).
- (10) Position master power switch to off (TM 9-2320-366-10-1).
- (11) Connect connector J31 to connector P31.
- (12) Install instrument panel assembly (para 7-15).



X2E9503A

e95. ENGINE FAN RUNS CONSTANTLY (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Lower cab (TM 9-2320-366-10-1).
- (2) Remove instrument panel assembly for access (para 7-15).
- (3) Disconnect connector J31 from connector P31.
- (4) Set multimeter to volts dc.
- (5) Connect positive (+) probe of multimeter to connector J31-3.
- (6) Connect negative (-) probe of multimeter to ground.
- (7) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If 24 vdc is not present, repair wire 1807 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (9) If 24 vdc is present, repair wire 1806 (para 2-45) or replace engine control cable assembly (para 7-80).
- (10) Position master power switch to off (TM 9-2320-366-10-1).
- (11) Connect connector J31 to connector P31.
- (12) Install instrument panel assembly (para 7-15).



X2E9505A

e96. ENGINE FAN DOES NOT TURN OFF USING RADIATOR FAN OFF SWITCH	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P






WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Remove kick panel (para 16-3).
- (2) Remove three screws and washers from PDP.
- (3) Remove three screws from PDP.
- (4) Lift PDP outward to gain access.
- (5) Disconnect wire 1807 from terminal board TB1 terminal 38.
- (6) Disconnect connector PX34 from fan solenoid JX34.
- (7) Set multimeter to volts dc.
- (8) Connect positive (+) probe of multimeter to connector PX34-1.
- (9) Connect negative (-) probe of multimeter to ground.
- (10) Position master power switch to on (TM 9-2320-366-10-1).
- (11) Position radiator fan off switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (12) If 24 vdc is not present, go to step 4 of this fault.
- (13) Position radiator fan off switch to off (TM 9-2320-366-10-1).
- (14) Position master power switch to off (TM 9-2320-366-10-1).
- (15) Connect wire 1807 to terminal board TB1 terminal 38.




x2e96011

e96. ENGINE FAN DOES NOT TURN OFF USING RADIATOR FAN OFF SWITCH (CONT)

KNOWN INFO
Circuit breaker OK. Radiator fan off switch OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty fan solenoid. Faulty fan clutch.

2.
Is continuity present between connector PX34-2 and a known good ground?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 3011 is faulty.



KNOWN INFO
Circuit breaker OK. Radiator fan off switch OK. Dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty fan solenoid. Faulty fan clutch.


3.
Does fan solenoid release air pressure to radiator fan?

TEST OPTIONS
Operational Test
REASON FOR QUESTION
If fan solenoid does not release air pressure to engine fan, fan solenoid is faulty.



CONTINUITY TEST




- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector PX34-2.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3011 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (5) Connect connector PX34 to fan solenoid.



X2E96021


OPERATIONAL TEST

- (1) Remove air hose from fan solenoid.
- (2) Start engine (TM 9-2320-366-10-1) and allow air pressure to build up to normal level.
- (3) Position radiator fan off switch to on (TM 9-2320-366-10-1).
- (4) If air pressure is not present, replace fan solenoid (para 7-24).
- (5) If air pressure is present, replace fan clutch (para 6-14).
- (6) Position radiator fan off switch to off (TM 9-2320-366-10-1).
- (7) Position master power switch to off (TM 9-2320-366-10-1).
- (8) Connect wire 1807 to terminal board TB1 terminal 38.
- (9) Install PDP on dashboard with three screws.
- (10) Install three washers and screws in PDP.
- (11) Install air hose on fan solenoid.
- (12) Install kick panel (para 16-3).



X2E96031

e96. ENGINE FAN DOES NOT TURN OFF USING RADIATOR FAN OFF SWITCH (CONT)







WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Set multimeter to volts dc.
- (2) Connect positive (+) probe of multimeter to terminal board TB1 terminal 37.
- (3) Connect negative (-) probe of multimeter to ground.
- (4) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 24 vdc is not present, repair wire 1935 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (6) Position master power switch to off (TM 9-2320-366-10-1).
- (7) Install PDP on dashboard with three screws.
- (8) Install three washers and screws in PDP.
- (9) Install kick panel (para 16-3).




RADIATOR FAN OFF SWITCH

CONTINUITY TEST

- (1) Remove instrument panel assembly for access (para 7-15).
- (2) Disconnect connector PX1 from radiator fan off switch.
- (3) Position radiator fan off switch to on (TM 9-2320-366-10-1).
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to radiator fan off switch terminal 5.
- (6) Connect negative (-) probe of multimeter to radiator fan off switch terminal 1.
- (7) If continuity is not present, replace radiator fan off switch (para 7-18).
- (8) Position radiator fan off switch to off (TM 9-2320-366-10-1).

X2E 96041

e96. ENGINE FAN DOES NOT TURN OFF USING RADIATOR FAN OFF SWITCH (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Lower cab (TM 9-2320-366-10-1).
- (2) Remove instrument panel assembly for access (para 7-15).
- (3) Disconnect connector J31 from connector P31.
- (4) Set multimeter to volts dc.
- (5) Connect positive (+) probe of multimeter to connector J31-4.
- (6) Connect negative (-) probe of multimeter to ground.
- (7) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If 24 vdc is not present, repair wire 1806 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (9) If 24 vdc is present, repair wire 1806 (para 2-45) or replace engine control cable assembly (para 7-80).
- (10) Position master power switch to off (TM 9-2320-366-10-1).
- (11) Connect connector J31 to connector P31.
- (12) Install instrument panel assembly (para 7-15).



X2E96051

e97. ETHER START DOES NOT OPERATE	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1). Spare tire lowered (TM 9-2320-366-10-2).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P
Materials/Parts Wire, Elect, 50 ft (Item 71, Appendix D)	




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Disconnect connector clamp from ether valve connector.
- (2) Disconnect ether valve connector from connector J93.
- (3) Disconnect connector clamp from ether sensor connector.
- (4) Disconnect connector P42 from ether sensor connector.
- (5) Install jumper wire from connector P42-1 to connector P42-2.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter to connector J93-1.
- (8) Connect negative (-) probe of multimeter to ground.
- (9) Position master power switch to on (TM 9-2320-366-10-1).
- (10) Press ether start switch (TM 9-2320-366-10-1) and note reading on multimeter.
- (11) If 24 vdc is not present, go to step 3 of this fault.
- (12) Release ether start switch (TM 9-2320-366-10-1).
- (13) Position master power switch to off (TM 9-2320-366-10-1).
- (14) Remove jumper wire from connector P42-1 and connector P42-2.
- (15) Connect connector P42 to ether sensor connector.
- (16) Lower cab (TM 9-2320-366-10-1).



X2E9701A


ø97. ETHER START DOES NOT OPERATE (CONT)

KNOWN INFO
Circuit breaker OK. Ether cylinder OK. Ether start switch OK. Dashboard cable assembly OK. Engine control cable assembly OK.
POSSIBLE PROBLEMS
Faulty start and charging cable assembly. Faulty ether valve.




TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 3014 is faulty. If continuity is present, ether valve is faulty.

KNOWN INFO
Circuit breaker OK. Ether cylinder OK. Start and charging cable assembly OK. Ether valve OK.
POSSIBLE PROBLEMS
Faulty ether start switch. Faulty dashboard cable assembly. Faulty engine control cable assembly.




TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, ether start switch is faulty.

- CONTINUITY TEST**
- (1) Set multimeter to ohms.
 - (2) Connect positive (+) probe of multimeter to connector J93-2.
 - (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
 - (4) If continuity is not present, repair wire 3014 (para 2-45) or replace start and charging cable assembly (para 7-132).
 - (5) If continuity is present, replace ether valve (para 4-15).
 - (6) Raise spare tire (TM 9-2320-366-10-1).




X2E9702A

- CONTINUITY TEST**
- (1) Remove instrument panel assembly for access (para 7-15).
 - (2) Disconnect connector PX13 from ether start switch.
 - (3) Set multimeter to ohms.
 - (4) Connect positive (+) probe of multimeter to ether start switch terminal 1.
 - (5) Connect negative (-) probe of multimeter to ether start switch terminal 3.
 - (6) Position ether start switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
 - (7) If continuity is not present, replace ether start switch (para 7-18).



X2E9703A

ø97. ETHER START DOES NOT OPERATE (CONT)



WARNING


Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Set multimeter to volts dc.
- (2) Connect positive (+) probe of multimeter to connector PX13-1.
- (3) Connect negative (-) probe of multimeter to ground.
- (4) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 24 vdc is not present, repair wire 1401 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (6) Position master power switch to off (TM 9-2320-366-10-1).

CONTINUITY TEST


- (1) Disconnect connector P31 from connector J31.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector PX13-3.
- (4) Connect negative (-) probe of multimeter to connector J31-2 and note reading on multimeter.
- (5) If continuity is not present, repair wire 1402 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).



CONNECTOR PX13





PX13 X2E9704A




CONNECTOR P31

CONNECTOR J31



PX13




J31

X2E9705A

ø97. ETHER START DOES NOT OPERATE (CONT)

KNOWN INFO
Circuit breaker OK. Ether cylinder OK. Start and charging cable assembly OK. Ether valve OK. Ether start switch OK.
POSSIBLE PROBLEMS
Faulty engine control cable assembly. Faulty ether sensor. Faulty dashboard cable assembly.






TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 1402 is faulty.



CONTINUITY TEST


- (1) Raise cab (TM 9-2320-366-10).
- (2) Disconnect connector P42 from ether sensor connector.
- (3) Connect jumper wire to connector P42-2.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to connector P31-2.
- (6) Connect negative (-) probe of multimeter to jumper wire and note reading on multimeter.
- (7) If continuity is not present, repair wire 1402 (para 2-45) or replace engine control cable assembly (para 7-80).



X2E9706A

ø97. ETHER START DOES NOT OPERATE (CONT)


KNOWN INFO
Circuit breaker OK. Ether cylinder OK. Start and charging cable assembly OK. Ether valve OK. Ether start switch OK. Dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty engine control cable assembly. Faulty ether sensor.




TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, ether sensor is faulty.




- | CONTINUITY TEST | |
|-----------------|---|
| (1) | Set multimeter to ohms. |
| (2) | Connect positive (+) probe of multimeter to ether sensor terminal 1. |
| (3) | Connect negative (-) probe of multimeter to ether sensor terminal 2 and note reading on multimeter. |
| (4) | If continuity is not present, replace ether sensor (para 7-47). |



ø97. ETHER START DOES NOT OPERATE (CONT)




- CONTINUITY TEST**
- (1) Set multimeter to ohms.
 - (2) Connect jumper wire to connector P42-1.
 - (3) Lower cab (TM 9-2320-366-10-1).
 - (4) Connect positive (+) probe of multimeter to connector P31-15.
 - (5) Connect negative (-) probe of multimeter to jumper wire and note reading on multimeter.
 - (6) If continuity is not present, repair wire 1403 (para 2-45) or replace engine control cable assembly (para 7-80).
 - (7) Raise cab (TM 9-2320-366-10-1).
 - (8) Remove jumper wire from connector P42.
 - (9) Connect connector P42 to ether sensor connector.
 - (10) Connect connector clamp on ether sensor connector.
 - (11) Lower cab (TM 9-2320-366-10-1).



X2E9708A

ø97. ETHER START DOES NOT OPERATE (CONT)

KNOWN INFO
Circuit breaker OK. Ether cylinder OK. Start and charging cable assembly OK. Ether valve OK. Ether start switch OK. Dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty engine control cable assembly. Faulty ether sensor.




TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 1403 is faulty.




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector J31-15.
- (3) Connect negative (-) probe of multimeter to connector J43-1 and note reading on multimeter.
- (4) If continuity is not present, repair wire 1403 (para 2-45) or replace engine control cable assembly (para 7-80).




X2E9709A

ø97. ETHER START DOES NOT OPERATE (CONT)




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect jumper wire to connector J93-1.
- (3) Connect positive (+) probe of multimeter to connector P43-1.
- (4) Connect negative (-) probe of multimeter to jumper wire and note reading on multimeter.
- (5) If continuity is not present, repair wire 1403 (para 2-45) or replace engine control cable assembly (para 7-80).
- (6) If continuity is present, replace ether sensor (para 7-47).
- (7) Remove jumper wire from connector J93.
- (8) Connect connector J93 to ether valve connector.
- (9) Connect connector clamp to ether valve connector.
- (10) Connect connector J43 to connector P43.
- (11) Install instrument panel assembly (para 7-15).



X2E9710A

e98. EXCESSIVE CONDENSATION IN FUEL	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	Materials/Parts Wire, Elect, 50 ft (Item 71, Appendix D)
References TM 9-4910-571-12&P	





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.



VOLTAGE TEST

- (1) Raise cab (TM 9-2320-366-10-1).
- (2) Disconnect connector clamp from fuel/water separator.
- (3) Disconnect connector P33 from fuel/water separator.
- (4) Set multimeter to volts dc.
- (5) Connect positive (+) probe of multimeter to connector P33-2.
- (6) Connect negative (-) probe of multimeter to ground.
- (7) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If 24 vdc is not present, go to step 3 of this fault.
- (9) Position master power switch to off (TM 9-2320-366-10-1).




X2E9801A

e98. EXCESSIVE CONDENSATION IN FUEL (CONT)



CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P33-1.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3017 (para 2-45) or replace engine control cable assembly (para 7-80).
- (5) If continuity is present, replace fuel/water separator (para 4-13).
- (6) Connect connector P33 to fuel/water separator.
- (7) Connect connector clamp on fuel/water separator.
- (8) Lower cab (TM 9-2320-366-10-1).




X2E9802A

WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Remove instrument panel assembly for access (para 7-15).
- (2) Disconnect connector P31 from connector J31.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to connector J31-13.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 24 vdc is not present, repair wire 1460 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (8) If 24 vdc is present, repair wire 1460 (para 2-45) or replace engine control cable assembly (para 7-80).
- (9) Position master power switch to off (TM 9-2320-366-10-1).
- (10) Connect connector P31 to connector J31.
- (11) Install instrument panel assembly on (para 7-15).



X2E9803A

e99. RADIO DOES NOT OPERATE	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Remove kick panel (para 16-3).
- (2) Disconnect connector J78 from radio.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to connector J78-3.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 12 vdc is not present, go to step 4 of this fault.
- (8) Position master power switch to off (TM 9-2320-366-10-1).




42E99011

e99. RADIO DOES NOT OPERATE (CONT)



- | CONTINUITY TEST | |
|-----------------|--|
| | (1) Set multimeter to ohms. |
| | (2) Connect positive (+) probe of multimeter to connector J78-2. |
| | (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter. |
| | (4) If continuity is not present, repair wire 3018 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11). |



42E99021


- | CONTINUITY TEST | |
|-----------------|--|
| | (1) Set multimeter to ohms. |
| | (2) Connect positive (+) probe of multimeter to connector J78-4. |
| | (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter. |
| | (4) If continuity is not present, repair wire 3019 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11). |
| | (5) If continuity is present, replace radio (notify Communications Section). |
| | (6) Connect connector J78 to radio. |
| | (7) Install kick panel (para 16-3). |

e99. RADIO DOES NOT OPERATE (CONT)

KNOWN INFO
Circuit breaker OK. Radio OK.
POSSIBLE PROBLEMS
Faulty relay K53. Faulty dashboard cable assembly.

4.
Is continuity present between relay K53 terminals 30 and 87A?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, relay K53 is faulty.



KNOWN INFO
Circuit breaker OK. Radio OK. Relay K53 OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly.

5. **WARNING**
Read WARNING on following page.
Is 24 vdc present at relay K53 terminal 85?

TEST OPTIONS
Voltage Test or STE/ICE-R #89
REASON FOR QUESTION
If 24 vdc is not present, wire 1960 is faulty. If 24 vdc is present, wire 1906 is faulty.



CONTINUITY TEST


- (1) Remove relay K53 from PDP.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to relay K53 terminal 30.
- (4) Connect negative (-) probe of multimeter to relay K53 terminal 87A and note reading on multimeter.
- (5) If continuity is not present, replace relay K53 (para 7-9).

WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Set multimeter to volts dc.
- (2) Connect positive (+) probe of multimeter to PDP, terminal 85, where relay K53 was removed.
- (3) Connect negative (-) probe of multimeter to ground.
- (4) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 24 vdc is not present, repair wire 1960 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (6) If 24 vdc is present, repair wire 1906 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (7) Position master power switch to off (TM 9-2320-366-10-1).
- (8) Install relay K53 in PDP.
- (9) Connect connector J78 to radio.
- (10) Install kick panel (para 16-3).





X2E99031

e100. START INHIBIT PUSHBUTTON DOES NOT OPERATE	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P
Materials/Parts Wire, Elect, 50 ft (Item 71, Appendix D)	




CONTINUITY TEST

- (1) Remove PDP cover (para 16-2).
- (2) Remove three screws and washers from PDP.
- (3) Remove three screws from PDP.
- (4) Lift PDP outward to gain access.
- (5) Disconnect terminal lugs TL158 and TL159 from start inhibit pushbutton switch.
- (6) Set multimeter to ohms.
- (7) Connect positive (+) probe of multimeter to start inhibit pushbutton switch terminal 1.
- (8) Connect negative (-) probe of multimeter to start inhibit pushbutton switch terminal 2.
- (9) Press start inhibit pushbutton switch and hold (TM 9-2320-366-10-1) and note reading on multimeter.
- (10) If continuity is not present, replace start inhibit pushbutton switch (para 7-19).
- (11) Install PDP on dashboard with three screws.
- (12) Install three washers and screws in PDP.



X2EK0011

ø100. START INHIBIT PUSHBUTTON DOES NOT OPERATE (CONT)





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Set multimeter to volts dc.
- (2) Connect positive (+) probe of multimeter to terminal lug TL159.
- (3) Connect negative (-) probe of multimeter to ground.
- (4) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 24 vdc is not present, repair wire 1463 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (6) Position master power switch to off (TM 9-2320-366-10-1).




X2EK0021

CONTINUITY TEST



- (1) Remove relay K19 from PDP.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to terminal lug TL158.
- (4) Connect negative (-) probe of multimeter to PDP, terminal 86, where relay K19 was removed, and note reading on multimeter.
- (5) If continuity is not present, repair wire 1637 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (6) Connect terminal lugs TL158 and TL159 to start inhibit pushbutton switch.

ø100. START INHIBIT PUSHBUTTON DOES NOT OPERATE (CONT)



CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to PDP, terminal 85, where relay K19 was removed.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3016 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (5) If continuity is present, replace relay K19 (para 7-9).
- (6) Install relay K19 in PDP.
- (7) Install PDP cover (para 16-2).



Pop002-

X2EK0031

e101. AIR DRYER DOES NOT OPERATE (ALL MODELS EXCEPT M1090/M1094)	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Disconnect connector P80 from air dryer connector.
- (2) Set multimeter to volts dc.
- (3) Connect positive (+) probe of multimeter to connector P80-2.
- (4) Connect negative (-) probe of multimeter to ground.
- (5) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (6) If 24 vdc is not present, go to step 3 of this fault.
- (7) Position master power switch to off (TM 9-2320-366-10-1).





X2EK1011

ø101. AIR DRYER DOES NOT OPERATE (ALL MODELS EXCEPT M1090/M1094) (CONT)




- | CONTINUITY TEST | |
|-----------------|---|
| | (1) Set multimeter to ohms. |
| | (2) Connect positive (+) probe of multimeter to connector P80-1. |
| | (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter. |
| | (4) If continuity is not present, repair wire 3009 (para 2-45) or replace start and charging cable assembly (para 7-132). |
| | (5) If continuity is present, replace or repair air dryer (para 23-11). |
| | (6) Connect connector P80 to air dryer connector. |



X2EK1021

ø101. AIR DRYER DOES NOT OPERATE (ALL MODELS EXCEPT M1090/M1094) (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Remove instrument panel assembly for access (para 7-15).
- (2) Disconnect connector J43 from connector P43.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to connector J43-9.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 24 vdc is not present, repair wire 1481 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (8) If 24 vdc is present, repair wire 1481 (para 2-45) or replace start and charging cable assembly (para 7-132).
- (9) Position master power switch to off (TM 9-2320-366-10-1).
- (10) Connect connector J43 to connector P43.
- (11) Install instrument panel assembly (para 7-15).



42EJ203A

e102. M1090/M1094 AIR DRYER DOES NOT OPERATE	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P






WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Disconnect connector P80B from air dryer.
- (2) Set multimeter to volts dc.
- (3) Connect positive (+) probe of multimeter to connector P80B-2.
- (4) Connect negative (-) probe of multimeter to ground.
- (5) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (6) If 24 vdc is not present, go to step 3 of this fault.
- (7) Position master power switch to off (TM 9-2320-366-10-1).






CONNECTOR P80B

42EK2011

e102. M1090/M1094 AIR DRYER DOES NOT OPERATE (CONT)




- | CONTINUITY TEST | |
|-----------------|--|
| | (1) Set multimeter to ohms. |
| | (2) Connect positive (+) probe of multimeter to connector P80B-1. |
| | (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter. |
| | (4) If continuity is not present, go to step 5 of this fault. |
| | (5) If continuity is present, replace air dryer (para 23-11). |
| | (6) Connect connector P80B to air dryer. |



42EK2021

e102. M1090/M1094 AIR DRYER DOES NOT OPERATE (CONT)




WARNING


Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Remove instrument panel assembly for access (para 7-15).
- (2) Disconnect connector J43 from connector P43.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to connector J43-9.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 24 vdc is not present, repair wire 1481 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (8) Position master power switch to off (TM 9-2320-366-10-1).
- (9) Connect connector J43 to connector P43.
- (10) Install instrument panel assembly (para 7-15).



e102. M1090/M1094 AIR DRYER DOES NOT OPERATE (CONT)





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST


- (1) Disconnect connector P80 from connector J80A.
- (2) Set multimeter to volts dc.
- (3) Connect positive (+) probe of multimeter to connector P80-2.
- (4) Connect negative (-) probe of multimeter to ground.
- (5) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (6) If 24 vdc is not present, repair wire 1481 in start and charging cable assembly (para 2-45) or replace start and charging cable assembly (para 7-132).
- (7) If 24 vdc is present, repair wire 1481 in dump cable assembly (para 2-45) or replace dump cable assembly (para 7-124).
- (8) Position master power switch to off (TM 9-2320-366-10-1).
- (9) Connect connector P80 to connector J80A.
- (10) Connect connector P80B to air dryer.




42EK2041

e102. M1090/M1094 AIR DRYER DOES NOT OPERATE (CONT)






- | CONTINUITY TEST | |
|-----------------|--|
| | (1) Connect connector P80B to air dryer. |
| | (2) Disconnect connector P80 from connector J80A. |
| | (3) Set multimeter to ohms. |
| | (4) Connect positive (+) probe of multimeter to connector P80-1. |
| | (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter. |
| | (6) If continuity is not present, repair wire 3009 in start and charging cable assembly (para 2-45) or replace start and charging cable assembly (para 7-132). |
| | (7) If continuity is present, repair wire 3009 in dump cable assembly (para 2-45) or replace dump cable assembly (para 7-124). |
| | (8) Connect connector P80 to connector J80A. |



42EK2051

e103. BATTERY TESTER DOES NOT OPERATE	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C) Goggles, Industrial (Item 15, Appendix C) Gloves, Rubber (Item 13, Appendix C) Apron, Rubber (Item 3, Appendix C)
Personnel Required (2)	
References TM 9-4910-571-12&P	




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock. Batteries can explode from a spark. Battery acid is harmful to skin and eyes. Always wear eye protection and rubber gloves when working with batteries.


CONTINUITY TEST

- (1) Remove battery box cover (TM 9-2320-366-10-2).
- (2) Open fuse holder on battery tester.
- (3) Remove fuse from fuse holder.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to one end of fuse.
- (6) Connect negative (-) probe of multimeter to other end of fuse and note reading on multimeter.
- (7) If continuity is not present, replace battery tester 3 milliamp fuse (para 7-54).



X2ek3011

¶103. BATTERY TESTER DOES NOT OPERATE (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock. Batteries can explode from a spark. Battery acid is harmful to skin and eyes. Always wear eye protection and rubber gloves when working with batteries.

VOLTAGE TEST

- (1) Set multimeter to volts dc.
- (2) Connect positive (+) probe of multimeter to terminal in right side of fuse holder.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If 24 vdc is not present, repair wire from right side of fuse holder to BT2-E1 (para 2-45) or replace battery tester (para 7-54).
- (5) If 24 vdc is present, replace battery tester (para 7-54).
- (6) Install fuse in battery tester fuse holder.
- (7) Close battery tester fuse holder.
- (8) Install battery box cover (TM 9-2320-366-10-2).



X2ek3021

e104. M1084/M1086 MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE


INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Personnel Required
 (2)

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 STE/ICE-R (Item 41, Appendix C)

References
 TM 9-4910-571-12&P




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Loosen four screws on junction box cover.
- (2) Open cover on junction box.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter on terminal board position 5.
- (5) Connect negative (-) probe of multimeter on ground quick-connect terminal block (above main power switch) and note reading on multimeter.
- (6) If 24 VDC is not present, go to step 2 of this fault.
- (7) If 24 VDC is present, perform Electrical System troubleshooting task e115. M1084/M1086 Material Handling Crane (MHC) Overload Shutdown System Stays Activated.




42EK4011

e104. M1084/M1086 MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE (CONT)

KNOWN INFO
Battery voltage OK. Circuit breakers OK. Auxiliary panel cable assembly OK. Dashboard wiring harness OK. Hydraulic system OK.
POSSIBLE PROBLEMS
Faulty crane power cable. Faulty junction box internal wiring. Faulty reverse polarity diode(s).


2.
Is continuity present between crane power cable connector pin B and terminal board position 5?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, crane power cable is faulty.



CONTINUITY TEST

- (1) Disconnect connector P171 from crane power cable connector.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to crane power cable connector pin B.
- (4) Connect negative (-) probe of multimeter to ground quick-connect terminal block (above main power switch) and note reading on multimeter.
- (5) If continuity is not present, replace crane power cable (para 7-90).
- (6) Connect positive (+) probe of multimeter to crane power cable connector pin C.
- (7) Connect negative (-) probe of multimeter to junction box terminal board position 5 and note reading on multimeter.
- (8) If continuity is not present, replace crane power cable (para 7-90).
- (9) Close cover on junction box.
- (10) Tighten four screws on junction box.



e104. MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE (CONT)


KNOWN INFO
Battery voltage OK. Circuit breakers OK. Auxiliary panel cable assembly OK. Dashboard wiring harness OK. Hydraulic system OK.
POSSIBLE PROBLEMS
Faulty crane power cable. Faulty junction box internal wiring. Faulty reverse polarity diode(s).

3.

WARNING
Read WARNING on following page.


Is 24 VDC present at connector P171-C?

TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
If 24 VDC is not present, wire 2069 is faulty.



VOLTAGE TEST

- (1) Set multimeter to volts DC.
- (2) Connect positive (+) probe of multimeter on connector P171-C.
- (2) Connect negative (-) probe of multimeter on ground.
- (3) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (4) If 24 VDC is not present, repair wire 2069 (para 2-45) or replace crane power cable (para 7-90).
- (5) Position master power switch to off (TM 9-2320-366-10-1).




X2E8904A

e104. MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE (CONT)


KNOWN INFO
Battery voltage OK. Circuit breakers OK. Auxiliary panel cable assembly OK. Dashboard wiring harness OK. Hydraulic system OK.
POSSIBLE PROBLEMS
Faulty crane power cable. Faulty junction box internal wiring. Faulty reverse polarity diode(s).

KNOWN INFO
Battery voltage OK. Circuit breakers OK. Auxiliary panel cable assembly OK. Dashboard wiring harness OK. Hydraulic system OK.
POSSIBLE PROBLEMS
Faulty crane power cable. Faulty junction box internal wiring. Faulty reverse polarity diode(s).



CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P171-B.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3077 (para 2-45) or replace crane power cable (para 7-90).




X2E8905A

CONTINUITY TEST



- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P171-E.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3078 (para 2-45) or replace crane power cable (para 7-90).
- (5) If continuity is present, notify DS Maintenance.
- (6) Connect connector P171 to crane power cable connector.

e105. M1084/M1086 MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE FROM REMOTE CONTROL	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P




CONTINUITY TEST


- (1) Loosen four screws on junction box cover.
- (2) Open cover on junction box.
- (3) Disconnect remote control cable from remote control box.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter on pin E of connector on remote control cable.
- (6) Connect negative (-) probe on junction box terminal board position 25 and note reading on multimeter.
- (7) If continuity is not present, replace remote control cable (para 7-96).
- (8) Close cover on junction box.
- (9) Tighten four screws on junction box cover.



WIRES REMOVED FOR CLARITY POSITION 25



REMOTE CONTROL CABLE CONNECTOR




REMOTE CONTROL CABLE CONNECTOR

42EK5011

e105. M1084/M1086 MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE FROM REMOTE CONTROL (CONT)


KNOWN INFO
Battery voltage OK.
Main power circuit breaker switch OK.
Input connector OK.
Crane power cable OK.
Reverse polarity diodes OK.
Control lockout relay OK.
Left outrigger proximity sensing switch cable assembly OK.
Right outrigger proximity sensing switch cable assembly OK.
Junction box internal wiring OK.
Overload shutdown system OK.
Hydraulic system shutdown relay OK.
Remote control cable OK.
POSSIBLE PROBLEMS
Faulty external remote control cable.
Faulty remote control box ON/OFF switch.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter on pin E of one end of external remote control cable connector.
	(3) Connect negative (-) probe of multimeter on pin E of other end of external remote control cable and note reading on multimeter.
	(4) If continuity is not present, replace external remote control cable.





42E9002-

e105. M1084/M1086 MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE FROM REMOTE CONTROL (CONT)



CONTINUITY TEST


- (1) Position ON/OFF switch to ON.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin H of remote control box receptacle.
- (4) Connect negative (-) probe of multimeter on pin J of remote control box receptacle and note reading on multimeter.
- (5) If continuity is not present, replace ON/OFF switch (para 7-32).
- (6) Position ON/OFF switch to OFF.
- (7) Connect positive (+) probe of multimeter on pin E of remote control box receptacle.
- (8) Connect negative (-) probe of multimeter on pin K of remote control box receptacle and note reading on multimeter.
- (9) If continuity is not present, replace ON/OFF switch (para 7-32).
- (10) If continuity is present, notify DS Maintenance.



**REMOTE CONTROL
BOX CONNECTOR**

42EK5031

e106. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST UP DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.


OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to and remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 23.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).


NOTE

Step (9) requires the aid of an assistant.


- (9) Position HOIST UP/DOWN to UP and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.



WIRES REMOVED FOR CLARITY




POSITION 23






42EK6011

e106. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST UP DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST

- (1) Disconnect hoist up solenoid connector from hoist up solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of hoist up solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of hoist up solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 23 and note reading on multimeter.
- (7) If continuity is not present, replace hoist up solenoid cable (para 7-93).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect hoist up solenoid cable connector to hoist up solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



42EK6021

e106. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST UP DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin F of connector on remote control box.
- (4) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE

Step (5) requires the aid of an assistant.

- (5) Position HOIST UP/DOWN controller to UP and note reading on multimeter.
- (6) If continuity is not present, go to step 4 of this fault.
- (7) If continuity is present, go to step 5 of this fault.



REMOTE CONTROL BOX CONNECTOR


42EK6031

e106. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST UP DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK.
Hoist up solenoid cable OK.
Hoist up solenoid OK.
External remote control cable OK.
Remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control box internal wiring harness.
Faulty hoist up/down controller.


4.
Is continuity present from remote control box connector pin F to HOIST UP/DOWN controller internal wiring harness pin 3 and remote control box connector pin H to HOIST UP/DOWN controller internal wiring harness pin 1?

TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control box internal wiring harness is faulty.
If continuity is present, HOIST UP/DOWN controller is faulty.



CONTINUITY TEST


- (1) Remove HOIST UP/DOWN controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin F of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 3 of HOIST UP/DOWN controller internal wiring harness and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (6) Connect negative (-) probe of multimeter on pin 1 of HOIST UP/DOWN controller internal wiring harness and note reading on multimeter.
- (7) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (8) If continuity is present, replace HOIST UP/DOWN controller (para 7-32).
- (9) Install HOIST UP/DOWN controller (para 7-32).
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



42EK6041

e106. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST UP DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Hoist up solenoid cable OK. Hoist up solenoid OK. Remote control box internal wiring harness OK. HOIST UP/DOWN controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
1	Set multimeter to ohms.
2	Connect positive (+) probe of multimeter on pin F of one end of external remote control cable connector.
4	Connect negative (-) probe of multimeter on pin F of other end of external remote control cable and note reading on multimeter.
5	If continuity is not present, replace external remote control cable.







42E1365-

e106. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST UP DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin F of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 23 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-96).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).



42ek6061

e107. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST DOWN DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.



OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to and remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 24.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).

NOTE

Step (9) requires the aid of an assistant.

- (9) Position HOIST UP/DOWN to DOWN and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.




WIRES REMOVED FOR CLARITY

POSITION 24


TELESCOPE IN/OUT CONTROLLER

REMOTE CONTROL BOX ON/OFF SWITCH




42E1371A

e107. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)




- | CONTINUITY TEST | |
|-----------------|--|
| (1) | Disconnect hoist down solenoid connector from hoist up solenoid. |
| (2) | Set multimeter to ohms. |
| (3) | Connect positive (+) probe of multimeter on pin 2 of hoist down solenoid cable connector. |
| (4) | Connect negative (-) probe of multimeter on ground and note reading on multimeter. |
| (5) | Connect positive (+) probe of multimeter on pin 1 of hoist down solenoid cable connector. |
| (6) | Connect negative (-) probe of multimeter on terminal board lower position 24 and note reading on multimeter. |
| (7) | If continuity is not present, replace hoist down solenoid cable (para 7-91). |
| (8) | If continuity is present, notify DS Maintenance. |
| (9) | Connect hoist down solenoid cable connector to hoist down solenoid. |
| (10) | Close cover on junction box. |
| (11) | Tighten four screws on junction box cover. |
| (12) | Stow crane (TM 9-2320-366-10-1). |



42ek7021

e107. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin G of connector on remote control box.
- (4) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE

Step (5) requires the aid of an assistant.


- (5) Position HOIST UP/DOWN controller to DOWN and note reading on multimeter.
- (6) If continuity is not present, go to step 4 of this fault.
- (7) If continuity is present, go to step 5 of this fault.



REMOTE CONTROL BOX CONNECTOR


42EK7031

e107. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)



CONTINUITY TEST


- (1) Remove HOIST UP/DOWN controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin G of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 4 of HOIST UP/DOWN controller internal wiring harness and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (6) Connect negative (-) probe of multimeter on pin 1 of HOIST UP/DOWN controller internal wiring harness and note reading on multimeter.
- (7) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (8) If continuity is present, replace HOIST UP/DOWN controller (para 7-32).
- (9) Install HOIST UP/DOWN controller (para 7-32).
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



42EK7041

ø107. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Hoist down solenoid cable OK. Hoist down solenoid OK. Remote control box internal wiring harness OK. HOIST UP/DOWN controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
1	Set multimeter to ohms.
2	Connect positive (+) probe of multimeter on pin G of one end of external remote control cable connector.
3	Connect negative (-) probe of multimeter on pin G of other end of external remote control cable and note reading on multimeter.
4	If continuity is not present, replace external remote control cable.



42E1375-

e107. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Hoist down solenoid cable OK. Hoist down solenoid OK. Remote control box internal wiring harness OK. HOIST UP/DOWN controller OK. External remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control cable.







TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control cable is faulty.




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin G of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 24 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-96).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).



e108. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM UP DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.




OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 21.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).

NOTE


Step (9) requires the aid of an assistant.

- (9) Position BOOM UP/DOWN to UP and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.



42E1381-



e108. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM UP DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST

- (1) Disconnect boom up solenoid connector from boom up solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of boom up solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of boom up solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 21 and note reading on multimeter.
- (7) If continuity is not present, replace boom up solenoid cable (para 7-88).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect boom up solenoid cable connector to boom up solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).


BOOM UP SOLENOID




BOOM UP SOLENOID CABLE CONNECTOR



WIRES REMOVED FOR CLARITY




POSITION 21



42ek8021

e108. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM UP DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Boom up solenoid cable OK Boom up solenoid OK.
POSSIBLE PROBLEMS
Faulty boom up/down controller. Faulty remote control box internal wiring harness. Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
This question eliminates possible problems and determines where to continue troubleshooting.





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin N of connector on remote control box.
- (4) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE

Step (5) requires the aid of an assistant.

- (5) Position BOOM UP/DOWN controller to UP and note reading on multimeter.
- (6) If continuity is not present, go to step 4 of this fault.
- (7) If continuity is present, go to step 5 of this fault.



REMOTE CONTROL BOX CONNECTOR


42EK8031

e108. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM UP DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Boom up solenoid cable OK Boom up solenoid OK. External remote control cable OK. Remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control box internal wiring harness. Faulty boom up/down controller.


4.
Is continuity present from remote control box connector pin N to BOOM UP/DOWN controller internal wiring harness pin 3 and remote control box connector pin H to BOOM UP/DOWN controller internal wiring harness pin 1?

TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control box internal wiring harness is faulty. If continuity is present, BOOM UP/DOWN controller is faulty.



CONTINUITY TEST


- (1) Remove BOOM UP/DOWN controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin N of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 3 of BOOM UP/DOWN controller internal wiring harness and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (6) Connect negative (-) probe of multimeter on pin 1 of BOOM UP/DOWN controller internal wiring harness and note reading on multimeter.
- (7) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (8) If continuity is present, replace BOOM UP/DOWN controller (para 7-32).
- (9) Install BOOM UP/DOWN controller (para 7-32).
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



42EK8041

e108. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM UP DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Boom up solenoid cable OK Boom up solenoid OK. Remote control box internal wiring harness OK. BOOM UP/DOWN controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
1	Set multimeter to ohms.
2	Connect positive (+) probe of multimeter on pin N of one end of external remote control cable connector.
3	Connect negative (-) probe of multimeter on pin N of other end of external remote control cable and note reading on multimeter.
4	If continuity is not present, replace external remote control cable.



42E1385-

e108. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM UP DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Boom up solenoid cable OK. Boom up solenoid OK. Remote control box internal wiring harness OK. BOOM UP/DOWN controller OK. External remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control cable.





TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control cable is faulty.





CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin N of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 21 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-96).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).



WIRES REMOVED FOR CLARITY

POSITION 21




REMOTE CONTROL CABLE CONNECTOR

REMOTE CONTROL CABLE CONNECTOR

42EK8061

e109. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM DOWN DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.



OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 22.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).

NOTE


Step (9) requires the aid of an assistant.

- (9) Position BOOM UP/DOWN to DOWN and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.




WIRES REMOVED FOR CLARITY

POSITION 22



42E1391-


e109. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST

- (1) Disconnect boom down solenoid connector from boom down solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of boom down solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of boom down solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 22 and note reading on multimeter.
- (7) If continuity is not present, replace boom down solenoid cable (para 7-86).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect boom down solenoid cable connector to boom down solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).


BOOM DOWN SOLENOID



WIRES REMOVED FOR CLARITY




POSITION 22



42ek9021

e109. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin M of connector on remote control box.
- (4) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE

Step (5) requires the aid of an assistant.

- (5) Position BOOM UP/DOWN controller to DOWN and note reading on multimeter.
- (6) If continuity is not present, go to step 4 of this fault.
- (7) If continuity is present, go to step 5 of this fault.



REMOTE CONTROL BOX CONNECTOR


42EK9031

e109. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Boom down solenoid cable OK. Boom down solenoid OK. External remote control cable OK. Remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control box internal wiring harness. Faulty boom up/down controller.


4.
Is continuity present from remote control box connector pin M to BOOM UP/DOWN controller internal wiring harness pin 4 and from remote control box connector pin H to BOOM UP/DOWN controller internal wiring harness pin 1?

TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control box internal wiring harness is faulty. If continuity is present, BOOM UP/DOWN controller is faulty.



CONTINUITY TEST


- (1) Remove BOOM UP/DOWN controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin M of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 4 of BOOM UP/DOWN controller internal wiring harness and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (6) Connect negative (-) probe of multimeter on pin 1 of BOOM UP/DOWN controller internal wiring harness and note reading on multimeter.
- (7) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (8) If continuity is present, replace BOOM UP/DOWN controller (para 7-32).
- (9) Install BOOM UP/DOWN controller (para 7-32).
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



42EK9041

e109. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Boom down solenoid cable OK. Boom down solenoid OK. Remote control box internal wiring harness OK. BOOM UP/DOWN controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
1	Set multimeter to ohms.
2	Connect positive (+) probe of multimeter on pin M of one end of external remote control cable connector.
3	Connect negative (-) probe of multimeter on pin M of other end of external remote control cable and note reading on multimeter.
4	If continuity is not present, replace external remote control cable.





42E1395-

e109. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin M of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 22 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-96).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).




WIRES REMOVED FOR CLARITY

POSITION 22




REMOTE CONTROL CABLE CONNECTOR



REMOTE CONTROL CABLE CONNECTOR

42EK9061

e110. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE IN DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.




OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 20.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).

NOTE


Step (9) requires the aid of an assistant.

- (9) Position TELESCOPE IN/OUT to IN and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.






42E1401-

e110. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE IN DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST

- (1) Disconnect telescope in solenoid connector from telescope in solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of telescope in solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of telescope in solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 20 and note reading on multimeter.
- (7) If continuity is not present, replace telescope in solenoid cable (para 7-101).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect telescope in solenoid cable connector to telescope in solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



42E1402-

e110. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE IN DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin D of connector on remote control box.
- (4) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE

Step (5) requires the aid of an assistant.

- (5) Position TELESCOPE IN/OUT controller to IN and note reading on multimeter.
- (6) If continuity is not present, go to step 4 of this fault.
- (7) If continuity is present, go to step 5 of this fault.



REMOTE CONTROL BOX CONNECTOR


42EL0031

e110. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE IN DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Telescope in solenoid cable OK. Telescope in solenoid OK. External remote control cable OK. Remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control box internal wiring harness. Faulty telescope in/out controller.




4.
Is continuity present from remote control box connector pin D to TELESCOPE IN/OUT controller internal wiring harness pin 3 and from remote control box connector pin H to TELESCOPE IN/OUT controller internal wiring harness pin 1?

TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control box internal wiring harness is faulty. If continuity is present, TELESCOPE IN/OUT controller is faulty.



CONTINUITY TEST


- (1) Remove TELESCOPE IN/OUT controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin D of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 3 of TELESCOPE IN/OUT controller internal wiring harness and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (6) Connect negative (-) probe of multimeter on pin 1 of TELESCOPE IN/OUT controller internal wiring harness and note reading on multimeter.
- (7) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (8) If continuity is present, replace TELESCOPE IN/OUT controller (para 7-32).
- (9) Install TELESCOPE IN/OUT controller (para 7-32).
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



42EK104A

e110. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE IN DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Telescope in solenoid cable OK. Telescope in solenoid OK. Remote control box internal wiring harness OK. TELESCOPE IN/OUT controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter on pin D of one end of external remote control cable connector.
	(3) Connect negative (-) probe of multimeter on pin D of other end of external remote control cable and note reading on multimeter.
	(4) If continuity is not present, replace external remote control cable.







42E1405-

ø110. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE IN DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin D of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 20 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-96).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).



42EL0061

e111. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.



OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 19.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).


NOTE

Step (9) requires the aid of an assistant.

- (9) Position TELESCOPE IN/OUT to OUT and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.




WIRES REMOVED FOR CLARITY POSITION 19




42E1411-

e111. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST


- (1) Disconnect telescope out solenoid connector from telescope out solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of telescope out solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of telescope out solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 19 and note reading on multimeter.
- (7) If continuity is not present, replace telescope out solenoid cable (para 7-103).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect telescope out solenoid cable connector to telescope out solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



WIRES REMOVED FOR CLARITY




POSITION 19




42E1412-

e111. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT DOES NOT OPERATE FROM REMOTE STATION (CONT)




e111. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST


- (1) Remove TELESCOPE IN/OUT controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin C of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 4 of TELESCOPE IN/OUT controller internal wiring harness and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (6) Connect negative (-) probe of multimeter on pin 1 of TELESCOPE IN/OUT controller internal wiring harness and note reading on multimeter.
- (7) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (8) If continuity is present, replace TELESCOPE IN/OUT controller (para 7-32).
- (9) Install TELESCOPE IN/OUT controller (para 7-32).
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



REMOTE CONTROL TELESCOPE IN/OUT WIRING HARNESS CONNECTOR




REMOTE CONTROL BOX CONNECTOR COVER



42EK004A

e111. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Telescope out solenoid cable OK. Telescope out solenoid OK. Remote control box internal wiring harness OK. TELESCOPE IN/OUT controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter on pin C of one end of external remote control cable connector.
	(3) Connect negative (-) probe of multimeter on pin C of other end of external remote control cable and note reading on multimeter.
	(4) If continuity is not present, replace external remote control cable.





42E1415-

e111. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin C of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 19 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-96).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).




WIRES REMOVED FOR CLARITY

POSITION 19




REMOTE CONTROL CABLE CONNECTOR



REMOTE CONTROL CABLE CONNECTOR

42EL1061

e112. M1084/M1086 MATERIAL HANDLING CRANE (MHC) SWING CW DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.



OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 18.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).


NOTE

Step (9) requires the aid of an assistant.

- (9) Position SWING CW/CCW to CW and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.




WIRES REMOVED FOR CLARITY POSITION 18




42E1421-

e112. M1084/M1086 MATERIAL HANDLING CRANE (MHC) SWING CW DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Disconnect swing CW solenoid connector from swing CW solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of swing CW solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of swing CW solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 18 and note reading on multimeter.
- (7) If continuity is not present, replace swing CW solenoid cable (para 7-99).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect swing CW solenoid cable connector to swing CW solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).




WIRES REMOVED FOR CLARITY



42E1422-

ø112. M1084/M1086 MATERIAL HANDLING CRANE (MHC) SWING CW DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin L of connector on remote control box.
- (4) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE

Step (5) requires the aid of an assistant.


- (5) Position SWING CW/CCW controller to CW and note reading on multimeter.
- (6) If continuity is not present, go to step 4 of this fault.
- (7) If continuity is present, go to step 5 of this fault.



REMOTE CONTROL BOX CONNECTOR


42EL2031

ø112. M1084/M1086 MATERIAL HANDLING CRANE (MHC) SWING CW DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Remove SWING CW/CCW controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin L of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 4 of SWING CW/CCW controller internal wiring harness and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (6) Connect negative (-) probe of multimeter on pin 1 of SWING CW/CCW controller internal wiring harness and note reading on multimeter.
- (7) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (8) If continuity is present, replace SWING CW/CCW controller (para 7-32).
- (9) Install SWING CW/CCW controller (para 7-32).
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).




REMOTE CONTROL SWING CW/CCW INTERNAL WIRING HARNESS CONNECTOR



42EL2041

ø112. M1084/M1086 MATERIAL HANDLING CRANE (MHC) SWING CW DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Swing CW solenoid cable OK. Swing CW solenoid OK. Remote control box internal wiring harness OK. SWING CW/CCW controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
1	Set multimeter to ohms.
2	Connect positive (+) probe of multimeter on pin L of one end of external remote control cable connector.
3	Connect negative (-) probe of multimeter on pin L of other end of external remote control cable and note reading on multimeter.
4	If continuity is not present, replace external remote control cable.





42E1425-

e112. M1084/M1086 MATERIAL HANDLING CRANE (MHC) SWING CW DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin L of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 18 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-96).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).




WIRES REMOVED FOR CLARITY

POSITION 18




REMOTE CONTROL CABLE CONNECTOR



REMOTE CONTROL CABLE CONNECTOR

42EL2061

e113. M1084/M1086 MATERIAL HANDLING CRANE (MHC) SWING CCW DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.



OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 17.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).


NOTE

Step (9) requires the aid of an assistant.

- (9) Position SWING CW/CCW controller to CCW and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.




WIRES REMOVED FOR CLARITY POSITION 17




42E1431-

e113. M1084/M1086 MATERIAL HANDLING CRANE (MHC) SWING CCW DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Disconnect swing CCW solenoid connector from swing CCW solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of swing CCW solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of swing CCW solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 17 and note reading on multimeter.
- (7) If continuity is not present, replace swing CCW solenoid cable (para 7-98).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect swing CCW solenoid cable connector to swing CCW solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).




WIRES REMOVED FOR CLARITY



42E1432-

e113. M1084/M1086 MATERIAL HANDLING CRANE (MHC) SWING CCW DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin A of connector on remote control box.
- (4) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE

Step (5) requires the aid of an assistant.


- (5) Position SWING CW/CCW controller to CCW and note reading on multimeter.
- (6) If continuity is not present, go to step 4 of this fault.
- (7) If continuity is present, go to step 5 of this fault.



REMOTE CONTROL BOX CONNECTOR




42EL3031

e113. M1084/M1086 MATERIAL HANDLING CRANE (MHC) SWING CCW DOES NOT OPERATE FROM REMOTE STATION (CONT)



CONTINUITY TEST


- (1) Remove SWING CW/CCW controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin A of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 3 of SWING CW/CCW controller internal wiring harness and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (6) Connect negative (-) probe of multimeter on pin 1 of SWING CW/CCW controller internal wiring harness and note reading on multimeter.
- (7) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (8) If continuity is present, replace SWING CW/CCW controller (para 7-32).
- (9) Install SWING CW/CCW controller (para 7-32).
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



42EL3041

e113. M1084/M1086 MATERIAL HANDLING CRANE (MHC) SWING CCW DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Swing CCW solenoid cable OK. Swing CCW solenoid OK. Remote control box internal wiring harness OK. SWING CW/CCW controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter on pin A of one end of external remote control cable connector.
	(3) Connect negative (-) probe of multimeter on pin A of other end of external remote control cable and note reading on multimeter.
	(4) If continuity is not present, replace external remote control cable.



42E1435-

e113. M1084/M1086 MATERIAL HANDLING CRANE (MHC) SWING CCW DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Swing CCW solenoid cable OK. Swing CCW solenoid OK. Remote control box internal wiring harness OK. SWING CW/CCW controller OK. External remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control cable.





TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control cable is faulty.





CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin A of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 17 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-96).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).




WIRES REMOVED FOR CLARITY

POSITION 17





42EL 3061


e114. M1084/M1086 MATERIAL HANDLING CRANE (MHC) OVERLOAD SHUTDOWN SYSTEM DOES NOT ACTIVATE	
INITIAL SETUP	
Equipment Conditions Batteries disconnected (para 7-57).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
References TM 9-4910-571-12&P	



CONTINUITY TEST
<ol style="list-style-type: none"> (1) Loosen four screws on junction box. (2) Open cover on junction box. (3) Disconnect overload lockout cable connector from overload shutdown box. (4) Set multimeter to ohms. (5) Connect positive (+) probe of multimeter in socket A of overload lockout cable connector. (6) Connect negative (-) probe of multimeter to terminal board position 6 and note reading on multimeter. (7) If continuity is not present, replace overload lockout cable (para 7-95).



CONTINUITY TEST
<ol style="list-style-type: none"> (1) Set multimeter to ohms. (2) Connect positive (+) probe of multimeter in socket B of overload lockout cable connector. (3) Connect negative (-) probe of multimeter on terminal board position 28 and note reading on multimeter. (4) If continuity is not present, replace overload lockout cable (para 7-95). (5) If continuity is present, perform Electrical System Troubleshooting (e116. M1084/M1086 Hoist Up Lockout Does Not Activate, e117. M1084/M1086 Boom Down Lockout Does Not Activate, e118. M1084/M1086 Boom Up Lockout Does Not Activate, and e119. M1084/M1086 Telescope Out Lockout Does Not Activate). (6) Connect overload lockout cable connector to overload shutdown box. (7) Close cover on junction box. (8) Tighten four screws on junction box. (9) Connect batteries (para 7-57).



42EL4011

e115. M1084/M1086 MATERIAL HANDLING CRANE (MHC) OVERLOAD SHUTDOWN SYSTEM STAYS ACTIVATED

INITIAL SETUP

Equipment Conditions

Batteries disconnected (para 7-57).

References


TM 9-4910-571-12&P


Tools and Special Tools

Tool Kit, Genl Mech (Item 46, Appendix C)

Multimeter, Digital (Item 22, Appendix C)

STE/ICE-R (Item 41, Appendix C)







- (1) Loosen four screws on junction box.
- (2) Open cover on junction box.
- (3) Visually inspect the wiring around terminal board position 28 for shorted wires that could put 24 vdc on position 28.




CONTINUITY TEST
(1) Set multimeter to ohms.
(2) Connect positive (+) probe of multimeter to terminal board position 28.
(3) Connect negative (-) probe of multimeter to terminal board position 6 and note reading on multimeter.
(4) If continuity is not present, replace overload lockout cable (para 7-27).
(5) If continuity is present, notify DS Maintenance.
(6) Close cover on junction box.
(7) Tighten four screws on junction box.
(8) Connect batteries (para 7-57).




E90---1-

e116. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST UP LOCKOUT DOES NOT ACTIVATE	
INITIAL SETUP	
Equipment Conditions Batteries disconnected (para 7-57).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
References TM 9-4910-571-12&P	




CONTINUITY TEST

- (1) Loosen four screws on junction box.
- (2) Open cover on junction box.
- (3) Disconnect hoist up lockout solenoid cable connector from hoist up lockout solenoid.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter in socket 1 of hoist up lockout solenoid cable connector.
- (6) Connect negative (-) probe of multimeter to terminal board position 28 and note reading on multimeter.
- (7) If continuity is not present, replace hoist up lockout solenoid cable (para 7-92).



POSITION 28




JUNCTION BOX


CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter in socket 2 of hoist up lockout solenoid cable connector.
- (3) Connect negative (-) probe of multimeter on ground in junction box and note reading on multimeter.
- (4) If continuity is not present, replace hoist up lockout solenoid cable (para 7-92).
- (5) Connect hoist up lockout solenoid cable connector to hoist up lockout solenoid valve.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.

HOIST UP LOCKOUT SOLENOID CABLE CONNECTOR




HOIST UP LOCKOUT SOLENOID CABLE CONNECTOR




HOIST UP LOCKOUT SOLENOID

42EL6011

e116. M1084/M1086 MATERIAL HANDLING CRANE (MHC) HOIST UP LOCKOUT DOES NOT ACTIVATE (CONT)




- | CONTINUITY TEST | |
|-----------------|--|
| | (1) Set multimeter to ohms. |
| | (2) Connect positive (+) probe of multimeter on contact two of hoist up lockout solenoid valve. |
| | (3) Connect negative (-) probe of multimeter to contact one of hoist up lockout solenoid valve and note reading on multimeter. |
| | (4) If continuity is not present, notify DS Maintenance. |
| | (5) If continuity is present, notify DS Maintenance. |
| | (6) Connect hoist up lockout solenoid cable to boom up lockout solenoid valve. |
| | (7) Connect batteries (para 7-57). |




2E12202-

e117. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM DOWN LOCKOUT DOES NOT ACTIVATE	
INITIAL SETUP	
Equipment Conditions Batteries disconnected (para 7-57).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
References TM 9-4910-571-12&P	





CONTINUITY TEST

- (1) Loosen four screws on junction box.
- (2) Open cover on junction box.
- (3) Disconnect boom down lockout solenoid cable connector from boom down lockout solenoid valve.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter in socket 1 of boom down lockout solenoid cable.
- (6) Connect negative (-) probe of multimeter to terminal board position 28 and note reading on multimeter.
- (7) If continuity is not present, replace boom down lockout solenoid cable (para 7-85).




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter in socket 2 of boom down lockout solenoid cable connector.
- (3) Connect negative (-) probe of multimeter on ground in junction box and note reading on multimeter.
- (4) If continuity is not present, replace boom down lockout solenoid cable (para 7-85).
- (5) Connect boom down lockout solenoid cable connector to boom down lockout solenoid valve.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.




BOOM DOWN LOCKOUT CONNECTOR



BOOM DOWN LOCKOUT SOLENOID


e117. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM DOWN LOCKOUT DOES NOT ACTIVATE (CONT)




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on contact two of boom down lockout solenoid valve.
- (3) Connect negative (-) probe of multimeter to contact one of boom down lockout solenoid valve and note reading on multimeter.
- (4) If continuity is not present, notify DS Maintenance.
- (5) If continuity is present, notify DS Maintenance.
- (6) Connect boom down lockout solenoid cable to boom down lockout solenoid valve.
- (7) Connect batteries (para 7-57).

**BOOM DOWN LOCKOUT
CABLE CONNECTOR**




**BOOM DOWN LOCKOUT
CABLE CONNECTOR**




**BOOM DOWN LOCKOUT
SOLENOID VALVE CONTACTS**

2E12302-


e118. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM UP LOCKOUT DOES NOT ACTIVATE	
INITIAL SETUP	
Equipment Conditions Batteries disconnected (para 7-57).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
References TM 9-4910-571-12&P	



- CONTINUITY TEST**
- (1) Loosen four screws on junction box.
 - (2) Open cover on junction box.
 - (3) Disconnect boom up lockout solenoid cable connector from boom up lockout solenoid valve.
 - (4) Set multimeter to ohms.
 - (5) Connect positive (+) probe of multimeter in socket 1 of boom up lockout solenoid cable.
 - (6) Connect negative (-) probe of multimeter to terminal board terminal 28 and note reading on multimeter.
 - (7) If continuity is not present, replace boom up lockout solenoid cable (para 7-87).




- CONTINUITY TEST**
- (1) Set multimeter to ohms.
 - (2) Connect positive (+) probe of multimeter in socket 2 of boom up lockout solenoid cable connector.
 - (3) Connect negative (-) probe of multimeter on ground in junction box and note reading on multimeter.
 - (4) If continuity is not present, replace boom up lockout solenoid cable (para 7-87).
 - (5) Connect boom up lockout solenoid cable connector to boom up lockout solenoid valve.
 - (6) Close cover on junction box.
 - (7) Tighten four screws on junction box cover.




42EL8011

e118. M1084/M1086 MATERIAL HANDLING CRANE (MHC) BOOM UP LOCKOUT DOES NOT ACTIVATE (CONT)




- | CONTINUITY TEST | |
|-----------------|---|
| | (1) Set multimeter to ohms. |
| | (2) Connect positive (+) probe of multimeter on contact two of boom up lockout solenoid valve. |
| | (3) Connect negative (-) probe of multimeter to contact one of boom up lockout solenoid valve and note reading on multimeter. |
| | (4) If continuity is not present, notify DS Maintenance. |
| | (5) If continuity is present, notify DS Maintenance. |
| | (6) Connect boom up lockout solenoid cable to boom up lockout solenoid valve. |
| | (7) Connect batteries (para 7-57). |

BOOM UP LOCKOUT SOLENOID VALVE CONTACTS




BOOM UP LOCKOUT CABLE CONNECTOR




BOOM UP LOCKOUT SOLENOID VALVE

2E12402-


e119. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT LOCKOUT DOES NOT ACTIVATE	
INITIAL SETUP	
Equipment Conditions Batteries disconnected (para 7-57).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
References TM 9-4910-571-12&P	




- CONTINUITY TEST**
- (1) Loosen four screws on junction box.
 - (2) Open cover on junction box.
 - (3) Disconnect telescope out lockout solenoid cable connector from telescope out lockout solenoid valve.
 - (4) Set multimeter to ohms.
 - (5) Connect positive (+) probe of multimeter in socket 1 of telescope out lockout solenoid cable.
 - (6) Connect negative (-) probe of multimeter to terminal board terminal 28 and note reading on multimeter.
 - (7) If continuity is not present, replace telescope out lockout solenoid cable (para 7-102).



POSITION 28




- CONTINUITY TEST**
- (1) Set multimeter to ohms.
 - (2) Connect positive (+) probe of multimeter in socket 2 of telescope out lockout solenoid cable connector.
 - (3) Connect negative (-) probe of multimeter on ground in junction box and note reading on multimeter.
 - (4) If continuity is not present, replace telescope out lockout solenoid cable (para 7-102).
 - (5) Connect telescope out lockout solenoid cable connector to telescope out lockout solenoid valve.
 - (6) Close cover on junction box.
 - (7) Tighten four screws on junction box cover.




42e19011


e119. M1084/M1086 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT LOCKOUT DOES NOT ACTIVATE (CONT)



- | CONTINUITY TEST |
|---|
| (1) Set multimeter to ohms. |
| (2) Connect positive (+) probe of multimeter on contact two of telescope out lockout solenoid valve. |
| (3) Connect negative (-) probe of multimeter to contact one of telescope out lockout solenoid valve and note reading on multimeter. |
| (4) If continuity is not present, notify DS Maintenance. |
| (5) If continuity is present, notify DS Maintenance. |
| (6) Connect telescope out lockout solenoid cable to telescope out lockout solenoid valve. |
| (7) Connect batteries (para 7-57). |



e120. M1089 MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-491-571-12&P






WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Loosen four screws on junction box cover.
- (2) Open cover on junction box.
- (3) Set multimeter to vdc.
- (4) Connect positive (+) probe of multimeter to terminal board position 2.
- (5) Connect negative (-) probe of multimeter to GROUND quick-connect terminal block (above main power switch) and note reading on multimeter.
- (6) If 24 vdc is not present, replace crane power cable (para 7-79).



X2E1051A

120. M1089 MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Set multimeter to vdc.
- (2) Connect positive (+) probe of multimeter to D6 of junction box.
- (3) Connect negative (-) probe of multimeter to GROUND quick-connect terminal block (above main power switch) and note reading on multimeter.
- (4) If 24 vdc is not present, repair junction box assembly (para 7-28).




VOLTAGE TEST

- (1) Set multimeter to vdc.
- (2) Connect positive (+) probe of multimeter to D7 of junction box.
- (3) Connect negative (-) probe of multimeter to GROUND quick-connect terminal block (above main power switch) and note reading on multimeter.
- (4) If 24 vdc is not present, repair junction box assembly (para 7-28).



X2E1051B

¶120. M1089 MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE (CONT)





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Set multimeter to vdc.
- (2) Connect positive (+) probe of multimeter to center position, between D6 and D7 of junction box.
- (3) Connect negative (-) probe of multimeter to GROUND quick-connect terminal block (above main power switch) and note reading on multimeter.
- (4) If 24 vdc is not present, repair junction box assembly (para 7-28).




X2E1051C

VOLTAGE TEST

- (1) Set multimeter to vdc.
- (2) Connect positive (+) probe of multimeter to MAIN POWER switch line position (white wire).
- (3) Connect negative (-) probe of multimeter to GROUND quick-connect terminal block (above main power switch) and note reading on multimeter.
- (4) If 24 vdc is not present, repair junction box assembly (para 7-28).

e120. M1089 MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.



VOLTAGE TEST

- (1) Set multimeter to vdc.
- (2) Connect positive (+) probe of multimeter to MAIN POWER switch load position (black wire).
- (3) Connect negative (-) probe of multimeter to GROUND quick-connect terminal block (above main power switch).
- (4) Position MAIN POWER switch to ON and note reading on multimeter.
- (5) If 24 vdc is not present, repair junction box assembly (para 7-28).




VOLTAGE TEST

- (1) Set multimeter to vdc.
- (2) Connect positive (+) probe of multimeter to junction box terminal board TB1 position 1.
- (3) Connect negative (-) probe of multimeter to GROUND quick-connect terminal block (above main power switch) and note reading on multimeter.
- (4) If 24 vdc is not present, repair junction box assembly (para 7-28).
- (5) Position MAIN POWER switch to OFF.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.



X2E1051-

e121. M1089 MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE FROM REMOTE CONTROL	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P




WARNING


Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Remove cover from left or right remote control cable bulkhead connector.
- (2) Set multimeter to volts dc.
- (3) Connect positive (+) probe of multimeter to pin E of remote control bulkhead connector.
- (4) Connect negative (-) probe of multimeter to pin B of remote control bulkhead connector.
- (5) Position MAIN POWER switch to ON (TM 9-2320-366-10-1) and note reading on multimeter.
- (6) If 24 vdc is not present, relace left or right remote control cable (para 7-115 or 7-118).



¶121. M1089 MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE FROM REMOTE CONTROL (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


CONTINUITY TEST

- (1) Connect external remote control cable to left or right remote control cable bulkhead connector.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin E of remote control cable connector.
- (4) Connect negative (-) probe of multimeter on pin B of remote control cable connector and note reading on multimeter.
- (5) If 24 vdc is not present, replace external remote control cable.
- (6) Disconnect external remote control cable from left or right remote control cable bulkhead connector.
- (7) Install cover on left or right remote control cable bulkhead connector.





42E1062-

6121. M1089 MATERIAL HANDLING CRANE (MHC) DOES NOT OPERATE FROM REMOTE CONTROL (CONT)



CONTINUITY TEST


- (1) Remove cover from crane remote control box connector.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin J of crane remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin H of crane remote control box connector and note reading on multimeter.
- (5) If continuity is not present, replace ON/OFF switch (para 7-32).
- (6) If continuity is present, repair crane remote control box internal wiring harness (para 7-32).
- (7) Install cover on crane remote control box connector.



REMOTE CONTROL BOX CONNECTOR

X2E1063-

e122. M1089 MATERIAL HANDLING CRANE (MHC) HOIST UP DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.




OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to and remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 15.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).

NOTE


Step (9) requires the aid of an assistant.

- (9) Position HOIST UP/DOWN controller to UP and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.
- (11) Position MAIN POWER switch to OFF.



X2E1071-



e122. M1089 MATERIAL HANDLING CRANE (MHC) HOIST UP DOES NOT OPERATE FROM REMOTE STATION (CONT)



CONTINUITY TEST


- (1) Disconnect hoist up solenoid connector from hoist up solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of hoist up solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of hoist up solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 15 and note reading on multimeter.
- (7) If continuity is not present, replace hoist up solenoid cable (para 7-113).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect hoist up solenoid cable connector to hoist up solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).

HOIST UP
SOLENOID CABLE
CONNECTOR




HOIST UP
SOLENOID

HOIST UP
SOLENOID CABLE
CONNECTOR




WIRES REMOVED
FOR CLARITY

POSITION 15



COVER




SCREW

JUNCTION
BOX

42em2021

e122. M1089 MATERIAL HANDLING CRANE (MHC) HOIST UP DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Position remote control box switch to ON.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter on pin F of connector on remote control box.
- (5) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE

Step (6) requires the aid of an assistant.

- (6) Position HOIST UP/DOWN controller to UP and note reading on multimeter.
- (7) If continuity is not present, go to step 4 of this fault.
- (8) If continuity is present, go to step 5 of this fault.
- (9) Position remote control box switch to OFF.



REMOTE CONTROL BOX CONNECTOR


42EM2031

e122. M1089 MATERIAL HANDLING CRANE (MHC) HOIST UP DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK.
Hoist up solenoid cable OK.
Hoist up solenoid OK.
External remote control cable OK.
Remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control box internal wiring harness.
Faulty hoist up/down controller.


4.
Is continuity present from remote control box connector pin F to HOIST UP/DOWN controller internal wiring harness pin 3 and from remote control box connector pin H to HOIST UP/DOWN controller internal wiring harness pin 1?

TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control box internal wiring harness is faulty.
If continuity is present, HOIST UP/DOWN controller is faulty.



CONTINUITY TEST


- (1) Remove HOIST UP/DOWN controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin F of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 3 of HOIST UP/DOWN controller internal wiring harness and note reading on multimeter.
- (5) Position remote control box switch to ON.
- (6) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (7) Connect negative (-) probe of multimeter on pin 1 of HOIST UP/DOWN controller internal wiring harness and note reading on multimeter.
- (8) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (9) If continuity is present, replace HOIST UP/DOWN controller (para 7-32).
- (10) Position remote control box switch to OFF.
- (11) Install HOIST UP/DOWN controller (para 7-32).
- (12) Close cover on junction box.
- (13) Tighten four screws on junction box cover.
- (14) Stow crane (TM 9-2320-366-10-1).



42EM2041

e122. M1089 MATERIAL HANDLING CRANE (MHC) HOIST UP DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Hoist up solenoid cable OK. Hoist up solenoid OK. Remote control box internal wiring harness OK. HOIST UP/DOWN controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
1	Set multimeter to ohms.
2	Connect positive (+) probe of multimeter on pin F of one end of external remote control cable connector.
4	Connect negative (-) probe of multimeter on pin F of other end of external remote control cable and note reading on multimeter.
5	If continuity is not present, replace external remote control cable.



X2E1075-

e122. M1089 MATERIAL HANDLING CRANE (MHC) HOIST UP DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Hoist up solenoid cable OK. Hoist up solenoid OK. Remote control box internal wiring harness OK. HOIST UP/DOWN controller OK. External remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control cable.






TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control cable is faulty.




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin F of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 15 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-115 or 7-118).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).



42EM2061

e123. M1089 MATERIAL HANDLING CRANE (MHC) HOIST DOWN DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.




OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to and remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 16.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).

NOTE


Step (9) requires the aid of an assistant.

- (9) Position HOIST UP/DOWN controller to DOWN and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.
- (11) Position MAIN POWER switch to OFF.





42en3011

e123. M1089 MATERIAL HANDLING CRANE (MHC) HOIST DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)



CONTINUITY TEST


- (1) Disconnect hoist down solenoid connector from hoist down solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of hoist down solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of hoist down solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 24 and note reading on multimeter.
- (7) If continuity is not present, replace hoist down solenoid cable (para 7-111).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect hoist down solenoid cable connector to hoist down solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



X2E1084-

e123. M1089 MATERIAL HANDLING CRANE (MHC) HOIST DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Hoist down solenoid cable OK. Hoist down solenoid OK.
POSSIBLE PROBLEMS
Faulty hoist up/down controller. Faulty remote control box internal wiring harness. Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
This question eliminates possible problems and determines where to continue troubleshooting.





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Position remote control box switch to ON.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter on pin G of connector on remote control box.
- (5) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE

Step (6) requires the aid of an assistant.

- (6) Position HOIST UP/DOWN controller to DOWN and note reading on multimeter.
- (7) If continuity is not present, go to step 4 of this fault.
- (8) If continuity is present, go to step 5 of this fault.
- (9) Position remote control box switch to OFF.




REMOTE CONTROL BOX CONNECTOR

42EM3031

e123. M1089 MATERIAL HANDLING CRANE (MHC) HOIST DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Hoist down solenoid cable OK. Hoist down solenoid OK. External remote control cable OK. Remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control box internal wiring harness. Faulty hoist up/down controller.




TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control box internal wiring harness is faulty. If continuity is present, HOIST UP/DOWN controller is faulty.



CONTINUITY TEST


- (1) Remove HOIST UP/DOWN controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin G of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 4 of HOIST UP/DOWN controller internal wiring harness and note reading on multimeter.
- (5) Position remote control box switch to ON.
- (6) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (7) Connect negative (-) probe of multimeter on pin 1 of HOIST UP/DOWN controller internal wiring harness and note reading on multimeter.
- (8) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (9) If continuity is present, replace HOIST UP/DOWN controller (para 7-32).
- (10) Position remote control box switch to OFF.
- (11) Install HOIST UP/DOWN controller (para 7-32).
- (12) Close cover on junction box.
- (13) Tighten four screws on junction box cover.
- (14) Stow crane (TM 9-2320-366-10-1).



42EM3041

e123. M1089 MATERIAL HANDLING CRANE (MHC) HOIST DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Hoist down solenoid cable OK. Hoist down solenoid OK. Remote control box internal wiring harness OK. HOIST UP/DOWN controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter on pin G of one end of external remote control cable connector.
	(3) Connect negative (-) probe of multimeter on pin G of other end of external remote control cable and note reading on multimeter.
	(4) If continuity is not present, replace external remote control cable.



X2E1083-

e123. M1089 MATERIAL HANDLING CRANE (MHC) HOIST DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Hoist down solenoid cable OK. Hoist down solenoid OK. Remote control box internal wiring harness OK. HOIST UP/DOWN controller OK. External remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control cable.






TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control cable is faulty.




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin G of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 16 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-115 or 7-118).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).



42EM3061

e124. M1089 MATERIAL HANDLING CRANE (MHC) BOOM UP DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.




OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 13.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).

NOTE


Step (9) requires the aid of an assistant.

- (9) Position BOOM UP/DOWN controller to UP and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.
- (11) Position MAIN POWER switch to OFF.






X2E1091-

e124. M1089 MATERIAL HANDLING CRANE (MHC) BOOM UP DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST

- (1) Disconnect boom up solenoid connector from boom up solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of boom up solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of boom up solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 13 and note reading on multimeter.
- (7) If continuity is not present, replace boom up solenoid cable (para 7-108).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect boom up solenoid cable connector to boom up solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



X2E1092-

e124. M1089 MATERIAL HANDLING CRANE (MHC) BOOM UP DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Position remote control box switch to ON.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter on pin N of connector on remote control box.
- (5) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE

Step (6) requires the aid of an assistant.


- (6) Position BOOM UP/DOWN controller to UP and note reading on multimeter.
- (7) If continuity is not present, go to step 4 of this fault.
- (8) If continuity is present, go to step 5 of this fault.
- (9) Position remote control box switch to OFF.




REMOTE CONTROL BOX CONNECTOR

42EM4031

e124. M1089 MATERIAL HANDLING CRANE (MHC) BOOM UP DOES NOT OPERATE FROM REMOTE STATION (CONT)




- | CONTINUITY TEST | |
|-----------------|--|
| (1) | Remove BOOM UP/DOWN controller (para 7-32). |
| (2) | Set multimeter to ohms. |
| (3) | Connect positive (+) probe of multimeter on pin N of remote control box connector. |
| (4) | Connect negative (-) probe of multimeter on pin 3 of BOOM UP/DOWN controller internal wiring harness and note reading on multimeter. |
| (5) | Position remote control box switch to ON. |
| (6) | Connect positive (+) probe of multimeter on pin H of remote control box connector. |
| (7) | Connect negative (-) probe of multimeter on pin 1 of BOOM UP/DOWN controller internal wiring harness and note reading on multimeter. |
| (8) | If continuity is not present, replace remote control box internal wiring harness (para 7-32). |
| (9) | If continuity is present, replace BOOM UP/DOWN controller (para 7-32). |
| (10) | Position remote control box switch to OFF. |
| (11) | Install BOOM UP/DOWN controller (para 7-32). |
| (12) | Close cover on junction box. |
| (13) | Tighten four screws on junction box cover. |
| (14) | Stow crane (TM 9-2320-366-10-1). |



42EM4041

e124. M1089 MATERIAL HANDLING CRANE (MHC) BOOM UP DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Boom up solenoid cable OK. Boom up solenoid OK. Remote control box internal wiring harness OK. BOOM UP/DOWN controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter on pin N of one end of external remote control cable connector.
	(3) Connect negative (-) probe of multimeter on pin N of other end of external remote control cable and note reading on multimeter.
	(4) If continuity is not present, replace external remote control cable.



X2E1095-

e124. M1089 MATERIAL HANDLING CRANE (MHC) BOOM UP DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Boom up solenoid cable OK. Boom up solenoid OK. Remote control box internal wiring harness OK. BOOM UP/DOWN controller OK. External remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control cable.




TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control cable is faulty.





CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin N of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 13 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-115 or 7-118).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).




POSITION 13



42em4061

e125. M1089 MATERIAL HANDLING CRANE (MHC) BOOM DOWN DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.


OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 14.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).

NOTE


Step (9) requires the aid of an assistant.

- (9) Position BOOM UP/DOWN controller to DOWN and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.
- (11) Position MAIN POWER switch to OFF.




X2E11001

e125. M1089 MATERIAL HANDLING CRANE (MHC) BOOM DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST

- (1) Disconnect boom down solenoid connector from boom down solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of boom down solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of boom down solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 14 and note reading on multimeter.
- (7) If continuity is not present, replace boom down solenoid cable (para 7-106).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect boom down solenoid cable connector to boom down solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).




BOOM DOWN SOLENOID CABLE CONNECTOR




BOOM DOWN SOLENOID
BOOM DOWN SOLENOID CABLE CONNECTOR

WIRES REMOVED FOR CLARITY




POSITION 14



42E11002

125. M1089 MATERIAL HANDLING CRANE (MHC) BOOM DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Position remote control box switch to ON.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter on pin M of connector on remote control box.
- (5) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE

Step (6) requires the aid of an assistant.


- (6) Position BOOM UP/DOWN controller to DOWN and note reading on multimeter.
- (7) If continuity is not present, go to step 4 of this fault.
- (8) If continuity is present, go to step 5 of this fault.
- (9) Position remote control box switch to OFF.



REMOTE CONTROL BOX CONNECTOR




42EM5031

ø125. M1089 MATERIAL HANDLING CRANE (MHC) BOOM DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)



CONTINUITY TEST


- (1) Remove BOOM UP/DOWN controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin M of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 4 of BOOM UP/DOWN controller internal wiring harness and note reading on multimeter.
- (5) Position remote control box switch to ON.
- (6) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (7) Connect negative (-) probe of multimeter on pin 1 of BOOM UP/DOWN controller internal wiring harness and note reading on multimeter.
- (8) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (9) If continuity is present, replace BOOM UP/DOWN controller (para 7-32).
- (10) Position remote control box switch to OFF.
- (11) Install BOOM UP/DOWN controller (para 7-32).
- (12) Close cover on junction box.
- (13) Tighten four screws on junction box cover.
- (14) Stow crane (TM 9-2320-366-10-1).



42EM5041

e125. M1089 MATERIAL HANDLING CRANE (MHC) BOOM DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Boom down solenoid cable OK. Boom down solenoid OK. Remote control box internal wiring harness OK. BOOM UP/DOWN controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter on pin M of one end of external remote control cable connector.
	(3) Connect negative (-) probe of multimeter on pin M of other end of external remote control cable and note reading on multimeter.
	(4) If continuity is not present, replace external remote control cable.



X2E11005

e125. M1089 MATERIAL HANDLING CRANE (MHC) BOOM DOWN DOES NOT OPERATE FROM REMOTE STATION (CONT)



KNOWN INFO
Other crane functions from remote station OK. Boom down solenoid cable OK. Boom down solenoid OK. Remote control box internal wiring harness OK. BOOM UP/DOWN controller OK. External remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control cable.




TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control cable is faulty.



- | CONTINUITY TEST | |
|-----------------|--|
| (1) | Set multimeter to ohms. |
| (2) | Connect positive (+) probe of multimeter on pin M of remote control cable connector. |
| (3) | Connect negative (-) probe of multimeter on terminal board lower position 14 and note reading on multimeter. |
| (4) | If continuity is not present, replace remote control cable (para 7-115 or 7-118). |
| (5) | If continuity is present, notify DS Maintenance. |
| (6) | Close cover on junction box. |
| (7) | Tighten four screws on junction box cover. |
| (8) | Stow crane (TM 9-2320-366-10-1). |



e126. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE IN DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.


OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 12.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).


NOTE

Step (9) requires the aid of an assistant.


- (9) Position TELESCOPE IN/OUT controller to IN and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.



MAIN POWER SWITCH




JUNCTION BOX



GROUND QUICK-CONNECT TERMINAL BOARD

POSITION 12

WIRES REMOVED FOR CLARITY




TELESCOPE IN/OUT CONTROLLER

REMOTE CONTROL BOX ON/OFF SWITCH


42em601-

ø126. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE IN DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST

- (1) Disconnect telescope in solenoid connector from telescope in solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of telescope in solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of telescope in solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 12 and note reading on multimeter.
- (7) If continuity is not present, replace telescope in solenoid cable (para 7-121).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect telescope in solenoid cable connector to telescope in solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).




TELESCOPE
IN SOLENOID
CABLE
CONNECTOR




TELESCOPE IN
SOLENOID

TELESCOPE IN
SOLENOID CABLE
CONNECTOR




WIRES REMOVED
FOR CLARITY

POSITION 12



42EM6021

ø126. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE IN DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Position remote control box switch to ON.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter on pin D of connector on remote control box.
- (5) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE


Step (6) requires the aid of an assistant.

- (6) Position TELESCOPE IN/OUT controller to IN and note reading on multimeter.
- (7) If continuity is not present, go to step 4 of this fault.
- (8) If continuity is present, go to step 5 of this fault.
- (9) Position remote control box switch to OFF.





42EM6031

ø126. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE IN DOES NOT OPERATE FROM REMOTE STATION (CONT)



CONTINUITY TEST


- (1) Remove TELESCOPE IN/OUT controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin D of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 3 of TELESCOPE IN/OUT controller internal wiring harness and note reading on multimeter.
- (5) Position remote control box switch to ON.
- (6) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (7) Connect negative (-) probe of multimeter on pin 1 of TELESCOPE IN/OUT controller internal wiring harness and note reading on multimeter.
- (8) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (9) If continuity is present, replace TELESCOPE IN/OUT controller (para 7-32).
- (10) Position remote control box switch to OFF.
- (11) Install TELESCOPE IN/OUT controller (para 7-32).
- (12) Close cover on junction box.
- (13) Tighten four screws on junction box cover.
- (14) Stow crane (TM 9-2320-366-10-1).



42EM6041

ø126. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE IN DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Telescope in solenoid cable OK. Telescope in solenoid OK. Remote control box internal wiring harness OK. TELESCOPE IN/OUT controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter on pin D of one end of external remote control cable connector.
	(3) Connect negative (-) probe of multimeter on pin D of other end of external remote control cable and note reading on multimeter.
	(4) If continuity is not present, replace external remote control cable.



X2E1115-

ø126. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE IN DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Telescope in solenoid cable OK. Telescope in solenoid OK. Remote control box internal wiring harness OK. TELESCOPE IN/OUT controller OK. External remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control cable.





TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control cable is faulty.



CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin D of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 12 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-115 or 7-118).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).



LEFT SIDE SHOWN
RIGHT SIDE SIMILAR

42EM6061

e127. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.


OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 11.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).

NOTE


Step (9) requires the aid of an assistant.

- (9) Position TELESCOPE IN/OUT controller to OUT and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.




X2E1121-

ø127. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT DOES NOT OPERATE FROM REMOTE STATION (CONT)




CONTINUITY TEST

- (1) Disconnect telescope out solenoid connector from telescope out solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of telescope out solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of telescope out solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 11 and note reading on multimeter.
- (7) If continuity is not present, replace telescope out solenoid cable (para 7-123).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect telescope out solenoid cable connector to telescope out solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



TELESCOPE OUT SOLENOID CABLE CONNECTOR




TELESCOPE OUT SOLENOID

TELESCOPE OUT SOLENOID CABLE CONNECTOR

WIRES REMOVED FOR CLARITY


GROUND TERMINAL BOARD



POSITION 11

MAIN POWER SWITCH


COVER



SCREW

JUNCTION BOX

ø127. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT DOES NOT OPERATE FROM REMOTE STATION (CONT)





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Position remote control box switch to ON.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter on pin C of connector on remote control box.
- (5) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE

Step (6) requires the aid of an assistant.

- (6) Position TELESCOPE IN/OUT controller to OUT and note reading on multimeter.
- (7) If continuity is not present, go to step 4 of this fault.
- (8) If continuity is present, go to step 5 of this fault.
- (9) Position remote control box switch to OFF.



REMOTE CONTROL BOX CONNECTOR


42EM7031

ø127. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Telescope out solenoid cable OK. Telescope out solenoid OK. External remote control cable OK. Remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control box internal wiring harness. Faulty telescope in/out controller.


4.
Is continuity present from remote control box connector pin C to TELESCOPE IN/OUT controller internal wiring harness pin 4 and from remote control box connector pin H to TELESCOPE IN/OUT controller internal wiring harness pin 1?

TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control box internal wiring harness is faulty. If continuity is present, TELESCOPE IN/OUT controller is faulty.



CONTINUITY TEST


- (1) Remove TELESCOPE IN/OUT controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin C of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 4 of TELESCOPE IN/OUT controller internal wiring harness and note reading on multimeter.
- (5) Position remote control box switch to ON.
- (6) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (7) Connect negative (-) probe of multimeter on pin 1 of TELESCOPE IN/OUT controller internal wiring harness and note reading on multimeter.
- (8) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (9) If continuity is present, replace TELESCOPE IN/OUT controller (para 7-32).
- (10) Position remote control box switch to OFF.
- (11) Install TELESCOPE IN/OUT controller (para 7-32).
- (12) Close cover on junction box.
- (13) Tighten four screws on junction box cover.
- (14) Stow crane (TM 9-2320-366-10-1).



42EM7041

ø127. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Telescope out solenoid cable OK. Telescope out solenoid OK. Remote control box internal wiring harness OK. TELESCOPE IN/OUT controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter on pin C of one end of external remote control cable connector.
	(3) Connect negative (-) probe of multimeter on pin C of other end of external remote control cable and note reading on multimeter.
	(4) If continuity is not present, replace external remote control cable.



X2E1125-

ø127. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Telescope out solenoid cable OK. Telescope out solenoid OK. Remote control box internal wiring harness OK. TELESCOPE IN/OUT controller OK. External remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control cable.





TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control cable is faulty.




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin C of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 11 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-115 or 7-118).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).



42E1126-

e128. M1089 MATERIAL HANDLING CRANE (MHC) SWING CW DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.


OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 10.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).

NOTE


Step (9) requires the aid of an assistant.

- (9) Position SWING CW/CCW controller to CW and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.






X2E1131-

ø128. M1089 MATERIAL HANDLING CRANE (MHC) SWING CW DOES NOT OPERATE FROM REMOTE STATION (CONT)



CONTINUITY TEST


- (1) Disconnect swing CW solenoid connector from swing CW solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of swing CW solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of swing CW solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 10 and note reading on multimeter.
- (7) If continuity is not present, replace swing CW solenoid cable (para 7-120).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect swing CW solenoid cable connector to swing CW solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



X2E1132-

ø128. M1089 MATERIAL HANDLING CRANE (MHC) SWING CW DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Swing CW solenoid cable OK. Swing CW solenoid OK.
POSSIBLE PROBLEMS
Faulty SWING CW/CCW controller. Faulty remote control box internal wiring harness. Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
This question eliminates possible problems and determines where to continue troubleshooting.




ø128. M1089 MATERIAL HANDLING CRANE (MHC) SWING CW DOES NOT OPERATE FROM REMOTE STATION (CONT)



CONTINUITY TEST


- (1) Remove SWING CW/CCW controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin L of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 4 of SWING CW/CCW controller internal wiring harness and note reading on multimeter.
- (5) Position remote control box switch to ON.
- (6) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (7) Connect negative (-) probe of multimeter on pin 1 of SWING CW/CCW controller internal wiring harness and note reading on multimeter.
- (8) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (9) If continuity is present, replace SWING CW/CCW controller (para 7-32).
- (10) Position remote control box switch to OFF.
- (11) Install SWING CW/CCW controller (para 7-32).
- (12) Close cover on junction box.
- (13) Tighten four screws on junction box cover.
- (14) Stow crane (TM 9-2320-366-10-1).



42EM8041

ø128. M1089 MATERIAL HANDLING CRANE (MHC) SWING CW DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Swing CW solenoid cable OK. Swing CW solenoid OK. Remote control box internal wiring harness OK. SWING CW/CCW controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter on pin L of one end of external remote control cable connector.
	(3) Connect negative (-) probe of multimeter on pin L of other end of external remote control cable and note reading on multimeter.
	(4) If continuity is not present, replace external remote control cable.



X2E1075-

ø128. M1089 MATERIAL HANDLING CRANE (MHC) SWING CW DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Swing CW solenoid cable OK. Swing CW solenoid OK. Remote control box internal wiring harness OK. SWING CW/CCW controller OK. External remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control cable.




TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control cable is faulty.





CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin L of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 10 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-115 or 7-118).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).

WIRES REMOVED FOR CLARITY




COVER JUNCTION BOX




REMOTE CONTROL CABLE CONNECTOR

LEFT SIDE SHOWN
RIGHT SIDE SIMILAR



42E1136-

e129. M1089 MATERIAL HANDLING CRANE (MHC) SWING CCW DOES NOT OPERATE FROM REMOTE STATION	
INITIAL SETUP	
Equipment Conditions Outriggers lowered (TM 9-2320-366-10-1). Crane erected with approximately five feet of cable payed out (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short circuit across electrical circuits and cause severe burns or electrical shock.


OUTPUT VOLTAGE TEST

- (1) Connect external remote control cable to remote control box (TM 9-2320-366-10-1).
- (2) Loosen four screws on junction box.
- (3) Open cover on junction box.
- (4) Position MAIN POWER switch to ON.
- (5) Lift guard and position remote control box ON/OFF switch to ON.
- (6) Set multimeter to volts dc.
- (7) Connect positive (+) probe of multimeter on terminal board lower position 9.
- (8) Connect negative (-) probe of multimeter on ground quick-connect terminal board (above MAIN POWER switch).

NOTE


Step (9) requires the aid of an assistant.

- (9) Position SWING CW/CCW controller to CCW and note reading on multimeter.
- (10) If 24 volts dc is not present, go to step 3 of this fault.
- (11) Position MAIN POWER switch to OFF.






X2E1141-

e129. M1089 MATERIAL HANDLING CRANE (MHC) SWING CCW DOES NOT OPERATE FROM REMOTE STATION (CONT)



CONTINUITY TEST


- (1) Disconnect swing CCW solenoid connector from swing CCW solenoid.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin 2 of swing CCW solenoid cable connector.
- (4) Connect negative (-) probe of multimeter on ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter on pin 1 of swing CCW solenoid cable connector.
- (6) Connect negative (-) probe of multimeter on terminal board lower position 9 and note reading on multimeter.
- (7) If continuity is not present, replace swing CCW solenoid cable (para 7-119).
- (8) If continuity is present, notify DS Maintenance.
- (9) Connect swing CCW solenoid cable connector to swing CCW solenoid.
- (10) Close cover on junction box.
- (11) Tighten four screws on junction box cover.
- (12) Stow crane (TM 9-2320-366-10-1).



X2E1142-

ø129. M1089 MATERIAL HANDLING CRANE (MHC) SWING CCW DOES NOT OPERATE FROM REMOTE STATION (CONT)

KNOWN INFO
Other crane functions from remote station OK. Swing CCW solenoid cable OK. Swing CCW solenoid OK.
POSSIBLE PROBLEMS
Faulty SWING CW/CCW controller. Faulty remote control box internal wiring harness. Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
This question eliminates possible problems and determines where to continue troubleshooting.





CONTINUITY TEST

- (1) Disconnect external remote control cable from remote control box.
- (2) Position remote control box switch to ON.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter on pin A of connector on remote control box.
- (5) Connect negative (-) probe of multimeter on pin H of connector on remote control box.

NOTE

Step (6) requires the aid of an assistant.


- (6) Position SWING CW/CCW controller to CCW and note reading on multimeter.
- (7) If continuity is not present, go to step 4 of this fault.
- (8) If continuity is present, go to step 5 of this fault.
- (9) Position remote control box switch to OFF.



REMOTE CONTROL BOX CONNECTOR


42em9031

e129. M1089 MATERIAL HANDLING CRANE (MHC) SWING CCW DOES NOT OPERATE FROM REMOTE STATION (CONT)



CONTINUITY TEST


- (1) Remove SWING CW/CCW controller (para 7-32).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter on pin A of remote control box connector.
- (4) Connect negative (-) probe of multimeter on pin 3 of SWING CW/CCW controller internal wiring harness and note reading on multimeter.
- (5) Position remote control box switch to ON.
- (6) Connect positive (+) probe of multimeter on pin H of remote control box connector.
- (7) Connect negative (-) probe of multimeter on pin 1 of SWING CW/CCW controller internal wiring harness and note reading on multimeter.
- (8) If continuity is not present, replace remote control box internal wiring harness (para 7-32).
- (9) If continuity is present, replace SWING CW/CCW controller (para 7-32).
- (10) Position remote control box switch to OFF.
- (11) Install SWING CW/CCW controller (para 7-32).
- (12) Close cover on junction box.
- (13) Tighten four screws on junction box cover.
- (14) Stow crane (TM 9-2320-366-10-1).



42EM9041

ø129. M1089 MATERIAL HANDLING CRANE (MHC) SWING CCW DOES NOT OPERATE FROM REMOTE STATION (CONT)


KNOWN INFO
Other crane functions from remote station OK. Swing CCW solenoid cable OK. Swing CCW solenoid OK. Remote control box internal wiring harness OK. SWING CW/CCW controller OK.
POSSIBLE PROBLEMS
Faulty external remote control cable. Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, external remote control cable is faulty.




CONTINUITY TEST	
	(1) Set multimeter to ohms.
	(2) Connect positive (+) probe of multimeter on pin A of one end of external remote control cable connector.
	(3) Connect negative (-) probe of multimeter on pin A of other end of external remote control cable and note reading on multimeter.
	(4) If continuity is not present, replace external remote control cable.



X2E1145-

e129. M1089 MATERIAL HANDLING CRANE (MHC) SWING CCW DOES NOT OPERATE FROM REMOTE STATION (CONT)



KNOWN INFO
Other crane functions from remote station OK. Swing CCW solenoid cable OK. Swing CCW solenoid OK. Remote control box internal wiring harness OK. SWING CW/CCW controller OK. External remote control cable OK.
POSSIBLE PROBLEMS
Faulty remote control cable.



TEST OPTIONS
Continuity Test or STE/ICE Test #91
REASON FOR QUESTION
If continuity is not present, remote control cable is faulty.


CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on pin A of remote control cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board lower position 9 and note reading on multimeter.
- (4) If continuity is not present, replace remote control cable (para 7-115 or 7-118).
- (5) If continuity is present, notify DS Maintenance.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.
- (8) Stow crane (TM 9-2320-366-10-1).




42E1146-

e130. M1089 MATERIAL HANDLING CRANE (MHC) HOIST UP LOCKOUT DOES NOT ACTIVATE	
INITIAL SETUP	
Equipment Conditions Batteries disconnected (para 7-57).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
References TM 9-4910-571-12&P	




CONTINUITY TEST

- (1) Loosen four screws on junction box.
- (2) Open cover on junction box.
- (3) Disconnect hoist up lockout solenoid cable connector from hoist up lockout solenoid.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter in socket 1 of hoist up lockout solenoid cable.
- (6) Connect negative (-) probe of multimeter to terminal board position 19 and note reading on multimeter.
- (7) If continuity is not present, replace hoist up lockout solenoid cable (para 7-112).




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter in socket 2 of hoist up lockout solenoid cable connector.
- (3) Connect negative (-) probe of multimeter on ground in junction box and note reading on multimeter.
- (4) If continuity is not present, replace hoist up lockout solenoid cable (para 7-112).
- (5) Connect hoist up lockout solenoid cable connector to hoist up lockout solenoid valve.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.




42EN0011

e130. M1089 MATERIAL HANDLING CRANE (MHC) HOIST UP LOCKOUT DOES NOT ACTIVATE (CONT)




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on contact two of hoist up lockout solenoid valve.
- (3) Connect negative (-) probe of multimeter to contact one of hoist up lockout solenoid valve and note reading on multimeter.
- (4) If continuity is not present, notify DS Maintenance.
- (5) If continuity is present, notify DS Maintenance.
- (6) Connect hoist up lockout solenoid cable to boom up lockout solenoid valve.
- (7) Connect batteries (para 7-57).



HOIST UP LOCKOUT SOLENOID VALVE


HOIST UP LOCKOUT SOLENOID VALVE CONTACTS







HOIST UP LOCKOUT SOLENOID SOLENOID CONNECTOR

X2E1152-

e131. M1089 MATERIAL HANDLING CRANE (MHC) BOOM DOWN LOCKOUT DOES NOT ACTIVATE	
INITIAL SETUP	
Equipment Conditions Batteries disconnected (para 7-57).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
References TM 9-4910-571-12&P	



- CONTINUITY TEST**
- (1) Loosen four screws on junction box.
 - (2) Open cover on junction box.
 - (3) Disconnect boom down lockout solenoid cable connector from boom down lockout solenoid valve.
 - (4) Set multimeter to ohms.
 - (5) Connect positive (+) probe of multimeter in socket 1 of boom down lockout solenoid cable.
 - (6) Connect negative (-) probe of multimeter to terminal board position 19 and note reading on multimeter.
 - (7) If continuity is not present, replace boom down lockout solenoid cable (para 7-105).




BOOM DOWN LOCKOUT SOLENOID CABLE CONNECTOR

- CONTINUITY TEST**
- (1) Set multimeter to ohms.
 - (2) Connect positive (+) probe of multimeter in socket 2 of boom down lockout solenoid cable connector.
 - (3) Connect negative (-) probe of multimeter on ground in junction box and note reading on multimeter.
 - (4) If continuity is not present, replace boom down lockout solenoid cable (para 7-105).
 - (5) Connect boom down lockout solenoid cable connector to boom down lockout solenoid valve.
 - (6) Close cover on junction box.
 - (7) Tighten four screws on junction box cover.

42EN1011


¶131. M1089 MATERIAL HANDLING CRANE (MHC) BOOM DOWN LOCKOUT DOES NOT ACTIVATE (CONT)




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on contact two of boom down lockout solenoid valve.
- (3) Connect negative (-) probe of multimeter to contact one of boom down lockout solenoid valve and note reading on multimeter.
- (4) If continuity is not present, notify DS Maintenance.
- (5) If continuity is present, notify DS Maintenance.
- (6) Connect boom down lockout solenoid cable to boom down lockout solenoid valve.
- (7) Connect batteries (para 7-57).

**BOOM DOWN LOCKOUT
CABLE CONNECTOR**




**BOOM DOWN LOCKOUT SOLENOID
VALVE CONTACTS**




**BOOM DOWN LOCKOUT
SOLENOID VALVE**


X2E1162-

e132. M1089 MATERIAL HANDLING CRANE (MHC) BOOM UP LOCKOUT DOES NOT ACTIVATE	
INITIAL SETUP	
Equipment Conditions Batteries disconnected (para 7-57).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
References TM 9-4910-571-12&P	







- CONTINUITY TEST**
- (1) Loosen four screws on junction box.
 - (2) Open cover on junction box.
 - (3) Disconnect boom up lockout solenoid cable connector from boom up lockout solenoid valve.
 - (4) Set multimeter to ohms.
 - (5) Connect positive (+) probe of multimeter in socket 1 of boom up lockout solenoid cable.
 - (6) Connect negative (-) probe of multimeter to terminal board position 19 and note reading on multimeter.
 - (7) If continuity is not present, replace boom up lockout solenoid cable (para 7-107).



BOOM UP LOCKOUT SOLENOID VALVE




BOOM UP LOCKOUT SOLENOID CABLE CONNECTOR



BOOM UP LOCKOUT SOLENOID CABLE CONNECTOR


- CONTINUITY TEST**
- (1) Set multimeter to ohms.
 - (2) Connect positive (+) probe of multimeter in socket 2 of boom up lockout solenoid cable connector.
 - (3) Connect negative (-) probe of multimeter on ground in junction box and note reading on multimeter.
 - (4) If continuity is not present, replace boom up lockout solenoid cable (para 7-107).
 - (5) Connect boom up lockout solenoid cable connector to boom up lockout solenoid valve.
 - (6) Close cover on junction box.
 - (7) Tighten four screws on junction box cover.

e132. M1089 MATERIAL HANDLING CRANE (MHC) BOOM UP LOCKOUT DOES NOT ACTIVATE (CONT)




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on contact two of boom up lockout solenoid valve.
- (3) Connect negative (-) probe of multimeter to contact one of boom up lockout solenoid valve and note reading on multimeter.
- (4) If continuity is not present, notify DS Maintenance.
- (5) If continuity is present, notify DS Maintenance.
- (6) Connect boom up lockout solenoid cable to boom up lockout solenoid valve.
- (7) Connect batteries (para 7-57).



BOOM UP LOCKOUT SOLENOID VALVE


BOOM UP LOCKOUT SOLENOID VALVE CONTACTS



BOOM UP LOCKOUT CABLE CONNECTOR



x2E1172-

e133. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT LOCKOUT DOES NOT ACTIVATE	
INITIAL SETUP	
Equipment Conditions Batteries disconnected (para 7-57).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
References TM 9-4910-571-12&P	





CONTINUITY TEST

- (1) Loosen four screws on junction box.
- (2) Open cover on junction box.
- (3) Disconnect telescope out lockout solenoid cable connector from telescope out lockout solenoid valve.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter in socket 1 of telescope out lockout solenoid cable.
- (6) Connect negative (-) probe of multimeter to terminal board position 19 and note reading on multimeter.
- (7) If continuity is not present, replace telescope out lockout solenoid cable (para 7-122).



TELESCOPE OUT LOCKOUT SOLENOID VALVE POSITION 19




TELESCOPE OUT LOCKOUT SOLENOID CABLE CONNECTOR

CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter in socket 2 of telescope out lockout solenoid cable connector.
- (3) Connect negative (-) probe of multimeter on ground in junction box and note reading on multimeter.
- (4) If continuity is not present, replace telescope out lockout solenoid cable (para 7-122).
- (5) Connect telescope out lockout solenoid cable connector to telescope out lockout solenoid valve.
- (6) Close cover on junction box.
- (7) Tighten four screws on junction box cover.


42EN3011

ø133. M1089 MATERIAL HANDLING CRANE (MHC) TELESCOPE OUT LOCKOUT DOES NOT ACTIVATE (CONT)




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on contact two of telescope out lockout solenoid valve.
- (3) Connect negative (-) probe of multimeter to contact one of telescope out lockout solenoid valve and note reading on multimeter.
- (4) If continuity is not present, notify DS Maintenance.
- (5) If continuity is present, notify DS Maintenance.
- (6) Connect telescope out lockout solenoid cable to telescope out lockout solenoid valve.
- (7) Connect batteries (para 7-57).




TELESCOPE OUT LOCKOUT SOLENOID VALVE



TELESCOPE OUT LOCKOUT SOLENOID CABLE CONNECTOR

X2E1182-

e134. M1089 MATERIAL HANDLING CRANE (MHC) OVERLOAD SHUTDOWN SYSTEM DOES NOT ACTIVATE	
INITIAL SETUP	
Equipment Conditions Batteries disconnected (para 7-57). References TM 9-4910-471-12&P	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)




CONTINUITY TEST

- (1) Loosen four screws on junction box.
- (2) Open cover on junction box.
- (3) Disconnect overload lockout cable connector from overload shutdown box.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter in socket A of overload lockout cable connector.
- (6) Connect negative (-) probe of multimeter to terminal board position 1 and note reading on multimeter.
- (7) If continuity is not present, replace overload lockout cable (para 7-116).


CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter in socket B of overload lockout cable connector.
- (3) Connect negative (-) probe of multimeter on terminal board position 19 and note reading on multimeter.
- (4) If continuity is not present, replace overload lockout cable (para 7-116).
- (5) If continuity is present, perform Electrical System Troubleshooting (e130. M1089 Hoist Up Lockout Does Not Activate, e131. M1089 Boom Down Lockout Does Not Activate, e132. M1089 Boom Up Lockout Does Not Activate, and e133. M1089 Telescope Out Lockout Does Not Activate).
- (6) Connect overload lockout cable connector to overload shutdown box.
- (7) Close cover on junction box.
- (8) Tighten four screws on junction box.
- (9) Connect batteries (para 7-57).






X2E1191-

e135. M1089 MATERIAL HANDLING CRANE (MHC) OVERLOAD SHUTDOWN SYSTEM STAYS ACTIVATED	
INITIAL SETUP	
Equipment Conditions Batteries disconnected (para 7-57). References TM 9-4910-571-12&P	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)






- (1) Loosen four screws on junction box.
- (2) Open cover on junction box.
- (3) Visually inspect the wiring around terminal board position 28 for shorted wires that could put 24 vdc on position 28.




CONTINUITY TEST	
(1)	Set multimeter to ohms.
(2)	Connect positive (+) probe of multimeter to terminal board position 19.
(3)	Connect negative (-) probe of multimeter to terminal board position 1 and note reading on multimeter.
(4)	If continuity is not present, replace overload lockout cable (para 7-116).
(5)	If continuity is present, notify DS Maintenance.
(6)	Close cover on junction box.
(7)	Tighten four screws on junction box.
(8)	Connect batteries (para 7-57).



42ENS011

e136. ALL M1089 CONTROL FUNCTIONS DO NOT OPERATE FROM WRECKER CONTROL PANEL AND WRECKER REMOTE CONTROL	
INITIAL SETUP	
Equipment Conditions Top control panel cover removed (para 17-20).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Disconnect connector P107 from connector J4.
- (2) Set multimeter to volts dc.
- (3) Connect positive (+) probe of multimeter to connector P107g.
- (4) Connect negative (-) probe of multimeter to ground.
- (5) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (6) If 24 vdc is not present, go to step 4 of this fault.
- (7) Position master power switch to off (TM 9-2320-366-10-1).
- (8) Connect connector P107 to connector J4.



42EN6011

ø136. ALL M1089 CONTROL FUNCTIONS DO NOT OPERATE FROM WRECKER CONTROL PANEL AND WRECKER REMOTE CONTROL (CONT)




WARNING


Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

STATION SELECTOR SWITCH VOLTAGE TEST


- (1) Set multimeter to volts dc.
- (2) Connect positive (+) probe of multimeter to wrecker control panel terminal board position 9.
- (3) Connect negative (-) probe of multimeter to wrecker control panel terminal board position C.
- (4) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 24 vdc is not present, go to step 6 of this fault.
- (6) Position master power switch to off (TM 9-2320-366-10-1).



POSITION 9




POSITION C



42EM602A

ø136. ALL M1089 CONTROL FUNCTIONS DO NOT OPERATE FROM WRECKER CONTROL PANEL AND WRECKER REMOTE CONTROL (CONT)





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Set multimeter to volts dc.
- (2) Connect positive (+) probe of multimeter to station selector switch center pin 9.
- (3) Connect negative (-) probe of multimeter to ground.
- (4) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 24 vdc is not present, repair wire 9 (para 2-45) or replace wrecker control panel wiring harness (para 7-83).
- (6) If 24 vdc is present, replace station selector switch (para 7-34).
- (7) Position master power switch to off (TM 9-2320-366-10-1).
- (8) Install top control panel cover (para 17-20).



42EN6031

ø136. ALL M1089 CONTROL FUNCTIONS DO NOT OPERATE FROM WRECKER CONTROL PANEL AND WRECKER REMOTE CONTROL (CONT)





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Remove personnel heater for access (para 18-9).
- (2) Disconnect connector P912 from connector J912.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to connector P912-1.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 24 vdc is not present, repair wire 2006 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (8) Position master power switch to off (TM 9-2320-366-10-1).
- (9) Connect connector P912 to connector J912.



42EN6041

ø136. ALL M1089 CONTROL FUNCTIONS DO NOT OPERATE FROM WRECKER CONTROL PANEL AND WRECKER REMOTE CONTROL (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Disconnect connector P108 from connector J108.
- (2) Set multimeter to volts dc.
- (3) Connect positive (+) probe of multimeter to connector P108-18.
- (4) Connect negative (-) probe of multimeter to ground.
- (5) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (6) If 24 vdc is not present, repair wire 2006 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (7) If 24 vdc is present, repair wire 2006 (para 2-45) or replace rear lights cable assembly (para 7-104).
- (8) Position master power switch to off (TM 9-2320-366-10-1).
- (9) Connect connector P108 to connector J108.
- (10) Install personnel heater (para 18-9).
- (11) Install top control panel cover (para 17-20).




42EN6051

ø136. ALL M1089 CONTROL FUNCTIONS DO NOT OPERATE FROM WRECKER CONTROL PANEL AND WRECKER REMOTE CONTROL (CONT)




CONTINUITY TEST

- (1) Disconnect connector P107 from connector J4.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector J4-g.
- (4) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (5) If continuity is not present, repair wire 9 (para 2-45) or replace wrecker control panel wiring harness (para 7-83).




42EN6061

ø136. ALL M1089 CONTROL FUNCTIONS DO NOT OPERATE FROM WRECKER CONTROL PANEL AND WRECKER REMOTE CONTROL (CONT)



- | CONTINUITY TEST | |
|-----------------|--|
| (1) | Set multimeter to ohms. |
| (2) | Connect positive (+) probe of multimeter to connector J4-a. |
| (3) | Connect negative (-) probe of multimeter to wrecker control panel terminal board position C and note reading on multimeter. |
| (4) | Connect positive (+) probe of multimeter to connector J4-b. |
| (5) | Connect negative (-) probe of multimeter to wrecker control panel terminal board position C and note reading on multimeter. |
| (6) | If continuity is not present at connector J4-a and/or J4-b, repair wire 9 (para 2-45) or replace wrecker control panel wiring harness (para 7-83). |
| (7) | If continuity is present, repair wire 3087 (para 2-45) or replace rear lights cable assembly (para 7-104). |
| (8) | Connect connector P107 to connector J4. |
| (9) | Install top control panel cover (para 17-20). |



42EN6071

e137. ALL WRECKER FUNCTIONS DO NOT OPERATE FROM WRECKER REMOTE CONTROL

INITIAL SETUP

Equipment Conditions

Engine shut down (TM 9-2320-366-10-1).
Top control panel cover removed (para 17-20).

Tools and Special Tools


Tool Kit, Genl Mech (Item 46, Appendix C)
Multimeter, Digital (Item 22, Appendix C)
STE/ICE-R (Item 41, Appendix C)

Personnel Required

(2)

References

TM 9-4910-571-12&P




WARNING



Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Set multimeter to vdc.
- (2) Connect positive (+) probe of multimeter to station selector switch rear pin.
- (3) Connect negative (-) probe of multimeter to wrecker control panel terminal board position C.
- (4) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 24 vdc is not present, replace station selector switch (para 7-34).
- (6) Position master power switch to off (TM 9-2320-366-10-1).




POSITION C



42EN701R

e137. ALL WRECKER FUNCTIONS DO NOT OPERATE FROM WRECKER REMOTE CONTROL (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Set multimeter to vdc.
- (2) Connect positive (+) probe of multimeter to wrecker control panel terminal board position 7.
- (3) Connect negative (-) probe of multimeter to wrecker control panel terminal board position C.
- (4) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 24 vdc is not present, repair wire 7 (para 2-45), or replace wrecker control panel wiring harness (para 7-83).
- (6) Position master power switch to off (TM 9-2320-366-10-1).
- (7) Install wrecker control panel top cover (para 17-20).



42EN702R

ø137. ALL WRECKER FUNCTIONS DO NOT OPERATE FROM WRECKER REMOTE CONTROL (CONT)





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Set multimeter to vdc.
- (2) Position station selector switch to REMOTE CONTROL (TM 9-2320-366-10-1).
- (3) Connect positive (+) probe of multimeter to pin C of connector J1 and/or J2.
- (4) Connect negative (-) probe of multimeter to ground.
- (5) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 24 vdc is not present, repair wire 7 (para 2-45), or replace wrecker control panel wiring harness (para 7-83).
- (6) If 24 vdc is present, perform Wrecker Pneumatic Troubleshooting (aa1. All Wrecker Functions Do Not Operate From Wrecker Remote Control).
- (7) Position master power switch to off (TM 9-2320-366-10-1).



J1/J2

42EN7031

e138. ALL WRECKER FUNCTIONS DO NOT OPERATE FROM WRECKER CONTROL PANEL	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1). Wrecker control panel top cover removed (para 17-20).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Set multimeter to volts dc.
- (2) Connect positive (+) probe of multimeter to station selector switch front pin.
- (3) Connect negative (-) probe of multimeter to ground.
- (4) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 24 vdc is not present, replace station selector switch (para 7-34).
- (6) Position master power switch to off (TM 9-2320-366-10-1).

STATION SELECTOR SWITCH
FRONT PIN



42EM801A

e138. ALL WRECKER FUNCTIONS DO NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)




WARNING



Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Set multimeter to volts dc.
- (2) Connect positive (+) probe of multimeter to TB-7A.
- (3) Connect negative (-) probe of multimeter to ground.
- (4) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 24 vdc is not present, repair wire 7A (para 2-45) or replace wrecker control panel wiring harness (para 7-83).
- (6) If 24 vdc is present, perform Electrical System Troubleshooting (e140. Main Winch Left or Right Speed Function Does Not Operate From Wrecker Control Panel or e141. Main Winch Left or Right Free Spool Function Does Not Operate From Wrecker Control Panel).
- (7) Position master power switch to off (TM 9-2320-366-10-1).
- (8) Install wrecker control panel top cover (para 17-20).




TB-7A



42EM802A

e138A. M1089 LH OR RH 30K WINCH DOES NOT PAY-IN	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 902320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



OPERATIONAL TEST

- (1) Start engine (TM 9-2320-366-10-1).
- (2) Position PTO switch to on.

CAUTION

Keep tachometer within 1,250-1,450 rpm when Power Take-Off (PTO) is engaged. Do not exceed 1,450 rpm. Failure to comply may result in damage to equipment.

NOTE




In the event of a tachometer failure a HAND THROTTLE lever positioned to L is approximately 1,250-1,450 rpm.

- (3) Set engine speed by increasing HAND THROTTLE lever until tachometer reads 1,250-1,450 rpm.
- (4) Position STATION SELECTOR switch to WRECKER CONTROL PANEL.

NOTE

The LH and RH 30K winches are operated the same way. LH shown.

- (5) Position MAIN WINCH LH SPEED switch to LOW.
- (6) Position MAIN WINCH LH lever to IN until cable is fully recovered.
- (7) If LH 30K winch does not pay-in, go to step 2 of this fault.
- (8) If LH 30K winch does pay-in, perform Electrical System Troubleshooting task e141. One Wrecker Function Does Not Operate From Wrecker Remote Control.
- (9) Set engine speed to idle (750 rpm) by decreasing HAND THROTTLE lever to full down position.
- (10) Position PTO to off.
- (11) Shut down engine (TM 9-2320-366-10-1).



X2EN8A1B

e138A. M1089 LH OR RH 30K WINCH DOES NOT PAY-IN (CONT)


KNOWN INFO
Hydraulic tank oil level OK. MAIN WINCH LH and RH FREE SPOOL switches to OFF. MODE SELECTOR SWITCH to NORMAL.
POSSIBLE PROBLEMS
Faulty MAIN WINCH LH/RH FREE SPOOL switch. Faulty M1089 air system. Faulty wrecker hydraulic system.

2.

WARNING
Read WARNING on following page.

Is 24 VDC present at terminal block (see Table 2-12.20. MAIN WINCH LH/RH FREE SPOOL Switch Terminal Blocks)?

TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
If 24 VDC is not present, perform Wrecker Air System troubleshooting. If 24 VDC is present, MAIN WINCH LH/RH FREE SPOOL switch is faulty.



WARNING



Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Remove M1089 control panel top cover (para 14-4).
- (2) Set multimeter to volts DC.
- (3) Connect positive (+) probe of multimeter to terminal block (see Table 2-12.20. MAIN WINCH LH/RH FREE SPOOL Switch Terminal Blocks).
- (4) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (5) If 24 VDC is not present, perform Wrecker Air System Troubleshooting task aa1. M1089 LH or Rh 30K Winch Does Not Pay-In.
- (6) If 24 VDC is present, replace MAIN WINCH LH/RH FREE SPOOL switch (para 7-34).
- (7) Install M1089 control panel top cover (para 14-4).

Table 2-12.20. MAIN WINCH LH/RH FREE SPOOL Switch Terminal Blocks

Side	Terminal Block
LH	TB19
RH	TB18



X2EN8A3B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL

INITIAL SETUP

Equipment Conditions

Engine shut down (TM 9-2320-366-10-1).
Wrecker control panel top cover removed (para 14-4).

Tools and Special Tools

Tool Kit, Genl Mech (Item 46, Appendix C)
Multimeter, Digital (Item 22, Appendix C)
STE/ICE-R (Item 41, Appendix C)


Personnel Required
(2)

References
TM 9-4910-571-12&P

NOTE

Perform Electrical System Troubleshooting task e1. Circuit Breaker Does Not Operate on circuit breaker CB50 prior to beginning this task.

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL.
POSSIBLE PROBLEMS
Faulty STATION SELECTOR switch. Faulty MAIN WINCH LH SPEED switch. Faulty MAIN WINCH RH SPEED switch. Faulty M1089 control panel wiring harness. Faulty M1089 30K winch control wiring harness. Faulty M1089 control panel power cable assembly. Faulty M1089 rear lights cable assembly. Faulty auxiliary panel cable assembly. Faulty dashboard cable assembly. Faulty jumper wire. Faulty wrecker hydraulic system.



WARNING

Goggles must be worn while operating wrecker control panel. Blowing dust and debris may become airborne while engine is running. Failure to comply may result in injury to personnel.

OPERATIONAL TEST

- (1) Start engine (TM 9-2320-366-10-1).
- (2) Position PTO switch to on.


CAUTION

Keep tachometer within 1,250-1,450 rpm when Power Take-Off (PTO) is engaged. Do not exceed 1,450 rpm. Failure to comply may result in damage to equipment.



NOTE

In the event of a tachometer failure a HAND THROTTLE lever positioned to L is approximately 1,250-1,450 rpm.

- (3) Set engine speed by increasing HAND THROTTLE lever until tachometer reads 1,250-1,450 rpm.
- (4) Position MAIN WINCH LH SPEED switch to LOW.
- (5) Position MAIN WINCH LH FREE SPOOL switch to OFF.
- (6) Position MAIN WINCH LH lever to OUT until the first five wraps of cable have pay-out.
- (7) Position MAIN WINCH LH SPEED switch to HIGH.
- (8) Position MAIN WINCH LH lever to OUT and note speed of winch.
- (9) If LH 30K winch does not operate at high speed, go to step 4 of this fault.




HAND THROTTLE LEVER



4BEN901B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. STATION SELECTOR switch OK. MAIN WINCH LH SPEED switch OK. M1089 control panel power cable assembly OK. M1089 rear lights cable assembly. Auxiliary panel cable assembly OK. Dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty MAIN WINCH RH SPEED switch. Faulty M1089 control panel wiring harness. Faulty M1089 30K winch control wiring harness. Faulty jumper wire. Faulty wrecker hydraulic system.







TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.

WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.


- VOLTAGE TEST**
- (1) Position MAIN WINCH LH SPEED switch to LOW.
 - (2) Position MAIN WINCH LH lever to IN until cable is fully recovered.
 - (3) Set engine speed to idle (750 rpm) by decreasing HAND THROTTLE lever to full down position.
 - (4) Position PTO switch to off.
 - (5) Shut down engine (TM 9-2320-366-10-1).
 - (6) Remove power distribution panel (PDP) cover (para 16-2).
 - (7) Remove circuit breaker CB50 from power distribution panel (PDP).
 - (8) Open LH and RH catwalks.
 - (9) Disconnect terminal lug on wire 12 from RH counter balance valve.
 - (10) Position MAIN WINCH RH SPEED switch to HIGH.
 - (11) Set multimeter to volts DC.
 - (12) Connect positive (+) probe of multimeter to terminal lug on wire 12.
 - (13) Connect negative (-) probe of multimeter to ground.
 - (14) Install circuit breaker CB50 in power distribution panel (PDP) and note reading on multimeter.
 - (15) If 24 VDC is not present go to step 7 of this fault.
 - (16) Remove circuit breaker CB50 from power distribution panel (PDP).
 - (17) Connect terminal lug on wire 12 to RH counter balance valve.
 - (18) Position MAIN WINCH RH SPEED switch to LOW.



4BEN902B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. STATION SELECTOR switch OK. MAIN WINCH LH SPEED switch OK. M1089 control panel power cable assembly OK. M1089 rear lights cable assembly. Auxiliary panel cable assembly OK. Dashboard cable assembly OK. MAIN WINCH RH SPEED switch OK. M1089 control panel wiring harness OK.
POSSIBLE PROBLEMS
Faulty M1089 30K winch control wiring harness. Faulty jumper wire. Faulty wrecker hydraulic system.



TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.


CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Disconnect terminal lug on wire C from RH counter balance valve.
- (3) Connect positive (+) probe of multimeter to terminal lug on wire C.
- (4) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (5) If continuity is not present, go to step 8 of this fault.
- (6) If continuity is present, notify DS Maintenance.
- (7) Connect terminal lug on wire C to RH counter balance valve.

NOTE

Perform steps (8) through (11) if continuity is present from terminal lug on wire C to ground.


- (8) Close LH and RH catwalks.
- (9) Install circuit breaker CB50 in PDP.
- (10) Install PDP cover (para 16-2).
- (11) Install wrecker control panel top cover (para 14-4).



4BEN903B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL.
POSSIBLE PROBLEMS
Faulty STATION SELECTOR switch. Faulty MAIN WINCH LH SPEED switch. Faulty MAIN WINCH RH SPEED switch. Faulty M1089 control panel wiring harness. Faulty M1089 30K winch control wiring harness. Faulty M1089 control panel power cable assembly. Faulty M1089 rear lights cable assembly. Faulty auxiliary panel cable assembly. Faulty dashboard cable assembly. Faulty jumper wire. Faulty wrecker hydraulic system.





TEST OPTIONS
Operational Test
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.

WARNING

Goggles must be worn while operating wrecker control panel. Blowing dust and debris may become airborne while engine is running. Failure to comply may result in injury to personnel.

OPERATIONAL TEST


- (1) Position MAIN WINCH LH SPEED switch to LOW.
- (2) Position MAIN WINCH LH lever to IN until cable is fully recovered.
- (3) Position MAIN WINCH RH SPEED switch to LOW.
- (4) Position MAIN WINCH RH FREE SPOOL switch to OFF.
- (5) Position MAIN WINCH RH lever to OUT until the first five wraps of cable have pay-out.
- (6) Position MAIN WINCH RH SPEED switch to HIGH.
- (7) Position MAIN WINCH RH lever to OUT and note speed of winch.
- (8) If RH 30K winch does not operate at high speed, go to step 9 of this fault.
- (9) Position MAIN WINCH RH SPEED switch to LOW.
- (10) Position MAIN WINCH RH lever to IN until cable is fully recovered.
- (11) Set engine speed to idle (750 rpm) by decreasing HAND THROTTLE lever to the full down position.
- (12) Position PTO switch to off.
- (13) Shut down engine (TM 9-2320-366-10-1).



4BEN904B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. STATION SELECTOR switch OK. MAIN WINCH RH SPEED switch OK. M1089 control panel power cable assembly OK. M1089 rear lights cable assembly. Auxiliary panel cable assembly OK. Dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty MAIN WINCH LH SPEED switch. Faulty M1089 control panel wiring harness. Faulty M1089 30K winch control wiring harness. Faulty jumper wire. Faulty wrecker hydraulic system.




TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.

WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.


- VOLTAGE TEST**
- (1) Remove power distribution panel (PDP) cover (para 16-2).
 - (2) Remove circuit breaker CB50 from power distribution panel (PDP).
 - (3) Open LH and RH catwalks.
 - (4) Disconnect terminal lug on wire 14 from LH counter balance valve.
 - (5) Position MAIN WINCH LH SPEED switch to HIGH.
 - (6) Set multimeter to volts DC.
 - (7) Connect positive (+) probe of multimeter to terminal lug on wire 14.
 - (8) Connect negative (-) probe of multimeter to ground.
 - (9) Install circuit breaker CB50 in power distribution panel (PDP) and note reading on multimeter.
 - (10) If 24 VDC is not present go to step 13 of this fault.
 - (11) Remove circuit breaker CB50 from power distribution panel (PDP).
 - (12) Connect terminal lug on wire 14 to RH counter balance valve.
 - (13) Position MAIN WINCH LH SPEED switch to LOW.



4BEN905B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. STATION SELECTOR switch OK. MAIN WINCH RH SPEED switch OK. M1089 control panel power cable assembly OK. M1089 rear lights cable assembly. Auxiliary panel cable assembly OK. Dashboard cable assembly OK. MAIN WINCH LH SPEED switch OK. M1089 control panel wiring harness OK.
POSSIBLE PROBLEMS
Faulty M1089 30K winch control wiring harness. Faulty jumper wire. Faulty wrecker hydraulic system.



TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.



CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Disconnect terminal lug on wire C from RH counter balance valve.
- (3) Connect positive (+) probe of multimeter to terminal lug on wire C.
- (4) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (5) If continuity is not present, go to step 14 of this fault.
- (6) If continuity is present, notify DS Maintenance.
- (7) Connect terminal lug on wire C to LH counter balance valve.

NOTE


Perform steps (8) through (11) if continuity is present from front/rear terminal lug of LH counter balance valve to ground.

- (8) Close LH and RH catwalks.
- (9) Install circuit breaker CB50 in PDP.
- (10) Install PDP cover (para 16-2).
- (11) Install wrecker control panel top cover (para 14-4).



4BEN906B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)




WARNING



Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Install circuit breaker CB50 in PDP.
- (2) Position MAIN WINCH RH SPEED switch to HIGH.
- (3) Set multimeter to volts DC.
- (4) Connect positive (+) probe of multimeter to terminal block TB12.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) If 24 VDC is not present, replace MAIN WINCH RH SPEED switch (para 7-34) and M1089 control panel wiring harness (para 7-83).
- (7) If 24 VDC is present, replace M1089 30K winch control wiring harness (para 7-142).
- (8) Position MAIN WINCH RH SPEED switch to LOW.
- (9) Close LH and RH catwalks.
- (10) Install PDP cover (para 16-2).
- (11) Install wrecker control panel top cover (para 14-4).



MAIN WINCH LH SPEED SWITCH




TERMINAL BLOCK TB12



RH CATWALK

LH CATWALK




4BEN907B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. STATION SELECTOR switch OK. MAIN WINCH LH SPEED switch OK. M1089 control panel power cable assembly OK. M1089 rear lights cable assembly. Auxiliary panel cable assembly OK. Dashboard cable assembly OK. MAIN WINCH RH SPEED switch OK. M1089 control panel wiring harness OK.
POSSIBLE PROBLEMS
Faulty M1089 30K winch control wiring harness. Faulty jumper wire.



8.
Is continuity present between terminal blocks TBC(1), TBC(2), TBC(3), TBC(4), and TBC(5).

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, jumper wire is faulty. If continuity is present, M1089 30K winch control wiring is faulty.



CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to terminal block TBC(1).
- (3) Connect negative (-) probe of multimeter to terminal block TBC(2) and note reading on multimeter.
- (4) Connect positive (+) probe of multimeter to terminal block TBC(2).
- (5) Connect negative (-) probe of multimeter to terminal block TBC(3) and note reading on multimeter.
- (6) Connect positive (+) probe of multimeter to terminal block TBC(3).
- (7) Connect negative (-) probe of multimeter to terminal block TBC(4) and note reading on multimeter.
- (8) Connect positive (+) probe of multimeter to terminal block TBC(4).
- (9) Connect negative (-) probe of multimeter to terminal block TBC(5) and note reading on multimeter.
- (10) If continuity is not present between two terminal blocks noted above, replace jumper wire between terminal blocks that continuity is not present (para 7-33).
- (11) If continuity is present, replace M1089 winch control wiring harness (para 7-142).
- (12) Close LH and RH catwalks.
- (13) Install circuit breaker CB50 in PDP.
- (14) Install wrecker control panel top cover (para 14-4).



4BEN908B


e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL.
POSSIBLE PROBLEMS
Faulty STATION SELECTOR switch. Faulty M1089 control panel wiring harness. Faulty M1089 control panel power cable assembly. Faulty M1089 rear lights cable assembly. Faulty auxiliary panel cable assembly. Faulty dashboard cable assembly. Faulty jumper wire.



CONTINUITY TEST


- (1) Remove power distribution panel (PDP) cover (para 16-2).
- (2) Remove circuit breaker CB50 from power distribution panel (PDP).
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to terminal block TBC(1).
- (5) Connect negative (-) probe of multimeter to terminal block TBC(2) and note reading on multimeter.
- (6) Connect positive (+) probe of multimeter to terminal block TBC(2).
- (7) Connect negative (-) probe of multimeter to terminal block TBC(3) and note reading on multimeter.
- (8) Connect positive (+) probe of multimeter to terminal block TBC(3).
- (9) Connect negative (-) probe of multimeter to terminal block TBC(4) and note reading on multimeter.
- (10) Connect positive (+) probe of multimeter to terminal block TBC(4).
- (11) Connect negative (-) probe of multimeter to terminal block TBC(5) and note reading on multimeter.
- (12) If continuity is not present between two terminal blocks noted above, replace jumper wire between terminal blocks that continuity is not present (para 7-33).



4BEN909B


e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL.
POSSIBLE PROBLEMS
Faulty STATION SELECTOR switch. Faulty M1089 control panel wiring harness. Faulty M1089 control panel power cable assembly. Faulty M1089 rear lights cable assembly. Faulty auxiliary panel cable assembly. Faulty dashboard cable assembly. Faulty jumper wire.



CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to terminal block TBC.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair terminal lug TL54 on wires 3087 and 3088 (para 2-45) or replace M1089 rear lights cable assembly (para 7-104).



4BEN910B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL.
POSSIBLE PROBLEMS
Faulty STATION SELECTOR switch. Faulty M1089 control panel wiring harness. Faulty M1089 control panel power cable assembly. Faulty M1089 rear lights cable assembly. Faulty auxiliary panel cable assembly. Faulty dashboard cable assembly. Faulty jumper wire.




TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, jumper wire if faulty.




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to terminal block TB9(a).
- (3) Connect negative (-) probe of multimeter to terminal block TB9(b) and note reading on multimeter.
- (4) If continuity is not present, replace jumper wire from terminal block TB9(a) to terminal block TB9(b) (para 7-33).



4BEN911B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Install circuit breaker CB50 in PDP.
- (2) Set multimeter to volts DC.
- (3) Connect positive (+) probe of multimeter to terminal block TB9.
- (4) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (5) If 24 VDC is not present, go to step 15 of this fault.
- (6) If 24 VDC is present, replace M1089 control panel wiring harness (para 7-83) and STATION SELECTOR switch (para 7-34).

NOTE


Perform steps (7) and (8) if 24 VDC is present at terminal block TB9.

- (7) Install PDP cover (para 16-2).
- (8) Install wrecker control panel top cover (para 14-4).



4BEN912B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)




WARNING



Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Install circuit breaker CB50 in PDP.
- (2) Position MAIN WINCH LH SPEED switch to HIGH.
- (3) Set multimeter to volts DC.
- (4) Connect positive (+) probe of multimeter to terminal block TB14.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) If 24 VDC is not present, replace MAIN WINCH LH SPEED switch (para 7-34) and M1089 control panel wiring harness (para 7-83).
- (7) If 24 VDC is present, replace M1089 30K winch control wiring harness (para 7-142).
- (8) Position MAIN WINCH RH SPEED switch to LOW.
- (9) Close LH and RH catwalks.
- (10) Install PDP cover (para 16-2).
- (11) Install wrecker control panel top cover (para 14-4).



MAIN WINCH LH SPEED SWITCH




TERMINAL BLOCK TB14



RH CATWALK

LH CATWALK




4BEN913B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. STATION SELECTOR switch OK. MAIN WINCH RH SPEED switch OK. M1089 control panel power cable assembly OK. M1089 rear lights cable assembly. Auxiliary panel cable assembly OK. Dashboard cable assembly OK. MAIN WINCH LH SPEED switch OK. M1089 control panel wiring harness OK.
POSSIBLE PROBLEMS
Faulty M1089 30K winch control wiring harness. Faulty jumper wire.




14.
Is continuity present between terminal blocks TBC(1), TBC(2), TBC(3), TBC(4), and TBC(5).

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, jumper wire is faulty. If continuity is present, M1089 30K winch control wiring is faulty.



CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to terminal block TBC(1).
- (3) Connect negative (-) probe of multimeter to terminal block TBC(2) and note reading on multimeter.
- (4) Connect positive (+) probe of multimeter to terminal block TBC(2).
- (5) Connect negative (-) probe of multimeter to terminal block TBC(3) and note reading on multimeter.
- (6) Connect positive (+) probe of multimeter to terminal block TBC(3).
- (7) Connect negative (-) probe of multimeter to terminal block TBC(4) and note reading on multimeter.
- (8) Connect positive (+) probe of multimeter to terminal block TBC(4).
- (9) Connect negative (-) probe of multimeter to terminal block TBC(5) and note reading on multimeter.
- (10) If continuity is not present between two terminal blocks noted above, replace jumper wire between terminal blocks that continuity is not present (para 7-33).
- (11) If continuity is present, replace M1089 winch control wiring harness (para 7-142).
- (12) Close LH and RH catwalks.
- (13) Install circuit breaker CB50 in PDP.
- (14) Install wrecker control panel top cover (para 14-4).



4BEN914B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. Jumper wires OK.
POSSIBLE PROBLEMS
Faulty M1089 control panel power cable assembly. Faulty M1089 rear lights cable assembly. Faulty auxiliary panel cable assembly. Faulty dashboard cable assembly.



TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.

CAUTION





Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Disconnect batteries (para 7-57).
- (2) Remove kick panel (para 16-3).
- (3) Disconnect connector J108 from connector P108.
- (4) Remove circuit breaker CB50 from PDP.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector J108 pin 16.
- (7) Connect negative (-) probe of multimeter to circuit breaker CB50 socket 2 and note reading on multimeter.
- (8) If continuity is not present, go to step 17 of this fault.



4BEN915B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)



CAUTION





Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Install circuit breaker CB50 in PDP.
- (2) Disconnect connector P107 from connector J107.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector P108 socket 16.
- (5) Connect negative (-) probe of multimeter to connector P107 socket g and note reading on multimeter.
- (6) If continuity is not present, repair wire 2006 from connector P107 socket g to connector P108 socket 16 (para 2-45) or replace M1089 rear lights cable assembly (para 7-104).
- (7) If continuity is present, repair wire 9 from connector J107 to terminal block TB9 (para 2-45) or replace M1089 control panel power cable assembly (para 7-109).
- (8) Connect connector P108 to connector J108.
- (9) Install kick panel (para 16-3).
- (10) Connect connector P107 to connector J107.
- (11) Install wrecker control panel top cover (para 14-4).
- (12) Connect batteries (para 7-57).



4BEN916B

e139. MAIN WINCH LH OR RH SPEED SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)



CAUTION





Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Remove personnel heater for access (para 18-9).
- (2) Disconnect connector P912 from connector J912.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector J108 pin 16.
- (5) Connect negative (-) probe of multimeter to connector J912 pin/socket 1 and note reading on multimeter.
- (6) If continuity is not present, repair wire 2006 from connector J108 pin 16 to connector J912 socket 1 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (7) If continuity is present, repair wire 2006 from circuit breaker CB50 socket 2 to connector P912 pin 1 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (8) Connect connector P912 to connector J912.
- (9) Install personnel heater (para 18-9).
- (10) Connect connector J108 to connector P108.
- (11) Install circuit breaker CB50 in PDP.
- (12) Install kick panel (para 16-3).
- (13) Install wrecker control panel top cover (para 14-4).
- (14) Connect batteries (para 7-57).



4BEN917B

e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL

INITIAL SETUP

Equipment Conditions

Engine shut down (TM 9-2320-366-10-1).
Wrecker control panel top cover removed (para 14-4).


Personnel Required
(2)

Tools and Special Tools

Tool Kit, Genl Mech (Item 46, Appendix C)
Multimeter, Digital (Item 22, Appendix C)
STE/ICE-R (Item 41, Appendix C)
Gloves, Welder's (Item 14, Appendix C)

References

TM 9-4910-571-12&P





WARNING

Goggles must be worn while operating wrecker control panel. Blowing dust and debris may become airborne while engine is running. Failure to comply may result in injury to personnel.

Wear leather gloves at all times when handling winch cable. Do not allow cable to slide through hands even with gloves on. Broken wires may cause injury.

Never let moving cable slide through hands, even when wearing gloves. A broken wire could cut through gloves and cut hands. Failure to comply may result in injury to personnel.



OPERATIONAL TEST

- (1) Start engine (TM 9-2320-366-10-1).
- (2) Position PTO switch to on.

CAUTION


Keep tachometer within 1,250-1,450 rpm when Power Take-Off (PTO) is engaged. Do not exceed 1,450 rpm. Failure to comply may result in damage to equipment.

NOTE

In the event of a tachometer failure a HAND THROTTLE lever positioned to L is approximately 1,250-1,450 rpm.

- (3) Set engine speed by increasing HAND THROTTLE lever until tachometer reads 1,250-1,450 rpm.
- (4) Position MAIN WINCH LH FREESPOOL switch to ON.
- (5) Pull cable to see if LH 30K winch drum FREESPOOLS.
- (6) If LH 30K winch does not freespool, go to step 5 of this fault.


MAIN WINCH LH FREESPOOL SWITCH



4BE001B

e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)



KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. MAIN WINCH LH and RH SPEED switches operate. LH 30K winch freespools. MAIN WINCH LH FREESPOOL switch OK. 30K winch pneumatic manifold solenoid L19 OK.
POSSIBLE PROBLEMS
Faulty MAIN WINCH RH FREESPOOL switch. Faulty M1089 control panel wiring harness. Faulty M1089 30K winch control wiring harness. Faulty jumper wire. Faulty 30K winch pneumatic manifold solenoid L17. Faulty wrecker air system.




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.


- VOLTAGE TEST**
- (1) Set engine speed to idle (750 rpm) by decreasing HAND THROTTLE lever to full down position.
 - (2) Position PTO switch to off.
 - (3) Shut down engine (TM 9-2320-366-10-1).
 - (4) Position MAIN WINCH LH FREESPOOL switch to OFF.
 - (5) Position MAIN WINCH RH FREESPOOL switch to ON.
 - (6) Set multimeter to volts DC.
 - (7) Connect positive (+) probe of multimeter to terminal block TB18.
 - (8) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
 - (9) If 24 VDC is not present, replace MAIN WINCH RH FREESPOOL switch (para 7-34) and M1089 wrecker control panel wiring harness (para 7-83).
 - (10) Position MAIN WINCH RH FREESPOOL switch to OFF.



TERMINAL BLOCK TB18




PTO SWITCH



e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)


KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. MAIN WINCH LH and RH SPEED switches operate. LH 30K winch freespools. MAIN WINCH LH FREESPOOL switch OK. 30K winch pneumatic manifold solenoid L19 OK. MAIN WINCH RH FREESPOOL switch OK. M1089 control panel wiring harness OK.
POSSIBLE PROBLEMS
Faulty M1089 30K winch control wiring harness. Faulty jumper wire. Faulty 30K winch pneumatic manifold solenoid L17. Faulty wrecker air system.



TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, jumper wire is faulty.


CONTINUITY TEST

- (1) Remove power distribution panel (PDP) cover (para 16-2).
- (2) Remove circuit breaker CB50 from power distribution panel (PDP).
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to terminal block TBC(1).
- (5) Connect negative (-) probe of multimeter to terminal block TBC(2) and note reading on multimeter.
- (6) Connect positive (+) probe of multimeter to terminal block TBC(2).
- (7) Connect negative (-) probe of multimeter to terminal block TBC(3) and note reading on multimeter.
- (8) Connect positive (+) probe of multimeter to terminal block TBC(3).
- (9) Connect negative (-) probe of multimeter to terminal block TBC(4) and note reading on multimeter.
- (10) Connect positive (+) probe of multimeter to terminal block TBC(4).
- (11) Connect negative (-) probe of multimeter to terminal block TBC(5) and note reading on multimeter.
- (12) If continuity is not present between two terminal blocks noted above, replace jumper wire between terminal blocks that continuity is not present (para 7-33).



4BEP003B

e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)



WARNING

Wear protective goggles to protect against possible injury from release of high pressure air. Failure to comply may result in injury to personnel.

AIR PRESSURE TEST


- (1) Install circuit breaker CB50 in PDP.
- (2) Open LH and RH catwalks.
- (3) Disconnect air hose from pneumatic manifold solenoid L17 port 1.
- (4) Start engine (TM 9-2320-366-10-1).
- (5) Position MAIN WINCH RH FREESPOOL switch to ON.
- (6) If air pressure is not present at pneumatic manifold solenoid L17 port 1, go to step 11 of this fault.
- (7) If air pressure is present at pneumatic manifold solenoid L17 port 1, perform Wrecker Air System Troubleshooting task aa3. Main Winch RH Freespool Does Not Operate.
- (8) Position MAIN WINCH RH FREESPOOL switch to OFF.
- (9) Shut down engine (TM 9-2320-366-10-1).
- (10) Connect air hose to pneumatic manifold solenoid L17 port 1.

NOTE


Perform steps (11) and (13) if air pressure is present at air hose.

- (11) Close LH and RH catwalks.
- (12) Install PDP cover (para 16-2).
- (13) Install wrecker control panel top cover (para 14-4).

**MAIN WINCH
RH FREESPOOL
SWITCH**




**CIRCUIT BREAKER
CB50**




RH CATWALK

LH CATWALK




**SOLENOID
VALVE L17**



4BEP004B

e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. MAIN WINCH LH and RH SPEED switches operate.
POSSIBLE PROBLEMS
Faulty MAIN WINCH LH FREESPOOL switch. Faulty MAIN WINCH RH FREESPOOL switch. Faulty M1089 control panel wiring harness. Faulty M1089 30K winch control wiring harness. Faulty jumper wire. Faulty 30K winch pneumatic manifold solenoid L17. Faulty 30K winch pneumatic manifold solenoid L19. Faulty wrecker air system.




TEST OPTIONS
Operational Test
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.

WARNING


Goggles must be worn while operating wrecker control panel. Blowing dust and debris may become airborne while engine is running. Failure to comply may result in injury to personnel.

Wear leather gloves at all times when handling winch cable. Do not allow cable to slide through hands even with gloves on. Broken wires may cause injury.

Never let moving cable slide through hands, even when wearing gloves. A broken wire could cut through gloves and cut hands. Failure to comply may result in injury to personnel.




MAIN WINCH LH FREESPOOL SWITCH **MAIN WINCH RH FREESPOOL SWITCH**



- OPERATIONAL TEST**
- (1) Position MAIN WINCH LH FREESPOOL switch to OFF.
 - (2) Position MAIN WINCH RH FREESPOOL switch to ON.
 - (3) Pull cable to see if RH 30K winch drum free spools.
 - (4) If RH 30K winch does not freespool, go to step 9 of this fault.
 - (5) Position MAIN WINCH RH FREESPOOL switch to OFF.
 - (6) Set engine speed to idle (750 rpm) by decreasing HAND THROTTLE lever to full down position.
 - (7) Position PTO switch to off.
 - (8) Shut down engine (TM 9-2320-366-10-1).

PTO SWITCH


HAND THROTTLE LEVER



4BEP005B

e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. MAIN WINCH LH and RH SPEED switches operate. RH 30K winch freespools. MAIN WINCH LH FREESPOOL switch OK. 30K winch pneumatic manifold solenoid L17 OK.
POSSIBLE PROBLEMS
Faulty MAIN WINCH LH FREESPOOL switch. Faulty M1089 control panel wiring harness. Faulty M1089 30K winch control wiring harness. Faulty jumper wire. Faulty 30K winch pneumatic manifold solenoid L19. Faulty wrecker air system.





WARNING


Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

- CONTINUITY TEST**
- (1) Position MAIN WINCH LH FREESPOOL switch to ON.
 - (2) Set multimeter to volts DC.
 - (3) Connect positive (+) probe of multimeter to terminal block TB19.
 - (4) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
 - (5) If 24 VDC is not present, replace MAIN WINCH LH FREESPOOL switch (para 7-34) and M1089 wrecker control panel wiring harness (para 7-83).
 - (6) Position MAIN WINCH LH FREESPOOL switch to OFF.

MAIN WINCH LH FREESPOOL SWITCH




TERMINAL BLOCK TB19



4BEP006B

e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)



KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. MAIN WINCH LH and RH SPEED switches operate. RH 30K winch freespools. MAIN WINCH RH FREESPOOL switch OK. 30K winch pneumatic manifold solenoid L17 OK. MAIN WINCH LH FREESPOOL switch OK. M1089 control panel wiring harness OK.
POSSIBLE PROBLEMS
Faulty M1089 30K winch control wiring harness. Faulty jumper wire. Faulty 30K winch pneumatic manifold solenoid L19. Faulty wrecker air system.



TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, jumper wire is faulty.


CONTINUITY TEST

- (1) Remove power distribution panel (PDP) cover (para 16-2).
- (2) Remove circuit breaker CB50 from power distribution panel (PDP).
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to terminal block TBC(1).
- (5) Connect negative (-) probe of multimeter to terminal block TBC(2) and note reading on multimeter.
- (6) Connect positive (+) probe of multimeter to terminal block TBC(2).
- (7) Connect negative (-) probe of multimeter to terminal block TBC(3) and note reading on multimeter.
- (8) Connect positive (+) probe of multimeter to terminal block TBC(3).
- (9) Connect negative (-) probe of multimeter to terminal block TBC(4) and note reading on multimeter.
- (10) Connect positive (+) probe of multimeter to terminal block TBC(4).
- (11) Connect negative (-) probe of multimeter to terminal block TBC(5) and note reading on multimeter.
- (12) If continuity is not present between two terminal blocks noted above, replace jumper wire between terminal blocks that continuity is not present (para 7-33).



4BEP007B

e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)



WARNING

Wear protective goggles to protect against possible injury from release of high pressure air. Failure to comply may result in injury to personnel.





AIR PRESSURE TEST

- (1) Install circuit breaker CB50 in PDP.
- (2) Open LH and RH catwalks.
- (3) Disconnect air hose from pneumatic manifold solenoid L19 port 1.
- (4) Start engine (TM 9-2320-366-10-1).
- (5) Position MAIN WINCH LH FREESPOOL switch to ON.
- (6) If air pressure is not present at pneumatic manifold solenoid L19 port 1, go to step 13 of this fault.
- (7) If air pressure is present at pneumatic manifold solenoid L19 port 1, perform Wrecker Air System Troubleshooting task aa3. Main Winch RH Freespool Does Not Operate.
- (8) Position MAIN WINCH LH FREESPOOL switch to OFF.
- (9) Shut down engine (TM 9-2320-366-10-1).
- (10) Connect air hose to pneumatic manifold solenoid L19 port 1.

NOTE

Perform steps (11) and (13) if air pressure is present at air hose.

- (11) Close LH and RH catwalks.
- (12) Install PDP cover (para 16-2).
- (13) Install wrecker control panel top cover (para 14-4).



4BEP008B


e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. MAIN WINCH LH and RH SPEED switches operate.
POSSIBLE PROBLEMS
Faulty M1089 control panel wiring harness. Faulty jumper wire. Faulty wrecker air system.

9. **WARNING**
Read WARNING on following page.

Is 24 VDC present at terminal block TB19?

TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
If 24 VDC is not present, M1089 control panel wiring harness is faulty.





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Position MAIN WINCH LH FREESPOOL switch to ON.
- (2) Set multimeter to volts DC.
- (3) Connect positive (+) probe of multimeter to terminal block TB19.
- (4) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (5) If 24 VDC is not present, replace M1089 control panel wiring harness (para 7-83).
- (6) Position MAIN WINCH LH FREESPOOL switch to OFF.

MAIN WINCH LH FREESPOOL SWITCH



TERMINAL BLOCK TB19




4BEP009B

e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. MAIN WINCH LH and RH SPEED switches operate. M1089 control panel wiring harness OK.
POSSIBLE PROBLEMS
Faulty jumper wire. Faulty wrecker air system.



10.
Is continuity present between terminal blocks TBC(1), TBC(2), TBC(3), TBC(4) and TBC(5)?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, jumper wires is faulty. If continuity is present, wrecker air system is faulty.



CONTINUITY TEST


- (1) Remove PDP cover (para 16-2).
- (2) Remove circuit breaker CB50 from PDP.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to terminal block TBC(1).
- (5) Connect negative (-) probe of multimeter to terminal block TBC(2) and note reading on multimeter.
- (6) Connect positive (+) probe of multimeter to terminal block TBC(2).
- (7) Connect negative (-) probe of multimeter to terminal block TBC(3) and note reading on multimeter.
- (8) Connect positive (+) probe of multimeter to terminal block TBC(3).
- (9) Connect negative (-) probe of multimeter to terminal block TBC(4) and note reading on multimeter.
- (10) Connect positive (+) probe of multimeter to terminal block TBC(4).
- (11) Connect negative (-) probe of multimeter to terminal block TBC(5) and note reading on multimeter.
- (12) If continuity is not present between two terminal blocks noted above, replace jumper wire between terminal blocks that continuity is not present (para 7-33).
- (13) If continuity is present, perform Wrecker Air System Troubleshooting task aa4. M1089 LH And RH 30K Winch FREESPOOL Do Not Operate.
- (14) Install circuit breaker CB50 in PDP.
- (15) Install PDP cover (para 16-2).
- (16) Install wrecker control panel top cover (para 14-4).



4BEP010B





e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. MAIN WINCH LH and RH SPEED switches operate. LH 30K winch freespools. MAIN WINCH LH FREESPOOL switch OK. Faulty 30K winch pneumatic manifold solenoid L19. MAIN WINCH RH FREESPOOL switch OK. M1089 control panel wiring harness OK. Faulty jumper wire.
POSSIBLE PROBLEMS
Faulty M1089 30K winch control wiring harness. Faulty 30K winch pneumatic manifold solenoid L17. Faulty wrecker air system.



TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, M1089 winch control wiring harness is faulty.

- CONTINUITY TEST**
- (1) Remove circuit breaker CB50 from PDP.
 - (2) Remove electrical tape from conductor splice at pneumatic solenoid L17.
 - (3) Cut wire 18 from conductor splice at pneumatic solenoid L17.
 - (4) Set multimeter to ohms.
 - (5) Connect positive (+) probe of multimeter to terminal block TB18.
 - (6) Connect negative (-) probe of multimeter to wire 18 and note reading on multimeter.
 - (7) If continuity is not present, replace M1089 winch control wiring harness (para 7-142).




4BEP011B

e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. MAIN WINCH LH and RH SPEED switches operate. LH 30K winch freespools. MAIN WINCH LH FREESPOOL switch OK. Faulty 30K winch pneumatic manifold solenoid L19. MAIN WINCH RH FREESPOOL switch OK. M1089 control panel wiring harness OK. Faulty jumper wire.
POSSIBLE PROBLEMS
Faulty M1089 30K winch control wiring harness. Faulty 30K winch pneumatic manifold solenoid L17. Faulty wrecker air system.






12.
Is continuity present from terminal block TBC to wire C?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, M1089 winch control wiring harness is faulty. If continuity is present, 30K winch pneumatic solenoid L17 is faulty.



CONTINUITY TEST


- (1) Cut wire C from conductor splice at pneumatic solenoid L17.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to terminal block TBC.
- (4) Connect negative (-) probe of multimeter to wire C and note reading on multimeter.
- (5) If continuity is not present, replace M1089 winch control wiring harness (para 7-142).
- (6) If continuity is present, replace 30K winch pneumatic manifold solenoid L17 (para 17-29).
- (7) Install circuit breaker CB50 in PDP.
- (8) Install PDP cover (para 16-2).
- (9) Install wrecker control panel top cover (para 14-4).
- (10) Close LH and RH catwalks.



4BEP012B

e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. MAIN WINCH LH and RH SPEED switches operate. RH 30K winch freespools. MAIN WINCH RH FREESPOOL switch OK. Faulty 30K winch pneumatic manifold solenoid L17. MAIN WINCH LH FREESPOOL switch OK. M1089 control panel wiring harness OK. Faulty jumper wire.
POSSIBLE PROBLEMS
Faulty M1089 30K winch control wiring harness. Faulty 30K winch pneumatic manifold solenoid L19. Faulty wrecker air system.







TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, M1089 winch control wiring harness is faulty.



CONTINUITY TEST

- (1) Remove circuit breaker CB50 from PDP.
- (2) Remove electrical tape from conductor splice at pneumatic solenoid L19.
- (3) Cut wire 19 from conductor splice at pneumatic solenoid L19.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to terminal block TB19.
- (6) Connect negative (-) probe of multimeter to wire 19 and note reading on multimeter.
- (7) If continuity is not present, replace M1089 winch control wiring harness (para 7-142).



4BEP013B


e140. MAIN WINCH LH OR RH FREESPOOL SWITCH DOES NOT OPERATE FROM WRECKER CONTROL PANEL (CONT)

KNOWN INFO
LH and RH winches operate from wrecker control panel. Circuit breaker CB50 OK. STATION SELECTOR switch to WRECKER CONTROL PANEL. MODE SELECTOR SWITCH to NORMAL. MAIN WINCH LH and RH SPEED switches operate. RH 30K winch freespools. MAIN WINCH RH FREESPOOL switch OK. Faulty 30K winch pneumatic manifold solenoid L17. MAIN WINCH LH FREESPOOL switch OK. M1089 control panel wiring harness OK. Faulty jumper wire.
POSSIBLE PROBLEMS
Faulty M1089 30K winch control wiring harness. Faulty 30K winch pneumatic manifold solenoid L19. Faulty wrecker air system.

14.





Is continuity present from terminal block TBC to wire C?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, M1089 winch control wiring harness is faulty. If continuity is present, 30K winch pneumatic solenoid L19 is faulty.



CONTINUITY TEST

- (1) Cut wire C from conductor splice at pneumatic solenoid L19.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to terminal block TBC.
- (4) Connect negative (-) probe of multimeter to wire C and note reading on multimeter.
- (5) If continuity is not present, replace M1089 winch control wiring harness (para 7-142).
- (6) If continuity is present, replace 30K winch pneumatic manifold solenoid L19 (para 17-29).
- (7) Install circuit breaker CB50 in PDP.
- (8) Install PDP cover (para 16-2).
- (9) Install wrecker control panel top cover (para 14-4).
- (10) Close LH and RH catwalks.



4BEP012B

e141. ONE WRECKER FUNCTION DOES NOT OPERATE FROM WRECKER REMOTE CONTROL

INITIAL SETUP

Equipment Conditions

Top control panel cover removed
(para 17-20).

Personnel Required

(2)

Tools and Special Tools


Tool Kit, Genl Mech (Item 46, Appendix C)
Multimeter, Digital (Item 22, Appendix C)
STE/ICE-R (Item 41, Appendix C)

Materials/Parts

Wire, Electrical, 50 ft (Item 67, Appendix D)

References

TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Connect wrecker remote control cable to RH remote control bulkhead connector (TM 9-2320-366-10-1).
- (2) Set multimeter to vdc.
- (3) Connect positive (+) probe of multimeter to terminal listed in Table 2-13. Actuator Voltage Test.
- (4) Connect negative (-) probe of multimeter on ground.
- (5) Position master power switch to on (TM 9-2320-366-10-1).
- (6) Position remote control box switch to position listed in Table 2-13. Actuator Voltage Test and note reading on multimeter.
- (7) If 24 vdc is not present, go to step 3 of this fault.
- (8) Position master power switch to off (TM 9-2320-366-10-1).
- (9) Disconnect remote control cable from RH remote control bulkhead connector (TM 9-2320-366-10-1).







TABLE 2-13. ACTUATOR VOLTAGE TEST


TB No.	ACTUATOR NAME	Remote Control Box Switch Position
2	Underlift fold up	UP
3	Stinger in	IN
4	Underlift up	UP
6	Main winch LH in	IN
8	Main winch RH in	IN
11	Main winch RH out	OUT
12	Main winch speed RH high	HIGH
13	Main winch LH out	OUT
14	Main winch speed LH high	HIGH
15	Underlift down	DOWN
16	Stinger out	OUT
17	Underlift fold down	DOWN



REMOTE CONTROL UNDERLIFT FOLD UP SWITCH

42EN101A

¶141. ONE WRECKER FUNCTION DOES NOT OPERATE FROM WRECKER REMOTE CONTROL (CONT)



- CONTINUITY TEST**
- (1) Set multimeter to ohms.
 - (2) Connect positive (+) probe of multimeter to terminal listed in Table 2-14. Actuator Solenoid Resistance Test.
 - (3) Connect negative (-) probe of multimeter on terminal block TB-C and note reading on multimeter.
 - (4) If resistance is less or greater than value listed in Table 2-14. Actuator Solenoid Resistance Test, notify DS Maintenance.
 - (5) Install wrecker control panel top cover (para 17-20).







TABLE 2-14. ACTUATOR SOLENOID RESISTANCE TEST

Function/Solenoid	Terminal Board (+) Position	Solenoid Resistance in Ohms
Underlift fold up - L18	2	81-101
Stinger in - L13	3	81-101
Underlift up - L14	4	81-101
Main winch LH in - L6	6	81-101
Main winch RH in - L1	8	81-101
Main winch RH out - L2	11	81-101
Main winch speed RH high	12	35-45
Main winch LH out - L5	13	81-101
Main winch speed LH high	14	35-45
Underlift down - L11	15	81-101
Stinger out - L16	16	81-101
Underlift fold down - L15	17	81-101

¶141. ONE WRECKER FUNCTION DOES NOT OPERATE FROM WRECKER REMOTE CONTROL (CONT)



- CONTINUITY TEST**
- (1) Set multimeter to ohms.
 - (2) Connect positive (+) probe of multimeter to pin listed in Table 2-15. Remote Control Box Continuity Test.
 - (3) Connect negative (-) probe of multimeter to pin listed in Table 2-15. Remote Control Box Continuity Test.
 - (4) Position remote control box switch to position listed in Table 2-15. Remote Control Box Continuity Test and note reading on multimeter.
 - (5) If continuity is not present, go to step 4 of this fault.
 - (6) If continuity is present, repair wire (para 2-45) or replace M1089 remote control wiring harness (para 7-117).





TABLE 2-15. REMOTE CONTROL BOX CONTINUITY TEST

Function	Remote Control Box Position	P2 Pin Positive (+)	P2 Pin Negative (-)
Underlift fold up	UP	c	e
Stinger in	IN	c	f
Underlift up	UP	c	g
Main winch LH in	IN	c	d
Main winch RH in	IN	c	b
Main winch RH out	OUT	c	Y
Main winch speed RH high	HIGH	c	X
Main winch LH out	OUT	c	W
Main winch speed LH high	HIGH	c	V
Underlift down	DOWN	c	U
Stinger out	OUT	c	T
Underlift fold down	DOWN	c	S
Emergency stop	KILL	a	Z

42EN103A

¶141. ONE WRECKER FUNCTION DOES NOT OPERATE FROM WRECKER REMOTE CONTROL (CONT)


KNOWN INFO
Circuit breaker CB50 OK. Mode selector switch in NORMAL position. Hydraulic functions OK. Station selector switch in remote control position. All functions from wrecker control panel OK. Actuator solenoids OK.
POSSIBLE PROBLEMS
Faulty remote control box. Faulty remote control wiring harness.



TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, wire is faulty.



- CONTINUITY TEST**
- (1) Open cover on remote control box.
 - (2) Remove four screws, washers, and panel from remote control box.
 - (3) Set multimeter to ohms.
 - (4) Connect positive (+) probe of multimeter to pin listed in Table 2-16. Remote Control Box Switch Continuity Test.
 - (5) Connect negative (-) probe of multimeter to pin listed in Table 2-16. Remote Control Box Switch Continuity Test.
 - (6) Position remote control box switch to position listed in Table 2-16. Remote Control Box Switch Continuity Test and note reading on multimeter.
 - (7) If continuity is not present, repair wire (para 2-45) or replace remote control box switch (para 7-35).
 - (8) Install panel on remote control box with four washers and screws.




42EP1041

TABLE 2-16. REMOTE CONTROL BOX SWITCH CONTINUITY TEST

Function	REF DES	Remote Control Box Position and Switch Number	Switch Pin Positive (+)	Switch Pin Negative (-)
Underlift fold up	S15	UP	7	2
Stinger in	S14	IN	7	3
Underlift up	S13	UP	7	4
Main winch LH in	S10	IN	7	6
Main winch RH in	S8	IN	7	8
Main winch RH out	S8	OUT	7	11
Main winch speed RH high	S9	HIGH	7	12
Main winch LH out	S10	OUT	7	13
Main winch speed LH high	S11	HIGH	7	14
Underlift down	S13	DOWN	7	15
Stinger out	S14	OUT	7	16
Underlift fold down	S15	DOWN	7	17
Emergency stop	S7	KILL	9	10





e141. ONE WRECKER FUNCTION DOES NOT OPERATE FROM WRECKER REMOTE CONTROL (CONT)



CONTINUITY TEST	
(1)	Set multimeter to ohms.
(2)	Connect positive (+) probe of multimeter to terminal block position listed in Table 2-17. Continuity Table.
(3)	Connect negative (-) probe of multimeter to J1/J2 pin listed in Table 2-17. Continuity Table and note reading on multimeter.
(4)	If continuity is not present, repair wire (para 2-45) or replace remote control wiring harness (para 7-117).
(5)	If continuity is present, perform Wrecker Pneumatic Troubleshooting (aa1. One Wrecker Function Does Not Operate From Wrecker Remote Control).
(6)	Install wrecker control panel top cover (para 17-20).

TABLE 2-17. REMOTE CONTROL BOX SWITCH CONTINUITY TEST


Function	TB Position	J1/J2 Pin
Underlift fold up	2	g
Stinger in	3	f
Underlift up	4	e
Main winch LH in	6	d
Main winch RH in	8	b
Main winch RH out	11	Y
Main winch speed RH high	12	X
Main winch LH out	13	W
Main winch speed LH high	14	V
Underlift down	15	U
Stinger out	16	T
Underlift fold down	17	S
Emergency shutdown run	9	a
Emergency shutdown kill	10	Z
Remote control box power	7	c



J1/J2

42EP1051

e142. M1090/M1094 TAILGATE RELEASE DOES NOT OPERATE	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Materials/Parts Wire, Elec, 50ft (Item 71, Appendix D)
Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C) Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)	Personnel Required (2)
	References TM 9-4910-571-12&P



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

Dump body weighs approximately 3,034 lbs (1,376 kgs). Attach a suitable lifting device prior to lifting. Failure to comply may result in injury to personnel or damage to equipment.




Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

VOLTAGE TEST


- (1) Raise dump bed (TM 9-2320-366-10-1).
- (2) Loosen screw on connector L7.
- (3) Disconnect connector L7 from tailgate release solenoid.
- (4) Set multimeter to volts DC.
- (5) Connect positive (+) probe of multimeter to connector L7 socket 1.
- (6) Connect negative (-) probe of multimeter to ground.
- (7) Press and hold tailgate release switch (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If 24 VDC is not present, go to step 3 of this fault.



L7

4BEP201B

e142. M1090/1094 TAILGATE RELEASE DOES NOT OPERATE (CONT)




CAUTION

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.


CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector L7 socket 2.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, go to step 7 of this fault.
- (5) If continuity is present, replace tailgate release solenoid (para 23-10).
- (6) Connect connector L7 to tailgate release solenoid.
- (7) Tighten screw in connector L7.



4BEP202B

e142. M1090/M1094 TAILGATE RELEASE DOES NOT OPERATE (CONT)



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

VOLTAGE TEST

- (1) Remove six screws from auxiliary panel.
- (2) Lift auxiliary panel outward to gain access.
- (3) Disconnect connector P910 from tailgate release switch.
- (4) Set multimeter to volts DC.
- (5) Connect positive (+) probe of multimeter to connector P910 socket 3.
- (6) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (7) If 24 VDC is not present, repair wire 2006 from connector P910 socket 3 to connector P912 socket 1 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).



4BEP203B

e142. M1090/M1094 TAILGATE RELEASE DOES NOT OPERATE (CONT)


KNOWN INFO
Dump bed raises and lowers. Pneumatic system OK. Tailgate release solenoid OK.
POSSIBLE PROBLEMS
Faulty auxiliary panel cable assembly. Faulty tailgate release switch. Faulty dump power cable assembly. Faulty dump cable assembly.

4.

CAUTION
Read CAUTION on following page.

Is continuity present from tailgate release switch terminal 1 to terminal 3?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, tailgate release switch is faulty.





CAUTION

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.


CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to terminal 1 of tailgate release switch.
- (3) Connect negative (-) probe of multimeter to terminal 3 of tailgate release switch.
- (4) Push and hold tailgate release switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If continuity is not present, replace tailgate release switch (para 7-18).



4BEP204B

e142. M1090/M1094 TAILGATE RELEASE DOES NOT OPERATE (CONT)



CAUTION




Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Remove kick panel (para 16-3).
- (2) Disconnect connector P108 from connector J108.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector P910 socket 1.
- (5) Connect negative (-) probe of multimeter to connector J108 pin 8 and note reading on multimeter.
- (6) If continuity is not present, repair wire 2045 from connector P910 socket 1 to connector J108 pin 8 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (7) Connect connector P108 to connector J108.
- (8) Install kick panel (para 16-3).
- (9) Connect connector P910 to tailgate release switch.
- (10) Position auxiliary panel on auxiliary panel housing with six screws.
- (11) Tighten six screws to 24 lb-in. (3N.m).



4BEP205B

e142. M1090/M1094 TAILGATE RELEASE DOES NOT OPERATE (CONT)



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


VOLTAGE TEST

- (1) Disconnect connector P172 from connector J172.
- (2) Set multimeter to volts DC.
- (3) Connect positive (+) probe of multimeter to connector P172 socket C.
- (4) Connect negative (-) probe of multimeter to ground.
- (5) Press and hold tailgate release switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (6) If 24 VDC is not present, repair wire 2045 from connector P172 socket C to connector P108 socket 8 (para 2-45) or replace dump power cable assembly (para 7-125).
- (7) If 24 VDC is present, repair wire 2045 from connector J172 pin C to connector L7 socket 1 (para 2-45) or replace dump cable assembly (para 2-124).
- (8) Connect connector P172 to connector J172.



4BEP206B

e142. M1090/M1094 TAILGATE RELEASE DOES NOT OPERATE (CONT)




CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.



- CONTINUITY TEST**
- (1) Set multimeter to ohms.
 - (2) Connect positive (+) probe of multimeter to connector P172 socket D.
 - (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
 - (4) If continuity is not present, repair wire 3079 from connector P172 socket D to terminal lug TL78 (para 2-45) or replace dump power cable assembly (para 7-125).
 - (5) If continuity is present, repair wire 3079 from connector J172 pin D to connector L7 socket 2 (para 2-45) or replace dump cable assembly (para 7-124).
 - (6) Connect connector P172 to connector J172.
 - (7) Start engine (TM 9-2320-366-10-1).
 - (8) Engage PTO (TM 9-2320-366-10-1).
 - (9) Lower dump body (TM 9-2320-366-10-1).
 - (10) Disengage PTO (TM 9-2320-366-10-1).
 - (11) Shut down engine (TM 9-2320-366-10-1).




4BEP207B

e143. M1090/M1094 DUMP BODY DOES NOT RAISE	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C) Goggles, Industrial (Item 15, Appendix C) Sling, Cargo (Item 31, Appendix C) Lifting Bracket, Dump Body (2) (Item E-24, Appendix E) Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C) Socket Set, Socket Wrench (Item 34, Appendix C)
Personnel Required (2)	
References TM 9-4910-571-12&P	Materials/Parts Wire, Elec, 50 ft (Item 71, Appendix D)

NOTE

Perform Electrical System Troubleshooting e1. Circuit Breaker Does Not Operate on circuit breaker CB50 prior to beginning this task.



WARNING

Wear appropriate eye protection when working under vehicle due to possibility of falling debris. Failure to comply may result in injury to personnel.






Dump body weighs approximately 3,030 lbs (1,376 kgs). Attach a suitable lifting device prior to lifting. Failure to comply may result in injury to personnel or damage to equipment.

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

- VOLTAGE TEST**
- (1) Remove safety pins from two locking pins.
 - (2) Remove two lock pins from dump body.
 - (3) Install two dump body lifting brackets in slots in dump body.
 - (4) Attach cargo sling to two dump body lifting brackets.
 - (5) Lift dump body.
 - (6) Raise two maintenance legs on frame.
 - (7) Lower dump body on maintenance legs.
 - (8) Loosen screw on connector L8.
 - (9) Disconnect connector L8 from solenoid valve.
 - (10) Set multimeter to volts DC.
 - (11) Connect positive (+) probe of multimeter to connector L8 socket 2.
 - (12) Connect negative (-) probe of multimeter to ground.
 - (13) Press and hold DUMP BED UP/DOWN switch to UP (TM 9-2320-366-10-1) and note reading on multimeter.
 - (14) If 24 VDC is not present, go to step 5, of this fault.
 - (15) Release DUMP BED UP/DOWN switch (TM 9-2320-366-10-1).



L8 4BEP301B

e143. M1090/M1094 DUMP BODY DOES NOT RAISE (CONT)



CAUTION

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE


Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector L8 socket 1.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, go to step 4 of this fault.


CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to terminal 1 on up solenoid.
- (3) Connect negative (-) probe of multimeter to terminal 2 on up solenoid and note reading on multimeter.
- (4) If continuity is not present, replace solenoid valve (para 7-142).
- (5) If continuity is present, notify DS Maintenance to perform Dump Body Hydraulic System troubleshooting task k1. Dump Body Does Not Raise.
- (6) Connect connector L8 to solenoid valve.
- (7) Tighten screw in connector L8.



4BEP302B

e143. M1090/M1094 DUMP BODY DOES NOT RAISE (CONT)



CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST


- (1) Disconnect connector P172 from connector J172.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector P172 socket H.
- (4) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (5) If continuity is not present, repair wire 3084 from connector P172 socket H to terminal lug TL77 (para 2-45) or replace M1090/M1094 dump power cable assembly (para 7-125).
- (6) If continuity is present, repair wire 3084 from connector J172 pin H to connector L8 socket 2 (para 2-45) or replace M1090/M1094 dump cable assembly (para 7-124).
- (7) Connect connector P172 to connector J172.
- (8) Connect connector L8 to solenoid valve.
- (9) Tighten screw in connector L8.
- (10) Lift dump body.
- (11) Place maintenance legs in stowed position.
- (12) Lower dump body.
- (13) Remove cargo sling from two dump body lifting brackets.
- (14) Remove two dump body lifting brackets from dump body.
- (15) Position two locking pins in dump body.
- (16) Install safety pin in two locking pins.



4BEP304B

e143. M1090/M1094 DUMP BODY DOES NOT RAISE (CONT)

KNOWN INFO
Hydraulic oil level OK. PTO OK. Circuit breaker CB50 OK.
POSSIBLE PROBLEMS
Faulty DUMP BED UP/DOWN switch. Faulty auxiliary panel cable assembly. Faulty M1090/M1094 dump cable assembly. Faulty M1090/M1094 dump power cable assembly. Faulty dashboard cable assembly.



TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
If 24 VDC is not present, wire 2006 is faulty.

WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.


CAUTION

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

VOLTAGE TEST
(1) Connect connector L8 to solenoid valve.
(2) Tighten screw in connector L8.
(3) Remove six screws from auxiliary panel.
(4) Lift auxiliary panel outward to gain access.
(5) Remove PDP cover from PDP (para 16-2).
(6) Remove circuit breaker CB50 from PDP.
(7) Disconnect connector P911 from DUMP BED UP/DOWN switch connector.
(8) Set multimeter to volts DC.
(9) Connect positive (+) probe of multimeter to P911 socket 3.
(10) Connect negative (-) probe of multimeter to ground.
(11) Install circuit breaker CB50 in PDP and note reading on multimeter.
(12) If 24 VDC is not present, go to step 9 of this fault.
(13) Remove circuit breaker CB50 from PDP.



4BEP305B

e143. M1090/M1094 DUMP BODY DOES NOT RAISE (CONT)


KNOWN INFO
Hydraulic oil level OK. PTO OK. Circuit breaker CB50 OK. Dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty DUMP BED UP/DOWN switch. Faulty auxiliary panel cable assembly. Faulty M1090/M1094 dump cable assembly. Faulty M1090/M1094 dump power cable assembly.

6.

CAUTION
Read CAUTION on following page.

Is continuity present from terminal 3 to terminal 7 on DUMP BED UP/DOWN switch?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, DUMP BED UP/DOWN switch is faulty.



CAUTION




Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to DUMP BED UP/DOWN switch terminal 3.
- (3) Connect negative (-) probe of multimeter to DUMP BED UP/DOWN switch terminal 7.
- (4) Press and hold DUMP BED UP/DOWN switch to UP and note reading on multimeter.
- (5) If continuity is not present, replace DUMP BED UP/DOWN switch (para 7-18).
- (6) Release DUMP BED UP/DOWN switch.
- (7) Install circuit breaker CB50 in PDP.



46ep306b

e143. M1090/M1094 DUMP BODY DOES NOT RAISE (CONT)


KNOWN INFO
Hydraulic oil level OK. PTO OK. Circuit breaker CB50 OK. Dashboard cable assembly OK. DUMP BED UP/DOWN switch OK.
POSSIBLE PROBLEMS
Faulty auxiliary panel cable assembly. Faulty M1090/M1094 dump cable assembly. Faulty M1090/M1094 dump power cable assembly.

7.

CAUTION
Read CAUTION on following page.

Is continuity present from connector J108 pin 6 to connector P911 socket 7?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, wire 2043 in auxiliary panel cable assembly is faulty.






CAUTION

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE


Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

- CONTINUITY TEST**
- (1) Disconnect batteries (para 7-57).
 - (2) Remove kick panel (para 16-3).
 - (3) Disconnect connector P108 from connector J108.
 - (4) Set multimeter to ohms.
 - (5) Connect positive (+) probe of multimeter to connector J108 pin 6.
 - (6) Connect negative (-) probe of multimeter to connector P911 socket 7 and note reading on multimeter.
 - (7) If continuity is not present, repair wire 2043 from connector J108 pin 6 to connector P911 socket 7 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
 - (8) Connect connector P911 to DUMP BED UP/DOWN switch.
 - (9) Position auxiliary panel on auxiliary panel housing with six screws.
 - (10) Tighten six screws to 24 lb-in. (3N.m).



4bep307b

e143. M1090/M1094 DUMP BODY DOES NOT RAISE (CONT)



CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Disconnect connector P172 from connector J172.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector P172 socket F.
- (4) Connect negative (-) probe of multimeter to connector P108 socket 6 and note reading on multimeter.
- (5) If continuity is not present, repair wire 2043 from connector P172 socket F to connector P108 socket 6 (para 2-45) or replace M1090/M1094 dump power cable assembly (para 7-125).
- (6) If continuity is present, repair wire 2043 from connector J172 Pin F to connector L8 socket 1 (para 2-45) or replace M1090/M1094 dump cable assembly (para 7-124).
- (7) Connect connector P172 to connector J172.
- (8) Connect connector P108 to connector J108.
- (9) Install kick panel (para 16-3).
- (10) Connect batteries (para 7-57).
- (11) Lift dump body.
- (12) Place maintenance legs in stowed position.
- (13) Lower dump body.
- (14) Remove cargo sling from dump body lifting brackets.
- (15) Remove two dump body lifting brackets from dump body.
- (16) Position two locking pins in dump body.
- (17) Install safety pin in two locking pins.



4BEP308B

e143. M1090/M1094 DUMP BODY DOES NOT RAISE (CONT)



CAUTION





Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Install circuit breaker CB 50 in PDP.
- (2) Install PDP cover on PDP (para 16-2).
- (3) Disconnect batteries (para 7-57).
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to connector P911 socket 3.
- (6) Connect negative (-) probe of multimeter to connector P909 socket 5 and note reading on multimeter.
- (7) If continuity is not present, repair wire 2006 from connector P911 socket 3 to connector P909 socket 5 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (8) Connect connector P911 to DUMP BED UP/DOWN switch.



4BEP309B


e143. M1090/M1094 DUMP BODY DOES NOT RAISE (CONT)

KNOWN INFO
Hydraulic oil level OK. PTO OK. Circuit breaker CB50 OK.
POSSIBLE PROBLEMS
Faulty auxiliary panel cable assembly. Faulty dashboard cable assembly.

10. **CAUTION**
Read CAUTION on following page.

Is continuity present from connector P909 socket 5 to connector J912 socket 1?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, wire 2006 in auxiliary panel cable assembly is faulty. If continuity is present, wire 2006 in dashboard cable assembly is faulty.



CAUTION





Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Remove personnel heater assembly for access (para 18-9).
- (2) Disconnect connector J912 from P912.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector P909 socket 5.
- (5) Connect negative (-) probe of multimeter to connector J912 socket 1 and note reading on multimeter.
- (6) If continuity is not present, repair wire 2006 from connector P909 socket 5 to connector J912 socket 1 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (7) If continuity is present, repair wire 2006 from connector P912 Pin 1 to circuit breaker CB50 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (8) Connect connector J912 to connector P912.
- (9) Install personnel heater (para 18-9).
- (10) Position auxiliary panel on auxiliary panel housing with six screws.
- (11) Tighten six screws to 24 lb-in (3N.m).
- (12) Connect batteries (para 7-57).
- (13) Lift dump body.
- (14) Place maintenance legs in stowed position.
- (15) Lower dump body.
- (16) Remove cargo sling from dump body lifting brackets.
- (17) Remove two dump body lifting brackets from dump body.
- (18) Position two locking pins in dump body.
- (19) Install safety pins in two locking pins.




4BEP310B

e144. M1090/M1094 DUMP BODY DOES NOT LOWER	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C) Goggles, Industrial (Item 15, Appendix C) Sling, Cargo (Item 31, Appendix C) Lifting Bracket, Dump Body (2) (Item E-24, Appendix E) Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C) Socket Set, Socket Wrench (Item 34, Appendix C)
Personnel Required (2)	
References TM 9-4910-571-12&P	Materials/Parts Wire, Elec, 50 ft (Item 71, Appendix D)

NOTE

Perform Electrical System Troubleshooting e1. Circuit Breaker Does Not Operate on circuit breaker CB50 prior to beginning this task.

KNOWN INFO
Hydraulic oil level OK. PTO OK. Circuit breaker CB50 OK.
POSSIBLE PROBLEMS
Faulty dump body hydraulic system. Faulty solenoid valve. Faulty DUMP BED UP/DOWN switch. Faulty auxiliary panel cable assembly. Faulty M1090/M1094 dump cable assembly. Faulty M1090/M1094 dump power cable assembly. Faulty dashboard cable assembly.



WARNING

Wear appropriate eye protection when working under vehicle due to possibility of falling debris. Failure to comply may result in injury to personnel.






Dump body weighs approximately 3,030 lbs (1,376 kgs). Attach a suitable lifting device prior to lifting. Failure to comply may result in injury to personnel or damage to equipment.

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

- VOLTAGE TEST**
- (1) Remove safety pins from two locking pins.
 - (2) Remove two lock pins from dump body.
 - (3) Install two dump body lifting brackets in slots in dump body.
 - (4) Attach cargo sling to two dump body lifting brackets.
 - (5) Lift dump body.
 - (6) Raise two maintenance legs on frame.
 - (7) Lower dump body on maintenance legs.
 - (8) Loosen screw on connector L9.
 - (9) Disconnect connector L9 from solenoid valve.
 - (10) Set multimeter to volts DC.
 - (11) Connect positive (+) probe of multimeter to connector L9 socket 1.
 - (12) Connect negative (-) probe of multimeter to ground.
 - (13) Press and hold DUMP BED UP/DOWN switch to DOWN (TM 9-2320-366-10-1) and note reading on multimeter.
 - (14) If 24 VDC is not present, go to step 5, of this fault.
 - (15) Release DUMP BED UP/DOWN switch (TM 9-2320-366-10-1).



4BEP401B

e144. M1090/M1094 DUMP BODY DOES NOT LOWER (CONT)



CAUTION

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE


Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector L9 socket 2.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, go to step 4 of this fault.


CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to terminal 1 on down solenoid.
- (3) Connect negative (-) probe of multimeter to terminal 2 on down solenoid and note reading on multimeter.
- (4) If continuity is not present, replace solenoid valve (para 7-142).
- (5) If continuity is present, notify DS Maintenance to perform Dump Body Hydraulic System troubleshooting task k2. Dump Body Does Not Lower.
- (6) Connect connector L9 to solenoid valve.
- (7) Tighten screw in connector L9.



4BEP402B

e144. M1090/M1094 DUMP BODY DOES NOT LOWER (CONT)



CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Disconnect connector P172 from connector J172.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector P172 socket H.
- (4) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (5) If continuity is not present, repair wire 3084 from connector P172 socket H to terminal lug TL77 (para 2-45) or replace M1090/M1094 dump power cable assembly (para 7-125).
- (6) If continuity is present, repair wire 3084 from connector J172 pin H to connector L9 socket 2 (para 2-45) or replace M1090/M1094 dump cable assembly (para 7-124).
- (7) Connect connector P172 to connector J172.
- (8) Connect connector L9 to solenoid valve.
- (9) Tighten screw in connector L9.
- (10) Lift dump body.
- (11) Place maintenance legs in stowed position.
- (12) Lower dump body.
- (13) Remove cargo sling from two dump body lifting brackets.
- (14) Remove two dump body lifting brackets from dump body.
- (15) Position two locking pins in dump body.
- (16) Install safety pin in two locking pins.



4BEP404B

e144. M1090/M1094 DUMP BODY DOES NOT LOWER (CONT)


KNOWN INFO
Hydraulic oil level OK. PTO OK. Circuit breaker CB50 OK.
POSSIBLE PROBLEMS
Faulty DUMP BED UP/DOWN switch. Faulty auxiliary panel cable assembly. Faulty M1090/M1094 dump cable assembly. Faulty M1090/M1094 dump power cable assembly. Faulty dashboard cable assembly.

5.

WARNING
CAUTION
Read WARNING and CAUTION on following page.

Is 24 VDC present at connector P911 socket 3?

TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
If 24 VDC is not present, wire 2006 is faulty.



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

VOLTAGE TEST

- (1) Connect connector L9 to solenoid valve.
- (2) Tighten screw in connector L9.
- (3) Remove six screws from auxiliary panel.
- (4) Lift auxiliary panel outward to gain access.
- (5) Remove PDP cover from PDP (para 16-2).
- (6) Remove circuit breaker CB50 from PDP.
- (7) Disconnect connector P911 from DUMP BED UP/DOWN switch connector.
- (8) Set multimeter to volts DC.
- (9) Connect positive (+) probe of multimeter to P911 socket 3.
- (10) Connect negative (-) probe of multimeter to ground.
- (11) Install circuit breaker CB50 in PDP and note reading on multimeter.
- (12) If 24 VDC is not present, go to step 9 of this fault.
- (13) Remove circuit breaker CB50 from PDP.



4bep405b

e144. M1090/M1094 DUMP BODY DOES NOT LOWER (CONT)


KNOWN INFO
Hydraulic oil level OK. PTO OK. Circuit breaker CB50 OK. Dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty DUMP BED UP/DOWN switch. Faulty auxiliary panel cable assembly. Faulty M1090/M1094 dump cable assembly. Faulty M1090/M1094 dump power cable assembly.

6.

CAUTION
Read CAUTION on following page.

Is continuity present from terminal 3 to terminal 1 on DUMP BED UP/DOWN switch?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, DUMP BED UP/DOWN switch is faulty.



CAUTION




Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to DUMP BED UP/DOWN switch terminal 3.
- (3) Connect negative (-) probe of multimeter to DUMP BED UP/DOWN switch terminal 1.
- (4) Press and hold DUMP BED UP/DOWN switch to DOWN and note reading on multimeter.
- (5) If continuity is not present, replace DUMP BED UP/DOWN switch (para 7-18).
- (6) Release DUMP BED UP/DOWN switch.
- (7) Install circuit breaker CB50 in PDP.



46ep406b

e144. M1090/M1094 DUMP BODY DOES NOT LOWER (CONT)


KNOWN INFO
Hydraulic oil level OK. PTO OK. Circuit breaker CB50 OK. Dashboard cable assembly OK. DUMP BED UP/DOWN switch OK.
POSSIBLE PROBLEMS
Faulty auxiliary panel cable assembly. Faulty M1090/M1094 dump cable assembly. Faulty M1090/M1094 dump power cable assembly.

7.

CAUTION
Read CAUTION on following page.

Is continuity present from connector J108 pin 7 to connector P911 socket 1?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, wire 2044 in auxiliary panel cable assembly is faulty.



CAUTION




Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Disconnect batteries (para 7-57).
- (2) Remove kick panel (para 16-3).
- (3) Disconnect connector P108 from connector J108.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to connector J108 pin 7.
- (6) Connect negative (-) probe of multimeter to connector P911 socket 1 and note reading on multimeter.
- (7) If continuity is not present, repair wire 2044 from connector J108 pin 7 to connector P911 socket 1 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (8) Connect connector P911 to DUMP BED UP/DOWN switch.
- (9) Position auxiliary panel on auxiliary panel housing with six screws.
- (10) Tighten six screws to 24 lb-in. (3N.m).



4bep407b

e144. M1090/M1094 DUMP BODY DOES NOT LOWER (CONT)






CAUTION

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

- CONTINUITY TEST**
- (1) Disconnect connector P172 from connector J172.
 - (2) Set multimeter to ohms.
 - (3) Connect positive (+) probe of multimeter to connector P172 socket G.
 - (4) Connect negative (-) probe of multimeter to connector P108 socket 7 and note reading on multimeter.
 - (5) If continuity is not present, repair wire 2044 from connector P172 socket G to connector P108 socket 7 (para 2-45) or replace M1090/M1094 dump power cable assembly (para 7-125).
 - (6) If continuity is present, repair wire 2044 from connector J172 pin G to connector L9 socket 1 (para 2-45) or replace M1090/M1094 dump cable assembly (para 7-124).
 - (7) Connect connector P172 to connector J172.
 - (8) Connect connector P108 to connector J108.
 - (9) Install kick panel (para 16-3).
 - (10) Connect batteries (para 7-57).
 - (11) Lift dump body.
 - (12) Place maintenance legs in stowed position.
 - (13) Lower dump body.
 - (14) Remove cargo sling from dump body lifting brackets.
 - (15) Remove two dump body lifting brackets from dump body.
 - (16) Position two locking pins in dump body.
 - (17) Install safety pin in two locking pins.



4kep408b


e144. M1090/M1094 DUMP BODY DOES NOT LOWER (CONT)

KNOWN INFO
Hydraulic oil level OK. PTO OK. Circuit breaker CB50 OK.
POSSIBLE PROBLEMS
Faulty auxiliary panel cable assembly. Faulty dashboard cable assembly.

9. **CAUTION**
Read CAUTION on following page.

Is continuity present from connector P911 socket 3 to connector P909 socket 5?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, wire 2006 in auxiliary panel cable assembly is faulty.



CAUTION





Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Install circuit breaker CB50 in PDP.
- (2) Install PDP cover on PDP (para 16-2).
- (3) Disconnect batteries (para 7-57).
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to connector P911 socket 3.
- (6) Connect negative (-) probe of multimeter to connector P909 socket 5 and note reading on multimeter.
- (7) If continuity is not present, repair wire 2006 from connector P911 socket 3 to (para 2-45) connector P909 socket 5 or replace auxiliary panel cable assembly (para 7-58).
- (8) Connect connector P911 to DUMP BED UP/DOWN switch.



4BEP409B

e144. M1090/M1094 DUMP BODY DOES NOT LOWER (CONT)



CAUTION





Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Remove personnel heater assembly for access (para 18-9).
- (2) Disconnect connector J912 from P912.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector P909 socket 5.
- (5) Connect negative (-) probe of multimeter to connector J912 socket 1 and note reading on multimeter.
- (6) If continuity is not present, repair wire 2006 from connector P909 socket 5 to connector J912 socket 1 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (7) If continuity is present, repair wire 2006 from connector P912 pin 1 to circuit breaker CB50 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (8) Connect connector J912 to connector P912.
- (9) Install personnel heater (para 18-9).
- (10) Position auxiliary panel on auxiliary panel housing with six screws.
- (11) Tighten six screws to 24 lb-in (3N.m).
- (12) Connect batteries (para 7-57).
- (13) Lift dump body.
- (14) Place maintenance legs in stowed position.
- (15) Lower dump body.
- (16) Remove cargo sling from dump body lifting brackets.
- (17) Remove two dump body lifting brackets from from dump body.
- (18) Position two locking pins in dump body.
- (19) Install safety pins in two locking pins.



4BEP410B

e145. TRANSMISSION AUXILIARY OIL COOLER FAN(S) RUN CONSTANTLY	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Remove PDP cover (para 16-2).
- (2) Remove relay K15 from PDP.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to PDP, where relay K15 terminal 86 was removed.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1).
- (7) Position radiator fan off switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If 24 vdc is not present, repair wire 1806 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (9) Position master power switch to off (TM 9-2320-366-10-1).
- (10) Position radiator fan off switch to off (TM 9-2320-366-10-1).



RELAY K15 CAVITY


42EP5011

e145. TRANSMISSION AUXILIARY OIL COOLER FAN(S) RUN CONSTANTLY (CONT)

KNOWN INFO
Engine fan operates normally. Wire 1806 OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty relay K15.



2.
Is continuity present between relay K15 terminal 85 and a known good ground?

TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 3012 is faulty. If continuity is present, relay K15 is faulty.



CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to PDP, where relay K15 terminal 85 was removed.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3012 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (5) If continuity is present, replace relay K15 (para 7-9).
- (6) Install relay K15 in PDP.
- (7) Install PDP cover (para 16-2).




RELAY K15 CAVITY

42EP5021

e146. TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (ALL MODELS EXCEPT M1088/M1089)	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P



- 
- (1) Check if vehicle is equipped with PTO.
 - (2) If vehicle is not equipped with PTO, go to step 10 of this fault.

WARNING



Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Remove PDP cover (para 16-2).
- (2) Remove circuit breaker CB22 from PDP.
- (3) Disconnect connector J209 from transmission auxiliary oil cooler fan connector.
- (4) Set multimeter to volts dc.
- (5) Connect positive (+) probe of multimeter to connector J209-1.
- (6) Connect negative (-) probe of multimeter to ground.
- (7) Start engine (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If 24 vdc is not present, go to step 4 of this fault.
- (9) Shut down engine (TM 9-2320-366-10-1).


CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector J209-2.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, go to step 9 of this fault.
- (5) If continuity is present, replace transmission auxiliary oil cooler fan (para 8-19 or 8-21).
- (6) Connect connector J209 to transmission auxiliary oil cooler fan connector.
- (7) Install circuit breaker CB22 in PDP.
- (8) Install PDP cover (para 16-2).



42EP6011

e146. TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (ALL MODELS EXCEPT M1088/ M1089) (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Remove relay K15 from PDP.
- (2) Set multimeter to volts dc.
- (3) Connect positive (+) probe of multimeter to relay K15 socket 30.
- (4) Connect negative (-) probe of multimeter to ground.
- (5) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (6) If 24 vdc is not present, repair wire 1808 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (7) Position master power switch to off (TM 9-2320-366-10-1).
- (8) Install circuit breaker CB22 in PDP.




42EP6021

CONTINUITY TEST



- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to relay K15 pin 30.
- (3) Connect negative (-) probe of multimeter to relay K15 pin 87A and note reading on multimeter.
- (4) If continuity is not present, replace relay K15 (para 7-9).

e146. TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (ALL MODELS EXCEPT M1088/ M1089) (CONT)



CONTINUITY TEST


- (1) Remove personnel heater to gain access (para 18-9).
- (2) Disconnect connector P912 from connector J912.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to relay K15 socket 87A.
- (5) Connect negative (-) probe of multimeter to connector P912-15 and note reading on multimeter.
- (6) If continuity is not present, repair wire 1811 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (7) Install relay K15 in PDP.



42EP6031

ø146. TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (ALL MODELS EXCEPT M1088/ M1089) (CONT)

KNOWN INFO
Engine starts. Circuit breaker OK. Transmission auxiliary oil cooler fan OK. Relay K15 OK. Dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty auxiliary panel cable assembly. Faulty oil cooler fan cable assembly. Faulty PTO cable assembly.




TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 1811 in auxiliary panel cable assembly is faulty.



CONTINUITY TEST

- (1) Disconnect connector P210 from connector J210.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector J912-15.
- (4) Connect negative (-) probe of multimeter to connector J210-1 and note reading on multimeter.
- (5) If continuity is not present, repair wire 1811 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (6) Connect connector P210 to connector J210.
- (7) Connect connector P912 to connector J912.
- (8) Install personnel heater (para 18-9).




42EP6041

ø146. TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (ALL MODELS EXCEPT M1088/ M1089) (CONT)

KNOWN INFO
Engine starts. Circuit breaker OK. Transmission auxiliary oil cooler fan OK. Relay K15 OK. Dashboard cable assembly OK. Auxiliary panel cable assembly OK.
POSSIBLE PROBLEMS
Faulty oil cooler fan cable assembly. Faulty PTO cable assembly.

8.
Is continuity present from connector P209B-1 to connector J209-1?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 1811 in oil cooler fan cable assembly is faulty. If continuity is present, wire 1811 in PTO cable assembly is faulty.





KNOWN INFO
Engine starts. Circuit breaker OK. Transmission auxiliary oil cooler fan OK. Relay K15 OK. Dashboard cable assembly OK. Auxiliary panel cable assembly OK.
POSSIBLE PROBLEMS
Faulty oil cooler fan cable assembly. Faulty PTO cable assembly.

9.
Is continuity present from connector P209B-2 to connector J209-2?


TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 3013 in oil cooler fan cable assembly is faulty. If continuity is present, wire 3013 in PTO cable assembly is faulty.



- CONTINUITY TEST**
- (1) Disconnect connector P209B from connector J209B.
 - (2) Disconnect connector J209 from transmission auxiliary oil cooler fan connector.
 - (3) Set multimeter to ohms.
 - (4) Connect positive (+) probe of multimeter to connector P209B-1.
 - (5) Connect negative (-) probe of multimeter to connector J209-1 and note reading on multimeter.
 - (6) If continuity is not present, repair wire 1811 (para 2-45) or replace oil cooler fan cable assembly (para 7-136).
 - (7) If continuity is present, repair wire 1811 (para 2-45) or replace PTO cable assembly (para 7-127).
 - (8) Connect connector J209 to transmission auxiliary oil cooler fan connector.
 - (9) Connect connector P209B to connector J209B.




- CONTINUITY TEST**
- (1) Disconnect connector P209B from connector J209B.
 - (2) Disconnect connector J209 from transmission auxiliary fan connector.
 - (3) Set multimeter to ohms.
 - (4) Connect positive (+) probe of multimeter to connector P209B-2.
 - (5) Connect negative (-) probe of multimeter to connector J209-2 and note reading on multimeter.
 - (6) If continuity is not present, repair wire 3013 (para 2-45) or replace oil cooler fan cable assembly (para 7-136).
 - (7) If continuity is present, repair wire 3013 (para 2-45) or replace PTO cable assembly (para 7-127).
 - (8) Connect connector J209 to transmission auxiliary oil cooler fan connector.
 - (9) Connect connector P209B to connector J209B.



42EP6051

e146. TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (ALL MODELS EXCEPT M1088/ M1089) (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Remove PDP cover (para 16-2).
- (2) Remove circuit breaker CB22 from PDP.
- (3) Disconnect connector J209 from transmission auxiliary oil cooler fan connector.
- (4) Set multimeter to volts dc.
- (5) Connect positive (+) probe of multimeter to connector J209-1.
- (6) Connect negative (-) probe of multimeter to ground.
- (7) Start engine (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If 24 vdc is not present, go to step 12 of this fault.
- (9) Shut down engine (TM 9-2320-366-10-1).




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector J209-2.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3013 (para 2-45) or replace oil cooler fan cable assembly (para 7-136).
- (5) If continuity is present, replace transmission auxiliary oil cooler fan (para 8-19 or 8-21).
- (6) Connect connector J209 to transmission auxiliary oil cooler fan connector.
- (7) Install circuit breaker CB22 in PDP.
- (8) Install PDP cover (para 16-2).



42EP6061

e146. TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (ALL MODELS EXCEPT M1088/ M1089) (CONT)





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Remove relay K15 from PDP.
- (2) Set multimeter to volts dc.
- (3) Connect positive (+) probe of multimeter to relay K15 socket 30.
- (4) Connect negative (-) probe of multimeter to ground.
- (5) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (6) If 24 vdc is not present, repair wire 1808 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (7) Position master power switch to off (TM 9-2320-366-10-1).
- (8) Install circuit breaker CB22 in PDP.




RELAY K15 CAVITY

42EP6071

CONTINUITY TEST



- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to relay K15 pin 30.
- (3) Connect negative (-) probe of multimeter to relay K15 pin 87A and note reading on multimeter.
- (4) If continuity is not present, replace relay K15 (para 7-9).

e146. TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (ALL MODELS EXCEPT M1088/ M1089) (CONT)




CONTINUITY TEST

- (1) Remove personnel heater to gain access (para 18-9).
- (2) Disconnect connector P912A from connector J912.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to relay K15 socket 87A.
- (5) Connect negative (-) probe of multimeter to connector P912A-15 and note reading on multimeter.
- (6) If continuity is not present, repair wire 1811 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (7) If continuity is present, repair wire 1811 (para 2-45) or replace oil cooler fan cable assembly (para 7-136).
- (8) Install relay K15 in PDP.
- (9) Connect connector P912A to connector J912.
- (10) Install personnel heater (para 18-9).




42EP6081

e147. M1088/M1089 TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	
References TM 9-4910-571-12&P	




VOLTAGE TEST

- (1) Remove PDP cover (para 16-2).
- (2) Remove circuit breaker CB22 from PDP.
- (3) Start engine (TM 9-2320-366-10-1).
- (4) If both transmission auxiliary oil cooler fan motors do not operate, go to step 4 of this fault.
- (5) Shut down engine (TM 9-2320-366-10-1).



42EP7011

e147. M1088/M1089 TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Disconnect connector clamp from connector J209.
- (2) Disconnect connector P209A or P209B from connector J209.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to connector P209A or P209B pin 1.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Start engine (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 24 vdc is not present, repair wire 1811 (para 2-45) or replace PTO cable assembly (para 7-127).
- (8) Shut down engine (TM 9-2320-366-10-1).





42EP7021

e147. M1088/M1089 TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (CONT)




CONTINUITY TEST

- (1) Set multimeter to volts dc.
- (2) Connect positive (+) probe of multimeter to connector P209A or P209B pin 2.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3013 (para 2-45) or replace PTO cable assembly (para 7-127).
- (5) If continuity is present, replace transmission auxiliary oil cooler fan (para 8-20).
- (6) Connect connector P209A or P209B to transmission auxiliary oil cooler fan connector.
- (7) Connect connector clamp to connector J209.
- (8) Install circuit breaker CB22 in PDP.
- (9) Install PDP cover (para 16-2).



42EP7031

e147. M1088/M1089 TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (CONT)





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Install circuit breaker CB22 in PDP.
- (2) Remove relay K15 from PDP.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to relay K15 socket 30.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 24 vdc is not present, repair wire 1808 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (8) Position master power switch to off (TM 9-2320-366-10-1).





RELAY K15 CAVITY

42EP7041

CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to relay K15 pin 30.
- (3) Connect negative (-) probe of multimeter to relay K15 pin 87A and note reading on multimeter.
- (4) If continuity is not present, replace relay K15 (para 7-9).


e147. M1088/M1089 TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (CONT)



- (1) Check if vehicle is M1088 W/O winch.
- (2) If vehicle is not an M1088 W/O winch, go to step 7 of this fault.
- (3) If vehicle is an M1088 W/O winch, go to step 9 of this fault.


CONTINUITY TEST

- (1) Remove personnel heater for access (para 18-9).
- (2) Disconnect connector P912 from connector J912.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to relay K15 socket 87A.
- (5) Connect negative (-) probe of multimeter to connector P912-15 and note reading on multimeter.
- (6) If continuity is not present, repair wire 1811 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (7) Install relay K15 in PDP.




42EP7051

e147. M1088/M1089 TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (CONT)




CONTINUITY TEST

- (1) Disconnect connector P210 from connector J210.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector J912-15.
- (4) Connect negative (-) probe of multimeter to connector J210-1 and note reading on multimeter.
- (5) If continuity is not present, repair wire 1811 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (6) If continuity is present, repair wire 1811 (para 2-45) or replace PTO cable assembly (para 7-127).
- (7) Connect connector P210 to connector J210.
- (8) Connect connector P912 to connector J912.
- (9) Install personnel heater (para 18-9).





42EP7061

e147. M1088/M1089 TRANSMISSION AUXILIARY OIL COOLER FAN DOES NOT OPERATE (CONT)



CONTINUITY TEST

- (1) Remove kick panel (para 16-3).
- (2) Disconnect connector P912A from connector J912.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector P912A-15.
- (5) Connect negative (-) probe of multimeter to relay K15 socket 87A and note reading on multimeter.
- (6) If continuity is not present, repair wire 1811A (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (7) If continuity is present, repair wire 1811A (para 2-45) or replace oil cooler fan cable assembly (para 7-136).
- (8) Connect connector P912A to connector J912.
- (9) Install kick panel (para 16-3).



42EP7071

e148. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE

INITIAL SETUP

Equipment Condition
 Engine shut down (TM 9-2320-366-10-1).

Personnel Required
 (2)

Material/Parts
 Wire, Elect, 50 ft (Item 71, Appendix D)


Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 Wrench, Torque, 0-200 lb-in (Item 59, Appendix C)

References
 TM 9-4910-571-12&P

NOTE

Perform Electrical System Troubleshooting e1. Circuit Breaker Does Not Operate on circuit breakers CB71, CB72, and CB74 prior to beginning this task.

KNOWN INFO
Circuit breakers CB71, CB72, and CB74 OK. Hazard lights illuminate. Light bulb OK.
POSSIBLE PROBLEMS
Faulty worklights switch. Faulty dashboard cable assembly. Faulty relay K12. Faulty auxiliary panel cable assembly. Faulty diode D2B. Faulty relay K9.



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

VOLTAGE TEST

- (1) Remove six screws from auxiliary panel.
- (2) Lift auxiliary panel from auxiliary panel housing to gain access.
- (3) Disconnect connector P905 from worklights switch.
- (4) Set multimeter to volts DC.
- (5) Connect positive (+) probe of multimeter to connector P905 socket 5.
- (6) Connect negative (-) probe of multimeter to ground.
- (7) Position main light switch to STOP LIGHT (TM 9-2320-366-10-1) and note reading on multimeter.
- (8) If 12 VDC is not present, go to step 7 of this fault.
- (9) Position main light switch to OFF (TM 9-2320-366-10-1).




4bep801b

e148. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE (CONT)

KNOWN INFO
Circuit breakers CB71, CB72, and CB74 OK. Hazard lights illuminate. Light bulb OK. Auxiliary panel cable assembly OK. Relay K9 OK. Diode D2B OK.
POSSIBLE PROBLEMS
Faulty worklights switch. Faulty dashboard cable assembly. Faulty relay K12.


2.
Is continuity present from worklight switch terminal 1 to terminal 5?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, worklights switch is faulty.



CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to worklights switch terminal 1.
- (3) Connect negative (-) probe of multimeter to worklights switch terminal 5.
- (4) Position worklights switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If continuity is not present, replace worklights switch (para 7-18).
- (6) Connect connector P905 to worklights switch.
- (7) Position auxiliary panel on auxiliary panel housing with six screws.
- (8) Tighten six screws to 24 lb-in. (3 N·m).



4kep802b

e148. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE (CONT)


KNOWN INFO
Circuit breakers CB71, CB72, and CB74 OK. Hazard lights illuminate. Light bulb OK. Auxiliary panel cable assembly OK. Relay K9 OK. Diode D2B OK. Worklights switch OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty relay K12.

3.

WARNING
Read WARNING on following page.

Is 12 VDC present at relay K12 terminal 86?

TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
If 12 VDC is not present, wire 1673 is faulty.





WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Remove PDP cover (para 16-2).
- (2) Remove relay K12 from PDP.
- (3) Set multimeter to volts DC.
- (4) Connect positive (+) probe of multimeter to PDP, where relay K12 terminal 86 was removed.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position main light switch to STOP LIGHT (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 12 VDC is not present, repair wire 1673 from relay K12 terminal 86 on PDP to connector J913 pin 1 (para 2-45) or replace WTEC II dashboard cable (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (8) Position main light switch to OFF (TM 9-2320-366-10-1).




RELAY K12 CAVITY

4kEP803b

e148. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE (CONT)

KNOWN INFO
Circuit breakers CB71, CB72, and CB74 OK. Hazard lights illuminate. Light bulb OK. Auxiliary panel cable assembly OK. Relay K9 OK. Diode D2B OK. Worklights switch OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty relay K12.

KNOWN INFO
Circuit breakers CB71, CB72, and CB74 OK. Hazard lights illuminate. Light bulb OK. Auxiliary panel cable assembly OK. Relay K9 OK. Diode D2B OK. Worklights switch OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty relay K12.



CONTINUITY TEST



- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to PDP, where relay K12 terminal 85 was removed.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3067 from relay K12 terminal 85 on PDP to terminal board TB2 position 30 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).

WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Set multimeter to volts DC.
- (2) Connect positive (+) probe of multimeter to PDP, where relay K12 terminal 30 was removed.
- (3) Connect negative (-) probe of multimeter to ground.
- (4) Position main light switch to STOP LIGHT (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 12 VDC is not present, repair wire 1674 from relay K12 terminal 30 on PDP to circuit breaker CB72 terminal 2 (para 2-45) or replace WTEC II dashboard cable (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (6) Position main light switch to OFF (TM 9-2320-366-10-1).




RELAY K12 CAVITY

4kEP804b

e148. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE (CONT)

KNOWN INFO
Circuit breakers CB71, CB72, and CB74 OK. Hazard lights illuminate. Light bulb OK. Auxiliary panel cable assembly OK. Relay K9 OK. Diode D2B OK. Worklights switch OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty relay K12.

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, wire 2002 is faulty. If continuity is present, relay K12 is faulty.



CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE


Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

VOLTAGE TEST

- (1) Set multimeter to ohms.
- (2) Remove three screws and washers from PDP.
- (3) Remove three screws from PDP.
- (4) Lift PDP outward to gain access.
- (5) Disconnect connector P51 from connector J51.
- (6) Connect positive (+) probe of multimeter to PDP, where relay K12 terminal 87 was removed.
- (7) Connect negative (-) probe of multimeter to connector J51 pin 1 and note reading on multimeter.
- (8) If continuity is not present, repair wire 2002 from relay K12 terminal 87 to connector J51 pin 1 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (9) If continuity is present, replace relay K12 (para 7-9).
- (10) Install relay K12 in PDP.
- (11) Install PDP on dashboard with three screws.
- (12) Install three washers and screws in PDP.
- (13) Install PDP cover (para 16-2).




RELAY K12 CAVITY



CONNECTOR J51

CONNECTOR P51




e148. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE (CONT)

KNOWN INFO
Circuit breakers CB71, CB72, and CB74 OK. Hazard lights illuminate. Light bulb OK. Auxiliary panel cable assembly OK. Worklights switch OK. Relay K12 OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty diode D2B. Faulty relay K9.

7. **WARNING**
Read WARNING on following page.

Is 12 VDC present at diode D2B terminal 4?

TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.




KNOWN INFO
Circuit breakers CB71, CB72, and CB74 OK. Hazard lights illuminate. Light bulb OK. Auxiliary panel cable assembly OK. Diode D2B OK. Worklights switch OK. Relay K12 OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty relay K9.

8. **WARNING**
Read WARNING on following page.

Is 12 VDC present at relay K9 terminal 86?

TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
If 12 VDC is not present, wire 1514 is faulty.



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CONTINUITY TEST


- (1) Remove PDP cover (para 16-2).
- (2) Remove diode D2B from PDP.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to PDP, where diode D2B terminal 4 was removed.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position main light switch to STOP LIGHT (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 12 VDC is not present, go to step 8 of this fault.
- (8) If 12 VDC is present, go to step 12 of this fault.
- (9) Position main light switch to OFF (TM 9-2320-366-10-1).

WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

VOLTAGE TEST


- (1) Install diode D2B in PDP.
- (2) Remove relay K9 from PDP.
- (3) Set multimeter to volts DC.
- (4) Connect positive (+) probe of multimeter to PDP, where relay K9 terminal 86 was removed.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position main light switch to STOP LIGHT (TM 9-232-366-10-1) and note reading on multimeter.
- (7) If 12 VDC is not present repair wire 1514 relay K9 terminal 86 to circuit breaker CB74 terminal 6 (para 2-45) or replace WTEC II dashboard cable (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (8) Position main light switch to OFF (TM 9-2320-366-10-1).



e148. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE (CONT)

KNOWN INFO
Circuit breakers CB71, CB72, and CB74 OK. Hazard lights illuminate. Light bulb OK. Auxiliary panel cable assembly OK. Diode D2B OK. Worklights switch OK. Relay K12 OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty relay K9.

KNOWN INFO
Circuit breakers CB71, CB72, and CB74 OK. Hazard lights illuminate. Light bulb OK. Auxiliary panel cable assembly OK. Diode D2B OK. Worklights switch OK. Relay K12 OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty relay K9.



CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to PDP, where relay K9 terminal 85 was removed.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3039 from relay K9 terminal 85 on PDP to terminal board TB2 position 56 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).

WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Set multimeter to volts DC.
- (2) Connect positive (+) probe of multimeter to PDP, where relay K9 terminal 30 was removed.
- (3) Connect negative (-) probe of multimeter to ground.
- (4) Position main light switch to STOP LIGHT (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) If 12 VDC is not present, repair wire 1566 from relay K9 terminal 30 on PDP to circuit breaker CB71 terminal 4 (para 2-45) or replace WTEC II dashboard cable (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (6) Position main light switch to OFF (TM 9-2320-366-10-1).




4bEP808b

e148. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE (CONT)




KNOWN INFO
Circuit breakers CB71, CB72, and CB74 OK. Hazard lights illuminate. Light bulb OK. Auxiliary panel cable assembly OK. Diode D2B OK. Worklights switch OK. Relay K12 OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty relay K9.

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, wire 1565 is faulty. If continuity is present, relay K9 is faulty.




VOLTAGE TEST

- (1) Set multimeter to ohms.
- (2) Remove diode D2B from PDP.
- (3) Connect positive (+) probe of multimeter to PDP, where relay K9 terminal 87 was removed.
- (4) Connect negative (-) probe of multimeter to PDP, where diode D2B terminal 4 was removed and note reading on multimeter.
- (5) If continuity is not present, repair wire 1565 from relay K9 terminal 87 to diode D2B terminal 4 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (6) If continuity is present, replace relay K9 (para 7-9).
- (7) Install relay K9 in PDP.
- (8) Install diode D2B in PDP.
- (9) Install PDP cover (para 16-2).
- (10) Connect connector P905 to worklights switch.
- (11) Position auxiliary panel on auxiliary panel housing with six screws.
- (12) Tighten six screws to 24 lb-in. (3 N·m).




DIODE D2 CAVITY



RELAY K9 CAVITY

4BEP809B




e148. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE (CONT)



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.


- VOLTAGE TEST**
- (1) Set multimeter to volts DC.
 - (2) Connect positive (+) probe of multimeter to PDP, where diode D2B terminal 3 was removed.
 - (3) Connect negative (-) probe of multimeter to ground.
 - (4) Position main light switch to STOP LIGHT (TM 9-2320-366-10-1) and note reading on multimeter.
 - (5) If 12 VDC is not present, replace diode D2B (para 7-9).
 - (6) If 12 VDC is present, repair wire 1672 from diode D2B terminal 3 on PDP to connector P913 socket 3 (para 2-45) or replace WTEC II dashboard cable (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
 - (7) Position main light switch to OFF (TM 9-2320-366-10-1).
 - (8) Install diode D2B in PDP.
 - (9) Install PDP cover (para 16-2).
 - (10) Connect connector P905 to worklights switch.
 - (11) Position auxiliary panel on auxiliary panel housing with six screws.
 - (12) Tighten six screws to 24 lb-in. (3 N·m).



DIODE D2 CAVITY

4BEP810B


e149. M1088/M1089 (LH) WORKLIGHTS DO NOT ILLUMINATE	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P
Materials/Parts Wire, Elect, 50 ft (Item 71, Appendix D)	



WARNING


Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


- VOLTAGE TEST**
- (1) Disconnect LH tractor or wrecker worklight from connector P133 or connector P133A.
 - (2) Set multimeter to volts dc.
 - (3) Connect positive (+) probe of multimeter to connector P133-B or connector P133A-2.
 - (4) Connect negative (-) probe of multimeter to ground.
 - (5) Position main light switch to STOP/PARK (TM 9-2320-366-10-1).
 - (6) Position work light switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
 - (7) If 12 vdc is not present, repair wire 2002 (para 2-45) or replace rear lights cable assembly (para 7-104).
 - (8) Position work light switch to off (TM 9-2320-366-10-1).
 - (9) Position main light switch to OFF (TM 9-2320-366-10-1).



42EP9011




e149. M1088/M1089 (LH) WORKLIGHTS DO NOT ILLUMINATE (CONT)






CONTINUITY TEST	
(1)	Set multimeter to ohms.
(2)	Connect positive (+) probe of multimeter to connector P133-A or connector P133A-1.
(4)	Connect negative (-) probe of multimeter to ground and note reading on multimeter.
(5)	If continuity is not present, repair wire 3063 (fixed worklight) or wire 3064 (hand-held worklight) (para 2-45) or replace rear lights cable assembly (para 7-104).
(6)	If continuity is present, replace LH tractor or wrecker worklight (para 7-42).
(7)	Connect worklight to connector P133 or P133A on LH tractor or wrecker.

CONNECTOR P133 WORKLIGHT CONNECTOR P133A



42EP9021


e150. M1088/M1089 (RH) WORKLIGHTS DO NOT ILLUMINATE	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P
Materials/Parts Wire, Elect, 50 ft (Item 71, Appendix D)	



WARNING


Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

- VOLTAGE TEST**
- (1) Disconnect RH tractor or wrecker worklight from connector P134 or connector P134A.
 - (2) Set multimeter to volts dc.
 - (3) Connect positive (+) probe of multimeter to connector P134-B or connector P134A-2.
 - (4) Connect negative (-) probe of multimeter to ground.
 - (5) Position main light switch to STOP/PARK (TM 9-2320-366-10-1).
 - (6) Position work light switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
 - (7) If 12 vdc is not present, repair wire 2002 (para 2-45) or replace rear lights cable assembly (para 7-104).
 - (8) Position work light switch to off (TM 9-2320-366-10-1).
 - (9) Position main light switch to OFF (TM 9-2320-366-10-1).




42EQ0011

ø150. M1088/M1089 (RH) WORKLIGHTS DO NOT ILLUMINATE (CONT)




- | CONTINUITY TEST | |
|-----------------|---|
| | (1) Set multimeter to ohms. |
| | (2) Connect positive (+) probe of multimeter to connector P134-A or connector P134A-1. |
| | (4) Connect negative (-) probe of multimeter to ground and note reading on multimeter. |
| | (5) If continuity is not present, repair wire 3061 (fixed worklight) or wire 3062 (hand-held worklight) (para 2-45) or replace rear lights cable assembly (para 7-104). |
| | (6) If continuity is present, replace RH tractor or wrecker worklight (para 7-42). |
| | (7) Connect worklight to connector P134 or P134A on RH tractor or wrecker. |



42E00021

e151. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE IN BLACKOUT MODE WITH BLACKOUT OVERRIDE SWITCH ON	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C) Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
Personnel Required (2)	Materials/Parts Wire, Elect, 50 ft (Item 71, Appendix D)
References TM 9-4910-571-12&P	




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Remove six screws from auxiliary panel.
- (2) Lift auxiliary panel from auxiliary panel housing outward to gain access.
- (3) Disconnect connector P906 from blackout override switch.
- (4) Set multimeter to volts dc.
- (5) Connect positive (+) probe of multimeter to connector P906-5.
- (6) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (7) If 12 vdc is not present, go to step 3 of this fault.


STEERING WHEEL
REMOVED FOR
CLARITY



CONNECTOR P906


AUXILIARY
INSTRUMENT
PANEL

AUXILIARY INSTRUMENT
PANEL HOUSING



SCREW


BLACKOUT
OVERRIDE
SWITCH




P906


42E01011

e151. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE IN BLACKOUT MODE WITH BLACKOUT OVERRIDE SWITCH ON (CONT)






- | CONTINUITY TEST | |
|-----------------|--|
| (1) | Set multimeter to ohms. |
| (2) | Position blackout override switch to on. |
| (3) | Connect positive (+) probe of multimeter to blackout override switch pin 5. |
| (4) | Connect negative (-) probe of multimeter to blackout override switch pin 1 and note reading on multimeter. |
| (5) | If continuity is not present, replace blackout override switch (para 7-18). |
| (6) | If continuity is present, go to step 4 of this fault. |
| (7) | Position blackout override switch to off. |



BLACKOUT OVERRIDE SWITCH

42eq1021

e151. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE IN BLACKOUT MODE WITH BLACKOUT OVERRIDE SWITCH ON (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Remove personnel heater to gain access (para 18-9).
- (2) Disconnect connector P913 from connector J913.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to connector J913-2.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) If 12 vdc is not present, repair wire 1674 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (8) If 12 vdc is present, repair wire 1674 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (9) Position master power switch to off (TM 9-2320-366-10-1).
- (10) Connect connector P913 to connector J913.
- (11) Install personnel heater (para 18-9).
- (12) Connect connector P906 to blackout override switch.
- (13) Position auxiliary panel on auxiliary panel housing with six screws.
- (14) Tighten six screws to 24 lb-in. (3 N·m).




42E01031

e151. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE IN BLACKOUT MODE WITH BLACKOUT OVERRIDE SWITCH ON (CONT)

KNOWN INFO
Circuit breaker OK. Worklights normal mode OK. Blackout override switch OK.
POSSIBLE PROBLEMS
Faulty dashboard cable assembly. Faulty auxiliary panel cable assembly. Faulty relay K12.

KNOWN INFO
Circuit breaker OK. Worklights normal mode OK. Blackout override switch OK.
POSSIBLE PROBLEMS
Faulty relay K12. Faulty dashboard cable assembly. Faulty auxiliary panel cable assembly.




TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, wire 3067 is faulty.

TEST OPTIONS
Continuity Test or STE/ICE-R #91
REASON FOR QUESTION
If continuity is not present, relay K12 is faulty.

CONTINUITY TEST

- (1) Remove PDP cover (para 16-2).
- (2) Remove relay K12 from PDP.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to relay K12 socket 85.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) If continuity is not present, repair wire 3067 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).




425601031

CONTINUITY TEST





- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to relay K12 pin 85.
- (3) Connect negative (-) probe of multimeter to relay K12 pin 86 and note reading on multimeter.
- (4) If continuity is not present, replace relay K12 (para 7-9).

e151. M1088/M1089 WORKLIGHTS DO NOT ILLUMINATE IN BLACKOUT MODE WITH BLACKOUT OVERRIDE SWITCH ON (CONT)




VOLTAGE TEST

- (1) Remove personnel heater to gain access (para 18-9).
- (2) Disconnect connector P913 from connector J913.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector J913-1.
- (5) Connect negative (-) probe of multimeter to PDP, relay K12 socket 86 and note reading on multimeter.
- (6) If continuity is not present, repair wire 1673 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10) or WTEC III dashboard cable assembly (para 7-11).
- (7) If continuity is present, repair wire 1673 (para 2-45) or replace auxiliary panel cable assembly (para 7-58).
- (8) Connect connector P913 to connector J913.
- (9) Install relay K12 in PDP.
- (10) Install personnel heater (para 18-9).
- (11) Connect connector P906 to blackout override switch.
- (12) Position auxiliary panel on auxiliary panel housing with six screws.
- (13) Tighten six screws to 24 lb-in. (3 N·m).



42EQ1051

e152. M1084/M1086 WORKLIGHTS DO NOT ILLUMINATE	
INITIAL SETUP	
Equipment Condition Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) STE/ICE-R (Item 41, Appendix C) Multimeter, Digital (Item 22, Appendix C)
Personnel Required (2)	References TM 9-4910-571-12&P
Materials/Parts Wire, Elect, 50 ft (Item 71, Appendix D)	




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.


VOLTAGE TEST

- (1) Disconnect connector P136 (RH worklight) or P135 (LH worklight).
- (2) Set multimeter to volts dc.
- (3) Connect positive (+) probe of multimeter to connector P136-B (RH) or P135-B (LH).
- (4) Connect negative (-) probe of multimeter to ground.
- (5) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (6) If 12 vdc is not present, repair wire 2004 (para 2-45) or replace crane power cable assembly (para 7-79).
- (7) Position master power switch to off (TM 9-2320-366-10-1).




X2E1361-

¶152. M1084/M1086 WORKLIGHTS DO NOT ILLUMINATE (CONT)



CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to (RH) connector P136-A or (LH) connector P135-A.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3065 (RH) or wire 3066 (LH) (para 2-45) or replace crane power cable assembly (para 7-79).
- (5) If continuity is present, replace crane worklight.
- (6) Connect connector P136 (RH) or P135 (LH) crane worklight connector.



X2E1362-

2-17. TRANSMISSION SYSTEM TROUBLESHOOTING

This paragraph covers Transmission System Troubleshooting. The Transmission System Fault Index, Table 2-18, lists faults for the transmission system of the vehicle.

Table 2-18. Transmission System Fault Index


Fault No.	Description	Page
f1.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Emits Eight Seconds of Beeps and/or Transmission Does Not Shift Gears	2-1584
f2.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 14	2-1586
f3.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 15	2-1594
f4.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 16	2-1600
f5.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 24 and/or 33 and Any Sub Code	2-1606
f6.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 32 and Any Sub Code	2-1620
f7.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 41, 42, 44, 45, 66, and/or 69 and Any Sub Code	2-1624
f8.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 43 and Any Sub Code	2-1628
f9.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 52 and Any Sub Code	2-1634
f10.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 57 and Any Sub Code	2-1640
f11.	Transmission Unusually Noisy When Operating	2-1644
f12.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 21 and Any Sub Code	2-1654
f13.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 51 Sub Code 10, 12, 21, 43, 45, or 65	2-1668
f14.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 25 and Any Sub Code	2-1672
f15.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 53 and Any Sub Code	2-1676
f16.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 54 Sub Code 01, 07, 10, 12, 17, 21, 23, 27, 32, 34, 43, 45, 54, 56, 65, 70, 71, 72, 80, 81, 82, 83, 85, 86, 92, 93, 95, 96, or 97	2-1680
f17.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 55 and Any Sub Code	2-1686
f18.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 56 and Any Sub Code	2-1692
f19.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 13 and Any Sub Code	2-1698
f19A.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 23 and Any Sub Code	2-1706.2
f19B.	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Does Not Illuminate	2-1706.16
f20.	Metal Particles Found During Transmission Oil Change	2-1708
f21.	Transmission Does Not Shift or Is Slow to Shift When Cold	2-1710


2-17. TRANSMISSION SYSTEM TROUBLESHOOTING (CONT)

Table 2-18. Transmission System Fault Index (Cont)

Fault No.	Description	Page
f22.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 14	2-1712
f23.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 15	2-1718
f24.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 16	2-1722
f25.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 24 and/or 33 and Any Sub Code	2-1728
f26.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 32 and Any Sub Code	2-1742
f27.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 42, 44, 45, 46, 66, and/or 69 and Any Sub Code	2-1748
f28.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 52 and Any Sub Code	2-1752
f29.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 57 and Any Sub Code	2-1758
f30.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 21 and Any Sub Code	2-1762
f31.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 51 and Any Sub Code	2-1776
f32.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 25 and Any Sub Code	2-1780
f33.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 53 and Any Sub Code	2-1784
f34.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 54 and Any Sub Code	2-1788
f35.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 55 and Any Sub Code	2-1794
f36.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 56 and Any Sub Code	2-1800
f37.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 13 and Any Sub Code	2-1806
f38.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Indicator Displays "--" and/or Transmission Does Not Shift Gears	2-1820
f39.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 23 and Any Sub Code	2-1822
f40.	WTEC III Transmission Pushbutton Shift Selector (TPSS) Does Not Illuminate	2-1822.12

f1. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) EMITS EIGHT SECONDS OF BEEPS AND/OR TRANSMISSION DOES NOT SHIFT GEARS
INITIAL SETUP Equipment Conditions Engine running (TM 9-2320-366-10-1).



- 
- (1) Perform WTEC II Code Reading and Code Clearing (para 8-4).
 - (2) If no diagnostic codes are logged after clearing, fault is corrected.
 - (3) If diagnostic codes are still logged, perform Transmission System Troubleshooting of active diagnostic codes per para 8-4, Table 8-1. WTEC II Diagnostic Code List and Description.

f2. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 22 SUB CODE 14


INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools (Cont)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 Wrench Set, Socket (Item 51, Appendix C)
 STE/ICE-R (Item 41, Appendix C)

Tools and Special Tools
 Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)

References
 TM 9-4910-571-12&P



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

RESISTANCE TEST


- (1) Disconnect transmission engine speed sensor connector from transmission engine speed sensor.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to terminal A of transmission engine speed sensor.
- (4) Connect negative (-) probe of multimeter to terminal B of transmission engine speed sensor and note reading on multimeter.

NOTE

A good transmission engine speed sensor will return a reading of 200-400 ohms resistance as follows:

- a. 200 ohms at -40° F (-40° C).
- b. 300 ohms at 68° F (20° C).
- c. 400 ohms at 230° F (110° C).

- (5) If resistance is not 200-400 ohms, replace transmission engine speed sensor (para 7-52).
- (6) Connect transmission engine speed sensor connector to transmission engine speed sensor.



XBF0201B

f2. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 22 SUB CODE 14 (CONT)


KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Transmission engine speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

2.

CAUTION
Read CAUTION on following page.

Is 200-400 ohms resistance present from connector pin P119m to P119s?

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If 200-400 ohms resistance is not present, or short circuits are found, DS Maintenance needs to be notified.



CAUTION




Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

RESISTANCE TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector P119 pin m.
- (7) Connect negative (-) probe of multimeter to connector P119 pin s and note reading on multimeter.
- (8) Connect negative (-) probe of multimeter to all other pins in connector P119 and note reading on multimeter.
- (9) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (10) If 200-400 ohms resistance is not present in step 7, or continuity is present in step 8 or step 9, notify DS Maintenance.



P119

XBF0202B


f2. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 22 SUB CODE 14 (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Transmission engine speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

3. **CAUTION**
Read CAUTION on following page.

Is continuity present from connector socket J119m to connector socket J115-7?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, WTEC II cab transmission harness is faulty.



CAUTION



Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Remove instrument panel assembly for access (para 7-15).
- (2) Disconnect connector J115 (top connector) from WTEC II TEPSS.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector socket J115-7.
- (5) Connect negative (-) probe of multimeter to connector socket J119m and note reading on multimeter.
- (6) Connect negative (-) probe of multimeter to all other sockets in connector J119 and note reading on multimeter.
- (7) Connect negative (-) probe of multimeter to ground to and note reading on multimeter.
- (8) If continuity is not present in step 5, or continuity is present in step 6 or step 7, replace WTEC II cab transmission harness (para 7-137).



XBF0203B


f2. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 22 SUB CODE 14 (CONT)

TEST OPTIONS
Transmission oil level OK. Fuse OK. Batteries OK. Transmission engine speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

4. **CAUTION**
Read CAUTION on following page.

Is continuity present from connector socket J119s to connector socket J115-16 ?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, WTEC II cab transmission harness is faulty.




CAUTION

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

- CONTINUITY TEST**
- (1) Set multimeter to ohms position.
 - (2) Connect positive (+) probe of multimeter to connector socket J115-16.
 - (3) Connect negative (-) probe of multimeter to connector socket J119s and note reading on multimeter.
 - (4) Connect negative (-) probe of multimeter to all other sockets in connector J119 and note reading on multimeter.
 - (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
 - (6) If continuity is not present in step 3, or continuity is present in step 4 or step 5, replace WTEC II cab transmission harness (para 7-137).
 - (7) If continuity is present in step 3 and no shorts circuits are found, replace WTEC II TEPSS (para 8-2).
 - (8) Connect connector J115 to WTEC II TEPSS.
 - (9) Install instrument panel assembly (para 7-15).
 - (10) Connect connector P119 to connector J119.
 - (11) Position front grille on cab with washer and screw.
 - (12) Position two washers and screws in front grille.
 - (13) Tighten screw to 48-60 lb-in. (5-7 N·m).
 - (14) Tighten two screws to 24 lb-in. (3 N·m).
 - (15) Clear diagnostic codes (para 8-4).



XBF0204B

f3. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 22 SUB CODE 15


INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)

Tools and Special Tools (Cont)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 Wrench Set, Socket (Item 51, Appendix C)
 STE/ICE-R (Item 41, Appendix C)

References
 TM 9-4910-571-12&P



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.


Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Remove instrument panel assembly for access (para 7-15).
- (6) Disconnect connector J115 (top connector) from WTEC II TEPSS.
- (7) Set multimeter to ohms.
- (8) Connect positive (+) probe of multimeter to connector J115-15.
- (9) Connect negative (-) probe of multimeter to connector J119p and note reading on multimeter.
- (10) Connect negative (-) probe of multimeter to all other sockets in connector J119 and note reading on multimeter.
- (11) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (12) If continuity is not present in step 9, or continuity is present in step 10 or step 11, replace WTEC II cab transmission harness (para 7-137).



XbF0301b

f3. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 22 SUB CODE 15 (CONT)


KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

2.

CAUTION
Read CAUTION on following page.

Is continuity present from connector J119 socket r to connector J115 socket 6?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, WTEC II cab transmission harness is faulty.



CAUTION



Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector J115 socket 6.
- (3) Connect negative (-) probe of multimeter to connector J119 socket r and note reading on multimeter.
- (4) Connect negative (-) probe of multimeter to all other sockets in connector J119 and note reading on multimeter.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) If continuity is not present in step 3, or continuity is present in step 4 or step 5, replace WTEC II cab transmission harness (para 7-137).



XBF0302B

f3. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 22 SUB CODE 15 (CONT)



CAUTION

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

RESISTANCE TEST





- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P119 pin p.
- (3) Connect negative (-) probe of multimeter to connector P119 pin r and note reading on multimeter.

NOTE

A good turbine speed sensor will return a reading of 200-400 ohms resistance as follows:

- a. 200 ohms at -40° F (-40° C).
- b. 300 ohms at 68° F (20° C).
- c. 400 ohms at 230° F (110° C).

- (4) Connect negative (-) probe of multimeter to all other pins in connector P119 and note reading on multimeter.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) If 200-400 ohms resistance is not present in step 4, or continuity is present in step 5 or step 6, notify DS Maintenance.
- (7) If 200-400 ohms resistance is present in step 3, and continuity is not present in step 5 or step 6, replace WTEC II TEPSS (para 8-2).
- (8) Connect connector J115 to WTEC II TEPSS.
- (9) Install instrument panel assembly (para 7-15).
- (10) Connect connector P119 to connector J119.
- (11) Position front grille on cab with washer and screw.
- (12) Position two washers and screws in front grille.
- (13) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (14) Tighten two screws to 24 lb-in. (3 N·m).
- (15) Clear diagnostic codes (para 8-4).



XBF0303B


f4. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 22 SUB CODE 16

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

References
 TM 9-4910-571-12&P

Tools and Special Tools
 Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 Wrench, Torque, 0-75 lb-in. (Item 90, Appendix B)
 STE/ICE-R (Item 41, Appendix C)



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

RESISTANCE TEST


- (1) Disconnect output speed sensor connector from transfer case connector.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to pin C of transfer case connector.

NOTE

A good output speed sensor will return a reading of 200-400 ohms resistance as follows:

- a. 200 ohms at -40° F (-40° C)
- b. 300 ohms at 68° F (20° C)
- c. 400 ohms at 230° F (110° C)

- (4) Connect negative (-) probe of multimeter to pin D of transfer case connector and note reading on multimeter.
- (5) If good resistance is not noted, notify DS Maintenance.
- (6) Connect output speed sensor connector to transfer case connector.




XbF0401b

f4. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 22 SUB CODE 16 (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.




2.
Is 200-400 ohms resistance present from connector P119n to P119g?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If 200-400 ohms resistance is not present, or short circuits are found, DS Maintenance needs to be notified.



CONTINUITY TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector P119n.
- (7) Connect negative (-) probe of multimeter to connector P119g and note reading on multimeter.
- (8) Connect negative (-) probe of multimeter to all other pins in connector P119, one at a time, and note reading on multimeter.
- (9) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (10) Connect positive (+) probe of multimeter to connector P119g.
- (11) Connect negative (-) probe of multimeter to all other pins in connector P119 (except P119n), one at a time, and note reading on multimeter.
- (12) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (13) If continuity 200-400 ohms resistance is not present in step 7, or continuity is present in step 8, 9, 11, or 12, notify DS Maintenance.




XBF0402B

f4. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 22 SUB CODE 16 (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.


3.
Is continuity present from connector J119n and J119g to connector J115-5 and J115-14?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, WTEC II cab transmission harness is faulty. If continuity is present, and no short circuits are found, WTEC II TEPSS is faulty.



CONTINUITY TEST

- (1) Remove instrument panel assembly for access (para 7-15).
- (2) Disconnect connector J115 (top connector) from WTEC II TEPSS.
- (3) Install jumper wire from connector J119g to J119n.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to connector J115-5.
- (6) Connect negative (-) probe of multimeter to connector J115-14 and note reading on multimeter.
- (7) Connect negative (-) probe of multimeter to all other sockets in connector J115, one at a time, and note reading on multimeter.
- (8) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (9) Connect positive (+) probe of multimeter to connector J115-14.
- (10) Connect negative (-) probe of multimeter to all other sockets in connector J115 (except J115-5), one at a time, and note reading on multimeter.
- (11) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (12) If continuity is not present in step 6, or continuity is present in step 7, 8, 10, or 11, replace WTEC II cab transmission harness (para 7-137).
- (13) If continuity is present in step 6, and continuity is not present in steps 7, 8, 10, and 11, replace WTEC II TEPSS (para 8-2).
- (14) Remove jumper wire from connector J119.
- (15) Connect connector J115 to WTEC II TEPSS.
- (16) Install instrument panel assembly (para 7-15).
- (17) Connect connector P119 to connector J119.
- (18) Position front grille on cab with washer and screw.
- (19) Position two washers and screws in front grille.
- (20) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (21) Tighten two screws to 24 lb-in. (3 N·m).
- (22) Clear diagnostic codes (para 8-4).



XbF0403b


f5. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

References
 TM 9-4910-571-12&P

Tools and Special Tools
 Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 STE/ICE-R (Item 41, Appendix C)



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Position master power switch to on (TM 9-2320-366-10-1).
- (2) Check to see if main code 24 or main code 33 is logged in WTEC II TEPSS (para 8-4).
- (3) If main code 24 is logged:
 - (a) WTEC II TEPSS has detected a sump oil temperature above (subcode 23) or below (subcode 12) operating limits.
 - (b) Troubleshoot oil cooling system followed by sump oil temperature sensor and circuits.
- (4) If main code 33 is logged:
 - (a) WTEC II TEPSS has detected a fault with sump oil temperature sensor or its circuit.
 - (b) Go to step 8 of this fault.
- (5) Position master power switch to off (TM 9-2320-366-10-1).

f5. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)


KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Engine does not overheat.
POSSIBLE PROBLEMS
Faulty transmission oil cooler tubes. Faulty transmission oil cooler hoses. Faulty transmission oil cooler. Faulty transmission auxiliary oil cooler. Faulty transmission oil filters. Faulty WTEC II cab transmission harness. Faulty transmission external wiring harness. Faulty WTEC II TEPSS.

2.

WARNING
Read WARNING on following page.

Are transmission oil cooler tubes/hoses free of damage?



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Damaged oil cooler tubes/hoses may cause WTEC II TEPSS to display main code 24 and/or 33.



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.


- (1) Check transmission oil cooler tubes/hoses for damage and restrictions.
- (2) If damage or restriction are present, replace transmission oil cooler tubes/hose (paras 8-15, 8-16, 8-17, or 8-25).



TRANSMISSION OIL COOLER TUBES

XBF0501B

f5. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)




WARNING

Do not drain transmission oil when transmission is hot. Failure to comply may result in injury to personnel.

CAUTION

Transmission oil must be changed whenever there is evidence of oil breakdown or contamination. Oil breakdown or contamination may be caused from overheating transmission and/or oil cooler internal failure and is indicated by discoloration, strong odor, or oil analysis.




TRANSMISSION OIL INSPECTION

Note


Transmission fluid capacity is 42.3 qt (40 L).

- (1) Start engine (TM 9-2320-366-10-1).
- (2) Allow oil to circulate for a few minutes.
- (3) Position drain pan under transmission AOAP valve.
- (4) Remove drain plug from transmission AOAP valve and press plunger to extract oil from system.
- (5) Allow approximately 1 qt (0.9 L) of oil to drain into drain pan. Release plunger.
- (6) Install drain plug on transmission AOAP valve.
- (7) Inspect oil for coolant contamination.
- (8) If oil is contaminated, replace transmission oil cooler (para 8-10).
- (9) Shut down engine (TM 9-2320-366-10-1).
- (10) Add oil to transmission (Appendix H).



XBF 0502B

f5. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.


AUXILIARY OIL COOLER FAN TEST

- (1) Raise cab (TM 9-2320-366-10-1).
- (2) Disconnect connector clamp from water temperature sensor.
- (3) Disconnect connector P36 from water temperature sensor (S56) to de-energize relay K15 and provide power to auxiliary oil cooler fan.
- (4) Position master power switch to on (TM 9-2320-366-10-1).

NOTE


M1088/M1089 are equipped with two transmission auxiliary oil cooler fans.

- (5) Check if auxiliary oil cooler fan comes on.
- (6) If fan does not come on, perform Electrical System Troubleshooting (e148. Transmission Auxiliary Oil Cooler Fan Does Not Operate (All Models Except M1088/M1089) or e149. M1088/M1089 Transmission Auxiliary Oil Cooler Fan Does Not Operate).
- (7) Position master power switch to off (TM 9-2320-366-10-1).
- (8) Connect connector P36 to water temperature sensor (S56).
- (9) Connect connector clamp on water temperature sensor.
- (10) Lower cab (TM 9-2320-366-10-1).



XBF 0503B

f5. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)



WARNING


Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

NOTE

M1088/M1089 are equipped with two transmission auxiliary oil cooler fans.

- (1) Check if transmission auxiliary oil cooler fins are plugged with dirt, mud, or other debris.
- (2) If fins are plugged with dirt, mud or other debris, clear transmission auxiliary oil cooler fins.


f5. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.


Check transmission oil filters for damage (para 8-9).



TRANSMISSION OIL FILTERS

XBF0504B

f5. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)



CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw, washer and front grille from cab.
- (3) Disconnect connector P119 from connector J119.
- (4) Remove instrument panel assembly for access (para 7-15).
- (5) Disconnect connector J115 (top connector) from WTEC II TEPSS.
- (6) Install jumper wire from connector J119d to J119a.
- (7) Set multimeter to ohms.
- (8) Connect positive (+) probe of multimeter to connector J115-13.
- (9) Connect negative (-) probe of multimeter on J115-1 and note reading on multimeter.
- (10) Connect negative (-) probe of multimeter to all other sockets in connector J115, one at a time, and note reading on multimeter.
- (11) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (12) Connect positive (+) probe of multimeter to connector J115-1.
- (13) Connect negative (-) probe of multimeter to all other pins in connector J115 (except J115-13), one at a time, and note reading on multimeter.
- (14) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (15) If continuity is not present in step 9, or continuity is present in step 10, 11, 13, or 14, replace WTEC II cab transmission harness (para 7-137).
- (16) Remove jumper wire from connector J119d to connector J119a.
- (17) Connect connector J115 to WTEC II TEPSS.
- (18) Install instrument panel assembly (para 7-15).



XBF0504B

f5. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)



CAUTION

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

RESISTANCE TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter on P119a.

NOTE

Transmission sump oil temperature sensor resistance reading is affected by temperature. Refer to Table 2-19. Transmission Sump Oil Temperature Sensor Resistance Readings for details.

- (3) Connect negative (-) probe of multimeter on P119d and note reading on multimeter.
- (4) Connect negative (-) probe of multimeter to all other pins in connector P119, one at a time, and note reading on multimeter.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) Connect positive (+) probe of multimeter to connector P119d.
- (7) Connect negative (-) probe of multimeter to all other pins in connector P119 (except P119a), one at a time, and note reading on multimeter.
- (8) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (9) If correct resistance is not present in step 3, or continuity is present in step 4, 5, 7, or 8, notify DS Maintenance.
- (10) If correct resistance is present in step 3 and continuity is not present in step 4, 5, 7, or 8, replace WTEC II TEPSS (para 8-2).
- (11) Connect connector P119 to connector J119.
- (12) Position front grille on cab with washer and screw.
- (13) Position two washers and screws in front grille.
- (14) Tighten screw to 48-60 lb-in. (5-7 N-m).
- (15) Tighten two screws to 24 lb-in. (3 N-m).
- (16) Clear diagnostic codes (para 8-4).




Table 2-19. Transmission Sump Oil Temperature Sensor Resistance Readings

Temperature	Resistance
-4° to 14°F (-20° to -10°C)	691-754 ohms
14° to 32°F (-10° to 0°C)	754-820 ohms
32° to 50°F (0° to 10°C)	820-889 ohms
50° to 68°F (10° to 20°C)	889-962 ohms
68° to 86°F (20° to 30°C)	962-1039 ohms
86° to 104°F (30° to 40°C)	1039-1118 ohms
104° to 122°F (40° to 50°C)	1118-1202 ohms
122° to 140°F (50° to 60°C)	1202-1286 ohms


f6. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 32 AND ANY SUBCODE

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

References
 TM 9-4910-571-12&P

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 STE/ICE-R (Item 41, Appendix C)



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Remove instrument panel assembly for access (para 7-15).
- (6) Disconnect connector J115 (top connector) from WTEC II TEPSS.
- (7) Install jumper wire from connector J119h to J119j.
- (8) Set multimeter to ohms.
- (9) Connect positive (+) probe of multimeter to connector J115-27.
- (10) Connect negative (-) probe of multimeter to connector J115-28 and note reading on multimeter.
- (11) Connect negative (-) probe of multimeter to all other sockets in connector J115, one at a time, and note reading on multimeter.
- (12) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (13) If continuity is not present in step 10, or continuity is present in step 11 or step 12, replace WTEC II cab transmission harness (para 7-137).
- (14) Connect connector P119 to connector J119.
- (15) Position front grille on cab with washer and screw.
- (16) Position two washers and screws in front grille.
- (17) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (18) Tighten two screws to 24 lb-in. (3 N·m).




f6. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 32 AND ANY SUBCODE (CONT)

KNOWN INFO
Fuse OK. Batteries OK. WTEC II cab transmission harness OK.
POSSIBLE PROBLEMS
Faulty WTEC II TEPSS.


2.
Does main code 32 appear on WTEC II TEPSS with new WTEC II TEPSS installed?

TEST OPTIONS
WTEC II TEPSS Replacement Check
REASON FOR QUESTION
If WTEC II TEPSS is faulty, WTEC II TEPSS may display main code 32.



WTEC II TEPSS REPLACEMENT CHECK

- (1) Remove original WTEC II TEPSS (para 8-2).
- (2) Install replacement WTEC II TEPSS (para 8-2).
- (3) Install instrument panel assembly (para 7-15).
- (4) Start engine (TM 9-2320-366-10-1).
- (5) Road test vehicle and read WTEC II TEPSS codes (para 8-4).
- (6) If main code 32 does not appear with replacement WTEC II TEPSS installed, replace original WTEC II TEPSS (para 8-2).
- (7) If main code 32 appears with replacement WTEC II TEPSS installed, notify DS Maintenance.
- (8) Shut down engine (TM 9-2320-366-10-1).
- (9) Clear diagnostic codes (para 8-4).



XBF0602B

f7. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 41, 42, 44, 45, 66, AND/OR 69 ANY SUB CODE


INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools (Cont)
 STE/ICE-R (Item 41, Appendix C)

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 Wrench, Torque, 0-75 lb-in. (Item 90, Appendix B)

References
 TM 9-4910-571-12&P



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Remove instrument panel assembly for access (para 7-15).
- (6) Disconnect connector J114 (bottom connector) from WTEC II TEPSS.
- (7) Install jumper wire on connector J119 for appropriate sub code. Refer to Table 2-20. WTEC II Cab Transmission Harness Transmission Solenoid Test Points.
- (8) Set multimeter to ohms.
- (9) Connect positive (+) probe of multimeter to connector J114. Refer to Table 2-20. WTEC II Cab Transmission Harness Transmission Solenoid Test Points.
- (10) Connect negative (-) probe of multimeter to connector J114 and note reading on multimeter. Refer to Table 2-20. WTEC II Cab Transmission Harness Transmission Solenoid Test Points.
- (11) Connect negative (-) probe of multimeter to all other sockets in connector J115, one at a time, and note reading on multimeter.
- (12) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (13) If continuity is not present in step 10, or continuity is present in step 11 or step 12, replace WTEC II cab transmission harness (para 7-137).
- (14) Connect connector J114 to WTEC II TEPSS.
- (15) Install instrument panel assembly (para 7-15).



XBF0701B

Table 2-20. WTEC II Cab Transmission Harness Transmission Solenoid Test Points


Sub Code	Jumper Across	Connector J114	
		Positive (+) Probe	Negative (-) Probe
12	J119M to J119B	J114-2	J114-20
13	J119T to J119N	J114-21	J114-28
14	J119C to J119V	J114-30	J114-3
15	J119W to J119B	J114-2	J114-31
16	J119U to J119N	J114-21	J114-29
21	J119F to J119H	J114-10	J114-7
22	J119D to J119V	J114-30	J114-4
23	J119P to J119S	J114-22	J114-27
24	J119J to J119B	J114-2	J114-11
26	J119K to J119A	J114-1	J114-16

f7. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 41, 42, 44, 45, 66, AND/OR 69 ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Batteries OK. WTEC II cab transmission harness OK.
POSSIBLE PROBLEMS
Faulty circuit from P119 to affected solenoid. Faulty WTEC II TEPSS.

2.
Is correct solenoid resistance present at connector P119?

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If correct resistance is not present at connector P119, DS Maintenance needs to be notified.



RESISTANCE TEST

- (1) Disconnect connector P119 from connector J119.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector P119. Refer to Table 2-21. Connector P119 Transmission Solenoid Resistance Test Points for appropriate sub code(s) and connector P119 pin(s).
- (4) Connect negative (-) probe of multimeter to connector P119 and note reading on multimeter. Refer to Table 2-21. Connector P119 Transmission Solenoid Resistance Test Points for appropriate sub code(s) and connector P119 pin(s).

NOTE

Transmission solenoid resistance is affected by temperature. Refer to Table 2-22. Transmission Solenoid Resistance Readings.

- (5) If resistance reading indicates transmission solenoid is good, replace WTEC II TEPSS (para 8-2).
- (6) If resistance reading indicates transmission solenoid is faulty, notify DS Maintenance.
- (7) Connect connector P119 to connector J119.
- (8) Position front grille on cab with washer and screw.
- (9) Position two washers and screws in front grille.
- (10) Tighten screw to 48-60 lb-in. (5-7 N-m).
- (11) Tighten two screws to 24 lb-in. (3 N-m).
- (12) Clear diagnostic codes (para 8-4).





Table 2-21. Connector P119 Transmission Solenoid Resistance Test Points

Sub Code	Connector P119	
	Positive (+) Probe	Negative (-) Probe
12	P119M	P119B
13	P119T	P119N
14	P119C	P119V
15	P119W	P119B
16	P119U	P119N
21	P119F	P119H
22	P119D	P119V
23	P119P	P119S
24	P119J	P119B
26	P119K	P119A

Table 2-22. Transmission Solenoid Resistance Readings

Temperature	Resistance
4° to 16° F (-20° to -10° C)	2.50-3.12 ohms
16° to 32° F (-10° to 0° C)	2.62-3.25 ohms
32° to 50° F (0° to 10° C)	2.74-3.38 ohms
50° to 68° F (10° to 20° C)	2.86-3.50 ohms
68° to 86° F (20° to 30° C)	2.98-3.62 ohms
86° to 104° F (30° to 40° C)	3.09-3.75 ohms
104° to 122° F (40° to 50° C)	3.21-3.88 ohms
122° to 140° F (50° to 60° C)	3.33-4.00 ohms

XBF0702B

f8. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 43 AND ANY SUB CODE

INITIAL SETUP

Equipment Conditions

Engine shut down (TM 9-2320-366-10-1).

References

TM 9-4910-571-12&P

Tools and Special Tools


Goggles, Industrial (Item 15, Appendix C)

Tool Kit, Genl Mech (Item 46, Appendix C)

Multimeter, Digital (Item 22, Appendix C)

Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)

STE/ICE-R (Item 41, Appendix C)





CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.



- CONTINUITY TEST**
- (1) Remove two screws and washers from front grille.
 - (2) Remove screw and washer from front grille.
 - (3) Remove front grille from cab.
 - (4) Disconnect connector P119 from connector J119.
 - (5) Remove instrument panel assembly for access (para 7-15).
 - (6) Disconnect connectors J114 and J115 from WTEC II TEPSS.
 - (7) Set multimeter to ohms.
 - (8) Connect positive (+) probe of multimeter to High side socket of connector J119. Refer to Table 2-23. Main Code 43 Sub Code 21 and 26 High Side Test Points.
 - (9) Connect negative (-) probe of multimeter to High side socket of connector J114 and note reading on multimeter. Refer to Table 2-23. Main Code 43 Sub Code 21 and 26 High Side Test Points.
 - (10) Connect negative (-) probe of multimeter to all other sockets in connector J114, one at a time, and note reading on multimeter.
 - (11) Connect negative (-) probe of multimeter to all sockets in connector J115, one at a time, and note reading on multimeter.
 - (12) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
 - (13) If continuity is not present in step 9, or continuity is present in step 10, 11, or 12, replace WTEC II cab transmission harness (para 7-137).

Table 2-23. Main Code 43 Sub Code 21 and 26 High Side Test Points


Sub Code	Connector J114	Connector J119
21	7	F
26	16	K

f8. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 43 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Batteries OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty transmission external wiring harness. Faulty WTEC II TEPSS.

2.
Is continuity present, and short circuits absent, on transmission solenoid circuits from connector J119 to connector J114?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, WTEC II cab transmission harness is faulty.




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector J119. Refer to Table 2-24. Main Code 43 Sub Code 21 and 26 Low Side Test Points.
- (3) Connect negative (-) probe of multimeter to connector J114 and note reading on multimeter. Refer to Table 2-24. Main Code 43 Sub Code 21 and 26 Low Side Test Points.
- (4) Connect negative (-) probe of multimeter to all other sockets in connector J114, one at a time, and note reading on multimeter.
- (5) Connect negative (-) probe of multimeter to all sockets in connector J115, one at a time, and note reading on multimeter.
- (6) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (7) If continuity is not present in step 3, or continuity is present in step 4, 5, or 6, replace WTEC II cab transmission harness (para 7-137).

Table 2-24. Main Code 43 Sub Code 21 and 26 Low Side Test Points

Sub Code	Connector J114	Connector J119
21	10	H
26	1	A




XBF0802B

f8. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 43 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Batteries OK. WTEC II cab transmission harness OK.
POSSIBLE PROBLEMS
Faulty transmission external wiring harness. Faulty WTEC II TEPSS.

3.
Is 3.26-4.4 ohms resistance present across connector P119 pins for affected solenoid circuit(s)?


TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If driver solenoids F and N do not have the proper resistance, WTEC II TEPSS may display main code 43.



- RESISTANCE TEST**
- (1) Set multimeter to ohms.
 - (2) Connect positive (+) probe of multimeter to connector P119. Refer to Table 2-25. Transmission Solenoid F and G Resistance Test Points.
 - (3) Connect negative (-) probe of multimeter to connector P119 and note reading on multimeter. Refer to Table 2-25. Transmission Solenoid F and G Resistance Test Points.
 - (4) Connect negative (-) probe of multimeter to all other pins in connector P119, one at a time, and note reading on multimeter.
 - (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
 - (6) If good resistance is not noted in step 3, or continuity is present in step 4 or step 5, transmission harness external wiring harness may be faulty, notify DS Maintenance.
 - (7) If good resistance is noted in step 3, and continuity is not present in step 4 or step 5, replace WTEC II TEPSS (para 8-2).
 - (8) Connect connector P119 to connector J119.
 - (9) Position front grille on cab with washer and screw.
 - (10) Position two washers and screws in front grille.
 - (11) Tighten screw to 48-60 lb-in. (5-7 N·m).
 - (12) Tighten two screws to 24 lb-in. (3 N·m).
 - (13) Connect connectors J114 and J115 to WTEC II TEPSS.
 - (14) Install instrument panel assembly (para 7-15).
 - (15) Clear diagnostic codes (para 8-4).

Table 2-25. Transmission Solenoids F and G Resistance Test Points

Sub Code	Affected Solenoid	Connector P119 High	Connector P119 Low
21	F	F	H
26	N	K	A



XBFO803B

f9. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 52 AND ANY SUB CODE


INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 Wrench, Torque, 0-75 lb-in. (Item 90, Appendix B)
 STE/ICE-R (Item 41, Appendix C)

References
 TM 9-4910-571-12&P

KNOWN INFO
Fuse OK. Batteries OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty transmission external wiring harness. Faulty WTEC II TEPSS.



TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, WTEC II cab transmission harness is faulty.


CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE
Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

- CONTINUITY TEST**
- (1) Remove two screws and washers from front grille.
 - (2) Remove screw and washer from front grille.
 - (3) Remove front grille on cab.
 - (4) Disconnect connector P119 from connector J119.
 - (5) Remove instrument panel assembly for access (para 7-15).
 - (6) Disconnect connector J115 (top connector) from WTEC II TEPSS.
 - (7) Set multimeter to ohms.
 - (8) Connect positive (+) probe of multimeter to connector J119h.
 - (9) Connect negative (-) probe of multimeter to connector J115-27 and note reading on multimeter.
 - (10) Connect negative (-) probe of multimeter to all other sockets in connector J115, one at a time, and note reading on multimeter.
 - (11) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
 - (12) If continuity is not present in step 9, or continuity is present in step 10 or step 11, replace WTEC II cab transmission harness (para 7-137).




XBF0901B

f9. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 52 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Batteries OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty transmission external wiring harness. Faulty WTEC II TEPSS.


2.
Is continuity present from connector J119j to connector J115-27 and absent from J119j to all other J115 sockets and ground?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present from connector J119j to connector J115-27, or continuity is present from J119j to any other J115 sockets or ground, WTEC II cab transmission harness is faulty.




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector J119j.
- (3) Connect negative (-) probe of multimeter to connector J115-28 and note reading on multimeter.
- (4) Connect negative (-) probe of multimeter to all other sockets in connector J115, one at a time, and note reading on multimeter.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) If continuity is not present in step 3, or continuity is present in step 4 or step 5, replace WTEC II cab transmission harness (para 7-137).



J119



J115


XBF0902B

f9. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 52 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Batteries OK. WTEC II cab transmission harness OK.
POSSIBLE PROBLEMS
Faulty transmission external wiring harness. Faulty WTEC II TEPSS.


3.
Is high resistance (20,000 ohms or higher) present from connector P119h to P119j?

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If resistance is high (20,000 ohms or higher), WTEC II TEPSS is faulty.



RESISTANCE TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P119h.
- (3) Connect negative (-) probe of multimeter to connector P119j and note reading on multimeter.
- (4) If resistance is high (20,000 ohms or higher), replace WTEC II TEPSS (para 8-2).
- (5) If resistance is low (less than 20,000 ohms), notify DS Maintenance.
- (6) Connect connector J115 to WTEC II TEPSS.
- (7) Install instrument panel assembly (para 7-15).
- (8) Connect connector P119 to connector J119.
- (9) Position front grille on cab with washer and screw.
- (10) Position two washers and screws in front grille.
- (11) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (12) Tighten two screws to 24 lb-in. (3 N·m).
- (13) Clear diagnostic codes (para 8-4).



XBF 0903B

f10. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 57 AND ANY SUB CODE

INITIAL SETUP


Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 Wrench Set, Socket (Item 51, Appendix C)

Materials/Parts
 Packing, Preformed (Item 197, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

Personnel Required
 (2)

References
 TM 9-491-571-12&P




WARNING

Wear approved eye protection when performing transmission pressure checks. If oil contacts eyes, seek medical attention immediately. Failure to comply may result in injury to personnel.

CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- CLUTCH PRESSURE TEST**
- (1) Remove front and intermediate propeller shafts (para 9-2).
 - (2) Position drain pan under C3 pressure tap plug.
 - (3) Remove C3 pressure tap plug and preformed packing from control valve module. Discard preformed packing.
 - (4) Connect tube to boss adapter, hose, and pipe to tube adapter to C3 pressure tap.
 - (5) Perform STE/ICE-R Test # 50 (TM 9-4910-571-12&P).
 - (6) Start engine (TM 9-2320-366-10-1) and run at idle.
 - (7) With parking brake applied, make shift indicated by sub code while assistant notes reading on STE/ICE-R.
 - (8) If pressure does not drop to zero in selected range indicated by code values, gaskets or C solenoid may be faulty in control valve module, notify DS Maintenance.
 - (9) Shut down engine (TM 9-2320-366-10-1).
 - (10) Remove pipe to tube adapter, hose, and tube to boss adapter from C3 pressure tap.
 - (11) Position preformed packing and C3 pressure tap plug in control valve module.
 - (12) Tighten C3 pressure tap plug to 84-120 lb-in. (9-14 N·m).
 - (13) Remove drain pan under C3 pressure tap.
 - (14) Install front and intermediate propeller shafts (para 9-2).




XBF1001B

Table 2-26. Sub Code Range

Sub Code	Sub Code Meaning	
11	1st	Range VER
22	2nd	Range VER
44	4th	Range VER
66	6th	Range VER
88	N1	Range VER
99	N2/N4	Range VER

f10. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 57 AND ANY SUB CODE



CAUTION




Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

RESISTANCE TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector P119h.
- (7) Connect negative (-) probe of multimeter to connector P119j and note reading on multimeter.
- (8) If 2 ohms (or less) resistance is present, the C3 pressure switch may be faulty, notify DS Maintenance.
- (9) If resistance is greater than 2 ohms, replace WTEC II TEPSS (para 8-2).
- (10) Connect connector P119 to connector J119.
- (11) Position front grille on cab with washer and screw.
- (12) Position two washers and screws in front grille.
- (13) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (14) Tighten two screws to 24 lb-in. (3 N·m).
- (15) Clear diagnostic codes (para 8-4).



P119

XBF1002B

f11. TRANSMISSION UNUSUALLY NOISY WHEN OPERATING


INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Goggles, Industrial (Item 15, Appendix C)
 Wrench Set, Socket (Item 51, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 Wrench, Torque, 0-175 lb ft (Item 58, Appendix C)
 STE/ICE-R (Item 41, Appendix C)

Materials/Parts
 Packing, Preformed (Item 197, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

References
 TM 9-4910-571-12&P




NOISE CHECK

- (1) Check if noise is heard when transmission is in neutral.
- (2) If noise is present when vehicle is in motion, probable causes are faulty propeller drive shafts, or faulty transfer case bearings.

f11. TRANSMISSION UNUSUALLY NOISY WHEN OPERATING (CONT)

KNOWN INFO
Transmission oil level OK. Oil not contaminated. Operating temperature normal. No codes logged in ECU.
POSSIBLE PROBLEMS
Faulty PTO engagement. Faulty scavenge pump engagement. Faulty oil pump. Faulty flexplate bolts. Faulty flexplate. Faulty propeller shafts and / or universal joints. Faulty transmission transfer case,

KNOWN INFO
Transmission oil level OK. Oil not contaminated. Operating temperature normal. No codes logged in ECU. PTO engagement OK.
POSSIBLE PROBLEMS
Faulty scavenge pump engagement. Faulty oil pump. Faulty flexplate bolts. Faulty flexplate. Faulty propeller shafts and / or universal joints. Faulty transmission transfer case,




TEST OPTIONS
Noise Check
REASON FOR QUESTION
Worn transmission gear teeth and / or PTO gear teeth will cause a noisy transmission.

TEST OPTIONS
Visual Inspection and Scavenge Pump Suction Test
REASON FOR QUESTION
Worn transmission gear teeth and / or scavenge pump gear will cause a noisy transmission.

NOISE CHECK

- (1) Engage PTO (TM 9-2320-366-10-1).
- (2) Listen for unusual noise or increase in noise from PTO.
- (3) If transmission is noisy when PTO is engaged, transmission gear teeth are faulty and / or PTO gear teeth are faulty. Notify DS Maintenance.
- (4) Disengage PTO (TM 9-2320-366-10-1).
- (5) Shut down engine (TM 9-2320-366-10-1).




- (1) Place drain pan under transfer case.
- (2) Disconnect scavenge pump suction hose at transfer case.
- (3) Start engine (TM 9-2320-366-10-1).
- (4) If oil drips or runs from fitting on transfer case, scavenge is not picking up oil from transmission transfer case causing it to overflow.
- (5) Perform scavenge pump suction test.
- (6) Shut down engine (TM 9-2320-366-10-1).

CAUTION

Be sure to shut down engine immediately after test has been completed. Failure to comply may result in damage to transmission.


SCAVENGE PUMP SUCTION TEST

- (1) Place end of hose in cup containing approximately one pint of oil.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Select neutral at pushbutton shift selector (TM 9-2320-366-10-1) and check if oil is immediately sucked into hose by scavenge pump.
- (4) Shut down engine (TM 9-2320-366-10-1).
- (5) If oil is not immediately removed from cup by scavenge pump, scavenge pump is faulty due to worn gears. Notify DS Maintenance.
- (6) Connect scavenge pump suction hose to transfer case.
- (7) Remove drain pan under transfer case.



XBF1102B

f11. TRANSMISSION UNUSUALLY NOISY WHEN OPERATING (CONT)




WARNING

Wear approved eye protection when performing transmission pressure checks. If oil contacts eyes, seek medical attention immediately. Failure to comply may result in injury to personnel.


MAIN OIL PRESSURE TEST

- (1) Position drain pan under pressure tap.
- (2) Remove main pressure tap plug and preformed packing from control valve module. Discard preformed packing.
- (3) Connect tube to boss adapter, hose, and pipe to tube adapter to main pressure tap.
- (4) Perform STE/ICE-R Test # 50 (TM 9-4910-571-12&P).
- (5) Start engine (TM 9-2320-366-10-1) and run at idle.
- (6) With parking brake applied, position WTEC II TEPSS to R position then to N position while assistant notes reading on STE/ICE-R.
- (7) Shut down engine (TM 9-2320-366-10-1).
- (8) If main oil pressure is low, oil pump is faulty. Notify DS Maintenance.
- (9) If oil pressure is good, moving components in transmission are faulty. Notify DS Maintenance.
- (10) Remove pipe to tube adapter, hose, and tube to boss adapter from main pressure tap.
- (11) Position preformed packing and main pressure tap plug in control valve module.
- (12) Tighten pressure tap plug to 84-120 lb-in. (9-14 N·m).
- (13) Remove drain pan under pressure tap.




XBF1103B

f11. TRANSMISSION UNUSUALLY NOISY WHEN OPERATING (CONT)




- (1) Remove four bolts from engine flywheel housing plate.
- (2) Turn engine alternator pulley in clockwise direction to reposition transmission flexplate for transmission to engine flexplate bolt inspection.
- (3) Inspect bolts in flexplate for looseness.
- (4) Inspect flexplate for play or damage.
- (5) If bolts are loose, transmission will make noise.
- (6) Tighten bolts in flexplate.
- (7) If flexplate has play or visible signs of damage, flexplate is faulty.



XBF1104B


f11. TRANSMISSION UNUSUALLY NOISY WHEN OPERATING (CONT)



WARNING

Wear approved eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

- (1) Inspect propeller shaft for loose universal joints, bent tubing, or missing balance weights.
- (2) If propeller shafts and universal joints are undamaged, bearings in transmission transfer case are faulty. Notify DS Maintenance.



X2F1105B

f12. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE


INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-365-10).

References
 TM 9-4910-571-12&P

Tools and Special Tools
 Tool Kit, Genl Mech (Item 44, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 STE/ICE-R (Item 39, Appendix C)

Personnel Required
 (2)



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.


NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

Main display code 21 needs to be cleared manually from WTEC II TEPSS after a maintenance task has been performed and before vehicle is returned to service (para 8-4).

WTEC II TEPSS RESET CHECK

- | |
|---|
| <ol style="list-style-type: none"> (1) Cycle master power switch to on (TM 9-2320-365-10), then to off five times to clear existing throttle count settings. (2) Position master power switch to on (TM 9-2320-365-10). (3) Depress accelerator pedal from idle position to full throttle position (TM 9-2320-365-10) to set new 0% and 100% throttle count values in WTEC II TEPSS. (4) Clear diagnostic code from WTEC II TEPSS (para 8-4). (5) If main code 21 does not reappear, electrical communication between WTEC II TEPSS and TPS may be faulty. (6) If main code 21 reappears, TPS may be faulty. (7) Position master power switch to off (TM 9-2320-365-10). |
|---|




XBF1201B

f12. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE (CONT)


KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS. Faulty TPS cable assembly.

2.
Is main code 33 logged in conjunction with main code 21?

TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
Main code 21 in conjunction with main code 33 indicates loss of common ground.



- (1) Position master power switch to on (TM 9-2320-365-10).
- (2) Press MODE button on WTEC II TEPSS to bring up second code (if any).
- (3) If main code 33 displays at WTEC II TEPSS, common ground may have been lost.
- (4) If main code 21 is the only code displayed TPS may be faulty. Go to step 4 of this fault.
- (5) Position master power switch to off (TM 9-2320-365-10).




f12. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK. TPS cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.




3.
Is continuity for common ground present from connector J115-1 to connector J119Z and J119a?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity for common ground is absent, main code 33 will be logged in addition to main code 21.



CONTINUITY TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Remove instrument panel assembly for access (para 7-15).
- (6) Disconnect connector J115 (top connector) from WTEC II TEPSS.
- (7) Set multimeter to ohms.
- (8) Connect positive (+) probe of multimeter to connector J115-1.
- (9) Connect negative (-) probe of multimeter to connector J119a and note reading on multimeter.
- (10) Connect negative (-) probe of multimeter to connector J119Z and note reading on multimeter.
- (11) If continuity is not present from connector J115-1 to connector J119a and J119Z, replace WTEC II cab transmission harness (para 7-137).
- (12) If continuity is present, replace WTEC II TEPSS (para 8-2).
- (13) Install instrument panel assembly (para 7-15).
- (14) Connect connector P119 to connector J119.
- (15) Position front grille on cab with washer and screw.
- (16) Position two washers and screws in front grille.
- (17) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (18) Tighten two screws to 24 lb-in. (3 N·m).
- (19) Clear diagnostic codes (para 8-4).




XBF1203B

f12. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE (CONT)


KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK.
POSSIBLE PROBLEMS
Faulty TPS cable assembly. Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

TEST OPTIONS
Linkage Test
REASON FOR QUESTION
Main code 21 will be displayed on WTEC II TEPSS if TPS cable assembly is out of adjustment.





KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK.
POSSIBLE PROBLEMS
Faulty TPS cable assembly. Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
Main code 21 will be displayed on WTEC II TEPSS if TPS is faulty.




LINKAGE TEST

- (1) Raise cab (TM 9-2320-366-10-1).
- (2) Verify distance between hitch pin clip on end of sensor rod and center of cable groove in ferrule is 4 in. (10 cm).
- (3) If distance is not 4 in. (10 cm), adjust bracket assembly to obtain correct measurement.



RESISTANCE TEST

- (1) Disconnect connector P73 from TPS connector.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to TPS terminal A.
- (4) Connect negative (-) probe of multimeter to TPS terminal C and verify multimeter reads between 9,000-15,000 ohms across terminals A and C.
- (5) Disconnect negative (-) probe of multimeter from terminal C.
- (6) Connect negative (-) probe of multimeter to TPS terminal B and note record on multimeter.
- (7) Move governor linkage to high idle stop and record reading on multimeter.
- (8) Return governor linkage to low idle stop.
- (9) Verify that difference between highest (high idle) reading and lowest (low idle) reading is between 4,000 and 6,000 ohms.
- (10) Verify that highest (high idle) reading does not exceed 15,000 ohms.
- (11) If resistance readings are not within limits, replace TPS cable assembly (para 4-16).




XBFI204b

f12. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE (CONT)


KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK. TPS cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, DS Maintenance needs to be notified.




KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK. TPS cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If any throttle position sensor wire is shorted, DS Maintenance needs to be notified.






CONTINUITY TEST


- (1) Disconnect connector P119 from connector J119.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector P119R.
- (4) Connect negative (-) probe of multimeter to connector P73 pin C and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter to connector P119f.
- (6) Connect negative (-) probe of multimeter to connector P73 pin B and note reading on multimeter.
- (7) Connect positive (+) probe of multimeter to connector P119Z.
- (8) Connect negative (-) probe of multimeter to connector P73 pin A and note reading on multimeter.
- (9) If continuity is not present on one or more wires, notify DS Maintenance.



CONNECTOR J119 CONNECTOR P119



CONNECTOR P73



CONNECTOR P73

XBF1205B

CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P119R.
- (3) Connect negative (-) probe of multimeter to all other pins in connector P119, one at a time, and note reading on multimeter.
- (4) If continuity is found between pin R and any other pin, notify DS Maintenance.
- (5) Perform steps (2) and (3) for P119f and P119Z.
- (6) If continuity is found between pin f and any other pin, or between pin Z and any other pin, notify DS Maintenance.
- (7) Connect connector P73 to TPS connector.

f12. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK. TPS cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

8.
Is continuity present from connector J119 to connector J114?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, WTEC II cab transmission harness is faulty.



CONTINUITY TEST	
(1) Lower cab (TM 9-2320-366-10-1).	
(2) Remove two screws and washers from front grille.	
(3) Remove screw and washer from front grille.	
(4) Remove front grille from cab.	
(5) Remove instrument panel assembly for access (para 7-15).	
(6) Disconnect connector J114 (bottom connector) at WTEC II TEPSS.	
(7) Set multimeter to ohms.	
(8) For each line of Table 2-27. WTEC II Cab Transmission Harness Continuity Check:	
(a) Install jumper wire across sockets in column 1.	
(b) Connect positive (+) probe of multimeter to socket in column 2.	
(c) Connect negative (-) probe of multimeter to socket in column 3 and note reading on multimeter.	
(9) If continuity is not present on any wire in Table 2-27. WTEC II Cab Transmission Harness Continuity Check, replace WTEC II cab transmission harness (para 7-137).	
(10) Remove jumper wire from connector J119.	





Table 2-27. WTEC II Cab Transmission Harness Continuity Check

Column 1 Jumper Across:	Column 2 Positive (+) Probe to:	COLUMN 3 Negative (-) probe to:
J119f to J119Z	J115-1	J115-22
J119Z to J119R	J115-1	J114-24
J119f to J119R	J115-22	J114-24




X2F12061.dwg

f12. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK. TPS cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.


9.
Are TPS wires free from short circuits at connectors J114 and J115?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
WTEC II TEPSS may display main code 21 if wire is shorted to another in the harness.



CONTINUITY TEST

- (1) Disconnect connector J115 (top connector) from WTEC II TEPSS.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector J114-24.
- (4) Connect negative (-) probe of multimeter to all other sockets in connector J114, one at a time, and all sockets in connector J115, one at a time, and note readings on multimeter.
- (5) Connect positive (+) probe of multimeter to connector J115-1.
- (6) Connect negative (-) probe of multimeter to all other sockets in connector J115, one at a time, and all sockets in connector J114, one at a time, and note readings on multimeter.
- (7) Connect positive (+) probe of multimeter to connector J115-22.
- (8) Connect negative (-) probe of multimeter to all other sockets in connector J115, one at a time, and all sockets in connector J114, one at a time, note readings on multimeter.
- (9) If continuity is present in step 4, 6, or 8, replace WTEC II cab transmission harness (para 7-137).
- (10) If continuity is not present in step 4, 6, and 8, replace WTEC II TEPSS (para 8-2).
- (11) Connect connector J114 (bottom connector) to WTEC II TEPSS.
- (12) Connect connector J115 (top connector) to WTEC II TEPSS.
- (13) Install instrument panel assembly (para 7-15).
- (14) Connect connector P119 to connector J119.
- (15) Position front grille on cab with washer and screw.
- (16) Position two washer and screws in front grille.
- (17) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (18) Tighten two screws to 24 lb-in. (3 N·m).
- (19) Clear diagnostic codes (para 8-4).



XBF1207B

f13. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 51 SUB CODE 10, 12, 21, 43, 45, or 65

INITIAL SETUP

Equipment Conditions

Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools


Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)

Materials/Parts

Packing, Preformed (Item 197, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

Personnel Required
(2)

References
TM 9-4910-571-12&P



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Check if main code 22 sub code 15 or 16 is logged in WTEC II TEPSS (para 8-4).
- (2) If main code 22 sub code 15 or 16 is logged, WTEC II TEPSS has sensed a fault with the turbine speed sensor, output speed sensor, or associated circuits. Perform Transmission System Troubleshooting (f3. WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 15 or f4. WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 16).

f13. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 51 SUB CODE 10, 12, 21, 43, 45, or 65 (CONT)


KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK. Turbine speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC II TEPSS.

2.

WARNING
Read WARNING on following page.

Does off-going clutch pressure go to 0 psi (0 kPa) when shift is made?


TEST OPTIONS
Clutch Pressure Test or STE/ICE-R Test #50
REASON FOR QUESTION
If off-going clutch oil pressure does not go to 0 psi (0 kPa) when transmission shifts, WTEC II TEPSS may display main code 51 and one or more sub codes.



WARNING

Wear approved eye protection when performing transmission pressure checks. If oil contacts eyes, seek medical attention immediately. Failure to comply may result in injury to personnel.

- CLUTCH PRESSURE TEST**
- (1) Remove front and intermediate propeller shafts (para 9-2).
 - (2) Position drain pan under pressure tap.
 - (3) Remove pressure tap plug and preformed packing from off-going clutch indicated by the sub code, refer to Table 2-28.
Off-Going Clutch Pressure Tap. Discard preformed packing.
 - (4) Connect tube to boss adapter, hose, and pipe to tube adapter to clutch pressure tap.
 - (5) Perform STE/ICE-R Test # 50 (TM 9-4910-571-12&P).
 - (6) Start engine (TM 9-2320-366-10-1) and run at idle.
 - (7) With parking brake applied, make shift indicated by sub code while assistant notes reading on STE/ICE-R.
 - (8) If one or more off-going clutches fail to loose pressure, notify DS Maintenance.
 - (9) Shut down engine (TM 9-2320-366-10-1).
 - (10) Remove pipe to tube adapter, hose, and tube to boss adapter from clutch pressure tap.
 - (11) Position preformed packing and pressure tap plug in control valve module.
 - (12) Tighten pressure tap plug to 84-120 lb-in. (9-14 N·m).
 - (13) Remove drain pan under pressure tap.
 - (14) Install front and intermediate propeller shafts (para 9-2).
 - (15) Clear diagnostic codes (para 8-4).



XBF1302B

Table 2-28. Off-Going Clutch Pressure Tap

Sub Code	Sub Code Meaning	Off-Going Clutch	Solenoid Location
10	2-1 Downshift	C5	Stationary Clutch
12	2-3 Upshift	C5	Stationary Clutch
21	3-2 Downshift	C4	Stationary Clutch
23	3-4 Upshift	C4	Stationary Clutch
43	5-4 Downshift	C2	Rotating Clutch
45	5-6 Upshift	C1	Rotating Clutch
65	7-6 Downshift	C4	Stationary Clutch

f14. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 25 AND ANY SUB CODE

INITIAL SETUP

Equipment Conditions

Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools


Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 Wrench Set, Socket (Item 51, Appendix C)

Materials/Parts

Packing, Preformed (Item 197, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

Personnel Required
(2)

Reference
TM 9-4910-571-12&P



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Check if main code 22 sub code 16 is logged in WTEC II TEPSS (para 8-4).
- (2) If main code 22 sub code 16 is logged, WTEC II TEPSS has sensed a fault with the output sensor or its circuit. Perform Transmission System Troubleshooting (f4. WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 16).


f14. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 25 AND ANY SUB CODE (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC II TEPSS.

2. **WARNING**
Read WARNING on following page.

Is there pressure to clutch(s) when shift is made?

TEST OPTIONS
Clutch Pressure Test or STE/ICE-R Test #50
REASON FOR QUESTION
If there is no pressure to clutch(s), or pressure is leaking when shift is made, WTEC II TEPSS may display main code 25 and one or more sub codes.



WARNING

Wear approved eye protection when performing transmission pressure checks. If oil contacts eyes, seek medical attention immediately. Failure to comply may result in injury to personnel.

CLUTCH PRESSURE TEST (CONT)

- (19) If all clutches indicate proper pressure, replace WTEC II TEPSS (para 8-2).
- (20) Clear diagnostic codes (para 8-4).

- CLUTCH PRESSURE TEST**
- (1) Remove front and intermediate propeller shafts (para 9-2).
 - (2) Position drain pan under pressure tap.
 - (3) Remove pressure tap plug and preformed packing from clutch pressure tap indicated by the sub code. Refer to Table 2-29. Clutch Pressure Tap. Discard preformed packing.
 - (4) Connect tube to boss adapter, hose, and pipe to tube adapter to clutch pressure tap.
 - (5) Perform STE/ICE-R Test # 50 (TM 9-4910-571-12&P).
 - (6) Start engine (TM 9-2320-366-10-1).
 - (7) With brake applied, make shift indicated by sub code. Refer to Table 2-29. Clutch Pressure Tap.
 - (8) Accelerate engine until WTEC II TEPSS displays desired range. Refer to Table 2-29. Clutch Pressure Tap.
 - (9) Maintain engine speed to keep desired transmission range while assistant notes reading on STE/ICE-R.
 - (10) Let engine return to idle.
 - (11) Shift transmission into neutral.
 - (12) Shut down engine (TM 9-2320-366-10-1).
 - (13) Remove pipe to tube adapter, hose, and tube to boss adapter from clutch pressure tap.
 - (14) Position preformed packing and pressure tap plug in control valve module.
 - (15) Tighten pressure tap plug to 84-120 lb-in. (9-14 N-m).
 - (16) Remove drain pan.
 - (17) Install front and intermediate propeller shafts (para 9-2).
 - (18) If one or more clutches failed to indicate proper pressure, notify DS Maintenance.




Table 2-29. Clutch Pressure Tap

Sub Code	Sub Code Meaning	Pressure at Clutches(s)	Pressure Readings at Taps
00	Speed Zero in 1st	C3 & C6	215-334 psi (1480-2300 kPa)
11	Speed Zero in 2nd	C1 & C5	215-305 psi (1480-2103 kPa)
22	Speed Zero in 3rd	C1 & C4	142-203 psi (980-1400 kPa)
33	Speed Zero in 4th	C1 & C3	142-203 psi (980-1400 kPa)
44	Speed Zero in 5th	C1 & C2	142-203 psi (980-1400 kPa)
55	Speed Zero in 6th	C2 & C3	128-189 psi (880-1300 kPa)
66	Speed Zero in 7th	C2 & C4	128-189 psi (880-1300 kPa)
77	Speed Zero in R	C3 & C5	215-334 psi (1480-2300 kPa)

XBF1401B

f15. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 53 AND ANY SUB CODE

INITIAL SETUP


Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 Wrench Set, Socket (Item 51, Appendix C)

Materials/Parts
 Packing, Preformed (Item 197, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

Personnel Required
 (2)

Reference
 TM 9-4910-571-12&P




CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Check if main code 22 sub code 15 or 16 is logged in WTEC II TEPSS (para 8-4).
- (2) If main code 22 sub code 15 or 16 is logged, WTEC II TEPSS has sensed a fault with the turbine speed sensor, output speed sensor, or associated circuits. Perform Transmission System Troubleshooting (f3. WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 15 or f4. WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 16).


f15. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 53 AND ANY SUB CODE (CONT)



WARNING

Wear approved eye protection when performing transmission pressure checks. If oil contacts eyes, seek medical attention immediately. Failure to comply may result in injury to personnel.

- CLUTCH PRESSURE TEST**
- (1) Remove front and intermediate propeller shafts (para 9-2).
 - (2) Position drain pan under pressure tap.
 - (3) Remove pressure tap plug and preformed packing from off-going clutch indicated by the sub code. Refer to Table 2-30. Off-Going Clutch Pressure Tap. Discard preformed packing.
 - (4) Connect tube to boss adapter, hose, and pipe to tube adapter to clutch pressure tap.
 - (5) Perform STE/ICE-R Test # 50 (TM 9-4910-571-12&P).
 - (6) Start engine (TM 9-2320-366-10-1) and run at idle.
 - (7) With parking brake applied, make shift indicated by sub code while assistant notes reading on STE/ICE-R.
 - (8) If off-going clutch pressure does not go to 8 psi (55 kPa) or less when shift is made, notify DS Maintenance.
 - (9) If off-going clutch pressure does go to 8 psi (55 kPa) or less when shift is made, replace WTEC III TEPSS (para 8-2).
 - (10) Shut down engine (TM 9-2320-366-10-1).
 - (11) Remove pipe to tube adapter, hose, and tube to boss adapter from clutch pressure tap.
 - (12) Position preformed packing and pressure tap plug in control valve module.
 - (13) Tighten pressure tap plug to 84-120 lb-in. (9-14 N-m).
 - (14) Remove drain pan under pressure tap.
 - (15) Install front and intermediate propeller shafts (para 9-2).
 - (16) Clear diagnostic codes (para 8-4).



XBF1501B

Table 2-30. Off-Going Clutch Pressure Tap

Sub Code	Sub Code Meaning	Off-Going Clutch(s)
08	L-N1 Shift	C3
18	1-N1 Shift	C1
28	2-N1 Shift	C1 & C4
29	2-N2 Shift	C1
38	3-N1 Shift	C1 & C3
39	3-N3 Shift	C1
48	4-N1 Shift	C1 & C2
49	4-N3 Shift	C1 & C2
58	5-N1 Shift	C2 & C3
59	5-N3 Shift	C2
68	6-N1 Shift	C2 & C4
69	6-N4 Shift	C2
78	R-N1 Shift	C3
99	N3-N2 or N2-N3 Shift	C2 & C4

f16. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 54 SUB CODE 01, 07, 10, 12, 17, 21, 23, 27, 32, 34, 43, 45, 54, 56, 65, 70, 71, 72, 80, 81, 82, 83, 85, 86, 92, 93, 95, 96, or 97

INITIAL SETUP


Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 Wrench Set, Socket (Item 51, Appendix C)

Materials/Parts
 Packing, Preformed (Item 197, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

Personnel Required
 (2)

Reference
 TM 9-4910-571-12&P



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Check if main code 22 sub code 15 or 16 is logged in the WTEC II TEPSS (para 8-4).
- (2) If main code 22 sub code 15 or 16 is logged, WTEC II TEPSS has sensed a fault with the turbine speed sensor, output sensor or associated circuits. Perform Transmission System Troubleshooting (f3. WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 15 or f4. WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 16).

f16. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 54 SUB CODE 01, 07, 10, 12, 17, 21, 23, 27, 32, 34, 43, 45, 54, 56, 65, 70, 71, 72, 80, 81, 82, 83, 85, 86, 92, 93, 95, 96, or 97 (CONT)


KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK. Turbine speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC II TEPSS.

2.

WARNING
Read WARNING on following page.

Is 218-276 psi (1,503-1,903 kPa) present at main oil pressure tap?

TEST OPTIONS
Pressure Test or STE/ICE-R Test #50
REASON FOR QUESTION
Low main oil pressure may cause WTEC II TEPSS to display main code 54 and one or more sub codes.




WARNING

Wear approved eye protection when performing transmission pressure checks. If oil contacts eyes, seek medical attention immediately. Failure to comply may result in injury to personnel.

PRESSURE TEST

- (1) Position drain pan under pressure tap.
- (2) Remove main pressure tap plug and preformed packing from control valve module.
- (3) Connect tube to boss adapter, hose, and pipe to tube adapter to main pressure tap.
- (4) Perform STE/ICE-R Test # 50 (TM 9-4910-571-12&P).
- (5) Start engine (TM 9-2320-366-10-1) and run at idle.
- (6) With parking brake applied, position WTEC II TEPSS to R position then to N position while assistant checks reading on STE/ICE-R.
- (7) Shut down engine (TM 9-2320-366-10-1).
- (8) If main oil pressure is low, notify DS Maintenance.
- (9) Remove pipe to tube adapter, hose, and tube to boss adapter from main pressure tap.
- (10) Position preformed packing and main pressure tap plug in control valve module.
- (11) Tighten main pressure tap plug to 84-120 lb-in. (9-14 N·m).
- (12) Remove drain pan under main pressure tap.




XBF1601B

f16. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 54 SUB CODE 01, 07, 10, 12, 17, 21, 23, 27, 32, 34, 43, 45, 54, 56, 65, 70, 71, 72, 80, 81, 82, 83, 85, 86, 92, 93, 95, 96, or 97 (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Turbine speed sensor OK. Output speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC II TEPSS.

3.
Is there pressure to clutch(s) when shift is made?

TEST OPTIONS
Pressure Test or STE/ICE-R Test #50
REASON FOR QUESTION
If there is no pressure to clutch(s) when shift is made, WTEC II TEPSS may display main code 54 and one or more sub codes.



CLUTCH PRESSURE TEST

- (1) Remove front and intermediate propeller shafts (para 9-2).
- (2) Position drain pan under pressure tap.
- (3) Remove pressure tap plug and preformed packing from clutch pressure tap indicated by the sub code. Refer to Table 2-31. Clutch Pressure Tap.
- (4) Connect tube to boss adapter, hose, and pipe to tube adapter to clutch pressure tap.
- (5) Start engine (TM 9-2320-366-10-1).
- (6) Perform STE/ICE-R Test # 50 (TM 9-4910-571-12&P).
- (7) With parking brake applied, make shift indicated by sub code. Refer to Table 2-31. Clutch Pressure Tap.
- (8) Accelerate engine until WTEC II TEPSS displays denied range. Refer to Table 2-31. Clutch Pressure Tap.
- (9) Maintain sufficient engine speed to keep desired transmission range while assistant notes reading on STE/ICE-R.
- (10) Let engine return to idle.
- (11) Shift WTEC II TEPSS into neutral.
- (12) If one or more clutches failed to indicate proper pressure, notify DS Maintenance.
- (13) If all clutches indicate proper pressure, replace WTEC II TEPSS (para 8-2).
- (14) Shut down engine (TM 9-2320-366-10-1).
- (15) Remove pipe to tube adapter, hose, and tube to boss adapter from clutch pressure tap.
- (16) Position preformed packing and pressure tap plug in control valve module.
- (17) Tighten pressure tap plug to 84-120 lb-in. (9-14 N·m).
- (18) Remove drain pan under pressure tap.
- (19) Install front and intermediate propeller shafts (para 9-2).
- (20) Clear diagnostic codes (para 8-4).

Table 2-31. Clutch Pressure Tap

Sub Code	Sub Code Meaning	Pressure at Clutch(s)	Pressure Readings at Taps
01	L-1 Upshift	C1 & C5	187-305 psi (1280-2100 kPa)
07	L-R Shift	C3 & C5	215-276 psi (1480-1900 kPa)
10	1-L Downshift	C3 & C6	215-334 psi (1480-2300 kPa)
12	1-2 Upshift	C1 & C4	142-203 psi (980-1400 kPa)
17	1-R Shift	C3 & C5	215-276 psi (1480-1900 kPa)
21	2-1 Downshift	C1 & C5	186-305 psi (1280-2100 kPa)
23	2-3 Upshift	C1 & C3	142-203 psi (980-1400 kPa)
27	2-R Shift	C3 & C5	215-334 psi (1480-2300 kPa)
32	3-2 Downshift	C1 & C4	142-203 psi (980-1400 kPa)
34	3-4 Upshift	C1 & C2	142-203 psi (980-1400 kPa)
43	4-3 Downshift	C1 & C3	142-203 psi (980-1400 kPa)
45	4-5 Upshift	C2 & C3	128-189 psi (880-1300 kPa)
54	5-4 Downshift	C1 & C2	142-203 psi (980-1400 kPa)
56	5-6 Upshift	C2 & C4	128-189 psi (880-1300 kPa)
65	6-5 Downshift	C2 & C3	128-189 psi (880-1300 kPa)
70	R-L Shift	C3 & C6	215-276 psi (1480-1900 kPa)
71	R-1 Shift	C1 & C5	186-305 psi (1280-2100 kPa)
72	R-2 Shift	C1 & C4	142-203 psi (980-1400 kPa)
80	N1-L Shift	C3 & C6	215-276 psi (1480-1900 kPa)
81	N1-1 Shift	C1 & C5	215-305 psi (1480-1900 kPa)
82	N1-2 Shift	C1 & C4	186-305 psi (1280-2100 kPa)
83	N1-3 Shift	C1 & C3	215-305 psi (1480-1900 kPa)
85	N1-5 Shift	C2 & C3	164-239 psi (1130-1650 kPa)
86	N1-6 Shift	C2 & C4	164-239 psi (1130-1650 kPa)
92	N2-2 Shift	C1 & C4	215-305 psi (1480-1900 kPa)
93	N3-3 Shift	C1 & C3	215-305 psi (1480-1900 kPa)
95	N3-5 Shift	C2 & C3	164-239 psi (1130-1650 kPa)
96	N4-6 Shift	C2 & C4	164-239 psi (1130-1650 kPa)
97	2-R Shift	C3 & C5	215-305 psi (1480-1900 kPa)

f17. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 55 AND ANY SUB CODE

INITIAL SETUP


Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 Wrench Set, Socket (Item 51, Appendix C)

Materials/Parts
 Packing, Preformed (Item 199, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

References
 TM 9-4910-571-12&P

Personnel Required
 (2)





- (1) Check transmission oil level (TM 9-2320-366-10-1).
- (2) If transmission oil level is improper, correct as required (TM 9-2320-366-10-1).



f17. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 55 AND ANY SUB CODE (CONT)


KNOWN INFO
Transmission oil level OK.
POSSIBLE PROBLEMS
Faulty WTEC II TEPSS.

2.

CAUTION
Read CAUTION
on following page.

Is main code 55 logged
without main code 32?

TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
If main code 32 is logged, C3 pressure switch or its circuit is faulty.



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Check if main code 32 is logged in WTEC II TEPSS (para 8-4).
- (2) If main code 32 is logged, WTEC II TEPSS has sensed a fault C3 pressure switch or its circuit. Perform Transmission System Troubleshooting (f6. WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 32 and Any Sub Code).


f17. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 55 AND ANY SUB CODE (CONT)

KNOWN INFO
Transmission oil level OK.
POSSIBLE PROBLEMS
Faulty WTEC II TEPSS.

3. **WARNING**
Read WARNING on following page.

Is 218-276 psi (1,503-1,903 kPa) present at main oil pressure tap?

TEST OPTIONS
Pressure Test or STE/ICE-R Test #50
REASON FOR QUESTION
Low main oil pressure may cause WTEC II TEPSS to display main code 55 and one or more sub codes.




WARNING

Wear approved eye protection when performing transmission pressure checks. If oil contacts eyes, seek medical attention immediately. Failure to comply may result in injury to personnel.

PRESSURE TEST

- (1) Position drain pan under pressure tap.
- (2) Remove main pressure tap plug and preformed packing from control valve module.
- (3) Connect tube to boss adapter, hose, and pipe to tube adapter to clutch pressure tap.
- (4) Perform STE/ICE-R Test # 50 (TM 9-4910-571-12&P).
- (5) Start engine (TM 9-2320-366-10-1) and run at idle.
- (6) With parking brake applied, position WTEC II TEPSS to R position then to N position while assistant checks reading on STE/ICE-R.
- (7) Shut down engine (TM 9-2320-366-10-1).
- (8) If main oil pressure is low, notify DS Maintenance.
- (9) Remove pipe to tube adapter, hose, and tube to boss adapter from main pressure tap.
- (10) Position preformed packing and main pressure tap plug in control valve module.
- (11) Tighten main pressure tap plug to 84-120 lb-in. (9-14 N·m).
- (12) Remove drain pan under pressure tap.




XBF1701B

f17. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 55 AND ANY SUB CODE (CONT)

KNOWN INFO
Transmission oil level OK.
POSSIBLE PROBLEMS
Faulty WTEC II TEPSS.

4.
Is pressure present at C3 clutch when shift is made?

TEST OPTIONS
Pressure Test or STE/ICE-R Test #50
REASON FOR QUESTION
If pressure is low or missing to C3 clutch when shift is made, WTEC II TEPSS may display main code 55 and one or more sub codes.



PRESSURE TEST

- (1) Remove front and intermediate propeller shafts (para 9-2).
- (2) Position drain pan under C3 pressure tap.
- (3) Remove C3 pressure tap plug and preformed packing from control valve module.
- (4) Connect tube to boss adapter, hose, and pipe to tube adapter to C3 pressure tap.
- (5) Perform STE/ICE-R test # 50 (TM 9-4910-571-12&P).
- (6) Start engine (TM 9-2320-366-10-1) and run at idle.
- (7) With parking brake applied, make shift indicated by sub code while assistant notes reading on STE/ICE-R. Refer to Table 2-32. Clutch Pressure Tap.
- (8) Shut down engine (TM 9-2320-366-10-1).
- (9) If 215-276 psi pressure is not obtained for affected code, notify DS Maintenance.
- (10) If 215-276 psi pressure is obtained, replace WTEC II TEPSS (para 8-2).
- (11) Remove pipe to tube adapter, hose, and tube to boss adapter from C3 pressure tap.
- (12) Position preformed packing and C3 pressure tap plug in control valve module.
- (13) Tighten C3 pressure tap plug to 84-120 lb-in. (9-14 N·m).
- (14) Remove drain pan under pressure tap.
- (15) Install front and intermediate propeller shafts (para 9-2).
- (16) Clear diagnostic codes (para 8-4).




Table 2-32. Clutch Pressure Tap

Sub Code	Sub Code Meaning	Pressure Readings C3 Tap
17	1-R Shift	215-276 psi (1480-1900 kPa)
27	2-R Shift	215-276 psi (1480-1900 kPa)
80	N1-L Shift	215-276 psi (1480-1900 kPa)
87	N1-R Shift	215-276 psi (1480-1900 kPa)
97	2-R Shift	215-276 psi (1480-1900 kPa)

XBF1702B

f18. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 56 AND ANY SUB CODE

INITIAL SETUP


Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 Wrench Set, Socket (Item 51, Appendix C)

Materials/Parts
 Packing, Preformed (Item 197, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

Personnel Required
 (2)

Reference
 TM 9-4910-571-12&P



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Check if main code 22 sub code 15 or 16 is logged in WTEC II TEPSS (para 8-4).
- (2) If main code 22 sub code 15 or 16 is logged, WTEC II TEPSS has sensed a fault with the turbine speed sensor, output speed sensor, or associated circuit(s). Perform Transmission System Troubleshooting (f3. WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 15 or f4. WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 16).

f18. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 56 AND ANY SUB CODE (CONT)


KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK. Transmission turbine speed sensor OK.
POSSIBLE PROBLEMS
Faulty oil pressure pump. Faulty control valve module. Faulty WTEC II TEPSS.

2.

WARNING
Read WARNING on following page.

Is 218-276 psi (1,503-1,903 kPa) present at main oil pressure tap?

TEST OPTIONS
Pressure Test or STE/ICE-R TEST #50
REASON FOR QUESTION
Low main oil pressure may cause WTEC II TEPSS to display main code 56 and one or more sub codes.




WARNING

Wear approved eye protection when performing transmission pressure checks. If oil contacts eyes, seek medical attention immediately. Failure to comply may result in injury to personnel.

PRESSURE TEST

- (1) Position drain pan under pressure tap.
- (2) Remove main pressure tap plug and preformed packing from control valve module.
- (3) Connect tube to boss adapter, hose, and pipe to tube adapter to main pressure tap.
- (4) Perform STE/ICE-R test #50 (TM 9-4910-571-12&P).
- (5) Start engine (TM 9-2320-366-10-1) and run at idle.
- (6) With parking brake applied, position WTEC II TEPSS to R position then to N position while assistant checks reading on STE/ICE-R.
- (7) Shut down engine (TM 9-2320-366-10-1).
- (8) If main oil pressure is low, notify DS Maintenance.
- (9) Remove pipe to tube adapter, hose, and tube to boss adapter from main pressure tap.
- (10) Position preformed packing and main pressure tap plug in control valve module.
- (11) Tighten main pressure tap plug to 84-120 lb-in. (9-14 N·m).
- (12) Remove drain pan under pressure tap.




XBF1801B

f18. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 56 AND ANY SUB CODE (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK. Transmission turbine speed sensor OK. Oil pressure pump OK.
POSSIBLE PROBLEMS
Faulty control valve module. Faulty WTEC II TEPSS.


3.
Is pressure present at clutch(s) when shift is made?

TEST OPTIONS
Pressure Test or STE/ICE-R Test #50
REASON FOR QUESTION
If pressure is low or missing to clutch(s) when shift is made, WTEC II TEPSS may display main code 56 and one or more sub codes.



PRESSURE TEST

- (1) Remove front and intermediate propeller shafts (para 9-2).
- (2) Position drain pan under pressure tap.
- (3) Remove pressure tap plug and preformed packing from clutch pressure tap indicated by the sub code. Refer to Table 2-33. Clutch Pressure Tap.
- (4) Connect tube to boss adapter, hose, and pipe to tube adapter to clutch pressure tap.
- (5) Perform STE/ICE-R test #50 (TM 9-4910-571-12&P).
- (6) Start engine (TM 9-2320-366-10-1).
- (7) Make shift indicated by sub code. Refer to Table 2-33. Clutch Pressure Tap.
- (8) Accelerate engine until WTEC II TEPSS displays desired range. Refer to Table 2-33. Clutch Pressure Tap.
- (9) Maintain sufficient engine speed to keep desired transmission range while assistant notes reading on STE/ICE-R.
- (10) Let engine return to idle.
- (11) Shift transmission into neutral (TM 9-2320-366-10-1).
- (12) Shut down engine (TM 9-2320-366-10-1).
- (13) If one or more of clutches failed to indicate proper pressure, notify DS Maintenance.
- (14) If all clutches indicate proper pressure, replace WTEC II TEPSS (para 8-2).
- (15) Remove pipe to tube adapter, hose, and tube to boss adapter from clutch pressure tap.
- (16) Position preformed packing and pressure tap plug in control valve module.
- (17) Tighten pressure tap plug to 84-120 lb-in. (9-14 N·m).
- (18) Remove drain pan under pressure tap.
- (19) Install front and intermediate propeller shafts (para 9-2).
- (20) Clear diagnostic codes (para 8-4).



XBF1802B

Table 2-33. Clutch Pressure Tap

Sub Code	Sub Code Meaning	Pressure at Clutch(s)	Pressure Readings at Taps
00	L Range Test	C3 & C6	215-334 psi (1480-2300 kPa)
11	1 Range Test	C1 & C5	215-305 psi (1480-2100 kPa)
22	2 Range Test	C1 & C4	142-203 psi (980-1400 kPa)
33	3 Range Test	C1 & C3	142-203 psi (980-1400 kPa)
44	4 Range Test	C1 & C2	142-203 psi (980-1400 kPa)
55	5 Range Test	C2 & C3	128-189 psi (880-1300 kPa)
66	6 Range Test	C2 & C4	128-189 psi (880-1300 kPa)
77	R Range Test	C3 & C5	215-276 psi (1480-1900 kPa)

f19. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 13 AND ANY SUB CODE


INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Personnel Required
 (2)

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 STE/ICE-R (Item 41, Appendix C)

References
 TM 9-4910-571-12&P



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.



CONNECTOR PX33


VOLTAGE TEST

- (1) Remove kick panel (para 16-3).
- (2) Set multimeter to volts DC.
- (3) Start engine (TM 9-2320-366-10-1).
- (4) Connect positive (+) probe of multimeter to connector PX33-J1.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) Connect positive (+) probe of multimeter to connector PX33-J2.
- (7) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (8) If 12 to 14.5 VDC is not verified, repair wire 1900 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).
- (9) Shut down engine (TM 9-2320-366-10-1).

XBF1901B

f19. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 13 AND ANY SUB CODE (CONT)



KNOWN INFO
Fuse OK. Battery OK. Vehicle runs. Battery charging system OK.
POSSIBLE PROBLEMS
Faulty WTEC II VIM. Faulty WTEC II cab transmission harness. Faulty WTEC II dashboard cable assembly. Faulty WTEC II TEPSS.



TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
If WTEC II VIM does not supply more than 8 VDC output, WTEC II TEPSS may display main code 13 sub code 12.

VOLTAGE TEST

- (1) Start engine (TM 9-2320-366-10-1).
- (2) Set multimeter to volts DC.
- (3) Connect positive (+) probe of multimeter to connector J116-E1.
- (4) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter to connector J116-E2.
- (6) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (7) If 12 to 14.5 VDC is not present, replace WTEC II VIM (para 8-6).
- (8) Shut down engine (TM 9-2320-366-10-1).




XBF1902B

f19. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 13 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Battery OK. Vehicle runs. Battery charging system OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II dashboard cable assembly. Faulty WTEC II VIM. Faulty WTEC II TEPSS.


3.
Is more than 8 VDC present at connector J115-2 and J115-11?

TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
If less than 8 VDC is present at connector J115-2 and J115-11, WTEC II TEPSS may display main code 13 sub code 12.



VOLTAGE TEST

- (1) Remove instrument panel assembly for access (para 7-15).
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Set multimeter to volts DC.
- (4) Disconnect connector J115 (top connector) from WTEC II TEPSS.
- (5) Connect positive (+) probe of multimeter to connector J115-2.
- (6) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (7) Connect positive (+) probe of multimeter to connector J115-11.
- (8) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (9) If 12 to 14.5 VDC is not present at connector J115-2 and J115-11, replace WTEC II cab transmission harness (para 7-137).
- (10) Shut down engine (TM 9-2320-366-10-1).




XBF1903B

f19. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 13 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Battery OK. Vehicle runs. Battery charging system OK.
POSSIBLE PROBLEMS
Faulty WTEC II dashboard cable assembly. Faulty WTEC II cab transmission harness. Faulty WTEC II VIM. Faulty WTEC II TEPSS.

4.
Is continuity present from connector PX33-K1 and PX33-K2 to a known good ground?


TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
Faulty battery ground may cause WTEC II TEPSS to display main code 13 sub code 12.



KNOWN INFO
Fuse OK. Battery OK. Vehicle runs. Battery charging system OK. WTEC II dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC II VIM. Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.




5.
Is continuity present from WTEC II VIM connector pins L1 and L2 to a known good ground?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
Faulty battery ground may cause WTEC II TEPSS to display main code 13 sub code 12.



CONTINUITY TEST

- (1) Loosen screw in connector PX33.
- (2) Disconnect connector PX33 from WTEC II VIM.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector PX33-K1.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) Connect positive (+) probe of multimeter to connector PX33-K2.
- (7) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (8) If continuity is not present on connector PX33-K1, repair wire 3101 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).
- (9) If continuity is not present on connector PX33-K2, repair wire 3102 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).
- (10) Connect connector PX33 to WTEC II VIM.
- (11) Tighten screw in connector PX33.



CONTINUITY TEST

- (1) Loosen screw in connector J116.
- (2) Disconnect connector J116 from WTEC II VIM.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to WTEC II VIM connector pin L1.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) Connect positive (+) probe of multimeter to WTEC II VIM connector pin L2.
- (7) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (8) If continuity is not present in steps (5) and (7), replace WTEC II VIM (para 8-6).
- (9) Connect connector J116 to WTEC II VIM.
- (10) Tighten screw in connector J116.
- (11) Install kick panel (para 16-3).


xbf1904b

f19. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 13 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Battery OK. Vehicle runs. Battery charging system OK. WTEC II dashboard cable assembly OK. WTEC II VIM OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.


6.
Is continuity present from connector J115-9 and J115-18 to a known good ground?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
Faulty battery ground may cause WTEC II TEPSS to display main code 13 sub code 12.



CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector J115-9.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) Connect positive (+) probe of multimeter to connector J115-18.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) If continuity is not present, replace WTEC II cab transmission harness (para 7-137).
- (7) If continuity is present, replace WTEC II TEPSS (para 8-2).
- (8) Connect connector J115 (top connector) to WTEC II TEPSS.
- (9) Install instrument panel assembly (para 7-15).
- (10) Clear diagnostic codes (para 8-4).



XBF1905B

f19A. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 23 AND ANY SUB CODE	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Personnel Required (2)
Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C)	References TM 9-4910-571-12&P

NOTE
 Perform Electrical System Troubleshooting e1.
 Circuit Breaker Does Not Operate on circuit breaker C35 prior to beginning this task.




CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Perform WTEC II Code Reading and Code Clearing (para 8-4).
- (2) If diagnostic code 23 is not logged after clearing, fault is corrected.
- (3) If diagnostic code 23 is logged after clearing, further troubleshooting is required.

f19A. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 23 AND ANY SUB CODE (CONT)



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION


Use care when testing electrical connectors not to bend connector pins or damage connector sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Remove kick panel (para 16-3).
- (2) Loosen screw in PX33 connector.
- (3) Disconnect connector PX33 from VIM connector.
- (4) Set multimeter to volts DC.
- (5) Connect positive (+) probe of multimeter to connector PX33 socket J1.
- (6) Connect negative (-) probe of multimeter to a known good ground and note reading on multimeter.
- (7) Connect positive (+) probe of multimeter to connector PX33 socket J2.
- (8) Connect negative (-) probe of multimeter to a known good ground and note reading on multimeter.
- (9) If 12 VDC is not present in steps (5) and (7), repair wire 1900 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).




x6f1901b

f19A. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 23 AND ANY SUB CODE (CONT)

KNOWN INFO
Circuit breaker CB35 OK.
POSSIBLE PROBLEMS
Faulty WTEC II dashboard cable assembly. Faulty 10 AMP MAIN POWER fuse. Faulty WTEC II VIM. Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.


3.
Is continuity present from connector PX33 socket K1 to ground?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, wire 3101 is faulty.




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector PX33 socket K1.
- (3) Connect negative (-) probe of multimeter to a known good ground and note reading on multimeter.
- (4) If continuity is not present, repair wire 3101 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).



x6f1901b

f19A. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 23 AND ANY SUB CODE (CONT)



CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Remove seven screws and washers from WTEC II VIM cover.
- (2) Remove screw, washer, WTEC II VIM cover, and nut from WTEC II VIM.
- (3) Remove 10 AMP MAIN POWER fuse from WTEC II VIM.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to one terminal on 10 AMP MAIN POWER fuse.
- (6) Connect negative (-) probe of multimeter to other terminal on 10 AMP MAIN POWER fuse and note reading on multimeter.
- (7) If continuity is not present, replace 10 AMP MAIN POWER fuse (para 8-6).
- (8) Position WTEC II VIM cover on WTEC II VIM with washer, screw, and nut.
- (9) Install seven washers, and screws in WTEC II VIM cover.



XBF19B12B

f19A. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 23 AND ANY SUB CODE (CONT)



CAUTION



Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Loosen screw in connector J116.
- (2) Disconnect connector J116 from WTEC II VIM.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to WTEC II VIM connector pin K3.
- (5) Connect negative (-) probe of multimeter to WTEC II VIM connector pin L2 and note reading on multimeter.
- (6) If continuity is not present, repair or replace WTEC II VIM (para 8-6).
- (7) Connect connector PX33 to WTEC II VIM connector.
- (8) Tighten screw in connector PX33.



xbf19a6b


f19A. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 23 AND ANY SUB CODE (CONT)

KNOWN INFO
Circuit breaker CB35 OK. WTEC II dashboard cable assembly OK. 10 AMP MAIN POWER fuse OK. WTEC II VIM OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

6. **CAUTION**
Read CAUTION on following page.

Is continuity present from connector J116 socket E2 to connector J115 socket 11 and no short circuits found?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, WTEC II cab transmission harness is faulty.





CAUTION

Use care when testing electrical connectors not to bend connector pins or damage connector sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

- CONTINUITY TEST**
- (1) Remove instrument panel assembly for access (para 7-15).
 - (2) Disconnect connector J115 from WTEC II TEPSS connector.
 - (3) Set multimeter to ohms.
 - (4) Connect positive (+) probe of multimeter to connector J116 socket E2.
 - (5) Connect negative (-) probe of multimeter to connector J115 socket 11 and note reading on multimeter.
 - (6) Connect negative probe (-) of multimeter to all other sockets in connector J115 and note reading on multimeter.
 - (7) Connect negative probe (-) of multimeter to ground and note reading on multimeter.
 - (8) If continuity is not present in step (5), or continuity is present in step (6) or step (7), replace WTEC II cab transmission harness (para 7-137).




f19A. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DISPLAYS MAIN CODE 23 AND ANY SUB CODE (CONT)

KNOWN INFO
Circuit breaker CB35 OK WTEC II dashboard cable assembly OK. 10 AMP MAIN POWER fuse OK. WTEC II VIM OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

CAUTION
Read CAUTION on following page.

7.
Is continuity present from connector J116 socket A1 to connector J115 socket 9 and no short circuits found?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, WTEC II cab transmission harness is faulty. If continuity is present and short circuits are not found, WTEC II TEPSS is faulty.




CAUTION

Use care when testing electrical connectors not to bend connector pins or damage connector sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

- CONTINUITY TEST**
- (1) Set multimeter to ohms.
 - (2) Connect positive (+) probe of multimeter to connector J116 socket A1.
 - (3) Connect negative (-) probe of multimeter to connector J115 socket 9 and note reading on multimeter.
 - (4) Connect negative probe (-) of multimeter to all other sockets in connector J115 and note reading on multimeter.
 - (5) Connect negative probe (-) of multimeter to ground and note reading on multimeter.
 - (6) If continuity is not present in step (3), or continuity is present in step (4) or step (5), replace WTEC II cab transmission harness (para 7-137).
 - (7) If continuity is present in step (3) and continuity is not present in step (4) or (5), replace WTEC II TEPSS (para 8-2).
 - (8) Connect connector J116 to VIM connector.
 - (9) Tighten screw in connector J116.
 - (10) Connect connector J115 to WTEC II TEPSS connector.
 - (11) Install kick panel (para 16-3).
 - (12) Install instrument panel assembly (para 7-15).
 - (13) Clear diagnostic codes (para 8-4).



f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).
 Kick panel removed (para 16-3).


Personnel Required
 (2)

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)

References
 TM 9-4910-571-12&P

NOTE

Perform Electrical System Troubleshooting e1. CIRCUIT BREAKER DOES NOT OPERATE on circuit breakers CB35 and CB79 prior to beginning this task.



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

VOLTAGE TEST

- (1) Loosen screw in connector PX33.
- (2) Disconnect connector PX33 from WTEC II VIM.
- (3) Set multimeter to volts DC.
- (4) Connect positive (+) probe of multimeter to connector PX33 socket J1.
- (5) Connect negative (-) probe of multimeter to ground.
- (6) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (7) Position master power switch to off (TM 9-2320-366-10-1).
- (8) If 12 VDC is not present, repair wire 1900 from connector PX33 sockets J1 and J2 to circuit breaker CB35 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).



x6f1901b

f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE (CONT)


KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB35 OK. Circuit breaker CB79 OK.
POSSIBLE PROBLEMS
Faulty WTEC II dashboard cable assembly. Faulty terminal board TB1. Faulty 10 AMP MAIN POWER fuse. Faulty 10 AMP IGNITION fuse. Faulty WTEC II VIM. Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

2.

WARNING
CAUTION
Read WARNING and CAUTION on following page.

Is 24 VDC present at connector PX33 socket C1?

TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

VOLTAGE TEST

- (1) Set multimeter to volts DC.
- (2) Connect positive (+) probe of multimeter to connector PX33 socket C1.
- (3) Connect negative (-) probe of multimeter to ground.
- (4) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (5) Position master power switch to off (TM 9-2320-366-10-1).
- (6) If 24 VDC is not present, go to step 10 of this fault.



XBF19B02B


f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE (CONT)

KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB35 OK. Circuit breaker CB79 OK. Terminal board TB1 OK.
POSSIBLE PROBLEMS
Faulty WTEC II dashboard cable assembly. Faulty 10 AMP MAIN POWER fuse. Faulty 10 AMP IGNITION fuse. Faulty WTEC II VIM. Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

3. **CAUTION**
Read CAUTION on following page.

Is continuity present from connector PX33 socket K1 to connector PX33 socket K2?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, WTEC II dashboard cable assembly is faulty.



CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Disconnect batteries (para 7-57).
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector PX33 socket K1.
- (4) Connect negative (-) probe of multimeter to connector PX33 socket K2 and note reading on multimeter.
- (5) If continuity is not present, Repair wires 3101 and 3102 from connector PX33 sockets K1 and K2 to terminal board TB2 position 16 and 17 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).



XBF19B02B


f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE (CONT)

KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB35 OK. Circuit breaker CB79 OK. Terminal board TB1 OK. WTEC II dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty 10 AMP MAIN POWER fuse. Faulty 10 AMP IGNITION fuse. Faulty WTEC II VIM. Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

4. **CAUTION**
Read CAUTION on following page.

Is continuity present from WTEC II VIM connector pin J1 to WTEC II VIM connector pin R1?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.



CAUTION



Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Loosen screw in connector J116.
- (2) Disconnect connector J116 from WTEC II VIM.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to WTEC II connector pin J1.
- (5) Connect negative (-) probe of multimeter to WTEC II connector pin R1 and note reading on multimeter.
- (6) If continuity is not present, go to step 12 of this fault.



XBF19B04B


f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE (CONT)

KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB35 OK. Circuit breaker CB79 OK. Terminal block TB1 OK. WTEC II dashboard cable assembly OK. 10 AMP MAIN POWER fuse OK.
POSSIBLE PROBLEMS
Faulty 10 AMP IGNITION fuse. Faulty WTEC II VIM. Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

5. **CAUTION**
Read CAUTION on following page.

Is continuity present from WTEC II VIM connector pin C1 to WTEC II VIM connector pin S1?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.



CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST


- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to WTEC II connector pin C1.
- (3) Connect negative (-) probe of multimeter to WTEC II connector pin S1 and note reading on multimeter.
- (4) If continuity is not present, go to step 13 of this fault.



**VIM CONNECTOR
PINS**

XBF19B05B

f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE (CONT)



CAUTION



Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to WTEC II connector pin L2.
- (3) Connect negative (-) probe of multimeter to WTEC II connector pin K2 and note reading on multimeter.
- (4) If continuity is not present, replace WTEC II VIM (para 8-6).
- (5) Connect connector PX33 to WTEC II VIM.
- (6) Tighten screw in connector PX33.



XBF19B06B

f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE (CONT)



CAUTION



Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector J116 socket E1.
- (3) Connect negative (-) probe of multimeter to connector J116 socket E2 and note reading on multimeter.
- (4) If continuity is not present, go to step 14 of this fault.



XBF19B07B


f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE (CONT)

KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB35 OK. Circuit breaker CB79 OK. Terminal board TB1 OK. WTEC II dashboard cable assembly OK. 10 AMP MAIN POWER fuse OK. 10 AMP IGNITION fuse OK. WTEC II VIM OK.
POSSIBLE PROBLEMS
Faulty WTEC II cab transmission harness. Faulty WTEC II TEPSS.

8. **CAUTION**
Read CAUTION on following page.

Is continuity present from connector J116 socket F1 to connector J115 socket 12?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, WTEC II cab transmission harness is faulty.



CAUTION



Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Remove instrument panel assembly for access (para 7-15).
- (2) Disconnect connector J115 from WTEC II TEPSS.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector J116 socket F1.
- (5) Connect negative (-) probe of multimeter to connector J115 socket 12 and note reading on multimeter.
- (6) If continuity is not present, replace WTEC II cab transmission harness (para 7-137).



XBF19B08B

f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE (CONT)



CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector J116 socket A2.
- (3) Connect negative (-) probe of multimeter to connector J115 socket 18 and note reading on multimeter.
- (4) If continuity is not present, replace WTEC II cab transmission harness (para 7-137).
- (5) If continuity is present, replace WTEC II TEPSS (para 8-2).
- (6) Connect connector J116 to WTEC II VIM connector.
- (7) Tighten screw in connector J116.
- (8) Install kick panel (para 16-3).



XBF19B09B


f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE (CONT)

KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB35 OK. Circuit breaker CB79 OK. 10 AMP MAIN POWER fuse OK. 10 AMP IGNITION fuse OK. WTEC II VIM OK. WTEC II cab transmission harness OK. WTEC II TEPSS OK.
POSSIBLE PROBLEMS
Faulty WTEC II dashboard cable assembly. Faulty terminal board TB1.

10. **CAUTION**
Read CAUTION on following page.

Is continuity present from connector PX33 socket C1 to terminal board TB1 position 60?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, WTEC II dashboard cable assembly is faulty.



CAUTION

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.




NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Disconnect batteries (para 7-57).
- (2) Remove PDP cover (para 16-2).
- (3) Remove three screws from PDP.
- (4) Remove three screws and washers from PDP.
- (5) Lift PDP outward to gain access.
- (6) Set multimeter to ohms.
- (7) Connect positive (+) probe of multimeter to connector PX33 socket C1.
- (8) Connect negative (-) probe of multimeter to terminal board TB1 position 60 and not reading on multimeter.
- (9) If continuity is not present, Repair wire 1460 from connector PX33 sockets C1 to terminal board TB1 position 60 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).
- (10) Connect connector PX33 to WTEC II VIM.
- (11) Tighten screw in connector PX33.
- (12) Install kick panel (para 16-3).

**TERMINAL BOARD
TB1**



**TERMINAL BOARD
TB1**




XBF19B10B

f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE (CONT)

KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB35 OK. Circuit breaker CB79 OK. 10 AMP MAIN POWER fuse OK. 10 AMP IGNITION fuse OK. WTEC II VIM OK. WTEC II cab transmission harness OK. WTEC II TEPSS OK.
POSSIBLE PROBLEMS
Faulty WTEC II dashboard cable assembly. Faulty terminal board TB1.



11.
 Is continuity present from terminal board TB1 position 60 to terminal board TB1 position 62?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, terminal board TB1 is faulty. If continuity is present, WTEC II dashboard cable assembly is faulty.




- CONTINUITY TEST**
- (1) Set multimeter to ohms.
 - (2) Connect positive (+) probe of multimeter to terminal board TB1 position 60.
 - (3) Connect negative (-) probe of multimeter to terminal board TB1 position 62 and note reading on multimeter.
 - (4) If continuity is not present, replace terminal board TB1 (para 7-10).
 - (5) If continuity is present, Repair wire 1690 from terminal board TB1 position 62 to circuit breaker CB79 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-10).
 - (6) Install PDP on dashboard with three screws.
 - (7) Install three washers and screws in PDP.
 - (8) Install PDP cover (para 16-2).
 - (9) Connect batteries (para 7-57).

TERMINAL BOARD TB1




TERMINAL BOARD TB1



XBF19B11B

f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE (CONT)


KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB35 OK. Circuit breaker CB79 OK. Terminal board TB1 OK. WTEC II dashboard cable assembly OK. 10 AMP IGNITION fuse OK. WTEC II cab transmission harness OK. WTEC II TEPSS OK.
POSSIBLE PROBLEMS
Faulty 10 AMP MAIN POWER fuse. Faulty WTEC II VIM.



TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, 10 AMP MAIN POWER fuse is faulty. If continuity is present, WTEC II VIM is faulty.

CONTINUITY TEST

- (1) Remove seven screws and washers from WTEC II VIM cover.
- (2) Remove screw, washer, cover, and nut from WTEC II VIM.
- (3) Remove 10 AMP MAIN POWER fuse from WTEC II VIM.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to one terminal on 10 AMP MAIN POWER fuse.
- (6) Connect negative (-) probe of multimeter to other terminal on 10 AMP MAIN POWER fuse and note reading on multimeter.
- (7) If continuity is not present, replace 10 AMP MAIN POWER fuse (para 8-6).
- (8) If continuity is present replace WTEC II VIM (para 8-6).




XBF19B12B

f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE (CONT)

KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB35 OK. Circuit breaker CB79 OK. Terminal block TB1 OK. WTEC II dashboard cable assembly OK. 10 AMP MAIN POWER fuse OK. WTEC II cab transmission harness OK. WTEC II TEPSS OK.
POSSIBLE PROBLEMS
Faulty 10 AMP IGNITION fuse. Faulty WTEC II VIM.


13.
 Is continuity present through 10 AMP IGNITION fuse?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, 10 AMP IGNITION fuse is faulty. If continuity is present, WTEC II VIM is faulty.




CONTINUITY TEST

- (1) Remove seven screws and washers from WTEC II VIM cover.
- (2) Remove screw, washer, cover, and nut from WTEC II VIM.
- (3) Remove 10 AMP IGNITION fuse from WTEC II VIM.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to one terminal on 10 AMP IGNITION fuse.
- (6) Connect negative (-) probe of multimeter to other terminal on 10 AMP IGNITION fuse and note reading on multimeter.
- (7) If continuity is not present, replace 10 AMP IGNITION fuse (para 8-6).
- (8) If continuity is present replace WTEC II VIM (para 8-6).



XBF19B13B

f19B. WTEC II TRANSMISSION ECU PUSHBUTTON SHIFT SELECTOR (TEPSS) DOES NOT ILLUMINATE (CONT)



CAUTION



Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST


- (1) Connect connector J116 to WTEC II VIM.
- (2) Tighten screw in connector J116.
- (3) Remove instrument panel assembly for access (para 7-15).
- (4) Disconnect connector J115 from WTEC II TEPSS.
- (5) Set multimeter ohms.
- (6) Connect positive (+) probe of multimeter to connector J115 socket 2.
- (7) Connect negative (-) probe of multimeter to connector J115 socket 11 and note reading on multimeter.
- (8) If continuity is not present, replace WTEC II cab transmission harness (para 7-137).
- (9) If continuity is present, replace WTEC II TEPSS (para 8-2).
- (10) Install kick panel (para 16-3).
- (11) Connect batteries (para 7-57).





XBF19B14B

f20. METAL PARTICLES FOUND DURING TRANSMISSION OIL CHANGE

INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C)



— | If metal particles are found on transfer case drain plug that are 0.165 in. (4.19 mm) x 0.078 in. (1.98 mm) or larger, C6 thrust bearing may be faulty. Notify DS Maintenance.



NEEDLE - SIDE VIEW

NEEDLE - END VIEW

METAL PARTICLES

X2F2001A

f21. TRANSMISSION DOES NOT SHIFT OR IS SLOW TO SHIFT WHEN COLD

INITIAL SETUP


Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Personnel Required
 (2)

References
 (TM 9-4910-571-12&P)

Tools and Special Tools
 Tool Kit, Genl, Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Goggles, Industrial (Item 15, Appendix C)

Materials/Parts
 Adapter, Pipe to Tube (Item 1, Appendix D)
 Packing, Preformed (Item 184, Appendix G)




WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

- (1) Check to see if vehicle is equipped with transmission oil cooler tubes.
- (2) If vehicle is not equipped with transmission oil cooler tubes, go to step 3 of this fault.

f21. TRANSMISSION DOES NOT SHIFT OR IS SLOW TO SHIFT WHEN COLD (CONT)



WARNING

Prolonged contact with lubricating oil (MIL-L-2104) may cause a skin rash. Skin and clothing that come in contact with lubricating oil should be thoroughly washed immediately. Saturated clothing should be removed immediately. Areas in which lubricating oil is used should be well ventilated to keep fumes to a minimum. Failure to comply may result in injury to personnel.



PRESSURE TEST

- (1) Place drain pan under transmission oil cooler tube.
- (2) Disconnect transmission oil sampling hose from 45 degree fitting.

NOTE


Note orientation of 45 degree fitting prior to removal.

- (3) Remove 45 degree fitting from transmission oil cooler tube.
- (4) Remove preformed packing from 45 degree fitting. Discard preformed packing.
- (5) Install adapter fitting in transmission oil cooler tube.
- (6) Install STE/ICE-R 0-1000 PSI transducer in adapter fitting.
- (7) Start engine (TM 9-2320-366-10-1).
- (8) Perform STE/ICE-R Test # 50 and note reading on STE/ICE-R.
- (9) If pressure is less than 10 PSI, notify DS Maintenance.
- (10) Shut down engine (TM 9-2320-366-10-1).
- (11) Remove STE/ICE-R 0-1000 PSI transducer from adapter fitting.
- (12) Remove adapter fitting from transmission oil cooler tube.
- (13) Install preformed packing on 45 degree fitting.
- (14) Install 45 degree fitting in transmission oil cooler tube.
- (15) Connect transmission oil sampling hose to 45 degree fitting.
- (16) Remove drain pan from under oil cooler tube.



XBF2101B

f21. TRANSMISSION DOES NOT SHIFT OR IS SLOW TO SHIFT WHEN COLD (CONT)



WARNING

Prolonged contact with lubricating oil (MIL-L-2104) may cause a skin rash. Skin and clothing that come in contact with lubricating oil should be thoroughly washed immediately. Saturated clothing should be removed immediately. Areas in which lubricating oil is used should be well ventilated to keep fumes to a minimum. Failure to comply may result in injury to personnel.


PRESSURE TEST

- (1) Place drain pan under transmission oil cooler hose.
- (2) Disconnect transmission oil sampling hose from 45 degree fitting.

NOTE

Note orientation of 45 degree fitting prior to removal.

- (3) Remove 45 degree fitting from transmission oil cooler hose.
- (4) Install street elbow on transmission oil cooler hose.
- (5) Connect flexible hose assembly to street elbow.
- (6) Install reducer fitting on flexible hose assembly.
- (7) Install STE/ICE-R 0-1000 PSI transducer on reducer fitting.
- (8) Start engine (TM 9-2320-366-10-1).
- (9) Perform STE/ICE-R Test # 50 and note reading on STE/ICE-R.
- (10) If pressure is less than 10 PSI, notify DS Maintenance.
- (11) Shut down engine (TM 9-2320-366-10-1).
- (12) Remove STE/ICE-R 0-1000 PSI transducer from reducer fitting.
- (13) Remove reducer fitting from flexible hose assembly.
- (14) Disconnect flexible hose assembly from street elbow.
- (15) Remove street elbow from transmission oil cooler hose.
- (16) Install 45 degree fitting on transmission oil cooler hose.
- (17) Connect transmission oil sampling hose to 45 degree fitting.
- (18) Remove drain pan from under oil cooler hose.



XBF2102B


f22. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 22 SUB CODE 14

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 Wrench, Torque, 0-75 lb-in. (Item 90, Appendix B)
 STE/ICE-R (Item 41, Appendix C)

References
 TM 9-4910-571-12&P



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

RESISTANCE TEST


- (1) Disconnect connector P72 from transmission engine speed sensor.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to pin A of transmission engine speed sensor.

NOTE

A good transmission engine speed sensor will return a reading of 200-400 ohms resistance as follows:

- a. 200 ohms at - 40° F (- 40° C)
- b. 300 ohms at 68° F (20° C)
- c. 400 Ohms at 230° F (110° C)

- (4) Connect negative (-) probe of multimeter to pin B of transmission engine speed sensor and note reading on multimeter.
- (5) If good resistance is not noted, replace transmission engine speed sensor (para 7-52).
- (6) Connect connector P72 to transmission engine speed sensor.




f22. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 22 SUB CODE 14 (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Transmission engine speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.




2.
Is 200-400 ohms resistance present from connector P119m to P119s?

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If 200-400 ohms resistance is not present, or short circuits are found, DS Maintenance needs to be notified.



RESISTANCE TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector P119m.
- (7) Connect negative (-) probe of multimeter to connector P119s and note reading on multimeter.
- (8) Connect negative (-) probe of multimeter to all other pins in connector P119, one at a time, and note reading on multimeter.
- (9) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (10) Connect positive (+) probe of multimeter to connector P119s.
- (11) Connect negative (-) probe of multimeter to all other pins in connector P119 (except P119m), one at a time, and note reading on multimeter.
- (12) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (13) If 200-400 ohms resistance is not present in step 7, or continuity is present in step 8, 9, 11, or 12, notify DS Maintenance.



P119


XBF2202B

f22. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 22 SUB CODE 14 (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Transmission engine speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.


3.
Is continuity present from connector J119m and J119s to connector P114-14 and P114-30?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, WTEC III cab transmission harness is faulty. If continuity is present, and no short circuits are found, WTEC III transmission ECU is faulty.



CONTINUITY TEST

- (1) Remove kick panel (para 16-3).
- (2) Disconnect connector clamp from connector P114.
- (3) Disconnect connector P114 from WTEC III transmission ECU.
- (4) Install jumper wire from connector J119m to J119s.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector P114-14.
- (7) Connect negative (-) probe of multimeter to connector P114-30 and note reading on multimeter.
- (8) Connect negative (-) probe of multimeter to all other sockets in connector P114, one at a time, and note reading on multimeter.
- (9) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (10) Connect positive (+) probe of multimeter to connector P114-30.
- (11) Connect negative (-) probe of multimeter to all other sockets in connector P114 (except P114-14), one at a time, and note reading on multimeter.
- (12) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (13) If continuity is not present in step 7, or continuity is present in step 8, 9, 11, or 12, replace WTEC III cab transmission harness (para 7-138).
- (14) If continuity is present in step 7, and continuity is not present in step 8, 9, 11, and 12, replace WTEC III transmission ECU (para 8-7).
- (15) Remove jumper wire from connector J119s and J119m.
- (16) Connect connector P119 to connector J119.
- (17) Position front grille on cab with washer and screw.
- (18) Position two washers and screws in front grille.
- (19) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (20) Tighten two screws to 24 lb-in. (3 N·m).
- (21) Connect connector P114 to WTEC III transmission ECU.
- (22) Connect connector clamp to connector P114.
- (23) Install kick panel (para 16-3).
- (24) Clear diagnostic codes (para 8-5).



XBF2203B

f23. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 22 SUB CODE 15


INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools (Cont)
 Wrench, Torque, 0-75 lb-in. (Item 90, Appendix B)
 STE/ICE-R (Item 41, Appendix C)

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)

References
 TM 9-4910-571-12&P



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE


Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Remove kick panel (para 16-3).
- (6) Disconnect connector clamp from connector P114.
- (7) Disconnect connector P114 from WTEC III transmission ECU.
- (8) Install jumper wire from connector J119p to J119r.
- (9) Set multimeter to ohms.
- (10) Connect positive (+) probe of multimeter to connector P114-15.
- (11) Connect negative (-) probe of multimeter to connector P114-31 and note reading on multimeter.
- (12) Connect negative (-) probe of multimeter to all other sockets in connector P114, one at a time, and note reading on multimeter.
- (13) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (14) Remove jumper wire from connector J119r and J119p.
- (15) Connect positive (+) probe of multimeter to connector P114-31.
- (16) Connect negative (-) probe of multimeter to all sockets in connector P114 (except P114-15), one at a time, and note reading on multimeter.
- (17) Connect negative (-) probe of multimeter to ground and note reading on multimeter.

CONTINUITY TEST (Cont)

- (18) If continuity is not present in step 11, or continuity is present in step 12, 13, 16, or 17, replace WTEC III cab transmission harness (para 7-138).
- (19) Connect connector P114 to WTEC III transmission ECU.
- (20) Connect connector clamp to connector P114.
- (21) Install kick panel (para 16-3).




XB F2301B

f23. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 22 SUB CODE 15 (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. WTEC III cab transmission harness OK.
POSSIBLE PROBLEMS
Faulty WTEC III transmission ECU.

2.
Is 200 - 400 ohms resistance present from connector P119p to P119r?

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If 200-400 ohms resistance is not present from connector P119p to P119r, or short circuits are found, DS Maintenance needs to be notified.



RESISTANCE TEST




- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P119p.
- (3) Connect negative (-) probe of multimeter to connector P119r and note reading on multimeter.

NOTE

A good turbine speed sensor will return a reading of 200-400 ohms resistance as follows:

- a. 200 ohms at -40° F (-40° C).
- b. 300 ohms at 68° F (20° C).
- c. 400 ohms at 230° F (110° C).

- (4) Connect negative (-) probe of multimeter to all other pins in connector P119, one at a time, and note reading on multimeter.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) Connect positive (+) probe of multimeter to connector P119r.
- (7) Connect negative (-) probe of multimeter to all pins in connector P119 (except P119p), one at a time, and note reading on multimeter.
- (8) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (9) If good resistance is not noted in step 3, or continuity is present in step 4, 5, 7, or 8, notify DS Maintenance.
- (10) If good resistance is noted in step 3 and continuity is not present in step 4, 5, 7, or 8, replace WTEC III transmission ECU (para 8-7).
- (11) Connect connector P119 to connector J119.
- (12) Position front grille on cab with washer and screw.
- (13) Position two washers and screws in front grille.
- (14) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (15) Tighten two screws to 24 lb-in. (3 N·m).
- (16) Clear diagnostic codes (para 8-5).



P119

XBf2302B


f24. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 22 SUB CODE 16

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

References
 TM 9-4910-571-12&P

Tools and Special Tools
 Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 Wrench, Torque, 0-75 lb-in. (Item 90, Appendix B)
 STE/ICE-R (Item 41, Appendix C)



KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If 200-400 ohms resistance is not present, notify DS Maintenance.

WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


RESISTANCE TEST

- (1) Disconnect output speed sensor connector from transfer case connector.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to pin C of transfer case connector.

NOTE

A good output speed sensor will return a reading of 200-400 ohms resistance as follows:

- a. 200 ohms at -40° F (-40° C)
 - b. 300 ohms at 68° F (20° C)
 - c. 400 ohms at 230° F (110° C)
- (4) Connect negative (-) probe of multimeter to pin D of transfer case connector and note reading on multimeter.
 - (5) If good resistance is not noted, notify DS Maintenance.
 - (6) Connect output speed sensor connector to transfer case connector.




XBF2401B

f24. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 22 SUB CODE 16 (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.




2.
Is 200-400 ohms resistance present from connector P119n to P119g?

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If 200-400 ohms resistance is not present, or short circuits are found, notify DS Maintenance.



RESISTANCE TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector P119n.
- (7) Connect negative (-) probe of multimeter to connector P119g and note reading on multimeter.
- (8) Connect negative (-) probe of multimeter to all other pins in connector P119, one at a time, and note reading on multimeter.
- (9) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (10) Connect positive (+) probe of multimeter to connector P119g.
- (11) Connect negative (-) probe of multimeter to all other pins in connector P119 (except P119n), one at a time, and note reading on multimeter.
- (12) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (13) If 200-400 ohms resistance is not present in step 7, or continuity is present in step 8, 9, 11, or 12, notify DS Maintenance.



P119


XBF2402B

f24. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 22 SUB CODE 16 (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.


3.
Is continuity present from connector J119n and J119g to connector P114-16 and P114-32?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, WTEC III cab transmission harness is faulty. If continuity is present, and no short circuits are found, WTEC III transmission ECU is faulty.



CONTINUITY TEST

- (1) Remove kick panel (para 16-3).
- (2) Disconnect connector clamp from connector P114.
- (3) Disconnect connector P114 from WTEC III transmission ECU.
- (4) Install jumper wire from connector J119g to J119n.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector P114-32.
- (7) Connect negative (-) probe of multimeter to connector P114-16 and note reading on multimeter.
- (8) Connect negative (-) probe of multimeter to all other sockets in connector P114, one at a time, and note reading on multimeter.
- (9) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (10) Connect positive (+) probe of multimeter to connector P114-16.
- (11) Connect negative (-) probe of multimeter to all other sockets in connector P114 (except P114-32), one at a time, and note reading on multimeter.
- (12) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (13) If continuity is not present in step 7, or continuity is present in step 8, 9, 11, or 12, replace WTEC III cab transmission harness (para 7-138).
- (14) If continuity is present in step 7, and continuity is not present in step 8, 9, 11, and 12, replace WTEC III transmission ECU (para 8-7).
- (15) Remove jumper wire from connector J119n and J119g.
- (16) Connect connector P119 to connector J119.
- (17) Position front grille on cab with washer and screw.
- (18) Position two washers and screws in front grille.
- (19) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (20) Tighten two screws to 24 lb-in. (3 N·m).
- (21) Connect connector P114 to WTEC III transmission ECU.
- (22) Connect connector clamp to connector P114.
- (23) Install kick panel (para 16-3).
- (24) Clear diagnostic codes (para 8-5).



XBF2403B

f25. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE

INITIAL SETUP

Equipment Conditions

Engine shut down (TM 9-2320-366-10-1).

References

TM 9-4910-571-12&P

Tools and Special Tools

Goggles, Industrial (Item 15, Appendix C)


Tool Kit, Genl Mech (Item 46, Appendix C)

Multimeter, Digital (Item 22, Appendix C)

Pan, Drain (Item 24, Appendix C)

Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)

STE/ICE-R (Item 41, Appendix C)




CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Position master power switch to on (TM 9-2320-366-10-1).
- (2) Check to see if main code 24 or main code 33 is displayed on WTEC III TPSS (para 8-5).
- (3) If main code 24 is displayed:
 - (a) WTEC III transmission ECU has detected a sump oil temperature above (sub code 23) or below (sub code 12) operating limits.
 - (b) Troubleshoot oil cooling system followed by sump oil temperature sensor and circuits.
- (4) If main code 33 is displayed:
 - (a) WTEC III transmission ECU has detected a fault with sump oil temperature sensor or its circuit.
 - (b) Troubleshoot electrical system.
- (5) Position master power switch to off (TM 9-2320-366-10-1).

f25. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Engine does not overheat.
POSSIBLE PROBLEMS
Faulty transmission oil cooler tubes. Faulty transmission oil cooler. Faulty transmission auxiliary oil cooler. Faulty transmission oil filters. Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.




TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
Damaged oil cooler tubes may cause WTEC III TPSS to display main code 24 and/or 33.

WARNING


Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

- (1) Check transmission oil cooler tubes for damage and restrictions.
- (2) If damage or restrictions are found, replace transmission oil cooler tube(s) (para 8-17).

**TRANSMISSION OIL COOLER TUBES**

XBF2501B

f25. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)



TRANSMISSION OIL INSPECTION

WARNING

Do not drain transmission oil when transmission is hot. Failure to comply may cause severe injury to personnel.



CAUTION

Transmission oil must be changed whenever there is evidence of oil breakdown or contamination. Oil breakdown or contamination may be caused from overheating transmission and/or oil cooler internal failure and is indicated by discoloration, strong odor, or oil analysis.

NOTE

Transmission fluid capacity is 42.3 qt (40 L).

- (1) Start engine (TM 9-2320-366-10-1).
- (2) Allow oil to circulate for a few minutes.
- (3) Place drain pan under transmission AOAP valve.
- (4) Remove drain plug from transmission AOAP valve and press plunger to extract oil from system.
- (5) Allow approximately 1 qt (0.9 L) of oil to drain into drain pan. Release plunger.
- (6) Install drain plug on transmission AOAP valve.
- (7) Inspect oil for coolant contamination.
- (8) If oil is contaminated, replace transmission oil cooler (para 8-10).
- (9) Shut down engine (TM 9-2320-366-10-1).
- (10) Fill transmission (Appendix H).




X.BF2502B

f25. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)


KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Engine does not overheat. Transmission oil cooler tubes OK. Transmission oil cooler OK.
POSSIBLE PROBLEMS
Faulty transmission auxiliary oil cooler. Faulty transmission oil filters. Faulty WTEC III cab transmission harness. Faulty transmission external wiring harness. Faulty WTEC III transmission ECU.

4.
Does transmission auxiliary oil cooler fan operate?

TEST OPTIONS
Auxiliary Oil Cooler Fan Test
REASON FOR QUESTION
Transmission may overheat if fan does not operate which will cause WTEC III TPSS to display main code 24 and/or 33 sub code 23.




- | AUXILIARY OIL COOLER FAN TEST |
|--|
| (1) Raise cab (TM 9-2320-366-10-1). |
| (2) Disconnect connector clamp from water temperature sensor. |
| (3) Disconnect connector P36 from water temperature sensor (S56) to de-energize relay K15 and provide power to auxiliary oil cooler fan. |
| (4) Position master power switch to on (TM 9-2320-366-10-1). |
| (5) Check if auxiliary oil cooler fan comes on. |
| (6) If fan does not come on, perform Electrical System Troubleshooting (e148. Transmission Auxiliary Oil Cooler Fan Does Not Operate (All Models Except M1088/M1089) or e149. M1088/M1089 Transmission Auxiliary Oil Cooler Fan Does Not Operate). |
| (7) Position master power switch to off (TM 9-2320-366-10-1). |
| (8) Connect connector P36 to water temperature sensor (S56). |
| (9) Connect connector clamp on water temperature sensor. |
| (10) Lower cab (TM 9-2320-366-10-1). |




TRANSMISSION
AUXILIARY
OIL COOLER


TRANSMISSION
AUXILIARY OIL
COOLER FAN



CONNECTOR
CLAMP



CONNECTOR
P36



WATER TEMPERATURE
SENSOR (S56)


XBF2503B

f25. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Engine does not overheat. Transmission oil cooler tubes OK. Transmission oil cooler OK.
POSSIBLE PROBLEMS
Faulty transmission auxiliary oil cooler. Faulty transmission oil filters. Faulty WTEC III cab transmission harness. Faulty transmission external wiring harness. Faulty WTEC III transmission ECU.

5.
Are transmission auxiliary oil cooler fins free from dirt, mud, or other debris?

TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
Transmission may overheat if auxiliary oil cooler fins are plugged with debris which will cause WTEC III TPSS to display main code 24 and/or 33 sub code 23.




NOTE

M1088/M1089 are equipped with two transmission auxiliary oil cooler fans.

- (1) Check if transmission auxiliary oil cooler fins are plugged with dirt, mud, or other debris.
- (2) If fins are plugged with dirt, mud or other debris, clean transmission auxiliary oil cooler fins.


f25. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Engine does not overheat. Transmission oil cooler tubes OK. Transmission oil cooler OK.
POSSIBLE PROBLEMS
Faulty transmission oil filters. Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.



TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
Plugged transmission oil filters may cause WTEC III TPSS to display main code 24 and/or 33.


⊥ Check transmission oil filters for damage (para 8-9).



XB F2504B

f25. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)


KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Engine does not overheat. Transmission oil cooler tubes OK. Transmission oil cooler OK. Transmission oil filters OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.



TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, WTEC III cab transmission harness is faulty.

CONTINUITY TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Remove kick panel (para 16-3).
- (6) Disconnect connector clamp from connector P114.
- (7) Disconnect connector P114 from WTEC III transmission ECU.
- (8) Install jumper wire from connector J119d to connector J119a.
- (9) Set multimeter to ohms.
- (10) Connect positive (+) probe of multimeter to P114-27.
- (11) Connect negative (-) probe of multimeter to connector P114-25 and note reading on multimeter.
- (12) Connect negative (-) probe of multimeter to all other sockets in connector P114, one at a time, and note reading on multimeter.
- (13) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (14) Connect positive (+) probe of multimeter to connector P114-25.
- (15) Connect negative (-) probe of multimeter to all sockets in connector P114 (except P114-27), one at a time, and note reading on multimeter.
- (16) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (17) If continuity is not present in step 11, or continuity is present in step 12, 13, 15, or 16, replace WTEC III cab transmission harness (para 7-138).
- (18) Remove jumper wire from connector J119.
- (19) Connect connector P114 to WTEC III transmission ECU.
- (20) Connect connector clamp on connector P114.
- (21) Install kick panel (para 16-3).




XBF2505B

f25. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 24 AND/OR 33 AND ANY SUB CODE (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Engine does not overheat. Transmission oil cooler tubes OK. Transmission oil cooler OK. Transmission oil filters OK. WTEC III cab transmission harness OK.
POSSIBLE PROBLEMS
Faulty WTEC III transmission ECU.

8.
Is correct resistance present, and no short circuits found, from connector P119a to P119d?

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If correct resistance is not present or short circuits are found, DS Maintenance needs to be notified. If correct resistance is present and no short circuits are found, WTEC III transmission ECU is faulty.



RESISTANCE TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P119a.

NOTE

Transmission sump oil temperature sensor resistance reading is affected by temperature. Refer to Table 2-34. Transmission Sump Oil Temperature Sensor Resistance Readings for details.

- (3) Connect negative (-) probe of multimeter to connector P119d and note reading on multimeter.
- (4) Connect negative (-) probe of multimeter to all other pins in connector P119, one at a time, and note reading on multimeter.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) Connect positive (+) probe of multimeter to connector P119d.
- (7) Connect negative (-) probe of multimeter to all other pins in connector P119 (except P119a), one at a time, and note reading on multimeter.
- (8) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (9) If correct resistance is not present in step 3, or continuity is present in step 4, 5, 7, or 8, notify DS Maintenance.
- (10) If correct resistance is present in step 3 and continuity is not present in step 4, 5, 7, or 8, replace WTEC III transmission ECU (para 8-7).
- (11) Connect connector P119 to connector J119.
- (12) Position front grille on cab with washer and screw.
- (13) Position two washers and screws in front grille.
- (14) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (15) Tighten two screws to 24 lb-in. (3 N·m).
- (16) Clear diagnostic codes (para 8-5).




Table 2-34. Transmission Sump Oil Temperature Sensor Resistance Readings

Temperature	Resistance
-4° to 14°F (-20° to -10°C)	691-754 ohms
14° to 32°F (-10° to 0°C)	754-820 ohms
32° to 50°F (0° to 10°C)	820-889 ohms
50° to 68°F (10° to 20°C)	889-962 ohms
68° to 86°F (20° to 30°C)	962-1039 ohms
86° to 104°F (30° to 40°C)	1039-1118 ohms
104° to 122°F (40° to 50°C)	1118-1202 ohms
122° to 140°F (50° to 60°C)	1202-1286 ohms


f26. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 32 AND ANY SUB CODE

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

References
 TM 9-4910-571-12&P

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 STE/ICE-R (Item 41, Appendix C)



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Remove kick panel (para 16-3).
- (6) Disconnect connector clamp from connector P114.
- (7) Disconnect connector P114 from WTEC III transmission ECU.
- (8) Set multimeter to ohms.
- (9) Connect positive (+) probe of multimeter to connector J119j.
- (10) Connect negative (-) probe of multimeter to connector P114-12 and note reading on multimeter.
- (11) Connect negative (-) probe of multimeter to all other sockets in connector P114, one at a time, and note reading on multimeter.
- (12) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (13) If continuity is not present in step 10, or continuity is present in step 11 or 12, replace WTEC III cab transmission harness (para 7-138).




XBF 2601B

f26. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 32 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Batteries OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.


2.
Is continuity present from connector J119h to connector P114-13?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, WTEC III cab transmission harness is faulty.



CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector J119h.
- (3) Connect negative (-) probe of multimeter to connector P114-13 and note reading on multimeter.
- (4) If continuity is not present, replace WTEC III cab transmission harness (para 7-138).
- (5) Connect connector P119 to connector J119.
- (6) Position front grille on cab with washer and screw.
- (7) Position two washers and screws in front grille.
- (8) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (9) Tighten two screws to 24 lb-in. (3 N·m).




XBF2602B

f26. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 32 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Batteries OK. WTEC III cab transmission harness OK.
POSSIBLE PROBLEMS
Faulty WTEC III transmission ECU.

3.
Does main code 32 appear on WTEC III TPSS with new WTEC III transmission ECU installed?

TEST OPTIONS
WTEC III Transmission ECU Replacement Check
REASON FOR QUESTION
If WTEC III transmission ECU is faulty, WTEC III TPSS may display main code 32.



WTEC III TRANSMISSION ECU REPLACEMENT CHECK
--

- | |
|--|
| <ol style="list-style-type: none">(1) Remove original WTEC III transmission ECU (para 8-7).(2) Install replacement WTEC III transmission ECU (para 8-7).(3) Install kick panel (para 16-3).(4) Start engine (TM 9-2320-366-10-1).(5) Road test vehicle and read WTEC III transmission ECU codes (para 8-5).(6) If main code 32 does not appear with new WTEC III transmission ECU, replace WTEC III transmission ECU (para 8-7).(7) If main code 32 does appear with new WTEC III transmission ECU, notify DS Maintenance.(8) Shut down engine (TM 9-2320-366-10-1).(9) Install original WTEC III transmission ECU (para 8-7).(10) Clear diagnostic codes (para 8-5). |
|--|

f27. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 42, 44, 45, 46, 66, AND/OR 69 AND ANY SUB CODE


INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools (Cont)
 Wrench, Torque, 0-75 lb-in. (Item 90, Appendix B)
 STE/ICE-R (Item 41, Appendix C)

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)

References
 TM 9-4910-571-12&P




CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.



- CONTINUITY TEST**
- (1) Remove two screws and washers from front grille.
 - (2) Remove screw and washer from front grille.
 - (3) Remove front grille from cab.
 - (4) Disconnect connector P119 from connector J119.
 - (5) Remove kick panel (para 16-3).
 - (6) Disconnect connector clamp from connector P114.
 - (7) Disconnect connector P114 from WTEC III transmission ECU.
 - (8) Install jumper wire on connector J119 for appropriate sub code. Refer to Table 2-35. WTEC III Cab Transmission Harness Transmission Solenoid Test Points.
 - (9) Set multimeter to ohms.
 - (10) Connect positive (+) probe of multimeter to connector P114. Refer to Table 2-35. WTEC III Cab Transmission Harness Transmission Solenoid Test Points.
 - (11) Connect negative (-) probe of multimeter to connector P114 and note reading on multimeter. Refer to Table 2-35. WTEC III Cab Transmission Harness Transmission Solenoid Test Points.
 - (12) Connect negative (-) probe of multimeter to all other sockets in connector P114, one at a time, and note reading on multimeter.
 - (13) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
 - (14) If continuity is not present, in step 11, or continuity is present in step 12 or 13, replace WTEC III cab transmission harness (para 7-138).
 - (15) Remove jumper wire from connector J119.
 - (16) Connect connector P119 to connector J119.

Table 2-35. WTEC III Cab Transmission Harness Transmission Solenoid Test Points


Sub Code	Jumper Across	Connector P114	
		Positive (+) Probe	Negative (-) Probe
12	J119M to J119B	P114-1	P114-4
13	J119T to J119N	P114-2	P114-20
14	J119C to J119V	P114-5	P114-17
15	J119W to J119B	P114-1	P114-21
16	J119U to J119N	P114-2	P114-6
21	J119F to J119H	P114-3	P114-22
22	J119D to J119V	P114-7	P114-17
23	J119P to J119S	P114-19	P114-23
24	J119J to J119B	P114-1	P114-8
26	J119K to J119A	P114-19	P114-24
27	J119M to J119B	P114-1	P114-4

f27. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 42, 44, 45, 46, 66, AND/OR 69 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Batteries OK. WTEC III cab transmission harness OK.
POSSIBLE PROBLEMS
Faulty circuit from P119 to affected solenoid. Faulty WTEC III transmission ECU.

2.
Is correct solenoid resistance present at connector P119?

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If correct resistance is not present at connector P119, DS Maintenance needs to be notified.



RESISTANCE TEST

- (1) Disconnect connector P119 from connector J119.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector P119. Refer to Table 2-36. Connector P119 Transmission Solenoid Resistance Test Points for appropriate sub code(s) and connector P119 pin(s).
- (4) Connect negative (-) probe of multimeter to connector P119 and note reading on multimeter. Refer to Table 2-36. Connector P119 Transmission Solenoid Resistance Test Points for appropriate sub code(s) and connector P119 pin(s).

NOTE

Transmission solenoid resistance is affected by temperature. Refer to Table 2-37. Transmission Solenoid Resistance Readings.

- (5) If resistance reading indicates transmission solenoid is good, replace WTEC III transmission ECU (para 8-7).
- (6) If resistance reading indicates transmission solenoid is faulty, notify DS Maintenance.
- (7) Connect connector P119 to connector J119.
- (8) Position front grille on cab with washer and screw.
- (9) Position two washers and screws in front grille.
- (10) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (11) Tighten two screws to 24 lb-in. (3 N·m).
- (12) Clear diagnostic codes (para 8-5).




Table 2-36. Connector P119 Transmission Solenoid Resistance Test Points

Sub Code	Connector P119	
	Positive (+) Probe	Negative (-) Probe
12	P119M	P119B
13	P119T	P119N
14	P119C	P119V
15	P119W	P119B
16	P119U	P119N
21	P119F	P119H
22	P119D	P119V
23	P119P	P119S
24	P119J	P119B
26	P119K	P119A
27	P119M	P119B

Table 2-37. Transmission Solenoid Resistance Readings

Temperature	Resistance
4° to 16°F (-20° to -10°C)	2.50-3.12 ohms
16° to 32°F (-10° to 0°C)	2.62-3.25 ohms
32° to 50°F (0° to 10°C)	2.74-3.38 ohms
50° to 68°F (10° to 20°C)	2.86-3.50 ohms
68° to 86°F (20° to 30°C)	2.98-3.62 ohms
86° to 104°F (30° to 40°C)	3.09-3.75 ohms
104° to 122°F (40° to 50°C)	3.21-3.88 ohms
122° to 140°F (50° to 60°C)	3.33-4.00 ohms


f28. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 52 AND ANY SUB CODE

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

References
 TM 9-4910-571-12&P

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 STE/ICE-R (Item 41, Appendix C)



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille on cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Remove kick panel (para 16-3).
- (6) Disconnect connector clamp from connector P114.
- (7) Disconnect connector P114 from WTEC III transmission ECU.
- (8) Set multimeter to ohms.
- (9) Connect positive (+) probe of multimeter to connector J199h.
- (10) Connect negative (-) probe of multimeter to connector P114-13 and note reading on multimeter.
- (11) If continuity is not present, replace WTEC III cab transmission harness (para 7-138).




XBF 2801B

f28. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 52 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Batteries OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.


2.
Is continuity present from connector J119j to connector P114-12 and absent from J119j to all other P114 sockets and ground?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present from connector J119j to connector P114-12, or continuity is present from J119j to any other P114 sockets or ground, WTEC III cab transmission harness is faulty.




CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector J119j.
- (3) Connect negative (-) probe of multimeter to connector P114-12 and note reading on multimeter.
- (4) Connect negative (-) probe of multimeter to all other sockets in connector P114, one at a time, and note reading on multimeter.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) If continuity is not present in step 3, or continuity is present in step 4 or 5, replace WTEC III cab transmission harness (para 7-138).



J119



P114


XBF2802B

f28. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 52 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Batteries OK. WTEC III cab transmission harness OK.
POSSIBLE PROBLEMS
Faulty WTEC III transmission ECU.



3.
Is high resistance (20,000 ohms or higher) present from connector P119h to P119j?

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If resistance is high (20,000 ohms or higher), WTEC III transmission ECU is faulty.



RESISTANCE TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P119h.
- (3) Connect negative (-) probe of multimeter to connector P119j and note reading on multimeter.
- (4) If resistance is high (20,000 ohms or higher), replace WTEC III transmission ECU (para 8-7).
- (5) If resistance is low (less than 20,000 ohms), notify DS maintenance.
- (6) Install instrument panel assembly (para 7-15).
- (7) Connect connector P119 to connector J119.
- (8) Position front grille on cab with washer and screw.
- (9) Position two washers and screws in front grille.
- (10) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (11) Tighten two screws to 24 lb-in. (3 N·m).
- (12) Connect connector P114 to WTEC III transmission ECU.
- (13) Connect connector clamp on connector P114.
- (14) Install kick panel (para 16-3).
- (15) Clear diagnostic codes (para 8-5).



f29. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 57 AND ANY SUB CODE

INITIAL SETUP


Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench Set, Socket (Item 51, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)

Materials/Parts
 Packing, Preformed (Item 197, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

Personnel Required
 (2)

References
 TM 9-491-571-12&P




WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- CLUTCH PRESSURE TEST**
- (1) Remove front and intermediate propeller shafts (para 9-2).
 - (2) Position drain pan under C3 pressure tap plug.
 - (3) Remove C3 pressure tap plug and preformed packing from control valve module. Discard preformed packing.
 - (4) Connect tube to boss adapter, hose, and pipe to tube adapter to C3 pressure tap.
 - (5) Perform STE/ICE-R Test # 50 (TM 9-4910-571-12&P).
 - (6) Start engine (TM 9-2320-366-10-1) and run at idle.
 - (7) With parking brake applied, make shift indicated by sub code while assistant notes reading on STE/ICE-R. Refer to Table 2-38. Sub Code Range.
 - (8) If pressure does not drop to zero in selected range indicated by code values, notify DS Maintenance.
 - (9) Shut down engine (TM 9-2320-366-10-1).
 - (10) Remove pipe to tube adapter, hose, and tube to boss adapter from C3 pressure tap.
 - (11) Position preformed packing and C3 pressure tap plug in control valve module.
 - (12) Tighten C3 pressure tap plug to 84-120 lb-in. (9-14 N·m).
 - (13) Remove drain pan under C3 pressure tap plug.
 - (14) Install front and intermediate propeller shafts (para 9-2).




XBF2901B

Table 2-38. Sub Code Range

Sub Code	Sub Code Meaning	
11	1st	Range VER
22	2nd	Range VER
44	4th	Range VER
66	6th	Range VER
88	N1	Range VER
99	N2/N4	Range VER

f29. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 57 AND ANY SUB CODE (CONT)



CAUTION



Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

RESISTANCE TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter on P119h.
- (7) Connect negative (-) probe of multimeter on P119j.
- (8) If 2 ohms (or less) resistance is present, notify DS Maintenance.
- (9) If resistance is greater than 2 ohms, replace WTEC III transmission ECU (para 8-7).
- (10) Connect connector P119 to connector J119.
- (11) Position front grille on cab with washer and screw.
- (12) Position two washers and screws in front grille.
- (13) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (14) Tighten two screws to 24 lb-in. (3 N·m).
- (15) Clear diagnostic codes (para 8-5).



P119

XBF2902B

f30. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE


INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

References
 TM 9-4910-571-12&P

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 STE/ICE-R (Item 41, Appendix C)

Personnel Required
 (2)



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

Main display code 21 needs to be cleared manually from WTEC III transmission ECU after a maintenance task has been performed and before vehicle is returned to service (para 8-5).

WTEC III TRANSMISSION ECU RESET CHECK


- | |
|--|
| <ol style="list-style-type: none"> (1) Cycle master power switch to on (TM 9-2320-366-10-1), then to off five times to clear existing throttle count settings. (2) Position master power switch to on (TM 9-2320-366-10-1). (3) Depress accelerator pedal from idle position to full throttle position (TM 9-2320-366-10-1) to set new 0% and 100% throttle count values in WTEC III transmission ECU. (4) Clear diagnostic code from WTEC III transmission ECU display (para 8-5). (5) If main code 21 does not reappear, electrical communication between WTEC III transmission ECU and TPS may be faulty. If main code 21 reappears, TPS may be faulty. (6) Position master power switch to off (TM 9-2320-366-10-1). |
|--|

f30. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU. Faulty TPS cable assembly.

2.
Is main code 33 logged in conjunction with main code 21?

TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
Main code 21 in conjunction with main code 33 indicates loss of common ground.




- (1) Position master power switch to on (TM 9-2320-366-10-1).
- (2) Press MODE button on WTEC III TPSS to bring up second code (if any) (para 8-5).
- (3) If main code 33 displays on WTEC III TPSS, common ground may have been lost. If main code 21 is the only code displayed, TPS may be faulty. Go to step 4 of this fault.
- (4) Position master power switch to off (TM 9-2320-366-10-1).

f30. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK. TPS cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.


3.
Is continuity for common ground present from connector P114-25 to connector J119Z and J119a?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity for common ground is absent, main code 33 will be logged in addition to main code 21.



CONTINUITY TEST

- (1) Remove two screws and washers from front grille.
- (2) Remove screw and washer from front grille.
- (3) Remove front grille from cab.
- (4) Disconnect connector P119 from connector J119.
- (5) Remove kick panel (para 16-3).
- (6) Disconnect connector clamp from connector P114.
- (7) Disconnect connector P114 from WTEC III transmission ECU.
- (8) Set multimeter to ohms.
- (9) Connect positive (+) probe of multimeter to connector P114-25.
- (10) Connect negative (-) probe of multimeter to connector J119a and note reading on multimeter.
- (11) Connect negative (-) probe of multimeter to connector J119Z and note reading on multimeter.
- (12) If continuity is not present from connector P114-25 to connector J119a and J119Z, replace WTEC III cab transmission harness (para 7-138).
- (13) If continuity is present, replace WTEC III transmission ECU (para 8-7).
- (14) Connect connector P114 to WTEC III transmission ECU.
- (15) Connect connector clamp on connector P114.
- (16) Install kick panel (para 16-3).
- (17) Connect connector P119 to connector J119.
- (18) Position front grille on cab with washer and screw.
- (19) Position two washers and screws in front grille.
- (20) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (21) Tighten two screws to 24 lb-in. (3 N·m).
- (22) Clear diagnostic codes (para 8-5).




XBF3001B

f30. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE (CONT)


KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK.
POSSIBLE PROBLEMS
Faulty TPS cable assembly. Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.

TEST OPTIONS
Linkage Test
REASON FOR QUESTION
Main code 21 will be displayed on WTEC III TPSS if TPS cable assembly is out of adjustment.




KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK.
POSSIBLE PROBLEMS
Faulty TPS cable assembly. Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
Main code 21 will be displayed on WTEC III TPSS if TPS cable assembly is faulty.




LINKAGE TEST

- (1) Raise cab (TM 9-2320-366-10-1).
- (2) Verify distance between hitch pin clip on end of sensor rod and center of cable groove in ferrule is 4 in. (10 cm).
- (3) If distance is not 4 in. (10 cm), adjust bracket assembly to obtain correct measurement.



RESISTANCE TEST

- (1) Disconnect connector P73 from TPS connector.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to TPS terminal A.
- (4) Connect negative (-) probe of multimeter to TPS terminal C and verify multimeter reads between 9,000-15,000 ohms across terminals A and C.
- (5) Disconnect negative (-) probe of multimeter from terminal C.
- (6) Connect negative (-) probe of multimeter to TPS terminal B and note record on multimeter.
- (7) Move governor linkage to high idle stop and record reading on multimeter.
- (8) Return governor linkage to low idle stop.
- (9) Verify that difference between highest (high idle) reading and lowest (low idle) reading is between 4,000 and 6,000 ohms.
- (10) Verify that highest (high idle) reading does not exceed 15,000 ohms.
- (11) If resistance readings are not within limits, replace TPS cable assembly (para 4-16).



XBf 3002b


f30. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK. TPS cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.

KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK. TPS cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.


6.
Is continuity present from connector P73 to connector P119?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, DS Maintenance needs to be notified.




7.
Are TPS wires free from short circuits at connector P119?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If any TPS wire is shorted, DS Maintenance needs to be notified.




CONTINUITY TEST

- (1) Disconnect connector P119 from connector J119.
- (2) Set multimeter to ohms.
- (3) Connect positive (+) probe of multimeter to connector P119R.
- (4) Connect negative (-) probe of multimeter to connector P73 pin C and note reading on multimeter.
- (5) Connect positive (+) probe of multimeter to connector P119f.
- (6) Connect negative (-) probe of multimeter to connector P73 pin B and note reading on multimeter.
- (7) Connect positive (+) probe of multimeter to connector P119Z.
- (8) Connect negative (-) probe of multimeter to connector P73 pin A and note reading on multimeter.
- (9) If continuity is not present on one or more wires, notify DS Maintenance.



CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P119R.
- (3) Connect negative (-) probe of multimeter to all other pins in connector P119, one at a time, and note reading on multimeter.
- (4) If continuity is found between pin R and any other pin, notify DS Maintenance.
- (5) Perform steps (2) and (3) for P119f and P119Z.
- (6) If continuity is found between pin f and any other pin, or between pin Z and any other pin, notify DS Maintenance.
- (7) Connect connector P73 to TPS connector.




XBF 3003B

f30. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK. TPS cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.

8.
Is continuity present from connector J119 to connector P114?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, WTEC III cab transmission harness is faulty.




CONTINUITY TEST

- (1) Lower cab (TM 9-2320-366-10-1).
- (2) Remove two screws and washers from front grille.
- (3) Remove screw and washer from front grille.
- (4) Remove front grille from cab.
- (5) Remove kick panel (para 16-3).
- (6) Disconnect connector clamp from connector P114.
- (7) Disconnect connector P114 from WTEC III transmission ECU.
- (8) Set multimeter to ohms.
- (9) For each line of Table 2-39. Cab Transmission Harness Continuity Check:
 - (a) Install jumper wire across sockets in column 1.
 - (b) Connect positive (+) probe of multimeter to socket in column 2.
 - (c) Connect negative (-) probe of multimeter to socket in column 3 and note reading on multimeter.
- (10) If continuity is not present on any wire in Table 2-39. Cab Transmission Harness Continuity Check, replace WTEC III cab transmission harness (para 7-138).
- (11) Remove jumper wire from connector J119.

Table 2-39. Cab Transmission Harness Continuity Check

COLUMN 1 Jumper Across:	Column 2 Positive (+) Probe to:	Column 3 Negative (-) Probe to:
J119f to J119Z	P114-10	P114-25
J119f to J119R	P114-10	P114-9
J119R to J119Z	P114-25	P114-9




x2f30041

f30. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 21 AND ANY SUB CODE (CONT)

KNOWN INFO
Fuse OK. Transmission oil level OK. Batteries OK. TPS cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC III cab transmission harness. Faulty WTEC III transmission ECU.


9.
Are TPS wires free from short circuits at connector P114?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If short circuits are present, WTEC III cab transmission harness is faulty.



CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P114-9.
- (3) Connect negative (-) probe of multimeter to all other sockets of connector P114, one at a time, and note reading on multimeter.
- (4) Connect positive (+) probe of multimeter to connector P114-10.
- (5) Connect negative (-) probe of multimeter to all other sockets of connector P114, one at a time, and note reading on multimeter.
- (6) Connect positive (+) probe of multimeter to connector P114-25.
- (7) Connect negative (-) probe of multimeter to all other sockets of connector P114 (except P114-13), one at a time, and note reading on multimeter.
- (8) If continuity is present in step 3, 5, or 7, replace WTEC III cab transmission harness (para 7-138).
- (9) If no short circuits are found, replace WTEC III transmission ECU (para 8-7).
- (10) Connect connector P114 to WTEC III transmission ECU.
- (11) Connect connector clamp on connector P114.
- (12) Install kick panel (para 16-3).
- (13) Connect connector P119 to connector J119.
- (14) Position front grille on cab with washer and screw.
- (15) Position two washers and screws in front grille.
- (16) Tighten screw to 48-60 lb-in. (5-7 N·m).
- (17) Tighten two screws to 24 lb-in. (3 N·m).
- (18) Clear diagnostic codes (para 8-5).



XBF 3005B

f31. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 51 AND ANY SUB CODE

INITIAL SETUP

Equipment Conditions

Engine shut down (TM 9-2320-366-10-1).

Materials/Parts

Packing, Preformed (Item 197, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)


Tools and Special Tools

Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench, Torque 0-200 lb in. (Item 59, Appendix C)

Personnel Required
(2)

Wrench Set, Socket (Item 51, Appendix C)

References
TM 9-4910-571-12&P




CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Check if main code 22 sub code 15 or 16 is logged in WTEC III TPSS (para 8-5).
- (2) If main code 22 sub code 15 or 16 is logged, WTEC III transmission ECU has sensed a fault with the turbine speed sensor, output sensor, or associated circuits. Perform Transmission System Troubleshooting (f23. WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 15 or f24. WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code16).


f31. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 51 AND ANY SUB CODE (CONT)



WARNING

Wear approved eye protection when performing transmission pressure checks. If oil contacts eyes, seek medical attention immediately. Failure to comply may result in injury to personnel.

- CLUTCH PRESSURE TEST**
- (1) Remove front and intermediate propeller shafts (para 9-2).
 - (2) Position drain pan under pressure tap.
 - (3) Remove pressure tap plug and preformed packing from off-going clutch indicated by the sub code, refer to Table 2-40. Off-Going Clutch Pressure Tap. Discard preformed packing.
 - (4) Connect tube to boss adapter, hose, and pipe to tube adapter to clutch pressure tap.
 - (5) Perform STE/ICE-R Test # 50 (TM 9-4910-571-12&P).
 - (6) Start engine (TM 9-2320-366-10-1) and run at idle.
 - (7) With parking brake applied, make shift indicated by sub code while assistant notes reading on STE/ICE-R. Refer to Table 2-40. Off-Going Clutch Pressure Tap.
 - (8) If one or more off-going clutches fail to loose pressure, notify DS Maintenance.
 - (9) Shut down engine (TM 9-2320-366-10-1).
 - (10) Remove pipe to tube adapter, hose, and tube to boss adapter from clutch pressure tap.
 - (11) Position preformed packing and pressure tap plug in control valve module.
 - (12) Tighten pressure tap plug to 84-120 lb-in. (9-14 N-m).
 - (13) Remove drain pan under pressure tap.
 - (14) Install front and intermediate propeller shafts (para 9-2).
 - (15) Clear diagnostic codes (para 8-5).



XBF3101B

Table 2-40. Off-Going Clutch Pressure Tap

Sub Code	Sub Code Meaning	Off-Going Clutch	Solenoid Assembly Location
10	2-1 Downshift	C5	Stationary Clutch
12	2-3 Upshift	C5	Stationary Clutch
21	3-2 Downshift	C4	Stationary Clutch
23	3-4 Upshift	C4	Stationary Clutch
43	5-4 Downshift	C2	Rotating Clutch
45	5-6 Upshift	C1	Rotating Clutch
65	7-6 Downshift	C4	Stationary Clutch

f32. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 25 AND ANY SUB CODE

INITIAL SETUP

Equipment Conditions

Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools

Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)

Wrench Set, Socket (Item 51, Appendix C)

Materials/Parts


Packing, Preformed (Item 197, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

Personnel Required

(2)

References

TM 9-4910-571-12&P




CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Check if main code 22 sub code 16 is logged in the WTEC III TPSS (para 8-5).
- (2) If main code 22 sub code 16 is logged, WTEC III transmission ECU has sensed a fault with the output speed sensor or its circuit. Perform Transmission System Troubleshooting (f24. WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 16).

f32. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 25 AND ANY SUB CODE (CONT)



WARNING

Wear approved eye protection when performing transmission pressure checks. If oil contacts eyes, seek medical attention immediately. Failure to comply may result in injury to personnel.

CLUTCH PRESSURE TEST (CONT)

- (19) If all clutches indicate proper pressure, replace WTEC III transmission ECU (para 8-7).
- (20) Clear diagnostic codes (para 8-5).

CLUTCH PRESSURE TEST

- (1) Remove front and intermediate propeller shafts (para 9-2).
- (2) Position drain pan under pressure tap.
- (3) Remove pressure tap plug and preformed packing from clutch pressure tap indicated by the sub code. Refer to Table 2-41. Clutch Pressure Tap. Discard preformed packing.
- (4) Connect tube to boss adapter, hose, and pipe to tube adapter to clutch pressure tap.
- (5) Perform STE/ICE-R Test # 50 (TM 9-4910-571-12&P).
- (6) Start engine (TM 9-2320-366-10-1).
- (7) With brake applied, make shift indicated by sub code. Refer to Table 2-41. Clutch Pressure Tap.
- (8) Accelerate engine until WTEC III TPSS displays desired range. Refer to Table 2-41. Clutch Pressure Tap.
- (9) Maintain engine speed to keep desired transmission range while assistant notes reading on STE/ICE-R.
- (10) Let engine return to idle.
- (11) Shift transmission into neutral (TM 9-2320-366-10-1).
- (12) Shut down engine (TM 9-2320-366-10-1).
- (13) Remove pipe to tube adapter, hose, and tube to boss adapter from pressure tap.
- (14) Position preformed packing and pressure tap plug in control valve module.
- (15) Tighten pressure tap plug to 84-120 lb-in. (9-14 N·m).
- (16) Remove drain pan under pressure tap.
- (17) Install front and intermediate propeller shafts (para 9-2).
- (18) If one or more clutches fail to indicate proper pressure, notify DS Maintenance.




Table 2-41. Clutch Pressure Tap

XBF3201B

Sub Code	Sub Code Meaning	Pressure at Clutch(s)	Pressure Readings at Taps
00	Speed Zero in 1st	C3 & C6	215-334 psi (1480-2300 kPa)
11	Speed Zero in 2nd	C1 & C5	215-305 psi (1480-2103 kPa)
22	Speed Zero in 3rd	C1 & C4	142-203 psi (980-1400 kPa)
33	Speed Zero in 4th	C1 & C3	142-203 psi (980-1400 kPa)
44	Speed Zero in 5th	C1 & C2	142-203 psi (980-1400 kPa)
55	Speed Zero in 6th	C2 & C3	128-189 psi (880-1300 kPa)
66	Speed Zero in 7th	C2 & C4	128-189 psi (880-1300 kPa)
77	Speed Zero in R	C3 & C5	215-334 psi (1480-2300 kPa)

f33. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 53 AND ANY SUB CODE

INITIAL SETUP

Equipment Conditions

Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools


- Goggles, Industrial (Item 15, Appendix C)
- Tool Kit, Genl Mech (Item 46, Appendix C)
- STE/ICE-R (Item 41, Appendix C)
- Pan, Drain (Item 24, Appendix C)
- Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
- Wrench Set, Socket (Item 51, Appendix C)

Materials/Parts

- Packing, Preformed (Item 197, Appendix G)
- Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
- Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
- Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

Personnel Required
(2)

References
TM 9-4910-571-12&P



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Check if main code 22 sub code 15 or 16 is logged in WTEC III TPSS (para 8-5).
- (2) If main code 22 sub code 15 or 16 is logged, WTEC III transmission ECU has sensed a fault with turbine speed sensor, output speed sensor, or associated circuits. Perform Transmission System Troubleshooting (f23. WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 15 or f24. WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 16).

f33. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 53 AND ANY SUB CODE (CONT)


KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK. Turbine speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC III transmission ECU.

2.

WARNING
Read WARNING on following page.

Does off-going clutch pressure go to 8 psi (55kPa) or less when shift is made?

TEST OPTIONS
Clutch Pressure Test or STE/ICE-R Test #50
REASON FOR QUESTION
If off-going clutch oil pressure does not go to 8 psi (55 kPa) or less when shifts is made, WTEC III TPSS may display main code 53 and one or sub codes.




WARNING

Wear approved eye protection when performing transmission pressure checks. If oil contacts eyes, seek medical attention immediately. Failure to comply may result in injury to personnel.

CLUTCH PRESSURE TEST

- (1) Remove front and intermediate propeller shafts (para 9-2).
- (2) Position drain pan under pressure tap.
- (3) Remove pressure tap plug and preformed packing from off-going clutch indicated by the sub code. Refer to Table 2-42. Off-Going Clutch Pressure Tap. Discard preformed packing.
- (4) Connect tube to boss adapter, hose, and pipe to tube adapter to clutch pressure tap.
- (5) Perform STE/ICE-R Test # 50 (TM 9-4910-571-12&P).
- (6) Start engine (TM 9-2320-366-10-1) and run at idle.
- (7) With parking brake applied, make shift indicated by sub code while assistant notes reading on STE/ICE-R. Refer to Table 2-42. Off-Going Clutch Pressure Tap.
- (8) If off-going clutch pressure does not go to 8 psi (55 kPa) or less when shift is made, notify DS Maintenance.
- (9) If off-going clutch pressure does go to 8 psi (55 kPa) or less when shift is made, replace WTEC III transmission ECU (para 8-7).
- (10) Shut down engine (TM 9-2320-366-10-1).
- (11) Remove pipe to tube adapter, hose, and tube to boss adapter from clutch pressure tap.
- (12) Position preformed packing and pressure tap plug in control valve module.
- (13) Tighten pressure tap plug to 84-120 lb-in. (9-14 N·m).
- (14) Remove drain pan under pressure tap.
- (15) Install front and intermediate propeller shafts (para 9-2).
- (16) Clear diagnostic codes (para 8-5).



**C1, C2, C3, C4
CLUTCH PRESSURE TAPS**

Xbf3301b

Table 2-42. Off-Going Clutch Pressure Tap

Sub Code	Sub Code Meaning	Off-Going Clutch(s)
08	L-N1 Shift	C3
18	1-N1 Shift	C1
28	2-N1 Shift	C1 & C4
29	2-N2 Shift	C1
38	3-N1 Shift	C1 & C3
39	3-N3 Shift	C1
48	4-N1 Shift	C1 & C2
49	4-N3 Shift	C1 & C2
58	5-N1 Shift	C2 & C3
59	5-N3 Shift	C2
68	6-N1 Shift	C2 & C4
69	6-N4 Shift	C2
78	R-N1 Shift	C2 or C4
79	N3-N2 or N2-N3 Shift	C3

f34. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 54 AND ANY SUB CODE

INITIAL SETUP

Equipment Conditions

Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools


Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 Wrench Set, Socket (Item 51, Appendix C)

Materials/Parts

Packing, Preformed (Item 197, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

Personnel Required
(2)

Reference
TM 9-4910-571-12&P



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Check if main code 22 sub code 15 or 16 is logged in WTEC III TPSS (para 8-5).
- (2) If main code 22 sub code 15 or 16 is logged, WTEC III transmission ECU has sensed a fault with the turbine speed sensor, output speed sensor, or associated circuits. Perform Transmission System Troubleshooting (f23. WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 15 or f24. WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 16).

f34. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 54 AND ANY SUB CODE (CONT)


KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK. Turbine speed sensor OK.
REASON FOR QUESTION
Faulty WTEC III transmission ECU.

2.

WARNING
Read WARNING
on following page.

Is 218-276 psi
(1,503-1,903 kPa) present
at main oil pressure tap?

TEST OPTIONS
Pressure Test or STE/ICE-R Test #50
REASON FOR QUESTION
Low main oil pressure may cause WTEC III TPSS to display main code 54 and one or more sub codes.




WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

PRESSURE TEST

- (1) Position drain pan under pressure tap.
- (2) Remove main pressure tap plug and preformed packing from control valve assembly.
- (3) Connect tube to boss adapter, hose, and pipe to tube adapter to main pressure tap.
- (4) Perform STE/ICE-R Test #50 (TM 9-4910-571-12&P).
- (5) Start engine (TM 9-2320-366-10-1) and run at idle.
- (6) With parking brake applied, position WTEC III TPSS to R position then to N position while assistant checks reading on STE/ICE-R.
- (7) Shut down engine (TM 9-2320-366-10-1).
- (8) If main oil pressure is low, notify DS Maintenance.
- (9) Remove pipe to tube adapter, hose, and tube to boss adapter from main pressure tap.
- (10) Position preformed packing and main pressure tap plug in control valve module.
- (11) Tighten main pressure tap plug to 84-120 lb-in. (9-14 N·m).




XBF3401B

f34. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 54 AND ANY SUB CODE (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC III transmission ECU.

3.
Is there pressure to clutch(s) when shift is made?

TEST OPTIONS
Pressure Test or STE/ICE-R Test #50
REASON FOR QUESTION
If there is no pressure to clutch(s) when shift is made, WTEC III TPSS may display main code 54 and one or more sub codes.



CLUTCH PRESSURE TEST

- (1) Remove front and intermediate propeller shafts (para 9-2).
- (2) Position drain pan under pressure tap.
- (3) Remove pressure tap plug and preformed packing from clutch pressure tap indicated by the sub code. Refer to Table 2-43. Clutch Pressure Tap.
- (4) Connect tube to boss adapter, hose, and pipe to tube adapter to clutch pressure tap.
- (5) Start engine (TM 9-2320-366-10-1).
- (6) Perform STE/ICE-R Test #50 (TM 9-4910-571-12&P).
- (7) With parking brake applied, make shift indicated by sub code. Refer to Table 2-43. Clutch Pressure Tap.
- (8) Accelerate engine until WTEC III TPSS displays denied range. Refer to Table 2-43. Clutch Pressure Tap.
- (9) Maintain sufficient engine speed to keep desired transmission range while assistant notes reading on STE/ICE-R.
- (10) Let engine return to idle.
- (11) Shift WTEC III TPSS into neutral.
- (12) If one or more clutches failed to indicate proper pressure, notify DS Maintenance.
- (13) If all clutches indicate proper pressure, replace WTEC III transmission ECU (para 8-7).
- (14) Shut down engine (TM 9-2320-366-10-1).
- (15) Remove pipe to tube adapter, hose, and tube to boss adapter from clutch pressure tap.
- (16) Position preformed packing and pressure tap plug in control valve module.
- (17) Tighten pressure tap plug to 84-120 lb-in. (9-14 N·m).
- (18) Remove drain pan under pressure tap.
- (19) Install front and intermediate propeller shafts (para 9-2).
- (20) Clear diagnostic codes (para 8-5).

Table 2-43. Clutch Pressure Tap

Sub Code	Sub Code Meaning	Pressure at Clutch(s)	Pressure Readings at Taps
01	L-1 Upshift	C1 & C5	187-305 psi (1280-2100 kPa)
07	L-R Shift	C3 & C5	215-276 psi (1480-1900 kPa)
10	1-L Downshift	C3 & C6	215-334 psi (1480-2300 kPa)
12	1-2 Upshift	C1 & C4	142-203 psi (980-1400 kPa)
17	1-R Shift	C3 & C5	215-276 psi (1480-1900 kPa)
21	2-1 Downshift	C1 & C5	186-305 psi (1280-2100 kPa)
23	2-3 Upshift	C1 & C3	142-203 psi (980-1400 kPa)
27	2-R Shift	C3 & C5	215-334 psi (1480-2300 kPa)
32	3-2 Downshift	C1 & C4	142-203 psi (980-1400 kPa)
34	3-4 Upshift	C1 & C2	142-203 psi (980-1400 kPa)
43	4-3 Downshift	C1 & C3	142-203 psi (980-1400 kPa)
45	4-5 Upshift	C2 & C3	128-189 psi (880-1300 kPa)
54	5-4 Downshift	C1 & C2	142-203 psi (980-1400 kPa)
56	5-6 Upshift	C2 & C4	128-189 psi (880-1300 kPa)
65	6-5 Downshift	C2 & C3	128-189 psi (880-1300 kPa)
70	R-L Shift	C3 & C6	142-203 psi (980-1400 kPa)
71	R-1 Shift	C1 & C5	186-305 psi (1280-2100 kPa)
72	R-2 Shift	C1 & C4	142-203 psi (980-1400 kPa)
80	N1-L Shift	C3 & C6	215-276 psi (1480-1900 kPa)
81	N1-1 Shift	C1 & C5	215-305 psi (1480-2100 kPa)
82	N1-2 Shift	C1 & C4	186-305 psi (1280-2100 kPa)
83	N1-3 Shift	C1 & C3	215-305 psi (1480-2100 kPa)
85	N1-5 Shift	C2 & C3	164-239 psi (1130-1650 kPa)
86	N1-6 Shift	C2 & C4	164-239 psi (1130-1650 kPa)
92	N2-2 Shift	C1 & C4	215-305 psi (1480-2100 kPa)
93	N3-3 Shift	C1 & C3	215-305 psi (1480-2100 kPa)
95	N3-5 Shift	C2 & C3	164-239 psi (1130-1650 kPa)
96	N4-6 Shift	C2 & C4	164-239 psi (1130-1650 kPa)
97	2-R Shift	C3 & C5	215-305 psi (1480-2100 kPa)

f35. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 55 AND ANY SUB CODE

INITIAL SETUP


Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).



Tools and Special Tools
 Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 Wrench Set, Socket (Item 51, Appendix C)

Materials/Parts
 Packing, Preformed (Item 197, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

Personnel Required
 (2)

References
 TM 9-4910-571-12&P



- 
- 
- (1) Check transmission oil level (TM 9-2320-366-10-1).
 - (2) If transmission oil level is improper, correct as required (TM 9-2320-366-10-1).

f35. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 55 AND ANY SUB CODE (CONT)


KNOWN INFO
Transmission oil level OK.
POSSIBLE PROBLEMS
Faulty WTEC III transmission ECU.

2.

CAUTION
Read CAUTION
on following page.

Is main code 55 logged
without main code 32?

TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
If main code 32 is logged, C3 pressure switch or its circuit is faulty.



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Check if main code 32 is logged in WTEC III TPSS (para 8-5).
- (2) If main code 32 is logged, WTEC III transmission ECU has sensed a fault with the C3 pressure switch or its circuit. Perform Transmission System Troubleshooting (f26. WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 32 and Any Sub Code).

f35. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 55 AND ANY SUB CODE (CONT)


KNOWN INFO
Transmission oil level OK.
POSSIBLE PROBLEMS
Faulty WTEC III transmission ECU.

3.

WARNING
Read WARNING
on following page.

Is 218-276 psi
(1,503-1,903 kPa) present
at main oil pressure tap?

TEST OPTIONS
Pressure Test or STE/ICE-R Test #50
REASON FOR QUESTION
Low main oil pressure may cause WTEC III TPSS to display main code 55 and one or more sub codes.




WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

PRESSURE TEST

- (1) Position drain pan under pressure tap.
- (2) Remove main pressure tap plug and preformed packing from control valve module.
- (3) Connect tube to boss adapter, hose, and pipe to tube adapter to main pressure tap.
- (4) Perform STE/ICE-R Test #50 (TM 9-4910-571-12&P).
- (5) Start engine (TM 9-2320-366-10-1) and run at idle.
- (6) With parking brake applied, position WTEC III TPSS to R position then to N position while assistant checks reading on STE/ICE-R.
- (7) Shut down engine (TM 9-2320-366-10-1).
- (8) If main oil pressure is low, notify DS Maintenance.
- (9) Remove pipe to tube adapter, hose, and tube to boss adapter from main pressure tap.
- (10) Position preformed packing and main pressure tap plug in control valve module.
- (11) Tighten main pressure tap plug to 84-120 lb-in. (9-14 N·m).
- (12) Remove drain pan under pressure tap.




XBF3501B

f35. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 55 AND ANY SUB CODE (CONT)

KNOWN INFO
Transmission oil level OK
POSSIBLE PROBLEMS
Faulty WTEC III transmission ECU.

4.
Is pressure present at C3 clutch when shift is made?

TEST OPTIONS
Pressure Test or STE/ICE-R Test #50
REASON FOR QUESTION
If pressure is low or missing to C3 clutch when shift is made, WTEC III TPSS may display main code 55 and one or more sub codes.




PRESSURE TEST

- (1) Remove front and intermediate propeller shafts (para 9-2).
- (2) Position drain pan under C3 pressure tap.
- (3) Remove C3 pressure tap plug and preformed packing from control valve module.
- (4) Connect tube to boss adapter, hose, and pipe to tube adapter to C3 pressure tap.
- (5) Perform STE/ICE-R test #50 (TM 9-4910-571-12&P).
- (6) Start engine (TM 9-2320-366-10-1) and run at idle.
- (7) With parking brake applied, make shift indicated by sub code while assistant notes reading on STE/ICE-R.
- (8) Shut down engine (TM 9-2320-366-10-1).
- (9) If 215-276 psi (1480-1900 kPa) pressure is not obtained for affected code, notify DS Maintenance.
- (10) If 215-276 psi (1480-1900 kPa) pressure is obtained, replace WTEC transmission ECU (para 8-7).
- (11) Remove pipe to tube adapter, hose, and tube to boss adapter from C3 pressure tap.
- (12) Position preformed packing and C3 pressure tap plug on control valve module.
- (13) Tighten C3 pressure tap plug to 84-120 lb-in. (9-14 N·m).
- (14) Remove drain pan under pressure tap.
- (15) Install front and intermediate propeller shafts (para 9-2).
- (16) Clear diagnostic codes (para 8-5).

Table 2-44. Clutch Pressure Tap

Sub Code	Sub Code Meaning	Pressure Readings C3 Tap
17	1-R Shift	215-276 psi (1480-1900 kPa)
27	2-R Shift	215-276 psi (1480-1900 kPa)
80	N1-L Shift	215-276 psi (1480-1900 kPa)
87	N1-R Shift	215-276 psi (1480-1900 kPa)
97	2-R Shift	215-276 psi (1480-1900 kPa)



XBF3502B

f36. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 56 AND ANY SUB CODE

INITIAL SETUP

Equipment Conditions

Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools


Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Pan, Drain (Item 24, Appendix C)
 Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)
 Wrench Set, Socket (Item 51, Appendix C)

Materials/Parts

Packing, Preformed (Item 197, Appendix G)
 Adapter, Straight, Pipe to Tube (Item 1.2, Appendix D)
 Adapter, Straight, Tube to Boss (Item 1.3, Appendix D)
 Hose Assembly, Nonmetallic (Item 24.13, Appendix D)

Personnel Required
(2)

References
TM 9-4910-571-12&P



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Check if main code 22 code 15 or 16 is logged in WTEC III TPSS (para 8-5).
- (2) If main code 22 sub code 15 or 16 is logged, WTEC III transmission ECU has sensed a fault with the turbine speed sensor, output speed sensor, or associated circuit(s).
Perform Transmission System Troubleshooting (f23. WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 15 or f24. WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 16).


f36. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 56 AND ANY SUB CODE (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK. Turbine speed sensor OK.
POSSIBLE PROBLEMS
Faulty WTEC III transmission ECU.

2. **WARNING**
Read WARNING on following page.

Is 218-276 psi (1,503-1,903 kPa) present at main oil pressure tap?

TEST OPTIONS
Pressure Test or STE/ICE-R TEST #50
REASON FOR QUESTION
Low main oil pressure may cause WTEC III TPSS to display main code 56 and one or more sub codes.




WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

PRESSURE TEST

- (1) Position drain pan under pressure tap.
- (2) Remove main pressure tap plug and preformed packing from control valve module.
- (3) Connect tube to boss adapter, hose, and pipe to tube adapter to main pressure tap.
- (4) Perform STE/ICE-R test #50 (TM 9-4910-571-12&P).
- (5) Start engine (TM 9-2320-366-10-1) and run at idle.
- (6) With parking brake applied, position WTEC III TPSS to R position then to N position while assistant checks reading on STE/ICE-R.
- (7) Shut down engine (TM 9-2320-366-10-1).
- (8) If main oil pressure is low, notify DS Maintenance.
- (9) Remove pipe to tube adapter, hose, and tube to boss adapter from main pressure tap.
- (10) Position preformed packing and main pressure tap plug in control valve module.
- (11) Tighten main pressure tap plug to 84-120 lb-in. (9-14 N·m).
- (12) Remove drain pan under pressure tap.



XBF3601B


f36. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 56 AND ANY SUB CODE (CONT)

KNOWN INFO
Transmission oil level OK. Fuse OK. Batteries OK. Output speed sensor OK. Turbine speed sensor OK. Main oil pressure OK.
POSSIBLE PROBLEMS
Faulty WTEC III transmission ECU.


3.

Is pressure present at clutch(s) when shift is made?

TEST OPTIONS
Pressure Test or STE/ICE-R Test #50
REASON FOR QUESTION
If pressure is low or missing to clutch(s) when shift is made, WTEC III TPSS may display main code 56 and one or more sub codes.



- PRESSURE TEST**
- (1) Remove front and intermediate propeller shafts (para 9-2).
 - (2) Position drain pan under pressure tap.
 - (3) Remove pressure tap plug and preformed packing from clutch pressure tap indicated by the sub code. Refer to Table 2-45. Clutch Pressure Tap.
 - (4) Connect tube to boss adapter, hose, and pipe to tube adapter to clutch pressure tap.
 - (5) Perform STE/ICE-R test #50 (TM 9-4910-571-12&P).
 - (6) Start engine (TM 9-2320-366-10-1).
 - (7) Make shift indicated by sub code. Refer to Table 2-45. Clutch Pressure Tap.
 - (8) Accelerate engine until WTEC III TPSS displays desired range. Refer to Table 2-45. Clutch Pressure Tap.
 - (9) Maintain sufficient engine speed to keep desired transmission range while assistant notes reading on STE/ICE-R.
 - (10) Let engine return to idle.
 - (11) Shift transmission into neutral (TM 9-2320-366-10-1).
 - (12) Shut down engine (TM 9-2320-366-10-1).
 - (13) If one or more of clutches failed to indicate proper pressure, notify DS Maintenance.
 - (14) If all clutches indicate proper pressure, replace WTEC III transmission ECU (para 8-7).
 - (15) Remove pipe to tube adapter, hose, and tube to boss adapter from clutch pressure tap.
 - (16) Position preformed packing and pressure tap plug in control valve module.
 - (17) Tighten pressure tap plug to 84-120 lb-in. (9-14 N·m).
 - (18) Remove drain pan under pressure tap.
 - (19) Install front and intermediate propeller shafts (para 9-2).
 - (20) Clear diagnostic codes (para 8-5).



XBFB3602B

Table 2-45. Clutch Pressure Tap

Sub Code	Sub Code Meaning	Pressure at Clutch(s)	Pressure Readings at Taps
00	L Range Test	C3 & C6	215-334 psi (1480-2300 kPa)
11	1 Range Test	C1 & C5	215-305 psi (1480-2100 kPa)
22	2 Range Test	C1 & C4	142-203 psi (980-1400 kPa)
33	3 Range Test	C1 & C3	142-203 psi (980-1400 kPa)
44	4 Range Test	C1 & C2	142-203 psi (980-1400 kPa)
55	5 Range Test	C2 & C3	128-189 psi (880-1300 kPa)
66	6 Range Test	C2 & C4	128-189 psi (880-1300 kPa)
77	R Range Test	C3 & C5	215-276 psi (1480-1900 kPa)

f37. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 13 AND ANY SUB CODE


INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

References
 TM 9-4910-571-12&P

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)
 STE/ICE-R (Item 41, Appendix C)

Personnel Required
 (2)



CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


- (1) Check to see if main code 13 sub code 12 is active in WTEC III TPSS (para 8-5).
- (2) If main code 13 sub code 12 is not active in WTEC III TPSS, go to step 7 of this fault.

f37. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 13 AND ANY SUB CODE (CONT)

KNOWN INFO
Vehicle runs. Batteries OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty WTEC III transmission ECU. Faulty WTEC III TPSS.


2.
Are connectors P115-1 and P115-16 free from short circuits to ground or to other wires?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If short circuits to ground or other wires are present, wire 136 is faulty.



CONTINUITY TEST

- (1) Remove kick panel (para 16-3).
- (2) Disconnect connector clamp from connector P115.
- (3) Disconnect connector P115 from WTEC III transmission ECU.
- (4) Set multimeter to ohms.
- (5) Connect positive (+) probe of multimeter to connector P115-1.
- (6) Connect negative (-) probe of multimeter to all other sockets in connector P115 (except P115-16), one at a time, and note reading on multimeter.
- (7) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (8) Connect positive (+) probe of multimeter to connector P115-16.
- (9) Connect negative (-) probe of multimeter to all other sockets in connector P115 (except P115-1), one at a time, and note reading on multimeter.
- (10) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (11) If continuity is present repair wire 136 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).




XBF3701B

f37. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 13 AND ANY SUB CODE (CONT)

KNOWN INFO
Vehicle runs. Batteries OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty WTEC III transmission ECU. Faulty WTEC III TPSS.


3.
Is 0.5 ohms, or less, resistance present from connectors P115-17 and P115-32 to ground?

TEST OPTIONS
Resistance Test or STE/ICE-R Test #91
REASON FOR QUESTION
If resistance is higher than 0.5 ohms, wire 143 is faulty.



RESISTANCE TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P115-17.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) Connect positive (+) probe of multimeter to connector P115-32.
- (5) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (6) If resistance noted in step 3 or step 5 is higher than 0.5 ohms, repair wire 143 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (7) Connect connector P115 to WTEC III transmission ECU.
- (8) Connect connector clamp on connector P115.




XBF3702B

f37. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 13 AND ANY SUB CODE (CONT)

KNOWN INFO
Vehicle runs. Batteries OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty WTEC III transmission ECU. Faulty WTEC III TPSS.





4.
Is continuity present from connector P116-16 to connector PX33R and no short circuits found?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, wire 136 is faulty.



CONTINUITY TEST

- (1) Disconnect connector clamp from connector P116.
- (2) Disconnect connector P116 from WTEC III transmission ECU.
- (3) Remove instrument panel assembly for access (para 7-15).
- (4) Disconnect connector PX33 from WTEC III TPSS.
- (5) Set multimeter to ohms.
- (6) Connect positive (+) probe of multimeter to connector P116-16.
- (7) Connect negative (-) probe of multimeter to connector PX33R and note reading on multimeter.
- (8) Connect negative (-) probe of multimeter to all other sockets in connector PX33, one at a time, and note reading on multimeter.
- (9) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (10) If continuity is not present in step 7, or continuity is present in step 8 or step 9, repair wire 136 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).




XBF3703B

f37. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 13 AND ANY SUB CODE (CONT)

KNOWN INFO
Vehicle runs. Batteries OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty WTEC III transmission ECU. Faulty WTEC III TPSS.




5.
Is continuity present from connector P116-32 to connector PX33P and no short circuits found?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, wire 143 is faulty.



CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P116-32.
- (3) Connect negative (-) probe of multimeter to connector PX33P and note reading on multimeter.
- (4) Connect negative (-) probe of multimeter to all other sockets in connector PX33, one at a time, and note reading on multimeter.
- (5) If continuity is not present in step 3, or continuity is present in step 4, repair wire 143 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (6) Connect connector PX33 to WTEC III TPSS.
- (7) Install instrument panel assembly (para 7-15).
- (8) Clear diagnostic codes (para 8-5).




XBF3704B

f37. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 13 AND ANY SUB CODE (CONT)

KNOWN INFO
Vehicle runs. Batteries OK. WTEC III dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC III transmission ECU. Faulty WTEC III TPSS.


6.
Does main code 13 sub code 12 appear on WTEC III TPSS with replacement WTEC III transmission ECU installed?

TEST OPTIONS
WTEC III transmission ECU replacement check
REASON FOR QUESTION
If main code 13 sub code 12 is not active, WTEC III transmission ECU is faulty. If main code 13 sub code 12 is active, WTEC III TPSS is faulty.



WTEC III TRANSMISSION ECU REPLACEMENT CHECK
<ol style="list-style-type: none">(1) Install replacement WTEC III transmission ECU (para 8-7).(2) Start engine (TM 9-2320-366-10-1).(3) Check to see if main code 13 sub code 12 appears on WTEC III TPSS (para 8-5).(4) If main code 13 sub code 12 does not appear, replace WTEC III transmission ECU (para 8-7).(5) If main code 13 sub code 12 does appear, replace WTEC III TPSS (para 8-3).(6) Shut down engine (TM 9-2320-366-10-1).(7) Install original WTEC III transmission ECU (para 8-7).(8) Clear diagnostic codes (para 8-5).

f37. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 13 AND ANY SUB CODE (CONT)




WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuit and cause severe burns or electrical shock.

VOLTAGE TEST

- (1) Start engine (TM 9-2320-366-10-1).
- (2) Remove dust cap from DCA connector.
- (3) Set multimeter to volts dc.
- (4) Connect positive (+) probe of multimeter to DCA connector terminal N.
- (5) Connect negative (-) probe of multimeter to DCA connector terminal P and note reading on multimeter.
- (6) If 33 VDC or more is present, replace 100 amp voltage regulator (para 7-5) or 200 amp voltage regulator (para 20-46).
- (7) If 24-32 is present, replace WTEC III transmission ECU (para 8-7).
- (8) Install dust cap on DCA connector.
- (9) Clear diagnostic codes (para 8-5).
- (10) Shut down engine (TM 9-2320-366-10-1).





XBF3705B

f38. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) LED DISPLAYS "- ."
AND/OR TRANSMISSION DOES NOT SHIFT GEARS

INITIAL SETUP

Equipment Conditions
 Engine running (TM 9-2320-366-10-1).




- 
- (1) Perform WTEC III Code Reading and Code Clearing (para 8-5).
 - (2) If no diagnostic codes are logged after clearing, fault is corrected.
 - (3) If diagnostic codes are still logged, perform Transmission System Troubleshooting of active diagnostic codes per para 8-25, Table 8-2. WTEC III Diagnostic Code List and Description.

f39. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 23 AND ANY SUB CODE	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools (Cont) Wrench Set, Socket (Item 51, Appendix C)
Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multimeter, Digital (Item 22, Appendix C) STE/ICE-R (Item 41, Appendix C) Wrench, Torque, 0-200 lb-in. (Item 59, Appendix C)	Personnel Required (2)
	References TM 9-4910-571-12&P

NOTE

Perform electrical system troubleshooting e1. Circuit Breaker Does Not Operate on circuit breakers C43 and CB79 prior to beginning this task.




CAUTION

Loose or dirty connectors may cause intermittent loss of power to transmission ECU and diagnostic codes to be logged. Ensure that all connectors are clean and tight before performing troubleshooting. Failure to comply may result in incorrect test results.

- (1) Perform WTEC III Code Reading and Code Clearing (para 8-5).
- (2) If diagnostic code 23 is not logged after clearing, fault is corrected.
- (3) If diagnostic code 23 is logged after clearing, further troubleshooting is required.

f39. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 23 AND ANY SUB CODE (CONT)



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION


Use care when testing electrical connectors not to bend connector pins or damage connector sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Remove kick panel (para 16-3).
- (2) Disconnect connector clamp from connector P115
- (3) Disconnect connector P115 from WTEC III transmission ECU connector.
- (4) Set multimeter to volts DC.
- (5) Connect positive (+) probe of multimeter to connector P115 socket 1.
- (6) Connect negative (-) probe of multimeter to a known good ground and note reading on multimeter.
- (7) Connect positive (+) probe of multimeter to connector P115 socket 16.
- (8) Connect negative (-) probe of multimeter to a known good ground and note reading on multimeter.
- (9) If 24 VDC is not present in steps (6) and (8), repair wire 136 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).




f39. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 23 AND ANY SUB CODE (CONT)

KNOWN INFO
Circuit breaker CB43 and CB79 OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty WTEC III transmission ECU. Faulty WTEC III TPSS.


3.
Is continuity present from connector P115 sockets 17, 25, and 32 to ground?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, wire 143 is faulty.



CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector P115 socket 17.
- (3) Connect negative (-) probe of multimeter to a known good ground and note reading on multimeter.
- (4) If continuity is not present in step (3), repair wire 143 from connector P115-17 to terminal board 2 pin 27 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (5) Connect positive (+) probe of multimeter to connector P115 socket 25.
- (6) Connect negative (-) probe of multimeter to a known good ground and note reading on multimeter.
- (7) If continuity is not present in step (6), repair wire 144 from connector P115-25 to chassis ground (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (8) Connect positive (+) probe of multimeter to connector P115 socket 32.
- (9) Connect negative (-) probe of multimeter to a known good ground and note reading on multimeter.
- (10) If continuity is not present in step (9), repair wire 143 from connector P115-32 to terminal board 2 pin 16 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (11) Connect connector P115 to WTEC III Transmission ECU.
- (12) Connect connector clamp on connector P115.



XBF3902B


f39. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 23 AND ANY SUB CODE (CONT)

KNOWN INFO
Circuit Breakers CB 43 and CB79 OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty WTEC III TPSS. Faulty WTEC III transmission ECU.

4. **CAUTION**
Read CAUTION on following page.

Is continuity present from connector P116 socket 3 to connector PX33 socket N and no short circuits found?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, wire 124 is faulty.



CAUTION




Use care when testing electrical connectors not to bend connector pins or damage connector sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Disconnect connector clamp from connector P116.
- (2) Disconnect connector P116 from WTEC III transmission ECU.
- (3) Remove instrument panel assembly for access (para 7-15).
- (4) Disconnect connector PX33 from WTEC III TPSS.
- (5) Connect positive (+) probe of multimeter to connector P116 socket 3.
- (6) Connect negative (-) probe of multimeter to connector PX33 socket N and note reading on multimeter.
- (7) Connect negative probe (-) of multimeter to all other sockets in connector PX33, one at a time, and note reading on multimeter.
- (8) Connect negative probe (-) of multimeter to ground and note reading on multimeter.
- (9) If continuity is not present in step 6, or continuity is present in step 7 or step 8, repair wire 124 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).



XBF3903B


f39. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 23 AND ANY SUB CODE (CONT)

KNOWN INFO
Circuit Breakers CB 43 and CB79 OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty WTEC III TPSS. Faulty WTEC III transmission ECU.

5. **CAUTION**
Read CAUTION on following page.

Is continuity present from connector P116 socket 32 to connector PX33 socket P and no short circuits found?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, or short circuits are found, wire 143 is faulty.



CAUTION





Use care when testing electrical connectors not to bend connector pins or damage connector sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Connect positive (+) probe of multimeter to connector P116 socket 32.
- (2) Connect negative (-) probe of multimeter to connector PX33 socket P and note reading on multimeter.
- (3) Connect negative probe (-) of multimeter to all other sockets in connector PX33, one at a time, and note reading on multimeter.
- (4) Connect negative probe (-) of multimeter to ground and note reading on multimeter.
- (5) If continuity is not present in step 2, or continuity is present in step 3 or step 4, repair wire 143 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (6) Connect connector P116 to WTEC III transmission ECU.
- (7) Connect connector clamp on connector P116.




XBF3904B

f39. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DISPLAYS MAIN CODE 23 AND ANY SUB CODE (CONT)

KNOWN INFO
Circuit Breakers CB43 and CB79 OK. WTEC III dashboard cable assembly OK.
POSSIBLE PROBLEMS
Faulty WTEC III TPSS. Faulty WTEC III transmission ECU.


6.
Does main code 23 appear on WTEC III TPSS with a known good WTEC III TPSS installed?

TEST OPTIONS
WTEC III TPSS replacement check.
REASON FOR QUESTION
If main code 23 does not appear, WTEC III TPSS is faulty. If main code 23 does appear, WTEC III transmission ECU is faulty.




WTEC III TPSS REPLACEMENT CHECK

- (1) Replace WTEC III TPSS with a known good WTEC III TPSS (para 8-3).
- (2) Start engine (TM 9-2320-365-10).
- (3) Observe if main code 23 appears on WTEC III TPSS (para 8-5).
- (4) If main code 23 does not appear, replace WTEC III TPSS (para 8-3).
- (5) If main code 23 does appear, replace WTEC III transmission ECU (para 8-7).
- (6) Shut down engine (TM 9-2320-365-10).
- (7) Install original WTEC III TPSS (para 8-3).
- (8) Connect connector PX33 to WTEC III TPSS.
- (9) Install instrument panel assembly (para 7-15).
- (10) Install kick panel (para 16-3).
- (11) Clear diagnostic codes (para 8-5).



**WTEC III
TRANSMISSION
ECU**

**WTEC III
TPSS**



**CONNECTOR
PX33**

XBF3905B

f40. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DOES NOT ILLUMINATE

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).
 Kick panel removed (para 16-3).


Personnel Required
 (2)

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 STE/ICE-R (Item 41, Appendix C)
 Multimeter, Digital (Item 22, Appendix C)

References
 TM 9-4910-571-12&P

NOTE

Perform Electrical System Troubleshooting e1. CIRCUIT BREAKER DOES NOT OPERATE on circuit breakers CB43 and CB79 prior to beginning this task.



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

VOLTAGE TEST

- (1) Disconnect connector clamp from connector P115.
- (2) Disconnect connector P115 from WTEC III ECU.
- (3) Set multimeter to volts DC.
- (4) Connect positive (+) probe of multimeter to connector P115 socket 16.
- (5) Connect negative (-) probe of multimeter to ground note reading on multimeter.
- (6) If 24 VDC is not present, repair wire 136 from connector P115 sockets 16 to circuit breaker CB43 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).



XBF4001B

f40. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DOES NOT ILLUMINATE (CONT)


KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB43 OK. Circuit breaker CB79 OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty terminal board TB1. Faulty WTEC III ECU. Faulty WTEC III TPSS.

2.

WARNING
CAUTION
Read WARNING and CAUTION on following page.

Is 24 VDC present at connector P115 socket 1?

TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
If 24 VDC is not present, WTEC III dashboard cable assembly is faulty.



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

VOLTAGE TEST

- (1) Set multimeter to volts DC.
- (2) Connect positive (+) probe of multimeter to connector P115 socket 1.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If 24 VDC is not present, repair wire 136 from connector P115 sockets 1 to circuit breaker CB43 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).



XBF4002B

f40. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DOES NOT ILLUMINATE (CONT)


KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB43 OK. Circuit breaker CB79 OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty terminal board TB1. Faulty WTEC III ECU. Faulty WTEC III TPSS.

3.

WARNING
CAUTION
Read WARNING and CAUTION on following page.

Is 24 VDC present at connector P116 socket 4?

TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

VOLTAGE TEST

- (1) Connect connector P115 to WTEC III ECU.
- (2) Connect connector clamp to connector P115.
- (3) Disconnect connector clamp from connector P116.
- (4) Disconnect connector P116 from WTEC III ECU.
- (5) Set multimeter to volts DC.
- (6) Connect positive (+) probe of multimeter to connector P116 socket 4.
- (7) Connect negative (-) probe of multimeter to ground.
- (8) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (9) Position master power switch to off (TM 9-2320-366-10-1).
- (10) If 24 VDC is not present, go to step 7 of this fault.



XBF 4003B

f40. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DOES NOT ILLUMINATE (CONT)


KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB43 OK. Circuit breaker CB79 OK. Terminal board TB1 OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty WTEC III ECU. Faulty WTEC III TPSS.

4.

WARNING
CAUTION
Read WARNING and CAUTION on following page.

Is 24 VDC present at connector PX33 socket R?

TEST OPTIONS
Voltage Test or STE/ICE-R Test #89
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.



WARNING

Remove rings, bracelets, watches, necklaces, and any other jewelry before working around vehicle. Jewelry can catch on equipment and cause injury or short across electrical circuits and cause severe burns or electrical shock.

CAUTION





Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

VOLTAGE TEST

- (1) Connect connector P116 to WTEC III ECU.
- (2) Connect connector clamp to connector P116.
- (3) Remove instrument panel for access (para 7-15).
- (4) Disconnect connector PX33 from WTEC III TPSS.
- (5) Set multimeter to volts DC.
- (6) Connect positive (+) probe of multimeter to connector PX33 socket R.
- (7) Connect negative (-) probe of multimeter to ground.
- (8) Position master power switch to on (TM 9-2320-366-10-1) and note reading on multimeter.
- (9) Position master power switch to off (TM 9-2320-366-10-1).
- (10) If 24 VDC is not present, go to step 9 of this fault.



XBF4004B

f40. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DOES NOT ILLUMINATE (CONT)


KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB43 OK. Circuit breaker CB79 OK. Terminal board TB1 OK. WTEC III ECU OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty WTEC III TPSS.

5.

CAUTION
Read CAUTION
on following page.

Is continuity present from connector PX33 socket T to known good ground?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, WTEC III dashboard cable assembly is faulty.



CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.


CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector PX33 socket T.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, Repair wire 186 from connector PX33 socket T to terminal board TB2 position 15 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).



XBF4005B

f40. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DOES NOT ILLUMINATE (CONT)



CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Set multimeter to ohms.
- (2) Connect positive (+) probe of multimeter to connector PX33 socket V.
- (3) Connect negative (-) probe of multimeter to ground and note reading on multimeter.
- (4) If continuity is not present, Repair wire 188 from connector PX33 socket V to terminal board TB2 position 13 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (5) If continuity is present, replace WTEC III TPSS (para 8-3).



XBF4006B

f40. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DOES NOT ILLUMINATE (CONT)


KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB43 OK. Circuit breaker CB79 OK. WTEC III ECU OK. WTEC III TPSS OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty terminal board TB1.

7.

CAUTION
Read CAUTION on following page.

Is continuity present from connector P116 socket 4 to terminal board TB1 position 60?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, WTEC III dashboard cable assembly is faulty.



CAUTION


Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Disconnect batteries (para 7-57).
- (2) Remove PDP cover (para 16-2).
- (3) Remove three screws from PDP.
- (4) Remove three screws and washers from PDP.
- (5) Lift PDP outward to gain access.
- (6) Set multimeter to ohms.
- (7) Connect positive (+) probe of multimeter to connector P116 socket 4.
- (8) Connect negative (-) probe of multimeter to terminal board TB1 position 60 and note reading on multimeter.
- (9) If continuity is not present, Repair wire 146 from connector P116 socket 4 to terminal board TB1 position 60 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (10) Connect connector P116 to WTEC III ECU.
- (11) Connect connector clamp to connector P116.
- (12) Install kick panel (para 16-3).




XBF4007B

f40. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DOES NOT ILLUMINATE (CONT)

KNOWN INFO
12 VDC and 24 VDC circuits operate. Circuit breaker CB43 OK. Circuit breaker CB79 OK. WTEC III ECU OK. WTEC III TPSS OK.
POSSIBLE PROBLEMS
Faulty WTEC III dashboard cable assembly. Faulty terminal board TB1.



8.
Is continuity present from terminal board TB1 position 60 to terminal board TB1 position 62?

TEST OPTIONS
Continuity Test or STE/ICE-R Test #91
REASON FOR QUESTION
If continuity is not present, terminal board TB1 is faulty. If continuity is present, WTEC III dashboard cable assembly is faulty.




- | CONTINUITY TEST | |
|-----------------|---|
| (1) | Set multimeter to ohms. |
| (2) | Connect positive (+) probe of multimeter to terminal board TB1 position 60. |
| (3) | Connect negative (-) probe of multimeter to terminal board TB1 position 62 and note reading on multimeter. |
| (4) | If continuity is not present, replace terminal board TB1 (para 7-11). |
| (5) | If continuity is present, Repair wire 1690 from terminal board TB1 position 62 to circuit breaker CB79 (para 2-45) or replace WTEC II dashboard cable assembly (para 7-11). |
| (6) | Install PDP on dashboard with three screws. |
| (7) | Install three washers and screws in PDP. |
| (8) | Install PDP cover (para 16-2). |
| (9) | Connect batteries (para 7-57). |

TERMINAL BOARD TB1




TERMINAL BOARD TB1



XBF4008B

f40. WTEC III TRANSMISSION PUSHBUTTON SHIFT SELECTOR (TPSS) DOES NOT ILLUMINATE (CONT)



CAUTION





Use care when testing electrical connectors. Do not damage connector pins or sockets with multimeter probes. Failure to comply may result in damage to equipment.

NOTE

Inspect connector pins/sockets for damage, corrosion, and serviceability. Check that connector pins are not pushed back and are capable of making good contact.

CONTINUITY TEST

- (1) Disconnect connector clamp from connector P116.
- (2) Disconnect connector P116 from WTEC III ECU.
- (3) Set multimeter to ohms.
- (4) Connect positive (+) probe of multimeter to connector PX33 socket R.
- (5) Connect negative (-) probe of multimeter to connector P116 socket 16 and note reading on multimeter.
- (6) If continuity is not present, repair wire 136 from connector PX33 socket R to connector P116 socket 16 (para 2-45) or replace WTEC III dashboard cable assembly (para 7-11).
- (7) If continuity is present, replace WTEC III ECU (para 8-7).
- (8) Connect connector PX33 to WTEC III TPSS.
- (9) Install instrument panel assembly (para 7-15).



XB4009B

2-18. PROPELLER SHAFT TROUBLESHOOTING

This paragraph covers Propeller Shaft Troubleshooting. The Propeller Shaft Fault Index, Table 2-46, lists faults for the drive shafts of the vehicle.

Table 2-46. Propeller Shaft Fault Index


Fault No.	Description	Page
g1.	Drive Shaft or Universal Joint Unusually Noisy When Operating	2-1824

g1. DRIVE SHAFT OR UNIVERSAL JOINT UNUSUALLY NOISY WHEN OPERATING

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Goggles, Industrial (Item 15, Appendix C)



KNOWN INFO
Nothing.
POSSIBLE PROBLEMS
Drive shaft require lubrication. Loose universal joint(s) bearing cap screws. Worn universal joints. Faulty drive shaft. Faulty M1086/M1089 coupler bearing or attaching hardware. Faulty M1086/M1089 intermediate front drive shaft.


KNOWN INFO
Drive shaft properly lubricated.
POSSIBLE PROBLEMS
Loose universal joint(s) bearing cap screws. Worn universal joints. Faulty drive shaft. Faulty M1086/M1089 coupler bearing or attaching hardware. Faulty M1086/M1089 intermediate front drive shaft.

WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

Lubricate drive shaft lubrication fittings (Appendix H).

- (1) Visually inspect universal joint(s) bearing cap screws for tightness.
- (2) Replace any screw(s) that appears to be loose (para 9-2).




Xbg0101b

g1. DRIVE SHAFT OR UNIVERSAL JOINT UNUSUALLY NOISY WHEN OPERATING (CONT)

KNOWN INFO
Drive shaft properly lubricated. Universal joint(s) bearing cap screws tight.
POSSIBLE PROBLEMS
Worn universal joints. Faulty drive shaft. Faulty M1086/M1089 coupler bearing or attaching hardware. Faulty M1086/M1089 intermediate front drive shaft.

3.
Are universal joints free from observable movement?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Drive shaft may operate unusually noisy if there is movement at universal joint.




KNOWN INFO
Drive shaft properly lubricated. Universal joint(s) bearing cap screws tight. Universal joints OK.
POSSIBLE PROBLEMS
Faulty drive shaft. Faulty M1086/M1089 coupler bearing or attaching hardware. Faulty M1086/M1089 intermediate front drive shaft.

4.
Does drive shaft pass drive shaft hinging inspection and visual inspection for damage?

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Drive shaft may operate unusually noisy if worn or damaged.



- (1) Check drive shaft for excessive movement at universal joints.
- (2) If universal joint(s) shows any movement, replace universal joint (para 9-2 or TM 9-2320-366-34).



Xbg0102b


- (1) Perform drive shaft hinging inspection (para 9-4).
- (2) Visually inspect drive shaft for damaged slip yoke, bent tubing, or missing balance weights.
- (3) If drive shaft does not pass hinging inspection or visual inspection, replace drive shaft (para 9-2 or TM 9-2320-366-34).

g1. DRIVE SHAFT OR UNIVERSAL JOINT UNUSUALLY NOISY WHEN OPERATING (CONT)


KNOWN INFO
Drive shaft properly lubricated. Universal joint(s) bearing cap screws tight. Universal joints OK. Drive shaft OK.
POSSIBLE PROBLEMS
Faulty M1086/M1089 coupler bearing or attaching hardware. Faulty M1086/M1089 intermediate front drive shaft.

5.
Are M1086/M1089 coupler bearing and attaching hardware secure?

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Drive shaft may operate unusually noisy if M1086/M1089 coupler bearing or attaching hardware is not secure.



- (1) Inspect M1086/M1089 coupler bearing attaching bolts and nuts for tightness. Tighten nuts to 66-81 lb-ft (90-110 N·m).
- (2) Inspect M1086/M1089 coupler bearing for any observable movement.
- (3) If any movement is observed at M1086/M1089 coupler bearing, notify DS Maintenance.



Xbg0103b


2-19. POWER TAKE-OFF (PTO) TROUBLESHOOTING

This paragraph covers Power Take-Off (PTO) Troubleshooting. The PTO Fault Index, Table 2-47, lists faults for the PTO.


Table 2-47. PTO Fault Index

Fault No.	Description	Page
h1.	Power Take-Off (PTO) Does Not Engage	2-1832

h1. POWER TAKE-OFF (PTO) DOES NOT ENGAGE	
INITIAL SETUP	
Equipment Conditions Engine running (TM 9-2320-366-10-1). Parking brake on (TM 9-2320-366-10-1). Wheels chocked (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C)



- (1) Engage PTO (TM 9-2320-366-10-1).
- (2) Check if PTO indicator lights.
- (3) If PTO indicator does not light, perform Electrical System Troubleshooting (e32. PTO Indicator Does Not Operate).
- (4) If PTO indicator does light, perform Electrical System Troubleshooting (e91. PTO Does Not Operate).
- (5) Disengage PTO (TM 9-2320-366-10-1).
- (6) Shut down engine (TM 9-2320-366-10-1).



X2H0101A

2-20. BRAKE SYSTEM TROUBLESHOOTING


This paragraph covers Brake System Troubleshooting. The Brake System Fault Index, Table 2-48, lists faults for the Brake System of the vehicle.

Table 2-48. Brake System Fault Index

Fault No.	Description	Page
i1.	Excessive Braking Distance	2-1836
i2.	Rear Brakes Do Not Apply	2-1848
i3.	Parking Brake Does Not Release	2-1878 ■
i4.	Front Brakes Overheat and/or Do Not Release	2-1904
i5.	Vehicle Brakes Unevenly, Brakes Pull to One Side or Grab	2-1910
i6.	Front Brakes Do Not Apply	2-1924
i7.	Rear Brakes Overheat	2-1934
i8.	Parking Brake Does Not Apply	2-1942
i9.	Brake System Loses Air When Service Brakes Are Applied	2-1946 ■

i1. EXCESSIVE BRAKING DISTANCE


INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Goggles, Industrial (Item 15, Appendix C) Tool Kit, Genl Mech (Item 46, Appendix C) Jack, Hydraulic, Hand (Item 21, Appendix C) Trestle, Motor Vehicle Maintenance (2) (Item 47, Appendix C) Tool, Spring Removal (Item 85, Appendix B)
Personnel Required (2)	



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

- (1) Apply brakes and observe operation of brake shoes at all rear wheels.
- (2) If brake shoes fail to apply at all rear wheels, rear brake system is faulty. Perform Brake System Troubleshooting (i2. Rear Brakes Do Not Apply).




X210101-

i1. EXCESSIVE BRAKING DISTANCE (CONT)

KNOWN INFO
Air tanks pressurized. Rear brakes apply OK.
POSSIBLE PROBLEMS
Front brakes do not apply. Faulty brake shoe adjustment. Faulty brake linings. Faulty return springs. Faulty detent washers. Faulty adjusting pawl. Faulty actuator. Faulty plunger chamber seals. Faulty wedge assemblies or brake chamber.

2.
Are front brakes operating?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Excessive braking distance may occur if front brakes do not apply.




KNOWN INFO
Air tanks pressurized. Rear brakes apply OK. Front brakes apply OK.
POSSIBLE PROBLEMS
Faulty brake shoe adjustment. Faulty brake linings. Faulty return springs. Faulty detent washers. Faulty adjusting pawl. Faulty actuator. Faulty plunger chamber seals. Faulty wedge assemblies or brake chamber.


3.
Are brake shoe clearances adjusted properly?

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Improperly adjusted brake shoes can cause excessive braking distance.





- (1) Apply brakes and observe operation of brake shoes at each front wheel.
- (2) If all shoes at front wheels fail to apply, front brake system is faulty. Perform Brake System Troubleshooting (i6. Front Brakes Do Not Apply).




- (1) Jack up axle with affected brakes and support with trestles.
- (2) Make periodic brake applications to position floating shoes.

NOTE

Over time a ridge will form on the outer edge of the brake shoes. This is normal and does not affect brake shoe serviceability.

- (3) Measure shoe clearance checking along centerline of shoe at scallop. Rotate wheel during check.
- (4) If clearance is not between .020" and .040", adjust brakes (para 11-2 or 11-3).

X210102-




TX210103

i1. EXCESSIVE BRAKING DISTANCE (CONT)

KNOWN INFO
Air tanks pressurized. Rear brakes apply OK. Front brakes apply OK. Brake shoes adjustment OK.
POSSIBLE PROBLEMS
Faulty brake linings. Faulty return springs. Faulty detent washers. Faulty adjusting pawl. Faulty actuator. Faulty plunger chamber seals. Faulty wedge assemblies or brake chamber.

4.
Are brake linings or drums free from damage?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Damaged or worn brake linings and drums will cause insufficient torque to stop vehicle.




KNOWN INFO
Air tanks pressurized. Rear brakes apply OK. Front brakes apply OK. Brake shoe adjustment OK. Brake linings OK.
POSSIBLE PROBLEMS
Faulty return springs. Faulty detent washers. Faulty adjusting pawl. Faulty actuator. Faulty plunger chamber seals. Faulty wedge assemblies or brake chamber.

5.
Are return springs free from damage?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A broken or damaged return spring will cause brake adjustment to fail.



- (1) Remove lugnuts and lift off wheel.
- (2) Slide brake drum off axle.
- (3) Inspect brake linings for worn, glazed, damaged condition, or contamination (para 11-2).
- (4) Inspect brake drum for, out of round, scoring, pitting, heat cracks, and blue scorch marks.



- (1) Detach each return spring from brake shoe.
- (2) Examine return spring for stretching, bluing, damage or breakage.
- (3) If return spring(s) is damaged, replace broken or damaged return spring (s) (para 11-2 or 11-3).




i1. EXCESSIVE BRAKING DISTANCE (CONT)

KNOWN INFO
Air tanks pressurized. Rear brakes apply OK. Front brakes apply OK. Brake shoe adjustment OK. Brake linings OK. Return springs OK.
POSSIBLE PROBLEMS
Faulty detent washers. Faulty adjusting pawl. Faulty actuator. Faulty plunger chamber seals. Faulty wedge assemblies or brake chamber.

6.
Are all detent washers free from damage?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Damaged detent washers will not allow automatic adjusters to operate properly.




KNOWN INFO
Air tanks pressurized. Rear brakes apply OK. Front brakes apply OK. Brake shoe adjustment OK. Brake linings OK. Return springs OK. Detent washers OK.
POSSIBLE PROBLEMS
Faulty adjusting pawl. Faulty actuator. Faulty plunger chamber seals. Faulty wedge assemblies or brake chamber.

7.
Are adjusting pawl springs present and free from damage and are pawl teeth free from damage?

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Automatic adjusters will not work if adjusting pawl springs are damaged or missing or if pawl teeth are damaged.




- (1) Remove brake shoes from clips on wheel hub.
- (2) Screw adjuster bolt out of plunger housing.
- (3) Check if detent washer is damaged or broken.
- (4) If detent washer is damaged, replace adjusting bolt assembly (para 11-4 or 11-5).



TX210106

- (1) Unscrew adjusting pawl from plunger housing.
- (2) Check adjusting pawl springs for damage. Ensure that springs are not missing or broken.
- (3) Check adjusting pawl teeth for damage and abrasion.




X210107-

i1. EXCESSIVE BRAKING DISTANCE (CONT)

KNOWN INFO
Air tanks pressurized. Rear brakes apply OK. Front brakes apply OK. Brake shoe adjustment OK. Brake linings OK. Return springs OK. Detent washers OK. Adjusting pawl OK.
POSSIBLE PROBLEMS
Faulty actuator. Faulty plunger chamber seals. Faulty wedge assemblies or brake chamber.

8.
Are actuator teeth free from damage?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Damaged actuator teeth will not allow automatic adjusters to operate properly.




KNOWN INFO
Air tanks pressurized. Rear brakes apply OK. Front brakes apply OK. Brake shoe adjustment OK. Brake linings OK. Return springs OK. Detent washers OK. Adjusting pawl OK. Actuator OK.
POSSIBLE PROBLEMS
Faulty plunger chamber seals. Faulty wedge assemblies or brake chamber.




9.
Are seals free from damage?

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Automatic adjusters will not work if seals are damaged and allow dirt to enter plunger chamber.






- (1) Lift actuator from plunger housing.
- (2) Check actuator teeth for damage.




- (1) Check that seal elements are not damaged or broken.
- (2) A damaged seal may permit dirt to enter plunger chamber and interfere with adjustment.






X210108-


i1. EXCESSIVE BRAKING DISTANCE (CONT)



- (1) Disconnect and tag air hoses to brake chambers at wheel.
- (2) Cage spring brakes on rear wheels (para 11-6).
- (3) Unscrew brake chamber(s) from hub.
- (4) Remove wedge assembly from wheel.
- (5) Inspect wedge spring for damage.
- (6) Inspect rollers for flattening or damage.
- (7) Manually check operation of wedge assembly in plunger chamber.
- (8) Insert wedge assembly into plunger chamber.
- (9) Screw brake chamber onto wheel hub (para 11-7 or 11-8).
- (10) Attach air hoses to brake chamber.
- (11) Uncage rear spring brakes (para 11-6).
- (12) Install plunger into plunger housing, open end up.
- (13) Align slot to accept pawl (para 11-4 or 11-5).
- (14) Install pawl and pawl spring into side of plunger housing.
- (15) Install actuator, seal, and adjustment bolt into head of plunger housing (para 11-4 or 11-5).
- (16) Install brake shoes into clips on wheel hub with leading (toe) edge of shoe fitting slot on head of adjusting bolt. Arrow stamped on shoe should point away from adjusting plunger (para 11-2 or 11-3).
- (17) Install return springs on brake shoes (para 11-2 or 11-3).
- (18) Install brake drum.
- (19) Adjust brake shoes (para 11-2 or 11-3).
- (20) Install wheel.
- (21) Raise vehicle and remove trestle.




i2. REAR BRAKES DO NOT APPLY	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Goggles, Industrial (Item 15, Appendix C)
Personnel Required (2)	




WARNING

- When working on parking brake control system vehicle may roll. Wheel shocks must be positioned in front of and behind one of the rear wheels to prevent it from rolling. Failure to comply may cause serious injury or death to personnel.
 - Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.
- (1) Loosen supply air hose at foot control valve.
 - (2) Check for presence of air. If no air is present, replace air hose (para 11-21).
 - (3) Tighten supply air hose to foot control valve.




i2. REAR BRAKES DO NOT APPLY (CONT)

KNOWN INFO
Front brakes OK. Air tanks pressurized. Supply air hose to foot control valve OK.
POSSIBLE PROBLEMS
Faulty foot control valve. Faulty air hoses at cab floor. Faulty air hose to check valve. Faulty check valve. Faulty air hose to control port of booster valve. Faulty air hose to supply port of booster valve. Faulty booster valve. Faulty air hose to load sensing valve. Faulty load sensing valve. Faulty air hose to control port of relay valve. Faulty air hose to supply port of relay valve. Faulty relay valve. Faulty air hoses to spring brakes. Faulty vent hose from spring brake service chamber. Faulty spring brake chamber.




TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A lack of air from delivery port of foot control valve will prevent air delivery to service brake chambers and cause brakes not to apply.






- (1) Loosen delivery air hose at foot control valve.
- (2) Apply brake and check for presence of air.
- (3) If no air is present, replace foot control valve (para 11-9).
- (3) Tighten delivery air hose on foot control valve.



i2. REAR BRAKES DO NOT APPLY (CONT)

KNOWN INFO
Front brakes OK. Air tanks pressurized. Supply air hose to foot control valve OK. Foot control valve OK.
POSSIBLE PROBLEMS
Faulty air hoses at cab floor. Faulty air hose to check valve. Faulty check valve. Faulty air hose to control port of booster valve. Faulty air hose to supply port of booster valve. Faulty booster valve. Faulty air hose to load sensing valve. Faulty load sensing valve. Faulty air hose to control port of relay valve. Faulty air hose to supply port of relay valve. Faulty relay valve. Faulty air hoses to spring brakes. Faulty vent hose from spring brake service chamber. Faulty spring brake chamber.





TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air hoses at cab floor junction are leaking or damaged, rear brakes may not apply.




- (1) Loosen delivery air hose at cab floor.
- (2) Apply brakes.
- (3) Check for presence of air from air hose when brake is applied.
- (4) If no air is present, replace air hose (para 11-21).
- (5) Tighten air hose at cab floor.
- (6) Raise cab (TM 9-2320-366-10-1).
- (7) Loosen delivery air hose under cab floor.
- (8) Apply foot brake.
- (9) Check for presence of air from fitting when brake is applied.
- (10) If no air is present, replace air hose and fitting (para 11-21).
- (11) Tighten air hose and fitting.

**REAR BRAKE
DELIVERY AIR HOSE
FROM FOOT CONTROL VALVE**




**FOOT BRAKE CONTROL VALVE
DELIVERY AIR HOSE FITTING
UNDER CAB FLOOR**



X210203A


i2. REAR BRAKES DO NOT APPLY (CONT)


KNOWN INFO
Front brakes OK. Air tanks pressurized. Supply air hose to foot control valve OK. Foot control valve OK. Air hoses at cab floor OK.
POSSIBLE PROBLEMS
Faulty air hose to check valve. Faulty check valve. Faulty air hose to control port of booster valve. Faulty air hose to supply port of booster valve. Faulty booster valve. Faulty air hose to load sensing valve. Faulty load sensing valve. Faulty air hose to control port of relay valve. Faulty air hose to supply port of relay valve. Faulty relay valve. Faulty air hoses to spring brakes. Faulty vent hose from spring brake service chamber. Faulty spring brake chamber.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A blocked or leaking air hose to the check valve will prevent air delivery to the check valve and will cause the rear brakes not to apply.




- 
- (1) Loosen supply air hose at check valve.
 - (2) Apply brakes.
 - (3) Check for presence of air at air hose when brake is applied.
 - (4) If no air is present, replace air hose (para 11-21).
 - (5) Tighten air hose at supply port of check valve.



X210204A

i2. REAR BRAKES DO NOT APPLY (CONT)

KNOWN INFO
Front brakes OK. Air tanks pressurized. Supply air hose to foot control valve OK. Foot control valve OK. Air hoses at cab floor OK. Air hose to check valve OK.
POSSIBLE PROBLEMS
Faulty check valve. Faulty air hose to control port of booster valve. Faulty air hose to supply port of booster valve. Faulty booster valve. Faulty air hose to load sensing valve. Faulty load sensing valve. Faulty air hose to control port of relay valve. Faulty air hose to supply port of relay valve. Faulty relay valve. Faulty air hoses to spring brakes. Faulty vent hose from spring brake service chamber. Faulty spring brake chamber.




TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A lack of air from the air delivery port of the check valve will not allow the rear brakes to be applied.



- (1) Loosen delivery air hose on check valve.
- (2) Apply brakes.
- (3) Check for presence of air from air hose when brake is applied.
- (4) If no air is present, replace check valve (para 11-16).
- (5) Tighten delivery air hose on check valve.

BRAKE CHECK VALVE




**SUPPLY AIR HOSE
FROM FOOT
CONTROL VALVE**

**DELIVERY AIR HOSE
TO BOOSTER VALVE**

X210205A

i2. REAR BRAKES DO NOT APPLY (CONT)


KNOWN INFO
Front brakes OK. Air tanks pressurized. Supply air hose to foot control valve OK. Foot control valve OK. Air hoses at cab floor OK. Air hose to check valve OK. Check valve OK.
POSSIBLE PROBLEMS
Faulty air hose to control port of booster valve. Faulty air hose to supply port of booster valve. Faulty booster valve. Faulty air hose to load sensing valve. Faulty load sensing valve. Faulty air hose to control port of relay valve. Faulty air hose to supply port of relay valve. Faulty relay valve. Faulty air hoses to spring brakes. Faulty vent hose from spring brake service chamber. Faulty spring brake chamber.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A lack of air at control port will prevent air delivery to service brake chambers and cause rear brakes not to apply.




- (1) Loosen control port air hose at booster valve
- (2) Apply brakes.
- (3) Check for presence of air.
- (4) If no air is present, replace damaged air hose (para 11-21).
- (5) Tighten control port air hose on booster valve.



i2. REAR BRAKES DO NOT APPLY (CONT)


KNOWN INFO
Front brakes OK. Air tanks pressurized. Supply air hose to foot control valve OK. Foot control valve OK. Air hoses at cab floor OK. Air hose to check valve OK. Check valve OK. Air hose to control port of booster valve OK.
POSSIBLE PROBLEMS
Faulty air hose to supply port of booster valve. Faulty booster valve. Faulty air hose to load sensing valve. Faulty load sensing valve. Faulty air hose to control port of relay valve. Faulty air hose to supply port of relay valve. Faulty relay valve. Faulty air hoses to spring brakes. Faulty vent hose from springbrake service chamber. Faulty spring brake chamber.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A blocked or leaking supply air hose to booster valve will prevent air delivery to service brake chambers and cause rear brakes not to apply.




- (1) Loosen supply air hose at booster valve.
- (2) Check for presence of air.
- (3) If no air is present, replace air hose (para 11-21).
- (4) Tighten supply air hose to booster valve.




i2. REAR BRAKES DO NOT APPLY (CONT)

KNOWN INFO
Front brakes OK. Air tanks pressurized. Supply air hose to foot control valve OK. Foot control valve OK. Air hoses at cab floor OK. Air hose to check valve OK. Check valve OK. Air hose to control port of booster valve OK. Air hose to supply port of booster valve OK.
POSSIBLE PROBLEMS
Faulty booster valve. Faulty air hose to load sensing valve. Faulty load sensing valve. Faulty air hose to control port of relay valve. Faulty air hose to supply port of relay valve. Faulty relay valve. Faulty air hoses to spring brakes. Faulty vent hose from spring brake service chamber. Faulty spring brake chamber.





TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A lack of air from delivery port of booster valve will prevent air delivery to service brake chambers and cause rear brakes not to apply.






- (1) Loosen booster valve delivery air hose at booster valve.
- (2) Apply brakes.
- (3) Check for presence of air.
- (4) If no air is present, replace booster valve (para 11-15).
- (5) Tighten delivery air hose on booster valve.



X210208-

i2. REAR BRAKES DO NOT APPLY (CONT)



KNOWN INFO
Front brakes OK.
Air tanks pressurized.
Supply air hose to foot control valve OK.
Foot control valve OK.
Air hoses at cab floor OK.
Air hose to check valve OK.
Check valve OK.
Air hose to control port of booster valve OK.
Air hose to supply port of booster valve OK.
Booster valve OK.
POSSIBLE PROBLEMS
Faulty air hose to load sensing valve.
Faulty load sensing valve.
Faulty air hose to control port of relay valve.
Faulty air hose to supply port of relay valve.
Faulty relay valve.
Faulty air hoses to spring brakes.
Faulty vent hose from spring brake service chamber.
Faulty spring brake chamber.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A blocked or leaking delivery air hose from booster valve to load sensing valve will prevent air delivery to service brake chambers and cause rear brakes not to apply.




- (1) Loosen delivery air hose at load sensing valve.
- (2) Apply brakes.
- (3) Check for presence of air.
- (4) If no air is present, replace air hose (para 11-21).
- (5) Tighten delivery air hose on load sensing valve.



4202091

i2. REAR BRAKES DO NOT APPLY (CONT)


KNOWN INFO
Front brakes OK. Air tanks pressurized. Supply air hose to foot control valve OK. Foot control valve OK. Air hoses at cab floor OK. Air hose to check valve OK. Check valve OK. Air hose to control port of booster valve OK. Air hose to supply port of booster valve OK. Booster valve OK. Air hose to load sensing valve OK.
POSSIBLE PROBLEMS
Faulty load sensing valve. Faulty air hose to control port of relay valve. Faulty air hose to supply port of relay valve. Faulty relay valve. Faulty air hoses to spring brakes. Faulty vent hose from spring brake service chamber. Faulty spring brake chamber.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A lack of air at load sensing valve will prevent air delivery to service brake chambers and cause rear brakes not to apply.




- (1) Loosen outlet air hose at load sensing valve.
- (2) Apply brakes.
- (3) Check for presence of air.
- (4) If no air is present, replace load sensing valve (para 11-10).
- (5) Tighten outlet air hose on load sensing valve.



X210210A


i2. REAR BRAKES DO NOT APPLY (CONT)

KNOWN INFO
Front brakes OK. Air tanks pressurized. Supply air hose to foot control valve OK. Foot control valve OK. Air hoses at cab floor OK. Air hose to check valve OK. Check valve OK. Air hose to control port of booster valve OK. Air hose to supply port of booster valve OK. Booster valve OK. Air hose to load sensing valve OK. Load sensing valve OK.
POSSIBLE PROBLEMS
Faulty air hose to control port of relay valve. Faulty air hose to supply port of relay valve. Faulty relay valve. Faulty air hoses to spring brakes. Faulty vent hose from spring brake service chamber. Faulty spring brake chamber.






TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A lack of air at relay valve control port air hose will prevent air delivery to service brake chambers and cause rear brakes not to apply.






- (1) Loosen control port air hoses at relay valve.
- (2) Apply brakes.
- (3) Check for presence of air.
- (4) If no air is present, replace air hose(s) (para 11-21).
- (5) Tighten inlet air hoses on relay valve.



X210211-

i2. REAR BRAKES DO NOT APPLY (CONT)


KNOWN INFO
Front brakes OK.
Air tanks pressurized.
Supply air hose to foot control valve OK.
Foot control valve OK.
Air hoses at cab floor OK.
Air hose to check valve OK.
Check valve OK.
Air hose to control port of booster valve OK.
Air hose to supply port of booster valve OK.
Booster valve OK.
Air hose to load sensing valve OK.
Load sensing valve OK.
Air hose to control port of relay valve OK.
POSSIBLE PROBLEMS
Faulty air hose to supply port of relay valve.
Faulty relay valve.
Faulty air hoses to spring brakes.
Faulty vent hose from spring brake service chamber.
Faulty spring brake chamber.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A blocked or leaking supply air hose from primary tank to supply port of relay valve will prevent air delivery to service brake chambers and cause rear brakes not to apply.




- (1) Loosen supply air hose at supply port of relay valve.
- (2) Apply brakes.
- (3) Check for presence of air.
- (4) If no air is present, replace air hose (para 11-21).
- (5) Tighten supply air hose to relay valve.



X210212-

i2. REAR BRAKES DO NOT APPLY (CONT)


KNOWN INFO
Front brakes OK. Air tanks pressurized. Supply air hose to foot control valve OK. Foot control valve OK. Air hoses at cab floor OK. Air hose to check valve OK. Check valve OK. Air hose to control port of booster valve OK. Air hose to supply port of booster valve OK. Booster valve OK. Air hose to load sensing valve OK. Load sensing valve OK. Air hose to control port of relay valve OK. Air hose to supply port relay valve OK.
POSSIBLE PROBLEMS
Faulty relay valve. Faulty air hoses to spring brakes. Faulty vent hose from spring brake service chamber. Faulty spring brake chamber.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A lack of air at delivery port(s) of relay valve will prevent air delivery to service brake chambers and cause rear brakes not to apply.




- (1) Loosen delivery air hose(s) at relay valve.
- (2) Apply brakes.
- (3) Check for presence of air.
- (4) If no air is present, replace relay valve (para 11-14).
- (5) Tighten delivery air hose(s) to relay valve.



X210213-

i2. REAR BRAKES DO NOT APPLY (CONT)


KNOWN INFO
Front brakes OK. Air tanks pressurized. Supply air hose to foot control valve OK. Foot control valve OK. Air hoses at cab floor OK. Air hose to check valve OK. Check valve OK. Air hose to control port of booster valve OK. Air hose to supply port of booster valve OK. Booster valve OK. Air hose to load sensing valve OK. Load sensing valve OK. Air hose to control port of relay valve OK. Air hose to supply port relay valve OK. Relay valve OK.
POSSIBLE PROBLEMS
Faulty air hoses to spring brakes. Faulty vent hose from spring brake service chamber. Faulty spring brake chamber.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A lack of air at service brake air chambers will cause rear brakes not to apply.




- (1) Loosen service brake air hose at spring brake chamber.
- (2) Apply brakes.
- (3) Check for presence of air.
- (4) If no air is present, replace air hose (para 11-21).
- (5) Tighten service brake air hose on spring brake chamber.



4210214-


i2. REAR BRAKES DO NOT APPLY (CONT)

KNOWN INFO
Front brakes OK.
Air tanks pressurized.
Supply air hose to foot control valve OK.
Foot control valve OK.
Air hoses at cab floor OK.
Air hose to check valve OK.
Check valve OK.
Air hose to control port of booster valve OK.
Air hose to supply port of booster valve OK.
Booster valve OK.
Air hose to load sensing valve OK.
Load sensing valve OK.
Air hose to control port of relay valve OK.
Air hose to supply port relay valve OK.
Relay valve OK.
Air hoses to spring brakes OK.
POSSIBLE PROBLEMS
Faulty vent hose from spring brake service chamber.
Faulty spring brake chamber.




TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Blocked vent hoses will prevent air from escaping at brake service chambers and will cause rear brakes not to apply.

- (1) Disconnect vent hose(s) at brake chamber(s).
- (2) Blow compressed air through vent hoses.
- (3) Check for air escaping at vent valve.
- (4) If air does not escape from vent hose, replace vent hose(s) (para 11-21) or relay valve (para 11-14).
- (5) If air does escape from vent hose, replace rear service brake air chamber (para 11-8).
- (6) Connect vent hose(s) at brake chamber(s).
- (7) Lower cab (TM 9-2320-366-10-1).



4210215-

i3. PARKING BRAKE DOES NOT RELEASE	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Goggles, Industrial (Item 15, Appendix C)




WARNING

When working on parking brake control system, vehicle may roll. Wheel chocks must be positioned in front of and behind one of the rear wheels to keep it from rolling. Failure to comply may result in serious injury or death to personnel.

- (1) Start engine (TM 9-2320-366-10-1).
- (2) Release SYSTEM PARK control (TM 9-2320-366-10-1).
- (3) Check if vehicle moves.
- (4) If vehicle moves, locate locked wheel(s) and troubleshoot individual wheel(s).
- (5) Shut down engine (TM 9-2320-366-10-1).

13. PARKING BRAKE DOES NOT RELEASE (CONT)

KNOWN INFO
Air tanks pressurized. Gladhands OK.
POSSIBLE PROBLEMS
Faulty air hose 107. Faulty park control two-way check valve. Faulty SYSTEM PARK air supply valve. Faulty air hose 103. Faulty air hose 109. Faulty two-way check valve. Faulty air hose 119. Faulty inversion valve. Faulty air hose 221. Faulty anti-compounding valve. Faulty air hose 231.






TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
SYSTEM PARK air supply valve cannot be tested if no air is present at supply port.

WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

- (1) Remove roll pins from knobs of SYSTEM PARK and TRAILER AIR SUPPLY valves.
- (2) Remove SYSTEM PARK and TRAILER AIR SUPPLY valve knobs.
- (3) Unscrew nuts at base of knob stem on each valve.
- (4) Remove six screws from dash plate.
- (5) Remove dash plate from personnel heater.
- (6) Pull out SYSTEM PARK air supply valve from personnel heater.
- (7) Loosen air hose 107 at SYSTEM PARK air supply valve supply port.
- (8) Check air hose 107 for escaping air.
- (9) If no air escapes from air hose 107, go to step 11 of this fault.




XBI0301B

13. PARKING BRAKE DOES NOT RELEASE (CONT)


KNOWN INFO
Air tanks pressurized. Gladhands OK. Air hose 107 OK. Park control two-way check valve OK.
POSSIBLE PROBLEMS
Faulty SYSTEM PARK air supply valve. Faulty air hose 103. Faulty air hose 109. Faulty two-way check valve. Faulty air hose 119. Faulty inversion valve. Faulty air hose 221. Faulty anti-compounding valve. Faulty air hose 231.

3.
Is air present at delivery port of SYSTEM PARK air supply valve?

TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
No air present at delivery port indicates faulty SYSTEM PARK air supply valve.




- (1) Tighten air hose 107 at SYSTEM PARK air supply valve supply port.
- (2) Loosen air hose 103 at SYSTEM PARK air supply valve delivery port.
- (3) Check for presence of air from SYSTEM PARK air supply valve.
- (4) If no air is present, replace SYSTEM PARK air supply valve (para 11-20).



XB10302B


13. PARKING BRAKE DOES NOT RELEASE (CONT)

KNOWN INFO
Air tanks pressurized. Gladhands OK. Air hose 107 OK. Park control two-way check valve OK.
POSSIBLE PROBLEMS
Faulty air hose 103. Faulty air hose 109. Faulty two-way check valve. Faulty air hose 119. Faulty inversion valve. Faulty air hose 221. Faulty anti-compounding valve. Faulty air hose 231.




TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
No air present at air hose 103 indicates faulty air hose.

- (1) Tighten air hose 103 at SYSTEM PARK air supply valve delivery port.
- (2) Loosen air hose 103 at cab floor fitting.
- (3) Check for presence of air from air hose 103.
- (4) If no air is present, replace air hose 103 (para 11-21).




STEERING COLUMN
REMOVED FOR CLARITY



XB10303B

13. PARKING BRAKE DOES NOT RELEASE (CONT)





KNOWN INFO
Air tanks pressurized. Gladhands OK. Air hose 107 OK. Park control two-way check Air hose 103 OK.
POSSIBLE PROBLEMS
Faulty air hose 109. Faulty two-way check valve. Faulty air hose 119. Faulty inversion valve. Faulty air hose 221. Faulty anti-compounding valve. Faulty air hose 231.



TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
Two-way check valve cannot be tested if no air is present at supply port.

**STEERING COLUMN
REMOVED FOR CLARITY**


- (1) Tighten air hose 103 at cab floor fitting.
- (2) Push SYSTEM PARK and TRAILER AIR SUPPLY valves back into personnel heater.
- (3) Install dash plate over valve stems with six screws.
- (4) Install nuts on knob stems.
- (5) Install SYSTEM PARK and TRAILER AIR SUPPLY knobs on stems with roll pins.
- (6) Raise cab (TM 9-2320-366-10-1).
- (7) Loosen air hose 109 at supply port of two-way check valve.
- (8) Check for presence of air at air hose 109.
- (9) If no air is present, replace air hose 109 (para 11-21).



XBI0307B

13. PARKING BRAKE DOES NOT RELEASE (CONT)

KNOWN INFO
Air tanks pressurized. Gladhands OK. Air hose 107 OK. Park control two-way check valve OK. Air hose 103 OK. Air hose 109 OK.
POSSIBLE PROBLEMS
Faulty two-way check valve. Faulty air hose. Faulty inversion valve. Faulty air hose 221. Faulty anti-compounding valve. Faulty air hose 231.




TEST OPTIONS
Visual inspection
REASON FOR QUESTION
No air at delivery port of two-way check valve indicates a faulty two-way check valve.

- (1) Tighten air hose 109 at two-way check valve supply port.
- (2) Loosen air hose (refer to Table 2-48.1. Air Hose Numbers) at delivery port of two-way check valve.
- (3) Release SYSTEM PARK (TM 9-2320-366-10-1) and check for presence of air at air hose (refer to Table 2-48.1. Air Hose Numbers).
- (4) If no air is present, replace two-way check valve (para 11-16).

Table 2-48.1. Air Hose Numbers


Air Hose Number	Model Used On
131	M1089
133	M1083/M1088/M1090/ M1094/M1092
136	M1086/M1096
138	M1085/M1084



XBI0308B

13. PARKING BRAKE DOES NOT RELEASE (CONT)

KNOWN INFO
Air tanks pressurized. Gladhands OK. Air hose 107 OK. Park control two-way check valve OK. Air hose 103 OK. Air hose 109 OK. Two-way check valve OK.
POSSIBLE PROBLEMS
Faulty air hose. Faulty inversion valve. Faulty air hose 221. Faulty anti-compounding valve. Faulty air hose 231.







TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
Inversion valve cannot be tested if no air is present at supply port.

- (1) Tighten air hose (refer to Table 2-48.2. Air Hose Numbers) at two-way check valve delivery port.
- (2) Lower cab (TM 9-2320-366-10-1).
- (3) Loosen air hose (refer to Table 2-48.2. Air Hoses Numbers) at inversion valve supply port.
- (4) Check for presence of air at air hose (refer to Table 2-48.2. Air Hose Numbers).
- (5) If no air is present, replace air hose (para 11-21).

Table 2-48.2. Air Hose Numbers


Air Hose Number	Model Used On
131	M1089
133	M1083/M1088/M1090/ M1094/M1092
136	M1086/M1096
138	M1085/M1084



4B10308B

13. PARKING BRAKE DOES NOT RELEASE (CONT)

KNOWN INFO
Air tanks pressurized. Gladhands OK. Air hose 107 OK. Park control two-way check valve OK. Air hose 103 OK. Air hose 109 OK. Two-way check valve OK. Air hose OK.
POSSIBLE PROBLEMS
Faulty inversion valve. Faulty air hose 221. Faulty anti-compounding valve. Faulty air hose 231.




TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
Leaking inversion valve may cause rapid loss of system air pressure.

- (1) Tighten air hose (refer to Table 2-48.3. Air Hose Numbers) at inversion valve supply port.
- (2) Loosen air hose 118 at inversion valve delivery port.
- (3) Check for presence of air at air hose 118.
- (4) If no air is present, replace inversion valve (para 11-13).

Table 2-48.3. Air Hose Numbers


Air Hose Number	Model Used On
131	M1089
133	M1083/M1088/M1090/ M1094/M1092
136	M1086/M1096
138	M1085/M1084



3BI0309B




13. PARKING BRAKE DOES NOT RELEASE (CONT)

KNOWN INFO
Air tanks pressurized. Gladhands OK. Air hose 107 OK. Park control two-way check valve OK. Air hose 103 OK. Air hose 109 OK. Two-way check valve OK. Air hose 119 OK. Inversion valve OK.
POSSIBLE PROBLEMS
Faulty air hose 221. Faulty anti-compounding valve. Faulty air hose 231.



TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
Anti-compounding valve cannot be checked if air is not present at supply port.

- (1) Tighten air hose 118 at inversion valve delivery port.
- (2) Loosen air hose 221 at supply port of anti-compounding valve.
- (3) Check for presence of air at air hose 221.
- (4) If no air is present, replace air hose 221 (para 11-21).




4ki0312b

13. PARKING BRAKE DOES NOT RELEASE (CONT)


KNOWN INFO
Air tanks pressurized. Gladhands OK. Air hose 107 OK. Park control two-way check valve OK. Air hose 103 OK. Air hose 109 OK. Two-way check valve OK. Air hose 119 OK. Inversion valve OK. Air hose 221 OK.
POSSIBLE PROBLEMS
Faulty anti-compounding valve. Faulty air hose 231.

10.
Is air present at delivery ports of anti-compounding valve?

TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
Leaking anti-compounding valve may cause rapid loss of system air pressure.



- (1) Tighten air hose 221 at anti-compounding valve supply port.
- (2) Loosen air delivery hoses at delivery ports of anti-compounding valve.
- (3) Check for presence of air at anti-compounding valve air hoses.
- (4) If no air is present, replace anti-compounding valve (para 11-12).
- (5) If air is present, replace air hose 231 (para 11-21).
- (6) Tighten air delivery hoses at delivery ports of anti-compounding valve.




46i0313b

13. PARKING BRAKE DOES NOT RELEASE (CONT)




KNOWN INFO
Air tanks pressurized. Gladhands OK. No air pressure present at SYSTEM PARK air supply valve supply port.
POSSIBLE PROBLEMS
Faulty air hose 107. Faulty park control two-way check valve.

11.
Is air present at park control two-way check valve delivery port?

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If no air pressure is present at park control two-way check valve, park control two-way check valve is faulty. If air pressure is present, air hose 107 is faulty.



- (1) Tighten air hose 107 at SYSTEM PARK air supply valve supply port.
- (2) Push SYSTEM PARK and TRAILER AIR SUPPLY valves back into personnel heater.
- (3) Install dash plate over valve stems with six screws.
- (4) Install nuts on knob stems.
- (5) Install SYSTEM PARK and TRAILER AIR SUPPLY knobs on stems with roll pins.
- (6) Loosen air hose 107 at park control two-way check valve delivery port.
- (7) Check for presence of air at air hose 107.
- (8) If no air is present, replace park control two-way check valve (para 11-19).
- (9) If air is present, replace air hose (para 11-21).
- (10) Tighten air hose 107 at park control two-way check valve.



XB10309B


i4. FRONT BRAKES OVERHEAT AND/OR DO NOT RELEASE

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Personnel
 (2)

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Goggles, Industrial (Item 15, Appendix C)
 Trestle, Motor Vehicle Maintenance (2)
 (Item 47, Appendix C)
 Adjusting Tool, Brake Shoe (Item 2, Appendix C)






WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

SOAPY WATER LEAK TEST

- (1) Apply soapy water solution to air hose 229 and fittings.
- (2) Check air hose 229 and fittings for bubbles, indicating leaks.

- (1) Check air hose 229 from front service gladhand to two-way check valve for leaks and damage.
- (2) If air hose 229 and/or fittings are faulty, replace damaged air hose 229 and/or fittings (para 11-21).



Xbr4001b

i4. FRONT BRAKES OVERHEAT AND/OR DO NOT RELEASE (CONT)


KNOWN INFO
Tires undamaged and inflated to proper operating pressure. Front gladhands OK. Air hose 229 OK.
POSSIBLE PROBLEMS
Faulty brake adjusting components. Faulty wedge assembly. Faulty wheel bearings. Faulty brake chamber(s).

2.

WARNING
Read WARNING on following page.

Are front brake adjusting bolts locked-up?

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Poorly adjusted brake shoes and/or stuck adjusting bolts may cause shoes to bind on wheels and brakes may overheat or not release.




KNOWN INFO
Tires undamaged and inflated to proper operating pressure. Front gladhands OK. Air hose 229 OK.
POSSIBLE PROBLEMS
Faulty brake adjusting components. Faulty wedge assembly. Faulty wheel bearings. Faulty brake chamber(s).

3.

CAUTION
Read CAUTION on following page.

Are front brake adjusting components functioning and free from damage and at affected wheel(s)?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Brake shoes will not retract and brakes will overheat if return springs and/or adjusting chamber components are stuck or damaged.



WARNING

Overheated brakes can cause severe burns. Perform task only when brakes have cooled. Failure to comply may result in injury to personnel.

- (1) Jack up side with overheated or non-releasing brakes, and support with trestle stands.
- (2) Turn adjusting bolt clockwise with adjusting tool.
- (3) If bolt will not turn or if brake shoes do not move away from wheel when adjuster is turned, adjust brakes (para 11-2).




- (1) Remove wheel(s) with affected brakes and disassemble brake components (para 11-2).
- (2) Inspect return springs for stretching, bluing, damage, or breakage.
- (3) If spring(s) is damaged, replace spring(s) (para 11-2).
- (4) Check adjusting pawl spring for damage.
- (5) Ensure adjusting pawl spring is not missing or broken.
- (6) Check adjusting pawl teeth for damage and abrasion.
- (7) Ensure seal elements are not damaged or broken.

CAUTION

Ensure seal is free from damage. Failure to comply may result in dirt entering plunger chamber and interfering with adjustment.

- (8) Check actuator teeth for damage.
- (9) Check plunger for freedom of movement inside plunger housing.




X6i40026

i4. FRONT BRAKES OVERHEAT AND/OR DO NOT RELEASE (CONT)


KNOWN INFO
Tires undamaged and inflated to proper operating pressure. Front gladhands OK. Air hose 229 OK. Brake adjusting components OK.
POSSIBLE PROBLEMS
Faulty wedge assembly. Faulty wheel bearings. Faulty brake chamber(s).

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If wedge assembly is damaged or does not operate, brake shoes may remain partially applied.




KNOWN INFO
Tires undamaged and inflated to proper operating pressure. Front gladhands OK. Air hose 229 OK. Brake adjusting components OK.
POSSIBLE PROBLEMS
Faulty wheel bearings. Faulty brake chamber(s).


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Loose or damaged wheel bearings may cause brakes to overheat.



- (1) Disconnect and tag air hoses from brake chambers at affected wheel(s).
- (2) Unscrew brake chambers from hub and remove wedge assembly from wheels (para 11-4).
- (3) Inspect wedge spring for damage.
- (4) Inspect rollers for flattening or damage.
- (5) Manually check operation of wedge assembly in plunger chamber.
- (6) Install wedge assembly and brake chamber (para 11-4).
- (7) Install front wheel brake components and adjust brakes (para 11-2).



- (1) Install wheel(s) (TM 9-2320-366-10-1).
- (2) Rotate affected wheel(s) by hand and listen for loose or damaged bearings.
- (3) If wheel makes grinding sound during rotation, replace wheel bearings (para 10-2).
- (4) Grasp wheel on opposite sides of top and bottom and pull in and out.
- (5) If wheel has excessive play on the axle, replace wheel bearings (para 10-2).
- (6) Check wheel hub oil level (Appendix H).
- (7) If oil level is low, replace wheel bearings (para 10-2).
- (8) Lower wheels to ground and remove trestle stands.



X6i4003b


i5. VEHICLE BRAKES UNEVENLY, BRAKES PULL TO ONE SIDE OR GRAB

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Personnel Required
 (2)

Tools and Special Tools
 Goggles, Industrial (Item 15, Appendix C)
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Trestle, Motor Vehicle Maintenance (2) (Item 47, Appendix C)
 Wrench, Torque, 0-175 lb-ft (Item 58, Appendix C)





- (1) Start engine (TM 9-2320-366-10-1).
- (2) Test drive unloaded vehicle and apply brakes.
- (3) Note response of brakes on both sides of vehicle and on each axle.
- (4) Shut down engine (TM 9-2320-366-10-1).
- (5) If vehicle pulls to one side when brakes are applied, front brakes are faulty.
- (6) If all rear wheels lock up before front wheels, load sensing valve may need adjustment or is faulty.
- (7) If individual rear wheel(s) lock up or drag, individual rear wheel brakes may need adjustment or are faulty.

15. VEHICLE BRAKES UNEVENLY, BRAKES PULL TO ONE SIDE OR GRAB (CONT)

KNOWN INFO
Air tanks pressurized.
POSSIBLE PROBLEMS
Contaminated front wheel brake shoes. Faulty front wheel brake adjustment. Faulty front axle quick release valve. Faulty air hose to front brake air chamber. Faulty front brake vent hose. Faulty front brake air chamber. Faulty load sensing valve. Contaminated rear brake shoes. Faulty rear wheel brake adjustment. Faulty relay valve. Faulty air hose to rear brake air chamber. Faulty rear brake vent hose or vent valve. Faulty rear brake air chamber(s).


KNOWN INFO
Air tanks pressurized. Front wheel brake shoes OK.
POSSIBLE PROBLEMS
Faulty front wheel brake adjustment. Faulty front axle quick release valve. Faulty air hose to front brake air chamber. Faulty front brake vent hose. Faulty front brake air chamber. Faulty load sensing valve. Contaminated rear brake shoes. Faulty rear wheel brake adjustment. Faulty relay valve. Faulty air hose to rear brake air chamber. Faulty rear brake vent hose or vent valve. Faulty rear brake air chamber(s).



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

- (1) Lift front axle so that front wheels are off the ground and support with maintenance trestles.
- (2) Rotate wheel and check for contamination, oil, or grease at brake shoe linings.
- (3) If oil contamination is present replace wheel bearing seals (para 10-2).




- (1) Apply brakes and observe operation of brake shoes at both front wheels.
- (2) If brake shoes fail to apply on one side, brake air delivery system or brake air chamber is faulty on that side.
- (3) If both wheel brakes apply, adjust brake shoe clearance (para 11-2).
- (4) Rotate wheel on affected side by hand and check if wheel grabs or is hard to turn.
- (5) If wheel resists turning by hand, adjust brake shoe clearance (para 11-2).


15. VEHICLE BRAKES UNEVENLY, BRAKES PULL TO ONE SIDE OR GRAB (CONT)

KNOWN INFO
Air tanks pressurized. Front wheel brake shoes OK. Front wheel brake adjustment OK.
POSSIBLE PROBLEMS
Faulty front axle quick release valve. Faulty air hose to front brake air chamber. Faulty front brake vent hose. Faulty front brake air chamber. Faulty load sensing valve. Contaminated rear brake shoes. Faulty rear wheel brake adjustment. Faulty relay valve. Faulty air hose to rear brake air chamber. Faulty rear brake vent hose or vent valve. Faulty rear brake air chamber(s).


KNOWN INFO
Air tanks pressurized. Front wheel brake shoes OK. Front wheel brake adjustment OK. Front axle quick release valve OK.
POSSIBLE PROBLEMS
Faulty air hose to front brake air chamber. Faulty front brake vent hose. Faulty front brake air chamber. Faulty load sensing valve. Contaminated rear brake shoes. Faulty rear wheel brake adjustment. Faulty relay valve. Faulty air hose to rear brake air chamber. Faulty rear brake vent hose or vent valve. Faulty rear brake air chamber(s).



- (1) Remove gravel deflector extension and gravel deflector (para 14-13).
- (2) Loosen delivery air hose on affected side of front axle quick release valve.
- (3) Apply brakes.
- (4) Listen for escaping air at delivery port of front axle quick release valve when brake is applied.
- (5) If escaping air cannot be heard at delivery port for affected side, replace front axle quick release valve (para 11-17).
- (6) Tighten delivery air hose at front axle quick release valve.
- (7) Install gravel deflector and gravel deflector extension (para 14-13).



- (1) Loosen supply air hose(s) at front brake air chamber(s).
- (2) Apply brakes.
- (3) Listen for escaping air at supply air hose(s) when brakes are applied.
- (4) If escaping air cannot be heard, replace supply air hose(s) (para 11-21).
- (5) Tighten supply air hose(s) at front brake air chamber(s).




XBI0503B

15. VEHICLE BRAKES UNEVENLY, BRAKES PULL TO ONE SIDE OR GRAB (CONT)

KNOWN INFO
Air tanks pressurized. Front wheel brake shoes OK. Front wheel brake adjustment OK. Front axle quick release valve OK. Air hose to front brake air chamber OK.
POSSIBLE PROBLEMS
Faulty front brake vent hose. Faulty front brake air chamber. Faulty load sensing valve. Contaminated rear brake shoes. Faulty rear wheel brake adjustment. Faulty relay valve. Faulty air hose to rear brake air chamber. Faulty rear brake vent hose or vent valve. Faulty rear brake air chamber(s).

6.
Is vent hose at affected wheel brake free from obstructions?


TEST OPTIONS
Audible and Visual inspection
REASON FOR QUESTION
If vent hose is plugged, brakes will not apply on affected side of vehicle.





KNOWN INFO
Air tanks pressurized. Front wheel brake shoes OK. Front wheel brake adjustment OK. Front axle quick release valve OK. Air hose to front brake air chamber OK. Front brake vent hose OK. Front brake air chamber OK.
POSSIBLE PROBLEMS
Faulty load sensing valve. Contaminated rear brake shoes. Faulty rear wheel brake adjustment. Faulty relay valve. Faulty air line to rear brake air chamber. Faulty rear brake vent line or vent valve. Faulty rear brake air chamber(s).

7.
Did rear brakes lock up before front brakes during road test?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If rear brakes lock up or grab before front brakes on unloaded vehicle, load sensing valve needs adjustment or is faulty.



- (1) Disconnect vent hose at front brake air chamber.
- (2) Blow compressed air through vent hose.
- (3) Check for air escaping at vent.
- (4) Attach vent hose at front brake air chamber.
- (5) Raise front axle off maintenance trestles.
- (6) Remove maintenance trestles and lower front wheels to ground.



- (1) If rear brakes locked up before front brakes on road test of unloaded vehicle, check load sensing valve hardware, arm position, adjusting clamp, and cable.
- (2) If valve arm is in full up position (valve spring rest position), adjust or replace load sensing valve (para 11-10).




4B10504B

15. VEHICLE BRAKES UNEVENLY, BRAKES PULL TO ONE SIDE OR GRAB (CONT)

KNOWN INFO
Air tanks pressurized. Front wheel brake shoes OK. Front wheel brake adjustment OK. Front axle quick release valve OK. Air hose to front brake air chamber OK. Front brake vent hose OK. Front brake air chamber OK. Load sensing valve OK.
POSSIBLE PROBLEMS
Contaminated rear brake shoes. Faulty rear wheel brake adjustment. Faulty relay valve. Faulty air hose to rear brake air chamber. Faulty rear brake vent hose or vent valve. Faulty rear brake air chamber(s).


KNOWN INFO
Air tanks pressurized. Front wheel brake shoes OK. Front wheel brake adjustment OK. Front axle quick release valve OK. Air hose to front brake air chamber OK. Front brake vent hose OK. Front brake air chamber OK. Load sensing valve OK. Rear brake shoes OK.
POSSIBLE PROBLEMS
Faulty rear wheel brake adjustment. Faulty relay valve. Faulty air hose to rear brake air chamber. Faulty rear brake vent hose or vent valve. Faulty rear brake air chamber(s).



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Rear brakes will slip or bind on affected wheels if brake shoes are contaminated.

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If one rear or more rear wheel brakes do not apply, vehicle will drag or swerve when brakes are applied.

- (1) Lift axle of each affected rear wheel so that rear wheels are off the ground and support with maintenance trestles.
- (2) Rotate affected wheel(s) and check for signs of contamination, oil, or grease at brake shoe linings.
- (3) If oil contamination is present, replace wheel bearing seals (para 10-2).
- (4) Lift affected axle off maintenance trestles.
- (5) Remove maintenance trestles and lower wheels to ground.




XBI0505B

- (1) Chock wheels.
- (2) Release parking brake (TM 9-2320-366-10-1).
- (3) Apply brakes and observe operation of brake shoes at rear wheels.
- (4) If brake shoes fail to apply on one side or at one wheel, brake air delivery system or brake air chamber is faulty on that side or at that wheel.
- (5) If all rear wheel brakes apply, adjust brake shoe clearance (para 11-3).


15. VEHICLE BRAKES UNEVENLY, BRAKES PULL TO ONE SIDE OR GRAB (CONT)

KNOWN INFO
Air tanks pressurized. Front wheel brake shoes OK. Front wheel brake adjustment OK. Front axle quick release valve OK. Air hose to front brake air chamber OK. Front brake vent hose OK. Front brake air chamber OK. Load sensing valve OK. Rear brake shoes OK. Rear wheel brake adjustment OK.
POSSIBLE PROBLEMS
Faulty relay valve. Faulty air hose to rear brake air chamber. Faulty rear brake vent hose or vent valve. Faulty rear brake air chamber(s).

KNOWN INFO
Air tanks pressurized. Front wheel brake shoes OK. Front wheel brake adjustment OK. Front axle quick release valve OK. Air hose to front brake air chamber OK. Front brake vent hose OK. Front brake air chamber OK. Load sensing valve OK. Rear brake shoes OK. Rear wheel brake adjustment OK. Relay valve OK.
POSSIBLE PROBLEMS
Faulty air hose to rear brake air chamber. Faulty rear brake vent hose or vent valve. Faulty rear brake air chamber(s).




TEST OPTIONS
Audible and Visual inspection
REASON FOR QUESTION
If relay valve does not supply air to all rear brake air chambers, braking will be uneven.




TEST OPTIONS
Audible and Visual inspection
REASON FOR QUESTION
If air hose(s) to affected brake(s) is damaged or blocked, brakes will not operate at affected wheel(s).

- (1) Loosen delivery air hoses on relay valve delivery ports.
- (2) Apply brakes.
- (3) Listen for escaping air from relay valve delivery ports when brakes are applied.
- (4) If escaping air cannot be heard, replace relay valve (para 11-14).
- (5) Tighten delivery air hoses on relay valve delivery ports.



RELAY VALVE
DELIVERY AIR HOSE TO RIGHT REAR BRAKE AIR CHAMBERS **DELIVERY AIR HOSE TO LEFT REAR BRAKE AIR CHAMBERS**

- (1) Loosen service brake air hose on rear brake air chamber.
- (2) Apply brakes.
- (3) Listen for escaping air from service brake air hose when brakes are applied.
- (4) If escaping air cannot be heard, replace air hose (para 11-21).
- (5) Tighten service brake air hose on rear brake air chamber.
- (6) Apply parking brake (TM 9-2320-366-10-1).



SERVICE BRAKE VENT HOSE
SERVICE BRAKE DELIVERY AIR HOSE
REAR BRAKE AIR CHAMBER


4B10506B

15. VEHICLE BRAKES UNEVENLY, BRAKES PULL TO ONE SIDE OR GRAB (CONT)



KNOWN INFO
Air tanks pressurized. Front wheel brake shoes OK. Front wheel brake adjustment OK. Front axle quick release valve OK. Air hose to front brake air chamber OK. Front brake vent hose OK. Front brake air chamber OK. Load sensing valve OK. Rear brake shoes OK. Rear wheel brake adjustment OK. Relay valve OK. Air hose to rear brake air chamber OK.
POSSIBLE PROBLEMS
Faulty rear brake vent hose or vent valve. Faulty rear brake air chamber(s).

12.
Are vent hoses and vent valve for affected rear wheel brakes free from obstructions?

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If vent hoses or vent valves are plugged, brakes will not apply at affected wheel(s).



- (1) Disconnect vent hose(s) on rear brake air chamber(s).
- (2) Blow compressed air through vent hoses.
- (3) Check for presence of air at vent valve.
- (4) Connect vent hose(s) on rear brake air chamber(s).
- (5) Remove wheel chocks (TM 9-2320-366-10-1).



4B10507B


i6. FRONT BRAKES DO NOT APPLY

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Personnel Required
 (2)

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Goggles, Industrial (Item 15, Appendix C)




WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

NOTE

Air system pressure must be in the 90-120 psi operating range to begin brake system troubleshooting. If air pressure cannot be maintained within operating range, proceed to Air System Troubleshooting.

- (1) Loosen air hose 208 at foot control valve supply port 12 and listen for presence of escaping air.
- (2) If escaping air cannot be heard, replace air hose 208 (para 11-21).
- (3) Tighten air hose 208 on foot control valve supply port 12.




i6. FRONT BRAKES DO NOT APPLY (CONT)

KNOWN INFO
Air tanks pressurized. Rear brakes OK. Air hose 208 OK.
POSSIBLE PROBLEMS
Faulty foot control valve. Faulty air hose 206. Faulty air hose 202. Faulty front brake two-way check valve. Faulty air hose 218. Faulty air hose 217. Faulty front axle quick release valve.

2.
Is air present at foot control valve delivery port 22 when applying brakes?


TEST OPTIONS
Audible and Visual Inspection
REASON FOR QUESTION
Lack of air from foot control valve delivery port 22 will prevent front brakes from applying.




KNOWN INFO
Air tanks pressurized. Rear brakes OK. Air hose 208 OK. Foot control valve OK.
POSSIBLE PROBLEMS
Faulty air hose 206. Faulty air hose 202. Faulty front brake two-way check valve. Faulty air hose 218. Faulty air hose 217. Faulty front axle quick release valve.

3.
Is air hose 206 free from leaks and damage?

TEST OPTIONS
Audible and Visual Inspection
REASON FOR QUESTION
A blocked or leaking air hose 206 may cause front brakes not to apply.



- (1) Loosen air hose 206 on foot control valve delivery port 22.
- (2) Apply foot brake.
- (3) Listen for escaping air from air hose 206 when brakes are applied.
- (4) If escaping air cannot be heard when brakes are applied, replace foot control valve (para 11-9).
- (5) Tighten air hose 206 on foot control valve delivery port 22.




- (1) Loosen air hose 206 at fitting on cab floor.
- (2) Apply foot brake.
- (3) Listen for air escaping from air hose 206 when brakes are applied.
- (4) If escaping air cannot be heard when brakes are applied, replace air hose 206 (para 11-21).
- (5) Tighten air hose 206 at fitting on cab floor.

XBI0602B

i6. FRONT BRAKES DO NOT APPLY (CONT)

KNOWN INFO
Air tanks pressurized. Rear brakes OK. Air hose 208 OK. Foot control valve OK. Air hose 206 OK.
POSSIBLE PROBLEMS
Faulty air hose 202. Faulty front brake two-way check valve. Faulty air hose 218. Faulty air hose 217. Faulty front axle quick release valve.



KNOWN INFO
Air tanks pressurized. Rear brakes OK. Air hose 208 OK. Foot control valve OK. Air hose 206 OK. Air hose 202 OK.
POSSIBLE PROBLEMS
Faulty front brake two-way check valve. Faulty air hose 218. Faulty air hose 217. Faulty front axle quick release valve.



TEST OPTIONS
Audible and Visual Inspection
REASON FOR QUESTION
A blocked or leaking air hose 202 may cause front brakes not to apply.

TEST OPTIONS
Audible and Visual Inspection
REASON FOR QUESTION
If air is not present at front brake two-way check valve delivery port when applying brakes, front brake two-way check valve is faulty.

- (1) Loosen air hose 202 on front brake two-way check valve supply port.
- (2) Apply foot brake.
- (3) Listen for escaping air from air hose 202 when brakes are applied.
- (4) If escaping air cannot be heard when brakes are applied, replace air hose 202 (para 11-21).
- (5) Tighten air hose 202 on front brake two-way check valve supply port.




XB10603B

- (1) Loosen air hose 218 on front brake two-way check valve delivery port.
- (2) Apply foot brake.
- (3) Listen for air escaping from front brake two-way check valve delivery port when brakes are applied.
- (4) If escaping air cannot be heard when brakes are applied, replace front brake two-way check valve (para 11-26).
- (5) Tighten air hose 218 on front brake two-way check valve delivery port.

16. FRONT BRAKES DO NOT APPLY (CONT)


KNOWN INFO
Air tanks pressurized. Rear brakes OK. Air hose 208 OK. Foot control valve OK. Air hose 206 OK. Air hose 202 OK. Front brake two-way check valve OK.
POSSIBLE PROBLEMS
Faulty air hose 218. Faulty air hose 217. Faulty front axle quick release valve.

TEST OPTIONS
Audible and Visual Inspection
REASON FOR QUESTION
A blocked or leaking air hose 218 may cause front brakes not to apply.




KNOWN INFO
Air tanks pressurized. Rear brakes OK. Air hose 208 OK. Foot control valve OK. Air hose 206 OK. Air hose 202 OK. Front brake two-way check valve OK. Air hose 218 OK.
POSSIBLE PROBLEMS
Faulty air hose 217. Faulty front axle quick release valve.


TEST OPTIONS
Audible and Visual Inspection
REASON FOR QUESTION
A blocked or leaking air hose 217 may cause front brakes not to apply.



- (1) Loosen air hose 218 on tee fitting.
- (2) Apply foot brake.
- (3) Listen for escaping air from air hose 218 when brakes are applied.
- (4) If escaping air cannot be heard when brakes are applied, replace air hose 218 (para 11-21).
- (5) Tighten air hose 218 on tee fitting.




- (1) Remove gravel deflector extension and gravel deflector (para 14-13).
- (2) Loosen air hose 217 on front axle quick release valve supply port.
- (3) Apply foot brake.
- (4) Listen for air escaping from air hose 217 when brakes are applied.
- (5) If escaping air cannot be heard when brakes are applied, replace air hose 217 (para 11-21).
- (6) If air can be heard escaping when brakes are applied, replace front axle quick release valve (para 11-17).
- (7) Tighten air hose 217 on front axle quick release valve supply port.
- (8) Install gravel deflector and gravel deflector extension (para 14-13).



XBI0604B

i7. REAR BRAKES OVERHEAT	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Goggles, Industrial (Item 15, Appendix C) Tool Kit, Genl Mech (Item 46, Appendix C) Trestle, Motor Vehicle Maintenance (2) (Item 47, Appendix C) Adjusting Tool, Brake Shoe (Item 2, Appendix C)
Personnel Required (2)	




WARNING

- Overheated brakes can cause severe burns. Perform task only when brakes have cooled. Failure to comply may result in injury to personnel.
- Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

NOTE


If wheel drums are too hot for hand touch after road test of vehicle, brakes are overheated.


- (1) Release parking brake (TM 9-2320-366-10-1).
- (2) Check for presence of air at air hose to spring brake chamber. If air is present at spring brake chamber, replace fittings or air hose (para 11-21).
- (3) Remove cover plug from caging hole at back of spring brake chamber (TM 9-2320-366-10-2).
- (4) With flashlight directed at caging hole, apply and release parking brake. Check if spring retracts when air is supplied by releasing parking brake. If brake does not cage (retract) when air is supplied to spring brake chamber, replace spring brake chamber (para 11-8).
- (5) Replace plug in caging hole of spring brake chamber (TM 9-2320-366-10-2).
- (6) Apply parking brake (TM 9-2320-366-10-1).





4210701A

i7. REAR BRAKES OVERHEAT (CONT)






- (1) Jack up axle with overheated brakes, and support with trestle stands.
- (2) Release parking brake (TM 9-2320-366-10-1).
- (3) Turn adjusting bolt clockwise with adjusting tool. If bolt will not turn or if brake shoes do not move away from wheel when adjuster is turned, perform brake adjustment (para 11-3).



4210702A

i7. REAR BRAKES OVERHEAT (CONT)

KNOWN INFO
Tires undamaged and inflated to operating pressure. Spring brake chamber(s) OK
POSSIBLE PROBLEMS
Faulty brake adjusting components. Faulty wedge assembly. Faulty wheel bearings.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
Brake shoes will not retract and brakes will overheat if return springs and adjusting chamber components are stuck or damaged.




- (1) Remove wheel(s) with affected brakes (TM 9-2320-366-10-1).
- (2) Disassemble brakes (para 11-3).
- (3) Inspect spring for stretching, bluing, damage, or breakage. If spring(s) is damaged, brake shoes will not retract from wheel.
- (4) Check adjusting pawl spring for damage. Ensure springs are not missing or broken.
- (5) Check adjusting pawl teeth for damage and abrasion.

NOTE


A damaged seal may permit dirt to enter plunger chamber and interfere with adjustment.

- (6) Ensure seal elements are not damaged or broken.
- (7) Check actuator teeth for damage.
- (8) Check plunger for freedom of movement inside plunger housing.



X210703-


i7. REAR BRAKES OVERHEAT (CONT)



WARNING


Spring brake chambers are very powerful. Cage spring brakes before removing chambers. Failure to comply may result in injury to personnel.

- (1) Disconnect and tag air lines to spring brake chambers at wheel.
- (2) Cage spring brakes on rear wheels (para 11-6).
- (3) Unscrew brake chamber(s) from hub and remove wedge assembly from wheel (para 11-5).
- (4) Inspect wedge spring for damage.
- (5) Inspect rollers for flattening or damage.
- (6) Manually check operation of wedge assembly in plunger chamber.
- (7) Install wedge assembly and brake chambers (para 11-5).
- (8) Install wheel brake components and adjust brakes (para 11-3).




X210704A



- (1) Install wheels (TM 9-2320-366-10-1).
- (2) Rotate affected wheel and listen for loose or damaged wheel bearings. If wheel makes grinding sound during rotation, adjust or replace wheel bearings (para 10-2).
- (3) Grasp wheel on opposite sides, top and bottom, and pull in and out. If wheel has excessive play on the axle, adjust or replace wheel bearings (para 10-2).
- (4) If wheel bearings are good, replace brake chamber(s) (para 11-8).
- (5) Check wheel hub oil level (Appendix H). If oil level is low, replace wheel bearings (para 10-2).
- (6) Set parking brake (TM 9-2320-366-10-1).
- (7) Remove trestle stands and lower wheels to ground.



i8. PARKING BRAKE DOES NOT APPLY	
INITIAL SETUP	
Equipment Conditions Air tanks pressurized (TM 9-2320-366-10-1). Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Goggles, Industrial (Item 15, Appendix C)
Personnel Required (2)	




- | SYSTEM PARK AIR SUPPLY VALVE TEST | |
|-----------------------------------|--|
| (1) | Push in system park air supply valve. |
| (2) | Pull system park air supply valve out and note release of air. |
| (3) | If air is not heard escaping from system park air supply valve, replace system park air supply valve (para 11-20). |




SYSTEM PARK AIR SUPPLY VALVE

X210801A


i8. PARKING BRAKE DOES NOT APPLY (CONT)




- (1) Push in SYSTEM PARK air supply valve.
- (2) Pull SYSTEM PARK air supply valve out and note release of air.
- (3) If air is not heard escaping from inversion valve, replace inversion valve (para 11-13).




- (1) Push in SYSTEM PARK air supply valve.
- (2) Pull SYSTEM PARK air supply valve out and note release of air.
- (3) If air is not heard escaping from anti-compounding relay valve, replace anti-compounding relay valve (para 11-12).
- (4) If air is heard escaping from anti-compounding relay valve, repair rear brake plunger assembly(ies) (para 11-5).
- (5) Pull SYSTEM PARK air supply valve out.



SYSTEM PARK
AIR SUPPLY VALVE



RELAY VALVE
AIR HOSE SUPPLY PORT RELAY VALVE
CONTROL PORT




42108021

i9. BRAKE SYSTEM LOSES AIR WHEN SERVICE BRAKES ARE APPLIED

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).



Tools and Special Tools
 Tool Kit, Genl Mech (Item 46 Appendix C)
 Goggles, Industrial (Item 15, Appendix C)



WARNING


Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

- (1) Have assistant apply service brakes (TM 9-2320-366-10-1).
- (2) Listen for air escaping from front axle quick release valve.
- (3) If air leak is present, replace front axle quick release valve (para 11-17).



**FRONT AXLE
QUICK RELEASE
VALVE**

- (1) Have assistant apply service brakes (TM 9-2320-366-10-1).
- (2) Listen for air escaping from rear gladhand(s).
- (3) If air leak is present, replace rear gladhand(s) (para 11-17).
- (4) If air leak is not present, perform Air System Troubleshooting J1. Air System Loses Pressure During Operation/Slow Air Pressure Buildup.



GLADHANDS

XBI0901B

2-21. AIR SYSTEM TROUBLESHOOTING

This paragraph covers Air System Troubleshooting. The Air System Fault Index, Table 2-49, lists faults for the Air System of the vehicle.

Table 2-49. Air System Fault Index

Fault No.	Description	Page
j1.	Air System Loses Pressure During Operation/Slow, No, or Incorrect Air Pressure Buildup	2-1948
j2.	Large Quantity of Moisture Expelled From Air Reservoirs	2-1964
j3.	Air Dryer Purges Constantly	2-1968
j4.	No Air Pressure Present at Rear Gladhand(s) (All Models Except M1088)	2-1972
j4A.	No Air Pressure Present at All M1088 Rear and Fifth Wheel Gladhands	2-1976.36
j4B.	No Air Pressure Present at M1088 Rear and/or Fifth Wheel EMERGENCY Gladhand(s)	2-1976.42
j4C.	No Air Pressure Present at M1088 Rear and/or Fifth Wheel SERVICE Gladhand(s)	2-1976.48
j4D.	M1088 Trailer Handbrake Control Does Not Operate	2-1976.60
j5.	Air System Pressure Builds Up More Than 120 psi (827 kPa) (Compressor Fails to Unload)	2-1978
j6.	Noisy Air Compressor Operation	2-1982
j7.	M1088 Rear Gladhand(s) Leaks or Does Not Operate	2-1986
j8.	M1091/M1094 Tailgate Release Does Not Operate	2-1988

j1. AIR SYSTEM LOSES PRESSURE DURING OPERATION/SLOW, NO, OR INCORRECT AIR PRESSURE BUILDUP

INITIAL SETUP

Equipment Conditions


- Engine running (TM 9-2320-366-10-1).
- Parking brake on (TM 9-2320-366-10-1).
- Wheels chocked (TM 9-2320-366-10-1).

Tools and Special Tools


- Tool Kit, Genl Mech (Item 46, Appendix C)
- Goggles, Industrial (Item 15, Appendix C)
- Pan, Wash (Item 25, Appendix C)

Materials/Parts

- Soap, Laundry (Item 63, Appendix D).



- (1) Check to see if both FRONT BRAKE/REAR BRAKE AIR pressure gages indicate less than 120 psi.
- (2) If only FRONT BRAKE AIR pressure gage indicates less than 120 psi, perform Brake Troubleshooting i6. Front Brakes Do Not Apply.
- (3) If only REAR BRAKE AIR pressure gage indicates less than 120 psi, perform Brake Troubleshooting i2. Rear Brakes Do Not Apply.



XBJ0101B

j1. AIR SYSTEM LOSES PRESSURE DURING OPERATION/SLOW, NO, OR INCORRECT AIR PRESSURE BUILDUP (CONT)


KNOWN INFO
FRONT BRAKE/REAR BRAKE AIR pressure gages OK.
POSSIBLE PROBLEMS
Damaged air hose from air cleaner to air compressor. Damaged air hose from air compressor to air dryer. Damaged air hose from air dryer to wet tank. Damaged air hose from wet tank to air compressor. Damaged air hoses from wet tank to primary and secondary air tanks. Faulty check valves at primary and secondary air tanks. Faulty air dryer purge valve and/or clogged desiccant cartridge. Faulty air compressor governor. Faulty air compressor.

2.

WARNING
Read WARNING on following page.

Are air hose from air cleaner to air compressor and fittings free from damage?


TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
A damaged air intake hose may cause air system to take an excessive amount of time to build up air pressure.





WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

- (1) Raise cab (TM 9-2320-366-10-1).
- (2) Check air intake hose from air cleaner to air compressor and fittings for damage.
- (3) If air intake hose and/or fittings are faulty, replace damaged air intake hose and/or fittings (para 23-2).



**AIR CLEANER
TO AIR COMPRESSOR
AIR INTAKE HOSE**



**AIR
COMPRESSOR**

**AIR COMPRESSOR
TO AIR CLEANER
AIR INTAKE HOSE**


XB J0102B

j1. AIR SYSTEM LOSES PRESSURE DURING OPERATION/SLOW, NO, OR INCORRECT AIR PRESSURE BUILDUP (CONT)

KNOWN INFO
FRONT BRAKE/REAR BRAKE AIR pressure gages OK. Air hoses and fittings from air cleaner to air compressor OK.
POSSIBLE PROBLEMS
Damaged air hose from air compressor to air dryer. Damaged air hose from air dryer to wet tank. Damaged air hose from wet tank to air compressor. Damaged air hoses from wet tank to primary and secondary air tanks. Faulty check valves at primary and secondary air tanks. Faulty air dryer purge valve and/or clogged desiccant cartridge. Faulty air compressor governor. Faulty air compressor.


3.
Are supply hose from air compressor to air dryer and fittings free from leaks or damage?

TEST OPTIONS
Soapy Water Leak Test and Visual Inspection
REASON FOR QUESTION
A leaking or damaged supply hose or fitting may cause air system to loose pressure or take an excessive amount of time to build up air pressure.



SOAPY WATER LEAK TEST


- (1) Apply soapy water solution to hoses, fittings, and couplings.
 - (2) Check hoses and fittings for bubbles, indicating leaks.
- (1) Check air hose from air compressor to pipe coupling and fittings for leaks or damage.
 - (2) Check air hose from pipe coupling to frame pipe coupling and fittings for leaks or damage.
 - (3) Check air hose from frame pipe coupling to air dryer and fittings for leaks or damage.
 - (4) If supply air hose and/or fittings are faulty, replace damaged supply air hose and/or fittings (para 23-2).



XBJ0103B

j1. AIR SYSTEM LOSES PRESSURE DURING OPERATION/SLOW, NO, OR INCORRECT AIR PRESSURE BUILDUP (CONT)


KNOWN INFO
FRONT BRAKE/REAR BRAKE AIR pressure gages OK. Air hoses and fittings from air cleaner to air compressor OK. Air hoses and fittings from air compressor to air dryer OK.
POSSIBLE PROBLEMS
Damaged air hose from air dryer to wet tank. Damaged air hose from wet tank to air compressor. Damaged air hoses from wet tank to primary and secondary air tanks. Faulty check valves at primary and secondary air tanks. Faulty air dryer purge valve and/or clogged desiccant cartridge. Faulty air compressor governor. Faulty air compressor.



TEST OPTIONS
Soapy Water Leak Test and Visual Inspection
REASON FOR QUESTION
A leaking or damaged hose or fitting may cause air system to loose pressure or take an excessive amount of time to build up air pressure.

SOAPY WATER LEAK TEST

- (1) Apply soapy water solution to hoses, fittings, and couplings.
 - (2) Check hoses and fittings for bubbles, indicating leaks.
-
- (1) Check air hose from air dryer to wet tank and fittings for leaks or damage.
 - (2) If air hose and/or fittings are faulty, replace damaged air hose and/or fittings (para 23-2).




XBJ0104B

j1. AIR SYSTEM LOSES PRESSURE DURING OPERATION/SLOW, NO, OR INCORRECT AIR PRESSURE BUILDUP (CONT)

KNOWN INFO
FRONT BRAKE/REAR BRAKE AIR pressure gages OK. Air hoses and fittings from air cleaner to air compressor OK. Air hoses and fittings from air compressor to air dryer OK. Air hose and fittings from air dryer to wet tank OK.
POSSIBLE PROBLEMS
Damaged air hose from wet tank to air compressor. Damaged air hoses from wet tank to primary and secondary air tanks. Faulty check valves at primary and secondary air tanks. Faulty air dryer purge valve and/or clogged desiccant cartridge. Faulty air compressor governor. Faulty air compressor.



5.
 Are air hose from wet tank
 to air compressor
 governor and fittings free
 from damage?

TEST OPTIONS
Soapy Water Leak Test and Visual Inspection
REASON FOR QUESTION
A damaged air hose or fitting may cause air system to loose pressure or take an excessive amount of time to build up air pressure.




SOAPY WATER LEAK TEST



- (1) Apply soapy water solution to hoses, fittings, and couplings.
 - (2) Check hoses and fittings for bubbles, indicating leaks.
-
- (1) Check air hose from wet tank to pipe coupling and fittings for leaks and damage.
 - (2) Check air hose from pipe coupling to air compressor and fittings for leaks and damage.
 - (3) If air hose and/or fittings are faulty, replace damaged air hose and/or fittings (para 23-2).
 - (4) Lower cab (TM 9-2320-366-10-1).



WET TANK AIR HOSE



AIR HOSE AIR HOSE
PIPE COUPLING



AIR HOSE
AIR COMPRESSOR


XB J0105B

j1. AIR SYSTEM LOSES PRESSURE DURING OPERATION/SLOW, NO, OR INCORRECT AIR PRESSURE BUILDUP (CONT)

KNOWN INFO
FRONT BRAKE/REAR BRAKE AIR pressure gages OK. Air hoses and fittings from air cleaner to air compressor OK. Air hoses and fittings from air compressor to air dryer OK. Air hose and fittings from air dryer to wet tank OK. Air hoses and fittings from wet tank to air compressor OK.
POSSIBLE PROBLEMS
Damaged air hoses from wet tank to primary and secondary air tanks. Faulty check valves at primary and secondary air tanks. Faulty air dryer purge valve and/or clogged desiccant cartridge. Faulty air compressor governor. Faulty air compressor.


6.
 Are air hoses from wet tank
 to primary and secondary
 air tanks, check valves, and
 fittings free from damage?

TEST OPTIONS
Soapy Water Leak Test and Visual Inspection
REASON FOR QUESTION
A leaking or damaged air hose or fitting may cause air system to loose pressure or take an excessive amount of time to build up air pressure.



SOAPY WATER LEAK TEST


- (1) Apply soapy water solution to hoses, fittings, and couplings.
 - (2) Check hoses and fittings for bubbles, indicating leaks.
-
- (1) Check air hose from wet tank to primary air tank check valve, and fittings for leaks and damage.
 - (2) Check air hose from primary air tank check valve to secondary air tank check valve, and fittings for leaks and damage.
 - (3) If air hose and/or fittings are faulty, replace damaged air hose and/or fittings (para 23-2).



4B J0106B

j1. AIR SYSTEM LOSES PRESSURE DURING OPERATION/SLOW, NO, OR INCORRECT AIR PRESSURE BUILDUP (CONT)



KNOWN INFO
FRONT BRAKE/REAR BRAKE AIR pressure gages OK. Air hoses and fittings from air cleaner to air compressor OK. Air hoses and fittings from air compressor to air dryer OK. Air hose and fittings from air dryer to wet tank OK. Air hoses and fittings from wet tank to air compressor OK. Air hoses, check valves, and fittings from wet tank to primary and secondary air tanks OK.
POSSIBLE PROBLEMS
Faulty air dryer purge valve and/or clogged desiccant cartridge. Faulty air compressor governor. Faulty air compressor.



TEST OPTIONS
Soapy Water Leak Test and Visual Insepction
REASON FOR QUESTION
A leaking air dryer purge valve or a clogged air dryer desiccant cartridge may cause air system to lose pressure or take an excessive amount of time to build up air pressure.

SOAPY WATER LEAK TEST


- (1) Apply soapy water solution to hoses, fittings, and couplings.
 - (2) Check hoses and fittings for bubbles, indicating leaks.
-
- (1) Open wet tank drain cock and check for excessive amounts of moisture.
 - (2) If moisture exists in wet tank, service air dryer desiccant cartridge (para 23-11).
 - (3) Close wet tank drain cock.



4BJ0107B

j1. AIR SYSTEM LOSES PRESSURE DURING OPERATION/SLOW, NO, OR INCORRECT AIR PRESSURE BUILDUP (CONT)


KNOWN INFO
FRONT BRAKE/REAR BRAKE AIR pressure gages OK. Air hoses and fittings from air cleaner to air compressor OK. Air hoses and fittings from air compressor to air dryer OK. Air hose and fittings from air dryer to wet tank OK. Air hoses and fittings from wet tank to air compressor OK. Air hoses, check valves, and fittings from wet tank to primary and secondary air tanks OK. Purge valve and desiccant cartridge OK.
POSSIBLE PROBLEMS
Faulty air compressor governor. Faulty air compressor.



TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
With no leaks in supply system, 120 psi cannot be maintained if air compressor governor is out of adjustment or faulty.



- (1) Allow pneumatic system to build pressure and observe FRONT BRAKE/REAR BRAKE AIR pressure gages without applying brakes or operating air system.
- (2) Check to see if air pressure stabilizes at 120 psi.
- (3) If air pressure remains below 120 psi, adjust or replace air compressor governor (para 11-31).
- (4) If air pressure continues to remain below 120 psi, notify DS Maintenance to replace air compressor.
- (5) Shut down engine (TM 9-2320-366-10-1).



XB J0108B

j2. LARGE QUANTITY OF MOISTURE EXPELLED FROM AIR RESERVOIRS

INITIAL SETUP


Equipment Conditions


Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools


Tool Kit, Genl Mech (Item 46, Appendix C)

Goggles, Industrial (Item 15, Appendix C)






- (1) Remove desiccant cartridge from air dryer (para 23-11).
- (2) Inspect the desiccant cartridge for cleanhoses.




AIR DRYER

42J0201A



- (1) Remove three screws, purge valve, and exhaust boot.
- (2) Check purge valve for blockage. If blocked, purge valve is faulty.
- (3) Install exhaust boot, purge valve, and three screws.




AIR DRYER

PURGE VALVE
PURGE VALVE
AIR HOSE


42J0202A

j2. LARGE QUANTITY OF MOISTURE EXPELLED FROM AIR RESERVOIRS (CONT)



BLOCKAGE TEST


- (1) Disconnect governor to air dryer air hose at governor and at purge valve.
- (2) Blow through one end of air hose. If no air escapes from other end of air hose, air hose is blocked.
- (3) Connect governor to air dryer air hose to governor and purge valve.



AIR COMPRESSOR
AIR COMPRESSOR TO AIR DRYER PURGE VALVE AIR HOSE

X2J0203A

- (1) Disconnect governor air hose at air dryer purge valve.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Check for presence of air at air hose. If no air escapes from air hose air compressor is defective. If air escapes, service air dryer for faulty purge valve.
- (4) Shut down engine (TM 9-2320-366-10-1).
- (5) Connect air compressor to air dryer air hose to air dryer.
- (6) Install desiccant cartridge in air dryer (para 23-11).



PURGE VALVE
AIR DRYER
AIR COMPRESSOR TO AIR DRYER PURGE VALVE AIR HOSE


42J0204A

j3. AIR DRYER CONTINUALLY PURGES

INITIAL SETUP



Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Goggles, Industrial (Item 15, Appendix C)



NOTE

- Air dryer heater cuts in at 32°F (0°C) and shuts off between 55-75°F (31-42°C).
- A failed air dryer heater will not affect operation of purge valve if vehicle is operating at temperature above freezing.



42J0301A


- (1) Start engine (TM 9-2320-366-10-1).
- (2) Bring engine to operating temperature.
- (3) Check bottom (heater) housing on air dryer.
- (4) If housing is not warm, heater is not receiving power or is faulty.
- (5) Shut down engine (TM 9-2320-366-10-1).

j3. AIR DRYER CONTINUALLY PURGES (CONT)

KNOWN INFO
Air hoses and fittings OK. Air dryer heater OK.
POSSIBLE PROBLEMS
Blocked air hose from air dryer to wet tank. Faulty air dryer. Faulty air compressor governor.

3.
Does air escape from air dryer to wet tank air hose?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
A blocked air hose from air dryer to wet tank will cause purge valve to release air.




KNOWN INFO
Air hoses and fittings OK. Air dryer heater OK. Air hose from air dryer to wet tank OK.
POSSIBLE PROBLEMS
Faulty air dryer. Faulty air compressor governor.

4.
Does air escape from compressor air hose at purge valve?


TEST OPTIONS
Check for air at purge valve air hose.
REASON FOR QUESTION
Air dryer will continually purge if air compressor governor is defective.




- (1) Disconnect air hose on wet tank coming from air dryer.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Check for presence of air at air hose. If no air escapes from air hose, air hose is faulty.
- (4) If air escapes, service air dryer (para 23-11).
- (5) Shut down engine (TM 9-2320-366-10-1).




- (1) Disconnect air hose from purge valve on air dryer.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Check for presence of air from air hose.
- (4) If air is steadily present from air hose and purge valve air has stopped, air compressor governor is defective.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) Connect air hose to purge valve on air dryer.



j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S) (ALL MODELS EXCEPT M1088)	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Goggles, Industrial (Item 15, Appendix C)




- (1) Disconnect dummy coupling from emergency gladhand.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Check for presence of air at emergency gladhand.
- (5) Connect dummy coupling to emergency gladhand.
- (6) Disconnect dummy coupling from service gladhand.
- (7) Apply service brakes (TM 9-2320-366-10-1).
- (8) Check for presence of air at service gladhand.
- (9) Shut down engine (TM 9-2320-366-10-1).
- (10) Connect dummy coupling to service gladhand.
- (11) If air is not present at both rear gladhands, go to step 5 of this fault.



Xb j4001b

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)


KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air hose 149, 150, or 151 OK. Air hose 102 OK. Air hose 108 OK. TRAILER AIR SUPPLY valve OK. Air hose 104 OK.
POSSIBLE PROBLEMS
Faulty emergency gladhand. Faulty air hose 155, 157, or 167. Faulty service gladhand. Faulty air hose 241, 253, or 254. Faulty air brake protecting valve. Faulty air hose 230 or 256. Faulty load sensing valve control port tee fitting. Faulty air hose 240 or 243. Faulty booster valve. Faulty service gladhand two-way check valve. Faulty air hose 145. Faulty air hose 120. Faulty inversion valve control port 90-degree fitting. Faulty air hose 128, 130, or 132.




TEST OPTIONS
Visual inspection
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.



- (1) Disconnect dummy coupling from service gladhand.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Apply service brakes (TM 9-2320-366-10-1).
- (5) Check for presence of air at service gladhand.
- (6) Shut down engine (TM 9-2320-366-10-1).
- (7) Connect dummy coupling to service gladhand.
- (8) If air is not present, go to step 10 of this fault.



j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

- (1) Loosen air hose (refer to Table 2-49.1 Emergency Gladhand Hose Numbers) at emergency gladhand.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose (refer to Table 2-49.1. Emergency Gladhand Hose Numbers).
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 4 of this fault.
- (7) If air is present, replace emergency gladhand (para 11-24).
- (8) Tighten air hose (refer to Table 2-49.1. Emergency Gladhand Hose Numbers) at emergency gladhand.





Table 2-49.1. Emergency Gladhand Hose Numbers

Model	Hose
All Except M1086 and M1089	157
M1086	167
M1089	155


4BJ4003B

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 149, 150, or 151 OK. Air hose 102 OK. Air hose 108 OK. TRAILER AIR SUPPLY valve OK. Air hose 104 OK. Service gladhand OK. Air hose 241, 253, or 254 OK. Air hose 230 or 256 OK. Load sensing valve control port tee fitting OK. Air hose 240 or 243 OK. Booster valve OK. Service gladhand two-way check valve OK. Air hose 145 OK. Air hose 120 OK. Inversion valve control port 90-degree fitting OK. Air hose 128, 130, or 132 OK.
POSSIBLE PROBLEMS
Faulty air hose 155, 157, or 167. Faulty air brake protecting valve.

4.
Is air present at air brake protecting valve delivery port TRLR E?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is not present, air brake protecting valve is faulty. If air is present, air hose (refer to Table 2-49.2. Emergency Gladhand Hose Numbers) is faulty.



- (1) Loosen air hose (refer to Table 2-49.2. Emergency Gladhand Hose Numbers) at air brake protecting valve delivery port TRLR E.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Check for presence of air at air brake protecting valve delivery port TRLR E.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, replace air brake protecting valve (para 11-18).
- (7) If air is present, replace air hose (refer to Table 2-49.2. Emergency Gladhand Hose Numbers) (para 11-21).
- (8) Tighten air hose (refer to Table 2-49.2. Emergency Gladhand Hose Numbers) at air brake protecting valve delivery port TRLR E.

Table 2-49.2. Emergency Gladhand Hose Numbers


Model	Hose
All Except M1086 and M1089	157
M1086	167
M1089	155



4BJ4004B

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Service gladhand OK. Air hose 241, 253, or 254 OK. Air hose 230 or 256 OK. Load sensing valve control port tee fitting OK. Air hose 240 or 243 OK. Booster valve OK. Service gladhand two-way check valve OK. Air hose 145 OK. Air hose 120 OK. Inversion valve control port 90-degree fitting OK. Air hose 128, 130, or 132 OK.
POSSIBLE PROBLEMS
Faulty air hose 149, 150, or 151. Faulty air hose 102. Faulty air hose 108. Faulty TRAILER AIR SUPPLY valve. Faulty air hose 104. Faulty air brake protecting valve.




TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, air brake protecting valve is faulty.

- (1) Loosen air hose (refer to Table 2-49.3. Air Brake Protecting Valve Control Hose Numbers) at air brake protecting valve control port TRA E.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose (refer to Table 2-49.3. Air Brake Protecting Valve Control Hose Numbers).
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 6 of this fault.
- (7) If air is present, replace air brake protecting valve (para 11-18).
- (8) Tighten air hose (refer to Table 2-49.3. Air Brake Protecting Valve Hose Numbers) at air brake protecting valve control port TRA E.

Table 2-49.3. Air Brake Protecting Valve Control Hose Numbers


Model	Hose
All Except M1086 and M1089	149
M1086	150
M1089	151



4BJ4005B

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Service gladhand OK. Air hose 241, 253, or 254 OK. Air brake protecting valve OK. Air hose 230 or 256 OK. Load sensing valve control port tee fitting OK. Air hose 240 or 243 OK. Booster valve OK. Service gladhand two-way check valve OK. Air hose 145 OK. Air hose 120 OK. Inversion valve control port 90-degree fitting OK. Air hose 128, 130, or 132 OK.
POSSIBLE PROBLEMS
Faulty air hose 149, 150, or 151. Faulty air hose 102. Faulty air hose 108. Faulty TRAILER AIR SUPPLY valve. Faulty air hose 104.




TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, air hose (refer to Table 2-49.4. Air Brake Protecting Valve Control Hose Numbers) is faulty.

- (1) Loosen air hose 102 at cab floor fitting.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 102.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 7 of this fault.
- (7) If air is present, replace air hose (refer to Table 2-49.4. Air Brake Protecting Valve Control Hose Numbers) (para 11-21).
- (8) Tighten air hose 102 at cab floor fitting.

Table 2-49.4. Air Brake Protecting Valve Control Hose Numbers


Model	Hose
All Except M1086 and M1089	149
M1086	150
M1089	151



XBJ4006B

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)


KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Air hose 149, 150, or 151 OK. Service gladhand OK. Air hose 241, 253, or 254 OK. Air brake protecting valve OK. Air hose 230 or 256 OK. Load sensing valve control port tee fitting OK. Air hose 240 or 243 OK. Booster valve OK. Service gladhand two-way check valve OK. Air hose 145 OK. Air hose 120 OK. Inversion valve control port 90-degree fitting OK. Air hose 128, 130, or 132 OK.
POSSIBLE PROBLEMS
Faulty air hose 102. Faulty air hose 108. Faulty TRAILER AIR SUPPLY valve. Faulty air hose 104.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, air hose 102 is faulty.




- (1) Remove roll pins from knobs of SYSTEM PARK and TRAILER AIR SUPPLY valves.
- (2) Remove SYSTEM PARK and TRAILER AIR SUPPLY valve knobs.
- (3) Unscrew nuts at base of valve stem on each valve.
- (4) Remove six screws and dash plate from personnel heater.
- (5) Pull out TRAILER AIR SUPPLY valve from personnel heater.
- (6) Loosen air hose 102 at TRAILER AIR SUPPLY valve delivery port.
- (7) Start engine (TM 9-2320-366-10-1).
- (8) Push in SYSTEM PARK control (TM 9-2320-366-10-1).
- (9) Push in TRAILER AIR SUPPLY valve stem.
- (10) Check for presence of air at TRAILER AIR SUPPLY valve delivery port.
- (11) If air is not present, go to step 8 of this fault.
- (12) If air is present, replace air hose 102 (para 11-21).
- (13) Shut down engine (TM 9-2320-366-10-1).
- (14) Tighten air hose 102 at TRAILER AIR SUPPLY valve delivery port.



XbJ4007b

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)


KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Air hose 149, 150, or 151 OK. Air hose 102 OK. Service gladhand OK. Air hose 241, 253, or 254 OK. Air brake protecting valve OK. Air hose 230 or 256 OK. Load sensing valve control port tee fitting OK. Air hose 240 or 243 OK. Booster valve OK. Service gladhand two-way check valve OK. Air hose 145 OK. Air hose 120 OK. Inversion valve control port 90-degree fitting OK. Air hose 128, 130, or 132 OK.
POSSIBLE PROBLEMS
Faulty air hose 108. Faulty TRAILER AIR SUPPLY valve. Faulty air hose 104.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is not present, air hose 108 is faulty.




- (1) Loosen air hose 108 at TRAILER AIR SUPPLY valve control port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in SYSTEM PARK control (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 108.
- (5) If air is not present, replace air hose 108 (para 11-21).
- (6) Shut down engine (TM 9-2320-366-10-1).
- (7) Tighten air hose 108 at TRAILER AIR SUPPLY valve control port.



XBJ4008B

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)


KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Air hose 149, 150, or 151 OK. Air hose 102 OK. Air hose 108 OK. Service gladhand OK. Air hose 241, 253, or 254 OK. Air brake protecting valve OK. Air hose 230 or 256 OK. Load sensing valve control port tee fitting OK. Air hose 240 or 243 OK. Booster valve OK. Service gladhand two-way check valve OK. Air hose 145 OK. Air hose 120 OK. Inversion valve control port 90-degree fitting OK. Air hose 128, 130, or 132 OK.
POSSIBLE PROBLEMS
Faulty TRAILER AIR SUPPLY valve. Faulty air hose 104.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is not present, air hose 104 is faulty. If air is present, TRAILER AIR SUPPLY valve is faulty.




- (1) Loosen air hose 104 at TRAILER AIR SUPPLY valve supply port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in SYSTEM PARK control (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 104.
- (5) If air is not present, replace air hose 104 (para 11-21).
- (6) If air is present, replace TRAILER AIR SUPPLY valve (para 11-20).
- (7) Shut down engine (TM 9-2320-366-10-1).
- (8) Tighten air hose 104 at TRAILER AIR SUPPLY valve supply port.
- (9) Push SYSTEM PARK and TRAILER AIR SUPPLY valves back into personnel heater.
- (10) Install dash plate on personnel heater with six screws.
- (11) Install nuts on valve stems.
- (12) Install SYSTEM PARK and TRAILER AIR SUPPLY knobs.



XBJ4009B

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

- (1) Loosen air hose (refer to Table 2-49.5. Service Gladhand Hose Numbers) at service gladhand.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Apply service brakes (TM 9-2320-366-10-1).
- (5) Check for presence of air at air hose (refer to Table 2-49.5. Service Gladhand Hose Numbers).
- (6) Shut down engine (TM 9-2320-366-10-1).
- (7) If air is not present, go to step 11 of this fault.
- (8) If air is present, replace service gladhand (para 11-24).
- (9) Tighten air hose (refer to Table 2-49.5. Service Gladhand Hose Numbers) at service gladhand.






Table 2-49.5. Service Gladhand Hose Numbers

Model	Hose
All Except M1086 and M1089	241
M1086	254
M1089	253

4BJ4010B

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Service gladhand OK. Air hose 149, 150, or 151 OK. Air hose 102 OK. Air hose 108 OK. TRAILER AIR SUPPLY valve OK. Air hose 104 OK.
POSSIBLE PROBLEMS
Faulty air hose 241, 253, or 254. Faulty air brake protecting valve. Faulty air hose 230 or 256. Faulty load sensing valve control port tee fitting. Faulty air hose 240 or 243. Faulty booster valve. Faulty service gladhand two-way check valve. Faulty air hose 145. Faulty air hose 120. Faulty inversion valve control port 90-degree fitting. Faulty air hose 128, 130, or 132.




TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, air hose (refer to Table 2-49.6. Service Gladhand Hose Numbers) is faulty.



- (1) Loosen air hose (refer to Table 2-49.6. Service Gladhand Hose Numbers) at air brake protecting valve delivery port TRLR S.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Apply service brakes (TM 9-2320-366-10-1).
- (5) Check for presence of air at air brake protecting valve delivery port TRLR S.
- (6) Shut down engine (TM 9-2320-366-10-1).
- (7) If air is not present, go to step 12 of this fault.
- (8) If air is present, replace air hose (refer to Table 2-49.6. Service Gladhand Hose Numbers) (para 11-21).
- (9) Tighten air hose (refer to Table 2-49.6. Service Gladhand Hose Numbers) at air brake protecting valve delivery port TRLR S.

Table 2-49.6. Service Gladhand Hose Numbers


Model	Hose
All Except M1086 and M1089	241
M1086	254
M1089	253



4b j4011b

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Service gladhand OK. Air hose 149, 150, or 151 OK. Air hose 102 OK. Air hose 108 OK. TRAILER AIR SUPPLY valve OK. Air hose 104 OK. Air hose 241, 253, or 254 OK.
POSSIBLE PROBLEMS
Faulty air brake protecting valve. Faulty air hose 230 or 256. Faulty load sensing valve control port tee fitting. Faulty air hose 240 or 243. Faulty booster valve. Faulty service gladhand two-way check valve. Faulty air hose 145. Faulty air hose 120. Faulty inversion valve control port 90-degree fitting. Faulty air hose 128, 130, or 132.




TEST OPTIONS
Visual inspection
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.

- (1) Loosen air hose (refer to Table 2-49.7. Air Brake Protecting Valve Supply Hose Numbers) at air brake protecting valve supply port FV1.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply service brakes (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose (refer to Table 2-49.7 Air Brake Protecting Valve Supply Hose Numbers).
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 14 of this fault (all models except M1089) or step 16 of this fault (M1089).
- (7) Tighten air hose (refer to Table 2-49.7. Air Brake Protecting Valve Supply Hose Numbers) at air brake protecting valve supply port FV1.

Table 2-49.7. Air Brake Protecting Valve Supply Hose Numbers

Model	Hose
All Except M1089	230
M1089	256



4BJ4012B


j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Service gladhand OK. Air hose 149, 150, or 151 OK. Air hose 102 OK. Air hose 108 OK. TRAILER AIR SUPPLY valve OK. Air hose 104 OK. Air hose 241, 253, or 254 OK. Air hose 230 or 256 OK. Load sensing valve control port tee fitting OK. Air hose 240 or 243 OK. Booster valve OK. Service gladhand two-way check valve OK. Air hose 145 OK.
POSSIBLE PROBLEMS
Faulty air brake protecting valve. Faulty air hose 120. Faulty inversion valve control port 90-degree fitting. Faulty air hose 128, 130, or 132.


13.

Is air present at air brake protecting valve supply port FV2?

TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
If air is present, air brake protecting valve is faulty.




- (1) Loosen air hose 120 at air brake protecting valve supply port FV2.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply service brakes (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 120.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 19 of this fault.
- (7) If air is present, replace air brake protecting valve (para 11-18).
- (8) Tighten air hose 120 at air brake protecting valve supply port FV2.



4BJ4013B

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)


KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Service gladhand OK. Air hose 149, 150, or 151 OK. Air hose 102 OK. Air hose 108 OK. TRAILER AIR SUPPLY valve OK. Air hose 104 OK. Air hose 241, 253, or 254 OK. Air brake protecting valve OK. Air hose 120 OK. Inversion valve control port 90-degree fitting OK. Air hose 128, 130, or 132 OK.
POSSIBLE PROBLEMS
Faulty air hose 230. Faulty load sensing valve control port tee fitting. Faulty air hose 240 or 243. Faulty booster valve. Faulty service gladhand two-way check valve. Faulty air hose 145.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, air hose 230 is faulty.



- (1) Loosen air hose 230 at load sensing valve control port tee fitting delivery port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply service brakes (TM 9-2320-366-10-1).
- (4) Check for presence of air at load sensing valve control port tee fitting delivery port.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 15 of this fault.
- (7) If air is present, replace air hose 230 (para 11-21).
- (8) Tighten air hose 230 at load sensing valve control port tee fitting delivery port.



4BJ4014B


j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Service gladhand OK. Air hose 149, 150, or 151 OK. Air hose 102 OK. Air hose 108 OK. TRAILER AIR SUPPLY valve OK. Air hose 104 OK. Air hose 241, 253, or 254 OK. Air brake protecting valve OK. Air hose 230 OK. Air hose 120 OK. Inversion valve control port 90-degree fitting OK. Air hose 128, 130, or 132 OK.
POSSIBLE PROBLEMS
Faulty load sensing valve control port tee fitting. Faulty air hose 240 or 243. Faulty booster valve. Faulty service gladhand two-way check valve. Faulty air hose.

15.

Is air present at load sensing valve control port tee fitting supply port?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, load sensing valve control port tee fitting is faulty.



- (1) Loosen air hose (refer to Table 2-49.8. Load Sensing Valve Control Port Tee Hose Numbers) at load sensing valve control port tee fitting supply port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply service brakes (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose (refer to Table 2-49.8. Load Sensing Valve Control Port Tee Hose Numbers) .
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 16 of this fault.
- (7) If air is present, replace load sensing valve control port tee fitting (para 11-10).
- (8) Tighten air hose (refer to Table 2-49.8. Load Sensing Valve Control Port Tee Hose Numbers) at load sensing valve control port tee fitting supply port.

Table 2-49.8. Load Sensing Valve Control Port Tee Hose Numbers

Model	Hose
All Except M1086	240
M1086	243




4bJ4015b

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Service gladhand OK. Air hose 149, 150, or 151 OK. Air hose 102 OK. Air hose 108 OK. TRAILER AIR SUPPLY valve OK. Air hose 104 OK. Air hose 241, 253, or 254 OK. Air brake protecting valve OK. Air hose 230 OK. Load sensing valve control port tee fitting OK. Air hose 120 OK. Inversion valve control port 90-degree fitting OK. Air hose 128, 130, or 132 OK.
POSSIBLE PROBLEMS
Faulty air hose 240, 243, or 256. Faulty booster valve. Faulty service gladhand two-way check valve. Faulty air hose 145.

16.
Is air present at booster valve delivery port?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, air hose (refer to Table 2-49.9. Booster Valve Delivery Hose Numbers) is faulty.



- (1) Loosen air hose (refer to Table 2-49.9. Booster Valve Delivery Hose Numbers) at booster valve delivery port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply service brakes (TM 9-2320-366-10-1).
- (4) Check for presence of air at booster valve delivery port.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 17 of this fault.
- (7) If air is present, replace air hose (refer to Table 2-49.9. Booster Valve Delivery Hose Numbers) (para 11-21).
- (8) Tighten air hose (refer to Table 2-49.9. Booster Valve Delivery Hose Numbers) at booster valve delivery port.

Table 2-49.9. Booster Valve Delivery Hose Numbers


Model	Hose
All Except M1086 and M1089	240
M1086	243
M1089	256



4BJ4016B


j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Service gladhand OK. Air hose 149, 150, or 151 OK. Air hose 102 OK. Air hose 108 OK. TRAILER AIR SUPPLY valve OK. Air hose 104 OK. Air hose 241, 253, or 254 OK. Air brake protecting valve OK. Air hose 230 or 256 OK. Load sensing valve control port tee fitting OK. Air hose 240 or 243 OK. Air hose 120 OK. Inversion valve control port 90-degree fitting OK. Air hose 128, 130, or 132 OK.
POSSIBLE PROBLEMS
Faulty booster valve. Faulty service gladhand two-way check valve. Faulty air hose 145.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, booster valve is faulty.

- (1) Loosen air hose 145 at booster valve supply port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply service brakes (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 145.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 18 of this fault.
- (7) If air is present, replace booster valve (para 11-15).
- (8) Tighten air hose 145 at booster valve supply port.




4BJ4017B

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)



KNOWN INFO
Vehicle park and service brakes OK.
Air hoses free from kinks.
Emergency gladhand OK.
Air hose 155, 157, or 167 OK.
Service gladhand OK.
Air hose 149, 150, or 151 OK.
Air hose 102 OK.
Air hose 108 OK.
TRAILER AIR SUPPLY valve OK.
Air hose 104 OK.
Air hose 241, 253, or 254 OK.
Air brake protecting valve OK.
Air hose 230 or 256 OK.
Load sensing valve control port tee fitting OK.
Air hose 240 or 243 OK.
Booster valve OK.
Air hose 120 OK.
Inversion valve control port 90-degree fitting OK.
Air hose 128, 130, or 132 OK.
POSSIBLE PROBLEMS
Faulty service gladhand two-way check valve.
Faulty air hose 145.

18.
Is air present at service gladhand two-way check valve delivery port?

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is not present, service gladhand two-way check valve is faulty. If air is present, air hose 145 is faulty.



- (1) Raise cab (TM 9-2320-366-10-1).
- (2) Loosen air hose 145 at service gladhand two-way check valve delivery port.
- (3) Start engine (TM 9-2320-366-10-1).
- (4) Apply service brakes (TM 9-2320-366-10-1).
- (5) Check for presence of air at service gladhand two-way check valve delivery port.
- (6) Shut down engine (TM 9-2320-366-10-1).
- (7) If air is not present, replace service gladhand two-way check valve (para 11-25).
- (8) If air is present, replace air hose 145 (para 11-21).
- (9) Tighten air hose 145 at service gladhand two-way check valve delivery port.
- (10) Lower cab (TM 9-2320-366-10-1).



4bJ4018b


j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Service gladhand OK. Air hose 149, 150, or 151 OK. Air hose 102 OK. Air hose 108 OK. TRAILER AIR SUPPLY valve OK. Air hose 104 OK. Air hose 241, 253, or 254 OK. Air hose 230 or 256 OK. Load sensing valve control port tee fitting OK. Air hose 240 or 243 OK. Booster valve OK. Service gladhand two-way check valve OK. Air hose 145 OK. Air brake protecting valve OK.
POSSIBLE PROBLEMS
Faulty air hose 120. Faulty inversion valve control port 90-degree fitting. Faulty air hose 128, 130, or 132.



19.

Is air present at inversion valve control port 90-degree fitting delivery port?

TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
If air is present, air hose 120 is faulty.



- (1) Loosen air hose 120 at inversion valve control port 90-degree fitting delivery port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply service brakes (TM 9-2320-366-10-1).
- (4) Check for presence of air at inversion valve control port 90-degree fitting delivery port.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 20 of this fault.
- (7) If air is present, replace air hose 120 (para 11-21).
- (8) Tighten air hose 120 at inversion valve control port 90-degree fitting delivery port.




4BJ4019B

j4. NO AIR PRESSURE PRESENT AT REAR GLADHAND(S)
(ALL MODELS EXCEPT M1088) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Emergency gladhand OK. Air hose 155, 157, or 167 OK. Service gladhand OK. Air hose 149, 150, or 151 OK. Air hose 102 OK. Air hose 108 OK. TRAILER AIR SUPPLY valve OK. Air hose 104 OK. Air hose 241, 253, or 254 OK. Air hose 230 or 256 OK. Load sensing valve control port tee fitting OK. Air hose 240 or 243 OK. Booster valve OK. Service gladhand two-way check valve OK. Air hose 145 OK. Air brake protecting valve OK. Air hose 120 OK.
POSSIBLE PROBLEMS
Faulty inversion valve control port 90-degree fitting. Faulty air hose 128, 130, or 132.

20.
Is air present at inversion valve control port 90-degree fitting supply port?

TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
If air is not present, air hose (refer to Table 2-49.10. Inversion Valve Control Port Fitting Hose Numbers) is faulty. If air is present, inversion valve control port 90-degree fitting is faulty.



- (1) Loosen air hose (refer to Table 2-49.10. Inversion Valve Control Port Fitting Hose Numbers) at inversion valve control port 90-degree fitting supply port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply service brakes (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose (refer to Table 2-49.10. Inversion Valve Control Port Fitting Hose Numbers).
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, replace air hose (refer to Table 2-49.10. Inversion Valve Control Port Fitting Hose Numbers) (para 11-21).
- (7) If air is present, replace inversion valve control port 90-degree fitting (para 11-13).
- (8) Tighten air hose (refer to Table 2-49.10. Inversion Valve Control Port Fitting Hose Numbers) at inversion valve control port 90-degree fitting supply port.




Table 2-49.10. Inversion Valve Control Port Fitting Hose Numbers

Model	Hose
All Except M1086 and M1089	130
M1086	132
M1089	128


4b J4020b

j4A. NO AIR PRESSURE PRESENT AT ALL M1088 REAR AND FIFTH WHEEL GLADHANDS

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).



Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Goggles, Industrial (Item 15, Appendix C)



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

- (1) Loosen air hose 134 at air brake protecting valve control port TRA E.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 134.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 2 of this fault.
- (7) If air is present, replace air brake protecting valve (para 11-18).
- (8) Tighten air hose 134 at air brake protecting valve control port TRA E.



4BJ4A01B


j4A. NO AIR PRESSURE PRESENT AT ALL M1088 REAR AND FIFTH WHEEL GLADHANDS (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air brake protecting valve OK.
POSSIBLE PROBLEMS
Faulty air hose 134. Faulty air hose 102. Faulty air hose 108. Faulty air hose 104. Faulty TRAILER AIR SUPPLY valve.

2.

Is air present at cab floor fitting?

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, air hose 134 is faulty.




KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air brake protecting valve OK. Air hose 134 OK.
POSSIBLE PROBLEMS
Faulty air hose 102. Faulty air hose 108. Faulty air hose 104. Faulty TRAILER AIR SUPPLY valve.



3.

Is air present at TRAILER AIR SUPPLY valve delivery port?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, air hose 102 is faulty.



- (1) Loosen air hose 102 at cab floor fitting.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 102.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 3 of this fault.
- (7) If air is present, replace air hose 134 (para 11-21).
- (8) Tighten air hose 102 at cab floor fitting.



- (1) Remove roll pins from knobs of SYSTEM PARK and TRAILER AIR SUPPLY valves.
- (2) Remove SYSTEM PARK and TRAILER AIR SUPPLY valve knobs.
- (3) Unscrew nuts at base of valve stem on each valve.
- (4) Remove six screws and dash plate from personnel heater.
- (5) Pull out TRAILER AIR SUPPLY valve from personnel heater.
- (6) Loosen air hose 102 at TRAILER AIR SUPPLY valve delivery port.
- (7) Start engine (TM 9-2320-366-10-1).
- (8) Push in SYSTEM PARK control (TM 9-2320-366-10-1).
- (9) Push in TRAILER AIR SUPPLY valve stem.
- (10) Check for presence of air at TRAILER AIR SUPPLY valve delivery port.
- (11) If air is not present, go to step 4 of this fault.
- (12) If air is present, replace air hose 102 (para 11-21).
- (13) Shut down engine (TM 9-2320-366-10-1).
- (14) Tighten air hose 102 at TRAILER AIR SUPPLY valve delivery port.




4BJ4A03B

j4A. NO AIR PRESSURE PRESENT AT ALL M1088 REAR AND FIFTH WHEEL GLADHANDS (CONT)


KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air brake protecting valve OK. Air hose 134 OK. Air hose 102 OK.
POSSIBLE PROBLEMS
Faulty air hose 108. Faulty air hose 104. Faulty TRAILER AIR SUPPLY valve.

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is not present, air hose 108 is faulty.




KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air brake protecting valve OK. Air hose 134 OK. Air hose 102 OK. Air hose 108 OK.
POSSIBLE PROBLEMS
Faulty air hose 104. Faulty TRAILER AIR SUPPLY valve.


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is not present, air hose 104 is faulty. If air is present, TRAILER AIR SUPPLY valve is faulty.



- (1) Loosen air hose 108 at TRAILER AIR SUPPLY valve control port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in SYSTEM PARK control (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 108.
- (5) If air is not present, replace air hose 108 (para 11-21).
- (6) Shut down engine (TM 9-2320-366-10-1).
- (7) Tighten air hose 108 at TRAILER AIR SUPPLY valve control port.



- (1) Loosen air hose 104 at TRAILER AIR SUPPLY valve supply port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in SYSTEM PARK control (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 104.
- (5) If air is not present, replace air hose 104 (para 11-21).
- (6) If air is present, replace TRAILER AIR SUPPLY valve (para 11-20).
- (7) Shut down engine (TM 9-2320-366-10-1).
- (8) Tighten air hose 104 at TRAILER AIR SUPPLY valve supply port.
- (9) Push SYSTEM PARK and TRAILER AIR SUPPLY valves back into personnel heater.
- (10) Install dash plate on personnel heater with six screws.
- (11) Install nuts on valve stems.
- (12) Install SYSTEM PARK and TRAILER AIR SUPPLY knobs.




4BJ4A04B

j4B. NO AIR PRESSURE PRESENT AT M1088 REAR AND/OR FIFTH WHEEL EMERGENCY GLADHAND(S)


INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Goggles, Industrial (Item 15, Appendix C)




- (1) Disconnect dummy coupling from rear emergency gladhand.
- (2) Position emergency gladhand selector valve handle to rear position (TM 9-232-366-10-1).
- (3) Start engine (TM 9-2320-366-10-1).
- (4) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (5) Check for presence of air at rear emergency gladhand.
- (6) Shut down engine (TM 9-2320-366-10-1).
- (7) Connect dummy coupling to rear emergency gladhand.
- (8) Disconnect fifth wheel emergency gladhand from dummy coupling.
- (9) Position emergency gladhand selector valve handle to fifth wheel position (TM 9-232-366-10-1).
- (10) Start engine (TM 9-2320-366-10-1).
- (11) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (12) Check for presence of air at fifth wheel emergency gladhand.
- (13) Shut down engine (TM 9-2320-366-10-1).
- (14) Connect fifth wheel emergency gladhand to dummy coupling.
- (15) If air is not present at both emergency gladhands, go to step 4 of this fault.



4BJ4B01B


j4B. NO AIR PRESSURE PRESENT AT M1088 REAR AND/OR FIFTH WHEEL EMERGENCY GLADHAND(S) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air present at rear and fifth wheel service gladhands. Air hose 165 OK. Air brake protecting valve OK.
POSSIBLE PROBLEMS
Faulty rear or fifth wheel emergency gladhand. Faulty air hose 163 or 170. Faulty emergency gladhand selector valve.




TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, affected emergency gladhand is faulty.

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air present at rear and fifth wheel service gladhands. Rear and fifth wheel emergency gladhands OK. Air hose 165 OK. Air brake protecting valve OK.
POSSIBLE PROBLEMS
Faulty air hose 163 or 170. Faulty emergency gladhand selector valve.




TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is not present, emergency gladhand selector valve is faulty. If air is present, air hose 163 or 170 is faulty.

- (1) Loosen air hose 163 at rear emergency gladhand or air hose 170 at fifth wheel emergency gladhand.
- (2) Position emergency gladhand selector valve to affected gladhand (TM 9-2320-366-10-1).
- (3) Start engine (TM 9-2320-366-10-1).
- (4) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (5) Check for presence of air at air hose 163 or 170.
- (6) Shut down engine (TM 9-2320-366-10-1).
- (7) If air is not present, go to step 3 of this fault.
- (8) If air is present, replace rear emergency gladhand (para 11-24) or fifth wheel emergency gladhand (para 11-33).
- (9) Tighten air hose 163 at rear emergency gladhand or air hose 170 at fifth wheel emergency gladhand.



- (1) Loosen air hose 163 (rear emergency gladhand) or 170 (fifth wheel emergency gladhand) at emergency gladhand selector valve output to affected gladhand.
- (2) Position emergency gladhand selector valve to affected gladhand (TM 9-2320-366-10-1).
- (3) Start engine (TM 9-2320-366-10-1).
- (4) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (5) Check for presence of air at emergency gladhand selector valve output to affected emergency gladhand.
- (6) Shut down engine (TM 9-2320-366-10-1).
- (7) If air is not present, replace emergency gladhand selector valve (para 11-33).
- (8) If air is present, replace air hose 163 or 170 (para 11-21).
- (9) Tighten air hose 163 (rear emergency gladhand) or 170 (fifth wheel emergency gladhand) at emergency gladhand selector valve output to affected gladhand.




4BJ4B02B

j4B. NO AIR PRESSURE PRESENT AT M1088 REAR AND/OR FIFTH WHEEL EMERGENCY GLADHAND(S) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air present at rear and fifth wheel service gladhands. Rear and fifth wheel emergency gladhands OK. Air hoses 163 and 170 OK.
POSSIBLE PROBLEMS
Faulty emergency gladhand selector valve. Faulty air hose 165. Faulty air brake protecting valve.

4.
Is air present at emergency gladhand selector valve supply port?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, emergency gladhand selector valve is faulty.




KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air present at rear and fifth wheel service gladhands. Rear and fifth wheel emergency gladhands OK. Air hoses 163 and 170 OK. Emergency gladhand selector valve OK.
POSSIBLE PROBLEMS
Faulty air hose 165. Faulty air brake protecting valve.

5.
Is air present at air brake protecting valve delivery port TRLR E?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is not present, air brake protecting valve is faulty. If air is present, air hose 165 is faulty.



- (1) Loosen air hose 165 at emergency gladhand selector valve supply port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 165.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 5 of this fault.
- (7) If air is present, replace emergency gladhand selector valve (para 11-33).
- (8) Tighten air hose 165 at emergency gladhand selector valve supply port.




AIR HOSE 165



- (1) Loosen air hose 165 at air brake protecting valve delivery port TRLR E.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Check for presence of air at air brake protecting valve delivery port TRLR E.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, replace air brake protecting valve (para 11-18).
- (7) If air is present, replace air hose 165 (para 11-21).
- (8) Tighten air hose 165 at air brake protecting valve delivery port TRLR E.

CONTROL PORT TRLR E



AIR BRAKE PROTECTING VALVE

AIR HOSE 165


4BJ4B04B

j4C. NO AIR PRESSURE PRESENT AT M1088 REAR AND/OR FIFTH WHEEL SERVICE GLADHAND(S)




INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Goggles, Industrial (Item 15, Appendix C)




- (1) Disconnect dummy coupling from rear service gladhand.
- (2) Position service gladhand selector valve handle to rear position (TM 9-232-366-10-1).
- (3) Start engine (TM 9-2320-366-10-1).
- (4) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (5) Apply service brakes (TM 9-2320-366-10-1).
- (6) Check for presence of air at rear service gladhand.
- (7) Shut down engine (TM 9-2320-366-10-1).
- (8) Connect dummy coupling to rear service gladhand.
- (9) Disconnect fifth wheel service gladhand from dummy coupling.
- (10) Position service gladhand selector valve handle to fifth wheel position (TM 9-232-366-10-1).
- (11) Start engine (TM 9-2320-366-10-1).
- (12) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (13) Apply service brakes (TM 9-2320-366-10-1).
- (14) Check for presence of air at fifth wheel service gladhand.
- (15) Shut down engine (TM 9-2320-366-10-1).
- (16) Connect fifth wheel service gladhand to dummy coupling.
- (17) If air is not present at both service gladhands, go to step 4 of this fault.



4BJ4C01B



j4C. NO AIR PRESSURE PRESENT AT M1088 REAR AND/OR FIFTH WHEEL SERVICE GLADHAND(S) (CONT)



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

- (1) Loosen air hose 257 at rear service gladhand or air hose 263 at fifth wheel service gladhand.
- (2) Position service gladhand selector valve to affected gladhand (TM 9-2320-366-10-1).
- (3) Start engine (TM 9-2320-366-10-1).
- (4) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (5) Apply service brakes (TM 9-2320-366-10-1).
- (6) Check for presence of air at air hose 257 or 263.
- (7) Shut down engine (TM 9-2320-366-10-1).
- (8) If air is not present, go to step 3 of this fault.
- (9) If air is present, replace rear service gladhand (para 11-24) or fifth wheel service gladhand (para 11-33).
- (10) Tighten air hose 257 at rear service gladhand or air hose 263 at fifth wheel service gladhand.



4BJ4C02B


j4C. NO AIR PRESSURE PRESENT AT M1088 REAR AND/OR FIFTH WHEEL SERVICE GLADHAND(S) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air present at rear and fifth wheel emergency gladhands. Rear and fifth wheel service gladhands OK. Air hose 258 OK. Air hose 135 OK. Air brake protecting valve OK. Air hose 256 OK. Booster valve OK. Service gladhand two-way check valve OK. Air hose 145 OK.
POSSIBLE PROBLEMS
Faulty air hose 257 or 263. Faulty service gladhand selector valve.

3.

Is air present at service gladhand selector valve output to affected service gladhand?

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is not present, service gladhand selector valve is faulty. If air is present, air hose 257 or 263 is faulty.




KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air present at rear and fifth wheel emergency gladhands. Rear and fifth wheel service gladhands OK. Air hoses 257 and 263 OK.
POSSIBLE PROBLEMS
Faulty service gladhand selector valve. Faulty air hose 258. Faulty air hose 135. Faulty air brake protecting valve. Faulty air hose 256. Faulty booster valve. Faulty service gladhand two-way check valve. Faulty air hose 145.



4.

Is air present at service gladhand selector valve supply port?

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, service gladhand selector valve is faulty.



- (1) Loosen air hose 257 (rear service gladhand) or 263 (fifth wheel service gladhand) at service gladhand selector valve output to affected service gladhand.
- (2) Position service gladhand selector valve to to affected gladhand (TM 9-2320-366-10-1).
- (3) Start engine (TM 9-2320-366-10-1).
- (4) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (5) Apply service brakes (TM 9-2320-366-10-1).
- (6) Check for presence of air at service gladhand selector valve output to affected service gladhand.
- (7) Shut down engine (TM 9-2320-366-10-1).
- (8) If air is not present, replace service gladhand selector valve (para 11-33).
- (9) If air is present, replace air hose 257 or 263 (para 11-21).
- (10) Tighten air hose 257 (rear service gladhand) or 263 (fifth wheel service gladhand) at service gladhand selector valve output to affected service gladhand.




4BJ4C03B

- (1) Loosen air hose 258 at service gladhand selector valve supply port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Apply service brakes (TM 9-2320-366-10-1).
- (5) Check for presence of air at air hose 258.
- (6) Shut down engine (TM 9-2320-366-10-1).
- (7) If air is not present, go to step 5 of this fault.
- (8) If air is present, replace service gladhand selector valve (para 11-33).
- (9) Tighten air hose 258 at service gladhand selector valve supply port.


j4C. NO AIR PRESSURE PRESENT AT M1088 REAR AND/OR FIFTH WHEEL SERVICE GLADHAND(S) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air present at rear and fifth wheel emergency gladhands. Rear and fifth wheel service gladhands OK. Air hoses 257 and 263 OK. Service gladhand selector valve OK.
POSSIBLE PROBLEMS
Faulty air hose 258. Faulty air hose 135. Faulty air brake protecting valve. Faulty air hose 256. Faulty booster valve. Faulty service gladhand two-way check valve. Faulty air hose 145.





TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, air hose 258 is faulty.

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air present at rear and fifth wheel emergency gladhands. Rear and fifth wheel service gladhands OK. Air hoses 257 and 263 OK. Service gladhand selector valve OK. Air hose 258 OK.
POSSIBLE PROBLEMS
Faulty air hose 135. Faulty air brake protecting valve. Faulty air hose 256. Faulty booster valve. Faulty service gladhand two-way check valve. Faulty air hose 145.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
This question eliminates possible problems and determines where troubleshooting continues.

- (1) Loosen air hose 258 at air brake protecting valve delivery port TRLR S.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Push in TRAILER AIR SUPPLY control (TM 9-2320-366-10-1).
- (4) Apply service brakes (TM 9-2320-366-10-1).
- (5) Check for presence of air at air brake protecting valve delivery port TRLR S.
- (6) Shut down engine (TM 9-2320-366-10-1).
- (7) If air is not present, go to step 6 of this fault.
- (8) If air is present, replace air hose 258 (para 11-21).
- (9) Tighten air hose 258 at air brake protecting valve delivery port TRLR S.




4BJ4C05B

- (1) Loosen air hose 256 at air brake protecting valve supply port FV1.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply service brakes (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 256.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 8 of this fault.
- (7) Tighten air hose 256 at air brake protecting valve supply port FV1.


j4C. NO AIR PRESSURE PRESENT AT M1088 REAR AND/OR FIFTH WHEEL SERVICE GLADHAND(S) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air present at rear and fifth wheel emergency gladhands. Rear and fifth wheel service gladhands OK. Air hoses 257 and 263 OK. Service gladhand selector valve OK. Air hose 258 OK. Air hose 256 OK. Booster valve OK. Service gladhand two-way check valve OK. Air hose 145 OK.
POSSIBLE PROBLEMS
Faulty air hose 135. Faulty air brake protecting valve.





TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
If air is not present, air hose 135 is faulty. If air is present, air brake protecting valve is faulty.

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air present at rear and fifth wheel emergency gladhands. Rear and fifth wheel service gladhands OK. Air hoses 257 and 263 OK. Service gladhand selector valve OK. Air hose 258 OK. Air hose 135 OK. Air brake protecting valve OK.
POSSIBLE PROBLEMS
Faulty air hose 256. Faulty booster valve. Faulty service gladhand two-way check valve. Faulty air hose 145.



TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, air hose 256 is faulty.

- (1) Loosen air hose 135 at air brake protecting valve supply port FV2.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply service brakes (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 135.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, replace air hose 135 (para 11-21).
- (7) If air is present, replace air brake protecting valve (para 11-18).
- (8) Tighten air hose 135 at air brake protecting valve supply port FV2.




4BJ4C07B

- (1) Loosen air hose 256 at booster valve delivery port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply service brakes (TM 9-2320-366-10-1).
- (4) Check for presence of air at booster valve delivery port.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 9 of this fault.
- (7) If air is present, replace air hose 256 (para 11-21).
- (8) Tighten air hose 256 at booster valve delivery port.


j4C. NO AIR PRESSURE PRESENT AT M1088 REAR AND/OR FIFTH WHEEL SERVICE GLADHAND(S) (CONT)

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air present at rear and fifth wheel emergency gladhands. Rear and fifth wheel service gladhands OK. Air hoses 257 and 263 OK. Service gladhand selector valve OK. Air hose 258 OK. Air hose 135 OK. Air brake protecting valve OK. Air hose 256 OK.
POSSIBLE PROBLEMS
Faulty booster valve. Faulty service gladhand two-way check valve. Faulty air hose 145.




TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, booster valve is faulty.

KNOWN INFO
Vehicle park and service brakes OK. Air hoses free from kinks. Air present at rear and fifth wheel emergency gladhands. Rear and fifth wheel service gladhands OK. Air hoses 257 and 263 OK. Service gladhand selector valve OK. Air hose 258 OK. Air hose 135 OK. Air brake protecting valve OK. Air hose 256 OK. Booster valve OK.
POSSIBLE PROBLEMS
Faulty service gladhand two-way check valve. Faulty air hose 145.




TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is not present, service gladhand two-way check valve is faulty. If air is present, air hose 145 is faulty.

- (1) Loosen air hose 145 at booster valve supply port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply service brakes (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 145.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 10 of this fault.
- (7) If air is present, replace booster valve (para 11-15).
- (8) Tighten air hose 145 at booster valve supply port.



- (1) Raise cab (TM 9-2320-366-10-1).
- (2) Loosen air hose 145 at service gladhand two-way check valve delivery port.
- (3) Start engine (TM 9-2320-366-10-1).
- (4) Apply service brakes (TM 9-2320-366-10-1).
- (5) Check for presence of air at service gladhand two-way check valve delivery port.
- (6) Shut down engine (TM 9-2320-366-10-1).
- (7) If air is not present, replace service gladhand two-way check valve (para 11-25).
- (8) If air is present, replace air hose 145 (para 11-21).
- (9) Tighten air hose 145 at service gladhand two-way check valve delivery port.
- (10) Lower cab (TM 9-2320-366-10-1).




4BJ4C09B

j4D. M1088 TRAILER HANDBRAKE DOES NOT OPERATE

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).



Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Goggles, Industrial (Item 15, Appendix C)



WARNING

Wear appropriate eye protection when working under vehicle due to the possibility of falling debris. Failure to comply may result in injury to personnel.

- (1) Loosen air hose 162 at air brake protecting valve supply port HC.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply trailer handbrake control (TM 9-2320-366-10-1).
- (4) Check for presence of air at air hose 162.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, go to step 2 of this fault.
- (7) Tighten air hose 162 at air brake protecting valve supply port HC.




4BJ4D01B

j4D. M1088 TRAILER HANDBRAKE DOES NOT OPERATE (CONT)

KNOWN INFO
Air present at rear and fifth wheel gladhands when service brakes applied. Air hoses free from kinks. Air brake protecting valve OK.
POSSIBLE PROBLEMS
Faulty air hose 162. Faulty air hose 129. Faulty trailer service brake valve. Faulty park control two-way check valve. Faulty air hose 161.

2.
Is air present at cab floor fitting?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, air hose 162 is faulty.




KNOWN INFO
Air present at rear and fifth wheel gladhands when service brakes applied. Air hoses free from kinks. Air brake protecting valve OK. Air hose 162 OK.
POSSIBLE PROBLEMS
Faulty air hose 129. Faulty trailer service brake valve. Faulty park control two-way check valve. Faulty air hose 161.

3.
Is air present at trailer service brake valve delivery port?

TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, air hose 129 is faulty.



- (1) Remove kick panel (para 16-3).
- (2) Loosen air hose 129 at cab floor fitting.
- (3) Start engine (TM 9-2320-366-10-1).
- (4) Apply trailer service brake (TM 9-2320-366-10-1).
- (5) Check for presence of air at air hose 129.
- (6) Shut down engine (TM 9-2320-366-10-1).
- (7) If air is not present, go to step 3 of this fault.
- (8) If air is present, replace air hose 162 (para 11-21).
- (9) Tighten air hose 129 at cab floor fitting.
- (10) Install kick panel (para 16-3).




AIR HOSE 129

CAB FLOOR FITTING

STEERING WHEEL REMOVED FOR CLARITY

AIR HOSE 129



TRAILER SERVICE BRAKE VALVE

- (1) Loosen air hose 129 at trailer service brake valve delivery port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Apply trailer service brake (TM 9-2320-366-10-1).
- (4) Check for presence of air at trailer service brake valve delivery port.
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) If air is not present, replace trailer service brake valve (para 11-32).
- (7) If air is present, replace air hose 129 (para 11-21).
- (8) Tighten air hose 129 at trailer service brake valve delivery port.


4BJ4D02B

j4D. M1088 TRAILER HANDBRAKE DOES NOT OPERATE (CONT)

KNOWN INFO
Air present at rear and fifth wheel gladhands when service brakes applied. Air hoses free from kinks. Air brake protecting valve OK. Air hose 162 OK. Air hose 129 OK.
POSSIBLE PROBLEMS
Faulty trailer service brake valve. Faulty park control two-way check valve. Faulty air hose 161.

4.
Is air present at trailer service brake valve supply port?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is present, trailer service brake valve is faulty.





KNOWN INFO
Air present at rear and fifth wheel gladhands when service brakes applied. Air hoses free from kinks. Air brake protecting valve OK. Air hose 162 OK. Air hose 129 OK. Trailer service brake valve OK.
POSSIBLE PROBLEMS
Faulty park control two-way check valve. Faulty air hose 161.

5.
Is air present at park control two-way check valve delivery port?


TEST OPTIONS
Visual inspection
REASON FOR QUESTION
If air is not present, park control two-way check valve is faulty. If air is present, air hose 161 is faulty.



- (1) Loosen air hose 161 at trailer service brake valve supply port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Check for presence of air at air hose 161.
- (4) Shut down engine (TM 9-2320-366-10-1).
- (5) If air is not present, go to step 5 of this fault.
- (6) If air is present, replace trailer service brake valve (para 11-32).
- (7) Tighten air hose 161 at trailer service brake valve supply port.



- (1) Loosen air hose 161 at park control two-way check valve delivery port.
- (2) Start engine (TM 9-2320-366-10-1).
- (3) Check for presence of air at park control two-way check valve delivery port.
- (4) Shut down engine (TM 9-2320-366-10-1).
- (5) If air is not present, replace park control two-way check valve (para 11-19).
- (6) If air is present, replace air hose 161 (para 11-21).
- (7) Tighten air hose 161 at park control two-way check valve delivery port.



**j5. AIR SYSTEM PRESSURE BUILDS UP MORE THAN 120 PSI (827 KPA)
(COMPRESSOR FAILS TO UNLOAD)**


INITIAL SETUP

Equipment Conditions

Engine shut down (TM 9-2320-366-10-1).
Air tanks drained (TM 9-2320-366-10-1).

Tools and Special Tools


Tool Kit, Genl Mech (Item 46, Appendix C)
Goggles, Industrial (Item 15, Appendix C)



WARNING

Engine compartment includes a partially covered fan blade. Extreme care should be taken when working in the engine compartment. Failure to comply may result in injury to personnel.

- (1) Raise cab (TM 9-2320-366-10-1).
- (2) Disconnect (wet tank to governor) air hose from air compressor governor.
- (3) Lower cab (TM 9-2320-366-10-1).
- (4) Start engine (TM 9-2320-366-10-1).
- (5) Raise cab (TM 9-2320-366-10-1).
- (6) Check for air escaping from (wet tank to governor) air hose.
- (7) If no air escapes, clear or replace air hose from wet tank to air compressor governor (para 23-2).
- (8) Lower cab (TM 9-2320-366-10-1).
- (9) Shut down engine (TM 9-2320-366-10-1).
- (10) Raise cab (TM 9-2320-366-10-1).
- (11) Connect (wet tank to governor) air hose to air compressor governor.




XBJ0501B

j5. AIR SYSTEM PRESSURE BUILDS UP MORE THAN 120 PSI (827 KPA)
(COMPRESSOR FAILS TO UNLOAD) (CONT)


KNOWN INFO
FRONT BRAKE/REAR BRAKE AIR pressure gage reads above 120 psi. Air hose from wet tank to air compressor governor OK.
POSSIBLE PROBLEMS
Blocked governor air hose. Faulty air compressor governor. Faulty purge valve.

TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
Air compressor will fail to unload if air compressor to purge valve air hose is blocked.




KNOWN INFO
FRONT BRAKE/REAR BRAKE AIR pressure gage reads above 120 psi. Air hose from wet OK. Governor air hose OK.
POSSIBLE PROBLEMS
Faulty air compressor governor. Faulty purge valve.


TEST OPTIONS
Visual Inspection
REASON FOR QUESTION
If air is not present from air compressor, air compressor governor is faulty. If air is present air dryer purge valve is faulty.



- (1) Disconnect (air compressor to purge valve) air hose from air compressor and purge valve.
- (2) Blow through one end of air hose. If no air escapes from other end of air hose, air hose is blocked.
- (3) Connect (air compressor to purge valve) air hose to air compressor.
- (4) Lower cab (TM 9-2320-366-10-1).





- (1) Start engine (TM 9-2320-366-10-1).
- (2) Check for presence of air at (air compressor to purge valve) air hose.
- (3) If no air escapes from air hose, Adjust or replace air compressor governor (para 11-31).
- (4) If air escapes from air hose, service air dryer for faulty purge valve (para 23-11).
- (5) Shut down engine (TM 9-2320-366-10-1).
- (6) Connect (air compressor to purge valve) air hose to air dryer purge valve.




XB J0502B

j6. NOISY AIR COMPRESSOR OPERATION	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C)







- (1) Raise cab (TM 9-2320-366-10-1).
- (2) Check air compressor oil hoses for kinks.




Check air compressor coolant hoses.





j6. NOISY AIR COMPRESSOR OPERATION (CONT)






- (1) Check air compressor for loose or missing mounting hardware.
- (2) Lower cab (TM 9-2320-366-10-1).




X2 J0602A


j7. M1088 REAR GLADHAND(S) LEAKS OR DOES NOT OPERATE	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C)



- (1) Check if vehicle is equipped with selector valve.
- (2) If vehicle is not equipped with selector valve, install M1088 gladhand selector valve (para 11-33).
- (3) If vehicle is equipped with selector valve, replace rear gladhand (para 11-21).



SELECTOR VALVE




42J07011

j8. M1090/M1094 TAILGATE RELEASE DOES NOT OPERATE

INITIAL SETUP

Equipment Conditions
 Engine shut down (TM 9-2320-366-10-1).
 Dump body raised to maintenance position (TM 9-2320-366-10-1).

Tools and Special Tools
 Tool Kit, Genl Mech (Item 46, Appendix C)
 Goggles, Industrial (Item 15, Appendix C)



KNOWN INFO
Air tanks pressurized.
POSSIBLE PROBLEMS
Faulty solenoid valve. Faulty air hose to front port on tailgate pneumatic cylinder. Faulty air hose to rear port on tailgate pneumatic cylinder. Faulty tailgate pneumatic cylinder. Faulty pressure protection valve. Faulty air hose to port P on manual override valve. Faulty manual override valve. Faulty air hose to port P on solenoid valve.

KNOWN INFO
Air tanks pressurized. Pressure protection valve OK. Air hose to port P on manual override valve OK. Manual override valve OK. Air hose to port P on solenoid valve OK.
POSSIBLE PROBLEMS
Faulty solenoid valve. Faulty air hose to front port on tailgate pneumatic cylinder. Faulty air hose to rear port on tailgate pneumatic cylinder. Faulty tailgate pneumatic cylinder.


WARNING

Wear protective goggles to protect against possible injury from release of high pressure air. Failure to comply may result in injury to personnel.


NOTE

Inspect air hoses and fittings for cracks, kinks, nicks, stripped threads, and cuts.

- (1) Loosen air hose at solenoid valve port P.
- (2) Check for presence of air at port P.
- (3) If air is not present, go to step 6 of this fault.
- (4) Tighten air hose on solenoid valve.



- (1) Loosen air hose at solenoid valve port A.
- (2) Check for presence of air at port A.
- (3) If air is not present, replace solenoid valve (para 32-10).
- (4) Tighten air hose on solenoid valve.




4BEJ801B

j8. M1090/M1094 TAILGATE RELEASE DOES NOT OPERATE

KNOWN INFO
Air tanks pressurized. Pressure protection valve OK. Air hose to port P on manual override valve OK. Manual override valve OK. Air hose to port P on solenoid valve OK.
POSSIBLE PROBLEMS
Faulty solenoid valve. Faulty air hose to front port on tailgate pneumatic cylinder. Faulty air hose to rear port on tailgate pneumatic cylinder. Faulty tailgate pneumatic cylinder.

KNOWN INFO
Air tanks pressurized. Pressure protection valve OK. Air hose to port P on manual override valve OK. Manual override valve OK. Air hose to port P on solenoid valve OK. Solenoid valve OK.
POSSIBLE PROBLEMS
Faulty air hose to front port on tailgate pneumatic cylinder. Faulty air hose to rear port on tailgate pneumatic cylinder. Faulty tailgate pneumatic cylinder.




WARNING

Wear protective goggles to protect against possible injury from release of high pressure air. Failure to comply may result in injury to personnel.

NOTE


Inspect air hoses and fittings for cracks, kinks, nicks, stripped threads, and cuts.

- (1) Loosen air hose at solenoid valve port B.
- (2) Press and hold tailgate release switch (TM 9-2320-366-10-1).
- (3) Check for presence of air at solenoid valve Port B.
- (4) If air is not present, perform Electrical System Troubleshooting (e142. M1090/M1094 Tailgate Release Does Not Operate).
- (5) Release tailgate switch.
- (6) Tighten air hose on solenoid valve.





4BE J802B

- (1) Loosen air hose at tailgate pneumatic cylinder front port.
- (2) Check for presence of air at front port.
- (3) If air is not present, replace air hose from tailgate pneumatic cylinder front port to solenoid valve port A (para 23-4).
- (4) Tighten air hose on tailgate pneumatic cylinder.



4BE J803B

j8. M1090/M1094 TAILGATE RELEASE DOES NOT OPERATE




WARNING

Wear protective goggles to protect against possible injury from release of high pressure air. Failure to comply may result in injury to personnel.

NOTE


Inspect air hoses and fittings for cracks, kinks, nicks, stripped threads, and cuts.

- (1) Loosen air hose at tailgate pneumatic cylinder rear port.
- (2) Check for presence of air at rear port.
- (3) If air is not present, replace air hose from tailgate pneumatic cylinder rear port to solenoid valve port B (para 23-4).
- (4) If air is present, replace tailgate pneumatic cylinder (para 23-9).
- (5) Tighten air hose on tailgate pneumatic cylinder.




4BEJ804B

- (1) Loosen air hose at pressure protection valve.
- (2) Check for presence of air at pressure protection valve.
- (3) If air is not present, replace pressure protection valve (para 23-12).
- (4) Tighten air hose on pressure protection valve.



4BEJ805B

j8. M1090/M1094 TAILGATE RELEASE DOES NOT OPERATE




WARNING

Wear protective goggles to protect against possible injury from release of high pressure air. Failure to comply may result in injury to personnel.

NOTE

Inspect air hoses and fittings for cracks, kinks, nicks, stripped threads, and cuts.

- (1) Loosen air hose at manual override valve port P.
- (2) Check for presence of air at port P on manual override valve.
- (3) If air is not present, replace air hose from manual override valve port P to pressure protection valve (para 23-4).
- (4) Tighten air hose on manual override valve.



4BEJ806B

- (1) Loosen air hose at manual override valve port A.
- (2) Check for presence of air at port A.
- (3) If air is not present, replace manual override valve (para 23-8).
- (4) If air is present, replace air hose from manual override valve port A to solenoid valve port P (para 23-4).
- (5) Tighten air hose on manual override valve.


2-22. WHEEL TROUBLESHOOTING


This paragraph covers Wheel Troubleshooting. The Wheel Fault Index, Table 2-50, lists faults for the Wheel of the vehicle.

Table 2-50. Wheel Fault Index



Fault No.	Description	Page
k1.	Tires Wear Unevenly or Excessively	2-1990
k2.	Wheel Wobbles or Shimmies	2-1994

k1. TIRES WEAR UNEVENLY OR EXCESSIVELY	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Multiplier, Torque Wrench (Item 23, Appendix C) Wrench, Torque, 0-600 lb-ft (Item 60, Appendix C)







Inspect tires for excessive wear and for spacing between lug nuts and wheels. Tires that are worn unevenly may indicate that lug nuts need tightening.




42K0101A



Inspect tires for excessive wear. Tires that have flat spots may indicate a defective shock absorber. Inspect shock absorbers for leaks or damage.




SHOCK ABSORBER




42K0102A

k1. TIRES WEAR UNEVENLY OR EXCESSIVELY (CONT)



 Check front wheel toe-in (para 13-5).

k2. WHEEL WOBBLES OR SHIMMIES	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C) Trestle, Motor Vehicle Maintenance (2) (Item 47, Appendix C)






WHEEL RUNOUT CHECK


WARNING

Vehicle must be on level ground and wheels must be chocked. Failure to comply may result in injury to personnel.

- (1) Jack up vehicle (TM 9-2320-366-10-1) one wheel at a time.
- (2) Rotate tire to check for bent wheel.
- (3) Insert pry bar under tire and lift while observing wheel play.
- (4) Check drag link play.
- (5) Lower vehicle (TM 9-2320-366-10-1).



42K0201A



X2K0202-

2-23. HYDRAULIC SYSTEM TROUBLESHOOTING

This paragraph covers Hydraulic System Troubleshooting. The Hydraulic System Fault Index, Table 2-51, lists faults for the Hydraulic System of the vehicle.

Table 2-51. Hydraulic System Fault Index

Fault No.	Description	Page
11.	Loss of Hydraulic Pressure (Single Stage Pump)	2-1998
12.	Loss of Hydraulic Pressure (Three Stage Pump)	2-2002

11. LOSS OF HYDRAULIC PRESSURE (SINGLE STAGE PUMP)


INITIAL SETUP

Equipment Conditions



Engine shut down (TM 9-2320-366-10-1).

Tools and Special Tools

Tool Kit, Genl Mech (Item 46, Appendix C)




— | Check hydraulic tubes and fittings for kinks, bends, and debris.




— | Check filter screen for debris.

XBL0101-


11. LOSS OF HYDRAULIC PRESSURE (SINGLE STAGE PUMP) (CONT)







- (1) Remove hydraulic oil filter (para 19-13).
- (2) Check hydraulic oil filter for blockage.
- (3) Install hydraulic oil filter (para 19-13).

I2. LOSS OF HYDRAULIC PRESSURE (Three Stage Pump)	
INITIAL SETUP	
Equipment Conditions Engine shut down (TM 9-2320-366-10-1).	Tools and Special Tools Tool Kit, Genl Mech (Item 46, Appendix C)







Check hydraulic tubes and fittings for kinks, bends, and debris.




Check filter screen for debris.




HYDRAULIC TUBES

42L0201A

12. LOSS OF HYDRAULIC PRESSURE (THREE STAGE PUMP) (CONT)





- (1) Remove hydraulic oil filter (para 19-14).
- (2) Check hydraulic oil filter for blockage.
- (3) Install hydraulic oil filter (para 19-14).

APPENDIX A REFERENCES

A-1. SCOPE

This appendix lists all forms, field manuals, technical manuals, and other publications referenced in this manual. Those publications that should be consulted for additional information about vehicle operations are also listed.

A-2. PUBLICATIONS INDEX

The following index should be consulted frequently for latest changes or revisions and for new publications relating to material covered in this technical manual.

Consolidated Index of Army Publications and Blank Forms DA Pam 25-30

A-3. FORMS

The following forms pertain to this manual. See DA Pam 25-30 for index of blank forms. See DA Pam 738-750, The Army Maintenance Management System (TAMMS), for instructions on the use of maintenance forms pertaining to this material.

Recommended Changes to Publications and Blank Forms	DA Form 2028
Equipment Inspection and Maintenance Worksheet	DA Form 2404
Maintenance Request	DA Form 2407
Equipment Control Record	DA Form 2408-9
Processing and Deprocessing Record of Shipping, Storage, and Issue of Vehicles and Spare Engines	DD Form 1397
Packaging Improvement Report	DD Form 6
Report of Item Discrepancy (ROID)	SF 364
Product Quality Deficiency Report	SF 368

A-4. OTHER PUBLICATIONS

The following publications contain information pertinent to the MTV and associated equipment.

a. Safety.

First Aid	FM 4-25.11
Security of Tactical Wheeled Vehicles	TB 9-2300-422-20
Safety Inspection and Testing of Lifting Devices	TB 43-0142

A-4. OTHER PUBLICATIONS (CONT)

b. MTV.

Direct Support and General Support Maintenance Manual for M1083 Series, 5-Ton, 6x6, Medium Tactical Vehicle (MTV) TM 9-2320-366-34

Hand Receipt Covering Contents of Components of End Item (COEI), Basic Issue Items (BII), and Additional Authorization List (AAL), for M1083 Series, 5-Ton, 6x6, Medium Tactical Vehicles (MTV) TM 9-2320-366-10-HR

Operator's Manual for M1083 Series, 5-Ton, 6x6, Medium Tactical Vehicle (MTV) TM 9-2320-366-10

Unit, Direct Support, and General Support Repair Parts and Special Tools List for M1083 Series, 5-Ton, 6x6, Medium Tactical Vehicle (MTV) TM 9-2320-366-24P

Warranty Program for M1083 Series, 5-Ton, 6x6, Medium Tactical Vehicle (MTV) TB 9-2300-366-15

c. General Vehicle Operation.

Army Motor Transport Units and Operations FM 55-30

Deleted

Manual for the Wheeled Vehicle Driver FM 21-305

Petroleum Tank Vehicle Operations FM 10-71

Safety Prevention of Motor Vehicle Accidents AR 385-557

Vehicle Recovery Operations FM 20-22

d. General Maintenance and Repair.

Army Oil Analysis Program TB 43-0211

Camouflage Pattern Painting FM 5-20

Charging System Troubleshooting DA Pam 750-33

Color, Marking, and Camouflage Painting of Military Vehicles TB 43-0209

Cooling Systems: Tactical Vehicles TM 750-254

Corrosion Prevention and Control Including Rustproofing Procedures for Tactical Vehicles and Trailers TB 43-0213

Description, Use, Bonding Techniques, and Properties of Adhesives TB ORD 1032

Equipment Improvement Report and Maintenance Digest: TACOM Equipment TB 43-0001-39-1

Equipment Improvement Report and Maintenance Summary TM 43-0143

Installation Instructions for Installation Kit, Electronic Equipment, MK-2700/VRC (NSN 5895-01-421-0814) (EIC: N/A) to Permit Installation of Radio Set AN/VRC-87/88/90 Series into M1078, M1080, M1081, M1083-M1086, M1088-M1094 and M1096 Family of Medium Tactical Vehicles TB 11-5820-890-20-101

Installation Instructions for Installation Kit, Electronic Equipment, MK-2715/VRC (NSN 5895-01-421-0812) (EIC: N/A) to Permit Installation of Radio Set AN/VRC-89/91/92 Series into M1078, M1080, M1081, M1083-M1086, M1088-M1094 and M1096 Family of Medium Tactical Vehicles TB 11-5820-890-20-92

Materials Used for Cleaning, Preserving, Abrading, and Cementing Ordnance Materiel and Related Materials Including Chemicals TM 9-247

Metal Body Repair and Related Operations FM 43-2

Operator's and Organizational Maintenance Manual for Radio Sets TM 11-5820-498-12

Operator's and Organizational Maintenance Manual Including Repair Parts and Special Tools List Simplified Test Equipment for Internal Combustion Engines Reprogrammable (STE/ICE-R) (NSN 4910-01-222-6589) TM 9-4910-571-12&P

Operator's Manual, Radio Set, AN/VRC-46 TM 11-5820-401-10-1

Operator's Manual, Radio Set, AN/VRC-90A TM 11-5820-890-10-1

Operator's, Unit, Direct Support, and General Support Maintenance Manual for Lead-Acid Storage Batteries TM 9-6140-200-14

Ordnance Tracked and Wheeled Vehicle Hull and Chassis Wiring, Repair of TB ORD 650
 Organizational Care, Maintenance, and Repair of Pneumatic Tires and Inner Tubes TM 9-2610-200-14
 Painting Instructions for Field Use TM 43-0139
 Purging, Cleaning, and Coating Interior Ferrous and Terne Sheet Vehicle Fuel Tanks TB 43-0212
 Repair of Tents, Canvas, and Webbing FM 10-16
 Rigging Techniques, Procedures, and Applications FM 5-125
 Use and Care of Hand Tools and Measuring Tools TM 9-243
 Use of Antifreeze Solutions and Cleaning Compounds in Engine Cooling Systems TB 750-651
 Welding Theory and Application TM 9-237

e. Cold Weather Operation.

Basic Cold Weather Manual FM 31-70
 Northern Operations FM 31-71
 Operation and Maintenance of Ordnance Materiel in Cold Weather (0° to -65°F) FM 9-207

f. Decontamination.

Decontamination Operations Facilities & Equipment TB 700-4
 NBC Decontamination FM 3-5
 NBC Protection FM 3-4

g. Maintenance of Special Purpose Kits.

Operator and Organizational Maintenance Manual for Chemical Alarm TM 3-6665-225-12
 Operator's and Unit Maintenance Manual Including Repair Parts and Special Tools
 List for Decontaminating Apparatus: M13 TM 3-4230-214-12&P
 Operator, Organizational, Direct Support, and General Support Maintenance Manual
 Including Repair Parts and Special Tools List for Various Machine Gun Mounts TM 9-1005-245-14

h. General.

Operator's Manual (M998 Series) TM 9-2320-280-10
 Operator's Manual (M1008 Series) TM 9-2320-289-10
 Operator's Manual (M35 Series) TM 9-2320-361-10
 Operator's Manual (M939 Series) TM 9-2320-272-10
 Principles of Automotive Vehicles TM 9-8000
 Procedures for Destruction of Tank-Automotive Equipment to Prevent Enemy Use
 (US Army Tank-automotive and Armaments Command) TM 750-244-6
 Route Reconnaissance and Classification FM 5-36
 Soldier's Manual MOS 88M Motor Transport Operator, Skill Levels 1/2 STP 55-88-M12-SM

i. Land, Sea, and Air Shipment.

Airdrop of Supplies and Equipment: Rigging 5-Ton Trucks FM 10-526
 Containerization of Military Vehicles MTMCTEA Ref 95-55-23
 Lifting and Tiedown of U.S. Military Helicopters MTMCTEA Ref 95-55-21
 Marine Lifting and Lashing Handbook MTMCTEA Ref 95-55-22
 Marine Terminal Lifting Guidance MTMCTEA Pam 56-1

A-4. OTHER PUBLICATIONS (CONT)

i. Land, Sea, and Air Shipment (Cont).

Multiservice Helicopter External Air Transport: Basic Operations and Equipment FM 55-450-3
Multiservice Helicopter External Air Transport: Dual-Point Load Rigging Procedures FM 55-450-5
Multiservice Helicopter External Air Transport: Single-Point Load Rigging Procedures FM 55-450-4
Standard Characteristics (Dimensions, Weight, and Cube) for Transportability of Military
Vehicles and Other Outsize/Overweight Equipment (in TOE Line Sequence) TB 55-46-1
Tiedown Handbook for Rail Movements MTMCTEA Pam 55-19
Tiedown Handbook for Truck Movements MTMCTEA Ref 92-55-20

APPENDIX B MAINTENANCE ALLOCATION CHART (MAC)

SECTION I

INTRODUCTION

B-1. The Army Maintenance System MAC.

a. This introduction (Section I) provides a general explanation of all maintenance and repair functions authorized at various maintenance levels under the standard Army Maintenance System concept.

b. The Maintenance Allocation Chart (MAC) in Section II designates overall authority and responsibility for the performance of maintenance functions on the identified end item or component. The application of the maintenance functions to the end item or component will be consistent with the capacities and capabilities of the designated maintenance levels, which are shown on the MAC in column (4) as:

Unit/FIELD - includes two subcolumns, C (Operator/Crew) and O (Unit) maintenance.

Direct Support/FIELD - includes an F subcolumn.

General Support/SUSTAINMENT - includes an H subcolumn.

Depot/SUSTAINMENT - includes a D subcolumn.

c. Section III lists the tools and test equipment (both special tools and common tool sets) required for each maintenance function as referenced from Section II.

d. Section IV contains supplemental instructions and explanatory notes for a particular maintenance function.

B-2. Maintenance Functions. Maintenance functions are limited to and defined as follows:

a. **Inspect.** To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination (e.g. by sight, sound, or feel).

b. **Test.** To verify serviceability by measuring the mechanical, pneumatic, hydraulic, or electrical characteristics of an item and comparing those characteristics with prescribed standards.

c. **Service.** Operations required periodically to keep an item in proper operating condition; e.g. to clean (includes decontaminate, when required), to preserve, to drain, to paint, or to replenish fuel, lubricants, chemicals fluids, or gases.

d. **Adjust.** To maintain or regulate, within prescribed limits, by bringing into proper position, or by setting the operating characteristics to specified parameters.

e. **Align.** To adjust specified variable elements of an item to bring about optimum or desired performance.

f. **Calibrate.** To determine and cause corrections to be made or to be adjusted on instruments or Test, Measurement, and Diagnostic Equipment (TMDE) used in precision measurement. Consists of comparison of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.

g. **Remove/Install.** To remove and install the same item when required to perform service or other maintenance functions. Install may be the act of emplacing, seating, or fixing into position a spare, repair part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.

h. **Replace.** To remove an unserviceable item and install a serviceable counterpart in its place. "Replace " is authorized by the MAC and assigned maintenance level is shown as the 3d position code of the SMR code.

i **Repair.** The application of maintenance services¹ including fault location/troubleshooting², removal/installation, and disassembly/assembly³ procedures, and maintenance actions⁴ to identify troubles and restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.

j. **Overhaul.** That maintenance effort (service/action) prescribed to restore an item to a completely serviceable/operational condition as required by maintenance standards in appropriate technical publications (i.e., DMWR). Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like new condition.

k. **Rebuild.** Consists of those services/actions necessary for the restoration of unserviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of material maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (e.g., hours/miles) considered in classifying Army equipment/components.

B-3. Explanation of Columns in the MAC, Section II.

a **Column 1, Group Number.** Column 1 lists functional group code numbers, the purpose of which is to identify maintenance significant components, assemblies, subassemblies, and modules with the next higher assembly.

b. **Column 2, Component/Assembly.** Column 2 contains the item names of components , assemblies, subassemblies, and modules for which maintenance is authorized.

c. **Column 3, Maintenance Function.** Column 3 lists the functions to be performed on the items listed in Column 2. (For detailed explanation of these functions, see Paragraph B-2.)

d. **Column 4, Maintenance Level.** Column 4 specifies each level of maintenance authorized to perform each function listed in Column 3, by indicating work time required (expressed in man-hours in whole hours or decimals) in the appropriate subcolumn. This work-time figure represents the active time required to perform that maintenance function at the indicated level of maintenance. If the number or complexity of the tasks within the listed maintenance function vary at different maintenance levels, appropriate work-time figures are to be shown for each level. The work-time figure represents the average time required to restore an item (assembly, subassembly, component, module, end item, or system) to a serviceable condition under typical field operating conditions.

¹Services – Inspect, test, service, adjust, align calibrate, and/or replace.

²Fault location/troubleshooting - The process of investigating and detecting the cause of equipment malfunction; the act of isolating a fault within a system or Unit Under Test (UUT).

³Disassembly/assembly - The step-by-step breakdown (taking apart) of a spare/functional group coded item, to the level of its least component, that is assigned an SMR code for the level of maintenance under consideration (i.e., identified as maintenance significant).

⁴Actions - Welding, grinding, riveting, straightening, facing, machining, and/or resurfacing.

This time includes preparation time (including any necessary disassembly/assembly time), troubleshooting/fault location time, and quality assurance time in addition to the time required to perform the specific tasks identified for the maintenance functions authorized in the maintenance allocation chart. The symbol designations for the various maintenance levels are as follows:

- C Operator or crew maintenance
- O Unit/Field maintenance
- F Direct Support/Field maintenance
- L Specialized Repair Activity (SRA)⁵
- H General Support/Sustainment maintenance
- D Depot/Sustainment maintenance

e. **Column 5, Tools and Test Equipment Reference Code.** Column 5 specifies, by code, those common tools sets (not individual tools), common TMDE, and special tools, special TMDE, and special support equipment required to perform the designated functions. Codes are keyed to tools and test equipment in Section III.

f. **Column 6, Remarks.** When applicable, this column contains a letter code, in alphabetical order, which is keyed to the remarks contained in Section IV.

B-4. Explanation of Columns in Tool and Test Equipment Requirements, Section III.

a. **Column 1, Reference Code.** The tool and test equipment reference code correlates with a code used in the MAC, Section II column 5.

b. **Column 2, Maintenance Level.** The lowest level of maintenance authorized to use the tool or test equipment.

c. **Column 3, Nomenclature.** Name or identification of the tool or test equipment.

d. **Column 4, National Stock Number.** The National Stock Number of tool or test equipment.

e. **Column 5, Tool Number.** The manufacturer's part number, model number, or type number.

B-5. Explanation of Columns in Remarks, Section IV.

a. **Column 1, Remarks Code.** The code recorded in column 6, Section II.

b. **Column 2, Remarks.** This column lists information pertinent to the maintenance function being performed as indicated in the MAC, Section II.

⁵This maintenance level is not included in Section II, Column (4) of the Maintenance Allocation Chart. Functions to this level of maintenance are identified by a work-time figure in the "H" column of Section II, Column (4), and an associated reference code is used in the Remarks column (6). This code is keyed to Section IV, Remarks, and the SRA complete repair application is explained there.

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD			SUSTAINMENT			
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
0100	ENGINE ASSEMBLY	Inspect		0.1				80	
		Test		1.5	0.3			80,81	
		Adjust			3.0			58,62,80,82	
		Service		0.8				59,61,80	
		Replace			7.0			19,58,61,63,80,81	
		Repair		0.4	1.6	3.3		19,35,36,46,58,61,62,63,80,81	
0101	CYLINDER HEAD ASSEMBLY	Inspect			0.1			80	
		Replace			2.0			46,58,61,62,80	
		Repair				2.5		58,61,62,63,64,80,83	
0102	CRANKSHAFT	Replace				16.0		58,59,62,73,80	
		Repair			3.8	16.0		19,35,36,58,61,62,63,80	
0103	FLEXPLATE, ENGINE	Replace			6.5			58,61,80	
		Repair			1.0			58,61,80	
0104	PISTON ASSEMBLY	Replace				9.0		58,59,61,62,64,80,81	
		Repair				0.6		80	
0105	CAMSHAFT ASSEMBLY	Replace				3.1		17,58,59,61,62,80	
		Repair				1.2		58,80	
0105	ROCKER ARM AND PUSH RODS	Replace			2.0			46,61,62,63,80	
		Repair			0.3			59,80	
0106	COOLER, ENGINE OIL	Replace			1.3			58,80	
		Repair			0.3			58,80	
0108	MANIFOLDS, INLET AND EXHAUST	Replace			1.5			58,62,63,80,81	
0301	INJECTOR ASSEMBLY, FUEL	Replace			2.1			46,59,80,82	
		Adjust			1.6			58,80,81,82	
0304	AIR INTAKE SYSTEM	Service		0.3					
		Repair		0.3				48,59,	

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
0304	INTAKE AIR CLEANER	Service		0.2					
		Replace		0.8			6,48,59, 80		
		Repair		0.4			59,80		
0305	TURBOCHARGER	Replace			0.8		58,63,80,81		
0306	FUEL TANK	Inspect	0.1						
		Replace		1.5			59,61,80		
0308	GOVERNOR, ENGINE SPEED	Replace			1.0		59,62,78,80,81		
		Repair		0.5	0.7		59,80		
0309	FILTER, FUEL/WATER SEPARATOR	Inspect	0.2						
		Service	0.2	0.3			80		
		Replace		0.5			59,80		
0311	ETHER STARTING AID	Replace		0.6			59,61,80		
0312	ACCELERATOR/HAND THROTTLE	Replace		0.5			59,80		
		Adjust		0.2			59,80		
0401	EXHAUST MUFFLER/PIPES	Inspect	0.1	0.2					
		Replace		0.9			59,61,80		
0501	RADIATOR/CHARGE AIR COOLER	Inspect	0.1						
		Replace		2.5			2,31,55,61,80		
		Service		1.5			61,80		
		Repair		0.6	2.0		2,31,55,61,80		
0501	RADIATOR OVERFLOW TANK	Replace		0.5			48,59,80		
		Repair		0.3			80		
0502	SHROUD, FAN	Replace		1.0			59,61,80,90		
0503	HOSES, WATER	Replace		0.5			59,61,80,90		
0504	PUMP, WATER	Replace		0.8			18,59,61,80,90		
0505	CLUTCH, ENGINE FAN	Inspect		1.0			59		
		Replace		1.5			2,55,59, 80		
		Repair			1.2		58,61,62,63,80,81		

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD			SUSTAINMENT			
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
0601	ALTERNATOR, 100 AMP	Inspect		0.2					
		Test		0.5	1.5			61,65,80	
		Replace		1.0				61,80	
		Repair		0.2	0.5			40,58,59,61,65,80,81	
0603	STARTING MOTOR, ENGINE	Inspect		0.1					
		Test		0.5	0.5			59,65	
		Replace		1.5				2,8,59,61,80	
		Repair			2.1			54,58,61,62,78,80	
0606	SOLENOID, FUEL SHUTOFF	Replace			1.0			62,80,82	
0607	CABLE ASSEMBLY, DASHBOARD	Test		0.5				58	
		Replace		2.9				59,61,78,80	
		Repair		1.0	0.6			58,59,63,80	
0607	DISPLAY, LIGHTED INDICATOR	Test		0.3					
		Replace		0.5				80,90	
		Repair		0.3				80	
0608	JUNCTION BOX ASSEMBLY, M1084/M1086	Inspect	0.1						
		Replace		1.5				59,61,80,90	
		Repair		1.5				59,61,65,80	
0608	JUNCTION BOX ASSEMBLY, M1089	Inspect	0.1						
		Replace		1.5				59,61,80,90	
		Repair		1.5				59,61,65,80	
0609	LIGHT ASSEMBLY, BACKUP	Inspect	0.1						
		Replace		0.8				59,80	
		Repair		0.3				80	
0609	LIGHT, BLACKOUT DRIVE	Inspect	0.1						
		Replace		0.8				59,61,80	
		Repair		0.5				80	
		Replace		0.8				59,61,80	

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
0609	TAILLIGHT ASSEMBLY, COMPOSITE	Inspect	0.1						
		Repair		0.5			80		
0609	LIGHT ASSEMBLY, FRONT TURN SIGNAL AND PARK	Inspect	0.1						
		Replace		0.8			59,61,80		
		Repair		0.5			80		
0609	HEADLIGHT	Inspect	0.1						
		Adjust		0.4					
		Replace		1.0			59,61,80		
0609	WORKLIGHT ASSEMBLY, M1088/M1089 STATIONARY	Inspect	0.1						
		Replace		0.8			80		
		Repair		0.3			80		
0610	AUDIBLE ALARM	Inspect	0.1						
		Replace		0.6			80		
0611	HORN, CAB	Inspect	0.1						
		Replace		0.4			59,80		
0612	BOX ASSEMBLY, BATTERY	Inspect	0.1						
		Test		0.5			59,80		
		Service		0.3			59	A	
		Replace		1.0			59,61,80		
		Repair		0.2			65		
0613	CABLE ASSEMBLY, LH/RH CAB AND DOOR MARKER LIGHTS	Inspect	0.1						
		Replace		0.8			80		
		Repair		0.7			65		
0613	CABLE ASSEMBLY, LOWER, CAB MARKER LIGHTS, M1093/M1094	Inspect	0.1						
		Replace		0.6			80,90		
		Repair		0.5			65		
0613	CABLE ASSEMBLY, UPPER, CAB CLEARANCE AND MARKER LIGHTS, M1093/M1094	Inspect	0.1						
		Replace		0.8			80,90		
		Repair		0.5			65		

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
0613	CABLE ASSEMBLY, STE/ICE-R	Replace		1.0				80	
		Repair		0.5	0.8			65	
0613	CABLE ASSEMBLY, CAB CLEARANCE AND MARKER LIGHTS	Inspect	0.1						
		Replace		1.2				59,80	
		Repair		0.5	0.8			65	
0613	CABLE ASSEMBLY, WARNING LIGHT	Replace		0.5				50,80,90	
		Repair		0.3	0.5			65	
0613	CABLE ASSEMBLY, WINDSHIELD WASHER PUMP/EMI	Replace		0.5				80	
		Repair		0.3				65	
		Repair		0.5	0.5			65	
0613	CABLE ASSEMBLY, CRANE POWER	Inspect	0.1						
		Replace		1.2				80	
		Repair		0.5	0.5			65	
0613	BOX ASSEMBLY, CRANE REMOTE CONTROL	Test		0.5					
		Repair		0.7				80,90	
0613	CABLE ASSEMBLY, ENGINE CONTROL	Inspect	0.1						
		Replace		2.3				59,80	
		Repair		0.5	0.5			65	
0613	CABLE ASSEMBLY, FRONT INTERVEHICULAR, 12 VDC	Replace		0.8				61,80	
		Replace		2.0				59,61,80,90	
0613	CABLE ASSEMBLY, FRONT LIGHTS	Repair		0.5	0.5			65	
		Replace		2.8				59,61,80	
0613	CABLE ASSEMBLY, REAR LIGHTS	Repair		0.5	0.5			65	
		Replace		2.0				59,80	
0613	CABLE, M1084/M1086 BOOM DOWN LOCKOUT SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613									

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD			SUSTAINMENT			
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
0613	BOOM DOWN SOLENOID	Repair		0.5	0.8			65	
	CABLE, M1084/M1086 BOOM UP LOCKOUT SOLENOID	Replace		2.0				59,80	
0613	CABLE, M1084/M1086 BOOM UP SOLENOID	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1084/M1086 CONTROL LOCKOUT SOLENOID	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1084/M1086 CRANE POWER	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1084/M1086 HOIST DOWN SOLENOID	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1084/M1086 HOIST UP LOCKOUT SOLENOID	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1084/M1086 HOIST UP SOLENOID	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1084/M1086 LEFT JACK CYLINDER PROXIMITY SENSOR	Repair		0.5	0.8			65	
		Replace		1.0				59,80	
0613	CABLE, M1084/M1086 OVERLOAD LOCKOUT	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1084/M1086 REMOTE CONTROL	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1084/M1086 SWING CCW SOLENOID	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1084/M1086 SWING CW SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613	CABLE, M1084/M1086 SYSTEM SHUTDOWN SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD			SUSTAINMENT			
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
0613	CABLE, M1084/M1086 TELESCOPE IN SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613	CABLE, M1084/M1086 TELESCOPE OUT LOCKOUT SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613	CABLE, M1084/M1086 TELESCOPE OUT SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613	CABLE, M1089 BOOM DOWN LOCKOUT SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613	CABLE, M1089 BOOM DOWN SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613	CABLE, M1089 BOOM UP LOCKOUT SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613	CABLE, M1089 BOOM UP SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613	CABLE ASSEMBLY, M1089 CONTROL PANEL POWER	Replace		2.0				80	
		Repair		0.5	0.8			65	
0613	CABLE, M1089 CRANE POWER	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613	CABLE, M1089 HOIST DOWN SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613	CABLE, M1089 HOIST UP LOCKOUT SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613	CABLE, M1089 HOIST UP SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613	CABLE, M1089 HYDRAULIC SYSTEM SOLENOID	Replace		2.0				59,80	
		Repair		0.5	0.8			65	
0613	CABLE, M1089 LEFT SIDE REMOTE CONTROL	Replace		2.0				59,80	

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD			SUSTAINMENT			
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
0613	CABLE, M1089 OVERLOAD LOCKOUT	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	WIRING HARNESS, M1089 REMOTE CONTROL	Repair		0.5	0.8			65	
		Replace		2.0				80	
0613	CABLE, M1089 RIGHT SIDE REMOTE CONTROL	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1089 SWING CCW SOLENOID	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1089 SWING CW SOLENOID	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1089 TELESCOPE IN SOLENOID	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1089 TELESCOPE OUT LOCKOUT SOLENOID	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	CABLE, M1089 TELESCOPE OUT SOLENOID	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
0613	BOX ASSEMBLY, WRECKER REMOTE CONTROL	Repair		0.5	0.8			65	
0613	CABLE ASSEMBLY, M1090/M1094 DUMP	Replace		0.8				59,61,80	
0613	CABLE ASSEMBLY, M1090/M1094 DUMP POWER	Repair		0.5	0.8			65	
		Replace		1.2				59,61,80	
0613	CABLE ASSEMBLY, PTO	Repair		0.5	0.8			65	
		Replace		1.6				59,61,80	
0613	CABLE ASSEMBLY, REAR INTERVEHICULAR, 24 VDC	Repair		0.5	0.8			65	
		Replace		0.6				61,80	
0613	CABLE ASSEMBLY, START AND CHARGING	Repair		0.5	0.8			65	
		Replace		2.0				59,80	
		Repair		0.5	0.8			65	

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
0613	CABLE ASSEMBLY, WINCH CONTROL VALVE	Replace		1.8				59,61,80	
		Repair		0.5	0.8			65	
0613	CABLE ASSEMBLY, TRANSMISSION AUXILIARY OIL COOLER FAN	Replace		1.8				59,61,80	
		Repair		0.5				65	
0705	VEHICLE INTERFACE MODULE	Replace		0.6				80	
		Repair		0.8				80	
0708	TORQUE CONVERTER	Adjust			0.9			22,61,62,80	
		Remove/			0.8			48,61,62,64,80	
		Install							
		Repair			1.3			34,58,61,62,64,80	
0710	TRANSMISSION	Inspect		0.4				80	
		Service		1.5				59,61,80	
		Replace			7.0			58,61,62,63,80,81,87	
		Repair		0.4	2.7	1.9		3,22,23,28,29,31,43,58,59,61,62,63,80,81,87	
0710	MODULE, FRONT SUPPORT	Remove/					2.0	58,59,61,62,63,80	
		Install							
		Repair					0.7		
0710	MODULE, PLANETARY GEAR (P1)	Remove/					2.0	61,62,73,80	
		Install							
		Repair					1.5	61,62,73,80	
0710	MODULE, PLANETARY (P2)	Remove/					2.0	3,58,61,62,63,80	
		Install							
		Repair					1.9	3,23,58,61,62,63,73,80	
0710	PLANETARY CARRIER (P3)	Remove/					2.0	3,58,62,80	
		Install							
		Repair					1.9	3,31,58,62,80	
0710	MODULE, MAIN SHAFT	Remove/					2.0	61,62,80	
		Install							
		Repair					0.4	61,62,80	

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
0710	MODULE, CONVERTER HOUSING	Remove/ Install					4.3	3,58,59,61,62,80	
		Repair					2.0	3,23,29,58,59,61,62,80	
0713	CLUTCH ASSEMBLY, C3/C4/C5, TRANSMISSION	Remove/ Install					2.0	58,59,61,62,80	
		Repair					1.0	43,58,59,61,62,80	
0713	MODULE, ROTATING CLUTCH	Remove/ Install					2.0	3,58,61,62,80	
		Repair					2.4	3,23,28,58,61,62,80	
0714	VALVE ASSEMBLY, CONTROL MODULE	Remove/ Install					2.0	58,61,62,63,80,81	
		Repair		1.0			2.5	61,63,80,81	
0714	BODY ASSEMBLY, MAIN VALVE	Service		1.5				59,61,80	
		Remove/ Install					2.0	58,61,62,63,80,81	
		Repair		1.5			2.5	58,61,62,63,80,81	
0801	MODULE, TRANSFER CASE	Adjust					1.0		
		Remove/ Install					2.0	25,58,59,61,62,63,73,76,80,81	
		Repair					1.1	27,31,37,52,58,59,62,80	
0802	HOUSING ASSEMBLY, C6 AND C7 CLUTCH	Remove/ Install					2.0	58,61,62,63,80	
		Repair					0.8	23,27,30,31,32,33,58,61,62,63,64,73,80	
0802	CONTROL VALVE ASSEMBLY	Remove/ Install					2.0	58,61,63,80,81	
		Repair					1.0	58,61,63,80,81	
0804	PUMP ASSEMBLY, OIL	Replace					1.0	81	
		Repair					0.8	81	
0900	PROPELLER SHAFT	Inspect		0.1					

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD			SUSTAINMENT			
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
1000	AXLE ASSEMBLY, FRONT	Service		0.5				61	
		Repair		0.6				59,61,80	
		Replace		0.5				59,61,80	
		Inspect	0.1	0.3	0.7			80	
		Adjust			1.0			59,81	
		Service		0.5				61,80	
		Replace			4.5			58,59,61,62,63,72,80	
1002	CARRIER ASSEMBLY DIFFERENTIAL	Repair		2.3	2.2	6.0		58,59,61,62,63,80	
		Inspect		0.1	0.1	0.1		80,81	
		Service			0.3			80	
1004	STEERING KNUCKLE, AXLE	Replace				4.6		25,58,59,61,62,80,81	
		Repair					2.7	58,59,61,62,80,81	
		Inspect			0.2				
		Adjust			2.5			81	
		Service			0.3			81	
1100	AXLE ASSEMBLY, INTERMEDIATE	Replace			5.1			58,59,61,62,73,80	
		Inspect	0.1	0.4	0.7				
		Service		0.8				59,61,80	
		Replace			4.5			58,59,61,62,63,80,87	
1100	AXLE ASSEMBLY, REAR	Repair			1.6	6.0		25,58,59,61,62,69,80	
		Inspect	0.1	0.4	0.7				
		Service		0.8				59,61,80	
		Replace			4.5			38,58,59,61,62,80,87	
		Repair			0.9	6.0		25,58,59,61,62,80,87,88	

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
1102	CARRIER ASSEMBLY DIFFERENTIAL INTERMEDIATE AXLE	Inspect		0.1	0.1	0.1		80,81	
		Service Replace			0.3	4.6		80 25,58,59, 61,62,69, 80	
		Repair				2.7		25,58,59, 61,62,63, 69,75,80 80,81	
1102	CARRIER ASSEMBLY DIFFERENTIAL, REAR AXLE	Inspect		0.1	0.1	0.1		80,81	
		Service Replace			0.3	4.6		80 25,58,59, 61,62,80, 81,88	
		Repair				2.7		25,39,58, 59,61,62, 73,75,80 61,80,81	
1202	BRAKE ASSEMBLY, FRONT AXLE	Inspect		0.1	1.0			61,80,81	
		Adjust Repair		0.4 1.5	0.5			59,61,80 59,61,80,8 5	
1202	BRAKE ASSEMBLY, INTERMEDIATE AND REAR AXLE	Inspect		0.1	1.0			61,80,81	
		Adjust Repair		0.4 1.5	0.5			59,61,80 59,61,80,8 5	
1208	AIR DRYER, BRAKE SYSTEM	Replace		0.5				59,61,80	
1209	AIR COMPRESSOR	Repair		1.0				59,61,80	
		Adjust Replace			0.6	1.2		61,80 58,62,63,8 0,81	
1311	WHEEL ASSEMBLY, PNEUMATIC TIRE	Inspect	0.1					59	B
		Replace		1.0	1.2			59,61	
1313	TIRE, PNEUMATIC	Repair		2.0				59,61	
1401	STEERING SYSTEM	Replace		2.0				59,61	
		Inspect Adjust			0.2	1.0		58,62,80	

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
		Repair		1.0	1.5			56,58,59,61,62,63,80,81	
1407	STEERING GEAR ASSEMBLY	Replace			4.0			58,62,80	
1410	PUMP, POWER STEERING	Replace			1.5			49,58,61,62,80	
1411	HOSES, POWER STEERING	Replace		0.3				59,61,80,90	
1413	HYDRAULIC RESERVOIR, POWER STEERING	Service	0.1	0.5				80	
1501	FRAME ASSEMBLY	Replace		0.8				61,80,90	
		Inspect	0.1	0.3					
		Repair		0.8	14.0			58,59,61,62,63,80,81	
1501	BOOM REST ASSEMBLY, CRANE	Inspect	0.1						
		Replace			2.0			58,59,61,62,80,81,87	
		Repair			0.7			58,59,61,62,80,81,87	
1504	RETAINER, SPARE TIRE	Inspect	0.1	0.1					
		Replace		3.0				59,61,80	
		Repair		0.6				59,61,80	
1506	FIFTH WHEEL ASSEMBLY	Inspect	0.1						
		Service		0.5				21,80	
		Replace			4.0			58,61,62,80,81	
1601	LEAF SPRING ASSEMBLIES	Repair			2.5			21,58,61,62,66,80,81	
		Inspect	0.1	0.2					
		Service		0.3				59	
1604	SHOCK ABSORBERS	Replace			2.7			58,59,61,62,80,81	
		Inspect	0.1	0.3					
		Replace		0.5				59,61,80	
1605	STABILIZER BAR, REAR	Inspect		0.2					
		Replace		2.0				59,61,70,80	
1801	CAB BODY, STANDARD	Repair		1.5				59,80	
		Inspect	0.1						

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
1801	CAB BODY, AIR DROP	Replace			60.0			58,59,62,63,80,81	
		Repair		0.6				59,61,80	
		Inspect	0.1						
		Replace			60.0			58,59,62,63,80,81	
1801	CAB DOORS, STANDARD	Repair		0.6				59,61,80	
		Inspect	0.1						
		Replace			1.0			57,61,80	
1801	CAB DOORS, AIR DROP	Repair		2.7				51,59,80	
		Inspect	0.1						
		Replace			1.0			57,61,80	
1801	SUPPORT ASSEMBLY, CAB FRONT	Repair		2.7				51,59,80	
		Inspect	0.1						
		Replace			1.1			59,61,80	
1801	SUPPORT ASSEMBLY, CAB REAR	Repair			3.0			7,15,59,61,62,80,81	
		Inspect	0.1						
		Replace		1.0				59,61,80	
1802	WINDSHIELD	Repair		0.8				59,80	
		Replace			0.6			57,61,80	
1802	FENDER, VEHICULAR, FRONT	Inspect	0.1						
1803	ROOF, CAB, M1093/M1094	Replace		2.0				59,61,80	
		Repair		0.5				59,80	
		Replace		1.0				47,52,59,61,80	
1805	STEP ASSEMBLY, CAB	Replace		1.0				59,80	
		Repair		0.7				59,80	
1808	TOOL BOX ASSEMBLY	Inspect	0.1						
		Replace		0.5				49,59,61,80	
		Repair		0.5				59,61,80	
1808	STOWAGE BOX, CAB	Replace		0.8				59,80	
		Repair		0.5				59,80	
1810	BODY, CARGO, (W/MHC, LWB AND LWB W/MHC)	inspect	0.1						
		Replace			4.0			58,59,61,62,80	

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
1810	DUMP BODY ASSEMBLY	Repair		0.5				80	
		Inspect	0.1					59,61,80	
		Repair		0.5	4.0			58,59,61,62,80	
1810	DUMP HYDRAULIC CYLINDER	Inspect	0.1						
		Replace			1.0			59,62,80	
		Repair				2.5		59,61,62,80,89	
1810	DUMP TAILGATE ASSEMBLY	Inspect	0.1						
		Replace		1.5				80	
		Repair		0.8				80	
1812	BOX ASSEMBLY, TOOL, M1089	Inspect	0.1						
		Remove/Install		1.0				59,61,80	
		Repair		0.8				59,61,80	
2001	UNDERLIFT ASSEMBLY, M1089	Inspect	0.1						
		Test		0.5	0.1				
		Service		0.5				61	
		Replace			6.0			58,59,61,62,80,87	
		Repair			1.0			54,58,59,61,62,80,81,86,87	
2001	CROSSBAR ASSEMBLY, M1089	Inspect			0.1				
		Replace			0.5			58,59,61,62,80,81,86	
		Repair			1.0			58,59,61,62,81,86	
2001	LOWER ARM, UNDERLIFT	Inspect			0.1				
		Replace			2.0			58,59,61,62,80,87	
		Repair			0.5			58,59,61,62,80,87	
2001	CYLINDER, TELESCOPIC LIFT	Replace			1.5			59,61,80	
		Repair				1.0		61,62,63,80	
2001	STIFFLEG ASSEMBLY	Inspect			0.1				

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
2001	BOOM FRAME, FOLDING, UNDERLIFT	Replace			2.0			59,61,62,80,87	
		Inspect			0.1				
2001	ARM ASSEMBLY, UPPER, UNDERLIFT	Repair			2.5			61,80	
		Repair			2.5			58,59,61,62,80	
2001	CYLINDER, UNDERLIFT FOLD	Replace			0.5			59,61,80,87	
		Repair					0.5	59,61,62,63,80	
2001	CYLINDER, UNDERLIFT STINGER	Replace			0.5			59,61,62,80,87	
		Repair					0.5	58,61,62,63,68,80,81	
2001	WINCH, 15K SELF-RECOVERY	Inspect	0.1	4.0					
		Service		0.2				61	
		Replace			1.0			61,62,80	
		Repair			0.9			61,62,80	
2001	MOTOR, HYDRAULIC, SELF-RECOVERY WINCH	Replace			0.5			59,80	
2001	MATERIAL HANDLING CRANE (MHC), M1089	Inspect	0.1	0.5				80	
		Test	0.2		0.3			59	
		Service		0.5				61	
		Replace			6.0			59,61,62,80,87	
		Repair			0.5			9,58,59,61,62,80	
2001	CYLINDER, LIFT, M1089 MHC	Inspect	0.1						
		Test			0.2			61	
		Replace			4.0			58,62,80	
		Repair					2.0	59,61,62,63,80	
2001	CYLINDER, ERECTION, M1089 MHC	Inspect	0.1						
		Test			0.2			61	
		Replace			4.0			58,62,80	
		Repair					2.0	59,61,62,63,80,81	
2001	HOIST ASSEMBLY, M1089 MHC	Inspect	0.1						

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
2001	HYDRAULIC MOTOR, HOIST, M1089 MHC	Test			0.2			61	
		Replace			6.0			61,62,80	
		Repair			3.0			59,61,62,80	
		Inspect	0.1						
2001	GEAR SET, M1089 MHC	Test			0.1			59,65	
		Replace			2.0			59,80	
		Repair				4.2		58,59,61,62,63,80	
		Inspect		0.2					
2001	BOOM ASSEMBLY, M1089 MHC	Test			0.2			61	
		Repair			1.7			61,62,80	
		Inspect	0.1						
2001	CYLINDER, TELESCOPIC, BOOM, M1089 MHC	Test			0.2				
		Replace			8.0			58,62,80	
		Repair			2.0			58,61,62,80	
		Inspect	0.1						
2001	SWING DRIVE ASSEMBLY, M1089 MHC	Test			0.2			61	
		Replace			6.0			58,61,62,80	
		Repair				2.0		59,61,62,80	
		Inspect	0.1	0.5					
2001	MOTOR, ORBIT, HYDRAULIC, M1089 MHC	Test			0.2			61	
		Service		0.3					
		Replace			4.0			59,61,62,80	
		Repair			4.0			59,61,62,80	
		Inspect	0.1						
2001		Test			0.2				
		Replace			1.0			59,61,62,80	
		Repair				3.0		59,61,62,63,80,81	

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
2001	CYLINDER ASSEMBLY, EXTENSION, OUTRIGGER, M1089 MHC	Inspect	0.1						
		Test			0.2			61	
		Replace			3.0			80	
2001	CYLINDER ASSEMBLY, JACK, M1089 MHC	Repair				5.0		61,62,80	
		Inspect	0.1						
		Test			0.2			61	
2001	VALVE ASSEMBLY, EIGHT-BANK, M1089 MHC	Replace			0.5			58,59,61,80	
		Repair			2.0			58,59,61,80	
		Inspect	0.1				5.0		59,61,62,80
2001	WINCH ASSEMBLY, M1089 (30K)	Inspect	0.1						
		Test		0.5	0.2			63	
		Replace			9.0			20,59,61,62,80,81	
2001	MOTOR ASSEMBLY, DRIVE, (30K) WINCH	Repair			0.5			59,61,62,63,73,80,81	
		Replace			8.0			59,61,62,63,73,80,81	
		Repair			0.5			61,62,80	
2001	VALVE ASSEMBLY, MAIN, UPPER, M1089	Replace			0.5			61,62,80	
		Repair			0.5			61,62,80	
		Replace			0.5			61,62,80	
2001	VALVE ASSEMBLY, MAIN, LOWER, M1089	Repair			0.5			61,62,80	
		Replace			1.5			59,61,62,80,87	
		Repair			1.0			59,61,62,80,87	
2001	MATERIAL HANDLING CRANE (MHC), M1084/M1086	Inspect	0.1						
		Test			0.2			81	

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD			SUSTAINMENT			
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
2001	CYLINDER, LIFT, M1084/M1086 MHC	Service		2.0				61	
		Replace			4.0			58,59,61,62,80	
		Repair					0.5	58,59,61,62,63,73,80,81	
		Inspect	0.1						
		Test			2.0			65,81	
2001	CYLINDER, ERECTION, M1084/M1086 MHC	Replace			2.0			58,59,62,80	
		Repair					4.0	58,59,62,80	
		Inspect	0.1						
		Test			0.2			65,81	
2001	HOIST ASSEMBLY, M1084/M1086 MHC	Replace			4.0			58,62,80	
		Repair					4.0	59,61,63,80,81	
		Inspect	0.1						
2001	MOTOR, HYDRAULIC, HOIST, M1084/M1086 MHC	Test			0.2			65,81	
		Replace			6.0			61,62,80	
		Repair					3.5	59,61,62,80	
2001	MOTOR, HYDRAULIC, HOIST, M1084/M1086 MHC	Inspect	0.1						
		Test			0.1			65,81	
		Replace			2.0			59,80	
2001	GEAR SET, M1084/M1086 MHC	Repair					4.2	58,59,61,62,63,80	
		Inspect		0.2					
		Test			0.2				
2001	CYLINDER, TELESCOPIC, BOOM, M1084/M1086 MHC	Repair			4.5			61,62,80	
		Inspect	0.1						
		Test			0.1			65,81	
		Replace			2.0			58,61,62,80	
2001	CYLINDER, TELESCOPIC, BOOM, M1084/M1086 MHC	Repair					4.0	59,61,62,80	

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD			SUSTAINMENT			
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
2001	SWING DRIVE ASSEMBLY, M1084/M1086 MHC	Inspect	0.1	0.5				61	
		Test			0.1			65,81	
		Service		0.3					
		Replace			4.0			59,61,62,80	
		Repair			3.5	4.2		59,61,62,80	
2001	MOTOR, ORBIT, HYDRAULIC, M1084/M1086 MHC	Inspect	0.1					61	
		Test			0.1			65,81	
		Replace			2.0			59,61,80	
		Repair				4.2		59,61,63,73,80,81	
2001	VALVE ASSEMBLY, CONTROL, FOUR WAY, M1084/M1086 MHC	Replace			0.8			59,61,62,80	
		Repair			1.1			59,61,62,80	
2001	VALVE ASSEMBLY, CONTROL, THREE WAY, M1084/M1086 MHC	Replace			0.8			59,61,62,80,81	
		Repair			1.1			59,61,62,80,81	
2001	CYLINDER, JACK, M1084/M1086 MHC	Inspect	0.1						
		Test			0.2			81	
		Replace			2.0			62,80	
2004	POWER TAKEOFF ASSEMBLY (PTO)	Repair					4.0	59,61,62,80	
		Inspect	0.1						
		Replace			1.0			58,59,61,62,80	
2201	CAB PROTECTOR, M1090/M1094	Repair			0.8			58,59,61,62,80	
		Inspect	0.1						
2202	MOTOR, WIPER, WINDSHIELD	Replace			2.0			58,80	
		Test		0.5					
2207	HEATER ASSEMBLY, PERSONNEL	Replace		1.0				80	
		Replace		2.0				59,61,80	

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
2210	DECALS	Inspect	0.1						
		Replace		1.0			80		
2401	POWER UNIT, AIR/HYDRAULIC	Inspect	0.1						
		Test		0.2					
		Service		1.0					
		Replace		3.0			59,61,80		
		Repair			2.0		59,61,62,71,80,81		
2402	MANIFOLD, HYDRAULIC	Inspect	0.1						
		Test		0.2					
		Replace		1.5			53,59,61,80		
		Repair		1.0			53,59,61,80		
2406	FILTER, HYDRAULIC	Service		0.3			61,80		
		Replace		0.2			61,80		
2407	LATCH, HYDRAULIC, CAB	Inspect	0.1						
		Adjust		0.5			59,61,80		
		Replace		0.5			59,61,80		
2408	RESERVOIR, HYDRAULIC	Replace		1.0			59,61,80		
		Repair		0.5			59,61,80		
2408	TANK ASSEMBLY, HYDRAULIC, M1089	Inspect	0.1						
		Service		2.0			59,61,80		
		Replace		2.0			6,9,59,61,80		
		Repair		0.5			59,61,80		
3307	ALTERNATOR KIT, 200 AMP	Inspect	0.1	0.2					
		Test		0.5					
		Remove/Install		2.0			59,61,80		
		Replace		1.0			59,61,80		
		Repair			0.5		58,59,62,63,80		
3307	ALTERNATOR, 200 AMP	Inspect		0.2					
		Test		0.5	1.5		61,65,80		
		Replace		1.0			59,61,80		
		Repair		0.2	0.5		58,59,62,63,65,80		
3307	CRANE (LMHC), MATERIAL HANDLING, LIGHT	Inspect	0.1	0.1					
		Replace		0.5			61,78,80		

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
3307	WEIGHT BLOCK AND WIRE ROPE, LMHC	Repair		0.5					
		Test		0.5					
		Inspect	0.1						
3307	WINCH, LMHC	Replace		0.1			61,80		
		Repair		0.5			61,80		
		Test			0.5				
3307	MAST/SWING ASSEMBLY, LMHC	Inspect	0.1						
		Replace		0.5			61,80		
		Repair		1.0			61,80		
3307	CONTROL BOX, LMHC	Test		0.5					
		Inspect	0.1						
		Replace		0.1					
3307	TROOPSEAT KIT	Repair		0.5			78,80		
		Test	0.1	0.5					
		Remove/Install	1.0						
3307	COVER KIT, CARGO SOFT TOP	Inspect	0.1						
		Replace		1.0					
		Repair		0.5			80		
3307	WARNING LIGHT ASSEMBLY, AMBER	Remove/Install	1.5						
		Inspect	0.1						
		Replace		2.0					
3401	MACHINE GUN RING KIT	Repair		0.5					
		Test		0.2					
		Inspect	0.1						
3402	MOUNT, SMALL ARMS	Remove/Install			4.0		58,59,62, 80,81,87		
		Repair		1.1			10,59,80		
		Inspect	0.1						
3901	WARNING LIGHT ASSEMBLY, AMBER, M1089	Replace		0.3			80		
		Repair		0.8			59,61,80		

Section II. MAINTENANCE ALLOCATION CHART FOR THE MTV VEHICLE

(1) Group Number	(2) Component/Assembly	(3) Maintenance Function	(4) Maintenance Level					(5) Tools and Equipment Ref Code	(6) Remarks Code
			FIELD		SUSTAINMENT				
			Unit		Direct Support	General Support	Depot		
			C	O	F	H	D		
3903	MAST, WARNING LIGHT, AMBER, M1089	Replace		0.6				59,61,80	
3909	CABLE ASSEMBLY, WARNING LIGHT	Inspect	0.1						
4316	AIR HOSE, CTIS	Replace		0.5				80	
		Inspect	0.1						
4317	VALVE, INVERSION	Replace		0.4				61,80	
		Replace		0.5				61,80	
4318	CYLINDER, PNEUMATIC, TAILGATE, M1090/M1094	Replace		0.4				61,80	
4321	AIR DRYER	Inspect	0.1	0.1					
		Replace		1.0				59,61,80	
		Repair		0.6				59,61,80	
4702	GAUGE, AIR FILTER RESTRICTION	Replace		0.5				80	

Section III. TOOLS AND TEST EQUIPMENT FOR MTV VEHICLES

Tool or Test Equipment REF Code	Maintenance Level	Nomenclature	National Stock Number	Tool Number
1	O,F	ADAPTER, RADIATOR	4910-01-170-4928	J29003-A
2	O	ADAPTER, SOCKET WRENCH	5120-00-240-8702	11655788-2
2.1	O	BASE, MAGNETIC		P5646
3	H	BUSHING DRIVER SET	5120-01-391-3541	J35922
4	O	CRIMPING TOOL, TERMINAL, HAND	5120-00-165-3912	M22520/1-01
5	O	CROWFOOT ATTACHMENT, SOCKET WRENCH	5120-00-078-3809	10935497
6	O	CROWFOOT ATTACHMENT, SOCKET WRENCH	5120-00-293-1010	5120-293-1282
7	F	CROWFOOT ATTACHMENT, SOCKET WRENCH	5120-01-074-7557	FCOM19
8	O	CROWFOOT ATTACHMENT, SOCKET WRENCH	5120-01-236-9996	FCOM15
9	O	CROWFOOT ATTACHMENT, SOCKET WRENCH	5120-01-335-1089	FCO28
10	O	CROWFOOT ATTACHMENT, SOCKET WRENCH	5120-01-335-1091	FCO32
11	O	CROWFOOT ATTACHMENT, SOCKET WRENCH	5120-01-335-1119	SCO34
12	O	CROWFOOT ATTACHMENT, SOCKET WRENCH	5120-01-335-1122	SCO40

Section III. TOOLS AND TEST EQUIPMENT FOR MTV VEHICLES

Tool or Test Equipment REF Code	Maintenance Level	Nomenclature	National Stock Number	Tool Number
12.1	O	CROWFOOT ATTACHMENT, SOCKET WRENCH	5120-01-335-1126	SCO48
13	O	CROWFOOT ATTACHMENT, SOCKET WRENCH	5120-01-335-1153	FCO20
14	O	CROWFOOT ATTACHMENT, SOCKET WRENCH	5120-01-335-1156	FCO26
15	F	CROWFOOT ATTACHMENT, SOCKET WRENCH	5120-01-348-9473	AN8508-19A
16	O	CUTTER, BOLT	5110-00-224-7057	GGG-C-740
16.1	O	DISPENSER, SEALANT	5120-00-061-1283	45RCT
16.2	F	DRILL SET, STOPCOLLAR	5133-01-383-7665	1955
17	H	DRIVER KIT, BEARING	4910-01-032-3128	8S0602
18		DELETED		
19	O,F	GAGE, BELT TENSION	6635-01-143-2237	GA-424
20	O,F	GAGE, PRESSURE, 0-150 psi	6685-00-474-5721	111T1D05A01
21	O	GAGE, PROFILE	5220-01-357-4913	TF-0237
22	F,H	GAGE, PROFILE	5220-01-388-1460	J-38548-1
23	H	HANDLE, DRIVE	5120-00-377-2259	J8092
24	O	HEATER, GUN TYPE, ELECTRIC	4940-00-561-1002	500A
25	F,H	HOLDING BAR, PINION	5120-01-166-0573	J3453
25.1	O	INDICATOR, DIAL		P36491
26	O	INSERTER AND REMOVER, ELECTRICAL CONTACT	5120-00-915-4588	MS3447-16
27	H	INSERTER AND REMOVER, SPRING	5120-01-388-3660	J38573
28	H	INSERTER AND REMOVER, SPRING	5120-01-388-4436	J35923
29	H	INSERTER, BEARING AND BUSHING	5120-01-388-7841	J-38565
30	H	INSERTER, BEARING AND BUSHING	5120-01-389-0658	J35921-1
31	H	INSERTER, BEARING AND BUSHING	5120-01-390-1104	J 38569
32	H	INSERTER, BEARING AND BUSHING	5120-01-390-1105	J 38568-3
33	H	INSERTER, BEARING AND BUSHING	5120-01-391-5133	J 38579
34	F,H	INSERTER, BEARING AND BUSHING	5120-01-414-7398	J38566
35	F	INSERTER, SEAL	5120-01-362-2026	1U7430
36	F	INSERTER, SEAL	5120-01-362-2027	1U7598
37	F	INSTALLER, SEAL	N/A	J38574
37.1	F	JACK, DOLLY TYPE HYDRAULIC	4910-01-396-5044	TTJ3
38	F	JACK, LEVELING SUPPORT, VEHICLE	2590-00-231-7418	10876244
38.1	O	KEY, SOCKET HEAD SCREW	5120-01-355-1670	AWML2.5
38.2	F	NOSE ASSEMBLY		99-3307
38.3	O	PLIERS, HOG RING STAPLE	5120-01-413-8837	0012
38.4	F	LIFTING SADDLE ASSEMBLY		TTJ-ZIFA
39	H	PULLER KIT, UNIVERSAL	5180-00-089-3660	A57QB
40	F	PULLER KIT, UNIVERSAL	5180-01-124-1903	1P3075
41	O	REMOVER, ELECTRICAL CONTACT	5120-00-148-9844	MS3448-001B
42	F	RIVETER, BLIND, HAND	5120-01-289-4310	HP-2

Section III. TOOLS AND TEST EQUIPMENT FOR MTV VEHICLES

Tool or Test Equipment REF Code	Maintenance Level	Nomenclature	National Stock Number	Tool Number
42.1	F	RIVETER, BLIND, PNEUMATIC	5130-01-232-4042	245
43	H	RIVETER, YOKE, HAND	5120-01-415-3558	J-39354
44	F	SCREWDRIVER ATTACHMENT, SOCKET WRENCH	5120-00-601-6934	LAW120A
45	O	SCREWDRIVER ATTACHMENT, SOCKET WRENCH	5120-01-053-4158	FAM5A
46	O,F,H	SCREWDRIVER ATTACHMENT, SOCKET WRENCH	5120-01-055-1308	ANSIB18.3.2M
47	O	SCREWDRIVER ATTACHMENT, SOCKET WRENCH	5120-01-079-8032	SAM8A
48	O	SCREWDRIVER ATTACHMENT, SOCKET WRENCH	5120-01-160-8862	S 6 HBS
49	O,F	SCREWDRIVER ATTACHMENT, SOCKET WRENCH	5120-01-367-3462	SA10A
49.1	O,F	SCREWDRIVER ATTACHMENT, SOCKET WRENCH	5120-01-367-3483	FA5LE
50	O,F	SCREWDRIVER ATTACHMENT, SOCKET WRENCH	5120-01-367-3497	TMP12A
51	O	SCREWDRIVER ATTACHMENT, SOCKET WRENCH	5120-01-367-3519	F23D
52	O	SCREWDRIVER ATTACHMENT, SOCKET WRENCH	5120-01-367-3526	FP24
53	O	SCREWDRIVER ATTACHMENT, SOCKET WRENCH	5120-01-367-3527	FP32A
54	F,H	SCREWDRIVER ATTACHMENT, SOCKET WRENCH	5120-01-367-3536	FTX40A
55	O	SCREWDRIVER ATTACHMENT, SOCKET WRENCH	5120-01-367-3574	GFA8A
56	O	SEPARATOR, BALL JOINT	5120-01-255-8238	2287
57	F	SETTING TOOL, WINDSHIELD	5120-01-316-4995	CRL216
58	O,F	SHOP EQUIPMENT, AUTOMOTIVE VEHICLE	4910-00-348-7696	SC4910-95CLA02
59	O,F,H	SHOP EQUIPMENT, AUTOMOTIVE VEHICLE	4910-00-754-0650	SC4910-95CLA72
60	O	SHOP EQUIPMENT, AUTOMOTIVE VEHICLE	4910-00-754-0653	SC4910-95CLA73
61	O,F,H	SHOP EQUIPMENT, AUTOMOTIVE VEHICLE	4910-00-754-0654	SC4910-95CLA74
62	F,H	SHOP EQUIPMENT, AUTOMOTIVE VEHICLE	4910-00-754-0705	SC4910-95CLA31
63	F,H	SHOP EQUIPMENT, AUTOMOTIVE VEHICLE	4910-00-754-0706	SC4910-95CLA62
64	O,F,H	SHOP EQUIPMENT, AUTOMOTIVE VEHICLE	4910-00-754-0707	SC4910-95CLA63
65	O,F	SHOP EQUIPMENT, FUEL AND ELECTRICAL	4910-00-754-0714	SC4910-95CLA01
66	F	SLIDER, SPRING COMPRESSOR	4910-01-165-6015	TF-TUN-J500
67	F	SLING, MULTIPLE LEG	3940-00-777-5744	A170

Section III. TOOLS AND TEST EQUIPMENT FOR MTV VEHICLES

Tool or Test Equipment REF Code	Maintenance Level	Nomenclature	National Stock Number	Tool Number
68	H	SOCKET SET, SOCKET WRENCH	5120-01-195-0640	208FA
69	F,H	SOCKET, SOCKET WRENCH	5120-01-068-5643	5555M
70	O	SOCKET, SOCKET WRENCH	5120-01-161-5907	GLDH382
71	F	SOCKET, SOCKET WRENCH	5120-01-335-0784	TW321
72	O	SOCKET, SOCKET WRENCH	5120-01-144-5324	ANS 1913A
73	F	SOLDERING AND BRAZING OUTFIT, RESISTANCE HEATING	3439-00-460-7198	SC4940-95-CLB20
74	O	SOLDERING IRON, ELECTRIC	3439-01-036-3308	3112-S3-40W
75	H	STAND, DIFFERENTIAL CARRIER REPAIR	4910-01-085-7729	J3409-D
76	H	STAND, MAINTENANCE, AUTOMOTIVE ENGINE	4910-00-808-3372	J29109
77	F	TOOL, DISTORTER	5120-01-119-1748	5P-7312
78	O,F	TOOL KIT, AUTO FUEL AND ELECTRICAL SYSTEM REPAIR	5180-00-754-0655	SC4910-95CLA50
79	F	TOOL KIT, BODY AND FENDER	5180-00-754-0643	SC5180-90-N34
80	O,F,H	TOOL KIT, GENERAL MECHANIC'S	5180-00-177-7033	SC5180-90-CL-N26
81	F,H	TOOL KIT, GENERAL MECHANIC'S	5180-00-699-5273	SC5180-90-CL-N05
82	F	TOOL KIT, INTERNAL COMBUSTION ENGINE	5180-01-356-8155	1U6680
83	H	TOOL KIT, DIESEL INJECTOR	5180-01-466-3966	143-2099
84	F	TOOL OUTFIT, HYDRAULIC	4940-01-036-5784	SC4940-95-CL-B07
85	O	TOOL, SPRING REMOVAL	5120-01-360-1918	TV940010
86	F	WIRE TWISTER, PLIER	5120-00-542-4171	GGG-W-340
87	F	WRENCH SET, CROWFOOT, RATCHETING	5120-00-293-0013	GGG-W-646
88	F	WRENCH SET, SOCKET	5120-00-148-3706	ANSI-B107.5
89	H	WRENCH SET, SPANNER	5120-00-215-1882	46D7578
90	O	WRENCH, TORQUE, 0-75 LB-IN.	5120-01-112-9532	TQSC6A

Section IV. REMARKS FOR THE MTV VEHICLE

Remarks Code	Remarks
A	Battery service will be in accordance with TM 9-6140-200-14.
B	Repair of tires will be in accordance with TM 9-2610-200-14.

APPENDIX C TOOLS IDENTIFICATION LIST

Section I. INTRODUCTION

C-1. INTRODUCTION

This appendix lists common tools, supplements, and special tools/fixtures that are suggested for maintenance tasks performed at the Unit Maintenance level.

C-2. EXPLANATION OF COLUMNS

a. Column (1) - Item Number. This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the item, e.g., "Bar, Pry (Item 1, Appendix C)."

b. Column (2) - Item Name. This column contains the nomenclature for the item.

c. Column (3) - National Stock Number. This is the national stock number assigned to the item which you can use to requisition it.

d. Column (4) - Part Number. This provides the Government, manufacturer, or vendor part number for the item.

e. Column (5) - Reference. This column contains the shop catalog (SC), technical manual, or other publication which provides an illustration and description of the item, or lists whether the item is fabricated.

APPENDIX C Section II. TOOLS IDENTIFICATION LIST

(1) ITEM NUMBER	(2) ITEM NAME	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) REFERENCE
1	ADAPTER, SOCKET WRENCH	5120-00-227-8088	A-A-2172	SC 4910-95-CL-A74
2	ADJUSTING TOOL, BRAKE SHOE	5120-01-154-3029	J34061	SC 4910-95-CL-A74
3	APRON, RUBBER	8145-00-082-6108	MIL-A-41829	SC 4910-95-CL-A74
4	CAPS, VISE JAW	5120-00-221-1506	GGG-C-137	SC 4910-95-CL-A74
5	DISPENSING PUMP, HAND DRIVEN	4930-00-263-9886	43D15069	SC 4910-95-CL-A74
6	DRILL SET, TWIST	5130-00-293-0983	58	SC 4910-95-CL-A74
7	DRILL, PORTABLE, ELECTRIC	5130-00-293-1849	W-D-661	SC 4910-95-CL-A74
8	DRILL, TWIST	5133-01-120-3519		SC 4910-95-CL-A72

Section II. TOOLS IDENTIFICATION LIST (CONT)

(1) ITEM NUMBER	(2) ITEM NAME	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) REFERENCE
9	FISHING TOOL, PNEUMATIC TIRE VALVE	5120-00-516-4220	991	SC 4910-95-CL-A74
10	GAGE, DEPTH, MICROMETER	5210-00-619-4045	445BZ-6RL	CTA 50-909
11	GAGE, TIRE PRESSURE	4910-01-117-2994	955	SC 4910-95-CL-A72
12	GAGE, WHEEL ALIGNMENT	5210-01-223-3701	WA361	SC 4910-95-CL-A72
13	GLOVES, RUBBER	8415-00-641-4601	ZZ-G-381	SC 4910-95-CL-A74
14	GLOVES, WELDER'S	8415-00-268-7859	A-A-50022	SC 4910-95-CL-A72
15	GOGGLES, INDUSTRIAL	4240-00-052-3776	A-A-1110	SC 4910-95-CL-A74
16	GUN, LUBRICATING	4930-00-253-2478	1142	SC 4910-95-CL-A74
17	HAMMER, HAND	5120-00-224-4130	A-A-1292	SC 4910-95-CL-A74
18	HAMMER, HAND	5120-01-065-9037	57-533	SC 4910-95-CL-A72
19	HOSE ASSEMBLY, NONMETALLIC	4720-00-356-8557	ZZ-H-461	SC 4910-95-CL-A74
20	IRON, TIRE	5120-00-765-8536	T48A	SC 4910-95-CL-A74
21	JACK, HYDRAULIC, HAND	5120-00-224-7330	D120	SC 4910-95-CL-A74
22	MULTIMETER, DIGITAL	6625-01-139-2512	T00377	SC 4910-95-CL-A74
23	MULTIPLIER, TORQUE WRENCH	5120-00-574-9318	292	SC 4910-95-CL-A72
24	PAN, DRAIN	4910-00-387-9592	450	SC 4910-95-CL-A74
25	PAN, WASH	4940-00-617-9859	5582281	SC 4910-95-CL-A72
26	PRESSURE TESTER, RADIATOR	4910-01-170-4929	J24460-01	SC 4910-95-CL-A74
27	PULLER KIT, MECHANICAL	5120-00-313-9496	1178	SC 4910-95-CL-A74
28	PULLER, BATTERY TERMINAL	5120-00-944-4268	21	SC 4910-95-CL-A74
29	RESPIRATOR, AIR FILTER	4240-00-022-2524	GGG-M-125/6	SC 4910-95-CL-A72
30	SCALE, WEIGHING	6670-00-254-4634	AAA-S-133	SC 4910-95-CL-A74
31	SLING, CARGO	1670-00-823-5043	63J4261-13	CTA 50-970
32	SLING, ENDLESS	3940-00-675-5003	PD101-96	CTA 50-970
33	SOCKET SET, IMPACT	5120-01-117-0466	4151MMY	SC 4910-95-CL-A74
34	SOCKET SET, SOCKET WRENCH	5120-01-073-2821	217FMY	SC 4910-95-CL-A74

Section II. TOOLS IDENTIFICATION LIST (CONT)

(1) ITEM NUMBER	(2) ITEM NAME	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) REFERENCE
35	SOCKET SET, SOCKET WRENCH	5120-01-115-1149	315SIMMY	SC 4910-95-CL-A74
36	SOCKET SET, SOCKET WRENCH	5120-01-117-3876	221FSMY	SC 4910-95-CL-A72
37	SOCKET, SOCKET WRENCH	5120-00-181-6813	5530	SC 4910-95-CL-A74
38	SOCKET, SOCKET WRENCH	5120-00-232-5681	1242	SC 4910-95-CL-A74
39	SOCKET, SOCKET WRENCH	5120-00-243-7351	5316	SC 4910-95-CL-A74
40	SOCKET, SOCKET WRENCH	5120-01-112-0581	SIMM190	SC 4910-95-CL-A74
41	STE/ICE-R	4910-01-222-6589	12259266	SC 4910-95-CL-A74
41.1	TEST KIT, RADIATOR	4910-00-728-8227		SC 4910-95-CL-A74
41.2	TAP AND DIE SET	5136-01-119-0005	TDM99117	SC 4910-95-CL-A72
42.3	TAP, THREAD, CUTTING	5136-00-729-5692	B94.9 ½-13 UNCHSGH3	SC 4910-95-CL-A72
42	TESTER, ANTIFREEZE AND BATTERY	6630-00-105-1418	10425	SC 4910-95-CL-A74
43	TOOL KIT, AUTO FUEL	5180-00-754-0655		SC 5180-95-CL-A50
44	TOOL KIT, BLIND RIVET	5180-01-201-4978	D-100-MIL-1	SC 4910-95-CL-A74
45	TOOL KIT, ELECTRICAL	5180-00-876-9336	7550526	SC 4910-95-CL-A72
46	TOOL KIT, GENERAL MECHANIC'S	5180-00-177-7033		SC 5180-90-N26
47	TRESTLE, MOTOR VEHICLE MAINTENANCE	4910-00-251-8013	306	SC 4910-95-CL-A74
48	VICE, MACHINIST	5120-00-293-1439	504M2	SC 4910-95-CL-A74
49	WRENCH SET, SOCKET	5120-00-081-2305	GGG-W-641	SC 4910-95-CL-A74
50	WRENCH SET, SOCKET	5120-00-204-1999	GGG-W-641	SC 4910-95-CL-A74
51	WRENCH SET, SOCKET	5120-00-322-6231	51200017510	SC 4910-95-CL-A74
52	WRENCH, ADJUSTABLE	5120-00-264-3793	2117080	SC 4910-95-CL-A74
53	WRENCH, ADJUSTABLE, AUTOMOTIVE	5120-00-449-8083	1B7536	SC 4910-95-CL-A74
54	WRENCH, BOX AND OPEN END	5120-00-277-8833	1244	SC 4910-95-CL-A74
55	WRENCH, BOX AND OPEN END	5120-00-277-8834	GGG-W-636	SC 4910-95-CL-A74
56	WRENCH, PIPE	5120-00-277-1485		SC 4910-95-CL-A74

Section II. TOOLS IDENTIFICATION LIST (CONT)

(1) ITEM NUMBER	(2) ITEM NAME	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) REFERENCE
57	WRENCH, STRAP, ADJUSTABLE	5120-00-020-2947	A91C	SC 4910-95-CL-A74
58	WRENCH, TORQUE, 0-175 lb- ft	5120-00-640-6364	1753LDF	SC 4910-95-CL-A74
59	WRENCH, TORQUE, 0-200 lb- in.	5120-00-853-4538	F2001	SC 4910-95-CL-A72
59.1	WRENCH, TORQUE, 0-300 lb- in.	5120-00-776-1841	2163993	SC 4910-95-CL-A74
60	WRENCH, TORQUE, 0-600 lb- ft	5120-00-221-7983	SW130-301	SC 4910-95-CL-A72

APPENDIX D EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST

Section I. INTRODUCTION

D-1. SCOPE

This appendix lists expendable and durable items that you will need to operate and maintain the MTV vehicle. This listing is for information only and is not authority to requisition the listed items. These items are authorized to you by CTA 50-970, Expendable/Durable Items (except medical, class V repair parts, and heraldic items), or CTA 8-100, Army Medical Department Expendable/Durable Items.

D-2. EXPLANATION OF COLUMNS

- a. **Column (1) - Item Number.** This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the item, e.g., "Oil, Lubricating (Item 25, Appendix D).
- b. **Column (2) - Level.** This column identifies the lowest level of maintenance that requires the item.
- c. **Column (3) - National Stock Number.** This is the national stock number assigned to the item which you can use to requisition it.
- d. **Column (4) - Item Name, Description, Commercial and Government Entity Code (CAGEC), and Part Number.** This provides the other information you need to identify the item.
- e. **Column (5) - Unit of Measure.** This code shows the physical measurement or count of an item, such as gallon, dozen, gross, etc.

Section II. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
1	O	4730-00-248-9340	Adapter, Pipe to Tube (81343) 4-4 010103B	ea
1.1	O	4730-01-453-9651	Adapter, Straight, Pipe to Boss (19207) 12421890-001	ea
1.2	O	4730-01-457-4025	Adapter, Straight, Pipe to Tube (96906) MS51503B4-4	ea
1.3	O	4730-00-760-3525	Adapter, Straight, Tube to Boss (81361) C116-3-71	ea
2	O	8040-00-273-8717	Adhesive (81348) MMM-A-121	pt
3	O	8040-00-152-0063	Adhesive (81348) MMM-A-1617 TY3	bt
4	O	8040-01-250-3969	Adhesive (05972) 242	ea
5	O	8040-00-117-8510	Adhesive (71984) 3145 RTV Clear	tu
6	O	8040-00-776-9602	Adhesive (73168) 80055-31	kt
7	O	8040-00-522-3429	Adhesive (81349) (MIL-A-46106)	oz

Section II. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
8	O	8040-00-118-2695	Adhesive (72799) RTV162	kt
9	O	8040-01-331-7473	Adhesive (81349) (MIL-A-46106 GP3TY1)	tu
10	O	8040-01-331-7470	Adhesive (81349) MIL-A-46106 5 oz tube	oz
10.1	O	8040-01-446-7842	Adhesive (01139) RTV123	ca
10.2	O	8040-00-728-3088	Adhesive (78500) 1199-T-3842 6 oz	kt
11	C	6850-00-174-1806	Antifreeze, Arctic Type (81349) (MIL-A-11755) 55 gl drum	dr
12	C		Antifreeze, Multi-Engine Type (58536) (A-A-52624A)	dr
		6850-01-441-3218	Type I (Green) - 1 gal	gal
		6850-01-441-3221	Type I (Green) - 5 gal	co
		6850-01-441-3257	Type II (Purple) - 5 gal	co
13	O	8030-00-597-5367	Antiseize Compound (81349) (MIL-A-907)	lb
13.1	O	5340-01-454-4336	Bracket, Angle (0FW39) 12421859-001	ea
14	O	5340-00-450-5718	Cap and Plug Set (19207) 10935405	ea
14.1	O	5340-01-423-0972	Clamp, Loop (18076) S630H-20	ea
14.2	O	5340-01-377-6171	Clamp, Loop (18076) 5630H-24	ea
15	O	6850-00-926-2275	Cleaning Compound, Windshield (81349) O-C-1901 16 oz bottle	bt
16	O	7920-00-044-9281	Cloth, Cleaning (81349) (MIL-C-85043)	bx
17	O		Corrosion Preventive Compound (81349) (MIL-C-16173)	
		8030-00-062-6950	Grade 1 - 1 qt can	qt
		8030-01-149-1731	Grade 2 - 1 qt can	qt
		8030-00-837-6557	Grade 3 - 1 pt can	pt
		8030-00-903-0931	Grade 4 - 1 pt can	pt
18	O	8030-00-033-4291	Corrosion Preventive Compound (81349) (MIL-C-82594) 8 oz can	bt
18.1	O	2540-01-460-8048	Cover, Seat, Vehicular (27797) WM1058	ea
18.2	O	2540-01-463-8394	Cover, Seat, Vehicular (0FW39) WM1059	ea
19	C	9150-00-024-9621	Damping Fluid (81348) VV-D-1078	pt
20	O	7520-01-209-1152	Dispenser, Pressure Sensitive Adhesive Tape (75037) STD-0-9	ea
20.1	O	4730-01-454-1233	Elbow, Pipe to Boss (19207) 12421891-001	ea
20.2	O	4730-00-863-9098	Elbow, Pipe to Tube (30780) 4VBTXB	ea
21	O	5330-01-325-6993	Gasket Forming Compound (05972) 515	ea
21.1	O		Gasket Maker, RTV Silicone (05972) 5699	ea

Section II. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
22	O	9150-01-197-7688 9150-01-197-7690 9150-01-197-7689 9150-01-197-7692	Grease, Automotive and Artillery (GAA) (81349) (MIL-G-10924) 2-1/4 oz tube 1.75 lb can 6.5 lb can 35 lb can	tu cn cn cn lb
23	O	9150-00-180-6382	Grease, General Purpose (81349) MIL-T-24139 6.5 lb can	ca
24	O	9150-00-935-4018	Grease, Molybdenum Disulfide (81349) (MIL-G-21164)	ea
24.1	O	4720-01-469-9208	Hose Assembly, Nonmetallic (0FW39) 12418004-002	ea
24.2	O		Hose Assembly (0FW39) 12421278-003	ea
24.3	O		Hose Assembly (0FW39) 12421858-002	ea
24.4	O		Hose Assembly (0FW39) 12421858-003	ea
24.5	O		Hose Assembly (0FW39) 12421858-004	ea
24.6	O		Hose Assembly (0FW39) 12421858-005	ea
24.7	O	4720-01-384-0995	Hose Assembly, Nonmetallic (19207) 12421858-006	ea
24.8	O		Hose Assembly (0FW39) 12421927-001	ea
24.9	O		Hose Assembly (0FW39) 12421927-002	ea
24.10	O		Hose Assembly (0FW39) 12421927-003	ea
24.11	O	4720-01-469-9266	Hose Assembly, Nonmetallic (0FW39) 12421927-004	ea
24.12	O		Hose Assembly (0FW39) 12421991	ea
24.13	O	4720-00-988-3842	Hose Assembly, Nonmetallic (50599) R25679-1	ea
25	C	9150-00-252-6383 9150-00-223-4134	Hydraulic Fluid A (81349) (MIL-H-5606) 1 qt can 1 gl can	cn cn
26	O	7510-00-145-0559	Ink, Marking Stencil (81349) (MIL-I-43553)	oz
27	O	7510-01-386-0787	Inking Pad, Rubber Stamp (88001) 0603A	ea
28	O	5970-01-100-4464	Insulating Compound, Electrical (08800) RTV-102WHITE	tu
28.1	O	5970-01-378-3018	Insulation Sleeving, Electrical (06090) ATUM-1/4-0-4FT	lg
29	O	5970-00-838-5951	Insulation Sleeving, Electrical (06090) CRN3-16BLACK	ft
29.1	O	5970-01-161-6796	Insulation Sleeving, Electrical (06090) M23053/4-302-0	ft
29.2	O	5970-00-767-0524	Insulation Sleeving, Electrical (81349) (MIL-1-23053/5 4 in.	ea

Section II. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
30	O	1650-00-166-4834	Lockwire (90166) 68A32	ea
31	O	9150-01-360-1905	Lubricant, Solid Film (81349) (MIL-L-46147) 16 oz can	cn
31.1	O		Modification Kit, Junction Box 6-576-100041 (12361)	ea
32	O	4730-00-019-0608	Nipple, Pipe (81996) A2303-12-52PC102	ea
33	O	4730-00-825-7304	Nipple, Tube (96906) MS51501B4	ea
34	O	5310-00-059-4265	Nut, Plain, Hex (89346) 98881R1	ea
34.1	C		Oil, Commercial Burner Fuel, Grade FO-1 (ASTM D396)	
34.2	C		Oil, Commercial Burner Fuel, Grade FO-2 (ASTM D396)	
35	C	9140-00-286-5282 9140-00-286-5283 9140-00-286-5284 9140-00-286-5285	Oil, Fuel, Diesel, DF-A Arctic (81348) (VV-F-800) 5 gl can Bulk 55 gl drum, 16 gauge 55 gl drum, 18 gauge	cn gl dr dr
36	C	9140-00-286-5286 9140-00-286-5287 9140-00-286-5288 9140-00-286-5289	Oil, Fuel, Diesel, DF-1, Winter (81348) (VV-F-800) Bulk 5 gl can 55 gl drum, 16 gauge 55 gl drum, 18 gauge	gl cn dr dr
37	C	9140-00-286-5294 9140-00-286-5295 9140-00-286-5296 9140-00-286-5297	Oil, Fuel, Diesel, DF-2, Regular (81348) (VV-F-800) Bulk Can 55 gl drum, 16 gauge 55 gl drum, 18 gauge	gl cn dr dr
38	C	9150-00-402-2372 9150-00-491-7197	Oil, Lubricating, Arctic (81349) (MIL-L-46167) 5 gl can 55 gl drum	cn dr
39	C	9150-01-035-5390 9150-01-035-5391	Oil, Lubricating, Gear, GO 75W (81349) (MIL-L-2105) 1 qt can 5 gl can	cn cn
40	C	9150-01-035-5392 9150-01-035-5393 9150-01-035-5394	Oil, Lubricating, Gear, 80W-90 (81349) (MIL-L-2105) 1 qt can 5 gl can 55 gl drum, 16 gauge	qt cn dr

Section II. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
41	O	9150-01-048-4591 9150-01-035-5395 9150-01-035-5396	Oil, Lubricating, Gear, 85W-140 (81349) (MIL-L-2105) 1 qt can 5 gl can 55 gl drum	qt cn dr
42	C	9150-00-183-7807 9150-00-186-6668 9150-00-191-2772	Oil, Lubricating, OE/HDO 10 (81349) (MIL-L-2104) Bulk 5 gl can 55 gl drum	gl cn dr
43	C	9150-00-189-6727	Oil, Lubricating, OE/HDO 10W (81349) (MIL-L-2104) 1 qt can	cn
44	C	9150-01-152-4117 9150-01-152-4118 9150-01-152-4119	Oil, Lubricating, OE/HDO 15W-40 (81349) (MIL-L-2104) 1 qt can 5 gl can 55 gl drum	cn cn dr
45	C	9150-00-183-7808 9150-00-186-6681 9150-00-188-9858 9150-00-189-6729	Oil, Lubricating, OE/HDO 30 (SAE 30) (81349) (MIL-L-2104) Bulk 1 qt can 5 gl can 55 gl drum, 18 gauge	gl cn cn dr
46	C	9150-00-405-2987 9150-00-189-6730 9150-00-188-9862	Oil, Lubricating, OE/HDO 40 (81349) (MIL-L-2104) Bulk 1 qt can 5 gl can	gl cn cn
47	O	5350-00-067-7639	Paper, Abrasive (28124) 02347 pg contains 100 sheets	pg
48	O	8010-01-146-2650	Polyurethane Coating (81349) (MIL-C-46168)	kt
49	O	8030-00-181-8372	Primer, Sealing Compound (05972) 747-56	cn
50	C	7920-00-205-1711	Rag, Wiping (64067) 7920-00-205-1711 50 lb bale	be
51		DELETED		
52	O	4020-00-106-9342	Rope, Nylon (81349) (MIL-R-24050)	ro
53	O	7520-00-634-2442	Rubber Stamp Set, Fixed Type (02663) W-5-3/8-AZ SET	ea
53.1	O	5305-01-299-4602	Screw, Cap, Hex Hd (64678) 000933 006058	ea
53.2	O	5305-01-454-5938	Screw, Cap, Hex Hd (19207) 12419954-093	ea
53.3	O	5305-00-021-3740	Screw, Cap, Hex Hd (97942) 645A560H43	ea

Section II. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
54	O	5305-01-296-0019	Screw, Cap, Socket Head (06888) SHCM75275 50 ct box	bx
54.1	O	8030-01-157-0988	Sealing Compound (83574) PR-1422 A-1/2 6 oz	ca
54.2	O	8030-01-371-8405	Sealing Compound (83574) PR-1422 B-1/2 6 oz	ca
55	O	8030-00-111-2762	Sealing Compound (05972) 290-31	bt
55.1	O	8030-01-255-4144	Sealant (19207) 12297953	tb
55.2	O	8030-00-956-2397	Sealing Compound 104	ea
55.3	O	8030-00-728-9665	Sealant (62377) 80017	pt
56	O	8030-00-133-3164	Sealing Compound (05972) 571-31	bt
57	O	8030-00-148-9833	Sealing Compound (05972) 271-21	bx
58	O	8030-00-204-9149	Sealing Compound (05972) 592-41	tu
59	O	8030-00-656-1426	Sealing Compound (81349) (MIL-S-45180)	pt
60	O	8030-01-025-1692	Sealing Compound (05972) 242-41 (MIL-S-46163)	bt
61	O	8030-01-088-8140	Sealing Compound (52571) 9001512-0011	bt
62	O	8030-01-155-3238	Sealing Compound (11083) 6V6640	ml
63	C	7930-00-634-3935	Soap, Laundry (81348) P-S-1792	lb
64	O	3439-00-006-7764	Solder, Tin Alloy (81348) SN63WRAP3 1 lb spool	sl
65	C	6850-00-281-1985 6850-00-664-5685	Solvent, Dry Cleaning SD (P-D-680) 1 gl can 1 qt can	cn cn
65.1	O		Strap, Tiedown, Electrical Components (06383) PLP2S	ea
65.2	O	9320-01-244-0046	Tape, Adhesive, Rubber (18876) MIS-41157-08 180 ft	ro
66	O	8030-00-889-3534	Tape, Antiseizing (81349) (MIL-T-27730)	ea
67	O	5640-00-103-2254	Tape, Duct (39428) 1791K70	ea
68	O	5970-00-644-3167	Tape, Insulation, Electrical (80063) TL83	ro
68.1	O	4730-00-138-8050	Tee, Pipe (81343) 8-8-8 140424C	ea
69	O	5975-01-379-4997	Ties, Cable, Plastic (06383) PLT 35-C-O	hd
69.1	C		Turbine Fuel, Aviation, Kerosene Type (MIL-T-83133), Grade JP-8	
69.2	C	9140-00-255-7764 9140-00-273-2378 9140-00-273-2377	Turbine Fuel, (MIL-F-16884), (NATO Code No. F75 or F-72) 5 gl can 55 gl drum 1 gl can	cn dr cn

Section II. EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
69.3	C	9130-00-273-2380	Turbine Fuel, (MIL-F-5624), Grade JP-4 (NATO Code No. F40) Drum, 16 gage	dr
69.4	C	9130-01-305-5596 9130-01-250-6353	Turbine Fuel, (MIL-T-5624), Grade JP-5 (NATO Code No. F-44) Bulk Drum, 16 gage	gl dr
70	O	8010-00-180-6343	Varnish, Oil (23667) 515320	pt
71	O	6145-01-148-2263	Wire, Electrical (80009) 175-0825-00 50 ft	ft
72	O	9505-00-555-8648	Wire, Nonelectrical (96906) MS20995C47 5 lb spool	sl

APPENDIX E

ILLUSTRATED LIST OF MANUFACTURED ITEMS

Section I. INTRODUCTION

E-1. INTRODUCTION

This appendix includes complete instructions for manufacturing or fabricating authorized items locally. All bulk materials needed to manufacture an item are listed by part number or specification number. Figures are provided as needed. See standards and specifications DoD-Std-00100D(AR) and ANSI Y14.5M1982 for required details.

Section II. MANUFACTURED ITEMS INDEX

ITEM NAME/PART NUMBER	ITEM DESCRIPTION	PARA NO.
Brake Adjusting Tool Support		E-2
Brake Plunger Seal Driver		E-3
Cab Support Tool		E-4
Dump Body Lifting Bracket		E-5
Headlight Adjustment Screen		E-6
M1089 30K Winch Test Adapter		E-7
M1089 Solenoid Test Adapter		E-8
Relay Test Wire		E-9
Transmission Auxiliary Oil Cooler Rubber Seal		E-10
Wheel Bearing Shim Tool Rest		E-11
12414690-001	Pneumatic Tube	E-12
12414690-002	Pneumatic Tube	E-12
12414690-003	Pneumatic Tube	E-12
12414690-004	Pneumatic Tube	E-12
12414690-005	Pneumatic Tube	E-12
12414690-006	Pneumatic Tube	E-12
12414690-007	Pneumatic Tube	E-12
12414690-008	Pneumatic Tube	E-12
12414690-009	Pneumatic Tube	E-12
12414690-010	Pneumatic Tube	E-12
12414690-101	Pneumatic Tube	E-12
12414690-102	Pneumatic Tube	E-12
12414690-103	Pneumatic Tube	E-12
12414690-104	Pneumatic Tube	E-12
12414690-105	Pneumatic Tube	E-12
12414690-106	Pneumatic Tube	E-12
12414690-107	Pneumatic Tube	E-12
12414690-108	Pneumatic Tube	E-12
12414690-109	Pneumatic Tube	E-12
12414690-112	Pneumatic Tube	E-12
12414690-113	Pneumatic Tube	E-12
12414690-115	Pneumatic Tube	E-12
12414690-118	Pneumatic Tube	E-12
12414690-120	Pneumatic Tube	E-12
12414690-125	Pneumatic Tube	E-12
12414690-128	Pneumatic Tube	E-12
12414690-129	Pneumatic Tube	E-12
12414690-130	Pneumatic Tube	E-12

Section II. MANUFACTURED ITEMS INDEX (CONT)

ITEM NAME/PART NUMBER	ITEM DESCRIPTION	PARA NO.
12414690-131	Pneumatic Tube	E-12
12414690-132	Pneumatic Tube	E-12
12414690-133	Pneumatic Tube	E-12
12414690-134	Pneumatic Tube	E-12
12414690-135	Pneumatic Tube	E-12
12414690-136	Pneumatic Tube	E-12
12414690-137	Pneumatic Tube	E-12
12414690-138	Pneumatic Tube	E-12
12414690-139	Pneumatic Tube	E-12
12414690-140	Pneumatic Tube	E-12
12414690-141	Pneumatic Tube	E-12
12414690-142	Pneumatic Tube	E-12
12414690-143	Pneumatic Tube	E-12
12414690-144	Pneumatic Tube	E-12
12414690-145	Pneumatic Tube	E-12
12414690-146	Pneumatic Tube	E-12
12414690-147	Pneumatic Tube	E-12
12414690-148	Pneumatic Tube	E-12
12414690-149	Pneumatic Tube	E-12
12414690-150	Pneumatic Tube	E-12
12414690-151	Pneumatic Tube	E-12
12414690-152	Pneumatic Tube	E-12
12414690-153	Pneumatic Tube	E-12
12414690-154	Pneumatic Tube	E-12
12414690-155	Pneumatic Tube	E-12
12414690-156	Pneumatic Tube	E-12
12414690-157	Pneumatic Tube	E-12
12414690-158	Pneumatic Tube	E-12
12414690-159	Pneumatic Tube	E-12
12414690-160	Pneumatic Tube	E-12
12414690-161	Pneumatic Tube	E-12
12414690-162	Pneumatic Tube	E-12
12414690-163	Pneumatic Tube	E-12
12414690-164	Pneumatic Tube	E-12
12414690-165	Pneumatic Tube	E-12
12414690-166	Pneumatic Tube	E-12
12414690-167	Pneumatic Tube	E-12
12414690-168	Pneumatic Tube	E-12
12414690-169	Pneumatic Tube	E-12
12414690-201	Pneumatic Tube	E-12
12414690-202	Pneumatic Tube	E-12
12414690-203	Pneumatic Tube	E-12
12414690-205	Pneumatic Tube	E-12
12414690-206	Pneumatic Tube	E-12
12414690-207	Pneumatic Tube	E-12
12414690-208	Pneumatic Tube	E-12
12414690-209	Pneumatic Tube	E-12
12414690-210	Pneumatic Tube	E-12
12414690-211	Pneumatic Tube	E-12
12414690-212	Pneumatic Tube	E-12
12414690-215	Pneumatic Tube	E-12

ITEM NAME/PART NUMBER	ITEM DESCRIPTION	PARA NO.
12414690-216	Pneumatic Tube	E-12
12414690-217	Pneumatic Tube	E-12
12414690-218	Pneumatic Tube	E-12
12414690-219	Pneumatic Tube	E-12
12414690-220	Pneumatic Tube	E-12
12414690-221	Pneumatic Tube	E-12
12414690-222	Pneumatic Tube	E-12
12414690-223	Pneumatic Tube	E-12
12414690-224	Pneumatic Tube	E-12
12414690-225	Pneumatic Tube	E-12
12414690-228	Pneumatic Tube	E-12
12414690-229	Pneumatic Tube	E-12
12414690-230	Pneumatic Tube	E-12
12414690-231	Pneumatic Tube	E-12
12414690-232	Pneumatic Tube	E-12
12414690-233	Pneumatic Tube	E-12
12414690-234	Pneumatic Tube	E-12
12414690-235	Pneumatic Tube	E-12
12414690-236	Pneumatic Tube	E-12
12414690-237	Pneumatic Tube	E-12
12414690-238	Pneumatic Tube	E-12
12414690-239	Pneumatic Tube	E-12
12414690-240	Pneumatic Tube	E-12
12414690-241	Pneumatic Tube	E-12
12414690-242	Pneumatic Tube	E-12
12414690-243	Pneumatic Tube	E-12
12414690-244	Pneumatic Tube	E-12
12414690-245	Pneumatic Tube	E-12
12414690-246	Pneumatic Tube	E-12
12414690-247	Pneumatic Tube	E-12
12414690-248	Pneumatic Tube	E-12
12414690-249	Pneumatic Tube	E-12
12414690-301	Pneumatic Tube	E-12
12414690-302	Pneumatic Tube	E-12
12414690-303	Pneumatic Tube	E-12
12416381P1	Non-Metallic Electrical Cable Conduit	E-13
12416381P10	Non-Metallic Electrical Cable Conduit	E-13
12416381P11	Non-Metallic Electrical Cable Conduit	E-13
12416381P12	Non-Metallic Electrical Cable Conduit	E-13
12416381P13	Non-Metallic Electrical Cable Conduit	E-13
12416381P14	Non-Metallic Electrical Cable Conduit	E-13
12416381P15	Non-Metallic Electrical Cable Conduit	E-13
12416381P16	Non-Metallic Electrical Cable Conduit	E-13
12416381P17	Non-Metallic Electrical Cable Conduit	E-13
12416381P2	Non-Metallic Electrical Cable Conduit	E-13
12416381P20	Non-Metallic Electrical Cable Conduit	E-13
12416381P21	Non-Metallic Electrical Cable Conduit	E-13
12416381P22	Non-Metallic Electrical Cable Conduit	E-13
12416381P23	Non-Metallic Electrical Cable Conduit	E-13
12416381P26	Non-Metallic Electrical Cable Conduit	E-13
12416381P3	Non-Metallic Electrical Cable Conduit	E-13
12416381P30	Non-Metallic Electrical Cable Conduit	E-13
12416381P32	Non-Metallic Electrical Cable Conduit	E-13

Section II. MANUFACTURED ITEMS INDEX (CONT)


ITEM NAME/PART NUMBER	ITEM DESCRIPTION	PARA NO.
12416381P34	Non-Metallic Electrical Cable Conduit	E-13
12416381P35	Non-Metallic Electrical Cable Conduit	E-13
12416381P36	Non-Metallic Electrical Cable Conduit	E-13
12416381P37	Non-Metallic Electrical Cable Conduit	E-13
12416381P38	Non-Metallic Electrical Cable Conduit	E-13
12416381P4	Non-Metallic Electrical Cable Conduit	E-13
12416381P5	Non-Metallic Electrical Cable Conduit	E-13
12416381P6	Non-Metallic Electrical Cable Conduit	E-13
12416381P7	Non-Metallic Electrical Cable Conduit	E-13
12416381P8	Non-Metallic Electrical Cable Conduit	E-13
12416381P9	Non-Metallic Electrical Cable Conduit	E-13
12418037	Steering Gear Return Hose	E-14
12418460-001	Transmission Oil Cooler Hose	E-14
12418460-002	Transmission Oil Cooler Hose	E-14
12418763	Lanyard Assembly	E-15
12420196	Lanyard Assembly	E-15
12420197-001	Non-Metallic Vent Air Hose	E-16
12420197-002	Non-Metallic Vent Air Hose	E-16
12420197-003	Non-Metallic Vent Air Hose	E-16
12420197-004	Non-Metallic Vent Air Hose	E-16
12420197-005	Non-Metallic Vent Air Hose	E-16
12420197-006	Non-Metallic Vent Air Hose	E-16
12420198-001	Non-Metallic Vent Air Hose	E-16
12420198-002	Non-Metallic Vent Air Hose	E-16
12420308-457	Personnel Heater Air Duct Hose	E-17
12420308-760	Personnel Heater Air Duct Hose	E-17
12420489	Block Seal	E-18
3256-H-1048	CTIS Seal Driver	E-19
3256-K-1051	Wheel Hub Grease Seal Driver	E-20
Dimmer Switch Test Wire		E-21
Purge Valve Tool		E-22
M1089 30K Winch Air Hoses		E-23
M1089 30K Winch Pneumatic Test Adapter		E-24

Section III. MANUFACTURED ITEMS

E-2. BRAKE ADJUSTING TOOL SUPPORT

Make the brake adjusting tool support from 0.134 in. (3.4 mm) flat steel stock according to the following instructions. Refer to the parts list and **Figure E-1. Brake Adjusting Tool Support** for details.

Item	Part Number	Material Description	Size	Qty
1	N/A	Steel, ASTM A569 Sheet, Hot Rolled	6.0 in. (152.4 mm) x 6.0 in. (152.4 mm) x 0.134 in. (3.4 mm)	2




YAPPD011

Figure E-1. Brake Adjusting Tool Support

- a. All dimensions are in inches (millimeters).
- b. Cut steel sheet as shown by dimensions on **Figure E-1. Brake Adjusting Tool Support**.
- c. De-burr and remove sharp edges.

E-3. BRAKE PLUNGER SEAL DRIVER



XAPPE021


Figure E-2. Brake Plunger Seal Driver

- a. All dimensions are in inches (millimeters).
- b. Manufacture from round steel stock.
- c. De-burr and remove sharp edges.

E-4. CAB SUPPORT TOOL

Make the cab support tool from .38 inch (.96 cm) flat steel stock and angle iron stock according to the following instructions. Refer to the parts list and **Figure E-3. Cab Support Tool Strut and Cab Rest** for details.

Item	Part Number	Material Description	Size	Qty
1	N/A	Steel, Flat Bar	4.0 in. (10.2 cm) X 33.38 in. X (84.8 cm) X 0.38 in. (0.96 cm)	1
2	N/A	Steel, Flat Bar	4.0 in. (10.2 cm) X 12.0 in. (30.5 cm) X 0.38 in. (0.96 cm)	1
3	N/A	Angle Iron	2.0 in. (5.1 cm) X 2.0 in. (5.1 cm) X 3.5 in. (8.9 cm)	2
4	H.S.105VW-1	Insulgrip, CSA 105 C		




XAPPE031

Figure E-3. Cab Support Tool Strut and Cab Rest

- All dimensions are in inches (centimeters).
- Cut cab support tool strut (1) from steel flat bar and bend to shape as shown in **Figure E-3. Cab Support Tool Strut and Cab Rest**.
- Cut cab support tool cab rest (2) from steel flat bar.
- De-burr and remove sharp edges.


E-4. CAB SUPPORT TOOL (CONT)



XAPPE041

Figure E-4. Cab Support Tool Seat

- e. Remove flange side of cab support tool seats (3) as shown in **Figure E-4. Cab Support Tool Seat**.
- f. Cut cab support tool seats (3) L and (3) R according to dimensions and left/right orientation shown on **Figure E-4. Cab Support Tool Seat**.
- g. De-burr and remove sharp edges.




XAPPE051

Figure E-5. Cab Support Tool Seat Layout

- h. Position and clamp cab support tool seats (3) L and (3) R together as shown by dimensions on **Figure E-5. Cab Support Tool Seat Layout**.
- i. Weld cab support tool seat (3) L to cab support tool seat (3) R as identified on assembly table and **Figure E-5. Cab Support Tool Seat Layout**.
- j. Position and clamp cab support tool seats (3) L and (3) R to cab support tool strut (1) as shown by dimensions on **Figure E-5. Cab Support Tool Seat Layout**.
- k. Weld items clamped in step (f) as shown in **Figure E-5. Cab Support Tool Seat Layout**.
- l. De-burr and remove sharp edges.

E-4. CAB SUPPORT TOOL (CONT)



XAPPE061

Figure E-6. Cab Support Tool Assembly

- m. Position and clamp cab support tool strut (1) to cab support tool cab rest (2) as shown by dimensions on **Figure E-6. Cab Support Tool Assembly**, before insulgrip (4) is applied.
- n. Weld cab support tool strut (1) to cab support tool cab rest (2).
- o. Apply Insulgrip (4) to cab support tool cab rest (2) as described on material container.

E-5. DUMP BODY LIFTING BRACKET

Make the dump body lifting bracket assembly from the front, rear, top, guide, and mount plates according to the following instructions. Refer to the parts list tables and accompanying figures for details.

Item	Part Number	Name/Description	Qty
1	N/A	Rear Plate	1
2	N/A	Top Plate	1
3	N/A </td <td>Front Plate</td> <td>1</td>	Front Plate	1
4	N/A	Guide Brace	1
5	N/A	Plate, Mounting	1





Figure E-7. Dump Body Lifting Bracket

- All dimensions are in inches (centimeters).
- Position and clamp pieces (1 through 5) together as shown by dimensions on **Figure E-7. Dump Body Lifting Bracket**.
- Weld pieces together as shown in **Figure E-7. Dump Body Lifting Bracket**.
- Coat all surfaces with Plastisol.

E-5. DUMP BODY LIFTING BRACKET (CONT)

Item	Part Number	Material Description	Size	Qty
1	N/A	Plate, steel, ASTM A-36	6.0 in. (15.2 cm) X 4.0 in. (10.2 cm) X 0.375 in. (0.95 cm)	1
2	N/A	Plate, steel, ASTM A-36	3.25 in. (8.26 cm) X 4.0 in. (10.2 cm) X 0.375 in. (0.95 cm)	1
4	N/A	Plate, steel, ASTM A-36	1.875 in. (4.75 cm) X 4.0 in. (10.2 cm) X 0.375 in. (0.95 cm)	1




XAPPE081

Figure E-8. Rear, Top, and Guide Plate

- a. All dimensions are in inches (centimeters).
- b. Fabricate (1),(2), and (4) from ASTM A-36 steel plate as shown on **Figure E-8. Rear, Top, and Guide Plate**.
- c. De-burr and remove sharp edges.

Item	Part Number	Material Description	Size	Qty
3	N/A	Plate steel, ASTM A36	10.5 in. (26.7 cm) X 4.0 in. (10.2 cm) X 0.375 in. (0.95 cm)	1
5	N/A	Plate steel, ASTM A36	5.25 in. (13.3 cm) X 4.0 in. (10.2 cm) X 0.375 in. (0.95 cm)	1



XAPPE091


Figure E-9. Front and Mounting Plate

- All dimensions are in inches (centimeters).
- Fabricate (3) and (5) from ASTM A-36 steel plate.
- Drill 1-1/2 inch (3.84 cm) diameter hole in (5) as shown on **Figure E-9. Front and Mounting Plate.**
- Grind bevel edge of each plate for weld surface as shown on **Figure E-9. Front and Mounting Plate.**
- De-burr and remove sharp edges.

E-6. HEADLIGHT ADJUSTMENT SCREEN

The headlight adjustment screen may be drawn on any vertical surface at least 50 in. (127 cm) high and 100 in. (254 cm) wide.

- a. Draw two vertical lines (1) 50 in. (127 cm) high and 90.6 in. (230 cm) apart (centered on headlight adjustment screen).
- b. Locate two points 40 in. (101.6 cm) from floor and 13 in. (33 cm) toward the center from each vertical line (1).
- c. Draw vertical line (2) about 3-5 in. (8-13 cm) centered on each of the two points.
- d. Draw horizontal line (3) about 3-5 in. (8-13 cm) centered on each of the two points.
- e. Measure out 4 in. (10 cm) along each vertical line (2) and horizontal line (3) from each of the two points to make 8 in. (20 cm) squares (4).




XAPPE101

Figure E-10. Headlight Adjustment Screen

E-7. M1089 30K WINCH TEST ADAPTER

Assemble the M1089 30K winch test adapter according to the following steps. Refer to the following parts list and **Figure E-11. M1089 30K Winch Test Adapter** for details.

Part Number	Material Description	National Stock Number	Qty
4-4-4 100401BA	Tee, Tube	4730-01-095-3430	1
4-6 100102BA	Adapter, Straight, Pipe to Tube	4730-01-096-9398	1
207P-4	Coupling, Pipe	4730-00-881-1161	1
NB-4-035	Tubing, Nonmetallic	4720-01-071-4042	4 in.
MIL-T-27730	Tape, Antiseizing	8030-00-889-3534	1 roll



XAPPE111


Figure E-11. M1089 30K Winch Test Adapter

- All dimensions are in inches (millimeters).
- Cut two pieces of nonmetallic tubing (1 and 2) to 2.0 in. (50.8 mm) long.
- Remove three nuts (3), sleeves (4), and ferrules (5) from tube tee (6).
- Install two nuts (3), sleeves (4), and ferrules (5) on nonmetallic tubing (1).
- Install nonmetallic tubing (1) on tube tee (6).
- Remove nut (7), sleeve (8), and ferrule (9) from straight adapter (10).
- Install two nuts (3 and 7), sleeves (4 and 8), and ferrules (5 and 9) on nonmetallic tubing (2).
- Install nonmetallic tubing (2) on tube tee (6).
- Install nut (9) on straight adapter (10).
- Apply one wrap of antiseizing tape to threads of straight adapter (10).
- Install pipe coupling (11) on straight adapter (10).

E-8. M1089 SOLENOID TEST ADAPTER

Assemble the M1089 solenoid test adapter according to the following steps. Refer to the following parts list and **Figure E-12. M1089 Solenoid Test Adapter** for details.

Part Number	Material Description	National Stock Number	Qty
2-2-2 080401CA	Tee, Tube	4730-01-214-6990	1
2-2 080202CA	Elbow, Pipe to Tube	4730-00-845-5345	1
4-2 130140B	Bushing, Pipe	4730-00-828-0171	1
NB-2-031	Tubing, Nonmetallic	4720-01-287-4499	24 in.



XAPPE121

Figure E-12. M1089 Solenoid Test Adapter

- a. All dimensions are in inches (millimeters).
- b. Cut one piece of nonmetallic tubing (1) to 6.0 in. (152.4 mm) long.
- c. Cut one piece of nonmetallic tubing (2) to 18.0 in. (457.2 mm) long.
- c. Remove three nuts (3) and ferrule sleeves (4) from tube tee (5).
- d. Install two nuts (3) and ferrule sleeves (4) on nonmetallic tubing (1).
- e. Install nonmetallic tubing (1) on tube tee (5).
- f. Remove nut (6) and ferrule sleeve (7) from pipe to tube elbow (8).
- g. Install two nuts (3 and 6) and ferrule sleeves (4 and 7) on nonmetallic tubing (2).
- h. Install nonmetallic tubing (2) on tube tee (5).
- i. Install nut (6) on pipe to tube elbow (8).
- j. Install pipe bushing (9) on pipe to tube elbow (8).

E-9. RELAY TEST WIRE

Fabricate the relay test wire according to the following steps. Refer to the following parts list for materials.

Material Description	National Stock Number	Cut Length
Wire, Electrical (MIL-W-16878)	6145-00-330-3318	6 in. (152 mm)

- a. Dimensions are in inches (millimeters).
- b. Cut a length of wire six inches (152 mm) long.
- c. Remove approximately 3/4 in. (19 mm) of electrical insulation from each end of wire.

E-10. TRANSMISSION AUXILIARY OIL COOLER RUBBER SEAL

Fabricate the transmission auxiliary oil cooler rubber seals in accordance with the following parts list.

Part Number	Description	National Stock Number	Cut Length	
			inches	mm
MIL-R-6130	Tape, Adhesive, Rubber	9320-00-501-7537	24.7	627

E-11. WHEEL BEARING SHIM TOOL REST

Fabricate the wheel bearing shim tool rest according to the following steps. Refer to the following parts list for materials.

Part Number	National Stock Number	Description
QQ-T-570	9510-00-866-1037	Bar, Metal

- a. Dimensions are in inches (millimeters)
- b. Cut metal bar to 9.0 inches (228.6 mm) long.
- c. De-burr and remove sharp edges from ends of metal bar.

E-12. PNEUMATIC TUBES FABRICATION

Cut pneumatic tubes from bulk tubing stock listed in **Table E-1. Pneumatic Tube Lengths**. Use a fine-toothed hacksaw or suitable cutting device and cut tubing to required length.

Table E-1. Pneumatic Tube Lengths

Tube Part Number	Bulk Tubing Part Number	Cut Length	
		inches	cm
12414690-001	NT-100-4 (79470)	18.1	46.0
12414690-002	NT-100-4 (79470)	16.0	40.6
12414690-003	NT-100-4 (79470)	15.0	38.1
12414690-004	NT-100-4 (79470)	74.8	190.0
12414690-005	NT-100-4 (79470)	69.7	177.0

E-12. PNEUMATIC TUBES FABRICATION (CONT)

Table E-1. Pneumatic Tube Lengths (Cont)

Tube Part Number	Bulk Tubing Part Number	Cut Length	
		inches	cm
12414690-006	NT-100-4 (79470)	239.0	607.0
12414690-007	NT-100-4 (79470)	254.8	647.0
12414690-008	NT-100-4 (79470)	286.3	727.0
12414690-009	NT-100-4 (79470)	294.1	747.0
12414690-010	NT-100-4 (79470)	180.0	457.2
12414690-101	J844TYBSIZE 3/8 (81343)	18.0	45.7
12414690-102	J844TYBSIZE 3/8 (81343)	35.4	90.0
12414690-103	J844TYBSIZE 3/8 (81343)	20.9	53.0
12414690-104	J844TYBSIZE 3/8 (81343)	13.8	35.0
12414690-105	J844TYBSIZE 3/8 (81343)	11.8	30.0
12414690-106	J844TYBSIZE 3/8 (81343)	20.5	52.0
12414690-107	J844TYBSIZE 3/8 (81343)	39.0	99.0
12414690-108	J844TYBSIZE 3/8 (81343)	15.4	39.0
12414690-109	J844TYBSIZE 3/8 (81343)	23.0	58.4
12414690-112	J844TYBSIZE 3/8 (81343)	80.0	198.0
12414690-113	J844TYBSIZE 3/8 (81343)	11.4	29.0
12414690-115	J844TYBSIZE 3/8 (81343)	82.8	210.2
12414690-118	J844TYBSIZE 3/8 (81343)	11.8	30.0
12414690-120	J844TYBSIZE 3/8 (81343)	11.9	30.2
12414690-125	J844TYBSIZE 3/8 (81343)	10.8	27.3
12414690-128	J844TYBSIZE 3/8 (81343)	180.1	457.5
12414690-129	J844TYBSIZE 3/8 (81343)	39.3	99.7
12414690-130	J844TYBSIZE 3/8 (81343)	164.4	417.5
12414690-131	J844TYBSIZE 3/8 (81343)	180.1	457.5
12414690-132	J844TYBSIZE 3/8 (81343)	219.5	557.5
12414690-133	J844TYBSIZE 3/8 (81343)		
12414690-134	J844TYBSIZE 3/8 (81343)	277.4	704.5
12414690-135	J844TYBSIZE 3/8 (81343)	325.0	825.5
12414690-136	J844TYBSIZE 3/8 (81343)	332.5	844.6
12414690-137	J844TYBSIZE 3/8 (81343)	51.0	129.5
12414690-138	J844TYBSIZE 3/8 (81343)	67.0	170.2
12414690-139	J844TYBSIZE 3/8 (81343)	98.5	250.2
12414690-140	J844TYBSIZE 3/8 (81343)	106.0	269.2
12414690-141	J844TYBSIZE 3/8 (81343)	52.5	133.4
12414690-142	J844TYBSIZE 3/8 (81343)	68.5	174.0
12414690-143	J844TYBSIZE 3/8 (81343)	100.0	254.0
12414690-144	J844TYBSIZE 3/8 (81343)	107.5	273.0

Table E-1. Pneumatic Tube Lengths (Cont)

Tube Part Number	Bulk Tubing Part Number	Cut Length	
		inches	cm
12414690-145	J844TYBSIZE 3/8 (81343)		
12414690-146	J844TYBSIZE 3/8 (81343)	267.3	679.0
12414690-147	J844TYBSIZE 3/8 (81343)	283.1	719.0
12414690-148	J844TYBSIZE 3/8 (81343)	314.6	799.0
12414690-149	J844TYBSIZE 3/8 (81343)	322.4	819.0
12414690-150	J844TYBSIZE 3/8 (81343)	296.1	752.0
12414690-151	J844TYBSIZE 3/8 (81343)	343.5	872.5
12414690-152	J844TYBSIZE 3/8 (81343)	36.0	91.5
12414690-153	J844TYBSIZE 3/8 (81343)	32.0	81.3
12414690-154	J844TYBSIZE 3/8 (81343)	48.0	122.0
12414690-155	J844TYBSIZE 3/8 (81343)	79.5	202.0
12414690-156	J844TYBSIZE 3/8 (81343)	87.0	221.0
12414690-157	J844TYBSIZE 3/8 (81343)	59.5	151.1
12414690-158	J844TYBSIZE 3/8 (81343)	66.5	169.0
12414690-159	J844TYBSIZE 3/8 (81343)	98.0	249.0
12414690-160	J844TYBSIZE 3/8 (81343)	105.5	268.0
12414690-161	J844TYBSIZE 3/8 (81343)	48.0	122.0
12414690-162	J844TYBSIZE 3/8 (81343)	36.0	91.5
12414690-163	J844TYBSIZE 3/8 (81343)	161.5	410.2
12414690-164	J844TYBSIZE 3/8 (81343)	120.0	304.8
12414690-165	J844TYBSIZE 3/8 (81343)	78.0	198.1
12414690-166	J844TYBSIZE 3/8 (81343)	108.0	274.3
12414690-167	J844TYBSIZE 3/8 (81343)	168.0	426.7
12414690-168	J844TYBSIZE 3/8 (81343)	108.0	274.3
12414690-169	J844TYBSIZE 3/8 (81343)	72.0	182.9
12414690-201	C608-100BLK (13174)	14.8	37.5
12414690-202	C608-100BLK (13174)	14.1	35.7
12414690-203	C608-100BLK (13174)	6.5	16.5
12414690-205	C608-100BLK (13174)	14.5	36.8
12414690-206	C608-100BLK (13174)	14.8	37.7
12414690-207	C608-100BLK (13174)	15.6	39.5
12414690-208	C608-100BLK (13174)	6.7	17.0
12414690-209	C608-100BLK (13174)	19.5	49.5
12414690-210	C608-100BLK (13174)	15.5	39.3
12414690-211	C608-100BLK (13174)	8.0	20.3
12414690-212	C608-100BLK (13174)	17.0	43.0
12414690-215	C608-100BLK (13174)	163.0	414.0
12414690-216	C608-100BLK (13174)	160.0	406.4
12414690-217	C608-100BLK (13174)	62.6	159.0

E-12. PNEUMATIC TUBES FABRICATION (CONT)

Table E-1. Pneumatic Tube Lengths (Cont)

Tube Part Number	Bulk Tubing Part Number	Cut Length	
		inches	cm
12414690-218	C608-100BLK (13174)	119.8	304.2
12414690-219	C608-100BLK (13174)	69.0	175.3
12414690-220	C608-100BLK (13174)	45.5	115.6
12414690-221	C608-100BLK (13174)	12.6	32.0
12414690-222	C608-100BLK (13174)	5.5	14.0
12414690-223	C608-100BLK (13174)	14.6	37.1
12414690-224	C608-100BLK (13174)	170.0	431.8
12414690-225	C608-100BLK (13174)	174.0	442.0
12414690-228	C608-100BLK (13174)	3.5	8.9
12414690-229	C608-100BLK (13174)	62.2	158.1
12414690-230	C608-100BLK (13174)	14.6	37.0
12414690-231	C608-100BLK (13174)	60.5	153.7
12414690-232	C608-100BLK (13174)	126.4	321.0
12414690-233	C608-100BLK (13174)	142.1	361.0
12414690-234	C608-100BLK (13174)		
12414690-235	C608-100BLK (13174)		
12414690-236	C608-100BLK (13174)	131.9	335.0
12414690-237	C608-100BLK (13174)	147.6	375.0
12414690-238	C608-100BLK (13174)	179.5	456.0
12414690-239	C608-100BLK (13174)	187.0	475.0
12414690-240	C608-100BLK (13174)	111.5	283.2
12414690-241	C608-100BLK (13174)	127.5	324.0
12414690-242	C608-100BLK (13174)	159.0	404.0
12414690-243	C608-100BLK (13174)	166.5	423.0
12414690-244	C608-100BLK (13174)	41.0	104.2
12414690-245	C608-100BLK (13174)	57.0	144.8
12414690-246	C608-100BLK (13174)	88.6	225.0
12414690-247	C608-100BLK (13174)	96.0	244.0
12414690-248	C608-100BLK (13174)	48.0	122.0
12414690-249	C608-100BLK (13174)	54.0	137.2
12414690-301	PFT-10B-BLK-100 (61424)	19.0	48.3
12414690-302	PFT-10B-BLK-100 (61424)	56.0	142.2
12414690-303	PFT-10B-BLK-100 (61424)	118.1	300.0

E-13. NON-METALLIC ELECTRICAL CABLE CONDUIT FABRICATION
--

Make conduit to cover electrical cables described on 1241638 from bulk tube stock listed in **Table E-2. Non-Metallic Electrical Cable Conduit Lengths**. Use a fine-toothed hacksaw or suitable cutting device and cut hose/tube to required length.

Table E-2. Non-Metallic Electrical Cable Conduit Lengths

Tube Part Number	Bulk Tube Part Number	Cut Length	
		inch	cm
12416381P1	49008	8.9	22.6
12416381P10	49008	17.8	45.2
12416381P11	49008	29.9	75.9
12416381P12	49008	33.0	83.8
12416381P13	49008	13.9	35.3
12416381P14	49008	4.0	10.2
12416381P15	49008	17.4	44.2
12416381P16	49008	3.2	8.1
12416381P17	49008	4.5	11.4
12416381P2	49008	16.2	41.1
12416381P20	27413	32.8	83.3
12416381P21	27413	9.2	23.4
12416381P22	27413	8.0	20.3
12416381P23	27413	23.3	59.2
12416381P26	49008	2.5	6.4
12416381P3	27413	7.3	18.5
12416381P30	49007	17.0	43.2
12416381P32	49005	1.7	4.3
12416381P34	49005	20.7	52.6
12416381P35	49005	21.8	55.4
12416381P36	49005	5.5	14.0
12416381P37	49005	8.0	20.3
12416381P38	49008	3.7	9.4
12416381P4	49008	12.0	30.5
12416381P5	49008	26.0	66.0
12416381P6	49008	7.7	19.6
12416381P7	49008	26.7	67.8
12416381P8	49008	5.2	13.2
12416381P9	49008	16.8	42.7

E-14. STEERING GEAR RETURN HOSE AND TRANSMISSION OIL COOLER HOSES FABRICATION


Cut the following hoses from bulk hose using a fine-toothed hacksaw or suitable cutting device.

Hose Part Number	Bulk Hose Part Number	Cut Length	
		inches	cm
12418037	A110 (30327)	75.5	191.7
12418460-001	MS521302B110360 (96906)	17.5	44.4
12418460-002	MS521301A206R (96906)	16.0	40.6

E-15. LANYARD ASSEMBLIES P/N 12418763 AND 12420196 FABRICATION

Make the following lanyard assemblies from bulk cable material, sleeves, and tab material and assemble according to **Figure E-14. Lanyard Assembly**. The following parts list identifies part numbers and lengths of cut pieces.

Item	Part Number	Material Description	Size	Qty
1	MIL-W-83420 Type 1, Comp B	1/16 in. stranded wire cable	4 in. (102 mm)	1
2	MS51844-22	Sleeve		2
3	N/A	Tab, Stainless Steel ASTM A617	.06 in. (16 cm) X .37 in. (9.5 mm) X 1.25 in. (32 mm)	1



XAPPE131

Figure E-14. Lanyard Assembly

- All dimensions are in inches (millimeters).
- Make from bulk cable and flat steel material as identified in parts list.
- Drill two 0.19 in. (4.8 mm) diameter holes through tab material as shown on **Figure E-14. Lanyard Assembly**.
- De-burr and remove sharp edges.
- Bend tab as shown on **Figure E-14. Lanyard Assembly**.
- Form loops on cable ends and insert sleeve material over cable on one end of cable and over cable and through sleeve at other end of cable as shown in **Figure E-14. Lanyard Assembly**.
- Crimp two sleeves over cable ends.

E-16. NON-METALLIC VENT AIR HOSES FABRICATION

Cut the following vent air hoses from bulk hose using a fine-toothed hacksaw or suitable cutting device.

Hose Part Number	Bulk Hose Part Number	Cut Length	
		inches	cm
12420197-001	483666 (02280)	180.0	457.2
12420197-002	483666 (02280)	120.0	304.8
12420197-003	483666 (02280)	96.0	243.8
12420197-004	483666 (02280)	36.0	91.4
12420197-005	483666 (02280)	156.0	396.2
12420197-006	483666 (02280)	72.0	182.9
12420198-001	881-16 (98441)	120.0	304.8
12420198-002	11657469	36.0	91.4

E-17. PERSONNEL HEATER AIR DUCT HOSE FABRICATION

Cut the following hoses from bulk hose using a fine-toothed hacksaw or suitable cutting device.

Hose Part Number	Bulk Hose Part Number	Cut Length	
		inches	cm
12420308-457	8711054 (19207)	18.3	46.4
12420308-760	8711054 (19207)	30.4	77.2

E-18. BLOCK SEAL 12420489 FABRICATION

Make block seal from P/N (0VXY8) STN2.38X.5. Use a suitable cutting tool to cut seal to 0.52 inch (1.3 cm) long.

E-19. CTIS SEAL DRIVER 3256-H-1048

Used on Front, Intermediate, and Rear Axle CTIS Seals.

NOTES ON USE OF DRIVER

- 1) SEAL END OF DRIVER TO BE CLEAN OF DEBRIS, DIRT, NICKS AND BURRS
- 2) DO NOT USE A METAL HAMMER ON DRIVER
A RUBBER, PLASTIC, WOOD OR SOME OTHER DEAD BLOW TYPE Mallet IS TO BE USED
- 3) SLIGHTLY GREASE SEAL END OF DRIVER PRIOR TO INSTALLING SEAL




Figure E-15. CTIS Seal Driver

- a. All dimensions are in inches (millimeters).
- b. Manufacture from round steel stock.
- c. De-burr and remove sharp edges.

E-20. WHEEL HUB GREASE SEAL DRIVER 3256-K-1051

NOTES ON USE OF DRIVER

- 1) SEAL END OF DRIVER TO BE CLEAN OF DEBRIS, DIRT, NICKS AND BURRS
- 2) DO NOT USE A METAL HAMMER ON DRIVER
A RUBBER, PLASTIC, WOOD OR SOME OTHER DEAD BLOW TYPE Mallet IS TO BE USED
- 3) SLIGHTLY GREASE SEAL END OF DRIVER PRIOR TO INSTALLING SEAL




Figure E-16. Wheel Hub Grease Seal Driver

- a. All dimensions are in inches (millimeters).
- b. Manufacture from round steel stock.
- c. De-burr and remove sharp edges.

E-21. DIMMER SWITCH TEST WIRE

Fabricate the dimmer switch test wire according to the following steps. Refer to the following parts list for materials.


Material Description	National Stock Number	Quantity	Cut Length
Wire, Electrical (M168678/14BKE9)	6145-01-229-4134	1	12 in (305 mm)
Pin, Grooved, Headless (12258939-1)	5315-01-156-6314	1	
Contact, Electrical (12258939-2)	5999-01-150-8808	1	

- a. Dimensions are in inches (millimeters).
- b. Cut a length of electrical wire approximately 12 in. (305 mm) long.
- c. Remove approximately 1/4 in. (6 mm) of insulation from each end of electrical wire.
- d. Crimp headless grooved pin on one end of electrical wire.
- e. Crimp electrical contact on opposite end of electrical wire.

E-22. PURGE VALVE TOOL

Fabricate Purge Valve Tool according to the following instructions. Refer to Figure E-17. Purge Valve Tool for details.

Item	Part Number	Material Description	Size	Qty
1	N/A	Steel, ASTM A 108 or A576 Grade 1015-1025, BAR (Ref UNS G10150-G10250). Finish Black Oxide Coat, Class I, IAW MIL-C-13924.	14.0 in. (356 mm)	1



Xappe17b

Figure E-17. Purge Valve Tool

- All dimensions are in inches (cm).
- Cut steel bar (1) and bend to shape as shown in Figure E-17.
- Dimensional limits apply after coating.
- All edges shall be broken and free from burrs.
- Metal Stamp, electro etch, or engrave with the following marking IAW MIL-STD-130: 19207-12379968 MFR-19207.

E-23. M1089 30K WINCH AIR HOSES
--

Cut air hoses and convoluted tubing from bulk hose stock listed in Table E-3. M1089 30K Winch Air Hose Lengths and Fittings. Use a fine-toothed hacksaw or suitable cutting device and cut air hoses and convoluted tubing to required length.

Table E-3. M1089 30K Air Hose Lengths and Fittings

Hose Name	Bulk Hose P/N	Hose Cut Length		Bulk Convoluted Tubing P/N	Convoluted Tubing Cut Length		Fittings P/N	Fittings Qty.
		in.	mm		in.	mm		
Air Supply	NB-4-035	96.0	2438	12420924-001	94.0	2388	4-100110B 4-100115B 63NTA-4	2 2 2
Manifold Supply	NB-4-035	40.0	1016	12420924-001	38.0	965	4-100110B 4-100115B 63NTA-4	2 2 2
LH freespool	NB-4-035	66.0	1676	12420924-001	64.0	1626	4-100110B 4-100115B 63NTA-4	2 2 2
RH freespool	NB-4-035	48.0	1219	12420924-001	46.0	1168	4-100110B 4-100115B 63NTA-4	2 2 2
LH regulator input	NB-4-035	12.0	305	N/A	N/A	N/A	4-100110B 4-100115B 63NTA-4	2 2 2
RH regulator input	NB-4-035	12.0	305	N/A	N/A	N/A	4-100110B 4-100115B 63NTA-4	2 2 2
LH check valve return	NB-4-035	3.0	76	N/A	N/A	N/A	4-100110B 4-100115B 63NTA-4	2 2 2
RH check valve return	NB-4-035	3.0	76	N/A	N/A	N/A	4-100110B 4-100115B 63NTA-4	2 2 2
Front LH tension supply	NB-4-035	48.0	1219	12420924-001	46.0	1168	4-100110B 4-100115B 63NTA-4	2 2 2
Front RH tension supply	NB-4-035	66.0	1676	12420924-001	64.0	1626	4-100110B 4-100115B 63NTA-4	2 2 2


Table E-3. M1089 30K Air Hose Lengths and Fittings (Cont)

Hose Name	Bulk Hose P/N	Hose Cut Length		Bulk Convoluted Tubing P/N	Convoluted Tubing Cut Length		Fittings P/N	Fittings Qty.
		in.	mm		in.	mm		
RH 30K winch supply	NB-2-016	40.0	1016	N/A	N/A	N/A	2-2 100102BA 2-2 100202BA	1 1
RH 30K winch return	NB-2-016	40.0	1016	N/A	N/A	N/A	2-2 100102BA	2
Underlift fold supply	NB-2-016	40.0	1016	N/A	N/A	N/A	2-2 100102BA	1
Underlift fold return	NB-2-016	40.0	1016	N/A	N/A	N/A	2-2 100102BA 2-2 100202BA	1 1
Underlift supply	NB-2-016	40.0	1016	N/A	N/A	N/A	2-2 100102BA	2
Underlift return	NB-2-016	40.0	1016	N/A	N/A	N/A	2-2 100102BA 2-2 100202BA	1 1
Stinger supply	NB-2-016	40.0	1016	N/A	N/A	N/A	2-2 100102BA	2
Stinger Return	NB-2-016	40.0	1016	N/A	N/A	N/A	2-2 100102BA 2-2 100202BA	1 1
LH 30K Winch supply	NB-2-016	40.0	1016	N/A	N/A	N/A	2-2 100102BA 2-2 100202BA	1 1
LH 30K winch return	NB-2-016	40.0	1016	N/A	N/A	N/A	2-2 100102BA	2

E-24. M1089 30K WINCH PNEUMATIC TEST ADAPTER

Assembly the M1089 30K winch pneumatic test adapter to the following steps. Refer to the following parts list and **Figure E-18. M1089 30K Winch Pneumatic Test Adapter** for details.

Part Number	Material Description	National Stock Number	Qty.
NB-4-035	Tubing, Nonmetallic	4720-01-071-4042	14 in. (355.6 mm)
MIL-T-27730	Tape, antiseizing	8030-00-889-3534	1 roll
207P-4	Coupling, Pipe	4730-00-881-1161	1
4-6 100102 BA	Adapter, Straight, Pipe to Tube	4730-01-096-9398	1
4-4 100101 BA	Nipple, Tube	4730-01-091-4012	1



Xappe18b

Figure E-18. M1089 30K Winch Pneumatic Test Adapter

- All dimensions are in inches (millimeter).
- Cut piece of nonmetallic tubing (1) to 14.0 in. (355.6 mm).
- Remove two nuts (2), ferrules (3), and sleeves (4) from tube nipple (5).
- Install nut (2), ferrule (3), and sleeve (4) on nonmetallic tubing (1).
- Install nonmetallic tubing (1) on tube nipple (5).
- Remove nut (6), ferrule (7), and sleeve (8) from straight adapter (9).
- Install nut (6), ferrule (7), and sleeve (8) on nonmetallic tubing (1).
- Install nonmetallic tubing (1) on straight adapter (9).
- Apply on wrap of antiseizing tape to threads of straight adapter (9).
- Install pipe coupling (10) on straight adapter (9).
- Retain nut (2), ferrule (3), and sleeve (4) for future use.

APPENDIX F TORQUE LIMITS

F-1. GENERAL


This appendix provides general torque limits for screws and nuts used on the vehicle. Special torque limits are shown in the maintenance procedures for applicable components. Use the general torque limit given in this appendix when specific torque limits are not given in the maintenance procedure. These general torque limits can not be applied to screws that retain rubber components. The rubber components will be damaged before the torque limit is reached. If a special torque limit is not given in the maintenance instructions for a fastener which retains a rubber component, tighten the screw or nut until it touches metal, then tighten one more turn. Whenever possible, the tightening force (torque) should be applied to the nut side of the fastener group.

F-2. TORQUE LIMITS

Refer to [Table F-1. Torque Limits for SAE and ANSI Fasteners](#) for torque limits on standard (SAE and ANSI) screws and free spinning nuts. Refer to [Table F-2. Torque Limits for SAE and ANSI Prevailing Torque Nuts](#) for torque limits on standard (SAE and ANSI) self-locking nuts. Refer to [Table F-3. Torque Limits for Metric Screws and Free Spinning Nuts](#) for torque limits on metric screws and free spinning nuts. Refer to [Table F-4. Torque Limits for Metric Prevailing Torque Nuts](#) for torque limits on metric self-locking nuts.

F-3. USE OF TORQUE TABLES

- (1) Measure the diameter of the screw to be installed.
- (2) Count the number of threads per inch.
- (3) Under the heading DIAMETER look down the column until the diameter of the screw is found. (There are usually two lines beginning with the same diameter.)
- (4) Under the heading THREADS PER INCH (SAE and ANSI) or THREAD PITCH (metric), find the number of threads per inch that matches the number counted in step (2).
- (5) To find the grade of the screw, match the markings on the head to the correct picture under CAPSCREW HEAD MARKINGS on the torque table.
- (6) Look down the column under the picture found in step (5) until the torque limit (lb-ft or N·m) for the diameter and threads per inch (or thread pitch, in the case of metric fasteners) of the screw are located.



XAPPF01A

APPENDIX F TORQUE LIMITS

Table F-1. Dry Torque Limits for SAE and ANSI Screws and Free Spinning Nuts









 <p style="text-align: center; font-size: small;">XAPPF02A</p> <p style="text-align: center;">NOTE Manufacturer's marks may vary. These are all SAE Grade 5.</p>		Material Grade Markings					
		 <p style="text-align: center; font-size: small;">XAPPF03A</p> <p style="text-align: center;">SAE Grade 2</p>		 <p style="text-align: center; font-size: small;">XAPPF04A</p> <p style="text-align: center;">SAE Grade 5</p>		 <p style="text-align: center; font-size: small;">XAPPF051</p> <p style="text-align: center;">SAE Grade 8</p>	
		Torque					
Diameter	Threads per inch						
inch		lb-ft	N·m	lb-ft	N·m	lb-ft	N·m
1/4	20	3-5	5-7	5-7	8-10	8-10	10-14
1/4	28	4-6	5-7	6-8	9-11	8-12	12-16
1/4	32	4-6	5-7	7-9	9-11	9-13	12-16
5/16	18	7-9	9-13	11-15	15-21	15-21	21-29
5/16	24	8-10	11-15	12-16	17-23	17-23	24-32
5/16	32	9-11	12-16	14-18	18-24	19-25	27-34
3/8	16	13-17	17-23	20-26	27-35	28-38	38-50
3/8	24	15-19	20-26	22-30	31-41	32-42	43-57
3/8	32	15-21	21-27	24-32	33-43	33-45	55-61
7/16	14	20-28	28-38	32-42	43-57	44-60	61-81
7/16	20	23-31	31-41	35-47	48-64	49-67	68-90
7/16	28	25-33	33-45	37-51	51-69	54-72	73-97
1/2	13	32-42	43-57	49-65	66-88	68-92	93-123
1/2	20	35-47	48-64	55-73	74-98	77-103	105-139
1/2	28	38-50	51-67	58-78	79-105	82-110	111-149
9/16	12	55-61	62-82	70-94	95-127	98-132	134-178
9/16	18	50-68	69-91	78-104	105-141	109-147	149-199
9/16	24	53-71	72-96	82-110	111-149	115-155	158-210
5/8	11	62-84	85-113	95-129	131-175	136-182	184-246
5/8	18	70-94	96-128	108-146	148-198	154-206	209-279
5/8	24	73-99	100-134	114-154	155-207	161-217	219-293

Table F-1. Dry Torque Limits for SAE and ANSI Screws and Free Spinning Nuts (Cont)

 Manufacturer's marks may vary. These are all SAE Grade 5		Material Grade Markings					
		 SAE Grade 2	 SAE Grade 5	 SAE Grade 8	Torque		
Diameter	Threads per inch	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m
inch							
11/16	24	99-133	135-181	153-207	209-279	217-291	296-394
3/4	10	110-148	150-200	171-229	232-310	240-324	328-438
3/4	16	123-165	168-224	190-256	259-345	269-361	366-488
3/4	20	127-171	174-232	197-265	268-358	278-374	379-505
13/16	20			252-340	345-459	357-481	487-649
7/8	9			275-369	374-498	387-521	528-704
7/8	14			303-407	413-551	427-575	583-777
7/8	20			319-429	435-579	450-606	614-818
15/16	20			395-531	538-718	558-750	760-1014
1	8			411-553	560-748	581-781	792-1056
1	12			450-606	614-818	636-856	867-1155
1	20			483-649	658-878	681-917	929-1239
1-1/16	18			576-776	782-1044	813-1095	1109-1479
1-1/8	7			507-683	693-923	824-1108	1123-1497
1-1/8	12			570-766	776-1034	923-1241	1258-1678
1-1/8	18			600-806	817-1089	971-1307	1324-1766
1-3/16	18			709-953	966-1288	1149-1545	1566-2088
1-1/4	7			716-964	976-1302	1161-1563	1584-2112
1-1/4	12			793-1067	1081-1441	1286-1730	1754-2338
1-1/4	18			831-1117	1132-1510	1346-1812	1835-2447
1-5/16	18			965-1299	1316-1754	1565-2105	2134-2846
1-3/8	6			939-1263	1281-1707	1523-2049	2076-2768

APPENDIX F TORQUE LIMITS

Table F-2. Dry Torque Limits for SAE and ANSI Prevailing Torque Nuts







		Material Grade Markings				
		 XAPPF061 SAE Grade 5				 XAPPF071 SAE Grade 8
Hole Diameter	Threads per inch	Torque				
		lb-ft	N-m	lb-ft	N-m	
inch						
1/4	20	10-12	14-16	15-17	20-24	
1/4	28	12-14	16-18	14-18	21-25	
5/16	18	20-24	27-33	26-32	36-44	
5/16	24	22-26	30-36	29-35	40-48	
3/8	16	35-41	47-55	48-58	65-77	
3/8	24	38-46	53-63	53-63	72-86	
7/16	14	55-65	74-88	75-91	103-123	
7/16	20	60-70	81-97	80-98	110-132	
1/2	13	86-102	116-138	113-137	154-184	
1/2	20	92-110	125-149	127-153	177-207	
9/16	12	120-144	162-194	168-202	229-273	
9/16	18	135-161	183-219	179-217	244-294	
5/8	11	165-199	226-270	226-272	306-368	
5/8	18	181-219	246-296	244-296	331-401	
3/4	10	296-354	402-480	395-479	538-648	
3/4	16	310-376	422-508	424-516	576-698	
7/8	9	460-554	625-749	612-746	833-1009	
7/8	14	503-607	684-822	652-800	888-1082	
1	8	686-828	933-1121	941-1141	1280-1544	

Table F-3. Dry Torque Limits for Metric Screws and Free Spinning Nuts

		Material Grade Markings							
		 XAPPF081 Metric Grade 4.8	 XAPPF091 Metric Grade 8.8	 XAPPF101 Metric Grade 10.9	 XAPPF111 Metric Grade 12.9				
Diameter	Thread Pitch	Torque							
		lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m
6	1	3	4-5	5-7	7-9	7-9	10-13	8-11	11-15
8	1.25	7-9	9-11	13-17	17-23	17-23	23-31	21-27	27-37
8	1	7-9	9-13	14-18	18-24	19-25	25-33	21-29	29-39
10	1.5	13-17	17-23	25-33	33-45	34-46	46-62	40-54	54-72
10	1.25	14-18	18-24	26-34	35-47	36-48	49-65	42-56	57-77
10	0.75	15-19	21-27	29-39	39-53	40-54	54-72	47-63	63-85
12	1.75	22-30	30-40	43-57	58-78	60-80	81-107	69-93	94-126
12	1.5	23-31	32-42	46-60	61-81	63-83	85-113	73-97	99-131
12	1.25	24-32	33-45	47-63	65-85	65-87	88-118	76-102	104-138
12	1	26-34	34-46	49-65	67-89	68-90	93-123	80-106	108-144
14	2	36-48	48-74	69-91	93-125	95-127	129-173	112-148	151-201
14	1.5	39-51	52-70	75-99	99-135	103-137	140-186	120-160	163-217
15	1	51-69	69-93	100-132	135-179	137-183	187-249	160-214	218-290
16	2	55-73	75-99	107-143	145-193	148-198	201-267	173-231	235-313
16	1.5	59-79	80-106	114-152	155-207	158-210	214-286	184-246	250-334
18	1.5			166-222	225-301	230-306	311-415	268-358	364-486
20	2.5			209-279	283-377	289-385	392-522	338-450	458-610
20	1.5			232-308	315-419	321-427	435-579	375-499	508-678
20	1			244-324	330-440	337-449	457-609	394-524	534-712
22	2.5			285-379	387-515	394-524	534-712	461-613	624-832
22	1.5			313-417	424-566	432-576	586-782	664-884	900-1200
24	3			361-481	489-653	499-665	677-903	584-778	791-1055
24	2			394-524	534-712	545-725	738-984	725-965	982-1310
25	1.5			467-621	633-843	645-859	875-1167	754-1004	1023-1363

APPENDIX F TORQUE LIMITS

Table F-4. Dry Torque Limits for Metric Prevailing Torque Nuts













		Material Grade Markings							
		 XAPPF121 Metric Grade 4.8	 XAPPF131 Metric Grade 8.8	 XAPPF141 Metric Grade 10.9			 XAPPF151 Metric Grade 12.9		
Diameter	Thread Pitch	Torque							
		lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m
6	1	5-6	7-8	7-9	10-12	10-12	14-17	11-14	15-19
8	1.25	12-14	16-18	18-22	24-30	24-30	32-40	27-33	36-46
8	1	12-14	16-20	19-23	25-31	25-31	34-42	28-36	38-48
10	1.5	21-25	28-34	33-41	44-56	44-56	60-76	50-64	68-86
10	1.25	21-25	29-35	34-42	46-58	46-58	63-79	53-67	71-91
10	0.75	23-27	31-37	37-47	49-63	50-64	68-86	57-73	77-99
12	1.75	33-41	46-56	55-69	74-94	75-95	102-128	85-109	115-147
12	1.5	35-43	47-57	56-72	77-97	78-98	106-134	89-113	120-152
12	1.25	36-44	48-60	58-74	79-101	81-103	109-139	91-117	125-159
12	1	37-45	50-62	61-77	82-104	84-106	114-144	95-121	129-165
14	2	53-65	72-88	87-109	117-149	118-150	160-204	134-172	182-232
14	1.5	57-69	76-94	92-116	125-159	126-160	171-217	143-183	194-248
16	2	79-97	107-131	130-166	177-225	178-228	243-309	204-262	277-355
16	1.5	82-102	112-138	138-176	187-239	189-241	256-328	215-277	292-376
18	1.5			197-253	267-343	271-347	367-471	309-399	420-542
20	2.5			248-318	337-431	342-438	464-594	391-503	530-682
20	1.5			271-349	369-473	374-480	507-651	428-552	580-750
20	1			283-365	384-494	390-502	529-681	447-577	606-784
22	2.5			335-429	455-583	460-592	624-802	526-680	714-922
22	1.5			363-467	492-634	499-643	676-872	730-950	990-1290
24	3			420-540	569-733	577-743	783-1009	662-856	897-1161
24	2			453-583	614-792	622-804	844-1090	803-1043	1088-1416

Table F-5. Wet Torque Limits for SAE and ANSI Screws and Free Spinning Nuts

 <p>NOTE Manufacturer's marks may vary. These are all SAE Grade 5.</p>		Material Grade Markings					
		 XAPPF03A SAE Grade 2	 XAPPF04A SAE Grade 5	 XAPPF051 SAE Grade 8	Torque		
Diameter	Threads per inch	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m
inch							
1/4	20	4	6	6	8	9	12
1/4	28	5	7	7	9	10	14
5/16	18	8	11	13	18	18	24
5/16	24	9	12	14	19	20	27
3/8	16	15	20	23	31	35	47
3/8	24	17	23	25	34	35	47
7/16	14	24	33	35	47	55	75
7/16	20	25	34	40	54	60	81
1/2	13	35	47	55	75	80	108
1/2	20	40	54	65	88	90	122
9/16	12	50	68	80	108	110	149
9/16	18	55	75	90	122	130	176
5/8	11	70	95	110	149	170	231
5/8	18	80	108	130	176	180	244
3/4	10	120	163	200	271	280	380
3/4	16	140	190	220	298	320	434
7/8	9	110	149	300	407	460	624
7/8	14	120	163	320	434	500	678
1	8	160	217	440	597	680	922
1	12	170	231	480	651	740	1003
1-1/8	7	220	298	600	814	960	1302
1-1/8	12	260	353	660	895	1080	1464

APPENDIX F TORQUE LIMITS

Table F-5. Wet Torque Limits for SAE and ANSI Screws and Free Spinning Nuts (Cont)

 <p style="text-align: center; font-size: small;">XAPPF02A</p> <p style="text-align: center; font-size: small;">Manufacturer's marks may vary. These are all SAE Grade 5</p>		Material Grade Markings					
		 <p style="text-align: center; font-size: small;">XAPPF03A</p> <p style="text-align: center;">SAE Grade 2</p>		 <p style="text-align: center; font-size: small;">XAPPF04A</p> <p style="text-align: center;">SAE Grade 5</p>		 <p style="text-align: center; font-size: small;">XAPPF051</p> <p style="text-align: center;">SAE Grade 8</p>	
		Torque					
Diameter	Threads per inch						
inch		lb-ft	N·m	lb-ft	N·m	lb-ft	N·m
1-1/4	7	320	434	840	1139	1360	1844
1-1/4	12	360	488	920	1248	1500	2034
1-3/8	6	420	570	1100	1492	1780	2414
1-3/8	12	460	624	1260	1709	2040	2766

APPENDIX G MANDATORY REPLACEMENT PARTS

Section I. INTRODUCTION

G-1. SCOPE

This appendix lists mandatory replacement parts you will need to maintain the MTV vehicle.

G-2. EXPLANATION OF COLUMNS

- a. Column (1) - Item Number.** This number is assigned to each entry in the listing and is referenced in the Initial Setup of the applicable task under Materials/Parts.
- b. Column (2) - Nomenclature.** Name or identification of the part.
- c. Column (3) - Part Number.** The manufacturer's part number.
- d. Column (4) - National Stock Number.** The National stock number of the part.

Section II. MANDATORY REPLACEMENT PARTS LIST

(1) ITEM NO.	(2) NOMENCLATURE	(3) PART NUMBER	(4) NATIONAL STOCK NUMBER
1	BLADE, WINDSHIELD WIPER	105.384	2540-01-364-1621
2	BOLT, MACHINE	12414307-065	5306-01-382-5054
3	BOOT KIT, EXHAUST	DQ6025	4730-01-417-3197
4	BUMPER, NONMETALLIC	1011-05	5340-01-342-1110
5	BUMPER, RUBBER	12419182	5340-01-410-8397
6	BUSHING, SLEEVE	7-199-002668	3120-01-367-6894
7	CHANNEL, RUBBER	ZZR765/2-001A7	9390-01-420-4560
8	CLAMP	12421183-005	4730-01-447-4312
9	CLAMP	12411183-006	4730-01-447-4313
9.1	CLAMP, WIRE ROPE, SADDLED	MS51868-56	4030-00-042-7882
10	COVER, FLUID FILTER	12412628	2590-01-414-1243
11	DECAL	12340917	7690-01-256-4909
12	FASTENER TAPE	MIL-F-21840	8315-00-006-9855
13	FASTENER TAPE	50-534718-19	8315-00-935-6762
14	FILTER ASSEMBLY	75223-11	2940-01-417-9333

Section II. MANDATORY REPLACEMENT PARTS LIST (CONT)

(1) ITEM NO.	(2) NOMENCLATURE	(3) PART NUMBER	(4) NATIONAL STOCK NUMBER
15	FILTER ELEMENT	1048011	2940-01-385-8931
16	FILTER ELEMENT, FLUID	K05-0104	2910-01-377-3128
17	FILTER ELEMENT, FLUID	R22146	2910-01-360-6366
17.1	FILTER ELEMENT, FLUID	ST117073098-000	2910-01-467-4594
18	FILTER ELEMENT, FLUID	29507750	2940-01-361-2405
19	FILTER ELEMENT, FLUID	599791	4460-01-284-2344
20	FILTER ELEMENT, FLUID	931558	2940-01-363-4377
21	FILTER ELEMENT, INTAKE AIR CLEANER	P52-7750	2940-01-361-2407
22	FILTER, FUEL	7E9763	2910-01-363-3089
23	FILTER, OIL	1R0739	2940-00-029-0388
24	GASKET	F337576M6	
25	GASKET	M28840/24HA	5935-01-421-9754
26	GASKET	QS-1181	5330-01-058-3788
27	GASKET	10-36675-18	5330-00-298-0190
27.1	GASKET	11446	5330-00-247-4174
28	GASKET	119-2940	5330-01-424-7905
29	GASKET	12412394	5330-01-371-6199
29.1	GASKET	12421155	5330-01-295-0115
29.2	GASKET	12421469	5330-01-453-2980
29.3	GASKET	3N4087	5330-01-061-8003
30	GASKET	350700	5330-01-295-3053
31	GASKET	350903	5330-00-576-4626
32	GASKET	352200	5330-01-421-6105
33	GASKET	352302	5330-01-421-6107
34	GASKET	353400	5330-01-421-6102
35	GASKET	353806	5330-01-421-6103
36	GASKET	353810	5330-01-450-6666
37	GASKET	355148	5330-01-423-0596
38	GASKET	355175	5330-01-423-0623
39	GASKET	3K3257	5330-01-305-6550
40	GASKET	4P1624	5330-01-360-5934

Section II. MANDATORY REPLACEMENT PARTS LIST (CONT)

(1) ITEM NO.	(2) NOMENCLATURE	(3) PART NUMBER	(4) NATIONAL STOCK NUMBER
41	GASKET	4W0549	5330-01-347-3207
42	GASKET	9Y8103	5330-01-360-5931
43	GASKET and PREFORMED PACKING KIT	P4-4	5330-00-122-0624
43.1	GASKET and PREFORMED PACKING SET	9X8318	5330-01-360-9098
44	GASKET, FUEL FILTER	7C1159	5330-01-360-5941
45	NOT USED		
46	GASKET, THERMOSTAT	2W7212	5330-01-347-3206
47	GROMMET, NONMETALLIC	MS21266-3N	5325-00-926-1394
48	GROMMET, NONMETALLIC	MS35489-109	5325-00-290-0074
49	GROMMET, NONMETALLIC	MS35489-6	5325-00-263-6632
50	GROMMET, NONMETALLIC	12412334-2	9320-01-456-1672
51	GROMMET, NONMETALLIC	12417598	5325-01-375-1299
52	GROMMET, NONMETALLIC	12421402	5325-01-440-2178
53	GROMMET, NONMETALLIC	4082-37634-01	5325-01-194-3076
54	GROMMET, NONMETALLIC	50S12-1-1AA	5325-01-145-0105
55	GROMMET, NONMETALLIC	8741442	5325-00-088-6147
55.1	HEAD, FLUID FILTER	7632-002-144	2940-01-387-4397
56	INDICATOR, SIGHT, LIQUID	SLT-1214	6680-01-356-8162
57	INSERT, NYLON	12SWS2520	5310-01-439-8881
58	INSERT, NYLON	12SWS2542	5310-01-439-8883
59	INSERT, NYLON	12421463-003	5310-01-453-2087
60	INSULATOR, TANK	A1394J	5970-01-385-7317
61	INSULATOR, TANK	A1394K	5970-01-385-7262
62	NOT USED		
63	KIT, FILTER	29526899	5330-01-453-0770
64	KIT, FILTER	29503829	
65	LAMP, INCANDESCENT	CM7-7373	6240-00-270-6824
66	LAMP, INCANDESCENT	CM7376	6240-00-499-6278
67	LATCH, BAIL HEAD	68-20-101-10	2540-01-232-2470
68	LOCKNUT	0770-023-003	5310-01-423-3725
69	LOCKWASHER	ABCH207-LW-1/2	
70	LOCKWASHER	ABCH207-LW-3/8	

Section II. MANDATORY REPLACEMENT PARTS LIST (CONT)

(1) ITEM NO.	(2) NOMENCLATURE	(3) PART NUMBER	(4) NATIONAL STOCK NUMBER
71	LOCKWASHER	D70336/1-20	5310-01-110-7933
72	LOCKWASHER	D70336/3-50	5310-01-439-2542
73	LOCKWASHER	D70336/3-52	5310-01-439-2543
73.1	LOCKWASHER	ERNA245	5310-00-584-5272
74	LOCKWASHER	MS35333-136	5310-01-078-9699
75	LOCKWASHER	MS35333-78	5310-00-261-7156
76	LOCKWASHER	MS35335-30	5310-00-209-0788
77	LOCKWASHER	MS35335-31	5310-00-596-7693
78	LOCKWASHER	MS35335-33	5310-00-209-0786
79	LOCKWASHER	MS35335-36	5310-00-550-3503
80	LOCKWASHER	MS35335-37	5310-00-209-5116
81	LOCKWASHER	MS35335-38	5310-00-616-6354
82	LOCKWASHER	MS35335-58	5310-00-209-1366
83	LOCKWASHER	MS35335-61	5310-00-527-3634
84	LOCKWASHER	MS35335-62	5310-00-184-9562
85	LOCKWASHER	MS35337-25	5310-00-012-1637
86	LOCKWASHER	MS35338-100	5310-00-261-8278
87	LOCKWASHER	MS35338-103	5310-00-184-8971
88	LOCKWASHER	MS35338-137	5310-00-933-8119
89	LOCKWASHER	MS35338-138	5310-00-933-8120
90	LOCKWASHER	MS35338-141	5310-00-984-7042
90.1	LOCKWASHER	MS35338-147	5310-00-926-5871
91	LOCKWASHER	MS35338-41	5310-00-045-4007
92	LOCKWASHER	MS35338-42	5310-00-045-3299
93	LOCKWASHER	MS35338-43	5310-00-045-3296
94	LOCKWASHER	MS35338-44	5310-00-582-5965
95	LOCKWASHER	MS35338-45	5310-00-407-9566
96	LOCKWASHER	MS35338-46	5310-01-334-4710
97	LOCKWASHER	MS35338-47	5310-00-209-0965
98	LOCKWASHER	MS35338-51	5310-00-584-7888
99	LOCKWASHER	MS35338-58	5310-00-702-6286
100	LOCKWASHER	MS51414-1	5310-01-235-2057

Section II. MANDATORY REPLACEMENT PARTS LIST (CONT)

(1) ITEM NO.	(2) NOMENCLATURE	(3) PART NUMBER	(4) NATIONAL STOCK NUMBER
101	LOCKWASHER	MS51414-2	5310-01-310-1098
102	LOCKWASHER	MS51414-4	5310-01-251-9276
103	LOCKWASHER	N9015	5310-01-046-0186
104	LOCKWASHER	N9459	5310-01-348-8393
105	LOCKWASHER	N9461	5310-01-348-8392
105.1	LOCKWASHER	XP1113	5310-01-460-5991
105.2	LOCKWASHER	10241	5310-01-416-3010
105.3	LOCKWASHER	10030	
106	LOCKWASHER	114021	5310-01-081-0798
107	LOCKWASHER	1229-S-513-C	5310-01-062-3384
108	LOCKWASHER	12412477-14	
109	LOCKWASHER	12412601-02	5310-01-387-1152
110	LOCKWASHER	12414570-005	5310-01-452-9420
111	LOCKWASHER	12414570-011	5310-01-374-3292
112	LOCKWASHER	12414570-013	5310-01-374-4515
113	LOCKWASHER	12414570-015	5310-01-388-2043
113.1	LOCKWASHER	12414570-019	5310-01-470-2362
114	LOCKWASHER	12414570-021	5310-01-374-4516
115	NOT USED		
116	NOT USED		
117	NOT USED		
118	LOCKWASHER	1729B262	5310-00-964-7811
119	NOT USED		
120	MOUNT, RESILIENT	12413126	5340-01-439-3765
121	MOUNT, RESILIENT	12418476	5340-01-377-0693
122	NUT, CLIP	MS90724-24	5310-01-074-5041
123	NUT, CONDUIT	BL75	5975-00-642-7261
124	NUT, CONDUIT	141	5975-00-152-1075
125	NUT, CONDUIT	143	5975-00-714-8031
126	NUT, PLAIN, BLIND RIVET	ALS7-632-80	5325-01-465-0001
127	NUT, PLAIN, HEX	MS35649-282	5310-00-934-9757
127.1	NUT, PLAIN, ROUND	1727N40	5310-00-123-2572
128	NUT, SELF-LOCKING	DIN-934STM6	5310-01-342-2739

Section II. MANDATORY REPLACEMENT PARTS LIST (CONT)

(1) ITEM NO.	(2) NOMENCLATURE	(3) PART NUMBER	(4) NATIONAL STOCK NUMBER
129	NUT, SELF-LOCKING	MS20500-524	5310-00-208-4023
130	NUT, SELF-LOCKING	MS21042-04	5310-00-811-6419
130.1	NUT, SELF-LOCKING	MS21045L5	5310-00-857-5559
131	NUT, SELF-LOCKING	MS21083N08	5310-00-941-6019
132	NUT, SELF-LOCKING	MS21083N6	5310-00-926-1852
133	NUT, SELF-LOCKING	MS51922-1	5310-00-088-1251
134	NUT, SELF-LOCKING	MS51922-17	5310-00-087-4652
135	NUT, SELF-LOCKING	MS51922-2	5310-00-929-1807
136	NUT, SELF-LOCKING	MS51922-33	5310-00-225-6993
137	NUT, SELF-LOCKING	MS51922-49	5310-00-269-4040
138	NUT, SELF-LOCKING	MS51922-5	5310-00-959-7600
139	NUT, SELF-LOCKING	MS51922-57	5310-00-067-6356
140	NUT, SELF-LOCKING	MS51922-65	5310-00-225-6992
141	NUT, SELF-LOCKING	MS51922-9	5310-00-984-3806
142	NUT, SELF-LOCKING	N9406	5310-01-362-6171
143	NUT, SELF-LOCKING	N9410	5310-01-348-8398
143.1	NUT, SELF-LOCKING	N9453	5310-01-348-8314
144	NUT, SELF-LOCKING	N9467	5310-01-350-4257
144.1	NUT, SELF-LOCKING	N9556	5310-01-423-0880
145	NUT, SELF-LOCKING	12301125	5310-01-210-0199
146	NUT, SELF-LOCKING	12412476-09	5310-01-445-6346
146.1	NUT, SELF-LOCKING	12411174-008	
147	NUT, SELF-LOCKING	12412476-11	5310-01-407-7178
148	NUT, SELF-LOCKING	12412476-12	
149	NUT, SELF-LOCKING	12412478-04	5310-01-381-9901
150	NUT, SELF-LOCKING	12414308-002	5310-01-381-9819
151	NUT, SELF-LOCKING	12414308-003	5310-01-377-1549
152	NUT, SELF-LOCKING	12414308-004	5310-01-369-5703
153	NUT, SELF-LOCKING	12414308-007	5310-01-369-6073
154	NUT, SELF-LOCKING	12414308-017	5310-01-381-9830
155	NUT, SELF-LOCKING	12414308-018	5310-01-369-3337
156	NUT, SELF-LOCKING	12414308-019	5310-01-369-9522

Section II. MANDATORY REPLACEMENT PARTS LIST (CONT)

(1) ITEM NO.	(2) NOMENCLATURE	(3) PART NUMBER	(4) NATIONAL STOCK NUMBER
157	NUT, SELF-LOCKING	12414308-020	5310-01-381-9849
158	NUT, SELF-LOCKING	12414308-021	5310-01-369-3338
159	NUT, SELF-LOCKING	12414308-022	5310-01-417-1262
160	NUT, SELF-LOCKING	12414308-023	5310-01-369-6705
161	NUT, SELF-LOCKING	12414308-025	5310-01-369-6706
162	NUT, SELF-LOCKING	12414308-027	5310-01-369-3339
163	NUT, SELF-LOCKING	12414308-078	
164	NUT, SELF-LOCKING	12414315-002	5310-01-374-1381
165	NUT, SELF-LOCKING	12414315-003	5310-01-374-1382
166	NUT, SELF-LOCKING	12414315-005	5310-01-372-3023
167	NUT, SELF-LOCKING	12414315-006	5310-01-369-3332
168	NUT, SELF-LOCKING	12414315-009	5310-01-365-7236
169	NUT, SELF-LOCKING	12414315-015	5310-01-462-0580
170	NUT, SELF-LOCKING	12414315-017	5310-01-368-8065
171	NUT, SELF-LOCKING	12414420-004	5310-01-370-0010
172	NUT, SELF-LOCKING	12419003	5310-01-376-0773
173	NUT, SELF-LOCKING	29514660	
174	NUT, SELF-LOCKING	7-660-081600	5310-01-390-8487
175	NUT, SELF-LOCKING	7-660-082504	5310-01-354-8734
176	NUT, SELF-LOCKING	7794625	5310-00-579-1031
177	NUT, SELF-LOCKING	7951286	5310-00-789-0398
178	PACKING, PREFORMED	A82777	5330-00-579-6495
178.1	PACKING, PREFORMED	F4001-16	5331-01-466-0354
179	PACKING, PREFORMED	J515-16-3	5331-01-465-3634
180	PACKING, PREFORMED	5999807	5331-01-456-9156
181	PACKING, PREFORMED	MS28775-011	5330-00-582-2133
181.1	PACKING, PREFORMED	MS28775-910	5331-00-448-6753
182	PACKING, PREFORMED	MS28778-10	5330-00-285-9842
183	PACKING, PREFORMED	MS28778-12	5330-00-251-8839
184	PACKING, PREFORMED	MS28778-16	5330-00-804-5694
185	PACKING, PREFORMED	MS28778-20	5330-00-816-3546

Section II. MANDATORY REPLACEMENT PARTS LIST (CONT)

(1) ITEM NO.	(2) NOMENCLATURE	(3) PART NUMBER	(4) NATIONAL STOCK NUMBER
186	PACKING, PREFORMED	MS28778-4	5330-00-805-2966
187	PACKING, PREFORMED	MS28778-6	5330-00-804-5695
188	PACKING, PREFORMED	MS9955-113	5330-01-374-2325
189	PACKING, PREFORMED	M25988/1-246	5330-01-189-6351
189.1	PACKING, PREFORMED	M83461/1-442	5330-01-183-0987
190	PACKING, PREFORMED	OR420A	5330-01-389-6028
191	PACKING, PREFORMED	11639519-1	5330-00-463-0200
191.1	PACKING, PREFORMED	12422548-004	5331-01-059-1141
192	PACKING, PREFORMED	1509	5330-00-172-1919
192.1	PACKING, PREFORMED	195045	5331-00-618-5361
192.2	PACKING, PREFORMED	19755	5331-01-415-9632
192.3	PACKING, PREFORMED	198336	5331-00-584-1840
193	PACKING, PREFORMED	2-012N507-90	5330-01-092-5502
194	PACKING, PREFORMED	2-018N507-90	5330-01-092-5503
195	PACKING, PREFORMED	2M4453	5330-00-074-3768
196	PACKING, PREFORMED	22617-16	5330-01-168-0885
197	PACKING, PREFORMED	23043446	5330-01-424-6629
197.1	PACKING, PREFORMED	250192	5331-01-417-5105
197.2	PACKING, PREFORMED	251216	5330-01-417-5107
198	PACKING, PREFORMED	29500969	5330-01-360-7852
199	PACKING, PREFORMED	29503383	5330-01-360-6017
200	PACKING, PREFORMED	3-906N552-90	5330-01-104-1093
201	PACKING, PREFORMED	3-908N552-90	5330-00-929-8171
202	PACKING, PREFORMED	3D2824	5330-00-944-8281
203	PACKING, PREFORMED	3J1907	5330-01-333-6444
204	PACKING, PREFORMED	3J7354	5330-00-952-8008
205	PACKING, PREFORMED	3K0360	5330-00-948-6482
206	PACKING, PREFORMED	4J5477	5330-00-855-8059
207	PACKING, PREFORMED	4L9564	5330-00-828-8639
207.1	PACKING, PREFORMED	420828	5340-01-417-3788
208	PACKING, PREFORMED	5-X-1155	5330-01-392-1637
209	PACKING, PREFORMED	5F7054	5330-00-339-6224

Section II. MANDATORY REPLACEMENT PARTS LIST (CONT)

(1) ITEM NO.	(2) NOMENCLATURE	(3) PART NUMBER	(4) NATIONAL STOCK NUMBER
210	PACKING, PREFORMED	5P7813	5330-01-335-0042
211	PACKING, PREFORMED	6V8397	5330-00-579-6495
212	PACKING, PREFORMED	673268	
213	PACKING, PREFORMED	673269	5330-01-395-1252
214	PACKING, PREFORMED	7F8267	5330-00-291-7353
215	PACKING, PREFORMED	7320658	5330-00-297-7106
216	PACKING, PREFORMED	9604792-001	5330-01-429-3089
217	PAD, CUSHIONING	12413120	2590-01-474-8307
218	PARTS KIT, DEHYDRATOR	RN-60-A	4440-01-337-7324
219	PARTS KIT, HYDRAULIC PUMP	P1-12RP	4320-00-125-3208
220	PARTS KIT, SEAL REPLACEMENT	SK10-2	5330-01-350-4474
221	PARTS KIT, SEAL REPLACEMENT	SK10-3	5330-01-350-4472
222	PARTS KIT, SEAL REPLACEMENT	SK10-4	5330-01-343-2745
222.1	PARTS KIT, SEAL REPLACEMENT, MECHANICAL	SKD1VW	5330-01-309-2603
223	PIN, COTTER	K-2412-Z	5315-01-179-9882
224	PIN, COTTER	MS24665-151	5315-00-815-1405
225	PIN, COTTER	MS24665-298	5315-00-234-1861
226	PIN, COTTER	MS24665-385	5315-00-187-9382
227	PIN, COTTER	MS24665-394	5315-00-234-1628
228	PIN, COTTER	MS24665-423	5315-00-013-7228
229	PIN, COTTER	MS24665-455	5315-00-187-9392
230	PIN, COTTER	MS24665-457	5315-00-187-9393
231	PIN, COTTER	MS24665-459	5315-00-187-9394
232	PIN, COTTER	MS24665-494	
233	PIN, COTTER	MS24665-498	5315-00-849-9854
234	PIN, COTTER	MS24665-628	5315-00-846-0126
235	PIN, COTTER	MS24665-654	5315-00-187-9413
236	PIN, COTTER	MS24665-69	5315-00-828-8190
236.1	PIN, COTTER	XB-781-1	5315-01-369-1346
237	NOT USED		
238	PIN, SPRING	MS16562-142	5315-00-058-6115

Section II. MANDATORY REPLACEMENT PARTS LIST (CONT)

(1) ITEM NO.	(2) NOMENCLATURE	(3) PART NUMBER	(4) NATIONAL STOCK NUMBER
239	PIN, SPRING	MS16562-146	5315-00-853-3814
240	PLASTIC STRIP	352700	5330-01-396-2109
241	RECEPTACLE	50R4-1-1AA	5325-01-049-2049
241.1	REPAIR KIT, GOVERNOR	RN32W	
241.2	RETAINER, PACKING	11863-012	5330-01-417-7795
241.3	RETAINER, PACKING	202624	5330-01-417-7794
242	RETAINER	A-1205-D-2344	5330-01-360-5253
243	RIVET, BLIND	AD66H	5320-01-008-8204
243.1	RIVET, BLIND	MS20601AD5W3	5320-00-582-3299
243.2	RIVET, BLIND	MS20601B4W2	5320-00-616-5274
244	RIVET, BLIND	MS20604B3W2	5320-00-721-9075
245	RIVET, BLIND	M24243/1-B302	5320-00-999-0397
246	RIVET, BLIND	M24243/1-B610	5320-00-454-5156
247	RIVET, BLIND	M24243/1-D404	5320-00-865-8994
248	RIVET, BLIND	M24243/1-D502	5320-00-850-3248
249	RIVET, BLIND	M24243/1-D504	5320-01-020-9756
250	RIVET, BLIND	M24243/1-D506	5320-00-850-3225
251	RIVET, BLIND	M24243/1-D604	5320-00-850-3233
252	RIVET, BLIND	M24243/1-D608	5320-00-850-3246
253	RIVET, BLIND	M24243/1-D610	5320-01-030-3218
254	RIVET, BLIND	M24243/1-F402	5320-00-129-9706
254.1	RIVET, BLIND	M24243/1F608	5320-01-392-0699
254.2	RIVET, BLIND	M24243/1F610	
255	RIVET, BLIND	M24243/6-A503H	5320-00-490-2238
256	RIVET, BLIND	NAS1398C5A4	5320-00-321-2521
257	RIVET, BLIND	SD64BSLF	5320-01-397-3347
258	RIVET, BLIND	206057	5320-01-411-0081
259	RIVET, COMPRESSION	12418469	5320-01-376-0699
260	RUBBER STRIP	12412581	9320-01-399-4888
260.1	SCREW, CAP	CSH5-24-39	5305-01-479-7857
261	SCREW, CAP	12414475-131	5303-01-363-0703

Section II. MANDATORY REPLACEMENT PARTS LIST (CONT)

(1) ITEM NO.	(2) NOMENCLATURE	(3) PART NUMBER	(4) NATIONAL STOCK NUMBER
262	SCREW, CAP	6V-2315	5306-01-433-4753
263	SCREW, SELF-LOCKING	MS16998-61L	5305-01-211-3097
264	SEAL	VC08G1R0B	5330-01-389-6109
265	SEAL	355150	5330-01-423-0689
266	SEAL ASSEMBLY, CTIS	A1205-Q-2435	5330-01-360-7753
267	SEAL ASSEMBLY, HUB	A1205-R-2254	5330-01-360-5252
268	SEAL RING, METAL	29505809	5330-01-360-5329
269	SEAL, NONMETALLIC	CC3350	5330-01-431-7575
270	SEAL, NONMETALLIC	12417725	5330-01-375-2908
270.1	SEAL, NONMETALLIC	077032935	5330-01-387-2167
271	SEAL, NONMETALLIC	673999	5310-01-454-5553
271.1	SEAL, PLAIN	N72143	5330-01-453-4462
271.2	SEAL, SHAFT	SE-RUR25-2	5330-01-135-3376
272	SEAL, URETHANE FOAM	12420420-001	5680-01-453-8912
273	SEAL, URETHANE FOAM	12420420-002	5680-01-453-8485
274	SEAL, URETHANE FOAM	12420420-003	5680-01-453-8486
274.1	SEMICONDUCTOR DEVICE, DIODE	JANTX1N3957	5961-00-181-0661
274.2	SPIDER, UNIVERSAL JOINT, VEHICULAR	R279X	
274.3	SPLICE, CONDUCTOR	M7928/5-4	5940-01-079-1375
274.4	SPLICE, CONDUCTOR	M83519/1-2	5940-01-136-2540
274.5	SPLICE, CONDUCTOR	M83519/1-3	5940-01-135-7077
274.6	SPLICE, CONDUCTOR	M83519/1-5	5940-01-135-7079
274.7	SPLICE, CONDUCTOR	12420927-001	5940-01-456-1319
275	SPLICE, CONDUCTOR	23035	5940-01-210-9261
276	SPLICE, CONDUCTOR	23075	3830-01-210-9260
276.1	SPACER	12422545	5365-01-490-6790
277	TERMINAL, LUG	MS20659-163	5940-00-113-3145
278	TERMINAL, LUG	MS20659-164	5940-00-113-3148
278.1	TERMINAL, LUG	12420344	5940-01-082-3321
279	TERMINAL, LUG	MS25036-122	5940-00-113-8190
279.1	WASHER, FLAT	12414473-010	5310-01-374-6990
280	WASHER, FLAT	12417948-004	5365-01-436-8308

Section II. MANDATORY REPLACEMENT PARTS LIST (CONT)

(1) ITEM NO.	(2) NOMENCLATURE	(3) PART NUMBER	(4) NATIONAL STOCK NUMBER
280.1	WASHER, FLAT	251391	5310-01-417-1041
280.2	WASHER, FLAT	990 3861	5310-01-155-1911
281	WASHER, FLAT RUBBER	900.032	5330-01-378-7541
282	WASHER, KEY	TW107	5310-01-014-5136
283	WASHER, NYLON	MS51859-16	5310-01-381-9990
284	WASHER, NYLON	12421464-001	
285	WASHER, NYLON	12421464-002	5310-01-445-6828
286	WASHER, SPRING	D63474/1-30	5310-01-413-8475
287	WASHER, SPRING	110 7289	5310-01-246-1387
288	WASHER, SPRING	12414559-021	5310-01-374-4517
289	WASHER, SPRING	12414560-009	5310-01-333-5517
290	WASHER, SPRING	12414560-011	5310-01-421-9556
291	WASHER, SPRING	12414560-017	5310-01-395-0820
292	WASHER, SPRING	12414560-018	5310-01-381-3281
293	WASHER, SPRING	12414560-019	5310-01-369-6074
294	WASHER, SPRING	12417503	5310-01-406-6326
295	WASHER, SPRING	12418220	5310-01-372-3495
296	WASHER, SPRING	128BSTM4	5310-01-333-5517
297	WASHER, SPRING	12414560-009	5310-01-333-5517

APPENDIX H LUBRICATION ORDER AND SERVICES

SECTION I. INTRODUCTION

H-1. GENERAL

The information contained in this appendix provides the lubrication/services requirements for the MTV vehicle.

- a. **Adherence.** Intervals (on-condition or hardtime) and the related man-hour times are based on normal operation. The man-hour time specified is the time needed to do all the services prescribed for a particular interval. On-condition (OC) oil sample intervals will be applied unless changed by the Army Oil Analysis Program (AOAP) laboratory. Change the hardtime interval if the lubricants are contaminated or if operating the equipment under adverse operating conditions, including longer-than-usual operating hours. The calendar interval may be extended during periods of low activity. If extended, adequate preservation precautions must be taken. Hardtime intervals will be applied in the event AOAP laboratory support is not available. Hardtime intervals must be applied during the warranty period.

Intervals shown in this lubrication order and services are based on mileage/calendar, and in some cases mileage alone. An example of a mileage/calendar interval is: **Q**, which means every 3,000 miles (4,827 km) or quarterly (every three months). The lubrication is to be performed at whichever interval occurs first for the vehicle. An example of a mileage alone interval is: **6K**, which stands for every 6,000 miles (9,654 km). The lubrication/services is to be performed at the mileage indicated regardless of the calendar interval.

WARNING

- **Dry Cleaning Solvent (P-D-680) is TOXIC and flammable. Wear protective goggles and gloves; use only in well-ventilated area; avoid contact with skin, eyes, and clothes, and do not breath vapors. Keep away from heat or flame. Never smoke when using solvent; the flashpoint for Type I Dry Cleaning Solvent is 100 F (38 C) and for Type II is 138 F (50 C). Failure to comply may result in serious injury or death to personnel.**
 - **If personnel become dizzy while using cleaning solvent, immediately get fresh air and medical help. If solvent contacts skin or clothes, flush with cold water. If solvent contacts eyes, immediately flush eyes with water and get medical attention. Failure to comply may result in injury to personnel.**
- b. **Cleaning fittings before lubricating.** Clean parts with dry cleaning solvent (SD P-D-680) (Item 65, Appendix D) or equivalent. Dry before lubricating. Dashed arrows indicate lubrication on both sides of the equipment.
- c. **Lubricating after fording.** If fording occurs, lubricate all fittings below fording depth and check submerged gearboxes for presence of water.
- d. **Lubricating after high-pressure washing.** After a thorough washing, lubricate all grease fittings and oil can points outside and underneath vehicle.
- e. **Level of Maintenance.** The lowest level of maintenance authorized to lubricate a point is Operator/Unit Maintenance (O). Operator/crew (C) may lubricate points authorized for Unit Maintenance (O) when authorized by Unit Maintenance (O).
- f. **Localized views.** A reference to the appropriate localized view is given after most lubrication entries. Localized views begin on page H-13.

H-1. GENERAL (CONT)

g. **Interval Symbols.** The lubrications/services interval symbols will be used as applicable:

- Q-quarterly/3,000 mi (4,827 km) (whichever occurs first)
- S-semiannually/6,000 mi (9,654 km) (whichever occurs first)
- A-annually/12,000 mi (19,308 km) (whichever occurs first)
- B-biennially/24,000 mi (38,616 km) (whichever occurs first)
- 3K-every 3,000 mi (4,827 km) (no calendar interval)
- 6K-every 6,000 mi (9,654 km) (no calendar interval)
- 12K-every 12,000 mi (19,308 km) (no calendar interval)
- 24K-every 24,000 mi (38,616 km) (no calendar interval)

H-2. OIL FILTERS

Oil filters shall be serviced/changed as applicable, when:

- a. They are known to be contaminated, or clogged;
- b. Service is recommended by AOAP laboratory analysis; or
- c. At prescribed hardtime intervals while vehicle is under warranty, or if AOAP is not available/used as required.

H-3. AOAP SAMPLING INTERVAL

WARNING

- **Engine oil is hot and under pressure. The oil sampling valve releases oil proportionally to the amount of pressure applied to valve. Activate oil sampling valve by pressing in slowly to prevent injury to personnel. Failure to comply may result in injury to personnel.**
- **Wear safety goggles when taking oil sample. Oil is under pressure and could cause injury to personnel. Failure to comply may result in injury to personnel.**

Units participating in AOAP will sample engine oil every 3,000 miles (4,827 km) or 6 months, whichever occurs first and change engine oil as directed by AOAP. Units participating in AOAP will sample transmission oil every 6,000 miles (9,654 km) or 12 months, whichever occurs first and change transmission oil as directed by AOAP. Units participating in AOAP will sample hydraulic system oil initially after 6 weeks or 10 hours of operation, whichever occurs first. After initial oil change samples should be taken every 12 months or 50 hours of operation, whichever occurs first and change hydraulic oil as directed by AOAP.

H-4. WARRANTY HARDTIME STATEMENT

"For equipment under manufacturer's warranty, hardtime oil service intervals shall be followed. Intervals shall be shortened if lubricants are known to be contaminated or if operation is under adverse conditions (such as longer than usual operating hours, extended idling periods, extreme dust)."

SECTION II. LUBRICATION/SERVICES CHART

H-5. LUBRICATION/SERVICES KEY

LUBRICANTS	
Specification	Type
MIL-L-2104 (OE/HDO)	Lubricating Oil, Internal Combustion Engine, Combat/Tactical Service
MIL-L-46167 (OEA)	Lubricating Oil, Internal Combustion Engine, Arctic
MIL-L-2105 (GO)	Lubricating Oil, Gear, Multipurpose
MIL-G-10924 (GAA)	Grease, Automotive and Artillery
MIL-G-18458 (GW)	Grease, Wire-Rope and Exposed Gear
MIL-H-5606 (OHA)	Hydraulic Fluid, Petroleum Base, Aircraft, Missile, and Ordnance

DESCRIPTION	CAPACITY	EXPECTED TEMPERATURES		
		Above +40 F (Above +4 C)	+40 F to -15 F (+4 C to -26 C)	-15 F to -50 F (-26 C to -46 C)
Engine crankcase	25 qt (24 L)	OE/HDO-15/40	OE/HDO-15/40	OEA
Transmission (total system) (all models except M1088 and M1089)	49.3 qt (46.7 L)	OE/HDO-15/40	OE/HDO-10	OEA
Transmission (at oil change) (all models except M1088 and M1089)	36.8 qt (34.7 L)	OE/HDO-15/40	OE/HDO-10	OEA
Transmission (total system) (M1088 and M1089)	58.6 qt (55.4 L)	OE/HDO-15/40	OE/HDO-10	OEA
Transmission (at oil change) (M1088 and M1089)	31.8 qt (30.0 L)	OE/HDO-15/40	OE/HDO-10	OEA
Transmission (after overhaul)	39.0 qt (37.0 L)	OE/HDO-15/40	OE/HDO-10	OEA
Steering system	5 qt (4.8 L)	OE/HDO-10	OE/HDO-10	OEA
Hydraulic reservoir (except M1089)	27 gal (102.2 L)	OE/HDO-10	OE/HDO-10	OEA
Hydraulic tank (M1089)	74 gal (280 L)	OE/HDO-10	OE/HDO-10	OEA
Front axle differential (maximum capacity)	9.5 qt (9 L)	GO-80/90	GO-80/90	SAE 75W90 OR GO-75
Intermediate axle differential (maximum capacity)	14.7 qt (13.9 L)	GO-80/90	GO-80/90	SAE 75W90 OR GO-75
Rear axle differential (maximum capacity)	12.15 qt (11.5 L)	GO-80/90	GO-80/90	SAE 75W90 OR GO-75
Front axle planetary hubs	11-13 oz (0.33-0.38 L)	GO-80/90	GO-80/90	SAE 75W90 OR GO-75

H-5. LUBRICATION/SERVICES KEY (CONT)

DESCRIPTION	CAPACITY	EXPECTED TEMPERATURES		
		Above +40 F (Above +4 C)	+40 F to -15 F (+4 C to -26 C)	-15 F to -50 F (-26 C to -46 C)
Rear axle bogie	0.5 qt (0.5 L)	GO-85/140	GO-85/140	GO-85/140
15K Self-Recovery Winch (SRW)	As Required	GO-85/140	GO-80/90	GO-75
30K winches	As Required	GO-85/140	GO-80/90	GO-75
Propeller shaft universal and slip joints	As Required	GAA	GAA	GAA
Tie rod ends	As Required	GAA	GAA	GAA
Towing pintle assembly	As Required	GAA	GAA	GAA
Fifth wheel	As Required	GAA	GAA	GAA
Spring bolts and spring shackles	As Required	GAA	GAA	GAA
Front axle shaft U-joints and steering knuckles	As Required	GAA	GAA	GAA
Front axle inner wheel bearing	As Required	GAA	GAA	GAA
Intermediate axle inner wheel bearing	As Required	GAA	GAA	GAA
Rear axle inner wheel bearing	As Required	GAA	GAA	GAA
Front lifting beam	As Required	GAA	GAA	GAA
15K Self-Recovery Winch (SRW) cable	As Required	GW	GW	GW
30K winch cables	As Required	GW	GW	GW
Air/hydraulic power unit	3 pt (1.4 L)	OHA	OHA	OHA
Backup hydraulic pump	19 oz (562 ml)	OHA	OHA	OHA

COOLANT	
Specification	Type
A-A-52624A	Antifreeze, Multi-Engine Type
MIL-A-11755	Antifreeze, Arctic-Type

DESCRIPTION	CAPACITY	EXPECTED TEMPERATURES		
		Above +40 F (Above +4 C)	+40 F to -15 F (+4 C to -26 C)	-15 F to -50 F (-26 C to -46 C)
Cooling system (engine only)	14 qt (13 L)	A-A-52624A	A-A-52624A	
Cooling system (total system)	50.3 qt (47.6 L)	A-A-52624A	A-A-52624A	N/A
Cooling system (total system) (M1088, M1089)	52.8 qt (49.9 L)	A-A-52624A	A-A-52624A	N/A
Cooling system, Arctic (total system)	64.8 qt (61.3 L)	N/A	N/A	MIL-A-11755
Cooling system, Arctic (total system) (M1088, M1089)	76.5 qt (72.4 L)	N/A	N/A	MIL-A-11755

CLEANING AGENT	
Specification	Type
P-D-680	Dry Cleaning Solvent, SD-II
O-C-1901	Cleaning Compound, Windshield

DESCRIPTION	CAPACITY	EXPECTED TEMPERATURES		
		Above +15 F (Above -9 C)	+15 F to -15 F (-9 C to -26 C)	-15 F to -50 F (-26 C to -46 C)
All metal parts as required	N/A	SD-II (all temperatures)		
Windshield washer reservoir	7.5 qt (7.1 L)	2/3 water to 1/3 O-C-1901	1/2 water to 1/2 O-C-1901	1/3 water to 2/3 O-C-1901

For arctic operation refer to FM 9-207.

H-6. LUBRICATION/SERVICES INTERVALS

Intervals		Total Man-Hours
Quarterly (Q)	Lubrication performed once every three months or 3,000 mi. (4,827 km).*	2.0
Semi-annually (S)	Lubrication performed once every six months or 6,000 mi. (9,654 km).*	6.0
Annually (A)	Lubrication performed once every year or every 12,000 mi. (19,308 km).*	1.5
Biennially (B)	Lubrication performed once every two years or every 24,000 mi. (38,616 km).*	3.5
3K	Lubrication performed once every 3,000 mi. (4,827 km).**	1.0
6K	Lubrication performed once every 6,000 mi. (9,654 km).**	1.0
12K	Lubrication performed once every 12,000 mi. (19,308 km).**	6.5
24K	Lubrication performed once every 24,000 mi. (38,616 km).**	0.5
* Whichever occurs first.		
** No calendar interval.		

H-7. LOCATOR VIEWS

LUBRICANT INTERVAL

INTERVAL LUBRICANT

Engine Crankcase Breather (O)
(See note 17 and view A)

Fuel Filter (O)
(See note 6 and view A)

Fuel/Water Separator (O)
(See note 5 and view B)

Cooling System (O)
(See note 7)

Transmission Filter (O)
(See note 3 and view F)

Transmission Drain and Fill (O)
(See note 3 and views D, E, and F)

Intermediate Axle and Rear Axle Inner Wheel Bearing Repack (O)
(See note 27)

Towing Pintle Fill (O)
(See note 16 and views J and K)

Engine Oil Filter (O)
(See note 2 and view C)

Crankcase Drain and Fill (O)
(See note 1 and views C and D)


Front Axle Inner Wheel Bearing Repack (O)
(See note 27)

Power Steering Reservoir Drain and Fill (O)
(See note 4 and view G)

Power Steering Filter (O)
(See note 4 and view G)

Rear Axle Bogie Drain and Fill (O)
(See note 28 and view AG)

15K Self-Recovery Winch (SRW) Cable Rear Roller Fairlead Fill (O)
(See note 29 and views AE and AF)



CHASSIS

4APPHD11

NOTE: Dashed arrows indicate lubrication on both sides of vehicle.

LUBRICANT INTERVAL

INTERVAL LUBRICANT

**Spring Shackle
Fill (O)**
(See note 18 and view I)


**Tie Rod Ends
Fill (O)**
(See note 13 and view N)

**Universal and Slip Joints
Fill (O)**
(See note 9 and view P)

Battery Posts (O)
(See note 19 and view Q)

Air Dryer (O)
(See note 37 and view BB)

**Universal and Slip Joints
Fill (O)**
(See note 9 and view P)



**Spring Bolt
Fill (O)**
(See note 18 and view H)

**Brake Wedge and Air
Chamber (O)**
(See note 21 and view L)

**Backup Hydraulic Pump
Drain and Fill (O)**
(See note 10 and view R)

**Air/Hydraulic Power Unit
Drain and Fill (O)**
(See note 10 and view S)

**Brake Wedge and Air
Chamber (O)**
(See note 21 and view M)

**Universal Joint and Slip
Joints
Fill (O)**
(See note 9 and view P)

**Brake Wedge and Air
Chamber (O)**
(See note 21 and view M)

CHASSIS


4APPH0E

NOTE: Dashed arrows indicate lubrication on both sides of vehicle.

H-7. LOCATOR VIEWS (CONT)

LUBRICANT INTERVAL

INTERVAL LUBRICANT




4APPH03B

NOTE: Dashed arrows indicate lubrication on both sides of vehicle.

LUBRICANT INTERVAL

INTERVAL LUBRICANT



30K Winch Cable
Fill (O)
 (See note 14 and view AB)

Pay-Out Assembly Lower
Tension Sheave
Fill (O)
 (See note 30 and view BA)

15K Self-Recovery Winch
(SRW) Cable Front Roller
Fairlead
Fill (O)
 (See note 29 and views Z
 and AA)

Hydraulic Tank and Filter
Drain and Fill (O)
 (See note 22 and view AD)

30K Winch Cable Guide
Rollers
Fill (O)
 (See note 30 and view AB)


30K Winch Cable Guide
Rollers
Fill (O)
 (See note 30 and view AC)

4APPHQ4A

M1089

NOTE: Dashed arrows indicate lubrication on both sides of vehicle.

H-7. LOCATOR VIEWS (CONT)



4APPH05B

M1089 MATERIAL HANDLING CRANE (MHC)

NOTE: Dashed arrows indicate lubrication on both sides of vehicle.

LUBRICANT INTERVAL

INTERVAL LUBRICANT


**Hoist
Check and Fill (O)**
(See note 24 and view AS)

**Boom Wear Pads
Fill (O)**
(See note 23)

**Boom Sheave
Fill (O)**
(See note 34 and view AT)

**Hoist Cable
Fill (O)**
(See note 14)

**Turntable Gearbox
Check and Fill (O)**
(See note 25 and view AU)



**Lift Cylinder Pivots
Fill (O)**
(See note 34 and view AV)

**Erection Cylinder and
Tension Link Pivots
Fill (O)**
(See note 34 and view AW)

**Erection Cylinder and
Tension Link Pivots
Fill (O)**
(See note 34 and view AX)

**Tension Link
Grease (O)**
(See note 38 and view BC)

**Turntable Bearing and
Pinion Gear Teeth
Fill (O)**
(See note 26 and view AY)

**Turntable Bearing
Fill (O)**
(See note 32 and view AZ)

4APP06B

M1084/M1086 MATERIAL HANDLING CRANE (MHC)

NOTE: Dashed arrows indicate lubrication on both sides of vehicle.


H-7. LOCATOR VIEWS (CONT)

LUBRICANT INTERVAL

INTERVAL LUBRICANT

Left and Right Lift Cylinder
Pivots
Fill (O)
(See note 35)

Left and Right Lower Arm
Pivots
Fill (O)
(See note 35)



Camlock Assembly
Fill (O)
(See note 35)





Crossbar Bushing
Fill (O)
(See note 35)

4APPH07A





M1089 UNDERLIFT ASSEMBLY





NOTE: Dashed arrows indicate lubrication on both sides of vehicle

H-8. LOCAL VIEWS











H-8. LOCAL VIEWS (CONT)













H-8. LOCAL VIEWS (CONT)













H-8. LOCAL VIEWS (CONT)













H-8. LOCAL VIEWS (CONT)













H-8. LOCAL VIEWS (CONT)







H-8. LOCAL VIEWS (CONT)





H-8. LOCAL VIEWS (CONT)



H-9. LUBRICATION/SERVICES NOTES

1. **ENGINE CRANKCASE.** Check engine oil level daily. Change engine oil at initial 5,000 miles (8,045 km). During the remainder of the 12,000 mile (19,308 km)/18 month warranty period. Units participating in AOAP will sample engine oil every 3,000 miles (4,827 km) or 6 months, whichever occurs first and change oil as directed by AOAP. Units not participating in AOAP, will change engine oil every 6,000 miles (9,654 km) or every six months, whichever occurs first. After expiration of engine warranty period, Units participating in AOAP will perform engine oil change as directed by AOAP. Units not participating in AOAP will change engine oil every 6,000 miles (9,654 km) or every six months, whichever occurs first, or when operating in dusty areas or under severe operating conditions, change the oil every 3,000 miles (4,827 km) or every three months, whichever occurs first. Drain engine oil when engine is warm. Refill engine crankcase with OE/HDO specified for the ambient temperature. Engine oil is full when level is within crosshatch marks on the dipstick. Do not overfill.
2. **ENGINE OIL FILTER.** Filter is replaced each time the crankcase is drained. If water or metal particles are detected during oil filter replacement, notify Direct Support Maintenance personnel before refilling crankcase (para 3-4).
3. **TRANSMISSION.** Check transmission oil level daily. Change transmission oil at initial 5,000 miles (8,045 km). During the remainder of the 24 month/unlimited mileage warranty. Units participating in AOAP will sample transmission oil every 6,000 miles (9,654 km) or 12 months, whichever occurs first and change oil as directed by AOAP. Units not participating in AOAP will perform transmission oil change every 24,000 miles (38,616 km) or once every two years, whichever occurs first. Drain transmission oil when engine is warm. Refill with OE/HDO specified for ambient temperature. Add oil until the proper level is reached (TM 9-2320-366-10-1). Do not overfill. Replace oil filters each time transmission oil is changed (para 8-9).
4. **POWER STEERING.** Check power steering oil level weekly. Change the oil every 24,000 miles (38,616 km). Disconnect upper and lower hoses from steering gear and drain oil. Refill power steering pump reservoir with OE/HDO specified for the ambient temperature. Reservoir is full when oil is between the two marks on the dipstick. Do not overfill. Remove dipstick, wipe clean and install dipstick fully into reservoir. Remove dipstick and read oil level. Replace oil filter each time power steering oil is changed (para 13-8).

5. FUEL/WATER SEPARATOR. Replace filter element every 6,000 miles (9,654 km) or once every six months, whichever occurs first (para 4-13).

6. FUEL FILTER. The fuel particle filter is replaced when a new fuel/water separator filter element is installed. The normal replacement interval is every 6,000 miles (9,654 km) or once every six months, whichever occurs first (para 4-14).

7. ENGINE COOLANT. Check engine coolant level daily. Change the coolant and flush the cooling system every 24,000 miles (38,616 km) or once every two years, whichever occurs first. Fill radiator overflow tank with an Ethylene Glycol/water mixture as specified in 0-A-548D. Service the cooling system before the specified interval if:

- Coolant is heavily contaminated.
- Engine overheats.
- Oil cooler has failed allowing oil and coolant to mix.

8. HYDRAULIC RESERVOIR AND FILTER (All Models Except M1089). Check oil level weekly and make sure oil level gage reads **F (full)**. Units participating in AOAP will sample oil annually and change oil and filter as directed by AOAP. Units not participating in AOAP will change oil and filter every two years. Drain oil and refill hydraulic reservoir with OE/HDO specified for ambient operating temperature. Fill hydraulic reservoir until oil level gage reads **F (full)**. Do not overfill. Replace oil filter each time oil is changed (para 19-13).

9. DRIVE SHAFT UNIVERSAL and SLIP YOKE.

Lubricate drive shafts with GAA every 3,000 miles (4,827 km) or once every three months, whichever occurs first, using a low pressure lubrication gun. If operating conditions are severe or abnormal, service at 1,000 miles (1,609 km) or once every month, whichever occurs first. Perform drive shaft hinging inspection every time drive shafts are serviced (para 9-3).

- UNIVERSAL JOINT:
 - A. Apply grease to both grease fittings until new grease purges from all four bearing caps.
 - B. If grease does not purge from all four bearing caps, perform the following steps:
 - (1) Loosen two screws on bearing cap that does not purge, approximately 1/4 in.
 - (2) Apply grease to grease fitting for bearing cap that does not purge until bearing cap purges.
 - (3) Remove and discard the two screws loosened in step (1).
 - (4) Position two replacement screws in bearing cap and tighten down evenly.
 - (5) Tighten two screws to 26-35 lb-ft (35-47 N m).
- SLIP JOINT:
 - A. Apply grease until grease appears at the vent in the welch plug.
 - B. Place your finger over the welch plug vent and add grease until grease purges from the dust seal.
 - C. If grease does not purge from the dust seal, inspect drive shaft slip yoke (para 9-2).

10. AIR/HYDRAULIC POWER UNIT and BACKUP HYDRAULIC PUMP. Change OHA oil every 24,000 miles (38,616 km) or once every two years, whichever occurs first. To service air/hydraulic power unit and backup hydraulic pump refer to vehicle para 19-8, Air Transportability Hydraulic System Service.

11. ALL AXLE DIFFERENTIALS. Check oil level in differentials every 3,000 miles (4,827 km). Check oil level with vehicle parked on level surface and axle differential at ambient temperature, allowing at least one hour to cool down after vehicle operation. If oil is checked when axle differential is hot, it is normal for oil to spill out of the port due to expansion from the heat. Oil level is considered full if it is within one inch of the bottom of the fill port. If oil spills from the fill port when the axle differential is cool, it is overfull. Allow oil to drain until no more drains out. If the oil level is more than one inch below the bottom of the fill port, refill axle differential with GO specified for the ambient temperature until level with bottom of fill port. Change the oil every 24,000 miles (38,616 km) or once every two years, whichever occurs first. Drain oil when hot after operation.

H-9. LUBRICATION/SERVICES NOTES (CONT)

12. FRONT AXLE WHEEL END PLANETARY HUBS. There are two lube intervals for the front axle wheel end planetary hubs.

- a. Check and fill front axle wheel end planetary hubs every 3,000 miles (4,827 km) or once every three months, whichever occurs first, as follows:
 - (1) Position vehicle on a level surface. Allow 15 minutes for vehicle to cool before checking oil levels.
 - (2) Position fill port at 4 o'clock position. If oil flows from fill port when plug is loosened, let oil drain to correct level. If oil level is below fill port, fill hub with GO specified for the ambient temperature until oil is level with fill port.

- b. Drain and fill front axle wheel end planetary hubs every 24,000 miles (38,616 km) or once every two years, whichever occurs first, following the repacking of the inner wheel bearings, or whenever wheel end assemblies are taken apart for other maintenance as follows:
 - (1) Position vehicle on a level surface.
 - (2) Position fill port at the 6 o'clock (down) position.
 - (3) Drain hub oil (allow a minimum of 15 minutes for oil to drain down from vent tubes).
 - (4) Refill hubs with 11-13 ounces of GO specified for the ambient temperature.

13. TIE ROD ENDS. Lubricate tie rod ends with GAA every 6,000 miles (9,654 km) or once every six months, whichever occurs first, using a low pressure lubrication gun, until new grease is seen purging from the boot area. If operating conditions are severe or abnormal, service at 1,000 miles (1,609 km) or once every month, whichever occurs first.

14. WINCH CABLES:

CAUTION

Do not use dry cleaning solvent to clean winch cables. Use of dry cleaning solvent will remove lubricant from inner strands of winch cables. Failure to comply may result in damage to equipment.

- a. After winch operation:
Refer to FM 5-125.

- b. Care of wire rope:
Refer to FM 5-125.

- c. Inspection of wire rope:
Refer to FM 5-125.

- d. Every six months:
 - (1) Unwind entire length of winch cable (TM 9-2320-366-10-1).
 - (2) Soak and clean winch cable with new OE/HDO 30.
 - (3) Wipe off excess OE/HDO 30.
 - (4) Coat winch cable with GW.
 - (5) Rewind winch cable (TM 9-2320-366-10-1).

15. 15K SRW. Check 15K SRW gear oil level every 6,000 miles (9,654 km) or once every six months, whichever occurs first. Refill 15K SRW with GO specified for ambient temperature. Change oil every 12,000 miles (19,308 km) or once every year, whichever occurs first. Use procedure (a) to check and fill oil level; use procedure (b) to change oil.

a. Check and fill oil level as follows:

- (1) Shift the freespool mechanism to the disengage position so the drum can be freely rotated.
- (2) Rotate the drum to where either plug is near the top of the 15K SRW. Remove the plug.
- (3) Rotate the drum 90 degrees in the direction that allows the other plug to be near the top of the 15K SRW. Remove the plug.

NOTE

Oil level is full if a small amount of oil runs out of lower plug.

- (4) Add oil until a small amount of oil runs out of lower plug hole.
- (5) Apply adhesive (Item 3, Appendix D) to plug and position plug in top hole.
- (6) Rotate drum until open hole is at top.
- (7) Apply adhesive (Item 3, Appendix D) to plug and position plug in top hole.
- (8) Tighten plugs to 13-15 lb-ft (18-20 N·m).

b. Change oil as follows:

- (1) Shift the freespool mechanism to the disengage position so the drum can be freely rotated.
- (2) Rotate the drum to where either plug is near the top of the 15K SRW. Remove the plug.
- (3) Rotate the drum 90 degrees in the direction that allows the other plug to be near the top of the 15K SRW. Remove the plug.
- (4) Position drain pan (Item 39, Appendix C) under 15K SRW.
- (5) Rotate the drum until either hole is straight down to the bottom of the 15K SRW. Allow the oil to drain completely.
- (6) Rotate the drum until either hole is at top.

NOTE

Oil level is full if a small amount of oil runs out of lower plug.

- (7) Add oil until a small amount of oil runs out of lower plug hole.
- (8) Apply adhesive (Item 3, Appendix D) to plug and position plug in top hole.
- (9) Rotate drum until open hole is at top.
- (10) Apply adhesive (Item 3, Appendix D) to plug and position plug in top hole.
- (11) Tighten plugs to 13-15 lb-ft (18-20 N·m).

16. TOWING PINTLE. Lubricate towing pintle with GAA every 6,000 miles (9,654 km) or once every six months, whichever occurs first, using a low pressure lubrication gun until new grease is seen purging.

H-9. LUBRICATION/SERVICES NOTES (CONT)

WARNING

- **Dry Cleaning Solvent (P-D-680) is TOXIC and flammable. Wear protective goggles and gloves; use only in well-ventilated area; avoid contact with skin, eyes, and clothes, and do not breath vapors. Keep away from heat or flame. Never smoke when using solvent; the flashpoint for Type I Dry Cleaning Solvent is 100 F (38 C) and for Type II is 138 F (50 C). Failure to comply may result in serious injury or death to personnel.**
- **If personnel become dizzy while using cleaning solvent, immediately get fresh air and medical help. If solvent contacts skin or clothes, flush with cold water. If solvent contacts eyes, immediately flush eyes with water and get medical attention. Failure to comply may result in injury to personnel.**

17. ENGINE CRANKCASE BREATHER. Remove crankcase breather and clean with Dry Cleaning Solvent (SD P-D-680) (Item 65, Appendix D) or equivalent, and replace o-ring seal every 6,000 miles (9,654 km) or once every six months, whichever occurs first (para 3-5).

18. FRONT AXLE SPRING BOLT and SPRING SHACKLE. Lubricate front axle spring bolt and spring shackle with GAA every 3,000 miles (4,827 km) or once every three months, whichever occurs first, using a low pressure lubrication gun until grease appears between pins and bushings at both ends of spring bolt and spring shackle. If pins do not accept grease, notify Direct Support to remove pins. Clean and inspect pins and bushings, replace if necessary. If operating conditions are severe or abnormal, service at 1,000 miles (1,609 km) or once every month, whichever occurs first.

19. BATTERY POSTS. Service batteries in accordance with TM 9-6140-200-14, every 6,000 miles (9,654 km) or once every six months, whichever occurs first.

20. FRONT AXLE SHAFT UNIVERSAL JOINTS and STEERING KNUCKLES. Lubricate universal joints every 3,000 miles (4,827 km) or once every three months, whichever occurs first. Lubricate steering knuckles with GAA every 6,000 miles (9,654 km) or once every six months, whichever occurs first, using a low pressure lubrication gun. If operating conditions are severe or abnormal, service at 1,000 miles (1,609 km) or once every month, whichever occurs first.

21. BRAKE WEDGE and AIR CHAMBER: BRAKE SPIDER, SELF-ADJUSTER MECHANISM, AND WEDGE ASSEMBLY. Clean and lubricate (with GAA) areas of spider and hardware that contact the brake shoes. Disassemble, clean and lubricate the self-adjuster mechanism. Clean and lubricate the wedge head, rollers and ramps in the plungers. Clean and lubricate every 6,000 miles (9,654 km). If operating conditions are severe or abnormal, service at 3,000 miles (4,827 km) or once every three months, whichever occurs first, or when any of the following occur: Refer to para 11-4 and 11-5

- Seals are replaced
- Plungers are removed
- Brakes are relined
- Grease becomes contaminated or hardened

22. HYDRAULIC TANK (M1089). Check oil level weekly and make sure oil level indicates FULL. Units participating in AOAP will sample oil annually and change oil and filter as directed by AOAP. Units not participating in AOAP will change oil and filter every two years. Drain oil and refill hydraulic tank with OE/HDO specified for ambient operating temperature. Fill hydraulic tank until oil level is at the FULL mark on the sight glass. Do not overfill. Replace hydraulic oil filter (para 19-20) when oil is changed. Check oil level with Material Handling Crane (MHC) in the stowed position.

23. BOOM WEAR PADS (M1084/M1086/M1089). Lubricate every 6,000 miles (9,654 km) or once every six months, whichever occurs first. Coat boom wear pads with GAA while boom is extended, for the lower wear pads, boom must be retracted and access cover removed at rear of base boom to grease the upper wear pads. Extend boom in and out while applying grease. This method assures full lubrication for entire length of boom. If operating conditions are severe or abnormal, service at 1,000 miles (1,609 km) or once every month, whichever occurs first.

24. HOIST ASSEMBLY DRUM (M1084/M1086/M1089). Check hoist assembly drum oil level every 6,000 miles (9,654 km) or every six months, whichever occurs first. Check oil level in hoist assembly drum using two pipe plugs (90 degrees apart) on the drum housing. Operate hoist assembly drum so that one pipe plug is positioned at top of drum (fill point) and the other is accessible and level with ground (check level point). Oil level is full if a small quantity of oil runs from check level opening. If oil level is low, add oil at fill opening. To drain, operate drum so that one pipe plug is bottom of drum. Remove plug to drain. Drain and refill with GO specified for the ambient temperature, if oil becomes contaminated.

25. SWING DRIVE GEARBOX (M1084/M1086/M1089). Check swing drive gearbox oil level every 6,000 miles (9,654 km) or once every six months, whichever occurs first. Oil level is checked by removing pipe plug located on side of gear reducer. Oil level is full if a small quantity of oil runs out of opening. Add oil at fill point if necessary. Notify Direct Support to drain and refill with GO specified for the ambient temperature, if oil becomes contaminated.

26. RING GEAR TEETH and PINION GEAR TEETH (M1084/M1086/M1089). Lubricate every 6,000 miles (9,654 km), after washing, or once every six months, whichever occurs first. Apply a light coat of GAA to ring gear teeth and pinion gear teeth. Operate MHC (TM 9-2320-366-10) to rotate turntable. This will allow grease to be applied to all gear teeth. If operating conditions are severe or abnormal, service at 1,000 miles (1,609 km) or once every month, whichever occurs first.

27. FRONT, INTERMEDIATE, and REAR AXLE INNER WHEEL BEARINGS. Repack inner wheel bearings with GAA every 12,000 miles (19,308 km), when semiannual PMCS inspection of service brakes reveals oil leak from inner hub, or whenever wheel end assemblies are taken apart for other maintenance (para 10-2).

28. REAR AXLE BOGIE. Change oil every 6,000 miles (9,654 km) or once every six months, whichever occurs first. Remove six screws and rear axle bogie cover from one side at a time. Raise axle on opposite side of vehicle to allow oil to drain out. Lower axle and repeat on other side of vehicle. Apply thin bead of silicone adhesive sealant 593 to seating surface of housing. Position cover (with fill plug at the 1 o'clock position) and six screws on housing. Tighten six screws to 24 lb-ft (32 N·m). Remove plug from cover and plug from top of rear axle bogie housing. Refill rear axle bogie with GO specified for the ambient temperature, until level with port on housing cover. Install plugs in cover and housing.

29. 15K SELF-RECOVERY WINCH (SRW) CABLE ROLLER FAIRLEADS. Lubricate with GAA every 6,000 miles (9,654 km) or once every six months, whichever occurs first, using a low pressure lubrication gun. If operating conditions are severe or abnormal, service at 1,000 miles (1,609 km) or once every month, whichever occurs first.

30. 30K WINCH CABLE GUIDE ROLLERS and PAY-OUT LOWER TENSION SHEAVE. Lubricate with GAA every 6,000 miles (9,654 km) or once every six months, whichever occurs first, using a low pressure lubrication gun. If operating conditions are severe or abnormal, service at 1,000 miles (1,609 km) or once every month, whichever occurs first.

H-9. LUBRICATION/SERVICES NOTES (CONT)

WARNING

- **Dry Cleaning Solvent (P-D-680) is TOXIC and flammable. Wear protective goggles and gloves; use only in well-ventilated area; avoid contact with skin, eyes, and clothes, and do not breath vapors. Keep away from heat or flame. Never smoke when using solvent; the flashpoint for Type I Dry Cleaning Solvent is 100 F (38 C) and for Type II is 138 F (50 C). Failure to comply may result in serious injury or death to personnel.**
- **If personnel become dizzy while using cleaning solvent, immediately get fresh air and medical help. If solvent contacts skin or clothes, flush with cold water. If solvent contacts eyes, immediately flush eyes with water and get medical attention. Failure to comply may result in injury to personnel.**

31. SCREEN and PLUG OIL FILTER ASSEMBLY (intermediate axle only). Clean the area around the screen and plug oil filter assembly. Remove the screen and plug oil filter assembly. Clean with Dry Cleaning Solvent (Item 65, Appendix D) or equivalent, every 12,000 miles (19,308 km) or once every year, whichever occurs first. Clean filter each time the differential is drained. If screen is crushed or bent, replace with a new one. Clean the screen cavity in the carrier of all debris and particles. If excessive amount of metal particles are detected during oil filter servicing, notify Direct Support Maintenance personnel before refilling differential.

32. TURNTABLE BEARING (M1084/M1086/M1089). Lubricate with GAA every 6,000 miles (9,654 km), after washing, or once every six months, whichever occurs first. Use a low pressure lubrication gun. Apply lubrication to grease fitting inside turntable bearing. Operate MHC (TM 9-2320-366-10) to rotate turntable bearing through full range of travel between applications of grease. This method assures full lubrication of the turntable bearing. If operating conditions are severe or abnormal, service at 1,000 miles (1,609 km) or once every month, whichever occurs first.

33. TOP and BOTTOM PLATES (M1089). Lubricate every 6,000 miles (9,654 km) or once every six months, whichever occurs first. Coat top and bottom plates with GAA. Extending outriggers in and out while applying grease assures full lubrication for the entire length of top and bottom plates. If operating conditions are severe or abnormal, service at 1,000 miles (1,609 km) or once every month, whichever occurs first.

34. CRANE GREASE FITTINGS (M1084/M1086/M1089). Lubricate with GAA every 6,000 miles (9,654), after washing, or once every six months, whichever occurs first. Use a low pressure lubrication gun. If operating conditions are severe or abnormal, service at 1,000 miles (1,609 km) or once every month, whichever occurs first.

35. UNDERLIFT ASSEMBLY GREASE FITTINGS. Lubricate with GAA every 6,000 miles (9,654), after washing, or once every six months, whichever occurs first. Use a low pressure lubrication gun. If operating conditions are severe or abnormal, service at 1,000 miles (1,609 km) or once every month, whichever occurs first.

36. FRONT LIFTING BEAM. Remove left and right lifting beams and clean with Dry Cleaning Solvent (Item 65, Appendix D) or equivalent, every 6,000 miles (9,654 km) or once every six months, whichever occurs first. Apply a light coat of GAA to lifting beams. If operating conditions are severe or abnormal, service at 1,000 miles (1,609 km) or once every month, whichever occurs first.

37. AIR DRYER. Service air dryer (para 23-11) every 12,000 miles (19,308 km) or annually, whichever occurs first.

38. TENSION LINKS. Lubricate tension link(s) every three months with GAA.

39. FRONT LEAF SPRING AND REAR BOGIE AXLE. At initial 1000 miles (1609 km) of vehicle operation, tighten U-bolts to 390-510 lb-ft (529-692 N•m).

APPENDIX J ADDITIONAL AUTHORIZATION LIST (AAL)

Section I. INTRODUCTION

J-1. SCOPE

This appendix lists additional items you are authorized for the support of the MTV.

J-2. GENERAL

This list identifies items that do not have to accompany the MTV and that do not have to be turned in with it. These items are all authorized to you by Common Tables of Allowance (CTA), Modification Table of Organization and Equipment (MTOE), Tables of Distribution and Allowances (TDA), or Joint Table of Allowance (JTA).

J-3. EXPLANATION OF LISTING

National Stock Numbers, description, and quantities are provided to help you identify and request the additional items you require to support this equipment.

Section II. ADDITIONAL AUTHORIZATION LIST

(1) National Stock Number	(2) Description (CAGE) Part Number	(3) U/M	(4) Qty Auth
6685-01-193-1733	10,000 PSI Transducer: (19207) 12258956	EA	1

APPENDIX K TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART

Section I. INTRODUCTION

K-1. INTRODUCTION

This appendix lists the various transmission controls and configuration modifications that may be required to permit the transmission to function correctly. This appendix will guide the mechanic through the hardware selection process by identifying compatibility issues between the transmission controls (WTEC II/WTEC III) and the numerous revisions of the Allison MD3070PT transmission (PRE-ID w/ 24-pin connector, PRE-ID w/ 31-pin connector, TID 1, TID 2, and TID 3). Refer to Figure 1. After replacing any component of the transmission controls or the transmission assembly, perform calibration procedures in TM 9-2320-366-20-4 paragraph 8-2 or 8-3.

K-2. EXPLANATION OF COLUMNS

- a. **Column (1) - Installed Controls or Controls Being Installed.** This column lists all of the variables concerning which version of transmission controls are installed in the vehicle, or may need to be installed, to communicate correctly with the transmission.
- b. **Column (2) - Installed Transmission or Transmission Being Installed.** This column lists all of the various revisions of the Allison MD3070PT transmissions that may be installed in the vehicle.
- c. **Column (3) - Required Modification.** This column lists the various electrical interface (hardware) modifications that may be required to allow the transmission controls to communicate with the transmission.

K-3. HOW TO USE THIS CHART

- a. Determine which controls and transmission are installed in the vehicle.
- b. Determine which component requires replacement.
- c. Read across the row to column (3) to determine the required modification.

Section II.

TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART

(1) Installed Controls or Controls Being Installed	(2) Installed Transmission or Transmission Being Installed	(3) Required Modification (Refer to Section III)
WTEC II (with 24-pin connector)	PRE-ID w/ 24-pin connector (transmission serial number prior to 6510032369)	No modification required.
WTEC II (with 24-pin connector)	PRE-ID w/ 31-pin connector (transmission serial number 6510032369 to 6510090785)	Install 31-pin connector.
WTEC II (with 24-pin connector)	TID 1 (transmission serial number 6510090786 to 6510142171)	Install 31-pin connector.
WTEC II (with 24-pin connector)	TID 2 (transmission serial number 6510142172 to 6510262116)	Install 31-pin connector and replace transmission internal wiring harness.

TRANSMISSION/TRANSMISSION CONTROLS ADAPTABILITY CHART (CONT)

(1) Installed Controls or Controls Being Installed	(2) Installed Transmission or Transmission Being Installed	(3) Required Modification (Refer to Section III)
WTEC II (with 24-pin connector)	TID 3 (transmission serial number 6510262117 and subsequent)	Install 31-pin connector, replace transmission internal wiring harness, and reprogram WTEC II TEPSS. ¹
WTEC II (with 31-pin connector)	PRE-ID w/ 24-pin connector (transmission serial number prior to 6510032369)	Install adapter cable assembly.
WTEC II (with 31-pin connector)	PRE-ID w/ 31-pin connector (transmission serial number 6510032369 to 6510090785)	No modification required.
WTEC II (with 31-pin connector)	TID 1 (transmission serial number 6510090786 to 6510142171)	No modification required.
WTEC II (with 31-pin connector)	TID 2 (transmission serial number 6510142172 to 6510262116)	Replace transmission internal wiring harness.
WTEC II (with 31-pin connector)	TID 3 (transmission serial number 6510262117 and subsequent)	Replace transmission internal wiring harness and reprogram WTEC II TEPSS. ¹
WTEC III (with ECU manufactured prior to October 1999) ²	PRE-ID w/ 24-pin connector (transmission serial number prior to 6510032369)	Install adapter cable assembly and ID harness.
WTEC III (with ECU manufactured prior to October 1999) ²	PRE-ID w/ 31-pin connector (transmission serial number 6510032369 to 6510090785)	Install ID harness.
WTEC III (with ECU manufactured prior to October 1999) ²	TID 1 (transmission serial number 6510090786 to 6510142171)	No modification required.
WTEC III (with ECU manufactured prior to October 1999) ²	TID 2 (transmission serial number 6510142172 to 6510262116)	No modification required.
WTEC III (with ECU manufactured prior to October 1999) ²	TID 3 (transmission serial number 6510262117 and subsequent)	Reprogram WTEC III ECU ¹ or install new WTEC III ECU (P/N 12421787-002).
WTEC III (with ECU manufactured after October 1999) ³	PRE-ID w/ 24-pin connector (transmission serial number prior to 6510032369)	Install adapter cable assembly and ID harness.
WTEC III (with ECU manufactured after October 1999) ³	PRE-ID w/ 31-pin connector (transmission serial number 6510032369 to 6510090785)	Install ID harness.
WTEC III (with ECU manufactured after October 1999) ³	TID 1 (transmission serial number 6510090786 to 6510142171)	No modification required.

¹ Reprogramming can only be accomplished by an authorized Allison Transmission distributor. You must provide the transmission serial number of the transmission being installed to ensure correct reprogramming. If at a later time, an earlier version transmission is installed in a WTEC II equipped vehicle, WTEC II TEPSS will require reprogramming again.

² Vehicle serial number 012477 and lower. Refer to Figure 1.

³ Vehicle serial number 012478 and higher. Refer to Figure 1.

(1) Installed Controls or Controls Being Installed	(2) Installed Transmission or Transmission Being Installed	(3) Required Modification (Refer to Section III)
WTEC III (with ECU manufactured after October 1999) ³	TID 2 (transmission serial number 6510142172 to 6510262116)	No modification required.
WTEC III (with ECU manufactured after October 1999) ³	TID 3 (transmission serial number 6510262117 and subsequent)	No modification required.

Section III.

MODIFICATION PARTS IDENTIFICATION

Identification	Part Number/NSN	Description
31-pin connector	300130 5935-21-921-1813	Converts a transmission external wiring harness from a 24-pin ("D" type) connector to a 31-pin (round type) connector.
Transmission internal wiring harness	29529474 6150-01-481-8088	Converts a TID 2 transmission to a TID 1 configuration to allow WTEC II controls to communicate with the transmission.
Gasket	29503283 5330-01-360-9035	Required when replacing transmission internal wiring harness.
ID harness	200100 6150-21-921-1191	Allows WTEC III controls to communicate with a PRE-ID transmission.
Adapter cable assembly	29519210 6150-01-420-5987	Adapts a PRE-ID transmission with 24-pin ("D" type) connector to a transmission external wiring harness with a 31-pin (round) connector.

MODIFICATION PARTS IDENTIFICATION (CONT)




FIGURE 1

4WTEC11

SUBJECT INDEX

Subject	Para	Subject	Para
A		A (Cont)	
Air		Auxiliary (Cont)	
Brake System Loses Air When Brakes Are Applied	2-20	Transmission Auxiliary Oil Cooler Fan Does Not Operate (All Models Except M1088/M1089)	2-16
Dryer Does Not Operate (All Models Except M1090/M1094)	2-16	Transmission Auxiliary Oil Cooler Fan Runs Constantly	2-16
Dryer Purges Constantly	2-21		
Large Quantity of Moisture Expelled From Air Reservoirs	2-21	B	
M1090/M1094 Air Dryer Does Not Operate	2-16	Battery Tester Does Not Operate	2-16
No Air Pressure Present At Rear Gladhand(s) (All Models Except M1088)	2-21	Bed	
No Air Pressure Present at All M1088 Rear and Fifth Wheel Gladhands	2-21	M1090/M1094 DUMP BED Down Does Not Operate	2-16
No Air Pressure Present at M1088 Rear and/or Fifth Wheel EMERGENCY Gladhands	2-21	M1090/M1094 DUMP BED Up Does Not Operate	2-16
No Air Pressure Present at M1088 Rear and/or Fifth Wheel SERVICE Gladhands	2-21	Boom	
Noisy Air Compressor Operation	2-21	M1084/M1086 Material Handling Crane (MHC) Boom Down Does Not Operate From Remote Station	2-16
System Loses Pressure During Operation/Slow, No, or Incorrect Air Pressure Buildup	2-21	M1084/M1086 Material Handling Crane (MHC) Boom Down Lockout Does Not Activate	2-16
System Pressure Builds Up to More Than 120 psi (827 kPa) (Compressor Fails to Unload)	2-21	M1084/M1086 Material Handling Crane (MHC) Boom Up Does Not Operate From Remote Station	2-16
System Troubleshooting	2-21	M1084/M1086 Material Handling Crane (MHC) Boom Up Lockout Does Not Activate	2-16
Alarm		M1089 Material Handling Crane (MHC) Boom Down Does Not Operate From Remote Station	2-16
Troop Transport Alarm Does Not Operate	2-31	M1089 Material Handling Crane (MHC) Boom Down Lockout Does Not Activate	2-16
All		M1089 Material Handling Crane (MHC) Boom Up Does Not Operate From Remote Station	2-16
No Air Pressure Present at All M1088 Rear and Fifth Wheel Gladhands	2-21	M1089 Material Handling Crane (MHC) Boom Up Lockout Does Not Activate	2-16
Wrecker Functions Do Not Operate From Wrecker Control Panel	2-16	Brake	
Wrecker Functions Do Not Operate From Wrecker Control Panel and Wrecker Remote Control	2-16	Parking Brake(s) Does Not Release	2-20
Wrecker Functions Do Not Operate From Wrecker Remote Control	2-16	System Loses Air When Brakes Are Applied	2-20
Auxiliary		System Troubleshooting	2-20
M1088/M1089 Transmission Auxiliary Oil Cooler Fan Does Not Operate	2-16		

SUBJECT INDEX (CONT)

Subject	Para	Subject	Para
B (Cont)		C (Cont)	
Brakes		Code (Cont)	
Front Brakes Do Not Apply	2-20	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 52 and Any Sub Code	2-17
Front Brakes Overheat and/or Do Not Release	2-20	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 57 and Any Sub Code	2-17
Rear Brakes Do Not Apply	2-20	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 21 and Any Sub Code	2-17
Rear Brakes Overheat	2-20	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 51 Sub Code 10, 12, 21, 43, 45, or 65	2-17
Vehicle Brakes Unevenly, Brakes Pull to One Side or Grab	2-20	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 25 and Any Sub Code	2-17
Braking		WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 53 and Any Sub Code	2-17
Excessive Braking Distance	2-20	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 54 Sub Code 01, 07, 10, 12, 17, 21, 23, 27, 32, 34, 43, 45, 54, 56, 65, 70, 71, 72, 80, 81, 82, 83, 85, 86, 92, 93, 95, 96, or 97	2-17
C		WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 55 and Any Sub Code	2-17
Central		WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 56 and Any Sub Code	2-17
Tire Inflation System (CTIS) Does Not Deflate Tires	2-16	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 13 and Any Sub Code	2-17
Tire Inflation System (CTIS) Does Not Inflate Tires	2-16	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 23 and Any Sub Code	2-17
Tire Inflation System (CTIS) Does Not Operate	2-16	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Does Not Illuminate	2-17
Code		WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 14	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Emits Eight Seconds of Beeps and/or Transmission Does Not Shift Gears	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 15	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 14	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 16	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 15	2-17		
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 16	2-17		
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 24 and/or 33 and Any Sub Code	2-17		
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 32 and Any Sub Code	2-17		
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 41, 42, 44, 45, 66, and/or 69 and Any Sub Code	2-17		
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 43 and Any Sub Code	2-17		

Subject	Para
C (Cont)	
Code (Cont)	
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 24 and/or 33 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 32 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 42, 44, 45, 46, 66, and/or 69 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 52 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 57 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 21 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 51 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 25 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 53 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 54 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 55 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 56 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 13 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Indicator Displays "--" and/or Transmission Does Not Shift Gears	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 23 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Does Not Illuminate	2-17

Subject	Para
C (Cont)	
Compressor	
Noisy Air Compressor Operation	2-21
Cooler	
M1088/M1089 Transmission Auxiliary Oil Cooler Fan Does Not Operate	2-16
Transmission Auxiliary Oil Cooler Fan Does Not Operate (All Models Except M1088/M1089)	2-16
Transmission Auxiliary Oil Cooler Fan Runs Constantly	2-16
CTIS	
Central Tire Inflation System (CTIS) Does Not Deflate Tires	2-16
Central Tire Inflation System (CTIS) Does Not Inflate Tires	2-16
Central Tire Inflation System (CTIS) Does Not Operate	2-16
D	
Deflate	
Central Tire Inflation System (CTIS) Does Not Deflate Tires	2-16
Differential Lock Solenoid Does Not Operate	2-16
Dryer	
Air Dryer Does Not Operate (All Models Except M1090/M1094)	2-16
Air Dryer Purges Constantly	2-21
M1090/M1094 Air Dryer Does Not Operate	2-16
Dump	
M1090/M1094 DUMP Body Does Not Raise	2-16
M1090/M1094 DUMP Body Does Not Lower	2-16
E	
Electrical	
System Does Not Maintain a Charge	2-16
System Troubleshooting	2-16
EMERGENCY	
No Air Pressure Present at M1088 Rear and/or Fifth Wheel EMERGENCY Gladhands	2-21
Engine Fan Does Not Turn Off Using Radiator Fan Off Switch	2-16
Fan Runs Constantly	2-16
Ether	
Start Does Not Operate	2-16

SUBJECT INDEX (CONT)

Subject	Para	Subject	Para
E (Cont)		H	
Excessive		Handbrake	
Braking Distance	2-20	M1088 Trailer Handbrake Control Does	
Condensation in Fuel	2-16	Not Operate	2-21
F		Hoist	
Fan		M1084/M1086 Material Handling	
Engine Fan Does Not Turn Off Using		Crane Hoist Down Does Not Operate	
Radiator Fan Off Switch	2-16	From Remote Station	2-16
Engine Fan Runs Constantly	2-16	M1084/M1086 Material Handling	
M1088/M1089 Transmission Auxiliary		Crane Hoist Up Does Not Operate	
Oil Cooler Fan Does Not Operate	2-16	From Remote Station	2-16
Transmission Auxiliary Oil Cooler Fan		M1084/M1086 Material Handling	
Does Not Operate (All Models Except		Crane Hoist Up Lockout Does	
M1088/M1089)	2-16	Not Activate	2-16
Transmission Auxiliary Oil Cooler		M1089 Material Handling Crane	
Fan Runs Constantly	2-16	Hoist Down Does Not Operate From	
Fifth Wheel		Remote Station	2-16
No Air Pressure Present at All M1088		M1089 Material Handling Crane	
Rear and Fifth Wheel Gladhands	2-21	Hoist Up Does Not Operate From	
No Air Pressure Present at M1088 Rear		Remote Station	2-16
and/or Fifth Wheel EMERGENCY		M1089 Material Handling Crane	
Gladhands	2-21	Hoist Up Lockout Does Not Activate	2-16
No Air Pressure Present at M1088 Rear		Hydraulic	
and/or Fifth Wheel SERVICE Gladhands	2-21	Loss of Hydraulic Pressure (Single Stage	
Freespool		Pump)	2-23
Main Winch LH or RH FREESPOOL		Loss of Hydraulic Pressure (Three Stage	
Switch Does Not Operate From		Pump)	2-23
Wrecker Control Panel	2-16	System Troubleshooting	2-23
Front		I	
Brakes Do Not Apply	2-20	Inflate	
Brakes Overheat and/or Do		Central Tire Inflation System (CTIS)	
Not Release	2-20	Does Not Inflate Tires	2-16
G		Inflation	
Gladhands		Central Tire Inflation System (CTIS)	
No Air Pressure Present At Rear		Does Not Deflate Tires	2-16
Gladhand(s) (All Models Except		Central Tire Inflation System (CTIS)	
M1088)	2-21	Does Not Inflate Tires	2-16
No Air Pressure Present at All M1088 Rear		Central Tire Inflation System (CTIS)	
and Fifth Wheel Gladhands	2-21	Does Not Operate	2-16
No Air Pressure Present at M1088 Rear		J	
and/or Fifth Wheel EMERGENCY		Joints	
Gladhands	2-21	Drive Shaft or Universal Joint	
No Air Pressure Present at M1088 Rear		Unusually Noisy When Operating	2-18
and/or Fifth Wheel SERVICE			
Gladhands	2-21		

Subject Para

L

Large Quantity of Moisture Expelled
 From Air Reservoirs 2-21

Left
 M1088/M1089 LH Worklight Does Not
 Illuminate 2-16

30K Winch Left or Right Freespool
 Function Does Not Operate From
 Wrecker Control Panel 2-16

Loss
 of Hydraulic Pressure (Single Stage
 Pump) 2-23

of Hydraulic Pressure (Three Stage
 Pump) 2-23

Lubrication
 AOAP Sampling Intervals H-3

General H-1

Intervals H-6

Key H-5

Local Views H-8

Locator Views H-7

Notes H-9

Oil Filters H-2

Warranty Hardtime Statement H-4

M

Main Winch LH or RH Speed Switch
 Does Not Operate From Wrecker
 Control Panel 2-16

Material Handling Crane
 M1084/M1086 Material Handling Crane
 (MHC) Boom Down Does Not Operate
 From Remote Station 2-16

M1084/M1086 Material Handling Crane
 (MHC) Boom Down Lockout Does Not
 Activate 2-16

M1084/M1086 Material Handling Crane
 (MHC) Boom Up Does Not Operate From
 Remote Station 2-16

M1084/M1086 Material Handling Crane
 (MHC) Boom Up Lockout Does Not
 Activate 2-16

M1084/M1086 Material Handling Crane
 (MHC) Does Not Operate 2-16

M1084/M1086 Material Handling Crane
 (MHC) Does Not Operate From Remote
 Control 2-16

M1084/M1086 Material Handling Crane
 (MHC) Hoist Down Does Not Operate
 From Remote Station 2-16

Subject Para

M (Cont)

Material Handling Crane (Cont)
 M1084/M1086 Material Handling Crane
 (MHC) Hoist Up Does Not Operate
 From Remote Station 2-16

M1084/M1086 Material Handling Crane
 (MHC) Hoist Up Lockout Does Not
 Activate 2-16

M1084/M1086 Material Handling Crane
 (MHC) Overload Shutdown System
 Does Not Activate 2-16

M1084/M1086 Material Handling Crane
 (MHC) Overload Shutdown System
 Stays Activated 2-16

M1084/M1086 Material Handling Crane
 (MHC) Swing CCW Does Not Operate
 From Remote Station 2-16

M1084/M1086 Material Handling Crane
 (MHC) Swing CW Does Not Operate
 From Remote Station 2-16

M1084/M1086 Material Handling Crane
 (MHC) Telescope In Does Not Operate
 From Remote Station 2-16

M1084/M1086 Material Handling Crane
 (MHC) Telescope Out Does Not
 Operate From Remote Station 2-16

M1084/M1086 Material Handling Crane
 (MHC) Telescope Out Lockout Does
 Not Activate 2-16

M1089 Material Handling Crane (MHC)
 Boom Down Does Not Operate From
 Remote Station 2-16

M1089 Material Handling Crane (MHC)
 Boom Down Lockout Does Not
 Activate 2-16

M1089 Material Handling Crane (MHC)
 Boom Up Does Not Operate From
 Remote Station 2-16

M1089 Material Handling Crane (MHC)
 Boom Up Lockout Does Not
 Activate 2-16

M1089 Material Handling Crane (MHC)
 Does Not Operate 2-16

M1089 Material Handling Crane (MHC)
 Does Not Operate From Remote
 Control 2-16

M1089 Material Handling Crane (MHC)
 Hoist Down Does Not Operate From
 Remote Station 2-16

M1089 Material Handling Crane (MHC)
 Hoist Up Does Not Operate From
 Remote Station 2-16

SUBJECT INDEX (CONT)

Subject	Para	Subject	Para
M (Cont)		M (Cont)	
Material Handling Crane (Cont)		MHC (Cont)	
M1089 Material Handling Crane (MHC)		M1084/M1086 Material Handling Crane	
Hoist Up Lockout Does Not		(MHC) Hoist Up Does Not Operate	
Activate	2-16	From Remote Station	2-16
M1089 Material Handling Crane (MHC)		M1084/M1086 Material Handling Crane	
Overload Shutdown System Does Not		(MHC) Hoist Up Lockout Does Not	
Activate	2-16	Activate	2-16
M1089 Material Handling Crane (MHC)		M1084/M1086 Material Handling Crane	
Overload Shutdown System Stays		(MHC) Overload Shutdown System Does	
Activated	2-16	Not Activate	2-16
M1089 Material Handling Crane (MHC)		M1084/M1086 Material Handling Crane	
Swing CCW Does Not Operate From		(MHC) Overload Shutdown System Stays	
Remote Station	2-16	Activated	2-16
M1089 Material Handling Crane (MHC)		M1084/M1086 Material Handling Crane	
Swing CW Does Not Operate From		(MHC) Swing CCW Does Not Operate	
Remote Station	2-16	From Remote Station	2-16
M1089 Material Handling Crane (MHC)		M1084/M1086 Material Handling Crane	
Telescope In Does Not Operate		(MHC) Swing CW Does Not Operate	
From Remote Station	2-16	From Remote Station	2-16
M1089 Material Handling Crane (MHC)		M1084/M1086 Material Handling Crane	
Telescope Out Does Not Operate		(MHC) Telescope In Does Not Operate	
From Remote Station	2-16	From Remote Station	2-16
M1089 Material Handling Crane (MHC)		M1084/M1086 Material Handling Crane	
Telescope Out Lockout Does		(MHC) Telescope Out Does Not Operate	
Not Activate	2-16	From Remote Station	2-16
MHC		M1084/M1086 Material Handling Crane	
M1084/M1086 Material Handling Crane		(MHC) Telescope Out Lockout Does Not	
(MHC) Boom Down Does Not Operate		Activate	2-16
From Remote Station	2-16	M1089 Material Handling Crane (MHC)	
M1084/M1086 Material Handling Crane		Boom Down Does Not Operate From	
(MHC) Boom Down Lockout Does Not		Remote Station	2-16
Activate	2-16	M1089 Material Handling Crane (MHC)	
M1084/M1086 Material Handling Crane		Boom Down Lockout Does Not	
(MHC) Boom Up Does Not Operate From		Activate	2-16
Remote Station	2-16	M1089 Material Handling Crane (MHC)	
M1084/M1086 Material Handling Crane		Boom Up Does Not Operate From	
(MHC) Boom Up Lockout Does Not		Remote Station	2-16
Activate	2-16	M1089 Material Handling Crane (MHC)	
M1084/M1086 Material Handling Crane		Boom Up Lockout Does Not Activate	2-16
(MHC) Does Not Operate	2-16	M1089 Material Handling Crane (MHC)	
M1084/M1086 Material Handling Crane		Does Not Operate	2-16
(MHC) Does Not Operate From Remote		M1089 Material Handling Crane (MHC)	
Control	2-16	Does Not Operate From Remote	
M1084/M1086 Material Handling Crane		Control	2-16
(MHC) Hoist Down Does Not Operate		M1089 Material Handling Crane (MHC)	
From Remote Station	2-16	Hoist Down Does Not Operate From	
		Remote Station	2-16

Subject Para

M (Cont)

MHC (Cont)

M1089 Material Handling Crane (MHC)
Hoist Up Does Not Operate From
Remote Station 2-16

M1089 Material Handling Crane (MHC)
Hoist Up Lockout Does Not Activate 2-16

M1089 Material Handling Crane (MHC)
Overload Shutdown System Does Not
Activate 2-16

M1089 Material Handling Crane (MHC)
Overload Shutdown System Stays
Activated 2-16

M1089 Material Handling Crane (MHC)
Swing CCW Does Not Operate From
Remote Station 2-16

M1089 Material Handling Crane (MHC)
Swing CW Does Not Operate From
Remote Station 2-16

M1089 Material Handling Crane (MHC)
Telescope In Does Not Operate
From Remote Station 2-16

M1089 Material Handling Crane (MHC)
Telescope Out Does Not Operate
From Remote Station 2-16

M1089 Material Handling Crane (MHC)
Telescope Out Lockout Does
Not Activate 2-16

M1088

No Air Pressure Present At Rear
Gladhand(s) (All Models Except
M1088) 2-21

No Air Pressure Present at All M1088
Rear and Fifth Wheel Gladhands 2-21

No Air Pressure Present at M1088 Rear
and/or Fifth Wheel EMERGENCY
Gladhands 2-21

No Air Pressure Present at M1088 Rear
and/or Fifth Wheel SERVICE Gladhands . . . 2-21

Trailer Handbrake Control Does Not
Operate 2-21

M1088/M1089

LH Worklight Does Not Illuminate 2-16

RH Worklight Does Not Illuminate 2-16

Transmission Auxiliary Oil Cooler Fan
Does Not Operate 2-16

Transmission Auxiliary Oil Cooler Fan
Does Not Operate (All Models Except
M1088/M1089) 2-16

Worklights Do Not Illuminate 2-16

Subject Para

M (Cont)

M1088/M1089 (Cont)

Worklights Do Not Illuminate In
Blackout Mode With Blackout Override
Switch On 2-16

M1089 LH or RH 30K Winch Does
Not Pay-In 2-16

M1090/M1094

Air Dryer Does Not Operate 2-16

Dump Body Does Not Raise 2-16

Dump Body Does Not Lower 2-16

Tailgate Release Does Not Operate 2-16

N

No Air Pressure or Low Air Pressure
Present At Rear Gladhands 2-21

Noisy Air Compressor Operation 2-21

Subject Para

O

Oil

M1088/M1089 Transmission Auxiliary
Oil Cooler Fan Does Not Operate 2-16

Transmission Auxiliary Oil Cooler Fan
Does Not Operate (All Models Except
M1088/M1089) 2-16

Transmission Auxiliary Oil Cooler Fan
Runs Constantly 2-16

One Wrecker Function Does Not Operate
From Wrecker Remote Control 2-16

Overheat

Front Brakes Overheat and/or Do
Not Release 2-20

Rear Brakes Overheat 2-20

Overload

M1084/M1086 Material Handling Crane
(MHC) Overload Shutdown System
Does Not Activate 2-16

M1084/M1086 Material Handling Crane
(MHC) Overload Shutdown System Stays
Activated 2-16

M1089 Material Handling Crane (MHC)
Overload Shutdown System Does Not
Activate 2-16

M1089 Material Handling Crane (MHC)
Overload Shutdown System Stays
Activated 2-16

SUBJECT INDEX (CONT)

Subject	Para	Subject	Para
P		R (Cont)	
Pay		Rear (Cont)	
15K Self-Recovery Winch (SRW) Does Not Reel In or Pay Out	2-16	No Air Pressure Present At Rear Gladhand(s) (All Models Except M1088)	2-21
15K Self-Recovery Winch (SRW) Does Not Pay Out	2-16	No Air Pressure Present at All M1088 Rear and Fifth Wheel Gladhands	2-21
M1089 LH or RH 30K Winch Does Not Pay-In	2-16	No Air Pressure Present at M1088 Rear and/or Fifth Wheel EMERGENCY Gladhands	2-21
Power		No Air Pressure Present at M1088 Rear and/or Fifth Wheel SERVICE Gladhands	2-21
Take-Off (PTO) Does Not Engage	2-19	Reel	
Take-Off (PTO) Does Not Operate	2-16	15K Self-Recovery Winch (SRW) Does Not Reel In	2-16
Take-Off (PTO) Troubleshooting	2-19	15K Self-Recovery Winch (SRW) Does Not Reel In or Pay Out	2-16
Pressure		Remote	
Air System Loses Pressure During Operation/Slow, No, or Incorrect Air Pressure Buildup	2-21	One Wrecker Function Does Not Operate From Wrecker Remote Control	2-16
Air System Pressure Builds Up More Than 120 psi (827 kPa) (Compressor Fails to Unload)	2-21	Reservoirs	
Loss of Hydraulic Pressure (Single Stage Pump)	2-23	Large Quantity of Moisture Expelled From Air Reservoirs	2-21
Loss of Hydraulic Pressure (Three Stage Pump)	2-23	Right	
No Air Pressure or Low Air Pressure Present at Rear Gladhands	2-21	30K Winch Left or Right Freespool Function Does Not Operate From Wrecker Control Panel	2-16
Propeller Shaft Troubleshooting	2-18	M1088/M1089 RH Worklight Does Not Illuminate	2-16
PTO		S	
Power Take-Off (PTO) Does Not Engage	2-19	Self-Recovery	
Power Take-Off (PTO) Does Not Operate	2-16	15K Self-Recovery Winch (SRW) Does Not Reel In or Pay Out	2-16
Power Take Off (PTO) Troubleshooting	2-19	15K Self-Recovery Winch (SRW) Does Not Pay Out	2-16
Pump		15K Self-Recovery Winch (SRW) Does Not Reel In	2-16
Loss of Hydraulic Pressure (Single Stage Pump)	2-23	Shaft	
Loss of Hydraulic Pressure (Three Stage Pump)	2-23	Drive Shaft or Universal Joint Unusually Noisy When Operating	2-18
Pushbutton		Propeller Shaft Troubleshooting	2-18
Start Inhibit Pushbutton Does Not Operate	2-16	Shift	
R		WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 13 and Any Sub Code	2-17
Radio Does Not Operate	2-16		
Rear			
Brakes Do Not Apply	2-20		
Brakes Overheat	2-20		

SUBJECT INDEX

Subject	Para	Subject	Para
S (Cont)		S (Cont)	
Shift (Cont)		Shift (Cont)	
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 21 and Any Sub Code	2-17	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 56 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 14	2-17	WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 57 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 15	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 13 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 16	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 21 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 24 and/or 33 and Any Sub Code	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 14	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 25 and Any Sub Code	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 15	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 32 and Any Sub Code	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 16	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 41, 42, 44, 45, 66, and/or 69 and Any Sub Code	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 24 and/or 33 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 43 and Any Sub Code	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 25 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 51 Sub Code 10, 12, 21, 43, 45, or 65	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 32 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 52 and Any Sub Code	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 41, 42, 44, 45, 46, 66, and/or 69 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 53 and Any Sub Code	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 43 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 54 Sub Code 01, 07, 10, 12, 17, 21, 23, 27, 32, 34, 43, 45, 54, 56, 65, 70, 71, 72, 80, 81, 82, 83, 85, 86, 92, 93, 95, 96, or 97	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 51 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 55 and Any Sub Code	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 52 and Any Sub Code	2-17
		WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 53 and Any Sub Code	2-17
		WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 54 and Any Sub Code	2-17

SUBJECT INDEX (CONT)

Subject	Para	Subject	Para
S (Cont)		S (Cont)	
Shift (Cont)		Swing (Cont)	
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 55 and Any Sub Code	2-17	M1089 Material Handling Crane (MHC) Swing CCW Does Not Operate From Remote Station	2-16
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 56 and Any Sub Code	2-17	M1089 Material Handling Crane (MHC) Swing CW Does Not Operate From Remote Station	2-16
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 57 and Any Sub Code	2-17	Switch	
Shutdown		M1088/M1089 Worklights Do Not Illuminate In Blackout Mode With Blackout Override Switch On	2-16
M1084/M1086 Material Handling Crane (MHC) Overload Shutdown System Does Not Activate	2-16	Main Winch LH or RH Speed Switch Does Not Operate From Wrecker Control Panel	2-16
M1084/M1086 Material Handling Crane (MHC) Overload Shutdown System Stays Activated	2-16	System	
M1089 Material Handling Crane (MHC) Overload Shutdown System Does Not Activate	2-16	Air System Loses Pressure During Operation/Slow, No, or Incorrect Air Pressure Buildup	2-21
M1089 Material Handling Crane (MHC) Overload Shutdown System Stays Activated	2-16	Air System Troubleshooting	2-21
Solenoid		Brake System Loses Air When Brakes Are Applied	2-20
Differential Lock Solenoid Does Not Operate	2-16	Brake System Troubleshooting	2-20
Speed		Central Tire Inflation System (CTIS) Does Not Deflate Tires	2-16
Main Winch LH or RH Speed Switch Does Not Operate From Wrecker Control Panel	2-16	Central Tire Inflation System (CTIS) Does Not Inflate Tires	2-16
SRW		Central Tire Inflation System (CTIS) Does Not Operate	2-16
15K Self-Recovery Winch (SRW) Does Not Reel In or Pay Out	2-16	Electrical System Does Not Maintain a Charge	2-16
15K Self-Recovery Winch (SRW) Does Not Pay Out	2-16	Electrical System Troubleshooting	2-16
15K Self-Recovery Winch (SRW) Does Not Reel In	2-16	Hydraulic System Troubleshooting	2-23
Start		M1089 Material Handling Crane (MHC) Overload Shutdown System Does Not Activate	2-16
Ether Start Does Not Operate	2-16	M1089 Material Handling Crane (MHC) Overload Shutdown System Stays Activated	2-16
Inhibit Pushbutton Does Not Operate	2-16	Transmission System Troubleshooting	2-17
Swing		T	
M1084/M1086 Material Handling Crane (MHC) Swing CCW Does Not Operate From Remote Station	2-16	Tailgate	
M1084/M1086 Material Handling Crane (MHC) Swing CW Does Not Operate From Remote Station	2-16	M1090/M1094 Tailgate Release Does Not Operate	2-16

Subject	Para
T (Cont)	
Telescope	
M1084/M1086 Material Handling Crane (MHC) Telescope In Does Not Operate From Remote Station	2-16
M1084/M1086 Material Handling Crane (MHC) Telescope Out Does Not Operate From Remote Station	2-16
M1084/M1086 Material Handling Crane (MHC) Telescope Out Lockout Does Not Activate	2-16
M1089 Material Handling Crane (MHC) Telescope In Does Not Operate From Remote Station	2-16
M1089 Material Handling Crane (MHC) Telescope Out Does Not Operate From Remote Station	2-16
M1089 Material Handling Crane (MHC) Telescope Out Lockout Does Not Activate	2-16
Tester	
Battery Tester Does Not Operate	2-16
Tire	
Central Tire Inflation System (CTIS) Does Not Deflate Tires	2-16
Central Tire Inflation System (CTIS) Does Not Inflate Tires	2-16
Central Tire Inflation System (CTIS) Does Not Operate	2-16
Tires Wear Unevenly or Excessively	2-22
Trailer	
M1088 Trailer Handbrake Control Does Not Operate	2-21
Transmission	
Auxiliary Oil Cooler Fan Does Not Operate (All Models Except M1088/M1089)	2-16
Auxiliary Oil Cooler Fan Runs Constantly	2-16
M1088/M1089 Transmission Auxiliary Oil Cooler Fan Does Not Operate	2-16
System Troubleshooting	2-17
Unusually Noisy When Operating	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 13 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 21 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 14	2-17

Subject	Para
T (Cont)	
Transmission (Cont)	
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 15	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 22 Sub Code 16	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 24 and/or 33 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 25 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 32 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 41, 42, 44, 45, 66, and/or 69 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 43 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 51 Sub Code 10, 12, 21, 43, 45, or 65	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 52 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 53 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 54 Sub Code 01, 07, 10, 12, 17, 21, 23, 27, 32, 34, 43, 45, 54, 56, 65, 70, 71, 72, 80, 81, 82, 83, 85, 86, 92, 93, 95, 96, or 97	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 55 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 56 and Any Sub Code	2-17
WTEC II Transmission ECU Pushbutton Shift Selector (TEPSS) Displays Main Code 57 and Any Sub Code	2-17

SUBJECT INDEX (CONT)

Subject	Para	Subject	Para
T (Cont)		T (Cont)	
Transmission (Cont)		Transmission (Cont)	
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 13 and Any Sub Code	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 56 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 21 and Any Sub Code	2-17	WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 57 and Any Sub Code	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 14	2-17	Troubleshooting	
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 15	2-17	Air System Troubleshooting	2-21
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 22 Sub Code 16	2-17	Brake System Troubleshooting	2-20
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 24 and/or 33 and Any Sub Code	2-17	Electrical System Troubleshooting	2-16
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 25 and Any Sub Code	2-17	Hydraulic System Troubleshooting	2-23
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 32 and Any Sub Code	2-17	Power Take Off (PTO) Troubleshooting	2-19
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 41, 42, 44, 45, 46, 66, and/or 69 and Any Sub Code	2-17	Propeller Shaft Troubleshooting	2-18
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 43 and Any Sub Code	2-17	Transmission System Troubleshooting	2-17
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 51 and Any Sub Code	2-17	Wheel Troubleshooting	2-22
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 52 and Any Sub Code	2-17		
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 53 and Any Sub Code	2-17	U	
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 54 and Any Sub Code	2-17	Universal	
WTEC III Transmission Pushbutton Shift Selector (TPSS) Displays Main Code 55 and Any Sub Code	2-17	Drive Shaft or Universal Joint	
		Unusually Noisy When Operating	2-18
		V	
		Vehicle Brakes Unevenly, Brakes Pull to One Side or Grab	2-20
		W	
		Wheel	
		Troubleshooting	2-22
		Wobbles or Shimmies	2-22
		Winch	
		15K Self-Recovery Winch (SRW) Does Not Reel In or Pay Out	2-16
		15K Self-Recovery Winch (SRW) Does Not Pay Out	2-16
		15K Self-Recovery Winch (SRW) Does Not Reel In	2-16
		Main Winch LH or RH Speed Switch Does Not Operate From Wrecker Control Panel	2-16
		M1089 LH or RH 30K Winch Does Not Pay-In	2-16

Subject Para

W (Cont)

Worklight

- M1088/M1089 LH Worklight Does Not
Illuminate 2-16
- M1088/M1089 RH Worklight Does Not
Illuminate 2-16

Worklights

- M1084/M1086 Worklights Do Not
Illuminate 2-16
- M1088/M1089 Worklights Do Not
Illuminate 2-16
- M1088/M1089 Worklights Do Not
Illuminate In Blackout Mode With
Blackout Override Switch On 2-16

Wrecker

- 30K Winch Left or Right Freespool
Function Does Not Operate From
Wrecker Control Panel 2-16
- 30K Winch Left or Right Speed
Function Does Not Operate From
Wrecker Control Panel 2-16
- All Wrecker Functions Do Not Operate
From Wrecker Control Panel 2-16
- All Wrecker Functions Do Not Operate
From Wrecker Control Panel and
Wrecker Remote Control 2-16
- All Wrecker Functions Do Not Operate
From Wrecker Remote Control 2-16
- One Wrecker Function Does Not
Operate From Wrecker Remote
Control 2-16
- Main Winch LH or RH Speed Switch
Does Not Operate From Wrecker
Control Panel 2-16

GLOSSARY ABBREVIATIONS

ANSI	American National Standards Institute
CCW	Counterclockwise
CTIS	Central Tire Inflation System
CW	Clockwise
ECU	Electronic Control Unit
EMI	Electromagnetic Interference
LED	Light Emitting Diode
LH	Left Hand
LMHC	Light Material Handling Crane
MAC	Maintenance Allocation Chart
MHC	Material Handling Crane
NATO	North Atlantic Treaty Organization
NBC	Nuclear, Biological, or Chemical
NO/NC	Normally Open/Normally Closed
O/R	Outrigger
PDP	Power Distribution Panel
PMCS	Preventive Maintenance Checks and Services
PTO	Power Takeoff
RH	Right Hand
SAE	Society of Automotive Engineers
SRW	Self-Recovery Winch
STE/ICE-R	Simplified Test Equipment/Internal Combustion Engine-Reprogrammable
TEPSS	Transmission ECU Pushbutton Shift Selector
TM	Technical Manual
TPS	Thottle Position Sensor


GLOSSARY ABBREVIATIONS (CONT)

TPSS	Transmission Pushbutton Shift Selector
VDC	Volts Direct Current
VIM	Vehicle Interface Module
WTEC II	World Transmission Electronic Controls (version 2)
WTEC III	World Transmission Electronic Controls (version 3)

By Order of the Secretary of the Army:

DENNIS J. REIMER
General, United States Army
Chief of Staff

Official:


JOEL B. HUDSON
Administrative Assistant to the
Secretary of the Army
05189

DISTRIBUTION: To be distributed in accordance with the initial distribution number (IDN) 380940, requirements for TM 9-2320-366-20-2.

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS For use of this form, see AR 25-30; the proponent agency is OAASA	Use Part II (reverse) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE Date you filled out this form
---	---	---------------------------------------

TO: (Forward to proponent of publication or form) (Include ZIP Code)	FROM: (Activity and location) (Include ZIP Code) Enter your mailing address
---	---

PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS

PUBLICATION/FORM NUMBER	DATE Publication Date	TITLE Publication Title
-------------------------	--------------------------	----------------------------

ITEM	PAGE	PARA-GRAPH	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON
10	15-33	15-7		4		<p>Item 10. Change Illustration. Reason: Text calls out 90-degree fitting. Art shows straight fitting. Text is correct.</p> <p>Step (4) of removal says to disconnect four hydraulic hoses from manifold. The correct number of hydraulic hoses is five. correct the text to reflect the actual quantity of hydraulic hoses. The supporting illustration is correct.</p>
	19-6	19-2				

* Reference to line numbers within the paragraph or subparagraph.

TYPED NAME, GRADE OR TITLE Your title	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION Your telephone number	SIGNATURE Your signature
--	---	---------------------------------

TO: <i>(Forward direct to addressee listed in publication)</i>	FROM: <i>(Activity and location) (Include ZIP Code)</i>	DATE
Enter your mailing address		Date you filled out this form.

PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER			DATE				TITLE	
			Publication Date				Your Title	
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION
<div style="font-size: 100px; opacity: 0.1; transform: rotate(-30deg); pointer-events: none;"> SAMPLE </div>								

PART III - REMARKS *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE
Your title	Your telephone number	Your signature

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS						Use Part II (<i>reverse</i>) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE
For use of this form, see AR 25-30; the proponent agency is OAASA							
TO: (<i>Forward to proponent of publication or form</i>) (<i>Include ZIP Code</i>)				FROM: (<i>Activity and location</i>) (<i>Include ZIP Code</i>)			
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER						DATE	TITLE
ITEM	PAGE	PARA- GRAPH	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON	
<i>* Reference to line numbers within the paragraph or subparagraph.</i>							
TYPED NAME, GRADE OR TITLE					TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE

TO: <i>(Forward direct to addressee listed in publication)</i>	FROM: <i>(Activity and location) (Include ZIP Code)</i>	DATE
---	--	-------------

PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER			DATE		TITLE			
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

PART III - REMARKS *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE
----------------------------	--	-----------

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS						Use Part II (<i>reverse</i>) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE
For use of this form, see AR 25-30; the proponent agency is OAASA							
TO: (<i>Forward to proponent of publication or form</i>) (<i>Include ZIP Code</i>)				FROM: (<i>Activity and location</i>) (<i>Include ZIP Code</i>)			
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER						DATE	TITLE
ITEM	PAGE	PARA-GRAPH	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON	
<i>* Reference to line numbers within the paragraph or subparagraph.</i>							
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE	

TO: <i>(Forward direct to addressee listed in publication)</i>	FROM: <i>(Activity and location) (Include ZIP Code)</i>	DATE
---	--	-------------

PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER			DATE		TITLE			
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

PART III - REMARKS *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE
----------------------------	--	-----------

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS						Use Part II (<i>reverse</i>) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE
For use of this form, see AR 25-30; the proponent agency is OAASA							
TO: (<i>Forward to proponent of publication or form</i>) (<i>Include ZIP Code</i>)				FROM: (<i>Activity and location</i>) (<i>Include ZIP Code</i>)			
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER						DATE	TITLE
ITEM	PAGE	PARA- GRAPH	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON	
<i>* Reference to line numbers within the paragraph or subparagraph.</i>							
TYPED NAME, GRADE OR TITLE					TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE

TO: <i>(Forward direct to addressee listed in publication)</i>	FROM: <i>(Activity and location) (Include ZIP Code)</i>	DATE
---	--	-------------

PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER			DATE		TITLE			
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

PART III - REMARKS *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE
----------------------------	--	-----------

10		11		12		13		14		15		16		17		18	
CONNECTOR		CONNECTOR (CONTINUED)		CONNECTOR (CONTINUED)		CONNECTOR (CONTINUED)		CONNECTOR (CONTINUED)		CONNECTOR (CONTINUED)		CONNECTOR (CONTINUED)		CONNECTOR (CONTINUED)		CONNECTOR (CONTINUED)	
NUMBER	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE	ZONE
DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION
101	A01	A02	A03	A04	A05	A06	A07	A08	A09	A10	A11	A12	A13	A14	A15	A16	A17
102	B01	B02	B03	B04	B05	B06	B07	B08	B09	B10	B11	B12	B13	B14	B15	B16	B17
103	C01	C02	C03	C04	C05	C06	C07	C08	C09	C10	C11	C12	C13	C14	C15	C16	C17
104	D01	D02	D03	D04	D05	D06	D07	D08	D09	D10	D11	D12	D13	D14	D15	D16	D17
105	E01	E02	E03	E04	E05	E06	E07	E08	E09	E10	E11	E12	E13	E14	E15	E16	E17
106	F01	F02	F03	F04	F05	F06	F07	F08	F09	F10	F11	F12	F13	F14	F15	F16	F17
107	G01	G02	G03	G04	G05	G06	G07	G08	G09	G10	G11	G12	G13	G14	G15	G16	G17
108	H01	H02	H03	H04	H05	H06	H07	H08	H09	H10	H11	H12	H13	H14	H15	H16	H17

FIGURE FO-1 ELECTRICAL SYSTEM SCHEMATIC FOLDOUT 2 OF 40

FF-3/ (FF-4) BLANK

FF-3/ (FF-4) BLANK

FF-3/ (FF-4) BLANK

FF-3/ (FF-4) BLANK

19		20		21		22		23		24		25		26		27			
CONSTRUCTORS (CONTINUED)		LIGHTS (CONTINUED)		LIGHTS (CONTINUED)		LIGHTS (CONTINUED)		LIGHTS (CONTINUED)		CIRCUIT BREAKERS (CONTINUED)		CIRCUIT BREAKERS (CONTINUED)		TERMINAL LUGS (CONTINUED)		TERMINAL LUGS (CONTINUED)			
NUMBER	ZONE (H) DESCRIPTION	NUMBER	ZONE (H) DESCRIPTION	NUMBER	ZONE (H) DESCRIPTION	NUMBER	ZONE (H) DESCRIPTION	NUMBER	ZONE (H) DESCRIPTION	NUMBER	ZONE (H) DESCRIPTION	NUMBER	ZONE (H) DESCRIPTION	NUMBER	ZONE (H) DESCRIPTION	NUMBER	ZONE (H) DESCRIPTION		
D581	D581 26 CAB - DASH - LEFT - INSTRUMENT PANEL	D581	D581 26 CAB - DASH - LEFT - INSTRUMENT PANEL	D581	D581 26 CAB - DASH - LEFT - INSTRUMENT PANEL	D581	D581 26 CAB - DASH - LEFT - INSTRUMENT PANEL	D581	D581 26 CAB - DASH - LEFT - INSTRUMENT PANEL	D581	D581 26 CAB - DASH - LEFT - INSTRUMENT PANEL	D581	D581 26 CAB - DASH - LEFT - INSTRUMENT PANEL	D581	D581 26 CAB - DASH - LEFT - INSTRUMENT PANEL	D581	D581 26 CAB - DASH - LEFT - INSTRUMENT PANEL	D581	D581 26 CAB - DASH - LEFT - INSTRUMENT PANEL

FIGURE FO-1 ELECTRICAL SYSTEM SCHEMATIC FOLDOUT 3 of 40

ILL. NO. SWD00L38 FF-5J (FF-6 BLANK)




FIGURE FO-1 ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 8 OF 40
 CASE B ILL. NO. 6WD0035B FF-35 (FF-18 BLANK)




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC FOLDOUT 14 OF 40

REV B ILL. NO. 8WD0029A FF-27/FF-28 BLANK




FIGURE FO-1 ELECTRICAL SYSTEM SCHEMATIC FOLDOUT 17 OF 40




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDDOUT 19 OF 40
 163 164 165 166 167 168 169 170 171





FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC FOLDOUT 21 OF 40






FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC FOLDOUT 24 OF 40




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDDOUT 25 OF 40
 655 B LL NO. 6W00020B FF-497 (FF-50 BLANK)




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC FOLDOUT 26 OF 40




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 28 OF 40




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC FOLDDOUT 29 OF 40




FIGURE FO-1 ELECTRICAL SYSTEM SCHEMATIC FOLDOUT 30 OF 40




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 31 OF 40
REV B ILL NO. 6W00028B FF-81/ (FF-82 BLANK) 278 279





FIGURE FO-1 ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 32 OF 40
REV. B ILL. NO. 6WD0027B FP-631/FP-64 BLANK






FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDDOUT 34 OF 40

REV	B	ILL. NO.	6WD00298	306
			FF-57/ (FF-48 BLANK)	306




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 35 OF 40




FIGURE F0-1 ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 37 OF 40
 REF B ILL NO 6WDD082A FF-78/FF-74 BLANK 333




FIGURE FO-1 ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 38 OF 40
REV. B ILL. NO. 6WPD0638B FP-75 (FP-76 BLANK) 342




FIGURE F0-1 ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 39 OF 40





FIGURE FO-1 ELECTRICAL SYSTEM SCHEMATIC
 FOLDDOUT 40 OF 40

REV B ILL NO. 6WPD085B FF-79/ (FF-80 BLANK) 359 360

SH ZONE	DESCRIPTION	SH ZONE	DESCRIPTION
3	E22 AIR BRAKE PRESSURE TRANSMITTER	4	F28 REGULATOR
3	F21 AIR BRAKE PRESSURE TRANSMITTER	8	D28 RELAY VALVE
3	A28 AIR BRAKE PROTECTING VALVE	4	E29 RH MAIN WINCH FREEPOOL
3	F20 AIR COMPRESSOR	4	E30 RH MAIN WINCH TENSIONER
3	F20 AIR DRIVER	4	G33 RH MAIN WINCH VALVE
3	B24 ANTI-COMPONDING VALVE	3	F22 SECONDARY AIR TANK
3	H28 BLEED VALVE	3	B24 SERVICE GLADHAND
3	B21 BOOSTER VALVE	3	D19 SERVICE GLADHAND
4	D30 CONTROL VALVE	4	G30 STINGER VALVE
4	D31 DEFILATE VALVE	3	C20 STOPLIGHT SWITCH
3	H20 DIFFERENTIAL LOCK SOLENOID	3	E21 STOPLIGHT SWITCH
3	G24 DUMP TAILGATE SOLENOID	4	D31 SUPPLY VALVE
3	A25 EMERGENCY GLADHAND	3	B21 SYSTEM PARK SUPPLY VALVE
3	A25 EMERGENCY GLADHAND	3	G25 TAILGATE CYLINDER
3	G28 EMERGENCY GLADHAND	3	A24 THREE WAY BALL VALVE
3	H20 FAN CLUTCH	3	B23 THREE WAY BALL VALVE
3	G20 FAN SOLENOID	3	B22 TRAILER AIR SUPPLY VALVE
3	C22 FOOT CONTROL VALVE	3	A21 TRAILER SERVICE VALVE
3	F20 INTAKE AIR CLEANER	3	D21 TWO WAY CHECK VALVE
3	H18 INTERMEDIATE AXLE DIFFERENTIAL	3	D21 TWO WAY CHECK VALVE
3	E23 INVERSION VALVE	3	E24 TWO WAY CHECK VALVE
3	G25 INVERSION VALVE	4	E30 TWO WAY CHECK VALVE
4	A28 KNEELING VALVE	4	E30 TWO WAY CHECK VALVE
4	C26 KNEELING VALVE	3	F23 TWO WAY CHECK VALVE
4	E28 LH MAIN WINCH FREEPOOL	3	G23 TWO WAY CHECK VALVE
4	E30 LH MAIN WINCH TENSIONER	4	G32 UNDERLIFT FOLD VALVE
4	G29 LH MAIN WINCH VALVE	4	G31 UNDERLIFT VALVE
3	C25 LOAD SENSING VALVE	3	F21 WET TANK
3	E23 LOW PRESSURE SWITCH	4	C34 WHEEL VALVE
3	F21 LOW PRESSURE SWITCH	4	A28 WHEEL VALVE
4	F28 MANFOLD	4	A22 WHEEL VALVE
4	G26 MANFOLD	4	A34 WHEEL VALVE
3	F22 MANUAL VALVE	4	C28 WHEEL VALVE
3	G21 MANUAL VALVE	4	C32 WHEEL VALVE
3	G22 MANUAL VALVE		
3	F22 ONE WAY CHECK VALVE		
3	G20 ONE WAY CHECK VALVE		
3	G22 ONE WAY CHECK VALVE		
3	G21 PRESSURE PROTECTION VALVE		
3	G22 PRIMARY AIR TANK		
4	B30 QUICK RELEASE VALVE		
4	B33 QUICK RELEASE VALVE		
4	B36 QUICK RELEASE VALVE		
3	C30 QUICK RELEASE VALVE		
4	E30 REGULATOR		
4	E31 REGULATOR		

MTV PNEUMATIC AND CTIS
 FIGURE FO-2. PNEUMATIC SYSTEM SCHEMATIC
 FOLDOUT 2 OF 4
 SEE B ILL. NO. 8FD00AL2 FF-3/FF-4 BLANK




MTV PNEUMATIC AND CTIS
FIGURE FO-2. PNEUMATIC SYSTEM SCHEMATIC
FOLDOUT 3 OF 4
REF B ILL NO 8FD00AG1 FR-5/FR-8 BLANK


SH ZONE	DESCRIPTION	SH ZONE	DESCRIPTION	SH ZONE	DESCRIPTION
6	D46	2 WAY SOLENOID VALVE	6	E54	HYDRAULIC ACCUMULATOR
7	D60	2 WAY SOLENOID VALVE	7	H61	LEFT JACK CYLINDER
7	D55	2 WAY SOLENOID VALVE, OPERATING PRESS	6	H48	LEFT JACK CYLINDER
7	F60	3 BANK VALVE ASSEMBLY	5	G42	LEFT MAIN WINCH
7	G61	4 BANK VALVE ASSEMBLY	7	A61	LIFT CYLINDERS
6	B62	BOOM	6	E48	LIFT CYLINDERS
7	F55	BULK-HEAD PLATE (SUBFRAME)	5	C37	LINEAR DIRECTIONAL CONTROL VALVE
7	F57	CHECK VALVE	5	B42	LOWER MAIN CONTROL VALVE ASSEMBLY
7	G62	CHECK VALVE	5	D37	M089 MATERIAL HANDLING CRANE LOC.
7	D65	CHECK VALVE	6	B51	MANUAL OVERRIDE
5	E37	CHECK VALVE CK1	7	G61	MAST ERECTION
5	E37	CHECK VALVE CK2	7	H69	MAST ERECTION CYLINDER
5	E37	CHECK VALVE CK3	4	C20	MATERIAL HANDLING EQUIPMENT
5	E37	CHECK VALVE CK4	5	E38	MCI SLAVE POWER
5	E37	CHECK VALVE CK5	5	E38	M02 EXTERNAL POWER
5	E37	CHECK VALVE CK6	5	D40	MONO BLOCK VALVE ASSEMBLY
6	E65	CONTROL VALVE	7	G58	MOTOR DRAIN
5	B44	COUNTERBALANCE VALVE	6	G46	MOTOR DRAIN
6	B48	CROSS RELIEF VALVE	6	D54	N/C 2 WAY VALVE
7	C57	CROSS RELIEF VALVE	6	H52	OUTRIGGER EXTENSION CYLINDER
8	E64	DUMP BODY HYDRAULIC HOBT	7	A60	PRESSURE CHECK POINT
6	G48	ERECTION CYLINDER	3	F21	PTO
5	E38	FC1 SLAVE POWER	4	E38	PTO
5	E38	FC2 EXTERNAL POWER	8	G68	PTO
3	F23	FLITER	3	F22	PUMP
4	D24	FLITER	4	E38	PUMP
6	E68	FLITER	8	F68	PUMP
5	B43	FLOW CONTROL VALVE	5	F37	PUMP ASSEMBLY
5	B46	FLOW CONTROL VALVE	5	D41	RELIEF VALVE
5	B43	FOLD CYLINDER	5	E41	RELIEF VALVE
7	G62	FULL FLOW	5	F42	RELIEF VALVE ASSEMBLY
6	G54	GAUGE PORT	5	B42	RELIEF VALVE ASBY (RIGHT MAIN WINCH)
6	E47	HAND PUMP	3	F24	RESERVOIR
7	E56	HAND PUMP	4	F34	RESERVOIR
7	G67	HOBT	8	G69	RESERVOIR
7	A62	HOBT	5	G40	RETURN VALVE
6	B53	HOBT	5	B44	RH UNDERLIFT COUNTERBALANCE VALVE
8	G65	HOBT CYLINDER	7	G62	RIGHT JACK CYLINDER
7	G68	HOBT MOTOR	6	H54	RIGHT JACK CYLINDER
6	G48	HOBT MOTOR	5	B42	RIGHT MAIN WINCH
7	H57	HOBT MOTOR CONTROL VALVE	5	F40	SAMPLING VALVE
6	H46	HOBT MOTOR CONTROL VALVE	3	E24	SELF RECOVERY WINCH
7	H69	HOLDING VALVE	5	G41	SELF RECOVERY WINCH
7	G62	HOLDING VALVE	8	B71	SELF RECOVERY WINCH
6	C47	HOLDING VALVE	5	G43	STIFF LEG CYLINDER LH
6	H53	HOLDING VALVE	5	G45	STIFF LEG CYLINDER RH
7	C55	HOLDING VALVE	5	B45	STINGER CYLINDER
7	G56	HOLDING VALVES	7	F59	SUCTION LINE-HAND PUMP
6	E48	HOLDING VALVES	3	G22	SUCTION LINE
6	G48	HOLDING VALVES	4	F33	SUCTION LINE
5	D41	HYDRAULIC MOTOR, PAY-OUT	5	E37	SUPPLY VALVE
5	E41	HYDRAULIC MOTOR, PAY-OUT	7	A58	SWING
7	A60	HYDRAULIC ACCUMULATOR	6	B50	SWING

FIGURE FO-3 HYDRAULIC SYSTEM SCHEMATIC
FOLDOUT 2 OF 8

REV B 7 16 15 14 13 12 11 10 A B C D E F G H




MTV TRUCK W/WINCH
FIGURE FO-3. HYDRAULIC SYSTEM SCHEMATIC
FOLDOUT 3 OF 8



MTV MATERIAL HANDLING CRANE

FIGURE FO-3. HYDRAULIC SYSTEM SCHEMATIC
FOLDOUT 4 OF 8



MTV WRECKER

FIGURE FO-3 HYDRAULIC SYSTEM SCHEMATIC
FOLDOUT 5 OF 8

REF B ILL NO. 6F201A03

FF-9/FF-10 BLANK

44

43

42

41

40

39

38

37

45

44

43

42

41

40

39

38

37

45

44

43

42

41

40

39

38

37

45

44

43

42


41

40

39



38

37



MTV DUMP W/ WINCH
 MTV DUMP W/O WINCH
 FIGURE FO-3. HYDRAULIC SYSTEM SCHEMATIC
 FOLDOUT 8 OF 8

REF	B	ILL. NO.	8ED0A06	FF-57/FP-16	BLANK
-----	---	----------	---------	-------------	-------



SH	ZONE	DESCRIPTION
2	D11	FILTER
2	D14	FIXED RESTRICTOR
2	E7	HYDRAULIC CYLINDER
2	E8	HYDRAULIC PUMP
2	C18	PRESSURE RELIEF VALVE
2	D18	TWO POSITION CONTROL VALVE
2	E16	VARIABLE PRESSURE CONTROL VALVE
2	E16	VARIABLE PRESSURE RELIEF VALVE
2	C11	VENTED RESERVOIR

FIGURE FO-4 HYDRAULIC STEERING SYSTEM
 FOLDOUT 1 OF 2
 SHEET NO. 8
 PARTIAL NO. 8
 PARTIAL NO. 9




FIGURE FO-4 HYDRAULIC STEERING SYSTEM
 FOLDOUT 2 OF 2

REF	B	ILL. NO.	Y8C00A01	FIG-3/FP-4 BLANK
			7	18

BH	ZONE	DESCRIPTION
3	A25	CAB AIR SUSPENSION W/DAMPER
3	F21	CHECK PILOT
3	A22	CHECK VALVE
3	A23	CHECK VALVE
3	B22	CHECK VALVE
3	B23	CHECK VALVE
3	B25	CHECK VALVE
3	C20	CHECK VALVE
3	C21	CHECK VALVE
3	E19	CHECK VALVE
3	E24	CHECK VALVE
3	E25	CHECK VALVE
3	F19	CHECK VALVE
3	F21	CHECK VALVE
3	G21	CHECK VALVE
3	A22	FLTER
3	B22	FLTER
3	A24	FLTER
3	B24	FLTER
3	D19	FLTER
3	D20	FLTER
3	D21	FLTER
3	E19	FLTER
3	G19	FLTER
3	G21	FLTER
3	A22	FIXED RESTRICTOR
3	B22	FIXED RESTRICTOR
3	A23	FIXED RESTRICTOR
3	B23	FIXED RESTRICTOR
3	F19	HAND PUMP
3	B25	HEIGHT CONTROL VALVE
3	B22	HYDRAULIC CYLINDER
3	B23	HYDRAULIC CYLINDER
3	C21	HYDRAULIC CYLINDER
3	F20	MUFFLER
3	F21	PRESSURE INTENSIFIER
3	F19	PRESSURE RELIEF VALVE
3	A24	REAR CAB LATCH
3	E21	THREE POSITION SELECTION VALVE
3	D26	TWO POSITION AIR PUMP VALVE
3	D25	TWO POSITION CAB SUSPENSION VALVE
3	C24	TWO POSITION CAB TILT VALVE
3	C23	TWO POSITION SPARE TIRE VALVE
3	D21	TWO POSITION SUSPENSION VALVE
3	G22	VARIABLE CONTROL CHECK VALVE
3	G22	VENTED RESERVOIR

FIGURE FO-5 AIR TRANSPORTABILITY
HYDRAULIC/PNEUMATIC SYSTEM SCHEMATIC

FOLDOUT 2 OF 3
REF: 7ADDDAL2
FF-31FF-4 BLANK




FIGURE FO-5 AIR TRANSPORTABILITY
HYDRAULIC/PNEUMATIC SYSTEM SCHEMATIC
FOLDOUT 3 OF 3
REF B ALL NO. YADDA001 FF-5/FF-6/BLANK

THE METRIC SYSTEM AND EQUIVALENTS

LINEAR MEASURE

1 Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
 1 Kilometer = 1000 Meters = 0.621 Miles

SQUARE MEASURE

1 Sq Centimeter = 100 Sq Millimeters = 0.155 Sq Inches
 1 Sq Meter = 10,000 Sq Centimeters = 10.76 Sq Feet
 1 Sq Kilometer = 1,000,000 Sq Meters = 0.386 Sq Miles

WEIGHTS

1 Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces
 1 Kilogram = 1000 Grams = 2.2 Lb
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

CUBIC MEASURE

1 Cu Centimeter = 1000 Cu Millimeters = 0.06 Cu Inches
 1 Cu Meter = 1,000,000 Cu Centimeters = 35.31 Cu Feet

LIQUID MEASURE


1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

TEMPERATURE

$5/9 (°F - 32) = °C$
 212° Fahrenheit is equivalent to 100° Celsius
 90° Fahrenheit is equivalent to 32.2° Celsius
 32° Fahrenheit is equivalent to 0° Celsius
 $9/5 C° + 32 = F°$

APPROXIMATE CONVERSION FACTORS

<u>TO CHANGE</u>	<u>TO</u>	<u>MULTIPLY BY</u>	<u>TO CHANGE</u>	<u>TO</u>	<u>MULTIPLY BY</u>
Inches	Centimeters	2.540	Centimeters	Inches	0.394
Inches	Millimeters	25.4	Millimeters	Inches	0.0394
Feet	Meters	0.305	Meters	Feet	3.280
Yards	Meters	0.914	Meters	Yards	1.094
Miles	Kilometers	1.609	Kilometers	Miles	0.621
Square Inches	Square Centimeters	6.451	Sq Centimeters	Square Inches	0.155
Square Feet	Square Meters	0.093	Square Meters	Square Feet	10.764
Square Yards	Square Meters	0.836	Square Meters	Square Yards	1.196
Square Miles	Square Kilometers	2.590	Square Kilometers	Square Miles	0.386
Acres	Square Hectometers	0.405	Sq Hectometers	Acres	2.471
Cubic Feet	Cubic Meters	0.028	Cubic Meters	Cubic Feet	35.315
Cubic Yards	Cubic Meters	0.765	Cubic Meters	Cubic Yards	1.308
Fluid Ounces	Milliliters	29.57	Milliliters	Fluid Ounces	0.034
Pints	Liters	0.473	Liters	Pints	2.113
Quarts	Liters	0.946	Liters	Quarts	1.057
Gallons	Liters	3.785	Liters	Gallons	0.264
Ounces	Grams	28.35	Grams	Ounces	0.035
Pounds	Kilograms	0.454	Kilograms	Pounds	2.205
Pounds (force)	Newtons	4.448	Newtons	Pounds (force)	0.2248
Short Tons	Metric Tons	0.907	Metric Tons	Short Tons	1.102
Pound-Feet	Newton-Meters	1.356	Newton-Meters	Pound-Feet	0.738
Pounds/Sq Inch	Kilopascals	6.895	Kilopascals	Pounds per Sq Inch	0.145
Miles per Gallon	Kilometers per Liter	0.425	Km per Liter	Miles per Gallon	2.354
Miles per Hour	Kilometers per Hour	1.609	Km per Hour	Miles per Hour	0.621



YMET001A

This fine document...

Was brought to you by me:



[Liberated Manuals -- free army and government manuals](#)

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals

– Sincerely
Igor Chudov
<http://igor.chudov.com/>