


TECHNICAL MANUAL

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE VOLUME I

PALLETIZED LOAD SYSTEM



MODEL M1074/M1075

NSN 2320-01-304-2277

NSN 2320-01-304-2278

INTRODUCTION	1-1
VEHICLE MAINTENANCE	2-1
ENGINE TROUBLESHOOTING	-43
TRANSMISSION TROUBLESHOOTING	2-115
AIR SYSTEM TROUBLESHOOTING	2-176
HYDRAULIC SYSTEM TROUBLESHOOTING	2-189
LOAD HANDLING SYSTEM TROUBLESHOOTING	2-246
MATERIAL HANDLING CRANE TROUBLESHOOTING	2-418
SELF-RECOVERY WINCH TROUBLESHOOTING	2-726
STEERING SYSTEM TROUBLESHOOTING	2-744
ARCTIC HEATER (MODEL B) TROUBLESHOOTING	2-766.2
REFERENCES	A-1
EXPENDABLE SUPPLIES AND MATERIALS	B-1
MANUFACTURED ITEMS	C-1
TORQUE LIMITS	D-1
MANDATORY REPLACEMENT PARTS	E-1
TOOL IDENTIFICATION LIST	F-1

DISTRIBUTION RESTRICTION A:
Approved for public release;
distribution is unlimited.

WARNING**CARBON MONOXIDE (EXHAUST GAS) CAN KILL YOU**

Carbon monoxide is a colorless, odorless, DEADLY POISONOUS gas and when breathed deprives body of oxygen and causes SUFFOCATION. Breathing air with carbon monoxide produces symptoms of headache, dizziness, loss of muscular control, a sleepy feeling, and coma. Permanent BRAIN DAMAGE or DEATH can result from severe exposure.

The following precautions MUST be followed to ensure personnel are safe whenever personnel heater or main or auxiliary engine is operated for any purpose.

- DO NOT operate personnel heater or engine of vehicle in enclosed area without adequate ventilation.
- DO NOT idle engine for long periods without ventilator blower operation. If tactical situation permits, open hatches.
- DO NOT drive any vehicle with inspection plates, cover plates, or engine compartment doors removed unless necessary for maintenance purposes.
- NEVER sleep in a vehicle when the heater is operating or the engine is idling.
- BE ALERT at all times during vehicle operation for exhaust odors and exposure symptoms. If either are present, IMMEDIATELY EVACUATE AND VENTILATE the area. Affected personnel treatment shall be: expose to fresh air; keep warm, DO NOT PERMIT PHYSICAL EXERCISE; if necessary, give artificial respiration as described in FM 12-11 and get medical attention.
- BE AWARE; neither the gas particulate filter unit nor field protection mask for nuclear-biological-chemical protection will protect you from carbon monoxide poisoning.

THE BEST DEFENSE AGAINST CARBON MONOXIDE POISONING IS GOOD VENTILATION

WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

WARNING

Blowing transmission oil can cause injury to eyes. Safety goggles must be worn when testing transmission oil pressure switch.

WARNING

Adhesive causes immediate bonding on contact with eyes, skin, or clothing and also gives off harmful vapors. Wear protective goggles and use in well-ventilated area. If adhesive gets in eyes, try to keep eyes open; flush eyes with water for 15 minutes and get immediate medical attention.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

WARNING

During pressure tests, ensure air pressure is drained to 0 psi (0 kPa) before taking off air compressor line or taking off any cover plates. If pressure is not released, plates or line could blow off and harm personnel. Air tanks have greater than 30 psi (207 kPa) in them. Do not drain air tanks with any part of body in air spray path. Skin embolisms and/or debris in eyes can occur from released pressure.

WARNING

Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.

WARNING

All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

WARNING

High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.

WARNING

Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

WARNING

Do not get under LHS when disconnecting or connecting connectors and hoses. A hydraulic malfunction could cause LHS to lower causing serious injury or death.

WARNING

The LHS hydraulic system operates at oil pressures up to 3625 psi (24,994 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.

WARNING

Middle frame and hook arm combined weight is 2100 lbs (953 kg). Hook arm cylinders weigh 210 lbs (95 kg) each. Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.

WARNING

Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.

WARNING

- Drycleaning Solvent (P-D-680) is TOXIC and flammable. Wear protective goggles, face shield, and gloves; use only in a well-ventilated area; avoid contact with skin, eyes, and clothes, and do not breathe vapors. Keep away from heat or flame. Never smoke when using solvent. The flashpoint for Type II Drycleaning Solvent is 140 degrees F (60 degrees C) and Type III Drycleaning Solvent is 200 degrees F (93 degrees C). Failure to do so may result in injury or death to personnel.
- If personnel become dizzy while using cleaning solvent, immediately get fresh air and medical help. If solvent contacts skin or clothes, flush with cold water. If solvent contacts eyes, immediately flush eyes with water and get immediate medical attention.

WARNING

If matchmarks are not aligned during installation of yoke, erratic steering will result. Erratic steering can cause serious injury or death to personnel.

WARNING

Use care when disconnecting intergear link. If it falls, it will cause injury to personnel.

WARNING

The truck steering operates with 3000 psi (20,685 kPa) hydraulic pressure. A high pressure hydraulic oil stream can pierce a body and cause severe injury to personnel. Never disconnect any high pressure hydraulic oil line or fitting without first dropping pressure to zero.

WARNING

Do not stand in front of vehicle when testing air box pressure. Brakes could fail and vehicle could move forward causing injury or death.

WARNING

Do not remove the radiator cap when the engine is hot; steam and hot coolant can escape and burn personnel.

WARNING

Use a clean thick waste cloth or like material to remove the cap. Avoid using gloves. If hot water soaks through gloves, personnel could be burned.

WARNING

Moving engine components can cause severe injury. Keep away from alternator belts and pulleys while engine is running.

WARNING

Never use fuel to clean parts. Fuel is highly flammable. Serious injury to personnel could result if fuel ignites during cleaning.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment (goggles/shield, gloves, etc). Failure to comply may result in injury to personnel.

WARNING

Steam cleaning creates hazardous noise levels and severe burn potential. Eye, skin, and ear protection is required. Failure to comply may result in injury to personnel.

WARNING

Solvents used with a spray gun must be used in a spray booth with filter. Face shield must be used by personnel operating spray gun. Failure to comply may result in injury to personnel.

WARNING

CARC paint contains isocyanate (HDI) which is highly irritating to skin and respiratory system. High concentrations of HDI can produce symptoms of itching and reddening of skin, a burning sensation in throat and nose and watering of the eyes. In extreme concentrations, HDI can cause cough, shortness of breath, pain during respiration, increased sputum production, and chest tightness. The following precautions must be taken whenever using CARC paint:

- ALWAYS use air line respirators when using CARC paint unless air sampling shows exposure to be below standards. Use chemical cartridge respirator if air sampling is below standards.
- DO NOT let skin or eyes come in contact with CARC paint. Always wear protective equipment (gloves, ventilation mask, safety goggles, etc.).
- DO NOT use CARC paint without adequate ventilation.
- NEVER weld or cut CARC-coated materials.
- DO NOT grind or sand painted equipment without high-efficiency air purifying respirators in use.
- BE AWARE of CARC paint exposure symptoms; symptoms can occur a few days after initial exposure. Seek medical help immediately if symptoms are detected.

WARNING

Unsafe welding practices can cause serious injury from fire, explosions, or harmful agents. Allow only authorized personnel to weld or cut metals, and follow safety precautions in TC 9-237. Protective clothing and goggles must be worn; adequate protective equipment used, a suitable fire extinguisher kept nearby, and requirements of TC 9-237 strictly followed.

WARNING

On direct contact, uncured silicone sealant irritates eyes. In case of contact, flush eyes with water and seek medical attention. In case of skin contact, wipe off and flush with water.

WARNING

Engine/transmission assembly weighs 3946 lbs (1791 kg). Attach suitable lifting device of adequate capacity for removal or installation to prevent possible injury to personnel.

WARNING

Use extreme care when installing engine/transmission assembly. Ensure engine/transmission assembly does not swing and damage equipment.

WARNING

Air compressor weighs 115 lbs (52 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Ensure cradle is fully supported upon removal of four screws and lockwashers or cradle may fall and cause injury to personnel.

WARNING

Transmission weighs 1050 lbs (477 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Transmission weighs 1023 lbs (477 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Cylinder head weighs 182 lbs (83 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Use extreme care when removing or installing spring retainers. Spring retainers are under tension and can act as projectiles when released suddenly. Ensure proper eye protection is worn to prevent injury to personnel.

WARNING

Use extreme care when compressing, releasing, removing, or installing springs. Springs are under tension and can act as projectiles when released. Ensure proper eye protection is worn to prevent injury to personnel.

WARNING

Vibration damper may fall from crankshaft and may cause injury to personnel.

WARNING

Ensure there are no personnel working under truck while performing this task. Engine will be supported by lifting device. If lifting device fails, engine may fall and cause severe injury or death to personnel.

WARNING

Lifting device is attached to support engine. Ensure lifting device is positioned snug to engine lifting bracket to prevent engine from falling. Failure to comply may result in injury or death to personnel.

WARNING

Lifting device must remain in place and truck must be properly tagged until after installation of this task is performed. Failure to comply may result in engine falling causing severe injury or death to personnel.

WARNING

Driveshafts can weigh up to 100 lbs (45kg). Properly support driveshafts when removing screws. After screws and brackets are removed, driveshafts can fall and may cause injury to personnel.

WARNING

Use extreme care when removing spring from oil cooler adapter plate. Spring is under tension and can act as a projectile when released. Ensure all personnel wear proper eye protection to prevent possible injury to personnel.

WARNING

Ensure all debris is kept clear of blower during removal. Failure to comply may result in damage to equipment.

WARNING

Blower lobes turn freely. Ensure fingers, jewelry, and hair are kept clear of rotors in blower. Failure to comply may result in severe injury to personnel.

WARNING

Blower weighs 71 lbs (32 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Gloves must be used when handling turbocharger insulation blanket. Turbocharger insulation blanket is made of fiberglass and may cause skin irritation. Failure to comply may result in injury to personnel.

WARNING

Gloves must be used when handling insulation blanket. Insulation blanket is made of fiberglass and may cause skin irritation. Failure to comply may result in injury to personnel.

WARNING

Turbocharger weighs 57 lbs (26 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Use extreme care when turning rotating assembly. Rotating assembly is sharp and injury to personnel may result.

WARNING

Fuel is very flammable and can explode easily. To avoid serious injury or death, keep fuel away from open fire and keep fire extinguisher within easy reach when working with fuel. Do not work on fuel system when engine is hot. Fuel can be ignited by hot engine.

WARNING

Bottom tank assembly weighs 82 lbs (37 kg). Ensure bottom tank is fully supported prior to removal or installation. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Top tank assembly weighs 76 lbs (35 kg). Ensure top tank assembly is fully supported prior to removal or installation. Failure to comply may result in injury to personnel or damage to equipment.

WARNING

Use extreme care when removing tester. Sudden release of pressure can cause injury to personnel.

WARNING

Allow engine to cool before removing harness to avoid injury to personnel.

WARNING

Corrosion compound contains alkali. Do not get in eyes; wear safety goggles/glasses when using. Avoid contact with skin. In case of contact, immediately wash area with soap and water. If eyes are contacted, flush with large amounts of water for at least 15 minutes and get immediate medical attention.

WARNING

Middle frame weighs 2500 lbs (1135 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

After removing wires and cables from battery terminals, ensure no contact is made with battery terminals, other wires, cables or any metal surface to prevent damage to parts, personal injury, or death.

WARNING

Battery acid (electrolyte) is extremely harmful. Always wear safety goggles and rubber gloves, and do not smoke when performing maintenance on batteries. Injury will result if acid contacts skin or eyes. Wear rubber apron to prevent clothing being damaged.

WARNING

Upon installation of all wires and cables, ensure no contact is made with battery terminals or other wires and cables. Strap wires and cables away from battery terminals and other wires and cables as required to prevent damage to parts, personal injury, or death.

WARNING

Do not drain transmission fluid while transmission is hot. Injury to personnel may result.

WARNING

Driveshaft weighs 90 lbs (41 kg). The aid of an assistant is required to prevent possible injury to personnel.

WARNING

Ensure one screw is left in place behind lifting bracket in flywheel. Screw is intended to secure flywheel until lifting device is in place. Failure to comply may result in serious injury to personnel and damage to equipment.

WARNING

Flywheel weighs 175 lbs (79 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

During flywheel removal, torque converter turbine can remain attached to flywheel or remain on transmission. Use care to prevent torque converter turbine from falling. If torque converter turbine stays attached to flywheel, lockup clutch may fall out of transmission. Use care to prevent lockup clutch from falling. Failure to comply may result in serious injury to personnel and damage to equipment may occur.

WARNING

Flywheel weighs 175 lbs (79 kg). Use extreme caution when dropping flywheel. Keep feet and hands out from under flywheel to avoid injury to personnel.

WARNING

Transfer case weighs 1500 lbs (681 kg). Attach lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Remove and install one transfer case support bracket at a time. Removing both transfer case support brackets at same time will cause transfer case to fall causing damage to parts or severe injury or death to personnel.

WARNING

Axle No. 1 and No. 2 weighs 1,950 lbs (885 kg). Use jackstands to support axles. Failure to do so could result in injury to personnel.

WARNING

Torque rod is under extreme pressure when being pressed from axle. Torque rod can be dangerous when it breaks loose and could cause injury to personnel.

WARNING

Axle No. 1 weighs 1950 lbs (885 kg). Attach a transmission jack prior to removal or installation. The axle must be chained to the transmission jack or an out of balance condition may result. Failure to comply may result in serious injury or death to personnel.

WARNING

Keep fingers out of beam holes. Failure to comply could result in serious injury to personnel.

WARNING

Axle No. 2 weighs 1907 lbs (866 kg) (without brake drums). Attach a transmission jack prior to removal or installation. The axle must be chained to the transmission jack or an out of balance condition may result. Failure to comply may result in serious injury or death to personnel.

WARNING

Pivot and spindle assembly weighs 90 lbs (41 kg). Support pivot and spindle assembly prior to removal to prevent possible injury to personnel.

WARNING

Trailing beam assembly weighs 150 lbs (68 kg). Attach a suitable lifting device to axle end of trailing beam assembly prior to removal or installation to prevent possible injury to personnel.

WARNING

Main fuel tank weighs between 50 to 700 lbs (23-318 kg) depending on the quantity of fuel inside. Support main fuel tank with suitable lifting device prior to removing mounting hardware to prevent possible injury to personnel.

WARNING

Axle No. 3 weighs 1780 lbs (808 kg). Attach a suitable lifting device prior to removal or installation to prevent possible injury to personnel. Axle housing must be chained to lifting device to prevent an out of balance condition when longitudinal torque rod is removed. Axle could roll out of control causing serious injury or death to personnel.

WARNING

Ensure axle is fully supported by jackstands prior to removing hydraulic jack from trailing beam assembly. Failure to comply may result in injury to personnel.

WARNING

Keep hands and feet clear of Axle No. 3 until Axle No. 3 is secured by longitudinal torque rod. Failure to comply may result in injury to personnel.

WARNING

Axle No. 4 weighs 1925 lbs (874 kg). Attach a transmission jack prior to removal or installation. The axle housing must be chained to transmission jack or an out-of-balance condition may result. Failure to comply may result in serious injury or death to personnel.

WARNING

The truck end of torque rod must not be removed. Axle No. 4 and 5 share mounting hardware for longitudinal torque rod. If hardware is removed from crossmember, an out-of-balance condition for both axles will result. Any personnel under axle No. 5, which is not secured at this time, could be seriously injured or killed.

WARNING

Axle No. 5 weighs 1905 lbs (865 kg). Attach a transmission jack prior to removal or installation. The axle housing must be chained to transmission jack or an out-of-balance condition may result. Failure to comply may result in serious injury or death to personnel.

WARNING

Brake shoes may be coated with dust. Breathing this dust may be harmful to your health. Do not use compressed air to clean brake shoes. Wear a filter mask approved for use against brake dust. Failure to comply may result in injury or death to personnel.

WARNING

Brake assembly weighs 80 lbs (36 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Brake assembly will swing out on Axles No. 1 and 2 when overhead lifting device is used and screws are removed. Support brake assembly during removal or injury to personnel may result.

WARNING

Use care when removing or installing brake springs. Brake springs are under spring tension and can act as projectiles when released and could cause severe injury to personnel.

WARNING

Ensure braided hose is cool prior to removal or injury to personal may result.

WARNING

Wheel hub assembly weight 115 lbs (52 kg). Support wheel hub assembly with suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

The steering hydraulic system operates at oil pressures up to 3000 psi (20,685 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.

WARNING

Do not remove castle nut from drag link before applying upward pressure on drag link. Serious injury to personnel or damage to equipment may result.

WARNING

Stand clear of tires while turning them. Failure to do so may result in injury or death to personnel.

WARNING

Do not turn relief plunger out more than flush with end of steering gear cover. Plunger could blow out and spray hydraulic oil, causing serious injury to personnel.

WARNING

Steering gear weighs 190 lbs (86 kg). Ensure steering gear is properly supported upon removal from truck. Failure to comply may result in severe injury to personnel.

WARNING

Front steering gear needs to be supported on transmission jack with two wooden blocks located in front of front steering gear. Wooden blocks should be 4 by 6 by 11 in. and 2 by 4 by 11 in. and should be positioned as shown. Failure to comply may result in steering gear falling from transmission jack and causing injury to personnel.

WARNING

Pitman arm is under pressure. Parts can act as projectiles when released and could cause severe eye injury to personnel.

WARNING

Intermediate steering gear weighs 170 lbs (77 kg). Attach lifting device prior to removal to prevent injury to personnel.

WARNING

Steering gear weighs 165 lbs (75 kg). Attach lifting device prior to removal to prevent possible injury to personnel.

WARNING

Cab weighs 1700 lbs (772 kg). Attach suitable lifting device prior to removal or installation of cab support to prevent possible injury to personnel.

WARNING

Rear crossmember weighs 220 lbs (100 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Power module frame weighs 275 lbs. (125 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Ensure truck frame is securely supported before removing spring assembly. If truck falls, serious injury to personnel or death may result.

WARNING

Do not stick fingers in pin holes. Injury to personnel may result.

WARNING

Front spring assembly weighs 208 lbs (94 kg). Rear spring assembly weighs 175 lbs (79 kg). Attach a suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Air bags may still be pressurized even though air pressure gauge reads 0 psi. Remove air line slowly to allow air to escape. Failure to comply may result in air line blowing off causing serious injury to personnel.

WARNING

Ensure truck is securely supported before removing equalizer beams. If truck falls, serious personal injury or death may result.

WARNING

Two equalizer beams and cross tube weigh 445 lbs (202 kg) assembled. Each equalizer beam weighs 212 lbs (96 kg). Attach a suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Equalizer beam weighs 212 lbs (96 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Force required to remove beam end bushings and beam center bushing may exceed 30 tons (27 metric tons). Use of a press of 60-ton (54 metric tons) capacity or more is required to remove and install bushings. Use care when pressing out bushings to prevent serious personal injury or death. Always wear eye protection to prevent injury when operating press.

WARNING

Rust preventive contains alkali. Do not get in eyes; wear goggles/safety glasses when using. Avoid contact with skin. In case of contact, immediately wash area with soap and water. If eyes are contacted, flush eyes with large amounts of water for at least 15 minutes and get immediate medical attention.

WARNING

Trailing beam bracket weighs 83 lbs. (38 kg). Attach a suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Do not drain coolant if water temperature gage reads above 180 degrees F (82 degrees C). Contact with steam or hot coolant will result in serious injury to personnel.

WARNING

Always wear eye protection and protective clothing when handling glass. Failure to comply may result in injury to personnel.

WARNING

Fender weighs 74 lbs (34 kg). Use an assistant to remove to prevent possible injury to personnel.

WARNING

LHS control box weighs 200 lbs (91 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

The crane hydraulic system operates at oil pressures up to 3100 psi (21,375 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.

WARNING

Crane weighs 4,700 lbs (2,134 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Boom weighs 2100 lbs (953 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Erection cylinder weight 78 lbs (35 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

One pin secures erection cylinder, tension cylinder, and mast. Be careful to drive out pin only as far as needed to remove erection cylinder, or other components may fall, causing injury to personnel.

WARNING

Lift cylinder weighs 122 lbs (55 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

One pin secures both lift cylinders and mast. Be careful to drive out pin only as far as needed to remove selected cylinder and prevent possible injury to personnel.

WARNING

Ensure boom is fully supported by the LHS hook. Failure to support boom with LHS hook will cause boom to drop and may result in serious injury or death to personnel.

WARNING

Long pin also holds in mast and erection cylinder. Be careful to drive out pin only as far as needed to remove tension cylinder to prevent possible injury to personnel.

WARNING

Mast weighs 109 lbs (49 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Telescope cylinder weighs 70 lbs (32 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Hoist assembly weighs 210 lbs (95 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

When second spring is released, cable follower may fly up against bracket. Keep hands and face away from this area, or injury to personnel may result.

WARNING

Turntable weighs 150 lbs (68 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Gear weighs 135 lbs (61 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Subframe weighs 1420 lbs (645 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Swing drive gear reducer weighs 140 lbs (64 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Four valve bank weighs 75 lbs (34 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Outrigger cylinder weighs 115 lbs (52 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Using HOIST control lever, crane should lift test weight a maximum of 1 in. (2.5 cm) before Overload Sensing System (OSS) disables hoist. If hoist lifts test load higher than 1 in. (2.5 cm), OSS is not functioning correctly and crane has failed load test. Perform Follow-On Maintenance and notify GS Maintenance.

WARNING

The winch hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping the pressure to zero. Failure to comply may result in serious injury or death to personnel.

WARNING

Hook weighs 200 lbs (91 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Hook arm weighs 1100 lbs (499 kg). Attach suitable lifting device prior to installation prevent possible injury to personnel.

WARNING

The LHS hydraulics system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury to personnel.

WARNING

Middle frame weighs 1000 lbs (454 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Main cylinder weighs 325 lbs (148 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Compression frame weighs 4200 lbs (1907 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

LHS main manifold bracket assembly weighs 120 lbs (54 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Main hydraulic pump weighs 215 lbs (98 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Never stand in front of main hydraulic pump during lifting. Hydraulic pump can swing out of door and cause serious injury to personnel.

WARNING

Prolonged contact with lubricating oil, MIL-L-7808 may causes skin rash. Skin and clothing that come in contact with lubricating oil should be thoroughly washed immediately. Saturated clothing should be removed immediately. Areas in which lubricating oil is used should be well ventilated to keep fumes to a minimum.

WARNING

Hook arm cylinders weighs 210 lbs. (95 kg). Attach suitable lifting device prior to removal, installation, or lifting to prevent possible injury to personnel.

WARNING

Ensure hook arm assembly is supported with wooden block prior to removal to prevent possible injury to personnel.

WARNING

Middle frame, hook arm and hook have a combined weight of 2,300 lbs. (1,044 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Oil will spray from cylinder manifold ports when rod is moved in or out. Cover ports with two cleaning cloths to prevent oil from spraying. Failure to comply may result in injury to personnel.

WARNING

Sharp edges of exhaust pipe could cause injury to personnel.

WARNING

Sharp edges of exhaust tube could cause injury to personnel.

WARNING

Battery box weighs 75 lbs (34 kg). Attach suitable lifting device prior to installation to prevent possible injury to personnel.

WARNING

Upon installation of all wires and cables, ensure No contact is made with battery terminals or other wires and cables. Strap wires as required to prevent injury or death to personnel or damage to equipment.

WARNING

200 AMP alternator weight 75 lbs (34 kg) Use an assistant to prevent possible injury.

WARNING

Always disconnect battery ground cable or power source before working on electrical components or injury to personnel may result. Discharge capacitors as noted. If personnel receive an electrical shock, get immediate medical attention.

WARNING

Machine gun ring front support weighs 55 lbs (25 kg). Attach suitable lifting device prior to installation to prevent injury to personnel.

WARNING

Machine gun ring weighs 295 lbs (134 kg). Attach suitable lifting device prior to installation to prevent injury to personnel.

WARNING

Starter weighs 73 lbs. (33 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Engine weighs 2600 lbs (1180 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Keep out from under engine when lifting. If engine slips, sways, or falls, serious injury or death may result.

WARNING

Diesel fuel is flammable. Do not perform this procedure near fire, flame or sparks. Injury or death to personnel could result.

WARNING

When installing lifting device, keep hands clear of rotors to prevent injury to personnel.

WARNING

Cylinder head with lifting device weighs 182 lbs (83 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Flywheel housing weighs 187 lbs (85 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Keep hands clear of gears when loosening nuts to prevent injury to personnel.

WARNING

Vibration damper may drop off crankshaft and may cause injury to personnel.

WARNING

Crankshaft weighs 185 lbs (84 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Control valve cover is under spring tension. Use extreme care when removing cover. Control valve cover may project when released suddenly. Ensure proper eye protection is worn to prevent injury to personnel.

WARNING

Slave piston is retained by spring under compression. Ensure proper eye protection is worn to avoid injury to personnel.

WARNING

Spring is under extreme tension. Wear proper eye protection. Spring may shoot out and cause injury to personnel.

WARNING

Avoid contact with steam. Steam can cause burns, blindness, and other serious injury. Ensure the wearing of protective aprons, gloves, and safety goggles when using live steam or injury to personnel may result.

WARNING

When making this pressure test, make sure personnel are protected against pressurized air and oil from possible rupture or leak in hose or fitting on cylinder head or injury to personnel may result.

WARNING

Some chemical agents (detergents, solvents, alkalis, etc.) may irritate skin or be harmful to the eyes. Others must only be used with adequate ventilation. When working with potentially harmful chemical substances, read and heed the warnings on the product labels and follow prescribed safety precautions. When working with any potentially harmful substance - including live steam, hot water, and compressed air - wear appropriate safety equipment (face shield, gloves, apron, etc.) if required, and use extreme care to avoid injury to personnel.

WARNING

Wear proper eye protection to protect against stream of pressurized water from leak or rupture of fitting, hose, or oil cooler core to prevent injury to personnel.

WARNING

Use care when removing or installing piston rings. Piston rings are under spring tension and can act as projectiles when released and could cause severe eye injury.

WARNING

High pressure steam can blow particles into eyes, can cause severe burns, and creates hazardous noise levels. Eye, skin, and hearing protection is required.

WARNING

Engine block weighs 732 lbs (332 kg). Attach suitable lifting device before removal to prevent possible injury or death to personnel.

WARNING

Be careful when using high air pressure. Ensure connections and seals are tight before applying pressure. High air pressure can blow out parts, hoses or debris with force. Explosive force can damage equipment and cause injury to personnel.

WARNING

Keep out from under engine when lifting. If engine slips, sways or falls, serious injury or death may result.

WARNING

Keep hands and fingers clear of rotors. If rotors turn, fingers may get caught between rotors and result in injury to personnel.

WARNING

Use care when removing retaining pin. Spring behind plug is under tension. Wear proper eye protection to avoid personal injury.

WARNING

Use care when replacing valve plug. Spring behind plug is under tension. Wear proper eye protection to avoid personal injury.

WARNING

Use care when replacing valve stop. Spring behind stop is under tension. Wear proper eye protection to avoid injury to personnel.

WARNING

Cover is under spring pressure. Wear proper eye protection to avoid personal injury.

WARNING

Washer is under spring tension. Wear proper eye protection to avoid injury to personnel.

WARNING

Torque converter housing weighs 100 lbs (45 kg). Attach suitable lifting device for removal or installation to prevent possible injury to personnel.

WARNING

When screws are removed, oil pump will fall. Make sure that assistant firmly supports oil pump inside torque converter housing to prevent personal injury or damage to parts.

WARNING

Forward clutch and turbine shaft assembly weighs 67 lbs (30 kg). Attach suitable lifting device for removal or installation to prevent possible injury to personnel.

WARNING

Use extreme caution when dropping forward clutch assembly. Keep feet and hands out from under parts to avoid personal injury.

WARNING

Ensure personnel wear heat resistant gloves prior to heating PTO gear with propane torch. Failure to comply may result in severe injury or death to personnel.

WARNING

Use extreme caution when dropping fifth clutch housing. Keep feet and hands out from under fifth clutch housing to avoid injury to personnel.

WARNING

Make sure all personnel stand clear when releasing pressure on spring compressor. Retaining ring can cause personal injury if not properly seated in retaining ring groove.

WARNING

Front planetary carrier assembly weighs 54 lbs (25 kg). Attach suitable lifting device for removal to prevent possible injury to personnel.

WARNING

Use extreme care when removing lifting bracket. Sun gear shaft, main shaft and gear fit loosely and may fall out and cause injury to personnel or damage to parts.

WARNING

Do not lift rear planetary assembly by ball bearing on rear end. Bearing may come off and planetary may fall resulting in personal injury or damage to equipment.

WARNING

Keep fingers away from inside of transmission housing while installing rear carrier assembly or injury to personnel may result.

WARNING

Planetary differential assembly weighs 160 lbs (73 kg). Use suitable lifting device to prevent possible injury to personnel.

WARNING

Planetary carrier assembly weighs 85 lbs (39 kg). Use the aid of an assistant to turn differential case over to prevent injury to personnel.

WARNING

Rear shaft assembly weighs 100 lbs (45 kg). Attach suitable lifting device to prevent possible injury to personnel.

WARNING

Rear housing weighs 210 lbs (95 kg). Attach suitable lifting device before removal or installation to prevent possible injury to personnel.

WARNING

Center shaft assembly weighs 145 lbs (66 kg). Attach suitable lifting device before removal or installation to prevent possible injury to personnel.

WARNING

Upper shaft assembly weighs 115 lbs (52 kg). Attach suitable lifting device before removal or installation to prevent possible injury to personnel.

WARNING

Differential shaft assembly weighs 100 lbs (45 kg). Use an assistant during removal or installation to prevent possible injury to personnel.

WARNING

Differential housing weighs 90 lbs (41 kg). Attach suitable lifting device before removal or installation to prevent possible injury to personnel.

WARNING

Front housing weighs 200 lbs (91 kg). Attach suitable lifting device before removal to prevent possible injury to personnel.

WARNING

To prevent injury to personnel or equipment damage, make sure chains will not slip off shaft assembly during lifting operation.

WARNING

Assembled portion of upper shaft assembly weighs 100 lbs (45 kg). Use an assistant to prevent possible injury to personnel.

WARNING

Axle No. 3 weighs 1780 lbs (807 kg). Attach a suitable lifting device prior to removal to prevent possible injury to personnel. Chains must be attached to axle housing to prevent an out of balance condition when axle is lifted. Axle could roll out of control causing serious injury or death to personnel.

WARNING

Brake drum weighs 132 lbs (60 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Spring in air brake chamber is very powerful and is under tension. Failure to cage air brake chamber before removal will release tension of spring abruptly and could result in injury to personnel.

WARNING

Air brake chamber can only be unscrewed a maximum of one turn. Otherwise, incorrect brake operation could result.

WARNING

Wheel hub assembly weighs 115 lbs (52 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Brake assembly weighs 80 lbs (36 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Seal race is extremely hot. Do not touch seal race without protective gloves or severe burns to hands could result.

WARNING

Pivot and spindle assembly weighs 90 lbs (41 kg). Use the aid of an assistant to prevent possible injury to personnel.

WARNING

Differential assembly weighs 198 lbs (90 kg). Attach a suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Differential and bevel gear weighs 70 lbs (32 kg). Attach a suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Prussian Blue Dye is poisonous and can burn skin on contact. Over exposure to dye can cause heart and skin problems, dizziness and unconsciousness.

WARNING

Differential assembly weighs 450 lbs (204 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Split torque weighs 62 lbs (28 kg). The aid of an assistant is required to prevent possible injury to personnel.

WARNING

Split torque weighs 62 lbs (28 kg) without flange assembly and 75 lbs (34 kg) with flange assembly. The aid of an assistant is required to prevent possible injury to personnel.

WARNING

Properly support spindle during removal. Failure to comply may result in injury to personnel.

WARNING

Differential assembly weighs 500 lbs (227 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Front housing weighs 90 lbs (41 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Ring and pinion assembly weighs 60 lbs (27 kg). Attach a suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Self-recovery winch weighs 980 lbs (445 kg). Attach suitable lifting device prior to removal or installation to prevent injury to personnel.

WARNING

Left side and right side mount weigh 48 lbs (22 kg). Ensure hands and fingers are kept clear of left side and right side mounts during removal. Failure to comply may result in serious injury to personnel.

WARNING

Ensure fingers do not get caught between secondary planetary carrier and ring gear or injury to personnel may result.

WARNING

Wheel end assembly weighs 200 lbs (91 kg). Support wheel end assembly with suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Internal pistons are under moderate spring tension. Keep pistons compressed when installing locknut. Failure to comply may result in injury to personnel.

WARNING

Exhaust manifolds and engine parts are hot. Use care to prevent personal injury.

WARNING

Use care when removing or installing springs. Springs are under tension and can act as projectiles when released and could cause severe eye injury.

WARNING

Alternator weighs 75 lbs (34 kg). Use the aid of an assistant to prevent possible injury to personnel.

WARNING

Engine weighs 2,600 lbs (1,180 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Keep out from under engine when lifting. If engine slips, sways, or falls, serious injury or death may result.

WARNING

Use care when removing retaining rings. Retaining rings are under tension and can act as projectiles when released causing injury to personnel.

WARNING

Accumulator testing and charging can expose personnel to high pressure nitrogen. Use of proper safety equipment is required to prevent serious injury or death.

WARNING

Accumulator testing and servicing can expose personnel to high pressure nitrogen. Use of proper safety equipment is required to prevent serious injury or death.

WARNING

High pressure hydraulics [oil under 3700 psi (25,512 kPa) pressure] operate this equipment. Refer to truck operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.

WARNING

To prevent corrosion, parts should be dipped in rust preventive within two hours of degreasing.

WARNING

Approved hearing protection devices and protective goggles must be worn when performing tasks. Failure to comply may result in injury to personnel.

WARNING

Fan may engage without warning. do not place any part of body in area of fan operation. Failure to do so may result in injury or death to personnel.

WARNING

Use care when removing or installing retaining rings. Retaining rings are under tension and can act as projectiles when released causing injury to personnel.

WARNING

Release air pressure prior to opening container or injury to personnel could result.

WARNING

Upper container weighs 222 lbs (101 kg). Attach lifting device prior to removal or installation to prevent injury to personnel.

WARNING

Transmission assembly weighs 1,061 lbs (482 kg). Attach lifting device prior to removal or installation to prevent injury to personnel.

WARNING

Protective goggles must be worn when drilling holes. Failure to comply may result in injury to personnel.

WARNING

Upper container weighs 250 lbs (114 kg). Attach lifting device prior to removal or installation to prevent injury to personnel.

WARNING

Transfer case weighs 1,388 lbs (630 kg). Attach lifting device prior to removal or installation to prevent injury to personnel.

WARNING

Axle No. 3 weighs 1,780 lbs (807 kg) and Axle No. 4 weighs 1,925 lbs (873 kg). Use jackstands to support axles. Failure to do so could result in injury to personnel.

WARNING

Driveshafts can weigh up to 100 lbs (45 kg). Properly support driveshafts when removing screws. After screws and brackets are removed, driveshaft can fall and cause injury to personnel.

WARNING

Pivot and spindle assembly weighs 90 lbs (41 kg). Use the aid of an assistant to prevent possible injury to personnel.

WARNING

Wheel end assembly weighs 300 lbs (136 kg). Support wheel end assembly with suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

The trailing beam assembly weighs 150 lbs (68 kg). Attach a suitable lifting device to truck end of trailing beam assembly prior to removal or installation to prevent possible injury to personnel.

WARNING

Axle No. 3 weighs 1780 lbs (808 kg). Attach a suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Keep fingers out of trailing beam assembly holes. Failure to comply could result in serious injury to personnel.

WARNING

Trailing beam assembly weighs 150 lbs (68 kg). Attach a hydraulic jack to axle end of air suspension beam assembly prior to installation to prevent possible injury to personnel.

WARNING

Main fuel tank weighs 50 to 700 lbs (23 to 318 kg) depending on the quantity of fuel inside. Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Axle No. 4 and Axle No. 5 share mounting hardware for longitudinal torque rods. Both axles must be supported during removal of screws and locknuts or axles may fall. Failure to comply may result in injury or death to personnel.

WARNING

Spindle is heavy. Properly support spindle during disassembly or serious injury to personnel may occur.

WARNING

Seal race is extremely hot. Do not touch seal race without protective gloves or severe burns to hands could result.

WARNING

Ensure crankcase cover is fully supported before removing screws. Failure to comply may result in crankcase cover falling causing injury to personnel.

WARNING

Upper container weighs 480 lbs (218 kg). Attach lifting device prior to removal to prevent injury to personnel.

WARNING

Allow cable to slowly retract. Cable is under tension and can snap back rapidly. Ensure that proper eye protection is used. Failure to comply may result in serious injury to personnel.

WARNING

Allow engine to cool before performing this procedure or injury to personnel may occur.

WARNING

Engine must be cool before performing maintenance. Failure to comply may result in injury to personnel.

WARNING

Use care when removing snap and retaining rings. Snap and retaining rings are under spring tension and can act as projectiles when released and could cause severe eye injury.

WARNING

Mounts weigh 48 lbs (22 kg). Ensure hands and fingers are kept clear of left side and right side mounts during removal and installation. Failure to comply may result in serious injury to personnel.

WARNING

Do not use brake drum that exceeds maximum wear specification. Failure to comply may result in brake failure and serious injury or death to personnel.

WARNING

Brake drum weighs 134 lbs (61 kg). Use lifting device or aid of an assistant to lift drum. Failure to comply may result in injury to personnel.

WARNING

Do not loosen locknuts more than one full turn. Failure to do so may cause steering gear to fall and cause injury or death to personnel.

WARNING

All personnel must stay clear of cab when lifting is in progress. Failure to comply may result in injury or death to personnel.

WARNING

Inner-mid section weighs 1,000 lbs (454 kg). Attach suitable lifting device prior to removal to prevent injury to personnel.

WARNING

Do not stick fingers under section to remove wear pads, or injury to hands may result.

WARNING

Outer-mid section weighs 800 lbs (363 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

- Fly section weighs 450 lbs (204 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.
- Keep fly section level or structural section will fall out. Move fly section slowly. Keep assembly as level as possible during removal. Failure to comply may cause injury to personnel.

WARNING

Structural section weighs 175 lbs (79 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Unsafe torching practices can cause serious injury from fire, explosions, or harmful agents. Allow only authorized personnel to heat metals. Protective clothing, gloves, and goggles must be worn; adequate protective equipment used; and a suitable fire extinguishers kept nearby. Failure to comply may result in severe injury to personnel.

WARNING

At least 0.06 in. (1.5 mm) of clearance is required between highest spot on fly section and bottom of wear pad or section may not operate properly. Damage to equipment may result.

WARNING

Boom weighs 2,100 lbs (953 kg). Attach suitable lifting device prior to installation to prevent possible injury to personnel.

WARNING

Ensure charging cylinder contains dry nitrogen. Dry nitrogen tanks are marked with one or two black bands. Certain other gasses can cause accumulator to explode. Failure to comply may result in injury to personnel.

WARNING

Compression frame weighs 800 lbs (363 kg). Attach suitable lifting device prior to removal to prevent possible injury to personnel.

WARNING

Screws are extremely hot. Do not touch screws without protective gloves or severe burns to hands could result.

WARNING

The main hydraulic system operates at oil pressures up to 3,675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.

WARNING

Cylinder weighs in excess of 210 lbs (95 kg). Attach suitable lifting device prior to lifting to prevent possible injury to personnel.

WARNING

Left front support bracket weighs 98 lbs (44 kg). Attach suitable lifting device to prevent possible injury to personnel.

WARNING

Box assembly weighs 92 lbs (42 kg). Ensure box assembly is properly supported prior to removal to prevent possible injury to personnel.

WARNING

Right front support bracket weighs 98 lbs (44 kg). Attach suitable lifting device to prevent possible injury to personnel.

WARNING

Front support assembly weighs 660 lbs (300 kg). Attach suitable lifting device to prevent possible injury to personnel.

WARNING

Stow weldment weighs 410 lbs (186 kg). Attach suitable lifting device to prevent possible injury to personnel.

WARNING

Rear guide assembly weighs 70 lbs (32 kg). Attach suitable lifting device to prevent possible injury to personnel.

WARNING

Rear roller bracket weighs 155 lbs (70 kg). Attach suitable lifting device to prevent possible injury to personnel.

WARNING

Rear roller brackets weigh 150 lbs (68 kg). Attach suitable lifting device to prevent possible injury to personnel.

WARNING

Right strut bracket assembly weighs 80 lbs (36 kg). Attach suitable lifting device to prevent possible injury to personnel.

WARNING

Horizontal roller weighs 75 lbs. (34 kg). Attach suitable lifting device prior to installation to prevent possible injury to personnel.

WARNING

Lifting frame weighs 1,600 lbs (704 kg). Attach suitable lifting device prior to installation to prevent possible injury to personnel.

WARNING

Container lock could drop suddenly if not supported. Failure to comply may result in injury to personnel.

WARNING

Tip of removal tool is very sharp. Use caution when using tool. Failure to comply may result in injury to personnel.

WARNING

Gloves must be used when handling turbocharger cover. Turbocharger cover is made of fiberglass and may cause skin irritation. Failure to comply may result in injury to personnel.

WARNING

Components in each valve bore are spring-loaded and must be compressed while removing retaining pin. Ensure proper eye protection is worn to avoid injury to personnel.

WARNING

Rear planetary carrier assembly weighs 86 lbs (39 kg). Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

WARNING

Rear cover weighs 98 lbs (44 kg). Attach suitable lifting device for removal or installation to prevent possible injury to personnel.

WARNING

Ensure that upward lifting force is applied to the holding fixture before screws are removed or transfer case may shift downward causing personal injury or damage to equipment.

WARNING

Press on inner diameter of bearing or equipment damage may result.

WARNING

Parts of the brake assembly may be coated with brake dust; breathing this dust can harm personnel.

- Use a filter mask approved for use against asbestos dust.
- Never use compressed air or dry brush to clean these assemblies.
- Use an industrial type vacuum cleaner with a high-efficiency filter system to remove dust.
- Use water and a soft bristle brush or cloth to remove dirt or mud.

WARNING

Differential gear weighs 70 lbs (32 kg). Attach a suitable lifting device prior to installation to prevent possible injury to personnel.

WARNING

Axle No. 3 weighs 2,048 lbs (808 kg). Attach a suitable lifting device prior to removal or installation to prevent possible injury to personnel. Axle housing must be chained to lifting device to prevent an out of balance condition when longitudinal torque rod is removed. Axle could roll out of control causing serious injury or death to personnel.

LIST OF EFFECTIVE PAGES

Dates of issue for original and changed pages are:

Original..... 30 November 2005

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 1182 CONSISTING OF THE FOLLOWING:

Page No.	* Change No.	Page No.	* Change No.
Cover.....	0	D-8 Blank	0
Blank	0	E-1 thru E-18	0
a thru ar	0	F-1 thru F-10.....	0
A.....	0	INDEX-1 thru INDEX-14	0
B Blank.....	0	SCHMTC-1	0
i thru iv	0	SCHMTC-2 Blank.....	0
1-1 thru 1-30.....	0	SCHMTC-3	0
2-1 thru 2-113.....	0	SCHMTC-4 Blank.....	0
2-114 Blank.....	0	FP-1 thru FP-69	0
2-115 thru 2-187.....	0	FP-70 Blank.....	0
2-188 Blank.....	0	SCHMTC-5	0
2-189 thru 2-862.....	0	SCHMTC-6 Blank.....	0
A-1 and A-2.....	0	FP-1 thru FP-51	0
B-1 thru B-8	0	FP-52 Blank.....	0
C-1 thru C-35	0		
C-36 Blank	0		
D-1 thru D-7.....	0		

* Zero In This Column Indicates An Original Page.

Direct Support and General Support Maintenance Manual

PALLETIZED LOAD SYSTEM

MODEL M1074/M1075
NSN 2320-01-304-2277
NSN 2320-01-304-2278

Current as of 31 October 2005

REPORTING OF ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028-2 (Recommended Change to Equipment Technical Publications) through the Internet on the Army Electronic Product Support (AEPS) website. The Internet address is <http://aepls1a.army.mil>. If you need a password, scroll down and click on "ACCESS REQUEST FORM." The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS. Fill out the form and click on "SUBMIT." Using this form on the AEPS will enable us to respond quickly to your comments and better manage the DA Form 2028 program. You may also mail, fax or e-mail your letter DA Form 2028, or DA Form 2028-2 directly to: Commandeur U.S. Army Tank Automotive and Armaments Command, AMN/AMSTA/OC-PIT, Rock IS and, 0061299-7630. The e-mail address is ACOM-TECHPUBS@ta.army.mil. The fax number is DSN 793-0726 or (Commercel) (309) 782-0726.

TABLE OF CONTENTS

	Page
CHAPTER 1 INTRODUCTION	1-1
Section I General Information	1-1
Section III Equipment Description and Data	1-5
Section II Principles of Operation	1-6
CHAPTER 2 VEHICLE MAINTENANCE	2-1
Section I Repair Parts	2-1
Section II Service Upon Receipt	2-1
Section III Troubleshooting	2-6
Section IV Maintenance Procedures	2-850
CHAPTER 3 ENGINE MAINTENANCE	3-1
CHAPTER 4 FUEL SYSTEM MAINTENANCE	4-1
CHAPTER 5 COOLING SYSTEM MAINTENANCE	5-1

This manual supersedes TM 9-2320-364-34-1, dated 01 August 1999.

TABLE OF CONTENTS (CONT).

		Page
CHAPTER 6	ELECTRICAL SYSTEM MAINTENANCE	6-1
CHAPTER 7	TRANSMISSION MAINTENANCE	7-1
CHAPTER 8	TRANSFER CASE MAINTENANCE	8-1
CHAPTER 9	AXLE MAINTENANCE	9-1
CHAPTER 10	BRAKE SYSTEM MAINTENANCE	10-1
CHAPTER 11	WHEEL AND TIRE MAINTENANCE	11-1
CHAPTER 12	STEERING SYSTEM MAINTENANCE	12-1
CHAPTER 13	FRAME MAINTENANCE	13-1
CHAPTER 14	SPRINGS AND SHOCKS MAINTENANCE	14-1
CHAPTER 15	CAB ACCESSORY MAINTENANCE	15-1
CHAPTER 16	MATERIAL HANDLING CRANE, SELF-RECOVERY WINCH, LOAD HANDLING SYSTEM AND CONTAINER HANDLING UNIT MAINTENANCE	16-1
Section I	Introduction	16-2
Section II	Material Handling Crane Maintenance	16-2
Section III	Self-Recovery Winch Maintenance	16-230
Section IV	Load Handling System Maintenance	16-246
CHAPTER 17	HYDRAULIC SYSTEM MAINTENANCE	17-1
CHAPTER 18	SPECIAL PURPOSE KITS MAINTENANCE	18-1
CHAPTER 19	CHEMICAL, BIOLOGICAL, AND RADIOLOGICAL (CBR) EQUIPMENT MAINTENANCE	19-1
CHAPTER 20	ENGINE MAINTENANCE	20-1
Section I	Introduction	20-3
Section II	Engine Repair (On-Stand)	20-4
CHAPTER 21	FUEL SYSTEM MAINTENANCE	21-1
CHAPTER 22	COOLING SYSTEM MAINTENANCE	22-1
CHAPTER 23	TRANSMISSION MAINTENANCE	23-1
CHAPTER 24	TRANSFER CASE MAINTENANCE	24-1
CHAPTER 25	AXLE MAINTENANCE	25-1

TABLE OF CONTENTS (CONT).

	Page
CHAPTER 26 BRAKE SYSTEM MAINTENANCE	26-1
CHAPTER 27 STEERING SYSTEM MAINTENANCE	27-1
CHAPTER 28 MATERIAL HANDLING CRANE AND SELF-RECOVERY WINCH MAINTENANCE	28-1
Section I Introduction	28-1
Section II Material Handling Crane Maintenance	28-2
Section III Self-Recovery Winch Maintenance	28-71
APPENDIX A REFERENCES	A-1
APPENDIX B EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST	B-1
APPENDIX C ILLUSTRATED LIST OF MANUFACTURED ITEMS	C-1
APPENDIX D TORQUE LIMITS	D-1
APPENDIX E MANDATORY REPLACEMENT PARTS	E-1
APPENDIX F TOOL IDENTIFICATION LIST	F-1
INDEX	INDEX-1
SCHEMATICS	SCHMTC-1
Section I 145 Amp Alternator and DDEC II Engine	
Section II 200 Amp Alternator and DDEC III/IV Engine	

HOW TO USE THIS MANUAL

This manual is designed to help maintain the Model M1074/M1075 Palletized Load System (PLS) truck. Listed below are some special features included in this manual to help locate and use the needed information:

- A front cover table of contents is provided for quick reference to chapters and sections that will be used often.
- Warning, caution, and note headings, subject headings, and other essential information are printed in bold type making them easier to see.
- The maintenance tasks describe what must be done to the truck before starting the task (Equipment Condition), and what must be done to return the vehicle to operating condition after the task is finished (Follow-On Maintenance).
- The Appendixes are located at the end of the manual. They contain a reference guide to other manuals, a list of expendable supplies and materials, and other material for maintaining the PLS truck.
- In addition to text, there are exploded-view illustrations showing how to take a component off and put it back on. Cleaning and inspection procedures are also included as required.
- Chapter 2 of this manual covers basic troubleshooting and Direct Support Maintenance for each PLS truck.

Follow these guidelines when using this manual:

- Read all WARNINGS and CAUTIONS before performing any procedure.
- The equipment conditions found in the maintenance procedures are of a general nature and the mechanic may be able to perform only certain steps within a procedure to accomplish the equipment condition.

CHAPTER 1

INTRODUCTION

Para	Contents	Page
1-1	Scope	1-1
1-2	Maintenance Forms, Records and Reports	1-5
1-3	Destruction Of Army Material To Prevent Enemy Use	1-5
1-4	Official Nomenclature, Names and Designations	1-5
1-5	Reporting Equipment Improvement Recommendations (EIR)	1-5
1-6	Warranty Information	1-5
1-7	Equipment Characteristics, Capabilities and Features	1-5
1-8	Location And Description Of Major Components	1-6
1-9	Equipment Data	1-6
1-10	Power Train	1-6
1-11	Engine Systems	1-9
1-12	Electrical System	1-12
1-13	Air System	1-19
1-14	Hydraulic System	1-20
1-15	Steering System	1-21
1-16	Self-Recovery Winch (SRW)	1-22
1-17	Material Handling Crane (MHC)	1-23
1-18	Load Handling System (LHS)	1-26
1-19	Wheels And Tires	1-27
1-20	Central Tire Inflation System (CTIS)	1-28
1-21	Cab	1-28
1-22	PLS Trailer (PLST)	1-29
1-23	PLS Flatrack (FR)	1-30

Section I. GENERAL INFORMATION

1-1. SCOPE.

This chapter provides general information, equipment descriptions and principles of operation for the M1074/M1075 Palletized Load System (PLS). The PLS will herein be referred to as the truck.

- a. *Type of Manual.* Direct and General Support Maintenance Instructions, TM 9-2320-364-34.
- b. *Model Numbers and Equipment Names.* The different truck models are listed below:

M1074	Truck with crane (Figure 1-1)
M1075	Truck without crane (Figure 1-2)
M1076	Trailer (Figure 1-3)
M1077	Flatrack (Figure 1-4)

c. *Purpose of Equipment.* The PLS is an ammunition-hauling tactical wheeled truck and trailer combination with integral self-load/unload capability using the PLS flatrack (FR).





Figure 1-1. M1074 Palletized Load System Truck (With Crane)





Figure 1-2. M1075 Palletized Load System Truck (Without Crane)





Figure 1-3. M1076 PLS Trailer




Figure 1-4. M1077 PLS Flatrack

1-2. MAINTENANCE FORMS, RECORDS AND REPORTS.

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 738-750, The Army Maintenance Management System (TAMMS) (Maintenance Management UPDATE).

1-3. DESTRUCTION OF ARMY MATERIAL TO PREVENT ENEMY USE.

Command decision, according to tactical situation, will determine when the destruction of the truck will be accomplished. A destruction plan will be prepared by the using organization unless one has been prepared by a higher authority. For general destruction procedures for this truck, refer to TM 750-224-6, Procedures for Destruction of Tank-Automotive Equipment to Prevent Enemy Use (US Army Tank-Automotive Command).

1-4. OFFICIAL NOMENCLATURE, NAMES AND DESIGNATIONS.

Table 1-1 lists the nomenclature cross-references used in this manual.

Table 1-1. Nomenclature Cross-Reference

<u>Common Name</u>	<u>Official Nomenclature</u>
Cable	Wire rope
Cold Start System	Ether quick-start system
Engine Coolant	Antifreeze, ethylene glycol mixture
Gladhand	Quick-disconnect coupling
Truck	Palletized Load System
Jacobs Brake	Engine Retarder

1-5. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR).

If your Palletized Load System needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Put it on an SF368 (Quality Deficiency Report). Mail it to us at: Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-TR-E-MPA, Warren, Michigan 48397-5000. We'll send you a reply.

1-6. WARRANTY INFORMATION.

Refer to PLS Warranty Technical Bulletin, TB 9-2320-364-15 for complete warranty information covering the truck. Warranty starts on the date found in block 23, DA Form 2408-9, in the logbook. Report all defects in material or workmanship to the supervisor, who will take appropriate action.

Section II. EQUIPMENT DESCRIPTION AND DATA

1-7. EQUIPMENT CHARACTERISTICS, CAPABILITIES AND FEATURES.

Refer to TM 9-2320-364-10 for equipment characteristics, capabilities and features.

1-8. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS.

Refer to TM 9-2320-364-10 for location and description of major components.

1-9. EQUIPMENT DATA.

Refer to TM 9-2320-364-10 for equipment data.

Section III. PRINCIPLES OF OPERATION

1-10. POWER TRAIN.




Figure 1-5. Power Train

Power for the truck is provided by a diesel engine (1) (Figure 1-5) which is coupled directly to an automatic transmission (2). Power from the transmission is transferred to the transfer case (3) and on to the drive and steering axles (4) and the drive only axles (5) through a series of drive shafts and universal joints. The truck drive train is enhanced through the use of the Detroit Diesel Electronic Control II (DDEC II) or Detroit Diesel Electronic Control III/IV (DDEC III/IV) electronic engine controller and the Allison Transmission Electronic Control (ATEC) electronic transmission controller. The primary components of the ATEC system are an Electronic Control Unit (ECU) and shifter in the truck cab, an electrohydraulic valve module beneath the transmission gearing section that contains solenoid valves for clutch control, a throttle sensor that is activated by the accelerator pedal and an output speed sensor that relays the transmission output speed to the ECU for shifting and control functions.

a. Engine. The truck is equipped with a Detroit Diesel Corporation (DDC) Model 8V92TA engine rated at 500 HP. The drive train control system consists of the engine and transmission systems.

(1) The DDEC II and DDEC III/IV contain a microprocessor-based electronic control module to regulate the electronic distributor unit. This distributor unit controls the individual or unit injectors that regulate both the amount and timing of fuel delivery. The DDEC II and DDEC III/IV electronically govern engine speed and can be programmed to accommodate truck configuration changes. The DDEC II and DDEC III/IV are electronically linked with the transmission, through the ATEC, to improve truck performance.

(2) The DDEC and ATEC systems perform self diagnostics, engine/transmission system diagnostics and truck performance diagnostics. Self diagnostics includes personnel initiated checks of main electronic components such as solenoids, wiring, sensors and control modules. System diagnostics monitor critical engine and transmission parameters such as oil temperature, oil pressure, coolant temperature, voltage and gear range attained. Truck performance diagnostic capabilities aid the mechanic in isolating problems outside of the electronic control system. Operating data is stored in the DDEC II's and DDEC III's memory for display at a later time. Stored data includes total engine hours and fuel consumed. The DDEC also tracks intermittent problems by logging the number of occurrences and the engine hours of each occurrence.

b. Transmission. The truck uses an Allison 700 Series Transmission, Model CLT-755. This hydro-kinetic type transmission has an integral-locking torque converter, lock-up clutch, constant mesh planetary gearing, the ATEC, a speedometer and a control valve body assembly.

(1) The Electronic Control Unit (ECU), which contains the microprocessor based electronics, is located in a protected area within the truck. The ECU receives information, in the form of signals from switches and sensors, processes the information and sends electrical signals to the appropriate solenoids which control the transmission operation. The ECU features diagnostics which can sense many electronic system malfunctions and identify them with a displayed code. The ECU also protects the transmission from cold weather start-ups by inhibiting normal shifting functions until a minimum sump oil temperature of 20 degrees F (-7 degrees C) is attained.

(a) The CHECK TRANS light alerts the operator, momentarily, every time the system is activated, as a lamp check, and/or when the ECU finds a problem in the system. If the check transmission light comes on, the problem is minor. In most cases, the transmission will continue to operate in a normal manner. However, in some cases the ECU will take action to reduce the possibility of damage to the truck or the transmission. The transmission should be serviced at the next opportunity.

(b) The DO NOT SHIFT light and/or buzzer alerts the operator, momentarily, every time the system is activated as a lamp check and any time the ECU has detected a more severe problem in the system. The ECU will cause the transmission to hold-in-gear and disengage the lock-up clutch.

(2) The push button range selector is totally electronic. Range selection is achieved by means of seven snap dome switches. To select a range, touch the pad. The pad will light up, a beep will be heard and a "click" will be felt. The transmission will be ready to operate in the selected range. The range selector also has a "DO NOT SHIFT" light and a warning tone or buzzer.

(a) Select the Drive position and the truck will start in first (low range only) or second range and automatically upshift to a higher range as output speed increases. As the truck slows down, output speed decreases and the transmission automatically downshifts to the correct range. If a locked brake or a slick-surface condition should occur, the ECU will command converter operation and inhibit downshifts for a period of time or until normal wheel speed has been restored. Drive (4) should be selected for moderate loads, grades and over-the-road operation with restrictive speed limits. Drive (3) is appropriate for operating in rough terrain or in heavy traffic. Drive (2) should be selected when need for speed control requires a second gear hold condition such as descending steep grades where additional engine braking is required, for operation on rough terrain, or greater retarder action. Selecting Drive (1) permits the driver to operate the truck in areas where maximum performance in extremely rough terrain is required.

1-10. POWER TRAIN (CONT).

CAUTION

Do not allow a truck to coast in neutral. Engine braking is nullified and the transmission will not receive adequate lubrication.

(b) Select the Neutral (N) pad when checking truck accessories and for extended periods of engine idle operation. The push button range selector will automatically select neutral when the master switch is turned on.

(c) Stop the truck before shifting from Forward (F) to Reverse (R) or from Reverse (R) to Forward (F). Touch the reverse (R) pad on the selector. The light under the Reverse (R) pad will light and the reverse warning signal on rear of truck will be activated.

(d) When the ECU detects a serious problem in the system, a beeper tone is produced for 10 seconds and a "DO NOT SHIFT" light is activated to warn the driver that the transmission is held-in-gear. Selecting another pad will have no affect or change, nor will a tone sound be produced.

(3) All lubricating and clutch-applied oil is provided by an engine-driven pump (in the transmission). Because of the pump location ahead of the transmission gearing and clutches, the engine cannot be started by pushing or towing the truck. Therefore, anytime that the truck must be towed, or pushed, the drive-line must be disconnected.

c. Transfer Case. The truck transfer case has two speeds and a 30/70 differential. The transfer case 30/70 differential provides full time, all wheel drive and proportions approximately 30 percent of the torque to the front tandem and 70 percent of the torque to the rear tridem. The differential has a driver-controlled air actuated lock-up mechanism which consists of a sliding lockout collar that locks the differential housing to the output shaft. This differential lock-up provides increased mobility in adverse operating conditions.

d. Suspension. The front tandem suspension is a walking beam suspension with a special low-friction spring. The third axle suspension is an air ride suspension. The rear tandem suspension is a specially designed low-friction spring.

(1) The suspension system design maintains tire/ground contact under adverse terrain profiles and conditions. The design equalizes loads between axles and provides the necessary roll stability to operate on a 30 percent side slope. The truck uses 16.00R20 tires of a tubeless radial design.

(2) The truck uses three steering axles. The front tandem axle wheels and the last axle wheels steer. Power steering controls the steering gear at each steering axle. The power steering pump is direct driven at the engine. The cab steering wheel provides directional input to the first and second axle steering gears. A control link from the first axle master steering gear provides a mechanical link to the second axle slave steering gear. The second axle slave gear provides directional control from a rotary output shaft to the steering gear on the fifth axle. The steering gears are sized to turn the wheels when the truck is fully loaded.

e. Axles. The truck uses a three drive/steer hub reduction axle and two hub reduction axle design.

1-11. ENGINE SYSTEMS.




Figure 1-6. Cooling System

a. *Cooling System.* The pressure-type cooling system (Figure 1-6) protects the engine by removing heat generated during the combustion process. Pressure within the cooling system is regulated by a pressure release in the radiator filler cap (1). The hot coolant flows from the engine (2) to the radiator tank (3) and through the radiator core where a stream of air removes heat. This stream of air is drawn through the core by the fan. A water pump (4) draws the coolant from the radiator and pushes it through the engine repeating the cooling process. Thermostats (5) mounted in each coolant outlet elbow, remain closed until the coolant approaches a predetermined temperature at which time they open. When the coolant temperature drops below the thermostat rating, they close. An air vent line between the radiator and the water pump inlet removes air trapped in the engine when the cooling system is being filled. An oil cooler (6) is mounted in the radiator lower tank.

1-11. ENGINE SYSTEMS (CONT).




Figure 1-7. Air Intake System

b. Air Intake System. The air intake system (Figure 1-7) consists of a dry-type air cleaner (1), ducting (2), turbocharger (3) and engine blower. Engine exhaust gases flow through the turbocharger driving a turbine wheel. A compressor wheel on the opposite end of the turbine wheel shaft rotates and draws in fresh air through the air cleaner, compresses the air and delivers it to the engine blower.




Figure 1-8. Fuel System

c. Fuel System. In the fuel system (Figure 1-8), fuel is drawn from the fuel tank (1) and passes through the electrical priming fuel pump (2) and the fuel/water separator (3). A fuel shut-off valve (4) controls the flow of fuel to the engine. A mechanical fuel pump (5) draws fuel through the secondary fuel filter (6) to the engine. Surplus fuel from the injectors is returned to the fuel tank through a return line. The fuel/water separator removes water and large solid particles from the fuel. The finer particles are removed by the secondary filter before they can enter the fuel injectors.

1-12. ELECTRICAL SYSTEM.




Figure 1-9. Electrical System

The 24 VDC electrical system (Figure 1-9) is waterproof, has reverse polarity protection and incorporates a 12 VDC lighting subsystem. Manual resetting circuit breakers (1) are used throughout the system and all circuits are identified. The voltages for the electrical system are indicated by two voltmeters (2) located on the dash panel inside the drivers compartment. Circuit breakers located in the cab protect the main circuits.




Figure 1-10. Electrical System

Electrical system (Figure 1-10) power is provided by four 12-volt series-parallel connected batteries (1). PLS trucks are either equipped with the dual voltage control system (DUVAC) and a 145 AMP alternator or the polarity protection system and a 200 AMP alternator. The DUVAC (2) delivers up to full alternator output on demand to either the 24 volt load, 12 volt load, or any combined load requirement from a single alternator. The DUVAC system can maintain battery equalization and balance even when the batteries are not matched or when they are in different charge states. Separate voltage regulation is provided for each battery bank. The battery box (3) is located on the left-hand fender and vents to the truck exterior. This location provides protection from the environment and allows ready access for service. The fiberglass battery box cover is designed to prevent short circuits during maintenance and operation. Power is distributed throughout the truck by wiring harnesses. The harnesses are interconnected by pin connectors. Connectors are provided at the rear of the truck to supply power for towed loads.

1-12. ELECTRICAL SYSTEM (CONT).




Figure 1-11. Electrical System

In the electrical system (Figure 1-11) a heavy duty starting motor (1) is mounted on the engine flywheel housing and provides the cranking power necessary for starting the engine. The DUVAC maintains both a 14- and 28-volt level for proper battery charging. The alternator (2) provides sufficient amperage to operate all electrical components and charge the batteries during engine idling. Truck exterior lights are mounted in protective locations or are protected to prevent damage. Protection is provided for lights during cross country travel. Polycarbonate lenses are provided for all lights except the sealed beam headlights and service lights. The PLS electrical system supplies all of the electrical power needed to operate the truck and trailer. The complete electrical system is made up of the following sub-systems:

- Power Storage and Generating
- Engine Starting and Stopping
- Service Lighting
- Blackout Lighting
- Accessory Lighting
- Instruments
- Warning Lights and Buzzers

a. Power Storage and Generating. Power storage for the truck consists of four 12-volt batteries. The four batteries are divided into two sets. Two batteries in each set are wired in parallel to produce higher amperage. The two sets are then wired in series to produce 24 volts. While the batteries can power all of the systems for a limited time, their primary purpose is to supply power to the engine's starting system. Once the engine is running, the generating system provides the electrical power for all of the systems. The engine driven alternator generates alternating current (AC) which is passed through a set of rectifiers that change it into direct current (DC). This direct current is used to charge the batteries and is distributed to the other systems of the PLS. The DUVAC adjusts alternator output to fit the needs of the electrical system.




Figure 1-12. Engine Starting System

b. Engine Starting and Stopping. The engine starting system (Figure 1-12) uses the stored electrical energy of the batteries to turn the starter motor. When the ignition switch (1) is turned to the START position, electrical power is passed through the neutral safety switch to the starter relay. The starter relay, when energized, draws electrical power directly from the batteries and sends it to the starter motor solenoid. When the solenoid is energized, the starter motor draws electrical power from the batteries and turns the engine. To stop the engine, shut off ignition switch.

1-12. ELECTRICAL SYSTEM (CONT).




Figure 1-13. Service Lighting System

c. *Service Lighting.* The service lighting system (Figure 1-13.) includes the headlights (1), tail lights (2) and clearance marker lights (3). They are energized by pressing the blackout light selector switch to the OFF position. The stop lights, clearance marker lights, panel lights, turn signals and emergency flashers are then controlled by separate switches located in the cab.




Figure 1-14. Blackout Lighting System

d. Blackout Lighting. The blackout lighting system (Figure 1-14) includes the front blackout marker lights (1), rear blackout marker lights (2), blackout stop lights (3) and panel lights. These are energized by turning on the blackout light selector switch and either the blackout marker switch or the blackout drive switch. The blackout stop lights and the panel lights are then controlled by other switches located in the cab.

e. Accessory Lighting. The accessory lighting system includes the dome light, beacon light and worklights. These are energized by turning the blackout light switch to the OFF position. The dome light, beacon light and worklights are then controlled by separate switches in the cab. The worklights also have switches built into the light assemblies themselves.

1-12. ELECTRICAL SYSTEM (CONT).




Figure 1-15. Instrument System

f. Instruments. The instrument system (Figure 1-15) includes all gages that give the operator information. The speedometer (1) receives signals from a sending unit mounted on the transfer case. Tachometer (2) input is provided from the DDEC controller. The fuel gage (3), oil pressure gage (4), water temperature gage (5) and transmission oil temperature gage (6) all receive electrical signals from sending units. These sending units monitor fluid level, pressure and temperature and send this information to the gages.

g. Warning Lights and Buzzers. The warning lights (7) and buzzers (8) in the cab are activated by sensors located in different systems. These include low air pressure, low engine oil pressure, low hydraulic oil level and high water temperature. When one or more of these sensors are activated, they energize the proper light and/or buzzer, informing the operator of a problem.

1-13. AIR SYSTEM.




Figure 1-16. Air System

The air system (Figure 1-16) consists of an engine-driven air compressor (1) and five air reservoirs (2). The system includes the necessary valves and air lines to control the truck's air operated devices. Pressurized air from the air compressor is passed through the air dryer (3) to the reservoir. The air dryer removes dirt and moisture from the pressurized air. Air from one reservoir goes to the brake treadle valve. This air passes to the rear brake chambers, located on axles #3, #4, and #5, which control the axle rear service brake. Air pressure in this system is shown by the red needle on the AIR PRESS gage. Air from another reservoir goes to the brake treadle valve. This air passes to the front brake chambers, located on axles #1 and #2, which control the front axle service brakes. Air pressure in this system is shown by the green needle on the AIR PRESS gage. The PARKING BRAKE valve applies or releases the rear axle (parking) brakes. The reservoirs are interconnected in such a way that if one reservoir fails, air will be supplied to release the rear axle (parking) brake from whichever reservoir is functioning. If air pressure falls below 60 to 70 psi (414 to 483 kPa) in either system, a buzzer will sound, the LOW AIR indicator will light and the rear axle brakes will be applied.

1-14. HYDRAULIC SYSTEM.




Figure 1-17. Hydraulic System

The hydraulic system (Figure 1-17) pumps (1) mounted in front of the engine provide the fluid power to operate the power steering, Self-Recovery Winch (SRW) (2), cooling fan (3), Material Handling Crane (MHC) (4) and Load Handling System (LHS) (5). A manually operated selector switch in the cab is used to select the auxiliary hydraulics.

1-15. STEERING SYSTEM.




Figure 1-18. Steering System

Steering system (Figure 1-18) power is supplied to steering gears (1), (2) and (3) by an engine-driven pump. The steering fluid reservoir (4) is separate from the main hydraulic system. The steering wheel, which is mechanically linked to the steering gear, rotates a gear that positions a spool in the front steering gear (1). This motion is hydraulically transmitted to a piston in the intermediate steering gear (2) causing it to follow the pitman arm and transmit rotary motion to the rear steering gear (3). These pitman arms move the steering mechanism on the axles left or right causing the truck to steer left or right. An emergency backup hydraulic pump, driven by the transfer case middle shaft, supplies limited emergency steering.

1-16. SELF-RECOVERY WINCH (SRW).




Figure 1-19. Self-Recovery Winch (SRW)

When specified, the truck is equipped with a winch (1) (Figure 1-19) for self-recovery capable of forward and rearward deployment. The winch is equipped with a holding brake and hydraulic counter-balance valve to safely deploy and hold the full rated load of the winch. The winch brake is automatic and is fully engaged anytime the winch is stopped or not in use and is fully released during operation. The winch cable is equipped with a clevis end and roller assemblies are provided to guide the cable. The winch is controllable from the driver's position and at the winch itself. All controls revert to neutral when released.

1-17. MATERIAL HANDLING CRANE (MHC).




Figure 1-20. Material Handling Crane (MHC)

The truck Material Handling Crane (MHC) (Figure 1-20) is a fully hydraulic load-moment sensing crane (1) powered by the truck hydraulic system. The crane is mounted behind the cab, bolt-attached to the truck frame and is capable of lifting a 3,900 lb (1770 kg) pallet from any location on the FR. The crane can load/unload pallets to either side of the truck. Truck stability and leveling is accomplished with left- and right-side hydraulically operated stabilizers (2) that are fabricated as a part of the crane substructure. These stabilizers/outrigger jacks can be controlled from either side of the truck by individual hydraulic controls. The jacks can level the truck when it is inclined up to 7 degree side slope. Check valves are used to hold the outriggers position. Safety switches are installed in the outrigger jacks to prevent crane operation unless the outriggers are in place. The outrigger pads (3) are attached to the outrigger jacks by means of quick pins (4) and are stowed on the crane base. The pads swivel 360 degrees when installed on the jacks.

a. Hydraulic System. The hydraulic filters and strainers are located to provide direct access and to allow removal without causing damage to the truck. Bypasses are furnished, where necessary, to protect filters during cold temperature operation. All cylinder rods exposed during operations have a hard chromium plating. Integral mounted or cartridge-type holding valves prevent sudden cylinder collapse in the event of hose burst or major hydraulic failure. If a hydraulic system failure occurs, a hydraulic hand pump (5) located at the operator station permits the operator to lower any load to the ground and stow the crane. The MHC is operated by two hydraulic valve banks (6), located approximately 60 inches (152 cm) above ground on the passenger side of the truck. Four electro-proportional control valves with manual handles connected to spools are used to control crane proper function. Three additional proportional manual control valves are used for erection and outrigger control. The outrigger manual control valves are also duplicated on the driver's side of the truck.

1-17. MATERIAL HANDLING CRANE (CONT).




Figure 1-21. Fixed Controls

b. Fixed Controls. All crane controls and indicators (1) (Figure 1-21) are located at the crane position on the passenger side of the truck. Controls (2) on the driver's side will also operate the outriggers. The controls are accessible to the operator while standing on the ground. Control valves, both crane and outrigger, automatically return to the neutral position should the operator inadvertently or intentionally release the control.




Figure 1-22. Remote Controls

c. Remote Controls. The remote control system (Figure 1-22) is designed to operate the spools of the directional control valve. Remote control is proportionally variable. Remote control (1) is provided with an emergency shutdown capability and designed so that when activated, all remote control crane functions cease and truck speed is reduced to idle. The operator can operate the remote control anywhere within 35 ft. (10.7 m) of the crane base. The controller has multiple functions to match control levers on the fixed control except for the mast and outrigger controls.




Figure 1-23. Overload Shutdown

d. **Overload Shutdown.** The crane is provided with an overload shutdown (Figure 1-23) which precludes structurally overloading. Two block and overload conditions are sensed through line-pull of the hoist. A preprogrammed micro-processor that is constantly comparing boom angle, boom length and hoist line pull activates solenoid valves in the telescope out, lift up, lift down and hoist up circuits when the unit is overloaded or two-blocked. During an overload condition, the crane's function cease. Hoist down, telescope in and swing in either direction can be used manually to bring the crane to a safe position.




Figure 1-24. Hoist, Swing Drive and Brake

e. **Hoist.** The crane provides vertical lift of a 3,900 lb. (1769 kg) load at 22.5 ft. (6.86 m) by means of a hoist (1) (Figure 1-24) with a 5.8 cu. in. (95 cu. cm.) motor. The hoist is controllable by manual control at the fixed operators station, or at the remote control. The hoist has a spring applied, hydraulically released multi-disc pack brake, hydraulically coupled to the hoist circuit, which applies automatically when the hoist control is released.

f. **Swing Drive and Brakes.** The swing drive (2) is a planetary gear box driven by a hydraulic motor to give a swing speed on 0.8 rpm. Mechanical stops limit the rotation to 180 degrees. The swing brake (3) is a spring applied, hydraulically released multi-disc pack, hydraulically coupled to the swing circuit, applying automatically when the swing control is released.

1-18. LOAD HANDLING SYSTEM (LHS).




Figure 1-25. Load Handling System (LHS)

The truck is equipped with a Load Handling System (LHS) (Figure 1-25). The LHS (1) is fully hydraulic, powered by the truck hydraulic system and is operated by hydraulic selector switch (2) and joystick (3) located to the driver's right in the truck cab. The LHS control system is electrically powered from the truck electrical system. The LHS is capable of the following, with a flatrack (FR) loaded with 33,000 lb. (15 metric tons) nominal payload:

- Loading/unloading the FR from the truck to 12 in. (30.5 cm) below ground level and any intermediate level,
- Loading/unloading from uneven ground slopes of 10 degrees from the trucks lateral and horizontal axis,
- Loading/unloading to/from the trailer or ramps in which the height is equal to or less than the height from the ground to the bottom of the FR (while on the truck).

a. Flatrack Locking. The LHS is designed with automatic locking features that secure the FR for all modes of transportation. The LHS can automatically guide, center and secure a FR to the truck so that even during rough trail operations, the FR remains safely secured.

b. LHS Overload. The LHS will not function when the payload exceeds 36,300 lbs. (16,480 kg) maximum. A warning light (4), located in the cab in plain view of the driver, activates when a FR with a payload between 34,500 and 35,500 lbs. (15,663 to 16,117 kg) is being loaded by the LHS while under the worst conditions.

c. Hydraulic System. Hydraulic filters are located to provide direct access and to allow removal without damage to the truck. By-passes are furnished where necessary to protect filters during cold temperature operation. All cylinder rods exposed during operation have a hard chromium plating.

d. Slave Hydraulics. Self-sealing quick disconnect hydraulic couplings and a hose with appropriate connectors are provided so that one PLS truck can readily hydraulically power the LHS of another PLS truck.

1-19. WHEELS AND TIRES.




Figure 1-26. Wheels and Tires

Each truck has eleven wheel/tire assemblies (Figure 1-26); the ten installed on the truck axles plus a spare. The components of each wheel/tire assembly are the wheel, tire, valve stem, Central Tire Inflation System (CTIS), wheel valve, bead lock and wheel cover.

- a. *Wheel.* The 20 by 10 inch wheel is manufactured in two pieces. Twelve studs (1) that protrude from the rear wheel half are used to bolt the two halves together. These studs are also used to mount the CTIS wheel valve bracket and secure the wheel cover (2).
- b. *Tire.* The 16.00R20 tires (3) are tubeless.
- c. *Bead Lock.* The bead lock is installed inside the assembled wheel and tire. It assures that the tire stays pressurized when tire pressure is low. It is manufactured in two halves that are bolted together.
- d. *CTIS Wheel Valve.* The wheel valve assembly allows air flow in and out of the tire during CTIS inflation/deflation cycles. It is mounted to the wheel and secured by a bracket assembly. The input and output ports are fitted with two flexible and steel tubes in parallel.
- e. *Valve Stem.* The valve stem connects inside the wheel and is routed to the CTIS wheel valve.
- f. *Wheel Cover.* The entire wheel end contains a wheel cover to protect the CTIS valve and air lines from physical damage. This cover always must be in place whenever the truck is in operation. It is secured to the wheel via four of the wheel studs.

1-20. CENTRAL TIRE INFLATION SYSTEM (CTIS).




Figure 1-27. Central Tire Inflation System (CTIS)

The Central Tire Inflation System (CTIS) (Figure 1-27) is designed to adjust the pressure of all tires on the truck for different traction conditions. The CTIS controller (1) has four pressure settings which the operator selects and activates in the cab. The CTIS consists of control valves for air supply and distribution, a dash mounted electrical controller that adjusts tire pressure, along with required air tubing, electrical cables, air dryer and air compressor. The drive-line lock-up controls with the exception of the TRANSFER CASE LOCKUP are integrated with the CTIS to simplify operation of the truck. Refer to TM 9-2320-364-10 for operating controls and indicators for the CTIS.

1-21. CAB.

The truck cab features a full width configuration and is positioned forward of the first axle. The cab controls and operating mechanisms are designed to accommodate a crew of two wearing the full range of clothing. Heating, ventilation, lighting, noise, vibration and shock control is provided for personnel use. The cab contains all of the driving controls and gages and some operating controls for the mounted equipment. Refer to TM 9-2320-364-10 for information concerning operating controls and indicators.

1-22. PLS TRAILER (PLST).




Figure 1-28. Palletized Load System Trailer (PLST)

The Palletized Load System Trailer (PLST) (Figure 1-28) is a three axle trailer designed to carry a Flatrack (FR) with a 33,000 lb. (15 metric tons) nominal payload. It can accommodate both full and partial loaded flatracks. Guides laterally position the FR on the trailer rear stops and these locate the longitudinal position of the FR in relation to the PLST. These stops prevent the FR from sliding rearward. A pneumatic locking device (1), located between the frame rails just above the second axle, hooks to engage the lock points and secure the FR to the PLST. An air valve controls the position of the lock hooks. Springs retain the hooks in the locked position. The PLST has a standard 12 volt electrical system with 24 volt military adapters (2). Also provided are two intervehicular electrical connecting cables of sufficient length to reach the towing truck. Two towing eyes (3), at the rear of the PLST permit towing with a medium duty tow bar. The spare tire carrier is ahead of the second axle in the center of the frame. The spare tire is held in place with bolts through the wheel bolt pattern. The spare tire and wheel assembly can be raised and secured in the spare tire carrier by the trailer-provided hand-operated winch. The PLST uses turntable-type steering for tracking and turning and is equipped with an air braking system. All three axles use 16.5 in. diameter by 7 in. wide (419 mm by 178 mm) S-cam brakes. The PLST has a dual brake system with separate service and emergency brake system. The PLST brake system is activated and charged by the truck air supply. The brakes are self-adjusting. Refer to TM 9-2330-385-14 for Operator's, Unit, Direct Support and General Support Maintenance for the PLS Trailer.

a. Service Brakes. The six service brakes on the PLST are powered by 24/20 inch (61/51 cm) brake chambers. Six inch automatic slack adjusters are provided with all brake chambers. The service brakes are activated when a signal from the foot-operated treadle valve or hand operated control valve is sent through a series of relay valves. The relay valves convert the proportioned service brake signal from the truck into a regulated service brake chamber pressure.

1-22. PLS TRAILER (PLST) (CONT).

b. Parking Brakes. Spring chamber parking brakes are provided on all PLST axles. The application and release of the six PLST spring brakes is controlled by a spring brake control valve. An absence of air pressure in the emergency/spring brake supply line causes the spring brake control valve to activate the spring brakes. The spring brake control valve also retains air pressure in the PLST air reservoir so the PLST spring brakes can be released by the spring release valve. The spring brake control valve also prevents compounding of pressures in the brake chambers by relieving the pressure on the spring brake side of the chambers when the spring brakes are set and the service brakes are applied. The PLST spring brake release valve is located on the right front corner of the trailer. This valve releases the PLST spring brakes without a prime mover air supply when there is sufficient air reservoir pressure. After the spring brakes have been released, they can be reapplied by actuating the release valve. When air is supplied through the emergency/spring brake supply line, the spring release valve is over-riden and the trailer spring brakes are released. If there is insufficient air reservoir pressure to release the trailer parking brakes, a cage nut release is provided on each spring chamber to mechanically release the spring brakes.

c. Emergency Brakes. Whenever there is a loss of pressure from the truck or PLST air reservoir, the emergency brakes are activated.

1-23. PLS FLATRACK (FR).




Figure 1-29. Palletized Load System Flatrack (FR)

The Flatrack (FR) (1) (Figure 1-29) accommodates a 33,000 lb. (15 metric tons) nominal payload during all modes of transportation and during all specified load/unload operations. The FR is designed to withstand the dynamic and static loads imposed while fully loaded during LHS load/unload operations. The FR has an empty weight of 3250 lb. (1476 kg) without sideboards. The FR can accommodate palletized, break bulk and 20 ft. (6.1 m) ISO container payloads. Tiedowns (2) and sideboards (3) are used to contain and hold cargo. Refer to TM 9-3990-206-14&P for Unit, Direct Support and General Support Maintenance for the PLS Flatrack.

CHAPTER 2

VEHICLE MAINTENANCE

Para	Contents	Page
2-1	Common Tools And Equipment	2-1
2-2	Special Tools, TMDE And Support Equipment	2-1
2-3	Repair Parts	2-2
2-4	Unpacking And Deprocessing	2-2
2-5	Hand Receipt Manual And Inventory Of Equipment	2-2
2-6	Service Before Operation	2-2
2-7	Troubleshooting Introduction	2-6
2-8	Troubleshooting Instructions	2-6
2-9	Introduction To Logic Tree Troubleshooting	2-35
2-10	Engine Troubleshooting Procedures	2-43
2-11	Transmission Troubleshooting Procedures	2-115
2-12	Air System Troubleshooting Procedures	2-176
2-13	Hydraulic System Troubleshooting Procedures	2-189
2-14	Load Handling System (LHS) Troubleshooting Procedures	2-246
2-15	Material Handling Crane (MHC) Troubleshooting Procedures	2-418
2-16	Self Recover Winch Troubleshooting Procedures	2-726
2-17	Steering System Troubleshooting Procedures	2-744
2-17.1	Airic Heater (Model B) Troubleshooting	2-768
2-18	Maintenance Introduction	2-850
2-19	Ground Handling	2-850
2-20	General Removal Instructions	2-850
2-21	General Disassembly Instructions	2-850
2-22	General Cleaning Instructions	2-851
2-23	General Inspection Instructions	2-853
2-24	General Welding Instructions	2-854
2-25	General Repair Instructions	2-855
2-26	General Assembly Instructions	2-855
2-27	General Installation Instructions	2-856
2-28	Preparation For Storage Or Shipment Introduction	2-862
2-29	Preparation For Storage Or Shipment	2-862
2-30	Storage Maintenance Procedures	2-862

Section I. REPAIR PARTS; SPECIAL TOOLS; TEST, MEASUREMENT, AND DIAGNOSTIC EQUIPMENT (TMDE); AND SUPPORT EQUIPMENT

2-1. COMMON TOOLS AND EQUIPMENT.

For authorized common tools and equipment, refer to the Modified Table of Organization and Equipment (MTOE) applicable to your unit.

2-2. SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT.

For a listing of special tools, TMDE, and support equipment, refer to the Tool Identification List, Appendix F, the Maintenance Allocation Chart (MAC) (TM 9-2320-364-20), and to the Repair Parts and Special Tools List (RPSTL), TM 9-2320-364-24P.

2-3. REPAIR PARTS.

Repair parts are listed and illustrated in the Repair Parts and Special Tools List (TM 9-2320-364-24P) covering Direct and General Support Maintenance for this equipment.

Section II. SERVICE UPON RECEIPT

2-4. UNPACKING AND DEPROCESSING.

a. Unpacking. Upon receipt of a new truck, the receiving organization must see if it has been properly prepared for service and is in good condition. Inspect all assemblies, subassemblies, and accessories to be sure they are in proper working order (TM 9-2320-364-10). Secure, clean, and correctly adjust and/or lubricate as needed (TM 9-2320-364-10 and TM 9-2320-364-20). Check all tools and equipment to be sure every item is accounted for (TM 9-2320-364-10-HR) in good condition, clean, and properly mounted or stowed (TM 9-2320-364-10).

b. Deprocessing. Read "Processing and Deprocessing Record of Shipping, Storage, and Issue of Trucks and Spare Engines" tag, (DD Form 1397) and follow all precautions checked. This tag should be attached to the steering wheel, shifting lever, or ENGINE START switch.

2-5. HAND RECEIPT MANUAL AND INVENTORY OF EQUIPMENT.

When a new truck is first received by the using organization, it is necessary to inventory the truck equipment. For detailed procedures, refer to Hand Receipt Manual, TM 9-2320-364-10-HR.

2-6. SERVICE BEFORE OPERATION.

a. General.

(1) Refer to TM 9-2320-364-10 for operating instructions for the truck.

(2) Upon receipt of a new, used, or reconditioned truck, the receiving organization must see if it has been properly prepared for service and is in good condition (TM 9-2320-364-10). Inspect all assemblies, subassemblies and accessories to be sure they are in proper working order. Secure, clean, and correctly adjust and/or lubricate (TM 9-2302-364-10 and TM 9-2320-364-20) as needed. Check all tools and equipment to be sure every item is there (TM 9-2320-364-10-HR), in good condition, clean, and properly mounted or stowed (TM 9-2320-364-10).

(3) Follow general procedures for all services and inspections given in TM 9-2320-364-10.

b. Inspection and Servicing Equipment.

NOTE

If truck has been driven to the using organization, most or all of the following work should have been done.

(1) When truck is received, inspect all items for damage that may have occurred during shipping and unloading operations. Pay close attention to any loose or missing nuts, bolts, screws, access plates, drain plugs, draincocks, oil plugs, assemblies, subassemblies, or components that may be easily lost or broken in transit. Check Basic Issue Items (BII) against checklist to make sure all items are accounted for and are in good condition (TM 9-2320-364-10-HR). Carefully list all discrepancies.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

- (2) Clean all exterior surfaces coated with rust-preventive compound with drycleaning solvent.
- (3) Perform the Unit Level Semiannual (6 month or 3,000-mile) Preventive Maintenance Checks and Services (PMCS), (TM 9-2320-364-20).
- (4) Lubricate specific points shown in TM 9-2320-364-10 and TM 9-2320-364-20 regardless of interval. Do not lubricate gear cases or engine. Check processing tag for gear case and engine oil. If tag states the oil is good for 500 mi (805 k) of operation and is of the proper grade for local climatic operation, check oil level but do not change oil.
- (5) Schedule a Semiannual service in accordance with DA Pam 738-750. Arrange for front tandem crossmember torque check (TM 9-2320-364-20) at 3,000 mi (4,827 km).
- (6) Activate battery if truck is delivered with dry-charged battery (TM 9-6140-200-14).

WARNING

- Do not remove the radiator cap when the engine is hot; steam and hot coolant can escape and burn personnel.
 - Use extreme care when removing the radiator pressure cap. Sudden release of pressure can cause a steam flash which could seriously injure personnel. Slowly loosen cap to the first stop to relieve pressure before removing cap completely. After opening, securely tighten cap.
 - Use a clean, thick waste cloth or like material to remove radiator pressure cap. Avoid using gloves. If hot water soaks through gloves, personnel could be burned.
- (7) Check radiator coolant. Check if solution is adequate for expected climatic conditions. Refer to TB 750-651 for preparation of antifreeze solutions. Put tag near filler cap with type of antifreeze and degree of protection written on tag.

2-6. SERVICE BEFORE OPERATION (CONT).

c. Special Service Instructions.

- (1) **Truck Body and Sheet Metal Inspection.**
 - (a) **Inspect body and sheet metal for evidence of damage during shipment.**
 - (b) **Check doors, latches, and hinges on compartments for proper operation.**
 - (c) **Check mounting hardware and tighten as necessary.**
- (2) **Truck Cab Inspection.**
 - (a) **Inspect cab for evidence of damage during shipment.**
 - (b) **Inspect windshields and window glass for cracks or other damage.**
 - (c) **Check door latches, hinges, and windows for proper operation.**
 - (d) **Check seats and seat belts to ensure they are securely installed, and that operator's seat adjustments are functioning properly.**
- (3) **Engine Inspection.**
 - (a) **Remove any seals, plugs or tape used to seal air inlets and ports on the engine during shipping.**
 - (b) **Check crankcase oil level with dipstick.**
 - (c) **Examine air cleaner element for dirty or restricted condition.**
 - (d) **Inspect engine and cooling hose connections for evidence of leakage.**
 - (e) **Clean away any obstruction of cooling air flow to radiator.**
- (4) **Transmission Inspection.**
 - (a) **Check fluid level with dipstick.**
 - (b) **Check external lines for evidence of leakage.**
- (5) **Transfer Case Inspection.**
 - (a) **Check level of lubricant at fill plug.**
 - (b) **Inspect lubrication pump and external lines for evidence of leakage.**
 - (c) **Operate driveline controls and observe power to front axle.**
 - (d) **Inspect bolts on driveline U-joints.**

- (6) **Electrical System Inspection.**
 - (a) Inspect battery cable connections and clean and tighten as necessary.
 - (b) Check light for burned out lamps, loose connections, and dirty or broken lenses.
 - (c) Ensure alternator is charging properly.
 - (d) Ensure all electrical equipment functions.
- (7) **Air System Inspection.**
 - (a) Drain any water from reservoirs.
 - (b) Inspect air hose and tubing connections for leakage.
- (8) **Steering System Inspection.**
 - (a) Check steering hydraulic reservoir for proper fluid level.
 - (b) Examine steering linkage and steering gears for damage incurred during shipment.
 - (c) Examine steering hoses and connections for evidence of leakage.
 - (d) Check steering system for proper operation during road test.
- (9) **Chassis and Running-Gear Inspection.**
 - (a) Check all lubricant levels.
 - (b) Check axle housing pressure vents to ensure freedom from foreign matter.
- (10) **Tire Inspection.**
 - (a) Check tire inflation.
 - (b) Inspect tires for serious cuts, bubbles, cracks, bruises, dry-rot, foreign objects, or exposure of internal cords. Remove foreign objects lodged between treads.
 - (c) Check all wheel mounting nuts for proper torque (TM 9-2320-364-10).
 - (d) Check front and rear suspension for broken spring leaves, damaged components, or damaged air bags.
- (11) **Fuel System Inspection.**
 - (a) Check fuel level and replenish, if necessary.
 - (b) Inspect fuel lines, connections, and filters for evidence of leakage.

Section III. TROUBLESHOOTING

2-7. TROUBLESHOOTING INTRODUCTION.

This section contains step-by-step procedures for identifying, locating, isolating and repairing equipment malfunctions.

This manual cannot list all malfunctions that may occur, nor all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify the supervisor.


2-8. TROUBLESHOOTING INSTRUCTIONS.

The first part of this section explains the use of the Troubleshooting Logic Tree. These procedures make use of Simplified Test Equipment for Internal Combustion Engines-Reprogrammable (STE/ICE-R), Detroit Diesel Electronic Control II (DDEC II) and Allison Transmission Electronic Control (ATEC) for testing and fault isolation. DDEC III/IV troubleshooting is located in the TM 9-2320-364-20.

a. Simplified Test Equipment for Internal Combustion Engines - Reprogrammable (STE/ICE-R). The PLS truck is equipped with several STE/ICE-R sensors that are used to support troubleshooting procedures. STE/ICE-R tests, employing these sensors, are incorporated into the standard troubleshooting tests to aid in fault isolation. The STE/ICE-R acts as a conventional digital multimeter to measure voltage, current and resistance. It can also measure pressure, speed, compression unbalance, engine power and some specialized battery and starter evaluations. The STE/ICE-R is powered by the truck batteries using an electrical harness called the Diagnostic Connector Assembly (DCA). The complete system includes a truck test meter (VTM), a transducer kit (TK), cables, transit case and technical publications. The STE/ICE-R can make TK measurements while connected to the DCA. STE/ICE tests are referenced. VIN number for PLS truck is "38".

b. Diagnostic Data Reader (DDR) Description.

- (1) DDR cartridge replacement.
 - (a) Disconnect DDR cable from DDL connector MC13.
 - (b) Hold DDR with thumbs placed against slanted surface and grasp cartridge with fingers.
 - (c) Squeeze DDR, push thumbs forward against slanted surface, and slide cartridge back at the same time.
 - (d) Slide cartridge from DDR.



- (e) Seat cartridge on back of DDR.



Damage will occur to the cartridge if it is held at an angle during installation. The cartridge must be held flat before sliding into place.

- (f) Slide cartridge forward until the cartridge clicks into place.
- (2) Cable connections to truck.
 - (a) The data/power cable must be connected to the truck before the DDR can function.
 - (b) The DDR will energize as soon as it is connected to the truck's electrical system and the ENGINE switch is turned ON. If it does not, there are several things to check.
 - (3) Troubleshooting.
 - (a) If the unit does not power up, check that the cartridge is plugged in correctly. Slide the cartridge out and plug it in again. If there is grease, oil or other grime on the edgeboard, carefully remove it with a soft cloth. DO NOT use solvents and DO NOT attempt to clean the terminals in the DDR unit itself.
 - (b) Check the 2-amp fuse located inside the cartridge. Remove the screws to disassemble the cartridge. Always use a 2-amp fuse for replacement.
 - (4) Readout window. The readout window contains a liquid crystal display (LCD). It has four lines, each with 20 characters. This provides a great deal of information at one time. A built-in backlight ensures that you will be able to read the display regardless of the lighting conditions in the truck. The readout uses letters, numbers and special symbols.
 - (5) Keypad.
 - (a) The keypad features 16 keys. They are totally sealed against contamination, including grease and fluids. You can clean them with a damp cloth or mild cleaner. DO NOT immerse the DDR in fluids; the edgeboard connector is NOT sealed.
 - (b) The keys operate with a soft touch, but unlike membrane keys, they "give" to indicate that your entry has been made.
 - (c) Ten NUMERIC KEYS arranged calculator-style for quick operation. Each key is imprinted with a single digit.
 - 1 To the right side of the keypad, there are four arrow keys, each imprinted with a direction arrow. The UP and DOWN arrow keys are used to scroll through the lines of the display. Each touch of a key causes the display to move one line, up or down. The LEFT and RIGHT arrow keys are used to toggle back and forth between choices given by the display; they may have other purposes, depending on which cartridge is used.

2-8. TROUBLESHOOTING INSTRUCTIONS (CONT).

- 2 The FUNC key, below the arrow keys, lets you choose various DDR modes, or functions, depending on the cartridge in use. These include several operating modes and a printing mode.
 - 3 The ENTER key lets you tell the DDR when to do something. Depending on what's showing in the readout window display, the ENTER key can make a selection, confirm an answer, or instruct the DDR to continue to the next step.
- (6) RS232 port. On the right side of the DDR case is an RS232 port. Using the proper cables, you can connect to a printer or terminal.
 - (7) DDL connector. The DDR receives information from the truck's on-board computer, the DDEC electronic control module (ECM) ATEC electronic control unit (ECU), through a connector called the Display Data Line (DDL). The DDL has 12 terminal cavities. The DDL adaptor plug is located on the left side of the cab at left door hinge area under the edge of the instrument panel.

c. DDEC II and DDEC III/IV Operation.

- (1) General instructions.
 - (a) The Check Engine Light (CEL) and Check Gages Light (CGL) will light for five seconds when the ENGINE switch is first turned ON as a bulb and system check. If the Check Engine Light remains on, the self-diagnostic system has detected a fault.
 - (b) The first step in diagnosis is identifying the symptom or problem condition. Always refer to DDEC II Troubleshooting (All Conditions) to begin troubleshooting.

Symptom A	CEL comes on and stays on
Symptom B	CEL is always off
Symptom C	CEL operates normally (comes on for up to 5 seconds, then goes off) and a fault is present
Symptom D	CEL and fault are intermittent
Symptom E	Engine cranks but will not start
Symptom F	CGL is always on or always off
 - (c) Once the key symptom is identified, refer to the fault index to find the page number of the flowchart for that symptom. Symptoms A, C, D and F's starting flowcharts will list secondary symptoms (Symptoms B and E have no secondary symptoms). Look to the right of the secondary symptom to find the page on which to begin troubleshooting. Go to that page.
 - (d) Diagnosis is built on codes that are displayed on the Diagnostic Data Reader (DDR) (Table 2-1). Since the self-diagnostics do not detect all possible faults, the absence of a code does not mean there are no problems in the system. If a DDEC problem is suspected (even in the absence of a code), go to the DDEC II Troubleshooting (All Conditions) flowchart, TM 9-2320-364-20 or DDEC III/IV Troubleshooting (All Conditions) flowchart, TM 9-2320-364-20. This chart can lead you to other charts which can aid in the troubleshooting process.
 - (e) If, after DDEC II or DDEC III/IV troubleshooting is completed and other symptoms remain, go to Engine Troubleshooting.
- (2) Using the Diagnostic Data Reader (DDR).
 - (a) Plug reader into truck connector and turn ENGINE switch ON.

Table 2-1. DDEC II System Code Index

Code Number	Affected Sensor	Description
11	Vernier Control	System on for 2 seconds with too low a voltage at the Vernier Control input to the DDEC ECM.
12	Vernier Control	System on for 2 seconds with too high a voltage at the Vernier Control input to the DDEC ECM.
14	Oil Temperature (OTS)	Engine running for 8 minutes with too high a voltage at the OTS input to the DDEC ECM.
15	Oil Temperature (OTS)	Engine running for 2 seconds with too low a voltage at the OTS input to the DDEC ECM.
21	Throttle Position (TPS)	System running for 2 seconds with too high a voltage at the TPS input to the DDEC ECM.
22	Throttle Position (TPS)	System running for 2 seconds with too low a voltage at the TPS input to the DDEC ECM.
23	Fuel Temperature (FTS)	Engine running for 8 minutes with too high a voltage at the FTS input to the DDEC ECM.
24	Fuel Temperature (FTS)	Engine running for 2 seconds with too low a voltage at the FTS input to the DDEC ECM.
25		NO CODES - No faults have been detected by DDEC since the last time the codes were cleared.
32		ECM FAILURE - The backup system inside the DDEC ECM has failed.
33	Turbo Boost (TBS)	Engine running (at less than 800 RPM or less than 30% of maximum torque) for 5 seconds with too high a voltage at the TBS input to the DDEC ECM.
34	Turbo Boost (TBS)	Engine running for 2 seconds with too low a voltage at the TBS input to the DDEC ECM.
35	Oil Pressure (OPS)	Engine running for 2 seconds at less than 800 RPM with too high a voltage at the OPS input to the DDEC ECM. Oil temperature must be greater than 60 degrees C to log this code.
36	Oil Pressure (OPS)	Engine running for 2 seconds with too low a voltage at the OPS input to the DDEC ECM.
41	Timing Reference (TRS)	The number TRS pulses received per revolution was incorrect or completely missing. One pulse per cylinder per revolution is required.
42	Synchronous Reference (SRS)	Did not receive an SRS pulse on every firing of the #1 cylinder.
44		HIGH OIL TEMPERATURE - System running for 2 seconds with the oil temperature greater than a calibrated limit.
45		LOW OIL PRESSURE - Engine running with the oil pressure less than the limit (different limits at different RPM's) for 7 seconds.
46		LOW BATTERY VOLTAGE - Engine running with low battery voltage (less than 10 volts) for more than 30 seconds.
51		EEPROM ERROR - An error has been detected in the EEPROM (Electrically Erasable, Programmable, Read Only Memory) inside the DDEC ECM.

2-8. TROUBLESHOOTING INSTRUCTIONS (CONT).

Table 2-1. DDEC II System Code Index (CONT).

Code Number	Affected Sensor	Description
52		ECM FAILURE - The DDEC ECM was unable to correctly convert sensor voltages into numbers for computer usage.
53		EEPROM ERROR - An error has been detected in the EEPROM inside the DDEC ECM which affects the logging of trouble codes.
56		ECM FAILURE - The DDEC ECM was unable to correctly convert sensor voltages into numbers for computer usage.
61 thru 68		RESPONSE TIME TOO LONG - The response time of the injector was longer than the maximum limit or the injector never responded at all. Oil temperature must be greater than 30 degrees C and battery voltage must be between 11 volts and 16 volts to log this code. The code is only logged at less than 2000 RPM.
71 thru 78		RESPONSE TIME TOO SHORT - The response time of the injector was shorter than the minimum limit. Oil temperature must be greater than 30 degrees C and battery voltage must be between 11 volts and 16 volts to log this code. The code is only logged at less than 2000 RPM.

- (b) When the reader powers up, observe the data readout window. It will remain on for several seconds. If the reader does not power up, check connections and be sure the ENGINE switch is ON.

MPSI PRO - LINK 9000
 SOFTWARE COPYRIGHT
 1989-91 VERSION 3.0
 DDEC I AND DDEC II

Data Readout Window

- (c) Observe the data readout window displaying a second message indicating communication with the DDEC Electronic Control Module (ECM). If needed, press ENTER on the DDR to display the screen.
- (d) After a few seconds, the first four lines in a data list will appear on the screen.
- (e) Use the UP and DOWN arrow keys to move through the list. The first four lines appear as follows:

01	ACTIVE CODES	YES
02	HISTORIC CODE	YES
04	ENGINE RPM	xxxx
05	ECM VOLTAGE	xxx

Data Readout Window

- (f) If, at any time, you observe a NO DATA message on the screen, check the cable connector and ensure the ENGINE switch is ON. Lastly, troubleshoot the DDEC ECM (Para 2-13).

- (g) Press the FUNC key to display the following screen:

FUNCTION SELECTIONS
SELECT DESIRED
MENU

[ENGINE] <----> PRO LINK

Data Readout Window

- (h) Use the LEFT arrow key to toggle to the ENGINE choice, then press ENTER.
- (i) Observe the Engine menu with a list of choices. You can move up and down on the list using the UP and DOWN arrow keys.

ENG MENU SELECTIONS
DIAGNOSTIC CODES

Data Readout Window

- (j) Select DIAGNOSTIC CODES and press ENTER to display the next menu screen:

DIAGNOSTIC CODE MENU
MODE 01
ACTIVE CODES

Data Readout Window

- (k) Use the UP and DOWN arrow keys to select MODE 1 ACTIVE codes, MODE 2 HISTORIC CODES and MODE 40 CLEAR CODES. Press ENTER for desired selections.
- (l) Generally, you will select ACTIVE CODES. Refer to the specific malfunction or condition and referenced instructions for more information. An ACTIVE CODE display resembles:

DDEC II S60 12.7
PTO
HIGH VOLTAGE
ACTIVE CODE 12

Data Readout Window

- (m) Clear DDEC codes.

CODES LAST CLEARED
AT XXXXXXXX.X ENG HRS
DO YOU WANT TO CLEAR
CODES YES <----> [NO]

Data Readout Window

2-8. TROUBLESHOOTING INSTRUCTIONS (CONT).

- 1 Select Mode 40 on the DDR.
- 2 Use arrow keys on the DDR to select YES.
- 3 Press ENTER.

NOTE

When ENTER has been pressed, the DDR will clear all stored codes and check the DDEC ECM to ensure all codes are cleared. The DDR will then display the results of the clearing function.

CODES NOT CLEARED
 ENTER TO RETRY
 FUNC TO EXIT

Data Readout Window

- 4 Press ENTER to retry the clearing function or FUNC to exit Mode 40.
- (3) Tools needed for DDEC diagnosis. The following tools and equipment are required to properly diagnose a complete system:
 - (a) Voltmeter and Ohmmeter: Use a digital volt-ohmmeter J-34029, or equivalent digital multimeter to measure voltage and resistance when required. A digital multimeter must be used when specified in the procedure.
 - (b) Test Light 6V: Use when specified in the procedure.
 - (c) Jumper Wires: Use to bypass a circuit and to insert between special connectors. This will permit access to the connector terminals for circuit checking.
 - (d) Diagnostic Data Reader (DDR) PRO LINK 9000: J38500-203.
 - (4) Reading diagnostic codes. If you have turned to this instruction to begin diagnosis of a problem and already know how to read, as well as understand Active and Historical codes, go to DDEC II Troubleshooting (All Conditions) and begin DDEC Troubleshooting.
 - (5) DDEC mode descriptions. Table 2-2 lists and describes each DDEC mode.
 - (6) Flashing DDEC codes. DDEC troubleshooting procedures are designed to be performed with the DDR. In situations where a DDR is not available, DDEC codes can be read by flashing them on the CEL. For example, codes 13 and 23 will be flashed as follows:
 - (a) Turn OFF ENGINE switch (TM 9-2320-364-10).
 - (b) Place a jumper wire between wires 435 and 451 on DDL connector MC13, terminals A and M.
 - (c) Turn ON ENGINE switch, observe the CEL and record the codes being flashed.
 - (d) The CEL will flash once for the one in the number 13 and pause for about a half a second.

Table 2-2. DDR Mode Index

Mode Number	Name	Description
01	ACTIVE CODES	If there is a condition present that causes the CEL to be ON, the condition is said to be active. An Active Code is set in DDEC ECM memory. The readout is YES if any active codes are present, and NO if there are none.
02	HISTORIC CODES	If a condition existed in the past to cause an active code, but the condition is no longer present, the condition is called historic. A Historic Code is set in DDEC ECM memory. The readout is YES if any historic codes are present, and NO if there are none. Engine protection codes (22, 44, and 45) will also store additional information, which will tell the engine hours when the code was set, the duration the code existed, and the number of times the code was logged.
04	ENGINE RPM	This displays the engine crankshaft revolutions per minute as determined from the timing reference sensor (TRS).
05	ECM VOLTAGE	This is the battery voltage available to the DDEC ECM.
07	TPS COUNTS	This is a digital value for the throttle position sensor (TPS). Range is 0 to 225 counts.
07	TPS IN %	This value is the percent opening of the throttle as determined from the throttle position sensor.
10	INJ RESP TIMES	This value is the fuel injector response time.
11	CYLINDER CUTOUT	Locates a cylinder whose output is different from other cylinders.
15	FUEL TEMP	This readout indicates the temperature of the fuel entering the engine in degrees Fahrenheit or Celsius, depending on which mode (English or Metric) you have chosen.
17	OIL PRS PSI (kPa)	Engine oil pressure is indicated in psi or kPa, depending on which mode (English or Metric) you have chosen.
18	OIL TEMP	This readout indicates the temperature of the engine oil in degrees Fahrenheit or Celsius, depending on which mode you have chosen.
19	BOOST PSI (kPa)	Turbo boost pressure is indicated in psi or kPa, depending on which mode you have chosen.
20	IDLE SPEED RPM	This is the engine idle RPM value.
21	PTO COUNTS	Power take-off counts is a digital representation of the PTO sensor voltage. Range 0 to 225 counts.
22	PTO SET RPM	This is an indication of the set RPM for the power take-off.
30	CHECK ENG LHT	This is an indication of the output command to the CEL. Readout is ON or OFF.
30	ENG BRK ENBLE	This is an indication of the status of the engine brake. Readout is ON or OFF.
30	STOP ENG LHT	This is an indication of the output command to the CGL. Readout is ON or OFF.
31	SRS RECEIVED	This is an indication of the signal from the synchronous reference sensor is being received. Readout is YES or NO.
40	CLEAR CODES	This mode is used to clear all stored codes in the DDEC ECM.

2-8. TROUBLESHOOTING INSTRUCTIONS (CONT).

- (e) Then the CEL will flash three times for the three in the number 13 and pause for about three seconds.
- (f) After the three second pause, the CEL will flash two times for the two in the number 23 and pause for about a half of a second.
- (g) After the half second pause, the CEL will flash three times for the three in the number 23.
- (h) The CEL will continue to flash in this manner until all of the DDEC codes in the DDEC ECM memory are displayed.
- (i) Turn OFF the ENGINE switch when all of the DDEC codes are flashed.
- (j) Remove the jumper wire.
- (k) Proceed to DDEC Troubleshooting (TM 9-2320-364-20) and the first code flashed by the CEL.

d. ATEC Operation.

- (1) The “CHECK TRANS” and “DO NOT SHIFT” lights will come ON when the ENGINE switch is first turned ON as a bulb and system check. If lights remain ON when truck is started and/or placed into gear, a failure has been detected. The ATEC ECU for the transmission will place a code into memory.
- (2) System selection procedure.
 - (a) Copyright screen. When the DDR powers up, the readout displays the copyright screen for several seconds.

MPSI PRO-LINK 9000
SOFTWARE COPYRIGHT
1989 VERSION 1.00
ATEC I

Data Readout Window

- (b) System selection process. In the ATEC I system, you must select the transmission type from the Transmission Type menu.

ATEC I SYSTEM
SELECT TRANS TYPE
MT(B) 600 OR V. HT (B)
OR C(L)(B)T 700

Data Readout Window

- (c) Note the arrow symbols in the DDR display. They remind you to use the UP and DOWN arrow keys to scroll to the desired transmission type. Each touch will move the display up or down by one item. If you hold an arrow key down, the display will scroll quickly. The list is circular; it will return to the beginning after the last one is viewed.

- (d) When you see the CLBT755 on the bottom line, press the ENTER key. The DDR now begins to display data. Refer to Step (4) (Data display).
- (3) Non-volatile memory. The ATEC cartridge has a non-volatile memory. This means that stored data are not lost when the DDR is disconnected from the truck power source.

NOTE

When the DDR establishes communication with the ATEC ECU in a truck, the DDR memory buffers are all cleared. You cannot use a truck's DDL connector to power your DDR to review recorded data. The recorded data will be lost.

- (a) When the DDR is connected to an external power source, for instance, at your workbench, the DDR recognizes that it is not communicating with an ATEC ECU. Under these conditions, the FUNC key is active. You can access stored data for review and printing. These include ATEC ECU operating data, diagnostic codes and snapshot data. For example, suppose you have used the DDR to store snapshot data during a road test. Later, using your workbench power supply, you can review the recorded data.
- (4) Data display.
- (a) Data readout. The main function of the DDR is to provide you with data from the truck's on-board computer, called the ATEC electronic control unit (ECU). This is what the DDR automatically does after the system type has been determined.
- 1 If the DDR is unable to establish communication with the ATEC ECU in the truck, you will see a NO DATA display. Press ENTER to command the DDR to try again.

NO ATEC DATA
RECEIVED

ENTER TO RETRY

Data Readout Window

- 2 If communication cannot be established and the NO DATA display reappears, see Step (4)(b).
- 3 When communication is established and the correct transmission type input, you will see the system confirmation screen.

ATEC I SYSTEM
DATA LIST
MT(B) 600 OR V. VH (B)
OR C(L)(B)T 700

Data Readout Window

2-8. TROUBLESHOOTING INSTRUCTIONS (CONT).

- 4** This display will appear for about three seconds.

<p>ECU A/N 16035879 DIAG CODES 21 32 TPS 128 CNTS 50 2% RANGE SEL N ATT N</p>
--

Data Readout Window

- 5** Use the UP and DOWN arrow keys to scroll through the entire data list. Pressing a key causes the display to move one line. Holding a key causes the display to scroll quickly. Pressing the LEFT arrow key causes the display to advance four lines. Pressing the RIGHT arrow key causes the display to move backward four lines. When you reach the end of the list, you will see the display that tells you which system you are testing.

NOTE

Parameters in the data list that do not pertain to the system you are testing will be designated by NA, meaning not available.

- 6** For an explanation of each of the items in the data list, refer to Steps (12) through (31) of this section.
- (b) What to do with NO DATA Readout. If you get the NO DATA message, there are several things to check:
- 1** Bad connection - Check the truck cable at each terminal for a good connection. In an extreme case, a wire may be broken in the truck cable or in the ATEC ECU wiring.
 - 2** Engine ON OFF switch - Be sure the ENGINE switch is ON.
 - 3** Bad ATEC ECU, or blown ATEC ECU fuse - If the ATEC ECU is incapable of transmitting data, the DDR will not receive any.
- (c) Data freeze operation.
- 1** There are times when you want to be able to quickly view several operating parameters at the same time, even though they are not normally together in the data list. One way to do this is to create a custom data list using the Custom Data List function. Another way is to use the Data Freeze function.

NOTE

There are two differences between Custom Data List and Data Freeze. In Custom Data, you can scroll the entire reorganized data list exactly like the normal data list. In Data Freeze, the items you “freeze” cannot be scrolled. The rest of the list scrolls normally. Also, you can use a custom list, but not a data freeze, when using Snapshot.

- 2** To freeze a line of data, follow Steps 3 through 5.

NOTE

You must be viewing the data list before you can freeze an item.

- 3** For the purposes of freezing data, the four lines in the readout display are numbered 1 through 4 from the top. Use the UP and DOWN arrow keys to scroll the data list. When an item you want to freeze is visible (on any readout line), press the numerical key that corresponds to the readout line of that item. A solid black square appears next to the item. In the following example, suppose you want to freeze OIL TEMP. To do so, press numerical key 3 because OIL TEMP is displayed on line 3.

LOCKUP RPM	1234
OUTPUT RPM	1234
OIL TEMP 123F	1234
FWD PRESS SW	OFF

Data Readout Window

- 4** Now, when you use the UP and DOWN arrows to scroll the data list, OIL TEMP remains frozen in position on the third line of the display. Although the item is frozen, its value is able to change, according to system operation.

RETARD REQUEST	YES
RETARD COMMAND	YES
OIL TEMP 123F	123C
SPECIAL INPUT	OFF

Data Readout Window

- 5** Now, suppose you also want to watch SPECIAL INPUT. Use the UP and DOWN arrow keys to scroll the list. As you can see above, the third line remains frozen. Eventually, your item appears on line 4. Press numerical key 4. The square will appear to indicate that line 4 is also frozen. You can continue doing this until you have frozen data on all four lines.
- (d) **Unfreezing data.** There are two ways to unfreeze data. To unfreeze just one line, press the numerical key corresponding to the line you want to unfreeze. The solid square disappears and the line can now be scrolled. To unfreeze the entire display at once, press the numerical key 0 (zero). All solid squares disappear and all lines are unfrozen.
- (e) **Functions.** The DDR's main purpose is to display data and it does this automatically. The DDR can also perform several other jobs, called functions. These functions are of two types. Some of them relate to the way DDR communicates with the ATEC ECU in the truck, such as diagnostic codes and ranges. Other functions relate to the way the DDR itself operates, such as Snapshot, RS-232 Serial Port and Contrast Adjustment.
- (f) **Use of the FUNC key.** For access to the functions, press the FUNC key. The DDR is programmed to provide access to only those functions that apply. If you see a function displayed, it is available to use. If you do not see a function displayed, it does not apply.

2-8. TROUBLESHOOTING INSTRUCTIONS (CONT).





- (5) **Diagnostic codes.** When the ENTER key is pressed on the DIAGNOSTIC CODES selection, the DDR will display the code number, along with a description of the code(s) stored in the ATEC ECU.
 - (a) When viewing DIAG CODES in the normal data list, the number on the left is usually a more severe code than the code on the right side of the display. If both memory locations have a code stored in the ATEC ECU, the arrows will appear on the bottom line of the code display screen.
 - (b) The readout contains the name of the system or component that caused the code to be set.

ATEC I DIAG CODES
SPEED SENSOR
CODE 22

Data Readout Window

- (c) Press the FUNC key to exit.

DIAGNOSTIC
DATA LINK
CONNECTOR MC13



TRANS
CHECK

- (6) Flashing ATEC codes. ATEC troubleshooting procedures are designed to be performed with the DDR. In situations where a DDR is not available, ATEC codes can be read by flashing them on the “TRANS CHECK” light. If “TRANS CHECK” light does not flash, no faults have been detected by ATEC since the last time the codes were cleared. For example, codes 13 and 23 will be flashed as follows:
- Turn OFF ENGINE switch (TM 9-2350-364-10).
 - Place a jumper wire between terminals A and B on DDL connector MC13.
 - Start engine, observe the “TRANS CHECK” light and record the codes being flashed.
 - The “TRANS CHECK” light will flash once for the one in the number 13 and pause for about a half a second.
 - Then the “TRANS CHECK” light will flash three times for the three in the number 13 and pause for about three seconds.
 - After the three second pause, the “TRANS CHECK” light will flash two times for the two in the number 23 and pause for about a half a second.
 - After the half second pause, the “TRANS CHECK” light will flash three times for the three in the number 23.
 - The “TRANS CHECK” light will continue to flash in this manner until all of the ATEC codes in the ATEC ECM memory are displayed.
 - Turn OFF the ENGINE switch when all of the ATEC codes are flashed.
 - Remove the jumper wire.
 - Proceed to ATEC Troubleshooting (TM 9-2320-364-20) and the first code flashed by the “TRANS CHECK” light.

- (7) Clear ATEC codes.
 - (a) Turn OFF ENGINE switch (TM 9-2320-364-10).
 - (b) Place a jumper wire between terminals A and B on DDL connector MC13.
 - (c) Start engine (TM 9-2320-364-10).
 - (d) Observe “TRANS CHECK” light for codes being flashed.
 - (e) Apply brake and shift the transmission in the following sequence:
 - 1 N (Neutral).
 - 2 D (Drive).
 - 3 R (Reverse) (Leave in reverse until “TRANS CHECK” light stops flashing, approximately five seconds).
 - 4 N (Neutral).
 - (f) If “TRANS CHECK” light stops flashing, codes have been cleared and fault corrected.
 - (g) If “TRANS CHECK” light continues flashing, fault has not been corrected.
 - (h) Turn OFF ENGINE switch.
 - (i) Remove jumper wire.
- (8) Range selected/range attained. When the driver selects a specific range for the transmission, the ATEC ECU begins shifting the transmission through the various ranges, depending on operating conditions, until the selected range is attained. Under some conditions, the range selected and the range attained will be the same. In other cases, the transmission will not attain the range selected. This information is of diagnostic value.
 - (a) When you select this function, the DDR reads out the range selected and the range attained.

RANGE SELECTED N	RANGE ATTAINED N
------------------------	------------------------

Data Readout Window

NOTE

In the diagnostic mode, the ATEC ECU update rate is approximately 1½ seconds. If the transmission is shifting rapidly, it is possible that the transmission may pass through several “attained” ranges more quickly than the readout can display them. This is not a fault of either the ATEC ECU or the DDR.

- (b) In this mode, the update rate is about ¼ of a second, so the values received will be more accurate than in the normal data list mode.

- (c) Range selected readout:

R - Reverse
 N - Neutral
 F5 - 1st through 5th (Drive)
 F4 - 1st through 4th (Drive)
 F3 - 1st through 3rd (Drive)
 F2 - 1st through 2nd
 F1 - 1st

- (d) Range attained readout:

R2 - Second reverse
 R - Reverse
 N - Neutral
 1C - 1st converter
 1L - 1st lockup
 2C - 2nd converter
 2L - 2nd lockup
 3C - 3rd converter
 3L - 3rd lockup
 4C - 4th converter
 4L - 4th lockup
 5C - 5th converter
 5L - 5th lockup

- (9) Custom data list. When you use your DDR to read data for an ATEC I system, it will be displayed in the same order each time because the list is fixed in the DDR’s memory.
- (a) There may be some instances when the programmed order of the data list is not convenient. For example, in order to solve a particular driveability problem, you need to look at TPS, Range SEL/ATT and Lockup RPM, all at the same time. But these three pieces of information are not together in the data list. The following text describes a method to watch all three items at the same time.
- (b) Locate Custom Data List in the DDR Main Function menu and press ENTER.
- (c) Once you enter the Custom Data List mode, you will be given a choice between continuing to use the standard list or creating a custom list. The default is STANDARD.

2-8. TROUBLESHOOTING INSTRUCTIONS (CONT).

```

SELECT DATA LIST
  DESIRED

(STANDARD)  CUSTOM
    
```

Data Readout Window

- (d) Use the LEFT and RIGHT arrows to toggle to your choice and press ENTER. Refer to Steps 1 and 2 for STANDARD instructions; or Step (e) for creating a custom list.

- 1 If you choose STANDARD, one of two things happens. If there was no custom list already in memory, you will be returned to the menu. If a custom list is still in DDR memory, you will see:

```

RESET CUSTOM LIST
ARE YOU SURE?

YES  [NO]
    
```

Data Readout Window

- 2 This display gives you the choice of continuing to use the existing custom list (choose NO) or creating a new custom list (choose YES). If you choose NO, you will return to the menu. If you choose YES, refer to Step (e) below. Press ENTER to confirm your choice.
- (e) Creating a custom list. You are now ready to actually create a new custom list. The available diagnostic parameter list is displayed on the bottom line, one item at a time. Use the UP and DOWN arrow keys to scroll the list.

```

SELECT PARAMETER
PRESS ENTER
Current line = 2
RANGE SEL/ATT
    
```

Data Readout Window

- 1 Line 4 now automatically indexes to the next item in the data list. Notice that the number on line 3 indicates that you are ready to select the parameter you want to place on the second line of your custom list. Use the UP and DOWN arrow keys to locate RANGE SEL/ATT in the list on line 4 and press ENTER. RANGE SEL/ATT is now entered on the second line of your customized list. Continue this process until you have located and entered each item you want on your customized list.
- 2 Press FUNC to exit. You can now use your customized list to read data. It is also available in Snapshot.

NOTE

If you change your mind while creating a custom list, you can use the LEFT arrow key to back up through the list. When the item you wish to change appears, simply scroll the parameter list to locate the new item and ENTER it. Also note that backing up through the list erases each item you pass through. You will have to recreate the list from the point of the change item.

- (10) **Snapshot.** The Snapshot function permits the DDR to record data while the truck is being driven. Then the data can be played back when you return to the shop. You can use this feature to locate operating problems that would be difficult to locate by any other method. Depending on truck type and the data rate, the DDR will record over 50 minutes of data.

NOTE

The amount of information that can be recorded is determined by the data update rate selected. Refer to Step (11)(f) (Data update rate).

- (a) When you are using Snapshot, the DDR is continuously recording data. When the memory is filled, the oldest data is dropped and the new data is continuously added. When an operating condition occurs, the DDR puts a marker in the data recording so you can find the exact spot later during play back. We call this ability to mark data for play back a “trigger”. Because driveability problems are often related to diagnostic codes, one of your choices is to use a diagnostic code as the trigger. You can choose any code, or a specific code to be the trigger. Or you can trigger the recorder yourself manually if a suspicious driveability condition occurs.
- (b) It is sometimes helpful to look at data that occurred before the operating condition happened, for instance, looking for an unnatural trend. It is also sometimes helpful to look at data that occurred after the operating condition happened. DDR allows you to decide ahead of time how much data will be retained before, as well as after, the trigger point.
- (c) When you select the Snapshot function, you will see the Snapshot menu selection readout. Choices include Quick Trigger, Trigger Set-Up, Data Update Rate and Review Snapshot.

<p>SNAPSHOT MODE XXX FRAMES FREE SELECTIONS QUICK TRIGGER</p>
--

Data Readout Window

NOTE

The second line indicates the amount of frames of memory available to record data. Although there is no simple way to relate frames to the amount of driving time that will be recorded, generally a larger number translates into more minutes of recording time than a smaller number.

- (d) **Quick trigger.** You will use Quick Trigger to start the snapshot process. If you are using Snapshot for the first time, selecting Quick Trigger automatically chooses the default operation. This is the manual Any Numeric Key trigger.

2-8. TROUBLESHOOTING INSTRUCTIONS (CONT).

- (e) If you are ready to take a second or third snapshot, using Quick Trigger permits you to use the operating parameters you used before. This means you do not have to constantly reset parameters.
- (f) Trigger setup. When you choose this menu entry, you can specify what will be used as the trigger.

SELECT SNAPSHOT
TRIGGER SOURCE
SELECTIONS
ANY NUMERIC KEY

Data Readout Window

- (g) Any numeric key. When you specify Any Numeric Key as the trigger, the DDR will place a marker in the recording at the time you press any of the numeric keys. You will probably use this trigger when you want to find the cause of a driveability problem that you can feel or hear when driving the truck. When the condition occurs, trigger the DDR by pressing any numeric key.
- (h) After entering Any Numeric Key, you will be given the opportunity to adjust the memory trigger point. Refer to Step (n) (Adjust memory trigger point).
- (i) If you choose diagnostic code as trigger source. If you decide to use a code as the trigger, you will be given two additional choices: Any Code or Specific Code.

SELECT SNAPSHOT
TRIGGER SOURCE
SELECTIONS
ANY CODE

Data Readout Window

- (j) If you use the ENTER key to choose Any Code, the DDR will recognize any diagnostic code as the trigger. You will now be given the opportunity to adjust the memory trigger point. Refer to Step (n) (Adjust memory trigger point).
- (k) If you use the ENTER key to choose Specific Code, the DDR will give you the opportunity to specify which code you want as the trigger.

SELECT CODE
CURRENT CODE [21]

CODE 21

Data Readout Window

- (l) The code presently chosen is enclosed in the brackets on line 2. There are two ways to choose another diagnostic code. You can input your choice with the numerical keys and press ENTER. Or you can use the UP and DOWN arrow keys to scroll the list. The code number choices appear on line 4. When you see the code you desire, press ENTER.

- (m) You will now be given the opportunity to adjust the memory trigger point. Refer to Step (n) (Adjust memory trigger point).
- (n) Adjust memory trigger point. You will get to this point, regardless of which trigger method you chose. Now you have the opportunity to determine where in memory you want the trigger.

DO YOU WISH
TO ADJUST THE MEMORY
TRIGGER POINT?
YES [NO]

Data Readout Window

- (o) If you do not wish to adjust the memory trigger point, press ENTER. The Snapshot function now begins. The readout displays the message: WAITING FOR TRIGGER.

ECU A/N 16035879
DIAG CODES 21 32
TPS 128 CNTS 50 2%
WAITING FOR TRIGGER

Data Readout Window

NOTE

To find out what happens when the trigger occurs, refer to Step (11) (Processing trigger).

- (p) If you do wish to adjust the memory trigger point, use the LEFT arrow key to toggle the indicator to YES and press ENTER. The display will now permit you to choose how much data you want retained in memory before and after the trigger point.

T INDICATES LOCATION
OF TRIGGER IN
MEMORY
BEG MID END
[T]

Data Readout Window

- (q) Use the LEFT and RIGHT arrows to move the T to the place you want the trigger to be. If you do not move the T, the DDR will continue recording data after the trigger occurs, placing the trigger in the middle of the data recorded. If you place the T at the right, the DDR will quit recording data as soon as the trigger occurs. All of the data recorded will be before the trigger point. If you place the T at the left, the DDR will continue recording data after the trigger occurs, placing the trigger at the beginning of the data recorded.

2-8. TROUBLESHOOTING INSTRUCTIONS (CONT).

NOTE

- The DDR begins recording data as soon as you see WAITING FOR TRIGGER on the bottom line of the readout. The DDR has no way of knowing when an operating condition is going to occur. So, when memory is full, the oldest data is dropped to make room for new data, in a continuing circular process. The trigger point you select actually determines how long the recording continues after the trigger occurs.
- To find out what happens when the trigger occurs, refer to Step (11) (Processing trigger).

(11) **Processing trigger.** While the DDR is waiting for the trigger to occur, the bottom line reads WAITING FOR TRIGGER. As soon as the trigger occurs (numeric key, any code, or specific code), the bottom line reads PROCESSING TRIGGER. This notice remains until the DDR has taken sufficient data to satisfy the trigger point location you selected.

(a) When the recording is completed, the display will change to permit you to play back the data recorded.

ECU A/N 16035879 DIAG CODES 21 32 TPS 128 CNTS 50 2% T=27 C=14 GO TO...
--

Data Readout Window

NOTE

- Refer to Step (b) (Review snapshot) to learn how to interpret this display.
- Regardless of which trigger you have chosen, when PROCESSING TRIGGER is visible on the readout, you can terminate the recording process at any time by pressing a numeric key.

(b) Review snapshot.

NOTE

The Review Snapshot mode choice does NOT appear in the Snapshot menu until you have actually triggered a recording.

(c) Choose this mode to play back the data recorded.

ECU A/N 16035879 DIAG CODES 21 32 TPS 128 CNTS 50 2% T=27 C=14 GO TO...
--

Data Readout Window

(d) The top three lines contain data. Use the UP and DOWN arrow keys to scroll through the list.

- (e) The bottom line contains the Snapshot operating information. The letter T indicates the number of the frame that contains the trigger. The letter C indicates the number of the frame you are CURRENTLY looking at. Use the LEFT and RIGHT arrow keys to increase or decrease the number of CURRENT frame. Observe the data as you move from one frame to the next. The display will show you the changes that took place. If you want to jump immediately to a specific frame, use the numeric keys to input the desired frame number. The numbers you input will replace the dashes after the GO TO. When you press ENTER, you will jump directly to the specified frame.

NOTE

- If you tell the DDR to GO TO a stream number larger than the highest one stored, the dashes will reappear.
 - If you plan to print out the data just recorded, write down the frame numbers of the data streams you want to print. You will need to know these frame numbers when you enter the Print function.
- (f) Data update rate. The data displayed by your DDR is updated at specified intervals. You can specify how often you want this to happen using Data Update Rate.

<p style="text-align: center;">DATA UPDATE RATE SELECT DELAY THEN PRESS ENTER CURRENT=0.0 NEW=0.0</p>

Data Readout Window

- (g) The amount of time that elapses between updates is called the delay. This can be varied from 0.0 to 9.9 seconds. Use the numerical keys to input a NEW delay rate. When this rate is displayed, press ENTER. The DDR will return to the Snapshot menu.
- (12) Contrast adjust. Contrast refers to the darkness of the readout letters and numbers when compared with the background. Under some viewing angles and at various air temperatures, you will be able to see the readout better if you adjust contrast.

NOTE

If you are using the DDR in direct sunlight, the heat of the sun may affect contrast. As temperature goes up, the display may darken. If so, adjust contrast.

- (a) To adjust contrast, select the Contrast Adjust function.

<p style="text-align: center;">DISPLAY CONTRAST TO CHANGE CONTRAST DEPRESS OR</p>

Data Readout Window

2-8. TROUBLESHOOTING INSTRUCTIONS (CONT).

- (b) You can change contrast by holding down either the UP or DOWN arrow key. Both keys cause the contrast to move through its entire range. You must hold the key down for several seconds. After the contrast reaches minimum, the readout will seem to disappear. This is normal. Simply keep holding the key down and the readout will return.
- (c) To exit Contrast Adjust, press the FUNC key.

NOTE

Each time the DDR is powered up, the contrast is automatically set at an average value.

- (13) **Restart.** When you select Restart and press ENTER, the DDR system restarts from the beginning (Step [2]). The copyright screen will not appear. The display will read: REQUESTING ATEC DATA. Refer to Step (2)(b) (System selection procedure) earlier in this manual.
- (14) **ECU/A/N.** The ATEC ECU and the calibration PROM together are identified by an 8-digit assembly number.
- (15) **Diagnostic codes.** When certain conditions occur, a diagnostic code will be set in one of two memory locations of the ATEC ECU. Both memory locations are displayed and the code in the left position is usually more severe to transmission operation.
- (16) **TPS counts and percent (%).** Throttle position sensor (TPS) monitors the position of the fuel control lever on the engine. The resulting voltage signal is converted to digital counts by the ATEC ECU. It is possible for the readout to range from 255 counts at idle to nearly 0 counts at open throttle. The throttle position count is converted by the ATEC ECU to percentage of throttle applied. It is possible for the readout to range from 0% (closed) to 100% (fully open).
- (17) **Range SEL.** When the truck driver operates the shift selector in the truck cab, the readout indicates the range selected. Note that this is the range selected, not necessarily the range the transmission actually attains. Also refer to Step (18) (Range ATT). The readouts include:

R - Reverse	F4 - 1st through 4th (Drive)
N - Neutral	F3 - 1st through 3rd (Drive)
F2 - 1st through 2nd	F5 - 1st through 5th (Drive)
F1 - 1st	

- (18) **Range ATT.** In response to the driver's request for a particular range, the ATEC ECU issues commands for the transmission to shift. Due to operating conditions, the range actually attained may or may not match the range selected. Also refer to Step (17) (Range SEL). The readouts include:

R2 - Second reverse	3C - 3rd converter
R - Reverse	3L - 3rd lockup
N - Neutral	4C - 4th converter
1C - 1st converter	4L - 4th lockup
1L - 1st lockup	5C - 5th converter
2C - 2nd converter	5L - 5th lockup
2L - 2nd lockup	

NOTE

In the diagnostic mode, the ATEC ECU update rate is approximately 1½ seconds. If the transmission is shifting rapidly, it is possible that the transmission may pass through several “attained” ranges more quickly than the readout can display them. This is not a fault of either the ATEC ECU or the DDR.

- (19) The readout displays the transmission output shaft speed (rpm) when the transmission made its last range upshift or downshift. Converter lockups are excluded. Due to the slow update rate of the ATEC ECU, be careful to match the displayed value with the proper shift. If you are not certain, use the transmission HOLD feature to inhibit unwanted shifts.
- (20) A speed sensor is located on the rear cover of the transmission to detect output shaft rpm. The readout shows actual transmission output shaft speed in revolutions per minute; the readout lower limit is 60 rpm.
- (21) The readout indicates the transmission output shaft speed (rpm) when the last converter lock-up (engage or disengage) occurred. When the converter is locked up (engaged), it provides a direct mechanical link from the engine through the converter. When the converter is not locked (disengaged), the converter pump and turbine are connected by hydraulic fluid only. Lock-up rpm is generally different at closed and open throttle positions.
- (22) Oil temperature. A temperature sensor is located in the transmission sump on CLT755 transmission. It is located in the lock-up valve body assembly. High oil temperature may result from overfilling or cooling system problems. Low oil temperature may result from cold weather conditions. The readout provides both Fahrenheit (-60°F to 350°F) and Celsius (-51°C to 177°C).
- (23) FWD PRESS SW. A pressure switch in the transmission detects if the transmission has attained a forward range. The readout is ON when there is forward pressure and OFF when there is no forward pressure. Because the ATEC ECU needs input from both forward and reverse switches to determine neutral range, refer to Step (24) (REV PRESS SW). Neutral is indicated when both readings are OFF.
- (24) REV PRESS SW. A pressure switch in the transmission detects if the transmission has attained a reverse range. The readout is ON when there is reverse pressure and OFF when there is no reverse pressure. Because the ATEC ECU needs input from both forward and reverse switches to determine neutral range, refer to Step (23) (FWD PRESS SW). Neutral is indicated when both readings are OFF.
- (25) When the transmission has been placed in reverse range, the readout indicates ON as a reverse warning signal. When the transmission is shifted from reverse range, the readout displays OFF.

NOTE

Oil level and fluidic sensor systems are used to detect low oil level conditions. The readout is OFF when a low oil level condition is detected. The readout is ON when the oil level is above the low oil level detection point.

- (26) Oil lube/LVL SW. This type of oil condition indicator is fluidic. The switch is used in the PLS truck.
- (27) Retard request. On the PLS truck, an instrument panel-mounted control is used to request operation of the engine brake. The readout indicates ON when the engine brake is requested and OFF when the engine brake is not requested. Refer to Step (28) (Retard command) for further information.

2-8. TROUBLESHOOTING INSTRUCTIONS (CONT).

- (28) Retard command. When the retard control is operated (see Step [27] Retard request) the ATEC ECU gives a command to operate the engine brake. The readout indicates YES when the retard command is given and NO when the command is not given.
- (29) Special input. This readout indicates the position of a special input switch used for certain options, ON or OFF.
- (30) Range commanded. This is the output signal to indicate that a specific gear range has been attained. The readout is YES or NO.
- (31) Input voltage. The readout indicates the voltage available to the ATEC ECU.

e. *Measurements Required for Troubleshooting.*

CAUTION

Use proper sized test leads and ensure care is used when checking for resistance, continuity or voltage at connectors or damage to equipment can result.

- (1) Resistance measurements.
 - (a) Connect red test lead to Volt-Ohm input connector and black lead to COM input connector on meter.
 - (b) Set the function/range switch to the desired ohm position. If the magnitude of the resistance is not known, set the switch to the highest range, then reduce until a satisfactory reading is obtained.
 - (c) If the resistance being measured is connected to a circuit, turn ENGINE switch OFF.
 - (d) Connect test leads to the circuit being measured. When measuring high resistance, be careful not to contact adjacent points, even if they are insulated. Some insulators have a relatively low insulation resistance which can affect the resulting measurement.
 - (e) Read the resistance value on the digital display.
- (2) Continuity checks.
 - (a) Place the function/range switch in any ohm range.

NOTE

- Some meters show "1+m", or simply "1" when function/range switch is in any ohm position.
- (b) Connect the red test lead to the Volt-Ohm input connector and black lead to COM input connector on the meter. When the test leads are separated or measuring an out-of-range resistance, the digital display will indicate "OL" (Over Limit).
 - (c) Put one test probe at one end of the wire or circuit to be tested. Use the other test lead to trace the circuit. When continuity is established, an ohm symbol will appear in the upper left corner of the digital display. If contact in the wire is maintained long enough (about 1/4 of a second), the OL will disappear and the resistance value of the wire or circuit will appear next to the symbol.
 - (d) If your multimeter does not work in this manner, learn how it operates before performing troubleshooting.

- (3) **Voltage measurements.** The PLS truck is equipped with both 12 vdc and 24 vdc circuits. Troubleshooting procedures will reference 12 vdc and 24 vdc measurements, however these values can vary. When the batteries are fully charged, 12.6 vdc can be measured on an open 12 volt circuit and 14.5 vdc can be measured when the engine is running at 1000 rpm. When the batteries are fully charged, 25.2 vdc can be measured on an open 24 volt circuit and 29 vdc can be measured when the engine is running at 1000 rpm.
- (a) Connect the red test lead to the volt-ohm input connector and the black lead to the COM input on the meter. If a DC-AC switch is present, make sure it is set to the DC position.
 - (b) Set the function/range switch to the desired volts position. If the magnitude of the voltage is not known, set the switch to a range which will be able to read most voltages seen on the truck (typically, a 200V range will do). Then reduce the range until a satisfactory reading is obtained.
 - (c) Connect the test leads to the circuit being measured. In the DDEC II diagnostic procedures, voltage measurements are always given as being taken at pins, sockets, battery (+) or ground. Following the voltage measurement point, the color test lead tube used is given in parenthesis (red is volt-ohm connection and black is the COM connection).

f. General Relay Troubleshooting Procedures. The following general relay troubleshooting procedures apply to all PLS relays.

NOTE

Configuration data covering each relay is listed in Table 2-3.

- (1) Pull relay out of socket just enough for the relay terminals to make contact with receptacle terminals. Leave about 1/4 to 3/8 in. (6.35 to 9.53 mm) space between the relay and relay socket to insert a multimeter lead and make contact with the terminal listed in the troubleshooting test.
- (2) Perform truck operation that will actuate the relay in question.

g. General Wire Test Procedures. PLS troubleshooting isolates problems down to the components that could cause a specific failure. When all of the components in a circuit are tested without isolating a fault, the wires are the only other components that could be suspected of being damaged. Each wire that must be tested may pass through two or more connectors. The following procedures provide general instructions for testing electrical wires. These procedures will either attempt to measure a voltage at the working end of a circuit or continuity from the power end of a specific wire to the working end. Before either of these tests are performed, all connectors in the circuit must be checked for looseness.

CAUTION

Use proper sized test leads and ensure care is used when checking for resistance, continuity or voltage at connectors or damage to equipment can result.

- (1) **Wire voltage drop test.**
 - (a) Disconnect connector from the component (light, relay, motor, etc.) at the working end of the circuit.
 - (b) Check connector terminal(s) for damage; repair or replace connector as necessary.
 - (c) Setup truck conditions that will create voltage at the working end of the wire.

2-8. TROUBLESHOOTING INSTRUCTIONS (CONT).

NOTE

PLS is equipped with 12 vdc and 24 vdc circuits. The troubleshooting fault that referenced these general wire tests will provide voltage information for testing wires.

- (d) Check for the required voltage at the working end of the wire.
 - 1 If the required voltage is not measured at the working end of the wire, go to Step (e).
 - 2 If the required voltage is measured at the working end of the wire, the fault has not been isolated. Continue with the fault isolation tests or notify supervisor.
- (e) Disconnect the first connector in line from the working end of the wire to the power source.
- (f) Check for the required voltage at the working end of the wire.
 - 1 If the required voltage is not measured at the working end of the wire, go to Step (g).
 - 2 If the required voltage is measured at the working end of the wire, a fault is in the section of wire most recently disconnected. Repair the wire and perform the voltage test again.
- (g) Repeat Steps (d) and (e) until all sections of the suspect wire are tested.
- (2) Wire continuity test.
 - (a) Disconnect wire from the component (light, relay, motor, etc.) at the working end of the circuit and from the power end.
 - (b) Setup truck conditions that will create the desired circuit.
 - (c) Check continuity from power end of the wire to the working end of the wire.
 - 1 If continuity is not measured go to Step (d).
 - 2 If continuity is measured, the fault has not been isolated. Continue with the fault isolation tests or notify supervisor.
 - (d) Disconnect the first connector from the working end of the wire in line to the power source.
 - (e) Check continuity.
 - 1 If continuity is not measured, go to Step (f).
 - 2 If continuity is measured, a fault is in the section of the wire most recently disconnected. Repair the wire and perform the continuity test again.
 - (f) Repeat Steps (d) and (e) until all sections of the suspect wire are tested.
- (3) Wire harness shorting wires test.
 - (a) Disconnect wire harness connector with wire suspected of damage.

Table 2-3. Relay Configuration Data

Voltage	Relay No.	Nomenclature	Terminal No./Wire No.					Coil Resistance	12 vdc into Relay at Terminal	24 vdc into Relay at Terminal	Contact Position 30 to 87A and 30 to 87 at Position
			30	85	86	87	87A				
12 volt	R1	Head Lts	1927	1049	1435	1017/ 1017	--	Position 85-86/ 85 ± 15 ohms	85 30		Closed Open
12 volt	R2	Cl. Lts	1835	1920	1435/ 1435	1012/ 1017	--	Position 85-86/ 85 ± 15 ohms	85 30		Closed Open
12 volt	R3	Horn	1026	1031	1016	1168	--	Position 85-86/ 85 ± 15 ohms	85 30		Closed Open
12 volt	R4	Work Lt	1040	1040A	1435/ 1435	1040B	--	Position 85-86/ 85 ± 15 ohms	85 30		Closed Open
12 volt	R5	Dimmer	1017	1017A	1435/ 1435	1007	1006	Position 85-86/ 85 ± 15 ohms	85 30		Closed Open
12 volt	R6	Beacon	1413	1184	1435/ 1435	1029	--	Position 85-86/ 85 ± 15 ohms	85 30		Closed Open
12 volt	R7	Trans	1713	508/ white	1711/ white	1839	--	Position 85-86/ 85 ± 15 ohms	86 30		Closed Open
12 volt	R8	Retarder	1839/ 211	213	1871/ 1871	1716/ 1714	--	Position 85-86/ 85 ± 15 ohms	86 30		Closed Open
12 volt	R9	Ck. Trans	1409	215	1517	--	1435	Position 85-86/ 85 ± 15 ohms	86 30		Closed Open
12 volt	R10	Reverse	1891	214	1871/ 1871	1149	--	Position 85-86/ 85 ± 15 ohms	86 30		Closed Open
12 volt	R11	Neutral	1021/ 1021	231	1871/ 1871	1021A	--	Position 85-86/ 85 ± 15 ohms	86 30		Closed Open
24 volt	R12	24 Volt	1189	1435/ 1435	1872	1189	--		30	86	Closed Open

Table 2-3. Relay Configuration Data - CONT.

Voltage	Relay No.	Nomenclature	Terminal No./Wire No.					Coil Resistance	12 vdc into Relay at Terminal	24 vdc into Relay at Terminal	Contact Position 30 to 87A and 30 to 87 at Position
			30	85	86	87	87A				
12 volt	R13	Trailer B.O. Stop	1676/ 1676	1435/ 1435	1678	1678C	--	Position 85-86/ 85 ± 15 ohms	86 30		Closed Open
12 volt	R14	Trailer Serv Tail	1676/ 1676	1435/ 1435	1017	1008C	--	Position 85-86/ 85 ± 15 ohms	86 30		Closed Open
12 volt	R15	L.H. Turn	1676/ 1676	1435/ 1435	1003	1003C	--	Position 85-86/ 85 ± 15 ohms	86 30		Closed Open
12 volt	R16	R.H. Turn	1676/ 1676	1435/ 1435	1004	1004C	--	Position 85-86/ 85 ± 15 ohms	86 30		Closed Open
12 volt	R17	Trailer B.O. Tail	1676	1435/ 1435	1680	1680C	--	Position 85-86/ 85 ± 15 ohms	86 30		Closed Open
24 volt	R18	DDEC	1075B	1435	1872	1871	--			86 30	Closed Open
24 volt	R19	Trans DDEC	1867	1435/ 1435	1872/ 1872	1875	--			86 30	Closed Open
24 volt	R20	Interaxle	1882/ 1882	1884	1888/ 1888	1889	--			86 30	Closed Open
24 volt	R21	Diff Lock	1882	1885	1888	1890	--			86 30	Closed Open
24 volt	R22	Crane Hi Idle	510	231	1737	510	--			86 30	Closed Open
24 volt	R23	Hi Range Lockout	1885	1435/ 1435	1095	1885	--			86 30	Closed Open
24 volt	R24	T.C. Dual Mode	309	1435/ 1435	1095	315/ 313	--			86 30	Closed Open

- (b) Set multimeter select switch to ohms.
- (c) Connect positive (+) multimeter lead to harness connector terminal of the suspected wire.
- (d) Connect negative (-) multimeter lead to each of the other terminals in the harness connector.
 - 1 If there is continuity, the suspected wire and the wire where continuity is measured are shorting together; repair wire.
 - 2 If there is no continuity, all wires are OK.
- (4) Wire repair. Refer to TM 9-2320-364-20 for the repair of wire harness connectors. Refer to TM 43-0158 for detailed instructions concerning electrical wiring repairs. Wire harness repair is limited to splicing and taping of wires at Unit Maintenance. If a wire harness cannot be repaired, notify DS Maintenance.

2-9. INTRODUCTION TO LOGIC TREE TROUBLESHOOTING.

- a. *Page Layout.* Troubleshooting procedures are divided into logic tree pages and test pages.
 - (1) A logic tree page is always a left-hand page, facing the test page on the right. The logic tree page provides the sequence of steps required to isolate a fault to a failed component. All critical information for decision making is on the left-hand page. Each logic tree page contains the following information:
 - (a) **INITIAL SETUP** - This box is located only on the first logic tree page of a fault. INITIAL SETUP lists tools, materials, references, personnel and equipment needed to troubleshoot the fault.
 - (b) **KNOWN INFO** - This box is located in the top left-hand column. KNOWN INFO lists conditions and information that will eliminate specific components as the cause of the fault.
 - (c) **POSSIBLE PROBLEMS** - This box is located directly below KNOWN INFO. All of the system components that could cause a fault are listed in the POSSIBLE PROBLEMS box. The first component listed in the POSSIBLE PROBLEMS box is the one that will be tested at that step in the logic sequence. When one of the components is tested and found to be operational, it is entered at the bottom of the KNOWN INFO box as OK.
 - (d) **QUESTION** - Each question, located in the middle column, refers to the first possible problem listed in POSSIBLE PROBLEMS. If the answer to the question is YES, proceed to the next step. If the answer is NO, follow the NO arrow to obtain directions for correcting the problem. If the step contains a WARNING or CAUTION message, a small shadow box is printed above the question. Text for WARNINGS or CAUTIONS is on the following right-hand page.
 - (e) **TEST OPTIONS** - This box is located in the top right-hand column. TEST OPTIONS lists tests available for testing parts suspected of failing.
 - (f) **REASON FOR QUESTION** - This box is located directly below TEST OPTIONS. It explains the purpose for the question in the middle column.

2-9. INTRODUCTION TO LOGIC TREE TROUBLESHOOTING (CONT).

- (2) A test page is always a right-hand page, facing the logic tree page on the left. The test provides detailed instructions for testing the first component listed in the POSSIBLE PROBLEMS box. This test will also provide an answer for the question in the middle column. Note the arrow connecting the test on the right-hand page to the REASON FOR QUESTION. When possible, illustrations are included to provide visual details. Warnings, cautions, and notes contain additional information for testing.

b. How to Begin Troubleshooting.

- (1) Determine the symptom or condition that indicates a problem or failure. Troubleshooting is divided into symptoms peculiar to a truck system or component, for example: air system or engine. Refer to the Troubleshooting Fault Index (Table 2-4). Follow DDEC II and DDEC III/IV Troubleshooting BEFORE going to Engine Troubleshooting.
- (2) Go to the referenced page to begin troubleshooting. Open the manual flat so both the left-hand and right-hand pages are displayed before you. The information on both pages is important to resolve the problem or failure. However, the experienced technician can follow the left-hand page instructions and refer to the right-hand page when necessary.
- (3) Follow the Diagnostic Procedure. Answer question no. 1 on the left-hand page and follow the YES or NO path to either the remedy or the next question. If necessary, look on the right-hand page for test instructions and illustrations.
- (4) Observe warnings, cautions and notes. The formatting and symbols used in this manual for warnings, cautions and notes are as follows:

WARNING

This is the symbol for a warning statement. If you see the word WARNING above a question on the left-hand page, look on the right-hand page for the text of the message. WARNINGS describe a situation which could cause severe injury or death to personnel.

CAUTION

This is the symbol for a caution statement. If you see the word CAUTION above a question on the left-hand page, look on the right-hand page for the text of the message. CAUTIONS describe a situation which could cause damage to equipment.

NOTE

This is the symbol for a note. Notes are located directly above the test to which they refer. Notes provide additional information for performing a test.

c. Abbreviations and Commonly Used Terms.

- (1) A/D - Analog to Digital: The computer inside the DDEC ECM uses an A/D converter to convert a sensor voltage into a number with which the computer can work.
- (2) Active Codes - These are the codes that currently keep the Check Engine Light on. They can only be read using the Diagnostic Data Reader.
- (3) BAT - Battery.

- (4) CEL - Check Engine Light: Mounted on the dash panel. Has two functions:
 - (a) Serves as a warning lamp to tell the driver that a problem has occurred and that the truck should be taken in for service as soon as possible.
 - (b) Serves as a light bulb check and system check. The Check Engine Light (CEL) will come on for about 5 seconds when the ENGINE switch is turned ON. If the CEL remains on, the self-diagnostics system has detected a problem. If the problem goes away, the light will go out, but the HISTORICAL trouble code will be stored in the DDEC ECM memory.
- (5) CGL - Check Gages Light: Mounted on the dash, it lights to warn the driver when a potential engine damaging condition has been detected (low oil pressure, low coolant, or engine over temperature). As a light bulb check, the CGL will come on for about 5 seconds when ignition switch is placed in the ON position.
- (6) CKT - Circuit.
- (7) COM - Common.
- (8) DCA - Diagnostic Connector Assembly: An electrical harness on the truck which allows the STE/ICE-R to be powered and to make measurements of key truck signals from a single connection. In addition to many basic electrical signals such as starter voltage and current, it includes engine speed and fuel return pressure. The STE/ICE-R can make TK measurements while connected to the DCA.
- (9) DDEC II - The Detroit Diesel Electronic Controls, second generation.
- (10) DDEC III - The Detroit Diesel Electronic Controls, third generation.
- (10.1) DDEC III/IV - The Detroit Diesel Electronic Controls, fourth generation.
- (11) DDL - Diagnostic Data Link: The lines (wires) over which the DDEC ECM communicates information to be read by a Diagnostic Data Reader.
- (12) DDR - Diagnostic Data Reader: The hand-held tool used for troubleshooting with the DDEC (DDR or PRO-LINK 9000).
- (13) Diagnostics - Troubleshooting by following an exact procedure.
- (14) DL+ - Data Link, positive side. Used for communications to the Diagnostic Data Reader, as well as other applications.
- (15) DL- - Data Link, negative side. Used for communications to the Diagnostic Data Reader, as well as other applications.
- (16) DREQ - Diagnostic Request Terminal: The pin on the DDL connector which must be grounded to obtain diagnostic codes (pin M).
- (17) ECM - Electric Control Module: The brains of DDEC II and DDEC III/IV. It receives input from the DDEC II and DDEC III/IV sensors and switches, calculates injector firing times and duration (using a built-in computer) and fires the injectors at the appropriate times. The ECM is powered by a 12 vdc input voltage.
- (18) EEPROM - Electronically Erasable Programmable Read Only Memory: Contains the engine calibration.
- (19) EFPA - Electronic Foot Pedal Assembly.
- (20) Erratic - Intermittent.

2-9. INTRODUCTION TO LOGIC TREE TROUBLESHOOTING (CONT).

- (21) **EUI - Electronic Unit Injector.**
- (22) **Historical Codes - All codes kept in DDEC ECM memory (may not trip the CEL). These codes can be cleared by using the Diagnostic Data Reader.**
- (23) **OPS - Oil Pressure Sensor: Monitors oil pressure at the main oil gallery.**
- (24) **OTS - Oil Temperature Sensor: Monitors oil temperature in the turbo oil supply line.**
- (25) **PW - Pulse width: The amount of time in crank degrees that the DDEC ECM is requesting the injectors to be turned on.**
- (26) **SRS - Synchronous Reference Sensor: Detects when the first cylinder in the firing order is about to be fired.**
- (27) **STE/ICE-R - Simplified Test Equipment for Internal Combustion Engines - Reprogrammable: A testing system used for performing tests and measurements on the truck. In addition to acting as a conventional digital multimeter to measure voltage, current and resistance, it is also capable of measuring pressure, speed, compression, unbalance, engine power and some specialized battery and starter evaluations. It is powered by the truck batteries. The complete system includes a truck test meter (VTM), a transducer kit (TK), cables, transit case and technical publications. STE/ICE tests are referenced.**
- (28) **System - A collection of devices which all are related to each other because they depend on each other to do some function or job. For example, the function of the fuel system is to inject fuel into the cylinders at the correct time in the correct amount and with the correct quantity. The collection of devices that are required to do this include the fuel pump, fuel lines, lift pump, fuel filter and injectors.**
- (29) **TBS - Turbo Boost Sensor: Used to monitor turbo boost pressure. The sensor generates a voltage (from 0 to 5 volts) which is proportional to pressure.**
- (30) **Test Chain: A series of tests to be followed in a particular order or sequence (numbered).**
- (31) **TPS - Throttle Position Sensor: Used to detect throttle position (percent of throttle).**
- (32) **Troubleshooting - The process of making measurements and observing the operation of the truck to find out if and where any problems exist.**
- (33) **TRS - Timing Reference Sensor: Detects whenever any cylinder is about to be fired.**
- (34) **VIN - Vehicle Identification Number.**
- (35) **VTM - Truck Test Meter: A box which performs the measurement and analysis functions of the STE/ICE-R system.**

Table 2-4. Troubleshooting Fault Index

Fault Number	Troubleshooting Procedure	Page Number
ENGINE SYSTEM FAULT INDEX		
1.	Engine Does Not Develop Full Power	2-44
2.	Engine Overheats (Water Temperature Gage Continuously Reads Over 230°F [110°C])	2-64
3.	Low Engine Oil Pressure (Less Than 5 psi [34 kPa]) At Idle, Less Than 40 psi (276 kPa) During Normal Operation	2-70
4.	Excessive Black Or Gray Exhaust Smoke (Engine At Normal Operating Temperature)	2-80
5.	Excessive Oil Consumption Or Blue Exhaust Smoke (Engine At Normal Operating Temperature)	2-92
6.	White Exhaust Smoke (Engine At Normal Operating Temperature)	2-104
TRANSMISSION SYSTEM FAULT INDEX		
1.	Low Oil Level Sensor Circuit Faulty	2-116
2.	Forward Pressure Switch Circuit Faulty	2-124
3.	Reverse Pressure Switch Circuit Faulty	2-130
4.	Oil Temperature Sensor Circuit Faulty	2-136
5.	Solenoids J, F, D, C, B, A, G, E Or H Circuit Faulty	2-140
6.	Transmission Overheats (Trans Temp Gage Continuously Reads Over 220°F [104° C])	2-146
7.	Transmission Unusually Noisy When Operating	2-152
8.	Transmission Will Not Shift Into Gear, Shifts Out Of Gear, Does Not Respond To Range Selection, Or Operates Abnormally	2-160
9.	Engine Stalls When Transmission Is Shifted Into Gear	2-168

Table 2-4. Troubleshooting Fault Index (CONT).

Fault Number	Troubleshooting Procedure	Page Number
AIR SYSTEM FAULT INDEX		
1.	Air Pressure Buildup Is Slow	2-178
2.	Noisy Air Compressor Operation	2-184
MAIN HYDRAULICS SYSTEM FAULT INDEX		
1.	Crane And Winch Operate Slowly	2-192
2.	Fan, LHS, Winch And Crane Do Not Operate Or Operate Slowly	2-196
3.	LHS, Winch And Crane Operate Slowly	2-202
4.	Fan Does Not Operate	2-206
5.	Fan Speed Does Not Decrease From High To Low Speed	2-214
6.	Fan Does Not Operate At High Speed	2-224
7.	Hydraulic System Operation Unusually Noisy	2-240
LOAD HANDLING SYSTEM (LHS) FAULT INDEX		
1.	Loss Of Hook Arm Safe Lowering	2-250
2.	Loss Of Middle Frame Safe Lowering	2-264
3.	Hook Arm Does Not Load	2-270
4.	Hook Arm Does Not Unload	2-286
5.	Loss Of Hook Arm Load Holding	2-302
6.	Middle Frame Does Not Load	2-322
7.	Middle Frame Does Not Unload	2-342
8.	Middle Frame Does Not Operate	2-360
9.	LHS Does Not Operate Or Operates Slowly	2-370
10.	Loss Of Middle Frame Load Holding	2-390
11.	LHS Hook Arm Disengages From Flatrack While Unloading	2-410

Table 2-4. Troubleshooting Fault Index (CONT).

Fault Number	Troubleshooting Procedure	Page Number
CRANE SYSTEM FAULT INDEX		
1.	Outriggers Do Not Operate Or Operate Slowly	2-428
2.	LH Outrigger Does Not Operate	2-446
3.	RH Outrigger Does Not Operate	2-460
4.	Four Valve Bank Functions (Swing, Lift, Telescope And Hoist) Do Not Operate Or Operate Slowly	2-474
5.	Mast Does Not Operate Or Operates Slowly	2-482
6.	Mast Does Not Raise	2-502
7.	Mast Does Not Lower	2-508
8.	Crane Does Not Swing Or Swings Slowly	2-514
9.	Crane Does Not Swing Clockwise (CW)	2-532
10.	Crane Does Not Swing Counter Clockwise (CCW)	2-540
11.	Boom Does Not Telescope In Or Telescopes In Slowly	2-548
12.	Boom Does Not Telescope Out Or Telescopes Out Slowly	2-562
13.	Boom Does Not Telescope Or Telescopes Slowly	2-576
14.	Boom Does Not Raise Or Raises Slowly	2-590
15.	Boom Does Not Lower Or Lowers Slowly	2-604
16.	Boom Does Not Operate Or Operates Slowly	2-614
17.	Boom Creeps Down	2-628
18.	Hoist Does Not Operate Or Operates Slowly	2-640
19.	Hoist Does Not Lower	2-650
20.	Hoist Does Not Raise	2-660

Table 2-4. Troubleshooting Fault Index (CONT).

Fault Number	Troubleshooting Procedure	Page Number
CRANE SYSTEM FAULT INDEX (CONT).		
21.	Crane Fails Load Test	2-674
22.	Overload Shutdown System (OSS) Disables Crane Functions, Boom Up, Boom Down, Telescope Out And Hoist Up	2-708
WINCH SYSTEM FAULT INDEX		
1.	Self-Recovery Winch (SRW) Does Not Operate	2-728
STEERING SYSTEM FAULT INDEX		
1.	Truck Is Hard To Steer	2-746
ARCTIC HEATER (MODEL B) FAULT INDEX		
1.	Fault Chart For Diagnostic of Arctic Heater Troubleshooting (Model B)	2-766.4
2.	Fault Code 001, 002, 010 or 011: Advance Warning-Overvoltage Shutdown, Advance Warning-Undervoltage Shutdown, Overvoltage Shutdown or Undervoltage Shutdown	2-766.10
3.	Fault Code 012, 013, 014 or 015: Overheating, Excessive Temperature at Flame Sensor, Possible Overheating Detected or Too Many Overheats	2-766.12
4.	Fault Code 020 or 021: Glow Pin Open Circuit or Glow Pin Short Circuit	2-766.14
5.	Fault Code 033: Blower Motor Speed Fault	2-766.34
6.	Fault Code 037, 042 or 059: Water Pump Not Working, Water Pump Short Circuit or Water Temperature Rises to Quickly	2-766.42
7.	Fault Code 043, 047 or 048: Short Circuit at External Component, Fuel Metering Pump Short Circuit or Fuel Pump Open Circuit	2-766.46
8.	Fault Code 050 or 052: Too Many No Start Attempts or No Start Safety Time Exceeded	2-766.48
9.	Fault Code 051: Faulty Flame Recognition	2-766.64
10.	Fault Code 053, 054, 55 or 056: Flame Cutout in Boost Mode, Flame Cutout in High Mode, Flame Cutout in Medium Mode or Flame Cutout in Low Mode	2-766.68
11.	Fault Code 060, 061, 071 or 072: Temperature Sensor Open Circuit, Temperature Sensor Short Circuit, Overheat Sensor Open Circuit or Overheat Sensor Short Circuit	2-766.72
12.	Fault Code 064 or 065: Flame Sensor Open Circuit or Flame Sensor Short Circuit	2-766.78
13.	Fault Code 090, 093, 094 or 097: Control Unit Defective (Internal Fault, RAM Error, EPROM Fault or Power Fault)	2-766.82

2-10. ENGINE TROUBLESHOOTING.

This paragraph covers Engine System Troubleshooting. The Engine System Fault Index, Table 2-5, lists faults for the engine system of the PLS truck.

Table 2-5. Engine System Fault Index

Fault No.	Description	Page
1.	Engine Does Not Develop Full Power	2-44
2.	Engine Overheats (Water Temperature Gage Continuously Reads Over 230°F [110°C])	2-64
3.	Low Engine Oil Pressure; (Less Than 5 psi [34 kPa] At Idle, Less Than 40 psi [276 kPa] During Normal Operation)	2-70
4.	Excessive Black Or Gray Exhaust Smoke (Engine At Normal Operating Temperature)	2-80
5.	Excessive Oil Consumption Or Blue Exhaust Smoke (Engine At Normal Operating Temperature)	2-92
6.	White Exhaust Smoke (Engine At Normal Operating Temperature)	2-104

2-10. ENGINE TROUBLESHOOTING (CONT).

1. ENGINE DOES NOT DEVELOP FULL POWER.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Analyzer Set, STE/ICE-R (Item 15, Appendix F)
 Cartridge, DDEC (Item 29, Appendix F)
 Connector Remover (Item 42, Appendix F)
 Reader, Diagnostic (Item 180, Appendix F)

Materials/Parts


Solution, Soap (Item 67, Appendix B)
 Gasket (2) (Item 115, Appendix E)
 Gasket (4) (Item 116, Appendix E)
 Lockwasher (30) (Item 282, Appendix E)

References

TM 9-2320-364-10
 TM 9-2320-364-20
 TM 9-4910-571-12&P





Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)



WARNING

Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.




VISUAL INSPECTION

- (1) Remove right side noise panel, (TM 9-2320-364-20).
- (2) Remove eight screws, lockwashers, washers and left side noise panel. Discard lockwashers.
- (3) Start engine, (TM 9-2320-364-10).
- (4) Check exhaust manifold, gasket and clamps for leaks and damage.
 - (a) If clamps are loose, tighten clamps. If exhaust manifold or gaskets are leaking or damaged replace exhaust manifold and/or gaskets, (Para 3-31).
 - (b) If exhaust manifold or gaskets are not leaking or damaged, perform Step (5) below and go to Step 2 of this Fault.
- (5) Turn OFF ENGINE switch.

SHOWN REMOVED FOR CLARITY

1. ENGINE DOES NOT DEVELOP FULL POWER (CONT).




WARNING



Do not stand in front of vehicle when testing air box pressure. Brakes could fail and vehicle could move forward causing injury or death.

CAUTION


Do not operate vehicle with transmission engaged and engine at maximum RPM for more than 15 seconds at a time. Transmission oil heats up quickly and could cause damage to transmission.



- STE/ICE-R #30**
- (1) Remove dust cover from DCA connector MC39.
 - (2) Connect DCA cable W1 to the vehicle test meter (VTM) and DCA connector MC39.
 - (3) Power up STE/ICE-R VTM in the DCA mode, (TM 9-4910-571-12&P).
 - (4) Set test select switch to #30.
 - (5) Start engine and allow engine to run for 5 minutes, (TM 9-2320-364-10).
 - (6) Perform Offset test, (TM 9-4910-571-12&P).
 - (7) Apply brake pedal and move transmission range selector to drive (D) position.
 - (8) Press and hold throttle pedal to floor.
 - (9) Press and release test button to obtain test results.
 - (a) If turbocharger outlet pressure is not 9.3 psi (64 kPa), perform Steps (10) through (14) below and go to Step 3 of this Fault.
 - (b) If turbocharger outlet pressure is 9.3 psi (64 kPa), perform Steps (10) through (14) below and go to Step 5 of this Fault.
 - (10) Return engine rpm to approximately 600 rpm.
 - (11) Move transmission range selector to neutral (N) position.
 - (12) Turn OFF ENGINE switch.
 - (13) Disconnect DCA cable W1.
 - (14) Install dust cover on DCA connector MC39.



1. ENGINE DOES NOT DEVELOP FULL POWER (CONT).




WARNING

Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.

TURBOCHARGER INSPECTION


- (1) Open engine access cover, (TM 9-2320-364-10).
- (2) Loosen clamp and remove air intake duct from turbocharger.
- (3) Loosen clamp and remove exhaust pipe from turbocharger.
- (4) Check mountings, air intake and outlet ducting gasket, clamps and connection for damage.
 - (a) If mountings, intake or exhaust ducting gasket and connection are damaged, replace damaged components, (Para 4-8) and perform Step (6) below.
 - (b) If mountings, intake and exhaust ducting and connection are OK, go to Step 5 below.
- (5) Check impeller and turbine blades for free movement and damage.
 - (a) If impeller or turbine blades do not move freely or if there are signs of internal oil leaks, replace turbocharger, (Para 4-8).
 - (b) If impeller and turbine blades move freely and there are no signs of oil leaks, perform Step (6) below and go to Step 4 of this Fault.
- (6) Install air intake duct and clamp.
- (7) Install exhaust pipe and clamp.




ENGINE ACCESS COVER



TURBINE BLADES/IMPELLER



1. ENGINE DOES NOT DEVELOP FULL POWER (CONT).



WARNING

Allow engine to cool before performing troubleshooting maintenance. If necessary, use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.


VISUAL INSPECTION
<ol style="list-style-type: none"> (1) Start engine, (TM 9-2320-364-10). (2) Use soap solution and check for leaks from blower gaskets. (3) Turn engine OFF. (4) Close engine access cover.

ENGINE ACCESS COVER




BLOWER

GASKET



1. ENGINE DOES NOT DEVELOP FULL POWER (CONT).






WARNING


Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.

VISUAL INSPECTION

- (1) Remove 22 screws, lockwashers, washers, and cab engine access panel. Discard lockwashers.
- (2) Turn ON ENGINE switch, (TM 9-2320-364-10).
- (3) Check secondary fuel filter and/or cover for leaks or damage.
 - (a) If secondary fuel filter and/or cover is leaking or damaged, perform Steps (4) and (5) below and replace secondary fuel filter and/or cover, (TM 9-2320-364-20).
 - (b) If secondary fuel filter and/or cover is not leaking or damaged, fuel filter and/or cover are OK.
- (4) Turn OFF ENGINE switch.
- (5) Install cab engine access panel with 22 lockwashers, washers, and screws.




1. ENGINE DOES NOT DEVELOP FULL POWER (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.


- INJECTOR RESPONSE TIME TEST**
- (1) Connect DDR to DDL connector MC13.
 - (2) Start engine, (TM 9-2320-364-10).
 - (3) Select mode 10 to display fuel injector response times on DDR.
 - (4) Compare response times of all eight injectors.
 - (a) If any injector response time is less than others or .80 milliseconds, perform Step (5) below and replace injector, (Para 4-2).
 - (b) If injector response times are same as others or greater than .80 milliseconds, response times are OK.
 - (5) Turn OFF ENGINE switch.



- DDR CYLINDER CUT OUT TEST**
- (1) Start engine, (TM 9-2320-364-10).
 - (2) Select mode 11 to display pulse widths on DDR.
 - (3) Compare pulse widths of all eight injectors.
 - (a) If pulse widths are less than the NO CUT OUT PW (pulse widths), or different from cylinder to cylinder, perform Steps (4) and (5) below and replace injector, (Para 4-2).
 - (b) If pulse widths are equal to or greater than the NO CUT OUT PW (pulse widths), perform Step (4) and (5) below and go to Step 8 of this Fault.
 - (4) Turn OFF ENGINE switch.
 - (5) Disconnect DDR from DDL connector MC13.



1. ENGINE DOES NOT DEVELOP FULL POWER (CONT).



WARNING

Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.


**VALVE CLEARANCE, ENGINE BRAKE,
INJECTOR TIMING AND INJECTOR
CALIBRATION (DDEC III/IV ONLY)
CHECK**

Check exhaust valve clearance, engine brake retarder adjustment, and injector timing, and injector calibration (DDEC III/IV only) (Para 3-2).


- (1) If engine exhaust valve clearance, engine brake retarder adjustment, injector timing and injector calibration (DDEC III/IV only) are not within specifications, perform engine tune-up, (Para 3-2 and Para 4-2).
- (2) If engine exhaust valve clearance, engine brake retarder adjustment, injector timing and injector calibration (DDEC III/IV only) are within specifications, go to Step 9 of this Fault.

CYLINDER LINER PORTS INSPECTION

- (1) Remove 14 screws, six engine air box covers and gaskets. Discard gaskets.
- (2) Check for clogged cylinder liner air inlet ports.
- (3) (a) If cylinder liner air inlet ports are clogged, perform Step (4) below and replace engine, (Para 3-4).
(b) If cylinder liner air inlet ports are not clogged, perform Step (4) below and go to Step 10 of this Fault.
- (4) Install six gaskets and engine air box covers with 14 screws.



1. ENGINE DOES NOT DEVELOP FULL POWER (CONT).



CAUTION


- Do not run more than two compression unbalance tests in a row.
- A fail message means compression is too far unbalanced to measure with STE/ICE-R.

STE/ICE-R #14




- (1) Remove dust cover from DCA connector MC39.
- (2) Connect DCA cable W1 to the vehicle test meter (VTM) and DCA connector.
- (3) Power up STE/ICE-R VTM in the DCA mode, (TM 9-4910-571-12&P).
- (4) Perform confidence Test.
- (5) Enter vehicle identification number (VIN) (38).
- (6) Perform STE/ICE-R #72 test.
- (7) Perform STE/ICE-R #73 test.
- (8) Perform STE/ICE-R #74 test.
- (9) Perform STE/ICE-R #75 test.
- (10) Set test select switch to #14.
- (11) Press and release test button.
- (12) Wait for a GO to appear on VTM display. If "UEH" appears, refer to TM 9-4910-571-12&P, test #14, and enter following information:

AI	ENTER
CYL -	04
CV1 -	3
CV2 -	98
CV3 -	43
CV4 -	4
CV5 -	53

- (13) Push down and hold engine stop switch and crank engine until OFF appears on VTM display. If a GO appears, repeat Steps (10) through (13) above.
- (14) Stop cranking engine and release engine stop switch, observe number displayed on VTM display. Number displayed is the percent unbalance between the highest and lowest cylinders. If "UEH" appeared, valves for Step "A" will be "1.00 min to 1.20 max". Valve for Step "B" will be "above 1.20".
 - (a) If the percentage of unbalance is between 0 and 11 percent, perform Steps (15) and (16) below and replace engine, (Para 3-4).
 - (b) If the percentage of unbalance cylinder is above 11 percent, perform Steps (15) and (16) below and go to Step 11 of this Fault.
- (15) Disconnect DCA cable W1 from DCA connector MC39.
- (16) Install dust cover on DCA connector MC39.




DOOR SHOWN REMOVED FOR CLARITY



STEERING WHEEL SHOWN REMOVED FOR CLARITY

1. ENGINE DOES NOT DEVELOP FULL POWER (CONT).



WARNING

Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.

COMPRESSION TEST
<ol style="list-style-type: none"> (1) Start engine, (TM 9-2320-364-10). (2) Remove radiator cap and check for exhaust gas bubbles in coolant. <ol style="list-style-type: none"> (a) If bubbles are present in coolant, turn OFF ENGINE switch and go to Step (3) below. (b) If there are no bubbles, turn OFF ENGINE switch and go to Step (6) below. (3) Perform compression test on each cylinder, (Para 3-3). <ol style="list-style-type: none"> (a) If pressure is below minimum requirements listed in Table 2-6, go to Step (4) below. (b) If pressure is above minimum requirements listed in Table 2-6, fault not corrected. Notify supervisor. (4) Remove cylinder head, (Para 3-7). (5) Check cylinder head for cracks, leaking valve seats or injector tubes. <ol style="list-style-type: none"> (a) If any of the components listed above are damaged, replace the cylinder head, (Para 3-7). (b) If all of the components listed above are OK, go to Step (6) below. (6) Remove 14 screws and six air box covers and gaskets. Discard gaskets. (7) Check pistons and piston rings for damage. Rings should spring in and out when pushed in. <ol style="list-style-type: none"> (a) If pistons and/or piston rings are damaged, replace engine, (Para 3-4). (b) If pistons and piston rings are not damaged, pistons and piston rings are OK, fault not corrected. Notify supervisor. (8) Install cylinder head.





Table 2-6. Compression Pressure Specifications


Minimum Compression Pressure at 600 RPM		Altitude above Sea Level	
psi	kPa	feet	meters
450	3101	500	152
415	2859	2,500	762
385	2653	5,000	1,524
355	2446	7,500	2,286
330	2274	10,000	3,048

1. ENGINE DOES NOT DEVELOP FULL POWER (CONT).



VERIFY REPAIR

- (1) Operate truck, (TM 9-2320-364-10) at 2100 rpm in each gear.
 - (a) If normal operating speeds cannot be sustained at 2100 rpm, fault not corrected. Perform Steps (2) and (3) below and notify supervisor.
 - (b) If normal operating speeds can be sustained, fault has been corrected.
- (2) Install right side noise panel, (TM 9-2320-364-20).
- (3) Install left side noise panel, eight washers, lockwashers and screws.



2-10. ENGINE TROUBLESHOOTING (CONT).

2. ENGINE OVERHEATS (WATER TEMPERATURE GAGE CONTINUOUSLY READS OVER 230°F [110°C]).

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
(Item 240, Appendix F)
Tester, Pressure, Radiator (Item 237, Appendix F)

References


TM 9-2320-364-10
TM 9-2320-364-20

Materials/Parts

Lockwasher (30) (Item 282, Appendix E)


Equipment Condition

Engine OFF, (TM 9-2320-364-10)
Parking brake applied, (TM 9-2320-364-10)
Wheels chocked, (TM 9-2320-364-10)



WARNING


- Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.
- Do not remove the radiator cap when the engine is hot; steam and hot coolant can escape and burn personnel.
- Use a clean, thick waste cloth or like material to remove the cap. Avoid using gloves. If hot water soaks through gloves, personnel could be burned.



COOLING SYSTEM PRESSURE TEST

- (1) Remove right side noise panel, (TM 9-2320-364-20).
- (2) Remove eight screws, lockwashers, washers and left side noise panel. Discard lockwashers.
- (3) Remove radiator cap, (TM 9-2320-364-10).
- (4) Install cooling system pressure tester.
- (5) Pressurize cooling system to 10 psi (69 kPa) and check expansion plugs for leaks.
 - (a) If expansion plugs are leaking, replace expansion plugs, (Para 3-8).
 - (b) If expansion plugs are not leaking, expansion plugs are OK.
- (6) Release pressure and remove cooling system pressure tester.
- (7) Install radiator cap.

2. ENGINE OVERHEATS (CONT).






WARNING


- Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.
- Moving engine components can cause severe injury. Keep away from alternator belts and pulleys while engine is running.

WATER PUMP INSPECTION

- (1) Remove 22 screws, lockwashers, washers and cab engine access panel. Discard lockwashers.
- (2) Start engine, (TM 9-2320-364-10).
- (3) Check water pump for leaks or unusual noise during operation.
 - (a) If water pump leaks or is unusually noisy, turn OFF ENGINE switch and replace water pump, (Para 5-6).
 - (b) If water pump does not leak or is not unusually noisy during operation, perform Steps (4) and (5) below and go to Step 3 of this Fault.
- (4) Turn OFF ENGINE switch.
- (5) Install cab engine access panel, 22 washers, lockwashers and screws.



2. ENGINE OVERHEATS (CONT).




WARNING

- Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.
- Do not remove the radiator cap when the engine is hot; steam and hot coolant can escape and burn personnel.
- Use a clean, thick waste cloth or like material to remove the cap. Avoid using gloves. If hot water soaks through gloves, personnel could be burned.


CYLINDER HEAD INSPECTION

- (1) Start engine, (TM 9-2320-364-10).
- (2) Remove radiator cap and check for bubbles.
 - (a) If bubbles are seen, perform Steps (3) and (4) below and replace cylinder head gaskets or cylinder head(s), (Para 3-7).
 - (b) If bubbles are not seen, perform Steps (3) and (4) below and go to Step 4 of this Fault.
- (3) Turn OFF ENGINE switch.
- (4) Install radiator cap.



VERIFY REPAIR

- (1) Start engine, (TM 9-2320-364-10) and allow it to run until engine temperature stabilizes.
 - (a) If water temperature gage continuously reads over 230°F (110°C), fault not corrected. Perform Steps (2) through (4) below and notify supervisor.
 - (b) If water temperature gage continuously reads under 230°F (110°C), fault has been corrected.
- (2) Turn OFF ENGINE switch.
- (3) Install left side noise panel with eight washers, lockwashers and screws.
- (4) Install right side noise panel, (TM 9-2320-364-20).



2-10. ENGINE TROUBLESHOOTING (CONT).

3. LOW ENGINE OIL PRESSURE (LESS THAN 5 PSI [34 KPA] AT IDLE, LESS THAN 40 PSI [276 KPA] DURING NORMAL OPERATION).

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
(Item 240, Appendix F)

References


TM 9-2320-364-10

Materials/Parts

Solvent, Drycleaning, (Item 68, Appendix B)
Screw, Self-locking, (Item 554, Appendix E)
Strainer, Element, (Item 675, Appendix E)

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
Parking brake applied, (TM 9-2320-364-10)
Wheels chocked, (TM 9-2320-364-10)




WARNING


Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.

**OIL PICKUP TUBE AND ELEMENT
STRAINER INSPECTION**

- (1) Remove engine oil pan (Para 3-22).
- (2) Check pickup tube and mounting hardware for looseness and damage.
 - (a) If pickup tube is loose, tighten connection (Para 3-26).
 - (b) If pickup tube is damaged, replace tube (Para 3-26).
 - (c) If pickup tube is not damaged, go to Step 3 below.
- (3) Remove two self-locking screws, washers and oil pickup screen strainer. Discard self-locking screws.
- (4) Check oil pickup tube screen strainer for restrictions.
 - (a) If oil pickup tube screen strainer is restricted, replace element strainer, perform Step (5) and (6) below and go to Step 6 of this Fault.
 - (b) If oil pickup tube screen strainer is not restricted, perform Step (5) below and go to Step 2 of this Fault.
- (5) Install oil pickup tube screen strainer, two washers and self-locking screws.
- (6) Install engine oil pan.



3. LOW ENGINE OIL PRESSURE (CONT).




WARNING

- Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.
- Drycleaning Solvent (P-D-680) is TOXIC and flammable. Wear protective goggles, face shield, and gloves; use only in a well-ventilated area; avoid contact with skin, eyes, and clothes, and do not breathe vapors. Keep away from heat or flame. Never smoke when using solvent. The flashpoint for Type II Drycleaning Solvent is 140 degrees F (60 degrees C) and Type III Drycleaning Solvent is 200 degrees F (93 degrees C). Failure to do so may result in injury or death to personnel.

OIL PRESSURE REGULATOR VALVE INSPECTION

- (1) Remove oil pressure regulator valve (Para 3-27).
- (2) Clean oil pressure regulator valve with drycleaning solvent.
- (3) Check valve inside oil pressure regulator valve for sludge, scoring, and not opening.
 - (a) If valve has sludge on it, clean valve again with drycleaning solvent.
 - (b) If valve is scored or not opening completely, replace oil pressure regulator valve (Para 3-27).
 - (c) If valve is not scored and opens completely, go to Step 3 of this Fault.



3. LOW ENGINE OIL PRESSURE (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. Oil pickup tube and pickup tube intake screen OK. Oil pressure regulator valve OK.
POSSIBLE PROBLEMS
Oil pressure relief valve faulty. Oil pump faulty. Oil cooler adapter plugged.


3.

WARNING

Read **WARNING** on Page 2-75

Is oil pressure relief valve inside plunger sticking open?

TEST OPTIONS
Oil pressure relief valve inspection.
REASON FOR QUESTION
If pressure relief valve sticks open, oil pressure can be low. ←




KNOWN INFO
Unit Troubleshooting tasks completed. Oil pickup tube and pickup tube intake screen OK. Oil pressure regulator valve OK. Oil pressure relief valve OK.
POSSIBLE PROBLEMS
Oil pump faulty. Oil cooler adapter plugged.

4.

Is oil pump free of damage?

TEST OPTIONS
Visual inspection.
REASON FOR QUESTION
If oil pump gears are worn or damaged, they will not pump enough oil to maintain correct operating pressure. ←




WARNING

- Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.
- Drycleaning Solvent (P-D-680) is TOXIC and flammable. Wear protective goggles, face shield, and gloves; use only in a well-ventilated area; avoid contact with skin, eyes, and clothes, and do not breathe vapors. Keep away from heat or flame. Never smoke when using solvent. The flashpoint for Type II Drycleaning Solvent is 140 degrees F (60 degrees C) and Type III Drycleaning Solvent is 200 degrees F (93 degrees C). Failure to do so may result in injury or death to personnel.


OIL PRESSURE RELIEF VALVE INSPECTION

- (1) Remove oil pressure relief valve (Para 3-28).
- (2) Clean oil pressure relief valve with drycleaning solvent.
- (3) Check valve inside oil pressure relief valve for sludge, scoring, and not closing.
 - (a) If valve has sludge on it, clean valve with drycleaning solvent.
 - (b) If valve is scored or not closing completely, replace oil pressure relief valve (Para 3-28).
 - (c) If valve is not scored and closes completely, go to Step 5 of this Fault.




VISUAL INSPECTION

- (1) Remove engine oil pump (Para 3-26).
- (2) Clean engine oil pump with drycleaning solvent.
- (3) Check engine oil pump for sludge, broken gear teeth, or other damage. Make sure pump turns freely.
 - (a) If oil pump is damaged, replace oil pump.
 - (b) If oil pump is not damaged, oil pump is OK.
- (4) Install engine oil pump (Para 3-26).
- (5) Install oil pressure relief valve (Para 3-28).
- (6) Install oil pressure regulator valve (Para 3-27).
- (7) Install engine oil pan (Para 3-22).



3. LOW ENGINE OIL PRESSURE (CONT).




WARNING


- Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.
- Drycleaning Solvent (P-D-680) is TOXIC and flammable. Wear protective goggles, face shield, and gloves; use only in a well-ventilated area; avoid contact with skin, eyes, and clothes, and do not breathe vapors. Keep away from heat or flame. Never smoke when using solvent. The flashpoint for Type II Drycleaning Solvent is 140 degrees F (60 degrees C) and Type III Drycleaning Solvent is 200 degrees F (93 degrees C). Failure to do so may result in injury or death to personnel.
- Use care when removing springs. Springs are under tension and can act as projectiles when released and could cause severe eye injury.

OIL COOLER ADAPTER INSPECTION

- (1) Remove engine oil cooler adapter (Para 3-30).
- (2) Remove plug, washer, spring and valve from oil cooler adapter.
 - (a) If valve and spring are clogged with sludge or damaged, clean or replace valve and/or spring (Para 3-30). Perform Steps (4) and (5) below and go to Step 6 of this Fault.
 - (b) If valve and spring are clean and free of damage, go to Step 3 below.
- (3) Check inside ports of oil cooler adapter.
 - (a) If oil cooler adapter is clogged with oil sludge, clean core with dry cleaning solvent. Perform Steps (4) and (5) below and go to Step 6 of this Fault.
 - (b) If cooler adapter is clean and free of sludge, fault not corrected. Perform Steps (4) and (5) below and notify supervisor.
- (4) Install valve, spring, washer and plug.
- (5) Install oil cooler adapter.




3. LOW ENGINE OIL PRESSURE (CONT).



VERIFY REPAIR

- (1) Start engine (TM 9-2320-364-10) and run until oil pressure stabilizes.
 - (a) If oil pressure is not between 5 to 10 psi (34 to 69 kPa) at idle and 40 to 60 psi (276 to 414 kPa) when oil pressure has stabilized, fault not corrected. Turn OFF ENGINE switch and notify supervisor.
 - (b) If oil pressure is within normal range, fault has been corrected.
- (2) Turn OFF ENGINE switch.



2-10. ENGINE TROUBLESHOOTING (CONT).

4. EXCESSIVE BLACK OR GRAY EXHAUST SMOKE (ENGINE AT NORMAL OPERATING TEMPERATURE).

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Analyzer Set, STE/ICE-R (Item 15, Appendix F)
- Cartridge, DDEC (Item 29, Appendix F)
- Reader, Diagnostic (Item 180, Appendix F)

Materials/Parts


- Gasket (2) (Item 115, Appendix E)
- Gasket (4) (Item 116, Appendix E)
- Lockwasher (8) (Item 282, Appendix E)

References

- TM 9-2320-364-10
- TM 9-2320-364-20
- TM 9-4910-571-12&P



Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)



WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.



DDEC MODE 10 TEST

- (1) Connect DDR to DDL connector MC13.
- (2) Start engine (TM 9-2320-364-10).
- (3) Select mode 10 to display fuel injector response times on DDR.
- (4) Compare response times of all eight injectors.
 - (a) If any injector response time is less than others or less than .80 milliseconds, perform Steps (5) and (6) below and replace injector (Para 4-2).
 - (b) If injector response times are same as others or greater than .80 milliseconds, response times are OK.
- (5) Turn OFF ENGINE switch.
- (6) Disconnect DDR from DDL connector MC13.

4. EXCESSIVE BLACK OR GRAY EXHAUST SMOKE (CONT).


KNOWN INFO
Unit Troubleshooting tasks completed. Injector response times OK.
POSSIBLE PROBLEMS
Injector pulse widths incorrect. Injector timing faulty. Blower bypass valve faulty. Clogged cylinder air inlet ports. Low air box pressure.

2.

WARNING
Read **WARNING**
on Page 2-83

Are all of the injector pulse widths equal to or greater than the NO CUT OUT PW (pulse widths)?

TEST OPTIONS
DDEC mode 11 test.
REASON FOR QUESTION
Pulse widths less than the base pulse width or different than other injector pulse widths indicate that injector is faulty. A misadjusted injector will cause black or gray exhaust smoke.




KNOWN INFO
Unit Troubleshooting tasks completed. Injector response times OK. Injector pulse widths OK.
POSSIBLE PROBLEMS
Injector timing faulty. Blower bypass valve faulty. Clogged cylinder air inlet ports. Low air box pressure.

3.

Is injector timing within specification?

TEST OPTIONS
Injector timing check.
REASON FOR QUESTION
Improperly timed injectors will cause fuel to burn unevenly and may cause black or gray exhaust smoke.




WARNING

- Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.
- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

DDEC MODE 11 TEST

- (1) Connect DDR to DDL connector MC13.
- (2) Start engine (TM 9-2320-364-10).
- (3) Select mode 11 to display pulse widths on DDR.
- (4) Compare pulse widths of all eight injectors.
 - (a) If pulse widths are less than the NO CUT OUT PW (pulse widths), or different from cylinder to cylinder, perform Steps (5) and (6) below and replace injector (Para 4-2).
 - (b) If pulse widths are equal to or greater than the NO CUT OUT PW (pulse widths), perform Steps (5) and (6) below and go to Step 3 of this Fault.
- (5) Turn OFF ENGINE switch.
- (6) Disconnect DDR from DDL connector MC13.


STEERING WHEEL REMOVED FOR CLARITY



INJECTOR TIMING CHECK

- Check injector timing.
- (1) If injectors are out of time, time injectors (Para 3-2).
 - (2) If injectors are in time, go to Step 4 of this Fault.

4. EXCESSIVE BLACK OR GRAY EXHAUST SMOKE (CONT).





WARNING


Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.

VISUAL INSPECTION

- (1) Remove blower bypass valve (Para 4-7).
- (2) Push blower bypass valve piston open by hand. Spring pressure should fully close valve.
 - (a) If blower bypass valve piston cannot be opened with hand pressure or will not fully seat with spring pressure, replace blower bypass valve (Para 4-7).
 - (b) If blower bypass valve piston can be opened with hand pressure and fully closed with spring pressure, blower bypass valve is OK.
- (3) Install blower bypass valve (Para 4-7).

**BLOWER BYPASS VALVE**

4. EXCESSIVE BLACK OR GRAY EXHAUST SMOKE (CONT).






WARNING


Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.

CYLINDER LINER PORTS INSPECTION

- (1) Remove eight screws, lockwashers, washers and left side noise panel. Discard lockwashers.
- (2) Remove 14 screws, six engine air box covers and gaskets. Discard gaskets
- (3) Check for clogged cylinder liner air inlet ports.
- (4) (a) If cylinder liner air inlet ports are clogged, replace engine (Para 3-4).
- (b) If cylinder liner air inlet ports are not clogged, perform Step (5) below and go to Step 6 of this Fault.
- (5) Install six gaskets and engine air box covers with 14 screws.



4. EXCESSIVE BLACK OR GRAY EXHAUST SMOKE (CONT).



WARNING

Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.

- | STE/ICE-R #32 |
|--|
| <ol style="list-style-type: none"> (1) Remove dust cover from DCA connector MC39. (2) Connect STE/ICE-R DCA W1 to the vehicle test meter (VTM) and DCA connector. (3) Power up STE/ICE-R VTM in the DCA mode. (4) Perform confidence test. (5) Enter vehicle identification number. (6) Perform STE/ICE-R #72 test. (7) Perform STE/ICE-R #73 test. (8) Perform STE/ICE-R #74 test. (9) Perform STE/ICE-R #75 test. (10) Set STE/ICE-R test select switch to 32. (11) Press and hold STE/ICE-R test button until CAL appears on display. (12) Release STE/ICE-R test button and wait for offset value to appear on display. (13) Start engine (TM 9-2320-364-10). (14) Press and release STE/ICE-R test button to obtain test results. <ol style="list-style-type: none"> (a) If reading is greater than those shown in Table 2-7 (Engine Air Box Pressures), perform Steps (15) through (17) and replace engine (Para 3-4). (b) If reading is less than those shown in Table 2-7 (Engine Air Box Pressures), perform Steps (15) through (17) below and replace blower (Para 4-4). (15) Turn OFF ENGINE switch. (16) Disconnect DCA cable W1 from DCA connector MC39. (17) Install dust cover on DCA connector MC39. |





Table 2-7. Engine Air Box Pressures

Air Box Pressure Full Load Minimum*	1800 rpm in. Hg (mm Hg)	1950 rpm in. Hg (mm Hg)	2100 rpm in. Hg (mm Hg)
At zero exhaust back pressure	48 (1216)	52.2 (1322)	54.8 (1388)
At maximum exhaust back pressure	41.9 (1061)	46.1 (1168)	48.7 (1233)


* 500 BHP 5234775 DDEC 1.520 timing

4. EXCESSIVE BLACK OR GRAY EXHAUST SMOKE (CONT).



VERIFY REPAIR

- (1) Start engine (TM 9-2320-364-10).
 - (a) If exhaust smoke is excessive and black or gray in color, fault not corrected. Perform Steps (2) through (4) below and notify supervisor.
 - (b) If exhaust smoke is normal in quantity and color, fault has been corrected.
- (2) Turn OFF ENGINE switch.
- (3) Install left side noise panel with eight washers, lockwashers and screws.
- (4) Install right side noise panel (TM 9-2320-364-20).



2-10. ENGINE TROUBLESHOOTING (CONT).

5. EXCESSIVE OIL CONSUMPTION OR BLUE EXHAUST SMOKE (ENGINE AT NORMAL OPERATING TEMPERATURE).

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Reader, Diagnostic (Item 180, Appendix F)

Materials/Parts


- Gasket (2) (Item 115, Appendix E)
- Gasket (4) (Item 116, Appendix E)
- Lockwasher (30) (Item 282, Appendix E)

References

- TM 9-2320-364-10
- TM 9-2320-364-20



Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.



VISUAL INSPECTION

- (1) Remove 22 screws, lockwashers, washers and cab engine access panel. Discard lockwashers.
- (2) Check crankshaft front cover and front oil seal for leaks or damage.
 - (a) If crankshaft front cover or front oil seal, are leaking or damaged, replace crankshaft front cover or front oil seal (Para 3-12).
 - (b) If crankshaft front cover and front oil seal are not leaking or damaged, go to Step 2 of this Fault.



5. EXCESSIVE OIL CONSUMPTION OR BLUE EXHAUST SMOKE (CONT).


KNOWN INFO
Unit Troubleshooting tasks completed. Crankshaft front cover and oil seal OK.
POSSIBLE PROBLEMS
Oil cooler leaking oil into coolant. Rear crankshaft oil seal leaks. Turbocharger oil seal faulty. Blower leaking oil. Cylinder head damaged/leaking. Piston rings faulty.

2.

WARNING
 Read **WARNING** on Page 2-95

Is engine coolant clean (free from engine lubricating oil)?

TEST OPTIONS
Visual inspection.
REASON FOR QUESTION
Engine oil in coolant indicates oil is leaking from oil cooler into coolant. Engine oil consumption will be high and blue exhaust smoke may be produced.




KNOWN INFO
Unit Troubleshooting tasks completed. Crankshaft front cover and oil seal OK. Oil cooler OK.
POSSIBLE PROBLEMS
Rear crankshaft oil seal leaks. Turbocharger oil seal faulty. Blower leaking oil. Cylinder head damaged/leaking. Piston rings faulty.

3.

Is rear crankshaft oil seal free from leaks?

TEST OPTIONS
Visual inspection.
REASON FOR QUESTION
If rear crankshaft oil seal leaks, engine oil consumption will be high.




WARNING

- Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.
- Do not remove the radiator cap when the engine is hot; steam and hot coolant can escape and burn personnel.
- Use a clean, thick waste cloth or like material to remove the cap. Avoid using gloves. If hot water soaks through gloves, personnel could be burned.


VISUAL INSPECTION

- (1) Remove radiator cap (TM 9-2320-364-10).
- (2) Check coolant for engine lubricating oil.
 - (a) If engine lubricating oil is present in coolant, replace oil cooler (Para 3-29).
 - (b) If no engine lubricating oil is present in coolant, perform Step (3) below and go to Step 3 of this Fault.
- (3) Install radiator cap.



VISUAL INSPECTION

- (1) Remove pipe plug from bottom of flywheel housing.
- (2) Check for oil in housing.
 - (a) If oil is present in flywheel housing, go to Step (3) below.
 - (b) If no oil is present in flywheel housing, go to Step (6) below.
- (3) Remove engine and transmission (Para 3-4).
- (4) Check rear oil seal for oil leaks.
 - (a) If rear oil seal leaks, replace oil seal (Para 3-14).
 - (b) If rear oil seal does not leak, perform Steps (5) and (6) below and go to Step 4 of this Fault.
- (5) Install engine and transmission (Para 3-4).
- (6) Install pipe plug in flywheel housing.



5. EXCESSIVE OIL CONSUMPTION OR BLUE EXHAUST SMOKE (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. Crankshaft front cover and oil seal OK. Oil cooler OK. Rear crankshaft oil seal OK.
POSSIBLE PROBLEMS
Turbocharger oil seal faulty. Blower leaking oil. Cylinder head damaged/leaking. Piston rings faulty.


4.

WARNING

Read **WARNING** on Page 2-97

Is turbocharger free from internal and external oil leaks?

TEST OPTIONS
Visual inspection.
REASON FOR QUESTION
If turbocharger or oil seal is leaking oil, oil consumption will be high.




KNOWN INFO
Unit Troubleshooting tasks completed. Crankshaft front cover and oil seal OK. Oil cooler OK. Rear crankshaft oil seal OK. Turbocharger oil seal OK.
POSSIBLE PROBLEMS
Blower leaking oil. Cylinder head damaged/leaking. Piston rings faulty.

5.

Are blower rotors free from oil?

TEST OPTIONS
Visual inspection.
REASON FOR QUESTION
If blower is damaged or worn and leaking oil, oil consumption will be high and blue exhaust smoke may be produced.




WARNING

Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.

VISUAL INSPECTION


- (1) Remove right side noise panel (TM 9-2320-364-20).
- (2) Loosen clamps and remove air outlet duct from turbocharger.
- (2) Loosen clamp and remove exhaust duct from turbocharger.
- (3) Check impeller and turbine blades for oil leaks.
 - (a) If there is oil present inside the turbocharger, replace turbocharger (Para 4-8).
 - (b) If the inside of the turbocharger is free of oil, go to Step 5 of this Fault.



ENGINE ACCESS COVER




TURBINE BLADES/IMPELLER




VISUAL INSPECTION

- (1) Remove air inlet housing (Para 4-3).
- (2) Check blower rotors for signs of oil.
 - (a) If signs of oil are found, replace blower (Para 4-4).
 - (b) If no signs of oil are found, perform Step (3) below and go to Step 6 of this Fault.
- (3) Install air inlet housing (Para 4-3).

BLOWER ROTORS



5. EXCESSIVE OIL CONSUMPTION OR BLUE EXHAUST SMOKE (CONT).




WARNING


Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.

VISUAL INSPECTION

- (1) Remove exhaust manifolds (Para 3-31).
- (2) Check inside of exhaust manifolds for leaking oil.
 - (a) If there is oil present inside the exhaust manifolds, go to Step (3) below.
 - (b) If there is no oil inside the exhaust manifold, go to Step 7 of this Fault.
- (3) Remove cylinder head (Para 3-7).
- (4) Check cylinder head, valve guides, valve guides seals, head gasket and oil seals for cracks and damage.
 - (a) If cylinder head, gaskets and/or seals are damaged, replace damaged components (Para 3-7).
 - (b) If cylinder head, gaskets and seals are OK, go to Step 7 of this Fault.
- (5) Install cylinder head (Para 3-7).
- (6) Install exhaust manifolds (Para 3-31).



5. EXCESSIVE OIL CONSUMPTION OR BLUE EXHAUST SMOKE (CONT).






WARNING


Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.

VISUAL INSPECTION





- (1) Remove eight screws, washers, lockwashers and left side noise panel. Discard lockwashers.
- (2) Remove 14 screws, six air box covers and gaskets. Discard gaskets.
- (3) Check for oil leakage past cylinder ports or piston rings.
 - (a) If oil is leaking past cylinder ports or piston rings, perform Step (4) and (5) below and replace engine (Para 3-4).
 - (b) If oil is not leaking past cylinder ports or piston rings, perform Step (4) and (5) below and go to Step 8 of this Fault.
- (4) Turn OFF ENGINE switch.
- (5) Install six gaskets and air box covers with 14 screws.



5. EXCESSIVE OIL CONSUMPTION OR BLUE EXHAUST SMOKE (CONT).



- VERIFY REPAIR**
- (1) Start engine (TM 9-2320-364-10) and observe quantity and color of exhaust smoke.
 - (a) If exhaust smoke is excessive and blue in color and oil consumption is still high, fault not corrected. Perform Steps (2) through (5) below and notify supervisor.
 - (b) If oil pressure is within normal range, and exhaust smoke color is normal, fault has been corrected.
 - (2) Turn OFF ENGINE switch.
 - (3) Install cab engine access panel with 22 washers, lockwashers and screws.
 - (4) Install left side noise panel with eight washers, lockwashers and screws.
 - (5) Install right side noise panel (TM 9-2320-364-20).



2-10. ENGINE TROUBLESHOOTING (CONT).

6. WHITE EXHAUST SMOKE (ENGINE AT NORMAL OPERATING TEMPERATURE).

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Cartridge, DDEC (Item 29, Appendix F)
- Reader, Diagnostic (Item 180, Appendix F)
- Tester, Pressure, Radiator (Item 237, Appendix F)

References


- TM 9-2320-364-10
- TM 9-2320-364-20

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)

Materials/Parts

- Gasket (2) (Item 115, Appendix E)
- Gasket (4) (Item 116, Appendix E)
- Lockwasher (8) (Item 282, Appendix E)




WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

DDEC MODE 10 TEST

- (1) Connect DDR to DDL connector MC13.
- (2) Start engine (TM 9-2320-364-10).
- (3) Select mode 10 to display fuel injector response times on DDR.
- (4) Compare response times of all eight injectors.
 - (a) If any injector response time is less than others or .80 milliseconds, perform Steps (5) and (6) below and replace injector (Para 4-2).
 - (b) If injector response times are same as others or greater than .80 milliseconds, response times are OK, perform Steps (5) and (6) below and go to Step 2 of this Fault.
- (5) Turn OFF ENGINE switch.
- (6) Disconnect DDR from DDL connector MC13.




6. WHITE EXHAUST SMOKE (CONT).




WARNING

Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.


DDR TEST
<p>(1) Connect DDR to DDL connector MC13.</p> <p>(2) Start engine (TM 9-2320-364-10).</p> <p>(3) Select mode 11 to display pulse widths on DDR.</p> <p>(4) Compare pulse widths of all eight injectors.</p> <p>(a) If pulse widths are less than the NO CUT OUT PW (pulse widths), or different from cylinder to cylinder, perform Steps (5) and (6) below and replace injector (Para 4-2).</p> <p>(b) If pulse widths are equal to or greater than the NO CUT OUT PW (pulse widths), perform Steps (5) and (6) below and go to Step 3 of this Fault.</p> <p>(5) Turn OFF ENGINE switch.</p> <p>(6) Disconnect DDR from DDL connector MC13.</p>



INJECTOR TIMING CHECK
<p>Perform injector timing check (Para 3-2).</p> <p>(1) If injectors are out of time, time injectors (Para 3-2).</p> <p>(2) If injectors are in time, go to Step 4 of this Fault.</p>



6. WHITE EXHAUST SMOKE (CONT).





WARNING


- Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.
- Do not remove the radiator cap when the engine is hot; steam and hot coolant can escape and burn personnel.
- Use a clean, thick waste cloth or like material to remove the cap. Avoid using gloves. If hot water soaks through gloves, personnel could be burned.

AFTERCOOLER INSPECTION

- (1) Remove right side noise panel (TM 9-2320-364-20).
- (2) Remove eight screws, lockwashers, washers and left side noise panel. Discard lockwashers.
- (3) Remove 14 screws, six engine air box covers and gaskets. Discard gaskets.
- (4) Remove radiator cap (TM 9-2320-364-10).
- (5) Install cooling system pressure tester on radiator.
- (6) Pressurize cooling system to 10 psi (69 kPa) and check air box for coolant.
 - (a) If coolant is found in air box, replace aftercooler (Para 5-5).
 - (b) If no coolant is found in air box, perform Step (7) below and go to Step 5 of this Fault.
- (7) Release pressure.



6. WHITE EXHAUST SMOKE (CONT).






WARNING

- Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.
- Do not remove the radiator cap when the engine is hot; steam and hot coolant can escape and burn personnel.
- Use a clean, thick waste cloth or like material to remove the cap. Avoid using gloves. If hot water soaks through gloves, personnel could be burned.

CYLINDER HEAD INSPECTION

- (1) Install cooling system pressure tester on radiator.
- (2) Pressurize cooling system to 10 psi (69 kPa) and check cylinder heads for leaks.
 - (a) If cylinder heads show signs of coolant leaking, replace cylinder head, sealing rings and preformed packings (Para 3-7).
 - (b) If cylinder head, sealing rings and preformed packings are not leaking but pressure still goes down, notify GS Maintenance.
- (3) Release pressure and remove cooling system pressure tester from radiator.
- (4) Install radiator cap.
- (5) Install six gaskets, engine air box covers and 14 screws.




6. WHITE EXHAUST SMOKE (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. Engine cylinders not misfiring. Injector response times OK. Injector pulse widths OK. Injector timing OK. Aftercooler OK. Cylinder head seals OK.
POSSIBLE PROBLEMS

6.


Is exhaust smoke quantity and color normal with engine at standard operating temperature?



TEST OPTIONS
Verify repair.
REASON FOR QUESTION
If exhaust smoke is not white, fault has been corrected. ←

VERIFY REPAIR

- (1) Start truck and observe quantity and color of exhaust smoke (TM 9-2320-364-10).
 - (a) If exhaust smoke is still white, fault not corrected. Perform Steps (2) through (4) below and notify supervisor.
 - (b) If exhaust smoke is normal in quantity and color, fault has been corrected.
- (2) Turn OFF ENGINE switch.
- (3) Install left side noise panel with eight washers, lockwashers and screws.
- (4) Install right side noise panel (TM 9-2320-364-20).



2-11. TRANSMISSION SYSTEM TROUBLESHOOTING.

This paragraph covers Transmission System Troubleshooting. The Transmission System Fault Index, Table 2-8, lists faults for the transmission system of the PLS truck.

Table 2-8. Transmission System Fault Index

Fault No.	Description	Page
1.	Low Oil Level Sensor Circuit Faulty	2-116
2.	Forward Pressure Switch Circuit Faulty	2-124
3.	Reverse Pressure Switch Circuit Faulty	2-130
4.	Oil Temperature Sensor Circuit Faulty	2-136
5.	Solenoids J,F,D,C,B,A,G,E Or H Circuit Faulty	2-140
6.	Transmission Overheats (Trans Temp Gage Continuously Reads Over 220°F [104°C])	2-146
7.	Transmission Unusually Noisy When Operating	2-152
8.	Transmission Will Not Shift Into Gear, Shifts Out Of Gear, Does Not Respond To Range Selection, Or Operates Abnormally	2-160
9.	Engine Stalls When Transmission Is Shifted Into Gear	2-168

2-11. TRANSMISSION SYSTEM TROUBLESHOOTING (CONT).

1. LOW OIL LEVEL SENSOR CIRCUIT FAULTY.

INITIAL SETUP

Tools and Special Tools


Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Analyzer Set, STE/ICE-R (Optional)
 (Item 15, Appendix F)
 Cartridge, ATEC (Item 28, Appendix F)
 Harness, Breakout (Item 94, Appendix F)
 Multimeter (Item 140, Appendix F)
 Reader, Diagnostic (Item 180, Appendix F)
 Jumperwire

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)
 Transmission internal oil filter removed,
 (Para 7-4)
 Left rear fender skirt removed,
 (TM 9-2320-364-20)

References

TM 9-2320-364-10
 TM 9-2320-364-20
 TM 9-4910-571-12&P




WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

CONTINUITY TEST

- (1) Set multimeter select switch to ohms.
- (2) Disconnect sensor harness assembly from low oil level sensor.
- (3) Is there continuity between oil level sensor terminals?
 - (a) If there is continuity, low oil level sensor is OK. Go to Step 2 of this Fault.
 - (b) If there is no continuity, replace low oil level sensor (Para 7-5).



1. LOW OIL LEVEL SENSOR CIRCUIT FAULTY (CONT).




WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

CONTINUITY TEST

- (1) Disconnect sensor harness assembly from solenoid wiring harness assembly connectors.
- (2) Connect jumper wire between terminals of sensor harness assembly double connector.
- (3) Is there continuity between the sensor harness assembly single terminals?
 - (a) If there is no continuity, replace sensor harness assembly (Para 7-6).
 - (b) If there is continuity, sensor harness assembly is OK.



1. LOW OIL LEVEL SENSOR CIRCUIT FAULTY (CONT).




WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

CONTINUITY TEST

- (1) Disconnect connector MC19 from transmission bulkhead connector.
- (2) Connect breakout harness connector to transmission bulkhead connector.
- (3) Is there continuity between terminal E and any other wire on breakout harness connector?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, go to Step (4) below.
- (4) Is there continuity between terminal H and any other wire on breakout harness connector?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, go to Step (5) below.
- (5) Connect a jumper wire between terminals 1 and 2 of solenoid wiring harness.
- (6) Is there continuity between terminals E and H on breakout harness connector?
 - (a) If there is no continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is continuity, go to Step (7) below.
- (7) Is there continuity between terminal H on the breakout harness connector and a known good ground?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, replace ATEC ECU (TM 9-2320-364-20).
- (8) Remove jumper wire from terminals 1 and 2.
- (9) Install sensor harness assembly.
- (10) Remove breakout harness.
- (11) Connect connector MC19 to transmission bulkhead connector.
- (12) Install internal oil filter (Para 7-4).




1. LOW OIL LEVEL SENSOR CIRCUIT FAULTY (CONT).



VERIFY REPAIR

- (1) Install an ATEC cartridge in DDR (TM 9-2320-364-20).
- (2) Connect DDR cable to DDL connector MC13.
- (3) Start engine (TM 9-2320-364-10).
- (4) Clear codes on DDR reader.
- (5) Check DDR for an active code 12.
 - (a) If a code 12 is not displayed, fault has been corrected. Perform Steps (6) through (8) below.
 - (b) If a code 12 is displayed, fault not corrected. Perform Steps (6) through (8) below and notify supervisor.
- (6) Turn OFF ENGINE switch.
- (7) Disconnect DDR cable from DDL connector MC13.
- (8) Install left rear fender skirt (TM 9-2320-364-20).



2-11. TRANSMISSION SYSTEM TROUBLESHOOTING (CONT).

2. FORWARD PRESSURE SWITCH CIRCUIT FAULTY.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Analyzer Set, STE/ICE-R (Optional)
 (Item 15, Appendix F)
 Cartridge, ATEC (Item 28, Appendix F)
 Goggles, Industrial (Item 83, Appendix F)
 Gun, Airblow (Item 86, Appendix F)
 Harness, Breakout (Item 94, Appendix F)
 Multimeter (Item 140, Appendix F)
 Reader, Diagnostic (Item 180, Appendix F)
 Wrench Set, Socket 3/8 In. (Item 273, Appendix F)
 Wrench, Torque (0-60 N·m) (Item 276, Appendix F)
 Zonal Separator, Oil and Water Spray Gun
 (Item 280, Appendix F)
 Jumperwire

Personnel Required

Two

References


TM 9-2320-364-10
 TM 9-2320-364-20
 TM 9-4910-571-12&P

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)
 Left rear fender skirt removed,
 (TM 9-2320-364-20)
 Transmission internal oil filter removed,
 (Para 7-4)


Materials/Parts

Packing, Preformed (Item 400, Appendix E)




WARNING

- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.
- Blowing transmission oil can cause injury to eyes. Safety goggles must be worn when testing transmission oil pressure switch.




CONTINUITY TEST	
(1)	Remove two screws, forward pressure switch and preformed packing. Discard preformed packing.
(2)	Disconnect pressure switch connector.
(3)	With the aid of an assistant, apply 25 to 35 psi (172 to 241 kPa) air to pressure switch orifice and check continuity across pressure switch. <ul style="list-style-type: none"> (a) If there is no continuity, replace forward pressure switch (Para 7-8). (b) If there is continuity, pressure switch is OK.
(4)	Install preformed packing, pressure switch and two screws. Tighten screws to 60 to 84 lbs-in (6.8 to 9.5 N-m).


SOLENOID WIRING HARNESS ASSEMBLY



FRONT OF TRUCK




2. FORWARD PRESSURE SWITCH CIRCUIT FAULTY (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

- CONTINUITY TEST**
- (1) Disconnect connector MC19 from transmission bulkhead connector.
 - (2) Connect breakout harness connector to transmission bulkhead connector.
 - (3) Is there continuity between terminal E and any other wire on breakout harness connector?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, go to Step (4) below.
 - (4) Is there continuity between terminal F and any other wire on breakout harness connector?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, go to Step (5) below.
 - (5) Connect a jumper wire between terminals 1 and 2.
 - (6) Is there continuity between terminals E and F on breakout harness connector?
 - (a) If there is no continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is continuity, go to Step (7) below.
 - (7) Is there continuity between terminal F on the breakout harness connector and a known good ground?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, replace ATEC ECU (TM 9-2320-364-20).
 - (8) Remove jumper wire from terminals 1 and 2.
 - (9) Remove breakout harness.
 - (10) Connect MC19 connector to bulkhead connector.
 - (11) Install internal oil filter (Para 7-4).




2. FORWARD PRESSURE SWITCH CIRCUIT FAULTY (CONT).



VERIFY REPAIR

- (1) Install an ATEC cartridge in DDR (TM 9-2320-364-20).
- (2) Connect DDR cable to DDL connector MC13.
- (3) Start engine (TM 9-2320-364-10).
- (4) Clear codes on DDR reader.
- (5) Check DDR for an active code 14.
 - (a) If a code 14 is not displayed, fault has been corrected. Perform Steps (6) through (8) below.
 - (b) If a code 14 is displayed, fault not corrected. Perform Steps (6) through (8) below and notify supervisor.
- (6) Turn OFF ENGINE switch.
- (7) Disconnect DDR cable from DDL connector MC13.
- (8) Install left rear fender skirt (TM 9-2320-364-20).



2-11. TRANSMISSION SYSTEM TROUBLESHOOTING (CONT).

3. REVERSE PRESSURE SWITCH CIRCUIT FAULTY.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Analyzer Set, STE/ICE-R (Optional)
 (Item 15, Appendix F)
 Cartridge, ATEC (Item 28, Appendix F)
 Goggles, Industrial (Item 83, Appendix F)
 Gun, Airblow (Item 86, Appendix F)
 Harness, Breakout (Item 94, Appendix F)
 Multimeter (Item 140, Appendix F)
 Reader, Diagnostic (Item 180, Appendix F)
 Wrench Set, Socket 3/8 In. (Item 273, Appendix F)
 Wrench, Torque (0-60 N·m) (Item 276, Appendix F)
 Zonal Separator, Oil and Water Spray Gun
 (Item 280, Appendix F)
 Jumperwire

Materials/Parts

Packing, Preformed (Item 400, Appendix E)

Personnel Required


Two

References

TM 9-2320-364-10
 TM 9-2320-364-20
 TM 9-4910-571-12&P


Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)
 Left rear fender skirt removed,
 (TM 9-2320-364-20)
 Transmission internal oil filter removed,
 (Para 7-4)




WARNING


- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.
- Blowing transmission oil can cause injury to eyes. Safety goggles must be worn when testing transmission oil pressure switch.



SOLENOID
WIRING
HARNESS
ASSEMBLY




FRONT OF TRUCK



CONTINUITY TEST

- (1) Remove two screws, reverse pressure switch and preformed packing. Discard preformed packing.
- (2) Disconnect pressure switch connector.
- (3) With the aid of an assistant, apply 25 to 35 psi (172 to 241 kPa) air to pressure switch orifice and check continuity across pressure switch.
 - (a) If there is no continuity, replace reverse pressure switch (Para 7-8).
 - (b) If there is continuity, pressure switch is OK.
- (4) Install preformed packing, pressure switch and two screws. Tighten screws to 60 to 84 lbs-in (6.8 to 9.5 N·m).


3. REVERSE PRESSURE SWITCH CIRCUIT FAULTY (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

- CONTINUITY TEST**
- (1) Disconnect connector MC19 from transmission bulkhead connector.
 - (2) Connect breakout harness connector to transmission bulkhead connector.
 - (3) Is there continuity between terminal E and any other wire on breakout harness connector?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, go to Step (4) below.
 - (4) Is there continuity between terminal G and any other wire on breakout harness connector?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, go to Step (5) below.
 - (5) Connect a jumper wire between terminals 1 and 2.
 - (6) Is there continuity between terminals E and G on breakout harness connector?
 - (a) If there is no continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is continuity, go to Step (7) below.
 - (7) Is there continuity between terminal G on the breakout harness connector and a known good ground?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, replace ATEC ECU (TM 9-2320-364-20).
 - (8) Remove jumper wire from terminals 1 and 2.
 - (9) Remove breakout harness.
 - (10) Connect connector MC19 to bulkhead connector.
 - (11) Install internal oil filter (Para 7-4).




3. REVERSE PRESSURE SWITCH CIRCUIT FAULTY (CONT).



VERIFY REPAIR

- (1) Install an ATEC cartridge in DDR (TM 9-2320-364-20).
- (2) Connect DDR cable to DDL connector MC13.
- (3) Start engine (TM 9-2320-364-10).
- (4) Clear codes on DDR reader.
- (5) Check DDR for an active code 15.
 - (a) If a code 15 is not displayed, fault has been corrected. Perform Steps (6) through (8) below.
 - (b) If a code 15 is displayed, fault not corrected. Perform Steps (6) through (8) below and notify supervisor.
- (6) Turn OFF ENGINE switch.
- (7) Disconnect DDR cable from DDL connector MC13.
- (8) Install left rear fender skirt (TM 9-2320-364-20).



2-11. TRANSMISSION SYSTEM TROUBLESHOOTING (CONT).

4. OIL TEMPERATURE SENSOR CIRCUIT FAULTY.

INITIAL SETUP

Tools and Special Tools


- Tool Kit General Mechanic's (Item 240, Appendix F)
- Analyzer Set, STE/ICE-R (Optional) (Item 15, Appendix F)
- Cartridge, ATEC (Item 28, Appendix F)
- Harness, Breakout (Item 94, Appendix F)
- Multimeter (Item 140, Appendix F)
- Reader, Diagnostic (Item 180, Appendix F)

References

- TM 9-2320-364-10
- TM 9-2320-364-20
- TM 9-4910-571-12&P

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Left rear fender skirt removed, (TM 9-2320-364-20)




WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

RESISTANCE TEST

- (1) Disconnect connector MC19 from transmission bulkhead connector.
- (2) Connect breakout harness to transmission bulkhead connector.
- (3) Is there resistance between breakout harness terminals A and P?
 - (a) If less than 5k ohms or more than 130k ohms are present, remove breakout harness and replace solenoid wiring harness assembly (Para 7-2).
 - (b) If 5k to 130k ohms are present, perform Steps (4) and (5) below and replace ATEC ECU (TM 9-2320-364-20).
- (4) Remove breakout harness.
- (5) Connect connector MC19 to bulkhead connector.




4. OIL TEMPERATURE SENSOR CIRCUIT FAULTY (CONT).



VERIFY REPAIR

- (1) Install an ATEC cartridge in DDR (TM 9-2320-364-20).
- (2) Connect DDR cable to DDL connector MC13.
- (3) Start engine (TM 9-2320-364-10).
- (4) Clear codes on DDR reader.
- (5) Check DDR for an active code 33.
 - (a) If a code 33 is not displayed, fault has been corrected. Perform Steps (6) through (8) below.
 - (b) If a code 33 is displayed, fault not corrected. Perform Steps (6) through (8) below and notify supervisor.
- (6) Turn OFF ENGINE switch.
- (7) Disconnect DDR cable from DDL connector MC13.
- (8) Install left rear fender skirt (TM 9-2320-364-20).



2-11. TRANSMISSION SYSTEM TROUBLESHOOTING (CONT).

5. SOLENOIDS J, F, D, C, B, A, G, E OR H CIRCUIT FAULTY.

INITIAL SETUP

Tools and Special Tools


Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Analyzer Set, STE/ICE-R (Optional)
 (Item 15, Appendix F)
 Cartridge, ATEC (Item 28, Appendix F)
 Harness, Breakout (Item 94, Appendix F)
 Multimeter (Item 140, Appendix F)
 Reader, Diagnostic (Item 180, Appendix F)
 Jumperwire

References

TM 9-2320-364-10
 TM 9-2320-364-20
 TM 9-4910-571-12&P

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)
 Left rear fender skirt removed,
 (TM 9-2320-364-20)
 Transmission internal oil filter removed, (Para 7-4)





WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

Table 2-9. Breakout Harness/Solenoid Wire Harness Assembly Test Points


Solenoid (Code No.)	Breakout Harness/Solenoid Wire Harness Assembly Test Points	
	Output Wires Terminals	Input Wires Terminals
J	B	D
F	V	U
D	V	W
C	W	B
B	U	T
A	C	T
G	O	L
E	M	N
H	K	N




RESISTANCE TEST

(1) Disconnect solenoid connector.
 (2) Measure resistance between solenoid connector terminals (see Table 2-9).
 (a) If 9 to 20 ohms are not present, replace solenoid (Para 7-7).
 (b) If 9 to 20 ohms are present, solenoid is OK.

SOLENOID CONNECTOR **FRONT OF TRUCK**



5. SOLENOIDS J, F, D, C, B, A, G, E OR H CIRCUIT FAULTY (CONT).



WARNING



Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE


Table 2-9 lists the breakout connector/solenoid power input and output terminals for each solenoid.

CONTINUITY TEST

- (1) Disconnect connector MC19 from transmission bulkhead connector.
- (2) Connect breakout harness connector to transmission bulkhead connector.
- (3) Is there continuity between the breakout harness input terminal for the suspected faulty solenoid, and any other breakout harness terminal?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, go to Step (4) below.
- (4) Is there continuity between the breakout harness output terminal for the suspected faulty solenoid, and any other breakout harness terminal?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, go to Step (5) below.
- (5) Connect a jumper wire between terminals 1 and 2 of suspected faulty solenoid.
- (6) Is there continuity between the breakout harness input and output terminals of the suspected faulty solenoid?
 - (a) If there is no continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is continuity, go to Step (7) below.
- (7) Is there continuity between terminal 1 and a known good ground with jumper wire connected?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, replace ATEC ECU (TM 9-2320-364-20).
- (8) Remove jumper wire from terminals 1 and 2.
- (9) Remove breakout harness.
- (10) Connect connector MC19 to transmission bulkhead connector.
- (11) Install internal oil filter (Para 7-4).




5. SOLENOIDS J, F, D, C, B, A, G, E OR H CIRCUIT FAULTY (CONT).



VERIFY REPAIR

- (1) Install an ATEC cartridge in DDR (TM 9-2320-364-20).
- (2) Connect DDR cable to DDL connector MC13.
- (3) Turn ON ENGINE switch (TM 9-2320-364-10).
- (4) Clear codes on DDR reader.
- (5) Check DDR for solenoid code.
 - (a) If code is not displayed, fault has been corrected. Perform Steps (6) through (8) below.
 - (b) If code is displayed, fault not corrected. Perform Steps (6) through (8) below and notify supervisor.
- (6) Turn OFF ENGINE switch.
- (7) Disconnect DDR cable from DDL connector MC13.
- (8) Install left rear fender skirt (TM 9-2320-364-20).



2-11. TRANSMISSION SYSTEM TROUBLESHOOTING (CONT).

6. TRANSMISSION OVERHEATS (TRANS TEMP GAGE CONTINUOUSLY READS OVER 220°F [104°C]).

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's (Item 240, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)
 Wrench Set, Socket 3/8 In. (Item 273, Appendix F)
 Wrench, Torque (0-60 N·m) (Item 276, Appendix F)

Materials/Parts

Sealing Compound (Item 53, Appendix B)

Personnel Required


Two

References

TM 9-2320-364-10

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)



WARNING

- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent or sealing compound gets on skin or clothing, wash immediately with soap and water.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

CAUTION


Due to limited work area, be prepared with suitable container to catch approximately one quart of oil when removing lube oil pressure port plug, or hose for pressure gage, from underside of torque converter housing, personnel can become wet with oil.

NOTE


Use a drain pan to catch leaking hydraulic oil.

PRESSURE TEST

- (1) Remove plug from lube pressure port in converter housing.
- (2) Install 1/8 in. NPT adapter from pressure test kit.
- (3) Install 6 ft. (1.8 m) hose from kit on adapter and 0 to 160 psi (1103 kPa) gage on hose. Extend gage out from under truck.
- (4) Start engine (TM 9-2320-364-10). Operate at approximately 1400 RPM while assistant reads pressure gage.
 - (a) If lubrication pressure is not between 40 to 45 psi (276 to 310 kPa), perform Steps (5) through (7) below and go to Step 2 of this Fault.
 - (b) If lubrication pressure is OK, perform Steps (5) through (7) below and replace transmission (Para 3-4).
- (5) Turn OFF engine switch.
- (6) Remove pressure gage, hose, and adapter from lube port of converter housing.
- (7) Apply thread sealing compound and install plug in lubrication port of converter housing. Tighten plug to 48 to 60 lb-in (5.4 to 6.8 N-m).




6. TRANSMISSION OVERHEATS (TRANS TEMP GAGE CONTINUOUSLY READS OVER 220°F [104°C]) (CONT).




VISUAL INSPECTION

- (1) Remove transmission internal oil filter (Para 7-4).
- (2) Inspect oil filter for damaged pickup tube, missing or defective preformed packing, or clogged filter.
 - (a) If filter or pickup tube and/or preformed packing are damaged or clogged, replace internal oil filter (Para 7-4).
 - (b) If filter and oil pickup tube are OK, replace transmission (Para 3-4).




6. TRANSMISSION OVERHEATS (TRANS TEMP GAGE CONTINUOUSLY READS OVER 220°F [104°C]) (CONT).



VERIFY REPAIR

Operate truck (TM 9-2320-364-10).

- (1) If transmission operates normally, fault has been corrected.
- (2) If transmission temperature gage continues to read over 220°F (104°C), fault not corrected. Notify supervisor.



2-11. TRANSMISSION SYSTEM TROUBLESHOOTING (CONT).

7. TRANSMISSION UNUSUALLY NOISY WHEN OPERATING.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)
 Wrench Set, Socket 3/8 In. (Item 273, Appendix F)
 Wrench, Torque (0-60 N·m) (Item 276, Appendix F)

Materials/Parts

Sealing Compound (Item 53, Appendix B)

Personnel Required


Two


References

TM 9-2320-364-10
 TM 9-2320-364-20


Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)






- VISUAL INSPECTION**
- (1) Shift transfer case to NEUT (N) (TM 9-2320-364-10).
 - (2) Turn transmission driveshaft back and forth by hand.
 - (a) If shaft is loose in yoke, replace yoke (Para 7-9).
 - (b) If shaft is not loose, go to Step 3 below.
 - (3) Shift transfer case to HI (H).



7. TRANSMISSION UNUSUALLY NOISY WHEN OPERATING (CONT).



WARNING

- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

CAUTION


Due to limited work area, be prepared with suitable container to catch approximately one quart of oil when removing lube oil pressure port plug, or hose for pressure gage, from underside of torque converter housing, personnel can become wet with oil.

NOTE


Use a drain pan to catch leaking hydraulic oil.

PRESSURE TEST

- (1) Remove plug from lube pressure port of converter housing.
- (2) Install 1/8 in. NPT adapter from pressure test kit.
- (3) Install 6 ft. (1.8 m) hose from kit on adapter and 0 to 160 psi (1103 kPa) gage on hose. Extend gage out from under truck.
- (4) Start engine (TM 9-2320-364-10). Operate at approximately 1400 RPM while assistant reads pressure gage.
 - (a) If lubrication pressure is not between 40 to 45 psi (276 to 310 kPa), perform Steps (5) through (7) below and go to Step 3 of this Fault.
 - (b) If lubrication pressure is OK, perform Steps (5) through (7) below and replace transmission (Para 3-4).
- (5) Turn OFF engine switch.
- (6) Remove pressure gage, hose, and adapter from lube port of converter housing.
- (7) Apply thread sealing compound and install plug in lubrication port of converter housing. Tighten plug to 48 to 60 lb-in (5.4 to 6.8 N-m).




7. TRANSMISSION UNUSUALLY NOISY WHEN OPERATING (CONT).




VISUAL INSPECTION

- (1) Remove transmission internal oil filter (Para 7-4).
- (2) Inspect oil filter for damaged pickup tube, missing or defective preformed packing, or clogged filter.
 - (a) If filter or pickup tube and/or preformed packing are damaged or clogged, replace internal oil filter (Para 7-4).
 - (b) If filter and oil pickup tube are OK, replace transmission (Para 3-4).




7. TRANSMISSION UNUSUALLY NOISY WHEN OPERATING (CONT).



VERIFY REPAIR

- Operate truck (TM 9-2320-364-10).
- (1) If transmission operates normally, fault has been corrected.
 - (2) If transmission continues to operate noisily, fault not corrected. Notify supervisor.

**STEERING WHEEL SHOWN
REMOVED FOR
CLARITY**



2-11. TRANSMISSION SYSTEM TROUBLESHOOTING (CONT).

8. TRANSMISSION WILL NOT SHIFT INTO GEAR, SHIFTS OUT OF GEAR, DOES NOT RESPOND TO RANGE SELECTION, OR OPERATES ABNORMALLY.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)
- Wrench Set, Socket 3/8 In. (Item 273, Appendix F)
- Wrench, Torque (0-60 N·m) (Item 276, Appendix F)

References

- TM 9-2320-364-10
- TM 9-2320-364-20

Equipment Condition


- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)

Materials/Parts

- Oil, Hydraulic (Item 34, Appendix B)
- Sealing Compound (Item 53, Appendix B)

Personnel Required

Two



WARNING

- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

CAUTION


Due to limited work area, be prepared with suitable container to catch approximately one quart of oil when removing lube oil pressure port plug, or hose for pressure gage, from underside of torque converter housing, personnel can become wet with oil.

NOTE


Use a drain pan to catch leaking hydraulic oil.

PRESSURE TEST

- (1) Remove main oil pressure port plug.
- (2) Install 1/8 in. NPT adapter from pressure test kit in main pressure port.
- (3) Install 6 ft. (1.8 m) hose from kit on adapter and 0 to 2000 psi (13790 kPa) gage on hose. Extend hose out from under truck to read while truck is in gear and running.
- (4) Start engine and allow to run at idle speed.
- (5) Select D (Drive) at shift selector (TM 9-2320-364-10) while assistant reads pressure gage.
 - (a) If pressure is less than 110 psi (758 kPa), perform Steps (6) through (10) below and go to Step 2 of this Fault.
 - (b) If pressure is a minimum of 110 psi (758 kPa), perform Steps (6) through (10) below and replace transmission (Para 3-4).
- (6) Select N (Neutral) at shift selector.
- (7) Turn OFF engine switch.
- (8) Remove 1/8 in. adapter, hose, and gage from main oil pressure port.
- (9) Apply thread sealing compound to plug.
- (10) Install plug in main port of converter housing. Tighten plug to 48 to 60 lb-in (5.4 to 6.8 N·m).




8. TRANSMISSION WILL NOT SHIFT INTO GEAR, SHIFTS OUT OF GEAR, DOES NOT RESPOND TO RANGE SELECTION, OR OPERATES ABNORMALLY (CONT).




VISUAL INSPECTION

- (1) Remove transmission internal oil filter (Para 7-4).
- (2) Inspect oil filter for damaged pickup tube, missing or defective preformed packing, or clogged filter.
 - (a) If filter or pickup tube and/or preformed packing are damaged or clogged, replace internal oil filter (Para 7-4).
 - (b) If filter and oil pickup tube are OK, go to Step 3 of this Fault.




8. TRANSMISSION WILL NOT SHIFT INTO GEAR, SHIFTS OUT OF GEAR, DOES NOT RESPOND TO RANGE SELECTION, OR OPERATES ABNORMALLY (CONT).




VISUAL INSPECTION

- (1) Inspect servo unit control valve assembly for cracks or damage.
 - (a) If servo unit control valve assembly is cracked or damaged, replace transmission (Para 3-4).
 - (b) If servo unit control valve assembly is not cracked or damaged, go to Step (2) below.
- (2) Inspect front plate assembly for cracks or damage.
 - (a) If front plate assembly is cracked or damaged, replace transmission (Para 3-4).
 - (b) If front plate assembly is not cracked or damaged, go to Step (3) below.
- (3) Inspect first clutch trimmer assembly for cracks or damage.
 - (a) If first clutch trimmer assembly is cracked or damaged, replace transmission (Para 3-4).
 - (b) If first clutch trimmer assembly is not cracked or damaged, go to Step (4) below.
- (4) Inspect shift valve body for cracks or damage.
 - (a) If shift valve body is cracked or damaged, replace transmission (Para 3-4).
 - (b) If shift valve body assembly is not cracked or damaged, go to Step (5) below.
- (5) Check screws of all valve assemblies for proper torque.
 - (a) Tighten all screws attaching valve assemblies 96 to 144 lb-in (10.8 to 16.3 N·m), perform Steps (6) and (7) below and go to Step 4 of this Fault.
 - (b) If screws of valve assemblies are OK, replace transmission (Para 3-4).
- (6) Install transmission internal oil filter (Para 7-4).
- (7) Add transmission oil as necessary (TM 9-2320-364-20).



8. TRANSMISSION WILL NOT SHIFT INTO GEAR, SHIFTS OUT OF GEAR, DOES NOT RESPOND TO RANGE SELECTION, OR OPERATES ABNORMALLY (CONT).




VERIFY REPAIR

Operate truck (TM 9-2320-364-10).

- (1) If truck does not shift into gear, shifts out of gear, does not respond to range selection, or otherwise operates abnormally, fault not corrected. Notify supervisor.
- (2) If truck operates normally, fault has been corrected.

**STEERING WHEEL SHOWN
REMOVED FOR
CLARITY**



**ENGINE
SWITCH**

**TRANSMISSION
RANGE
SELECTOR**

2-11. TRANSMISSION SYSTEM TROUBLESHOOTING (CONT).

9. ENGINE STALLS WHEN TRANSMISSION IS SHIFTED INTO GEAR.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Analyzer Set, STE/ICE-R (Optional) (Item 15, Appendix F)
- Cartridge, ATEC (Item 28, Appendix F)
- Harness, Breakout (Item 94, Appendix F)
- Multimeter (Item 140, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)
- Reader, Diagnostic (Item 180, Appendix F)
- Wrench, Torque (0-60 N·m) (Item 276, Appendix F)
- Jumperwire

Materials/Parts

- Sealing Compound (Item 53, Appendix B)

Personnel Required


Two

References

- TM 9-2320-364-10
- TM 9-2320-364-20

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Left rear fender skirt removed, (TM 9-2320-364-20)
- Transmission internal oil filter removed, (Para 7-4)





WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

Table 2-10. Breakout Harness/Solenoid Wire Harness Assembly Test Points

Solenoid (Code No.)	Breakout Harness/Solenoid Wire Harness Assembly Test Points	
	Output Wires Terminals	Input Wires Terminals
J	B	D
F	V	U
D	V	W
C	W	B
B	U	T
A	C	T
G	O	L
E	M	N
H	K	N



RESISTANCE TEST


(1) Disconnect solenoid connector.
 (2) Measure resistance between solenoid connector terminals (see Table 2-10.
 (a) If 9 to 20 ohms are not present, replace solenoid (Para 7-7).
 (b) If 9 to 20 ohms are present, solenoid is OK.

**SOLENOID
CONNECTOR**


FRONT OF TRUCK

SOLENOID

TERMINALS



9. ENGINE STALLS WHEN TRANSMISSION IS SHIFTED INTO GEAR (CONT).



WARNING



Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE


Table 2-10 lists the breakout connector/solenoid power input and output terminals for each solenoid.

CONTINUITY TEST

- (1) Disconnect connector MC19 from transmission bulkhead connector.
- (2) Connect breakout harness connector to transmission bulkhead connector.
- (3) Is there continuity between the breakout harness input terminal for the suspected faulty solenoid, and any other breakout harness terminal?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, go to Step (4) below.
- (4) Is there continuity between the breakout harness output terminal for the suspected faulty solenoid, and any other breakout harness terminal?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, go to Step (5) below.
- (5) Connect a jumper wire between terminals 1 and 2 of suspected faulty solenoid.
- (6) Is there continuity between the breakout harness input and output terminals of the suspected faulty solenoid?
 - (a) If there is no continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is continuity, go to Step (7) below.
- (7) Is there continuity between terminal 1 and a known good ground with jumper wire connected?
 - (a) If there is continuity, replace solenoid wiring harness assembly (Para 7-2).
 - (b) If there is no continuity, solenoid wiring harness assembly is OK.
- (8) Remove jumper wire from terminals 1 and 2.
- (9) Remove breakout harness.
- (10) Connect connector MC19 to transmission bulkhead connector.
- (11) Install internal oil filter (Para 7-4).



9. ENGINE STALLS WHEN TRANSMISSION IS SHIFTED INTO GEAR (CONT).



WARNING

- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

CAUTION


Due to limited work area, be prepared with suitable container to catch approximately one quart of oil when removing lube oil pressure port plug, or hose for pressure gage, from underside of torque converter housing, personnel can become wet with oil.

NOTE


Use a drain pan to catch leaking hydraulic oil.

PRESSURE TEST

- (1) Remove plugs from "non active" and "lockup" ports of converter housing.
- (2) Install 1/8 in. NPT adapters, from pressure test kit, in "nonactive" and "lockup" ports of converter housing.
- (3) Install 5 ft. (1.5 m) hose from kit, on adapter in "non active" port and 0 to 160 psi (1,103 kPa) gage on hose. Extend hose out from under truck.
- (4) Install 8 ft. (2.4 m) hose from kit on adapter in "lockup" port and 0 to 2000 psi (13,790 kPa) gage on hose. Extend gage out from under truck.
- (5) Start engine (TM 9-2320-364-10) and allow to run at idle speed while assistant reads pressure gages.
 - (a) If pressure is between 150 to 160 psi (1,034 kPa to 1,103 kPa) on both gages, lockup shift valve is OK, replace ATEC ECU, (TM 9-2320-364-20).
 - (b) If pressure is between 150 to 160 psi (1,034 kPa to 1,103 kPa) on gage hooked up to "lockup" port, and no pressure is shown on gage hooked up to "non active" port, replace lockup shift valve (Para 23-12).
- (6) Turn OFF engine switch.
- (7) Remove gages, hose, and adapters from "lockup" and "non active" ports of converter housing.
- (8) Apply thread sealing compound and install plugs in lubrication ports of converter housing. Tighten plugs to 48 to 60 lb-in (5.4 to 6.8 N·m).




9. ENGINE STALLS WHEN TRANSMISSION IS SHIFTED INTO GEAR (CONT).



VERIFY REPAIR

- (1) Operate truck (TM 9-2320-364-10).
 - (a) If engine does not stall when transmission is shifted into gear, fault has been corrected.
 - (b) If engine continues to stall when transmission is shifted into gear, fault not corrected. Notify supervisor.
- (2) Install left rear fender skirt (TM 9-2320-364-20).

**STEERING WHEEL SHOWN
REMOVED FOR
CLARITY**



**ENGINE
SWITCH**

**TRANSMISSION
RANGE
SELECTOR**

2-12. AIR SYSTEM TROUBLESHOOTING.

This paragraph covers Air System Troubleshooting. The Air System Fault Index, Table 2-11, lists faults for the air system of the PLS truck. Refer to schematic Figure 2-1 when performing tests and corrective actions.

Table 2-11. Air System Fault Index

Fault No.	Description	Page
1.	Air Pressure Buildup Is Slow	2-178
2.	Noisy Air Compressor Operation	2-184




Figure 2-1. Air System Diagram.

2-12. AIR SYSTEM TROUBLESHOOTING (CONT).

1. AIR PRESSURE BUILDUP IS SLOW.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)
 Wrench, Combination 1-1/2 in.
 (Item 260, Appendix F)

Materials/Parts


Solution, Soap (Item 67, Appendix B)

References


TM 9-2320-364-20
 TM 9-2320-364-10

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brakes applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)
 Right side noise panel removed,
 (TM 9-2320-364-20)
 Central Tire Inflation System (CTIS) turned off,
 (TM 9-2320-364-10)



STEERING WHEEL
SHOWN REMOVED
FOR CLARITY




ENGINE SWITCH




CYLINDER
HEAD

VISUAL INSPECTION

- (1) Apply soap solution between cylinder head and cylinder block.
- (2) Start engine (TM 9-2320-364-10).
- (3) Inspect compressor for bubbles indicating visible leaks between cylinder head and cylinder block.
 - (a) If compressor does leak, turn OFF ENGINE switch, and replace air compressor (Para 10-4).
 - (b) If compressor does not leak, cylinder head gasket is OK.
- (4) Turn OFF ENGINE switch.



1. AIR PRESSURE BUILDUP IS SLOW (CONT).



WARNING



- During pressure tests, ensure air pressure is drained to 0 psi (0 kPa) before taking off air compressor line or taking off any cover plates. If pressure is not released, plates or line could blow off and harm personnel. Air tanks have greater than 30 psi (207 kPa) in them. Do not drain air tanks with any part of body in air spray path. Skin embolisms and/or debris in eyes can occur from released pressure.
- Allow engine to cool before performing troubleshooting maintenance. If necessary use insulated pads and gloves. Hot engine components will burn and cause injury to personnel.

CAUTION


Be sure line and air gage are clear of fan, or damage to equipment could result.

PRESSURE TEST

- (1) Disconnect air line 2001 from elbow on compressor.
 - (a) If there is oil dripping from line 2001, turn OFF ENGINE switch, and replace air compressor (Para 10-4).
 - (b) If there is no oil dripping from line 2001, go to Step 2 below.
- (2) Remove elbow from air compressor port and install tee in its place.
- (3) Install air line 2001 and pressure gage on tee.
- (4) Start engine and allow pressure to build up (TM 9-2320-364-10).
 - (a) If 125 ± 4 psi (862 ± 28 kPa) are not measured, perform Steps (5) through (7) below, and replace air compressor (Para 10-4).
 - (b) If 125 ± 4 psi (862 ± 28 kPa) are measured, air compressor is OK.
- (5) Turn OFF ENGINE switch.
- (6) Remove pressure gage, air line 2001, and tee from air compressor.
- (7) Install elbow and connect air line 2001 to elbow.




1. AIR PRESSURE BUILDUP IS SLOW (CONT).



VERIFY REPAIR

- (1) Start engine and allow pressure to build up (TM 9-2320-364-10).
- (2) Observe air pressure gage.
 - (a) If air pressure does build up to 125 ± 4 psi (862 ± 28 kPa) in 5 minutes, fault has been corrected. Perform Step (3) below.
 - (b) If air pressure does not build up to 125 ± 4 psi (862 ± 28 kPa) in 5 minutes, fault not corrected. Perform Step (3) below and notify supervisor.
- (3) Install right side noise panel (TM 9-2320-364-20).



2-12. AIR SYSTEM TROUBLESHOOTING (CONT).

2. NOISY AIR COMPRESSOR OPERATION.

INITIAL SETUP

Tools and Special Tools


Tool Kit, General Mechanic's
(Item 240, Appendix F)

References


TM 9-2320-364-20
TM 9-2320-364-10

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
Parking brakes applied, (TM 9-2320-364-10)
Wheels chocked, (TM 9-2320-364-10)
Right side noise panel removed,
(TM 9-2320-364-20)



STEERING WHEEL
SHOWN REMOVED
FOR CLARITY




ENGINE SWITCH


VISUAL INSPECTION

Check air compressor for damage and loose or damaged mounting hardware.

- (1) If compressor is cracked, leaking, or mounting hardware loose or damaged, tighten or replace loose or damaged mounting hardware (Para 10-4).
- (2) If compressor is securely mounted and is not damaged, compressor is OK.



CYLINDER HEAD



CRANKCASE


REAR END COVER

FLANGE


CYLINDER BLOCK

CRANKCASE COVER

2. NOISY AIR COMPRESSOR OPERATION (CONT).




STEERING WHEEL
SHOWN REMOVED
FOR CLARITY




ENGINE SWITCH

VERIFY REPAIR

- (1) Start engine (TM 9-2320-364-10).
- (2) Listen for excessive noise from air compressor.
 - (a) If compressor operation is not excessively noisy, fault has been corrected. Perform Steps (3) and (4) below.
 - (b) If compressor operation is still excessively noisy, fault not corrected. Perform Steps (3) and (4) below and notify supervisor.
- (3) Turn OFF ENGINE switch.
- (4) Install right side noise panel (TM 9-2320-364-20).



CYLINDER
HEAD



2-13. HYDRAULIC SYSTEM TROUBLESHOOTING.

This paragraph covers Hydraulic System Troubleshooting. The Hydraulic System Fault Index, Table 2-12, lists faults for the hydraulic system of the PLS truck. Refer to schematic Figures 2-2 and 2-3 when performing tests and corrective actions.

Table 2-12. Hydraulic System Fault Index

Fault No.	Description	Page
1.	Crane And Winch Operate Slowly	2-192
2.	Fan, LHS, Winch And Crane Do Not Operate Or Operate Slowly	2-196
3.	LHS, Winch And Crane Operate Slowly	2-202
4.	Fan Does Not Operate	2-206
5.	Fan Speed Does Not Decrease From High To Low Speed	2-214
6.	Fan Does Not Operate At High Speed	2-224
7.	Hydraulic System Operation Unusually Noisy	2-240




Figure 2-2. Multifunction Manifold Hydraulic Schematic




Figure 2-3. Multifunction Manifold Wiring Schematic

2-13. HYDRAULIC SYSTEM TROUBLESHOOTING (CONT).

1. CRANE AND WINCH OPERATE SLOWLY.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Materials/Parts

Oil, Hydraulic (Item 34, Appendix B)
 Lockwashers (4) (Item 266, Appendix E)
 Lockwashers (8) (Item 282, Appendix E)
 Parts Kit, Seal (Item 410, Appendix E)


Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)



WARNING

- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.




NOTE

- Use drain pan to catch leaking hydraulic oil.
- Only remove center screw on engine side of LHS control box cover.

VISUAL/AUDIBLE INSPECTION




- (1) Remove eight screws, lockwashers, washers and left side noise panel. Discard lockwashers.
- (2) Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
- (3) Remove shuttle valve C from multifunction manifold.
- (4) Remove and discard three preformed packings and two packing retainers.
- (5) Shake valve and listen for ball to rattle.
 - (a) If ball does not rattle, clean or replace shuttle valve C (Para 17-18).
 - (b) If check ball rattles, shuttle valve is OK.
- (6) Lubricate two preformed packings and packing retainers with hydraulic oil and install on shuttle valve.
- (7) Install shuttle valve C.

1. CRANE AND WINCH OPERATE SLOWLY (CONT).



VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Start engine (TM 9-2320-364-10).
- (3) Operate crane and winch.
 - (a) If crane and winch operate correctly, fault has been corrected. Perform Steps (4) through (6) below.
 - (b) If crane and winch still operate slowly, fault not corrected. Perform Steps (4) through (6) below and notify supervisor.
- (4) Turn OFF ENGINE switch.
- (5) Install LHS control box cover and four lockwashers and screws.
- (6) Install left side noise panel and eight washers, lockwashers and screws.



2-13. HYDRAULIC SYSTEM TROUBLESHOOTING (CONT).

2. FAN, LHS, WINCH AND CRANE DO NOT OPERATE OR OPERATE SLOWLY.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Pan, Drain 4 gal (Item 144, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)

Materials/Parts


- Oil, Hydraulic (Item 34, Appendix B)


References

- TM 9-2320-364-10
- TM 9-2320-364-20

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)






AUDIBLE INSPECTION

- (1) Start engine (TM 9-2320-364-10).
- (2) Open front access cover.
- (3) Listen to main hydraulic pump operation.
 - (a) If pump does not rattle, turn OFF ENGINE switch and go to Step 2 of this Fault.
 - (b) If pump rattles while operating, turn OFF ENGINE switch and replace main hydraulic pump (Para 17-2).

2. FAN, LHS, WINCH AND CRANE DO NOT OPERATE OR OPERATE SLOWLY (CONT).




WARNING


- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

PRESSURE TEST

- (1) Refer to Para 17-5 and check main hydraulic pump output pressure.
 - (a) If 3,675 +75, -50 psi (25,339 +517, -345 kPa) are not present on flowmeter pressure gage when flow drops to 0 gpm (0 lpm), adjust or replace hydraulic pump control (Para 17-5).
 - (b) If 3,675 +75, -50 psi (25,339 +517, -345 kPa) are present, hydraulic pump control is OK.
- (2) Check main hydraulic reservoir oil level and add oil as necessary (TM-9-2320-364-20).




2. FAN, LHS, WINCH AND CRANE DO NOT OPERATE OR OPERATE SLOWLY (CONT).



VERIFY REPAIR

- (1) Start engine (TM 9-2320-364-10).
- (2) Operate LHS, winch and crane and observe operation.
 - (a) If systems above do not operate correctly, fault not corrected. Perform Steps (3) and (4) below and notify supervisor.
 - (b) If systems above operate correctly, fault has been corrected.
- (3) Turn OFF ENGINE switch.
- (4) Turn hydraulic selector switch OFF.

**STEERING WHEEL SHOWN
REMOVED FOR
CLARITY**



2-13. HYDRAULIC SYSTEM TROUBLESHOOTING (CONT).

3. LHS, WINCH AND CRANE OPERATE SLOWLY.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Materials/Parts

Oil, Hydraulic (Item 34, Appendix B)
 Lockwashers (4) (Item 266, Appendix E)
 Lockwashers (8) (Item 282, Appendix E)
 Parts Kit, Seal (Item 411, Appendix E)

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)




WARNING

- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

- Use drain pan to catch leaking hydraulic oil.
- Only remove center screw on engine side of LHS control box cover.


VISUAL/AUDIBLE INSPECTION
(1) Remove eight screws, lockwashers, washers and left side noise panel. Discard lockwashers.
(2) Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
(3) Remove shuttle valve B from multifunction manifold.
(4) Remove and discard three preformed packings and two packing retainers.
(5) Shake valve and listen for ball to rattle. <ul style="list-style-type: none"> (a) If ball does not rattle, clean or replace shuttle valve (Para 17-18). (b) If check ball rattles, shuttle valve is OK.
(6) Lubricate preformed packing with hydraulic oil and install on shuttle valve.
(7) Install shuttle valve B.



3. LHS, WINCH AND CRANE OPERATE SLOWLY (CONT).



STEERING WHEEL SHOWN
REMOVED FOR
CLARITY




ENGINE SWITCH

HYDRAULIC
SELECTOR
SWITCH

VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Start engine (TM 9-2320-364-10).
- (3) Operate crane and winch and observe operation.
 - (a) If crane and winch still operate slowly, fault not corrected. Perform Steps (4) through (7) below and notify supervisor.
 - (b) If crane and winch operate correctly, fault has been corrected.
- (4) Turn OFF ENGINE switch.
- (5) Turn hydraulic selector switch OFF.
- (6) Install LHS control box cover and four lockwashers and screws.
- (7) Install left side noise panel, eight washers, lockwashers and screws.




LOCKWASHER

LHS CONTROL
BOX COVER

WASHER

SCREW



LEFT SIDE
NOISE PANEL

LOCKWASHER

SCREW

2-13. HYDRAULIC SYSTEM TROUBLESHOOTING (CONT).

4. FAN DOES NOT OPERATE.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's (Item 240, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)

Materials/Parts

Oil, Hydraulic (Item 34, Appendix B)
 Lockwashers (4) (Item 266, Appendix E)
 Lockwashers (8) (Item 282, Appendix E)
 Parts Kit, Seal (Item 412, Appendix E)

Personnel Required


Two

References

TM 9-2320-364-10
 TM 9-2320-364-20


Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)



WARNING

- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.




NOTE

- Use drain pan to catch leaking hydraulic oil.
- Only remove center screw on engine side of LHS control box cover.

VISUAL/AUDIBLE INSPECTION	
(1)	Remove eight screws, lockwashers, washers and left side noise panel. Discard lockwashers.
(2)	Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
(3)	Remove shuttle valve B from multifunction manifold.
(4)	Remove and discard three preformed packings and two packing retainers.
(5)	Shake valve and listen for ball to rattle. <ul style="list-style-type: none"> (a) If ball does not rattle, clean or replace shuttle valve B (Para 17-18). (b) If check ball rattles, shuttle valve is OK.
(6)	Lubricate two preformed packings and packing retainers with hydraulic oil and install on shuttle valve.
(7)	Install shuttle valve B.

4. FAN DOES NOT OPERATE (CONT).



WARNING

- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use drain pan to catch leaking hydraulic oil.


VISUAL INSPECTION

- (1) Remove multifunction manifold (Para 17-18).
- (2) Remove plug and orifice from bottom of multifunction manifold.
- (3) Inspect orifice for clogging and dirt.
 - (a) If orifice is clogged or dirty, clean or replace orifice (Para 17-18).
 - (b) If orifice is not clogged or dirty, orifice is OK.
- (4) Install orifice and plug in bottom of multifunction manifold.
- (5) Install multifunction manifold (Para 17-18).


**MULTIFUNCTION
MANIFOLD**

ORIFICE

PLUG



4. FAN DOES NOT OPERATE (CONT).





WARNING

- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use drain pan to catch leaking hydraulic oil.

PRESSURE TEST	
(1)	Disconnect hose 2773 from main hydraulic filter.
(2)	Connect hose 2773 to out port of flow meter.
(3)	Connect a hose between flow meter in port and filter elbow.
(4)	Completely open flow meter load valve.
(5)	Disconnect connector MC59 from EPAC.
(6)	Start engine (TM 9-2320-364-10). Allow engine to run until reaching normal operating temperature 170° to 195°F (77° to 91°C).
(7)	While assistant presses throttle switch, observe flow meter. <ul style="list-style-type: none"> (a) If 12 to 14 gpm (45 to 53 lpm) are not present, perform Steps (8) through (10) below and replace fan motor (Para 5-9). (b) If 12 to 14 gpm (45 to 53 lpm) are present, perform Steps (8) through (10) below and notify supervisor.
(8)	Release throttle switch and turn OFF ENGINE switch.
(9)	Connect connector MC59 to EPAC.
(10)	Remove flow meter and connect hose 2773 to main hydraulic filter output elbow.






4. FAN DOES NOT OPERATE (CONT).



VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Start engine (TM 9-2320-364-10).
- (3) Observe fan operation.
 - (a) If fan does not operate, fault not corrected. Perform Steps (4) through (6) below notify supervisor.
 - (b) If fan operates, fault has been corrected.
- (4) Turn OFF ENGINE switch.
- (5) Install LHS control box cover and four lockwashers and screws.
- (6) Install left side noise panel with eight washers, lockwashers and screws.



2-13. HYDRAULIC SYSTEM TROUBLESHOOTING (CONT).

5. FAN SPEED DOES NOT DECREASE FROM HIGH TO LOW SPEED.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Analyzer Set, STE/ICE-R (Optional) (Item 15, Appendix F)
- Multimeter (Item 140, Appendix F)
- Pan, Drain 4 gal (Item 144, Appendix F)

Personnel Required

Two

References


- TM 9-2320-364-10
- TM 9-2320-364-20
- TM 9-4910-571-12&P

Materials/Parts

- Oil, Hydraulic (Item 34, Appendix B)
- Sealing Compound (Item 62, Appendix B)
- Lockwashers (4) (Item 266, Appendix E)
- Lockwashers (30) (Item 282, Appendix E)
- Parts Kit, Seal (Item 412, Appendix E)
- Parts Kit, Seal (Item 408, Appendix E)

Equipment Condition


- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Coolant temperature at 190°F, (88°C)




AUDIBLE INSPECTION

- (1) Start engine (TM 9-2320-364-10).
- (2) Turn hydraulic selector switch to AUTO.
- (3) Listen for audible slowing down of fan.
 - (a) If fan does not slow down, perform Steps (4) and (5) below and go to Step 3 of this Fault.
 - (b) If fan does slow down, perform Steps (4) and (5) below and go to Step 2 of this Fault.
- (4) Turn hydraulic selector switch OFF.
- (5) Turn OFF ENGINE switch.

**STEERING WHEEL SHOWN
REMOVED FOR
CLARITY**



5. FAN DOES NOT DECREASE FROM HIGH TO LOW SPEED (CONT).




WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

Table 2-13. EPAC Temperature vs Voltage Values


Water Temp. Gage Reading		Voltage Values (vdc)
°F	C°	
170	77	22
175	79	16
185	85	12
190	88	10
202-204	94-96	7.3-7.7



- VOLTAGE TEST**
- (1) Remove 22 screws, lockwashers, washer and access panel. Discard lockwashers.
 - (2) Set multimeter select switch to volts dc.
 - (3) Start engine (TM 9-2320-364-10).
 - (4) Allow engine to warm up to at least 175°F (79°C) and turn OFF ENGINE switch.
 - (5) Disconnect connector MC76 from fan control solenoid valve.
 - (6) Connect positive (+) multimeter lead to wire 1936 at harness connector MC76, terminal A.
 - (7) Connect negative (-) multimeter lead to wire 1935 at harness connector MC76, terminal B.
 - (8) While assistant turns ON ENGINE switch, observe multimeter and check EPAC output voltages versus engine water temperature readings (Table 2-13).
 - (a) If voltage outputs are not correct, perform Steps (9) through (11) below and adjust or replace EPAC (Para 6-12).
 - (b) If voltage outputs are correct, replace fan control solenoid valve (TM 9-2320-364-20).
 - (9) Turn OFF ENGINE switch.
 - (10) Connect connector MC76 to fan control solenoid valve connector.
 - (11) Install inside access panel with 22 washers, lockwashers and screws.



5. FAN DOES NOT DECREASE FROM HIGH TO LOW SPEED (CONT).



WARNING


- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

NOTE


- Use drain pan to catch leaking hydraulic oil.
- Only remove center screw on engine side of LHS control box cover.

VISUAL INSPECTION

- (1) Remove eight screws, lockwashers, washers and left side noise panel. Discard lockwashers.
- (2) Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
- (3) Loosen screw and disconnect solenoid connector.
- (4) Remove nut and solenoid.
- (5) Remove high speed fan lockout solenoid valve from multifunction manifold.
- (6) Remove and discard two preformed packings and packing retainers.
- (7) Push plunger inside valve with a non-metallic probe.
 - (a) If plunger sticks or does not move freely up and down, replace solenoid valve (Para 17-18).
 - (b) If plunger moves freely up and down, solenoid valve is OK.
- (8) Lubricate two preformed packings and packing retainers with hydraulic oil and install on solenoid valve.
- (9) Install high speed fan lockout solenoid valve.
- (10) Install solenoid and nut.
- (11) Connect solenoid connector.
- (12) Tighten connector screw and coat head of connector screw with sealing compound.



5. FAN DOES NOT DECREASE FROM HIGH TO LOW SPEED (CONT).



WARNING


- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Remove high speed fan lockout differential pressure sensing valve from multifunction manifold.
- (2) Remove and discard three preformed packings and four packing retainers.
- (3) Push plunger inside valve with a non-metallic probe.
 - (a) If plunger sticks and does not move freely up and down, replace differential pressure sensing valve (Para 17-18).
 - (b) If plunger moves freely up and down, differential pressure sensing valve is OK.
- (4) Lubricate three preformed packings and four packing retainers with hydraulic oil and install on differential pressure sensing valve.
- (5) Install high speed fan lockout differential pressure sensing valve.




5. FAN DOES NOT DECREASE FROM HIGH TO LOW SPEED (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. 22 to 28 vdc to high speed fan lockout solenoid valve is present. EPAC controller OK. Fan control solenoid valve OK. High speed fan lockout solenoid valve OK. High speed fan lockout differential pressure sensing valve OK.
POSSIBLE PROBLEMS


5.

Does fan lower from high to low speed?



TEST OPTIONS
Verify repair.
REASON FOR QUESTION?
If fan lowers from high to low speed, fault has been corrected. ←



**STEERING WHEEL
SHOWN REMOVED
FOR CLARITY**



**ENGINE
SWITCH**

VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Start engine (TM 9-2320-364-10).
- (3) Listen and observe fan.
 - (a) If fan speed does not lower, fault not corrected. Perform Steps (4) through (6) below and notify supervisor.
 - (b) If fan speed lowers, fault has been corrected.
- (4) Turn OFF ENGINE switch.
- (5) Install LHS control box cover and four lockwashers and screws.
- (6) Install left side noise panel, eight lockwashers and screws.



2-13. HYDRAULIC SYSTEM TROUBLESHOOTING (CONT).

6. FAN DOES NOT OPERATE AT HIGH SPEED.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Analyzer Set, STE/ICE-R (Optional) (Item 15, Appendix F)
- Multimeter (Item 140, Appendix F)
- Pan, Drain 4 gal (Item 144, Appendix F)

Materials/Parts

- Oil, Hydraulic (Item 34, Appendix B)
- Sealing Compound (Item 62, Appendix B)
- Lockwashers (4) (Item 266, Appendix E)
- Lockwashers (8) (Item 282, Appendix E)
- Packing, Preformed (Item 352, Appendix E)
- Parts Kit, Seal (Item 410, Appendix E)

Materials/Parts


- Parts Kit, Seal (Item 411, Appendix E)
- Parts Kit, Seal (Item 412, Appendix E)




References

- TM 9-2320-364-10
- TM 9-2320-364-20
- TM 9-4910-571-12&P

Equipment Condition


- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Coolant temperature at 190°F, (88°C)






FAN OPERATION TEST

- (1) Start engine (TM 9-2320-364-10).
- (2) Disconnect connector MC59 from EPAC and observe fan operation.
 - (a) If fan does not operate at high speed, Turn OFF ENGINE switch and go to Step 2 of this Fault.
 - (b) If fan operates at high speed, turn OFF ENGINE switch and adjust or replace EPAC (Para 6-12).



6. FAN DOES NOT OPERATE AT HIGH SPEED (CONT).



WARNING


- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use drain pan to catch leaking hydraulic oil.

FAN OPERATION TEST

- (1) Disconnect hose 2777 female quick disconnect from LHS control box and listen for change in fan speed.
- (2) Start engine (TM 9-2320-364-10).
 - (a) If fan does not operate at high speed, perform Steps (3) and (4) below and go to Step 5 of this Fault.
 - (b) If fan operates at high speed, perform Steps (3) and (4) below and go to Step 3 of this Fault.
- (3) Turn OFF ENGINE switch.
- (4) Connect hose 2777 to LHS control box.



6. FAN DOES NOT OPERATE AT HIGH SPEED (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.


NOTE

Only remove center screw on engine side of LHS control box cover.

VOLTAGE TEST
(1) Remove eight screws, lockwashers, washers and left side noise panel. Discard lockwashers.
(2) Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
(3) Loosen screw and disconnect solenoid connector.
(4) Set multimeter select switch to volts dc.
(5) Connect positive (+) multimeter lead to solenoid connector, terminal 1.
(6) Connect negative (-) multimeter lead to a known good ground.
(7) Turn ON ENGINE switch (TM 9-2320-364-10).
(a) If 22 to 28 vdc are not present, wire 1734 is OK. Turn OFF ENGINE switch and go to Step 4 of this Fault.
(b) If 22 to 28 vdc are present, turn OFF ENGINE switch and repair wire 1734 (see schematic Fig 2-3) or replace chassis wire harness (Para 6-29).



6. FAN DOES NOT OPERATE AT HIGH SPEED (CONT).



WARNING


- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Adhesive, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

NOTE


Use drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Remove nut and solenoid.
- (2) Remove LHS supply solenoid valve.
- (3) Remove and discard two preformed packings and packing retainers.
- (4) Push plunger inside valve with a non-metallic probe.
 - (a) If plunger sticks or does not move freely up and down, replace solenoid valve (Para 17-18).
 - (b) If plunger moves freely up and down, solenoid valve is OK.
- (5) Lubricate two preformed packings and packing retainers with hydraulic oil and install on solenoid valve.
- (6) Install LHS supply solenoid valve.
- (7) Install solenoid and nut.
- (8) Connect solenoid connector.
- (9) Tighten connector screw and coat head of connector screw with sealing compound.



6. FAN DOES NOT OPERATE AT HIGH SPEED (CONT).




WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

VOLTAGE TEST

- (1) Loosen screw and disconnect solenoid connector from high speed fan lockout solenoid valve.
- (2) Set multimeter select switch to volts dc.
- (3) Connect positive (+) multimeter lead to wire 1733 at connector, terminal 2.
- (4) Connect negative (-) multimeter lead to a known good ground.
- (5) Check to ensure hydraulic selector switch is OFF.
- (6) Turn ON ENGINE switch (TM 9-2320-364-10).
 - (a) If 22 to 28 vdc are not present, wire 1733 is OK. Turn OFF ENGINE switch and go to Step 6 of this Fault.
 - (b) If 22 to 28 vdc are present, turn OFF ENGINE switch and repair wire 1733 (see schematic Fig 2-3) or replace chassis wire harness (Para 6-29).



6. FAN DOES NOT OPERATE AT HIGH SPEED (CONT).



WARNING


- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Adhesive, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

NOTE


Use drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Remove nut and solenoid.
- (2) Remove high speed fan lockout solenoid valve from multifunction manifold.
- (3) Remove and discard two preformed packings and packing retainers.
- (4) Push plunger inside valve with a non-metallic probe.
 - (a) If plunger sticks or does not move freely up and down, replace solenoid valve (Para 17-18).
 - (b) If plunger moves freely up and down, solenoid valve is OK.
- (5) Lubricate two preformed packings and packing retainers with hydraulic oil and install on solenoid valve.
- (6) Install high speed fan lockout solenoid valve.
- (7) Install solenoid and nut.
- (8) Connect solenoid connector.
- (9) Tighten connector screw and coat head of connector screw with sealing compound.



6. FAN DOES NOT OPERATE AT HIGH SPEED (CONT).



WARNING


- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Remove high speed fan lockout differential pressure sensing valve from multifunction manifold.
- (2) Remove and discard three preformed packings and four packing retainers.
- (3) Push plunger inside valve with a non-metallic probe.
 - (a) If plunger sticks and does not move freely up and down, replace differential pressure sensing valve (Para 17-18).
 - (b) If plunger moves freely up and down, differential pressure sensing valve is OK.
- (4) Lubricate three preformed packings and four packing retainers with hydraulic oil and install on valve.
- (5) Install high speed fan lockout differential pressure sensing valve.




NOTE


Use drain pan to catch leaking hydraulic oil.


VISUAL INSPECTION

- (1) Remove low speed fan differential pressure sensing valve from multifunction manifold.
- (2) Remove and discard two packing retainers and five preformed packings.
- (3) Push plunger inside valve with a non-metallic probe.
 - (a) If plunger sticks and does not move freely up and down, replace differential pressure sensing valve (Para 17-18).
 - (b) If plunger moves freely up and down, differential pressure sensing valve is OK.
- (4) Lubricate two packing retainers and five preformed packings and install on valve.
- (5) Install low speed fan differential pressure sensing valve.




6. FAN DOES NOT OPERATE AT HIGH SPEED (CONT).







ENGINE SWITCH



- | VERIFY REPAIR |
|--|
| (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20). |
| (2) Start engine (TM 9-2320-364-10). |
| (3) Inspect fan operation. |
| (a) If fan does not operate at high speed, fault not corrected. Perform Steps (4) through (7) below and notify supervisor. |
| (b) If fan operates at high speed, fault has been corrected. |
| (4) Turn OFF ENGINE switch. |
| (5) Install LHS control box cover, four lockwashers and screws. |
| (6) Install left side noise panel eight washers, lockwashers and screws. |
| (7) Connect connector MC59 to EPAC controller. |



2-13. HYDRAULIC SYSTEM TROUBLESHOOTING (CONT).

7. HYDRAULIC SYSTEM OPERATION UNUSUALLY NOISY.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Pan, Drain 4 Gal (Item 144, Appendix F)

References


TM 9-2320-364-10


Materials/Parts

Oil, Hydraulic (Item 34, Appendix B)
 Lockwashers (4) (Item 266, Appendix E)
 Lockwashers (8) (Item 282, Appendix E)
 Parts Kit, Seal (Item 411, Appendix E)

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)
 Coolant temperature at 190°F, (88°C)





WARNING


- High pressure hydraulics [oil under 3,675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Remove eight screws, lockwashers, washers and left side noise panel. Discard lockwashers.
- (2) Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
- (3) Remove low speed differential pressure sensing valve from multifunction manifold.
- (4) Remove and discard three preformed packings and four packing retainers.
- (5) Push plunger inside valve with a non-metallic probe.
 - (a) If plunger sticks and does not move freely up and down, replace differential pressure sensing valve (Para 17-18).
 - (b) If plunger moves freely up and down, differential pressure sensing valve is OK.
- (6) Lubricate three preformed packings and four packing retainers with hydraulic oil and install on valve.
- (7) Install low speed differential pressure sensing valve.




7. HYDRAULIC SYSTEM OPERATION UNUSUALLY NOISY (CONT).




WARNING

- High pressure hydraulics [oil under 3,675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.




AUDIBLE INSPECTION


- (1) Remove cap from low speed differential pressure sensing valve.
- (2) Start engine, (TM 9-2320-364-10).
- (3) Loosen jam nut.
- (4) Turn adjustable screw one turn clockwise (maximum of four turns).
 - (a) If noise only decreases slightly, valve is not adjusted correctly. Continue adjustment (maximum of four turns) until noise is gone.
 - (b) If noise does not decrease, valve is faulty. Replace valve, (Para 17-18).
- (5) Tighten jam nut.
- (6) Replace cap.
- (7) Shut OFF engine.



7. HYDRAULIC SYSTEM OPERATION UNUSUALLY NOISY (CONT).





**STEERING WHEEL
SHOWN REMOVED
FOR CLARITY**



OPERATIONAL TEST

- (1) Check hydraulic oil level and add oil as necessary, (TM 9-2320-364-10).
- (2) Start engine.
- (3) Operate winch.
 - (a) If hydraulic system operation is unusually noisy, fault not corrected. Perform Step (4), (5) and (6) below and notify supervisor.
 - (b) If hydraulic system operation is normal, fault has been corrected.
- (4) Turn OFF engine switch.
- (5) Install LHS control box cover and four lockwashers and screws.
- (6) Install left side noise panel, eight lockwashers and screws.



2-14. LOAD HANDLING SYSTEM (LHS) TROUBLESHOOTING.

This paragraph covers Load Handling System (LHS) Troubleshooting. The LHS Fault Index, Table 2-14, lists faults for the LHS of the PLS truck. Refer to schematics, Figures 2-4 through 2-6 when performing tests and corrective actions.

Table 2-14. Load Handling System Fault Index

Fault No.	Description	Page
1.	Loss Of Hook Arm Safe Lowering	2-250
2.	Loss Of Middle Frame Safe Lowering	2-264
3.	Hook Arm Does Not Load	2-270
4.	Hook Arm Does Not Unload	2-286
5.	Loss Of Hook Arm Load Holding	2-302
6.	Middle Frame Does Not Load	2-322
7.	Middle Frame Does Not Unload	2-342
8.	Middle Frame Does Not Operate	2-360
9.	LHS Does Not Operate Or Operates Slowly	2-370
10.	Loss Of Middle Frame Load Holding	2-390
11.	LHS Hook Arm Disengages From Flatrack While Unloading	2-410




Figure 2-4. LHS Supply Circuit




Figure 2-5. LHS Hook Arm Circuit




Figure 2-6. LHS Middle Frame Circuit

2-14. LOAD HANDLING SYSTEM (LHS) TROUBLESHOOTING (CONT).

1. LOSS OF HOOK ARM SAFE LOWERING.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Jackstand (2) (Item 132, Appendix F)
 Wooden Block (2) (Appendix C)
 Steel Tube (Appendix C)
 Load (500 lb [227 kg] minimum)

Materials/Parts

Sealing Compound (Item 62, Appendix B)
 Lockwasher (4) (Item 266, Appendix E)
 Packing, Preformed (4) (Item 393, Appendix E)

Personnel Required


Two

References

TM 9-2320-364-10


Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)



WARNING

All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.




NOTE


Only remove center screw on engine side of LHS control box cover.

OPERATION TEST

- (1) Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
- (2) Position LHS hook to rear of truck (TM 9-2320-364-10).
- (3) Attach 500 lb (227 kg) minimum load to hook.
- (4) Raise hook arm approximately half of its travel.
- (5) Push in hook arm safe lowering button.
 - (a) If hook arm does not safe lower, lower load using normal controls, Perform Steps (6) through (9) below and go to Step 5 of this Fault.
 - (b) If hook arm does safe lower, perform Steps (6) through (9) below and go to Step 2 of this Fault.
- (6) Remove load from hook.
- (7) Put LHS in transit position.
- (8) Set hydraulic selector switch to OFF position.
- (9) Turn OFF ENGINE switch.



1. LOSS OF HOOK ARM SAFE LOWERING (CONT).




WARNING

- Do not get under LHS when disconnecting or connecting connectors and hoses. A hydraulic malfunction could cause LHS to lower causing serious injury or death.
- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


CAUTION

Do not scratch surface of cylinder rod. Damage to cylinder seals could result causing cylinder failure.

VISUAL INSPECTION	
(1)	Raise hook arm approximately 24 in. (61 cm) and block into position.
(2)	Turn OFF ENGINE switch (TM 9-2320-364-10).
(3)	Loosen connector screw and disconnect connector from safe lowering solenoid valve in port VA on RH hook arm manifold.
(4)	Remove safe lowering solenoid valve and preformed packings from RH hook arm manifold. Discard preformed packings.
(5)	Attempt to push poppet into valve toward solenoid coil. <ul style="list-style-type: none"> (a) If poppet does not move, replace safe lowering solenoid valve (Para 17-13). Perform Step (14) below and go to Step 4 of this Fault. (b) If poppet moves, perform Steps (6) through (8) below.
(6)	Connect connector to removed safe lowering solenoid valve and tighten connector screw.
(7)	Turn ON ENGINE switch.
(8)	With the aid of an assistant, hold in safe lowering button and observe the poppet valve. <ul style="list-style-type: none"> (a) If poppet does not move, turn OFF ENGINE switch and replace the solenoid coil (Para 17-13). Perform Step (14) below and go to Step 4 of this Fault. (b) If poppet moves, the solenoid coil is OK. Perform Steps (9) through (13) below and go to Step 3 of this Fault.
(9)	Turn OFF ENGINE switch.
(10)	Disconnect connector from removed safe lowering solenoid valves.
(11)	Install safe lowering solenoid valve and preformed packings in port VA on RH hook arm manifold.
(12)	Connect connector to safe lowering solenoid valve.
(13)	Tighten screw and coat head of screw with sealing compound.
(14)	Remove two wooden blocks from hook arm.



1. LOSS OF HOOK ARM SAFE LOWERING (CONT).




WARNING

- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.
- Do not get under LHS when disconnecting or connecting connectors and hoses. A hydraulic malfunction could cause LHS to lower causing serious injury or death.


CAUTION

Do not scratch surface of cylinder rod. Damage to cylinder seals could result causing cylinder failure.

VISUAL INSPECTION
(1) Loosen connector screw and disconnect connector from safe lowering solenoid valve in port VA on LH hook arm manifold.
(2) Remove safe lowering solenoid valve and preformed packing from LH hook arm manifold. Discard preformed packing.
(3) Attempt to push poppet into valve toward solenoid coil. <ul style="list-style-type: none"> (a) If poppet does not move, replace safe lowering solenoid valve (Para 17-13). Perform Step (12) below and go to Step 4 of this Fault. (b) If poppet moves, perform Steps (4) through (6) below.
(4) Connect connector to removed safe lowering solenoid valve and tighten connector screw.
(5) Turn ON ENGINE switch (TM 9-2320-364-10).
(6) With the aid of an assistant, hold in safe lowering button and observe the poppet valve. <ul style="list-style-type: none"> (a) If poppet does not move, turn OFF ENGINE switch and replace the solenoid coil (Para 17-13). Perform Step (12) below and go to Step (4) of this Fault. (b) If poppet moves, fault not corrected. Perform Steps (7) through (12) below and notify supervisor.
(7) Turn OFF ENGINE switch.
(8) Loosen connector screw and disconnect connector from removed safe lowering solenoid valve.
(9) Install safe lowering solenoid valve and preformed packing in port VA on LH hook arm manifold.
(10) Connect connector to safe lowering solenoid valve.
(11) Tighten connector screw and coat head of connector screw with sealing compound.
(12) Remove two wooden blocks from hook arm.






1. LOSS OF HOOK ARM SAFE LOWERING (CONT).




WARNING

All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

- VERIFY REPAIR**
- (1) Position LHS hook to rear of truck and engage hook on steel tube supported by jackstands.
 - (2) Using LHS, lift truck only enough to lift vehicle weight off suspension. Do not lift tires off ground.
 - (3) Push in hook arm safe lowering button.
 - (a) If truck does not settle on its suspension, fault not corrected. Perform Steps (4) through (8) and notify supervisor.
 - (b) If truck settles on its suspension, fault has been corrected.
 - (4) Disengage hook from steel tube.
 - (5) Put LHS in transit position.
 - (6) Set hydraulic selector switch to OFF position (TM 9-2320-364-10).
 - (7) Turn OFF ENGINE switch.
 - (8) Install four screws, lockwashers and LHS control box cover.



1. LOSS OF HOOK ARM SAFE LOWERING (CONT).



WARNING


- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.
- Do not get under LHS when disconnecting or connecting connectors and hoses. A hydraulic malfunction could cause LHS to lower causing serious injury or death.

CAUTION


Do not scratch surface of cylinder rod. Damage to cylinder seals could result causing cylinder failure.

VISUAL INSPECTION

- (1) Raise hook arm approximately 24 in. (61 cm) and block into position (TM 9-2320-364-10).
- (2) Turn OFF ENGINE switch.
- (3) Loosen screw and disconnect connector from safe lowering solenoid valve in port VB on RH hook arm manifold.
- (4) Remove safe lowering solenoid valve and preformed packings from RH hook arm manifold. Discard preformed packings.
- (5) Attempt to push poppet into valve toward solenoid coil.
 - (a) If poppet does not move, replace safe lowering solenoid valve (Para 17-13). Perform Step (14) below and go to Step 7 of this Fault.
 - (b) If poppet moves, perform Steps (6) through (8) below.
- (6) Connect connector to removed safe lowering solenoid valve and tighten connector screw.
- (7) Turn ON ENGINE switch.
- (8) With the aid of an assistant, hold in safe lowering button and observe the poppet valve.
 - (a) If poppet does not move, turn OFF ENGINE switch and replace the solenoid coil (Para 17-13). Perform Step (14) below and go to Step 7 of this Fault.
 - (b) If poppet moves, the solenoid coil is OK. Perform Steps (9) through (13) and go to Step 6 of this Fault.
- (9) Turn OFF ENGINE switch.
- (10) Loosen connector screw and disconnect connector from removed safe lowering solenoid valves.
- (11) Install safe lowering solenoid valve and preformed packings in port VB on RH hook arm manifold.
- (12) Connect connector to safe lowering solenoid valve.
- (13) Tighten screw and coat head of connector screw with sealing compound.
- (14) Remove two wooden blocks from hook arm.



1. LOSS OF HOOK ARM SAFE LOWERING (CONT).



WARNING


- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.
- Do not get under LHS when disconnecting or connecting connectors and hoses. A hydraulic malfunction could cause LHS to lower causing serious injury or death.

CAUTION


Do not scratch surface of cylinder rod. Damage to cylinder seals could result causing cylinder failure.

VISUAL INSPECTION

- (1) Loosen connector screw and disconnect connector from safe lowering solenoid valve in port VB on LH hook arm manifold.
- (2) Remove safe lowering solenoid valve and preformed packing from LH hook arm manifold. Discard preformed packing.
- (3) Attempt to push poppet into valve toward solenoid coil.
 - (a) If poppet does not move, replace safe lowering solenoid valve (Para 17-13). Perform Step (12) below and go to Step 7 of this Fault.
 - (b) If poppet moves, perform Steps (4) through (6) below.
- (4) Connect connector to removed safe lowering solenoid valve and tighten connector screw.
- (5) Turn ON ENGINE switch (TM 9-2320-364-10).
- (6) With the aid of an assistant, hold in safe lowering button and observe the poppet valve.
 - (a) If poppet does not move, turn OFF ENGINE switch and replace the solenoid coil (Para 17-13). Perform Steps (7) through (12) below and go to Step 7 of this Fault.
 - (b) If poppet moves, fault not corrected. Perform Steps (7) through (12) below and notify supervisor.
- (7) Turn OFF ENGINE switch.
- (8) Loosen connector screw and disconnect connector from removed safe lowering solenoid valves.
- (9) Install safe lowering solenoid valve and preformed packing in port VB on LH hook arm manifold.
- (10) Connect connector to safe lowering solenoid valve.
- (11) Tighten connector screw and coat head of connector screw with sealing compound.
- (12) Remove two wooden blocks from hook arm.




1. LOSS OF HOOK ARM SAFE LOWERING (CONT).



WARNING


All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.



VERIFY REPAIR

- (1) Position LHS hook to rear of truck (TM 9-2320-364-10).
- (2) Attach 500 lb (227 kg) minimum load to hook.
- (3) Raise hook arm approximately half of its travel.
- (4) Push in hook arm safe lowering button.
 - (a) If hook arm does not safe lower, fault not corrected. Lower load using normal controls, perform Steps (5) through (10) below and notify supervisor.
 - (b) If hook arm safe lowers, fault has been corrected.
- (5) Disengage load from hook.
- (6) Put LHS in transit position.
- (7) Set hydraulic selector switch to OFF position.
- (9) Turn OFF ENGINE switch.
- (10) Install four screws, lockwashers and LHS control box cover.

**HOOK ARM
SAFE
LOWERING
BUTTON**



2-14. LOAD HANDLING SYSTEM (LHS) TROUBLESHOOTING (CONT).

2. LOSS OF MIDDLE FRAME SAFE LOWERING.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Jackstand (2) (Item 132, Appendix F)
- Wrench, Torque (0-60 N·m) (Item 276, Appendix F)
- Wrench Set, Socket 3/8 in. Drive (Item 273, Appendix F)
- Steel Tube, (Appendix C)

References


TM 9-2320-364-10

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)

Materials/Parts


- Oil, Hydraulics (Item 34, Appendix B)
- Lockwashers (4) (Item 266, Appendix E)
- Packing, Preformed (Item 393, Appendix E)




NOTE

- Ensure manual push button is pushed past free play to engage.
- Only remove center screw on engine side of LHS control box cover.

OPERATION TEST
(1) Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
(2) Push in transit DC valve manual push button (TM 9-2320-364-10). <ul style="list-style-type: none"> (a) If button cannot be pushed in, transit DC valve is faulty. Replace transit DC valve (Para 17-11). (b) If button can be pushed in, transit DC valve is OK.




2. LOSS OF MIDDLE FRAME SAFE LOWERING (CONT).




VISUAL INSPECTION

- (1) Remove LHS main manifold (Para 16-43).
- (2) Remove plug, preformed packing and orifice from main manifold. Discard preformed packing.
- (3) Inspect orifice for contaminants or clogging.
 - (a) If orifice is plugged or damaged, clean or replace orifice and perform Steps (4) through (7) below.
 - (b) If orifice is OK, fault not corrected. Perform Steps (4) through (7) below and notify supervisor.
- (4) Install orifice in main manifold.
- (5) Lubricate preformed packing.
- (6) Install preformed packing on plug and install plug in main manifold. Tighten to 96 lb-in (11 N·m).
- (7) Install LHS main manifold.




2. LOSS OF MIDDLE FRAME SAFE LOWERING (CONT).




WARNING

All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.




STEERING WHEEL
SHOWN REMOVED
FOR CLARITY



- | VERIFY REPAIR | |
|---------------|---|
| (1) | Position LHS hook to rear of truck and engage hook on steel tube supported by jackstands. |
| (2) | Using LHS, lift truck only enough to lift vehicle weight off suspension. Do not lift tires off ground. |
| (3) | Push in middle frame safe lowering button. |
| (a) | If truck does not settle on its suspension, fault not corrected. Perform Steps (4) through (8) below and notify supervisor. |
| (b) | If truck settles on its suspension, fault has been corrected. |
| (4) | Disengage hook from steel tube. |
| (5) | Put LHS in transit position. |
| (6) | Set hydraulic selector switch to OFF position (TM 9-2320-364-10). |
| (7) | Turn OFF ENGINE switch. |
| (8) | Install four screws, lockwashers and LHS control box cover. |

HOOK ARM
SAFE
LOWERING
BUTTON



2-14. LOAD HANDLING SYSTEM (LHS) TROUBLESHOOTING (CONT).

3. HOOK ARM DOES NOT LOAD.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
(Item 240, Appendix F)
Pressure Test Kit (Item 165, Appendix F)

Materials/Parts

Sealing Compound (Item 62, Appendix B)

Personnel Required


Two

References

TM 9-2320-364-10

Equipment Condition




Engine OFF, (TM 9-2320-364-10)
Parking brake applied, (TM 9-2320-364-10)
Wheels chocked, (TM 9-2320-364-10)




NOTE


- Ensure manual push button is pushed past free play to engage.
- Only remove center screw on engine side of LHS control box cover.

OPERATION TEST
(1) Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
(2) Start engine (TM 9-2320-364-10).
(3) Set hydraulic selector switch to MAN HA.
(4) Push in free flow valve manual push button while pushing in DC valve hook arm load manual push button. <ul style="list-style-type: none"> (a) If hook arm loads, perform Steps (5) and (6) below and replace upper DC valve (Para 17-10). (b) If hook arm does not load, DC valve is OK.
(5) Set hydraulic selector switch to OFF position.
(6) Turn OFF ENGINE switch.





3. HOOK ARM DOES NOT LOAD (CONT).





OPERATION TEST

- (1) Start engine (TM 9-2320-364-10).
- (2) Set hydraulic selector switch to MAN HA.
- (3) With the aid of an assistant, attempt to load using cab joystick while pushing in hook arm safe lowering button.
 - (a) If hook arm does not load, perform Steps (4) and (5) below and go to Step 6 of this Fault.
 - (b) If hook arm loads, perform Steps (4) and (5) below and go to Step 3 of this Fault.
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.



3. HOOK ARM DOES NOT LOAD (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. Hook arm unloads. DC valve OK. LH and RH hook arm cylinders OK.
POSSIBLE PROBLEMS
Load control valve faulty.


3.

Does hook arm load with harness connectors disconnected from safe lowering solenoid valves on port VA side of LH and RH hook arm manifolds and safe lowering button pushed in?

WARNING

Read WARNING on Page 2-275





TEST OPTIONS
Operation test.
REASON FOR QUESTION
Safe lowering solenoid valves on port VA side of LH and RH hook arm manifolds only bypass load control valves on port VA side.



WARNING

- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.
- Do not get under LHS when disconnecting or connecting connectors and hoses. A hydraulic malfunction could cause LHS to lower causing serious injury or death.

OPERATION TEST	
(1)	Raise hook arm approximately 24 in. (61 cm) (TM 9-2320-364-10).
(2)	Loosen connector screw and disconnect connector from safe lowering solenoid valve on port VA side of LH hook arm manifold.
(3)	Loosen connector screw and disconnect connector from safe lowering solenoid valve on port VA side of RH hook arm manifold.
(4)	Set hydraulic selector switch to MAN HA.
(5)	With the aid of an assistant, attempt to load using cab joystick while pushing in hook arm safe lowering button. <ul style="list-style-type: none"> (a) If hook arm does not load, perform Steps (6) and (7) below and go to Step 5 of this Fault. (b) If hook arm loads, perform Steps (6) through (9) below and go to Step 4 of this Fault.
(6)	Set hydraulic selector switch to OFF position.
(7)	Turn OFF ENGINE switch.
(8)	Connect connector to safe lowering solenoid valve on LH hook arm manifold.
(9)	Tighten connector screw and coat head of connector screw with sealing compound.




3. HOOK ARM DOES NOT LOAD (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. Hook arm unloads. DC valve OK. LH and RH hook arm cylinders OK.
POSSIBLE PROBLEMS
Load control valve faulty.

4.

Does hook arm load with harness connector disconnected from safe lowering solenoid valve on port VB side of RH hook arm manifold and safe lowering button pushed in?




TEST OPTIONS
Operation test.
REASON FOR QUESTION
Safe lowering solenoid valves at port VB of LH and RH hook arm manifolds only bypass load control valves on port VB side.




WARNING

Do not get under LHS when disconnecting or connecting connectors and hoses. A hydraulic malfunction could cause LHS to lower causing serious injury or death.

- OPERATION TEST**
- (1) Raise hook arm approximately 24 in. (61 cm) (TM 9-2320-364-10).
 - (2) Loosen connector screw and disconnect connector from safe lowering solenoid valve on port VB side of RH hook arm manifold.
 - (3) Set hydraulic selector switch to MAN HA.
 - (4) With the aid of an assistant, attempt to load using cab joystick while pushing in hook arm safe lowering button.
 - (a) If hook arm does not load, perform Steps (5) and (6) below and repair RH hook arm manifold at port VB (Para 17-13).
 - (b) If hook arm loads, perform Steps (5) and (6) below and repair LH hook arm manifold at port VB (Para 17-13).
 - (5) Turn OFF ENGINE switch.
 - (6) Set hydraulic selector switch to OFF position.







3. HOOK ARM DOES NOT LOAD (CONT).




WARNING

Do not get under LHS when disconnecting or connecting connectors and hoses. A hydraulic malfunction could cause LHS to lower causing serious injury or death.

- | OPERATION TEST | |
|----------------|---|
| (1) | Connect connector on safe lowering solenoid valve on port VA side of LH hook arm manifold. |
| (2) | Turn ON ENGINE switch (TM 9-2320-364-10). |
| (3) | Set hydraulic selector switch to MAN HA. |
| (4) | With the aid of an assistant, attempt to load using cab joystick while pushing in hook arm safe lowering button. <ul style="list-style-type: none"> (a) If hook arm does not load, perform Steps (5) and (6) below and repair RH hook arm manifold at port VA (Para 17-13). (b) If hook arm loads, perform Steps (5) and (6) below and repair LH hook arm manifold at port VA (Para 17-13). |
| (5) | Set hydraulic selector switch to OFF position. |
| (6) | Turn OFF ENGINE switch. |




3. HOOK ARM DOES NOT LOAD (CONT).



WARNING



- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Do not get under LHS when disconnecting or connecting connectors and hoses. A hydraulic malfunction could cause LHS to lower causing serious injury or death.




FLOWMETER TEST

- (1) Put LHS in transit position (TM 9-2320-364-10).
- (2) Turn OFF ENGINE switch.
- (3) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (4) Disconnect hose 2891 from middle frame bulkhead.
- (5) Connect adapter hose to hose 2891.
- (6) Connect adapter hose to middle frame bulkhead.
- (7) Connect flowmeter IN port to adapter hose connected to hose 2891.
- (8) Connect flowmeter OUT port to adapter hose connected to middle frame bulkhead.
- (9) Completely open flowmeter load valve.
- (10) Connect hose 2917 quick disconnect.
- (11) Start engine.
- (12) Set hydraulic selector switch to MAN HA position.
- (13) With the aid of an assistant, observe flowmeter while holding joystick in LOAD position.
 - (a) If more than 0 gpm (0 lpm) are present, perform Steps (14) through (21) below and replace LH cylinder (Para 17-12).
 - (b) If 0 gpm (0 lpm) are present, fault not corrected. Perform Steps (14) through (21) below and to to Step 7 of this Fault.
- (14) Set hydraulic selector switch to OFF position.
- (15) Turn OFF ENGINE switch.
- (16) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (17) Disconnect flowmeter from two adapter hoses.
- (18) Disconnect adapter hose from middle frame bulkhead.
- (19) Disconnect adapter hose from hose 2891.
- (20) Connect hose 2891 to middle frame bulkhead.
- (21) Connect quick disconnect hose 2917.

STEERING WHEEL SHOWN REMOVED FOR CLARITY




3. HOOK ARM DOES NOT LOAD (CONT).






WARNING

- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Do not get under LHS when disconnecting or connecting connectors and hoses. A hydraulic malfunction could cause LHS to lower causing serious injury or death.




STEERING WHEEL SHOWN REMOVED FOR CLARITY




FLOWMETER TEST	
(1)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(2)	Disconnect hose 2882 from middle frame bulkhead.
(3)	Connect adapter hose to hose 2882.
(4)	Connect adapter hose to middle frame bulkhead.
(5)	Connect flowmeter IN port to adapter hose connected to hose 2882.
(6)	Connect flowmeter OUT port to adapter hose connected to middle frame bulkhead.
(7)	Completely open flowmeter load valve.
(8)	Connect quick disconnects.
(9)	Start engine (TM 9-2320-364-10).
(10)	Set hydraulic selector switch to MAN HA position.
(11)	With the aid of an assistant, observe flowmeter while holding joystick in LOAD position. <ul style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are present, perform Steps (12) through (19) below and replace RH cylinder (Para 17-12). (b) If 0 gpm (0 lpm) are present, fault not corrected. Perform Steps (12) through (19) below and notify supervisor.
(12)	Set hydraulic selector switch to OFF position.
(13)	Turn OFF ENGINE switch.
(14)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(15)	Disconnect flowmeter from two adapter hoses.
(16)	Disconnect adapter hose from middle frame bulkhead.
(17)	Disconnect adapter hose from hose 2882.
(18)	Connect hose 2882 to middle frame bulkhead.
(19)	Connect quick disconnect hose 2917.

3. HOOK ARM DOES NOT LOAD (CONT).




VERIFY REPAIR

- (1) Start engine (TM 9-2320-364-10).
- (2) Set hydraulic selector switch to AUTO position.
- (3) Hold joystick in LOAD position.
 - (a) If hook arm does not load, fault not corrected. Perform Steps (4) through (6) below and notify supervisor.
 - (b) If hook arm loads, fault has been corrected.
- (4) Place LHS in the transit position.
- (5) Set hydraulic selector switch to OFF position.
- (6) Turn OFF ENGINE switch.



**STEERING WHEEL
SHOWN REMOVED
FOR CLARITY**



2-14. LOAD HANDLING SYSTEM (LHS) TROUBLESHOOTING (CONT).

4. HOOK ARM DOES NOT UNLOAD.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
(Item 240, Appendix F)
Pressure Test Kit (Item 165, Appendix F)

Materials/Parts

Sealing Compound (Item 62, Appendix B)
Lockwasher (4) (Item 266, Appendix E)

Personnel Required


Two

References

TM 9-2320-364-10


Equipment Condition

Engine OFF, (TM 9-2320-364-10)
Parking brake applied, (TM 9-2320-364-10)
Wheels chocked, (TM 9-2320-364-10)



LHS CONTROL
BOX COVER

HOOK ARM



SCREW

LOCKWASHER

FREE FLOW
VALVE MANUAL
PUSH BUTTON

HOOK ARM
UNLOAD MANUAL
PUSH BUTTON

STEERING WHEEL
SHOWN
REMOVED
FOR CLARITY

HYDRAULIC
SELECTOR
SWITCH


ENGINE SWITCH

NOTE


- Ensure manual push button is pushed past free play to engage.
- Only remove center screw on engine side of LHS control box cover.


OPERATION TEST

- (1) Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
- (2) Start engine (TM 9-2320-364-10).
- (3) Set hydraulic selector switch to MAN HA.
- (4) Push in free flow valve manual push button while pushing in DC valve hook arm unload manual push button.
 - (a) If hook arm does not unload, DC valve is OK. Perform Steps (5) and (6) below and go to Step 2 of this Fault.
 - (b) If hook arm unloads, perform Steps (5) and (6) below and replace upper DC valve (Para 17-10).
- (5) Set hydraulic selector switch to OFF position.
- (6) Turn OFF ENGINE switch.



4. HOOK ARM DOES NOT UNLOAD (CONT).








OPERATION TEST

With the aid of an assistant, attempt to unload using cab joystick while pushing in hook arm safe lowering button (TM 9-2320-364-10).

- (1) If hook arm does not unload, go to Step 6 of this Fault.
- (2) If hook arm unloads, go to Step 3 of this Fault.



4. HOOK ARM DOES NOT UNLOAD (CONT).






WARNING


- Do not get under LHS when disconnecting or connecting connectors or hoses. A hydraulic malfunction could cause LHS to lower causing serious injury or death.
- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

OPERATION TEST

- (1) With the aid of an assistant, raise hook arm approximately 24 in. (61 cm) while holding in hook arm safe lowering button (TM 9-2320-364-10).
- (2) Loosen connector screw and disconnect connector from safe lowering solenoid valve on port VA side of LH hook arm manifold.
- (3) Loosen connector screw and disconnect connector from safe lowering solenoid valve on port VA side of RH hook arm manifold.
- (4) Set hydraulic selector switch to MAN HA.
- (5) With the aid of an assistant, attempt to unload using cab joystick while pushing in hook arm safe lowering button.
 - (a) If hook arm does not unload, perform Steps (6) through (9) below and go to Step 5 of this Fault.
 - (b) If hook arm unloads, perform Steps (6) through (9) below and go to Step 4 of this Fault.
- (6) Set hydraulic selector switch to OFF position.
- (7) Turn OFF ENGINE switch.
- (8) Connect connector to safe lowering solenoid valve on LH hook arm manifold.
- (9) Tighten connector screw and coat head of connector screw with sealing compound.






4. HOOK ARM DOES NOT UNLOAD (CONT).




WARNING

- Do not get under LHS when disconnecting or connecting connectors or hoses. A hydraulic malfunction could cause LHS to lower causing serious injury or death.
- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

OPERATION TEST	
(1)	With the aid of an assistant, raise hook arm approximately 24 in. (61 cm) while holding in hook arm safe lowering button (TM 9-2320-364-10).
(2)	Set hydraulic selector switch to MAN HA.
(3)	Loosen connector screw and disconnect connector from safe lowering solenoid valve on port VB side of RH hook arm manifold.
(4)	With the aid of an assistant, attempt to unload using cab joystick while pushing in hook arm safe lowering button.
(a)	If hook arm does not unload, load control valve is faulty. Perform Steps (5) through (8) below and repair RH hook arm manifold at port VB (Para 17-13).
(b)	If hook arm unloads, load control valve is faulty. Perform Steps (5) through (8) below and repair LH hook arm manifold at port VB (Para 17-13).
(5)	Connect connector to safe lowering solenoid valve on port VB side of RH hook arm manifold.
(6)	Tighten connector screw and coat head of connector screw with sealing compound.
(7)	Set hydraulic selector switch to OFF position.
(8)	Turn OFF ENGINE switch.






4. HOOK ARM DOES NOT UNLOAD (CONT).




WARNING

- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.
- Do not get under LHS when disconnecting or connecting connectors or hoses. A hydraulic malfunction could cause LHS to lower causing serious injury.

OPERATION TEST	
(1)	Loosen connector screw and disconnect connector from safe lowering solenoid valve on port VA side of RH hook arm manifold.
(2)	With the aid of an assistant, attempt to unload using cab joystick while pushing in hook arm safe lowering button (TM 9-2320-364-10). <ul style="list-style-type: none"> (a) If hook arm does not unload, load control valve is faulty. Perform Steps (3) through (6) below and repair RH hook arm manifold at port VA (Para 17-13). (b) If hook arm unloads, load control valve is faulty. Perform Steps (3) through (6) below and repair LH hook arm manifold at port VA (Para 17-13).
(3)	Connect connector to safe lowering solenoid valve on port VA side of RH hook arm manifold.
(4)	Tighten connector screw and coat head of connector screw with sealing compound.
(5)	Set hydraulic selector switch to OFF position.
(6)	Turn OFF ENGINE switch.







4. HOOK ARM DOES NOT UNLOAD (CONT).




WARNING

- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Do not get under LHS when disconnecting or connecting connectors or hoses. A hydraulic malfunction could cause LHS to lower causing serious injury.

FLOWMETER TEST	
(1)	Raise hook arm completely (TM 9-2320-364-10).
(2)	Set hydraulic selector switch to OFF position.
(3)	Turn OFF ENGINE switch.
(4)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(5)	Disconnect hose 2881 from middle frame bulkhead.
(6)	Connect adapter hose to hose 2881.
(7)	Connect adapter hose to middle frame bulkhead.
(8)	Connect flowmeter IN port to adapter hose connected to hose 2881.
(9)	Connect flowmeter OUT port to adapter hose connected to middle frame bulkhead.
(10)	Completely open flowmeter load valve.
(11)	Connect quick disconnect hose 2917.
(12)	Start engine (TM 9-2320-364-10).
(13)	Set hydraulic selector switch to MAN HA position.
(14)	With the aid of an assistant, observe flowmeter while holding joystick in UNLOAD position. <ul style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are present, perform Steps (15) through (22) below and replace LH cylinder (Para 17-12). (b) If 0 gpm (0 lpm) are present, cylinder is OK.
(15)	Set hydraulic selector switch to OFF position.
(16)	Turn OFF ENGINE switch.
(17)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(18)	Disconnect flowmeter from two adapter hoses.
(19)	Disconnect adapter hose from middle frame bulkhead.
(20)	Disconnect adapter hose from hose 2881.
(21)	Connect hose 2881 to middle frame bulkhead.
(22)	Connect quick disconnect hose 2917.







4. HOOK ARM DOES NOT UNLOAD (CONT).




WARNING

- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Do not get under LHS when disconnecting or connecting connectors or hoses. A hydraulic malfunction could cause LHS to lower causing serious injury.




FLOWMETER TEST	
(1)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(2)	Disconnect hose 2892 from middle frame bulkhead.
(3)	Connect adapter hose to hose 2892.
(4)	Connect adapter hose to middle frame bulkhead.
(5)	Connect flowmeter IN port to adapter hose connected to hose 2892.
(6)	Connect flowmeter OUT port to adapter hose connected to middle frame bulkhead.
(7)	Completely open flowmeter load valve.
(8)	Connect quick disconnect hose 2917.
(9)	Start engine (TM 9-2320-364-10).
(10)	Set hydraulic selector switch to MAN HA position.
(11)	With the aid of an assistant, observe flowmeter while holding joystick in UNLOAD position. <ul style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are present, perform Steps (12) through (19) below and replace RH cylinder (Para 17-12). (b) If 0 gpm (0 lpm) are present, cylinder is OK.
(12)	Set hydraulic selector switch to OFF position.
(13)	Turn OFF ENGINE switch.
(14)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(15)	Disconnect flowmeter from two adapter hoses.
(16)	Disconnect adapter hose from middle frame bulkhead.
(17)	Disconnect adapter hose from hose 2892.
(18)	Connect hose 2892 to middle frame bulkhead.
(19)	Connect quick disconnect hose 2917.

4. HOOK ARM DOES NOT UNLOAD (CONT).




VERIFY REPAIR

- (1) Start engine (TM 9-2320-364-10).
- (2) Set hydraulic selector switch to AUTO position.
- (3) Hold joystick in UNLOAD position.
 - (a) If hook arm does not unload, fault not corrected. Perform Steps (4) through (6) below and notify supervisor.
 - (b) If hook arm unloads, fault has been corrected.
- (4) Put LHS in transit position.
- (5) Set hydraulic selector switch to OFF position.
- (6) Turn OFF ENGINE switch.



**STEERING WHEEL
SHOWN REMOVED
FOR CLARITY**



2-14. LOAD HANDLING SYSTEM (LHS) TROUBLESHOOTING (CONT).

5. LOSS OF HOOK ARM LOAD HOLDING.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Cap and Plug Set (Item 34, Appendix F)
 Jackstand (2) (Item 132, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)
 Steel Tube (Appendix C)
 Load (500 lb [227 kg] minimum)

Personnel Required

Two

References


TM 9-2320-364-10

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)

Materials/Parts

Oil, Hydraulic (Item 34, Appendix B)




WARNING


All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

OPERATION TEST

- (1) Position LHS hook to rear of truck and engage hook on steel tube supported by jackstands.
- (2) Using LHS, lift truck only enough to lift vehicle weight off suspension. Do not lift tires off ground.
 - (a) If hook arm does not hold weight off vehicle suspension, lower truck and perform Steps (4) and (5) below and go to Step 6 of this Fault.
 - (b) If hook arm does hold weight off vehicle suspension, perform Steps (3) through (5) below and go to Step 2 of this Fault.
- (3) Disengage hook from steel tube.
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.



5. LOSS OF HOOK ARM LOAD HOLDING (CONT).



WARNING


- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.
- Do not get under LHS when disconnecting or connecting connectors or hoses. A hydraulic malfunction could cause LHS to lower causing serious injury.

NOTE


Use drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Attach 500 lb (227 kg) minimum load to hook.
- (2) Raise hook arm approximately half of its travel (TM 9-2320-364-10).
- (3) Set hydraulic selector switch to OFF position.
- (4) Turn OFF ENGINE switch.
- (5) Disconnect hose 2881 from LH hook arm manifold, port VB. Plug hose.
- (6) Disconnect hose 2892 from RH hook arm manifold, port VB. Plug hose.
- (6) Allow one to two minutes to pass to allow excess oil laying in manifold to drain out.
 - (a) If hydraulic fluid stops draining from hook arm manifolds, load control valves are OK. Perform Steps (7) through (13) below and go to Step 3 of this Fault.
 - (b) If hydraulic fluid continues to drain from LH or RH hook arm manifold at port VB, remove plug from hose and connect hose to hook arm manifold that does not leak. Replace load control valve at leaking port VB (Para 17-13).
- (7) Remove plugs from hoses 2881 and 2892.
- (8) Connect hose 2881 to LH hook arm manifold, port VB and hose 2892 to RH hook arm manifold, port VB.
- (9) Turn ON ENGINE switch.
- (10) Set hydraulic selector switch to MAN HA position.
- (11) Disengage LHS hook arm from load.
- (12) Set hydraulic selector switch to OFF position.
- (13) Turn OFF ENGINE switch.




5. LOSS OF HOOK ARM LOAD HOLDING (CONT).



WARNING


- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Do not get under LHS when disconnecting or connecting connectors or hoses. A hydraulic malfunction could cause LHS to lower causing serious injury.




STEERING WHEEL SHOWN REMOVED FOR CLARITY

QUICK DISCONNECTS


HOSE 2917



FLOWMETER TEST	
(1)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(2)	Disconnect hose 2891 from middle frame bulkhead.
(3)	Connect adapter hose to hose 2891.
(4)	Connect adapter hose to middle frame bulkhead.
(5)	Connect flowmeter IN port to adapter hose connected to hose 2891.
(6)	Connect flowmeter OUT port to adapter hose connected to middle frame bulkhead.
(7)	Completely open flowmeter load valve.
(8)	Connect quick disconnect hose 2917.
(9)	Start engine (TM 9-2320-364-10).
(10)	Set hydraulic selector switch to MAN HA position.
(11)	With the aid of an assistant, observe flowmeter while holding joystick in LOAD position. <ul style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are present, perform Steps (12) through (19) below and replace LH hook arm cylinder (Para 17-12). (b) If 0 gpm (0 lpm) are present, cylinder is OK.
(12)	Set hydraulic selector switch to OFF position.
(13)	Turn OFF ENGINE switch.
(14)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(15)	Disconnect flowmeter from two adapter hoses.
(16)	Disconnect adapter hose from middle frame bulkhead.
(17)	Disconnect adapter hose from hose 2891.
(18)	Connect hose 2891 to middle frame bulkhead.
(19)	Connect quick disconnect hose 2917.




5. LOSS OF HOOK ARM LOAD HOLDING (CONT).





WARNING

- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Do not get under LHS when disconnecting or connecting connectors or hoses. A hydraulic malfunction could cause LHS to lower causing serious injury.




STEERING WHEEL SHOWN REMOVED FOR CLARITY



FLOWMETER TEST	
(1)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(2)	Disconnect hose 2882 from middle frame bulkhead.
(3)	Connect adapter hose to hose 2882.
(4)	Connect adapter hose to middle frame bulkhead.
(5)	Connect flowmeter IN port to adapter hose connected to hose 2882.
(6)	Connect flowmeter OUT port to adapter hose connected to middle frame bulkhead.
(7)	Completely open flowmeter load valve.
(8)	Connect quick disconnect hose 2917.
(9)	Start engine (TM 9-2320-364-10).
(10)	Set hydraulic selector switch to MAN HA position.
(11)	With the aid of an assistant, observe flowmeter while holding joystick in LOAD position. <ul style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are present, perform Steps (12) through (20) below and replace RH hook arm cylinder (Para 17-12). (b) If 0 gpm (0 lpm) are present, cylinder is OK. Perform Steps (12) through (20) below and go to Step 7 of this Fault.
(12)	Set hydraulic selector switch to OFF position.
(13)	Turn OFF ENGINE switch.
(14)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(15)	Disconnect flowmeter from two adapter hoses.
(16)	Disconnect adapter hose from middle frame bulkhead.
(18)	Disconnect adapter hose from hose 2882.
(19)	Connect hose 2882 to middle frame bulkhead.
(20)	Connect quick disconnect hose 2917.

5. LOSS OF HOOK ARM LOAD HOLDING (CONT).




WARNING


All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

VERIFY REPAIR

- (1) Attach 500 lb (227 kg) minimum load to hook.
- (2) Raise hook arm approximately half of its travel (TM 9-2320-364-10).
- (3) Turn OFF ENGINE switch.
 - (a) If hook arm does not hold load, fault not corrected. Lower load using normal controls, perform Steps (4) through (7) below and notify supervisor.
 - (b) If hook arm holds load, fault has been corrected.
- (4) Disengage LHS hook arm from load.
- (5) Put LHS in transit position.
- (6) Set hydraulic selector switch to OFF position.
- (7) Turn OFF ENGINE switch.



5. LOSS OF HOOK ARM LOAD HOLDING (CONT).






WARNING


- All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.
- Do not get under LHS when disconnecting or connecting connectors or hoses. A hydraulic malfunction could cause LHS to lower causing serious injury.

VISUAL INSPECTION

- (1) Using LHS, lift truck only enough to lift vehicle weight off suspension. Do not lift tires off ground (TM 9-2320-364-10).
- (2) Set hydraulic selector switch to OFF position.
- (3) Turn OFF ENGINE switch.
- (4) Disconnect hose 2891 from LH hook arm manifold, port VA. Plug hose.
- (5) Disconnect hose 2882 from RH hook arm manifold, port VA. Plug hose.
 - (a) If no fluid leaks from LH or RH hook arm manifold at port VA, load control valves are OK. Perform Steps (6) through (8) below and go to Step 7 of this Fault.
 - (b) If fluid leaks from LH or RH hook arm manifold where hose is removed, remove plug from hose and connect hose to hook arm manifold that does not leak. replace load control valve at leaking port VA (Para 17-13).
- (6) Remove plugs from hoses 2891 and 2882.
- (7) Connect hose 2891 to LH hook arm manifold, port VA.
- (8) Connect hose 2882 to RH hook arm manifold, port VA.







5. LOSS OF HOOK ARM LOAD HOLDING (CONT).



WARNING

- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Do not get under LHS when disconnecting or connecting connectors or hoses. A hydraulic malfunction could cause LHS to lower causing serious injury.

FLOWMETER TEST
<ol style="list-style-type: none"> (1) Disengage hook from steel tube. (2) Raise hook arm completely (TM 9-2320-364-10) (3) Set hydraulic selector switch to OFF position. (4) Turn OFF ENGINE switch. (5) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect. (6) Disconnect hose 2881 from middle frame bulkhead. (7) Connect adapter hose to hose 2881. <p style="text-align: center;"><i>Continued on next page.</i></p>



5. LOSS OF HOOK ARM LOAD HOLDING (CONT).





WARNING

- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Do not get under LHS when disconnecting or connecting connectors or hoses. A hydraulic malfunction could cause LHS to lower causing serious injury.

FLOWMETER TEST (CONT).

- (8) Connect adapter hose to middle frame bulkhead.
- (9) Connect flowmeter IN port to adapter hose connected to hose 2881.
- (10) Connect flowmeter OUT port to adapter hose connected to middle frame bulkhead.
- (11) Completely open flowmeter load valve.
- (12) Connect quick disconnect hose 2917.
- (13) Start engine.
- (14) Set hydraulic selector switch to MAN HA position.





Continued on next page.




WARNING

- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Do not get under LHS when disconnecting or connecting connectors or hoses. A hydraulic malfunction could cause LHS to lower causing serious injury.

FLOWMETER TEST (CONT).	
(15)	With the aid of an assistant, observe flowmeter while holding joystick in UNLOAD position.
(a)	If more than 0 gpm (0 lpm) are present, perform Steps (16) through (23) below and replace LH hook arm cylinder (Para 17-12).
(b)	If 0 gpm (0 lpm) are present, cylinder is OK.
(16)	Set hydraulic selector switch to OFF position.
(17)	Turn OFF ENGINE switch.
(18)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(19)	Disconnect flowmeter from two adapter hoses.
(20)	Disconnect adapter hose from middle frame bulkhead.
(21)	Disconnect adapter hose from hose 2881.
(22)	Connect hose 2881 to middle frame bulkhead.
(23)	Connect quick disconnect hose 2917.







5. LOSS OF HOOK ARM LOAD HOLDING (CONT).




WARNING

- High pressure hydraulics [oil under 3675 psi (25,339 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Do not get under LHS when disconnecting or connecting connectors or hoses. A hydraulic malfunction could cause LHS to lower causing serious injury.



FLOWMETER TEST	
(1)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(2)	Disconnect hose 2892 from middle frame bulkhead.
(3)	Connect adapter hose to hose 2892.
(4)	Connect adapter hose to middle frame bulkhead.
(5)	Connect flowmeter IN port to adapter hose connected to hose 2892.
(6)	Connect flowmeter OUT port to adapter hose connected to middle frame bulkhead.
(7)	Completely open flowmeter load valve.
(8)	Connect quick disconnect hose 2917.
(9)	Start engine (TM 9-2320-364-10).
(10)	Set hydraulic selector switch to MAN HA position.
(11)	With the aid of an assistant, observe flowmeter while holding joystick in UNLOAD position. <ul style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are present, perform Steps (12) through (19) below and replace RH hook arm cylinder (Para 17-12). (b) If 0 gpm (0 lpm) are present, cylinder is OK.
(12)	Set hydraulic selector switch to OFF position.
(13)	Turn OFF ENGINE switch.
(14)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(15)	Disconnect flowmeter from two adapter hoses.
(16)	Disconnect adapter hose from middle frame bulkhead.
(17)	Disconnect adapter hose from hose 2892.
(18)	Connect hose 2892 to middle frame bulkhead.
(19)	Connect quick disconnect hose 2917.

5. LOSS OF HOOK ARM LOAD HOLDING (CONT).




WARNING

All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

VERIFY REPAIR

- (1) Position LHS hook to rear of truck and engage hook on steel tube supported by jackstands.
- (2) Using LHS, lift truck only enough to lift vehicle weight off suspension. Do not lift tires off ground.
- (3) Turn OFF ENGINE switch (TM 9-2320-364-10).
 - (a) If hook arm does not hold weight off vehicle suspension, fault not corrected. Perform Steps (4) through (7) below and notify supervisor.
 - (b) If hook arm holds weight off vehicle suspension, fault has been corrected.
- (4) Disengage hook from steel tube.
- (5) Put LHS in transit position.
- (6) Set hydraulic selector switch to OFF position.
- (7) Turn OFF ENGINE switch.
- (8) Check main hydraulic oil level and add oil as necessary (TM 9-2320-364-20).



2-14. LOAD HANDLING SYSTEM (LHS) TROUBLESHOOTING (CONT).

6. MIDDLE FRAME DOES NOT LOAD.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Cap and Plug Set (Item 34, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)
 Wrench Set, Socket 3/8 in. Drive
 (Item 273, Appendix F)
 Wrench, Torque (0-60 N·m)
 (Item 276, Appendix F)

Materials/Parts

Oil, Hydraulic (Item 34, Appendix B)
 Tags, Identification (Item 72, Appendix B)
 Lockwashers (4) (Item 266, Appendix E)
 Parts Kit, Seal (Item 408, Appendix E)

Personnel Required


Two


References

TM 9-2320-364-10

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)







NOTE

- Ensure button is pushed past free play to engage.
- Only remove center screw on engine side of LHS control box cover.


OPERATION TEST
(1) Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
(2) Start engine (TM 9-2320-364-10).
(3) Set hydraulic selector switch to MAN MF.
(4) Push in free flow valve manual push button while pushing in directional control valve middle frame down manual push button. <ul style="list-style-type: none"> (a) If middle frame does not load, perform Steps (5) through (7) below and go to Step 2 of this Fault. (b) If hook arm loads, perform Steps (5) and (6) below and replace middle frame down directional control valve (Para 17-10).
(5) Set hydraulic selector switch to OFF position.
(6) Turn OFF ENGINE switch.
(7) Install LHS control box cover, four lockwashers and screws.



STEERING WHEEL SHOWN REMOVED FOR CLARITY



6. MIDDLE FRAME DOES NOT LOAD (CONT).






WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


PRESSURE TEST

- (1) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (2) Remove plug from main manifold, port TPMA.
- (3) Remove preformed packing and backup ring from plug. Discard preformed packing and backup ring.
- (4) Connect pressure gage to main manifold, port TPMA.
- (5) Tag, mark and disconnect hoses 2888, 2887, 2588, 2666, 2889 and 2890 from six compression frame bulkhead fittings.
- (6) Cap and plug six hoses and six bulkhead fittings using metal caps and plugs.
- (7) Connect quick disconnect hose 2917.

Continued on next page.



LH SIDE







6. MIDDLE FRAME DOES NOT LOAD (CONT).

WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.





PRESSURE TEST (CONT).	
(8)	Start engine (TM 9-2320-364-10).
(9)	Raise hook arm approximately 24 in. (61 cm).
(10)	Set hydraulic selector switch to MAN MF.
(11)	With the aid of an assistant, observe pressure gage while holding joystick in LOAD position.
(a)	If more than 3675 psi (25,339 kPa) are not present, perform Steps (12) through (21) below and replace LH (outboard) main cylinder manifold load control valve (Para 17-6).
(b)	If 3675 psi (25,339 kPa) or more are present, load control valve is OK.
(12)	Put LHS in transit position. Continued on next page.




WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

PRESSURE TEST (CONT.)	
(13)	Set hydraulic selector switch to OFF position.
(14)	Turn OFF ENGINE switch.
(15)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(16)	Remove pressure gage from main manifold.
(17)	Lubricate preformed packing and backup ring with hydraulic oil.
(18)	Install preformed packing and backup ring on plug and install plug in main manifold, port TPMA. Tighten to 96 lb-in (11 N-m).
(19)	Remove caps and plugs from six bulkhead fittings and hoses.
(20)	Connect hoses 2888, 2887, 2588, 2666, 2889 and 2890 to bulkhead fittings.
(21)	Connect quick disconnect hose 2917.




6. MIDDLE FRAME DOES NOT LOAD (CONT).




WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

PRESSURE TEST	
(1)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(2)	Disconnect hose 2890 from adapter at port T of RH main cylinder manifold.
(3)	Install metal plug in removed hose.
(4)	Connect pressure gage to adapter at main cylinder manifold, port T.
(5)	Connect quick disconnect hose 2917.
(6)	Start engine (TM 9-2320-364-10).
(7)	Set hydraulic selector switch to MAN MF.
(8)	With the aid of an assistant, observe gage while holding joystick in LOAD position. <ul style="list-style-type: none"> (a) If more than 0 psi (0 kPa) are present, relief valve is faulty. Perform Steps (9) through (12) and (15) below and repair RH main cylinder manifold (Para 17-16). (b) If 0 psi (0 kPa) are present, relief valve is OK.
(9)	Set hydraulic selector switch to OFF position.
(10)	Turn OFF ENGINE switch.
(11)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(12)	Remove gage from adapter.
(13)	Remove plug from hose.
(14)	Connect hose to adapter.
(15)	Connect quick disconnect hose 2917.







6. MIDDLE FRAME DOES NOT LOAD (CONT).




WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

PRESSURE TEST	
(1)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(2)	Disconnect hose 2889 from adapter at port T of LH main cylinder manifold.
(3)	Install metal plug in removed hose.
(4)	Connect pressure gage to adapter at LH main cylinder manifold, port T.
(5)	Connect quick disconnect hose 2917.
(6)	Start engine (TM 9-2320-364-10).
(7)	Set hydraulic selector switch to MAN MF.
(8)	With the aid of an assistant, observe gage while holding joystick in LOAD position. <ul style="list-style-type: none"> (a) If more than 0 psi (0 kPa) are present, relief valve is faulty. Perform Steps (9) through (12) and (15) below and repair LH main cylinder manifold (Para 17-16). (b) If 0 psi (0 kPa) are present, relief valve is OK.
(9)	Set hydraulic selector switch to OFF position.
(10)	Turn OFF ENGINE switch.
(11)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(12)	Remove gage from adapter.
(13)	Remove plug from hose.
(14)	Connect hose to adapter.
(15)	Connect quick disconnect hose 2917.




6. MIDDLE FRAME DOES NOT LOAD (CONT).




WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.



PRESSURE TEST	
(1)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(2)	Remove plug from main manifold, port TPMA.
(3)	Remove preformed packing and backup ring from plug. Discard preformed packing and backup ring.
(4)	Connect pressure gage to main manifold, port TPMA.
(5)	Connect quick disconnect hose 2917.
(6)	Start engine (TM 9-2320-364-10).
(7)	Set hydraulic selector switch to MAN MF.
(8)	Raise main frame approximately 24 in. (61 cm).
(9)	With the aid of an assistant, observe pressure gage while holding joystick in LOAD position. <ul style="list-style-type: none"> (a) If more than 1300 psi (8964 kPa) are present, perform Steps (10) and (16) below and replace RH (inboard) main cylinder manifold load control valve (Para 17-6). (b) If 1300 psi (8964 kPa) or less are present, load control valve is OK.
(10)	Set hydraulic selector switch to OFF position.
(11)	Turn OFF ENGINE switch.
(12)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(13)	Remove pressure gage from main manifold.
(14)	Lubricate preformed packing and backup ring with hydraulic oil.
(15)	Install preformed packing and backup ring on plug and install plug in main manifold, port TPMA. Tighten to 96 lb-in (11 N·m).
(16)	Connect quick disconnect hose 2917.





6. MIDDLE FRAME DOES NOT LOAD (CONT).




WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.






- FLOWMETER TEST**
- (1) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
 - (2) Disconnect hose 2888 from LH main cylinder manifold adapter port VA.
 - (3) Connect adapter hose to hose 2888.
 - (4) Connect adapter hose to main cylinder manifold adapter port VA.
 - (5) Connect flowmeter OUT port to adapter hose connected to hose 2888.
 - (6) Connect flowmeter IN port to adapter hose connected to LH main cylinder manifold, port VA.
 - (7) Completely open flowmeter load valve.
 - (8) Set flowmeter to LOW scale.
 - (9) Connect quick disconnect hose 2917.
 - (10) Start engine (TM 9-2320-364-10).
 - (11) Set hydraulic selector switch to MAN MF position.
- Continued on next page.




6. MIDDLE FRAME DOES NOT LOAD (CONT).

WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.



FLOWMETER TEST (CONT).	
(12)	With the aid of an assistant, observe flowmeter while holding joystick in LOAD position.
(a)	If more than 0 gpm (lpm) are present, perform Steps (13) through (20) below and replace LH main cylinder (Para 17-15).
(b)	If 0 gpm (0 lpm) are present, LH main cylinder is OK.
(13)	Set hydraulic selector switch to OFF position.
(14)	Turn OFF ENGINE switch. Continued on next page.






WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

FLOWMETER TEST (CONT).

- (15) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (16) Disconnect flowmeter from two adapter hoses.
- (17) Disconnect adapter hose main cylinder manifold adapter.
- (18) Disconnect adapter hose from hose 2888.
- (19) Connect hose 2888 to LH main cylinder manifold adapter port VA.
- (20) Connect quick disconnect hose 2917.




6. MIDDLE FRAME DOES NOT LOAD (CONT).




WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.



FLOWMETER TEST	
(1)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(2)	Disconnect hose 2887 from RH main manifold adapter port VA.
(3)	Connect adapter hose to hose 2887.
(4)	Connect adapter hose to main cylinder manifold adapter port VA.
(5)	Connect flowmeter OUT port to adapter hose connected to hose 2887.
(6)	Connect flowmeter IN port to adapter hose connected to manifold.
(7)	Completely open flowmeter load valve.
(8)	Set flowmeter to LOW scale.
(9)	Connect quick disconnect hose 2917.
(10)	Start engine (TM 9-2320-364-10).
(11)	Set hydraulic selector switch to MAN MF position.
(12)	With the aid of an assistant, observe flow meter while holding joystick in LOAD position. <ul style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are present, perform Steps (13) through (23) below and replace RH main cylinder (Para 17-15). (b) If 0 gpm (0 lpm) are present, RH main cylinder is OK.
(13)	Set hydraulic selector switch to OFF position.
(14)	Turn OFF ENGINE switch.
(15)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(16)	Disconnect flowmeter from two adapter hoses.
(17)	Disconnect adapter hose main cylinder manifold adapter.
(18)	Disconnect adapter hose from hose 2887.
(19)	Connect hose 2887 to main cylinder manifold adapter port VA.
(20)	Connect quick disconnect hose 2917.




6. MIDDLE FRAME DOES NOT LOAD (CONT).




VERIFY REPAIR

- (1) Start engine (TM 9-2320-364-10).
- (2) Set hydraulic selector switch to AUTO position.
- (3) Hold joystick in LOAD position.
 - (a) If middle frame does not load, fault not corrected. Perform Steps (4) through (5) below and notify supervisor.
 - (b) If middle frame does load, fault has been corrected.
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.



**STEERING WHEEL
SHOWN REMOVED
FOR CLARITY**



2-14. LOAD HANDLING SYSTEM (LHS) TROUBLESHOOTING (CONT).

7. MIDDLE FRAME DOES NOT UNLOAD.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Cap and Plug Set (Item 34, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)
- Wrench Set, Socket 3/8 in. Drive (Item 273, Appendix F)
- Wrench, Torque (0-60 N·m) (Item 276, Appendix F)

Personnel Required

Two

References


TM 9-2320-364-10


Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)

Materials/Parts

- Oil, Hydraulic (Item 34, Appendix B)
- Tags, Identification (Item 72, Appendix B)
- Lockwashers (4) (Item 266, Appendix E)
- Parts Kit, Seal (Item 408, Appendix E)






NOTE


- Ensure button is pushed past free play to engage.
- Only remove center screw on engine side of LHS control box cover.

OPERATION TEST

- (1) Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
- (2) Start engine (TM 9-2320-364-10).
- (3) Set hydraulic selector switch to MAN MF.
- (4) Push in free flow valve manual push button while pushing in directional control valve middle frame up manual push button.
 - (a) If middle frame does not unload, perform Steps (5) through (7) below and go to Step 2 of this Fault.
 - (b) If hook arm unloads, perform Steps (5) and (6) below and replace middle frame up directional control valve (Para 17-10).
- (5) Set hydraulic selector switch to OFF position.
- (6) Turn OFF ENGINE switch.
- (7) Install LHS control box cover, four lockwashers and screws.



7. MIDDLE FRAME DOES NOT UNLOAD (CONT).







WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

PRESSURE TEST

- (1) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (2) Remove plug from main manifold, port TPMB.
- (3) Remove preformed packing and backup ring from plug. Discard preformed packing and backup ring.
- (4) Connect pressure gage to main manifold, port TPMB.
- (5) Tag, mark and disconnect hoses 2888, 2887, 2588, 2666, 2889 and 2890 from six compression frame bulkhead fittings.
- (6) Cap and plug six hoses and six bulkhead fittings using metal caps and plugs.
- (7) Connect quick disconnect hose 2917.
- (8) Start engine (TM 9-2320-364-10).
- (9) Raise hook arm approximately 24 in. (61 cm).
- (10) Set hydraulic selector switch to MAN MF.

Continued on next page.




7. MIDDLE FRAME DOES NOT UNLOAD (CONT).

WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

PRESSURE TEST (CONT).





- (11) With the aid of an assistant, observe pressure gage while holding joystick in UNLOAD position.
 - (a) If less than 3600 psi (24,822 kPa) is present, perform Steps (12) through (21) below and replace RH (inboard) load control valve (Para 17-6).
 - (b) If 3600 psi (24,822 kPa) or more are present, load control valve is OK.
 - (12) Put LHS in transit position.
 - (13) Set hydraulic selector switch to OFF position.
- Continued on next page.




WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

- PRESSURE TEST (CONT).**
- (14) Turn OFF ENGINE switch.
 - (15) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
 - (16) Remove pressure gage from main manifold.
 - (17) Lubricate preformed packing and backup ring with hydraulic oil.
 - (18) Install preformed packing and backup ring on plug and install plug in main manifold, port TPMB. Tighten to 96 lb-in (11 N·m).
 - (19) Remove caps and plugs from six bulkhead fittings and hoses.
 - (20) Connect six hoses to bulkhead fittings.
 - (21) Connect quick disconnect hose 2917.



7. MIDDLE FRAME DOES NOT UNLOAD (CONT).







WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

PRESSURE TEST

- (1) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (2) Disconnect hose 2890 from adapter at port T of RH main cylinder manifold.
- (3) Install metal plug in removed hose.
- (4) Connect pressure gage to adapter at main cylinder manifold, port T.
- (5) Connect quick disconnect hose 2917.
- (6) Start engine (TM 9-2320-364-10).
- (7) Set hydraulic selector switch to MAN MF.
- (8) With the aid of an assistant, observe gage while holding joystick in UNLOAD position.
 - (a) If more than 0 psi (0 kPa) are present, relief valve is faulty. Perform Steps (9) through (13) and (16) below and repair RH main cylinder manifold (Para 17-16).
 - (b) If 0 psi (0 kPa) are present, RH main cylinder manifold relief valve is OK.
- (9) Put LHS in transit position.
- (10) Set hydraulic selector switch to OFF position.
- (11) Turn OFF ENGINE switch.
- (12) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (13) Remove gage from adapter.
- (14) Remove plug from hose.
- (15) Connect hose to adapter.
- (16) Connect quick disconnect hose 2917.



7. MIDDLE FRAME DOES NOT UNLOAD (CONT).







WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

PRESSURE TEST

- (1) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (2) Disconnect hose 2889 from adapter at port T of LH main cylinder manifold.
- (3) Install metal plug in removed hose.
- (4) Connect pressure gage to adapter at main cylinder manifold, port T.
- (5) Connect quick disconnect hose 2917.
- (6) Start engine (TM 9-2320-364-10).
- (7) Set hydraulic selector switch to MAN MF.
- (8) With the aid of an assistant, observe gage while holding joystick in UNLOAD position.
 - (a) If more than 0 psi (0 kPa) are present, relief valve is faulty. Perform Steps (9) through (13) and (16) below and repair LH main cylinder manifold (Para 17-16).
 - (b) If 0 psi (0 kPa) are present, LH main cylinder manifold relief valve is OK.
- (9) Put LHS in transit position.
- (10) Set hydraulic selector switch to OFF position.
- (11) Turn OFF ENGINE switch.
- (12) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (13) Remove gage from adapter.
- (14) Remove plug from hose 2889.
- (15) Connect hose to adapter.
- (16) Connect quick disconnect hose 2917.



7. MIDDLE FRAME DOES NOT UNLOAD (CONT).






WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

PRESSURE TEST

- (1) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (2) Remove plug from main manifold, port TPMB.
- (3) Remove preformed packing and backup ring from plug. Discard preformed packing and backup ring.
- (4) Connect pressure gage to main manifold, port TPMB.
- (5) Connect quick disconnect hose 2917.
- (6) Start engine (TM 9-2320-364-10).
- (7) Set hydraulic selector switch to MAN MF.
- (8) With the aid of an assistant, observe pressure gage while holding joystick in UNLOAD position.
 - (a) If more than 1300 psi (8964 kPa) are present, perform Steps (9) through (16) below and replace LH (outboard) load control valve (Para 17-6).
 - (b) If 1300 psi (8960 kPa) or less are measured, load control valve is OK.
- (9) Put LHS in transit position.
- (10) Set hydraulic selector switch to OFF position.
- (11) Turn OFF ENGINE switch.
- (12) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (13) Remove pressure gage from main manifold.
- (14) Lubricate preformed packing and backup ring with hydraulic oil.
- (15) Install preformed packing and backup ring on plug and install plug in main manifold, port TPMB. Tighten to 96 lb-in (11 N·m).
- (16) Connect quick disconnect hose 2917.



7. MIDDLE FRAME DOES NOT UNLOAD (CONT).







WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

FLOWMETER TEST

- (1) Raise middle frame completely (TM 9-2320-364-10).
- (2) Set hydraulic selector switch to OFF position.
- (3) Turn OFF ENGINE switch.
- (4) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (5) Disconnect hose 2588 from LH main cylinder manifold adapter port VB.
- (6) Connect adapter hose to hose 2588.
- (7) Connect adapter hose to main cylinder manifold adapter port VB.
- (8) Connect flowmeter OUT port to adapter hose connected to hose 2588.
- (9) Connect flowmeter IN port to adapter hose connected to LH main manifold.
- (10) Completely open flowmeter load valve.
- (11) Set flowmeter to LOW scale.
- (12) Connect quick disconnect hose 2917.
- (13) Start engine.
- (14) Set hydraulic selector switch to MAN MF position.
- (15) With the aid of an assistant, observe flowmeter while holding joystick in UNLOAD position.
 - (a) If more than 0 gpm (lpm) are present, perform Steps (16) through (24) below and replace LH main cylinder (Para 17-15).
 - (b) If 0 gpm (lpm) are present, LH main cylinder is OK.
- (16) Put LHS in transit position.
- (17) Set hydraulic selector switch to OFF position.
- (18) Turn OFF ENGINE switch.
- (19) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (20) Disconnect flowmeter from two adapter hoses.
- (21) Disconnect adapter hose main cylinder manifold adapter.
- (22) Disconnect adapter hose from hose 2588.
- (23) Connect hose 2588 to main cylinder manifold adapter port VB.
- (24) Connect quick disconnect hose 2917.



7. MIDDLE FRAME DOES NOT UNLOAD (CONT).






WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

FLOWMETER TEST

- (1) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (2) Disconnect hose 2666 from RH main cylinder manifold adapter port VB.
- (3) Connect adapter hose to hose 2666.
- (4) Connect adapter hose to main cylinder manifold adapter port VB.
- (5) Connect flowmeter OUT port to adapter hose connected to hose 2666.
- (6) Connect flowmeter IN port to adapter hose connected to RH main cylinder manifold.
- (7) Completely open flowmeter load valve.
- (8) Set flowmeter to LOW scale.
- (9) Connect quick disconnect hose 2917.
- (10) Start engine (TM 9-2320-364-10).
- (11) Set hydraulic selector switch to MAN MF position.
- (12) With the aid of an assistant, observe flowmeter while holding joystick in UNLOAD position.
 - (a) If more than 0 gpm (0 lpm) are present, perform Steps (13) through (21) below and replace RH main cylinder (Para 17-15).
 - (b) If 0 gpm (0 lpm) are present, RH main cylinder is OK.
- (13) Put LHS in transit position.
- (14) Set hydraulic selector switch to OFF position.
- (15) Turn OFF ENGINE switch.
- (16) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (17) Disconnect flowmeter from two adapter hoses.
- (18) Disconnect adapter hose main cylinder manifold adapter.
- (19) Disconnect adapter hose from hose 2666.
- (20) Connect hose 2666 to main cylinder manifold adapter port VB.
- (21) Connect quick disconnect hose 2917.




7. MIDDLE FRAME DOES NOT UNLOAD (CONT).




VERIFY REPAIR

- (1) Start engine (TM 9-2320-364-10).
- (2) Set hydraulic selector switch to AUTO position.
- (3) Hold joystick in UNLOAD position.
 - (a) If middle frame does not unload, fault not corrected. Perform Steps (4) through (6) below and notify supervisor.
 - (b) If middle frame does unload, fault has been corrected.
- (4) Put LHS in transit position.
- (5) Set hydraulic selector switch to OFF position.
- (6) Turn OFF ENGINE switch.



**STEERING WHEEL
SHOWN REMOVED
FOR CLARITY**



2-14. LOAD HANDLING SYSTEM (LHS) TROUBLESHOOTING (CONT).

8. MIDDLE FRAME DOES NOT OPERATE.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Cap and Plug Set (Item 26, Appendix F)
- Goggles, Industrial (Item 83, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)
- Wrench Set, Socket 3/8 in. Drive (Item 273, Appendix F)
- Wrench, Torque (0-60 N·m) (Item 276, Appendix F)
- Wooden Blocks (Appendix C)
- Lifting Device, Minimum capacity 2500 lb (1134kg)

Materials/Parts

- Oil, Hydraulic (Item 34, Appendix B)
- Parts Kit, Seal (Item 412, Appendix E)
- Parts Kit, Seal (Item 408, Appendix E)

References


TM 9-2320-364-10

Personnel Required

Two

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)







WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

PRESSURE TEST

- (1) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (2) Remove plug from main manifold, port TPMB.
- (3) Remove preformed packing and backup ring from plug. Discard preformed packing and backup ring.
- (4) Connect pressure gage to main manifold, port TPMB.
- (5) Tag, mark and disconnect hoses 2888, 2887, 2588, 2666, 2889 and 2890 from six compression frame bulkhead fittings.
- (6) Cap and plug six hoses and six bulkhead fittings using metal caps and plugs.
- (7) Connect quick disconnect hose 2917.
- (8) Start engine (TM 9-2320-364-10).
- (9) Set hydraulic selector switch to MAN MF.
- (10) With the aid of an assistant, observe pressure gage while holding joystick in LOAD position.
 - (a) If less than 3600 psi (24,822 kPa) is present, perform Steps (11) through (20) below and replace transit directional control valve (Para 17-11).
 - (b) If 3600 psi (24,822 kPa) or more are present, transit directional control valve is OK.
- (11) Put LHS in transit position.
- (12) Set hydraulic selector switch to OFF position.
- (13) Turn OFF ENGINE switch.
- (14) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (15) Remove pressure gage from main manifold, port TPMB.
- (16) Lubricate preformed packing and backup ring with hydraulic oil.
- (17) Install preformed packing and backup ring on plug and install plug in main manifold, port TPMB. Tighten to 96 lb-in (11 N-m).
- (18) Remove caps and plugs from six bulkhead fittings and hoses.
- (19) Connect hoses 2888, 2887, 2588, 2666, 2889 and 2890 to bulkhead fittings.
- (20) Connect quick disconnect hose 2917.




8. MIDDLE FRAME DOES NOT OPERATE (CONT).




WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guard and personal protective equipment (goggles/shield, gloves, etc.). Failure to comply may result in injury to personnel.

VISUAL INSPECTION	
(1)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(2)	Disconnect hose from LH main cylinder manifold, port VB adapter.
(3)	Plug hose using metal plug.
(4)	Remove LH main cylinder manifold.
(5)	Remove adapter and velocity fuse from main cylinder manifold, port VB.
(6)	Remove preformed packing from adapter. Discard preformed packing.
(7)	Blow compressed air into velocity fuse.
(a)	If air cannot be blown through velocity fuse, replace velocity fuse.
(b)	If air can be blown through velocity fuse, velocity fuse is OK.
(8)	Lubricate preformed packing with hydraulic oil and install on adapter.
(9)	Install velocity fuse and adapter with new preformed packing in main cylinder manifold.
(10)	Install main cylinder manifold on main cylinder.
(11)	Install hose on main cylinder manifold adapter port VB.
(12)	Repeat Steps (2) through (11) above for RH main cylinder manifold.
(13)	Connect quick disconnect hose 2917.



8. MIDDLE FRAME DOES NOT OPERATE (CONT).





WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

FLOWMETER TEST

- (1) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (2) Disconnect hose 2887 from RH main cylinder adapter port VA.
- (3) Connect adapter hose to hose 2887.
- (4) Connect adapter hose to main cylinder manifold adapter port VA.
- (5) Connect flowmeter OUT port to adapter hose connected to hose 2887.
- (6) Connect flowmeter IN port to adapter hose connected to main cylinder manifold.
- (7) Completely open flowmeter load valve.
- (8) Set flowmeter to LOW scale.
- (9) Connect quick disconnect hose 2917.
- (10) Start engine (TM 9-2320-364-10).
- (11) Set hydraulic selector switch to MAN MF position.
- (12) With the aid of an assistant, observe flowmeter while holding joystick in LOAD position.
 - (a) If more than 0 gpm (0 lpm) are present, perform Steps (13) through (20) below and replace RH main cylinder (Para 17-15).
 - (b) If 0 gpm (0 lpm) are present, RH main cylinder is OK.
- (13) Set hydraulic selector switch to OFF position.
- (14) Turn OFF ENGINE switch.
- (15) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (16) Disconnect flowmeter from two adapter hoses.
- (17) Disconnect adapter hose from main cylinder manifold.
- (18) Disconnect adapter hose from hose 2887.
- (19) Connect hose 2887 to main cylinder manifold adapter port VA.
- (20) Connect quick disconnect hose 2917.




8. MIDDLE FRAME DOES NOT OPERATE (CONT).




WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.



FLOWMETER TEST	
(1)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(2)	Disconnect hose 2888 from LH main cylinder adapter port VA.
(3)	Connect adapter hose to hose 2888.
(4)	Connect adapter hose to main cylinder manifold adapter port VA.
(5)	Connect flowmeter OUT port to adapter hose connected to hose 2888.
(6)	Connect flowmeter IN port to adapter hose connected to main cylinder manifold.
(7)	Completely open flowmeter load valve.
(8)	Set flowmeter to LOW scale.
(9)	Connect quick disconnect hose 2917.
(10)	Start engine (TM 9-2320-364-10).
(11)	Set hydraulic selector switch to MAN MF position.
(12)	With the aid of an assistant, observe flowmeter while holding joystick in LOAD position. <ul style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are present, perform Steps (13) through (20) below and replace LH main cylinder (Para 17-15). (b) If 0 gpm (0 lpm) are present, LH main cylinder is OK.
(13)	Set hydraulic selector switch to OFF position
(14)	Turn OFF ENGINE switch.
(15)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(16)	Disconnect flowmeter from two adapter hoses.
(17)	Disconnect adapter hose from main cylinder manifold.
(18)	Disconnect adapter hose from hose 2888.
(19)	Connect hose 2888 to main cylinder manifold adapter port VA.
(20)	Connect quick disconnect hose 2917.



8. MIDDLE FRAME DOES NOT OPERATE (CONT).



WARNING


Middle frame and hook arm have a combined weight 2100 lbs (953 kg). Hook arm cylinders weigh 210 lbs (95 kg) each. Attach suitable lifting device prior to removal or installation to prevent possible injury to personnel.

CAUTION


Blocks supporting middle frame can fall when middle frame is supported by a lifting device. Have assistant prevent block from falling or damage to LHS could occur.

OPERATION TEST

- (1) Attach lifting device to hook arm.
- (2) With the aid of an assistant, lift hook arm with middle frame until middle frame pivot pin is above main cylinder while middle frame safe lowering button is pushed in (TM 9-2320-364-10).
- (3) Block middle frame up in two places with wooden blocks.
- (4) Remove lifting device from hook arm.
- (5) Attach lifting device to LH main cylinder.
- (6) Attach lifting device to RH main cylinder.
- (7) Remove rod lug end of LH main cylinder from middle frame (Para 17-15).
- (8) Remove rod lug end of RH main cylinder from middle frame.
- (9) Position LH and RH cylinders using lifting device so that cylinders can extend completely.
- (10) Start engine.
- (11) Put hydraulic selector switch in MAN MF position.
- (12) With the aid of an assistant, hold joystick in UNLOAD position and observe main cylinder operation.
 - (a) If one cylinder does not move, replace faulty main cylinder and install other main cylinder.
 - (b) If both cylinders operate, fault not corrected. Perform Steps (13) through (19) below and notify supervisor.
- (13) Position main cylinders and install rod lug ends to middle frame.
- (14) Remove lifting devices from main cylinders.
- (15) Raise hook arm.
- (16) Remove wooden blocks from hook arm.
- (17) Put LHS in transit position.
- (18) Set hydraulic selector switch to OFF position.
- (19) Turn OFF ENGINE switch.




8. MIDDLE FRAME DOES NOT OPERATE (CONT).




VERIFY REPAIR

- (1) Start engine (TM 9-2320-364-10).
- (2) Set hydraulic selector switch to AUTO position.
- (3) Hold joystick in UNLOAD position and then in the LOAD position.
 - (a) If middle frame does not operate, fault not corrected. Perform Steps (4) through (6) below and notify supervisor.
 - (b) If middle frame does operate, fault has been corrected.
- (4) Place LHS in transit position.
- (5) Set hydraulic selector switch to OFF position.
- (6) Turn OFF ENGINE switch.



**STEERING WHEEL
SHOWN REMOVED
FOR CLARITY**



2-14. LOAD HANDLING SYSTEM (LHS) TROUBLESHOOTING (CONT).

9. LHS DOES NOT OPERATE OR OPERATES SLOWLY.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)
- Wrench, Combination 1-1/2 in. (Item 260, Appendix F)
- Wrench, Combination 1-5/8 in. (Item 261, Appendix F)

References


TM 9-2320-364-10

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)



Materials/Parts

- Oil, Hydraulic (Item 34, Appendix B)
- Lockwasher (4) (Item 266, Appendix E)
- Lockwasher (8) (Item 282, Appendix E)
- Parts Kit, Seal (Item 408, Appendix E)




OPERATION TEST

- (1) Operate LHS (TM 9-2320-364-10).
 - (a) If LHS does not operate, perform Steps (2) through (4) below and go to Step 4 of this Fault.
 - (b) If LHS operates slowly, perform Steps (2) through (4) below and go to Step 2 of this Fault.
- (2) Put LHS in transit position.
- (3) Set hydraulic selector switch to OFF.
- (4) Turn OFF ENGINE switch.



9. LHS DOES NOT OPERATE OR OPERATES SLOWLY (CONT).



WARNING



- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Only remove center screw on engine side of LHS control box cover.

VISUAL INSPECTION

- (1) Remove eight screws, lockwashers, washers and left side noise panel. Discard lockwashers.
- (2) Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
- (3) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (4) Remove shuttle valve B from multifunction manifold (Para 17-18).
- (5) Remove and discard three preformed packings and two packing retainers.
- (6) Shake shuttle valve and listen for ball to rattle.
 - (a) If check ball does not rattle, clean or replace shuttle valve.
 - (b) If check ball does rattle, shuttle valve is OK.
- (7) Lubricate three preformed packings and two packing retainers with hydraulic oil and install on shuttle valve.
- (8) Install shuttle valve B.




9. LHS DOES NOT OPERATE OR OPERATES SLOWLY (CONT).




WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

VISUAL INSPECTION	
(1)	Remove shuttle valve C from multifunction manifold.
(2)	Remove and discard three preformed packings and two packing retainers.
(3)	Shake shuttle valve and listen for ball to rattle. <ul style="list-style-type: none"> (a) If check ball does not rattle, clean or replace shuttle valve (Para 17-18). (b) If check ball does rattle, fault not corrected. Perform Steps (4) through (8) below and notify supervisor.
(4)	Lubricate three preformed packings and two packing retainers with hydraulic oil and install on shuttle valve.
(5)	Install shuttle valve C.
(6)	Connect quick disconnect hose 2917.
(7)	Install left side noise panel, eight lockwashers and screws.
(8)	Install four screws, lockwashers and LHS control box cover.



9. LHS DOES NOT OPERATE OR OPERATES SLOWLY (CONT).




WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

FLOWMETER TEST

- (1) Disconnect pressure hose 2777 female quick disconnect from LHS control box male quick disconnect.
- (2) Connect adapter hose of same size to hose 2777.
- (3) Connect adapter hose of same size to LHS control box male quick disconnect.
- (4) Connect flowmeter IN port to adapter hose connected to hose 2777.
- (5) Connect flowmeter OUT port to adapter hose connected to LHS control box male quick disconnect.
- (6) Completely open flowmeter load valve.
- (7) Set flowmeter to high.
- (8) Start engine (TM 9-2320-364-10).
- (9) Set hydraulic selector switch to AUTO position.
- (10) Raise engine speed to full throttle and observe flowmeter.
 - (a) If 28 to 32 gpm (106 to 121 lpm) are not present, perform Steps (11) and (15) below and go to Step 5 of this Fault.
 - (b) If 28 to 32 gpm (106 to 121 lpm) are present, perform Steps (11) and (15) below and go to Step 6 of this Fault.
- (11) Set hydraulic selector switch to OFF position.
- (12) Turn OFF ENGINE switch.
- (13) Remove adapter hose 2777 from female quick disconnect.
- (14) Remove adapter hose 2777 from LHS control box male quick disconnect.
- (15) Connect quick disconnect hose 2777.




9. LHS DOES NOT OPERATE OR OPERATES SLOWLY (CONT).




VISUAL INSPECTION

- (1) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (2) Disconnect pressure hose 2777 female quick disconnect from LHS control box male quick disconnect.
- (3) Remove pressure hose 2777 from multifunction manifold, port C2.
- (4) Remove fitting and preformed packing from multifunction manifold. Discard preformed packing.
- (5) Remove orifice and preformed packing from multifunction manifold, port C2. Discard preformed packing.
- (6) Inspect orifice for contaminants or clogging.
 - (a) If orifice is plugged or damaged, clean or replace orifice (Para 17-18). Perform Step (10) below.
 - (b) If orifice is OK, replace LHS differential pressure sensing valve. Perform Steps (7) through (10) below.
- (7) Lubricate orifice preformed packing and install orifice and preformed packing in multifunction manifold.
- (8) Lubricate fitting preformed packing and install fitting and preformed packing on multifunction manifold.
- (9) Install pressure hose 2777 on fitting.
- (10) Connect quick disconnect hoses 2917 and 2777.



9. LHS DOES NOT OPERATE OR OPERATES SLOWLY (CONT).




NOTE


Only remove center screw on engine side of LHS control box cover.

OPERATION TEST

- (1) Remove four screws, lockwashers and LHS control box cover. Discard lockwashers.
- (2) Push in free flow solenoid valve manual push button (TM 9-2320-364-10).
 - (a) If manual push button cannot be pushed in, replace free flow solenoid valve (Para 17-9).
 - (b) If manual push button can be pushed in, free flow solenoid valve is OK.
- (3) Install LHS control box cover, four lockwashers and screws.




9. LHS DOES NOT OPERATE OR OPERATES SLOWLY (CONT).



WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.





CAUTION


Do not allow valve to go over relief for over 10 seconds, or damage to equipment may result.

PRESSURE TEST

- (1) Connect 0 to 6000 psi (0 to 41,370 kPa) pressure gage to multifunction manifold, port G2.
- (2) Start engine (TM 9-2320-364-10).
- (3) Set hydraulic selector switch to AUTO position.
- (4) With the aid of an assistant, observe pressure gage while holding joystick in LOAD position.
 - (a) If pressure is not 3600 to 3625 psi (24,822 to 24,994 kPa), perform Steps (5) and (6) below and go to Step 8 of this Fault.
 - (b) If pressure is 3600 to 3625 psi (24,822 to 24,994 kPa), relief valve is OK, perform Steps (5) through (7) below and go to Step 10 of this Fault.
- (5) Set hydraulic selector switch to OFF position.
- (6) Turn OFF ENGINE switch.
- (7) Disconnect pressure gage from multifunction manifold.




9. LHS DOES NOT OPERATE OR OPERATES SLOWLY (CONT).



WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.




PRESSURE TEST

Adjust LHS relief valve while observing pressure gage connected to multifunction manifold, port G2.

- (1) If pressure cannot be changed by adjusting using LHS relief valve, replace relief valve (Para 17-8).
- (2) If pressure can be adjusted using LHS relief valve, go to Step 9 of this Fault.




9. LHS DOES NOT OPERATE OR OPERATES SLOWLY (CONT).




WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.



PRESSURE TEST
(1) Connect 0 to 6000 psi (0 to 41,370 kPa) pressure gage to multifunction manifold, port G2.
(2) Start engine (TM 9-2320-364-10).
(3) Set hydraulic selector switch to AUTO position.
(4) Adjust LHS relief valve while observing pressure gage connected to port G2. <ul style="list-style-type: none"> (a) If pressure cannot be adjusted up to 3600 to 3625 psi (24,822 to 24,994 kPa) using LHS relief valve, perform Steps (5) through (7) below and replace LHS relief valve (Para 17-8). (b) If pressure can be adjusted up using LHS relief valve, fault not corrected. Perform Steps (5) through (9) below and notify supervisor.
(5) Set hydraulic selector switch to OFF position.
(6) Turn OFF ENGINE switch.
(7) Disconnect pressure gage from multifunction manifold.
(8) Install left side noise panel, eight washers, lockwashers, and screws.
(9) Install four screws, lockwashers and LHS control box cover.




9. LHS DOES NOT OPERATE OR OPERATES SLOWLY (CONT).




VERIFY REPAIR

- (1) Start engine (TM 9-2320-364-10).
- (2) Set hydraulic selector switch to AUTO position.
- (3) Hold joystick in UNLOAD position and then in LOAD position.
 - (a) If LHS does not operate, fault not corrected. Perform Steps (4) through (6) below and notify supervisor.
 - (b) If LHS does operate, fault has been corrected.
- (4) Put LHS in transit position.
- (5) Set hydraulic selector switch to OFF position.
- (6) Turn OFF ENGINE switch.



**STEERING WHEEL
SHOWN REMOVED
FOR CLARITY**



2-14. LOAD HANDLING SYSTEM (LHS) TROUBLESHOOTING (CONT).

10. LOSS OF MIDDLE FRAME LOAD HOLDING.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Cap and Plug Set (Item 34, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)
- Jackstand (2) (Item 132, Appendix F)
- Steel Tube (Appendix C)
- Load (500 lb [227 kg] minimum)
- Chain (Approximately 8 ft)

References


TM 9-2320-364-10

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)

Personnel Required

Two




WARNING

All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.


OPERATION TEST

- (1) Start engine (TM 9-2320-364-10).
- (2) Position LHS hook to rear of truck and engage hook on steel tube supported by jackstands.
- (3) Using LHS, lift truck only enough to lift vehicle weight off suspension. Do not lift tires off ground.
- (3) Set hydraulic selector switch to OFF position.
- (4) Turn OFF ENGINE switch.
 - (a) If middle frame does not hold weight off vehicle suspension, perform Steps (5) through (8) below and go to Step 6 of this Fault.
 - (b) If middle frame does hold weight off vehicle suspension, perform Steps (5) through (8) below and go to Step 2 of this Fault.
- (5) Disengage hook from bar.
- (6) Put LHS in transit position.
- (7) Set hydraulic selector switch to OFF position.
- (8) Turn OFF ENGINE switch.




**STEERING WHEEL SHOWN
REMOVED FOR
CLARITY**

**HYDRAULIC
SELECTOR
SWITCH**






10. LOSS OF MIDDLE FRAME LOAD HOLDING (CONT).




WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

VISUAL INSPECTION	
(1)	Position LHS hook to rear of truck (TM 9-2320-364-10).
(2)	Attach 500 lb (227 kg) minimum load to hook.
(3)	Lower middle frame approximately half of its travel.
(4)	Set hydraulic selector switch to OFF position.
(5)	Turn OFF ENGINE switch.
(6)	Disconnect hose 2889 from LH main cylinder manifold, port T. Plug disconnected hose.
(7)	Disconnect hose 2890 from RH main cylinder manifold, port T. Plug disconnected hose. <ul style="list-style-type: none"> (a) If no fluid leaks from LH or RH main cylinder manifolds where hoses were removed, main cylinder manifold relief valves are OK. Perform Steps (8) through (13) below and go to Step 3 of this Fault. (b) If fluid leaks from LH or RH main cylinder manifold where hose is removed, relief valve is faulty. Perform Steps (8) through (13) below and repair main cylinder manifold (Para 17-16).
(8)	Remove plug from hose 2890 and connect hose to LH main cylinder manifold, port T.
(9)	Remove plug from hose 2889 and connect hose to RH main cylinder manifold, port T.
(10)	Remove 500 lb (227 kg) load from LHS hook.
(11)	Put LHS in transit position.
(12)	Set hydraulic selector switch to OFF position.
(13)	Turn OFF engine.




10. LOSS OF MIDDLE FRAME LOAD HOLDING (CONT).



WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.




STEERING WHEEL SHOWN REMOVED FOR CLARITY

FLOWMETER TEST

- (1) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (2) Disconnect hose 2888 from LH main cylinder manifold, port VA.
- (3) Connect adapter hose to hose 2888.
- (4) Connect adapter hose to main cylinder manifold, port VA.
- (5) Connect flowmeter IN port to adapter hose connected to LH main cylinder manifold, port VA.
- (6) Connect flowmeter OUT port to adapter hose connected to hose 2888.
- (7) Completely open flowmeter load valve.
- (8) Connect quick disconnect hose 2917.
- (9) Start engine (TM 9-2320-364-10).
- (10) Set hydraulic selector switch to MAN MF position.
- (11) With the aid of an assistant, observe flowmeter while holding joystick in LOAD position.
 - (a) If more than 0 gpm (0 lpm) are present, perform Steps (12) through (19) below and replace LH main cylinder (Para 17-15).
 - (b) If 0 gpm (0 lpm) are present, LH main cylinder is OK.
- (12) Set hydraulic selector switch to OFF position.
- (13) Turn OFF ENGINE switch.
- (14) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (15) Disconnect flowmeter from two adapter hoses.
- (16) Disconnect adapter hose from LH main cylinder manifold, port VA.
- (17) Disconnect adapter hose from hose 2888.
- (18) Connect hose 2888 to LH main cylinder manifold, port VA.
- (19) Connect quick disconnect hose 2917.




10. LOSS OF MIDDLE FRAME LOAD HOLDING (CONT).



WARNING



- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

FLOWMETER TEST	
(1)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(2)	Disconnect hose 2887 from RH main cylinder manifold, port VA.
(3)	Connect adapter hose to hose 2887.
(4)	Connect adapter hose to main cylinder manifold, port VA.
(5)	Connect flowmeter IN port to adapter hose connected to RH main cylinder manifold.
(6)	Connect flowmeter OUT port to adapter hose connected to hose 2666.
(7)	Completely open flowmeter load valve.
(8)	Connect quick disconnect hose 2917.
(9)	Start engine (TM 9-2320-364-10).
(10)	Set hydraulic selector switch to MAN MF position.
(11)	With the aid of an assistant, observe flowmeter while holding joystick in LOAD position. <ul style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are present, perform Steps (12) through (19) below and replace RH main cylinder (Para 17-15). (b) If 0 gpm (0 lpm) are present, perform Steps (12) through (19) below and replace load control valve (Para 17-6).
(12)	Set hydraulic selector switch to OFF position.
(13)	Turn OFF ENGINE switch.
(14)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(15)	Disconnect flowmeter from two adapter hoses.
(16)	Disconnect adapter hose from RH main cylinder manifold, port VA.
(17)	Disconnect adapter hose from hose 2887.
(18)	Connect hose 2666 to RH main cylinder manifold, port VA.
(19)	Connect quick disconnect hose 2917.




STEERING WHEEL SHOWN REMOVED FOR CLARITY


QUICK DISCONNECTS



RH MAIN CYLINDER MANIFOLD



10. LOSS OF MIDDLE FRAME LOAD HOLDING (CONT).




WARNING


All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

VERIFY REPAIR


- (1) Position LHS hook to rear of truck (TM 9-2320-364-10).
- (2) Attach 500 lb (227 kg) minimum load to hook.
- (3) Lower middle frame approximately half of its travel.
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.
 - (a) If middle frame does not hold load, fault not corrected. Perform Steps (6) through (9) below and notify supervisor.
 - (b) If middle frame does hold load, fault has been corrected.
- (6) Remove 500 lb (227 kg) load from LHS hook.
- (7) Put LHS in transit position.
- (8) Set hydraulic selector switch to OFF position.
- (9) Turn OFF ENGINE switch.



**STEERING WHEEL
SHOWN REMOVED
FOR CLARITY**



10. LOSS OF MIDDLE FRAME LOAD HOLDING (CONT).






WARNING


All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

VISUAL INSPECTION

- (1) Start engine (TM 9-2320-364-10).
- (2) Position LHS hook to rear of truck and engage hook on steel tube supported by jackstands.
- (3) Using LHS, lift truck only enough to lift vehicle weight off suspension. Do not lift tires off ground.
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.
- (6) Disconnect hose 2889 from LH main cylinder manifold, port T. Plug hose.
- (7) Disconnect hose 2890 from RH main cylinder manifold, port T. Plug hose.
 - (a) If no fluid leaks from LH or RH main cylinder manifolds where hoses were removed, relief valves are OK. Perform Steps (8) through (13) below and go to Step 7 of this Fault.
 - (b) If fluid leaks from LH or RH main cylinder manifold where hose is removed, relief valve is faulty. Perform Steps (8) through (13) below and repair main cylinder manifold (Para 17-16).
- (8) Remove plug from hose 2890 and connect hose to RH main cylinder manifold, port T.
- (9) Remove plug from hose 2889 and connect hose to LH main cylinder manifold, port T.
- (10) Disengage hook from steel tube.
- (11) Put LHS in transit position.
- (12) Set hydraulic selector switch to OFF position.
- (13) Turn OFF ENGINE switch.






10. LOSS OF MIDDLE FRAME LOAD HOLDING (CONT).



WARNING


- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.



FLOWMETER TEST


- (1) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (2) Disconnect hose 2888 from LH main manifold, port VA.
- (3) Connect adapter hose to hose 2888.
- (4) Connect adapter hose to main cylinder manifold, port VA.
- (5) Connect flowmeter IN port to adapter hose connected to LH main cylinder manifold.
- (6) Connect flowmeter OUT port to adapter hose connected to hose 2888.
- (7) Completely open flowmeter load valve.
- (8) Set flowmeter to low scale.
- (9) Connect quick disconnect hose 2917.
- (10) Start engine (TM 9-2320-364-10).
- (11) Set hydraulic selector switch to MAN MF position.
- (12) With the aid of an assistant, observe flowmeter while holding joystick in LOAD position.
 - (a) If more than 0 gpm (0 lpm) are present, perform Steps (13) through (20) below and replace LH main cylinder (Para 17-15).
 - (b) If 0 gpm (0 lpm) are present, LH main cylinder is OK.
- (13) Set hydraulic selector switch to OFF position.
- (14) Turn OFF ENGINE switch.
- (15) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (16) Disconnect flowmeter from two adapter hoses.
- (17) Disconnect adapter hose from LH main cylinder manifold, port VA.
- (18) Disconnect adapter hose from hose 2888.
- (19) Connect hose 2888 to LH main cylinder manifold, port VA.
- (20) Connect quick disconnect hose 2917.

10. LOSS OF MIDDLE FRAME LOAD HOLDING (CONT).




WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.



FLOWMETER TEST	
(1)	Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
(2)	Disconnect hose 2887 from RH main cylinder manifold, port VA.
(3)	Connect adapter hose to hose 2887.
(4)	Connect adapter hose to main cylinder manifold, port VA.
(5)	Connect flowmeter IN port to adapter hose connected main cylinder manifold, port VA.
(6)	Connect flowmeter OUT port to adapter hose connected to hose 2887.
(7)	Completely open flowmeter load valve.
(8)	Set flowmeter to LOW scale.
(9)	Connect quick disconnect hose 2917.
(10)	Start engine (TM 9-2320-364-10).
(11)	Set hydraulic selector switch to MAN MF position.





Continued on next page.



10. LOSS OF MIDDLE FRAME LOAD HOLDING (CONT).

WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.





FLOWMETER TEST (CONT).

- (12) With the aid of an assistant, observe flowmeter while holding joystick in LOAD position.
 - (a) If more than 0 gpm (0 lpm) are measured, perform Steps (13) through (20) below and replace RH main cylinder (Para 17-15).
 - (b) If 0 gpm (0 lpm) are measured, perform Steps (13) through (20) below and replace load control valve (Para 17-6).
- (13) Set hydraulic selector switch to OFF position.
- (14) Turn OFF ENGINE switch.
- (15) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (16) Disconnect flowmeter from two adapter hoses.

Continued on next page.



WARNING

- The LHS hydraulic system operates at oil pressures up to 3675 psi (25,339 kPa). Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in serious injury or death to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.




FLOWMETER TEST (CONT).

- (17) Disconnect adapter hose from RH main cylinder manifold, port VA.
- (18) Disconnect adapter hose from hose 2887.
- (19) Connect hose 2887 to RH main cylinder manifold, port VA.
- (20) Connect quick disconnect hose 2917.



10. LOSS OF MIDDLE FRAME LOAD HOLDING (CONT).





WARNING

All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

VERIFY REPAIR

- (1) Position LHS hook to rear of truck and engage hook on steel tube supported by jackstands.
- (2) Using LHS, lift truck only enough to lift vehicle weight off suspension. Do not lift tires off ground.
- (3) Set hydraulic selector switch to OFF position (TM 9-2320-364-10).
- (4) Turn OFF ENGINE switch.
 - (a) If middle frame does not hold weight off vehicle suspension, fault not corrected. Perform Steps (5) through (8) below and notify supervisor.
 - (b) If middle frame does hold weight off vehicle suspension, fault has been corrected.
- (5) Disengage hook from steel tube.
- (6) Put LHS in transit position.
- (7) Set hydraulic selector switch to OFF position.
- (8) Turn OFF ENGINE switch.



2-14. LOAD HANDLING SYSTEM (LHS) TROUBLESHOOTING (CONT).

11. LHS HOOK ARM DISENGAGES FROM FLATRACK WHILE UNLOADING.

INITIAL SETUP

Tools and Special Tools

Gage Set, Telescoping (Item 69, Appendix F)
 Level (Item 134, Appendix F)
 Micrometer, Outside, Caliper, Set (Item 139, Appendix F)
 Plumb Bob (Item 161, Appendix F)
 Ruler, Tape (Item 235, Appendix F)
 Wooden Block (4) (Appendix C)

References


TM 9-2320-364-10
 TM 9-3990-206-14&P

Equipment Condition

Flatrack unloaded, (TM 9-2320-364-10)

Personnel Required

Two




NOTE

The 1/8 in. (3.175 mm) measurement is for the bottom of the hook bar only.


WEAR MEASUREMENT TEST

Measure the amount of wear on the hook bar.

- (1) If wear at lower back side of hook bar is 1/4 in. (6.35 mm) or less, and 1/8 in. (3.175 mm) or less at bottom of hook bar, hook bar is OK. Go to Step 2 of this Fault.
- (2) If wear at lower back side of hook bar is greater than 1/4 in. (6.35 mm) or greater than 1/8 in. (3.175 mm) at bottom of hook bar, repair flatrack hook bar. Refer to TM 9-3990-206-14&P. Verify repair and go to Step 4 of this Fault.



11. LHS HOOK ARM DISENGAGES FROM FLATRACK WHILE UNLOADING (CONT).




NOTE


Clearance given is for a hook bar with or without any wear.

CLEARANCE MEASUREMENT TEST

- (1) Load flatrack onto truck (TM 9-2320-364-10).
- (2) Verify LHS hook arm is in its lowest position.
- (3) Verify flatrack is resting squarely on all four LHS support points.
- (4) Using a telescoping gage, measure the vertical clearance between the bottom of the flatrack hook bar and the LHS lift hook.
 - (a) If clearance is less than 0.875 in. (22.2 mm), fault not corrected, notify the supervisor.
 - (b) If clearance is greater than 0.875 in. (22.2 mm), go to Step 3 of this Fault.



11. LHS HOOK ARM DISENGAGES FROM FLATRACK WHILE UNLOADING (CONT).







WARNING

Do not stand under hook arm. Mechanical failure or operator error may cause injury or death to personnel.


NOTE

- Front boards will be used to aid in measuring the flatrack hook bar height.
- Boards are used under the front and rear of the flatrack to ensure the main rails will be at the same height.
- Use of a level (3 ft minimum [92 cm]) is required when leveling flatrack.
- Flatrack hook bar height range is given for a hook bar with or without wear.
- If hook does not swing toward truck, push hook toward truck and insert pin to hold in measurement position.

HEIGHT MEASUREMENT TEST	
(1)	Position flatrack on a flat level surface with 3 in. by 12 in. by 6 ft boards under the frame rails, at the front and rear of the flatrack. Level flatrack as required from side to side and front to back. Place level on outside edge of flatrack frame.
(2)	Using a plumb bob, mark a spot on the board to indicate the bottom center of the flatrack hook bar.
(3)	With the aid of an assistant, measure vertical distance between the spot on the board and the bottom center of the flatrack hook bar. <ul style="list-style-type: none"> (a) If measurement is not between 60-13/16 in. and 61-1/8 in. (154.46 and 155.25 cm), repair flatrack hook bar, refer to TM 9-3990-206-14&P. Verify repair, go to Step (4) of this Fault. (b) If measurement is between 60-13/16 in. and 61-1/8 in. (154.46 and 155.25 cm), go to Step (4) below.
(4)	Operate LHS to extended position (TM 9-2320-364-10).
(5)	Remove snapper pin (1), washer (2) and retaining pin (3) from hook (4) and hook arm (5). Allow hook to swing toward truck.
(6)	Measure length of hook arm by measuring from bottom of pin hole to hook thumb radius. <ul style="list-style-type: none"> (a) If hook arm measurement is not between 22-1/8 in. (561.9 mm) and 22-3/8 in. (568.3 mm), replace hook arm. Refer to Para 16-38. Verify repair, go to Step 4 of this Fault. (b) If hook arm measurement is between 22-1/8 in. (561.9 mm) and 22-3/8 in. (568.3 mm), fault not corrected, notify supervisor.



11. LHS HOOK ARM DISENGAGES FROM FLATRACK WHILE UNLOADING (CONT).



VERIFY REPAIR

Unload flatrack from truck
(TM 9-2320-364-10).

- (1) If flatrack unloads correctly, fault has been corrected.
- (2) If flatrack does not unload correctly, fault not corrected, notify supervisor.

2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING.

This paragraph covers Material Handling Crane System Troubleshooting. The Material Handling Crane System Fault Index, Table 2-15, lists faults for the crane system of the PLS truck. Refer to the schematics Figures 2-7 through 2-14 when performing tests and corrective actions.

Table 2-15. Material Handling Crane System Fault Index

Fault No.	Description	Page
1.	Outriggers Do Not Operate Or Operate Slowly	2-428
2.	LH Outrigger Does Not Operate	2-446
3.	RH Outrigger Does Not Operate	2-460
4.	Four Valve Bank Functions (Swing, Lift, Telescope And Hoist) Do Not Operate Or Operate Slowly	2-474
5.	Mast Does Not Operate Or Operates Slowly	2-482
6.	Mast Does Not Raise	2-502
7.	Mast Does Not Lower	2-508
8.	Crane Does Not Swing Or Swings Slowly	2-514
9.	Crane Does Not Swing Clockwise (CW)	2-532
10.	Crane Does Not Swing Counter Clockwise (CCW)	2-540
11.	Boom Does Not Telescope In Or Telescopes In Slowly	2-548
12.	Boom Does Not Telescope Out Or Telescopes Out Slowly	2-562
13.	Boom Does Not Telescope Or Telescopes Slowly	2-576
14.	Boom Does Not Raise Or Raises Slowly	2-590
15.	Boom Does Not Lower Or Lowers Slowly	2-604
16.	Boom Does Not Operate Or Operates Slowly	2-614
17.	Boom Creeps Down	2-628
18.	Hoist Does Not Operate Or Operates Slowly	2-640
19.	Hoist Does Not Lower	2-650
20.	Hoist Does Not Raise	2-660
21.	Crane Fails Load Test	2-674
22.	Overload Shutdown System (OSS) Disables Crane Functions, Boom Up, Boom Down, Telescoped Out And Hoist Up	2-708




Figure 2-7. Material Handling Crane Wiring Schematic




Figure 2-8. Mast Circuit Schematic




Figure 2-9. Swing Circuit Schematic




Figure 2-10. Telescope Circuit Schematic




Figure 2-11. Boom Circuit Schematic




Figure 2-12. Hoist Circuit Schematic




Figure 2-13. Outrigger Circuit Schematic (Sheet 1 of 2)




Figure 2-13. Outrigger Circuit Schematic (Sheet 2 of 2)




Figure 2-14. Four Bank Valve Hydraulic Schematic

2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

1. OUTRIGGERS DO NOT OPERATE OR OPERATE SLOWLY.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)
 Pan, Drain 6 gal (Item 145, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)
 Wrench, Combination, 1-1/2 in.
 (Item 260, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20





Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)

Materials/Parts

Oil, Hydraulic (Item 34, Appendix B)
 Wire, Nonelectrical (Item 79, Appendix B)
 Lockwashers (4) (Item 282, Appendix E)
 Packing, Preformed (2) (Item 337, Appendix E)
 Packing, Preformed (2) (Item 389, Appendix E)
 Packing, Preformed (2) (Item 391, Appendix E)





OPERATION TEST

- (1) Start engine (TM 9-2320-364-10).
- (2) Set WINCH/CRANE switch to CRANE position.
- (3) Set hydraulic selector switch to CRANE/SRW position.
- (4) Set crane POWER switch to ON position.
- (5) Operate outriggers using O/R JACK control levers on LH side of truck.
 - (a) If outriggers do not operate, go to Step 2 of this Fault.
 - (b) If outriggers operate, perform Steps (6) through (8) below and repair four valve bank (Para 16-26).
- (6) Set crane POWER switch to OFF position.
- (7) Set hydraulic selector switch to OFF position.
- (8) Turn OFF ENGINE switch.


1. OUTRIGGERS DO NOT OPERATE OR OPERATE SLOWLY (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. Winch and LHS operate.
POSSIBLE PROBLEMS
Four valve bank faulty. Solenoid valve assembly faulty. Main hydraulic pressure valve faulty. Multifunction manifold faulty. Relief valve faulty.

2.




Do outriggers operate using O/R JACK control levers on RH side of truck?

TEST OPTIONS
Operation test.
REASON FOR QUESTION
If check valve in center manifold of four valve bank is faulty, outriggers can be operated from one side of truck but not the other.




OPERATION TEST

- (1) Operate outriggers using O/R JACK control levers on RH side of truck (TM 9-2320-364-10).
 - (a) If outriggers do not operate, go to Step 3 of this Fault.
 - (b) If outriggers operate, perform Steps (2) through (4) below and repair four valve bank (Para 16-26).
- (2) Set crane POWER switch to OFF position.
- (3) Set hydraulic selector switch to OFF position.
- (4) Turn OFF ENGINE switch.






1. OUTRIGGERS DO NOT OPERATE OR OPERATE SLOWLY (CONT).




OPERATION TEST

- (1) Cut safety wire from MHC SYSTEM HYDRAULIC PRESSURE MANUAL OVERRIDE button.
- (2) Push in MHC SYSTEM HYDRAULIC PRESSURE MANUAL OVERRIDE push button.
- (3) Attempt to operate outriggers using O/R JACK control levers.
 - (a) If outriggers do not operate, perform Steps (4) through (6) below and go Step 4 of this Fault.
 - (b) If outriggers operate, perform Steps (4) through (6) below, and repair solenoid valve assembly (Para 16-24).
- (4) Set crane POWER switch to OFF position.
- (5) Set hydraulic selector switch to OFF position.
- (6) Turn OFF ENGINE switch.



1. OUTRIGGERS DO NOT OPERATE OR OPERATE SLOWLY (CONT).



WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Remove four screws, lockwashers, nuts, eight washers and cover. Discard lockwashers.
- (2) Disconnect tube from four valve bank center manifold elbow. Discard preformed packing.
- (3) Disconnect tube from bottom right solenoid valve assembly adapter (below crane hydraulic system manual override). Discard preformed packing.
- (4) Install cap on elbow.
- (5) Connect adapter hose with preformed packing to solenoid valve assembly adapter.
- (6) Connect flowmeter IN port to adapter hose connected to solenoid valve assembly.
- (7) Disconnect hose 2917 male quick disconnect from LHS control box female quick disconnect.
- (8) Connect adapter hose to hose 2917 quick disconnect.
- (9) Connect flowmeter OUT port to adapter hose connected to quick disconnect.
- (10) Disconnect high speed fan connector at multifunction valve.
- (11) Open flowmeter load valve fully.
- (12) Disconnect connector MC59 from EPAC.
- (13) Set hydraulic selector switch to CRANE/SRW position.
- (14) Start engine (TM 9-2320-364-10).
- (15) Set crane POWER switch to ON position.

Continued on next page.



1. OUTRIGGERS DO NOT OPERATE OR OPERATE SLOWLY (CONT).


WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST (CONT).	
(16)	Push in MHC SYSTEM HYDRAULIC PRESSURE MANUAL OVERRIDE push button. <ul style="list-style-type: none"> (a) If 10 to 12 gpm (38 to 45 lpm) or more are not measured, perform Steps (17) through (25) and replace main hydraulic pressure valve (Para 16-24). (b) If 10 to 12 gpm (38 to 45 lpm) are measured, perform Steps (17) through (25) below and go to Step 5 of this Fault.
(17)	Set crane POWER switch to OFF position.
(18)	Set hydraulic selector switch to OFF position.
(19)	Turn OFF ENGINE switch.
(20)	Disconnect adapter hose from hose 2917 quick disconnect.
(21)	Connect hose 2917 quick disconnect to LHS control box quick disconnect.
<i>Continued on next page.</i>	



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST (CONT).

- (23) Install safety wire on MHC SYSTEM HYDRAULIC PRESSURE MANUAL OVERRIDE button.
- (24) Disconnect adapter hose from solenoid valve assembly. Discard preformed packing.
- (25) Install tube with preformed packings on solenoid valve adapter and four valve bank elbow.



1. OUTRIGGERS DO NOT OPERATE OR OPERATE SLOWLY (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,675 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Remove cap from tube coming from bottom of four valve bank. Discard preformed packing.
- (2) Connect pressure gage with preformed packing to tube.
- (3) Set WINCH/CRANE switch to CRANE position (TM 9-2320-364-10).
- (4) Start engine.
- (5) Set hydraulic selector switch to CRANE/SRW position.
- (6) Set crane POWER switch to ON position.
- (7) Set crane high idle switch to LATCH.
- (8) Hold RH O/R JACK control lever on RH side of truck in UP position.
 - (a) If 3000 psi (20,685 kPa) are not measured, go to Step 6 of this Fault.
 - (b) If 3000 psi (20,685 kPa) are measured, perform Steps (9) through (13) and replace shuttle valve (Para 17-18).
- (9) Set crane POWER switch to OFF position.
- (10) Set hydraulic selector switch to OFF position.
- (11) Turn OFF ENGINE switch.
- (12) Disconnect pressure gage from tube. Discard preformed packing.
- (13) Install cap with preformed packing on tube.



1. OUTRIGGERS DO NOT OPERATE OR OPERATE SLOWLY (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,675 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Hold BOOM control lever in DOWN position (TM 9-2320-364-10).
 - (a) If 3000 psi (20,685 kPa) are not measured, go to Step 7 of this Fault.
 - (b) If 3000 psi (20,685 kPa) are measured, perform Steps (2) through (6) below and replace check valve in four valve bank center manifold (Para 16-26).
- (2) Set crane POWER switch to OFF position.
- (3) Set hydraulic selector switch to OFF position.
- (4) Turn OFF ENGINE switch.
- (5) Disconnect pressure gage from tube. Discard preformed packing.
- (6) Install cap with preformed packing on tube.



1. OUTRIGGERS DO NOT OPERATE OR OPERATE SLOWLY (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,675 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.


FLOWMETER TEST

- (1) Loosen jam nut on relief valve.
- (2) Hold RH O/R JACK control lever on RH side of truck in UP position (TM 9-2320-364-10).
- (3) Adjust relief valve by turning screw left or right and observe pressure gage.
 - (a) If 3000 to 3100 psi (20,685 to 21,375 kPa) cannot be obtained, perform Steps (4) through (9) below and repair four valve bank center manifold (Para 16-26).
 - (b) If 3000 to 3100 psi (20,685 to 21,375 kPa) can be obtained, perform Steps (4) through (8) below and notify supervisor.
- (4) Tighten jam nut on relief valve.
- (5) Set crane POWER switch to OFF position.
- (6) Set hydraulic selector switch to OFF position.
- (7) Turn OFF ENGINE switch.
- (8) Disconnect pressure gage from tube. Discard preformed packing.
- (9) Install cap with preformed packing on tube.




1. OUTRIGGERS DO NOT OPERATE OR OPERATE SLOWLY (CONT).





VERIFY REPAIR
(1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
(2) Start engine (TM 9-2320-364-10).
(3) Set WINCH/CRANE switch to CRANE position.
(4) Set hydraulic selector switch to CRANE/SRW position.
(5) Set crane POWER switch to ON position.
(6) Operate outriggers using O/R JACK control levers. <ul style="list-style-type: none"> (a) If outriggers do not operate, fault not corrected. Perform Steps (7) through (10) below and notify supervisor. (b) If outriggers operate, fault has been corrected.
(7) Raise outriggers completely.
(8) Set crane POWER switch to OFF position.
(9) Set hydraulic selector switch to OFF position.
(10) Turn OFF ENGINE switch.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

2. LH OUTRIGGER DOES NOT OPERATE.

INITIAL SETUP

Tools and Special Tools


Tool Kit, General Mechanic's
(Item 240, Appendix F)

References

TM 9-2320-364-10


Equipment Condition

Engine OFF, (TM 9-2320-364-10)
Parking brake applied, (TM 9-2320-364-10)
Wheels chocked, (TM 9-2320-364-10)



OPERATION TEST

- Operate LH outrigger using LH O/R JACK control lever on LH side of truck (TM 9-2320-364-10).
- (1) If LH outrigger does not operate, go to Step 4 of this Fault.
 - (2) If LH outrigger operates, go to Step 2 of this Fault.




2. LH OUTRIGGER DOES NOT OPERATE (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. RH outrigger operates. Two valve bank OK. LH outrigger cylinder assembly OK.
POSSIBLE PROBLEMS
Three valve bank faulty.


2.
Does LH outrigger operate using LH O/R JACK control lever on RH side of truck with RH O/R JACK control lever in UP position?

TEST OPTIONS
Operation test.
REASON FOR QUESTION
If three valve bank check valve is faulty, pump compensator will not receive load sense pressure from LH O/R JACK valve and will receive load sense pressure from RH O/R JACK valve.




OPERATION TEST

- (1) Operate LH outrigger using LH O/R JACK control lever on RH side of truck while holding RH O/R JACK control lever in UP position (TM 9-2320-364-10).
 - (a) If LH outrigger does not operate with RH O/R JACK control lever in UP position, perform Steps (2) through (4) below and go to Step 3 of this Fault.
 - (b) If LH outrigger operates, check valve in three valve bank is faulty. Perform Steps (2) through (4) below and repair three valve bank (Para 16-27).
- (2) Set crane POWER switch to OFF position.
- (3) Set hydraulic selector switch to OFF position.
- (4) Turn OFF ENGINE switch.



2. LH OUTRIGGER DOES NOT OPERATE (CONT).



WARNING



- High pressure hydraulics [oil under 3000 psi (20,675 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Remove three valve bank from crane (Para 16-27).
- (2) Remove valves from three valve bank body (Para 16-27).
- (3) Remove orifice from LH O/R JACK control valve (Para 16-27).
 - (a) If orifice is clogged or damaged, replace orifice (Para 16-27) and perform Steps (4) and (5) below.
 - (b) If orifice is OK, repair LH O/R JACK valve (Para 16-27) and perform Steps (4) and (5) below.
- (4) Assemble three valve bank (Para 16-27).
- (5) Install three valve bank on crane (Para 16-27).




2. LH OUTRIGGER DOES NOT OPERATE (CONT).



OPERATION TEST

- (1) Operate LH outrigger using LH O/R JACK control lever on RH side of truck (TM 9-2320-364-10).
 - (a) If LH outrigger does not operate, LH outrigger cylinder is faulty. Perform Steps (2) through (4) below and replace outrigger cylinder (Para 16-31).
 - (b) If LH outrigger operates, go to Step 5 of this Fault.
- (2) Set crane POWER switch to OFF position.
- (3) Set hydraulic selector switch to OFF position.
- (4) Turn OFF ENGINE switch.




2. LH OUTRIGGER DOES NOT OPERATE (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. RH outrigger operates. Three valve bank OK. LH outrigger cylinder OK.
POSSIBLE PROBLEMS
Two valve bank faulty.





5.

Does LH outrigger operate using LH O/R JACK control lever on LH side of truck with RH O/R JACK control lever in UP position?


TEST OPTIONS
Operation test.
REASON FOR QUESTION
If two valve bank check valve is faulty, pump compensator will not receive load sense pressure from LH O/R JACK valve and will receive load sense pressure from RH O/R JACK valve.



- OPERATION TEST**
- (1) Operate LH outrigger using LH O/R JACK control lever on LH side of truck while holding RH O/R JACK control lever in UP position (TM 9-2320-364-10).
 - (a) If LH outrigger does not operate with RH O/R JACK control lever in UP position, perform Steps (2) through (4) below and go to Step 6 of this Fault.
 - (b) If LH outrigger operates, check valve in two valve bank is faulty. Perform Steps (2) through (4) below and repair two valve bank (Para 16-28).
 - (2) Set crane POWER switch to OFF position.
 - (3) Set hydraulic selector switch to OFF position.
 - (4) Turn OFF ENGINE switch.



2. LH OUTRIGGER DOES NOT OPERATE (CONT).



WARNING



- High pressure hydraulics [oil under 3000 psi (20,675 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION


- (1) Remove two valve bank from crane (Para 16-28).
- (2) Remove control valves from two valve bank body (Para 16-28).
- (3) Remove orifice from LH O/R JACK valve (Para 16-28).
 - (a) If orifice is clogged or damaged, replace orifice (Para 16-28).
 - (b) If orifice is OK, repair LH O/R JACK valve (Para 16-28) and perform Steps (4) and (5) below.
- (4) Assemble two valve bank (Para 16-28).
- (5) Install two valve bank on crane (Para 16-28).




2. LH OUTRIGGER DOES NOT OPERATE (CONT).




- | VERIFY REPAIR |
|---|
| <ol style="list-style-type: none"> (1) Start engine (TM 9-2320-364-10). (2) Set hydraulic selector switch to CRANE/SRW position. (3) Turn ON crane POWER switch. (4) Operate LH outrigger using LH O/R JACK control levers on both LH and RH sides of truck. <ol style="list-style-type: none"> (a) If LH outrigger does not operate fault not corrected. Perform Steps (5) through (7) below and notify supervisor. (b) If LH outrigger operates, fault has been corrected. (5) Set crane POWER switch to OFF position. (6) Set hydraulic selector switch to OFF position. (7) Turn OFF ENGINE switch. |



LH O/R JACK CONTROL LEVER




LH OUTRIGGER



LH O/R JACK CONTROL LEVER

HYDRAULIC SELECTOR SWITCH



ENGINE SWITCH

STEERING WHEEL SHOWN REMOVED FOR CLARITY

2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

3. RH OUTRIGGER DOES NOT OPERATE.

INITIAL SETUP

Tools and Special Tools


Tool Kit, General Mechanic's
(Item 240, Appendix F)


References

TM 9-2320-364-10

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
Parking brake applied, (TM 9-2320-364-10)
Wheels chocked, (TM 9-2320-364-10)






OPERATION TEST

Operate RH outrigger using
RH O/R JACK control lever on LH
side of truck (TM 9-2320-364-10).

- (1) If RH outrigger does not operate,
go to Step 4 of this Fault.
- (2) If RH outrigger operates,
go to Step 2 of this Fault.




3. RH OUTRIGGER DOES NOT OPERATE (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. LH outrigger operates. Two valve bank OK. RH outrigger cylinder OK.
POSSIBLE PROBLEMS
Three valve bank faulty.


2.

Does RH outrigger operate using RH O/R JACK control lever on RH side of truck with LH O/R JACK control lever in up position?


TEST OPTIONS
Operation test.
REASON FOR QUESTION
If three valve bank check valve is faulty, pump compensator will not receive load sense pressure from RH O/R JACK valve and will receive load sense pressure from LH O/R JACK valve.



OPERATION TEST
<p>(1) Operate RH outrigger using RH O/R JACK control lever on RH side of truck while holding LH O/R JACK control lever in UP position (TM 9-2320-364-10).</p> <p>(a) If RH outrigger does not operate with RH O/R JACK control lever in UP position, perform Steps (2) through (4) below and go to Step 3 of this Fault.</p> <p>(b) If RH outrigger operates, check valve in three valve bank is faulty. Perform Steps (2) through (4) below and repair three valve bank (Para 16-27).</p> <p>(2) Set crane POWER switch to OFF position.</p> <p>(3) Set hydraulic selector switch to OFF position.</p> <p>(4) Turn OFF ENGINE switch.</p>



3. RH OUTRIGGER DOES NOT OPERATE (CONT).



WARNING



- High pressure hydraulics [oil under 3000 psi (20,675 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Remove three valve bank from crane (Para 16-27).
- (2) Remove valves from three valve bank body (Para 16-27).
- (3) Remove orifice from RH O/R JACK valve (Para 16-27).
 - (a) If orifice is clogged or damaged, clean or replace orifice (Para 16-27) and perform Steps (4) and (5) below.
 - (b) If orifice is OK, repair RH O/R JACK valve (Para 16-27) and perform Steps (4) and (5) below.
- (4) Assemble three valve bank (Para 16-27).
- (5) Install three valve bank on crane (Para 16-27).




3. RH OUTRIGGER DOES NOT OPERATE (CONT).








OPERATION TEST

- (1) Operate RH outrigger using RH O/R JACK control lever on RH side of truck (TM 9-2320-364-10).
 - (a) If RH outrigger does not operate, Perform Steps (2) through (4) below and replace outrigger cylinder (Para 16-31).
 - (b) If RH outrigger operates, go to Step 5 of this Fault.
- (2) Set crane POWER switch to OFF position.
- (3) Set hydraulic selector switch to OFF position.
- (4) Turn OFF ENGINE switch.



3. RH OUTRIGGER DOES NOT OPERATE (CONT).






OPERATION TEST

- (1) Operate RH outrigger using RH O/R JACK control lever on LH side of truck while holding LH O/R JACK control lever in UP position (TM 9-2320-364-10).
 - (a) If RH outrigger does not operate with LH O/R JACK control lever in UP position, perform Steps (2) through (4) below and go to Step 6 of this Fault.
 - (b) If RH outrigger operates, check valve in two valve bank is faulty. Perform Steps (2) through (4) below and repair two valve bank (Para 16-28).
- (2) Set crane POWER switch to OFF position.
- (3) Set hydraulic selector switch to OFF position.
- (4) Turn OFF ENGINE switch.

3. RH OUTRIGGER DOES NOT OPERATE (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,675 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.


VISUAL INSPECTION

- (1) Remove two valve bank from crane (Para 16-28).
- (2) Remove control valves from two valve bank body (Para 16-28).
- (3) Remove orifice from RH O/R JACK valve (Para 16-28).
 - (a) If orifice is clogged or damaged, clean or replace orifice (Para 16-28) and perform Steps (4) and (5) below.
 - (b) If orifice is OK, repair RH O/R JACK valve (Para 16-28) and perform Steps (4) and (5) below.
- (4) Assemble two valve bank (Para 16-28).
- (5) Install two valve bank on crane (Para 16-28).






3. RH OUTRIGGER DOES NOT OPERATE (CONT).





- VERIFY REPAIR**
- (1) Start engine (TM 9-2320-364-10).
 - (2) Set hydraulic selector switch to CRANE/SRW position.
 - (3) Turn ON crane POWER switch.
 - (4) Operate RH outrigger using RH O/R JACK control levers on both LH and RH sides of truck.
 - (a) If RH outrigger does not operate, fault not corrected. Perform Steps (5) through (7) below and notify supervisor.
 - (b) If RH outrigger operates, fault has been corrected.
 - (5) Set crane POWER switch to OFF position.
 - (6) Set hydraulic selector switch to OFF position.
 - (7) Turn OFF ENGINE switch.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

4. FOUR VALVE BANK FUNCTIONS (SWING, LIFT, TELESCOPE AND HOIST) DO NOT OPERATE OR OPERATE SLOWLY.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
(Item 240, Appendix F)

Materials/Parts


Wire, Nonelectrical (Item 79, Appendix B)

References

TM 9-2320-364-10


Equipment Condition

Engine OFF, (TM 9-2320-364-10)
Parking brake applied, (TM 9-2320-364-10)
Wheels chocked, (TM 9-2320-364-10)
Outriggers down with weight off
vehicle suspension, (TM 9-2320-364-10)




OPERATION TEST

- (1) Remove safety wire from MHC SYSTEM HYDRAULIC PRESSURE MANUAL OVERRIDE push button (TM 9-2320-364-10).
- (2) Push in manual override push button.
 - (a) If manual push button cannot be pushed in, repair solenoid valve assembly (Para 16-34).
 - (b) If manual push button can be pushed in, go to Step 2 of this Fault.





4. FOUR VALVE BANK FUNCTIONS DO NOT OPERATE OR OPERATE SLOWLY (CONT).





OPERATION TEST

- (1) Start engine (TM 9-2320-364-10).
- (2) Set WINCH/CRANE switch to CRANE position.
- (3) Set hydraulic selector switch to CRANE/SRW position.
- (4) Operate one of the four functions on the four valve bank while pushing in the MHC SYSTEM HYDRAULIC PRESSURE VALVE MANUAL OVERRIDE push button.
 - (a) If function does not operate, solenoid valve assembly and four valve bank are suspect. Perform Steps (5) through (8) below and go to Step 3 of this Fault.
 - (b) If function operates, system hydraulic pressure valve is faulty. Perform Steps (5) through (8) below and repair solenoid valve assembly (Para 16-34).
- (5) Set crane POWER switch to OFF position.
- (6) Set hydraulic selector switch to OFF position.
- (7) Turn OFF ENGINE switch.
- (8) Install safety wire on MHC SYSTEM HYDRAULIC PRESSURE MANUAL OVERRIDE push button.





4. FOUR VALVE BANK FUNCTIONS DO NOT OPERATE OR OPERATE SLOWLY (CONT).






OPERATION TEST
<p>(1) Operate one of the four functions (SWING, TELE, BOOM, HOIST) on the four valve bank while holding LH or RH O/R JACK control lever in the DOWN position (TM 9-2320-364-10).</p> <p>(a) If function does not operate, perform Steps (2) through (4) below and repair solenoid valve assembly (Para 16-34).</p> <p>(b) If function operates, perform Steps (2) through (4) below and repair four valve bank center manifold (Para 16-26).</p> <p>(2) Set crane POWER switch to OFF position.</p> <p>(3) Set hydraulic selector switch to OFF position.</p> <p>(4) Turn OFF ENGINE switch.</p>






4. FOUR VALVE BANK FUNCTIONS DO NOT OPERATE OR OPERATE SLOWLY (CONT).



VERIFY REPAIR

- (1) Start engine (TM 9-2320-364-10).
- (2) Set WINCH/CRANE switch to CRANE position.
- (3) Set hydraulic selector switch to CRANE/SRW position.
- (4) Operate the four functions on the four valve bank.
 - (a) If functions do not operate, fault not corrected. Perform Steps (5) through (7) below and notify supervisor.
 - (b) If functions operate, fault has been corrected.
- (5) Set crane POWER switch to OFF position.
- (6) Set hydraulic selector switch to OFF position.
- (7) Turn OFF ENGINE switch.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

5. MAST DOES NOT OPERATE OR OPERATES SLOWLY.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Cap and Plug Set (Item 26, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)

Personnel Required

Two

References


TM 9-2320-364-10
 TM 9-2320-364-20

Materials/Parts

Oil, Hydraulics (Item 34, Appendix B)
 Tags, Identification (Item 72, Appendix B)
 Preformed Packing (2) (Item 336, Appendix E)
 Preformed Packing (5) (Item 337, Appendix E)
 Preformed Packing (3) (Item 389, Appendix E)

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)
 Outriggers down with weight off
 vehicle suspension, (TM 9-2320-364-10)



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOW/PRESSURE TEST

- (1) Tag, mark and disconnect hose from fitting at bottom of MAST valve. Discard preformed packing.
- (2) Plug hose with metal plug.
- (3) Tag, mark and disconnect hose from elbow at bottom of MAST valve. Discard preformed packing.
- (4) Plug hose with metal plug.
- (5) Connect adapter hose with preformed packing to elbow.
- (6) Connect adapter hose to flowmeter OUT port.
- (7) Connect adapter hose with preformed packing to fitting.
- (8) Connect adapter hose to flowmeter IN port.
- (9) Open flowmeter load valve.
- (10) Start engine (TM 9-2320-364-10).
- (11) Set WINCH/CRANE switch to CRANE position.
- (12) Set hydraulic selector switch to CRANE/SRW position.
- (13) Set crane POWER switch to ON position.
- (14) Hold MAST control lever in UP position.
 - (a) If 6 gpm (23 lpm) or more are not present, perform Steps (15) through (20) below and replace MAST valve on three valve bank (Para 16-27).
 - (b) If at least 6 gpm (23 lpm) are present, three valve bank is OK.
- (15) Set crane POWER switch to OFF position.
- (16) Set hydraulics selector switch to OFF position.
- (17) Turn OFF ENGINE switch.
- (18) Disconnect adapter hoses from elbow and fitting. Discard preformed packings.
- (19) Remove plugs from hoses.
- (20) Connect two hoses with preformed packings to elbow and fitting.






5. MAST DOES NOT OPERATE OR OPERATES SLOWLY (CONT).




OPERATION TEST

- (1) Operate crane mast using MAST control lever (TM 9-2320-364-10).
 - (a) If mast does not operate, perform Steps (2) through (4) below and go to Step 7 of this Fault.
 - (b) If mast operates slowly, perform Steps (2) through (4) below and go to Step 3 of this Fault.
- (2) Set crane POWER switch to OFF position.
- (3) Set hydraulic selector switch to OFF position.
- (4) Turn OFF ENGINE switch.



5. MAST DOES NOT OPERATE OR OPERATES SLOWLY (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Tag, mark and disconnect hose from fitting at bottom of MAST four way valve. Discard preformed packing.
- (2) Connect adapter hose with preformed packing to disconnected hose.
- (3) Connect adapter hose to flowmeter OUT port.
- (4) Connect adapter hose with preformed packing to fitting.
- (5) Connect adapter hose to flowmeter IN port.
- (6) Open flowmeter load valve.
- (7) Start engine (TM 9-2320-364-10).
- (8) Set WINCH/CRANE switch to CRANE.
- (9) Set hydraulic selector switch to CRANE/SRW position.
- (10) Turn ON crane POWER switch.
- (11) Raise mast completely using MAST control lever.
- (12) Hold MAST control lever in UP position while observing flowmeter.
 - (a) If more than 0 gpm (0 lpm) are present, lift cylinder piston seals are faulty. Perform Steps (13) through (19) below and replace erection cylinder (Para 16-5).
 - (b) If 0 gpm (0 lpm) are present, lift cylinder piston seals are OK.
- (13) Set crane POWER switch to OFF position.
- (14) Set hydraulic selector switch to OFF position.
- (15) Turn OFF ENGINE switch.
- (16) Disconnect adapter hose from crane hose. Discard preformed packing.
- (17) Disconnect adapter hose from fitting. Discard preformed packing.
- (18) Lubricate preformed packing.
- (19) Connect crane hose with preformed packing to fitting.






5. MAST DOES NOT OPERATE OR OPERATES SLOWLY (CONT).




OPERATION TEST

- (1) Operate crane mast using MAST control lever (TM 9-2320-364-10).
 - (a) If mast operates slowly in both directions, perform Steps (2) through (4) below and go to Step 5 of this Fault.
 - (b) If mast operates slowly in one direction and normally in the other, cylinder is faulty. Replace erection cylinder (Para 16-5).
- (2) Set crane POWER switch to OFF position.
- (3) Set hydraulic selector switch to OFF position.
- (4) Turn OFF ENGINE switch.



5. MAST DOES NOT OPERATE OR OPERATES SLOWLY (CONT).



WARNING




- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.


VISUAL INSPECTION

- (1) Disconnect hose from elbow at port P of cylinder. Discard preformed packing.
- (2) Remove elbow from adapter at port P of cylinder. Discard preformed packing.
- (3) Remove adapter from cylinder port P. Discard preformed packing.
 - (a) If orifice in adapter is clogged or damaged, clean or replace adapter and perform Steps (4) through (6) below.
 - (b) If orifice is OK, perform Steps (4) through (6) below and go to Step 6 of this Fault.
- (4) Install adapter with preformed packing on cylinder.
- (5) Install elbow with preformed packing on adapter.
- (6) Connect hose with preformed packing on elbow.






5. MAST DOES NOT OPERATE OR OPERATES SLOWLY (CONT).






OPERATION TEST

- (1) Remove two screws, washers and bushings from lockpins and boom.
- (2) Remove two lock pins from pivot pin.
- (3) With aid of assistant, drive pivot pin out of boom and tension link only enough so that tension link can be removed from boom. Do not drive pivot pin through mast.
- (4) Operate mast using MAST control lever.
 - (a) If mast does not operate normally, replace erection cylinder (Para 16-5).
 - (b) If mast does operate normally, replace tension link (Para 16-8).



5. MAST DOES NOT OPERATE OR OPERATES SLOWLY (CONT).




WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST	
(1)	Tag, mark and disconnect hose from fitting at bottom of MAST four way valve. Discard preformed packing.
(2)	Connect adapter hose with preformed packing to disconnected hose.
(3)	Connect adapter hose to flowmeter OUT port.
(4)	Connect adapter hose with preformed packing to fitting.
(5)	Connect adapter hose to flowmeter IN port.
(6)	Open flowmeter load valve.
(7)	Start engine (TM 9-2320-364-10).
(8)	Set WINCH/CRANE switch to CRANE position.
(9)	Set hydraulic selector switch to CRANE/SRW position.
(10)	Turn ON crane POWER switch.
(11)	Hold MAST control lever in UP position while observing flowmeter. <ul style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are present, perform Steps (12) through (17) and replace erection cylinder (Para 16-5). (b) If 0 gpm (0 lpm) are present, cylinder piston seals are OK.
(12)	Set crane POWER switch to OFF position.
(13)	Set hydraulic selector switch to OFF position.
(14)	Turn OFF ENGINE switch.
(15)	Disconnect adapter hose from crane hose. Discard preformed packing.
(16)	Disconnect adapter hose from fitting. Discard preformed packing.
(17)	Connect crane hose with preformed packing to fitting.



5. MAST DOES NOT OPERATE OR OPERATES SLOWLY (CONT).



WARNING




- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.


VISUAL INSPECTION

- (1) Disconnect hose from elbow at port P of cylinder. Discard preformed packing.
- (2) Remove elbow from adapter at port P of cylinder. Discard preformed packing.
- (3) Remove adapter from cylinder port P. Discard preformed packing.
 - (a) If orifice in adapter is clogged or damaged, clean or replace adapter and perform Steps (4) through (6) below.
 - (b) If orifice is OK, perform Steps (4) through (6) below and go to Step 9 of this Fault.
- (4) Install adapter with preformed packing on cylinder.
- (5) Install elbow with preformed packing on adapter.
- (6) Connect hose with preformed packing on elbow.






5. MAST DOES NOT OPERATE OR OPERATES SLOWLY (CONT).







OPERATION TEST

- (1) Remove two screws, washers, bushings from lockpins and boom.
- (2) Remove two lock pins from pivot pin.
- (3) With aid of assistant, drive pivot pin out of boom and tension link only enough so that tension link can be removed from boom. Do not drive pivot pin through mast.
- (4) Operate mast using MAST control lever.
 - (a) If mast does not operate normally, replace erection cylinder (Para 16-5).
 - (b) If mast does not operate normally, replace tension link (Para 16-8).





5. MAST DOES NOT OPERATE OR OPERATES SLOWLY (CONT).





VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Operate crane mast using MAST control lever.
 - (a) If mast does not operate, fault not corrected. Perform Steps (3) through (5) below and notify supervisor.
 - (b) If mast operates, fault has been corrected.
- (3) Set crane POWER switch to OFF position.
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

6. MAST DOES NOT RAISE.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Cap and Plug Set (Item 26, Appendix F)
- Pan, Drain 4 gal (Item 144, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)

Materials/Parts


- Oil, Hydraulic (Item 34, Appendix B)
- Tags, Identification (Item 72, Appendix B)
- Packing, Preformed (5) (Item 337, Appendix E)
- Packing, Preformed (2) (Item 389, Appendix E)

References

- TM 9-2320-364-10
- TM 9-2320-364-20

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Outriggers down with weight off vehicle suspension, (TM 9-2320-364-10)




WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOW/PRESSURE TEST	
(1)	Tag, mark and disconnect hose from fitting at bottom of MAST control valve. Discard preformed packing.
(2)	Plug hose with metal plug.
(3)	Tag, mark and disconnect hose from elbow at bottom of MAST control valve. Discard preformed packing.
(4)	Plug hose with metal plug.
(5)	Connect adapter hose with preformed packing to elbow.
(6)	Connect adapter hose to flowmeter OUT port.
(7)	Connect adapter hose with preformed packing to fitting.
(8)	Connect adapter hose to flowmeter IN port.
(9)	Open flowmeter load valve.
(10)	Start engine (TM 9-2320-364-10).
(11)	Set WINCH/CRANE switch to CRANE position.
(12)	Set hydraulic selector switch to CRANE/SRW position.
(13)	Set crane POWER switch to ON position.
(14)	Hold MAST control lever in UP position. <ul style="list-style-type: none"> (a) If 6 gpm (23 lpm) or more are not present, perform Steps (15) through (20) below and replace MAST valve on three valve bank (Para 16-27). (b) If at least 6 gpm (23 lpm) are present, three valve bank is OK.
(15)	Set crane POWER switch to OFF position.
(16)	Set hydraulics selector switch to OFF position.
(17)	Turn OFF ENGINE switch.
(18)	Disconnect adapter hoses from elbow and fitting. Discard preformed packings.
(19)	Remove metal plugs from two hoses.
(20)	Connect two hoses with preformed packings to elbow and fitting.



6. MAST DOES NOT RAISE (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST




- (1) Tag, mark and disconnect hose from fitting at bottom of MAST four way valve. Discard preformed packing.
- (2) Connect adapter hose with preformed packing to disconnected hose.
- (3) Connect adapter hose to flowmeter OUT port.
- (4) Connect adapter hose with preformed packing to fitting.
- (5) Connect adapter hose to flowmeter IN port.
- (6) Open flowmeter load valve.
- (7) Start engine (TM 9-2320-364-10).
- (8) Set WINCH/CRANE switch to CRANE position.
- (9) Set hydraulic selector switch to CRANE/SRW position.
- (10) Raise mast completely using MAST control lever.
- (11) Hold MAST control lever in UP position while observing flowmeter.
 - (a) If more than 0 gpm (0 lpm) are present, perform Steps (12) through (17) below and replace erection cylinder (Para 16-5).
 - (b) If 0 gpm (0 lpm) are present, cylinder piston seals are OK. Fault not corrected. Perform Steps (12) through (17) below and notify supervisor.
- (12) Set crane POWER switch to OFF position.
- (13) Set hydraulic selector switch to OFF position.
- (14) Turn OFF ENGINE switch.
- (15) Disconnect adapter hose from crane hose. Discard preformed packing.
- (16) Disconnect adapter hose from fitting. Discard preformed packing.
- (17) Connect crane hose with preformed packing to fitting.



6. MAST DOES NOT RAISE (CONT).



VERIFY REPAIR
<p>(1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).</p> <p>(2) Operate crane mast using MAST control lever (TM 9-2320-364-10).</p> <p style="padding-left: 20px;">(a) If mast does not raise, fault not corrected. Perform Steps (3) through (5) below and notify supervisor.</p> <p style="padding-left: 20px;">(b) If mast raises, fault has been corrected.</p> <p>(3) Set crane POWER switch to OFF position.</p> <p>(4) Set hydraulic selector switch to OFF position.</p> <p>(5) Turn OFF ENGINE switch.</p>



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

7. MAST DOES NOT LOWER.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's (Item 240, Appendix F)
 Cap and Plug Set (Item 26, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)

Materials/Parts


Oil, Hydraulic (Item 34, Appendix B)
 Tags, Identification (Item 72, Appendix B)
 Packing, Preformed (5) (Item 337, Appendix E)
 Packing, Preformed (2) (Item 389, Appendix E)

References

TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)
 Outriggers down with weight off vehicle suspension, (TM 9-2320-364-10)



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOW/PRESSURE TEST

- (1) Tag, mark and disconnect hose from fitting at bottom of MAST valve. Discard preformed packing.
- (2) Plug hose with metal plug.
- (3) Tag, mark and disconnect hose from elbow at bottom of MAST valve. Discard preformed packing.
- (4) Plug hose with metal plug.
- (5) Connect adapter hose with preformed packing to elbow.
- (6) Connect adapter hose to flowmeter IN port.
- (7) Connect adapter hose with preformed packing to fitting.
- (8) Connect adapter hose to flowmeter OUT port.
- (9) Open flowmeter load valve.
- (10) Start engine (TM 9-2320-364-10).
- (11) Set WINCH/CRANE switch to CRANE position.
- (12) Set hydraulic selector switch to CRANE/SRW position.
- (13) Set crane POWER switch to ON position.
- (14) Hold MAST control lever in DOWN position.
 - (a) If 6 gpm (23 lpm) or more are not present, perform Steps (15) through (20) below and replace MAST valve on three valve bank (Para 16-27).
 - (b) If at least 6 gpm (23 lpm) are present, three valve bank is OK.
- (15) Set crane POWER switch to OFF position.
- (16) Set hydraulics selector switch to OFF position.
- (17) Turn OFF ENGINE switch.
- (18) Disconnect adapter hoses from elbow and fitting. Discard preformed packings.
- (19) Remove metal plugs from two hoses.
- (20) Connect two hoses with preformed packings to elbow and fitting.



7. MAST DOES NOT LOWER (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.


FLOWMETER TEST

- (1) Tag, mark and disconnect hose from fitting at bottom of MAST valve. Discard preformed packing.
- (2) Connect adapter hose with preformed packing to disconnected hose.
- (3) Connect adapter hose to flowmeter IN port.
- (4) Connect adapter hose with preformed packing to fitting.
- (5) Connect adapter hose to flowmeter OUT port.
- (6) Open flowmeter load valve.
- (7) Start engine (TM 9-2320-364-10).
- (8) Set WINCH/CRANE switch to CRANE position.
- (9) Set hydraulic selector switch to CRANE/SRW position.
- (10) Turn ON crane POWER switch.
- (11) Hold MAST control lever in DOWN position while observing flowmeter.
 - (a) If more than 0 gpm (0 lpm) are present, perform Steps (12) through (17) below and replace erection cylinder (Para 16-5).
 - (b) If 0 gpm (0 lpm) are present, cylinder piston seals are OK. Fault not corrected. Perform Steps (12) through (17) below and notify supervisor.
- (12) Set crane POWER switch to OFF position.
- (13) Set hydraulic selector switch to OFF position.
- (14) Turn OFF ENGINE switch.
- (15) Disconnect adapter hose from crane hose. Discard preformed packing.
- (16) Disconnect adapter hose from fitting. Discard preformed packing.
- (17) Connect crane hose with preformed packing to fitting.





7. MAST DOES NOT LOWER (CONT).





VERIFY REPAIR
<ol style="list-style-type: none"> (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20). (2) Operate crane mast using MAST control lever (TM 9-2320-364-10). <ol style="list-style-type: none"> (a) If mast does not lower, fault not corrected. Perform Steps (3) through (5) below and notify supervisor. (b) If mast lowers, fault has been corrected. (3) Set crane POWER switch to OFF position. (4) Set hydraulic selector switch to OFF position. (5) Turn OFF ENGINE switch.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

8. CRANE DOES NOT SWING OR SWINGS SLOWLY.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Cap and Plug Set (Item 26, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)

Personnel Required

Two

References


TM 9-2320-364-10
 TM 9-2320-364-20

Materials/Parts


Oil, Hydraulic (Item 34, Appendix B)
 Tags, Identification (Item 72, Appendix B)
 Lockwasher (2) (Item 269, Appendix E)
 Lockwasher (4) (Item 282, Appendix E)
 Packing, Preformed (9) (Item 347, Appendix E)
 Packing, Preformed (8) (Item 389, Appendix E)

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)
 Outriggers down with weight off
 vehicle suspension, (TM 9-2320-364-10)





STEERING WHEEL SHOWN
REMOVED FOR CLARITY




OPERATION TEST

- (1) Start engine (TM 9-2320-364-10).
- (2) Set WINCH/CRANE switch to CRANE position.
- (3) Set hydraulic selector switch to CRANE/SRW position.
- (4) Set crane POWER switch to ON position.
- (5) Attempt to swing crane using SWING control lever while holding TELE control lever in the IN position.
 - (a) If crane does not swing, perform Steps (6) through (8) below and go to Step 2 of this Fault.
 - (b) If crane swings, check valve in four valve bank tele/swing manifold is faulty. Perform Steps (6) through (8) below and repair four valve bank (Para 16-26).
- (6) Set crane POWER switch to OFF position.
- (7) Set hydraulic selector switch to OFF position.
- (8) Turn OFF ENGINE switch.



8. CRANE DOES NOT SWING OR SWINGS SLOWLY (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Remove four nuts, lockwashers, screws and washers and cover from crane. Discard lockwashers.
- (2) Tag, mark and disconnect two hoses from elbows at left side of four valve bank. Discard preformed packings.
- (3) Plug hoses with metal plugs.
- (4) Connect adapter hose with preformed packing to inboard (smaller) elbow.
- (5) Connect adapter hose to flowmeter OUT port.
- (6) Connect adapter hose with preformed packing to outboard (taller) elbow.
- (7) Connect adapter hose to flowmeter IN port.
- (8) Open flowmeter load valve.
- (9) Start engine (TM 9-2320-364-10).
- (10) Set WINCH/CRANE switch to CRANE position.
- (11) Set hydraulic selector switch to CRANE/SRW position.
- (12) Set crane POWER switch to ON position.
- (13) Hold SWING control lever in CW and CCW positions and observe flowmeter.
 - (a) If 4 gpm (15 lpm) or more are not present, perform Steps (14) through (19) below and go to Step 7 of this Fault.
 - (b) If at least 4 gpm (15 lpm) are present, perform Steps (14) through (19) below and go to Step 3 of this Fault.
- (14) Set crane POWER switch to OFF position.
- (15) Set hydraulic selector switch to OFF position.
- (16) Turn OFF ENGINE switch.
- (17) Disconnect adapter hoses from elbows. Discard preformed packings.
- (18) Remove plugs from hoses.
- (19) Connect two hoses with preformed packings to elbows.



8. CRANE DOES NOT SWING OR SWINGS SLOWLY (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

PRESSURE TEST

- (1) Tag, mark and disconnect hose from taller elbow at left of four valve bank. Discard preformed packing.
- (2) Connect flowmeter IN port adapter hose with preformed packing to elbow.
- (3) Connect flowmeter OUT port adapter hose with preformed packing to disconnected crane hose.
- (4) Open flowmeter load valve.
- (5) Start engine (TM 9-2320-364-10).
- (6) Set WINCH/CRANE switch to CRANE position.
- (7) Set hydraulic selector switch to CRANE/SRW position.
- (8) Set crane POWER switch to ON position.
- (9) Hold SWING control lever in CW position and observe flowmeter.
 - (a) If a minimum of 1800 psi (12,411 kPa) are not present, perform Steps (10) through (14) below and repair swing motor valve (Para 16-19).
 - (b) If 1800 psi (12,411 kPa) or more are present, perform Steps (10) through (14) below and go to Step 4 of this Fault.
- (10) Set crane POWER switch to OFF position.
- (11) Set hydraulic selector switch to OFF position.
- (12) Turn OFF ENGINE switch.
- (13) Disconnect adapter hoses from elbow and hose. Discard preformed packings.
- (14) Connect crane hose with preformed packing to elbow.



8. CRANE DOES NOT SWING OR SWINGS SLOWLY (CONT).





WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.

OPERATION TEST	
(1)	Tag, mark and disconnect two hoses from swing motor valve. Discard preformed packings.
(2)	Connect adapter hoses with preformed packings to swing motor hoses.
(3)	Connect adapter hoses with preformed packings to swing motor.
(4)	Disconnect tube from swing motor valve assembly. Discard preformed packings.
(5)	With aid of assistant, remove two screws, lockwashers and swing motor from swing drive gear reducer. Discard lockwashers.
(6)	Install cap on swing brake motor valve assembly where tube was removed from.
(7)	Start engine (TM 9-2320-364-10).
(8)	Set WINCH/CRANE switch to CRANE position.
(9)	Set hydraulic selector switch to CRANE/SRW position.
(10)	Set crane POWER switch to ON position.
(11)	Operate swing motor using SWING control lever. <ul style="list-style-type: none"> (a) If swing motor does not operate, perform Steps (12) through (14) below and go to Step 5 of this Fault. (b) If swing motor operates, perform Steps (12) through (14) below and go to Step 6 of this Fault.
(12)	Set crane POWER switch to OFF position.
(13)	Set hydraulic selector switch to OFF position.
(14)	Turn OFF ENGINE switch.



8. CRANE DOES NOT SWING OR SWINGS SLOWLY (CONT).




WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION
(1) Disconnect adapter hoses from swing motor valve and from crane hoses. Discard preformed packings.
(2) Remove swing motor valve from swing motor (Para 16-19).
(3) Disassemble swing motor valve assembly (Para 16-19). <ul style="list-style-type: none"> (a) If valve assembly is damaged or clogged, repair swing motor valve (Para 16-19). (b) If swing motor valve is OK, swing motor is faulty. Replace swing motor (Para 16-19) and perform Steps (4) through (9) below.
(4) Assemble swing motor valve (Para 16-19).
(5) Install swing motor valve on swing motor (Para 16-19).
(6) Remove cap from swing motor valve assembly. Discard preformed packing.
(7) Install swing motor on swing drive gear reducer with two lockwashers and screws.
(8) Install two hoses with preformed packings on swing motor valve.
(9) Install tube with preformed packing on swing motor valve.



8. CRANE DOES NOT SWING OR SWINGS SLOWLY (CONT).






WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use a drain pan to catch leaking hydraulic oil.

PRESSURE TEST
<ol style="list-style-type: none"> (1) Remove cap from swing motor valve elbow. Discard preformed packing. (2) Connect pressure gage with preformed packing to elbow. (3) Start engine (TM 9-2320-364-10). (4) Set WINCH/CRANE switch to CRANE position. (5) Set hydraulic selector switch to CRANE/SRW position. (6) Set crane POWER switch to ON position. (7) Operate swing motor using SWING control lever. <ol style="list-style-type: none"> (a) If 1800 psi (12,411 kPa) or more are not present, repair swing motor valve (Para 16-19) and perform Steps (8) through (15) below. (b) If 1800 psi (12,411 kPa) or more are present, swing brake is faulty. Perform Steps (8) through (15) below and notify supervisor. <p style="text-align: right;"><i>Continued on next page.</i></p>



8. CRANE DOES NOT SWING OR SWINGS SLOWLY (CONT).

WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

PRESSURE TEST (CONT).

- (8) Set crane POWER switch to OFF position.
- (9) Set hydraulic selector switch to OFF position.
- (10) Turn OFF ENGINE switch.
- (11) Disconnect pressure gage from elbow. Discard preformed packing.
- (12) Disconnect two adapter hoses from swing motor valve and crane hoses. Discard preformed packings.
Continued on next page.




SWING MOTOR VALVE



ELBOW

PRESSURE GAGE

PREFORMED PACKING



SWING CONTROL LEVER

CRANE POWER SWITCH

WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use a drain pan to catch leaking hydraulic oil.

PRESSURE TEST (CONT).

- (13) Install swing motor on swing drive gear reducer with two lockwashers and screws.
- (14) Install two hoses with preformed packings on swing motor valve.
- (15) Install tube with preformed packing on swing motor valve.




8. CRANE DOES NOT SWING OR SWINGS SLOWLY (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. Outriggers operate. Telescope operates. Loss of output from SWING four way valve.
POSSIBLE PROBLEMS
Four valve bank faulty.

7.

Is orifice between SWING valve and tele/swing manifold free of contaminants clogging it?

TEST OPTIONS
Visual inspection.
REASON FOR QUESTION
If orifice in four valve bank is faulty, pressure and flow supplied to SWING valve will be restricted.



WARNING




- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION


- (1) Remove four valve bank from crane (Para 16-26).
- (2) Remove SWING valve from four valve bank (Para 16-26).
- (3) Remove orifice from four valve bank where SWING valve was removed from.
- (4) Inspect orifice for contamination clogging it.
 - (a) If orifice is contaminated, clean or replace orifice and inspect bores in four valve bank for additional contamination (Para 16-26).
 - (b) If orifice is OK, repair SWING valve (Para 16-33).
- (5) Install orifice on four valve bank (Para 16-26).
- (6) Install SWING valve on four valve bank (Para 16-26).
- (7) Install four valve bank on crane (Para 16-26).






8. CRANE DOES NOT SWING OR SWINGS SLOWLY (CONT).



STEERING WHEEL SHOWN
REMOVED FOR CLARITY



VERIFY REPAIR	
(1)	Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
(2)	Start engine (TM 9-2320-364-10).
(3)	Set WINCH/CRANE switch to CRANE position.
(4)	Set hydraulic selector switch to CRANE/SRW position.
(5)	Set crane POWER switch to ON position.
(6)	Swing crane using SWING control lever. <ul style="list-style-type: none"> (a) If crane does not swing, fault not corrected. Perform Steps (7) through (10) below and notify supervisor. (b) If crane does swing, fault has been corrected.
(7)	Set crane POWER switch to OFF position.
(8)	Set hydraulic selector switch to OFF position.
(9)	Turn OFF ENGINE switch.
(10)	Install cover with four screws, washers, lockwashers and nuts on crane.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

9. CRANE DOES NOT SWING CLOCKWISE (CW).

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Cap and Plug Set (Item 26, Appendix F)
- Pan, Drain 4 gal (Item 144, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)

Materials/Parts


- Oil, Hydraulic (Item 34, Appendix B)
- Tags, Identification (Item 72, Appendix B)
- Lockwasher (4) (Item 282, Appendix E)
- Packings, Preformed (11) (Item 347, Appendix E)
- Packings, Preformed (3) (Item 389, Appendix E)

References

- TM 9-2320-364-10
- TM 9-2320-364-20

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Outriggers down with weight off vehicle suspension, (TM 9-2320-364-10)





WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.



NOTE

Use a drain pan to catch leaking hydraulic oil.




OPERATION TEST	
(1)	Remove four nuts, lockwashers, washers and nuts and cover. Discard lockwashers.
(2)	Tag, mark and disconnect two hoses from two elbows at left of four valve bank. Discard preformed packings.
(3)	Connect each removed hose with preformed packing to the elbow the other was removed from (cross them).
(4)	Start engine (TM 9-2320-364-10).
(5)	Set WINCH/CRANE switch to CRANE position.
(6)	Set hydraulic selector switch to CRANE/SRW position.
(7)	Set crane POWER switch to ON position.
(8)	Swing crane CW by moving SWING control lever to CCW position. <ul style="list-style-type: none"> (a) If crane does not swing, perform Steps (9) through (13) below and go to Step 2 of this Fault. (b) If crane does swing, perform Steps (9) through (11) below and replace SWING valve on four valve bank (Para 16-26).
(9)	Set crane POWER switch to OFF position.
(10)	Set hydraulic selector switch to OFF position.
(11)	Turn OFF ENGINE switch.
(12)	Disconnect two hoses from elbows. Discard preformed packings.
(13)	Install hoses with preformed packings on elbows using tags and marks to install correctly.

STEERING WHEEL SHOWN REMOVED FOR CLARITY



9. CRANE DOES NOT SWING CW (CONT).



WARNING


- High pressure hydraulics [oil under 3,000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

PRESSURE TEST

- (1) Disconnect hose from outboard (taller) elbow at left of four valve bank. Discard preformed packing.
- (2) Disconnect hose from inboard (shorter) elbow at left of four valve bank. Discard preformed packing.
- (3) Connect adapter hose to flowmeter IN port.
- (4) Connect IN port adapter hose with preformed packing to outboard (taller) elbow.
- (5) Connect adapter hose to flowmeter OUT port.
- (6) Connect OUT port adapter hose with preformed packing to crane hose disconnected from outboard (taller) elbow.
- (7) Connect hose to inboard (shorter) elbow.
- (8) Start engine (TM 9-2320-364-10).
- (9) Set WINCH/CRANE switch to CRANE position.
- (10) Set hydraulic selector switch to CRANE/SRW position.
- (11) Set crane POWER switch to ON position.
- (12) Hold SWING control lever in CW position.
 - (a) If a minimum of 1,800 psi (12,411 kPa) are not present, perform Steps (13) through (18) below and replace relief valve at rear (left) side of swing motor valve assembly (Para 16-19).
 - (b) If 1,800 psi (12,411 kPa) or more are present, perform Steps (13) through (18) below and go to Step 3 of this Fault.
- (13) Set crane POWER switch to OFF position.
- (14) Set hydraulic selector switch to OFF position.
- (15) Turn OFF ENGINE switch.
- (16) Disconnect hose from outboard (taller) elbow on four valve bank. Discard preformed packings.
- (17) Disconnect adapter hoses from elbow and crane hose. Discard preformed packings.
- (18) Connect crane hoses with preformed packing to elbow.



9. CRANE DOES NOT SWING CW (CONT).



WARNING



- High pressure hydraulics [oil under 3,000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

PRESSURE TEST




- (1) Disconnect tube from swing brake and swing motor valve. Discard preformed packings.
- (2) Install pressure gage with preformed packing to elbow on swing motor valve.
- (3) Start engine (TM 9-2320-364-10).
- (4) Set WINCH/CRANE switch to CRANE position.
- (5) Set hydraulic selector switch to CRANE/SRW position.
- (6) Set crane POWER switch to ON position.
- (7) Hold SWING control lever in CW position.
 - (a) If 1,800 psi (12,411 kPa) or more are not present, perform Steps (8) through (12) below and repair swing motor valve (Para 16-19).
 - (b) If 1,800 psi (12,411 kPa) or more are present, perform Steps (8) through (12) below and go to Step 4 of this Fault.
- (8) Set crane POWER switch to OFF position.
- (9) Set hydraulic selector switch to OFF position.
- (10) Turn OFF ENGINE switch.
- (11) Disconnect pressure gage from swing motor valve. Discard preformed packing.
- (12) Connect tube with two preformed packings to swing drive gear reducer and swing motor valve.



9. CRANE DOES NOT SWING CW (CONT).




STEERING WHEEL SHOWN
REMOVED FOR CLARITY



VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Start engine (TM 9-2320-364-10).
- (3) Set WINCH/CRANE switch to CRANE position.
- (4) Set hydraulic selector switch to CRANE/SRW position.
- (5) Set crane POWER switch to ON position.
- (6) Swing crane CW using SWING control lever.
 - (a) If crane does not swing, fault not corrected. Perform Steps (7) through (10) below and notify supervisor.
 - (b) If crane does swing, fault has been corrected.
- (7) Set crane POWER switch to OFF position.
- (8) Set hydraulic selector switch to OFF position.
- (9) Turn OFF ENGINE switch.
- (10) Install cover with four screws, washers, lockwashers and nuts.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

10. CRANE DOES NOT SWING COUNTER CLOCKWISE (CCW).

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Cap and Plug Set (Item 26, Appendix F)
- Pan, Drain 4 gal (Item 144, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)

Materials/Parts


- Oil, Hydraulic (Item 34, Appendix B)
- Tags, Identification (Item 72, Appendix B)
- Lockwasher (4) (Item 282, Appendix E)
- Packings, Preformed (11) (Item 347, Appendix E)
- Packings, Preformed (3) (Item 389, Appendix E)

References

- TM 9-2320-364-10
- TM 9-2320-364-20


Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Outriggers down with weight off vehicle suspension, (TM 9-2320-364-10)



WARNING


- High pressure hydraulics [oil under 3,000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.





NOTE

Use a drain pan to catch leaking hydraulic oil.


OPERATION TEST	
(1)	Remove four nuts, lockwashers, washers and nuts and cover. Discard lockwashers.
(2)	Tag, mark and disconnect two hoses from two elbows at left of four valve bank. Discard preformed packings.
(3)	Connect each removed hose with preformed packing to the elbow the other was removed from (cross them).
(4)	Start engine (TM 9-2320-364-10).
(5)	Set WINCH/CRANE switch to CRANE position.
(6)	Set hydraulic selector switch to CRANE/SRW position.
(7)	Set crane POWER switch to ON position.
(8)	Swing crane CCW by moving SWING control lever to CW position. <ul style="list-style-type: none"> (a) If crane does not swing, perform Steps (9) through (13) below and go to Step 2 of this Fault. (b) If crane does swing, perform Steps (9) through (13) below and replace SWING valve on four valve bank (Para 16-26).
(9)	Set crane POWER switch to OFF position.
(10)	Set hydraulic selector switch to OFF position.
(11)	Turn OFF ENGINE switch.
(12)	Disconnect two hoses from elbows. Discard preformed packings.
(13)	Install hoses with preformed packings on elbows using tags and marks to install correctly.



STEERING WHEEL SHOWN REMOVED FOR CLARITY



10. CRANE DOES NOT SWING CCW (CONT).



WARNING




- High pressure hydraulics [oil under 3,000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

PRESSURE TEST

- (1) Disconnect hose from outboard (taller) elbow at left of four valve bank. Discard preformed packing.
- (2) Disconnect hose from inboard (shorter) elbow at left of four valve bank. Discard preformed packing.
- (3) Connect adapter hose to flowmeter IN port.
- (4) Connect IN port adapter hose with preformed packing to inboard (shorter) elbow.
- (5) Connect adapter hose to flowmeter OUT port.
- (6) Connect OUT port adapter hose with preformed packing to crane hose disconnected from inboard (shorter) elbow.
- (7) Connect hose to outboard (taller) elbow.
- (8) Start engine (TM 9-2320-364-10).
- (9) Set WINCH/CRANE switch to CRANE position.
- (10) Set hydraulic selector switch to CRANE/SRW position.
- (11) Set crane POWER switch to ON position.
- (12) Hold SWING control lever in CCW position.
 - (a) If a minimum of 1800 psi (12,411 kPa) are not present, perform Steps (13) through (18) below and replace relief valve at rear (left) side of swing motor valve assembly (Para 16-19).
 - (b) If 1800 psi (12,411 kPa) or more are present, perform Steps (13) through (18) below and go to Step 3 of this Fault.
- (13) Set crane POWER switch to OFF position.
- (14) Set hydraulic selector switch to OFF position.
- (15) Turn OFF ENGINE switch.
- (16) Disconnect hose from outboard (taller) elbow on four valve bank. Discard preformed packing.
- (17) Disconnect adapter hoses from elbow and crane hose. Discard preformed packings.
- (18) Connect crane hoses with preformed packing to elbows.



10. CRANE DOES NOT SWING CCW (CONT).



WARNING



- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

PRESSURE TEST


- (1) Disconnect tube from swing brake and swing motor valve. Discard preformed packings.
- (2) Install pressure gage with preformed packing to elbow on swing motor valve.
- (3) Start engine (TM 9-2320-364-10).
- (4) Set WINCH/CRANE switch to CRANE position.
- (5) Set hydraulic selector switch to CRANE/SRW position.
- (6) Set crane POWER switch to ON position.
- (7) Hold SWING control lever in CCW position.
 - (a) If 1800 psi (12,411 kPa) or more are not present, perform Steps (8) through (12) below and repair swing motor valve (Para 16-19).
 - (b) If 1800 psi (12,411 kPa) or more are present, perform Steps (8) through (12) below and go to Step 4 of this Fault.
- (8) Set crane POWER switch to OFF position.
- (9) Set hydraulic selector switch to OFF position.
- (10) Turn OFF ENGINE switch.
- (11) Disconnect pressure gage from swing motor valve. Discard preformed packing.
- (12) Connect tube with two preformed packings to swing brake and swing motor valve.






10. CRANE DOES NOT SWING CCW (CONT).



STEERING WHEEL SHOWN
REMOVED FOR CLARITY



VERIFY REPAIR	
(1)	Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
(2)	Start engine (TM 9-2320-364-10).
(3)	Set WINCH/CRANE switch to CRANE position.
(4)	Set hydraulic selector switch to CRANE/SRW position.
(5)	Set crane POWER switch to ON position.
(6)	Swing crane CCW using SWING control lever.
(a)	If crane does not swing, fault not corrected. Perform Steps (7) through (10) below and notify supervisor.
(b)	If crane swings, fault has been corrected.
(7)	Set crane POWER switch to OFF position.
(8)	Set hydraulic selector switch to OFF position.
(9)	Turn OFF ENGINE switch.
(10)	Install cover with four screws, washers, lockwashers and nuts.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

11. BOOM DOES NOT TELESCOPE IN OR TELESCOPES IN SLOWLY.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic
 (Item 240, Appendix F)
 Cap and Plug Set (Item 26, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)
 Lifting Device (Minimum Capacity
 200 lbs/91 kg)

Materials/Parts

Oil Hydraulic (Item 34, Appendix B)
 Tags, Identification (Item 72, Appendix B)
 Lockwasher (4) (Item 282, Appendix E)
 Packing, Preformed (9) (Item 337, Appendix E)
 Packing, Preformed (8) (Item 396, Appendix E)
 Packing, Preformed (3) (Item 398, Appendix E)

Materials/Parts - Continued


Pin, Cotter (2) (Item 417, Appendix E)

References

TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)
 Outriggers down with weight off
 vehicle suspension, (TM 9-2320-364-10)



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Remove four nuts, lockwashers, washers and screws and cover. Discard lockwashers.
- (2) Tag, mark and disconnect two hoses from elbows at top of four valve bank above TELE valve. Discard preformed packings.
- (3) Connect adapter hose with preformed packing to inboard (smaller) elbow.
- (4) Connect adapter hose to flowmeter IN port.
- (5) Connect adapter hose with preformed packing to outboard (taller) elbow.
- (6) Connect adapter hose to flowmeter OUT port.
- (7) Open flowmeter load valve.
- (8) Start engine (TM 9-2320-364-10).
- (9) Set WINCH/CRANE switch to CRANE position.
- (10) Set hydraulic selector switch to CRANE/SRW position.
- (11) Set crane POWER switch to ON position.
- (12) Hold TELE control lever in the IN position.
 - (a) If 6 gpm (23 lpm) or more are not present, repair four valve bank (Para 16-26).
 - (b) If 6 gpm (15 lpm) or more are present, go to Step 2 of this Fault.
- (13) Set crane POWER switch to OFF position.
- (14) Set hydraulics selector switch to OFF position.
- (15) Turn OFF ENGINE switch.
- (16) Disconnect adapter hoses from elbows. Discard preformed packings.
- (17) Connect two hoses with preformed packings to elbows.



11. BOOM DOES NOT TELESCOPE IN OR TELESCOPES IN SLOWLY (CONT).




WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST
<ol style="list-style-type: none"> (1) Set crane POWER switch to OFF position (TM 9-2320-364-10). (2) Set hydraulics selector switch to OFF position. (3) Turn OFF ENGINE switch. (4) Remove adapter hose from outboard (taller) elbow. Discard preformed packing. (5) Connect adapter hose with preformed packing to the crane hose removed from inboard (shorter) elbow. (6) Install crane hose with preformed packing on outboard (taller) elbow. (7) Open flowmeter load valve. (8) Start engine. (9) Set WINCH/CRANE switch to CRANE position. (10) Set hydraulic selector switch to CRANE/SRW position. (11) Set crane POWER switch to ON position. (12) Telescope boom in completely if boom operates slowly. (13) Hold TELE control lever in the IN position. <ol style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are present, perform Steps (14) through (19) below and go to Step 4 of this Fault. (b) If 0 gpm (0 lpm) are present, perform Steps (14) through (19) below and go to Step 3 of this Fault. (14) Set crane POWER switch to OFF position. (15) Set hydraulics selector switch to OFF position. (16) Turn OFF ENGINE switch. (17) Tag, mark and disconnect crane hose from outboard (taller) elbow. Discard preformed packing. (18) Disconnect adapter hoses from elbow and crane hose. Discard preformed packings. (19) Connect two crane hoses with preformed packings to elbows.



11. BOOM DOES NOT TELESCOPE IN OR TELESCOPES IN SLOWLY (CONT).




CAUTION

Cable must be held when disconnected and allowed to retract slowly by hand. Failure to do so may result in equipment damage.

OPERATION TEST
(1) Start engine (TM 9-2320-364-10).
(2) Set WINCH/CRANE rocker switch to CRANE position.
(3) Set hydraulic selector switch to CRANE/SRW position.
(4) Turn ON crane POWER switch.
(5) Position end of crane boom on LH side of truck and lower it so that telescope retaining pins can be easily reached.
(6) Raise hoist hook block until it contacts boom nose.
(7) Remove two screws, lockwashers and RH cylinder hold down.
(8) Remove two screws, lockwashers and LH cylinder hold down.
(9) Attach lifting device to telescope cylinders.
(10) Remove screw, overload sensing system (OSS) cable end, spacer, and washer from retaining pin and carefully let cable retract.
(11) Remove two cotter pins from retaining pin and retaining pin from cylinder rod and boom on OSS side of boom. Discard cotter pins.
(12) Loosen two screws enough to allow cylinder rod to be pulled out away from boom.
(13) Remove cotter pin from retaining pin and retaining pin from cylinder rod on other side of boom.
(14) Loosen two screws enough to allow cylinder rod to be pulled out away from boom.
(15) Swing both telescope cylinders out enough that cylinder rods can be extended without contacting boom.

Continued on next page.



11. BOOM DOES NOT TELESCOPE IN OR TELESCOPES IN SLOWLY (CONT).


CAUTION

Cable must be held when disconnected and allowed to retract slowly by hand. Failure to do so may result in equipment damage.

OPERATION TEST (CONT).

- (16) Operate telescope cylinders using TELE control lever.
 - (a) If one cylinder does not operate or operates slowly, perform Steps (17) through (25) below and replace telescope cylinder (Para 16-10).
 - (b) If both cylinders operate equally or both do not operate, fault not corrected. Perform Steps (17) through (25) and notify supervisor.
- (17) Set crane POWER switch to OFF position (TM 9-2320-364-10).
- (18) Set hydraulics selector switch to OFF position.
- (19) Turn OFF ENGINE switch.

Continued on next page.




CAUTION


Cable must be held when disconnected and allowed to retract slowly by hand. Failure to do so may result in equipment damage.

OPERATION TEST (CONT).

- (20) Install cylinder rod on OSS side of boom with retain pin and cotter pin.
- (21) Install washer, spacer, and OSS cable end with screw.
- (22) Tighten two screws.
- (23) Install other cylinder rod with retaining pin and cotter pin.
- (24) Tighten two screws.
- (25) Install LH and RH cylinder holddowns with two screws and lockwashers each.
- (25) Remove lifting device.



11. BOOM DOES NOT TELESCOPE IN OR TELESCOPES IN SLOWLY (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Tag, mark and disconnect two hoses from telescope cylinder fitting and elbow. Discard preformed packings.
 - (2) Install plugs with preformed packings on disconnected hoses.
 - (3) Install cap with preformed packings on fitting.
 - (4) Connect flowmeter OUT port adapter hose with preformed packing to telescope elbow.
 - (5) Disconnect hose from outboard (taller) elbow above TELE valve. Discard preformed packings.
 - (6) Install plug with preformed packing in crane hose.
 - (7) Connect flowmeter IN port adapter to four valve bank elbow.
 - (8) Open flowmeter load valve.
 - (9) Start engine (TM 9-2320-364-10).
 - (10) Set WINCH/CRANE switch to CRANE position.
 - (11) Set hydraulic selector switch to CRANE/SRW position.
 - (12) Set crane POWER switch to ON position.
 - (13) Hold TELE control lever in the IN position.
 - (a) If more than 0 gpm (0 lpm) are measured, perform Steps (14) through (23) and replace telescope cylinder (Para 16-10) on LHS side of boom.
 - (b) If 0 gpm (0 lpm) are measured, perform Steps (14) through (23) and replace telescope cylinder (Para 16-10) on cab side of boom.
- Continued on next page.*



11. BOOM DOES NOT TELESCOPE IN OR TELESCOPES IN SLOWLY (CONT).


WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST (CONT).	
(14)	Set crane POWER switch to OFF position (TM 9-2320-364-10).
(15)	Set hydraulics selector switch to OFF position.
(16)	Turn OFF ENGINE switch.
(17)	Disconnect adapter hose from elbow.
(18)	Remove two plugs from hoses. Discard preformed packings.
(19)	Remove two caps from elbow and adapter. Discard preformed packings.
<i>Continued on next page.</i>	



WARNING



- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST (CONT).

- (20) Connect hose with preformed packing to elbow.
- (21) Connect hose with preformed packing to fitting.
- (22) Connect hose to elbow on four valve bank.
- (23) Install cover with four screws, washers, lockwashers and nuts.






11. BOOM DOES NOT TELESCOPE IN OR TELESCOPES IN SLOWLY (CONT).



VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Telescope boom in using TELE control handle (TM 9-2320-364-10).
 - (a) If boom does not telescope in, fault not corrected. Perform Steps (3) through (5) below and notify supervisor.
 - (b) If boom telescopes in, fault has been corrected.
- (3) Set crane POWER switch to OFF position.
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

12. BOOM DOES NOT TELESCOPE OUT OR TELESCOPES OUT SLOWLY.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Cap and Plug Set (Item 26, Appendix F)
- Pan, Drain 4 gal (Item 144, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)
- Lifting Device (Minimum Capacity 200 lbs [91 kg])

Materials/Parts

- Oil Hydraulic (Item 34, Appendix B)
- Tags, Identification (Item 72, Appendix B)
- Lockwasher (4) (Item 282, Appendix E)
- Packing, Preformed (9) (Item 337, Appendix E)
- Packing, Preformed (9) (Item 347, Appendix E)

Materials/Parts - Continued


- Packing, Preformed (2) (Item 363, Appendix E)
- Packing, Preformed (3) (Item 389, Appendix E)
- Packing, Preformed (3) (Item 398, Appendix E)
- Pin, Cotter (2) (Item 417, Appendix E)

References

- TM 9-2320-364-10
- TM 9-2320-364-20

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Outriggers down with weight off vehicle suspension, (TM 9-2320-364-10)




WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST
(1) Remove four nuts, lockwashers, washers and screws and cover. Discard lockwashers.
(2) Tag, mark and disconnect two hoses from elbows at top of four valve bank above TELE valve. Discard preformed packings.
(3) Connect adapter hose with preformed packing to inboard (smaller) elbow.
(4) Connect adapter hose to flowmeter OUT port.
(5) Connect adapter hose with preformed packing to outboard (taller) elbow.
(6) Connect adapter hose to flowmeter IN port.
(7) Open flowmeter load valve.
(8) Start engine (TM 9-2320-364-10).
(9) Set WINCH/CRANE switch to CRANE position.
(10) Set hydraulic selector switch to CRANE/SRW position.
(11) Set crane POWER switch to ON position.
(12) Hold TELE control lever in the IN position. <ul style="list-style-type: none"> (a) If 6 gpm (23 lpm) or more are not present, perform Steps (13) through (17) below and go to Step 5 of this Fault. (b) If at least 6 gpm (23 lpm) are present, go to Step 2 of this Fault.
(13) Set crane POWER switch to OFF position.
(14) Set hydraulics selector switch to OFF position.
(15) Turn OFF ENGINE switch.
(16) Disconnect adapter hoses from elbows. Discard preformed packings.
(17) Connect two hoses with preformed packings to elbows.



12. BOOM DOES NOT TELESCOPE OUT OR TELESCOPES OUT SLOWLY (CONT).




WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST
<ol style="list-style-type: none"> (1) Remove adapter hoses from elbows. Discard preformed packings. (2) Connect flowmeter IN port adapter hose with preformed packing to the crane hose removed from inboard (shorter) elbow. (3) Connect flowmeter OUT port adapter hose with preformed packing to inboard (shorter) elbow. (4) Install crane hose with preformed packing on outboard (taller) elbow. (5) Open flowmeter load valve. (6) Start engine (TM 9-2320-364-10). (7) Set WINCH/CRANE switch to CRANE position. (8) Set hydraulic selector switch to CRANE/SRW position. (9) Set crane POWER switch to ON position. (10) Telescope boom in completely if boom operates slowly. (11) Hold TELE control lever in the OUT position. <ol style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are present, perform Steps (12) through (17) below and go to Step 4 of this Fault. (b) If 0 gpm (0 lpm) are present, perform Steps (12) through (17) below and go to Step 3 of this Fault. (12) Set crane POWER switch to OFF position. (13) Set hydraulics selector switch to OFF position. (14) Turn OFF ENGINE switch. (15) Tag, mark and disconnect crane hose from outboard (taller) elbow. Discard preformed packing. (16) Disconnect adapter hoses from elbow and crane hose. Discard preformed packings. (17) Connect two crane hoses with preformed packings to elbows.



12. BOOM DOES NOT TELESCOPE OUT OR TELESCOPES OUT SLOWLY (CONT).




CAUTION

Cable must be held when disconnected and allowed to retract slowly by hand. Failure to do so may result in equipment damage.


OPERATION TEST	
(1)	Start engine (TM 9-2320-364-10).
(2)	Set WINCH/CRANE rocker switch to CRANE position.
(3)	Set hydraulic selector switch to CRANE/SRW position.
(4)	Turn ON crane POWER switch.
(5)	Position end of crane boom on LH side of truck and lower it so that telescope retaining pins can be easily reached.
(6)	Raise hoist hook block until it contacts boom nose.
(7)	Remove two screws, lockwashers and RH cylinder hold down.
(8)	Remove two screws, lockwashers and LH cylinder hold down.
(9)	Attach lifting device to telescope cylinders.
(10)	Remove screw, overload sensing system (OSS) cable end, spacer, and washer from retaining pin and carefully let cable retract.
(11)	Remove two cotter pins from retaining pin and retaining pin from cylinder rod and boom on OSS side of boom. Discard cotter pins.
(12)	Loosen two screws enough to allow cylinder rod to be pulled out away from boom.
(13)	Remove cotter pin from retaining pin and retaining pin from cylinder rod on other side of boom.
(14)	Loosen two screws enough to allow cylinder rod to be pulled out away from boom.
(15)	Swing both telescope cylinders out enough that cylinder rods can be extended without contacting boom.

Continued on next page.



12. BOOM DOES NOT TELESCOPE OUT OR TELESCOPES OUT SLOWLY (CONT).


- | OPERATION TEST (CONT). | |
|------------------------|---|
| (16) | Operate telescope cylinders using TELE control lever. |
| (a) | If one cylinder does not operate or operates slowly, perform Steps (17) through (25) below and replace telescope cylinder (Para 16-10). |
| (b) | If both cylinders operate equally, fault not corrected. Perform Steps (17) through (25) and notify supervisor. |
| (17) | Set crane POWER switch to OFF position (TM 9-2320-364-10). |
| (18) | Set hydraulics selector switch to OFF position. |
| (19) | Turn OFF ENGINE switch. |
- Continued on next page.*




CAUTION

Cable must be held when disconnected and allowed to retract slowly by hand. Failure to do so may result in equipment damage.

OPERATION TEST (CONT).	
(20)	Install cylinder rod on OSS side of boom with retain pin and cotter pin.
(21)	Install washer, spacer, and OSS cable end with screw.
(22)	Tighten two screws.
(23)	Install other cylinder rod with retaining pin and cotter pin.
(24)	Tighten two screws.
(25)	Install LH and RH cylinder holddowns with two screws and lockwashers each.
(25)	Remove lifting device.



12. BOOM DOES NOT TELESCOPE OUT OR TELESCOPES OUT SLOWLY (CONT).




WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST
<ol style="list-style-type: none"> (1) Tag, mark and disconnect two hoses from telescope cylinder fitting and tee on side of boom without OSS box. Discard preformed packings. (2) Install plugs with preformed packings on disconnected hoses. (3) Install caps with preformed packings on fitting and tee. (4) Start engine (TM 9-2320-364-10). (5) Set WINCH/CRANE switch to CRANE position. (6) Set hydraulic selector switch to CRANE/SRW position. (7) Set crane POWER switch to ON position. (8) Hold TELE control lever in the IN position. <ol style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are measured, perform Steps (9) through (18) below and replace telescope cylinder (Para 16-10) that is not on the OSS side of the boom. (b) If 0 gpm (0 lpm) are measured, perform Steps (9) through (18) below and replace telescope cylinder (Para 16-10) that is on OSS side of boom. (9) Set crane POWER switch to OFF position. (10) Set hydraulics selector switch to OFF position. (11) Turn OFF ENGINE switch. (12) Remove two plugs from hoses. Discard preformed packings. (13) Remove two caps from tee and adapter. Discard preformed packings. (14) Connect hose with preformed packing to tee. (15) Connect hose with preformed packing to fitting. (16) Disconnect hose from outboard (taller) elbow above TELE valve. Discard preformed packing. (17) Disconnect adapter hoses from elbow and hose. Discard preformed packing. (18) Connect two hoses with preformed packings to elbows.



12. BOOM DOES NOT TELESCOPE OUT OR TELESCOPES OUT SLOWLY (CONT).





WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE




Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST	
(1)	Disconnect hose 2918 from main hydraulic filter.
(2)	Connect adapter hose to return filter.
(3)	Connect adapter hose to flowmeter OUT port.
(4)	Connect adapter hose to hose 2918.
(5)	Connect adapter hose to flowmeter IN port.
(6)	Open flowmeter load valve.
(7)	Start engine (TM 9-2320-364-10).
(8)	Set WINCH/CRANE switch to CRANE position.
(9)	Set hydraulic selector switch to CRANE/SRW position.
(10)	Set crane POWER switch to ON position.
(11)	Observe and record flowmeter gpm (lpm) measured.
(12)	Hold TELE control lever in OUT position. <ul style="list-style-type: none"> (a) If gpm (lpm) present are not more than gpm (lpm) measured in Step (11) above, perform Steps (13) through (19) below and replace TELE valve on four valve bank (Para 16-26). (b) If gpm (lpm) measured are more than gpm (lpm) measured in Step (11) above, perform Steps (13) through (19) below and replace OSS directional valve on four valve bank (Para 16-26).
(13)	Set crane POWER switch to OFF position.
(14)	Set hydraulic selector switch to OFF position.
(15)	Turn OFF ENGINE switch.
(16)	Disconnect adapter hose from hose 2918. Discard preformed packing.
(17)	Disconnect adapter hose from return filter. Discard preformed packing.
(18)	Connect hose 2918 with preformed packing to filter.
(19)	Install cover with four screws, washers, lockwashers and nuts.



12. BOOM DOES NOT TELESCOPE OUT OR TELESCOPES OUT SLOWLY (CONT).





VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Telescope boom out using TELE control handle.
 - (a) If boom does not telescope out, fault not corrected. Perform Steps (3) through (5) below and notify supervisor.
 - (b) If boom telescopes out, fault has been corrected.
- (3) Set crane POWER switch to OFF position (TM 9-2320-364-10).
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.

2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

13. BOOM DOES NOT TELESCOPE OR TELESCOPES SLOWLY.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Cap and Plug Set (Item 26, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)
 Lifting Device (Minimum Capacity
 200 lbs/91 kg)

Materials/Parts

Oil, Hydraulic (Item 34, Appendix B)
 Tags, Identification (Item 72, Appendix B)
 Lockwasher (4) (Item 282, Appendix E)
 Packing, Preformed (2) (Item 337, Appendix E)
 Packing, Preformed (2) (Item 347, Appendix E)

Materials/Parts - Continued


Pin, Cotter (2) (Item 417, Appendix E)




References

TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)
 Outriggers down with weight off
 vehicle suspension, (TM 9-2320-364-10)






OPERATION TEST




- (1) Start engine (TM 9-2320-364-10).
- (2) Set WINCH/CRANE switch to CRANE position.
- (3) Set hydraulic selector switch to CRANE/SRW position.
- (4) Set crane POWER switch to ON position.
- (5) Attempt to telescope boom using TELE control lever.
 - (a) If boom does not telescope, perform Steps (6) through (8) below and go to Step 2 of this Fault.
 - (b) If boom does telescope some but not completely, perform Steps (6) through (8) below and go to Step 5 of this Fault.
- (6) Set crane POWER switch to OFF position.
- (7) Set hydraulic selector switch to OFF position.
- (8) Turn OFF ENGINE switch.

13. BOOM DOES NOT TELESCOPE OR TELESCOPES SLOWLY (CONT).




OPERATION TEST

- (1) Start engine (TM 9-2320-364-10).
- (2) Set WINCH/CRANE switch to CRANE position.
- (3) Set hydraulic selector switch to CRANE/SRW position.
- (4) Set crane POWER switch to ON position.
- (5) Attempt to telescope while holding BOOM control lever in UP position.
 - (a) If boom does not telescope, perform Steps (6) through (8) below and go to Step 3 of this Fault.
 - (b) If boom telescopes, perform Steps (6) through (8) below and repair four valve bank (Para 16-26).
- (6) Set crane power switch to OFF position.
- (7) Set hydraulic selector switch to OFF position.
- (8) Turn OFF ENGINE switch.



13. BOOM DOES NOT TELESCOPE OR TELESCOPES SLOWLY (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Remove four nuts, lockwashers, washers and screws and cover. Discard lockwashers.
- (2) Tag, mark and disconnect two hoses from elbows at top of four valve bank above TELE valve.
- (3) Connect adapter hose with preformed packing to inboard (smaller) elbow.
- (4) Connect adapter hose to flowmeter IN port.
- (5) Connect adapter hose with preformed packing to outboard (taller) elbow.
- (6) Connect adapter hose to flowmeter OUT port.
- (7) Open flowmeter load valve.
- (8) Start engine (TM 9-2320-364-10).
- (9) Set WINCH/CRANE switch to CRANE position.
- (10) Set hydraulic selector switch to CRANE/SRW position.
- (11) Set crane POWER switch to ON position.
- (12) Hold TELE control lever in the IN position.
 - (a) If 4 gpm (15 lpm) or more are not present, perform Steps (13) through (17) below and go to Step 6 of this Fault.
 - (b) If at least 4 gpm (15 lpm) are present, perform Steps (13) through (17) below and go to Step 4 of this Fault.
- (13) Set crane POWER switch to OFF position.
- (14) Set hydraulics selector switch to OFF position.
- (15) Turn OFF ENGINE switch.
- (16) Disconnect adapter hoses from elbows. Discard preformed packings.
- (17) Connect two hoses with preformed packings to elbows.




13. BOOM DOES NOT TELESCOPE OR TELESCOPES SLOWLY (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. Crane swings. Four valve bank OK.
POSSIBLE PROBLEMS
Telescope cylinder faulty. Boom chain or cable faulty.

4.

Do both telescope cylinder rods operate and travel at the same rate with rod ends disconnected from boom?


TEST OPTIONS
Operation test.
REASON FOR QUESTION
Faulty cylinder will not operate or will operate slowly when compared to functioning cylinder when disconnected from boom.




CAUTION

Cable must be held when disconnected and allowed to retract slowly by hand. Failure to do so may result in equipment damage.

OPERATION TEST
(1) Attach lifting device to telescope cylinders.
(2) Remove screw, OSS cable end, spacer, and washer from retaining pin and carefully let cable retract.
(3) Remove two cotter pins from retaining pin and retaining pin from cylinder rod and boom on OSS side of boom. Discard cotter pins.
(4) Loosen two screws enough to allow cylinder rod to be pulled out away from boom.
(5) Remove cotter pin from retaining pin and retaining pin from cylinder rod on other side of boom.
(6) Loosen two screws enough to allow cylinder rod to be pulled out away from boom.
(7) Swing both telescope cylinders out enough that cylinder rods can be extended without contact truck.
(8) Start engine.
(9) Set WINCH/CRANE rocker switch to CRANE position.
(10) Set hydraulic selector switch to CRANE/SRW position.
(11) Turn ON crane POWER switch.
(12) Operate telescope cylinders using TELE control lever. <ul style="list-style-type: none"> (a) If one cylinder does not operate or operates slowly, cylinder assembly is faulty. Replace telescope cylinder (Para 16-10). (b) If both cylinders operate equally, cylinders are OK.
(13) Set crane POWER switch to OFF position.
(14) Set hydraulics selector switch to OFF position.
(15) Turn OFF ENGINE switch.
(16) Install cylinder rod on OSS side of boom with retain pin and cotter pin.
(17) Install washer, spacer, and OSS cable end with screw.
(18) Tighten two screws.
(19) Install other cylinder rod with retaining pin and cotter pin.
(20) Tighten two screws.
(21) Remove lifting device.






13. BOOM DOES NOT TELESCOPE OR TELESCOPES SLOWLY (CONT).




VISUAL INSPECTION

- (1) Remove four screws, washers and cover from rear of boom.
- (2) Inspect cable and chain for damage and incorrect routing (binding).
- (3) Remove four screws, washers and cover from front of boom.
- (4) Inspect cable and chain for damage and incorrect routing.
 - (a) If cable or chain are faulty, repair boom (Para 16-3).
 - (b) If cable and chain are OK, fault not corrected. Perform Steps (5) and (6) below and notify supervisor.
- (5) Install cover on front of boom with four screws and washers.
- (6) Install cover on rear of boom with four screws and washers.



13. BOOM DOES NOT TELESCOPE OR TELESCOPES SLOWLY (CONT).



WARNING




- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Remove four valve bank from crane (Para 16-26).
- (2) Remove TELE valve from four valve bank (Para 16-33).
- (3) Remove orifice from four valve bank where TELE valve was removed from (Para 16-33).
- (4) Inspect orifice for contamination clogging it.
 - (a) If orifice is contaminated, clean or replace orifice and inspect bores in four valve bank for additional contaminants.
 - (b) If orifice is OK, TELE valve is faulty. Repair TELE valve on four valve bank (Para 16-33).
- (5) Install orifice on four valve bank (Para 16-26).
- (6) Install TELE valve on four valve bank (Para 16-33).
- (7) Install four valve bank on crane (Para 16-26).






13. BOOM DOES NOT TELESCOPE OR TELESCOPES SLOWLY (CONT).



VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Start engine (TM 9-2320-364-10).
- (3) Set WINCH/CRANE switch to CRANE position.
- (4) Set hydraulic selector switch to CRANE/SRW position.
- (5) Set crane power switch to ON position.
- (6) Telescope boom using TELE control lever.
 - (a) If boom does not telescope, fault not corrected. Perform Steps (7) through (9) below and notify supervisor.
 - (b) If boom telescopes, fault has been corrected.
- (7) Set crane power switch to OFF position.
- (8) Set hydraulic selector switch to OFF position.
- (9) Turn OFF ENGINE switch.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

14. BOOM DOES NOT RAISE OR RAISES SLOWLY.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Cap and Plug Set (Item 26, Appendix F)
- Pan, Drain 4 gal (Item 144, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)

Materials/Parts


- Oil, Hydraulic (Item 34, Appendix B)
- Tags, Identification (Item 72, Appendix B)
- Lockwasher (4) (Item 282, Appendix E)
- Packing, Preformed (3) (Item 335, Appendix E)
- Packing, Preformed (6) (Item 336, Appendix E)
- Packing, Preformed (2) (Item 363, Appendix E)
- Packing, Preformed (8) (Item 389, Appendix E)
- Wooden Block (Appendix C)
- Wooden Block (Appendix C)

References

- TM 9-2320-364-10
- TM 9-2320-364-20

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Outriggers down with weight off vehicle suspension, (TM 9-2320-364-10)



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Remove four nuts, lockwashers, washers and screws and cover. Discard lockwashers.
- (2) Tag, mark and disconnect two hoses from elbows at top of four valve bank above BOOM valve. Discard preformed packings.
- (3) Connect adapter hose with preformed packing to inboard (smaller) elbow.
- (4) Connect adapter hose to flowmeter OUT port.
- (5) Connect adapter hose with preformed packing to outboard (taller) elbow.
- (6) Connect adapter hose to flowmeter IN port.
- (7) Open flowmeter load valve.
- (8) Start engine (TM 9-2320-364-10).
- (9) Set WINCH/CRANE switch to CRANE position.
- (10) Set hydraulic selector switch to CRANE/SRW position.
- (11) Set crane POWER switch to ON position.
- (12) Hold BOOM control lever in the UP position.
 - (a) If 6 gpm (23 lpm) or more are not present, perform Steps (13) through (18) below and go to Step 4 of this Fault.
 - (b) If 6 gpm (23 lpm) or more are present, perform Steps (13) through (15) below and go to Step 2 of this Fault.
- (13) Set crane POWER switch to OFF position.
- (14) Set hydraulics selector switch to OFF position.
- (15) Turn OFF ENGINE switch.
- (16) Disconnect adapter hoses from elbows. Discard preformed packings.
- (17) Lubricate preformed packings.
- (18) Connect two hoses with preformed packings to elbows.



14. BOOM DOES NOT RAISE OR RAISES SLOWLY (CONT).




WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST	
(1)	Disconnect adapter hoses from elbows. Discard preformed packings.
(2)	Install crane hose with preformed packing on inboard (shorter) elbow.
(3)	Connect flowmeter OUT port adapter hose with preformed packing to the crane hose removed from outboard (taller) elbow.
(4)	Connect flowmeter IN port adapter hose with preformed packing to outboard (taller) elbow.
(5)	Start engine.
(6)	Set WINCH/CRANE switch to CRANE position.
(7)	Set hydraulic selector switch to CRANE/SRW position.
(8)	Set crane POWER switch to ON position.
(9)	Extend boom lift cylinders completely if boom raise slowly.
(10)	Hold BOOM control lever in the UP position. <ul style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are present, perform Steps (11) through (13) below and go to Step 5 of this Fault. (b) If 0 gpm (0 lpm) are present, perform Steps (11) through (15) below and go to Step 3 of this Fault.
(11)	Set crane POWER switch to OFF position.
(12)	Set hydraulics selector switch to OFF position.
(13)	Turn OFF ENGINE switch.
(14)	Disconnect adapter hoses from elbow and crane hose. Discard preformed packings.
(15)	Connect crane hoses with preformed packing to elbow.







14. BOOM DOES NOT RAISE OR RAISES SLOWLY (CONT).




OPERATION TEST

- (1) Block up boom lift cylinder on side of boom with hoist motor.
- (2) Remove screw, washer and bushing from lock pin.
- (3) Remove lock pin from pivot pin.
- (4) Remove pivot pin from boom lift cylinder and boom.
- (5) Start engine (TM 9-2320-364-10).
- (6) Set WINCH/CRANE switch to CRANE position.
- (7) Set hydraulic selector switch to CRANE/SRW position.
- (8) Turn ON crane POWER switch.
- (9) Operate boom lift cylinder using BOOM control lever.
 - (a) If cylinder does not operate, perform Steps (10) through (12) below and replace cylinder (Para 16-6) on hoist motor side of crane.
 - (b) If cylinder operates, perform Steps (10) through (12) and replace boom lift cylinder (Para 16-6) not on hoist motor side of boom.
- (10) Set crane POWER switch to OFF position.
- (11) Set hydraulics selector switch to OFF position.
- (12) Turn OFF ENGINE switch.



14. BOOM DOES NOT RAISE OR RAISES SLOWLY (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Disconnect hose 2918 from main hydraulic filter.
- (2) Connect adapter hose to filter.
- (3) Connect adapter hose to flowmeter OUT port.
- (4) Connect adapter hose to hose 2918.
- (5) Connect adapter hose to flowmeter IN port.
- (6) Open flowmeter load valve.
- (7) Start engine (TM 9-2320-364-10).
- (8) Set WINCH/CRANE switch to CRANE position.
- (9) Set hydraulic selector switch to CRANE/SRW position.
- (10) Set crane POWER switch to ON position.
- (11) Observe and record gpm (lpm) measured.
- (12) Hold BOOM control lever in UP position.
 - (a) If an increase in flow is not present, perform Steps (13) through (18) below and replace BOOM valve on four valve bank (Para 16-26).
 - (b) If an increase in flow is measured, perform Steps (13) through (18) below and replace OSS directional valve on four valve bank (Para 16-26).
- (13) Set crane POWER switch to OFF position.
- (14) Set hydraulic selector switch to OFF position.
- (15) Turn OFF ENGINE switch.
- (16) Disconnect adapter hose from hose 2918. Discard preformed packing.
- (17) Disconnect adapter hose from return filter. Discard preformed packing.
- (18) Connect hose 2918 with preformed packing to filter.



14. BOOM DOES NOT RAISE OR RAISES SLOWLY (CONT).



WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.



NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Tag, mark and disconnect three hoses from boom lift cylinder on side of boom without OSS box. Discard preformed packings.
- (2) Install plugs with preformed packings on disconnected hoses.
- (3) Install caps with preformed packings on two cylinder fittings closest to four valve bank.
- (4) Disconnect flowmeter OUT port adapter hose from crane hose. Discard preformed packing.
- (5) Install plug with preformed packing in crane hose.
- (6) Connect adapter hose with preformed packing to remaining fitting on boom lift cylinder.
- (7) Start engine.
- (8) Set WINCH/CRANE switch to CRANE position.
- (9) Set hydraulic selector switch to CRANE/SRW position.
- (10) Set crane POWER switch to ON position.
- (11) Hook hoist block on ring and take out slack in cable to prevent boom from raising.
- (12) Hold BOOM lever in UP position.
 - (a) If more than 0 gpm (0 lpm) are measured, perform Steps (13) through (22) below and replace cylinder that is not on the OSS side of the boom (Para 16-6).
 - (b) If 0 gpm (0 lpm) are measured, perform Steps (13) through (22) below replace cylinder that is on OSS side of boom (Para 16-6).
- (13) Set crane POWER switch to OFF position.
- (14) Set hydraulics selector switch to OFF position.
- (15) Turn OFF ENGINE switch.

Continued on next page.



14. BOOM DOES NOT RAISE OR RAISES SLOWLY (CONT).

WARNING



- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST (CONT).

- (16) Disconnect adapter hose and two caps from cylinder. Discard preformed packing.
 - (17) Remove three plugs from hoses. Discard preformed packings.
 - (18) Lubricate preformed packings with hydraulic oil.
- Continued on next page.*



WARNING




- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST (CONT).

- (19) Connect three hoses with preformed packings to boom lift cylinder.
- (20) Disconnect adapter hose from elbow. Discard preformed packings.
- (21) Connect crane hose with preformed packing to elbow.
- (22) Install cover with four screws, washers, lockwashers and nuts.






14. BOOM DOES NOT RAISE OR RAISES SLOWLY (CONT).



VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Raise boom up using BOOM control lever.
 - (a) If boom does not raise, fault not corrected. Perform Steps (3) through (5) below and notify supervisor.
 - (b) If boom does raise, fault has been corrected.
- (3) Set crane POWER switch to OFF position.
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

15. BOOM DOES NOT LOWER OR LOWERS SLOWLY.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Cap and Plug Set (Item 26, Appendix F)
- Pan, Drain 4 gal (Item 144, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)
- Lifting Device (Minimum Capacity 2500 lbs/1135 kg)

References


- TM 9-2320-364-10
- TM 9-2320-364-20

Materials/Parts

- Oil, Hydraulic (Item 34, Appendix B)
- Tags, Identification (Item 72, Appendix B)
- Lockwasher (4) (Item 282, Appendix E)
- Preformed Packing (4) (Item 389, Appendix E)
- Wooden Block (Appendix C)
- Wooden Block (Appendix C)

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Outriggers down with weight off vehicle suspension, (TM 9-2320-364-10)



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Remove four nuts, lockwashers, washers and screws and cover. Discard lockwashers.
- (2) Tag, mark and disconnect two hoses from elbows at top of four valve bank above BOOM valve. Discard preformed packings.
- (3) Connect adapter hose with preformed packing to inboard (shorter) elbow.
- (4) Connect adapter hose to flowmeter IN port.
- (5) Connect adapter hose with preformed packing to outboard (taller) elbow.
- (6) Connect adapter hose to flowmeter OUT port.
- (7) Open flowmeter load valve.
- (8) Start engine (TM 9-2320-364-10).
- (9) Set WINCH/CRANE switch to CRANE position.
- (10) Set hydraulic selector switch to CRANE/SRW position.
- (11) Set crane POWER switch to ON position.
- (12) Hold BOOM control lever in the DOWN position.
 - (a) If 4 gpm (15 lpm) or more are not present, perform Steps (13) through (17) below and replace BOOM valve on four valve bank (Para 16-26).
 - (b) If 4 gpm (15 lpm) or more are present, perform Steps (13) through (15) below and go to Step 2 of this Fault.
- (13) Set crane POWER switch to OFF position.
- (14) Set hydraulics selector switch to OFF position.
- (15) Turn OFF ENGINE switch.
- (16) Disconnect adapter hoses from elbows. Discard preformed packings.
- (17) Connect two hoses with preformed packings to elbows.



15. BOOM DOES NOT LOWER OR LOWERS SLOWLY (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Disconnect adapter hoses from elbows. Discard preformed packings.
- (2) Install crane hose with preformed packing on inboard (shorter) elbow.
- (3) Connect flowmeter IN port adapter hose with preformed packing to the crane hose removed from outboard (taller) elbow.
- (4) Connect flowmeter OUT port adapter hose with preformed packing to outboard (taller) elbow.
- (5) Start engine.
- (6) Set WINCH/CRANE switch to CRANE position.
- (7) Set hydraulic selector switch to CRANE/SRW position.
- (8) Set crane POWER switch to ON position.
- (9) Hold BOOM control lever in the DOWN position.
 - (a) If more than 0 gpm (0 lpm) are present, go to Step 4 of this Fault.
 - (b) If 0 gpm (0 lpm) are present, perform Steps (10) through (14) below and go to Step 3 of this Fault.
- (10) Set crane POWER switch to OFF position.
- (11) Set hydraulics selector switch to OFF position.
- (12) Turn OFF ENGINE switch.
- (13) Disconnect adapter hoses from elbow and crane hose. Discard preformed packings.
- (14) Connect crane hose with preformed packing to elbow.






15. BOOM DOES NOT LOWER OR LOWERS SLOWLY (CONT).




OPERATION TEST

- (1) Attach lifting device and blocks to boom and support boom.
- (2) Block up boom lift cylinder on LHS side of boom.
- (3) Remove screw, washer and bushing from lock pin.
- (4) Remove lock pin from pivot pin.
- (5) Remove pivot pin from boom lift cylinder and boom.
- (6) Start engine (TM 9-2320-364-10).
- (7) Set WINCH/CRANE switch to CRANE position.
- (8) Set hydraulic selector switch to CRANE/SRW position.
- (9) Turn ON crane POWER switch.
- (10) Operate boom lift cylinder using BOOM control lever.
 - (a) If cylinder does not operate, perform Steps (11) through (13) below and replace cylinder on LHS side of boom (Para 16-6).
 - (b) If cylinder operates, perform Steps (11) through (13) below and replace cylinder on cab side of boom (Para 16-6).
- (11) Set crane POWER switch to OFF position.
- (12) Set hydraulics selector switch to OFF position.
- (13) Turn OFF ENGINE switch.



15. BOOM DOES NOT LOWER OR LOWERS SLOWLY (CONT).



WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.


FLOWMETER TEST

- (1) Set crane POWER switch to OFF position (TM 9-2320-364-10).
- (2) Set hydraulic selector switch to OFF position.
- (3) Turn OFF ENGINE switch.
- (4) Tag, mark and disconnect two hoses from boom lift cylinder on LHS side of boom. Discard preformed packings.
- (5) Install plugs with preformed packings on disconnected hoses.
- (6) Install caps with preformed packings on two cylinder fittings.
- (7) Start engine.
- (8) Set WINCH/CRANE switch to CRANE position.
- (9) Set hydraulic selector switch to CRANE/SRW position.
- (10) Set crane POWER switch to ON position.
- (11) Hold BOOM lever in DOWN position.
 - (a) If more than 0 gpm (0 lpm) are measured, perform Steps (12) through (20) below and replace cylinder that is on the LHS side of the boom (Para 16-6).
 - (b) If 0 gpm (0 lpm) are measured, perform Steps (12) through (20) below and replace cylinder that is on cab side of boom (Para 16-6).
- (12) Set crane POWER switch to OFF position.
- (13) Set hydraulics selector switch to OFF position.
- (14) Turn OFF ENGINE switch.
- (15) Remove two caps from cylinder assemblies. Discard preformed packings.
- (16) Remove two plugs from hoses. Discard preformed packings.
- (17) Connect two hoses with preformed packings to boom lift cylinder.
- (18) Disconnect adapter hoses from elbow and crane hose. Discard preformed packings.
- (19) Connect crane hose with preformed packing to elbow.
- (20) Install cover with four screws, washers, lockwashers and nuts.

CRANE POWER SWITCH






15. BOOM DOES NOT LOWER OR LOWERS SLOWLY (CONT).



VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Lower boom using BOOM control lever.
 - (a) If boom does not lower, fault not corrected. Perform Steps (3) through (5) below and notify supervisor.
 - (b) If boom lowers, fault has been corrected.
- (3) Set crane POWER switch to OFF position.
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

16. BOOM DOES NOT OPERATE OR OPERATES SLOWLY.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Cap and Plug Set (Item 26, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)
 Lifting Device (Minimum Capacity
 2500 lbs/1134 kg)

Materials/Parts


Oil, Hydraulic (Item 34, Appendix B)
 Tags, Identification (Item 72, Appendix B)
 Lockwasher (4) (Item 282, Appendix E)
 Preformed Packing (3) (Item 335, Appendix E)
 Preformed Packing (6) (Item 336, Appendix E)
 Preformed Packing (8) (Item 389, Appendix E)
 Wooden Block (Appendix C)
 Wooden Block (Appendix C)

References

TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)
 Outriggers down with weight off
 vehicle suspension, (TM 9-2320-364-10)



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Remove four nuts, lockwashers, washers and screws and cover. Discard lockwashers.
- (2) Tag, mark and disconnect two hoses from elbows at top of four valve bank above BOOM valve. Discard preformed packings.
- (3) Connect adapter hose with preformed packing to inboard (smaller) elbow.
- (4) Connect adapter hose to flowmeter OUT port.
- (5) Connect adapter hose with preformed packing to outboard (taller) elbow.
- (6) Connect adapter hose to flowmeter IN port.
- (7) Open flowmeter load valve.
- (8) Start engine (TM 9-2320-364-10).
- (9) Set WINCH/CRANE switch to CRANE position.
- (10) Set hydraulic selector switch to CRANE/SRW position.
- (11) Set crane POWER switch to ON position.
- (12) Hold BOOM control lever in the UP position and then in the DOWN position.
 - (a) If 4 gpm (15 lpm) or more are not present, perform Steps (13) through (17) below and go to Step 4 of this Fault.
 - (b) If 4 gpm (15 lpm) or more are present, perform Steps (13) through (15) below and go to Step 2 of this Fault.
- (13) Set crane POWER switch to OFF position.
- (14) Set hydraulics selector switch to OFF position.
- (15) Turn OFF ENGINE switch.
- (16) Disconnect adapter hoses from elbows. Discard preformed packings.
- (17) Connect two hoses with preformed packings to elbows.



16. BOOM DOES NOT OPERATE OR OPERATES SLOWLY (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Disconnect adapter hoses from elbows. Discard preformed packings.
- (2) Install crane hose with preformed packing on inboard (shorter) elbow.
- (3) Connect flowmeter OUT port adapter hose with preformed packing to the crane hose removed from outboard (taller) elbow.
- (4) Connect flowmeter IN port adapter hose with preformed packing to outboard (taller) elbow.
- (5) Start engine.
- (6) Set WINCH/CRANE switch to CRANE position.
- (7) Set hydraulic selector switch to CRANE/SRW position.
- (8) Set crane POWER switch to ON position.
- (9) Extend boom lift cylinders completely if boom raise slowly.
- (10) Hold BOOM control lever in the UP position.
 - (a) If more than 0 gpm (0 lpm) are present, go to Step 5 of this Fault.
 - (b) If 0 gpm (0 lpm) are present, perform Steps (11) through (15) below and go to Step 3 of this Fault.
- (11) Set crane POWER switch to OFF position.
- (12) Set hydraulics selector switch to OFF position.
- (13) Turn OFF ENGINE switch.
- (14) Disconnect adapter hoses from elbow and crane hose. Discard preformed packings.
- (15) Connect crane hoses with preformed packing to elbow.




16. BOOM DOES NOT OPERATE OR OPERATES SLOWLY (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. Hoist operates. Four valve bank OK.
POSSIBLE PROBLEMS
Lift cylinder faulty.

3.




Does boom lift cylinder on LHS side of crane operate with rod end disconnected from boom?

TEST OPTIONS
Operation test.
REASON FOR QUESTION
Faulty cylinder will not operate or will operate slowly when compared to functioning cylinder when disconnected from boom.




OPERATION TEST

- (1) Attach lifting device and wooden blocks to boom and support boom.
- (2) Block up boom lift cylinder on hoist motor side of boom.
- (3) Remove screw, washer and bushing from lock pin.
- (4) Remove lock pin from pivot pin.
- (5) Remove pivot pin from boom lift cylinder and boom.
- (6) Start engine (TM 9-2320-364-10).
- (7) Set WINCH/CRANE rocker switch to CRANE position.
- (8) Set hydraulic selector switch to CRANE/SRW position.
- (9) Turn ON crane POWER switch.
- (10) Operate boom lift cylinder using BOOM control lever.
 - (a) If cylinder does not operate, perform Steps (11) through (13) below and replace cylinder on LHS side of boom (Para 16-6).
 - (b) If cylinder operates, perform Steps (11) through (13) below and replace cylinder on cab side of boom (Para 16-6).
- (11) Set crane POWER switch to OFF position.
- (12) Set hydraulics selector switch to OFF position.
- (13) Turn OFF ENGINE switch.



16. BOOM DOES NOT OPERATE OR OPERATES SLOWLY (CONT).



WARNING




- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Remove four valve bank from crane (Para 16-26).
- (2) Remove BOOM valve from four valve bank (Para 16-26).
- (3) Remove orifice from four valve bank where BOOM valve was removed from (Para 16-26).
- (4) Inspect orifice for contamination clogging it.
 - (a) If orifice is contaminated, clean or replace orifice and inspect bores in BOOM valve for additional contaminants.
 - (b) If orifice is OK, repair BOOM valve on four valve bank (Para 16-33).
- (5) Install orifice on four valve bank (Para 16-26).
- (6) Install BOOM valve on four valve bank (Para 16-26).
- (7) Install four valve bank on crane (Para 16-26).



16. BOOM DOES NOT OPERATE OR OPERATES SLOWLY (CONT).





WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

- Use a drain pan to catch leaking hydraulic oil.
- Ensure hook block is hooked on ring and slack is taken out of cable, to prevent boom from raising.

FLOWMETER TEST
<ol style="list-style-type: none"> (1) Set crane POWER switch to OFF position. (2) Set hydraulic selector switch to OFF position. (3) Turn OFF ENGINE switch. (4) Tag, mark and disconnect three hoses from boom lift cylinder on LHS side of boom. Discard preformed packings. (5) Install plugs with preformed packings on disconnected hoses. (6) Install caps with preformed packings on two cylinder fittings closest to four valve bank. (7) Disconnect flowmeter OUT port adapter hose from crane hose. Discard preformed packing. (8) Install plug with preformed packing in crane hose. (9) Connect adapter hose with preformed packing to remaining fitting on boom lift cylinder. (10) Start engine (TM 9-2320-364-10). (11) Set WINCH/CRANE switch to CRANE position. (12) Set hydraulic selector switch to CRANE/SRW position. (13) Set crane POWER switch to ON position. (14) Hold BOOM lever in UP position. <ol style="list-style-type: none"> (a) If more than 0 gpm (0 lpm) are measured, perform Steps (15) through (23) below and replace boom lift cylinder (Para 16-6) (Para 16-3) on LHS side of boom. (b) If 0 gpm (0 lpm) are measured, perform Steps (15) through (23) below and replace boom lift cylinder (Para 16-6) on cab side of boom. <p style="text-align: right;"><i>Continued on next page.</i></p>



16. BOOM DOES NOT OPERATE OR OPERATES SLOWLY (CONT).

WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST (CONT).

- (15) Set crane POWER switch to OFF position.
- (16) Set hydraulics selector switch to OFF position.
- (17) Turn OFF ENGINE switch.
- (18) Disconnect adapter hose and two caps from cylinder. Discard preformed packing.
- (19) Remove three plugs from hoses. Discard preformed packings.
Continued on next page.



WARNING



- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST (CONT).

- (20) Connect three hoses with preformed packings to boom lift cylinder.
- (21) Disconnect adapter hose from elbow. Discard preformed packings.
- (22) Connect crane hose with preformed packing to elbow.
- (23) Install cover with four screws, washers, lockwashers and nuts.






16. BOOM DOES NOT OPERATE OR OPERATES SLOWLY (CONT).



VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Operate boom using BOOM control lever.
 - (a) If boom does not operate, fault not corrected. Perform Steps (3) through (5) below and notify supervisor.
 - (b) If boom operates, fault has been corrected.
- (3) Set crane POWER switch to OFF position.
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

17. BOOM CREEPS DOWN.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Cap and Plug Set (Item 26, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)
 Wrench, Torque (0-175 lb-ft) (Item 277, Appendix F)
 Lifting Device (Minimum Capacity
 2500 lbs/1135 kg)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Materials/Parts

Oil, Hydraulic (Item 34, Appendix B)
 Tags, Identification (Item 72, Appendix B)
 Lockwasher (4) (Item 282, Appendix E)
 Packing, Preformed (3) (Item 335, Appendix E)
 Packing, Preformed (7) (Item 336, Appendix E)
 Packing, Preformed (4) (Item 389, Appendix E)

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)
 Outriggers down with weight off
 vehicle suspension, (TM 9-2320-364-10)






WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Do not work on any item supported only by lift jacks or hoist. Always use blocks or proper stands to support the item prior to any work. Equipment may fall and cause injury or death to personnel.

NOTE

- Use a drain pan to catch leaking hydraulic oil.
- Fluid laying in hose and fitting should drain quickly and then stop. Hose may drain more fluid for a longer period of time than fitting.



VISUAL INSPECTION	
(1)	Start engine (TM 9-2320-364-10).
(2)	Set WINCH/CRANE switch to CRANE position.
(3)	Set hydraulic selector switch to CRANE/SRW position.
(4)	Set crane POWER switch to ON position.
(5)	Raise boom until approximately level with ground using BOOM control lever.
(6)	Raise mast completely using MAST control lever.
(7)	Attach lifting device to boom and support boom.
(8)	Disconnect hose from fitting at bottom of boom lift cylinder on LHS side of crane. Discard preformed packing.
(9)	Allow boom to creep down with lifting device. Do not remove lifting device from boom.
(10)	Allow fluid laying in hose and fitting to drain out. <ul style="list-style-type: none"> (a) If no hydraulic fluid drains from fitting or hose after fluid laying in fitting and hose has drained out, perform Steps (11) through (18) below and go to Step 2 of this Fault. (b) If fluid continues to drain from fitting or hose as boom creeps down, that cylinder is faulty. Fluid from leaking load control valve will continue to leak from hose or fitting as long as cylinder is allowed to creep down. Perform Steps (11) through (18) below and replace holding valve that continues to leak hydraulic fluid (Para 16-7). <i>Continued on next page.</i>

17. BOOM CREEPS DOWN (CONT).




WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Do not work on any item supported only by lift jacks or hoist. Always use blocks or proper stands to support the item prior to any work. Equipment may fall and cause injury or death to personnel.

NOTE

- Use a drain pan to catch leaking hydraulic oil.
- Fluid laying in hose and fitting should drain quickly and then stop. Hose may drain more fluid for a longer period of time than fitting.

OPERATION TEST (CONT).	
(11)	Support boom with lifting device.
(12)	Connect hose with preformed packing fitting.
(13)	Remove lifting device from boom.
(14)	Operate boom lift cylinders using BOOM control lever to remove any air that may be in cylinders.
(15)	Place crane in stowed position (TM 9-2320-364-10).
<i>Continued on next page.</i>	



WARNING




- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Do not work on any item supported only by lift jacks or hoist. Always use blocks or proper stands to support the item prior to any work. Equipment may fall and cause injury or death to personnel.

NOTE


- Use a drain pan to catch leaking hydraulic oil.
- Fluid laying in hose and fitting should drain quickly and then stop. Hose may drain more fluid for a longer period of time than fitting.

OPERATION TEST (CONT).

- (16) Place crane power switch to OFF position.
- (17) Set hydraulic selector switch to OFF position.
- (18) Turn OFF ENGINE switch.



17. BOOM CREEPS DOWN (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Remove four nuts, lockwashers, washers, screws and cover. Discard lockwashers.
- (2) Disconnect upper hose from outboard (taller) elbow above BOOM valve. Discard preformed packings.
- (3) Connect flowmeter OUT port adapter hose with preformed packing to the crane hose removed from outboard (taller) elbow.
- (4) Connect flowmeter IN port adapter hose with preformed packing to outboard (taller) elbow.
- (5) Start engine (TM 9-2320-364-10).
- (6) Set WINCH/CRANE switch to CRANE position.
- (7) Set hydraulic selector switch to CRANE/SRW position.
- (8) Set crane POWER switch to ON position.
- (9) Extend boom lift cylinders completely.
- (10) Hold BOOM control lever in the UP position.
 - (a) If more than 0 gpm (0 lpm) are present, go to Step 3 of this Fault.
 - (b) If 0 gpm (0 lpm) are present, fault not corrected. Perform Steps (11) through (15) below and notify supervisor.
- (11) Set crane POWER switch to OFF position.
- (12) Set hydraulics selector switch to OFF position.
- (13) Turn OFF ENGINE switch.
- (14) Disconnect adapter hoses from elbow and crane hose. Discard preformed packings.
- (15) Connect crane hose with preformed packing to elbow.



17. BOOM CREEPS DOWN (CONT).



WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Set crane POWER switch to OFF position (TM 9-2320-364-10).
- (2) Set hydraulic selector switch to OFF position.
- (3) Turn OFF ENGINE switch.
- (4) Disconnect flowmeter OUT port adapter hose from crane hose. Discard preformed packing.
- (5) Install plug with preformed packing in crane hose.
- (6) Tag, mark and disconnect three hoses from boom lift cylinder on side of boom without OSS box. Discard preformed packings.
- (7) Install plugs with preformed packings on disconnected hoses.
- (8) Install caps with preformed packings on two cylinder fittings closest to four valve bank.
- (9) Connect adapter hose with preformed packing to remaining fitting on boom lift cylinder.
- (10) Start engine.
- (11) Set WINCH/CRANE switch to CRANE position.
- (12) Set hydraulic selector switch to CRANE/SRW position.
- (13) Set crane POWER switch to ON position.
- (14) Hook hoist block on ring and take out slack in cable to prevent boom from raising.
- (15) Hold BOOM lever in UP position.
 - (a) If more than 0 gpm (0 lpm) are measured, perform Steps (16) through (23) below and replace boom lift cylinder (Para 16-6) on LHS side of boom.
 - (b) If 0 gpm (0 lpm) are measured, perform Steps (16) through (23) below and replace boom cylinder (Para 16-6) on cab side of boom.

Continued on next page.



17. BOOM CREEPS DOWN (CONT).

WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST (CONT).

- (16) Set crane POWER switch to OFF position.
- (17) Set hydraulics selector switch to OFF position.
- (18) Turn OFF ENGINE switch.
- (19) Disconnect adapter hose and two caps from cylinder. Discard preformed packing.
- (20) Remove three plugs from hoses. Discard preformed packings.
Continued on next page.



WARNING



- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST (CONT).

- (21) Connect three hoses with preformed packings to boom lift cylinder.
- (22) Disconnect adapter hoses from elbow and crane hose. Discard preformed packings.
- (22) Connect crane hose with preformed packing to elbow.
- (23) Install cover with four screws, washers, lockwashers and nuts.






17. BOOM CREEPS DOWN (CONT).



VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Start engine (TM 9-2320-364-10).
- (3) Set WINCH/CRANE switch to CRANE position.
- (4) Set hydraulic selector switch to CRANE/SRW position.
- (5) Raise boom using BOOM control lever.
- (6) Set crane POWER switch to OFF position.
- (7) Set hydraulic selector switch to OFF position.
- (8) Turn OFF ENGINE switch.
 - (a) If boom creeps down, fault not corrected. Notify supervisor.
 - (b) If boom does not creep down, fault has been corrected.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

18. HOIST DOES NOT OPERATE OR OPERATES SLOWLY.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Cap and Plug Set (Item 26, Appendix F)
- Pan, Drain 4 gal (Item 144, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)
- Wrench, Torque (0-175 lb-ft) (Item 277, Appendix F)
- Lifting Device (Minimum Capacity 200 lbs/91 kg)

Materials/Parts

- Oil, Hydraulic (Item 34, Appendix B)
- Tags, Identification (Item 72, Appendix B)
- Gasket (Item 106, Appendix E)

Materials/Parts - Continued


- Lockwasher (4) (Item 282, Appendix E)
- Lockwasher (2) (Item 286, Appendix E)
- Packing, Preformed (2) (Item 337, Appendix E)
- Packing, Preformed (2) (Item 345, Appendix E)


References

- TM 9-2320-364-10
- TM 9-2320-364-20



Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Outriggers down with weight off vehicle suspension, (TM 9-2320-364-10)






OPERATION TEST	
(1)	Start engine (TM 9-2320-364-10).
(2)	Set WINCH/CRANE switch to CRANE position.
(3)	Set hydraulic selector switch to CRANE/SRW position.
(4)	Set crane POWER switch to ON position.
(5)	Attempt to operate hoist while holding BOOM control lever in UP position.
(a)	If hoist does not operate, perform Steps (6) through (8) below and go to Step 2 of this Fault.
(b)	If hoist operates, perform Steps (6) through (8) below and repair check valve in four valve bank lift/hoist manifold (Para 16-26).
(6)	Set crane POWER switch to OFF position.
(7)	Set hydraulic selector switch to OFF position.
(8)	Turn OFF ENGINE switch.



18. HOIST DOES NOT OPERATE OR OPERATES SLOWLY (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Remove four nuts, lockwashers, washers and screws and cover. Discard lockwashers.
- (2) Tag, mark and disconnect two hoses from elbows at top of four valve bank above HOIST valve. Discard preformed packings.
- (3) Connect adapter hose with preformed packing to inboard (smaller) elbow.
- (4) Connect adapter hose to flowmeter OUT port.
- (5) Connect adapter hose with preformed packing to outboard (taller) elbow.
- (6) Connect adapter hose to flowmeter IN port.
- (7) Open flowmeter load valve.
- (8) Start engine (TM 9-2320-364-10).
- (9) Set WINCH/CRANE switch to CRANE position.
- (10) Set hydraulic selector switch to CRANE/SRW position.
- (11) Set crane POWER switch to ON position.
- (12) Hold HOIST control lever in UP position and observe flowmeter.
 - (a) If 10 gpm (38 lpm) or more are not present, perform Steps (13) through (17) below and go to Step 4 of this Fault.
 - (b) If 10 gpm (38 lpm) or more are present, perform Steps (13) through (17) below and go to Step 3 of this Fault.
- (13) Set crane POWER switch to OFF position.
- (14) Set hydraulic selector switch to OFF position.
- (15) Turn OFF ENGINE switch.
- (16) Disconnect adapter hoses from elbows. Discard preformed packings.
- (17) Connect two hoses with preformed packings to elbows.








18. HOIST DOES NOT OPERATE OR OPERATES SLOWLY (CONT).




WARNING

All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

- OPERATION TEST**
- (1) Attach lifting device to hoist motor.
 - (2) Remove two screws, lockwashers and hoist motor from hoist assembly. Discard lockwashers.
 - (3) Remove gasket and coupler from hoist assembly. Discard gasket.
 - (4) Start engine (TM 9-2320-364-10).
 - (5) Set WINCH/CRANE switch to CRANE position.
 - (6) Set hydraulic selector switch to CRANE/SRW position.
 - (7) Set crane POWER switch to ON position.
 - (8) Hold HOIST control lever in UP position.
 - (a) If hoist motor does not operate, perform Steps (9) through (13) below and replace hoist motor (Para 16-12).
 - (b) If hoist motor does operate, hoist assembly (not hoist brake) is faulty. Perform Steps (9) through (13) below and notify supervisor.
 - (9) Set crane POWER switch to OFF position.
 - (10) Set hydraulic selector switch to OFF position.
 - (11) Turn OFF ENGINE switch.
 - (12) Install gasket and coupler on hoist assembly.
 - (13) Install hoist motor on hoist assembly with two screws and lockwashers. Tighten screws to 75 lb-ft (102 N·m).



18. HOIST DOES NOT OPERATE OR OPERATES SLOWLY (CONT).



WARNING





- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Remove four valve bank from crane (Para 16-26).
- (2) Remove HOIST valve from four valve bank (Para 16-26).
- (3) Remove orifice from four valve bank where HOIST valve was removed from (Para 16-26).
- (4) Inspect orifice for contamination clogging it.
 - (a) If orifice is contaminated, clean or replace orifice and inspect bores in HOIST valve for additional contaminants (Para 16-26).
 - (b) If orifice is OK, repair HOIST valve on four valve bank (Para 16-26).
- (5) Install orifice on four valve bank (Para 16-26).
- (6) Install HOIST valve on four valve bank (Para 16-26).
- (7) Install four valve bank on crane (Para 16-26).
- (8) Install cover with four screws, washers, lockwashers, and nuts.






18. HOIST DOES NOT OPERATE OR OPERATES SLOWLY (CONT).



VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Start engine (TM 9-2320-364-10).
- (3) Set WINCH/CRANE switch to CRANE position.
- (4) Set hydraulic selector switch to CRANE/SRW position.
- (5) Set crane POWER switch to ON position.
- (6) Operate hoist using HOIST control lever.
 - (a) If hoist does not operate, fault not corrected. Perform Steps (7) through (9) below and notify supervisor.
 - (b) If hoist operates, fault has been corrected.
- (7) Set crane POWER switch to OFF position.
- (8) Set hydraulic selector switch to OFF position.
- (9) Turn OFF ENGINE switch.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

19. HOIST DOES NOT LOWER.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Cap and Plug Set (Item 26, Appendix F)
- Pan, Drain 4 gal (Item 144, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)
- Wrench, Torque (0-175 lb-ft) (Item 277, Appendix F)
- Lifting Device (Minimum Capacity 200 lbs/91 kg)

Materials/Parts

- Oil, Hydraulic (Item 34, Appendix B)
- Sealing Compound (Item 53, Appendix B)
- Tags, Identification (Item 72, Appendix B)
- Gasket (Item 106, Appendix E)
- Kit, Repair (Item 153, Appendix E)
- Lockwasher (4) (Item 282, Appendix E)

Materials/Parts - Continued


- Lockwasher (2) (Item 286, Appendix E)
- Packing, Preformed (Item 336, Appendix E)
- Packing, Preformed (2) (Item 337, Appendix E)
- Packing, Preformed (2) (Item 343, Appendix E)
- Packing, Preformed (2) (Item 345, Appendix E)
- Packing, Preformed (2) (Item 348, Appendix E)
- Packing, Preformed (Item 383, Appendix E)

References

- TM 9-2320-364-10
- TM 9-2320-364-20

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Outriggers down with weight off vehicle suspension, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Remove four nuts, lockwashers, washers and screws and cover. Discard lockwashers.
- (2) Tag, mark and disconnect two hoses from elbows at top of four valve bank above HOIST valve. Discard preformed packings.
- (3) Connect adapter hose with preformed packing to inboard (smaller) elbow.
- (4) Connect adapter hose to flowmeter IN port.
- (5) Connect adapter hose with preformed packing to outboard (taller) elbow.
- (6) Connect adapter hose to flowmeter OUT port.
- (7) Open flowmeter load valve.
- (8) Start engine (TM 9-2320-364-10).
- (9) Set WINCH/CRANE switch to CRANE position.
- (10) Set hydraulic selector switch to CRANE/SRW position.
- (11) Set crane POWER switch to ON position.
- (12) Hold HOIST control lever in DOWN position and observe flowmeter.
 - (a) If 10 gpm (38 lpm) or more are not present, perform Steps (13) through (17) below and replace HOIST valve on four valve bank (Para 16-26).
 - (b) If at least 10 gpm (38 lpm) are present, perform Steps (13) through (17) below and go to Step 2 of this Fault.
- (13) Set crane POWER switch to OFF position
- (14) Set hydraulic selector switch to OFF position
- (15) Turn OFF ENGINE switch.
- (16) Disconnect adapter hoses from elbows. Discard preformed packings.
- (17) Connect two hoses with preformed packings to elbows.
- (18) Install cover with four screws, washers, lockwashers and nuts.






19. HOIST DOES NOT LOWER (CONT).




WARNING

All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

OPERATION TEST	
(1)	Attach lifting device to hoist motor.
(2)	Remove two screws, lockwashers and hoist motor from hoist assembly. Discard lockwashers.
(3)	Remove gasket and coupler from hoist assembly. Discard gasket.
(4)	Start engine (TM 9-2320-364-10).
(5)	Set WINCH/CRANE switch to CRANE position.
(6)	Set hydraulic selector switch to CRANE/SRW position.
(7)	Set crane POWER switch to ON position.
(8)	Hold HOIST control lever in DOWN position. <ul style="list-style-type: none"> (a) If hoist motor does not operate, perform Steps (9) through (13) below and go to Step 4 of this Fault. (b) If hoist motor does operate, perform Steps (9) through (13) below and go to Step 3 of this Fault.
(9)	Set crane POWER switch to OFF position.
(10)	Set hydraulic selector switch to OFF position.
(11)	Turn OFF ENGINE switch.
(12)	Install gasket and coupler on hoist assembly.
(13)	Install hoist motor on hoist assembly with two screws and lockwashers. Tighten screws to 75 lb-ft (102 N-m).



19. HOIST DOES NOT LOWER (CONT).



WARNING


- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

NOTE


Use a drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Disconnect hose from hoist brake check valve. Discard preformed packing.
- (2) Remove check valve from hoist brake elbow.
- (3) Using a non metallic rod, push on check ball inside check valve.
 - (a) If check valve check ball is stuck open, check valve is faulty. Replace hoist brake check valve (Para 16-14).
 - (b) If check valve check ball has freedom of movement inside check valve, hoist brake is faulty. Perform Steps (4) through (7) below and notify supervisor.
- (4) Coat check valve threads that will be installed into hoist brake elbow with pipe sealant.
- (5) Install check valve on hoist brake elbow.
- (6) Coat preformed packing with oil.
- (7) Install hose with preformed packing on hoist brake check valve.



19. HOIST DOES NOT LOWER (CONT).






WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.



VISUAL INSPECTION
<p>(1) Tag, mark and disconnect three hoses from hoist motor valve. Discard preformed packings.</p> <p>(2) Remove four screws, lockwashers, hoist motor valve and two preformed packings from hoist motor. Discard preformed packings and lockwashers.</p> <p>(3) Remove safety relief (holding) valve, three preformed packings, backup rings and orifice from hoist motor valve. Discard three preformed packings and backup rings.</p> <p style="margin-left: 20px;">(a) If orifice is clogged with contaminants, clean or replace orifice (Para 16-13) and perform Steps (4) through (7) below.</p> <p style="margin-left: 20px;">(b) If orifice is OK, safety relief valve is faulty. Replace safety relief valve in hoist motor valve (Para 16-13) and perform Steps (4) through (7) below.</p> <p>(4) Install preformed packing, backup ring, preformed packing, two backup rings and preformed packing on safety relief valve.</p> <p>(5) Install orifice and safety relief valve in hoist motor valve.</p> <p>(6) Install hoist motor valve with two preformed packings and four screws and lockwashers.</p> <p>(7) Install three hoses with preformed packings on hoist motor valve.</p>



19. HOIST DOES NOT LOWER (CONT).



VERIFY REPAIR
<ol style="list-style-type: none"> (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20). (2) Operate hoist using HOIST control lever (TM 9-2320-364-10). <ol style="list-style-type: none"> (a) If hoist does not lower, fault not corrected. Perform Steps (3) through (5) below and notify supervisor. (b) If hoist lowers, fault has been corrected. (3) Turn OFF crane POWER switch. (4) Set hydraulic selector switch to OFF position. (5) Turn OFF ENGINE switch.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

20. HOIST DOES NOT RAISE.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Cap and Plug Set (Item 26, Appendix F)
- Pan, Drain 4 gal (Item 144, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)
- Wrench, Torque (0-175 lb-ft) (Item 277, Appendix F)
- Lifting Device (Minimum Capacity 200 lbs/91 kg)

Materials/Parts

- Oil, Hydraulic (Item 34, Appendix B)
- Tag, Identification (Item 72, Appendix B)
- Gasket (Item 106, Appendix E)

Materials/Parts- Continued


- Lockwasher (4) (Item 282, Appendix E)
- Lockwasher (2) (Item 286, Appendix E)
- Packing, Preformed (2) (Item 337, Appendix E)
- Packing, Preformed (2) (Item 345, Appendix E)
- Packing, Preformed (2) (Item 363, Appendix E)

References

- TM 9-2320-364-10
- TM 9-2320-364-20

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Outriggers down with weight off vehicle suspension, (TM 9-2320-364-10)




WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST
(1) Remove four nuts, lockwashers, washers and screws and cover. Discard lockwashers.
(2) Tag, mark and disconnect two hoses from elbows at top of four valve bank above HOIST valve. Discard preformed packings.
(3) Connect adapter hose with preformed packing to inboard (smaller) elbow.
(4) Connect adapter hose to flowmeter OUT port.
(5) Connect adapter hose with preformed packing to outboard (taller) elbow.
(6) Connect adapter hose to flowmeter IN port.
(7) Open flowmeter load valve.
(8) Start engine (TM 9-2320-364-10).
(9) Set WINCH/CRANE switch to CRANE position.
(10) Set hydraulic selector switch to CRANE/SRW position.
(11) Set crane POWER switch to ON position.
(12) Hold HOIST control lever in UP position and observe flowmeter. <ul style="list-style-type: none"> (a) If 10 gpm (38 lpm) or more are not present, perform Steps (13) through (17) below and go to Step 5 of this Fault. (b) If 10 gpm (38 lpm) or more are present, go to Step 2 of this Fault.
(13) Set crane POWER switch to OFF position.
(14) Set hydraulic selector switch to OFF position.
(15) Turn OFF ENGINE switch.
(16) Disconnect adapter hoses from elbows.
(17) Connect two hoses with preformed packings to elbows.



20. HOIST DOES NOT RAISE (CONT).



WARNING




- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Hold HOIST control lever in UP position while closing flowmeter load valve.
 - (a) If 2000 to 2150 psi (13,790 to 14,824 kPa) are not present, go to Step 4 of this Fault.
 - (b) If 2000 to 2150 psi (13,790 to 14,824 kPa) are present, perform Steps (2) through (7) below and go to Step 3 of this Fault.
- (2) Open flowmeter load valve.
- (3) Set crane POWER switch to OFF position.
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.
- (6) Disconnect adapter hoses from elbows. Discard preformed packings.
- (7) Connect two hoses with preformed packings to elbows.



20. HOIST DOES NOT RAISE (CONT).









WARNING


All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

OPERATION TEST

- (1) Attach lifting device to hoist motor.
- (2) Remove two screws, lockwashers and hoist motor from hoist assembly. Discard lockwashers.
- (3) Remove gasket and coupler from hoist assembly. Discard gasket.
- (4) Start engine (TM 9-2320-364-10).
- (5) Set WINCH/CRANE switch to CRANE position.
- (6) Set hydraulic selector switch to CRANE/SRW position.
- (7) Set crane POWER switch to ON position.
- (8) Hold HOIST control lever in UP position.
 - (a) If hoist motor does not operate, perform Steps (9) through (14) below and replace safety relief valve on hoist motor valve (Para 16-13).
 - (b) If hoist motor does operate, hoist brake is faulty. Perform Steps (9) through (14) below and notify supervisor.
- (9) Set crane POWER switch to OFF position.
- (10) Set hydraulic selector switch to OFF position.
- (11) Turn OFF ENGINE switch.
- (12) Install gasket and coupler on hoist assembly.
- (13) Install hoist motor on hoist assembly with two screws and lockwashers. Tighten screws to 75 lb-ft (102 N-m).
- (14) Install cover with four screws, washers, lockwashers and nuts.



20. HOIST DOES NOT RAISE (CONT).



WARNING



- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Loosen jam nut on hoist relief valve.
- (2) Attempt to adjust hoist relief valve to 2100 psi (14,480 kPa) with flowmeter pressure control valve closed and HOIST control lever in UP position.
 - (a) If pressure cannot be adjusted to 2100 psi (14,480 kPa), perform Steps (2) through (7) below and repair relief valve in four valve bank lift/hoist manifold (Para 16-26).
 - (b) If pressure can be adjusted to 2100 psi (14,480 kPa), tighten jam nut on relief valve and perform Steps (2) through (7) below.
- (2) Open flowmeter load valve.
- (3) Set crane POWER switch to OFF position.
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.
- (6) Disconnect adapter hoses from elbows. Discard preformed packings.
- (7) Connect two hoses with preformed packings to elbows.
- (8) Install cover with four screws, washers, lockwashers and nuts.



20. HOIST DOES NOT RAISE (CONT).



WARNING





- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST

- (1) Disconnect hose 2918 from main hydraulic filter.
- (2) Connect adapter hose to filter.
- (3) Connect adapter hose to flowmeter OUT port.
- (4) Connect adapter hose to hose 2918.
- (5) Connect adapter hose to flowmeter IN port.
- (6) Open flowmeter load valve.
- (7) Start engine (TM 9-2320-364-10).
- (8) Set WINCH/CRANE switch to CRANE position.
- (9) Set hydraulic selector switch to CRANE/SRW position.
- (10) Turn ON crane POWER switch.
- (11) Observe and record gpm (lpm) measured.
- (12) Hold HOIST control lever in UP position.
 - (a) If an increase in flow is not measured, perform Steps (13) through (18) below and repair HOIST valve on four valve bank (Para 16-33).
 - (b) If an increase in flow is measured, hoist relief valve or OSS directional valve is faulty. Replace hoist OSS directional valve in four valve bank (Para 16-26). Perform Steps (13) through (15) and go to Step 6 of this Fault.
- (13) Set crane POWER switch to OFF position.
- (14) Set hydraulic selector switch to OFF position.
- (15) Turn OFF ENGINE switch.
- (16) Disconnect adapter hose from hose 2918. Discard preformed packing.
- (17) Disconnect adapter hose from return line filter. Discard preformed packing.
- (18) Connect hose 2918 to adapter.



20. HOIST DOES NOT RAISE (CONT).








WARNING

- High pressure hydraulics [oil under 3000 psi (20,685 kPa) pressure] operate this equipment. Refer to vehicle operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.


NOTE

Use a drain pan to catch leaking hydraulic oil.

FLOWMETER TEST
(1) Start engine (TM 9-2320-364-10).
(2) Set WINCH/CRANE switch to CRANE position.
(3) Set hydraulic selector switch to CRANE/SRW position.
(4) Turn ON crane POWER switch.
(5) Observe flowmeter to compare gpm (lpm) with gpm (lpm) measured in Step (6).
(6) Hold HOIST control lever in UP position. <ul style="list-style-type: none"> (a) If an increase in flow is not measured, fault not corrected. Perform Steps (7) through (12) below and notify supervisor. (b) If an increase in flow is measured, perform Steps (7) through (12) below and replace hoist relief valve on four valve bank (Para 16-26).
(7) Set crane POWER switch to OFF position.
(8) Set hydraulic selector switch to OFF position.
(9) Turn OFF ENGINE switch.
(10) Disconnect adapter hose from hose 2918. Discard preformed packing.
(11) Disconnect adapter hose from return line filter. Discard preformed packing.
(12) Connect hose 2918 to adapter.
(13) Install cover with screws, washers, lockwashers and nuts.






20. HOIST DOES NOT RAISE (CONT).



VERIFY REPAIR

- (1) Check hydraulic oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Operate hoist using HOIST control lever (TM 9-2320-364-10).
 - (a) If hoist does not raise, fault not corrected. Perform Steps (3) through (5) below and notify supervisor.
 - (b) If hoist raises, fault has been corrected.
- (3) Turn OFF crane POWER switch.
- (4) Set hydraulic selector switch to OFF position.
- (5) Turn OFF ENGINE switch.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

21. CRANE FAILS LOAD TEST.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- OSS Tester (Item 142, Appendix F)
- Protractor, Magnetic (Item 170, Appendix F)
- Tape Measuring (Item 235, Appendix F)
- Test Weight, 3890 to 3910 lbs (1766 kg)
- Test Weight, 4280 to 4300 lbs (1943 kg)

Materials/Parts

- Cable Tie (2) (Item 9, Appendix B)
- Sealing Compound (Item 62, Appendix B)
- Wire, Nonelectrical (Item 79, Appendix B)
- Packing, Preformed (4) (Item 357, Appendix E)

Personnel Required


Two


References

TM 9-2320-364-10

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Outriggers down with weight off vehicle suspension, (TM 9-2320-364-10)






NOTE

Flatrack may be on Load Handling System (LHS) for ease of testing.

OPERATION TEST

- (1) Start engine (TM 9-2320-364-10).
- (2) Set WINCH/CRANE switch to CRANE position.
- (3) Set hydraulic selector switch to CRANE/SRW position.
- (4) Set crane main POWER switch to ON position.
- (5) Disconnect hook block from truck.
- (6) Raise boom and mast using BOOM and MAST control levers.
- (7) Swing crane CCW using SWING control lever until boom is over LHS.
- (8) Position boom so that OSS box is easily reached when standing on LHS.
- (9) Set crane main POWER switch to OFF position.
- (10) Set hydraulic selector switch to OFF position.
- (11) Turn OFF ENGINE switch.

Continued on next page.



21. CRANE FAILS LOAD TEST (CONT).

WARNING

- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.

CAUTION

Hooked test unit connector must not contact other transistor wire or damage to OSS and test unit will result.


NOTE

When connecting test unit connector to display receptacle, test unit connector white wire must be engaged in the third pin from the right (fourth pin from left) of display receptacle.

OPERATION TEST (CONT).





- (12) Remove four screws, preformed packings, and cover from OSS box.
- (13) Remove safety lock seal from two screws.
- (14) Remove four screws and cover from central processor unit.
- (15) Connect test unit connector to display receptacle.
- (16) Connect test unit red connector to RH inductive coil wire.
- (17) Connect test unit black connector to LH inductive coil wire.
- (18) Connect test unit hooked connector to transistor middle wire.
- (19) Tie strap test unit connector cable to post.

Continued on next page.



WARNING


- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.



OPERATION TEST (CONT).

- (20) Start engine (TM 9-2320-364-10).
- (21) Set WINCH/CRANE switch to CRANE position.
- (22) Set hydraulic selector switch to CRANE/SRW position.
- (23) Turn ON crane main POWER switch.
- (24) Adjust clarity of display using control knob on bottom of test unit.
 - (a) If display does not come on, perform Steps (25) through (27) and repair green wire (see schematic Fig 2-7) or replace harness (Para 6-29) from OSS box top connector to crane main junction box.
 - (b) If display comes on, go to Step 2 of this Fault.
- (25) Set crane main POWER switch to OFF position.
- (26) Set hydraulic selector switch to OFF position.
- (27) Turn OFF ENGINE switch.

21. CRANE FAILS LOAD TEST (CONT).






WARNING

Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.


NOTE

Hoist drum has three layers of cable on it with hook block raised completely and boom telescoped out completely.

OPERATION TEST	
(1)	Raise hoist hook block completely using HOIST control lever (TM 9-2320-364-10).
(a)	If test unit display indicates LAYER = OFF, go to Step 8 of this Fault.
(b)	If test unit display indicates LAYER = ON, go to Step (2) below.
(2)	With the aid of an assistant observing hoist drum, lower hoist hook block using HOIST control lever.
(a)	If test unit does not indicate LAYER = OFF the instant the third layer of cable is off the hoist drum and only two layers remain, go to Step 8 of this Fault.
(b)	If test unit indicates LAYER = OFF the instant the third layer of cable is off the hoist drum and only two layers remain, hoist proximity sensor is OK. Go to Step 3 of this Fault.



21. CRANE FAILS LOAD TEST (CONT).





WARNING


Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.

CALIBRATION TEST

- (1) Attach magnetic protractor to underside of boom.
- (2) Compare actual angle indicated by magnetic protractor to angle indicated on test unit display.
 - (a) If indicated angles are not within 1 degree of each other, go to Step 10 of this Fault.
 - (b) If indicated angles are within 1 degree of each other, remove magnetic protractor from boom and go to Step 4 of this Fault.



21. CRANE FAILS LOAD TEST (CONT).




WARNING


Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.

CALIBRATION TEST

- (1) Using TELE control lever, extend boom completely (TM 9-2320-364-10).
 - (a) If test unit does not indicate 22.5 ft (6.86 m), go to Step 11 of this Fault.
 - (b) If test unit indicates 22.5 ft (6.86 m), go to Step (2) below.
- (2) Using TELE control lever, retract boom completely.
 - (a) If test unit does not indicate 7.3 ft (2.22 m), go to Step 11 of this Fault.
 - (b) If test unit indicates 7.3 ft (2.22 m), go to Step 5 of this Fault.



21. CRANE FAILS LOAD TEST (CONT).



WARNING




All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

NOTE


Test weight can be \pm 10 lbs (4.5 kg).

CALIBRATION TEST

- (1) Using BOOM control lever, operate boom until test unit indicates a 15 degree angle (TM 9-2320-364-10).
- (2) Using TELE control lever, telescope boom out completely.
- (3) Using HOIST control lever, operate hoist until hoist hook block is 3.5 ft. (1 m) above the ground.
 - (a) If test unit does not indicate WT = 0, go to Step 12 of this Fault.
 - (b) If test unit indicates WT = 0, go to Step (4) below.
- (4) Using BOOM control lever, lower boom until test unit indicates 5 degrees.
- (5) Connect hook block to 3900 lb. (1771 kg) load.
- (6) Using HOIST control lever, lift load from ground 3 to 4 ft. (91 to 122 cm).
 - (a) If test unit does not indicate WT = 3900 (1770 kg), lower load and go to Step 12 of this Fault.
 - (b) If test unit indicates WT = 3900 (1770 kg) go to Step 6 of this Fault.



21. CRANE FAILS LOAD TEST (CONT).




WARNING



All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

NOTE

- Boom should be telescoped out completely and at five degrees. Check that mast is up completely.
- Test weight can be \pm 10 lbs (4.5 kg).



LOAD TEST	
(1)	Using HOIST control lever, lift 3900 lb (1771 kg) load from ground (TM 9-2320-364-10).
(a)	If crane lifts load and OSS does not lock out crane functions, stow crane, perform Steps (2) through (4) and go to Step 7 of this Fault.
(b)	If OSS locks out crane functions, perform Steps (2) through (4) and replace OSS box (Para 6-8).
(2)	Set crane main POWER switch to OFF position.
(3)	Set hydraulic selector switch to OFF position.
(4)	Turn OFF ENGINE switch.



21. CRANE FAILS LOAD TEST (CONT).

KNOWN INFO
Unit Troubleshooting tasks completed. OSS box grounded. Hoist proximity sensor OK. OSS box calibrated correctly. Crane lifts loads in excess of load test specifications.
POSSIBLE PROBLEMS
OSS box faulty. Harness faulty.


7.

WARNING

Read **WARNING** on Page 2-689

Is continuity measured between connector, terminal B and crane junction box, terminal 18?




TEST OPTIONS
Continuity test.
REASON FOR QUESTION
If white wire from OSS box top connector to crane junction box, terminal 18 is faulty, 22 to 28 vdc will not be input to crane function lockout valves.




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.

CONTINUITY TEST	
(1)	Disconnect top harness connector from OSS box.
(2)	Loosen six screws and remove six clips from crane main junction box cover.
(3)	Remove cover from junction box.
(4)	Set multimeter to ohms scale.
(5)	Check continuity between harness connector, terminal B and junction box, terminal 18.
(a)	If no continuity is present, repair harness (Para 6-29).
(b)	If continuity is present, perform Step (6) below and replace OSS box (Para 6-8).
(6)	Install cover on junction box with six screws and clips.



21. CRANE FAILS LOAD TEST (CONT).




WARNING

Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.

OPERATION TEST

- (1) Using HOIST control lever, raise hoist hook block completely.
- (2) Using HOIST control lever, lower hook block until only one layer of cable remains on hoist drum.
 - (a) If test unit does not indicate both LAYER = ON and LAYER = OFF, go to Step 9 of this Fault.
 - (b) If test unit indicates both LAYER = OFF and LAYER = ON, adjust hoist proximity sensor (Para 6-9).
- (3) Using HOIST control lever, raise hook block. Test unit should indicate that proximity sensor turns on when third layer of cable starts.
 - (a) If test unit does not indicate the proximity sensor is ON, recheck hoist proximity sensor adjustment (Para 6-9).
 - (b) If test unit indicates that proximity sensor is on, go to Step 12 of this Fault.



21. CRANE FAILS LOAD TEST (CONT).


KNOWN INFO
Unit Troubleshooting tasks completed. OSS box is grounded.
POSSIBLE PROBLEMS
Hoist proximity sensor faulty. OSS box faulty.

9.

WARNING
Read **WARNING** on Page 2-693

Are 22 to 28 vdc measured at hoist proximity sensor black wire with hook block all the way up and 0 vdc measured with only two layers of cable on hoist drum?

TEST OPTIONS
Voltage test.
REASON FOR QUESTION
If hoist proximity sensor is faulty, 22 to 28 vdc may be input to OSS box when it should not be or voltage may not be input to OSS box when it should be.



WARNING

- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.


NOTE

It may be necessary to crack and remove paint from harness.

VOLTAGE TEST

- (1) Loosen two screws on adapter.
- (2) Remove adapter and washer from nut. Slide adapter and washer down harness and away from nut.
- (3) Pull seal from nut while holding harness to prevent pulling harness out of connector.
- (4) Remove nut from connector.
- (5) Set multimeter to volts dc.
- (6) Connect positive multimeter lead to black wire.
- (7) Connect negative multimeter lead to known good ground.

Continued on next page.




21. CRANE FAILS LOAD TEST (CONT).

WARNING

- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.

VOLTAGE TEST (CONT).

- (8) Start engine (TM 9-2320-364-10).
 - (9) Set WINCH/CRANE switch to CRANE position.
 - (10) Set hydraulic selector switch to CRANE/SRW position.
 - (11) Set crane main POWER switch to ON position.
 - (12) Using HOIST control lever, raise hoist hook block completely.
 - (a) If 0 vdc are present, perform Steps (14) through (20) and replace hoist proximity sensor (Para 6-9).
 - (b) If 22 to 28 vdc are present, go to Step (13) below.
 - (13) With the aid of an assistant, hold HOIST control lever in down position until only two even layers of cable remains on hoist cable drum.
 - (a) If 22 to 28 vdc are present, perform Steps (14) through (20) below and replace hoist proximity sensor (Para 6-9).
 - (b) If 0 vdc are present, replace OSS box (Para 6-8).
 - (14) Set crane main POWER switch to OFF position.
 - (15) Set hydraulic selector switch to OFF position.
 - (16) Turn OFF ENGINE switch.
- Continued on next page.*




WARNING


- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.

VOLTAGE TEST (CONT).

(17) Disconnect multimeter leads.
 (18) Install nut on connector.
 (19) Slide seal into nut.
 (20) Install washer and adapter on connector and tighten two screws.



21. CRANE FAILS LOAD TEST (CONT).






WARNING


- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.

ADJUSTMENT TEST

- (1) Loosen screw at bottom of angle sensor.
- (2) Attempt to adjust angle sensor so that actual angle (indicated by magnetic protractor) and angle indicated on test unit display are the same.
- (3) Tighten screw.
 - (a) If it is not possible to adjust angle sensor enough that test unit indicates actual angle, remove magnetic protractor from boom and replace OSS box (Para 6-8).
 - (b) If test unit indicates actual angle, angle sensor is OK. Remove magnetic protractor from boom and go to Step 14 of this Fault.



21. CRANE FAILS LOAD TEST (CONT).



WARNING

- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.


NOTE

- Record any adjustment made to gear assembly and length trimpot. The number of gear teeth moved or turns of trimpot screw may be necessary information for later steps.
- Adjustment made in Step (3) may be affected by adjustment made in Step (6).

ADJUSTMENT TEST

- (1) Using TELE control lever, retract boom completely (TM 9-2320-364-10).
 - (a) If test unit does not indicate 7.3 ft (2.22 m), go to Step (2) below.
 - (b) If test unit indicates 7.3 ft (2.22 m), go to Step (5) below.
- (2) Loosen screw on gear assembly and slide gear assembly away from idler gear being careful not to move gears in relation to each other.
- (3) Rotate gear assembly gear to the right to increase test unit reading or to the left to decrease test unit reading. Moving the gear one to two teeth in a particular direction will increase or decrease test unit reading 0.1 to 0.2 ft (.03 to .06 m).
- (4) Mesh gear assembly gear and idler gear and tighten screw when test unit indicates 7.3 ft (2.22 m).
 - (a) If it is not possible to adjust gear assembly enough that test unit indicates 7.3 ft (2.22 m), replace OSS box (Para 6-8).
 - (b) If test unit indicates 7.3 ft (2.22 m), go to Step (5) below.
- (5) Using TELE control lever, extend boom completely.
 - (a) If test unit does not indicate 22.5 ft (6.86 m), go to Step (6) below.
 - (b) If test unit indicates 22.5 ft (6.86 m) go to Step 14 of this Fault.
- (6) Adjust length trimpot until test unit indicates 22.5 ft (6.86 m).
 - (a) If it is not possible to adjust length trimpot enough that test unit indicates 22.5 ft (6.86 m), replace OSS box (Para 6-8).
 - (b) If test unit indicates 22.5 ft (6.86 m), go to Step (7) below.
- (7) Repeat Steps (1) through (6) a maximum of two more times to achieve a consistent reading of 7.3 ft (2.22 m) (retracted) and 22.5 ft (6.86 m) (extended) without needing adjustment.

Continued on next page.




21. CRANE FAILS LOAD TEST (CONT).

WARNING

- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.

ADJUSTMENT TEST (CONT).

- If Steps (1) through (6) have been completed three times and it is still necessary to adjust trimpot or gear every time boom is fully extended or retracted, go to Step (8) below.
 - If, after repeating Steps (1) through (6), the boom can be extended and retracted and test unit will indicate 22.5 ft (6.86 m) and 7.3 ft (2.22 m) without adjustment, go to Step 14 of this Fault.
- Loosen screw on gear assembly and slide gear assembly away from idler gear being careful not to move gears in relation to each other.
 - Rotate gear assembly gear back three teeth past the position it was in prior to any adjustment (if gear was turned seven teeth to the right during adjustment, then turn gear 10 teeth to the left).
 - Mesh gear assembly gear and idler gear and tighten screw.
 - Using TELE control lever, retract boom completely (TM 9-2320-364-10).
Continued on next page.




WARNING


- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.

ADJUSTMENT TEST (CONT).

- (12) Adjust length trimpot until test unit indicates 7.3 ft (2.22 m)
- (13) Using TELE control lever, extend boom completely.
 - (a) If test unit does not indicate 22.5 ft (6.86 m), go to Step (14) below.
 - (b) If test unit indicates 22.5 ft (6.86 m) go to Step 14 of this Fault.
- (14) Loosen screw on gear assembly and slide gear assembly away from idler gear being careful not to move gears in relation to each other.
- (15) Rotate gear assembly gear to the right to increase test unit reading or to the left to decrease test unit reading. Moving the gear 1 to 2 teeth in a particular direction will increase or decrease test unit reading 0.1 to 0.2 ft (.03 to .06 m).
- (16) Mesh gear assembly gear and idler gear and tighten screw when test unit indicates 22.5 ft (6.86 m).
- (17) Repeat Steps (8) through (17) until boom can be extended and retracted with test unit indicating 22.5 ft (6.86 m) and 7.3 ft (2.22 m) without adjustment and then go to Step 14 of this Fault.



21. CRANE FAILS LOAD TEST (CONT).



WARNING


- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

NOTE


- Boom should be telescoped out completely and at 5 degrees. Check that mast is up completely.
- Test weight can be ± 10 lbs (4.5 kg).
- Turn screw to right to increase display weight indication and to the left to decrease display weight indication.

ADJUSTMENT TEST

- (1) Using HOIST control lever, lift 3900 lbs (1771 kg) load from ground.
 - (a) If test unit does not indicate 3900 lbs (1770 kg), go to Step (2) below.
 - (b) If test unit indicates 3900 lbs (1770 kg), lower load to the ground and go to Step 13 of this Fault.
- (2) Attempt to adjust load trimpot until test unit display indicates 3900 lbs (1770 kg).
 - (a) If it is not possible to adjust trimpot enough that test unit indicates 3900 lbs (1770 kg), lower load to the ground and replace tension load cell (Para 16-25).
 - (b) If test unit indicates 3900 lbs, (1770 kg) lower load to the ground and go to Step 13 of this Fault.



21. CRANE FAILS LOAD TEST (CONT).




WARNING


- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

ADJUSTMENT TEST

- (1) Disconnect hook block from load.
- (2) Using LIFT control lever, move boom to 15 degrees (TM 9-2320-364-10).
- (3) Using HOIST control lever, position hook block 3.5 ft. (1 m) above ground.
- (4) Attempt to adjust load zero trimpot until test unit display indicates 0 lbs (0 kg).
 - (a) If it is not possible to adjust trimpot enough that test unit indicates 0 lbs (0 kg), replace OSS box (Para 6-8).
 - (b) If test unit indicates 0 lbs (0 kg), go to Step 14 of this Fault.



21. CRANE FAILS LOAD TEST (CONT).



WARNING






- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.
- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

CAUTION

Hooked test unit connector must not contact other transistor wire or damage to OSS and test unit will result.

VERIFY REPAIR

- (1) Set crane main POWER switch to OFF position.
- (2) Set hydraulic selector switch to OFF position.
- (3) Turn OFF engine switch.
- (4) Disconnect four connectors from OSS box.
- (5) Install cover on central processor unit with four screws.
- (6) Install safety lock seal on two screws.
- (7) Install cover on OSS box with four screws and preformed packings.
- (8) Apply bead of sealant to edge of cover where it is against OSS box.
- (9) Perform load test (Para 16-32).
 - (a) If crane does not pass load test, fault not corrected. Notify supervisor.
 - (b) If crane passes load test, fault has been corrected.



2-15. MATERIAL HANDLING CRANE TROUBLESHOOTING (CONT).

22. OVERLOAD SHUTDOWN SYSTEM (OSS) DISABLES CRANE FUNCTIONS, BOOM UP, BOOM DOWN, TELESCOPE OUT AND HOIST UP.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- OSS Tester (Item 142, Appendix F)

Materials/Parts


- Cable Ties (2) (Item 9, Appendix B)
- Sealing Compound (Item 62, Appendix B)
- Wire, Nonelectrical (Item 79, Appendix B)
- Packing, Preformed (4) (Item 357, Appendix E)

References

TM 9-2320-364-10

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)
- Outriggers down with weight off vehicle suspension, (TM 9-2320-364-10)



WARNING


Accumulator testing and charging can expose personnel to high pressure nitrogen. Use of proper safety equipment is required to prevent serious injury or death.

NOTE


- Accumulator can only be accurately charged when there is 0 psi (0 kPa) present in all crane hydraulic circuits.
- Ensure that all crane control levers are manually operated to the full up and down positions. Failure to comply could result in trapped hydraulic pressure, resulting in incorrect accumulator charge readings.

PRESSURE TEST

- (1) Manually operate all crane control levers fully up and down.
- (2) Remove two screws and guard.
- (3) Remove valve stem cap from accumulator fitting.
- (4) Attach accumulator pressure test hose to accumulator fitting.
- (5) Read accumulator charge pressure.
 - (a) If there is not 190 to 210 psi (1,310 to 1,448 kPa) present, recharge accumulator (Para 16-22).
 - (b) If there is 190 to 210 psi (1,310 to 1,448 kPa) present, perform Steps (6) through (8) below, and go to Step 2 of this Fault.
- (6) Remove accumulator pressure test hose from accumulator fitting.
- (7) Install valve stem cap on accumulator fitting.
- (8) Install guard with two screws.



22. OSS DISABLES FUNCTIONS (CONT).






NO → Go to Step 5 of this Fault.



YES ↓

WARNING


- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.



OPERATION TEST	
(1)	Loosen six screws and remove six clips from crane main junction box cover.
(2)	Remove cover from junction box.
(3)	Connect junction box terminals 1 and 19 using jumper wire.
(4)	Disconnect top connector from OSS box.
(5)	Start engine (TM 9-2320-364-10).
(6)	Set WINCH/CRANE switch to CRANE position.
(7)	Set hydraulic selector switch to CRANE/SRW position.
(8)	Set crane main POWER switch to ON position.
(9)	Attempt to operate boom and hoist functions using BOOM, TELESCOPE and HOIST control levers.
(a)	If functions do not operate, perform Steps (12) through (15) below and go to Step 5 of this Fault.
(b)	If functions operate, perform Steps (10) through (17) below and go to Step 3 of this Fault.
(10)	Position boom so that OSS box is accessible for repairs.
(11)	Telescope boom out completely.
(12)	Set crane main POWER switch to OFF position.
(13)	Set hydraulic selector switch to OFF position.
(14)	Turn OFF ENGINE switch.
(15)	Remove two screws and disconnect four white wires from crane main junction box, terminal 18.
(16)	Disconnect jumper wire from crane main junction box terminals 1 and 19.
(17)	Connect connector to OSS box.



22. OSS DISABLES FUNCTIONS (CONT).



WARNING

- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.



CAUTION

Hooked test unit connector must not contact other transistor wire or damage to OSS and test unit will result.

NOTE

When connecting test unit connector to display receptacle, test unit connector white wire receptacle must be engaged in the third pin from the right (fourth pin from left) of display receptacle.

CALIBRATION TEST	
(1)	Remove four screws, preformed packings, and cover from OSS box. Discard preformed packings.
(2)	Remove safety lock seal from two screws.
(3)	Remove four screws and cover from central processor unit.
(4)	Connect test unit connector to display receptacle pins.
(5)	Connect test unit red connector to RH inductive coil wire.
(6)	Connect test unit black connector to LH inductive coil wire.
(7)	Connect test unit hooked connector to transistor middle wire.
<i>Continued on next page.</i>	






22. OSS DISABLES FUNCTIONS (CONT).

WARNING

- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.

CALIBRATION TEST (CONT).

- (8) Start engine (TM 9-2320-364-10).
- (9) Set WINCH/CRANE switch to CRANE position.
- (10) Set hydraulic selector switch to CRANE/SRW position.
- (11) Set crane main POWER switch to ON position.
- (12) Using TELE control lever, telescope boom out completely.
- (13) Adjust clarity of test unit display using control knob on bottom of test unit.
 - (a) If test unit does not indicate between 22.0 and 23.0 ft (6.7 to 7 m), go to Step 4 of this Fault.
 - (b) If test unit indicates between 22.0 and 23.0 ft (6.7 to 7 m), go to Step (14) below.
- (14) Using TELE control lever, retract boom completely.
 - (a) If test unit does not indicate between 6.8 and 7.8 ft (2.1 to 2.4 m), go to Step 4 of this Fault.
 - (b) If test unit indicates between 6.8 and 7.8 ft (2.1 to 2.4 m), perform Steps (15) through (22) below and replace tension load cell (Para 16-25).
Continued on next page.








WARNING

- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.
- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


CAUTION

Hooked test unit connector must not contact other transistor wire or damage to OSS and test unit will result.

- CALIBRATION TEST (CONT).**
- (15) Set crane main POWER switch to OFF position (TM 9-2320-364-10).
 - (16) Set hydraulic selector switch to OFF position.
 - (17) Turn OFF engine switch.
 - (18) Disconnect four connectors from OSS box.
 - (19) Install cover on central processor unit with four screws.
 - (20) Install safety lock seal on two screws.
 - (21) Install cover on OSS box with four screws and preformed packings.
 - (22) Apply bead of sealant to edge of cover where it is against OSS box.



22. OSS DISABLES FUNCTIONS (CONT).



WARNING

- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.


NOTE

- Record any adjustment made to gear assembly and length trimpot. The number of gear teeth moved or turns of trimpot screw may be necessary information for later steps.
- Adjustment made in Step (3) may be affected by adjustment made in Step (6).

ADJUSTMENT TEST

- (1) Using TELE control lever, retract boom completely if not already done (TM 9-2320-364-10).
 - (a) If test unit does not indicate 7.3 ft (2.2 m), go to Step (2) below.
 - (b) If test unit indicates 7.3 ft (2.2 m), go to Step (5) below.
- (2) Loosen screw on gear assembly and slide gear assembly away from idler gear being careful not to move gears in relation to each other.
- (3) Rotate gear assembly gear to the right to increase test unit reading or to the left to decrease test unit reading. Moving the gear one to two teeth in a particular direction will increase or decrease test unit reading 0.1 to 0.2 ft (.03 to .06 m).
- (4) Mesh gear assembly gear and idler gear and tighten screw when test unit indicates 7.3 ft (2.2 m).
 - (a) If it is not possible to adjust gear assembly enough that test unit indicates 7.3 ft (2.2 m), replace OSS box (Para 6-8).
 - (b) If test unit indicates 7.3 ft (2.2 m), go to Step (5) below.
- (5) Using TELE control lever, extend boom completely.
 - (a) If test unit does not indicate 22.5 ft (6.86 m), go to Step (6) below.
 - (b) If test unit does indicate 22.5 ft (6.86 m) go to Step 14 of this Fault.
- (6) Adjust length trimpot until test unit indicates 22.5 ft (6.86 m).
 - (a) If it is not possible to adjust length trim pot enough that test unit indicates 22.5 ft (6.86 m), replace OSS box (Para 6-8).
 - (b) If test unit indicates 22.5 ft (6.86 m), go to Step (7) below.
- (7) Repeat Steps (1) through (6) a maximum of two more times to achieve a consistent reading of 7.3 ft (2.2 m) (retracted) and 22.5 ft (6.86 m) (extended) without needing adjustment.

Continued on next page.



22. OSS DISABLES FUNCTIONS (CONT).


WARNING

- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.

ADJUSTMENT TEST (CONT).

- If Steps (1) through (6) have been completed three times and it is still necessary to adjust trimpot or gear every time boom is fully extended or retracted, go to Step (8) below.
- If, after repeating Steps (1) through (6), the boom can be extended and retracted and test unit will indicate 22.5 ft (6.86 m) and 7.3 ft (2.2 m) without adjustment, go to Step 6 of this Fault.

- Loosen screw on gear assembly and slide gear assembly away from idler gear being careful not to move gears in relation to each other.
- Rotate gear assembly gear back three teeth past the position it was in prior adjustment (if gear was turned seven teeth to the right during adjustment, then turn gear 10 teeth to the left).
- Mesh gear assembly gear and idler gear and tighten screw.
- Using TELE control lever, retract boom completely (TM 9-2320-364-10).
Continued on next page.




WARNING


- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.

ADJUSTMENT TEST (CONT).

- (12) Adjust length trimpot until test unit indicates 7.3 ft (2.2 m).
- (13) Using TELE control lever, extend boom completely.
 - (a) If test unit does not indicate 22.5 ft (6.86 m), go to Step (14) below.
 - (b) If test unit does indicate 22.5 ft (6.86 m) go to Step 6 of this Fault.
- (14) Loosen screw on gear assembly and slide gear assembly away from idler gear being careful not to move gears in relation to each other.
- (15) Rotate gear assembly gear to the right to increase test unit reading or to the left to decrease test unit reading. Moving the gear one to two teeth in a particular direction will increase or decrease test unit reading 0.1 to 0.2 ft (.03 to .06 m).
- (16) Mesh gear assembly gear and idler gear and tighten screw when test unit indicates 22.5 ft (6.86 m).
- (17) Repeat Steps (8) through (17) until boom can be extended and retracted with test unit indicating 22.5 ft (6.86 m) and 7.3 ft (2.2 m) without adjustment and then go to Step 6 of this Fault.



22. OSS DISABLES FUNCTIONS (CONT).






WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.


NOTE

- Disconnected white wires should not be in contact.
- Steps (4) through (14) are for crane junction box.
- White wires should have 0 vdc present when OSS is not activated. Faulty wire is shorted to a wire with 22 to 28 vdc present.

CONTINUITY TEST	
(1)	Check disconnected harness connector for continuity between terminals B and A.
(a)	If continuity is present, replace harness (Para 6-29).
(b)	If continuity is not present, go to Step (2) below.
(2)	Check disconnected harness connector for continuity between terminals B and D.
(a)	If continuity is present, replace harness (Para 6-29).
(b)	If continuity is not present, go to Step (3) below.
(3)	Connect harness connector to OSS box.
(4)	Set multimeter to volts dc.
(5)	Connect multimeter negative lead to known good ground.
(6)	Connect multimeter positive lead to one of the four white wires disconnected from terminal 18 with ENGINE switch OFF (TM 9-2320-364-10).
(7)	Turn ON ENGINE switch.
(8)	Set WINCH/CRANE switch to CRANE position.
(9)	Set hydraulic selector switch to CRANE/SRW position.
(10)	Set crane main POWER switch to ON position.
(11)	Repeat Steps (6) through (10) until wire with 22 to 28 vdc present is found. Repair white wire (Fig 2-7) with 22 to 28 vdc present or replace harness after completing Steps (12) through (14) below.
(12)	Set crane main power switch to OFF position.
(13)	Set hydraulic selector switch to OFF position.
(14)	Turn OFF ENGINE switch.







22. OSS DISABLES FUNCTIONS (CONT).



WARNING

- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.


VERIFY REPAIR	
(1)	Connect four white wires on crane junction box, terminal 18 with two screws.
(2)	Disconnect jumper wire from crane junction box, terminals 1 and 19.
(3)	Start engine (TM 9-2320-364-10).
(4)	Set WINCH/CRANE switch to CRANE position.
(5)	Set hydraulic selector switch to CRANE/SRW position.
(6)	Turn ON crane main POWER switch.
(7)	Attempt to operate boom and hoist functions using BOOM, TELESCOPE and HOIST control levers.
(a)	If functions do not operate, fault not corrected. Notify supervisor and perform Steps (8) through (17) below.
(b)	If functions operate, fault has been corrected. Perform Steps (8) through (17) below.
<i>Continued on next page.</i>	



22. OSS DISABLES FUNCTIONS (CONT).

WARNING




- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.



VERIFY REPAIR (CONT).

- (8) Set crane main POWER switch to OFF position.
- (9) Set hydraulic selector switch to OFF position.
- (10) Turn OFF ENGINE switch.
- (11) Install cover on crane main junction box.
- (12) Place six clips on edge of cover and tighten six screws.

Continued on next page.



WARNING

- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits a direct short may result. Damage to equipment, injury or death to personnel may result.
- Do not stand under crane. Mechanical failure and operator error can cause injury or death to personnel.
- Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors, and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in well-ventilated area. If adhesives, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.


CAUTION

Hooked test unit connector must not contact other transistor wire or damage to OSS and test unit will result.

NOTE

If OSS box cover is installed, do not perform Steps (13) through (17) below.

VERIFY REPAIR (CONT).	
(13)	Disconnect four connectors from OSS box.
(14)	Install cover on central processor unit with four screws.
(15)	Install safety lock seal on two screws.
(16)	Install cover on OSS box with four screws and preformed packings.
(17)	Apply bead of sealant to edge of cover where it is against OSS box.



2-16. SELF-RECOVERY WINCH TROUBLESHOOTING.

This paragraph covers Self-Recovery Winch Troubleshooting. The Self-Recovery Winch Fault Index, Table 2-16, lists faults for the Self-Recovery Winch system of the PLS truck. Refer to schematic Figure 2-15 when performing tests and corrective actions.

Table 2-16. Self-Recovery Winch Fault Index

Fault No.	Description	Page
1.	Self-Recovery Winch (SRW) Does Not Operate	2-728




Figure 2-15. Self-Recovery Winch Hydraulic Diagram

2-16. SELF-RECOVERY WINCH TROUBLESHOOTING (CONT).

1. SELF-RECOVERY WINCH (SRW) DOES NOT OPERATE.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's (Item 240, Appendix F)
- Plug and Cap Set (Item 26, Appendix F)
- Pan, Drain 4 gal (Item 144, Appendix F)
- Pressure Test Kit (Item 165, Appendix F)
- Wrench, Torque (0-60 N·m) (Item 276, Appendix F)

Materials/Parts

- Lockwashers (6) (Item 266, Appendix E)
- Lockwashers (8) (Item 282, Appendix E)
- Parts Kit, Seal (Item 410, Appendix E)
- Parts Kit, Seal (Item 411, Appendix E)
- Parts Kit, Seal (Item 412, Appendix E)

Personnel Required


Two

References

- TM 9-2320-364-10
- TM 9-2320-364-20



Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)



WARNING


- High pressure hydraulics [oil under 3700 psi (25,512 kPa) pressure] operate this equipment. Refer to truck operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.



NOTE

Use drain pan to catch leaking hydraulic oil.

PRESSURE TEST
(1) Remove eight screws, lockwashers, washers and left side noise panel. Discard lockwashers.
(2) Remove six screws, lockwashers and LHS control box cover. Discard lockwashers.
(3) Remove dust cap from multifunction manifold, port G9.
(4) Connect pressure gauge to multifunction manifold, port G9. <i>Continued on next page.</i>



1. SELF-RECOVERY WINCH (SRW) DOES NOT OPERATE (CONT).

WARNING




- High pressure hydraulics [oil under 3700 psi (25,512 kPa) pressure] operate this equipment. Refer to truck operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE

Use drain pan to catch leaking hydraulic oil.



PRESSURE TEST (CONT).	
(5)	Start engine (TM 9-2320-364-10).
(6)	Set WINCH/CRANE switch to WINCH position.
(7)	Set hydraulic selector switch to CRANE/SRW position.
(8)	Move freespooling lever to disengage position.
(9)	With the aid of an assistant, hold winch lever in the forward position while observing pressure gauge.
(10)	With the aid of an assistant, hold winch lever in the rearward position while observing pressure gauge. <ul style="list-style-type: none"> (a) If 290 psi (2000 kPa) or more are not measured with lever forward and also with lever rearward, go to Step 2 of this Fault. (b) If 290 psi (2000 kPa) or more are measured with lever held in forward position and also with lever held in rearward position, perform Steps (11) through (14) below and go to Step 4 of this Fault.
(11)	Set hydraulic selector switch to OFF position.
(12)	Turn OFF ENGINE switch.

Continued on next page.



WARNING

- High pressure hydraulics [oil under 3700 psi (25,512 kPa) pressure] operate this equipment. Refer to truck operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.



NOTE

Use drain pan to catch leaking hydraulic oil.

PRESSURE TEST (CONT).


- (13) Disconnect pressure gage from multifunction manifold.
- (14) Install dust cap on multifunction manifold, port G9.

**MULTIFUNCTION
MANIFOLD**


**PORT
G9**

**DUST
CAP**

**PRESSURE
GAGE**




1. SELF-RECOVERY WINCH (SRW) DOES NOT OPERATE (CONT).



WARNING

- High pressure hydraulics [oil under 3700 psi (25,512 kPa) pressure] operate this equipment. Refer to truck operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.




NOTE

Use drain pan to catch leaking hydraulic oil.

PRESSURE TEST

- (1) With the aid of an assistant, hold winch lever in the forward position while observing pressure gage.
 - (a) If 290 psi (2000 kPa) or more are not present, Step (2) below.
 - (b) If 290 psi (2000 kPa) or more are measured, perform Steps (3) through (6) below and replace winch control manifold (Para 16-37).
- (2) With the aid of an assistant, hold winch lever in the rearward position while observing pressure gauge.
 - (a) If 290 psi (2000 kPa) or more are not measured, perform Steps (3) through (6) below and go to Step 3 of this Fault.
 - (b) If 290 psi (2000 kPa) or more are measured, perform Steps (3) through (6) below and replace winch control manifold (Para 16-37).
- (3) Set hydraulic selector switch to OFF position.
- (4) Turn OFF ENGINE switch.
- (5) Disconnect pressure gage from multifunction manifold.
- (6) Install dust cap on multifunction manifold, port G9.




MULTIFUNCTION MANIFOLD


PORT G9

DUST CAP

PRESSURE GAGE



1. SELF-RECOVERY WINCH (SRW) DOES NOT OPERATE (CONT).



WARNING


- High pressure hydraulics [oil under 3700 psi (25,512 kPa) pressure] operate this equipment. Refer to truck operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Remove nut and solenoid from valve.
- (2) Remove shuttle valve from multifunction manifold.
- (3) Remove three preformed packings and two packing retainers from shuttle valve. Discard preformed packings and packing retainers.
- (4) Shake shuttle valve hard enough to hear check ball rattle.
 - (a) If shuttle valve check ball does not rattle, replace shuttle valve (Para 17-18) and perform Step (7) below.
 - (b) If shuttle valve check ball rattles, perform Steps (5) through (7) below and replace winch control manifold (Para 16-37).
- (5) Install three preformed packings and two packing retainers on the shuttle valve that was removed from multifunction manifold.
- (6) Install shuttle valve in multifunction manifold.
- (7) Install solenoid and nut on valve.



1. SELF-RECOVERY WINCH (SRW) DOES NOT OPERATE (CONT).



WARNING


- High pressure hydraulics [oil under 3700 psi (25,512 kPa) pressure] operate this equipment. Refer to truck operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.

NOTE


Use drain pan to catch leaking hydraulic oil.

FLOWMETER TEST


- (1) Remove two tubes from between winch control manifold and counterbalance valve.
- (2) Connect flowmeter IN hose to top winch control manifold port.
- (3) Connect flowmeter OUT hose to bottom winch control manifold port.
- (4) Open flowmeter load valve.
- (5) Set lever in DISENGAGE position (TM 9-2320-364-10).
- (5) Start engine.
- (6) Set WINCH/CRANE switch to WINCH position.
- (7) Set hydraulic selector switch to CRANE/SRW position.
- (8) Observe flowmeter while holding winch control lever forward and then rearward.
 - (a) If 12 gpm (45 lpm) or more are not present, perform Steps (9) through (12) below and replace winch control manifold (Para 16-37).
 - (b) If 12 gpm (45 lpm) or more are present, perform Steps (9) through (12) below and go to Step 5 of this Fault.
- (9) Set hydraulic selector switch to OFF position.
- (10) Turn OFF ENGINE switch.
- (11) Disconnect adapter hoses from winch control manifold.
- (12) Install tubes between winch control manifold and counterbalance valve.



STEERING WHEEL SHOWN REMOVED FOR CLARITY



1. SELF-RECOVERY WINCH (SRW) DOES NOT OPERATE (CONT).



WARNING


- High pressure hydraulics [oil under 3700 psi (25,512 kPa) pressure] operate this equipment. Refer to truck operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Drycleaning Solvent (P-D-680) is TOXIC and flammable. Wear protective goggles, face shield, and gloves; use only in a well-ventilated area; avoid contact with skin, eyes, and clothes, and do not breathe vapors. Keep away from heat or flame. Never smoke when using solvent. The flashpoint for Type II Drycleaning Solvent is 140 degrees F (60 degrees C) and Type III Drycleaning Solvent is 200 degrees F (93 degrees C). Failure to do so may result in injury or death to personnel.
- If personnel become dizzy while using cleaning solvent, immediately get fresh air and medical help. If solvent contacts skin or clothes, flush with cold water. If solvent contacts eyes, immediately flush eyes with water and get immediate medical attention.

NOTE


Use drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Remove valve cartridge from counterbalance valve.
- (2) Remove preformed packings and backup rings from valve cartridge. Discard preformed packings and backup rings.
- (3) Clean cartridge with drycleaning solvent P-D-680.
- (4) Using a non-metallic probe, manually operate moving parts inside valve.
 - (a) If valve parts do not operate, replace valve cartridge (Para 16-36).
 - (b) If valve cartridge parts operate, perform Steps (5) and (6) below and go to Step 6 of this fault.
- (5) Install preformed packings on valve valve cartridge.
- (6) Install valve cartridge in counterbalance valve.



1. SELF-RECOVERY WINCH (SRW) DOES NOT OPERATE (CONT).



WARNING


- High pressure hydraulics [oil under 3700 psi (25,512 kPa) pressure] operate this equipment. Refer to truck operator and maintenance manuals for hydraulic oil pressure. Never disconnect any hydraulic line or fitting without first dropping pressure to zero. Failure to comply may result in injury to personnel.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Drycleaning Solvent (P-D-680) is TOXIC and flammable. Wear protective goggles, face shield, and gloves; use only in a well-ventilated area; avoid contact with skin, eyes, and clothes, and do not breathe vapors. Keep away from heat or flame. Never smoke when using solvent. The flashpoint for Type II Drycleaning Solvent is 140 degrees F (60 degrees C) and Type III Drycleaning Solvent is 200 degrees F (93 degrees C). Failure to do so may result in injury or death to personnel.
- If personnel become dizzy while using cleaning solvent, immediately get fresh air and medical help. If solvent contacts skin or clothes, flush with cold water. If solvent contacts eyes, immediately flush eyes with water and get immediate medical attention.

NOTE


Use drain pan to catch leaking hydraulic oil.

VISUAL INSPECTION

- (1) Remove relief valve from counterbalance valve.
- (2) Remove preformed packings and backup rings from relief valve. Discard preformed packings and backup rings.
- (3) Clean relief valve with drycleaning solvent P-D-680.
- (4) Using a non-metallic probe, manually operate moving parts inside valve.
 - (a) If valve parts do not operate, replace valve cartridge (Para 16-36).
 - (b) If valve cartridge parts operate, perform Steps (5) and (6) below and replace SRW motor (Para 16-35).
- (5) Install preformed packings on relief valve cartridge.
- (6) Install relief valve cartridge in counterbalance valve.





1. SELF-RECOVERY WINCH (SRW) DOES NOT OPERATE (CONT).



VERIFY REPAIR

- (1) Operate winch (TM 9-2320-364-10).
 - (a) If winch does not pay out or winch in winch cable, fault not corrected. Perform Steps (2) and (3) and notify supervisor.
 - (b) If winch pays out and winches in winch cable, fault has been corrected.
- (2) Install LHS control box cover with six screws and lockwashers.
- (3) Install left side noise panel with eight screws, lockwashers and washers.



2-17. STEERING SYSTEM TROUBLESHOOTING.

This paragraph covers Steering System Troubleshooting. The Steering System Fault Index, Table 2-17, lists faults for the steering system of the PLS truck. Refer to schematic Figure 2-16 when performing tests and corrective actions.

Table 2-17. Steering System Fault Index

Fault No.	Description	Page
1.	Truck Is Hard To Steer	2-746




Figure 2-16. Steering System Hydraulic Diagram

2-17. STEERING SYSTEM TROUBLESHOOTING (CONT).

1. TRUCK IS HARD TO STEER.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's
 (Item 240, Appendix F)
 Cap and Plug Set (Item 26, Appendix F)
 Jackstand (Item 132, Appendix F)
 Pan, Drain 4 gal (Item 144, Appendix F)
 Pressure Test Kit (Item 165, Appendix F)

Personnel Required

Two

References

TM 9-2320-364-10


TM 9-2320-364-20

Materials/Parts

Oil, Hydraulic (Item 34, Appendix B)
 Key (Item 137, Appendix E)
 Locknut (3) (Item 213, Appendix E)
 Lockwasher (2) (Item 249, Appendix E)

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)



STEERING TEST
(1) If hard steering occurs over 25 mph (40 km/hr), go to Step 3 of this Fault. (2) If hard steering occurs at less than 25 mph (40 km/hr), go to Step 9 of this Fault.

- (1) If hard steering occurs over 25 mph (40 km/hr), go to Step 3 of this Fault.
(2) If hard steering occurs at less than 25 mph (40 km/hr), go to Step 9 of this Fault.

1. TRUCK IS HARD TO STEER (CONT).


KNOWN INFO
Unit Troubleshooting tasks completed.
POSSIBLE PROBLEMS
Air present in steering system hydraulics. 2.21:1 gear reducer faulty. Shaft bearing and intersteering shaft faulty. Rear steering gear faulty. Front steering gear faulty. Intermediate steering gear faulty. Steering hydraulic pump faulty. Check valve faulty. Hydraulic pump control faulty. Front differential pressure sensing valve faulty. Priority flow valve faulty. Rear differential pressure sensing valve faulty. Sequence valve faulty.

2.

WARNING
Read WARNING on Page 2-749

Is steering system hydraulic oil free from air?

TEST OPTIONS
Purge steering system hydraulics.
REASON FOR QUESTION
If there is air in steering hydraulic system, truck will be hard to steer.




KNOWN INFO
Unit Troubleshooting tasks completed. Steering system hydraulics free of air.
POSSIBLE PROBLEMS
2.21:1 gear reducer faulty. Shaft bearing and intersteering shaft faulty. Rear steering gear faulty. Front steering gear faulty. Intermediate steering gear faulty. Steering hydraulic pump faulty. Check valve faulty. Hydraulic pump control faulty. Front differential pressure sensing valve faulty. Priority flow valve faulty. Rear differential pressure sensing valve faulty. Sequence valve faulty.

3.

Does 2.21:1 gear reducer turn freely without binding?

TEST OPTIONS
Visual inspection.
REASON FOR QUESTION
If 2.21:1 gear reducer binds or does not turn freely, truck will be hard to steer.



WARNING


The truck steering operates with 3000 psi (20,685 kPa) hydraulic pressure. A high pressure hydraulic oil stream can pierce a body and cause severe injury to personnel. Never disconnect any high pressure hydraulic oil line or fitting without first dropping pressure to zero.

PURGE STEERING SYSTEM
<p>Perform steering system purging procedure (Para 12-13).</p> <p>(1) If there is air present in steering hydraulic system, continue to purge system (Para 12-14) and go to Step 13 of this fault.</p> <p>(2) If there is no air in steering hydraulic system go to Step 3 of this fault.</p>


NOTE

Leave input shaft and steering shaft disconnected. They will be reconnected later in this task.

VISUAL INSPECTION
<p>(1) Remove two screws and locknuts from shaft bearing mounting bracket. Discard locknuts. Support steering shaft to keep it from falling.</p> <p>(2) Remove screw and locknut from intersteering shaft yoke at gear reducer. Discard locknut.</p> <p>(3) Slide intersteering shaft to the rear until yoke is free of gear reducer output shaft.</p> <p>(4) Remove screw and locknut from gear box steering shaft yoke. Discard locknut.</p> <p>(5) Slide gear box shaft forward until yoke is free of gear reducer input shaft. Support steering shaft to keep it from falling.</p> <p>(6) Turn 2.21:1 gear reducer input shaft by hand.</p> <p>(a) If shaft binds or does not turn freely, replace 2.21:1 gear reducer (Para 12-6).</p> <p>(b) If shaft turns freely without binding, 2.21:1 gear reducer is OK.</p> <p>(7) Install gear box steering shaft yoke on gear reducer input shaft.</p> <p>(8) Install screw and locknut on gear box steering shaft yoke.</p> <p>(9) Install intersteering shaft yoke on gear reducer output shaft.</p> <p>(10) Install shaft bearing mounting bracket, two screws and locknuts.</p>



1. TRUCK IS HARD TO STEER (CONT).




WARNING


If matchmarks are not aligned during installation of yoke, erratic steering will result. Erratic steering can cause serious injury or death to personnel.

VISUAL INSPECTION

- (1) Match mark Axle No. 5 steering shaft yoke and rear steering gear.
- (2) Remove screw, and locknut from Axle No. 5 steering shaft yoke. Discard locknut.
- (3) Slide Axle No. 5 steering shaft forward until yoke is free of rear steering gear input shaft. Support steering shaft to keep it from falling.
- (4) Turn Axle No. 5 steering shaft by hand.
 - (a) If shaft bearing binds and does not turn freely or shaft is bent, replace bearing and/or shaft (Para 12-6).
 - (b) If shaft bearing turns freely and shaft is OK, perform Steps (5) and (6) below and go to Step 5 of this Fault.
- (5) Align match marks on yoke and rear steering gear.
- (6) Slide yoke onto steering gear input shaft and install screw and locknut.





1. TRUCK IS HARD TO STEER (CONT).




VISUAL INSPECTION

- (1) Jack up rear axle until both wheels are off the ground (TM 9-2320-364-10).
- (2) Turn Axle No. 5 steering shaft by hand.
 - (a) If rear steering gear binds and does not turn freely, replace rear steering gear (Para 12-11).
 - (b) If rear steering gear turns freely without interference, rear steering gear is OK.




1. TRUCK IS HARD TO STEER (CONT).



←



WARNING

Use care when disconnecting intergear link. If it falls, it will cause injury to personnel.




VISUAL INSPECTION

- (1) Jack up Axles No. 1 and No. 2 until all four wheels are off the ground (TM 9-2320-364-10).
- (2) Remove screw, nut and lockwasher and disconnect intergear link from intermediate steering gear pitman arm. Discard lockwasher. Support intergear link to keep it from falling.
- (3) Remove screw, nut and draglink from front steering gear.
- (4) Turn steering wheel by hand.
 - (a) If steering gear binds and does not turn freely, replace front steering gear (Para 12-9).
 - (b) If steering gear turns freely without interference, go to Step 7 of this Fault.








1. TRUCK IS HARD TO STEER (CONT).




WARNING


Use care when disconnecting intergear link. If it falls, it will cause injury to personnel.

- VISUAL INSPECTION**
- (1) Turn intermediate steering gear pitman arm by hand.
 - (a) If intermediate steering gear binds and does not turn freely, replace intermediate steering gear (Para 12-10).
 - (b) If intermediate steering gear turns freely, go to Step 9 of this Fault.
 - (2) Slide intergear link into intermediate steering gear pitman arm and install screw, lockwasher and nut.
 - (3) Install bolt, locknut, and draglink in pitman arm.
 - (4) Install key and slide gear box steering shaft onto 2.21:1 gear reducer input shaft and install screw and locknut.
 - (5) Lower Axles No. 1, No. 2, and No. 5 until all wheels are on the ground.



1. TRUCK IS HARD TO STEER (CONT).






AUDIBLE INSPECTION

- (1) Start engine (TM 9-2320-364-10).
- (2) Open front access cover.
- (3) Listen to steering hydraulic pump operation.
 - (a) If pump does not make excessive noise, turn OFF ENGINE switch and go to Step 9 of this Fault.
 - (b) If pump make excessive noise while operating, turn OFF ENGINE switch and replace steering hydraulic pump (Para 17-2).

1. TRUCK IS HARD TO STEER (CONT).



WARNING

The truck steering operates with 3000 psi (20,685 kPa) hydraulic pressure. A high pressure hydraulic oil stream can pierce a body and cause severe injury to personnel. Never disconnect any high pressure hydraulic oil line or fitting without first dropping pressure to zero.

CAUTION


Damage to main steering pump or hydraulic pump control will occur if load valve is closed for more than 10 seconds.

NOTE


Use a drain pan to catch spilling hydraulic oil.

PRESSURE TEST

- (1) Open front access cover (TM 9-2320-364-10).
- (2) Remove dust cover from test point TP2.
- (3) Connect a 6000 psi (41,370 kPa) pressure gage to test point TP2.
- (4) Disconnect hose 2393 from MPO port on steering manifold.
- (5) Install a flowmeter in line between hose 2393 and MPO port on steering manifold.
- (6) Fully open flowmeter load valve.
- (7) Start engine.
 - (a) If 0 psi (0 kPa) are present at test point TP2 while 280 to 300 psi (1931 to 2069 kPa) are present on flowmeter, replace check valve (Para 17-7).
 - (b) If the pressure measured at test point TP2 is equal to the pressure measured at hose 2393, check valve is OK.
- (8) Slowly close load valve on flowmeter until flow drops to 0 gpm (0 lpm).
 - (a) If 3000 ± 150 psi ($20,685 \pm 1034$ kPa) are not present when flow is 0 gpm (0 lpm), adjust hydraulic pump control (Para 12-2). If hydraulic pump control adjustment does not change the pump output, perform Steps (9) through (13) below and replace hydraulic pump control (Para 17-4).
 - (b) If 3000 ± 150 psi ($20,685 \pm 1034$ kPa) are present when flow is 0 gpm (0 lpm), hydraulic pump control adjustment is OK.
- (9) Fully open load valve.
- (10) Turn OFF ENGINE switch.
- (11) Remove pressure/flow valve.
- (12) Connect hose 2393 to MPO port on steering manifold.
- (13) Check steering oil level and add oil as necessary (TM 9-2320-364-20).



1. TRUCK IS HARD TO STEER (CONT).




WARNING


The truck steering operates with 3000 psi (20,685 kPa) hydraulic pressure. A high pressure hydraulic oil stream can pierce a body and cause severe injury to personnel. Never disconnect any high pressure hydraulic oil line or fitting without first dropping pressure to zero.

CAUTION


Damage to main steering pump or hydraulic pump control will occur if load valve is closed for more than 10 seconds.



- | FLOW/PRESSURE TEST | |
|--------------------|---|
| (1) | Disconnect hose 2301 from front steering gear. |
| (2) | Install a flowmeter in line between hose 2301 and rear steering gear. |
| (3) | Fully open flowmeter load valve. |
| (4) | Start engine (TM 9-2320-364-10). |
| (a) | If less than 6 gpm (23 lpm) are present, replace priority flow valve (Para 12-13). |
| (b) | If 6 gpm (23 lpm) are present, priority flow valve is OK. |
| (5) | Slowly close load valve on meter. |
| (a) | If 2000 to 2025 psi (13,790 to 13,962 kPa) are not present when flow drops to 0 gpm (0 lpm), adjust pressure sensing valve (Para 12-2). |
| (b) | If 2000 to 2025 psi (13,790 to 13,962 kPa) are present, pressure sensing valve is adjusted correctly. |
| (6) | Open load valve fully. |
| (7) | Turn OFF ENGINE switch. |
| (8) | Install pressure sensing valve cover. |
| (9) | Connect hose 2301 to front steering gear. |
| (10) | Check steering oil level and add oil as necessary (TM 9-2320-364-20). |
| (11) | Close front access cover. |



1. TRUCK IS HARD TO STEER (CONT).



WARNING


The truck steering operates with 3000 psi (20,685 kPa) hydraulic pressure. A high pressure hydraulic oil stream can pierce a body and cause severe injury to personnel. Never disconnect any high pressure hydraulic oil line or fitting without first dropping pressure to zero.

CAUTION


Damage to main steering pump or hydraulic pump control will occur if load valve is closed for more than 10 seconds.

PRESSURE TEST

- (1) Disconnect hose 2275 from rear steering gear.
- (2) Install a flowmeter in line between hose 2275 and rear steering gear.
- (3) Open load valve on flowmeter fully.
- (4) Start engine (TM 9-2320-364-10).
 - (a) If less than 3 gpm (11 lpm) are present, perform Steps (6) and (7) below and replace priority flow valve (Para 12-13).
 - (b) If at least 3 gpm (11 lpm) are present, priority flow valve is OK.
- (5) Slowly close load valve on meter.
 - (a) If 2000 to 2025 psi (13,790 to 13,962 kPa) are not present when flow drops to 0 gpm (0 lpm), adjust pressure sensing valve (Para 12-13).
 - (b) If 2000 to 2025 psi (13,790 to 13,962 kPa) are present, pressure relief valve is adjusted correctly.
- (6) Open load valve fully.
- (7) Turn OFF ENGINE switch.



1. TRUCK IS HARD TO STEER (CONT).



WARNING



The truck steering operates with 3000 psi (20,685 kPa) hydraulic pressure. A high pressure hydraulic oil stream can pierce a body and cause severe injury to personnel. Never disconnect any high pressure hydraulic oil line or fitting without first dropping pressure to zero.

CAUTION

Damage to main steering pump or hydraulic pump control will occur if relief pressure is held for more than 10 seconds.

PRESSURE TEST

- (1) Start engine (TM 9-2320-364-10).
- (2) While assistant slowly turns steering wheel in one direction, slowly close load valve. Pressure should be 1800 psi (12,411 kPa) and flow will drop to zero and front axles will not steer.
 - (a) If 1800 to 1825 psi (12,411 to 12,583 kPa) are not present, adjust sequence valve (Para 12-2) or replace sequence valve (Para 12-13).
 - (b) If 1800 to 1825 psi (12,411 to 12,583 kPa) are present, sequence valve is adjusted correctly.
- (3) Turn OFF ENGINE switch.
- (4) Remove flowmeter.
- (5) Connect hose 2275 to rear steering gear.



VERIFY REPAIR

- (1) Check steering oil level and add oil as necessary (TM 9-2320-364-20).
- (2) Check steering while truck is moving at less than 25 mph (40 km/hr).
- (3) Check steering while truck is moving at greater than 25 mph (40 km/hr).
 - (a) If steering is still difficult, fault not corrected. Notify supervisor.
 - (b) If steering is no longer difficult, fault has been corrected.

2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING.

This paragraph covers Arctic Heater (Model B) Troubleshooting. The Arctic Heater (Model B) System Fault Index, Table 2-17.1, lists faults for the arctic heater (Model B) system of the PLS truck. Refer to schematic Figure 2-16.1 when performing tests and corrective actions.

Table 2-17.1. Arctic Heater (Model B) System Fault Index

Fault No.	Description	Page
1	First Chart For Diagnostic of Arctic Heater Troubleshooting (Model B)	2-766.4
2	Fault Code 001, 002, 010 or 011: Advance Warning-Overvoltage Shutdown, Advance Warning-Undervoltage Shutdown, Overvoltage Shutdown or Undervoltage Shutdown	2-766.10
3	Fault Code 012, 013, 014 or 015: Overheating, Excessive Temperature at Flame Sensor, Possible Overheating Detected or Too Many Overheats	2-766.12
4	Fault Code 020 or 021: Glow Pin Open Circuit or Glow Pin Short Circuit	2-766.14
5	Fault Code 033: Blower Motor Speed Fault	2-766.34
6	Fault Code 037, 042 or 059: Water Pump Not Working, Water Pump Short Circuit or Water Temperature Rises to Quickly	2-766.42
7	Fault Code 043, 047 or 048: Short Circuit at External Component, Fuel Metering Pump Short Circuit or Fuel Pump Open Circuit	2-766.46
8	Fault Code 050 or 052: Too Many No Start Attempts or No Start Safety Time Exceeded	2-766.48
9	Fault Code 051: Faulty Flame Recognition	2-766.64
10	Fault Code 053, 054, 55 or 056: Flame Cutout in Boost Mode, Flame Cutout in High Mode, Flame Cutout in Medium Mode or Flame Cutout in Low Mode	2-766.68
11	Fault Code 060, 061, 071 or 072: Temperature Sensor Open Circuit, Temperature Sensor Short Circuit, Overheat Sensor Open Circuit or Overheat Sensor Short Circuit	2-766.72
12	Fault Code 064 or 065: Flame Sensor Open Circuit or Flame Sensor Short Circuit	2-766.78
13	Fault Code 090, 093, 094 or 097: Control Unit Defective (Internal Fault, RAM Error, EPROM Fault or Power Fault)	2-766.82




Figure 2-16.1 Arctic Heater (Model B) Electrical Schematic

2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING (CONT).

1. FAULT CHART FOR DIAGNOSTIC OF ARCTIC HEATER TROUBLESHOOTING (MODEL B).

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's: Automotive (Item 241, Appendix F)
 STE/ICE-R (optional) (Item 15, Appendix F)
 Multimeter (Item 140, Appendix F)
 Fault Code Retrieval Device (FCRD) (Item 60.1, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)

NOTE

All unit level troubleshooting must be completed before performing this procedure.



WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE


- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (1) through (3) only if fault code retrieval device (FCRD) is available.

VISUAL INSPECTION
(1) Remove cover from arctic heater (TM 9-2320-364-20).
(2) Install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector.
(3) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.
(4) Turn arctic heater ON (TM 9-2320-364-10).
(5) Using the arctic heater indicator light and the chart to the right or the fault code retrieval device (FCRD), note which fault code is displayed.
(6) Turn arctic heater switch to OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed.
(7) If fault code 000 was displayed on fault code retrieval device (FCRD) or arctic heater indicator illuminates (it does not flash), go to Step 2 of this Fault.
(8) Troubleshoot fault code displayed as indicated. <ul style="list-style-type: none"> (a) Code 001 or 002: Go to Para 2-17.1 Fault 2. (b) Code 010: Go to Para 2-17.1 Fault 2. (c) Code 011: Go to Para 2-17.1 Fault 2. (d) Code 012, 013, 014 or 015: Go to Para 2-17.1 Fault 3. (e) Code 020 or 021: Go to Para 2-17.1 Fault 4. (f) Code 033: Go to Para 2-17.1 Fault 5. (g) Code 037, 042 or 059: Go to Para 2-17.1 Fault 6. (h) Code 043, 047 or 048: Go to Para 2-17.1 Fault 7. (i) Code 050 or 052: Go to Para 2-17.1 Fault 8. (j) Code 051: Go to Para 2-17.1 Fault 9. (k) Code 053, 054, 055 or 056: Go to Para 2-17.1 Fault 10. (l) Code 060, 061, 071 or 072: Go to Para 2-17.1 Fault 11. (m) Code 064 or 065: Go to Para 2-17.1 Fault 12. (n) Code 090, 093, 094 or 097: Go to Para 2-17.1 Fault 13.

FAULT FLASH CODE	
CODE 000	
CODE 090, 093, 094, OR 097	
CODE 050 OR 052	
CODE 010	
CODE 011	
CODE 033	
CODE 001 OR 002	
CODE 043, 047, OR 048	
CODE 064 OR 065	
CODE 060, 061, 071, OR 072	
CODE 012, 013, 014, OR 015	
CODE 037, 042, OR 059	
CODE 020 OR 021	
CODE 053, 054, 055, OR 056	
CODE 051	

8 SECONDS

1. FAULT CHART FOR DIAGNOSTIC OF ARCTIC HEATER TROUBLESHOOTING (MODEL B) (CONT).



WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE


- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- Perform Steps (2) and (3) only if fault code retrieval device (FCRD) is available.

VISUAL INSPECTION

- (1) Ensure vehicle is returned to normal operating condition.
- (2) Install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector.
- (3) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.
- (4) Turn arctic heater ON (TM 9-2320-364-10).
- (5) Observe arctic heater for proper operation.
- (6) Turn arctic heater switch to OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed.
 - (a) If arctic heater operates normally fault has been corrected. Remove fault code retrieval device (FCRD) and install arctic heater cover (TM 9-2320-364-20).
 - (b) If arctic heater does not operate normally, replace arctic heater control unit (Para 18-2.2) and go to Step 3 of this Fault.



1. FAULT CHART FOR DIAGNOSTIC OF ARCTIC HEATER TROUBLESHOOTING (MODEL B) (CONT).



WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (2) and (3) only if fault code retrieval device (FCRD) is available.

VERIFY REPAIR

- (1) Ensure vehicle is returned to normal operating condition.
- (2) If removed, install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector.
- (3) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.
- (4) Turn arctic heater ON (TM 9-2320-364-10).
- (5) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed.
- (6) Observe arctic heater for proper operation.
- (7) Turn arctic heater switch to OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed.
- (8) If installed, remove fault code retrieval device (FCRD).
- (9) Install arctic heater cover (TM 9-2320-364-20).
 - (a) If arctic heater operates normally and arctic heater indicator light is illuminated (Fault code 000 displayed on FCRD), fault has been corrected.
 - (b) If arctic heater indicator light flashes (Fault code other than 000 displayed on FCRD), troubleshoot arctic heater fault code displayed (TM 9-2320-364-20).
 - (c) If arctic heater does not operate normally and arctic heater indicator light is illuminated, notify supervisor.



2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING (CONT).

2. FAULT CODE 001, 002, 010, OR 011: ADVANCED WARNING - OVERVOLTAGE SHUTDOWN, ADVANCED WARNING - UNDERVOLTAGE SHUTDOWN, OVERVOLTAGE SHUTDOWN OR UNDERVOLTAGE SHUTDOWN.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's: Automotive (Item 241, Appendix F)
 STE/ICE-R (optional) (Item 15, Appendix F)
 Multimeter (Item 140, Appendix F)
 Fault Code Retrieval Device (FCRD) (Item 60.1, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)

NOTE

The following steps should only be used if troubleshooting was started at First Chart for Diagnosis of Arctic Heater Troubleshooting procedures (Para 2-17.1 Fault 1) (all conditions) and you were referred here.




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (4) and (5) only if fault code retrieval device (FCRD) is available.

VISUAL INSPECTION
<ol style="list-style-type: none"> (1) Remove cover from arctic heater (TM 9-2320-364-20). (2) Replace arctic heater control unit (Para 18-2.2). (3) Ensure vehicle is returned to normal operating condition. (4) Install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector. (5) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON. (6) Turn arctic heater ON (TM 9-2320-364-10). (7) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown. (8) Observe arctic heater for proper operation. (9) Start engine (TM 9-2320-364-10). (10) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown. (11) Turn arctic heater switch OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed. (12) Turn engine OFF (TM 9-2320-364-10). (13) If installed, remove fault code retrieval device (FCRD). (14) Install cover on arctic heater (TM 9-2320-364-20) <ol style="list-style-type: none"> (a) If arctic heater operates normally and arctic heater indicator light is illuminated (Fault 000 displayed on FCRD), fault has been corrected. (b) If arctic heater indicator light flashed flash code shown (Fault code 001, 002, 010 or 011 displayed on FCRD), notify supervisor. (c) If arctic heater indicator light flashed different flash code (Fault code other than code 001, 002, 010 or 011 displayed on FCRD), troubleshoot arctic heater fault code displayed (TM 9-2320-364-20).



2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING (CONT).

3. FAULT CODE 012, 013, 014 OR 015: OVERHEATING, EXCESSIVE TEMPERATURE AT FLAME SENSOR, POSSIBLE OVERHEATING DETECTED OR TOO MANY OVERHEATS.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's: Automotive (Item 241, Appendix F)
- STE/ICE-R (optional) (Item 15, Appendix F)
- Multimeter (Item 140, Appendix F)
- Fault Code Retrieval Device (FCRD) (Item 60.1, Appendix F)

References


- TM 9-2320-364-10
- TM 9-2320-364-20

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)

NOTE

The following steps should only be used if troubleshooting was started at First Chart For Diagnosis of Arctic Heater Troubleshooting procedure (Para 2-17.1 Fault 1) (all conditions) and you were referred here.




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.


NOTE

Arctic heater temperature sensor resistance is between 650 ohms at -13°F (-25°C) and 1000 ohms at 77°F (25°C).

CONTINUITY TEST	
(1)	Ensure engine coolant temperature is between -13° and 77°F (-25° and 25°C).
(2)	Remove cover from arctic heater
(3)	Disconnect arctic heater unit harness connector from arctic heater control unit (TM 9-2320-364-20).
(4)	Remove three screws and arctic heater control unit (Para 18-2.2).
(5)	Connect positive (+) lead to yellow wire at arctic heater internal harness connector, terminal 14.
(6)	Connect negative (-) lead to yellow wire at arctic heater internal harness connector, terminal (18).
(7)	Is resistance measured across arctic heater temperature sensor between 650 and 1000 ohms, at room temperature?
(a)	If resistance reading is not between 650 and 1000 ohms at room temperature, replace arctic heater temperature sensor (Para 18-2.2).
(b)	If resistance reading is between 650 and 1000 ohms at room temperature, go to Step 2 of this Fault.



3. FAULT CODE 012, 013, 014 OR 015: OVERHEATING, EXCESSIVE TEMPERATURE AT FLAME SENSOR, POSSIBLE OVERHEATING DETECTED OR TOO MANY OVERHEATS (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Arctic heater overhear sensor resistance is between 150K ohms at 13°F (-25°C) and 10K ohms at 77°F (25°C).
- A multimeter must be used when measuring continuity across the overhear sensor. Failure to do so may cause inaccurate readings.

CONTINUITY TEST	
(1)	Ensure arctic heater temperature is between -13° and 77°F (-25° and 25°C).
(2)	Set multimeter to ohms setting.
(3)	Connect multimeter positive (+) lead to blue wire at arctic heater internal harness connector, terminal 11.
(4)	Connect multimeter negative (-) lead to blue wire at arctic heater internal harness connector, terminal 17.
(5)	Is resistance across arctic heater overhear sensor between 10K and 150K ohms at room temperature?
(a)	If resistance reading is not between 10K and 150K ohms at room temperature, replace arctic heater overhear sensor (Para 18-2.2).
(b)	If resistance reading is between 10K and 150K ohms at room temperature, go to Step 2 of this Fault.



3. FAULT CODE 012, 013, 014 OR 015: OVERHEATING, EXCESSIVE TEMPERATURE AT FLAME SENSOR, POSSIBLE OVERHEATING DETECTED OR TOO MANY OVERHEATS (CONT).


KNOWN INFO
Arctic heater coolant level checks OK unit level. Arctic heater coolant hoses and valves check OK unit level. Arctic heater temperature sensor OK. Arctic heater overheat sensor OK.
POSSIBLE PROBLEMS
Arctic heater flame sensor faulty. Arctic heater coolant pump faulty. Arctic heater in lockout mode (fault code 15 active).

3.

WARNING
Read **WARNING** on Page 2-766.17

Is resistance across arctic heater flame sensor between 900 and 1100 ohms, at room temperature?

TEST OPTIONS
Continuity test. STE/ICE-R #91.
REASON FOR QUESTION
If resistance reading is between 900 and 1100 ohms at room temperature, arctic heater coolant pump may be faulty. If not, arctic heater flame sensor is faulty. ←




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.


NOTE

Arctic heater flame sensor resistance is between 900 ohms at 13°F (-25°C) and 1100 ohms at 77°F (25°C).

CONTINUITY TEST	
(1)	Ensure arctic heater temperature is between -13° and 77°F (-25° and 25°C).
(2)	Connect positive (+) lead to gray wire at arctic heater internal harness connector, terminal 15.
(3)	Connect negative (-) lead to gray wire at arctic heater internal harness connector, terminal 16.
(4)	Is resistance across arctic heater flame sensor between 900 and 1100 ohms at room temperature?
(a)	If resistance reading is between 900 and 1100 ohms at room temperature, replace arctic heater coolant pump (Para 18-2.2).
(b)	If resistance reading is not between 900 and 1100 ohms at room temperature, replace arctic heater flame sensor (Para 18-2.2).



3. FAULT CODE 012, 013, 014 OR 015: OVERHEATING, EXCESSIVE TEMPERATURE AT FLAME SENSOR, POSSIBLE OVERHEATING DETECTED OR TOO MANY OVERHEATS (CONT).



WARNING



Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE


- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If arctic heater does not operate, arctic heater may be in lockout mode due to too many overheat occurrences (code 015).
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (3) and (4) only if fault code retrieval device (FCRD) is available.

VISUAL INSPECTION

- (1) If removed, install arctic heater control unit and three screws (Para 18-2.2).
- (2) If removed, connect arctic heater unit harness connector to arctic heater control unit (TM 9-2320-364-20).
- (3) Install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector.
- (4) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.
- (5) Turn arctic heater ON (TM 9-2320-364-10).
- (6) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed.
- (7) Observe arctic heater for proper operation.
- (8) Turn arctic heater switch OFF (TM 9-2320-364-10) or press the D button on the (FCRD), if installed.
 - (a) If arctic heater does not operate and arctic heater indicator light flashed code shown (FCRD is not available). Replace arctic heater control unit (Para 18-2.2) and go to Step 6 of this Fault.
 - (b) If arctic heater does not operate and arctic heater indicator light flashed flash code shown (Fault code 015 displayed on FCRD), go to Step 5 of this Fault.
 - (c) If arctic heater operates, go to Step 6 of this Fault.



3. FAULT CODE 012, 013, 014 OR 015: OVERHEATING, EXCESSIVE TEMPERATURE AT FLAME SENSOR, POSSIBLE OVERHEATING DETECTED OR TOO MANY OVERHEATS (CONT).



WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE


- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If arctic heater does not operate, arctic heater may be in lockout mode due to too many overheating occurrences (code 015).

VISUAL INSPECTION

- (1) Ensure vehicle is returned to normal operating condition.
- (2) Install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector.
- (3) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.
- (4) Clear fault code 015.
- (5) Press the D button on fault code retrieval device (FCRD) twice to turn arctic heater OFF and ON.
- (6) Observe arctic heater for proper operation.
 - (a) If arctic heater does not operate, fault not corrected. Perform Steps (7), (8) and (9) below. Notify supervisor.
 - (b) If arctic heater operates, perform Step (7) below and go to Step 6 of this Fault.
- (7) Press the D button on fault code retrieval device (FCRD) to turn arctic heater OFF.
- (8) Remove fault code retrieval device (FCRD).
- (9) Install cover on arctic heater (TM 9-2320-364-20).



3. FAULT CODE 012, 013, 014 OR 015: OVERHEATING, EXCESSIVE TEMPERATURE AT FLAME SENSOR, POSSIBLE OVERHEATING DETECTED OR TOO MANY OVERHEATS (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (2) and (3) only if fault code retrieval device (FCRD) is available.

VERIFY REPAIR
<ol style="list-style-type: none"> (1) Ensure vehicle is returned to normal operating condition. (2) If removed, install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector. (3) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON. (4) Turn arctic heater ON (TM 9-2320-364-10). (5) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown. (6) Observe arctic heater for proper operation. (7) Turn arctic heater switch to OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed. (8) If installed, remove fault code retrieval device (FCRD). (9) Install arctic heater cover (TM 9-2320-364-20). <ol style="list-style-type: none"> (a) If arctic heater operates normally and arctic heater indicator light is illuminated (Fault code 000 displayed on FCRD), fault has been corrected. (b) If arctic heater indicator light flashed flash code shown (Fault 012, 013, 014 or 015 displayed on FCRD), notify supervisor. (c) If arctic heater indicator light flashed different flash code (Fault code other than 012, 013, 014 or 015 displayed on FCRD), troubleshoot arctic heater fault code displayed (TM 9-2320-364-20).



2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING (CONT).

4. FAULT CODE 020 OR 021: GLOW PIN OPEN CIRCUIT OR GLOW PIN SHORT CIRCUIT.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's: Automotive
 (Item 241, Appendix F)
 STE/ICE-R (optional) (Item 15, Appendix F)
 Multimeter (Item 140, Appendix F)
 Fault Code Retrieval Device (FCRD)
 (Item 60.1, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)

NOTE

The following steps should only be used if troubleshooting was started at First Chart For Diagnosis of Arctic Heater Troubleshooting procedure (Para 2-17.1 Fault 1) (all conditions) and you were referred here.




WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE


Arctic heater glow pin harness white and brown wires are connected with an insulator. Do not separate white and brown wires at glow pin terminal.



**GLOW PIN
HARNESS
WHITE WIRE
TERMINAL**




**ARCTIC
HEATER
CONTROL
UNIT**




**GLOW PIN
HARNESS
BROWN WIRE
TERMINAL**

**ARCTIC
HEATER**




**ARCTIC HEATER
INTERNAL
HARNESS
CONNECTOR**




CONTINUITY TEST

- (1) Remove cover from arctic heater (TM 9-2320-364-20).
- (2) Disconnect arctic heater unit harness connector from arctic heater control unit (TM 9-2320-364-20).
- (3) Remove three screws and arctic heater control unit (Para 18-2.2).
- (4) Remove nut and glow pin harness from arctic heater glow pin terminal (Para 18-2.2).
- (5) Connect positive (+) lead to white wire at arctic heater internal harness connector, terminal 2.
- (6) Connect negative (-) lead to white wire at arctic heater glow pin terminal.
- (7) Is continuity measured across arctic heater glow pin harness white wire?
 - (a) If there is no continuity, replace arctic heater glow pin harness (Para 18-2.2).
 - (b) If there is continuity, go to Step 2 of this Fault.



4. FAULT CODE 020 OR 021: GLOW PIN OPEN CIRCUIT OR GLOW PIN SHORT CIRCUIT (CONT).





WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.


NOTE

Arctic heater glow pin harness white and brown wires are connected with an insulator. Do not separate white and brown wires at glow pin terminal.

CONTINUITY TEST	
(1)	Connect positive (+) lead to brown wire at arctic heater internal harness connector, terminal 7.
(2)	Connect negative (-) lead to brown wire at arctic heater glow pin terminal.
(3)	Is continuity measured across arctic heater glow pin harness brown wire?
(a)	If there is no continuity, replace arctic heater glow pin harness (Para 18-2.2).
(b)	If there is continuity, go to Step 3 of this Fault.



4. FAULT CODE 020 OR 021: GLOW PIN OPEN CIRCUIT OR GLOW PIN SHORT CIRCUIT (CONT).





WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.


NOTE

Arctic heater glow pin harness white and brown wires are connected with an insulator. Do not separate white and brown wires at glow pin terminal.

CONTINUITY TEST	
(1)	Connect positive (+) lead to brown wire at arctic heater internal harness connector, terminal 7.
(2)	Connect negative (-) lead to white wire at arctic heater internal harness connector, terminal 2.
(3)	Are arctic heater glow pin wires free of shorts?
(a)	If there is continuity, replace arctic heater glow pin harness (Para 18-2.2).
(b)	If there is no continuity, go to Step 4 of this Fault.



4. FAULT CODE 020 OR 021: GLOW PIN OPEN CIRCUIT OR GLOW PIN SHORT CIRCUIT (CONT).



WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE


Glow pin should have a nominal 2 ohms resistance.

CONTINUITY TEST

- (1) Connect positive (+) lead to glow pin top terminal.
- (2) Connect negative (-) lead to glow pin bottom terminal.
- (3) Is continuity measured across glow pin?
 - (a) If there is no continuity, replace arctic heater glow pin (Para 18-2.2).
 - (b) If there is continuity, replace arctic heater control unit (Para 18-2.2).



4. FAULT CODE 020 OR 021: GLOW PIN OPEN CIRCUIT OR GLOW PIN SHORT CIRCUIT (CONT).



WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (5) and (6) only if fault code retrieval device (FCRD) is available.

VERIFY REPAIR

- (1) If removed, install arctic heater glow pin harness and nut on arctic heater glow pin terminal (Para 18-2.2).
- (2) If removed, install arctic heater control unit (Para 18-2.2).
- (3) Connect arctic heater unit harness connector to arctic heater control unit (TM 9-2320-364-20).
- (4) Ensure vehicle is returned to normal operating condition.
- (5) Install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector.
- (6) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.
- (7) Turn arctic heater ON (TM 9-2320-364-10).
- (8) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown.
- (9) Observe arctic heater for proper operation.
- (10) Turn arctic heater switch to OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed.
- (11) If installed, remove fault code retrieval device (FCRD).
- (12) Install cover on arctic heater (TM 9-2320-364-20).
 - (a) If arctic heater operates normally and arctic heater indicator light is illuminated (Fault code 000 displayed on FCRD). Fault has been corrected.
 - (b) If arctic heater indicator light flashed flash code shown (Fault 020 or 021 displayed on FCRD), notify supervisor.
 - (c) If arctic heater indicator light flashed different flash code (Fault code other than 020 or 021 displayed on FCRD), troubleshoot arctic heater fault code displayed (TM 9-2320-364-20).



2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING (CONT).

5. FAULT CODE 033: BLOWER MOTOR SPEED FAULT.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's: Automotive
 (Item 241, Appendix F)
 STE/ICE-R (optional) (Item 15, Appendix F)
 Multimeter (Item 140, Appendix F)
 Fault Code Retrieval Device (FCRD)
 (Item 60.1, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)

NOTE

The following steps should only be used if troubleshooting was started at First Chart For Diagnosis of Arctic Heater Troubleshooting procedure (Para 2-17.1 Fault 1) (all conditions) and you were referred here.



WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE


An audible whine should be heard when power is applied, indicating the arctic heater blower motor is operating.

VISUAL INSPECTION

- (1) Remove cover from arctic heater (TM 9-2320-364-20).
- (2) Disconnect arctic heater unit harness connector from arctic heater control unit (TM 9-2320-364-20).
- (3) Remove three screws and arctic heater control unit (Para 18-2.2).
- (4) Connect 24 vdc power supply positive (+) lead to orange wire at arctic heater internal harness connector, terminal 1.
- (5) Connect 24 vdc power supply negative (-) lead to black wire at arctic heater internal harness connector, terminal 4.
- (6) Turn 24 vdc power supply ON and apply power to circuit.
- (7) Observe operation of blower motor.
- (8) Turn 24 vdc power supply OFF.
 - (a) If arctic heater blower motor does not operate, replace arctic heater blower (Para 18-2.2).
 - (b) If arctic heater blower motor operates, go to Step 2 of this Fault.



5. FAULT CODE 033: BLOWER MOTOR SPEED FAULT (CONT).






WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

VOLTAGE TEST

- (1) Remove 24 vdc power supply.
- (2) Connect arctic heater unit harness connector to arctic heater control unit (TM 9-2320-364-10).
- (3) Connect positive (+) lead to arctic heater control unit internal connector, terminal 10.
- (4) Connect negative (-) lead to arctic heater control unit internal connector, terminal 5.
- (6) Turn arctic heater switch ON (TM 9-2320-364-10).
 - (a) If 5 vdc is not present, replace arctic heater control unit (Para 18-2.2).
 - (b) If 5 vdc is present, go to Step 3 of this Fault.




5. FAULT CODE 033: BLOWER MOTOR SPEED FAULT (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

VOLTAGE TEST	
(1)	Turn arctic heater switch OFF (TM 9-2320-364-10).
(2)	Remove cable tie from arctic heater internal harness.
(3)	Connect arctic heater internal harness connector to arctic heater control unit internal connector (Para 18-2.2).
(4)	Connect (back probe) positive (+) lead to violet wire at arctic heater internal harness connector, terminal 13.
(5)	Connect (back probe) negative (-) lead to green wire at arctic heater internal harness connector, terminal 5.
(6)	Turn arctic heater switch ON. <ul style="list-style-type: none"> (a) If 2.2 to 2.8 vdc are not present, replace arctic heater blower (Para 18-2.2). (b) If 2.2 to 2.8 vdc are present, replace arctic heater control unit (Para 18-2.2).



5. FAULT CODE 033: BLOWER MOTOR SPEED FAULT (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (5) and (6) only if fault code retrieval device (FCRD) is available.

VERIFY REPAIR
<p>(1) If removed, install cable ties on arctic heater internal harness (Para 18-2.2).</p> <p>(2) Install arctic heater control unit and three screws (Para 18-2.2).</p> <p>(3) Connect arctic heater unit harness connector to arctic heater control unit (TM 9-2320-364-20).</p> <p>(4) Ensure vehicle is returned to normal operating condition.</p> <p>(5) Install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector.</p> <p>(6) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.</p> <p>(7) Turn arctic heater ON (TM 9-2320-364-10).</p> <p>(8) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown.</p> <p>(9) Observe arctic heater for proper operation.</p> <p>(7) Turn arctic heater switch to OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed.</p> <p>(8) If installed, remove fault code retrieval device (FCRD).</p> <p>(9) Install arctic heater cover (TM 9-2320-364-20).</p> <p>(a) If arctic heater operates normally and arctic heater indicator light is illuminated (Fault code 000 displayed on FCRD), fault has been corrected.</p> <p>(b) If arctic heater indicator light flashed flash code shown (Fault code 033 displayed on FCRD), notify supervisor.</p> <p>(c) If arctic heater indicator light flashed different flash code (Fault code other than 033 displayed on FCRD), troubleshoot arctic heater fault code displayed (TM 9-2320-364-20).</p>



2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING (CONT).

6. FAULT CODE 037, 042 OR 059: WATER PUMP IS NOT WORKING WATER PUMP SHORT CIRCUIT OR WATER TEMPERATURE RISES TOO QUICKLY.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's: Automotive (Item 241, Appendix F)
 STE/ICE-R (optional) (Item 15, Appendix F)
 Multimeter (Item 140, Appendix F)
 Fault Code Retrieval Device (FCRD) (Item 60.1, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)

NOTE

The following steps should only be used if troubleshooting was started at First Chart for Diagnosis of Arctic Heater Troubleshooting procedures (Para 2-17.1 Fault 1) (all conditions) and you were referred here.




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.


NOTE

Arctic heater temperature sensor resistance is between 650 ohms at -13°F (-25°C) and 1000 ohms at 77°F (25°C).

CONTINUITY TEST	
(1)	Ensure engine coolant temperature is between -13° and 77°F (-25° and 25°C).
(2)	Remove cover from arctic heater (TM 9-2320-364-20).
(3)	Disconnect arctic heater unit harness connector from arctic heater control unit (TM 9-2320-364-20).
(4)	Remove three screws and arctic heater control unit (Para 18-2.2).
(5)	Connect positive (+) lead to yellow wire at arctic heater internal harness connector, terminal 14.
(6)	Connect negative (-) lead to yellow wire at arctic heater internal harness connector, terminal 18.
(7)	Is resistance measured across arctic heater temperature sensor between 650 and 1000 ohms at room temperature?
(a)	If resistance reading is between 650 and 1000 ohms at room temperature, replace arctic heater coolant pump (Para 18-2.2).
(b)	If resistance reading is not between 650 and 1000 ohms at room temperature, replace arctic heater temperature sensor (Para 18-2.2).



6. FAULT CODE 037, 042 OR 059: WATER PUMP IS NOT WORKING WATER PUMP SHORT CIRCUIT OR WATER TEMPERATURE RISES TOO QUICKLY (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (4) and (5) only if fault code retrieval device (FCRD) is available.

VERIFY REPAIR
<ol style="list-style-type: none"> (1) If removed, install arctic heater control unit and three screws (Para 18-2.2). (2) Connect arctic heater unit harness connector to arctic heater control unit (TM 9-2320-364-20). (3) Ensure vehicle is returned to normal operating condition. (4) Install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector. (5) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON. (6) Turn arctic heater ON (TM 9-2320-364-10). (7) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown. (8) Observe arctic heater for proper operation. (9) Turn arctic heater switch to OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed. (10) If installed, remove fault code retrieval device (FCRD). (11) Install arctic heater cover (TM 9-2320-364-20). <ol style="list-style-type: none"> (a) If arctic heater operates normally and arctic heater indicator light is illuminated (Fault code 000 displayed on FCRD), fault has been corrected. (b) If arctic heater indicator light flashed flash code shown (Fault code 037, 042 or 059 displayed on FCRD), notify supervisor. (c) If arctic heater indicator light flashed different flash code (Fault code other than 037, 042 or 059 displayed on FCRD), troubleshoot arctic heater fault code displayed (TM 9-2320-364-20).



2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING (CONT).

7. FAULT CODE 043, 047 OR 048: SHORT CIRCUIT AT EXTERNAL COMPONENT, FUEL METERING PUMP SHORT CIRCUIT OR FUEL METERING PUMP OPEN CIRCUIT.

INITIAL SETUP

Tools and Special Tools

- Tool Kit, General Mechanic's: Automotive (Item 241, Appendix F)
- STE/ICE-R (optional) (Item 15, Appendix F)
- Multimeter (Item 140, Appendix F)
- Fault Code Retrieval Device (FCRD) (Item 60.1, Appendix F)

References


- TM 9-2320-364-10
- TM 9-2320-364-20

Equipment Condition

- Engine OFF, (TM 9-2320-364-10)
- Parking brake applied, (TM 9-2320-364-10)
- Wheels chocked, (TM 9-2320-364-10)

NOTE

The following steps should only be used if troubleshooting was started at First Chart for Diagnosis of Arctic Heater Troubleshooting procedures (Para 2-17.1 Fault 1) (all conditions) and you were referred here.



WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (4) and (5) only if fault code retrieval device (FCRD) is available.

VISUAL INSPECTION


- (1) Remove cover from arctic heater (TM 9-2320-364-20).
- (2) Replace arctic heater control unit (Para 18-2.2).
- (3) Ensure vehicle is returned to normal operating condition.
- (4) Install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector.
- (5) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.
- (6) Turn arctic heater ON (TM 9-2320-364-10).
- (7) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown.
- (8) Observe arctic heater for proper operation.
- (9) Turn arctic heater switch OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed.
- (10) If installed, remove fault code retrieval device (FCRD).
- (11) Install cover on arctic heater (TM 9-2320-364-20).
 - (a) If arctic heater operates normally and arctic heater indicator light is illuminated (Fault 000 displayed on FCRD), fault has been corrected.
 - (b) If arctic heater indicator light flashed flash code shown (Fault code 043, 047 or 048 displayed on FCRD), notify supervisor.
 - (c) If arctic heater indicator light flashed different flash code (Fault code other than code 043, 047 or 048 displayed on FCRD), troubleshoot arctic heater fault code displayed (TM 9-2320-364-20).

FAULT FLASH CODE

CODE 043, 047, OR 048



8 SECONDS



2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING (CONT).

8. FAULT CODE 050 OR 052: TOO MANY NO START ATTEMPTS OR NO START SAFETY TIME EXCEEDED.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's: Automotive
 (Item 241, Appendix F)
 STE/ICE-R (optional) (Item 15, Appendix F)
 Multimeter (Item 140, Appendix F)
 Fault Code Retrieval Device (FCRD)
 (Item 60.1, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)

NOTE

The following steps should only be used if troubleshooting was started at First Chart for Diagnosis of Arctic Heater Troubleshooting procedures (Para 2-17.1 Fault 1) (all conditions) and you were referred here.





WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.


NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If arctic heater does not operate, arctic heater may be in lockout mode due to too many start attempts (code 050). Arctic heater lockout mode (code 050) is activated if arctic heater fails to start after 20 successive start attempts (10 successive start cycles).
- An audible whine will be heard after the system check is completed, indicating the blower motor has switched on and the system is operating. Audible clicking may also be heard from the fuel metering pump if the arctic heater fuel system isn't primed.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (2) and (3) only if fault code retrieval device (FCRD) is available.

VISUAL INSPECTION	
(1)	Remove cover from arctic heater (TM 9-2320-364-20).
(2)	Install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector.
(3)	Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.
(4)	Turn arctic heater ON (TM 9-2320-364-10).
(5)	Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown.
(6)	Observe arctic heater for proper operation.
(7)	Turn arctic heater switch OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed.
(a)	If arctic heater does not operate and arctic heater indicator flashed code shown (Fault code 050 displayed on FCRD), go to Step 2 of this Fault.
(b)	If arctic heater attempts to start, go to Step 6 of this Fault.



8. FAULT CODE 050 OR 052: TOO MANY NO START ATTEMPTS OR NO START SAFETY TIME EXCEEDED (CONT).



WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE


- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If arctic heater does not operate, arctic heater may be in lockout mode due to too many start attempts (code 050). Arctic heater lockout mode (code 050) is activated if arctic heater fails to start after 20 successive start attempts (10 successive start cycles).
- An audible whine will be heard after the system check is completed, indicating the blower motor has switched on and the system is operating. Audible clicking may also be heard from the fuel metering pump if the arctic heater fuel system isn't primed.
- Perform Steps (2) through (5) only if fault code retrieval device (FCRD) is available.
- Perform Steps (6) and (7) only if fault code retrieval device (FCRD) is not available.

VISUAL INSPECTION

- (1) Ensure vehicle is returned to normal operating condition.
- (2) Install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector.
- (3) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.
- (4) Clear fault code 050.
- (5) Press the D button on fault code retrieval device (FCRD) twice to turn arctic heater OFF and ON.
- (6) Replace arctic heater control unit (Para 18-2.2) if fault code retrieval device is not available.
- (7) Turn arctic heater ON (TM 9-2320-364-10).
- (8) Observe arctic heater for proper operation.
 - (a) If arctic heater operates, perform Step (9) below and go to Step 3 of this Fault.
 - (b) If arctic heater does not operate, fault not corrected, perform Steps (9), (10) and (11) below and notify supervisor.
- (9) Turn arctic heater switch OFF (TM 9-2320-364-10) or press the D button on the (FCRD), if installed.
- (10) If installed, remove fault code retrieval device (FCRD).
- (11) Install cover on arctic heater (TM 9-2320-364-20).



8. FAULT CODE 050 OR 052: TOO MANY NO START ATTEMPTS OR NO START SAFETY TIME EXCEEDED (CONT).



WARNING


- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.
- Fuel is very flammable and can explode easily. To avoid serious injury or death, keep fuel away from open fire and keep fire extinguisher within easy reach when working with fuel. Do not work on fuel system when engine is hot. Fuel can be ignited by hot engine.

NOTE


- If arctic heater does not operate, arctic heater may be in lockout mode due to too many start attempts (code 050). Arctic heater lockout mode (code 050) is activated if arctic heater fails to start after 20 successive start attempts (10 successive start cycles).
- Audible clicking and low fuel flow from the fuel metering pump may indicate that the arctic heater fuel system isn't primed.
- Fuel should flow from fuel line into container 63 seconds after arctic heater starts. Fuel will shut off automatically after 105 seconds. Fuel will begin flow again after 50 to 60 second preheat, and will turn off after 75 seconds (This indicates two start attempts). The arctic heater will shut down after the second start attempt (one start cycle).
- Total fuel quantity should be between 0.62 to 0.65 ounces (18.64 and 19.36 ml) in Steps (5) and (6).

VISUAL INSPECTION

- (1) If installed, remove fault code retrieval device (FCRD).
- (2) Loosen clamp screw and disconnect arctic heater fuel line from arctic heater (TM 9-2320-364-20).
- (3) Place arctic heater fuel line into graduated 1 quart (950 ml) measuring container.
- (4) Turn arctic heater switch ON (TM 9-2320-364-20).
- (5) Observe fuel flowing into measuring container.
- (6) Turn arctic heater switch OFF when fuel stops flowing after second start attempt.
- (7) Inspect measuring container for 0.62 to 0.65 ounces (18.64 to 19.36 ml).
 - (a) If arctic heater does not operate, (lockout mode activated), perform Step (8) below and go to Step 2 of this Fault.
 - (b) If no or low fuel delivery and audible clicking is heard from fuel metering pump, go to Step 4 of this Fault.
 - (c) If fuel metering pump delivers less than 0.62 ounces (18.64 ml) of fuel, perform Step (8) below and replace arctic heater fuel metering pump (TM 9-2320-364-20).
 - (d) If fuel metering pump delivers between 0.62 and 0.65 ounces (18.64 and 19.36 ml) of fuel, perform Step (8) below and go to Step 6 of this Fault.
- (8) Connect arctic heater fuel line to arctic heater and tighten clamp screw.



8. FAULT CODE 050 OR 052: TOO MANY NO START ATTEMPTS OR NO START SAFETY TIME EXCEEDED (CONT).



WARNING


- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.
- Fuel is very flammable and can explode easily. To avoid serious injury or death, keep fuel away from open fire and keep fire extinguisher within easy reach when working with fuel. Do not work on fuel system when engine is hot. Fuel can be ignited by hot engine.

NOTE


- Audible clicking and low fuel flow from the fuel metering pump may indicate that the arctic heater fuel system isn't primed. The arctic heater should self-prime itself within ten start attempts (five start cycles).
- If arctic heater does not operate, arctic heater may be in lockout mode due to too many start attempts (code 050). Arctic heater lockout mode (code 050) is activated if arctic heater fails to start after 20 successive start attempts (10 successive start cycles).

VISUAL INSPECTION

- (1) Connect fuel line on arctic heater and tighten screw (TM 9-2320-364-20).
- (2) Check fuel in fuel tank. Add fuel if required to ensure fuel is supplied to arctic heater.
- (3) Turn arctic heater switch ON (TM 9-2320-364-10).
- (4) Observe arctic heater for proper operation. Note if audible clicking is heard from arctic heater fuel metering pump.
- (5) When arctic heater shuts down after two start attempts, turn arctic heater switch OFF.
- (6) Repeat Steps (3) through (5) four times or until arctic heater operates normally.
 - (a) If arctic heater does not operate, when arctic heater switch is turned ON (lockout mode activated), go to Step 5 of this Fault.
 - (b) If arctic heater fuel metering pump fails to prime itself within ten start attempts (five start cycles), replace arctic heater fuel metering pump (TM 9-2320-364-20).
 - (c) If arctic heater fuel metering pump primes itself within ten start attempts (five start cycles), fault has been corrected.



8. FAULT CODE 050 OR 052: TOO MANY NO START ATTEMPTS OR NO START SAFETY TIME EXCEEDED (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.


NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If arctic heater does not operate, arctic heater may be in lockout mode due to too many start attempts (code 050). Arctic heater lockout mode (code 050) is activated if arctic heater fails to start after 20 successive start attempts (10 successive start cycles).
- An audible whine will be heard after the system check is completed, indicating the blower motor has switched on and the system is operating. Audible clicking may also be heard from the fuel metering pump if the arctic heater fuel system isn't primed.
- Perform Steps (2) through (4) only if fault code retrieval device (FCRD) is available.
- Perform Steps (5) and (6) only if fault code retrieval device (FCRD) is not available.

VISUAL INSPECTION
<ol style="list-style-type: none"> (1) Ensure vehicle is returned to normal operating condition. (2) Install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector. (3) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON. (4) Clear fault code 050. (5) Press the D button on fault code retrieval device (FCRD) twice to turn arctic heater OFF and ON. (6) Replace arctic heater control unit (Para 18-2.2) if fault code retrieval device is not available. (7) Turn arctic heater ON (TM 9-2320-364-10). (8) Observe arctic heater for proper operation. <ol style="list-style-type: none"> (a) If arctic heater operates, perform Steps (9) and (10) below and go to Step 4 of this Fault. (b) If arctic heater does not operate, fault not corrected. Perform Steps (9), (10) and (11) below and notify supervisor. (9) Turn arctic heater switch OFF (TM 9-2320-364-10) or press the D button on fault code retrieval device (FCRD), if installed. (10) If installed, remove fault code retrieval device (FCRD). (11) Install cover on arctic heater (TM 9-2320-364-20).



8. FAULT CODE 050 OR 052: TOO MANY NO START ATTEMPTS OR NO START SAFETY TIME EXCEEDED (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.


NOTE

Arctic heater flame sensor resistance is between 900 ohms at 13°F (-25°C) and 1100 ohms at 77°F (25°C).

- | CONTINUITY TEST | |
|-----------------|---|
| (1) | Ensure arctic heater temperature is between -13° and 77°F (-25° and 25°C). |
| (2) | Disconnect arctic heater unit harness connector from arctic heater control unit (TM 9-2320-364-20). |
| (3) | Remove three screws and arctic heater control unit (Para 18-2.2). |
| (4) | Connect positive (+) lead to gray wire at arctic heater internal harness connector, terminal 15. |
| (5) | Connect negative (-) lead to gray wire at arctic heater internal harness connector, terminal 16. |
| (6) | Is resistance across arctic heater flame sensor between 900 and 1100 ohms at room temperature? |
| (a) | If resistance reading is not between 900 and 1100 ohms at room temperature, replace arctic heater flame sensor (Para 18-2.2). |
| (b) | If resistance reading is between 900 and 1100 ohms at room temperature, replace arctic heater glow pin (Para 18-2.2). |



8. FAULT CODE 050 OR 052: TOO MANY NO START ATTEMPTS OR NO START SAFETY TIME EXCEEDED (CONT).



WARNING


- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.
- Fuel is very flammable and can explode easily. To avoid serious injury or death, keep fuel away from open fire and keep fire extinguisher within easy reach when working with fuel. Do not work on fuel system when engine is hot. Fuel can be ignited by hot engine.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- If arctic heater does not operate, arctic heater may be in lockout mode due to too many start attempts (code 050). Arctic heater lockout mode (code 050) is activated if arctic heater fails to start after 20 successive start attempts (10 successive start cycles).
- Perform Steps (5) and (6) only if fault code retrieval device (FCRD) is available.

VERIFY REPAIR

- (1) If disconnected, connect fuel line on arctic heater and tighten screw (TM 9-2320-364-20).
- (2) If removed, install arctic heater control unit and three screws (Para 18-2.2).
- (3) If disconnected, connect arctic heater unit harness connector to arctic heater control unit (TM 9-2320-364-20).
- (4) Ensure vehicle is returned to normal operating condition.
- (5) Install fault code retrieval device (FCRD) (TM 9-2320-364-20) on arctic heater unit harness diagnostic connector.
- (6) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.
- (7) Turn arctic heater ON (TM 9-2320-364-10).
- (8) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown.
- (9) Observe arctic heater for proper operation.
- (10) Turn arctic heater switch to OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed.
- (11) If installed, remove fault code retrieval device (FCRD).
- (12) Install arctic heater cover (TM 9-2320-364-20).
 - (a) If arctic heater operates normally and arctic heater indicator light is illuminated (Fault code 000 displayed on FCRD), fault has been corrected.
 - (b) If arctic heater does not operate and arctic heater indicator light flashed flash code shown (Fault 050 displayed on FCRD), go to Step 8 of this Fault.
 - (c) If arctic heater tries to start and arctic heater indicator light flashed flash code shown (Fault code 052 displayed on FCRD), notify supervisor.
 - (d) If arctic heater indicator light flashed flash code (Fault code other than 052 or 052 displayed on FCRD), troubleshoot arctic heater fault code displayed (TM 9-2320-364-20).



8. FAULT CODE 050 OR 052: TOO MANY NO START ATTEMPTS OR NO START SAFETY TIME EXCEEDED (CONT).


KNOWN INFO
Fuel level OK (checked at operational level). Arctic heater intake port checks OK at unit level. Arctic heater exhaust port and exhaust tube checks OK at unit level. Arctic heater fuel lines check OK at unit level. Arctic heater fuel metering pump OK. Arctic heater fuel system primed. Arctic heater flame sensor OK. Arctic heater glow pin OK.
POSSIBLE PROBLEMS
Arctic heater in lockout mode (fault code 050 active).

8.

WARNING

Read **WARNING** on Page 2-766.63

Does arctic heater operate after fault code 050 is cleared or arctic heater control unit is replaced?



TEST OPTIONS
Visual inspection.
REASON FOR QUESTION
Fault code 050 must be cleared to clear lockout mode before testing can continue. ←

WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If arctic heater does not operate, arctic heater may be in lockout mode due to too many start attempts (code 050). Arctic heater lockout mode (code 050) is activated if arctic heater fails to start after 20 successive start attempts (10 successive start cycles).
- An audible whine will be heard after the system check is completed, indicating the blower motor has switched on and the system is operating. Audible clicking may also be heard from the fuel metering pump if the arctic heater fuel system isn't primed.
- Perform Steps (2) through (5) only if fault code retrieval device (FCRD) is available.
- Perform Steps (6) and (7) only if fault code retrieval device (FCRD) is not available.

VISUAL INSPECTION

- (1) Ensure vehicle is returned to normal operating condition.
- (2) If removed, install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector.
- (3) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.
- (4) Clear fault code 050.
- (5) Press the D button on fault code retrieval device (FCRD) twice to turn arctic heater OFF and ON.
- (6) Replace arctic heater control unit (Para 18-2.2) if fault code retrieval device is not available.
- (7) Turn arctic heater ON (TM 9-2320-364-10).
- (8) Observe arctic heater for proper operation.
 - (a) If arctic heater operates, perform Step (9) below and go to Step 7 of this Fault.
 - (b) If arctic heater does not operate, fault not corrected. Perform Steps (9), (10) and (11) below and notify supervisor.
- (9) Turn arctic heater switch OFF (TM 9-2320-364-10) or press the D button on fault code retrieval device (FCRD), if installed.
- (10) If installed, remove fault code retrieval device (FCRD).
- (11) Install cover on arctic heater (TM 9-2320-364-20).



2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING (CONT).

9. FAULT CODE 051: FAULTY FLAME RECOGNITION.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's: Automotive
 (Item 241, Appendix F)
 STE/ICE-R (optional) (Item 15, Appendix F)
 Multimeter (Item 140, Appendix F)
 Fault Code Retrieval Device (FCRD)
 (Item 60.1, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)

NOTE

The following steps should only be used if troubleshooting was started at First Chart For Diagnosis of Arctic Heater Troubleshooting procedure (Para 2-17.1 Fault 1) (all conditions) and you were referred here.




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.


NOTE

Arctic heater flame sensor resistance is between 900 ohms at -13°F (-25°C) and 1100 ohms at 77°F (25°C).

CONTINUITY TEST
(1) Ensure arctic heater temperature is between -13° and 77°F (-25° and 25°C).
(2) Remove cover from arctic heater (TM 9-2320-364-20).
(3) Disconnect arctic heater unit harness connector from arctic heater control unit (TM 9-2320-364-20).
(4) Remove three screws and arctic heater control unit (Para 18-2.2).
(5) Connect positive (+) lead to gray wire at arctic heater internal harness connector, terminal 15.
(6) Connect negative (-) lead to gray wire at arctic heater internal harness connector, terminal 16.
(7) Is resistance across arctic flame sensor between 900 and 1100 ohms at room temperature?
(a) If resistance reading is not between 900 and 1100 ohms at room temperature, replace flame sensor (Para 18-2.2).
(b) If resistance reading is between 900 and 1100 ohms at room temperature, replace arctic heater control unit (Para 18-2.2).



9. FAULT CODE 051: FAULTY FLAME RECOGNITION (CONT).



WARNING



Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (4) and (5) only if fault code retrieval device (FCRD) is available.

VERIFY REPAIR

- (1) If removed, install arctic heater control unit and three screws (Para 18-2.2).
- (2) Connect arctic heater unit harness connector to arctic heater control unit (TM 9-2320-364-20).
- (3) Ensure vehicle is returned to normal operating condition.
- (4) Install fault code retrieval device (FCRD) on arctic heater harness diagnostic connector.
- (5) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.
- (6) Turn arctic heater ON (TM 9-2320-364-10).
- (7) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown.
- (8) Observe arctic heater for proper operation.
- (9) Turn arctic heater switch OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed.
- (10) If installed, remove fault code retrieval device (FCRD).
- (11) Install cover on arctic heater (TM 9-2320-364-20).
 - (a) If arctic heater operates normally and arctic heater indicator light is illuminated (Fault code 000 displayed on FCRD), fault has been corrected.
 - (b) If arctic heater indicator light flashed flash code shown (Fault code 051 displayed on FCRD), notify supervisor.
 - (c) If arctic heater indicator light flashed different flash code (Fault code other than 051 displayed on FCRD), troubleshoot arctic heater fault code displayed (TM 9-2320-364-20).



2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING (CONT).

10. FAULT CODE 053, 054, 055 OR 056: FLAME CUTOUT IN BOOST MODE, FLAME CUTOUT IN HIGH MODE, FLAME CUTOUT IN MEDIUM MODE OR FLAME CUTOUT IN LOW MODE.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's: Automotive (Item 241, Appendix F)
 STE/ICE-R (optional) (Item 15, Appendix F)
 Multimeter (Item 140, Appendix F)
 Fault Code Retrieval Device (FCRD) (Item 60.1, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)

NOTE

The following steps should only be used if troubleshooting was started at First Chart For Diagnosis of Arctic Heater Troubleshooting procedure (Para 2-17.1 Fault 1) (all conditions) and you were referred here.




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.


NOTE

Arctic heater flame sensor resistance is between 900 ohms at -13°F (-25°C) and 1100 ohms at 77°F (25°C).

CONTINUITY TEST
(1) Ensure arctic heater temperature is between -13° and 77°F (-25° and 25°C) .
(2) Remove cover from arctic heater (TM 9-2320-364-20).
(3) Disconnect arctic heater unit harness connector from arctic heater control unit (TM 9-2320-364-20).
(4) Remove three screws and arctic heater control unit (Para 18-2.2).
(5) Connect positive (+) lead to gray wire at arctic heater internal harness connector, terminal 15.
(6) Connect negative (-) lead to gray wire at arctic heater internal harness connector, terminal 16.
(7) Is resistance across arctic heater flame sensor between 900 and 1100 ohms at room temperature?
(a) If resistance reading is not between 900 and 1100 ohms at room temperature, replace arctic heater flame sensor (Para 18-2.2).
(b) If resistance reading is between 900 and 1100 ohms at room temperature, replace arctic heater blower (Para 18-2.2).



10. FAULT CODE 053, 054, 055 OR 056: FLAME CUTOUT IN BOOST MODE, FLAME CUTOUT IN HIGH MODE, FLAME CUTOUT IN MEDIUM MODE OR FLAME CUTOUT IN LOW MODE (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (4) and (5) only if fault code retrieval device (FCRD) is available.

VERIFY REPAIR
<ol style="list-style-type: none"> (1) If removed, install arctic heater control unit and three screws (Para 18-2.2). (2) Connect arctic heater unit harness connector to arctic heater control unit (TM 9-2320-364-20). (3) Ensure vehicle is returned to normal operating condition. (4) Install fault code retrieval device (FCRD) on arctic heater harness diagnostic connector. (5) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON. (6) Turn arctic heater ON (TM 9-2320-364-10). (7) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown. (8) Observe arctic heater for proper operation. (9) Turn arctic heater switch OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed. (10) If installed, remove fault code retrieval device (FCRD). (11) Install cover on arctic heater (TM 9-2320-364-20). <ol style="list-style-type: none"> (a) If arctic heater operates normally and arctic heater indicator light is illuminated (Fault code 000 displayed on FCRD), fault has been corrected. (b) If arctic heater tries to operate and arctic heater indicator light flashed flash code shown (Fault 053, 054, 055 or 056 displayed on FCRD), notify supervisor. (c) If arctic heater indicator light flashed different flash code (Fault code other than 051 displayed on FCRD), troubleshoot arctic heater fault code displayed (TM 9-2320-364-20).



2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING (CONT).

11. FAULT CODE 060, 061, 071 OR 072: TEMPERATURE SENSOR OPEN CIRCUIT, TEMPERATURE SENSOR SHORT CIRCUIT, OVERHEAT SENSOR OPEN CIRCUIT OR OVERHEAT SENSOR SHORT CIRCUIT.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's: Automotive (Item 241, Appendix F)
 STE/ICE-R (optional) (Item 15, Appendix F)
 Multimeter (Item 140, Appendix F)
 Fault Code Retrieval Device (FCRD) (Item 60.1, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)

NOTE

The following steps should only be used if troubleshooting was started at First Chart For Diagnosis of Arctic Heater Troubleshooting procedure (Para 2-17.1 Fault 1) (all conditions) and you were referred here.



WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE


Arctic heater temperature sensor resistance is between 650 ohms at -13°F (-25°C) and 1000 ohms at 77°F (25°C).

CONTINUITY TEST

- (1) Ensure engine coolant temperature is between -13° and 77°F (-25° and 25°C).
- (2) Remove cover from arctic heater (TM 9-2320-364-20).
- (3) Disconnect arctic heater unit harness connector from arctic heater control unit (TM 9-2320-364-20).
- (4) Remove three screws and arctic heater control unit (Para 18-2.2).
- (5) Connect positive (+) lead to yellow wire at arctic heater internal harness connector, terminal 14.
- (6) Connect negative (-) lead to yellow wire at arctic heater internal terminal 18.
- (7) Is resistance measured across arctic heater temperature sensor between 650 and 1000 ohms at room temperature?
 - (a) If resistance reading is not between 650 and 1000 ohms at room temperature, replace arctic heater temperature sensor (Para 18-2.2).
 - (b) If resistance reading is between 650 and 1000 ohms at room temperature, go to Step 2 of this Fault.



11. FAULT CODE 060, 061, 071 OR 072: TEMPERATURE SENSOR OPEN CIRCUIT, TEMPERATURE SENSOR SHORT CIRCUIT, OVERHEAT SENSOR OPEN CIRCUIT OR OVERHEAT SENSOR SHORT CIRCUIT (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.


NOTE

- Arctic heater flame sensor resistance is between 150K ohms at -13°F (-25°C) and 10K ohms at 77°F (25°C).
- A multimeter must be used when measuring continuity across overheat sensor. Failure to do so may cause inaccurate readings.

VOLTAGE TEST	
(1)	Ensure arctic heater temperature is between -13° and 77°F (-25° and 25°C).
(2)	Set multimeter to ohms setting.
(3)	Connect multimeter positive (+) lead to blue wire at arctic heater internal harness connector, terminal 11.
(4)	Connect multimeter negative (-) lead to blue wire at arctic heater internal harness connector, terminal 17.
(5)	Is resistance across arctic heater overheat sensor between 10K and 150K ohms at room temperature?
(a)	If resistance reading is not between 10K and 150K ohms, replace arctic heater overheat sensor (Para 18-2.2).
(b)	If resistance reading is between 10K and 150K ohms, replace arctic heater control unit (Para 18-2.2).



11. FAULT CODE 060, 061, 071 OR 072: TEMPERATURE SENSOR OPEN CIRCUIT, TEMPERATURE SENSOR SHORT CIRCUIT, OVERHEAT SENSOR OPEN CIRCUIT OR OVERHEAT SENSOR SHORT CIRCUIT (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (4) and (5) only if fault code retrieval device (FCRD) is available.

VERIFY REPAIR
<ol style="list-style-type: none"> (1) If removed, install arctic heater control unit (Para 18-2.2). (2) Connect arctic heater unit harness connector to arctic heater control unit (TM 9-2320-364-20). (3) Ensure vehicle is returned to normal operating condition. (4) Install fault code retrieval device (FCRD) on arctic heater harness diagnostic connector. (5) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON. (6) Turn arctic heater ON (TM 9-2320-364-10). (7) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown. (8) Observe arctic heater for proper operation. (9) Turn arctic heater switch OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed. (10) If installed, remove fault code retrieval device (FCRD). (11) Install cover on arctic heater (TM 9-2320-364-20). <ol style="list-style-type: none"> (a) If arctic heater operates normally and arctic heater indicator light is illuminated (Fault code 000 displayed on FCRD), fault has been corrected. (b) If arctic heater indicator light flashed flash code shown (Fault 060, 061, 071 or 072 displayed on FCRD), notify supervisor. (c) If arctic heater indicator light flashed different flash code (Fault code other than 060, 061, 071 or 072 displayed on FCRD), troubleshoot arctic heater fault code displayed (TM 9-2320-364-20).



2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING (CONT).

12. FAULT CODE 064 OR 065: FLAME SENSOR OPEN CIRCUIT OR FLAME SENSOR SHORT CIRCUIT.

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's: Automotive
 (Item 241, Appendix F)
 STE/ICE-R (optional) (Item 15, Appendix F)
 Multimeter (Item 140, Appendix F)
 Fault Code Retrieval Device (FCRD)
 (Item 60.1, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)

NOTE

The following steps should only be used if troubleshooting was started at First Chart For Diagnosis of Arctic Heater Troubleshooting procedure (Para 2-17.1 Fault 1) (all conditions) and you were referred here.



WARNING


Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE


Arctic heater flame sensor resistance is between 900 ohms at -13°F (-25°C) and 1100 ohms at 77°F (25°C).

CONTINUITY TEST

- (1) Ensure arctic heater temperature is between -13° and 77°F (-25° and 25°C).
- (2) Remove cover from arctic heater (TM 9-2320-364-20).
- (3) Disconnect arctic heater unit harness connector from arctic heater control unit (TM 9-2320-364-20).
- (4) Remove three screws and arctic heater control unit (Para 18-2.2).
- (5) Connect positive (+) lead to gray wire at arctic heater internal harness connector, terminal 15.
- (6) Connect negative (-) lead to gray wire at arctic heater internal harness connector, terminal 16.
- (7) Is resistance measured across arctic heater flame sensor between 900 and 1100 ohms at room temperature?
 - (a) If resistance reading is not between 900 and 1100 ohms at room temperature, replace arctic heater flame sensor (Para 18-2.2).
 - (b) If resistance reading is between 900 and 1100 ohms at room temperature, replace arctic heater control unit (Para 18-2.2).



12. FAULT CODE 064 OR 065: FLAME SENSOR OPEN CIRCUIT OR FLAME SENSOR SHORT CIRCUIT (CONT).




WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (4) and (5) only if fault code retrieval device (FCRD) is available.

VERIFY REPAIR
<ol style="list-style-type: none"> (1) If removed, install arctic heater control unit (Para 18-2.2). (2) Connect arctic heater unit harness connector to arctic heater control unit (TM 9-2320-364-20). (3) Ensure vehicle is returned to normal operating condition. (4) Install fault code retrieval device (FCRD) on arctic heater harness diagnostic connector. (5) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON. (6) Turn arctic heater ON (TM 9-2320-364-10). (7) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown. (8) Observe arctic heater for proper operation. (9) Turn arctic heater switch OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed. (10) If installed, remove fault code retrieval device (FCRD). (11) Install cover on arctic heater (TM 9-2320-364-20). <ol style="list-style-type: none"> (a) If arctic heater operates normally and arctic heater indicator light is illuminated (Fault code 000 displayed on FCRD), fault has been corrected. (b) If arctic heater indicator light flashed flash code shown (Fault 064 or 065 displayed on FCRD), notify supervisor. (c) If arctic heater indicator light flashed different flash code (Fault code other than 064 or 065 displayed on FCRD), troubleshoot arctic heater fault code displayed (TM 9-2320-364-20).



2-17.1. ARCTIC HEATER (MODEL B) TROUBLESHOOTING (CONT).

13. FAULT CODE 090, 093, 094 OR 097: CONTROL UNIT DEFECTIVE (INTERNAL FAULT, RAM ERROR, EPROM FAULT OR POWER FAILURE).

INITIAL SETUP

Tools and Special Tools

Tool Kit, General Mechanic's: Automotive
 (Item 241, Appendix F)
 STE/ICE-R (optional) (Item 15, Appendix F)
 Multimeter (Item 140, Appendix F)
 Fault Code Retrieval Device (FCRD)
 (Item 60.1, Appendix F)

References


TM 9-2320-364-10
 TM 9-2320-364-20

Equipment Condition

Engine OFF, (TM 9-2320-364-10)
 Parking brake applied, (TM 9-2320-364-10)
 Wheels chocked, (TM 9-2320-364-10)

NOTE

The following steps should only be used if troubleshooting was started at First Chart for Diagnosis of Arctic Heater Troubleshooting procedures (Para 2-17.1 Fault 1) (all conditions) and you were referred here.



WARNING

Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry or tools contact positive electrical circuits, a direct short may result. Damage to equipment, injury or death to personnel may occur.

NOTE

- Refer to arctic heater (Model B) troubleshooting (TM 9-2320-364-20) for fault code retrieval device (FCRD) operation.
- If the fault code retrieval device (FCRD) is not installed, the arctic heater indicator light displays the diagnostic flash codes for the arctic heater. These flash codes are 8 seconds long and repeat after 8 seconds.
- The fault code retrieval device (FCRD) displays the last 5 faults that occur. The latest fault displayed is either AF or F1. If more than one fault code is displayed, troubleshoot the latest fault code first.
- Perform Steps (4) and (5) only if fault code retrieval device (FCRD) is available.


VISUAL INSPECTION

- (1) Remove cover from arctic heater (TM 9-2320-364-20).
- (2) Replace arctic heater control unit (Para 18-2.2).
- (3) Ensure vehicle is returned to normal operating condition.
- (4) Install fault code retrieval device (FCRD) on arctic heater unit harness diagnostic connector.
- (5) Press the D button on fault code retrieval device (FCRD) to turn arctic heater ON.
- (6) Turn arctic heater ON (TM 9-2320-364-10).
- (7) Observe arctic heater indicator light or fault code retrieval device (FCRD) display, if installed. Note if arctic heater indicator light flashes code shown.
- (8) Observe arctic heater for proper operation.
- (9) Turn arctic heater switch OFF (TM 9-2320-364-10) or press the D button on the fault code retrieval device (FCRD), if installed.
- (10) If installed, remove fault code retrieval device (FCRD).
- (11) Install cover on arctic heater (TM 9-2320-364-20).
 - (a) If arctic heater operates normally and arctic heater indicator light is illuminated (Fault 000 displayed on FCRD), fault has been corrected.
 - (b) If arctic heater indicator light flashed flash code shown (Fault code 043, 047 or 048 displayed on FCRD), notify supervisor.
 - (c) If arctic heater indicator light flashed different flash code (Fault code other than code 090, 093, 094 or 097 displayed on FCRD), troubleshoot arctic heater fault code displayed (TM 9-2320-364-20).

FAULT FLASH CODE

CODE 090, 093, 094 OR 097

8 SECONDS



Section IV. MAINTENANCE PROCEDURES

2-18. MAINTENANCE INTRODUCTION.

This section provides general procedures to be followed for the Direct and General Support Maintenance level as specified in the Maintenance Allocation Chart (MAC). When a special procedure is used, the detailed procedure will be in the section covering that component.

2-19. GROUND HANDLING.

- a. *Towing.* Two towing eyes are located at front and two located at rear of truck.
- b. *Parking.* Parking brakes are designed to hold vehicle GVW on a minimum of 7-9 percent grade, pointing either uphill or downhill per Federal Motor Carrier Safety Regulation 393.41.
- c. *Mooring and Transport.* For forward, aft, lateral, and upward movements, truck has four tiedown rings. Refer to TM 9-2320-364-10 for mooring condition and tiedown locations.
- d. *Hoisting.* Sling assemblies and towing eyes used for hoisting are found on the truck.

2-20. GENERAL REMOVAL INSTRUCTIONS.

- a. *Work Required.* Remove parts if repair or replacement is required. Do not disassemble a component any further than needed.
- b. *Preparation.* Before removal of any electrical, hydraulic, or air system components, ensure system component is not energized or pressurized. Disconnect battery ground cables. On those trucks equipped with a battery disconnect switch, the switch may be used to disconnect batteries. Relieve air system pressure. Before removal of fasteners (nuts, locknuts), remove any paint on threads to prevent binding of fastener.
- c. *Identification.* To ease assembly and installation, tag and mark shims, connectors, wires, and mating ends of lines before disconnecting them. Identify similar parts to ensure correct assembly.
- d. *Position of Valves.* Before removing valve handles, mark or diagram their positions when open and closed. This will help during assembly.
- e. *Location.* Before removing cable ties, cushion clamps, hoses, tubing, wiring, etc., note the location, position and routing to ensure correct assembly.

2-21. GENERAL DISASSEMBLY INSTRUCTIONS.

CAUTION

Self-locking fasteners that are loosened must be replaced, not tightened.

- a. *Cleanliness.* Work area must be as clean as possible to prevent contamination to components.
- b. *Locking Parts.* Replace all lockwire, lockwashers, cotter pins, and locknuts at time of reassembly.
- c. *Expendable Parts.* All gaskets, packings, and seals removed during repair must be discarded and replaced with new parts.

d. Removing Seals. Be sure all traces of oil, gaskets, and sealants are removed from components. When possible, use wood or plastic probes and scrapers to prevent damage to machined surfaces.

CAUTION

Do not use tape to close off fuel or oil openings. Sticky surface of tape can mix with fuel and oil and cause engine malfunctions.

e. Parts Protection. To keep dust, dirt, moisture, and other objects out of internal parts of systems or components, cap or tape over all open tubes, hoses, fittings, air lines and component openings as soon as part is removed. Wrap all removed parts in clean paper or dip parts in preservation oil.

2-22. GENERAL CLEANING INSTRUCTIONS.

WARNING

- Drycleaning Solvent (P-D-680) is TOXIC and flammable. Wear protective goggles, face shield, and gloves; use only in a well-ventilated area; avoid contact with skin, eyes, and clothes, and do not breathe vapors. Keep away from heat or flame. Never smoke when using solvent. The flashpoint for Type II Drycleaning Solvent is 140 degrees F (60 degrees C) and Type III Drycleaning Solvent is 200 degrees F (93 degrees C). Failure to do so may result in injury or death to personnel.
- If personnel become dizzy while using cleaning solvent, immediately get fresh air and medical help. If solvent contacts skin or clothes, flush with cold water. If solvent contacts eyes, immediately flush eyes with water and get immediate medical attention.
- Never use fuel to clean parts. Fuel is highly flammable. Serious injury to personnel could result if fuel ignites during cleaning.

a. Cleaning Solvents. Use only approved cleaning solvents to clean parts. Drycleaning solvent, P-D-680, is commonly used. Always work in a well-ventilated area.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment (goggles/shield, gloves, etc). Failure to comply may result in injury to personnel.

b. Removing Deposits. Soak parts in dry cleaning solvent, and wash away deposits by flushing or spraying. When necessary, brush with a soft bristle brush (not wire) moistened in solvent. Use compressed air to dry parts, except bearings, after cleaning. Bearings must drip and air dry.

c. Tools. Do not use wire brushes, abrasive wheels, or compounds to clean parts unless specifically approved in the detailed procedures. Parts may be scratched or altered, and may weaken a highly stressed part.

2-22. GENERAL CLEANING INSTRUCTIONS (CONT).

d. Ball and Roller Bearings. When cleaning ball or roller bearings, place them in a basket and suspend them in a container of drycleaning solvent. If needed, use a brush to remove caked grease, chips, etc. Avoid rotating bearing before solid particles are removed to prevent damaging races and balls. When bearings have been cleaned, coat them lightly with lubricating oil to remove solvent.

CAUTION

Do not clean tires, lubricant seals, rubber hoses, or electrical components with solvent mixture.

e. Rubber Parts. Do not clean preformed packings or rubber parts in drycleaning solvent. Wipe parts clean with a dry, lint-free cloth.

WARNING

Steam cleaning creates hazardous noise levels and severe burn potential. Eye, skin, and ear protection is required. Failure to comply may result in injury to personnel.

f. Exterior Parts. Steam clean all exterior parts thoroughly before removing. This will make inspection and disassembly easier.

WARNING

Solvents used with a spray gun must be used in a spray booth with filter. Face shield must be used by personnel operating spray gun. Failure to comply may result in injury to personnel.

g. Engine, Cab, and Body. Use a spray gun and solvent mixture for cleaning exterior of engine, cab, and body. Allow mixture to remain on item surface for 10 minutes before rinsing. Rinse with hot water under 80 to 120 pounds of pressure, if available. An ordinary garden hose with nozzle may be used if other equipment is not available. Rinse thoroughly.

WARNING

To prevent corrosion, parts should be dipped in rust preventive within two hours of degreasing.

h. Degreasing Machine. A degreasing machine may be used to remove heavy grease and oil from metal parts.

i. Passages. After degreasing, check all oil passages and cavities for dirt or blockage before coating with rust preventive. Run a thin, flexible wire through oil passages to make sure they are not clogged. Use a pressure spray gun and drycleaning solvent to clean dirty passages.

j. Electrical Parts. Electrical parts, such as coils, junction blocks, and switches should not be soaked or sprayed with cleaning solutions. Clean these parts with a clean, lint-free cloth moistened with drycleaning solvent.

CAUTION

Do not use soap or alkalis for cleaning tank interiors.

k. Oil and Fuel Tanks. Pay special attention to all warnings and cautions when working on truck's fuel tank. Oil tanks and fuel tanks should be flushed, using a spray gun and drycleaning solvent.

l. Battery. Exterior surfaces of the electrical system and battery should be cleaned with a weak solution of baking soda and water. Apply solution with a bristle brush to remove corrosion. Pay special attention to all warnings and cautions when working on batteries.

WARNING

- Drycleaning Solvent (P-D-680) is TOXIC and flammable. Wear protective goggles, face shield, and gloves; use only in a well-ventilated area; avoid contact with skin, eyes, and clothes, and do not breathe vapors. Keep away from heat or flame. Never smoke when using solvent. The flashpoint for Type II Drycleaning Solvent is 140 degrees F (60 degrees C) and Type III Drycleaning Solvent is 200 degrees F (93 degrees C). Failure to do so may result in injury or death to personnel.
- If personnel become dizzy while using cleaning solvent, immediately get fresh air and medical help. If solvent contacts skin or clothes, flush with cold water. If solvent contacts eyes, immediately flush eyes with water and get immediate medical attention.

CAUTION

Never use gasoline or other petroleum base products to clean or preserve hydraulic system parts.

m. Hydraulic System. When cleaning hydraulic system parts use drycleaning solvent, P-D-680. Clean and dry parts thoroughly to make sure no residue remains. If a coating preservative is required before assembly, apply a light film of preservative oil. If petroleum-free solvents are not available, use the same hydraulic fluid as used in the truck's system.

2-23. GENERAL INSPECTION INSTRUCTIONS.

a. Cleaning. Clean all parts before inspection. Check for defects such as physical distortion, wear, cracks, and pitting.

b. Sealing Surfaces. Inspect all surfaces in contact with gaskets, packings, or seals for nicks and burrs. If any defect is found, remove it before assembly.

c. Bearings. Inspect bearings for rusted or pitted balls, races, or separators. Inspect balls and races for brinnelling, abrasion and serious discoloration. The following are conditions for bearing rejection:

- (1) Cuts or grooves parallel to ball or roller rotation.
- (2) Fatigue pits (not minor machine marks or scratches).
- (3) Cracks.

2-23. GENERAL INSPECTION INSTRUCTIONS (CONT).

d. Gears and Splined Shafts. Inspect gears and splined shafts for wear, pittings, rolling, peening, scoring, burning, brinnelling, and fatigue cracks.

e. Tubing, Hoses and Fittings. Inspect all hose surfaces for broken or frayed fabric. Check for breaks caused by sharp kinks or contact with other parts of the truck. Inspect copper tubing lines for kinks. Inspect fittings and tubing and mating surfaces and threads for nicks, cracks, scratches and other damage. Replace any defective part. After assembly and during initial truck operation period, check for leaks.

f. Electrical Parts. Inspect all wiring harnesses for broken, chafed, or burned wiring. Inspect all terminal connectors for loose connections and broken parts.

g. Metal Parts. Visually inspect all castings and weldments for cracks. Parts that carry a great load should receive magnetic particle inspection. Critical non-ferrous parts may be inspected with fluorescent penetrant.

h. Drain Plugs. When removing drain plugs from transmission, engine, hydraulic system components, or axle differential and planetary hubs, check amount of sediment on plugs. Accumulations of grit or fine metal particles may indicate actual or potential component failure. A few fine particles are normal. This inspection helps to determine if there are defective parts prior to internal inspection of the component, and to predict degradation of the equipment.

2-24. GENERAL WELDING INSTRUCTIONS.

WARNING

- CARC paint contains isocyanate (HDI) which is highly irritating to skin and respiratory system. High concentrations of HDI can produce symptoms of itching and reddening of skin, a burning sensation in throat and nose and watering of the eyes. In extreme concentrations, HDI can cause cough, shortness of breath, pain during respiration, increased sputum production, and chest tightness. The following precautions must be taken whenever using CARC paint:
- ALWAYS use air line respirators when using CARC paint unless air sampling shows exposure to be below standards. Use chemical cartridge respirator if air sampling is below standards.
- DO NOT let skin or eyes come in contact with CARC paint. Always wear protective equipment (gloves, ventilation mask, safety goggles, etc.).
- DO NOT use CARC paint without adequate ventilation.
- NEVER weld or cut CARC-coated materials.
- DO NOT grind or sand painted equipment without high-efficiency air purifying respirators in use.
- BE AWARE of CARC paint exposure symptoms; symptoms can occur a few days after initial exposure. Seek medical help immediately if symptoms are detected.
- Unsafe welding practices can cause serious injury from fire, explosions, or harmful agents. Allow only authorized personnel to weld or cut metals, and follow safety precautions in TC 9-237. Protective clothing and goggles must be worn; adequate protective equipment used, a suitable fire extinguisher kept nearby, and requirements of TC 9-237 strictly followed.

CAUTION

PLS truck must be properly prepared before welding or damage to equipment may result.
To prepare PLS truck for welding, refer to Para 6-39.

Thoroughly inspect all weldments for cracks, chips, or other damage. Areas of concern include the frame, radiator, LHS, Material Handling Crane, and cab assembly.

2-25. GENERAL REPAIR INSTRUCTIONS.

- a. *Burrs.* Remove burrs from surface teeth with a fine-cut file or cross cloth.
- b. *Exterior Parts.* Chassis and exterior painted parts may be resurfaced when paint is damaged, or where parts have been repaired.

NOTE

Polished or machined steel parts not protected by cadmium, tin, copper, or other plating or surface treatments require protection. Bare metal surfaces must be free of moisture when protective coating is applied.

- c. *Protecting Parts.* Protect bare steel surfaces from rust when not actually undergoing repair work. Dip parts in, or spray them with corrosion preventive compound. Aluminum parts may require protection in atmospheres having a high salt content.
- d. *Screws, Nuts, and Fittings.* Replace any screw, nut, or fitting with damaged threads. Inspect tapped holes for thread damage. If cross-threading is evident retap the hole for the next oversize screw or stud. If the retapping will weaken the part, or if the cost of the part makes retapping impractical, replace the part. Chasing the threads with proper size tap or die may be adequate.
- e. *Stud Installation.* When installing studs use a proper driver. A worn stud driver may damage the end thread. Then a chasing die must be used before a nut can be screwed on. This procedure will remove cadmium plating and allow corrosion. Before installing a stud, inspect the hole for chips. Blow out foreign matter and start stud by hand. Before final insertion, coat thread with a film of antiseize compound. Install stud to proper "setting height", which is the total projecting length.
- f. *Dents.* Straighten minor body dents by bumping with a soft-faced hammer while using a wooden block backing.
- g. *Sheet Metal Repair.* Repair minor skin cracks by installing patches.

2-26. GENERAL ASSEMBLY INSTRUCTIONS.

- a. *Preparation.* Remove protective grease coatings from new parts before installation.
- b. *Preformed Packing Installation.* Lubricate all preformed packings with a thin coat of light mineral oil before installing. To install a preformed packing, first clean the groove, then stretch packing and place into position. Place component on flat surface and uniformly press packing into position. Ensure preformed packings are not nicked or torn during assembly.

2-26. GENERAL ASSEMBLY INSTRUCTIONS (CONT).

CAUTION

Use sealing compound sparingly and only on male threads. Do not apply compound on first two threads to avoid contamination of system from compound. Do not apply compound to hose connections or fittings with preformed packings. Damage to equipment may result.

c. Pipe Joints and Fittings. Use sealing compound sealant or adhesive as indicated in each maintenance task. Refer to Para 2-27 for tightening procedure.

d. Oil Seals. Coat oil seals evenly with oil or grease before installing. Install oil seals with seal lip facing toward lubricant, applying an even force to outer edge of seal. If oil seals are to be installed over keyed or splined shafts, use a guide to prevent sharp edge of keyway or splines from cutting the leather or neoprene seal. Construct guides of very thin gage sheet metal and shape to the required diameter. Make certain guide edges are not sharp and are bent slightly inward so they do not cut the seal.

e. Bearings and Shafts. When mounting bearings on shafts always apply force to the inner races. When mounting bearings into housing always apply the force to the outer race.

f. Bearing Lubrication. Lubricate bearings before assembly with lubricant used in the related housing or container to provide the first run-in until lubricant from the system can reach the bearings.

WARNING

On direct contact, uncured silicone sealant irritates eyes. In case of contact, flush eyes with water and seek medical attention. In case of skin contact, wipe off and flush with water.

g. Silicone Sealant. Silicone sealant is often used instead of a gasket to seal mating parts. The mating parts must be clean, dry, and free of oil or grease for proper adhesion. After silicone sealant has been applied, the mating parts must be assembled immediately. Silicone sealant starts to set-up in 15 minutes and takes 24 hours to completely set. Excess silicone sealant should be wiped off after assembling the mating parts.

h. Gaskets. Remove all traces of previous gasket and sealant before installing new gasket. Coat both sides of gasket with sealant to provide added sealing.

2-27. GENERAL INSTALLATION INSTRUCTIONS.

a. Preparation. When unpacking items, remove all packing material, barrier paper, tape, plastic bags, protective caps, and protective grease coatings. Handle and store removed components carefully.

CAUTION

Use sealing compound sparingly and only on male threads. Do not apply compound on first two threads to avoid contamination of system from compound. Do not apply compound to hose connections or fittings with preformed packings. Damage to equipment may result.

b. Sealing Compounds. Use sealing compounds as required in each maintenance task.

c. *Torquing.* Tighten bolts, screws, washers, hoses and fittings as required in Appendix D or in each maintenance task.

d. *Identification Tags.* Put hoses, tubes, lines, and electrical wiring in place by matching identification tags and markings on equipment.

e. *Hoses, Airline and Wiring.* After installing hoses, air lines and wiring, ensure that they do not contact moving parts or components edges. Secure in place, out of way with cable ties and cushion clips.

f. *Hose and Fitting Tightening Procedure.*

NOTE

Tighten hoses and fittings as required in Appendix D or in each maintenance task. If a torque wrench and crowsfoot are not available or cannot be used, use the following procedure.

- (1) Install hose nut (1) on fitting (2).

NOTE


When turning effort increases, hose nut seat is in contact with adapter seat.

- (2) Tighten hose nut (1) until seated on fitting (2).

NOTE

Alignment marks allow the mechanic to count the number of flats the hose nut has rotated during tightening.

- (3) Scribe alignment mark on hose nut (1) and fitting (2).
- (4) Tighten hose nut (1) until mark on hose nut has rotated correct number of flats (Refer to Table 2-18).




2-27. GENERAL INSTALLATION INSTRUCTIONS (CONT).

Table 2-18. Recommended Flats Rotation.

Dash No.	SAE 37 Degree Flared Hose and Fitting Machined Seat	SAE 45 Degree Flared Hose and Fitting Machined Seat	37 Degree Flared Tube
-4	1 1/2 - 1 3/4	1 - 1 1/4	2 1/4 - 2 3/4
-5	1 - 1 1/2	1 - 1 1/4	2 1/4 - 2 3/4
-6	1 - 1 1/2	3/4 - 1	2 1/4 - 2 3/4
-8	1 1/4 - 1 3/4	1 - 1 1/4	2 1/4 - 2 3/4
-10	1 1/4 - 1 3/4	1 - 1 1/4	2 - 2 1/2
-12	1 - 1 1/2	1 - 1 1/4	2 - 2 1/2
-16	3/4 - 1	-----	2 1/4 - 2 3/4
-20	1/2 - 3/4	-----	1 1/4 - 1 3/4
-24	1/2 - 3/4	-----	3/4 - 1 1/4
-32	3/4	-----	1 - 1 1/4

g. Air Line Tightening Procedure.



- (1) Ensure end of air line (1) is cut square.
- (2) Remove nut (2), ferrule (3) and tube support (4) from fitting (5).
- (3) Position nut (2), ferrule (3) and tube support (4) on air line (1).

NOTE

Air line is properly seated when tube support bottoms out in fitting.

- (4) Install air line (1) in fitting (5) hand tight.

NOTE

Alignment mark allows mechanic to count the number of times the nut has rotated during tightening.

- (5) Scribe mark on nut (2) and fitting (5).
- (6) Tighten nut (2) until mark on nut (2) has rotated correct number of turns. (Refer to Table 2-19).




Table 2-19. Air Line Tightening.

Air Line O.D. Size	Additional Number of Turns from Hand-Tight
1/4	3
3/8 and 1/2	4
5/8 and 3/4	3 1/2

2-27. GENERAL INSTALLATION INSTRUCTIONS (CONT).

h. Pipe Thread Tightening Procedures.

WARNING

Adhesives, solvents, and sealing compounds can burn easily, can give off harmful vapors and are harmful to skin and clothing. To avoid injury or death, keep away from open fire and use in a well-ventilated area. If adhesive, solvent, or sealing compound gets on skin or clothing, wash immediately with soap and water.

CAUTION

Use sealing compound sparingly and only on male threads. Do not apply compound on first two threads to avoid contamination of system from compound. Do not apply compound to hose connections or fittings with preformed packings. Damage to equipment may result.

- (1) Coat threads of male fitting with sealing compound, sealant or adhesive as indicated in each maintenance task.
- (2) Position male fitting on female fitting finger tight.
- (3) Scribe alignment mark on both fittings.

CAUTION

- It may be necessary to tighten fitting slightly more or less than 2 1/2 turns to match position noted prior to removal. Do not loosen fitting to arrive at proper position or a leak may occur.
 - Over tightening may cause pipe fitting to deform and damage to the joining fitting, flange or component.
- (4) Tighten male fitting 2 1/2 (3 maximum) full turns past hand tight position.

i. *Fastener Tightening Sequence Procedures.*




Figure 2-17. *General Tightening Sequences.*

NOTE

If a component has a critical tightening sequence it will be illustrated in that particular task; otherwise, use the general sequence charts provided (Figure 2-17).

- (1) **Installation Torque.**
 - (a) Tighten nuts twice in a criss-cross pattern using a torque wrench. The first time nut is torqued apply approximately 75 percent of the final torque value.
 - (b) Repeat the sequence a second time until 100 percent of the final torque value has been obtained for each nut.
- (2) **Checking Torque.**

NOTE

When one or more screws are loose, check torque for all bolts on the component. Tighten nuts in a criss-cross pattern using a torque wrench. Apply 100 percent of the final torque value.

2-28. PREPARATION FOR STORAGE OR SHIPMENT INTRODUCTION.

Refer to (TM 9-2320-364-20) for introduction to preparation for storage and shipment.

2-29. PREPARATION FOR STORAGE OR SHIPMENT.

Refer to (TM 9-2320-364-20) for preparation for storage and shipment.

2-30. STORAGE MAINTENANCE PROCEDURES.

Refer to (TM 9-2320-364-20) for Storage Maintenance Procedures.

APPENDIX A

REFERENCES

A-1. SCOPE.

Indexes should be consulted frequently for latest changes or revisions of references given in this appendix and for new publications relating to material covered in this publication.

Military Publication Indexes.

Consolidated Index of Army Publications and Forms DA PAM 310-1

A-2. FORMS.

Refer to DA PAM 738-750, The Army Maintenance Management System (TAMMS), for instructions on the use of maintenance forms pertaining to the vehicle.

A-3. FIELD MANUALS.

The following publications contain information pertinent to the vehicle material.

Camouflage	FM 20-3
Manual for Wheel Vehicle Driver	FM 21-305
Nuclear, Biological, and Chemical Defense	FM 21-40
Basic Cold Weather Manual	FM 31-70
Northern Operations	FM 31-71
Chemical, Biological, and Radiological (CBR) Decontamination	FM 3-5
Nuclear, Biological, and Chemical (NBC) Reconnaissance and Decontamination Operations (How to Fight)	FM 3-87 (HTF)
Army Motor Transport Units and Operations	FM 55-30
Operation and Maintenance of Ordnance Materiel in Cold Weather 0°F to -65°F	FM 9-207

A-4. TECHNICAL MANUALS.

Painting Instructions	TM 43-0139
General Shop Practice Requirements for Repair, Maintenance, and Test of Electronic Equipment	TM 43-0158

A-4. TECHNICAL MANUALS (CONT).

Administrative Storage of Equipment **TM 740-90-1**

**Procedures for Destruction of Tank Automotive Equipment to Prevent
Enemy Use (U.S. Army Tank-Automotive Command)** **TM 750-244-6**

**Operator's and Organizational Support Maintenance Manual
for Care, Maintenance, Repair, and Inspection of Pneumatic
Tires and Inner Tubes** **TM 9-2610-200-14**

**Operator/Unit/Direct Support/General Support Maintenance Manual Including
Repair Parts and Special Tools List for Simplified Test Equipment
For Internal Combustion Engines** **TM 9-4910-571-12&P**

Maintenance and Repair for Lead-Acid Storage Batteries **TM 9-6140-200-14**

Inspection, Care, and Maintenance of Antifriction Bearings **TM 9-214**

**Materials Used for Cleaning, Preserving, Abrading, and Cementing
Ordinance Material and Related Materials Including Chemicals** **TM 9-247**

A-5. MISCELLANEOUS PUBLICATIONS.

Description, Use, Bonding Techniques, and Properties of Adhesives **TB ORD1032**

Safety Inspection and Testing of Lifting Devices **TB 43-0142**

**Use of Antifreeze Solutions and Cleaning Compounds in
Engine Cooling Systems** **TB 750-651**

Operator's Circular for Welding Theory and Application **TC 9-237**

APPENDIX B

EXPENDABLE SUPPLIES AND MATERIALS LIST

Section I. INTRODUCTION

B-1. SCOPE.

This appendix lists expendable supplies and materials you will need to operate and maintain the truck. These items are authorized to you by CTA50-970, Expendable Items (Except Medical, Class V, Repair Parts and Heraldic Items) or CTA8-100, Army Medical Department Expendable/Durable Items.

B-2. EXPLANATION OF COLUMNS.

- a. Column (1) - Item Number.* This number is assigned to the entry in the listing and is referenced in the narrative task box to identify the material (e.g., “Compound, Antiseize, Item 14, Appendix B”).
- b. Column (2) - Level.* This indicates the level of maintenance authorized to use the material as approved by the Maintenance Allocation Chart (MAC).
- c. Column (3) - National Stock Number.* This is the National Stock Number assigned to the item; use it to request or requisition the item.
- d. Column (4) - Description.* Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the Commercial and Government Entity (CAGE) code in parentheses followed by the part number.
- e. Column (5) - Unit of Measure.* Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in., pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
1	F	8040-00-843-0802 8040-00-225-4548	Adhesive, RTV 108 (80244) MIL-A-46106 GP1TY1 3 ounce kit 12 ounce tube	oz oz
2	F	8040-00-865-8991	Adhesive, RTV 732 (19207) 12266964	kt
3	F		Adhesive, (0PMN0) Sika 255FC BLK (45152) 3145938	oz
4	F		Adhesive, Spray (45152) 1537350	oz
5	F	6810-01-075-5546	Alcohol, Isopropyl (53390) 7618-19-4 40 ounce bottle	oz
6	F	6850-00-181-7940	Antifreeze	gl
7	F	7920-00-062-5468	Brush, Bristle (72387) 2-305SBN	ea
8	H	8020-00-324-9700	Brush, Paint (96906) MS 16866	ea
9	F	5975-00-273-8133	Cable Ties (96906) MS3367-3	pk
10	F	7510-00-223-6706	Chalk (58536) A-A-318	bx
11	F	7920-00-165-7195 7920-00-044-9281	Cloth, Cleaning (81349) MIL-C-85043 Type 1 - 10 lb box Type 2 - 10 lb box	lb lb
12	F	5350-00-221-0872	Cloth, Crocus (81348) P-C-458 50 sheet package	sh
13	F	8030-01-106-8393	Coating, Protective (09687) 57-021-102 1 quart can	qt
14	F	8030-01-087-8254 8030-00-155-6444	Compound, Antiseize (81399) MIL-A-907 8 ounce can with brush applicator 16 ounce aerosol can	oz oz

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
15	F	8030-00-062-6950 8030-01-149-1731 8030-00-837-6557 8030-00-903-0931	Compound, Corrosion Preventive (81349) MIL-C-16173 Grade 1 - 1 quart can Grade 2 - 1 quart can Grade 3 - 1 pint can Grade 4 - 1 pint can	qt qt pt pt
16	F		Compound, International No. 2 (45152) 5198563	oz
17	H		Compound, Retaining Type II (81349) MIL-R-46082B	oz
18	F	8030-00-231-2349 8030-00-231-2344	Compound, Rust Preventive (81349) MIL-R-10036 1 gallon can 5 gallon can	gl gl
19	F	6950-01-092-3550	Compound, Silicone (75037) 1609 can aerosol	oz
20	H	8010-00-889-9745	Dye, Prussian Blue (45152) 15963	oz
21	F	9150-01-197-7688 9150-01-197-7689	Grease, Automotive and Artillery (81349) MIL-G-10924 2.25 ounce tube 6.5 pound can	oz lb
22	F	9150-01-306-9202 9150-00-823-8047	Grease, General Purpose (81349) MIL-G-23549 1 pound can 35 pound can	lb lb
23	F	9150-01-145-1259	Grease, High Temperature (81349) DOD-G-85733	qt
24	F	9150-01-137-4657	Grease, HI-Vacuum (98079) 269352-2	qt
25	H	9150-01-235-5057	Grease, Instrument (97343) SRI-2 1 pint can	pt
26	F	9150-00-076-1587	Grease, Lithium (07748) 5555	oz
27	F	9150-01-091-9336	Grease, Molybdenum Disulfide (58372) 60G 1.5 pound can	lb

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
28	F	9150-00-754-2595 9150-00-965-2003	Grease, Molybdenum Disulfide (81349) MIL-G-21164 1.75 pound can 35 pound can	lb lb
29	F		Heatshrink, Sealed (46152) 1704940	ea
30	F	5970-00-815-1295	Heatshrink, Sealed (45152) 1704950	ea
31	F	2540-00-256-5529 2540-00-256-5526 2540-00-256-5527	Lubricant, Tire (96980) AA20 5 gallon can 1 quart can (96980) AA17 1 gallon can	gl qt gl
32	F	9140-00-286-5294	Oil, Diesel, Fuel BULK (81348) VVF800GRADEDF2RE	gl
33	H	9150-01-024-6059	Oil, Honing (58436) MB-30	qt
34	F	9150-00-189-6727 9150-00-183-7807	Oil, Hydraulic OE/HDO 10 (81349) MIL-L-2104 1 quart can 55 gallon drum	qt gl
35	F	6850-00-779-6851	Oil, Injector Test (33287) J 26400-5	oz
36	F	9150-00-186-6681 9150-00-189-6729	Oil, Lubricating OE/HDO 30 (81349) MIL-L-2104 1 quart can 55 gallon drum	qt gl
37	F	9150-00-189-6730 9150-00-405-2987	Oil, Lubricating, Engine OE/HDO 40 (81349) MIL-L-2104 1 quart can 55 gallon drum	qt gl
38	F	9150-01-152-4117 9150-01-152-4119	Oil, Lubricating, Engine OE/HDO 15W/40 (81349) MIL-L-2104 1 quart can 55 gallon drum	qt gl
39	F	9150-00-186-6699 9150-00-186-6703	Oil, Lubricating, Engine OE/HDO 10W/30 (81349) MIL-L-46152 1 quart can 55 gallon drum	qt gl

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
40	F		Oil, Lubricating, Gear 75 W/90 (81349) MIL-L-2105	qt
41	F	9150-01-035-5392 9150-00-001-9395	Oil, Lubricating, Gear 80W/90 (81349) MIL-L-2105 1 quart can 5 gallon can	qt gl
42	H		Paint, Black (45152) PS-025-9	oz
43	H	9150-00-250-0931 9150-00-250-0933	Petrolatum (81348) VV-P-236 8 ounce tube 7.5 pound can	oz lb
44	H	5210-00-640-6178	Plastigage (77220) PR-1	ea
45	F		Primer, (OPMN0) Sika Cleaner 205 (45152) 3145939	oz
46	F	8030-01-388-5604	Primer, "T" 7471 (05972) 19267	oz
47	F	7920-00-205-1711	Rags, Wiping (58536) A-A-531 50 pound bale	lb
48	F	4020-00-106-9342	Rope, 3/4 in. thick, 20 ft. (19207) MIL-R-24050	ea
49	F	8030-00-111-2762 8030-01-253-2319	Sealant, Adhesive (81349) MIL-S-46163 50 cc bottle 12 ounce tube	bt tu
50	F		Sealant, Electrical (00CE9) RTV200-257	
51	F		Sealer, Automotive (45152) 706786X	oz
52	H	8030-00-954-9371	Sealing Compound (77247) 51D 1 pint can	pt
53	F	8030-01-166-0675	Sealing Compound (05972) 56765	tu
54	F	8030-01-158-6070	Sealing Compound (05972) MIL-S-46163 Type 1 Grade K 10 milliliter bottle	bt

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
55	F	8030-01-069-3046	Sealing Compound (111280A) (05972) MIL-S-46163A Type II Grade M	bt
56	F	8030-01-104-5392 8030-01-025-1692	Sealing Compound (05972) Loctite #242 (80244) MIL-S-46163A Type 2 Grade N 10 milliliter bottle 250 milliliter bottle	bt bt
57	F	8030-01-159-4374 8030-01-142-9830 8030-01-142-3131	Sealing Compound (3206779) (05972) Loctite #262 10 milliliter bottle 50 milliliter bottle 250 milliliter bottle	ml ml ml
58	F	8030-01-303-0502 8030-01-387-2007	Sealing Compound (05972) Loctite #680 50 milliliter bottle 250 milliliter bottle	ml ml
59	F	8030-00-180-6150 8030-00-180-6222 8030-00-891-8358	Sealing Compound (05972) Loctite #609 (80244) MIL-R-46082B Type 1 10 milliliter bottle 50 milliliter bottle 250 milliliter bottle	bt bt bt
60	F		Sealing Compound (05972) Loctite #518 50 milliliter bottle 300 milliliter cartridge	bt cr
61	O	8030-01-054-0740 8030-00-204-9149 8030-01-166-0675	Sealing Compound (05972) Loctite #567 50 milliliter bottle 250 milliliter tube (05972) Loctite #567-47 50 milliliter tube	ml ml ml
62	F	8040-01-260-1939	Sealing Compound (71984) RTV 738	oz
63	F	8030-00-291-1787 8030-00-291-1789	Sealing Compound (81349) MIL-S-45180 1 pint can 1 gallon can	pt gl
64	F	8030-00-656-1426	Sealing Compound (77247) Permatex-3D 1 pint can	pt

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
65	F	8030-01-137-6964	Sealing Compound (05972) Loctite #515 50 milliliter tube	tu
65.1	F	8030-01-026-1538	Sealing Compound (05972) Loctite #569 250 milliliter bottle	bt
66	O	6850-00-177-5094	Silicone Compound, Anti-Corrosion (71984) DC4-2OZ 2 ounce tube	oz
67	F	6810-00-252-1345	Solution, Soap (81349) MIL-W-15000 Class C	bt
68	F	6850-00-664-5685 6850-00-264-9038	Solvent, Drycleaning (81348) P-D-680 1 quart can 5 gallon can (Environmentally Compliant Solvent) (OK209) Breakthrough	qt gl
		6850-01-378-0679	5 gallon can	gl
69	F	8010-00-440-4224	Spirits, Mineral (83992) 3526	gl
70	F	9515-01-268-9500	Strip, Metal (39428) 9500K18	in
71	F	9320-00-491-5351	Strip, Rubber (98882) 70-17-13	ft
72	F	9905-00-537-8957 9905-00-537-8955	Tags, Identification (81349) MIL-T-12755 White Yellow	ea ea
73	F	7510-00-680-2395	Tape, Masking (26066) 231	ea
74	F	5970-00-547-0966	Tape, Electrical (19207) BISEALTYPE3	ea
75	F	7510-01-358-8770	Tape, Pressure Sensitive (52152) 4950 36 yard roll	yd
76	H	8010-00-401-0421	Varnish (79810) FIXATIF	qt
77	F	5970-00-901-5331	Varnish, Insulating, Electrical (15202) 10-9002	oz

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST (CONT)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
78	F	6145-01-074-7535	Wire, 16 Gage (45152) 1927FX	ft
79	H	9505-00-331-3275	Wire, Nonelectrical (96906) MS20995C41	lb

APPENDIX C

ILLUSTRATED LIST OF MANUFACTURED ITEMS

Section I. INTRODUCTION

C-1. SCOPE.


This appendix includes complete instructions for manufacturing or fabricating authorized items locally. All bulk materials needed to manufacture an item are listed by part number or specification number in a tabular list with an illustration, as needed.

Section II. MANUFACTURED ITEMS

C-2. FUEL HOSE FABRICATION.

The following hoses are cut from bulk hose using a fine-toothed hacksaw or suitable cutting device. Locations and installation instructions for fuel hoses are found in TM 9-2320-364-20. Table C-1 lists the fuel hoses.

Table C-1. Fuel System Hoses



Hose Assembly P/N	Bulk Hose P/N	Cut off Length	
		Inches	cm
65068AX-024	2575-48RL	24	610
47371AXU-018	FC350-04	18	457
EU102958-025	FC350-06	25	635
EU101958-052	FC350-06	52	1321
1924600U-034	FC350-10	34	864
56845AXU-005	FC350-10	5	127

C-3. AIR INTAKE HOSE FABRICATION.

There are two hoses in the air intake system that require fabrication. Both hoses can be cut from bulk stock using a fine-toothed hacksaw or suitable cutting device. Refer to TM 9-2320-364-20 for locations and installation instructions.

Table C-2. Air Intake Hoses

Hose Assembly P/N	Bulk Hose P/N	Cutoff Length	
		Inches	mm
2103FXW-120	21020FX	120	3048
1732400U-067	FC300-16	67	1702

C-4. COOLING SYSTEM HOSES FABRICATION.

The following hoses for the cooling system are cut from bulk hose using a fine-toothed hacksaw or suitable cutting device. Locations and installation instructions are found in TM 9-2320-364-20.


Table C-3. Cooling System Hoses

Hose Assembly P/N	Bulk Hose P/N	Cutoff Length	
		Inches	mm
69940AX-048	3230-0293	48	1219
4811FX-100	4811FX	100	2540
46754AX-U-020	FC350-06	20	508

C-5. SEAL FABRICATION.

Fabricate seals from bulk seal stock listed in Table C-4. Use a suitable cutting tool to cut seal to length required.

Table C-4. Seal, Nonmetallic




The diagram shows a perspective view of a long, thin, rectangular piece of bulk seal stock. A double-headed arrow above the piece is labeled "CUTTING LENGTH", indicating the distance from the left end to a specific point on the right side. An arrow points from the text "BULK SEAL STOCK" below to the center of the piece.

Seal P/N	Seal Bulk P/N	Cutoff Length	
		inches	mm
59747AX-040	101-2203	40	1016
59747AX-055	101-2203	55	1397
59745AX-040	75000519	40	1016
59745AX-055	75000519	55	1397
125865A-047	75001366	47	1194
125865A-116	75001366	116	2946
125865A-160	75001366	160	4064

C-6. EDGING AND MOLDING FABRICATION.

Edging and molding can be fabricated from bulk stock listed in Table C-5. Use suitable cutting tool to cut to length required.

Table C-5. Edging and Molding




The diagram shows a perspective view of a rectangular block of material, labeled 'BULK MOLDING STOCK'. A horizontal double-headed arrow above the block is labeled 'CUTTING LENGTH', indicating the dimension to be cut.

Edging/Molding P/N	Edging/Molding Bulk P/N	Cutoff Length	
		inches	mm
1339700-011	1339700	11	279
26927AX-026	26927AX	26	660
26947BX-002	75000317	2	51
26947BX-003	75000317	3	76
26947BX-004	75000317	4	102
26947BX-005	75000317	5	127
26947BX-006	75000317	6	152
26947BX-017	75000317	17	432
26947BX-018	75000317	18	457
1467160-012	75000317	12	305
42925AX-005	OR40	5	127
27022AX-002	R-422-N	2	5
27022AX-019	R-422-N	19	483
27022AX-024	R-422-N	24	610
27022AX-043	R-422-N	43	1092
27022AX-093	R-422-N	93	2362
27022AX-101	R-422-N	101	2565
27022AX-130	R-422-N	130	3302

C-7. LOCKWIRE ROPE FABRICATION.

The lockwire length is shown in Table C-6. Crimped button stop caps are used to attach the lockwire to other components. Each application requires two swaging sleeve clips.



NOTES:

1. Obtain all components required to fabricate lockwire.
2. Use a fine toothed hacksaw or suitable cutting device, and cut lockwire to length required.
3. Slide wire through hole in component, until lockwire comes through other side.
4. Slide cap onto lockwire, until cap bottoms against component and wire comes through cap.
5. Crimp cap to lockwire.
6. Slide opposite end of wire through assembly, and slide other cap over end of wire.
7. Slide wire through hole in component, until lockwire comes through other side.
8. Slide cap onto lockwire, until cap bottoms against component and wire comes through cap.
9. Crimp cap to lockwire

The following wire rope is cut from bulk stock. Refer to Table C-6 for cutting lengths.


Table C-6. Lockwire Rope

Lockwire Rope Part Number	Lockwire Rope Bulk Park Number	Cutoff Length	
		Inches	cm
1533100-010	1533100	10	25
1533100-015	1533100	15	38
1533100-020	1533100	20	51
1533100-024	1533100	24	61

C-8. WIRE AND WIRE ASSEMBLIES FABRICATION.

Fabricate from bulk wire stock listed in Table C-7. Use wire cutters to cut wire to required length, then strip ends of wire 1/4 in (6.35 mm). Crimp the required lugs or terminals onto wire ends.

Table C-7. Wire and Wire Assemblies




The diagram illustrates the fabrication of a wire assembly. It shows a central section of 'BULK WIRE STOCK' with a 'CUTTING LENGTH' indicated by a double-headed arrow above it. At each end of the wire, a '1/4 IN. (6 mm)' section is marked with arrows, indicating the length to be stripped. On each end, a 'TERMINAL' (labeled 'A' and 'B') is crimped onto the wire. The terminals are shown as U-shaped components with a central opening.

Wire/Assembly Part Number	Bulk Wire Part Number	Cutoff Length	
		inches	cm
1884540W-012	121782A	12	31
1947560W-012	121782A	12	31
1959390W-012	121782A	12	31
1959600W-012	121782A	12	31
1977300W-010	4127FX	10	25
1974580-013	R-64951	13	33
1974590-005	R-64951	5	13
1978470W-005	R-64951	5	13

C-9. HOSES AND TUBES.

Fabricate hoses and tubes from bulk hose or tube stock listed in Table C-8. Use a fine toothed hacksaw or suitable cutting device and cut hose/tube to desired length. Place fitting A in vise and screw hose/tube counterclockwise until hose/tube bottoms out in fitting. Back off 1/4 turn. Repeat for fitting B.

Table C-8. Hoses and Tubes



Hose/Tube Part Number	Bulk Hose Part Number	Cutoff Length	
		Inches	cm
5113689-12	1525-6	12	31
21021FX-026	2102CFX	26	66
32850AX-014	22020	14	36
32850AX-016	22020	16	41
32850AX-030	22020	30	76
32850AX-036	22020	36	91
32850AX-51	22020	51	130
31270AX-029	31270AX	29	74
31270AX-082	31270AX	82	208
31270AX-096	31270AX	96	244
31270AX-140	31270AX	140	356
69940AX-006	3230-0293	6	15
69940AX-065	3230-0293	65	165
31271AX-040	3250-101	40	102
31271AX-047	3250-101	47	119
31271AX-053	3250-101	53	135
31271AX-092	3250-101	92	234
31271AX-150	3250-101	150	381

Table C-8. Hoses and Tubes (Cont)

Hose/Tube Part Number	Bulk Hose Part Number	Cutoff Length	
		Inches	cm
AAAC0085	5199575	85	216
AAAC0105	5199575	105	267
AAAC0190	5199575	190	483
AAAC0260	5199575	260	660
AAAE0090	5199575	90	229
1944510	70-062		Variable
1944520	70-062		Variable
23319FX-012	C604-200 BLK	12	31
23319FX-023	C604-200 BLK	23	58
23319FX-029	C604-200 BLK	29	74
23319FX-244	C604-200 BLK	244	620
23319FX-257	C604-200 BLK	257	653
23323FX-008	C606 BLACK	8	20
23323FX-008	C606 BLACK	8	20
23323FX-010	C606 BLACK	10	25
23323FX-010	C606 BLACK	10	25
23323FX-012	C606 BLACK	12	31
23323FX-014	C606 BLACK	14	36
23323FX-019	C606 BLACK	19	48
23323FX-022	C606 BLACK	22	56
23323FX-026	C606 BLACK	26	66
23323FX-030	C606 BLACK	30	76
23323FX-033	C606 BLACK	33	84
23323FX-042	C606 BLACK	42	107
23323FX-042	C606 BLACK	42	107
23323FX-044	C606 BLACK	44	112
23323FX-046	C606 BLACK	46	117
23323FX-050	C606 BLACK	50	127
23323FX-052	C606 BLACK	52	132
23323FX-055	C606 BLACK	55	140
23323FX-057	C606 BLACK	57	145
23323FX-060	C606 BLACK	60	152
23323FX-060	C606 BLACK	60	152
23323FX-082	C606 BLACK	82	208
23323FX-087	C606 BLACK	87	221
23323FX-089	C606 BLACK	89	226

Table C-8. Hoses and Tubes (Cont)

Hose/Tube Part Number	Bulk Hose Part Number	Cutoff Length	
		Inches	cm
23323FX-148	C606 BLACK	148	376
23323FX-159	C606 BLACK	159	404
23323FX-163	C606 BLACK	163	414
23323FX-200	C606 BLACK	200	508
23323FX-335	C606 BLACK	335	851
23323FX-377	C606 BLACK	377	958
198872A U-200	FC300-04	20	51
115134A W-004	FC300-04	4	10
1732400 U-067	FC300-16	67	170
1620950 U-099	FC350-04	99	252
47371AX U-055	FC350-04	5	13
47371AX U-006	FC350-04	6	15
47371AX U-012	FC350-04	12	31
47371AX U-017	FC350-04	17	43
47371AX U-018	FC350-04	18	46
47371AX U-120	FC350-04	120	305
60264AX U-031	FC350-04	31	79
60264AX U-034	FC350-04	34	86
60264AX U-054	FC350-04	54	137
60264AX U-057	FC350-04	57	145
60264AX U-063	FC350-04	63	160
60264AX U-082	FC350-04	82	208
60296AX U-029	FC350-04	29	74
60296AX U-036	FC350-04	36	91
60296AX U-061	FC350-04	61	155
1780700 U-032	FC350-06	32	81
1780700 U-035	FC350-06	35	89
1780700 U-039	FC350-06	39	99
1780700 U-041	FC350-06	41	104
1782400 U-022	FC350-06	22	56
1782410 U-021	FC350-06	21	53
1782450 U-025	FC350-06	25	64
47336AX-060	FC350-06	60	152
47554AX U-020	FC350-06	20	51
118971A U-022	FC350-08	22	56
118971A U-095	FC350-08	95	241

Table C-8. Hoses and Tubes (Cont)

Hose/Tube Part Number	Bulk Hose Part Number	Cutoff Length	
		Inches	cm
119784A U-010	FC350-08	10	25
119784A U-021	FC350-08	21	53
119784A U-047	FC350-08	47	119
1782340 U-019	FC350-08	19	48
1782360 U-020	FC350-08	20	51
1921290 U-025	FC350-08	25	64
1936150 U-032	FC350-08	32	81
1936150 U-034	FC350-08	34	86
1936150 U-038	FC350-08	38	97
1936150 U-040	FC350-08	40	102
69390AX U-006	FC350-08	6	15
69390AX U-019	FC350-08	19	48
69390AX U-020	FC350-08	20	51
69390AX U-020	FC350-08	20	51
69390AX U-021	FC350-08	21	53
69390AX U-025	FC350-08	25	37
1780720 U-020	FC350-10	20	51
1780720 U-051	FC350-10	51	130
1782370 U-037	FC350-10	37	94
1782380 U-031	FC350-10	31	79
1782390 U-020	FC350-10	20	51
1782420 U-039	FC350-10	39	99
1782430 U-031	FC350-10	31	79
1782440 U-019	FC350-10	19	48
1924600 U-090	FC350-10	90	229
47750AX U-009	FC350-10	9	23
58989AX U-020	FC350-10	20	51
58989AX U-034	FC350-10	34	86
58989AX U-064	FC350-10	64	163
66798AX U-020	FC350-10	20	51
66798AX U-025	FC350-10	25	64
66798AX U-030	FC350-10	30	76
66798AX U-077	FC350-10	77	196
1780710 U-082	FC350-12	82	208
1780710 U-083	FC350-12	83	211
47369AX U-127	FC350-12	127	323



Table C-8. Hoses and Tubes (Cont)

Hose/Tube Part Number	Bulk Hose Part Number	Cutoff Length	
		Inches	cm
61608AX U-093	FC350-12	93	236
61608AX U-142	FC350-12	142	361
47468AX U-011	FC350-16	11	28
47468AX U-022	FC350-16	22	56
47468AX U-045	FC350-16	45	114
47468AX U-046	FC350-16	46	117
47468AX U-089	FC350-16	89	226
47213AX-012	NT10012-50FT	12	31
47213AX-016	NT10012-50FT	16	41
47213AX-021	NT10012-50FT	21	53
47213AX-023	NT10012-50FT	23	58
47213AX-025	NT10012-50FT	25	64
47213AX-025	NT10012-50FT	25	64
47213AX-060	NT10012-50FT	60	152
47213AX-073	NT10012-50FT	73	185
47213AX-073	NT10012-50FT	73	185
47213AX-173	NT10012-50FT	173	439
47213AX-194	NT10012-50FT	194	493
1656470-030	PFT-4A-BLU	30	76
1656470-104	PFT-4A-BLU	104	264
1656470-115	PFT-4A-BLU	115	292
1656470-139	PFT-4A-BLU	139	353
1605260-008	PFT-4A-GRN	8	20
1605330-020	PFT-4A-ORG	20	51
1605330-040	PFT-4A-ORG	40	102
1605330-071	PFT-4A-ORG	71	180
1605330-112	PFT-4A-ORG	112	285
1605330-124	PFT-4A-ORG	124	315
1605170-007	PFT-4A-RED	7	18
1605270-023	PFT-6B-GRN	23	58
1605270-028	PFT-6B-GRN	28	71
1605270-056	PFT-6B-GRN	56	142
1605270-057	PFT-6B-GRN	57	145
1605270-100	PFT-6B-GRN	100	254
1605270-108	PFT-6B-GRN	108	274
1605270-146	PFT-6B-GRN	146	371

Table C-8. Hoses and Tubes (Cont)

Hose/Tube Part Number	Bulk Hose Part Number	Cutoff Length	
		Inches	cm
1605320-205	PFT-6B-ORG	205	521
1605160-012	PFT-6B-RED	12	31
1605160-014	PFT-6B-RED	14	36
1605160-030	PFT-6B-RED	30	76
1605160-031	PFT-6B-RED	31	79
1605160-047	PFT-6B-RED	47	119
1605160-048	PFT-6B-RED	48	122
1605160-049	PFT-6B-RED	49	125
1605160-055	PFT-6B-RED	55	140
1605160-102	PFT-6B-RED	102	259
1605160-103	PFT-6B-RED	103	262
1605160-114	PFT-6B-RED	114	290
1605160-165	PFT-6B-RED	165	419
1605160-213	PFT-6B-RED	213	541
1605300-026	PFT-6B-YEL	26	66
1605300-066	PFT-6B-YEL	66	168
1605300-070	PFT-6B-YEL	70	178
1605300-129	PFT-6B-YEL	129	328
1605300-132	PFT-6B-YEL	132	335
1605300-150	PFT-6B-YEL	150	381
1605300-022	PFT-8B-BLU	22	56
1605300-316	PFT-8B-BLU	316	802
1656500-128	PFT-10B-GRN	128	325
1656500-183	PFT-10B-GRN	183	465
1656490-102	PFT-10B-RED	102	259
1656490-202	PFT-10B-RED	202	513
1656490-257	PFT-10B-RED	257	653
W-22-13	W-22	13	33
W-22-9	W-22	9	23
40AW168-010	W-22-L	10	25
40AW168-050	W-22-L	50	127
40AW168-19	W-22-L	19	48
40AW168-27	W-22-L	27	69
40AW168-45	W-22-L	45	114

C-10. WOODEN BLOCKS.



- a. Fabricate from MML751 lumber stock.
- b. Using saw and standard planing machine, cut stock to size required in Table C-9.


Table C-9. Wooden Blocks

Para Number	Finished Dimensions of Block In. (cm)	Qty.
2-14	3 by 12 by 72 in. (8 by 30 by 183 cm)	4
2-15	2 by 4 by 12 in. (5 by 10 by 30 cm)	1
2-15	4 by 4 by 24 in. (10 by 10 by 61 cm)	1
3-7	4 by 4 by 24 in. (10 by 10 by 61 cm)	2
3-12	2 by 4 by 16 in. (5 by 10 by 41 cm)	2
3-18	4 by 4 by 24 in. (10 by 10 by 61 cm)	2
3-19	4 by 4 by 24 in. (10 by 10 by 61 cm)	2
3-33	2 by 4 by 12 in. (5 by 10 by 30 cm)	1
5-7	2 by 4 by 12 in. (5 by 10 by 30 cm)	2
6-31	4 by 4 by 24 in. (10 by 10 by 61 cm)	2
7-10	2 by 4 by 30 in. (5 by 10 by 76 cm)	2
9-3	2 by 4 by 12 in. (5 by 10 by 30 cm)	1
9-11	2 by 4 by 12 in. (5 by 10 by 30 cm)	1
9-13	2 by 4 by 12 in. (5 by 10 by 30 cm)	1
12-9	2 by 4 by 12 in. (5 by 10 by 30 cm)	1
12-9	2 by 4 by 11 in. (5 by 10 by 28 cm)	1
12-9	4 by 6 by 11 in. (10 by 15 by 28 cm)	1
12-10	2 by 4 by 12 in. (5 by 10 by 30 cm)	1
12-11	2 by 4 by 12 in. (5 by 10 by 30 cm)	1
13-2	2 by 4 by 6 in. (5 by 10 by 15 cm)	2
13-4	2 by 4 by 6 in. (5 by 10 by 15 cm)	2
13-13	6 by 7 by 15 in. (15 by 18 by 38 cm)	2
14-6	1 by 3 by 12 in. (3 by 8 by 30 cm)	1
15-2	2 by 2 by 4 in. (5 by 5 by 10 cm)	2
16-2	4 by 6 by 42 in. (10 by 15 by 107 cm)	4
16-3	2 by 4 by 12 in. (5 by 10 by 30 cm)	1
16-3	4 by 4 by 36 in. (10 by 10 by 91 cm)	1

Table C-9 Wooden Blocks (Continued)


Para Number	Finished Dimensions of Block In. (cm)	Qty.
16-6	4 by 4 by 18 in. (10 by 10 by 46 cm)	1
16-17	4 by 6 by 42 in. (10 by 15 by 107 cm)	2
16-26	4 by 4 by 18 in. (10 by 10 by 46 cm)	1
16-31	2 by 4 by 6 in. (5 by 10 by 15 cm)	1
16-38	4 by 6 by 35 in. (10 by 15 by 89 cm)	2
16-40	4 by 6 by 35 in. (10 by 15 by 89 cm)	2
16-41	2 by 4 by 6 in. (5 by 10 by 15 cm)	2
17-8	2 by 4 by 6 in. (5 by 10 by 15 cm)	2
17-12	4 by 6 by 35 in. (10 by 15 by 89 cm)	2
17-13	4 by 6 by 35 in. (10 by 15 by 89 cm)	2
17-14	1 by 2 by 6 in. (3 by 5 by 15 cm)	2
17-15	4 by 6 by 35 in. (10 by 15 by 89 cm)	2
17-16	4 by 6 by 35 in. (10 by 15 by 89 cm)	2
20-19	4 by 4 by 24 in. (10 by 10 by 61 cm)	2
20-39	2 by 4 by 12 in. (5 by 10 by 30 cm)	2
20-47	4 by 4 by 24 in. (10 by 10 by 61 cm)	2
20-48	2 by 4 by 36 in. (5 by 10 by 91 cm)	2
20-49	2 by 4 by 36 in. (5 by 10 by 91 cm)	2
20-50	4 by 4 by 24 in. (10 by 10 by 61 cm)	2
20-52	4 by 4 by 24 in. (10 by 10 by 61 cm)	2
20-53	4 by 4 by 24 in. (10 by 10 by 61 cm)	2
21-2	4 by 4 by 16 in. (10 by 10 by 41 cm)	2
23-12	2 by 4 by 30 in. (5 by 10 by 76 cm)	2
23-13	4 by 6 by 24 in. (10 by 15 by 61 cm)	2
23-14	6 by 6 by 16 in. (15 by 15 by 41 cm)	2
23-15	4 by 4 by 16 in. (10 by 10 by 41 cm)	2
23-18	2 by 4 by 30 in. (5 by 10 by 76 cm)	1
23-18	4 by 4 by 24 in. (10 by 10 by 61 cm)	2
23-19	4 by 4 by 24 in. (10 by 10 by 61 cm)	2
28-2	2 by 2 by 12 in. (5 by 5 by 30 cm)	2
28-3	2 by 2 by 12 in. (5 by 5 by 30 cm)	1
28-6	2 by 2 by 12 in. (5 by 5 by 30 cm)	2
28-9	4 by 6 by 35 in. (10 by 15 by 89 cm)	1
28-11	2 by 2 by 12 in. (5 by 5 by 30 cm)	2
28-13	2 by 2 by 12 in. (5 by 5 by 30 cm)	2
28-14	4 by 4 by 24 in. (10 by 10 by 61 cm)	2

C-11. FLANGE HOLDER.




Fabricate the flange holder from 1/2 in. (13 mm) thick mild steel stock. Using a torch, cut steel stock to dimensions shown. Using a grinder, remove all rough edges.

C-12. JET EXTRACTOR.




Fabricate from 3/8 in. (10 mm) thick mild steel stock. Using a hacksaw, cut to dimensions shown. Using a file or grinder, remove all rough edges.

C-13. PLYWOOD SHEET.




Fabricate from 1/2 in. (13 mm) thick plywood stock. Using a saw, cut to dimensions shown. Using a file or sandpaper, remove all rough edges.

C-14. STEEL TUBE.




Fabricate from 1/4 in. (6 mm) thick steel square tube stock. Using a hacksaw, cut a 24 in. (61 cm) length piece of tube. File off rough edges.

C-15. ADAPTER DIFFERENTIAL PRELOAD.




- (1) Fabricate from .250 in. (6.4 mm) thick x .625 in. (13 mm) wide mild steel stock.
- (2) Drill .328 in. (8.3 mm) hole where indicated.
- (3) Bend 90° where indicated.

C-16. WIRE HOOK.




- (1) Fabricate from 1/8 in. (3.2 mm) diameter steel welding rod or equivalent stiff wire.
- (2) Using cutting pliers, cut welding rod to 6 in. (15.2 cm) length or longer.
- (3) Using machinist's vise, bend 1/2 in. (13 mm) length of rod 90 degrees.

C-17. V-BLOCK BASE AND V-BLOCK.




Fabricate V-Block from 1 in. (25 mm) thick mild steel stock. Using a grinder, remove any sharp edges. Using a file and then a sharpening stone, remove roughness from the inside surface of the V.

C-18. LHS BUSHING REMOVER/INSTALLER (SMALL).


Fabricate large LHS bushing remover/installer from 4 in. (101 mm) x 3.339 in. diameter steel stock.

- a. Turn round stock to 3.339 in. ± .005 in.
- b. Cut a 1/4 in. (6 mm) x 45 degree chamfer where indicated.
- c. Drill through a 1.275 in. hole in the center of the 3.339 in. diameter steel stock where indicated.
- d. Starting at the end opposite of the chamfer, turn a length of 2.75 in. down to 3.146 in. ± .005 in. where indicated.
- e. Paint as required.


C-19. CHU BUSHING REMOVER/INSTALLER (SMALL).



Fabricate small CHU bushing remover/installer from 3.25 in. (8.255 cm) x 2.76 in. (7.01 cm) diameter steel stock.

- a. Turn round stock to 2.76 in. ± .005 in. (7.01 cm ± ∞ ®)
- b. Cut a 1/4 in. (6 mm) x 45 degree chamfer where indicated.
- c. Drill through a 1.275 in. (32.38 mm) hole in the center of the 2.76 in. diameter steel stock where indicated.
- d. Starting at the end opposite of the chamfer, turn a length of 2.00 in. down to 2.5 in. ± .005 in. where indicated.
- e. Paint as required.


C-20. LHS BUSHING REMOVER/INSTALLER (LARGE).



Fabricate small LHS bushing remover/installer from 1 in. (25 mm) x 4 1/4 in. (108 mm) diameter steel stock.

- a. Drill 1 1/2 in. (38 mm) through steel stock where indicated.
- b. Cut a 1/4 in. (6.35 mm) x 45 degree chamfer on both inside and outside diameters where indicated.
- c. Paint as required.


C-21. LHS LEAD SCREW.



Fabricate LHS lead screw from grade 8 steel.

- a. Cut length of thread rod to 9.750 in. (25 cm).
- b. Thread nut on rod until total length measures 10.00 in. (25 cm).
- c. Plug weld nut to thread rod.
- d. Two grade 8 nuts are required, one loose and one welded.


C-22. LHS BUSHING REMOVER.



Fabricate LHS bushing remover from 3.38 in. (85.85mm) x 4 1/2 in. (114 mm) diameter steel tubing.


- a. Cut 4 1/2 in. (114 mm) outside diameter x 1/2 in. (13 mm) thick tubing to cut length of 3.38 in. (85.85 mm).
- b. Cut a 1/4 in. (6 mm) x 45 degree chamfer where indicated.
- c. Paint as required.

C-23. LIFTING TEE HANDLES.



Fabricate material from: screw (1) .375 in. x 16 x 8 in. (20 cm) grade 5, and screw (1) .375 in. x 16 x 4 1/2 in. (11 cm) grade 5.


- a. Weld together screws where indicated.
- b. Paint as required.

C-24. LIFTING EYES.

Fabricate from 7/16 in. (11 mm) x 6 in. (152 mm) cold rolled steel.

- a. Thread 7/16 x 14 x 1 in. (25 mm) long.
- b. Heat unthreaded end and bend over 1 1/4 in. (32 mm) diameter rod.


C-25. TURBOCHARGER HOLDING FIXTURE.



Fabricate from 3/4 in. (19 mm) exterior grade plywood.

- a. Drill 1 1/2 in (38 mm) diameter hole in center of base.
- b. Drill four 1/2 in. (13 mm) diameter holes in corners of base.
- c. Draw a circle with a 1 5/8 in. (41 mm) radius.
- d. Route four 1/2 in. (13 mm) x 3/4 in. (19 mm) slots in base into circle as shown.
- e. Fabricate two 1 15/16 in. (49 mm) x 2 1/2 in (63.5 mm) x 1 1/4 in. (32 mm) fingers from plywood.
- f. Grind bottom of fingers 23/32 in. (18 mm) wide and 7/16 in. (11 mm) high. Contour front surface of fingers to fit turbine wheel blades.


C-26. CONSTANT VELOCITY U-JOINT BEARING CAP REMOVAL TOOL.



Fabricate from 1 in. (25.4 mm) mild steel round stock; 4 in. (101.6 mm) long.

- a. Turn down 2 1/4 in. (57.15 mm) of 1 in. (25.4 mm) mild steel round stock to .39 in. (10 mm).
- b. Tap 1 in. (25.4 mm) of 10 mm diameter shaft with 10 mm by 1 in. (25.4 mm) threads.
- c. Drill 5/8 in. (16mm) hole 1 in. (25.4mm) deep in 1 in. (25.4 mm) end of mild steel round stock.
- d. Tap 1 in. (25.4 mm) of 3/4 in. by 16 diameter hole in 1 in. (25.4 mm) end of mild steel round stock.


C-27. LHS WASHER.



Fabricate LHS washer from 2 1/4 in. (57.15 mm) by 1/4 in. (6.35 mm) diameter steel stock.

- a. Drill 1 1/4 in. (31.75 mm) hole through steel stock where indicated.
- b. Paint as required.
- c. An alternate flat washer that may be used is part number MS51412-44.


C-28. SPANNER SOCKET.



Fabricate spanner wrench from any 2 1/2 in. (63.50 mm) OD socket.


- a. Weld four 2 in. (50.80 mm) long strips of 3/16 in. (4.83 mm) keystock on socket, so that 1/2 in. (12.70 mm) extends beyond socket face.

C-29. STEEL DISC.



Fabricate steel disc from 2.5 in. (63.5 mm) round steel stock. Using a hacksaw, cut to dimension shown. File off rough edges.


C-30. FLANGE NUT SOCKET.



Fabricate flange nut socket from socket P/N 1M1005 NSN 5130-00-234-1890.


- a. Machine down outside diameter, face end of socket by 4.250 in. (107.95 mm) at a depth of 1.50 in. (38.10 mm).

C-31. STEERING STOP PLATE.




Fabricate steering stop plate from 1/8 in. (3 mm) thick mild steel stock. Using a hacksaw, cut to dimension shown. File off rough edges.

C-32. PITMAN ARM ANGLE PLATE.



Fabricate pitman arm angle plate from 3/16 in. (4.76 mm) thick mild steel stock. Using a hacksaw, cut to dimension shown. File off rough edges.


C-33. AXLE PLATE.



Fabricate axle plate from 1/8 in. (3 mm) thick mild steel stock.

- a. Cut a steel plate 4.50 in. (114.30 mm) by 8 in. (203.20 mm).
- b. Drill eight .62 in. (15.75 mm) diameter holes where shown.
- c. Drill four .44 in. (11.18 mm) diameter holes where shown.
- d. File off rough edges.
- e. Paint as required.


C-34. OIL COOLER TEST PLATE.



Fabricate oil cooler test plate from 3/8 in. (9.525 mm) thick mild steel stock.

- a. Using oil cooler gasket for template, cut a steel plate 9 5/16 in. (236 mm) by 10 7/16 in. (265 mm).
- b. Drill ten 3/8 in. (9.525 mm) diameter holes where shown.
- c. Drill 7/16 in. (11 mm) diameter hole where shown and tap to fit 1/2 in. NPT fitting.
- d. File off rough edges.
- e. Paint as required.


C-35. SEAL INSTALLER.



Machine seal installer from 2.75 in. (7 cm) diameter aluminum round stock.

- a. Cut a 6 in. (15 cm) piece of 2.75 in. (7 cm) diameter aluminum round stock.
- b. Drill 1.53 in. (4 cm) diameter hole through center of piece.
- c. Turn down to 1.970 in. (5 cm) diameter by .785 in. (20 cm) deep.
- d. Turn down to 2.210 in. (6 cm) diameter by .750 in. (19 cm) deep.


C-36. ADAPTER.



Fabricate from: screw (1) .500 in. x 13 x 1 in. grade 5, and nut 16mm x 1.50.

- a. Weld together screw and nut where indicated.
- b. Paint as required.

C-37. BEARING SHELL REMOVER.



- (1) Fabricate from 3/8 in. (9.5 mm) diameter cold rolled steel.
- (2) Heat and flatten 4-1/2 in. (114 mm) length of round stock until end is 1/8 X 1/2 X 4-1/2 in. (3.2 X 13 X 114 mm).
- (3) All dimensions are in inches (millimeters).

APPENDIX D

TORQUE LIMITS

D-1. SCOPE.

This section provides general torque limits for the screws, hoses and fittings used on the truck. Special torque limits are listed in the maintenance procedures for applicable components. The general torque limits given in this appendix shall be used when specific torque limits are not indicated in the maintenance procedure. These general torque limits cannot be applied to screws that retain rubber components. The rubber components will be damaged before the torque limit is reached. If a special torque limit is not given in the maintenance instructions, tighten the screw or nut until it touches the metal bracket then tighten it one more turn.


D-2. TORQUE LIMITS.

Table D-1 lists the torque limits for wet flange nuts. Table D-2 lists the torque limits for wet socket head capscrews. Table D-3 lists dry torque limits for capscrews. Dry torque limits are used on screws that do not have high pressure lubricants applied to the threads. Table D-4 lists wet torque limits for capscrews. Wet torque limits are used on screws that have high pressure lubricants applied to the threads. Table D-5 lists the torque limits for SAE 37 degree flare hose connections. Table D-6 lists the torque limits for SAE 45 degree flare hose connections. Table D-7 lists the torque limits for ORS preformed packing face seal hose connections. Table D-8 lists the torque limits for NPSM swivel connections.

D-3. HOW TO USE TORQUE TABLE.


a. Screws and Nuts.

- (1) Measure the diameter of the screw you are installing with a ruler.



D-3. HOW TO USE TORQUE TABLE (CONT).

- (2) Measure out one inch with a ruler and count the number of threads per inch.
- (3) Under the heading **SIZE**, look down the left hand column until you find the diameter of the screw you are installing (there will usually be two lines beginning with the same size).
- (4) In the second column under **SIZE**, find the number of threads per inch that matches the number of threads per inch you counted in Step 2. (Not required for metric screws).
- (5) To find the grade screw you are installing, match the markings on the head to the correct picture of **CAPSCREW HEAD MARKINGS** on the torque table.
- (6) Look down the column under the picture you found in Step 5. until you find the torque limit (lb-ft or N-m) for the diameter and threads per inch of the screw you are installing.
- (7) Use wet torque values.



CAPSCREW HEAD MARKINGS



Manufacturer's marks may vary. These are all SAE Grade 5 (3-line).	Metric screws are of three grades: 8.8, 10.9, and 12.9. Grades & Manufacturer's marks appear on the screw head.
 <p>STANDARD</p>	 <p>METRIC</p>

Table D-1. Torque Limits For Wet Flange Nuts



SPIRALLOCK FLANGE NUT MARKINGS GRADE 8	DIAMETER		THREADS PER INCH	TORQUE	
	IN.	MM		LB-FT	N-m
	1/4	6.35	20	15	20
	5/16	7.94	18	25	34
	3/8	9.65	16	45	61
	1/2	12.70	13	110	149
	5/8	15.87	11	210	285
	3/4	19.05	10	375	508

Table D-2. Torque Limits For Wet Socket Head Cap Screws

SOC HEAD/12 PT.	TORQUE IN FT. LBS. (CAP SCREWS) LUBED		
	SIZE	SOC HD OR 12 PT	SOC FLAT HD
	.10-24	5	2.5
	.25-20	12	6
	.31-18	25	12
	.38-16	44	22
	.50-13	70	36
SOC FLAT HEAD	.56-12	106	53
	.62-11	212	106
	.75-10	375	187
	1.00-8	781	

b. *Hoses and Fittings.*


NOTE

Most fluid piping system sizes are measured by dash numbers. These are universally used abbreviations for the size of the component expressed as the numerator of the fraction with the denominator always being 16. For example, a -04 port is 4/16 or 1/4-inch. Dash numbers are usually nominal (in name only) and are abbreviations that make ordering of components easier.


- (1) Measure the I.D./O.D. diameter with a caliper as shown.

- (2) Under the heading MALE THREAD O.D. and FEMALE THREAD I.D., match the measurements with the row in table to determine proper torque.

- (3) To find the sealing surface angle, use a protractor and measure the sealing surface parallel to the center line of the fitting.



**O.D.
(MALE THREADS)**



**I.D.
(FEMALE THREADS)**





Table D-3. Torque Limits For Dry Fasteners

SIZE			TORQUE							
			SAE GRADE NO. 2		SAE GRADE NO. 5		SAE GRADE NO. 6 or 7		SAE GRADE NO. 8	
DIA. INCHES	THREADS PER INCH	MILLIMETERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS
1/4	20	6.35	5	7	8	11	10	14	12	16
1/4	28	6.35	6	9	10	14	12	16	14	19
5/16	18	7.94	11	15	17	23	21	28	25	34
5/16	24	7.94	12	16	19	26	24	33	25	34
3/8	16	9.53	20	27	30	41	40	54	45	61
3/8	24	9.53	23	31	35	47	45	61	50	68
7/16	14	11.11	30	41	50	68	60	81	70	95
7/16	20		35	47	55	75	70	95	80	108
1/2	13	12.70	50	68	75	102	95	129	110	149
1/2	20		55	75	90	122	100	136	120	163
9/16	12	14.29	65	88	110	149	135	183	150	203
9/16	18		75	102	120	163	150	203	170	231
5/8	11	15.88	90	122	150	203	190	258	220	298
5/8	18		100	136	180	244	210	285	240	325
3/4	10	19.05	160	217	260	353	320	434	380	515
3/4	16		180	244	300	407	360	488	420	570
7/8	9	22.23	140	190	400	542	520	705	600	814
7/8	14		155	210	440	597	580	786	660	895
1	8	25.40	220	298	580	786	800	1085	900	1220
1	12		240	325	640	868	860	1166	1000	1356
1-1/8	7	25.58	300	407	800	1085	1120	1519	1280	1736
1-1/8	12		340	461	880	1193	1260	1709	1440	1953
1-1/4	7	31.75	420	570	1120	1519	1580	2142	1820	2468
1-1/4	12		460	624	1240	1681	1760	2387	2000	2712
1-3/8	6	34.93	560	759	1460	1980	2080	2820	2380	3227
1-3/8	12		640	868	1680	2278	2380	3227	2720	3688
1-1/2	6	38.10	740	1003	1940	2631	2780	3770	3160	4285
1-1/2	12		840	1139	2200	2983	3100	4204	3560	4827

CAPSCREW HEAD MARKINGS



Manufacturer's marks may vary. These are all SAE Grade 5 (3-line).







Table D-4. Torque Limits For Wet Fasteners

CAPSCREW HEAD MARKINGS			TORQUE							
SIZE			SAE GRADE NO. 2		SAE GRADE NO. 5		SAE GRADE NO. 6 or 7		SAE GRADE NO. 8	
DIA. INCHES	THREADS PER INCH	MILLIMETERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS	POUNDS FEET	NEWTON METERS
1/4	20	6.35	4	6	6	8	8	11	9	12
1/4	28	6.35	5	7	7	9	9	12	10	14
5/16	18	7.94	8	11	13	18	16	22	18	24
5/16	24	7.94	9	12	14	19	18	24	20	27
3/8	16	9.53	15	20	23	31	30	41	35	47
3/8	24	9.53	17	23	25	34	30	41	35	47
7/16	14	11.11	24	33	35	47	45	61	55	75
7/16	20		25	34	40	54	50	68	60	81
1/2	13	12.70	35	47	55	75	70	95	80	108
1/2	20		40	54	65	88	80	108	90	122
9/16	12	14.29	50	68	80	108	100	136	110	149
9/16	18		55	75	90	122	110	149	130	176
5/8	11	15.88	70	95	110	149	140	190	170	231
5/8	18		80	108	130	176	160	217	180	244
3/4	10	19.05	120	163	200	271	240	325	280	380
3/4	16		140	190	220	298	280	380	320	434
7/8	9	22.23	110	149	300	407	400	542	460	624
7/8	14		120	163	320	434	440	597	500	678
1	8	25.40	160	217	440	597	600	814	680	922
1	12		170	231	480	651	660	895	740	1003
1-1/8	7	25.58	220	298	600	814	840	1139	960	1320
1-1/8	12		260	353	660	895	940	1275	1080	1464
1-1/4	7	31.75	320	434	840	1139	1100	1492	1360	1844
1-1/4	12		360	488	920	1248	1320	1790	1500	2034
1-3/8	6	34.93	420	570	1100	1492	1560	2115	1780	2414
1-3/8	12		460	624	1260	1709	1780	2414	2040	2776
1-1/2	6	38.10	560	760	1460	1980	2080	2820	2360	3200
1-1/2	12		620	841	1640	2224	2320	3146	2660	3607

Table D-5. Torque Limits For 37 Degree Flare Hose Connections



				
INCH SIZE	DASH NO.	THREAD SIZE	TORQUE LB.FT.	TORQUE N·m
1/4	04	7/16-20	11-12	15-16
3/8	06	9/16-18	18-21	24-28
1/2	08	3/4-16	36-39	49-53
5/8	10	7/8-14	57-62	77-84
3/4	12	1 1/16-12	79-87	107-118
7/8	14	1 3/16-12	83-91	113-123
1	16	1 5/16-12	108-113	146-153
1 1/4	20	1 5/8-12	127-133	172-180
1 1/2	24	1 7/8-12	158-167	214-224
2	32	2 1/2-12	245-258	332-350

Table D-6. Torque Limits For 45 Degree Flare Hose Connections



				
INCH SIZE	DASH NO.	THREAD SIZE	TORQUE LB.FT.	TORQUE N·m
1/4	04	7/16-20	8-9	11-12
3/8	06	5/8-18	18-20	24-27
1/2	08	3/4-16	36-38	49-51
5/8	10	7/8-14	52-54	70-73
3/4	12	1 1/16-14	71-74	97-100

Table D-7. Torque Limits For ORS Preformed Packing Face Seal Hose Connections



				
INCH SIZE	DASH NO.	THREAD SIZE	TORQUE LB.FT.	TORQUE N-m
1/4	04	9/16-18	10-12	14-16
3/8	06	11/16-16	18-20	24-27
1/2	08	13/16-16	32-35	43-47
5/8	10	1-14	46-50	62-68
3/4	12	1 3/16-12	65-70	88-95
1	16	1 7/16-12	108-113	146-153
1 1/4	20	1 11/16-12	127-133	172-180
1 1/2	24	2-12	158-167	214-226

Table D-8. Torque Limits For NPSM Swivel Connections

				
INCH SIZE	DASH NO.	THREAD SIZE	TORQUE LB.FT.	TORQUE N-m
1/8	02	1/8-27	3-4	4-5
1/4	04	1/4-18	10-11	14-15
3/8	06	3/8-18	16-18	22-24
1/2	08	1/2-14	25-27	34-37
3/4	12	3/4-14	46-48	62-65
1	16	1-1 1/2	80-83	108-113
1 1/4	20	1 1/4-11/2	130-134	176-182
1 1/2	24	1 1/2-11/2	160-164	217-222
2	32	2-11/2	170-174	231-240

APPENDIX E

MANDATORY REPLACEMENT PARTS

Section I. INTRODUCTION

E-1. SCOPE.

This appendix lists all mandatory replacement parts required for performance of Direct and General Support Maintenance of the PLS truck. It authorizes the requisitioning, issue, and disposition of consumable repair parts. All consumable repair parts listed in the maintenance tasks are listed here for ease of reference.

E-2. EXPLANATION OF COLUMNS (SECTION II).

- a. Column (1) - Replacement Part Reference Code.* This number is assigned to the entry in the listing and is referenced in the narrative task box to identify the part e.g., Clamp (Item 12, Appendix E).
- b. Column (2) - Nomenclature.* Indicates the federal item name and, if required, a description to identify the item.
- c. Column (3) - Part Number.* This is the vendor number assigned to the item.
- d. Column (4) - National Stock Number.* This is the National Stock Number assigned to the item; use it to request or requisition the item.

Section II. MANDATORY REPLACEMENT PARTS LIST

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
1	Adapter, Fuel	8928631	4730-01-336-6943
2	Ball	4B9880	3110-00-949-1438
3	Beam Center Bushing	29481-5	5365-01-161-4062
4	Beam Center Bushing	49400	3120-01-329-4297
5	Beam Center Bushing	C-2159	5365-01-344-2477
6	Beam End Bushing	45163	3120-01-345-0940
7	Beam End Bushing	45900	3120-01-155-4522
8	Bearing	23503649	3110-01-359-4525
9	Bearing	23503687	3110-01-359-4677
10	Bearing	441843-0001	3120-01-239-1369
11	Bearing Kit, Taper	V88130017	3120-01-346-7757
12	Bearing Set	2405CPA	3120-01-157-6832
13	Bearing, Intermediate	5196026	3120-00-843-6994
14	Bearing, Piston Pin	23501687	3120-00-094-3552
15	Bearing, Taper	V75650169	3110-01-273-0041
16	Bearing, Thrust	443688-1	3120-01-239-5139
17	Bearing, Thrust	TP612	3120-00-596-7688
18	Bolt Kit, Air Spring	A-10284	5305-01-345-3748
19	Bolt Set	A-5332	5306-01-344-7993
20	Bolt, Self-Locking	N9077	5306-01-223-4345
21	Bushing	209P-8-4	4730-01-348-6542
22	Bushing	5122445	3120-00-811-4699
23	Bushing	5123700	3120-00-662-1651
24	Bushing	GLY.PG 808560 A	5364-01-355-9529
25	Bushing, Plastic, Spacer	194	5365-01-154-8511
26	Clamp	24433	5340-01-131-8313
27	Clamp	5132650	5340-01-048-7743
28	Clamp	5143999	4730-00-080-5799
29	Clamp	700-88	5340-01-355-7648
30	Clamp	X300	5340-01-197-1196
31	Clip	COV0713	5340-01-029-9172
32	Collar, Adjustment	B-2848	3040-01-346-9820
33	Collar, Shaft	8925751	3040-01-234-8467
34	Copper Washer	265850FC88	5310-00-193-9753
35	Copper Washer	23513842	5310-01-395-1250
36	Copper Washer	5108436	5310-00-486-3129
37	Cover, Access	5117733	5340-00-833-0822
38	Cross	V75750400	2520-01-352-9164
39	Cross And Bearing	5-103X	2530-01-244-4949
40	Dust Cover	L-28-VC-121	5340-01-346-2252
41	Dust Shield	23016012	5340-01-318-9153

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
42	Element	5101760	2940-00-089-2520
43	Element	5106910	4730-01-160-5668
44	Filter Element	2020PMOR	2910-01-344-5791
45	Filter Element	23014205	2940-01-328-5584
46	Filter Element	25010643	4330-01-132-4842
47	Filter Element	25010778	2910-01-022-8183
48	Fitting, Grease	N1199N1860	4730-01-348-9511
49	Fitting, Grease	V75501903	4730-01-345-0734
50	Fitting, Grease	V75503714	4730-01-384-6286
51	Fitting, Lubrication	MS15002-3	4730-00-172-0015
52	Front/Rear Steer Gear Repair Kit	5518181	2530-01-335-7776
53	Fuel Pipe, Jumper	8928628	4710-01-337-4466
54	Gasket	02-23-00870-150	5330-01-281-1842
55	Gasket	03158320033	
56	Gasket	03158320035	
57	Gasket	0601-16501	5330-01-356-9971
58	Gasket	11007B	5330-01-344-0539
59	Gasket	11028B	5330-01-147-2520
60	Gasket	14079550	5330-00-107-3925
61	Gasket	23016017	5330-01-302-5092
62	Gasket	23017225	5330-01-328-7635
63	Gasket	23045365	5330-01-341-6493
64	Gasket	23046658	5330-01-088-5980
65	Gasket	23501587	5330-01-058-0587
66	Gasket	23506157	5330-01-348-3331
67	Gasket	23515145	5330-01-390-9045
68	Gasket	23520287	5330-01-447-1706
69	Gasket	2-510-011-860	5330-01-145-4573
70	Gasket	3921989	5330-00-107-3925
71	Gasket	5100638	5330-01-058-0586
72	Gasket	5100860	5330-01-058-8267
73	Gasket	5101408	5330-01-133-0119
74	Gasket	5104081	5330-01-078-7186
75	Gasket	5104105	5330-01-163-8178
76	Gasket	5104507	5330-01-088-5984
77	Gasket	5104978	5330-01-163-8179
78	Gasket	5117231	5330-00-972-8108
79	Gasket	5117243	5330-00-735-4289
80	Gasket	5117254	5330-00-745-7831
81	Gasket	5117269	5330-00-735-4291
82	Gasket	5117332	5330-00-725-2301
83	Gasket	5117535	5330-00-844-2907
84	Gasket	5117734	5330-00-745-7776

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
85	Gasket	5117786	5330-00-781-7117
86	Gasket	5117993	5330-00-973-1415
87	Gasket	5120224	5330-00-862-6929
88	Gasket	5121714	5330-00-745-7669
89	Gasket	5121835	5330-00-847-4967
90	Gasket	5123240	5330-00-054-8290
91	Gasket	5123570	5330-00-915-2835
92	Gasket	5123638	5330-00-862-6934
93	Gasket	5123812	5330-00-892-1764
94	Gasket	5126160	5330-00-458-2325
95	Gasket	5126161	5330-00-458-2324
96	Gasket	5126499	5330-00-736-0228
97	Gasket	5130995	5330-00-980-1546
98	Gasket	5136678	5330-00-198-7953
99	Gasket	5138659	5330-00-769-4882
100	Gasket	23520012	5330-00-915-4511
101	Gasket	5144901	5330-01-054-2399
102	Gasket	5145581	5330-00-222-0801
103	Gasket	5148810	5330-01-058-0585
104	Gasket	5150193	5330-00-212-6290
105	Gasket	6750186	5330-00-537-2388
106	Gasket	6-794-000557	3040-01-199-7951
107	Gasket	6833980	5330-01-236-1753
108	Gasket	6839213	5330-01-049-0552
109	Gasket	6880389	5330-01-141-9579
110	Gasket	731740-002	5330-01-355-4809
111	Gasket	79031	5330-01-078-2825
112	Gasket	8921312	5330-01-206-3263
113	Gasket	8923492	5330-01-037-4129
114	Gasket	8923512	5330-01-206-3264
115	Gasket	8923791	5330-01-088-5982
116	Gasket	8923792	5330-01-206-3265
117	Gasket	8924266	5330-01-270-1161
118	Gasket	8924413	
119	Gasket	8925778	5330-01-247-2474
120	Gasket	8926782	5330-00-758-2863
121	Gasket	97706	5330-01-078-2826
122	Gasket	D346-177	5330-00-364-3550
123	Gasket, Compression	5100404	5330-01-054-2398
124	Gasket, Cylinder Block	297428	5330-01-346-1605
125	Gasket, Cylinder Cover	297429	5330-01-348-8352
126	Gasket, Cylinder Head	297427	5330-01-346-1604
127	Gasket, Manifold	243430	5330-00-262-3272

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
128	Gasket, Oil Pan	23013339	5330-01-363-8833
129	Gasket, Seal Strip	5183476	5330-00-171-8763
130	Hardware Kit, Electronic	5234934	2920-01-408-8145
131	Impeller	23505995	2930-01-354-4353
132	Insert, Liner	5148501	2815-01-058-0254
133	Inserts, Screw	5121459	5340-00-921-6413
134	Intermediate Steer Gear Repair Kit	5541261	5330-01-344-0581
135	Isolator	23512307	5340-01-414-2177
136	Isolators	5104515	5340-01-057-4230
137	Key	49749AX	5315-00-837-2919
138	Key	5131724	5315-00-089-8807
139	Key	6772552	5315-00-402-0421
140	Key	7-569-000030	5315-01-203-6490
141	Key	8-47-17-06-002	5315-01-280-7372
142	Key	8926247	5315-01-214-1876
143	Key	8928537	5315-01-260-4595
144	Key	8928545	5315-01-304-9174
145	Kit, Overhaul	23012606	2520-01-176-6004
146	Kit, Plug	3331322K	5365-01-394-5979
147	Kit, Repair	5199617	5330-01-056-1111
148	Kit, Repair	711917	5330-01-362-0907
149	Kit, Repair	7350-5	5330-01-352-8831
150	Kit, Repair	75251-01SK	5330-01-372-4652
151	Kit, Repair	75251-13SK	5330-01-373-2973
152	Kit, Repair	75252-08SK	5330-01-392-8534
152.1	Kit, Repair	9-752-101062	5330-01-398-8749
153	Kit, Repair	9-752-101064	5330-01-374-3260
154	Kit, Repair	9-752-101065	5330-01-372-4651
155	Kit, Repair	MS28775-008	5330-00-579-3158
156	Kit, Repair	SK-16-2	4820-01-233-3441
157	Kit, Repair	SKMEH-3	5330-01-372-5297
158	Kit, Repair	SKMEH-4	5330-01-372-5296
159	Kit, Seal Replacement	RPGC-QAN	5330-01-K63-2529
160	Kit, Wire Gate	K240111	
161	Lip Seal	2-283-001-378	5330-01-233-8692
162	Lock, Valve	5111337	2815-00-529-8193
163	Locknut	0223-01030-011	5310-01-395-6272
164	Locknut	103026	5310-00-011-7049
165	Locknut	110310A	5310-01-159-8178
166	Locknut	110311-A	5310-01-111-0645
167	Locknut	110312A	5310-01-150-5918
168	Locknut	111316A	5306-01-106-7496
169	Locknut	115307A	5310-01-151-1036

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
170	Locknut	11841	5310-01-151-5546
171	Locknut	1244954-2	5310-00-074-1387
172	Locknut	1333510	5310-01-340-5671
173	Locknut	1408910	5310-01-111-0645
174	Locknut	1571850	5310-01-288-5096
175	Locknut	1598030	5310-01-342-8595
176	Locknut	1600460	5310-01-346-9445
177	Locknut	1764650	5301-01-346-3692
178	Locknut	192481	5310-01-058-3353
179	Locknut	22NM04	5310-00-207-9341
180	Locknut	2560HX	5310-01-081-5351
181	Locknut	29749	5310-01-019-3129
182	Locknut	30191	5310-01-178-5976
183	Locknut	41NE120	5310-00-530-0239
184	Locknut	44NTE-1210	5310-01-346-3789
185	Locknut	5117972	5310-00-043-0427
186	Locknut	5149163	2835-01-015-5419
187	Locknut	5151601	5310-00-270-7111
188	Locknut	60861A	5310-01-061-5678
189	Locknut	6772182	5310-01-228-6394
190	Locknut	8925752	5310-01-268-6783
191	Locknut	9174746	5310-00-844-0127
192	Locknut	93604342	5310-01-081-5351
193	Locknut	9413533	5310-01-018-5266
194	Locknut	L-10-MNS-500-X-1	5310-01-345-2350
195	Locknut	MA219-21065	5310-01-328-9940
196	Locknut	MS51849-74	5305-00-470-3321
197	Locknut	MS35690-525	5310-00-012-0368
197.1	Locknut	MS51922-17	5310-00-087-4652
198	Locknut	MS51922-21	5310-00-959-1488
199	Locknut	MS51922-37	5310-00-067-9507
200	Locknut	MS51922-53	5310-00-225-6408
201	Locknut	MS51922-9	5310-00-984-3806
202	Locknut	MS51943-31	5310-00-061-4650
203	Locknut	MS51967-14	5310-00-768-0318
204	Locknut	MS51967-23	5310-00-763-8921
205	Locknut	MS51967-27	5310-00-880-8187
206	Locknut	N12	5310-00-185-6345
207	Locknut	N9091	5310-01-050-5005
208	Locknut	N9406	5310-01-362-6171
209	Locknut	N9410	5310-01-348-8398
210	Locknut	T893R	5310-01-288-1116
211	Locknut	TLA-10008-GRC	5310-01-080-9201

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
212	Locknut	TLA-1213-GRC	5310-01-081-8244
213	Locknut	TLA-3816-GRC	5310-01-222-9097
214	Locknut	TLNF-0832-S	5310-01-165-1312
215	Locknut	V75502830	5310-01-344-6738
216	Locknut	V75503336	5310-01-344-6740
217	Locknut	V75503716	5310-01-357-3768
218	Lockplate	57022	5340-01-127-5636
219	Lockscrew	190770	5305-00-019-0770
220	Lockscrew	5101196	5306-01-120-3659
221	Lockscrew	5148324	5306-01-083-9374
222	Lockscrew	9409047	5306-01-210-3836
223	Lockscrew	9409620	5306-01-336-9667
224	Lockscrew	9412014	5305-01-165-3295
225	Lockstrip	6880899	5340-01-056-0037
225.1	Lockwasher	0400139971	
226	Lockwasher	103321	5310-00-261-7340
227	Lockwasher	112264	5310-01-081-0799
228	Lockwasher	114021	5310-01-081-0798
229	Lockwasher	11500879	5305-01-320-2395
230	Lockwasher	11501719	5306-01-407-7190
231	Lockwasher	122078A	5310-01-344-5946
232	Lockwasher	1388	5310-01-162-5737
233	Lockwasher	1459-254	5310-00-171-1734
234	Lockwasher	1495-Z	5310-01-161-2527
235	Lockwasher	1498	5310-01-161-7311
236	Lockwasher	1813	5310-01-132-0955
237	Lockwasher	187130	5310-00-584-5272
238	Lockwasher	1937550	5310-01-355-8798
239	Lockwasher	2150HX1	5310-01-141-5565
240	Lockwasher	2152HX	5310-00-939-1060
241	Lockwasher	2250HX	
242	Lockwasher	2261H	5310-00-080-9786
243	Lockwasher	23016303	5310-01-081-0799
244	Lockwasher	237648	5310-00-085-3891
245	Lockwasher	237686	5310-00-465-5643
246	Lockwasher	2434	5310-00-775-5139
247	Lockwasher	2435	5310-00-045-3299
248	Lockwasher	2523	5310-00-775-5182
249	Lockwasher	318B	5310-01-061-5302
250	Lockwasher	3231	5310-00-032-1814
251	Lockwasher	351AX	5310-01-129-0450
252	Lockwasher	352A	5310-01-081-1283
253	Lockwasher	352AX	5310-01-081-1283

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
254	Lockwasher	353AX	5310-00-582-5965
255	Lockwasher	355AX	5310-01-133-2130
256	Lockwasher	371AX	5310-00-775-5139
257	Lockwasher	50001716	5310-01-372-6391
258	Lockwasher	5177769	5310-00-209-1543
259	Lockwasher	7520854	5310-00-264-1888
260	Lockwasher	777-A	5310-01-061-4481
261	Lockwasher	7-949-000235	5310-01-173-3637
262	Lockwasher	7-949-000527	5310-01-205-3471
263	Lockwasher	7-949-000534	5310-01-259-6358
264	Lockwasher	7-950-160050	5310-01-292-4150
265	Lockwasher	8926285	5310-01-233-1338
266	Lockwasher	93613642	5310-01-068-8446
267	Lockwasher	AE30574	5310-00-092-6831
268	Lockwasher	MS15795-19	5310-00-209-0693
269	Lockwasher	MS27183-12	5310-00-081-4219
270	Lockwasher	MS35333-105	5310-00-019-0669
271	Lockwasher	MS35335-31	5310-00-596-7693
272	Lockwasher	MS35335-62	5310-00-184-9562
273	Lockwasher	MS35338-100	5310-00-261-8278
274	Lockwasher	MS35338-101	5310-00-184-8970
275	Lockwasher	MS35338-103	5310-00-184-8971
276	Lockwasher	MS35338-105	5310-00-577-5354
277	Lockwasher	MS35338-138	5310-00-933-8120
278	Lockwasher	MS35338-15	5310-00-012-1326
279	Lockwasher	MS35338-41	5310-00-045-4007
280	Lockwasher	MS35338-42	5310-00-045-3299
281	Lockwasher	MS35338-43	5310-00-045-3296
282	Lockwasher	MS35338-44	5310-00-582-5965
283	Lockwasher	MS35338-45	5310-00-407-9566
284	Lockwasher	MS35338-46	5310-00-637-9541
285	Lockwasher	MS35338-47	5310-00-209-0965
286	Lockwasher	MS35338-48	5310-00-584-5272
287	Lockwasher	MS35338-49	5310-00-167-0680
288	Lockwasher	MS35338-50	5310-00-820-6653
289	Lockwasher	MS35338-51	5310-00-584-7888
290	Lockwasher	MS35338-6	5310-00-010-3319
291	Lockwasher	MS35338-7	5310-00-010-3320
292	Lockwasher	MS35338-8	5310-00-261-7340
293	Lockwasher	MS35340-45	5310-00-959-4679
294	Lockwasher	MS45904-60	5310-00-080-9786
295	Lockwasher	MS51848-7	5310-01-040-7762
296	Lockwasher	N9015	4310-01-046-0186

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
297	Lockwasher	N9018	5310-01-032-4827
298	Lockwasher	N9265	5310-01-136-4888
299	Lockwasher	N9461	5310-01-348-8392
300	Lockwasher	N9574	5310-01-439-0818
301	Lockwasher	V88350241	5310-01-346-0138
302	Lockwasher	V88412056	2835-01-355-1918
303	Lockwasher	W08	5310-01-355-8794
304	Lockwasher	W 12	5310-00-010-6265
304.1	Lockwasher	Z093078423	
304.2	Lockwasher	Z095002434	
305	Machine Gun Kit	1878620U	1005-01-363-2502
306	Mount, Resilient	5104515	5340-01-057-4230
307	Nut, Adjusting	V75502102	5310-01-344-6280
308	Nut, Adjusting	V88140038	5310-01-344-6279
309	Nut, Flange	298125	5310-01-346-3787
310	Nut, Flanged Wiz Lock	31 WLF 51618	5310-00-166-8341
311	Nut, Plain, Hex	V75700689	5310-01-345-3757
312	Nut, Push-On	390963	5310-01-143-0542
313	Nut, Spanner	V75503561	5310-01-344-6313
314	Nut, Spanner	V88350222	5310-01-345-5495
315	Nut, Spanner	V88900207	5310-01-344-6312
316	Nut, Spring Clip	7-659-000256	5310-01-271-3286
317	Ring Set, Piston	23524350	2815-01-058-2204
318	Packing, Preformed	001081	5330-01-086-1013
319	Packing, Preformed	001082	5330-01-085-3105
320	Packing, Preformed	001083	5330-01-086-6196
321	Packing, Preformed	00908-77-00-00	5330-01-361-1181
322	Packing, Preformed	1081	5330-00-408-9895
323	Packing, Preformed	1082	5330-01-352-3354
324	Packing, Preformed	1083	5330-01-157-3798
325	Packing, Preformed	11007B	5330-01-344-0539
326	Packing, Preformed	11350	5330-01-147-6003
327	Packing, Preformed	11-910	5330-01-106-4336
328	Packing, Preformed	1332	
329	Packing, Preformed	177969	5330-01-353-9388
330	Packing, Preformed	19265FX	5330-01-054-7297
331	Packing, Preformed	200-116-4490	5330-01-361-1505
332	Packing, Preformed	200-214-4490	5330-01-116-8112
333	Packing, Preformed	200-912-4490	5330-00-395-5737
334	Packing, Preformed	2-011N103-70	5330-00-419-0749
335	Packing, Preformed	2-011N507-90	5330-01-265-8308
336	Packing, Preformed	2-012N507-90	5330-01-092-5502
337	Packing, Preformed	2-014N103-70	5330-00-213-8722

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
338	Packing, Preformed	2-016N552-90	5330-01-115-8225
339	Packing, Preformed	2-018N507-90	5330-01-092-5503
340	Packing, Preformed	2-021N507-90	5330-01-109-1366
341	Packing, Preformed	2-029N507-90	5330-01-093-3503
342	Packing, Preformed	2-040N674-70	5330-00-137-3204
343	Packing, Preformed	2-112N507-90	5330-01-093-3504
344	Packing, Preformed	2-114N507-90	5330-01-288-4786
345	Packing, Preformed	22012-10	5330-00-966-8620
346	Packing, Preformed	22012-12	5330-00-966-8621
347	Packing, Preformed	22012-6	5330-00-200-8125
348	Packing, Preformed	22012-8	5330-00-996-8627
348.1	Packing, Preformed	22100070001	5331-01-475-3921
349	Packing, Preformed	2-219N674-70	5330-00-013-7784
350	Packing, Preformed	22617-10	5330-01-040-4772
351	Packing, Preformed	22617-12	5330-00-228-7196
352	Packing, Preformed	22617-16	5330-01-168-0885
353	Packing, Preformed	22617-20	5330-01-168-1802
354	Packing, Preformed	22617-6	5330-01-198-8439
355	Packing, Preformed	22617-8	5330-01-244-2273
356	Packing, Preformed	23017303	5330-01-334-9946
357	Packing, Preformed	23045075	5330-01-341-6763
358	Packing, Preformed	23503769	5365-01-286-3994
359	Packing, Preformed	23504352	5330-01-420-8670
360	Packing, Preformed	235063	5330-00-454-0370
360.1	Packing, Preformed	32075110	5331-01-475-3917
360.2	Packing, Preformed	32075111	5331-01-475-3907
361	Packing, Preformed	32185	5330-00-013-7784
362	Packing, Preformed	353264	5330-01-358-5432
363	Packing, Preformed	3-924N552-90	5330-01-038-3074
363.1	Packing, Preformed	405420	4730-01-351-7845
364	Packing, Preformed	405862	5330-00-490-1899
365	Packing, Preformed	5101138	5330-01-062-0942
366	Packing, Preformed	5101160	5330-01-058-0281
367	Packing, Preformed	5101198	5330-00-090-4638
368	Packing, Preformed	5101419	5330-01-164-0344
369	Packing, Preformed	6830007	5330-01-049-0547
370	Packing, Preformed	71040	5330-01-012-2722
371	Packing, Preformed	71041	5330-00-633-6827
372	Packing, Preformed	7-543-002870	4720-01-352-6004
373	Packing, Preformed	7-755-014003	5330-00-472-2783
374	Packing, Preformed	7-755-166003	5330-01-353-9544
375	Packing, Preformed	7-755-238003	5330-01-352-7742
376	Packing, Preformed	7-755-246003	5330-01-354-0235

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
377	Packing, Preformed	85318952	5330-01-155-4277
378	Packing, Preformed	8-74-80-09-059	5330-01-388-3727
379	Packing, Preformed	8923959	5330-00-166-1020
380	Packing, Preformed	8928676	5330-01-346-0846
381	Packing, Preformed	962	5330-00-056-4405
382	Packing, Preformed	9631	5330-00-232-0635
383	Packing, Preformed	A307777000-8	5330-00-920-4157
384	Packing, Preformed	FF446-25	5330-01-269-6152
385	Packing, Preformed	FF9446-12	5330-01-115-8226
386	Packing, Preformed	FF9446-14	5330-01-269-8580
387	Packing, Preformed	FF9446-18	5330-01-092-5503
388	Packing, Preformed	FF9446-21	5330-01-269-4323
389	Packing, Preformed	FF9855-12	5330-01-376-9629
390	Packing, Preformed	FF9855-16	5330-01-372-3867
391	Packing, Preformed	FF9855-18	5330-01-363-7073
392	Packing, Preformed	FF9855-21	5330-01-363-7074
393	Packing, Preformed	J200AS128	5330-00-111-3747
393.0.1	Packing, Preformed	M053225163	
393.1	Packing, Preformed	MS28775-013	5331-00-684-3420
394	Packing, Preformed	MS28775-026	5330-00-631-1342
395	Packing, Preformed	MS28775-121	5330-00-542-1398
396	Packing, Preformed	MS28778-16	5330-00-804-5694
397	Packing, Preformed	MS28778-20	5330-00-816-3546
398	Packing, Preformed	MS28778-4	5330-00-805-2966
399	Packing, Preformed	MS29512-16	5330-00-263-8054
400	Packing, Preformed	MS29561-14	5330-00-729-5254
401	Packing, Preformed	RK11341	5330-01-214-5090
402	Packing, Preformed	V75502787	5330-01-354-4160
402.1	Packing, Preformed	XA-2265	
403	Packing, Preformed	Z053071038	5330-00-633-6818
403.1	Packing, Preformed	Z053074979	
403.2	Packing, Preformed	Z053074980	
403.3	Packing, Preformed	Z053074981	
404	Packing, Preformed	Z053095777	5330-01-304-3453
405	Parts Kit, Air Flow	289352	2530-01-134-1834
406	Parts Kit, Gear Box	02-23-01251-022	5330-00-633-6188
407	Parts Kit, Hydraulic	23012606	2520-01-176-6004
408	Parts Kit, Seal	SK-10-2	5330-01-162-8277
409	Parts Kit, Seal	SK-10-3	2920-00-060-3411
410	Parts Kit, Seal	SK3-0002N-1	5330-01-357-7904
411	Parts Kit, Seal	SK3-10-3S	5330-01-358-3739
412	Parts Kit, Seal	SK3-16-3S	5330-01-358-3740
413	Pin	274889	5315-00-823-4333

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
414	Pin	5106909	5315-01-089-6864
415	Pin	5156295	5315-00-238-0843
416	Pin, Cotter	MS24665-134	5315-00-839-5820
417	Pin, Cotter	MS24665-283	5315-00-842-3044
418	Pin, Cotter	MS24665-287	5315-00-011-9120
419	Pin, Cotter	MS24665-291	5315-00-019-0777
420	Pin, Cotter	MS24665-353	5315-00-839-5822
421	Pin, Cotter	MS24665-360	5315-00-298-1499
422	Pin, Cotter	MS24665-624	5315-00-059-0217
423	Pin, Cotter	MS24665-625	5315-00-209-7273
424	Pin, Cotter	MS24665-627	5315-00-013-7308
425	Pin, Cotter	MS24665-752	5315-00-546-4297
426	Pin, Dowel	141346	5315-00-014-1346
427	Pin, Dowel	142522	5315-00-081-9924
428	Pin, Dowel	5103045	5315-01-137-3373
429	Pin, Dowel	5151576	5315-00-524-7660
430	Pin, Dowel	5175641	5315-00-829-0381
431	Pin, Lube Valve	6838442	5315-01-055-4411
432	Pin, Roll	WLM110004	5315-01-174-4642
433	Pin, Spring	6835729	5360-01-083-1433
434	Pin, Spring	7-690-081044	5315-01-382-8969
435	Plastic Bushing	45289-2	5365-01-163-8204
436	Plate	5103307	2815-01-058-3683
437	Plate, Separator	29501599	5365-01-342-8541
438	Plug	121-6T	5365-01-272-1481
439	Plug	8923313	4730-01-188-3492
440	Plug	8924749	4730-00-005-7376
441	Plug	8924750	4730-01-210-4251
442	Plug	8924751	4730-01-210-4253
443	Plug, Expansion	5139989	5340-00-255-4423
444	Plug, Lube Orifice	6883707	4730-01-127-6900
445	Plug, Nylon	715001A	5340-01-372-3982
446	Preformed Packing Kit	22617-12	5330-00-228-7196
447	Preformed Packing Kit	9S000104	5330-01-363-0667
448	Preformed Packing Kit	9S-000105	5330-01-393-5075
449	Preformed Packing Kit	9S000106	5330-01-372-8377
450	Preformed Packing Kit	FF9446-11	5330-01-214-4857
451	Preformed Packing Kit	SK2-10-2	5330-01-226-6810
452	Preformed Packing Kit	SK3-0017N-1	5330-01-357-7511
453	Preformed Packing Kit	SK3-0039N-1	5330-01-357-7510
454	Preformed Packing Kit	SK3-0024N-1	5330-01-357-7512
455	Preformed Packing Kit	SK3-0088N-1	5330-01-355-9248
456	Pump Assembly	V75503039	5365-01-345-1088

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
457	Push Clips	H360-4-2	5340-01-151-8391
458	Quickedge Molding	75000317	2510-01-176-1177
459	Repair Kit	60539	5330-01-302-2413
460	Repair Kit	711921	5330-01-393-4779
461	Repair Kit	711922	5330-01-354-4314
462	Repair Kit	9400	2530-01-344-5748
463	Repair Kit	9403	5330-01-344-2572
464	Repair Kit	9436	2520-01-344-9375
465	Repair Kit	9-752-100778	5330-01-353-9623
466	Repair Kit	9-752-100788	5330-01-352-6659
467	Repair Kit	9-752-100901	5330-01-353-9513
468	Repair Kit	9-752-100915	5330-01-354-3834
469	Repair Kit	9-752-101050	5330-01-353-9514
470	Retainer	1790632	2530-01-340-4080
471	Retainer	5149154	5365-01-015-5414
472	Retainer	MS28783-16	5330-00-171-5910
473	Retainer	MS28783-26	5330-00-944-9577
474	Retainer, Piston Pin	5180250	5340-00-792-9020
475	Retaining Ring	6758779	5365-00-852-2641
476	Ring Set	282525	2530-01-104-9031
477	Ring, Lock	14-00-139-040	5365-01-201-8981
478	Ring, Lock	5115572	5365-00-590-1739
479	Ring, Locking	2262131	5310-01-344-0559
480	Ring, Oil Collector	23011130	2520-01-145-0301
481	Ring, Piston	23524191	2815-01-337-3963
482	Ring, Piston	8923113	2815-01-321-2231
483	Ring, Piston	8923729	2815-01-247-7125
484	Ring, Piston	T-560-0330-001	3040-01-341-2340
485	Ring, Piston	T-561-0329-002	2815-01-345-1068
486	Ring, Retaining	001023	5365-01-087-8727
487	Ring, Retaining	1023	5365-01-157-3779
488	Ring, Retaining	14-00-139-033	5365-01-202-2587
489	Ring, Retaining	14-02-053-001	5365-01-205-9013
490	Ring, Retaining	23514733	
491	Ring, Retaining	329-1	5365-00-843-8601
492	Ring, Retaining	5198049	5365-00-930-3257
493	Ring, Retaining	MS16224-1087	5365-00-804-2025
494	Ring, Retaining	MS16624-1250	5365-00-806-2357
495	Ring, Retaining	MS16624-1315	5365-00-200-6684
496	Ring, Retaining	MS16625-1081	5365-00-804-9740
497	Ring, Retaining	MS16625-1200	5365-00-804-2784
498	Ring, Retaining	MS16625-1525	5365-00-504-3138
499	Ring, Retaining	V75501125	5365-01-344-8448

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
500	Ring, Retaining	V75503628	5365-01-345-2353
501	Ring, Retaining	V88150021	5360-01-345-2728
502	Ring, Retaining	V88510252	5330-01-354-4218
503	Ring, Retaining	V88510253	5330-01-345-0157
504	Ring, Retaining (Blue)	6882795	5365-01-083-1532
505	Ring, Retaining (Red)	6882797	5365-01-083-1533
506	Ring, Retaining (Yellow)	6882796	5365-01-083-1534
507	Ring, Seal	23019653	5330-01-338-6302
508	Ring, Seal	5103544	5330-01-088-6596
509	Ring, Seal	5197583	5330-00-930-3254
510	Ring, Seal	5198936	5365-01-016-0443
511	Ring, Seal, Cylinder Liner	8927189	5330-01-054-2267
512	Ring, Spindle	V88350243	5365-01-344-6016
513	Rod Bearing Set	23501025	3120-01-336-3064
514	Screw	115289A	5306-01-150-5884
515	Screw	1344950	5305-01-155-6107
516	Screw	1514640	5305-01-347-9802
517	Screw	1756870	5306-01-341-0712
518	Screw	186292	5306-00-849-8812
519	Screw	2009HX	5305-01-210-7413
520	Screw	2271280	
521	Screw	23045343	5306-01-245-9837
522	Screw	23512308	5306-01-411-6384
523	Screw	3829139	5306-00-024-6580
524	Screw	5103530	5306-01-084-4413
525	Screw	5103534	5306-01-078-4981
526	Screw	5103642	5305-01-078-1999
527	Screw	5121466	5306-00-894-2391
528	Screw	5148794	5305-01-058-5320
529	Screw	54067AX	5305-01-150-8714
530	Screw	7092	5305-00-335-4067
531	Screw	711053A	5305-01-355-2641
532	Screw	8-73-412	5306-01-336-8874
533	Screw	8920631	5306-01-169-5526
534	Screw	8923569	5305-01-192-2168
535	Screw	8923570	5306-01-208-7957
536	Screw	8923571	5306-01-128-3980
537	Screw	8925603	5306-01-297-6987
538	Screw	8927580	5306-01-193-9291
539	Screw	B1821BH038C400N	5305-00-781-3928
540	Screw	C95A37	5305-01-066-1825
541	Screw	CPR102737	5306-00-182-9230
542	Screw	MS35295-58	5305-01-056-5448

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
543	Screw	MS51095-416	5305-00-964-0589
544	Screw	MS90725-5	5305-00-068-0501
545	Screw	MS90725-60	5305-00-269-3211
546	Screw	MS90728-193	5305-00-947-4356
546.1	Screw	Z112007092	
547	Screw And Washer Assy	23018827	5305-01-341-8904
548	Screw, Cap W/Lockwasher	237757	5305-01-133-7193
549	Screw, Lock	5145092	5306-00-869-2868
550	Screw, Self-Locking	11504603	5305-01-336-6757
551	Screw, Self-Locking	23015458	5306-01-363-4057
552	Screw, Self-Locking	31 WLFS 51618-062	5306-01-350-8223
553	Screw, Self-Locking	378429-8	5306-01-145-6949
554	Screw, Self-Locking	9409010	5306-00-940-9010
555	Screw, Self-Locking	9409037	5305-00-292-4595
556	Screw, Self-Locking	MS35763-1033	5306-00-842-8223
557	Screw, Self-Tapping	1324510	5305-01-157-5624
558	Screw, Self-Tapping	1345280	5305-01-159-8544
559	Screw, Self-Tapping	1723180	5305-01-145-4003
560	Screw, Self-Tapping	58368AX	5305-01-167-0288
561	Screw, Self-Tapping	B71-10015-002	5305-01-352-2066
562	Screw, Tapping	234-94420-382	5305-01-351-8783
563	Seal	001332	5330-01-173-6825
564	Seal	23504641	5330-01-336-2997
565	Seal	23511486	5330-01-397-6491
565.1	Seal	251816010004	5340-01-474-7928
565.2	Seal	251816011300	5340-01-474-7934
565.3	Seal	251816991107	5340-01-474-8059
565.4	Seal	252044010012	5330-01-474-7061
566	Seal	3S9643-00	5330-00-246-6380
567	Seal	5102098	5330-01-058-5220
568	Seal	5103646	5330-01-088-2740
569	Seal	513439	5330-01-384-9330
570	Seal	5148502	5365-01-062-0943
571	Seal	589332	5330-01-372-5634
572	Seal	71246	5330-01-187-3640
573	Seal	80X100X10	5330-01-355-9269
574	Seal	8922140	5330-00-764-1659
575	Seal	NA1205A2315	5330-01-344-0635
576	Seal	NA1205W2259	5330-01-345-4712
577	Seal Kit	430457B	5330-01-394-3549
578	Seal Kit	9638	5330-01-344-2573
579	Seal Kit, Needle	23500533	5340-00-678-0944
580	Seal, Double Lipped, Teflon	3J3598	5330-01-162-8277

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
581	Seal, Oil	10124	5330-01-281-0907
582	Seal, Oil	13585	5330-00-202-1292
583	Seal, Oil	23016947	5330-01-245-0159
584	Seal, Oil	31333CRWH1	5330-01-204-5486
585	Seal, Oil	415023-SSR	5330-01-340-9882
586	Seal, Oil	415025-SSR	5330-01-340-9882
587	Seal, Oil	415304	5330-01-033-2697
588	Seal, Oil	5106223	5330-01-083-3980
589	Seal, Oil	5148502	5365-01-062-0943
590	Seal, Oil	5177786	5330-00-961-9801
591	Seal, Oil	6773311	5330-00-999-3752
592	Seal, Oil	8-74-21-25-017	5330-01-138-2629
593	Seal, Oil	8-74-21-25-021	5330-01-207-6676
594	Seal, Oil	8921150	5330-01-166-3618
595	Seal, Oil	8921209	5330-00-992-0695
596	Seal, Oil	9-734-100635	5330-01-208-7006
597	Seal, Oil	A11507	5330-00-846-8177
598	Seal, Oil	E75503729	5330-01-344-8263
598.1	Seal, Oil	M054097799	
599	Seal, Oil	V75503486	5330-01-344-8935
600	Seal, Oil	V75503596	5330-01-350-2906
601	Seal, Oil	V88350180	5330-01-344-0639
602	Seal, Oil, Rear	8929750	5330-01-324-0437
603	Seal, Plain	6836799	5330-01-145-0697
604	Seal, Plain, Encased	5177786	5330-00-961-9801
605	Seal, Ring	23011453	5330-01-088-5847
606	Seal, Ring	23011454	5365-01-084-5258
607	Seal, Ring	23011455	2520-01-149-3273
608	Seal, Ring	23014441	5330-01-087-6849
609	Seal, Ring	23014631	5935-01-342-3363
610	Seal, Ring	23019652	5330-01-054-2242
611	Seal, Ring	23045519	5330-01-280-7491
612	Seal, Ring	6758740	5330-00-582-0456
613	Seal, Ring	6770492	5330-00-999-3760
614	Seal, Ring	6833980	5330-01-236-1753
615	Seal, Ring	6836796	5330-01-336-6709
616	Seal, Ring	6836799	5330-01-145-0697
617	Seal, Ring	6836800	5330-01-336-2998
618	Seal, Ring	NA1205A2315	5330-01-344-0635
619	Seal, Ring	NA1205W2259	5330-01-345-4712
620	Seal, Valve	23045075	5330-01-341-6763
621	Seal, Water	23506248	5330-01-359-2143
622	Seal, Water	5148502	5365-01-062-0943

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
623	Sealing Kit (Inner)	V88510252	5330-01-354-4218
624	Sealing Kit (Outer)	V88510253	5330-01-345-0157
625	Setscrew	8927479	5305-01-297-7528
626	Setscrew	8927579	5305-01-336-5925
627	Setscrew Assy	35370-2	5305-01-167-0232
628	Shaft	23506053	3040-01-354-0406
629	Shim	4-195-9-00297	5365-01-354-0251
630	Shim	4-195-9-00298	5365-01-354-0252
631	Shim	4-195-9-00299	5365-01-354-0253
632	Shim	5183323	5365-00-377-2888
633	Shim	5185318	5365-00-377-2889
634	Shim	5185319	5365-00-377-2887
635	Shim Kit, Adjusting	V86010008	5365-01-344-6846
636	Shim Kit, Adjusting	V86010009	5365-01-344-6847
637	Shim Kit, Adjusting	V86010010	5365-01-344-4425
638	Shim Kit, Adjusting	V86010012	5365-01-344-6848
639	Shim Kit, Adjusting	V86010048	5310-01-345-2637
640	Shim Kit, Adjusting	V86010049	5365-01-350-3080
641	Shim Kit, Adjusting	V86010079	5365-01-345-2639
642	Shim Kit, Adjusting	V86010080	5365-01-345-3969
643	Shim Kit, Adjusting	V86010081	5365-01-345-3962
644	Shim Kit, Adjusting	V86020076	5365-01-345-0228
645	Shims	5100703	5365-01-082-1972
646	Skirt, Piston	23508986	2815-01-406-1952
647	Sleeve	V75503563	5365-01-344-4387
648	Snap Ring	8922605	5365-01-173-3437
649	Snap Ring	N1229N4408	5365-01-344-2598
650	Spacer	2262141	5310-01-344-0560
651	Spacer, Plate	59808BX	5365-01-156-0026
652	Spring	001288	5360-01-174-3821
653	Spring	007500	5360-01-145-7555
654	Spring	011434	5360-01-209-8802
655	Spring	12321866	5360-01-216-7059
656	Spring	3-4X1MD	5360-01-043-4761
657	Spring	5108918	5360-00-689-8264
658	Spring	5108919	2815-00-053-8992
659	Spring	5134477	5360-00-930-3264
660	Spring	5144857	
661	Spring	53733AX	5360-01-145-4724
662	Spring	54396AX	5360-01-086-1419
663	Spring	6768544	5360-00-679-7009
664	Spring	6831656	5360-00-211-9547
665	Spring	6880418	5360-01-035-9396

(1) Index No.	(2) Nomenclature	(3) Part Number	(4) National Stock Number
666	Spring	8923176	5360-01-206-3186
667	Spring	8927794	5360-01-336-9229
668	Spring Kit	23013754	5360-01-128-5646
669	Spring, Converter By-Pass	6834666	4820-01-082-9452
670	Spring, Lockup Shift Val	6839419	5360-01-144-6170
671	Spring, Lube Valve	6837882	5360-01-128-5645
672	Spring, Main Pressure Reg	6839209	5360-01-084-2394
673	Standard Piston Kit	282525	2530-01-104-9031
674	Standoff	23019304	3040-01-K62-9137
675	Strainer, Element	5126143	2940-00-745-7741
676	Stud	5130488	5307-01-044-7270
677	Stud	8925804	5307-00-550-1879
678	Thrust Washer, Oversize	5116485	5365-00-837-8352
679	Thrust Washer, Standard	5111424	3120-00-585-3282
680	Tube, Vent	6769580	4710-00-124-5737
681	U-Bolt	90359-A	4730-01-353-9723
682	U-Bolt	X125	5340-01-351-5690
683	Union, Bulkhead	1890800	4730-01-356-8646
684	Valve Guide	5149771	2815-01-062-0855
685	Valve Seat Insert	5148490	2815-01-055-7659
686	Valve, Lube	6837881	2520-01-051-6670
687	Valve, Seat	5148490	2815-01-055-7659
688	Washer	31425BX	2520-01-041-3542
689	Washer	40393AX	3120-01-146-9782
690	Washer	5104701	5330-00-599-0505
691	Washer	5125108	5310-00-785-3961
692	Washer	8925749	5365-01-239-9477
692.1	Washer, Fiber	Z082073500	3110-01-302-9300
693	Washer, Flat	5198988	5310-00-153-2717
694	Washer, Flat	60598	5310-00-663-7617
695	Washer, Seal	1760040	5310-01-353-2062
695.1	Washer, Seal	XA-1470	
696	Washer, Spring	M12133/1-12P	5310-01-038-2294
697	Washer, Thrust	5111424	3120-00-585-3282
698	Washer, Thrust	5117005	2815-00-735-4202
699	Washer, Thrust	6835321	3120-01-084-4607
700	Washer, Thrust	6881352	3120-01-056-2112
701	Washer, Thrust	6881638	3120-01-053-1819
702	Wear Pad	4-198-9-00020	2590-01-199-7975
703	Wear Pad	6-671-000306	2590-01-354-8240
704	Wear Pad	6-671-000308	2590-01-354-5443
705	Wear Pad	6-671-000362	2590-01-352-2339
706	Windshield Seal/Locking Strip	7500690	5330-01-178-7174

APPENDIX F

TOOL IDENTIFICATION LIST

Section I. INTRODUCTION

F-1. SCOPE.

This appendix lists all of the tools needed to repair the PLS.

F-2. GENERAL.

This appendix is a list of tools, both common and special, test equipment and tool kits used at Direct and General Support Maintenance level to repair the truck. This list is arranged alphabetically and shows the nomenclature, Part Number (P/N) and National Stock Number (NSN), when applicable. The index number corresponds to the index number found in the task box of maintenance procedures.

Section II. TOOLS, TEST EQUIPMENT AND TOOL KITS

Item No.	Description	Part No.	NSN	Reference
1	Adapter, Engine Stand	J33850	4910-00-146-9624	
2	Adapter Kit, Transfer Case	J-39911	4910-01-385-6779	
3	Adapter, Maintenance Stand, Differential	J-39929-A	4910-01-384-6264	
4	Adapter, Mechanical Puller	J7932	5120-00-733-8890	
5	Adapter, Press	206457	5120-01-357-0740	
6	Adapter, Radiator	J-29003-A	4910-01-170-4929	
7	Adapter, Slip Test	J33765	5935-01-297-2481	
8	Adapter, Socket (3/4 in. male to 1/2 in. female)	11655788-3	5120-00-144-5207	SC 4910-95-A31
9	Adapter, Socket (3/4 in. female to 1/2 in. male)	97-3725	5120-00-227-8088	
10	Adapter, Socket (3/4 in. female to 1 in. male)	A-A-2172	5120-00-227-8104	
11	Adapter, Socket (3/8 in. female to 1/4 in. male)	A-6	5120-00-227-8095	SC 4940-95-B20-HR
12	Alignment Tool, Blower	J33001	5120-01-158-3991	
13	Alignment Tool, Clutch	J-24221	5120-01-115-1156	
14	Alignment Tool, Pin	J24285	5120-01-232-0007	
15	Analyzer Set, STE/ICE-R	12259266	4910-01-222-6589	
16	Attachment, Ball, Micro	J4757	5210-00-221-1921	
17	Bit Set, Screwdriver	38699-1	5120-01-170-4454	SC 4910-95-A72-HR
18	Blade Kit, Hole Saw	GGG-S-66	3455-00-684-3918	

Section II. TOOLS, TEST EQUIPMENT AND TOOL KITS (CONT)

Item No.	Description	Part No.	NSN	Reference
19	Box, Chalk, Reel and Line	GGG-C-291	5210-00-273-9793	
20	Bracket, Lifting	J-24196	5120-01-115-1157	
21	Bracket, Lifting	J24408-A	5306-01-338-6292	
22	Bracket, Mounting, Cylinder Liner	J24565-02	5340-01-158-3984	
23	Brush, Wire, Scratch	HB178	7920-00-291-5815	SC 4910-95-31
24	Brush, Wire, Valve Cylinder	J5437	5120-00-766-2141	
25	Caliper, Dial, 0-6 in. w/Dial	599-579-2	5210-01-010-4522	SC 3470-95-A02
26	Cap and Plug Set	10935405	5340-00-450-5718	
27	Caps, Vise Jaw	GGG-C-137	5120-00-246-4747	
28	Cartridge, ATEC	J38500-303	4940-01-367-6194	
29	Cartridge, DDEC	J38500-750	4940-01-367-4657	
29.1	Cartridge DDEC III/IV	J38500-1500	7025-01-482-8761	
30	Charging Kit, Pressure	12252157	4910-01-046-7109	
31	Clamp	42052	5340-01-084-4459	
32	Clamp, Machinist's	GGG-C-406	5120-00-222-1612	SC 4910-95-A72-HR
33	Clamp Plate	206459	5120-01-357-0741	
34	Collector Ring Installer and Staking Set	J24200	5120-01-048-3124	
35	Compressor Unit, Air	MIL-C-13874	4130-00-752-9633	
36	Compressor, Ring	J24204-1	5120-01-048-3130	
37	Compressor, Ring	J24227	4910-01-158-3974	
38	Compressor, Ring, Piston	RC40C	5120-00-250-6055	
39	Compressor, Spring	J24204-3	5120-01-048-2159	
40	Compressor, Spring	J24219	5120-01-048-2160	
41	Compressor, Spring, Valve	J7455-A	5120-01-297-2347	
42	Connector Remover	J38384	5120-01-355-3012	
43	Crowbar	1051985	5120-00-224-1390	SC 4910-95-A31
44	DDEC Repair Kit	J35888	2815-01-355-5993	
45	Detector, Leak, Vacuum Gage	J-23987-B	6685-01-061-4253	
46	Die Set, Metal Stamping	GGG-D-280	5110-00-289-0004	SC 4910-95-A31
47	Drill Machine, Upright	MIL-D-80038	3413-00-165-4117	
48	Drill Set, Twist	GGG-D-751	5133-00-449-6775	SC 3470-95-A02
49	Drill, Electric, Portable, 1/4 in.	1070	5130-00-889-8993	SC 4910-95-A31
50	Driver	2HS115	5120-01-374-6200	
51	Driver Bearing, Gear	J25257	5120-01-033-8902	

Section II. TOOLS, TEST EQUIPMENT AND TOOL KITS (CONT)

Item No.	Description	Part No.	NSN	Reference
52	Driver, CTIS Seal	J41112	5120-01-355-0857	
53	Driver, CTIS Seal	J41113	5120-01-355-0858	
54	Expander, Seal, Oil	J4239	5120-00-336-0445	
55	Expander, Seal, Oil	J8682	5120-01-232-0005	
56	Extractor, Inertial	2HE226	5120-01-355-3010	
57	Extractor, Inertial	2HE227	5120-01-354-9543	
58	Eyes, Lifting	3016T39	5306-01-197-6569	
59	Eyes, Lifting	8891T82	5306-01-333-5486	
60	Eyes, Lifting	3016T65	5306-01-239-5053	
60.1	Fault Code Retrieval Device (FCRD)	CA1 05 020		
61	Fixture, Holding	J-24310	5120-01-115-1165	
62	Fixture, Lifting, Cylinder Head	J22062-01	4910-00-456-7620	
63	Fixture, PTO, Gear	J26899	4910-01-158-3969	
64	Fixture, Test, Head	J28454	4910-01-158-3985	
65	Gage Set, Cylinder Compression	J7334-E	4910-01-148-1236	
66	Gage Set, Feeler	FB310B	5210-01-119-7601	
67	Gage Set, Feeler	J 1698-02	5210-01-245-9564	
68	Gage Set, Feeler, Piston	J5438-01	5210-00-116-1631	
69	Gage Set, Telescoping	599-590	5210-00-473-9350	SC 4910-95-A63
70	Gage, Center And Front	J-29198-3	5210-01-133-6888	
71	Gage, Depth	J-22273-01	5210-00-023-4798	
72	Gage, Depth, Cylinder Liner	J24898	5210-01-174-4498	
73	Gage, Depth, Micrometer	GGG-C-105	5210-00-619-4045	SC 3470-95-A02
74	Gage, Dial	J-8165-2	4910-00-779-7103	
75	Gage, Dial, Bore, Cylinder	J5347-B	5210-01-070-4543	
76	Gage, Feeler	J3174-02	5210-00-671-2275	
77	Gage, Feeler	J9708-15	5210-01-156-7302	
78	Gage, Feeler, Jacobs Brake	007958	5210-01-214-2938	
79	Gage, Piston, Groove	J24599	5220-01-028-1109	
80	Gage, Timing, Injector	J25502	5220-01-348-1638	
81	Gloves, Chemical Oil Protective	ZZ-G-381	8415-00-641-4601	
82	Gloves, Heavy Duty	A-A-50022	8415-00-268-7859	SC 4910-95-A31
83	Goggles, Industrial	GGG-G-513	4240-00-269-7912	SC 4910-95-A31
84	Grinding Kit, Valve Seat	1750	4910-00-473-6437	SC 4910-95-A63

Section II. TOOLS, TEST EQUIPMENT AND TOOL KITS (CONT)

Item No.	Description	Part No.	NSN	Reference
85	Grinding Machine, Valve Face	00G686	4910-00-540-4679	SC 4910-95-A63
86	Gun, Airblow	GGG-G-770	4940-00-333-5541	SC 4910-95-A31
87	Gun, Heat	500	4940-00-561-1002	SC 4910-95-A31
88	Hammer, Hand, Soft Plastic	3-HD	5120-01-065-9037	SC 4910-95-A72-HR
89	Hammer, Slide	J6125-1B	5120-01-112-2165	
90	Handle, Driver	J8092	5120-00-677-2259	
91	Handle, Driver	J-3154-1	5120-00-808-5082	
92	Handle, Driver	J24202-4	5120-01-054-4048	
93	Handle, Installer	J7079-2	5120-00-977-5578	
94	Harness, Breakout	J34517	6150-01-373-7771	
95	Holder, Stator Roller	J24218-2	5120-01-115-1158	
96	Honing Unit, Cylindrical Bore, Portable	J5902-01	5130-00-629-9782	
97	Indicator, Dial, Set	J5959-01	5120-00-794-9178	SC 4910-95-A31
98	Indicator, Dial, Set w/Magnetic Base	J7872	5120-00-402-9619	
99	Indicator, Dial, Timing Tool	J34930A	2815-01-355-6628	
100	Insertor and Remover, Charge Pump	J33080	5120-01-166-0572	
101	Insertor, Bearing And Bushing	J25562	5120-01-158-3946	
102	Insertor, Center Bushing, Front	302031	5120-01-186-3126	
103	Insertor, Plug, Cylinder Block	J-21850	5120-01-166-5419	
104	Insertor, Seal	J35373	5120-01-340-1820	
105	Installation Tool, Cup Plug	J33420	5120-01-297-2457	
106	Installer and Remover	J25275	5120-01-048-2180	
107	Installer, Bearing	J-24197	5120-01-115-1160	
108	Installer, Guide, Valve	J-21520	5120-00-999-8617	
109	Installer, Lock Ring	J24453	5120-01-054-4050	
110	Installer, Oil Seal, Sleeve	J21983	5120-01-227-8483	
111	Installer, Output Shaft Seal	J-24202-1A	5120-01-054-4042	
112	Installer, Plug	J-24411	5120-01-385-7288	
113	Installer, Plug	J24369	5120-01-054-4053	
114	Installer, Seal, Crankshaft, Front	J9783	5120-00-936-4377	
115	Installer, Seal	J9791	5120-01-013-1678	
116	Installer, Seal	J8550	5120-00-977-5579	
117	Installer, Seal	J24198	5120-01-054-4049	

Section II. TOOLS, TEST EQUIPMENT AND TOOL KITS (CONT)

Item No.	Description	Part No.	NSN	Reference
118	Installer, Seal, Oil	J8501	5120-00-937-7267	
119	Installer, Seal, Transfer Case	6227 TRS	5120-01-383-7878	
120	Installer, Sleeve	J21983	5120-01-227-8483	
121	Installer, Valve Bridge	J7482	5120-00-999-8616	
122	Installer, Water Pump Seal	J-38858	5120-01-365-4079	
123	Installer Tool, Center Bushing, Rear	302026	4910-01-158-3941	
124	Installing Tool, Piston	J-23762-A	5120-00-127-7757	
125	Installing Tool, Valve	J24357	5120-01-048-3118	
126	Installing/Removing Tool	J-23019	5120-01-130-8864	
127	Jack, Dolly Type	93660	4910-00-289-7233	SC 4910-95-A31
128	Jack, Hydraulic, Hand	5029209-111-101	5120-00-188-1790	SC 4910-95-A31
129	Jack, Kit, Hydraulic, Hand	GGG-J-60	5120-00-595-8387	SC 4910-95-A31
130	Jack, Stabilizer	LO-J		
131	Jack, Transmission	49	4910-00-585-3622	SC 4910-95-A62
132	Jackstand	306	4910-00-251-8013	SC 4910-95-A74
133	Lathe, Brake Drum	4100	4910-01-028-9849	SC 4910-95-A31
134	Level	2579573-002	4920-00-064-8974	
135	Lifting, Bracket, Center	J-24195	5120-01-116-6048	
136	Lifting, Bracket, Flywheel	J-24365	5120-01-116-6049	
137	Lifting, Fixture, Clutch	J-24209	5120-01-115-1159	
138	Mag Ins Unit, Stat	MIL-M-6867C	6635-00-566-9772	
139	Micrometer, Outside, Caliper, Set	GGG-C-105	5210-00-554-7134	SC 3470-95-A02
140	Multimeter	ANURM105C	6625-00-999-6282	SC 4910-95-A31
141	Multiplier, Torque	292	5120-00-574-9318	SC 4910-95-A72-HR
142	OSS Tester	13189	4910-00-370-4908	
143	Oil, Seal, Expander	J8682	5120-01-232-0005	
144	Pan, Drain 4 gal	450	4910-00-387-9592	SC 4910-95-A31
145	Pan, Drain 6 gal	MIL-P-45819	4910-00-287-2944	
146	Pin, Guide	J1126	5315-01-165-1469	
147	Pin, Guide Set	J24315	5315-01-141-9458	
148	Plate Kit, Gear Bearing	2SK900	5180-01-167-4285	
149	Plate, Adapter, Transfer Case	TRS4114	5340-01-372-6413	
150	Pliers, Brake Repair	131A	5120-00-690-8044	SC 4910-95-A31
151	Pliers, Channel Lock	GGG-W-649	5120-00-287-2512	

Section II. TOOLS, TEST EQUIPMENT AND TOOL KITS (CONT)

Item No.	Description	Part No.	NSN	Reference
152	Pliers, Retaining Ring	2BH945	5120-01-375-5699	
153	Pliers, Retaining Ring	0200	5120-00-288-9717	SC 4910-95-A31
154	Pliers, Retaining Ring	0500	5120-00-293-0046	SC 4910-95-A31
155	Pliers, Retaining Ring	0100	5120-00-293-0048	SC 4910-95-A31
156	Pliers, Retaining Ring	0400	5120-00-293-0049	SC 4910-95-A31
157	Pliers, Retaining Ring	0900	5120-00-293-0186	SC 4910-95-A31
158	Pliers, Retaining Ring	407	5120-00-595-9551	SC 4910-95-A31
159	Pliers, Retaining Ring	S6800	5120-00-595-9552	SC 4910-95-A31
160	Plug, Cylinder Block	J24597	5120-01-166-5421	
161	Plumb Bob	GGG-P-501	5210-00-007-8229	
162	Press, Arbor, Hand Operated	MIL-P-80261	3444-00-163-4338	SC 4910-95-A31
163	Press Plate	51100	5120-01-357-0743	
164	Press, 60 Ton	26A49	3444-00-449-7295	SC 4910-95-A31
165	Pressure Test Kit	3SK912	4910-01-378-8863	
166	Pressure Test Kit	3SK911	4910-01-378-9068	
167	Protector, Piston	J24210	5120-01-048-2156	
168	Protector, Seal	J24216-01	5120-01-048-2157	
169	Protector, Spindle	2HE234	3830-01-349-7390	
170	Protractor, Magnetic	2150A251	5210-01-415-0075	
171	Protractor, Square	05-12INCH	5210-00-273-1937	
172	Puller, Bolts	J26901-A	5210-01-185-6811	
173	Puller, Mechanical	J1902-B	5120-00-219-8397	
174	Puller Kit, Universal	1677	5180-00-423-1596	SC 4910-95-A31
175	Puller Kit, Universal, Slide Hammer	1178	5120-00-313-9496	SC 4910-95-A74
176	Pulley Kit, Pump, Roof Mount	2HP645	5120-01-375-5700	
177	Pulley Remover	J5356	5120-00-944-0363	
178	Pump, Force	466-46483	4130-01-192-0496	
179	Punch, Drift	PWA14920	5120-00-004-4921	
180	Reader, Diagnostic	J 38500-1	4910-01-343-3508	
181	Reamer Set, Hand	GGG-R-180	5110-00-357-6858	SC 3470-95-A02
182	Reconditioning Set, Injector Tube	J-22525-B	5180-00-019-4208	
183	Remover and Installer, Piston Ring	7950177	5120-00-494-1846	
184	Remover Assembly	J24563-A	4910-01-158-3982	
185	Remover Set, Valve Bridge	J7091-01	5120-00-999-8614	

Section II. TOOLS, TEST EQUIPMENT AND TOOL KITS (CONT)

Item No.	Description	Part No.	NSN	Reference
186	Remover, Bearing, Front Support	J28557	5120-01-117-2523	
187	Remover, Bushing, Beam End	302030	5120-01-186-3125	
188	Remover, Center Bushing, Front	302032	5120-01-374-8970	
189	Remover, Center Bushing, Rear	302027	5120-01-357-0742	
190	Remover, Guide, Valve	J6569	5120-00-733-8880	
191	Remover, Snap Ring	J26598-A	4910-01-158-3996	
192	Remover, Valve Bridge	J7453	5120-00-999-8615	
193	Remover, Valve Pin	J-24412-2	5120-01-048-3128	
194	Remover, Valve Seat	J23479-E	5120-01-165-1935	
195	Respirator, Air Filter	GGG-M-125/6	4240-00-022-2524	SC 4910-95-A31
196	Rivet Gun	352	5130-00-982-8078	
197	Rule, Steel, Machinist	GGG-R-791	5210-00-204-1283	
198	Sander, Portable, Disk Electric	OOS90	5130-00-596-9728	SC4910-95-A31
199	Scale, Tension	J-8129	4910-00-779-6832	
200	Screw, Guide	J-1927-01	5120-01-144-4483	
201	Seal Installer, Flywheel	J21112-B	4910-01-176-4230	
202	Sleeve, Puller	J25007-4	4910-01-162-3633	
202.1	Smart Card	J38500-2300	7025-01-482-8800	
203	Snap Ring Assembly	J-24208-D	5120-01-116-5016	
204	Socket Set, 3/8 in.	221FSMY	5120-01-117-3876	SC 4910-94-A72-HR
205	Socket Set, Deep Well, 1/2 in.	GGG-W-641	5120-00-596-8622	SC 4910-95-A72-HR
206	Socket, Socket Head Screw, 12 mm	SAM12A	5120-01-104-5346	SC 4910-95-A31
207	Socket, Socket Head Screw, 14 mm	SAM14A	5120-01-079-8033	SC 4910-95-A31
208	Socket, Socket Head Screw, 3/4 in.	LAW124A	4470-01-350-0895	
209	Socket, Socket Head Screw, 1/8 in., 3/8 in. Drive	FA4A	5120-00-516-4979	
210	Socket, Socket Head Screw, 3/16 in., 3/8 in. Drive	4080-12	5120-00-683-8597	SC 4910-95-A31
211	Socket, Socket Head Screw, 5/16 in., 1/2 in. Drive	SA10A	5120-01-022-9505	
212	Socket, Socket Head Screw, 9/16 in., 1/2 in. Drive	SA18A	5120-01-367-3466	
213	Socket, Socket Head Screw, 5/8 in., 3/4 in. Drive	LAW120A	5120-00-601-6934	

Section II. TOOLS, TEST EQUIPMENT AND TOOL KITS (CONT)

Item No.	Description	Part No.	NSN	Reference
214	Socket, Socket Head Screw, 3/8 in., 1/2 in. Drive	SA12A	5120-00-585-6237	
215	Socket, 12 mm Hex Head	849550-3-8AF	5120-00-240-6148	
216	Socket, 1-11/16 in.	GGG-W-641	5120-01-024-0168	
217	Socket, 55 mm	J39938	5120-01-386-5999	
218	Socket, 63 mm	J39939	5120-01-386-5988	
219	Socket, Spindle Nut	J41111	5120-01-354-9451	
220	Socket, Swivel 13/16 in.	A-A-1396	5120-00-236-7619	
221	Socket, Wrench Attachment, Screwdriver	J34650	5120-01-297-2374	
222	Spanner	2HE229	5120-01-354-9452	
223	Spanner	2HE230	5120-01-354-9450	
224	Spanner	2HE231	5120-01-354-9449	
225	Stand, Maintenance, Axle	150-AX	4910-00-241-3329	
226	Stand, Maintenance, Engine	J29109	4910-00-808-3372	
227	Steam Cleaner	PRO 12-5	7910-01-157-8272	
228	Stone, Abrasive, Cylinder	J5902-14	5130-00-937-7280	
229	Stone, Sharpening	A6F0	5345-00-584-4607	
230	Straight Edge	11-1480	4920-00-442-1030	SC 3470-95-A02
231	Stud Remover and Setter	GGG-S-775	5120-00-596-0980	SC 4910-95-A31
232	Stud Set	J25002	5120-01-048-2155	
233	Studs, Guide	J-24748	5315-01-162-3630	
234	Tap and Die Set	TDM99117	5136-01-119-0005	
235	Tape, Measuring	D-1420-A	5210-00-234-6745	SC 4910-95-A31
236	Tension Gage, Belt	J-23600-B	6635-01-093-3710	
237	Tester, Pressure, Radiator	J24460-01	4910-01-170-4928	
238	Testing Kit, Cylinder Block	2SK737	5180-01-252-9800	
238.1	Tool Kit, Blind Rivet	D-100-MIL-1	5180-01-201-4978	SC 4910-95-A74
239	Tool Kit, Electric	7550526	5180-00-876-9336	SC 4910-95-A01
240	Tool Kit, General Mechanic's	SC5180-90-CL-N05	5180-00-699-5273	
241	Tool Kit, General Mechanic's: Automotive	SC5180-90-N26	5180-00-177-7033	
242	Tool Set, Blower	J-6270-G	4940-00-611-7945	
243	Tool, Knuckle, Adjusting	J41115	5120-01-355-6571	
244	Tool, Lifting	J33079	5120-01-159-1736	
245	Tool, Staking	J24200-1	5120-01-359-2757	

Section II. TOOLS, TEST EQUIPMENT AND TOOL KITS (CONT)

Item No.	Description	Part No.	NSN	Reference
246	Tool, Timing, SRS/TRS	J39815	5120-01-343-1001	
247	Torch, Propane	737-1-0000	3433-01-161-4998	
248	Vise, Machinist's	504M2	5120-00-293-1439	SC 4910-95-A31
249	Vise, Pipe, Chain	CV12	5120-00-078-6662	
250	Weatherpac Crimper	J38852	5120-00-374-8936	
251	Welder, Arc	MIL-W-4125	3433-00-357-6311	SC 3433-90-N01-HR
252	Winch, Cable, Hand Operating	415526-1	3950-00-079-1202	
253	Wrench, Chain	CW24	5120-01-192-9403	
254	Wrench, Combination 1-1/16 in.	1234	5120-00-228-9515	SC 4910-95-A74
255	Wrench, Combination 1-1/8 in.	1172	5210-00-228-9516	SC 4910-95-A74
256	Wrench, Combination 1-1/4 in.	1173	5120-00-228-9517	SC 4910-95-A74
257	Wrench, Combination 1-5/16 in.	1174	5120-00-228-9518	SC 4910-95-A74
258	Wrench, Combination 1-3/8 in.	1175	5120-00-277-8833	SC 4910-95-A74
259	Wrench, Combination 1-7/16 in.	1176	5120-00-228-9519	SC 4910-95-A74
260	Wrench, Combination 1-1/2 in.	1178	5120-00-277-8834	SC 4910-95-A74
261	Wrench, Combination 1-5/8 in.	1180	5120-01-016-7144	
262	Wrench, Combination 1-11/16 in.	A-A-1351	5120-00-184-8566	
263	Wrench, Combination 1-3/4 in.	1256	5120-00-020-8658	
264	Wrench, Combination 1-13/16 in.	GGG-W-636TY4	5120-00-081-9099	
265	Wrench, Combination 1-7/8 in.	1260	5120-00-020-8632	
266	Wrench, Combination 2-1/8 in.	1268	5120-00-203-4795	
267	Wrench, Crowfoot, 7/8 in., 3/8 in. Drive	FC28A	5120-00-541-4071	
268	Wrench, Crowfoot, 3/4 in., 3/8 in. Drive	FC024	5120-00-187-7898	SC 4910-95-A31
269	Wrench, Crowfoot, 9/16 in., 3/8 in. Drive	GGG-W-646	5120-00-222-7975	SC 4910-95-A31
270	Wrench, Fuel Line	J-8932-B	5120-00-019-5232	
271	Wrench, Pipe 3-1/2 in. Opening	GGG-W-651	5120-00-277-1485	SC 4910-95-A31
272	Wrench Set, Pushrod	J21100-D	5120-00-132-2109	
273	Wrench Set, Socket 3/8 in. Drive	51200017510	5120-00-322-6231	SC 4910-95-A31
274	Wrench Set, Socket 3/4 in. Drive	FEDSTD353	5120-00-204-1999	SC 4910-95-A31
275	Wrench, Spanner	J41108	5120-01-375-4502	
276	Wrench, Torque (0-60 N·m)	TESI60	5120-01-112-9531	SC 4910-95-A31
277	Wrench, Torque (0-175 lb-ft [0-237 N·m])	A-A-2411	5120-00-640-6364	SC 4910-95-A31

Section II. TOOLS, TEST EQUIPMENT AND TOOL KITS (CONT)

Item No.	Description	Part No.	NSN	Reference
278	Wrench, Torque (0-600 lb-ft [0-814 N·m])	SW130-301	5120-00-221-7983	SC 4910-95-A31
279	Wrench, Torque Driver	TQSC6A	5120-01-112-9532	SC 4910-95-A72-HR
280	Zonal Separator, Oil and Water Spray Gun	MIL-S-12928CLASS1	4940-00-242-4100	SC 4910-95-A73

INDEX

Subject, Para

Subject, Para

A

Accumulator Service, 16-22
 Adapter Housing, First Clutch Repair, 23-19
 Adjustments, Engine 3-2
 Aftercooler
 Inspection, 20-56
 Installation, 20-86
 Removal, 20-21
 Replacement, 5-5
 Air
 Bags Replacement, No. 3 Axle, 14-4
 Box
 Drain
 Installation, 20-89
 Removal, 20-18
 Replacement, 3-16
 Cover and Gasket Replacement, 3-15
 Covers
 Installation, 20-90
 Removal, 20-17
 Brake Chamber Replacement
 No. 1 and 2 Axle, 26-4
 No. 3 and 4 Axle, 25-18
 No. 5 Axle, 26-5
 Compressor
 Repair, 26-2
 Replacement, 10-4
 Dryer Guard Installation, 18-7
 Horn Kit Installation, 18-8
 Inlet Housing
 Installation, 20-103
 Replacement, 4-3
 Inlet Housing Turbocharger, Removal, 20-5
 Line Replacement, Dressed Axle, 25-30
 Suspension Beam Assembly, Repair, No. 3 Axle, 14-6
 Suspension Beam Mount Replacement/Adjustment,
 No. 3 Axle, 14-7
 System, 1-13
 System Troubleshooting Procedures, 2-13
 Air-Ride Seat and Seatbelt (Four Point) Kit
 Installation, 18-16
 Alternator
 Assembly
 Repair, 145 Amp, 6-2
 Repair, 200 Amp, 6-3

A (Cont)

Kit (200 Amp.) and Battery Disconnect Switch Kit
 Installation, 18-3
 Arctic Heater (Model B) Troubleshooting, 2-17.1
 Arctic Kit (Model A), Engine, Installation, 18-2
 ATEC Wire Harness Replacement, 6-26
 Auxiliary Fuel Tank Installation, 18-6
 Axle Assembly
 No. 1, Replacement, 9-3
 No. 2, Replacement, 9-4
 No. 3, Replacement, 9-11
 No. 4, Replacement, 9-12
 No. 5, Replacement, 9-13
 Axle
 Brake Assembly Replacement, 10-2
 On Stand Removal/Installation, 26-2
 Shaft, No. 3 and 4, Replacement, 9-5

B

Base Mount Replacement, SRW, 28-14
 Deleted.
 Battery Disconnect Wire Harness Replacement
 (200 Amp with Battery Disconnect Switch), 6-41
 Bearing
 Main, and Crankshaft Installation, 20-65
 Main, and Crankshaft Repair, 20-63
 Block Plate
 Front Cylinder, Installation, 20-71
 Rear Cylinder, Installation, 20-72
 Blower
 Assembly
 Installation, 20-95
 Removal, 20-13
 Repair, 21-2
 Replacement, 4-4
 By-Pass Valve Replacement, 4-7
 Oil Supply Tube Assembly Repair, 4-5
 Blower Drive Assembly
 Installation, 20-87
 Removal, 20-20
 Replacement, 4-6
 Repair, 20-55
 Boom Assembly Repair, 16-3
 Boom Cable and Chain Adjustment, 16-4

INDEX (CONT).

Subject, Para

Subject, Para

B (Cont)

C (Cont)

Brake Assembly
 Axle, Replacement, 10-2
 Replacement No. 1, 2 and 5 Axle, 26-8
 Replacement No. 3 and 4 Axle, 25-21
 Brake Drum
 Inspection/Repair, 11-3
 Replacement
 No. 1, 2, 5 Axle, 26-3
 No. 3 and 4 Axle, 25-17
 Brake Retarder, Engine
 Removal, 20-14
 Replacement, 3-32
 Brake, Swing Drive
 Repair, 28-10
 Replacement, 16-21
 Brake, Treadle Valve, Repair, 10-3
 Brake, Winch, SRW, Repair, 28-13
 Breather and Hoses, Engine Oil, Replacement, 3-23
 By-Pass Valve, Blower, Replacement, 4-7

Central Tire Inflation System (CTIS), 1-20
 Chassis Wire Harness Replacement, 6-29
 Chemical Alarm Kit Installation, 19-3
 Common Tools and Equipment, 2-1
 Compression Frame Repair, 16-42
 Connecting Rod and Piston Repair, 20-60
 Connecting Rod and Liner, Piston
 Installation, 20-67
 Removal, 20-40
 Constant Velocity Joint Repair, No. 1, 2 and 5
 Axle, 9-8, 26-13
 Container Handling Unit (CHU)
 Kit Installation, 18-13
 Lifting Frame Lower Container Lock Handle Repair,
 16-46
 Pivot Repair, 16-44
 Rail Transport ISO Corner Locks Repair, 16-47
 Slider Arm Bushing Replacement, 16-45
 Container, Shipping
 Engine Assembly Replacement, 3-33
 Transfer Case Assembly Replacement, 8-6
 Transmission Assembly Replacement, 7-11
 Control Valve
 Assembly, Repair, 23-9
 Bank Mount, Four/Three Function, Replacement,
 16-29
 Bank Repair
 Four Function, 16-26
 Three Function, 16-27
 Bank, Two Function, Replacement, 16-28
 Crane, Repair, 16-33
 Hoist Motor
 Repair, 16-13
 Replacement, 16-12
 LHS Directional, Control Valve Replacement, 17-10
 Main Frame Replacement LHS, Load, 17-6
 Mount, Four/Three Function, Replacement, 16-29
 Cooler
 Adapter, Engine Oil, Replacement, 3-30
 Assembly
 Engine Oil, Installation, 20-83
 Engine Oil, Removal, 20-24
 Engine Oil, Replacement, 3-29
 Convert DDEC II Engine Assembly to DDEC III/IV
 Engine Assembly, 18-14

C

Cab, 1-21
 Cab
 Assembly Replacement, 15-2
 Support, Front, Replacement, 13-2
 Support, Rear, Replacement, 13-4
 Wire Harness Replacement, 6-19
 Cable and Connector, Crane Remote Control, Left
 Side and Right Side, Repair, 16-30
 Cam Follower/Push Rod Repair, 20-47
 Cam Follower and Push Rod
 Replacement, 3-19
 Camshaft Repair, 20-62
 Camshaft
 Assembly
 Installation, 20-73
 Removal, 20-34
 Cell Replacement, Tension Load, 16-25
 Center
 Shaft Repair, 24-13
 Support Repair, 23-16

INDEX (CONT).

Subject, Para

Subject, Para

C (Cont)

Counterbalance Valve Repair, Self-Recovery Winch
16-36

Covers, Air Box
Installation, 20-90
Removal, 20-17

Crane
Assembly Replacement, 16-2
Control Valves Repair, 16-33
Junction Box Assembly Repair, 6-6
Load Test, 16-32
Material Handling (MHC), 1-17
Remote Control, Cable and Connector, Repair, Left
Side and Right Side, 16-30
Subframe Replacement, 16-17
Troubleshooting Procedures, 2-15
Wiring Replacement, 6-30

Crankcase
Front Cover and Oil Seal Replacement, 3-12

Crankshaft
and Main Bearing
Installation, 20-65
Removal, 20-42
Repair, 20-63
Front Cover and Seal
Installation, 20-68
Removal, 20-39

Pulley
Installation, 20-70
Removal, 20-37
Replacement, 3-9

Timing Gear
Installation, 20-74
Removal, 20-33

Crossmember
Gusset
Front Tandem, Replacement, 13-6
Rear Tandem, Replacement, 13-10
Front Tandem, Replacement, 13-6
Front, Replacement, 13-5
Rear, Replacement, 13-11
Replacement
No. 1 Intermediate, 13-7
No. 2 Intermediate, 13-8
No. 3 Intermediate, 13-9

C (Cont)

CTIS
Cab Wire Harness Replacement, 6-27
Chassis Wire Harness Replacement, 6-28

Cylinder
Block, Engine, Repair, 20-64
Erection, Repair, 28-2
Erection, Replacement, 16-5
Head Assembly Replacement, 3-7
Head
Installation, 20-88
Removal, 20-19
Repair, 20-49
LHS Hook Arm, Replacement, 17-12

Lift
Repair, 28-3
Replacement, 16-6

Liner Repair, 20-61

Outrigger
Repair, 28-11
Replacement, 16-31

Telescope
Replacement, 16-10
Repair, 28-6

D

Damper and Front Balance, Vibration, Cover
Installation, 20-82

DDEC
Battery Power Wire Harness Replacement
(145 Amp), 7-16
Battery Power Wire Harness Replacement
(200 Amp), 7-17
Engine Power Wire Harness Replacement, 7-13
Speed Sensor Pulse Wheel Replacement, 3-21

DDEC II Timing and Synchronous Reference
Sensor (TRS/SRS) Replacement/Adjustment, 6-10

DDEC III/IV Timing and Synchronous Reference
Sensor (TRS/SRS) Replacement/Adjustment, 6-11

DDEC II Wire Harness Replacement, 7-14

DDEC III/IV Wire Harness Replacement, 7-15

Decontamination Kit Installation
(With Auxiliary Fuel Tank Installed), 19-4

INDEX (CONT).

Subject, Para

Subject, Para

D (Cont)

Decontamination Kit Installation
(Without Auxiliary Fuel Tank Installed), 19-5
Destruction Of Army Material To Prevent Enemy
Use, 1-3
Differential Assembly Repair
No. 1 and 5 Axle, 26-15
No. 2 Axle, 26-16
No. 3 Axle, 25-28
No. 4 Axle, 25-29
Differential Shaft Repair, 24-12
Dipstick and Dipstick Tube, Engine Oil,
Replacement, 3-25
Diverter Block Repair, 17-19
Drag Link Repair, 12-3
Drain, Air Box,
Installation, 20-89
Removal, 20-18
Dressed Axle Air Line Replacement, 25-30

E

ECB/Transmission Wire Harness Replacement, 6-35
ECB Wire Harness Replacement, 6-25
Electrical Proportional Analog Control (EPAC)
Controller Replacement and Adjustment, 6-12
Electrical System, 1-12
Electronic Control Box Light Wire Harness
Replacement, 6-24
Electronic Control Box Wire Harness Replacement,
6-25
Electronic Control Module (ECM)
Installation, 20-104
Removal, 20-4
Emergency Steering Pump Replacement,
12-12
Engine
Adjustments, 3-2, 20-94
Assembly Replacement, Shipping Container, 3-33
Arctic Kit (Model A) Installation, 18-2
Brake Retarder
Installation, 20-93
Removal, 20-14

E (Cont)

Engine (cont)
Brake Retarder (cont)
Repair, 20-44
Replacement, 3-32
Cylinder Block Repair, 20-64
Lifting Brackets
Installation, 20-102
Removal, 20-6
Replacement, 3-6
Oil
Breather and Hoses Replacement, 3-23
Cooler Adapter Replacement, 3-30
Cooler Assembly
Installation, 20-83
Removal, 20-24
Replacement, 3-29
Testing, 20-57
Dipstick and Dipstick Tube Replacement, 3-25
Filler Tube Replacement, 3-24
Filter and Spin-On Adapter Housing
Installation, 20-84
Removal, 20-23
Pan and Gasket Replacement, 3-22
Pan
Installation, 20-80
Removal, 20-27
Pressure
Regulator Valve
Installation, 20-79
Removal, 20-28
Replacement, 3-27
Relief Valve
Installation, 20-78
Removal, 20-29
Replacement, 3-28
Pump Assembly
Installation, 20-77
Removal, 20-30
Repair, 3-26
Pump Drive Gear
Inspection, 20-59
Installation, 20-66
Removal, 20-41
Testing, 3-3

INDEX (CONT).

Subject, Para

Subject, Para

E (Cont)

Engine (cont)
 Troubleshooting Procedures, 2-11
 Wire Harness Replacement, 7-12
 Engine Systems, 1-11
 Engine Tune-up Adjustments, 20-94
 Engine/Transmission
 Assembly Replacement, 3-4
 Separation, 3-5
 Equalizer Beam, Front and Rear Tandem Repair, 14-5
 Equipment Characteristics, Capabilities, And
 Features, 1-7
 Equipment Data, 1-9
 Erection Cylinder
 Repair, 28-2
 Replacement, 16-5
 Exhaust
 Manifold
 Installation, 20-105
 Removal, 20-3
 Replacement, 3-31
 Valve Bridge
 Repair, 20-46
 Replacement, 3-17
 Valve
 Repair, 20-48
 Replacement, 3-18
 Expansion Plug Replacement, 3-8

F

Fan
 Drive Motor Replacement, 5-9
 Suction, Assembly Replacement, 5-8
 Fender
 Right, Replacement, 15-4
 Left, Replacement, 15-5
 Fifth Clutch Repair, 23-14
 Filler Tube, Engine Oil, Replacement, 3-24
 Filter and Spin-On
 Adapter, Engine Oil, Housing Installation, 20-84
 Engine Oil, Adapter Housing Removal, 20-23
 Filter Element, Transmission Internal Oil,
 Replacement, 7-4

F (Cont)

Filter Unit Kit, Gas Particulate, Installation, 19-2
 First
 Clutch and Adapter Housing Repair, 23-19
 Range Trimmer Valve Repair, 23-6
 Shift Valve Repair, 23-7
 Flange Assembly and Oil Seal Replacement
 No. 1 and 5 Axle, 9-7
 No. 2 Axle, 9-18
 No. 3 and 4 Axle, 9-18
 Flange Assembly Rear Oil Seal Replacement,
 Axle No. 3, 25-26
 Flatrack (FR), PLS, 1-23
 Flex Plate
 Installation, 20-81
 Removal, 20-26
 Flex Plate and Hub Replacement, 3-13
 Flywheel
 and Torque Converter Turbine Repair, 7-10
 Housing and Rear Oil Seal
 Installation, 20-76
 Removal, 20-31
 Forward Clutch and Turbine Shaft Repair, 23-13
 Four Function Control Valve Bank Repair, 16-26
 Four/Three Function Control Valve Bank Mount
 Replacement, 16-29
 Fourth Clutch Repair, 23-15
 Frame
 Compression, Repair, 16-42
 Frame Inspection, 13-14
 LHS Middle, Repair, 16-40
 Tube, LHS Middle, Replacement, 16-41
 Front
 Balance and Vibration Damper Cover
 Removal, 20-25
 Balance Cover and Vibration Damper
 Replacement, 3-10
 Cab Support Replacement, 13-2
 Cover and Seal, Crankshaft, Installation, 20-68
 Crossmember Replacement, 13-5
 Cylinder Block Plate
 Installation, 20-71
 Removal, 20-36
 Shaft Assembly Repair, 24-10
 Steering Gear and Pitman Arm Replacement, 12-9
 Tandem Crossmember/Gusset Replacement, 13-6

INDEX (CONT).

Subject, Para

Subject, Para

F (Cont)

Front (cont)
 Tow Eye and Cross Brace Replacement, 13-3
 Front and Rear
 Spring Assembly Replacement, 14-3
 Steering Gear Repair, 27-3
 Tandem Equalizer Beam Replacement, 14-5
 Fuel Hoses Removal/Head/Secondary Fuel Filter, 20-9
 Fuel Injector
 Installation, 20-92
 Removal, 20-15
 Repair, 4-2
 Fuel Pump Assembly Installation, 20-98
 Fuel Pump
 Removal, 20-10
 Replacement, 4-10
 Fuel/Water Separator Repair, 4-9

G

Gas Particulate Filter Unit (GPFU) Kit Installation, 19-2
 Gasket
 Pan, Transmission Oil, Replacement, 23-3
 Rocker Cover Removal, 20-11
 Gear Box, 90 Degree, Repair, 12-5
 Gear
 Front Steering and Pitman Arm, Replacement, 12-9
 Intermediate Steering and Pitman Arm,
 Replacement, 12-10
 Rear Steering and Pitman Arm, Replacement, 12-11
 Replacement, and Turntable, 16-16
 Gear Reducer, 2.21:1
 Repair, 27-2
 Replacement, 12-6
 Gear Reducer Mount Replacement (M1075 Only), 13-15
 Gear Reducer, Swing Drive
 Repair, 28-9
 Replacement, 16-18
 General
 Assembly Instructions, 2-26
 Cleaning Instructions, 2-22
 Disassembly Instructions, 2-21
 Ground Handling, 2-19
 Inspection Instructions, 2-23
 Installation Instructions, 2-27

G (Cont)

General (cont)
 Removal Instructions, 2-20
 Repair Instructions, 2-25
 Welding Instructions, 2-24
 Welding Maintenance, 6-39

H

Hand Receipt Manual and Inventory of Equipment, 2-5
 Hoist
 Assembly
 Repair, 28-7
 Replacement, 16-11
 Boom, Telescope, Swing Solenoid Valve
 Repair, 16-34
 Brake Repair, 16-14
 Cable Follower Repair, 16-15
 Hydraulic, Motor, Repair, 28-8
 Motor Valve Repair, 16-13
 Proximity Sensor Replacement/Adjustment, 6-9
 Holding Valve, Lift Cylinder, Replacement, 16-7
 Hook Arm/Main Cylinder Repair, LHS, 17-14
 Hub
 Drum Repair/Ring Gear Assembly, Self-Recovery
 Winch, 28-17
 Repair, Motor End, Self-Recovery Winch, 28-16
 Hub and Flex Plate Replacement, 3-13
 Hydraulic
 Adjustment, Steering System, 12-2
 Adjustment, Main Hydraulic System, 17-5
 Hoist Motor
 Repair, 28-8
 Replacement, 16-12
 Manual Override Solenoid Manifold Repair, 16-24
 Motor Replacement, 28-12
 Multifunction Manifold/Bracket Repair, 17-18
 Pump, Emergency Steering, Replacement, 12-12
 Return Manifold Replacement, 17-17
 System, 1-14
 System Troubleshooting Procedures, 2-13

INDEX (CONT).

Subject, Para

Subject, Para

I

Idler Gear
 Installation, 20-75
 Removal, 20-32
 Repair, 20-58
 Inflation System (CTIS), Central Tire, 1-20
 Injector Tube Repair, 20-53
 Inner Axle Shaft Seal Replacement, 9-10
 Installing Engine On Stand, 20-2
 Interface Kit Installation, 18-9
 Intergear Link Repair, 12-4
 Intermediate Crossmember No. 1 Replacement, 13-7
 Intermediate Crossmember No. 2 Replacement, 13-8
 Intermediate Crossmember No. 3 Replacement, 13-9
 Intermediate Steering Gear and Pitman Arm
 Replacement, 12-10
 Intermediate Steering Gear Repair, 27-4
 Inter-Steering Shaft Repair, 12-7
 Inter-Steering Shaft, 2.21:1 Gear Reducer,
 Replacement, 12-6
 Introduction to Logic Tree Troubleshooting, 2-9

J

Junction Box Assembly Repair, Crane, 6-6

L

Lateral Torque Rod Replacement, 14-8
 Left Fender Replacement 15-5
 Left Side
 Power Module Frame Replacement, 13-12
 Thermostat Housing
 Removal, 20-7
 Replacement, 5-4
 Left Side and Right Side Crane Remote Control
 Cable and Connector Repair, 16-30
 Left Thermostat Housing Installation, 20-101
 LHS
 Cab-to-Bulkhead Wire Harness Replacement, 6-33
 Compression Frame Repair, 16-42
 Controller Protection Kit Installation, 18-10
 Differential Pressure Switch Replacement, 6-5
 Directional Control Valve Replacement, LHS, 17-10

L (Cont)

LHS Hook Arm (cont)
 Cylinder Replacement, LHS, 17-12
 Manifold Repair, 17-13
 Repair, 16-39
 Hook
 Arm/Main Cylinder Repair, LHS, 17-14
 Arm Repair, 16-39
 Replacement, 16-38
 Main
 Cylinder
 Hook Arm, Repair, 17-14
 Manifold Repair, 17-16
 Frame Load Control Valve Replacement, 17-6
 Manifold
 Bracket Replacement, 16-43
 Check Valve Replacement, 17-7
 Relief Valve Replacement, 17-8
 Solenoid Valve and Coil Replacement, 17-9
 Middle Frame
 Repair, 16-40
 Tube Replacement, 16-41
 Transit Valve Replacement, 17-11
 Wire Harness, Main Replacement, 6-31
 LHS Cab Interface Wire Harness Replacement, 6-32
 LHS Control Box to LHS Main Junction Box Wire
 Harness Replacement, 6-33.2
 LHS Load Control Valve Main Frame Replacement,
 17-6
 LHS Main Junction Box to LHS Bulkhead Wire
 Harness Replacement, 6-33.1
 LHS Main Wire Harness Replacement, 6-31
 Lift Cylinder
 Holding Valve Replacement, 16-7
 Repair, 28-3
 Replacement, 16-6
 Lifting Brackets, Engine
 Installation, 20-102
 Removal, 20-6
 Replacement, 3-6
 Load Cell, Tension, Replacement, 16-25
 Load Handling System (LHS), 1-18
 Load Handling System (LHS) Troubleshooting
 Procedures, 2-13

INDEX (CONT).

Subject, Para

Subject, Para

L (Cont)

Location And Description Of Major Components, 1-8
 Locking Cylinder Replacement
 No. 1 and 5 Axle, 9-15, 26-10
 No. 2 Axle, 9-16, 26-11
 Locking Cylinder Replacement (cont)
 No. 3 Axle, 9-17, 25-22
 No. 4 Axle, 9-16, 25-23
 Longitudinal Torque Rod Replacement, 14-9
 Low Oil
 Sensor Assembly Replacement, Transmission,
 7-5, 23-5
 Sensor Harness Replacement, Transmission, 7-6
 Lower Shift Rod Repair, 24-16
 Lubrication Pump, Transfer Case, Replacement, 8-5

M

Machine Gun Kit Installation, 18-5
 Maintenance Forms, Records, And Reports, 1-2
 Maintenance
 Introduction, 2-18
 Storage Procedures, 2-30
 Main Bearing and Crankshaft
 Installation, 20-65
 Removal, 20-42
 Repair, 20-63
 Main Cylinder Replacement, 17-15
 Main Cylinder, Hook Arm Repair, LHS, 17-14
 Main Frame Replacement, Load Control Valve, 17-6
 Main Hydraulic
 Pump Control Subassembly Replacement, 17-4
 Pump Repair, 17-2
 Pump Input Shaft Seal Repair, 17-3
 System Adjustment, 17-5
 Main Manifold
 LHS
 Bracket Replacement, 16-43
 Check Valve Replacement, 17-7
 Relief Valve Replacement 17-8
 Solenoid Valve and Coil Replacement, 17-9
 Manifold
 Exhaust
 Installation, 20-105

M (Cont)

Removal, 20-3
 Replacement, 3-31
 LHS Hook Arm, Repair, 17-13
 LHS Main Cylinder Repair, 17-16
 LHS Main Cylinder Replacement, 17-15
 Manifold (cont)
 Self-Recovery Winch, Replacement, 16-37
 Manual Override Solenoid Manifold Repair, 16-24
 Mast Assembly
 Repair, 28-5
 Replacement, 16-9
 Material Handling Crane (MHC), 1-17
 Material Handling Crane (MHC) Troubleshooting
 Procedures, 2-15
 Motor End
 Hub Repair, Self-Recovery Winch, 28-16
 Support Repair, Self-Recovery Winch, 28-15
 Motor
 Hydraulic Hoist, Repair, 28-8
 Replacement, Self-Recovery Winch, 16-35
 Replacement, Fan Drive, 5-9
 Swing Drive, Replacement, 16-20
 Multifunction Manifold Bracket, Hydraulic Repair,
 17-18

N

Neutral Start Switch Replacement/Adjustment, 24-5
 90 Degree Gear Box Repair, 12-5
 No. 1 and 2 Axle
 Air Brake Chamber Replacement, 26-4
 No. 1 and 5 Axle
 Differential Assembly Repair, 26-15
 Flange Assembly and Oil Seal Replacement, 9-7
 Locking Cylinder Replacement, 9-15, 26-10
 No. 1 Axle
 Assembly Replacement, 9-3
 Intermediate Crossmember Replacement, 13-7
 No. 1, 2 and 5 Axle
 Brake
 Assembly Replacement, 26-8
 Drum Replacement, 26-3
 Constant Velocity Joint Repair, 9-8, 26-13
 Dressed Axle Air Line Replacement, 25-30

INDEX (CONT).

Subject, Para

Subject, Para

N (Cont)

Inner and Outer Axle Shaft Seals and Bearing Replacement, 9-10

Pivot and Spindle Assembly and Outer Axle Shaft Seal and Bearing Replacement, 9-9

Pivot and Spindle/Trunnion Bearing Assembly Repair, 26-12

No. 1, 2 and 5 Axle (cont)

Planetary Hub Gear Replacement, 9-6, 26-6

Tie Rod Repair, 26-9

Trunnion Bearing Inspection, 9-2

Wheel

Hub Assembly

Repair, 11-2

Replacement, 26-7

No. 2 Axle

Assembly Replacement, 9-4

Differential Assembly Repair, 26-16

Flange Assembly and Oil Seal Replacement, 9-18

Intermediate Crossmember Replacement, 13-8

Locking Cylinder Replacement, 9-16, 26-11

Rear Output Assembly Replacement, 26-14

No. 3 and 4 Axle

Air Brake Chamber Replacement, 25-18

Brake Assembly Replacement, 25-21

Brake Drum Replacement, 25-17

Flange Assembly and Oil Seal Replacement, 9-18

Planetary Hub Gears Replacement, 9-6, 25-19

Shaft Replacement, 9-5, 25-25

Spindle Assembly Repair, 9-14

Spindle Repair, 25-24

Wheel Hub Assembly Repair, 25-20

No. 3 Axle

Air

Bags Replacement, 14-4

Suspension Beam

Assembly Repair, 14-6

Mount Replacement/Adjustment, 14-7

Assembly Replacement, 9-11

Differential Assembly Repair, 25-28

Dressed Axle Air Line Replacement, 25-30

Flange Assembly and Oil Seal Replacement, 9-18

Intermediate Crossmember Replacement, 13-9

Locking Cylinder Replacement, 9-17, 25-22

N (Cont)

Rear Flange Oil Seal Replacement, 25-26

No. 4 Axle

Assembly Replacement, 9-12

Differential Assembly Repair, 25-29

Dressed Axle Air Line Replacement, 25-30

Flange Assembly and Oil Seal Replacement, 9-18

Locking Cylinder Replacement, 9-16, 25-23

No. 4 Axle (cont)

Rear Output Assembly Replacement, 25-27

No. 5 Axle

Air Brake Chamber Replacement, 26-5

Assembly Replacement, 9-13

O

Official Nomenclature, Names, And Designations, 1-4

Oil

Engine, Breather and Hoses Replacement, 3-23

Engine, Cooler Adapter Replacement, 3-30

Engine, Cooler Assembly Replacement, 3-29

Engine, Dipstick and Dipstick Tube Replacement, 3-25

Engine, Filler Tube Replacement, 3-24

Engine, Pressure Regulator Valve Replacement, 3-27

Engine, Pressure Relief Valve Replacement, 3-28

Engine, Pump Repair, 3-26

Oil Filter Element, Transmission Internal, Replacement, 7-4, 23-4

Oil Pan and Gasket

Engine, Replacement, 3-22

Transmission, Replacement, 7-3, 23-3

Oil Seal and Crankcase Front Cover Replacement, 3-12

Oil Seal/Sleeve, Rear, Replacement, 3-14

Oil Seal, Transmission Yoke/Dust Shield/, Replacement, 7-9

Oil Seals, Transfer Case Yoke, Replacement, 8-4

Oil Sensor Assembly, Transmission Low Oil, Replacement, 7-5, 23-5

Oil Sensor Harness, Transmission Low Oil, Replacement, 7-6

Outrigger Cylinder

Repair 28-11

Replacement, 16-31

INDEX (CONT).

Subject, Para

Subject, Para

O (Cont)

Overload Shutdown System
 Replacement, 6-8
 Wire Gasket Replacement, 6-7

P

Packing/Unpacking Shipping Container
 Engine Assembly Replacement, 3-33
 Transfer Case Assembly Replacement, 8-6
 Transmission Assembly Replacement, 7-11
 Piston and Connecting Rod Repair, 20-60
 Piston, Connecting Rod, and Liner
 Installation, 20-67
 Removal, 20-40
 Pivot and Spindle Assembly and Outer Axle Shaft
 Seal and Bearing Replacement,
 No. 1, 2 and 5 Axle, 9-9
 Planetary
 Hub Gears Replacement, 9-6
 Hub Gear Replacement, No. 1, 2 and 5 Axle, 26-6
 Gearing, Shafts and Third Clutch Repair, 23-17
 PLS Flatrack (FR), 1-23
 PLS Trailer (PLST), 1-22
 Polarity Power Wire Harness Replacement (200 Amp),
 6-37
 Polarity Protection and Alternator Wire Harness
 Replacement (200 Amp with Battery Disconnect
 Switch), 6-40
 Polarity Wire Harness Replacement (200 Amp), 6-38
 Power Module Frame
 Left Side, Replacement, 13-12
 Right Side, Replacement, 13-13
 Power Train, 1-10
 Preparation for Storage or Shipment, 2-29
 Preparation for Storage or Shipment Introduction, 2-28
 Pressure Switch, LHS Differential, Replacement, 6-5
 Principles of Operation:
 Air System, 1-13
 Cab, 1-21
 Central Tire Inflation System (CTIS), 1-20
 Electrical System, 1-12
 Engine Systems, 1-11
 Hydraulic System, 1-14

P (Cont)

Load Handling System (LHS), 1-18
 Material Handling Crane (MHC), 1-17
 Power Train, 1-10
 Self-Recovery Winch (SRW), 1-16
 Steering System, 1-15
 Wheels And Tires, 1-19
 Pulley, Crankshaft Replacement, 3-9
 Pump
 Assembly Engine Oil,
 Installation, 20-77
 Removal, 20-30
 Repair, 3-26
 Drive Gear
 Engine Oil
 Inspection, 20-59
 Installation, 20-66
 Removal, 20-41
 Main Hydraulic
 Input Shaft Seal Replacement, 17-3
 Repair, 17-2
 Push Rod and Cam Follower
 Repair, 20-47
 Replacement, 3-19

R

Radiator Assembly Repair/Test, 5-2
 Rear
 Cab Support Replacement, 13-4
 Crossmember Replacement, 13-11
 Cylinder Block Plate
 Installation, 20-72
 Removal, 20-35
 Light Wire Harness Replacement, 6-42
 Oil Seal/Sleeve Replacement, 3-14
 Oil
 and Flywheel Housing Seal Removal, 20-31
 Seal and Flywheel Housing Installation, 20-76
 Output Assembly Replacement
 No. 2 Axle, 26-14
 No. 4 Axle, 25-27
 Shaft Assembly Repair, 24-11
 Steering Gear and Pitman Arm Replacement, 12-11

INDEX (CONT).

Subject, Para

Subject, Para

R (Cont)

Steering Gear Assembly
 Repair, 27-3

Tandem Crossmember
 Gusset Replacement, 13-10

Transmission Cover Assembly Repair, 23-18

Regulator Valve, Engine Oil Pressure,
 Installation, 20-79
 Removal, 20-28
 Replacement, 3-27

Relief Valve
 Engine Oil Pressure,
 Installation, 20-78
 Replacement, 3-28
 Removal, 20-29

Remote Engine Oil Filter Kit Installation, 18-12

Remote Engine Oil Filter Manifold
 Installation, 20-84
 Removal, 20-23

Removing Engine From Stand, 20-106

Repair Parts, 2-3

Reporting Equipment Improvement Recommendations
 (EIR), 1-5

Reverse Polarity Power Wire Harness Replacement
 (145 Amp), 6-36

Right Fender Replacement, 15-4

Right Thermostat Housing Installation, 20-100

Right Side
 Crane Remote Control Cable Connector Repair,
 16-30
 Power Module Frame Replacement, 13-13
 Thermostat Housing
 Removal, 20-8
 Replacement, 5-3

Ring Gear Assembly/Hub Assembly Repair,
 Self-Recovery Winch, 28-17

Rocker
 Arm
 Repair, 20-45
 Replacement, 3-20

Cover
 Installation, 20-97
 Repair, 20-43

R (Cont)

Cover and Gasket
 Removal, 20-11

S

Scope, 1-1

Seals, Inner and Outer Axle Shaft and Bearing,
 Replacement, 9-10

Second Clutch Repair, 23-20

Secondary Fuel Filter, Head and Fuel Hoses
 Installation, 20-99
 Removal, 20-9

Self-Recovery Winch
 Base Mount Replacement, 28-14
 Brake Repair, 28-13
 Counterbalance Valve Replacement, 16-36
 Manifold Replacement, 16-37
 Motor End Hub Repair, 28-16
 Motor End Support Repair, 28-15
 Motor Replacement, 16-35
 Ring Gear Assembly/Hub Drum Repair, 28-17

Self-Recovery Winch (SRW), 1-16

Service Before Operation, 2-6

Shafts
 No. 3 and 4 Axle, Replacement, 25-25
 Planetary Gearing, and Third Clutch Repair, 23-17

Shift Connector Replacement, 24-4

Shift Rod
 Upper, Repair, 24-15
 Lower, Repair, 24-16

Shipment or Storage
 Introduction, 2-28
 Preparation, 2-29

Shipping Container
 Engine Assembly Replacement, 3-33
 Transfer Case Assembly Replacement, 8-6
 Transmission Assembly Replacement, 7-11

Singars Radio Kit, Installation, 18-4

Solenoid
 Manifold, Manual Override Repair, 16-24
 Valve and Coil Repair, LHS Main Manifold, 17-9
 Valve, Hoist, Boom, Telescope Swing, Repair, 16-34

Special Tools, TMDE, and Support Equipment, 2-2

Speedometer Sensor Replacement, 24-6

INDEX (CONT).

Subject, Para

Subject, Para

S (Cont)

Spindle, No. 3 and 4 Axle
 Repair, 9-14, 25-24

Spring
 Assembly, Front and Rear, Replacement, 14-3
 Tandem Hanger Replacement, 14-2

Starter Repair, 6-4

STE/ICE-R
 Alternator Wire Harness Replacement (145 Amp),
 6-21
 Alternator Wire Harness Replacement (200 Amp),
 6-22
 Chassis Wire Harness Replacement, 6-23
 Wire Harness Replacement, 6-20

Steering Gear
 Front and Rear Repair, 27-3
 Intermediate, Repair, 27-4

Steering System, 1-15

Steering System
 Alignment and Adjustment, 12-8
 Hydraulic Adjustment, 12-2
 Manifold Repair, 12-13
 Purging Procedure, 12-14
 Troubleshooting Procedures, 2-17

Storage Maintenance Procedures, 2-30

Storage or Shipment
 Introduction, 2-28
 Preparation, 2-29

Suction Fan Assembly Replacement, 5-8

Swing Drive
 Brake
 Repair, 28-10
 Replacement, 16-21
 Gear Reducer
 Repair, 28-9
 Replacement, 16-18
 Motor
 Replacement, 16-20
 Valve Repair, 16-19

Swing Solenoid Valve, Hoist, Boom, Telescope, Repair,
 16-34

Synchronous and Timing Reference Sensor (TRS/SRS)
 Installation, 20-91
 Removal, 20-16
 Replacement/Adjustment, 6-10, 6-11

S (Cont)

System
 Air, 1-13
 Electrical, 1-12
 Hydraulic, 1-14
 (LHS) Load Handling, 1-18
 Systems, Engine, 1-11

T

2.21:1 Gear Reducer and Inter-Steering Shaft
 Replacement, 12-6

2.21:1 Gear Reducer Repair, 27-2

Tachometer Drive Assembly
 Installation, 20-96
 Removal, 20-12

Tandem Spring Hanger Replacement, 14-2

Telescope Cylinder
 Repair, 28-6
 Replacement, 16-10

Tension Link
 Repair, 28-4
 Replacement, 16-8

Tension Load Cell Replacement, 16-25

Thermostat Housing
 Left Side, Replacement, 5-4
 Right Side, Replacement, 5-3

Third Clutch, and Planetary Gearing, Shafts
 Repair, 23-17

Three Function Control Valve Bank Repair, 16-27

Tie Rod Repair, No. 1, 2, 5 Axle, 26-9

Timing and Synchronous Reference Sensor (TRS/SRS)
 Installation, 20-91
 Removal, 20-16
 Replacement/Adjustment (DDEC II and III), 6-10,
 6-11

Timing Gear, Crankshaft
 Installation, 20-74
 Removal, 20-33

Torque Converter
 Flywheel, Turbine Repair, 7-10
 Housing Repair, 23-12
 Pump Repair, 23-11
 Stator Repair, 23-10

INDEX (CONT).

Subject, Para

Subject, Para

T (Cont)

Torque Rod
 Lateral, Replacement, 14-8
 Longitudinal, Replacement, 14-9
 Tow Eye, Front and Cross Brace Replacement, 13-3
 Trailer (PLST), PLS, 1-22
 Transfer Case
 Assembly
 Repair, 24-8
 Replacement, 8-2
 Support Replacement, 8-3
 Differential Assembly Repair, 24-9
 Lubrication Hoses Replacement, 24-3
 Lubrication Pump
 Repair, 24-17
 Replacement, 8-5
 Oil Seal Replacement, 8-4
 On Stand Installation/Removal, 24-2
 Shipping Container, Assembly Replacement, 8-6
 Yoke Replacement, 8-4, 24-7
 Transit Valve Replacement, LHS, 17-11
 Transmission
 Internal Oil Filter Element Replacement, 7-4, 23-4
 Low Oil Sensor Assembly Replacement, 7-5, 23-5
 Low Oil Sensor Harness Replacement, 7-6
 Oil Pan and Gasket
 Replacement, 7-3, 23-3
 On Stand Installation/Removal, 23-2
 Shipping Container, Assembly Replacement, 7-11
 Solenoid Pressure Switch Replacement, 7-8
 Solenoid Replacement, 7-7
 Solenoid Wire Harness Repair, 23-8
 Solenoid Wire Harness Replacement, 7-2
 Transmission/Engine
 Assembly Replacement, 3-4
 Separation, 3-5
 Troubleshooting Procedures, 2-12
 Yoke/Dust Shield/Oil Seal Replacement, 7-9
 Trimmer Valve, First Range, Repair, 23-6
 Troubleshooting
 Instructions, 2-8
 Introduction, 2-7
 Procedures
 Air System, 2-12
 Arctic Heater (Model B), 2-17.1

T (Cont)

Troubleshooting (cont)
 Procedures (cont)
 Crane, 2-15
 Engine, 2-10
 Hydraulic System, 2-13
 Load Handling System (LHS), 2-14
 Steering System, 2-17
 Transmission, 2-11
 Winch, 2-16
 Trunnion Bearing Inspection, No. 1, 2 and 5 Axle, 9-2
 Turbine Shaft and Forward Clutch Repair, 23-13
 Turbocharger
 and Air Inlet Housing
 Installation, 20-103
 Removal, 20-5
 Assembly
 Repair, 21-3
 Replacement, 4-8
 Turntable Bearing Inspection, 16-15.1
 Turntable and Gear Replacement, 16-16
 Two Function Control Valve Bank Repair, 16-28
 Two Way Hydraulic Solenoid Valve Repair, 16-23

U

Unpacking and Deprocessing, 2-4
 Upper
 Shaft Repair, 24-14
 Shift Rod Repair, 24-15

V

Valve
 Bridge, Exhaust
 Repair, 20-46
 Replacement, 3-17
 Bridge Guide Repair, 20-51
 Exhaust, Replacement, 3-18
 Guide Repair, 20-50
 Seat Insert Repair, 20-52
 Vibration Damper
 Installation, 20-69
 Removal, 20-38
 Replacement, 3-11

INDEX (CONT).

Subject, Para

V (Cont)

Vibration Damper and Front Balance Cover
 Installation, 20-82
 Removal, 20-25
 Vibration Damper/Front Balance Cover Replacement,
 3-10

W

Warranty Information, 1-6
 Water
 Nozzle Repair, 20-54
 Pump
 Assembly
 Installation, 20-85
 Removal, 20-22
 Repair, 22-2
 Replacement, 5-6
 Drive Gear Replacement, 5-7
 Welding, General Maintenance, 6-39
 Wheel
 Hub Assembly
 No. 1, 2 and 5 Axle Replacement, 26-7
 No. 3 and 4 Axle Repair, 25-20
 Repair, 11-2
 Wheels and Tires, 1-19
 Windshield Glass Replacement, 15-3
 Winch (Self-Recovery) Troubleshooting Procedures,
 2-16
 Winch (SRW), Self-Recovery, 1-16
 Wire Harness
 ATEC, Replacement, 6-26
 Battery Disconnect, Replacement (200 Amp with
 Battery Disconnect Switch), 6-41
 Cab, Replacement, 6-19
 Chassis, Replacement, 6-29
 CTIS Cab, Replacement, 6-27
 CTIS, Chassis, Replacement, 6-28
 DDEC
 Battery Power, Replacement (145 Amp), 6-17
 Battery Power, Replacement (200 Amp), 6-18
 Engine Power, Replacement, 6-14
 ECB Light, Replacement, 6-24
 ECB, Replacement, 6-25

Subject, Para

W (Cont)

Wire Harness (cont)
 ECB/Transmission, Replacement, 6-35
 Engine, Replacement, 6-13
 LHS
 Cab-to-Bulkhead, Replacement, 6-33
 Main, Replacement, 6-31
 LHS Cab Interface, Replacement, 6-32
 Polarity Power, Replacement (200 Amp), 6-37
 Polarity Protection and Alternator, Replacement
 (200 Amp with Battery Disconnect Switch), 6-40
 Polarity, Replacement (200 Amp), 6-38
 Reverse Polarity Power, Replacement (145 Amp),
 6-36
 STE/ICE-R
 Alternator, Replacement (145 Amp), 6-21
 Alternator, Replacement (200 Amp), 6-22
 Chassis, Replacement, 6-23
 Replacement, 6-20
 Transmission Solenoid, Replacement, 7-2
 Transmission Solenoid, Repair, 23-8
 24 Volt Trailer, Replacement, 6-34
 Wiring, Crane, Replacement, 6-30

Y

Yoke and Oil Seal, Transfer Case, Replacement, 8-4

SCHEMATICS

The following sections contain the schematics which are the same in all volumes of TM 9-2320-364-20 and TM 9-2320-364-34.

Section I contains the schematics for trucks equipped with the 145 amp alternator and the DDEC II engine.

Section II contains the schematics for trucks equipped with the 200 amp alternator and the DDEC III/IV engine.

SCHEMATICS

Section I. 145 AMP ALTERNATOR AND DDEC II ENGINE.

Section I contains the schematics for trucks equipped with the 145 amp alternator and the DDEC II engine.

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
439	MC116-MC106	4	EMERGENCY ENG STOP
439	MC116-S30	3	EMERGENCY ENG STOP
439	MC116-S30	3	EMERGENCY ENG STOP
439	MC116-CB13	4	DDEC
439	MC106-MC13	3	
439	SPLC-MC106	4	
439	MC11-MC18	5	ECM
439	MC8-L6	3	CHECK ENGINE LIGHT
439	MC8-L3	3	ENGINE STOP LIGHT
439	MC44-MC8	3	
439	MC11-SPLICE	4	
439	SPLICE-MC44	4	
439	SPLC-MC116	4	
451	MC11-MC18	5	ECM
451	MC106-MC13	3	
451	MC11-MC106	4	
505	MC106-MC13	3	
505	MC11-MC106	4	
505	MC11-MC18	5	ECM
508	MC11-R7	4	TRANSMISSION
508	MC11-MC18	5	ECM
509	MC11-MC18	5	ECM
509	MC8-L3	3	ENGINE STOP LIGHT
509	MC44-MC8	3	
509	MC11-MC44	4	
510	MC11-MC18	5	ECM
510	MC44-PS4	3	PARKING BRAKE
510	R22-MC44	4	
510	MC11-R22	4	
900	MC11-MC106	4	
900	MC11-MC18	5	ECM
900	MC106-MC13	3	
901	MC11-MC18	5	ECM
901	MC106-MC13	3	
901	MC11-MC106	4	
908	MC11-MC18	5	ECM
908	MC11-M4	4	THROTTLE POSN CONT
916	MC44-MC6	3	
916	MC11-MC44	4	
916	MC38-M16	3	
916	MC6-MC38	3	VERNIER CONTROL
916	MC6-M35	3	THROTTLE SENSOR
916	MC11-MC18	5	ECM
952	MC38-M16	3	
952	MC11-MC44	4	
952	MC44-MC6	3	THROTTLE SENSOR
952	MC11-MC18	5	ECM
952	MC6-MC38	3	VERNIER CONTROL
1001	MC8-L4	3	
1001	MC7-SPLICE	3	
1001	MC8-SPLICE	3	
1001	SPLICE-L13	3	
1001	SPLICE-L14	3	

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1001	S1-MC7	3	RH HEADLIGHT
1002	S1-MC7	3	LH HEADLIGHT
1002	MC8-L11	3	
1002	MC7-SPLICE	3	
1002	SPLICE-MC8	3	
1002	SPLICE-L18	3	
1002	SPLICE-L16	3	
1003	MC7-MC3	3	
1003	S1-MC7	3	LH RR TURN SIGNAL
1003	MC3-MC80	6	
1003	MC3-MC16	6	TRAILER CONN 12VDC
1003	MC1-R15	4	LH TURN LIGHT
1003	MC80-L24	6	LH STOP LIGHT
1003	MC27-MC3	6	FRONT TOW
1003	MC7-MC1	3	
1003C	MC25-R17	4	LH TURN LIGHT
1003C	MC25-MC15	6	TRAILER CONN 12VDC
1004	MC7-MC1	3	
1004	MC7-MC3	3	
1004	S1-MC7	3	
1004	MC3-MC80	6	
1004	MC80-L22	6	RH STOP LIGHT
1004	MC27-MC3	6	
1004	MC3-MC78	6	
1004	MC3-MC16	6	
1004	MC1-R16	4	
1004C	MC25-R16	4	RH TURN LIGHT
1004C	MC25-MC15	6	TRAILER CONN 24VDC
1005	MC126-S9	3	
1005	PS3-MC3	3	
1005	MC3-MC16	6	TRAILER CONN 24VDC
1005	MC126-PS1	3	
1005	PS2-PS3	3	
1005	MC27-MC3	6	FRONT TOW
1005	PS1-PS2	3	
1005A	MC7-MC126	3	
1005A	MC126-S9	3	
1005A	S1-MC7	3	TURN SIGNAL/DIM SW
1006	MC2-SPLICE	3	
1006	SPLICE-L12	3	
1006	SPLICE-L17	3	
1006	MC2-R5	4	DIMMER
1007	MC2-R5	4	DIMMER
1007	MC2-SPLICE	3	
1007	SPLICE-L12	3	
1007	SPLICE-L17	3	
1008	MC3-MC78	6	
1008	MC4-S12	3	HEADLIGHTS

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1008	MC27-MC3	6	FRONT TOW
1008	MC3-SPLICE	3	
1008	MC3-MC4	3	
1008	MC3-MC16	6	TRAILER CONN 12VDC
1008	MC78-L22	6	RH TAIL LIGHT
1008	MC78-L24	6	LH TAIL LIGHT
1008C	MC25-MC15	6	TRAILER CONN 24VDC
1008C	MC25-R14	4	B.O. SERVICE
1009	PS2-PS3	3	
1009	PS1-PS2	3	
1009	MC2-PS1	3	
1009	MC2-CB6	4	STOP LIGHT
1012	MC3-SPLICE	3	
1012	SPLC-SPLC	3	
1012	MC2-SPLICE	3	
1012	SPLC-SPLC	3	
1012	SPLICE-L19	3	
1012	MC2-R2	4	CLEARANCE LIGHTS
1012	MC3-SPLICE	6	
1012	SPLICE-MC27	6	
1012	SPLICE-MC80	6	
1012	SPLICE-L32	6	RH SIDE MARKER
1012	SPLICE-L34	6	LH SIDE MARKER
1012	MC90-L31	6	RR SIDE MARKER
1012	MC90-L25	6	ID LIGHTS
1012	MC80-MC90	6	
1012	MC90-L33	6	RR SIDE MARKER
1016	MC92-MC2	3	
1016	S15-MC92	3	
1016	MC2-R3	4	HORN
1017	SPLICE-R5	4	
1017	MC52-R14	4	
1017	R2-MC52	4	
1017	MC2-SPLICE	4	
1017	SPLICE-R1	4	
1017	MC91-MC2	3	
1017	S1-MC91	3	
1017A	MC91-MC2	3	
1017A	S1-MC91	3	
1017A	MC2-R5	4	
1018	MC8-L10	3	HIGH BEAM
1018	MC8-1007	3	
1019	L15-1679	3	
1020	L14-L16	3	
1020	DUVAC IGN	5	FUEL PUMP
1020	S2-MC21	3	
1020	R27-MC48	5	
1020	MC60-IGN	5	DUVAC CONTROLLER
1020	MC21-MC60	5	
1020	MC108-M81	5	
1020	M81-MC60	5	
1021	MC2-S2	3	
1021	MC2-R11	4	
1021	R11-M76	4	

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 3 OF 35
ENGINEERING DWG 1878290 SHEET 1
FP-5/FP-6 BLANK

REVISION V
CN 23138
11-24-92

CODE SORT			
CCCE	ROUTING	SH	DESCRIPTION
1021	MC52-R11	4	FRONT TOW
1021A	R11-MC1	4	
1021A	MC1-MC21	3	
1021A	MC21-MC60	5	
1021A	MC60-R27	5	
1026	MC52-CB16	4	
1029	MC2-R6	4	BEACON
1029	MC2-MC28	3	
1031	R3-SPLICE	4	
1032	MC8-MC21	3	
1032	M39-L9	3	LOW OIL PSI
1032	MC8-M39	3	
1032	PS9-MC21	5	ENGINE OIL PSI SW
1033	M39-M18	3	OIL PSI/H WTR ALM
1036	MC23-M8	5	
1036	MC23-M7	5	
1036	MC21-MC56	5	ETHER START
1036	MC21-S25	3	
1040	CB4-R4	4	WORKLIGHT
1040A	S6-MC4	3	
1040A	MC2-R4	4	WORKLIGHT
1040A	MC4-MC2	3	
1040B	MC3-MC79	6	RH WORKLIGHT
1040B	MC2-MC3	3	
1040B	MC2-R4	4	WORKLIGHT
1040B	MC3-MC54	6	LH WORKLIGHT
1045	R27-M7	5	
1049	MC2-R1	4	HEADLIGHTS
1049	MC4-MC2	3	
1049	S12-MC4	3	
1052	S20-S19	3	CHEM ALM-GPF
1052	S19-S18	3	GAS PART FLTR-SRW
1052	S18-S4	3	SRW-SRW/MHC
1052	S4-S30	3	SRW/MHC-EMER ENG S D
1052	S30-SPLICE	3	EMER ENG SHUT DOWN
1052	SPLICE-G11	3	AIR PRESSURE GAUGE
1052	MC4-SPLICE	3	
1052	SPLICE-L44	3	HEATER PANEL LIGHT
1052	S5-S6	3	BEACON LT-WORK LT
1052	S6-S7	3	WORK LT-WSHLD WSHR
1052	S7-S8	3	WSHLD WASHER-WIPERS
1052	S8-S21	3	WIPERS-DOME LIGHT
1052	S21-S9	3	DOME LT-B.O.SERV SEL
1052	S9-S10	3	BO SERV SEL-BO MKR
1052	S10-S11	3	B.O. MARKER-B.O. DR
1052	S11-S12	3	B.O. DRIVE-HEADLTS
1052	S12-S16	3	HEADLIGHTS-ENG BK
1052	S16-S14	3	ENG BRAKE-RHEO/DOME
1052	S14-SPLICE	3	RHEOSTAT/DOME
1052	SPLICE-G6	3	VOLTMETER 12V
1052	SPLC-SPLC	3	
1052	SPLICE-G10	3	XMSN OIL TEMP GAUGE
1052	SPLICE-G1	3	WATER TEMP GAUGE
1052	SPLICE-G2	3	OIL PRESSURE GAUGE
1052	SPLICE-G4	3	TACHOMETER
1052	SPLICE-G5	3	SPEEDOMETER
1052	SPLICE-G3	3	FUEL GAUGE

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1052	MC1-SPLICE	3	
1052	SPLICE-L43	3	POST LIGHT
1052	SPLC-MC125	3	
1052	MC125-G12	3	AIR RESTRICTION GA
1052	MC1-SPLICE	3	
1052	MC1-CB1	4	15 AMP HEADLIGHT
1052	MC50-MC1	4	
1055	MC115-M7	5	
1055	M7-1277	5	
1055	M7-1281	5	
1056	MC111-MC32	3	
1056	MC32-MC109	6	CTI POWER MANIFOLD
1057	M20-M20	5	
1057	MC111-MC32	3	
1057	MC32-MC109	6	CTI POWER MANIFOLD
1058	MC32-MC109	6	CTI POWER MANIFOLD
1058	MC111-MC32	3	
1059	MC32-MC109	6	CTI POWER MANIFOLD
1059	MC111-MC32	3	
1061	MC22-MC109	6	CTI POWER MANIFOLD
1061	MC111-MC32	3	
1062	MC32-MC109	6	CTI POWER MANIFOLD
1062	MC111-MC32	3	
1063	MC32-MC109	6	CTI POWER MANIFOLD
1064	MC32-MC109	6	CTI POWER MANIFOLD
1064	MC111-MC32	3	
1065	MC32-MC109	6	CTI POWER MANIFOLD
1065	MC111-MC32	3	
1066	MC32-MC64	6	CTI AUX MANIFOLD
1066	MC110-MC32	3	
1067	MC32-MC64	6	CTI AUX MANIFOLD
1068	MC32-MC64	6	CTI AUX MANIFOLD
1068	MC110-MC32	3	
1070	MC32-MC64	6	CTI AUX MANIFOLD
1070	MC110-MC32	3	
1071	MC110-MC32	3	
1071	MC32-MC64	6	CTI AUX MANIFOLD
1072	R26-R25	3	
1072	MC110-MC32	3	
1072	MC32-MC64	6	CTI AUX MANIFOLD
1073	MC32-MC64	6	CTI AUX MANIFOLD
1073	MC110-MC32	3	
1074	MC110-MC32	3	
1074	R25-CB10	4	
1074	MC32-MC64	6	CTI AUX MANIFOLD
1075	M6-R25	4/3	
1075B	R25-R18	4	
1076	MC110-MC32	3	
1076	MC32-MC64	6	CTI AUX MANIFOLD
1079	CB5-M6	4	HAZARD LIGHTS
1080	MC7-MC2	3	

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1080	MC2-M5	4	TURN SIGNAL/FLASHER
1082	MC2-MC52	4	
1082	MC2-M81	3	
1082	M81-S3	3	
1082	MC52-CB15	4	HEATER
1084	MC1-CB5	4	B.O. LIGHTS
1084	MC4-MC1	3	
1084	MC4-S9	3	
1091	L17-GROUND	3	
1092	L7-MC8	3	
1092	MC8-M51	3	
1093	MC31-MC57	6	
1093	MC1-MC31	3	
1093	MC1-CB16	4	
1093	MC57-S13	6	DRIVE LINE LOCK-UP
1094	S5-S14	3	
1095	R23-R24	4	
1095	MC44-R23	4	
1095	MC31-MC44	3	
1095	MC57-S13	6	DRIVE LINE LOCK-UP
1095	MC31-MC57	6	
1108	MC44-MC8	3	
1108	S05-MC44	4	
1108	MC8-G4	3	TACHOMETER
1113	MC8-MC21	3	
1113	G2-MC8	3	OIL PSI GAUGE
1113	SU3-MC21	5	ENG OIL PSI SNDG UN
1114	M66-MC8	3	
1114	MC96-MC8	3	LOW OIL LEVEL LIGHT
1114	MC8-L36	3	
1114	L36-M66	3	
1118	MC4-1919	3	
1118	S8-MC4	3	
1120	M66-MC8	3	
1120	M66-M3	3	
1120	PS6-PS7	3	
1120	PS6-MC8	3	
1120	L2-M66	3	
1137	M6(1)-M6(2)	5	
1137	M6(3)-M6(4)	5	
1138	M48-M7	5	SHUNT
1138	M7-M23	5	SLAVE
1138	M6-M48	5	SHUNT
1138	M77-M7	5	ARCTIC BATTERIES
1139	M7-M23	5	SLAVE
1139	M6-M7	5	
1139	M77-M7	5	ARCTIC BATTERIES
1147	TS2-MC21	5	ENG WTR TEMP SNDG UN
1147	M39-L8	3	HIGH WATER TEMP
1147	MC8-MC21	3	
1147	MC8-M39	3	
1149	MC1-R10	4	REVERSE
1149	MC3-MC78	6	
1149	MC1-MC124	3	
1149	MC78-MC77	6	REVERSE LIGHT
1149	MC124-MC77	6	

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 4 OF 35
ENGINEERING DWG 1878290 SHEET 2
FP-7/FP-8 BLANK

REVISION V
CN 24138
11-24-92

16

15

14

13

12

10

9

8

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1678	MC78-L22	6	RH B.O. STOP LIGHT
1678	SPLICE-MC3	3	
1678	MC1-R13	4	
1678	SPLICE-MC4	3	
1678	MC4-S9	3	
1678C	MC25-R13	4	B.O. STOP LIGHT
1678C	MC25-MC15	6	TRAILER CONN 24VDC
1679	L15-MC4	3	
1679	MC4-S11	3	
1680	MC3-SPLICE	3	
1680	SPLICE-MC1	3	
1680	SPLC-SPLC	3	
1680	SPLICE-MC4	3	
1680	SPLC-SPLC	3	
1680	SPLC-SPLC	3	
1680	SPLICE-L19	3	
1680	SPLICE-L19	3	
1680	MC3-MC78	6	
1680	MC4-S10	3	
1680	MC78-L24	6	LH B.O. TAIL LIGHT
1680	MC1-R17	4	B.O. LIGHTS
1680	MC78-L22	6	RH B.O. TAIL LIGHT
1680C	MC25-MC15	6	TRAILER CONN 24VDC
1680C	MC25-MC15	6	TRAILER CONN 24VDC
1680C	MC25-R17	4	B.O. TAIL LIGHTS
1680C	MC25-MC15	6	TRAILER CONN 24VDC
1702	MC44-MC34	3	
1702	MC34-G7	3	
1702	MC44-R26	4	
1708	M32-1709	3	PASSENGER AIR HTR
1709	MC58-S19	3	GAS PART FILTER SW
1709	MC58-M30	3	
1710	M31-1709	3	DRIVER AIR HEATER
1711	CB11-R7	4	
1712	MC1-CB7	4	ENGINE BRAKE
1712	MC4-MC1	3	
1713	MC53-L37	3	
1713	MC4-MC1	3	
1713	S16-MC4	3	ENGINE BRAKE
1713	MC1-R7	4	TRANSMISSION
1713	S16-MC53	3	
1714	MC1-1716	4	
1714	MC4-MC1	3	ENGINE BRAKE
1714	S16-MC4	3	ENGINE BRAKE
1715	MC4-MC1	3	ENGINE BRAKE
1715	S16-MC4	3	ENGINE BK RH COILS
1715	MC11-MC1	4	
1715	MC11-M21	5	LH ENGINE BRAKE
1716	MC11-R5	4	RETARDER
1716	MC11-M22	5	RH ENGINE BRAKE
1717	MC44-S20	3	CHEMICAL ALARM SW
1717	MC44-CB19	4	
1718	M76-M77	6	BACK-UP ALARM
1722	MC34-1734	3	

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1722	L26-MC34	3	
1722	MC33-MC84	7	
1722	MC84-MC83	7	
1723	MC44-S18	3	SELF RECOVERY WN SW
1723	MC44-CB18	4	
1724	MC112-SPLC	3	
1724	SPLICE-MC33	3	
1724	MC33-MC93	7	
1724	L27-MC112	3	
1724	M67-SPLICE	3	
1724	SPLC-MC112	3	
1724	M67-MC33	3	
1725	L28-MC112	3	
1725	MC84-MC83	7	
1725	MC33-MC84	7	
1725	MC112-MC33	3	
1726	MC33-MC84	7	
1726	MC84-MC83	7	
1726	MC112-MC33	3	
1726	L29-MC112	3	
1729	MC31-S18	3	SELF RECOVERY WINCH
1729	MC31-MC55	6	
1729	MC55-MC121	6	SELF RECOVERY WINCH
1730	MC31-S18	3	SELF RECOVERY WINCH
1730	MC55-MC122	6	SELF RECOVERY WINCH
1730	MC31-MC55	6	
1731	MC3-S4	3	SELF RECOVERY WINCH
1731	MC3-S4	3	SELF RECOVERY WINCH
1731	MC3-MC29	6	CRANE
1732	MC55-MC123	6	SELF RECOVERY WINCH
1732	S4-MC31	3	SELF RECOVERY WINCH
1732	MC31-MC55	6	
1733	MC31-M67	3	
1733	MC31-M51	6	
1734	M67-SPLICE	3	
1734	SPLC-SPLC	3	
1734	SPLICE-MC31	3	
1734	MC31-M10	6	
1736	MC39-MC39	5	
1737	MC31-MC1	3	
1737	MC1-R22	4	CRANE HI IDLE
1737	MC31-MC29	6	CRANE
1738	MC44-1755	4	
1738	MC44-MC31	3	
1738	MC31-MC29	6	CRANE
1739	MC44-CB21	4	

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1739	MC44-S19	3	GAS PARTICULATE SW
1744	S4-M67	3	
1745	MC103-S20	3	CHEMICAL ALARM
1746	MC103-M29	3	CHEMICAL ALARM
1747	MC103-M29	3	CHEMICAL ALARM
1755	MC84-MC83	7	
1755	MC44-CB18	4	
1755	MC33-MC84	7	
1755	MC33-MC44	3	
1765	MC3-MC113	6	
1765	L35-MC8	3	
1765	MC3-MC8	3	
1809	MC41-MC65	5	PULSE TACH DRIVE
1809	MC65-MC39	5	STE/ICE
1809	MC41-M40	5	PULSE TACH DRIVE
1810	MC65-MC39	5	STE/ICE
1810	MC41-M40	5	PULSE TACH DRIVE
1810	MC41-MC65	5	PULSE TACH DRIVE
1811	MC42-M41	5	DIFFERENTIAL PSI
1811	MC42-MC39	5	STE/ICE
1812	MC42-M41	5	DIFFERENTIAL PSI
1812	MC42-MC39	5	STE/ICE
1813	MC39-M6	5	
1814	MC39-M6	5	BATTERIES
1815	MC39-MC24	5	
1815	MC24-MC114	5	
1815	MC24-M20	5	
1816	MC39-MC65	5	STE/ICE
1816	MC39-M7	5	STARTER

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1818	MC39-M7	5	STARTER
1818	MC39-MC65	5	STE/ICE
1819	MC39-M7	5	
1820	MC24-M20	5	
1820	MC24-M20	5	
1820	MC39-MC24	5	
1821	MC39-M6	5	
1822	MC39-M6	5	BATTERIES
1824	SPLICE-MC67	5	
1824	MC66-M70	5	
1824	MC68-M72	5	
1824	SPLICE-MC70	5	
1824	SPLICE-MC71	5	
1824	MC65-MC39	5	STE/ICE
1824	SPLICE-MC68	5	
1824	MC67-M71	5	
1824	MC43-M42	5	FUEL PSI
1824	MC69-M73	5	
1824	MC70-M74	5	
1824	MC71-M75	5	
1824	SPLICE-MC69	5	
1824	MC66-SPLICE	5	
1824	SPLICE-MC65	5	
1824	SPLICE-MC43	5	
1825	MC68-MC69	5	
1825	MC70-MC71	5	
1825	MC65-MC43	5	
1825	MC43-MC67	5	
1825	MC67-MC68	5	
1825	MC70-M74	5	
1825	MC69-MC70	5	
1825	MC41-MC65	5	
1825	MC68-M72	5	
1825	MC66-M70	5	TURBO OUTLET PSI
1825	MC65-MC39	5	STE/ICE
1825	MC69-M73	5	
1825	MC67-M71	5	
1825	MC39-MC40	5	STE/ICE MODULE
1825	MC43-M42	5	FUEL PSI
1825	MC71-M75	5	
1825A	MC39-MC40	5	STE/ICE MODULE
1826	MC40-MC39	5	
1827	MC40-MC39	5	
1828	MC39-M48	5	SHUNT
1829	MC39-M48	5	SHUNT
1835	R2-CB2	4	
1839	R7-R8	4	
1860	MC39-MC24	5	
1860	MC24-MC114	5	
1861	MC24-MC114	5	

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 6 OF 35
ENGINEERING DWG 1878290 SHEET 2
FP-11/FP-12 BLANK

16

15

14

13

12

10

9

8

REVISION P
CN 23873
5-14-92

28 27 26 25 24 23 22 21 20

H
G
F
E
D
C
B
A





FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 8 OF 35
ENGINEERING DWG 1878290 SHEET 3
FP-15/FP-16 BLANK

28 27 26 25 24 23 22 21 20

REVISION P
CN 23873
5-14-92



LH TURN L11
HIGH BEAM L10
LOW OIL PSI L9
HIGH WATER TEMP L8
TRANS CHECK L5

SPEEDOMETER G5
TACH G4
FUEL GAUGE G3
OIL PRESSURE GAUGE G2
WATER TEMP GAUGE G1
XMSN OIL TEMP GAUGE G10
VOLTMETER 12V G6
VOLTMETER 24V G7

AIR RESTRICTION GAUGE G12
AIR PRESSURE GAUGE G11

AC M39
AC M39
LOW OIL PSI/HI WATER TEMP ALARM CONTINUOUS TONE M18
CTI CONTROLLER M28

LHS OVERLOAD L29
NO TRANSIT L28
AUXILLARY HYDRAULIC L27
LOAD HANDLING SYSTEM L26
FLAT RACK L38
ENGINE BRAKE L37

WHITE MC8 GAUGES

POS	CODE
A	1519
B	1519
C	1435
D	1147
E	1318
F	1320
G	1449
H	1113
I	1765
J	1114
K	1108
L	439
M	419
N	1409
O	1001
P	509
R	1120
S	1371
T	1018
U	1032
V	1092

MC105

POS	CODE
1	1435
2	
3	1884
4	1885

MC35

POS	CODE
1	1519
2	1519
3	
4	
5	PLUG
6	
7	1435
8	1435
9	
10	1880

MC110

POS	CODE
1	1072
2	1073
3	1076
4	1071
5	PLUG
6	1070
7	1066
8	SHIELD
9	1068
10	1074

MC111

POS	CODE
1	1056
2	1057
3	1058
4	1059
5	PLUG
6	1061
7	1062
8	SHIELD
9	1064
10	1065

MC32

POS	CODE
A	1056
B	1063/1067
C	1065
D	PLUG
E	1074
F	1076
G	1072
H	1071
I	1070
J	1068
K	SHIELD
L	PLUG
M	1066
N	1061
O	1058
P	1064
Q	1062
R	1059
S	SHIELD
T	1057
U	1073
V	PLUG

CAB ← CHASSIS

MC31

POS	CODE
A	
B	
C	
D	1435
E	1435
F	
G	
H	
I	
J	1729
K	1730
L	1734
M	1733
N	1732
O	
P	1738
Q	1737
R	1095
S	1093
T	1928
U	1929
V	1435

SEE SHEET 6 CHASSIS

MC33

POS	CODE
A	1755
B	1435
C	1722
D	1724
E	1725
F	1726

SEE SHEET 7 LHS

MC34

POS	CODE
A	
B	
C	1702
D	1928
E	1929
F	1722

DASH ← CAB

MC112

POS	CODE
A	1724
B	1725
C	1726
D	
E	
F	1435

DASH ← CAB

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 9 OF 35
ENGINEERING DWG 1878290 SHEET 3
FP-17/FP-18 BLANK

REVISION P
CN 23873
5-14-92




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 10 OF 35
ENGINEERING DWG 1878290 SHEET 3
FP-19/FP-20 BLANK

REVISION P
CN 23873
5-14-92




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC FOLDOUT 11 OF 35 ENGINEERING DWG 1878290 SHEET 3 FP-21/FP-22 BLANK

REVISION AA
CN 24575
9-9-94




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 12 OF 35
ENGINEERING DWG 1878290 SHEET 4
FP-23/FP-24 BLANK

REVISION AA
CN 24575
9-9-94




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 13 OF 35
ENGINEERING DWG 1878290 SHEET 4
FP-25/FP-26 BLANK

SEE SHEET 3
ZONE 9E




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 14 OF 35
ENGINEERING DWG 1878290 SHEET 4
FP-27/FP-28 BLANK

REVISION AA
CN 24575
9-9-94




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 15 OF 35
ENGINEERING DWG 1878290 SHEET 5
FP-29/FP-30 BLANK




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 16 OF 35
ENGINEERING DWG 1878290 SHEET 5
FP-31/FP-32 BLANK




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 17 OF 35
ENGINEERING DWG 1878290 SHEET 5
FP-33/FP-34 BLANK




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 18 OF 35
ENGINEERING DWG 1878290 SHEET 6
FP-35/FP-36 BLANK




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 19 OF 35
ENGINEERING DWG 1878290 SHEET 6
FP-37/FP-38 BLANK




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 20 OF 35
ENGINEERING DWG 1878290 SHEET 7
FP-39/FP-40 BLANK

REVISION U
CN 23966
12-1-92






FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 21 OF 35
 ENGINEERING DWG. 1878290 SHEET 7
 FP-41/FP-42 BLANK

EMI SHIELDED WIRES




MC83	
POS	CODE
A	1482
B	1481
C	1486
D	1480
E	1755
F	1435
G	1483
H	1484
J	1485
K	1722
L	1487
M	1488
N	1489
P	1490
R	1726
S	1725
T	---

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 22 OF 35
 ENGINEERING DWG 1878290 SHEET 8
 FP-43/FP-44 BLANK



MC81	
POS	CODE
A	1465
B	1467
C	1468
D	1464
E	1466
F	1472
G	1469
H	1463
J	1462
K	1435
L	1435
M	1471
N	1460
P	1459
R	1435
S	1435
T	-

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 23 OF 35
 ENGINEERING DWG 1878290 SHEET 8
 FP-45/FP-46 BLANK



POWER CABLE TO VEHICLE

POS	CODE	WHT	GRN	BLK	RED	SHIELD
A	WHT					
B	GRN					
C	BLK					
D	RED					
E	SHIELD					

PASSENGER SIDE REMOTE CABLE

POS	CODE	RED	GRN	YEL	WHT	BLU	BLK	ORG	VIO	RED/GRN	GRY	TAN	BRN	SHIELD
A	RED													
B	GRN													
C	YEL													
D	WHT													
E	BLU													
F	BLK													
G	ORG													
H	VIO													
J	RED/GRN													
K	GRY													
L	TAN													
M	BRN													
N	PNK													
P	SHIELD													

OVERLOAD SHUTDOWN SYSTEM

POS	CODE	BLK	WHT	GRN	RED
A	BLK				
B	WHT				
C	GRN				
D	RED				


OVERLOAD SHUTDOWN SYSTEM (continued)

POS	CODE	BLU	BLK	BRN
A	BLU			
B	BLK			
C	BRN			

OVERLOAD SHUTDOWN SYSTEM (continued)

POS	CODE	WHT	BLK	RED	GRN	SHIELD
A	WHT					
B	BLK					
C	RED					
D	GRN					
E	SHIELD					

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 24 OF 35
 ENGINEERING DWG 1878290 SHEET 9
 FP-47/FP-48 BLANK



JUNCTION BOX ASSY

REMOTE CONTROL BOX

DRIVER SIDE O/R ENGAGED SENSING SWITCH

POWER SWITCH 10 AMP MAGNETIC CIRCUIT BREAKER

HIGH IDLE SWITCH LATCH-UNLATCH

DRIVER SIDE REMOTE CABLE

REMOTE CONTROL CABLE

PASSENGER SIDE O/R ENGAGED SENSING SWITCH

O/R MAST SHUTDOWN SOLENOID

SWING	
POS	CODE
1	RED
2	GRN
3	WHT
4	BLU

TELE	
POS	CODE
1	RED
2	GRN
3	WHT
4	BLU

BOOM	
POS	CODE
1	RED
2	GRN
3	WHT
4	BLU


HOIST	
POS	CODE
1	RED
2	GRN
3	WHT
4	BLU

POS	CODE
A	RED
B	GRN
C	YEL
D	WHT
E	BLU
F	BLK
G	ORG
H	VIO
J	RED/GRN
K	GRY
L	TAN
M	BRN
N	PNK
P	SHIELD

POS	CODE
A	RED
B	GRN
C	YEL
D	WHT
E	BLU
F	BLK
G	ORG
H	VIO
J	RED/GRN
K	GRY
L	TAN
M	BRN
N	PNK
P	SHIELD

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLIOUT 25 OF 35
 ENGINEERING DWG 1878290 SHEET 9
 FP-49/FP-50 BLANK

REVISION F
CN 24526
3-28-94



- NOTES:
1. A DASHED LINE WITH A LARGE ARROW SIGNIFIES A HARD CONNECTION DIRECTLY TO THE COMPONENT (WITH A TEE FITTING). THIS SYMBOL DOES NOT REPRESENT THE PRESENCE OF NYLON TUBING.
 2. SEE OOD-STD-100 FOR DRAWING INTERPRETATION STANDARDS
 3. PARENTHETICAL IDENTITIES ARE FOR REFERENCE ONLY

FIGURE FO-2. AIR SYSTEM SCHEMATIC
FOLDOUT 26 OF 35
ENGINEERING DWG 1878300 SHEET 1
FP-51/FP-52 BLANK

REVISION D
CN 24303
6-25-93





FIGURE FO-2. AIR SYSTEM SCHEMATIC
FOLIOUT 27 OF 35
ENGINEERING DWG 1878300 SHEET 1
FP-53/FP-54 BLANK

REVISION D
CN 24303
6-25-93



SEE SHEET 2
(CTI REAR MANIFOLD)
SEE SHEET 2
(CTI FRONT MANIFOLD)

FIGURE FO-2. AIR SYSTEM SCHEMATIC
FOLDOUT 28 OF 35
ENGINEERING DWG 1878300 SHEET 1
FP-55/FP-56 BLANK




FIGURE FO-2. AIR SYSTEM SCHEMATIC
FOLDOUT 29 OF 35
ENGINEERING DWG 1878300 SHEET 2
FP-57/FP-58 BLANK

REVISION B
CN 23468
8-8-91




FIGURE FO-2. AIR SYSTEM SCHEMATIC
FOLDOUT 30 OF 35
ENGINEERING DWG 1878300 SHEET 2
FP-59/FP-60 BLANK




FIGURE FO-3. HYDRAULIC SYSTEM SCHEMATIC
 FOLDOUT 31 OF 35
 ENGINEERING DWG 1878310 SHEET 1
 FP-61/FP-62 BLANK




FIGURE FO-3. HYDRAULIC SYSTEM SCHEMATIC
FOLDOUT 32 OF 35
ENGINEERING DWG 1878310 SHEET 1
FP-63/FP-64 BLANK




FIGURE FO-3. HYDRAULIC SYSTEM SCHEMATIC
FOLDOUT 33 OF 35
ENGINEERING DWG 1878310 SHEET 1
FP-65/FP-66 BLANK




FIGURE FO-3. HYDRAULIC SYSTEM SCHEMATIC
FOLDOUT 34 OF 35
ENGINEERING DWG 1878310 SHEET 2
FP-67/FP-68 BLANK




FIGURE FO-3. HYDRAULIC SYSTEM SCHEMATIC
FOLDOUT 35 OF 35
ENGINEERING DWG 1878310 SHEET 2
FP-69/FP-70 BLANK

SCHEMATICS

Section II. 200 AMP ALTERNATOR AND DDEC III/IV ENGINE.

Section II contains the schematics for trucks equipped with the 200 amp alternator and the DDEC III/IV engine.

MULTIPLE CONNECTORS			
NUMBER	ZONE	SH	DESCRIPTION
MC1	H3	3	CAB/ELECTRICAL BOX
MC1	C26	4	CAB/ELECTRICAL BOX
MC2	D3	3	CAB/ELECTRICAL BOX
MC2	D26	4	CAB/ELECTRICAL BOX
MC3	C3	3	CHASSIS
MC3	H17	6	CHASSIS
MC4	G10	3	SWITCHES
MC5	B12	3	WIPER MOTOR
MC6	D15	3	THROTTLE SENSOR
MC7	H8	3	TURN SIGNAL
MC8	F19	3	GAUGES
MC9	G4	4	ECU ATEC
MC10	G4	4	ECU ATEC
MC11	D3	4	DDEC
MC11	D26	5	DDEC
MC12	H26	4	SHIFT CONT ATEC
MC13	F6	3	DIGN CONN DDEC
MC14	B4	4	DDEC SIGNAL GROUND
MC15	B4	6	MILITARY CONNECTOR
MC16	D4	6	TRAILER
MC17	G11	5	DDEC
MC18	E11	5	DDEC
MC19	E13	5	TRANSMISSION
MC20	E12	5	TRANSMISSION
MC21	E2	3	ENGINE SENSOR
MC21	H26	5	ENGINE SENSOR
MC23	B23	5	ETHER START
MC24	G19	5	ALTERNATOR
MC25	C17	6	TRAILER 24VDC
MC27	F18	6	FRONT TOW
MC28	E6	3	BEACON LIGHT
MC29	F8	6	CRANE
MC30	C5	6	TRAILER
MC31	B21	3	CAB/CHASSIS
MC32	B23	3	CTI CHASSIS
MC33	F17	7	LHS CAB
MC34	C19	3	24V METERS
MC35	D24	3	CTI
MC36	A5	4	THROTTLE SENSOR
MC38	C15	3	VERNIER CONTROL
MC39	H7	5	STE/ICE
MC40	G5	5	STE/ICE MODULE
MC41	G2	5	PULSE TACH DRIVE
MC42	H4	5	DIFFERENTIAL PRESS
MC43	F2	5	FUEL PRESSURE
MC44	C5	3	CAB/TRANSMISSION
MC44	F26	4	CAB/TRANSMISSION
MC45	D5	4	ECU ATEC

MULTIPLE CONNECTORS			
NUMBER	ZONE	SH	DESCRIPTION
MC50	C7	4	RELAYS/ATEC
MC51	C6	4	ECU ATEC
MC52	B23	4	HEATER/DIMMER
MC53	F23	3	ENGINE BRAKE
MC54	F8	6	WORK LIGHT
MC55	B13	6	SELF RECOVERY WINCH
MC56	C23	5	ETHER THERMOSTAT
MC57	F6	6	DRIVE LINE LOCK
MC58	E7	3	GAS PART FILTER
MC59	G13	6	FAN CONTROL
MC60	G24	5	REVERSE PLRT PROTR
MC61	G10	6	FAN CONTL WTR TEMP
MC62	F13	5	DDEC ENGINE POWER
MC63	G11	6	FAN CONTROL
MC64	D15	6	AUXILIARY CTI MANF
MC65	E5	5	STE/ICE ENGINE
MC66	G2	5	TURBO OUTLET PSI
MC67	E2	5	AIR CLEANER
MC68	D2	5	AIR BOX PSI
MC69	D2	5	FUEL RETURN
MC70	C2	5	ENGINE OIL TEMP
MC71	B2	5	ENGINE WATER TEMP
MC73	F13	6	FAN CONTROL
MC76	F11	6	FAN CONTROL VALVE
MC77	E3	6	BACK UP LIGHT
MC78	F4	6	REAR LIGHT GROUP
MC79	G7	6	WORK LIGHT
MC80	G4	6	REAR LIGHT GROUP
MC81	E13	7	LHS
MC82	E12	7	LHS
MC83	E14	7	LHS
MC84	E15	7	LHS
MC85	E9	7	LHS
MC86	E7	7	LHS
MC87	D5	7	LHS
MC88	E6	7	LHS
MC90	C3	6	REAR LIGHT GP HARN
MC91	G8	3	STRN COL. -CAB HARN
MC92	F8	3	STRG COL. -CAB HARN
MC93	C17	7	LHS
MC94	B17	7	LHS
MC95	B15	5	DDEC BATTERY POWER
MC96	C2	3	LOW HYD OIL
MC97	B10	6	AIR DRYER
MC98	B9	6	AIR DRYER
MC99	B8	6	AFTER COOLER
MC102	A3	4	DDEC 6.8K RESISTOR
MC103	E5	3	CHEM DETECTOR
MC104	E5	3	CHEM ALARM

MULTIPLE CONNECTORS			
NUMBER	ZONE	SH	DESCRIPTION
MC105	E24	3	CTI ACCESS OUTPUT
MC106	H4	3	DDEC DIAGNOSTIC
MC107	D6	6	FUEL WATER SEP
MC108	C20	5	FUEL PUMP
MC109	C15	6	CTI POWER MANIFOLD
MC110	C24	3	CTI AUX MANF CAB
MC111	B24	3	CTI POWER MANF CAB
MC112	B19	3	LHS LIGHTS
MC113	F16	6	EMERGENCY STEER SW
MC116	B12	4	EMER ENG SHUT DOWN
MC118	A9	5	STE/ICE
MC119	B22	4	ARCTIC PUMP
MC120	B7	6	ARCTIC PUMP
MC121	C12	6	SELF RECOVERY WINCH
MC122	D12	6	SELF RECOVERY WINCH
MC123	D12	6	SELF RECOVERY WINCH
MC124	E3	6	BACK-UP LIGHT/ALARM
MC125	G18	3	AIR RESTRICTION LT
MC126	E11	3	STOP LIGHTS
MC127	B15	3	THROTTLE POSN SW
MC128	G10	6	AUX WATER TEMP SW

LIGHTS			
NUMBER	ZONE	SH	DESCRIPTION
L1	G16	3	PARKING BRAKE IND
L2	G17	3	LOW AIR INDICATOR
L3	G17	3	CHECK GAUGES IND
L4	G17	3	RH TURN INDICATOR
L5	G24	3	TRANS CHECK IND
L6	G18	3	CHECK ENGINE IND
L7	G17	3	DRIVE LINE LOCK IND
L8	G24	3	HI WATER TEMP IND
L9	G24	3	LOW OIL PSI IND
L10	G25	3	HI BEAM INDICATOR
L11	G28	3	LH TURN INDICATOR
L12	F27	3	RH HEADLIGHT
L13	G27	3	RH SIDE TURN SIGNAL
L14	F27	3	RH COMPOSITE
L15	E27	3	BLACKOUT DRIVE
L16	D27	3	LH COMPOSITE
L17	C27	3	LH HEADLIGHT
L18	C27	3	LH SIDE TURN SIGNAL
L19	B27	3	ID & CLEARANCE
L20	H10	3	DOME
L21	G7	6	RH WORK LIGHT
L22	G2	6	RH REAR COMPOSITE
L23	G2	6	BACK UP
L24	F2	6	LH REAR COMPOSITE
L25	C2	6	ID/CLEARANCE REAR
L26	E22	3	AUXILLARY HYDR IND
L27	E22	3	AUXILLARY HYDR IND
L28	E23	3	TRANSIT INDICATOR
L29	E23	3	LHS OVERLOAD IND
L31	D2	6	RH REAR S MKR (RED)
L32	H4	6	RH SIDE MKR (AMBER)
L33	B2	6	LH SIDE MKR (AMBER)
L34	H4	6	LH REAR S MKR (RED)
L35	G16	3	EMERGENCY STEERING
L36	G16	3	LOW HYD OIL
L37	D21	3	ENGINE BRAKE
L38	D21	3	FLAT RACK
L39	F7	6	LH WORK LIGHT
L40	F7	3	T.C. LOCKUP
L41	C2	6	L.H. B.O. CL LIGHT
L42	D2	6	R.H. B.O. CL LIGHT
L43	B5	3	POST LIGHT
L44	F5	3	HEATER PANEL LIGHT

SWITCHES			
NUMBER	ZONE	SH	DESCRIPTION
S1	H6	3	TURN SIGNAL/DIMMER
S2	E13	3	IGNITION
S3	F5	3	HEATER
S4	D8	3	SELF RECOVERY CRANE
S5	H12	3	BEACON LIGHT
S6	H13	3	WORK LIGHT
S7	H14	3	WINDSHIELD WASHER
S8	G15	3	WINDSHIELD WIPER
S9	F16	3	BLACK OUT SVCE SEL
S10	F54	3	BLACK OUT MARKER
S11	F14	3	BLACK OUT DRIVE
S12	F14	3	HEADLIGHTS
S13	F5	6	DRIVE LINE LOCK
S14	F12	3	RHEOSTAT
S15	F7	3	HORN
S16	F13	3	ENGINE BRAKE
S17	F7	3	DIAGNOSTIC REQUEST
S18	D7	3	SELF RECOVERY WINCH
S19	D6	3	GAS PARTIULATE FLTR
S20	D5	3	CHEMICAL ALARM
S21	H15	3	DOME LIGHT
S22	C8	5	STE/ICE ZEROING
S23	C22	7	PROX SW HOOK ARM UP
S24	C23	7	PROX SW MDL FR DOWN
S25	D13	3	ETHER START
S26	F7	3	TC LOCKUP
S27	E5	7	HOOK ARM DOWN
S28	G8	7	OVERLOAD PSI
S29	B19	4	ARCTIC PUMP
S30	E9	3	EMER ENG SHUT DOWN
S31	C16	3	THROTTLE POSITION
S32	C17	5	BATTERY DISCONNECT
PRESSURE SWITCHES			
NUMBER	ZONE	SH	DESCRIPTION
PS1	G9	3	FRONT BRAKE
PS2	F9	3	REAR BRAKE
PS3	F9	3	HAND BRAKE
PS4	C14	3	PARKING BRAKE
PS5	B15	3	PARKING BRAKE SW
PS6	D17	3	LOW AIR PRESSURE
PS7	D17	3	LOW AIR PRESSURE
PS8	C22	5	ATEC OIL PRESSURE
PS9	D22	5	ENGINE OIL
PS10			GOVERNOR PRESSURE
PS11			GOVERNOR PRESSURE
PS13	F15	6	EMERGENCY STEER
PS12	D23	5	ALTER. OIL PRESSURE
PS15	F26	5	BOOST PRESSURE

TEMPERATURE SWITCHES			
NUMBER	ZONE	SH	DESCRIPTION
TS1	C23	5	ETHER START
TS2	D23	5	ENGINE WATER
TS3	F10	6	ENGINE WATER
TS4	G10	6	ENGINE WATER
RELAYS			
NUMBER	ZONE	SH	DESCRIPTION
R1	G24	4	HEADLIGHTS
R2	G23	4	ID/CLEARANCE LIGHTS
R3	G22	4	HORN
R4	G21	4	WORK LIGHTS
R5	G20	4	DIMMER
R6	G19	4	BEACON LIGHTS
R7	G18	4	TRANSMISSION
R8	G18	4	RATARDER
R9	G18	4	CK TRANSMISSION
R10	G17	4	REVERSE
R11	G16	4	NEUTRAL START
R12	G15	4	12 V MAG SWITCH
R13	G15	4	B.O. STOP
R14	G14	4	BO SERVICE TAIL LTS
R15	G13	4	LH TURN SIGNAL
R16	G12	4	RH TURN SIGNAL
R17	G12	4	BLACK OUT TAIL LTS
R18	G11	4	DDEC
R19	G10	4	TRANS DDEC
R20	G9	4	INTER AXLE
R21	G9	4	DIFFERENTIAL LOCK
R22	G8	4	CRANE HI IDLE
R23	G7	4	HIGH RANGE LOCKOUT
R24	G6	4	T.C. DUAL MODE
R25	B17	4	MAGNETIC SWITCH
R26	B18	4	MAGNETIC SWITCH
R27	D19	5	MAGNETIC SWITCH
R28	C21	4	MAGNETIC SWITCH
R29	C10	7	MIDDLE FR LOCKOUT
SENDING UNIT			
NUMBER	ZONE	SH	DESCRIPTION
SU1	E21	5	WATER TEMPERATURE
SU2	D21	5	TRANSMISSION TEMP
SU3	D21	5	ENGINE OIL PRESSURE
SU4	F6	6	SPEEDOMTER
SU5	D6	6	FUEL LEVEL

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 1 OF 26
ENGINEERING DWG 3053493 SHEET 1
FP-1/FP-2 BLANK

CIRCUIT BREAKERS			
NUMBER	ZONE	SH	DESCRIPTION
CB1	D22	4	15 AMP
CB2	D22	4	15 AMP
CB3	D21	4	15 AMP
CB4	D21	4	15 AMP
CB5	D20	4	20 AMP
CB6	D20	4	15 AMP
CB7	D19	4	10 AMP
CB8	D19	4	15 AMP
CB9	D18	4	10 AMP
CB10	D17	4	3 AMP
CB11	D16	4	8 AMP
CB12	D16	4	8 AMP
CB13	D15	4	8 AMP
CB14	D14	4	15 AMP
CB15	D13	4	15 AMP
CB16	D12	4	15 AMP
CB17	D12	4	3 AMP
CB18	D11	4	10 AMP
CB19	D10	4	15 AMP
CB20	D9	4	15 AMP
CB21	D9	4	30 AMP
CB22	D7	4	20 AMP
CB23	D7	4	20 AMP
CB24	C20	5	3 AMP
CB25	A14	4	15 AMP
CB26	A13	4	15 AMP
GAUGES			
NUMBER	ZONE	SH	DESCRIPTION
G1	G20	3	WATER TEMPERATURE
G2	G21	3	OIL PRESSURE
G3	G22	3	FUEL LEVEL
G4	G22	3	TACHOMETER
G5	G23	3	SPEEDOMETER
G6	G19	3	VOLTMETER 12V
G7	G19	3	VOLTMETER 24V
G10	G20	3	XMSN OIL TEMP
G11	G18	3	AIR PRESSURE
G12	H18	3	AIR RESTRICTION

MISCELLANEOUS			
NUMBER	ZONE	SH	DESCRIPTION
M1	B6	3	WINDSHIELD WSHR SOL
M2	B13	3	WIPER MOTOR
M3	E17	3	LOW OIL & AIR ALARM
M4	A5	4	THROTTLE POSN CONT
M5	C20	4	FLASHER
M6	C16	5	BATTERIES
M7	E17	5	STARTER
M8	B22	5	ETHER START
M9	D6	6	FUEL/WATER SEP
M10	C10	6	LHS SOLENOID VALVE
M11	C8	6	AFTERCOOLER
M12	C20	5	FUEL PUMP
M13	B10	6	AIR DRYER
M14	E6	3	CHEMICAL DETECTOR
M14	B9	6	AIR DRYER
M15	D1	3	HORN
M16	D16	3	VERNIER CONTROL
M17	F5	3	HEATER MOTOR
M18	F24	3	LOW OIL PRESS ALARM
M20	G22	5	ALTERNATOR, STD
M21	C25	5	RH SIDE ENG BK COIL
M22	C24	5	LH SIDE ENG BK COIL
M23	D18	5	SLAVE CONNECTER
M24	B15	6	CTI POWER MANIFOLOD
M25	D15	6	CTI AUXILIARY MANF
M26	E13	7	LHS CAB CONTROLLER
M27	B13	6	SELF RECOVERY WINCH
M28	E25	3	CTI CONTROLLER
M29	G14	7	CHEMICAL ALARM
M30	D11	3	GAS PART FILTER
M31	D11	3	AIR HEATER DRIVER
M32	D12	3	AIR HEATER PASS
M33	D3	7	SRW SOLENOID VALVE
M35	E15	3	THROTTLE POSITIONER
M36	C9	4	DIODE
M39	F9	4	RECTIFIER
M40	G2	5	PULSE TACH DRIVE
M41	H5	5	DIFFERENTIAL PRESS
M42	F2	5	FUEL PRESSURE
M43	G5	5	STE/ICE MODULE
M45	F10	6	FAN CONTROL VALVE
M48	D16	5	SHUNT
M49	B9	3	XFR CASE LKUP SOL
M50	B8	3	INTER AXLE SOL V
M51	B8	3	DIFF SOLENOID VALVE
M51	C11	6	FAN
M52	A21	4	RECTIFIER
M53	G11	7	LHS HOOK ARM B
M54	G10	7	LHS HOOK ARM A
M55	G10	7	LHS MAIN CYLINDER B
M56	G10	7	LHS MAIN CYLINDER A

MISCELLANEOUS			
NUMBER	ZONE	SH	DESCRIPTION
M57	G9	7	LHS FREEFLOW
M58	G9	7	LHS TRANSIT
M59	F3	7	LHS LH HOOK ARM A
M60	F3	7	LHS LH HOOK ARM B
M61	F2	7	LHS RH HOOK ARM A
M62	F2	7	LHS RH HOOK ARM B
M64	C19	5	POLARITY PROTECTION
M66	G16	3	RECTIFIER
M67	C8	3	RECTIFIER
M68	G12	7	RECTIFIER
M70	F2	5	TURBO OUTLET PSI
M71	E2	5	AIR CLEANER
M72	D2	5	AIR BOX PSI
M73	C2	5	FUEL RETURN
M74	C2	5	ENGINE OIL TEMP
M75	B2	5	ENGINE WATER TEMP
M76	E10	4	RECTIFIER
M77	B17	5	ARCTIC BATTERIES
M78	E2	6	BACK-UP ALARM
M80	B7	6	ARCTIC PUMP
M81	F4	3	RECTIFIER
M83	F3	10	LHS FUSE - 5 AMP

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
104	MC36-M4	4	THROTTLE SENSOR
104	MC10-MC36	4	THROTTLE SENSOR
105	MC10-MC19	4/5	ATEC
106A	MC10-MC36	4	THROTTLE SENSOR
106A	MC36-M4	4	THROTTLE SENSOR
106A	MC10-106B	4/5	ATEC
106B	106A-MC19	4/5	ATEC
107	MC10-MC19	4/5	ATEC
108	MC10-MC19	4/5	ATEC
109	MC10-MC19	4/5	ATEC
110	MC10-MC19	4/5	ATEC
111	MC10-MC19	4/5	ATEC
112	MC10-MC20	4/5	ATEC
113	MC10-MC20	4/5	ATEC
114	MC10-MC19	4/5	ATEC
115	MC11-MC18	5	ECM
115	MC11-MC102	4	6.8K RESISTOR
115	MC10-MC19	4/5	ATEC
116	MC10-MC19	4/5	ATEC
117	MC10-MC19	4/5	ATEC
118	MC10-MC19	4/5	ATEC
119	MC10-MC19	4/5	ATEC
120	MC10-MC19	4/5	ATEC
121	MC10-MC19	4/5	ATEC
122	MC10-MC19	4/5	ATEC
123	MC10-MC19	4/5	ATEC
124	MC36-M4	4	THROTTLE SENSOR
124	MC10-MC36	4	THROTTLE SENSOR
150	MC62-MC62	5/4	
150	MC17-MC62	5	
195	MC5-M2	3	
201	MC51-GROUND	4	
201	MC9-MC51	4	
202A	MC9-SPLICE	4	
203	MC9-MC51	4	
203	MC51-CB12	4	
204	MC9-MC12	4	ATEC
206	MC9-MC12	4	ATEC
207A	MC51-MC106	4	ATEC
207A	MC9-MC51	4	ATEC
207A	MC106-MC13	4	
208/209	MC11-SPLICE	4	
208/209	SPLICE-MC51	4	
208/209	M6-MC95	5	
208/209	MC95-MC11	5	
208/209	MC51-MC9	4	
210A	MC9-MC12	4	
211	R8-MC50	4	
211	MC50-R8	4	RETARDER
211	MC9-MC50	4	

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
212	MC9-MC12	4	
213	MC50-R8	4	RETARDER
213	MC9-MC50	4	
214	MC50-R10	4	REVERSE
214	MC9-MC50	4	
215	MC9-MC50	4	
215	MC50-R9	4	CHECK TRANSMISSION
216A	MC106-MC13	3	
216A	MC9-MC51	4	ATEC
216A	MC51-MC106	4	ATEC
218	MC9-MC12	4	ATEC
219	MC9-MC12	4	ATEC
220	MC9-MC12	4	ATEC
221	MC9-MC12	4	ATEC
222	MC9-GROUND	4	ATEC
223A	MC51-CB14	4	TRANSMISSION
223A	MC51-SPLICE	4	
223A	SPLC-SPLC	4	
223A	SPLC-SPLC	4	
223A	SPLICE-MC9	4	
223B	MC12-SPLICE	4	
225	CB11-MC12	4	
230	MC12-234	4	
231	MC50-MC12	4	
231	MC50-R22	4	CRANE HI IDLE
231	MC50-M36	4	
231	M36-R11	4	NEUTRAL START
233	MC50-MC12	4	
234	MC12-GROUND	4	
240	MC62-CB23	5/4	
240	CB23-M6	4/5	
240	MC17-MC62	5	
240	MC62-M6	5	
241	MC62-CB22	5/4	
241	MC62-M6	5	
241	MC17-MC62	5	
241	CB22-M6	4/5	
309	MC45-R24	4	TC DUAL MODE
313	MC45-R24	4	TC DUAL MODE
315	MC45-R24	4	TC DUAL MODE
417	MC6-M35	3	
417	MC11-MC44	4	
417	MC11-MC18	5	ECM
417	MC44-MC6	3	THROTTLE SENSOR
419	MC11-MC18	5	ECM
419	MC11-MC44	4	
419	MC44-MC8	3	
419	MC8-L6	3	CHECK ENGINE LIGHT

REVISION D
CN 15194
12/23/97

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 2 OF 26
ENGINEERING DWG 3053493 SHEET 1
FP-3/FP-4 BLANK

REVISION D
CN 15194
12/23/97

CODE SORT				CODE SORT				CODE SORT			
CODE	ROUTING	SH	DESCRIPTION	CODE	ROUTING	SH	DESCRIPTION	CODE	ROUTING	SH	DESCRIPTION
439	MC116-MC106	4	EMERGENCY ENG STOP	1001	MC7-SPLICE	3		1008	MC27-MC3	6	FRONT TOW
439	MC116-S30	3	EMERGENCY ENG STOP	1001	MC8-SPLICE	3		1008	MC3-SPLICE	3	
439	MC116-S30	3	EMERGENCY ENG STOP	1001	SPLICE-L13	3		1008	MC3-MC4	3	
439	MC116-CB13	4	DDEC	1001	SPLICE-L14	3		1008	MC3-MC16	6	TRAILER CONN 12VDC
439	MC106-MC13	3		1001	S1-MC7	3	RH HEADLIGHT	1008	MC78-L22	6	RH TAIL LIGHT
439	SPLC-MC106	4		1002	S1-MC7	3	LH HEADLIGHT	1008	MC78-L24	6	LH TAIL LIGHT
439	MC11-MC18	5	ECM	1002	MC8-L11	3		1008C	MC25-MC15	6	TRAILER CONN 24VDC
439	MC8-L6	3	CHECK ENGINE LIGHT	1002	MC7-SPLICE	3		1008C	MC25-R14	4	B.O. SERVICE
439	MC8-L3	3	ENGINE STOP LIGHT	1002	SPLICE-MC8	3		1009	PS2-PS3	3	
439	MC44-MC8	3		1002	SPLICE-L18	3		1009	PS1-PS2	3	
439	MC11-SPLICE	4		1002	SPLICE-L16	3		1009	MC2-PS1	3	
439	SPLICE-MC44	4		1003	MC7-MC3	3		1009	MC2-CB6	4	STOP LIGHT
439	SPLC-MC116	4		1003	S1-MC7	3	LH RR TURN SIGNAL	1012	MC3-SPLICE	3	
505	MC44-MC8	3	TACHOMETER	1003	MC3-MC80	6		1012	SPLC-SPLC	3	
505	MC11-MC44	4		1003	MC3-MC16	6	TRAILER CONN 12VDC	1012	MC2-SPLICE	3	
505	MC8-G4	3		1003	MC1-R15	4	LH TURN LIGHT	1012	SPLC-SPLC	3	
505	MC11-MC18	5		1003	MC80-L24	6	LH STOP LIGHT	1012	SPLICE-L19	3	
509	MC11-MC18	5	ECM	1003	MC27-MC3	6	FRONT TOW	1012	MC2-R2	4	CLEARANCE LIGHTS
509	MC8-L3	3	ENGINE STOP LIGHT	1003	MC7-MC1	3		1012	MC3-SPLICE	6	
509	MC44-MC8	3		1003C	MC25-R17	4	LH TURN LIGHT	1012	SPLICE-MC27	6	
509	MC11-MC44	4		1003C	MC25-MC15	6	TRAILER CONN 12VDC	1012	SPLICE-MC80	6	
510	MC11-MC18	5	ECM	1004	MC7-MC1	3		1012	SPLICE-L32	6	RH SIDE MARKER
510	MC44-PS4	3	PARKING BRAKE	1004	MC7-MC3	3		1012	SPLICE-L34	6	LH SIDE MARKER
510	R22-MC44	4		1004	S1-MC7	3		1012	MC90-L31	6	RR SIDE MARKER
510	MC11-R22	4		1004	MC3-MC80	6		1012	MC90-L25	6	ID LIGHTS
528	MC11-MC18	5	DIAG. REQ.	1004	MC80-L22	6	RH STOP LIGHT	1012	MC80-MC90	6	
528	MC106-S17	3		1004	MC27-MC3	6		1012	MC90-L33	6	RR SIDE MARKER
528	MC11-MC106	4		1004	MC3-MC78	6		1016	MC92-MC2	3	
900	MC11-MC106	4		1004	MC3-MC16	6		1016	S15-MC92	3	
900	MC11-MC18	5	ECM	1004	MC1-R16	4		1016	MC2-R3	4	HORN
900	MC106-MC13	3		1004C	MC25-R16	4	RH TURN LIGHT	1017	SPLICE-R5	4	
901	MC11-MC18	5	ECM	1004C	MC25-MC15	6	TRAILER CONN 24VDC	1017	MC52-R14	4	
901	MC106-MC13	3		1005	MC126-S9	3		1017	R2-MC52	4	
901	MC11-MC106	4		1005	PS3-MC3	3		1017	MC2-SPLICE	4	
908	MC11-MC18	5	ECM	1005	MC3-MC16	6	TRAILER CONN 24VDC	1017	SPLICE-R1	4	
908	MC11-M4	4	THROTTLE POSN CONT	1005	MC126-PS1	3		1017	MC91-MC2	3	
916	MC44-MC6	3		1005	PS2-PS3	3		1017	S1-MC91	3	
916	MC11-MC44	4		1005	MC27-MC3	6	FRONT TOW	1017A	MC91-MC2	3	
916	MC38-M16	3		1005	PS1-PS2	3		1017A	S1-MC91	3	
916	MC6-MC38	3	VERNIER CONTROL	1005A	MC7-MC126	3		1017A	MC2-R5	4	
916	MC6-M35	3	THROTTLE SENSOR	1005A	MC126-S9	3		1018	MC8-L10	3	HIGH BEAM
916	MC11-MC18	5	ECM	1005A	S1-MC7	3	TURN SIGNAL/DIM SW	1018	MC8-1007	3	
952	MC38-M16	3		1006	MC2-SPLICE	3		1019	L15-1679	3	
952	MC11-MC44	4		1006	SPLICE-L12	3		1020	L14-L16	3	
952	MC44-MC6	3	THROTTLE SENSOR	1006	SPLICE-L17	3		1020	S2-MC21	3	
952	MC11-MC18	5	ECM	1006	MC2-R5	4	DIMMER	1020	MC60-CB24	5	
952	MC6-MC38	3	VERNIER CONTROL	1007	MC2-R5	4	DIMMER	1020	MC21-MC60	5	
953	M6-MC14	5	DDEC SIGNAL GROUND	1007	MC2-SPLICE	3		1020	M12-MC60	5	
953	MC14-SPLICE	4		1007	SPLICE-L12	3		1020A	CB24-PS12	5	
953	SPLICE-MC102	4		1007	SPLICE-L17	3		1020B	PS12-ENG	5	ALTERNATOR
953	SPLICE-R22	4		1008	MC3-MC78	6		1021	MC2-S2	3	
953	SPLICE-MC106	4		1008	MC4-S12	3	HEADLIGHTS	1021	MC2-R11	4	
953	MC106-S17	3						1021	R11-M76	4	
953	S17-MC13	3						1021A	R11-MC1	4	
988	MC11-R7	4	TRANSMISSION					1021A	MC1-MC21	3	
988	MC11-MC18	5	ECM					1021B	MC21-MC60	5	
1001	MC8-L4	3						1021B	MC60-R27	5	

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 3 OF 26
ENGINEERING DWG 3053493 SHEET 1
FP-5/FP-6 BLANK

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1021	MC52-R11	4	FRONT TOW
1021A	R11-MC1	4	
1021A	MC1-MC21	3	
1021A	MC21-MC60	5	
1021A	MC60-R27	5	
1026	MC52-CB16	4	
1029	MC2-R6	4	BEACON
1029	MC2-MC28	3	
1031	R3-SPLICE	4	
1032	MC8-MC21	3	
1032	M39-L9	3	LOW OIL PSI
1032	MC8-M39	3	
1032	PS9-MC21	5	ENGINE OIL PSI SW
1033	M39-M18	3	OIL PSI/H WTR ALM
1036	MC23-M8	5	
1036	MC23-M7	5	
1036	MC21-MC56	5	ETHER START
1036	MC21-S25	3	
1040	CB4-R4	4	WORKLIGHT
1040A	S6-MC4	3	
1040A	MC2-R4	4	WORKLIGHT
1040A	MC4-MC2	3	
1040B	MC3-MC79	6	RH WORKLIGHT
1040B	MC2-MC3	3	
1040B	MC2-R4	4	WORKLIGHT
1040B	MC3-MC54	6	LH WORKLIGHT
1045	R27-M7	5	
1049	MC2-R1	4	HEADLIGHTS
1049	MC4-MC2	3	
1049	S12-MC4	3	
1052	S20-S19	3	CHEM ALM-GPF
1052	S19-S18	3	GAS PART FLTR-SRW
1052	S18-S4	3	SRW-SRW/MHC
1052	S4-S30	3	SRW/MHC-EMER ENG S D
1052	S30-SPLICE	3	EMER ENG SHUT DOWN
1052	SPLICE-G11	3	AIR PRESSURE GAUGE
1052	MC4-SPLICE	3	
1052	SPLICE-L44	3	HEATER PANEL LIGHT
1052	S5-S6	3	BEACON LT-WORK LT
1052	S6-S7	3	WORK LT-WSHLD WSHR
1052	S7-S8	3	WSHLD WASHER-WIPERS
1052	S8-S21	3	WIPERS-DOME LIGHT
1052	S21-S9	3	DOME LT-B.O.SERV SEL
1052	S9-S10	3	BO SERV SEL-BO MKR
1052	S10-S11	3	B.O. MARKER-B.O. DR
1052	S11-S12	3	B.O. DRIVE-HEADLTS
1052	S12-S16	3	HEADLIGHTS-ENG BK
1052	S16-S14	3	ENG BRAKE-RHEO/DOME
1052	S14-SPLICE	3	RHEOSTAT/DOME
1052	SPLICE-G6	3	VOLTMETER 12V
1052	SPLC-SPLC	3	
1052	SPLICE-G10	3	XMSN OIL TEMP GAUGE
1052	SPLICE-G1	3	WATER TEMP GAUGE
1052	SPLICE-G2	3	OIL PRESSURE GAUGE
1052	SPLICE-G4	3	TACHOMETER
1052	SPLICE-G5	3	SPEEDOMETER
1052	SPLICE-G3	3	FUEL GAUGE

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1052	MC1-SPLICE	3	
1052	SPLICE-L43	3	POST LIGHT
1052	SPLC-MC125	3	
1052	MC125-G12	3	AIR RESTRICTION GA
1052	MC1-SPLICE	3	
1052	MC1-CB1	4	15 AMP HEADLIGHT
1052	MC50-MC1	4	
1055	M7-R27	5	
1056	MC111-MC32	3	
1056	MC32-MC109	6	CTI POWER MANIFOLD
1057	MC111-MC32	3	
1057	MC32-MC109	6	CTI POWER MANIFOLD
1058	MC32-MC109	6	CTI POWER MANIFOLD
1058	MC111-MC32	3	
1059	MC32-MC109	6	CTI POWER MANIFOLD
1059	MC111-MC32	3	
1061	MC22-MC109	6	CTI POWER MANIFOLD
1061	MC111-MC32	3	
1062	MC32-MC109	6	CTI POWER MANIFOLD
1062	MC111-MC32	3	
1063	MC32-MC109	6	CTI POWER MANIFOLD
1064	MC32-MC109	6	CTI POWER MANIFOLD
1064	MC111-MC32	3	
1065	MC32-MC109	6	CTI POWER MANIFOLD
1065	MC111-MC32	3	
1066	MC32-MC64	6	CTI AUX MANIFOLD
1066	MC110-MC32	3	
1067	MC32-MC64	6	CTI AUX MANIFOLD
1068	MC32-MC64	6	CTI AUX MANIFOLD
1068	MC110-MC32	3	
1070	MC32-MC64	6	CTI AUX MANIFOLD
1070	MC110-MC32	3	
1071	MC110-MC32	3	
1071	MC32-MC64	6	CTI AUX MANIFOLD
1072	R26-R25	3	
1072	MC110-MC32	3	
1072	MC32-MC64	6	CTI AUX MANIFOLD
1073	MC32-MC64	6	CTI AUX MANIFOLD
1073	MC110-MC32	3	
1074	MC110-MC32	3	
1074	R25-CB10	4	
1074	MC32-MC64	6	CTI AUX MANIFOLD
1075	M6-R25	4/3	
1075B	R25-R18	4	
1076	MC110-MC32	3	
1076	MC32-MC64	6	CTI AUX MANIFOLD
1079	CB5-M6	4	HAZARD LIGHTS
1080	MC7-MC2	3	

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1080	MC2-M5	4	TURN SIGNAL/FLASHER
1082	MC2-MC52	4	
1082	MC2-M81	3	
1082	M81-S3	3	
1082	MC52-CB15	4	HEATER
1084	MC1-CB5	4	B.O. LIGHTS
1084	MC4-MC1	3	
1084	MC4-S9	3	
1091	L17-GROUND	3	
1092	L7-MC8	3	
1092	MC8-M51	3	
1093	MC31-MC57	6	
1093	MC1-MC31	3	
1093	MC1-CB16	4	
1093	MC57-S13	6	DRIVE LINE LOCK-UP
1094	S5-S14	3	
1095	R23-R24	4	
1095	MC44-R23	4	
1095	MC31-MC44	3	
1095	MC57-S13	6	DRIVE LINE LOCK-UP
1095	MC31-MC57	6	
1113	MC8-MC21	3	
1113	G2-MC8	3	OIL PSI GAUGE
1113	SU3-MC21	5	ENG OIL PSI SNOG UN
1114	M66-MC8	3	
1114	MC96-MC8	3	LOW OIL LEVEL LIGHT
1114	MC8-L36	3	
1114	L36-M66	3	
1118	MC4-1919	3	
1118	S8-MC4	3	
1120	M66-MC8	3	
1120	M66-M3	3	
1120	PS6-PS7	3	
1120	PS6-MC8	3	
1120	L2-M66	3	
1137	M6(1)-M6(2)	5	
1137	M6(3)-M6(4)	5	
1138	M48-M7	5	SHUNT
1138	M7-M23	5	SLAVE
1138	M6-M48	5	SHUNT
1138	M77-M7	5	ARCTIC BATTERIES
1139	M7-M23	5	SLAVE
1139	M6-M7	5	
1139	M77-M7	5	ARCTIC BATTERIES
1147	TS2-MC21	5	ENG WTR TEMP SNOG UN
1147	M39-L8	3	HIGH WATER TEMP
1147	MC8-MC21	3	
1147	MC8-M39	3	
1149	MC1-R10	4	REVERSE
1149	MC3-MC78	6	
1149	MC1-MC124	3	
1149	MC78-MC77	6	REVERSE LIGHT
1149	MC124-MC77	6	

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 4 OF 26
 ENGINEERING DWG 3053493 SHEET 2
 FP-7/FP-8 BLANK

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1678	MC78-L22	6	RH B.O. STOP LIGHT
1678	SPLICE-MC3	3	
1678	MC1-R13	4	
1678	SPLICE-MC4	3	
1678	MC4-S9	3	
1678C	MC25-R13	4	B.O. STOP LIGHT
1678C	MC25-MC15	6	TRAILER CONN 24VDC
1679	L15-MC4	3	
1679	MC4-S11	3	
1680	MC3-SPLICE	3	
1680	SPLICE-MC1	3	
1680	SPLC-SPLC	3	
1680	SPLICE-MC4	3	
1680	SPLC-SPLC	3	
1680	SPLICE-L19	3	
1680	SPLICE-L19	3	
1680	MC3-MC78	6	
1680	MC4-S10	3	
1680	MC78-L24	6	LH B.O. TAIL LIGHT
1680	MC1-R17	4	B.O. LIGHTS
1680	MC78-L22	6	RH B.O. TAIL LIGHT
1680C	MC25-MC15	6	TRAILER CONN 24VDC
1680C	MC25-MC15	6	TRAILER CONN 24VDC
1680C	MC25-R17	4	B.O. TAIL LIGHTS
1680C	MC25-MC15	6	TRAILER CONN 24VDC
1702	MC44-MC34	3	
1702	MC34-G7	3	
1702	MC44-R26	4	
1708	M32-1709	3	PASSENGER AIR HTR
1709	MC58-S19	3	GAS PART FILTER SW
1709	MC58-M30	3	
1710	M31-1709	3	DRIVER AIR HEATER
1711	CB11-R7	4	
1712	MC1-CB7	4	ENGINE BRAKE
1712	MC4-MC1	3	
1713	MC53-L37	3	
1713	MC4-MC1	3	
1713	S16-MC4	3	ENGINE BRAKE
1713	MC1-R7	4	TRANSMISSION
1713	S16-MC53	3	
1714	MC1-1716	4	
1714	MC4-MC1	3	ENGINE BRAKE
1714	S16-MC4	3	ENGINE BRAKE
1715	MC4-MC1	3	ENGINE BRAKE
1715	S16-MC4	3	ENGINE BK RH COILS
1715	MC11-MC1	4	
1715	MC11-M21	5	LH ENGINE BRAKE
1716	MC11-R5	4	RETARDER
1716	MC11-M22	5	RH ENGINE BRAKE
1717	MC44-S20	3	CHEMICAL ALARM SW
1717	MC44-CB19	4	
1718	M78-M77	6	BACK-UP ALARM
1722	MC34-1734	3	

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1722	L26-MC34	3	
1722	MC33-MC84	7	
1722	MC84-MC83	7	
1723	MC44-S18	3	SELF RECOVERY WN SW
1723	MC44-CB18	4	
1724	MC112-SPLC	3	
1724	SPLICE-MC33	3	
1724	MC33-MC93	7	
1724	L27-MC112	3	
1724	M67-SPLICE	3	
1724	SPLC-MC112	3	
1724	M67-MC33	3	
1725	L28-MC112	3	
1725	MC84-MC83	7	
1725	MC33-MC84	7	
1725	MC112-MC33	3	
1726	MC33-MC84	7	
1726	MC84-MC83	7	
1726	MC112-MC33	3	
1726	L29-MC112	3	
1729	MC31-S18	3	SELF RECOVERY WINCH
1729	MC31-MC55	6	
1729	MC55-MC121	6	SELF RECOVERY WINCH
1730	MC31-S18	3	SELF RECOVERY WINCH
1730	MC55-MC122	6	SELF RECOVERY WINCH
1730	MC31-MC55	6	
1731	MC3-S4	3	SELF RECOVERY WINCH
1731	MC3-S4	3	SELF RECOVERY WINCH
1731	MC3-MC29	6	CRANE
1732	MC55-MC123	6	SELF RECOVERY WINCH
1732	S4-MC31	3	SELF RECOVERY WINCH
1732	MC31-MC55	6	
1733	MC31-M67	3	
1733	MC31-M51	6	
1734	M67-SPLICE	3	
1734	SPLC-SPLC	3	
1734	SPLICE-MC31	3	
1734	MC31-M10	6	
1736	MC39-MC39	5	
1737	MC31-MC1	3	
1737	MC1-R22	4	CRANE HI IDLE
1737	MC31-MC29	6	CRANE
1738	MC44-1755	4	
1738	MC44-MC31	3	
1738	MC31-MC29	6	CRANE
1739	MC44-CB21	4	

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1739	MC44-S19	3	GAS PARTICULATE SW
1744	S4-M67	3	
1745	MC103-S20	3	CHEMICAL ALARM
1746	MC103-M29	3	CHEMICAL ALARM
1747	MC103-M29	3	CHEMICAL ALARM
1755	MC84-MC83	7	
1755	MC44-CB18	4	
1755	MC33-MC84	7	
1755	MC33-MC44	3	
1765	MC3-MC113	6	
1765	L35-MC8	3	
1765	MC3-MC8	3	
1809	MC41-MC65	5	PULSE TACH DRIVE
1809	MC65-MC39	5	STE/ICE
1810	MC41-M40	5	PULSE TACH DRIVE
1810	MC65-MC39	5	STE/ICE
1810	MC41-M40	5	PULSE TACH DRIVE
1810	MC41-MC65	5	PULSE TACH DRIVE
1811	MC42-M41	5	DIFFERENTIAL PSI
1811	MC42-MC39	5	STE/ICE
1812	MC42-M41	5	DIFFERENTIAL PSI
1812	MC42-MC39	5	STE/ICE
1813	MC39-M6	5	
1814	MC39-M6	5	BATTERIES
1815	MC39-MC24	5	
1815	MC24-MC114	5	
1815	MC24-M20	5	
1816	MC39-MC65	5	STE/ICE
1816	MC39-M7	5	STARTER

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1818	MC39-M7	5	STARTER
1818	MC39-MC65	5	STE/ICE
1819	MC39-M7	5	
1820	MC24-M20	5	
1820	MC24-M20	5	
1820	MC39-MC24	5	
1821	MC39-M6	5	
1822	MC39-M6	5	BATTERIES
1824	SPLICE-MC67	5	
1824	MC66-M70	5	
1824	MC68-M72	5	
1824	SPLICE-MC70	5	
1824	SPLICE-MC71	5	
1824	MC65-MC39	5	STE/ICE
1824	SPLICE-MC68	5	
1824	MC67-M71	5	
1824	MC43-M42	5	FUEL PSI
1824	MC69-M73	5	
1824	MC70-M74	5	
1824	MC71-M75	5	
1824	SPLICE-MC69	5	
1824	MC66-SPLICE	5	
1824	SPLICE-MC65	5	
1824	SPLICE-MC43	5	
1825	MC68-MC69	5	
1825	MC70-MC71	5	
1825	MC65-MC43	5	
1825	MC43-MC67	5	
1825	MC67-MC68	5	
1825	MC70-M74	5	
1825	MC69-MC70	5	
1825	MC41-MC65	5	
1825	MC68-M72	5	
1825	MC66-M70	5	TURBO OUTLET PSI
1825	MC65-MC39	5	STE/ICE
1825	MC69-M73	5	
1825	MC67-M71	5	
1825	MC39-MC40	5	STE/ICE MODULE
1825	MC43-M42	5	FUEL PSI
1825	MC71-M75	5	
1825A	MC39-MC40	5	STE/ICE MODULE
1826	MC40-MC39	5	
1827	MC40-MC39	5	
1828	MC39-M48	5	SHUNT
1829	MC39-M48	5	SHUNT
1835	R2-CB2	4	
1839	R7-R8	4	
1860	MC39-MC24	5	
1860	MC24-MC114	5	
1861	MC24-MC114	5	

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC FOLDOUT 6 OF 26 ENGINEERING DWG 3053493 SHEET 2 FP-11/FP-12 BLANK

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1861	MC39-MC24	5	
1866	CB12-M6	4	
1866	M6-CB12	4/3	
1867	R19-CB12	4	
1871	MC11-CB11	4	DDEC TRANS
1871	PS8-MC11	5	ATEC OIL PSI SWITCH
1871	MC11-R8	4	
1871	MC11-R11	4	
1871	MC11-R10	4	
1871	MC11-R18	4	
1872	R19-MC44	4	
1872	MC44-R18	4	DDEC
1872	MC44-1020	3	
1875	CB14-R19	4	
1880	MC4-MC35	3	
1880	MC44-CB17	4	CTI
1882	MC52-R21	4	
1882	MC52-SPLICE	4	
1882	MC52-R20	4	
1883	S26-L40	3	TC LOCK-UP LIGHT
1883	S26-M49	3	TC LOCK-UP
1884	MC1-R20	4	INTER AXLE
1884	MC1-M39	4	
1884	MC1-MC105	3	
1885	MC1-M39	4	
1885	MC1-MC105	3	
1885	R23-R21	4	
1885	MC1-R23	4	
1888	CB16-R21	4	DIFFERENTIAL LOCK
1888	CB16-R20	4	INTER AXLE
1889	MC44-R20	4	INTER AXLE
1889	MC44-M50	3	INTER AXLE LOCK
1890	MC44-M51	3	DIFFERENTIAL LOCK
1890	MC44-R21	4	DIFFERENTIAL LOCK
1891	MC52-SPLICE	4	
1891	MC52-R10	4	REVERSE
1916	S8-MC4	3	
1916	MC5-M2	3	WIPER MOTOR
1916	MC5-MC4	3	WIPER MOTOR
1917	MC5-M2	3	
1917	MC5-MC4	3	
1917	S8-MC4	3	
1919	MC2-MC5	3	
1919	MC5-M2	3	
1919	MC5-1118	3	
1919	MC2-CB10	4	
1920	MC2-1008	3	
1920	MC2-R2	4	CLEARANCE LIGHTS
1921	S7-MC4	3	
1921	M1-MC4	3	

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1926	MC56-MC23	5	ETHER START
1927	R1-CB1	4	HEADLIGHTS
1928	MC34-MC31	3	
1928	L38-MC34	3	
1928	MC31-MC30	6	TRAILER
1929	MC31-MC30	6	TRAILER
1929	MC34-MC31	3	
1932	MC128-MC61	6	WATER TEMP
1932	MC61-TS3	6	WATER TEMP
1932	MC59-MC63	6	
1932	MC63-MC128	6	
1933	MC61-TS3	6	WATER TEMP
1933	MC63-MC61	6	
1933	MC59-MC63	6	
1935	MC76-M45	6	FAN CONTROL VALVE
1935	MC59-MC76	6	
1935	MC76-M45	6	FAN CONTROL VALVE
1935	MC59-MC76	6	
1938	MC70-M74	5	
1938	MC70-MC65	5	
1938	MC65-MC39	5	
1938B	MC39-S22	5	STE/ICE ZEROING
1939	MC71-M75	5	ENGINE WATER TEMP
1939	MC65-MC39	5	STE/ICE
1939	MC71-MC65	5	
1939B	MC39-S22	5	STE/ICE ZEROING
1940	MC71-MC65	5	
1940	MC71-M75	5	ENGINE WATER TEMP
1940	MC65-MC39	5	STE/ICE
1940B	MC39-S22	5	STE/ICE ZEROING
1941	MC43-M42	5	FUEL PSI
1941	MC43-MC65	5	
1941	MC65-MC39	5	STE/ICE
1942	MC43-MC65	5	
1942	MC65-MC39	5	
1942	MC43-M42	5	FUEL PSI
1943	MC65-MC39	5	STE/ICE
1943	MC66-M70	5	TURBO OUTLET PSI
1943	MC66-MC65	5	TURBO OUTLET PSI
1944	MC66-M70	5	
1944	MC65-MC39	5	STE/ICE
1944	MC66-MC65	5	TURBO OUTLET PSI
1945	MC68-MC65	5	
1945	MC68-M72	5	AIR BOX PSI
1945	MC65-MC39	5	STE/ICE
1946	MC67-M71	5	

CODE SORT			
CODE	ROUTING	SH	DESCRIPTION
1946	MC65-MC39	5	STE/ICE
1946	MC68-M72	5	AIR BOX PSI
1946	MC68-MC65	5	
1947	MC67-MC65	5	
1947	MC65-MC39	5	STE/ICE
1947	MC67-M71	5	AIR CLEANER
1948	MC67-MC65	5	
1948	MC65-MC39	5	STE/ICE
1949	MC69-MC65	5	FUEL RETURN
1949	MC69-MC65	5	
1949	MC65-MC39	5	STE/ICE
1950	MC5-MC4	3	
1950	S8-MC4	3	
1951	MC65-MC39	5	STE/ICE
1951	MC69-M73	5	FUEL RETURN
1951	MC69-MC65	5	
1952	MC65-MC39	5	
1952	MC70-M74	5	ENGINE OIL TEMP
1952	MC70-MC65	5	
1952B	MC39-S22	5	STE/ICE ZEROING
1953	MC39-MC24	5	
1953	MC24-MC114	5	
1953	MC24-M20	5	
1955	M67-MC21	3	FAN SPEED CONTROL
1956	MC127-MC44	3	FAN SPEED CONTROL
1957	MC127-MC21	3	FAN SPEED CONTROL
SHIELD	MC32-MC64	6	CTI AUX MANIFOLD
SHIELD	MC32-MC109	6	CTI POWER MANIFOLD

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 7 OF 26
 ENGINEERING DWG 3053493 SHEET 2
 FP-13/FP-14 BLANK

REVISION 0

28 27 26 25 24 23 22 21 20

H
G
F
E
D
C
B
A




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 8 OF 26
ENGINEERING DWG 3053493 SHEET 3
FP-15/FP-16 BLANK

28 27 26 25 24 23 22 21 20




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 9 OF 26
 ENGINEERING DWG 3053493 SHEET 3
 FP-17/FP-18 BLANK

REVISION D





FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 10 OF 26
 ENGINEERING DWG 3053493 SHEET 3
 FP-19/FP-20 BLANK

REVISION 0



- NOTE:
- SWITCH IS ONLY REQUIRED ON VEHICLES EQUIPPED WITH BOTH CRANE AND SELF RECOVERY WINCH.
 - WHEN ONLY CRANE IS INSTALLED SWITCH S4 IS ELIMINATED. CONNECT 1744 AND 1731 TOGETHER.
 - WHEN ONLY SELF RECOVERY WINCH IS INSTALLED SWITCH S4 IS ELIMINATED. CONNECT 1744 AND 1732 TOGETHER.
 - GROUND LOCATION:
 - △ • LH HEAD LIGHT
 - △ • LH SIDE CONTROL BOX
 - △ DIODES TO BE 1N4001
 - GROUND MET:
 - ⊗ LH SIDE OF HEATER
 - ⊗ RH SIDE OF HEATER
 - ▽ SPLICE
 - EMI SHIELDED WIRES

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC FOLDOUT 11 OF 26 ENGINEERING DWG 3053493 SHEET 3 FP-21/FP-22 BLANK

26

25

24

23

22

21

20

19

18

MC12	
POS	CODE
1	210A
2	204
3	221
4	206
5	220
6	218
7	219
8	223B
9	231
10	230
11	212
12	235
13	235
14	234
15	

MC44	
POS	CODE
A	1108
B	509
C	419
D	439
E	510
F	916
G	417
H	952
I	1723
J	1738
K	
L	1755
M	1739
N	1717
O	1095
P	1702
Q	1889
R	1890
S	1640
T	1872
U	1880
V	1189

MC2	
POS	CODE
A	1017A
B	1049
C	1012
D	1189
E	1188
F	1016
G	1040B
H	1040A
I	1017
J	1009
K	1080
L	1007
M	1008
N	1029
O	1184
P	1919
Q	1292
R	1536
S	1021
T	1276
U	1082
V	1920

MC1	
POS	CODE
A	1084
B	1052
C	1712
D	1052
E	1021A
F	1149
G	1409
H	1714
I	1093
J	
K	
L	1678
M	1713
N	1715
O	1431
P	1680
Q	1003
R	1004
S	1487
T	1884
U	1885
V	1737

MC57	
POS	CODE
A	1017
B	1082
C	1026
D	1021
E	1891
F	1882

MC119	
POS	CODE
A	1431
B	1640
C	1644
D	1435

SHIFT CONTROLLER ATEC 12VDC

SEE SHEET 5

BLACK

WHITE

REVISION C
CN 14815
12-15-97




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 12 OF 26
 ENGINEERING DWG 3053493 SHEET 4
 FP-23/FP-24 BLANK

REVISION C
CN 14815
12-15-97





FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 13 OF 26
ENGINEERING DWG 3053493 SHEET 4
FP-25/FP-26 BLANK



SEE SHEET 6
24V TRAILER

KNIT LOOM
W/COPPER
TO XSMN
CONNECTOR
SEE SHEET 5

x = UNUSED
SEALED
POSITIONS


POS	CODE
1	1000
2	
3	
4	1000
5	
6	
7	

SEE SHEET 5

- GROUND LOCATION
- △ LH HEAD LIGHT
 - △ RH SIDE CONTROL BOX
 - △ FERRISHIELD FAIRRITE PN 55282032
 - △ FERRISHIELD FAIRRITE PN TC2881500
 - ⊙ EMI SHIELDED WIRES

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 14 OF 26
ENGINEERING DWG 3053493 SHEET 4
FP-27/FP-28 BLANK

REVISION C
CN 14815
12/15/97



POS	CODE
A	1320
B	1449
C	1113
D	1021A
E	1032
F	1147
G	1020
H	1036
J	X
K	X
L	X
M	1957
N	1955
O	X
P	X
R	X
S	X
T	X
U	X
V	X

POS	CODE
A	1021A
B	1020

POS	CODE
A	X
B	916
C	419
D	509
E	439
F	901
G	900
H	952
J	417
K	528
L	908
M	505
N	X
O	510
P	1517
R	1871
S	1715
T	1716
U	208/209
V	115
W	X
X	X

POS	CODE
A	1036
B	1926

POS	CODE
A	1928
B	1435

POS	CODE
A	1020
B	1435


POS	CODE
A	1020
B	1435

POS	CODE
1	1860
2	1820
3	1815
4	1861
5	1953

SEE SHEET 4

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 15 OF 26
ENGINEERING DWG 3053493 SHEET 5
FP-29/FP-30 BLANK

REVISION C
CN14815
12/15/97



POS	CODE
A	240
B	151
C	241
D	150
E	150

POS	CODE
A	240
B	151
C	241
D	150
E	150

POS	CODE
A	123
B	114
C	121
D	111
E	101
F	118
G	116
H	122
J	
K	108
L	109
M	119
N	117
O	107
P	1068
Q	
R	
S	
T	115
U	105
V	120
W	110
X	

POS	CODE
A	113
B	112

POS	CODE
A1	988
A2	555
A3	916
B1	419
B2	509
B3	439
C1	901
C2	900
C3	952
D1	510
D2	417
D3	749
E1	451
E2	
E3	
F1	542
F2	544
F3	499
G1	528
G2	543
G3	545
H1	
H2	
H3	115
J1	541
J2	531
J3	908
K1	505
K2	
K3	

POS	CODE
L1	X
L2	X
L3	925
M1	X
M2	X
M3	926
N1	X
N2	X
N3	X
P1	432
P2	530
P3	X
R1	X
R2	120
R3	472
S1	112
S2	111
S3	X
T1	109
T2	110
T3	X
V1	416
V2	X
V3	X
X1	X
X2	X
X3	X
Y1	X
Y2	452
Y3	X

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 16 OF 26
ENGINEERING DWG 3053493 SHEET 5
FP-31/FP-32 BLANK

REVISION C
CN 14815
12-15-97




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 17 OF 26
ENGINEERING DWG 3053493 SHEET 5
FP-33/FP-34 BLANK




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 18 OF 26
 ENGINEERING DWG 3053493 SHEET 6
 FP-35/FP-36 BLANK

REVISION 0





FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 19 OF 26
 ENGINEERING DWG 3053493 SHEET 6
 FP-37/FP-38 BLANK



MC33		
POS	CODE	
A	1755	(24 VDC IN)
B	1435	(GROUND)
C	1722	(LHS IND & VA.)
D	1724	(SRW-CRANE & VA.)
E	1725	(TRANS LIGHT NO)
F	1726	(OVER LOAD)

SEE SHEET 3

1860810 (7200)

MC84		
POS	CODE	
A	1482	
B	1481	
C	1486	
D	1480	
E	1755	
F	1435	
G	1483	
H	1484	
J	1485	
K	1722	
L	1487	
M	1488	
N	1489	
P	1490	
R	1726	
S	1725	
T	---	

1860800 (7190)

MC83		
POS	CODE	
A	1482	
B	1481	
C	1486	
D	1480	
E	1755	
F	1435	
G	1483	
H	1484	
J	1485	
K	1722	
L	1487	
M	1488	
N	1489	
P	1490	
R	1726	
S	1725	
T	---	

M26
CAB CONTROL BOX
1891370
M.R. "A" SOLENOID
H.A. "B" SOLENOID
M.R. "B" SOLENOID
H.A. "A" SOLENOID
SEQUENCING (3)
24 VOLT +
SEQUENCING (6)
TRANSIT VALVE
FREE FLOW VALVE
0 VOLTS
0 VOLTS
PROXIMITY H.A. DOWN

SEE SHEET 8 FOR DETAIL OF CAB CONTROL BOX

MC81		
POS	CODE	
A	1465	
B	1467	
C	1468	
D	1464	
E	1466	
F	1472	
G	1469	
H	1463	
J	1462	
K	1435	
L	1435	
M	1471	
N	1460	
P	1459	
R	1435	
S	1435	
T	---	


GREEN
RED
WHITE
DRAIN WIRE

1860790 (7170)

MC82		
POS	CODE	
A	1465	
B	1467	
C	1468	
D	1464	
E	1466	
F	1472	
G	1469	
H	1463	
J	1462	
K	1435	
L	1435	
M	1471	
N	1460	
P	1459	
R	1435	
S	1435	
T	---	

1883440

1877480 (7140)
HOOKARM SOL A M53
1877470 (7150)
HOOKARM SOL B M54



MC93		
POS	CODE	
A	1724	
B	1480	
C	1481	
D	1482	
E	1483	
F	1484	

MC94		
POS	CODE	
A	1485	
B	1486	
C	1487	
D	1488	
E	1489	
F	1490	




FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
FOLDOUT 20 OF 26
ENGINEERING DWG 3053493 SHEET 7
FP-39/FP-40 BLANK

REVISION 0






FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 21 OF 26
 ENGINEERING DWG 3053493 SHEET 7
 FP-41/FP-42 BLANK

REVISION 0




NC83	
POS	CODE
A	1482
B	1481
C	1486
D	1480
E	1755
F	1435
G	1483
H	1484
J	1485
K	1722
L	1487
M	1488
N	1489
P	1490
R	1728
S	1725
T	----

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 22 OF 26
 ENGINEERING DWG 3053493 SHEET 8
 FP-43/FP-44 BLANK



MCB1	
POS	CODE
A	1465
B	1467
C	1468
D	1464
E	1466
F	1472
G	1469
H	1463
J	1462
K	1435
L	1435
M	1471
N	1460
P	1459
R	1435
S	1435
T	---

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 23 OF 26
 ENGINEERING DWG 3053493 SHEET 8
 FP-45/FP-46 BLANK



POS	CODE
A	WHT
B	GRN
C	BLK
D	RED
E	SHIELD

POS	CODE
A	RED
B	GRN
C	YEL
D	WHT
E	BLU
F	BLK
G	ORG
H	VIO
J	RED/GRN
K	GRY
L	TAN
M	BRN
N	PNK
P	SHIELD

POS	CODE
A	BLK
B	WHT
C	GRN
D	RED

POS	CODE
A	BLU
B	BLK
C	BRN

POS	CODE
A	WHT
B	BLK
C	RED
D	GRN
E	SHIELD

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 24 OF 26
 ENGINEERING DWG 3053493 SHEET 9
 FP-47/FP-48 BLANK





FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC
 FOLDOUT 25 OF 26
 ENGINEERING DWG 3053493 SHEET 9
 FP-49/FP-50 BLANK



FOR LHS CIRCUIT PROTECTION CONFIGURATION

FIGURE FO-1. ELECTRICAL SYSTEM SCHEMATIC FOLDOUT 26 OF 26 ENGINEERING DWG 3053493 SHEET 10 FP-51/FP-52 BLANK

By Order of the Secretary of the Army:

PETER J. SCHOOMAKER
General, United States Army
Chief of Staff

Official:



SANDRA R. RILEY

Administrative Assistant to the
Secretary of the Army

0525710

DISTRIBUTION:

To be distributed in accordance with the initial distribution number (IDN) 380893,
requirements for TM 9-2320-364-34-1.

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS For use of this form, see AR 25-30; the proponent agency is ODISC4.						Use Part II (reverse) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE Date you filled out this form.
TO: (Forward to proponent of publication or form) (Include ZIP Code) AMSTALC-LPIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630						FROM: (Activity and location) (Include ZIP Code) Your mailing address	
PART I – ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER TM 9-2320-364-34-1				DATE 30 November 2005	TITLE Palletized Load System, Models M1074/M1075		
ITEM NO.	PAGE NO.	PARA-GRAPH	LINE NO. *	FIGURE NO.	TABLE NO.	RECOMMENDED CHANGES AND REASON (Provide exact wording of recommended changes, if possible).	
	0004 00-2	4-7				Wrong POC is listed.	
							
<i>*Reference to line numbers within the paragraph or subparagraph.</i>							
TYPED NAME, GRADE OR TITLE Your Name				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE Your Signature	

TO: <i>(Forward direct to addressee listed in publication)</i> AMSTALC-LPIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630	FROM: <i>(Activity and location) (Include ZIP Code)</i> Your address	DATE Date you filled out this form
--	--	--

PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER TM 9-2320-364-34-1	DATE 30 November 2005	TITLE Palletized Load System, Models M1074/M1075
--	--------------------------	---

PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

PART III - REMARKS *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE Your Name	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE Your Signature
---	--	-----------------------------

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS						Use Part II (reverse) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE
For use of this form, see AR 25-30; the proponent agency is ODISC4.							
TO: (Forward to proponent of publication or form) (Include ZIP Code) AMSTALC-LPIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630						FROM: (Activity and location) (Include ZIP Code)	
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER TM 9-2320-364-34-1				DATE 30 November 2005		TITLE Palletized Load System, Models M1074/M1075	
ITEM NO.	PAGE NO.	PARA-GRAPH	LINE NO. *	FIGURE NO.	TABLE NO.	RECOMMENDED CHANGES AND REASON (Provide exact wording of recommended changes, if possible).	
<i>*Reference to line numbers within the paragraph or subparagraph.</i>							
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE	

TO: <i>(Forward direct to addressee listed in publication)</i> AMSTALC-LPIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630	FROM: <i>(Activity and location) (Include ZIP Code)</i>	DATE
--	--	-------------

PART II – REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER TM 9-2320-364-34-1	DATE 30 November 2005	TITLE Palletized Load System, Models M1074/M1075
--	--------------------------	---

PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

PART III – REMARKS *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE
----------------------------	--	-----------

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS						Use Part II (reverse) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE
For use of this form, see AR 25-30; the proponent agency is ODISC4.							
TO: (Forward to proponent of publication or form) (Include ZIP Code) AMSTALC-LPIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630						FROM: (Activity and location) (Include ZIP Code)	
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER TM 9-2320-364-34-1					DATE 30 November 2005	TITLE Palletized Load System, Models M1074/M1075	
ITEM NO.	PAGE NO.	PARA-GRAPH	LINE NO. *	FIGURE NO.	TABLE NO.	RECOMMENDED CHANGES AND REASON (Provide exact wording of recommended changes, if possible).	
<i>*Reference to line numbers within the paragraph or subparagraph.</i>							
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE	

TO: <i>(Forward direct to addressee listed in publication)</i> AMSTALC-LPIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630	FROM: <i>(Activity and location) (Include ZIP Code)</i>	DATE
--	--	-------------

PART II – REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER TM 9-2320-364-34-1	DATE 30 November 2005	TITLE Palletized Load System, Models M1074/M1075
--	--------------------------	---

PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

PART III – REMARKS *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE
----------------------------	--	-----------

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS For use of this form, see AR 25-30; the proponent agency is ODISC4.						Use Part II (reverse) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE
TO: (Forward to proponent of publication or form) (Include ZIP Code) AMSTALC-LPIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630						FROM: (Activity and location) (Include ZIP Code)	
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER TM 9-2320-364-34-1						DATE 30 November 2005	TITLE Palletized Load System, Models M1074/M1075
ITEM NO.	PAGE NO.	PARA-GRAPH	LINE NO. *	FIGURE NO.	TABLE NO.	RECOMMENDED CHANGES AND REASON (Provide exact wording of recommended changes, if possible).	
<i>*Reference to line numbers within the paragraph or subparagraph.</i>							
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE	

TO: <i>(Forward direct to addressee listed in publication)</i> AMSTALC-LPIT / TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630	FROM: <i>(Activity and location) (Include ZIP Code)</i>	DATE
--	--	-------------

PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER TM 9-2320-364-34-1	DATE 30 November 2005	TITLE Palletized Load System, Models M1074/M1075
--	--------------------------	---

PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

PART III - REMARKS *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE
----------------------------	--	-----------

THE METRIC SYSTEM AND EQUIVALENTS

LINEAR MEASURE

1 Centimeter=10 Millimeters=0.01 Meters=0.3937 Inches
 1 Meter=100 Centimeters=1000 Millimeters=39.37 Inches
 1 Kilometer=1000 Meters=0.621 Miles

SQUARE MEASURE

1 Sq Centimeter=100 Sq Millimeters=0.155 Sq Inches
 1 Sq Meter=10,000 Sq Centimeters=10.76 Sq Feet
 1 Sq Kilometer=1,000,000 Sq Meters=0.386 Sq Miles

WEIGHTS

1 Gram=0.001 Kilograms=1000 Milligrams=0.035 Ounces
 1 Kilogram=1000 Grams=2.2 Lb
 1 Metric Ton=1000 Kilograms=1 Megagram=1.1 Short Tons

CUBIC MEASURE

1 Cu Centimeter=1000 Cu Millimeters=0.06 Cu Inches
 1 Cu Meter=1,000,000 Cu Centimeters=35.31 Cu Feet

LIQUID MEASURE

1 Milliliter=0.001 Liters=0.0338 Fluid Ounces
 1 Liter=1000 Milliliters=33.82 Fluid Ounces


TEMPERATURE

$5/9 (°F - 32) = °C$
 212° Fahrenheit is equivalent to 100° Celsius
 90° Fahrenheit is equivalent to 32.2° Celsius
 32° Fahrenheit is equivalent to 0° Celsius
 $9/5 C + 32 = F$

APPROXIMATE CONVERSION FACTORS

<u>TO CHANGE</u>	<u>TO</u>	<u>MULTIPLY BY</u>
Inches.....	Centimeters.....	2.540
Feet.....	Meters.....	0.305
Yards.....	Meters.....	0.914
Miles.....	Kilometers.....	1.609
Square Inches.....	Square Centimeters.....	6.451
Square Feet.....	Square Meters.....	0.093
Square Yards.....	Square Meters.....	0.836
Square Miles.....	Square Kilometers.....	2.590
Acres.....	Square Hectometers.....	0.405
Cubic Feet.....	Cubic Meters.....	0.028
Cubic Yards.....	Cubic Meters.....	0.765
Fluid Ounces.....	Milliliters.....	29.573
Pints.....	Liters.....	0.473
Quarts.....	Liters.....	0.946
Gallons.....	Liters.....	3.785
Ounces.....	Grams.....	28.349
Pounds.....	Kilograms.....	0.454
Short Tons.....	Metric Tons.....	0.907
Pound-Feet.....	Newton-Meters.....	1.356
Pounds/Sq Inch.....	Kilopascals.....	6.895
Miles per Gallon.....	Kilometers per Liter.....	0.425
Miles per Hour.....	Kilometers per Hour.....	1.609

<u>TO CHANGE</u>	<u>TO</u>	<u>MULTIPLY BY</u>
Centimeters.....	Inches.....	0.394
Meters.....	Feet.....	3.280
Meters.....	Yards.....	1.094
Kilometers.....	Miles.....	0.621
Sq Centimeters.....	Square Inches.....	0.155
Square Meters.....	Square Feet.....	10.764
Square Meters.....	Square Yards.....	1.196
Square Kilometers.....	Square Miles.....	0.386
Sq Hectometers.....	Acres.....	2.471
Cubic Meters.....	Cubic Feet.....	35.315
Cubic Meters.....	Cubic Yards.....	1.308
Milliliters.....	Fluid Ounces.....	0.034
Liters.....	Pints.....	2.113
Liters.....	Quarts.....	1.057
Liters.....	Gallons.....	0.264
Grams.....	Ounces.....	0.035
Kilograms.....	Pounds.....	2.205
Metric Tons.....	Short Tons.....	1.102
Newton-Meters.....	Pound-Feet.....	0.738
Kilopascals.....	Pounds per Sq Inch.....	0.145
Km per Liter.....	Miles per Gallon.....	2.354
Km per Hour.....	Miles per Hour.....	0.621



PIN: 072625-000