

TECHNICAL MANUAL

**OPERATOR'S MANUAL
FOR
SEMITRAILER, TANK, 5000-GALLON,
FUEL DISPENSING, AUTOMOTIVE
M969A2 (NSN 2330-01-377-9337)**



**EQUIPMENT DESCRIPTION
AND DATA
PAGE 1-5**

**OPERATING
INSTRUCTIONS
PAGE 2-1**

**PREVENTIVE
MAINTENANCE CHECKS
AND SERVICES (PMCS)
PAGE 2-9**

**TROUBLESHOOTING 2
PAGE 3-2**

**MAINTENANCE
PROCEDURES
PAGE 3-24**

APPENDIXES

**INDEX
PAGE INDEX-1**

Approved for public release; distribution is unlimited.

**HEADQUARTERS, DEPARTMENT OF THE ARMY
June 1996**

WARNING**GROUNDING SEMITRAILER**

- Be sure that grounding connections are made properly and firmly before any fueling operations begin. This will ensure that grounding connections will not release, thus eliminating the possibility of sparks caused by static electricity which will ignite the fuel. This applies to top loading and bottom loading at a fixed loading facility loading is the preferred method when facilities are available. Failure to follow this warning may cause a spark to ignite, resulting in serious injury or death to personnel.
- The grounding cable must be connected before any servicing operations. The first clip should be attached to the ground rod. The second clip should be attached to the aircraft grounding fitting, if one is provided, or to a convenient unpainted metal point on the aircraft. Grounding should not be made to a propeller, radio antenna, or highly stressed components of the landing gear where scratches could cause metal failure. Always disconnect the grounding clips in reverse order: first the aircraft, then the ground rod. The grounding cables shall be disconnected only after fuel-servicing operations have been completed and all dispensing nozzles and hoses have been disconnected or removed from the filler opening and stowed on the refueling vehicle. Grounding cables attached to dispensing nozzles may be disconnected only after nozzles have been disconnected or removed from filler openings of the aircraft being serviced. Failure to follow this warning may cause a spark to ignite, resulting in serious injury or death to personnel.

WARNING**BONDING AND GROUNDING AIRCRAFT OR VEHICLE TO SEMITRAILER**

- Bond the fuel nozzle to the aircraft or vehicle before opening the filler cap. Connect closed-circuit nozzles securely before beginning fuel flow. Electrical hazards may be introduced in several ways, such as:
 - Electrostatic sparks.
 - Operation of aircraft engines, auxiliary power units, and heaters.
 - Operation of automotive equipment, other than that performing the fuel-servicing functions, within 50 feet (15.25 m) of the aircraft or vehicle during fuel-servicing operations.
 - Arcing of electrical circuits.
 - Open flames.
 - Energy from energized equipment.
 - Lightning.

WARNING**BONDING AND GROUNDING AIRCRAFT OR VEHICLE TO SEMITRAILER (continued)**

- Due to the dangers of static electricity, grounding the semitrailer to the aircraft or vehicle while refueling is mandatory, regardless of the amount of fuel to be dispensed. Failure to follow this warning may cause spark to ignite, resulting in serious injury or death to personnel.
- Before performing maintenance on the semitrailer, the semitrailer must be grounded to an approved (earth) ground and it must be safe to proceed. Failure to follow this warning may cause a spark to ignite, resulting in serious injury or death to personnel.

WARNING**FUEL HANDLING**

- To avoid serious Injury or death to personnel, DO NOT fill tanker while pump engine is running, while smoking, or when near open flame. Never overfill the tanker or spill fuel. If fuel is spilled, clean it up immediately.
- Post signs that read " NO SMOKING WITHIN 50 FEET" when performing any fueling operation. Failure to follow this warning can cause fuel to ignite, resulting in serious injury or death to personnel.
- Do not smoke while performing any fueling operation, or when located within 50 feet (15.25 m) of fueling and fuel storage areas.
- Do not let fuel or oil drain on hot engine. Fuel or oil can catch fire and cause injury or death to personnel.
- Keep fuel away from open flames and keep fire extinguisher within easy reach when working with fuel. Fuel is very flammable and can explode easily, resulting in serious injury or death to personnel.
- Spilled fuel is slippery and can cause you to slip and fall. To avoid injury, wipe up spilled fuel immediately with rags.
- Follow all fuel-handling procedures precisely, to prevent injury or death to personnel.
- All fueling/defueling operations must be performed outside. Failure to follow this warning may cause spark to ignite fuel vapors, resulting in serious injury or death to personnel.

WARNING**FUEL HANDLING (continued)**

- Before and after all fuel-servicing operations, all valves must be in the closed position. Failure to follow this warning could cause excessive spillage or fire, resulting in serious injury or death to personnel.
- DO NOT permit automotive equipment, other than that performing the fuel-servicing functions, to be within 50 feet (15.25 m) of the aircraft or vehicle during fuel-servicing operations.
- When the semitrailer is emptied of fuel, a mixture of vapor and air remains that may be, and often is, within the flammable range. Refilling the semitrailer with a different type of fuel other than it originally contained can cause a potential explosive atmosphere within the semitrailer. Know what fuel was previously carried so that preventive measures may be taken to ensure that injurious or explosive fumes are not released. Failure to follow this warning may result in serious injury or death to personnel.
- DO NOT attempt aircraft fueling operations if combustion heaters (e.g., wing and tail surface heaters or integral cabin heaters) are being operated on the aircraft. Failure to follow this warning may cause a fire or explosion, resulting in serious injury or death to personnel.
- When filling tank by means of bottom loading, or self-loading, a test of the precheck system is mandatory. If this system is not functioning, stop all operations.
- the problem and have it corrected by a qualified technician. Failure of automatic shutoff to function may cause uncontrolled fuel spillage, fire, and/or explosion, resulting in serious injury or death to personnel.
- When top loading through fill cover, there is no automatic shutdown. Man the loading hose to avoid fuel spillage. Use the capacity indicator gage and dipstick gage to determine amount of fuel loaded. Failure to follow this warning may cause uncontrolled fuel spillage, fire, and/or explosion, resulting in serious injury or death to personnel.
- DO NOT mix incompatible fuels in the tank. Dangerous fumes and explosion may result. Know what fuel was previously carried so that preventive measures may be taken to ensure that injurious or explosive fumes are not released. Failure to follow this warning may result in injury or death to personnel.
- In an emergency, pull emergency valve A control handle to CLOSED or pull emergency valve A shutoff valve on opposite side (curb side) of semitrailer. Failure to do so may result in injury to personnel.

WARNING**FUEL HANDLING (continued)**

- The operator must be alert for leaking or malfunctioning equipment. Stop all servicing operations immediately at the first sign of leaks or malfunctions. Corrective action must be performed by qualified technicians before resuming any operations. Failure to follow this warning may cause fire or explosion, resulting in serious injury or death to personnel.
- Parking areas for fuel-servicing vehicles should be arranged to:
 - Facilitate the dispersal of vehicles in event of an emergency.
 - Provide a distance of at least 25 feet (7.63 m) of clear space between vehicles for accessibility for fire control purposes.
 - Prevent fuel from any vehicle from draining into an adjacent building.
 - Provide a distance of at least 50 feet (15.25 m) from any structure that houses the public and may have windows or doors in exposed walls.
- All vapor-freeing work by any method should be carried on outdoors, remote from vehicles and other known sources of ignition, and the tank unit must be stationed where flammable vapors will not blow or drift indoors. Failure to follow this warning may result in serious injury or death to personnel.
- DO NOT allow fuel-dispensing nozzle spray to contact skin. Diesel fuel under pressure can penetrate flesh and cause serious injury and infection.
- The following must be observed if the semitrailer is to be moved to the inside of a building: .
 - The tank must be completely drained and purged.
 - The interior of the tank must be checked with explosive meter prior to moving into the building.
 - The combustible gas indicator set must be used to check the tank prior to starting work each day, and random checks must be performed during the day.
 - No open flames, welding, or use of heat-producing devices is permitted near the tank during maintenance unless the tank tests safe with the combustible gas indicator set.
 - No smoking is allowed within 50 feet (15.25 m) of semitrailer at any time.
- DO NOT climb into interior of the tank until it has been completely drained and purged and a combustible gas indicator set check indicates that it is safe. Adequate forced-air ventilation or a self-contained breathing apparatus must be used. Any person entering the tank must have an attached lifeline. An observer must be stationed at the manhole opening so that assistance may be summoned in the event of an emergency. Failure to follow this warning may result in serious injury or death to personnel.

WARNING

GENERAL OPERATION

DO NOT let go of static reel cable when rewinding until ball stop is firmly touching the reel. Failure to follow this warning may cause injury to personnel.

WARNING

The semitrailer must not be operated if fuel leaks from semitrailer tank or engine. Report any fuel leaks to your supervisor or Unit maintenance. Failure to do so may result in a fire hazard, which can cause severe injury or death to personnel.

WARNING

Ladder has narrow treads. To prevent injury, use care when climbing.

WARNING

Spare tire and ladder are heavy. Make sure cable is not frayed or damaged. Do not raise spare tire and ladder past the vertical position or they will slam into carrier assembly. Failure to follow this warning may result in severe injury to personnel or damage to equipment.

WARNING

The following should be done when servicing a semitrailer when connected to the prime mover, regardless of the nature of the repair:

- The prime mover's engine should be shut down.
- The prime mover's parking brakes should be applied.
- The prime mover's Ignition key should be removed and be in the hands of the operating technician or be locked in an area away from the vehicle.



WARNING

Handle charged fire extinguisher cylinders with care. To prevent serious injury to personnel, DO NOT jar or expose to temperature above 140OF (600C).

WARNING

Voltage of 115-220 volts can cause personal injury or death. Take extreme care when working with this much voltage.

WARNING**GENERAL OPERATION (continued)**

Manhole fill cover does not lock open. Injury may occur if manhole fill cover accidentally closes on personnel.

WARNING

DO NOT crawl underneath, on top, or near the tires of the semitrailer unless the brakes are positively locked and all other personnel are aware of your presence.

WARNING

Operators must wear ear protection while on engine side of semitrailer when engine is running. Failure to follow this warning may result in injury to personnel.

WARNING**HOSE REEL**

When the hose has been pulled from the hose reel, the hose reel is under spring tension. To avoid movement of the hose reel by accidental activation of the hose reel rewind switch, tighten the hose reel lock. Failure to follow this warning may result in personal injury.

WARNING

Use extreme caution when operating electric rewind on the hose reels. NEVER use the electric rewind on both hose reels at the same time. Electric rewind should be halted, then resumed carefully as the fuel-dispensing nozzle approaches the vehicle. As the hose becomes fully wound on the hose reel, the nozzle may slam against the vehicle with force sufficient to cause injury to personnel and/or damage to equipment. Extreme care is to be used, ensuring that the hose is rewound slowly. Caution should be used at the hose reels to prevent accidental tripping of the rewind switches. If these are accidentally depressed by hand or by falling objects, serious injury to personnel and/or damage to equipment may occur.

WARNING**SOLVENT P-D-680 HAZARDS**

- Drycleaning solvent (P-D-680) is TOXIC and flammable. Wear protective goggles and gloves; use only in a well-ventilated area; avoid contact with skin, eyes, and clothes; and do not breathe vapors. Keep away from heat or flame. Never smoke when using drycleaning solvent. Failure to follow this warning may result in injury or death to personnel.

SOLVENT P-D-680 HAZARDS (continued)

- If personnel become dizzy while using drycleaning solvent, immediately get fresh air and medical help. If solvent contacts skin or clothes, flush with cold water. If solvent contacts eyes, immediately flush them with water and get immediate medical attention.
- When P-D-680 drycleaning solvent is used, notify the local medical authority (preventive medicine) and environmental coordinator concerning medical surveillance, respiratory protection, and disposal requirements.

WARNING**BATTERY HAZARDS**

- Lead-acid batteries can explode. Do not smoke, have open flames, or make sparks around a battery, especially if the caps are off. If a battery is gassing, it can explode and cause injury to personnel.
- Ventilate when charging or using battery in an enclosed space.
- Wear safety goggles and acid-proof gloves when battery cover must be removed or when adding electrolyte.
- Avoid contact between battery electrolyte and skin, eyes, or clothing. If electrolyte spills, take immediate action to stop burning effects:
 - External. Immediately flush with cold running water to remove all acid.
 - Eyes. Flush with cold water for at least 15 minutes. Seek immediate medical attention.
 - Internal. Drink large amounts of water or milk. Follow with milk of magnesia, beaten egg, or vegetable oil. Seek immediate medical attention.
 - Clothing or Vehicle. Wash at once with cold water. Neutralize with baking soda or household ammonia solution.
- Wear safety glasses or goggles when checking batteries. Always check electrolyte level with engine stopped. Do not smoke or use exposed flame when checking battery; explosive gases are present and severe injury to personnel can result.
- Remove or disconnect batteries prior to performing maintenance in immediate battery area or working on electrical system. Such disconnections prevent electrical shock to personnel or equipment.

BATTERY HAZARDS (continued)

- Battery acid (electrolyte) is extremely harmful. Always wear safety goggles and rubber gloves, and do not smoke when performing maintenance on batteries. Injury will result if acid contacts skin or eyes. Wear rubber apron to prevent damage to clothing.
- Remove all jewelry, such as rings, identification tags, bracelets, and so on. If jewelry contacts battery terminal, a direct short may result in instant heating of tools, damage to equipment, and injury or death to personnel.

WARNING**NUCLEAR, BIOLOGICAL, OR CHEMICAL (NBC) EXPOSURE AND VEHICLE AIR FILTER HAZARDS**

- NBC-contaminated air filters must be handled and disposed of only by authorized and trained personnel. The unit commander or senior officer in charge of maintenance personnel must ensure that prescribed protective clothing (FM 3-4) is used and that prescribed safety measures and decontamination procedures (FM 3-5) are followed. The local unit SOP is responsible for final disposal of contaminated air filters. Failure to comply with this warning may cause severe injury to personnel.
- The NBC protection filters use a type of carbon that contains Chromium VI. This is a known carcinogen if inhaled or swallowed. Damaged or unusable filters are classified as hazardous waste.
 - Do not throw away damaged or unusable filters as trash.
 - Turn in damaged or unusable filters to your Hazardous Waste Management Office or Defense Reutilization and Marketing Office.
- Filters are completely safe to handle and use if they are not damaged in such a way that carbon leaks from them. If carbon does leak use protection, such as a dust respirator to cover nose and mouth, and put carbon in a container, such as a self-sealing plastic bag; turn in to Hazardous Waste Management Office or Defense Reutilization and Marketing Office.
- Disposal of hazardous waste is restricted by law. Violation is subject to criminal penalties.
- Hearing protection is required within 50 feet of tanker during operation of the engine. Failure to follow this warning may result in injury to personnel.
- Sudden changes in temperature may cause M969A2 semitrailers to develop leaks at the fittings and connectors. Use caution and pay special attention to these areas.
- something is broken or worn out, notify Unit maintenance. Corrective action must be performed before resuming any operations. Failure to follow this warning may result in injury to personnel.

**TECHNICAL MANUAL
OPERATOR'S MANUAL
FOR
SEMITRAILER, TANK, 5000-GALLON,
FUEL DISPENSING, AUTOMOTIVE
M969A2 (NSN 2330-01-377-9337)**

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual If you find any mistakes or know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual directly to Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-IM-OPIT, Warren, MI 48397-5000. A reply will be furnished to you.

You may also provide DA Form 2028-2 information to TACOM via datafax or e-mail:

- TACOM's fax number is DSN 786-6323 or (810) 574-6323.
- TACOM's e-mail address is tacom-tech-pubs-cc.army.mil.

Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

| | | Page |
|-------------------------------------|---|-------------|
| HOW TO USE THIS MANUAL | | iii |
| CHAPTER 1 | INTRODUCTION | |
| Section I | General Information | 1-1 |
| Section II | Equipment Description and Data | 1-5 |
| Section III | Principles of Operation | 1-11 |
| CHAPTER 2 | OPERATING INSTRUCTIONS | |
| Section I | Description and Use of Operator's Controls and Indicators | 2-1 |
| Section II | Operator/Crew Preventive Maintenance Checks and Services (PMCS) | 2-9 |
| Section III | Operation Under Usual Conditions | 2-28 |
| Section IV | Operation Under Unusual Conditions | 2-61 |

CHAPTER 3 MAINTENANCE INSTRUCTIONS

| | | |
|-------------|--|------|
| Section I | Lubrication Instructions | 3-1 |
| Section II | Operator/Crew Troubleshooting Procedures | 3-2 |
| Section III | Maintenance Procedures | 3-24 |

APPENDIX A REFERENCESA-1

APPENDIX B COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LISTS

| | | |
|-------------|-------------------------------------|-----|
| Section I | Introduction | B-1 |
| Section II | Components of End Item (COEI) | B-2 |
| Section III | III Basic Issue Items (BI) | B-3 |

APPENDIX C ADDITIONAL AUTHORIZATION LIST

| | | |
|------------|---|-----|
| Section I | Introduction | C-1 |
| Section II | Additional Authorization List (AAL) | C-2 |

APPENDIX D EXPENDABLE AND DURABLE ITEMS LIST

| | | |
|------------|---|-----|
| Section I | Introduction | D-1 |
| Section II | Expendable and Durable Items List | D-2 |

APPENDIX E LUBRICATION INSTRUCTIONSE-1

INDEX Index-1

HOW TO USE THIS MANUAL

SCOPE.

This technical manual provides you with the information you will need to operate and maintain the M969A2 Automotive Fuel Dispensing 5000-Gallon Tank Semitrailer.

The information contained in this manual is presented in three chapters and five appendixes. Each chapter is divided into sections covering operating procedures and/or other information for specific systems or components. When a reference is made to a table, figure, paragraph, or appendix, refer to that portion of the manual.

You must read and understand this manual BEFORE operating any of the semitrailers.

Throughout this manual you will frequently see the phrase "notify Unit maintenance." When instructed to notify Unit maintenance, do exactly that; Unit maintenance personnel have the tools and training to efficiently and correctly perform the next level of maintenance.

Note that the titles of publications and forms referenced anywhere in this manual are listed in Appendix A. Also, acronyms and abbreviations used in the manual are listed and spelled out on page 1-3.

INDEXING.

Four indexing procedures are used to help you locate information quickly:

- Cover Index. Lists chapters and other important parts of the manual, with corresponding page numbers. Each chapter/part listed is boxed in, with a black outer edge that is in line with the first page of that chapter/part.
- Table of contents. The table of contents starts on page i, following the summary of warnings.
- Section Indexes. Each section in a chapter starts with a numerical listing of all paragraphs in that section.
- Index. The alphabetically arranged subject index starts on page Index-1.

WARNINGS, CAUTIONS, AND NOTES.

Throughout this manual you will see WARNING, CAUTION, and NOTE headings. There are good reasons for every one of these notices.

WARNING

A warning is used to alert the user to hazardous operating and maintenance procedures, practices, or conditions that could result in injury or death. Warnings must be strictly observed.

CAUTION

A caution is used to alert the user to hazardous operating and maintenance procedures, practices, or conditions that could result in damage to, or destruction of, equipment or mission effectiveness. Cautions must be strictly observed.

WARNINGS, CAUTIONS, AND NOTES (continued).

NOTE

A note highlights an essential operating or maintenance procedure, condition, or statement.

Warnings and cautions appear immediately preceding the step to which they pertain. It is important to read and thoroughly understand the warnings and/or cautions before beginning maintenance.

Notes may precede or follow the steps to which they pertain, depending on what makes the most sense.


**CHAPTER 1
INTRODUCTION**

Section I. GENERAL INFORMATION

| Paragraph Number | Paragraph Title | Page Number |
|-------------------------|--|--------------------|
| 1-1 | Scope | 1-1 |
| 1-2 | Maintenance Forms and Procedures | 1-3 |
| 1-3 | Destruction of Army Materiel To Prevent Enemy Use | 1-3 |
| 1-4 | Reporting Equipment Improvement Recommendations (EIRs) | 1-3 |
| 1-5 | Corrosion Prevention and Control (CPC) | 1-3 |
| 1-6 | List of Abbreviations and Acronyms | 1-3 |
| 1-7 | Warranty Data | 1-4 |

1-1. SCOPE.

This manual contains operation and maintenance instructions for the M969A2 Automotive Fuel Dispensing 5000- Gallon Tank Semitrailer.



Throughout the manual, the terms "right side" or "curb side" and "left side" or "road side" are used to describe views of the semitrailer as viewed from the rear.

The operation and maintenance of any fuel-hauling semitrailer can be hazardous due to the flammable and explosive nature of the load.

Read and become familiar with all WARNINGS in the warning summary at the front of this manual. Throughout this manual, WARNINGS are placed as they pertain to specific operational or maintenance procedures. Read these warnings and follow them exactly.

The following is a summary of safety regulations that MUST be strictly observed when operating or maintaining the M969A2 semitrailers. Personnel who fail to follow these regulations endanger the mission, equipment, and their lives and the lives of bystanders.

- a. Refer to FM 10-20, FM 10-68, FM 10-69, and FM 10-71 to become familiar with safe fuel-handling procedures.
- b. Personnel engaged in the operation and maintenance of the semitrailer must not wear clothing that generates static electricity. DO NOT wear nylon, silk, rayon, or other similar materials. Remove all contents from pockets. Wear rubber boots and gloves during fuel loading and unloading.

1-1. SCOPE (continued).

- c. Before loading or unloading fuel or purging tank on semitrailer, connect all bonding and grounding connections (para 2-16b).
- d. Never climb on the semitrailer without first touching a grounding stud to discharge static electricity from your body.
- e. Under normal circumstances, perform all maintenance on the semitrailer outdoors, away from buildings, and with the tank empty. The semitrailer tank should be checked to make sure it is free of vapors that could ignite during maintenance activities.
- f. If circumstances require that maintenance be performed inside a building, the semitrailer tank must be thoroughly drained and purged and the exterior of the semitrailer must be steam cleaned. After purging, the combustible gas indicator must read in the SAFE zone. Even if the semitrailer has tested SAFE with a combustible gas indicator set, the semitrailer **MUST** be retested prior to starting work each day and at regular intervals throughout the day. This test can be accomplished by authorized Unit or Direct Support maintenance personnel with a military occupational specialty (MOS) of 77F or the equivalent (see FM 10-20).
- g. Hearing protection is required for personnel within 50 feet (15.25 m) of the semitrailer when the pump engine is running.
- h. To reduce the risk of fire and explosion, **DO NOT** perform the following operations on the semitrailer unless the tank has been drained and purged and the exterior has been steam cleaned:
 - Replace any component that communicated with the inside of the tank and therefore came in contact with fuel or vapors; these components include the manhole, the jet level sensor and tubing, the emergency valve, vapor collection system components, vent caps, the sump drain, and the piping assembly.
 - Troubleshoot the electrical system with any test device other than the ohms scale of a multimeter.
 - Weld or solder.
 - Cut with acetylene torch or chisel and hammer.
 - Drill (except aluminum).
- i. Follow these rules if working inside a purged tank:
 - Always provide adequate forced air ventilation with air directed inside to the compartment where work is being performed.
 - **NEVER** work alone inside a tank; a second person must be stationed at the manhole opening. A third person must be close by to provide aid and/or assistance in case of an emergency. The person inside the tank must have on a safety line and harness for rescue operations in case of emergency.
 - If the person inside the tank encounters any difficulties, the person stationed at the manhole must summon assistance **IMMEDIATELY**. **DO NOT** attempt a rescue until assistance has arrived.

1-2. MAINTENANCE FORMS AND PROCEDURES.

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by (as applicable) DA Pam 738-750 or AR 700-138.

1-3. DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE.

Refer to TM 750-244-6 for procedures on the destruction of military vehicles to prevent enemy use.

1-4. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR'S).

If your semitrailer needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design or performance. Put it on an SF Form 368 (Product Quality Deficiency Report). Mail it to the address specified in DA Pam 738-750.

1-5. CORROSION PREVENTION AND CONTROL (CPC).

Corrosion prevention and control (CPC) of Army materiel is a continuing concern. It is important that any corrosion problems with the semitrailers be reported so that the problems can be corrected and improvements can be made in order to prevent the problems in future semitrailers.

While corrosion is typically associated with the rusting of metals, it can also include deterioration of other materials, such as rubber and plastic. Unusual cracking, softening, swelling, or breaking of these materials may be a corrosion problem. If a corrosion problem is identified (refer to TB 43-0213), it can be reported using an SF Form 368. The use of key words, such as "corrosion, " "rust, " "deterioration, " or "cracking, " will ensure that the information is identified as a CPC problem. The form should be submitted to the address specified in DA Pam 738-750 for corrective maintenance. If the problem persists. notify Unit maintenance.

1-6. LIST OF ABBREVIATIONS AND ACRONYMS.

| | |
|------------|---------------------------------------|
| A | annually |
| AAL..... | Additional Authorization List |
| BIl..... | Basic Issue Items |
| CAGEC..... | Commercial and Government Entity Code |
| CARC | chemical agent resistant coating |
| Class..... | classification |
| COEI..... | Components of End Item |
| cp..... | candle power |
| DA..... | Department of the Army |
| DOD..... | Department of Defense |
| E | empty |
| EIR..... | equipment improvement recommendation |
| GAA..... | grease, automotive and artillery |
| H..... | hour |
| IAW..... | in accordance with |
| JTA | Joint Table of Allowances |

1-6. LIST OF ABBREVIATIONS AND ACRONYMS (continued).

| | |
|----------------|--|
| L..... | liter- low |
| LED..... | light-emitting diode |
| M..... | monthly |
| MOS | military occupational specialty |
| MTOE | Modification Table of Organization and Equipment |
| NBC | nuclear, biological, and chemical |
| NSN..... | national stock number |
| OC | on condition |
| p..... | page |
| para | paragraph |
| PMCS | preventive maintenance checks and services |
| Qty. Recm..... | quantity recommended |
| Qty. Rqr | quantity required |
| S | semiannually |
| S/N..... | serial number |
| TAMMS..... | The Army Maintenance Management System |
| TDA | Table of Distribution and Allowances |
| TOE | Table of Organization and Equipment |
| U/M..... | unit of measure |
| V dc | volts, direct current |
| W/ | with |
| W/O | without |

1-7. WARRANTY DATA.

There is no warranty on the M969A2 semitrailer.

Section II. EQUIPMENT DESCRIPTION AND DATA

| Paragraph Number | Paragraph Title | Page Number |
|------------------|--|-------------|
| 1-8 | Equipment Characteristics. Capabilities, and Features..... | 1-5 |
| 1-9 | Location and Description of Major Components..... | 1-6 |
| 1-10 | Equipment Data | 1-8 |

1-8. EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES.


The entire M969A2 semitrailer is constructed of welded stainless steel. Semitrailers have a stainless steel. single-compartment tank of 5000-gallon capacity, plus 3 percent capacity for product expansion. The chassis is constructed of welded steel and is equipped with full floating tandem axles and manually operated landing gear.

The semitrailer is designed to be towed by a truck tractor equipped with a fifth wheel. Authorized 5-ton truck tractors are the M818. M931, M931A1, M931A2, M932, M932A1, M932A2, and M1088. When driving on hard surface highways only, the 10-ton military -adapted commercial 6 x 4 truck tractors (the M915, M915A1, and M915A2) are also authorized.

The M969A2 semitrailer can be loaded through the bottom or the top fill opening. The four-cylinder diesel engine and pump assembly provide self-load/unload capability.

The semitrailer is equipped with pressure and vacuum vents, hose troughs, a sealed manhole, a vapor recovery system, bulk fuel hoses, a portable grounding rod, a static reel, and a spare tire. A ladder is provided at the rear of the M969A2 semitrailer for access to the top manhole.

1-9. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS.



1-9. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS (continued).

| KEY | COMPONENT | DESCRIPTION |
|------------|--|---|
| 1 | Hose Trough Covers | Protect hoses when stored in hose troughs. |
| 2 | Grounding Studs | Allow semitrailer to be grounded, discharging static electricity (four on top, one on each side). |
| 3 | Drain Pipes | Allow water to drain from top of semitrailer. |
| 4 | Emergency Valve Shut-Off Control | Manually stops fuel flow in an emergency. |
| 5 | Engine Fuel Tank | Stores fuel for pump engine. |
| 6 | Pump and Engine Compartment | Houses pump and engine. |
| 7 | Batteries | Provide electricity for starting pump engine. |
| 8 | Filter/Separator | Separates water from fuel and filters fuel. |
| 9 | Hose Troughs | Store hoses (one trough on left side, one on right side). |
| 10 | Portable Grounding Rod | Allows semitrailer to be grounded, discharging static electricity. |
| 11 | Ladder | Allows access to top manhole. |
| 12 | Portable M13 Decontaminating Apparatus | Used to spray decontaminating agent DS-2 on surfaces of semitrailer and equipment to reduce the level of toxic chemical agents. |
| 13 | Step | Allows access to ladder. |
| 14 | Spare Tire Carrier and Winch | Allow easy deployment and recovery of spare tire. |
| 15 | Fire Extinguishers | Provide portable fire extinguishing capabilities at point of operation. |
| 16 | Hose Reel Cabinets | House hose reels and hoses. |
| 17 | Piping Assembly | Dispenses fuel. |
| 18 | Tool Box | Stores tools. |
| 19 | Engine Control Panel | Houses controls, meters, and gages for pump engine. |
| 20 | Landing Leg Ground Boards | Positioned under landing leg shoe when semitrailer is uncoupled in mud, sand, or snow. |

1-10. EQUIPMENT DATA.

Bridge Classification:

| | |
|--|-----------|
| Empty weight with prime mover | Class. 14 |
| Empty weight without prime mover | Class. 6 |
| Cross-country loaded with prime mover | Class. 25 |
| Cross-country loaded without prime mover | Class. 18 |
| Highway loaded with prime mover | Class. 30 |
| Highway loaded without prime mover | Class. 22 |

Fuel-Dispensing Hose (Automotive, Overwing):

| | |
|--------------------|--------------------|
| Length | 50 ft (15.25 m) |
| Quantity | 2 |
| Nominal size | 1.25 in. (3.18 cm) |

Meter:

| | |
|------------------------|---------------|
| Quantity | 2 |
| Type | full metering |
| Maximum capacity | 100 gpm |

Angle of departure 60°

Capacities of Tank (Vehicle Capacity):

| | |
|--|-----------------------|
| Hard surface road and cross-country | 5000 gal. (18, 925 L) |
| 200/o maximum side slope without leakage | 5000 gal. (18, 925 L) |
| 10% maximum longitudinal slope without leakage | 5000 gal. (18, 925 L) |

Center of Gravity:

| | |
|--|----------------------|
| Empty (vertical) | 54 in. (137.16 cm) |
| Empty (horizontal from kingpin) | 198 in. (502.92 cm) |
| Loaded (vertical) | 66.5 in. (168.91 cm) |
| Loaded (horizontal from kingpin) | 170 in. (431.80 cm) |

Dimensions Overall:

| | |
|---------------------------|-----------------------|
| Height | 104.5 in. (265.43 cm) |
| Length | 366 in. (929.64 cm) |
| Width | 96 in. (243.84 cm) |
| To outside of tires | 97.75 in. (248.28 cm) |

Weights:

| | |
|---------------------|-------------------------|
| Empty | 16, 350 lb (7422.9 kg) |
| Tongue weight | 6800 lb (3087.2 kg) |
| Rear axle | 9650 lb (4381.1 kg) |
| Loaded | 50, 010 lb (22704.5 kg) |

Kingpin Location:

| | |
|----------------------------|-------------------|
| From nose of vehicle | 28 in. (71.12 cm) |
| To landing gear | 80 in. (203.2 cm) |

1-10. EQUIPMENT DATA (continued).

Portable Fire Extinguishers:

Type Purple-K, dry chemical
 Size 10 lb (4.5 kg)
 Number per vehicle 2

Tires

Quantity (including spare) 9
 Type radial
 Size 11.00 x R20 Numeric
 Tube equipped yes
 Tire pressure, cross-country and sand 45 psi (310.3 kPa)
 Tire pressure, hard surface roads 65 psi (448.2 kPa)

Towing Facility kingpin

Prime Mover:

5-ton M818, M931, M931A1, M931A2, M932, M932A1, M932A2, and M1088
 10-ton (hard surface highway only) M915 and M91SA1

Track:

Center to center of dual wheels 72 in. (182.88 cm)

Transfer Hose:

Type flexible
 Storage trough

Axles and Suspension:

Axle model number A21T-7CT7R-DW10A
 Capacity 25, 000 lb (11, 350 kg)
 Suspension model number 10476-01
 Type tandem overslung axle

Springs:

Type semielliptic multileaf
 Shaft semielliptic

Brakes:

Quantity 4 sets
 Type fail-safe
 Actuation full air S-type cam
 Operating pressure 75-95 psi (517-655 kPa)

Drain Valve:

Working pressure 120 psi (827.4 kPa)

Electrical System-Engine-

Type 12 V dc
 Alternator (Model A001-2300JB) 65 amps, belt drive
 Batteries 2, 12 V dc each, connected in parallel

Electrical System-Vehicle.

Voltage 24 V dc

1-10. EQUIPMENT DATA.

Lamps:
 Clearance lights 3 cp
 Taillights (service) 3 cp
 Taillights (blackout) 3 cp
 Stoplights (service) 32 cp

Engine:
 Type..... 4-cylinder, 4-cycle, diesel, air-cooled (Onan)
 Model..... DJC-4494W
 Horsepower 27.5
 Bore 3.25 in. (8.25 cm)
 Stroke 3.625 in. (9.21 cm)

Oil Capacity Crankcase:
 Without oil filter change 6 qt (5.6 L)
 With oil filter change 6-1/2 qt (6.149 L)
 Displacement 120 cu in (774 cu cm)
 Injection (firing) sequence 1-2-4-3

Throttle Control:
 Length 100 in. (645 cu cm)
 Model..... flexible
 Type push-pull with locking handle

Engine Air Cleaner:
 Capacity (Air-flow) 1 15 cf m @ 12 in. H20

Filter/Separator:
 Construction aluminum
 Rating 300 gpm @ 150 psi (1034.25 kPa)
 Differential pressure gage psi indicator 0-25 psid (0-172.38 kPa)

Bulk Fuel Servicing Hose (Two with Male and Female Connectors, One with Female Connector, Both Ends):
 Length 14 ft (4.27 m)
 Quantity 3
 Nominal size 4 in. (10.1 cm)

Hose Reels:
 Type electric, full control and manual crank

Landing Gear:
 Type vertical support with footpads
 Operation hand crank, two-speeds

Pump (4-Inch Model):
 Type low pressure, centrifugal
 Drive flexible coupling to engine

Emergency Valve Control:
 Type..... full release
 Control flexible cable

Section III. PRINCIPLES OF OPERATION


| Paragraph Number | Paragraph Title | Page Number |
|------------------|-------------------------------|-------------|
| 1-11 | General | 1-11 |
| 1-12 | Principles of Operation | 1-11 |

1-11. GENERAL.

The purpose of the M969A2 5000-gallon tank semitrailer is to provide the means for automotive refueling or bulk fuel hauling and delivery. The M969A2 semitrailer can be loaded through the top or bottom fill opening.


1-12. PRINCIPLES OF OPERATION.

PUMP AND ENGINE ASSEMBLY




ENGINE. Provides power through flexible coupling to the centrifugal pump (2). The diesel engine (1) is a 4-cylinder, 4-cycle, valve-in-head, air-cooled engine with a maximum rating of 27.5 horsepower, located on the curb side of the semitrailer. The engine (1) is operated and monitored by the control panel (3) located on the road side of the semitrailer.

PUMP. The M969A2 semitrailer is equipped with a 4-inch, self-priming, low-head, low-pressure centrifugal pump (2). The centrifugal pump (2) provides a flow rate for metered fuel (gasoline or diesel) delivery of up to 60 gpm through one or both fuel-dispensing nozzles.



1-12. PRINCIPLES OF OPERATION (continued).

FILTER/SEPARATOR ASSEMBLY



FILTER/SEPARATOR. Provides filtering capabilities to remove contamination and condensation in fuel. The filter/separator consists of an aluminum tank (1) containing 15 filter elements (5) and five second-stage water stripper elements (3). Fuel under pressure from the pump enters the filter tank inlet (6) and flows through the 15 filter elements (5), where solid particles are removed. The fuel then flows through the five second-stage water stripper elements (3), which further filter out smaller solid particles and coalesce water particles to be collected in the filter sump (7).

Coalescence is a process by which many small droplets of free water in the fuel are collected to form larger water drops.

These large water drops are then released into the filter sump (7).


AUTOMATIC WATER DRAIN VALVE. Allows water collected in the filter sump (7) to be automatically ejected. The filter sump (7) has a ball float that will float only in water and not in any type of fuel. As water accumulates in the filter sump (7) a float rises. When the float reaches a certain level, a valve will open in the automatic drain valve (9), allowing pump pressure to be applied to a diaphragm valve, opening the automatic drain valve (9). Water is then ejected out of the filter sump (7) through the automatic drain valve (9). While water is being ejected, fuel flow is continued.

MANUAL DRAIN VALVE. Used primarily during cold weather operations. Water accumulated in the filter sump may freeze. It is important that the manual drain valve (8) on the filter sump be opened after each operation to drain the water accumulation into suitable container. Be sure to close the manual drain valve after draining.

GO-NO-GO FUSES. Each of the five second-stage water stripper elements (3) is equipped with three Go-No-Go fuses (2). These fuses are fuel contaminant monitoring devices located "downstream" of the second stage. The fuses restrict the fuel flow when small amounts of water and solid contaminants are present in the fuel stream.

PRESSURE RELIEF VALVE. Automatically opens to relieve internal pressure of filter/separator when pressure exceeds 150 psi (984.2 kPa). Pressure relief valve (4) vents to the atmosphere.

1-12. PRINCIPLES OF OPERATION (continued).

VAPOR RECOVERY SYSTEM

VAPOR RECOVERY SYSTEM. The vapor recovery system allows a fuel depot to collect or recover the vapors and gases that are present during loading operations, and the semitrailer to collector recover the vapors and gases present during unloading operations. This system consists of a sealed vapor-tight line (5) from the vapor recovery hood (2) on the emergency valve vent (6) (directly behind the manhole cover) to the rear of the tank (3). The rollover rail (1) on the roadside of the semitrailer is used as part of the line (5). The adapter (4) on the end of the line (5) is compatible with the 4-inch vapor recovery quick-disconnect connections at a majority of the fuel depots.

1-13/(1-14 blank)

**CHAPTER 2
OPERATING INSTRUCTIONS**

Section I. DESCRIPTION AND USE OF OPERATOR'S CONTROLS AND INDICATORS


| Paragraph Number | Paragraph Title | Page Number |
|-----------------------------|---|------------------------|
| 2-1 | General | 2-1 |
| 2-2 | Engine Control Panel | 2-2 |
| 2-3 | Valves, Piping, and Dispensing Components | 2-4 |

2-1. GENERAL.

This section shows the location and function of all M969A2 semitrailer controls and indicators. Review this section thoroughly before operating the semitrailer.

2-2. ENGINE CONTROL PANEL.

The engine control panel is located on the road side of the semitrailer, above the piping assembly. Control functions and gage readings are explained in the table that follows the illustration.



| KEY | COMPONENT | DESCRIPTION |
|-----|------------------|--|
| 1 | Preheater Switch | Connects battery voltage to glow plugs in engine intake manifold to preheat the engine. (Engine switch, item 2, must be in RUN position.) |
| 2 | Engine Switch | In RUN position, energizes engine electrical system and fuel pumps to permit engine operation. STOP position cuts off fuel supply and stops the engine. |
| 3 | Indicator Light | This should turn on when preheater switch, item 1, is turned to ON position. If light does not come on, it indicates there is no current flow to the manifold heaters and glow plugs |


2-2. ENGINE CONTROL PANEL (continued).

| KEY | COMPONENT | DESCRIPTION |
|-----|--------------------------------|--|
| 4 | Starter Switch | Engages starter motor to turn and start the engine. (Engine switch, item 2, must be in RUN position.) |
| 5 | Battery Voltage Gage | Indicates battery operating voltage. Normal indication is 12-14 V dc with engine running. |
| 6 | Engine Operating | Contains engine operating instructions. Instruction Plate |
| 7 | Valves Operating | Contains valve operating instructions. Instruction Plate |
| 8 | Control Panel Cover | Protects control panel when not in use. |
| 9 | Engine RPM (Tachometer) | Indicates engine rpm. Used with flow rate/rpm data plate or Table 2-3 (p. 2-52) to select desired flow rate. |
| 10 | Engine Hours Meter | Indicates engine running time. |
| 11 | Engine Throttle | Controls and sets engine speed. Pull out handle to selected setting, then rotate it clockwise to lock it in position. |
| 12 | Control Panel Light and Switch | Activated to illuminate control panel. Activate light switch at bottom of light. |
| 13 | Oil Pressure Gage | Indicates pressure in engine lubrication system. Normal indication is 30-40 psi (207-276 kPa) when engine is warm and running. |
| 14 | Fuel Pressure Gage | Indicates pressure in fuel injection system. Normal indication is 12-14 psi (83-97 kPa). |
| 15 | Filter/Separator Gage | Indicates amount of restriction in filter/separator. |
| | | NOTE |
| | | Pressure will vary. Engine speed, type of operation, and nozzles used have a direct effect on pump pressure. |
| 16 | Pump Pressure Gage | Indicates pressure in pump discharge line. Normal operating pressure is 30 psi (207 kPa) for the four-inch low-head pump. |

2-3. VALVES, PIPING, AND DISPENSING COMPONENTS.

The operator/crew should become thoroughly familiar with the location of valves, piping, and dispensing components, and with the piping schematic mounted on the storage box cover before beginning any fuel-servicing or fuel-dispensing operation.

Piping Control Assembly. This assembly contains a four-inch pilot-operated control valve, plus the components listed in the table that follows.




| KEY | COMPONENT | DESCRIPTION |
|-----|-----------------------------------|---|
| 1 | Bottom Loading Adapter (D-1) | Allows tanker to be closed-circuit loaded from the bottom |
| 2 | Valve E | Located next to precheck valve (D). Provides load/unload selection. |
| 3 | Fuel-Dispensing Instruction Plate | Provides engine rpm and pump gpm requirements during fuel-dispensing operations |
| 4 | Valve D, Precheck | Provides a way to check shut-off float for proper functioning. |

2-3. VALVES, PIPING, AND DISPENSING COMPONENTS (continued).

| KEY | COMPONENT | DESCRIPTION |
|-----|---|---|
| 5 | Check Valve | Eliminates backflow of fuel during bottom loading. |
| 6 | Top Manifold | Directs fuel to various valves. |
| 7 | Valve K | Allows fuel flow between bulk delivery connections and hose reel assembly. Located on rear manifold. |
| 8 | Hose Reel Cabinet Door | Covers hose reel cabinet. Assembly |
| 9 | Static Reel | The static ground cable is pulled from static reel and attached to unit being serviced or to a ground plug, stud, or clamp. The static reel has an automatic locking device that engages when cable is extended to desired length and releases when cable is pulled out again. The reel is spring loaded to rewind automatically. |
| 10 | Valve F | Opens pump outlet line to permit bulk fuel delivery (nonfiltered). |
| 11 | Rear Manifold | Directs fuel to various valves. |
| 12 | Outlet B | Main outlet for bulk fuel delivery. |
| 13 | Valve B | Controls the opening for bulk delivery connections. Fastened to the rear manifold. |
| 14 | Valve G | Permits gravity unloading and self-loading. Valve is open when handle is parallel to pipe. Located between front and rear manifolds. |
| 15 | Valve H | Permits fuel flow through manifold to pump. Located in front manifold. |
| 16 | Valve J | Allows water to drain from front manifold. |
| 17 | Front Manifold | Directs fuel flow to valve(s). |
| 18 | Valve A, Emergency Valve Control Handle | Mechanically controls operator emergency valve on outlet sump and vapor vent on top of semitrailer. |
| 19 | Top Manifold Drain Cocks (Two) | Permit water to drain from top manifold. |

2-3. VALVES, PIPING, AND DISPENSING COMPONENTS (continued).

Hose Reel Cabinet




2-3. VALVES, PIPING, AND DISPENSING COMPONENTS (continued).

| KEY | COMPONENT | DESCRIPTION |
|-----|-------------------------|---|
| 1 | Front Hose Reel | Stores and rewinds front 1 1/4-inch hose. |
| 2 | Meter Outlet Nipple | Connects meter to hose reel. |
| 3 | Front Meter | Records amount of fuel being dispensed through front hose. |
| 4 | Meter Reset Knob | Pushed in and turned clockwise to reset meter. |
| 5 | Rear Meter | Records amount of fuel being dispensed through rear hose. |
| 6 | Meter Reset Knob | Pushed in and turned clockwise to reset meter. |
| 7 | Valve R | Permits fuel flow through the rear hose reel. (Valve is open when handle is parallel to pipe). |
| 8 | Hose Reel Rewind Crank | Used to manually rewind hose reels. (Turn clockwise for left hose reel; turn counterclockwise for right hose reel.) Installed on rewind shaft of hose reel. (Stored in hose reel cabinet.) |
| 9 | Hose Reel Rewind Button | Used to electrically rewind hose reels. (Use while engine is running to avoid discharging battery.) |
| 10 | Static Reel | The static ground cable is pulled from static reel and attached to unit being serviced and to a ground plug, stud, or clamp. The static reel has an automatic device that engages when cable is extended to desired length and releases when cable is pulled out again. The static reel is spring loaded to rewind automatically. |
| 11 | Hose Reel Lock | Locks hose reel in position. |
| 12 | Rear Hose Reel | Stores and rewinds rear 1 1/4-inch hose. |
| 13 | Valve P | Permits fuel flow through front hose reel. (Valve is open when handle is parallel to pipe.) |
| 14 | Hose Reel Rewind Button | Used to electrically rewind hose reels. (Use while engine is running to avoid discharging battery.) |
| 15 | Hose Reel Lock | Turn hand wheel on hose reel clockwise to lock hose reel in position. Turn hand wheel counterclockwise to release hose reel lock. |

2-3. VALVES, PIPING, AND DISPENSING COMPONENTS (continued).

Filter/Separator



| KEY | COMPONENT | DESCRIPTION |
|-----|-----------------------|---|
| 1 | Antipilferage | Gives operator a quick method of checking for filter/ separator tampering |
| 2 | Relief Valve | Gives pressure/vacuum relief during loading or unloading. |
| 3 | Valve M | Controls fuel flow from pump outlet to inlet of filter/ separator Valve is open when handle is parallel to pipe |
| 4 | Pump | With engine running, provides fuel flow and pressure to system |
| 5 | Pump Inlet Screen | Catches large particles. preventing damage to pump assembly |
| 6 | Filter/Separator | Filters p[articulates and separates water from fuel when fuel flows through system. |
| 7 | Valve N | Allows manual draining of sump on filter/separator. |
| 8 | Float Assembly | Allows automatic discharge of excess water. |
| 9 | Automatic Drain Valve | Automatically drains water from filter sump when water accumulates to a certain level. |

**Section II. OPERATOR/CREW PREVENTIVE MAINTENANCE
CHECKS AND SERVICES (PMCS)**

| Paragraph Number | Paragraph Title | Page Number |
|-------------------------|---|--------------------|
| 2-4 | General | 2-9 |
| 2-5 | Service Intervals | 2-9 |
| 2-6 | Reporting Repairs | 2-9 |
| 2-7 | General PMCS Procedures | 2-10 |
| 2-8 | Specific PMCS Procedures | 2-10 |
| 2-9 | Leakage Definitions | 2-11 |
| Table 2-1 | Operator/Crew Preventive Maintenance Checks and Services (PMCS) | 2-12 |

2-4. GENERAL.

- a. To ensure that the M969A2 semitrailers are ready for operation at all times, they must be inspected on a regular basis so that defects may be found before they result in serious damage, equipment failure, or injury to personnel. This section contains systematic instructions on inspections, adjustments, and corrections to be performed by the operator.
- b. While performing PMCS, read and follow all safety instructions found in the Warning Summary at the front of this manual. Keep in mind all WARNINGS and CAUTIONS.

2-5. SERVICE INTERVALS.

Perform PMCS procedures, listed in Table 2-1, at the following intervals:

- Perform Before PMCS just before operating the M969A2 semitrailer.
- Perform During PMCS while operating the M969A2 semitrailer.
- Perform After PMCS right after operating the M969A2 semitrailer.
- Perform Weekly PMCS once each week.
- Perform Monthly PMCS once each month.

2-6. REPORTING REPAIRS.

All defects that the operator cannot fix must be reported on a DA Form 2404, Equipment Inspection and Maintenance Worksheet, immediately after completing PMCS. If a serious problem is found, IMMEDIATELY report it to your supervisor on Unit maintenance.

2-7. GENERAL PMCS PROCEDURES.

WARNING

- Drycleaning solvent P-D-680 is toxic and flammable. Always wear protective goggles and gloves, and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes, and DO NOT breathe vapors. DO NOT use near open flame or excessive heat.
 - When drycleaning solvent is used, notify the local medical authority (preventive medicine) and environmental coordinator concerning medical surveillance, respiratory protection, and disposal requirements.
- a. Keep Equipment Clean. Dirt, oil, and debris may cover up a serious problem. Clean as you work and as needed. Use drycleaning solvent (Item 3, Appendix D) on all metal surfaces. Use solution of soap (Item 12, Appendix D) and water on rubber, plastic, and painted surfaces.
- b. While performing specific PMCS procedures, inspect the following components:
- Bolts, Nuts, and Screws.** Make sure they are not loose, missing, bent, or broken. If possible, tighten loose bolts, nuts, and screws with tools from BII (Section III, Appendix B). Report missing bolts, nuts, and screws to Unit maintenance.
- Welds.** Inspect for gaps where parts are welded together. Check for loose or chipped paint, rust, and cracks. Report bad welds to Unit maintenance.
- Electric Conduit, Wires, or Connectors.** Inspect for cracked or broken conduit insulation, bare wires, and loose or broken connectors. Report any damage, leaks, or loose fittings to Unit maintenance.
- Hose and Fluid Lines.** Inspect for wear, damage, and leaks. Make sure that clamps and fittings are tight. Wet spots indicate leaks, of course, but a stain around a fitting or connector can also mean a leak. If a leak comes from a loose fitting or connector, notify Unit maintenance. If something is broken, damaged, or worn out, report it to Unit maintenance.
- c. Check to see that components are adequately lubricated in accordance with Appendix E.
- d. Check to see that basic issue items (BII) are on the semitrailer and in good working condition. BII consists of the items in Appendix B, Section III. The semitrailer is considered not fully mission capable if any of these items are missing.

2-8. SPECIFIC PMCS PROCEDURES.

- a. Operator/crew PMCS as provided in Table 2-1. Always perform PMCS procedures in the order listed. Once they become routine, spotting problems will become much easier.
- b. Before performing PMCS, read all the checks required for the applicable interval and prepare all tools needed for the task. Have several clean rags (Item 15, Appendix D) ready for use. Perform ALL inspections at the applicable intervals. Necessary tools are in BII (Appendix B Section III).
- c. If any problems are discovered through PMCS, perform the appropriate troubleshooting task as described in Chapter 3, Section II. If any component or system is not serviceable, or if any service does not correct the problem, notify your supervisor.

2-8. SPECIFIC PMCS PROCEDURES (continued).

- d. Table 2-1, your PMCS table. Lists the inspections and care of your equipment required to keep it good operating condition. Explanations of the column headings are as follows

Item No. The item number column is to be used for reference When completing DA Form 2404, include the item number for the check/service indicating a fault Item numbers also appear in the order that you must do checks and services for the intervals listed.

Interval. This column tells you when to do a certain check or service.

Item To Check/Service. This column names the location and the item to be checked or serviced.

Procedure. This column tells you how to do the required checks and services and which crew member(s) is responsible for each check or service. Carefully follow these instructions. If you do not have the tools, or if the procedure tells you to, have Unit maintenance do the work.

Not Fully Mission Capable If. This column tells you when and why your equipment cannot be used.

2-9. LEAKAGE DEFINITIONS.

- a. It is important to know how fluid leakage affects the status of the semitrailer. The following are types/classes of leakage an operator must know to determine whether the semitrailer is mission-capable. Learn these leakage definitions. When in doubt, notify your supervisor.

Leakage Definitions

Class I Seepage of fluid (as indicated by wetness or discoloration) not great enough to form drops.

Class II Leakage great enough to form drops. but not great enough to cause drops to drip from item being inspected.

Class III Leakage of fluid great enough to form drops that fall from the item being inspected.

WARNING

The semitrailer must not be operated if there are any fuel leaks from semitrailer tank or from engine. Report any fuel leaks to your supervisor or Unit maintenance. Failure to do so will result in a fire hazard, which can cause severe injury or death to personnel.

CAUTION

When operating engine with Class I or 11 oil leaks, continue to check fluid levels in addition to that required in PMCS. Parts without fluid will stop working or may be damaged.

- b. Equipment operation is allowed with minor (Class I or 11) leakage. Fluid levels in an item/system affected with such leakage must be checked more frequently than required in PMCS. When in doubt, notify your supervisor.
- c. Report Class III oil leaks IMMEDIATELY to your supervisor or Unit maintenance.

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS)

| ITEM NO. | INTERVAL | ITEM TO CHECK/ SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|-------------------------|---|--|
| 1 | Before | Exterior of Semitrailer | <p style="text-align: center;">NOTE</p> <p>Perform Weekly as well as Before PMCS if:</p> <p>a. You are the assigned operator but have not operated the semitrailer since the last weekly PMCS.</p> <p>b. You are operating the semitrailer for the first time.</p> <p>a. Walk around semitrailer. Check for evidence of product leakage on or under semitrailer.</p> <p>b. Check each fire extinguisher. Make sure red button is down. Check security of mounting bracket or security pin.</p> <p>c. Check for operation of hazardous materials placards.</p> | <p>a. Any product leakage is evident.</p> <p>b. Fire extinguisher is missing. Red button is up. Security pin is missing (if so equipped).</p> <p>c. Any placard is missing or inoperative.</p> |




Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)

| ITEM NO. | INTERVAL | ITEM TO CHECK/ SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|--|--|--|
| 2 | Before | Tank | <ul style="list-style-type: none"> a. Inspect tank shell for dents, leaks, and broken welds. b. Check for leaks around fusible vent caps. Tighten caps if loose. c. Check for leaks around manhole cover. If leaks are evident, check for damaged cover gasket or loose mounting ring. Also check to see that cover can be opened, closed, and securely latched. d. Inspect front and rear catwalk drains for clogs or restrictions. Remove any debris or foreign matter. e. Inspect vapor recovery hood for any loose, damaged, or missing hardware. f. Check tank for rust at intersections where brackets are welded to tank. Check condition of paint. If any damage is found, notify your supervisor. | <ul style="list-style-type: none"> a. Tank shell has fuel leaks. b. Any fuel leaks are present. c. Manhole cover gasket is damaged, manhole cover cannot be securely closed, or any fuel leaks are present. |
| 3 | Before | Kingpin or Upper Coupler (Kingpin) Plate | <ul style="list-style-type: none"> a. Inspect kingpin or upper coupler (kingpin) plate for damage or loose mounting bolts, or mounting bolts are loose. b. Visually inspect for obvious cracked or broken welds around kingpin. <div data-bbox="651 1018 1029 1360" style="text-align: center;"> </div> | <ul style="list-style-type: none"> a. Kingpin or upper coupler (kingpin) plate is damaged |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)



| ITEM NO. | INTERVAL | ITEM TO CHECK/ SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|------------------------|---|--|
| 4 | Before | Engine Assembly | Perform before-operation checks listed in paragraph 2-17a, engine operating instructions.  | Engine does not operate and is required for mission. |
| 5 | Before | Centrifugal Pump | Inspect pump for signs of leaks | Any fuel leaks are present. |
| 6 | Before | Batteries | Check batteries for secure mounting. | Battery is required for mission but is damaged |
| 7 | Before | Filter/ Separator | Check relief valve for debris at top of filter/ separator Remove debris  | |
| 2-14 | | | | |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)


| ITEM NO. | INTERVAL | ITEM TO CHECK/SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|-----------------------|---|--|
| 8 | Before | Hose Troughs | <p>Visually inspect hose trough lock bars for obvious damaged or missing parts. Check all mounting hardware for loose or missing components. Check drain holes for clogs or debris. Remove debris.</p>  | |
| 9 | Before | Vapor Recovery Kit | Check discharge outlet for debris or any other foreign matter. Check all mounting hardware for loose or missing components. | Vapor recovery kit is required for mission, but is damaged. |
| 10 | Before | Tires and Wheels | Inspect tires and wheels for unusual wear or damage. | Tires or wheels have damage that could result in tire failure. |
| 11 | Before | Spare Tire Winch | <p>a. Visually inspect spare tire winch assembly for loose, damaged, or missing components. Assembly</p> <p>b. Visually inspect for frayed or worn cable.</p> | <p>b. Cable is frayed or worn.</p> |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)

| ITEM NO. | INTERVAL | ITEM TO CHECK/ SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|------------------------|---|---|
| 12 | Before | Hose Reels | Check operation of rewind handle for front and rear hose reels | Either front or rear hose reel is inoperable. |
| | | | | |
| 13 | Before | Grounding Devices | <ul style="list-style-type: none"> a. Check static reel operation. Inspect for missing grounding clips and loose or missing mounting hardware. b. Check portable grounding rod to ensure that it is not damaged or missing. | <ul style="list-style-type: none"> a. Static reel is missing from vehicle or is damaged. b. Portable grounding rod is missing from vehicle or is damaged. |
| 14 | During | Piping System | <ul style="list-style-type: none"> a. Check all valves and couplings for leaks. b. Check valves P and R for proper operation. | <ul style="list-style-type: none"> a. Any fuel leaks are present. b. Valve is hard to open or close. |
| 15 | During | Towing Connections | <ul style="list-style-type: none"> a. Connect air lines of prime mover to couplings on semitrailer. With prime mover engine running, check air lines and couplings for air leaks. b. Connect electrical line of prime mover to receptacle on semitrailer. Check all lights for damage. Check to see that all lights are operating, and check tightness of connection at receptacle. If tight, and lights still do not operate, notify Unit maintenance. Check electrical line for damage. | <ul style="list-style-type: none"> a. Air leaks are present. b. Turn signal and stop lights are not operating. Prime mover intervehicular cable is damaged (cuts, cracks, broken wires, etc.) |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)



| ITEM NO. | INTERVAL | ITEM TO CHECK/ SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|------------------------|---|---|
| 16 | During | Brake System | <p>a. With prime mover coupled to semitrailer, apply prime mover brakes and inspect semitrailer service and emergency air brake couplings and all air lines and fittings for leaks. If leaks are found, notify Unit maintenance.</p>  | <p>a. Any leaks are present.</p> |
| 17 | During | Landing Gear | <p>a. With prime mover coupled to semitrailer, engage landing gear handle and raise and lower landing gear legs.</p> <p>b. Inspect landing leg ground boards for serviceability.</p>  | <p>b. Brakes do not stop semitrailer, or semitrailer pulls to one side.</p> <p>a. Landing gear legs cannot be raised or lowered.</p> <p>b. Wood is required for mission but is dry-rotted</p> |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)



| ITEM NO. | INTERVAL | ITEM TO CHECK/SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|-----------------------|--|--|
| 18 | During | Emergency Valve | <p>Make sure all valves are closed. Move emergency valve A control handle to OPEN position. On front curb side of the semitrailer, pull emergency valve shut-off control. Make sure emergency valve A control handle has moved to CLOSED position.</p>  | Emergency valve A does not move to the CLOSED position. |
| 19 | During | Engine Assembly | <p>a. Check air cleaner restriction indicator for red area. If red area is visible, remove and clean engine air cleaner filter element (para 3-9). Notify Unit maintenance to replace air cleaner filter element after six cleanings or annually.</p> <p>b. Check engine assembly for fuel and oil leaks.</p>  | <p>a. Restriction indicator has red area visible.</p> <p>b. Any fuel leaks or Class III oil leaks are present.</p> |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)



| ITEM NO. | INTERVAL | ITEM TO CHECK/ SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|------------------------|---|---|
| 20 | During | Filter/ Separator | <p>Place suitable container under automatic drain valve. Check automatic drain valve on bottom of filter/separator for fuel seepage. No other liquid except water should be detected at the automatic drain valve.</p>  | Any fuel leaks are present. |
| 21 | During | Rear Axles | <p>During movement of semitrailer, be aware of wander or side pull. Listen for excessive noise. These are indications of improper rear axle alignment.</p>  | Semitrailer wanders, has side pull, or rear axles make excessive noise. |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)

| ITEM NO. | INTERVAL | ITEM TO CHECK/ SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: | | | | | | | | | | | | | | | | | | | | |
|----------|----------|-----------------------------|---|--|----|--------|-----------------------------|--|--|----|--------|-------------------------|--|---|--|--|--|--|--|----|--------|-----------------------------|---|--|
| 22 | During | Hoses and Hose Reels | a. When unwinding hoses, observe for binding in front Or rear hose reel b. Inspect hoses for cuts and cracks | a. Hose reel binds or will not unwind hose. b. Either hose has cuts or cracks that allow leakage. | | | | | | | | | | | | | | | | | | | | |
| | | | | | 23 | During | Meters | Check front and rear meters for registration of fuel being dispense, | | 24 | During | Precheck Control System | Check operation of shut-off float (para 2-18a) | Precheck control system does not operate. Emergency valve A control handle does not move freely from closed to open position. | | | | | | 25 | During | Load/ Unload Selector Valve | Check operation of selector control valve (para 2-18b). | Load/unload selector valve does not operate. Emergency valve A control handle does not move freely from closed to open position. |
| 23 | During | Meters | Check front and rear meters for registration of fuel being dispense, | | | | | | | | | | | | | | | | | | | | | |
| 24 | During | Precheck Control System | Check operation of shut-off float (para 2-18a) | Precheck control system does not operate. Emergency valve A control handle does not move freely from closed to open position. | | | | | | | | | | | | | | | | | | | | |
| | | | | | 25 | During | Load/ Unload Selector Valve | Check operation of selector control valve (para 2-18b). | Load/unload selector valve does not operate. Emergency valve A control handle does not move freely from closed to open position. | | | | | | | | | | | | | | | |
| 25 | During | Load/ Unload Selector Valve | Check operation of selector control valve (para 2-18b). | Load/unload selector valve does not operate. Emergency valve A control handle does not move freely from closed to open position. | | | | | | | | | | | | | | | | | | | | |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)


| ITEM NO. | INTERVAL | ITEM TO CHECK/SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|-----------------------|--|--|
| 26 | During | Control Panel | <p>a. Check switches for proper operation</p> <p>b. Check to see that preheat indicator light is lit when engine is preheating.</p>  <p>c. Check gages for proper operation as follows:</p> <ol style="list-style-type: none"> (1) Check tachometer operation. (2) Battery voltage gage should read 12-14 V do with engine running (3) Oil pressure gage should read 30-40 psi (206.9-275.8 kPa) with engine warm and running. (4) Fuel pressure gage should read 12-14 psi (82.7-96.5 kPa). (5) Pump pressure gage should read 30 psi (206.9 kPa) for four-inch low-head pump. (6) Check filter/separator gage <p>d. Check control panel light for proper operation</p> | <p>a. Switch does not work</p> <p>b. Preheat indicator light is not lit.</p> <p>c(1). Tachometer is inoperative or operates erratically.</p> <p>c(3). Oil pressure gage is inoperative or operates erratically</p> <p>c(5). Pump pressure gage is not functioning properly during pumping operations.</p> <p>c(6). Filter/separator gage indicates 20 psi (137.9 kPa) or higher.</p> |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)





| ITEM NO. | INTERVAL | ITEM TO CHECK/ SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|--------------------------|---|---|
| 27 | During | Emergency Valve and Vent | <p>Make sure all valves are closed. Operate emergency valve A control handle, and make sure cable is actuating emergency valve shut-off control and opens vent on top of semitrailer.</p>  | Emergency valve A control handle will not actuate emergency valve shut-off control, or vent fails to open. |
| 28 | After | Piping System | <p>a. Inspect all pipes for dents and cracks.</p> <p>b. Drain water from piping system drains.</p>    | <p>a. Pipes are damaged to the extent that fuel flow will be restricted. Pipes are cracked, allowing fuel leakage</p> |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)



| ITEM NO. | INTERVAL | ITEM TO CHECK/SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|-----------------------|--|--|
| 29 | After | Brake System | <p>a. Drain water from both air reservoirs by opening air reservoir drain cocks.</p> <p>b. Check mounting screws and mounting brackets for loose, missing, or damaged hardware.</p>  | <p>b. Notify Unit maintenance if hardware is loose, missing, or damaged.</p> |
| 30 | After | Engine Assembly | <p>a. Inspect for debris in grille of air cooling intake area.</p> <p>b. Inspect alternator belt for tightness and cracks.</p> <p>c. Inspect hoses and connections for tightness and leaks.</p> <p>d. Inspect electrical harnesses for tightness and cracks</p> <p>e. Check engine oil level. Add oil if needed. For oil specifications, refer to page E-8.</p> <p>f. Check fuel tank for fuel. Add if needed; 1/4 of a tank is required.</p>  | |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)




| ITEM NO. | INTERVAL | ITEM TO CHECK/ SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|---------------------------|--|--------------------------------------|
| 31 | After | Hose Troughs | Inspect troughs for debris. Remove any debris found and check to see that water drain holes are open.  | |
| 32 | Weekly | Landing Gear | Inspect for loose landing gear shoes, bent or damaged landing gear legs, and loose or missing mounting bolts.  | Mounting bolts are loose or missing. |
| 33 | Weekly | Engine Assembly | Visually inspect engine assembly for loose, damaged, or missing cowlings or shrouds.  | Any cowling or shroud is missing. |
| 34 | Weekly | Centrifugal Pump | Remove pipe plug and check oil level. Add oil if below bottom of pipe plug hole. For oil specifications, refer to page E-8. | |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)


| ITEM NO. | INTERVAL | ITEM TO CHECK/ SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|------------------------------|---|--|
| 35 | Weekly | Batteries | a. Remove battery cover. Visually inspect batteries for damage. b. Check electrolyte level in each cell.  | a. Any battery is damaged. b. If electrolyte level is low, notify Unit maintenance. |
| 36 | Weekly | Battery Cables and Terminals | Check for corrosion at terminals. Check cable tightness on terminals. Check for cable damage. | If terminals are loose or damaged, notify Unit maintenance. |
| 37 | Weekly | Tires and Wheels | Check for proper air pressure: Radial hard road surface - 65 psi (448.2 kPa). Cross country - 45 psi (310.8 kPa). | |
| | | | | |
| 38 | Monthly | Tires and Wheels | a. Inspect wheels for cracks or other damage. Check tightness of wheel nuts. b. Inspect spare tire for secure mounting. c. Inspect wheel assemblies. | a. Wheel is damaged or three or more wheel nuts are missing. |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)




| ITEM NO. | INTERVAL | ITEM TO CHECK/ SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|------------------------|--|--|
| 39 | Monthly | Suspension | <p>a. Visually inspect Trunnion assembly for obvious damage.</p> <p>b. Inspect springs for broken leaves.</p> <p>c. Visually inspect suspension for loose, missing, or damaged hardware.</p>  | <p>c. Suspension hardware is loose, missing, or damaged.</p> |
| 40 | Monthly | Engine Assembly | <p>Using a suitable container, drain water from both fuel filters. Using combination wrench set (Item 24, Appendix B), loosen but do not remove drain plugs at bottom of filters. Allow fuel to drain until clear of water Tighten drain plugs.</p>  | |

Table 2-1. Operator/Crew Preventive Maintenance Checks and Services (PMCS) (continued)

| ITEM NO. | INTERVAL | ITEM TO CHECK/SERVICE | PROCEDURE | NOT FULLY MISSION[CAPABLE IF: |
|----------|----------|-------------------------|---|---|
| 41 | Monthly | Fuel-Dispensing Nozzles | Clean nozzle screens (para 3-11). | |
| 42 | Monthly | Fire Extinguishers | <p style="text-align: center;">WARNING</p> <p>Handle charged fire extinguisher cylinders with care. DO NOT jar or expose to temperature above 140OF (60-C).</p> <p>a. Remove cover from each fire extinguisher. Check to see that lockup handle moves freely and is not damaged.</p> <p>b. Check to see that plastic indicator on top of fire extinguisher is intact.</p> <p style="text-align: center;">NOTE</p> <p>Some fire extinguishers have a safety wire lead or plastic seal attached to pull pin.</p> <p>c. Check to see that safety wire lead or plastic seal is not broken or missing.</p> <p>d. Check to see that tube is not kinked and nozzle is free of obstructions.</p> <div style="text-align: center;">  </div> | <p>a. Lockup handle is missing, damaged, or inoperative.</p> <p>b. Plastic indicator is missing, damaged, or inoperative.</p> <p>c. Safety wire lead or plastic seal is missing, damaged, or inoperative.</p> <p>d. Tube or nozzle is missing, damaged, or inoperative.</p> |

Section III. OPERATION UNDER USUAL CONDITIONS

| Paragraph Number | Paragraph Title | Page Number |
|-------------------------|--|--------------------|
| 2-10 | General..... | 2-28 |
| 2-11 | Initial Adjustments, Checks and Self-Test..... | 2-28 |
| 2-12 | Coupling Semitrailer to Prime Mover..... | 2-29 |
| 2-13 | Spare Tire Dismounting and Mounting..... | 2-32 |
| 2-14 | Uncoupling Semitrailer from Prime Mover | 2-34 |
| 2-15 | Decals and Data Plates..... | 2-36 |
| 2-16 | General Fuel-Handling Instructions..... | 2-38 |
| 2-17 | Engine Operating instructions | 2-40 |
| 2-18 | Fueling/Defueling Precheck and Operations Summary | 2-44 |
| 2-19 | Basic Bulk Haul and Fuel-Servicing Operations Not Involving Use of Engine and Pump..... | 2-46 |
| 2-20 | Nonfiltered Fuel Servicing Involving Use of Engine and Pump..... | 2-52 |
| 2-21 | Filtered Fuel Servicing Operations | 2-57 |
| 2-22 | Refuel on the Move (ROM) Assembly and Operating Procedures | 2-60 |

2-10. GENERAL.

WARNING

If used incorrectly, this equipment can cause severe injury or death. Those who use and maintain the equipment should be trained in its proper use, should be warned of its dangers, and should read this entire manual before attempting to set up, operate, adjust, or service the equipment.

This section provides operator/crew instructions for the operations and proper use of the M969A2 semitrailers under usual conditions.

2-11. INITIAL ADJUSTMENTS, CHECKS, AND SELF-TEST.

WARNING

Equipment, safety devices, and working areas must be inspected frequently to ensure personal and operational safety and to correct potential or actual hazards.

- a. The semitrailer must not be operated if any of the following conditions exist.
 - (1) Fuel leaks
 - (2) Damage to wiring or electrical conduits, causing inoperative lights
 - (3) Damage to prime mover or semitrailer
 - (4) Inoperative primary or parking brake systems.

2-11. INITIAL ADJUSTMENTS, CHECKS AND SELF-TEST (continued).**NOTE**

Pressure, vacuum, and fusible vents are installed to meet code requirements and to protect the semitrailer from damage. A plugged or inoperative vent can cause extensive shell damage if design pressure or vacuum is exceeded. The fusible vents are designed to operate at high temperatures if these vents are coated with paint, dirt, or other foreign material, the temperature when relief vent opens may be greatly increased.

- (5) Plugged, inoperative, or removed vents
- b. The before-operation services specified in Title 2-1, Operator/Crew Preventive Maintenance Checks and Services, must be performed before using the semitrailer
- c. You must follow approved practices and precautions. A detailed study of Section IV, Operation Under Unusual Conditions, is essential for use of the M96C3A2 semitrailer under unusual conditions.


2-12. COUPLING SEMITRAILER TO PRIME MOVER.**WARNING**

All personnel must stand clear of prime mover and semitrailer during coupling operation. Failure to follow this warning may result in serious injury or death to personnel.

CAUTION

Do not ram prime mover into semitrailer upper coupling (kingpin) plate. Failure to follow this caution may damage equipment.

1. With the aid of an assistant, back prime mover slowly to front of semitrailer. Maneuver prime mover so kingpin (4) on semitrailer is in line with fifth wheel jaws on prime mover
2. Stop prime mover before upper coupler (kingpin) plate (5) of semitrailer starts to ride on fifth wheel of prime mover.
3. Make sure kingpin (4) and fifth wheel are properly aligned. Landing gear legs (3) may need to be raised or lowered to align the level of upper coupler (kingpin) plate (5) and fifth wheel.
4. Back prime mover under upper coupler (kingpin) plate (5) until kingpin (4) and fifth wheel hook automatically. Make sure kingpin (4) and fifth wheel are engaged and locked. Engage prime mover parking brake.
5. Remove dummy couplings (1) from semitrailer service air coupling (6) and semitrailer emergency air coupling (2). Connect prime mover air line marked SERVICE to service air coupling (6), and connect air line marked EMERGENCY to emergency air coupling (2)



2-12. COUPLING SEMITRAILER TO PRIME MOVER (continued).

CAUTION


Proper operation of semitrailer primary brake system is essential for safe operation of vehicle. Functional system check is necessary before putting trailer into service. Semitrailer parking brakes are provided to maintain braking and holding requirements whether semitrailer is fully loaded or empty. The system will automatically apply parking brakes when air pressure in primary reservoir falls below specified pressure. Proper operation of this system must be maintained.

6. Close drain valves (7) on front and rear reservoir tanks (8 and 9).


NOTE

Some prime movers are not equipped with shut-off valves.

7. Open shut-off valves on air lines of prime mover



8. Plug intervehicular cable (10) into receptacle (11) on semitrailer.




2-12. COUPLING SEMITRAILER TO PRIME MOVER (continued).

9. With the aid of an assistant, operate lights from prime mover to make sure all semitrailer lights are working properly.
10. Release landing gear operating crank (13) from clip (15), and engage crank (13) on shaft (12).

NOTE

- **When there is no load, pull out on crankshaft to engage high-speed gears for fast raising or lowering of landing gear legs.**
- **When greater power is needed, push in on operating shaft to engage low-speed gears to lower or raise landing gear legs.**
- **Rotate crank clockwise to raise landing gear legs. Rotate crank counterclockwise to lower landing gear legs.**

11. Rotate crank (13) and raise landing gear legs (3).
12. Replace crank (13) in clip (15).



13. If ground boards (14) were used, stow them in brackets (16) at each side of semitrailer.


2-13. SPARE TIRE DISMOUNTING AND MOUNTING.**a. DISMOUNTING**

- 1 Remove two nuts (6) and reinforcement channel (7) from studs and spare tire (5).
- 2 Remove curb-side then road-side quick-release pins (1) from ladder (4) and carrier assembly (3).



WARNING

Spare tire and ladder are heavy. Make sure cable is not frayed or damaged. Do not raise spare tire and ladder past the vertical position or they will slam into carrier assembly. Failure to heed this warning may result in severe injury to personnel or damage to the equipment.

- 3 Rotate winch handle (8) until cable (2) is tight, then rotate winch handle (8) 1-1/2 turns in opposite direction.
- 4 Push spare tire (5) and ladder (4) away from carrier assembly (3) until supported by cable (2).
- 5 Rotate winch handle (8) until spare tire (5) and ladder (4) are fully lowered to the ground and cable (2) is slack.
- 6 Unhook cable (2) from ladder (4) and remove cable (2) from spare tire (5). Roll spare tire (5) off ladder (4).



2-13. SPARE TIRE DISMOUNTING AND MOUNTING (continued).

**b. MOUNTING**

- 1 Roll spare tire (5) onto ladder (4). Route cable (2) through ventilation holes in spare tire (5) and hook to ladder (4).

WARNING

Spare tire and ladder are heavy. Make sure cable is not frayed or damaged. Do not raise spare tire and ladder past the vertical position or they will slam into carrier assembly. Failure to heed this warning may result in severe injury to personnel or damage to the equipment.

2. Rotate winch handle (8) until spare tire (5) and ladder (4) are nearly vertical, with weight still supported by cable (2).
3. Carefully push spare tire (5) and ladder (4) in until resting against carrier assembly (3).
4. Install road-side then curb-side quick-release pins (1) in ladder (4) and carrier assembly (3).
5. Secure spare tire (5) to carrier assembly (3) with two nuts (6) and reinforcement channel (7)
6. Rotate winch handle (8) until cable (2) is tight and winch handle (8) is pointing down

2-14. UNCOUPLING SEMITRAILER FROM PRIME MOVER.**WARNING**

All personnel must stand clear of prime mover and semitrailer during uncoupling operation. Failure to follow this warning may result in serious injury or death to personnel.

NOTE


If the semitrailer is to be uncoupled in mud, sand, or snow, or if the prime mover is an M931 AI or M932A1, begin at step

1. Otherwise, go to step 2.
1. Center ground boards (1) beneath landing gear shoes (4).
2. Close shut-off valves on service and emergency air lines at rear of prime mover.


NOTE

Semitrailer brakes will set automatically when service airbrake hose is uncoupled.


3. Disconnect emergency and service air lines from emergency and service air couplings (2 and 3) on semitrailer.
4. Install dummy couplings (5) in semitrailer emergency and service air couplings (2 and 3).
5. Disconnect intervehicular cable (7) from receptacle (6) on semitrailer.



2-14. UNCOUPLING SEMITRAILER FROM PRIME MOVER (continued).



6. Open drain valves (9) on front and rear reservoirs (8 and 10).
7. Release landing gear operating crank (12) from clip (13), and engage crank (12) on shaft (11).
8. Rotate crank (12) counterclockwise to lower landing gear (14) until shoes (4) are firmly on the ground or ground boards (1).
9. Replace crank (12) in clip (13) and secure.



10. Pull out lockjaw handle to release semitrailer kingpin from prime mover's fifth wheel hook. If hook is binding and will not release, pull hook harder to force release.
11. Drive prime mover forward until semitrailer is disengaged from prime mover and is resting on semitrailer's landing gear (14).

2-15. DECALS AND DATA PLATES.

- a. The following illustrations show the location and contents of all decals and data plates.
- b. Maintain all decals and data plates so that all information remains legible. If any decals or data plate is missing or no longer legible, notify Unit maintenance.

NOTE: A dotted line means the decal/data plate is hidden from view

OPERATING INSTRUCTIONS-M969A2
EACH OPERATION BEGINS AND ENDS WITH ALL VALVES CLOSED

| OPERATION | VALVE POSITIONS | | | | | | | | | | | | | | | | |
|------------------------|-----------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | A | B | C | D | E | F | G | H | I | J | K | L | M | N | O | P | Q |
| 1. WATER DRAIN | 0 | | | | | | | | | | | | | | | | |
| 2. GRAVITY UNLOAD | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 3. BOTTOM LOAD | 0 | | | | | | | | | | | | | | | | |
| 4. BULK DELIVER | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 5. SELF LOAD | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 6. FILTERED BULK DELVY | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 7. KIT DISP & T. RED. | 0 | | | | | | | | | | | | | | | | |
| 8. KIT DISP ACW FILTER | 0 | | | | | | | | | | | | | | | | |
| 9. PRE-CHECK | 0 | | | | | | | | | | | | | | | | |

0: OPEN 1: LOAD 2: UNLOAD

A. IN AN EMERGENCY, CLOSE VALVE "A" OR PULL EMER. VALVE SHUT OFF ON OPPOSITE SIDE.
B. PERIODICALLY CHECK FILTER SEPARATOR PRESSURE DIFFERENTIAL.
C. DO NOT EXCEED 100 G.P.M. THRU FILTER WHEN PUMPING DIESEL FUEL (MOTOR GASOLINE 300 G.P.M.)
D. USE HIGH ENGINE SPEED ONLY TO ATTAIN MAXIMUM FLOW. START ENGINE BEFORE OPENING VALVES.

SEMI-TRAILER, TANK, 5000 GAL., M969A2
NATIONAL STOCK NO. 2330-01-377-9337
MANUFACTURED BY _____ U.S.A.
VEHICLE IDENTIFICATION NO. _____
CONTRACT NO. _____

PUBLICATIONS
TECHNICAL MANUALS: TM-9-2330-398-10, TM-9-2330-398-10HR, TM-9-2330-398-24, TM-9-2330-398-24P

WEIGHT AND DIMENSION DATA
DIMENSIONS: 301, 187.50, 211, 104, 177, 80, 170, 52, 58, 16, 104, 58

| WEIGHT | EMPTY | CROSSCOUNTRY/HIGHWAY |
|------------|------------|----------------------|
| PAYLOAD | 33,950 LBS | |
| ON WHEELS | 11,271 LBS | 30,288 LBS |
| ON KINGPIN | 5,229 LBS | 20,162 LBS |
| TOTAL | 16,500 LBS | 50,450 LBS |

SHIPPING CUBAGE-2200 CU FT

DELIVERY DATE _____ INSPECTED _____

ENGINE OPERATING INSTRUCTIONS

- CHECK ENGINE FUEL AND OIL LEVELS. USE NO. 2 DIESEL FUEL ABOVE 32 F. NO. 1 DIESEL FUEL BELOW 32 F.
- TO START COLD ENGINE, TURN ENGINE SWITCH TO "RUN" POSITION, TURN PRE-HEATER SWITCH TO "ON" POSITION FOR 1 MINUTE. AFTER 1 MINUTE, HOLDING PRE-HEATER SWITCH, TURN STARTER SWITCH TO "START" POSITION. DO NOT HOLD "START" POSITION MORE THAN 10 SECONDS. RELEASE WHEN ENGINE STARTS.
- IF ENGINE FAILS TO START AFTER CRANKING INTERMITTENTLY FOR 1 MINUTE, PRE-HEAT 1 MINUTE MORE. THEN REPEAT INTERMITTENT CRANKING. RELEASE WHEN ENGINE STARTS.
- TO SHUT OFF ENGINE, THROTTLE ENGINE TO IDLE AND TURN ENGINE SWITCH TO "STOP" POSITION.
- IF ENGINE IS RESTARTED AFTER SHORT PERIOD OF TIME, PRE-HEATING IS USUALLY NOT REQUIRED. FOR OTHER INSTRUCTIONS CONSULT ENGINE SERIAL NUMBER PLATE AND OPERATOR'S MANUAL.

THROTTLE LOCK



FUEL DISPENSING BULK HAUL-M969A2

| SELF LOADING | KIT DISPENSING | | | | BULK DELIVERY | | | | | |
|--------------|----------------|---------------|-------------|---------------|---------------|---------------|-------------|---------------|------|------|
| | THRU FILTER | BYPASS FILTER | THRU FILTER | BYPASS FILTER | THRU FILTER | BYPASS FILTER | THRU FILTER | BYPASS FILTER | | |
| ENG RPM | 2200 | 2400 | 1200 | 2400 | 1200 | 2400 | 2200 | 2400 | 2200 | 2400 |
| PUMP GPM | 290 | 320 | 44 | 88 | 44 | 88 | 175 | 190 | 480 | 530 |

DECREASE ENGINE RPM TO OBTAIN LOWER GPM IF REQD

VALVE E FUNCTION SELECTOR
LOAD UNLOAD

VALVE D LOADING PRE-CHECK
OPEN CLOSED

CAUTION
PRE-CHECK AT START OF EACH BOTTOM LOADING OR SELF LOADING OPERATION.

CAUTION

- DO NOT REWIND HOSE REELS SIMULTANEOUSLY.
- REWIND HOSES WHILE ENGINE IS RUNNING TO AVOID DISCHARGING BATTERY.

CAUTION


THIS TANK IS EQUIPPED WITH AN EMISSION COLLECTION HEADER, TERMINATING AT THE VAPOR RETURN CONNECTION.

WHEN BOTTOM LOADING THE TANK, THE VAPOR RETURN LINE OF ADEQUATE CAPACITY, TO PREVENT CREATION OF A PRESSURE OF 1.5 PSIG OR A VACUUM OF 0.5 PSIG, IN ORDER TO AVOID DAMAGE TO THE TANK BEING LOADED.

NORMAL VENTING, IN ACCORDANCE WITH DOT-MC-406 WILL BE OPERATIONAL BELOW THESE PRESSURE AND VACUUM LIMITS.

(Mounted on Hose Reel)

2-15. DECALS AND DATA PLATES (continued).



VAPOR RECOVERY KIT, FUEL SERVICING

MANUFACTURED BY _____

KIT IDENTIFICATION NO. **11685993**


CONTRACT NO. _____

PUBLICATIONS

TECHNICAL MANUAL **TM 9-2330-398-24**

DELIVERY DATE _____ INSPECTED _____

WARNING
MAXIMUM CAPACITY
3000 GALLONS
WHEN USED WITH 5 TON PRIME MOVER



SEMITRAILER TANK 5000 GALLON

- USE ALL (4) LIFTING PROVISIONS WHEN LIFTING.
- USE SIZE 30 SLING ASSEMBLY IN ACCORDANCE WITH MIL-S-22824.
- USE ADDITIONAL 3 FT. EXTENSION SLING ON EACH FRONT LEG FOR LEVEL LIFT WITH EMPTY LOAD.
- USE ADDITIONAL 1 3/8" DIA. SHACKLE ON EACH FRONT LEG FOR LEVEL LIFT WITH FULL LOAD.
- USE ALL (8) TIEDOWNS TO SECURE.

| TRAILER | EMPTY WEIGHT | FULL WEIGHT |
|---------|--------------|-------------|
| M969A2 | 16060 | 50010 |
| | | |
| | | |

WEIGHT IN LBS

MAX. LIFTING LOAD FOR PROVISIONS 500010 LBS

MFG.' S/N _____ DATE _____

D.O.T.-MC-406 CERT. _____

PRES-DESIGN O P.S.I.G. 180° F

TEST 3 P.S.I.G. DATE _____

MATL-SHELL-T304 S.S. HEAD-T 304 S.S.

WELD-308 LINING - NONE

ONE COMPT 5000 U.S. GAL.

MAX. LOAD 37,500LBS. 7.5 LBS./GAL.

LIMIT-LDG 1.5 P.S.I.G. UNL 0.5 P.S.I.G.

2-16. GENERAL FUEL-HANDLING INSTRUCTIONS.

WARNING

- Follow all fuel-handling procedures precisely, to prevent injury or death to personnel.
 - Make sure that grounding connections are made properly and firmly before any fueling operations begin so that grounding connections will not release. This will eliminate the possibility of static electricity creating sparks which will ignite the fuel. Failure to follow this warning may result in serious injury or death to personnel.
 - Ladder has narrow tread. Use care when climbing.
- a. **SAFETY PRECAUTIONS.** It is important that all fuel-handling and operating procedures be followed precisely. A detailed study of FM 10-20, FM 10-68, FM 10-69, and FM 10-71 is essential for all fuel-handling operations.
- b. **BONDING AND GROUNDING**

NOTE


Always connect a static ground cable to the vehicle, storage facility, aircraft, or equipment being serviced. If portable ground is used, make sure a good connection is made. Make sure grounding cables are secured to grounding studs.

1. Bonding is electrically connecting units or containers to equalize any static potential that might exist before operations begin and to provide a continuous path for any static electricity that might be generated after operations begin.
 2. Grounding is electrically connecting single or bonded units to a ground rod to discharge into the earth any static potential that might already exist or that might be generated.
 3. If two or more units are bonded, and one is grounded, the whole system is effectively grounded.
 4. Follow bonding and grounding procedures presented in specific paragraphs on loading, transferring, and dispensing.
 5. Before performing maintenance on semitrailer, semitrailer must be grounded to an approved (earth) ground.
- c. **FIRE EXTINGUISHERS.** During all fuel-handling operations, the fire extinguishers must be removed from their stowage brackets and brought to the point of operation. Replace fire extinguishers and their covers when fuel servicing is completed.

2-16. GENERAL FUEL-HANDLING INSTRUCTIONS (continued).**WARNING**

The operator must be alert for leaking and malfunctioning equipment. Stop all servicing operations immediately at the first sign of leaks or malfunctions. Corrective action must be performed by qualified technicians before resuming any operations. Failure to observe these precautions may result in injury to personnel.

- d. **SPILLS AND LEAKS.** All spills must be cleaned up immediately. Suitable containers must be placed under hose connections to collect leakage or spills.
- e. **VAPOR RECOVERY.** Refer to paragraph 1-11 for information on the vapor recovery system.
- f. **BULK FUEL SERVICING HOSES.** Whenever bulk fuel hose is required, remove the necessary lengths from hose troughs and couple together as required.
- g. **FUEL-DISPENSING NOZZLES.** Make sure hoses are installed with correct fuel dispensing nozzles for the operation intended. Refer to paragraph 3-11 to install fuel-dispensing nozzles.
- h. **EMERGENCY VALVE OPERATION.** The emergency valve (2) controls the tank outlet. The emergency valve (2) and its vapor vent (3) are mechanically operated by the emergency valve A control handle (5) in the piping control assembly. Engaging the emergency valve A control handle (5) opens the emergency valve (2) to permit fuel flow to/from tank sump. At the same time, vapor vent (3) at top of tank opens to relieve pressure/ vacuum during loading or unloading.
 1. Emergency valve (2) must be open for all loading/unloading operations except top loading.
 2. In an emergency, close emergency valve (2) by disengaging emergency valve A control handle (5) (road side of semitrailer), or by pulling emergency valve shut-off (1) (curb side).
 3. In the event of fire or explosion, either the fusible nut (6) on emergency valve A control handle (5) or the fuse plates (4) at emergency valve (2) will melt, releasing emergency valve (2) and automatically stopping fuel flow.



2-17. ENGINE OPERATING INSTRUCTIONS.**WARNING**

Before and after fuel-servicing operations, all valves are to be in the closed position. Failure to follow this warning could result in excessive spillage and create a fire hazard.


CAUTION

- Prior to starting engine, make sure all manually operated valves are closed. This is a must before starting or ending any fuel-servicing operation.
- To prevent collapse of tank when filling or emptying tank, make sure that the top vent is working properly.
- Open only those valves required to perform a specific operation. All other valves must remain closed. Close all valves again after completing the operation.

a. BEFORE OPERATION**NOTE**

Before starting engine, the checks and services listed in steps 1 through 3 should be performed.

- 1 Before starting engine (1), remove fuel tank cap (4) and check fuel level in fuel tank (5). Fill with winter-grade diesel fuel oil (Item 6, Appendix D) or Arctic diesel fuel oil (Item 4, Appendix D) for operation below 32°F (0°C). Use regular-grade diesel fuel oil (Item 5, Appendix D) for operation above 32°F (0°C). Tank capacity is approximately four gallons (15.1 L).



2-17. ENGINE OPERATING INSTRUCTIONS (continued).

2. Pull oil dipstick (6) and check oil level. If dipstick (6) reads L (low), add one quart to bring oil to F (full) mark. If below L mark, add one quart at a time until dipstick (6) reads F. For oil specifications, refer to page E-8.
3. Check air cleaner restriction indicator window (2). A red band indicates that engine air cleaner (3) is dirty. Clean or replace air cleaner filter element (para 3-9).

b. STARTING ENGINE**WARNING**

- **Carbon monoxide can be deadly. DO NOT operate engine in an enclosed area unless it is adequately ventilated.**
- **Hearing protection is required within 50 feet of tanker during operation of engine. Failure to follow this warning may result in injury to personnel.**

NOTE

This procedure is for starting a cold engine in temperatures above 55°F (13°C).

1. Set engine switch (11) on control panel (8) to RUN.


NOTE

When engine is warm or is being restarted after short periods of time, preheating is usually not necessary. In temperature below 30°F (-1°C), a longer preheating period is needed (subpara f).

2. Set preheater switch (12) to ON for about one minute. Make sure indicator light (13) is illuminated.
3. After one minute, turn starter switch (7) to START.
4. After engine (1) starts, release starter switch (7) and preheater switch (12).
5. Check gages (10) on control panel (8) for correct indications (Table 2-1). Stop engine (1) if a system malfunction is indicated.


c. STOPPING ENGINE

1. To allow for gradual cooling of engine, run engine at fast idle (1200 rpm) for about five minutes before stopping.
2. Release throttle (9) to allow engine (1) to return to low idle.
3. Set engine switch (7) to STOP.



2-17. ENGINE OPERATING INSTRUCTIONS (continued).**d. ENGINE OPERATION (High Temperature)**

1. Make sure nothing obstructs air flow to and from engine oil cooler (15) and cylinder cooling fins (16).
2. Make sure all shrouds (14) are properly installed and in good condition.

**e. ENGINE OPERATION (Low Temperature)**

1. Make sure engine (1) has the proper oil and fuel for existing temperatures. For fuel specifications, refer to paragraph 2-17a. For oil specifications, refer to page E-8.
2. Keep batteries (17) fully charged.

NOTE


Entire cold weather starting procedure may not be required. The colder the temperature, the more preheating and cranking will be required.

f. COLD WEATHER STARTING**NOTE**

When temperatures are below 30°F (-1°C), use this procedure to start engine.

1. Pull out throttle (9) about halfway.
2. Set preheater switch (12) to ON.

2-17. ENGINE OPERATING INSTRUCTIONS (continued).



3. After two minutes, set engine switch (11) on control panel (8) to RUN. Wait 15 seconds, then turn starter switch (7) to START and crank for 15 seconds. Release starter switch (7).

NOTE

DO NOT disengage starter switch at first firing of engine. Continue with switch engaged for a limited time (30 seconds maximum) to help engine run and gain speed.

4. Wait one minute and turn starter switch (7) to START. Crank for one minute, or until running, then release starter switch (7). Leave preheater switch (12) in ON position for about five minutes after engine starts.
5. If engine still has not started, turn starter switch (7) to START and crank for one minute. Engine should be firing. Release starter switch (7) when engine speed is increasing.
6. Release preheater switch (12).

2-18. FUELING/DEFUELING PRECHECK AND OPERATIONS SUMMARY.**a. LOADING PRECHECK****WARNING**


When filling tank by means of bottom loading or self-loading, a test of the precheck system is mandatory. If this system is not functioning, stop all operations. Determine the problem and have it corrected by a qualified technician. Failure of automatic shut-off to function may result in uncontrolled fuel spillage and danger of fire and explosion.

1. Shortly after fuel flow has begun, open precheck valve D (4) to precheck automatic shut-off. Opening valve D (4) sends fuel to float valve (2) inside tank to simulate full-tank condition.
2. If shut-off float is functional, flow should stop after about 20-25 seconds.
3. Close valve D (4). Flow will resume in about 20 seconds.
4. During normal loading through bottom of tank (3), shut-off system will stop incoming flow automatically when fuel reaches the level of the float valve (2).

b. LOAD/UNLOAD SELECTOR

Before opening any valves for a fuel-servicing operation, make sure unload/load selector valve E (5) handle is in proper position for fuel-servicing operation.

- (a) Load Position. When selector valve E (5) is in load position, it directs pilot pressure to the 4-inch (10.16- cm)



2-18. FUELING/DEFUELING PRECHECK AND OPERATIONS SUMMARY (continued).

- (b) Unload Position. When selector valve E (5) is in unload position, it shuts off pilot pressure to the 4-inch (10.16 cm) control valve (1). With pilot pressure shut off, the 4-inch (10.16 cm) control valve (1) closes, eliminating flow through control valve (1) during bulk delivery and fuel-servicing operation.

C. FUELING/DEFUELING OPERATIONS.

WARNING

All fueling/defueling operations must be performed outside.

NOTE

Refer to Table 2-2, Fueling/Defueling Operations Summary, for a list of paragraphs pertaining to the semi-trailer.

Table 2-2. Fueling/Defueling Operations Summary

The following operations can be performed with the M969A2 semi-trailer:

BULK HAUL AND FUEL SERVICING NOT INVOLVING USE OF ENGINE AND PUMP

| | |
|------------------------------------|------------|
| Top Loading | Para 2-19a |
| Bottom Loading (Nonfiltered) | Para 2-19b |
| Gravity Unload..... | Para 2-19c |

NONFILTERED FUEL SERVICING INVOLVING USE OF ENGINE AND PUMP

| | |
|------------------------------|------------|
| Self-load | Para 2-20a |
| Bulk Delivery..... | Para 2-20b |
| Nonfiltered Dispensing | Para 2-20c |

FILTERED FUEL-SERVICING OPERATIONS

| | |
|-------------------------------|------------|
| Filtered Bulk Delivery..... | Para 2-21a |
| Filtered Fuel Dispensing..... | Para 2-21b |

WARNING

DO NOT mix incompatible fuels in tank. Dangerous fumes and explosion may result. Know what fuel was previously carried so that preventive measures may be taken to ensure that injurious or explosive fumes are not released. Failure to follow this warning may result in injury or death to personnel.

Changing Fuels. If fuel to be loaded is not the same fuel as previously carried, refer to FM 10-71 for information on purging requirements.

2-19. BASIC BULK HAUL AND FUEL-SERVICING OPERATIONS NOT INVOLVING USE OF ENGINE AND PUMP.**a. TOP LOADING****WARNING**

- When top loading through fill cover, there is no automatic shutdown. Man the loading hose to avoid fuel spillage. Use capacity indicator gage and dipstick gage to determine amount of fuel loaded. Failure to follow this warning may result in uncontrolled fuel spillage and a fire or explosion hazard.
- Ladder has narrow steps. Use care when climbing.

1. Review general fuel-handling instructions (para 2-16).

NOTE

Operation begins and ends with all valves closed.

2. Make sure all valves are closed.

NOTE


When loading with a rack or stand, perform step 3. When loading with a hose, perform step 4.

3. Connect bonding and grounding cable (3) of loading rack or stand to one of six grounding studs (2) before opening manhole fill cover (1).
4. Before opening fill cover (1), connect vehicle bonding and grounding cable (3) to one of four grounding studs (2) on top of tank and to some part of permanent piping of storage facility (4).

NOTE

The loading hose supplied by the storage facility may have a metal fitting on the free end, and the hose may not be bonded internally. Such a fitting is insulated and could become charged.

5. Install vapor recovery hose (5).




2-19. BASIC BULK HAUL AND FUEL-SERVICING OPERATIONS NOT INVOLVING USE OF ENGINE AND PUMP (continued).

6. Remove fire extinguishers (6) and bring them to the point of operation.

WARNING

Manhole fill cover does not lock open. Injury may occur if manhole fill cover accidentally closes on personnel.

7. Remove padlock (7). Slowly open fill cover (1) in manhole cover (9) and insert hose far enough to keep end of hose in contact with bottom of tank.



NOTE

Capacity indicator gage is located inside tank near fill cover.

8. Slowly begin flow, and fill tank no further than to bottom of capacity indicator gage (8).
9. Remove vapor recovery hose (5). Close and secure fill cover (1) with padlock (7).
10. Drain accumulated water (para 2-19d).
11. Remove bonding and grounding cable (3) from storage facility (4) and grounding studs (2) on semi-trailer. Store and cover fire extinguishers (6).

b. BOTTOM LOADING (NONFILTERED)



1. Review general fuel-handling instructions (para 2-16).

NOTE

Operation begins and ends with all valves closed.

2. Make sure all valves are closed.
3. Remove fire extinguishers (6) and bring them to the point of operation.

2-19. BASIC BULK HAUL AND FUEL-SERVICING OPERATIONS NOT INVOLVING USE OF ENGINE AND PUMP (continued).



4. Connect static reel grounding cable (15) to ground rod (16) (Item 20, Appendix B) or other suitable ground.
5. Remove cover (11) from bottom loading connection (12). Connect bottom loading hose to bottom loading connection (12).
6. Set function selector valve E (13) to LOAD position.
7. Pull emergency valve A control handle (10) to OPEN position.
8. Begin fuel flow.

WARNING

When filling tank by means of bottom loading, a test of precheck system is mandatory. If this system is not functioning, stop all operations and notify your supervisor. Failure of automatic shut-off to function may result in uncontrolled fuel spillage and danger of fire and explosion.

9. After flow has begun, set precheck valve D (14) to OPEN position to precheck automatic shut-off (para 2-18a). If shut-off float is functional, flow should stop after about 20-25 seconds.
10. Set precheck valve D (14) to CLOSED position. Flow will resume in about 20 seconds.

NOTE

If fuel flow into semi-trailer stops because of a shut-off float malfunction, a defective 4-inch control valve, or the presence of leaks, or if any other unusual conditions are observed, stop fuel supply at loading facility and notify your supervisor.

2-19. BASIC BULK HAUL AND FUEL-SERVICING OPERATIONS NOT INVOLVING USE OF ENGINE AND PUMP (continued).

11. When tank is full, fuel flow should stop automatically. Close all valves. Disconnect hose from bottom loading connection (12) and install cover (11). Drain hose into suitable container.
12. Drain accumulated water (para 2-19d).

WARNING

DO NOT let go of static reel grounding cable when rewinding until ball stop is firmly touching reel. Failure to follow this warning may cause injury to personnel.

13. Disconnect static reel grounding cable (15) from ground rod (16) (Item 20, Appendix B) or suitable ground.
14. Store and cover fire extinguishers (6).


C. GRAVITY UNLOAD

1. Review general fuel-handling instructions (para 2-16).


NOTE

Operation begins and ends with all valves closed.

2. Make sure all valves are closed.
3. Connect static reel grounding cable (15) to ground rod (16) (Item 20, Appendix B) or suitable ground.
4. Disconnect spring pins and turn hose trough bars out of the way to remove 4-inch (10.16-cm) bulk delivery hose(s) from trough.



2-19. BASIC BULK HAUL AND FUEL-SERVICING OPERATIONS NOT INVOLVING USE OF ENGINE AND PUMP (continued).



5. Remove dust cover (19) from outlet B (17). Connect 4-inch (10.16-cm) bulk delivery hose to outlet B (17) and storage facility.
6. Remove fire extinguishers (6) and bring to point of operation.
7. Make sure valve E (13) is in UNLOAD position.
8. Pull emergency valve A control handle (10) to OPEN position and open valves B, G, and H (18, 20, and 21) to begin flow.
9. At end of operation, close all valves. Drain 4-inch (10.16-cm) bulk delivery hose into suitable container. Disconnect hose and put it in hose trough. Secure hose trough latches. Install dust cover (19) on outlet B (17).
10. Drain accumulated water (para 2-19d).

WARNING

DO NOT let go of static reel grounding cable when rewinding until ball stop is firmly touching reel. Failure to follow this warning may cause injury to personnel.

11. Remove static reel grounding cable (15) from ground rod (16) or suitable ground.
12. Store and cover fire extinguishers (6).




2-19. BASIC BULK HAUL AND FUEL-SERVICING OPERATIONS NOT INVOLVING USE OF ENGINE AND PUMP (continued).

d. WATER DRAIN

NOTE

- Accumulated water should be drained from the system after each period of operation.
- Operation begins and ends with all valves closed.

1. Make sure all valves are closed.
2. Place suitable container under manifold (23) in piping control cabinet. Pull emergency valve A control handle (10) to OPEN position. Slowly open valves H and J (21 and 22). Allow to drain until pure fuel begins to flow. Close valves H and J (21 and 22), and set emergency valve A control handle (10) to CLOSED position.
3. Place suitable container under drain valves (25 and 26). Open drain valves (25 and 26). Drain valves (25) are located behind piping control assembly near 4-inch (10.16-cm) flow control valve (24). Drain valves (26) are located beneath the tank, fastened to emergency valve discharge tube (27). Allow to drain until fuel begins to flow. Close drain valves.
4. Place suitable container under valve N (30) on bottom of filter/separator (29). Open valve M (28), then slowly open valve N (30). Allow to drain until fuel flow begins. Close valves N and M (30 and 28).



2-20. NONFILTERED FUEL SERVICING INVOLVING USE OF ENGINE AND PUMP.

a. SELF-LOAD

NOTE

- Use this procedure when it is necessary to use onboard engine and pump to load fuel from storage facility to semi-trailer.
- Operation begins and ends with all valves closed.

1. Review general fuel-handling instructions (para 2-16).
2. Make sure all valves are closed.
3. Connect static reel grounding cable (4) to storage facility. Remove fire extinguishers and bring to point of operation.
4. Start engine (para 2-17b). When engine is warm, adjust to idle speed (1000-1200 rpm).
5. Disconnect spring pins and turn hose trough bars out of the way to remove 4-inch (10.16-cm) bulk fuel hose from hose trough.
6. Remove dust cover (5) from outlet B (6) and connect bulk fuel hose to outlet B (6) and storage facility.
7. Put valve E (2) in LOAD position.
8. Pull emergency valve A control handle (1) to OPEN position.
9. Open valves B and G (7 and 8).
10. Adjust engine throttle for desired flow rate (refer to Table 2-3).




Table 2-3. Fuel-Dispensing Flow Rates in Gallons per Minute (GPM)

| | SELF-LOAD | | DISPENSING | | | | BULK DELIVERY | | | |
|------------|-----------|------|------------|------|-------------|------|---------------|------|-------------|-----|
| | | | FILTERED | | NONFILTERED | | FILTERED | | NONFILTERED | |
| ENGINE RPM | 2200 | 2400 | 1200 | 2400 | 2200 | 2400 | 2200 | 2400 | | |
| PUMP GPM | 290 | 320 | 44 | 88 | 44 | 88 | 175 | 190 | 480 | 530 |

**2-20. NONFILTERED FUEL SERVICING INVOLVING USE OF ENGINE AND PUMP
(continued).**

WARNING

When filling tank by means of bottom loading, a test of the precheck system is mandatory. If this system is not functioning, stop all operations. Notify Unit maintenance. Failure of automatic shut-off to function may result in uncontrolled fuel spillage and danger of fire and explosion.

11. Shortly after flow has started, open valve D (3) to precheck automatic shut-off. If shut-off float is functional, flow should stop after about 20-25 seconds (para 2-18a).
12. Close valve D (3). Flow will resume in about 20 seconds.

WARNING

In an emergency, pull emergency valve A control handle to CLOSED or pull emergency valve A shut-off valve on opposite side (curb side) of semi-trailer. Failure to do so may result in injury to personnel.

13. When tank is full, flow should stop automatically.
14. At end of operation, idle down engine. Close all valves. Drain 4-inch (10.16 cm) bulk delivery hose into suitable container. Disconnect hose and place in hose trough. Secure hose trough latches. Install dust cover (5) on outlet B (6).
15. Stop engine (para 2-17c).
16. Drain accumulated water (para 2-19d).

WARNING

DO NOT let go of static reel grounding cable when rewinding until ball stop is firmly touching reel. Failure to follow this warning may cause injury to personnel.

17. Remove static reel grounding cable (4) from storage facility.
18. Store and cover fire extinguishers.


b. BULK DELIVERY**NOTE**

- **Use this procedure to pump fuel from semi-trailer to storage facility.**
- **Operation begins and ends with all valves closed.**

1. Review general fuel-handling instructions (para 2-16).
2. Make sure all valves are closed.
3. Connect static reel grounding cable (4) to storage facility. Remove fire extinguishers and bring them to the point of operation.
4. Start engine (para 2-17b). When engine is warm, adjust engine speed to 1000-1200 rpm.
5. Disconnect spring pins and turn hose trough bars out of the way to remove 4-inch (10.16-cm) bulk fuel hose from trough.

2-20. NONFILTERED FUEL SERVICING INVOLVING USE OF ENGINE AND PUMP (continued).

6. Remove dust cover (5) from outlet B (6) and connect 4-inch (10.16-cm) bulk fuel hose to outlet B (6) and storage facility.
7. Put valve E (2) in UNLOAD position.
8. Pull emergency valve A control handle (1) to OPEN position, and open valves B, F, and H (7, 10, and 11).
9. Adjust engine speed for desired flow rate (refer to Table 2-3).
10. Idle down engine at end of operation. Close all valves, and disconnect 4-inch (10.16-cm) bulk fuel hose. Drain hose into suitable container, and install dust cover (5) on outlet B (6).
11. Put bulk fuel hoses in hose trough and secure latches.
12. Stop engine (para 2-17c).
13. Drain accumulated water (para 2-19d).
14. Remove static reel grounding cable (4) from storage facility.
15. Store and cover fire extinguishers.



C. NONFILTERED DISPENSING

NOTE

Use this procedure for fuel that does not require filtering and is routed directly from pump to hose reels, bypassing filter/separator.

1. Review general fuel-handling instructions (para 2-16).

NOTE

Operation begins and ends with all valves closed.

2. Make sure all valves are closed.


NOTE

If two semi-trailers are being serviced, make sure they are both grounded to each other using separate static reel grounding cables.

3. Unreel static reel grounding cable (4), and connect it to a suitable ground.

2-20. NONFILTERED FUEL SERVICING INVOLVING USE OF ENGINE AND PUMP (continued).

4. Remove fire extinguishers and bring them to the point of operation.
5. Start engine (para 2-17b). When engine is warm, adjust engine speed to 1000-1200 rpm.
6. Put valve E (2) in UNLOAD position.
7. Pull emergency valve A control handle (1) to OPEN position, and open valves F, H, and K (10, 11, and 9).



8. Reset meter (12 or 14) to zero by pushing reset knob (13) and turning clockwise.

NOTE

Valves P and R may be opened at the same time if two vehicles are being serviced. Make sure both vehicles are grounded to each other and to earth ground.

9. Open valve P (19) if front hose (21) reel is being used, or open valve R (15) if rear hose (18) reel is being used.
10. Adjust engine throttle for desired flow rate (refer to Table 2-3).
11. Release lock (16) on hose (18 or 21) reel and unwind hose.
12. Insert fuel-dispensing nozzle (17 or 20) into vehicle fuel tank/container. Squeeze fuel-dispensing nozzle (17 or 20) trigger to start flow.
13. At end of operation, release trigger of fuel-dispensing nozzle (17 or 20) and remove nozzle from vehicle fuel tank/container.
14. Adjust engine speed to 1000-1200 rpm.
15. Rewind hose (18 or 21) and tighten lock(s) (16) on hose (18 or 21) reel.


**2-20. NONFILTERED FUEL SERVICING INVOLVING USE OF ENGINE AND PUMP
(continued).**

16. Close all valves.
17. Stop engine (para 2-17c).

WARNING

**DO NOT let go of static reel grounding cable when rewinding until ball stop is firmly touching reel.
Failure to follow this warning may cause injury to personnel.**

18. Disconnect and rewind static reel grounding cable (4).



19. Store and cover fire extinguishers.

2-21. FILTERED FUEL SERVICING OPERATIONS.

a. FILTERED BULK DELIVERY

NOTE


Use this procedure when filtered fuel is required in storage facility. Fuel is pumped from semi-trailer tank through filter/separator to storage facility.

1. Review general fuel-handling instructions (para 2-16).

NOTE


Operation begins and ends with all valves closed.

2. Make sure all valves are closed.
3. Connect static reel grounding cable (1) to ground rod (3). Remove 4-inch (10.1 6-cm) bulk delivery hose (6) from hose trough and connect it to receiving facility. Remove dust cover (7) from outlet B (5) and connect bulk delivery hose (6) to outlet B (5).
4. Remove fire extinguishers (2) and bring them to point of operation.
5. Start engine (para 2-17b) and, when warm, adjust engine speed to 1000-1200 rpm.
6. Set valve E (4) to UNLOAD position.



**2-21. FILTERED FUEL SERVICING OPERATIONS
(continued).**

- 7. Pull emergency valve A control handle (8) to OPEN position, and open valves B, H, M, and K (10, 11, 12, and 9).
- 8. Adjust engine throttle for desired flow rate (refer to Table 2-3).
- 9. At end of operation, adjust engine speed to 1000-1200 rpm.
- 10. Close all valves. Drain bulk delivery hose (6) into suitable container.
- 11. Remove bulk delivery hose (6) from outlet B (5) and receiving facility and store in hose troughs. Secure hose trough latches (11). Install dust cover (7) on outlet B (5).



2-21. FILTERED FUEL SERVICING OPERATIONS (continued).

12. Shut off engine (para 2-17c).

WARNING

DO NOT let go of static reel grounding cable when rewinding until ball stop is firmly touching reel. Failure to follow this warning may cause injury to personnel.

13. Remove static reel grounding cable (1) from ground rod (3) or suitable ground.

14. Cover and store fire extinguishers (2).

b. FILTERED FUEL DISPENSING

NOTE


Use this procedure to dispense metered fuel from semi-trailer tank to vehicle. Fuel is pumped through filter/seperator, meter, and hose reel to vehicle.

1. Review general fuel-handling instructions (para 2-16).

NOTE

Operation begins and ends with all valves closed.

2. Make sure all valves are closed.
3. Connect static reel grounding wire (16) to vehicle.
4. Remove fire extinguishers (2) and bring them to point of operation.
5. Start engine (para 2-17b) and, when warm, adjust engine speed to 1000-1200 rpm.
6. Set valve E (4) to UNLOAD position.
7. Pull emergency valve A control handle (8) to OPEN position and open valves H and M (11 and 12) and either P (20) or R (15), depending on which hose reel is to be used. If both hose reels are to be used, open both valve P (20) and valve R (15).
8. Reset meter(s) (13) to zero by pushing in meter reset knob(s) (14) and turning clockwise.
9. Adjust engine throttle for desired flow rate (refer to Table 2-3).
10. Release hose reel lock (17) on hose reel (19 or 22) to be used. Unwind hose (19 or 22).
11. Insert nozzle (18 or 21) into vehicle being serviced, and squeeze nozzle trigger to start flow.



2-21. FILTERED FUEL SERVICING OPERATIONS (continued).

- 12. Release nozzle trigger at end of operation and remove nozzle (18 or 21) from vehicle.
- 13. Adjust engine speed to 1000-1200 rpm.
- 14. Rewind hose reel (19 or 22). Do not rewind both hose reels at the same time. Tighten hose reel lock (17). Drain hose into suitable container.
- 15. Close all valves.
- 16. Shut off engine (para 2-17c).

WARNING

DO NOT let go of static reel grounding cable when rewinding until ball stop is firmly touching reel. Failure to follow this warning may cause injury to personnel.


- 17. Disconnect static reel grounding wire (16) from vehicle. Rewind static reel grounding wire (16).
- 18. Cover and store fire extinguishers (2). Close hose reel cabinet doors.

C. FUEL SAMPLING

Fuel sampling is done during filtered fuel dispensing operation. Fuel is removed through an Aqua-Glo probe and adapter installed on outlet nipple of one or both meters.

NOTE

Additional information on fuel sampling may be obtained from FM 10-68.



2-22. REFUEL ON THE MOVE (ROM) ASSEMBLY AND OPERATING PROCEDURES.

WARNING

Fuel handlers must wear appropriate safety equipment during fueling operations, to avoid injury.

NOTE

Components of the Refuel on the Move (ROM) Assembly (NSN 4730-01-295-1842) are listed in Appendix C.

The M969A2 semi-trailers have ROM capabilities. Refer to FM 10-71 for instructions on installing, operating, and disassembling the ROM kit.

Section IV. OPERATION UNDER UNUSUAL CONDITIONS

| Paragraph Number | Paragraph Title | Page Number |
|-------------------------|---|--------------------|
| 2-23 | General | 2-61 |
| 2-24 | Operation in Extreme Cold | 2-61 |
| 2-25 | Operation in Extreme Heat | 2-62 |
| 2-26 | Operation in High Humidity and Saltwater Areas..... | 2-62 |
| 2-27 | Operation in Mud and Snow..... | 2-63 |
| 2-28 | Operation in Dusty or Sandy Areas..... | 2-63 |
| 2-29 | Fording | 2-63 |

2-23. GENERAL.

- a. This section contains instructions for safely operating the M969A2 semi-trailers under unusual conditions. In addition to normal preventive maintenance service, special care must be taken to keep the M969A2 semi-trailers operational in extreme temperatures and humidity.
- b. For information on driver selection, training, and supervision, refer to FM 55-30.
- c. For information on special driving instructions for operating wheeled vehicles under unusual conditions, refer to FM 21-305.

2-24. OPERATION IN EXTREME COLD.

WARNING

Sudden changes in temperature may cause M969A2 semi-trailers to develop leaks at the fittings and connectors. Use caution and pay special attention to these areas. If something is broken or worn out, report it to Unit maintenance. Corrective action must be performed before resuming any operations. Failure to follow this warning may result in injury to personnel.

- a. Special care must be taken when operating M969A2 semi-trailers in extreme cold weather. Refer to FM 9-207 for information on operation in cold weather.
- b. In addition to performing all normal PMCS, special care must be taken in regard to cleaning and lubrication when extremes in temperature, humidity, and terrain conditions are present or anticipated. Proper cleaning, lubrication, storage, and handling ensures proper operation and function and also guards against excessive wear. Refer to Appendix E for proper lubrication during extreme cold weather.
- c. Generally, extreme cold causes lubricants to thicken or freeze and various semi-trailer construction materials to become hard and brittle, and easily damaged or broken. The operator must be alert to effects of extreme cold on semi-trailers.
- d. Care must be taken when handling cables. Extreme cold weather can cause insulation material on electrical wire to crack, causing short circuits. Construction material may become hard, brittle, and easily broken or damaged.

**2-24. OPERATION IN EXTREME COLD
(continued).**

- e. When parking for any period of time in temperatures below 0F (-180C), park in a sheltered area out of the wind and clean off any buildup of ice or snow. Place a footing of planks or brush under tires to prevent them from freezing to the ground. Make sure tires are properly inflated (para 1-10). Under-inflated tires will freeze, resulting in flat spots.
- f. Use caution when placing semi-trailer in motion after a shutdown. Thickened lubricants may cause component failure. Free frozen brakeshoes, or tires frozen to ground, with care.

2-25. OPERATION IN EXTREME HEAT.

- a. Refer to Appendix E for proper lubrication during high heat conditions.
- b. Do not park semi-trailer in sunlight for long periods of time. Heat and sunlight shorten tire life.

CAUTION

DO NOT use gasoline or drycleaning solvent to remove oil or grease spots from tarpaulin. Use only water and a scrubbing brush. Failure to follow this caution will damage the tarpaulin.

- c. Cover inactive semi-trailers with tarpaulins if no other shelter is available. Tarpaulins are subject to deterioration from mildew and attacks by insects or animals. Shake out and air tarpaulins weekly for several hours. Clean mildewed tarpaulins with a dry scrubbing brush. DO NOT clean with water until mildew is removed. If mildew is found, examine tarpaulin to determine if it is rotted or weakened. Replace tarpaulin if damaged. If tarpaulin is not damaged, treat as outlined in FM 10-16.
- d. Semi-trailers inactive for long periods in hot, humid weather are subject to rusting and the accumulation of fungi growth. Frequently inspect, clean, and lubricate to prevent deterioration.

2-26. OPERATION IN HIGH HUMIDITY AND SALTWATER AREAS.

- a. Dampness increases chances of corrosion. Inspect all surfaces and electrical connections for signs of corrosion. Remove all signs of corrosion. Apply silicone compound (Item 2, Appendix D) to all electrical connections.
- b. Protect semi-trailer from direct rainfall whenever possible.
- c. Keep moisture from entering the fuel supply. Drain the filter separator sump (para 3-10) before each operation, to remove accumulated moisture.
- d. Clean, inspect, and lubricate the semi-trailer frequently when operating in saltwater areas (refer to Appendix E).

2-27. OPERATION IN MUD AND SNOW.

- a. Immediately after operation in mud or snow, thoroughly clean, inspect, and lubricate if tactical situation permits (refer to Appendix E).
 - b. Refer to FM 21-305 for special instructions on driving hazards in snow.
 - c. After each operation, remove ice and snow from underneath semi-trailer and from hoses, lines, tubes, and electrical connections.
-

2-28. OPERATION IN DUSTY OR SANDY AREAS.

- a. Clean, inspect, and lubricate semi-trailer frequently when operating in dusty or sandy areas (refer to Appendix E).
 - b. Maintain proper tire pressure:
 - 1. Reduce tire pressure to 32 psi (221 kPa) for operation in soft sand.
 - 2. Reduce tire pressure to 45 psi (310.3 kPa) for operation on cross-country terrain. Tire pressure must be returned to 65 psi (448.2 kPa) when operation resumes on hard-surface roads if tactical situation permits.
 - c. When uncoupling semi-trailer in sandy areas, use ground boards to prevent landing gear from sinking.
-

2-29. FORDING.

- a. The M969A2 semi-trailer is designed for fording hard bottom water crossings deep enough to submerge the running gear.
- b. Refer to the towing vehicle operating instructions for information on fording. Towing vehicle instructions are also applicable to the semi-trailer.
- c. Before entering water, spray engine assembly electrical connections with silicone compound (Item 2, Appendix D). Notify Unit maintenance to pack wheel bearings after each submersion (refer to Appendix E).
- d. Reduce tire pressure to aid in amphibious landings.

2-63(2-64 blank)

CHAPTER 3

MAINTENANCE INSTRUCTIONS

Section I. LUBRICATION INSTRUCTIONS

3-1. LUBRICATION INSTRUCTIONS.

Lubrication instructions are in Appendix E of this manual. All lubrication instructions are mandatory.

Section II. OPERATOR/CREW TROUBLESHOOTING PROCEDURES

| Paragraph Number | Paragraph Title | Page Number |
|-------------------------|--------------------------------------|--------------------|
| 3-2 | General | 3-2 |
| 3-3 | Quick Guide to Troubleshooting | 3-3 |
| 3-4 | Troubleshooting Chart..... | 3-4 |

3-2. GENERAL.

- a. This section provides information for identifying and correcting malfunctions that may develop while operating your semi-trailer.
- b. The Quick Guide to Troubleshooting (para 3-3) lists common symptoms you may find during operation or maintenance of your semi-trailer or its components, and refers you to the Troubleshooting Chart (para 3-4) for the appropriate troubleshooting procedures. You should perform the tests/inspections and corrective actions in the order listed.
- c. If you are unsure of the location of an item mentioned in troubleshooting, refer to paragraph 1-9 or to the maintenance task where the item is serviced.
- d. Before performing troubleshooting, read and follow all safety instructions found in the warning summary at the beginning of this manual.
- e. This section cannot list all malfunctions that may occur, nor all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by the corrective actions listed, notify your supervisor or Unit maintenance.
- f. When troubleshooting a malfunction:
 - Locate the symptom(s) in the Quick Guide to Troubleshooting (para 3-3) that best describes the symptom(s).
 - Turn to the page in the Troubleshooting Chart (para 3-4) where the troubleshooting procedures for the symptom(s) in question are described.
 - Perform each step in the order listed until the malfunction is corrected. DO NOT perform any maintenance task unless the troubleshooting procedure tells you to do so.

3-3. QUICK GUIDE TO TROUBLESHOOTING.

| <u>ITEM</u> | <u>SYMPTOM</u> | <u>PARAGRAPH</u> |
|---------------------------|---|------------------|
| ENGINE | ENGINE WILL NOT TURN OVER. | para 3-4a(1) |
| | ENGINE IS HARD TO START OR TURNS OVER SLOWLY. | para 3-4a(2) |
| | ENGINE TURNS OVER BUT FAILS TO START. | para 3-4a(3) |
| | ENGINE MISFIRES AT HEAVY LOAD OR ENGINE POWER IS LOW. | para 3-4a(4) |
| | LOW OIL PRESSURE IS INDICATED ON GAGE (minimum 20 psi [138 kPa]). | para 3-4a(5) |
| ELECTRICAL SYSTEM | LIGHTS ON TRAILER WILL NOT OPERATE. | para 3-4b(1) |
| | ONE OR MORE LIGHTS (BUT NOT ALL) WILL NOT OPERATE, OR LIGHTS ARE DIM OR FLICKERING. | para 3-4b(2) |
| | CONTROL PANEL SECURE LIGHTING DOES NOT OPERATE. | para 3-4b(3) |
| BRAKE SYSTEM | BRAKES WILL NOT RELEASE. | para 3-4c(1) |
| | NO BRAKES OR BRAKES ARE WEAK. | para 3-4c(2) |
| | BRAKE APPLICATION OR RELEASE IS SLOW. | para 3-4c(3) |
| | BRAKES GRAB. | para 3-4c(4) |
| FUELING OPERATIONS | FUEL DOES NOT FLOW DURING ANY NONFILTERED FUELING OPERATION. | para 3-4d(1) |
| | FUEL DOES NOT FLOW DURING ANY FILTERED FUELING OPERATION. | para 3-4d(2) |
| | FUEL DOES NOT FLOW DURING ANY OVERWING FUELING OPERATION. | para 3-4d(3) |
| TIRES | TIRES ARE EXCESSIVELY WORN, SCUFFED, OR CUPPED. | para 3-4e(1) |
| LANDING GEAR | CRANK IS DIFFICULT TO OPERATE. | para 3-4f(1) |


3-4. TROUBLESHOOTING CHART.

a. ENGINE

(1) ENGINE WILL NOT TURN OVER.

A. 1. Set engine switch on engine control panel to RUN.
 2. Check for discharged or defective battery.
 3. Set engine switch to STOP.

Does battery voltage indicator read 12-14 V dc?



Notify Unit maintenance that additional troubleshooting is required.



B. 1. Remove battery cover Para 3-6
 2. Check for loose or corroded battery cable connections Para 3-6
 3. Clean connections
 4. Remove vent fill caps and check for loss of electrolyte (Para 3-6) If low, notify Unit maintenance.

WARNING

Do not attempt to jump-start engine. Jump-starting may result in damage to batteries or serious fire hazard. Failure to heed this warning may result in severe injury or death to personnel.

5. Notify Unit maintenance if battery is discharged.

END OF TASK




3-4. TROUBLESHOOTING CHART (continued).

- a. ENGINE (continued)
- (2) ENGINE IS HARD TO START OR TURNS OVER SLOWLY.

A. 1. Set engine switch on engine control panel to RUN.
2. Check for discharged or defective battery.
3. Set engine switch to STOP.

Does battery voltage indicator read 12-14 V dc?



B. 1. Remove battery cover (para 3-6)..
2. Check for loose or corroded battery cable connections
3. Clean connections (para 3-6.
4. Remove vent fill caps and check for loss of electrolyte (para 3-6. If low, notify Unit maintenance.



WARNING

Do not attempt to jump-start engine. Jump-starting may result in damage to batteries or serious fire hazard. Failure to heed this warning may result in severe injury or death to personnel.

5. Notify Unit maintenance if battery is discharged or engine does not operate.

C. Check air cleaner restriction indicator for red band.


Is red band showing?



continued on next page

3-4. TROUBLESHOOTING CHART (continued).

- a. ENGINE (continued)
- (2) ENGINE IS HARD TO START OR TURNS OVER SLOWLY (CONTINUED).




3-4. TROUBLESHOOTING CHART (continued).

a. ENGINE (continued)

(3) ENGINE TURNS OVER BUT FAILS TO START.

A. 1. Remove fuel cap from engine fuel tank.
 2. Check fuel level in engine fuel tank.

Is fuel level low?




Add fuel as required. Verify problem is solved.

B. **NOTE**

Engine switch energizes and de-energizes fuel stop solenoid, causing solenoid piston to move up and down.

1. Check position of fuel stop solenoid piston.
2. Set engine switch to RUN.
3. Check position of fuel stop solenoid piston.
4. Set engine switch to STOP.

Does fuel stop solenoid piston move up and down?






NOTE

If engine is overheated, high-temperature switch contacts open and de-energize fuel stop solenoid, stopping the engine.

Cool engine for 3 to 5 minutes before attempting to start engine again. Verify problem is solved.

Notify Unit maintenance that additional troubleshooting is required.


END OF TASK




3-4. TROUBLESHOOTING CHART (continued).

a. ENGINE (continued)

(4) ENGINE MISFIRES AT HEAVY LOAD OR ENGINE POWER IS LOW.





END OF TASK



3-4. TROUBLESHOOTING CHART (continued).

a. ENGINE (continued)

(5) LOW OIL PRESSURE IS INDICATED ON GAGE (minimum 20 psi [138 kPa]).



END OF TASK



3-4. TROUBLESHOOTING CHART (continued).

b. ELECTRICAL SYSTEM

(1) LIGHTS ON TRAILER WILL NOT OPERATE.

NOTE

Prime mover must be coupled to semitrailer prior to performing this procedure (para 2-12).



END OF TASK



3-4. TROUBLESHOOTING CHART (continued).

b. ELECTRICAL SYSTEM (continued)

(2) ONE OR MORE LIGHTS (BUT NOT ALL) WILL NOT OPERATE, OR LIGHTS ARE DIM OR FLICKERING.

NOTE

Prime mover must be coupled to semitrailer prior to performing this procedure (para 2-12).



INTERVEHICULAR CABLE

INTERVEHICULAR CABLE RECEPTACLE

END OF TASK

3-4. TROUBLESHOOTING CHART (continued).

b. ELECTRICAL SYSTEM (continued)

(3) CONTROL PANEL SECURE LIGHTING DOES NOT OPERATE.

Notify Unit maintenance.

3-4. TROUBLESHOOTING CHART (continued).

c. BRAKE SYSTEM

(1) BRAKES WILL NOT RELEASE.

NOTE

Prime mover must be coupled to semitrailer prior to performing this procedure (para 2-12).

A. 1. Set parking brakes of prime mover.
 2. Apply service brake.
 3. Check emergency supply brake valve on prime mover.

Is emergency supply brake valve applied?

no

yes

Move emergency supply brake valve to released position. Verify problem is solved.

NOTE

Some prime movers may not be equipped with shut-off valves.

B. Check shut-off valves on prime mover.

Are shut-off valves closed?



no

yes

Open shut-off valves. Verify problem is solved.

C. Check components of airbrake system for damage or leaks.

Are any components of airbrake system leaking or damaged?



continued on next page



COMPONENTS OF AIRBRAKE SYSTEM

3-4. TROUBLESHOOTING CHART (continued).

c. BRAKE SYSTEM (continued)

(1) BRAKES WILL NOT RELEASE (continued).

CONTINUED FROM C



END OF TASK

3-4. TROUBLESHOOTING CHART (continued).

c. BRAKE SYSTEM (continued)

(2) NO BRAKES OR BRAKES ARE WEAK.

NOTE

- Prime mover must be coupled to semitrailer prior to performing this procedure (para 2-12).
- Some prime movers are not equipped with shut-off valves.

A. 1. Set parking brakes of prime mover.
 2. Apply service brake.
 3. Check position of shut-off valves on prime mover.


Are shut-off valves open?



Open shut-off valves. Verify problem is solved.

B. Check components of airbrake system for leaks or damage.



Are any components of airbrake system leaking or damaged?



Notify Unit maintenance to replace or repair damaged components of airbrake system. Verify problem is solved.

Notify Unit maintenance that additional troubleshooting is required.

END OF TASK



COMPONENTS OF AIRBRAKE SYSTEM


3-4. TROUBLESHOOTING CHART (continued).

c. BRAKE SYSTEM (continued)


(3) BRAKE APPLICATION OR RELEASE IS SLOW.

NOTE

Prime mover must be coupled to semitrailer prior to performing this procedure (para 2-12).



END OF TASK



COMPONENTS OF AIRBRAKE SYSTEM



3-4. TROUBLESHOOTING CHART (continued).

c. BRAKE SYSTEM (continued)

(4) BRAKES GRAB.

NOTE

Prime mover must be coupled to semitrailer prior to performing this procedure (para 2-12).






END OF TASK

3-4. TROUBLESHOOTING CHART (continued).

d. FUELING OPERATIONS

(1) FUEL DOES NOT FLOW DURING ANY NONFILTERED FUELING OPERATION.




FUEL-DISPENSING NOZZLE

END OF TASK



3-4. TROUBLESHOOTING CHART (continued).

d. FUELING OPERATIONS (continued)

(2) FUEL DOES NOT FLOW DURING ANY FILTERED FUELING OPERATION.





continued on next page



3-4. TROUBLESHOOTING CHART (continued).

d. FUELING OPERATIONS (continued)

(2) FUEL DOES NOT FLOW DURING ANY FILTERED FUELING OPERATION (continued).




END OF TASK


3-4. TROUBLESHOOTING CHART (continued).

d. FUELING OPERATIONS (continued)

(3) FUEL DOES NOT FLOW DURING ANY OVERWING FUELING OPERATION.




END OF TASK



3-4. TROUBLESHOOTING CHART (continued).

e. TIRES

(1) TIRES ARE EXCESSIVELY WORN, SCUFFED, OR CUPPED.



END OF TASK


3-4. TROUBLESHOOTING CHART (continued).

f. LANDING GEAR


(1) CRANK IS DIFFICULT TO OPERATE.

NOTE

Prime mover must be coupled to semitrailer prior to performing this procedure (para 2-12).



END OF TASK



Section III. MAINTENANCE PROCEDURES

| Paragraph Number | Paragraph Title | Page Number |
|------------------|--|-------------|
| 3-5 | General..... | 3-24 |
| 3-6 | Batteries, Terminals, and Cables Service | 3-24 |
| 3-7 | Air Reservoirs Maintenance | 3-26 |
| 3-8 | Storage Box Maintenance | 3-27 |
| 3-9 | Engine Air Cleaner Service | 3-28 |
| 3-10 | Filter/Separator Sump Maintenance..... | 3-30 |
| 3-11 | Fuel-Dispensing Nozzle Maintenance..... | 3-31 |

3-5. GENERAL.

This section provides maintenance instructions for those items that are the responsibility of the operator/crew. The maintenance functions are limited to those operations that are authorized by the Maintenance Allocation Chart (MAC), Appendix B of TM 9-2330-398-24.

3-6. BATTERIES, TERMINALS, AND CABLES SERVICE.

This Task covers:

Inspection and Service

Initial Setup:

Materials/Parts:

- Baking soda (Item 1, Appendix D)

Equipment Conditions:

- Semitrailer uncoupled from prime mover (para 2-14).

INSPECTION AND SERVICE


WARNING

Batteries produce explosive gases. Keep sparks, flames, and smoking material away. Ventilate when charging or using in an enclosed space. The batteries contain sulfuric acid that causes severe burns. If acid contacts eyes, skin, or clothing, flush well with water. For contact with eyes, get immediate medical attention. Do not jump-start engine. Batteries must be removed for recharging.


NOTE

Each time before vehicle is put into operation, battery terminals and cables should be inspected for excessive dirt and corrosion, loose connections, and damage. Dirt, combined with electrolyte or moisture on top of battery, can result in a continuous battery discharge.

3-6. BATTERIES, TERMINALS, AND CABLES SERVICE (continued).



- a. Remove four wingnuts (1) and washers (2) securing battery cover (3) to battery hold-down bracket (4). Remove battery cover (3) from hold-down bracket (4).
- b. Inspect battery area for excessive dirt and corrosion. Clean battery area with mixture of baking soda and water, then flush battery area with clean water.



- c. Check four cables (5) for frayed insulation. If insulation is worn or frayed, notify Unit maintenance.
- d. Check terminals (7) for looseness. If loose, notify Unit maintenance.
- e. Remove 12 vent fill caps (6) and check electrolyte level. Electrolyte level must be just below ring at bottom of each cell opening. If electrolyte level is low, notify Unit maintenance. Install 12 vent fill caps (6).
- f. Install battery cover (3) on hold-down bracket (4) with four wingnuts (1) and washers (2).

FOLLOW-ON MAINTENANCE:

- None

3-7. AIR RESERVOIRS MAINTENANCE.

This Task Covers:

Draining Water from Air Reservoir

Initial Setup:


Equipment Conditions:

- Semitrailer uncoupled from prime mover (para 2-14).
-

DRAINING WATER FROM AIR RESERVOIR**NOTE**

Perform this procedure daily.

1. Open drain valve (2) on each of two air reservoirs (1) and allow water to flow out.
2. Close drain valve (2) on each of two air reservoirs (1).

**FOLLOW-ON MAINTENANCE:**

- None

3-8. STORAGE BOX MAINTENANCE.

This Task Covers:

a. Cleaning

b. Inspection

Initial Setup:

Equipment Conditions:


- Semitrailer uncoupled from prime mover (para 2-14).
-

a. CLEANING

Periodically clean dirt and debris from storage box (2) and cover (1). Make sure all drain holes (3) are clear of debris or restrictions.

b. INSPECTION

Inspect storage box (2) and cover (1) for damage. Report any damage to Unit maintenance.



FOLLOW-ON MAINTENANCE:

- None

3-9. ENGINE AIR CLEANER SERVICE.*This Task Covers:*

- | | |
|-----------------|----------------------------|
| a. Removal | b. Cleaning and Inspection |
| c. Installation | |

*Initial Setup:***Materials/Parts:**

- Rag (Item 11, Appendix D)

Equipment Conditions:

- Semitrailer uncoupled from prime mover (para 2-14).

CAUTION

Do not run engine if red band is showing in restriction indicator. Damage to engine could result.

NOTE

Service air cleaner whenever restriction indicator (1) shows a red band.


a. REMOVAL

1. To service filter, loosen clamp (6) and remove filter end cap (4) from air cleaner body (9).

CAUTION

Never run engine with filter or dust collector removed. Dam, age to engine could result.

2. Unscrew wingnut (3) and washer (7) and remove filter element (8) from air cleaner body (9).
3. Remove baffle (5) from end cap (4), and remove any accumulated dirt.



3-9. ENGINE AIR CLEANER SERVICE (continued).

4. Remove rain cap (2) from air cleaner body (9).

b. CLEANING AND INSPECTION

1. Clean rain cap with clean rag.
2. Use a clean rag to wipe clean the interior of air cleaner and end cap.
3. Use a clean rag to wipe obstructions and dirt from filter element. After six cleanings or annually, have Unit maintenance obtain a replacement filter element.

c. INSTALLATION

1. Install baffle (5) in end cap (4).
2. Install new or cleaned filter element (8) in air cleaner body (9). Fasten in place with washer (7) and wingnut (3).
3. Install end cap (4) on air cleaner body (9). Make sure portion of end cap marked "TOP" is at top. Secure end cap (4) by tightening clamp (6).
4. Install rain cap (2) on air cleaner body (9).
5. Press button on air restriction indicator (1) to reset red band.

FOLLOW-ON MAINTENANCE:

- None

3-10. FILTER/SEPARATOR SUMP MAINTENANCE.

This Task covers:

Draining Sump

Initial Setup:


Equipment Conditions:

- Semitrailer uncoupled from prime mover (para 2-14).
-

DRAINING SUMP**NOTE**

Place drain pan under sump before, during, and after operation.

Place suitable container under valve N (2) of filter/separator sump (3). Open valve N (2) to drain water from filter/separator (1) after each period of operation (para 2-19d).

**FOLLOW-ON MAINTENANCE:**

- None

3-11. FUEL-DISPENSING NOZZLE MAINTENANCE.*This Task Covers:*

- | | |
|-----------------|------------|
| a. Removal | b. Service |
| c. Installation | |

*Initial Setup:***Materials/Parts:**

- Drycleaning solvent (Item 6, Appendix D)
- Rag (Item 15, Appendix D)

Equipment Conditions:

- All fuel-handling valves closed (para 2-16).

a. REMOVAL

1. Unscrew fuel-dispensing nozzle (2) from hose (1).
2. Using suitable container, drain fuel from nozzle (2) and hose (1).

NOTE

Cover end of hose with rag to keep out dirt and debris.

b. SERVICE**NOTE**

Screen in fuel-dispensing nozzle must be cleaned periodically and whenever flow through nozzle is restricted.

1. Unscrew spout (4) from nozzle (2).
2. Remove screen (3) from inside of spout (4).

WARNING

Drycleaning solvent P-D-680 is toxic and flammable. Always wear protective goggles and gloves, and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes, and DO NOT breathe vapors. DO NOT use near open flames or excessive heat.



3. Clean screen (3) with drycleaning solvent and rag. Use compressed air to dry screen and remove any excess material.
4. Install screen (3) in spout (4).
5. Install spout (4) on nozzle (2).

c. INSTALLATION

Install nozzle (2) on hose (1).

FOLLOW-ON MAINTENANCE:

- None



**APPENDIX A
REFERENCES**

| Paragraph Number | Paragraph Title | Page Number |
|-------------------------|--------------------------|--------------------|
| A-1 | Scope | A-1 |
| A-2 | Publications Index | A-1 |
| A-3 | Forms | A-1 |
| A-4 | Field Manuals | A-2 |
| A-5 | Technical Manuals | A-2 |
| A-6 | Bulletins | A-3 |
| A-7 | Other Publications | A-3 |

A-1. SCOPE.

This appendix lists all forms, manuals, bulletins, and other publications that are referenced in this manual and/or are applicable to material covered in this manual.

A-2. PUBLICATIONS INDEX.

DA Pam 25-30, Consolidated Index of Army Publications and Blank Forms, should be consulted frequently for the latest revisions and for new publications relating to material covered in this manual. Also consult DA Pam 350-9, Index and Description of Army Training Devices.

A-3. FORMS.

For instructions on the use of maintenance forms, refer to DA Pam 738-750, The Army Maintenance Management System (TAMMS).

| | |
|---|----------------|
| Recommended Changes to Publications and Blank Forms..... | DA Form 2028 |
| Recommended Changes to Equipment Technical Publications | DA Form 2028-2 |
| Organization Control Record for Equipment | DA Form 2401 |
| Equipment Inspection and Maintenance Worksheet..... | DA Form 2404 |
| Maintenance Request | DA Form 2407 |
| Equipment Log Assembly (Records)..... | DA Form 2408 |
| Preventive Maintenance Schedule and Record | DD Form 314 |
| Processing and Deprocessing Record for Shipment, Storage and Issue of Vehicles and Spare Engines | DD Form 1397 |
| Report of Discrepancy (ROD) | SF Form 364 |
| Product Quality Deficiency Report..... | SF Form 368 |

A-4. FIELD MANUALS.

| | |
|---|--------------|
| NBC Contamination Avoidance | FM 3-3 |
| NBC Protection..... | FM 3-4 |
| NBC Decontamination..... | FM 3-5 |
| Field Behavior of NBC Agents (Including Smoke and Incendiaries) | FM 3-6 |
| Route Reconnaissance and Classification | FM 5-36 |
| Ammunition Handbook..... | FM 9-13 |
| Operation and Maintenance of Ordnance Materiel in Cold Weather (0 Degrees F to Minus 65 Degrees F) | FM 9-207 |
| General Fabric Repair..... | FM 10-16 |
| Organizational Maintenance of Military Petroleum Pipelines, Tanks and Related Equipment | FM 10-20 |
| Aircraft Refueling..... | FM 10-68 |
| Petroleum Supply Point Equipment and Operations | FM 10-69 |
| Petroleum Tank Vehicle Operations | FM 10-71 |
| Camouflage..... | FM 20-3 |
| Vehicle Recovery Operations..... | FM 20-22 |
| First Aid for Soldiers..... | FM 21-11 |
| Manual for the Wheeled Vehicle Driver..... | FM 21-305 |
| Battle Focused Training | FM 25-101 |
| Basic Cold Weather Manual..... | FM 31-70 |
| Northern Operations..... | FM 31-71 |
| Railway Operating and Safety Rules..... | FM 55-21 |
| Army Motor Transport Units and Operations..... | FM 55-30 |
| Desert Operations (How to Fight)..... | FM 90-3(HTF) |
| Mountain Operations | FM 90-6 |
| Operational Terms and Symbols..... | FM 101-5-1 |

A-5. TECHNICAL MANUALS.

| | |
|--|---------------------|
| Operator and Organizational Maintenance Manual (Including Repair Parts and Special Tools List) for Nozzle Assembly, Closed Circuit Refueling W/Strainer Assembly | TM 5-4930-226-12&P |
| Inspection, Care and Maintenance of Antifriction Bearings..... | TM 9-214 |
| Deepwater Fording of Ordnance Materiel | TM 9-238 |
| Materials Used for Cleaning, Preserving, Abrading and Cementing Ordnance Materiel and Related Materials Including Chemicals..... | TM 9-247 |
| Hand Receipt: Semitrailer, Tank, 5000-Gallon, M969A2 | TM 9-2330-398-10-HR |
| Unit, Direct Support, and General Support Maintenance Manual for Semitrailer, Tank, 5000-Gallon, Fuel Dispensing, Automotive, M969A2..... | TM 9-2330-398-24 |
| Unit, Direct Support, and General Support Maintenance Repair Parts and Special Tools List for Semitrailer, Tank, 5000-Gallon, M969A2 (NSN 2330-01-155-0048)..... | TM 9-2330-398-24P |
| Operator's, Unit, Direct Support and General Support Maintenance Manual for Care, Maintenance Repair and Inspection of Pneumatic Tires and Inner Tubes..... | TM 9-2610-200-14 |
| Operator's, Unit, Intermediate Direct Support and Intermediate General Support Maintenance Manual for Lead-Acid Storage Batteries | TM 9-6140-200-14 |
| Painting Instructions for Army Materiel..... | TM 43-0139 |
| Railcar Loading Procedures | TM 55-601 |
| Storage and Materials Handling..... | TM 743-200-1 |
| Procedures for Destruction of Tank-Automotive Equipment to Prevent Enemy Use..... | TM 750-244-6 |
| Direct Support and General Support for Quality Control Inspector's Inspection Criteria | TM 750-245-4 |

A-6. BULLETINS.

Storage Serviceability Standard: Tracked Vehicles, Wheeled Vehicles,
and Component Parts SB 740-98-1

Occupational and Environmental Health: Sanitary Control and Surveillance of
Field Water Supplies..... TB MED 577

Description, Use, Bonding Techniques and Properties of Adhesives TB ORD 1032

Hand Portable Fire Extinguishers Approved for Army Users TB 5-4200-200-10

Tactical Wheeled Vehicles: Repair of Frames TB 9-2300-247-40

Equipment Improvement Report and Maintenance Digest (U.S. Army
Tank-automotive and Armaments Command) TB 43-0001-39 Series

Maintenance Expenditure Limits for Tactical Wheeled Vehicles.
FSC Group 23, FSC Classes 2320 and 2330..... TB 43-0002-81

Color, Marking, and Camouflage Painting of Military Vehicles, Construction
Equipment and Materials Handling Equipment..... TB 43-0209

Purging, Cleaning and Coating Interior Ferrous and Terne Sheet
Vehicle Fuel Tanks TB 43-0212

Corrosion Prevention and Control Including Rustproofing Procedures for
Tactical Vehicles and Trailers..... TB 43-0213

Maintenance in the Desert TB 43-0239

A-7. OTHER PUBLICATIONS.

Army Logistics Readiness and Sustainability AR 700-138

Army Medical Department Expendable/Durable Items CTA 8-100

Expendable/Durable Items (Except Medical, Class V, Repair Parts
and Heraldic Items)..... CTA 50-970

**APPENDIX B
COMPONENTS OF END ITEM AND BASIC ISSUE ITEMS LISTS**

Section I. INTRODUCTION

| Paragraph Number | Paragraph Title | Page Number |
|------------------|--|-------------|
| B-1 | Scope | B-1 |
| B-2 | General..... | B-1 |
| B-3 | Explanation of Columns in Sections II and III..... | B-1 |

B-1. SCOPE.

This appendix lists components of the end item and basic issue items for the M969A2 semitrailer, to help you inventory items required for safe and efficient operation.

B-2. GENERAL.

The components of end item and basic issue items lists are divided into the following sections:


- a. Section II. Components of End Item (COEI). This listing is for informational purposes only, and is not authority to requisition replacements. These items are part of the end item, but are removed and packaged separately for transportation or shipment. As part of the end item, these items must be with the end item whenever it is issued or transferred between property accounts. Illustrations are furnished to assist you in identifying the items.
- b. Section III. Basic Issue Items (BII). This list contains the minimum essential items required to place the semitrailer in operation, to operate it, and to perform emergency repairs. Although shipped separately, packaged BII must be with the semitrailer during operation and whenever it is transferred between property accounts. This manual is your authority to request/requisition replacement BII, based on TOE/MTOE authorizations of the end item.

B-3. EXPLANATION OF COLUMNS IN SECTIONS II AND III.

The following provides an explanation of columns found in the tabular listings in Sections II and III:


- a. Column (1), Illus. Number [Illustration Number], gives you the illustration number of the item.
- b. Column (2), National Stock Number, identifies the national stock number assigned to the item; this number is used for requisitioning purposes.
- c. Column (3), Description, CAGEC and Part Number, identifies the Federal item name (in capital letters) and, if required, gives a brief description to identify and locate the item. The last line below the description is the Commercial and Government Entity Code (CAGEC) (in parentheses), followed by the part number.
- d. Column (4), U/M [Unit of Measure], indicates how the item is issued for the national stock number shown in column 2. This measure is expressed by a two-character alphabetical abbreviation: EA for "each."
- e. Column (5), Qty. Rqr. [Quantity Required], indicates the quantity of the item authorized to be used with or on the equipment.

Section II. COMPONENTS OF END ITEM (COEI)




| (1) ILLUS NUMBER | (2) NATIONAL STOCK NUMBER | (3) DESCRIPTION, CAGEC and Part Number | Usable On Code | (4) U/M | (5) QTY Reqd |
|------------------------|------------------------------------|---|-------------------|------------|--------------------|
| 1 | 2510-00-741-7585 | BOARD, GROUND (stowed at landing legs) (19207) 7417585 | | EA | 2 |
| 2 | 2610-00-029-0563 | TUBE, INNER, PNEUMATIC (stowed on rear bracket) | | EA | 1 |
| 3 | 2610-00-373-7294 | TIRE, SPARE, RADIAL (stowed on rear bracket) | | EA | 1 |
| 4 | 2640-00-555-2924 | FLAP, INNER TUBE (stowed on rear bracket) | | EA | 1 |


Section III. BASIC ISSUE ITEMS (BII)




| (1) ILLUS NUMBER | (2) NATIONAL STOCK NUMBER | (3) DESCRIPTION, CAGEC and Part Number | (4) Usable On Code U/M | (5) QTY Reqd |
|------------------------|------------------------------------|--|---------------------------------|--------------------|
| 1 | 5140-00-772-4142 | BAG, TOOL (stowed in tool box) (19207) 7724142 | EA | 2 |
| 2 | 5340-01-290-2727 | COVER, ACCESS (on fire extinguishers) (19207) 11668081 | EA | 2 |
| 3 | 4210-00-808-4544 | EXTINGUISHER, FIRE (stowed on rear and side bracket) (3670) IK10E | EA | 2 |
| 4 | 5210-01-054-9934 | GAGE, STICK (stowed on stowage tube) (19207)11685988 | EA | 1 |
| 5 | 4720-01-058-6032 | HOSE ASSEMBLY, 1-1/4 IN. x 50 FT (19207)11685953 | EA | 2 |



| (1) ILLUS NUMBER | (2) NATIONAL STOCK NUMBER | (3) DESCRIPTION, CAGEC and Part Number | Usable On Code | (4) U/M | (5) QTY Reqd |
|------------------------|------------------------------------|---|-------------------|------------|--------------------|
| 6 | 4730-00-640-6188 | PLUG, QUICK-DISCONNECT (96906) MS27029-17 | | EA | 4 |
| 7 | 5330-00-899-4509 | GASKET (96906) MS27030-9 | | EA | 6 |
| 8 | 4720-01-096-4390 | HOSE, TRANSFER (stowed in hose trough) (19207)11685834 | | EA | 1 |
| 9 | 4730-00-640-6156 | CAP, QUICK-DISCONNECT (96906) MS27028-17 | | EA | 2 |
| 10 | 4720-01-087-5876 | HOSE, TRANSFER (stowed in hose trough) (19207)11685835 | | EA | 2 |



| (1) ILLUS NUMBER | (2) NATIONAL STOCK NUMBER | (3) DESCRIPTION, CAGEC and Part Number | (4) U/M | (5) QTY Reqd |
|------------------------|------------------------------------|--|------------|--------------------|
| 11 | 4930-01-377-3136 | NOZZLE ASSEMBLY (stowed in tool box) (19207) 12275441-3 | EA | 2 |
| 12 | 4730-00-2687479 | BUSHING, PIPE SHOULDER (stowed in tool box) (96906) MS14315-23 | EA | 2 |
| 13 | 5340-01-170-4999 | DUST CAP (stowed in tool box) (19207) 12275443 | EA | 2 |
| 14 | 4730-01-170-4973 | STRAINER (stowed in tool box) (19207) 12275444 | EA | 2 |
| 15 | 5340-00-912-4086 | PADLOCK SET, W/CLEVIS AND CHAIN, COMPOSED OF 2 PADLOCKS AND 2 KEYS (96906) MS21313-160 | EA | 1 |
| 16 | 4730-00-951-3293 | REDUCER, QUICK-DISCONNECT (stowed in tool box) (96906) MS49000-1 | EA | 1 |
| 17 | 531000-612-2414 | GASKET, REDUCER (stowed in tool box) (96906) MS27030-6 | EA | 1 |
| 18 | 4730-00-951-3295 | REDUCER, QUICK-DISCONNECT (stowed in tool box) (96906) MS49000-5 | EA | 1 |
| 19 | 5330-00-8994509 | GASKET, REDUCER (stowed in tool box) (96906) MS27030-9 | EA | 1 |



| (1) ILLUS NUMBER | (2) NATIONAL STOCK NUMBER | (3) DESCRIPTION, CAGEC and Part Number | (4) Usable On Code U/M | (5) QTY Reqd |
|------------------------|------------------------------------|--|---------------------------------|--------------------|
| 20 | 5975-01-050-5707 | ROD, GROUND (stowed in stowage tube) (97403) 13219E0462 | EA | 1 |
| 21 | 5120-00-234-8913 | SCREWDRIVER, CROSS TIP (19207) 11655777-12 | EA | 1 |
| 22 | 5120-00-222-8852 | SCREWDRIVER, FLAT TIP (96906) MS15219-1 | EA | 1 |
| 23 | 5120-00-240-5328 | WRENCH, ADJUSTABLE (96906) MS15461-3 | EA | 1 |
| 24 | 5120-00-148-7917 | WRENCH SET, COMBINATION (81348) GGG-W-636 | EA | 1 |

APPENDIX C
ADDITIONAL AUTHORIZATION LIST

Section I. INTRODUCTION

| Paragraph Number | Paragraph Title | Page Number |
|------------------|------------------------------|-------------|
| C-1 | Scope | C-1 |
| C-2 | Explanation of Listing | C-1 |

C-1. SCOPE.

- a. This appendix lists additional items you are authorized for support of the M969A2 semitrailer.
- b. The list in Section II identifies items that do not have to accompany the semitrailer and do not have to be turned in with it. These items are all authorized to you by CTA, MTOE, TDA, or JTA.

C-2. EXPLANATION OF LISTING.

The national stock number, description, Commercial and Government Entity Code (CAGEC) (in parentheses), part number, unit of measure (U/M), and quantity recommended (Qty. Recm.) are provided for each item to help you identify and request the additional items you require to support this equipment. The items are listed in alphabetical sequence by item name.

Section II. ADDITIONAL AUTHORIZATION LIST (AAL)

| (2) National Stock Number | (3) Description CAGEC and Part Number | (4) U/M | (5) Qty. Recm. |
|---------------------------------|---|------------|----------------------|
| 4930-00-516-0839 | ADAPTER ASSEMBLY, GRAVITY FILL (96124) 780000-5 | EA | 1 |
| 2590-00-473-6331 | BRACKET, VEHICULAR (19207) 6566675 | EA | 1 |
| 7240-00-377-5269 | CAN, GASOLINE (81349) MIL-C-53109 | EA | 1 |
| 4720-01-065-9388 | COUPLING, FUEL SAMPLING (19207)11668858 | EA | 1 |
| 4730-01-088-8675 | COUPLING HALF, QUICK-DISCONNECT (16069) F4333 | EA | 1 |
| 4930-00-360-0710 | COUPLING HALF, QUICK-DISCONNECT, 1 1/2-IN. FUEL HOSE, 1-IN. MALE - 1-IN. FEMALE (81718) 633B1INAL | EA | 1 |
| 4930-00-117-4726 | NOZZLE ASSEMBLY, CLOSED-CIRCUIT REFUELING, W/STRAINER (79326) CCN101/14 | EA | 1 |
| 4930-01-068-5100 | NOZZLE, UNLEADED FUEL (33456) OPW11AP | EA | 1 |
| 4730-00-889-2382 | REDUCER, QUICK-DISCONNECT, 1-IN. MALE - 1 1/2-IN. FEMALE (96906) MS49000-7 | EA | 1 |
| 4730-01-295-1842 | REFUEL ON THE MOVE (ROM) ASSEMBLY (19207)12356117 Consisting of: | EA | 1 |
| 4730-00-936-4584 | CAP, 1.50 IN. (3.81 cm) (96906) MS27028-10 | EA | 8 |
| 4730-00-929-0787 | CAP, 3.00 IN. (7.62 cm) (96906) MS27028-15 | EA | 15 |
| 4730-00-640-6156 | CAP, 4.00 IN. (10.16 cm) (96906) MS27028-117 | EA | 3 |
| 4730-00-203-1010 | COUPLING, 1.5 F to 1-1/2 NPT (96906) MS27026-9 | EA | 8 |
| 4210-00-257-5343 | FIRE EXTINGUISHER (03670) K20E | EA | 8 |

Section II. ADDITIONAL AUTHORIZATION LIST (AAL) (continued)

| (2) National Stock Number | (3) Description CAGEC and Part Number | (4) U/M | (5) Qty. Recm. |
|---------------------------------|--|------------|----------------------|
| 5330-00-360-0595 | GASKET, 1.50 IN. (3.81 cm) (96906) MS27030-5 | EA | 8 |
| 5330-00-088-9166 | GASKET, 3.00 IN. (7.62 cm) (96906) MS27030-8 | EA | 23 |
| 5330-00-899-4509 | GASKET, 4.00 IN. (10.16 cm) (96906) MS27030-9 | EA | 4 |
| 5975-01-050-5707 | GROUND ROD (97403)13219E0462 | EA | 8 |
| 4720-00-555-8325 | HOSE ASSEMBLY, 1.50 IN. (3.81 cm) I.D. (81349) M370B05B2C3000 | EA | 8 |
| 4720-00-083-0048 | HOSE ASSEMBLY, 3.00 IN. (7.62 cm) I.D. (73842) 543-419-3-50 | EA | 8 |
| 4930-00-471-0288 | NOZZLE, FUEL (19207)10896274 | EA | 8 |
| 4730-00-823-5316 | PLUG, 1.50 IN. (3.81 cm) (96906) MS27029-9 | EA | 8 |
| 4730-00-929-0790 | PLUG, 3.00 IN. (7.62 cm) (96906) MS27029-15 | EA | 15 |
| 4730-00-640-6188 | PLUG, 4.00 IN. (10.16 cm) (96906) MS27029-17 | EA | 2 |
| 4730-00-951-3293 | REDUCER, 4.0/3.0 F/M 24869) MS49000-1 | EA | 1 |
| 4730-00-951-3296 | REDUCER, 4.0/3.0 M/F (96906) MS49000-9 | EA | 1 |
| 4730-01-096-1039 | TEE ASSEMBLY, QUICK-DISCONNECT, 3.0 X 1.5 IN. (7.62 x 3.81 cm) (97403) 13222E9884 | | EA |
| 4730-00-075-2405 | TEE ASSEMBLY, QUICK-DISCONNECT, 4.00 IN. (10.16 cm) (97403)5-14-676C | EA | 1 |
| 4820-01-098-4925 | VALVE ASSEMBLY, 3.00 IN. (7.62 cm) (97403)13222E9888 | EA | 6 |
| 4720-01-064-8820 | TUBING ASSEMBLY, NONMETALLIC (19207)11668857 | EA | 1 |
| | C-3/(C-4 blank) | | |

**APPENDIX D
EXPENDABLE AND DURABLE ITEMS LIST**

Section I. INTRODUCTION

| Paragraph Number | Paragraph Title | Page Number |
|------------------|------------------------------|-------------|
| D-1 | Scope | D-1 |
| D-2 | Explanation of Columns | D-2 |

D-1. SCOPE.

This appendix lists expendable/durable supplies and materials you will need to operate and maintain the M969A2 semitrailer.

This listing is for informational purposes only and is not authority to requisition the listed items. These items are authorized to you by CTA 50-970, Expendable/Durable Items (Except Medical, Class V, Repair Parts and Heraldic Items), or CTA 8-100, Army Medical Department Expendable/Durable items.

D-2. EXPLANATION OF COLUMNS.

There are five columns in Section II, Expendable and Durable Items List:

Column (1) - Item Number. This number is assigned to the entry in the listing and is referenced in the Initial Setup of maintenance paragraphs or narrative instructions to identify the material needed (e.g., Drycleaning solvent, Item 6, Appendix D).

Column (2) - Level. This column identifies the lowest level of maintenance that requires the listed item:

- C - Operator/Crew
- O- Unit
- F - Direct Support
- H - General Support

Column (3) - National Stock Number. This is the national stock number assigned to the item; use it to request or requisition the item.

Column (4) - Description (CAGEC). This column indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the Commercial and Government Entity Code (CAGEC) (in parentheses) followed by the part number, if applicable.

Column (5) - U/M [Unit of Measure]. Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation: EA (each), GL (gallon), LB (pound), OZ (ounce), PT (pint), and OT (quart). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

Section II. EXPENDABLE AND DURABLE ITEMS LIST

| (1) ITEM NUMBER | (2) LEVEL | (3) NATIONAL STOCK NUMBER | (4) DESCRIPTION (CAGEC) | (5) U/M |
|-----------------------|--------------|------------------------------------|---|------------|
| 1 | C | 8950-00-292-9611 | BAKING SODA (63298) A-A-20086 | Oz |
| 2 | C | 6850-01-092-3550 | COMPOUND: Silicone (75037)1609 | EA |
| 3 | C | | DRYCLEANING SOLVENT: Type II (81348) P-D-680 | |
| | | 6850-00-110-4498 | 1 -Pint Can | PT |
| | | 6850-00-274-5421 | 5-Gallon Can | GL |
| | | 6850-00-285-8011 | 55-Gallon Drum | GL |
| 4 | C | | FUEL OIL, DIESEL: Arctic, DF-A (81348) W-F-800 | |
| | | 9140-00-286-5282 | 5-Gallon Can | GL |
| | | 8140-00-286-5284 | 55-Gallon Drum | GL |
| 5 | C | | FUEL OIL, DIESEL: Regular, DF-2 (81348) W-F-800 | |
| | | 9140-00-286-5295 | 5-Gallon Can | GL |
| | | 9140-00-286-5296 | 55-Gallon Drum | GL |
| 6 | C | | FUEL OIL, DIESEL: Winter, DF-1 (81348) W-F-800 | |
| | | 9140-00-286-5287 | 5-Gallon Can | GL |
| | | 9140-00-286-5288 | 55-Gallon Drum | GL |
| 7 | C | | GREASE: Automotive and Artillery (81349) MIL-G-10924 | |
| | | 9150-01-197-7688 | 2 1/4-Ounce Tube | Oz |
| | | 9150-01-197-7689 | 6 1/2-Pound Can | LB |
| | | 9150-01-197-7690 | 1 3/4-Pound Can | LB |
| | | 9150-01-197-7692 | 35-Pound Can | LB |
| | | 9150-01-197-7693 | 14-Ounce Cartridge | Oz |
| 8 | C | | LUBRICATING OIL: Internal Combustion Engine, Arctic, OEA (81349) MIL-L-46167 | |
| | | 9150-00-402-4478 | 1 -Quart Can | QT |
| | | 9150-00-402-2372 | 5-Gallon Can | GL |
| | | 9150-00-491-7197 | 55-Gallon Drum | GL |

Section II. EXPENDABLE AND DURABLE ITEMS LIST (continued)

| (1) ITEM NUMBER | (2) LEVEL | (3) NATIONAL STOCK NUMBER | (4) DESCRIPTION (CAGEC) | (5) U/M |
|-----------------------|--------------|--|---|----------------|
| 9 | C | 9150-00-189-6727 9150-00-186-6668 9150-00-191-2772 | LUBRICATING OIL: OE/HDO 10W (81349) MIL-L-2104 1 -Quart Can 5-Gallon Can 55-Gallon Drum | QT GL GL |
| 10 | C | (81349) MIL-L-2104 9150-00-186-6681 9150-00-188-9858 9150-00-189-6729 | LUBRICATING OIL: OE/HDO 15/40W 1-Quart Can 5-Gallon Can 55-Gallon Drum | QT GL GL |
| 11 | C | 7920-00-205-1711 | RAG: Wiping, Cotton and Cotton Synthetic (58536) A-A-531 | LB |
| 12 | C | 8520-00-228-0598 | 50-Pound Bale SOAP: Toilet, Liquid (81348) P-S-624 Type 1 | GL |

D-3/(D-4 blank)

**APPENDIX E
LUBRICATION INSTRUCTIONS**

| Paragraph Number | Paragraph Title | Page Number |
|------------------|---|-------------|
| E-1 | General | E-1 |
| E-2 | Specific Lubrication Instructions | E-1 |

E-1. GENERAL.

NOTE

These instructions are MANDATORY.

- a. Semitrailers must receive lubrication with approved lubricants at recommended intervals in order to be mission-capable at all times.
- b. The KEY (p. E-8) lists lubricants to be used in all temperature ranges and shows the intervals.
- c. The lubrication charts (pp. E-3 through E-7) show lubrication points, items to be lubricated, the required lubricants, and recommended intervals for lubrication. Any special lubricating instructions required for specific components are contained in the NOTES section (p. E-8).
- d. Recommended intervals are based on normal conditions of operation, temperature, and humidity. When operating under extreme conditions, lubricants should always be changed more frequently. When in doubt, notify your supervisor.

E-2. SPECIFIC LUBRICATION INSTRUCTIONS.

- a. Keep all lubricants in a closed container and store in a clean, dry place away from extreme heat. Keep container covers clean and do not allow dust, dirt, or other foreign material to mix with lubricants. Keep all lubrication equipment clean and ready for use.
- b. Maintain a record of lubrication performed and report any problems noted during lubrication. Refer to DA Pam 738-750 for maintenance forms and procedures for recording and reporting any findings.

WARNING

Wipe excess lubricant from the area of brakeshoe linings to prevent grease from soaking the linings. If brakeshoe linings become soaked, have Unit maintenance replace them. Failure to follow this warning may cause brakes to malfunction, resulting in serious injury or death to personnel.

- c. Keep all external parts of equipment not requiring lubrication free of lubricants. After lubrication, wipe off excess oil or grease to prevent accumulation of foreign matter.
- d. Refer to FM 9-207 for lubrication instructions in cold weather.

E-2. SPECIFIC LUBRICATION INSTRUCTIONS (continued).

- e. After operation in muddy, sandy, or dusty conditions, clean and inspect all points of lubrication for fouled lubricants.
- f. Intervals (on-condition or hard time) and the related man-hour times are based on normal operation. The man-hour time specified is the time you need to do all services prescribed for a particular interval. Decrease the intervals if your lubricants are contaminated or if you are operating equipment under adverse conditions, including longer than usual operating hours. The intervals may be extended during periods of low activity. If extended, adequate preservation precautions must be taken.


WARNING

Drycleaning solvent P-D680 is toxic and flammable. Always wear protective goggles and gloves, and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes, and DO NOT breathe vapors. DO NOT use near open flames or excessive heat.


Clean all fittings and areas around lubrication points with drycleaning solvent (Item 3, Appendix D) or the equivalent before lubricating equipment. After lubrication, wipe off excess oil or grease with clean rags (Item 11, Appendix D) to prevent accumulation of foreign matter.

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT



W • OE/HDO
Landing Gear Handle
(see Note 2)




OE/HDO • W
Landing Gear
Foot Pads

| INTERVAL | MAN-HOURS * |
|----------|-------------|
| W | 0.2 |

* The man-hour time specified is the time you need to do all the services prescribed for a particular interval.

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT




| INTERVAL | MAN-HOURS * |
|----------|-------------|
| W | 0.2 |

* The man-hour time specified is the time you need to do all the services prescribed for a particular interval.

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT



| INTERVAL | MAN-HOURS * |
|----------|-------------|
| W | 0.2 |


* The man-hour time specified is the time you need to do all the services prescribed for a particular interval.

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT



OE/HDO • W
 Hose Reel Side
 Bearings
 (see Note 3)





W • GAA
 Hose Reel Hand Crank
 Operating Shaft
 (see Note 3)

| INTERVAL | MAN-HOURS * |
|----------|-------------|
| W | 0.4 |

* The man-hour time specified is the time you need to do all the services prescribed for a particular interval.

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT



W • OE/HDO Winch Assembly

| INTERVAL | MAN-HOURS * |
|----------|-------------|
| W | 0.4 |

* The man-hour time specified is the time you need to do all the services prescribed for a particular interval.

-KEY-

| LUBRICANT | EXPECTED TEMPERATURE* | | | INTERVAL |
|--|-----------------------------|----------------------------------|----------------------------------|------------|
| | Above +15°F (Above -9°C) | +40°F to -0°F (+4°C to -18°C) | +41°F to 67°F (+5°C to -55°C) | |
| OEIHDO (MIL-L-2104) Lubricating-Oil, Internal Combustion Engine, Tactical Service OEA (MIL-L-46167) Lubricating Oil, Internal Combustion Engine, Arctic | OE/HDO 15W40 | OE/HDO 15W40 | OEA (see Note 1) | W - Weekly |
| GAA (MIL-G-10924) Grease, Automotive and Artillery * For Arctic operations, refer to FM 9-207. | All Temperatures | | | |

NOTES:

1. For operation of equipment in extended cold temperatures below -15°F (-26°C), remove lubricants prescribed in the key for temperatures above -15°F (-26°C). Relubricated with lubricants specified in the key for temperatures below -15°F (-26°C). If OEA lubricant is required to meet the temperature changes prescribed in the key, OEA lubricant is to used in place of OE/HDO lubricant for all temperature ranges where OE/HDO lubricant is specified in the key.
2. Landing Gear Handle. After lubricating , operate landing gear up and down to distribute lubricant.
3. Grease zerk fittings until grease appears.

INDEX

| Subject | Page |
|--|------|
| A | |
| Abbreviations and Acronyms | 1-3 |
| Additional Authorization List | C-1 |
| Adjustments, Initial | 2-28 |
| Air Reservoirs Maintenance | 3-26 |
| Automatic Water Drain Valve | 1-12 |
| B | |
| Basic Issue Items (BII) | B-3 |
| Batteries, Terminals, and Cables Service | 3-24 |
| Bonding and Grounding | 2-38 |
| Bulk Haul and Fuel-Servicing Operations Not Involving Use of Engine and Pump | 2-46 |
| Bulletins | A-3 |
| C | |
| Cables, Servicing of | 3-24 |
| Checks, Self-Test, and Initial Adjustments | 2-28 |
| Cold, Operation in Extreme | 2-61 |
| Components, Major | 1-6 |
| Components of End Item and Basic Issue Items Lists | B-1 |
| Components of End Item (COEI) | B-2 |
| Controls and Indicators | 2-1 |
| Corrosion Prevention and Control (CPC) | 1-3 |
| Coupling Semitrailer to Prime Mover | 2-29 |
| D | |
| Data Plates | 2-36 |
| Decals | 2-36 |
| Destruction of Army Materiel To Prevent Enemy Use | 1-3 |
| Dispensing Components, Valves, and Piping | 2-4 |
| Dusty Areas, Operation in | 2-63 |
| E | |
| Engine | 1-11 |
| Engine Air Cleaner Service | 3-28 |
| Engine Control Panel | 2-2 |
| Engine Operating Instructions | 2-40 |
| Equipment Characteristics, Capabilities, and Features | 1-5 |

Subject **Page**

E (continued)

Equipment Data 1-8
 Equipment Improvement Recommendations (EIRs), Reporting 1-3
 Expendable and Durable Items List D-1

F

Field Manuals A-2
 Filter/Separator Assembly 1-12
 Filter/Separator Sump Maintenance 3-29
 Fording 2-63
 Forms A-1
 Fuel-Dispensing Nozzle Maintenance 3-30
 Fuel-Handling Instructions 2-38
 Fueling/Defueling Precheck and Operations Summary 2-44
 Fuel-Servicing (Filtered) Operations 2-57
 Fuel-Servicing (Nonfiltered) Involving Use of Engine and Pump 2-52
 Fuses, Go-No-Go 1-12

G

Go-No-Go Fuses 1-12
 Grounding, Bonding and 2-38

H

Heat, Operation in Extreme 2-62
 How To Use This Manual iii
 Humidity, Operation in High 2-62

I

Indicators and Controls 2-1

L

Leakage Definitions 2-11
 Lubrication Chart E-3
 Lubrication Instructions 3-1, E-1

M


Maintenance Forms and Procedures 1-3
 Major Components, Location and Description 1-6
 Manual Drain Valve 1-12
 Mud and Snow, Operation in 2-63

| Subject | Page |
|---|------|
| N | |
| Nozzle Maintenance | 3-30 |
| O | |
| Operating Instructions | 2-1 |
| Operation in Dusty or Sandy Areas | 2-63 |
| Operation in Extreme Cold | 2-61 |
| Operation in Extreme Heat | 2-62 |
| Operation in High Humidity and Saltwater Areas | 2-62 |
| Operation in Mud and Snow | 2-63 |
| Operation, Principles of | 1-11 |
| Operation Under Unusual Conditions | 2-61 |
| Operation Under Usual Conditions | 2-28 |
| Operator's Controls and Indicators | 2-1 |
| P | |
| Piping, Dispensing Components, and Valves | 2-4 |
| Preventive Maintenance Checks and Services (PMCS) | 2-9 |
| PMCS Procedures, General | 2-10 |
| PMCS Procedures, Specific | 2-10 |
| PMCS Table | 2-12 |
| Principles of Operation | 1-11 |
| Publications Index | A-1 |
| Pump | 1-11 |
| Pump and Engine Assembly | 1-11 |
| Q | |
| Quick Guide to Troubleshooting | 3-1 |
| R | |
| References | A-1 |
| Refuel on the Move (ROM) | 2-60 |
| Repairs, Reporting | 2-9 |
| S | |
| Saltwater Areas, Operation in | 2-62 |
| Sandy Areas, Operation in | 2-63 |
| Self-Test, Initial Adjustments, Checks, and | 2-28 |
| Snow Intervals | 2-9 |
| Snow, Operation in | 2-63 |
| Spare Tire Dismounting and Mounting | 2-32 |
| Storage Box Maintenance | 3-26 |

| Subject | Page |
|---|-------------|
| T | |
| Technical Manuals | A-2 |
| Terminals, Batteries, and Cables Service | 3-24 |
| Troubleshooting Chart | 3-4 |
| Troubleshooting Procedures, Operator/Crew | 3-2 |
| Troubleshooting, Quick Guide to | 3-3 |
| U | |
| Uncoupling Semitrailer from Prime Mover | 2-34 |
| V | |
| Valves, Piping, and Dispensing Components | 2-4 |
| Vapor Recovery System | 1-13 |
| W | |
| Warning Summary | a |
| Warranty Data | 1-4 |

By Order of the Secretary of the Army:

Official



JOEL B. HUDSON
*Administrative Assistant to the
Secretary of the Army*
02067

DENNIS J. REIMER
*General, United States Army
Chief of Staff*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-39-E, block 2019, requirements for TM 9-2330-398-10.

* U.S. GOVERNMENT PRINTING OFFICE: 1996 746-014/2028

THE METRIC SYSTEM AND EQUIVALENTS

LINEAR MEASURE

1 Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
 1 Kilometer = 1000 Meters = 0.621 Miles

WEIGHTS

1 Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces
 1 Kilogram = 1000 Grams = 2.2 Lb
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

SQUARE MEASURE

1 Sq Centimeter = 100 Sq Millimeters = 0.155 Sq Inches
 1 Sq Meter = 10,000 Sq Centimeters = 10.76 Sq Feet
 1 Sq Kilometer = 1,000,000 Sq Meters = 0.386 Sq Miles

CUBIC MEASURE

1 Cu Centimeter = 1000 Cu Millimeters = 0.06 Cu Inches
 1 Cu Meter = 1,000,000 Cu Centimeters = 35.31 Cu Feet


TEMPERATURE

$5.9 (^{\circ}\text{F} - 32) = ^{\circ}\text{C}$
 212^o Fahrenheit is equivalent to 100^o Celsius
 90^o Fahrenheit is equivalent to 32.2^o Celsius
 32^o Fahrenheit is equivalent to 0^o Celsius
 $9 \text{ } ^{\circ}\text{C} + 32 = \text{ } ^{\circ}\text{F}$

APPROXIMATE CONVERSION FACTORS

| <u>TO CHANGE</u> | <u>TO</u> | <u>MULTIPLY BY</u> |
|----------------------------------|--------------------------------|--------------------|
| Inches | Centimeters | 2.540 |
| Feet | Meters | 0.305 |
| Yards | Meters | 0.914 |
| Miles | Kilometers | 1.609 |
| Square Inches | Square Centimeters | 6.451 |
| Square Feet | Square Meters | 0.093 |
| Square Yards | Square Meters | 0.836 |
| Square Miles | Square Kilometers | 2.590 |
| Acres | Square Hectometers | 0.405 |
| Cubic Feet | Cubic Meters | 0.028 |
| Cubic Yards | Cubic Meters | 0.765 |
| Fluid Ounces | Milliliters | 29.573 |
| Pints | Liters | 0.473 |
| Quarts | Liters | 0.946 |
| Gallons | Liters | 3.785 |
| Ounces | Grams | 28.349 |
| Pounds | Kilograms | 0.454 |
| Short Tons | Metric Tons | 0.907 |
| Pound-Feet | Newton-Meters | 1.356 |
| Pounds per Square Inch | Kilopascals | 6.895 |
| Miles per Gallon | Kilometers per Liter | 0.425 |
| Miles per Hour | Kilometers per Hour | 1.609 |

| <u>TO CHANGE</u> | <u>TO</u> | <u>MULTIPLY BY</u> |
|--------------------------------|----------------------------------|--------------------|
| Centimeters | Inches | 0.394 |
| Meters | Feet | 3.280 |
| Meters | Yards | 1.094 |
| Kilometers | Miles | 0.621 |
| Square Centimeters | Square Inches | 0.155 |
| Square Meters | Square Feet | 10.764 |
| Square Meters | Square Yards | 1.196 |
| Square Kilometers | Square Miles | 0.386 |
| Square Hectometers | Acres | 2.471 |
| Cubic Meters | Cubic Feet | 35.315 |
| Cubic Meters | Cubic Yards | 1.308 |
| Milliliters | Fluid Ounces | 0.034 |
| Liters | Pints | 2.113 |
| Liters | Quarts | 1.057 |
| Liters | Gallons | 0.264 |
| Grams | Ounces | 0.035 |
| Kilograms | Pounds | 2.205 |
| Metric Tons | Short Tons | 1.102 |
| Newton-Meters | Pound-Feet | 0.738 |
| Kilopascals | Pounds per Square Inch | 0.145 |
| Kilometers per Liter | Miles per Gallon | 2.354 |
| Kilometers per Hour | Miles per Hour | 0.621 |



TA089991

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT... PIN-POINT WHERE IT IS

| PAGE NO. | PARA-GRAPH | FIGURE NO. | TABLE NO. |
|----------|------------|------------|-----------|
|----------|------------|------------|-----------|

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

