

CHANGE
No. 1

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington D.C.
10 November 1995

**LUBRICATION ORDER
FOR
RECOVERY VEHICLE, FULL-TRACKED
MEDIUM, M88A1
(2350-00-1 22-6826)**

LO 9-2350-256-12, 28 February 1986, is changed as follows:

1. Remove old pages and insert new pages as indicated below.
2. New or changed material is indicated by a vertical bar in the margin of the page.
3. File this change sheet in the front of the publication for reference purposes.

Remove pages


Card 1 of 38 thru Card 14 of 38
Card 33 of 38 thru Card 37 of 38

Insert pages

Card 1 of 38 thru Card 14 of 38
Card 33 of 38 thru Card 37 of 38

By Order of the Secretary of the Army:

Official:



YVONNE M. HARRISON
*Administrative Assistant to the
Secretary of the Army*

01032

DENNIS J. REIMER
*General, United States Army
Chief of Staff*

DISTRIBUITION:

To be distributed in accordance with DA Form 12-37-E, block 1447, requirements for
LO 9-2350-256-12.

Approved for public release; distribution is unlimited.

LUBRICATION ORDER

LO 9-2350-256-12

28 February 1986

(Supersedes LO 9-2350-256-12 July 1976)

RECOVERY VEHICLE, FULL-TRACKED MEDIUM, M88A1 (2350-00-122-6826)

Intervals (on-condition or hard time) and the related man-hour times are based on normal operation. The man-hour time specified is the time you need to do all the services prescribed for a particular interval. On-condition (OC) oil sample intervals shall be applied unless changed by the Army Oil Analysis Program (AOAP) laboratory. Change the hard-time if your lubricants are contaminated or if you are operating the equipment under adverse operating conditions, including longer-than-usual operating hours. The hard-time interval may be extended during periods of low activity. If extended, adequate preservation precautions must be taken. Hard-time intervals will be applied in the event AOAP laboratory support is not available.

WARNING

Dry-cleaning solvent, type II used to clean parts, is potentially dangerous to personnel and property. Do not use near open flame or excessive heat. Flash point of solvent is 138°F (58.8°C).

NOTE

Always install dust caps on fittings after lubrication procedures.

Clean parts with dry-cleaning solvent, type II (SD-2) or equivalent. Dotted arrow points indicate lubrication on both sides of the equipment. The lowest level of maintenance authorized to lubricate a point is indicated by one of the following symbols as appropriate: Operator/Crew (C); and Organizational Maintenance (O).

Reporting errors and recommending Improvements. You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter or DA Form 2028 (recommended Changes to Publications and Blank Forms) directly to: Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-IM-MMAA, Warren, MI 48397-5000. A reply will be furnished to you.

TOTAL MAN-HOURS	
INTERVALS	MAN-HOURS
D	7.3
M	11.3
S	9.0
A	1.0
OC	5.8
After fording	24.0

*If AOAP support is not available and hard-time intervals are used, 2 man-hours will be required for each 25-hour period or monthly (whichever comes first); additionally, semiannual labor requirements will increase by 2.5 man-hours.

SERVICE FROM CREW COMPARTMENT

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT

Bearing Plate (See note 7 and view F) (O)

Spade Release Mechanism (See note 3 and view B) (O)

Compensating Idler Wheel Arm Bearings (See note 8 and view G) (O)


Track Adjusting Link (See note 4 and view C) (O)

Hoist Winch Cable Roller Bearings (See note 6 and view E) (O)

Main Winch Cable Roller (See note 13 and view L) (O)

Compensating Idler Wheel Bearings (See note 2 and view A) (O)

Roadwheel Bearings (See note 9 and view H) (O)



0.50-Caliber Machine Gun, Flexible M2 (See note 10 and view I) (O)

Track Support Rollers (See note 11 and view J) (O)

Towing Pintle (See note 12 and view K) (O)


Roadwheel Arm Bearings (See note 5 and view D) (O)

Commander's Cupola Hold-Open Latch (See note 14 and view M) (O)

Personnel Door Torsion Bar (See note 15 and view N) (O)

Boom Lever Pin (See note 16 and view O) (O)

Boom Stayline Cables (See note 17 and view P) (O)



TA171786

SERVICE FROM CREW COMPARTMENT

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT

Spade Cylinder Pins (See note 18 and view Q) (O)

Boom Cylinder Pin (See note 19 and view R) (O)


Spade Cylinder Pins (See note 18 and views Q through T) (O)

Hoist Winch Gear Case Fill and Level (See note 20 and view V) (O)

Breather Cap-Hoist Winch Gear Case (See note 21 and view V) (O)

Hoist Winch Cable (See note 23 and view X) (O)

Hoist Winch Gear Case Drain (See note 22 and view W) (O)



Spade Link Pin (See note 24 and view Y) (O)

Boom Foot Pivot Pin (See note 25 and view Z) (O)

Boom Pivot Pin (See note 26 and view AA) (O)

Main Winch Level Winder Guide (See note 27 and view AB) (O)

Main Winch Gear Case Fill and Level (See note 28 and view AC) (O)

Breather Cap-Main Winch Gear Case (See note 29 and view AC) (O)

Mechanical Transmission Oil Filter (See note 30 and view AD) (O)

TA171787

SERVICE FROM CREW COMPARTMENT

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT

Hydraulic Reservoir Drain
(See note 31 and view
AE) (O)


Mechanical Transmission
Drain (See note 32 and
view AF) (O)

Mechanical Transmission
and Hydraulic Pump Shaft
Coupling (See note 33
and view AG) (O)

Mechanical Transmission
Fill and Level (See note
34 and view AH) (O)

Breather Cap-Mechanical
Transmission (See note 35
and view AI)(O)

Mechanical Transmission
Shaft Universal Joint (See
note 36 and view AJ) (O)



Main Winch Cable
(See note 37 and view
AJ) (C)

Main Winch Gear Case
Drain (See note 38 and
view AK) (O)

Hydraulic Reservoir Fill
and Level (See note 39
and view AL) (O)

Hydraulic Reservoir Filter
(See note 40 and view
AM) (O)

TA171788


SERVICE FROM CREW COMPARTMENT

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT

Steering Control Assembly (See note 41 and view AN) (O)

GAA • M



Steering Linkage (See note 42 and view AO) (O)

GAA • M

M • GAA

Accelerator Pedal Assembly (See note 48 and view AU) (O)

Steering Linkage Bell Crank Assembly (See note 43 and view AP) (O)

GAA • M

M • GAA

Shifting Control Assembly (See note 49 and view AV) (O)

Service Brake Pedal (See note 44 and view AQ) (O)

GAA • M

M • GAA

Shifting Linkage Pillow Block (See note 50 and view AW) (O)

Service Brake Linkage (See note 45 and view AR) (O)

GAA • M

M • GAA


Accelerator Linkage Pillow Block (See note 51 and view AX) (O)

Service Brake Linkage Pillow Block (See note 46 and view AS) (O)

GAA • M

Service Brake Shaft (See note 47 and view AT) (O)

GAA • M



TA171789

SERVICE FROM ENGINE COMPARTMENT

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT

Mechanical Transmission Shaft Universal Joint (See note 52 and view AY) (O)

GAA • M

OC or S •

Main Engine Crankcase Drain (See note 59 and view BE) (C)

Main Engine Oil Filter (See note 53 and view AZ) (O)

• OC or M

D •

Main Engine Crankcase Level (See note 60 and view BF) (C)

Main Engine On-Condition AOAP (See note 54 and view AZ) (O)

• OC or 25H or M

• OEMDO

Main Engine Crankcase Fill (See note 60 and view BG) (C)

Transmission Drain (See note 55 and view BA) (C)

• OC or S

S • GAA

Fuel Transfer Pump (See note 61 and view BH) (O)

Transmission Oil Filters (See note 56 and view BB) (O)

• OC or M

M • GAA

Brake Slack Adjuster Lever (See note 62 and view BI) (O)

Brake Air Valve Linkage Bracket (see note 64 and view BJ) (O)

GAA • M

OC or S •


Output Reduction Drives-Drain (See note 63 and view BI) (O)

Transmission Fill and Level (See note 58 and view BD) (C)

OEMDO • D

OC or 25H or M

Transmission On-Condition AOAP (See note 57 and view BC) (O)



TA171790

SERVICE FROM ENGINE COMPARTMENT

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT

Accelerator Linkage Bell Crank (See note 65 and view BK) (O)

Accelerator Linkage Pillow Block (See note 65 and view BK) (O)

Service Brake Linkage Lever (See note 66 and view BL) (O)

Service Brake Linkage Shaft (See note 67 and view BM) (O)

Service Brake Linkage Bell Crank (See note 68 and view BN) (O)

GAA • M

GAA • M

GAA • M

GAA • M

GAA • M

S or 100H •

D • OE/MDO

OC or S •

M • GAA

M • GAA


Auxiliary Power Unit Chaincase Drain (See note 69 and view BO) (C)

Auxiliary Power Unit Chaincase Fill and Level (See note 70 and view BO) (C)

Auxiliary Power Unit Engine Filter (See note 71 and view BP)

Service Brake Linkage Pillow Block (See note 68 and view BN) (O)

Service Brake Linkage Shaft (See note 72 and view BQ) (O)




TA171791

SERVICE FROM ENGINE COMPARTMENT

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT



Shifting Linkage Bell Crank (See note 74 and view BS) (O)

GAA • M

Steering Linkage Bell Crank (See note 73 and view BR) (O)

GAA • M

Shifting Linkage Bell Crank (See note 74 and view BS) (O)

GAA • M

Steering Linkage Bell Crank (See note 73 and view BR) (O)

GAA • M

S • GAA Rear Boom Lever Cylinder Pins (See note 75 and view BT) (O)

TA171792


SERVICE FROM APU COMPARTMENT

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT

Auxiliary Power Unit
Crankcase Drain (See
note 76 and view BP) (O)

• S or
100 H




D • OE/MDO

Auxiliary Power Unit
Crankcase Fill and Level
(See note 77 and view
BU) (C)

OIL CAN POINTS — EXTERIOR

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT



TA171794

OIL CAN POINTS — EXTERIOR

LUBRICANT • INTERVAL


INTERVAL • LUBRICANT

Snatch Block (See note 79 and view CC) (C)

PL-S • M

M • PL-S

Door Latch (See note 79 and view CF) (C)



Headlamp Removal Nut (See note 79 and view CD) (C)

PL-S • S

M • PL-S

Door-Latch (See note 79 and view CG) (C)

On-Vehicle Stowage Clamps (See note 79 and view CE) (C)

PL-S • S

S • PL-S

On-Vehicle Stowage Clamps (See note 79 and view CH) (C)

TA171795

OIL CAN POINTS — EXTERIOR

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT

Door Latches (See note 79 and view CI) (C)

PL-S • M

M • PL-S


Door Latch (See note 79 and view CI) (C)

Sheave (See note 79 and view CJ) (C)

PL-S • M

M • PL-S

0.50-Caliber Machine Gun Mount Traverse Lock (See note 79 and view CM) (C)



On-Vehicle Stowage Clamps (See note 79 and view CK) (C)

PL-S • S

S • PL-S

Headlamp Removal Nut (See note 79 and view CN) (C)

OIL CAN POINTS — INTERIOR

LUBRICANT • INTERVAL


INTERVAL • LUBRICANT

Seat Moving Parts (See note 79 and view CO) (C)

PL-S • S

M • PL-S

Boom Limit Valve Actuating Arm Shaft (See note 79 and view CQ) (C)



Side Door Lockpin (See note 79 and view CR) (C)

PL-S • S

M • PL-S


Manual Fuel Shutoff Linkage (See note 79 and view CP) (C)

TA171797

LUBRICANTS		CAPACITIES	EXPECTED TEMPERATURES For Arctic Operation. Refer to FM 9-207			INTERVALS
			Above 15°F (Above -9°C)	+40°F to -10°F (+4°C to -23°C)	0°F to -63°F (-18°C to -54°C)	
GAA MILG-10924	—GREASE, Automotive and Artillery All grease points	AS REQUIRED	ALL TEMPERATURES			
GO MIL-L-2105 or GOS MIL-L-10324	—LUBRICATING OIL, Gear, Multipurpose —LUBRICATING OIL, Gear, Subzero Hoist Winch Gear Case Main Winch Gear Case	3 gal. (11.36 L) 11 gal. (41.64 L)	GO 90	GO 90	GOS	Intervals Are As Follows: OC — As Directed by AOAP Laboratory H — Hours D — Daily; Days M — Monthly S — Semiannually
OE/HDO MIL-L-21040 or OEA MIL-L-46167	—LUBRICATING OIL, Internal Combustion Engine, Tactical Service —LUBRICATING OIL, Internal Combustion Engine, Arctic Boom Stayline Cables Hoist Winch Cable Main Winch Cable Mechanical Transmission Hydraulic Reservoir Transmission Main Engine Crankcase APU Chaincase APU Engine Crankcase	AS REQUIRED 1 gal. (3.79 L) 95 gal. (359.58 L) 17 gal. (64.35 L) 16.5 gal. (62.45 L) 1 qt. (0.95 L) 3.5 qt. (3.31 L)	OE/HDO-10	OE/HDO-10	OEA	
			OE/HDO-30	OE/HDO-10	OEA	
PL-S VV-L-800	—LUBRICATING OIL, General Purpose. Preservative All oil can points	AS REQUIRED	ALL TEMPERATURES			
CW VV-L-751	—LUBRICATING OIL, Chain, Wire Rope, Exposed Gear Hoist Winch Cable Main Winch Cable	AS REQUIRED	CW-IIC	CW-IIB	CW-IIA	TA171798


A

**COMPENSATING IDLER
WHEEL BEARINGS**




B

SPADE RELEASE MECHANISM




C

TRACK ADJUSTING LINK




D

ROADWHEEL ARM BEARINGS




E

**HOIST WINCH CABLE
ROLLER BEARINGS**



F


BEARING PLATES



TA171799


G

**COMPENSATING IDLER
WHEEL ARM BEARINGS**




H

ROADWHEEL BEARINGS




I

**0.50-CALIBER MACHINE
GUN, FLEXIBLE M2**




J

TRACK SUPPORT ROLLER




K

TOWING PINTLE



L


MAIN WINCH CABLE ROLLER



TA171800


M

**COMMANDER'S CUPOLA
HOLD-OPEN LATCH**




N

**PERSONNEL DOOR TORSION
BAR**




O

BOOM LEVER PIN




P

BOOM STAYLINE CABLES




Q

SPADE CYLINDER PIN



R

SPADE CYLINDER PIN





TA171801

S

SPADE CYLINDER PIN

LEFT REAR PIN ACCESS DOOR





FITTING FOR LEFT REAR PIN

T

SPADE CYLINDER PIN

RIGHT REAR PIN ACCESS PLATES




FITTING FOR RIGHT REAR PIN

U

BOOM CYLINDER PIN


FITTING




V

HOIST WINCH BREATHER CAP, FILL TUBE AND LEVEL CHECK

ACCESS DOOR





BREATHER CAP, FILL TUBE AND BAYONET GAGE (HIDDEN)



W

HOIST WINCH GEAR CASE DRAIN

DRAIN VALVE ACCESS DOOR




HOIST WINCH DRAIN VALVE

X

HOIST WINCH CABLE


HOIST WINCH CABLE



TA171802


Y

SPADE LINK PIN




Z

BOOM FOOT PIVOT PIN




AA

BOOM PIVOT PIN




AB

MAIN WINCH LEVEL WINDER GUIDE




AC

MAIN WINCH GEAR CASE BREATHER CAP, FILL TUBE, AND LEVEL CHECK



AD


MECHANICAL TRANSMISSION OIL FILTER



TA171803


AE

HYDRAULIC RESERVOIR DRAIN




AF

MECHANICAL TRANSMISSION AND OIL COOLER DRAIN




AG

MECHANICAL TRANSMISSION AND HYDRAULIC PUMP SHAFT COUPLING




AH

MECHANICAL TRANSMISSION BREATHER CAP AND FILL AND LEVEL




AI

MECHANICAL TRANSMISSION SHAFT UNIVERSAL JOINT



AJ


MAIN WINCH CABLE



TA171804


AK

MAIN WINCH GEAR CASE DRAIN




AL

HYDRAULIC RESERVOIR FILL AND LEVEL




AM

HYDRAULIC RESERVOIR FILTER




AN

STEERING CONTROL ASSEMBLY




AO

STEERING LINKAGE




AP

STEERING LINKAGE BELLCRANK ASSEMBLY




TA171805


AQ SERVICE BRAKE PEDAL




AR SERVICE BRAKE LINKAGE




AS SERVICE BRAKE LINKAGE PILLOW BLOCK




AT SERVICE BRAKE SHAFT



AU ACCELERATOR PEDAL ASSEMBLY




AV SHIFTING CONTROL ASSEMBLY




TA171806


AW SHIFTING LINKAGE PILLOW BLOCKS




AX ACCELERATOR LINKAGE PILLOW BLOCKS




AY MECHANICAL TRANSMISSION SHAFT UNIVERSAL JOINT




AZ MAIN ENGINE OIL FILTER AND ON-CONDITION AOAP



BA TRANSMISSION DRAIN




BB TRANSMISSION OIL FILTERS (RIGHT AND LEFT)




BC

TRANSMISSION ON-CONDITION AOAP




BD

TRANSMISSION FILL AND LEVEL




BE

MAIN ENGINE CRANKCASE DRAIN




BF

MAIN ENGINE CRANKCASE LEVEL




BG

MAIN ENGINE CRANKCASE FILL



BH


FUEL TRANSFER PUMP



TA171808


BI

**BELL CRANK AND SLACK ADJUSTER
LEVER AND OUTPUT
REDUCTION DRIVES**




BJ

**BRAKE AIR VALVE LINKAGE
BRACKET**




BK

**ACCELERATOR LINKAGE
BELL CRANK AND PILLOW
BLOCK**




BL

**SERVICE BRAKE LINKAGE
LEVER**




BM

**SERVICE BRAKE LINKAGE
SHAFT**



BN


**SERVICE BRAKE LINKAGE, BELL CRANK
AND PILLOW BLOCK**



TA171809


BO

**AUXILIARY POWER UNIT
CHAINCASE OIL**




BP

**AUXILIARY POWER UNIT ENGINE OIL
FILTER AND CRANKCASE DRAIN**




BQ

**SERVICE BRAKE LINKAGE
SHAFT**




BR

**STEERING LINKAGE
BELL CRANK**




BS

**SHIFTING LINKAGE
BELL CRANK**



BT


BOOM LEVER CYLINDER PINS



TA171810


BU

AUXILIARY POWER UNIT FILL AND LEVEL




BV

GRILLE DOOR HINGES AND RETAINING BOLTS




BW

WISE




BX

BOOM LOCKPIN




BY

GRILLE DOOR HINGES AND RETAINING BOLTS



BZ


LATCHES



TA171811


CA

EXHAUST DEFLECTOR PIVOT PIN AND HINGES




CB

PIVOT PINS




CC

SNATCH BLOCKS




CD

HEADLAMP REMOVAL NUT




CE

ON-VEHICLE STORAGE CLAMPS



CF


DOOR LATCH



TA171812


CG

DOOR LATCH




CH

ON-VEHICLE STORAGE CLAMPS




CI

DOOR LATCHES




CJ

SHEAVE




CK

ON-VEHICLE STORAGE CLAMPS



CL


DOOR LATCH



TA171813


CM

CAL. .50 MACHINE GUN
MOUNT TRAVERSE LOCK




CN

HEADLAMP REMOVAL NUT




CO

DRIVER'S MECHANIC'S
RIGGER'S SEAT MOVING PARTS




CP

MANUAL FUEL SHUTOFF
LINKAGE




CQ

BOOM LIMIT VALVE
ACTUATING ARM SHAFT



CR


SIDE DOOR LOCKPIN



TA171814


CS

**PERSONNEL HEATER MOTOR
DO NOT LUBRICATE**




CS

**VENTILATING BLOWER MOTOR
DO NOT LUBRICATE**




CS

**AUXILIARY POWER UNIT
AIR CLEANER
DO NOT LUBRICATE**




CT

**STARTER
LUBRICATE AT ASSEMBLY**




CT

**COMMANDER'S CUPOLA
LUBRICATE AT ASSEMBLY**



CT


**FUEL INJECTOR DRIVE
COUPLING
LUBRICATE AT ASSEMBLY**



TA171815

CT

**DRIVER AND MECHANIC
HATCH MECHANISM
LUBRICATE AT ASSEMBLY**



TA171816

1. FOR OPERATION OF EQUIPMENT IN PROTRACTED COLD TEMPERATURES BELOW -10°F (-23°C). Remove lubricants prescribed in key for temperatures above -10°F (-23°C). Clean parts with drycleaning solvent, type II (SD-2) or equivalent. Relubricate with lubricants specified in the key (card 14) for temperatures of 0°F to -65°F (-18°C to -50°C).

2. COMPENSATING IDLER WHEEL BEARINGS. If vehicle is without grease fittings, remove plug and insert fitting. Lubricate with GAA through fitting. Remove fitting and install plug.

3. SPADE RELEASE MECHANISM. Clean and coat exposed part of spade lockpin with GAA. Use a hand grease gun to pump grease into fitting on right side of pin housing.

4. TRACK ADJUSTING LINK. Lubricate with GAA through fitting.

5. ROADWHEEL ARM BEARINGS. Lubricate with GAA through three fittings on each roadwheel arm.

6. HOIST WINCH CABLE ROLLER BEARINGS. Open hoist winch cable access cover and lubricate with GAA through four fittings. Close access cover.

7. BEARING PLATE. Clean and coat plate with GAA.

8. COMPENSATING IDLER WHEEL ARM BEARINGS. Lubricate with GAA through fitting.

9. ROADWHEEL BEARINGS. Lubricate with GAA through six fittings at each side.

10. 0.50 CALIBER MACHINE GUN, FLEXIBLE, M2. Lubricate with GAA (refer to TM 9-1005-213-10).

11. TRACK SUPPORT ROLLERS. Lubricate with GAA through three fittings on each wheel.

12. TOWING PINTLE. Lubricate with GAA through three fittings.

13. MAIN WINCH CABLE ROLLER. Lubricate with GAA through two fittings.

14. COMMANDER'S CUPOLA HOLD-OPEN LATCH. Lubricate with GAA through fitting at end of pivot pin.

15. PERSONNEL DOOR TORSION BAR. Lubricate with GAA through four fittings.

16. BOOM LEVER PIN. Lubricate with GAA through fitting.

WARNING

Never handle cable with bare hands. Broken or frayed wire strands can cause severe cuts. Always wear protective (leather) gloves when handling cable.

17. BOOM STAYLINE CABLES. Clean and oil with OE. If cable has not been used within a six-month period, clean entire cable and brush soak it with OE. Wipe cable to remove excess oil. Coat cable with CW.

18. SPADE CYLINDER PINS. Remove eight screws, four flat washers, eight lockwashers, and remove subfloor plates. Lubricate with GAA through fitting at front of each cylinder and fitting at rear of each cylinder. Install subfloor plates and install four flat washers, eight lockwashers and eight screws.

19. BOOM CYLINDER PIN. Lubricate with GAA through fitting.

20. HOIST WINCH GEAR CASE FILL AND LEVEL. Open access door. Remove bayonet gage and check to see that 011 level is not

below ADD mark on the gage rod. If necessary, add GO (see temperature table on card 14) up to FULL mark. Close access door.

21. BREATHER CAP - HOIST WINCH GEAR CASE. Open access door. Remove breather cap and clean it with dry-cleaning solvent (SD-2). Install breather cap. Close access door.

22. HOIST WINCH GEAR CASE DRAIN.

NOTE

Drain oil from hoist winch gear case when oil is at operating temperature.

Open access door. Place a suitable receiving container of three-gallon capacity under oil outlet. Open hull drain valves; then open hoist winch drain valve. After oil has drained, close hoist winch valve; then close hull drain valve. Refill hoist winch gear case with appropriate weight of oil (see note 20 and table on card 14). Close access door.

WARNING

Never handle cable with bare hands. Broken or frayed wire strands can cause severe cuts. Always wear protective (leather) gloves when handling cable.

23. HOIST WINCH CABLE.

(a) DAILY, if winch has been used, clean cable and oil with OE.

(b) SEMIANNUALLY. Unwind and clean entire cable. Brush, soak cable with OE and wipe to remove excess oil. Coat and drain cable with CW before rewinding cable.

24. SPADE LINK PIN. Remove two screws and two lockwashers, and remove subfloor plate. Lubricate with GAA through fittings. Install subfloor plate and install two lockwashers and two screws.

25. BOOM FOOT PIVOT PIN. Raise boom and lubricate with GAA through fitting.

26. BOOM PIVOT PIN. Lubricate with GAA through fitting.

27. MAIN WINCH LEVEL WINDER GUIDE. Lubricate with GAA through two fittings.

28. MAIN WINCH GEAR CASE FILL AND LEVEL. Remove two screws and two lockwashers, and remove subfloor plate. Before operation, remove breather cap and bayonet gage. Check to see that oil level is to the FULL mark on gage. If level is below FULL mark, add oil (see table on card 14 for capacity and type) until oil level rises to FULL mark. Install bayonet gage and cap. Install subfloor plate and install two screws and lockwashers.

29. BREATHER CAP - MAIN WINCH GEAR CASE. Remove two screws and two lockwashers, and remove subfloor plate. Remove breather cap and clean it with dry-cleaning solvent (SD-2). Install breather cap. Install subfloor plate, and install two screws and lockwashers.

30. MECHANICAL TRANSMISSION OIL FILTER. Remove four screws, four flat washers and four lockwashers, and remove subfloor plate. Remove filter from mechanical transmission. Clean filter with dry-cleaning solvent (SD-2) and install filter. Install subfloor plate, and install four screws, four flat washers and four lockwashers.

31. HYDRAULIC RESERVOIR DRAIN. Open access door. Before draining hydraulic system, warm hydraulic fluid by idling main engine at 675 rpm for 5 minutes with main hydraulic pump engaged and all hydraulic levers in neutral. Shut down engine and open hull drain valves. Open hydraulic reservoir drain valve, After reservoir is drained, close hydraulic reservoir drain valve and hull drain valves. Refill reservoir (see note 39).

NOTE

Each time hydraulic oil is changed, hydraulic reservoir filter should be serviced (see note 40).

Close access door.

32. MECHANICAL TRANSMISSION DRAIN. Remove two screws, two flat washers and two lockwashers, and remove subfloor plate. Drain oil from mechanical transmission semiannually or every 1500 miles. Start main engine to operate transmission until warm. Shut down engine and open hull drain valve. Open mechanical transmission and oil cooler drain valve. After oil has drained, close mechanical transmission and oil cooler drain valve, and close hull drain valves. Fill mechanical transmission (see note 34). Install subfloor plate, two screws, two flat washers and two lockwashers.

33. MECHANICAL TRANSMISSION AND HYDRAULIC PUMP SHAFT COUPLING, Remove two screws, two flat washers and two lockwashers, and remove subfloor plate. Lubricate with GAA through two fittings. Install subfloor plate and two screws, flat washers and lockwashers.

34. MECHANICAL TRANSMISSION FILL AND LEVEL. Remove two screws, two flat washers and two lockwashers, and remove subfloor plate. Before operation, remove cap and bayonet gage. Check that oil level is to the FULL mark on gage. If necessary, fill mechanical transmission with oil (see table on card 14 for capacity and type) until FULL mark is reached. Start main engine to operate mechanical transmission for a few minutes. Stop engine and check oil level again. Add oil, if necessary. Install subfloor plate, two screws, two flat washers and two lockwashers.

35. BREATHER CAP - MECHANICAL TRANSMISSION. Remove two screws, two flat washers and two lockwashers, and remove subfloor plate. Remove breather cap, and clean it with drycleaning solvent (SD-2). Install cap. Install subfloor plate and two straws, two flat washers and two lockwashers.

36. MECHANICAL TRANSMISSION SHAFT UNIVERSAL JOINT. Remove four screws, four flat washers and four lockwashers, and remove subfloor plate, Remove boot and rotate joint as necessary to obtain access to two grease fittings. Lubricate with GAA through fittings. Install boot and subfloor plate, and install four screws, four flat washers and four lockwashers.

WARNING

Never handle cable with bare hands. Broken or frayed wire strands can cause severe cuts. Always wear protective (leather) gloves when handling cable.

37. MAIN WINCH CABLE.

(a) DAILY, if winch has been used, clean cable and oil with OE.

(b) SEMIANNUALLY. Unwind and clean entire cable. Brush soak cable with OE and wipe to remove excess oil. Coat winch drum with CW before rewinding cable. Rewind cable.

38. MAIN WINCH GEAR CASE DRAIN, Open access cover. Operate main winch to warm oil to operating temperature. Shut down all systems, Open hull drain valves and open main winch drain valve. After draining, close main winch drain valve and hull drain valves, Refill main winch (see note 28) with oil (see table on card 14 for capacity and type). Close access cover.

39. HYDRAULIC RESERVOIR FILL AND LEVEL. Remove two screws, two flat washers and two lockwashers, and remove subfloor plate. Before operation, remove bayonet gage and check that oil level in the reservoir measures up to the FULL mark, If necessary, remove fill cap and add oil (see table on card 14 for capacity and type) until oil level reaches FULL on bayonet gage. Install bayonet gage and fill cap. Operate hydraulic system until hydraulic oil reaches operating temperature. Shut down all systems and check oil level again. Add oil, if necessary Install subfloor plate and install two screws, two flat washers and two lockwashers.

40. HYDRAULIC RESERVOIR FILTER. Remove four screws, four flat washers and four lockwashers, and remove subfloor plate under rigger's seat. Remove eight screws in filter cover, and remove cover. Remove filter element and clean it with &y-cleaning solvent (SD-2); then dry with low pressure compressed air. Remove preformed gasket from between cover and filter element. Discard used gasket and install new gasket. Install filter element, filter cover and eight attaching screws. Operate hydraulic system and check for leaks. Shut down system and install subfloor plate, four screws, four flat washers and four lockwashers,

41. STEERING CONTROL ASSEMBLY, Lubricate with GAA through two fittings.

42. STEERING LINKAGE. Lubricate with GAA through two fittings,

43. STEERING LINKAGE BELL CRANK ASSEMBLY, Lubricate with GAA through fitting.

44. SERVICE BRAKE PEDAL. Lubricate with GAA through fitting.

45. SERVICE BRAKE LINKAGE. Lubricate with GAA through fitting.

46. SERVICE BRAKE LINKAGE PILLOW BLOCK. Lubricate with GAA through three fittings.

47. SERVICE BRAKE SHAFT. Lubricate with GAA through two fittings.

48. ACCELERATOR PEDAL ASSEMBLY, Lubricate with GAA through fitting.

49. SHIFTING CONTROL ASSEMBLY. Lubricate with GAA through two fittings.

50. SHIFTING LINKAGE PILLOW BLOCK. Lubricate with GAA through three fittings.

51. ACCELERATOR LINKAGE PILLOW BLOCK. Lubricate with GAA through two fittings.

52. MECHANICAL TRANSMISSION SHAFT UNIVERSAL JOINT, Remove front engine deck grille and lubricate universal joint with GAA through fitting. Install front engine deck grille,

53. MAIN ENGINE OIL FILTER. Remove front engine deck grille, Remove oil filter cover and remove elements, Discard removed elements and install new elements. Install oil filter cover and front

engine deck grille.

54. ARMY OIL ANALYSIS PROGRAM (AOAP) - MAIN ENGINE. For active units, obtain oil samples from engine every 25 hours of operation or 30 days (whichever comes first). Send these samples to nearest AOAP laboratory. Refer to TB 43-0210 for sampling instructions. If or when AOAP laboratory support is unavailable, hard-time intervals will apply.

55. TRANSMISSION DRAIN.

NOTE

- Drain oil only when hot after operation.
- New transmissions are filled with preservative oil which should be drained after 100 miles (or 10 hours) of operation. Refill with proper grade of lubricant (see table on card 14 and note 58). After 500 miles, again drain and fill.
- Periodically, a sample of oil shall be sent to the AOAP laboratory for analysis. Oil is to be drained at intervals determined by oil analysis. See note 54 and TB 43-0210 for details.
- When AOAP laboratory support is not available, drain and refill transmission oil at 1500 miles or semiannually.
- Coordinate any seasonal change of oil weight with this service.

Remove six bolts and six lockwashers that secure transmission drain plate to bottom of hull. Remove drain plate and gasket. Remove drain plug to drain transmission.

NOTE

If transmission is to be flushed, drain output reduction drives in accordance with note 63.

Clean drain plug with dry-cleaning solvent (SD-2). Install plug after transmission is fully drained. Fill transmission with lubricant (see note 58). Check that no O11 seeps around drain plug, and install gasket, drain plate and six attaching bolts and lockwashers

56. TRANSMISSION OIL FILTERS. Open rear engine deck grille exhaust deflector and grille. Remove left and right cover plates and remove four elements (two under each plate). Clean elements and covers with dry-cleaning solvent (SD-2). Install elements and install left and right covers. Close rear engine deck grille exhaust deflector and grille.

57. ARMY OIL ANALYSIS PROGRAM (AOAP) - TRANSMISSION. For active units, obtain oil samples from transmission every 25 hours of operation or 30 days (whichever comes first). Send these samples to the nearest AOAP laboratory. Refer to TB 43-0210 for sampling instructions. If or when AOAP laboratory support is unavailable, hard-time intervals will apply.

58. TRANSMISSION FILL AND LEVEL. Open rear engine deck

grille exhaust deflector and grille. Remove gage rod (dipstick) from transmission tube. Wipe rod, then reinsert it. Remove rod again. If oil shows on oil level gage, it is safe to start engine. If oil does not show on gage rod, add oil until visible on rod. Set vehicle parking brake. With shift selector set to neutral range, start engine. Allow engine to run at 1200 to 1600 rpm for 2 to 3 minutes.

WARNING

Transmission may be hot after operation. Use caution when reaching into engine/transmission compartment.

Stop engine. Wait 3 to 5 minutes; then check oil level again. Add or drain oil until oil level measures between ADD and FULL marks (see table on card 14 for capacity).

NOTE

If vehicle has been operating for a period of time sufficient to warm oil to 180°F to 200° F, oil level should be at, or above, FULL mark. This is a normal condition and is due to expansion of the oil.

Install oil gage rod and close rear engine deck grille exhaust deflector and grille.

59. MAIN ENGINE CRANKCASE DRAIN.

NOTE

- Drain oil only when hot after operation.
- Periodically, a sample of oil shall be sent to AOAP laboratory for analysis. Oil is to be drained at intervals determined by oil analysis. See note 54 and TB 43-0210 for details
- When AOAP laboratory support is not available, drain and refill engine oil at 1500 miles, 150 hours or semiannually if OE/HDO is used (750 miles, 75 hours if OEA is used).
- Coordinate any seasonal change of oil weight with this service.

Park vehicle on level ground. Remove oil cooler vent capscrew and open oil filter drain valve. Remove six screws and six lockwashers that secure engine drain plate to bottom of hull. Remove drain plate and gasket. Remove drain plug to drain engine. Clean drain plug with dry-cleaning solvent (SD-2). Install plug after engine is fully drained. Install oil cooler vent capscrew and close oil filter drain valve.

CAUTION

Before refilling, replace oil filter elements (note 53).

Refill crankcase (see note 60). Check that no oil seeps around drain plug. Install gasket, engine drain plate and six attaching bolts and lockwashers.

60. **MAIN ENGINE CRANKCASE FILL AND LEVEL** Raise engine deck door and access doors. Before starting engine, check OIL GAGE ROD (dipstick) to see that oil level is up to or above the ENGINE STOPPED SAFE TO START mark. If necessary, add oil (see table on card 14 for type) to bring level up to or above ENGINE STOPPED SAFE TO START mark before starting engine. Set parking brakes, and with selector lever in PARK position, start engine. Run engine 5 or 6 minutes at 1000 to 2000 rpm to warm engine oil to operating temperature. Reduce engine idle to 675 to 725 rpm. Add oil to bring level up to FULL mark on gage.

61. **FUEL TRANSFER PUMP** Raise engine grille doors and lubricate with GAA through fitting.

62. **BRAKE SLACK ADJUSTER LEVER** Remove six screws and six lockwashers which secure brake adjustment access cover to bottom of hull. Remove access cover and gasket. Lubricate brake slack adjuster lever with GAA through fitting. Install gasket, access cover and six screws and lockwashers. Repeat procedure for other side of vehicle.

63. **OUTPUT REDUCTION DRIVES—DRAIN**

NOTE

Each time transmission is drained, approximately five gallons of oil remain in each output reduction assembly. Drain this oil each time transmission is flushed.

Remove six screws and six lockwashers which secure brake adjustment access cover to bottom of hull. Remove access cover and gasket. Remove bolt located at bottom centerline of saddle mounting face (this is the same bolt that secures end of brake stop to assembly). After oil has drained, install bolt. Install gasket, access cover, and six screws and lockwashers. Repeat procedure for other side of vehicle.

64. **BRAKE AIR VALVE LINKAGE BRACKET** Open rear engine deck grille exhaust deflector and grille. Lubricate linkage with GAA through fitting. Close rear engine deck grille exhaust deflector and grille.

65. **ACCELERATOR LINKAGE BELL CRANK AND PILLOW BLOCK** Each time engine is removed, lubricate with GAA through bell crank fitting and two pillow block fittings.

66. **SERVICE BRAKE LINKAGE LEVER** Each time main engine is removed, lubricate lever with GAA through two fittings.

67. **SERVICE BRAKE LINKAGE SHAFT** Each time main engine is removed, lubricate shaft with GAA through fitting.

68. **SERVICE BRAKE LINKAGE BELL CRANK AND PILLOW BLOCKS** Each time main engine is removed, lubricate bell cranks through four fittings and lubricate pillow blocks through three fittings. Use GAA as lubricant.

69. **AUXILIARY POWER UNIT (APU) CHAINCASE DRAIN**

WARNING

APU engine is hot after operation. Use caution when reaching into the APU compartment.

NOTE

- Drain oil only when hot after operation.
- Coordinate any seasonal change of oil weight with this service.

Remove front engine deck grilles. Position container (1 quart minimum capacity) under chaincase drain plug to receive drained oil. Remove drain plug and clean it with dry-cleaning solvent (SD-2). After oil has drained, install drain plug. Fill chaincase in accordance with note 70. Install front engine deck grilles.

70. **AUXILIARY POWER UNIT (APU) CHAINCASE FILL AND LEVEL**

WARNING

APU engine is hot after operation. Use caution when reaching into the APU compartment. Do not check level of the oil until engine is cool.

Remove front engine deck grille. Remove filler plug. Check that oil level at fill hole reaches bottom of threads. If necessary, add oil to chaincase through fill hole until oil level reaches threads (see table on card 14 for required oil type and capacity). Install filler plug and install front engine deck grille.

71. **AUXILIARY POWER UNIT (APU) ENGINE OIL FILTER**

WARNING

APU engine is hot after operation. Use caution when reaching into APU compartment.

NOTE

Oil filter should be changed each time the APU engine crankcase oil is changed. Filter should be replaced more frequently when operating in extremely dusty environments.

Open right front engine grille door. Remove oil filter with a wrench, and discard filter. Lightly lubricate gasket of replacement filter and tighten it until gasket contacts base, then tighten filter an additional one-half turn.

NOTE

Do not overtighten filter.

Start APU engine (TM 9-2350-256-10) and check for oil leaks around filter gasket. Tighten filter as necessary if leakage occurs. Close right front engine grille door.

72. SERVICE BRAKE LINKAGE SHAFT. Each time main engine is removed, lubricate with GAA through fitting.

73. STEERING LINKAGE BELL CRANK. Each time main engine is removed, lubricate with GAA through five fittings.

74. SHIFTING LINKAGE BELL CRANK. Each time main engine is removed, lubricate with GAA through five fittings.

75. REAR BOOM LEVER CYLINDER PINS. Open engine grilles and remove stoplight plate. Lubricate with GAA through front fittings (accessible through grille) and rear fittings (through stoplight access)

76. AUXILIARY POWER UNIT (APU) CRANKCASE DRAIN.

WARNING

APU engine is hot after operation.
Use caution when reaching into APU compartment

NOTE

- Drain oil only when hot after operation
- Coordinate any seasonal change of 011 weight with this service.

Remove the six screws and six lockwashers which secure hull drain cover to bottom of hull. Remove drain plate. Open right front engine grille door. Open APU crankcase drain valve. When oil has drained from crankcase, close drain valve. Close right front engine grille door. Refill engine crankcase with proper grade of oil (see note 77 and table on card 14). Start APU engine (TM 9-2350 -256-10) and check for 011 leaks past drain valve (indicated by oil dripping from drain hose). If oil leak is present, double check that drain valve handle is closed securely. Notify organizational maintenance if leakage persists. Install engine drain cover at bottom of hull and install six lockwashers and screws.

77. AUXILIARY POWER UNIT (APU) CRANKCASE FILL AND LEVEL

WARNING

APU engine is hot after operation.
Use caution when reaching into the APU compartment

Open side APU access door. Remove bayonet gage and wipe it with a clean rag. Insert bayonet gage and remove it again. Observe the oil level indicated on the bayonet gage. If 011 level reads below full (F) mark, remove oil filler cap and add oil until level rises to full (F) mark (see key on card 14 for required oil type). Install bayonet gage and filler cap, and close side APU access door.

78. LUBRICATION AFTER FORDING OPERATIONS. As soon as possible after any fording operation in water of 12 inches or more, lubricate all chassis points to cleanse bearings of water or grit. Also lubricate any other points requiring maintenance after fording. If vehicle has been in deep water for a considerable length of time, or was submerged beyond its fording capabilities, the following precautions must be taken as soon as practicable to avoid damage to engine and other vehicle com-

ponents:

(a) Perform a complete lubrication service.

(b) Check auxiliary power unit, main engine and transmission for presence of water or sludge in oil. If found, drain and flush transmission with PE-1 Lubricating Oil, Internal Combustion engine, and drain and flush engines with OE-30 Lubricating Oil, Internal Combustion engine. If PE-1 is not available, flush transmission with OE-10, Lubricating Oil, Internal Combustion engine. Before refilling with clean oil, remove, clean and install transmission oil filters (see note 56). Replace engine oil filter elements (see note 53).

(c) Check lubricant in hydraulic reservoir and winch gear cases for evidence of water or sludge contamination. If there is evidence of contamination, drain and refill with correct lubricant.

79. OIL CAN POINTS. Monthly lubricate all pivot points, headlamp removal nut, 0.50-caliber machine gun mount traverse lock, side door lockpin, seat moving parts, engine throttle control linkage latches, grille door hinges and retaining bolts, pivot pins, boom lockpin, on-vehicle stowage clamps, vise turn screw, exhaust deflector pivot pin and hinges, snatch blocks, sheaves, and boom limit valve actuating arm shaft. Use Lubricating Oil, General Purpose, PL-S.

80. DO NOT LUBRICATE personnel heater motor, ventilating blower motor, auxiliary power unit air cleaner (see view CS).

81. LUBRICATE AT ASSEMBLY BY FIELD OR DEPOT MAINTENANCE UNITS starter, commander's cupola, fuel injector drive coupling, and driver's, rigger's and mechanic's hatch mechanisms (see view CT).

82. Copy of this lubrication order will remain with the equipment at all times; instructions contained herein are mandatory and supersede all conflicting lubrication instructions dated prior to this LO.

By Order of the Secretary of the Army:

JOHN A. WICKHAM, JR.
General, United States
Army Chief of Staff

MILDRED E. HEDBERG
Brigadier General, United States Army
The Adjutant General

Distribution shall be in accordance with DA Form 12-37 requirements for Recovery Vehicle, M88A1, Medium.

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN...JOT DOWN THE
DOPE ABOUT IT ON THIS FORM.
CAREFULLY TEAR IT OUT, FOLD IT
AND DROP IT IN THE MAIL.

SOMETHING WRONG WITH PUBLICATION

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT PIN-POINT WHERE IT IS

PAGE
NO.

PARA-
GRAPH

FIGURE
NO.

TABLE
NO.

IN THIS SPACE, TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT.

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

THE METRIC SYSTEM AND EQUIVALENTS

WEIGHT MEASURE

1 Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
 1 Kilometer = 1000 Meters = 0.621 Miles

WEIGHTS

1 Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces
 1 Kilogram = 1000 Grams = 2.2 lb.
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

SQUARE MEASURE

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches
 1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet
 1 Sq. Kilometer = 1,000,000 Sq. Meters = 0.386 Sq. Miles

CUBIC MEASURE

1 Cu. Centimeter = 1000 Cu. Millimeters = 0.06 Cu. Inches
 1 Cu. Meter = 1,000,000 Cu. Centimeters = 35.31 Cu. Feet

TEMPERATURE

$5/9(^{\circ}\text{F} - 32) = ^{\circ}\text{C}$
 212° Fahrenheit is equivalent to 100° Celsius
 90° Fahrenheit is equivalent to 32.2° Celsius
 32° Fahrenheit is equivalent to 0° Celsius
 $9/5^{\circ}\text{C} + 32 = ^{\circ}\text{F}$

APPROXIMATE CONVERSION FACTORS

TO CHANGE	TO	MULTIPLY BY
Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	0.914
Miles	Kilometers	1.609
Square Inches	Square Centimeters	6.451
Square Feet	Square Meters	0.093
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	0.405
Cubic Feet	Cubic Meters	0.028
Cubic Yards	Cubic Meters	0.765
Fluid Ounces	Milliliters	29.573
its	Liters	0.473
arts	Liters	0.946
allons	Liters	3.785
Ounces	Grams	28.349
Pounds	Kilograms	0.454
Short Tons	Metric Tons	0.907
Pound-Feet	Newton-Meters	1.356
Pounds per Square Inch	Kilopascals	6.895
Miles per Gallon	Kilometers per Liter	0.425
Miles per Hour	Kilometers per Hour	1.609

TO CHANGE	TO	MULTIPLY BY
Centimeters	Inches	0.394
Meters	Feet	3.280
Meters	Yards	1.094
Kilometers	Miles	0.621
Square Centimeters	Square Inches	0.155
Square Meters	Square Feet	10.764
Square Meters	Square Yards	1.196
Square Kilometers	Square Miles	0.386
Square Hectometers	Acres	2.471
Cubic Meters	Cubic Feet	35.315
Cubic Meters	Cubic Yards	1.308
Milliliters	Fluid Ounces	0.034
Liters	Pints	2.113
Liters	Quarts	1.057
ers	Gallons	0.264
ms	Ounces	0.035
ograms	Pounds	2.205
Metric Tons	Short Tons	1.102
Newton-Meters	Pounds-Feet	0.738
Kilopascals	Pounds per Square Inch	0.145
ometers per Liter	Miles per Gallon	2.354
ometers per Hour	Miles per Hour	0.621



PIN: 015351-001