
## **TECHNICAL MANUAL**

## **UNIT MAINTENANCE MANUAL**

## FOR

## CARRIER, CARGO TRACKED, 6–TON M548A1 2350–01–096–9356 (EIC AEU)

# M548A3 2350-01-369-6081 (EIC AE9)



<u>SUPERSEDURE NOTICE</u> — This manual supersedes TM 9–2350–247–20 dated August 1994, including all changes. DISTRIBUTION STATEMENT A — Approved for public release; distribution is unlimited.

# HEADQUARTERS, DEPARTMENT OF THE ARMY 30 June 2001

## WARNING SUMMARY

#### WARNING SUMMARY

This list summarizes critical WARNINGS in this manual. They are repeated here to let you know how important they are. Study these WARNINGS carefully; they can save your life and the lives of personnel with whom you work.



Energized system and equipment can burn you. If MASTER POWER SWITCH is ON, electrical system and equipment will be energized. Make sure MASTER POWER SWITCH is OFF when you work on electrical systems or equipment.

## WARNING



Failure to set the parking brake and block the road wheels can allow the carrier to move and could result in injury or death. Always set the parking brake and block road wheels before working on the carrier.

## WARNING



Battery post and cables touched by metal objects can short circuit and burn you. Gas from batteries can explode and injure you. Battery acid can blind you or burn you.

- Do not wear jewelry when you work on electrical systems.
- Use caution when you work near battery or electrical system with tools or other metal objects.
- Do not get acid on your skin or in your eyes.
- Do not allow sparks near batteries.

## WARNING SUMMARY (cont)

## WARNING



Heater and engine exhaust can kill or poison you. Close power plant access panel tight before you start engine. Do not run heater or engine indoors without very good fresh air flow. Keep power plant access cover closed when you run engine. Check for the smell of exhaust fumes. If you notice any fumes, open hatches and turn on vent fans.



Exhaust gases can make you ill or kill you. Signs of exhaust gas poison are dizziness, headache, loss of muscle control, sleepiness, coma, or death. If anyone shows signs of exhaust gas poisoning:

- (1) Get all personnel out of carrier.
- (2) Get medical help.
- (3) Make sure personnel have lots of fresh air.
- (4) Keep personnel warm.
- (5) Do not let anyone do hard exercise.

If anyone stops breathing, give artificial respiration.

### WARNING



Air pressure in excess of 30 psi (207 kpa) can injure personnel. Do not direct pressurized air at yourself or others. Always wear goggles.

#### WARNING



If you work on a carrier that has been running, you could be burned. All tasks begin with a cooled down carrier. Allow carrier to cool, or use care if you work on a hot carrier.

## WARNING SUMMARY (cont)



Unsafe use of chemical products can injure you. Read and follow warnings and instructions on labels of all chemical products. Follow all general shop safety procedures. See supervisor for further instructions on safety.



Portable and fixed fire extinguisher cylinders are under pressure and can discharge and injury you. Handle cylinders with care.



Hanging loads could kill or injure you. Keep away from hanging loads and overhead equipment. Keep hands away from pinch points. Keep hands out of engine compartment while power unit is being removed or installed.



Starting engine right after a fire could restart the fire and kill or injure you. Do not turn MASTER SWITCH ON until cause of fire has been repaired or removed.

## WARNING SUMMARY (cont)

## WARNING

|--|

Loctite sealing compound can damage your eyes. Before you handle loctite sealing compound, wear safety glasses/goggles and avoid contact with eyes. If it gets into your eyes, flush eyes with fresh water and get medical help.



Loose clothing is dangerous around moving belts and pulleys. You could get badly hurt if your clothes get caught in moving parts.



Hot radiator coolant can burn you. Use hand to remove cap ONLY if cool to touch. Turn cap slowly to release pressure. Replace cap by pressing down and turning until tight.



Radiator is heavy and can cause back injury if handled improperly. Be sure to use a hoist and helper to remove radiator.

## WARNING SUMMARY (cont)



Do not work under power plant. Power plant is heavy and may cause personnel and equipment damage if it falls. Lower power plant close to the ground before starting task.



Carbon Monoxide is poisonous and can kill you. Play it safe. Make sure power plant access covers and door are closed tight before you start engine. Do not idle engine with driver's power plant access panel off unless there is very good air flow.



Damaged lifting slings can fail with load. Soldiers can be killed or injured. Inspect all slings before use. Do not use damaged slings.



Do not touch exhaust pipes with bare hands. You could get a bad burn.

## WARNING SUMMARY (cont)

## WARNING



Gas from batteries can explode. Ventilate compartment before you disconnect of connect battery cables. Battery acid can burn or blind you. Do not get acid on your skin or eyes. ALWAYS disconnect battery negative leads first and connect them last.

# 

Lifting or moving objects in excess of 70 lb (32 kg) could injury you. Make sure to get an assistant or use a lifting device to move any heavy objects.

## WARNING



Chemical agent resistant coating (CARC) paint contains isocyanate (HDI) which is highly irritating to skin and respiratory system. High concentrations of HDI can produce symptoms of itching and reddening of skin, a burning sensation in throat and nose, and watering of the eyes. In extreme concentrations, HDI can cause cough, shortness of breath, pain during respiration, increased sputum production, and chest tightness. The following precautions must be taken whenever using CARC paint:

- ALWAYS use air line respirators when using CARC paint unless air sampling shows exposure to be below standards. Use chemical cartridge respirator if air sampling is below standards.
- DO NOT let skin or eyes come in contact with CARC paint. Always wear protective equipment (gloves, ventilation mask, safety goggles, etc.)
- DO NOT use CARC paint without adequate ventilation.
- NEVER weld or cut CARC-coated materials.
- DO NOT grind or sand painted equipment without high-efficiency air purifying respirators in use.
- BE AWARE of CARC paint exposure symptoms; symptoms can occur a few days after initial exposure. Seek medical help immediately if symptoms are detected.

## WARNING SUMMARY (cont)

# WARNING

Mixing of CARC paint must be done in a well-ventilated mixing room or spraying area away from open flame with personnel wearing eye protection. Paint is flammable and can cause injury or death to personnel.



Protective equipment (gloves, goggles, ventilation mask) must be worn when using CARC paint. DO NOT leave any skin exposed. Contact with CARC paint can cause skin burns.

# WARNING



High-efficiency air purifying respirators should be used when grinding or sanding CARC-coated equipment. Failure to do so may result in injury or death to personnel.



Carrier operation during hot weather may result in potential heat stress to crew members. Crew members should limit their exposure based on TB med 507 using PHEL Chart (WP 0542 00) curve as a guide.

## WARNING SUMMARY (cont)

## WARNING



Start up of equipment or moving parts could injure you or others. If other personnel are working on your carrier, be sure you know what they are doing. Place DO NOT OPERATE tags on MASTER SWITCH when needed to prevent startup.



Unsafe use of tools and equipment can injure you. Read and follow warnings and instructions on labels of all tools and equipment. Follow all general shop safety procedures. See unit commander for further instructions on safety.



Heat shield insulation may contain asbestos. Inhaled asbestos dust can cause permanent lung damage. Wear a filter mask approved for asbestos protection and rubber gloves during handling of asbestos. Wash skin and clothing with soap and water after handling asbestos. Dispose of asbestos material in accordance with approved hazardous waste disposal procedures.

## WARNING SUMMARY (cont)



HIGH VOLTAGE is used in the operation of this equipment.

DEATH ON CONTACT may result if personnel fail to observe safety precautions.

NEVER work on equipment unless at least one person familiar with the operation and hazards of the equipment is nearby. That person should also be competent in giving first aid. When an operator assists a technician, that operator must be warned about dangerous areas.

SHUT OFF POWER supply to equipment before beginning work. When working inside equipment with power off, take special care to ground every capacitor likely to hold a dangerous potential.

BE CAREFUL not to contact high-voltage connections when installing or operating this equipment.

KEEP one hand away from the equipment to reduce the hazard of current flowing through life-sustaining organs of the body.



Magnesium may catch on fire and burn you if welded on or if exposed to high temperatures. Do not weld on magnesium casings or expose them to high temperature. Be careful when filing or grinding magnesium. Use grinding equipment marked FOR MAGNESIUM ONLY. Keep a Class D fire extinguisher of a sodium chloride base dry powder to fight magnesium fires. Water and foam-type fire extinguisher will cause magnesium fires to flare up and create toxic fumes which can result is death.



Do not weld on plastic molding material (foam filled) parts. Welding on plastic molding material (foam filled) parts creates toxic fumes. Fumes are hazardous to your health and can result in death.

## WARNING SUMMARY (cont)



Do not wear jewelry. It can get caught and cause electrical burns or may cause electrocution.



Steam can splash back and burn you. Direct steam splash back away from you and others. Always wear full eye protection.



NBC agents can kill you. Do not service air cleaner or vent system after NBC attack until carrier has been decontaminated and filters disposed of by NBC team. Unit commander or officer in charge must assign NBC team to decontaminate system and dispose of filters. Unit commander of officer in charge must prescribe necessary protective clothing and safety measures for NBC team.



M548A3 requires both battery negative leads disconnected before maintenance. Each side provides power that may kill or injure personnel if both negative leads are not completely disconnected.

## WARNING SUMMARY (cont)



Failure to lock right and left steering levers (M548A1) or apply parking brake (M548A3) and block the road wheels can allow the carrier to move and could result in injury or death. Always lock right and left steering levers (M548A1) or apply parking brake (M548A3) and block road wheels before working on the carrier.



If road wheel lifters slips while lowering road arm, it could injure you. Stand clear before you lower or raise road arm.



Do not handle wire rope with bare hands. Broken wires can rip your hands open. Wear leather gloves when handling wire rope.

#### INSERT LATEST UPDATED PAGES / WORK PACKAGES. DESTROY SUPERSEDED DATA.

## LIST OF EFFECTIVE PAGES / WORK PACKAGES

NOTE: Updates to all portions of this TM are indicated by a vertical bar in the outer margin of the page.

Dates of issue for original and updated pages / work packages are:

Original 0 (30 June 2001)

# TOTAL NUMBER OF PAGES FOR FRONT AND REAR MATTER IS 80 AND TOTAL NUMBER OF WORK PACKAGES IS 146 CONSISTING OF THE FOLLOWING:

Page / WP No.	* Change No.	Page / WP No.	* Change No.	Page / WP No.	* Change No.
Title	0				
a – k/l blank	0				
A/B	0				
i — xxii	0				
WP 0001 00 - 0146 00	0				
1 – 47	0				
DA 2028 (3 copies)	0				
Authentication	0				
Back cover (Metric)	0				
Back Cover (PIN)	0				

\* Zero in this column indicates an original page or work package.

HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D.C., 30 June 2001

#### **TECHNICAL MANUAL**

#### UNIT MAINTENANCE MANUAL

CARRIER, CARGO TRACKED, 6-TON M548A1 NSN 2350-01-096-9356 (EIC AEU)

> M548A3 NSN 2350-01-369-6081 (EIC AE9)

#### **REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS**

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028–2 (Recommended Changes to Equipment Technical Publications), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <u>http://aeps.ria.army.mil</u>. If you need a password, scroll down and click on "ACCESS REQUEST FORM". The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax, or email your letter, DA Form 2028 or DA Form 2028–2 direct to: Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-LC-CIP—WT (Tech Pubs Control Point), Rock Island, IL 61299–7630. The email address is TACOM-TECH-PUBS@ria.army.mil . The fax number is DSN 793–0726 or Commercial (309) 782–0726.

SUPERSEDURE NOTICE — This manual supersedes TM 9-2350-247-20 dated 15 August 1994.

DISTRIBUTION STATEMENT A — Approved for public release; distribution is unlimited.

## TABLE OF CONTENTS

WP Sequence No.

## Volume 1

#### WARNING SUMMARY

HOW TO USE THIS MANUAL

CHAPTER 1 — UNIT INTRODUCTORY INFORMATION WITH THEORY OF OPERATION	
GENERAL INFORMATION	
EQUIPMENT DESCRIPTION	
THEORY OF OPERATION	
REPAIR PARTS, SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT	

CHAPTER 2 — UNIT TROUBLESHOOTING PROCEDURES

INTRODUCTION TO HOW TO USE TROUBLESHOOTING	0005.00
MALFUNCTION/SYMPTOM INDEX WP	
ENGINE OVERHEATS (M548A1)	
ENGINE OVERHEATS (M548A3)	
ENGINE WILL NOT REACH OPERATING TEMPERATURE	
ENGINE DOES NOT CRANK (M548A1)	
ENGINE DOES NOT CRANK (M548A3)	
ENGINE CRANKS SLOWLY (M548A1)	
ENGINE CRANKS SLOWLY (M548A3)	
ENGINE CRANKS BUT WILL NOT START	
ENGINE CRANKS BUT WILL NOT START BELOW 40°F (AIR BOX HEATER IS	
USED)	0015 00
ENGINE RUNS ROUGH, STALLS, OR DOES NOT PUT OUT FULL POWER	
(M548A1)	0016 00
ENGINE RUNS ROUGH, STALLS, OR DOES NOT PUT OUT FULL POWER	0015 00
(M548A3)	
ENGINE FUEL SYSTEM SCHEMATIC	
STARTING SYSTEM SCHEMATIC (M548A1)	
STARTING SYSTEM SCHEMATIC (M548A3)	
AIR BOX HEATER SYSTEM SCHEMATIC	
POWER TRAIN/STEERING/BRAKES/GEAR SELECTION/THROTTLE DIAGRAMS	
100 AMP CHARGING SYSTEM MALFUNCTIONS (M548A1)	
200 AMP CHARGING SYSTEM OPERATIONAL CHECK (M548A3)	
200 AMP NO CHARGE/REGULATION TROUBLESHOOTING (M548A3)	
200 AMP FULL FIELD CHARGE TROUBLESHOOTING (M548A3)	
200 AMP OVER VOLTAGE TROUBLESHOOTING (M548A3)	
CONNECT/DISCONNECT 200 AMP GENERATOR TEST KIT (M548A3)	
100 AMP ENGINE CHARGING SYSTEM SCHEMATIC (M548A1)	
200 AMP ENGINE CHARGING SYSTEM SCHEMATIC (M548A3)	
HI TEMP DIFF OIL INDICATOR COMES ON (M548A1)	
HI TEMP TRANS OIL INDICATOR COMES ON (M548A1)	
HI TEMP TRANS OIL INDICATOR COMES ON (M548A3)	
NO EXTERIOR LIGHTS OPERATE	
BLACKOUT DRIVE LIGHT DOES NOT WORK	
SERVICE HEADLIGHTS DO NOT OPERATE	
INFRARED HEADLIGHT(S) DOES NOT OPERATE	
SERVICE AND/OR BLACKOUT STOPLIGHTS MALFUNCTION	
BLACKOUT STOPLIGHT DOES NOT WORK	
BLACKOUT MARKER LIGHT(S) AND/OR TAILLIGHT(S) DO NOT OPERATE	
SERVICE TAILLIGHT DOES NOT OPERATE	
SERVICE STOPLIGHT DOES NOT WORK	
TRAILER LIGHTS DO NOT OPERATE	0043 00

HORN DOES NOT OPERATE	
INSTRUMENT PANEL ILLUMINATION LIGHTS MALFUNCTION	
LOW PRESS ENGINE OIL INDICATOR FAILS TO GO OFF AFTER ENGINE	
STARTS	0046 00
TRANS LOW OIL PRESS INDICATOR COMES ON (M548A3)	
DOME LIGHT WORKS IMPROPERLY	0048 00
MASTER SWITCH ON INDICATOR DOES NOT LIGHT	0049 00
FUEL LEVEL INDICATOR MALFUNCTIONS	
HIGH BEAM INDICATOR LIGHT MALFUNCTIONS	0051 00
BATTERY/GENERATOR INDICATOR MALFUNCTIONS	
COOLANT TEMPERATURE GAUGE MALFUNCTIONS	
LO PRESS ENGINE OIL INDICATOR MALFUNCTIONS	0054 00
TRANS LOW OIL PRESS INDICATOR MALFUNCTIONS (M548A3)	
HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A1)	0056 00
HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A3)	0057 00
HI TEMP DIFF OIL INDICATOR MALFUNCTIONS (M548A1)	
TRANS OIL HI DIFF PRESS INDICATOR MALFUNCTIONS (M548A3)	0059 00
WINDSHIELD WIPER DOES NOT OPERATE	
INSTRUMENT PANEL INDICATORS SCHEMATIC (M548A1)	
INSTRUMENT PANEL INDICATORS SCHEMATIC (M548A3) (SHEET 1 OF 2)	
INSTRUMENT PANEL INDICATORS SCHEMATIC (M548A3) (SHEET 2 OF 2)	0063 00
ELECTRICAL SYSTEM SCHEMATIC	0064 00
TURN SIGNAL LAMP, STOPLIGHT OR CONTROL LIGHT DOES NOT LIGHT OR FLASH WHEN CONTROL IS IN RIGHT OR LEFT TURN POSITION	
TURN SIGNAL LAMPS AND STOPLIGHTS DO NOT FLASH WITH CONTROL IN HAZARD POSITION	
IN LEFT OR RIGHT TURN SIGNAL POSITION, INDIVIDUAL LIGHT DOES NOT FLASH	
STEERING/BRAKES MALFUNCTION (M548A1)	
CARRIER DOES NOT MOVE IN ANY SHIFT LEVER POSITION (M548A1)	
TRANSMISSION SYSTEM SCHEMATIC (M548A3)	
CARRIER DOES NOT MOVE IN ANY SHIFT LEVER POSITION (M548A3)	0071 00
CARRIER DOES NOT PIVOT (M548A1)	
TRANSMISSION DOES NOT PIVOT STEER (M548A3)	
CARRIER MOVES WITH TRANSMISSION IN SL (M548A3)	
CARRIER DRIFTS OR DOES NOT STEER (M548A3)	0075 00
SERVICE AND/OR PARKING BRAKE WILL NOT HOLD CARRIER (M548A3)	
TRANSMISSION WILL NOT UPSHIFT OR SHIFTS ERRATICALLY IN 1-4 POSITION (M548A3)	
TRANSMISSION DOES NOT DOWNSHIFT IN 1-4 POSITION (M548A3)	
TRANSMISSION DOES NOT HOLD 1ST POSITION (M548A3)	0079 00
TRANSMISSION DOES NOT HOLD 2ND POSITION (M548A3)	0080 00

## TABLE OF CONTENTS (cont)

TRANSMISSION DOES NOT HOLD 3RD POSITION (M548A3)	
TRANSMISSION DOES NOT REVERSE (M548A3)	
BILGE PUMP SYSTEM SCHEMATIC	
FRONT BILGE PUMP AND/OR LIGHT DOES NOT OPERATE	0084 00
VEHICLE COMPARTMENT HEATER MALFUNCTIONS	0085 00
COOLANT HEATER MALFUNCTIONS	
SPEEDOMETER MALFUNCTIONS	0087 00
TACHOMETER MALFUNCTIONS	
WINCH CASE OVERHEATS (M548A1)	
WINCH DRUM DOES NOT TURN WITH DRUM CLUTCH IN "CLUTCH IN" POSITION (M548A1)	0090 00
WINCH DRUM DOES NOT TURN DRUM CLUTCH IN "CLUTCH OUT" POSITION (M548A1)	0091 00
WINCH BRAKE DOES NOT HOLD (M548A1)	
POWER TAKEOFF DOES NOT ENGAGE WHEN WINCH CONTROL IS ACTUATED (M548A1)	
EXCESSIVE OIL LEAKS (WINCH TRANSFER GEARCASE AND POWER	
TAKEOFF) (M548A1)	
WINCH PROPELLER SHAFT NOISY DURING OPERATION (M548A1)	
COMPRESSOR AIR OUTPUT ADEQUATE, BUT NO AIR PRESSURE INDICATION ON PANEL AIR BRAKE PRESSURE INDICATOR (M548A1)	0096 00
LOW AIR PRESSURE WARNING LIGHT DOES NOT LIGHT WHEN AIR PRESSURE FALLS BELOW 60 PSI (414 KPA) (M548A1)	0007.00
COMPRESSOR DOES NOT MAINTAIN AIR PRESSURE (M548A1)	
TOWED LOAD BRAKES DO NOT OPERATE WHEN PEDAL IS PRESSED; AIR	
PRESSURE ADEQUATE (M548A1)	
TOO MUCH OIL DRAINAGE FROM RESERVOIR DRAIN COCK (M548A1)	0100 00
TOO MUCH FOREIGN MATTER IN RESERVOIR (M548A1)	0101 00
COMPRESSOR OPERATION TOO NOISY (M548A1)	0102 00
PARTICULATE PRECLEANER MOTOR DOES NOT WORK (M548A3)	0103 00
M3 HEATER DOES NOT WORK (M548A3)	0104 00
NO AIR FLOW AT ONE OR MORE OUTLETS (M548A3)	0105 00
LOW AIR FLOW AT ALL OUTLETS (M548A3)	0106 00
INTRODUCTION STE/ICE–R (SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES-REPROGRAMMABLE) PROCEDURES	0107 00
STE/ICE-R CHARGING CIRCUIT TROUBLESHOOTING	0108 00
STE/ICE-R STARTER CIRCUIT TROUBLESHOOTING	0109 00
STE/ICE-R LOW OIL PRESSURE TROUBLESHOOTING	0110 00
STE/ICE-R BATTERY TROUBLESHOOTING	0111 00
STE/ICE-R ENGINE WILL NOT CRANK TROUBLESHOOTING	0112 00
STE/ICE-R ENGINE WILL CRANK BUT WILL NOT START TROUBLESHOOTING	0113 00
HOOK UP/REMOVE STE/ICE-R FOR POWER	0114 00
HOOK UP/REMOVE STE/ICE-R FOR ENGINE RPM	0115 00

## WP Sequence No.

	0116.00
HOOK UP/REMOVE STE/ICE-R FOR STARTER CIRCUIT TESTS HOOK UP/REMOVE STE/ICE-R TEST SET FOR TEST NUMBERS 72 THRU 75	
STE/ICE-R TEST 01 DISPLAY ENGINE RPM WITH NEXT MEASUREMENT	
STE/ICE-R TEST 01 DISPLAY ENGINE RPM WITH NEXT MEASUREMENT STE/ICE-R TEST 10 ENGINE RPM	
STE/ICE-R TEST 10 ENGINE RPM	
STE/ICE-R TEST 13 POWER (PERCENT) STE/ICE-R TEST 14 COMPRESSION UNBALANCE (POWER CABLE)	
STE/ICE-R TEST 67 BATTERY VOLTAGE	
STE/ICE-R TEST 72 STARTER CURRENT (FIRST PEAK)	0123 00
STE/ICE-R TEST 73 BATTERY RESISTANCE — STE/ICE-R TEST 75 BATTERY RESISTANCE CHANGE (PACK)	
STE/ICE-R TEST 74 STARTER CIRCUIT RESISTANCE	
STE/ICE-R TEST 90 DC CURRENT 0 TO 1500 AMP	
CHAPTER 3 — UNIT MAINTENANCE INSTRUCTIONS FOR PMCS INCLUDING LUBRICATION INSTRUCTIONS	
SERVICE UPON RECEIPT OF MATERIEL	0127 00
PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS), INCLUDING	
LUBRICATION INSTRUCTIONS	
MULTIPLE PIN AND SOCKET IDENTIFICATION	0129 00
CHAPTER 4 — UNIT MAINTENANCE INSTRUCTIONS FOR ENGINE	
REMOVE/INSTALL POWER PLANT (M548A1)	0130 00
REMOVE/INSTALL POWER PLANT (M548A3)	0131 00
BLOCK POWER PLANT (M548A1)	0132 00
BLOCK POWER PLANT (M548A3)	0133 00
REPLACE AIR BOX DRAIN AND CRANKCASE BREATHER COLLECTOR CAN	0134 00
REPLACE AIR BOX DRAIN TUBES (M548A1)	013500
REPLACE AIR BOX DRAIN CHECK VALVE AND TUBES (M548A3)	
REPLACE ENGINE CRANKCASE BREATHER HOSE	0137 00
REPLACE ENGINE OIL GAUGE ROD AND TUBE (M548A1)	0138 00
REPLACE ENGINE OIL GAUGE ROD AND TUBE (M548A3)	0139 00
REPLACE ENGINE OIL FILLER CAP AND TUBE	0140 00
REPLACE ENGINE OIL FILTER HOSES (M548A1)	0141 00
REPLACE ENGINE OIL FILTER ELEMENT HOSES AND FITTINGS (M548A3)	0142 00
REPLACE ENGINE OIL FILTER ELEMENT AND PARTS (M548A1)	0143 00
REPLACE ENGINE OIL FILTER ELEMENT AND COVER (M548A3)	
REPLACE ENGINE OIL FILTER ASSEMBLY (M548A1)	
REPLACE ENGINE OIL FILTER ASSEMBLY (M548A3)	014600

## Volume 2

CHAPTER 5 — UNIT MAINTENANCE INSTRUCTIONS FOR FUEL SYSTEM

## TABLE OF CONTENTS (cont)

ENGINE FUEL PUMP FLOW TEST	0147 00
SERVICE PERSONNEL HEATER FUEL PUMP/ELECTRIC FUEL PUMPS FLOW	
TEST	0148 00
REPLACE ENGINE FUEL PUMP (M548A1)	0149 00
REPLACE ENGINE FUEL PUMP (M548A3)	0150 00
REPLACE ELECTRIC FUEL PUMPS	0151 00
REPLACE AIR CLEANER AND ELEMENT (M548A1)	0152 00
REPLACE AIR CLEANER HOSE AND CLAMPS (M548A1)	0153 00
REPLACE AIR CLEANER FILTER INDICATOR ASSEMBLY (M548A1)	0154 00
SERVICE AIR CLEANER FILTER ELEMENT (M548A3)	0155 00
REPLACE AIR CLEANER FILTER ELEMENT (M548A3)	0156 00
REPLACE AIR CLEANER INDICATOR AND HOSE (M548A3)	0157 00
REPLACE AIR CLEANER DOOR GASKET (M548A3)	0158 00
REPLACE AIR CLEANER ASSEMBLY AND RELATED PARTS (M548A3)	0159 00
REPLACE AIR CLEANER EXHAUST CHECK VALVE AND EJECTOR TUBE	
(M548A3)	0160 00
REPLACE AIR CLEANER ELBOW AND INLET DUCT ASSEMBLIES (M548A3)	
DRAIN FUEL COMPARTMENT	0162 00
REMOVE/INSTALL FUEL COMPARTMENT ACCESS COVERS	0163 00
REPLACE FUEL FILLER CAP AND STRAINER	
REPLACE FUEL FILLER TUBES, HOSES, AND FITTINGS	0165 00
REPLACE FUEL COMPARTMENT TUBES, HOSES, AND FITTINGS (M548A3)	0166 00
REPLACE ENGINE TO BULKHEAD FUEL LINES AND FITTINGS (M548A1)	0167 00
REPLACE ENGINE TO BULKHEAD FUEL LINES AND FITTINGS (M548A3)	0168 00
REPLACE FUEL LEVEL TRANSMITTER	0169 00
REPLACE AIR SEPARATOR TANK (M548A1)	0170 00
REPLACE AIR SEPARATOR TANK (M548A3)	0171 00
REPLACE AIR SEPARATOR TO FUEL TANK TUBES, HOSES, AND FITTINGS (M548A1)	0172 00
REPLACE AIR SEPARATOR TO FUEL TANK TUBES, HOSES, AND FITTINGS	0172.00
(M548A3)	0173 00
REPLACE FUEL COMPARTMENT EXPANSION TANK VENT TUBES, HOSES,	
AND FITTINGS	
REPAIR FUEL COMPARTMENT EXPANSION CHAMBER (SEALING)	
REPLACE PRIMARY FUEL FILTER (M548A1)	
REPLACE SECONDARY FUEL FILTER (M548A1)	0177 00
REPLACE PRIMARY AND SECONDARY FUEL FILTERS/ELEMENTS (M548A3)	0178 00
REPLACE PRIMARY AND SECONDARY FUEL FILTER ELEMENTS (M548A1)	0179 00
REPLACE AIR BOX HEATER HOSES, TUBES, AND FITTINGS (M548A1)	0180 00
REPLACE AIR BOX HEATER HOSES, TUBES, AND FITTINGS (M548A3)	
REPLACE AIR BOX HEATER HARNESS AND IGNITER CABLE (M548A1)	0182 00
REPLACE AIR BOX HEATER HARNESS AND IGNITION CABLE (M548A3)	0183 00

REPLACE EXHAUST PIPE (M548A3) REPLACE EXHAUST DUCTS (M548A3)	
REPLACE EXHAUST PIPES (M548A1)	
REPLACE ENGINE EXHAUST PIPE GUARD (M548A1)	
REPLACE EXHAUST MUFFLER (M548A1) REPLACE EXHAUST MUFFLER (M548A3)	
CHAPTER 6 — UNIT MAINTENANCE INSTRUCTIONS FOR EXHAUST SYSTEM	0206.00
REPLACE FUEL CUTOFF CONTROL CABLE ASSEMBLY (M548A3)	
ADJUST THROTTLE VALVE (TV) MODULATOR (M548A3)	
REPLACE THROTTLE VALVE MODULATOR AND LEVER (M548A3)	
REPLACE FUEL CONTROL SHAFT AND LINKAGE (M548A3)	
REPLACE THROTTLE PEDAL CONTROL (M548A3)	
ADJUST ACCELERATOR LINKAGE (M548A3)	
(M548A1)	
ADJUST ENGINE GOVERNOR THROTTLE ARM (MJ48AT)	0198.00
ADJUST ENGINE GOVERNOR THROTTLE ARM (M548A1)	
REPLACE THROTTLE PEDAL CONTROL DETENT (M948A1)	
REPLACE THROTTLE PEDAL CONTROL/DETENT (M548A1)	
REPLACE FUEL CUTOFF HAND CONTROL (M548A1) ADJUST FUEL CUTOFF HAND CONTROL	
ADJUST HAND THROTTLE CONTROL CABLE	
REPLACE HAND THROTTLE CONTROL	
REPLACE AIR PUMP	
REPLACE AIR PUMP VANE KIT	
REPLACE AIR BOX HEATER (M548A1)	
REPLACE AIR BOX HEATER ELECTRODE (M548A3)	
REPLACE AIR BOX HEATER SOLENOID VALVE (M548A3)	
REPLACE AIR BOX HEATER SOLENOID VALVE (M548A1)	

REPLACE COOLANT TUBES, HOSES, AND FITTINGS (M548A3)	
REPLACE COOLANT PUMP (M548A1)	
REPLACE COOLANT PUMP (M548A3)	
REPLACE ENGINE COOLANT PUMP DRIVE BELTS AND IDLER PULLEY	
(M548A1)	
REPLACE COOLANT PUMP DRIVE BELTS (M548A3)	
REPLACE COOLANT PUMP IDLER PULLEY AND ADJUSTING BRACKET (M548A3)	0225 00
(M548A5) REPLACE FAN DRIVE BELTS (M548A1)	
REPLACE COOLING FAN DRIVE BELT (M548A3)	
REPLACE FAN DRIVE BELT IDLER PULLEY (M548A3)	
REPLACE COOLING FAN IDLER PULLEY (M548A3)	
REPLACE FAN DRIVE BELT IDLER ADJUSTING LINKAGE (M548A1)	
REPLACE FAN JACKSHAFT PULLEYS (M548A1)	
REPLACE COOLING FAN IDLER ARM (M548A3)	
REPLACE COOLING FAN IDLER ARM (MJ+0A3) REPLACE COOLING FAN IDLER ARM SUPPORT (M548A3)	
REPLACE FAN PULLEY (M548A1)	
REPLACE COOLING FAN (M548A1)	
REPLACE COOLING FAN AND PULLEY (M548A3)	
REPLACE DRIVE SHAFT LUBRICATION HOSE, FITTINGS, AND BEARINGS	
(M548A1)	
REPLACE COOLING FAN DRIVE HOUSING AND SHAFT (M548A3)	
REPLACE DRAIN CAP AND SIGHT GAUGE (M548A3)	
CHAPTER 8 — UNIT MAINTENANCE INSTRUCTIONS FOR ELECTRICAL SYSTEM	
REPLACE GENERATOR DRIVE BELTS (M548A1)	0240.00
ADJUST GENERATOR DRIVE BELTS (M548A1)	
REPLACE 100 AMP GENERATOR (M548A1)	
REPLACE GENERATOR DRIVE BELTS ADJUSTING LINKAGE (M548A1)	
REPLACE GENERATOR MOUNT (M548A1)	
REPLACE/ADJUST GENERATOR DRIVE BELT (M548A3)	
REPLACE GENERATOR (M548A3)	
REPLACE GENERATOR DRIVE BELT ADJUSTING LINKAGE (M548A3)	
REPLACE GENERATOR MOUNT (M548A3)	
ADJUST GENERATOR-REGULATOR	
REPLACE GENERATOR REGULATOR MOUNT (M548A1)	
REPLACE GENERATOR REGULATOR AND GROUND LEAD (M548A3)	
REPLACE GENERATOR REGULATOR MOUNT (M548A3)	
REPLACE STARTER (M548A1)	
REPLACE STARTER (M548A3)	
REPLACE STARTER RELAY (M548A3)	
REMOVE/INSTALL INSTRUMENT PANEL (PARTIAL)	

	1
REPLACE HIGH BEAM INDICATOR LIGHT	
REPLACE HIGH BEAM INDICATOR LIGHT BULB	
REPLACE HORN AND START SWITCHES	0259 00
REPLACE AIR BOX HEATER, TRANSMISSION-DIFFERENTIAL TEST, INFRARED-BLACKOUT SELECTOR OR WINDSHIELD WIPER SWITCHES	0260.00
REPLACE BILGE AND FUEL PUMP SWITCHES	
REPLACE BILGE AND FUEL PUMP SWITCHES REPLACE LIGHT SWITCH	
REPLACE LIGHT SWITCH REPLACE INFRARED-BLACKOUT SELECT SWITCH	
REPLACE PANEL LIGHTS	
REPLACE UTILITY OUTLET	
REPLACE OTHER TOOTLET	
TEMPERATURE GAUGE	0266 00
REPLACE CIRCUIT BREAKER	
REPLACE BILGE PUMP CIRCUIT BREAKER	0268 00
REPLACE GENERATOR-REGULATOR CIRCUIT BREAKER	0269 00
REPLACE MASTER SWITCH TO BUS BAR ELECTRICAL LEAD (M548A3)	
REPLACE MASTER SWITCH ASSEMBLY	
REPLACE ELECTRIC FUEL PUMP CIRCUIT BREAKERS (M548A3)	0272 00
REPLACE BEAM SELECTOR SWITCH	0273 00
REPLACE STOPLIGHT SWITCH	0274 00
REPLACE BLACKOUT HEADLIGHTS	0275 00
REPLACE SERVICE HEADLIGHTS	0276 00
REPLACE INFRARED HEADLIGHTS	0277 00
REPLACE STOPLIGHT-TAILLIGHTS	0278 00
REPLACE CAB DOME LIGHT	
REPLACE BLACKOUT MARKER LIGHT	
REPLACE ENGINE OIL LOW PRESSURE SWITCH (M548A1)	0281 00
REPLACE ENGINE LOW OIL PRESSURE TRANSMITTER (M548A3)	
REPLACE ENGINE COOLANT TEMPERATURE TRANSMITTER (M548A1)	
REPLACE ENGINE COOLANT TEMPERATURE TRANSMITTER (M548A3)	
REPLACE DIFFERENTIAL OIL HIGH TEMPERATURE THERMOSTATIC SWITCH	
(M548A1)	0285 00
REPLACE TRANSMISSION OIL HIGH TEMPERATURE THERMOSTATIC SWITCH (M548A1)	0286.00
REPLACE TRANSMISSION OIL HIGH TEMPERATURE SWITCH (M548A3)	
REPLACE GENERATOR FIELD SWITCH.	
REPLACE GENERATOR FIELD SWITCH	
REPLACE BATTERIES AND BATTERY COMPARTMENT (M548A1)	
REPLACE BATTERIS AND BATTERI COMPARTMENT (M548A1) REPLACE BATTERY COMPARTMENT BRACKET (M548A3)	
REPLACE BAITERT COMPARIMENT BRACKET (M348A3) REMOVE/INSTALL BATTERY NEGATIVE LEAD(S)	
REPLACE CARRIER BATTERIES (M548A3)	
REPLACE CARRIER DATTERIES (M348AS) REPAIR WIRING HARNESS	
NELAIN WININO HANNESS	0294 00

## TABLE OF CONTENTS (cont)

REPLACE GENERATOR-TO-REGULATOR WIRING HARNESS (M548A1)	0295.00
REPLACE GENERATOR TO REGULATOR WIRING HARNESS (M548A3)	
REPLACE TRANSMISSION WIRING HARNESS (M548A3)	
REPLACE POWER PLANT WIRING HARNESS (M548A3)	
REPLACE BATTERY TO REGULATOR CABLE JACK (M548A3)	
REPLACE ENGINE GROUND LEAD (M548A3)	
REPLACE TRAILER WIRING HARNESS	
REPLACE FUEL PUMP WIRING HARNESS (M548A3)	
REPLACE AUXILIARY POWER (SLAVE) RECEPTACLE	
CHAPTER 9 — UNIT MAINTENANCE INSTRUCTIONS FOR TRANSMISSION	
REPLACE TRANSMISSION VENT TUBE, GAUGE ROD, AND FILLER NECK (M548A1)	0304 00
REPLACE TRANSMISSION OIL LEVEL GAUGE ROD, FILLER TUBE, AND	
ADAPTER (M548A3)	
REPLACE TRANSMISSION SHIFT CONTROL (M548A3)	
REPLACE TRANSMISSION SHIFT CONTROL LAMP (M548A3)	0307 00
REPLACE NEUTRAL START SWITCH	0308 00
REPLACE TRANSMISSION SHIFT CONTROL SWITCH (M548A3)	0309 00
REPLACE TOW START CABLE/COVER (M548A3)	
ADJUST TOW START CONTROL CABLE ASSEMBLY (M548A3)	0311 00
ADJUST TRANSMISSION STEERING (M548A3)	0312 00
CHECK TRANSMISSION BRAKE ADJUSTMENT (M548A3)	0313 00
ADJUST TRANSMISSION BRAKES (M548A3)	0314 00
REPLACE TRANSMISSION RANGE SELECTOR LINKAGE (M548A1)	0315 00
ADJUST TRANSMISSION RANGE SELECTOR CONTROL AND LINKAGE (M548A1)	0316 00
REPLACE GOVERNOR ASSEMBLY (M548A3)	0317 00
REPLACE TRANSMISSION OIL HOSES AND FITTINGS (M548A1)	0318 00
REPLACE TRANSMISSION OIL HOSES AND FITTINGS (M548A3)	0319 00
REPLACE TRANSMISSION OIL FILTER ELEMENT (M548A1)	0320 00
REPLACE TRANSMISSION OIL FILTER ELEMENT (M548A3)	0321 00
REPLACE TRANSMISSION AOAP VALVE, HOSE, AND BRACKET (M548A1)	0322 00
REPLACE TRANSMISSION OIL SAMPLING VALVE, GUARD, AND PRESSURE	0222.00
SWITCH (M548A3) REPLACE DIFFERENTIAL PRESSURE SWITCH AND BYPASS PLUG (M548A3)	
REPLACE DIFFERENTIAL PRESSURE SWITCH AND BIFASS PLUG (M548A3)	0324 00
CHAPTER 10 — UNIT MAINTENANCE INSTRUCTIONS FOR TRANSFER GEARCASE FINAL DRIVE	
REPLACE TRANSFER GEARCASE MOUNTS (M548A1)	0325 00
REPLACE FINAL DRIVE	0326 00
REPLACE FINAL DRIVE PINION OIL SEAL	0327 00
REPLACE FINAL DRIVE GAUGE ROD	0328 00

## TABLE OF CONTENTS (cont)

WP Sequence No.           REPLACE FINAL DRIVE VENT, FILLER TUBE, AND FITTINGS (RIGHT SIDE)	TABLE OF CONTENTS (cont)	
REPLACE FINAL DRIVE VENT, FILLER TUBE, AND FITTINGS (LEFT SIDE)       .033000         REPLACE TRANSFER GEARCASE OIL LEVEL GAUGE ROD AND FILLER NECK       .0331 00         CHAPTER 11 — UNIT MAINTENANCE INSTRUCTIONS FOR PROPELLER SHAFTS AND       .0331 00         REPLACE TRANSMISSION-TO-DIFFERENTIAL SHAFT (M548A1)       .0332 00         REPLACE TRANSMISSION-TO-DIFFERENTIAL SHAFT (M548A1)       .0333 00         REPLACE RIGHT FINAL DRIVE SHAFT (M548A1)       .0333 00         REPLACE FINAL DRIVE SHAFT (M548A1)       .0335 00         CHAPTER 12 — UNIT MAINTENANCE INSTRUCTIONS FOR DIFFERENTIAL-RELATED COMPONENTS (M548A1)       .0336 00         REPLACE DIFFERENTIAL OIL PUMP (M548A1)       .0336 00         REPLACE DIFFERENTIAL OIL PUMP (M548A1)       .0337 00         REPLACE DIFFERENTIAL OIL FILTER AND OIL FILTER ELEMENT (M548A1)       .0338 00         REPLACE DIFFERENTIAL OIL LEVEL GAUGE ROD (M548A1)       .0338 00         REPLACE DIFFERENTIAL OIL LEVEL GAUGE ROD (M548A1)       .0334 00         REPLACE DIFFERENTIAL OIL LEVEL GAUGE ROD (M548A1)       .0340 00         ADJUST DIFFERENTIAL BRAKES (M548A1)       .0342 00         REPLACE DIFFERENTIAL OIL LEVEL (GM548A1)       .0344 00         CHAPTER 13 — UNIT MAINTENANCE INSTRUCTIONS FOR BRAKES       .0345 00         ADJUST PARKING BRAKE (M548A3)       .0345 00         REPLACE DIFFERENTIAL GASKET (M548A1)       .0346		WP Sequence No.
REPLACE TRANSFER GEARCASE OIL LEVEL GAUGE ROD AND FILLER NECK (M548A1).	REPLACE FINAL DRIVE VENT, FILLER TUBE, AND FITTINGS (RIGHT SIDE)	
(M548A1)	REPLACE FINAL DRIVE VENT, FILLER TUBE, AND FITTINGS (LEFT SIDE)	033000
CHAPTER 11 — UNIT MAINTENANCE INSTRUCTIONS FOR PROPEILIER SHAFTS AND UNIVERSAL JOINTS REPLACE TRANSMISSION-TO-DIFFERENTIAL SHAFT (M548A1)	REPLACE TRANSFER GEARCASE OIL LEVEL GAUGE ROD AND FILLER NECK	
UNIVERSAL JOINTS REPLACE TRANSMISSION-TO-DIFFERENTIAL SHAFT (M548A1)	(M548A1)	
REPLACE TRANSMISSION-TO-DIFFERENTIAL SHAFT (M548A1).       .0332 00         REPLACE LEFT FINAL DRIVE SHAFT (M548A1).       .0333 00         REPLACE RIGHT FINAL DRIVE SHAFT (M548A1).       .0333 00         REPLACE FINAL DRIVE SHAFTS (M548A3).       .0335 00         CHAPTER 12 — UNIT MAINTENANCE INSTRUCTIONS FOR DIFFERENTIAL-RELATED COMPONENTS (M548A1).       .0336 00         REPLACE DIFFERENTIAL OIL PUMP (M548A1).       .0336 00         REPLACE DIFFERENTIAL OIL FILTER AND OIL FILTER ELEMENT (M548A1).       .0337 00         REPLACE DIFFERENTIAL OIL FILTER AND OIL FILTER ELEMENT (M548A1).       .0338 00         REPLACE DIFFERENTIAL OIL LEVEL GAUGE ROD (M548A1).       .0340 00         ADJUST DIFFERENTIAL OIL LEVEL GAUGE ROD (M548A1).       .0341 00         REPLACE DIFFERENTIAL OIL LEVEL (M548A1).       .0341 00         REPLACE DIFFERENTIAL SWITCH LEAD (M548A1).       .0343 00         REPLACE DIFFERENTIAL SWITCH LEAD (M548A1).       .0344 00         CHAPTER 13 — UNIT MAINTENANCE INSTRUCTIONS FOR BRAKES       .0345 00         ADJUST PARKING BRAKE (M548A3).       .0347 00         REPLACE DIFFERENTIAL SWITCH LEVER/CABLE ASSEMBLY (M548A3).       .0347 00         REPLACE DIFFERENTIAL SWITCH LEVER/CABLE ASSEMBLY (M548A3).       .0346 00         ODJUST BRAKE CONTROL LINKAGE (M548A3).       .0347 00         REPLACE DIFFERENTIAL COLLINKAGE (M548A3).       .0345 00 <td>CHAPTER 11 — UNIT MAINTENANCE INSTRUCTIONS FOR PROPELLER SHAFTS AND</td> <td></td>	CHAPTER 11 — UNIT MAINTENANCE INSTRUCTIONS FOR PROPELLER SHAFTS AND	
REPLACE LEFT FINAL DRIVE SHAFT (M548A1).       .0333 00         REPLACE RIGHT FINAL DRIVE SHAFT (M548A1).       .0334 00         REPLACE RIGHT FINAL DRIVE SHAFT (M548A1).       .0335 00         CHAPTER 12	UNIVERSAL JOINTS	
REPLACE RIGHT FINAL DRIVE SHAFT (M548A1).       .0334 00         REPLACE FINAL DRIVE SHAFTS (M548A3).       .0335 00         CHAPTER 12 — UNIT MAINTENANCE INSTRUCTIONS FOR DIFFERENTIAL-RELATED COMPONENTS (M548A1)       .0336 00         REPLACE DIFFERENTIAL OIL PUMP (M548A1).       .0336 00         REPLACE DIFFERENTIAL OIL PUMP (M548A1).       .0337 00         REPLACE DIFFERENTIAL BREATHER (M548A1).       .0338 00         REPLACE DIFFERENTIAL OIL LEVEL GAUGE ROD (M548A1).       .0338 00         REPLACE DIFFERENTIAL OIL HOSES AND FITTINGS (M548A1).       .0340 00         ADJUST DIFFERENTIAL BREATHER (M548A1).       .0341 00         REPLACE DIFFERENTIAL SUTCH LEAD (M548A1).       .0344 00         REPLACE DIFFERENTIAL GASKET (M548A1).       .0344 00         REPLACE DIFFERENTIAL GASKET (M548A1).       .0344 00         CHAPTER 13 — UNIT MAINTENANCE INSTRUCTIONS FOR BRAKES       .0345 00         ADJUST PARKING BRAKE (M548A3).       .0345 00         REPLACE BRAKE CONTROL LINKAGE (M548A3).       .0346 00         ADJUST BRAKE CONTROL LINKAGE (M548A3).       .0346 00         CHAPTER 14 — UNIT MAINTENANCE INSTRUCTIONS FOR WHEELS AND TRACKS	REPLACE TRANSMISSION-TO-DIFFERENTIAL SHAFT (M548A1)	
REPLACE FINAL DRIVE SHAFTS (M548A3)	REPLACE LEFT FINAL DRIVE SHAFT (M548A1)	0333 00
CHAPTER 12 — UNIT MAINTENANCE INSTRUCTIONS FOR DIFFERENTIAL-RELATED COMPONENTS (M548A1) REPLACE DIFFERENTIAL OIL PUMP (M548A1)	REPLACE RIGHT FINAL DRIVE SHAFT (M548A1)	0334 00
COMPONENTS (M548A1) REPLACE DIFFERENTIAL OIL PUMP (M548A1)	REPLACE FINAL DRIVE SHAFTS (M548A3)	
REPLACE DIFFERENTIAL OIL FILTER AND OIL FILTER ELEMENT (M548A1).       .0337 00         REPLACE DIFFERENTIAL BREATHER (M548A1).       .0338 00         REPLACE DIFFERENTIAL OIL LEVEL GAUGE ROD (M548A1).       .0339 00         REPLACE DIFFERENTIAL OIL HOSES AND FITTINGS (M548A1).       .0340 00         ADJUST DIFFERENTIAL BRAKES (M548A1).       .0341 00         REPLACE DIFFERENTIAL AND MOUNTS (M548A1).       .0342 00         REPLACE DIFFERENTIAL SWITCH LEAD (M548A1).       .0343 00         REPLACE DIFFERENTIAL GASKET (M548A1).       .0343 00         REPLACE DIFFERENTIAL GASKET (M548A1).       .0344 00         CHAPTER 13 — UNIT MAINTENANCE INSTRUCTIONS FOR BRAKES       .0345 00         REPLACE PARKING BRAKE (M548A3).       .0345 00         REPLACE PARKING BRAKE CONTROL LEVER/CABLE ASSEMBLY (M548A3).       .0346 00         ADJUST BRAKE CONTROL LINKAGE (M548A3).       .0347 00         REPLACE BRAKE CONTROL LINKAGE (M548A3).       .0349 00         REPLACE TORSION BAR       .0349 00         REPLACE TORSION BAR ANCHOR.       .0350 00         REPLACE ROAD WHEEL SUPPORT ARM, HOUSING, BEARINGS, AND SEALS.       .0351 00         REPLACE ROAD WHEEL SUPPORT ARM BUMPER STOP/SUPPORT.       .0353 00         REPLACE ROAD WHEEL ARM ASSEMBLY.       .0354 00         REPLACE TRACK TENSION ADJUSTER AND MOUNT.       .0356 00		
REPLACE DIFFERENTIAL BREATHER (M548A1)       .0338 00         REPLACE DIFFERENTIAL OIL LEVEL GAUGE ROD (M548A1)       .0339 00         REPLACE DIFFERENTIAL OIL HOSES AND FITTINGS (M548A1)       .0340 00         ADJUST DIFFERENTIAL BRAKES (M548A1)       .0341 00         REPLACE DIFFERENTIAL AND MOUNTS (M548A1)       .0342 00         REPLACE DIFFERENTIAL AND MOUNTS (M548A1)       .0343 00         REPLACE DIFFERENTIAL SWITCH LEAD (M548A1)       .0343 00         REPLACE DIFFERENTIAL GASKET (M548A1)       .0344 00         CHAPTER 13 — UNIT MAINTENANCE INSTRUCTIONS FOR BRAKES       .0345 00         REPLACE PARKING BRAKE (M548A3)       .0345 00         REPLACE PARKING BRAKE CONTROL LEVER/CABLE ASSEMBLY (M548A3)       .0346 00         ADJUST BRAKE CONTROL LINKAGE (M548A3)       .0347 00         REPLACE BRAKE CONTROL LINKAGE (M548A3)       .0348 00         CHAPTER 14 — UNIT MAINTENANCE INSTRUCTIONS FOR WHEELS AND TRACKS         REPLACE TORSION BAR       .0349 00         REPLACE TORSION BAR ANCHOR       .0350 00         REPLACE ROAD WHEEL SUPPORT ARM, HOUSING, BEARINGS, AND SEALS       .0351 00         REPLACE ROAD WHEEL SUPPORT ARM BUMPER STOP/SUPPORT       .0353 00         REPLACE ROAD WHEEL HUB/BEARINGS AND SEALS       .0355 00         REPLACE TRACK TENSION ADJUSTER AND MOUNT       .0356 00         REPLACE TRA	REPLACE DIFFERENTIAL OIL PUMP (M548A1)	
REPLACE DIFFERENTIAL OIL LEVEL GAUGE ROD (M548A1)       .0339 00         REPLACE DIFFERENTIAL OIL HOSES AND FITTINGS (M548A1)       .0340 00         Adjust DIFFERENTIAL BRAKES (M548A1)       .0341 00         REPLACE DIFFERENTIAL AND MOUNTS (M548A1)       .0342 00         REPLACE DIFFERENTIAL SWITCH LEAD (M548A1)       .0343 00         REPLACE DIFFERENTIAL SWITCH LEAD (M548A1)       .0343 00         REPLACE DIFFERENTIAL GASKET (M548A1)       .0344 00         CHAPTER 13 — UNIT MAINTENANCE INSTRUCTIONS FOR BRAKES       .0345 00         REPLACE PARKING BRAKE (M548A3)       .0345 00         REPLACE PARKING BRAKE CONTROL LEVER/CABLE ASSEMBLY (M548A3)       .0346 00         ADJUST BRAKE CONTROL LINKAGE (M548A3)       .0347 00         REPLACE BRAKE CONTROL LINKAGE (M548A3)       .0348 00         CHAPTER 14 — UNIT MAINTENANCE INSTRUCTIONS FOR WHEELS AND TRACKS       .0349 00         REPLACE TORSION BAR       .0349 00         REPLACE TORSION BAR       .0350 00         REPLACE TORSION BAR ANCHOR       .0352 00         REPLACE ROAD WHEEL SUPPORT ARM, HOUSING, BEARINGS, AND SEALS       .0351 00         REPLACE ROAD WHEEL HUB       .0352 00         REPLACE IDLER WHEEL HUB/BEARINGS AND SEALS       .0355 00         REPLACE TRACK TENSION ADJUSTER AND MOUNT       .0356 00         REPLACE TRACK TENSION ADJUSTER A	REPLACE DIFFERENTIAL OIL FILTER AND OIL FILTER ELEMENT (M548A1)	
REPLACE DIFFERENTIAL OIL HOSES AND FITTINGS (M548A1)	REPLACE DIFFERENTIAL BREATHER (M548A1)	
ADJUST DIFFERENTIAL BRAKES (M548A1)	REPLACE DIFFERENTIAL OIL LEVEL GAUGE ROD (M548A1)	
REPLACE DIFFERENTIAL AND MOUNTS (M548A1).0342 00REPLACE DIFFERENTIAL SWITCH LEAD (M548A1).0343 00REPLACE DIFFERENTIAL GASKET (M548A1).0344 00CHAPTER 13 — UNIT MAINTENANCE INSTRUCTIONS FOR BRAKES0345 00ADJUST PARKING BRAKE (M548A3).0345 00REPLACE PARKING BRAKE CONTROL LEVER/CABLE ASSEMBLY (M548A3).0346 00ADJUST BRAKE CONTROL LINKAGE (M548A3).0347 00REPLACE BRAKE CONTROL LINKAGE (M548A3).0348 00CHAPTER 14 — UNIT MAINTENANCE INSTRUCTIONS FOR WHEELS AND TRACKS0349 00REPLACE TORSION BAR.0350 00REPLACE TORSION BAR ANCHOR.0350 00REPLACE ROAD WHEEL SUPPORT ARM, HOUSING, BEARINGS, AND SEALS.0351 00REPLACE ROAD WHEEL SUPPORT ARM BUMPER STOP/SUPPORT.0353 00REPLACE IDLER WHEEL ARM ASSEMBLY.0355 00REPLACE IDLER WHEEL ARM ASSEMBLY.0355 00REPLACE TRACK TENSION ADJUSTER AND MOUNT.0356 00REPLACE TRACK TENSION ADJUSTER AND MOUNT.0356 00REPLACE TRACK SHOE AND PAD ASSEMBLY.0357 00REPLACE TRACK SHOE AND PAD ASSEMBLY.0359 00	REPLACE DIFFERENTIAL OIL HOSES AND FITTINGS (M548A1)	
REPLACE DIFFERENTIAL SWITCH LEAD (M548A1)0343 00REPLACE DIFFERENTIAL GASKET (M548A1)0344 00CHAPTER 13 — UNIT MAINTENANCE INSTRUCTIONS FOR BRAKES.0345 00REPLACE PARKING BRAKE (M548A3)0345 00REPLACE PARKING BRAKE CONTROL LEVER/CABLE ASSEMBLY (M548A3)0346 00ADJUST BRAKE CONTROL LINKAGE (M548A3)0347 00REPLACE BRAKE CONTROL LINKAGE (M548A3)0348 00CHAPTER 14 — UNIT MAINTENANCE INSTRUCTIONS FOR WHEELS AND TRACKS.0349 00REPLACE TORSION BAR0349 00REPLACE TORSION BAR0350 00REPLACE TORSION BAR ANCHOR0350 00REPLACE ROAD WHEEL SUPPORT ARM, HOUSING, BEARINGS, AND SEALS0351 00REPLACE ROAD WHEEL SUPPORT ARM BUMPER STOP/SUPPORT0353 00REPLACE IDLER WHEEL ARM ASSEMBLY0354 00REPLACE IDLER WHEEL ARM ASSEMBLY0355 00REPLACE TRACK TENSION ADJUSTER AND MOUNT0356 00REPLACE TRACK TENSION ADJUSTER AND MOUNT0356 00REPLACE TRACK TENSION ADJUSTER AND MOUNT0358 00REPLACE TRACK SHOE AND PAD ASSEMBLY0359 00	ADJUST DIFFERENTIAL BRAKES (M548A1)	
REPLACE DIFFERENTIAL GASKET (M548A1)	REPLACE DIFFERENTIAL AND MOUNTS (M548A1)	
CHAPTER 13 — UNIT MAINTENANCE INSTRUCTIONS FOR BRAKES ADJUST PARKING BRAKE (M548A3)	REPLACE DIFFERENTIAL SWITCH LEAD (M548A1)	
ADJUST PARKING BRAKE (M548A3)	REPLACE DIFFERENTIAL GASKET (M548A1)	0344 00
REPLACE PARKING BRAKE CONTROL LEVER/CABLE ASSEMBLY (M548A3)	CHAPTER 13 — UNIT MAINTENANCE INSTRUCTIONS FOR BRAKES	
ADJUST BRAKE CONTROL LINKAGE (M548A3)	ADJUST PARKING BRAKE (M548A3)	0345 00
REPLACE BRAKE CONTROL LINKAGE (M548A3)	REPLACE PARKING BRAKE CONTROL LEVER/CABLE ASSEMBLY (M548A3)	0346 00
CHAPTER 14 — UNIT MAINTENANCE INSTRUCTIONS FOR WHEELS AND TRACKSREPLACE TORSION BAR.0349 00REPLACE TORSION BAR ANCHOR0350 00REPLACE ROAD WHEEL SUPPORT ARM, HOUSING, BEARINGS, AND SEALS0351 00REPLACE ROAD WHEEL HUB0352 00REPLACE ROAD WHEEL SUPPORT ARM BUMPER STOP/SUPPORT0353 00REPLACE IDLER WHEEL ARM ASSEMBLY0354 00REPLACE IDLER WHEEL HUB/BEARINGS AND SEALS0355 00REPLACE IDLER WHEEL HUB/BEARINGS AND SEALS0355 00REPLACE TRACK TENSION ADJUSTER AND MOUNT0356 00REPLACE DRIVE SPROCKETS, CUSHIONS, AND CARRIER ASSEMBLY0357 00REPLACE TRACK0358 00REPLACE TRACK SHOE AND PAD ASSEMBLY0359 00	ADJUST BRAKE CONTROL LINKAGE (M548A3)	
REPLACE TORSION BAR.0349 00REPLACE TORSION BAR ANCHOR.0350 00REPLACE ROAD WHEEL SUPPORT ARM, HOUSING, BEARINGS, AND SEALS.0351 00REPLACE ROAD WHEEL HUB.0352 00REPLACE ROAD WHEEL SUPPORT ARM BUMPER STOP/SUPPORT.0353 00REPLACE IDLER WHEEL ARM ASSEMBLY.0354 00REPLACE IDLER WHEEL HUB/BEARINGS AND SEALS.0355 00REPLACE TRACK TENSION ADJUSTER AND MOUNT.0356 00REPLACE DRIVE SPROCKETS, CUSHIONS, AND CARRIER ASSEMBLY.0358 00REPLACE TRACK SHOE AND PAD ASSEMBLY.0359 00	REPLACE BRAKE CONTROL LINKAGE (M548A3)	
REPLACE TORSION BAR ANCHOR0350 00REPLACE ROAD WHEEL SUPPORT ARM, HOUSING, BEARINGS, AND SEALS0351 00REPLACE ROAD WHEEL HUB0352 00REPLACE ROAD WHEEL SUPPORT ARM BUMPER STOP/SUPPORT0353 00REPLACE IDLER WHEEL ARM ASSEMBLY0354 00REPLACE IDLER WHEEL HUB/BEARINGS AND SEALS0355 00REPLACE TRACK TENSION ADJUSTER AND MOUNT0356 00REPLACE DRIVE SPROCKETS, CUSHIONS, AND CARRIER ASSEMBLY0357 00REPLACE TRACK0358 00REPLACE TRACK SHOE AND PAD ASSEMBLY0359 00	CHAPTER 14 — UNIT MAINTENANCE INSTRUCTIONS FOR WHEELS AND TRACKS	
REPLACE ROAD WHEEL SUPPORT ARM, HOUSING, BEARINGS, AND SEALS0351 00REPLACE ROAD WHEEL HUB0352 00REPLACE ROAD WHEEL SUPPORT ARM BUMPER STOP/SUPPORT0353 00REPLACE IDLER WHEEL ARM ASSEMBLY0354 00REPLACE IDLER WHEEL HUB/BEARINGS AND SEALS0355 00REPLACE TRACK TENSION ADJUSTER AND MOUNT0356 00REPLACE DRIVE SPROCKETS, CUSHIONS, AND CARRIER ASSEMBLY0357 00REPLACE TRACK0358 00REPLACE TRACK SHOE AND PAD ASSEMBLY0359 00	REPLACE TORSION BAR	0349 00
REPLACE ROAD WHEEL HUB0352 00REPLACE ROAD WHEEL SUPPORT ARM BUMPER STOP/SUPPORT0353 00REPLACE IDLER WHEEL ARM ASSEMBLY0354 00REPLACE IDLER WHEEL HUB/BEARINGS AND SEALS0355 00REPLACE TRACK TENSION ADJUSTER AND MOUNT0356 00REPLACE DRIVE SPROCKETS, CUSHIONS, AND CARRIER ASSEMBLY0357 00REPLACE TRACK0358 00REPLACE TRACK SHOE AND PAD ASSEMBLY0359 00	REPLACE TORSION BAR ANCHOR	
REPLACE ROAD WHEEL SUPPORT ARM BUMPER STOP/SUPPORT0353 00REPLACE IDLER WHEEL ARM ASSEMBLY0354 00REPLACE IDLER WHEEL HUB/BEARINGS AND SEALS0355 00REPLACE TRACK TENSION ADJUSTER AND MOUNT0356 00REPLACE DRIVE SPROCKETS, CUSHIONS, AND CARRIER ASSEMBLY0357 00REPLACE TRACK0358 00REPLACE TRACK SHOE AND PAD ASSEMBLY0359 00	REPLACE ROAD WHEEL SUPPORT ARM, HOUSING, BEARINGS, AND SEALS	0351 00
REPLACE IDLER WHEEL ARM ASSEMBLY	REPLACE ROAD WHEEL HUB	
REPLACE IDLER WHEEL HUB/BEARINGS AND SEALS0355 00REPLACE TRACK TENSION ADJUSTER AND MOUNT0356 00REPLACE DRIVE SPROCKETS, CUSHIONS, AND CARRIER ASSEMBLY0357 00REPLACE TRACK0358 00REPLACE TRACK SHOE AND PAD ASSEMBLY0359 00	REPLACE ROAD WHEEL SUPPORT ARM BUMPER STOP/SUPPORT	
REPLACE TRACK TENSION ADJUSTER AND MOUNT	REPLACE IDLER WHEEL ARM ASSEMBLY	
REPLACE DRIVE SPROCKETS, CUSHIONS, AND CARRIER ASSEMBLY0357 00 REPLACE TRACK	REPLACE IDLER WHEEL HUB/BEARINGS AND SEALS	
REPLACE TRACK0358 00 REPLACE TRACK SHOE AND PAD ASSEMBLY0359 00	REPLACE TRACK TENSION ADJUSTER AND MOUNT	0356 00
REPLACE TRACK SHOE AND PAD ASSEMBLY0359 00	REPLACE DRIVE SPROCKETS, CUSHIONS, AND CARRIER ASSEMBLY	
	REPLACE TRACK	
REPLACE IDLER WHEEL	REPLACE TRACK SHOE AND PAD ASSEMBLY	0359 00
	REPLACE IDLER WHEEL	0360 00

## TABLE OF CONTENTS (cont)

WP Sequence No.

REPLACE ROAD WHEEL	0361 00
CHAPTER 15 — UNIT MAINTENANCE INSTRUCTIONS FOR STEERING	
ADJUST STEERING WHEEL LINKAGE (M548A3)	0362 00
REPLACE STEERING WHEEL QUICK RELEASE PIN AND BRACKET (M548A3)	0363 00
REPLACE STEERING WHEEL LINKAGE (M548A3)	0364 00
REPLACE STEERING WHEEL, COLUMN, HOUSING, AND SHAFT (M548A3)	0365 00
REPLACE STEERING CONTROL/LINKAGE (M548A1)	0366 00
ADJUST STEERING CONTROLS (M548A1)	0367 00
REPLACE ENGINE DISCONNECT CONTROL (M548A1)	0368 00
REPLACE PIVOT STEERING BRAKE CONTROLS/LINKAGE (M548A1)	0369 00
ADJUST PIVOT STEERING BRAKE CONTROLS/LINKAGE (M548A1)	0370 00
REPLACE PIVOT STEERING BRAKE MASTER CYLINDER (M548A1)	0371 00
REPLACE PIVOT STEERING BRAKE HOSES/TUBES/FITTINGS (M548A1)	0372 00
REPLACE PIVOT STEERING BRAKE ASSEMBLY (M548A1)	0373 00
REPLACE PIVOT STEERING CLUTCH DISK (M548A1)	0374 00
REPLACE PIVOT STEERING BRAKE LINING (M548A1)	0375 00
CHAPTER 16 — UNIT MAINTENANCE INSTRUCTIONS FOR TIEDOWN AND TOWING ATTACHMENTS	
REPLACE TOWING EYE AND HOOK	0376 00
REPAIR/REPLACE TOWING PINTLE	0377 00
REPLACE REAR TIEDOWN PLATES	037800

## Volume 3

CHAPTER 17 — UNIT MAINTENANCE INSTRUCTIONS FOR SHOCK ABSORBERS	
REPLACE SHOCK ABSORBER	0379 00
REPLACE SHOCK ABSORBER PIN	0380 00
REPLACE SHOCK ABSORBER MOUNT	0381 00
CHAPTER 18 — UNIT MAINTENANCE INSTRUCTIONS FOR HULL	
REPLACE LIFTING EYE	
REPLACE HULL BOTTOM ACCESS COVER AND DRAIN COVER	
REPLACE TRANSVERSE BEAM AND CENTER SEAT PANEL (M548A1)	0384 00
REPLACE TRANSVERSE BEAM BOLTED (M548A3)	0385 00
REPLACE CAB DOOR, HANDLES, AND LINKAGE	0386 00
REPLACE DOOR WINDOWS	0387 00
REPLACE CAB DOOR SEAL	0388 00
REPLACE POWER PLANT RIGHT REAR ACCESS COVER SEAL	
REMOVE/INSTALL TOP ACCESS COVER AND GRILLES (M548A1)	0390 00

## TABLE OF CONTENTS (cont)

- REMOVE/INSTALL FRONT ACCESS COVER (M548A3)	0201.00
REPLACE WINDSHIELDS AND WINDSHIELD FRAME	
RAISE/LOWER CARGO COMPARTMENT FLOOR PLATES	
REMOVE/INSTALL CAB FLOOR PLATES (M548A1)	
REPLACE CAB FLOOR PLATES, DOOR, AND SEAT SUPPORT (M548A3)	
REPLACE CAB FLOOR PLATES, DOOR, AND SEAT SUPPORT (M348A3) REPLACE CENTER SEAT SUPPORT (M548A1)	
REPLACE CENTER SEAT SUFFORT (M348AT)	
REPLACE DRIVER S SEAT	
REPLACE CAB FERSONNEL SEATS	
REMOVE/INSTALL RIGHT SEAT (M548A1)	
REPLACE M13 DECONTAMINATION BRUSH GUARD AND BACKING PLATE	
REPLACE CARGO DOOR	
REPLACE CARGO DOOR SEALS	
REPLACE TAILGATE CONTROLS	
REPLACE TAILGATE END SEALS AND BUMPERS	
REPAIR HULL BY WELDING	
CHAPTER 19 — UNIT MAINTENANCE INSTRUCTIONS FOR WINCH AND POWER TAKEOFF (M548A1)	
REPLACE WINCH (M548A1)	0407 00
ADJUST DRUM BRAKE SHOE (M548A1)	0408 00
ADJUST DRUM SAFETY BRAKE (M548A1)	
REPLACE CLUTCH LEVER (M548A1)	0410 00
REPLACE DRUM LOCK HANDLE (M548A1)	0411 00
REPLACE WINCH PROPELLER SHAFT (M548A1)	0412 00
REPLACE WINCH TRANSFER GEARCASE (M548A1)	0413 00
REPLACE WINCH POWER TAKEOFF CONTROL (M548A1)	041400
REPLACE POWER TAKEOFF (M548A1)	0415 00
REPLACE WIRE ROPE, HOOK, AND CHAIN (M548A1)	041600
CHAPTER 20 — UNIT MAINTENANCE INSTRUCTIONS FOR HULL ACCESSORY ITEMS	
REPLACE CARGO COMPARTMENT COVER	0417 00
REPLACE CAB COVER AND FRAMES	
REPLACE FRONT STEP	
REPLACE WINDSHIELD WIPER MOTOR	
REPLACE WINDSHIELD WIPER LINKAGE	
REPLACE WINDSHIELD WIPER ARM AND BLADE	
REPLACE WIPER MOTOR GEAR	0423 00
REPLACE BILGE PUMP	0424 00
REPLACE BILGE PUMP DISCHARGE TUBES AND HOSES (M548A1)	
REPLACE BILGE PUMP DISCHARGE TUBES AND HOSES (M548A3)	
SERVICE/REPAIR/ADJUST VEHICLE COMPARTMENT HEATER	

REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY AND MOUNTING	
BRACKETS (M548A3)	
SERVICE VEHICLE COMPARTMENT HEATER FUEL PUMP	
REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY FUEL PUMP	0420.00
(M548A3) REPLACE VEHICLE COMPARTMENT HEATER CONTROL BOX	
REPLACE VEHICLE COMPARTMENT HEATER CONTROL BOX	
(M548A3)	0432 00
REPLACE VEHICLE COMPARTMENT HEATER DEFROSTER FAN TOGGLE SWITCHES/IDENTIFICATION PLATE	
REPLACE VEHICLE COMPARTMENT HEATER DEFROSTER FAN WIRING HARNESS	0434 00
REPLACE VEHICLE COMPARTMENT HEATER WIRING HARNESS (M548A3)	
SERVICE PERSONNEL HEATER FUEL FILTER (M548A3)	0436 00
REPLACE VEHICLE COMPARTMENT HEATER EXHAUST METAL HOSE	
ASSEMBLY (M548A3)	
REPLACE VEHICLE COMPARTMENT HEATER AIR INLET DUCTS (M548A3)	0438 00
REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES TO FUEL/ SEPARATOR FILTER (M548A3)	0439.00
REPLACE PLATES, STENCILS, DECALS, RUBBER PADS, AND STRAPS	
DATA PLATE, MARKER, AND DECAL CHART (M548A1)	
DATA PLATE, MARKER, AND DECAL CHART (M548A3)	
CHAPTER 21 — UNIT MAINTENANCE INSTRUCTIONS FOR TOOLS AND TEST EQUIPMENT	
INSPECT POWER PLANT SLING	0443 00
	0443 00
CHAPTER 22 — UNIT MAINTENANCE INSTRUCTIONS FOR SPECIAL PURPOSE KITS	0443 00
CHAPTER 22 — UNIT MAINTENANCE INSTRUCTIONS FOR SPECIAL PURPOSE KITS REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND	0444 00
CHAPTER 22 — UNIT MAINTENANCE INSTRUCTIONS FOR SPECIAL PURPOSE KITS REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT II OR III) (M548A1)	0444 00
CHAPTER 22 — UNIT MAINTENANCE INSTRUCTIONS FOR SPECIAL PURPOSE KITS REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT I) (M548A1)	0444 00
CHAPTER 22 — UNIT MAINTENANCE INSTRUCTIONS FOR SPECIAL PURPOSE KITS REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT I) OR III)	0444 00 0445 00 0446 00
CHAPTER 22 — UNIT MAINTENANCE INSTRUCTIONS FOR SPECIAL PURPOSE KITS REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT II OR III) (M548A1)	0444 00 0445 00 0446 00 0447 00
CHAPTER 22 — UNIT MAINTENANCE INSTRUCTIONS FOR SPECIAL PURPOSE KITS REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT I) (M548A1)	0444 00 0445 00 0446 00 0447 00
CHAPTER 22 — UNIT MAINTENANCE INSTRUCTIONS FOR SPECIAL PURPOSE KITS REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT II OR III) (M548A1)	0444 00 0445 00 0446 00 0447 00 0448 00
CHAPTER 22 — UNIT MAINTENANCE INSTRUCTIONS FOR SPECIAL PURPOSE KITS REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT I) (M548A1)	0444 00 0445 00 0446 00 0447 00 0448 00 0449 00
CHAPTER 22 — UNIT MAINTENANCE INSTRUCTIONS FOR SPECIAL PURPOSE KITS REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT I) (M548A1)	0444 00 0445 00 0446 00 0447 00 0448 00 0449 00 0450 00
<ul> <li>CHAPTER 22 — UNIT MAINTENANCE INSTRUCTIONS FOR SPECIAL PURPOSE KITS</li> <li>REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT I) (M548A1)</li> <li>REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT II OR III) (M548A1)</li> <li>REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT I) (M548A1)</li> <li>REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT II OR III) (M548A1)</li> <li>REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT I) (M548A1)</li> <li>REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT I) (M548A1)</li> <li>REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT I) OR III) (M548A1)</li> <li>REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT II OR III) (M548A1)</li> <li>REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT II OR III)</li> <li>REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT II OR III)</li> <li>REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT II OR III)</li> <li>REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT II OR III)</li> <li>REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT II OR III)</li> <li>REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT II OR III)</li> </ul>	0444 00 0445 00 0446 00 0447 00 0447 00 0449 00 0449 00 0450 00 0451 00
CHAPTER 22 — UNIT MAINTENANCE INSTRUCTIONS FOR SPECIAL PURPOSE KITS REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER ASSEMBLY (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER FUEL PUMP (KIT II OR III) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER WIRING HARNESS (M548A1) REPLACE VEHICLE COMPARTMENT HEATER AIR DUCTS AND HOSES (KIT I) (M548A1) REPLACE VEHICLE COMPARTMENT HEATER AIR DUCTS AND HOSES (KIT I)	0444 00 0445 00 0446 00 0447 00 0447 00 0449 00 0450 00 0451 00 0452 00
<ul> <li>CHAPTER 22 — UNIT MAINTENANCE INSTRUCTIONS FOR SPECIAL PURPOSE KITS</li> <li>REPLACE VEHICLE COMPARTMENT HEATER FUEL HOSES, TUBES, AND FITTINGS (KIT I) (M548A1)</li></ul>	0444 00 0445 00 0446 00 0447 00 0447 00 0449 00 0450 00 0451 00 0452 00

REPLACE VEHICLE COMPARTMENT HEATER EXHAUST GUARD (M548A1)       .04         REPLACE FIBERGLASS CAB COVER       .04         REPLACE FIBERGLASS MACHINE GUN HATCH COVER       .04         REPLACE CAB WINDOWS.       .04         REPLACE CAB WINDOWS.       .04         REPLACE LOWER CAB INSULATION       .04         REPLACE CLOTH SEAT COVERS.       .04         REPLACE CLOTH SEAT COVERS.       .04         REPLACE CARGO AREA HEATER AND CONTROL BOX MOUNTING.       .04         REPLACE CARGO AREA HEATER FUEL LINES, FITTINGS AND SHIELDS.       .04         REPLACE CARGO AREA HEATER FUEL LINES, FITTINGS AND SHIELDS.       .04         REPLACE CARGO AREA HEATER WINING HARNESS.       .04         REPLACE ESCAPE HATCH COVERS.       .04         REPLACE INSULATED CARGO COVERS.       .04         REPLACE SCAPE HATCH COVERS.       .04         REPLACE FESONNEL SEAT COVERS.       .04         REPLACE FREAMIN HEATER CONTROL BOX       .04         REPLACE PRESONNEL SEAT COVERS.       .04         REPLACE ENGINE COOLANT HEATER WINING HARNESS.       .04         REPLACE ENGINE COOLANT HEATER WINING HARNESS.       .04         REPLACE ENSONNEL SEAT COVERS.       .04         REPLACE ENSONNEL SEAT COVERS.       .04         REPLACE ENSONNEL SEAT COVERS. <t< th=""><th></th><th></th></t<>		
REPLACE FIBERGLASS MACHINE GUN HATCH COVER	REPLACE VEHICLE COMPARTMENT HEATER EXHAUST GUARD (M548A1)	
REPLACE CAB WINDOWS       .04         REPLACE LOWER CAB INSULATION       .04         REPLACE CLOTH SEAT COVERS       .04         REPLACE CLOTH SEAT COVERS       .04         REPLACE CARGO AREA HEATER AND CONTROL BOX MOUNTING.       .04         REPLACE CARGO AREA HEATER FUEL LINES, FITTINGS AND SHIELDS       .04         REPLACE CARGO AREA HEATER FUEL PUMP.       .04         REPLACE CARGO AREA HEATER FUEL PUMP.       .04         REPLACE CARGO AREA HEATER WIRING HARNESS       .04         REPLACE INSULATED CARGO COVERS.       .04         REPLACE INSULATED CARGO COVERS.       .04         REPLACE ENSULATED COVER WINDOWS.       .04         REPLACE CARGO DOR INSULATION       .04         REPLACE ARGO DOR INSULATION       .04         REPLACE PLOOR PLATE COVERS.       .04         REPLACE PRESONNEL SEAT COVERS.       .04         REPLACE PRESONNEL SEAT COVERS.       .04         REPLACE REGINE COOLANT HEATER WIRING HARNESS.       .04         REPLACE ENGINE COOLANT HEATER WIRING HARNESS.       .04         REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES.       .04         REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES.       .04         REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES.       .04         REPLACE ENGINE COOLANT HEATER	REPLACE FIBERGLASS CAB COVER	0456 00
REPLACE LOWER CAB INSULATION	REPLACE FIBERGLASS MACHINE GUN HATCH COVER	0457 00
REPLACE CLOTH SEAT COVERS.       04         REPLACE THERMAL DOOR WINDOWS.       04         REPLACE CARGO AREA HEATER AND CONTROL BOX MOUNTING.       04         REPLACE CARGO AREA HEATER AND CONTROL BOX MOUNTING.       04         REPLACE CARGO AREA HEATER FUEL LINES, FITTINGS AND SHIELDS.       044         REPLACE CARGO AREA HEATER WIRING HARNESS.       044         REPLACE INSULATED CARGO COVERS.       044         REPLACE INSULATED COVER WINDOWS.       044         REPLACE INSULATED COVER WINDOWS.       044         REPLACE CARGO DOOR INSULATION.       044         REPLACE FLOOR PLATE COVERS.       044         REPLACE FLOOR PLATE COVERS.       044         REPLACE PRISONNEL SEAT COVERS.       044         REPLACE PROOR PLATE COVERS.       044         REPLACE REGINE COOLANT HEATER WIRING HARNESS.       047         REPLACE REGINE COOLANT HEATER FUEL PUMP/FUEL LINES.       047         REPLACE RENGINE COOLANT HEATER FUEL PUMP/FUEL LINES.       047         REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1).       047         REPLACE ENGINE COOLANT HEATER EXHAUST	REPLACE CAB WINDOWS	
REPLACE THERMAL DOOR WINDOWS	REPLACE LOWER CAB INSULATION	
REPLACE CARGO AREA HEATER AND CONTROL BOX MOUNTING	REPLACE CLOTH SEAT COVERS	
REPLACE CARGO AREA HEATER FUEL LINES, FITTINGS AND SHIELDS	REPLACE THERMAL DOOR WINDOWS	
REPLACE CARGO AREA HEATER FUEL PUMP.       044         REPLACE CARGO AREA HEATER WIRING HARNESS.       044         REPLACE INSULATED CARGO COVERS.       044         REPLACE ENCAPE HATCH COVER.       044         REPLACE ENSULATED COVER WINDOWS.       044         REPLACE CARGO DOOR INSULATION.       044         REPLACE FLOOR PLATE COVERS.       044         REPLACE FLOOR PLATE COVERS.       044         REPLACE PERSONNEL SEAT COVERS.       044         REPLACE PERSONNEL SEAT COVERS.       044         REPLACE ENGINE COOLANT HEATER WIRING HARNESS.       044         REPLACE ENGINE COOLANT HEATER WIRING HARNESS.       044         REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES.       044         REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES.       044         REPLACE ENGINE COOLANT HEATER.       044         REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1).       044         REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1).       044         REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1).       044         REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3).       044 <tr< td=""><td>REPLACE CARGO AREA HEATER AND CONTROL BOX MOUNTING</td><td></td></tr<>	REPLACE CARGO AREA HEATER AND CONTROL BOX MOUNTING	
REPLACE CARGO AREA HEATER WIRING HARNESS.044REPLACE INSULATED CARGO COVERS.044REPLACE INSULATED COVER WINDOWS.044REPLACE INSULATED COVER WINDOWS.044REPLACE CARGO DOOR INSULATION.044REPLACE FLOOR PLATE COVERS.047REPLACE PERSONNEL SEAT COVERS.047REPLACE ENGINE COOLANT HEATER WIRING HARNESS.047REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES.047REPLACE BATTERY BOX HEAT EXCHANGER/HOSES/FITTINGS.047REPLACE ENGINE COOLANT HEATER COOLANT PUMP047REPLACE ENGINE COOLANT HEATER COOLANT PUMP047REPLACE ENGINE COOLANT HEATER COOLANT PUMP047REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1).044REPLACE BEAM/BEAM SUPPORTS/STOPS.044REPLACE PERSONNEL SEATS/SAFETY BELT.044REMOVE/INSTALL MULHE	REPLACE CARGO AREA HEATER FUEL LINES, FITTINGS AND SHIELDS	
REPLACE INSULATED CARGO COVERS.044REPLACE ESCAPE HATCH COVER.044REPLACE ENSULATED COVER WINDOWS.044REPLACE INSULATED COVER WINDOWS.044REPLACE CARGO DOOR INSULATION.044REPLACE FLOOR PLATE COVERS.047REPLACE PERSONNEL SEAT COVERS.047REPLACE PERSONNEL SEAT COVERS.047REPLACE ENGINE COOLANT HEATER WIRING HARNESS.047REPLACE ENGINE COOLANT HEATER WIRING HARNESS.047REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES.047REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES.047REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES.047REPLACE ENGINE COOLANT HEATER COOLANT PUMP.047REPLACE ENGINE COOLANT HEATER.047REPLACE ENGINE COOLANT HEATER COOLANT PUMP.047REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1).047REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1).048REMOVE/INSTALL MATERIAL HANDLING KIT.044REPLACE BEAM/BEAM SUPPORTS/STOPS.044REPLACE BEAM/BEAM SUPPORTS/STOPS.044REPLACE HOIST ASSEMBLY.044REPLACE HOIST ASSEMBLY.044REPLACE RIFLE RACK.044REPLACE AIR BRAKE COMPRESSOR (M548A1).044REPLACE AIR BRAKE COMPRESSOR (M548A1).044REPLACE AIR BRAKE COMPRESSOR (M548A1).044REPLACE AIR BRAKE RESERVOIR (M548A1).044REPLACE AIR BRAKE RESERVOIR (M548A1).044REPLACE AIR BRAKE RESERVOIR (M548A1).044	REPLACE CARGO AREA HEATER FUEL PUMP	0464 00
REPLACE ESCAPE HATCH COVER.044REPLACE INSULATED COVER WINDOWS.044REPLACE CARGO DOOR INSULATION.044REPLACE CARGO DOOR INSULATION.044REPLACE FLOOR PLATE COVERS.047REPLACE PERSONNEL SEAT COVERS.047REPLACE PERSONNEL SEAT COVERS.047REPLACE ENGINE COOLANT HEATER WIRING HARNESS.047REPLACE ENGINE COOLANT HEATER WIRING HARNESS.047REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES.047REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES.047REPLACE BATTERY BOX HEAT EXCHANGER/HOSES/FITTINGS.047REPLACE ENGINE COOLANT HEATER.047REPLACE ENGINE COOLANT HEATER.047REPLACE ENGINE COOLANT HEATER.047REPLACE ENGINE COOLANT HEATER COOLANT PUMP.047REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1).047REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1).044REMOVE/INSTALL MATERIAL HANDLING KIT.044REPLACE BEAM/BEAM SUPPORTS/STOPS.044REPLACE BEAM/BEAM SUPPORTS/STOPS.044REPLACE HOIST/STOPS/SLING.044REPLACE HOIST/STOPS/SLING.044REPLACE PERSONNEL SEATS/SAFETY BELT.044REPLACE AIR BRAKE COMPRESSOR (M548A1).044REPLACE AIR BRAKE GOVERNOR (M548A1).044REPLACE AIR BRAKE GOVERNOR (M548A1).044REPLACE AIR BRAKE RESERVOIR (M548A1).044	REPLACE CARGO AREA HEATER WIRING HARNESS	
REPLACE INSULATED COVER WINDOWS044REPLACE CARGO DOOR INSULATION044REPLACE FLOOR PLATE COVERS047REPLACE FLOOR PLATE COVERS047REPLACE PERSONNEL SEAT COVERS047REPLACE PERSONNEL SEAT COVERS047REPLACE ENGINE COOLANT HEATER WINING HARNESS047REPLACE ENGINE COOLANT HEATER WINING HARNESS047REPLACE ENGINE COOLANT HEATER CONTROL BOX047REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES047REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES047REPLACE ENGINE COOLANT HEATER047REPLACE ENGINE COOLANT HEATER047REPLACE ENGINE COOLANT HEATER047REPLACE ENGINE COOLANT HEATER COOLANT PUMP047REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1)048REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1)044REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)044REPLACE BEAM/BEAM SUPPORTS/STOPS044REPLACE HOIST/STOPS/SLING044REPLACE HOIST/STOPS/SLING044REPLACE PERSONNEL SEATS/SAFETY BELT044REPLACE RIFLE RACK044REPLACE AIR BRAKE COMPRESSOR (M548A1)044REPLACE AIR BRAKE GOVERNOR (M548A1)044REPLACE AIR BRAKE RESERVOIR (M548A1)044REPLACE AIR BRAKE RESERVOIR (M548A1)044	REPLACE INSULATED CARGO COVERS	
REPLACE CARGO DOOR INSULATION044REPLACE FLOOR PLATE COVERS047REPLACE FLOOR PLATE COVERS047REPLACE PERSONNEL SEAT COVERS047REPLACE PERSONNEL SEAT COVERS047REPLACE ENGINE COOLANT HEATER WIRING HARNESS047REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES047REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES047REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES047REPLACE ENGINE COOLANT HEATER047REPLACE ENGINE COOLANT HEATER047REPLACE ENGINE COOLANT HEATER047REPLACE ENGINE COOLANT HEATER COOLANT PUMP.047REPLACE ENGINE COOLANT HEATER COOLANT PUMP.047REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1).048REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1).044REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3).044REPLACE PERSONNEL SEATS/SAFETY BELT.044REPLACE PERSONNEL SEATS/SAFETY BELT.044REPLACE AIR BRAKE COMPRESSOR (M548A1).0	REPLACE ESCAPE HATCH COVER	0467 00
REPLACE FLOOR PLATE COVERS04'REPLACE PERSONNEL SEAT COVERS04'REPLACE PERSONNEL SEAT COVERS04'REPLACE ENGINE COOLANT HEATER WIRING HARNESS04'REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES04'REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES04'REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES04'REPLACE ENGINE COOLANT HEATER COOLANT PUMP04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)04'REPLACE BEGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)04'REPLACE BEGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)04'REPLACE BEAM/BEAM SUPPORTS/STOPS04'REPLACE HOIST/STOPS/SLING04'REPLACE HOIST/STOPS/SLING04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE AIR BRAKE COMPRESSOR (M548A1)04'REPLACE AIR BRAKE GOVERNOR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'	REPLACE INSULATED COVER WINDOWS	
REPLACE PERSONNEL SEAT COVERS04'REPLACE/REPAIR HEATER CONTROL BOX04'REPLACE ENGINE COOLANT HEATER WIRING HARNESS04'REPLACE ENGINE COOLANT HEATER CONTROL BOX04'REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES04'REPLACE BATTERY BOX HEAT EXCHANGER/HOSES/FITTINGS04'REPLACE ENGINE COOLANT HEATER04'REPLACE ENGINE COOLANT HEATER04'REPLACE ENGINE COOLANT HEATER04'REPLACE ENGINE COOLANT HEATER COOLANT PUMP04'REPLACE ENGINE COOLANT/VEHICLE COMPARTMENT HEATER EXHAUST.04'PIPES GUARD (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)04'REPLACE BEAM/BEAM SUPPORTS/STOPS04'REPLACE HOIST/STOPS/SLING04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE AIR BRAKE COMPRESSOR (M548A1)04'REPLACE AIR BRAKE GOVERNOR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'	REPLACE CARGO DOOR INSULATION	0469 00
REPLACE/REPAIR HEATER CONTROL BOX04'REPLACE ENGINE COOLANT HEATER WIRING HARNESS04'REPLACE ENGINE COOLANT HEATER CONTROL BOX04'REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES04'REPLACE BATTERY BOX HEAT EXCHANGER/HOSES/FITTINGS04'REPLACE BATTERY BOX HEAT EXCHANGER/HOSES/FITTINGS04'REPLACE ENGINE COOLANT HEATER04'REPLACE ENGINE COOLANT HEATER04'REPLACE ENGINE COOLANT HEATER COOLANT PUMP04'REPLACE ENGINE COOLANT/VEHICLE COMPARTMENT HEATER EXHAUST.04'PIPES GUARD (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)04'REPLACE BEAM/BEAM SUPPORTS/STOPS04'REPLACE HOIST/STOPS/SLING04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE AIR BRAKE COMPRESSOR (M548A1)04'REPLACE AIR BRAKE COMPRESSOR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04' </td <td>REPLACE FLOOR PLATE COVERS</td> <td>0470 00</td>	REPLACE FLOOR PLATE COVERS	0470 00
REPLACE ENGINE COOLANT HEATER WIRING HARNESS04'REPLACE ENGINE COOLANT HEATER CONTROL BOX04'REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES04'REPLACE BATTERY BOX HEAT EXCHANGER/HOSES/FITTINGS04'REPLACE BATTERY BOX HEAT EXCHANGER/HOSES/FITTINGS04'REPLACE ENGINE COOLANT HEATER04'REPLACE ENGINE COOLANT HEATER04'REPLACE ENGINE COOLANT HEATER COOLANT PUMP04'REPLACE ENGINE COOLANT/VEHICLE COMPARTMENT HEATER EXHAUST.04'PIPES GUARD (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)04'REPLACE BEAM/BEAM SUPPORTS/STOPS04'REPLACE HOIST/STOPS/SLING04'REPLACE HOIST ASSEMBLY04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE RIFLE RACK04'REPLACE AIR BRAKE COMPRESSOR (M548A1)04'REPLACE AIR BRAKE COMPRESSOR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'REPLA	REPLACE PERSONNEL SEAT COVERS	0471 00
REPLACE ENGINE COOLANT HEATER CONTROL BOX04'REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES04'REPLACE BATTERY BOX HEAT EXCHANGER/HOSES/FITTINGS04'REPLACE ENGINE COOLANT HEATER04'REPLACE ENGINE COOLANT HEATER COOLANT PUMP04'REPLACE ENGINE COOLANT/VEHICLE COMPARTMENT HEATER EXHAUST.04'PIPES GUARD (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)04'REPLACE BEAM/BEAM SUPPORTS/STOPS04'REPLACE BEAM/BEAM SUPPORTS/STOPS04'REPLACE HOIST ASSEMBLY04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE AIR BRAKE COMPRESSOR (M548A1)04'REPLACE AIR BRAKE GOVERNOR (M548A1)04'REPLACE AIR BRAKE GOVERNOR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'	REPLACE/REPAIR HEATER CONTROL BOX	
REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES04'REPLACE BATTERY BOX HEAT EXCHANGER/HOSES/FITTINGS04'REPLACE ENGINE COOLANT HEATER.04'REPLACE ENGINE COOLANT HEATER COOLANT PUMP04'REPLACE ENGINE COOLANT/VEHICLE COMPARTMENT HEATER EXHAUST.04'PIPES GUARD (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)04'REPLACE BEAM/BEAM SUPPORTS/STOPS04'REPLACE HOIST/STOPS/SLING04'REPLACE HOIST ASSEMBLY04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE RIFLE RACK04'REPLACE AIR BRAKE COMPRESSOR (M548A1)04'REPLACE AIR BRAKE GOVERNOR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'	REPLACE ENGINE COOLANT HEATER WIRING HARNESS	
REPLACE BATTERY BOX HEAT EXCHANGER/HOSES/FITTINGS04'REPLACE ENGINE COOLANT HEATER04'REPLACE ENGINE COOLANT HEATER COOLANT PUMP04'REPLACE ENGINE COOLANT/VEHICLE COMPARTMENT HEATER EXHAUST04'PIPES GUARD (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)04'REPLACE BEAM/BEAM SUPPORTS/STOPS04'REPLACE HOIST/STOPS/SLING04'REPLACE HOIST ASSEMBLY04'REPLACE PERSONNEL SEATS/SAFETY BELT04'REPLACE RIFLE RACK04'REPLACE AIR BRAKE COMPRESSOR (M548A1)04'REPLACE AIR BRAKE GOVERNOR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'	REPLACE ENGINE COOLANT HEATER CONTROL BOX	0474 00
REPLACE ENGINE COOLANT HEATER.04'REPLACE ENGINE COOLANT HEATER COOLANT PUMP.04'REPLACE ENGINE COOLANT/VEHICLE COMPARTMENT HEATER EXHAUST04'PIPES GUARD (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1)04'REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)04'REPLACE BEAM/BEAM SUPPORTS/STOPS.04'REPLACE HOIST/STOPS/SLING.04'REPLACE HOIST/STOPS/SLING.04'REPLACE PERSONNEL SEATS/SAFETY BELT.04'REPLACE RIFLE RACK.04'REPLACE RIFLE RACK.04'REPLACE AIR BRAKE COMPRESSOR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'REPLACE AIR BRAKE RESERVOIR (M548A1)04'	REPLACE ENGINE COOLANT HEATER FUEL PUMP/FUEL LINES	0475 00
REPLACE ENGINE COOLANT HEATER COOLANT PUMP047REPLACE ENGINE COOLANT/VEHICLE COMPARTMENT HEATER EXHAUST PIPES GUARD (M548A1)047REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1)048REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)048REMOVE/INSTALL MATERIAL HANDLING KIT044REPLACE BEAM/BEAM SUPPORTS/STOPS044REPLACE HOIST/STOPS/SLING044REPLACE HOIST/STOPS/SLING044REPLACE PERSONNEL SEATS/SAFETY BELT044REPLACE PERSONNEL SEATS/SAFETY BELT044REPLACE RIFLE RACK044REPLACE AIR BRAKE COMPRESSOR (M548A1)044REPLACE AIR BRAKE GOVERNOR (M548A1)044REPLACE AIR BRAKE RESERVOIR (M548A1)044	REPLACE BATTERY BOX HEAT EXCHANGER/HOSES/FITTINGS	
REPLACE ENGINE COOLANT/VEHICLE COMPARTMENT HEATER EXHAUST PIPES GUARD (M548A1)	REPLACE ENGINE COOLANT HEATER	
PIPES GUARD (M548A1)04REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1)048REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3)048REMOVE/INSTALL MATERIAL HANDLING KIT044REPLACE BEAM/BEAM SUPPORTS/STOPS044REPLACE HOIST/STOPS/SLING044REPLACE HOIST/STOPS/SLING044REPLACE PERSONNEL SEATS/SAFETY BELT044REPLACE PERSONNEL SEATS/SAFETY BELT044REPLACE RIFLE RACK044REPLACE RIFLE RACK044REPLACE AIR BRAKE COMPRESSOR (M548A1)044REPLACE AIR BRAKE RESERVOIR (M548A1)044	REPLACE ENGINE COOLANT HEATER COOLANT PUMP	
REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A1).048REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3).048REMOVE/INSTALL MATERIAL HANDLING KIT.048REPLACE BEAM/BEAM SUPPORTS/STOPS.048REPLACE HOIST/STOPS/SLING.048REPLACE HOIST/STOPS/SLING.048REPLACE PERSONNEL SEATS/SAFETY BELT.048REPLACE RIFLE RACK.048REPLACE RIFLE RACK.048REPLACE AIR BRAKE COMPRESSOR (M548A1).049REPLACE AIR BRAKE RESERVOIR (M548A1).049		0479 00
REPLACE ENGINE COOLANT HEATER EXHAUST SYSTEM (M548A3).048REMOVE/INSTALL MATERIAL HANDLING KIT048REPLACE BEAM/BEAM SUPPORTS/STOPS048REPLACE HOIST/STOPS/SLING048REPAIR HOIST ASSEMBLY048REPLACE PERSONNEL SEATS/SAFETY BELT048REMOVE/INSTALL BULKHEAD PROTECTOR048REPLACE RIFLE RACK048REPLACE AIR BRAKE COMPRESSOR (M548A1)049REPLACE AIR BRAKE RESERVOIR (M548A1)049		
REMOVE/INSTALL MATERIAL HANDLING KIT		
REPLACE BEAM/BEAM SUPPORTS/STOPS.043REPLACE HOIST/STOPS/SLING.043REPAIR HOIST ASSEMBLY.043REPLACE PERSONNEL SEATS/SAFETY BELT.043REMOVE/INSTALL BULKHEAD PROTECTOR.043REPLACE RIFLE RACK.043REPLACE AIR BRAKE COMPRESSOR (M548A1).044REPLACE AIR BRAKE GOVERNOR (M548A1).044REPLACE AIR BRAKE RESERVOIR (M548A1).044		
REPAIR HOIST ASSEMBLY048REPLACE PERSONNEL SEATS/SAFETY BELT048REMOVE/INSTALL BULKHEAD PROTECTOR048REPLACE RIFLE RACK048REPLACE AIR BRAKE COMPRESSOR (M548A1)048REPLACE AIR BRAKE GOVERNOR (M548A1)049REPLACE AIR BRAKE RESERVOIR (M548A1)049		
REPLACE PERSONNEL SEATS/SAFETY BELT043REMOVE/INSTALL BULKHEAD PROTECTOR043REPLACE RIFLE RACK043REPLACE AIR BRAKE COMPRESSOR (M548A1)044REPLACE AIR BRAKE GOVERNOR (M548A1)044REPLACE AIR BRAKE RESERVOIR (M548A1)044REPLACE AIR BRAKE RESERVOIR (M548A1)044	REPLACE HOIST/STOPS/SLING	
REMOVE/INSTALL BULKHEAD PROTECTOR	REPAIR HOIST ASSEMBLY	
REPLACE RIFLE RACK	REPLACE PERSONNEL SEATS/SAFETY BELT	0486 00
REPLACE AIR BRAKE COMPRESSOR (M548A1)	REMOVE/INSTALL BULKHEAD PROTECTOR	
REPLACE AIR BRAKE GOVERNOR (M548A1)	REPLACE RIFLE RACK	
REPLACE AIR BRAKE RESERVOIR (M548A1)	REPLACE AIR BRAKE COMPRESSOR (M548A1)	
	REPLACE AIR BRAKE GOVERNOR (M548A1)	
	REPLACE AIR BRAKE RESERVOIR (M548A1)	0491 00
	REPLACE AIR BRAKE SAFETY VALVE (M548A1)	
REPLACE STOPLIGHT SWITCH (M548A1)		
REPLACE AIR LOW PRESSURE SWITCH (M548A1)	REPLACE AIR LOW PRESSURE SWITCH (M548A1)	0494 00

## **TABLE OF CONTENTS (cont)**

WP Sequence No.

REPLACE AIR HOSES/TUBES/FITTINGS (M548A1)	
REPLACE OIL HOSES/FITTINGS (M548A1)	
REPLACE COMPRESSOR DRIVE BELT GUARD (M548A1)	
ADJUST/ALIGN COMPRESSOR DRIVE PULLEY/BELTS (M548A1)	
REPLACE COMPRESSOR DRIVE PULLEY/BELTS (M548A1)	
REPLACE AIR STRAINER (M548A1)	
REPLACE AIR BRAKE INSTRUMENT PANEL (M548A1)	
REPLACE AIR LOW PRESSURE WARNING LIGHT (M548A1)	
REPLACE AIR BRAKE PRESSURE INDICATOR (M548A1)	
REPLACE AIR BRAKE PANEL LIGHT (M548A1)	0504 00
REPLACE TURN SIGNAL LIGHT	0505 00
REPLACE BLACKOUT MARKER LIGHT	0506 00
REPLACE BLACKOUT STOPLIGHT-TAILLIGHT	
REPLACE TURN SIGNAL CONTROL/MOUNT	0508 00
REPLACE FLASHER	
REPLACE REFLECTOR	0510 00
REPLACE TURN SIGNAL FRONT WIRING HARNESS	
REPLACE TURN SIGNAL REAR WIRING HARNESS	
REPLACE CALIBER .50 MACHINE GUN MOUNT	
REPLACE M66 RING MOUNT KIT	0514 00
REPLACE 7.62 MM MACHINE GUN MOUNT	
CHAPTER 23 — UNIT MAINTENANCE INSTRUCTIONS FOR GAUGES	
REPLACE SPEEDOMETER	
REPLACE SPEEDOMETER CABLE HOUSING AND ADAPTER	0517 00
REPLACE SPEEDOMETER CABLE	
REPLACE TACHOMETER	0519 00
REPLACE TACHOMETER CABLE HOUSING AND ADAPTER (M548A1)	
REPLACE TACHOMETER CABLE HOUSING AND ADAPTER (M548A3)	
REPLACE TACHOMETER CABLE (M548A1)	
REPLACE TACHOMETER CABLE (M548A3)	
CHAPTER 24 — UNIT MAINTENANCE INSTRUCTIONS FOR FIRE EXTINGUISHER SYSTEM	
REPLACE NOZZLES, TUBES, AND FITTINGS (NEW CONFIGURATION)	
REPLACE NOZZLES, TUBES, AND FITTINGS (OLD CONFIGURATION)	
REPLACE CARBON DIOXIDE (CO2) CYLINDER	
REPLACE FYR-FYTER CONTROL VALVE	
REPLACE WALTER KIDDE CONTROL VALVE	
REPLACE/REPAIR PORTABLE FIRE EXTINGUISHER PANEL ASSEMBLY	0500.00
(M548A3)	

CHAPTER 25 — UNIT MAINTENANCE INSTRUCTIONS FOR NBC SYSTEM (M548A3)

WP Sequence No.

REPLACE NBC CIRCUIT BREAKER AND RELAY (M548A3)0530 00
REPLACE NBC WIRING HARNESS FROM BATTERY COMPARTMENT TO MANIFOLD (M548A3)0531 00
REPLACE NBC M3 HEATER AND ADAPTER (M548A3)0532 00
REPAIR NBC MANIFOLD (M548A3)0533 00
REMOVE/INSTALL NBC M1A1-19 PRECLEANER ASSEMBLY AND FRAME (M548A3)0534 00
REPLACE NBC M19 PARTICULATE FILTER UNIT (M548A3)0535 00
REPLACE NBC M18 FILTER (M548A3)0536 00
REPLACE NBC FILTERED AIR HOSE (M548A3)0537 00
REPLACE NBC ORIFICE CONNECTOR ASSEMBLY AND BRACKET (M548A3)0538 00
CHAPTER 26 — UNIT SUPPORTING INFORMATION
REFERENCES0539 00
MAINTENANCE ALLOCATION CHART (MAC)0540 00
COMMON TOOLS AND SUPPLEMENTS AND SPECIAL TOOLS/FIXTURES LIST0541 00

## HOW TO USE THIS MANUAL

#### HOW TO USE THIS MANUAL

This manual tells you how to perform unit maintenance for the M548A1 and M548A3 carriers.

Before starting a task or procedure, read HOW TO USE THIS MANUAL and the General Maintenance Procedures Work Package.

#### USE YOUR MANUAL ON THE JOB

The best way to learn about this manual is to practice using it. Knowing how to use this manual will save both time and energy.

### HOW TO USE THE WORK PACKAGES (WP)

#### How to find the Work Package you need

Pick a key word from the vehicle part or system to be used. Look in the INDEX for this key word or the name of the action you will perform. Turn to the Work Package and page indicated.

The INDEX lists each Work Package under one or more headings. For example, the WP titled REPLACE TOWING PINTLE could be found under the two headings "Pintle", and "Towing".

#### How to read the Work Package

Pay attention to all **warnings**, **cautions** and **notes**. These can appear in all types of procedures. They help you avoid harm to yourself, other personnel, and equipment. They also tell you things you should know about the procedure.

Before you start a procedure, get all the tools, supplies, and personnel you need to do the procedure. These items will be listed in the INITIAL SETUP of the Work Package.

Start with step 1 and do each step in the order given. Numbered primary steps tell you WHAT to do. Alpha substeps tell you HOW to do it.

Look at the illustrations. Locators show you where the equipment and parts are located on the vehicle. Closeup illustrations show the details you need to do the procedure.

#### **Maintenance Procedures Work Packages**

Maintenance Procedures Work Packages keep the carrier in shape to operate. Maintenance Procedures are used to present maintenance instructions. Each maintenance procedure details steps which you need to perform. If the vehicle and parts need maintenance that is not included in any procedure in the manual, notify your supervisor.

Read the INITIAL SETUP section carefully before you start any procedure. Get the tools and supplies listed and the personnel needed. Be sure the equipment is in the condition required.

Read all of the Work Package before starting. Follow the steps in the order given.

FOLLOW-THROUGH STEPS tell you what to do after the maintenance task is done. The words END OF TASK will tell you when you have finished the procedure.

#### **Troubleshooting Work Packages**

Troubleshooting Work Packages help you locate faulty parts. They direct you to the maintenance procedure to correct these faults. Chapter 2, Troubleshooting, contains detailed information on how to perform troubleshooting procedures. Read HOW TO USE TROUBLESHOOTING Work Package (WP 0005 00) before performing the troubleshooting procedures in the chapter.

#### Preventive Maintenance Checks and Services (PMCS) Work Package

Preventive maintenance is required to keep your carrier in good running condition. The PMCS procedures for unit maintenance are performed on a periodic basis.

## HOW TO USE THIS MANUAL (cont)

If anything seems wrong with the carrier systems and you cannot fix it yourself, notify unit maintenance. Common things to watch for are loose bolts or damaged welds. Watch for worn insulation, loose clamps, and loose connectors when checking wiring harnesses.

#### **DEFINITION OF WORK PACKAGE TERMS**

#### Warnings, Cautions, And Notes

Pay attention to all warnings and cautions within the WP. Ignoring a warning could cause death or injury to yourself or other personnel. Ignoring a caution could cause damage to equipment. Notes contain facts to make the procedure easier. Warnings, cautions, and notes always appear just above the step to which they apply.

WARNINGS	Call attention to things that could kill or injure personnel. Warnings are also listed in the Warning Summary section (page a).
CAUTIONS	Call attention to actions or materials that could damage equipment.
NOTES	Contain important facts to make the procedure easier.

#### Helper

Helpers are needed in procedures that require more than one person. A helper may be needed to help lift objects or act as an outside observer.

If a helper is needed to perform a procedure, the INITIAL SETUP will list "Helper (H)" under the PERSONNEL REQUIRED heading.


If a helper assists with a step or substep, the step or substep will include: "Have helper assist".

If a helper performs the action alone, the step will start with "(H):".

#### **Locational Terms**

The terms FRONT, REAR, LEFT, and RIGHT are used to indicate where items are located on the vehicle. The point of reference for these terms is different for *Carrier* items and *Power Unit* items. (Carrier items are items which are not on the power unit. Power unit items are items on the engine, transmission, differential, or transfer gearcase.)


If you are working with carrier items, use this point of reference. Think of the location as if you were sitting in the driver's seat looking forward.



### M548A1 SHOWN

# HOW TO USE THIS MANUAL (cont)

If you are working with power unit items, use this point of reference. Think of the location as if you were standing at the transfer gearcase end of the power unit and facing the flywheel. This rule applies whether the power unit is IN or OUT of the carrier.



### M548A1 SHOWN

#### REFERENCES

References within a procedure refer to a different manual or to another procedure in the same manual. They are found in the INITIAL SETUP and in the FOLLOW-THROUGH steps. For example.

MASTER SWITCH OFF (see your -10)


Battery ground lead disconnected (WP 0310 00, WP 0311 00, or WP 0312 00)

For all procedures, the following comments apply:

- Parts which are discarded when removed will be referred to as "new" in the procedure step when installed. Examples are: gaskets, lockwashers, some preformed packings, and some retaining rings.
- These and other new parts are listed under MATERIALS/PARTS in the INITIAL SETUP.

### **GENERAL MAINTENANCE**

Cleaning, inspecting, checking for leaks, and similar procedures which apply to most procedures are found in the GENERAL MAINTENANCE PROCEDURES section of the PMCS (WP 0128 00). Use these steps to clean and inspect any part being removed, repaired, or installed. Special cleaning will be covered in the procedure step. Below is a step that would require general cleaning.



5. Remove gasket (1) from upper tube flange (2). Discard gasket.

### TM 9-2350-247-20-1

# HOW TO USE THIS MANUAL (cont)

After performing this step, you would clean the mating surface with cleaning compound and a wiping rag according to the general cleaning procedures. In other procedures, hoses or rubber hatch seals will need to be checked for leaks. Refer to Chapter 3 for general procedures.

### HOW TO USE THE REPAIR PARTS AND SPECIAL TOOLS LIST (RPSTL) WITH THIS MANUAL

The RPSTL (TM 9-2350-247-24P) gives the National Stock Number (NSN) required to order parts used in the maintenance procedure. To use the RPSTL to identify and order a part, do the following:

- 1. In this manual, turn to the first page of the procedure to be performed.
- 2. Find Materials/Parts under INITIAL SETUP and read the part(s) that need replacement. If required, find the illustrated part in the procedure steps.
- 3. Go to the RPSTL and find the same illustrated part. That part will have an item number assigned to it. Look this item number up in the listing for that figure. Use the figure and item number index to find the NSN.
- 4. If you inspect an item and find that it is damaged, go to the RPSTL and find the SMR code for the item. If the SMR code does not authorize you to repair the item, reassemble it and send it to the authorized level of maintenance.
- 5. The usable on code in the RPSTL appears in the lower left corner of the Description column heading. Usable on codes are shown as 'UOC......' in the Description column (justified left) on the first line following the item description/ nomenclature. Uncoded items are applicable to all models. Identification of the usable on codes in the RPSTL are:

#### Table 1. RPSTL Usable Codes

Code	Used On
V96	M548A1 Carrier, Cargo, tracked
AP4	M548A3 Carrier, Cargo, Tracked

### TM 9-2350-247-20-1

## CHAPTER 1

# UNIT INTRODUCTORY INFORMATION WITH THEORY OF OPERATION

# WORK PACKAGE INDEX


Title	Sequence No.
GENERAL INFORMATION	
EQUIPMENT DESCRIPTION	
THEORY OF OPERATION	
REPAIR PARTS, SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT	


# **GENERAL INFORMATION**

#### SCOPE

Type of Manual: Unit Maintenance

**Model Number and Equipment Name:** M548A1/M548A3 - Carrier, Cargo Tracked, 6-Ton **Purpose of Equipment:** Transportation and positioning combat troops and supplies.





The terms left and right as used in this manual are defined as standing at the rear and looking toward the front of the carrier.

### MAINTENANCE FORMS, RECORDS, AND REPORTS

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA Pamphlet 738-750, The Army Maintenance Management System (TAMMS). Forms needed by units maintaining this material are listed in the References work package (WP 0539 00).

### **GENERAL INFORMATION** — Continued

#### **REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR)**

If your M548A1 or M548A3 carrier needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Tell us why a procedure is hard to perform. Put it on an SF 368 (Quality Deficiency Report). Mail it to: Commander, US Army Tank-Automotive Command, ATTN: AMSTA-TR-QCL, Warren, MI 48090. We will send you a reply.

### DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE

See the following technical manuals for information on destruction of Army materiel:

TM 750-244-2 Procedures for Destruction of Electronics Materiel to Prevent Enemy Use.

TM 750-244-6 Procedures for Destruction of Tank Automotive Equipment to Prevent Enemy Use.

TM 750-244-7 Procedures for Destruction of Equipment in Federal Supply Classifications 1000, 1005, 1010, 1520, 2530, 5590, 5595 to Prevent Enemy Use.

### PREPARATION FOR STORAGE OR SHIPMENT

See MIL-C-62015 for information about administrative storage or shipment of the M548A1 and M548A3 and their components.

#### NOMENCLATURE CROSS-REFERENCE

This listing includes nomenclature cross references used in this manual.

Adapter	Nipple, pipe, union
Air vent, personnel	Register, metal: personnel air vent
Assembly	Adapter assembly
Bilge pump	Rotary pump
Breather	Air filter intake
Bulb	Incandescent lamp
Coolant	Antifreeze and water
Coolant gauge	Temp indicator
Detector	Liquid transmitter
Dipstick	Liquid level gauge rod
Drain plug	Pipe plug
Engine oil filter	Fluid pressure filter
Engine oil gauge	Dial pressure gauge
Exhaust collector	Exhaust connection
Fastener	Toggle pin
Fire bottle	Compression gas cylinder
Fluid level detector	Liquid transmitter
Fuel control cable	Fuel control
Fuel filter	Fluid filter
Fuel gauge	Liquid quantity gauge
Fuel tank	Fuel compartment

### **GENERAL INFORMATION** — Continued

Course have	Mashaniaal kausina
Gear box	Mechanical housing
Grease fitting	Lubrication fitting
Hand brake	Parking brake lever
Hinge pin	Headless straight pin
Horn switch button	Push switch
Hub	Support
Indicator light	Indicator lamp
Inlet grille	Intake grille
Jack	Receptacle
Jam nut	Hexagonal nut
Key washer	Locking plates
Link	Plain rod bearing
Lock nut	Self-locking nut
Lock screw	Self-locking bolt
Lock washer	Self-locking washer
Lock wire	Non-electrical wire
Lubrication pump	Hydraulic pump
NBC	Nuclear, biological, and chemical
Plug	Connector
Propeller shaft	Flexible drive shaft
Quick disconnect	Quick coupling shaft
Radio	Receiver-transmitter
Road wheel	Solid rubber wheel
Road wheel arm	Support assembly
Rod	Connecting link
Screen	Metal grille
Screw	Machine bolt
Seat belt	Vehicular safety belt
Shim	Spacer
Shim pack	Spacer assortment
Slave cable	Adapter cable assembly
Splined shaft	Output carrier
Starter switch	Interlock switch
Stop light	Taillight
Stowage box	Vehicular accessory box

### **GENERAL INFORMATION** — Continued

Switch	Circuit breaker
Throttle control cable	Throttle control
Tie strap	Electric tiedown strap
Towing pintle	Pintle hook latch
Turn signal assembly	Vehicle directional light
Universal joint	Universal joint spider

### LIST OF ABBREVIATIONS / ACRONYMS

Many abbreviations are used in this manual. They are listed below. Learn what each one means. It will make your job easier.

•	-
Α	After
В	Before
BATT	Battery
во	Blackout
BRT	Bright
СВ	Circuit Breaker or common battery
COEIL	Components of end items list
CVC	Combat Vehicle Communications
D	During
ENG	Engine
FOV	Field-of-view
GEN	Generator
HI TEMP	High Temperature
Intercom	Intercommunication
IR	Infrared
NBC	Nuclear, biological and chemical
N2	Nitrogen gas
OVE	On Vehicle Equipment
PMCS	Preventive Maintenance Checks and Services
PRESS	Pressure
TEMP	Temperature
TRANS	Transmission
Vent	Ventilation
W	Weekly

### SAFETY, CARE, AND HANDLING

Read warnings in WARNING SUMMARY.

# **EQUIPMENT DESCRIPTION**


### **EQUIPMENT DATA**

For equipment data, characteristics, capabilities, and features, see your -10.

#### LOCATION AND DESCRIPTIONS OF MAJOR COMPONENTS


#### M548A1

The major components of the M548A1 carrier are connected together to form the power train. The diesel engine, transfer gearcase, and automatic transmission form the power plant. The steering control differential, final drives, drive shafts, and universal joints complete the power train. A propeller drive shaft couples the steering control differential to the transmission. Power from the two differential output propeller drive shafts is transferred to the left and right final drives. The final drives turn the track drive sprockets.



### M548A3

The major components of the M548A3 carrier are connected together to form the power train. The power train furnishes and controls the power to drive and steer the carrier. A V6 diesel engine, transmission, connecting propeller shafts and left and right final drives make up the power train. The power plant consists of the diesel engine and automatic transmission. Power developed by the engine is transmitted to the transmission which delivers power through the final drives to the sprockets of the suspension system. The engine and transmission control the speed of power from one side to the other, providing the method of steering the carrier.



### LOCATION OF COMPONENTS - LEFT FRONT VIEW

### NOTE

Lifting eye may be removed if 50 caliber machine gun mount is installed. Cab cover may not be there if M2 machine gun is mounted.




Table 1.
----------

1. Lifting eye	6. Fire extinguisher outside handle
2. Cab cover	7. Fuel filler cap
3. Radiator filler cab (M548A3)	8. Idler wheel
4. Cab hatch cover	9. Road wheel
5. Air intake grille (M548A3)	10. Track

11. Cab door	16. Winch (M548A1)
12. Cab step	17. Vehicle compartment heater (M548A3)
13. Drive sprocket	18. Spare track shoe
14. Towing hooks	19. Pioneer tools
15. Lights	20. Decontamination guard (M548A3)

# LOCATION OF COMPONENTS - RIGHT REAR VIEW




Table 2.

1. Cargo compartment cover	7. Track cover
2. Cargo compartment hatch cover	8. Tailgate
3. Radiator filler cap (M548A1)	9. Towing pintle
4. Front bilge pump outlet (hole in hull)	10. Cargo compartment door
5. Cab door	11. Towing cable
6. Cab step	

### **DIFFERENCES BETWEEN CARRIERS**

This manual covers two different carriers. The major differences can be determined from the chart below.

### DIFFERENCES BETWEEN CARRIERS

Carrier function	M548A1	M548A3
Personnel/Cargo	Х	Х
Winch	Х	
Vehicle compartment heater installation		Х
Special purpose kits:		
Air brake kit	Х	
Caliber .50 machine gun mount kit	Х	Х
Engine heater coolant kit	Х	Х
Material handling kit	Х	Х
M66 ring mount kit	Х	Х
Vehicle compartment heater kit		
Cab (primary)	Х	
Cab (secondary)	Х	Х
Cargo area (primary)	Х	Х
Cargo area (secondary)	Х	Х
7.62 mm machine gun mount kit	Х	Х
Turn signal kit	Х	Х

### **EQUIPMENT DATA**

The following table lists data you may need to perform unit maintenance on M548A1 and M548A3. Other data necessary to operate and service your carrier is listed in -10, PMCS, and RPSTL.

### **EQUIPMENT DATA**

Engine (M548A1)	Characteristics	Metric Equivalents
Manufacturer	Detroit Diesel Engine Corporation	
Model	5063-5299	
Series	6V53	
Туре	two-cycle diesel compression-ignition	
Number of cylinders	6	
Bore	3.875 in	10 cm
Stroke	4.5 in	11 cm

### 0002 00

Piston displacement	3.18 cu/in	5.2 liters
Compression ratio	21:1	
Injectors	M50	
Crankshaft rotation (viewed at pulley)	clockwise	
Compression pressure (minimum) speed 600 rpm, injectors removed)	510 psi	3516 kPa
Firing order	1L-3R-3L-2R-2L-1R	
Cylinder numbering left bank (front-to-rear)	1L-2L-3L	
Cylinder numbering right bank (front-to-rear)	1R-2R-3R	
Idle speed	650 to 700 rpm	
Governed speed (no load) with quick disconnect engaged	2925 to 2975 rpm	
Horsepower	210 at 2800 rpm	
Lubrication (type)	forced feed	
Lubrication pressure (normal at 2800 rpm)	40-60 psi	276 to 414 kPa
Lubricating pump type	rotary	
Stall speed	1900 to 2100 rpm	
Valves	overhead, rocker arm	
Dry weight	1345 lb	611 kg
Engine (M548A3)	Characteristics	Metric Equivalents
Manufacturer	Detroit Diesel Engine Corporation	
Model	5063-5292	
Series	6V53T	
Туре	two-cycle diesel compression-ignition	
Number of cylinders	6	
Idle speed	650-700 rpm	
Horsepower	275 at 2800 rpm	
No-load governor speed	2,925-2,975 rpm	
Crankshaft location (viewed at pulley)	clockwise	
Cylinder number		
Left bank (front-to-rear)	1R-2R-3R	
Right bank (front-to-rear)	21L, 2L, 3L	
Firing order	1L, 3R, 3L, 2R, 2L, 1R	

0002 00

Cooling System (M548A1)	Characteristics	Metric Equivalents
Capacity	9.5 gal	36 liters
Thermostat (closed)	161-169°F	72-76°C
Thermostat (open)	161-189°F	72-87°C
Normal operating temperature (engine)	160-230°F	71-110°C
Radiator cap (auxiliary tank) pressure rating	13-18 psi	90-124 kPa
Cooling System (M548A3)	Characteristics	Metric Equivalents
Capacity	58 quarts (14.4 gallons)	55 liters
Refill	(approx) 9.5 gallons	36 liters
Thermostat range (bypass type)	162-167° to 280-185°F	
Transfer Gearcase (M548A1)	Characteristics	Metric Equivalents
Туре	four helical gears w/power takeoffs	
Transfer ratio	1:1.286	
Dry weight	118 lb	54 kg
Transmission (M548A1)	Characteristics	Metric Equivalents
Manufacturer	Allison Division GMC	Metrie Equivalents
Model	TX 100-1	
Туре	Straight through, torque converter, planetary gear, automatic	
Drive ranges	reverse, neutral, 2-3, 1-3, 1-2, 1	
Dry weight	309 lb	140 kg
Transmission (M548A3)	Characteristics	Metric Equivalents
Manufacturer	Allison Transmission Division, GMC	
Model	X-200-4	
Туре	Hydromechanical cross drive	
Rating		
Input horsepower (max)	275	
Input speed	2975 rpm	

Hydraulic torque converter		
Туре	Single stage, thre element, polyphase	
Stall torque ratio	3.32:1	
Lockup clutch	Automatic second through fourth range	
Gearing type	Constant mesh, spur type, planetary	
Ranges	Four forward, one reverse	
Ratios		
First	4.16:1	
Second	2.34:1	
Third	1.46:1	
Fourth	1.04:1	
Reverse	6.62:1	
Steering Type	Infinitely variable hydrostatically controlled differential	
Range	Minimum Steer Ratio	
First	2.31:1	
Second	1.58:1	
Third	1.32:1	
Fourth	1.22:1	
Neutral	Pivot	
Brakes		
Туре	Multiple wet plate	
Service apply	Dydraulic with mechanical actuation	
Parking/emergency apply	Mechanical back-up service brakes	
Deceleration Rate	16 ft/sec/sec	5 m/sec/sec
Oil System		
Capacity	12 gallons	45 liters
Sump	Integral	
Filter	Integral, two stage with differential pressure warning switch and automatic bypass	
Weight (dry)	975 lb	443 kg
with container	Approximately 1500 lb	681 kg

0002 00

Steering Control (M548A1)	Characteristics	Metric Equivalents
Model	DS200	
Suspension	3-point	
Rating		
Input (maximum)	4675 lb-ft	6339 N•m
Input (maximum)	3825 rpm	
Net input (maximum)	215 hp	
Rotation		
Input shaft (in forward range)	clockwise	
Left output shaft (in forward range)	clockwise	
Right output shaft (in forward range)	counterclockwise	
Steering control (internal)	mechanical brakes	
Bevel gear ratio	1.28:1	
Suspension:		
Torsion bars	5 each side	
Shock absorbers, hydraulic, direct action	3 each side	
Road arm bumpers	3 each side	
Idler wheels	1 each side	
Sprocket wheels	1 each side	
Idler assemblies	1 each side	
Road wheels:		
Туре	Aluminum disk with solid rubber tires (steel discs optional)	
Quantity	20 (10 duals)	
Size	24 in dia x 2 1/8 in wide	61 cm dia x 5 cm wid
Support assembly, road wheel	5 each side	
Track, flat, single pin, (removable rubber pads)		
Model	T130 5 1/4 in	13 cm
	T130E1 4 3/4 in	12 cm
Tread (centerline to centerline of tracks)	85 in	38 cm
Number of shoes (new)	66 each side	
Width	15 in	38 cm
Tension (between track and 2nd road wheel)	3/8-5/8 in	10-16 mm

### TM 9-2350-247-20-1

0002 00

		Matrix Daniel 1
Electrical System	Characteristics	Metric Equivalents
Batteries	NEE2140 1 (C140 01 210 10C4)	
Туре	M552149-1 (6140-01-210-1964)	
Voltage (M548A1)	24 Vdc (two 12-volt in series)	
Voltage (M548A3)	24 Vdc (four 12-volt in series/parallel)	
Generator (M548A1) 100 amp		
Manufacturer	Leece Neville (2920-00-782-1955)	
Model	2184A	
Generator 200 AMP (M548A3)		
Manufacturer	Leece Neville (2920-01-238-9710)	
Model	A0012266AA	
Manufacturer	C.E. Niehoff and Co. (2920-01-292-2993)	
Model	N1206	
Manufacturer	Prestolite Electric (2920-01-292-2994)	
Model	AMZ-4001	
Starter		
Manufacturer	Delco Remy Division GMC	
Model	16764-11663416 (MS53011-4)	
Optional manufacturer	Prestolite	
Model	11668641 (MS50311-4)	
Optional manufacturer	Leece Neville	
Model	12253404 (MS53011-4)	
Туре	4-pole, 24 Vdc	
Brushes	8	
Rotation (viewed from drive end)	clockwise	
Type of engagement	shift lever solenoid plunger	
Internal wiring	series	
Engine low oil pressure switch (transmitter) breaks contact at	9-13 psi	62-90 kPa
Differential high oil temperature switch (transmitter) (M548A1) closes at	$305^{\circ}F + 5^{\circ}$	152°C
Transmission high oil temperature switch (transmitter) closes at	$305^{\circ}F + 5^{\circ}$	152°C

EQUIPMENT DESCRIPTION — Cont	inued		0002
Winch (M548A1)		Characteristics	Metric Equivalents
Weight			
Complete	444 lb		202 kg
Less wire rope	313 lb		142 kg
Winch Transfer Gearcase			
Manufacturer	FMC		
Weight	21 1/2 lb		9.8 kg
Vehicle Compartment Heater Kit (Primary)		Characteristics	Metric Equivalents
Heater (South Wind)			
Manufacturer	Stewart-Warner		
Model	8460C24		
Part number	7748716		
Operating voltage	20.0-28.5 Vdc		
Current consumption above 30°F (1°C)			
Start	16.5 amp		
Run	10.0 amp		
Current consumption below 30°F (1°C)			
Start	20.0 amp		
Run	13.5 amp		
Heat output			
High heat	60,000 Btu		63,300 J
Low heat	30,000 Btu		31,650 J
Fuel pressure requirement	3-15 psi		21-103 kN/sq cm
Overheat switch setting (maximum)	475°F		246°C
Height	24 1/8 in		61 cm
Diameter (nominal)	8 in		20.3 cm
Width (maximum)	13 in		33 cm
Weight	32.75 lb		14.9 kg
Heater (Perfection)			
Manufacturer	Hupp		
Model	MF510A		
Part number	11601809		
Operating voltage	20-28.5 Vdc		

Current consumption above 30°F (1°C)		
Start	15 amp	
Run	9.5 amp	
Current consumption below 30°F (1°C)		
Start	19.5 amp	
Run	17 amp	
Heat output		
High heat	60,000 Btu	63,300 J
Low heat	30,000 Btu	31,650 J
Fuel pressure requirement	3-15 psi	21.0-103.0 kN/sq cm
Overheat switch setting (maximum)	475°F	246°C
Height	24 1/8 in	61 cm
Diameter (nominal)	8 in	20.3 cm
Width (maximum)	13 in	33 cm
Weight	31 lb	14 kg
Fuel pump		
Part number	MS5132-2 (96906)	
Output pressure	3-6 psi	21.0-41.0 kN/sq cm
Control box		
Part number	7748721 (19207)	
Part number (optional control box)	10947220 (19207)	
Fuel		
Usable fuel	Any hydrocarbon fuel at temperature down to cloud point except DFA down to $-65^{\circ}F$	-54°C
Engine Coolant Heater Kit	Characteristics	Metric Equivalents
Manufacturer	Stewart-Warner	
Model	939-J24	
Part number	11601698	
Heat output (surrounding air temperature)	$70^{\circ}$ F	21°C
Coolant		
High heat	15,000 Btu/hr	4.4 kW/hr
Low heat	8,000 Btu/hr	2.3 kW/hr
Exhaust		
High heat	8,000 Btu/hr	2.3 kW/hr

EQUIPMENT DESCRIPTION — Continu	led	0002 0
Low heat	4,500 Btu/hr	1.3 kW/hr
Operating temperature range (surrounding)	$-65^{\circ}$ to $+100^{\circ}$ F	$-54^{\circ}$ to $+38^{\circ}$ C
Electrical requirements		
Operating voltage range	20-28.5 V	
Amperes draw (maximum above)	30°F	-1°C
Start	12.0 amp	
Run	3.5 amp	
Amperes draw (maximum below)	30°F	-1°C
Start	15.0 amp	
Run	3.5 amp	
Performance		
Fuel	grades DF-2, DFA, JP-5, JP-8	
Fuel flow rate		
High flow (normal)	0.021-0.031 lb/min	0.010-0.015 kg/min
Low flow (normal)	0.008-0.014 lb/min	0.004-0.007 kg/min
Fuel pressure (at fuel valve inlet)	3-15 psi	21-103 kN/sq cm
Fuel pump output pressure	3-6 psi	21-41 kN/sq cm
Temperature settings		
Overheat thermostat (opens)	245°F	118°C
Restriction thermostat		
Opens	220°F	104°C
Closes	190°F	88°C
Dimensions and weight		
Height	9 /12 in	34 cm
Length	15 5/16 in	38 cm
Width	6 3/4 in	17 cm
Weight	15 lb	7 kg
Operating capacity	Must be capable of operating against 0.75 in H2O exhaust restriction	19 mm H2O
Coolant pump		
Manufacturer	MP Pumps	
Model	12245	
Part number	10160875	
Electrical requirements		
Operate voltage range	20-28.5 V	

### TM 9-2350-247-20-1

### EQUIPMENT DESCRIPTION — Continued

#### 0002 00

Ampere draw	2.0 amp	
Output	12-13 gpm	45-49 liter/min
Weight (maximum)	10 lb	5 kg
Air Brake Kit (M548A1)	Characteristics	Metric Equivalents
Compressor		
Manufacturer	Bendix-Westinghouse (P/N 11634086)	
Maximum operating speed	2,400 rpm	
Air delivery	100 psi	689 kN/sq cm
Weight	24 lb	11 kg
Nominal rating	7 1/4 cfm at 1,250 rpm	0.2 cm m at 1,250 rpm
Reservoir		
Manufacturer	Midland Steel Bendix-Westinghouse	
Maximum hydrostatic pressure	250 psi	1724 kN/sq cm
Air capacity	1.1 cu in	0.03 cu m
Safety valve		
Manufacturer	Bendix-Westinghouse Midland-Ross	
Type valve	Spring-loaded ball check valve	
Blowoff pressure	150 psi	1034 kN/sq cm
Panel Assembly		
Manufacturer	FMC	
Air pressure gauge	0-120 psi	0-827 kN/sq cm
Air Brake Treadle Valve		
Manufacturer	Bendix-Westinghouse Automotive Air Brake	
1st 3 degrees travel	5 psi	34 kN/sq cm
2nd 17 degrees travel	Graduating range 5-75 psi	34 kN/sq cm
Stop light switch		
Manufacturer	Bendix-Westinghouse	
Type of switch	Electro-pneumatic	
Point closing pressure	5 psi	34 kN/sq cm
Low Pressure Indicator		
Manufacturer	Bendix-Westinghouse	
Type of switch	Spring-loaded rubber diaphragm	
Point closing pressure	54-66 psi	372-455 kN/sq cm
Governor		

Manufacturer	Bendix-Westinghouse	
Cutout pressure	100-105 psi	689-724 kN/sq cm
Cut-in pressure	80-85 psi	552-586 kN/sq cm
Material Handling Kit	Characteristics	Metric Equivalents
Material Handling Kit	P/N 11633807	
Beam:		
Туре	6 in x 4.3 lb per foot I-beam	15 cm x 2 kg per m I-beam
Length	158 3/8 in	402 cm
Weight	57 lb	26 kg
Hoist		
Capacity	1,500 lb	681 kg
Net weight	80 lb	36 kg
I-beam (minimum)	5 in x 3 in flange	13 x 8 cm
I-beam (maximum)	12 in x 5 in flange	30 x 13 cm
Chain length needed to lift load 1 foot	27.2 ft	8 m
Chain pull to lift capacity load	58 lb	26 kg
Hand chain drop	7 ft	2 m

Refer to your -10 for equipment data on caliber 0.50 or 7.62 mm machine gun mount kit and M66 ring mount kit. Refer to your RPSTL for equipment data on turn signal kit.

#### 0002 00

## METRIC EQUIVALENTS

Metric equivalents are used throughout this manual. Metric symbols and units are:

# **Metric Equivalents**

SYMBOL	UNIT
С	Celsius
сс	cubic centimeter
cm	centimeter
j	joule
kg	kilogram
kg/min	kilogram per minute
km	kilometer
km/h	kilometer per hour
kPa	kilopascal
kw hr	kilowatt hour
1	liter
m	meter
mm	millimeter
N•m	Newton-meters

# THEORY OF OPERATION

### SCOPE

This section describes how major systems and components of the carrier operate. An understanding of how each part functions in a system and how components relate to each other will help solve possible maintenance problems with the carrier.

### INTEGRATED SYSTEMS AND COMPONENTS

### **POWER PLANT**


The M548A1 power plant consists of the diesel engine, transfer gearcase, and transmission. The M548A3 power plant consists of the diesel engine and hydromechanical cross drive transmission. The fuel, exhaust, cooling, starter, generator, and engine air systems are support systems for the power plant.

Engine power is supplied by a liquid cooled, 6–cylinder, V-type, compression ignition (diesel) unit. Starting is by a heavy duty 24 V starter. Engine is protected from low oil pressures and high temperatures by transmitters in the oil and cooling systems which activate warning light circuits.


The M548A1 transfer gearcase transfers power from the engine flywheel to the transmission torque converter through four gears at a ratio of 1 to 1.286. An engine disconnect allows the engine to operate independently of the rest of the power plant. A power takeoff within the transfer gearcase drives the cooling fan through a pulley and drive belts. Another power takeoff within the transfer gearcase drives the 100 amp generator through a pulley and drive belts. A third power takeoff within the transfer gearcase drives the winch.

The M548A1 transmission is a three speed, constant mesh, planetary gear train with hydraulic torque converter and lockup clutch. It automatically selects the proper gear based on road and load conditions and range selected. The transmission delivers power from the transfer gearcase to the differential.

The M548A3 diesel engine delivers power directly to a hydromechanical cross drive transmission with hydrostatic steering. This transmission delivers power from the engine to the left and right final drives through the propeller shafts. The final drives power the drive sprockets in the suspension system. This transmission has its own oil system with filters and separately mounted engine and transmission oil cooler. The transmission oil system is separate from the engine oil system. The 200 amp generator and cooling fan are engine driven with drive belts and pulleys.



0003 00




#### OIL COOLING SYSTEM COMPONENTS - ENGINE, TRANSMISSION, AND DIFFERENTIAL


The M548A1 engine, transmission, and differential oil cooling systems keep the oil clean and within proper operating temperature range. The components of the system are the engine, transmission, and differential oil cooler unit is mounted on the engine. By circulating the hot oil through this unit, heat is given off to the surrounding engine coolant. Engine coolant is in turn cooled by the engine cooling system.

Oil cleanliness is maintained by circulating engine oil through the engine oil filter and differential oil through the differential oil filter. Transmission oil is cleaned by the transmission oil filter which is an integral part of the transmission.

Differential oil pump is mounted on the transfer gearcase. It pumps oil from the bottom of the differential housing to the differential oil filter. Oil flows through the filter and cooler and back to top of differential. a power takeoff within the transfer gearcase drives the differential oil pump.

The M548A3 oil system provides lubrication for the engine. Oil is cycled throughout the engine by an engine oil pump. An oil filter cleans the oil, and engine oil cooler reduces oil temperature. The transmission oil system is incorporated in the hydromechanical cross drive transmission.







### FUEL SYSTEM

The M548A1 fuel compartment is located at the rear of the carrier under the cargo compartment deck. Two electric fuel pumps supply fuel through fuel supply lines from the fuel compartment to an air separator tank. From the air separator tank, the engine fuel pump draws the fuel through the primary fuel filter. The engine fuel pump forces the fuel through the secondary fuel filter to the engine fuel injectors. It then returns surplus fuel through the air separator tanks and fuel return lines to the fuel compartment. Fuel for the air box heater is drawn from the secondary fuel filter. Quick disconnect fuel couplings are used to connect the supply and return lines to the engine. The fuel compartment is filled through a fuel filler at the left rear of the carrier and is drained through a fuel drain under the center tailgate hinge. The entire system is vented by tubes located at the right rear corner of the carrier and the fuel filler tube.

The air box heater preheats air entering the engine cylinders with an electric air pump, fuel pump, and igniter. This improves fuel ignition at low temperatures. Fuel is sprayed into the cylinder block air box and ignited to preheat incoming air.


The M548A3 fuel compartment and components are similar to M548A1. Only the front of carrier and its components are shown.






### AIR INDUCTION AND EXHAUST SYSTEMS

Air for M548A1 engine combustion is drawn and filtered through an air cleaner container mounted on the transverse beam. Air enters the air cleaner through an opening in the head and filters through the air cleaner filter element. It then flows into the engine blower through an engine air intake horn between the engine air intake and air cleaner. The restriction indicator hose connects to the air cleaner indicator in the cab area. When the air cleaner element gets too dirty or dusty, the restriction of air causes the air cleaner indicator to register the change. Air is discharged at the opposite side of the engine blower, creating air pressure in the air box under the engine blower. Pressurized air blows through ports in the engine cylinders. Exhaust gases are removed and fresh air for combustion is supplied.







#### **EXHAUST SYSTEM AND COMPONENTS**

Burned fuel fumes from M548A1 carriers are exhausted through the right and left crossover pipes, into the muffler, and out the exhaust pipe. The crossover pipes extend from the rear of the right and left exhaust manifolds to the main exhaust pipe. The crossover pipes are joined together by sliding joints with a ball-and-socket type joint on the main exhaust pipe.

The exhaust muffler is bolted in the power plant compartment on the M548A1. An exhaust pipe (exhaust stack assembly) extends above the top of the exhaust well on both carriers. The exhaust pipe has a guard and a cap.

The M548A3 major exhaust system parts are the turbocharger, exhaust manifolds, and muffler. The turbocharger is driven by exhaust gases from the engine. The turbocharger helps the engine develop more power and operate more efficiently. The exhaust manifolds carry the exhaust gases to the turbocharger from the engine. The muffler cuts down engine noise and allows exhaust to escape outside the carrier.







### **COOLING SYSTEM**

The M548A1 and M548A3 cooling system consists of a radiator, engine coolant pump, thermostat, engine, transmission and differential (M548A1) oil cooler, and connecting hoses and clamps. A fan assembly provides fresh air for the engine air intake and power plant cooling systems. The fan drive belt set connects the power from the fan drive shaft (M548A1) to the fan assembly. The belt set is a matched set. If one or more belts are bad, the whole set needs to be replaced.

The fan and radiator are mounted on the right side of the power plant compartment. The engine coolant pump, thermostat, and oil cooler are integral components of the engine assembly. The coolant filler cap is where the engine coolant is filled. Coolant is drawn by the pump from the bottom of the radiator and circulated through the oil cooler, cylinder block, and cylinder heads to the thermostat housing and back to top of radiator. The thermostat is a full bypass-type with a range of 161°  $- 169^{\circ}F(72^{\circ} - 76^{\circ}C)$  for the M548A1 and  $181^{\circ} - 189^{\circ}F(83^{\circ} - 87^{\circ}C)$  for the M548A3. The deaeration elbow helps to remove air from the coolant system.

The M548A3 radiator auxiliary tank acts as an overflow tank to keep the cooling system from overpressurizing. It also removes air from the engine coolant. There is a low coolant level transmitter to signal the operator if more coolant is needed.





#### M548A1

#### **ELECTRICAL SYSTEM**

A 24 volt direct current system supplies electrical current for the carrier. The M548A1 has two 12 volt wet-cell batteries, with an amperage capability of 100 amps per hour and connected in series. The M548A3 has four 12 volt wet-cell batteries with an amperage capability of 200 amps per hour and connected in series parallel.

The batteries supply the carrier with electricity. The vehicle compartment heater, cargo compartment heater kit, coolant heater kit, and engine starter are connected directly to the carrier batteries. See your -10 for location of all heaters. Electrical power flows from the batteries through the bus bar, cables, and wiring assemblies to the electrical equipment. The hull is a ground for the electrical system.

Battery drain is replenished and system voltage is maintained by an alternating current generator, which has 100 amps per hour capability in the M548A1 carrier and 200 amps per hour capability in the M548A3 carrier. The battery recharge current flow is regulated by the generator-regulator on top of the engine.


There are several electrical subsystems within the hull. Each subsystem contains at least one wiring assembly. A major electrical subsystem with assemblies is exterior lights, which include blackout lights, stoplight, and headlights, and interior lights, which include dome lights and panel lights.

#### GENERATOR

The generator is part of the carrier electrical system. It is driven by the transfer gearcase on the M548A1. On the M548A3, the generator is driven by a pulley on the crankshaft of the engine. The generator charges the batteries in the carrier when the engine is running. A regulator mounted on top of the engine keeps the voltage at correct levels.

### **GENERATOR FIELD SWITCH**

The generator switch is mounted on the secondary fuel filter. When starting the engine, the field switch is open and the generator is not energized to allow the engine to start with less drag. When the secondary fuel filter is pressurized with fuel, the field switch closes and signals the regulator to energize the generator and start charging the batteries.



M548A3

#### DIFFERENTIAL COMPONENTS (M548A1)


The differential consists of three major assemblies. These are the right angle gearbox, steering unit with brake shoes, and two output shafts.


Power flows from the transmission to the right angle gearbox to the steering unit. When driving straight forward, the steering unit delivers equal power to both output shafts. Pressure on either right or left steering lever slows or stops the right or left brake drum inside the center steering unit and reduces the speed of the right or left output shaft. By slowing down one side, the differential action within the steering until increases the speed of the opposite output shaft and causes the carrier to turn in the direction of the applied brake. Pulling with equal pressure, exerted at the same time on both right and left steering levers, applies both brakes and slows or stops the carrier.

Differential is protected from high oil temperatures by a differential overheat switch connected to a warning light in the driver's compartment. The warning light comes on when the oil temperature is too high.

The breather needs to be kept clean and free of oil and dirt. If the breather is plugged, the oil inside the differential will build up pressure and low out a gasket, preformed packing, hose, oil level gauge rod.

The resilient mount reduces shocks to the differential housing. Two lifting eyes are provided for removal and installation of the differential from the carrier.





#### SUSPENSION SYSTEM AND COMPONENTS


The suspension system supports the carrier and delivers engine power to the road. It allows the carrier to maneuver and be stable. Suspension system components are the drive sprockets, tracks, idler wheels, track tension adjuster, road wheels, road wheel arms, torsion bars, and shock absorbers.

The drive sprockets drive the tracks. The M548A1 drive sprockets are powered by left and right final drives from the differential. The M548A3 drive sprockets are powered by left and right final drives from the transmission. The tracks consist of two flexible chains of track shoes. The tracks ride on the drive sprockets and are guided by the road wheels and idler wheels. The idler wheels can be adjusted to maintain correct track tension.

The tracks consist of track pads bolted to track shoes that are linked together by pins to form a continuous track. The tracks, each driven by a track drive sprocket secured to the final drive, provide the surface on which the road wheels roll. Track guides keep the track centered under the road wheels. A track tension adjuster at each track idler wheel is used to adjust track tension. The track tension adjuster cylinders are filled with grease. Rubber bumpers cushion the road wheel arms when the suspension bottoms out in rough terrain.

There are five pairs of road wheels per side. Track center guides fit between each pair of road wheels. Road wheels mount on arms that are individually splined to the torsion bars. The torsion bars extend the width of the hull, are secured by torsion bar anchors bolted to the hull, and act as springs to keep the road wheels on the ground and from hitting the bottom of the carrier.

Shock absorbers stabilize the carrier when operating over rough terrain. Shock absorbers are at each first two road wheels and each rear road wheel.



#### **PIVOT STEERING AND BRAKES (M548A1)**

Pivot steering brakes are disk brakes and work like the differential brakes, but quicker. Only use disk brakes in the water or when stopped. Speeds above 10 mph (16 km/h) damage disk brakes.

#### **AUXILIARY AUTOMOTIVE SYSTEM**

The auxiliary automotive system includes driver controls, vehicle compartment heater, bilge pump, and fire suppression system.

The driver controls regulate the engine, transmission, steering, and braking systems of the carrier.

The fuel shutoff control is used to stop the supply of fuel to the injectors. To start the engine, the driver must push in the fuel shutoff control. The throttle linkages are used to control the engine speed. The gear selector allows the driver to choose the proper gear for the carrier. The steering and braking levers control separate right and left steering brakes in the control differential on M548A1. By pulling the levers, you can slow or stop either track for steering, or both tracks at once for stopping. A lock button at the top of each lever lets you set and lock the brakes for parking. On M548A3, the steering wheel controls steering and pivoting turns. On the M548A3, when the brake pedal and parking brake are applied at the same time they will hold the carrier.

The vehicle compartment heater system provides heat inside the carrier. Major parts are the combination combustion chamber/heat exchanger, blowers, a fuel pump, and an electrical control. The heater operates using diesel fuel pumped from the fuel tank. Fuel is delivered to the combustion chamber from the fuel pump. Outside air is drawn into the combustion chamber by one of the blowers. A blower draws air from the crew compartment into the heater exchanger. The air is warmed by heat created by the combustion process and then returned to the crew compartment.

The electrically driven bilge pump removes water at a rate of 46 gpm (gallons per minute) and other liquids from the hull. Water enters the pump through a screened inlet. The pumps force water out of the carrier through an outlet tube. The bilge pump is controlled by a switch on the driver's panel.

The fire extinguisher system consists of Carbon Dioxide (CO2) cylinders; one fixed and one portable. CO2 can put out fires quickly and effectively. The fixed cylinder is located near the driver's compartment and is operated manually by pulling cables located on top of carrier next to driver's door. The fixed cylinder releases CO2 in the power plant compartment only. The portable fire extinguisher is located in the crew compartment and is manually discharged.

## **KIT INTEGRATED SYSTEMS**

#### SPECIAL PURPOSE KITS

When special purpose kits are installed, their systems and components become integrated with the carrier's systems and components. The carriers may be equipped with any of the following special purpose kits.

#### VEHICLE COMPARTMENT (PRIMARY) KIT (M548A1)

The vehicle compartment (primary) heater kit provides heat for personnel and windshield defrosting in cold weather. The carrier can be equipped with any one of three vehicle compartment heater kits. Each kit includes a heater, fuel system, exhaust system, electrical system, and an air circulating system. Kit I takes in air through a duct in the power plant compartment and has a tubular heat defroster manifold which crosses the width of the cab below the windshields and a duct that supplies heated air to the crew compartment. Kit II takes in cab air through a duct behind the driver's seat and has two defroster ducts, a separate duct to heat the driver's footwell, and a crew compartment heat distribution duct or manifold. Kit III is identical to Kit II except that there is no regulator valve, and two fans with individual on-off switches circulate cab air to the defroster ducts instead of air from the heater.

One of two basic heater models are furnished with the vehicle compartment heater kits. Both heaters are electrically controlled multi-fuel heaters capable of burning any hydrocarbon fuel. Air is drawn in at the top for heating and combustion. Heated air is forced out the bottom. Combustion gases are discharged outside the carrier. The heaters contain an electric glow plug, flame detector switch, and an overheat switch.

All three heater kits have the same fuel, exhaust, and electrical systems. Heater fuel system consists of an electric fuel pump and related fuel lines and fittings. Exhaust system consists of an exhaust pipe which carries exhaust gases outside the carrier. Electrical system consists of a wiring harness and a heater control box, with the Kit III wiring harness also connecting the left and right defrost fans with two on-off control switches.

Air circulating system consists of a two stage blower, hoses and ducts, and an outlet manifold in the cab. In Kits II and III, air is drawn from behind the driver's seat into the heater. In Kit I, air is drawn from the cargo area. Kits I and II have adjustable outlet ducts in the manifold. Kit III has two defrost fans in the system.

## VEHICLE COMPARTMENT (SECONDARY) HEATER KIT (M548A1)

The vehicle compartment (secondary) heater kit is used with the vehicle compartment (primary) heater during extremely cold weather,  $-25^{\circ}$  to  $-65^{\circ}$ F ( $-31^{\circ}$  to  $-54^{\circ}$ C). The kit contains a cab cover, fabric machine gun hatch cover, lower cab insulation and thermal door windows, and seat covers for driver and personnel seats.

#### **ENGINE COOLANT HEATER KIT**

Engine coolant heater kit provides heat for starting the carrier during extreme cold weather operation between  $-25^{\circ}$  and  $-65^{\circ}$ F ( $-31^{\circ}$  and  $-54^{\circ}$ C). Heater warms and circulates the engine coolant through the engine and a battery box heat exchanger which warms the engine block, lubricating oil, and battery electrolyte when the engine is not in operation.

Engine coolant heater produces heat by burning a mixture of fuel and air in a heat exchanger. Air is supplied for combustion by a blower through a connecting tube to the burner air inlet in the heat exchanger. Electrical components are connected to the wiring harness through a bracket mounted terminal strip located on the side of the heater.

Heater has fuel, exhaust, and electrical systems. Fuel system consists of a fuel pump, fuel manifold, fuel control valve, and related fuel lines and fittings. Exhaust system consists of an exhaust pipe with a removal moisture trap, which carries exhaust gases out of the heater. Electrical system consists of a coolant heater control box and a wiring harness which supplies power to heater control box, coolant heater fuel pump, and coolant pump.

Engine coolant heater kit has a coolant circulating system, which consists of an electrically operated coolant pump. The pump circulates coolant through the heater and engine battery box heat exchanger plate and back through the coolant heater.

#### AIR BRAKE KIT (M548A1)

The air brake kit provides regulated, pressurized air to operate the trailer equipment air brakes. The kit's main components are a compressor, reservoir, governor, safety valve, and stop light and air low pressure switches. Other components are a treadle valve pedal, dial-type air pressure indicator and warning light, disconnect and air couplings, and dummy fittings.

Compressor is engine driven and air cooled. It charges a 1,100 cubic inch (0.016 cu m) storage reservoir at the rate of 7 1/4 cfm (0.2 cu M) at an engine speed of 1250 rpm. Air is drawn through a strainer into compressor cylinders, compressed by pistons, and then forced through discharge valves and a hose and a tube into a reservoir.

Reservoir stores pressurized air for brake operation and is a place for air, heated during compression, to cool. Cooling causes oil and water to condense to form an oil-water emulsion.

The governor receives air from the reservoir at one of it reservoir ports. Air acts on the piston and the inlet and discharge valve. When air pressure reaches a cutout setting of the governor, piston and inlet and discharge valve move up. The discharge stem of the inlet passage opens and allows reservoir air to flow by the open inlet valve through a drilled passage in the piston and out to the unloading mechanism in the compressor. Air flows around the piston and acts on an additional area of the piston, assuring full opening of the inlet passage. As air pressure drops to governor cut-in setting, force exerted by air setting spring moves the piston down, which causes the inlet stem of the inlet and discharge valve to set. The discharge passage opens and allows air at the compressor unloader pistons to escape back through the piston and discharge stem and out the discharge port.

A spring-loaded ball check safety valve protects the air brake system against air pressure above 150 psi (1034 kN/sq cm). The valve lifts and lets air discharge if pressure in reservoir rises above 150 psi (1034 kN/sq cm).

The air brake kit has a stop light and air low pressure switches. The stop light switch is an electro-pneumatic switch, which operates in conjunction with the brake valve and stop light and closes the stop light electrical circuit when the brakes are applied. The air low pressure switch is a safety device, which lights a warning light on the air brake instrument panel when reservoir air pressure falls below 60 psi (418 kN/sq cm) and closes electrical contacts on the rubber diaphragm with spring pressure.

Other components are a treadle valve pedal, dial-type air pressure indicator and warning light, disconnect and air couplings, and dummy fittings. Compressed air flow to the towed load is controlled by foot pressure on the treadle valve pedal, which bears down on a plunger in the treadle valve. Treadle valve pressure also actuates the stop light switch. A dial-type air pressure indicator and warning light, which show condition of the air brake system, are on the air brake instrument panel. Disconnect couplings are located on the rear cab bulkhead above the left power plant compartment grille and connect to service and emergency air brake hoses that run along left side of hull to rear of carrier. Two air couplings on the hose ends permit connections to towed equipment brake couplings, are closed by dummy fittings when not in use, and are stowed on the cargo door.

#### **TURN SIGNAL KIT**

Turn signal kit provides directional turn signals and hazard warning lights on the carrier to comply with regulations for highway operation. Turn signal lights are added on front of carrier. Right stop light-taillight is replaced with a dual purpose stop light-taillight. A blackout stop light-taillight is added on right rear of carrier. Reflectors are added on rear of carrier. Trailer light wiring harness is replaced to provide for adaptation of turn signals on any towed load. A control and flasher are added in cab. A wiring harness an leads connect the control, flasher, and lights to carrier lighting system.

#### CARGO AREA (PRIMARY) HEATER KIT

Cargo area (primary) heater kit provides heat for personnel seated in the cargo area. Heater kit contains one of two model heaters: Model 8460C or MF510A. Both heaters are electrically controlled, multi-fuel burning units. Air is drawn at the top for heating and combustion. Heated air is forced out the bottom. Combustion gases are discharged outside the carrier. Heater contains an electric glow plug, detector switch, and an overheat switch. heater has fuel, exhaust, and electrical systems. Fuel system consists of an electric pump and related fuel lines and fittings. Exhaust system has an exhaust pipe, which is enclosed in a two-piece heat guard, with related clamps and brackets. Electrical system consists of a wiring harness and a heater control box.

#### CARGO AREA (SECONDARY) HEATER KIT

Cargo area (secondary) heater kit is used with the cargo area (primary) heater kit during very cold weather  $-25^{\circ}$  to  $-65^{\circ}$ F ( $-31^{\circ}$  to  $-54^{\circ}$ C). Kit consists of an insulated cargo compartment cover, heater exhaust closure cone, an insulated escape hatch cover, foam insulation for cargo door, plywood floor plate covers, and two cloth covers for the personnel seats.

#### **CALIBER .50 MACHINE GUN MOUNT KIT**

Caliber .50 machine gun mount kit consists of ring mount M49A1, four supports, pintle, and cradle. Each front support carries a tray for stowage of an ammo box and straps which secure the ammo boxes. ring mount M49A1 consists of a ring (track), carriage link, backrest, cradle, and ammo box tray. Carriage link and backrest rotate 360° on the ring and can be secured in any position by a hand brake. Cradle is installed in the carriage, mounts the machine gun, and permits 360° of traverse, 80° of elevation, and 20° of depression. Machine gun is fed by a tray supported ammo box mounted on the cradle's left side. A canvas deflector mounted under the carriage deflects ejected cartridges away from the operator.

#### **M66 RING MOUNT KIT**

M66 ring mount kit consists of ring mount M66, four supports, deflector support, cartridge deflector, four straps, and attaching hardware. Two front lifting eyes are stowed on a crossbeam in the cargo compartment. Two front supports are bolted to the lifting eye brackets forward of the windshield. Two rear supports are bolted to brackets on the cab transverse beam. Each front support carries a tray for stowage of an ammo box and straps which secure the ammo boxes.

M66 ring mount consists of a ring mount and a .50 caliber machine gun mount. M66 ring mount can also be used with 7.62 mm machine gun. The ring mount consists of a series of rings rotating on disks, a backrest, ring brake, and a pintle traverse lock. The cartridge deflector and deflector support are attached to the ring mount. The .50 caliber machine gun mount consists of a pintle, cradle equilibrator spring, ammo box tray, and mounting and locking pins.

#### 7.62 MM MACHINE GUN MOUNT KIT

The 7.62 mm machine gun mount kit is used to mount a 7.62 mm machine gun M60 over the carrier cab. Kit consists of a pintle, platform, and cradle and holder. Kit does not contain a cartridge case deflector or tripod stowage bracket. A pintle connects other components of a gun mount to the ring mount assembly. A platform supports the 7.62 mm machine gun and retains the gun with a platform latch. The cradle and holder support and retain a box of 7.62 mm ammo. A screw on the pintle permits adjustment of maximum depression.

#### MATERIAL HANDLING KIT

Material handling kit is used to load and unload cargo. It provides seating for a four man crew and stowage for up to six rifles on the cargo floor. Beam supports are installed on the cargo/over bows and are adjustable. Beam can be set and locked in several positions. Hand operated hoist can be moved and secured in any position on the beam. Bulkhead protector prevents damage to the power plant compartment bulkhead during loading and unloading of cargo.

# **REPAIR PARTS, SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT**

#### COMMON TOOLS AND EQUIPMENT

For authorized common tools and equipment, refer to Modified Table of Organization and Equipment (MTOE) for your unit.

#### SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT

Special tools and support equipment are needed for unit maintenance. They are listed in listed in Repair Parts and Special Tools List (RPSTL) TM 9-2350-247-24P. Common tools and supplements and special tools and fixtures are listed in WP 0541 00.

#### **REPAIR PARTS**

The Maintenance Allocation Chart lists those parts you are authorized to replace at the unit maintenance level. Repair parts for the M548A1 and M548A3 can be ordered from and are listed and illustrated in the Repair Parts and Special Tools List (RPSTL) TM 9-2350-247-24P.

#### SPECIAL PURPOSE KITS

For parts, tools, and equipment in the caliber .50 machine gun mount and M66 ring mount kits, see your -10.

# CHAPTER 2

# UNIT TROUBLESHOOTING PROCEDURES

# WORK PACKAGE INDEX

Title	Sequence_No.
INTRODUCTION TO HOW TO USE TROUBLESHOOTING	
MALFUNCTION/SYMPTOM INDEX WP	
ENGINE OVERHEATS (M548A1)	
ENGINE OVERHEATS (M548A3)	
ENGINE WILL NOT REACH OPERATING TEMPERATURE	
ENGINE DOES NOT CRANK (M548A1)	
ENGINE DOES NOT CRANK (M548A3)	0011 00
ENGINE CRANKS SLOWLY (M548A1)	
ENGINE CRANKS SLOWLY (M548A3)	
ENGINE CRANKS BUT WILL NOT START	0014 00
ENGINE CRANKS BUT WILL NOT START BELOW 40°F (AIR BOX HEATER IS USED)	
ENGINE RUNS ROUGH, STALLS, OR DOES NOT PUT OUT FULL POWER (M548A1)	0016 00
ENGINE RUNS ROUGH, STALLS, OR DOES NOT PUT OUT FULL POWER (M548A3)	0017 00
ENGINE FUEL SYSTEM SCHEMATIC	0018 00
STARTING SYSTEM SCHEMATIC (M548A1)	0019 00
STARTING SYSTEM SCHEMATIC (M548A3)	
AIR BOX HEATER SYSTEM SCHEMATIC	
POWER TRAIN/STEERING/BRAKES/GEAR SELECTION/THROTTLE DIAGRAMS	
100 AMP CHARGING SYSTEM MALFUNCTIONS (M548A1)	
200 AMP CHARGING SYSTEM OPERATIONAL CHECK (M548A3)	0024 00
200 AMP NO CHARGE/REGULATION TROUBLESHOOTING (M548A3)	
200 AMP FULL FIELD CHARGE TROUBLESHOOTING (M548A3)	0026 00
200 AMP OVER VOLTAGE TROUBLESHOOTING (M548A3)	
CONNECT/DISCONNECT 200 AMP GENERATOR TEST KIT (M548A3)	
100 AMP ENGINE CHARGING SYSTEM SCHEMATIC (M548A1)	0029 00
200 AMP ENGINE CHARGING SYSTEM SCHEMATIC (M548A3)	0030 00
HI TEMP DIFF OIL INDICATOR COMES ON (M548A1)	0031 00
HI TEMP TRANS OIL INDICATOR COMES ON (M548A1)	
HI TEMP TRANS OIL INDICATOR COMES ON (M548A3)	0033 00
NO EXTERIOR LIGHTS OPERATE	0034 00
BLACKOUT DRIVE LIGHT DOES NOT WORK	0035 00
SERVICE HEADLIGHTS DO NOT OPERATE	
INFRARED HEADLIGHT(S) DOES NOT OPERATE	
SERVICE AND/OR BLACKOUT STOPLIGHTS MALFUNCTION	0038 00
BLACKOUT STOPLIGHT DOES NOT WORK	0039 00
BLACKOUT MARKER LIGHT(S) AND/OR TAILLIGHT(S) DO NOT OPERATE	
SERVICE TAILLIGHT DOES NOT OPERATE	0041 00

# **CHAPTER 2**

# UNIT TROUBLESHOOTING PROCEDURES

# WORK PACKAGE INDEX (Continued)

Title	Sequence No.
SERVICE STOPLIGHT DOES NOT WORK	
TRAILER LIGHTS DO NOT OPERATE	0043 00
HORN DOES NOT OPERATE	0044 00
INSTRUMENT PANEL ILLUMINATION LIGHTS MALFUNCTION	0045 00
LOW PRESS ENGINE OIL INDICATOR FAILS TO GO OFF AFTER ENGINE STARTS	0046 00
TRANS LOW OIL PRESS INDICATOR COMES ON (M548A3)	0047 00
DOME LIGHT WORKS IMPROPERLY	0048 00
MASTER SWITCH ON INDICATOR DOES NOT LIGHT	0049 00
FUEL LEVEL INDICATOR MALFUNCTIONS	
HIGH BEAM INDICATOR LIGHT MALFUNCTIONS	0051 00
BATTERY/GENERATOR INDICATOR MALFUNCTIONS	0052 00
COOLANT TEMPERATURE GAUGE MALFUNCTIONS	0053 00
LO PRESS ENGINE OIL INDICATOR MALFUNCTIONS	0054 00
TRANS LOW OIL PRESS INDICATOR MALFUNCTIONS (M548A3)	0055 00
HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A1)	
HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A3)	
HI TEMP DIFF OIL INDICATOR MALFUNCTIONS (M548A1)	0058 00
TRANS OIL HI DIFF PRESS INDICATOR MALFUNCTIONS (M548A3)	0059 00
WINDSHIELD WIPER DOES NOT OPERATE	0060 00
INSTRUMENT PANEL INDICATORS SCHEMATIC (M548A1)	0061 00
INSTRUMENT PANEL INDICATORS SCHEMATIC (M548A3) (SHEET 1 OF 2)	
INSTRUMENT PANEL INDICATORS SCHEMATIC (M548A3) (SHEET 2 OF 2)	0063 00
ELECTRICAL SYSTEM SCHEMATIC	0064 00
TURN SIGNAL LAMP, STOPLIGHT OR CONTROL LIGHT DOES NOT LIGHT OR FLASH WHEN CONTROL IS IN RIGHT OR LEFT TURN POSITION	0065 00
TURN SIGNAL LAMPS AND STOPLIGHTS DO NOT FLASH WITH CONTROL IN	
HAZARD POSITION	
IN LEFT OR RIGHT TURN SIGNAL POSITION, INDIVIDUAL LIGHT DOES NOT FLASH	
STEERING/BRAKES MALFUNCTION (M548A1)	
CARRIER DOES NOT MOVE IN ANY SHIFT LEVER POSITION (M548A1)	
TRANSMISSION SYSTEM SCHEMATIC (M548A3)	
CARRIER DOES NOT MOVE IN ANY SHIFT LEVER POSITION (M548A3)	
CARRIER DOES NOT PIVOT (M548A1)	0072 00
TRANSMISSION DOES NOT PIVOT STEER (M548A3)	0073 00
CARRIER MOVES WITH TRANSMISSION IN SL (M548A3)	
CARRIER DRIFTS OR DOES NOT STEER (M548A3)	0075 00
SERVICE AND/OR PARKING BRAKE WILL NOT HOLD CARRIER (M548A3)	0076 00
TRANSMISSION WILL NOT UPSHIFT OR SHIFTS ERRATICALLY IN 1-4 POSITION (M548A3)	

# CHAPTER 2

# UNIT TROUBLESHOOTING PROCEDURES

# WORK PACKAGE INDEX (Continued)

Title	Sequence_No.
TRANSMISSION DOES NOT DOWNSHIFT IN 1-4 POSITION (M548A3)	0078 00
TRANSMISSION DOES NOT HOLD 1ST POSITION (M548A3)	
TRANSMISSION DOES NOT HOLD 2ND POSITION (M548A3)	0080 00
TRANSMISSION DOES NOT HOLD 3RD POSITION (M548A3)	0081 00
TRANSMISSION DOES NOT REVERSE (M548A3)	0082 00
BILGE PUMP SYSTEM SCHEMATIC	0083 00
FRONT BILGE PUMP AND/OR LIGHT DOES NOT OPERATE	0084 00
VEHICLE COMPARTMENT HEATER MALFUNCTIONS	
COOLANT HEATER MALFUNCTIONS	0086 00
SPEEDOMETER MALFUNCTIONS	0087 00
TACHOMETER MALFUNCTIONS	
WINCH CASE OVERHEATS (M548A1)	0089 00
WINCH DRUM DOES NOT TURN WITH DRUM CLUTCH IN "CLUTCH IN" POSITION (M548A1)	0090 00
WINCH DRUM DOES NOT TURN DRUM CLUTCH IN "CLUTCH OUT" POSITION (M548A1)	
WINCH BRAKE DOES NOT HOLD (M548A1)	
POWER TAKEOFF DOES NOT ENGAGE WHEN WINCH CONTROL IS ACTUATED (M548A1)	
EXCESSIVE OIL LEAKS (WINCH TRANSFER GEARCASE AND POWER TAKEOFF) (M548A1)	
WINCH PROPELLER SHAFT NOISY DURING OPERATION (M548A1)	009500
COMPRESSOR AIR OUTPUT ADEQUATE, BUT NO AIR PRESSURE INDICATION ON PANEL AIR BRAKE PRESSURE INDICATOR (M548A1)	
LOW AIR PRESSURE WARNING LIGHT DOES NOT LIGHT WHEN AIR PRESSURE FALLS BELOW 60 PSI (414 KPA) (M548A1)	
COMPRESSOR DOES NOT MAINTAIN AIR PRESSURE (M548A1)	0098 00
TOWED LOAD BRAKES DO NOT OPERATE WHEN PEDAL IS PRESSED; AIR PRESSURE	
ADEQUATE (M548A1)	
TOO MUCH OIL DRAINAGE FROM RESERVOIR DRAIN COCK (M548A1)	0100 00
TOO MUCH FOREIGN MATTER IN RESERVOIR (M548A1)	0101 00
COMPRESSOR OPERATION TOO NOISY (M548A1)	0102 00
PARTICULATE PRECLEANER MOTOR DOES NOT WORK (M548A3)	0103 00
M3 HEATER DOES NOT WORK (M548A3)	0104 00
NO AIR FLOW AT ONE OR MORE OUTLETS (M548A3)	0105 00
LOW AIR FLOW AT ALL OUTLETS (M548A3)	0106 00
INTRODUCTION STE/ICE–R (SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES-REPROGRAMMABLE) PROCEDURES	0107 00
STE/ICE-R CHARGING CIRCUIT TROUBLESHOOTING	0108 00

# **CHAPTER 2**

# UNIT TROUBLESHOOTING PROCEDURES

# WORK PACKAGE INDEX (Continued)

Title	Sequence No.
STE/ICE-R STARTER CIRCUIT TROUBLESHOOTING	
STE/ICE-R LOW OIL PRESSURE TROUBLESHOOTING	0110 00
STE/ICE-R BATTERY TROUBLESHOOTING	0111 00
STE/ICE-R ENGINE WILL NOT CRANK TROUBLESHOOTING	0112 00
STE/ICE-R ENGINE WILL CRANK BUT WILL NOT START TROUBLESHOOTING	0113 00
HOOK UP/REMOVE STE/ICE-R FOR POWER	0114 00
HOOK UP/REMOVE STE/ICE-R FOR ENGINE RPM	0115 00
HOOK UP/REMOVE STE/ICE-R FOR STARTER CIRCUIT TESTS	0116 00
HOOK UP/REMOVE STE/ICE-R TEST SET FOR TEST NUMBERS 72 THRU 75	0117 00
STE/ICE-R TEST 01 DISPLAY ENGINE RPM WITH NEXT MEASUREMENT	0118 00
STE/ICE-R TEST 10 ENGINE RPM	
STE/ICE-R TEST 13 POWER (PERCENT)	
STE/ICE-R TEST 14 COMPRESSION UNBALANCE (POWER CABLE)	0121 00
STE/ICE-R TEST 67 BATTERY VOLTAGE	0122 00
STE/ICE-R TEST 72 STARTER CURRENT (FIRST PEAK)	0123 00
STE/ICE-R TEST 73 BATTERY RESISTANCE — STE/ICE-R TEST 75 BATTERY RESISTANCE CHANGE (PACK)	0124 00
STE/ICE-R TEST 74 STARTER CIRCUIT RESISTANCE	
STE/ICE-R TEST 90 DC CURRENT 0 TO 1500 AMP	0126 00

# INTRODUCTION TO HOW TO USE TROUBLESHOOTING

#### PURPOSE

The purpose of unit maintenance level troubleshooting is to diagnose carrier problems which are reported to unit maintenance. Troubleshooting tasks in this manual are common to all carriers except where indicated. You should not begin unit maintenance troubleshooting until all operator troubleshooting procedures have been completed. You will perform four actions in unit maintenance troubleshooting:

- (1) Before starting a troubleshooting task, verify that the reported problem is present in the carrier.
- (2) After verifying the symptom, find the part that is causing the problem.
- (3) Replace or adjust that part.
- (4) Check to make sure the problem no longer exists, and that there are no other problems.

#### DEFINITIONS AND DESCRIPTIONS OF TROUBLESHOOTING PROCEDURES

Troubleshooting tasks always have a beginning and an end. You will use task steps, test procedures, indexes, maintenance tasks, and other technical manuals to troubleshoot. Troubleshooting uses the following terms that are not used in other kinds of tasks:

1. FAULT:	The part that is not operating correctly and is causing the problem.
2. SYMPTOM:	The problem reported to unit maintenance.
3. VERIFY NO FAULTS FOUND:	After you have completed the corrective action, you must verify that no faults exist. If the fault condition still exists, then the fault is not fixed or there is another fault. If this happens, start at the beginning of the troubleshooting procedure until you find and correct all faults. Always operate the system and/or carrier to make sure that you have corrected the reported problem. If troubleshooting does not identify a faulty part, the carrier is defective beyond the level of unit maintenance.
4. LIGHT BULB CHECK:	In troubleshooting tasks checking indicator lights, light bulb is good if multimeter indicates any continuity.

#### TROUBLESHOOTING BASICS

## **Troubleshooting Procedure**

A troubleshooting procedure serves as a starting point for your troubleshooting work. You will branch in and out of procedures as you work to find a fault. Also, you will correct the fault and check that the fault has been corrected. The parts of a troubleshooting procedure are given below.

Legend	
1 TITLE	This is the name of the procedure.
2 INITIAL SETUP	This tells you the tools, materials/parts, personnel, references, and equipment conditions needed to do the procedure.
3 TASK STEPS	These boxes give you step-by-step instructions.
4 ILLUSTRATIONS	These help you locate and identify parts.
<b>5</b> QUESTIONS	This is the last step in YES blocks. The answer to this question will direct you to the next block.
6 REFERENCE LETTER	This will send you to the correct block to continue with the troubleshooting procedure.

# INTRODUCTION TO HOW TO USE TROUBLESHOOTING—Continued

## Locating the Correct Troubleshooting Procedure

- (1) Carrier arrives at shop.
- (2) Read DA form 2404.
- (3) Verify that the problem on DA form 2404 exists.
- (4) Look up the carrier symptom in Troubleshooting Task Index, (WP 0006 00), in this chapter and go to that task.

## **Doing the Troubleshooting Procedure**

- (1) Make sure you have all items in INITIAL SETUP.
- (2) Perform required action(s) in Equipment Conditions.
- (3) Complete the first block of task steps.
- (4) Refer to system schematic or diagram for system components, detail, and clarification.
- (5) Answer the question at the bottom of the first block.
- (6) Follow YES or NO arrows to the next block.
- (7) Move from block to block. Answer questions and follow instructions. You may be directed to:
  - do further checks and tests on parts;
  - go to another manual and do tasks;
  - or go to another task in this manual.

# NOTE

# After completing the actions called for on another page or manual, return to the point in the troubleshooting procedure where you left off.

- (8) Locate the fault in the carrier or part and perform the corrective action.
- (9) Check to make sure fault is corrected and no new faults are found.
- (10) Button up by installing items in Equipment Conditions after finishing the troubleshooting task.

#### INTRODUCTION TO HOW TO USE TROUBLESHOOTING—Continued

#### TROUBLESHOOTING SAMPLE

The following description takes you through a typical troubleshooting procedure.

#### Finding the Right Troubleshooting Procedure

A carrier arrives at the shop. The DA form 2404 shows that the engine cranks but will not start. Engine cranks but will not start is part of the carrier Engine System. Therefore, you look up engine cranks but will not start listed under Engine System in Troubleshooting Task Index, (WP 0006 00), in this chapter.

Check title to make sure you are troubleshooting the correct system for the problem. Next, read the INITIAL SETUP carefully. Make sure you have all the items listed in the INITIAL SETUP. Some access steps in Equipment Conditions may not need to be performed depending on the fault location. The INITIAL SETUP also includes tools and references. In instances where STE/ICE-R troubleshooting may be more advantageous and time saving for the user, cross references to (WP 0107 00), STE/ICE-R troubleshooting, are given under references. (WP 0107 00) contains references to standard troubleshooting procedures. It's up to you to decide which are necessary for your particular problem.

Now you're ready to begin troubleshooting. Look at the first block. Do step 1. Does bilge pump fail to come on? If the answer is NO. Follow the NO arrow to the reference indicated. If the answer is YES. Follow the Yes arrow to the next box. Do steps 1 through 3. Let's say the multimeter reads 17 volts. The answer to the question, "Does multimeter read more than 17 volts," is NO. Follow the NO arrow to the reference indicated. Lets say the multimeter reads more than 17 volts. The answer to the question, "Does multimeter read more than 17 volts," is YES. Follow the YES arrow to the next box.

Follow the YES box on the following page. Do steps 1 and 3. In this sample, let's say the multimeter reads more than 1/2 volt. The answer to step 3 is NO. Follow the NO arrow to the the reference indicated.

The NO arrow takes you to the next box. This box gives you the step to correct the fault. Do step 1. It tells you to go to another task in the manual. Go to the page shown and perform the task. Return to this box when you have completed the task. Step 2 in this box is "Verify no faults found." You must check to make sure you have correctly fixed the fault.

After no faults found has been verified, return carrier to operation. This is the end of the troubleshooting sample.

# MALFUNCTION/SYMPTOM INDEX WP

## **ENGINE SYSTEM**

ENGINE OVERHEATS (M548A1) ENGINE OVERHEATS (M548A3)	WP 0007 00
ENGINE OVERHEATS (M548A3)	
ENGINE WILL NOT REACH OPERATING TEMPERTURE	WP 0009 00
ENGINE DOES NOT CRANK (M548A1)	WP 0010 00
ENGINE DOES NOT CRANK (M548A3)	
ENGINE CRANKS SLOWLY (M548A1)	
ENGINE CRANKS SLOWLY (M548A3)	
ENGINE CRANKS BUT WILL NOT START	
ENGINE CRANKS BUT WILL NOT START BELOW 40°F (AIR BOX	
HEATER IS USED)	WP 0015 00
ENGINE RUNS ROUGH, STALLS, OR DOES NOT PUT OUT FULL	
POWER (M548A1)	WP 0016 00
ENGINE RUNS ROUGH, STALLS, OR DOES NOT PUT OUT FULL	
POWER (M548A3)	WP 0017 00
ENGINE FUEL SYSTEM SCHEMATIC	WP 0018 00
STARTING SYSTEM SCHEMATIC (M548A1)	WP 0019 00
STARTING SYSTEM SCHEMATIC (M548A3)	WP 0020 00
AIR BOX HEATER SCHEMATIC	WP 0021 00
POWER TRAIN/STEERING /BRAKES/GEAR SELECTION/THROTTLE	
DIAGRAMS	WP 0022 00

# **CHARGING SYSTEM**

100 AMP CHARGING SYSTEM MALFUNCTIONS (M548A1)	WP 0023 00
200 AMP CHARGING SYSTEM OPERATIONAL CHECK (M548A3)	WP 0024 00
200 AMP NO CHARGE/REGULATION TROUBLESHOOTING (M548A3)	WP 0025 00
200 AMP FULL FIELD CHARGE TROUBLESHOOTING (M548A3)	WP 0026 00
200 AMP OVER VOLTAGE TROUBLESHOOTING (M548A3).	
CONNECT/DISCONNECT 200 AMP GENERATOR TEST KIT (M548A3)	WP 0028 00
100 AMP ENGINE CHARGING SYSTEM SCHEMATIC (M548A1)	WP 0029 00
200 AMP ENGINE CHARGING SYSTEM SCHEMATIC (M548A3)	WP 0030 00

# **ELECTRICAL SYSTEM**

HI TEMP DIFF OIL INDICATOR COMES ON (M548A1)	WP 0031 00
HI TEMP TRANS OIL INDICATOR COMES ON (M548A1)	WP 0032 00
HI TEMP TRANS OIL INDICATOR COMES ON (M548A3)	WP 0033 00
NO EXTERIOR LIGHTS OPERATE	WP 0034 00
BLACKOUT DRIVE LIGHT DOES NOT WORK	
SERVICE HEADLIGHTS DO NOT OPERATE	WP 0036 00
INFRARED HEADLIGHT(S) DOES NOT OPERATE	WP 0037 00
SERVICE AND/OR BLACKOUT STOPLIGHTS MALFUNCTION	
BLACKOUT STOPLIGHT DOES NOT OPERATE	WP 0039 00
BLACKOUT MARKER LIGHT(S) AND/OR TAILLIGHT(S) DO NOT	
OPERATE	
SERVICE TAILLIGHT DOES NOT OPERATE	
SERVICE STOPLIGHT DOES NOT WORK	
TRAILER LIGHTS DO NOT OPERATE	
HORN DOES NOT OPERATE	WP 0044 00
INSTRUMENT PANEL ILLUMINATION LIGHTS MALFUNCTION	WP 0045 00

## MALFUNCTION/SYMPTOM INDEX WP—Continued

LOW PRESS ENGINE OIL INDICATOR FAILS TO GO OFF AFTER	
ENGINE STARTS	
TRANS LOW OIL PRESS INDICATOR COMES ON	WP 0047 00
DOME LIGHT WORKS IMPROPERLY	WP 0048 00
MASTER SWITCH ON INDICATOR DOES NOT LIGHT	WP 0049 00
FUEL LEVEL INDICATOR MALFUNCTIONS	WP 0050 00
HIGH BEAM INDICATOR LIGHT MALFUNCTIONS	WP 0051 00
BATTERY/GENERATOR INDICATOR MALFUNCTIONS	
COOLANT TEMPERATURE GAUGE MALFUNCTIONS	
LO PRESS ENGINE OIL INDICATOR MALFUNCTIONS	WP 0054 00
TRANS LOW OIL PRESS INDICATOR MALFUNCTIONS (M548A3)	WP 0055 00
HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A1)	WP 0056 00
HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A3)	
HI TEMP DIFF OIL INDICATOR MALFUNCTIONS (M548A1)	WP 0058 00
TRANS OIL HI DIFF PRESS INDICATOR MALFUNCTIONS (M548A3)	
WINDSHIELD WIPER DOES NOT OPERATE	WP 0060 00
INSTRUMENT PANEL INDICATORS SCHEMATIC (M548A1)	WP 0061 00
INSTRUMENT PANEL INDICATORS SCHEMATIC (M548A3)	WP 0062 00
ELECTRICAL SYSTEM SCHEMATIC	

# **TURN SIGNAL**

TURN SIGNAL LAMP, STOPLIGHT OR CONTROL LIGHT DOES NOT	
LIGHT OF FLASH WHEN CONTROL IS IN RIGHT OR LEFT TURN	
POSITION	WP 0065 00
TURN SIGNAL LAMPS AND STOPLIGHTS DO NOT FLASH WITH	
CONTROL IN HAZARD POSITION	.WP 0066 00
IN LEFT OR RIGHT TURN SIGNAL POSITION, INDIVIDUAL LIGHT	
DOES NOT FLASH	WP 0067 00

# STEERING SYSTEM

STEERING/BRAKES MALFUNCTION (M548A1)	WP 0068 00
CARRIER DOES NOT MOVE IN ANY SHIFT LEVER POSITION	
(M548A1)	WP 0069 00
TRANSMISSION SYSTEM SCHEMATIC (M548A3)	WP 0070 00
CARRIER DOES NOT MOVE IN ANY SHIFT LEVER POSITION	
(M548A3)	WP 0071 00
CARRIER DOES NOT PIVOT (M548A1)	
TRANSMISSION DOES NOT PIVOT STEER (M548A3)	
CARRIER MOVES WITH TRANSMISSION IN SL (M548A3)	
CARRIER DRIFTS OR DOES NOT STEER (M548A3)	
SERVICE AND/OR PARKING BRAKE WILL NOT HOLD CARRIER	
(M548A3)	WP 0076 00
TRANSMISSION WILL NOT UPSHIFT OR SHIFTS ERRATICALLY IN	
1–4 POSITION (M548A3)	WP 0077 00
TRANSMISSION DOES NOT DOWNSHIFT IN 1-4 POSITION (M548A3)	
TRANSMISSION DOES NOT HOLD 1ST POSITION (M548A3).	
TRANSMISSION DOES NOT HOLD 2ND POSITION (M548A3)	
TRANSMISSION DOES NOT HOLD 3RD POSITION (M548A3)	
TRANSMISSION DOES NOT REVERSE (M548A3)	

MALFUNCTION/SYMPTOM INDEX WP—Continued	0006 00
BILGE PUMPS SYSTEM	
BILGE PUMP SYSTEM SCHEMATIC	WP 0083 00
FRONT BILGE PUMP AND/OR LIGHT DOES NOT OPERATE	WP 0084 00
VEHICLE COMPARTMENT HEATER	
VEHICLE COMPARTMENT HEATER MALFUNCTIONS	WP 0085 00
WINTERIZATION SYSTEM	
COOLANT HEATER MALFUNCTIONS	WP 0086 00
SPEEDOMETER/TACHOMETER	
SPEEDOMETER MALFUNCTIONS	WP 0087 0
TACHOMETER MALFUNCTIONS	WP 0088 00
WINCH	
WINCH CASE OVERHEATS (M548A1)	WP 0089 0
WINCH DRUM DOES NOT TURN WITH DRUM CLUTCH IN "CLUTCH	
IN" POSITION (M548A1)	WP 0090 0
WINCH DRUM DOES NOT TURN DRUM CLUTCH IN "CLUTCH OUT"	
POSITION (M548A1)	WP 0091 0
WINCH BRAKE DOES NOT HOLD (M548A1).	WP 0092 0
POWER TAKEOFF DOES NOT ENGAGE WHEN WINCH CONTROL IS	
ACTUATED (M548A1)	WP 0093 0
EXCESSIVE OIL LEAKS (WINCH TRANSFER GEARCASE AND POWER TAKEOFF) (M548A1)	
WINCH PROPELLER SHAFT NOISY DURING OPERATION (M548A1)	
AIR COMPRESSOR	
COMPRESSOR AIR OUTPUT ADEQUATE, BUT NO AIR PRESSURE INDICATION ON PANEL AIR BRAKE PRESSURE INDICATOR	
(M548A1)	WP 0096 0
LOW AIR PRESSURE WARNING LIGHT DOES NOT LIGHT WHEN AIR	
PRESSURE FALLS BELOW 60 PSI (414 KPA) (M548A1)	WP 0097 0
COMPRESSOR DOES NOT MAINTAIN AIR PRESSURE (M548A1)	
TOWED LOAD BRAKES DO NOT OPERATE WHEN PEDAL IS	
PRESSED; AIR PRESSURE ADEQUATE (M548A1)	WP 0099 0
TOO MUCH OIL DRAINAGE FROM RESERVOIR DRAIN COCK	
(M548A1)	
TOO MUCH FOREIGN MATTER IN RESERVOIR (M548A1)	
COMPRESSOR OPERATION TOO NOISY (M548A1)	WP 0102 0

# **NBC SYSTEM**

PARTICULATE PRECLEANER MOTOR DOES NOT WORK (M548A3)	WP 0103 00
M3 HEATER DOES NOT WORK (M548A3)	WP 0104 00
NO AIR FLOW AT ONE OR MORE OUTLETS (M548A3)	WP 0105 00

MALFUNCTION/SYMPTOM INDEX WP—Continued	0006 00
LOW AIR FLOW AT ALL OUTLETS (M548A3)	WP 0106 00
STE/ICE-R TROUBLESHOOTING	
STE/ICE-R (SIMPLIFIED TEST EQUIPMENT FOR INTERNAL	
COMBUSTION ENGINES-REPROGRAMMABLE) PROCEDURES	WP 0107 00
STE/ICE-R CHARGING CIRCUIT TROUBLESHOOTING	
STE/ICE-R STARTER CIRCUIT TROUBLESHOOTING	WP 0109 00
STE/ICE-R LOW OIL PRESSURE TROUBLESHOOTING	
STE/ICE-R BATTERY TROUBLESHOOTING	
STE/ICE-R ENGINE WILL NOT CRANK TROUBLESHOOTING	WP 0112 00
STE/ICE-R ENGINE WILL NOT CRANK BUT WILL NOT START	
TROUBLESHOOTING	
HOOK UP/REMOVE STE/ICE-R FOR POWER	
HOOK UP/REMOVE STE/ICE-R FOR ENGINE RPM	
HOOK UP/REMOVE STE/ICE-R FOR STARTER CIRCUT TESTS	WP 0116 00
HOOK UP/REMOVE STE/ICE-R TEST SET FOR TEST NUMBERS 72	
THRU 75	WP 0117 00
STE/ICE-R TEST 01 DISPLAY ENGINE RPM WITH NEXT	
MEASUREMENT	
STE/ICE-R TEST 10 ENGINE RPM	
STE/ICE-R TEST 13 POWER (PERCENT)	
STE/ICE-R TEST 14 COMPRESSION UNBALANCE (POWER CABLE)	
STE/ICE-R TEST 67 BATTERY VOLTAGE	
STE/ICE-R TEST 72 STARTER CURRENT (FIRST PEAK) STE/ICE-R TEST 73 BATTERY RESISTANCE-STE/ICE-R TEST 75	WP 0123 00
	W/D 0124 00
BATTERY RESISTANCE CHANGE (PACK) STE/ICE-R TEST 74 STARTER CIRCUIT RESISTANCE	
STE/CE-K TEST /4 STAKTER CIRCUIT RESISTANCE	wr 0125 00

STE/ICE-R TEST 90 DC CURRENT 0 TO 1500 AMPS......WP 0126 00

# ENGINE OVERHEATS (M548A1)

#### INITIAL SETUP:

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Radiator Test Kit (WP 0541 00, Item 54)

#### Personnel Required


Unit Mechanic


#### References

See your -10

#### Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10) Power plant upper rear access door opened (see your -10) Hull bottom access cover removed (WP 0383 00)






## ENGINE OVERHEATS (M548A1)—Continued

0007 00




## ENGINE OVERHEATS (M548A1)—Continued



### ENGINE OVERHEATS (M548A1)—Continued

0007 00



# **ENGINE OVERHEATS (M548A3)**

#### INITIAL SETUP:

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Radiator Test Kit (WP 0541 00, Item 54)

#### Personnel Required


Unit Mechanic


#### References

See your -10

#### Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10) Power plant rear access panel removed (see your -10) Left grille removed (see your -10) Hull bottom access cover removed (WP 0383 00)






## ENGINE OVERHEATS (M548A3)—Continued


0008 00



## ENGINE OVERHEATS (M548A3)—Continued



#### ENGINE OVERHEATS (M548A3)—Continued



# ENGINE WILL NOT REACH OPERATING TEMPERATURE

#### **INITIAL SETUP:**

Maintenance Level	
-------------------	--

Unit

#### Personnel Required

Unit Mechanic

#### References


See your -10

#### **Equipment Condition**

Engine stopped (see your -10) Carrier blocked (see your -10)

# NOTE

#### M548A1 and M548A3 troubleshooting procedures are the same.



# **ENGINE DOES NOT CRANK (M548A1)**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) STE/ICE-R Test Set (WP 0541 00, Item 6) Multimeter (WP 0541 00, Item 29) Socket Wrench Set (WP 0541 00, Item 64)

#### Personnel Required

Unit Mechanic Helper (H)

#### References


See your -10 (WP 0112 00)

Equipment Condition

Engine stopped (see your -10)


Carrier blocked (see your -10)


Center seat raised (see your -10)




## ENGINE DOES NOT CRANK (M548A1)—Continued


0010 00










# 5BY 1. Inspect engine harness circuit 6 (1) leads. 2. Are leads and terminal free of corrosion and damage? Image: Corrosion and damage Image: Corrosion and damage: Corrosion and damage Image: Corrosion and damage: Corrosion and damage Image: Corrosion and damage: Corrosion and









# **ENGINE DOES NOT CRANK (M548A3)**

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

Personnel Required


Unit Mechanic Helper (H) References


See your -10


Equipment Condition Engine stopped (see your -10) Carrier blocked (see your -10) Power plant rear access panel removed (see your -10) Center and driver's seats raised (see your -10) Hull bottom access cover removed (WP 0383 00)


# NOTE


#### A helper is needed throughout task.























# ENGINE CRANKS SLOWLY (M548A1)

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) STE/ICE-R Test Set (WP 0541 00, Item 6) Multimeter (WP 0541 00, Item 29)


Personnel Required


Unit Mechanic Helper (H) References


See your -10 (WP 0109 00)


Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10) Driver's seat raised (see your -10) Power plant rear access door removed (see your -10) Center seat raised (see your -10)














# ENGINE CRANKS SLOWLY (M548A3)

#### Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

#### Personnel Required


Unit Mechanic Helper (H)


#### References


See your -10


#### Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10) Power plant rear access panel removed (see your -10) Center and driver's seats raised (see your -10) Hull bottom access cover removed (WP 0383 00)



















# ENGINE CRANKS BUT WILL NOT START

#### INITIAL SETUP:

Maintenance Level

Unit <u>Tools and Special Tools</u> <u>General Mechanic's Tool Kit (WP 0541 00, Item 57)</u> <u>STE/ICE-R Test Set (WP 0541 00, Item 6)</u> <u>Materials/Parts</u> <u>Suitable container</u> <u>Personnel Required</u> <u>Unit Mechanic</u> Helper (H)

#### References


See your -10 (WP 0113 00)

Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10) Power plant rear access door/panel removed (see your -10)


# NOTE

#### M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.



#### ENGINE CRANKS BUT WILL NOT START—Continued






#### ENGINE CRANKS BUT WILL NOT START—Continued

## **3BY**

- 1. Replace fuel pump (WP 0149 00 or WP 0150 00).
- 2. Verify no faults found.



# ENGINE CRANKS BUT WILL NOT START BELOW 40°F (AIR BOX HEATER IS USED)

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) STE/ICE-R Test Set (WP 0541 00, Item 6) Multimeter (WP 0541 00, Item 29)

Personnel Required

Unit Mechanic Helper (H) References


See your -10 WP 0113 00

Equipment Condition Engine stopped (see your -10)


Carrier blocked (see your -10) Cab personnel seats raised (see your -10) Power plant rear access door/panel removed (see your -10)


# NOTE

#### M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.




# ENGINE CRANKS BUT WILL NOT START BELOW 40°F (AIR BOX HEATER IS USED)—Continued







4Y4YN NO Clear or replace air box fuel supply Inspect fuel supply line to solenoid. 1. 2. Is line free from kinks or clogs? line (WP 0180 00 or WP 0181 00). Verify no faults found. YES **5**Y 5YN NO Install solenoid fuel supply line on return tee. Replace air box heater fuel supply 1. 1. solenoid (WP 0186 00 or Remove air box heater harness plug (1) from solenoid (2). 2. 3. Measure voltage between plug (1) sockets A (+) and B (-) with air WP 0187 00). box heater switch on. 2. Verify no faults found. 4. Does multimeter read less than 17 volts? (2) YES **6**Y Install solenoid to air box heater fuel line. 1. 2. Install air box heater harness plug on to fuel solenoid. Did multimeter read less than 17 volts? 3. YES DY


#### 0015 00







#### 0015 00









0015 00


#### 5DY


- 1. Repair front main harness circuit 406 (WP 0294 00).
- 2. Verify no faults found.

#### **INITIAL SETUP:**


Maintenance Level	References
Unit	See your -10
Tools and Special Tools         General Mechanic's Tool Kit (WP 0541 00, Item 57)         Materials/Parts         Wiping rag (WP 0542 00, Item 45)         Suitable container         Personnel Required	Equipment Condition Engine stopped (see your -10) Carrier blocked (see your -10) Air cleaner element cleaned (see your -10) Primary and secondary fuel filters serviced (see your -10)
Unit Mechanic Helper (H)	Power plant rear access door removed (see your -10)


# WARNING Fuel flowing over a metal surface causes static electricity. This will cause a spark unless the surface is grounded. WARNING Loose clothing is dangerous around moving belts and pulley. You could get badly hurt if your clothes get caught in moving parts. Push forward on quick disconnect coupling (1) to disconnect 1. return hose (2) from fuel return line (3). 2. Remove half of quick disconnect coupling (1) from return hose (2) and retain. 2 Continued





#### 0016 00






#### **3BY 3BYN** NO Pull fuel supply hose (1) from quick disconnect coupling (2) in Fuel supply hose or fuel tank pickup 1. 1 power plant compartment. tube obstructed. 2. Place wiping rags under fuel supply hose quick disconnect 2. Replace obstructed fuel lines coupling (2). (WP 0167 00). Turn MASTER SWITCH ON. 3. Verify no faults found. 3. Depress plunger inside quick disconnect coupling (2) for about 5 4. seconds. 5. Turn MASTER SWITCH OFF. Connect fuel supply hose (1) to quick disconnect coupling (2). 6. 7. Did fuel flow freely from fuel supply hose? YES 4BY Replace engine fuel pump (WP 0149 00). 1. Verify no faults found. 2.

#### **INITIAL SETUP:**


Maintenance Level	Equipment Condition
Unit	Engine stopped (see your -10)
Tools and Special Tools	Carrier blocked (see your -10)
General Mechanic's Tool Kit (WP 0541 00, Item 57)	Center seat and driver's seat raised (see your -10)
Materials/Parts Wiping rag (WP 0542 00, Item 45) Suitable container	Air cleaner element cleaned (WP 0155 00)
	Hull bottom access cover removed (WP 0383 00)
Personnel Required	Primary and secondary fuel filters serviced
Unit Mechanic	(WP 0178 00)
References See your -10	Power plant rear access panel removed (see your -10)
	Top left access grille removed (see your -10)





YES

#### 0017 00


- 1. Drain complete fuel system (WP 0162 00) and change filter
- elements (WP 0178 00).
- 2. Fill fuel tank with clean fuel (see your -10).
- 3. Verify no faults found.










7AY	
1.	Air leak in suction side of fuel system.
2.	Tighten all connections from the air separator (1) to the electric
	fuel pumps (2).
	South -
	<u>h</u> ,
	X
3.	Verify no faults found.









#### DY

- 1. Inspect fuel lines on engine between secondary fuel filter and engine cylinder heads.
- 2. Inspect fuel lines on engine between right engine cylinder head and left cylinder head.
- 3. Inspect fuel lines on engine between engine cylinder head and restrictor block.
- 4. Are any fuel lines kinked or leaking?


YES


#### **GO TO HY** (PAGE 0017 00-11)

NO

#### 2DY

- 1. Tighten and/or replace fuel lines as needed (WP 0168 00).
- 2. Verify no faults found.






#### 0017 00-11/12 blank

#### ENGINE FUEL SYSTEM SCHEMATIC

#### DESCRIPTION


Use the schematic below as an aid for performing system troubleshooting procedures.



#### STARTING SYSTEM SCHEMATIC (M548A1)

#### DESCRIPTION

Use the schematic below as an aid for performing system troubleshooting procedures.




ENGINE COMPARTMENT

#### **STARTING SYSTEM SCHEMATIC (M548A3)**

#### DESCRIPTION


Use the schematic below as an aid for performing system troubleshooting procedures.



#### AIR BOX HEATER SYSTEM SCHEMATIC

#### DESCRIPTION


Use the schematic below as an aid for performing system troubleshooting procedures.



# POWER TRAIN/STEERING/BRAKES/GEAR SELECTION/THROTTLE DIAGRAMS

# DESCRIPTION

Use the diagrams below as an aid for performing system troubleshooting procedures.




POWER TRAIN/STEERING/BRAKES/GEAR SELECTION/THROTTLE DIAGRAMS

# 100 AMP CHARGING SYSTEM MALFUNCTIONS (M548A1)


#### **INITIAL SETUP:**


Maintenance Level	References	
Unit	See your -10	
	(WP 0108 00)	
Tools and Special Tools		
General Mechanic's Tool Kit (WP 0541 00, Item 57)	Equipment Condition	
STE/ICE-R Test Set (WP 0541 00, Item 6)	Engine stopped (see your -10)	
Multimeter (WP 0541 00, Item 29)	Carrier blocked (see your -10)	
Jumper Wire	Engine disconnect lever IN (see your -10)	
Personnel Required	Power plant rear access door/panel removed (see your -10)	
Unit Mechanic		
	Cab personnel seats raised (see your -10)	
<b>T</b>		
<u>T</u>		
NOTE	NO 1. Stop engine (see your -10).	




0023 00


## 100 AMP CHARGING SYSTEM MALFUNCTIONS (M548A1)—Continued

















0023 00


# **3BY**

- 1. Replace generator (WP 0242 00 or WP 0246 00).
- 2. Verify no faults found.

# 200 AMP CHARGING SYSTEM OPERATIONAL CHECK (M548A3)


#### **INITIAL SETUP:**

Maintenance Level<br/>UnitReferences<br/>See your -10<br/>TM 9-6140-200-14Tools and Special Tools<br/>General Mechanic's Tool Kit (WP 0541 00, Item 57)<br/>Multimeter (WP 0541 00, Item 29)Equipment Condition<br/>Engine stopped (see your -10)<br/>Carrier blocked (see your -10)Personnel Required<br/>Unit MechanicEngine stopped (see your -10)<br/>Carrier blocked (see your -10)



0024 00


## 200 AMP CHARGING SYSTEM OPERATIONAL CHECK (M548A3)—Continued




1. Verify no faults found.

2BY

#### 200 AMP CHARGING SYSTEM OPERATIONAL CHECK (M548A3)—Continued







# 200 AMP NO CHARGE/REGULATION TROUBLESHOOTING (M548A3)

#### **INITIAL SETUP:**

Tools and Special Tools       TM 9         General Mechanic's Tool Kit (WP 0541 00, Item 57)       TM 9	
Tools and Special Tools       TM 9         General Mechanic's Tool Kit (WP 0541 00, Item 57)       TM 9	
Multimator (WP 0541 00 Itom 20)	
Multimeter (WP 0541 00, Item 29) Equipme	ent Condition
Slip Joint Pliers (WP 0541 00, Item 33)	
Generator Test Kit (WP 0541 00, Item 53) Engin	e stopped (see your -10)
Personnel Required Carrie	er blocked (see your -10)
Unit Mechanic All ra	dios and heaters OFF (see your -10)



## 200 AMP NO CHARGE/REGULATION TROUBLESHOOTING (M548A3)—Continued




# 200 AMP FULL FIELD CHARGE TROUBLESHOOTING (M548A3)

#### **INITIAL SETUP:**

Maintenance Level References Unit See your -10 **Tools and Special Tools** General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Equipment Condition Slip Joint Pliers (WP 0541 00, Item 33) Engine stopped (see your -10) Generator Test Kit (WP 0541 00, Item 53) Carrier blocked (see your -10) Personnel Required Unit Mechanic All radios and heaters OFF (see your -10) TN NO Disconnect batteries (WP 0293 00). Tighten or repair connections, 1. 2. Check all electrical connectors, harnesses, and Cannon plugs Cannon plugs, and harnesses. before connecting generator test kit. 2. Repeat 200 amp charging system 3. operational check (WP 0024 00). Are connectors and Cannon plugs tight and pins in place in harnesses? YES Y YN NO 1. Remove six screws (1) and cover (2) from voltage regulator (3). Ensure lock washers (1) and screws 1. Connect multimeter to clean unpainted surface and carrier ground. (2) are tight on plate (3). 2. 3. Does multimeter read 0.5 ohms or less? 2. Tighten nut (4) securing ground lead (5) to voltage regulator (6). 6 3 2 Install cover and screws on voltage 3. regulator. 4. Repeat 200 amp charging system operational check (WP 0024 00). YES

# 200 AMP FULL FIELD CHARGE TROUBLESHOOTING (M548A3)—Continued



# 200 AMP OVER VOLTAGE TROUBLESHOOTING (M548A3)


#### **INITIAL SETUP:**

Т

Maintenance Level<br/>UnitReferences<br/>See your -10<br/>TM 9-6140-200-14Tools and Special Tools<br/>General Mechanic's Tool Kit (WP 0541 00, Item 57)<br/>Multimeter (WP 0541 00, Item 29)<br/>Generator Test Kit (WP 0541 00, Item 53)Equipment Condition<br/>Engine stopped (see your -10)<br/>Carrier blocked (see your -10)


<u> </u>		
1.		GO TO BY (PAGE 0027 00-3)
2.	Measure battery voltage by placing red lead (1) in positive socket	
	of NATO plug (2) on auxiliary power (slave) receptacle (3).	
	Touch black negative lead (4) to outside of NATO plug on	
	receptacle.	
3.	Adjust 200 amp voltage regulator to lowest setting (WP 0249 00).	
<i>3</i> . 4.	Start engine (see your -10) and accelerate.	
4. 5.		
э.	Does voltage climb to 32 to 34 volts and suddenly drop to battery	
	voltage?	
	$\mathbf{\tilde{v}}$	
	·	
	YES	
	Ÿ	

# 200 AMP OVER VOLTAGE TROUBLESHOOTING (M548A3)—Continued



# 200 AMP OVER VOLTAGE TROUBLESHOOTING (M548A3)—Continued

Υ



# CONNECT/DISCONNECT 200 AMP GENERATOR TEST KIT (M548A3)

# THIS WORK PACKAGE COVERS:

Hook-up (page 0028 00-2). Disconnect (page 0028 00-4).

# **INITIAL SETUP:**

Maintenance Level	References
Unit	See your -10
Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57)	Equipment Condition
Slip Joint Pliers (WP 0541 00, Item 33) Generator Test Kit (WP 0541 00, Item 53)	Engine stopped (see your -10) Carrier blocked (see your -10)
Personnel Required	All radios and heaters turned off (see your -10)
Unit Mech 63T10	Center seat and driver's seat raised (see your -10)

# CONNECT/DISCONNECT 200 AMP GENERATOR TEST KIT (M548A3)—Continued

- 1. Disconnect both battery negative leads (WP 0292 00).
- 2. Check all electrical connectors and wiring harnesses before connecting generator test kit.
- 3. Remove plug (1) and plug (2) from voltage regulator (3).
- 4. Connect diagnostic test wiring harness (4) plug (5) and plug (6) to plug (1) and plug (2).
- 5. Connect diagnostic test wiring harness (4) lead 2(7) to terminal 5 (8) to test kit rheostat (9).


# CAUTION

If ground lead (10) is not connected to chassis and kit rheostat, the generator could be damaged when engine is started.

- 6. Connect kit ground lead (10) to terminal 6 (11) to test kit rheostat (9) and to ground.
  - a. Remove screw (12), lock washer(13), washer (14), and ground lead (15) from voltage regulator mounting plate (16).
  - b. Install ground lead (10) and ground lead (15) on voltage regulator mounting plate (16) with washer (14), lock washer (13) and screw (12).

# CONNECT/DISCONNECT 200 AMP GENERATOR TEST KIT (M548A3)—Continued


7. Connect both battery negative leads (WP 0292 00).



# CONNECT/DISCONNECT 200 AMP GENERATOR TEST KIT (M548A3)—Continued

#### DISCONNECT


- 1. Disconnect both battery negative leads (WP 0292 00).
- 2. Disconnect ground lead (1) from terminal 6 (2) of test kit rheostat (3) and ground.
  - a. Remove screw (4), lock washer (5), washer (6), ground lead (1) and ground lead (7) from voltage regulator mounting plate (8).
  - b. Install ground lead (7) on voltage regulator mounting plate (8) with washer (6), lock washer (5), and screw (4).
- 3. Disconnect diagnostic test wiring harness (9) lead 2(10) from terminal 5 (11) of test kit rheostat (3).
- 4. Disconnect diagnostic test wiring harness (9) plug (12) and plug (13) from plug (14) and plug (15).
- 5. Connect plug (14) and plug (15) to voltage regulator (16).
- 6. Connect both battery negative leads (WP 0292 00).



# **100 AMP ENGINE CHARGING SYSTEM SCHEMATIC (M548A1)**

#### DESCRIPTION


Use the schematic below as an aid for performing system troubleshooting procedures.



# 200 AMP ENGINE CHARGING SYSTEM SCHEMATIC (M548A3)

# DESCRIPTION

Use the schematic below as an aid for performing system troubleshooting procedures.



# HI TEMP DIFF OIL INDICATOR COMES ON (M548A1)

#### 0031 00

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

Personnel Required


Unit Mechanic

References


See your -10


Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10) Differential oil filter replaced (WP 0337 00)



# HI TEMP DIFF OIL INDICATOR COMES ON (M548A1)—Continued





1. Suspected faulty oil cooler.

2. Notify your supervisor.

0031 00-3/4 blank

# HI TEMP TRANS OIL INDICATOR COMES ON (M548A1)

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57)

Personnel Required


Unit Mechanic

#### References


See your -10

**Equipment Condition** 

Engine stopped (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10) Transmission oil filter element replaced (WP 0320 00).



# HI TEMP TRANS OIL INDICATOR COMES ON (M548A1)—Continued



## HI TEMP TRANS OIL INDICATOR COMES ON (M548A3)

#### **INITIAL SETUP:**

### Maintenance Level

Unit

#### Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Pressure Gauge Kit (WP 0541 00, Item 34)

#### Personnel Required


Unit Mechanic

#### References


See your -10 See your PMCS

#### **Equipment Condition**


Engine stopped (see your -10) Carrier blocked (see your -10) Transmission in SL (see your -10) Transmission oil level checked (see your PMCS) Cab floor plates raised (WP 0395 00)




## HI TEMP TRANS OIL INDICATOR COMES ON (M548A3)—Continued




### HI TEMP TRANS OIL INDICATOR COMES ON (M548A3)—Continued



## HI TEMP TRANS OIL INDICATOR COMES ON (M548A3)—Continued





# NO EXTERIOR LIGHTS OPERATE

### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

Personnel Required

Unit Mechanic

References


See your -10

Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10) Instrument panel partially removed (WP 0256 00)

## NOTE

### M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.



### NO EXTERIOR LIGHTS OPERATE—Continued



# **BLACKOUT DRIVE LIGHT DOES NOT WORK**

Maintenance Level Unit

Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

## Personnel Required

Unit Mechanic

References


See your -10

Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10) IR/BO select on BO (see your -10)

## NOTE


### M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.



## **BLACKOUT DRIVE LIGHT DOES NOT WORK—Continued**



### BLACKOUT DRIVE LIGHT DOES NOT WORK—Continued



# SERVICE HEADLIGHTS DO NOT OPERATE

### INITIAL SETUP:

Maintenance Level Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Personnel Required

Unit Mechanic


References


See your -10

Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10)

# NOTE







## SERVICE HEADLIGHTS DO NOT OPERATE—Continued



## SERVICE HEADLIGHTS DO NOT OPERATE—Continued



## SERVICE HEADLIGHTS DO NOT OPERATE—Continued



## INFRARED HEADLIGHT(S) DOES NOT OPERATE

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Slip Joint Pliers (WP 0541 00, Item 33)

#### Personnel Required

Unit Mechanic

References

See your -10


**Equipment Condition** 


Engine stopped (see your -10)


Carrier blocked (see your -10)

# NOTE

### M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.









## **6**Y

- 1. Install circuit 520 plug on IR/BO select switch.
- 2. Replace light switch (WP 0262 00).
- 3. Verify no faults found.





# SERVICE AND/OR BLACKOUT STOPLIGHTS MALFUNCTION

### INITIAL SETUP:

Maintenance Level Unit

Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Personnel Required

Unit Mechanic

References


See your -10

**Equipment Condition** 


Engine stopped (see your -10) Carrier blocked (see your -10)

# NOTE


M548A1 and M548A3 troubleshooting procedures are the same. M548A1S procedure is shown.



## SERVICE AND/OR BLACKOUT STOPLIGHTS MALFUNCTION—Continued



## SERVICE AND/OR BLACKOUT STOPLIGHTS MALFUNCTION—Continued




## SERVICE AND/OR BLACKOUT STOPLIGHTS MALFUNCTION—Continued


### 0038 00


## **3BY**


- 1. Install main harness plugs on jack and taillight.
- 2. 3. Replace light switch (WP 0262 00).
- Verify no faults found.


# **BLACKOUT STOPLIGHT DOES NOT WORK**











0039 00

## 10Y

- 1. Adjust stoplight switch (WP 0274 00).
- 2. Verify no faults found.

# BLACKOUT MARKER LIGHT(S) AND/OR TAILLIGHT(S) DO NOT OPERATE

### **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Personnel Required

Unit Mechanic

References


See your -10

**Equipment Condition** 


Engine stopped (see your -10) Carrier blocked (see your -10)

# NOTE

M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.




## BLACKOUT MARKER LIGHT(S) AND/OR TAILLIGHT(S) DO NOT OPERATE—Continued



0040 00

## BLACKOUT MARKER LIGHT(S) AND/OR TAILLIGHT(S) DO NOT OPERATE—Continued



1. Repair main harness circuit 20/24 (WP 0294 00).

2. Verify no faults found.

## SERVICE TAILLIGHT DOES NOT OPERATE

### INITIAL SETUP:

Maintenance Level Unit

Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

Personnel Required

Unit Mechanic


References

See your -10


Equipment Condition Engine stopped (see your -10) Carrier blocked (see your -10)

# NOTE


### M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.




## SERVICE TAILLIGHT DOES NOT OPERATE—Continued




# SERVICE STOPLIGHT DOES NOT WORK




## SERVICE STOPLIGHT DOES NOT WORK—Continued




## SERVICE STOPLIGHT DOES NOT WORK—Continued



# TRAILER LIGHTS DO NOT OPERATE



## TRAILER LIGHTS DO NOT OPERATE—Continued



# HORN DOES NOT OPERATE

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Jumper Wire

Personnel Required


Unit Mechanic Helper (H) References


See your -10

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10)


# NOTE






# HORN DOES NOT OPERATE—Continued






## HORN DOES NOT OPERATE—Continued



## HORN DOES NOT OPERATE—Continued



# INSTRUMENT PANEL ILLUMINATION LIGHTS MALFUNCTION

## INITIAL SETUP:

Maintenance Level Unit

Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

Personnel Required

Unit Mechanic

References


See your -10


**Equipment Condition** 

Engine stopped (see your -10) Carrier blocked (see your -10)

# NOTE

M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.






# INSTRUMENT PANEL ILLUMINATION LIGHTS MALFUNCTION—Continued

## **4**Y

- 1. Replace light switch (WP 0262 00).
- 2. Verify no faults found.



# **INSTRUMENT PANEL ILLUMINATION LIGHTS MALFUNCTION—Continued**

## 0045 00

# **3BY**

- 1. Install main harness plug on light switch jack.
- 2. 3. Replace instrument panel light assembly (WP 0264 00).
- Verify no faults found.

# LOW PRESS ENGINE OIL INDICATOR FAILS TO GO OFF AFTER ENGINE STARTS

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) STE/ICE-R Test Kit (WP 0541 00, Item 6) Oil Pressure Gauge Kit (WP 0541 00, Item 34)

Personnel Required

Unit Mechanic

References


See your -10

See your -PMCS (WP 0110 00)

Equipment Condition Engine stopped (see your -10) Carrier blocked (see your -10) Engine warm Engine oil level checked (see your PMCS) Engine idle speed checked (see your -10) Cab personnel seats raised (see your -10) Power plant rear access door/panel removed (see your -10)

# NOTE

#### M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.




# LOW PRESS ENGINE OIL INDICATOR FAILS TO GO OFF AFTER ENGINE STARTS—Continued

Y	
1.	Low engine oil pressure.
2.	Notify your supervisor.


# TRANS LOW OIL PRESS INDICATOR COMES ON (M548A3)

#### **INITIAL SETUP:**


Maintenance Level Unit	References See your -10
Tools and Special Tools	See your PMCS Equipment Condition
General Mechanic's Tool Kit (WP 0541 00, Item 57) Tube-pipe Fitting Kit (WP 0541 00, Item 15) Pressure Gauge Kit (WP 0541 00, Item 34)	Engine stopped (see your -10) Carrier blocked (see your -10) Parking brake off (see your -10) Transmission in SL (see your -10) Transmission oil level checked (see your PMCS)
Personnel Required Unit Mechanic	Power plant warm Idle speed set at 600 rpm (see your -10) Center seat raised (see your -10)



## TRANS LOW OIL PRESS INDICATOR COMES ON (M548A3)—Continued



## TRANS LOW OIL PRESS INDICATOR COMES ON (M548A3)—Continued



#### TRANS LOW OIL PRESS INDICATOR COMES ON (M548A3)—Continued 0047 00 BY BYN NO Check to see if FILTER IN pressure is within 20 psi (138 kPa) of 1 Replace transmission filter element MAIN pressure. (WP 0321 00). 2. Is FILTER IN pressure within 20 psi (138 kPa) of MAIN Verify no faults found. 2 pressure? YES 2BY 2BYN NO Check transmission brake adjustment (WP 0314 00). Adjust transmission brakes 1. Are transmission brakes correctly adjusted? (WP 0314 00). 2. Verify no faults found. YES **3BY 3BYN** NO Check service brake control linkage adjustment (WP 0347 00). Adjust service brake control linkage 1. Ι. Is linkage properly adjusted? (WP 0347 00). 2 2. Verify no faults found. YES 4BY Verify no faults found. CY CYN NO Check to see if FILTER IN pressure is 35 psi (241 kPa) or more Go to TRANS OIL HI DIFF PRESS 1. greater than MAIN pressure. indicator malfunctions WP 0059 00. 2. Is FILTER IN pressure 35 psi (241 kPa) or more greater than MAIN pressure? YES 2CY Faulty transmission beyond unit maintenance repair. Notify your supervisor. 2

# DOME LIGHT WORKS IMPROPERLY

## **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Personnel Required

Unit Mechanic

0048 00


References

See your -10


Equipment Condition Engine stopped (see your -10) Carrier blocked (see your -10)

# NOTE

M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.



## DOME LIGHT WORKS IMPROPERLY—Continued



# MASTER SWITCH ON INDICATOR DOES NOT LIGHT

## 0049 00

## **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

Personnel Required

Unit Mechanic

References


See your -10

Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10)

# NOTE

#### M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.




# MASTER SWITCH ON INDICATOR DOES NOT LIGHT—Continued




## MASTER SWITCH ON INDICATOR DOES NOT LIGHT—Continued

# **4**Y

- 1. Replace MASTER SWITCH ON indicator assembly (WP 0271 00).
- 2. Verify no faults found.



# MASTER SWITCH ON INDICATOR DOES NOT LIGHT—Continued



# FUEL LEVEL INDICATOR MALFUNCTIONS

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Jumper Wire

Personnel Required

Unit Mechanic

References


See your -10

**Equipment Condition** 


Engine stopped (see your -10) Carrier blocked (see your -10)

# NOTE

#### M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.



## FUEL LEVEL INDICATOR MALFUNCTIONS—Continued



# HIGH BEAM INDICATOR LIGHT MALFUNCTIONS

# 0051 00

## **INITIAL SETUP:**

 Maintenance Level

 Unit

 Tools and Special Tools

 General Mechanic's Tool Kit (WP 0541 00, Item 57)

 Multimeter (WP 0541 00, Item 29)

 Jumper Wire

 Personnel Required

 Unit Mechanic

# References


See your -10

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) MASTER SWITCH OFF (see your -10)

# NOTE

## M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.




# HIGH BEAM INDICATOR LIGHT MALFUNCTIONS—Continued

## 2Y

- Replace high beam indicator light bulb (WP 0257 00).
   Verify no faults found.
- AY
  1. Remove circuit 519/519A lead (1) from high beam indicator light.
  2. Measure resistance between each terminal (2), (3), and ground.
  3. Does multimeter read less than infinity?

1. Remove circuit 519/519A lead (1) from high beam indicator light.
2. Measure resistance between each terminal (2), (3), and ground.
3. Does multimeter read less than infinity?
Image: Control of the second seco

## HIGH BEAM INDICATOR LIGHT MALFUNCTIONS—Continued



# **BATTERY/GENERATOR INDICATOR MALFUNCTIONS**

## **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) STE/ICE-R Test Kit (WP 0541 00, Item 6) Multimeter (WP 0541 00, Item 29) Personnel Required

Unit Mechanic

References


See your -10 (WP 0052 00)

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10)

# NOTE

## M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.



## BATTERY/GENERATOR INDICATOR MALFUNCTIONS—Continued

0052 00

# Y

- 1. Replace BATTERY/GENERATOR indicator panel light
- (WP 0264 00).
- 2. Verify no faults found.

# COOLANT TEMPERATURE GAUGE MALFUNCTIONS

# 0053 00

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Jumper wire

Personnel Required


Unit Mechanic

References


See your -10


Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Cab personnel seats raised (see your -10) Power plant rear access door/panel removed (see your -10)




## COOLANT TEMPERATURE GAUGE MALFUNCTIONS—Continued








0053 00



4. Verify no faults found.







# LO PRESS ENGINE OIL INDICATOR MALFUNCTIONS

## 0054 00

### **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Jumper Wire


Personnel Required Unit Mechanic References

See your -10

Equipment Condition Engine stopped (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10)


# NOTE

#### M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.




#### 2Y


- 1. Replace engine oil low pressure switch (WP 0281 00).
- 2. Verify no faults found.



# 3AY


- Replace LO PRESS ENGINE OIL indicator panel light assembly (WP 0264 00).
- 2. Verify no faults found.





1. 2. 3.	Remove power harness circuit 27J/34 plug (1) from LO PRESS ENGINE OIL indicator jack (2). Measure resistance between circuit 34 plug pin and ground. Does multimeter read more than 0 ohms?	NO 1. 2. 3. 4.	switch (WP 0281 00).
	YES		

#### 0054 00



## 2CYN

- 1. Remove jumper wire.
- 2. Install power harness plug on LO PRESS ENGINE OIL indicator jack.
- 3. Install indicator cover lens and bulb.
- Repair engine harness circuit 34
  - (WP 0294 00).
- 5. Verify no faults found.

## 3CY

- 1. Remove jumper wire.
- 2. Install engine harness onto LO PRESS ENGINE OIL switch.
- 3. Repair power harness circuit 34 (WP 0294 00).
- 4. Verify no faults found.

# **TRANS LOW OIL PRESS INDICATOR MALFUNCTIONS (M548A3)**

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanics Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Jumper Wire

Personnel Required

Unit Mechanic

## References

See your -10


#### Equipment Condition

Engine stopped (see your -10) Parking brake off (see your -10) Service brake off (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10) Floor plates removed (WP 0395 00)


Т		TN
1.	Remove TRANS LOW OIL PRESS indicator lens (1), gasket (2),	NO 1. Replace TRANS LOW OIL PRESS
	bulb (3), and gasket (4).	bulb (WP 0264 00).
2.	Measure resistance between bulb base and bulb center contact.	2. Verify no faults found.
3.	Does multimeter indicate any continuity?	
	YES	
	★	

### TM 9-2350-247-20-1

## TRANS LOW OIL PRESS INDICATOR MALFUNCTIONS (M548A3)—Continued




## TRANS LOW OIL PRESS INDICATOR MALFUNCTIONS (M548A3)—Continued




## TRANS LOW OIL PRESS INDICATOR MALFUNCTIONS (M548A3)—Continued

## **3BY**

- Replace TRANS LOW OIL PRESS indicator assembly (WP 0264 00).
- 2. Verify no faults found.



## TRANS LOW OIL PRESS INDICATOR MALFUNCTIONS (M548A3)—Continued



# HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A1)

### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Jumper Wire

## Personnel Required


Unit Mechanic


## References

See your -10


### Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10) Engine and transmission cooled down Center seat raised (see your -10) Power plant rear access door removed (see your -10)






## HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A1)—Continued





### HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A1)—Continued



## HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A1)—Continued


## **3DY**


- Install power harness circuit 327/27G plug on HI TEMP TRANS 1.
- OIL indicator.
- 2. 3. Repair engine harness circuit 327 (WP 0294 00).
- Verify no faults found.

# HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A3)

#### **INITIAL SETUP:**


Maintenance Level<br/>UnitReferences<br/>See your -10Tools and Special Tools<br/>General Mechanic's Tool Kit (WP 0541 00, Item 57)<br/>Multimeter (WP 0541 00, Item 29)<br/>Jumper WireEquipment Condition<br/>Engine stopped (see your -10)<br/>Carrier blocked (see your -10)<br/>Center seat raised (see your -10)<br/>Cab floor plates removed (WP 0250 00)







3. Verify no faults found.

## HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A3)—Continued





## HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A3)—Continued



## HI TEMP TRANS OIL INDICATOR MALFUNCTIONS (M548A3)—Continued

# **3DY**

- Install instrument panel wiring harness circuit 327/27G plug on 1.
- HI TEMP TRANS OIL indicator.
- 2. 3. Repair power plant wiring harness circuit 327 (WP 0294 00).
- Verify no faults found.

# HI TEMP DIFF OIL INDICATOR MALFUNCTIONS (M548A1)

#### **INITIAL SETUP:**

Maintenance Level Unit Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57)

Multimeter (WP 0541 00, Item 29) Personnel Required


Unit Mechanic


## References

See your -10

Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10)






- 1. Replace differential oil high temperature thermostatic switch (WP 0285 00).
- 2. Verify no faults found.

## HI TEMP DIFF OIL INDICATOR MALFUNCTIONS (M548A1)—Continued






## HI TEMP DIFF OIL INDICATOR MALFUNCTIONS (M548A1)—Continued

## 4CY

- 1. Repair power harness circuit 27K (WP 0294 00).
- 2. Verify no faults found.



## HI TEMP DIFF OIL INDICATOR MALFUNCTIONS (M548A1)—Continued

### 0058 00

## **3DY**

- Remove jumper wire. 1.
- 2. 3. Install plug on HI TEMP DIFF OIL indicator assembly.
- Repair power harness circuit 328 (WP 0294 00).
- 4. Verify no faults found.

#### INITIAL SETUP:

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

Jumper Wire


Personnel Required

Unit Mechanic Helper (H) References

See your -10

Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10) Center seat and driver's seat raised (see your -10)




#### TM 9-2350-247-20-1

0059 00


#### TRANS OIL HI DIFF PRESS INDICATOR MALFUNCTIONS (M548A3)—Continued







### **6**Y

- 1. Remove jumper wire and install harness 12313482 plug on
- differential pressure switch.
- 2. Faulty harness 12313483 circuit 323.
- 3. Notify your supervisor.







## WINDSHIELD WIPER DOES NOT OPERATE

#### **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Personnel Required

Unit Mechanic


References


See your -10

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10)

## NOTE





#### WINDSHIELD WIPER DOES NOT OPERATE—Continued

0060 00


### <u>3</u>Y

- Repair windshield wiper linkage (WP 0421 00).
   Verify no faults found.

## **INSTRUMENT PANEL INDICATORS SCHEMATIC (M548A1)**

### DESCRIPTION

Use the schematic below as an aid for performing system troubleshooting procedures.




0061 00-1/2 blank

## INSTRUMENT PANEL INDICATORS SCHEMATIC (M548A3) (SHEET 1 OF 2)

0062 00

### DESCRIPTION

Use the schematic below as an aid for performing system troubleshooting procedures.




0063 00

## INSTRUMENT PANEL INDICATORS SCHEMATIC (M548A3) (SHEET 2 OF 2)

#### DESCRIPTION

Use the schematic below as an aid for performing system troubleshooting procedures.



## **ELECTRICAL SYSTEM SCHEMATIC**


Use the schematic below as an aid for performing system troubleshooting procedures.

#### **ELECTRICAL SYSTEM SCHEMATIC—Continued**

0064 00

#### NOTE

M548A1 has two batteries. M548A3 has four batteries.



#### **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

Personnel Required

Unit Mechanic

References


See your -10


Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10) MASTER SWITCH OFF (see your -10)


## NOTE


#### M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.




























#### **INITIAL SETUP:**






















# IN LEFT OR RIGHT TURN SIGNAL POSITION, INDIVIDUAL LIGHT DOES NOT FLASH

0067 00

#### **INITIAL SETUP:**



## IN LEFT OR RIGHT TURN SIGNAL POSITION, INDIVIDUAL LIGHT DOES NOT FLASH—Continued



## **STEERING/BRAKES MALFUNCTION (M548A1)**

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57)

#### Personnel Required


Unit Mechanic

#### References

See your -10

#### **Equipment Condition**

Engine stopped (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10) Inspect suspension (see your -10)



# CARRIER DOES NOT MOVE IN ANY SHIFT LEVER POSITION (M548A1)

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57)

## Personnel Required


Unit Mechanic

#### References


See your -10

### Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Engine disconnect lever IN (see your -10) Center seat raised (see your -10) Hull bottom access cover removed (WP 0383 00)




## CARRIER DOES NOT MOVE IN ANY SHIFT LEVER POSITION (M548A1)—Continued



# **TRANSMISSION SYSTEM SCHEMATIC (M548A3)**

## DESCRIPTION

Use the schematic below as an aid for performing system troubleshooting procedures.



# **CARRIER DOES NOT MOVE IN ANY SHIFT LEVER POSITION (M548A3)**

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Slip Joint Pliers (WP 0541 00, Item 33)

#### Personnel Required


Unit Mechanic

#### References


See your -10

#### Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10) Transmission oil level normal Center floor plates removed (WP 0395 00) Center seat raised (see your -10)



## CARRIER DOES NOT MOVE IN ANY SHIFT LEVER POSITION (M548A3)—Continued



## CARRIER DOES NOT MOVE IN ANY SHIFT LEVER POSITION (M548A3)—Continued



## CARRIER DOES NOT MOVE IN ANY SHIFT LEVER POSITION (M548A3)—Continued


## 0071 00

# **3BY**


- 1. Faulty transmission beyond unit maintenance repair.
- 2. Notify your supervisor.

## CARRIER DOES NOT PIVOT (M548A1)

#### **INITIAL SETUP:**



## CARRIER DOES NOT PIVOT (M548A1)—Continued



# **TRANSMISSION DOES NOT PIVOT STEER (M548A3)**

## 0073 00

## INITIAL SETUP:

Maintenance Level

Unit

#### Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Slip Joint Pliers (WP 0541 00, Item 33)

## Personnel Required


Unit Mechanic

## References


See your -10

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Transmission in PV position (see your -10) Center seat raised (see your -10) Center floor plates removed (WP 0395 00)



## TRANSMISSION DOES NOT PIVOT STEER (M548A3)—Continued




## TRANSMISSION DOES NOT PIVOT STEER (M548A3)—Continued

# **3**Y


- 1. Install wiring harness 12313482 plug on wiring harness
- 12313483 jack at carrier bulkhead.
- 2. Replace faulty transmission shift control switch (WP 0309 00).
- 3. Verify no faults found.

## **CARRIER MOVES WITH TRANSMISSION IN SL (M548A3)**

#### **INITIAL SETUP:**



## CARRIER MOVES WITH TRANSMISSION IN SL (M548A3)—Continued




## CARRIER MOVES WITH TRANSMISSION IN SL (M548A3)—Continued

# **4**Y


- 1. Install wiring harness 12313482 plug on wiring harness
- 12313483 jack at carrier bulkhead.
- 2. Replace faulty transmission shift control switch(WP 0309 00).
- 3. Verify no faults found.

# CARRIER DRIFTS OR DOES NOT STEER (M548A3)

#### **INITIAL SETUP:**




## CARRIER DRIFTS OR DOES NOT STEER (M548A3)—Continued




# SERVICE AND/OR PARKING BRAKE WILL NOT HOLD CARRIER (M548A3)

0076 00

#### **INITIAL SETUP:**





0076 00

## SERVICE AND/OR PARKING BRAKE WILL NOT HOLD CARRIER (M548A3)—Continued

#### NO Check operation of service brake linkage (1) between brake pedal 1. Replace/adjust service brakes control (2) and transmission (3). linkage (WP 0347 00 or 2. Is linkage free from obstruction, binding, and damage? WP 0348 00). Verify no faults found. 2. 2 3 YES 2YN NO Check transmission brake adjustment (WP 0313 00). Faulty transmission brakes beyond Did brakes require adjustment? unit maintenance repair. 2 Notify your supervisor. 2. YES **3**Y **3YN** NO Check service brake control linkage adjustment (WP 0347 00). Adjust service brake control linkage 1. 1. Is service brake linkage properly adjusted? (WP 0347 00). 2. Verify no faults found. 2 YES 43 Verify no faults found.

# TRANSMISSION WILL NOT UPSHIFT OR SHIFTS ERRATICALLY IN 1-4 POSITION (M548A3)

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) STE/ICE Test Set (WP 0541 00, Item 6)

#### Personnel Required


Unit Mechanic

#### References


See your -10 TM 9-4910-571-12&P

#### Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Transmission in SL (see your -10) Power plant rear access panel removed (see your -10) Center seat raised (see your -10)



# TRANSMISSION WILL NOT UPSHIFT OR SHIFTS ERRATICALLY IN 1-4 POSITION (M548A3)—Continued



# TRANSMISSION WILL NOT UPSHIFT OR SHIFTS ERRATICALLY IN 1-4 POSITION (M548A3)—Continued

0077 00

**3**Y

- 1. G2 pressure is OK.
- 2. Transmission faulty beyond unit repair.
- 3. Notify your supervisor.

# **TRANSMISSION DOES NOT DOWNSHIFT IN 1-4 POSITION (M548A3)**

## INITIAL SETUP:

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Pressure Gauge Kit (WP 0541 00, Item 34)

#### Personnel Required

Unit Mechanic

## References


See your -10

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Transmission in SL (see your -10) Power plant rear access panel removed (see your -10) Center seat raised (see your -10)

# NOTE

## Pressure gauge must read 4 psi (28 kPa). Any other reading indicates a fault.



# TRANSMISSION DOES NOT DOWNSHIFT IN 1-4 POSITION (M548A3)—Continued

0078 00

## 2Y

1. Faulty transmission beyond unit maintenance repair.

2. Notify your supervisor.

# **TRANSMISSION DOES NOT HOLD 1ST POSITION (M548A3)**

## 0079 00

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Slip Joint Pliers (WP 0541 00, Item 33)

#### Personnel Required


Unit Mechanic

## References


See your -10

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Transmission in 1st position (see your -10) Cab floor plates raised (WP 0395 00)







## TRANSMISSION DOES NOT HOLD 1ST POSITION (M548A3)—Continued

# **3**Y

- 1. Install wiring harness 12313482 plug on wiring harness
- 12349813 jack at carrier bulkhead.
- 2. Replace faulty transmission shift control switch (WP 0309 00).
- 3. Verify no faults found.

# **TRANSMISSION DOES NOT HOLD 2ND POSITION (M548A3)**

## 0080 00

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Slip Joint Pliers (WP 0541 00, Item 33)

### Personnel Required


Unit Mechanic

## References


See your -10

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Transmission in 1-2 position (see your -10) Cab floor plates raised (WP 0395 00)



## TRANSMISSION DOES NOT HOLD 2ND POSITION (M548A3)—Continued



# TRANSMISSION DOES NOT HOLD 2ND POSITION (M548A3)—Continued

# **3**Y

- 1. Install wiring harness 12313482 plug on wiring harness
- 12313483 jack at carrier bulkhead.
- 2. Replace faulty transmission shift control switch (WP 0309 00).
- 3. Verify no faults found.

# **TRANSMISSION DOES NOT HOLD 3RD POSITION (M548A3)**

# 0081 00

### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Slip Joint Pliers (WP 0541 00, Item 33)

### Personnel Required


Unit Mechanic

## References


See your -10

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Transmission in 1-3 position (see your -10) Cab floor plates raised (WP 0250 00)



## TRANSMISSION DOES NOT HOLD 3RD POSITION (M548A3)—Continued



# TRANSMISSION DOES NOT HOLD 3RD POSITION (M548A3)—Continued

# **3**Y

- 1. Install wiring harness 12313482 plug on wiring harness
- 12313483 jack at carrier bulkhead.
- 2. Replace faulty transmission shift control switch (WP 0309 00).
- 3. Verify no faults found.

# TRANSMISSION DOES NOT REVERSE (M548A3)

### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Slip Joint Pliers (WP 0541 00, Item 33)

### Personnel Required


Unit Mechanic

References


See your -10

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Transmission in R position (see your -10) Cab floor plates raised (WP 0250 00)



## TRANSMISSION DOES NOT REVERSE (M548A3)—Continued



# TRANSMISSION DOES NOT REVERSE (M548A3)—Continued


# **3**Y

- 1. Install wiring harness 12313482 plug on wiring harness
- 12313483 jack at carrier bulkhead.
- 2. Replace faulty transmission shift control switch (WP 0309 00).
- 3. Verify no faults found.

# **BILGE PUMP SYSTEM SCHEMATIC**

# NOTE

M548A1 has two batteries. M548A3 has four batteries. M548A1 bilge pump system schematic is shown.



# FRONT BILGE PUMP AND/OR LIGHT DOES NOT OPERATE

### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

### Personnel Required

Unit Mechanic

#### References


See your -10

**Equipment Condition** 


Engine stopped (see your -10) Carrier blocked (see your -10) MASTER SWITCH OFF (see your -10) Driver's seat raised (see your -10) Center floor plates raised (WP 0394 00 or WP 0395 00)

# NOTE


### M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.



## FRONT BILGE PUMP AND/OR LIGHT DOES NOT OPERATE—Continued




# FRONT BILGE PUMP AND/OR LIGHT DOES NOT OPERATE—Continued



# FRONT BILGE PUMP AND/OR LIGHT DOES NOT OPERATE—Continued 0084 00 **3BY 3BYN** NO Turn MASTER SWITCH OFF. 1. Replace bilge pump circuit breaker 2. Remove plug 450A (1) and plug 450 (2) from bilge pump circuit (WP 0268 00). breaker (3). Verify no faults found. 2 Measure resistance between circuit breaker jacks. 3. 4. Does multimeter read 0 ohms? 2 YES 4BY **4BYN** NO Measure resistance between plug 450C to 450C lead end at bus Replace/repair circuit 450C lead 1. 1. (WP 0294 00). bar. Does multimeter read 0 ohms? 2. Verify no faults found. YES

# FRONT BILGE PUMP AND/OR LIGHT DOES NOT OPERATE—Continued



### FRONT BILGE PUMP AND/OR LIGHT DOES NOT OPERATE—Continued

0084 00

# 3CY

1. Replace bilge pump discharge tubes and hoses (WP 0425 00).

2. Verify no faults found.

# **VEHICLE COMPARTMENT HEATER MALFUNCTIONS**

### **INITIAL SETUP:**

 Maintenance Level

 Unit

 Tools and Special Tools

 General Mechanic's Tool Kit (WP 0541 00, Item 57)

 Multimeter (WP 0541 00, Item 29)

 Slip Joint Pliers (WP 0541 00, Item 33)

 Personnel Required

Unit Mechanic

References

See your -10 TM 9-2540-205-24&P


**Equipment Condition** 


Engine stopped (see your -10) Carrier blocked (see your -10) Heater HI-LO switch in LO

# NOTE


M548A1 and M548A3 troubleshooting procedures are the same even though component locations are different. When needed, locators are used to show the different component locations.


The M548A3 has a fuel filter in between the fuel pump and the heater.





## VEHICLE COMPARTMENT HEATER MALFUNCTIONS—Continued 0085 00 **10Y** 10YN NO 1. Listen to heater until blower shuts off. Faulty heater flame detector switch. 2. Does blower shut off in less than five minutes? See TM 9-2540-205-24&P. YES 11**Y** Heater is operating properly. 1. 2. Verify no faults found. BY **BYN** NO Remove heater-on indicator cover lens (1) and bulb (2). Replace heater-on bulb 1. 1. (WP 0472 00). 2. Check continuity between bulb center contact and base. 3. Does multimeter indicate continuity? Verify no faults found. 2 Ŀ æ YES **2BYN** 2BY NO Remove main harness circuit 400 plug (1) from control box Repair main harness circuit 400 1. 1. jack (2). between master switch and heater 2. Measure voltage between main harness circuit 400 plug (1) pin control box (WP 0294 00). and ground. 2. Verify no faults found. 3. Does multimeter read 17 volts or more? 8 G , **e**\_ 2 1 YES






# 3CY

- Faulty vehicle compartment heater. Replace vehicle compartment heater (WP 0427 00, WP 0428 00, WP 0429 00, WP 0430 00, WP 0431 00, WP 0432 00, WP 0433 00, WP 0434 00, WP 0435 00, WP 0437 00, WP 0438 00, WP 0439 00, WP 0446 00 or WP 0447 00).
   Verify no faults found.
- DY DYN NO Remove heater control box (WP 0431 00). Repair faulty lead (WP 0294 00). 1. 1. Measure resistance between lead ends from circuit breaker Verify no faults found. 2. 2. terminal 17 (1) and RUN-OFF-START switch terminal 15 (2). 3. Does multimeter read 0 ohms? 2 YES 2DY 2DYN NO Repair heater switch jumper lead Measure resistance between lead ends from RUN-OFF-START switch terminals 21 (1) and 14 (2). between terminal 21 and 14 2. Does multimeter read 0 ohms? (WP 0294 00). 2 Verify no faults found. YES


## **3DY**


- Replace heater RUN-OFF-START switch (WP 0472 00).
   Verify no faults found.
- 2. Verify no faults fo





# **3EY**

- 1. Replace vehicle compartment heater fuel pump (WP 0448 00 or WP 0449 00).
- 2. Verify no faults found.











# COOLANT HEATER MALFUNCTIONS


### **INITIAL SETUP:**





0086 00-1


### TM 9-2350-247-20-1

























## 2FY

- 1. Replace heater ON/OFF/START switch (WP 0472 00).
- 2. Verify no faults found.




#### COOLANT HEATER MALFUNCTIONS—Continued



#### COOLANT HEATER MALFUNCTIONS—Continued

#### **3IY**

- 1. Faulty flame detector switch.
- 2. Notify your supervisor.




## SPEEDOMETER MALFUNCTIONS


Maintenance Level	References
Unit	See your -10
	See your PMCS
Tools and Special Tools	
General Mechanic's Tool Kit (WP 0541 00, Item 57)	Equipment Condition
Materials/Parts	Engine stopped (see your -10)
Grease WP 0542 00, Item 14 Personnel Required	Carrier blocked (see your -10)
	Instrument panel partially removed (WP 0256 00)
	Left cab floor plate removed (WP 0394 00 or
Unit Mechanic	WP 0395 00)


## NOTE

M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.




#### SPEEDOMETER MALFUNCTIONS—Continued





#### SPEEDOMETER MALFUNCTIONS—Continued

0087 00




## TACHOMETER MALFUNCTIONS

#### **INITIAL SETUP:**


ee your -10 ee your PMCS
-
~
ipment Condition
Ingine stopped (see your -10)
Carrier blocked (see your -10)
ower plant rear access door/panel removed
(see your -10)
nstrument panel partially removed (WP 0256 00)

NOTE

#### M548A1 and M548A3 troubleshooting procedures are the same. M548A1 procedure is shown.



## **TACHOMETER MALFUNCTIONS—Continued** 008800 2 Y N NO Inspect tachometer flexible core. Replace tachometer cable 2. Is flexible core serviceable? (WP 0522 00 or WP 0523 00). Verify no faults found. YES **3**Y 3VN NO Replace tachometer adapter Remove tachometer adapter from engine (WP 0520 00 or WP 0521 00). (WP 0520 00 or WP 0521 00). Is tachometer adapter (1) serviceable? Verify no faults found. 2. 3 YES 4YFaulty shaft drive assembly. Ι. Notify your supervisor. 2 BY BYN NO Check tachometer if it gives a steady reading. Replace tachometer (WP 0519 00). 1. Does tachometer fail to give a steady reading? Verify no faults found. 2. YES



#### TACHOMETER MALFUNCTIONS—Continued

0088 00

### **3BY**

- 1. Replace tachometer cable (WP 0522 00 or WP 0523 00).
- 2. Verify no faults found.


## WINCH CASE OVERHEATS (M548A1)

#### INITIAL SETUP:


Maintenance Level Unit	References See your -10
Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57)	Equipment Condition
Personnel Required Unit Mechanic	Engine stopped (see your -10) Carrier blocked (see your -10)
<ul><li>T</li><li>1. Pull out wire rope from winch drum (see your -10).</li><li>2. Is winch drum dragging?</li></ul>	<b>NO 1</b> . Notify your supervisor.
YES	
<ol> <li>Adjust winch brakes (WP 0409 00).</li> <li>Verify no faults found.</li> </ol>	

# WINCH DRUM DOES NOT TURN WITH DRUM CLUTCH IN "CLUTCH IN" POSITION (M548A1)

#### **INITIAL SETUP:**



## WINCH DRUM DOES NOT TURN WITH DRUM CLUTCH IN "CLUTCH IN" POSITION (M548A1)—Continued



# WINCH DRUM DOES NOT TURN DRUM CLUTCH IN "CLUTCH OUT" POSITION (M548A1)

#### **INITIAL SETUP:**

 Maintenance Level
 References


 Unit
 See your -10

 Tools and Special Tools
 Equipment Condition


 General Mechanic's Tool Kit (WP 0541 00, Item 57)
 Equipment Condition

 Personnel Required
 Engine stopped (see your -10)


 Unit Mechanic
 Carrier blocked (see your -10)




## WINCH DRUM DOES NOT TURN DRUM CLUTCH IN "CLUTCH OUT" POSITION (M548A1)—Continued



## WINCH BRAKE DOES NOT HOLD (M548A1)





# POWER TAKEOFF DOES NOT ENGAGE WHEN WINCH CONTROL IS ACTUATED (M548A1)

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57)

#### Personnel Required


Unit Mechanic

#### References


See your -10

**Equipment Condition** 

Engine stopped (see your -10) Carrier blocked (see your -10) Power plant upper rear access door removed (see your -10) Center seat raised (see your -10) Center floor plates removed (WP 0394 00)



## POWER TAKEOFF DOES NOT ENGAGE WHEN WINCH CONTROL IS ACTUATED (M548A1)—Continued



# EXCESSIVE OIL LEAKS (WINCH TRANSFER GEARCASE AND POWER TAKEOFF) (M548A1)

#### **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57)


#### Personnel Required

Unit Mechanic

#### References

See your -10

Equipment Condition Engine stopped (see your -10) Carrier blocked (see your -10)



## WINCH PROPELLER SHAFT NOISY DURING OPERATION (M548A1)

#### **INITIAL SETUP:**

Maintenance Level Unit

.....

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Personnel Required


Unit Mechanic

References

See your -10

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10)



## COMPRESSOR AIR OUTPUT ADEQUATE, BUT NO AIR PRESSURE INDICATION ON PANEL AIR BRAKE PRESSURE INDICATOR (M548A1)

#### 0096 00

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57)

Personnel Required


Unit Mechanic

References

See your -10


**Equipment Condition** 

Engine stopped (see your -10) Carrier blocked (see your -10) Power plant rear access door removed (see your -10)



## COMPRESSOR AIR OUTPUT ADEQUATE, BUT NO AIR PRESSURE INDICATION ON PANEL AIR BRAKE PRESSURE INDICATOR (M548A1)—Continued

#### 0096 00



## LOW AIR PRESSURE WARNING LIGHT DOES NOT LIGHT WHEN AIR PRESSURE FALLS BELOW 60 PSI (414 KPA) (M548A1)

#### 0097 00

#### **INITIAL SETUP:**


Maintenance Level References Unit Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29) Personnel Required

Unit Mechanic


See your -10

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10)



### LOW AIR PRESSURE WARNING LIGHT DOES NOT LIGHT WHEN AIR PRESSURE FALLS BELOW 60 PSI (414 KPA) (M548A1)—Continued



## **COMPRESSOR DOES NOT MAINTAIN AIR PRESSURE (M548A1)**

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57)

#### Personnel Required


Unit Mechanic

#### References

See your -10


#### Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Power plant rear access cover/door removed (see your -10)






#### 0098 00



#### COMPRESSOR DOES NOT MAINTAIN AIR PRESSURE (M548A1)—Continued

#### 0098 00



## COMPRESSOR DOES NOT MAINTAIN AIR PRESSURE (M548A1)—Continued

0098 00

### 9Y

- 1. Replace worn compressor (WP 0489 00).
- 2. Verify no faults found.

## TOWED LOAD BRAKES DO NOT OPERATE WHEN PEDAL IS PRESSED; AIR PRESSURE ADEQUATE (M548A1)

0099 00

### **INITIAL SETUP:**

Aaintenance Level	References
Unit	See your -10
Cools and Special Tools	
General Mechanic's Tool Kit (WP 0541 00, Item 57)	Equipment Condition
Personnel Required Unit Mechanic	Engine stopped (see your -10) Carrier blocked (see your -10)
	Carrier blocked (see your -10)
ſ	TN
. Start engine (see your -10).	<b>NO</b> 1. Stop engine (see your -10).
2. Check for faulty treadle valve (1).	2. Notify your supervisor.
8. While observing air indicator gauge, press brake pedal a	
release. Pressure should momentarily drop and stabilize.	
also audibly exhaust from treadle valve (1) as air brake p	
released. If no needle movement is noted, treadle valve i	is faulty.
. Did treadle valve (1) cause needle movement?	
the second se	<b>x</b>
	7
Y	
Э	
YES	
V H	VN

Y YN
1. Check air lines, tubings, fittings, and coupler to towed load for air leaks.
2. Is brake system free of air leaks?
YN
1. Stop engine (see your -10).
2. Replace faulty parts (WP 0495 00).
3. Verify no faults found.

YES

## TOWED LOAD BRAKES DO NOT OPERATE WHEN PEDAL IS PRESSED; AIR PRESSURE ADEQUATE (M548A1)—Continued

0099 00

#### 2Y

- 1. Stop engine (see your -10).
- 2. Notify your supervisor.

### TOO MUCH OIL DRAINAGE FROM RESERVOIR DRAIN COCK (M548A1)

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57)

#### Personnel Required


Unit Mechanic

#### References

See your -10


#### **Equipment Condition**

Engine stopped (see your -10) Carrier blocked (see your -10) Power plant rear access door removed (see your -10) Center seat raised (see your -10)



#### TOO MUCH OIL DRAINAGE FROM RESERVOIR DRAIN COCK (M548A1)—Continued

#### 0100 00



#### TOO MUCH FOREIGN MATTER IN RESERVOIR (M548A1)

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57)

#### Personnel Required


Unit Mechanic

#### References


See your -10

#### **Equipment Condition**

Engine stopped (see your -10) Carrier blocked (see your -10) Power plant rear access door removed (see your -10) Center seat raised (see your -10)



#### TOO MUCH FOREIGN MATTER IN RESERVOIR (M548A1)—Continued



### COMPRESSOR OPERATION TOO NOISY (M548A1)

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57)

#### Personnel Required


Unit Mechanic

#### References


See your -10


Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Power plant rear access door removed (see your -10)




#### COMPRESSOR OPERATION TOO NOISY (M548A1)—Continued






#### COMPRESSOR OPERATION TOO NOISY (M548A1)—Continued



#### COMPRESSOR OPERATION TOO NOISY (M548A1)—Continued



#### 0103 00

#### **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

Personnel Required

Unit Mechanic


#### References

See your -10


#### **Equipment Condition**


Engine stopped (see your -10) Carrier blocked (see your -10)


Т		
1.	Turn NBC AIR FILTER SWITCH (1) OFF (see your -10).	<b>NO</b> GO TO <b>BY</b> (PAGE 0103 00-3)
2.	Turn MASTER SWITCH OFF.	
3.	Remove NBC wiring harness connector J1 (2) from particulate	
	precleaner (3).	
4.	Turn MASTER SWITCH ON.	
5.	Turn NBC AIR FILTER SWITCH (1) ON (see your -10).	
6.	Measure voltage between wiring harness connector J1 (2) and	
	ground.	
7.	Does multimeter read more than 17 volts?	
	YES	
	$\checkmark$	



0103 00









#### TM 9-2350-247-20-1

#### PARTICULATE PRECLEANER MOTOR DOES NOT WORK (M548A3)—Continued





#### M3 HEATER DOES NOT WORK (M548A3)

#### **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

## Personnel Required


Unit Mechanic


References


See your -10


Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10)

















#### NO AIR FLOW AT ONE OR MORE OUTLETS (M548A3)

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

## Personnel Required

Unit Mechanic

References


See your -10 TM 3-6680-316-10

**Equipment Condition** 

Engine stopped (see your -10) Carrier blocked (see your -10)


#### NOTE

#### Where more than one component exists, troubleshoot one path at a time.



0105 00

#### NO AIR FLOW AT ONE OR MORE OUTLETS (M548A3)—Continued




#### NO AIR FLOW AT ONE OR MORE OUTLETS (M548A3)—Continued

#### 0105 00



2.


3YN NO Turn NBC AIR FILTER SWITCH (1) OFF (see your -10). 1 Turn MASTER SWITCH OFF. 3. Loosen clamp (2) and remove hose (3) from manifold (4). 2. 4. Turn MASTER SWITCH ON. 5. Turn NBC AIR FILTER SWITCH (1) ON (see your -10). 6. Is air flow from hose (3) restricted? 4. 1 5.




YES

- Turn NBC AIR FILTER switch OFF (see your -10). Turn MASTER SWITCH OFF. 3. Cover air intake holes by sliding spring clip forward over holes on
  - particulate precleaner. Repair and/or replace manifold
  - (WP 0533 00).
  - Verify no faults found.

#### NO AIR FLOW AT ONE OR MORE OUTLETS (M548A3)—Continued



#### NO AIR FLOW AT ONE OR MORE OUTLETS (M548A3)—Continued



#### LOW AIR FLOW AT ALL OUTLETS (M548A3)

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) Multimeter (WP 0541 00, Item 29)

#### Personnel Required

Unit Mechanic

References


See your -10 TM 3-6680-316-10

Equipment Condition


Engine stopped (see your -10) Carrier blocked (see your -10)

#### NOTE


#### Where more than one component exists, troubleshoot one path at a time.



#### LOW AIR FLOW AT ALL OUTLETS (M548A3)—Continued



#### LOW AIR FLOW AT ALL OUTLETS (M548A3)—Continued



## INTRODUCTION STE/ICE-R (SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES-REPROGRAMMABLE) PROCEDURES

#### GENERAL

STE/ICE–R, a testing system for internal combustion engines, provides measurements on voltage resistance, pressure, temperature and speed to analyze the condition of an engine system.


STE/ICE–R, a testing system for internal combustion engines, provides measurements on voltage resistance, pressure, temperature and speed to analyze the condition of an engine system.

This section provides a general overview of STE/ICE–R equipment and operations, along with specific procedures in diagnosing and isolating malfunctions of the M548A1 or M548A3 engine.

STE/ICE–R will also provide a thorough preventative maintenance check on the M548A1 or M548A3 engine as part of service upon receipt and as an annual check in the PMCS.

#### **DESCRIPTION OF STE/ICE-R EQUIPMENT**


The STE/ICE–R set consists of a vehicle test meter (VTM), five cable assemblies, transducer kit (TK), TM 9-4910-571-12&P manual, test probe kit and transit case.



## INTRODUCTION STE/ICE-R (SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES-REPROGRAMMABLE) PROCEDURES—Continued

#### Vehicle Test Meter (VTM)

The VTM is the diagnostic meter of STE/ICE–R used for testing electrical and mechanical components of the M548A1 or M548A3 engine. The VTM consists of three switches, a readout display, flip cards, and four cable connectors.



a. SWITCHES.

The three switches are a PUSH ON/PULL OFF switch, TEST SELECT switch and TEST button. The PUSH ON/PULL OFF switch is used to control power to the VTM from the power source. The TEST SELECT switch are two ten-position switches used to select the test to be performed. The TEST button has two functions: (1) when pressed and released, it initiates selected test; (2) when pressed and held, it initiates an offset test.

#### **b. READOUT DISPLAY.**

The readout display gives five different types of messages during testing and up to a maximum of four characters per message. The readout display messages can be found on (WP 0107 00). The types of messages are:

- error,
- status,
- numerical,
- prompting, and
- confidence test error.


# **c. FLIP CARDS.** The flip cards, attached to the front of the VTM, provide a quick but limited reference for the operator. These flip cards list test numbers, messages, and some procedures. Test limits are also provided for some vehicles.

#### 0107 00-2

# INTRODUCTION STE/ICE-R (SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES-REPROGRAMMABLE) PROCEDURES—Continued

**d. CABLE CONNECTORS.** The four cable connectors on the VTM are DCA/PWR J1, transducer cable connectors J2 TK and J3 TK, and VOLTS/OHMS J4.

- DCA/PWR connector J1 used to connect VTM to either a vehicle diagnostic connector with the DCA cable W1 or to a DC power source with the power cable W5. The DC power source is usually the vehicle's batteries.
- Transducer cable connectors J2 TK and J3 TK used to connect transducer cables W4 to VTM. Power and signals are routed through these connectors. Both connectors may be used when a test requires two measurements to be made at the same time.
- VOLTS/OHMS connector J4 used to connect test probe cable W2 to VTM for voltage and resistance tests.




# INTRODUCTION STE/ICE-R (SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES-REPROGRAMMABLE) PROCEDURES—Continued

#### **Cable Assemblies**


In procedures in this manual, the cable assemblies are referred to by a number for quick identification. Each cable also has a name which describes its use. A reference to W1, for example, would indicate the DCA cable. Connectors on the cable are identified by a number preceded by either a P or an E, such as P1 or E2.


The cable assemblies included in the STE/ICE-R are:


- W1 DCA cable,
- W2 test probe cable,
- W3 ignition adapter cable,
- W4 transducer cable (two), and
- W5 power cable.












W4

CE I S wз

0107 00

When cables are connected, the large key (1) located by the white stripe (2) on the cable connector mates with large keyway (3) of connector on VTM or transducer.



a. DIAGNOSTIC CNCTR ASSY CABLE W1.

b. TEST PROBE CABLE W2.

connected to vehicle/equipment-mounted DCA. The test probe cable for both general and special measurements. It is used for measuring voltages, frequency, resistance and continuity, and also for the first peak


The W1 is used to power the VTM and provide access to test points and sensors

series and compression unbalance tests. W2 is divided into two color coded leads: red for E1 and black for E2. Test clips E1 and E2 of W2 attach to points on the


c. IGNITION ADAPTER CABLE W3. The ignition adapter cable W3 is used in measuring dwell angle, points voltage, engine rpm and power tests. W3 is divided into two color coded leads: red for E1 and black for E2.

vehicle/equipment being tested.

d. TRANSDUCER<br/>CABLES W4.The transducer cables W4 are used as extensions to connect the VTM to a pressure<br/>transducer, pulse tachometer, current probe or ignition adapter cable. If necessary,<br/>two transducer cables can be joined using connector adapter, TK item 29.



e. POWER CABLES W5. The power cable W5 is used to power the VTM when cable W1 is not being used. Cable W5 is divided into two leads with color coded clips: red for E1 and black for E2. Battery clips E1 and E2 are attached to a vehicle/equipment battery or a 9 to 32 volt 4A regulated power supply. Do not connect the VTM to a battery charger. Damage to the VTM may result.



## Transducer Kit (TK)

The TK is a tray inside the transit case that contains transducers, adapters, and fittings. The TK is stored in a molded tray in the top of the case.

Many of the fittings do not have part number markings on them and are referred to by TK item number and name. Each fitting is identified by TK item number and part number.


## Manual

TM 9-4910-571-12&P contains operating instructions, operator and organizational maintenance instructions, and repair parts and special tools information.

## **Transit Case**

The STE/ICE-R is housed in a portable protective transit case which contains all necessary accessories and instructions.

A pressure relief valve located on the front of the case allows the operator to release any pressure or vacuum resulting from changes in climate during transit.



TECHNICAL MANUAL

## **READOUT DISPLAY MESSAGES**

## **Error Messages**

Error messages indicate the VTM needs additional or corrected information before testing can continue or additional procedures are required.

All error messages are displayed as an E followed by three numbers (for example, E003).

DISPLAY

MEANING

E000

VTM has been asked for information that it does not have. For example, you have requested the vehicle/equipment ID and it has not been entered.

E001	A test number which does not exist has been entered on the TEST SELECT switches.
E002	The required transducer is not connected.
E003	Test number wrong for DCA connected. This can occur if test selected does not apply to the class of vehicle/equipment under test or if the DCA harness does not have the required transducer.
E004	No longer used. If message appears turn in test set.
E005	Required offset test was not performed.
E007	The VID number and number-of-cylinders information entered do not agree.
E008	VTM is not receiving required voltage signal for selected test. This message can occur on tests, 14, 15, and 72 thru 79.
E009	VTM is not receiving engine speed signal. This applies only to engine power test and SI full power simulation.
E010	A wrong VID number was entered. The VTM will only accept numbers between 01 and 99. If E010 is displayed when the VID entered was between 01 and 99, it means that the VID does not agree with the identity of the DCA harness powering the VTM. The VTM will accept this, allowing you to power through the DCA while testing another vehicle.
E011	Throttle control was operated incorrectly. It was taking too long to accelerate or decelerate during power test.
E012	The SI ignition adapter, TK item 30, or CI pulse tachometer, TK item 34, is missing or is not connected to the VTM.
E013	VTM is unable to use data received.
E014	The wrong number of cylinders was entered.
E015	No longer used. If message appears, turn in test set.
E017	VTM is not receiving ignition information during dwell test.
E018	Test discontinued due to no information being detected by VTM. This will occur after several minutes of no-signal operation.
E020	No first peak information was detected by the VTM.
E021	VTM cannot calculate result. Current is over current probe's range, and VTM did not sample correct portion of data.
E022	External voltage was detected in the circuit under test while measuring resistance.
E023	VTM's constant voltage source is not working.
E024	Test is not valid for VID entered.
E027	Error is entry of compression unbalance constants.
E028	Test just entered cannot be used with control function 06.
E030	VID entered conflicts with speed transducer attached.
E032	Carrier's cranking speed is varying too much for a compression unbalance measurement.

E033

Error in entry of power test constants.

## **Status Messages**

Status messages keep the operator informed of what is happening.

DISPLAY	MEANING
.8.8.8.8	There is power to the VTM, and the display is working properly. This appears only for a short period after power is turned on.
.9.9.9.9	VTM is reading a test value beyond its range.
PASS	Unit under test has passed test, or VTM has accepted a control function entry.
FAIL	Unit under test has failed test.
CON	Accepted control function input.
AUE	Numerical display is an average value.
LO	Engine speed below 1600 rpm during SI power test indicates the engine failed the power test.
-1-1-1-1	VTM is busy.

## **Numerical Readouts**

Units of measurement (psi, rpm, Volts, etc.) are not displayed. Numerical readouts indicate the measured value in units of the measurement being made. For example, if you are measuring 0–45 volts dc, 12.7 is volts dc. If you are measuring 0–25 psig pressure, 12.7 is psig. The units for each test are listed on the flip cards. Also, the readout will alternate between displaying values and displaying vehicle identification data (VID).

## **Prompting Messages**

Prompting messages tell the operator to do something. After the operator action is completed, testing will continue. Some of the prompting messages and their meanings are as follows:

DISPLAY	MEANING
UEH	Tells the operator to enter VID on the TEST SELECT switches.
CYL	Tells the operator to enter the number-of-cylinders into the VTM.
GO	Tells the operator to crank engine.
0066	Tells the operator to set TEST SELECT switches to 99 during confidence test.
CAL	Tells the operator to release the TEST button during an offset test.
CIP	Tells the operator to apply full throttle in a CI power test.

## **Confidence Test Error Messages**

Confidence test messages are displayed either as PASS or by a C followed by three numbers (#). A C### is an error message used by VTM repair personnel as an aid in troubleshooting.

If a C### message appears during confidence test or during normal operation, go to confidence test fault isolation, TM 9-4910-571-12&P, for the necessary corrective action.

### **TEST METHOD**

The test method consists of a pre-test inspection and STE/ICE-R testing.

### **Pre-test Inspection**

Before using STE/ICE-R to test the carriers, perform the following pre-test inspections:

a. FAN BELTS.	Check for proper tension. Replace if cracked of frayed.		
b. OIL LEVEL.	Bring up to proper level if low.		
c. FUEL LEVEL.	Check that the fuel tank has enough fuel for testing.		
d. RADIATOR.	Bring up to proper level if low.		
e. BATTERY.	Replace the battery if the case is cracked or the terminal posts are damaged. Clean off all corrosion. Check that the battery connections to ground and starter motor are in good condition, securely connected, and clean. Check the electrolyte level. See TM 9-6140-200-14. If low, bring up to proper level with distilled water.		

## Vehicle Test Card (VTC)

Once familiar with STE/ICE–R testing procedures, the vehicle test card (located on (WP 0107 00)) can be used as a quick reference.

The front of the test card contains all of the information, in abbreviated format, that the user will need to perform common measurements on the carrier. The organization from the top of the card to the bottom represents a logical order of steps from powering up the VTM to completing a series of tests.

The top of the card describes the power up sequence of STE/ICE–R for the carrier. Next, a table is provided which lists many measurements that are useful in troubleshooting the carrier. The table includes the associated VTM test number, any required offset test limits, operating condition of the engine, special connections required, the expected limits for pass or fail, and the units of measurement. Also included on the front of the card are hook-up diagrams.

The organization of the table allows measurements with the carrier engine turned off to be performed first. These measurements will ensure that the starting system of the carrier is in working order before proceeding. The order of the other measurements is as follow:

Measurements with the engine running but not warm.

Measurements requiring the engine to be warm and running.

Measurements requiring the engine to be warm and not running.

Miscellaneous measurements.

The back of the VTC contains the hookups for measurements used to troubleshoot carrier components. Measurements that require special hookups are also included on this side of the VTC.

### STE/ICE-R ENGINE TROUBLESHOOTING METHOD

When a malfunction in the engine is recognized by the mechanic, the "flip cards to Troubleshooting" will provide a reference to a specific procedure to isolate the cause of the malfunction.

To start the STE/ICE-R engine troubleshooting method, do the following:

a. PERFORM HOOK UP.	First, perform HOOK UP to set up STE/ICE–R and check to see if it is in working order.
b. PERFORM PROCEDURE.	Now that STE/ICE–R is hooked up properly and checks out, perform the procedure cited in the "Quick Guild Troubleshooting."

The rules to follow when using STE/ICE-R engine troubleshooting method are:

(1) Never enter in the middle of a procedure.

- (2) Follow each instruction in a procedure. Do not skip any instructions or procedures.
- (3) After correcting a problem with a procedure, test run the component, engine or power plant to ensure the problem does not still exist.

## **BATTERY TEST CARDS**

The STE/ICE–R battery test procedures allow the user to evaluate the condition and state of charge of carrier/equipment batteries. These procedures use the battery internal resistance and battery resistance change measurements. Battery internal resistance evaluates the state of charge of the battery. Battery resistance change evaluates the battery condition.

Battery state of charge is a measure of the amount of energy stored in the battery. A fully charged battery contains the maximum amount of energy stored. If the battery fails the battery state of charge evaluation, the battery may be recharged to return the battery to full charge.

The battery condition is a measure of the battery's ability to accept and maintain a good charge. A battery in poor condition may be able to be fully recharged. However, a battery in poor condition with a full charge will lose its charge more quickly than a better in good condition with a full charge. If a battery fails the battery condition evaluation, then the battery should be replaced.

The procedures for testing batteries are listed on three battery test cards. Each card describes procedures for evaluating different combinations of batteries:

Complete battery pack, Series pair of batteries, and Individual batteries.

## BATTERY PARKS

A battery pack is the combination of four or more batteries in a particular circuit of a carrier/equipment, i.e. the starting circuit. Testing the batteries in a pack evaluates the general condition of the pack as a whole. Note, the results of a battery pack test may be misleading. A single battery from a pack of four may be bad even though the pack as a whole may pass the tests. This can happen if the other three batteries in the pack are in very good condition. In order to test a battery pack, the current probe must be clamped around a single cable carrying all of the starter current. If such a connection cannot be made, then test each pair of batteries separately.

## SERIES PAIRS

A series pair is one in which the negative terminal of one battery is connected by a cable to the positive terminal of another battery. This test configuration should be used when any of the following conditions exists:

- There are only two batteries (one series pair) in the carrier/equipment.
- An evaluation of the pack is desired, but the current probe cannot measure the total starter current. This condition can occur if the cable is not readily accessible or if the cable is physically too large.
- The battery pack test has failed, and the user wants to further identify any bad battery pair.

Note: Testing each series pair yields a better evaluation than testing the pack as a whole.

## INDIVIDUAL BATTERIES

An individual battery test refers to the process of testing one battery at a time. The battery could be part of a pack, a series pair, or a single battery. Test the batteries individually if a battery series pair failed the tests and it is desired to isolate to a single battery (or if there is only one battery in the circuit). Testing individual batteries gives the best evaluation.

## **DESCRIPTION OF TEST CARDS**

The front of each test card has three sections. The top of the card explains how to connect the VTM to the batteries being tested. The middle part of the card describes the procedure to follow in order to evaluate the batteries. The bottom of the card contains illustrations showing typical carrier hookups.

The back of each card also has three sections. The upper left-hand block lists the possible VTM displays and explains their meanings. This block suggests corrective action for the user. The right-hand side of the card contains battery test limits for three common military batteries. These limits may be used if the carrier/equipment TM does not provide limits. The lower left-hand portion of the card contains a table showing how to apply the limits to evaluate the battery condition and state of charge.

## BATTERY EVALUATION PROCEDURE

## Use Procedures On Battery Test Card To Hook-up VTM.

The following information will enable the user to determine the correct tests:

Use series 73 and 75 for the following conditions:

- (1) Testing a battery pack that is also powering the VTM.
- (2) Testing a battery series pair that is also powering the VTM.
- (3) Testing an individual battery that is the only battery in the circuit and is powering the VTM.

Use series 77 and 79 for the following conditions:

- (1) Testing a battery pack that is not powering the VTM.
- (2) Testing a battery series pair that is not powering the VTM.
- (3) Testing an individual battery that is not the only battery in a circuit or is not powering the VTM.

## Use Test Procedure On Battery Test Card To Complete Evaluation.

Evaluate battery condition using battery resistance change test (#75 or #79). Note the result.

Evaluate battery state of charge using the battery internal resistance test (#73 or #77). Note the result.

Compare test results to limits in carrier/equipment TM. If carrier/equipment TM does not have test limits, use test limits provided in this section. If the battery internal resistance test passes, then the batteries are fully charged. If the battery internal resistance test fails, then the batteries are not adequately charged. If the battery resistance change test passes, then the batteries are good and will retain their charge. If the battery resistance change test fails, then the batteries are bad and will not retain their charge.

If batteries are out of limits, perform one or all of the following:


- (1) Check battery electrolyte level.
- (2) Check battery connections and terminals. Clean or tighten if necessary. Check connections between VTM and batteries.
- (3) Refer to carrier/equipment TM to check battery specific gravity.
- (4) Repeat battery resistance change and internal battery resistance tests one time. If internal battery resistance result (test #73 or #77) is out of limits, then charge batteries. If battery resistance change result (test #75 or #79) is out of limits, then continue testing to isolate bad batteries.

### 0107 00

PRE-TEST INSPECTION		POWEI	RING UP VTM			<u> </u>	
	ei Level lieries		1 Connect VTM to WS cable WS ca 2 Enter VID into VTM using test 60 3 Perform confidence test, test 66	)	#A in lig	jure 2.	
MEASUREMENT NAME	VTM TEST NOS	VTM OFFSET	OPERATING CONDITION	SPECIAL CONNECTIONS REQUIRED	LIM	MAX	UNITS
Battery Voltage Current First Peak Venicle Oil Pressure Warning Light Charging Voltage Venicle Gage Coolant Temp Engine RPM (Average) Power Engine RPM (Average) Compression Unbalance Cranking RPM Cranking Voltage Cranking Voltage Cranking Current Battery Pack Internal Resistance Statter Circuit Resistance	67 72 	- 225 	Engine oll Crank on GO Idle-use test 10 to check idle speed Lights & accessories on 1000-1200 RPM Warm engine Governor Engine warm Idle Warm Engine — Crank on GO Cranking Cranking Crank on GO Crank on GO	Current probe — ligure 2 Puise tachometer — ligure 1 Puise tachometer — ligure 2 Current probe — ligure 2 Current probe — ligure 2	26.5 120	1 Goes 22.9 185 3000 - 700 8 - 425 25.0	Voits Amps Out Voits *F RPM % RPM % APM Voits Amps Milliohms


Test limits given are advisory only and are not necessarily the same as vehicle TM's specifications. If test limits are different, use vehicle TM's specifications.

\* If vehicle has a turbocharger or fuel limiter, go to vehicle TM for procedure to do power test




M113 (M548A1) VEHICLE TEST CARD - VID 03

0107 00



Test limits given are advisory only and are not necessarily the same as vehicle TM's specifications. if test limits are different, use vehicle TM's specifications.

M113 (M548A1) VEHICLE TEST CARD – VID 03 ADDITIONAL TEST CONNECTIONS



Test limits given are advisory only and are not necessarily the same as vehicle TM's specifications. If test limits are different use vehicle TM's specifications.

M113 (M548A1) VEHICLE TEST CARD - VID 03 ADDITIONAL TEST CONNECTIONS

### 0107 00

THE BATTERY INTERNAL RESISTANCE TEST (73 or 77) evaluates the state of charge of the battery series pair. The BATTERY RESISTANCE CHANGE TEST (75 or 79) evaluates whether the battery is good or bad, even if it is discharged. A good battery that is discharged may be recharged. A bad battery may hold a charge for a short time.

#### STE/ICE HOOKUP

1. The power to operate the STE/ICE-R VTM may be taken from the batteries being tested as shown in the appropriate figure below or from an alternate power source (such as another vehicle's batteries).


- 2. Perform VTM general setup; run confidence test, and enter vehicle ID
- Find a series pair of batteries. A battery series pair has the negative terminal of one battery connected to the positive terminal of another battery by a cable. For example, in figures 1 and 2 below, batteries A and B are a series pair; and in figure 1 below batteries C and D are a series pair.
- <sup>4</sup> a If power to the VTM comes from a different set of batteries than the batteries under test, use tests 77 and 79 instead of tests 73 and 75. Connect test probe cable W2 to the batteries under test. Connect the red clip to the positive terminal closest to the starter and the black clip lead to the negative terminal closest to the starter and the black clip lead to the negative terminal closest to the starter and the black clip lead to the negative terminal closest to the starter and the black clip lead to the negative terminal closest to the starter and the black clip lead to the negative terminal closest to the ground.


b. If power to the VTM comes from the same set of batteries as the batteries under test, use lests 73 and 75. The test probe cable W2 is not used

5 Clamp the current probe around the cable connecting the two batteries. Point the arrow of the current probe along the cable leading towards the negative battery terminal as shown below in figures 1 and 2 for batteries A and B.


#### TEST PROCEDURE

- 1 Condition the current probe before running these tests
- 2. Measure the battery resistance change by entering test number 75 or 79 (as described in the hookup procedure). Then engage the starter for about 5 seconds.
- 3 Measure the battery internal resistance by entering test number 73 or 77 (as described in the hookup procedure). Then engage the starter for about 5 seconds.
- 4 Compare the results of both measurements to limits in the vehicle/equipment TM or to limits on this revurse side of this curd
- 5 If either measurement is outside of normal limits, check battery terminals and connections, and check battery electrolyte level. Then perform both measurements a second time.
- 6. If the battery resistance change test (75 or 79) fails after the second measurement, then the battery series pair is in bad condition. Test each battery individually to determine which is good and which is bad or replace the battery series pair.
- 7. If the battery internal resistance test (73 or 77) fails after the second measurement, then the batteries should be recharged






### STE/ICE-R BATTERY SERIES PAIR TEST CARD



TEST 77 BATTERY INTERNAL RESISTANCE TEST RESULT	TEST 79 BATTERY RESISTANCE CHANGE TEST RESULT	BATTERY CONDITION
PASS	PASS	The battery tested is o.k. and in good state of charge
PASS	FAIL	The battery tested is in poor condition, but has a fresh charge.
FAIL	PASS	The battery tested is o.k., but needs to be recharged.
FAIL	FAIL	The battery tested is in poor condition and in a state of discharge.

## STE/ICE-R INDIVIDUAL BATTERY TEST CARD



## STE/ICE-R INDIVIDUAL BATTERY TEST CARD

## TM 9-2350-247-20-1

## INTRODUCTION STE/ICE-R (SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES-REPROGRAMMABLE) PROCEDURES—Continued

#### 0107 00

The BATTERY INTERNAL RESISTANCE TEST (73 or 77) evaluates the state of charge of an individual battery. The BATTERY RESISTANCE CHANGE TEST (75 or 79) evaluates whether the battery is good or bad, even if it is discharged. A good battery that is discharged bay be recharged, A	
bad battery may hold a charge for a short time.	

#### STE/ICE HOOKUP

- 1 The power to operate the STE/ICE-R VTM may be taken from the batteries being tested as shown in the appropriate figure below or from an alternate power source (such as another vehicle's batteries).
- 2. Perform VTM general setup; run confidence test and enter vehicle ID.
- 3. If there is more than one battery in the vehicle/equipment, then find the battery series pair that includes the battery under test. A battery series pair is a pair of batteries for which the negative terminal of one battery is connected by a cable to the positive terminal of another battery. For example, in figure 1 and 2 below, batteries A and B are a series pair, and in figure 1 below, batteries C and D are a series pair.
- 4 a If the vehicle/equipment under test has more than one battery or if the VTM is powered from an alternate power source, then use tests 77 and 79. Connect the red clip of test probe cable W2 to the positive terminal of the battery under test. Connect the black clip of test probe cable W2 to the negative terminal of the battery under test.
- If the vehicle/equipment under test has only one battery which is also supplying power to the VTM, use tests 73 and 75. The test probe cable W2 is not used.
- 5. a. If the vehicle/equipment under test has more than one battery, then the battery under test is part of a series pair of batteries. Clamp the current probe around the cable connecting the series pair. Point the arrow on the current probe along the cable leading towards the negative terminal as shown in figures 1 and 2.
  - b. If the vehicle/equipment under test has only one battery, then clamp the current probe around the positive battery cable connected to the starter. Point the arrow on the current probe along the cable in the direction leading towards the starter as shown in figure 3.

#### **TEST PROCEDURE**


- Condition the current probe before running these tests.
- 2 Measure the battery resistance change by entering test number 75 or 79 (as described in the hookup procedure). Then engage the starter for about 5 seconds.


Measure the battery internal resistance by entering test number 73 or 77 (as described in the hookup procedure). Then engage the starter for about 5 seconds.

Compare the results of both measurements to limits in the vehicle/equipment TM or to limits on the reverse side of this card

If either measurement is outside of normal limits, check battery terminals and connections, and check battery electrolyte level. Then perform both measurements a second time.

- 3. If the battery resistance change test (75 or 79) fails after the second measurement, then the battery is in bad condition. The battery may be able to accept and hold a charge, but it will quickly become discharged during use. A battery in bad condition should be replaced
- 4 If the battery internal resistance test (73 or 77) fails after the second measurement, then the battery should be recharged






STE/ICE-R INDIVIDUAL BATTERY TEST CARD

BATTERY TEST RESU	LTS
	WHAT IT MEANS
STE/ICE-R DISPLAY	<ol> <li>The battery in series with the battery under test may be bad. Check that battery next.</li> </ol>
GO	<ol> <li>Check the battery negative cables and cables to the starter for corroded or loose connections. If all of the cables and connec- tions are o.k., then the starter is possibly faulty.</li> <li>connections are o.k., it is possible that the starter is faulty.</li> </ol>
.9.9.9.9	<ol> <li>There is a bad connection on the battery being tested. Clean and tighten the posts and clamps, and check the cable between the batteries.</li> </ol>
L	2. The battery under test is in extremely poor condition.
14.2	If any number is displayed, then the number is a STE/ICE test result. Compare the test result to the values shown along the right edge of this card to determine a pass or fail. See table below to determine the condition of the battery.
F013	<ol> <li>The battery being tested may be in a discharged state. Check battery electrolyte level; charge battery, and then retest.</li> <li>If display shows E013 after battery has been charged, then the</li> </ol>
	2. If display shows E013 after battery has been charged, then the battery is in poor condition.
E002 ·····	····· The current probe is not connected. Connect current probe.
E005	Offset test for current probe has not been performed. Perform current probe offset test.
E008	Test leads are improperly connected. Check test leads.

TEST 77 BATTERY INTERNAL RESISTANCE TEST RESULT	TEST 79 BATTERY RESISTANCE CHANGE TEST RESULT	BATTERY CONDITION
PASS	PASS	The battery tested is o.k. and in good state of charge.
PASS	FAIL	The battery tested is in poor condition, but has a fresh charge
FAIL	PASS	The battery tested is o.k., but needs to be recharged.
FAIL	FAIL	The battery tested is in poor condition and in a state of discharge.

STE/ICE-R BATTERY SERIES PAIR TEST CARD



STE/ICE–R BATTERY SERIES PAIR TEST CARD

### TM 9-2350-247-20-1

## INTRODUCTION STE/ICE–R (SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES-REPROGRAMMABLE) PROCEDURES—Continued

#### 0107 00


The BATTERY INTERNAL RESISTANCE TEST (73 or 77) evaluates the state of charge of an individual battery. The BATTERY RESISTANCE CHANGE TEST (75 or 79) evaluates whether the battery is good or bad, even if it is discharged. A good battery that is discharged bay be recharged. A bad battery may hold a charge for a short time.

#### STE/ICE HOOKUP

- 1. The power to operate the STE/ICE-R VTM may be taken from the batteries being tested as shown in the appropriate figure below or from an alternate power source (such as another vehicle's batteries).
- 2. Perform VTM general setup; run confidence test, and enter vehicle ID.
- 3. a. If power to the VTM comes from a different set of batteries than the battery pack under test, use tests 77 and 79. Connect test probe cable W2 to the battery pack under test. Connect the red clip to the positive terminal closest to the starter. Connect the black clip to the negative terminal closest to vehicle/equipment ground.
- b. If power to the VTM comes from the battery pack under tests, use tests 73 and 75. The test probe cable W2 is not used.
- Clamp the current probe around the positive cable connected to the starter. Point the arrow on the current probe along the cable leading towards the starter as shown in figure 1.

#### **TEST PROCEDURE**

- 1. Condition the current probe before running these tests.
- Measure the battery resistance change by entering test number 75 or 79 (as described in the hookup procedure). Then engage the starter for about 5 seconds.
- 3. Measure the battery internal resistance by entering test number 73 or 77 (as described in the hookup procedure). Then engage the starter for about 5 seconds
- 4. Compare the results of both measurements to limits in the vehicle/equipment TM or to limits on the reverse side of this card.
- If either measurement is outside of normal limits, check battery terminals and connections, and check battery electrolyte level. Then perform both i measurements a second time.
- If the battery resistance change test (75 or 79) fails after the second measurement, then the battery pack is in bad condition. Test each series pair to determine which is good and which is bad.
- 7. If the battery internal resistance test (73 or 77) fails after the second measurement, then the battery should be recharged.




#### STE/ICE-R BATTERY PACK TEST CARD

BATTERY TEST RESULT	S
	WHAT IT MEANS
STE/ICE-R DISPLAY AFTER-TEST	The battery in series with the battery under test may be bad. Check that battery next.
GO { 2.	There is a bad connection in the starter circuit somewhere. Check the battery negative cables, and cables to the starter for corroded or loose connections. If all of the cables and connec- tions are o.k., then the starter is possibly faulty.
.9.9.9.9	There is a bad connection on the battery being tested. Clean and tighten the posts and clamps, and check the cable between the batteries.
<b>(</b> 2.	The battery under test is in extremely poor condition.
14.2	If any number is displayed, then the number is a STE/ICE test result. Compare the test result to the values shown along the right edge of this card to determine a pass or fail. See table below to determine the condition of the battery.
E013	The battery being tested may be in a discharged state. Check battery electrolyte level; charge battery, and then retest.
2.	If display shows E013 after battery has been charged, then the battery is in poor condition.
	The current probe is not connected. Connect current probe.
E005	Offset test for current probe has not been performed. Perform current probe offset test.
E008	Test leads are improperly connected. Check test leads.

TEST 77 BATTERY INTERNAL RESISTANCE TEST RESULT	TEST 79 BATTERY RESISTANCE CHANGE TEST RESULT	BATTERY CONDITION
PASS	PASS	The battery tested is o.k and in good state of charge
PASS	FAIL	The battery tested is in poo condition, but has a fresh charge
FAIL	PASS	The battery tested is o.k., but needs to be recharged.
FAIL	FAIL	The battery tested is in poor condition and in a state of discharge.

STE/ICE-R BATTERY PACK TEST CARD

## 0107 00



STE/ICE-R BATTERY PACK TEST CARD

## STE/ICE-R CHARGING CIRCUIT TROUBLESHOOTING

## **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools


General Mechanic's Tool Kit (WP 0541 00, Item 57) STE/ICE-R Test Set (WP 0541 00, Item 6)

### Personnel Required

Unit Mechanic


References See your -10 TM 9-4910-571-12&P (WP 0023 00)

Equipment Condition Engine stopped (see your -10) Carrier blocked (see your -10) Power plant rear access door/panel removed (see your -10) STE/ICE-R hooked up for power (WP 0114 00)



## STE/ICE-R CHARGING CIRCUIT TROUBLESHOOTING—Continued

### 0108 00





## STE/ICE-R CHARGING CIRCUIT TROUBLESHOOTING—Continued

### 0108 00

## FIELD CURRENT

- 1. Install current probe around circuit 1 lead of generator to regulator cable.
- 2. Point arrow on current probe toward generator.
- 3. Set test select switches to 01.
- 4. Press and release test button.
- 5. When PASS appears, set test select switches to 90.
- 6. Press and release test button.
- 7. Raise engine speed to 1000 to 1200 rpm and read rpm display.
- 8. Stop engine (see your -10).
- 9. Is current below 6 amps?





## STE/ICE-R STARTER CIRCUIT TROUBLESHOOTING

## **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) STE/ICE-R Test Set (WP 0541 00, Item 6)

## Personnel Required


Unit Mechanic

#### References

See your -10 TM 9-4910-571-12&P TM 9-6140-200-14 (WP 0012 00 or WP 0013 00)

## Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10)) All electrical power off (see your -10) STE/ICE-R hooked up for tests 72 thru 75 (WP 0117 00) STE/ICE-R hooked up for power (WP 0114 00)




### STE/ICE-R STARTER CIRCUIT TROUBLESHOOTING—Continued 0109 00 NO Check if starter circuit resistance is within 5 to 27. GO TO CY (PAGE 0109 00-3) 2. Is starter circuit resistance within 5 to 27? YES 3Y Check batteries to make sure they are fully charged TM 9-6140-200-14. Verify no faults found. BY BYN NO Check to see if E013 Is displayed. Check batteries to make sure they are 1. 1 2. Is E013 displayed? fully charged TM 9-6140-200-14. Verify no faults found. 2 YES 2BY NO Crank engine (see your -10). GO TO DY (PAGE 0109 00-4) 1. 2. Does any message appear other than GO? YES **3BY 3BYN** NO Check how many times E013 has been displayed Repeat this part of troubleshooting. 1. 1. Is this the third time E013 was displayed? 2. Verify no faults found. 2 YES 4BY 4BYN NO Turn off all electrical equipment. Go to offset fault isolation TM 1. 1. 2. Set test select switches to 90. 9-4910-571-12&P. 3. Press and hold test until CAL appears on display. Verify no faults found. Is offset value within limits of -225 to +225? 4. YES

#### STE/ICE-R STARTER CIRCUIT TROUBLESHOOTING—Continued 0109 00 5BY 5BYN NO 1. Press and release test button. 1. Check batteries TM 9-6140-200-14. 2. Crank engine for a few seconds with fuel off. Verify no faults found. 2. 3. Is starter current above 100 amps? YES 6BY Error message E013 displayed earlier indicates short circuit, 1. frozen starter, or tight engine. 2. Check wiring to starter for short circuits. 3. If wiring is ok, engine may be tight. 4. Notify your supervisor. 5. Verify no faults found. **CYN** CY NO Check to see if resistance is high. Repair short circuit in starter circuit. 1. Is resistance high? Verify no faults found. 2. YES 2CY 2CYN NO Attempt to start engine while listening for clicking of starter Check switches, wiring, relays, and 1. circuit breakers to starter solenoid. solenoid. 2. Does starter solenoid click? 2. Verify no faults found. YES 3CY **3CYN** Connect test probe cable W2P1 to J4 on VTM. NO Go to offset fault isolation TM 2. Connect red and black clips together. 9-4910-571-12&P. 3. Set test select switches to 89. Verify no faults found. 4. Press and hold test until CAL appears on display.

4. Press and hold test until CAL appears on display


5. Is offset value within limits of -6.8 to +6.8?

YES




## STE/ICE-R STARTER CIRCUIT TROUBLESHOOTING—Continued

### 0109 00



## STE/ICE-R STARTER CIRCUIT TROUBLESHOOTING—Continued

0109 00



## STE/ICE-R LOW OIL PRESSURE TROUBLESHOOTING

## **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) STE/ICE-R Test Set (WP 0541 00, Item 6)

## Personnel Required


Unit Mechanic

### References


See your -10 TM 9-4910-571-12&P (WP 0046 00)

## Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10) STE/ICE-R hooked up for power (WP 0114 00) STE/ICE-R engine RPM test hooked up (WP 0115 00)



## STE/ICE-R LOW OIL PRESSURE TROUBLESHOOTING—Continued



## STE/ICE-R BATTERY TROUBLESHOOTING

### **INITIAL SETUP:**

### Maintenance Level

Unit

#### Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) STE/ICE-R Test Set (WP 0541 00, Item 6)

## Personnel Required

Unit Mechanic

## References


See your -10 TM 9-4910-571-12&P (WP 0052 00)

## Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Fuel off, engine must not start (see your -10) All electrical power off (see your -10) Driver's seat raised (see your -10) STE/ICE-R starter circuit test hooked up (WP 0116 00) STE/ICE-R power hooked up (WP 0114 00)


Т	TN
<ol> <li>Make sure all electrical accessories are off.</li> <li>Set test select switches to 75.</li> <li>Press and hold test button until CAL appears on display.</li> <li>Release test button, wait for offset value to appear on display.</li> <li>Is offset value within -225 to +225?</li> </ol>	<ol> <li>Go to offset fault isolation TM 9-4910-571-12&amp;P.</li> <li>Verify no faults found.</li> </ol>
YES Y	YN
While cranking engine with bad or discharged batteries, it is possible for VTM to lose power and come on again after cranking has stopped. If this occurs, clean battery posts and clamps. If they are loose or corroded, correct them and repeat test.	<ol> <li>If display shows GO, there is a bad connection in the starter circuit. Check cables and connections to starter and repeat test.</li> <li>If GO is still displayed, then you may have a very poor battery in the series pair being tested.</li> </ol>
<ol> <li>Press and release test button.</li> <li>When GO appears, engage starter switch for two seconds or until OFF is displayed.</li> <li>Is test value displayed?</li> </ol>	3. If display shows .9.9.9.9., there may be a bad connection on the batteries being tested. Clean and tighten the connections on the batteries and repeat test.
YES	<ol> <li>If display shows or .9.9.9.9., the batteries being tested may be in a discharged state. Check batteries' electrolyte level; charge batteries and repeat test.</li> <li>If display shows E013 three times, or , or .9.9.9.9. after batteries have been charged, replace batteries.</li> <li>Verify no faults found.</li> </ol>

## STE/ICE-R BATTERY TROUBLESHOOTING—Continued



#### STE/ICE-R BATTERY TROUBLESHOOTING—Continued

0111 00




## STE/ICE-R BATTERY TROUBLESHOOTING—Continued


#### 0111 00

## **6**Y

- 1. Check electrolyte levels in batteries TM 9-6140-200-14.
- 2. Clean battery terminals TM 9-6140-200-14.
- 3. Check specific gravity in batteries TM 9-6140-200-14.
- 4. Charge batteries if necessary TM 9-6140-200-14.
- 5. Verify no faults found.



## STE/ICE-R BATTERY TROUBLESHOOTING—Continued




## STE/ICE-R ENGINE WILL NOT CRANK TROUBLESHOOTING

## 0112 00

#### **INITIAL SETUP:**

References	
See your -10 (WP 0010 00)	
Equipment Condition	
Engine stopped (see your -10)	
Carrier blocked (see your -10) Center seat raised (see your -10)	
、 <b>、</b>	
-	See your -10 (WP 0010 00) Equipment Condition Engine stopped (see your -10) Carrier blocked (see your -10)



## STE/ICE-R ENGINE WILL CRANK BUT WILL NOT START TROUBLESHOOTING

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) STE/ICE-R Test Set (WP 0541 00, Item 6)


Personnel Required

Unit Mechanic


#### References

See your -10 TM 9-94910-571-12&P (WP 0015 00) **Equipment Condition** 

Engine stopped (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10) STE/ICE-R power hooked up (WP 0114 00) STE/ICE-R engine RPM test hooked up (WP 0119 00)



## STE/ICE-R ENGINE WILL CRANK BUT WILL NOT START TROUBLESHOOTING—Continued



## STE/ICE-R ENGINE WILL CRANK BUT WILL NOT START TROUBLESHOOTING—Continued


#### <u>3</u>Y

- 1. Remove red stripe pressure transducer from secondary fuel filter.
- 2. Check operation of engine shutoff cable (WP 0193 00).
- 3. Check restriction in air intake (WP 0193 00).
- 4. Check cold weather operation (see your -10).
- 5. If engine still does not start, notify your supervisor.
- 6. Verify no faults found.

## CAUTION

## Pull fuel shutoff all the way out. Transducer will be damaged if engine starts.

- 1. Remove red stripe pressure transducer from secondary fuel filter.
- 2. Connect fuel supply hose to secondary fuel filter.
- 3. Remove inlet plug (1) from secondary fuel filter (2) and install red stripe pressure transducer (3) in inlet hole (4) of filter.
- 4. Pull fuel shutoff all the way out.
- 5. Crank engine and read display.
- 6. Is fuel pressure greater than 4 psi (28 kPa)?



YES

BYN

NO

- Remove red stripe pressure transducer from secondary fuel filter.
- 2. Check engine fuel pump (WP 0149 00 or WP 0150 00).
- 3. Check generator field switch (WP 0288 00).
- 4. In freezing temperatures, check fuel lines for ice blockage or coagulation of fuel.
- 5. Start engine (see your -10).
- 6. If engine still does not start, repair blockage in fuel line.
- 7. Verify no faults found.

## STE/ICE-R ENGINE WILL CRANK BUT WILL NOT START TROUBLESHOOTING—Continued

## 2BY

- 1. Remove red striped pressure transducer and install plug in secondary fuel filter.
- 2. Replace fuel filter element (WP 0178 00 or WP 0179 00).
- 3. Start engine (see your -10).
- 4. If engine still does not start, check fuel system (WP 0162 00 thru WP 0175 00).
- 5. Verify no faults found.

References

See your -10

Equipment Condition

TM 9-4910-571-12&P

Engine stopped (see your -10)

Carrier blocked (see your -10)

Driver's seat raised (see your -10)

## HOOK UP/REMOVE STE/ICE-R FOR POWER

## THIS WORK PACKAGE COVERS:

Hookup (page 0114 00-1) Removal (page 0114 00-3)

#### **INITIAL SETUP:**

Maintenance Level Unit


Tools and Special Tools STE/ICE-R Test Set WP 0541 00, Item NSN-4910-01-222-6589

Personnel Required

Unit Mechanic

#### **HOOK-UP**


- 1. Remove VTM and power cable W5 from transit case.
- 2. Pull VTM circuit breaker to OFF.
- 3. Install plug W5P1 (1) on VTM jack J1 (2).



4. Connect red clip of power cable W5 to positive terminal of battery.

#### HOOK UP/REMOVE STE/ICE-R FOR POWER—Continued

5.





- 6. Push VTM circuit breaker to ON.
  - a. If display reads (8888) and (---), go to Step 8.
  - b. If display is not blank, but does not read (**8888**) and (---), write up DA form 2404 on faulty VTM display. Report problem to supervisor.
  - c. If display is blank, go to VTM blank display diagnostic troubleshooting see TM 9-4910-571-12&P.

#### HOOK UP/REMOVE STE/ICE-R FOR POWER—Continued

## NOTE

If VTM fails to display current readouts, refer to confidence test fault isolation (see TM 9-4910-571-12&P ).

## NOTE

Intermediate test results are displayed indicating test in progress. The end result will alternately show software revision number and the PASS message. The displayed software revision number has a month (one digit), year (two digits), and the version number (zero). The software revision flashing on the display should match the software revision number on the label located on the side of the VTM. If they are different, return the STE/ICE-R set to your supervisor.

- 7. Perform VTM confidence check:
  - a. Set test select switches to 66.
  - b. Press and release test button.
  - c. Wait for display to show 0066.
  - d. Set test switches to 99.
  - e. Press and release test button.
  - f. Wait for the alternate display of the revision number and PASS message. Go to Step 9
  - g. If PASS is not displayed, go to STE/ICE-R confidence test fault isolation (see TM 9-4910-571-12&P).
- 8. Select test 60, then press and release TEST button.
- 9. Enter carrier VID (03) into VTM, then press and release TEST button.
- Select test 61, then press and release TEST button. If carrier VID (03) does not appear on VTM display, (see TM 9-4910-571-12&P).
- 11. Return to troubleshooting that referred you to this task.

#### REMOVAL

- 1. Pull VTM circuit breaker to OFF.
- 2. Remove power cable W5 from batteries and VTM. Use electrical connector pliers.
- 3. Stow VTM and power cable W5 in transit case.

## HOOK UP/REMOVE STE/ICE-R FOR ENGINE RPM

## THIS WORK PACKAGE COVERS:

Hook-up (page 0115 00-1). Removal (page 0115 00-2).

## **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57) STE/ICE-R Test Set (WP 0541 00, Item 6)

Personnel Required

Unit Mechanic

# **HOOK-UP**

- Remove transducer cable W4 and pulse tachometer from transit case. 1.
- 2. Pull VTM circuit breaker to OFF.
- Connect cable W4P1 (1) to jack J2 TK (2) on VTM. 3.
- Disconnect tachometer cable (3) from tachometer drive adapter (4) on engine (WP 0520 00 or WP 0521 00). 4.

TM 9-2350-247-20-1

References

See your -10

**Equipment Condition** 

(see your -10)

TM 9-4910-571-12&P


Engine stopped (see your -10)

Carrier blocked (see your -10)

Driver's seat raised (see your -10)

STE/ICE-R power hooked up (WP 0114 00) Power plant rear access door/panel removed

5. Install pulse tachometer (5) on tachometer drive adapter (4).



## 0115 00


#### HOOK UP/REMOVE STE/ICE-R FOR ENGINE RPM—Continued

#### 0115 00

## CAUTION

To prevent cable damage, make sure cable is clear of belts and fan blade.

- 6. Connect cable W4P2 (6) to pulse tachometer (5).
- 7. Push VTM circuit breaker to ON.
- 8. Return to troubleshooting task that referred you to this task.



#### REMOVAL

- 1. Pull VTM circuit breaker to OFF.
- 2. Disconnect cable W4P2 from pulse tachometer.
- 3. Remove pulse tachometer from tachometer drive adapter.
- 4. Install tachometer cable on drive adapter (WP 0520 00 or WP 0521 00).
- 5. Remove cable W4P1 from jack J2 TK on VTM.
- 6. Stow transducer cable and pulse tachometer in transit case.

## HOOK UP/REMOVE STE/ICE-R FOR STARTER CIRCUIT TESTS

## THIS WORK PACKAGE COVERS:

Hook-up (page 0116 00-1). Removal (page 0116 00-2).

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools STE/ICE-R Test Set (WP 0541 00, Item 6)

Personnel Required

Unit Mechanic

References

See your -10 TM 9-4910-571-12&P

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10) STE/ICE-R power hooked up (WP 0114 00)


#### HOOK UP

1. Remove transducer cable W4 from transit case.

2. Pull VTM circuit breaker to OFF.

3. Install cable W4P1 (1) on VTM jack J3 TK (2).

4. Attach cable W4P2 (3) to current probe (4).




#### HOOK UP/REMOVE STE/ICE-R FOR STARTER CIRCUIT TESTS—Continued

## NOTE

If current probe is below room temperature, wait at least 5 minutes after connecting probe to VTM before doing offset test, or perform offset within 30 seconds of starting each measurement.

5. Clamp current probe (4) around positive (+) battery cable (5) going to the starter (6). Point arrow on probe along cable to starter. Make sure probe is closed.



- 6. Push VTM circuit breaker to ON.
  - a. If display reads (8888) and (---), go to Step 7.
  - b. If display is not blank, but does not read (**8888**) and (---), write up DA form 2404 on faulty VTM display. Report problem to supervisor.
  - c. If display is blank, go to VTM blank display diagnostic troubleshooting (See TM 9-4910-571-12&P).
- 7. Return to troubleshooting task that referred you to this task.

#### REMOVAL

- 1. Pull VTM circuit breaker to OFF.
- 2. Remove transducer cable W4 from battery cable and VTM.
- 3. Disconnect cable W4P2 from current probe.
- 4. Stow transducer cable W4 and current probe in transit case.

## HOOK UP/REMOVE STE/ICE-R TEST SET FOR TEST NUMBERS 72 THRU 75

#### THIS WORK PACKAGE COVERS:

Hook-up (page 0117 00-1). Removal (page 0117 00-3).

## **INITIAL SETUP:**


Maintenance Level	Equipment Condition
Unit	Engine stopped (see your -10)
Tools and Special Tools	Carrier blocked (see your -10)
STE/ICE-R Test Set (WP 0541 00, Item 6)	Center seat raised (see your -10)
Personnel Required	All electrical accessories turned off (see your -10)
Unit Mechanic	Engine at operating temperature (see your -10)
References	Fuel off, engine must not start (see your -10)
See your -10	STE/ICE-R power hooked up (WP 0114 00)

#### HOOK-UP

## NOTE

#### Do not have battery charger connected when performing test numbers 72 thru 75.


- 1. Remove transducer cable W4 and current probe from transit case.
- 2. Pull VTM circuit breaker to OFF.
- 3. Install cable W4P1 (1) on VTM jack J3 TK (2).
- 4. Attach cable W4P2 (3) to current probe (4).




5. Push VTM circuit breaker to ON.

#### HOOK UP/REMOVE STE/ICE-R TEST SET FOR TEST NUMBERS 72 THRU 75—Continued

6. For test numbers 72 or 74, current probe (4) is connected to positive cable (5) between battery (6) and starter (7). Point arrow on current probe along cable to starter. Make sure current probe is closed.



7. For test numbers 73 or 75, clamp current probe (1) around cable (2) connecting series pair of batteries (3). Point arrow on current probe along cable toward negative terminal (4). Make sure current probe is closed.



## NOTE

#### Engine must not start while cranking engine. If engine starts, repeat Step 8.

8. Continue current probe by engaging starter only long enough to briefly turn engine (approximately 1 second).

0117 00

#### HOOK UP/REMOVE STE/ICE-R TEST SET FOR TEST NUMBERS 72 THRU 75—Continued

9. Return to troubleshooting task that referred you to this task.

#### REMOVE

- 1. Pull VTM circuit breaker to OFF.
- 2. Remove cable W4P1 from VTM jack J3 TK.
- 3. Remove cable W4P2 from current probe.
- 4. Stow transducer cable W4 and current probe in transit case.

## STE/ICE-R TEST 01 DISPLAY ENGINE RPM WITH NEXT MEASUREMENT

0118 00

#### THIS WORK PACKAGE COVERS:

Test (page 0118 00-1)

#### **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools

STE/ICE-R Test Set (WP 0541 00, Item 6)

## Personnel Required

Unit Mechanic

References See your -10

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10) STE/ICE-R power hooked up (WP 0114 00) STE/ICE-R engine RPM test hooked up (WP 0115 00)

1. Select TEST 01.

2. Press and release TEST button.

3. VTM will display CON.

## NOTE

Hook up and offset steps should already have been completed. Do not repeat.

Go to desired measurement procedure. Follow that procedure. VTM will alternately display the engine speed and the desired measurement. The first number displayed will be RPM.

4. Return to troubleshooting task that referred you to this task.

## STE/ICE-R TEST 10 ENGINE RPM

#### THIS WORK PACKAGE COVERS:

Test (page 0119 00-1)

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

STE/ICE-R Test Set (WP 0541 00, Item 6)

Personnel Required

Unit Mechanic

References

See your -10 TM 9-4910-571-12&P

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) STE/ICE-R power hooked up (WP 0114 00) STE/ICE-R starter circuit test hooked up (WP 0116 00) STE/ICE-R engine RPM test hooked up (WP 0115 00)

1. Select TEST 10.

2. Press and release TEST button.

## NOTE

At speeds below 50 RPM, the VTM will display 0. At speeds above 5000 RPM, the display may give a false reading.

3. VTM will display engine RPM:

#### Table 1.

CONDITIONS	ENGINE RPM
CRANKING	100 minimum
IDLE	650 - 700
GOVERNED SPEED (NO LOAD)	2975 - 3000

- a. If error message appears, see (WP 0107 00).
- b. If display is erratic or reads **0** with engine turning, see TM 9-4910-571-12&P.
- 4. Read cranking RPM while starting engine.
- 5. Check engine idle speed.
  - a. Watch VTM for 10 seconds.
  - b. If engine idle speed does not remain between 650 and 700 RPM, notify your supervisor.
- 6. Return to troubleshooting task that referred you to this task.

## STE/ICE-R TEST 13 POWER (PERCENT)

#### THIS WORK PACKAGE COVERS:

Test (page 0120 00-1)

### **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools STE/ICE-R Test Set (WP 0541 00, Item 6) Personnel Required

Unit Mechanic

References See your -10

Equipment Condition Engine stopped (see your -10) Carrier blocked (see your -10) STE/ICE-R power hooked up (WP 0114 00) STE/ICE-R engine RPM test hooked up (WP 0115 00) Warm engine to operating temperature (see your -10)

## NOTE

If VID has been performed during power hook up procedure (WP 0114 00), go to Step 2 page 0120 00-0. If not, then continue to do Step 1 page 0120 00-0.

- 1. Enter VID.
  - a. Set TEST SELECT switches to 60.
  - b. Press and release TEST button.
  - c. Wait for prompting message **UEH** to appear on display.
  - d. Set TEST SELECT switches to 03.
  - e. Press and release TEST button.
  - f. Wait for VTM to display and hold VID number.

## NOTE

Engine idle speed must be checked before performing power test. If idle speed is not within limits specified for vehicle/equipment, adjust idle speed to be within proper limits. Do not run power test if idle speed cannot be properly adjusted.

- 2. Start and idle engine.
  - a. Set TEST SELECT switches to 10.
  - b. Press and release TEST button.
  - c. Observe displayed value (rpm) and adjust idle speed if necessary.
  - d. Observe displayed value (rpm).

## CAUTION

Engine governor speed must be checked before performing power test. If governor speed is not within limits specified for vehicle/equipment, notify your supervisor.

Do not run power test if governor speed is not within specified limits. Damage to engine may result.

To prevent damage to equipment, allow engine to idle for at least two minutes after running power test.

3. Perform power test.

## STE/ICE-R TEST 13 POWER (PERCENT)—Continued

- a. Set TEST SELECT switches to 13.
- b. Press and release TEST button.
- c. When **CIP** is displayed, sharply depress accelerator. Hold it to the floor. When VTM displays**OFF**, release accelerator.
- d. A number will be displayed after engine has returned to idle speed. This number is the test result in units of percent of nominal rated power.
- 4. Return to troubleshooting task that referred you to this task.

% Power: Minimum Test Limit			
Vehicle	Altitude		
M113/M548 FOV	0 to 2000 feet	2000 feet to 4000 feet	Above 4000 feet
	75%	66%	60%
Test result appears in units of percent of nominal power			

## Table 1.

## STE/ICE-R TEST 14 COMPRESSION UNBALANCE (POWER CABLE)

#### 0121 00

#### THIS WORK PACKAGE COVERS:

Test (page 0121 00-1)

#### **INITIAL SETUP:**

Maintenance Level Unit Tools and Special Tools STE/ICE-R Test Set (WP 0541 00, Item 6) Personnel Required

Unit Mechanic

References

See your -10

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) STE/ICE-R power hooked up (WP 0114 00) Warm engine to operating temperature (see your -10) Disengage transfer gearcase (see your -10) Run test 72 (WP 0123 00) Run test 73 (WP 0124 00) Run test 74 (WP 0125 00) Run test 75 (WP 0124 00)

## NOTE

## If VID has been performed during power hook up procedure (WP 0114 00), go to Step 2 page 0121 00-0. If not, then continue to do Step 1 page 0121 00-0.

- 1. Enter VID.
  - a. Set TEST SELECT switches to 60.
  - b. Press and release TEST button.
  - c. Wait for prompting message UEH to appear on display.
  - d. Set TEST SELECT switches to 03 for vehicle being tested.
  - e. Press and release TEST button.
  - f. Wait for VTM to display and hold VID number.

## NOTE

Do not run more than two compression unbalance tests in a row. Idle engine between pairs of compression unbalance tests.

Crank engine without fuel for 5 seconds to clear fuel from cylinders.

#### NOTE

If E013 appears, test data cannot be analyzed because of weak batteries or interrupted cranking during test. Correct problem and repeat Step 2 page 0121 00-0.

- 2. Perform test.
  - a. Set TEST SELECT switches to 14.
  - b. Press and release TEST button.
  - c. When GO appears, crank engine. Display will change to (---) while engine is turning.
  - d. When OFF or E013 appears, stop cranking. Wait for message to appear.

#### 0121 00-1

#### STE/ICE-R TEST 14 COMPRESSION UNBALANCE (POWER CABLE)—Continued

- 1) If a number is displayed, refer to the vehicle test card for its meaning (WP 0107 00).
- 2) If GO appears, go back to Step 2.c page 0121 00-0.
- 3) A FAIL message usually means compression is too far unbalanced to measure with STE/ICE-R. Occasionally, a FAIL message may be caused by carrier/equipment accessories that are activated during cranking or by imperfections in the starting system.

## STE/ICE-R TEST 67 BATTERY VOLTAGE

#### THIS WORK PACKAGE COVERS:

Test page 0122 00-1

#### **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools

STE/ICE-R Test Set (WP 0541 00, Item 6)

#### Personnel Required

Unit Mechanic

References See your -10 TM 9-4910-571-12&P

Equipment Condition Engine stopped (see your -10) Carrier blocked (see your -10) STE/ICE-R power hooked up (WP 0114 00) STE/ICE-R starter circuit test hooked up (WP 0116 00) STE/ICE-R engine rpm test hooked up (WP 0115 00)

1. Select TEST 67.

2. Press and release TEST button.

Table 1.

CONDITION	VOLTS
ENGINE OFF MASTER SWITCH OFF	22 or more
CRANKING ENGINE FUEL OFF	18 or more
CHARGING 1200 RPM SERVICE LIGHTS ON	26 to 29

- a. If display is erratic or shows **0** volts, see TM 9-4910-571-12&P.
- b. If error message appears, see (WP 0107 00).
- c. If .9.9.9.9 is displayed, voltage is not within test range. Use test 89, see TM 9-4910-571-12&P.

3. Return to troubleshooting task that referred you to this task.

0122 00

## STE/ICE-R TEST 72 STARTER CURRENT (FIRST PEAK)

#### THIS WORK PACKAGE COVERS:

Test (page 0123 00-1)

#### INITIAL SETUP:

Maintenance Level

Unit

Tools and Special Tools

STE/ICE-R Test Set (WP 0541 00, Item 6)

#### Personnel Required

Unit Mechanic

References

See your -10 TM 9-4910-571-12&P

- 1. Select TEST 72.
- 2. Perform offset test.
  - a. Press and hold TEST button until CAL appears. Release TEST button.
  - b. If VTM reads between -225 and +225, offset test passes.
  - c. If offset test fails, see TM 9-4910-571-12&P.
- 3. Press and release TEST button.
- 4. When GO appears, turn MASTER SWITCH ON and crank engine for 2 seconds or until one of the following appears on VTM:

#### Table 1.

DISPLAY	PERFORM/RESULT
a. OFF	Stop cranking and wait for message to appear.
b. A number	CIRCUIT RESISTANCE (in amps)
c9.9.9.9	Beyand range of VTM, cannot be measured.
d. Error message	See (WP 0107 00)

- 5. Turn MASTER SWITCH OFF.
- 6. Observe VTM reading.
  - a. If VTM reading is between 700 and 1275, test passes.
  - b. If reading is erratic or cannot be obtained, see TM 9-4910-571-12&P.
- 7. Return to troubleshooting task that referred you to this task.

#### 0123 00-1/2 blank

### 0123 00

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) All electrical accessories turned off (see your -10) Fuel OFF, engine must not start (see your -10) STE/ICE-R power hooked up (WP 0114 00) STE/ICE-R starter circuit test hooked up (WP 0116 00)

## STE/ICE-R TEST 73 BATTERY RESISTANCE — STE/ICE-R TEST 75 BATTERY RESISTANCE CHANGE (PACK)

#### THIS WORK PACKAGE COVERS:

Test (page 0124 00-1)

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

STE/ICE-R Test Set (WP 0541 00, Item 6)

#### Personnel Required

Unit Mechanic

References

See your -10 TM 9-4910-571-12&P Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Battery cover removed (see your -10) STE/ICE-R power hooked up (WP 0114 00) STE/ICE-R starter circuit test hooked up (WP 0116 00)

## WARNING



Battery posts and cables touched by metal objects can short circuit and burn you. Do not wear jewelry, necklaces, or watches when working on the electrical system. Keep tools away from posts, wires, and terminals.

- 1. Reposition current probe.
  - a. Pull VTM switch to OFF.
  - b. Remove current probe from positive battery cable.
  - c. Connect current probe to cable connecting series pair of batteries together.
  - d. Push VTM switch to ON.
  - e. Select TEST 73.

## NOTE

Both TEST 73 and TEST 75 must be performed to determine condition of series pair of batteries.

- 2. Perform offset test.
  - a. Press and hold TEST button until CAL appears. Release TEST button.
  - b. If VTM reads between -225 and +225, offset test passes.
  - c. If offset test fails, see TM 9-4910-571-12&P.

#### 0124 00

# STE/ICE-R TEST 73 BATTERY RESISTANCE — STE/ICE-R TEST 75 BATTERY RESISTANCE CHANGE (PACK)—Continued

3. Press and release TEST button.

4. When GO appears, crank engine for two seconds or until one of the following appears on display:

#### Table 1. DISPLAY PERFORM/RESULT a. OFF Stop cranking and wait for message to appear. b. A number CIRCUIT RESISTANCE (milliohms test 73; milliohms/ seconds test 75) c. .9.9.9.9 Beyond range of VTM, cannot be measured. d. Error message See (WP 0107 00) VTM lost power during test. e. (---) Batteries may be too weak. Try powering VTM using external source.

#### 5. Observe VTM reading.

- a. If test 73 VTM reading is **25** or less, test passes.
- b. If test 73 VTM reading is over **25**, test fails.
- c. If test 75 VTM reading is **50** or less, test passes.
- d. If test 75 VTM reading is over **50**, test fails.

Table 2.	
----------	--

TEST 73	TEST 75	
BATTERY INTERNAL RESISTANCE	BATTERY RESISTANCE CHANGE	BATTERY PACK CONDITION
TEST RESULT	TEST RESULT	
PASS	PASS	The batteries tested are ok and in good state of charge.
PASS	FAIL	The batteries tested are in poor condition, but have a fresh charge.
FAIL	PASS	The batteries tested are ok, but need to be recharged.
FAIL	FAIL	The batteries tested are in poor condition and in a state of discharge.

6. Select test 75.

## STE/ICE-R TEST 73 BATTERY RESISTANCE — STE/ICE-R TEST 75 BATTERY RESISTANCE CHANGE (PACK)—Continued

- 7. Repeat Steps 2 page 0124 00-0 5 page 0124 00-0.
- 8. Determine condition of series pair of batteries using table.
  - a. If batteries are in poor condition, go to individual battery tests 77 and 79 (see TM 9-4910-571-12&P).
- 9. Return to troubleshooting task that referred you to this one.

## STE/ICE-R TEST 74 STARTER CIRCUIT RESISTANCE

## THIS WORK PACKAGE COVERS:

Test (page 0125 00-1)

#### INITIAL SETUP:

Maintenance Level

Unit

Tools and Special Tools

STE/ICE-R Test Set (WP 0541 00, Item 6)

#### Personnel Required

Unit Mechanic

References

See your -10 TM 9-4910-571-12&P

- 1. Select TEST 74.
- 2. Perform offset test.
  - a. Press and hold TEST button until CAL appears. Release TEST button.
  - b. If VTM reads between -225 and +225, offset test passes.
  - c. If offset test fails, see TM 9-4910-571-12&P.
- 3. Press and release TEST button.
- 4. When GO appears, turn MASTER SWITCH ON and crank engine for 5 seconds or until one of the following appears on VTM:

## Table 1.

DISPLAY	PERFORM/RESULT
a. OFF	Stop cranking and wait for message to appear.
b. A number	CIRCUIT RESISTANCE (in milliohms)
c9.9.9.9	Beyond range of VTM, cannot be measured.
d. Error message	See (WP 0107 00)

- 5. Turn MASTER SWITCH OFF.
- 6. Observe VTM reading.
  - a. If VTM reading is between 5 and 27, test passes.
  - b. If reading is erratic or cannot be obtained, see TM 9-4910-571-12&P.
- 7. Return to troubleshooting task that referred you to this one.

#### 0125 00-1/2 blank

## 0125 00

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) All electrical accessories turned off (see your -10) Fuel OFF, engine must not start (see your -10) STE/ICE-R power hooked up (WP 0114 00) STE/ICE-R starter circuit test hooked up (WP 0116 00)

## STE/ICE-R TEST 90 DC CURRENT 0 TO 1500 AMP

#### THIS WORK PACKAGE COVERS:

Test (page 0126 00-1)

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

STE/ICE-R Test Set (WP 0541 00, Item 6)

#### Personnel Required

Unit Mechanic

References

See your -10 TM 9-4910-571-12&P Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) STE/ICE-R power hooked up (WP 0114 00) STE/ICE-R starter circuit test hooked up (WP 0116 00)

## NOTE

If current probe is below room temperature, wait at least 5 minutes after connecting probe to VTM before doing offset test, or perform offset within 30 seconds of starting each measurement.

- 1. Perform offset test.
  - a. Set TEST select switches to 90.
  - b. Push and hold TEST button until CAL appears. Release TEST button.
  - c. If VTM reads between -225 and +225, offset test passes.
  - d. If offset test fails, see TM 9-4910-571-12&P.
- 2. Press and release TEST button
- 3. Turn on circuit used to condition current probe. If starter is used to condition probe, energize starter long enough to obtain a reading. Do not allow engine to start.
- 4. Note polarity sign of conditioning current. If readout is negative (–), reverse current probe, and repeat Steps 1 page 0126 00-0 4 page 0126 00-0.
- 5. Turn off circuit used to condition current probe.
- 6. Perform offset test.

## NOTE

Stray magnetic fields can affect the current reading. Such fields may exist within a foot or so of operating carrier generators and alternators, motor generators under load, and electric motors. Keep current probe at least one foot away from any operating generators, alternators, or electric motors.

- 7. During offset test, the component being tested must be off, and the circuit must be de-energized.
  - a. Turn off component to be tested.
  - b. Install current probe where current is to be measured.

#### 0126 00-1

## 0126 00

## STE/ICE-R TEST 90 DC CURRENT 0 TO 1500 AMP—Continued

- c. Push and hold TEST button until CAL appears. Release TEST button.
- d. If VTM reads between -225 and +225, offset test passes.
- e. If offset test fails, see TM 9-4910-571-12&P.
- 8. Press and release TEST button.
- 9. Turn on component to be tested.

## NOTE

If .9.9.9.9 appears on display, the test current is greater than 1500 amp and cannot be measured with STE/ICE-R.

If display reads a value with a minus sign, current probe has been installed backwards. Repeat Steps 1 page 0126 00-0 - 5 page 0126 00-0. Be careful not to reinstall current probe backwards.

- 10. Observe VTM reading.
  - a. If VTM reads between 250 and 425 amp, test passes.
  - b. If reading is erratic or cannot be obtained, see TM 9-4910-571-12&P.
- 11. Turn off component in Step 9 page 0126 00-0.
- 12. Return to troubleshooting task that referred you to this one.

## TM 9-2350-247-20-1

## CHAPTER 3

## UNIT MAINTENANCE INSTRUCTIONS FOR PMCS INCLUDING LUBRICATION INSTRUCTIONS

WORK PACKAGE INDEX	
Title	Sequence No.
SERVICE UPON RECEIPT OF MATERIEL	
PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS), INCLUDING LUBRICATION INSTRUCTIONS	
MULTIPLE PIN AND SOCKET IDENTIFICATION	

## SERVICE UPON RECEIPT OF MATERIEL

#### THIS WORK PACKAGE COVERS:

This section tells you how to service your carrier when it is first received from a depot. It also gives information on administrative storage.

#### **INITIAL SETUP:**

Maintenance Level

Unit

### **GENERAL INSTRUCTIONS**

If you find anything wrong during this preliminary check and service, or during break-in period, report them to your supervisor. These deficiencies must be corrected before carrier can be placed in service.

You are required to report any serious problems which appear to involve unsatisfactory design or material. Prepare the Equipment Improvement Recommendations (EIR) using SF-369, Quality Deficiencies Report, as stated in DA PAM 738-750.

#### PRELIMINARY CHECKS AND ADJUSTMENTS

#### **DEPROCESSING CARRIER**

1. All new or reconditioned carriers, when first received by using soldiers, must be deprocessed. Unit Mechanics must decide if carrier has been properly prepared for service. The carrier must be in condition to perform its assigned mission.

The carrier crew will assist in the performance of these checks and services.

Remove rust preventive coatings from all exterior services. Use cleaning compound (WP 0542 00, Item 9).

Read DD Form 1397 (Processing and Deprocessing record for Shipment, Storage, and Issue of Vehicles and Spare Engines). Follow precautions checked on the form. Form should be in a waterproof cover attached to one of the headlights. A duplicate copy should be in the driver's compartment.

Read and follow instructions on all warning tags attached to engine, radiator filler neck, and driver's compartment.

Follow procedures given in the Preventive Maintenance Checks and Services (WP 0128 00).


#### M548A1 AND M548A3 DEPROCESSING PROCEDURES

## NOTE

The shipping closure and attaching hardware are reusable items. Do not damage. Keep attaching hardware with closure. Refer to your supervisor for disposition of these items. One access panel is installed on each side of cab.

1. Remove shipping closure (1).

- a. Remove six lag bolts (2), washers (3), and two side access panels (4) from two cab doors (5). Open cab doors.
- b. Remove two nuts (6), four washers (7), two washers (8), screws (9), and front of shipping closure (1) from two windshield mounting holes (10).
- c. Remove two nuts (11), washers (12), washers (13), and rear of shipping closure (1) from two studs (14). Lift shipping closure from carrier.
- d. Before storage of shipping closure (1), install two side access panels on shipping closure with six washers (3) and lag bolts (2).



2. Remove equipment packages from driver's cab. Packages contain windshield wiper blades and arms with attaching nuts, exhaust pipe, and two hooks and pintle.

- 4. Remove tape seals from exhaust outlet and engine air intake, oil filler cap, and oil dipstick.
- 5. Install air cleaner hose on engine air intake (WP 0153 00) or (WP 0159 00).
- 6. Check tension on drive belts for generator (WP 0241 00) or (WP 0245 00), fan and coolant pump (WP 0252 00).
- Unpack batteries. Add electrolyte to batteries TM 9-6140-200-14 to 3/8 inch (9 mm) above bottom plates (about 2 gallons (8 liters) each). Install two batteries for M548A1 (WP 0290 00) and four batteries for M548A3 (WP 0293 00) in carrier battery compartment.
- 8. Unpack windshield and side door windows. Install windshield on carrier (WP 0392 00). Install side door windows on driver's cab doors (WP 0387 00).
- 9. Unpack windshield wiper blades and arms with attaching nuts. Install blades and arms on carrier (WP 0422 00).
- 10. Unpack exhaust pipe. Install pipe on exhaust muffler outlet (WP 0209 00) or (WP 0210 00).
- 11. Remove tape and paper wrappings from seat cushions and backrests.
- 12. Remove wire cloth screens from access and drain openings in hull. Install drain plugs, float valves, drain covers, and hull bottom access cover (WP 0383 00).
- 13. Unpack cab cover, left and right side frames, and rear crossbow. Install cover, frames, and crossbow on carrier (WP 0418 00).
- 14. Unpack and inventory basic issue items (BII) (see your -10). Record any missing or damaged items and stow BII on carrier.
- 15. If equipped (M548A1), unpack vehicle compartment heater kit defroster duct. Install defroster duct in carrier (WP 0432 00).
- 16. If equipped (M548A1), unpack machine gun mount kit. Install gun mount on carrier (WP 0513 00), (WP 0514 00), or (WP 0515 00).
- 17. Unpack towing hooks. Install hooks on towing eyes (WP 0376 00).
- 18. Unpack towing pintle. Install pintle on carrier tailgate (WP 0377 00).
- 19. Unpack cargo covers and bows. Install them over cargo compartment (WP 0417 00).
- 20. If equipped (M548A1), unpack material handling kit. Install hoist kit in cargo compartment (WP 0482 00).
- 21. Remove preservative coating from outer moving parts on winch (M548A1). Use cleaning compound (WP 0542 00, Item 9).
- 22. Clean pivot steering brake disks. Use cleaning compound (WP 0542 00, Item 9).
- 23. Perform Before PMCS (see your -10).
- 24. Check operation of all controls (see your -10).
- 25. Perform complete lube (WP 0128 00).
- 26. Start and run engine (see your -10). Check for oil leaks. Disregard smoky exhaust for first few minutes of operating. Some rust preventive fuel will be in the system when engine is started. It will burn along with the regular fuel.



## Do not handle wire rope with bare hands. Broken wires can rip your hands open. Wear leather gloves when handling wire rope.

- 27. Unreel winch cable (M548A1) (see your -10). Remove preservative coating from cable with cleaning compound (WP 0542 00, Item 9). Coat cable with preservative lubricating oil (WP 0542 00, Item 15). Rewind cables on drums.
- 28. Check pivot steering brakes (M548A1).
  - a. Place transmission range selector lever in 1-2 range.
  - b. Release differential brakes.
  - c. Slowly press accelerator pedal until carrier reaches speed of 3 mph (5 km/h).
  - d. Release accelerator pedal and pull back on both left and right steering levers evenly and firmly until carrier comes to a complete stop.



## Do not handle wire rope with bare hands. Broken wires can rip your hands open. Wear leather gloves when handling wire rope.

- 29. Unreel shelter puller winch cable (M548A1) (see your -10). Remove preservative coating from cable with cleaning compound (WP 0542 00, Item 9). Coat cable with preservative lubricating oil (WP 0542 00, Item 15). Rewind cables on drums.
- 30. Check operation of all controls (see your -10).

### M548A1/M548A3 CALIBER .50 MACHINE GUN MOUNT KIT DEPROCESSING PROCEDURES

- 1. General procedures:
  - a. Check material to make sure it is ready for use. Clean, lube as needed, and prepare material for service.
  - b. List missing or damaged parts and any malfunctions.
  - c. Report serious problems on DA Form 2404.
- 2. Specific procedures:
  - a. Unpackage and inventory machine gun mount kit parts against packing list and TM 9-1005-245-14.
  - b. Assemble ring mount. See TM 9-1005-245-14.
  - c. Install supports and ring mount (WP 0514 00).
  - d. Install pintle and cradle (WP 0515 00).

- e. Lube ring mount (WP 0128 00).
- f. Perform Before PMCS (see your -10).

### M548A1/M548A3 M66 RING MOUNT KIT DEPROCESSING PROCEDURES

- 1. General procedures:
  - a. Check material to make sure it is ready for use. Clean, lube as needed, and prepare material for service.
  - b. List missing or damaged parts and any malfunctions.
  - c. Report serious problems on DA Form 2404.
- 2. Specific procedures:
  - a. Unpackage and inventory gun mount kit parts against packing list and TM 9-1005-245-14.
  - b. Assemble ring mount. See TM 9-1005-245-14.
  - c. Install supports and ring mount (WP 0514 00).
  - d. Install deflector support and cartridge deflector (WP 0514 00).
  - e. Install machine gun mount. See TM 9-1005-245-14.
  - f. Lube gun mount (WP 0128 00).
  - g. Perform Before PMCS (see your -10).

#### M548A1/M548A3 7.62 MM MACHINE GUN MOUNT KIT DEPROCESSING PROCEDURES

- 1. General procedures:
  - a. Check material to make sure it is ready for use. Clean, lube as needed, and prepare material for service.
  - b. List missing or damaged parts and any malfunctions.
  - c. Report serious problems on DA Form 2404.
- 2. Specific procedures:
  - a. Unpackage and inventory machine gun mount kit parts against packing list and RPSTL.
  - b. Install M66 gun mount kit (WP 0514 00). Omit deflector and tripod brackets.
  - c. Install 7.62 mm gun mount (WP 0515 00).
  - d. Perform Before PMCS (see your -10).
  - e. Perform After PMCS (see your -10).

#### M548A1/M548A3 MATERIAL HANDLING KIT DEPROCESSING PROCEDURES

- 1. General procedures:
  - a. Check material to make sure it is ready for use. Clean and prepare material for service.
  - b. List missing or damaged parts and any malfunctions. Correct deficiencies.
  - c. Report serious deficiencies which appear to involve unsatisfactory design or material on SF-368, Quality Deficiencies Report.
- 2. Specific procedures:
  - a. Unpack and inventory material handling kit parts against packing list and RPSTL.

## M548A1/M548A3 TURN SIGNAL KIT DEPROCESSING PROCEDURES

- 1. General procedures:
  - a. Check material to make sure it is ready for use. Clean and prepare material for service.
  - b. List missing or damaged parts and any malfunctions. Correct deficiencies.
  - c. Report serious deficiencies which appear to involve unsatisfactory design or material on SF-368, Quality Deficiencies Report.
- 2. Specific procedures:
  - a. Check that all parts are properly assembled and installed.
  - b. Test operation of turn signal (WP 0505 00).

### ADMINISTRATIVE STORAGE

1. Instructions for administrative storage of your carrier are contained in MIL-C-62015.

## **END OF TASK**

## THIS WORK PACKAGE COVERS:

Semi-Annual (Table 16, page 0128 00-20).

### **INITIAL SETUP:**

Maintenance Level	References
Unit	FM 9-207 TM 9-214
Tools and Special ToolsAdapter (WP 0541 00)Socket Set (WP 0541 00)Socket Set (WP 0541 00, Item 64)Torque Wrench (WP 0541 00)Torque Wrench (WP 0541 00, Item 70)Torque Wrench (WP 0541 00, Item 71)Torque Wrench (WP 0541 00)Torque Wrench (WP 0541 00)Torque Wrench (WP 0541 00, Item 69)	TB 43-0211 TM 43-0319 TM-3-6680-316-10 TM 9-2350-247-10 TM 3-6665-224-12 TM 9-6100-200-14 TM 9-2350-247-24P TM 9-2450-205-24&P TM 3-4240-276-30 TM 3-4240-276-30P
Materials/Parts Automotive grease (WP 0542 00) Cleaning compound (WP 0542 00, Item 9) General purpose detergent (WP 0542 00, Item 16) Sealing tape (WP 0542 00, Item 25)	Equipment Condition Engine stopped (see your -10)

Personnel Required

Unit Mechanic

### SCOPE

This section details preventive maintenance checks and services (PMCS) and lubrication procedures required for the M548A1 and M548A3 Carriers at the unit maintenance level. For crew level PMCS, see your -10.

### MAINTENANCE FORMS AND RECORDS

The forms and records you fill out have many uses. They are a permanent record of the service, repairs, and changes made to your vehicle. They also tell you whether faults have been repaired. For information on forms and records, see DA Pamphlet 738-750.

### WARNINGS AND CAUTIONS

Always observe the WARNINGS and CAUTIONS appearing in the PMCS tables BEFORE, DURING, and AFTER you operate the equipment. The WARNINGS and CAUTIONS appear before certain procedures. You must observe these WARNINGS and CAUTIONS to prevent serious injury to yourself and others or prevent your equipment from being damaged.

### PMCS PROCEDURES

## CAUTION

Water in engine exhaust system and heater exhaust will cause serious damage. Keep water out of engine exhaust system by either running the engine or taping over the exhaust outlet. Tightly cover heater exhaust wells.

Obey all WARNINGS and CAUTIONS when you do PMCS.

## 0128 00

Name, caution, and instruction plates should be easy to read. If they are dirty or corroded, clean them, and coat them with lacquer. See TM 43-0319 for instructions.

If something doesn't work, troubleshoot it using the troubleshooting procedures (WP 0005 00).

Do the Semi-annual PMCS every 1500 miles (2414 km) of operation or 150 hours, whichever comes first, after the last Semi-annual PMCS. Complete forms DA Form 2404 and DD Form 314.

Always do your PMCS in the same order so it gets to be a habit. With practice, you'll spot anything that is wrong.

Keep your carrier clean. Dirt, grease, oil, and debris only get in the way, and may cover up a serious problem. Clean your vehicle as you work and as needed.

After operation in water, mud, or loose sand, clean and lube carrier as soon as possible. Do not wait for next scheduled PMCS. Use cleaning compound (WP 0542 00, Item 9) on metal surfaces. Use general purpose detergent (WP 0542 00, Item 16) and water when you clean rubber or plastic parts.

You need to know how fluid leaks affect your vehicle. Definitions of the types and classes of leaks are given in General Maintenance Instructions below. You need to know them to determine the condition of your vehicle. Learn them. REMEMBER: WHEN IN DOUBT, NOTIFY YOUR SUPERVISOR!

## NOTE

The carrier may continue to operate with minor water or oil leaks (Class I or II). You must consider how much fluid the item or system being checked or inspected can hold. When in doubt, notify your supervisor. Any Class III leaks or any fuel leaks will make the carrier NOT READY/AVAILABLE.

CLASS I Seepage of fluid (as indicated by wetness or discoloration) not great enough to form drops.

CLASS II Leakage of fluid great enough to form drops, but not enough to cause drops to drip from item being checked/ inspected.

CLASS III Leakage of fluid great enough to form drops that fall from the item being checked/inspected.

## **GENERAL MAINTENANCE INSTRUCTIONS**


## SCOPE

This section contains safety warnings, guidelines, and general maintenance instructions such as cleaning, inspection and repair. They should be followed when doing maintenance procedures. These instructions only apply to procedures authorized at unit maintenance level.


### 1. **PREPARATION FOR MAINTENANCE**

- a. *PERSONNEL SAFETY*. Practice all shop safety procedures and read all warnings in this manual.
- b. *PROPER EQUIPMENT*. Get tools and equipment before starting a maintenance task. See RPSTL, TM 9-2350-247-24P, and the maintenance task for tools, equipment, parts, and materials.
- c. *WHAT TO DISCARD.* Parts to discard, such as lock washers, lock nuts, and gaskets, are listed in the maintenance tasks. If the step does not say to discard a part, the part should be saved. It may be used later or repaired.
- d. HANDLING TECHNIQUES.
  - 1) Avoid damage to parts during removal, cleaning, inspection, repair, and installation procedures. Nicks, scratches, and dents caused by careless handling could result in equipment failure.
  - 2) Dirt can damage parts and cause malfunctions. Make sure all air and fluid openings, lines, and hoses are capped or plugged during maintenance procedures.
- e. IDENTIFICATION.
  - 1) During removal, tag parts to ensure proper installation.
  - 2) During removal, tag leads on electrical parts to ensure proper installation. Tag each lead as it is removed.

f. *TORQUING*. Where needed, torque values are listed in the maintenance task. When torquing, use one of the star pattern sequences below unless otherwise stated in the maintenance task.




10-HOLE PATTERN




#### 17-HOLE PATTERN

- g. USE OF TORQUE WRENCH ADAPTERS AND THE CONVERSION FORMULA.
  - 1) The torque values given in the text of this manual are the actual values that must be applied to the nut or screw for proper maintenance.
  - 2) Some tasks require the use of a torque wrench adapter when the nut or screw cannot be reached with a regular socket on the end of the torque wrench. When an adapter is used on a torque wrench, definite rules must be followed or the nut or screw will be over- or under-torqued. The center line of the adapter should be used in one of two positions:



b) The other position is to have the center line of the adapter in line with the center line of the torque wrench. In this case, the adapter adds to the overall length of the torque wrench and makes the dial or scale reading less than the actual torque applied to the nut or screw. To prevent overtorquing and damage to equipment, you must calculate a corrected dial or scale reading.



3) To determine the corrected scale or dial reading, use the following formula and refer to the example.

## NOTE

The length of the torque wrench is measured from the center of the handle to the center of the drive. The length of the adapter is measured from the center of the drive to the center of the wrench.

Corrected reading	=	Required torque value	÷	Length of torque wrench + length of adapter
				Length of torque wrench
~		LENGTH TORQUE WF		LENGTH OF ADAPTER
	Ó			

In the following example, the torque wrench measured 12 inches (30 cm) and the adapter measured 3 inches (8 cm). From step (4), the required torque is 104 lb-ft (141 N $\cdot$ m).

Replace mission track tension adjuster mount screws (1). Tighten loose screws to 130–140 lb-ft (176–190 N•m) torque. Use adapter (WP 0541 00, Item 2) and torque wrench (WP 0541 00, Item 3).

Use 3 inch adapter.

Use 1/2 inch drive torque wrench.

To determine the corrected reading for this task, use the formula:

Corrected reading	=	Required torque value	torque value ÷ Length of torque wrench + lengt	
			_	Length of torque wrench
Corrected reading	=	130 lb-ft	÷	12 inches $+ 3$ inches
			_	12 inches
Corrected reading	=	130 lb-ft	÷	15 inches
			_	12 inches
Corrected reading	=	130 lb-ft	÷	1.25
Corrected reading	=	104 lb-ft		

Repeat above steps for other value.

## 2. CLEANING

a. *GENERAL*. Cleaning is very important. All parts must be cleaned well and kept clean during maintenance. Dirt or foreign matter can cause malfunctions and equipment failure. General cleaning procedures are detailed in steps b through n. Special cleaning procedures are covered in the task relating to the specific part.

- 1) Inspect and cap all air and fluid openings, lines, and hoses.
- b. *CLEAN EVERY PART*. Clean every part well after removal and before installation. Clean parts such as housings, covers, and dipsticks before removal. Avoid getting dirt and foreign matter in a system.
  - 1) Clean all parts before inspection, after repair, and before installation. Use cleaning compound or approved cleaner. Dry parts with wiping rag (WP 0542 00, Item 45).
- c. *HANDLE WITH CARE.* Use care when handling parts during cleaning and maintenance. Nicks, scratches, dents, or burrs can prevent proper assembly or cause malfunctions after assembly.
  - 1) Keep hands free of grease; grease collects dirt.
  - 2) After cleaning, cover or wrap parts to protect from dirt.
- d. *AVOID ABRASIVES*. Except where specially called for in a task, don't use abrasives, files, wire brushes, or sharp tools. On some surfaces, finish is important to the operation of close-fitting parts.
- *REMOVAL AGENTS.* Remove gum or old grease deposits by soaking parts in cleaning compound (WP 0542 00, Item 9). Scrub with a brush (WP 0542 00, Item 30) Use cleaning cloth (WP 0542 00, Item 8) to remove minor surface defects.

## WARNING



Air under pressure in excess of 30 psi (207 kpa) can injure personnel. Do not direct pressurized air at yourself or others. Always wear goggles.

## CAUTION

Lye or caustic mixtures will damage metal surfaces. Do not use lye or caustic mixtures to clean metal surfaces.

- f. *STEAM CLEANING*. If steam cleaning is used, dry clean parts at once with compressed air. Apply a thin film of clean oil to surfaces that are not painted to prevent rusting. Never use lye or caustic mixtures that will corrode or etch metal surfaces.
- g. *LUBRICATION OF NEW BEARINGS*. See TM 9-214 for cleaning and lubrication procedures. Bearings that have been in service should also be lubricated.

h. CASTINGS.

## WARNING



Air pressure in excess of 30 psi (207 kpa) can injure personnel. Do not direct pressurized air at yourself or others. Always wear goggles.

- 1) Clean inner and outer surfaces of casting with cleaning compound (WP 0542 00, Item 9). Dry casting with compressed air.
- 2) Remove sludge and gum deposits with brush (WP 0542 00, Item 30).
- 3) Blow out all tapped holes with compressed air.
- i. *BEARINGS*. Bearings require special cleaning techniques. See TM 9-214 for cleaning and maintenance procedures for bearings.
- j. BATTERIES. See TM 9-6140-200-14 to service batteries.
- k. OIL PASSAGES.
  - 1) Make sure oil passages are not clogged.
  - 2) Clean oil passages and break up any sludge or gum deposits.





Air pressure in excess of 30 psi (207 kpa) can injure personnel. Do not direct pressurized air at yourself or others. Always wear goggles.

- 2) Flush oil passages with cleaning compound (WP 0542 00, Item 9). Dry parts with compressed air.
- 1. OIL SEALS, ELECTRIC CABLES, AND FLEXIBLE HOSES.

## CAUTION

Cleaning compound causes leather, rubber, and synthetic materials to become brittle. Do not use cleaning compound to clean seals, cables, and flexible hoses.

1. Clean seals, cables, and flexible hoses with general purpose detergent (WP 0542 00, Item 16) and water. Dry with wiping rag (WP 0542 00, Item 45).

## WARNING



Air pressure in excess of 30 psi (207 kpa) can injure personnel. Do not direct pressurized air at yourself or others. Always wear goggles.

- m. INSERTS. Blow out insert holes with compressed air.
- n. *GASKETS*. If a gasket is being removed, scrape old gasket material and sealant off mating surface. Clean mating surface with cleaning compound (WP 0542 00, Item 9). Dry with wiping rag (WP 0542 00, Item 45).

## 3. INSPECTION

All removed parts must be inspected with care. Replace parts if damage or wear exceeds allowable limits.

- a. *GENERAL*. Procedures for inspection will be the same for most parts. General inspection procedures are given in steps b through q below. Special inspection procedures are covered in the task as needed.
- b. CASTINGS.
  - 1) Inspect all castings and forgings for breaks, cracks, and wear or scoring that would impair function.
  - 2) Inspect machined surfaces for nicks, burrs, and raised metal. Mark damaged areas for repair.
  - 3) Use straightedge to check all mounting flanges on housings and supports for bends. Inspect mating flanges for stains which would indicate oil leakage.
  - 4) Inspect all threaded parts for damaged or stripped threads.
- c. *BEARINGS.* Inspect bearings for free and smooth rotation, and broken or missing rollers. Also look for tightness of fit in bearing bores. Inspect bearing races for wear and color changes due to heat. See TM 9-214 for inspection procedures.
- d. STUDS. Inspect all studs for stripped or damaged threads, bent or loose condition, and signs of stretching.
- e. GEARS. Inspect gears for burs, wear, cracked or broken teeth, and pitting at tooth contact areas.
- f. BUSHINGS AND BUSHING-TYPE BEARINGS.
  - 1) Check all bushings and bushing-type bearings for secure fit in casting. Check for color changes which could mean overheating. Inspect for size, scoring, out-of-roundness, burs, sharp edges, and signs of seizing.
  - 2) Check for dirt in oil holes and in bushing-type bearings. Oil holes and grooves must be clean and not damaged.
- g. OIL SEALS.
  - 1) Inspect feather edge of oil seals for tears, fraying, hardening, and cracking.
  - 2) Replace metal-covered oil seals when there are signs of damage or oil leakage.
- h. CORE HOLE PLUGS. Inspect core hole plugs for signs of leakage. Replace damaged core hole plugs.
- i. INSERTS.
  - 1) Inspect inserts for cracks and stripped or damaged threads.
  - 2) Check inserts for loose fit.
- j. GREASE SEALS, PREFORMED PACKINGS, AND GASKETS.

- 1) Inspect seals that are composition—type, rings, and preformed packings for wear, brittleness, cracks, cuts, and damage.
- 2) Inspect lip seals for cracks, wear, cuts, and brittleness. Inspect springs and seal shells for damage.
- 3) Gaskets and seals on electrical parts may be reused. Inspect gaskets and seals for wear, nicks, cuts, and torn or missing gasket material. Replace gasket, if needed.
- k. SPLINED PARTS. Inspect splined parts for burrs, wear, twisted, cracked, or broken splines.
- 1. *THREADED PARTS*. Inspect all threaded parts for burrs and stripped or damaged threads.
- m. RETAINING RINGS. Inspect retaining rings for nicks, burrs, defects, loss of tension, and wear.
- n. SPRINGS. Inspect springs visually for wear, defects, breaks, and loss of tension or compression.
- o. SHAFTS AND SPINDLES. Inspect shafts and spindles for excessive wear, binding, scores, cracks, and burrs.

#### p. ELECTRICAL PARTS.

- 1) Inspect electrical parts before you install them. Look for mildewed, corroded, or burned parts.
- 2) Inspect electrical parts for pinched or loose wires and for cracked or broken wires, circuit cards, relays, and connectors.
- 3) Inspect insulation and heatshrink tubing for cracks, tears, burns, or missing material.
- q. CANVAS COVERS AND ROPES.
  - 1) Inspect canvas covers and webbing for holes, cuts, seam tears, and mildew.
  - 2) Inspect ropes and webbing for broken strands. If more than half the strands are broken, replace rope or webbing.

#### 4. **REPAIR**

- a. *GENERAL*. General repair procedures are given in steps b through l below. Special procedures are covered in the task. After procedures, clean all parts well.
- b. CASTINGS.
  - 1) Replace all cracked or broken castings.
  - 2) Repair minor damage to machined surfaces of castings with cleaning cloth (WP 0542 00, Item 8). Replace any part with defects that cannot be corrected or which will impair function.
- c. Repair minor surface bends by working bent surface of casting across sheet of crocus cloth on surface plate. Replace bent castings which would impair assembly or function.
- d. BEARINGS. See TM 9-214 for inspection and maintenance of needle roller or ball bearings.
- e. *BUSHINGS AND BUSHING-TYPE BEARINGS*. Replace bushings and bushing-type bearings if they are loose, scored, or have color change due to heat. When you replace bushings and bushing-type bearings, check nearby parts for damage or wear.
- f. OIL SEALS. Oil seals must be replaced when thin feather edge is damaged or when seal material is brittle.
  - 1) Press damaged oil seal from casting. Be careful not to damage bore.
  - When oil seal bore is damaged so an oil-tight seal is impossible, replace casting or adapter. Remove slight nicks, burs, and scratches with cleaning cloth (WP 0542 00, Item 8) dipped in cleaning compound (WP 0542 00, Item 9).
  - 3) Install new oil seal in casting bore or adapter using suitable oil seal replacement tool.

- g. *GREASE SEALS, PREFORMED PACKINGS, GROMMETS, AND GASKETS.* Preformed packings, seals, grommets, and gaskets should be replaced when removed unless otherwise stated in the maintenance task. They should not be reused.
- h. *THREADED PARTS*. Replace all parts that have stripped or damaged threads. Replace parts that cannot be repaired by chasing threads with a used tap or die.
- i. RETAINING RINGS.
  - 1) Retaining rings that have defects should be replaced when removed unless otherwise stated in the maintenance task. They should not be reused.
  - 2) Some retaining rings are beveled on one side. When installing this type of ring, the beveled side must face the part to be retained.
- j. *SPRINGS*. Discard springs that have defects. Load and height inspection data, where needed, are given in maintenance procedures.
- k. SHAFTS AND SPINDLES.
  - 1) Replace shafts and spindles that show signs of wear, binding, scores, cracks, burrs, or clogged oil passages.





Air pressure in excess of 30 psi (207 kpa) can injure personnel. Do not direct pressurized air at yourself or others. Always wear goggles.

- 2) Remove obstructions with compressed air or by probing with soft wire.
- 3) Remove burrs and minor surface defects with a cleaning cloth (WP 0542 00, Item 8).
- 1. ELECTRICAL PARTS.
  - 1) Replace corroded or burned parts and parts which show sings of mildew.
  - 2) Tighten loose connections.
  - 3) Replace cracked or broken wires, circuit cards, relays, and connectors.
  - 4) Replace cracked, torn, or burned insulation and heatshrink tubing.
- m. CANVAS COVERS AND ROPES.
  - 1) Repair canvas cover tears and ripped seams. See FM 10-16 for canvas and webbing repair.
  - 2) Repair rope and faulty rope ends with twine or adhesive tape. Trim rope ends. Reverse rope that shows minor wear.

### 5. FLUID LEAKS AND CHECKING FOR LEAKS

a. *GENERAL*. Fluid leaks in hoses and fluid lines affect the carrier parts operation. The types and classes of leaks are given below.

CLASS I Fluid seepage is not great enough to form drops, but it is shown by wetness or color changes.

CLASS II	Fluid leakage is great enough to form drops. Drops do not drip from the item being checked or inspected.
CLASS III	Fluid leakage is great enough to form drops that fall from the item being checked or inspected

## NOTE

You are allowed to operate equipment with minor water or oil leaks (Class I or II). You must consider how much fluid the item or system being checked or inspected can hold. When in doubt, notify your supervisor. Any fuel or Class III leaks will make the vehicle NOT READY/ AVAILABLE.

- b. *CHECKING FOR LEAKS AFTER A MAINTENANCE TASK.* After doing maintenance on a part which involves hoses or fluid lines, check for leaks. If leaks occur after you have done a replace or repair task, find the source of the leak. Correct the problem. Follow these procedures.
  - 1) Do visual inspections to find the source of the leak.
    - a) Check for cracks on housing or cover.
    - b) Check that screws and any connections are not loose or overtight.
  - 2) If you cannot see the source of the leak, check the items listed below.
    - a) Check that preformed gasket is not bent, or pinched.
    - b) Check machined surfaces for fit and cleanliness.
    - c) If leak persists, notify supervisor.
- c. *CHECKING FOR LEAKS USING CHALK TEST.* Following replacement, repair, or adjustment of a door, access panel, or rubber seal, check for leaks by performing a chalk test. Use the following procedure:
  - 1) Use chalk or chalk powder to coat area around seal.
  - 2) Close door or panel.
  - 3) Open door or panel.
  - 4) Check for unbroken chalk line on mating surface. Where chalk does not stick to mating surface, there is a leak in the seal surface.
  - 5) If a leak is found, perform adjustment to correct the problem.

### 6. WARM-UP ENGINE (M548A1)

To warm up the engine for a maintenance or troubleshooting task, do the following:

- a. Cover air inlet grill.
- b. Start engine (see your -10).
- c. Lock left and right steering levers.
- d. Move gear selector to 2-3 range. Do not release left and right steering levers.
- e. Raise engine speed to 1500 rpm until normal operating temperature is reached.
- f. Lower engine rpm to idle.
- g. Move gear selector to NEUTRAL.
- h. Stop engine (see your -10).

i. Uncover air inlet grill.

### 7. WARM-UP ENGINE (M548A3)

To warm up the engine for a maintenance or troubleshooting task, do the following:

- a. Cover air inlet grill.
- b. Start engine (see your -10).
- c. Apply parking brake and foot brake.
- d. Move gear selector to 2-3 range.
- e. Run engine at approximately 800 rpm for 3 to 5 minutes, or until normal operating temperature is reached.
- f. Lower engine rpm to idle.
- g. Move gear selector to SL.
- h. Stop engine (see your -10).
- i. Uncover air inlet grill.

#### **EXPLANATION OF PMCS TABLE ENTRIES**

**Item Number Column** — Numbers in this column are for reference. When completing DA Form 2404 (Equipment Inspection and Maintenance Worksheet), include the item number for the check/service indicating a fault. Item numbers also appear in the order that you must do the checks and services for the intervals listed.

**Interval Column** — This column tells you how often you must perform the checks/services. Semi-Annual checks/services must be performed every six months or after 1500 (2400 km) of operation.

**Man-Hour Column** — This column gives the man-hours (to the nearest 10th of an hour) needed to complete the prescribed lubrication service. This column is used only for lubrication services.

Item To Be Checked or Serviced Column — This column lists the item to be checked or serviced.

**Crewmember/Procedure Column** — This column gives the procedure you must do to check or service the item listed in the *Item To Be Checked or Serviced* column to know if the equipment is ready or available for its intended mission or for operation. You must do the procedure at the time stated in the interval column.

**Equipment Not Ready/Available If: Column** — Information in this column tells you what faults will keep your equipment from being capable of performing its primary mission. If you perform check and service procedures that show faults as listed in this column, do not operate the equipment. Follow standard operating procedures for maintaining the equipment or reporting equipment failure.

## ARMY OIL ANALYSIS PROGRAM (AOAP)

## NOTE

## Park carrier on level ground to check oil levels. Clean fittings with cleaning compound. Dry before lubricating. Check/lubricate all oil and grease fitting points after washing or fording.

AOAP is an effective maintenance diagnostic tool and not a maintenance substitute. TB 43-106 and TM 9-2300-422-23&P must not be interpreted to mean that AOAP minimizes in any way the need to employ good maintenance practices and strong maintenance discipline.

#### SAMPLING REQUIREMENTS

Samples may be taken without warming a component to operating temperature if the equipment has been operated within the last 30 days. If the equipment has not been operated within the last 30 days, these requisites apply to both routine and special sampling. Several hours of operation are needed to completely mix old and new oils.

## SAMPLING PROCEDURES

Perform AFTER operation checks and services. See your -10.

## NOTE

DO NOT ADD OIL immediately prior to taking oil samples. When AFTER operation checks and services indicate the need to replenish oil levels, WAIT until after taking samples. New oil added immediately prior to taking samples will adversely effect oil analysis results.

Obtain two sample bottles (NSN 8125-01-082-9697) and two DA Form 2026 from the unit AOAP monitor.

Start engine. See your -10. If required (see Sampling Requirements above), drive carrier. See your -10 to bring engine and transmission up to normal operating temperatures.

Stop carrier and set the brakes. See your -10.

Place range selector in the N (Neutral) position and keep engine running. On M548A3, lock the steering wheel. See your -10.

Raise crew seat and center floor plate. See your -10.

With engine operating, remove dust caps from the engine and transmission oil sampling valves.

Open sample valve on engine oil filter and drain a small amount of oil into a container to clear valve of grit and contamination. (Properly dispose of container and oil upon completion of sample taking.) Fill sampling bottle to the neck shoulder and seal it. Attach DA Form 2026 to sampling bottle.



Close oil sample valve and install dust cap.

Take oil sample from transmission in the same manner (see previous three steps).

Stop engine. See your -10.

Lower crew seat and center floor plate. See your -10.

Deliver sample bottles to the unit AOAP monitor.

## NOTE

For location of nearest AOAP Laboratory and complete information about AOAP, refer to TB 43-0106. "Oil filters shall be serviced/cleaned/changed as applicable, when: (a) They are known to be contaminated, or clogged; (b) Service is recommended by AOAP Laboratory analysis, or (c) At prescribed hard time intervals."

### LUBRICATION TABLES

Lubrication intervals will be indicated by one of the following symbols:

OC = AOAP On-Condition B = Before D = Daily AF = After W = Weekly M = Monthly S = 1,500 miles (2,400 km), Semi-annually AN = Annually

The following tables are used during PMCS lubrication checks.

SYMBOL	NOMENCLATURE	SPECIFICATION
FRH	Hydraulic Fluid, Rust Inhibited, Fire Resistant	MIL-H-46170
GAA	Greas, Automotive and Artillery	MIL-G-10924
OE/HDO	Lubricating Oil, Internal Combustion Engine	MIL-L-2104
OEA	Lubricating Oil, Internal Combustion Engine	MIL-L-46167
PE	Preservation Oil	MIL-L-21260

## Table 1. LUBRICATION SYMBOLS

## Table 2. LUBRICANT USAGE: ENGINE (M548A3)

COMPONENTS REFILL INTERVALS = AF. CAPACITY		LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
INTERVALS = AF, OC	(APPROX)	+5°F to +120°F (-15°C to +48.8°C)	+40°F to -60°F (+5°C to -51.1°C)	
OE/HDO (MIL-L-2104) or OEA (MIL-L-46167)	18 qt.	OE/HDO-15/40	OEA	
PE (MIL-L-21260)		PE 30-1		
* For Arctic Operation Refer to FM 9-207				

COMPONENTS	REFILL	LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
INTERVALS = D, S, OC	CAPACITY (APPROX)	Above +32°F (Above 0°C)	+40°F to -10°F (+5°C to -23°C)	0°F to -65°F (-18°C to -54°C)
OE/HDO (MIL-L-2104) or OEA (MIL-L-46167)	18 qt.	OE/HDO-15/40	OE/HDO-15/40	OEA
* For Arctic Operation Refer to FM 9-207				

## Table 3. LUBRICANT USAGE: ENGINE (M548A1)

## Table 4. LUBRICANT USAGE: TRANSMISSION (M548A3)

COMPONENTS	REFILL CAPACITY	LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
INTERVALS = AF, S, AN, OC	(APPROX)	+5°F to +120°F (-15°C to +48.8°C)	+40°F to -60°F (+5°C to -51.1°C)	
OE/HDO (MIL-L-2104) or OEA (MIL-L-46167)	40 qt. or 10 gal.	OE/HDO-15/40	OEA	
PE (MIL-L-21260)	See Note	PE 30-1		
NOTE: If transmission has been filled with preservation oil (MIL-L-21260) by the manufacturer or at time of overhaul, leave this oil in transmission until first scheduled oil change. Maintain operating oil level by adding same grade of PE oil. When first scheduled oil change is made, refill transmission with applicable grade oil (OE/HDO or OEA).				
* For Arctic Operation I	Refer to FM 9-207			

## Table 5. LUBRICANT USAGE: TRANSMISSION (M548A1)

COMPONENTS	REFILL	LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
INTERVALS = AF, S, OC	CAPACITY (APPROX)	Above +32°F (Above 0°C)	+40°F to -10°F (+5°C to -23°C)	0°F to -65°F (-18°C to -54°C)
OE/HDO (MIL-L-2104) or OEA (MIL-L-46167)	16 qt.	OE/HDO-15/40	OE/HDO-15/40	OEA
* For Arctic Operation Refer to FM 9-207				

COMPONENTS	REFILL	LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
INTERVALS = AF, S, OC	CAPACITY (APPROX)	Above +32°F (Above 0°C)	+40°F to -10°F (+5°C to -23°C)	0°F to -65°F (-18°C to -54°C)
OE/HDO (MIL-L-2104) or OEA (MIL-L-46167)	2.5 qt.	OE/HDO-15/40	OE/HDO-15/40	OEA
* For Arctic Operation Refer to FM 9-207				

## Table 6. LUBRICANT USAGE: TRANSFER GEARCASE

## Table 7. LUBRICANT USAGE: DIFFERENTIAL

COMPONENTS	REFILL	LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
INTERVALS = AF, S, OC	CAPACITY (APPROX)	Above +32°F (Above 0°C)	+40°F to -10°F (+5°C to -23°C)	0°F to -65°F (-18°C to -54°C)
OE/HDO (MIL-L-2104) or OEA (MIL-L-46167)	20 qt.	OE/HDO-15/40	OE/HDO-15/40	OEA
* For Arctic Operation Refer to FM 9-207				

## Table 8. LUBRICANT USAGE: FINAL DRIVES

COMPONENTS	REFILL	LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
INTERVALS = D, S, OC	CAPACITY (APPROX) Above +32°F (Above 0°C)	+40°F to -10°F (+5°C to -23°C)	0°F to -65°F (-18°C to -54°C)	
OE/HDO (MIL-L-2104) or OEA (MIL-L-46167)	3.5 qt. or 7 pt.	OE/HDO-15/40	OE/HDO-15/40	OEA
* For Arctic Operation Refer to FM 9-207				

COMPONENTS	REFILL CAPACITY	LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
INTERVALS = AN, S	(APPROX)	+5°F to +120°F (-15°C to +48.8°C)	+40°F to -60°F (+5°C to -51.1°C)	
GIA (MIL-G-23827	As Required			
GAA (MIL-G-10924)	As Required	All Temperatures		
OE/HDO (MIL-L-2104) or OEA (MIL-L-46167)	As Required			
* For Arctic Operation Refer to FM 9-207				

### Table 9. LUBRICANT USAGE: TACHOMETER AND SPEEDOMETER

## Table 10. LUBRICANT USAGE: FAN GEAR BOX

COMPONENTS	REFILL CAPACITY (APPROX)	LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
INTERVALS= M, S		+5°F to +120°F (-15°C to +48.8°C)	+40°F to -60°F (+5°C to -51.1°C)	
OE/HDO (MIL-L-2104)	0.75 pt.	OE/HDO-15/40	OEA	
* For Arctic Operation Refer to FM 9-207				

## Table 11. LUBRICANT USAGE: PULLEY SUPPORT ARM

COMPONENTS INTERVALS = M, S	REFILL CAPACITY (APPROX)	LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
		+5°F to +120°F (-15°C to +48.8°C)	+40°F to -60°F (+5°C to -51.1°C)	
GAA (MIL-G-10924)	As Required	All Temperatur	res	
* For Arctic Operation Refer to FM 9-207				

## Table 12. LUBRICANT USAGE: STEERING CONTROL BEARINGS; FOOT BRAKE PEDAL LINKAGE

COMPONENTS INTERVALS = S	REFILL CAPACITY (APPROX)	LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
		+5°F to +120°F (-15°C to +48.8°C)	+40°F to -60°F (+5°C to -51.1°C)	
GAA (MIL-G-10924)	As Required	All Temperatu	ires	
* For Arctic Operation Refer to FM 9-207				

## Table 13. LUBRICANT USAGE: PIVOT STEER SYSTEM

COMPONENTS INTERVALS = S	REFILL CAPACITY (APPROX)	LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
		Above +32°F (Above 0°C)	+40°F to -10°F (+5°C to -23°C)	0°F to -65°F (-18°C to -54°C)
FRH (MIL-H-46170)	1 pt.		All Temperatures	
* For Arctic Operation Refer to FM 9-207				

## Table 14. LUBRICANT USAGE: FAN DRIVE SHAFT; STEERING CONTROL LEVER

COMPONENTS INTERVALS = S	REFILL	LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
	CAPACITY (APPROX)	Above +32°F (Above 0°C)	+40°F to -10°F (+5°C to -23°C)	0°F to -65°F (-18°C to -54°C)
GAA (MIL-G-10924)	As Required		All Temperatures	
* For Arctic Operation Refer to FM 9-207				

## Table 15. LUBRICANT USAGE: UNIVERSAL JOINT

COMPONENTS INTERVALS= S	REFILL CAPACITY (APPROX)	LUBRICANTS TO USE AT EXPECTED TEMPERATURES *		
		+5°F to +120°F (-15°C to +48.8°C)	+40°F to -60°F (+5°C to -51.1°C)	
GAA (MIL-G-10924)	As Required	All Temperat	ures	
* For Arctic Operation Refer to FM 9-207				

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
1	Semi- Annual		Road Test	<section-header><text><text><text><section-header><text><text><text></text></text></text></section-header></text></text></text></section-header>	
a	Semi- Annual		Left and Right Steering	CAUTION Power plant can be damaged. Do not pivot steer when carrier is moving except in a track failure emergency. a. Check steering in left and right turns. If carrier does not finish a complete turn when wheel/ laterals is turned to left or right, troubleshoot steering system (WP 0006 00).	Carrier does not turn properly.

## Table 16. Semi-Annual Unit Level Preventive Maintenance Checks and Services for M548A1 and M548A3

#### 0128 00

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
b	Semi- Annual		Steering in Forward and Reverse Range	a. For M548A3 Only. Check steering wheel in forward range and reverse range. If carrier does not make a complete turn after steering wheel is turned to the left and right, troubleshoot steering system (WP 0006 00).	Binding, grabbing, unusual noise, vibration or carrier fails to turn.
с	Semi- Annual		Carrier Braking	<ul> <li>a. Check carrier braking. If carrier does not slow down or stop when brakes are slightly or fully depressed, troubleshoot brake system (WP 0006 00).</li> </ul>	Carrier fails to stop.
d	Semi- Annual		Carrier Shifting in All Ranges	a. Check shifting of carrier in all ranges. If carrier does not respond properly to selected driving range, troubleshoot gear selection system (WP 0006 00).	Carrier fails to shift into selected range.
e	Semi- Annual		Shutdown	<b>CAUTION</b> Turbo may be damaged by shutting down engine if engine is immediately stopped after periods of operation. Allow engine to run at idle speed (600–650 rpm) for 3 to 5 minutes before stopping. a. When shutting down engine: Check operation of fuel cutoff control.	Fuel cutoff control is
2	Semi- Annual		After Road Test	WARNING         Image: Constraint of the set of the set parking brake and block road wheels can allow carrier to move and could result in injury or death. Always set parking brake and block road wheels before working on carrier.	inoperative.

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
				a. Immediately after road test cautiously feel all wheel and idler hub for noticeable difference in temperature between hubs. An overheated hub indicates that bearing is out of adjustment, poorly lubricated, or damaged.	Any Class III leaks, cold shocks, or bad bearings.
				<ul> <li>b. Check temperature of shock absorbers. Shock absorbers should be warm. A cold shock absorber is faulty.</li> </ul>	
2	Guad			c. Visually check inside and outside of carrier for fuel, oil, or hydraulic leaks.	
3	Semi- Annual		Idle Test	<b>CAUTION</b> Avoid lengthy engine idling. This causes coolant temperature to drop below operating temperature and can shorten engine life.	
				a. Run engine at 800 rpm for 3-5 minutes with range selector in 2 to 3 range and brakes locked until normal operating temperature is reached.	Engine runs hot or rough.
				<ul> <li>b. If outside temperature is less than 85 degrees F (29 degrees C), normal operating temperature should be 160 degrees F to 200 degrees F (71 degrees to 93 degrees C). If outside air temperature is greater than 85 degrees F (29 degrees C), normal operating temperature should be 160 degrees to 225 degrees F (71 degrees to 107 degrees C).</li> </ul>	
				<ul> <li>c. With range selector in N (M548A1) or SL (M548A3), engine should idle smoothly at 650 to 700 rpm.</li> </ul>	
				<ul> <li>d. High or low engine idle speed is usually caused by accelerator linkage being out of adjustment. Adjust linkage if necessary (WP 0197 00 or WP 0200 00).</li> </ul>	
				e. Rough idling is usually caused by faulty injector timing and rack setting, faulty injectors or air in the injection system. Notify your supervisor.	

			1		
ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	<u>CREWMEMBER</u> PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
4	Semi- Annual	0.2	Transmission Oil	<ul> <li>a. Sample transmission oil. Use procedures given in TB 43-0106. For lubricant information, see Table 4, page 0128 00-16 or Table 5, page 0128 00-16.</li> </ul>	Hard time interval exceeded, AOAP recommends change.
5	Semi- Annual	0.2	Engine Oil	<ul> <li>a. Sample engine oil. Use procedures given in TB 43-0106. For lubricant information, see Table 2, page 0128 00-15 or Table 3, page 0128 00-16.</li> </ul>	Hard time interval exceeded, AOAP recommends change.
6	Semi- Annual	0.2	Final Drive Oil	a. Check left and right final drive oil level. Use procedures given in TB 43-0106. For lubricant information, see Table 8, page 0128 00-17.	Hard time interval exceeded, AOAP recommends change.
7	Semi- Annual		Track Tension Adjuster	<ul> <li>a. Check adjuster for broken or cracked hardware on both carrier sides. Replace damaged parts (WP 0356 00).</li> </ul>	Adjuster or hardware is failed, leaking or missing.
				HARDWARE	
8	Semi- Annual		Idler and road Wheel Arms	a. Check cracked or bent idler arm or road wheel arms. Check idler or road wheel arm relief valves and grease fittings if leaking. Check for leaking road wheel arm seals and gaskets.	Any bent, broken or cracked arm, leaking seal, or loose bearing.

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:			
9	Semi- Annual		Idler and road Wheel Mounting Nuts	<ul> <li>a. Check idler and road wheel mounting nuts for looseness. Tighten loose nuts to 150–170 lb-ft (203–230 N•m) torque.</li> </ul>	Any missing or stripped nuts.			
10	Semi- Annual		Idler/Road Wheels and Idler/Road Wheel Hubs	<ul> <li>a. Check for cracked, broken or bent idler/road wheels and idler wheel hubs.</li> </ul>	Any broken, bent or cracked idler road wheels or leaking hub seals.			
				<ul> <li>b. At each service, or whenever track is removed, adjust wheel bearings if looseness or end play is evident (WP 0351 00).</li> </ul>	Any loose bearings or Class III leaks.			
				c. Check for leaking seals and gaskets.				
				d. Check for leaking grease fittings and relief valves.	Any leaking grease fittings.			


0128 00

### PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS), INCLUDING LUBRICATION INSTRUCTIONS — Continued

#### ITEM **INTERVAL** MAN-ITEM TO BE CREWMEMBER EQUIPMENT NO. HOUR CHECKED OR PROCEDURE NOT READY/ SERVICED AVAILABLE IF: 11 Idler and Road a. Check for bent, broken or stripped idler/road Semi-Any broken, Annual Wheel Hub wheel hub ribbed bolts. bent and **Ribbed Bolts** stripped bolts. ROAD WHEEL ARM SUPPORT BUMPER ROAD MOUNTING WHEEL HARDWARE MOUNTING NUTS ARM MOUNTING RIBBED BOLTS HOLES **ROAD WHEEL HUBS** 12 Road Wheel Semia. Check and tighten loose road wheel arm Any loose Arm Mounting mounting hardware to 130-140 lb-ft (176-190 mounting Annual Hardware and N•m) torque. Check for missing or loose road hardware. Support wheel arm support bumpers. Bumpers 13 Semi-Road Wheel a. Check for road wheel mounting holes extending Any elongated Annual Mounting Holes beyond head of mounting nut. holes that extend beyond mounting nuts. ROAD WHEEL ARM MOUNTING NUT MOUNTING HARDWARE MOUNTING HOLES 14 Shock Absorber Any cracked, Semia. Check shock absorbers for leaks, dents, cracks, or loose bearings. Replace shock absorber that broken, bent or Annual is bent, broken, cracked or dented enough to missing shocks or dents that hinder operation. Replace worn bearing (WP 0379 00). hinder shock operation.


ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:		
				<ul> <li>b. Check shock absorbers for Class III fluid leaks or loose fitting bearings.</li> </ul>	Any Class III fluid leaks.		
				<ul> <li>c. Check shock absorber mounting hardware for looseness. Tighten loose hardware to 130–140 lb-ft (176–190 N•m) torque.</li> </ul>			
				<ul> <li>d. Check shock absorber bracket mounting hardware for looseness. Tighten loose hardware to 130–140 lb-ft (176–190 N•m) torque.</li> </ul>			
	SHOCK ABSORBER BRACKET MOUNTING HARDWARE						
				ISHOCK ABSORBER	RE		
	SHOCK ABSORBER						
15	Semi- Annual		Sprocket and Cushion	<ul> <li>a. Check and/or reverse sprocket teeth if their edges fall behind wear gauge (see your -10 PMCS). Check and replace sprocket cushions if gouges, chips, and cuts are enough to cause thumping.(WP 0357 00).</li> </ul>	Sprocket is broken or cracked.		
				<ul> <li>b. Torque loose mounting screws to 110–115 lb-ft (149–156 N•m) torque.</li> </ul>	Any screws are missing, loose or worn. Any elongated holes that extend beyond screw heads.		
				c. Torque loose sprocket hub screws to 170–190 lb-ft (231–258 N•m) torque.			


ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
				SPROCKET CUSHIONS HUB SCREWS	
16	Semi- Annual		Towing Pintle, Tow Hooks and Lifting Eyes	MOUNTING SCREWS a. Check and replace missing or damaged retaining pins and keys (WP 0377 00). Check if towing pintle is securely mounted and operates satisfactorily.	



ITEM NO. 17	INTERVAL Semi-	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED Tailgate and Cab	CREWMEMBER         PROCEDURE         a. Check cab doors and tailgate for ease of	EQUIPMENT NOT READY/ AVAILABLE IF:			
17	Annual		Doors	a. Check cab doors and tangate for ease of movement, damaged seals, and general condition. Tighten loose hardware and check adjustments for watertight fit. Adjust if required (WP 0388 00 and WP 0405 00).				
	SEAL							
	CAB DOOR							
	TAILGATE							

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:			
18	Semi- Annual		Cab and Rear Compartment Covers	<ul> <li>a. Check covers for tears, loose straps, broken ropes, and damaged grommets. Replace broken rope. Replace covers that are damaged (WP 0417 00 and WP 0418 00).</li> </ul>				
		CORD						
	COVER STRAP STRAP M548A3 SHOWN							
19	Semi- Annual		Taillights and Stoplights	<ul> <li>a. Check and replace discolored and cracked taillight lens (WP 0278 00). With helper's assistance, check operation of service taillight, service stoplight, blackout taillight, and blackout stoplight (see your -10). Repair or replace lights that do not work. See (WP 0275 00, WP 0276 00, or WP 0278 00) as required.</li> </ul>				







AnnualAnchors, or SplinesLB-FT (434–447 N•M). When power plant is removed, torque power plant compartmentbent, stripp	bars or ng						
or cotter pins on torsion bar anchors (WP 0350 00). c. Check that torsion bar plugs are fully seated and retaining screws are tight. ANCHOR SCREWS COTTER PIN COTTER PIN SPLINES PIN							
ANCHOR SCREWS ANCHOR SCREWS COTTER PIN COTTER PIN SPLINES PIN							
ANCHOR SCHEWS COTTER PIN SPLINES PIN							
SPLINES PIN							

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
24	Semi- Annual		Track	<ul> <li>a. Torque loose track pin retaining nuts 115–135 lb-ft (156–183 N•m). Check for missing, damaged or worn track pads or track shoes. Torque loose retaining nuts to 135–155 lb-ft (183–210 N•m).</li> </ul>	Any pins/nuts that are cracked, broken, bent, stripped, missing or protruding.
				TRACK SHOES PADS PADS PINS NUTS RETAINING NUTS	
25	Semi- Annual		Cooling System	a. Addition of extender to antifreeze is a one time service. When extender is added to antifreeze, the date must be recorded in the "remarks" block of DD Form 314. If DD Form 314 identifies the unsafe coolant as having been extended before or the coolant as arctic antifreeze, then the coolant must be drained and replace with fresh coolant. See WP 0212 00 and WP 0213 00, or WP 0214 00, as required.	
				b. Check coolant cleanliness by draining a small amount of coolant into a clean container and look for excessive rust, foreign particles, and/or sediments.	Excessive coolant contamination is found.

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
26	Semi- Annual		Cooling System Radiator Hoses, Pump, and pump Drive Belts	NOTE         M548A1 access is through the passenger seat. M548A3 access is through the rear power plant rear access panel.         a. Check radiator and coolant pump for leaks. Check that all hose clamps and mounting screws are tight. Check cooling pump drive belt for 3/8 inch (10 cm) deflection, cracks and looseness. Tighten loose belts by adjusting pulley. Secure belt adjustment by tightening screws.         VARNING         VARNING         Air pressure in excess of 30 psi (207 kpa) can injure personnel. Do not direct pressurized air at yourself or others. Always wear goggles.         Clean outside of radiator with air gun. Check cap and seal for damage that allows leakage. Replace or repair damaged hardware (WP 0215 00 or WP 0216 00).	Any hardware is loose or missing or has any Class III fluid leaks.






ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:		
28	Semi- Annual		Fixed Fire Extinguisher	a. Remove and weigh fixed fire extinguisher cylinder (WP 0526 00). If cylinder is low, refill.			
				<ul> <li>Before reconnecting or replacing cylinder, operate discharge handles and be sure cables and controls work right.</li> </ul>			
				c. Install cylinder and replace copper seal wires (WP 0527 00 or WP 0528 00).			
				<ul> <li>Replace discharge tubes that are crimped or cracked (WP 0524 00 or WP 0525 00).</li> </ul>			

r		1		l	ı	
ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:	
29	Semi- Annual		Driver's and Cab Personnel Seats	NOTE M548A1 carriers have two passenger seats. M548A3 has only one passenger seat. a. Check and replace damaged seat cushions (WP 0397 00 or WP 0398 00).		
				<ul> <li>b. Check and replace damaged straps (WP 0397 00 or WP 0398 00).</li> <li>c. Check and replace damaged hinges (WP 0397 00 or WP 0398 00).</li> </ul>		
				d. Check and replace damaged seals (WP 0397 00 or WP 0398 00).		

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
30	Semi- Annual		Batteries	<section-header><section-header><text><text><section-header><image/><text><text><text></text></text></text></section-header></text></text></section-header></section-header>	





-	Ī				,	
ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:	
				<ul> <li>c. Check electrolyte level in all cells of batteries. Add distilled water as needed. See TM 9-6140-200-14.</li> </ul>	Any leaks, loose, damaged, burned post, cracked, broken, missing batteries or hardware.	
				<ul> <li>d. Test specific gravity of batteries. See TM 9-6140-200-14.</li> </ul>	Cell is below specific gravity.	
				e. Clean vent holes in cell caps. See TM 9-6140-200-14.		
				<ul> <li>f. Clean terminals, posts, and bolts. See TM 9-6140-200-14.</li> </ul>	One or more batteries unserviceable, missing, broken, or frayed cables.	
				g. Tighten terminals and bolts with care to avoid damage to batteries. Apply light coat of GAA grease (WP 0542 00, Item 14).	One or more batteries unserviceable, missing, broken, or frayed cables.	
		•	•	POSITIVE POST		
	POST POST VENT HOLE					
				NEGATIVE POST M548A3 SHOWN		


ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:		
31	Semi- Annual		Fuel System	a. Inspect fuel lines, fuel pumps, and fuel cap for leaks, bent/buckled, deteriorated lines, chaffed hoses, fittings, electrical connectors and wires for security, looseness or frayed wires.			
32	Semi- Annual		Engine Fuel Pump	a. Check engine fuel pump for leaks.	Any fuel leak.		
	ENGINE FUEL PUMP						
33	Semi- Annual		Electric Fuel Pumps	a. Check electric fuel pumps lines for leaks.	Any fuel leak.		
	M548A3 ELECTRIC FUEL PUMPS						

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:		
34	Semi- Annual		Air Separator Tank	a. Check air separator tank and lines for leaks.	Any fuel leak.		
				AIR SEPARATOR TANK			
35	Semi- Annual		Filler Cap	a. Check filler cap, strainer, and hoses for leaks and damage.	Missing filler cap. Any fuel leak.		
	Itak.						


ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:		
36	Semi- Annual		Fuel Filters Primary/ Secondary	a. Replace primary and secondary fuel filter elements (WP 0178 00 or WP 0179 00). Check for leaks.	Any fuel leak.		
	SECONDARY FUEL FILTER PRIMARY FUEL FILTER						
	M548A3 SHOWN						
37	Semi- Annual		Air Box Heater Air Pump	<ul> <li>a. Check operation of air box heater air pump (see your –10). Disconnect lead from fuel shutoff solenoid valve. Have helper pull out fuel shutoff and intermittently crank engine and run air pump at same time for total of 20 seconds. Connect lead to fuel shutoff solenoid valve.</li> </ul>	Any fuel leak.		










ITEM	INTERVAL	MAN-	ITEM TO BE	CREWMEMBER	EQUIPMENT
NO.		HOUR	CHECKED OR SERVICED	PROCEDURE	NOT READY/ AVAILABLE IF:
				<ul> <li>b. HARD TIME. Hard time interval may be shortened if equipment operates under adverse conditions (for arctic operations, refer to FM 9-207; for desert operations, refer to FM 90-3).</li> </ul>	Hard time interval exceeded.
				<b>CAUTION</b> Engine and transmission can be damaged if filled above the FULL (F) mark on the gauge rods.	
				NOTE	
				If AOAP laboratory is not available, drain engine oil and change filter element/ gaskets every 150 hours, 1500 miles (2414 km) or semi-annually. Transmission oil should be drained and filter element/ gaskets changed every 150 hours, 1500 miles (2414 km) or semi-annually.	
				NOTE	
				Always change filters on transmission and engine even when using AOAP every 150 hours, 1500 miles (2414 km) or semi-annually.	
				c. ON CONDITION. To drain engine or transmission oil, remove hull bottom access cover and drain plug. Inspect oil for metal particles. If metal particles are found, notify your supervisor. Replace engine or transmission oil filters each time an oil change is required.	













ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
				d. Clean inside of engine filter cover or transmission filter cavity with cleaning compound.	
				e. Install new engine filter element/gasket (WP 0145 00 or WP 0146 00) or transmission element/packings (WP 0320 00 or WP 0321 00).	
				f. Refill engine with approximately 18 quarts (17 liters) of OE/HDO or OEA. Bring level between full and low marks on gauge rod. Start and run engine (see your -10) and check for oil leaks.	Any Class III leaks.
				g. Refill transmission with approximately 16 quarts (15 liters) for M548A1) or 12 gallons (45 liters) for M548A3 of OE/HDO or OEA after oil change. Start and run engine (see your -10) and operate transmission through all gear selector positions.	Any Class III leaks.
				<ul> <li>h. Check operation of engine and transmission. Run engine (see your −10) and check for oil leaks at filter and drain plug. Inspect access covers on hull bottom for leaks and replace gasket or cover if required (WP 0383 00).</li> </ul>	Any Class III leaks.










ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
45	Semi- Annual		Air Cleaner	<b>CAUTION</b> Operation with dirty or improper air cleaner element can cause poor performance and severe engine damage due to abrasive action. Make sure element is clean and properly installed.	
				a. Inspect air cleaner. Clean as required.	Air filter or hoses damaged or missing.
				b. Clean or replace air cleaner element(WP 0152 00 or WP 0156 00).	
				c. Replace damaged air cleaner housing (WP 0152 00 or WP 0159 00).	
				d. Check for cracked, broken, or brittle air cleaner hoses.	


ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
				AIR CLEANER	
			AIR CLEANER ~	M548A3	


		EQUIPMENT NOT READY/ AVAILABLE IF:							
M548A3 SCREW M54	lb-ft (117–127 40 lb-ft (47–54 en and retighten								
	7C UNIVERSAL								
7C UNIVERSAL JOINT SCREWS M548A1 M548	BA3 BCREWS 7C UNIV JOI								

		1			1
ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
				<ul> <li>b. Check for loose screws on 6C universal joints. Tighten loose screws to 35–40 lb-ft (47–54 N•m) torque. Loosen and retighten screws to 35–40 lb-ft (47–54 N•m) torque (M548A1).</li> </ul>	
				c. If universal joint has lubrication fittings, lubricate with GAA (Table 15, page 0128 00-19).	
			M548A1	SCREW SCREW	I
47	Semi- Annual (M548A3)		Steering Rod and Connecting Link	a. Check steering linkage lever on top of transmission for ease of movement from low to full position. If linkage does not move easily, troubleshoot steering system (WP 0006 00).	Loose or damaged steering rod and connecting link.
			TRANSMI STEERING LINKAGE	ISSION LEVER	
48	Semi- Annual (M548A3)		Power Plant Compartment	a. Clean power plant compartment with cleaning compound (WP 0542 00). Remove debris and wipe up spilled oil and fuel.	





ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
51	Semi- Annual (M548A3)	0.3	Fan Gearbox	a. Check fan gearbox oil level and add oil, if needed. For lubricant information, see Table 10, page 0128 00-18.	Empty or leaking fan gearbox.
				FITTING   FITTING FULC FULL OIL LEVEL SIGHT GLASS CAP AND LOCKING WIRE (DRAIN PORT)	








ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE		EQUIPMENT NOT READY/ AVAILABLE IF:		
56	Semi- Annual (M548A3)		Fuel Cutoff	a. Operate fuel cutoff to c binding occurs, adjust (		Binding, broken or missing parts.		
				<ul> <li>b. Operate accelerator peo- linkage. If binding occ</li> </ul>	dal to check for binding in urs, adjust (WP 0200 00).			
				c. Move transmission shift gears to check for bind replace (WP 0306 00).	ft control through all ing. If grinding occurs,			
		C	FUEL	HAND THROTTLE	TRANSMISSION SHIFT CONTROL			
	PARKING BRAKE HANDLE SERVICE							
57	Semi- Annual		Vehicle Compartment Heater	PEDAL a. Tighten loose mounting vehicle compartment h				
				b. Remove control cover the left.	by turning two screws to			
				c. Check flame detector s control. See TM 9-254				




















ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
				<ul> <li>f. Check heater control box, switches, and light bulb. Tighten or replace bad switches and bulb (WP 0474 00).</li> <li>g. Start, run, and stop heater (see your -10). During start cycle, check that switches and</li> </ul>	
				<ul><li>lights work properly.</li><li>h. During operation, check for unusual noises. Check for increase in coolant temperature.</li></ul>	
				i. When stopping heater, check for correct purge cycle. Check that indicator light works right. If heater does not operate as specified above, perform troubleshooting (WP 0086 00).	





ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
63	Semi- Annual (M548A3)		Quick Disconnect Coupling	<ul> <li>a. Check quick disconnect coupling for proper fit on protective mask and orifice connector assembly. Replace any defective coupling (WP 0538 00).</li> </ul>	
64	Semi- Annual (M548A3)		Orifice Connector Assembly	a. Check valve and general condition of orifice connector. Replace valve or orifice connector as required (WP 0538 00).	
65	Semi- Annual (M548A3)		Air Flow (3.0–4.5 cfm) (.08–.13 cum)	<b>NOTE</b> Air flow should be 3.0–4.5 cfm (.08–.13 cum) (cubic feet/meter per minute)	
				<ul> <li>a. Check each station using M39 air flow tester TM 3-6680-316-10.</li> </ul>	
66	Semi- Annual (M548A3)		ID Plate	a. Replace identification plate if not legible (WP 0440 00).	
67	Semi- Annual (M548A3)		Paint	a. Paint surface to prevent rust or corrosion TB 43-0209.	



ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
69	Semi- Annual (M548A1)		Transfer and Differential Gearcase Mounting	<ul> <li>a. Check for loose mount pins or retaining clips on transfer and differential gearcases. Check for loose transfer clamps. Torque bolts to 75–80 lb-ft (102–108 N•m).</li> </ul>	Any cracked, broken, missing, or binding hardware.
	=   BOL				BOLT
	BO				AINING LIPS /


ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
70	Semi- Annual (M548A1)		Differential Brake Adjustment	a. Using weighing scale (WP 0541 00, Item 43), perform pull test to inspect for proper operation of steering levers and differential brakes. With the levers locked at the second quadrant position, 10 to 30 pounds (4.5 to 14 kg) of pull should unlock the levers. Adjust differential brakes if needed (WP 0341 00).	
		_		DIFFERENTIAL MOUNTS	
		DIFFEF		DIFFERENTIAL MOUNTS MOUNT PINS RETAINING CLIPS DIFFERENTIAL WEIGHING BRAKES SCALE	

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
71	Semi- Annual (M548A1)		Differential Oil Drain	<ul> <li>a. Differential oil every 150 hours, 1500 miles (2414 km), or semi-annually. Drain only when hot after operation. To drain, remove front hull bottom access cover and drain cover (WP 0337 00). Inspect drain cover and oil for metallic particles. If metal chips are found, notify your supervisor.</li> </ul>	Any metal chips are present or Class III oil leaks are found.
				<ul> <li>b. Clean and install drain cover (WP 0383 00) Remove gauge rod from housing and add OE/ HDO oil (approximately 18 quarts) (17 liters). Check oil level and install gauge rod.</li> </ul>	
			GAUGE ROD		
				DRAIN COVER HULL BOTTOM ACCESS COVERS	
				HULL BOTTOM	5

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
				<ul> <li>c. Remove differential oil filter (WP 0338 00). Clean differential oil filter and breather every 150 hours, 1500 miles (2414 km), or semi-annually, using cleaning compound (WP 0542 00).</li> </ul>	
			DIFFERENTIAL OIL FILTER	BREATHER	

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
72	Semi- Annual (M548A1)	1.2	Pivot Steer	<section-header>WARNINGImage: Descent in the second interval inte</section-header>	
				Do not overfill. NOTE If hydraulic fluid is contaminated, or fluid	
				<ul> <li>type is changed, drain pivot steer system, (WP 0371 00).</li> <li>a. Remove fill plugs and check pivot steer master avlinders avery 150 hours, 1500 miles or</li> </ul>	
				cylinders every 150 hours, 1500 miles or semi-annually. Add FRH as required to bring fluid within 1/2 to 3/4 inch from top of cylinder. For lubricant information, see Table 13, page 0128 00-19.	

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
73	Semi- Annual (M548A1)	0.5	Transfer Gearcase Drain	a. Drain gearcase oil. Drain only when hot after operation. Remove hull bottom access cover and drain cover (WP 0383 00). Inspect oil being drained for metal particles. If metal particles are found, notify your supervisor.	Any metal chips are present or Class III oil leaks are found.
				<ul> <li>b. Drain at least 15 minutes. Clean and install drain cover (WP 0383 00)Fill gearcase with approximately 2 1/2 quarts (2 liters) of OE/HDO oil. Make sure gearcase filler cap is closed and breather hole in gauge rod is open. Start engine (see your -10) and operate for one minute. Stop engine and check gearcase oil level. It should be between the gauge rod's FULL and ADD marks. Install hull bottom access cover securely. For lubricant information, see Table 6, page 0128 00-17 (WP 0383 00).</li> </ul>	



	-					
ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:	
74	Semi- Annual (M548A1)		Winch Power Takeoff Controls	a. Check winch power takeoff control for ease of operation and proper alignment. Adjust as needed (WP 0415 00).		
				TAKEOFF CONTROL		
75	Semi- Annual		Decals, Instruction Plates, Stencils, and Paint	a. Replace unreadable decals, instruction plates, and stencil markings (WP 0440 00). Clean and paint bare spots on painted surfaces that might otherwise rust or corrode. See TB 43-0209.		
76	Semi- Annual		Final Road Test	a. Perform final carrier road test. Drive carrier at least 5 miles (8 km).		
				b. Ensure correction of operational faults. pay close attention to those items that were faulty to begin with.		
77	Semi- Annual       Left and Right Steering       CAUTION Power plant can be damaged. Do not pivot steer when carrier is moving except on a track failure emergency.					
				a. Check steering in left and right turns. If carrier does not finish a complete turn, troubleshoot steering system (WP 0006 00).	Carrier does not turn properly.	

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
78	Semi- Annual		Steering Forward and Reverse Range	a. Check steering in forward range and in reverse range. If carrier does not make a complete turn, troubleshoot steering system (WP 0006 00).	Binding, grabbing, unusual noise, vibration or carrier fails to turn.
79	Semi- Annual		Carrier Braking	a. Check carrier braking. If carrier does not stop when brakes are applied, troubleshoot brake system (WP 0068 00).	Carrier fails to stop.
80	Semi- Annual		Carrier Shifting in All Ranges	<ul> <li>a. Check shifting of carrier in all ranges. If carrier does not respond properly to selected driving range, troubleshoot gear selection (WP 0006 00).</li> </ul>	Carrier fails to shift into selected range.
81	Semi- Annual		After Road Test	a. Immediately after road test, cautiously feel all wheel and idler hubs for noticeable difference in temperature between hubs. An overheated hub indicates that bearing is out of adjustment, poorly lubricated, or unserviceable.	Any Class III leaks, cold shocks, or bad bearings.
				b. Check temperature of shock absorbers. Shock absorbers should be warm. A cold shock absorber has failed, replace it (WP 0379 00).	
				c. Visually check inside, outside, and underneath of carrier for fuel, oil, or hydraulic leaks.	Any Class III leak or fuel leak.
82	Semi- Annual		Idle Test	<b>CAUTION</b> Avoid lengthy engine idling. This causes coolant temperature to drop below operating temperature and can shorten engine life.	
				NOTE	
				After a successful road test, perform engine idle and governed no load test only.	
				a. Run engine at 800 to 1000 rpm for 3–5 minutes with range selector in 2–3 range and brakes locked until normal operating temperature is reached.	Engine runs hot or rough.

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
				<ul> <li>b. If outside air temperature is less than 85 degrees F (29 degrees C), normal operating temperature should be 160 to 200 degrees F (71 to 93 degrees C). If outside air temperature is greater than 85 degrees F (29 degrees C), normal operating temperature should be 160 to 230 degrees F (71 to 110 degrees C).</li> </ul>	
				<ul> <li>c. With range selector in N (M548A1) or SL (M548A3), engine should idle smoothly at 650 to 700 rpm.</li> </ul>	
				<ul> <li>d. High and low engine idle speed is usually caused by accelerator linkage being out of adjustment. Adjust linkage if necessary (WP 0197 00 or WP 0200 00).</li> </ul>	
				e. Rough idling is usually caused by faulty injector timing and rack setting, faulty injectors, or air in the injection system. Notify your supervisor.	
83	Semi- Annual		Governed No-Load Test	a. Run engine at 800 to 1000 rpm for 3–5 minutes with range selector in 2–3 range and brakes locked until normal engine operating temperature is reached.	
				<ul> <li>b. If outside air temperature is less than 85 degrees F (29 degrees C), normal operating temperature should be 160 to 200 degrees F (71 to 93 degrees C). If outside air temperature is greater than 85 degrees F (29 degrees C), normal operating temperature should be 160 to 230 degrees F (71 to 110 degrees C).</li> </ul>	
				<ul> <li>c. With range selector in N (M548A1) or SL (M548A3), slowly open throttle control until accelerator is fully depressed.</li> </ul>	

ITEM NO.	INTERVAL	MAN- HOUR	ITEM TO BE CHECKED OR SERVICED	CREWMEMBER PROCEDURE	EQUIPMENT NOT READY/ AVAILABLE IF:
				CAUTION When you suspect a faulty governor, do not exceed 3,000 rpm on engine for more than 2 or 3 seconds. d. Engine speed may exceed 3,000 rpm momentarily, but should stabilize at 2,925 to 2,975 rpm.	If governor cuts in and out or surges at this speed, adjustments are needed. Notify your supervisor.

The following list of parts are required when performing semi-annual, annual, or on-condition PMCS. The semiannual parts list contain the mandatory replacement parts for one semi-annual PMCS. The annual parts list contains the mandatory replacement parts for one semi-annual PMCS combined with the mandatory replacement parts for one (1) annual PMCS. The on-condition parts list contains replacement parts that are required when engine and transmission oil changes are directed by the Army Oil Analysis Program (AOAP) Laboratory. If AOAP Laboratory support is not available, change oil and filter elements/gasket every 150 hours/1500 miles or annually.

#### Table 17. SEMIANNUAL (1500 MILES)

Item No.	Part Number	NSN	Nomenclature	Qty
1	MS28778-12	5330-00-251-8839	PACKING	1

#### 0128 00

Item No.	Part Number	NSN	Nomenclature	Qty
1	MS28778-12	5330-00-251-8839	PACKING	1
2	IO874832	4730-00-766-4714	FILTER	1
3	MS28775-231	5330-00-527-7025	PACKING	1
4	5574161	5330-00-846-9841	GASKET	1
5	CW226MP	2910-00-287-1912	FILTER, ELEMENT	1
6	5574126	5330-00-612-3123	GASKET	1
7	1503536	5330-00-551-0433	GASKET	1
8	T552	2940-00-745-7730	FILTER, ELEMENT	1
9	5703232	2940-01-214-9303	PARTS KIT, FLUID PRE	1

### Table 18. ANNUAL (1500 MILES)

### Table 19. ON-CONDITION (1500 MILES)

Item No.	Part Number	NSN	Nomenclature	Qty
1	57023089	2940-00-678-0641	PARTS KIT	1
2	FL804FP	2940-01-197-7106	FILTER ELEMENT, FLUID	1
3	5703232	2940-01-214-9303	PARTS KIT, FLUID PRE	1
4	MS28775-231	5330-00-527-7025	PACKING	1
5	10874832	4730-00-766-4714	FILTER	1
6	MS35338-45	5310-00-407-9566	WASHER , LOCK	1

### MULTIPLE PIN AND SOCKET IDENTIFICATION

#### THIS WORK PACKAGE COVERS:

Inspection-Acceptance and Rejection Criteria (page 0129 00-1).


#### **INITIAL SETUP:**


Maintenance Level

Unit


#### INSPECTION-ACCEPTANCE AND REJECTION CRITERIA


- 1. It is important to identify the correct pins and sockets for repair when troubleshooting electrical connectors and receptacles.
- 2. Letters or other markings are stamped next to each pin and corresponding socket to ensure proper identification.
- 3. Following are examples of typical connectors found in carriers.











**END OF TASK** 

# TM 9-2350-247-20-1

#### **CHAPTER 4**

# UNIT MAINTENANCE INSTRUCTIONS FOR ENGINE

# WORK PACKAGE INDEX

Title	Sequence_No.
REMOVE/INSTALL POWER PLANT (M548A1)	0130 00
REMOVE/INSTALL POWER PLANT (M548A3)	0131 00
BLOCK POWER PLANT (M548A1)	0132 00
BLOCK POWER PLANT (M548A3)	0133 00
REPLACE AIR BOX DRAIN AND CRANKCASE BREATHER COLLECTOR CAN	0134 00
REPLACE AIR BOX DRAIN TUBES (M548A1)	013500
REPLACE AIR BOX DRAIN CHECK VALVE AND TUBES (M548A3)	0136 00
REPLACE ENGINE CRANKCASE BREATHER HOSE	0137 00
REPLACE ENGINE OIL GAUGE ROD AND TUBE (M548A1)	0138 00
REPLACE ENGINE OIL GAUGE ROD AND TUBE (M548A3)	0139 00
REPLACE ENGINE OIL FILLER CAP AND TUBE	0140 00
REPLACE ENGINE OIL FILTER HOSES (M548A1)	0141 00
REPLACE ENGINE OIL FILTER ELEMENT HOSES AND FITTINGS (M548A3)	0142 00
REPLACE ENGINE OIL FILTER ELEMENT AND PARTS (M548A1)	0143 00
REPLACE ENGINE OIL FILTER ELEMENT AND COVER (M548A3)	0144 00
REPLACE ENGINE OIL FILTER ASSEMBLY (M548A1)	0145 00
REPLACE ENGINE OIL FILTER ASSEMBLY (M548A3)	0146 00

# **REMOVE/INSTALL POWER PLANT (M548A1)**

#### THIS WORK PACKAGE COVERS:


Removal (page 0130 00-2). Inspection-Acceptance and Rejection Criteria (page 0130 00-14). Installation (page 0130 00-14).

# **INITIAL SETUP:**


Maintenance Level	Equipment Condition
Unit	Engine stopped (see your -10)
Tools and Special ToolsGeneral Mechanic's Tool Kit (WP 0541 00, Item 57)Beam Type Sling (WP 0541 00, Item 45)Socket Wrench Set (WP 0541 00, Item 64)Socket Wrench Set (WP 0541 00, Item 65)Torque Wrench (WP 0541 00, Item 71)Torque Wrench (WP 0541 00, Item 72)Lifting device with rated lift capacity of at least 2500 lb(1135 kg)	<ul> <li>Carrier blocked (see your -10)</li> <li>Both battery negative leads disconnected (WP 0292 00)</li> <li>Neutral safety switch disconnected (WP 0308 00)</li> <li>Machine gun mount kit removed, if equipped with machine gun mount kit (WP 0513 00), (WP 0514 00), and (WP 0515 00)</li> <li>Fabric and/or fiberglass cab covers and frame removed (WP 0418 00) and (WP 0456 00)</li> <li>Top access cover and grilles removed (WP 0390 00)</li> </ul>
Materials/Parts         Antifreeze (WP 0542 00, Item 4)         Engine lubricating oil (WP 0542 00, Item 13)         GAA grease (WP 0542 00, Item 14)         Sealing compound (WP 0542 00, Item 37)         Gasket         Lock nut (2)         Suitable container         Washer (2)         Personnel Required         Unit mechanic         Helper (H)	<ul> <li>Bulkhead protector removed, if equipped with material handling kit (WP 0487 00)</li> <li>Power plant rear access door removed (see your -10)</li> <li>Cab personnel seats removed (WP 0398 00)</li> <li>Cab floor plates removed (WP 0394 00)</li> <li>Hull bottom access cover removed (WP 0383 00)</li> <li>Air cleaner container and element removed (WP 0152 00)</li> <li>Air cleaner hose disconnected from engine air intake (WP 0153 00)</li> <li>Air cleaner filter indicator removed (WP 0154 00)</li> <li>Air pump hose disconnected (WP 0191 00)</li> </ul>
References	Transverse beam removed (WP 0384 00)
See your -10	Cooling system drained (WP 0213 00)

#### REMOVAL

- 1. Loosen two clamps (4) that secure air cleaner hose (5) to air intake (6) and air cleaner head (7). Remove hose.
- 2. Drain oil from engine, transmission and transfer gearcase, if necessary (WP 0128 00).




3. Disconnect differential oil hoses at quick-disconnect coupling (1) and at right angle gearbox (2).




#### NOTE

#### Tag and identify electrical connectors and cables for installation.


- 4. Disconnect power plant bulkhead connectors.
  - a. Disconnect regulator-to-bulkhead cable connector (3) from bulkhead connector (4).
  - b. Disconnect starter-to-bulkhead cable connector (5) from bulkhead connector (6).
  - c. Disconnect power plant wiring harness connector (7) from bulkhead connector (8).




- 5. Disconnect differential oil high temperature switch circuit 328 lead (1) at connector (2).
- 6. Remove vehicle compartment heater duct (WP 0452 00), (WP 0453 00), or (WP 0454 00).




- 7. Remove screw (3) and nut (4) that secure accelerator pedal link (5) to inner cross shaft lever (6).
- 8. Remove screw (7) and nut (8) that secure gear selector link (9) at outer cross shaft lever (10).




- 9. Disconnect winch propeller shaft from winch power takeoff.
  - a. Remove four nuts (1) and lock washers (2) that secure two U-bolts (3) and universal joint (4) to power takeoff yoke (5).
  - b. Remove propeller shaft (6) and universal joint (4) from power takeoff yoke (5) on power takeoff (7). Loosen setscrew (8) if needed.




- 10. Disconnect winch power takeoff control cable from winch power takeoff.
  - a. Loosen setscrew (9) that secures control cable (10) to actuating lever (11).
  - b. Remove two nuts (12), screw (13), and clamp (14) that secure control cable (10) to control bracket (15).
  - c. Remove control cable (10) from power takeoff (7).




- 11. Remove transmission-to-differential propeller shaft (WP 0332 00).
- 12. If carrier is equipped with engine coolant heater kit, disconnect coolant hoses.
  - a. Unscrew heater-to-engine coolant hose (1) from nipple (2) at engine coolant heater (3).
  - b. Unscrew pump-to-engine outlet hose (4) from nipple (5) at engine outlet shutoff valve (6).



- 13. Disconnect radiator-to-thermostat housing coolant vent lines at thermostat housing.
  - a. Loosen two clamps (1) that secure coolant vent line (2) and coolant vent line (3) at thermostat housing (4) and deaeration elbow (5). Remove vent lines.
- 14. Remove radiator-to-oil cooler tube and radiator-to-thermostat housing coolant tube.
  - a. Loosen two hose clamps (6) that secure radiator-to-oil cooler tube (7) and radiator-to-thermostat housing tube (8) to two hoses (9).
  - b. Remove four screws (10), washers (11), and two gaskets (12) that secure radiator-to-oil cooler tube (7) to oil cooler (13) and radiator-to-thermostat housing tube (8) to thermostat housing (14). Discard gaskets.



- 15. Remove screw (1) and washer (2) that secure starter ground lead (3) to hull. Remove starter ground wire.
- 16. Remove two screws (4) and washers (5) that secure front engine mount (6) to hull. Discard washers.




t

ł


I

I


- 17. Remove fuel cutoff cable from power plant.
  - a. Loosen two setscrews (1) that secure control cable (2) in two collars (3) and stop lever (4).
  - b. Remove two screws (5) and lock nuts (6) that secure control cable (2) in clamp (7). Remove cable from power plant. Discard lock nuts.



- 18. Remove rear fan drive belts from jackshaft pulley.
  - a. Loosen belt tension on belt adjuster (8).
  - b. Remove two rear fan drive belts (9) from jackshaft pulley (10).




- 19. Remove engine exhaust pipe from muffler and left crossover pipe.
  - a. Remove clamp (1) that secures exhaust pipe (2) to muffler (3).
  - b. Remove exhaust pipe (2) from muffler (3) and left crossover pipe (4). If needed, loosen clamp (5) on left crossover pipe and clamp (6) on right crossover pipe (7) to remove exhaust pipe.
- 20. Disconnect tachometer drive cable (8) from tachometer drive adapter (9) at engine flywheel housing (10).



# NOTE

# Tag and cover all fuel lines.

21. Disconnect two fuel lines at quick-disconnect couplings (1) at rear of power plant.



# NOTE


Have helper assist with Steps 22 - 25.

22. Attach beam type sling.





Make sure lifting device has rated lift capacity of at least 2500 lb (1135 kg) to safely raise the power plant. Keep all parts of body from under the suspended load.

23. Use lifting device and beam type sling (2) to lift power plant slightly to relieve pressure.



- 24. Remove transfer gearcase mounting clamps.
  - a. Remove mounting clamp (3) that secures left transfer gearcase mount (4) to hull.
  - b. Remove mounting clamp (5) that secures right transfer gearcase mount (6) to hull.
- 25. Carefully raise power plant out of power plant compartment.





#### INSPECTION-ACCEPTANCE AND REJECTION CRITERIA

# CAUTION

Steam clean power plant only. Do not use cleaner or solvent which could damage rubber and plastic.


1. It tactical situation permits, steam clean power plant compartment. Make sure it is ready to receive power plant.

#### INSTALLATION



Make sure lifting device has rated lift capacity of at least 2500 lb (1135 kg) to safely raise the power plant. Keep all parts of body from under the suspended load.


1. (H) Attach beam type sling (1) to lifting device. Slowly raise power plant and lower it into power plant compartment. Keep slight tension on sling.




#### NOTE

#### Install mounting clamps so nuts are on inboard and forward sides of mounts.


- 2. Install transfer gearcase mounting clamps.
  - a. Install mounting clamp (2) to secure right transfer gearcase mount (3) to hull.
  - b. Install mounting clamp (4) to secure left transfer gearcase mount (5) to hull.




- 3. Install two screws (6) with two new washers (7) in front engine mount (8). Tighten screws finger tight.
- 4. (H) Lower beam type sling (1) and detach from power plant.
- 5. Tighten two screws (6) securing front engine mount (8) to hull to 120-130 lb-ft (163-176 N•m) torque.



6.




7. Connect tachometer drive cable (2) to tachometer drive adapter (3) at engine flywheel housing (4).




# NOTE

Make sure ball sockets of exhaust pipe (5) are lined up with left crossover pipe (6) before you tighten clamps. This is to keep ball sockets from leaking exhaust gases.


- 8. Install engine exhaust pipe on muffler and left crossover pipe.
  - a. Install exhaust pipe (5) on left crossover pipe (6). Turn exhaust pipe install on ball joint to line up with muffler (7). Install clamp (8).
  - b. Tighten nut on clamp (8) to 200-220 lb-in (23-25 N•m) torque.
  - c. If needed, tighten nuts on clamp (9) and clamp (10) to 200-220 lb-in (23-25 (N•m) torque to secure exhaust pipe (5) to right crossover pipe (6).



- 9. Install rear fan drive belts on jackshaft pulley.
  - a. Install two rear fan drive belts (11) on jackshaft pulley (12).
  - b. Adjust belt tension by turning belt adjuster (13) (WP 0226 00).




- 10. Install fuel cutoff cable on power plant (WP 0205 00).
- 11. Adjust fuel cutoff hand control (WP 0195 00).
- 12. Install washer (1) and screw (2) to secure starter ground lead (3) to hull.




13. Install radiator-to-oil cooler tube and radiator-to-thermostat housing coolant tube (WP 0219 00).

- 14. Connect radiator-to-thermostat housing coolant vent lines at thermostat housing.
  - a. Install coolant vent line (4) on thermostat housing (5). Install coolant vent line (6) on deaeration elbow (7). Secure both lines with two clamps (8).




M548A1


- 15. If carrier is equipped with engine coolant heater kit, connect coolant hoses.
  - a. Connect pump-to-engine outlet hose (9) to nipple (10) at engine outlet shutoff valve (11).
  - b. Connect heater-to-engine coolant hose (12) to nipple (13) at engine coolant heater (14).



- 16. Install transmission-to-differential propeller shaft (WP 0332 00).
- 17. Install winch power takeoff control cable to winch power takeoff (WP 0414 00).
- 18. Adjust winch control cable (WP 0414 00).
- 19. Connect winch propeller shaft to winch power takeoff.
  - a. Install four lock washers (1) and nuts (2) to secure two U-bolts (3) and universal joint (4) to power takeoff yoke (5). Tighten nuts to 169-200 lb-in (19-23 N•m) torque.
  - b. Install propeller shaft (6) and universal joint (4) on power takeoff yoke (5) on power takeoff (7).
  - c. If needed, tighten setscrew (8) to secure power takeoff yoke (5) to power takeoff (7).




- 20. Install screw (3) and nut (4) to secure gear selector link (5) to outer cross shaft lever (6).
- 21. Install screw (7) and nut (8) to secure accelerator pedal link (9) to inner cross shaft lever (10).



# CAUTION

Make sure differential oil hose quick disconnect coupling (1) is connected properly and secured. Connect coupling assemblies by aligning pin on body with groove on collar, pull back collar, and join two halves of quick disconnect. Release and rotate collar so pin does not align with groove.


- 22. Connect differential oil hoses to quick disconnect coupling (1) on differential and to right angle gear box (2).
- 23. Connect differential oil high temperature switch circuit 328 lead (3) to connector (4).



### NOTE

#### Use previously placed tags to identify cables and connectors.

- 24. Connect power plant bulkhead cable connector to bulkhead connectors.
  - a. Connect regulator-to-bulkhead cable connector (1) to bulkhead connector (2).
  - b. Connect starter-to-bulkhead cable connector (3) to bulkhead connector (4).
  - c. Connect power plant wiring harness connector (5) to bulkhead connector (6).



- 25. Close all cooling system drain valves. Fill cooling system (WP 0212 00).
- 26. Install all oil drain plugs (engine, transmission, and transfer gearcase) and fill engine transmission and transfer gearbox with oil (WP 0128 00).
- 27. Install air cleaner hose (WP 0153 00).

# WARNING



# Keep your hands, arms, and clothing away from rotating belts, pulleys, and shafts. Look, do not touch.

- 28. Start engine (see your -10).
- 29. Check fan, generator, and air compressor drive belts for proper operation. Adjust drive belts if necessary (WP 0226 00) and (WP 0240 00).
- 30. Check power plant operation for fuel, oil, and coolant leaks and loose parts.
- 31. Stop engine (see your -10).

- 1. Install transverse beam (WP 0384 00).
- 2. Install cab floor plates, door, and seat support (WP 0394 00).
- 3. Install cab personnel seats (WP 0398 00).
- 4. Connect air pump hose at pump (WP 0191 00).
- 5. Connect air cleaner indicator hose to engine air intake (WP 0153 00).
- 6. Install air cleaner container and element (WP 0152 00).
- 7. Install hull bottom access cover (WP 0383 00).
- 8. Lower center seat (see your -10).
- 9. Install power plant rear access door (see your -10).
- 10. Install bulkhead protector, if equipped with material handling kit (WP 0487 00).
- 11. Install top access cover and grilles (WP 0390 00)
- 12. Install fabric and/or fiberglass cab covers and frame (WP 0418 00) or (WP 0456 00).
- 13. Install machine gun mount kit, if required (WP 0513 00), (WP 0514 00), or (WP 0515 00).
- 14. Connect neutral safety switch (WP 0308 00).
- 15. Test neutral safety switch and adjust if necessary (WP 0308 00).
- 16. Connect battery negative lead (WP 0292 00).
- 17. Road test carrier (WP 0128 00).

#### **END OF TASK**

# **REMOVE/INSTALL POWER PLANT (M548A3)**

# THIS WORK PACKAGE COVERS:


Removal (page 0131 00-1). Installation (page 0131 00-9).

# **INITIAL SETUP:**


Maintenance Level	References
Unit	See your -10
Tools and Special Tools	See your PMCS
General Mechanic's Tool Kit (WP 0541 00, Item 57) Engine and Transmission Sling (WP 0541 00, Item 47) Torque Wrench (WP 0541 00, Item 68)	Equipment Condition
Lifting device with rated lift capacity of at least 3000 lb	Engine stopped (see your -10)
(1362 kg)	Carrier blocked (see your -10)
Materials/Parts	Both battery negative leads disconnected (WP 0292 00)
Antifreeze (WP 0542 00, Item 4)	Cab cover and frame removed (see your -10)
Cotter pin (2) Lock nut (2)	Rear compartment cover folded back or rear compartment cover and bows removed (WP 0417 00)
Lock nut (2)	Power plant rear access panel removed (see your -10)
Lock nut Lock nut (4) Lock washer	Personnel seat and seat support removed (WP 0395 00), (WP 0398 00)
Lock washer (2)	Transverse beam removed (WP 0385 00)
Suitable containers	Two center floor plates removed (WP 0395 00)
Personnel Required Unit mechanic	Support from seat support and floor support removed (WP 0395 00)
Helper (H)	Muffler removed (WP 0207 00)

#### REMOVAL


1. Loosen two clamps (1) and remove air filter-to-turbo hose (2), turbocharger outlet (3), and air cleaner outlet (4).




2. Disconnect engine fuel supply hose (1) and fuel return hose (2) from two quick disconnect couplings (3).




3. Remove screw (4), lock washer (5), ground lead (6), and four power plant wiring harnesses (7) from battery compartment bulkhead. Discard lock washer.




4. Remove lock nut (8), washer (9), screw (10), and throttle arm rod bearing (11) from governor lever arm (12). Discard lock nut.



- 5. Loosen setscrew (13) and remove collar (14) from fuel cutoff cable (15).
- 6. Loosen clamp setscrew (16) and pull fuel cutoff cable (15) through guide clamp (17).




- 7. Remove screw (18), cable clamp (19), washer (20), and nut (21) from tow start cable (22).
- 8. Loosen setscrew (23) and remove collar (24) and tow start cable (22) from lever arm (25).




0131 00


- 9. Remove two lock nuts (1), washers (2), and screws (3) and separate connecting link (4) and connecting link (5). Discard lock nuts.
- 10. Remove lock nut (6), washer (7), and connecting link (5) from lever (8). Discard lock nut.




11. Loosen tachometer cable nut (9) at engine right angle adapter (10) and remove tachometer cable (11).



- 12. Remove cotter pin (12), washer (13), pin (14) and rod end (15) from connecting link (16). Discard cotter pin.
- 13. Remove lock nut (17), washer (18), link (16) and spacer (19) from shaft (20). Discard lock nut.
- 14. Remove screw (21), washer (22), and lock washer (23) from right brake arm (24). Discard lock washer.
- 15. Remove screw (25), washer (26), and lock washer (27) from left brake arm (28). Discard lock washer.
- 16. Remove brake linkage assembly from carrier.




- 17. Remove cotter pin (1), washer (2), pin (3), and rod bearing (4) from link (5). Discard cotter pin.
- 18. Remove two lock nuts (6), four washers (7), and two screws (8) from bearing (9). Discard lock nuts.
- 19. Remove two lock nuts (10), four washers (11) and two screws (12) from bearing (13). Discard lock nuts.
- 20. Remove shaft (14) with link (5), bearing (9), and bearing (13) from carrier.
- 21. Separate key (15), bearing (13), and spacer (16) from shaft (14).




- 22. Remove two propeller shafts (WP 0335 00).
- 23. Remove hull bottom access cover (WP 0383 00).
- 24. Drain cooling system (WP 0213 00).


25. Loosen three clamps (17) and remove three coolant hoses (18) from radiator auxiliary tank (19).




26. Remove four clamps (20) and slide two coolant hoses (21) back from radiator (22).



- 27. Remove cooling fan drive belt (WP 0227 00).
- 28. Remove two couplings (23) from rear engine mounts (24).



29. Remove four screws (1), washers (2), and two trunnion caps (3) from hull.



Damaged lifting slings can fall with load. Personnel can be injured or killed. Inspect all slings. Do not use damaged slings.

30. Inspect sling for damage (WP 0443 00).



Lifting sling may slip and allow power plant to drop. Personnel may be injured. Be sure sling is firmly attached and maintains engine support.

# CAUTION

Visually monitor power plant clearance at rear bulkhead to avoid damage to components.

- 31. Attach sling to power plant lifting points, making sure shackle is in hole stamped B.
- 32. Carefully remove power plant from carrier with hoist and place on blocks.

#### 0131 00

#### INSTALLATION



Damaged lifting slings can fall with load. Personnel can be injured or killed. Inspect all slings. Do not use damaged slings.

1. Inspect sling for damage (WP 0443 00).

# CAUTION

Trunnion cap and spacer can get damaged. Make sure trunnion and spacer are positioned and installed correctly before you install mounting bolts.

# NOTE

Make certain transmission aligning ring is installed in groove in lower half of right transmission mount or transmission trunnion.


2. Attach sling to power plant lifting points, making sure shackle is in hole stamped B.




Lifting sling may slip and allow power plant to drop. Personnel may be injured. Be sure sling is firmly attached and maintains engine support.

3. Slowly lift and position power plant on its mounts inside carrier.

4. Install two trunnion caps (3), four washers (2) and screws (1) on hull. Tighten screws to 86-94 ft-lb (117-127 N•m) torque.




5. Install two couplings (1) on rear engine mounts (2).




- 6. Remove lifting sling from power plant.
- 7. Install cooling fan drive belt (WP 0227 00)

8. Slide two coolant hoses (3) and four clamps (4) on radiator (5). Tighten clamps.




9. Install three clamps (6) and coolant hoses (7) on radiator auxiliary tank (8). Tighten clamps.




- 10. Service cooling system (WP 0214 00).
- 11. Install two propeller shafts (WP 0335 00).

- 13. Install shaft (11) with link (12), bearing (9), and bearing (13) in carrier.
- 14. Install two new lock nuts (14), four washers (15), two screws (16) and bearing (9) on bulkhead.
- 15. Install two new lock nuts (17), four washers (18), two screws (19) and bearing (13) on bulkhead.
- 16. Install rod bearing (20), pin (21), washer (22) and new cotter pin (23) on link (12).
- 17. Install key (24), spacer, (25), link (26), washer (27) and new lock nut (28) on shaft (11).




- 18. Position brake linkage assembly between brake arms on transmission and shaft (1).
- 19. Install screw (2), washer (3), new lock washer (4) and right brake arm (5) on transmission.
- 20. Install screw (6), washer (7), new lock washer (8) and left brake arm (9) on transmission.
- 21. Install rod end (10), pin (11), washer (12) and new cotter pin (13) on connecting link (14).




0131 00-12


22. Install tachometer cable (15) on engine right angle adapter (16) and secure with tachometer cable nut (17).




- 23. Install connecting link (18), washer (19), and new lock nut (20) on lever (21).
- 24. Join connecting link (18) and connecting link (22) and install two screws (23), washers (24) and new lock nuts (25).




26. Install cable clamp (29), screw (30), washer (31) and nut (32) on tow start cable (26).




- 27. Push fuel cutoff cable (1) through guide clamp (2) and install in fuel cutoff lever (3).
- 28. Install collar (4) on fuel cutoff cable (1) and tighten setscrew (5).
- 29. Tighten screw (6) on guide clamp (2).




30. Install throttle arm rod bearing (7), washer (8), screw (9) and new lock nut (10) on governor lever arm (11).



31. Install screw (12), new lock washer (13), ground lead (14), and four power plant wiring harnesses (15) on battery compartment bulkhead.




32. Connect engine fuel supply hose (16) and fuel return hose (17) to two quick disconnect couplings (18).



#### 0131 00-15

33. Install two clamps (19) and air filter-to-turbo hose (20) on turbocharger outlet (21) and air cleaner outlet (22). Tighten clamps.



# FOLLOW-THROUGH STEPS

- 1. Install hull bottom access cover (WP 0383 00).
- 2. Install muffler (WP 0207 00).
- 3. Install support from seat support and floor support (WP 0395 00).
- 4. Install two center floor plates (WP 0395 00).
- 5. Install transverse beam (WP 0385 00).
- 6. Install personnel seat and seat support (WP 0395 00), (WP 0398 00).
- 7. Unfold rear compartment cover forward or install rear compartment cover and bows (WP 0417 00).
- 8. Install cab cover and frame (see your -10)
- 9. Adjust throttle valve modulator (WP 0204 00).
- 10. Check engine and transmission fluid levels (see your PMCS).
- 11. Connect both battery negative leads (WP 0292 00)
- 12. Start engine (see your -10). Check for leaks.
- 13. Stop engine (see your -10).
- 14. Install power plant rear access panel (see your -10).
- **END OF TASK**

# **BLOCK POWER PLANT (M548A1)**

# THIS WORK PACKAGE COVERS:

Block (page 0132 00-1).

#### **INITIAL SETUP:**

Maintenance Level

Unit

Equipment Condition

Power plant removed from carrier (WP 0130 00)

Materials/Parts

Wood block (as necessary)

Personnel Required

Unit Mechanic Helper (H)

JACKING

**BLOCK POWER PLANT** 



WARNING

You could get hurt if power plant is not blocked to prevent sudden movement. Block power plant as shown before you attempt any disassembly.




Hanging loads could kill or injure you. Keep away from hanging loads and overhead equipment. Keep hands out of engine compartment while power unit is being removed or installed.

1. Use a lifting device of at least 2,500 lb (1,135 kg) capacity and sling to lift power plant. Have helper assist.


# BLOCK POWER PLANT (M548A1) — Continued

- 2. On level ground place two 4 x 6 x 18 inch (10 x 15 x 46 cm) blocks (1) under front of engine. Place blocks parallel to each other with 6 inch (15 cm) side down. Blocks should be about 18 inches (46 cm) apart from outside edges.
- 3. Stack two 4 x 6 x 18 inch (10 x 15 x 46 cm) blocks (2) on top of each other. Place blocks on top of blocks (1) at a 90 degree angle. Blocks will be about 10 1/2 inches (24 cm) high.



# BLOCK POWER PLANT (M548A1) — Continued

- 5. Stack a 4 x 6 x 18 inch (10 x 15 x 46 cm) block (4) and a 2 x 4 x 18 inch (5 x 10 x 46 cm) block (5) under rear of engine. Blocks should be about 7 inches (16 cm) high.
- 6. Lower power plant slowly down onto blocks. Check that power plant is firmly supported by the blocks.
- 7. Cover air inlet housing (6). Use wiping rag.



# FOLLOW-THROUGH STEPS

1. Install power plant in carrier (WP 0130 00).

# **BLOCK POWER PLANT (M548A3)**

# THIS WORK PACKAGE COVERS:

Block (page 0133 00-1).

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools


General Mechanic's Tool Kit (WP 0541 00, Item 57) Engine and Transmission Sling (WP 0541 00, Item 47) Lifting device with rated lift capacity of at least 3000 lb (1362 kg) capacity

#### Materials/Parts

All blocks are made from surfaced dimensioned lumber. Dimensions are in inches with metric equivalents. Lumber 4 x 6 x 40 inch (10 x 15 x 102 cm) Lumber 4 x 6 x 20 inch (10 x 15 x 51 cm)

JACKING

#### **BLOCK POWER PLANT**



Helper (H)

Equipment Condition Power plant removed (WP 0131 00)




WARNING

Blocking power plant on unlevel, soft ground can cause power plant to sink and tip over. Personnel can be injured and power plant can be damaged. Make sure to block power plant on flat, hard ground.

1. Use a lifting device of at least 3000 lb (1362 kg) capacity and engine and transmission sling to lift power plant.

# BLOCK POWER PLANT (M548A3) — Continued

- 2. On level ground, place a 4 x 6 x 40 inch (10 x 15 x 102 cm) block (1) under motor mounts of engine (2).
- 3. On level ground, place two 4 x 6 x 20 inch (10 x 15 x 52 cm) blocks (3) under transmission (4).



- 4. Lower power plant down slowly onto blocks. Have helper assist.
- 5. Check that power plant is firmly supported by blocks.

# REPLACE AIR BOX DRAIN AND CRANKCASE BREATHER COLLECTOR CAN

#### 0134 00

#### THIS WORK PACKAGE COVERS:

Removal (page 0134 00-1). Installation (page 0134 00-1).

# **INITIAL SETUP:**

Maintenance Level Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57)

#### Personnel Required

Unit Mechanic

References

See your -10


**Equipment Condition** 

Engine stopped (see your -10) Carrier blocked (see your -10) Battery ground lead(s) disconnected (WP 0292 00) Hull bottom access cover removed (WP 0383 00)

#### REMOVAL

1. Turn collector can (1) to the left.

2. Remove collector can from mounting bracket (2).



#### INSTALLATION

- 1. Place collector can (1) on mounting bracket (2).
- 2. Secure collector can (1) by turning it to the right.

# REPLACE AIR BOX DRAIN AND CRANKCASE BREATHER COLLECTOR CAN — Continued

# **FOLLOW-THROUGH STEPS**

- 1. Connect battery negative lead(s) (WP 0292 00).
- 2. Start engine (see your -10).
- 3. Check air box drain and crankcase breather collector can for proper operation.
- 4. Stop engine (see your -10).
- 5. Install hull bottom access cover (WP 0383 00).

# **REPLACE AIR BOX DRAIN TUBES (M548A1)**

# THIS WORK PACKAGE COVERS:

Removal (page 0135 00-1). Installation (page 0135 00-1).

#### INITIAL SETUP:

Maintenance Level Unit

References

See your -10

 Tools and Special Tools

 General Mechanic's Tool Kit (WP 0541 00, Item 57)

 Personnel Required


 Unit Mechanic

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Battery ground lead disconnected (WP 0292 00) Hull bottom access cover removed (WP 0383 00)

#### REMOVAL

- 1. Loosen two nuts (1) that secure two drain tubes (2) to each side of engine.
- 2. Loosen three clamps (3) that secure hose (4) between right drain tube (2) and collector can (5).
- 3. Remove two drain tubes (2) from air box. Remove hose (4) from crankcase breather collector can (5) through bracket (6).



# INSTALLATION

- 1. Place drain tube (2), with hose (4), on each side of engine. Secure with three clamps (3) and two nuts (1).
- 2. Place ends of drain hose (4) through collector can (5) and bracket (6) into collector can.

# REPLACE AIR BOX DRAIN TUBES (M548A1) - Continued

# **FOLLOW-THROUGH STEPS**

- 1. Connect battery negative lead (WP 0292 00).
- 2. Start engine (see your -10).
- 3. Check air box drain tubes for proper operation.
- 4. Stop engine (see your -10).
- 5. Install hull bottom access cover (WP 0383 00).

# **REPLACE AIR BOX DRAIN CHECK VALVE AND TUBES (M548A3)**

# THIS WORK PACKAGE COVERS:

Removal (page 0136 00-1). Installation (page 0136 00-3).


# **INITIAL SETUP:**

Maintenance Level	References
Unit	See your -10
Tools and Special Tools	Equipment Condition
General Mechanic's Tool Kit (WP 0541 00, Item 57)	Engine stopped (see your -10)
Materials/Parts	Carrier blocked (see your -10)
Lock washer	Both battery negative leads disconnected (WP 0292 00) Hull bottom access cover removed (WP 0383 00)
Personnel Required	Air cleaner assembly removed (WP 0159 00)
Unit Mechanic	Center seat raised (see your -10)

#### REMOVAL

Left side

- 1. Remove adapter (1) and two washers (2) from engine.
- 2. Remove bolt (3), lock washer (4), and spacer (5) from engine. Discard lock washer.
- 3. Remove tube assembly (6) from check valve (7).
- 4. Remove check valve (7) from elbow (8).




# REPLACE AIR BOX DRAIN CHECK VALVE AND TUBES (M548A3) - Continued

0136 00

Right side

- 5. Remove adapter (9) and two washers (10) from engine.
- 6. Remove tube assembly (11) from check valve (12).
- 7. Remove check valve (12) and connector (13) from tube assembly (14).
- 8. Remove check valve (12) from connector (13).




## REPLACE AIR BOX DRAIN CHECK VALVE AND TUBES (M548A3) - Continued

#### INSTALLATION

# Left side


- 1. Install check valve (1) on elbow (2).
- 2. Install tube assembly (3) on check valve (1).
- 3. Install tube assembly (3) with spacer (4), new lock washer (5), and bolt (6) on engine.
- 4. Install tube assembly (3) with two washers (7) and adapter (8) on engine.



# REPLACE AIR BOX DRAIN CHECK VALVE AND TUBES (M548A3) - Continued

Right side

- 5. Install connector (9) on check valve (10).
- 6. Install connector (9) and check valve (10) on tube assembly (11).
- 7. Install tube assembly (12) on check valve (10).
- 8. Install tube assembly (12) with two washers (13) and adapter (14) on engine.



# **FOLLOW-THROUGH STEPS**

- 1. Install air cleaner assembly (WP 0159 00).
- 2. Install hull bottom access cover (WP 0383 00).
- 3. Connect both battery negative leads (WP 0292 00).
- 4. Lower center seat (see your -10).

# **REPLACE ENGINE CRANKCASE BREATHER HOSE**

## THIS WORK PACKAGE COVERS:

Removal (page 0137 00-1). Installation (page 0137 00-2).

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57)

#### Personnel Required


Unit Mechanic

#### References

See your -10

#### REMOVAL

- 1. Remove hose clamp (1) that secures breather hose (2) to valve cover ventilation outlet (3).
- 2. Remove two screws (4), washers (5), and clamps (6) from bracket (7).
- 3. Remove other end of breather hose (2) from collector can mount (8).




Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Battery ground lead(s) disconnected (WP 0292 00) Top access cover and grilles removed (WP 0390 00) Hull bottom access cover removed (WP 0383 00)

# **REPLACE ENGINE CRANKCASE BREATHER HOSE — Continued**

#### INSTALLATION

- 1. Place breather hose (2) on valve cover ventilation outlet (3).
- 2. Install other end of breather hose through collector can mount (8).
- 3. Place breather hose on bracket (7). Secure hose to bracket with two screws (4), washers (5), and clamps (6).



#### **FOLLOW-THROUGH STEPS**

- 1. Connect battery negative lead(s) (WP 0292 00).
- 2. Start engine (see your -10).
- 3. Check crankcase breather hose for proper operation.
- 4. Stop engine (see your -10).
- 5. Install top access cover and grilles (WP 0390 00).
- 6. Install hull bottom access cover (WP 0383 00).

# **REPLACE ENGINE OIL GAUGE ROD AND TUBE (M548A1)**

# THIS WORK PACKAGE COVERS:

Removal (page 0138 00-1). Installation (page 0138 00-2).

# **INITIAL SETUP:**


See your -10
Equipment Condition
Engine stopped (see your -10)
Carrier blocked (see your -10)
Center seat raised (see your -10)

#### REMOVAL

1. Turn gauge rod handle (1) to the left to release. Lift gauge rod from tube (2).

2. Remove screw (3) that secures clamp (4) to coolant pump (5). Remove clamp.

3. Unscrew nut (6) that secures tube to engine. Remove tube.




# 0138 00

# REPLACE ENGINE OIL GAUGE ROD AND TUBE (M548A1) - Continued

# INSTALLATION

- 1. Place tube (2) on engine. Secure with nut (6).
- 2. Place clamp (4) on tube on coolant pump (5). Secure with screw (3).
- 3. Insert gauge rod (1) in tube and turn gauge rod handle to the right.



#### FOLLOW-THROUGH STEPS

1. Lower center seat (see your -10).

# **REPLACE ENGINE OIL GAUGE ROD AND TUBE (M548A3)**

# THIS WORK PACKAGE COVERS:

Removal (page 0139 00-2). Installation (page 0139 00-3).


# **INITIAL SETUP:**

Maintenance Level	References
Unit	See your -10
Tools and Special Tools	
General Mechanic's Tool Kit (WP 0541 00, Item 57)	Equipment Condition
Materials/Parts Adhesive (WP 0542 00, Item 1) Self-locking screw	Engine stopped (see your -10) Carrier blocked (see your -10)
Personnel Required	Both battery negative leads disconnected (WP 0292 00)
Unit Mechanic	Center seat raised (see your -10)

# REPLACE ENGINE OIL GAUGE ROD AND TUBE (M548A3) - Continued

# REMOVAL


- 1. Turn gauge rod (1) counterclockwise and remove from tube (2).
- 2. Remove self-locking screw (3), washer (4), and clamp (5) from engine. Remove clamp (5) from tube (2). Discard self-locking screw.
- 3. Loosen nut (6) and remove tube (2) from adapter (7).
- 4. Remove adapter (7) from oil pan.



## REPLACE ENGINE OIL GAUGE ROD AND TUBE (M548A3) - Continued

#### INSTALLATION

- 1. Apply a thin coat of adhesive to external threads of adapter (7).
- 2. Install adapter (7) in oil pan.
- 3. Install tube (2) on adapter (7) and tighten nut (6).
- 4. Install clamp (5) on tube (2). Secure clamp and tube to engine with new self-locking screw (3) and washer (4).
- 5. Install gauge rod (1) in tube (2) and turn clockwise to tighten.



#### **FOLLOW-THROUGH STEPS**

- 1. Connect both battery negative leads (WP 0292 00).
- 2. Lower center seat (see your -10).

# **REPLACE ENGINE OIL FILLER CAP AND TUBE**

# THIS WORK PACKAGE COVERS:

Removal (page 0140 00-2). Installation (page 0140 00-5).

# **INITIAL SETUP:**

Maintenance Level	References
Unit	See your -10
Tools and Special Tools	
General Mechanic's Tool Kit (WP 0541 00, Item 57)	Equipment Condition
Materials/Parts Gasket Screws (2) Washers (2)	Engine stopped (see your -10) Carrier blocked (see your -10) Center seat raised (see your -10)
Personnel Required Unit Mechanic	Power plant rear access door/panel removed (see your -10)


# REMOVAL

- 1. Turn cap (1) left to release. Lift cap from filler tube (2).
- 2. Remove screw (3), nut (4), and cap retaining chain (5) from filler tube (2). Remove cap (1) with chain.

# NOTE

#### If your carrier has an air compressor, do Step 3 and Step 4.


- 3. Remove clamp (6). Separate compressor outlet hose (7) from adapter. Remove adapter from filler tube (2).
- 4. Remove clamp (8). Separate coolant heater outlet hose (9) from filler tube (2).




# NOTE

#### If your carrier does not have an air compressor do Step 5.

- 5. Remove pipe plug (10) from filler tube (2).
- 6. Remove screw (11), nut (12), and clamp (13) from front bracket (14).
- 7. Remove two screws (15), nuts (16), and front bracket (14) from engine.




- 8. Remove screw (1), nut (2), and clamp (3) from rear bracket (4).
- 9. Remove two screws (5), washers (6), and rear bracket (4) from engine. Discard screws and washers.
- 10. Remove two screws (7) and clamps (8) from hose (9). Remove filler tube (10) from hose (9).
- 11. Remove three screws (11), and washers (12), from elbow (13), and gasket (14) from engine. Separate elbow from gasket. Discard gasket.



#### INSTALLATION

- 1. Install rear bracket (1) on engine with two new screws (2) and washers (3).
- 2. Install front bracket (4) on engine with two screws (5) and nuts (6).
- 3. Install new gasket (7) and elbow (8) on engine with three screws (9) and washers (10).
- 4. Install hose (11) on elbow (8) with clamp (12) and screw (13).
- 5. Install filler tube (14) on hose (11) with clamp (12) and screw (13).
- 6. Secure filler tube (14) to rear bracket (1) with clamp (15), screw (16), and nut (17).
- 7. Secure filler tube (14) to front bracket (4) with clamp (18), screw (19), and nut (20).
- 8. Install caps retaining chain (21) on filler tube (14) with screw (22) and nut (23).
- 9. Place cap (24) on filler tube (14) and turn right to secure.



#### NOTE


#### If your carrier has an air compressor, do Step 10 and Step 11.

- 10. Install compressor outlet hose (25) to filler tube (14) with clamp (26).
- 11. Install coolant heater outlet hose (27) to filler tube (14) with clamp (28).

# NOTE

If your carrier does not have an air compressor, do Step 12.

12. Install pipe plug (29) in filler tube (14).



# **FOLLOW-THROUGH STEPS**

- 1. Lower center seat (see your -10).
- 2. Install power plant rear access door/panel (see your -10).

# **REPLACE ENGINE OIL FILTER HOSES (M548A1)**

#### THIS WORK PACKAGE COVERS:

Removal (page 0141 00-2). Cleaning (page 0141 00-3). Installation (page 0141 00-4).

# **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools

General Mechanic's Tool Kit (WP 0541 00, Item 57)

#### Materials/Parts

Antiseize compound (WP 0542 00, Item 6) Cleaning compound (WP 0542 00, Item 9) Sealing compound (WP 0542 00, Item 37) Engine oil (WP 0128 00) Self-locking nut (2) Suitable container Personnel Required

Unit Mechanic

References See your -10 Standard Operating Procedures

#### **Equipment Condition**


Engine stopped (see your -10) Carrier blocked (see your -10) Battery ground lead disconnected (WP 0292 00) Hull bottom access cover removed (WP 0383 00) Power plant rear access door removed (see your -10)

# 0141 00

# REPLACE ENGINE OIL FILTER HOSES (M548A1) — Continued

# REMOVAL

- 1. Remove screw (1) and nut (2). Remove clamp (3) that secures engine oil filter hose (4) and engine oil filter hose (5) to power plant (6).
- 2. Remove screw (7) and nut (8). Remove two clamps (9) that secure oil filter hose (4) and oil filter hose (5) to power plant (6).
- 3. Remove two screws (10), lock nuts (11), and clamps (12) from oil filter hose (4) and AOAP hose (13). Discard lock nuts.
- 4. Place container under hose (4), hose (5), and hose (13) to catch oil.




#### **REPLACE ENGINE OIL FILTER HOSES (M548A1) — Continued**

# NOTE

#### Dispose of engine oil in accordance with Standard Operating Procedures.

- 5. Disconnect oil filter hose (4) and oil filter hose (5) at engine block (14). Hold hoses down to let oil drain.
- 6. Remove two elbows (15) from engine block (14).
- 7. Disconnect oil filter hose and oil filter hose (5) at oil filter (16). Remove two elbows (17) from oil filter (16).




### CLEANING

- 1. Clean outside threads of tapered and straight pipe fittings with cleaning compound.
- 2. Put sealing compound on outside threads of tapered pipe fittings.
- 3. Put light coat of antiseize compound on outside threads of straight pipe fittings.

### REPLACE ENGINE OIL FILTER HOSES (M548A1) - Continued


### INSTALLATION

- 1. Install two elbows (1) on engine oil filter (2). Connect oil filter hose (3) and oil filter hose (4) to elbows.
- 2. Install two elbows (5) on engine block (6). Connect oil filter hose (3) and oil filter hose (4) to elbows.
- 3. Secure oil filter hoses (3 and 4) to power plant (7) with clamp (8), nut (9), and screw (10).



### REPLACE ENGINE OIL FILTER HOSES (M548A1) — Continued

- 4. Secure hoses (3 and 4) to power plant (7) with two clamps (11), one nut (12), and screw (13).
- 5. Secure AOAP hose (14) to outlet hose (15) with two clamps (16), screws (17), and new lock nuts (18).
- 6. Add engine oil (WP 0128 00).



### **FOLLOW-THROUGH STEPS**

- 1. Connect battery negative lead (WP 0292 00).
- 2. Start engine (see your -10).
- 3. Check engine oil filter hoses for leaks.
- 4. Stop engine (see your -10).
- 5. Install hull bottom access cover (WP 0383 00).
- 6. Install power plant rear access door (see your -10).

# **END OF TASK**

# REPLACE ENGINE OIL FILTER ELEMENT HOSES AND FITTINGS (M548A3)

### THIS WORK PACKAGE COVERS:

Removal (page 0142 00-2). Installation (page 0142 00-3).

#### **INITIAL SETUP:**

Maintenance Level Unit
Tools and Special Tools
General Mechanic's Tool Kit (WP 0541 00, Item 57)
Materials/Parts
Antiseize compound (WP 0542 00, Item 6)
Sealing Compound (WP 0542 00, Item 37)
Suitable container
Strap (2)
Personnel Required
Unit Mechanic

#### References

See your -10 Standard Operating Procedures

#### Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Both battery negative leads disconnected (WP 0292 00) Center seat raised (see your -10) Air cleaner assembly removed (WP 0159 00)

0142 00

0142 00


#### REPLACE ENGINE OIL FILTER ELEMENT HOSES AND FITTINGS (M548A3) - Continued

### REMOVAL

# NOTE

#### Dispose of engine oil in accordance with Standard Operating Procedures.


- 1. Place clean container of at least 1 quart (1 liter) capacity under engine oil cooler. Disconnect inlet hose (1) from adapter (2) and outlet hose (3) from adapter (4) on engine oil cooler.
- 2. Remove adapter (2) and adapter (4) from engine oil cooler.
- 3. Disconnect inlet hose (1) from elbow (5) and outlet hose (3) from elbow (6) on oil filter head (7).
- 4. Remove elbow (5) and elbow (6) from oil filter head (7).
- 5. Remove two straps (8) from hose (1) and hose (3). Discard straps.
- 6. Remove two straps (8) from hose (1) and hose (3). Discard straps.



#### REPLACE ENGINE OIL FILTER ELEMENT HOSES AND FITTINGS (M548A3) — Continued

#### INSTALLATION

- 1. Apply sealing compound to external tapered threads of elbow (1) and elbow (2) and install elbows in oil filter head (3).
- 2. Apply antiseize compound to external threads of adapter (4) and adapter (5) and install adapters in engine oil cooler.
- 3. Connect inlet hose (6) to elbow (1) and adapter (4).
- 4. Connect outlet hose (7) to elbow (2) and adapter (5).
- 5. Install two new straps (8) around hose (6) and hose (7).



#### **FOLLOW-THROUGH STEPS**

- 1. Connect both battery negative leads (WP 0292 00).
- 2. Add oil if needed (WP 0128 00).
- 3. Install air cleaner assembly (WP 0159 00).
- 4. Lower center seat (see your -10).
- 5. Start engine and check engine oil filter hoses for leaks (see your -10).
- 6. Stop engine (see your -10).

#### **END OF TASK**

# **REPLACE ENGINE OIL FILTER ELEMENT AND PARTS (M548A1)**

# THIS WORK PACKAGE COVERS:

Removal (page 0143 00-2). Installation (page 0143 00-3).

# **INITIAL SETUP:**

Maintenance Level	Personnel Required
Unit	Unit Mechanic
Tools and Special Tools	
General Mechanic's Tool Kit (WP 0541 00, Item 57)	References
Torque Wrench (WP 0541 00, Item 69)	See your -10
Materials/Parts	Standard Operating Procedures
Cleaning compound (WP 0542 00, Item 9)	
Sealing compound (WP 0542 00, Item 39)	Equipment Condition
Sealing compound primer (WP 0542 00, Item 40)	
Engine oil (WP 0128 00)	Engine stopped (see your -10)
Gasket	Battery negative lead(s) disconnected (WP 0292 00)
Gasket	Power plant right rear access cover removed
Preformed packing	(see your -10)
Suitable container	Top access cover and grilles removed (WP 0390 00).

#### **REPLACE ENGINE OIL FILTER ELEMENT AND PARTS (M548A1) — Continued**

#### REMOVAL

1. Place suitable container under oil filter housing (1).

### NOTE


#### Dispose of engine oil in accordance with Standard Operating Procedures.

- 2. Remove drain plug (2) from oil filter housing (1) and drain oil.
- 3. Back out retaining bolt (3). Remove oil filter housing (1), oil filter element (4), and bolt as an assembly. Discard oil filter element and gasket (5).

### NOTE

#### If only oil filter element is being replaced, go to Step 9.

- 4. Remove nut (6) from retaining bolt (3).
- 5. Remove retaining bolt (3) and gasket (7) from oil filter housing (1). Discard gasket.
- 6. Remove preformed packing (8) and retaining bolt (3). Discard preformed packing.
- 7. Remove washer (9), spring (10), and retainer (11) from retaining bolt (3).
- 8. If needed, remove plug (12) from filter head (13).
- 9. Remove valve (14) and bushing (15) from filter head (13).




#### **REPLACE ENGINE OIL FILTER ELEMENT AND PARTS (M548A1) — Continued**

#### INSTALLATION

# NOTE

# If only oil filter element is being replaced, do Step 1, Step 4, Step 5, Step 6, and Step 7, and follow-through Steps 1 - 3.

- 1. Apply a thin coat of engine oil on new gasket (1). Install gasket in filter head (2).
- 2. Install new gasket (3) on oil filter housing (4). Install retaining bolt (5) in housing.
- 3. Install washer (6), spring (7), new preformed packing (8), and retainer (9) on retaining bolt (5). Secure with nut (10).
- 4. Place new oil filter element (11) very carefully over retaining bolt (5) in housing (4).
- 5. Install oil filter housing (4) with new oil filter element (11) on filter head (2).
- 6. Install drain plug (12) in oil filter housing (4).
- 7. Tighten retaining bolt (5) to 50-60 lb-ft (68-81 N•m) torque.
- 8. Clean external threads of plug (14) and bushing (13) with cleaning compound.
- 9. Apply a thin coat of sealing compound and sealing compound primer to cleaned external threads of plug (14) and bushing (13).
- 10. If removed, install plug (14) in filter head (2).
- 11. Install bushing (13) in filter head (2).
- 12. Install valve (15) in bushing (13) and filter head (2).



# REPLACE ENGINE OIL FILTER ELEMENT AND PARTS (M548A1) - Continued

13. Add engine oil (WP 0128 00).

### **FOLLOW-THROUGH STEPS**

- 1. Connect battery negative lead(s) (WP 0292 00).
- 2. Start engine (see your -10). Check for oil leaks.
- 3. Stop engine (see your -10). Wait about 20 minutes for engine oil to drain back to pan, then check engine oil level. Add oil if needed (WP 0128 00).
- 4. Install power plant right rear access cover (see your -10).
- 5. Install top access cover and grilles (WP 0390 00).

#### **END OF TASK**

# **REPLACE ENGINE OIL FILTER ELEMENT AND COVER (M548A3)**

# THIS WORK PACKAGE COVERS:

Removal (page 0144 00-2). Installation (page 0144 00-3).

#### **INITIAL SETUP:**

Maintenance Level

Unit

Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57)

Materials/Parts

Cleaning compound (WP 0542 00, Item 9) Gasket Gasket Preformed packing Suitable container Personnel Required

Unit Mechanic

References

See your -10 Standard Operating Procedures

Equipment Condition

Engine stopped (see your -10) Carrier blocked (see your -10) Both battery negative leads disconnected (WP 0292 00) Center seat raised (see your -10)

#### 0144 00

### REPLACE ENGINE OIL FILTER ELEMENT AND COVER (M548A3) - Continued


#### REMOVAL

1. Place clean container of at least 1 quart (1 liter) capacity under oil filter housing (1).

# NOTE

### Dispose of engine oil in accordance with Standard Operating Procedures.


- 2. Remove drain plug (2) from oil filter housing (1) and drain oil.
- 3. Remove bolt (3) and oil filter housing (1) with oil filter element (4) from filter head (5).
- 4. Remove nut (6) and oil filter element (4) from bolt (3).
- 5. Remove oil filter element (4) and gasket (7) from oil filter housing (1). Discard element and gasket.
- 6. Remove packing retainer (8), spacer (9), preformed packing (10), and spring (11) from bolt (3). Discard preformed packing.
- 7. Remove bolt (3) and gasket (12) from oil filter housing (1). Discard gasket.



#### REPLACE ENGINE OIL FILTER ELEMENT AND COVER (M548A3) - Continued

#### INSTALLATION

- 1. Clean oil filter housing (1) with cleaning compound.
- 2. Install bolt (2) and new gasket (3) in oil filter housing (1).
- 3. Install spring (4), new preformed packing (5), spacer (6), and packing retainer (7) on bolt (2).
- 4. Install new oil filter element (8), new gasket (9), and nut (10) in oil filter housing (4).
- 5. Install oil filter housing (1) with new oil filter element (8) on filter head (11).
- 6. Install drain plug (12) in oil filter housing (1).



#### **FOLLOW-THROUGH STEPS**

- 1. Connect both battery negative leads (WP 0292 00).
- 2. Add oil if needed (WP 0128 00).
- 3. Lower center seat (see your -10).

#### **END OF TASK**

# **REPLACE ENGINE OIL FILTER ASSEMBLY (M548A1)**

# THIS WORK PACKAGE COVERS:

Removal (page 0145 00-2). Installation (page 0145 00-3).

#### **INITIAL SETUP:**

Maintenance Level	References
Unit	See your -10
Tools and Special Tools	Standard Operating Procedures
General Mechanic's Tool Kit (WP 0541 00, Item 57)	
Materials/Parts	Equipment Condition
Cleaning compound (WP 0542 00, Item 9) Sealing compound (WP 0542 00, Item 39) Sealing compound primer (WP 0542 00, Item 40) Engine oil (WP 0128 00)	Engine stopped (see your -10) Carrier blocked (see your -10) Battery negative lead disconnected (WP 0292 00)
Suitable container	Power plant right rear access cover removed
Personnel Required	(see your -10)
Unit Mechanic	Top access cover and grilles removed (WP 0390 00)

### REPLACE ENGINE OIL FILTER ASSEMBLY (M548A1) - Continued

#### 0145 00


#### REMOVAL

- 1. Place suitable container under oil filter assembly (1).
- 2. Remove drain plug (2) from oil filter assembly (1). Allow engine oil to drain.

# NOTE

#### Dispose of engine oil in accordance with Standard Operating Procedures.

- 3. Disconnect oil hose (3) and oil hose (5) from elbow (4) and elbow (6).
- 4. Remove elbows (4, 6) from oil filter assembly (1).
- 5. Remove sampling valve (7) and bushing (8) from oil filter assembly (1).
- 6. Remove four screws (9), two washers (10), four nuts (11), and oil filter assembly (1) from bracket (12).



#### REPLACE ENGINE OIL FILTER ASSEMBLY (M548A1) — Continued


#### INSTALLATION

- 1. Clean external threads of elbow (1) and elbow (2) with cleaning compound.
- 2. Apply a thin even coat of sealing compound primer and sealing compound to cleaned external threads of elbow (1) and elbow (2) before installation.

### NOTE

#### Washers (6) are used on the two top screws only.

- 3. Install oil filter assembly (3) on bracket (4) with four screws (5), two washers (6), and four nuts (7).
- 4. Install bushing (8) and sampling valve (9) on oil filter assembly (3).
- 5. Install elbow (1) and elbow (2) on oil filter assembly (3).
- 6. Install oil hose (10) and oil hose (11) on elbow (1) and elbow (2).
- 7. Install drain plug (12) in oil filter assembly (3)



8. Add engine oil (WP 0128 00).

#### FOLLOW-THROUGH STEPS

- 1. Connect battery negative lead (WP 0292 00).
- 2. Start engine (see your -10).
- 3. Check filter assembly for leaks.
- Stop engine (see your -10). Wait about 20 minutes for engine oil to drain back to pan. Then check oil level. Add oil if needed (WP 0128 00).
- 5. Install top access cover and grilles (WP 0390 00).
- 6. Install power plant right rear access cover (see your -10).

#### **END OF TASK**

#### 0145 00-3/4 blank

# **REPLACE ENGINE OIL FILTER ASSEMBLY (M548A3)**

# THIS WORK PACKAGE COVERS:

Removal (page 0146 00-2). Installation (page 0146 00-3).

## **INITIAL SETUP:**

Maintenance Level	References
Unit Tools and Special Tools General Mechanic's Tool Kit (WP 0541 00, Item 57)	See your -10 See your PMCS Standard Operating Procedures
Materials/Parts	
Sealing compound (WP 0542 00, Item 39)	Equipment Condition
Sealing compound primer (WP 0542 00, Item 40) Lock nuts (4)	Engine stopped (see your -10)
Suitable container	Carrier blocked (see your -10)
Personnel Required	Center seat raised (see your -10)
Unit Mechanic	Both battery negative leads disconnected (WP 0292 00)

0146 00-1

### REPLACE ENGINE OIL FILTER ASSEMBLY (M548A3) - Continued

#### 0146 00


#### REMOVAL

1. Place a clean suitable container of at least 1 quart (1 liter) capacity under oil filter assembly (1).

# NOTE

### Dispose of engine oil in accordance with Standard Operating Procedures.


- 2. Remove drain plug (2) from oil filter assembly (1). And allow engine oil to drain from filter.
- 3. Disconnect inlet hose (3) from elbow (4).
- 4. Disconnect outlet hose (5) from elbow (6).
- 5. Remove elbows (4 and 6) from oil filter assembly (1).
- 6. Remove AOAP sampling valve (7) and bushing (8) from oil filter assembly (1).
- 7. Remove four screws (9), lock nuts (10), eight washers (11), and oil filter assembly (1) from bracket (12). Discard lock nuts.



#### REPLACE ENGINE OIL FILTER ASSEMBLY (M548A3) — Continued

#### INSTALLATION

- 1. Apply sealing compound primer and a thin even coat of sealing compound to cleaned external threads of elbow (1) and elbow (2) before installing.
- 2. Install oil filter assembly (3) on bracket (4) with four screws (5), new lock nuts (6), and eight washers (7).
- 3. Install bushing (8) and AOAP sampling valve (9) on oil filter assembly (3).
- 4. Install elbow (1) and elbow (2) on oil filter assembly (3).
- 5. Connect oil inlet hose (10) to elbow (1).
- 6. Connect oil outlet hose (11) on elbow (2).
- 7. Start engine (see your -10). Check oil filter assembly (3) for leaks.



8. Stop engine (see your -10). Wait about 20 minutes for oil to drain back to pan. Then check oil level. Add oil if needed (WP 0128 00).

#### **FOLLOW-THROUGH STEPS**

- 1. Connect both battery negative leads (WP 0292 00).
- 2. Lower center seat (see your -10)

### **END OF TASK**

# INDEX

Subject	WP Sequence NoPage			-Page No.				
7.62 mm machine gun mount								
Replacement								0515.00.1
	•••	•	•	•	•	•	 •	0515 00-1
Α								
Accelerator linkage								
M548A3								
Adjustment								0200 00-1
Access cover								
Front (M548A3), removal/installation						•	 •	0391 00-1
Hull bottom, replace						•		0383 00-1
Seal, power plant right rear, replace								0389 00-1
Top (M548A1), removal/installation								0390 00-1
Access covers								
Fuel compartment								
Removal/installation								0163 00-1
Adapter								
NBC M3 heater (M548A3), replace								0532 00-1
Adjusting linkage								
Generator drive belts								
(M548A1), replace								0243 00-1
(M548A3), replace								0247 00-1
Air box drain and crankcase breather collector can								
Replacement								0134 00-1
Air box drain check valve and tubes								
M548A3								
Replacement								0136 00-1
Air box drain tubes								
M548A1								
Replacement								0135 00-1
Air box heater								
M548A1								
Replacement								0189 00-1
Switch, replace								0260 00-1
Air box heater electrode								
M548A3								
Replacement								0188 00-1
Air box heater harness and igniter cable								
M548A1								
Replacement								0182 00-1
Air box heater harness and ignition cable								
M548A3								
Replacement								0183 00-1
Air box heater hoses, tubes, and fittings								

# INDEX, cont'd

WP Sequence No.-Page No.

Subject

M548A1						
Replacement				 	 	0180 00-1
M548A3						
*				 	 	0181 00-1
Air box heater ignition	coil					
M548A1						
-				 	 	0184 00-1
Air box heater ignition	coil, air pump,	and check va	alve			
M548A3						
1				 	 	0185 00-1
Air box heater solenoid	l valve					
M548A1						
1				 	 	0186 00-1
M548A3						
Replacement				 	 	0187 00-1
Air brake compressor						
M548A1						
Replacement				 	 	0489 00-1
Air brake governor						
M548A1						
Replacement				 	 	0490 00-1
Air brake instrument pa	anel					
M548A1						
Replacement				 	 	0501 00-1
Air brake panel light						
M548A1						
Replacement				 	 	0504 00-1
Air brake pressure indic	cator					
M548A1						
Replacement				 	 	0503 00-1
Air brake reservoir						
M548A1						
Replacement				 	 	0491 00-1
Air brake safety valve						
M548A1						
Replacement				 	 	0492 00-1
Air cleaner and elemen	t					
M548A1						
Replacement				 	 	0152 00-1
Air cleaner assembly ar						
M548A3	1					
Replacement				 	 	0159 00-1
Air cleaner door gasket						
M548A3						

2

Subject	WP Sequence NoPage No.
Replacement	0158 00-1
Air cleaner elbow and inlet duct assemblies	
M548A3	
Replacement	0161 00-1
Air cleaner exhaust check valve and ejector tube	
M548A3	
Replacement	0160 00-1
Air cleaner filter element	
M548A3	
Replacement	
Servicing	
Air cleaner filter indicator assembly	
M548A1	
Replacement	
Air cleaner hose and clamps	
M548A1	
Replacement	
Air cleaner indicator and hose	
M548A3	
Replacement	
Air ducts and hoses	
Kit I (M548A1), replace	
Kit II (M548A1), replace	
Kit III (M548A1), replace	
Air fittings	
M548A1	
Replacement	
Air hoses	
M548A1	
Replacement	
Air inlet ducts	
Vehicle compartment heater	
M548A3	
Replacement	
Air low pressure switch	
M548A1	
Replacement	
Air low pressure warning light	
M548A1	
Replacement	
Air pump	
Replacement	
Air pumpvane kit	
Replacement	

Subject	WP Sequence NoPage No.
Air separator tank	
M548A1	
Replacement	0170 00-1
M548A3	
Replacement	0171 00-1
Air separator to fuel tank tubes, hoses, and fittings	
M548A1	
Replacement	0172 00-1
M548A3	
Replacement	0173 00-1
Air strainer	
M548A1	
Replacement	0500 00-1
Air tubes	
M548A1	
Replacement	0495 00-1
Anchor	
Torsion bar	0250.00.1
Replacement	0350 00-1
AOAP valve, hose, and bracket	
Transmission M548A1	
Replacement	0322.00.1
Arm and blade	
Windshield wiper	
Replacement	0422 00-1
Arm assembly	
Idler wheel	
Replacement	0354 00-1
Assembly and mounting brackets	
Vehicle compartment heater	
M548A3	
Replacement	
Assembly and related parts	
Air cleaner	
M548A3	
Replacement	0159 00-1
Auxiliary power (slave) receptable	
Replacement	0303 00-1
Auxiliary tank	
Radiator	
M548A3	
Replace	0217 00-1

# INDEX, cont'd

# Subject

# WP Sequence No.-Page No.

B

Battery															
Box heat exchanger/hoses/fittings, replace													 		0476 00-1
Compartment (M548A1), replace													 		0290 00-1
Compartment (M548A3), replace													 •		0291 00-1
Compartment bracket (M548A3), replace													 •		0291 00-1
(M548A1), replace													 •		0290 00-1
(M548A3), replace													 •		0293 00-1
Negative lead(s), remove/install													 •		0292 00-1
Battery to regulator cable jack															
M548A3															
Replacement								•	 •		•		 •		0299 00-1
Beam															
Material handling kit, replace					 •			•	 •		••	•	 •		0483 00-1
Transverse, bolted (M548A3), replace					 •			•	 •	• •	••	•	 •		0385 00-1
Beam selector															
Switch, replace								•	 •		••	•	 •		0273 00-1
Bearings															
Drive shaft lubrication															
M548A1															
Replacement					 •			•	 •	• •	••	•	 •		0237 00-1
Bearings and seals															
Idler wheel															
Replacement				• •				•	 •		••	•	 •		0355 00-1
Belts															
Safety															
Replacement								•	 •		•	•	 •		0399 00-1
Bilge pump															
Circuit breaker, replace															
Replacement															
Switch, replace			• •	• •	 •			•	 •		•	•	 •		0261 00-1
Bilge pump discharge tubes and hoses															
M548A1															
Replacement			• •	• •	 •			•	 •		•	•	 •		0425 00-1
M548A3															
Replacement			• •	• •	 •			•	 •		••	•	 •		0426 00-1
Blackout															
Headlights, replace	• •	• •	• •	• •	 •			•	 •	• •	••	•	 •	•	0275 00-1
Blackout marker light															
Replacement															
Blackout marker light, replace	• •	• •	• •		 •	• •		•	 •	• •	•	·	 •	•	0280 00-1
Blackout stoplight-taillight															
Replacement	• •		• •	• •	 •	•••	• •	•	 •	• •	•	•	 •	•	0507 00-1
Bracket															

Subject	WP Sequence NoPage No.
Steering wheel (M548A3), replace	0363 00-1
Brake	
Parking	
M548A3	
Adjustment	0345 00-1
Pivot steering (M548A1)	
Brake assembly, replace	0373 00-1
Controls/linkage	
Adjustment	0370 00-1
Replace	0369 00-1
Hoses/tubes/fittings, replace	0372 00-1
Lining, replace	
Master cylinder, replace	
Brake adjustment	
Transmission	
M548A3	
Check	0313 00-1
Brake control linkage	
M548A3	
Adjustment	0347 00-1
Replacement	
Brakes	
Differential	
M548A1	
Adjustment	0341 00-1
Transmission	
M548A3	
Adjustment	031/100-1
Breather	
Differential	
M548A1	
Replacement	0338 00-1
Bulkhead protector	
Removal/installation	0/187 00-1
С	
Cab	
Dome light, replace	0279 00-1
Door	
Handles and linkage, replace	0386 00-1
Seal, replace	0388 00-1
Windows, replace	0458 00-1
Cab cover and frames	
Replacement	0418 00-1

Subject	WP Sequence NoPage No.
Cab floor plates	
M548A1	
Removal/installation	0394 00-1
Cab floor plates, door, and seat support	
M548A3	
Replacement	0395 00-1
Cab personnel seats	
Replacement	0398 00-1
Cable	
Speedometer	
Replacement	0518 00-1
Tachometer	
M548A1	
Replacement	0522 00-1
M548A3	
Replacement	0523 00-1
Tow start	
M548A3	0010.00.1
Replacement	0310 00-1
Cable assembly	
Fuel cutoff control	
M548A3	0205.00.1
Replacement	0205 00-1
Parking brake M548A3	
Replacement	0346.00.1
Cable housing and adapter	
Speedometer	
Replacement	0517 00-1
Tachometer	
M548A1	
Replacement	0520 00-1
M548A3	
Replacement	
Cable jack	
Battery to regulator	
M548A3	
Replacement	
Caliber .50 machine gun mount	
Replacement	
Cap and strainer	
Fuel filler	
Replacement	0164 00-1
Carbon dioxide (CO2) cylinder	

# INDEX, cont'd

WP Sequence No.-Page No.

Subject

Replacement	
Control box mounting, replace       0462 00-1         Fuel lines/fittings/shields, replace       0463 00-1         Fuel pump       0464 00-1         Wiring harness       0465 00-1         Cargo compartment       0393 00-1         Floor plates, raise/lower       0393 00-1         Cargo compartment cover       0465 00-1         Replacement       0417 00-1         Replacement       0469 00-1         Replacement       0402 00-1         Cargo door       0402 00-1         Cargo door seals       Replacement         Replacement       0403 00-1         Center seat       0403 00-1         Panel (M548A1), replace       0384 00-1         Center seat support       M548A3         M548A3       0396 00-1         Check valve and tubes       0396 00-1         Circuit breaker       0376 00-1         Bilge pump, replace       0268 00-1         Fuel pump, lectric (M548A3, replace       0272 00-1         Generator-regulator, replace       0269 00-1         Replacement       0269 00-1         Replace       0267 00-1         Circuit breaker       0269 00-1         Replace       0267 00-1         Circuit breaker<	
Fuel lines/fittings/shields, replace       0463 00-1         Fuel pump       0464 00-1         Wiring harness       0465 00-1         Cargo compartment       0463 00-1         Floor plates, raise/lower       0393 00-1         Cargo compartment cover       Replacement         Replacement       0417 00-1         Cargo door seals       0469 00-1         Replacement       0402 00-1         Cargo door seals       0403 00-1         Replacement       0403 00-1         Center seat       0403 00-1         Panel (M548A1), replace       0384 00-1         Center seat support       M548A1         M548A3       0396 00-1         Circuit breaker       0136 00-1         Circuit breaker       0136 00-1         Circuit breaker       0268 00-1         Bilge pump, replace       0268 00-1         Fuel pump, electric (M548A3), replace       0272 00-1         Generator-regulator, replace       0269 00-1         Replacement       0136 00-1         Circuit breaker       0269 00-1         Bilge pump, replace       0269 00-1         Replace       0269 00-1         Replace, conter regulace       0269 00-1         Rep	Cargo area heater
Fuel pump       0464 00-1         Wiring harness       0465 00-1         Cargo compartment       0393 00-1         Floor plates, raise/lower       0393 00-1         Cargo compartment cover       Replacement       0417 00-1         Cargo door       0402 00-1         Insulation, replace       0402 00-1         Cargo door seals       0403 00-1         Center seat       0403 00-1         Center seat       0384 00-1         Center seat support       0384 00-1         Check valve and tubes       0396 00-1         Check valve and tubes       0396 00-1         Circuit breaker       0396 00-1         Bilge pump, replace       0268 00-1         Fuel pump, electric (M548A3), replace       0272 00-1         Generator-regulator, replace       0269 00-1         Circuit breaker       0268 00-1         Bilge pump, replace       0268 00-1         Fuel pump, electric (M548A3), replace       0272 00-1         Generator-regulator, replace       0269 00-1         Replacement       0530 00-1         Circuit breaker and relay       0269 00-1         NBC       M548A3       0269 00-1         Replacement       0530 00-1       0530 00-1 </td <td>Control box mounting, replace</td>	Control box mounting, replace
Wiring harness       0465 00-1         Cargo compartment       0393 00-1         Floor plates, raise/lower       0393 00-1         Cargo compartment cover       0417 00-1         Replacement       0417 00-1         Cargo door       0469 00-1         Insulation, replace       0469 00-1         Replacement       0402 00-1         Cargo door seals       0402 00-1         Replacement       0403 00-1         Center seat       0484 01), replace         Panel (M548A1), replace       0384 00-1         Center seat support       0384 00-1         M548A1       Replacement       0396 00-1         Check valve and tubes       0396 00-1         Air box drain       M548A3       0396 00-1         Circuit breaker       0136 00-1       0136 00-1         Bilge pump, replace       0268 00-1       0269 00-1         Generator-regulator, replace       0268 00-1       0269 00-1         Replace.       0267 00-1       0136 00-1       0136 00-1         Circuit breaker       0272 00-1       0269 00-1       0269 00-1         Replace       0267 00-1       0269 00-1       0269 00-1         NBC       M548A3       0260 00-1       0269	Fuel lines/fittings/shields, replace
Cargo compartment       Floor plates, raise/lower       0393 00-1         Cargo compartment cover       Replacement       0417 00-1         Cargo door       Insulation, replace       0469 00-1         Replacement       0402 00-1         Cargo door seals       Replacement       0403 00-1         Center seat       Panel (M548A1), replace       0384 00-1         Center seat support       M548A1       0396 00-1         Check valve and tubes       0396 00-1       Check valve and tubes         Air box drain       M548A3       0396 00-1         Circuit breaker       0136 00-1       Circuit breaker         Bilge pump, replace       0268 00-1       Panel (M548A3), replace       0272 00-1         Generator-regulator, replace       0268 00-1       Panel Q269 00-1       Replacement       0269 00-1         Circuit breaker       Bilge pump, replace       0272 00-1       Generator-regulator, replace       0269 00-1         Replace       0267 00-1       Circuit breaker and relay       NBC       NBC         M548A3       Replacement       0530 00-1       Cincuit breaker and relay       NBC         NBC       M548A3       Replacement       0530 00-1         Clutch       Exet covers, replace       0460 00-1	Fuel pump
Floor plates, raise/lower       0393 00-1         Cargo compartment cover       0417 00-1         Replacement       0417 00-1         Cargo door       0402 00-1         Replacement       0403 00-1         Center seat       0403 00-1         Center seat       0384 00-1         Center seat support       0384 00-1         Center seat support       0396 00-1         Check valve and tubes       0396 00-1         Circuit breaker       0136 00-1         Circuit breaker       0268 00-1         Fuel pump, replace       0269 00-1         Greent breaker       0272 00-1         Generator-regulator, replace       0269 00-1         Replacement       0269 00-1         Replace       0269 00-1         Replace       0269 00-1         Replace       0269 00-1         Guereut breaker       0269 00-1         Bilge pump, replace       0269 00-1         Replace       0269 00-1         Replacement       0269 00-1         Circuit breaker and relay       0269 00-1	Wiring harness
Cargo compartment cover       0417 00-1         Cargo door       0469 00-1         Replacement       0469 00-1         Replacement       0402 00-1         Cargo door seals       0403 00-1         Cargo door seals       0403 00-1         Center seat       0403 00-1         Panel (M548A1), replace       0384 00-1         Center seat support       0384 00-1         M548A1       0396 00-1         Check valve and tubes       0396 00-1         Air box drain       0396 00-1         M548A3       0136 00-1         Circuit breaker       0136 00-1         Bilge pump, replace       0268 00-1         Fuel pump, electric (M548A3), replace       0272 00-1         Generator-regulator, replace       0269 00-1         Replacement       0269 00-1         Replace       0269 00-1         Replace       0267 00-1         Circuit breaker and relay       0267 00-1         NBC       04548A3         Replacement       0530 00-1         Cloth seat covers, replace       0374 00-1         Clutch       0374 00-1         Disk, pivot steering (M548A1), replace       0374 00-1         Clutch       0374 00-1	Cargo compartment
Replacement       0417 00-1         Cargo door       0469 00-1         Insulation, replace       0469 00-1         Replacement       0403 00-1         Cargo door seals       0403 00-1         Center seat       0403 00-1         Center seat       0384 00-1         Center seat support       0584 00-1         M548A1       0396 00-1         Check valve and tubes       0396 00-1         Air box drain       0396 00-1         Circuit breaker       0136 00-1         Bilge pump, replace       0268 00-1         Fuel pump, replace       0268 00-1         Fuel pump, replace       0268 00-1         Generator-regulator, replace       0269 00-1         Replacement       0136 00-272 00-1         Generator-regulator, replace       0269 00-1         Replace       0269 00-1         Replace       0269 00-1         Replace       0267 00-1         Circuit breaker and relay       0267 00-1         NBC       M548A3       0530 00-1         Clutch       0450 00-1       0460 00-1         Clutch       0540 00-1       0374 00-1         Disk, pivot steering (M548A1), replace       0374 00-1	Floor plates, raise/lower
Cargo door       0469 00-1         Replacement       0402 00-1         Cargo door seals       0402 00-1         Replacement       0403 00-1         Center seat       0403 00-1         Panel (M548A1), replace       0384 00-1         Center seat support       0384 00-1         Cheter seat support       0396 00-1         Check valve and tubes       0396 00-1         Check valve and tubes       0396 00-1         Circuit breaker       0136 00-1         Bilge pump, replace       0268 00-1         Fuel pump, replace       0268 00-1         Generator-regulator, replace       0268 00-1         Generator-regulator, replace       0269 00-1         Replacement       0267 00-1         Circuit breaker and relay       0267 00-1         NBC       M548A3         Replacement       0530 00-1         Circuit breaker and relay       0530 00-1         Circuit breaker and relay       0530 00-1         Cittch       0374 00-1         Cutch       0374 00-1         Cutch lever       0374 00-1         M548A1       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1	Cargo compartment cover
Insulation, replace       0469 00-1         Replacement       0402 00-1         Cargo door seals       0403 00-1         Replacement       0403 00-1         Center seat       0384 00-1         Panel (M548A1), replace       0384 00-1         Center seat support       M548A1         Replacement       0396 00-1         Check valve and tubes       344         Air box drain       M548A3         Replacement       0136 00-1         Circuit breaker       0136 00-1         Bilge pump, replace       0268 00-1         Fuel pump, electric (M548A3), replace       0272 00-1         Generator-regulator, replace       0269 00-1         Replacement       0269 00-1         Replace       0269 00-1         Circuit breaker and relay       NBC         M548A3       0530 00-1         Clutch       0530 00-1         Clutch       0530 00-1         Disk, pivot steering (M548A1), replace       0374 00-1         Clutch	Replacement
Replacement       0402 00-1         Cargo door seals       0403 00-1         Replacement       0403 00-1         Center seat       0384 00-1         Panel (M548A1), replace       0396 00-1         Center seat support       0396 00-1         M548A1       0396 00-1         Check valve and tubes       0396 00-1         Air box drain       0136 00-1         Circuit breaker       0136 00-1         Bilge pump, replace       0268 00-1         Fuel pump, electric (M548A3), replace       0272 00-1         Generator-regulator, replace       0269 00-1         Replacement       0267 00-1         Circuit breaker       0267 00-1         NBC       M548A3         Replacement       0530 00-1         Circuit breaker and relay       0267 00-1         NBC       M548A3         Replacement       0530 00-1         Clutch       0374 00-1         Clutch       0374 00-1         Clutch lever       M548A1         Replacement       0374 00-1         Clutch lever       0374 00-1         M548A1       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1 <td>Cargo door</td>	Cargo door
Cargo door seals       0403 00-1         Center seat       0384 00-1         Panel (M548A1), replace       0384 00-1         Center seat support       0396 00-1         M548A1       0396 00-1         Check valve and tubes       0396 00-1         Air box drain       0396 00-1         Circuit breaker       0136 00-1         Circuit breaker       0136 00-1         Circuit breaker       0268 00-1         Fuel pump, replace       0268 00-1         Fuel pump, replace       0268 00-1         Fuel pump, replace       0269 00-1         Generator-regulator, replace       0269 00-1         Replacement       0269 00-1         Replace       0267 00-1         Circuit breaker and relay       0267 00-1         NBC       M548A3         Replacement       0530 00-1         Cloth seat covers, replace       0460 00-1         Clutch       0374 00-1         Clutch lever       M548A1         Replacement       0374 00-1         Clutch lever       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1	Insulation, replace
Replacement       0403 00-1         Center seat       0384 00-1         Panel (M548A1), replace       0384 00-1         Center seat support       M548A1         Replacement       0396 00-1         Check valve and tubes       0396 00-1         Air box drain       M548A3         Replacement       0136 00-1         Circuit breaker       0136 00-1         Bilge pump, replace       0268 00-1         Fuel pump, replace       0268 00-1         Fuel pump, replace       0268 00-1         Fuel pump, replace       0269 00-1         Replacement       0267 00-1         Circuit breaker and relay       0267 00-1         NBC       M548A3         Replacement       0530 00-1         Cloth seat covers, replace       0460 00-1         Clutch       0374 00-1         Clutch lever       M548A1         Replacement       0374 00-1         Clutch lever       M548A1         Replacement       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1	Replacement
Center seat Panel (M548A1), replace	Cargo door seals
Panel (M548A1), replace	Replacement
Center seat support M548A1 Replacement	Center seat
M548A1 Replacement	Panel (M548A1), replace
M548A1 Replacement	Center seat support
Check valve and tubes         Air box drain         M548A3         Replacement         Bilge pump, replace         Bilge pump, replace         O268 00-1         Fuel pump, electric (M548A3), replace         Generator-regulator, replace         O267 00-1         Circuit breaker and relay         NBC         M548A3         Replacement         O530 00-1         Cloth seat covers, replace         O374 00-1         Clutch         Disk, pivot steering (M548A1), replace         M548A1         Replacement         O374 00-1         Clutch lever         M548A1         Replacement       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1	
Air box drain       M548A3         Replacement       0136 00-1         Circuit breaker       0268 00-1         Bilge pump, replace       0268 00-1         Fuel pump, electric (M548A3), replace       0272 00-1         Generator-regulator, replace       0269 00-1         Replace       0269 00-1         Replace       0267 00-1         Circuit breaker and relay       0267 00-1         NBC       0548A3         Replacement       0530 00-1         Cloth seat covers, replace       0460 00-1         Clutch       0374 00-1         Disk, pivot steering (M548A1), replace       0374 00-1         Clutch lever       M548A1         Replacement       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1	Replacement
M548A3       0136 00-1         Circuit breaker       0268 00-1         Fuel pump, replace       0268 00-1         Fuel pump, electric (M548A3), replace       0272 00-1         Generator-regulator, replace       0269 00-1         Replace       0269 00-1         Replace       0267 00-1         Circuit breaker and relay       0267 00-1         NBC       0267 00-1         Cloth seat covers, replace       0530 00-1         Clutch       0460 00-1         Disk, pivot steering (M548A1), replace       0374 00-1         Clutch lever       M548A1         Replacement       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1	Check valve and tubes
Replacement       0136 00-1         Circuit breaker       0268 00-1         Bilge pump, replace       0268 00-1         Fuel pump, electric (M548A3), replace       0272 00-1         Generator-regulator, replace       0269 00-1         Replace       0267 00-1         Circuit breaker and relay       0267 00-1         NBC       0267 00-1         Cloth seat covers, replace       0530 00-1         Clutch       0460 00-1         Clutch lever       0374 00-1         M548A1       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1	Air box drain
Circuit breaker       Bilge pump, replace       0268 00-1         Fuel pump, electric (M548A3), replace       0272 00-1         Generator-regulator, replace       0269 00-1         Replace       0267 00-1         Circuit breaker and relay       0267 00-1         NBC       0267 00-1         Cloth seat covers, replace       0530 00-1         Clutch       0374 00-1         Clutch lever       0374 00-1         Clutch lever       04548A1         Replacement       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1	M548A3
Bilge pump, replace       0268 00-1         Fuel pump, electric (M548A3), replace       0272 00-1         Generator-regulator, replace       0269 00-1         Replace       0267 00-1         Circuit breaker and relay       0267 00-1         NBC       0530 00-1         Cloth seat covers, replace       0530 00-1         Clutch       0374 00-1         Clutch lever       0374 00-1         M548A1       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1	Replacement
Fuel pump, electric (M548A3), replace       0272 00-1         Generator-regulator, replace       0269 00-1         Replace       0267 00-1         Circuit breaker and relay       0267 00-1         NBC       0530 00-1         Cloth seat covers, replace       0530 00-1         Clutch       0460 00-1         Disk, pivot steering (M548A1), replace       0374 00-1         Clutch lever       0374 00-1         Clutch lever       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1	Circuit breaker
Fuel pump, electric (M548A3), replace       0272 00-1         Generator-regulator, replace       0269 00-1         Replace       0267 00-1         Circuit breaker and relay       0267 00-1         NBC       0530 00-1         Cloth seat covers, replace       0530 00-1         Clutch       0460 00-1         Disk, pivot steering (M548A1), replace       0374 00-1         Clutch lever       0374 00-1         Clutch lever       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1	Bilge pump, replace
Generator-regulator, replace       0269 00-1         Replace       0267 00-1         Circuit breaker and relay       0267 00-1         NBC       0530 00-1         Cloth seat covers, replace       0530 00-1         Clutch       0460 00-1         Disk, pivot steering (M548A1), replace       0374 00-1         Clutch lever       0548A1         Replacement       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1	Fuel pump, electric (M548A3), replace
Circuit breaker and relay NBC M548A3 Replacement	Generator-regulator, replace
Circuit breaker and relay NBC M548A3 Replacement	Replace
NBC       M548A3         Replacement       0530 00-1         Cloth seat covers, replace       0460 00-1         Clutch       0530 00-1         Disk, pivot steering (M548A1), replace       0374 00-1         Clutch lever       0548A1         M548A1       0410 00-1         Common Tools, Supplements, and Fixtures List       0541 00-1	Circuit breaker and relay
Replacement       0530 00-1         Cloth seat covers, replace       0460 00-1         Clutch       0374 00-1         Clutch lever       0374 00-1         M548A1       0410 00-1         Common Tools, Supplements, and Fixtures List       0510 00-1	
Cloth seat covers, replace	M548A3
Cloth seat covers, replace	Replacement
Clutch Disk, pivot steering (M548A1), replace	•
Clutch lever M548A1 Replacement	
Clutch lever M548A1 Replacement	Disk, pivot steering (M548A1), replace
Replacement	
Replacement	M548A1
Common Tools, Supplements, and Fixtures List	
	*
Guard, exhaust pipes (M548A1), replace	
Compressor	
Air brake	*

Subject	WP Sequence NoPage No.
M548A1	
Replacement	
Compressor drive belt guard	
M548A1	
Replacement	0497 00-1
Compressor drive belts	
M548A1	
Adjustment/alignment	0498 00-1
Replacement	0499 00-1
Compressor drive pulley	
M548A1	
Adjustment/alignment	0498 00-1
Replacement	0499 00-1
Control	
Steering (M548A1)	
Replace	0366 00-1
Throttle pedal	
M548A1	
Replacement	0196 00-1
Turn signal	
Replacement	0508 00-1
Control box	
Vehicle compartment heater	
Replacement	0431 00-1
Control box, heater	
Cargo compartment, repair/replace	0472 00-1
Control cable assembly	
Tow start	
M548A3	0211.00.1
Adjustment	
Control lever	
Parking brake M548A3	
Replacement	0246 00 1
Control linkage	0340 00-1
Brake	
M548A3	
Adjustment	0347 00-1
Replacement	
Control valve	
Fyr-Fyter	
Replacement	
Walter Kidde	
Replacement	0528 00-1
	0528 00-1

# INDEX, cont'd

# Subject

# WP Sequence No.-Page No.

Controls	
Cover, vehicle compartment heater (M548A1), replace	00-1
Engine disconnect (M548A1), replace	00-1
Pivot steering brake (M548A1)	
Adjustment	00-1
Replace	00-1
Steering (M548A1)	
Adjustment	00-1
Tailgate	
Replacement	00-1
Coolant heater, engine	
Control box, replace	00-1
Coolant pump, replace	
Exhaust system	
(M548A1), replace	00-1
(M548A3), replace	
Fuel pump/fuel lines, replace	
Guard, exhaust pipes (M548A1), replace	
Replace	
Wiring harness, replace	
Coolant pump	<i>,</i> 0 1
M548A1	
Replacement	)0-1
M548A3	<i>i</i>
Replacement	)0-1
Coolant pump drive belts	<i>J</i> <b>O</b> 1
M548A3	
Replacement	001
Coolant pump drive belts and idler pulley	J0-1
Engine	
M548A1	
Replacement	00 1
Coolant pump idler pulley and adjusting bracket	J0-1
M548A3	
Replacement	00 1
	J0-1
Coolant tubes/hoses/fittings M548A3	
	00 1
Replacement	JO-1
Cooling fan	
M548A1	0.1
Replacement	JO-1
Cooling fan and pulley	
M548A3	·
Replacement	)0-1

Subject	WP Sequence NoPage No.
Cooling fan drive belt	
M548A3	
Replacement	0227 00-1
Cooling fan drive housing and shaft	
M548A3	
Replacement	0238 00-1
Cooling fan idler arm	
M548A3	
Replacement	
Cooling fan idler arm support	
M548A3	
Replacement	
Cooling fan idler pulley M548A3	
Replacement	
Cooling system	
M548A1	
Drain	0213 00-1
Fill	0212 00-1
M548A3	
Drain	0214 00-1
Fill	
Corrosion Prevention and Control (CPC)	0001 00-1
Cover	
Cab	
Fiberglass, replace	0456 00-1
Cargo compartment	
Replacement	
Controls, vehicle compartment heater (M548A1), replace	
Drain, hull bottom, replace	
Escape hatch, replace	
Floor plate, replace	
Hatch, machine gun, fiberglass, replace	
Cargo, replace	
Seat, cloth, replace	
Seat, personnel, replace	
Tow start	
M548A3	
Replacement	0310 00-1
Cover and frames	
Cab	
Replacement	0418 00-1
representation in the second s	

Subject	WP Sequence NoPage No.
Crankcase breather hose	
Engine	
Replacement	0137 00-1
D	
Data plate, marker, and decal chart	
M548A1	0441 00-1
M548A3	0442 00-1
Decontamination brush guard and backing plate	
M13	
Replacement	0401 00-1
Defroster fan identification plate	
Vehicle compartment heater	
Replacement	0433 00-1
Defroster fan toggle switches	
Vehicle compartment heater	
Replacement	0433 00-1
Defroster fan wiring harness	
Vehicle compartment heater	
Replacement	0434 00-1
Defroster, hoses, and fans	
Vehicle compartment heater	
M548A3	
Replacement	
Destruction of Army Materiel to Prevent Enemy Use	0001 00-1
Detent	
Throttle pedal	
M548A1	
Replacement	0196 00-1
Differential (M548A1)	
High temperature switch, replace	
Differential and mounts	
M548A1	
Replacement	0342 00-1
Differential brakes	
M548A1	
Adjustment	0341 00-1
Differential breather	
M548A1	
Replacement	0338 00-1
Differential gasket	
M548A1	
Replacement	0344 00-1
Differential oil filter and oil filter element	

Subject	WP Sequence NoPage No.
M548A1	
Replacement	0337 00-1
Differential oil hoses and fittings	
M548A1	
Replacement	0340 00-1
Differential oil level gauge rod	
M548A1	
Replacement	0339 00-1
Differential oil pump	
M548A1	
Replacement	0336 00-1
Differential pressure switch and bypass plug	
M548A3	
Replacement	0324 00-1
Differential switch lead	
M548A1	
Replacement	0343 00-1
Discharge tubes and hoses	
Bilge pump	
M548A1	
Replacement	0425 00-1
M548A3	
Replacement	0426 00-1
Disconnect control, engine (M548A1), replace	0368 00-1
Disk, clutch, pivot steering (M548A1), replace	0374 00-1
Dome light, cab, replace	
Door	
Cab	
Handles/linkage, replace	0386 00-1
Seal, replace	0388 00-1
Thermal windows, replace	
Windows, replace	0387 00-1
Cargo	
Replacement	0402 00-1
Door gasket	
Air cleaner	
M548A3	
Replacement	0158 00-1
Drain and crankcase breather collector can	
Air box	0104.00.1
Replacement	0134 00-1
Drain cap and sight gauge	
M548A3	0000 00 1
Replacement	

Subject	WP Sequence NoPage No.
Drain tubes	
Air box	
M548A1	
Replacement	0135 00-1
Drive belt	
Cooling fan	
M548A3	
Replacement	0227 00-1
Generator	
(M548A1)	
Adjust	0241 00-1
Replace	0240 00-1
(M548A3), replace/adjust	0245 00-1
Drive belt guard	
Compressor	
M548A1	
Replacement	0497 00-1
Drive belts	
Compressor	
M548A1	
Adjustment/alignment	
Replacement	0499 00-1
Coolant pump	
M548A3	
Replacement	0224 00-1
Fan	
M548A1	
Replacement	0226 00-1
Drive belts and idler pulley	
Coolant pump	
M548A1	
Replacement	0223 00-1
Drive housing and shaft	
Cooling fan	
M548A3	
Replacement	0238 00-1
Drive pulley	
Compressor	
M548A1	0408 00 1
Adjustment/alignment	
Replacement	
Drive sprockets, cushions, and carrier assembly	0257 00 1
Replacement	
Dirver 5 seat	

Subject	WP Sequence NoPage No.
Replacement	0307.00.1
Drum brake shoe	
M548A1	
Adjustment	0408 00-1
Drum lock handle	
M548A1	
Replacement	0411 00-1
Drum safety brake	
M548A1	
Adjustment	
Ε	
Elbow and inlet duct assemblies	
Air cleaner	
M548A3	
Replacement	0161 00-1
Electric fuel pumps	
Flow test	0148 00-1
Replacement	
Electrical lead, master switch to bus bar (M548A3), replace	
Electrode	
Air box heater	
M548A3	
Replacement	0188 00-1
End seals and bumpers	
Tailgate	
Replacement	
Engine	
Coolant heater	
Control box, replace	
Coolant pump, replace	
Exhaust system	
(M548A1), replace	
(M548A3), replace	
Fuel pump/fuel lines, replace	0475 00-1
Guard, exhaust pipes (M548A1), replace	
Replace	
Wiring harness, replace	
Coolant temperature transmitter	
(m548A1), replace	
(M548A3), replace	
Disconnect control (M548A1), replace	0368 00-1
Low oil pressure transmitter (M548A3), replace	0282 00-1
Oil filter	

# INDEX, cont'd

WP Sequence No.-Page No.

Subject

Hoses/fittings
(M548A1), replace
Oil low pressure switch (M548A1), replace
Engine coolant pump drive belts and idler pulley M548A1
Replacement
Engine crankcase breather hose
Replacement
Engine exhaust pipe guard M548A1
Replacement
Engine fuel pump
Flow test
M548A1
Replacement
M548A3
Replacement
Engine governor throttle arm
M548A1
Adjustment
Engine ground lead
M548A3
Replacement
Engine oil filler cap and tube
Replacement
Engine oil filter assembly
M548A1
Replacement         0145 00-1
M548A3
Replacement
Engine oil filter element and cover
M548A3
Replacement         0144 00-1
Engine oil filter element and parts
M548A1
Replacement
Engine oil filter element hoses and fittings
M548A3
Replacement
Engine oil gauge rod and tube
M548A1
Replacement
M548A3
Replacement         0139 00-1
$\mathbf{K} = \mathbf{K} = $

### 16

Subject	WP Sequence NoPage No.
Engine thermostat	
M548A1	
Replacement	
Engine to bulkhead fuel lines and fittings	
M548A1	
Replacement	0167 00-1
M548A3	
Replacement	0168 00-1
Equipment Description	0002 00-1
Location and Description of Major Components	0002 00-1
Exhaust	
Coolant heater system	
(M548A1), replace	0480 00-1
(M548A3), replace	
Guard	
Engine coolant/vehicle compartment heater pipes (M548A1), replace	
Vehicle compartment heater (M548A1), replace	
Exhaust check valve and ejector tube	
Air cleaner	
M548A3	
Replacement	0160 00-1
Exhaust ducts	
M548A3	
Replacement	0211 00-1
Exhaust metal hose assembly	
Vehicle compartment heater	
M548A3	
Replacement	0437 00-1
Exhaust muffler	
M548A1	
	0206.00.1
M548A3	
Replacement	0207.00.1
•	
Exhaust pipe M548A3	
	0210 00 1
Replacement	
Exhaust pipe guard	
Engine	
M548A1	0000 00 1
Replacement	
Exhaust pipes	
M548A1	000000
Replacement	
Expansion chamber (sealing)	

Subject	WP Sequence NoPage No.
Fuel compartment	
Repair	0175 00-1
Expendable/Durable Supplies and Materials List	
Eye, lifting, replace	
$\mathbf{F}$	
Fan drive belt idler adjusting linkage	
M548A1	
Replacement	0230 00-1
Fan drive belt idler pulley	
M548A1	0000 00 1
Replacement	0228 00-1
Fan drive belts	
M548A1	
Replacement	0226 00-1
Fan jackshaft pulleys	
M548A1	0221.00.1
Replacement	0231 00-1
Fan pulley M548A1	
	0224 00 1
Replacement	
Fiberglass cover      Cab, replace	0456 00 1
Hatch, machine gun, replace	
Filter element	
Air cleaner	
M548A3	
Replacement	0156 00 1
Servicing	
Filter indicator assembly	0155 00-1
Air cleaner	
M548A1	
Replacement	0154 00-1
Filtered air hose	
NBC	
M548A3	
Replacement	
Final drive	
Replacement	0326 00-1
Final drive gauge rod	
Replacement	0328 00-1
Final drive pinion oil seal	
Replacement	0327 00-1
Final drive shafts	

### INDEX, cont'd

Subject

WP Sequence No.-Page No.

M548A3
Replacement
Final drive vent, filler tube, and fittings (left side)
Replacement
Final drive vent, filler tube, and fittings (right side)
Replacement
Fittings
Air
M548A1
Replacement
Brake, pivot steering (M548A1), replace
Coolant
M548A3
Replacement
Drive shaft lubrication
M548A1
Replacement
Oil
M548A1
Replacement
Vehicle compartment heater
Kit I (M548A1), replace
Kit II or III (M548A1), replace
Fixtures, Common Tools, and Supplements List
Flasher
Replacement
Floor plates
Cab
M548A1
Removal/installation
Cargo compartment, raise/lower
Covers, cargo compartment heater kit, replace
Floor plates, door, and seat support
Cab
M548A3
Replacement
Frame
Windshield, replace
Front step
Replacement
Front wiring harness
Turn signal
Replacement
Fuel compartment

Subject	WP Sequence NoPage No.
Drain	0162 00-1
Removal/installation	0163 00-1
Fuel compartment expansion chamber (sealing)	
Repair	
Fuel compartment expansion tank vent tubes, hoses, and fittings	
Replacement	0174 00-1
Fuel compartment tubes, hoses, and fittings	
M548A3	
Replacement	0166 00-1
Fuel control shaft and linkage	
M548A3	
Replacement	0202 00-1
Fuel cutoff control cable assembly	
M548A3	
Replacement	0205 00-1
Fuel cutoff hand control	
Adjustment	0195 00-1
M548A1	
Replacement	0194 00-1
Fuel filler cap and strainer	
Replacement	0164 00-1
Fuel filler tubes, hoses, and fittings	
Replacement	0165 00-1
Fuel filter	
Elements, primary and secondary	0150 00 1
(M548A3), replace	0178 00-1
Personnel heater	
M548A3	0426 00 1
Servicing	0450 00-1
M548A1	
Replacement	0176 00-1
Secondary	0170 00-1
M548A1	
Replacement	0177 00-1
Fuel filter elements	
Primary and secondary	
M548A1	
Replacement	0179 00-1
Fuel hoses	
Vehicle compartment heater	
Kit I (M548A1), replace	0444 00-1
Kit II or III (M548A1), replace	0445 00-1

### INDEX, cont'd

WP Sequence No.-Page No.

Fuel hoses to fuel filter	
Vehicle compartment heater	
M548A3	
Replacement	0439 00-1
Fuel hoses to separator filter	
Vehicle compartment heater	
M548A3	
Replacement	0439 00-1
Fuel level	
Gauge, replace	0266 00-1
Fuel level transmitter	
Replacement	0169 00-1
Fuel lines and fittings	
Engine to bulkhead	
M548A1	
Replacement	0167 00-1
M548A3	
Replacement	0168 00-1
Fuel pump	
Circuit breaker, electric (M548A3), replace	0272 00-1
Engine	
Flow test	0147 00-1
M548A1	
Replacement	0149 00-1
M548A3	
Replacement	0150 00-1
Switch, replace	0261 00-1
Vehicle compartment heater	
Kit I (M548A1), replace	0448 00-1
M548A3	
Replacement	0430 00-1
Servicing	0429 00-1
Fuel pump wiring harness	
M548A3	
Replacement	0302 00-1
Fuel pumps	
Electric	
Flow test	0148 00-1
Replacement	
Fyr-Fyter control valve	
Replacement	0527 00-1
-	

G

Gasket

Subject

### INDEX, cont'd

WP Sequence No.-Page No.

Subject

Differential M548A1	
Replacement	11 00 1
*	14 00-1
Gauge Battery-generator, replace	ss 00 1
Coolant temperature, replace	
Fuel level. replace	
Gauge rod	0 00-1
Final drive	
Replacement	28 00-1
General Information	
Generator	)1 00 I
100 amp (M548A1), replace	42.00-1
Drive belts	12 00 1
Adjusting linkage	
(M548A1), replace	43 00-1
(M548A3), replace	
(M548A1)	
Adjust	41 00-1
Replace	
(M548A3), replace/adjust	
Field switch, replace	
(M548A3), replace	
Mount	
(M548A1), replace	44 00-1
(M548A3), replace	48 00-1
Regulator	
Adjust	49 00-1
Ground lead (M548A3), replace	51 00-1
Mount	
(M548A3), replace	52 00-1
Regulator/Mount	
(M548A1), replace	50 00-1
Wiring harness (to regulator)	
(M548A1), replace	€ 00-1
Generator to regulator wiring harness	
M548A3	
Replacement	<del>)</del> 6 00-1
Governor	
Air brake	
M548A1	
Replacement	<del>)</del> 0 00-1
Governor assembly	
M548A3	

22

Subject	WP Sequence NoPage No.
Replacement	0317 00-1
Governor throttle arm	
Engine	
M548A1	
Adjustment	0198 00-1
Ground lead	
Engine	
M548A3	
Replacement	0300 00-1
Ground lead (M548A3)	
Generator regulator	
replace	0251 00-1
Guard	
Engine coolant/vehicle compartment heater exhaust pipes (M548A1), replace .	0479 00-1
Vehicle compartment heater exhaust (M548A1), replace	
Н	
Hand throttle control	
Replacement	0192 00-1
Hand throttle control cable	
Adjustment	0193 00-1
Handles/linkage, cab door, replace	0386 00-1
Harness and igniter cable	
Air box heater	
M548A1	
Replacement	0182 00-1
Harness and ignition cable	
Air box heater	
M548A3	
Replacement	0183 00-1
Headlights	
Blackout, replace	0275 00-1
Infrared, replace	0277 00-1
Service, replace	
Heater	
NBC, M3 (M548A3), replace	0532 00-1
High beam indicator light	
Bulb, replace	0258 00-1
Replace	0257 00-1
Hoist assembly	
Repair	0485 00-1
Hoist, material handling kit	
Replace	0484 00-1
Hook	

Subject	WP Sequence NoPage No.
Towing, replace	0376 00-1
Horn	
Replace	0289 00-1
Switch, replace	0259 00-1
Hose	
Drive shaft lubrication	
M548A1	
Replacement	
Engine crankcase breather	
Replacement	0137 00-1
Hose and clamps	
Air cleaner	
M548A1	
Replacement	
Hose, fittings, and bearings	
Drive shaft lubrication	
M548A1	
Replacement	0237 00-1
Hoses	
Air	
M548A1	
Replacement	0495 00-1
Brake, pivot steering (M548A1), replace	
Coolant	
M548A3	
Replacement	0220.00.1
Engine oil filter	0141.00.1
(M548A1), replace	0141 00-1
M548A1	0406 00 1
Replacement	0496 00-1
Vehicle compartment heater	0452 00 1
Kit I (M548A1), replace	
Kit II (M548A1), replace	
Kit III (M548A1), replace	0454 00-1
Hoses and fittings	
Engine oil filter element	
M548A3	
Replacement	0142 00-1
Hoses, tubes, and fittings	
Air box heater	
M548A1	
Replacement	0180 00-1
M548A3	

Subject	WP Sequence NoPage No.
Replacement	0181 00-1
Hub	
Idler wheel	
Replacement	0355 00-1
Road wheel	
Replacement	0352 00-1
Hull bottom access cover and drain cover, replace	0383 00-1
Hull by welding	
Repair	0406 00-1
I	
Identification plate	
Defroster fan	
Vehicle compartment heater	
Replacement	0433.00.1
Idler adjusting linkage	
Fan drive belt	
M548A1	
	0220.00.1
Replacement	
Cooling fan	
M548A3	0000 00 1
Replacement	
Idler arm support	
Cooling fan	
M548A3	
Replacement	0233 00-1
Idler pulley	
Cooling fan	
M548A3	
Replacement	0229 00-1
Fan drive belt	
M548A1	
Replacement	0228 00-1
Idler pulley and adjusting bracket	
Coolant pump	
Replacement	0225 00-1
Idler wheel	
Replacement	0360 00-1
Idler wheel arm assembly	
Replacement	0354 00-1
Idler wheel bearings and seals	
Replacement	0355 00-1
Idler wheel hub	

Subject	WP Sequence NoPage No.
Replacement	0355 00-1
Ignition coil	
Air box heater	
M548A1	
Replacement	0184 00-1
Ignition coil, air pump, and check valve	
Air box heater	
M548A3	
Replacement	0185 00-1
Indicator	
High beam	
Light bulb, replace	
Replace	0257 00-1
Indicator and hose	
Air cleaner	
M548A3	<b>.</b>
Replacement	
Infrared headlights, replace	
Infrared-blackout select switch, replace	0260 00-1, 0263 00-1
Instrument panel	
Air brake M548A1	
Replacement	0501.00.1
Removal/installation (partial)	
	0250 00-1
Cargo door, replace	0469 00-1
Lower cab, replace	
J	
Jackshaft pulleys	
Fan	
M548A1	
Replacement	
К	
Kit	
Air pumpvane	
Replacement	0100.00.1
Material handling, removal/installation	
	0482 00-1
L	
Left final drive shaft	
M548A1	
Replacement	0333 00-1

Subject	WP Sequence NoPage No.
Lever	
Clutch	
M548A1	
Replacement	
Lifting eye, replace	
Light	
Blackout marker	
Replacement	0506 00-1
Blackout marker, replace	
Cab dome, replace	
High beam indicator	
Bulb, replace	
Replace	
Panel, replace	
Switch, replace	
Turn signal	
Replacement	0505 00-1
Lining, brake, pivot steering (M548A1), replace	0375 00-1
Linkage	
Accelerator	
M548A3	
Adjustment	0200 00-1
Brake, pivot steering (M548A1)	
Adjustment	
Steering (M548A1), replace	0366 00-1
Steering wheel (M548A3)	
Adjustment	
Replace	0364 00-1
Throttle pedal	
M548A1	
Replacement	0197 00-1
Windshield wiper	
Replacement	
List of Abbreviations	0001 00-1
Lock handle	
Drum	
M548A1	0411.00.1
Replacement	0411 00-1
Low pressure warning light	
Air M548A1	
M548A1	0503 00 1
Replacement	
Lubrication hose, fittings, and bearings	
Drive shaft	

Subject	WP Sequence NoPage No.
M548A1	
Replacement	0237 00-1
$\mathbf{M}$	
M18 filter	
NBC	
M548A3	
Replacement	0536 00-1
M19 particulate filter unit NBC	
M548A3	
Replacement	
M1A1-19 precleaner assembly and frame	
NBC	
M548A3	
Removal/installation	
M3 heater, NBC (M548A3), replace	
M66 ring mount kit	
Replacement	
Maintenance Allocation Chart (MAC)	
Maintenance Forms, Records, and Reports	
Manifold, NBC (M548A3), repair	
Master cylinder, brake, pivot steering (M548A1), replace	
Master switch	
Electrical lead (to bus bar) (M548A3), replace	
Replace	
Material handling kit	
Beam, replace	
Hoist	
Replace	
Removal/installation	
Sling, replace	
Stops	
Beam, replace	
Hoist, replace	
Supports, beam, replace	
Materials and Expendable Supplies List	0542 00-1
Modulator	
Throttle valve (TV)	
M548A3	
Adjustment	0204 00-1
Modulator and lever	
Throttle valve	
M548A3	

Subject	WP Sequence NoPage No.
Replacement	0203 00-1
Motor	
Windshield wiper	
Replacement	
Motor gear	
Windshield wiper	
Replacement	0423 00-1
Mount	
Generator	
(M548A1), replace	0244 00-1, 0250 00-1
(M548A3), replace	0248 00-1
Generator regulator	
(M548A3), replace	0252 00-1
Turn signal	
Replacement	0508 00-1
Mount, shock absorber, replace	0381 00-1
Mounts	
Transfer gearcase M548A1	
Replacement	0325 00-1
Multiple pin and socket identification	0129 00-1
Ν	
NBC (M548A3)	
M3 heater/adapter, replace	0532 00-1
Manifold, repair	0533 00-1
NBC circuit breaker and relay	
M548A3	
Replacement	0530 00-1
NBC filtered air hose	
M548A3	
Replacement	0537 00-1
NBC M18 filter	
M548A3	
Replacement	0536 00-1
NBC M19 Particulate filter unit	
M548A3	
Replacement	0535 00-1
NBC M1A1-19 precleaner assembly and frame	
M548A3	
Removal/installation	0534 00-1
NBC orifice connector assembly and bracket	
M548A3	
Replacement	0538 00-1

Subject	WP Sequence NoPage No.
NBC wiring harness from battery compartment to manifold M548A3	
Replacement	
Negative lead(s), battery, remove/install	
Neutral start switch	
Replacement	
Nomenclature Cross-Reference List	
Nozzles, tubes, and fittings	
M548A1	
Replacement	
M548A3	
Replacement	
0	
Oil filler cap and tube	
Engine	
Replacement	0140 00-1
Oil filter and oil filter element	
Differential	
M548A1	
Replacement	0337 00-1
Oil filter assembly	
Engine	
M548A1	
Replacement	0145 00-1
M548A3	
Replacement	0146 00-1
Oil filter element	
Transmission	
M548A1	
Replacement	0320 00-1
M548A3	
Replacement	0321 00-1
Oil filter element and cover	
Engine	
M548A3	
Replacement	0144 00-1
Oil filter element and parts	
Engine	
M548A1	
Replacement	0143 00-1
Oil filter element hoses and fittings	
Engine	
M548A3	

Subject	WP Sequence NoPage No.
Replacement	0142.00.1
Oil fittings	
M548A1	
	0406 00 1
Oil gauge rod and tube	
Engine	
M548A1	
Replacement	0138 00 1
M548A3	
Replacement	0139.00.1
Oil hoses	
M548A1	
Replacement	0496.00.1
Oil hoses and fittings	
Differential	
M548A1	
Replacement	0340.00.1
Transmission	
M548A1	
Replacement	0318 00 1
M548A3	
Replacement	0319.00.1
Oil hoses/fittings	
Engine filter	
(M548A1), replace	01/11 00-1
Oil level gauge rod	
Differential	
M548A1	
Replacement	0339.00.1
Oil level gauge rod and filler neck	
Transfer gearcase	
M548A1	
Replacement	0331.00.1
Oil level gauge rod, filler tube, and adapter	
Transmission	
M548A3	
Replacement	0305 00-1
Oil pump	
Differential	
M548A1	
Replacement	0336.00.1
Oil sampling valve, guard, and pressure switch	055000-1
Transmission	
M548A3	

Subject	WP Sequence NoPage No.
Replacement	0323 00 1
Orifice connector assembly and bracket	0525 00-1
NBC	
M548A3	
Replacement	0538.00.1
Outlet, utility, replace	
Р	
Panel	
Center seat (M548A1), replace	
Lights, replace	
Panel assembly	
Portable fire extinguisher	
M548A3	
Replacement/repair	
Panel light	
Air brake	
M548A1	
Replacement	0504 00-1
Parking brake	
M548A3	
Adjustment	0345 00-1
Parking brake cable assembly	
M548A3	
Replacement	0346 00 1
Parking brake control lever	
M548A3	
	0246 00 1
Replacement	
Personnel heater fuel filter	
M548A3	0.126.00.1
Servicing	0436 00-1
Personnel safety belt	
Replacement	0486 00-1
Personnel seat	
Covers, cargo compartment heater kit, replace	0471 00-1
Personnel seats	
Replacement	0486 00-1
Pin	
Quick release, steering wheel (M548A3), replace	
Pin, shock absorber, replace	0380 00-1
Pinion oil seal	
Final drive	
Replacement	0327 00-1
Pintle, towing, repair/replace	0377 00-1

### INDEX, cont'd

Subject

WP Sequence No.-Page No.

ivot steering brake (M548A1)	
Brake assembly, replace	373 00-1
Controls/linkage	
Adjustment	370 00-1
Replace	369 00-1
Disk, clutch, replace	374 00-1
Lining, replace	375 00-1
Master cylinder, replace	371 00-1
lates	
Rear tiedown	
Replace	378 00-1
lates, stencils, decals, rubber pads, and straps	
Replacement	440 00-1
ortable fire extinguisher panel assembly	
M548A3	
Replacement/repair	529 00-1
ower plant	
Access cover seal, right rear, replace	389 00-1
M548A1	
Block	132 00-1
Removal/installation	130 00-1
M548A3	
Block	133 00-1
Removal/installation	131 00-1
ower plant sling	
Inspection	443 00-1
ower plant wiring harness	
M548A3	
Replacement	298 00-1
ower takeoff	
M548A1	
Replacement	415 00-1
ower takeoff control	
Winch	
M548A1	
Replacement	414 00-1
reparation for Storage and Shipment	
ressure indicator	
Air brake	
M548A1	
Replacement	503 00-1
ressure switch and bypass plug	
Differential	
M548A3	

Subject	WP Sequence NoPage No.
Replacement	0324 00-1
Preventive Maintenance Checks and Services (PMCS), Including Lubrication Instruct	ions
Semi-Annual	0128 00-1
Preventive Maintenance Checks and Services (PMCS), Including Lubrication Instruct	ions
Annual	0128 00-1
Primary and secondary fuel filter elements	
M548A1	
Replacement	0179 00-1
Primary fuel filter	
M548A1	0156.00.1
Replacement	0176 00-1
Propeller shaft Winch	
M548A1	
Replacement	0412 00-1
Pump	0412 00-1
Bilge	
Replacement	
Coolant	
Engine coolant heater, replace	
M548A1	
Replacement	0221 00-1
M548A3	
Replacement	0222 00-1
0	
Quick release pin, steering wheel (M548A3), replace	0363 00 1
Quick release pin, steering wheel (191346A3), replace	0505 00-1
R	
Radiator and seals	
M548A3	
Replacement	
Radiator auxiliary tank	
M548A3	
Replace	0217 00-1
Radiator tubes, hoses, and fittings	
M548A1	0010 00 1
Replacement	
Radiator/seal         (M548A1), replace	0215 00 1
(M548A1), replace	
Transmission	
M548A1	
Adjustment	0316 00-1

# INDEX, cont'd

Subject	WP Sequence NoPage No.
Range selector linkage	
Transmission	
M548A1	
Replacement	0315 00-1
Rear tiedown plates	
Replace	
Rear wiring harness	
Turn signal	
Replacement	
References	
Reflector	
Replacement	
Regulator	
Generator	
Ground lead (M548A3), replace	
(M548A1), replace	
Relay	
Starter (M548A3), replace	
Reporting of Equipment Improvement Recommendations (EIR)	
Reservoir	
Air brake	
M548A1	
Replacement	
Rifle rack	
Replacement	
Right final drive shaft	
M548A1	
Replacement	
Right seat	
M548A1	
Removal/installation	
Road wheel	
Replacement	
Road wheel hub	
Replacement	
Road wheel support arm bumper stop	
Replacement	
Road wheel support arm support	
Replacement	
Road wheel support arm, housing, bearings, and seals	
Replacement	

## S

Safety belts

Subject	WP Sequence NoPage No.
Replacement	0399 00-1
Safety brake	
Drum	
M548A1	
Adjustment	0409 00-1
Safety valve	
Air brake	
M548A1	
Replacement	
Scope	
Seals	
Cab door, replace	
Cargo door	
Replacement	
Seat	
Driver's	
Replacement	
Right	
M548A1	
Removal/installation	
Seat support	
Center	
M548A1	
Replacement	
Seats	
Cab personnel	
Replacement	
Secondary fuel filter	
M548A1	
Replacement	0177 00-1
Service headlights, replace	
Service Upon Receipt	0127 00-1
Shaft	
Left final drive	
M548A1	
Replacement	0333 00-1
Right final drive	
M548A1	
Replacement	0334 00-1
Shaft and linkage	
Fuel control	
M548A3	
Replacement	0202 00-1
Shafts	

Subject	WP Sequence NoPage No.		
Final drive			
M548A3			
Replacement	0335 00-1		
Shift control			
Transmission			
M548A3			
Replacement	0306 00-1		
Shift control lamp			
Transmission			
M548A3	0207.00.1		
Replacement       Shift control switch	030/00-1		
Transmission			
M548A3			
Replacement	0309 00-1		
Shock absorber			
Mount, replace			
Pin, replace			
Replace	0379 00-1		
Shoe			
Drum brake			
M548A1			
Adjustment	0408 00-1		
Shoe and pad assembly			
Track			
Replacement	0359 00-1		
Sight gauge			
Drain cap and M548A3			
Replacement	0239.00.1		
Sling	0259 00-1		
material handling kit, replace	0484 00-1		
Power plant			
Socket identification, multiple pin			
Solenoid valve			
Air box heater			
M548A1			
Replacement	0186 00-1		
M548A3			
Replacement	0187 00-1		
Speedometer			
Replace	0516 00-1		
Speedometer cable			

Subject	WP Sequence NoPage No.
Replacement	
Speedometer cable housing and adapter	
Replacement	
Start switch, replace	
Starter	
(M548A1), replace	
(M548A3), replace	
Relay (M548A3), replace	
Steering	
Control/linkage (M548A1)	
Replace	0366 00-1
Controls (M548A1)	
Adjustment	0367 00-1
Transmission	
M548A3	
Adjustment	0312 00-1
Wheel (M548A3)	
Column/housing/shaft, replace	
Linkage	
Adjustment	0362 00-1
Replace	
Quick release pin/bracket, replace	
Step	
Front	
Replacement	
Stoplight	
Switch, replace	
Stoplight switch	
M548A1	
Replacement	
Stoplight-taillight	
Blackout	
Replacement	
Stoplight-taillights, replace	
Stops	
Beam, material handling kit, replace	
Hoist, material handling kit, replace	
Strainer	
Air	
M548A1	
Replacement	
Supplements, Fixtures, and Common Tools List	
Support	
Beam, material handling kit, replace	

### INDEX, cont'd

Subject	WP Sequence NoPage No.		
Support arm bumper stop			
Road wheel			
Replacement	0353 00-1		
Support arm support			
Road wheel			
Replacement	0353 00-1		
Support arm, housing, bearings, and seals			
Road wheel			
Replacement	0351 00-1		
Switch			
Air box heater, replace			
Air low pressure			
M548A1			
Replacement			
Beam selector, replace			
Bilge pump, replace			
Differential oil high temperature			
(M548A1), replace			
Engine oil low pressure (M548A1), replace			
Fuel pump, replace			
Generator field, replace			
Horn, replace			
Infrared-blackout select, replace			
Infrared-blackout selector, replace			
Light, replace			
Master, replace	0271 00-1		
Neutral start	0000 00 1		
Replacement			
Start, replace	0259 00-1		
Stoplight			
M548A1	0.402.00.1		
Replacement			
Stoplight, replace			
Transmission oil high temperature	0000001		
(M548A1), replace			
(M548A3), replace			
Windshield wiper, replace	0260 00-1		
Switch lead			
Differential			
M548A1	0010 00 1		
Replacement	0343 00-1		

### Т

Tachometer

Subject	WP Sequence NoPage No.
Replacement	0519 00-1
Tachometer cable	
M548A1	
Replacement	0522 00-1
M548A3	
Replacement	0523 00-1
Tachometer cable housing and adapter	
M548A1	0520.00.1
Replacement	
Replacement	0521 00-1
Tailgate controls	
Replacement	0404 00-1
Tailgate end seals and bumpers	0.405.00.1
Replacement	0405 00-1
Tank Air concretor	
Air separator M548A1	
Replacement	0170 00 1
M548A3	
Replacement	0171 00-1
Tension adjuster and mount Track	
Replacement	
Theory of Operation	
Thermal door windows, replace	0461 00-1
Thermostat	
Engine	
M548A1	
Replacement	0218 00-1
Throttle pedal control	
M548A1	0106.00.1
Replacement	0196 00-1
M548A3 Replacement	0201.00.1
Throttle pedal detent	
M548A1	
Replacement	0196 00-1
Throttle pedal linkage M548A1	
Replacement	0197 00-1
Throttle pedal to full throttle and idle positions	
M548A1	
Adjustment	0199 00-1

Subject	WP Sequence NoPage No.			
Throttle valve (TV) modulator				
M548A3				
Adjustment				
Throttle valve modulator and lever				
M548A3				
Replacement				
To full throttle and idle positions				
Throttle pedal				
M548A1				
Adjustment	0199 00-1			
Toggle switches				
Defroster fan				
Vehicle compartment heater				
Replacement	0433 00-1			
Torsion bar				
Replace	0349 00-1			
Torsion bar anchor				
Replacement	0350 00-1			
Tow start cable				
M548A3				
Replacement	0310 00-1			
Tow start cable assembly				
M548A3				
Adjustment	0311 00-1			
Tow start cover				
M548A3				
Replacement	0310 00-1			
Towing				
Eye and hook, replace	0376 00-1			
Pintle, repair/replace	0377 00-1			
Track				
Replacement	0358 00-1			
Track shoe and pad assembly				
Replacement	0359 00-1			
Track tension adjuster and mount				
Replacement	0356 00-1			
Trailer wiring harness				
Replacement	0301 00-1			
Transfer gearcase				
Winch				
M548A1				
Replacement	0413 00-1			
Transfer gearcase mounts				
M548A1				

Subject	WP Sequence NoPage No.
Replacement	0325 00-1
M548A1	
Replacement	0331 00-1
Transmission	
Differential test switch, replace	0260 00-1
Oil high temperature switch	
(M548A1), replace	0286 00-1
(M548A3), replace	0287 00-1
Transmission AOAP valve, hose, and bracket	
M548A1	
Replacement	0322 00-1
Transmission brake adjustment	
M548A3	
Check	0313 00-1
Transmission brakes	
M548A3	
Adjustment	0314 00-1
Transmission oil filter element	
M548A1	0000 00 1
Replacement	0320 00-1
M548A3	
Replacement	0321 00-1
Transmission oil hoses and fittings	
M548A1	0210 00 1
Replacement	0318 00-1
M548A3	0210 00 1
Replacement	
Transmission oil level gauge rod, filler tube, and adapter M548A1	
	0205 00 1
Replacement	
M548A3	
Replacement	0323.00.1
Transmission range selector control and linkage	
M548A1	
Adjustment	0316.00-1
Transmission range selector linkage	
M548A1	
Replacement	0315 00-1
Transmission shift control	
M548A3	
Replacement	
Transmission shift control lamp	
*	

Subject	WP Sequence NoPage No.			
M548A3				
Replacement	0307 00-1			
Transmission shift control switch				
M548A3				
Replacement	0309 00-1			
Transmission steering				
M548A3				
Adjustment	0312 00-1			
Transmission vent tube, gauge rod, and filler neck				
M548A1				
Replacement	0304 00-1			
Transmission wiring harness				
M548A3				
Replacement	0297 00-1			
Transmission-to-differential shaft				
M548A1				
Replacement	0332 00-1			
Transmitter				
Coolant temperature				
(M548A1), replace	0283 00-1			
(M548A3), replace				
Engine low oil pressure (M548A3), replace	0282 00-1			
Fuel level				
Replacement	0169 00-1			
Transverse beam				
(M548A1), replace	0384 00-1			
Tubes				
Air				
M548A1				
Replacement	0495 00-1			
Air box drain				
M548A1				
Replacement	0135 00-1			
Coolant				
M548A3	0000 00 1			
Replacement				
Pivot steering brake (M548A1), replace	0372 00-1			
Vehicle compartment heater	0444.00.1			
Kit I (M548A1), replace $\ldots$				
Kit II or III (M548A1), replace				
Tubes, hoses, and fittings				
Air separator to fuel tank				
M548A1	0170 00 1			
Replacement	017200-1			

Subject	WP Sequence NoPage No.				
M548A3					
Replacement	0173 00-1				
Fuel compartment					
M548A3					
Replacement	0166 00-1				
Fuel filler					
Replacement	0165 00-1				
Radiator					
M548A1					
Replacement	0219 00-1				
Tubes/hoses/fittings					
Coolant					
M548A3					
Replacement	0220 00-1				
Turn signal control					
Replacement	0508 00-1				
Turn signal front wiring harness					
Replacement	0511 00-1				
Turn signal light					
Replacement	0505 00-1				
Turn signal mount					
Replacement	0508 00-1				
Turn signal rear wiring harness					
Replacement	0512 00-1				
U					
Utility outlet, replace	0265 00 1				
	0203 00-1				
$\mathbf{V}$					
Vehicle compartment heater					
Adjustment	0427 00-1				
Exhaust guard (M548A1), replace	0455 00-1				
Guard, exhaust pipes (M548A1), replace	0479 00-1				
Kit I (M548A1), replace	0446 00-1				
Kits (M548A1)					
Air ducts/hoses					
Kit I, replace	0452 00-1				
Kit II, replace	0453 00-1				
Kit III, replace	0454 00-1				
Controls cover, replace	0450 00-1				
Fuel Hoses/tubes/fittings					
Kit I, replace	0444 00-1				
Fuel hoses/tubes/fittings					
Kit II or III, replace	0445 00-1				

### INDEX, cont'd

### Subject

### WP Sequence No.-Page No.

Fuel pump
Kit I, replace
Kit II or III, replace
Heater
Kit II or III, replace
Wiring harness, replace
Repair
Servicing
Vehicle compartment heater air inlet ducts
M548A3
Replacement
Vehicle compartment heater assembly and mounting brackets
M548A3
Replacement
Vehicle compartment heater assembly fuel pump
M548A3
Replacement
Vehicle compartment heater control box
Replacement
Vehicle compartment heater defroster fan identification plate
Replacement
Vehicle compartment heater defroster fan toggle switches
Replacement
Vehicle compartment heater defroster fan wiring harness
Replacement
Vehicle compartment heater defroster, hoses, and fans
M548A3
Replacement
Vehicle compartment heater exhaust metal hose assembly
M548A3
Replacement
Vehicle compartment heater fuel hoses to fuel filter
M548A3
Replacement
Vehicle compartment heater fuel hoses to separator filter
M548A3
Replacement
Vehicle compartment heater fuel pump
Servicing
Vehicle compartment heater wiring harness
M548A3
Replacement
Vent tube, gauge rod, and filler neck
Transmission

Subject	WP Sequence NoPage No.			
M548A1				
Replacement	0304 00-1			
Vent tubes, hoses, and fittings				
Fuel compartment expansion tank				
Replacement	0174 00-1			
Vent, filler tube, and fittings (left side)				
Final drive				
Replacement	0330 00-1			
Vent, filler tube, and fittings (right side)				
Final drive				
Replacement	0329 00-1			
W				
Walter Kidde control valve				
Replacement	0528 00-1			
Welding				
Hull by				
Repair				
Wheel				
Steering (M548A3)				
Column/housing/shaft, replace	0365 00-1			
Linkage				
Adjustment	0362 00-1			
Replace	0364 00-1			
Quick release pin/bracket, replace	0363 00-1			
Winch				
M548A1				
Replacement	0407 00-1			
Winch power takeoff control				
M548A1				
Replacement	0414 00-1			
Winch propeller shaft				
M548A1				
Replacement	0412 00-1			
Winch transfer gearcase				
M548A1				
Replacement	0413 00-1			
Windows				
Door, replace	0387 00-1			
Vehicle compartment heater kit				
Cab, replace				
Thermal door, replace	0461 00-1			
Windshield wiper				
Switch, replace				

Subject	WP Sequence NoPage No.		
Windshield wiper arm and blade			
Replacement			
Windshield wiper linkage	0.401.00.1		
Replacement	0421 00-1		
Windshield wiper motor			
Replacement			
Windshield/frame, replace	0392 00-1		
Wiper motor gear	0.400.00.1		
Replacement			
Wire rope, hook, and chain			
M548A1			
Replacement			
Wiring harness			
Defroster fan			
Vehicle compartment heater			
Replacement			
Engine coolant heater, replace			
Fuel pump			
M548A3			
Replacement	0302 00-1		
Generator to regulator			
(M548A1), replace			
M548A3			
Replacement			
Power plant			
M548A3			
Replacement			
Repair			
Trailer			
Replacement	0301 00-1		
Transmission			
M548A3			
Replacement			
Vehicle compartment heater			
(M548A1), replace			
M548A3			
Replacement			
Wiring harness from battery compartment to manifold			
NBC			
M548A3			
Replacement			

By Order of the Secretary of the Army:

ERIC K. SHINSEKI General, United States Army Chief of Staff

Official

JOEL B. HUDSON Administrative Assistant to the Secretary of the Army 0105107

#### **DISTRIBUTION:**

To be distributed in accordance with the initial distribution number (IDN) 370825, requirements for TM 9-2350-247-20-1.

RECOMMENDED CHANGES TO PUBLICATION BLANK FORMS For use of this form, see AR 25-30; the proponent agency is OAA						Special To	ol Lists	e) for Repair Parts and (RPSTL) and Supply Januals (SC/SM).	DATE	
<b>TO:</b> (Forward to proponent of publication or form) (Include					ZIP Code)	FROM: (Activity and location) (Include ZIP Code)			Code)	
		F	PART I - A	ALL PUBLI	CATIONS	(EXCEPT R		SC/SM)	AND BLANK FORMS	
PUBLICATION/FORM NUMBER						DATE		TITLE		
ITEM	PAGE	PARA- GRAPH	LINE	FIGURE NO.	TABLE		RE	COMM	ENDED CHANGES AND F	REASON
* Reference to line numbers							<i>in the parag</i> ANGE/AUT(		subparagraph. SIGNATURE	
TYPED NAME, GRADE OR TITLE TELEPH PLUS E					XTENSION		0 v 0 N,	GIGINATORE		

TO: (Fo	rward dii	rect to add	dressee listed in publicat	tion)	FROM:	(Activity	and loca	ntion) (I	Include ZIP (	Code)	DATE	
	PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS											
PUBLICA	TION N				DATE			TITLE				
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER		REFERENCE NO.		ITEM NO.	OF N IT	PTAL NO. MAJOR RECOMMENDED AC ITEMS PPORTED		CTION	
	PAI	RT III - REI									ublications an	d
	PART III - REMARKS (Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)											
TYPED NAME, GRADE OR TITLE T					ONE EX( (TENSIO	CHANGE/A )N	UTOVO	VON, SIGNATURE				

RECO	For use of thi		NK FOR	MS			Special To	ol Lists	e) for Repair Parts and (RPSTL) and Supply Januals (SC/SM).	DATE
TO: (For	ward to pro	oublicatio	n or form)	(Include	ZIP Code)	FROM: (A	Code)			
		F	PART I - A	ALL PUBLI	CATIONS	(EXCEPT R	PSTL AND	SC/SM)	AND BLANK FORMS	
PUBLICA	TION/FORM	M NUMBER				DATE		TITLE		
ITEM	PAGE	PARA- GRAPH	LINE	FIGURE NO.	TABLE		RE	COMM	ENDED CHANGES AND F	REASON
TVDED		ידוד מס		Reference			<i>in the parag</i> ANGE/AUT(		<i>subparagraph.</i> SIGNATURE	
TYPED NAME, GRADE OR TITLE TELEPH PLUS E						XTENSION			JIGINATORE	

TO: (Fo	rward dii	rect to add	dressee listed in publicat	tion)	FROM:	(Activity	and loca	ntion) (I	Include ZIP (	Code)	DATE	
	PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS											
PUBLICA	TION N				DATE			TITLE				
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER		REFERENCE NO.		ITEM NO.	OF N IT	PTAL NO. MAJOR RECOMMENDED AC ITEMS PPORTED		CTION	
	PAI	RT III - REI									ublications an	d
	PART III - REMARKS (Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)											
TYPED NAME, GRADE OR TITLE T					ONE EX( (TENSIO	CHANGE/A )N	UTOVO	VON, SIGNATURE				

RECO	For use of thi		NK FOR	MS			Special To	ol Lists	e) for Repair Parts and (RPSTL) and Supply Januals (SC/SM).	DATE
TO: (For	ward to pro	oublicatio	n or form)	(Include	ZIP Code)	FROM: (A	Code)			
		F	PART I - A	ALL PUBLI	CATIONS	(EXCEPT R	PSTL AND	SC/SM)	AND BLANK FORMS	
PUBLICA	TION/FORM	M NUMBER				DATE		TITLE		
ITEM	PAGE	PARA- GRAPH	LINE	FIGURE NO.	TABLE		RE	COMM	ENDED CHANGES AND F	REASON
TVDED		ידוד מס		Reference			<i>in the parag</i> ANGE/AUT(		<i>subparagraph.</i> SIGNATURE	
TYPED NAME, GRADE OR TITLE TELEPH PLUS E						XTENSION			JIGINATORE	

TO: (Fo	rward dii	rect to add	dressee listed in publicat	tion)	FROM:	(Activity	and loca	ntion) (I	Include ZIP (	Code)	DATE	
	PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS											
PUBLICA	TION N				DATE			TITLE				
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER		REFERENCE NO.		ITEM NO.	OF N IT	PTAL NO. MAJOR RECOMMENDED AC ITEMS PPORTED		CTION	
	PAI	RT III - REI									ublications an	d
	PART III - REMARKS (Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)											
TYPED NAME, GRADE OR TITLE T					ONE EX( (TENSIO	CHANGE/A )N	UTOVO	VON, SIGNATURE				

### METRIC CONVERSION CHART

#### APPROXIMATE CONVERSION FACTORS

### **TO CHANGE**

#### TO

### **MULTIPLY BY** 2.540

Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	0.914
Miles	Kilometers	1.609
Square Inches	Square Centimeters	6.451
Square Feet	Square Meters	0.093
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	0.405
Cubic Feet	Cubic Meters	0.028
Cubic Yards	Cubic Meters	0.765
Fluid Ounces	Milliliters	29.573
Pints	Liters	0.473
Quarts	Liters	0.946
Gallons	Liters	3.785
Ounces	Grams	28.349
Pounds	Kilograms	0.454
Short Tons	Metric Tons	0.907
Pound-Feet	Newton-Meters	1.356
Pounds per Square Inch	Kilopascals	6.895
Miles per Gallon	Kilometers per Liter	0.425
Miles per Hour	Kilometers per Hour	1.609

#### **TO CHANGE**

Centimeters	Inches
Meters	Feet
Meters	Yards
Kilometers	Miles
Square Centimeters	Square Inches
Square Meters	Square Feet
Square Meters	Square Yards
Square Kilometers	Square Miles
Square Hectometers	Acres
Cubic Centimeters	Cubic Inches
Cubic Meters	Cubic Feet
Cubic Meters	Cubic Yards
Milliliters	Fluid Ounces
Liters	Pints
Liters	Quarts
Liters	Gallons
Grams	Ounces
Kilograms	Pounds
Metric Tons	Short Tons
Newton-Meters	Pound-Feet
Kilopascals	Pounds per Square Inch .
Kilometers per Liter	Miles per Gallon
Kilometers per Hour	Miles per Hour

# TO

#### **MULTIPLY BY**

Inches	0.394
Feet	3.280
Yards	1.094
Miles	0.621
Square Inches	0.155
Square Feet	10.764
Square Yards	1.196
Square Miles	0.386
Acres	2.471
Cubic Inches	0.060
Cubic Feet	35.315
Cubic Yards	1.308
Fluid Ounces	0.034
Pints	2.113
Quarts	1.057
Gallons	0.264
Ounces	0.035
Pounds	2.205
Short Tons	1.102
Pound-Feet	0.738
Pounds per Square Inch	0.145
Miles per Gallon	2.354
Miles per Hour	0.621

#### **TEMPERATURE CONVERSIONS**

5/9 (°F - 32) = °C212° Fahrenheit is equivalent to 100° Celsius 90° Fahrenheit is equivalent to 32.2° Celsius 32° Fahrenheit is equivalent to 0° Celsius  $9/5 C^{\circ} + 32 = F^{\circ}$ 

PIN: 073084-000