


**UNIT MAINTENANCE MANUAL  
FOR  
HULL SYSTEMS  
AND  
COMPONENTS**



**HOWITZER, MEDIUM,  
SELF-PROPELLED:  
155MM, M109A6  
(NSN 2350-01-305-0028)  
(EIC:3FC)**

TABLE OF CONTENTS	i	
HOW TO USE THIS MANUAL	iv	
INTRODUCTION	1-1	
GENERAL MAINTENANCE	2-1	
TROUBLESHOOTING	3-1	
POWERPACK	4-1	
FUEL SYSTEM	5-1	
EXHAUST SYSTEM	6-1	
COOLING SYSTEM	7-1	
ALPHABETICAL INDEX	INDEX-1	


Distribution Statement A: Approved for public release; distribution is unlimited.

© 1997 United Defense, L.P. All rights reserved under the copyright laws.

This material may be reproduced for U.S. Government purposes only, pursuant to the copyright license under the clause at (DFARS 52.227-7013) dated October 1988.

**WARNING**

## RADIOACTIVE MATERIAL(S)



### TRITIUM (HYDROGEN-3) GAS

This item contains radioactive material. Control of this radioactive material is mandated by federal law. Immediately report any suspected lost or damaged items to your Radiation Safety Officer (RSO). If your RSO cannot be reached, contact the TACOM-RI safety office.

Handle with care. In the event the radioluminous source is broken, cracked, or there is no illumination, immediately wrap device in plastic bag (item 5, Appendix D) and notify the local RSO. Contact the base safety office for the name and telephone number of your local RSO:

LOCAL RSO: \_\_\_\_\_ TELEPHONE: \_\_\_\_\_

#### SAFETY PROCEDURES FOR NUCLEAR REGULATORY COMMISSION (NRC) TRITIUM FIRE CONTROL DEVICES

1. Purpose: To implement mandatory license requirements for use and maintenance of tritium radioluminous fire control devices used on howitzers, mortars, tanks, and rifles.
2. Scope: This procedure is applicable to all personnel working with tritium devices, including unit, direct support, general support maintenance, and operator levels.
3. Radiological hazard: The beta radiation emitted by tritium presents no external radiation hazard. However, if taken internally, it can damage soft tissue. If a capsule is broken, the tritium gas will dissipate into the surrounding air, and surfaces near the vicinity of the break may become contaminated. Tritium can be taken into the body by inhalation, ingestion, or skin absorption/injection.
4. Safety precautions:
  - a. Check for illumination prior to use or service in low light or darkroom. If not illuminated, do not repair. Wrap the entire device in plastic bag (item 11, Appendix C) and notify the local RSO.
  - b. No eating, drinking, or smoking will be allowed in tritium device work areas.
5. Emergency procedures: If a tritium source breaks, inform other personnel to vacate the area or move upwind. If skin contact is made with any area contaminated with tritium, wash immediately with nonabrasive soap and water. Report the incident to the local RSO. Actions below will be taken under supervision or direction of the local RSO.

TM 9-2350-314-20-1-1

- a. Personnel handling the device should wear rubber or latex gloves (item 20, Appendix C). Device must be immediately double wrapped in plastic (item 11, Appendix C), sealed with tape (item 63, Appendix C), and marked as "Broken Tritium Device — Do Not Open" per RSO direction. Dispose of used gloves as radioactive waste, per instructions from local RSO and wash hands well.
- b. Personnel who may have handled the broken tritium should report to health clinic for tritium bioassay. Optimum bioassay sample is at least 4 hours after exposure.
- c. Broken tritium sources indoors may result in tritium contamination in the area, such as work bench or table. The area must be cordoned off, restricted until wipe tests indicate no contamination.


6. Further information:

- a. Requirements for safe handling and maintenance are located in TM 9-254, General Maintenance Procedures for Fire Control Materiel.
- b. If assistance is needed, contact your local or major command (MACOM) safety office(s) for information on safe handling, shipping, storage, maintenance, or disposal of radioactive devices.
- c. The TACOM-RI RSO/licensee may be contacted by calling: DSN 793-2965/2969/2995, Commercial (309) 782-2965/2969/2995. After duty hours contact the Staff Duty Office through the operator at DSN 793-6001, Commercial (309) 782-6001. The following rules and regulations are available from TACOM-RI, ATTN: AMSTA-LC-SF, 1 Rock Island Arsenal, Rock Island, IL 61299-7630. Copies may be requested, or further information obtained by contacting the TACOM-RI Radiation Safety Office (RSO).
  - (1) Title 10 CFR Part 19 - Notices, Instructions, and Reports to Workers.
  - (2) Title 10 CFR Part 20 - Standards for Protection Against Radiation.
  - (3) Title 10 CFR Part 21 - Reporting of Defects and Noncompliance.
  - (4) NRC License, License Conditions, and License Application.

7. Safety, Care, and Handling:

**WARNING**

Nuclear, Biological, and Chemical (NBC) agents can kill you. If NBC exposure is suspected, all air filter media must be handled by personnel wearing full NBC protective equipment (FM 21-11).



## RADIATION HAZARD

Fire control instruments containing Tritium are used as a part of a backup system for manual firing. Loss of illumination may indicate that leakage has occurred. Do not attempt to repair a non-illuminated device.

### Pre-Maintenance Check:

- a. Prior to taking any maintenance action on fire control devices (e.g., purging or charging M1A1 Collimator), check for broken/cracked reticle or loss of illumination as follows:
  - (1) Place device in the dark for at least four hours to prevent exterior light from activating the phosphor.
  - (2) Check for cracks/illumination in a low light environment after allowing sufficient time to accustom eyes to the dark.
- b. If illumination is not observed, or illuminated but cracks are observed, take following actions:
  - (1) Personnel handling the device should wear rubber or plastic gloves (item 20, Appendix C).
  - (2) Seal entire device in two plastic bags (item 11, Appendix C).
  - (3) Mark the outer bag as "Broken Tritium Device - Do Not Open."
  - (4) Dispose of used gloves as radioactive waste as per instructions from local Radiation Safety Officer (RSO). Wash hands well with nonabrasive soap and water. ■
- c. If illumination is observed, maintenance actions may proceed.



**WARNING**

**CARBON MONOXIDE POISONING IS DEADLY**

Carbon monoxide is a colorless, odorless, deadly poisonous gas, which, when breathed, deprives the body of oxygen and causes suffocation. Exposure to carbon monoxide produces headache, dizziness, loss of muscular control, drowsiness, and coma. Permanent brain damage or death can result from severe exposure.

Carbon monoxide occurs in the exhaust of fuel-burning heaters and internal-combustion engines and becomes dangerously concentrated under conditions of inadequate ventilation. The following precautions must be observed to insure the safety of personnel whenever the personnel heater, main, or auxiliary engine of any vehicle is operated for maintenance purposes or tactical use.

**THE BEST DEFENSE AGAINST CARBON MONOXIDE  
POISONING IS ADEQUATE VENTILATION**

1. DO NOT operate heater or engine of vehicle in an enclosed area unless it is ADEQUATELY VENTILATED.
2. DO NOT idle engine for long periods without maintaining adequate ventilation in personnel compartments.
3. DO NOT drive any vehicle with inspection plates, cover plates, or engine compartment doors removed unless necessary for maintenance purposes.
4. BE ALERT at all times during vehicle operation for exhaust odors and exposure symptoms. If either are present, IMMEDIATELY VENTILATE personnel compartments. If symptoms persist, remove affected personnel from vehicle and treat as follows: Expose to fresh air; keep warm; do not permit physical exercise; if necessary, administer artificial respiration. For detailed first aid instruction consult FM 21-11, First Aid for Soldiers.

<b>WARNING</b>
----------------

**EXHAUST SYSTEM HAZARDS****EXHAUST GASES CAN KILL**

Brain damage or death can result from heavy exposure. Precautions must be followed to ensure crew safety when personnel heater, main, or auxiliary engine of any vehicle is operated for any purpose.

1. Do not operate vehicle engine in enclosed areas.
2. Do not idle vehicle engine with vehicle windows closed.
3. Be alert at all times for exhaust odors.
4. Be alert for exhaust poisoning symptoms. They are:
  - Headache
  - Dizziness
  - Sleepiness
  - Loss of muscular control
5. If you see another person with exhaust poisoning symptoms:
  - Remove person from area
  - Expose to open air
  - Keep person warm
  - Do not permit physical exercise
  - Administer artificial respiration, if necessary\*
  - Seek immediate medical attention

\*For artificial respiration, refer to FM 21-11.

6. BE AWARE, the field protective mask for nuclear-biological-chemical (NBC) protection will not protect you from carbon monoxide poisoning.

THE BEST DEFENSE AGAINST EXHAUST POISONING IS ADEQUATE VENTILATION.

- Allow engine to cool before performing maintenance on the muffler, exhaust pipe, exhaust manifold, or turbocharger. If necessary, use insulated pads and gloves.
- Do not touch hot exhaust system with bare hands; injury to personnel will result.

**WARNING**

**ENGINE OIL HAZARD**

Do not drain engine oil while engine is hot. Severe injury to personnel may result.

**WARNING**

**NOISE HAZARDS**

- Excessive noise levels are present any time the equipment is operating. Wear hearing protection while operating or working around equipment while it is running. Failure to do so could result in damage to your hearing. Seek medical aid should you suspect a hearing problem (ref. FM 21-11).
- Hearing protection is required for operator and also for all personnel working in and around this vehicle while engine is running.
- Personnel hearing can be PERMANENTLY DAMAGED if exposed to constant high noise levels of 85 dB (A) or greater. Wear approved hearing protection devices when working in high noise level areas. Personnel exposed to high noise levels shall participate in a hearing conservation program in accordance with TB MED 501. Hearing loss occurs gradually, but becomes permanent over time.

**WARNING**

**FALLING EQUIPMENT HAZARDS**

- Never crawl under equipment when performing maintenance unless equipment is securely blocked. Equipment may fall and cause serious injury or death to personnel.
- Keep clear of equipment when it is being raised or lowered. Equipment may fall and cause serious injury or death to personnel.
- Do not work on any item supported only by lift jacks or hoist. Always use blocks or proper stands to support the item prior to any work. Equipment may fall and cause serious injury or death to personnel.
- Do not allow heavy components to swing while suspended by lifting device. Equipment may strike personnel and cause injury.
- Exercise extreme caution when working near a cable or chain under tension. A snapped cable, shifting or swinging load may result in injury or death to personnel.
- All personnel must stand clear during lifting operations. A swinging or shifting load may cause injury or death to personnel.

<b>WARNING</b>
----------------

**FIRE HAZARD**

Diesel fuel and combustible materials are used in operation and maintenance of this equipment. Do not smoke or allow open flames or sparks in areas where diesel fuel and combustible materials are used or stored. DEATH or severe injury may result if personnel fail to observe this precaution. If you are burned, seek medical aid immediately (ref. FM 21-11).

<b>WARNING</b>
----------------

**STEAM UNDER PRESSURE**

- Do not remove the radiator cap when the engine is hot; steam and hot coolant can escape and burn personnel.
- Use extreme care when removing the radiator pressure cap. Sudden release of pressure can cause a steam flash which could seriously injure personnel. Slowly loosen cap to the first stop to relieve pressure before removing cap completely. After use, securely tighten cap.
- Use a clean, thick waste cloth or like material to remove the cap. Avoid using gloves. If hot water soaks through gloves, personnel could be burned.
- Extreme care should be taken when removing radiator filler cap if temperature gage reads above 180° F (82° C). Contact by steam or hot coolant may result in injury or death to personnel.

<b>WARNING</b>
----------------

**DO NOT USE MINERAL SPIRITS OR PAINT  
THINNER TO CLEAN THE HOWITZER**

Mineral spirits and paint thinners are highly toxic and combustible. Prolonged breathing can cause dizziness, nausea, and even death (ref. FM 21-11).

**DO NOT USE THESE MATERIALS**



**WARNING**

**DRY-CLEANING SOLVENT**

Dry-cleaning solvent (P-D-680), used to clean parts, is toxic and flammable. Wear protective goggles and gloves, and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes. Do not breathe vapors. Do not use near open flame or excessive heat. Do not smoke when using solvent. Failure to do so could cause **SERIOUS INJURY**. If you become dizzy while using cleaning solvent, get fresh air immediately, and if necessary, get medical attention. If contact with skin or clothes is made, flush thoroughly with water. If the solvent contacts your eyes, wash with water immediately, and obtain medical aid (ref. FM 21-11).

**WARNING**

**BATTERY HAZARDS**

- Batteries contain sulfuric acid which can cause severe burns. Avoid contact with skin, eyes, or clothing, and remove all metal or jewelry. If battery electrolyte is spilled, stop its burning effects immediately (ref. FM 21-11).
- Lead-acid battery gases can explode. Do not smoke, have open flames, or make sparks around a battery, especially if caps are off. If a battery is gassing, it can explode and cause injury to personnel.
  - a. Ventilate when charging or using in an enclosed space.
  - b. Wear safety goggles and acid-proof gloves when battery cover must be removed or when adding electrolyte.
  - c. Avoid electrolyte contact with skin, eyes, or clothing. If battery electrolyte spills, take immediate action to stop burning effects:
    - External: Immediately flush with cold running water to remove all acid.
    - Eyes: Flush with cold water for at least 15 minutes. Seek immediate medical attention.
    - Internal: Drink large amounts of water or milk. Follow with milk of magnesia, beaten egg, or vegetable oil. Seek immediate medical attention.
    - Clothing or Vehicle: Wash at once with cold water. Neutralize with baking soda or household ammonia solution.
- Wear safety glasses or goggles when checking batteries. Always check electrolyte level with engine stopped. Do not smoke or use exposed flame when checking battery; explosive gases are present and severe injury to personnel can result.
- Remove or disconnect batteries and turn vehicle MASTER switch OFF prior to performing maintenance in immediate battery area or working on electrical system. Such disconnections prevent electrical shock to personnel or equipment.

<b>WARNING</b>
----------------

**BATTERY HAZARDS - CONTINUED**

- Battery acid (electrolyte) is extremely harmful. Always wear safety goggles and rubber gloves, and do not smoke when performing maintenance on batteries. Injury will result if acid contacts skin or eyes. Wear rubber apron to prevent clothing being damaged.
- Remove all jewelry such as rings, dog tags, bracelets, etc. If jewelry contacts battery terminal, a direct short may result in instant heating of tools, damage to equipment, and injury or death to personnel.

<b>WARNING</b>
----------------

**ELECTRICAL HAZARD**

Be certain vehicle MASTER switch is OFF when working on hull electrical system to prevent injury due to electrical shock (ref. FM 21-11).

<b>WARNING</b>
----------------

**NBC EXPOSURE AND VEHICLE AIR FILTER HAZARDS**

- NBC-contaminated air filters must be handled and disposed of only by authorized and trained personnel. The unit commander or senior officer in charge of maintenance personnel must ensure that prescribed protective clothing (FM 3-4) is used, and prescribed safety measures and decontamination procedures (FM 3-5) are followed. The local unit SOP is responsible for final disposal of contaminated air filters. Failure to comply may cause severe injury or death to personnel.
- The NBC protection filters use a type of carbon that contains Chromium VI. This is a known carcinogen if inhaled or swallowed. Damaged or unusable filters are classified as hazardous waste.
  - a. Do not throw away damaged or unusable filters as trash.
  - b. Turn in damaged or unusable filters to your Hazardous Waste Management Office or Defense Reutilization and Marketing Office (DRMO).

Filters are completely safe to handle and use if they are not damaged in such a way that carbon leaks from them. If carbon does leak, use protection such as a dust respirator to cover nose and mouth and put carbon in container such as a self-sealing plastic bag; turn in to Hazardous Waste Management Office or DRMO.

Disposal of hazardous waste is restricted by law. Violation is subject to criminal penalties.

**WARNING**

**FIRE EXTINGUISHING SYSTEM HAZARDS**

- Fire extinguisher bottles can discharge and injure personnel. Insert antirecoil plugs, lock pins, and cotter pins before working on or near bottles.
- CO<sup>2</sup> can cause frostbite or eye injury. Wear protective clothing and goggles to avoid contact. If CO<sup>2</sup> contacts hands, hold hands under armpits or in warm water until warmed. If CO<sup>2</sup> contacts eyes, flush with large amounts of water and get medical attention immediately.

**WARNING**

**FAN SCREEN HAZARD**

Installed or removed, the rotation of the radiator cooling fans creates a hazard during maintenance on a running engine. A fan screen (12268262, NSN 2510-01-247-2976) must be installed prior to maintenance on a running engine (ref. FM 21-11).

**WARNING**

**ROTATION HAZARD**

- When working on a running engine, provide shielding for exposed rotating parts. Tools, clothing, or hands can get caught and cause serious injury to personnel.
- With engine running and driver's engine compartment access cover removed for maintenance, keep hands, clothing, and tools clear of generator pulley and belt. Injury or death could result.

**WARNING**

**WASTE HAZARD**

When servicing this vehicle, performing maintenance, or disposing of materials such as engine coolant, transmission fluid, lubricants, battery acids or batteries, and CARC paint, consult your unit/local regulatory guidance. If further information is needed, please contact the U.S. Army Environmental Hotline at 1-800-872-3845.

**WARNING****FALLING EQUIPMENT/ROLLING VEHICLE HAZARD**

Unless otherwise specified, perform all maintenance procedures with all equipment lowered to the ground, transmission in neutral, parking/emergency brake applied, and the engine stopped to prevent possible injury to personnel due to falling equipment or rolling vehicle (ref. FM 21-11).

**WARNING****PARKING HAZARD**

Do not park vehicles head to head. Personnel injury or damage to the vehicles could occur if one vehicle jumps (ref. FM 21-11).

**WARNING****EXPLOSION HAZARD**

Cylinders containing compressed gases must not be dropped, struck, or subjected to any temperature above +140°F (+60°C). This could result in an explosion and injury to personnel (ref. FM 21-11).

**WARNING****COMPRESSED AIR HAZARD**

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment (goggles/shield, gloves, etc.).

**WARNING****SNAP AND RETAINING RING HAZARD**

Use care when removing snap and retaining rings. Snap and retaining rings are under spring tension and can act as projectiles when released and could cause severe eye injury.

**WARNING**

**TURRET HAZARD**

The turret can kill or injure personnel as it turns. Do not enter or exit turret unless turret traverse lock is locked and turret power is off.

**WARNING**

**FASTENERS AND ATTACHING HARDWARE HAZARD**

Always use the same fastener part number (or equivalent) when replacing fasteners. Do not risk using a fastener of less quality; do not mix metric and inch (customary) fasteners. Mismatched or incorrect fasteners can result in damage, malfunction, or injury.

**WARNING**

**ADHESIVE HAZARDS**

- Adhesive causes immediate bonding on contact with eyes, skin, or clothing and also gives off harmful vapors. Wear protective goggles and use it in a well-ventilated area. If adhesive gets in eyes, try to keep eyes open; flush eyes with water for 15 minutes and get immediate medical attention.
- Adhesive sealant MIL-S-46163 can damage your eyes. Wear safety goggles/glasses when using; avoid contact with eyes. If sealant contacts eyes, flush eyes with water and get immediate medical attention.

**WARNING**

**WASTE HAZARD**

When servicing this vehicle, performing maintenance, or disposing of materials such as engine coolant, transmission fluid, lubricants, battery acids or batteries, and CARC paint, consult your unit/local regulatory guidance. If further information is needed please contact the U.S. Army Environmental Hotline at 1-800-872-3845.

INSERT LATEST CHANGED PAGES.  
DESTROY SUPERSEDED PAGES

**LIST OF EFFECTIVE PAGES**

Note: The portion of the text affected by the changes is indicated by a vertical line in the outer margin of the page. Changes to illustrations are indicated by miniature pointing hands. Changes to wiring diagrams are indicated by shaded areas.

Date of issue for original and changed pages are:

Original ..... 0 ..... 8 February 1999  
 Change ..... 1 ..... 1 May 2001  
 Change ..... 2 ..... 1 Aug 2003

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 1722, CONSISTING OF THE FOLLOWING:

TM 9-2350-314-20-1-1 = 732 Pages

TM 9-2350-314-20-1-2 = 972 Pages

**TM 9-2350-314-20-1-1 VOLUME 1**

Page No.	*Change No.	Page No.	*Change No.	Page No.	*Change No.
Cover	2	2-24	0	3-251	1
Blank	0	2-25 - 2-38	0	3-252	0
Change 2 Errata Added (2)	2	2-39	1	3-253 - 3-256	0
Change 1 Errata	1	2-40	0	3-257 - 3-258	1
a - b	2	2-41 - 2-44	0	3-258.1 - 3-258.6 Added	1
c	2	2-45	1	3-259	1
d	0	2-46	0	3-260	0
e - l	0	2-47	1	3-261 - 3-262	0
A - D	2	2-48	0	3-263 - 3-264	1
i - ii	1	2-49 - 2-50	0	3-264.1 - 3-264.4 Added	1
iii	1	2-51	0	3-265 - 3-410 Blank	0
iv	0	2-52	1	4-1 - 4-18	0
1-1	0	2-53	0	4-19	2
1-2	1	2-54	1	4-20	0
1-3	1	3-1 - 3-2	0	4-21	2
1-4	0	3-3	0	4-22	0
1-5 - 1-6	0	3-4	1	4-23 - 4-34	0
2-1 - 2-4	0	3-5	1	4-35	0
2-5	0	3-6	2	4-36	2
2-6	2	3-7 - 3-10	1	4-37	2
2-7	2	3-11	1	4-38	0
2-8	0	3-12	1	4-39 - 4-54	0
2-9 - 2-10	0	3-13	1	5-1 - 5-20	0
2-11	0	3-14 Blank	0	5-21 - 5-24	2
2-12	2	3-15 - 3-164 Blank	0	5-25	2
2-13 - 2-14	0	3-165	1	5-26	0
2-15	2	3-166	0	5-27	2
2-16	1	3-167 - 3-196	0	5-28	0
2-17 - 2-18	0	3-197	0	5-29	0
2-19	0	3-198	1	5-30	1
2-20	2	3-199 - 3-226	0	5-31	2
2-21	0	3-227	1	5-32	0
2-22	2	3-228	0	5-33	2
2-23	1	3-229 - 3-250	0	5-34	0

\*Zero in this column indicates an original page

TM 9-2350-314-20-1-1 VOLUME 1 - CONTINUED

Page No.	*Change No.	Page No.	*Change No.	Page No.	*Change No.
5-35 – 5-96	0	7-13	0	DA Form 2028-2	1
5-97	1	7-14	2	DA Form 2028-2 Address	1
5-98	0	7-15 – 7-52	0	DA Form 2028-2	1
5-99	1	Index-1 – Index-8	0	DA Form 2028-2 Address	1
5-100 Blank	0	DA Form 2028-2 Sample	1	DA Form 2028-2	1
6-1 – 6-16	0	Blank	0	DA Form 2028-2 Address	1
6-17	0	DA Form 2028-2	1	Measurement Page	0
6-18 Blank	1	DA Form 2028-2 Address	1	Blank	0
7-1 – 7-12	0				

TM 9-2350-314-20-1-2 VOLUME 2

Page No.	*Change No.	Page No.	*Change No.	Page No.	*Change No.
Cover	2	8-65 – 8-84	0	8-258	0
Blank	0	8-85	0	8-259	0
Change 2 Errata Added (4)	2	8-86	2	8-260	2
Change 1 Errata (2)	1	8-87	2	8-261 – 8-262	0
a – b	2	8-88	0	8-263	2
c	2	8-89 – 8-168	0	8-264	0
d	0	8-169	2	8-265 – 8-268	0
e – l	0	8-170	0	8-269	2
A – B	2	8-171 – 8-182	0	8-270	1
C	2	8-183	2	8-271 – 8-272	0
D Blank	2	8-184	0	8-273	2
i – ii	1	8-185	2	8-274	1
iii	0	8-186	0	8-275	0
iv Blank	0	8-187 – 8-220	0	8-276	1
8-1 – 8-8	0	8-221	2	8-277	0
8-9 – 8-10	2	8-222	0	8-278	1
8-11 – 8-32	0	8-223	2	8-279	0
8-33	0	8-224	0	8-280	2
8-34	2	8-225 – 8-236	0	8-281	0
8-35	2	8-237	0	8-282	2
8-36	0	8-238	2	8-283	0
8-37 – 8-42	1	8-239	0	8-284	1
8-43	1	8-240	1	8-285	1
8-44	0	8-241 – 8-242	0	8-286	2
8-45 – 8-48	0	8-243	2	8-287	0
8-49	1	8-244	1	8-288	2
8-50	0	8-245	0	8-289	1
8-51	0	8-246	2	8-290	2
8-52	2	8-247 – 8-250	0	8-291	0
8-53	0	8-251	2	8-292	2
8-54	1	8-252	0	8-293 – 8-294	0
8-55 – 8-60	0	8-253	0	8-295	0
8-61	0	8-254	2	8-296	2
8-62	1	8-255 – 8-256	0	8-297	0
8-63 – 8-64	2	8-257	2	8-298	2

\*Zero in this column indicates an original page

TM 9-2350-314-20-1-2 VOLUME 2 - CONTINUED

Page No.	*Change No.	Page No.	*Change No.	Page No.	*Change No.
8-299	0	13-1 - 13-14	0	16-167 - 16-204	0
8-300	2	14-1 - 14-6	0	17-1 - 17-10	0
8-301 - 8-302	2	15-1 - 15-4	0	17-11	0
8-303	0	15-5	2	17-12 Blank	0
8-304	2	15-6	0	18-1 - 18-6	0
8-305	0	15-7 - 15-8	0	18-7	0
8-306	2	15-9	0	18-8	1
8-307 - 8-330	0	15-10 Blank	0	18-9	1
8-331	0	16-1 - 16-64	0	18-10	0
8-332	2	16-65	0	18-11 - 18-12	1
8-333 - 8-344	0	16-66	1	18-13 - 18-14	0
9-1 - 9-42	0	16-67 - 16-68	0	18-15 - 18-28	1
9-41	0	16-69	2	18-29	1
9-42 Blank	0	16-70	0	18-30	0
10-1 - 10-6	0	16-71	0	18-31 - 18-34	0
10-7	2	16-72	2	18-35	2
10-8	0	16-73 - 16-74	2	18-36	0
10-9 - 10-12	0	16-75 - 16-88	0	18-37 - 18-38	0
10-13	2	16-89 - 16-90	2	19-1 - 19-38	0
10-14	0	16-91 - 16-96	0	20-1 - 20-10	0
10-15 - 10-16	0	16-97	0	20-11	0
10-17	0	16-98	1	20-12 Blank	0
10-18 Blank	0	16-99 - 16-100	1	21-1 - 21-26	0
11-1 - 11-20	0	16-101	1	21-27	0
11-21	0	16-102	0	21-28 Blank	0
11-22 Blank	0	16-103 - 16-104	2	22-1	0
12-11	2	16-105 - 16-116	0	22-2	1
12-12	0	16-117	1	22-3	1
12-13 - 12-18	0	16-118	0	22-4	0
12-19	0	16-119	1	22-5 - 22-10	0
12-20	2	16-120	0	23-1 - 23-4	0
12-21	0	16-121 - 16-126	0	23-5	0
12-22	2	16-127	0	23-6 Blank	0
12-23 - 12-24	0	16-128	1	A-1 - A-4	0
12-25	2	16-129	1	B-1 - B-10	0
12-26	0	16-130	0	B-11	0
12-27	0	16-131 - 16-138	0	B-12	1
12-28	2	16-139 - 16-140	2	B-13 - B-16	0
12-29 - 12-32	0	16-141 - 16-146	0	B-17	1
12-33 - 12-34	2	16-147	0	B-18	0
12-35	0	16-148	2	C-1 - C-2	0
12-36	2	16-149	0	C-3	2
12-37 - 12-40	0	16-150	2	C-4	0
12-41	2	16-151	2	C-5	2
12-42	0	16-152	0	C-6 Blank	0
12-43	0	16-153 - 16-162	0	D-1 - D-4	0
12-44	2	16-163	0	D-5	0
12-45	2	16-164	2	D-6 Blank	0
12-46	0	16-165	2	E-1	0
12-47 - 12-54	0	16-166	0	E-2	2

\*Zero in this column indicates an original page



TM 9-2350-314-20-1-2 VOLUME 2 - CONTINUED

Page No.	*Change No.	Page No.	*Change No.	Page No.	*Change No.
E-3	2	Index-1 – Index-6	0	DA Form 2028-2 Sample	1
E-4	0	FP-1	1	Blank	0
E-5	2	FP-2 Blank	0	DA Form 2028-2	1
E-6	0	FP-3	1	DA Form 2028-2 Address	1
E-7	2	FP-4 Blank	0	DA Form 2028-2	1
E-8	1	FP-5	1	DA Form 2028-2 Address	1
E-9	0	FP-6 Blank	0	DA Form 2028-2	1
E-10	2	FP-7	2	DA Form 2028-2 Address	1
F-1	0	FP-8 Blank	0	DA Form 2028-2	1
F-2	2	FP-9	1	DA Form 2028-2 Address	1
F-3	0	FP-10 Blank	0	Measurement Page	0
F-4 Blank	0	FP-11 Added	1	Blank	0
G-1 – G-2	0	FP-12 Blank	1		

\*Zero in this column indicates an original page

CHANGE  
NO. 2

TM 9-2350-314-20-1-1  
C2  
HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 1 AUG 2003

**TECHNICAL MANUAL  
UNIT MAINTENANCE MANUAL  
FOR  
HULL SYSTEMS AND COMPONENTS  
HOWITZER, MEDIUM,  
SELF-PROPELLED: 155MM M109A6  
(NSN 2350-01-305-0028) (EIC: 3FC)**

TM 9-2350-314-20-1-1, February 1999, is changed as follows:

1. The purpose of this change is to update TM 9-2350-314-20-1-1.
2. New or changed material is indicated by a vertical bar in the outside margin of text changes and by a hand symbol beside illustration changes.
3. Remove the old page and insert the new page as indicated below:

Remove Pages

a through d

A through C/D blank

2-5 through 2-8

2-11 and 2-12

2-15 and 2-16

2-19 through 2-22

3-5 and 3-6

4-19 through 4-22

4-35 through 4-38

5-21 through 5-28

5-31 through 5-34

7-13 and 7-14

Cover/blank

Insert Pages

a through d

A through D

2-5 through 2-8

2-11 and 2-12

2-15 and 2-16

2-19 through 2-22

3-5 and 3-6

4-19 through 4-22

4-35 through 4-38

5-21 through 5-28

5-31 through 5-34

7-13 and 7-14

Cover/blank

4. File this change in front of the publication.

Distribution Statement A: Approved for public release; distribution is unlimited.

By Order of the Secretary of the Army:

Official:



JOEL B. HUDSON

*Administrative Assistant to the  
Secretary of the Army*

0211903

PETER J. SCHOOMAKER  
*General, United States Army  
Chief of Staff*

DISTRIBUTION: To be distributed in accordance with the initial distribution number (IDN) 371933, requirements for TM 9-2350-314-20-1-1.

CHANGE  
NO.1

**TECHNICAL MANUAL  
UNIT MAINTENANCE MANUAL  
FOR  
HULL SYSTEMS AND COMPONENTS  
HOWITZER, MEDIUM,  
SELF-PROPELLED: 155MM, M109A6  
(NSN 2350-01-305-0028) (EIC: 3FC)**

TM 9-2350-314-20-1-1, February 1999, is changed as follows:

1. The purpose of this change is to update TM 9-2350-314-20-1-1.
2. New or changed material is indicated by a vertical bar in the outside margin of text changes and by a hand symbol beside illustration changes.
3. Remove the old page and insert the new page as indicated below:

Remove Pages

none  
i through iv  
1-1 through 1-4  
2-15 and 2-16  
2-23 and 2-24  
2-39 and 2-40  
2-45 through 2-48  
2-51 through 2-54  
3-3 through 3-13/(3-14 blank)  
3-165 and 3-166  
3-197 and 3-198  
3-227 and 3-228  
3-251 and 3-252  
3-257 through 3-260  
3-263 and 3-264  
5-29 through 5-32  
5-97 through 5-99/(5-100 blank)  
DA2028-2 sample form  
DA2028-2 form (4)  
Cover/blank

Insert Pages

A through C/(D blank)  
i through iv  
1-1 through 1-4  
2-15 and 2-16  
2-23 and 2-24  
2-39 and 2-40  
2-45 through 2-48  
2-51 through 2-54  
3-3 through 3-13/(3-14 blank)  
3-165 and 3-166  
3-197 and 3-198  
3-227 and 3-228  
3-251 and 3-252  
3-257 through 3-260  
3-263 through 3-264.4  
5-29 through 5-32  
5-97 through 5-99/(5-100 blank)  
DA2028-2 sample form  
DA2028-2 form (4)  
Cover/blank

4. File this change in front of the publication.

Distribution Statement A: Approved for public release; distribution is unlimited.

By Order of the Secretary of the Army:

Official:



JOEL B. HUDSON

*Administrative Assistant to the  
Secretary of the Army*

0105103

ERIC K. SHINSEKI  
*General, United States Army  
Chief of Staff*

DISTRIBUTION: To be distributed in accordance with the initial distribution requirements for IDN: 371933  
TM 9-2350-314-20-1-1.

**UNIT MAINTENANCE MANUAL  
FOR  
HULL SYSTEMS AND COMPONENTS  
HOWITZER, MEDIUM, SELF-PROPELLED:  
155MM, M109A6  
(NSN 2350-01-305-0028)(EIC: 3FC)**

**REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS**

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028-2 (Recommended Changes to Equipment Technical Publications), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <http://aeprs.ria.army.mil>. If you need a password, scroll down and click on "ACCESS REQUEST FORM". The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax or email your letter, DA Form 2028, or DA Form 2028-2 direct to: Technical Publication Information Office, TACOM-RI, 1 Rock Island Arsenal, Rock Island, IL 61299-7630. The email address is [TACOM-TECH-PUBS@ria.army.mil](mailto:TACOM-TECH-PUBS@ria.army.mil). The fax number is DSN 793-0726 or Commercial (309) 782-0726.

Distribution Statement A: Approved for public release; distribution is unlimited.

**TABLE OF CONTENTS  
VOLUME 1**

<u>CONTENTS</u>	<u>PAGE</u>
HOW TO USE THIS MANUAL .....	iv
CHAPTER 1 - INTRODUCTION .....	1-1
Section I.    General Information .....	1-2
Section II.   Equipment Description and Data .....	1-3
Section III.  Principles of Operation .....	1-6
CHAPTER 2 - GENERAL MAINTENANCE .....	2-1
Section I.    Repair Parts, Special Tools, TMDE, and Support Equipment .....	2-2
Section II.   Service Upon Receipt .....	2-2
Section III.  Preventive Maintenance Checks and Services (PMCS) .....	2-5
Section IV.   Slave Starting .....	2-50
CHAPTER 3 - TROUBLESHOOTING .....	3-1
CHAPTER 4 - POWERPACK .....	4-1
Section I.    Powerpack .....	4-2
Section II.   Engine Assembly .....	4-36
Section III.  Engine Lubrication System .....	4-46

TABLE OF CONTENTS - CONTINUED

<u>CONTENTS</u>	<u>PAGE</u>
CHAPTER 5 - FUEL SYSTEM ..... 5-1	
Section I.    Fuel Pumps .....	5-2
Section II.   Air Cleaner .....	5-21
Section III.  Supercharger, Blower, or Turbocharger .....	5-34
Section IV.  Tanks, Lines, Fittings, and Headers .....	5-36
Section V.   Fuel Filters .....	5-60
Section VI.  Accelerator, Throttle, or Choke Controls .....	5-76
CHAPTER 6 - EXHAUST SYSTEM ..... 6-1	
CHAPTER 7 - COOLING SYSTEM ..... 7-1	
Section I.    Radiator .....	7-2
Section II.   Shrouds .....	7-14
Section III.  Water Manifold, Headers, Thermostats, and Housing .....	7-18
Section IV.  Fan Assembly .....	7-52
ALPHABETICAL INDEX .....	Index-1

VOLUME 2

CHAPTER 8 - ELECTRICAL SYSTEMS ..... 8-1	
Section I.    Generator .....	8-5
Section II.   Voltage Regulator .....	8-32
Section III.  Starting Motor .....	8-33
Section IV.  Instrument or Engine Control Panels .....	8-37
Section V.   Miscellaneous Items .....	8-70
Section VI.  Lights .....	8-96
Section VII.  Sending Units and Warning Switches .....	8-124
Section VIII.  Batteries .....	8-146
Section IX.  Hull Wiring Harness .....	8-162
Section X.   Ventilating Equipment .....	8-336
CHAPTER 9 - TRANSMISSION ..... 9-1	
Section I.    Gear Shift and Controls .....	9-2
Section II.   Transmission Assembly and Associated Parts .....	9-14
CHAPTER 10 - TRANSFER AND FINAL DRIVE ASSEMBLIES ..... 10-1	
CHAPTER 11 - BRAKES ..... 11-1	
Section I.    Hand Brake .....	11-2
Section II.   Mechanical Brake System .....	11-10
CHAPTER 12 - WHEELS AND TRACKS ..... 12-1	
Section I.    Suspension Assembly .....	12-2
Section II.   Track Idlers and Brackets .....	12-28
Section III.  Track Drive Sprocket .....	12-40
Section IV.  Track Assembly .....	12-42
CHAPTER 13 - STEERING ..... 13-1	

TABLE OF CONTENTS - CONTINUED

<u>CONTENTS</u>	<u>PAGE</u>
CHAPTER 14 - TOWING ATTACHMENTS .....	14-1
CHAPTER 15 - SHOCK ABSORBERS .....	15-1
CHAPTER 16 - BODY, CAB, HOOD, AND HULL .....	16-1
Section I. Body, Cab, Hood, and Hull Assemblies .....	16-4
Section II. Fenders .....	16-109
Section III. Driver's Hatch and Periscopes .....	16-111
Section IV. Drain Plugs .....	16-128
Section V. Floor, Subfloor, and Related Components .....	16-130
Section VI. Driver's Seat .....	16-139
Section VII. Stowage Racks, Boxes, Straps, Carrying Cases, and Cable Reels .....	16-151
CHAPTER 17 - SPADE ASSEMBLIES .....	17-1
CHAPTER 18 - BODY, CHASSIS, OR HULL ACCESSORY ITEMS .....	18-1
Section I. Accessory Items .....	18-2
Section II. Bilge Pump .....	18-8
Section III. Winterization Equipment .....	18-12
Section IV. Data Plates and Instruction Holders .....	18-34
CHAPTER 19 - SPECIAL PURPOSE KITS .....	19-1
CHAPTER 20 - GAGES .....	20-1
CHAPTER 21 - FIRE FIGHTING EQUIPMENT .....	21-1
CHAPTER 22 - NUCLEAR, CHEMICAL, AND BIOLOGICAL (NBC) EQUIPMENT .....	22-1
CHAPTER 23 - ADMINISTRATIVE STORAGE .....	23-1
APPENDIX A - REFERENCES .....	A-1
APPENDIX B - MAINTENANCE ALLOCATION CHART .....	B-1
APPENDIX C - EXPENDABLE AND DURABLE ITEMS LIST .....	C-1
APPENDIX D - TORQUE LIMITS .....	D-1
APPENDIX E - MANDATORY REPLACEMENT PARTS LIST .....	E-1
APPENDIX F - TOOL IDENTIFICATION LIST .....	F-1
APPENDIX G - CORROSION PREVENTION AND CONTROL .....	G-1
ALPHABETICAL INDEX .....	Index-1
ELECTRICAL SCHEMATICS .....	FP-1



## HOW TO USE THIS MANUAL

### Indexing

Five major indexing procedures are used in this manual to help the technician locate information rapidly.

1. Cover index: Lists sections of text and page number. Includes Index Mark ( ) which lines up with Index Marks on the actual page of reference.

Example: Troubleshooting. 3-1

2. Table of Contents: Pages i through iii.
3. Chapter indexes: Lists data/information covered within the chapter and section.
4. Troubleshooting symptoms index: Identifies system malfunction and provides page reference for specific troubleshooting procedures.
5. Index, pages Index-1 through Index-6: Alphabetical listing of information.

### Maintenance Text and Illustrations (Chapter 4 through 23)

1. Maintenance procedures are to be performed in the sequence shown in the text and illustrations. Step 1 must be performed before Step 2. Procedure a must be performed before Procedure b, and so on.
2. Equipment illustrations use numbers to identify parts of the system/components.

Example:

1. Remove both wiring harnesses (1) and (2).
2. Remove four screws (3), four flat washers (4), four lockwashers (5) and four nuts (6).

# CHAPTER 1 INTRODUCTION

---

## GENERAL

This chapter provides a general introduction to the purpose, safe use, and capabilities of the M109A6 Howitzer. Section I describes procedures for destroying equipment to prevent enemy use, references to other technical manuals, and forms to recommend improvements. Sections II and III familiarize the mechanic with equipment data and operating principles of the howitzer's systems.

---

<u>CONTENTS</u>	<u>Page</u>
Section I. GENERAL INFORMATION	
1-1 SCOPE .....	1-2
1-2 MAINTENANCE FORMS, RECORDS, AND REPORTS .....	1-2
1-3 DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE .....	1-2
1-4 PREPARATION FOR STORAGE OR SHIPMENT .....	1-2
1-5 QUALITY ASSURANCE (QA) .....	1-2
1-6 NOMENCLATURE CROSS-REFERENCE LIST .....	1-3
1-7 REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS .....	1-3
1-8 WARRANTY INFORMATION .....	1-3
1-9 CORROSION PREVENTION AND CONTROL .....	1-3
Section II. EQUIPMENT DESCRIPTION AND DATA	
1-10 EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES .....	1-3
1-11 LOCATION AND DESCRIPTION OF MAJOR COMPONENTS .....	1-3
1-12 DIFFERENCES BETWEEN MODELS .....	1-3
1-13 EQUIPMENT DATA .....	1-4
Section III. PRINCIPLES OF OPERATION	
1-14 EQUIPMENT OPERATION AND DESCRIPTION .....	1-6

## Section I. GENERAL INFORMATION

### 1-1 SCOPE.

Type of manual: Unit Maintenance. This manual deals with maintenance for the hull and associated components. TM 9-2350-314-20-2 deals with maintenance of the cab and associated components.

Model number and equipment name: M109A6, Howitzer, Medium, Self-Propelled, 155MM.

Purpose of Equipment: Provides artillery fire in support of ground-gaining troops.

### 1-2 MAINTENANCE FORMS, RECORDS, AND REPORTS.

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 738-750, The Army Maintenance Management System (TAMMS) as contained in Maintenance Management Update.

Accidents involving injury to personnel or damage to materiel will be reported on DA Form 285 (Accident Reporting) in accordance with AR 385-40.

### 1-3 DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE.

Refer to TM 750-244-6 for procedures on how to destroy the M109A6 Howitzer. You will find procedures for destruction of munitions in TM 750-244-5-1 (conventional ammo) or TM 43-0002-33 (improved conventional munitions). Procedures for destruction of chemical munitions are outlined in TM 3-250.

Below are some general guidelines to follow in destruction of equipment to prevent enemy use.

Destruction of the vehicle, armament, and equipment, when subject to capture or abandonment in a combat zone, will be undertaken only when the unit commander decides such action is necessary in accordance with orders of, or policy established by, the Army commander.

In general, destruction of essential parts, followed by burning, will usually be sufficient to render the vehicle, armament, and equipment useless. Time is usually critical.

Materiel must be damaged so that it cannot be restored to usable condition by either repair or cannibalization. If lack of time or personnel prevents destruction of all parts, give priority to destruction of parts hardest to replace. It is important that the same parts be destroyed on all units to prevent construction of one complete unit from several damaged ones.

All items of sighting and fire control instruments and equipment, especially telescopes, gunner's quadrants, and binoculars, are costly and difficult to replace. They should be conserved whenever possible. If you cannot carry them with you, destroy them by smashing with your sledgehammer, pick, or mattock. Throw the pieces in all directions.

When time is short, a method of destroying the equipment with materials at hand is as follows:

Retrieve or smash sighting and fire control equipment.

Load cannon with projectile and full powder charge. Attach a 50-foot (15.2 m) or longer lanyard to firing mechanism. Disconnect recoil cylinder lines and fire the weapon.

Take a sledgehammer and bend the end of the counterrecoil buffer rod.

A second method is to close the breechblock and toss several thermite grenades down the tube. Elevate the tube so that the grenades will fall against the breechblock. This will melt the breech and the powder chamber, causing them to fuse together.

### 1-4 PREPARATION FOR STORAGE OR SHIPMENT.

Refer to Chapter 23 for the requirements for Administrative Storage. Refer to TM 9-2350-314-20-2 for the requirements for vehicle shipment.

### 1-5 QUALITY ASSURANCE (QA).

No particular quality assurance manual pertains specifically to the M109A6 Howitzer.

Defective material received through the supply system should be reported on Quality Deficiency Report (QDR) SF368. Instructions for preparing QDRs are provided in AR 702-7, Reporting of Quality Deficiency Data. QDRs should be mailed directly to:

Department of the Army  
U.S. Army Tank-automotive and Armaments Command  
ATTN: AMSTA-TR-E-PQDR MS 267  
Warren, MI 48397-5000

A reply will be furnished directly to you.

## 1-6 NOMENCLATURE CROSS-REFERENCE LIST.

Nomenclature in this manual was chosen in accordance with the terms used for provisioning as they appear in the Repair Parts and Special Tools List (RPSTL) and Maintenance Allocation Chart (MAC) for unit maintenance.

A few tools and hull components are, however, referred to by names more common than those in the RPSTL. In many cases the more common name is a shorter name for the same component.

<u>OFFICIAL PROVISIONING NOMENCLATURE</u>	<u>MORE COMMON NAME</u>
Ammunition rack	Ammo rack
Cable assembly	Wiring harness
Gage rod	Dipstick, bayonet gage
Intercommunications power harness	Intercom wiring harness
Intercommunications system	Intercom system
155MM medium self-propelled howitzer M109A6	Howitzer (Modified 155MM)
Safety wire	Lockwire
Socket head screw key	Hex key

## 1-7 REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS.

If your M109A6 Howitzer needs improvement, let us know. Send us an Equipment Improvement Recommendation (EIR). You, the user, are the only one who can tell us what you don't like about our equipment. Let us know why you don't like the design or performance. Put it on a SF 368 (Product Quality Deficiency Report). EIRs should be mailed to:

Department of the Army  
U.S. Army Tank-automotive and Armaments Command  
ATTN: AMSTA-LC-CIP-W  
Rock Island, IL 61299-7630

## 1-8 WARRANTY INFORMATION.

The M109A6 is not warranted.

## 1-9 CORROSION PREVENTION AND CONTROL.

Corrosion Prevention and Control (CPC) of Army materiel is a continuing concern. It is important that any corrosion problem with the howitzer be reported so that improvements can be made to prevent the problem in the future. While corrosion is typically associated with rusting of metals, it can also include deterioration of other materials such as rubber and plastic. Unusual cracking, softening, swelling, or breaking of these materials may be a corrosion problem. Additional information concerning corrosion prevention and control is found in Appendix G of this manual. If a corrosion problem is identified, report the specific problem to the address specified in Appendix G.

## Section II. EQUIPMENT DESCRIPTION AND DATA

### 1-10 EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES.

#### 1-10.1 Characteristics.

Refer to TM 9-2350-314-10 for Characteristics of the M109A6 Howitzer.

#### 1-10.2 Capabilities and Features.

Refer to TM 9-2350-314-10 for Capabilities and Features of the M109A6 Howitzer.

### 1-11 LOCATION AND DESCRIPTION OF MAJOR COMPONENTS.

Refer to TM 9-2350-314-10 for Location and Description of Major Components of the M109A6 Howitzer.

### 1-12 DIFFERENCES BETWEEN MODELS.

There is currently only one model of the M109A6 Howitzer.

**1-13 EQUIPMENT DATA.**

GENERAL

Crew .....	4
Weight (combat loaded) .....	62,960 lbs (28,583.84 kg)
Weight (empty) .....	56,400 lbs (25,605.6 kg)
Overall length (with baskets) to rear .....	423 inches (10.75 m)
Overall length (with baskets) forward .....	392 inches (9.96 m)
Overall width (with baskets) to rear .....	128 inches (3.25 m)
Overall width (with baskets) forward .....	154 inches (3.9 m)
Height (including machinegun) .....	143 inches (3.6 m)
Lowest operable height .....	128 inches (3.25 m)
Ground clearance .....	18 inches (0.45 m)
Shipping volume .....	3737 cu ft (104.64 cu m)
Bridge classification .....	26 ton (23,608 kg)

PERFORMANCE

High speed (max) .....	38 mph (governed) (61.1 kmph)
Low speed (max) .....	6 mph (9.6 kmph)
Reverse speed (max) .....	7 mph (11.26 kmph)
Maximum grade .....	60%
Maximum trench .....	72 inches (1.83 m)
Maximum vertical wall .....	21 inches (0.53 m)
Turn radius (min) .....	1 vehicle length
Cruising range .....	186 miles (299 km)
Fuel capacity .....	133 gallons (503.4 LI)

ENGINE

Type/model .....	Detroit Diesel, Allison 8V71T, model 91, liquid cooled
Manufacturer .....	Detroit Diesel, Allison Div., GMC
Horsepower (gross) .....	440 at 2300 rpm
Displacement .....	568 cu. in. (9.32 LI)
Bore .....	4.25 inches (108 mm)
Stroke .....	5 inches (127 mm)
Compression ratio .....	17:1
Torque (max gross) .....	980 lb-ft at 1700 (1328 N·m)
Torque (max net) .....	895 lb-ft at 1600 (1213 N·m)
Ignition .....	Compression
Fuel .....	Diesel: 40 octane, VV-F-800
Regular grade (DF-2) .....	Temperature range: +20° to +115° F (-7° to +46° C)
(NATO F-54)	
Winter grade (DF-1) .....	Temperature range: -20° to +20° F (-29° to -7° C)
Arctic grade (DF-A) .....	Temperature range: - 65° to -25° F (-54° to -35° C)
Fuel acceptance (safe max) .....	50 gpm (3.1 LI/sec)
Lubrication oil system	
capacity (refill) .....	27 quarts (25.5 LI) (approx)
capacity (dry) .....	38 quarts (36 LI) (approx)
Cooling system	
capacity (refill) .....	14-1/2 gallons (55 LI)
capacity (dry) .....	20-1/4 gallons (77 LI)

**1-13 EQUIPMENT DATA - CONTINUED**

**TRANSMISSION**

Model . . . .	XTG-411-4
Manufacturer . . . . .	Allison Div., GMC
Usable ranges:	
First (low range) . . . . .	4.69:1
Second (low intermediate) . . . . .	3.17:1
Third (low intermediate) . . . . .	1.58:1
Fourth (high range) . . . . .	0.79:1
Low reverse (R-1) . . . . .	5.60:1
High reverse (R-1) . . . . .	3.79:1
Steer . . . . .	1.475:1
Steer control - first and second . . . . .	Clutch brake
Steer control - third and fourth . . . . .	Geared
Brakes . . .	Mechanical - applied
Oil capacity (refill) . . . . .	12 gallons (45.5 LI)
Oil capacity (dry) . . . . .	21 gallons (79 LI)

**ELECTRICAL SYSTEM**

Voltage (nominal) . . . . .	24
Batteries (12 volts each, series - parallel connected) . . . . .	4
Type . . . . .	6 TN
Generator	
Manufacturer . . . . .	Bendix Corp.
Model . . . . .	30895-468 (P/N 12361436)
Amperage . . . . .	650

**SUSPENSION**

Type . . . . .	Independent torsion bar
Roadwheel . . . . .	7 sets
Size . .	24 inches (0.6 m)
Loadings	
1, 2, and 7 positions . . . . .	4000 lbs (approx) (1816 kg)
Intermediate positions . . . . .	2600 lbs (approx) (1180 kg)

**TRACK**

Adjustment at idler wheel . . . . .	Track adjuster
Shoes per track . . . . .	80
Pitch . . . . .	6 inches (15.2 cm)
Width . . . . .	15 inches (38 cm)

**FINAL DRIVES AND SPROCKETS**

Type . . . . .	Spur gear
Ratio . . . . .	4.36:1
Sprocket pitch diameter . . . . .	19.3 inches (49.5 cm)
Number teeth per sprocket . . . . .	10

**FIRE EXTINGUISHER**

Fixed - 10-pound bottles (CO <sup>2</sup> ) . . . . .	2
Portable - 5-pound bottles (Halon) . . . . .	1

**Section III. PRINCIPLES OF OPERATION**

**1-14 EQUIPMENT OPERATION AND DESCRIPTION.**

Refer to TM 9-2350-314-10 for hull-related systems and components.

## CHAPTER 2 GENERAL MAINTENANCE

---

### GENERAL

This chapter presents instructions and information needed to keep the M109A6 hull equipment and components in good repair. These instructions provide a step-by-step, item-by-item, illustrated text describing M109A6 equipment, component service, and maintenance.

The maintenance functions described in this chapter are limited to those functions authorized by the MAC for Unit Maintenance level activities. If maintenance is needed on any hull equipment or components that are not discussed in this chapter, notify Support Maintenance.

---

<u>CONTENTS</u>	<u>Page</u>
Section I. REPAIR PARTS, SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT	
2-1 GENERAL .....	2-2
2-2 COMMON TOOLS AND EQUIPMENT .....	2-2
2-3 SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT .....	2-2
2-4 REPAIR PARTS .....	2-2
Section II. SERVICE UPON RECEIPT	
2-5 GENERAL .....	2-2
2-6 INITIAL PROCEDURES .....	2-2
2-7 PREOPERATIONAL PROCEDURES .....	2-4
2-8 OPERATIONAL PROCEDURES .....	2-4
2-9 EQUIPMENT FAULTS .....	2-4
Section III. PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)	
2-10 GENERAL .....	2-5
2-11 PROCEDURES FOR THE SEMIANNUAL AND ANNUAL SERVICES .....	2-8
Section IV. SLAVE STARTING	
2-12 STARTING INSTRUCTIONS .....	2-50



## Section I. REPAIR PARTS, SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT

### 2-1 GENERAL.

Repair parts, special tools, and support equipment are issued for maintaining the vehicle. Tools and equipment should not be used for purposes other than those prescribed. When not in use, they should be properly stowed.

### 2-2 COMMON TOOLS AND EQUIPMENT.

For authorized common tools and equipment, refer to the Modified Table of Organization and Equipment (MTOE), CTA 50-970, or CTA 8-100, as applicable to your unit.

The tool kit (box) assigned to the mechanic (on a 1-per-mechanic-by-MOS basis) shall be identified in the individual maintenance paragraphs by nomenclature and supply catalog (SC) number. No tool in the kit shall be further identified. Other tools required for performance of all tasks for the maintenance levels covered in the manual shall be identified in the setup and shall be referenced to the Tool Identification List, Appendix F. "Other tools" includes tools which are part of components of shop sets authorized to sections/teams; tools authorized by RPSTL and CTA 50-970; special tools; and items of TMDE.

### 2-3 SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT.

Special tools and equipment necessary to perform the maintenance described in this manual are listed in Appendix B for information only. Special tools and equipment are listed in TM 9-2350-314-24P-1, which is the authority requisitioning replacements. Fabricated tools are identified in the initial setup; manufacturing instructions have been written into the task which requires the fabricated tool.

### 2-4 REPAIR PARTS.

Repair parts are listed and illustrated in the repair parts and special tools list covering unit maintenance (TM 9-2350-314-24P-1). All mandatory replacement parts identified in the initial setup are listed in Appendix E of this manual.

Gaskets, packings, preformed packings, seals, lockwashers, locknuts, self-locking nuts, cotter pins, and spring pins must be replaced. Bushings must be replaced only if removed.

Springs must be replaced if broken, kinked, cracked, or do not conform to standards specified in the repair data.

## Section II. SERVICE UPON RECEIPT

### 2-5 GENERAL.

This section covers the procedures for servicing M109A6 Howitzer upon receipt. A run-in of at least 5 miles will be performed on all new or reconditioned vehicles, and of a sufficient number of miles on used vehicles, to check their operation completely. This section may provide material which is duplicated in TM 9-2350-314-20-2. This duplication is limited only to activities which require crew and maintenance technicians' joint efforts.

### 2-6 INITIAL PROCEDURES.

#### NOTE

If the vehicle has been shipped by rail, unblock and unload the equipment according to TM 9-2350-314-20-2. Observe existing regulations.

#### 2-6.1 Checking Unpacked Equipment.

- a. Inspect the equipment for damage incurred during shipment. If the equipment has been damaged, report the damage on SF 364 Form, Packing Improvement Report.
- b. Check the equipment against the packing slip to see if the shipment is complete. Report all discrepancies in accordance with the instructions on DA PAM 738-750.
- c. Check whether the equipment has been modified. Reference shall be made to the authorized equipment configuration change list when applicable.

## 2-6.2 Deprocessing Unpacked Equipment.

- a. Install fire control and sighting equipment as is. No cleaning is required.
- b. Clean all other tools and equipment.
- c. Store all basic issue items in their respective vehicle storage facility as indicated in TM 9-2350-314-10.
- d. Clean the vehicle as follows:

**WARNING**

Dry-cleaning solvent (P-D-680) is toxic and flammable. To avoid injury, wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes. Do not breathe vapors. Do not use near open flame or excessive heat. Do not smoke when using solvent. Failure to do so could cause **SERIOUS INJURY**. If you become dizzy while using dry-cleaning solvent, get fresh air immediately, and if necessary, get medical attention. If contact with skin or clothes is made, flush thoroughly with water. If the solvent contacts your eyes, wash them with water immediately and obtain medical aid (FM 21-11).

1. Remove any rust-preventive compound from exterior surfaces with dry-cleaning solvent (item 59, Appx C). Whenever possible, the vehicle crew will help in the cleaning.
2. Armament parts are coated with rust-preventive compound when received from storage. Clean these parts thoroughly with rags or a brush saturated with dry-cleaning solvent (item 59, Appx C). After complete removal of the rust-preventive compound, lubricate as specified in TM 9-2350-314-10. Component parts of each weapon should be cleaned separately where possible. Component parts are interchangeable; however, the parts originally assembled work best together.

## 2-6.3 Assembly of Equipment.

The M109A6 Howitzer equipment and systems are shipped as assembled units. Assembly is not required.

## 2-6.4 Equipment Installation Instructions.

- a. Installation instructions for the M109A6 Howitzer require installation of on-board vehicle equipment, equipment racks, and stowage of equipment in the hull as shown in Chapter 16.
- b. Follow all precautions on DD Form 1397 (Processing and Deprocessing Record for Shipment, Storage, and Issue of Vehicles and Spare Engines). One tag will be with the Records Book and one in an envelope attached to a headlamp.

## 2-7 PREOPERATIONAL PROCEDURES.

Inspect all wires/hydraulic lines/connectors, electrical connectors, welds, bolts, and seals.

### 2-7.1 Installation of Batteries.

- a. Service batteries in accordance with TM 9-6140-200-14.
- b. Install batteries in accordance with Chapter 8, Section VIII.

### 2-7.2 Checking Vehicle Systems.

Check for the following:

- a. ENGINE COOLANT: Check level and specific gravity (item 31, Table 2-1).
- b. ENGINE OIL: Check level (TM 9-2350-314-10).
- c. FUEL: Fuel vehicle (TM 9-2350-314-10).
- d. TRANSMISSION OIL: Check level (TM 9-2350-314-10).
- e. FIRE EXTINGUISHER BOTTLES: Check valve safety wire (items 2 and 12, Table 2-1).

## 2-8 OPERATIONAL PROCEDURES.

### 2-8.1 Initial Starting and Break-In.

#### NOTE

Engine contains preservative oil upon receipt. Preservative engine oils PE1 and PE2 are identical to engine oils OE-10 and OE-30, except that they contain a preservative additive. PE1 and PE2 will be used in the same manner as the regularly used engine oils OE-10 or OE-30. PE1 or PE2 will also be used in the transmission until the first scheduled 2000-mile or semiannual oil change. Refer to TM 9-2350-314-10 for correct lubrication instructions.

- a. Start and run engine (TM 9-2350-314-10) until preservative oil is out of combustion chambers and engine is operating smoothly. Check for fuel and oil leaks immediately.

#### NOTE

Due to international processing, engine may be hard to start, and may smoke and run rough. Let it run for 5 minutes and see if it improves. Perform troubleshooting procedures if engine fails to develop full power after 5 minutes.

- b. Perform complete annual service (Table 2-1).

### 2-8.2 Operational Test.

Test vehicle systems for proper operation (TM 9-2350-314-10).

### 2-8.3 Road Test.

Road test vehicle to check and qualify all operational systems (TM 9-2350-314-10).

## 2-9 EQUIPMENT FAULTS.

Equipment faults disclosed during preliminary inspection and servicing or during break-in period will be corrected by the using unit or support maintenance.

### 2-9.1 Reporting Design and Material Faults.

Serious equipment faults which appear to involve unsatisfactory design or material will be reported on SF 368, Quality Deficiency Report (Category II), as prescribed in DA PAM 738-750.

## Section III. PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)

### 2-10 GENERAL.

This section contains Unit preventive maintenance checks and services.

Preventive maintenance is the step-by-step care, inspection, and service of equipment to maintain it in good condition and to find problems before extensive and time-consuming repairs or replacements are needed. Refer to DA PAM 738-750 for instructions on use of forms for preventive maintenance services.

#### 2-10.1 Intervals.

The preventive maintenance checks and services listed in Table 2-1 are to be performed at Unit level at intervals determined by whichever comes first:

- (a) semiannually, 1500 miles, or 150 hours;
- (b) annually, 3000 miles, or 300 hours.

Preventive maintenance checks and services items and intervals have been determined by using Reliability Centered Maintenance (RCM) logic and are to be scheduled on DD Form 314 in accordance with DA PAM 738-750.

After operation in water, mud, or loose sand, the vehicle should be cleaned as soon as possible. Lubricate without waiting for the next scheduled service.

#### 2-10.2 Lubrication Instructions.

Detailed lubrication steps and instructions covering locations, intervals, and lubricants for M109A6 vehicles are listed in Table 2-1.

Lubrication instructions are to be performed by Unit Maintenance personnel.

Intervals (on-condition or hard time) are based on normal operation. On-Condition (OC) oil sample intervals shall be applied unless changed by the Army Oil Analysis Program (AOAP) laboratory. Change the hard time interval if your lubricants are contaminated or if you are operating the equipment under adverse operating conditions, including longer than usual operating hours. The hard time interval may be extended during periods of low activity. If extended, adequate preservation precautions must be taken. Hard time intervals will be applied in the event AOAP laboratory support is not available.

Engine oil/transmission oil/hydraulic fluids must be sampled at 25 hours of operation or 60 days, whichever occurs first, as prescribed by DA PAM 738-750.

When AOAP analysis service is available, change oil and filters at the direction of the AOAP laboratory.

When AOAP analysis service is not available, change oil and filters at 75 hours or 750 miles of operation.

Always use the Expected Temperature Lubrication Table to determine seasonal lubrication requirements.

When changing engine and transmission oil due to seasonal requirements, always change the oil filters.

Sound maintenance practice dictates that AOAP is not a maintenance substitute, but is used as an effective maintenance diagnostic tool. Therefore, if 12 months have elapsed since the last AOAP or seasonally directed oil and filter change, the oil and filters will be changed.

Clean parts with SOLVENT, DRY-CLEANING (P-D-680).

2-10 GENERAL - CONTINUED

**WARNING**

Dry-cleaning solvent (P-D-680) is toxic and flammable. To avoid injury, wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes. Do not breathe vapors. Do not use near open flame or excessive heat. Do not smoke when using solvent. Failure to do so could cause **SERIOUS INJURY**. If you become dizzy while using dry-cleaning solvent, get fresh air immediately, and if necessary, get medical attention. If contact with skin or clothes is made, flush thoroughly with water. If the solvent contacts your eyes, wash them with water immediately and obtain medical aid (FM 21-11).

Before you start your lube service, observe the following:

**NEVER**

- a. Use wrong type lubricant.
- b. Use too much lubricant

**ALWAYS**

- a. Clean grease fittings before lubrication.
- b. Use these lubrication instructions as your guide.
- c. Check for lubricant and fuel leaks along with daily services.

After water fording, you have to lubricate.

Make sure vehicle is level when checking oil levels: If it isn't, you'll get incorrect readings on dipsticks and sight gages.

Oil filters shall be serviced/cleaned/changed as applicable, when:

- a. They are known to be contaminated or clogged;
- b. Service is recommended by AOAP laboratory analysis; or
- c. At prescribed hardtime intervals.

■ OE/HDO Lubricating Oil, ICE, Tactical Service (MIL-PRF-2104)

OEA Lubricating Oil, Internal Combustion Engine, Arctic (MIL-L-46167)

LOMD Lubricating Oil, Molybdenum Disulfide (DOD-L-25681) (9150-00-543-7220) NATO-S-1735

O-156 Lubricating Oil, Aircraft Turbine Engine (MIL-L-23699)

2-10 GENERAL - CONTINUED

2-10.2 Lubrication Instructions - Continued

LUBRICANT/COMPONENT	CAPACITIES	Above +5_F (Above -15_C)	+5_F to -65_F (-15_C to -54_C)	LUBRICANT FOR EXPECTED TEMPERATURE			INTER- VALS
				Above +15_F (Above -9_C)	+40_F to -15_F (+4_C to -26_C)	+40_F to -65_F (+4_C to -54_C)	
OE/HDO (MIL-PRF-2104) Lubricating Oil, ICE, Tactical  OEA (MIL-L-46167) Lubricating Oil, ICE, Arctic  <u>Engine</u>  <u>Final Drive</u>	27 Qts. (25.54 LI)  As Req.	OE/ HDO-15/40 (0-1236)  See NOTE 2	OEA  See NOTE 2	OE/HDO-15/40 (0-1236) or OE/HDO-30 (0-238)  See NOTE 2	OE/HDO-15/40 (0-1236) or OE/HDO-10 (0-237)  See NOTES 1&2	OEA (0-183)	For arctic operation, refer to FM 9-207
Transmission & Generator, 650 AMP	49 Qts. (46.35 LI)  As Req.	OE/ HDO-15/40 (0-1236)  See NOTE 2	OEA  See NOTES 1&2	OE/HDO-15/40 (0-1236) or OE/HDO-10 (0-237)	OE/HDO-15/40 (0-1236) or OE/HDO-10 (0-237)	OEA (0-183)	
GAA (MIL-PRF-10924) Grease, Automotive and Artillery  LOMD NATO-S-1735 Lubricating Oil, Molybdenum Disulfide							
Engine Mount Screw	As Req.	GMD or LOMD All Temperatures					
0-156 (MIL-L-23699) Lubricating Oil, Aircraft Turbine Engine  Fan Gear Case	As Req.						

NOTE

1. If OEA lubricant is required to meet the low expected-temperature range, OEA lubricant is to be used in lieu of OE/HDO-10 lubricant for all expected-temperature ranges where OE/HDO-10 is specified in the KEY.
2. Multigrade oil (15W-40) does not automatically replace single weight oils. Use 15W-40 oil to avoid seasonal oil changes if your operational conditions match the table.

## 2-10 GENERAL - CONTINUED

### 2-10.3 Procedures.

- a. Routine applications. TM 9-2350-314-10 contains maintenance instructions which the Unit mechanic must use to perform his duties.
- b. Crew participation. The crew will accompany the vehicle and help the Unit mechanics perform the Unit services.



Do not direct a stream of water or steam against the opening between the hull and cab (cab race ring), grilles, exhaust deflectors, fire control, or armament openings. Failure to comply may cause equipment damage.

- c. Vehicle cleanliness. The crew should bring a clean vehicle to a scheduled preventive maintenance service. It should be dry and not caked with mud. Washing the vehicle should not be done just before an inspection. Some defects, such as loose parts and oil leaks, may not be noticed immediately after washing.

### 2-10.4 Services.

- a. Unit level services are defined by, and limited to, the following general procedures. Approval to perform higher level services must be given by the supporting maintenance unit.
- b. Adjustment. Make all needed adjustments using instructions in this manual and/or technical bulletins.
- c. Cleaning. Clean the unit to remove old lubricant, dirt, and other foreign matter. Special cleaning instructions are given as needed.
- d. Special lubrication. Special lubrication applies either to lubrication operations that do not appear in TM 9-2350-314-10 or to items that do appear, but which should be done with the annual service.
- e. Service. Servicing covers operations such as adding battery water, draining and refilling units with oil, and changing or cleaning the oil filters, fuel filters, and air cleaners.
- f. Tightening. All tightening operations should be done according to specified torque readings where noted in this manual. When torque isn't specified, care should be taken not to strip or distort threads by overtightening. Use a torque wrench where specified. Tightening includes the correct installing of lockwasher, nut, lockwire, or cotter pin needed to secure the tightened nut or bolt in place. Refer to Appendix D for torque requirements.
- g. Repair. Restore an item to a serviceable condition. This includes, but is not limited to, inspection, cleaning, preserving, adjusting, replacing, welding, riveting and strengthening.

## 2-11 PROCEDURES FOR SEMIANNUAL AND ANNUAL SERVICES.

DA Form 2404, Equipment Inspection and Maintenance Worksheet, is used by the mechanic to record periodic maintenance services performed and faults corrected. The item number on the DA Form 2404 must correspond to the item number of the preventive maintenance check.

Specified items to be checked SEMIANNUALLY and ANNUALLY are found in Table 2-1. Before you begin to check specific items, remember to check things common in all areas.

## 2-11 PROCEDURES FOR SEMIANNUAL AND ANNUAL SERVICES - CONTINUED

### NOTE

Perform Unit Maintenance level repair or replacement as authorized. Report faulty equipment which is beyond Unit Maintenance level as prescribed in DA PAM 738-750.

#### 2-11.1 Electrical Wires and Connectors.

Electrical wiring should be checked for cracks due to aging and for exposed wires which cause electrical shorts. Repair with electrical tape or replace. Check connectors and tighten if loose (complete hull wiring diagram, harnesses and detail in Chapter 8 and electrical schematics (foldout pages) of this manual). Notify support maintenance if further repair is required.

#### 2-11.2 Welds.

Many items are attached to the hull with welds. Check for damaged welds by looking for chipped paint or oxidation. Notify support maintenance if further repair is required.

#### 2-11.3 Seals.

Check for leaks around seals. Check gasket material. Check door and hatch seals. Check for deterioration, cracks, and tears.

#### 2-11.4 Bolts.

Check for loose bolts. A loose bolt can be difficult to spot without actually applying a wrench. You can often tell by loose or chipped paint around the bolt head and bare metal or oxidation present at the base of the bolt head.

#### 2-11.5 Hoses and Fluid Lines.

Check all hoses and lines for signs of wear (deterioration or cracks), leaks, loose clamps, and loose fittings. A stain around a fitting is a sign of a leak. Tighten, repair, or replace hoses and fittings.

#### 2-11.6 Inserts.

If inserts are damaged when removing a component, notify support maintenance.

#### 2-11.7 Corrosion Prevention and Control.

Corrosion Prevention and Control (CPC) of Army materiel is a continuing concern. It is important that any corrosion problems with this item be reported so that the problem can be corrected and improvements can be made to prevent the problem in future items. Refer to Appendix G of this manual for more information on unit level CPC.

#### 2-11.8 Classification of Fluid Leaks.

The following definitions concern types/classes of fluid leakage. Each crewmember must be familiar with these definitions in order to determine whether or not the vehicle is mission capable.



## 2-11 PROCEDURES FOR SEMIANNUAL AND ANNUAL SERVICES - CONTINUED



Equipment operation is allowable with minor leakage (Class I or II). Consideration must be given to the fluid capacity in the item/system being checked/inspected. When in doubt, notify your supervisor. When operating with Class I or Class II leaks, continue to check fluid levels as required in your PMCS. Class III leaks should be reported to unit maintenance supervisor.

Class I: Seepage of fluid (indicated by wetness or discoloration) not great enough to form drops.

Class II: Leakage of fluid great enough to form drops but not enough to cause drops to drip from item being checked/inspected.

Class III: Leakage of fluid great enough to form drops that fall from the item being checked/inspected.

### 2-11.9 Warning and Cautions.


Always observe the WARNINGS and CAUTIONS appearing in your PMCS table. Warnings and cautions appear before applicable procedures. You must observe these WARNINGS and CAUTIONS to prevent serious injury to yourself and others or to prevent your equipment from being damaged.

### 2-11.10 Explanation of Table Entries.

- a. Item Number column. Numbers in this column are for reference. When completing DA Form 2404 (Equipment Inspection and Maintenance Worksheet), include the item number for the check/service indicating a fault. Item numbers also appear in the order that you must do checks and services for the intervals listed.
- b. Interval column. This column tells you when you must do the procedure listed in the procedure column. SEMIANNUAL procedures must be done every 6 months, or 1500 miles, or 150 hours of vehicle operation. ANNUAL procedures must be done every 12 months, or 3000 miles, or 300 hours, of vehicle operation.
- c. Location, Item to Check/Service column. This column provides the location and the item to be checked or serviced. The item location is underlined.
- d. Procedure column. This column gives the procedure you must do to check or service the item listed in the Check/Service column to know if the equipment is ready or available for its intended mission or for operation. You must do the procedure at the time stated in the interval column.
- e. Not Fully Mission Capable If: column. Information in this column tells you what faults will keep your equipment from being capable of performing its primary mission. If you make check and service procedures that show faults listed in this column, do not operate the equipment. Follow standard operating procedures for maintaining the equipment or reporting equipment failure.





**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
1	SEMIANNUALLY	EXTERIOR	<p>Perform lubrication as required by TM 9-2350-314-10.</p> <div data-bbox="850 569 1101 663" style="border: 2px solid black; padding: 5px; text-align: center; margin: 10px 0;"> <p><b>WARNING</b></p> </div> <p>Cylinders must not be dropped, struck, or subject to any temperature above +140° F (60° C). An explosion may result, causing severe injury or DEATH.</p> <p>Disconnect fire extinguisher cylinders (para 21-1). Operate exterior discharge handle (1) to ensure cable does not bind. Check to ensure handle (1) is properly seated and new wire and seal (2) are laced and sealed.</p>	<p>Cable binds. Wire and seal (2) broken, missing, or extinguisher handle (1) is pulled.</p>
2		Fire extinguisher system		
3		Stencil markings	Restencil markings that are not legible (para 18-14). Refer to TM 9-2350-314-10 for stencil locations.	





76ph007m


**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
4	SEMIANNUALLY	EXTERIOR	<p>Check electrical wiring harness and connectors at front bulkhead (1) and actuator (2) for cuts, breaks, and proper mounting.</p>   <p style="text-align: right;">18ph258m</p>	<p>Wiring harness or connectors are broken.</p>
		<p>Travel lock electrical connectors</p>		
4.1		<p>Final Drive Drain and Refill</p>	<p>a. Remove end cover (1). Inspect bearing retainer nut (2) and cotter pin (3).</p>  <p style="text-align: right;">08ph043m</p> <p>b. Add oil (item 30, Appendix C) at level-check opening.</p> <p>c. Clean level-check plugs (4), apply antiseizing tape (item 60, Appendix C) to threads, and install level-check plugs (4).</p>  <p style="text-align: right;">08ph044m</p>	<p>Any visual signs of a loose nut or sheared cotter pin, final drive will be removed and replaced.</p>

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
5	SEMIANNUALLY	BATTERY AND ENGINE COMPARTMENT  Batteries	<p>Open transmission access doors (1), air intake grille (2), and battery compartment access doors (3) (TM 9-2350-314-10). Remove fan access door (4) (para 16-26) and hull exhaust grille (5) (para 16-25).</p>  <p style="text-align: right; font-size: small;">18ph107m</p> <div style="border: 2px solid black; padding: 5px; text-align: center; margin: 10px 0;"><b>WARNING</b></div> <p>Battery gasses can explode. Do not smoke, have open flame, or create sparks around a battery. Severe injury may result due to explosion. Remove all chains, rings, and watches.</p> <ol style="list-style-type: none"> <li>a. Remove battery caps (1) from all cells of four batteries (2). Each cell must be tested separately.</li> <li>b. Test specific gravity of each battery (2) with duo-tester (item 39, Appx F).</li> </ol> <p>If duo-tester indicates a specific gravity reading of 1.120 or less, battery (2) must be recharged.</p>  <p style="text-align: right; font-size: small;">06ph073m</p>	<p>If batteries are below 1.120 specific gravity, cracked or unserviceable.</p>


**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
6	SEMIANNUALLY	BATTERY AND ENGINE COMPARTMENT	<p>Check all connections (1) for evidence of leaks. Change fuel filter elements (primary and secondary) (2) (para 5-14).</p> 	Leaks as defined in para 5-14 exist.
		Fuel system		

03ph037m


**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
7	SEMIANNUALLY	BATTERY AND ENGINE COMPARTMENT  Engine fan drive system	<p>Perform backlash test as follows:</p> <ol style="list-style-type: none"> <li>Remove powerpack (para 4-1).</li> <li>Mark any accessible blade (1).</li> <li>While holding opposite fan impeller, rotate marked blade as far left as possible. Mark fan housing directly above blade mark (2).</li> <li>While holding opposite fan impeller, rotate marked blade as far right as possible. Mark fan housing directly above blade mark (3).</li> <li>Measure distance between marks (2) and (3). If distance (4) is over 1 inch (2.5 cm), backlash is excessive. Notify support maintenance if this condition exists.</li> <li>By hand attempt to rotate nut (5). Ensure key washer locking tabs are fully bent into the slots of the lock nut (6). If any looseness is found, notify Support Maintenance.</li> </ol>	<p>Excessive backlash is measured. If locking hardware is missing or not secure.</p>



**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**


ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
7	SEMIANNUALLY	BATTERY AND ENGINE COMPARTMENT	<p>g. Remove eight screws (5) and radiator shroud cover (6). Inspect two fan drive shafts (7) for cracked rubber boots (8) or loose retaining rings (9). If rubber boots (8) are cracked or retaining rings (9) are loose, replace fan drive shafts (para 7-11).</p> <p>h. Install radiator shroud cover (6) with eight screws (5).</p>	
		Engine fan drive system - Continued		



05ph035m

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
8	SEMIANNUALLY	BATTERY AND ENGINE COMPARTMENT	<div style="border: 2px solid black; padding: 5px; width: fit-content; margin: 0 auto;"><b>WARNING</b></div>	
		Fan gear case	<p>Dry-cleaning solvent (P-D-680) is toxic and flammable. To avoid injury, wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes. Do not breathe vapors. Do not use near open flame or excessive heat. Do not smoke when using solvent. Failure to do so could cause <b>SERIOUS INJURY</b>. If you become dizzy while using dry-cleaning solvent, get fresh air immediately, and if necessary, get medical attention. If contact with skin or clothes is made, flush thoroughly with water. If the solvent contacts your eyes, wash them with water immediately and obtain medical aid (FM 21-11).</p> <p>Remove radiator from shroud (para 7-1). Clean area around plug (1) on fan gear box housing (2) with P-D-680 (item 59, Appx C). Remove plug (1). Check that oil level is up to bottom of hole. If not, add 0-156 (item 35, Appx C) until oil level reaches bottom of hole. Clean plug (1) with P-D-680 before installing.</p>	






**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
9	SEMIANNUALLY	BATTERY AND ENGINE COMPARTMENT	<p style="text-align: center;"><b>NOTE</b></p> <p>Powerpack must be removed to perform item number 9. Perform item number 9 at a time on or near the semi-annual service when the powerpack has been removed for maintenance or when evidence that a maintenance problem exists. Do not remove the powerpack just to perform this inspection.</p> <p>If powerpack is removed, lube screw (1) with GMD or LOMD.</p>	
		Engine mounting base		




01ph020m

Install powerpack (para 4-1).

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**


ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
10	SEMIANNUALLY	BATTERY AND ENGINE COMPARTMENT	<p>Inspect upper fuel tank (1) and exhaust heat shield (2) for damage. Check condition and tightness of all seals and fasteners (paras 5-11, 5-12, and 6-3).</p> <p>Close transmission access doors (3), air intake grille (4), and battery compartment access doors (5) (TM 9-2350-314-10). Install hull exhaust grille (6) (para 16-25) and fan access door (7) (para 16-26).</p>	
		Fuel tank and exhaust heat shield		



18ph103m

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**



ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
11	SEMIANNUALLY	INTERIOR	<ol style="list-style-type: none"> <li>a. Ensure ventilation intake/exhaust duct grille is clear of debris.</li> <li>b. Turn vehicle MASTER switch ON.</li> <li>c. Move ventilation fan selection switch (1) to LEAD FILTER (INTAKE).</li> <li>d. Check for air flow at filter cover (2).</li> <li>e. Cover the grille surface cover (2) with a 12"x12" piece of cardboard or wood.</li> <li>f. Press lamp test cover (3) and observe if LEAD FILTER CHANGE lamp illuminates. If LEAD FILTER CHANGE lamp illuminates with grille covered, this will indicate LEAD FILTER is clogged and CHANGE lamp is operating properly.</li> <li>g. Remove cardboard or wood from grille surface.</li> </ol>	
		Lead particulate filter and ventilation system		



18ph105m


**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
12	SEMIANNUALLY	INTERIOR  Fire extinguisher system	<div style="border: 2px solid black; padding: 5px; text-align: center; margin-bottom: 10px;"><b>WARNING</b></div> <p>Cylinders must not be dropped, struck, or subject to any temperature above +140° F (60° C). An explosion may result causing severe injury or DEATH.</p> <p>Ensure fire extinguisher cylinders are disconnected (para 21-1). Operate driver's discharge handle (1) to ensure cable does not bind. Install new seal and wire (2) on control valve (3) and driver's discharge handle (1). Remove fixed fire extinguisher cylinders (4) (para 21-1). Take cylinders to appropriate maintenance activity IAW local SOP for serviceability determination. Install fixed fire extinguishers (4) (para 21-1). Make sure bottle hold down brackets (5) are properly latched. Check distribution lines (6) for loose fittings, tight mountings, and cracks.</p>	<p>Cables bind. Wire and seal (2) broken, missing, or extinguisher handle (1) is pulled.</p> <p>Distribution lines (6) loose, cracked, or not mounted tightly.</p>





76ph008m

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
13	SEMIANNUALLY	INTERIOR	<div style="border: 2px solid black; padding: 5px; text-align: center; margin-bottom: 10px;"><b>WARNING</b></div> <p>If NBC exposure is suspected, all air filter media will be handled by personnel wearing full NBC protective equipment and proper handling and disposal procedures followed.</p> <p>Check for worn or missing seals (1) and hoses (2). Check blower motors for operation. Troubleshoot if necessary (Chapter 3). Clean, repair, or replace motors, seals, and filter packs as required (para 5-5 and 5-8). Clean filter as follows:</p> <div style="border: 2px solid black; padding: 5px; text-align: center; margin-bottom: 10px;"><b>WARNING</b></div> <p>Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment (goggles/shield, gloves, etc.).</p> <ol style="list-style-type: none"> <li>a. Shake out dust. Using compressed air, clean filter by applying compressed air to inside of filter and blowing dust outward away from filter.</li> <li>b. Replace filter elements which have holes or ruptures.</li> </ol>  <p style="text-align: right; font-size: small;">03ph039m</p>	<p>Any seals or hoses cracked, worn, or missing.</p> <p>Blower motors inoperative.</p> <p>Air cleaner filters clogged or wet.</p> <p>Air cleaner doors, filter elements, or hoses are missing.</p> <p>Air cleaner doors won't open or close properly.</p>
		Air cleaner filter		

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**


ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
14	SEMIANNUALLY	INTERIOR  Air cleaner indicator	Check indicator (1) for damage and corrosion. Check to see that bracket (2) is secure. Check two nuts (3) for tightness. Check hose fitting (4) for leaks. Tighten as required.	
15		Generator belt, pulleys and belt tensioner	Remove engine compartment access cover (para 16-7). Inspect generator belt (1) for frays or cracks. Replace as required (para 8-1). Check belt tensioner (2) and pulley (3) for looseness or cracks. Replace as required (para 8-2). Tighten tensioner bolt (4) in accordance with para 8-2. Tighten pulley bolt (5) as required. Check generator pulley (6) and bracket (7) for looseness or cracks. Replace pulley (6) and bracket (7) as required. Tighten bracket bolts (8) in accordance with para 8-3.	Belt is frayed or cracked. Belt tensioner, pulleys or bracket is loose or cracked.



**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
16	SEMIANNUALLY	INTERIOR	<div style="border: 2px solid black; padding: 5px; text-align: center; margin-bottom: 10px;"><b>WARNING</b></div> <p>If NBC exposure is suspected, all air filter media will be handled by personnel wearing full NBC protective equipment and proper handling and disposal procedures followed.</p> <ol style="list-style-type: none"> <li>a. Inspect condition of hose assemblies (1). Check for deterioration, loose connections, holes, and other damage (para 22-1 and 22-3).</li> <li>b. Inspect electrical cable assemblies (2) for damaged insulation and broken or damaged terminals.</li> <li>c. Operate ventilated face piece system (TM 9-2350-314-10). Check that air moves through each air hose outlet orifice connector (3).</li> </ol> <p style="text-align: center;"><b>NOTE</b></p> <p>Allow M3 heater to operate for approximately 15 minutes before checking for warm air circulation.</p> <ol style="list-style-type: none"> <li>d. Check operation of M3 heater (4) by turning control knob (5) ON. Indicator light should be lit and air should get warmer as knob is turned clockwise.</li> <li>e. Troubleshoot MCS system if defective (Chapter 3).</li> </ol>	
		MCS equipment		


**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
16	SEMIANNUALLY	INTERIOR		
		MCS equipment-Continued		


18ph104m



**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
17	SEMIANNUALLY	INTERIOR	<p>Check all areas inside of vehicle for fuel or hydraulic oil leaks.</p> <p>Replace decals and instruction plates or stencils that are not legible (para 18-13 or 18-14).</p> <div style="border: 2px solid black; padding: 5px; text-align: center; margin: 10px 0;"><b>WARNING</b></div> <p>Clear all personnel and equipment from hull while travel lock controls are inspected.</p> <p>Check control box lights for proper operation. Follow troubleshooting procedures in Chapter 3 if malfunction occurs.</p> <ol style="list-style-type: none"> <li>a. Turn vehicle MASTER switch ON (TM 9-2350-314-10).</li> <li>b. POWER light (1) should light when ON/OFF switch (2) is ON.</li> <li>c. R/U light (3) should light when switch (4) is at RAISE/UNLOCK position. L/L light (5) should light when switch (4) is at LOWER/LOCK position.</li> <li>d. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).</li> </ol> <div style="text-align: center; margin-top: 20px;">  <p style="text-align: right; margin-right: 50px;">06ph076m</p> </div>	Any Class III leak is present.
18		Leakage from hydraulic systems or personnel heater		
19		Decals, instruction plates, and stencil markings Travel lock control box		


**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
20	SEMIANNUALLY	INTERIOR	<p>Inspect seat belt (1), seat, and backrest cushions (2 and 3) for deterioration. Make sure seat belt (1) buckle and end plate engage securely. Ensure seat adjustment levers (4 and 5) securely lock seat in all positions. Fold and unfold backrest (6) and check for binding. Check for loose or missing mounting hardware.</p>  <p>18ph022ma</p>	<p>Seat belts (1) or buckles are worn or damaged.</p>
		Driver's seat		

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
21	ANNUALLY	EXTERIOR	<p>Inspect roadwheels for rubber separation (1) and missing rubber chunks that may cause thumping. Check for cracks in wheel (2). Tighten nuts (3) to 162-198 lb-ft (219-268 N·m) with torque wrench (item 87, Appx F).</p> <p>Measure roadwheel wear as follows:</p> <ol style="list-style-type: none"> <li>a. Pull out threaded rod (4) and place gage (5) (item 23, Appx F) over roadwheel as shown, backing off knurled knob (6) as required.</li> <li>b. When gaging balls (7) are in contact with wear ring (8) and inside of wheel disk (9), slowly turn knurled knob (6) clockwise until it just contacts rod housing. Do not tighten knob (6), since this will pull inner gage ball (7) away from wheel disk (9).</li> <li>c. Pull rod (4) back, without disturbing knob (6) until gage (5) can be removed from the wheel.</li> <li>d. Push rod (4) in until knob (6) contacts housing. Measure dimension between gaging balls (7).</li> <li>e. If the dimension between the balls (7) is 7/16 inch (11 mm) or less, roadwheel should be replaced (para 12-5).</li> </ol>	<p>Missing, bent or cracked roadwheel or idler wheel; elongated roadwheel or idler wheel mounting holes; separation of 1/2 of rubber contact from steel hub; chunking across 1/2 width of outer rubber surface on any pair of roadwheels (inner and outer); torsion bars missing or broken.</p> <p>Roadwheel (2) and idler wheel arms damaged, bent, broken, or missing.</p> <p>Dimension between gaging balls (7) is less than 7/16 inch (11 mm) (TM 9-2350-200-24).</p>
		Roadwheels and idler wheels		

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
21	ANNUALLY	EXTERIOR		
		Roadwheels and idler wheels - Continued		

13ph020m

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**



ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
22	ANNUALLY	EXTERIOR	a. Tighten upper and lower bumper stop mounting bracket bolts (1) (para 15-2). b. Tighten hydraulic bumper stop mounting retaining nuts (2) (para15-3).	
		Bumper stop mounting brackets		


FORWARD

13ph023m

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**



ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
23	ANNUALLY	EXTERIOR	<p>Check for missing shock absorber cotter pins (1). If missing, check torque, and replace cotter pin in accordance with para 15-1.</p> 	
24		Torsion bars	<p>Pry up each roadwheel (1) with crowbar (item 12, Appx F) to see if there are broken torsion bars. Check that torsion bar plugs (2) are fully seated and retaining screws (3) are in place.</p> 	Any torsion bar is broken.

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
25	ANNUALLY	EXTERIOR Drive sprocket and hubs	<p>Each series drive sprocket (1) has two teeth (2) with wear marks. If either tooth is worn to edge of wear mark (3), replace drive sprocket (para 12-12). Tighten mounting bolts (4) to 90 lb-ft (122 N·m) with torque wrench (item 86, Appx F) and tighten hub bolts (5) to 450-475 lb-ft (610-644 N·m) with torque wrench (item 87, Appx F).</p>  <p style="text-align: right;">13ph022m</p>	Sprocket tooth is worn to edge of wear mark; mounting bolts are loose or missing.

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
26	ANNUALLY	EXTERIOR  Tracks	<p>Measure thickness of center guide (1) at a point 1 inch (2.5 cm) from end. Replace track block if center guide measures less than 1/4 inch (6.4 mm) or grouser (2) measures less than 1/4 inch (6.4 mm). Replace pads (3) when worn even with metal grouser (2) (para 12-13). Tighten connector screws (4) to 380-420 lb-ft (515-570 N-m) with torque wrench (item 87, Appx F).</p>	<p>Three or more distorted (dead) shoes indicating excessive rubber bushing wear, missing or cracked end connectors, two consecutive missing center guides, or any end connector bolts missing (TM 9-2350-200-24).</p>
27		Drain covers and plugs	<p>Check that 19 drain plugs and four access covers are present. Replace or secure access covers and plugs on underside of hull (para 16-39 and 16-41).</p>	<p>Any drain plugs or access covers are not present for fording operation.</p>







**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
28	ANNUALLY	EXTERIOR	Check for cracks in rubber (1) and for missing screws (2).	
		Fuel filler neck seal		

FORWARD






03ph040m

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
29	ANNUALLY	BATTERY AND ENGINE COMPARTMENT	<div style="border: 2px solid black; padding: 5px; text-align: center; margin-bottom: 10px;"><b>WARNING</b></div> <p>Do not remove a radiator cap from a warm engine. Coolant can burn severely.</p> <p>Check for cracked, weak, or broken hoses. Check coolant system for leakage. Check coolant level. Remove eight screws (1) and shroud cover (2).</p> <p>Clean radiator with oil cleaning tool (item 10, Appx F) and a cleaning agent which removes deposits of sand, oil, clay, and other debris from radiator cooling fins while installed in vehicle.</p>	Coolant is not visible in filler neck; Class III leak is present or hoses are unserviceable.
		Cooling system, radiator hoses, and pumps		



05ph039m

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**


ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
29	ANNUALLY	BATTERY AND ENGINE COMPARTMENT	<p>Clean radiator as follows:</p> <ul style="list-style-type: none"> <li>a. Open hull drains.</li> <li>b. Cover all exposed openings of engine.</li> </ul> <p style="text-align: center;"><b>NOTE</b></p> <p>Cleaning agent can be a solution of detergent and water or of nontoxic, nonflammable solvent and water. The cleaning agent may be mixed one part detergent to five parts water.</p> <ul style="list-style-type: none"> <li>c. Connect tool (item 10, Appx F) to air supply. Insert liquid supply hose into container of cleaning solution.</li> <li>d. Insert tool through shroud cover opening and wet front and back of radiator with cleaning solution. Soak for approximately 10 minutes.</li> <li>e. Remove heavy deposits from face of radiator by brushing with medium stiff brush that will not damage fins.</li> <li>f. Blast radiator with air/solution mixture, holding head of tool approximately 1/2 inch (12.7 mm) from face of radiator. Alternate from back to front until cleaning solution flows smoothly through radiator.</li> <li>g. Drain the container and fill with clean water. Flush engine parts and radiator completely. Remove liquid supply hose from container and use air to complete operation.</li> <li>h. Uncover engine openings and install radiator shroud cover (2) with eight screws (1). Close hull drains.</li> </ul>	Radiator is unserviceable.
		Cooling system, radiator hoses, and pumps - Continued		


**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
30	ANNUALLY	BATTERY AND ENGINE COMPARTMENT	<p>Remove and clean pressure relief valve (para 7-3) as follows:</p> <ol style="list-style-type: none"> <li>a. Unscrew nut (1) and remove hose (2) from lower end of pressure relief valve block (3).</li> <li>b. Remove four screws (4). Lift off relief valve (5). Discard gasket (6).</li> <li>c. Wipe off accumulation of rust. Depress spring to ensure it is not broken.</li> <li>d. Install pressure relief valve (para 7-3).</li> </ol>	Pressure relief valve (5) is unserviceable.
		Cooling system pressure relief valve		

FORWARD →






05ph040

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**


ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
31	ANNUALLY	BATTERY AND ENGINE COMPARTMENT	<div style="border: 2px solid black; padding: 5px; text-align: center; margin-bottom: 10px;"><b>WARNING</b></div> <p>Do not remove a radiator cap from a warm engine. Hot coolant can burn severely.</p> <p>Remove quick-release pin (1), open radiator access cover (2) and slowly remove radiator cap (3).</p> <p>Coolant should be visible. If not, start engine and slowly add coolant until it reaches the top of filler neck. Run engine until new coolant is mixed with old coolant.</p> <p>Use optical battery/antifreeze tester (item 39, Appx F) to test coolant protection. Test radiator coolant for proper protection (TB 750-651).</p>	Does not pass alkalinity test in TB 750-651. Not protected to -20° F (-30° C).
		Coolant		



**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
32	ANNUALLY	BATTERY AND ENGINE COMPARTMENT	Perform STE PMCS testing (Chapter 3).  <div style="border: 2px solid black; padding: 5px; text-align: center; width: fit-content; margin: 10px auto;"><b>CAUTION</b></div> <p>Do not dry test bilge pump longer than 1 minute.</p> <p>Check bilge pump for proper operation. Turn vehicle MASTER switch (1) ON and turn bilge pump switch (2) ON. If engine compartment is dry, feel for air at bilge pump outlet (3).</p>	
33		Bilge pump		


FORWARD



06ph077m



**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
34	ANNUALLY	BATTERY AND ENGINE COMPARTMENT	Replace damaged components (Chapter 6). Check all clamps (1), mounting bolts (2), springs (3), and brackets (4).	Exhaust leak is present.
		Exhaust outlet duct		



04ph001m



**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
35	ANNUALLY	BATTERY AND ENGINE COMPARTMENT		
		Final drive quick-disconnect and universal joint safety wiring (both sides)	<p>Check for missing or broken wires (1). Tighten mounting bolts (2) to 37-42 lb-ft (50-57 N-m) with torque wrench (item 86, Appx F). Replace wires (1) if wires are missing, loose, or broken.</p>  <p>08ph026m</p>	Any loose, broken, or missing bolts or wires.
			<p>Close transmission access doors (3), air intake grille (4), and battery compartment access doors (5) (TM 9-2350-314-10). Install exhaust grille (6) (para 16-25) and fan access cover (7) (para 16-26).</p>  <p>18ph108m</p>	




**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**



ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
	ANNUALLY	BATTERY AND ENGINE COMPARTMENT	<p align="center"><b>NOTE</b></p> <p>Refer to Army Oil Analysis Program (AOAP) DA PAM 738-750.</p>	
36		Transmission	<p>Annually, drain transmission (only after operation). Place vehicle on level ground, remove cover plate (1) on bottom of hull, and remove drain plug (2). After draining, clean and reinstall plug and cover. Refill transmission with OE/HDO to within operating range on dipstick (TM 9-2350-314-10). Refill is approximately 49 qts (46.35 LI).</p> <p>For extreme cold operation with OEA this is a semi-annual check.</p> <div style="border: 1px solid black; padding: 5px; text-align: center; width: fit-content; margin: 10px auto;"><b>WARNING</b></div> <p>Dry-cleaning solvent (P-D-680) is toxic and flammable. To avoid injury, wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes. Do not breathe vapors. Do not use near open flame or excessive heat. Do not smoke when using solvent. Failure to do so could cause <b>SERIOUS INJURY</b>. If you become dizzy while using dry-cleaning solvent, get fresh air immediately, and if necessary, get medical attention. If contact with skin or clothes is made, flush thoroughly with water. If the solvent contacts your eyes, wash them with water immediately and obtain medical aid (FM 21-11).</p> <p>Remove cover (3) and then remove filter element. Inspect, clean with P-D-680, dry and reinstall.</p> <p><b>NOTE</b></p> <p>VMS Removed for clarity.</p>	




**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
37	ANNUALLY	BATTERY AND ENGINE COMPARTMENT	<p align="center"><b>NOTE</b></p> <p>Refer to Army Oil Analysis Program (AOAP) DA PAM 738-750.</p> <p>Annually, drain engine crankcase (only after operation). Coordinate any required seasonal change of oil weight with this service, if possible.</p> <p>Place vehicle on level ground, remove cover plate (1) on bottom of hull, and remove oil drain plug (2). After draining, clean and reinstall plug and cover. Refill crankcase with OE/HDO up to ADD mark on dipstick (TM 9-2350-314-10). Refill is approximately 27 qts (25.54 LI) (dry 38 qts (36 LI)).</p> <p>For extreme cold operation with OEA this is a semi-annual check.</p> <div style="border: 1px solid black; padding: 5px; text-align: center; margin: 10px 0;"><b>WARNING</b></div> <p>Dry-cleaning solvent (P-D-680) is toxic and flammable. To avoid injury, wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes. Do not breathe vapors. Do not use near open flame or excessive heat. Do not smoke when using solvent. Failure to do so could cause <b>SERIOUS INJURY</b>. If you become dizzy while using dry-cleaning solvent, get fresh air immediately, and if necessary, get medical attention. If contact with skin or clothes is made, flush thoroughly with water. If the solvent contacts your eyes, wash them with water immediately and obtain medical aid (FM 21-11).</p> <p>Drain oil filters, remove elements, clean shell parts with P-D-680. Dry, inspect, and reinstall with new elements.</p> <p align="center"><b>NOTE</b></p> <p>Travel lock assembly and grille removed for clarity.</p>	
		<p align="center">Engine crankcase</p>  <p align="center">OIL FILTERS</p> <p align="right">01ph021m</p>		


**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
38	ANNUALLY	INTERIOR	<p data-bbox="699 478 1195 596">Move transmission shift control lever to all positions. Shift control lever should not bind. If binding occurs, adjust as prescribed (para 9-1).</p>  <p data-bbox="1078 1073 1175 1094">07ph014m</p>	<p data-bbox="1227 478 1446 562">Transmission shift lever is unserviceable.</p>
		Transmission shift control		
39		Neutral safety switch	<p data-bbox="699 1121 1195 1297">Clear personnel and equipment from near vehicle. Apply brakes and pull out fuel shut-off control. Attempt to crank engine in gear. If starter engages, stop immediately and follow troubleshooting procedure (Chapter 3).</p>  <p data-bbox="1078 1787 1175 1808">07ph002m</p>	Neutral safety switch is defective.


**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
40	ANNUALLY	INTERIOR		
		Starter protection relay	<p>Check for proper operation of starter protection relay (shift control lever in neutral position).</p>  <p style="text-align: right; margin-right: 50px;">07ph015m</p> <ol style="list-style-type: none"> <li>a. Pull fuel shutoff to prevent engine from starting during procedure (TM 9-2350-314-10).</li> <li>b. Engage starter (TM 9-2350-314-10). Note amount of time starter cranks and when it stops.</li> </ol> <p style="text-align: center;"><b>NOTE</b></p> <p>During normal operation, when starter is cranking, the starter protection device should automatically cut starter off after cranking for the following period of time:</p> <ol style="list-style-type: none"> <li>a. 25-35 seconds at 50° F (10° C) or above.</li> <li>b. 55-65 seconds at 0° to 50° F (-18° to 10° C).</li> <li>c. 100-140 seconds at 0° to -50° F (-18° to -45° C).</li> </ol> <p>Starter protection device should reset in 105-140 seconds. If starter does not shut off as indicated or device will not reset, replace device.</p> <ol style="list-style-type: none"> <li>c. If starter cranks for more than 21 to 31 seconds, troubleshoot starter protection circuit (Chapter 3).</li> <li>d. If starter cranks 21 to 31 seconds, wait two minutes and try to engage engine again. If starter operates, troubleshoot starter protection circuit (Chapter 3).</li> </ol>	

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
40	ANNUALLY	INTERIOR	<div data-bbox="846 506 1073 585" style="border: 2px solid black; border-radius: 15px; padding: 5px; text-align: center; margin-bottom: 10px;"> <b>CAUTION</b> </div> <p data-bbox="743 625 1149 791">Combat override switch should be used only in an emergency or when tested as in this step. Excessive use may damage starter.</p> <p data-bbox="716 812 1206 978">e. Place combat override switch ON (TM 9-2350-314-10) and engage starter for five seconds or less. If starter does not operate, troubleshoot starter protection circuit (Chapter 3).</p> <p data-bbox="716 1010 1190 1247">f. Place combat override switch OFF. Release fuel shut-off handle and attempt to start engine. If starter engages before 2.0 minutes and 2.8 minutes have elapsed since step b, troubleshoot starter protection circuit (Chapter 3).</p> <div data-bbox="690 1346 1154 1835" style="text-align: center;">  </div> <p data-bbox="1094 1829 1214 1850" style="text-align: right; font-size: small;">06ph078m</p>	
		Starter protection relay - Continued		



**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
41	ANNUALLY	INTERIOR  Instrument panel	<p>Check all lights and gages for proper operation. Follow troubleshooting procedures in Chapter 3 if malfunction appears.</p> <ol style="list-style-type: none"> <li>Engine water temperature gage (1): 170° -185° F (76-85° C).</li> <li>Engine oil pressure gage (2): 30-50 psi (207-345 kPa) at 1000 rpm, 50-70 psi (345-482 kPa) at 2100 rpm. (70 psi (482 kPa) is maximum.)</li> <li>Transmission oil temperature gage (3): 220° -240° F (104-115° C) is normal. (300° F (148° C) is maximum.)</li> <li>Transmission oil pressure gage (4): 10 psi (69 kPa) at 1000 rpm minimum. 18-45 psi (124-310 kPa) at 1835-1900 rpm.</li> <li>Battery-generator indicator gage (5): green zone (charging).</li> <li>Tachometer (6) should operate without excessive fluctuation or unusual noises.</li> <li>Low coolant level indicator (7): Press-to-test for proper operation.</li> </ol>	<p>Any one of lights 7, 10, or 11 missing or not working.</p> <p>Any one of gages 1 thru 6, or 8 missing or not working.</p>
 <p>06ph079m</p>			<ol style="list-style-type: none"> <li>Fuel gage (8): indicates fuel quantity available in either tank. Use panel switch (9) to select tank.</li> <li>Master warning indicator lamp (10): Be sure lamp goes off within 15 seconds after engine starts.</li> <li>Master indicator light (11), is illuminated when vehicle MASTER switch is ON.</li> <li>Glowplug wait lamp (12): Will flash on briefly when temperature is above 50°F (10°C). Will turn on for 35 seconds, then flash on/off for a minute when temperature is below 50°F (10°C).</li> </ol>	

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:																		
	ANNUALLY	INTERIOR																				
42		Steering control	<p>Move steering wheel through its entire range.</p> <p>With vehicle operating at 15 to 20 mph (24 to 32 kmph) and steering wheel centered, observe if steering wanders or pulls to one side. Troubleshoot if required (Chapter 3).</p>	Any binding or excessive looseness is detected.																		
43		Brakes	Accelerate vehicle to 15 mph (24 kmph). Release accelerator pedal, and apply brakes. Vehicle should stop without pulling to one side. With vehicle stopped on an incline and with transmission in neutral, depress brake pedal and apply parking brake. Brakes should lock securely and hold vehicle in place. Adjust brakes if required (para 11-1).	Brakes bind or do not stop vehicle; pedal sticks; defective, inoperative, or out of adjustment parking brake.																		
44		Engine governed speed and performance	<p>Test again for acceleration and power in each gear. While testing in first gear, accelerate with wide open throttle from low speed to top speed. Governed speed under load should not exceed 2350 rpm. Maximum speeds are as follows:</p> <table border="0" data-bbox="732 1339 1170 1591"> <tr> <td>1st</td> <td>6 mph</td> <td>(9.6 kmph)</td> </tr> <tr> <td>2nd</td> <td>9 mph</td> <td>(14.5 kmph)</td> </tr> <tr> <td>3rd</td> <td>24 mph</td> <td>(38.6 kmph)</td> </tr> <tr> <td>4th</td> <td>35 mph</td> <td>(56.3 kmph)</td> </tr> <tr> <td>R1</td> <td>5 mph</td> <td>(8.0 kmph)</td> </tr> <tr> <td>R2</td> <td>7 mph</td> <td>(11.3 kmph)</td> </tr> </table>	1st	6 mph	(9.6 kmph)	2nd	9 mph	(14.5 kmph)	3rd	24 mph	(38.6 kmph)	4th	35 mph	(56.3 kmph)	R1	5 mph	(8.0 kmph)	R2	7 mph	(11.3 kmph)	Vehicle does not have at least one forward and reverse gear, and cannot attain a minimum forward speed of 10 mph (16.0 kmph) on a level, unimproved road.
1st	6 mph	(9.6 kmph)																				
2nd	9 mph	(14.5 kmph)																				
3rd	24 mph	(38.6 kmph)																				
4th	35 mph	(56.3 kmph)																				
R1	5 mph	(8.0 kmph)																				
R2	7 mph	(11.3 kmph)																				

**TABLE 2-1. UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES FOR M109A6 SELF-PROPELLED HOWITZER - CONTINUED**

ITEM NO.	INTERVAL	ITEM TO BE CHECKED OR SERVICED	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
45	ANNUALLY	EXTERIOR  Temperature of hubs and shock absorbers	<p style="text-align: center;"><b>NOTE</b></p> <p>Check item 45 immediately after road test.</p> <p>Feel all wheel hubs cautiously. Notice difference in temperature between hubs. An overheated hub (1) indicates a bearing problem. Feel lower end of shock absorber (2). Check for difference in temperature between hull and shock absorber (2). If shock absorber (2) is operating properly, it will be warmer than hull.</p> <p style="text-align: center;">FORWARD </p>  <p style="text-align: right; font-size: small;">13ph024m</p>	
46		Fuel/hydraulic oil leaks	Inspect all areas inside of vehicle for fuel or hydraulic oil leaks.	Any Class III leak found. Vehicle has damage or is missing items that would make operation hazardous.
47		Final road test	Check performance of items that were adjusted, repaired, or replaced as a result of road test.	



## Section IV. SLAVE STARTING

---

### 2-12 STARTING INSTRUCTIONS.

---

This task covers:      a. Pre-starting instructions                                      b. Starting instructions

---

**INITIAL SETUP**

Tools  
Special-purpose cable kit  
(item 8, Appx F)

Personnel Required  
Three

---

#### a. Pre-starting instructions.

- 1 Check batteries for damage. Replace damaged batteries (para 8-54).
- 2 Check electrolyte level in batteries. Replenish as required (TM 9-6140-200-14).

**WARNING**


- Do not park vehicles head to head. Personnel injury or damage to the vehicles could occur if one vehicle jumps.
- Do not allow vehicles to touch and leave enough space between vehicles to permit working room for the technician. Shorted circuits could allow electricity to flow through the vehicles causing injury to personnel and/or damage to equipment.

**Section IV. SLAVE STARTING - CONTINUED**


**2-12 STARTING INSTRUCTIONS - CONTINUED**

**a. Pre-starting instructions - Continued**

- 3 Park vehicles in a side-by-side position or park live vehicle in front of, and at right angles to, dead vehicle.



**SAFE POSITION**



18ph106m

Section IV. SLAVE STARTING - CONTINUED

2-12 STARTING INSTRUCTIONS - CONTINUED


a. Pre-starting instructions - Continued

- 4 Place both vehicles' shift levers (1) in N (neutral) position.
- 5 Set parking brakes (2) on both vehicles.



Make sure all electrical equipment and all switches are off in both vehicles to prevent damage to the electrical system.

- 6 Place vehicle MASTER switch (3) in OFF position.
- 7 Place all electrical switches in OFF position in driver's (4) and portable (5) instrument panels on both vehicles.



06ph080m

---

## Section IV. SLAVE STARTING - CONTINUED

---

### 2-12 STARTING INSTRUCTIONS - CONTINUED

---

#### a. Pre-starting instructions - Continued

- 8 Attach slave cable (6) securely to slave receptacle (7) in both vehicles.

#### b. Starting instructions.

**WARNING**

Make sure vehicle MASTER switches are OFF in both vehicles after vehicles are fully charged.




- 1 Place vehicle MASTER switch (3) to OFF position on dead vehicle.
- 2 Place vehicle MASTER switch (3) to ON in live vehicle and run engine at 1000 to 1200 rpm.
- 3 Allow batteries in dead vehicle to charge for 5 minutes before trying to start the engine.
- 4 Idle engine of live vehicle and move vehicle MASTER switch (3) to SLAVE position.
- 5 Start up dead vehicle (TM 9-2350-314-10).
- 6 After engine in disabled vehicle is running smoothly, turn OFF vehicle MASTER switch (3).
- 7 Disconnect slave cable (6) from both vehicles.
- 8 Turn both vehicle MASTER switches (3) ON again.

#### **NOTE**

After disconnecting slave cable, run both engines at 1000 rpm to stabilize generators (alternators) and charge batteries.

Section IV. SLAVE STARTING - CONTINUED

2-12 STARTING INSTRUCTIONS - CONTINUED



06ph081m

# CHAPTER 3 TROUBLESHOOTING

---

## GENERAL

This chapter illustrates and provides specific instructions for troubleshooting the M109A6 hull assemblies.

---

### CONTENTS

Page

3-1	GENERAL TROUBLESHOOTING INSTRUCTIONS .....	3-2
3-2	QUICK GUIDE TO TROUBLESHOOTING .....	3-3
3-3	TROUBLESHOOTING CHART .....	3-15
3-4	SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) .....	3-353



### 3-1 GENERAL TROUBLESHOOTING INSTRUCTIONS.

This chapter contains a "Quick Guide to Troubleshooting" index and troubleshooting chart. The Quick Guide to Troubleshooting is the master reference table for locating troubleshooting information. The Guide contains a list of various malfunctions which may occur during operation or inspection and provides a reference to the troubleshooting information on the troubleshooting chart or a solution. The troubleshooting chart provides step-by-step instructions for isolating and correcting malfunctions.

#### 3-1.1 STE/ICE Troubleshooting.

#### NOTE

This test is now designated as STE-ICE-R (Reprogrammable). The "R" indicates its circuit boards can now be reprogrammed at depot. There are no other changes to this test set. For testing purposes, STE-ICE and STE-ICE-R are the same.

When a malfunction is recognized on the engine, the Quick Guide may reference paragraph 3-4. This means there is a STE/ICE (Simplified Test Equipment for Internal Combustion Engine) method for analyzing the malfunction. The STE/ICE method will be the primary troubleshooting procedure when referenced; the listed procedure should be used only when STE/ICE is unavailable.

#### 3-1.2 Electrical Troubleshooting.

Electrical troubleshooting in this chapter provides schematic diagrams and pictorial diagrams to give insight to the harnesses involved.

When troubleshooting any electrical system or component, exercise extreme care to prevent electrical shock.

#### WARNING

Throughout troubleshooting of the electrical system or electrical components, be certain vehicle MASTER switch is OFF between every step unless otherwise directed. Remove all jewelry and metal objects when working on the electrical system to prevent injury due to electrical shock.

The multimeter is used throughout troubleshooting. Make sure when using the multimeter that it is used with a probe kit (item 35, Appx F).

#### 3-1.3 Wiring Harness Shorts Test.

When doing a shorts test, make sure all connectors and/or leads are disconnected from their components. Probe the pins (or sockets) with a multimeter. This is done by placing the red lead on pin (or socket) A (or 1) and then placing the black lead on the next pin (or socket) in alphabetical (or numerical) order. Probe every pin (or socket) on the connector or lead with the black lead of the multimeter.


When this probing has been completed, place the red lead on the second pin (or connector) and do the probing with the black lead in order again. Do this until every pin has been probed with the red lead of the multimeter. Then place the black lead of the multimeter on the connector and place the red lead on each pin (or socket) on the connector.

### 3-1.3 Wiring Harness Shorts Test - Continued


If continuity is present between any two points during probing, a short exists. Shorts must be repaired to continue any operation.

If instructed in a procedure to skip a pin (or socket) during a shorts test, that is because that pin (or socket) is not used or is shielded. Those pins (or sockets) will be covered in separate troubleshooting.

When a repair or replacement of a lead or harness has been done, do the shorts test again to make sure the problem has been corrected.



PIN TO PIN (SOCKET TO SOCKET)  
HARNESS SHORTS TEST



CONNECTOR TO PIN (SOCKET)  
HARNESS SHORTS TEST

03pc004t

## 3-2 QUICK GUIDE TO TROUBLESHOOTING.

To effectively troubleshoot the M109A6 Howitzer, follow these steps;

- a. Determine the symptom.
- b. Locate the symptom in the Quick Guide to Troubleshooting.
- c. Locate the troubleshooting reference for your symptom.
- d. Turn to the chart identified in the Quick Guide to Troubleshooting.
- e. Study the function description, pictorial view, and/or schematic located at the beginning of each troubleshooting section.
- f. Perform the corrective action as required by troubleshooting chart.
- g. Verify that the corrective action eliminated the symptom.

If any problem is not listed or will not correct through troubleshooting, notify direct support maintenance.

### NOTE

Electrical harness views are included in the troubleshooting chart as reference guides only (refer to Chapter 8 for detailed information on the electrical harnesses).



**3-2 QUICK GUIDE TO TROUBLESHOOTING - CONTINUED**

<u>ITEM</u>	<u>SYMPTOM</u>	<u>PAGE</u>	<u>PARAGRAPH</u>
AIR CLEANER BLOWER MOTORS	AIR CLEANER BLOWER MOTORS FAIL TO OPERATE.	3-16	para 3-3.a(1)
	ONE AIR CLEANER BLOWER MOTOR FAILS TO OPERATE. Other blower motor operates properly.	3-28	para 3-3.a(2)
	AIR CLEANER BLOWER MOTORS FAIL TO SHUT OFF WHEN TRANSMISSION IS IN NEUTRAL AND ENGINE IS RUNNING.	3-29	para 3-3.a(3)
AUXILIARY OUTLET	AUXILIARY OUTLET FAILS TO OPERATE.	3-32	para 3-3.b(1)
BILGE PUMP	BILGE PUMP FAILS TO OPERATE. Other electrical components operate.	3-36	para 3-3.c(1)
CAB POWER	NO POWER TO CAB SEGMENT BOARDS.	3-42	para 3-3.d(1)
DRIVER'S MCS HEATER	DRIVER'S MCS ELECTRICAL AIR HEATER (M3) FAILS TO OPERATE.	3-50	para 3-3.e(1)
ENGINE	ENGINE DOES NOT CRANK.	3-54	para 3-3.f(1)
	ENGINE CRANKS SLOWLY - BATTERY INDICATOR IN LOW YELLOW OR RED.	3-68	para 3-3.f(2)
	ENGINE CRANKS BUT DOES NOT START.	3-69	para 3-3.f(3)
	COMBAT OVERRIDE SWITCH WILL NOT OVERRIDE.	3-73	para 3-3.f(4)
	ENGINE DOES NOT ACCELERATE PROPERLY OR DOES NOT DEVELOP FULL POWER.	3-75	para 3-3.f(5)
	ENGINE DOES NOT MAINTAIN STEADY RPM.	3-78	para 3-3.f(6)
	ENGINE USES EXCESSIVE OIL.		Check oil lines, oil filters, and engine cover for excessive leaks.
	ENGINE USES EXCESSIVE FUEL.	3-80	para 3-3.f(7).258.1

**3-2 QUICK GUIDE TO TROUBLESHOOTING - CONTINUED**

<u>ITEM</u>	<u>SYMPTOM</u>	<u>PAGE</u>	<u>PARAGRAPH</u>	
ENGINE (CONTINUED)	BLACK EXHAUST SMOKE IS PRESENT.		Check air filters for restrictions and/or dirty filter elements. (TM 9-2350-314-10)	
	WHITE EXHAUST SMOKE IS PRESENT.	3-82	para 3-3.f(8)	
	EXHAUST FUMES PRESENT IN CREW COMPARTMENT.	3-83	para 3-3.f(9)	
	ENGINE HAS LOW OR NO OIL PRESSURE.	3-85	para 3-3.f(10)	
	ENGINE OVERHEATS.	3-87	para 3-3.f(11)	
	ENGINE CRANKS BUT WILL NOT START IN COLD WEATHER. Temperature below 40° F(4° C).	3-91	para 3-3.f(12)	
	GAGES	ENGINE OIL PRESSURE GAGE FAILS TO OPERATE WITH ENGINE RUNNING. All other instruments operate.	3-101	para 3-3.g(1)
		ENGINE WATER TEMPERATURE GAGE FAILS TO OPERATE PROPERLY. Engine water gage needle does not move, is not steady, or is inaccurate. All other gages operate properly.	3-104	para 3-3.g(2)
TRANSMISSION OIL PRESSURE GAGE FAILS TO OPERATE PROPERLY. All other instruments operate.		3-108	para 3-3.g(3)	
TRANSMISSION OIL TEMPERATURE GAGE FAILS TO INDICATE TRANSMISSION OIL TEMPERATURE. All other instruments operate.		3-111	para 3-3.g(4)	
FUEL GAGE FAILS TO INDICATE A LEVEL READING WITH BOTH FUEL TANKS FULL. All other instruments operate.		3-115	para 3-3.g(5)	
FUEL GAGE FAILS TO INDICATE LEVEL OF UPPER FUEL TANK. Indicates lower fuel tank level properly.		3-119	para 3-3.g(6)	
FUEL GAGE FAILS TO INDICATE FUEL LEVEL IN LOWER FUEL TANK. Indicates upper fuel tank level properly.		3-122	para 3-3.g(7)	
BATTERY/GENERATOR GAGE FAILS TO OPERATE PROPERLY - NO OR UNSTEADY READING. All other instruments operate.		3-125	para 3-3.g(8)	

**3-2 QUICK GUIDE TO TROUBLESHOOTING - CONTINUED**

<u>ITEM</u>	<u>SYMPTOM</u>	<u>PAGE</u>	<u>PARAGRAPH</u>
GAGES (CONTINUED)	TACHOMETER FAILS TO OPERATE WHEN ENGINE IS RUNNING.	3-127	para 3-3.g(9)
	SPEEDOMETER FAILS TO OPERATE WHEN VEHICLE IS MOVING FORWARD.	3-130	para 3-3.g(10)
■ GENERATOR	GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady or inaccurate reading.	3-134	para 3-3.h(1)
	GENERATOR OVERCHARGING BATTERIES. Battery/generator gage in high red.	3-150	para 3-3.h(2)
HULL INTERCOM CIRCUIT	DRIVER'S OR EXTERNAL INTERCOM FAILS TO OPERATE. Chief of Section and crew intercoms operate.	3-156	para 3-3.i(1)
IN-TANK FUEL PUMPS	ELECTRICAL IN-TANK FUEL PUMP FAILS TO OPERATE. Engine misses when low on fuel.	3-160	para 3-3.j(1)
LIGHTS	ALL ENGINE MASTER WARNING LEDS FAIL TO OPERATE WITH MASTER SWITCH ON. All gages operate.	3-166	para 3-3.k(1)
	PORTABLE INSTRUMENT PANEL MASTER WARNING LED FAILS TO OPERATE. Other warning lights operate properly.	3-169	para 3-3.k(2)
	STEERING SHAFT MASTER WARNING LIGHT FAILS TO OPERATE. Other MASTER warning lights operate properly.	3-171	para 3-3.k(3)
	CREW COMPARTMENT MASTER WARNING LIGHT FAILS TO OPERATE. Other MASTER warning lights operate properly.	3-173	para 3-3.k(4)
	CREW COMPARTMENT MASTER WARNING LIGHT FAILS TO OPERATE WITH COOLANT LIGHT ON.	3-175	para 3-3.k(5)
	MASTER WARNING LIGHTS FAIL TO OPERATE WHEN ENGINE IS OVERHEATED.	3-176	para 3-3.k(6)
	MASTER WARNING LIGHTS FAIL TO OPERATE WHEN TRANSMISSION OVERHEATS.	3-177	para 3-3.k(7)
	MASTER WARNING LIGHTS CONTINUE TO OPERATE WITH ENGINE OPERATING PROPERLY.	3-178	para 3-3.k(8)
	MASTER WARNING LIGHTS CONTINUE TO OPERATE WITH ENGINE OPERATING PROPERLY.	3-178	para 3-3.k (8)

**3-2 QUICK GUIDE TO TROUBLESHOOTING - CONTINUED**

<u>ITEM</u>	<u>SYMPTOM</u>	<u>PAGE</u>	<u>PARAGRAPH</u>
LIGHTS (CONTINUED)	ENGINE LOW LEVEL COOLANT WARNING LIGHT FAILS TO LIGHT WHEN ENGINE COOLANT LEVEL IS LOW. Operates press-to-test.	3-180	para 3-3.k(9)
	ENGINE LOW LEVEL COOLANT LIGHT FAILS TO LIGHT WHEN PRESSED TO TEST. All other lights operate.	3-183	para 3-3.k(10)
	GLOW PLUG WAIT LIGHT DOES NOT ILLUMINATE	3-188	para 3-3.k(11)
	Engine starts and all other electrical accessories operate properly.		
	MASTER SWITCH INDICATOR LIGHT FAILS TO OPERATE. Vehicle MASTER switch ON.	3-191	para 3-3.k(12)
	HIGH BEAM INDICATOR LIGHT FAILS TO OPERATE.	3-193	para 3-3.k(13)
	PARKING BRAKE INDICATOR LIGHT FAILS TO OPERATE. Parking brake set.	3-195	para 3-3.k(14)
	PERSONNEL HEATER INDICATOR LED FAILS TO OPERATE PRESS-TO-TEST OR HEATER OPERATING.	3-198	para 3-3.k(15)
	SERVICE DRIVE LIGHTS FAIL TO OPERATE.	3-199	para 3-3.k(16)
	HEADLIGHTS FAIL TO OPERATE. All other lights operate.	3-200	para 3-3.k(17)
	TAILLIGHT FAILS TO OPERATE. All other lights operate.	3-206	para 3-3.k(18)
	STOPLIGHT FAILS TO OPERATE. All other lights operate.	3-208	para 3-3.k(19)
	FRONT BLACKOUT (BO) MARKER LEDS FAIL TO OPERATE.	3-211	para 3-3.k(20)
REAR BLACKOUT (BO) MARKERS LEDS FAIL TO OPERATE. All other lights operate.	3-214	para 3-3.k(21)	
BLACKOUT (BO) DRIVE LIGHT FAILS TO OPERATE.	3-216	para 3-3.k(22)	
BLACKOUT (BO) STOPLIGHT LED FAILS TO OPERATE. All other lights operate.	3-219	para 3-3.k(23)	

**3-2 QUICK GUIDE TO TROUBLESHOOTING - CONTINUED**

<u>ITEM</u>	<u>SYMPTOM</u>	<u>PAGE</u>	<u>PARAGRAPH</u>
LIGHTS (CONTINUED)	ALL INSTRUMENT PANEL LIGHTS FAIL TO OPERATE. All other lights operate.	3-222	para 3-3.k(24)
	DRIVER'S INSTRUMENT PANEL LIGHTS FAIL TO OPERATE. All other lights operate.	3-223	para 3-3.k (25)
	PORTABLE INSTRUMENT PANEL LIGHTS FAIL TO OPERATE. All other lights operate.	3-224	para 3-3.k(26)
	ACCESSORY CONTROL BOX LEDS FAIL TO OPERATE. All other lights operate.	3-227	para 3-3.k(27)
	DOME LIGHT FAILS TO OPERATE. All other lights operate.	3-229	para 3-3.k(28)
	DRIVER'S NIGHT VIEWER FAILS TO OPERATE.	3-234	para 3-3.k(29)
NATO SLAVE RECEPTACLE	NO POWER TO SLAVED VEHICLE'S SLIP RING FROM NATO SLAVE RECEPTACLE. Slaved vehicle had power when operating.	3-236	para 3-3.l(1)
	BATTERIES FAIL TO RECHARGE WHEN VEHICLE IS SLAVED. All other electrical components operate.	3-239	para 3-3.l(2)
	NO POWER TO VEHICLE'S SLIP RING FROM EXTERNAL POWER RECEPTACLE.	3-245	para 3-3.l(3)
PERSONNEL HEATER (For vehicles with Accessory Control Box P/N 12268582)	PERSONNEL HEATER FAILS TO OPERATE. Other electrical components operate.	3-252	para 3-3.m(1)
	HEATER MOTOR RUNS BUT HEATER FAILS TO OPERATE. Sufficient fuel is in tank.	3-255	para 3-3.m(2)
	HEATER WILL NOT STOP RUNNING WITH SWITCH OFF. All other electrical components operate properly.	3-257	para 3-3.m(3)
PERSONNEL HEATER (For vehicles with Accessory Control Box P/N 12268547)	PERSONNEL HEATER FAILS TO OPERATE. Other electrical components operate.	3-258.1	para 3-3.m.1(1)
	HEATER MOTOR RUNS BUT HEATER FAILS TO OPERATE. Sufficient fuel is in tank.	3-258.4	para 3-3.m.1(2)
	HEATER WILL NOT STOP RUNNING WITH SWITCH OFF. All other electrical components operate properly.	3-258.6	para 3-3.m.1(3)

**3-2 QUICK GUIDE TO TROUBLESHOOTING - CONTINUED**

<u>ITEM</u>	<u>SYMPTOM</u>	<u>PAGE</u>	<u>PARAGRAPH</u>
PERSONNEL VENTILATION BLOWER AND LEAD FILTER FAN (For vehicles with Accessory Control Box P/N 12268582)	PERSONNEL VENTILATION BLOWER FAILS TO OPERATE. All other components operate properly.	3-260	para 3-3.n(1)
PERSONNEL VENTILATION BLOWER AND LEAD FILTER FAN (For vehicles with Accessory Control Box P/N 12268547)	LEAD FILTER FAN DOES NOT OPERATE. Personnel ventilation fan operates properly.	3-262	para 3-3.n(2)
PERSONNEL VENTILATION BLOWER AND LEAD FILTER FAN (For vehicles with Accessory Control Box P/N 12268547)	PERSONNEL VENTILATION BLOWER FAILS TO OPERATE. All other components operate properly.	3-264.1	para 3-3.n.1(1)
PERSONNEL VENTILATION BLOWER AND LEAD FILTER FAN (For vehicles with Accessory Control Box P/N 12268547)	LEAD FILTER FAN DOES NOT OPERATE. Personnel ventilation fan operates properly.	3-264.3	para 3-3.n.1(2)
STE DCA CIRCUIT	STE FAILS TO GIVE READING (WHILE PERFORMING TEST 10 OR 13). STE passed power-up and confidence tests (para 3-4.a(1)).	3-266	para 3-3.o(1)
	STE FAILS TO GIVE COMPRESSION UNBALANCE READING (WHILE PERFORMING TEST 14). STE passed power-up and confidence tests (para 3-4.a(1)).	3-267	para 3-3.o(2)
	STE FAILS TO GIVE FUEL SUPPLY PRESSURE READING (WHILE PERFORMING TEST 24). STE passed power-up and confidence tests (para 3-4.a(1)).	3-269	para 3-3.o(3)
	STE FAILS TO GIVE FUEL FILTER DIFFERENTIAL PRESSURE READING (WHILE PERFORMING TEST 26). STE passed power-up and confidence tests (para 3-4.a(1)).	3-272	para 3-3.o (4)
	STE FAILS TO GIVE AIR CLEANER PRESSURE DIFFERENTIAL READING (WHILE PERFORMING TEST 28). STE passed power-up and confidence tests (para 3-4.a(1)).	3-275	para 3-3.o(5)
	STE FAILS TO GIVE AIR BOX PRESSURE READING (WHILE PERFORMING TEST 32). STE passed power-up and confidence tests (para 3-4.a(1)).	3-277	para 3-3.o(6)

**3-2 QUICK GUIDE TO TROUBLESHOOTING - CONTINUED**

<u>ITEM</u>	<u>SYMPTOM</u>	<u>PAGE</u>	<u>PARAGRAPH</u>
STE DCA CIRCUIT (CONTINUED)	STE FAILS TO GIVE BATTERY VOLTAGE READING (WHILE PERFORMING TEST 67). STE passed power-up and confidence tests (para 3-4.a(1)).	3-281	para 3-3.o(7)
	STE FAILS TO GIVE STARTER MOTOR VOLTAGE READING (WHILE PERFORMING TEST 68). STE passed power-up and confidence tests (para 3-4.a(1)).	3-283	para 3-3.o(8)
	STE FAILS TO GIVE STARTER NEGATIVE CABLE DROP READING (WHILE PERFORMING TEST 69). STE passed power-up and confidence tests (para 3-4.a(1)).	3-285	para 3-3.o(9)
	STE FAILS TO GIVE STARTER SOLENOID VOLTAGE READING (WHILE PERFORMING TEST 70). STE passed power-up and confidence tests (para 3-4.a(1)).	3-287	para 3-3.o(10)
	STE FAILS TO GIVE STARTER CURRENT READING (WHILE PERFORMING TEST 71). STE passed power-up and confidence tests (para 3-4.a(1)).	3-290	para 3-3.o(11)
	STE FAILS TO GIVE READING (WHILE PERFORMING TESTS 72, 73, 74, or 75). STE passed power-up and confidence tests (para 3-4.a(1)).	3-291	para 3-3.o(12)
	STE FAILS TO GIVE ALTERNATOR/GENERATOR OUTPUT VOLTAGE READING (WHILE PERFORMING TEST 82). STE passed power-up and confidence tests (para 3-4.a(1)).	3-293	para 3-3.o(13)
	STE FAILS TO GIVE ALTERNATOR/GENERATOR FIELD VOLTAGE READING (WHILE PERFORMING TEST 83). STE passed power-up and confidence tests (para 3-4.a(1)).	3-296	para 3-3.o(14)
	STE FAILS TO GIVE ALTERNATOR/GENERATOR NEGATIVE CABLE DROP READING (WHILE PERFORMING TEST 84). STE passed power-up and confidence tests (para 3-4.a(1)).	3-300	para 3-3.o(15)
TRACKS AND SUSPENSION	VEHICLE BRAKES POORLY. Vehicle does not stop correctly when brake is applied.	3-304	para 3-3.p(1)
	VEHICLE PULLS TO ONE SIDE WITH STEERING WHEEL IN CENTER POSITION.	3-305	para 3-3.p(2)

**3-2 QUICK GUIDE TO TROUBLESHOOTING - CONTINUED**

<u>ITEM</u>	<u>SYMPTOM</u>	<u>PAGE</u>	<u>PARAGRAPH</u>
TRACKS AND SUSPENSION (CONTINUED)	VEHICLE THROWS TRACK.	3-307	para 3-3.p(3) Check for correct installation of torsion bars (paras 12-1 and 12-6)
	VEHICLE RIDE IS ROUGH OR SUSPENSION SYSTEM IS NOISY DURING OPERATION.		para 3-3.p(4)
TRANSMISSION AND DRIVING CONTROLS	HAND THROTTLE CONTROL DOES NOT MAINTAIN A CONSTANT RPM.	3-309	Check for loose mounting bolts on hand throttle control rod accelerator shaft (paras 5-19 and 5-21)
	ENGINE DOES NOT CHANGE RPM.		Adjust accelerator pedal and hand throttle control rod (paras 5-19 and 5-21)
	VEHICLE CREEPS FORWARD IN NEUTRAL.		Adjust transmission control linkage (para 5-21)
	TRANSMISSION OVERHEATS. Transmission oil temperature gage reads over 285° F (140° C). MASTER warning light is lit.	3-314	para 3-3.q(1)
	VEHICLE DRIVES, BUT NOT IN SELECTED RANGE.		Adjust transmission control linkage (para 5-21)
	VEHICLE DOES NOT DRIVE. Transmission does not operate in any shift position.	3-317	para 3-3.q(2)
	SHIFT CONTROL DOES NOT MOVE TO SELECTED RANGE.		Adjust transmission shift control linkage (para 5-21)
	VEHICLE DOES NOT STEER IN EITHER DIRECTION IN ANY RANGE.	3-320	para 3-3.q(3)
VEHICLE STEERS WELL IN ONE DIRECTION ONLY.	3-322	para 3-3.q(4)	



**3-2 QUICK GUIDE TO TROUBLESHOOTING - CONTINUED**

<u>ITEM</u>	<u>SYMPTOM</u>	<u>PAGE</u>	<u>PARAGRAPH</u>
TRAVEL LOCK	CONTROL BOX WILL NOT POWER UP.	3-326	para 3-3.r(1)
	TRAVEL LOCK WILL NOT RAISE/UNLOCK OR LOWER/LOCK.	3-330	para 3-3.r(2)
	LOWER/LOCK LED WILL NOT LIGHT.	3-334	para 3-3.r(3)
	RAISE/UNLOCK LED WILL NOT LIGHT.	3-339	para 3-3.r(4)
WINTERIZATION KIT	COOLANT HEATER DOES NOT OPERATE.	3-346	para 3-3.s(1)
	HEATER BLOWER OPERATES BUT MOTOR DOES NOT.	3-350	para 3-3.s(2)
	HEATER MOTOR OVERHEATS.	3-352	para 3-3.s(3)
STE/ICE PMCS	VTM CONNECTIONS AND CHECKOUT FOR DCA.	3-359	para 3-4.a(1)
	VTM CONNECTIONS AND CHECKOUT FOR TK.	3-364	para 3-4.a(1a)
	CURRENT FIRST PEAK TEST - DCA.	3-369	para 3-4.a(2)
	CURRENT FIRST PEAK TEST -TK.	3-370	para 3-4.a(2a)
	ENGINE START AND LUBRICATION CHECK- DCA.	3-371	para 3-4.a(3)
	ENGINE START AND LUBRICATION CHECK - TK.	3-373	para 3-4.a(3a)
	CHARGING VOLTAGE TEST - DCA.	3-375	para 3-4.a(4)
	CHARGING VOLTAGE TEST- TK.	3-376	para 3-4.a(4a)
	COOLANT CHECK/ENGINE OIL PRESSURE GAGE TEST - DCA.	3-377	para 3-4.a(5)
	COOLANT CHECK/ENGINE OIL PRESSURE GAGE TEST - TK.	3-378	para 3-4.a(5a)
	GOVERNOR CHECK/POWER TEST - DCA.	3-379	para 3-4.a(6)
GOVERNOR CHECK/POWER TEST - TK.	3-380	para 3-4.a(6a)	
IDLE SPEED CHECK - DCA.	3-381	para 3-4.a(7)	
IDLE SPEED CHECK - TK.	3-382	para 3-4.a(7a)	
COMPRESSION UNBALANCE TEST - DCA.	3-383	para 3-4.a(8)	

**3-2 QUICK GUIDE TO TROUBLESHOOTING - CONTINUED**


<u>ITEM</u>	<u>SYMPTOM</u>	<u>PAGE</u>	<u>PARAGRAPH</u>
STE/ICE TROUBLE- SHOOTING CONTINUED	GENERATOR NEGATIVE CABLE DROP - TEST 84.	3-384	para 3-4.b(1)
	STARTER CIRCUIT RESISTANCE - TEST 74.	3-385	para 3-4.b(2)
	BATTERY INTERNAL RESISTANCE (DCA) - TEST 73.	3-386	para 3-4.b(3)
	BATTERY RESISTANCE CHANGE - TEST 75.	3-387	para 3-4.b(4)
	STARTER NEGATIVE CABLE DROP - TEST 69.	3-388	para 3-4.b(5)
	GENERATOR FIELD VOLTAGE - TEST 83.	3-389	para 3-4.b(6)
	FUEL PRESSURE RETURN - TEST 49.	3-391	para 3-4.b(7)
	CHARGING CIRCUIT (at battery) - TEST 67.	3-392	para 3-4.b(8)
	ENGINE RPM - TEST 10.	3-394	para 3-4.b(9)
	COMPRESSION UNBALANCE - TEST 14.	3-395	para 3-4.b(10)
	ENGINE POWER PERCENTAGE - TEST 13.	3-396	para 3-4.b(11)
	GENERATOR OUTPUT VOLTAGE - TEST 82.	3-397	para 3-4.b(12)
	FUEL SUPPLY PRESSURE (DCA and TK) - TEST 24.	3-399	para 3-4.b(13)
	CRANKING CURRENT - TEST 71.	3-401	para 3-4.b(14)
	CURRENT FIRST PEAK - TEST 72.	3-402	para 3-4.b(15)
	STARTER SOLENOID VOLTAGE - TEST 70.	3-403	para 3-4.b(16)
	VEHICLE OIL PRESSURE - TEST 50.	3-404	para 3-4.b(17)
	AIR FILTER PRESSURE DIFFERENTIAL - TEST 28.	3-405	para 3-4.b(18)
	STARTER POSITIVE TERMINAL VOLTAGE - TEST 68.	3-406	para 3-4.b(19)
	INDIVIDUAL BATTERY VOLTAGE - TEST 89.	3-407	para 3-4.b(20)
	AIR BOX PRESSURE - TEST 32.	3-408	para 3-4.b(21)
	FUEL PRESSURE DROP - TEST 26.	3-409	para 3-4.b(22)

# 3-3 TROUBLESHOOTING CHART

## a. AIR CLEANER BLOWER MOTORS

The air cleaner blower motor system consists of the blower motor, the air cleaner blower motor relay, air cleaner and generator system relay switch, neutral safety switch, circuit breaker numbers 5 (CB5) and 7 (CB7) and associated wiring. The relationship of these components is shown in the diagram below.

When the vehicle MASTER switch is turned ON, 24 V dc is supplied through the MASTER relay to circuit breaker CB5 and CB7. 24 V dc from circuit breaker CB5 is routed through the generator system and fuel pumps relay, the air cleaner and generator system relay switch (oil pressure activated) which provides a ground for that circuit, and through the neutral safety switch to the air cleaner blower motor relay (relay activation voltage). 24 V dc from circuit breaker CB7 is supplied to the air cleaner blower motors through the air cleaner blower motor relay.



3-017


# 3-3 TROUBLESHOOTING CHART - CONTINUED

a. AIR CLEANER BLOWER MOTORS (1) AIR CLEANER BLOWER MOTORS FAIL TO OPERATE. - CONTINUED


**INITIAL SETUP**

<p><u>Tools</u></p> <p>General mechanic's tool kit (SC 5180-90-N26)          Multimeter (item 38, Appx F)          (Long test leads may be needed for some tests.          16 AWG wire may be used as an extension.)</p>	<p><u>Equipment Conditions</u></p> <p>Air intake grille opened (TM 9-2350-314-10)          Battery access doors open (TM 9-2350-314-10)          Transmission access doors opened (TM 9-2350-314-10)</p> <p><u>Personnel Required</u></p> <p>Two</p>
--	--

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove engine compartment access cover (para 16-7).
  3. Disconnect lead 415B from air cleaner/generator system relay switch.
  4. Place a jumper lead from lead 415B connector socket to ground.
  5. Place transmission lever in gear (not neutral) (TM 9-2350-314-10).
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
- Do air cleaner blower motors operate?



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect lead 415B to air cleaner/generator system relay switch.
  3. Disconnect harness W105 connector P1 from harness W104 connector J1.
  4. Place a jumper wire from harness W105 connector P1 socket S to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
- Do air cleaner blower motors operate?



CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

a. AIR CLEANER BLOWER MOTORS - (1) AIR CLEANER BLOWER MOTORS FAIL TO OPERATE. - CONTINUED

CONTINUED FROM STEP B




Repair or replace harness W104 lead 415B from engine disconnect bracket to air cleaner/generator system relay switch (para 8-63).

**C**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W114 connector P1 from harness W105 connector J1 at driver's bulkhead.
3. Check W105 for continuity by placing one multimeter lead in W105 J1 socket S and other lead to ground.

Is continuity present?




Repair or replace harness W105 (para 8-64).




**D**

1. Reconnect harness W114 connector P1 to harness W105 connector J1.
2. Remove driver's instrument panel front cover (para 8-12).
3. Disconnect harness W114 lead 415B from harness W123 lead 415B behind driver's instrument panel.
4. Check W114 lead 415B for continuity by placing one multimeter lead in harness W114 lead 415B and other lead to ground.

Is continuity present?



Repair or replace harness W114 lead 415B (para 8-73).



3\_020B

CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

a. AIR CLEANER BLOWER MOTORS - (1) AIR CLEANER BLOWER MOTORS FAIL TO OPERATE. - CONTINUED

CONTINUED FROM STEP D

- E**
1. Remove jumper from harness W105 and reconnect W105 connector P1 to harness W104 J1 at engine disconnect bracket.
  2. Place a jumper in harness W123 lead 415B and to ground.
  3. Disconnect harness W123 connector P1 from generator system and fuel pumps relay.
  4. Place one multimeter lead in harness W123 connector P1 socket D and other lead to ground.
  5. Check for continuity.


Is continuity present?



- F**
1. Place red multimeter lead in harness W123 P1 socket A and B (one at a time) and place black lead to ground.
  2. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  3. Check for voltage.

Is voltage present?


CONTINUED ON NEXT PAGE



# 3-3 TROUBLESHOOTING CHART - CONTINUED


a. AIR CLEANER BLOWER MOTORS - (1) AIR CLEANER BLOWER MOTORS FAIL TO OPERATE. - CONTINUED

CONTINUED FROM STEP F



- G**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W123 connector P1 to generator system and fuel pumps relay.
  3. Disconnect harness W123 lead 415G from circuit breaker 5 (CB5).
  4. Place red multimeter lead on circuit breaker pin and place black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  6. Check for voltage?


Is voltage present?



- H**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W123 lead 415G to circuit breaker 5 (CB5).
  3. Disconnect harness W124 lead 10 at circuit breaker 5 (CB5).
  4. Place red multimeter lead in harness W124 lead 10 and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  6. Check for voltage.





Is voltage present?

CONTINUED ON NEXT PAGE




# 3-3 TROUBLESHOOTING CHART - CONTINUED

a. AIR CLEANER BLOWER MOTORS - (1) AIR CLEANER BLOWER MOTORS FAIL TO OPERATE. - CONTINUED



CONTINUED ON NEXT PAGE







# 3-3 TROUBLESHOOTING CHART - CONTINUED

a. AIR CLEANER BLOWER MOTORS - (1) AIR CLEANER BLOWER MOTORS FAIL TO OPERATE. - CONTINUED

CONTINUED FROM STEP J




CONTINUED FROM STEP I


**K**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Reconnect harness W123 connector P1 to generator system and fuel pumps relay.
3. Reconnect harness W123 lead 415 to Y-connector of harnesses W114 and W115.
4. Disconnect harness W114 lead 415C from lead 415A of neutral safety switch.
5. Place multimeter red lead in harness W114 lead 415C and other lead to ground.
6. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
7. Check for voltage.

Is voltage present?



3-026C



CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

a. AIR CLEANER BLOWER MOTORS - (1) AIR CLEANER BLOWER MOTORS FAIL TO OPERATE. - CONTINUED

CONTINUED FROM STEP K

- L**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W114 lead 415C to neutral safety switch lead 415A.
  3. Disconnect neutral safety switch lead 415B from harness W122 lead 415F.
  4. Place red multimeter lead in neutral safety switch lead 415B connector and other lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  6. Check for voltage.



Is voltage present?



- M**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W122 lead 415F to neutral safety switch lead 415B.
  3. Disconnect harness W122 connector P1 from air cleaner blower motor relay.
  4. Place multimeter red lead in harness W122 connector P1 socket B and other lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  6. Check for voltage.

Is voltage present?


CONTINUED ON NEXT PAGE



# 3-3 TROUBLESHOOTING CHART - CONTINUED

a. AIR CLEANER BLOWER MOTORS - (1) AIR CLEANER BLOWER MOTORS FAIL TO OPERATE. - CONTINUED


CONTINUED FROM STEP M



**N**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Place multimeter red lead in harness W122 connector P1 socket A and black lead to ground.
3. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
4. Check for voltage.

Is voltage present?




**O**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W122 lead 415A from circuit breaker No. 7 (CB7).
3. Place multimeter red lead in circuit breaker No. 7 (CB7) connector and black lead to ground.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
5. Check for voltage.

Is voltage present?

CONTINUED ON NEXT PAGE





06ph036t

### 3-3 TROUBLESHOOTING CHART - CONTINUED

a. AIR CLEANER BLOWER MOTORS - (1) AIR CLEANER BLOWER MOTORS FAIL TO OPERATE. - CONTINUED

CONTINUED FROM STEP O



06ph037t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


a. AIR CLEANER BLOWER MOTORS - (1) AIR CLEANER BLOWER MOTORS FAIL TO OPERATE. - CONTINUED

CONTINUED FROM STEP N

**Q**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Reconnect harness W122 connector P1 to air cleaner blower motor relay.
3. Disconnect harness W122 lead 415 from harness W119 lead 415.
4. Place multimeter red lead on harness W122 lead 415 connector pin and black lead to ground.
5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
6. Check for voltage.


Is voltage present?





**R**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W122 connector P1 from air cleaner blower motor relay.
3. Check for continuity by placing one multimeter lead in harness W122 lead 415 and the other lead in harness W122 connector P1 socket C.

Is continuity present?



CONTINUED ON NEXT PAGE







06ph038t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

a. AIR CLEANER BLOWER MOTORS - (1) AIR CLEANER BLOWER MOTORS FAIL TO OPERATE. - CONTINUED

CONTINUED FROM STEP R



06ph039t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

a. AIR CLEANER BLOWER MOTORS - (1) AIR CLEANER BLOWER MOTORS FAIL TO OPERATE. - CONTINUED

CONTINUED FROM STEP Q


- U**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W122 lead 415 to harness W119 lead 415.
  3. Disconnect both harness W119 leads 415 from air cleaner blower motors.
  4. Place red multimeter lead in each harness W119 lead 415 connectors (one at a time) and place black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  6. Check for voltage.

Is voltage present?




- V**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect both harness W119 leads 415 to air cleaner blower motors.
  3. Remove jumper in harness W123 lead 415B and connector lead 415B to harness W114 lead 415.
  4. Install driver's instrument panel front cover (para 8-14).
  5. Disconnect harness W125 lead 7 from both air cleaner blower motors.
  6. Place one multimeter lead in W125 lead 7 (one at a time) and other lead to ground.
  7. Check for continuity.

Is continuity present?



END OF TASK



3-023B


## 3-3 TROUBLESHOOTING CHART - CONTINUED

a. AIR CLEANER BLOWER MOTORS - (2) ONE AIR CLEANER BLOWER MOTOR FAILS TO OPERATE. Other blower motor operates properly.



**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)  
 (Long test leads may be needed for some tests.  
 16 AWG wire may be used as an extension)

- A**
1. Shut engine off and turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W119 lead 415 from faulty air cleaner blower motor.
  3. Disconnect harness W119 lead 415 connector from W122 lead 415.
  4. Check for continuity from faulty motor connector of W119 and lead 415 going to W122.



- B**
1. Reconnect harness W119 lead 415 to faulty air cleaner blower motor.
  2. Disconnect harness W125 lead 7 from faulty air cleaner blower motor.
  3. Check lead 7 for continuity from harness W125 connector pin to ground.



06ph041t

**END OF TASK**




# 3-3 TROUBLESHOOTING CHART - CONTINUED

a. AIR CLEANER BLOWER MOTORS - (3) AIR CLEANER BLOWER MOTORS FAIL TO SHUT OFF WHEN TRANSMISSION IS IN NEUTRAL AND ENGINE IS RUNNING.


**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

1. Install engine oil pressure switch jumper to ground.
2. Disconnect harness W122 lead 415F from neutral safety switch lead 415B.
3. Place multimeter red lead on neutral safety switch lead 415B connector pin and black lead to ground.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
5. Check for voltage.



**END OF TASK**




06ph046t

### 3-3 TROUBLESHOOTING CHART - CONTINUED

#### b. AUXILIARY OUTLET

The auxiliary outlet is located on the driver's control panel. The auxiliary outlet circuit consists of the outlet, circuit breaker number 6 (CB6) and related electrical wiring. The diagram below shows the relationship of these components.

The primary use of the auxiliary outlet is for the vehicle's night viewer. When the night viewer is installed, the power cord is plugged into the auxiliary outlet. By turning on the vehicle MASTER switch, 24 V dc from the batteries is applied through the master relay to circuit breaker 6 which supplies the voltage to the auxiliary outlet.



06ph047t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


b. AUXILIARY OUTLET - CONTINUED (1) AUXILIARY OUTLET FAILS TO OPERATE.

**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)



- A**
1. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  2. Place multimeter red lead on auxiliary outlet center contact and black lead to ground.
  3. Check for voltage.

Is voltage present?



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove driver's instrument panel from mounting for access to auxiliary outlet socket connector (para 8-12).
  3. Disconnect lead 37 from auxiliary outlet connector.
  4. Place multimeter red lead in lead 37 connector socket and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



06ph048t


CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


b. AUXILIARY OUTLET - CONTINUED (1) AUXILIARY OUTLET FAILS TO OPERATE. - CONTINUED

CONTINUED FROM STEP B


- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect lead 37 to auxiliary outlet connector.
  3. Disconnect harness W124 lead 10 from circuit breaker no. 6 (CB6).
  4. Place multimeter red lead in lead 10 connector socket and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



Is voltage present?




- D**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W124 lead 10 to circuit breaker no. 6 (CB6) connector.
  3. Disconnect harness W115 lead 37/38 from circuit breaker no. 6 (CB6).
  4. Place multimeter red lead on circuit breaker connector pin and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



06ph049t

Is voltage present?



END OF TASK


# 3-3 TROUBLESHOOTING CHART - CONTINUED

## c. BILGE PUMP

The bilge pump is used to evacuate water from the engine compartment, usually after fording. The bilge pump is not to be run for more than one minute in a dry compartment or fifteen minutes in a wet compartment unless the engine is running.

The bilge pump system consists of the bilge pump, bilge pump relay, bilge pump circuit breaker, circuit breaker number 2 (CB2), and related electrical wiring.

To operate the bilge pump, the vehicle MASTER switch must be ON. By turning on the vehicle MASTER switch, power from the batteries travels through the MASTER relay to circuit breaker 2 (CB2). From circuit breaker 2 (CB2), the power travels to the bilge pump switch. Once the bilge pump switch is turned on, the power travels through the bilge pump circuit breaker to the bilge pump relay. The bilge pump relay sends the power to the bilge pump and the bilge pump is energized.



06ph083t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

c. BILGE PUMP - CONTINUED (1) BILGE PUMP FAILS TO OPERATE. Other electrical components operate.

<p><b>INITIAL SETUP</b></p> <p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Powerpack removed (para 4-1)</p> <p><u>Personnel Required</u>                  Two</p>
--	--

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W113 lead 452 from bilge pump connector.
  3. Place multimeter red lead on harness W113 lead 452 connector socket and black lead on ground.
  4. Turn vehicle MASTER and BILGE PUMP switches ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?




**NOTE**


It may be necessary to remove the bilge pump relay from its mounting bracket to make it easier to disconnect and reconnect harness.

- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W113 connector P3 from bilge pump relay.
  3. Place multimeter red lead in harness W113 connector P3 socket C and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE



06ph084t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


c. BILGE PUMP - CONTINUED (1) BILGE PUMP FAILS TO OPERATE. Other electrical components operate. - CONTINUED

CONTINUED FROM STEP B

**C**

1. Turn BILGE PUMP switch ON (TM 9-2350-314-10).
2. Place multimeter red lead in harness W113 connector P3 socket A and black lead on ground and check for voltage.


Is voltage present?



**D**

1. Turn vehicle MASTER and BILGE PUMP switches OFF (TM 9-2350-314-10).
2. Check continuity of harness W113, by placing one multimeter lead in harness W113 connector lead 452 at bilge pump and other lead in harness W113 connector P3 socket B.

Is continuity present?




CONTINUED FROM STEP B

**E**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W105 lead 452A from bilge pump circuit breaker.
3. Place multimeter red lead on harness W105 lead 452A and black lead on ground.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?

CONTINUED ON NEXT PAGE




06ph085t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

c. BILGE PUMP - CONTINUED (1) BILGE PUMP FAILS TO OPERATE. Other electrical components operate. - CONTINUED

CONTINUED FROM STEP E




- F**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W105 lead 452A to bilge pump circuit breaker connector.
  3. Disconnect harness W113 lead 452B from bilge pump circuit breaker connector.
  4. Place multimeter red lead on circuit breaker connector terminal and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



CONTINUED FROM STEP C

- G**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W124 lead 10 from circuit breaker no. 2.
  3. Place multimeter red lead in harness W124 lead 10 connector socket and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?

CONTINUED ON NEXT PAGE




06ph087t



# 3-3 TROUBLESHOOTING CHART - CONTINUED

c. BILGE PUMP - CONTINUED (1) BILGE PUMP FAILS TO OPERATE. Other electrical components operate. - CONTINUED


CONTINUED FROM STEP G



**H**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Reconnect harness W124 lead 10 to circuit breaker no. 2.
3. Disconnect harness W120 lead 450 from circuit breaker no. 2.
4. Place multimeter red lead on circuit breaker connector pin and black lead on ground.
5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.


Is voltage present?




**I**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Reconnect harness W120 lead 450 to circuit breaker no. 2.
3. Disconnect harness W120 lead 450 from bilge pump switch.
4. Place multimeter red lead in harness W120 lead 450 connector socket and black lead to ground.
5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE



06ph090t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


c. BILGE PUMP - CONTINUED (1) BILGE PUMP FAILS TO OPERATE. Other electrical components operate. - CONTINUED

CONTINUED FROM STEP I

**J**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W115 lead 450 from bilge pump switch.
3. Turn bilge pump switch ON (TM 9-2350-314-10).
4. Check for continuity across bilge pump switch.



Is continuity present?



**K**

1. Reconnect harness W120 lead 450 to bilge pump switch connector.
2. Disconnect harness W115 connector P1 from harness W113 bulkhead connector J1.
3. Check harness W113 for continuity from connector P3 socket A to connector J1 pin L.

Is continuity present?



06ph088t


**END OF TASK**

# 3-3 TROUBLESHOOTING CHART - CONTINUED

## d. CAB POWER

The cab power circuit consists of the vehicle batteries, the master relay, vehicle MASTER switch, external power and NATO slave receptacles, circuit breaker number 2 (CB2), hull slip ring assembly, and related electrical wiring. The diagram below shows the relationship of these components.

When the vehicle MASTER switch is ON, 24 V dc is supplied from the batteries through the master relay to the hull slip ring providing power to the cab. The cab can also receive power from another vehicle by connecting a slave cable to either the vehicle's NATO slave or external power receptacles and turning on the other vehicle's MASTER switch.




06ph074t

### 3-3 TROUBLESHOOTING CHART - CONTINUED


d. CAB POWER - CONTINUED (1) NO POWER TO CAB SEGMENT BOARDS.

INITIAL SETUP  
Tools  
 General mechanic's tool kit  
 (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)

- A**
1. Check the NATO receptacle for voltage by placing multimeter red lead in NATO receptacle socket and black lead on ground.
  2. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
- Is voltage present?



CONTINUED ON NEXT PAGE




06ph075t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


d. CAB POWER - CONTINUED (1) NO POWER TO CAB SEGMENT BOARDS. - CONTINUED

CONTINUED FROM STEP A


**B** Check at left segment board for voltage by placing multimeter red lead on harness W117 leads 10 terminals (E5-E6) and black lead on harness W116 leads 7 terminals (E5-E6).  
Is voltage present?



**C** Check at right segment board for voltage by placing multimeter red lead on harness W117 leads 10 terminal (E7-E8) and black lead on harness W116 leads 7 terminal (E7-E8).  
Is voltage present?



CONTINUED ON NEXT PAGE




06ph076t

# 3-3 TROUBLESHOOTING CHART - CONTINUED





d. CAB POWER - CONTINUED (1) NO POWER TO CAB SEGMENT BOARDS. - CONTINUED

CONTINUED FROM STEP C

- D**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect battery grounds from shunt located in battery compartment (para 8-33).
  3. Disconnect leads E1-7C, E2-7C, E3-7C, and E4-7C from left and right segment boards (this is a dual wire lead).
  4. Check leads for continuity by placing one multimeter lead on lead terminal E1-7C and other lead on lead terminal E2-7C.
  5. Check leads for continuity by placing one multimeter lead on lead terminal E3-7C and other lead on lead terminal E4-7C.
- Is continuity present at both points?



- E** Using a multimeter, perform a shorts test (para 3-1.3) on leads by placing one multimeter lead on point one and other lead on point two.
- | POINT ONE | POINT TWO    | DO NOT CHECK |
|-----------|--------------|--------------|
| E1-7C     | E3-7C, E4-7C | E2-7C        |
| E2-7C     | E3-7C, E4-7C | E1-7C        |
| E3-7C     | E1-7C, E2-7C | E4-7C        |
| E4-7C     | E1-7C, E2-7C | E3-7C        |
- Are any shorts present?



06ph077t

CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

d. CAB POWER - CONTINUED (1) NO POWER TO CAB SEGMENT BOARDS. - CONTINUED

CONTINUED FROM STEP E

- F**
1. Remove leads E1-47, E2-47, E3-47, and E4-47 from left and right segment board (this is a dual wire lead).
  2. Check leads for continuity by placing one multimeter lead on lead wire E1-47 and other lead on lead wire E2-47.
  3. Check leads for continuity by placing one multimeter lead on lead wire E3-47 and other lead on lead wire E4-47.



Is continuity present at both points?



- G** Perform a shorts test (para 3-1.3) on leads by placing one multimeter lead on point one and other lead on point two.

POINT ONE	POINT TWO	DO NOT CHECK
E1-47	E3-47, E4-47	E2-47
E2-47	E3-47, E4-47	E1-47
E3-47	E1-47, E2-47	E4-47
E4-47	E1-47, E2-47	E3-47

Are any shorts present?



CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

d. CAB POWER - CONTINUED (1) NO POWER TO CAB SEGMENT BOARDS. - CONTINUED


CONTINUED FROM STEP B OR C

**H** Check harness W117 wire 10 for voltage by placing multimeter red lead on harness W117 E7/E8 or E5/E6 and black lead to ground.

Is voltage present?



CONTINUED ON NEXT PAGE



06ph079t




# 3-3 TROUBLESHOOTING CHART - CONTINUED

d. CAB POWER - CONTINUED (1) NO POWER TO CAB SEGMENT BOARDS. - CONTINUED



CONTINUED FROM STEP H

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect battery ground (para 8-33).
3. Disconnect harnesses W116 lead 7 connector terminals E3, E4, E5, E6, E7, E8 (para 8-75) and W125 lead 7 connector terminal E12 (para 8-83).
4. Check each connector terminal (one at a time), except W125 lead 7 for continuity by placing one multimeter lead on connector terminal and placing other multimeter lead to ground.

Is continuity present?



**END OF TASK**




### 3-3 TROUBLESHOOTING CHART - CONTINUED

#### e. DRIVER'S MCS ELECTRICAL AIR HEATER (M3)

The driver's MCS heater system consists of the heater, circuit breaker number 8 (CB8), and related electrical wiring. The relationship of these components is shown in the diagram below.

To operate the MCS heater the vehicle MASTER switch must be ON. 24 V dc is supplied from the batteries, through the master relay to circuit breaker 8 (CB8). Circuit breaker 8 (CB8) applies the voltage to the MCS heater. The heater is controlled with a rheostat-type switch.



### 3-3 TROUBLESHOOTING CHART - CONTINUED


e. DRIVER'S MCS ELECTRICAL AIR HEATER (M3) - CONTINUED (1) DRIVER'S MCS ELECTRICAL AIR HEATER (M3) FAILS TO OPERATE.

**INITIAL SETUP**



Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)

- A**
1. Disconnect harness lead 10N from driver's MCS heater connector.
  2. Place multimeter red lead in lead 10N connector socket and black lead to ground.
  3. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE



06ph050t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

e. DRIVER'S MCS ELECTRICAL AIR HEATER (M3) - CONTINUED (1) DRIVER'S MCS ELECTRICAL AIR HEATER (M3) FAILS TO OPERATE. - CONTINUED

CONTINUED FROM STEP A


- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W124 lead 10 from circuit breaker no. 8 connector.
  3. Place multimeter red lead in lead 10 connector socket and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?




- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W124 lead 10 to circuit breaker no. 8 connector.
  3. Disconnect lead 10N from circuit breaker no. 8 connector.
  4. Place multimeter red lead on circuit breaker connector pin and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE




06ph051t

### 3-3 TROUBLESHOOTING CHART - CONTINUED

e. DRIVER'S MCS ELECTRICAL AIR HEATER (M3) - CONTINUED      (1) DRIVER'S MCS ELECTRICAL AIR HEATER (M3) FAILS TO OPERATE. - CONTINUED

CONTINUED FROM STEP A or C


- |                        |   |
|------------------------|---|
| <b>D</b>               | <ol style="list-style-type: none"> <li>1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).</li> <li>2. Reconnect harness lead 10N to driver's MCS heater connector.</li> <li>3. Disconnect harness 125 lead 7 from MCS heater.</li> <li>4. Check for continuity from driver's MCS heater ground point to ground.</li> </ol> |
| Is continuity present? |   |



Repair or replace harness W125 lead 7 to driver's MCS heater (para 8-83 and para 8-59).

Repair or replace driver's MCS heater (para 22-4).

**END OF TASK**




06ph052t

### 3-3 TROUBLESHOOTING CHART - CONTINUED

#### f. ENGINE

The engine is an internal-combustion, liquid-cooled, diesel engine with an exhaust-driven turbocharger. The engine is the main component of the vehicle drive train and has many components and associated wiring. The relationship of the engine and these components are shown below in the pictorial diagram.

The engine is started by turning on the vehicle MASTER switch which supplies voltage from the batteries through the master relay. When the START button is pushed, voltage is supplied to the starter which cranks and starts the engine. Once started, the engine can develop up to 440 horsepower at 2300 rpm and deliver this power to the transfer assembly. The transfer assembly will then send this power to the transmission.



06ph132t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK.

<p><b>INITIAL SETUP</b></p> <p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long test leads may be needed for some tests.                  16 AWC wire may be used as an extension.)</p>	<p><u>Personnel Required</u>                  Two</p> <p><u>Equipment Conditions</u>                  Left transmission access door open (TM 9-2350-314-10)</p>
---	---

**A**

1. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
2. Check vehicle MASTER switch warning lamp (TM 9-2350-314-10).



Is lamp on?



**B**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Loosen two screws and rotate master relay cover to right (para 8-22).
3. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
4. Check for voltage by placing multimeter red lead on master relay terminal X1 and black lead on ground.

Is voltage present?



06ph133t

CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK. - CONTINUED

CONTINUED FROM STEP B

**C**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W113 lead 7 from X2 of master relay (para 8-72).
3. Check for continuity from X1 to X2 of master relay.


Is continuity present?



**D**

Check for continuity from harness W113 lead 7 to ground.





Is continuity present?



**E**

1. Reconnect harness W113 lead 7 to X2 (para 8-72).
2. Rotate cover to original position and tighten two screws (para 8-22).
3. Check for voltage by placing multimeter red lead on terminal A2 of master relay and black lead to ground.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Is voltage present?



06ph134t

CONTINUED ON NEXT PAGE



# 3-3 TROUBLESHOOTING CHART - CONTINUED


f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK. - CONTINUED

CONTINUED FROM STEP E

**F**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W105 connector P3 from starter protection device.
3. Check for voltage by placing multimeter red lead in socket B of connector P3 and black lead to ground.


Is voltage present?



**G**

1. Check for voltage by placing multimeter red lead in socket A of harness W105 connector P3 and black lead to ground.
2. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
3. Place STARTER switch in the START position (TM 9-2350-314-10).


Is voltage present?







**H**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Place a jumper lead between sockets B and E of connector P3 of harness W105.
3. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Does engine crank?



CONTINUED ON NEXT PAGE



06ph135t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK. - CONTINUED

CONTINUED FROM STEP H

**I**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Reconnect harness W105 connector P3 and disconnect harness W105 connector P1 at engine bracket.
3. Check for voltage by placing multimeter red lead in socket W or X of harness W105 connector P1 and black lead to ground.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).


Is voltage present?




**J**

1. Check for voltage by placing multimeter red lead in socket T of harness W105 connector P1 and black lead to ground.
2. Place STARTER switch in the START position (TM 9-2350-314-10).

Is voltage present?



CONTINUED ON NEXT PAGE



06ph136t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK. - CONTINUED

CONTINUED FROM STEP J

**K**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Reconnect harness W105.
3. Check for voltage at DCA connector (harness W100 connector J1) by placing multimeter red lead on socket S and black lead on socket M of harness W100 connector J1.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
5. Place STARTER switch in the START position (TM 9-2350-314-10).
6. Check for voltage.



Is voltage present?



**L**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Check for voltage by placing multimeter red lead on socket T and black lead on socket M of harness W100 connector J1.
3. Place STARTER switch in the START position (TM 9-2350-314-10).

Is voltage present?



06ph137t

CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK. - CONTINUED

CONTINUED FROM STEP A


**M** 1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).  
 2. Check for voltage at master relay by placing multimeter red lead on master relay terminal A1 and black lead to ground.

Is voltage present?




**N** 1. Disconnect harness W114 connector P1 from harness W105 connector J1 at the driver's compartment bulkhead.  
 2. Check for voltage by placing multimeter red lead on socket L of harness W105 connector J1 and black lead to ground.

Is voltage present?



CONTINUED ON NEXT PAGE



06ph138t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK. - CONTINUED

CONTINUED FROM STEP N

**O**

1. Reconnect harness W114 connector P1 to harness W105 connector J1.
2. Disconnect harness W112 connector P1 from harness W114 connector J1 at disconnect bracket.
3. Check for voltage by placing multimeter red lead on socket L of harness W114 connector J1 and black lead to ground.


Is voltage present?



**P**

1. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
2. Check for continuity between pins L and W of harness W112 connector P1.
3. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).



Is continuity good?



**Q**

1. Remove portable instrument panel cover (TM 9-2350-314-10).
2. Disconnect lead 459B from vehicle MASTER switch.
3. Check for continuity from pin L harness W112 connector P1 to lead 459B connector.

Is continuity good?





06ph139T

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK. - CONTINUED




CONTINUED FROM STEP Q

- R**
1. Disconnect lead 459 of harness W112 at vehicle MASTER switch.
  2. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  3. Check for continuity between 459 and 459B connectors on the vehicle MASTER switch.
- Is continuity good?



CONTINUED FROM STEP B or P

- S**
1. Remove portable instrument panel cover (para 8-14).
  2. Disconnect harness W112 connector P1 and lead 459 at vehicle MASTER switch.
  3. Check continuity from harness W112 459 connector to pin W of harness W112 connector P1.
- Is continuity good?



CONTINUED ON NEXT PAGE

06ph140t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK. - CONTINUED

CONTINUED FROM STEP S




- T**
1. Reconnect harness W112 connector P1 and lead 459 at vehicle MASTER switch.
  2. Install portable instrument panel cover (para 8-14).
  3. Remove driver's instrument panel (para 8-12).
  4. Disconnect harness W114 lead 459 from harness W115 lead 459.
  5. Check for voltage by placing multimeter red lead in harness W114 lead 459 connector and black lead to ground.
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Is voltage present?



- U**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W114 lead 459 to harness W115 lead 459.
  3. Install driver's instrument panel (para 8-12).
  4. Disconnect harness W115 connector P1 at driver's compartment bulkhead.
  5. Check for voltage by placing multimeter red lead in socket Q of harness W115 connector P1 and black lead to ground.
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Is voltage present?



CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK. - CONTINUED

CONTINUED FROM STEP G

**V**

1. Disconnect harness W114 lead 14 from starter switch.
2. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
3. Check for voltage by placing multimeter red lead on starter switch pin where lead 14 was disconnected from and black lead to ground.
4. Place STARTER switch in the START position.


Is voltage present?



**W**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Reconnect harness W114 lead 14 to starter switch.
2. Disconnect harness W120 lead 10S from the starter switch.
3. Check for voltage by placing multimeter red lead in harness W120 lead 10S connector and black lead to ground.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).





Is voltage present?



**X**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Reconnect harness W120 lead 10S to starter switch and disconnect harness W120 10S at circuit breaker no. 4.
3. Install driver's instrument panel (para 8-12).
4. Check for voltage by placing multimeter red lead in circuit breaker connector and black lead to ground.
5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Is voltage present?



CONTINUED ON NEXT PAGE



06ph142t



# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK. - CONTINUED

CONTINUED FROM STEP X



06ph143t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK. - CONTINUED


CONTINUED FROM STEP V

- AA**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W114 lead 14 to starter switch.
  3. Disconnect both harness W114 leads 14 from the neutral safety switch.
  4. Check for voltage by placing multimeter red lead in harness W114 lead 14 sockets, one at a time, and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  6. Hold the STARTER switch in the START position (TM 9-2350-314-10).

Is voltage present in one of two leads 14?



CONTINUED ON NEXT PAGE




# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK. - CONTINUED

CONTINUED FROM STEP AA


- AB**
1. Ensure engine transmission shift lever is in the neutral position (TM 9-2350-314-10).
  2. Check continuity between both connector leads of the neutral safety switch.

Is continuity good?




- AC**
1. Adjust neutral safety switch (para 9-1).
  2. Recheck for continuity as in step AB.

Is continuity good?




- AD**
1. Disconnect harness W114 connector P1 at driver's compartment bulkhead.
  2. Check for continuity from pin V to lead 14 socket (opposite lead 14 socket that had voltage in step AA).

Is continuity good?



CONTINUED ON NEXT PAGE




06ph145t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


f. ENGINE - CONTINUED (1) ENGINE DOES NOT CRANK. - CONTINUED

CONTINUED FROM STEP AD

- AE**
1. Reconnect harness W114 connector P1 at driver's bulkhead.
  2. Disconnect harness W105 connector P3 from starter protection device.
  3. Check for continuity between harness W105 connector J1 pin V and harness W105 connector P3 socket A.
- Is continuity present?



END OF TASK



06ph146t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


f. ENGINE - CONTINUED (2) ENGINE CRANKS SLOWLY - BATTERY INDICATOR IN LOW YELLOW OR RED.

<p><u>INITIAL SETUP</u></p> <p><u>Tools</u>                  General mechanic's tool kit                  (SC 5180-90-N26)                  Multimeter (item 38, Appx F)</p> <p><u>Equipment Conditions</u>                  Transmission access doors open                  (TM 9-2350-314-10)</p>	<p><u>Personnel Required</u>                  Two</p>
---	---

**A**

1. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
2. Place multimeter red lead on master relay terminal A1 (power-in terminal) and black lead to ground.
3. Pull and hold fuel shutoff handle (TM 9-2350-314-10) and check for voltage while cranking engine.



Are 18 to 24 volts present?



**B**

1. Clean, tighten, and repair or replace defective battery cables (para 8-56).
2. Charge batteries.
3. Check the specific gravity of each battery (Chap. 2 PMCS).

Do all batteries show full charge?




06ph147t

**END OF TASK**

### 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (3) ENGINE CRANKS BUT DOES NOT START.

<u>INITIAL SETUP</u>	
<u>Tools</u> General mechanic's tool kit (SC 5180-90-N26) Multimeter (item 38, Appx F)	<u>Personnel Required</u> Two
<u>Equipment Conditions</u> Air intake grille opened (TM 9-2350-314-10)	



CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (3) ENGINE CRANKS BUT DOES NOT START. - CONTINUED

CONTINUED FROM STEP C


**D** Check primary fuel filter for contamination (TM 9-2350-314-10).

Is primary fuel filter free of contamination?




**E** 1. Open drain on bottom of secondary fuel filter (TM 9-2350-314-10).  
2. Check for fuel.

Is fuel present in secondary fuel filter?




**F** Check secondary fuel filter for contamination (TM 9-2350-314-10).

Is secondary fuel filter free of contamination?



**G** Check for pinched, kinked, clogged, or leaking fuel tubes or hoses (para 5-13 and 5-14).

Are fuel lines free of pinches, kinks, clogs, and leaks?



CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (3) ENGINE CRANKS BUT DOES NOT START. - CONTINUED

CONTINUED FROM STEP G

**H** Check the main fuel hose for proper connection at primary fuel filter (para 5-13).


Is main fuel line properly connected?



**I**

1. Disconnect harness W123 connector P1 from generator/fuel pump relay.
2. Place a jumper wire in harness W123 connector P1 from socket B to socket C.
3. Turn vehicle MASTER switch ON and crank engine.


Does engine start?





**J**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Reconnect harness W123 connector P1 to generator/fuel pump relay.
3. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
4. Hold down fuel prime switch for 45 seconds.
5. Check secondary filter for fuel (TM 9-2350-314-10).


Is secondary filter full of fuel?



CONTINUED ON NEXT PAGE



W123 CONNECTOR P1 GENERATOR/FUEL PUMP RELAY



W123 CONNECTOR P1 SOCKET B SOCKET C

06ph055t




# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (3) ENGINE CRANKS BUT DOES NOT START. - CONTINUED

CONTINUED FROM STEP J

**K** Crank engine to start (TM 9-2350-314-10).  
Does engine start?



Problem solved.

**L** 1. Turn MASTER switch OFF (TM 9-2350-314-10).  
2. Check the engine air cleaner system for clogs or restrictions (TM 9-2350-314-10).  
Is the system clogged or restricted?



Service or repair air cleaner system (para 5-5).

1. Perform STE/ICE test 24 (para 3-4.b(13)).  
2. Perform STE/ICE test 14 (para 3-4.b(10)).  
3. Perform STE/ICE test 10 (para 3-4.b(9)).

END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (4) COMBAT OVERRIDE SWITCH WILL NOT OVERRIDE.


<p><b>INITIAL SETUP</b></p> <p><u>Tools</u></p> <p>General mechanic's tool kit (SC 5180-90-N26)          Multimeter (item 38, Appx F)          Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u></p> <p>Transmission access doors opened (TM 9-2350-314-10)</p> <p><u>Personnel Required</u></p> <p>Two</p>
--	---

**NOTE**


When starter is cranking, the starter protection device should automatically cut starter off after cranking for the following period of time:

- 25-35 seconds at 50°F (10°C) or above.
- 55-65 seconds at 0° to 50°F (-17° to 10°C)
- 100-140 seconds at 0° to -50° F (-17° to -45°C)

Starter protection device should reset in 105-140 seconds. If starter does not shut off as indicated or device will not reset, replace device.




- A**
1. Disconnect harness W114 lead 611 and harness W114 lead 7 from combat override switch.
  2. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and pull fuel shutoff handle out (so engine will not start).
  3. Press starter switch and crank engine until starter automatically shuts off (TM 9-2350-314-10).
  4. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  5. Place a jumper lead between harness W114 lead 611 and harness W114 lead 7.
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  7. Attempt to crank engine.



Does starter crank?

- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove jumper lead.
  3. Place multimeter red lead in harness W114 lead 7 socket and black lead to ground.
  4. Check continuity of harness W114 lead 7.



Is continuity present?


CONTINUED ON NEXT PAGE

06oh05.31

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (4) COMBAT OVERRIDE SWITCH WILL NOT OVERRIDE. - CONTINUED


CONTINUED FROM STEP B



**C**

1. Reconnect harness W114 lead 611 and harness W114 lead 7 to combat override switch.
2. Disconnect harness W114 connector P1 from harness W105 connector J1.
3. Make sure combat override switch is ON (TM 9-2350-314-10).
4. Using a multimeter, check continuity of harness W114 lead 611 by placing one multimeter lead on harness W114 connector P1 pin W and placing the other lead to ground.


Is continuity present?



**D**





1. Reconnect harness W114 connector P1 to harness W105 connector J1.
2. Disconnect harness W105 connector P3 from the starter protection device.
3. Make sure combat override switch is ON (TM 9-2350-314-10).
4. Using a multimeter, check continuity of lead 611 by placing one multimeter lead in harness W105 connector P3 socket F and placing the other lead to ground.

Is continuity present?



Replace starter protection relay (para 8-23).

END OF TASK



06ph054t

### 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (5) ENGINE DOES NOT ACCELERATE PROPERLY OR DOES NOT DEVELOP FULL POWER.

**INITIAL SETUP**


Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Pressure gage tester (item 22, Appx F)

**WARNING**

Do not smoke or use open flame when working on fuel system. An explosion may occur, causing severe injury or death.


**A** Check hand throttle control rod and accelerator pedal adjustment (para 5-19 and para 5-20).

Are hand throttle control rod and accelerator pedal properly adjusted?



**B**

1. Open engine access door (TM 9-2350-314-10).
2. Remove fuel supply pressure transducer at secondary fuel filter (para 8-43).
3. Install appropriate pressure gage from kit.
4. Start engine and increase idle to 1500 rpm (TM 9-2350-314-10). Pressure should be 40-70 psi at 1500 to 2300 rpm.
5. Remove pressure gage.
6. Install fuel supply pressure transducer at secondary fuel filter (para 8-43).



CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


f. ENGINE - CONTINUED (5) ENGINE DOES NOT ACCELERATE PROPERLY OR DOES NOT DEVELOP FULL POWER. - CONTINUED

CONTINUED FROM STEP B

**C**


1. Remove plug and install a 100 psi gage with a fitting in the primary fuel filter inlet.
2. Disconnect harness W123 connector P1 from the fuel pump relay.
3. Place a jumper wire from socket A to socket C of harness W123 connector P1.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and watch the gage.

Does gage show at least 4 psi?





**D** Check fuel lines to secondary fuel filter for restrictions and/or leaks (para 5-13 and para 5-14).

Are fuel lines free of leaks and/or restrictions?



**E** Check primary and secondary fuel filters for restricted filter elements (para 5-16).

Are primary and secondary filter elements free of restrictions?



CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (5) ENGINE DOES NOT ACCELERATE PROPERLY OR DOES NOT DEVELOP FULL POWER. - CONTINUED

CONTINUED FROM STEP B

**F** Ensure brakes are properly adjusted (not adjusted too tight) (para 11-1).

Are brakes properly adjusted?



Adjust brakes (para 11-1).

**G** Perform mechanical fuel pump test (para 5-4).

Is fuel flow at least 1/2 gallon (1.9 L) per minute?



1. Remove exhaust crossover pipe.
2. Check for dirt in relief valve (para 5-3).
3. Replace mechanical fuel pump if shaft is broken (para 5-2).

Notify direct support maintenance.

**END OF TASK**

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (6) ENGINE DOES NOT MAINTAIN STEADY RPM.


<u>INITIAL SETUP</u>	
<u>Tools</u> General mechanic's tool kit (SC 5180-90-N26)	<u>Equipment Conditions</u> Air intake grille opened (TM 9-2350-314-10)

**WARNING**

Do not smoke or use open flame when working on fuel system. An explosion may occur, causing severe injury or death.


**A** Ensure that engine coolant is at operating temperature (170° F (77°C)) (TM 9-2350-314-10).

Is engine at operating temperature?




**B** Check accelerator and throttle linkage for loose mounting hardware (para 5-22).

Are accelerator and throttle securely mounted?



**C** Check for pinched, kinked, clogged, or leaking fuel tubes or hoses (para 5-13 and 5-14).

Are fuel lines free of pinches, kinks, clogs, and leaks?



CONTINUED ON NEXT PAGE

**3-3 TROUBLESHOOTING CHART - CONTINUED**

f. ENGINE - CONTINUED (6) ENGINE DOES NOT MAINTAIN STEADY RPM. - CONTINUED

CONTINUED FROM STEP C

**D** Check primary and secondary fuel filters for restricted filter element (para 5-16).  
 Are filter elements free of restrictions?

yes

no

Notify direct support maintenance.

1. Drain/service fuel tanks (TM 9-2350-314-10).
2. Change primary and secondary fuel filters (para 5-16).
3. If symptom still exists notify direct support maintenance.

**END OF TASK**



# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (7) ENGINE USES EXCESSIVE FUEL.


<b>INITIAL SETUP</b>	
<u>Tools</u> General mechanic's tool kit (SC 5180-90-N26)	<u>Equipment Conditions</u> Air intake grille opened (TM 9-2350-314-10) Transmission access door opened (TM 9-2350-314-10)

**WARNING**

Do not smoke or use open flame when working on fuel system. An explosion may occur, causing severe injury or death.


**A** Start engine and check exhaust output (TM 9-2350-314-10).

Is exhaust black or gray?



**B** Check air filters for restrictions or dirty filter elements (para 5-5 and TM 9-2350-314-10).

Are air filters free of restriction and dirty filter elements?




CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (7) ENGINE USES EXCESSIVE FUEL. - CONTINUED

CONTINUED FROM STEP B

**C** Inspect fuel tanks, mechanical fuel pump, fuel lines and connections for leaks (Chapter 5).  
 Are all fuel tanks, lines, and connections free of leaks?



Tighten all fuel lines and connections that leak. If leak persists, replace lines and/or connections. If fuel tank leaks, notify direct support maintenance.

Notify direct support maintenance.

END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (8) WHITE EXHAUST SMOKE IS PRESENT.


<b>INITIAL SETUP</b>	
<u>Tools</u> General mechanic's tool kit (SC 5180-90-N26)	<u>Equipment Conditions</u> Transmission access door opened (TM 9-2350-314-10)

**WARNING**

Do not smoke or use open flame when working on fuel system. An explosion may occur, causing severe injury or death.


**A** Check fuel filters for contaminated fuel and dirty filter elements (para 5-16).

Are fuel and filter elements clean?



**B** Check radiator for low coolant level. If low, check engine oil for contamination (TM 9-2350-314-10).

Is radiator coolant level low and oil contaminated?



**END OF TASK**

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (9) EXHAUST FUMES PRESENT IN CREW COMPARTMENT.

**INITIAL SETUP**


<p><u>Tools</u> General mechanic's tool kit (SC 5180-90-N26)</p>	<p><u>Equipment Conditions</u> Air intake grille opened (TM 9-2350-314-10)</p>
--	--

**WARNING**

Make sure engine and exhaust systems are cool enough to permit handling. Failure to do so may cause serious burns to personnel.


**A** Check exhaust outlet pipe and connections for leaks (Table 2-1, PMCS item 34).

Are there any leaks in exhaust outlet pipe and connections?



**B** Remove engine compartment access cover and inspect seal (para 16-7).

Is access cover seal serviceable?




**C** Inspect all exhaust pipes and clamps for damage or looseness (para 6-1).

Are all exhaust pipes and clamps tight and serviceable?

CONTINUED ON NEXT PAGE

### 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (9) EXHAUST FUMES PRESENT IN CREW COMPARTMENT. - CONTINUED



END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (10) ENGINE HAS LOW OR NO OIL PRESSURE.


<u>INITIAL SETUP</u>	
<u>Tools</u> General mechanic's tool kit (SC 5180-90-N26) Pressure gage tester (item 22, Appx F)	<u>Equipment Conditions</u> Air intake grille opened (TM 9-2350-314-10) Transmission access doors open (TM 9-2350-314-10)

**CAUTION**

If engine indicates low oil pressure (MASTER warning light on) or no oil pressure, shut engine off immediately. Failure to do so may result in serious damage to engine.


**A** Check engine oil level. Level should be between add and full marks (TM 9-2350-314-10).

Is oil level between add and full?



**B** Check oil lines, oil filter housing (para 4-6), and engine cover for oil leaks.

Is engine oil system free of leaks?




CONTINUED ON NEXT PAGE

### 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (10) ENGINE HAS LOW OR NO OIL PRESSURE. - CONTINUED

CONTINUED FROM STEP B

<b>C</b>	1. Remove plug (or oil sample line) from oil filter (para 4-6).
	2. Install pressure gage.
	3. Start engine (TM 9-2350-314-10).
Is oil pressure 30 to 50 psi at 1000 rpm?	



Troubleshoot engine oil pressure gage circuit (para 3-3.g(1)).

END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (11) ENGINE OVERHEATS.


<u>INITIAL SETUP</u>	
<u>Tools</u> General mechanic's tool kit (SC 5180-90-N26)	<u>Equipment Conditions</u> Air intake grille opened (TM 9-2350-314-10)

**WARNING**  
Do not remove radiator cap on a hot engine. Failure to follow this procedure may result in severe injury.


**WARNING**  
To avoid burns, ensure engine and coolant have cooled before removing components. Failure to comply may result in severe injury.

**WARNING**  
A protective fan screen must be installed prior to doing maintenance in the engine compartment when the engine is running or engine is in ground hop mode. Contact with rotating fan can cause injury.

**A** Check coolant in radiator for proper level (TM 9-2350-314-10).  
Is coolant at proper level?



**B** Check engine oil for proper level (TM 9-2350-314-10).  
Is engine oil at proper level?



CONTINUED ON NEXT PAGE




# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (11) ENGINE OVERHEATS. - CONTINUED

CONTINUED FROM STEP B

**C** Troubleshoot engine coolant temperature indicator circuit (para 3-3.g(2)).

Is engine coolant temperature indicator circuit operating properly?




Repair or replace engine coolant temperature indicator circuit components as required.

**D**

1. Remove radiator cap and start engine (TM 9-2350-314-10).
2. Check radiator for contaminated coolant or restricted water tubes (TM 9-2350-314-10 and para 7-1).


Are there restrictions in the radiator or is coolant contaminated?



Notify direct support maintenance for cleaning and flushing of cooling system.

**E** Check radiator water for air bubbles.

Are there air bubbles in radiator?



Notify direct support maintenance.


**F** Check engine fan drive system (Table 2-1, PMCS item 7).

Are fans operating properly?

CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (11) ENGINE OVERHEATS. - CONTINUED




# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (11) ENGINE OVERHEATS. - CONTINUED

CONTINUED FROM STEP H

- |                             |   |
|-----------------------------|---|
| <b>I</b>                    | <ol style="list-style-type: none"><li>1. Remove inlet and bypass thermostats (paras 7-8 and 7-9).</li><li>2. Reassemble thermostat housing without thermostats (paras 7-8 and 7-9).</li><li>3. Start engine and check if engine still overheats (TM 9-2350-314-10).</li></ol> |
| Does engine still overheat? |   |



**END OF TASK**

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (12) ENGINE CRANKS BUT WILL NOT START IN COLD WEATHER. Temperature below 40°F (4°C).


**INITIAL SETUP**

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Engine grill cover open (TM 9-2350-314-10)                  Fan protective screens installed (para 4-1.c)                  Transmission access doors opened (TM 9-2350-314-10)</p>
<p><u>Personnel Required</u>                  Two</p>	

**A**

1. Disconnect plug harness 12268389 from glow plug controller.
2. Using a multimeter, place red lead on positive terminal of batteries and black lead to sockets A thru H.
3. Check all eight sockets for  $24 \pm 3$  V dc.


Is voltage indicated on all eight sockets?




**B**

1. Remove glow plug harness assembly 12268389 from glow plugs.
2. Perform continuity check between sockets A thru H and glow plug connector.

Is continuity indicated for each socket?



CONTINUED ON NEXT PAGE





06ph347t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (12) ENGINE CRANKS BUT WILL NOT START IN COLD WEATHER. Temperature below 40°F (4°C). - CONTINUED

CONTINUED FROM STEP B

- C**
1. Place red lead of multimeter on positive terminal of batteries and black lead to each glow plug.
  2. Check all eight glow plugs for vehicle voltage.
- Is voltage indicated on all eight glow plugs?



06ph348t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (12) ENGINE CRANKS BUT WILL NOT START IN COLD WEATHER. Temperature below 40°F (4°C) .- CONTINUED

CONTINUED FROM STEP A

- D**
1. Reconnect harness assembly 12268389 to glow plug controller and glow plugs.
  2. Disconnect glow plug controller to engine starter wiring harness 23506389 at glow plug controller.
  3. Place red lead of multimeter in socket A and black lead to ground.
  4. Check for continuity.


Is continuity indicated?






Notify direct support maintenance to replace wiring harness 23506389.

- E**
1. Place red lead of multimeter at sockets E and B and black lead to ground.
  2. Check for  $24 \pm 3$  V dc.

Is voltage indicated on both pins.



Notify direct support maintenance to replace wiring harness 23506389.



06ph349t


CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


f. ENGINE - CONTINUED (12) ENGINE CRANKS BUT WILL NOT START IN COLD WEATHER. Temperature below 40°F (4°C). - CONTINUED

CONTINUED FROM STEP E


<b>F</b>	<ol style="list-style-type: none"> <li>1. Place red lead of multimeter in socket F of wiring harness 23506389 and black lead to ground.</li> <li>2. Turn MASTER switch ON.</li> <li>3. Pull fuel shutoff handle and engage starter switch (refer to TM 9-2350-314-10).</li> <li>4. Check for <math>24 \pm 3</math> V dc.</li> <li>5. Turn MASTER switch OFF (refer to TM 9-2350-314-10).</li> </ol>
Is voltage indicated?	



no	yes
Notify direct support maintenance to replace wiring harness 23506389.	



<b>G</b>	<ol style="list-style-type: none"> <li>1. Reconnect glow plug controller to engine starter wiring harness connector 23506389 to glow plug controller.</li> <li>2. Disconnect harness assembly W104 connector P2 from glow plug controller.</li> <li>3. Place red lead of multimeter in socket B (lead 486A) and black lead to ground.</li> <li>4. Turn MASTER switch ON and hold glow plug switch on.</li> <li>5. Check for <math>24 \pm 3</math> V dc.</li> <li>6. Turn MASTER switch OFF and release glow plug switch (refer to TM 9-2350-314-10).</li> </ol>
Is voltage indicated?	



NOTE: No voltage should be present on sockets A or C. Also, there should be continuity between A and C.


06ph350t

CONTINUED ON NEXT PAGE



# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (12) ENGINE CRANKS BUT WILL NOT START IN COLD WEATHER. Temperature below 40°F (4°C). - CONTINUED

CONTINUED FROM STEP G



- H**
1. Reconnect harness assembly W104 connector P2 to glow plug controller.
  2. Disconnect harness assembly 12268389 from glow plug controller.
  3. Place red lead of multimeter on pin A thru H of connector on glow plug controller and black lead to ground.
  4. Turn MASTER switch ON and hold glow plug switch ON (refer to TM 9-2350-314-10).
  5. Check for  $24 \pm 3$  V dc.
  6. Turn MASTER switch OFF (refer to TM 9-2350-314-10).
- Is voltage indicated?



06ph351t




# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (12) ENGINE CRANKS BUT WILL NOT START IN COLD WEATHER. Temperature below 40°F (4°C). - CONTINUED

CONTINUED FROM STEP G


- I**
1. Reconnect wiring harness assembly W104 connector P2 to glow plug controller.
  2. Disconnect wiring harness W105 connector P1 from engine disconnect bracket.
  3. Place red multimeter lead in harness W105 connector P1 sockets C and O (one at a time) and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  5. Hold GLOW PLUGS switch ON (TM 9-2350-314-10).
  6. Check for voltage.

Is voltage present at point C and not present at pin C?






- J**
1. Release GLOW PLUGS switch (TM 9-2350-314-10).
  2. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  3. Reconnect harness W105 connector P1 to engine disconnect bracket.
  4. Disconnect wiring harness W114 connector P1 from driver's bulkhead.
  5. Place red multimeter lead on harness W114 connector P1 pins C and R (one at a time) and black lead to ground.
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  7. Hold GLOW PLUGS switch ON (TM 9-2350-314-10).
  8. Check for voltage.

Is voltage present at pin C and not present at pin R?



CONTINUED ON NEXT PAGE



06ph352t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (12) ENGINE CRANKS BUT WILL NOT START IN COLD WEATHER. Temperature below 40°F (4°C). - CONTINUED

CONTINUED FROM STEP F


**K** Is voltage present at pin R?




Repair or replace harness W114 (para 8-73).

- L**
1. Release GLOW PLUGS switch (TM 9-2350-314-10).
  2. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  3. Reconnect harness W114 connector P1 to driver's bulkhead.
  4. Remove driver's instrument panel (para 8-12).
  5. Disconnect lead 486A from GLOW PLUGS switch.
  6. Place red multimeter lead in GLOW PLUGS switch connector and black lead to ground.
  7. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  8. Hold GLOW PLUGS switch ON (TM 9-2350-314-10).
  9. Check for voltage.

Is voltage present?



Repair or replace harness W114 (para 8-73).



06ph081t



CONTINUED ON NEXT PAGE

### 3-3 TROUBLESHOOTING CHART - CONTINUED

f. ENGINE - CONTINUED (12) ENGINE CRANKS BUT WILL NOT START IN COLD WEATHER. Temperature below 40°F (4°C). - CONTINUED

CONTINUED FROM STEP L

- |                     |  |
|---------------------|--|
| <b>M</b>            | <ol style="list-style-type: none"> <li>1. Release GLOW PLUGS switch (TM 9-2350-314-10).</li> <li>2. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).</li> <li>3. Reconnect lead 486A to GLOW PLUGS switch.</li> <li>4. Disconnect lead 10S from GLOW PLUGS switch.</li> <li>5. Place red multimeter lead in lead 10S connector and black lead to ground.</li> <li>6. Turn vehicle MASTER switch ON (TM 9-2350-314-10).</li> <li>7. Check for voltage.</li> </ol> |
| Is voltage present? |  |



06ph082t

**END OF TASK**

## 3-3 TROUBLESHOOTING CHART - CONTINUED

### g. GAGES

The gages are located on the portable instrument panel and include the engine oil pressure gage, engine water temperature gage, transmission oil pressure gage, transmission oil temperature gage, fuel gage, and the battery/generator gage. Included in the gage system are the tachometer and speedometer, located on the driver's control panel.

The engine oil pressure gage circuit consists of the pressure gage, circuit breaker number 1 (CB1), pressure transmitter, and related wiring. The engine oil pressure gage should indicate engine oil pressure any time the vehicle MASTER switch is ON and the engine is running. The relationship of the engine oil pressure gage components is shown in the block diagram on the following page.

The engine water temperature gage circuit consists of the temperature gage, circuit breaker CB1, temperature transmitter, and related wiring. The engine water temperature gage should indicate engine coolant temperature any time the vehicle MASTER switch is ON. The relationship of the engine water temperature gage circuit is shown in the block diagram on the following page.

The transmission oil pressure gage circuit consists of the pressure gage, circuit breaker CB1, pressure transmitter, and related wiring. The transmission oil pressure gage should indicate transmission oil pressure any time the vehicle MASTER switch is ON and the engine is running. The relationship of the components in the transmission oil pressure gage circuit is shown in the block diagram on the following page.

The transmission oil temperature gage circuit consists of the temperature gage, circuit breaker CB1, temperature transmitter, and related wiring. The transmission oil temperature gage should indicate transmission oil temperature any time the vehicle MASTER switch is ON. The block diagram on the following page shows the relationship of the transmission oil temperature gage circuit components.







The fuel gage circuit consists of the fuel gage, circuit breaker CB1, fuel gage switch, upper and lower fuel tank transmitters, and related wiring. The fuel gage should indicate the level of fuel in the upper tank when the gage switch is set to UPPER and the vehicle MASTER switch is ON. Setting the gage switch to LOWER and turning the vehicle MASTER switch ON, the gage should indicate the fuel level in the lower tank. The relationship of the fuel gage circuit components is shown in the block diagram on the following page.

The battery/generator gage circuit consists of the gage, circuit breaker CB1, and related electrical wiring. The battery/generator gage should indicate vehicle voltage any time the vehicle MASTER switch is ON. See hull electrical schematic in fold-out pages (FP-1 through FP-9/FP-10 blank).

The tachometer system consists of the tachometer, flexible drive shaft, pulse tachometer, and drive output shaft. The tachometer should indicate engine revolutions per minute any time the vehicle MASTER switch is ON and the engine is running. See troubleshooting in-text art for pictorial description of components.

The speedometer system consists of the speedometer, flexible drive shaft, speedometer drive shaft, and speedometer drive. The speedometer should indicate vehicle speed in miles per hour any time the vehicle MASTER switch is ON with the engine running and the transmission in a forward gear. See troubleshooting chart for a pictorial description of components.

# 3-3 TROUBLESHOOTING CHART - CONTINUED



# 3-3 TROUBLESHOOTING CHART - CONTINUED

**g. GAGES - CONTINUED** (1) ENGINE OIL PRESSURE GAGE FAILS TO OPERATE WITH ENGINE RUNNING. All other instruments operate.

**INITIAL SETUP**


Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)  
 (Long test leads may be needed for some tests. 16 AWG wire may be used as an extension.)

Personnel Required  
 Two

Equipment Conditions  
 Air intake grille open (TM 9-2350-314-10)  
 Transmission access doors open (TM 9-2350-314-10)  
 Portable instrument panel cover removed (para 8-14)  
 Engine compartment access cover in driver's compartment removed (para 16-7)


- A**
1. Make sure vehicle MASTER switch is OFF (TM 9-2350-314-10).
  2. Disconnect harness W104 lead 36 from engine oil pressure transmitter.
  3. Place a jumper lead in harness W104 lead 36 connector socket. At this time, do not connect the other end of jumper.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10), oil pressure gage should read maximum.
  5. Ground jumper lead. Oil pressure gage should read minimum.

Does engine oil pressure gage show maximum when not grounded and minimum when grounded?




- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W112 lead 27 from engine oil pressure gage.
  3. Place multimeter red lead in harness W112 lead 27 socket and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE




06ph057t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


g. GAGES - CONTINUED (1) ENGINE OIL PRESSURE GAGE FAILS TO OPERATE WITH ENGINE RUNNING. All other instruments operate. - CONTINUED

CONTINUED FROM STEP B


- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W105 connector P1 from harness W104 connector J1.
  3. Remove jumper lead from harness W104 lead 36.
  4. Place one multimeter lead on harness W104 connector J1 pin D and other lead in harness W104 lead 36 connector socket. Check for continuity.
- Is continuity present?



- D**
1. Reconnect lead 36 to engine oil pressure transmitter.
  2. Disconnect harness W114 connector P1 from harness W105 connector J1.
  3. Place one multimeter lead in harness W105 connector P1 socket D and other lead in harness W105 connector J1 socket E. Check for continuity.
- Is continuity present?



CONTINUED ON NEXT PAGE



# 3-3 TROUBLESHOOTING CHART - CONTINUED


g. GAGES - CONTINUED (1) ENGINE OIL PRESSURE GAGE FAILS TO OPERATE WITH ENGINE RUNNING. All other instruments operate. - CONTINUED

CONTINUED FROM STEP D

**E**

1. Reconnect harness W105 connector P1 to harness W104 connector J1.
2. Disconnect harness W112 connector P1 from harness W114 connector J1.
3. Place one multimeter lead in harness W114 connector P1 pin E and other lead in harness W114 connector J1 socket D. Check for continuity.


Is continuity present?




**F**

1. Reconnect harness W114 connector P1 to bulkhead disconnect.
2. Disconnect harness W112 lead 36 from engine oil pressure gage connector.
3. Place one multimeter lead on harness W112 connector P1 pin D and other lead in harness W112 lead 36 connector socket. Check for continuity.

Is continuity present?



END OF TASK



06ph059t




### 3-3 TROUBLESHOOTING CHART - CONTINUED

**g. GAGES - CONTINUED** (2) **ENGINE WATER TEMPERATURE GAGE FAILS TO OPERATE PROPERLY.** Engine water gage needle does not move, is not steady, or is inaccurate. All other gages operate properly.

<b>INITIAL SETUP</b>	
<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long test leads may be needed for some tests. 16 AWG wire may be used as an extension.)</p>	<p><u>Equipment Conditions</u>                  Engine and transmission access doors open (TM 9-2350-314-10)                  Portable instrument panel cover removed (para 8-14)</p> <p><u>Personnel Required</u>                  Two</p>

- A**
1. With engine not running and vehicle MASTER switch OFF, disconnect harness W104 lead 33A from engine coolant temperature transmitter.
  2. Place a jumper lead in harness W104 lead 33A connector socket. At this time do not connect other end of jumper.
  3. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and observe engine water temperature gage. Gage should indicate minimum reading.
  4. Place jumper lead connected to harness W104 lead 33A to ground and observe gage. Gage should indicate maximum reading.




Does water temperature gage show minimum when not grounded, and maximum when grounded?


```

    graph TD
        Q1{Does water temperature gage show minimum when not grounded, and maximum when grounded?}
        Q1 -- yes --> A[Replace engine coolant temperature transmitter (para 8-51).]
        Q1 -- no --> B[ ]
    
```

- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W105 connector P1 from harness W104 connector J1.
  3. Remove jumper lead from harness W104 lead 33A.
  4. Place one multimeter lead on harness W104 connector J1 pin E and other in harness W104 lead 33A connector socket. Check for continuity.



Is continuity present?




CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (2) ENGINE WATER TEMPERATURE GAGE FAILS TO OPERATE PROPERLY. Engine water gage needle does not move, is not steady, or is inaccurate. All other gages operate properly. - CONTINUED


CONTINUED FROM STEP B



- C**
1. Reconnect harness W104 lead 33A to coolant temperature transmitter.
  2. Disconnect harness W114 connector P1 from harness W105 connector J1.
  3. Check harness W105 lead 33A for continuity by placing one multimeter lead in harness W105 connector P1 socket E and the other lead in harness W105 connector J1 socket F.
- Is continuity present?



CONTINUED ON NEXT PAGE



06ph061t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


g. GAGES - CONTINUED (2) ENGINE WATER TEMPERATURE GAGE FAILS TO OPERATE PROPERLY. Engine water gage needle does not move, is not steady, or is inaccurate. All other gages operate properly. - CONTINUED

CONTINUED FROM STEP C


- D**

  1. Reconnect harness W105 connector P1 to harness W104 connector J1.
  2. Disconnect harness W112 connector P1 from harness W114 connector J1.
  3. Check lead 33A for continuity by placing one multimeter lead on harness W114 connector P1 pin F and other lead in harness W114 connector J1 socket F.

Is continuity present?



CONTINUED ON NEXT PAGE



06ph062t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (2) ENGINE WATER TEMPERATURE GAGE FAILS TO OPERATE PROPERLY. Engine water gage needle does not move, is not steady, or is inaccurate. All other gages operate properly. - CONTINUED

CONTINUED FROM STEP D

- E**
1. Reconnect harness W114 connector P1 to harness W105 connector J1.
  2. Disconnect harness W112 lead 33A from engine water temperature gage.
  3. Check lead 33A for continuity by placing one multimeter lead on harness W112 connector P1 pin F and the other lead in harness W112 lead 33A socket.


Is continuity present?



Repair or replace harness W112 from connector P1 to lead 33A (para 8-71).

- F**
1. Reconnect harness W112 connector P1 to harness W114 connector P2.
  2. Disconnect harness W112 lead 27 from engine water temperature gage.
  3. Place multimeter red lead in harness W112 lead 27 connector and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.


Is voltage present equal to battery voltage reading?



Repair or replace harness W112 from connector P1 to lead 27 at the engine water temperature gage (para 8-71).

Replace engine water temperature gage (para 8-14).

END OF TASK




# 3-3 TROUBLESHOOTING CHART - CONTINUED

**g. GAGES - CONTINUED** (3) TRANSMISSION OIL PRESSURE GAGE FAILS TO OPERATE PROPERLY. All other instruments operate.

<b>INITIAL SETUP</b>	
<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long test leads may be needed for some tests. 16 AWG wire may be used as an extension.)</p>	<p><u>Equipment Conditions</u>                  Air intake grille open (TM 9-2350-314-10)                  Transmission access doors open (TM 9-2350-314-10)                  Portable instrument panel cover removed (para 8-16)</p> <p><u>Personnel Required</u>                  Two</p>


- A**
1. Make sure vehicle MASTER switch is OFF (TM 9-2350-314-10).
  2. Disconnect harness W104 lead 321 at transmission oil pressure transmitter.
  3. Place a jumper lead in harness W104 lead 321 connector socket.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10). Transmission oil pressure gage should indicate maximum reading.
  5. Ground jumper lead. Transmission oil pressure gage should indicate minimum reading.

Does transmission oil pressure gage show maximum when not grounded and minimum when grounded?




- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W112 lead 27 at transmission oil pressure gage connector.
  3. Place multimeter red lead in harness W112 lead 27 connector socket and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE



06ph064 t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


g. GAGES - CONTINUED (3) TRANSMISSION OIL PRESSURE GAGE FAILS TO OPERATE PROPERLY. All other instruments operate. - CONTINUED

CONTINUED FROM STEP B

**C**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W105 connector P1 from harness W104 connector J1.
3. Remove jumper lead from harness W104 lead 321 connector socket.
4. Place one multimeter lead on harness W104 connector J1 pin J and other lead in harness W104 lead 321 connector socket. Check for continuity.


Is continuity present?






**D**

1. Reconnect harness W104 lead 321 to transmission oil pressure transmitter.
2. Disconnect harness W114 connector P1 from harness W105 connector J1.
3. Place one multimeter lead in harness W105 connector P1 socket J and other lead in harness W105 connector J1 socket H. Check for continuity.

Is continuity present?



CONTINUED ON NEXT PAGE



06ph065t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


g. GAGES - CONTINUED (3) TRANSMISSION OIL PRESSURE GAGE FAILS TO OPERATE PROPERLY. All other instruments operate. - CONTINUED

CONTINUED FROM STEP D

**E**

1. Reconnect harness W105 connector P1 to harness W104 connector P1.
2. Disconnect harness W112 connector P1 from harness W114 connector J1.
3. Place one multimeter lead on harness W114 connector P1 pin H and other lead in harness W114 connector J1 socket H. Check for continuity.


Is continuity present?




**F**

1. Reconnect harness W114 connector P1 to harness W105 connector J1.
2. Disconnect harness W112 lead 321 from transmission oil pressure gage connector.
3. Place one multimeter lead on harness W112 connector P1 pin H and other lead in harness W112 lead 321 connector socket. Check for continuity.

Is continuity present?



END OF TASK



06ph066t



### 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (4) TRANSMISSION OIL TEMPERATURE GAGE FAILS TO INDICATE TRANSMISSION OIL TEMPERATURE. All other instruments operate.

**INITIAL SETUP**

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long test leads may be needed for some tests. 16 AWG wire may be used as an extension.)</p>	<p><u>Equipment Conditions</u>                  Air intake grille open (TM 9-2350-314-10)                  Transmission access doors open (TM 9-2350-314-10)                  Portable instrument panel cover removed (para 8-14)                  Driver's instrument panel removed (para 8-12)</p> <p><u>Personnel Required</u>                  Two</p>
--	--

- A**
1. Turn engine and vehicle MASTER switch OFF (TM 9-2350-314-10), if ON.
  2. Disconnect harness W104 lead 324 from transmission oil temperature transmitter.
  3. Place a jumper lead in harness W104 lead 324 connector socket. Do not attach other end of jumper at this time.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10). Transmission oil temperature gage should indicate minimum.
  5. Ground jumper lead. Transmission oil temperature gage should indicate maximum.
- Does transmission oil temperature gage show minimum when not grounded and maximum when grounded?



06ph067t




# 3-3 TROUBLESHOOTING CHART - CONTINUED


g. GAGES - CONTINUED (4) TRANSMISSION OIL TEMPERATURE GAGE FAILS TO INDICATE TRANSMISSION OIL TEMPERATURE. All other instruments operate. - CONTINUED

CONTINUED FROM STEP A

- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W112 lead 27 from transmission oil temperature gage.
  3. Place multimeter red lead in harness W112 lead 27 connector socket and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present equal to battery voltage reading?



CONTINUED ON NEXT PAGE



06ph068t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (4) TRANSMISSION OIL TEMPERATURE GAGE FAILS TO INDICATE TRANSMISSION OIL TEMPERATURE. All other instruments operate. - CONTINUED

CONTINUED FROM STEP B

- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W105 connector P1 from harness W104 connector J1.
  3. Remove jumper lead from harness W104 lead 324 connector socket.
  4. Check harness W104 lead 324 for continuity by placing one multimeter lead in harness W104 lead 324 connector socket and other lead on harness W104 connector J1 pin F.


Is continuity present?



Repair or replace harness W104 from transmission oil temperature transmitter to engine disconnect (para 8-63).


- D**
1. Reconnect harness W104 lead 324 to transmission oil temperature transmitter.
  2. Disconnect harness W114 connector P1 from harness W105 connector J1.
  3. Check harness W105 lead 324 for continuity by placing one multimeter lead in harness W105 connector P1 socket F and other lead in harness W105 connector J1 socket G.

Is continuity present?



Repair or replace harness W105 from engine connector to bulkhead connector (para 8-64).

CONTINUED ON NEXT PAGE



06ph069t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


g. GAGES - CONTINUED (4) TRANSMISSION OIL TEMPERATURE GAGE FAILS TO INDICATE TRANSMISSION OIL TEMPERATURE. All other instruments operate. - CONTINUED

CONTINUED FROM STEP D

**E**

1. Reconnect harness W105 connector P1 to harness W104 connector J1.
2. Disconnect harness W112 connector P1 from harness W114 connector J1.
3. Check harness W114 lead 324 for continuity by placing one multimeter lead on harness W114 connector P1 pin G and other lead in harness W114 connector J1 socket G.


Is continuity present?



**F**





1. Reconnect harness W114 connector P1 to harness W105 connector J1.
2. Disconnect harness W112 lead 324 from transmission oil temperature gage connector.
3. Check harness W112 lead 324 for continuity by placing one multimeter lead on harness W112 connector P1 pin G and other lead in harness W112 lead 324 connector socket.

Is continuity present?



END OF TASK

W112 CONNECTOR P1 W114 CONNECTOR J1



TRANSMISSION OIL TEMPERATURE GAGE

W112 CONNECTOR P1 PIN G


# 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (5) FUEL GAGE FAILS TO INDICATE A LEVEL READING WITH BOTH FUEL TANKS FULL. All other instruments operate.



**INITIAL SETUP**

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long test leads may be needed for some tests. 16 AWG wire may be used as an extension.)</p>	<p><u>Equipment Conditions</u>                  Engine and transmission access doors open (TM 9-2350-314-10)                  Portable instrument panel cover removed (para 8-14)                  Fuel tanks full (TM 9-2350-314-10)                  Driver's instrument panel removed (para 8-12)</p>
--	--

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W112 lead 27 from fuel gage connector.
  3. Place multimeter red lead in harness W112 lead 27 connector socket and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W112 lead 27 to fuel gage connector.
  3. Disconnect harness W112 lead 29-31 from fuel gage connector.
  4. Connect jumper lead to fuel gage connector pin. (Do not attach jumper to ground.)
- NOTE:** Fuel gage should indicate FULL.
5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  6. Ground jumper lead.
- NOTE:** Fuel gage should indicate EMPTY.



06ph071t

CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


g. GAGES - CONTINUED (5) FUEL GAGE FAILS TO INDICATE A LEVEL READING WITH BOTH FUEL TANKS FULL. All other instruments operate. - CONTINUED

CONTINUED FROM STEP B

**C**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W112 connector P1 from harness W114 connector J1.
3. Check harness W112 lead 29-31 for continuity by placing one multimeter lead in harness W112 lead 29-31 connector socket and other lead on wiring harness W112 connector P1 pin S.


Is continuity present?




**D**

1. Remove jumper lead from fuel gage.
2. Reconnect harness W112 lead 29-31 to fuel gage.
3. Disconnect harness W114 lead 29-31 from fuel level switch.
4. Check harness W114 lead 29-31 for continuity by placing one multimeter lead in harness W114 lead 29-31 connector socket to harness W114 connector J1 socket S.

Is continuity present?



CONTINUED ON NEXT PAGE



06ph072t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (5) FUEL GAGE FAILS TO INDICATE A LEVEL READING WITH BOTH FUEL TANKS FULL. All other instruments operate. - CONTINUED

CONTINUED FROM STEP D


- E**
1. Disconnect harness W115 leads 29 and 31 from fuel level switch.
  2. Check fuel level switch for continuity by placing one multimeter lead in top connector and other lead to center connector, then place fuel level switch in UPPER position.
  3. Check fuel level switch for continuity by placing one multimeter lead in lower connector and other lead in center connector, then place fuel level switch in LOWER position.

Is continuity present for both checks?




- F**
1. Remove exhaust grille (para 16-24).
  2. Remove access covers from upper and lower fuel tank transmitters (para 5-12).
  3. Disconnect harness W113 lead 31 from upper fuel tank transmitter and harness W113 lead 29 from lower fuel tank transmitter.
  4. Place one multimeter lead in harness W115 lead 29 connector and other lead in harness W115 lead 31 connector.
  5. Check for continuity.

Is continuity present?



CONTINUED ON NEXT PAGE



06ph073t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (5) FUEL GAGE FAILS TO INDICATE A LEVEL READING WITH BOTH FUEL TANKS FULL. All other instruments operate. - CONTINUED

CONTINUED FROM STEP F

- G**
1. Disconnect harness W115 connector P1 from harness W113 J1.
  2. Place one multimeter lead in harness W115 lead 29 and the other multimeter lead in harness W115 lead 31.
  3. Check for continuity.



Is continuity present?




Repair or replace harness W113 (para 8-72).

Repair or replace harness W115 (para 8-74).

END OF TASK



W115 P1 W113 J1



06ph091t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (6) FUEL GAGE FAILS TO INDICATE LEVEL OF UPPER FUEL TANK. Indicates lower fuel tank level properly.




**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

Equipment Conditions  
 Driver's instrument panel removed (para 8-12)

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 lead 29 from fuel UPPER/LOWER switch.
  3. Ensure fuel UPPER/LOWER switch is in the UPPER position (TM 9-2350-314-10).
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Does fuel gage indicate FULL?



06ph092t



# 3-3 TROUBLESHOOTING CHART - CONTINUED


g. GAGES - CONTINUED (6) FUEL GAGE FAILS TO INDICATE LEVEL OF UPPER FUEL TANK. Indicates lower fuel tank level properly. - CONTINUED

CONTINUED FROM STEP A




- B**

  1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W115 lead 29 to fuel UPPER/LOWER switch.
  3. Disconnect harness W115 connector P1 from harness W113 connector J1 at driver's compartment bulkhead.
  4. Check for continuity by placing one lead in socket J of harness W115 connector P1 and other lead to ground.

Is continuity present?



CONTINUED ON NEXT PAGE



06ph093t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (6) FUEL GAGE FAILS TO INDICATE LEVEL OF UPPER FUEL TANK. Indicates lower fuel tank level properly. - CONTINUED


CONTINUED FROM STEP B

- C**
1. Reconnect harness W115 connector P1 to harness W113 connector J1.
  2. Remove exhaust grille (para 16-24).
  3. Remove access cover from upper fuel tank transmitter (para 5-12).
  4. Disconnect W113 lead 31 from upper fuel tank transmitter.
  5. Ensure fuel switch is in the UPPER position (TM 9-2350-314-10).
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Does fuel gage indicate FULL?



END OF TASK



06ph094t




# 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (7) FUEL GAGE FAILS TO INDICATE FUEL LEVEL IN LOWER FUEL TANK. Indicates upper fuel tank level properly.

**INITIAL SETUP**

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Driver's instrument panel removed (para 8-12)</p>
--	---

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 lead 31 from fuel UPPER/LOWER switch.
  3. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  4. Ensure fuel UPPER/LOWER switch is in LOWER position (TM 9-2350-314-10).



06ph095t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (7) FUEL GAGE FAILS TO INDICATE FUEL LEVEL IN LOWER FUEL TANK. Indicates upper fuel tank level properly. - CONTINUED



CONTINUED FROM STEP A

- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W115 lead 31 to fuel UPPER/LOWER switch.
  3. Disconnect harness W115 connector P1 from harness W113 connector J1 at driver's compartment.
  4. Check for continuity by placing one multimeter lead on harness W115 connector P1 socket K and other lead to ground.

Is continuity present?



CONTINUED ON NEXT PAGE



W115  
CONNECTOR P1  
SOCKET K

06ph096t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (7) FUEL GAGE FAILS TO INDICATE FUEL LEVEL IN LOWER FUEL TANK. Indicates upper fuel tank level properly. - CONTINUED


CONTINUED FROM STEP B

- C**
1. Reconnect harness W115 connector P1 to harness W113 connector J1.
  2. Remove exhaust grille (para 16-24).
  3. Remove access cover to lower fuel tank transmitter (para 5-12).
  4. Disconnect harness W113 lead 29 from lower fuel tank transmitter.
  5. Ensure fuel UPPER/LOWER switch is in LOWER position (TM 9-2350-314-10).
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Does fuel gage indicate FULL?



END OF TASK



# 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (8) BATTERY/GENERATOR GAGE FAILS TO OPERATE PROPERLY - NO OR UNSTEADY READING. Other instruments operate.

**INITIAL SETUP**


<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Battery access doors open (TM 9-2350-314-10)                  Portable instrument panel removed (TM 9-2350-314-10)</p>
--	--

**NOTE**




The battery/generator gage indicates battery voltage when the generator is not operating and generator output when generator is running. The color zones on gage indicate the following voltages:

- low red (left side of gage) 18-22 volts.
- yellow 22-26 volts.
- green 26-30 volts.
- high red (right side of gage) 30-34 volts.

- A**
- Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  - Disconnect harness W112 lead 27 from battery/generator gage connector.
  - Place multimeter red lead in lead 27 connector socket and black lead to ground.
  - Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



- B**
- Start engine (TM 9-2350-314-10).
  - Place multimeter red lead on harness W109 lead 81 at battery and black lead to shunt.



CONTINUED ON NEXT PAGE


06ph086t

### 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (8) BATTERY/GENERATOR GAGE FAILS TO OPERATE PROPERLY - NO OR UNSTEADY READING. Other instruments operate. - CONTINUED

CONTINUED FROM STEP B

- C**
1. Shut ENGINE and vehicle MASTER switches OFF (TM 9-2350-314-10).
  2. Ensure battery/generator gage is securely mounted.
  3. Reconnect lead 27 to battery generator gage connector.
  4. Turn vehicle MASTER switch ON and check gage (TM 9-2350-314-10). Voltage should be present.
  5. Start engine and check gage (TM 9-2350-314-10). Generator output voltage should be as shown in note at the beginning of this procedure.
- Does gage show voltage reading?




END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (9) TACHOMETER FAILS TO OPERATE WHEN ENGINE IS RUNNING. - CONTINUED

<b>INITIAL SETUP</b>	
<p><u>Tools</u> General mechanic's tool kit (SC 5180-90-N26)</p>	<p><u>Equipment Conditions</u> Engine and transmission access doors open (TM 9-2350-314-10) Portable instrument panel removed (TM 9-2350-314-10)</p>
<p><u>Personnel Required</u> Two</p>	



- A**
1. Shut engine OFF, if running (TM 9-2350-314-10).
  2. Disconnect tachometer drive shaft from tachometer (para 20-2).
  3. Pull fuel shutoff out and hold so engine will not start (TM 9-2350-314-10).
  4. Crank engine (TM 9-2350-314-10) and observe tachometer flexible drive shaft for rotation.



**WARNING**

A protective fan screen **MUST** be installed prior to doing maintenance in the engine compartment when the engine is running or engine is in ground hop mode. Contact with a rotating fan can cause injury.

- B**
1. Install fan protective screens (para 4-1c.)
  2. Disconnect tachometer drive shaft from tachometer drive on engine (para 20-2).
  3. Have assistant hold fuel shutoff out and crank engine (TM 9-2350-314-10).
  4. Observe tachometer drive output shaft for rotation.



06ph089t

CONTINUED ON NEXT PAGE



# 3-3 TROUBLESHOOTING CHART - CONTINUED


g. GAGES - CONTINUED (9) TACHOMETER FAILS TO OPERATE WHEN ENGINE IS RUNNING. - CONTINUED

CONTINUED FROM STEP B

**C**

1. Reconnect tachometer drive shaft to tachometer drive on engine (para 20-2).
2. Disconnect tachometer drive shaft from bulkhead coupling (para 20-2).
3. Have assistant hold fuel shutoff handle out and crank engine (TM 9-2350-314-10).
4. Observe tachometer flexible drive shaft for rotation.





Does tachometer flexible drive shaft rotate?



**D**

1. Reconnect tachometer drive shaft to bulkhead coupling.
2. Disconnect tachometer drive shaft from pulse tachometer.
3. Have assistant hold fuel shutoff handle out. Crank engine (TM 9-2350-314-10).
4. Observe pulse tachometer for rotation.

Does pulse tachometer drive rotate?




CONTINUED ON NEXT PAGE

**3-3 TROUBLESHOOTING CHART - CONTINUED**

g. GAGES - CONTINUED (9) TACHOMETER FAILS TO OPERATE WHEN ENGINE IS RUNNING. - CONTINUED

CONTINUED FROM STEP B

<b>E</b>	<ol style="list-style-type: none"> <li>1. Remove tachometer drive adapter from engine (para 20-2).</li> <li>2. By hand, rotate drive shaft at one end while observing other end for rotation.</li> </ol>
Does shaft rotate?	



Notify direct support maintenance.

**END OF TASK**

# 3-3 TROUBLESHOOTING CHART - CONTINUED


g. GAGES - CONTINUED (10) SPEEDOMETER FAILS TO OPERATE WHEN VEHICLE IS MOVING FORWARD.

<b>INITIAL SETUP</b>	
<u>Tools</u> General mechanic's tool kit (SC 5180-90-N26)	<u>Equipment Conditions</u> Portable instrument panel removed (TM 9-2350-314-10) Transmission access doors open (TM 9-2350-314-10)
<u>Personnel Required</u> Two	

- A**

  1. Disconnect speedometer drive shaft from speedometer drive on transmission (para 20-1).
  2. By hand, rotate flexible drive shaft at one end (speedometer drive end) while observing speedometer for movement.




Does speedometer have movement?



- B**

  1. Disconnect speedometer drive shaft from speedometer (para 20-1).
  2. By hand, rotate flexible drive shaft at one end (speedometer drive end) while observing other end for rotation.

Does flexible drive shaft rotate?



47ph001t

CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED





g. GAGES - CONTINUED (10) SPEEDOMETER FAILS TO OPERATE WHEN VEHICLE IS MOVING FORWARD. - CONTINUED

CONTINUED FROM STEP B

**C**

1. Disconnect speedometer drive shaft from speedometer drive at bulkhead coupling (para 20-1).
2. By hand, rotate flexible drive shaft at one end (speedometer drive end) while observing other end for rotation.

Does flexible drive shaft rotate?




CONTINUED FROM STEP A

**D**

1. Remove speedometer angle drive adapter from straight drive adapter (para 20-1).
2. By hand, rotate flexible drive shaft at one end while observing other end for rotation.

Does shaft rotate?




CONTINUED ON NEXT PAGE

### 3-3 TROUBLESHOOTING CHART - CONTINUED

g. GAGES - CONTINUED (10) SPEEDOMETER FAILS TO OPERATE WHEN VEHICLE IS MOVING FORWARD. - CONTINUED

CONTINUED FROM STEP D

<b>E</b>	<ol style="list-style-type: none"><li>1. Remove right transmission trunion support cap (para 4-1).</li><li>2. Remove straight drive adapter (para 20-1).</li><li>3. By hand, rotate drive shaft at one end while observing other end for rotation.</li></ol>
	Does shaft rotate?



END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED


## h. GENERATOR

The generator circuit consists of the generator, voltage regulator, vehicle batteries, master relay, generator system and fuel pumps relay, air cleaner/generator system relay switch, starter switch, circuit breaker number 5, and related electrical wiring. The relationship of these components is shown on the electrical diagram below.

When the vehicle MASTER switch is turned ON, 24 V dc is supplied through circuit breaker number 5 (CB5) to the generator system and fuel pumps relay. Voltage also is supplied to the voltage regulator through the starter switch. The air cleaner/generator system relay switch closes when the engine is cranked and oil pressure reaches 4-8 psi causing the generator system and fuel pumps relay to close. This closes a circuit in the voltage regulator and the generator begins operating and supplying voltage to charge the batteries and operate all electrical components on the vehicle.

### WARNING

Probing the DIAGNOSTIC CONNECTOR ASSEMBLY (DCA) connector during voltage tests can result in equipment damage and/or injury to personnel due to high voltage peaks.



hipt723

# 3-3 TROUBLESHOOTING CHART - CONTINUED

**h. GENERATOR - CONTINUED** (1) **GENERATOR FAILS TO CHARGE BATTERIES.** Gage indication: not charging, unsteady, or inaccurate reading.

<p><b>INITIAL SETUP</b></p> <p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long test leads may be needed for some tests. 16 AWG wire may be used as an extension.)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)                  Battery box access doors open (TM 9-2350-314-10)                  Engine compartment access cover removed (para 16-7)                  Driver's instrument panel removed (para 8-12)                  Air intake grille open (TM 9-2350-314-10)</p>
--	--

**WARNING**

When engine is running and driver's compartment access panel has been removed for maintenance or troubleshooting use extreme care. Tools, clothing or hands can catch in generator belt and cause injury or death.


**NOTE**

- Ensure that circuit breaker on voltage regulator is in the ON position.
- Check ground strap (hull to transmission housing) for dirty/corroded/painted ground connections.
- Check generator for secure mounting.
- Check generator pulley for secure mounting and ensure proper tension is applied to the generator belt.

**A**



1. Start engine (TM 9-2350-314-10) and run at 1000 rpm.
2. Check for voltage by placing multimeter red lead on harness W109 lead 81 in the rear battery compartment and black lead on ground.

Are approximately 27.5 V dc present?



**B** Check for voltage by placing multimeter red lead on lead 81 connector in the forward battery compartment and black lead on ground.

Are approximately 27.5 V dc present?



# 3-3 TROUBLESHOOTING CHART - CONTINUED



h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED

CONTINUED FROM STEP A OR B

**C**

1. Shut engine OFF (TM 9-2350-314-10).
2. Using a lead with an alligator clip, connect multimeter red lead to lead 81 (+) at generator and place black lead on ground.
3. Ensure all leads are clear of generator belt and pulley.
4. Start engine (TM 9-2350-314-10) and check for voltage.



Are approximately 27.5 V dc present?



**D**

1. Shut engine OFF (TM 9-2350-314-10).
2. Turn vehicle MASTER power switch OFF (TM 9-2350-314-10).
3. Leave multimeter connection from previous step in place.
4. Disconnect harness W104 lead 415B from air cleaner/generator relay switch.
5. Place a jumper lead from harness W104 lead 415B connector socket to ground.
6. Place multimeter black lead to ground.
7. Start engine (TM 9-2350-314-10) and check for voltage.

Are approximately 27.5 V dc present?



CONTINUED ON NEXT PAGE

06ph101t




# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED


CONTINUED FROM STEP D

- E**
1. Shut ENGINE OFF and turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect multimeter red lead from generator.
  3. Leave jumper from lead 415B to ground in place.
  4. Disconnect harness W123 connector P1 at fuel pump/generator system relay.
  5. Check continuity from socket D of harness W123 connector P1 to ground.

Is continuity good?



CONTINUED ON NEXT PAGE



# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED

CONTINUED FROM STEP E

**F**

1. Reconnect harness W123 connector P1 to fuel pump/generator system relay.
2. Disconnect harness W123 lead 415B from harness W114 lead 415B.
3. Check continuity from harness W114 lead 415B connector to ground.

Is continuity good?



Repair or replace W123 (lead 415B) (para 8-81).



**G**

1. Reconnect harness W123 lead 415B to harness W114 lead 415B.
2. Disconnect harness W114 connector P1 from harness W105 connector J1 at driver's compartment bulkhead.
3. Check continuity from socket S of harness W105 connector J1 to ground.

Is continuity good?



Repair or replace harness W114 (para 8-73).



W105 CONNECTOR J1 SOCKET S

06ph103t

CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

**h. GENERATOR - CONTINUED** (1) **GENERATOR FAILS TO CHARGE BATTERIES.** Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED

CONTINUED FROM STEP G

**H**

1. Reconnect harness W114 to harness W105.
2. Disconnect harness W105 connector J1 at engine electrical disconnect bracket.
3. Check continuity from pin S of harness W104 connector J1 to ground.

Is continuity good?




Repair or replace harness W105 (para 8-64).      Repair or replace harness W104 (para 8-63).

CONTINUED FROM STEP E



**I**

1. Reconnect harness W123 connector P1 to fuel pump/generator system relay.
2. Disconnect lead 415C of harness W114 at three-way connector.
3. Check for voltage by placing multimeter red lead in three-way connector and black lead on ground.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).




Is voltage present?



CONTINUED ON NEXT PAGE



W104 CONNECTOR J1 PIN S




# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED


CONTINUED FROM STEP I

- J**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W123 connector P1 at fuel pump/generator system relay.
  3. Check for voltage by placing the multimeter red lead in sockets A and B (one at a time) and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Is voltage present?



CONTINUED ON NEXT PAGE




06ph105t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED


CONTINUED FROM STEP J

- K**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W123 lead 415 from three-way connector.
  3. Check for continuity from socket C of harness W123 connector P1 to lead 415 connector.
- Is continuity present?



Repair or replace harness W123 (lead 415) (para 8-81).

CONTINUED ON NEXT PAGE



# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED

CONTINUED FROM STEP J

- L**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W123 lead 415G at circuit breaker no. 5.
  3. Check for voltage by placing multimeter red lead on circuit breaker connector and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Is voltage present?



Repair or replace harness W123 (lead 415G) (para 8-81).


- M**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W124 lead 10 at circuit breaker no. 5.
  3. Check for voltage by placing multimeter red lead in lead 10 connector and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Is voltage present?



Replace circuit breaker no. 5 (para 8-20).

Repair or replace harness W124 (para 8-82).



CONTINUED ON NEXT PAGE

06ph107t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED

CONTINUED FROM STEP I




- N**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W123 leads 415C and 415 at three-way connector.
  3. Disconnect harness W114 lead 415C at starter switch.
  4. Check for voltage by placing the multimeter red lead in connector on harness W114 lead 415C and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Is voltage present?



- O**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W114 lead 415C at starter switch.
  3. Disconnect harness W114 lead 27B from starter switch.
  4. Check for voltage by placing multimeter red lead in starter switch lead 27B (lead coming from starter switch) and the black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Is voltage present?



06ph108t

CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED

CONTINUED FROM STEP O


- P**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W114 lead 27B to starter switch.
  3. Disconnect harness W114 connector P3 from voltage regulator control box.
  4. Check for voltage by placing multimeter red lead in harness W114 connector P3 socket D and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Is voltage present?






- Q**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Place one multimeter lead on voltage regulator control box pin A and the other lead on pin B.
  3. Ensure regulator control box switch is in the ON position.
  4. Check for continuity.

Is continuity present?



CONTINUED ON NEXT PAGE



06ph109t




# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED


CONTINUED FROM STEP Q

- R**
1. Disconnect harness W114 connector P1 from harness W105 connector J1 at driver's compartment bulkhead.
  2. Check for continuity by placing one multimeter lead on pin U of harness W114 connector P1 and the other lead in socket B of harness W114 connector P3.

Is continuity present?



CONTINUED ON NEXT PAGE





06ph110t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED

CONTINUED FROM STEP R

- S**
1. Reconnect harness W114 connector P1 to harness W105 J1 at driver's compartment bulkhead.
  2. Reconnect harness W114 connector P3 to voltage regulator control box.
  3. Place a three-way connector between harness W105 lead L+ and harness W106 lead L+.
  4. Check for voltage by placing the multimeter red lead in the three-way connector and the black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
- Is voltage present?




# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED

CONTINUED FROM STEP S





- T**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove three-way connector.
  3. Reconnect harness W106 lead L+ to harness W105 lead L+.
  4. Disconnect harness W106 lead AV from harness W106 lead AV-F+.
  5. Check for voltage by placing the multimeter red lead in harness W106 lead AV-F+ socket and black lead to ground.
  6. Start engine (TM 9-2350-314-10) and run at 1000 rpm.

Is voltage present?



- U**
1. Shut engine OFF and turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W106 connector P1 from voltage regulator.
  3. Check continuity from socket C of harness W106 connector P1 to connector AV-F+.

Is continuity good?



CONTINUED ON NEXT PAGE

06ph112t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED


CONTINUED FROM STEP T

**WARNING**

Engine may be hot. Use care when leaning over engine. Severe injury may result.





- V**
1. Remove turbo inlet adapter from engine (para 4-1).
  2. Disconnect harness W106 connectors P2 and P3 from generator.
  3. Disconnect harness W106 connector P1.
  4. Check harness W106 for continuity as follows:
- | FROM CONNECTOR | TO CONNECTOR |
|----------------|--------------|
| P1 socket C    | P2 socket C  |
| P1 socket D    | P2 socket B  |
| P1 socket F    | P3 pin A     |
| P1 socket G    | P3 pin D     |
| P1 socket H    | P3 pin B     |
| P1 socket J    | P3 pin C     |

Is continuity present for all checks?



- W**
1. Disconnect W106 harness lead 605-AC.
  2. Check for shorts to ground on harness W106 by placing one multimeter lead on ground and the other multimeter lead one at a time on pin C, D, F, G, H and J of harness W106 connector P1.

Is continuity present on any check?



06ph113t

CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED

CONTINUED FROM STEP C



- |          |   |
|----------|---|
| <b>X</b> | <ol style="list-style-type: none"> <li>1. Turn engine and vehicle MASTER switch OFF (TM 9-2350-314-10).</li> <li>2. Disconnect harness W109 connector P1 from harness W110 connector J1.</li> <li>2. Check for continuity between wire lead 81 at battery and W109 sockets A, B, C, and D.</li> </ol> |
|----------|---|

Is continuity good at all points?




Repair or replace harness W110 (para 8-69).

Repair or replace harness W109 (para 8-68).



CONTINUED ON NEXT PAGE




# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (1) GENERATOR FAILS TO CHARGE BATTERIES. Gage indication: not charging, unsteady, or inaccurate reading. - CONTINUED




CONTINUED FROM STEP B

- Y**
1. Disconnect harness W108 connector P1 from harness W107 connector J1.
  2. Check for continuity between wire lead 7 at shunt and sockets A, B, C, and D of harness W108.
- Is continuity good at all points?



Repair or replace harness W107 (para 8-66).      Repair or replace harness W108 (para 8-67).

END OF TASK



06ph115t



### 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (2) GENERATOR OVERCHARGING BATTERIES.  
 Battery/generator gage in high red.

**INITIAL SETUP**

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)                  Battery compartment access doors open (TM 9-2350-314-10)</p>
--	---

- A**
1. Shut engine and vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Place multimeter red lead on positive terminal on battery "A" and black lead to ground.
  3. Start engine (TM 9-2350-314-10).
  4. Check for voltage.
- Is 33 V dc or more present?



CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (2) GENERATOR OVERCHARGING BATTERIES.  
 Battery/generator gage in high red. - CONTINUED


CONTINUED FROM STEP A

- B**
1. Shut engine and vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Place a three-way connector between harness W105 lead OVS, and harness W106 lead OVS.
  3. Check for voltage by placing the red multimeter lead in the three-way connector and black lead to ground.
  4. Start engine (TM 9-2350-314-10).

Is 33 V dc or more present?



CONTINUED ON NEXT PAGE



06ph119t




# 3-3 TROUBLESHOOTING CHART - CONTINUED


h. GENERATOR - CONTINUED (2) GENERATOR OVERCHARGING BATTERIES.  
 Battery/generator gage in high red. - CONTINUED

CONTINUED FROM STEP B

- C**
1. Shut engine and vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove three-way connector from harness W105 lead OVS and harness W106 lead OVS.
  3. Disconnect harness W106 connector P1 from voltage regulator.
  4. Check for continuity by placing one multimeter lead in socket I of harness W106 connector P1 and the other lead in harness W106 lead OVS.



CONTINUED ON NEXT PAGE



06ph120t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (2) GENERATOR OVERCHARGING BATTERIES.  
Battery/generator gage in high red. - CONTINUED


CONTINUED FROM STEP C

- D**
1. Reconnect harness W106 connector P1 to voltage regulator.
  2. Disconnect harness W114 connector P1 from harness W105 connector J1.
  3. Check for continuity by placing one multimeter lead in socket I of harness W105 connector J1 and the other lead on harness W105 lead OVS pin.

Is continuity present?



CONTINUED ON NEXT PAGE



06ph121t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

h. GENERATOR - CONTINUED (2) GENERATOR OVERCHARGING BATTERIES.  
Battery/generator gage in high red. - CONTINUED

CONTINUED FROM STEP D

- E**
1. Reconnect harness W105 lead OVS to harness W106 lead OVS.
  2. Disconnect harness W114 connector P3 from voltage regulator control box.
  3. Check for continuity by placing one multimeter lead in harness W114 connector P3 socket C and the other lead on harness W114 connector P1 pin I.


Is continuity present?



Repair or replace harness W114 (para 8-73).

Replace voltage regulator (para 8-10).

END OF TASK



# 3-3 TROUBLESHOOTING CHART - CONTINUED

## i. HULL INTERCOM CIRCUIT


The vehicle is equipped with an AN/VIC-3(V)-6. The hull has two full function crew stations (FFCS): number 6 driver's and number 5 external.

The relationship of these components and wiring is shown in the diagrams below.

When the vehicle MASTER switch is turned ON, 24 V dc is supplied to the slip ring which distributes power to the driver's intercom, the exterior intercom, and the cab communications circuit. When power is supplied and the intercom boxes are turned ON, they are linked together and both stations (cab and hull) are able to communicate.

For AN/VIC-3(V)-6, refer to TM 11-5830-263-20&P.

### INTERCOM INSTALLATION, HULL AN/VIC-3 (V)-6



22ph004t


### 3-3 TROUBLESHOOTING CHART - CONTINUED

i. HULL INTERCOM CIRCUIT - CONTINUED (1) DRIVER'S OR EXTERNAL INTERCOM FAILS TO OPERATE. Chief of Section and crew intercoms operate.

<u>INITIAL SETUP</u>	
<u>Tools</u> General mechanic's tool kit (SC 5180-90-N26) Multimeter (item 38, Appx F) Probe kit (item 35, Appx F) (Long test leads may be needed for some tests. 16 AWG wire may be used as an extension.)	<u>Personnel Required</u> Two

**A** Visually inspect harness W111A for any cuts, breaks, kinks, or missing segments.



Are there any cuts, breaks, kinks, or missing segments?



**B**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W111A lead 48 from circuit breaker no. 9 connector.
3. Place multimeter red lead on circuit breaker connector pin and black lead on ground.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE

### 3-3 TROUBLESHOOTING CHART - CONTINUED


i. HULL INTERCOM CIRCUIT - CONTINUED (1) DRIVER'S OR EXTERNAL INTERCOM FAILS TO OPERATE. Chief of Section and crew intercoms operate - CONTINUED

CONTINUED FROM STEP B

**C**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Reconnect harness W111A lead 48 to circuit breaker no. 9 connector.
3. Disconnect harness W111A lead 7 from harness W125 lead 7 connector.
4. Check harness W125 lead 7 for continuity. Place one multimeter lead in harness W125 lead 7 connector pin and other lead on ground.


Is continuity present?




**D**

1. Reconnect harness W111A lead 7 to harness W125 lead 7 connector.
2. Disconnect harness W111A connector P1 at VMS hull side modem connector J2.
3. Make sure vehicle MASTER switch is ON.
4. Place multimeter red lead in harness W111A connector P1 socket A and black lead in harness W111A connector P1 socket B.
5. Check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE



06ph126t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


i. HULL INTERCOM CIRCUIT - CONTINUED (1) DRIVER'S OR EXTERNAL INTERCOM FAILS TO OPERATE. Chief of Section and crew intercoms operate - CONTINUED

CONTINUED FROM STEP D

**E**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W111A connector J2 from harness A3206130-10 connector P3 and harness W111A connector J3 from right slipping connector.
3. Check harness W111A for continuity by placing one multimeter lead in connector P1 socket C and other lead first in connector J2 socket H and then in connector J3 socket H.
4. Place one multimeter lead in connector P1 socket D and other lead first in connector J2 socket G and then in connector J3 socket G.





Is continuity present at all points?



**F**

Do shorts test on harness W111A connectors P1, J2, and J3 (para 3-1.3).

Are any shorts present?



06ph125t


END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED

## j. IN-TANK FUEL PUMPS

The in-tank fuel pump system consists of circuit breaker number 5 (CB5), in-tank fuel pumps, generator system and fuel pumps relay, left and right fuel pump assembly, air cleaner and generator system switch, and associated wiring. The relationship of these components is shown in the diagram below.

When the vehicle MASTER switch is turned ON, 24 V dc is supplied through MASTER RELAY and CB5 to in-tank fuel pumps generator system relay. When the engine is cranked and oil pressure reaches 4-8 psi, the air-cleaner and generator system relay switch closes, causing the in-tank fuel pump generator system relay to close. When the relay closes, 24 V dc is supplied to the left and right in-tank fuel pumps.



hipt725



### 3-3 TROUBLESHOOTING CHART - CONTINUED

j. IN-TANK FUEL PUMPS - CONTINUED (1) ELECTRICAL IN-TANK FUEL PUMP FAILS TO OPERATE. Engine misses when low on fuel.

**INITIAL SETUP**

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Driver's engine access cover removed (para 16-7).</p>
--	---

**WARNING**



Do not use open flame or smoke when working on the fuel system. An explosion may occur, causing severe injury or death.

**NOTE**

Left fuel pump can be tested from driver's access panel. Powerplant must be removed to test right fuel pump.

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W123 lead 415B from harness W114 lead 415B.
  3. Place a jumper lead from harness W123 lead 415B connector socket to ground.
  4. Disconnect harness W113 connector P4 from left in-tank fuel pump connector.
  5. Place multimeter red lead in harness W113 connector P4 lead 76 connector socket and black lead to ground.
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?




# 3-3 TROUBLESHOOTING CHART - CONTINUED

j. IN-TANK FUEL PUMPS - CONTINUED (1) ELECTRICAL IN-TANK FUEL PUMP FAILS TO OPERATE. Engine misses when low on fuel. - CONTINUED


CONTINUED FROM STEP A

- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 lead 76 from harness W123 lead 415.
  3. Disconnect harness W115 connector P1 from harness W113 connector J1.
  4. Check harness W115 lead 76 for continuity by placing one multimeter lead in lead 76 connector socket and other lead in harness W115 connector P1 socket H.




CONTINUED FROM STEP A

- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Check for continuity by placing one multimeter lead in harness W113 connector P4 GND socket and other lead to ground.



CONTINUED ON NEXT PAGE




### 3-3 TROUBLESHOOTING CHART - CONTINUED

j. IN-TANK FUEL PUMPS - CONTINUED (1) ELECTRICAL IN-TANK FUEL PUMP FAILS TO OPERATE. Engine misses when low on fuel. - CONTINUED

CONTINUED FROM STEP C

- D**
1. Disconnect fuel inlet line at primary fuel filter (para 5-14).
  2. Place fuel line in suitable container to catch fuel.
  3. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for fuel.


Is fuel pumped into container?



Replace left in-tank fuel pump (para 5-1).


- E**
1. Remove powerpack (para 4-1).
  2. Reconnect battery ground lead (para 8-33).
  3. Place gear selector in neutral (TM 9-2350-314-10).
  4. Disconnect harness W113 connector P5 from right in-tank fuel pump connector.
  5. Place multimeter red lead in harness W113 connector P5 lead 76 connector socket and black lead on ground.
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



Repair or replace harness W113 (para 8-72).

CONTINUED ON NEXT PAGE



# 3-3 TROUBLESHOOTING CHART - CONTINUED


j. IN-TANK FUEL PUMPS - CONTINUED (1) ELECTRICAL IN-TANK FUEL PUMP FAILS TO OPERATE. Engine misses when low on fuel. - CONTINUED

CONTINUED FROM STEP E

**F**


1. Turn MASTER switch OFF (TM 9-2350-314-10).
2. Check for continuity by placing one multimeter lead in harness W113 connector P5 GND socket and other lead to ground.

Is continuity present?



Repair or replace harness W113 (para 8-72).

Replace right in-tank fuel pump (para 5-1).



06ph266t

END OF TASK

### 3-3 TROUBLESHOOTING CHART - CONTINUED

#### k. LIGHTS

The vehicle lighting system consists of left/right headlight assemblies, left/right taillight assemblies, stoplight switch, dimmer switch, dome light, driver's night vision unit, and light switch assembly.

Driver's instrument panel lights consist of: HIGH BEAM indicator light, GLOW PLUG WAIT light, PARKING BRAKE light, and one panel light for illumination of speedometer and tachometer.

Portable instrument panel lights consist of: master indicator light, MASTER WARNING light, LOW COOLANT light, and two panel lights for illumination of the portable instrument panel.

Lights associated with the accessory control box consist of HEATER indicator light, LEAD FILTER CHANGE indicator light, EXHAUST indicator light, and two panel lights for illumination of the accessory control box panel face.

Miscellaneous lighting consists of a master indicator light located on the steering shaft and another on the enclosure assembly in the crew compartment. The MCS heater (M3) is equipped with an on/off indicator light.

The travel lock control box consists of an ON indicator light, R/U light (raise/unlock) and L/L light (lower/lock).

Lighting on the voltage regulator control box consists of a VOLT REG OFF light.

Refer to HULL ELECTRICAL SCHEMATIC (FP-1 through FP-11/(FP-12 blank)) for the relationship of the lighting systems and individual components. ■

When the vehicle MASTER switch is turned ON, 24 V dc is supplied through the master relay to the circuit breaker panel. Circuit breakers numbered 1, 2, 4, and 6 distribute voltage to various lamps, LEDs, and controlling switches.




### 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (1) ALL ENGINE MASTER WARNING LEDS FAIL TO OPERATE WITH MASTER SWITCH ON. All gages operate.

**INITIAL SETUP**

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)                  Air intake grille open (TM 9-2350-314-10)</p> <p><u>Personnel Required</u>                  Two</p>
--	--

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W114 connector P1 from harness W105 connector J1 at driver's compartment bulkhead.
  3. Check for continuity by placing one multimeter lead in socket N of harness W105 and other lead to ground.
- Is continuity present?



CONTINUED ON NEXT PAGE


06ph127t

# 3-3 TROUBLESHOOTING CHART - CONTINUED



k. LIGHTS - CONTINUED (1) ALL ENGINE MASTER WARNING LEDS FAIL TO OPERATE WITH MASTER SWITCH ON. All gages operate. - CONTINUED

CONTINUED FROM STEP A

- B**
1. Reconnect harness W114 connector P1 to harness W105 connector J1.
  2. Disconnect harness W105 connector P1 from harness W104 connector J1 at engine disconnect bracket.
  3. Check for continuity by placing one multimeter lead on pin K of harness W104 connector J1 and the other lead to ground.
- Is continuity present?



CONTINUED ON NEXT PAGE



W104  
CONNECTOR J1  
PIN K

06ph128t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (1) ALL ENGINE MASTER WARNING LEDS FAIL TO OPERATE WITH MASTER SWITCH ON. All gages operate. - CONTINUED

CONTINUED FROM STEP B




- C**
1. Remove driver's compartment engine access cover (para 16-7).
  2. Disconnect harness W104 lead 509B from engine oil pressure switch and lead 509C from the transmission oil pressure switch.
  3. One at a time, connect a jumper from harness W104 lead 509B and 509C to ground.
  4. Check for continuity of each lead by placing one multimeter lead on pin K of harness W104 connector J1 and the other lead to ground.

Is continuity present with either check?



If continuity is present on lead 509B replace engine oil pressure switch (para 8-47). If continuity is present on lead 509C replace transmission oil pressure switch (para 8-46).

END OF TASK



06ph129t




# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (2) PORTABLE INSTRUMENT PANEL MASTER WARNING LED FAILS TO OPERATE. Other warning lights operate properly.


**INITIAL SETUP**

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Portable instrument panel cover removed (para 8-14)</p> <p><u>Personnel Required</u>                  Two</p>
--	---


- A**
1. Remove bulb from MASTER warning LED (para 8-14).
  2. Place multimeter red lead on center contact of light socket and black lead on ground.
  3. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



- B**
1. Disconnect harness W112 leads 27/509 at master warning LED.
  2. Place one multimeter lead in harness W112 lead 509 and other lead to ground.
  3. Check for continuity.



CONTINUED ON NEXT PAGE



06ph130t




# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (2) PORTABLE INSTRUMENT PANEL MASTER WARNING LED FAILS TO OPERATE. Other warning lights operate properly. - CONTINUED

CONTINUED FROM STEP B

- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Place multimeter red lead in harness W112 lead 27 socket and black lead to ground.
  3. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.




Is voltage present?



CONTINUED FROM STEP B

- D**
1. Reconnect harness W112 leads 27/509 to master warning LED.
  2. Disconnect harness W112 connector P1 from harness W114 J1.
  3. Place one multimeter lead in socket P of harness W114 J1 and other lead to ground.
  4. Check for continuity.

Is continuity present?



END OF TASK

06ph148t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (3) STEERING SHAFT MASTER WARNING LIGHT FAILS TO OPERATE. Other MASTER warning lights operate properly.



**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

- A**
1. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  2. Press to test bulb.



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W114 lead 27 from steering shaft MASTER warning light.
  3. Place multimeter red lead in harness W114 lead 27 connector socket and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



06ph149t



CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (3) STEERING SHAFT MASTER WARNING LIGHT FAILS TO OPERATE. Other MASTER warning lights operate properly. - CONTINUED

CONTINUED FROM STEP A or B

- |                     |  |
|---------------------|--|
| <b>C</b>            | <ol style="list-style-type: none"> <li>1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).</li> <li>2. Disconnect harness W114 lead 509 from steering shaft MASTER warning light.</li> <li>3. Place multimeter red lead in harness W114 lead 509 connector socket and black lead on ground.</li> <li>4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.</li> </ol> |
| Is voltage present? |  |



06ph158t

**END OF TASK**

# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (4) CREW COMPARTMENT MASTER WARNING LIGHT FAILS TO OPERATE. Other MASTER warning lights operate properly.

**INITIAL SETUP**


Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

Personnel Required  
 Two

**A**

1. Remove bulb from crew compartment MASTER warning light (para 8-21).
2. Place multimeter red lead on center contact in light socket and black lead on ground.
3. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.


Is voltage present?




**B**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W114 connector P2 from crew compartment MASTER warning light.
3. Place multimeter red lead on harness W114 connector P2 socket A and black lead on ground.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE





### 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (4) CREW COMPARTMENT MASTER WARNING LIGHT FAILS TO OPERATE. Other MASTER warning lights operate properly. - CONTINUED

CONTINUED FROM STEP A or B

- |                        |   |
|------------------------|---|
| <b>C</b>               | <ol style="list-style-type: none"> <li>1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).</li> <li>2. Place one multimeter lead in harness W114 connector P2 socket C and other lead on ground.</li> <li>3. Check for continuity.</li> </ol> |
| Is continuity present? |   |



06ph151t

**END OF TASK**

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (5) CREW COMPARTMENT MASTER WARNING LIGHT FAILS TO OPERATE WITH COOLANT LIGHT ON.

**INITIAL SETUP**





Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

Personnel Required  
 Two

- A**
1. Remove cover and bulb from crew compartment warning light (para 8-21).
  2. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  3. Place multimeter red lead in the center of light socket and place black lead on ground.
  4. Check for voltage.



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W114 connector P2 from crew compartment MASTER warning light connector.
  3. Place multimeter red lead on harness W114 connector P2 pin B and place black lead on ground.
  4. Check for continuity.



06ph152t

### 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (6) MASTER WARNING LIGHTS FAIL TO OPERATE WHEN ENGINE IS OVERHEATED.



<b>INITIAL SETUP</b>	
<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Engine and transmission access doors open (TM 9-2350-314-10)</p> <p><u>Personnel Required</u>                  Two</p>

**NOTE**

Engine coolant temperature switch will close at 220° F to 230° F (104° C to 110° C) and will reopen when temperature goes below 220° F (104° C).

1. Disconnect harness W104 lead 509A from engine coolant temperature switch, harness W104 lead 509B from engine oil pressure switch, harness W104 lead 509C from transmission oil pressure switch, and harness W104 lead 509D from transmission oil temperature switch.
2. Place a jumper lead from harness W104 lead 509A socket to ground.
3. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and observe MASTER warning light.

Does MASTER warning light operate?



06ph153t

**END OF TASK**



# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (7) MASTER WARNING LIGHTS FAIL TO OPERATE WHEN TRANSMISSION OVERHEATS.



<b>INITIAL SETUP</b>	
<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long test leads may be needed for some tests. 16 AWG wire may be used as an extension.)</p>	<p><u>Equipment Conditions</u>                  Engine and transmission access doors open (TM 9-2350-314-10)</p> <p><u>Personnel Required</u>                  Two</p>

**NOTE**

Transmission oil temperature switch will close at 300° F to 310° F (148° C to 154° C) and will re-open at 295° F (146° C).

1. Disconnect harness W104 lead 509A from engine coolant temperature switch, harness W104 lead 509B from engine oil pressure switch, harness W104 lead 509C from transmission oil pressure switch, and harness W104 lead 509D from transmission oil temperature switch.
2. Place a jumper lead from harness W104 lead 509D lead socket to ground.
3. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and observe MASTER warning lights.

Do MASTER warning lights operate?



**END OF TASK**

06ph154 t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (8) MASTER WARNING LIGHTS CONTINUE TO OPERATE WITH ENGINE OPERATING PROPERLY.

<b>INITIAL SETUP</b>	
<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long test leads may be needed for some tests. 16 AWG wire may be used as an extension.)</p>	<p><u>Equipment Conditions</u>                  Air intake grille open (TM 9-2350-314-10)                  Transmission access doors open (TM 9-2350-314-10)                  Fan protective screens installed (para 4-1c)</p>


**WARNING**

Protective fan screens must be installed prior to doing maintenance in the engine compartment when the engine is running or engine is in ground hop mode. Contact with rotating fan can cause injury.

**A**

1. Start engine (TM 9-2350-314-10).
2. With engine running, disconnect harness W104 lead 509A at engine coolant temperature switch.


Do MASTER warning lights go out?




**B**

1. Reconnect harness W104 lead 509A to engine coolant temperature switch.
2. Shut off engine (TM 9-2350-314-10).
3. Disconnect harness W104 lead 509B from engine oil pressure switch.
4. Start engine (TM 9-2350-314-10).

Do MASTER warning lights go out?



CONTINUED ON NEXT PAGE



06ph155t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (8) MASTER WARNING LIGHTS CONTINUE TO OPERATE WITH ENGINE OPERATING PROPERLY. - CONTINUED

CONTINUED FROM STEP B

**C**

1. Shut off engine (TM 9-2350-314-10).
2. Reconnect harness W104 lead 509B to engine oil pressure switch.
3. Start engine (TM 9-2350-314-10).
4. Disconnect harness W104 lead 509C from transmission oil pressure switch.


Do MASTER warning lights go out?



**D**


1. Reconnect harness W104 lead 509C to transmission oil pressure switch.
2. Disconnect harness W104 lead 509D from transmission oil temperature switch.
3. Shut off engine (TM 9-2350-314-10).

Do MASTER warning lights go out?



Check circuit 509 for shorts to ground. Repair or replace as required.

END OF TASK



06ph156t


### 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (9) ENGINE LOW LEVEL COOLANT WARNING LIGHT FAILS TO LIGHT WHEN ENGINE COOLANT LEVEL IS LOW. Operates press-to-test.

<p><b>INITIAL SETUP</b></p> <p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long test leads may be needed for some tests.                  16 AWG wire may be used as an extension)</p> <p><u>Equipment Conditions</u>                  Air intake grille open (TM 9-2350-314-10)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)                  Portable instrument panel removed (TM 9-2350-314-10)</p> <p><u>Personnel</u>                  Two</p>
--	--


- A**
1. Make sure engine is not running and vehicle MASTER switch is in the OFF position (TM 9-2350-314-10).
  2. Disconnect harness W104 lead 352B from the engine aeration detector.
  3. Place a jumper lead from harness W104 lead 352B to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and observe engine low level coolant warning light.

Does light come on?




- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove jumper from harness W104 lead 352B.
  3. Disconnect harness W105 connector P1 from harness W104 connector J1.
  4. Check harness W104 lead 352B for continuity by placing one multimeter lead in harness W104 lead 352B connector and other lead in harness W104 connector J1 pin A.

Is continuity present?



CONTINUED ON NEXT PAGE



06ph159t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (9) ENGINE LOW LEVEL COOLANT WARNING LIGHT FAILS TO LIGHT WHEN ENGINE COOLANT LEVEL IS LOW. Operates press-to-test. - CONTINUED

CONTINUED FROM STEP B

**C**

1. Reconnect lead 352B to aeration detector lead connector.
2. Disconnect harness W114 connector P1 from harness W105 connector J1.
3. Check lead 352B for continuity by placing one multimeter lead in harness W105 connector P1 socket A and other lead in harness W105 connector J1 socket A.


Is continuity present?




**D**

1. Reconnect harness W105 connector P1 to harness W104 connector J1.
2. Disconnect harness W112 connector P1 from harness W114 connector J1.
3. Check lead 352B for continuity by placing one multimeter lead on harness W114 connector P1 pin A and other lead in harness W114 connector J1 socket B.

Is continuity present?



CONTINUED ON NEXT PAGE



06ph160


# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (9) ENGINE LOW LEVEL COOLANT WARNING LIGHT FAILS TO LIGHT WHEN ENGINE COOLANT LEVEL IS LOW. Operates press-to-test. - CONTINUED

CONTINUED FROM STEP D





- E**
1. Reconnect harness W114 connector P1 to harness W105 connector J1.
  2. Remove portable instrument panel front cover for access to harness W112 lead 352B.
  3. Disconnect harness W112 lead 352B from low level coolant warning light lead connector.
  4. Check lead 352B for continuity by placing one multimeter lead on harness W112 connector P1 pin B and other lead in harness W112 lead 352B connector socket.

Is continuity present?



- F**
1. Reconnect harness W112 connector P1 to harness W114 connector J1.
  2. Place a jumper lead from low level coolant warning light lead 352B connector pin to ground.
  3. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and observe low level coolant warning light.

Does low level coolant warning light come on?



06ph161t

END OF TASK


# 3-3 TROUBLESHOOTING CHART - CONTINUED

**k. LIGHTS - CONTINUED** **(10) ENGINE LOW LEVEL COOLANT LIGHT FAILS TO LIGHT WHEN PRESSED TO TEST. All other lights operate.**


INITIAL SETUP

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long test leads may be needed for some tests. 16 AWG wire may be used as an extension.)</p>	<p><u>Equipment Conditions</u>                  Air intake grille open (TM 9-2350-314-10)                  Transmission access doors open (TM 9-2350-314-10)                  Portable instrument panel removed (para 8-14)</p> <p><u>Personnel Required</u>                  Two</p>
--	---


- A**
1. Make sure engine is not running and vehicle MASTER switch is in OFF position (TM 9-2350-314-10).
  2. Disconnect W104 lead 352A from aeration lead 352A connector.
  3. Place a jumper lead from W104 lead 352A connector socket to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and press low level coolant light to test.





Does engine low level coolant light come on?



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove portable instrument panel front cover for access to harness W112 lead 27.
  3. Disconnect harness W112 lead 27 from low level coolant light lead connector.
  4. Place multimeter red lead in harness W112 lead 27 connector socket and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



Is voltage present?



CONTINUED ON NEXT PAGE


06ph166t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (10) ENGINE LOW LEVEL COOLANT LIGHT FAILS TO LIGHT WHEN PRESSED TO TEST. All other lights operate. - CONTINUED






CONTINUED FROM STEP B

- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W112 lead 27 to coolant light lead connector.
  3. Remove coolant light cover and bulb (para 8-14).
  4. Place multimeter red lead on light socket center contact and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



Replace coolant light bulb (para 8-14). Turn vehicle MASTER switch ON and press-to-test light. If light illuminates, remove jumper lead and reconnect lead 352A at low level coolant detector lead connector.

- D**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W105 connector P1 from harness W104 connector P1.
  3. Remove jumper lead.
  4. Check lead 352A for continuity by placing one multimeter lead in W104 lead 352A connector socket and other lead on harness W104 connector J1 pin B.
- Is continuity present?



06ph165t

CONTINUED ON NEXT PAGE







# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (10) ENGINE LOW LEVEL COOLANT LIGHT FAILS TO LIGHT WHEN PRESSED TO TEST. All other lights operate. - CONTINUED

CONTINUED FROM STEP D

- E**
1. Reconnect lead 352A to low level coolant detector lead connector.
  2. Disconnect harness W114 connector P1 from harness W105 connector J1.
  3. Check lead 352A for continuity by placing one multimeter lead in harness W105 connector P1 socket B and other lead in harness W105 connector J1 socket B.
- Is continuity present?



W105  
CONNECTOR P1  
SOCKET B



W105  
CONNECTOR J1  
SOCKET B








06ph164t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (10) ENGINE LOW LEVEL COOLANT LIGHT FAILS TO LIGHT WHEN PRESSED TO TEST. All other lights operate. - CONTINUED

CONTINUED FROM STEP E

- F**
1. Reconnect harness W105 connector P1 to harness W104 connector J1.
  2. Disconnect harness W112 connector P1 from harness W114 connector J1.
  3. Check lead 352A for continuity by placing one multimeter lead on harness W114 connector P1 pin B and other lead in harness W114 connector J1 socket C.
- Is continuity present?




06ph163t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (10) ENGINE LOW LEVEL COOLANT LIGHT FAILS TO LIGHT WHEN PRESSED TO TEST. All other lights operate. - CONTINUED

CONTINUED FROM STEP F


- G**
1. Reconnect harness W114 connector P1 to harness W105 connector J1.
  2. Disconnect harness W112 lead 352A from coolant light lead 352A connector.
  3. Check lead 352A for continuity by placing one multimeter lead on harness W112 connector P1 pin C and other lead in harness W112 lead 352A socket.
- Is continuity present?



- H**
1. Reconnect harness W112 connector P1 to harness W114 connector J1.
  2. Place a jumper lead from coolant light lead 352A connector pin to ground.
  3. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and press light to test.
- Does coolant light come on?



END OF TASK



### 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (11) GLOW PLUG WAIT LIGHT DOES NOT ILLUMINATE. Engine starts and all other electrical accessories operate properly.

**INITIAL SETUP**



Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

Equipment Conditions  
 Air intake grille open (TM 9-2350-314-10)  
 Transmission access doors open (TM 9-2350-314-10)

- A**
1. Remove LED from glow plug WAIT light on instrument panel (TM 9-2350-314-10).
  2. Place red multimeter lead in glow plug WAIT light socket and black lead to ground.
  3. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  4. Turn GLOW PLUG ENABLE switch ON (TM 9-2350-314-10).
  5. Check for voltage.
- Is voltage present?



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Place LED back in glow plug WAIT light (TM 9-2350-314-10).
  3. Remove driver's instrument panel (para 8-12).
  4. Disconnect lead 486 from back of glow plug WAIT light.
  5. Place red multimeter lead in lead 486 socket and black lead to ground.
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  7. Turn GLOW PLUG ENABLE switch ON (TM 9-2350-314-10).
  8. Check for voltage.
- Is voltage present?



06ph167t


CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (11) GLOW PLUG WAIT LIGHT DOES NOT ILLUMINATE. Engine starts and all other electrical accessories operate properly. - CONTINUED

CONTINUED FROM STEP B


- C**
1. Turn GLOW PLUG ENABLE switch OFF (TM 9-2350-314-10).
  2. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  3. Disconnect harness W114 connector P1 from driver's bulkhead connector.
  4. Place one multimeter lead on pin R of harness W114 connector P1 and other lead on socket lead 486 at WAIT light.
  5. Check for continuity.
  6. Place one multimeter lead on pin C of harness W114 connector P1 and other lead on socket lead 486A at GLOW PLUG ENABLE switch.
  7. Check for continuity.
- Is continuity present at both leads?



- D**
1. Disconnect harness W105 connector P1 from engine disconnect bracket.
  2. Place one multimeter lead in socket O of harness W105 connector P1 and other lead in socket R of harness W105 connector J1 at driver's bulkhead.
  3. Check for continuity.
  4. Place one multimeter lead in socket C of harness W105 connector P1 and other lead in socket C of harness W105 connector J1 at driver's bulkhead.
  5. Check for continuity.
- Is continuity present at both points?



CONTINUED ON NEXT PAGE




06ph168t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (11) GLOW PLUG WAIT LIGHT DOES NOT ILLUMINATE.  
 Engine starts and all other electrical accessories operate properly. - CONTINUED

CONTINUED FROM STEP D

- E**
1. Disconnect harness W104 connector P2 from glow plug controller.
  2. Place one multimeter lead in sockets A and C (one at a time) of harness W104 connector P2 and other lead on pin O of harness W104 connector J1 at engine disconnect bracket.
  3. Check for continuity.
  4. Place one multimeter lead in socket B of harness W104 connector P2 and other lead on pin C of harness W104 connector J1 at engine disconnect bracket.
  5. Check for continuity.
- Is continuity present at all three points?



END OF TASK



06ph169t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (12) MASTER SWITCH INDICATOR LIGHT FAILS TO OPERATE. Vehicle MASTER switch ON.



**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect any disconnected leads.
  3. Remove vehicle MASTER switch indicator LED (para 8-14).
  4. Place multimeter red lead on light socket center contact and ground black lead.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove portable instrument panel front cover (para 8-14).
  3. Disconnect harness W112 lead 459L from vehicle MASTER switch warning lamp assembly.
  4. Place multimeter red lead on harness W112 lead 459L and place black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?




CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (12) MASTER SWITCH INDICATOR LIGHT FAILS TO OPERATE. Vehicle MASTER switch ON. - CONTINUED

CONTINUED FROM STEP B

- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W112 lead 459L to lamp assembly.
  3. Install portable instrument panel cover (para 8-14).
  4. Disconnect harness W112 connector P1 from harness W114 connector P2.
  5. Place one lead of multimeter on harness W112 connector P1 pin W and place the other lead on harness W112 connector P1 pin L.
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for continuity.
- Is continuity present?



END OF TASK



06ph171t




# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (13) HIGH BEAM INDICATOR LIGHT FAILS TO OPERATE.

**INITIAL SETUP**  
**Tools**  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)


- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove high beam indicator light cover and LED (para 8-12).
  3. Ensure that light switch is set to service drive and headlights are on high beam.
  4. Place multimeter red lead in high beam indicator light socket and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).





Is voltage present?



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 connector P4 from dimmer switch.
  3. Remove dimmer switch for access to pins (para 8-27).
  4. Place one multimeter lead on dimmer switch pin C and other lead on headlight dimmer switch pin D. Check for continuity.
  5. Place one multimeter lead on headlight dimmer switch pin G and other lead on dimmer switch pin H. Check for continuity.
- NOTE:** If reading is not obtained, depress and release dimmer switch button.



Is continuity indicated?



CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (13) HIGH BEAM INDICATOR LIGHT FAILS TO OPERATE. - CONTINUED

CONTINUED FROM STEP B

**NOTE**  
 There are two leads 519 connected to the high beam indicator light. One lead is for service drive high beam and the other is for I.R. high beam.

- C**
1. Disconnect harness W115 leads 519 from high beam indicator light.
  2. Place one multimeter lead in harness W115 connector P4 socket D and other lead in harness W115 lead 519 socket. Check for continuity.
  3. Place one multimeter lead in harness W115 connector P4 socket H and other lead in harness W115 lead 519 socket. Check for continuity.


Is continuity indicated?



Repair or replace harness W115 (para 8-74).

Replace high beam indicator light assembly (para 8-12).

END OF TASK



06ph173t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (14) PARKING BRAKE INDICATOR LIGHT FAILS TO OPERATE. Parking brake set.


**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)


Equipment Conditions  
 Driver's instrument panel cover removed (para 8-14)

Personnel Required  
 Two



- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove parking brake light bulb
  3. Place multimeter red lead on light socket center contact and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W114 lead 509E from parking brake light.
  3. Place multimeter red lead on harness W114 lead 509E connector pin and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



CONTINUED ON NEXT PAGE



06ph174t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (14) PARKING BRAKE INDICATOR LIGHT LEAD FAILS TO OPERATE. Parking brake set. - CONTINUED

CONTINUED FROM STEP B


- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove driver's instrument panel from mounting for access to wiring (para 8-14).
  3. Disconnect harness W120 lead 509E from harness W114 lead 509E.
  4. Place multimeter red lead in harness W120 lead 509E connector socket and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?





- D**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W114 lead 509E to harness W120 lead 509E.
  3. Disconnect harness W114 leads 509E from parking brake warning switch.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  5. Place multimeter black lead to ground and red lead in harness W114 leads 509E connector pins (one at a time). Check for voltage.

Is voltage present on one of the 509E leads?



CONTINUED ON NEXT PAGE




06ph175t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (14) PARKING BRAKE INDICATOR LIGHT FAILS TO OPERATE. Parking brake set. - CONTINUED

CONTINUED FROM STEP D

- E**
1. Ensure parking brake is still set (TM 9-2350-314-10).
  2. Check continuity of parking brake warning switch by placing one multimeter lead in one parking brake warning switch connector and other lead in parking brake warning switch connector socket.
- Is continuity present?



END OF TASK



PARKING BRAKE WARNING SWITCH

06ph176t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (15) PERSONNEL HEATER INDICATOR LED FAILS TO OPERATE PRESS-TO-TEST OR HEATER OPERATING.

**INITIAL SETUP**

Tools  
 General mechanic's tool kit  
 (SC 5180-90-N26)



- A**
1. Remove press-to-test heater indicator LED on accessory control box (TM 9-2350-314-10).
  2. Place multimeter red lead on light socket center contact and black lead on ground.
  3. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  4. Check for voltage.

Is voltage present?




- B**
- Replace indicator LED and press-to-test heater indicator light on accessory control box (TM 9-2350-314-10).

Does indicator LED come on?



Note: For vehicles with Accessory Control Box P/N 12268582



Note: For vehicles with Accessory Control Box P/N 12268547

06ph177ta

**END OF TASK**

### 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (16) SERVICE DRIVE LIGHTS FAIL TO OPERATE.


**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)  
 (Long test leads may be needed for some tests. 16 AWG wire may be used as an extension.)



Equipment Conditions  
 Driver's instrument panel removed (para 8-12)

Personnel Required  
 Two

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 lead 15 from harness W124 lead 10.
  3. Place multimeter red lead in harness W124 lead 10 connector socket and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W115 lead 15 to harness W124 lead 10.
  3. Disconnect harness W115 connector P3 from light switch connector.
  4. Place multimeter red lead in harness W115 connector P3 socket F and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.




06ph178t

# 3-3 TROUBLESHOOTING CHART - CONTINUED





k. LIGHTS - CONTINUED (17) HEADLIGHTS FAIL TO OPERATE. All other lights operate.

<p><b>INITIAL SETUP</b></p> <p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long test leads may be needed for some tests.                  16 AWG wire may be used as an extension.)</p>	<p><u>Equipment Conditions</u>                  Driver's instrument panel removed (para 8-12)</p> <p><u>Personnel Required</u>                  Two</p>
---	---


- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 connector P3 from light switch.
  3. Turn light switch to service drive (TM 9-2350-314-10).
  4. Place one multimeter lead on light switch pin F and other lead on light switch pin M. Check for continuity.



- B**
1. Reconnect harness W115 connector P3 to light switch.
  2. Disconnect harness W115 connector P4 from dimmer switch.
  3. Ensure light switch is turned to service drive (TM 9-2350-314-10).
  4. Place multimeter red lead in harness W115 connector P4 socket G and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



MAIN LIGHT SWITCH  
PIN F  
PIN M



W115  
CONNECTOR P4  
SOCKET G

06ph179t

CONTINUED ON NEXT PAGE



# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (17) HEADLIGHTS FAIL TO OPERATE. All other lights operate. - CONTINUED

CONTINUED FROM STEP B

**C**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Place one multimeter lead on headlight dimmer switch pin G and other lead on headlight dimmer switch pins E and F (one at a time). Check for continuity.
3. Depress headlight dimmer switch and repeat step 2.



Is continuity present on one pin before headlight dimmer switch is depressed and on other pin after depressed?



**D**

1. Disconnect harness W115 connector P1 from harness W113 connector J1.
2. Place one multimeter lead in harness W115 connector P4 socket F and other lead in harness W115 connector P1 socket B. Check continuity.
3. Place one multimeter lead in harness W115 connector P4 socket E and other lead in harness W115 connector P1 socket C. Check for continuity.

Is continuity present?




CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (17) HEADLIGHTS FAIL TO OPERATE. All other lights operate. - CONTINUED

CONTINUED FROM STEP D


- E**
1. Reconnect harness W115 connector P4 to headlight dimmer switch and W115 connector P1 to driver's bulkhead connector.
  2. Disconnect harness W113 leads 17 from both headlight mount lead 17 connectors.
  3. Ensure main light switch is turned to service drive (TM 9-2350-314-10).
  4. Place multimeter red lead in harness W113 lead 17 sockets (one at a time) and black lead to ground.
  5. Turn vehicle MASTER switch ON and headlight dimmer switch to HIGH BEAM (high beam indicator light on) (TM 9-2350-314-10).
  6. Check for voltage.
- Is voltage present at both lead 17 connector sockets?



- F**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W113 leads 17 to both headlight mount lead 17 connectors.
  3. Disconnect harness W113 leads 18 from both headlight mount lead 18 connectors.
  4. Place multimeter red lead in harness W113 lead 18 connector sockets (one at a time) and black lead to ground.
  5. Turn vehicle MASTER switch ON and headlight dimmer switch to LOW BEAM position (high beam indicator light not lit) (TM 9-2350-314-10).
  6. Check for voltage.
- Is voltage present at both lead 18 connector sockets?



CONTINUED ON NEXT PAGE



06ph181t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (17) HEADLIGHTS FAIL TO OPERATE. All other lights operate. - CONTINUED

CONTINUED FROM STEP F


- G**
1. Depress headlight dimmer switch for high beam.
  2. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  3. Reconnect harness W113 leads 18 to both headlight mount lead 18 connectors.
  4. Remove both headlight assemblies from headlight mount assemblies (para 8-35).
  5. Place multimeter red lead in both headlight mounts socket B (one at a time) and black lead on ground.
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  7. Check for voltage.

Is voltage present at both headlight mounts?





- H**
1. Place headlight dimmer switch in LOW BEAM position (high beam indicator light not lit) (TM 9-2350-314-10).
  2. Place multimeter red lead in both headlight mount sockets A (one at a time) and black lead to ground.
  3. Check for voltage.

Is voltage present at both headlight mounts?



CONTINUED ON NEXT PAGE




06ph182t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (17) HEADLIGHTS FAIL TO OPERATE. All other lights operate. - CONTINUED

CONTINUED FROM STEP H


- I**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Check lead 91 for continuity by placing one multimeter lead in both headlight mounts socket C one at a time and other lead on ground.
- Is continuity present?



- J**
1. Remount headlight assemblies to headlight mounting assemblies (para 8-35).
  2. Remove service drive seal beam (para 8-35).
  3. Place multimeter black lead to ground and red lead in light connector sockets (one at a time) until a voltage reading is obtained at both headlights.
  4. Turn vehicle MASTER switch ON and place headlight dimmer switch to HIGH BEAM (high beam indicator light lit) (TM 9-2350-314-10).
- Is voltage present at one socket?



CONTINUED ON NEXT PAGE



06ph183t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (17) HEADLIGHTS FAIL TO OPERATE. All other lights operate. - CONTINUED

CONTINUED FROM STEP J

**K**

1. Place headlight dimmer switch to LOW BEAM (high beam indicator light not lit) (TM 9-2350-314-10).
2. Place multimeter black lead to ground and red lead in light connector sockets (one at a time) until a voltage reading is obtained at both headlights.


Is voltage present at one socket of each light?




**L**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Place one multimeter lead on ground and other lead in each light connector socket (one at a time). Check for continuity.

Is continuity present?



END OF TASK




# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (18) TAILLIGHT FAILS TO OPERATE. All other lights operate.

**INITIAL SETUP**  
**Tools**  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)


- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove service taillight bulb (para 8-37).
  3. Place multimeter red lead on light socket center contact and black lead on ground.
  4. Turn vehicle MASTER switch ON and light switch to SERVICE DRIVE (TM 9-2350-314-10).
  5. Check for voltage.



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 connector P3 from light switch.
  3. Ensure light switch is in SERVICE DRIVE (TM 9-2350-314-10).
  4. Check light switch for continuity by placing one multimeter lead on pin F and other lead on pin H.



CONTINUED ON NEXT PAGE



06ph185t



# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (18) TAILLIGHT FAILS TO OPERATE. All other lights operate. - CONTINUED

CONTINUED FROM STEP B

- C**
1. Reconnect harness W115 connector P3 to light switch.
  2. Remove wiring harness hull rear access cover (para 8-102).
  3. Disconnect harness W115 lead 21 from taillight harness W115 lead 21 connector.
  4. Place multimeter red lead in harness W115 lead 21 connector socket and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



06ph186t

END OF TASK


# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (19) STOPLIGHT FAILS TO OPERATE. All other lights operate.



**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Ensure brake pedal is depressed and locked (TM 9-2350-314-10).
  3. Ensure light switch is in STOPLIGHT or SERVICE DRIVE position (TM 9-2350-314-10).
  4. Remove stoplight bulb (para 8-37).
  5. Place multimeter red lead on stoplight socket center contact and black lead to ground.
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove driver's instrument panel (para 8-12).
  3. Disconnect harness W115 connector P3 from light switch.
  4. Ensure light switch is set for STOPLIGHT or SERVICE DRIVE (TM 9-2350-314-10).
  5. Make the following continuity checks on light switch:
    - a. Place one multimeter lead on pin F and other lead on pin A.
    - b. Place one multimeter lead on pin C and other lead on pin K.



06ph187t



# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (19) STOPLIGHT FAILS TO OPERATE. All other lights operate. - CONTINUED

CONTINUED FROM STEP B

**C**

1. Disconnect harness W115 leads 75 from stoplight switch.
2. Place one multimeter lead in harness W115 connector P3 socket A and other lead in harness W115 lead 75 socket. Check for continuity.
3. Place one multimeter lead in other harness W115 lead 75 socket and other lead in harness W115 connector P3 socket K. Check for continuity.


Is continuity present?




**D**

1. Reconnect harness W115 connector P3 to main light switch.
2. Place one multimeter lead on one stoplight switch pin and other lead on other stoplight switch pin. Check for continuity.

Is continuity present?



CONTINUED ON NEXT PAGE





06ph188t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (19) STOPLIGHT FAILS TO OPERATE. All other lights operate. - CONTINUED

CONTINUED FROM STEP D

- E**
1. Reconnect harness W115 leads 75 to stoplight switch connectors.
  2. Remove wiring harness hull rear access cover (para 8-102).
  3. Disconnect harness W115 lead 22 from left taillight connector.
  4. Place multimeter red lead in harness W115 lead 22 connector socket and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



06ph189t

END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (20) FRONT BLACKOUT (BO) MARKER LEDS FAIL TO OPERATE.


**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)  
 (Long test leads may be needed for some tests. 16 AWG wire may be used as an extension.)


Personnel Required  
 Two

**NOTE**  
 Both right and left front blackout marker LEDs are checked in the same manner.




- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove BO marker LEDs (para 8-34).
  3. Ensure light switch is set to BO marker (TM 9-2350-314-10).
  4. Place multimeter red lead on light socket center contact and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove driver's instrument panel (para 8-12).
  3. Disconnect harness W115 connector P3 from light switch.
  4. Place one multimeter lead on pin F of light switch and other lead on pin E of light switch. Check for continuity.
- Is continuity present?



CONTINUED ON NEXT PAGE



06ph190t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (20) FRONT BLACKOUT (BO) MARKER LEDS FAIL TO OPERATE. - CONTINUED.

CONTINUED FROM STEP B

**C**

1. Disconnect harness W115 connector P1 from harness W113 connector J1.
2. Place one multimeter lead on harness W115 connector P3 socket E and other lead on W115 connector P1 socket D. Check for continuity.


Is continuity present?




**D**

1. Reconnect harness W115 connector P3 to main light switch and W115 connector P1 to harness W113 connector J1.
2. Disconnect harness W113 lead 20 from headlight mount lead 20 connector.
3. Place multimeter red lead in harness W113 lead 20 connector socket and black lead on ground.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE



06ph191t




# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (20) FRONT BLACKOUT (BO) MARKER LEDS FAIL TO OPERATE. - CONTINUED

CONTINUED FROM STEP D

- E**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W113 lead 20 to headlight mount lead 20 connector.
  3. Remove headlight assembly from headlight mount assembly (para 8-35).
  4. Place multimeter red lead in headlight mount socket F and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



06ph192t

END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (21) REAR BLACKOUT (BO) MARKERS, LEDS FAIL TO OPERATE. All other lights operate.


**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)



Equipment Conditions  
 Driver's instrument panel removed (para 8-12)  
 Wiring harness access cover (right only) removed (para 8-102)  
 Wiring harness access cover (left only) removed (para 8-102)

**NOTE**  
 Both right and left rear blackout marker LEDs are checked in the same manner.

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove BO marker LED (para 8-37).
  3. Make sure light switch is set to BO marker (TM 9-2350-314-10).
  4. Place multimeter red lead on BO light socket center contact and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 connector P3 from light switch.
  3. Place one multimeter lead on light switch pin F and other lead on light switch pin E. Check for continuity.




CONTINUED ON NEXT PAGE

### 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (21) REAR BLACKOUT (BO) MARKERS LEDS FAIL TO OPERATE. All other lights operate. - CONTINUED

CONTINUED FROM STEP B

- C**
1. Reconnect harness W115 connector P3 to light switch.
  2. Disconnect harness W115 lead 24 from taillight lead 24 connector.
  3. Place multimeter red lead in harness W115 lead 24 connector socket and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



END OF TASK




06ph194t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (22) BLACKOUT (BO) DRIVE LIGHT FAILS TO OPERATE.

<p><u>INITIAL SETUP</u></p> <p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long test leads may be needed for some tests.                  16 AWG wire may be used as an extension.)</p>	<p><u>Equipment Conditions</u>                  Driver's instrument panel cover removed (para 8-12)</p> <p><u>Personnel Required</u>                  Two</p>
---	---


- A**
1. Turn vehicle MASTER switch OFF. (TM 9-2350-314-10).
  2. Remove blackout drive light bulb (para 8-37).
  3. Make sure that light switch is set to BO (TM 9-2350-314-10).
  4. Place multimeter red lead on light socket center contact and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 connector P3 from light switch.
  3. Place one multimeter lead on light switch pin F and other lead on light switch pin D. Check for continuity.



CONTINUED ON NEXT PAGE






# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (22) BLACKOUT (BO) DRIVE LIGHT FAILS TO OPERATE. - CONTINUED

CONTINUED FROM STEP B


- C**
1. Reconnect harness W115 connector P3 to light switch.
  2. Disconnect harness W115 lead 520 from three-way connector from behind driver's instrument panel.
  3. Place multimeter red lead in harness W115 lead 520 connector socket and black lead on ground.
  4. Make sure light switch is set to BO drive (TM 9-2350-314-10).
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



- D**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 connector P1 from harness W113 connector J1 and W115 lead 19 from three-way connector.
  3. Place one multimeter lead in harness W115 connector P1 socket A and other lead in harness W115 lead 19. Check for continuity.



CONTINUED ON NEXT PAGE




# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (22) BLACKOUT (BO) DRIVE LIGHT FAILS TO OPERATE. - CONTINUED

CONTINUED FROM STEP D


- E**
1. Reconnect harness W115 connector P1 to harness W113 connector J1 and harness W115 lead 19 and 520 to three-way connector.
  2. Disconnect harness W113 lead 19 from left headlight mount lead 19 connector.
  3. Place multimeter red lead in harness W113 lead 19 connector socket and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.




Is voltage present?



- F**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W113 leads 19 to left headlight mount lead 19 connector.
  3. Remove left headlight assembly from headlight mount assembly (para 8-36).
  4. Place multimeter red lead in headlight mount connector socket G and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



Is voltage present?



Repair or replace left headlight assembly (para 8-35).

END OF TASK

06ph196t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (23) BLACKOUT (BO) STOPLIGHT LED FAILS TO OPERATE. All other lights operate.

**INITIAL SETUP**



Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

Equipment Conditions  
 Driver's instrument panel removed (para 8-12)

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove blackout stoplight LED (para 8-37).
  3. Ensure that light switch is set to BO MARKER or BO DRIVE and that brake pedal is depressed and locked (TM 9-2350-314-10).
  4. Place multimeter red lead on light socket center contact and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 connector P3 from light switch.
  3. Make the following continuity checks at main light switch.
    - a. Place one multimeter lead on pin F and other lead on pin A.
    - b. Place one multimeter lead on pin K and other lead on pin N.
- Is continuity present?



06ph197t

CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (23) BLACKOUT (BO) STOPLIGHT LED FAILS TO OPERATE. All other lights operate. - CONTINUED

CONTINUED FROM STEP B

**C**

1. Disconnect harness W115 leads 75 from stoplight switch.
2. Make the following continuity checks:
  - a. Place one multimeter lead in harness W115 connector P3 socket A and other lead in two harness W115 lead 75 connector sockets (one at a time).
  - b. Place one multimeter lead in harness W115 connector P3 socket K and other lead in other harness W115 lead 75 connector sockets (one at a time).


Is continuity present?





**D**

1. Reconnect harness W115 connector P3 to light switch.
2. Ensure that brake pedal is depressed and locked (TM 9-2350-314-10).
3. Place one multimeter lead on one pin of stoplight switch connector pin and other lead on other stoplight switch connector pin. Check for continuity.

Is continuity present?



CONTINUED ON NEXT PAGE



06ph198t



# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (23) BLACKOUT (BO) STOPLIGHT LED FAILS TO OPERATE. All other lights operate. - CONTINUED

CONTINUED FROM STEP D

- E**
1. Reconnect harness W115 leads 75 to stoplight switch.
  2. Remove wiring harness hull rear access cover (para 8-102).
  3. Disconnect harness W115 lead 23 from right taillight lead 23 connector.
  4. Place multimeter red lead in harness W115 lead 23 connector socket and black lead on ground.
  5. Ensure light switch is set to BO marker or BO drive (TM 9-2350-314-10).
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



06ph199t

END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (24) ALL INSTRUMENT PANEL LIGHTS FAIL TO OPERATE. All other lights operate.


**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)


Equipment Conditions  
 Driver's instrument panel removed (para 8-12)

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W115 connector P3 from light switch.
3. Ensure light switch is in any position except OFF and auxiliary light switch is set to panel bright (BRT) or DIM (TM 9-2350-314-10).
4. Place one multimeter lead on light switch pin F and other lead on light switch pin B. Check for continuity.

Is continuity present?



END OF TASK



06ph200t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (25) DRIVER'S INSTRUMENT PANEL LIGHTS FAIL TO OPERATE. All other lights operate

**INITIAL SETUP**



Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

Equipment Conditions  
 Driver's instrument panel removed (para 8-12)

- A**
1. Remove driver's instrument panel light bulb (para 8-12).
  2. Ensure that light switch is in any position but OFF and AUXILIARY LIGHT switch is set to BRT or DIM (TM 9-2350-314-10).
  3. Place multimeter red lead on light socket center contact and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 lead 40 from panel light connector.
  3. Place multimeter red lead in harness W115 lead 40 connector pin and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



END OF TASK

06ph201t

### 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (26) PORTABLE INSTRUMENT PANEL LIGHTS FAIL TO OPERATE. All other lights operate

**INITIAL SETUP**


<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Portable instrument panel removed from driver's instrument panel (TM 9-2350-314-10)</p>
--	---

**NOTE**


Both portable instrument panel lights are checked in the same manner.

- A**
1. Remove portable instrument panel light bulb (TM 9-2350-314-10).
  2. Place multimeter red lead on light socket center contact black lead on ground.
  3. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE



06ph202t




# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (26) PORTABLE INSTRUMENT PANEL LIGHTS FAIL TO OPERATE. All other lights operate - CONTINUED

CONTINUED FROM STEP A

- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W112 connector P1 from harness W114 connector J1.
  3. Remove cover from portable instrument panel (para 8-14).
  4. Disconnect harness W112 lead 40 from portable instrument panel light.
  5. Place multimeter lead on harness W112 connector P1 pin R and other lead on harness W112 lead 40 connector pin. Check for continuity.
- Is continuity present?



CONTINUED ON NEXT PAGE



06ph203t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (26) PORTABLE INSTRUMENT PANEL LIGHTS FAIL TO OPERATE. All other lights operate - CONTINUED

CONTINUED FROM STEP B

- C**
1. Reconnect harness W112 lead 40 in portable instrument panel light.
  2. Install cover on portable instrument panel (para 8-14).
  3. Remove driver's instrument panel (para 8-12).
  4. Disconnect harness W114 lead 40 from harness W119 three-way connector.
  5. Place one multimeter lead in W114 connector J1 socket R and other lead in harness W114 lead 40 connector socket. Check for continuity.

Is continuity present?


yes

no

Repair or replace harness W114 (para 8-73).

Replace panel light assembly (para 8-14).

END OF TASK



06ph204t

# 3-3 TROUBLESHOOTING CHART - CONTINUED



k. LIGHTS - CONTINUED (27) ACCESSORY CONTROL BOX LEDS FAIL TO OPERATE. All other lights operate

**INITIAL SETUP**


Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

**NOTE**  
 Both accessory control box panel LEDs are checked in the same manner.

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Remove panel LED (TM 9-2350-314-10).
  3. Place multimeter red lead on LED socket center contact and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
  5. Turn vehicle light switch to panel light position (TM 9-2350-314-10) and check for voltage.



Note: For vehicles with Accessory Control Box P/N 12268582



Note: For vehicles with Accessory Control Box P/N 12268547


06ph205tc

# 3-3 TROUBLESHOOTING CHART - CONTINUED




k. LIGHTS - CONTINUED (27) ACCESSORY CONTROL BOX LEDS FAIL TO OPERATE. All other lights operate - CONTINUED

CONTINUED FROM STEP A

- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W119 connector P1 from accessory control box connector J1.
  3. Place multimeter red lead on harness W119 connector P1 pin D and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W119 connector P1 to accessory control box connector J1.
  3. Remove driver's instrument panel (para 8-12).
  4. Disconnect harness W115 lead 40 from three-way connector.
  5. Place multimeter red lead on harness W115 lead 40 connector socket and black lead on ground.
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



END OF TASK

06ph206t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (28) DOME LIGHT FAILS TO OPERATE. All other lights operate.

**INITIAL SETUP**



Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

**NOTE**  
 Move dome light switch to both positions. If dome light comes on in one position, go to step F.

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 lead 38 from dome light three-way connector.
  3. Place multimeter red lead in W115 lead 38 connector socket and black lead on ground.
  3. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 lead 37/38 from circuit breaker no. 6.
  3. Place multimeter lead in harness W115 lead 38 at dome light and other multimeter lead in lead 37/38 at circuit breaker no. 6. Check for continuity.



06ph207t

CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (28) DOME LIGHT FAILS TO OPERATE. All other lights operate. CONTINUED

CONTINUED FROM STEP B


- C**
1. Disconnect harness W125 lead 7 from dome light (para 8-38).
  2. Place multimeter lead on harness W125 lead 7 at dome light and other lead to ground.
  3. Check for continuity.

Is continuity present?






- D**
1. Reconnect harness W125 lead 7 to dome light (para 8-38).
  2. Reconnect harness W115 lead 37/38 to circuit breaker no. 6 and lead 38 at dome light.
  3. Disconnect harness W124 lead 10 from circuit breaker no. 6.
  4. Place multimeter red lead in harness W124 lead 10 connector socket and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



Replace circuit breaker no. 6 (para 8-20).



06ph208t

CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (28) DOME LIGHT FAILS TO OPERATE. All other lights operate. CONTINUED




CONTINUED FROM STEP A

- E**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W115 lead 38 to dome light three-way connector.
  3. Remove dome light door (para 8-38).
  4. Place multimeter red lead on switch power in terminal and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE




06ph209t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


k. LIGHTS - CONTINUED (28) DOME LIGHT FAILS TO OPERATE. All other lights operate. CONTINUED

CONTINUED FROM STEP E

- F**
1. Turn dome light switch to white light position (TM 9-2350-314-10).
  2. With multimeter black lead grounded, place red lead on switch terminal 1 and check for voltage.
  3. Turn dome light switch to BO light position (TM 9-2350-314-10).
  4. Place multimeter red lead on switch terminal 2 and check for voltage.
- Is voltage present?



CONTINUED ON NEXT PAGE



06ph210t




# 3-3 TROUBLESHOOTING CHART - CONTINUED




k. LIGHTS - CONTINUED (28) DOME LIGHT FAILS TO OPERATE. All other lights operate. - CONTINUED

CONTINUED FROM STEP F

- G**
1. Turn dome light switch OFF (TM 9-2350-314-10).
  2. Remove bulbs from BO and white light sockets (para 8-38).
  3. Check for voltage by placing multimeter red lead on light socket center contact and black lead on ground.
  4. Turn dome light switch to BO light position and check BO light socket for voltage (TM 9-2350-314-10).
  5. Turn dome light switch to white light position (TM 9-2350-314-10) and check white light socket for voltage.



END OF TASK



06ph211t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

k. LIGHTS - CONTINUED (29) DRIVER'S NIGHT VIEWER FAILS TO OPERATE.


**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W118 connector P1 from driver's night viewer device.
3. Place multimeter red lead on harness W118 connector P1 socket A and black lead on socket B.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.



**END OF TASK**



06ph212t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

## I. NATO SLAVE RECEPTACLE

The NATO slave receptacle is located in the driver's compartment. When a slave cable is connected between the NATO slave receptacles on two vehicles, one vehicle can power the other vehicle's system. With the vehicle MASTER switch set to ON in the master vehicle and the vehicle MASTER switch set to SLAVE in the slaved vehicle, 24 V dc is supplied to the slaved vehicle's master relay, energizing it, which supplies voltage to the batteries and starting system.

The external power receptacle is located at the right rear of the vehicle. This receptacle is used to provide power to the cab from another vehicle by connecting a slave cable to both vehicles' external power receptacles, and turning the other vehicle's MASTER switch to ON.

The diagram below shows the connection to the NATO slave and external power receptacles.



06ph215t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

I. NATO SLAVE RECEPTACLE - CONTINUED (1) NO POWER TO SLAVED VEHICLE'S SLIP RING FROM NATO SLAVE RECEPTACLE. Slaved vehicle had power when operating.


**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)

**A**

1. Disconnect NATO slave cable from disabled vehicle.
2. Place multimeter red lead on slave cable center contact and black lead to outer contact. Check for voltage.
3. Turn slaving POWER ON and check for voltage.


Is voltage present?



**B**

1. Reconnect NATO slave cable to disabled vehicle. Ensure NATO slave cable is fully seated in NATO slave receptacle.
2. Place multimeter red lead on NATO slave receptacle on W124 positive terminal and black lead on W116 negative terminal.

Is voltage present?




**C**

1. Disconnect NATO slave cable from disabled vehicle.
2. Place one multimeter lead on NATO slave receptacle negative terminal and other lead on ground.

Is continuity present?

CONTINUED ON NEXT PAGE




06ph216t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


I. NATO SLAVE RECEPTACLE - CONTINUED (1) NO POWER TO SLAVED VEHICLE'S SLIP RING FROM NATO SLAVE RECEPTACLE. Slaved vehicle had power when operating. - CONTINUED

CONTINUED FROM STEP C





**D** 1. Reconnect NATO slave cable to disabled vehicle. Ensure NATO slave cable is fully seated in NATO slave receptacle.  
 2. Check harness W117 wire 10 for voltage by placing multimeter red lead on harness W117 E7/E8 or E5/E6 and black lead to ground.

Is voltage present?



Repair or replace harness W117 (para 8-76).

CONTINUED ON NEXT PAGE




06ph079t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

I. NATO SLAVE RECEPTACLE - CONTINUED (1) NO POWER TO SLAVED VEHICLE'S SLIP RING FROM NATO SLAVE RECEPTACLE. Slaved vehicle had power when operating. - CONTINUED


CONTINUED FROM STEP C

- E**
1. Disconnect NATO slave cable from disabled vehicle.
  2. Disconnect battery grounds from ground bus in battery compartment (para 8-33).
  3. Disconnect harnesses W116 lead 7 connector terminals E3, E4, E5, E6, E7, E8 (para 8-75) and W125 lead 7 connector terminal E12 (para 8-83).
  4. Check each connector terminal (one at a time) except W125 lead 7 for continuity by placing one multimeter lead in connector terminal and placing other multimeter lead to ground.
- Is continuity present?



1. Reconnect harnesses W116 lead 7 connector terminals E3, E4, E5, E6, E7, E8 (para 8-75) and W125 lead 7 connector terminal E12 (para 8-83).
2. Reconnect battery grounds to ground bus in battery compartment (para 8-33).
3. Refer to TM 9-2350-314-20-2.

END OF TASK



# 3-3 TROUBLESHOOTING CHART - CONTINUED

I. NATO SLAVE RECEPTACLE - CONTINUED (2) BATTERIES FAIL TO RECHARGE WHEN VEHICLE IS SLAVED. All other electrical components operate.

**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)


Equipment Conditions  
 Transmission access doors open  
 (TM 9-2350-314-10)

Personnel Required  
 Two

**A**

- Place MASTER switch to SLAVE and hold (TM 9-2350-314-10).
- Place multimeter red lead on lead 81 connector terminal A1 at MASTER relay and black lead to ground.
- Check for voltage.


Is a voltage of approximately 28 V dc present?




**B**

- Loosen two screws and rotate cover to right (para 8-22).
- Place multimeter red lead on lead 459 connector terminal X1 at master relay and black lead to ground.

Is a voltage of approximately 28 V dc present?



CONTINUED ON NEXT PAGE





06ph217t



# 3-3 TROUBLESHOOTING CHART - CONTINUED

- |                                      |   |
|--------------------------------------|---|
| I. NATO SLAVE RECEPTACLE - CONTINUED | (2) BATTERIES FAIL TO RECHARGE WHEN VEHICLE IS SLAVED. All other electrical components operate. - CONTINUED |
|--------------------------------------|---|

CONTINUED FROM STEP B



CONTINUED FROM STEP B



06ph218t

CONTINUED ON NEXT PAGE




# 3-3 TROUBLESHOOTING CHART - CONTINUED

- I. NATO SLAVE RECEPTACLE - CONTINUED
- (2) BATTERIES FAIL TO RECHARGE WHEN VEHICLE IS SLAVED. All other electrical components operate. - CONTINUED

CONTINUED FROM STEP D


- E**
1. Disconnect harness W112 connector P1 from harness W114 connector J1.
  2. Check harness W114 lead 459A for continuity by placing one multimeter lead in harness W114 lead 459A pin and placing the other lead in harness W114 connector J1 socket V.

Is continuity present?







- F**
1. Reconnect harness W114 lead 459A to harness W120 lead 459A connector.
  2. Place MASTER switch to SLAVE and hold (TM 9-2350-314-10).
  3. Check harness W112 for continuity by placing one multimeter lead on harness W112 connector P1 pin V and placing the other lead on pin W.


Is continuity present?



CONTINUED ON NEXT PAGE



W112 CONNECTOR P1 PIN V & PIN W



W114 CONNECTOR J1 SOCKET V

06ph219t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


- |                                      |   |
|--------------------------------------|---|
| I. NATO SLAVE RECEPTACLE - CONTINUED | (2) BATTERIES FAIL TO RECHARGE WHEN VEHICLE IS SLAVED. All other electrical components operate. - CONTINUED |
|--------------------------------------|---|

CONTINUED FROM STEP F

**G**

1. Remove driver's portable instrument panel cover (para 8-14).
2. Disconnect harness W112 lead 459A from MASTER switch connector.
3. Check harness W112 lead 459A for continuity by placing one multimeter lead in harness W112 lead 459A and placing the other lead on harness W112 connector P1 pin V.


Is continuity present?









**H**

1. Disconnect harness W112 lead 459 from MASTER switch.
2. Check harness W112 lead 459 for continuity by placing one multimeter lead on harness W112 lead 459 connector socket and placing the other lead on harness W112 connector P1 pin W.

Is continuity present?



CONTINUED ON NEXT PAGE




# 3-3 TROUBLESHOOTING CHART - CONTINUED

I. NATO SLAVE RECEPTACLE - CONTINUED (2) BATTERIES FAIL TO RECHARGE WHEN VEHICLE IS SLAVED. All other electrical components operate. - CONTINUED

CONTINUED FROM STEP H

- I**
1. Place and hold the MASTER switch in the SLAVE position (TM 9-2350-314-10).
  2. Check the MASTER switch for continuity by placing one multimeter lead in switch connector for harness W112 lead 459 and placing the other lead in switch connector for harness W112 lead 459A.


Is continuity present?




CONTINUED FROM STEP F

- J**
1. Install cover on driver's portable instrument panel.
  2. Disconnect harness W114 lead 459 from harness W115 lead 459.
  3. Check harness W114 lead 459 for continuity by placing one multimeter lead in harness W114 connector J1 socket W and placing the other lead in harness W114 lead 459 connector.

Is continuity present?



CONTINUED ON NEXT PAGE



06ph221t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


- I. NATO SLAVE RECEPTACLE - CONTINUED
- (2) BATTERIES FAIL TO RECHARGE WHEN VEHICLE IS SLAVED. All other electrical components operate. - CONTINUED

CONTINUED FROM STEP J


**K**

1. Disconnect harness W115 connector P1 from harness W113 connector J1.
2. Check harness W115 for continuity by placing one multimeter lead in harness W115 connector P1 socket Q and other lead in harness W115 lead 459 connector socket.

Is continuity present?



END OF TASK




# 3-3 TROUBLESHOOTING CHART - CONTINUED

I. NATO SLAVE RECEPTACLE - CONTINUED (3) NO POWER TO VEHICLE'S SLIP RING FROM EXTERNAL POWER RECEPTACLE.



**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

- A**
1. Disconnect slave cable from disabled vehicle.
  2. Place multimeter red lead on slave cable center contact and black lead to outer contact.
  3. Turn slaving power ON and check for voltage.



- B**
1. Disconnect slave cable from disabled vehicle.
  2. Disconnect battery ground from ground bus located in battery compartment (para 8-33).
  3. Remove external power receptacle guard (para 8-92).
  4. Reconnect battery ground to ground bus located in battery compartment (para 8-33).
  5. Reconnect NATO slave cable to disabled vehicle. Make sure cable is fully seated in the external power receptacle.
  6. Place multimeter red lead on external power receptacle positive terminal and black lead on negative terminal. Check for voltage.



CONTINUED ON NEXT PAGE

06ph223t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


I. NATO SLAVE RECEPTACLE - CONTINUED                      (3) NO POWER TO VEHICLE'S SLIP RING FROM EXTERNAL POWER RECEPTACLE. - CONTINUED

CONTINUED FROM STEP B




- C**

  1. Disconnect NATO slave cable from disabled vehicle.
  2. Disconnect battery ground from ground bus located in battery compartment (para 8-33).
  3. Disconnect leads 49B from left and 49A at right rear positive (+) ring segments.
  4. Check leads one at a time from lead terminal connector to positive (+) bus bar.

Are bus bars and leads securely attached?



CONTINUED ON NEXT PAGE



06ph224t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


I. NATO SLAVE RECEPTACLE - CONTINUED                      (3) NO POWER TO VEHICLE'S SLIP RING FROM EXTERNAL POWER RECEPTACLE. - CONTINUED

CONTINUED FROM STEP C

**D**

1. Disconnect lead 49B from left segment board and the external power receptacle.
2. Check lead for continuity by placing one multimeter lead on lead wire E1-49B and other lead on wire E2-49B.
3. Check lead 49B for continuity by placing one multimeter lead on lead wire E3-49B and other lead on wire E4-49B.

Is continuity present at both points?




Replace lead assembly (para 8-88).


**E** Perform a shorts test (para 3-1.3) on lead 49B by placing one multimeter lead on point one and other lead on point two.

POINT ONE	POINT TWO	DO NOT CHECK
E1-49B	E3-49B, E4-49B	E2-49B
E2-49B	E3-49B, E4-49B	E1-49B
E3-49B	E3-49B, E4-49B	E4-49B
E4-49B	E1-49B, E2-49B	E3-49B

Are any shorts present?



Replace lead assembly (para 8-88).



CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


I. NATO SLAVE RECEPTACLE - CONTINUED                      (3) NO POWER TO VEHICLE'S SLIP RING FROM EXTERNAL POWER RECEPTACLE. - CONTINUED

CONTINUED FROM STEP E

**F**

1. Disconnect lead 49A from right segment board and external power receptacle.
2. Check lead 49A for continuity by placing one multimeter lead on wire E1-49A and other lead on wire E2-49A.
3. Check lead 49A for continuity by placing one multimeter lead on lead wire E3-49A and other lead on wire E4-49A.


Is continuity present at both points?




**G** Perform a shorts test (para 3-1.3) on lead 49A by placing one multimeter lead on point one and other lead on point two.

POINT ONE	POINT TWO	DO NOT CHECK
E1-49A	E3-49A, E4-49A	E2-49A
E2-49A	E3-49A, E4-49A	E1-49A
E3-49A	E3-49A, E4-49A	E4-49A
E4-49A	E1-49A, E2-49A	E3-49A

Are any shorts present?



CONTINUED ON NEXT PAGE





# 3-3 TROUBLESHOOTING CHART - CONTINUED


I. NATO SLAVE RECEPTACLE - CONTINUED (3) NO POWER TO VEHICLE'S SLIP RING FROM EXTERNAL POWER RECEPTACLE. - CONTINUED

CONTINUED FROM STEP G

**H**

1. Disconnect lead 50A from right segment board and external power receptacle.
2. Check lead 50A for continuity by placing one multimeter lead on wire E1-50A and other lead on wire E2-50A.
3. Check lead 50A for continuity by placing one multimeter lead on lead wire E3-50A and other lead on wire E4-50A.




Is continuity present at both points?



**I** Perform a shorts test (para 3-1.3) on lead 50A by placing one multimeter lead on point one and other lead on point two.

POINT ONE	POINT TWO	DO NOT CHECK
E1-50A	E3-50A, E4-50A	E2-50A
E2-50A	E3-50A, E4-50A	E1-50A
E3-50A	E3-50A, E4-50A	E4-50A
E4-50A	E1-50A, E2-50A	E3-50A

Are any shorts present?



CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

I. NATO SLAVE RECEPTACLE - CONTINUED                      (3) NO POWER TO VEHICLE'S SLIP RING FROM EXTERNAL POWER RECEPTACLE. - CONTINUED

CONTINUED FROM STEP I

- J**
1. Disconnect lead 50B from right segment board and external power receptacle.
  2. Check lead 50B for continuity by placing one multimeter lead on lead wire E1-50B and other lead on wire E2-50B.
  3. Check lead 50B for continuity by placing one multimeter lead on lead wire E3-50B and other lead on wire E4-50B.


Is continuity present?



- K**
- Perform a shorts test (para 3-1.3) on lead 50B by placing one multimeter lead on point one and other lead on point two.


POINT ONE	POINT TWO	DO NOT CHECK
E1-50B	E3-50B, E4-50B	E2-50B
E2-50B	E3-50B, E4-50B	E1-50B
E3-50B	E1-50B, E2-50B	E4-50B
E4-50B	E1-50B, E2-50B	E3-50B

Are any shorts present?



- L**
1. Reconnect leads 49A, 49B, 50A, 50B at segment boards and external power receptacle (para 8-87, 8-88, 8-89, and 8-90).
  2. Reconnect battery ground at ground bus located in battery compartment (para 8-33).
  3. Refer to TM 9-2350-314-20-2.

**END OF TASK**




06ph228t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

## m. PERSONNEL HEATER (For vehicles with Accessory Control Box P/N 12268582)

The personnel heater system consists of the personnel heater, accessory control box, and heater fuel pump. The diagram below shows the relationship of these components.

When the vehicle MASTER switch is turned ON, 24 V dc is supplied to the accessory control panel. When the HEAT SELECTOR SWITCH is turned to LOW, voltage is applied to the heater fuel pump and personnel heater. After approximately 3 minutes, the heater indicator light will illuminate to indicate the heater is operating properly.



06ph358t

### 3-3 TROUBLESHOOTING CHART - CONTINUED

m. PERSONNEL HEATER - CONTINUED (1) PERSONNEL HEATER FAILS TO OPERATE. Other electrical components operate.


**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

Personnel Required  
 Two

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W124 P1 lead 10 from accessory control box connector.
  3. Place multimeter red lead on harness W124 P1 lead 10 connector socket and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.


Is voltage present?





**WARNING**  
 Harness W119 connector at lead 400 accessory control box has battery voltage if batteries are connected. Use care when removing connector to avoid electrical shock and burns.

- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W119 connector P1 from accessory control box connector J1.
  3. Place multimeter red lead on harness W119 connector P1 pin A and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  5. Check for voltage.



Is voltage present?



CONTINUED ON NEXT PAGE



ACCESSORY CONTROL BOX



W119 CONNECTOR P1 PIN A


06ph214t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

m. PERSONNEL HEATER - CONTINUED (1) PERSONNEL HEATER FAILS TO OPERATE. Other electrical components operate. - CONTINUED






CONTINUED FROM STEP B

- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W119 lead 400 from harness W114 lead 400 connector.
  3. Place multimeter red lead in harness W114 lead 400 connector socket and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  5. Check for voltage.
- Is voltage present?



CONTINUED FROM STEP B

- D**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W124 P1 lead 10 to accessory control box connector.
  3. Turn heater selector switch to LOW or HIGH (TM 9-2350-314-10).
  4. Place multimeter red lead in accessory control box connector socket C and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  6. Check for voltage.
- Is voltage present?



06ph229t

CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

m. PERSONNEL HEATER - CONTINUED (1) PERSONNEL HEATER FAILS TO OPERATE. Other electrical components operate. - CONTINUED

CONTINUED FROM STEP D



**E**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Make the following continuity checks of harness W119:



Disconnect harness W119 connector P4 from personnel heater and and:

- a. Place one multimeter lead on connector P1 pin B and other lead in connector P4 socket B.
- b. Place one multimeter lead on connector P1 pin C and other lead in connector P4 socket C.
- c. Place one multimeter lead on connector P1 pin E and other lead in connector P4 socket D.
- d. Place one multimeter lead on connector P1 pin F and other lead in connector P4 socket E.
- e. Place one multimeter lead on control box ground terminal and other lead in connector P4 socket A.

Is continuity present?



<p>W119 CONNECTOR P4 SOCKET B (SOCKET C) (SOCKET D) (SOCKET E) (SOCKET A)</p>	<p>W119 CONNECTOR P1 PIN B (PIN C) (PIN E) (PIN F)</p>
---	--



**END OF TASK**

06ph230t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

m. PERSONNEL HEATER - CONTINUED (2) HEATER MOTOR RUNS BUT HEATER FAILS TO OPERATE. Sufficient fuel is in tank.

**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)


- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W119 lead 402A from heater fuel pump connector.
  3. Place multimeter red lead in harness W119 lead 402A connector socket and black lead to ground.
  4. Make sure HEAT selector switch is on (HIGH or LOW) (TM 9-2350-314-10).
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?





**WARNING**

Do not use open flame or smoke when working on the fuel system; an explosion may occur, causing severe injury or death.

- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W119 lead 402A to heater fuel pump.
  3. Disconnect fuel line from heater fuel pump at fuel filter (para 18-8).
  4. Place fuel line in suitable container to catch fuel.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
- Is fuel pumped into container?



CONTINUED ON NEXT PAGE





22ph002t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

m. PERSONNEL HEATER - CONTINUED (2) HEATER MOTOR RUNS BUT HEATER FAILS TO OPERATE. Sufficient fuel is in tank. - CONTINUED


CONTINUED FROM STEP B

- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect heater fuel pump inlet fuel line from quick-disconnect.
  3. Place line in suitable container of fuel.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
- Is fuel pumped from container?



CONTINUED FROM STEP B

- D**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect fuel line from fuel pump to fuel filter.
  3. Disconnect fuel line at personnel heater (para 18-9).
  4. Place line in suitable container to catch fuel.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
- Is fuel pumped into container?



END OF TASK



# 3-3 TROUBLESHOOTING CHART - CONTINUED


m. PERSONNEL HEATER - CONTINUED (3) HEATER WILL NOT STOP RUNNING WITH SWITCH OFF. All other electrical components operate properly.

**INITIAL SETUP**  
**Tools**  
 General mechanic's tool kit (SC 5180-90-N26)


**WARNING**  
 If heater is blowing hot air, do not disconnect any electrical leads to the heater. An explosion may occur causing severe injury or death.

1. If heater continues to blow hot air after switch is turned off and after cool down period has elapsed (one to two minutes), go to heater fuel pump and disconnect harness W119 lead 402A.
2. When heater blows cool air, turn vehicle MASTER switch OFF (TM 9-2350-314-10).

Does heater motor continue to operate?



**END OF TASK**




# 3-3 TROUBLESHOOTING CHART - CONTINUED

## m.1 PERSONNEL HEATER (For vehicles with Accessory Control Box P/N 12268547)

The personnel heater system consists of the personnel heater, accessory control box, and heater fuel pump. The diagram below shows the relationship of these components.

When the vehicle MASTER switch is turned ON, 24 V dc is supplied to the accessory control panel. When the HEAT SELECTOR SWITCH is turned to LOW, voltage is applied to the heater fuel pump and personnel heater. After approximately 3 minutes, the heater indicator light will illuminate to indicate the heater is operating properly.



Ø6ph359ta

# 3-3 TROUBLESHOOTING CHART - CONTINUED


m.1 PERSONNEL HEATER - CONTINUED (1) PERSONNEL HEATER FAILS TO OPERATE. Other electrical components operate.

**INITIAL SETUP**


Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

Personnel Required  
 Two

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W124 P1 lead 10 from accessory control box connector.
  3. Place multimeter red lead on harness W124 P1 lead 10 connector socket and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.






Is voltage present?




**WARNING**  
 Harness W119 connector at lead 400 accessory control box has battery voltage if batteries are connected. Use care when removing connector to avoid electrical shock and burns.

- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W119 connector P1 from accessory control box connector J1.
  3. Place multimeter red lead on harness W119 connector P1 pin A and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  5. Check for voltage.



Is voltage present?






CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

m.1 PERSONNEL HEATER - CONTINUED (1) PERSONNEL HEATER FAILS TO OPERATE. Other electrical components operate. - CONTINUED



CONTINUED FROM STEP B

- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W119 lead 400 from harness W114 lead 400 connector.
  3. Place multimeter red lead in harness W114 lead 400 connector socket and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  5. Check for voltage.
- Is voltage present?



CONTINUED FROM STEP B

- D**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W124 P1 lead 10 to accessory control box connector.
  3. Turn HEATER switch to START or RUN (TM 9-2350-314-10).
  4. Place multimeter red lead in accessory control box connector socket C and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  6. Check for voltage.
- Is voltage present?



06ph229ta

CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

m.1 PERSONNEL HEATER - CONTINUED (1) PERSONNEL HEATER FAILS TO OPERATE. Other electrical components operate. - CONTINUED

CONTINUED FROM STEP D



**E**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Make the following continuity checks of harness W119:

Disconnect harness W119 connector P4 from personnel heater and and:



- a. Place one multimeter lead on connector P1 pin B and other lead in connector P4 socket B.
- b. Place one multimeter lead on connector P1 pin C and other lead in connector P4 socket C.
- c. Place one multimeter lead on connector P1 pin E and other lead in connector P4 socket D.
- d. Place one multimeter lead on connector P1 pin F and other lead in connector P4 socket E.
- e. Place one multimeter lead on control box ground terminal and other lead in connector P4 socket A.

Is continuity present?



W119 CONNECTOR P4  
SOCKET B  
(SOCKET C)  
(SOCKET D)  
(SOCKET E)  
(SOCKET A)

W119 CONNECTOR P1  
PIN B  
(PIN C)  
(PIN E)  
(PIN F)



ACCESSORY CONTROL BOX  
GROUND TERMINAL

END OF TASK

06ph230ta


# 3-3 TROUBLESHOOTING CHART - CONTINUED

m.1 PERSONNEL HEATER - CONTINUED (2) HEATER MOTOR RUNS BUT HEATER FAILS TO OPERATE. Sufficient fuel is in tank.

**INITIAL SETUP**

Tools  
 General mechanic's tool kit  
 (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)




- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W119 lead 402A from heater fuel pump connector.
  3. Place multimeter red lead in harness W119 lead 402A connector socket and black lead to ground.
  4. Make sure HEATER control switch is on (START or RUN) (TM 9-2350-314-10).
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



**WARNING**

Do not use open flame or smoke when working on the fuel system; an explosion may occur, causing severe injury or death.

- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect harness W119 lead 402A to heater fuel pump.
  3. Disconnect fuel line from heater fuel pump at fuel filter (para 18-8).
  4. Place fuel line in suitable container to catch fuel.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
- Is fuel pumped into container?



22ph002t


CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

m.1 PERSONNEL HEATER - CONTINUED (2) HEATER MOTOR RUNS BUT HEATER FAILS TO OPERATE. Sufficient fuel is in tank. - CONTINUED


CONTINUED FROM STEP B

- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect heater fuel pump inlet fuel line from quick-disconnect.
  3. Place line in suitable container of fuel.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
- Is fuel pumped from container?




CONTINUED FROM STEP B

- D**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect fuel line from fuel pump to fuel filter.
  3. Disconnect fuel line at personnel heater (para 18-9).
  4. Place line in suitable container to catch fuel.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
- Is fuel pumped into container?



END OF TASK



22ph001

# 3-3 TROUBLESHOOTING CHART - CONTINUED


m.1 PERSONNEL HEATER - CONTINUED (3) HEATER WILL NOT STOP RUNNING WITH SWITCH OFF. All other electrical components operate properly.

**INITIAL SETUP**  
**Tools**  
 General mechanic's tool kit (SC 5180-90-N26)


**WARNING**  
 If heater is blowing hot air, do not disconnect any electrical leads to the heater. An explosion may occur causing severe injury or death.

1. If heater continues to blow hot air after switch is turned off and after cool down period has elapsed (one to two minutes), go to heater fuel pump and disconnect harness W119 lead 402A.
2. When heater blows cool air, turn vehicle MASTER switch OFF (TM 9-2350-314-10).

Does heater motor continue to operate?



**END OF TASK**






# 3-3 TROUBLESHOOTING CHART - CONTINUED

## n. PERSONNEL VENTILATION BLOWER AND LEAD FILTER FAN (For vehicles with Accessory Control Box P/N 12268582)

This system consists of the personnel vent fan, the lead filter fan, and the accessory control box. The diagram below shows the relationship of these components.

When vehicle MASTER switch is turned ON, 24 V dc is supplied from the batteries through the master relay to the accessory control box. When the ventilation blower switch is set to EXHAUST, voltage is applied to energize the personnel vent fan in either a forward or reverse direction. The lead filter fan operates when the vehicle MASTER switch is turned on, supplying power from the batteries, through the master relay to the accessory control box, and the ventilation blower switch is set to INTAKE.



# 3-3 TROUBLESHOOTING CHART - CONTINUED

n. PERSONNEL VENTILATION BLOWER - CONTINUED (1) PERSONNEL VENTILATION BLOWER FAILS TO OPERATE. All other components operate properly.


**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)



**WARNING**

Exercise care to prevent injury, especially to fingers and hands, during maintenance operations on personnel ventilation blower.

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W119 connector P3 from ventilation blower connector.
  3. Turn ventilation blower switch to EXHAUST (TM 9-2350-314-10).
  4. Place multimeter red lead in harness W119 connector P3 socket A and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect W119 connector P2 from accessory control box.
  3. Place red lead of multimeter on socket C of accessory control box and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



CONTINUED ON NEXT PAGE

06ph234t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


n. PERSONNEL VENTILATION BLOWER - CONTINUED (1) PERSONNEL VENTILATION BLOWER FAILS TO OPERATE. All other components operate properly. - CONTINUED

CONTINUED FROM STEP A

**C**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W119 lead 7 from the accessory control box.
3. Place one multimeter lead on lead 7 and place the other lead in socket D of harness W119 connector P3.

Is continuity present?




CONTINUED FROM STEP B


**D**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W124 lead 10 from accessory control box.
3. Place red lead of multimeter in harness W124 lead 10 socket and place the black lead to ground.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Is voltage present?



END OF TASK



06ph246t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

n. LEAD FILTER FAN (2) LEAD FILTER FAN DOES NOT OPERATE. Personnel ventilation fan operates properly.

**INITIAL SETUP**


Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)

Equipment Conditions  
 Vehicle MASTER switch OFF (TM 9-2350-314-10)

**WARNING**  
 Lead filter must be handled in accordance with local SOP complying with Occupational Safety Health Act (OSHA). Dust-sized lead particles are injurious to your health when ingested or absorbed.



- A**
1. Remove fan ground cable from fan and chassis ground (para 8-99).
  2. Place one multimeter lead on one end of ground cable and other lead to other end of ground cable.
  3. Check for continuity.

Is continuity present?



- B**
1. Reconnect ground cable to filter fan and chassis ground (para 8-99).
  2. Disconnect lead 657 connector from fan motor (para 8-98).
  3. Place red multimeter lead on lead 657 connector socket and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  5. Turn fan selector switch to INTAKE (TM 9-2350-314-10).
  6. Check for voltage.

Is voltage present?



06ph235t



CONTINUED ON NEXT PAGE

### 3-3 TROUBLESHOOTING CHART - CONTINUED

n. LEAD FILTER FAN - CONTINUED (2) LEAD FILTER FAN DOES NOT OPERATE. Personnel ventilation fan operates properly. - CONTINUED

CONTINUED FROM STEP B

- C**
1. Turn fan selector switch OFF (TM 9-2350-314-10).
  2. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  3. Reconnect lead 657 to fan motor (para 8-98).
  4. Disconnect lead 657 connector from accessory control box (para 8-98).
  5. Place red multimeter lead on accessory control box connector socket and black lead to ground.
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  7. Turn selector switch to INTAKE (TM 9-2350-314-10).
  8. Check for voltage.
- Is voltage present?



06ph232t


END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED

## n.1 PERSONNEL VENTILATION BLOWER AND LEAD FILTER FAN (For vehicles with Accessory Control Box P/N 12265847)

This system consists of the personnel vent fan, the lead filter fan, and the accessory control box. The diagram below shows the relationship of these components.

When vehicle MASTER switch is turned ON, 24 V dc is supplied from the batteries through the master relay to the accessory control box. When the ventilation blower switch is set to EXHAUST, voltage is applied to energize the personnel vent fan in either a forward or reverse direction. The lead filter fan operates when the vehicle MASTER switch is turned on, supplying power from the batteries, through the master relay to the accessory control box, and the ventilation blower switch is set to INTAKE.



Ø6ph357ta

# 3-3 TROUBLESHOOTING CHART - CONTINUED

n.1 PERSONNEL VENTILATION BLOWER - CONTINUED (1) PERSONNEL VENTILATION BLOWER FAILS TO OPERATE. All other components operate properly.



**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)



**WARNING**

Exercise care to prevent injury, especially to fingers and hands, during maintenance operations on personnel ventilation blower.

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W119 connector P3 from ventilation blower connector.
  3. Turn ventilation blower switch to EXHAUST (TM 9-2350-314-10).
  4. Place multimeter red lead in harness W119 connector P3 socket A and black lead on ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect W119 connector P2 from accessory control box.
  3. Place red lead of multimeter on socket C of accessory control box and black lead on ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10) and check for voltage.
- Is voltage present?



CONTINUED ON NEXT PAGE

06ph234ta


# 3-3 TROUBLESHOOTING CHART - CONTINUED

n.1 PERSONNEL VENTILATION BLOWER - CONTINUED (1) PERSONNEL VENTILATION BLOWER FAILS TO OPERATE. All other components operate properly. - CONTINUED

CONTINUED FROM STEP A

- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W119 lead 7 from the accessory control box.
  3. Place one multimeter lead on lead 7 and place the other lead in socket D of harness W119 connector P3.


Is continuity present?




CONTINUED FROM STEP B

- D**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W124 lead 10 from accessory control box.
  3. Place red lead of multimeter in harness W124 lead 10 socket and place the black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Is voltage present?



END OF TASK



06ph246ta



# 3-3 TROUBLESHOOTING CHART - CONTINUED

n.1 LEAD FILTER FAN (2) LEAD FILTER FAN DOES NOT OPERATE. Personnel ventilation fan operates properly.

**INITIAL SETUP**


Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)

Equipment Conditions  
 Vehicle MASTER switch OFF (TM 9-2350-314-10)

**WARNING**  
 Lead filter must be handled in accordance with local SOP complying with Occupational Safety Health Act (OSHA). Dust-sized lead particles are injurious to your health when ingested or absorbed.



- A**
1. Remove fan ground cable from fan and chassis ground (para 8-99).
  2. Place one multimeter lead on one end of ground cable and other lead to other end of ground cable.
  3. Check for continuity.

Is continuity present?



- B**
1. Reconnect ground cable to filter fan and chassis ground (para 8-99).
  2. Disconnect lead 657 connector from fan motor (para 8-98).
  3. Place red multimeter lead on lead 657 connector socket and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  5. Turn fan selector switch to INTAKE (TM 9-2350-314-10).
  6. Check for voltage.

Is voltage present?



06ph235t



CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

n.1 LEAD FILTER FAN - CONTINUED (2) LEAD FILTER FAN DOES NOT OPERATE. Personnel ventilation fan operates properly. - CONTINUED

CONTINUED FROM STEP B

- C**
1. Turn fan selector switch OFF (TM 9-2350-314-10).
  2. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  3. Reconnect lead 657 to fan motor (para 8-98).
  4. Disconnect lead 657 connector from accessory control box (para 8-98).
  5. Place red multimeter lead on accessory control box connector socket and black lead to ground.
  6. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  7. Turn selector switch to INTAKE (TM 9-2350-314-10).
  8. Check for voltage.



06ph356ta

END OF TASK


# 3-3 TROUBLESHOOTING CHART - CONTINUED

## o. STE DCA CIRCUIT

The Special Test Equipment Diagnostic Connector Assembly (STE DCA) circuit is used in conjunction with Special Test Equipment for Internal Combustion Engines (STE/ICE) when troubleshooting engine or related circuit problems.

When the vehicle MASTER switch is ON, 24 V dc is supplied through the STE DCA and STE cable W1 to the vehicle test meter (VTM). Using multiple types of STE cables and probes, the VTM can conduct a full spectrum of tests on the engine and all its sensors. The pictorial diagram below illustrates the VTM connected to the STE DCA with STE cable W1.

Refer to HULL ELECTRICAL SCHEMATIC (FP-1 through FP-9/FP-10 blank) for the relationship of the STE DCA circuit.



06ph236t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (1) STE FAILS TO GIVE READING (WHILE PERFORMING TEST 10 OR 13). STE passed power-up and confidence tests (para 3-4.a(1)).

**INITIAL SETUP**

Tools  
 General mechanic's tool kit  
 (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)


- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W1 from harness W100 connector J1 (DCA connector).
  3. Disconnect harness W100 connector P3 from pulse tachometer.
  4. Check harness W101 for continuity as follows:
    - a. Place one multimeter lead in harness W100 J1 (DCA connector) socket c and other head on harness W100 connector P3 socket 1.
    - b. Place one multimeter lead in harness W100 connector J1 (DCA connector) socket d and other lead on harness W100 connector P3 pin 2.

Is continuity present?




- B**
1. Reconnect W100 connector P3 to pulse tachometer.
  2. Go to TM 9-4910-571-12&P and troubleshoot STE cable W1.

Is STE cable W1 in good condition?



**END OF TASK**



06ph237t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (2) STE FAILS TO GIVE COMPRESSION UNBALANCE READING (WHILE PERFORMING TEST 14). STE passed power-up and confidence tests (para 3-4.a(1)).

**INITIAL SETUP**


Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

Equipment Conditions  
 Battery compartment access doors open (TM 9-2350-314-10)


- A**
1. Shut engine and vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W1 from harness W100 connector J1.
  3. Disconnect harness W100 connector P1 from harness W101 connector J1.
  4. Check harness W101 for voltage:
    - a. Place multimeter red lead on connector J1 socket r and place black lead to ground.
    - b. Place multimeter red lead on connector J1 socket v and place black lead to ground.
- Is voltage present for both tests?



- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Check harness W101 lead AZ for continuity by placing one multimeter lead on harness W101 connector AZ at battery negative (-) post and other lead in harness W101 connector J1 socket s.
- Is continuity present?



CONTINUED ON NEXT PAGE



# 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (2) STE FAILS TO GIVE COMPRESSION UNBALANCE READING (WHILE PERFORMING TEST 14). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED

CONTINUED FROM STEP B




**C** Make the following continuity checks on harness W100:

- a. Place one multimeter lead on connector P1 pin r and other lead in connector J1 socket V.
- b. Place one multimeter lead on connector P1 pin s and other lead in connector J1 socket W.
- c. Place one multimeter lead on connector P1 pin v and other lead in connector J1 socket E.

Is continuity present?



END OF TASK



# 3-3 TROUBLESHOOTING CHART - CONTINUED



o. STE DCA CIRCUIT - CONTINUED (3) STE FAILS TO GIVE FUEL SUPPLY PRESSURE READING (TEST 24). STE passed power-up and confidence tests (para 3-4.a(1)).

**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

Equipment Conditions  
 Transmission access doors open (TM 9-2350-314-10)

- A**
1. Shut engine and vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W1 from harness W100 connector J1 (DCA connector).
  3. Disconnect harness W101 connector P1 from harness W102 connector J1.
  4. Disconnect harness W102 connector P2 from fuel supply pressure transducer.
  5. Make the following continuity checks on harness W102:
    - a. Place one multimeter lead in connector P2 socket 1 and other lead in connector J1 socket c.
    - b. Place one multimeter lead in connector P2 socket 2 and other lead in connector J1 socket h.
    - c. Place one multimeter lead in connector P2 pin 3 and other lead in connector J1 socket U.
    - d. Place one multimeter lead in connector P2 pin 4 and other lead in connector J1 socket b.



06ph240t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

o. STE DCA CIRCUIT - CONTINUED (3) STE FAILS TO GIVE FUEL SUPPLY PRESSURE READING (TEST 24). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED




CONTINUED FROM STEP A

- B**
1. Reconnect harness W102 connector J1 to fuel supply pressure transducer.
  2. Disconnect harness W100 connector P1 from harness W101 connector J1.
  3. Make the following continuity checks on harness W101:
    - a. Place one multimeter lead in connector P1 pin c and other lead in connector J1 socket C.
    - b. Place one multimeter lead in connector P1 pin h and other lead in connector J1 socket H.
    - c. Place one multimeter lead in connector P1 pin U and other lead in connector J1 socket J.
    - d. Place one multimeter lead in connector P1 pin b and other lead in connector J1 socket P.

Is continuity present?



CONTINUED ON NEXT PAGE





# 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (3) STE FAILS TO GIVE FUEL SUPPLY PRESSURE READING (TEST 24). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED

CONTINUED FROM STEP B

**C**


1. Reconnect harness W101 connector P1 to harness W102 connector J1.
2. Make the following continuity checks on harness W100:
  - a. Place one multimeter lead on connector P1 pin C and other lead in connector J1 socket f.
  - b. Place one multimeter lead on connector P1 pin H and other lead in connector J1 sockets D and g.
  - c. Place one multimeter lead on connector P1 pin J and other lead in connector J1 socket u.
  - d. Place one multimeter lead on connector P1 pin P and other lead in connector J1 socket v.

Is continuity present?




**D** Go to TM 9-4910-571-12&P and troubleshoot STE cable W1.



Is STE cable W1 in good condition?



END OF TASK



W100  
CONNECTOR P1  
PIN C  
PIN H  
PIN J  
PIN P



W100  
CONNECTOR J1  
SOCKET f  
SOCKETS D and g  
SOCKET u  
SOCKET v

06ph242t



# 3-3 TROUBLESHOOTING CHART - CONTINUED

o. STE DCA CIRCUIT - CONTINUED (4) STE FAILS TO GIVE FUEL FILTER DIFFERENTIAL PRESSURE READING (TEST 26). STE passed power-up and confidence tests (para 3-4.a(1)).

**INITIAL SETUP**

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)</p>	<p><u>Equipment Condition</u>                  Transmission access doors open (TM 9-2350-314-10)</p>
	<p><u>Personnel Required</u>                  Two</p>

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W1 from harness W100 connector J1 (DCA connector).
  3. Disconnect harness W101 connector P1 from harness W102 connector J1.
  4. Disconnect harness W102 connector P4 from fuel filter differential pressure transducer.
  5. Make the following continuity checks on harness W102:
    - a. Place one multimeter lead in harness W102 connector P4 socket 1 and other lead in connector J1 socket a.
    - b. Place one multimeter on harness W102 connector P4 pin 2 and other lead in connector J1 socket g.




# 3-3 TROUBLESHOOTING CHART - CONTINUED

o. STE DCA CIRCUIT - CONTINUED (4) STE FAILS TO GIVE FUEL FILTER DIFFERENTIAL PRESSURE READING (TEST 26). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED


CONTINUED FROM STEP A

- B**
1. Reconnect harness W102 connector P4 to fuel filter differential pressure transducer.
  2. Disconnect harness W100 connector P1 from harness W101 connector J1.
  3. Make the following continuity checks on harness W101:
    - a. Place one multimeter lead on connector P1 pin a and other lead in connector J1 socket O.
    - b. Place one multimeter lead on connector P1 pin g and other lead in connector J1 socket V.

Is continuity present?



CONTINUED ON NEXT PAGE




# 3-3 TROUBLESHOOTING CHART - CONTINUED

o. STE DCA CIRCUIT - CONTINUED (4) STE FAILS TO GIVE FUEL FILTER DIFFERENTIAL PRESSURE READING (TEST 26). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED

CONTINUED FROM STEP B



- C**
1. Reconnect harness W101 connector P1 to harness W102 connector J1.
  2. Make the following continuity checks on harness W100:
    - a. Place one multimeter lead on connector P1 pin O and other lead in connector J1 socket s.
    - b. Place one multimeter lead on connector P1 pin V and other lead in connector J1 socket t.

Is continuity present?





- D**
1. Reconnect harness W100 connector P1 to harness W101 connector J1.
  2. Go to TM 9-4910-571-12&P and troubleshoot STE cable W1.

Is STE cable W1 in good condition?



W100  
CONNECTOR P1  
PIN O  
(PIN V)



W100  
CONNECTOR J1  
SOCKET s  
(SOCKET t)

06ph245t

**END OF TASK**





# 3-3 TROUBLESHOOTING CHART - CONTINUED

o. STE DCA CIRCUIT - CONTINUED (5) STE FAILS TO GIVE AIR CLEANER PRESSURE DIFFERENTIAL READING (WHILE PERFORMING TEST 28). STE passed power-up and confidence tests (para 3-4.a(1)).


**INITIAL SETUP**

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long test leads may be needed for some tests. 16 AWG wire may be used as an extension.)</p>	<p><u>Personnel Required</u>                  Two</p>
--	---

- A**
1. Shut engine and vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W100 from DCA connector.
  3. Disconnect harness W100 connector P2 from air cleaner pressure transducer connector.
  4. Make the following continuity checks on harness W100:
    - a. Place one multimeter lead in harness W100 lead connector P2 socket 1 and other lead in harness W100 connector J1 socket f.
    - b. Place one multimeter lead in harness W100 lead connector P2 socket 2 and other lead in harness W100 connector J1 socket D and g.
    - c. Place one multimeter lead on W100 connector P2 pin 3 and other lead in harness W100 connector J1 socket AA.
    - d. Place one multimeter lead on harness W100 connector P2 pin 4 and other lead in harness W100 connector J1 socket AB.



Is continuity present?



CONTINUED ON NEXT PAGE

06ph247t


### 3-3 TROUBLESHOOTING CHART - CONTINUED

o. STE DCA CIRCUIT - CONTINUED (5) STE FAILS TO GIVE AIR CLEANER PRESSURE DIFFERENTIAL READING (WHILE PERFORMING TEST 28). STE passed power-up and confidence tests (para 3-4.a(1)) - CONTINUED.

CONTINUED FROM STEP A

**B** Go to TM 9-4910-571-12&P and troubleshoot STE cable W1.

Is STE cable W1 in good condition?



**END OF TASK**

### 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (6) STE FAILS TO GIVE AIR BOX PRESSURE READING (WHILE PERFORMING TEST 32). STE passed power-up and confidence tests (para 3-4.a(1)).

**INITIAL SETUP**

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)</p>
--	---

**A** Perform test on STE/ICE cable W1 (TM 9-4910-571-12&P).

Is STE cable W1 in good condition?



CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED



o. STE DCA CIRCUIT - CONTINUED (6) STE FAILS TO GIVE AIR BOX PRESSURE READING (WHILE PERFORMING TEST 32). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED

CONTINUED FROM STEP A

**B**

1. Disconnect harness W100 connector P1 from harness W101 J1 at driver's compartment bulkhead.
2. Make the following continuity checks on harness W100:
  - a. Place one multimeter lead on harness W100 connector P1 pin K and other lead in harness W100 connector J1 socket f.
  - b. Place one multimeter lead on harness W100 connector P1 pin L and other lead in harness W100 connector J1 sockets D and g (make checks one socket at a time).
  - c. Place one multimeter lead on harness W100 connector P1 pin Q and other lead in harness W100 connector J1 socket y.
  - d. Place one multimeter lead on harness W100 connector P1 pin R and other lead in harness W100 connector J1 socket z.

Is continuity present?



06ph248t




# 3-3 TROUBLESHOOTING CHART - CONTINUED

o. STE DCA CIRCUIT - CONTINUED (6) STE FAILS TO GIVE AIR BOX PRESSURE READING (WHILE PERFORMING TEST 32). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED


CONTINUED FROM STEP B

- C**
1. Disconnect harness W101 connector P1 at engine disconnect bracket.
  2. Make the following continuity checks on harness W101:
    - a. Place one multimeter lead on harness W101 connector P1 pin P and other lead in harness W101 connector J1 socket K.
    - b. Place one multimeter lead on harness W101 connector P1 pin R and other lead in harness W101 connector J1 socket L.
    - c. Place one multimeter lead on harness W101 connector P1 pin X and other lead in harness W101 connector J1 socket Q.
    - d. Place one multimeter lead on harness W101 connector P1 pin Z and other lead in harness W101 connector J1 socket R.

Is continuity present?



CONTINUED ON NEXT PAGE



06ph249t


### 3-3 TROUBLESHOOTING CHART - CONTINUED

o. STE DCA CIRCUIT - CONTINUED (6) STE FAILS TO GIVE AIR BOX PRESSURE READING (WHILE PERFORMING TEST 32). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED


CONTINUED FROM STEP C

- D**
1. Reconnect harness W100 connector P1 to harness W101 connector J1.
  2. Remove powerpack (para 4-1).
  3. Disconnect harness W102 connector P3 from the air box pressure transducer connector.
  4. Make the following continuity checks on harness W102:
    - a. Place one multimeter lead in harness W102 connector P3 socket 1 and other lead in harness W102 connector J1 socket P.
    - b. Place one multimeter lead in harness W102 connector P3 socket 2 and other lead in harness W102 connector J1 socket R.
    - c. Place one multimeter lead on harness W102 connector P3 pin 3 and other lead in harness W102 connector J1 socket X.
    - d. Place one multimeter lead on harness W102 connector P3 pin 4 and other lead in harness W102 connector J1 socket Z.

Is continuity present?



END OF TASK



06ph250


# 3-3 TROUBLESHOOTING CHART - CONTINUED

o. STE DCA CIRCUIT - CONTINUED (7) STE FAILS TO GIVE BATTERY VOLTAGE READING (WHILE PERFORMING TEST 67). STE passed power-up and confidence tests (para 3-4.a(1)).


**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)


- A**
1. Shut engine and vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W1 from harness W100 connector J1 (DCA connector).
  3. Disconnect harness W100 connector P1 from harness W101 connector J1.
  4. Place multimeter red lead on harness W101 connector J1 socket v and black lead to ground.
  5. Check for voltage.



- B** Check harness W101 lead AZ for continuity by placing red multimeter lead on harness W101 connector J1 socket s and black lead to ground.



CONTINUED ON NEXT PAGE



### 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (7) STE FAILS TO GIVE BATTERY VOLTAGE READING (WHILE PERFORMING TEST 67). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED

CONTINUED FROM STEP B


**C** Make the following continuity check on harness W100:

1. Place one multimeter lead on connector P1 pin v and other lead in connector J1 socket E.
2. Place one multimeter lead on connector P1 pin s and other lead in connector J1 socket W.

Is continuity present?



END OF TASK



06ph252t



# 3-3 TROUBLESHOOTING CHART - CONTINUED

o. STE DCA CIRCUIT - CONTINUED (8) STE FAILS TO GIVE STARTER MOTOR VOLTAGE READING (WHILE PERFORMING TEST 68). STE passed power-up and confidence tests (para 3-4.a(1)).

**INITIAL SETUP**

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)</p> <p><u>Personnel Required</u>                  Two</p>
--	---

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W1 from harness W100 connector J1 (DCA connector).
  3. Disconnect harness W101 connector P1 from harness W102 connector J1.
  4. Disconnect harness W100 connector P1 from harness W101 connector J1.
  5. Check harness W101 for continuity as follows:
    - a. Place one multimeter lead on connector P1 pin F and other lead in connector J1 socket m.
    - b. Place one multimeter lead in connector J1 socket s and other lead to ground.



06ph25:

# 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (8) STE FAILS TO GIVE STARTER MOTOR VOLTAGE READING (WHILE PERFORMING TEST 68). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED

CONTINUED FROM STEP A

**B** Make the following continuity checks on harness W100:

- a. Place one multimeter lead on connector P1 pin m and other lead in connector J1 socket T.
- b. Place one multimeter lead on connector P1 pin s and other lead in connector J1 socket W.


Is continuity present?





**C**

1. Reconnect harness W100 connector P1 to harness W101 connector J1.
2. Remove powerplant (para 4-1).
3. Check harness W102 lead AY for continuity by placing one multimeter lead on harness W102 lead AY at starter solenoid connection and other lead in harness W102 connector J1 socket F.

Is continuity present?



END OF TASK



# 3-3 TROUBLESHOOTING CHART - CONTINUED





o. STE DCA CIRCUIT - CONTINUED (9) STE FAILS TO GIVE STARTER NEGATIVE CABLE DROP READING (WHILE PERFORMING TEST 69). STE passed power-up and confidence tests (para 3-4.a(1)).

**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

Equipment Conditions  
 Transmission access cover open (TM 9-2350-314-10)

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W1 from harness W100 connector J1 (DCA connector).
  3. Disconnect harness W101 connector P1 from harness W102 connector J1.
  4. Check harness W100 connector P1 from harness W101 connector J1.
  5. Check harness W101 for continuity as follows:
    - a. Place one multimeter lead on connector P1 pin E and other lead in connector J1 socket n.
    - b. Place one multimeter lead in connector J1 socket w and other lead on ground.



06ph255t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (9) STE FAILS TO GIVE STARTER NEGATIVE CABLE DROP READING (WHILE PERFORMING TEST 69). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED

CONTINUED FROM STEP A

**B** Make the following continuity checks on harness W100:

1. Place one multimeter lead on connector P1 pin n and other lead in connector J1 socket M.
2. Place one multimeter lead on connector P1 pin w and other lead in connector J1 socket F.


Is continuity present?





**C**

1. Reconnect harness W100 connector P1 to harness W101 connector J1.
2. Remove powerpack (Chapter 4).
3. Check harness W102 lead GND N for continuity by placing one multimeter lead on harness W102 lead GND N at starter ground terminal and other lead in harness W102 connector J1 socket E.

Is continuity present?



END OF TASK





# 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (10) STE FAILS TO GIVE STARTER SOLENOID VOLTAGE READING (WHILE PERFORMING TEST 70). STE passed power-up and confidence tests (para 3-4.a(1)).

**INITIAL SETUP**


Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

Equipment Conditions  
 Transmission access doors open (TM 9-2350-314-10)

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W1 from harness W100 connector J1 (DCA connector).
  3. Disconnect harness W101 connector P1 from harness W102 connector J1.
  4. Disconnect harness W100 connector P1 from harness W101 connector J1.
  5. Check harness W101 for continuity as follows:
    - a. Place one multimeter lead on connector P1 pin B and other lead in connector J1 socket d.
    - b. Place one multimeter lead on connector P1 pin E and other lead in connector J1 socket n.
- Is continuity present?



CONTINUED ON NEXT PAGE



06ph257t

# 3-3 TROUBLESHOOTING CHART - CONTINUED



o. STE DCA CIRCUIT - CONTINUED (10) STE FAILS TO GIVE STARTER SOLENOID VOLTAGE READING (WHILE PERFORMING TEST 70). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED.

CONTINUED FROM STEP A



**B** Make the following continuity checks on harness W100:

- a. Place one multimeter lead on connector P1 pin d and other lead in connector J1 socket S.
- b. Place one multimeter lead on connector P1 pin n and other lead in connector J1 socket M.

Is continuity present?



W100  
CONNECTOR P1  
PIN d  
(PIN n)



W100  
CONNECTOR J1  
SOCKET S  
(SOCKET M)

06ph258t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

o. STE DCA CIRCUIT - CONTINUED (10) STE FAILS TO GIVE STARTER SOLENOID VOLTAGE READING (WHILE PERFORMING TEST 70). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED


CONTINUED FROM STEP B

- C**
1. Reconnect harness W100 connector P1 to harness W101 connector J1.
  2. Remove powerpack (para 4-1).
  3. Check harness W102 for continuity as follows:
    - a. Place one multimeter lead on starter solenoid terminal with harness W104 lead 14B and harness W102 lead AX and other lead in connector J1 socket B.
    - b. Place one multimeter lead on starter ground terminal GND N and other lead in connector J1 socket E.

Is continuity present?



END OF TASK



06ph259t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (11) STE FAILS TO GIVE STARTER CURRENT READING (WHILE PERFORMING TEST 71). STE passed power-up and confidence tests (para 3-4.a(1)).

**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)  
 (Long leads may be needed for some tests. 16 AWG wire may be used as an extension.)


- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W1 from harness W100 connector J1 (DCA connector).
  3. Disconnect harness W100 connector P1 from harness W101 connector J1 at driver's bulkhead.
  4. Place one multimeter lead on harness W101 connector J1 sockets p and u (one at a time) and other lead on ground and check for continuity.

Is continuity present?







- B**
- a. Place one multimeter lead on connector P1 pin p and other lead in connector J1 socket X.
  - b. Place one multimeter lead on connector P1 pin u and other lead in connector J1 socket Y.

Is continuity present?



**END OF TASK**



# 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (12) STE FAILS TO GIVE READING (WHILE PERFORMING TEST 72, or 73, or 74, or 75). STE passed power-up and confidence tests (para 3-4.a(1)).

**INITIAL SETUP**

Tools  
 General mechanic's tool kit  
 (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)


- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W1 from harness W100 connector J1 (DCA connector).
  3. Disconnect harness W100 connector P1 from harness W101 connector J1 at driver's bulkhead.
  4. Place multimeter red lead on harness W101 connector J1 sockets r and v (one at a time) and black lead to ground. Check for voltage.

Is voltage present?




- B**
- Place one multimeter lead on harness W101 connector J1 sockets p, s, and u (one at a time) and other lead to ground. Check for continuity.

Is continuity present?



CONTINUED ON NEXT PAGE



06-5261

# 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (12) STE FAILS TO GIVE READING (WHILE PERFORMING TEST 72, or 73, or 74, or 75). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED

CONTINUED FROM STEP B


**C** Check harness W100 for continuity as follows:

- Place one multimeter lead on connector P1 pin p and other lead in connector J1 socket X.
- Place one multimeter lead on connector P1 pin r and other lead in connector J1 socket V.
- Place one multimeter lead on connector P1 pin s and other lead in connector J1 socket W.
- Place one multimeter lead on connector P1 pin u and other lead in connector J1 socket Y.
- Place one multimeter lead on connector P1 pin v and other lead in connector J1 socket E.

Is continuity present?



END OF TASK



06ph262t

# 3-3 TROUBLESHOOTING CHART - CONTINUED



o. STE DCA CIRCUIT - CONTINUED (13) STE FAILS TO GIVE ALTERNATOR/GENERATOR OUTPUT VOLTAGE READING (WHILE PERFORMING TEST 82). STE passed power-up and confidence tests (para 3-4.a(1)).

**INITIAL SETUP**

Tools  
 General mechanic's tool kit (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)

Equipment Conditions  
 Transmission access doors open (TM 9-2350-314-10)

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W1 from harness W100 connector J1 (DCA connector).
  3. Disconnect harness W100 connector P1 from harness W101 connector J1 at driver's bulkhead.
  4. Disconnect harness W101 connector P1 from harness W102 connector J1 at engine disconnect bracket.
  5. Check harness W101 for continuity as follows:
    - a. Place one multimeter on connector P1 pin p and other lead in connector J1 socket t.
    - b. Place one multimeter lead in connector J1 socket s and other lead to ground.



06ph294t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (13) STE FAILS TO GIVE ALTERNATOR/GENERATOR OUTPUT VOLTAGE READING (WHILE PERFORMING TEST 82). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED

CONTINUED FROM STEP A


**B** Check harness W100 for continuity as follows:

- Place one multimeter lead on connector P1 pin s and other lead in connector J1 socket W.
- Place one multimeter lead on connector P1 pin t and other lead in connector J1 socket N.



Is continuity present?



CONTINUED ON NEXT PAGE



W100  
CONNECTOR P1  
PIN s  
(PIN t)



W100  
CONNECTOR J1  
SOCKET W  
(SOCKET N)

06ph295t




# 3-3 TROUBLESHOOTING CHART - CONTINUED




o. STE DCA CIRCUIT - CONTINUED (13) STE FAILS TO GIVE ALTERNATOR/GENERATOR OUTPUT VOLTAGE READING (WHILE PERFORMING TEST 82). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED

CONTINUED FROM STEP B

- C**
1. Reconnect harness W100 connector P1 to harness W101 connector J1.
  2. Check harness W102 lead AW for continuity by placing one multimeter lead on harness W102 lead AW at generator positive terminal and other lead in harness W102 connector J1 socket p.
- Is continuity present?



END OF TASK





06ph296t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

o. STE DCA CIRCUIT - CONTINUED (14) STE FAILS TO GIVE ALTERNATOR/GENERATOR FIELD VOLTAGE READING (WHILE PERFORMING TEST 83). STE passed power-up and confidence tests (para 3-4.a(1)).

<p><b>INITIAL SETUP</b></p> <p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)</p>
--	---

- A**
1. Shut engine and vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W1 from harness W100 connector J1 (DCA connector).
  3. Disconnect harness W101 connector P1 from harness W102 connector J1.
  4. Disconnect harness W100 connector P1 from harness W101 connector J1.
  5. Disconnect harness W101 lead AV from harness W106 lead F+ connector.
  6. Check harness W101 for continuity as follows:
    - a. Place one multimeter lead on connector P1 pin E and other lead in connector J1 socket n.
    - b. Place one multimeter lead on lead AV connector pin and other lead in connector J1 socket y.



# 3-3 TROUBLESHOOTING CHART - CONTINUED



o. STE DCA CIRCUIT - CONTINUED (14) STE FAILS TO GIVE ALTERNATOR/GENERATOR FIELD VOLTAGE READING (WHILE PERFORMING TEST 83). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED

CONTINUED FROM STEP A

**B** Check harness W100 for continuity as follows:

- Place one multimeter lead on connector P1 pin n and other lead in connector J1 socket M.
- Place one multimeter lead on connector P1 pin y and other lead in connector J1 socket O.

Is continuity present?



06ph298t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (14) STE FAILS TO GIVE ALTERNATOR/GENERATOR FIELD VOLTAGE READING (WHILE PERFORMING TEST 83). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED

CONTINUED FROM STEP B

**C**

1. Disconnect harness W106 connector P1 from voltage regulator.
2. Check harness W106 for continuity by placing one multimeter lead in harness W106 connector P1 socket C and other lead in harness W106 lead F+ connector socket.


Is continuity present?




**D**

1. Reconnect harness W100 connector P1 to harness W101 connector J1.
2. Reconnect harness W106 connector P1 voltage regulator and lead F+ to harness W101 lead AV.
3. Remove powerpack (para 4-1).
4. Check harness W102 for continuity by placing one multimeter lead on starter ground terminal GND-N and other lead in harness W102 connector J1 socket E.

Is continuity present?



CONTINUED ON NEXT PAGE




06ph299t

# 3-3 TROUBLESHOOTING CHART - CONTINUED




o. STE DCA CIRCUIT - CONTINUED (14) STE FAILS TO GIVE ALTERNATOR/GENERATOR FIELD VOLTAGE READING (WHILE PERFORMING TEST 83). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED

CONTINUED FROM STEP D

- E**
1. Disconnect harness W107 lead 3 at generator negative terminal.
  2. Check harness W107 lead 3 by placing one multimeter lead on harness W107 lead 3 at generator negative terminal and other lead to ground.
- Is continuity present?



END OF TASK



06ph300t

### 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (15) STE FAILS TO GIVE ALTERNATOR/GENERATOR NEGATIVE CABLE DROP READING (WHILE PERFORMING TEST 84). STE passed power-up and confidence tests (para 3-4.a(1)).

**INITIAL SETUP**


<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)                  (Long leads may be needed for some tests. 16 AWG wire may be used as an extension.)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)</p>
---	---

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect STE cable W1 from harness W100 connector J1 (DCA connector).
  3. Disconnect harness W101 connector P1 from harness W102 connector J1.
  4. Disconnect harness W100 connector P1 from harness W101 connector J1 at driver's bulkhead.
  5. Check harness W101 for continuity as follows:
    - a. Place one multimeter lead on connector P1 pin S and other lead in connector J1 socket z.
    - b. Place one multimeter lead in connector J1 socket s and other lead to ground.

Is continuity present?



CONTINUED ON NEXT PAGE



# 3-3 TROUBLESHOOTING CHART - CONTINUED


o. STE DCA CIRCUIT - CONTINUED (15) STE FAILS TO GIVE ALTERNATOR/GENERATOR NEGATIVE CABLE DROP READING (WHILE PERFORMING TEST 84). STE passed power-up and confidence tests (para 3-4a.(1)). - CONTINUED

CONTINUED FROM STEP A


**B** Check harness W100 for continuity as follows:

- Place one multimeter lead on connector P1 pin s and other lead in connector J1 socket W.
- Place one multimeter lead on connector P1 pin z and other lead in connector J1 socket P.



Is continuity present?



CONTINUED ON NEXT PAGE



W100  
CONNECTOR P1  
PIN s  
(PIN z)



W100  
CONNECTOR J1  
SOCKET W  
(SOCKET P)

06ph302t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

o. STE DCA CIRCUIT - CONTINUED (15) STE FAILS TO GIVE ALTERNATOR/GENERATOR NEGATIVE CABLE DROP READING (WHILE PERFORMING TEST 84). STE passed power-up and confidence tests (para 3-4.a(1)). - CONTINUED



CONTINUED FROM STEP B

- C**
1. Reconnect harness W100 connector P1 to harness W101 connector J1.
  2. Check harness W102 by placing one multimeter lead on harness W102 lead GDN-2 at generator negative (-) terminal and other lead in harness W102 connector J1 socket S.

Is continuity present?



**END OF TASK**



06ph303t




# 3-3 TROUBLESHOOTING CHART - CONTINUED

## p. TRACK AND SUSPENSION

The track and suspension system consists of the vehicle tracks, final drives, sprocket wheel, universal joints, roadwheels, idler wheels, idler hubs, shocks, and torsion bars. The relationship of these components is shown in the diagram below.

When the track receives power from the transmission through the universal joints, final drives, and sprockets, the track begins to revolve around roadwheels, over the idler wheels and back to the sprockets. This propels the vehicle forward and backward, depending on selected transmission gear.




# 3-3 TROUBLESHOOTING CHART - CONTINUED

p. TRACK AND SUSPENSION - CONTINUED (1) VEHICLE BRAKES POORLY. Vehicle does not stop correctly when brake is applied.


INITIAL SETUP

Tools  
 General mechanic's tool kit  
 (SC 5180-90-N26)


**A** Check parking brakes and linkages for proper adjustment (para 11-1).  
 Are brakes properly adjusted?



**B** Check brake linkage and brake related items for faulty components (para 11-2).  
 Are all brake linkage and related items free of faults?



**C** Check transmission internal brake adjustment (para 9-4).  
 Is transmission internal brake properly adjusted?



Notify direct support maintenance.

**END OF TASK**

# 3-3 TROUBLESHOOTING CHART - CONTINUED

p. TRACK AND SUSPENSION - CONTINUED                      (2) VEHICLE PULLS TO ONE SIDE WITH STEERING WHEEL IN CENTER POSITION.

**INITIAL SETUP**


<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)</p>
---	---

**NOTE**

Crown on road causes vehicle to pull away from center of road. Road test vehicle on flat surface.


**A** Check for disconnected or improperly adjusted steering control linkage (paras 13-1 and 13-2).

Is steering control linkage properly connected and adjusted?




**B** Refer to para 3-3p (1) and check brake system.

Are brakes properly adjusted?



**C** Check tracks for proper adjustment (para 12-14).

Are tracks properly adjusted?



CONTINUED ON NEXT PAGE


### 3-3 TROUBLESHOOTING CHART - CONTINUED

p. TRACK AND SUSPENSION - CONTINUED                      (2) VEHICLE PULLS TO ONE SIDE WITH STEERING WHEEL IN CENTER POSITION. - CONTINUED

CONTINUED FROM STEP C


**D** Refer to para 12-1 and check suspension system for broken, damaged, and/or binding suspension components.

Are suspension components in good condition?




**E** Check drive sprockets for even wear of all sprockets (para 12-12).

Are all sprockets worn the same?



**F**

1. Remove final drive quick-disconnects (para 10-3).
2. Start engine (TM 9-2350-314-10) and maintain 1000 to 1500 rpm.
3. Do STE/ICE test 50 (para 3-4.b(17)) using blue striped transducer.
4. Use the following test points (para 9-2):
  - a. gear steer apply pressure; left 16, right 15.
  - b. output clutch apply pressure; left 21, right 13.
5. Record results.



**END OF TASK**


# 3-3 TROUBLESHOOTING CHART - CONTINUED

p. TRACK AND SUSPENSION (3) VEHICLE THROWS TRACKS.  
- CONTINUED


INITIAL SETUP  
Tools  
General mechanic's tool kit  
(SC 5180-90-N26)

**NOTE**  
Improper driving or operation of vehicle (high speed turns) causes the vehicle to throw tracks.


**A** Check for loose, worn, or damaged tracks (paras 12-14 and 12-16).  
Are tracks tight and in good condition?



**B** Check drive sprockets for excessive wear (Table 2-1, PMCS item 25).  
Are drive sprockets free of excessive wear?



**C** Check for foreign objects wedged between roadwheels or idler wheels.  
Are roadwheels and idler wheels free of foreign objects?



CONTINUED ON NEXT PAGE

### 3-3 TROUBLESHOOTING CHART - CONTINUED

p. TRACK AND SUSPENSION (3) VEHICLE THROWS TRACKS. - CONTINUED  
- CONTINUED

CONTINUED FROM STEP C

**D** Check for broken torsion bars (Table 2-1, PMCS item 24).  
Are all torsion bars in good condition?

yes

no

Replace broken torsion bars as required (para 12-6).

Disconnect track and lay out flat (para 12-16). Inspect track and track shoes (TM 9-2350-200-24). Replace as required (para 12-15).

END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED

p. TRACK AND SUSPENSION - CONTINUED (4) VEHICLE RIDE IS ROUGH OR SUSPENSION SYSTEM IS NOISY DURING OPERATION.


**INITIAL SETUP**  
Tools  
 General mechanic's tool kit (SC 5180-90-N26)

**WARNING**  
 Use caution when feeling shock absorbers. They can get hot enough to cause burns.

**NOTE**  
 A defective shock absorber will be colder than the other shock absorbers.

- A**
1. Immediately after road test, place the back of your hand on shocks to feel for the presence of heat. Heat indicates shock absorbers are functioning properly (TM 9-2350-314-10, PMCS).
  2. Check shock absorbers and hydraulic bumpers for oil leaks (TM 9-2350-314-10, PMCS).
  3. Check shock absorbers and hydraulic bumpers for proper mounting (paras 15-1 and 15-3).

Are shock absorbers and hydraulic bumpers properly mounted, free of oil leaks, and are shock absorbers approximately the same temperature?



**NOTE**  
 Roadwheels which are hot to the touch indicate a bearing problem.

CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

p. TRACK AND SUSPENSION - CONTINUED	(4) VEHICLE RIDE IS ROUGH OR SUSPENSION SYSTEM IS NOISY DURING OPERATION. - CONTINUED
--	---


CONTINUED FROM STEP A

**WARNING**

Use caution when checking roadwheel hubs. They can get hot enough to cause burns.

**B** Immediately after road test, check roadwheel hubs with the back of your hand for excessive heat.


Are roadwheel hubs at normal operating temperature?



Replace defective roadwheel hub components as required (para 12-4).

**C** Check drive sprockets for excessive wear (Table 2-1, PMCS item 25).


Are drive sprockets free of excessive wear?



Reverse or replace drive sprockets as required (para 12-12).

**D** Refer to Table 2-1, PMCS item 24 and check for broken torsion bars.

Are all torsion bars in good condition?



Replace broken torsion bars as required (para 12-6).


CONTINUED ON NEXT PAGE



**3-3 TROUBLESHOOTING CHART - CONTINUED**

p. TRACK AND SUSPENSION - CONTINUED (4) VEHICLE RIDE IS ROUGH OR SUSPENSION SYSTEM IS NOISY DURING OPERATION. - CONTINUED

CONTINUED FROM STEP D



END OF TASK


### 3-3 TROUBLESHOOTING CHART - CONTINUED

#### q. TRANSMISSION AND DRIVING CONTROLS

The transmission is mechanically and hydraulically operated and is oil cooled. Power to operate the transmission is delivered by the engine through the transfer assembly. See diagram below.

The transmission has 7 gears - 4 forward, 1 neutral, and 2 reverse. Once power is provided to the transmission, it delivers this power to the left and right drive sprockets through an output shaft, universal joints, and the final drive assemblies. The final drive assemblies reduce the transmission power and provide this reduced power to the sprockets and hubs.

The transmission also serves as the steering and braking mechanism for the vehicle.



07ph001t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


q. TRANSMISSION AND DRIVING CONTROLS - CONTINUED (1) TRANSMISSION OVERHEATS. Transmission oil temperature gage reads over 285° F (140° C). MASTER warning light is lit.

<b>INITIAL SETUP</b>	
<u>Tools</u> General mechanic's tool kit (SC 5180-90-N26) Gage (item 22, Appx F) or STE/ICE test set (item 72, Appx F)	<u>Equipment Conditions</u> Transmission access doors open (TM 9-2350-314-10)


**WARNING**

- Vehicle has no brakes when final drives are disconnected. Failure to securely block vehicle could injure personnel or damage vehicle equipment if vehicle rolls out of control.
- Transmission contains hot oil under high pressure. Stop engine before removing or installing pipe plugs and gage adapters in pressure test points. Install pipe plug as soon as gage adapter is removed. Remove only pipe plug at test point. Failure to comply with these precautions may result in equipment damage or personnel injury.

**A** Check transmission oil level (TM 9-2350-314-10).  
 Is transmission oil at proper level?



**B** Check transmission oil cooler lines for leaks or restrictions (para 9-9).  
 Are transmission oil cooler lines free of leaks and restrictions?




CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


q. TRANSMISSION AND DRIVING CONTROLS - CONTINUED (1) TRANSMISSION OVERHEATS. Transmission oil temperature gage reads over 285° F (140° C). MASTER warning light is lit. - CONTINUED

CONTINUED FROM STEP B

**C** Troubleshoot transmission oil temperature indicator circuit (para 3-3.g(4)).  
Is transmission oil temperature indicator circuit operating properly?




**D** Check transmission oil filter for cleanliness and proper installation (para 9-3).  
Is transmission oil filter clean and properly installed?



**NOTE**  
To test transmission oil pressure, use a 400 psi (2758 kpa) gage or do STE/ICE test 50 (para 3-4.b(17)) using the blue striped transducer.

**E** Start the engine (TM 9-2350-314-10) and hold speed at 1000 to 1500 RPM and check the transmission oil pressures at test point 3 (para 9-2).  
Is the transmission oil pressure below specifications?




CONTINUED ON NEXT PAGE

### 3-3 TROUBLESHOOTING CHART - CONTINUED

q. TRANSMISSION AND DRIVING CONTROLS - CONTINUED (1) TRANSMISSION OVERHEATS. Transmission oil temperature gage reads over 285° F (140° C). MASTER warning light is lit. - CONTINUED

CONTINUED FROM STEP E

**F** Check the brake linkage and internal brake clearance for correct adjustment (para 11-1 and 9-4).  
Are brakes correctly adjusted?



Notify direct support maintenance.

END OF TASK

### 3-3 TROUBLESHOOTING CHART - CONTINUED

q. TRANSMISSION AND DRIVING CONTROLS - CONTINUED (2) VEHICLE DOES NOT DRIVE. Transmission does not operate in any shift position.


<b>INITIAL SETUP</b>	
<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Gage (item 22, Appx F) or STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)</p>

**WARNING**

- Vehicle has no brakes when final drives are disconnected. Failure to securely block vehicle could injure personnel or damage vehicle equipment if vehicle rolls out of control.
- Transmission contains hot oil under high pressure. Stop engine before removing or installing pipe plugs and gage adapters in pressure test points. Install pipe plug as soon as gage adapter is removed. Remove only pipe plug at test point. Failure to comply with these precautions may result in equipment damage or personnel injury.

**A** Check transmission oil level (TM 9-2350-314-10).

Is transmission oil at proper level?



CONTINUED ON NEXT PAGE

### 3-3 TROUBLESHOOTING CHART - CONTINUED

q. TRANSMISSION AND DRIVING CONTROLS - CONTINUED      (2) VEHICLE DOES NOT DRIVE. Transmission does not operate in any shift position. - CONTINUED

CONTINUED FROM STEP A

**B** Check oil to see if oil appears milky or contaminated (TM 9-2350-314-10).

Is oil burnt or contaminated?

yes

no

Send oil sample to AOAP and notify direct support maintenance.

**C** Check for improperly adjusted or disconnected shift control linkage (para 9-1).

Is shift control linkage connected and properly adjusted?

yes

no

Reconnect and/or adjust shifting linkage as required (para 9-1).

**D** Check brake linkage (para 11-1) and transmission internal brake (para 9-4) adjustment.

Is brake linkage and transmission internal brake properly adjusted?

yes

no

Adjust brake linkage (para 11-1) and/or transmission internal brake (para 9-4).


CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

q. TRANSMISSION AND DRIVING CONTROLS - CONTINUED      (2) VEHICLE DOES NOT DRIVE. Transmission does not operate in any shift position. - CONTINUED

CONTINUED FROM STEP D


**E** Inspect final drive and universal joints (para 10-3).  
 Are universal joints unbroken and in good condition?



**F**

1. Using a 400 psi (2758 kpa) gage or STE/ICE test 50 (para 3-4.b(17)) with blue striped transducer, check transmission oil pressure (para 9-2) at the following points:
  - a. main - test point 3.
  - b. range clutch - test points 4, 5 and 6.
  - c. trans. lub. - test points 11 and 20.
  - d. gear steer apply (no steer) - test points 10 and 18.
  - e. output clutch - test points 13 and 21.
2. Start the engine (TM 9-2350-314-10) and hold 1000 to 1500 rpm.
3. Record the results.

Are any of the transmission oil pressures below specifications?



**END OF TASK**



### 3-3 TROUBLESHOOTING CHART - CONTINUED

q. TRANSMISSION AND DRIVING CONTROLS - CONTINUED      (3) VEHICLE DOES NOT STEER IN EITHER DIRECTION IN ANY RANGE.


**INITIAL SETUP**

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  STE/ICE test set (item 72, Appx F) or Gage (item 22, Appx F)</p>	<p><u>Equipment Conditions</u>                  Transmission access door open (TM 9-2350-314-10)</p>
---	--

**A**      Check transmission oil level (TM 9-2350-314-10).

---


Is transmission oil at the proper level?



**B**      Check for broken, disconnected or out-of-adjustment steering linkage (para 13-1).

---

Is steering linkage unbroken and properly connected and adjusted?



CONTINUED ON NEXT PAGE

### 3-3 TROUBLESHOOTING CHART - CONTINUED


q. TRANSMISSION AND DRIVING CONTROLS - CONTINUED      (3) VEHICLE DOES NOT STEER IN EITHER DIRECTION IN ANY RANGE. - CONTINUED

CONTINUED FROM STEP B

**C**

1. Using a 400 psi (2758 kpa) gage or STE/ICE test 50 (para 3-4.b(17)) with blue striped transducer, check transmission oil pressure (para 9-2) at the following points:
  - a. gear steer pressure applied; left - 16, right - 15.
  - b. output clutch; left - 21, right - 13.
  - c. gear steer clutches; left - 18, right - 10.
2. Record results.

Are any pressures below specifications?



**END OF TASK**

### 3-3 TROUBLESHOOTING CHART - CONTINUED

q. TRANSMISSION AND DRIVING CONTROLS - CONTINUED (4) VEHICLE STEERS WELL IN ONE DIRECTION ONLY.


<b>INITIAL SETUP</b>	
<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  STE/ICE test set (item 72, Appx G) or Gage (item 22, Appx F)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)</p>

**WARNING**

- Vehicle has no brakes when final drives are disconnected. Failure to securely block vehicle could injure personnel or damage vehicle equipment if vehicle rolls out of control.
- Transmission contains hot oil under high pressure. Stop engine before removing or installing pipe plugs and gage adapters in pressure test points. Install pipe plug as soon as gage adapter is removed. Remove only pipe plug at test point. Failure to comply with these precautions may result in equipment damage or personnel injury.


**A** Check steering control linkage adjustment (para 13-2).

Is steering control linkage properly adjusted?



**B** Check brake linkage (para 11-1) and transmission internal brake (para 9-4) for correct adjustment.

Is brake linkage and transmission internal brake adjusted properly?




CONTINUED ON NEXT PAGE

### 3-3 TROUBLESHOOTING CHART - CONTINUED

q. TRANSMISSION AND DRIVING CONTROLS - CONTINUED      (4) VEHICLE STEERS WELL IN ONE DIRECTION ONLY. - CONTINUED

CONTINUED FROM STEP B

<b>C</b>	<ol style="list-style-type: none"> <li>1. Using a 400 psi (2758 kpa) gage or STE/ICE test 50 (para 3-4.b(17)) with blue striped transducer, check transmission oil pressure (para 9-2) at the following points:               <ol style="list-style-type: none"> <li>a. first gear, second gear, and reverse 1; brake pressure: left 16, right 15. steer gear: left 18, right 10. brake coolant: left 17, right 14.</li> <li>b. third gear, fourth gear, and reverse 2; output clutch: left 21, right 13. steer gear: left 18, right 10. steer gear coolant: left 19, right 12.</li> </ol> </li> <li>2. Record results.</li> </ol>
Are any pressures below specifications?	




**END OF TASK**

# 3-3 TROUBLESHOOTING CHART - CONTINUED

## r. TRAVEL LOCK

The travel lock consists of gun tube travel lock, travel lock control box, and circuit breaker number 4 (CB4). The relationship of these components is shown in the diagram below.

When vehicle MASTER power switch is turned ON, 24 V dc is applied through the master relay and CB4 to the travel lock control box. When POWER ON-OFF switch on the travel lock control box is turned ON, the travel lock may be raised or lowered using the RAISE/UNLOCK - LOWER/LOCK switch. The extend limit switch and retract limit switch will cause the RAISE/UNLOCK and LOWER/LOCK indicator lamps to illuminate when the travel lock reaches the end of travel.




06ph267t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


r. TRAVEL LOCK - CONTINUED (1) CONTROL BOX WILL NOT POWER UP.

<p><b>INITIAL SETUP</b></p> <p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)</p> <p><u>Personnel Required</u>                  Two</p>
--	---


- A**
1. Ensure vehicle MASTER switch is OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 connector P2 from travel lock control box.
  3. Check for voltage by placing multimeter red lead in socket A and black lead in socket B.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).




- B**
1. Turn glow plug ENABLE switch ON (TM 9-2350-314-10).
- Is glow plug WAIT LED on?



- C**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W120 lead 10S from circuit breaker (CB4).
  3. Check for voltage by placing multimeter red lead on lead 10S side of CB4 and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).





CONTINUED ON NEXT PAGE



# 3-3 TROUBLESHOOTING CHART - CONTINUED

r. TRAVEL LOCK - CONTINUED (1) CONTROL BOX WILL NOT POWER UP. - CONTINUED

CONTINUED FROM STEP C



06ph269t

CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


r. TRAVEL LOCK - CONTINUED (1) CONTROL BOX WILL NOT POWER UP. - CONTINUED

CONTINUED FROM STEP B

**E**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Disconnect harness W115 lead TL1 from harness W120 socket 10S.
3. Check for voltage by placing multimeter red lead in socket 10S and black lead to ground.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).


Is voltage present?




**F**

1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
2. Reconnect harness W115 lead TL1 to harness W120 lead 10S.
3. Check for voltage by placing multimeter red lead in socket A and black lead to ground.
4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).

Is voltage present?



CONTINUED ON NEXT PAGE



06ph270t



# 3-3 TROUBLESHOOTING CHART - CONTINUED

r. TRAVEL LOCK - CONTINUED (1) CONTROL BOX WILL NOT POWER UP. - CONTINUED

CONTINUED FROM STEP F

- G**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect harness W115 lead TL2 from harness W125 lead 7.
  3. Place one multimeter lead in harness W115 connector P2 socket B and other lead in TL2 and check for continuity.

Is continuity present?


yes

no

Repair or replace harness W120 (para 8-79).

Repair or replace harness W115 (para 8-74).

END OF TASK



06ph271t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


r. TRAVEL LOCK - CONTINUED (2) TRAVEL LOCK WILL NOT RAISE/UNLOCK OR LOWER/LOCK.

<p><u>INITIAL SETUP</u></p> <p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)</p> <p><u>Personnel Required</u>                  Two</p>
--	---

**A**

1. Attempt to operate travel lock in RAISE/UNLOCK and LOWER/LOCK modes (TM 9-2350-314-10).
2. Listen to actuator motor.


Is actuator motor running?




**B**

1. Turn vehicle MASTER and TRAVEL LOCK power switches OFF (TM 9-2350-314-10).
2. Disconnect harness W126 connector P2 from travel lock actuator.
3. Place a jumper from socket F to Socket G of harness W126 connector P2.
4. Check for voltage by placing multimeter red lead in sockets A and C one at a time and black lead to ground.
5. Turn vehicle MASTER and TRAVEL LOCK power switches ON (TM 9-2350-314-10).
6. Hold travel lock switch in RAISE/UNLOCK position (TM 9-2350-314-10).

Is voltage present?



CONTINUED ON NEXT PAGE



06ph272t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

r. TRAVEL LOCK - CONTINUED (2) TRAVEL LOCK WILL NOT RAISE/UNLOCK OR LOWER/LOCK. - CONTINUED




CONTINUED FROM STEP B

**C**

1. Release travel lock switch.
2. Turn vehicle MASTER and TRAVEL LOCK power switches OFF (TM 9-2350-314-10).
3. Remove jumper from harness W126 connector P2.
4. Disconnect harness W126 connector P1 at bow plate feed through.
5. Check harness W126 for continuity as follows:

FROM CONNECTOR	TO CONNECTOR
P2 socket A	P1 pin A
P2 socket B	P1 pin B
P2 socket C	P1 pin C
P2 socket D	P1 pin D
P2 socket F	P1 pin F
P2 socket I	P1 pin I

Is continuity present?



06ph273t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


r. TRAVEL LOCK - CONTINUED (2) TRAVEL LOCK WILL NOT RAISE/UNLOCK OR LOWER/LOCK. - CONTINUED

CONTINUED FROM STEP C

**D**

1. Reconnect harness W126 connector P2 to travel lock actuator.
2. Disconnect harness W113 connector P2 from the bow plate feed through.
3. Check bow plate feed through sockets and pins for damage.

Are pins and sockets in good condition?







**E**

1. Reconnect harness W126 connector P1 to bow plate feed through.
2. Disconnect harness W115 connector P1 from harness W113 connector J1.
3. Check harness W113 for continuity as follows:

FROM CONNECTOR	TO CONNECTOR
P2 socket A	J1 pin N
P2 socket C	J1 pin N
P2 socket B	J1 pin P
P2 socket D	J1 pin P
P2 socket F	J1 pin R
P2 socket I	J1 pin U

Is continuity present?



06ph274t

CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

r. TRAVEL LOCK - CONTINUED (2) TRAVEL LOCK WILL NOT RAISE/UNLOCK OR LOWER/LOCK. - CONTINUED


CONTINUED FROM STEP E

**F**

1. Reconnect harness W113 connector P2 to bow plate feed through.
2. Disconnect harness W115 connector P2 from travel lock control box.
3. Check harness W115 for continuity as follows:

FROM CONNECTOR	TO CONNECTOR
P1 socket N	P2 socket C
P1 socket P	P2 socket D
P1 socket R	P2 socket F




Is continuity present?



Replace travel lock control box (para 8-16).

Repair or replace harness W115 (para 8-74).

END OF TASK



06ph275t

### 3-3 TROUBLESHOOTING CHART - CONTINUED


r. TRAVEL LOCK - CONTINUED (3) LOWER/LOCK LED WILL NOT LIGHT.

<p><u>INITIAL SETUP</u></p> <p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)</p> <p><u>Personnel Required</u>                  Two</p>
--	---



- A**

  1. Turn vehicle MASTER and TRAVEL LOCK power switches OFF (TM 9-2350-314-10).
  2. Remove LOWER/LOCK LED (TM 9-2350-314-10).
  3. Place multimeter red lead in LED socket center contact and black lead on ground.
  4. Turn vehicle MASTER and TRAVEL LOCK power switches ON (TM 9-2350-314-10).
  5. Place and hold travel lock switch in LOWER/LOCK position and check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE




# 3-3 TROUBLESHOOTING CHART - CONTINUED

r. TRAVEL LOCK - CONTINUED (3) LOWER/LOCK LED WILL NOT LIGHT. - CONTINUED

CONTINUED FROM STEP A


**B** 1. Place and hold travel lock switch in LOWER/LOCK position.  
2. Listen to actuator motor.

Is actuator motor running?





**C** 1. Release travel lock switch.  
2. Turn vehicle MASTER and TRAVEL LOCK power switches OFF (TM 9-2350-314-10).  
3. Disconnect harness W126 connector P2 from travel lock actuator.  
4. Place jumper lead between socket I and socket H.  
5. Turn vehicle MASTER and TRAVEL LOCK power switches ON (TM 9-2350-314-10).  
6. Place and hold travel lock switch in LOWER/LOCK position.

Does LOWER/LOCK LED light?



CONTINUED ON NEXT PAGE



06ph277t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

r. TRAVEL LOCK - CONTINUED (3) LOWER/LOCK LED WILL NOT LIGHT. - CONTINUED





CONTINUED FROM STEP C

**D**


1. Release travel lock switch.
2. Turn vehicle MASTER and TRAVEL LOCK power switches OFF (TM 9-2350-314-10).
3. Remove jumper from harness W126 connector P2.
4. Disconnect harness W126 connector P1 at bow plate feed through.
5. Check harness W126 for continuity as follows:

FROM CONNECTOR	TO CONNECTOR
P2 socket H	P1 pin H
P2 socket I	P1 pin I

Is continuity present?



W126  
CONNECTOR P1  
PIN H  
(PIN I)



W126  
CONNECTOR P2  
SOCKET H  
(SOCKET I)

06ph278t



# 3-3 TROUBLESHOOTING CHART - CONTINUED


r. TRAVEL LOCK - CONTINUED (3) LOWER/LOCK LED WILL NOT LIGHT. - CONTINUED

CONTINUED FROM STEP D

**E**

1. Reconnect harness W126 connector P2 to travel lock actuator.
2. Disconnect harness W113 connector P2 from the bow plate feed through.
3. Check bow plate feed through sockets and pins for damage.

Are pins and sockets in good condition?







**F**


1. Reconnect harness W126 connector P1 to bow plate feed through.
2. Disconnect harness W115 connector P1 from harness W113 connector J1.
3. Check harness W113 for continuity as follows:

FROM CONNECTOR	TO CONNECTOR
P2 socket H	J1 pin T
P2 socket I	J1 pin U

Is continuity present?



W113 CONNECTOR P2 SOCKET H (SOCKET I)



W113 CONNECTOR J1 PIN T (PIN U)

06ph279t

CONTINUED ON NEXT PAGE


# 3-3 TROUBLESHOOTING CHART - CONTINUED

r. TRAVEL LOCK - CONTINUED (3) LOWER/LOCK LED WILL NOT LIGHT. - CONTINUED




CONTINUED FROM STEP F

- G**
1. Reconnect harness W113 connector P2 to bow plate feed through.
  2. Disconnect harness W115 connector P2 from travel lock control box.
  3. Check harness W115 for continuity as follows:
- | <u>FROM CONNECTOR</u> | <u>TO CONNECTOR</u> |
|-----------------------|---------------------|
| P1 socket T           | P2 socket H         |
| P1 socket U           | P2 socket I         |


Is continuity present?



END OF TASK



W115  
CONNECTOR P1  
SOCKET T  
(SOCKET U)



W115  
CONNECTOR P2  
SOCKET H  
(SOCKET I)




06ph280t

### 3-3 TROUBLESHOOTING CHART - CONTINUED

r. TRAVEL LOCK - CONTINUED (4) RAISE/UNLOCK LED WILL NOT LIGHT.

<b>INITIAL SETUP</b>	
<u>Tools</u> General mechanic's tool kit (SC 5180-90-N26) Multimeter (item 38, Appx F) Probe kit (item 35, Appx F)	<u>Equipment Conditions</u> Transmission access doors open (TM 9-2350-314-10)
	<u>Personnel Required</u> Two

- A**
1. Turn vehicle MASTER and TRAVEL LOCK power switches OFF (TM 9-2350-314-10).
  2. Remove RAISE/UNLOCK LED (TM 9-2350-314-10).
  3. Place multimeter red lead in LED socket center contact and black lead on ground.
  4. Turn vehicle MASTER and TRAVEL LOCK power switches ON (TM 9-2350-314-10).
  5. Place and hold travel lock switch in RAISE/UNLOCK position and check for voltage.




# 3-3 TROUBLESHOOTING CHART - CONTINUED

r. TRAVEL LOCK - CONTINUED (4) RAISE/UNLOCK LED WILL NOT LIGHT. - CONTINUED

CONTINUED FROM STEP A

**B** 1. Place and hold travel lock switch in RAISE/UNLOCK position.  
2. Listen to actuator motor.


Is actuator motor running?



Adjust RAISE/UNLOCK limit switch (para 16-12).



**C** 1. Release travel lock switch.  
2. Turn vehicle MASTER and TRAVEL LOCK power switches OFF (TM 9-2350-314-10).  
3. Disconnect harness W126 connector P2 from travel lock actuator.  
4. Place jumper lead between socket E and socket F.  
5. Turn vehicle MASTER and TRAVEL LOCK power switches ON (TM 9-2350-314-10).  
6. Place and hold travel lock switch in RAISE/UNLOCK position.

Does LOWER/LOCK LED light?



Replace travel lock actuator (para 16-10).

CONTINUED ON NEXT PAGE



06ph282t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

r. TRAVEL LOCK - CONTINUED (4) RAISE/UNLOCK LED WILL NOT LIGHT. - CONTINUED


CONTINUED FROM STEP C

- D**
1. Release travel lock switch.
  2. Turn vehicle MASTER and TRAVEL LOCK power switches OFF (TM 9-2350-314-10).
  3. Remove jumper from harness W126 connector P2.
  4. Disconnect harness W126 connector P1 at bow plate feed through.
  5. Check harness W126 for continuity as follows:
- | FROM CONNECTOR | TO CONNECTOR |
|----------------|--------------|
| P2 socket E    | P1 pin E     |
| P2 socket F    | P1 pin F     |

Is continuity present?



CONTINUED ON NEXT PAGE



06ph283

# 3-3 TROUBLESHOOTING CHART - CONTINUED


r. TRAVEL LOCK - CONTINUED (4) RAISE/UNLOCK LED WILL NOT LIGHT. - CONTINUED

CONTINUED FROM STEP D

**E**

1. Reconnect harness W126 connector P2 to travel lock actuator.
2. Disconnect harness W113 connector P2 from the bow plate feed through.
3. Check bow plate feed through sockets and pins for damage.

Are pins and sockets in good condition?







**F**

1. Reconnect harness W126 connector P1 to bow plate feed through.
2. Disconnect harness W115 connector P1 from harness W113 connector J1.
3. Check harness W113 for continuity as follows:

FROM CONNECTOR	TO CONNECTOR
P2 socket E	J1 pin M
P2 socket F	J1 pin R

Is continuity present?



06ph284t




CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED


r. TRAVEL LOCK - CONTINUED (4) RAISE/UNLOCK LED WILL NOT LIGHT. - CONTINUED

CONTINUED FROM STEP F

- G**
1. Reconnect harness W113 connector P2 to bow plate feed through.
  2. Disconnect harness W115 connector P2 from travel lock control box.
  3. Check harness W115 for continuity as follows:
- | <u>FROM CONNECTOR</u> | <u>TO CONNECTOR</u> |
|-----------------------|---------------------|
| P1 socket M           | P1 socket E         |
| P1 socket R           | P2 socket F         |



END OF TASK




06ph285t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

## s. WINTERIZATION KIT CIRCUIT

The winterization kit consists of a coolant heater (blower motor, flame detector switch, overheat thermostat, restriction thermostat, resistor ignitor, fuel control valve, shutoff solenoid, restriction solenoid), coolant pump, fuel pump, and control box. The diagram below shows the relationship of these components.

The winterization kit works whether the vehicle MASTER switch is ON or OFF. Placing the START/OFF/RUN switch in the START position energizes the coolant heater and causes the indicator on the control box to illuminate. Placing the START/OFF/RUN switch in the RUN position energizes the coolant pump and blower motor, causing the coolant to be circulated through the engine and battery compartment.



06ph286t



### 3-3 TROUBLESHOOTING CHART - CONTINUED


s. WINTERIZATION KIT CIRCUIT - CONTINUED (1) COOLANT HEATER DOES NOT OPERATE.

**INITIAL SETUP**


<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Engine and transmission access doors open (TM 9-2350-314-10)                  Battery access doors open (TM 9-2350-314-10)</p>
--	--

- A**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect coolant heater to bulkhead harness connector from coolant heater.
  3. Place multimeter red lead in coolant heater to bulkhead harness connector socket C and black lead to ground.
  4. Turn vehicle MASTER switch ON and heater control switch to start (TM 9-2350-314-10).
  5. Check for voltage.

Is voltage present?



CONTINUED ON NEXT PAGE




06ph287t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


s. WINTERIZATION KIT CIRCUIT - CONTINUED (1) COOLANT HEATER DOES NOT OPERATE. - CONTINUED

CONTINUED FROM STEP A

- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect bulkhead to control box harness connector from coolant heater to bulkhead harness at driver's compartment bulkhead.
  3. Check continuity by placing one multimeter lead in coolant heater to bulkhead harness connector pin C and other lead in coolant heater to bulkhead harness connector socket C.
- Is continuity present?



CONTINUED ON NEXT PAGE




06ph288t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


s. WINTERIZATION KIT CIRCUIT - CONTINUED      (1) COOLANT HEATER DOES NOT OPERATE. - CONTINUED

CONTINUED FROM STEP B

- |                     |   |
|---------------------|---|
| <b>C</b>            | <ol style="list-style-type: none"> <li>1. Disconnect bulkhead to control box harness lead 400 from heater control box connector.</li> <li>2. Place multimeter red lead in bulkhead to control box harness lead 400 connector socket and black lead to ground.</li> <li>3. Turn vehicle MASTER switch ON (TM 9-2350-314-10).</li> <li>4. Check for voltage.</li> </ol> |
| Is voltage present? |   |



CONTINUED ON NEXT PAGE



06ph289t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

S. WINTERIZATION KIT CIRCUIT - CONTINUED (1) COOLANT HEATER DOES NOT OPERATE. - CONTINUED


CONTINUED FROM STEP C

- D**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Reconnect bulkhead to control box harness lead 400 to heater control box.
  3. Disconnect bulkhead to control box harness connector from heater control box.
  4. Place multimeter red lead on control box connector pin C and black lead to ground.
  5. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  6. Turn heater control switch to START (TM 9-2350-314-10) and check for voltage.

Is voltage present?



END OF TASK



06ph290t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


s. WINTERIZATION KIT CIRCUIT - CONTINUED                      (2) HEATER BLOWER OPERATES BUT MOTOR DOES NOT.

**INITIAL SETUP**

Tools  
 General mechanic's tool kit  
 (SC 5180-90-N26)  
 Multimeter (item 38, Appx F)  
 Probe kit (item 35, Appx F)


- A**
1. Turn vehicle MASTER switch and heater control switch OFF (TM 9-2350-314-10).
  2. Disconnect lead 402C from heater fuel pump.
  3. Place multimeter red lead in lead 402C connector socket and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  5. Turn START/RUN switch to START (TM 9-2350-314-10).
  6. Turn HIGH/LOW switch to LOW and then to HIGH (TM 9-2350-314-10).
  7. Check for voltage in both positions.

Is voltage present in both positions?




- B**
1. Turn vehicle MASTER switch OFF (TM 9-2350-314-10).
  2. Disconnect bulkhead to control box harness connector from coolant heater to bulkhead harness at driver's compartment bulkhead.
  3. Check continuity by placing one multimeter lead on coolant heater to bulkhead harness lead 402C and other lead on coolant heater to bulkhead harness connector pin A.

Is continuity present?



CONTINUED ON NEXT PAGE



06ph291t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

S. WINTERIZATION KIT CIRCUIT - CONTINUED      (2) HEATER BLOWER OPERATES BUT MOTOR DOES NOT. - CONTINUED


CONTINUED FROM STEP B

- C**
1. Turn heater START/RUN switch OFF (TM 9-2350-314-10).
  2. Disconnect bulkhead to control box harness connector from heater control box.
  3. Place multimeter red lead on control box connector pin A and black lead to ground.
  4. Turn vehicle MASTER switch ON (TM 9-2350-314-10).
  5. Turn START/RUN switch to START (TM 9-2350-314-10).
  6. Turn HIGH/LOW switch to LOW and then to HIGH (TM 9-2350-314-10).
  7. Check for voltage in both positions.

Is voltage present in both positions?



END OF TASK




### 3-3 TROUBLESHOOTING CHART - CONTINUED


s. WINTERIZATION KIT CIRCUIT (3) HEATER MOTOR OVERHEATS.  
- CONTINUED

<p><u>INITIAL SETUP</u></p> <p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  Multimeter (item 38, Appx F)                  Probe kit (item 35, Appx F)</p>	<p><u>Equipment Conditions</u>                  Transmission access doors open (TM 9-2350-314-10)</p>
--	---

- |                     |   |
|---------------------|---|
| <b>A</b>            | <ol style="list-style-type: none"> <li>1. Disconnect lead 403B from coolant pump.</li> <li>2. Place multimeter red lead on lead 403B connector and black lead to ground.</li> <li>3. Start heater (TM 9-2350-314-10).</li> <li>4. When heater indicator light comes on, turn HIGH/LOW switch to LOW (TM 9-2350-314-10).</li> <li>5. Check for voltage.</li> </ol> |
| Is voltage present? |   |



**END OF TASK**



06ph293t

### 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE).

#### NOTE

This test set is now designated as STE-ICE-R (Reprogrammable). The "R" indicates its circuit boards can now be reprogrammed at depot. There are no other changes to this test set. For testing purposes, STE-ICE and STE-ICE-R are the same.

#### 3-4.1 Introduction.

The Simplified Test Equipment for Internal Combustion Engines (STE/ICE) connects to the M109A6 Diagnostic Cable Assembly (DCA) located in the driver's compartment. The DCA reduces the mechanic's need to install test transducers and leads to perform engine and engine component diagnostic checks. This section covers STE/ICE setup, test procedures, and troubleshooting using the vehicle's DCA as well as tests involving the installation of transducer kits (TK).

#### 3-4.2 General.

STE/ICE provides measurements on voltage resistance, pressure, temperature, and speed to analyze the condition of an engine system.

STE/ICE also provides a thorough preventive maintenance check on the M109A6 engine as part of service upon receipt and as an annual check in the PMCS.

#### 3-4.3 Description of STE/ICE Equipment.

The STE/ICE set consists of a vehicle test meter (VTM), five cable assemblies, transducer kit (TK), test probe kit, manual, and transit case.

- a. Vehicle Test Meter - The VTM is the diagnostic meter of STE/ICE used for testing electrical and mechanical components. The VTM has three switches, readout display, flip cards, and four cable connectors.
  - (1) Switches - The three switches are PUSH ON/PULL OFF, TEST SELECT, and TEST. The PUSH ON/PULL OFF switch controls power to the VTM. TEST SELECT is two switches with 10 positions used to select which test is to be done. The TEST button has two uses: when it is pressed and released, it initiates a selected test and when it is pressed and held, it initiates an offset test.
  - (2) Readout Display - During testing, the display can give five different types of messages with up to four characters per message. The messages are error, status, numerical, prompting, and confidence test error.
  - (3) Flip Cards - The flip cards are attached to the front of the VTM. The cards list test numbers, messages, and some procedures. They can be used as a quick reference.
  - (4) Cable Connectors - The four cable connectors on the VTM are DCA/PWR J1, transducer cable connectors J2TK and J3TK, and VOLTS/OHMS J4.
    - DCA/PWR connector J1 - used to connect the VTM to either a vehicle diagnostic connector with the DCA cable W1 or to a DC power source with power cable W5.
    - Transducer cable connectors J2TK and J3TK - used to connect transducer cables W4 to VTM. Power and signals are routed through these connectors. Both connectors may be used when a test requires two measurements to be made at the same time.
    - VOLTS/OHMS connector J4 - used to connect test probe cable W2 to VTM for voltage and resistance tests.



### 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

#### 3-4.3 Description of STE/ICE Equipment - Continued

- b. Cable Assemblies - The cables used with STE/ICE are:
  - (1) Diagnostic Connector Assembly (DCA) Cable W1 - This cable is used to power the VTM and provide access to test points and sensors connected to the DCA.
  - (2) Test Probe Cable W2 - The Test Probe cable is used for measuring voltages, frequency, resistance and continuity, first peak series, and compression unbalance tests.
  - (3) Ignition Adapter Cable W3 - This cable is used to measure dwell angle, points voltage, engine rpm, and power tests.
  - (4) Transducer Cables W4 - These cables are used as extensions to connect the VTM to a pressure transducer, pulse tachometer, current probe, or ignition adapter cable.
  - (5) Power Cable W5 - Used to power VTM when cable W1 is not being used.
- c. Transducer Kit (TK) - The TK is stored in a tray in the top of the Transit Case and has transducer, adapters, and fittings to be used with the STE/ICE.
- d. Test Probe Kit - The Test Probe Kit has a variety of probes and clips that can be attached to Test Probe Cable W2 to make it easier to take different types of measurements.
- e. Manual - TM 9-4910-571-12&P has operating instructions, operator and organizational maintenance instructions, and repair parts and special tools information.
- f. Transit Case - The STE/ICE with all necessary accessories and instructions is housed in this portable protective transit case.

#### 3-4.4 Engine Testing.

The STE/ICE equipment is used for two different test methods. The PMCS tests check the general condition of the howitzer engine. Using STE/ICE for troubleshooting will isolate a malfunction down to the defective part or assembly.

##### 3.4.4.1 PMCS Test Method.

The PMCS Test consists of a pre-test inspection and STE/ICE testing.

- a. Pre-test Inspections - Before using STE/ICE do the following inspections:
  - (1) Fan Belts - Check for proper tension. Replace if cracked or frayed.
  - (2) Ignition Cables - Make sure they are in good condition and securely connected.
  - (3) Oil Level - Check oil. If low, fill to proper level.
  - (4) Fuel Level - Make sure there is enough fuel for testing.
  - (5) Radiator - Check water level. If low, fill to proper level.
  - (6) Battery - If the case is cracked or terminal post is damaged, replace battery. Clean off any corrosion. Make sure connections to ground and starter motor are clean and in good condition. Check electrolyte level. If low, fill to proper level with distilled water.

### 3-4.4 Engine Testing - Continued

- b. STE/ICE Testing. STE/ICE testing has two different sequences of tests: PMCS and Troubleshooting. A PMCS tree is a logical sequence of tests performed to determine the general condition of the engine. PMCS trees are arranged so testing starts with PMCS-(1) and goes through each PMCS tree until the test is terminated by a pass or failure. If testing is terminated by the last PMCS tree, then the vehicle has no identifiable problem. If any test is terminated by a failure, you will be sent to a Troubleshooting tree for more testing and troubleshooting to determine the cause of the failure.

Rules to follow when using the PMCS test methods:

#### NOTE

The DCA PMCS trees are the primary troubleshooting trees. The TK PMCS trees are to be used only when the DCA connector and/or wiring is faulty.

- (1) Select the proper PMCS (DCA or TK) tree.
  - (2) Always start with PMCS tree #1. Do not start in the middle of any tree.
  - (3) Complete each step in a tree. Do not skip any procedure or instructions.
  - (4) If a PMCS tree fails a test, go to the specified troubleshooting tree or higher level of maintenance.
  - (5) After correcting a failed test with a troubleshooting tree, return to PMCS test #1 and restart testing to make sure there are no other problems with the vehicle.
  - (6) Each PMCS tree test depends on the passing of a previous test. Do not skip any test under any circumstance.
- c. Vehicle Test Card (VTC). When familiar with the STE/ICE procedures, the vehicle test card can be used as a quick reference. The front of the test card has all of the information the user will need to do common measurements on the vehicle. The card has logical order (from top to bottom) of steps from powering up the VTM to completing a series of tests.

The top of the card tells you how to power up STE/ICE for the vehicle. Next, a table lists many measurements that can be useful when troubleshooting the vehicle. This table has the VTM test number, required offset test limits, engine operating condition, required special connections, expected pass/fail limits, and units of measurement. The order of the measurements in this table allow for the first measurements to be taken with the engine off. This makes sure the starting system of the vehicle is in working order. Order of the other measurements are:

- (1) Engine running but not warm
- (2) Engine running and warm
- (3) Engine not running but warm
- (4) Miscellaneous

Hookups for measurements used to troubleshoot the vehicle are on the back of the VTC. Measurement that require special hookups are also done on the back of the VTC.

To begin the PMCS test method, do the pre-test inspections and then go to PMCS tree #1.

### 3-4.4 Engine Testing - Continued

#### 3-4.4.2 STE/ICE Troubleshooting Method.

- a. STE/ICE engine troubleshooting uses only troubleshooting trees. When an engine malfunction is recognized, using the "Quick Guide to Troubleshooting" index will send you to a specific troubleshooting tree to isolate the cause of the malfunction.

To start the STE/ICE troubleshooting method, do the following:

#### **NOTE**

The DCA troubleshooting trees are the primary troubleshooting trees. The TK troubleshooting trees are to be used only when the DCA connector and/or wiring is faulty.

- (1) Select the proper troubleshooting (DCA or TK) tree.
- (2) Do PMCS tree #1 to make sure STE/ICE is in working order.
- (3) Do troubleshooting tree listed in "Quick Guide to Troubleshooting" for malfunction.

Follow the following rules when doing STE/ICE troubleshooting:

- (1) Do not enter a troubleshooting tree in the middle. Always start at the beginning.
- (2) Follow all instructions and procedures of a PMCS tree.
- (3) After correcting a problem with a troubleshooting tree, do any testing necessary to make sure the problem no longer exists.

TEST INSPECTION	POWERING UP VTM	
	DCA MODE	TK MODE
1. Oil Level 2. Coolant Level 3. Fuel Level 4. Battery Electrolyte Level	1. Connect DCA cable W1 to VTM 2. Connect DCA cable W1 to DCA connector 3. Perform confidence test 66/99. 4. Enter vehicle VID number using test 60.	1. Connect VTM to cable W5 2. Connect cable W5 to batteries 3. Perform confidence test 66/99. 4. Enter vehicle VID number using test 60. (See note)
Keep a log of all performance parameters. This is the best indication of system deterioration or failure. NOTE: To use TK mode, remove the required DCA transducers to install STE/ICE Kit transducers.		

PMCS STE/ICE TEST CARD

MEASUREMENT NAME	DCA VTM TEST NOS.	VTM OFFSET LIMITS	OPERATING CONDITION	TK VTM TEST NOS.	SPECIAL CONNECTION REQUIRED	LIMITS		UNITS
						MIN	MAX	
Battery Voltage	67	-	Engine OFF	67	↑ Fig.4	22	-	Volts
Current First Peak	72	+225	Crank On Go	72	↑ Fig.4	875	1680	Amps
Vehicle Gage Oil Pressure	-	-	Idle-Use Test 10 to check IDM RPM	-	Pulse Tachometer	10	-	PSI
Charging Voltage	01, 67		Lights and ACC on 1000-1200 RPM	01, 67	↓	26.5	28.5	Volts
Vehicle Gage Cool Temp	-	-	Warm Engine	-	-	170	185	_F
Vehicle Gage Oil Temp	-	-	Warm Engine	-	↓	30	50	F
Engine RPM Average	10	-	Idle	10	↓	550	600	RPM
Engine RPM Average	10	-	Governor	10	↓	2350	2500	RPM
Power	13	-	Warm Engine	13	↓	60**	-	%
Compression Unbalance	14	-	Warm Engine Crank on Go	14	-	-	10	%
Cranking RPM	10	-	Cranking	10	↓	100	-	RPM
Cranking Voltage	67	-	Cranking	67	↑	18	-	Volts
Cranking Current	71	±225	Cranking	90	↑	350	550	Amps
Battery Pack Internal Resistance	73	±225	Crank on Go	73	↑	-	13	Milliohms
Starter Circuit Resistance	74	±225	Crank on Go	74	↑	3	25	Milliohms
Battery Pack Resistance Charge	75	±225	Crank on Go	75	↑ Current Probe	-	50	Milliohms/sec

\* Used when DCA is not operable or not applicable to test.

\*\* Typical power % for engine with a turbocharger and fuel limiting device is 68%. If power % falls below 60%, you should investigate further.

VEHICLE TEST CARD - VID11

### 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

a. STE/ICE PMCS (1) VTM CONNECTIONS AND CHECKOUT FOR DCA.

**WARNING**  
Do not connect or disconnect VTM while engine is running.

**CAUTION**  
Connect connector P1 of DCA cable W1 to J1 on the VTM before connecting to the diagnostic connector.

Connect battery to VTM:



1. Pull VTM power switch to the OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 connector P2 to harness W100 connector P4 (DCA receptacle).
4. Make sure all connections are correct and tightened.

**NOTE**  
Place the VTM so only its rubber feet touch the vehicle, or do all testing with the vehicle MASTER switch ON. This will prevent sparking during testing. Sparking will interrupt testing, but will not hurt the VTM.

**A**

1. Push power switch on VTM to ON position.
2. Make sure VTM display shows ".8.8.8.8" for two seconds and then changes to "- - - -".

Does VTM display show ".8.8.8.8" and then change to "- - - -"?



06ph304t

CONTINUED ON NEXT PAGE

# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED


a. STE/ICE PMCS - CONTINUED (1) VTM CONNECTIONS AND CHECKOUT FOR DCA. - CONTINUED

CONTINUED FROM STEP A

**B**

1. Pull VTM power switch to OFF position.
2. Check and clean battery connections and all interconnecting cables.
3. Push VTM power switch to ON.


Does VTM display show ".8.8.8.8" and then change to "----"?



**C**



1. Pull VTM power switch to OFF.
2. Disconnect DCA cable W1 from harness W100 connector P4 (DCA receptacle) and from STE/ICE VTM connector J1.
3. Connect DCA cable W5 to VTM connector J1.
4. Connect DCA cable W5 to known good battery.
5. Push VTM power switch to ON.

Does VTM display show ".8.8.8.8" and then change to "----"?



1. Check battery electrolyte level (TM 9-2350-314-10).
2. Clean battery terminals (TM 9-2350-314-10).
3. Check battery specific gravity (Table 2-1, PMCS, item 5)
4. If necessary, charge batteries.
5. Return to step A.

If the problem happens again, check for broken or loose connections in the DCA wiring from the battery or in cable W1.



06ph305t

CONTINUED ON NEXT PAGE


# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

a. STE/ICE PMCS - CONTINUED (1) VTM CONNECTIONS AND CHECKOUT FOR DCA. - CONTINUED

CONTINUED FROM STEP B



**D** 1. Dial 66 into TEST SELECT to run confidence test.  
2. Press and release TEST button.

Does VTM show and hold "0066"?



**E** 1. Pull VTM power switch to OFF.  
2. Do step A one time.  
3. Do step D again, one time.

Does VTM show and hold "0066"?



06ph306t

CONTINUED ON NEXT PAGE

# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED


a. STE/ICE PMCS - CONTINUED (1) VTM CONNECTIONS AND CHECKOUT FOR DCA. - CONTINUED

CONTINUED FROM STEPS D AND E

**F** 1. Dial 99 into TEST SELECT.  
2. Press and release TEST button.


Does VTM show "0099" and ".8.8.8.8"?

**NOTE**  
All numbers of the display should be lighted. If some parts are not, go to TM 9-4910-571-12&P to replace module.




**G** 1. Make sure several series of numbers are showing on display. This means the VTM is going through confidence test.  
2. Look for VTM to show and hold the word "PASS".

Does VTM show and hold the word "PASS"?



**NOTE**  
VTM can fail confidence test because of a bad transducer. If failure happens when connected with cable W1, disconnect all cables from VTM and connect only W5. Clip W5 to vehicle batteries. If VTM passes test, a transducer is bad in the DCA. Continue testing with TK PMCS troubleshooting trees starting with para 3-4.a(1a). If VTM still fails, VTM has failed internally.

CONTINUED ON NEXT PAGE



06ph307t



# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED


a. STE/ICE PMCS - CONTINUED (1) VTM CONNECTIONS AND CHECKOUT FOR DCA. - CONTINUED

CONTINUED FROM STEP G


- H**
1. Dial 60 into TEST SELECT.
  2. Press and release TEST button. Message "UEH" should be shown.
  3. When "UEH" message is shown, dial in the identification number 11.
  4. Press and release TEST button.

Does VTM display identification number 11?


**NOTE**  
If error message "E010" is shown, wrong VID has been entered.



**I** Does VTM show an error message?



END OF TASK



06ph308t

# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

a. STE/ICE PMCS - CONTINUED (1a) VTM CONNECTIONS AND CHECKOUT FOR TK.

**WARNING**  
Do not connect or disconnect VTM while engine is running.

**CAUTION**  
Connect connector P1 of power cable W5 to J1 on the VTM before connecting clip leads to battery.

Connect battery to VTM:


1. Pull VTM power switch to the OFF position.
2. Connect cable W5 connector P1 to VTM connector J1.
3. Connect red clip lead to positive terminal of battery and connect black lead to negative terminal.

**NOTE**  
Place the VTM so only its rubber feet touch the vehicle, or do all testing with the vehicle MASTER switch on. This will prevent sparking during testing. Sparking will interrupt testing, but will not hurt the VTM.


**A**

1. Push power switch on VTM to ON position.
2. Make sure VTM display shows ".8.8.8.8" for two seconds and then changes to "- - - -".

Does VTM display show ".8.8.8.8" and then change to "- - - -"?



CONTINUED ON NEXT PAGE



06ph309t

### 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED


a. STE/ICE PMCS - CONTINUED (1a) VTM CONNECTIONS AND CHECKOUT FOR TK. - CONTINUED

CONTINUED FROM STEP A

**B**

1. Pull VTM power switch to OFF position.
2. Check and clean battery connections and all interconnecting cables.
3. Push VTM power switch to ON.


Does VTM display show ".8.8.8.8" and then change to "- - - -"?



**C**


1. Pull VTM power switch to OFF.
2. Disconnect DCA cable W5 from battery and connect to a known good battery.
3. Push VTM power switch to ON.

Does VTM display show ".8.8.8.8" and then change to "- - - -"?



1. Check battery electrolyte level (TM 9-2350-314-10).
2. Clean battery terminals (TM 9-2350-314-10).
3. Check battery specific gravity (Table 2-1, PMCS item 5).
4. If necessary, charge batteries.
5. Return to step A.

CONTINUED ON NEXT PAGE



06ph310t


# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

a. STE/ICE PMCS - CONTINUED      (1a) VTM CONNECTIONS AND CHECKOUT FOR TK. - CONTINUED

CONTINUED FROM STEPS A AND C


**D** 1. Dial 66 into TEST SELECT to run confidence test.  
2. Press and release TEST button.

Does VTM show and hold "0066"?



**E** 1. Pull VTM power switch to OFF.  
2. Do step A one time.  
3. Do step D again, one time.


Does VTM show and hold "0066"?




**F** 1. Dial 99 into TEST SELECT.  
2. Press and release TEST button.

Does VTM show "0099" and ".8.8.8.8"?

**NOTE**  
All numbers of the display should be lighted. If some parts are not, go to TM 9-4910-571-12&P to replace module.



CONTINUED ON NEXT PAGE



06ph311t


# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

a. STE/ICE PMCS - CONTINUED (1a) VTM CONNECTIONS AND CHECKOUT FOR TK. - CONTINUED

CONTINUED FROM STEP F

**G** 1. Make sure several numbers are showing on display. This means the VTM is going through confidence test.  
2. Look for VTM to show and hold the word "PASS".


Does VTM show and hold the word "PASS"?



**NOTE**  
VTM can fail confidence test because of a bad transducer. If failure happens when connected with cable W5, disconnect all cables from J2, J3, and J4 and try again. If it passes, a transducer is bad. If it fails, the VTM has failed internally.

**H** 1. Dial 60 into TEST SELECT.  
2. Press and release TEST button. Message "UEH" should be shown.  
3. When "UEH" message is shown, dial in the identification number 11.  
4. Press and release TEST button.





Does VTM display identification number "11"?



**I** Does VTM show an error message?

yes: Do error message fault isolation per TM 9-4910-571-12&P.

no: Replace faulty STE/ICE. (TM 9-4910-571-12&P)



06ph312t

CONTINUED ON NEXT PAGE

### 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

a. STE/ICE PMCS - CONTINUED (1a) VTM CONNECTIONS AND CHECKOUT FOR TK. - CONTINUED

CONTINUED FROM STEP H

- J**
1. Dial 67 into TEST SELECT, press and release TEST button.
  2. Make sure VTM shows battery voltage is above +22 Vdc.
- Is voltage above +22 V dc?

yes no

Check VTM connections, clean battery connections, check specific gravity, and charge batteries, if necessary. Troubleshoot W5 in accordance with TM 9-4910-571-12&P. After repairs, start para 3-4.a(1a) over.

**WARNING**

Protective fan screens must be installed prior to doing maintenance in the engine compartment when the vehicle is running or engine is in ground hop mode. Contact with rotating fan can cause injury.

**WARNING**

To prevent injury to personnel, turn engine OFF before installing pulse tachometer.

**CAUTION**

Clean all mounting surfaces before you install the transducer to keep foreign substances from damaging the engine or the transducer.




**NOTE**

If RPM or power tests vary more than  $\pm 5\%$ , tach drive adapter and pulse tachometer should be removed. You might have to rotate the tach speed adapter to connect the pulse tachometer.

- K**
1. Install fan protective screens (para 4-1.c).
  2. Disconnect tachometer cable from engine (para 20-2).
  3. Install pulse tachometer on engine.
  4. Connect cable W4 connector P1 to VTM connector J2.
  5. Connect cable W4 connector P2 to the connector on the pulse tachometer. Make sure cable W4 is clear of belts and fans.

Go to para 3-4.a (2a).

**END OF TASK**




06ph313t






### 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

a. STE/ICE PMCS - CONTINUED (2) CURRENT FIRST PEAK TEST - DCA.

- A**
1. Turn vehicle MASTER switch OFF.
  2. Dial 72 into TEST SELECT.
  3. Press and hold TEST until the message "CAL" appears on the display and release TEST button.
  4. Wait for offset value to appear.
- Is offset value in the limits of -225 to +225?



- B**
1. Press and release TEST button.
  2. Wait for message "GO" to show on display.
- NOTE**  
If ".9.9.9.9" shows, go to TM 9-4910-571-12&P for offset fault isolation.
3. When "GO" shows on display, pull and hold engine fuel shutoff handle and depress the starter switch until "OFF" or "E013" is on display.
- NOTE**  
If VTM loses power and comes on again showing "- - - -" on display after cranking, go to para 3-4.b(4).



06ph314t

END OF TASK


### 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

a. STE/ICE PMCS - CONTINUED

(2a) CURRENT FIRST PEAK TEST - TK.


- A**
1. Turn vehicle MASTER switch OFF.
  2. Connect cable W4 connector P1 to VTM connector J3 and connect cable W4 connector P2 to connector on current probe.
  3. Clamp the current probe around leads 81A from battery to master relay. Point arrow on the probe to the starter.
  4. Make sure the probe is closed.
  5. Dial 72 into TEST SELECT.
  6. Press and hold TEST until the message "CAL" appears on the display, and release TEST button.
  7. Wait for offset value to appear.

Is offset value in the limits of -225 to +225?





- B**
1. Press and release TEST button.
  2. Wait for message "GO" to show on display.
- NOTE**  
If ".9.9.9.9" shows, go to TM 9-4910-571-12&P for offset fault isolation.
3. When "GO" shows on display, pull and hold engine fuel shut off handle and depress the starter switch until "OFF" or "E013" is on display.
- NOTE**  
If VTM loses power and comes on again showing "- - - -" on display after cranking, go to para 3-4.b(20).

Is current within 875-1680 amps?



END OF TASK



06ph315t



**3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED**


a. STE/ICE PMCS - CONTINUED (3) ENGINE START AND LUBRICATION CHECK - DCA.

**WARNING**  
Do not remove radiator cap when engine is hot to prevent serious injury to personnel.

**CAUTION**  
To prevent equipment damage, check oil level and turn all hydraulic power switches OFF before starting the engine.

**NOTE**  
Check coolant level and battery electrolyte level. Add coolant and distilled water as necessary.

**A** Start engine using the proper procedures in TM 9-2350-314-10.




# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED


a. STE/ICE PMCS - CONTINUED (3) ENGINE START AND LUBRICATION CHECK - DCA. - CONTINUED

CONTINUED FROM STEP A




**B** Check engine oil pressure gage to make sure pressure is at least 10 psi.  
Is pressure at least 10 psi?



**C** Check battery gage for proper voltage (TM 9-2350-314-10).  
Does battery gage read normal (TM 9-2350-314-10)?



**D** Check the rest of the vehicle gages for normal readings (TM 9-2350-314-10).  
Do gages have normal readings (TM 9-2350-314-10)?



06ph316t

**END OF TASK**

# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED


a. STE/ICE PMCS - CONTINUED (3a) ENGINE START AND LUBRICATION CHECK - TK.

**WARNING**  
To prevent serious injury to personnel, do not remove radiator cap when engine is hot.


**CAUTION**  
To prevent equipment damage, check oil level and turn all hydraulic power switches OFF before starting the engine.

**NOTE**  
Check coolant level and battery electrolyte level. Add coolant and distilled water as necessary.


**A** Start engine using the proper procedures in TM 9-2350-314-10.  
Does engine start?



**B** Check engine oil pressure gage to make sure pressure is at least 10 psi.  
Is pressure at least 10 psi?



CONTINUED ON NEXT PAGE




06ph317t

# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED




a. STE/ICE PMCS - CONTINUED (3a) ENGINE START AND LUBRICATION CHECK - TK. - CONTINUED

CONTINUED FROM STEP B

**C** Check battery gage for proper voltage (TM 9-2350-314-10).  
Does battery gage read normal (TM 9-2350-314-10)?



**D** Check the rest of the vehicle gages for normal readings (TM 9-2350-314-10).  
Do gages have normal readings (TM 9-2350-314-10)?




06ph318t

END OF TASK


### 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

a. STE/ICE PMCS - CONTINUED (4) CHARGING VOLTAGE TEST - DCA.


- A**
1. Dial 01 into TEST SELECT and press and release TEST button.
  2. When VTM shows "CON" on display, dial 67 into TEST SELECT and press and release TEST button.
- NOTE**  
VTM will show battery voltage and rpm alternately. If VTM does not show rpm, a connection may be loose. Check connection between STE/ICE and pulse tachometer in driver's compartment. If rpm is still not displayed, replace pulse tachometer.
3. Start engine (TM 9-2350-314-10).
  4. Adjust rpm to 1000-1200 rpm.
  5. Turn ON headlights and accessories to load charging system.
  6. Watch the display to make sure battery voltage is between 26.5 and 28.5 V dc.




Is voltage between 26.5 and 28.5 V dc?



**B** Check battery gage for normal reading (TM 9-2350-314-10).  
Does battery gage indicate normal (TM 9-2350-314-10)?



END OF TASK





06ph319t

### 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED


a. STE/ICE PMCS - CONTINUED

(4a) CHARGING VOLTAGE TEST - TK.

- A**
1. Dial 01 into TEST SELECT and press and release TEST button.
  2. When VTM SHOWS "CON" on display, dial 67 into TEST SELECT and press and release TEST button.
- NOTE**  
VTM will show battery voltage and rpm alternately. If VTM does not show rpm, a connection may be loose. Check connection between STE/ICE and pulse tachometer in driver's compartment. If rpm is still not displayed, replace pulse tachometer.
3. Start engine (TM 9-2350-314-10).
  4. Adjust rpm to 1000-1200 rpm.
  5. Turn ON headlights and accessories to load charging system.
  6. Watch the display to make sure battery voltage is between 27.5 and 28.5 V dc.




Is voltage between 27.5 and 28.5 V dc?






**B** Check battery gage for a normal reading (TM 9-2350-314-10).

Does battery gage indicate normal (TM 9-2350-314-10)?



**C** Is battery voltage low?

Is voltage low?



06ph319ta


END OF TASK

### 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

a. STE/ICE PMCS - CONTINUED (5) COOLANT CHECK/ENGINE OIL PRESSURE GAGE TEST - DCA.


- A**
1. Check vehicle for oil, fuel, and coolant leaks, repair as necessary.
  2. Warm up the engine and check ENGINE WATER TEMP gage.

Does ENGINE WATER TEMP gage read between 170° and 185° F (76° and 85° C)?





- B**
1. Dial 10 into TEST SELECT; press and release TEST.
  2. Increase engine rpm to 2100 rpm on VTM display.
  3. Check engine OIL PRESSURE gage.

Is oil pressure between 50 and 70 psi (344.75 and 482.65 kpa).



END OF TASK



06ph320t

### 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

a. STE/ICE PMCS - CONTINUED

(5a) COOLANT CHECK/ENGINE OIL PRESSURE GAGE TEST - TK.

**NOTE**

If VTM does not display engine rpm, isolate fault is pulse tachometer (TM 9-4910-571-12&P).

- A**
1. Check vehicle for oil, fuel, and coolant leaks, repair as necessary.
  2. Warm up the engine and check water temperature gage.

Does temperature gage read between 170° and 185° F (76° and 85° C)?



If temperature is above 185° F (85° C), go to QUICK GUIDE and troubleshoot for engine and cooling system high temperature. If temperature is below 170° F (76° C), go directly to para 3-4.b(21).

- B**
1. Dial 10 into TEST SELECT; press and release TEST.
  2. Increase engine rpm to 2100 rpm on VTM display.
  3. Check engine oil pressure gage.



Is oil pressure between 50 and 70 psi (344.75 and 482.65 kpa).



Go to para 3-4.a(6a).

Go to para 3-4.b(17).

**END OF TASK**



06ph320ta



# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED


a. STE/ICE PMCS - CONTINUED (6) GOVERNOR CHECK/POWER TEST - DCA.

**CAUTION**  
To avoid possible damage to the engine, check governor operation before doing Power Test.

**NOTE**  
Before doing Power Test, engine must be at normal operating temperature.

- A**
1. While watching the VTM, increase engine speed to maximum governor speed of 2350-2500 rpm.
  2. Press accelerator to full throttle.

Does engine rpm stay between 2350-2500 rpm?





**CAUTION**  
Do not do Power Test if engine temperature is above the normal operating temperature to avoid possible engine damage.

- B**
1. Dial 13 into TEST SELECT; press and release TEST.
  2. When prompting message "CIP" shows on display, press down and hold accelerator until the VTM shows "OFF". Then release accelerator.
  3. A number will show on VTM. This number is equal to the percentage of power. Compare this number with the following table:

% POWER: MINIMUM TEST LIMIT		
0-2000 FT	2000-4000 FT	ABOVE 4000 FT
75%	68%	60%

Is power limit in the above table?



06ph323t

### 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

a. STE/ICE PMCS - CONTINUED (6a) GOVERNOR CHECK/POWER TEST - TK.

**CAUTION**


To avoid possible damage to the engine, check governor operation before doing Power Test.

**NOTE**

Before doing Power Test, engine must be at normal operating temperature.

- A**
1. While watching the VTM, increase engine speed to maximum governor speed of 2350-2500 rpm.
  2. Press accelerator to full throttle.

Does engine rpm stay between 2350-2500 rpm?



**CAUTION**

Do not do Power Test if engine temperature is above the normal operating temperature to avoid possible engine damage.


**NOTE**

Engine speed must be below 1000 rpm.


- B**
1. Dial 13 into TEST SELECT; press and release TEST.
  2. When prompting message "CIP" shows on display, press down and hold accelerator until the VTM shows "OFF". Then release accelerator.
  3. A number will show on VTM. This number is equal to the percentage of power. Compare this number with the following table:

% POWER: MINIMUM TEST LIMIT		
0-2000 FT	2000-4000 FT	ABOVE 4000 FT
75%	68%	60%

Is power limit in the above table?



**END OF TASK**




06ph324t

# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED



a. STE/ICE PMCS - CONTINUED (7) IDLE SPEED CHECK - DCA.

- A**
1. Dial 10 into TEST SELECT; press and release TEST.
  2. Adjust engine idle to 550-600 rpm.
  3. Watch the VTM display for 10 seconds to make sure idle speed stays between 550 and 600 rpm.
- Does idle speed stay between 550-600 rpm?



**B** Check throttle linkage (para 5-17).

Is linkage correct?




06ph325t

END OF TASK


# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED

a. STE/ICE PMCS - CONTINUED (7a) IDLE SPEED CHECK - TK.


- A**
1. Dial 10 into TEST SELECT; press and release TEST.
  2. Adjust engine idle to 550-600 rpm.
  3. Watch the VTM display for 10 seconds to make sure idle speed stays between 550 and 600 rpm.
- Does idle speed stay between 550-600 rpm?



- B** Check throttle linkage (para 5-19).
- Is throttle linkage correct?



**END OF TASK**



06ph325ta

# 3-4 SIMPLIFIED TEST EQUIPMENT FOR INTERNAL COMBUSTION ENGINES (STE/ICE) - CONTINUED


a. STE/ICE PMCS - CONTINUED (8) COMPRESSION UNBALANCE TEST - DCA.

**NOTE**

- Before doing compression unbalance test, engine must be at normal operating temperature.
- To prevent discharging batteries, do not do more than two (2) compression unbalance tests in a row.

- A**
1. Shut off fuel supply (TM 9-2350-314-10).
  2. Crank engine with no fuel for 5 seconds to clear cylinders.
  3. Dial 14 into TEST SELECT and press and release TEST button.

Does prompting message "GO" show on display?



Make sure VTM is operating properly (TM 9-4910-571-12&P).

- B**
1. Pull and hold fuel shut off handle (TM 9-2350-314-10).
  2. Crank engine and watch VTM to make sure it shows "- - - -" on display.
  3. Stop cranking engine when VTM shows "OFF" or "E013".
  4. Wait for VTM to display a number.

Is a number on VTM display?



If the number is between 0 and 10, PMCS trees are completed.





Does the VTM display "GO" or "FAIL"?



If "GO", do step "B" again. If "FAIL", warm up engine and charge batteries, then do Step "B" again.

If a number higher than 10 or if "GO" or "FAIL" did not appear, notify direct support maintenance.

**END OF TASK**





06ph327t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING (1) GENERATOR NEGATIVE CABLE DROP - TEST 84.

<p><u>Tools</u>                  General mechanic's tool kit                  (SC 5180-90-N26)                  STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u>                  Vehicle MASTER switch ON                  (TM 9-2350-314-10)</p>
--	--

1. Pull power switch on VTM to OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
4. Push power switch on VTM to ON position.
5. Do confidence test 66/99 (para 3-4.a(1)).
6. Dial GO into TEST SELECT.
7. Press and release TEST; message "UEH" should be displayed.
8. Enter Vehicle ID (VID) number 11.
9. Enter 01 into TEST SELECT to view rpm and voltage alternately on the VTM during testing. Press TEST and "CON" should show on VTM.
10. Enter 84 into TEST SELECT and press TEST. Record test results and check limits on VTM.
11. Start engine (TM 9-2350-314-10). Increase engine rpm to 1000 to 1200 rpm.
12. Record test results and check limits on VTM.




END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED


b. STE/ICE TROUBLESHOOTING (2) STARTER CIRCUIT RESISTANCE - TEST 74.  
- CONTINUED

<p><u>Tools</u> General mechanic's tool kit (SC 5180-90-N26) STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u> MASTER switch ON (TM 9-2350-314-10)</p>
---	--

1. Pull power switch on VTM to OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 to harness W101 connector P4 (DCA receptacle).
4. Push power switch on VTM to ON position.
5. Do confidence test 66/99 (para 3-4.a(1)).
6. Dial 60 into TEST SELECT.
7. Press and release TEST; message "UEH" should be displayed.
8. Enter Vehicle ID (VID) number 11.
9. Enter 74 into TEST SELECT; press TEST until "CAL" appears.
10. Press and release TEST.
11. When "GO" shows on VTM, crank engine while holding fuel shutoff control handle.
12. When VTM shows "OFF", stop cranking engine. Record results and check limits.



Are results between 3 and 25 milliohms?



**END OF TASK**


06ph329t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


b. STE/ICE TROUBLESHOOTING (3) BATTERY INTERNAL RESISTANCE (DCA) - TEST 73.  
- CONTINUED

<p><u>Tools</u> General mechanic's tool kit (SC 5180-90-N26) STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u> Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
---	--

1. Pull power switch on VTM to OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 connector to harness W100 connector J1.
4. Push power switch on VTM to ON position.
5. Do confidence test 66/99 (para 3-4.a(1)).
6. Dial 60 into TEST SELECT.
7. Press and release TEST; message "UEH" should be displayed.
8. Enter Vehicle ID (VID) number 11.
9. Enter 73 into TEST SELECT; press and hold TEST until "CAL" appears.
10. Press and release TEST.
11. When "GO" shows on VTM, crank engine while holding fuel shutoff control handle out.
12. When VTM shows "OFF", stop cranking engine.
13. Record results and check limits.



Is reading less than 13 milliohms?



**END OF TASK**





# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING (4) BATTERY RESISTANCE CHANGE - TEST 75.  
- CONTINUED

<p><u>Tools</u> General mechanic's tool kit (SC 5180-90-N26) STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u> Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
---	--

1. Pull power switch on VTM to OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 to harness W100 connector J1 (DCA receptacle).
4. Push power switch on VTM to ON position.
5. Do confidence test 66/99 (para 3-4.a(1)).
6. Dial 60 into TEST SELECT.
7. Press and release TEST; message "UEH" should be displayed.
8. Enter Vehicle ID (VID) number 11.
9. Enter 75 into TEST SELECT; press and hold TEST until "CAL" appears.
10. Press and release TEST.
11. When "GO" shows on VTM, crank engine while holding fuel shutoff control handle out.
12. When VTM shows "OFF", stop cranking engine.
13. Record results and check limits.

Is reading less than 50 milliohms?




END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING (5) STARTER NEGATIVE CABLE DROP - TEST 69.  
- CONTINUED

<p><b>Tools</b> General mechanic's tool kit (SC 5180-90-N26) STE/ICE test set (item 72, Appx F)</p>	<p><b>Equipment Conditions</b> Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
---	--

1. Pull power switch on VTM to OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 to harness W101 connector P4 (DCA receptacle).
4. Push power on VTM to ON position.
5. Do confidence test 66/99 (para 3-4.a(1)).
6. Dial 60 into TEST SELECT.
7. Press and release TEST; message "UEH" should be displayed.
8. Enter Vehicle ID (VID) 11.
9. Enter 69 into TEST SELECT.
10. Press and release TEST.
11. Crank engine while holding fuel shutoff control handle. Record results.



Is reading higher than 1.2 V dc?

```

    graph TD
        Q{Is reading higher than 1.2 V dc?}
        Q -- yes --> A[Do test 91 on cable (TM 9-4910-571-12&P). If cable is bad, repair or replace wiring harness W101 (para 8-61).]
        Q -- no --> B[Fault does not exist as indicated. Recheck fault symptom.]
    
```

**END OF TASK**


06ph330t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


b. STE/ICE TROUBLESHOOTING (6) GENERATOR FIELD VOLTAGE - TEST 83.  
- CONTINUED

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  STE/ICE test set (item 72, Appx F)                  Electrical contact tool kit (item 73, Appx F)</p>	<p><u>Equipment Conditions</u>                  Air intake grille open (TM 9-2350-314-10)                  Transmission access doors open (TM 9-2350-314-10)                  Battery compartment access doors open (TM 9-2350-314-10)                  Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
--	---

- A**
1. Pull power switch on VTM to OFF position.
  2. Connect DCA cable W1 connector P1 to VTM connector J1.
  3. Connect DCA cable W1 to harness W101 connector P4 (DCA receptacle).
  4. Push power switch on VTM to ON position.
  5. Do confidence test 66/99 (para 3-4.a(1)).
  6. Dial 60 into TEST SELECT.
  7. Press and release TEST; message "UEH" should be displayed.
  8. Enter Vehicle ID (VID) 11.
  9. Start engine (TM 9-2350-314-10); turn on vehicle headlights, hydraulic pump, and increase engine rpm to 1000 to 1200 rpm.
  10. Enter 01 into TEST SELECT to see rpm and test limits alternately on VTM and press TEST. Message "CON" on VTM should appear.
  11. Enter 83 into TEST SELECT; press and release TEST.
  12. Record results (Limits: maximum 22 V dc.



Is reading higher than 22 V dc or does reading stay at 0?



CONTINUED ON NEXT PAGE

06ph326t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - CONTINUED      (6) GENERATOR FIELD VOLTAGE - TEST 83. - CONTINUED

CONTINUED FROM STEP A

- B**
1. Shut engine OFF (TM 9-2350-314-10). Turn vehicle MASTER switch OFF.
  2. Disconnect harness W106 lead L+ from harness W105 lead L+.
  3. Install a 3-way connector between harness W105 lead L+ and harness W106 lead L+.
  4. Connect cable W2 to VTM connector J4.
  5. Place red lead in open socket of 3-way connector and black lead to ground.
  6. Turn vehicle MASTER switch ON.
  7. Enter 89 into TEST SELECT and press TEST.
  8. Start engine (TM 9-2350-314-10) and read voltage on VTM.



Is battery voltage present?



CONTINUED FROM STEP A

- C**
- Do individual battery tests 75 (para 3-4.b(4)), 73 (para 3-4.b(3)), and test 89 (para 3-4.b(20)).

Are batteries good?



06ph331t

END OF TASK



# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING (7) FUEL PRESSURE RETURN - TEST 49.  
- CONTINUED

<b>Tools</b> General mechanic's tool kit (SC 5180-90-N26) STE/ICE test set (item 72, Appx F)	<b>Equipment Conditions</b> Air intake grille open (TM 9-2350-314-10) Transmission access doors open (TM 9-2350-314-10) Vehicle MASTER switch ON (TM 9-2350-314-10)
--	--

**WARNING**  
 Protective fan screens must be installed prior to doing maintenance in the engine compartment when the engine is running, or engine is in ground hop mode. Contact with rotating fan can cause injury.

1. Install fan protective screens (para 4-1.c)
2. Pull power switch on VTM to OFF position.
3. Connect DCA cable W1 connector P1 to VTM connector J1 .
4. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
5. Install red striped transducer TK22 and adapter TK24 at the engine fuel return line quick-disconnect.
6. Connect cable W4 connector P1 to VTM connector J3.
7. Connect cable W4 connector P2 to transducer TK22.
8. Push power switch on VTM to ON position.
9. Do confidence test 66/99 (para 3-4.a(1)).
10. Dial 60 into TEST SELECT.
11. Press and release TEST; message "UEH" should be displayed.
12. Enter Vehicle ID (VID) number 11.
13. Enter 01 into TEST SELECT; press TEST to see RPM and test limits alternately.
14. When "CON" shows on VTM, enter 49 into TEST SELECT; press TEST until "CAL" appears.
15. Press and release TEST.
16. Start engine (TM 9-2350-314-10). Record the results (in psi).



**END OF TASK**

06ph332t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING (8) CHARGING CIRCUIT (at battery) - TEST 67.  
- CONTINUED

<p><u>Tools</u> General mechanic's tool kit (SC 5180-90-N26) STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u> Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
---	--


- A**
1. Pull power switch on VTM to OFF position.
  2. Connect DCA cable W1 connector P1 to VTM connector J1.
  3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
  4. Push power switch on VTM to ON position.
  5. Do confidence test 66/99 (para 3-4.a(1)).
  6. Dial 60 into TEST SELECT.
  7. Press and release TEST; message "UEH" should be displayed.
  8. Enter Vehicle ID (VID) number 11.
  9. Enter 67 into TEST SELECT; press TEST to check for static voltage.

Is static voltage at least 22 volts?




- B**
1. Enter 02 into TEST SELECT and press TEST. When VTM shows "CON", enter 67 into TEST SELECT and press TEST.
  2. Crank engine while holding fuel shutoff control handle.
  3. Record the results of cranking test.

Is cranking voltage at least 18 volts?



CONTINUED ON NEXT PAGE



06ph333t



# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING (8) CHARGING CIRCUIT (at battery) - TEST 67. - CONTINUED  
- CONTINUED

CONTINUED FROM STEP B

- C**
1. Enter 01 into TEST SELECT and press TEST. When "CON" shows on VTM, enter 67 into TEST SELECT and press TEST.
  2. Start engine (TM 9-2350-314-10).
  3. Record reading at idle (550 rpm) and at governor (2300 rpm).
  4. Turn engine off (TM 9-2350-314-10).

Is charging voltage between 26.5 and 28.5 V dc?



END OF TASK

06ph334t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING (9) ENGINE RPM - TEST 10.  
- CONTINUED

<p><u>Tools</u> General mechanic's tool kit (SC 5180-90-N26) STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u> Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
---	--


- A**
1. Pull power switch on VTM to OFF position.
  2. Connect DCA cable W1 connector P1 to VTM connector J1.
  3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
  4. Push power switch on VTM to ON position.
  5. Do confidence test 66/99 (para 3-4.a(1)).
  6. Dial 60 into TEST SELECT.
  7. Press and release TEST; message "UEH" should be displayed.
  8. Enter Vehicle ID (VID) number 11. Enter 10 into TEST SELECT; press TEST.
  9. Crank engine while holding fuel shutoff control handle.

Is cranking rpm at least 100 rpm?




- B**
1. Release fuel shutoff and start the engine (TM 9-2350-314-10).
  2. Let the engine warm up for about 1 minute and then read rpm.

Is idle between 550 and 600 rpm?




- C** Slowly accelerate engine for governor test.

Is governor rpm between 2350 and 2500 rpm?



**END OF TASK**



06ph335t




# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING (10) COMPRESSION UNBALANCE - TEST 14.  
- CONTINUED


<p><b>Tools</b> General mechanic's tool kit (SC 5180-90-N26) STE/ICE test set (item 72, Appx F)</p>	<p><b>Equipment Conditions</b> Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
---	--

1. Pull power switch on VTM to OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
4. Push power switch on VTM to ON position.
5. Do confidence test 66/99 (para 3-4.a(1)).
6. Dial 60 into TEST SELECT.
7. Press and release TEST; message "UEH" should be displayed.
8. Enter Vehicle ID (VID) number 11.
9. Enter 14 into TEST SELECT; press TEST.
10. When "GO" shows on VTM, crank engine.
11. While holding fuel shutoff control handle (TM 9-2350-314-10), when VTM shows "OFF", stop cranking engine.
12. Read VTM.

Is reading 10% or less?



**END OF TASK**




06ph336t

# 3-3 TROUBLESHOOTING CHART - CONTINUED


b. STE/ICE TROUBLESHOOTING - CONTINUED (11) ENGINE POWER PERCENTAGE - TEST 13.

<b>Tools</b> General mechanic's tool kit (SC 5180-90-N26) STE/ICE test set (item 72, Appx F)	<b>Equipment Conditions</b> Vehicle MASTER switch ON (TM 9-2350-314-10)
---	---


- A**
1. Pull power switch on VTM to OFF position.
  2. Connect DCA cable W1 connector P1 to VTM connector J1.
  3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
  4. Push power switch on VTM to ON position.
  5. Do confidence test 66/99 (para 3-4.a(1)).
  6. Dial 60 into TEST SELECT.
  7. Press and release TEST; message "UEH" should be displayed.
  8. Enter Vehicle ID (VID) number 11.
  9. Start engine (TM 9-2350-314-10).
  10. Enter 13 into TEST SELECT; press TEST.
  11. When "CIP" shows on VTM, quickly accelerate engine. Release accelerator when VTM shows "OFF".
  12. Run this test twice and then record results.
- Is engine limit at least 60%?



- B**
1. Do the following tests using control function 01:
    - 24 - Fuel supply pressure (para 3-4.b(13))
    - 26 - Fuel pressure drop (para 3-4.b(22))
    - 49 - Fuel pressure return (para 3-4.b(7))
    - 32 - Air box pressure (para 3-4.b(21))
    - 28 - Air filter pressure differential (para 3-4.b(18))
    - 14 - Compression unbalance (para 3-4.b(10))
  2. Do mechanical fuel pump test (para 5-4).



**END OF TASK**



06ph337t


# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - (12) GENERATOR OUTPUT VOLTAGE - TEST 82.  
CONTINUED

<p><u>Tools</u> General mechanic's tool kit (SC 5180-90-N26) STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u> Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
---	--



- A**
1. Pull power switch on VTM to OFF position.
  2. Connect DCA cable W1 connector P1 to VTM connector J1.
  3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
  4. Push power switch on VTM to ON position.
  5. Do confidence test 66/99 (para 3-4.a(1)).
  6. Dial 60 into TEST SELECT.
  7. Press and release TEST; message "UEH" should be displayed.
  8. Enter Vehicle ID (VID) number 11.
  9. Enter 01 into TEST SELECT; press TEST.
  10. When "CON" shows on VTM, enter 82 into TEST SELECT; press TEST.
  11. Record the results.

Is reading on VTM below 26.5 V dc?



- B**
1. Enter 01 into TEST SELECT and press TEST. When "CON" shows on VTM, enter 83 into TEST SELECT and press TEST (para 3-4.b(6)).
  2. Enter 01 into TEST SELECT and press TEST. When "CON" shows on VTM, enter 84 into TEST SELECT and press TEST (para 3-4.b(1)).

Do these tests pass?



CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - CONTINUED (12) GENERATOR OUTPUT VOLTAGE - TEST 82. - CONTINUED

CONTINUED FROM STEP A

**C** If the reading on VTM was above 28.5 V dc, do the battery tests 75 (para 3-4.b(4)), 73 (para 3-4.b(3)), and 89 (para 3-4.b(20)).

Are batteries good?



Go to para 3-3.h (2).

Replace batteries (para 8-54).




END OF TASK

# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - (13) FUEL SUPPLY PRESSURE (DCA AND TK) -TEST 24. CONTINUED

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u>                  Air intake grille open (TM 9-2350-314-10)                  Transmission access doors open (TM 9-2350-314-10)                  Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
---	---

- A**
1. Pull power switch on VTM to OFF position.
  2. Connect DCA cable W1 connector P1 to VTM connector J1.
  3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
  4. Push power switch on VTM to ON position.
  5. Do confidence test 66/99 (para 3-4.a(1)).
  6. Dial 60 into TEST SELECT.
  7. Press and release TEST; message "UEH" should be displayed.
  8. Enter Vehicle ID (VID) number 11.
  9. Enter 01 into TEST SELECT; press TEST.
  10. When VTM shows "CON", enter 24 into TEST SELECT; press TEST until "CAL" appears.
  11. Press and release TEST.
  12. Crank engine for 10 seconds while holding fuel shutoff control handle. Record the results.
  13. Release fuel shutoff control handle and start engine (TM 9-2350-314-10). Record results.
- Is reading on VTM between 40 and 70 psi (275.8 and 482.65 kpa)?




CONTINUED ON NEXT PAGE

# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - CONTINUED (13) FUEL SUPPLY PRESSURE (DCA AND TK) TEST 24. - CONTINUED


- C**
1. Remove harness W123 connector P1 from pump generator relay and place a jumper wire from sockets A and C.
  2. Install red striped transducer TK22 and adapter TK24 at the inlet side of the primary fuel filter.
  3. Connect cable W4 connector P1 to connector J3 on VTM.
  4. Connect cable W4 connector P2 to transducer TK22.
  5. Turn vehicle MASTER switch ON.
  6. Enter 49 into TEST SELECT and press TEST.

Is 4 psi (27.58 kpa) showing on VTM?




- D**
1. Remove the jumper wire and reconnect W123 connector P1.
  2. Turn vehicle MASTER switch ON and start engine (TM 9-2350-314-10).
  3. Enter 49 into TEST SELECT and press TEST.
  4. Hold engine rpm at 1200 rpm.

Is a pressure of 1.2 psi (8.274 kpa) held?



**END OF TASK**




# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - (14) CRANKING CURRENT - TEST 71.  
CONTINUED

<p><u>Tools</u> General mechanic's tool kit (SC 5180-90-N26) STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u> Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
---	--


- A**

  1. Pull power switch on VTM to OFF position.
  2. Connect DCA cable W1 connector P1 to VTM connector J1.
  3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
  4. Push power switch on VTM to ON position.
  5. Do confidence test 66/99 (para 3-4.a(1)).
  6. Dial 60 into TEST SELECT.
  7. Press and release TEST; message "UEH" should be displayed.
  8. Enter Vehicle ID (VID) number 11.
  9. Enter 71 into TEST SELECT; press TEST and hold "CAL" appears.
  10. Press and release TEST.
  11. Crank the engine while holding fuel shutoff control handle. Record the results.
- Is VTM reading between 350 and 500 amps?



- B**

  1. Perform the following tests:
    - 72 - Current first peak (para 3-4.b(15)).
    - 73 - Battery internal resistance (para 3-4.b(3))
    - 74 - Starter circuit resistance (para 3-4.b(2))
    - 75 - Battery resistance charge (para 3-4.b(4))
  2. If tests are good, perform the following tests:
    - 68 - Starter positive terminal voltage (para 3-4.b(19))
    - 69 - Starter negative cable drop (para 3-4.b(5))
    - 70 - Starter solenoid voltage (para 3-4.b(16))
  3. If fault still exists, do individual battery voltage test 89 (para 3-4.b(20)).



**END OF TASK**


# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - (15) CURRENT FIRST PEAK - TEST 72.  
CONTINUED


<p><u>Tools</u> General mechanic's tool kit (SC 5180-90-N26) STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u> Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
---	--

- A**
1. Pull power switch on VTM to OFF position.
  2. Connect DCA cable W1 connector P1 to VTM connector J1.
  3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
  4. Push power switch on VTM to ON position.
  5. Do confidence test 66/99 (para 3-4.a(1)).
  6. Dial 60 into TEST SELECT.
  7. Press and release TEST; message "UEH" should be displayed.
  8. Enter Vehicle ID (VID) number 11.
  9. Enter 72 into TEST SELECT; press TEST.
  10. When "GO" shows on VTM, crank engine while holding fuel shutoff control handle until "OFF" or ".9.9.9.9" show on VTM. Record results.

Is VTM reading between 875 and 1800 amps?



- B**
1. Perform the following tests:
    - 72 - Current first peak (para 3-4.b(14)).
    - 73 - Battery internal resistance (para 3-4.b(3))
    - 74 - Starter circuit resistance (para 3-4.b(2))
    - 75 - Battery resistance charge (para 3-4.b(4))
  2. If tests are good, perform the following tests:
    - 68 - Starter positive terminal voltage (para 3-4.b(19))
    - 69 - Starter negative cable drop (para 3-4.b(5))
    - 70 - Starter solenoid voltage (para 3-4.b(16))
  3. If fault still exists, do individual battery voltage test 89 (para 3-4.b(20)).



**END OF TASK**





# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - CONTINUED (16) STARTER SOLENOID VOLTAGE - TEST 70.

<p><u>Tools</u>                  General mechanic's tool kit                  (SC 5180-90-N26)                  STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u>                  Vehicle MASTER switch ON                  (TM 9-2350-314-10)</p>
--	--

1. Pull power switch on VTM to OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
4. Push power switch on VTM to ON position.
5. Do confidence test 66/99 (para 3-4.a(1)).
6. Dial 60 into TEST SELECT.
7. Press and release TEST; message "UEH" should be displayed.
8. Enter Vehicle ID (VID) number 11.
9. Enter 70 into TEST SELECT; press TEST.
10. Crank engine while holding fuel shutoff control handle. Record results.

Does VTM show at least 18 V dc?



06ph343t

**END OF TASK**



### 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - CONTINUED (17) VEHICLE OIL PRESSURE - TEST 50.

<p><b>Tools</b>                  General mechanic's tool kit (SC 5180-90-N26)                  STE/ICE test set (item 72, Appx F)</p>	<p><b>Equipment Conditions</b>                  Air intake grille open (TM 9-2350-314-10)                  Transmission access doors open (TM 9-2350-314-10)                  Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
---	---

1. Pull power switch on VTM to OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
4. Push power switch on VTM to ON position.
5. Do confidence test 66/99 (para 3-4.a(1)).
6. Dial 60 into TEST SELECT.
7. Press and release TEST; message "UEH" should be displayed.
8. Enter vehicle ID (VID) number 11.
9. Install blue-striped transducer TK17 with TK26 elbow installed between W4 and manifold sampling port or plug.
10. Enter 01 into TEST SELECT and press TEST.
11. When "CON" shows on VTM, enter 50 into TEST SELECT; press TEST until "CAL" is displayed.
12. Press and release TEST.
13. Start engine (TM 9-2350-314-10) and let run for 5 minutes.
14. Accelerate engine to 1000 rpm and record results.

Is VTM reading between 30 and 50 psi (206.85 and 344.75 kpa)?



END OF TASK

06ph344 t



# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - CONTINUED (18) AIR FILTER PRESSURE DIFFERENTIAL - TEST 28.

Tools  
 General mechanic's tool kit  
 (SC 5180-90-N26)  
 STE/ICE test set (item 72, Appx F)

1. Pull power switch on VTM to OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
4. Push power switch on VTM to ON position.
5. Do confidence test 66/99 (para 3-4.a(1)).
6. Dial 60 into TEST SELECT.
7. Press and release TEST; message "UEH" should be displayed.
8. Enter Vehicle ID (VID) number 11.
9. Enter 28 into TEST SELECT; press TEST until "CAL" is displayed.
10. Press and release TEST.
11. Turn vehicle MASTER switch ON and start engine (TM 9-2350-314-10).
12. Record the results.

Is VTM reading above - 20 H<sub>2</sub>O?



06ph341t

**END OF TASK**



# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - CONTINUED (19) STARTER POSITIVE TERMINAL VOLTAGE - TEST 68.

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u>                  Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
---	---

1. Pull power switch on VTM to OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
4. Push power switch on VTM to ON position.
5. Do confidence test 66/99 (para 3-4.a(1)).
6. Dial 60 into TEST SELECT.
7. Press and release TEST; message "UEH" should be displayed.
8. Enter Vehicle ID (VID) number 11.
9. Enter 68 into TEST SELECT and press TEST until "CAL" is displayed.
10. Press and release TEST.
11. Crank engine while holding fuel shutoff control handle. Record results.

Is VTM reading at least 18 V dc?



06ph341t


**END OF TASK**

# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - CONTINUED (20) INDIVIDUAL BATTERY VOLTAGE - TEST 89.

<p><b>Tools</b>                  General mechanic's tool kit (SC 5180-90-N26)                  STE/ICE test set (item 72, Appx F)</p>	<p><b>Equipment Conditions</b>                  Battery access doors open (TM 9-2350-314-10)</p>
---	--


1. Pull power switch on VTM to OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 to harness W100 J1.
4. Push power switch on VTM to ON position.
5. Do confidence test 66/69 (para 3-4a(1)).
6. Connect STE-ICE cable W2 connector P1 to VTM connector J4.
7. Attach red clip of cable W2 to black clip of cable W2.
8. Enter 89 into TEST SELECT.
9. Press and hold TEST button until "CAL" appears on the display.
10. Release TEST button and wait for offset value to appear on the display.
11. If offset value is between -6.8 and +6.8, connect red clip of cable W2 to positive terminal of battery "A" and black clip on negative terminal of battery "A".
12. Crank engine while holding fuel shutoff control handle out.
13. Record value displayed while cranking engine.
14. Test batteries B, C, and D one at a time by connecting red clip on positive terminal and black clip on negative terminal and repeat steps 12 and 13.



Is each battery value at least 9.5 V dc?

```

    graph TD
        Q{Is each battery value at least 9.5 V dc?}
        Q -- yes --> A[Fault does not exist as indicated. Recheck fault symptom.]
        Q -- no --> B[Check battery electrolyte level. Perform specific gravity checks (Table 2-1, PMCS item 5). Replace batteries as needed (para 8-54).]
    
```



END OF TASK


06ph345t

# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - CONTINUED (21) AIR BOX PRESSURE - TEST 32.

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u>                  Vehicle MASTER switch ON (TM 9-2350-314-10)                  Final drive quick-disconnects removed (para 10-3)</p>
---	--

1. Pull power switch on VTM to OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 to harness W100 J1.
4. Push power switch on VTM to ON position.
5. Do confidence test 66/69 (para 3-4a(1)).
6. Dial 60 into TEST SELECT.
7. Press and release TEST; message "UEH" should be displayed.
8. Enter vehicle ID (VID) number 11.
9. Enter 01 into TEST SELECT; press TEST.
10. When VTM shows "CON", enter 32 into TEST SELECT and press TEST until "CAL" is displayed.
11. Press and release TEST.
12. Start engine (TM 9-2350-314-10), apply brakes and place transmission in 4th gear. Increase engine to FULL THROTTLE.
13. When VTM shows peak reading, record results and slow engine to 1000 rpm.
14. Place transmission in NEUTRAL and let engine run for 3 to 5 minutes.



Were the following results shown?  
 1550-1800 RPM/21-28 in. Hg.

```

    graph TD
        Q{Were the following results shown?  
1550-1800 RPM/21-28 in. Hg.}
        Q -- yes --> A[Fault does not exist as indicated.  
Recheck fault symptom.]
        Q -- no --> B[Do tests 13 (para 3-4.b(11)) and 14 (para 3-4.b(10)).  
If tests fail, check blower, blower seals, air box seals,  
and turbocharger. If faulty, notify direct support maintenance.]
    
```

**END OF TASK**



# 3-3 TROUBLESHOOTING CHART - CONTINUED

b. STE/ICE TROUBLESHOOTING - CONTINUED (22) FUEL PRESSURE DROP - TEST 26.

<p><u>Tools</u>                  General mechanic's tool kit (SC 5180-90-N26)                  STE/ICE test set (item 72, Appx F)</p>	<p><u>Equipment Conditions</u>                  Air intake grille open (TM 9-2350-314-10)                  Vehicle MASTER switch ON (TM 9-2350-314-10)</p>
---	--

1. Pull power switch on VTM to OFF position.
2. Connect DCA cable W1 connector P1 to VTM connector J1.
3. Connect DCA cable W1 to harness W101 connector P4 DCA receptacle.
4. Push power switch on VTM to ON position.
5. Do confidence test 66/99 (para 3-4.a(1)).
6. Dial 60 into TEST SELECT.
7. Press and release TEST; message "UEH" should be displayed.
8. Enter Vehicle ID (VID) number 11.
9. Enter 26 into TEST SELECT.
10. Start engine (TM 9-2350-314-10) and increase engine speed to 2400-2500 rpm.
11. Press TEST and record results.

Does VTM show "PASS"?



06ph346t

**END OF TASK**

# CHAPTER 4 POWERPACK

---

## GENERAL

This chapter illustrates and defines procedures for removal and installation of the powerpack consisting of the engine, transfer case and transmission assemblies, and related components. Procedures for operating the powerpack after removal from the vehicle are also given.

The powerpack shall be given periodic checks to find possible fire hazards. Inspections for foreign matter shall be performed on the powerpack cooling components, air shrouding, wiring, and powerpack hull compartment during each maintenance service.

Whenever the powerpack is removed for maintenance, the powerpack should be given a general cleaning and inspection of wiring, hoses, and piping.

This chapter also illustrates and defines maintenance procedures for various engine components, including instructions for removal, disassembly, assembly, installation, and inspection.

---

## CONTENTS

Page

Section I.	POWERPACK	
4-1	POWERPACK .....	4-2
Section II.	ENGINE ASSEMBLY	
4-2	SHOCK MOUNT AND ENGINE BRACKETS .....	4-36
4-3	ENGINE MOUNTING BRACKET, LOWER ENGINE BAR, AND UNIVERSAL JOINT .....	4-38
4-4	FLYWHEEL HOUSING COVER AND GASKET .....	4-42
4-5	BREATHER TUBES .....	4-44
Section III.	ENGINE LUBRICATION SYSTEM	
4-6	ENGINE OIL FILTER LINES, MOUNTING BRACKET, FITTINGS, ENGINE OIL SAMPLING VALVE, AND ENGINE OIL SENSOR FITTINGS .....	4-46
4-7	ENGINE OIL FILTER .....	4-49



---

## Section I. POWERPACK

---

### 4-1 POWERPACK.

---

This task covers:     a. Removal                                b. Inspection                                c. Special Equipment Hookups  
                              d. Testing    e. Special Equipment Removal    f. Installation

---

#### **INITIAL SETUP**

Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Lifting sling (item 62, Appx F)  
Suitable lifting device (5000 lb min.)  
Box wrench (item 80, Appx F)  
Torque wrench (item 86, Appx F)  
Ground hop kit (item 34, Appx F)  
Torque wrench (item 87, Appx F)  
Fan protective screens (2) (item 56, Appx F)

Materials/Parts

Lumber (item 38, Appx C) (3) (4 x 4 x 18 in.)  
Lockwashers (2) (item 47, Appx E)  
Lockwashers (2) (item 20, Appx E)  
Lock wire (item 310, Appx E)  
Cotter pin (item 8, Appx E)  
Assembled screws (2) (item 298, Appx E)  
Self-locking nuts (9) (item 120, Appx E)

Equipment Conditions

Vehicle parked on level surface  
(TM 9-2350-314-10)  
Tracks blocked (TM 9-2350-314-10)  
Gun tube travel lock in maintenance position  
(TM 9-2350-314-10)

Equipment Conditions - Continued

Cab traversed to 90°  
(TM 9-2350-314-10)  
Vehicle MASTER switch OFF  
(TM 9-2350-314-10)  
Parking brake released (TM 9-2350-314-10)  
Throttle in idle position (TM 9-2350-314-10)  
Air intake grille open and secured  
(TM 9-2350-314-10)  
Battery ground leads disconnected  
(para 8-33)  
Hull front slope and exhaust grille support plate  
removed (para 16-30)  
Grille adjustable support assembly removed  
(para 16-31)  
Exhaust outlet pipe removed (para 6-1)  
Steering control rod removed from engine  
compartment (para 13-1)

Personnel Required

Three

References

TM 9-2350-314-10

---

#### a. Removal.

#### **WARNING**

Track must be blocked so that the vehicle will not roll out of control. When powerpack is disconnected, vehicle is without brakes. Failure to securely block vehicle tracks may result in severe injury to personnel or equipment damage.

Section I. POWERPACK - CONTINUED


4-1 POWERPACK - CONTINUED

a. Removal - Continued


**NOTE**

Provide an area 8 feet by 10 feet (2.0 by 3.0 m) near the track for the powerpack after removal.

- 1 Remove air intake grille handle bracket (1) by removing two screws (2).



- 2 Disconnect quick-disconnect assembly (3) at engine to lower fuel tank return hose (4).



---

Section I. POWERPACK - CONTINUED

---

4-1 POWERPACK - CONTINUED


---

a. Removal - Continued

**NOTE**

To ease removal of flange, remove cotter pin, nut, washer, spring, and screw; then rotate flange to access other nut.

- 3 Loosen hose clamp (5) and disconnect turbocharger inlet duct (6) from turbocharger (7).




01ph023m

Section I. POWERPACK - CONTINUED

4-1 POWERPACK - CONTINUED

a. Removal - Continued

- 4 Disconnect engine fuel shutoff control by pulling quick-release pin (8). Remove two assembled screws (9) from pulley bracket (10). Lay cable (11) and pulley bracket (10) on hull. Discard assembled screws.
- 5 From inside driver's compartment, loosen engine mount release shaft (12) by turning counterclockwise.
- 6 Disconnect fuel line quick-disconnect (13) at the primary fuel filter (14).



Section I. POWERPACK - CONTINUED

4-1 POWERPACK - CONTINUED

a. Removal - Continued


**CAUTION**

Do not turn clevis nuts during handling of quick disconnect clamping devices.

**NOTE**

- The final drive clamping clevises (quick-disconnects) for left and right of engine are removed the same way. Right side is shown.
- Remove only clamping devices located on the transmission side of each final drive.

- 7 At the clamping clevis (15) (transmission side), cut and discard one locking wire (16). Remove one bolt (17).
- 8 Separate universal joint (18) from transmission flange (19).
- 9 Disconnect speedometer cable (20) by unscrewing nut (21).
- 10 Loosen nut (22) and disconnect speedometer adapter drive (23) from transmission adapter (24).




08ph027m

Section I. POWERPACK - CONTINUED

4-1 POWERPACK - CONTINUED

a. Removal - Continued

- 11 Disconnect wiring harness W28 connector P1 (25) from top of vehicle motion sensor (VMS) (26).
- 12 Remove screw (27), two lockwashers (28), and ground cable (29). Discard lockwashers.
- 13 Disconnect wiring harness W113 connector P2 (30) from travel lock power cable (31).



06ph082m

## Section I. POWERPACK - CONTINUED

---

### 4-1 POWERPACK - CONTINUED

---

#### a. Removal - Continued



After disconnecting, make sure steer and shift control rods are in the driver's compartment wall to prevent damage when the powerpack is hoisted or reinstalled.

- 14 Release throttle governor control rod (32) by moving throttle control to full open position and pulling out quick-release pin (33).

#### NOTE


Tag cables before removing shafts to avoid wrong connections during installation.

- 15 Remove tachometer and speedometer flexible drive shafts (34) by unscrewing two nuts (35).
- 16 Disconnect throttle valve control rod (36) by removing lockpin (37) and headed pin (38).
- 17 Disconnect shift control rod (39) by pulling out quick-release pin (40). Move control rod into hull to prevent damage, place shift control in R2 position.
- 18 Disconnect brake control sprocket and shaft (41) by removing cotter pin (42) and retainer pin (43). Discard cotter pin.
- 19 Remove screw (44), flat washer(45), and remote control lever (46).

Section I. POWERPACK - CONTINUED

4-1 POWERPACK - CONTINUED

a. Removal - Continued



07ph016m



---

**Section I. POWERPACK - CONTINUED**

---

**4-1 POWERPACK - CONTINUED**


---

**a. Removal - Continued**


**NOTE**

Tag electrical wires to ensure proper installation.

- 19 Disconnect wiring harness W106 connector P1 (47) from voltage regulator (48). Disconnect four connectors (49) from hull wiring harnesses.



- 20 Disconnect harness W101 connector P1 (50) from harness W102 connector J1 (51), harness W109 connector P1 (52) from harness W110 connector J1 (53), harness W108 connector P1 (54) from harness W107 connector J1 (55), and harness W105 connector P1 (56) from harness W104 connector J1 (57). Secure cables to hull.



---

**Section I. POWERPACK - CONTINUED**

---


**4-1 POWERPACK - CONTINUED**

---

**a. Removal - Continued****NOTE**

- Trunnion caps must be marked for proper location.
- If shims are present with caps, they must be retained for the same location as they were removed.

- 21 Remove trunnion support caps (58) and two upper inserts (59) from support assembly by removing four screws (60) and four flat washers (61).




Section I. POWERPACK - CONTINUED

4-1 POWERPACK - CONTINUED

a. Removal - Continued

- 22 At the coolant surge tank, remove two screws (62), two flat washers (63), and retainer pad (64). Remove two screws (65), two nuts (66), and two lockwashers (67) on the coolant pump to surge tank hose (68). Remove coolant surge tank (69) and place on top of transmission. Discard lockwashers.




05ph043m

Section I. POWERPACK - CONTINUED

4-1 POWERPACK - CONTINUED

a. Removal - Continued

- 23 Remove screw (70) and washer (71) from heat shield (72).
- 24 Remove five self-locking nuts (73), five flat washers (74), baffle (75), plate (76), and seal (77). Discard self-locking nuts.
- 25 Remove four self-locking nuts (78), four flat washers (79), plate (80), and seal (81). Discard self-locking nuts.



## Section I. POWERPACK - CONTINUED

---

### 4-1 POWERPACK - CONTINUED

---

#### a. Removal - Continued

**WARNING**

- Perform visual inspection and check load test date on lifting sling. Never crawl under equipment when performing maintenance unless equipment is securely blocked.
- Keep clear of equipment when it is being raised or lowered. Do not allow heavy components to swing while suspended by lifting device.
- Exercise extreme caution when working near a cable or chain under tension.

**CAUTION**





Use extreme care when removing/installing the powerpack to avoid damaging the fuel tanks, radiator, and transmission/generator oil line.

- 26 Secure coolant surge tank (69) to powerpack (82).
- 27 Attach lifting sling to suitable lifting device and powerpack (82) at four lifting eyes (83).
- 28 Lift powerpack (82) out of hull slowly. After lifting powerpack several inches, shift it towards front of vehicle for clearance. Watch all sides of powerpack to ensure clearance during removal.
- 29 Place powerpack (82) on wooden blocks.
- 30 Remove two lower trunnion inserts (84) from support assembly.

Section I. POWERPACK - CONTINUED

4-1 POWERPACK - CONTINUED

a. Removal - Continued



## Section I. POWERPACK - CONTINUED

---

### 4-1 POWERPACK - CONTINUED

---

#### b. Inspection.

Powerpack should be given a general inspection in the following areas, whenever the powerpack is removed from the vehicle:

#### NOTE

Replace or repair any defective or damaged item or component as required. If replacement or repair is beyond scope of unit level maintenance, notify support maintenance.

- 1 Check gaskets, seals, and covers for seepage of fuel and oil.
- 2 Check for damaged, distorted, or broken hose, tube, or line connector assemblies (nuts, adapters, reduction fittings, and couplers).
- 3 Check fuel hoses, tubes, and connectors for cracks, leaks, and/or seepage of fuel (para 5-14).
- 4 Check oil hoses, tubes, and connectors for cracks, leaks, and/or seepage of oil (para 4-6).
- 5 Check for stripped or damaged threads on connector assemblies and retaining bolts, nuts, or studs. Repair threads or replace components/items as appropriate.
- 6 Check electrical wires, leads, and connectors for cracked insulation, oil, and grease on cables/connectors.
- 7 Check for broken screws or bolts. Replace broken screws or bolts.
- 8 Check for damaged, burred, pitted, or gummed-up seal, gasket, or preformed packing seals. Clean, remove burrs, or replace components as required.
- 9 Check hull engine compartment floor for pools of oil, fuel, and coolant.

#### WARNING

Be sure engine is cool before removing radiator cap.  
Hot coolant can cause severe burns.

- 10 Check radiator for coolant level. Check coolant for serviceability (para 2-7).
- 11 Check coolant hoses and tubes for cracks, deterioration, and signs of coolant seepage (Table 2-1, PMCS item 29).
- 12 Check oil filters (para 4-7) and fuel filters (para 5-16) for collection of sediment on filter elements.

Operating the powerpack out of the vehicle lets maintenance personnel inspect the control and drive components of the powerpack unit by hand-operating the control linkages on the transmission. Components can be checked for proper functioning and performance with the powerpack unit outside the vehicle without harm to the unit.

---

## Section I. POWERPACK - CONTINUED

---

### 4-1 POWERPACK - CONTINUED


---

#### c. Special Equipment Hookups.

**CAUTION**

Ensure all hoses are connected and secure.

- 1 Check hoses and connectors (85) of surge tank (69) connections. Make sure hoses are not kinked.
- 2 Position surge tank (69) next to powerpack transmission left side at final drive universal joints.
- 3 Connect ground cable (29) to appropriate grounding device. Be certain paint or rust is removed at connection point.






Section I. POWERPACK - CONTINUED



4-1 POWERPACK - CONTINUED

c. Special Equipment Hookups - Continued

- 4 Connect harness W101 connector P1 (50) to harness W102 connector J1 (51), harness W109 connector P1 (52) to harness W110 connector J1 (53), harness W108 connector P1 (54) to harness W107 connector J1 (55), and harness W105 connector P1 (56) to harness W104 connector J1 (57) using ground hop kit.



- 5 At the primary fuel filter (14), connect fuel line quick-disconnect (13).
- 6 Connect quick-disconnect (3) at engine to lower fuel tank return hose (4).



**Section I. POWERPACK - CONTINUED**

**4-1 POWERPACK - CONTINUED**

**c. Special Equipment Hookups - Continued**

- 7 Install turbocharger air inlet safety screen (86).
- 8 Attach tachometer (87) to tachometer flexible drive shaft assembly (34) and position it where it will not be affected by engine vibration.


**WARNING**

A protective fan screen must be installed prior to doing maintenance in the engine compartment when engine is running or when engine is in ground hop mode. Contact with rotating fan can cause injury.

**NOTE**

Flat side of screen should align with two lower mounting bolts of fan housing.

- 9 Install two fan protective screens (88), thumb or hex head screw (89), and locknut (90).



## Section I. POWERPACK - CONTINUED

---

### 4-1 POWERPACK - CONTINUED

---

d. Testing.

**WARNING**

- A protective fan screen must be installed prior to doing maintenance in the engine compartment when engine is running or when engine is in ground hop mode. Contact with rotating fan can cause injury.
- Excessive noise levels are present any time the equipment is operating. Wear hearing protection while it is running. Failure to do so could result in damage to your hearing.

**CAUTION**


- Make sure coolant and engine lubricants are replenished before starting engine.
  - When operating the powerpack while mounted on blocks, watch closely. Prevent powerpack from vibrating off the blocks.
- 1 Start engine (TM 9-2350-314-10) and operate at 1200 to 1400 rpm until engine coolant temperature is 169° F (76° C) and transmission oil temperature is 160° F (71° C). Allow engine to return to normal idle speed (650 rpm).
  - 2 Check engine operation.
  - 3 Check for leaks, excess smoke, or strange noises. Try to locate the source of leaks. If any problems persist, notify support maintenance.
  - 4 Shut down engine (TM 9-2350-314-10).

Section I. POWERPACK - CONTINUED

4-1 POWERPACK - CONTINUED

e. Special Equipment Removal.

- 1 Loosen locknut (90) and thumb or hex head screw (89) on each fan protective screen (88). Remove two fan protective screens (88).
- 2 Remove tachometer (87) from tachometer flexible drive shaft assembly (34).
- 3 Remove turbocharger air inlet safety screen (86).




Section I. POWERPACK - CONTINUED

4-1 POWERPACK - CONTINUED

e. Special Equipment Removal - Continued

- 4 Disconnect quick-disconnect assembly (3) at engine to lower fuel tank return hose (4).
- 5 At primary fuel filter (14), disconnect fuel line quick-disconnect (13).
- 6 Disconnect ground hop kit harness W101 connector P1 (50) from harness W102 connector J1 (51), harness W109 connector P1 (52) from harness W110 connector J1 (53), harness W108 connector P1 (54) from harness W107 connector J1 (55), and harness W105 connector P1 (56) from harness W104 connector J1 (57).
- 7 Disconnect ground cable (29) from appropriate grounding device.
- 8 Position surge tank (69) on top of transmission. Make sure hoses (85) are not kinked.



03ph041m

Section I. POWERPACK - CONTINUED


4-1 POWERPACK - CONTINUED

f. Installation.


**NOTE**

Be sure to lubricate engine and exercise engine mounting bracket prior to installing powerpack (TM 9-2350-314-10).

- 1 Position fuel return hose (4) against powerpack compartment wall.



- 2 Install remote control lever (46) with screw (44) and flat washer (45).



---

## Section I. POWERPACK - CONTINUED





---

### 4-1 POWERPACK - CONTINUED

---

#### f. Installation - Continued

- 3 Install two lower trunnion inserts (84) in support assembly.
- 4 Secure surge tank (69) to powerpack (82).
- 5 Position lift vehicle for powerpack (82) installation.
- 6 Attach lifting sling to powerpack (82) at four lifting eyes (83).



---

**Section I. POWERPACK - CONTINUED**

---


**4-1 POWERPACK - CONTINUED**

---

**f. Installation - Continued****CAUTION**

Watch all sides of the powerpack, making sure it clears the hull. Have one person observe from the driver's compartment through the engine compartment access to ensure air intake duct, generator oil lines, and fuel tank are not damaged.

- 7 Lift and set powerpack (82) in vehicle hull.
- 8 Remove lifting sling from powerpack (82).
- 9 Install surge tank (69), retainer pad (64), two screws (62), and two flat washers (63).



01ph028m



---

## Section I. POWERPACK - CONTINUED

---

### 4-1 POWERPACK - CONTINUED

---


#### f. Installation - Continued

- 10 Install two screws (65), two new lockwashers (67), and two nuts (66) on coolant pump to surge tank hose (68).

#### NOTE

- Make sure trunnion cap inserts are installed at the original locations from which they were removed.
- Make sure trunnion caps are installed in proper location as marked on caps (left front and right front) with stamp facing towards front of vehicle.
- Primary fuel pump bracket (lifting eye) must be disconnected and removed to install and properly torque right front trunnion capscrews.

- 11 Install two upper inserts (59) and two trunnion support caps (58) with four screws (60) and four flat washers (61). Torque screws to 85-90 lb-ft (115-122 N·m).




Section I. POWERPACK - CONTINUED

4-1 POWERPACK - CONTINUED

f. Installation - Continued

- 12 Install seal (81), plate (80), four flat washers (79), and four new self-locking nuts (78).
- 13 Install baffle (75) with plate (76), seal (77), five flat washers (74), and five new self-locking nuts (73).
- 14 Install screw (70) and washer (71) in heat shield (72).




Section I. POWERPACK - CONTINUED


4-1 POWERPACK - CONTINUED

f. Installation - Continued

- 15 Connect harness W101 connector P1 (50) to harness W102 connector J1 (51), harness W109 connector P1 (52) to harness W110 connector J1 (53), harness W108 connector P1 (54) to harness W107 connector J1 (55), and harness W105 connector P1 (56) to harness W104 connector J1 (57).



- 16 Connect wiring harness W106 connector P1 (47) to voltage regulator (48). Connect four connectors (49) to hull wiring harnesses.



---

**Section I. POWERPACK - CONTINUED**


---

**4-1 POWERPACK - CONTINUED**

---

**f. Installation - Continued**

- 17 Connect brake control sprocket and shaft (41) by installing retainer pin (43) and new cotter pin (42).
- 18 Place shift control in N position. Connect shift control rod (39) by installing quick-release pin (40).
- 19 Install steering control rod in engine compartment (para 13-1).
- 20 Connect throttle valve control rod (36) with headed pin (38) and lock pin (37).
- 21 Connect tachometer and speedometer flexible drive shafts (34) by tightening two nuts (35).
- 22 Connect throttle governor control rod (32) by installing quick-release pin (33).



07ph017m

---

**Section I. POWERPACK - CONTINUED**


---

**4-1 POWERPACK - CONTINUED**

---

**f. Installation - Continued**

- 23 Connect wiring harness W113 connector P2 (30) to travel lock power cable (31).
- 24 Connect powerpack ground cable (29) by installing screw (27) and two new lockwashers (28).
- 25 Connect wiring harness W28 connector P1 (25) to top of vehicle motion sensor (26).



06ph082m

Section I. POWERPACK - CONTINUED

4-1 POWERPACK - CONTINUED

f. Installation - Continued

**CAUTION**

Do not turn clevis nuts during handling of quick disconnect clamping devices.

**NOTE**


Quick-disconnects for left and right side of engine are installed the same way. Right side is shown.

- 26 Connect universal joint (18) to transmission flange (19).
- 27 Install clamping clevis (quick-disconnect) (15) and bolt (17). Torque bolt (17) to 37-42 lb-ft (50-56.9 N-m) and install new locking wire (16).

**CAUTION**

Speedometer adapter drive must be installed so that it does not contact rotating quick-disconnect or equipment damage will result.

- 28 Install speedometer adapter drive (23) on transmission adapter (24) by tightening nut (22).
- 29 Connect speedometer cable (20) by tightening nut (21).



---

**Section I. POWERPACK - CONTINUED**


---

**4-1 POWERPACK - CONTINUED**

---

**f. Installation - Continued**

- 30 Connect fuel line quick-disconnect (13) at the primary fuel filter (14).
- 31 Tighten engine mount release shaft (12) by turning clockwise. Torque shaft to 174 lb-ft (236 N·m).
- 32 Install governor fuel shutoff cable (11) and quick-release pin (8). Install pulley bracket (10) with two new assembled screws (9).




Section I. POWERPACK - CONTINUED

4-1 POWERPACK - CONTINUED

f. Installation - Continued

33 Connect turbocharger inlet duct (6) to turbocharger (7) and tighten hose clamp (5).

34 Connect quick-disconnect assembly (3) at engine to lower fuel tank return hose (4).



01ph030m



## Section I. POWERPACK - CONTINUED

---

### 4-1 POWERPACK - CONTINUED

---

#### f. Installation - Continued

35 Install exhaust outlet pipe (para 6-1).

#### WARNING

- A protective fan screen must be installed prior to doing maintenance in the engine compartment when engine is running or when engine is in ground hop mode. Contact with rotating fan can cause injury.
- Excessive noise levels are present any time the equipment is operating. Wear hearing protection while it is running. Failure to do so could result in damage to your hearing.

#### CAUTION

- Ensure coolant and engine lubricants are replenished before starting engine.
  - While performing test run, check coolant and oil temperatures. Coolant temperature should not exceed 180° F (82° C). Oil temperature should not exceed 259° F (126° C). If either condition exists, run engine at 1000-1200 rpm for 2 minutes before shutdown.
- 36 Connect both battery ground leads (para 8-33). Place vehicle MASTER switch in ON position. Start engine and operate at 1200-1400 rpm until engine coolant temperature is 169° F (76° C) and transmission oil temperature is 160° F (71° C). Allow engine to return to normal idle speed (650 rpm) (TM 9-2350-314-10).
- 37 Check engine operation. If engine is not operating properly, perform engine Troubleshooting (Chapter 3).
- 38 Check for leaks, excess smoke, or strange noises. Try to locate the source of leaks. If any problems persist, notify support maintenance.

---

## Section I. POWERPACK - CONTINUED


---

### 4-1 POWERPACK - CONTINUED

---

#### f. Installation - Continued

- 39 Install air intake grille handle bracket (1) with two screws (2).



18ph111m

- 40 Set parking brake and remove blocks from under tracks (TM 9-2350-314-10).

#### NOTE

##### FOLLOW-ON MAINTENANCE:


- Install grille adjustable support assembly (para 16-31)
- Install hull front slope and exhaust grille support plate (para 16-30)
- Perform transmission throttle control adjustment (para 5-21)
- Position gun tube travel lock in travel position (TM 9-2350-314-10)
- Secure gun tube in travel lock (TM 9-2350-314-10)
- Operate vehicle (TM 9-2350-314-10)



Section II. ENGINE ASSEMBLY - CONTINUED

4-2 SHOCK MOUNT AND ENGINE BRACKETS - CONTINUED

b. Installation - Continued



01ph013m

**NOTE**


**FOLLOW-ON MAINTENANCE:**  
Install cradle mounting bracket (para 8-8)



Section II. ENGINE ASSEMBLY - CONTINUED

4-3 ENGINE MOUNTING BRACKET, LOWER ENGINE BAR, AND UNIVERSAL JOINT - CONTINUED

a. Removal - Continued



01ph014m


b. Disassembly.

- 1 Remove four cotter pins (11) and two jaw pins (12) from base (13). Discard cotter pins.
- 2 Remove jaw assembly (14) from base (13).

**NOTE**

One end of tensioning tie rod and one nut have left-handed threads.

- 3 Remove two jaws (15) from tensioning tie rod (3).
- 4 Remove two nuts (16 and 17) from two jaws (15).



01ph029m

---

**Section II. ENGINE ASSEMBLY - CONTINUED**

---

**4-3 ENGINE MOUNTING BRACKET, LOWER ENGINE BAR, AND UNIVERSAL JOINT - CONTINUED**

---

**c. Assembly.**

- 1 Install two nuts (16 and 17) in two jaws (15).

**CAUTION**


Make sure jaws are spaced evenly on tensioning tie rod. Damage to equipment may occur if jaws are not adjusted properly prior to jaw assembly installation.

- 2 Install two jaws (15) on tensioning tie rod (3).

**NOTE**

Make sure that hex head end of rod is on high side of base.

- 3 Install jaw assembly (14) in base (13).
- 4 Install two jaw pins (12) in base (13) and through jaws (15).
- 5 Install four new cotter pins (11) in jaw pins (12).



---

**Section II. ENGINE ASSEMBLY - CONTINUED**


---

**4-3 ENGINE MOUNTING BRACKET, LOWER ENGINE BAR, AND UNIVERSAL JOINT - CONTINUED**

---

**d. Installation.**

- 1 Install engine mounting bracket (10) with four screws (8) and four new lockwashers (9).
- 2 Install bushing (6) on lower engine bar (5).
- 3 Install lower engine bar (5) through driver's bulkhead (7).
- 4 Install universal joint (2) on lower engine bar (5) with new cotter pin (4).
- 5 Install universal joint (2) on tensioning tie rod (3) with new cotter pin (1).



01ph032m

**NOTE**

**FOLLOW-ON MAINTENANCE:**  
Install powerpack (para 4-1)






Section II. ENGINE ASSEMBLY - CONTINUED

4-4 FLYWHEEL HOUSING COVER AND GASKET - CONTINUED

b. Installation - Continued



01ph033m

**NOTE**

**FOLLOW-ON MAINTENANCE:**  
 Close and secure air intake grille  
 (TM 9-2350-314-10)

## Section II. ENGINE ASSEMBLY - CONTINUED

---

### 4-5 BREATHER TUBES.

---

This task covers:      a. Removal                              b. Installation

---

#### **INITIAL SETUP**

##### Tools

General mechanic's tool kit  
(SC 5180-90-N26)

##### Equipment Conditions

Air intake grille open and secured  
(TM 9-2350-314-10)

##### Materials/Parts

Tiedown straps (4) (item 90, Appx E)  
Tiedown strap (item 167, Appx E)

##### References

TM 9-2350-314-10

---

#### **NOTE**

- Perform Removal steps 1 and 3 and Installation steps 1 and 3 for maintenance of left bank breather tube.
- Perform Removal steps 1, 2, and 3 and Installation steps 1, 2, and 3 for maintenance of right bank breather tube.

#### **a. Removal.**

- 1 Remove two tiedown straps (1) securing hose (2) to lifting bracket (3) and breather elbow (4). Discard tiedown straps.
- 2 Remove tiedown strap (5) securing hose (2) to glow plug wiring harness (6). Discard tiedown straps.
- 3 Remove clamp (7) securing hose (2) to breather retainer (8).

#### **b. Installation.**

- 1 Install hose (2) on breather retainer (8) with clamp (7).
- 2 Secure hose (2) to glow plug wiring harness (6) with new tiedown strap (5).
- 3 Secure hose (2) to lifting bracket (3) and breather elbow (4) with two new tiedown straps (1).

---


**Section II. ENGINE ASSEMBLY - CONTINUED**

---

**4-5 BREATHER TUBES - CONTINUED**

---

**b. Installation - Continued**



01ph034m

**NOTE**

**FOLLOW-ON MAINTENANCE:**  
Close and secure air intake grille  
(TM 9-2350-314-10)




**Section III. ENGINE LUBRICATION SYSTEM - CONTINUED**

**4-6 ENGINE OIL FILTER LINES, MOUNTING BRACKET, FITTINGS, ENGINE OIL SAMPLING VALVE, AND ENGINE OIL SENSOR FITTINGS - CONTINUED**

**b. Installation - Continued**

- |                             |                           |                              |                            |
|-----------------------------|---------------------------|------------------------------|----------------------------|
| 1. Oil Filters (para 4-7)   | 8. Angle Bracket          | 16. Screws (2)               | 23. Pipe Flanges (4)       |
| 2. Screws (4)               | 9. Flat Washers (6)       | 17. Elbow                    | 24. Preformed Packings (2) |
| 3. Pipe Bushings (2)        | 10. Self-Locking Nuts (2) | 18. Hose Assembly            | 25. Clamps (2)             |
| 4. Elbow                    | 11. Lockwashers (2)       | 19. Hose Assembly (para 4-1) | 26. Lockwasher             |
| 5. Hose Assembly (para 4-1) | 12. Screws (2)            | 20. Tee                      | 27. Screw                  |
| 6. Screws (2)               | 13. Lockwashers (4)       | 21. Screws (8)               | 28. Elbow                  |
| 7. Mounting Bracket         | 14. Nuts (4)              | 22. Lockwashers (8)          | 29. Valve                  |



01ph036m

---

**Section III. ENGINE LUBRICATION SYSTEM - CONTINUED**


---

**4-6 ENGINE OIL FILTER LINES, MOUNTING BRACKET, FITTINGS, ENGINE OIL SAMPLING VALVE, AND ENGINE OIL SENSOR FITTINGS - CONTINUED**

---

**b. Installation - Continued**

- 30. Tee
- 31. Cluster Fitting
- 32. Pipe Nut



**NOTE**

- FOLLOW-ON MAINTENANCE:**
- Install engine oil pressure transmitter (para 8-49)
  - Install In-tank fuel pumps and generator system relay switch (para 8-48)
  - Install engine oil pressure switch (para 8-47)
  - Close and secure air intake grille (TM 9-2350-314-10)
  - Close and secure transmission access doors (TM 9-2350-314-10)
  - Install generator oil cooling line to oil filter (para 8-9)






Section III. ENGINE LUBRICATION SYSTEM - CONTINUED

4-7 ENGINE OIL FILTER - CONTINUED

a. Removal.

- 1 Remove two drain plugs (1) and drain oil from two oil filters (2) into suitable container.
- 2 Disconnect hose (3) from elbow (4) and hose (5) from tee (6).
- 3 Disconnect hose (7) from elbow (8).
- 4 Remove elbow (4), tee (6), and two bushings (9) from filter adapter (10).
- 5 Remove elbow (8) from filter adapter (10).
- 6 Remove four screws (11), four nuts (12), four lockwashers (13), four flat washers (14), two oil filters (2), and filter adapter (10) from bracket (15). Discard lockwashers.



01ph041m

---

**Section III. ENGINE LUBRICATION SYSTEM - CONTINUED**


---


**4-7 ENGINE OIL FILTER - CONTINUED**


---

**b. Disassembly.**
**NOTE**

- Both oil filters are disassembled and assembled in the same manner.
- This task disassembles and assembles only one oil filter.

- 1 Unscrew center stud (16) and remove cover (17) with filter element assembly (18) and gasket (19) from filter adapter (10). Discard gasket.
- 2 Remove center stud (16), preformed packing (20), filter element (21), retaining ring (22), retainer (23), gasket set (24), and spring (25) from cover (17). Discard gasket set, preformed packing, and retaining ring.
- 3 Remove plug (26) and gasket (27). Discard gasket.



---

## Section III. ENGINE LUBRICATION SYSTEM - CONTINUED

---

### 4-7 ENGINE OIL FILTER - CONTINUED

---


c. Assembly.

- 1 Install center stud (16) with new preformed packing (20) into cover (17).
- 2 Install spring (25), new gasket set (24), retainer (23), new retaining ring (22), and filter element (21) on center stud (16).

#### NOTE

To allow for proper draining of oil filter, the plug must be installed with the drain plug hole positioned downward.

- 3 Install cover (17) with filter element assembly (18) and new gasket (19) on filter adapter (10). Torque center stud to 40-50 lb-ft (54-68 N-m).
- 4 Install plug (26) and new gasket (27).



---

**Section III. ENGINE LUBRICATION SYSTEM - CONTINUED**

---

**4-7 ENGINE OIL FILTER - CONTINUED**

---


**d. Installation.**

- 1 Install two oil filters (2) with filter adapter (10) on filter bracket (15) with four screws (11), four flat washers (14), four new lockwashers (13), and four nuts (12).

**NOTE**

Before elbow can be installed in filter adapter, remove and discard shipping plug.

- 2 Install elbow (8) in filter adapter (10).
- 3 Install two bushings (9), elbow (4), and tee (6) in filter adapter (10).



01ph039m

---

## Section III. ENGINE LUBRICATION SYSTEM - CONTINUED


---

### 4-7 ENGINE OIL FILTER - CONTINUED

---

#### d. Installation - Continued

- 4 Connect hose (7) to elbow (8).
- 5 Connect hose (3) to elbow (4) and hose (5) to tee (6).
- 6 Install two drain plugs (1) in two filters (2).
- 7 Check engine oil level (TM 9-2350-314-10).



#### NOTE

##### FOLLOW-ON MAINTENANCE:

- Close and secure transmission access doors (TM 9-2350-314-10)
- Connect generator oil cooling line at oil filter (para 8-9)

## CHAPTER 5 FUEL SYSTEM

---

### GENERAL

This chapter illustrates and defines procedures for removal, disassembly, assembly, installation, and service of the fuel system, turbocharger, air cleaners, and accelerator, throttle, or choke controls, and related components.

---

<u>CONTENTS</u>	<u>Page</u>
Section I. FUEL PUMPS	
5-1 RIGHT AND LEFT FUEL PUMP AND HANGER ASSEMBLIES .....	5-2
5-2 MECHANICAL FUEL PUMP .....	5-10
5-3 MECHANICAL FUEL PUMP RELIEF VALVE .....	5-13
5-4 MECHANICAL FUEL PUMP TEST .....	5-16
Section II. AIR CLEANER	
5-5 AIR CLEANER ASSEMBLY .....	5-21
5-6 AIR CLEANER BOX ASSEMBLY .....	5-28
5-7 AIR CLEANER DUCT AND HOSES .....	5-30
5-8 AIR CLEANER BRACKET AND BLOWER .....	5-32
Section III. SUPERCHARGER, BLOWER, OR TURBOCHARGER	
5-9 TURBOCHARGER OIL LINE .....	5-34
Section IV. TANKS, LINES, FITTINGS, AND HEADERS	
5-10 DRAIN FUEL TANKS .....	5-36
5-11 FUEL TANK FILLER ASSEMBLY (CAP, SEAL, AND FILLER) .....	5-41
5-12 FUEL TANK LEVEL TRANSMITTERS (UPPER AND LOWER) .....	5-44
5-13 LINES AND FITTINGS (UPPER AND LOWER FUEL TANKS) .....	5-49
5-14 ENGINE FUEL LINES AND FITTINGS .....	5-52
5-15 ELECTRIC FUEL PUMP .....	5-57
Section V. FUEL FILTERS	
5-16 FUEL FILTERS (PRIMARY AND SECONDARY) .....	5-60
5-17 PRIMARY FUEL FILTER AND BRACKET .....	5-64
5-18 SECONDARY FUEL FILTER AND BRACKET .....	5-66
Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS	
5-19 HAND THROTTLE GOVERNOR CONTROL ROD .....	5-76
5-20 ENGINE THROTTLE GOVERNOR CONTROL ROD .....	5-77
5-21 TRANSMISSION THROTTLE CONTROL ADJUSTMENT .....	5-80
5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR .....	5-82
5-23 FUEL SHUTOFF IDENTIFICATION PLATE .....	5-95
5-24 FUEL SHUTOFF CONTROL .....	5-96

## Section I. FUEL PUMPS

---

### 5-1 RIGHT AND LEFT FUEL PUMP AND HANGER ASSEMBLIES.

---

This task covers:      a. Removal                      b. Inspection                      c. Disassembly  
                                    d. Assembly                      e. Installation

---

#### **INITIAL SETUP**

##### Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Multimeter (item 38, Appx F)

##### Materials/Parts

Gasket (item 101, Appx E)  
Gasket (item 240, Appx E)  
Gasket (item 221, Appx E)  
Lockwashers (3) (item 48, Appx E)  
Lockwashers (4) (item 314, Appx E)  
Preformed packing (item 251, Appx E)  
Lockwasher (item 315, Appx E)  
Compression sleeve (right fuel pump) (item 216, Appx E)

##### Equipment Conditions

Vehicle MASTER switch OFF  
(TM 9-2350-314-10)  
Powerpack removed (right fuel  
pump only) (para 4-1)  
Fuel tanks drained  
(TM 9-2350-314-10)  
Engine compartment access cover removed  
(left fuel pump only) (para 16-7)

##### References

TM 9-2350-314-10

---

#### **NOTE**

- Two fuel pump and hanger assemblies are installed in the fuel system.
- Both fuel pump and hanger assemblies are removed and installed in the same manner. This task removes only one.

#### **a. Removal.**

#### **WARNING**


Do not smoke or use open flame when working on fuel systems. An explosion may occur, causing serious injury or death.

- 1 Disconnect electrical wiring harness W113 connector P4 or P5 (1) from fuel pump and hanger assembly (2).
- 2 Remove fuel hose (3) from check valve (4).
- 3 Remove check valve (4) from fuel pump and hanger assembly (2).
- 4 Remove ten screws (5), fuel pump and hanger assembly (2), and gasket (6). Discard gasket.

Section I. FUEL PUMPS - CONTINUED

5-1 RIGHT AND LEFT FUEL PUMP AND HANGER ASSEMBLIES - CONTINUED

a. Removal - Continued



03ph043m



---

## Section I. FUEL PUMPS - CONTINUED


---

### 5-1 RIGHT AND LEFT FUEL PUMP AND HANGER ASSEMBLIES - CONTINUED


---

b. Inspection.

- 1 Inspect fuel pump housing (7). Replace if damaged or defective.
- 2 Inspect fuel pump inlet screens (8). Clean if clogged.
- 3 Inspect electrical cable (9). Replace if frayed or damaged.
- 4 Disconnect and test electrical cable (9) for continuity (para 3-1.3). Replace if shorted or defective.
- 5 Test ground lead (10) for continuity (para 3-1.3). Replace if defective.



LEFT FUEL PUMP



RIGHT FUEL PUMP

03ph044m

---

**Section I. FUEL PUMPS - CONTINUED**


---

**5-1 RIGHT AND LEFT FUEL PUMP AND HANGER ASSEMBLIES - CONTINUED**

---

**b. Inspection - Continued**

- 6 Inspect connector assembly (11). Replace if damaged or deteriorated.
- 7 Test connector assembly (11) for continuity. Replace if shorted or defective.
- 8 Inspect access cover (12). Replace if damaged or defective.
- 9 Inspect discharge fitting (13). Replace if damaged or defective.
- 10 Inspect hose (14 and 15) and tube (16). Replace if cracked or deteriorated.
- 11 Inspect all other components for damage. Replace if damaged.



LEFT FUEL PUMP

RIGHT FUEL PUMP

03ph045m

Section I. FUEL PUMPS - CONTINUED


5-1 RIGHT AND LEFT FUEL PUMP AND HANGER ASSEMBLIES - CONTINUED

c. Disassembly.

NOTE

- Left and right fuel pumps have the same basic components and are disassembled in the same sequence. The right fuel pump has a canted access cover.
- Perform Disassembly steps 1, 2, 4, 5, 7, and 8 and Assembly steps 1, 2, 4, 5, and 7 thru 9 for maintenance of left fuel pump.
- Perform Disassembly steps 1, 3, 4, and 6 thru 8, and Assembly steps 1, 3, 5, 6, 8, and 9 for maintenance of right fuel pump.

- 1 Remove three nuts (17), three lockwashers (18), connector assembly (11), gasket (19), plate (20), and gasket (21) from access cover (12). Discard lockwashers and gaskets.
- 2 Remove nut (22) from discharge fitting (13). (Left fuel pump).
- 3 Remove nut (22), sleeve (23), and tube (16) from discharge fitting (13). Discard sleeve. (Right fuel pump).
- 4 Remove nut (24), lockwasher (25), preformed packing (26), and discharge fitting (13) from access cover (12). Discard preformed packing and lockwasher.
- 5 Remove clamp (27) and hose (14 or 15) from fuel pump (7).
- 6 Remove clamp (27) and separate hose (15) from tube (16).



03ph046m

**Section I. FUEL PUMPS - CONTINUED**

**5-1 RIGHT AND LEFT FUEL PUMP AND HANGER ASSEMBLIES - CONTINUED**

**c. Disassembly - Continued**

- 7 Open latch (28) and separate fuel pump (7) and access cover (12).


**NOTE**

No further disassembly of the fuel pump is possible. If fuel pump is defective, replace pump.

- 8 Remove two screws (29), two nuts (30), four lockwashers (31), and ground lead (10) from access cover (12) and fuel pump (7). Discard lockwashers.

**d. Assembly.**

- 1 Install ground lead (10) on access cover (12) and fuel pump (7) with two screws (29), four new lockwashers (31), and two nuts (30).
- 2 Install fuel pump (7) in access cover (12) and close latch (28).




Section I. FUEL PUMPS - CONTINUED

5-1 RIGHT AND LEFT FUEL PUMP AND HANGER ASSEMBLIES - CONTINUED

d. Assembly - Continued

- 3 Install hose (15) on tube (16) with clamp (27).
- 4 Install hose (14 or 15) on fuel pump (7) with clamp (27).
- 5 Install discharge fitting (13) on access cover (12) with new preformed packing (26), new lockwasher (25), and nut (24).
- 6 Install new sleeve (23) and tube (16) on discharge fitting (13) with nut (22). (Right fuel pump).
- 7 Install hose (14) on discharge fitting (13) with nut (22). (Left fuel pump).
- 8 Install new gasket (21), plate (20), new gasket (19), and connector assembly (11) with three new lockwashers (18) and three nuts (17) on access cover (12).
- 9 Connect shielded electrical cable (9) to connector assembly (11) and fuel pump (7).



03ph048m

---

**Section I. FUEL PUMPS - CONTINUED**



---

**5-1 RIGHT AND LEFT FUEL PUMP AND HANGER ASSEMBLIES - CONTINUED**


---

**e. Installation.**

- 1 Install fuel pump and hanger assembly (2) and new gasket (6) with ten screws (5).
- 2 Install check valve (4) in fuel pump and hanger assembly (2).
- 3 Install fuel hose (3) in check valve (4).
- 4 Connect wiring harness W113 connector P4 or P5 (1) to fuel pump and hanger assembly (2).


**NOTE**
**FOLLOW-ON MAINTENANCE:**

- Install engine compartment access cover (left fuel pump only) (para 16-7)
- Install powerpack (right fuel pump only) (para 4-1)
- Fill fuel tanks (TM 9-2350-314-10)



---

**Section I. FUEL PUMPS - CONTINUED**

---

**5-2 MECHANICAL FUEL PUMP - CONTINUED**

---

**a. Removal - Continued**


- 5 Remove three bolts (8), mechanical fuel pump assembly (9), and gasket (10). Discard gasket.
- 6 Remove coupling fork (11) from drive shaft (12).
- 7 Remove tee (4) and elbow (7) from mechanical fuel pump assembly (9).

**b. Installation.**

- 1 Install elbow (7) and tee (4) on mechanical fuel pump assembly (9).
- 2 Install new gasket (10) on mechanical fuel pump assembly (9).
- 3 Install coupling fork (11) on drive shaft (12).
- 4 Position inlet port on pump body cover (13) (marked "L.H.IN") facing down.

**NOTE**

Make sure coupling fork is aligned with contact slot in drive disc.





---

**Section I. FUEL PUMPS - CONTINUED**


---

**5-2 MECHANICAL FUEL PUMP - CONTINUED**


---

**b. Installation - Continued**

- 5 Install mechanical fuel pump assembly (9) with three bolts (8). Torque bolts to 13-17 lb-ft (18-23 N·m).
- 6 Connect mechanical fuel pump-to-secondary filter tube (6) at elbow (7).
- 7 Connect mechanical fuel pump-to-electric fuel pump hose (5) at tee (4).
- 8 Connect primary filter-to-mechanical fuel pump tube (3) at tee (4).



- 9 Install exhaust crossover tube (2) and tighten two exhaust clamps (1).



**NOTE**

**FOLLOW-ON MAINTENANCE:**  
Install front slope plate (para 16-30)

---

## Section I. FUEL PUMPS - CONTINUED

---

### 5-3 MECHANICAL FUEL PUMP RELIEF VALVE.

---

This task covers: Servicing

---

#### INITIAL SETUP

##### Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Torque wrench (item 86, Appx F)

##### Equipment Conditions

Mechanical fuel pump removed  
(para 5-2)

##### Materials/Parts

Gasket (item 103, Appx E)  
Dry-cleaning solvent (item 59, Appx C)  
Lubricating oil (item 30, Appx C)


---

#### Servicing.

#### WARNING

Do not smoke or use open flame when working on fuel systems. An explosion may occur, causing severe injury or death.

- 1 Remove plug (1) and gasket (2) from mechanical fuel pump (3). Discard gasket.
- 2 Remove spring (4), pin (5), and valve (6) from mechanical fuel pump (3).



## Section I. FUEL PUMPS - CONTINUED

---

### 5-3 MECHANICAL FUEL PUMP RELIEF VALVE - CONTINUED

---

#### Servicing - Continued

**WARNING**

Dry-cleaning solvent (P-D-680) is toxic and flammable. To avoid injury, wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes. Do not breathe vapors. Do not use near open flame or excessive heat. Do not smoke when using solvent. Failure to do so could cause **SERIOUS INJURY**. If you become dizzy while using dry-cleaning solvent, get fresh air immediately, and if necessary, get medical attention. If contact with skin or clothes is made, flush thoroughly with water. If the solvent contacts your eyes, wash them with water immediately and obtain medical aid (FM 21-11).

- 3 Wash valve (6), pin (5), and spring (4) with dry-cleaning solvent.

**WARNING**

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kpa). Use only with effective chip guarding and personal protective equipment (goggles/shield, gloves, etc.)
- Air pressure may create airborne debris. Use eye protection or injury to personnel may result.

- 4 Blow out fuel pump valve port (7) with compressed air.

---

**Section I. FUEL PUMPS - CONTINUED**


---

**5-3 MECHANICAL FUEL PUMP RELIEF VALVE - CONTINUED**

---

**Servicing - Continued**

- 5 Lubricate outside diameter of valve (6) with clean lubricating oil.
- 6 Install valve (6), pin (5), and spring (4) in mechanical fuel pump (3).
- 7 Install new gasket (2) and plug (1) in mechanical fuel pump. Torque plug to 18-22 lb-ft (24-30 N·m).

**NOTE****FOLLOW-ON MAINTENANCE:**

- Install mechanical fuel pump (para 5-2)
- Perform mechanical fuel pump test (para 5-4)



---

## Section I. FUEL PUMPS - CONTINUED

---

### 5-4 MECHANICAL FUEL PUMP TEST - CONTINUED

---

#### a. Test - Continued


**WARNING**

Protective fan screen must be installed prior to doing maintenance in the engine compartment when engine is running or when engine is in ground hop mode. Contact with rotating fan can cause injury.

**NOTE**

Flat side of screen should align with two lower mounting bolts of fan housing.

- 2 Install two fan protective screens (3) with thumb or hex head screw (4), and locknut (5).



## Section I. FUEL PUMPS - CONTINUED

---

### 5-4 MECHANICAL FUEL PUMP TEST - CONTINUED

---

a. Test - Continued

**WARNING**

- The rotation of the radiator cooling fan creates a hazard during maintenance on a running engine. Exercise care to prevent injury, especially to fingers and hands, during maintenance operations on a running engine.
  - Excessive noise levels are present any time equipment is operating. Wear hearing protection while it is running. Failure to do so could result in damage to your hearing.
- 3 Start and warm up engine to 170°F (77°C) (TM 9-2350-314-10).
  - 4 Disconnect fuel return hose (6) at coupling assembly (7), and attach ground hop hose assembly to coupling assembly (7). Coupling assembly is located at rear and radiator side of engine.
  - 5 Place ground hop hose assembly in utility pail to catch fuel.
  - 6 Set engine speed at 1200 rpm (TM 9-2350-314-10).

**NOTE**

Make sure valve in coupling assembly is fully depressed during test for an accurate measurement of fuel flow.

- 7 Depress valve of ground hop hose assembly for one minute and catch fuel in utility pail.
- 8 Shutdown engine (TM 9-2350-314-10).

**NOTE**

Dispose of drained fuel in an appropriate manner.


- 9 Measure fuel in 2 qt liquid measure. If fuel flow is less than 1/2 gallon (1.9 liter) per minute, perform shaft check. If fuel flow is 1/2 gallon (1.9 liter) or more per minute, go to next step.

Section I. FUEL PUMPS - CONTINUED


5-4 MECHANICAL FUEL PUMP TEST - CONTINUED

a. Test - Continued

10 Disconnect ground hop hose assembly, and connect fuel return hose (6) at coupling assembly (7).



11 Loosen locknut (5) and thumb or hex head screw (4). Remove two fan protective screens (3).





---

## Section I. FUEL PUMPS - CONTINUED


---

### 5-4 MECHANICAL FUEL PUMP TEST - CONTINUED


---

b. Shaft check.

- 1 Remove top pump body drain plug (8).
- 2 Insert a small wire (approximate size and length of a straightened paper clip) in pump body hole (9).
- 3 While holding wire, rotate shaft by momentarily cranking engine. If no vibration is felt, replace mechanical fuel pump (para 5-2). If vibration is felt, shaft is good. Check and clean mechanical fuel pump relief valve (para 5-3).
- 4 Install drain plug (8).
- 5 Connect fuel return hose (6) at coupling assembly (7).



- 6 Loosen locknut (5) and thumb or hex head screw (4). Remove two fan protective screens (3).



#### NOTE

#### FOLLOW-ON MAINTENANCE:

Close and secure air intake grille  
(TM 9-2350-314-10)

---

## Section II. AIR CLEANER

---

### 5-5 AIR CLEANER ASSEMBLY.

---

This task covers:    a. Removal                    b. Disassembly                    c. Assembly                    d. Installation

---

#### **INITIAL SETUP**

##### Tools

General mechanic's tool kit  
(SC 5180-90-N26)

##### Materials/Parts

Nonmetallic seals (2) (item 109, Appx E)  
Gaskets (2) (item 110, Appx E)  
Gaskets (2) (item 107, Appx E)  
Gaskets (2) (item 106, Appx E)  
Gaskets (2) (item 105, Appx E)  
Adhesive (item 4, Appx C)  
Self-locking nuts (28) (item 15, Appx E)  
Lockwasher (item 9, Appx E)  
Lockwashers (2) (item 22, Appx E)  
Lockwashers (8) (item 3, Appx E)  
Lockwashers (22) (item 20, Appx E)

##### Equipment Conditions

Filter packs removed  
(TM 9-2350-314-10)  
Air cleaner duct and hoses disconnected  
(para 5-7)

##### References

TM 9-2350-314-10

---

## Section II. AIR CLEANER - CONTINUED

---

### 5-5 AIR CLEANER ASSEMBLY - CONTINUED

---

#### a. Removal.

- 1 Remove screw (1), lockwasher (2), and clamp (3). Discard lockwasher.
- 2 Disconnect hose (4) from adapter (5) and remove adapter (5).

#### NOTE

Support air cleaner boxes prior to performing step 3.

- 3 Remove eight screws (6), eight flat washers (7), and eight lockwashers (8). Discard lockwashers.

#### CAUTION

Damage to air cleaner duct may result if duct is not supported during removal of air cleaner.

- 4 Lower air cleaner box assemblies (9) to hull deck.
- 5 Remove 28 self-locking nuts (10) and 28 flat washers (11) securing air cleaner duct (12) to air cleaner box assemblies (9). Discard self-locking nuts.
- 6 Lift air cleaner duct (12) clear of lugs (13).
- 7 Remove left and right air cleaner box assemblies (9) from vehicle.


#### b. Disassembly.

- 1 Remove and discard two gaskets (14).
- 2 Disconnect hose (4) from indicator (15).
- 3 Remove two screws (16), two nuts (17), two lockwashers (18), and indicator (15) from bracket (19). Discard lockwashers.
- 4 Remove two screws (20), two flat washers (21), two lockwashers (22), and bracket (19) from left box assembly (23). Discard lockwashers.
- 5 Deleted
- 6 Remove 20 screws (30), 20 flat washers (31), 20 lockwashers (32), two box assemblies (23), and two gaskets (33). Discard lockwashers and two gaskets.

Section II. AIR CLEANER - CONTINUED

5-5 AIR CLEANER ASSEMBLY - CONTINUED

b. Disassembly - Continued



03ph058m

## Section II. AIR CLEANER - CONTINUED

---

### 5-5 AIR CLEANER ASSEMBLY - CONTINUED

---

#### b. Disassembly - Continued

- 7 Remove nonmetallic seal (34) from each box assembly (23). Discard nonmetallic seal.
- 8 Remove gasket (35) from each air cleaner assembly door (36). Discard gaskets.
- 9 Remove gasket (37) from each air cleaner box assembly (9). Discard gaskets.
- 10 Remove eight screws (38) and latch assembly (39) from each air cleaner box assembly (9).

#### c. Assembly.

- 1 Install latch assembly (39) with eight screws (38) in each air cleaner box assembly (9).

#### NOTE


Apply adhesive to gaskets 35 minutes prior to installation.

- 2 Install new gasket (37) in each air cleaner box assembly (9).
- 3 Install new gasket (35) in each air cleaner assembly door (36).
- 4 Install new nonmetallic seal (34) on each box assembly (23).
- 5 Install two box assemblies (23) and two new gaskets (33) with 20 screws (30), 20 new lockwashers (32), and 20 flat washers (31).
- 6 Step deleted.
- 7 Step deleted.
- 8 Install bracket (19) on left box assembly (23) with two screws (20), two new lockwashers (22), and two flat washers (21).
- 9 Install indicator (15) on bracket (19) with two screws (16), two new lockwashers (18), and two nuts (17).
- 10 Connect hose (4) to indicator (15).
- 11 Install two new gaskets (14).

Section II. AIR CLEANER - CONTINUED

5-5 AIR CLEANER ASSEMBLY - CONTINUED

c. Assembly - Continued



03ph059m

## Section II. AIR CLEANER - CONTINUED

---

### 5-5 AIR CLEANER ASSEMBLY - CONTINUED

---

#### d. Installation.

- 1 Position left and right air cleaner box assemblies (9) so air cleaner duct (12) can be installed.
- 2 Place air cleaner duct (12) over lugs (13) and install 28 flat washers (11) and 28 new self-locking nuts (10).

#### **NOTE**

Supports under air cleaner boxes may help position assembly for installation.

- 3 Install air cleaner box assemblies (9) on hull wall with eight screws (6), eight new lockwashers (8), and eight flat washers (7).
- 4 Install adapter (5) and connect hose (4) to adapter (5).
- 5 Install clamp (3) with screw (1) and new lockwasher (2).

#### **NOTE**


Apply new decal only if illegible or if air cleaner door is replaced.

- 6 Apply new decal (40) (para 18-13).

Section II. AIR CLEANER - CONTINUED

5-5 AIR CLEANER ASSEMBLY - CONTINUED

d. Installation - Continued



03ph060m

**NOTE**

**FOLLOW-ON MAINTENANCE:**  
 Connect air cleaner ducts and hoses (para 5-7)  
 Install filter packs (TM 9-2350-314-10)



## Section II. AIR CLEANER - CONTINUED

---

### 5-6 AIR CLEANER BOX ASSEMBLY.

---

This task covers:      a. Disassembly                      b. Assembly

---

#### **INITIAL SETUP**

##### Tools

General mechanic's tool kit  
(SC 5180-90-N26)

##### Materials/Parts

Spring pin (item 112, Appx E)  
Adhesive (item 1 or 2, Appx C)  
Nonmetallic seal (item 113, Appx E)  
Lockwashers (2) (item 20, Appx E)

##### Equipment Conditions

Air box removed from air cleaner  
(para 5-5)  
Clogged filter indicator bracket  
removed (left side box) (para 5-5)

---

#### a. Disassembly.

##### **NOTE**

- Screws, lockwashers, and flat washers are removed with indicator bracket for left side box.
- Right side is illustrated.

- 1 For right side box, remove two screws (1), two lockwashers (2), and two flat washers (3).
- 2 Remove spring pin (4) from pin (5). Discard spring pin.
- 3 Remove pin (5), spring (6), and two spacers (7) from baffle (8).
- 4 Remove baffle (8) from box (9).
- 5 Remove seal (10) from baffle (8). Discard seal.

#### b. Assembly.

##### **NOTE**


Apply adhesive to seal 35 minutes prior to assembly.

- 1 Install new seal (10) in baffle (8).
- 2 Install baffle (8) in box (9) with pin (5), spring (6), two spacers (7), and new spring pin (4).
- 3 For right side box, install two flat washers (3), two new lockwashers (2), and two screws (1).

Section II. AIR CLEANER - CONTINUED

5-6 AIR CLEANER BOX ASSEMBLY - CONTINUED

b. Assembly - Continued



**NOTE**

**FOLLOW-ON MAINTENANCE:**  
Install clogged filter indicator (left side box) bracket (para 5-5)  
Install air box on air cleaner (para 5-5)

03ph061m

**Section II. AIR CLEANER - CONTINUED**

---

**5-7 AIR CLEANER DUCT AND HOSES.**

---

This task covers: a. Removal b. Installation

---

**INITIAL SETUP**

Tools

General mechanic's tool kit  
(SC 5180-90-N26)

Equipment Conditions

Powerpack removed (For elbow duct and turbocharger hose only) (para 4-1)

Materials/Parts

Gasket (item 108, Appx E)  
Lockwashers (10) (item 3, Appx E)

---

**a. Removal.**

**NOTE**

Note the different length and location of screws being removed for proper installation and brackets.

- 1 Remove two screws (1), two flat washers (2), two lockwashers (3), and bracket (4) from right air cleaner (4.1). Discard lockwashers.
- 1.1 Remove screw (4.2), lockwasher (4.3), and flat washer (4.4). Discard lockwasher.
- 2 Remove two screws (5), six flat washers (6) and shield (7) from left air cleaner (7.1).
- 2.1 Remove screw (7.2), lockwasher (7.3), flat washer (7.4) and bracket (7.5). Discard lockwasher.
- 3 Remove four hose clamps (8) and two air cleaner-to-duct exhaust hoses (9).
- 4 Remove two hose clamps (10) and air cleaner duct-to-elbow duct hose (11).
- 5 Remove four hose clamps (12) and two duct exhaust-to-elbow hoses (13).
- 6 Remove hose clamp (14), coupling (15), and turbocharger hose (16).
- 7 Remove six screws (17), six flat washers (18), and six lockwashers (19). Discard lockwashers.
- 8 Remove elbow duct (20) and gasket (21) through bulkhead into engine compartment. Discard gasket.


**b. Installation.**

- 1 Install elbow duct (20) and new gasket (21) with six screws (17), six new lockwashers (19), and six flat washers (18).
- 2 Install turbocharger hose (16) with hose clamp (14) and coupling (15).
- 3 Install two exhaust-to-elbow hoses (13) with four hose clamps (12).
- 4 Install air cleaner duct-to-elbow duct hose (11) with two hose clamps (10).
- 5 Install two air cleaner-to-duct exhaust hoses (9) with four hose clamps (8).
- 5.1 Install bracket (7.5), flat washer (7.4), new lockwasher (7.3) and screw (7.2).
- 6 Install shield (7) with two screws (5) and six flat washers (6) to left air cleaner (7.1).
- 6.1 Install flat washer (4.4), new lockwasher (4.3) and screw (4.2).
- 7 Install bracket (4), two new lockwashers (3), two flat washers (2), and two screws (1) to right air cleaner (4.1).

Section II. AIR CLEANER - CONTINUED

5-7 AIR CLEANER DUCT AND HOSES - CONTINUED

b. Installation - Continued



03ph062m

**NOTE**

**FOLLOW-ON MAINTENANCE:**  
Install powerpack (For elbow duct and turbocharger hose only) (para 4-1)

## Section II. AIR CLEANER - CONTINUED

---

### 5-8 AIR CLEANER BRACKET AND BLOWER.

---

This task covers:          a. Removal                                  b. Installation

---

<b>INITIAL SETUP</b>
----------------------

Tools

General mechanic's tool kit  
(SC 5180-90-N26)

Materials/Parts

Lockwashers (4) (item 3, Appx E)  
Lockwashers (4) (item 5, Appx E)  
Self-locking nuts (2) (item 115, Appx E)

---

**a. Removal.**

- 1 Disconnect four electrical leads (1) at air cleaner blower motors (2).
- 2 Loosen four clamps (3) and disconnect four hoses (4) from air cleaner blower motors (2).
- 3 Loosen two screws (5) on two clamps (6).
- 4 Pull air cleaner blower motors (2) out of two clamps (6).
- 5 Remove four screws (7), four lockwashers (8), two clamps (6), and two pads (9). Discard lockwashers.
- 6 Remove two screws (10), two flat washers (11), and two lockwashers (12). Discard lockwashers.
- 7 Remove two screws (13), four flat washers (14), two lockwashers (15), two nuts (16), and bracket (17). Discard lockwashers.
- 8 Remove two screws (5) and two self-locking nuts (18). Discard self-locking nuts.


**b. Installation.**

- 1 Install bracket (17) with two screws (13), two new lockwashers (15), four flat washers (14), and two nuts (16).
- 2 Install two screws (10), two new lockwashers (12), and two flat washers (11).
- 3 Install two screws (5) and two new self-locking nuts (18) in two clamps (6). Do not tighten.
- 4 Install two clamps (6) and two pads (9) with four new lockwashers (8) and four screws (7).
- 5 Install air cleaner blower motors (2) in two clamps (6).
- 6 Tighten two screws (5) in two clamps (6).
- 7 Connect four hoses (4) to air cleaner blower motors (2) and tighten four clamps (3).
- 8 Connect four electrical leads (1) of air cleaner blower motors (2).

Section II. AIR CLEANER - CONTINUED

5-8 AIR CLEANER BRACKET AND BLOWER - CONTINUED

b. Installation - Continued



03ph063m

---

### Section III. SUPERCHARGER, BLOWER, OR TURBOCHARGER.

---

#### 5-9 TURBOCHARGER OIL LINE.

---

This task covers:      a. Removal    b. Installation

---

**INITIAL SETUP**

Tools

General mechanic's tool kit  
(SC 5180-90-N26)

Equipment Conditions

Engine oil drained  
(Table 2-1; PMCS item 37)  
Powerpack removed (para 4-1)

Materials/Parts

Tiedown straps (2) (item 43, Appx E)

---

#### a. Removal.

- 1 Remove two tiedown straps (1). Discard tiedown straps.
- 2 Loosen two clamps (2) and remove oil line (3).


#### b. Installation.

- 1 Install oil line (3) with two clamps (2).
- 2 Install two new tiedown straps (1).

Section III. SUPERCHARGER, BLOWER, OR TURBOCHARGER - CONTINUED

5-9 TURBOCHARGER OIL LINE - CONTINUED

b. Installation - Continued



03ph064m

**NOTE**

**FOLLOW-ON MAINTENANCE:**  
 Install powerpack (para 4-1)  
 Fill engine with oil  
 (Table 2-1; PMCS item 37)






Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED

5-10 DRAIN FUEL TANKS - CONTINUED

a. Draining.

- 1 Drive vehicle (TM 9-2350-314-10) over pit to provide clearance for suitable container used to catch fuel.
- 2 Remove three screws (1), three flat washers (2), access cover (3), and gasket (4). Discard gasket.
- 3 Remove fuel plug (5) and drain fuel into suitable container.



## Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED

---

### 5-10 DRAIN FUEL TANKS - CONTINUED

---

#### a. Draining - Continued

- 4 Attach adapter (6) and fuel hose extension (7) to main fuel line at quick-disconnect (8).
- 5 Place open end of fuel hose extension (7) in 55-gallon drum to catch fuel.

#### NOTE





If powerpack has been removed perform steps 7 thru 11 and steps 13 thru 16.

- 6 Disconnect harness W105 connector P1 (9) from harness W104 connector J1 (10) at engine disconnect bracket (11).
- 7 Connect a jumper wire (12) from socket S of harness W105 connector P1 (9) to ground.
- 8 Connect battery ground cables, if disconnected (para 8-35).
- 9 Place vehicle MASTER switch in ON position (TM 9-2350-314-10) to operate fuel pumps and drain fuel tanks.
- 10 Place vehicle MASTER switch in OFF position (TM 9-2350-314-10) to stop fuel pumps when fuel tanks are empty.
- 11 Remove jumper wire (12) from ground and socket S of harness W105 connector P1 (9).
- 12 Connect harness W105 connector P1 (9) to harness W104 connector J1 (10) at engine disconnect bracket (11).
- 13 Disconnect adapter (6) and fuel hose extension (7) from quick-disconnect (8).
- 14 Connect quick-disconnect (8) to main fuel line.
- 15 Disconnect battery ground cables (para 8-33), if required, prior to performance of refueling maintenance.
- 16 Dispose of drained fuel in an appropriate manner.

Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED

5-10 DRAIN FUEL TANKS - CONTINUED

a. Draining - Continued



03ph090m

---

**Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED**


---

**5-10 DRAIN FUEL TANKS - CONTINUED**

---

**b. Refueling.**

- 1 Install fuel plug (5).
- 2 Install access cover (3) and new gasket (4) with three flat washers (2) and three screws (1).
- 3 Refuel vehicle (TM 9-2350-314-10).





## Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED

---

### 5-11 FUEL TANK FILLER ASSEMBLY (CAP, SEAL, AND FILLER) - CONTINUED

---

#### a. Removal - Continued

#### NOTE

Top washer, outer seal, inner seal, and bottom washer can be removed as an assembly.

- 3 Remove eight screws (4), top washer (5), outer seal (6), inner seal (7), and bottom washer (8).
- 4 Remove six screws (9), six flat washers (10), and six lockwashers (11). Discard lockwashers.

#### WARNING

Dry-cleaning solvent (P-D-680), used to clean parts, is toxic and flammable. Wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes. Do not breathe vapors. Do not use near open flame or excessive heat. Do not smoke when using solvent. Failure to do so could cause SERIOUS INJURY. If you become dizzy while using dry-cleaning solvent, get fresh air immediately, and if necessary, get medical attention. If contact with skin or clothes is made, flush thoroughly with water. If the solvent contacts your eyes, wash with water immediately, and obtain medical aid (ref. FM 21-11).

- 5 Remove fuel strainer element (3). Clean with dry-cleaning solvent.
- 6 Remove filler neck (12), gasket (13), spacer (14), and gasket (15). Discard gaskets.

#### b. Installation.

- 1 Install fuel strainer element (3) in filler neck (12).
- 2 Install new gasket (15), spacer (14), new gasket (13), filler neck (12), and fuel strainer element (3) with six screws (9), six new lockwashers (11), and six flat washers (10).

**Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED**


**5-11 FUEL TANK FILLER ASSEMBLY (CAP, SEAL, AND FILLER) - CONTINUED**

**b. Installation - Continued**

**NOTE**

Bottom washer, inner seal, outer seal, and top washer can be installed as an assembly.

- 3 Install bottom washer (8), inner seal (7), outer seal (6), and top washer (5) with eight screws (4).
- 4 Secure filler cap chain (2) to fuel strainer element (3).
- 5 Install filler cap (1).



03ph066m

**NOTE**

**FOLLOW-ON MAINTENANCE:**  
Install fuel fill access door (para 16-32)



**Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED**

---

**5-12 FUEL TANK LEVEL TRANSMITTERS (UPPER AND LOWER).**

---

This task covers:          a. Removal                                  b. Installation

---

**INITIAL SETUP**

Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Torque wrench (item 84, Appx F)

Equipment Conditions

Exhaust grille removed  
(para 16-25)  
Fuel tank drained (lower transmitter only)  
(para 5-10)

Materials/Parts

Lockwashers (3) (item 9, Appx E)  
Self-locking nuts (7) (item 120, Appx E)  
Self-locking nuts (2) (item 118, Appx E)  
Sealing compound (item 51, Appx C)  
Gaskets (2) (upper level transmitter) (item 119, Appx E)  
Sealing compound (item 50, Appx C)  
Gasket (lower level transmitter) (item 119, Appx E)

---

**NOTE**

- Perform Removal steps 1 thru 4 and Installation steps 7 thru 10 for maintenance of upper fuel tank transmitter.
- Perform Removal steps 5 thru 9 and Installation steps 1 thru 6 for maintenance of lower fuel tank level transmitter.

**a. Removal.**

**WARNING**

Do not smoke or use open flame when working on the fuel system. An explosion may occur, causing severe injury or death.


- 1 Remove three screws (1), three lockwashers (2) and cover (3). Discard lockwashers.
- 2 Disconnect electrical connector (4).

Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED

5-12 FUEL TANK LEVEL TRANSMITTERS (UPPER AND LOWER) - CONTINUED

a. Removal - Continued

- 3 Remove five screws (5), five flat washers (6), and ground lead (7).
- 4 Remove transmitter (8), two gaskets (9), and spacer (10). Discard gaskets.



03ph067m

## Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED

---

### 5-12 FUEL TANK LEVEL TRANSMITTERS (UPPER AND LOWER) - CONTINUED

---

#### a. Removal - Continued

- 5 Remove seven self-locking nuts (11), flat washer (12), screw (13), flat washer (14), bar (15), retainer (16), and seal (17). Discard self-locking nuts.
- 6 Remove two self-locking nuts (18), two flat washers (19), and plate (20). Discard self-locking nuts.
- 7 Remove electrical connector (21).
- 8 Remove five screws (22), five flat washers (23), and ground lead (24).
- 9 Remove transmitter (25) and gasket (26). Discard gasket.

#### b. Installation.

- 1 Apply sealing compound (item 51, Appx C) to mating surfaces of new gasket (26).

#### NOTE


Notch in gasket must be aligned with transmitter electrical connector for proper installation.

- 2 Install transmitter (25), new gasket (26), and ground lead (24) with five screws (22) and five flat washers (23). Torque screws to 28-32 lb-in. (3.1-3.6 N·m).
- 3 Connect electrical connector (21).
- 4 Install plate (20) with two new self-locking nuts (18) and two flat washers (19).
- 5 Apply sealing compound (item 50, Appx C) to screw (13).
- 6 Install bar (15), seal (17), and retainer (16) with seven new self-locking nuts (11), flat washer (12), flat washer (14), and screw (13).

Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED

5-12 FUEL TANK LEVEL TRANSMITTERS (UPPER AND LOWER) - CONTINUED

b. Installation - Continued



03ph068m

---

**Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED**

---

**5-12 FUEL TANK LEVEL TRANSMITTERS (UPPER AND LOWER) - CONTINUED**

---


**b. Installation - Continued**

- 7 Apply sealing compound (item 51, Appx C) to mating surfaces of two new gaskets (9).

**NOTE**

Notch in gaskets and spacer must be aligned with transmitter electrical connector for proper installation.

- 8 Install transmitter (8), two new gaskets (9), spacer (10), and ground lead (7) with five screws (5) and five flat washers (6). Torque screws to 22-26 lb-in. (2.5-2.9 N-m).
- 9 Connect electrical connector (4).
- 10 Install cover (3) with three screws (1) and three new lockwashers (2).



**NOTE**

**FOLLOW-ON MAINTENANCE:**  
Install exhaust grille (para 16-25)  
Fill fuel tank (TM 9-2350-314-10)

**Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED**

**5-13 LINES AND FITTINGS (UPPER AND LOWER FUEL TANKS).**

This task covers:      a. Removal    b. Installation

<b>INITIAL SETUP</b>
----------------------

Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Torque wrench (item 84, Appx F)

Equipment Conditions

Powerpack removed (para 4-1)  
Fuel tanks drained (para 5-10)

Materials/Parts

Sealing compound (item 52, Appx C)  
Antiseizing tape (item 60, Appx C)  
Lockwashers (10) (item 9, Appx E)  
Lockwasher (item 22, Appx E)

**a. Removal.**

<b>WARNING</b>
----------------

Do not use open flame or smoke when working on the fuel system. An explosion may occur, causing severe injury or death.

**NOTE**

- Remove only those hoses and tubes which must be replaced.
  - Tag all hoses, tubes, brackets, and fittings prior to removal to aid in installation.
- 1 Remove exhaust heat shield (para 6-3), if required.
  - 2 Remove hoses, tubes, brackets, and fittings in accordance with the following legend and illustration.
  - 3 Remove clamps and attaching hardware securing hoses, tubes, and brackets to vehicle as shown in legend and illustration. Discard lockwashers.

---

**Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED**

---

**5-13 LINES AND FITTINGS (UPPER AND LOWER FUEL TANKS) - CONTINUED**

---

**b. Installation.**

**NOTE**

Apply antiseize tape or sealing compound to all pipe threads during installation.

- 1 Install hoses, tubes, brackets, and fittings in accordance with the following legend and illustration.
- 2 Secure hoses, tubes, and brackets to vehicle with clamps, attaching hardware, and new lockwashers as shown in legend and illustration.
- 3 Tighten hose clamp (32) to 35 - 40 lb-in (3.9 - 4.5 N·m).
- 4 Install exhaust heat shield (para 6-3), if required.


**LEGEND**

- |   |  |
|---|--|
| 1. Upper fuel tank                        | 23. Personnel heater hose                        |
| 2. Lower fuel tank                        | 24. Fuel tank pump hose                          |
| 3. Upper-to-lower fuel tank drain hose    | 25. Terminal fitting to primary fuel filter hose |
| 4. Adapter                                | 26. Elbows (2)                                   |
| 5. Elbow                                  | 27. Lower fuel tank return hose                  |
| 6. Upper-to-lower fuel tank breather hose | 28. Adapters (2)                                 |
| 7. Adapters (2)                           | 29. Coupling clamp                               |
| 8. Clamps (2)                             | 30. Hose flange                                  |
| 9. Tee                                    | 31. Upper-to-lower drain tank main drain         |
| 10. Adapter                               | 32. Hose clamp                                   |
| 11. Lower fuel tank breather tube         | 33. Fuel pump                                    |
| 12. Elbow                                 | 34. Fuel pump                                    |
| 13. Fuel tank drain hose                  | 35. Screws (3)                                   |
| 14. Nut                                   | 36. Lockwasher                                   |
| 15. Washer                                | 37. Loop clamps (8)                              |
| 16. Elbow                                 | 38. Screws (4)                                   |
| 17. Plug                                  | 39. Lockwashers (10)                             |
| 18. Fuel pump discharge check valves (2)  | 40. Screws (5)                                   |
| 19. Fuel tank pump hose                   | 41. Loop clamp                                   |
| 20. Adapters (2)                          | 42. Nuts (2)                                     |
| 21. Fuel distribution terminal fitting    | 43. Elbow  |
| 22. Adapters (2)                          | 44. Bracket                                      |

Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED

5-13 LINES AND FITTINGS (UPPER AND LOWER FUEL TANKS) - CONTINUED

b. Installation - Continued



03ph070m

**NOTE**

**FOLLOW-ON MAINTENANCE:**

- Install powerpack (para 4-1)
- Fill fuel tank (TM 9-2350-314-10)



---

## Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED

---

### 5-14 ENGINE FUEL LINES AND FITTINGS.

---

This task covers:      a. Removal                                      b. Installation

---

**INITIAL SETUP**

Tools

General mechanic's tool kit  
(SC 5180-90-N26)

Equipment Conditions

Transmission access doors  
open (TM 9-2350-314-10)  
Air intake grille open and  
secured (TM 9-2350-314-10)

Materials/Parts

Antiseizing tape (item 60, Appx C)  
Lockwashers (6) (item 91, Appx E)  
Lockwashers (4) (item 5, Appx E)  
Preformed packings (4) (item 124, Appx E)  
Lockwashers (2) (item 22, Appx E)  
Lockwashers (2) (item 122, Appx E)  
Lockwasher (item 20, Appx E)  
Lockwashers (2) (item 123, Appx E)

References

TM 9-2350-314-10

---

**a. Removal.**

**WARNING**

Do not smoke or use open flame when working on fuel system. An explosion may occur, causing severe injury or death.

**NOTE**

- Remove only those hoses and tubes which must be replaced.
  - Tag all hoses, tubes, brackets, and fittings prior to removal to aid in installation.
- 1 Remove hoses, tubes, brackets, and fittings in accordance with the following legend and illustration.
  - 2 Remove clamps and attaching hardware securing hoses, tubes, and brackets as shown in legend and illustration. Discard lockwashers.

---

**Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED**

---

**5-14 ENGINE FUEL LINES AND FITTINGS - CONTINUED**

---

b. Installation.

**NOTE**

Apply antiseizing tape to all male pipe threads during installation.

- 1 Install hoses, tubes, brackets, and fittings in accordance with the following legend and illustration.
- 2 Secure hoses, tubes, and brackets with clamps, attaching hardware, and new lockwashers as shown in legend and illustration.

---

**Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED**

---

**5-14 ENGINE FUEL LINES AND FITTINGS - CONTINUED**

---

**b. Installation - Continued**

**LEGEND:**

- |                                    |  |
|------------------------------------|--|
| 1. Screws (4)                      | 34. Adapters (2)   |
| 2. Bracket (para 5-17)             | 35. Bushing (para 5-2)   |
| 3. Lockwashers (6)                 | 36. Tee (para 5-2)   |
| 4. Screws (6)                      | 37. Elbow (para 5-2)   |
| 5. Plugs (2)                       | 38. Engine-driven fuel pump (para 5-2)                                     |
| 6. Primary fuel filter (para 5-17) | 39. Engine-driven fuel pump to electric fuel pump hose assembly (para 5-2) |
| 7. Elbows (2)                      | 40. Elbow  |
| 8. Elbow                           | 41. Bushing  |
| 9. Flat washers (4)                | 42. Coupling assembly  |
| 10. Lockwashers (4)                | 43. Bracket  |
| 11. Nuts (4)                       | 44. Flat washer  |
| 12. Adapters (2)                   | 45. Clamp  |
| 13. Packings (4)                   | 46. Screw  |
|                                    | 47. Clamp  |
|                                    | 48. Flat washer  |
|                                    | 49. Lockwasher   |
|                                    | 50. Nut  |
|                                    | 51. Bracket (para 5-18)  |
|                                    | 52. Clamp  |
|                                    | 53. Fuel hose assembly   |
|                                    | 54. Elbow  |
|                                    | 55. Tee  |
|                                    | 56. Elbow  |
|                                    | 57. Elbow  |
|                                    | 58. Fuel supply pressure transducer (para 8-45)                            |
|                                    | 59. Secondary fuel filter (para 5-18)                                      |
|                                    | 60. Fuel pressure differential transducer (para 8-44)                      |
|                                    | 61. Elbow  |
|                                    | 62. Fuel line  |
|                                    | 63. Tee  |
|                                    | 64. Nuts (2)   |
|                                    | 65. Lockwashers (2)  |
|                                    | 66. Clamps (4)   |
|                                    | 67. Screws (2)   |
|                                    | 68. Flat washers (3)   |
|                                    | 69. Fuel line (para 4-1)   |
|                                    | 70. Fuel line (para 4-1)   |
|                                    | 71. Elbow (para 5-2)   |
|                                    | 72. Elbow  |

**NOTE**


- Install one check valve with free flow direction indicator toward fuel pump.
- Install one check valve with free flow direction indicator toward secondary filter.

14. Check valves (2)
15. Nipples (2)
16. Sleeve
17. Nut
18. Primary fuel filter to engine-driven fuel pump tube
19. Screws (2)
20. Clamp
21. Bracket with attaching hardware
22. Lockwashers (2)
23. Nuts (2)
24. Elbow
25. Clamps (7) with attaching hardware
26. Primary fuel filter to engine-driven fuel pump tube (para 4-1)
27. Nuts (2)
28. Lockwashers (2)
29. Bracket (para 5-15)
30. Screws (2)
31. Electric fuel pump (para 5-15)
32. Coupler
33. Elbow

Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED

5-14 ENGINE FUEL LINES AND FITTINGS - CONTINUED

b. Installation - Continued




03ph072m

Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED

5-14 ENGINE FUEL LINES AND FITTINGS - CONTINUED

b. Installation - Continued



03ph073m

**NOTE**

**FOLLOW-ON MAINTENANCE:**

- Close and secure air intake grille  
(TM 9-2350-314-10)
- Close and secure transmission access doors  
(TM 9-2350-314-10)

---

**Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED**

---

**5-15 ELECTRIC FUEL PUMP.**

---

This task covers:      a. Removal                              b. Installation

---

**INITIAL SETUP**

Tools

General mechanic's tool kit  
(SC 5180-90-N26)

Equipment Conditions

Air intake grille open and secured  
(TM 9-2350-314-10)  
Front slope plate removed (para 16-30)

Materials/Parts

Lockwashers (2) (item 122, Appx E)  
Preformed packings (2) (item 124, Appx E)

References

TM 9-2350-314-10

---

Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED


5-15 ELECTRIC FUEL PUMP - CONTINUED

a. Removal.

**WARNING**

Do not smoke or use open flame when working on fuel system. An explosion may occur, causing severe injury or death.

- 1 Disconnect wiring harness W104 wire 588 (1) from electric fuel pump lead.
- 2 Remove hose (2), elbow (3), and coupling (4) from electric fuel pump (5).
- 3 Remove hose (6), nipple (7), preformed packing (8), check valve (9), preformed packing (10), adapter (11), and elbow (12) from electric fuel pump (5). Discard preformed packings.
- 4 Remove two screws (13), two nuts (14), two lockwashers (15), and electric fuel pump (5) from bracket (16). Discard lockwashers.



03ph074m

---

**Section IV. TANKS, LINES, FITTINGS, AND HEADERS - CONTINUED**



---

**5-15 ELECTRIC FUEL PUMP - CONTINUED**


---

**b. Installation.**

- 1 Install electric fuel pump (5) on bracket (16) with two screws (13), two new lockwashers (15), and two nuts (14).
- 2 Install elbow (12), adapter (11), new preformed packing (10), check valve (9), new preformed packing (8), nipple (7), and hose (6) to electric fuel pump (5).
- 3 Install coupling (4), elbow (3), and hose (2) to electric fuel pump (5).
- 4 Connect wiring harness W104 wire 588 (1) to electric fuel pump lead.


**NOTE**

**FOLLOW-ON MAINTENANCE:**  
 Install front slope plate (para 16-30)  
 Close and secure air intake grille  
 (TM 9-2350-314-10)



## Section V. FUEL FILTERS

---

### 5-16 FUEL FILTERS (PRIMARY AND SECONDARY).

---

This task covers: Service

---

#### **INITIAL SETUP**

##### Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Utility pail (item 40, Appx F)

##### Materials/Parts

Dry-cleaning solvent  
(item 59, Appx C)  
Filter element with gaskets (primary)  
(item 125, Appx E)  
Filter element with gaskets (secondary)  
(item 126, Appx E)

##### Equipment Conditions

Transmission access doors  
open (TM 9-2350-314-10)  
Fuel supply line disconnected  
(para 4-1)

##### References

TM 9-2350-314-10

---

Service.

#### **WARNING**

Do not smoke or use open flame when working on fuel system. An explosion may occur, causing severe injury or death.

- 1 Open fuel filter draincock (1) and drain fuel into utility pail. Close fuel filter draincock (1).
- 2 Remove bolt (2), gasket (3), and fuel filter canister (4) from filter head (5). Discard gasket.
- 3 Remove filter element (6) from filter canister (4) and gasket (7) from filter head (5). Discard element and gasket.

Section V. FUEL FILTERS - CONTINUED


5-16 FUEL FILTERS (PRIMARY AND SECONDARY) - CONTINUED

Service - Continued

**WARNING**

Dry-cleaning solvent (P-D-680) is toxic and flammable. To avoid injury, wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes. Do not breathe vapors. Do not use near open flame or excessive heat. Do not smoke when using solvent. Failure to do so could cause **SERIOUS INJURY**. If you become dizzy while using dry-cleaning solvent, get fresh air immediately, and if necessary, get medical attention. If contact with skin or clothes is made, flush thoroughly with water. If the solvent contacts your eyes, wash them with water immediately and obtain medical aid (FM 21-11).

4 Wash fuel filter canister (4) with dry-cleaning solvent.



03ph075m

---

Section V. FUEL FILTERS - CONTINUED

---


5-16 FUEL FILTERS (PRIMARY AND SECONDARY) - CONTINUED

---

Service - Continued

**WARNING**

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment (goggles/shield, gloves, etc.).
  - Air pressure may create airborne debris. Use eye protection or injury to personnel may result.
- 5 Blow out fuel filter canister (4) with compressed air.
  - 6 Make sure element seat (8) and retaining ring (9) have not slipped out of place. Check spring (10) by pressing on element seat (8). When spring (10) is released, the element seat (8) must return against retaining ring (9).
  - 7 Check spring seat (11) and gasket (12) for wear or deterioration.



03ph076m

---

**Section V. FUEL FILTERS - CONTINUED**


---

**5-16 FUEL FILTERS (PRIMARY AND SECONDARY) - CONTINUED**

---

**Service - Continued**

- 8 Install new gasket (7), new filter element (6), and filter canister (4) on filter head (5).
- 9 Install bolt (2) and new gasket (3) securing filter canister (4) with new fuel filter element (6) to filter head (5). Tighten bolt (2) enough to prevent fuel leakage.



03ph077m

**NOTE****FOLLOW-ON MAINTENANCE:**

Close and secure transmission access doors  
(TM 9-2350-314-10)  
Connect fuel supply line (para 4-1)

## Section V. FUEL FILTERS - CONTINUED

---

### 5-17 PRIMARY FUEL FILTER AND BRACKET.

---

This task covers:      a. Removal                                      b. Installation

---

#### **INITIAL SETUP**

##### Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Suitable container

##### Equipment Conditions

Right transmission access door  
opened (TM 9-2350-314-10)

##### Materials/Parts

Antiseizing tape (item 60, Appx C)  
Lockwashers (3) (item 91, Appx E)  
Lockwashers (2) (item 5, Appx E)

##### References

TM 9-2350-314-10

---

#### a. Removal.

#### **WARNING**

Do not smoke or use open flame when working on fuel system. An explosion may occur, causing severe injury or death.

- 1 Open fuel filter draincock (1) and drain fuel into suitable container. Remove fuel filter draincock (1).
- 2 Disconnect fuel line (2) from elbow (3).
- 3 Remove elbow (3) from fuel filter (4).
- 4 Disconnect fuel line (5) from check valve (6).
- 5 Remove check valve (6) from elbow (7).
- 6 Remove elbow (7) and two plugs (8) from fuel filter (4).
- 7 Remove two bolts (9), two nuts (10), two lockwashers (11), two flat washers (12), and fuel filter (4) from bracket (13). Discard lockwashers.
- 8 Remove three bolts (14), three lockwashers (15), and bracket (13). Discard lockwashers.

**Section V. FUEL FILTERS - CONTINUED**

**5-17 PRIMARY FUEL FILTER AND BRACKET - CONTINUED**


**b. Installation.**

- 1 Install bracket (13) with three bolts (14) and three new lockwashers (15).
- 2 Install fuel filter (4) with two bolts (9), two flat washers (12), two new lockwashers (11), and two nuts (10).
- 3 Install two plugs (8) and elbow (7) in fuel filter (4).

**NOTE**

Apply antiseizing tape to all male pipe threads during installation.

- 4 Install check valve (6) on elbow (7) and connect fuel line (5).
- 5 Install elbow (3) on fuel filter (4) and connect fuel line (2) to elbow (3).
- 6 Install fuel filter draincock (1) in fuel filter (4).



03ph078m

**NOTE**

**FOLLOW-ON MAINTENANCE:**  
 Close and secure right transmission access door  
 (TM 9-2350-314-10)  
 Prime fuel system (TM 9-2350-314-10)



---

**Section V. FUEL FILTERS - CONTINUED**


---

**5-18 SECONDARY FUEL FILTER AND BRACKET - CONTINUED**

---

**a. Removal - Continued**

- 2 Disconnect fuel line hose (2) at elbow (3).
- 3 Remove elbow (3), tee (4), and elbow (5) from fuel filter (6).
- 4 Disconnect tube (7) from elbow (8).
- 5 Remove elbow (8) from fuel filter (6).
- 6 Disconnect tube (9) from tee (10).
- 7 Remove tube (11) from tee (10) and elbow (12).
- 8 Disconnect connector (13) from wiring harness W102 connector P4 (14).
- 9 Remove elbow (12), transducer (15), elbow (16), and tee (10) from fuel filter (6).



03ph080m



---

## Section V. FUEL FILTERS - CONTINUED

---


### 5-18 SECONDARY FUEL FILTER AND BRACKET - CONTINUED

---

a. Removal - Continued

10 Remove two bolts (17), two nuts (18), two lockwashers (19), two flat washers (20), and fuel filter (6) from bracket (21). Discard lockwashers.

11 Remove three bolts (22), three lockwashers (23), and bracket (21). Discard lockwashers.




03ph081m

**Section V. FUEL FILTERS - CONTINUED**

**5-18 SECONDARY FUEL FILTER AND BRACKET - CONTINUED**

**b. Disassembly.**

- 1 Remove bolt (24), gasket (25), and filter head (26) from fuel filter canister (27). Discard gasket.
- 2 Remove filter element (28) from fuel filter canister (27). Remove gasket (29) from filter head (26). Discard element and gasket.
- 3 Remove retaining ring (30), element seat (31), gasket (32), spring seat (33), and spring (34) from fuel filter canister (27). Discard retaining ring, gasket, and spring seat.



03ph082m

---

Section V. FUEL FILTERS - CONTINUED

---

5-18 SECONDARY FUEL FILTER AND BRACKET - CONTINUED


---

c. Assembly.

**WARNING**

Dry-cleaning solvent (P-D-680) is toxic and flammable. To avoid injury, wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes. Do not breathe vapors. Do not use near open flame or excessive heat. Do not smoke when using solvent. Failure to do so could cause **SERIOUS INJURY**. If you become dizzy while using dry-cleaning solvent, get fresh air immediately, and if necessary, get medical attention. If contact with skin or clothes is made, flush thoroughly with water. If the solvent contacts your eyes, wash them with water immediately and obtain medical aid (FM 21-11).

- 1 Wash fuel filter canister (27) with dry-cleaning solvent.



03ph083m

---

**Section V. FUEL FILTERS - CONTINUED**

---

**5-18 SECONDARY FUEL FILTER AND BRACKET - CONTINUED**


---

## c. Assembly - Continued

**WARNING**

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment.
- Air pressure may create airborne debris. Use eye protection or injury to personnel may result.

- 2 Blow out fuel filter canister (27) with compressed air.
- 3 Install spring (34), new spring seat (33), new gasket (32), element seat (31), and new retaining ring (30) in fuel filter canister (27).
- 4 Install drain cock (1) in fuel filter canister (27).



03ph084m

---

## Section V. FUEL FILTERS - CONTINUED


---

### 5-18 SECONDARY FUEL FILTER AND BRACKET - CONTINUED

---

#### c. Assembly - Continued

- 5 Install new gasket (29), new fuel filter element (28), and fuel filter canister (27) on filter head (26).
- 6 Install bolt (24) and new gasket (25) securing filter canister (27) with fuel filter element (28) to filter head (26). Tighten bolt (24) enough to prevent fuel leakage.



03ph085m

---

**Section V. FUEL FILTERS - CONTINUED**


---

**5-18 SECONDARY FUEL FILTER AND BRACKET - CONTINUED**

---

**d. Installation.**

- 1 Install bracket (21) with three bolts (22) and three new lockwashers (23).
- 2 Install fuel filter (6) on bracket (21) with two bolts (17), two flat washers (20), two new lockwashers (19), and two nuts (18).



03ph086m

## Section V. FUEL FILTERS - CONTINUED

---

### 5-18 SECONDARY FUEL FILTER AND BRACKET - CONTINUED

---

#### d. Installation - Continued

#### NOTE


Apply antiseizing tape to all male pipe fittings during installation.

- 3 Install elbow (16), elbow (8), tee (10), and elbow (5) in fuel filter (6).
- 4 Install transducer (15) on elbow (16).
- 5 Install elbow (12) in transducer (15).
- 6 Connect connector (13) to wiring harness W102 connector P4 (14).
- 7 Install tube (11) in elbow (12) and tee (10).
- 8 Connect tube (9) to tee (10).
- 9 Connect tube (7) to elbow (8).
- 10 Install tee (4) and elbow (3) on elbow (5).
- 11 Connect fuel line hose (2) to elbow (3).

Section V. FUEL FILTERS - CONTINUED

5-18 SECONDARY FUEL FILTER AND BRACKET - CONTINUED

d. Installation - Continued



**NOTE**

**FOLLOW-ON MAINTENANCE:**  
 Install fuel supply pressure transducer  
 (para 8-43)



**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS.**

**5-19 HAND THROTTLE GOVERNOR CONTROL ROD.**

This task covers: Adjustment

**INITIAL SETUP**

Tools


General mechanic's tool kit  
(SC 5180-90-N26)

Materials/Parts

Cotter pin (item 127, Appx E)

**Adjustment.**

- 1 Position hand throttle lever (1) so positioning hole in lever is in line with positioning hole "X" in cover (2). Insert drive pin punch.
- 2 Remove cotter pin (3) and headed pin (4) from throttle lever (5). Remove rod assembly (6) from throttle lever (5). Discard cotter pin.
- 3 Position throttle lever (5) so positioning hole (7) in throttle lever (5) is in line with positioning hole in driver's bulkhead. Insert drive pin punch.
- 4 Loosen two nuts (8) and adjust rod ends (9) so that headed pin (4) can be easily inserted through lever (5) and rod end (9).
- 5 Install headed pin (4) and new cotter pin (3).
- 6 Tighten two nuts (8) and remove two drive pin punches.



**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED**

**5-20 ENGINE THROTTLE GOVERNOR CONTROL ROD.**

This task covers: Adjustment

**INITIAL SETUP**

Tools

General mechanic's tool kit  
(SC 5180-90-N26)

Personnel Required

Two

Equipment Conditions


Air intake grille open and secured  
(TM 9-2350-314-10)

References

TM 9-2350-314-10

**Adjustment.**

- 1 Fully depress accelerator pedal (1) to move engine throttle governor control rod assembly (2) away from driver's bulkhead.



03ph104m

---

**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED**

---

**5-20 ENGINE THROTTLE GOVERNOR CONTROL ROD - CONTINUED**

---


**Adjustment - Continued**

- 2 Remove quick-release pin (3) and disconnect engine throttle governor control rod assembly (2) from lever (4).
- 3 Push engine throttle governor control rod assembly (2) toward rear of vehicle (accelerator still depressed).

**NOTE**

Make sure engine throttle governor control rod lever does not bottom out bracket.

- 4 Note whether quick-release pin (3) can be easily inserted in lever (4) and engine throttle governor control rod end (5). If it cannot, loosen nut (6) on engine throttle governor control rod assembly (2) and rotate engine throttle governor control rod end (5) 1/2 turn at a time until quick-release pin (3) can be easily inserted into lever (4) and engine throttle governor control rod end (5).
- 5 Install quick-release pin (3) and tighten nut (6). Release accelerator pedal (1). Throttle should release fully to idle position.



03ph105m

---

**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED**


---

**5-20 ENGINE THROTTLE GOVERNOR CONTROL ROD - CONTINUED**

---

**Adjustment - Continued**

- 6 Fully depress accelerator pedal (1). Loosen nut (7) and adjust pedal stop screw (8) to allow 0 to 1/16" (0 to 0.15 cm) clearance from pedal (1) at wide open throttle. Governor operating range is 32°/30 min. Tighten nut (7) against bulkhead.



03ph106m

**NOTE****FOLLOW-ON MAINTENANCE:**

Close and secure air intake grille  
(TM 9-2350-314-10)

---

**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED**

---

**5-21 TRANSMISSION THROTTLE CONTROL ADJUSTMENT.**

---

This task covers:        Adjustment

---

**INITIAL SETUP**

Tools

General mechanic's tool kit  
(SC 5180-90-N26)

Personnel Required

Two

References

TM 9-2350-314-10


Equipment Conditions

Air intake grille open and secured  
(TM 9-2350-314-10)  
Hull front slope plate removed (para 16-30)

---

**Adjustment.**

- 1 Perform engine throttle governor control rod adjustment (para 5-20).
- 2 Remove locking pin (1), headed pin (2) and disconnect transmission throttle valve control rod assembly (3) from lever (4) on throttle control lever bracket (5).



03ph108m

---

**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED**



---

**5-21 TRANSMISSION THROTTLE CONTROL ADJUSTMENT - CONTINUED**


---

**Adjustment - Continued**

- 3 Fully depress accelerator pedal (6) and hold in depressed position (lever on throttle control lever bracket will move toward driver's bulkhead).
- 4 Move transmission throttle valve lever (7) against internal stop (toward driver's bulkhead).
- 5 Loosen nut (8) on transmission throttle valve control rod assembly (3) and rotate rod 1/2 turn at a time until pin (2) fits freely in rod end (9) and lever (4) with zero compression on spring (10).
- 6 Release accelerator pedal (6).
- 7 Remove pin (2) and rod end (9) from lever (4).
- 8 Adjust rod end (9) approximately two turns shorter clockwise and tighten nut (8) against rod end (9). This prevents positive stop (located in transmission selector valve body) from acting as engine stop.
- 9 Secure transmission throttle valve control rod assembly (3) to lever (4) on throttle control bracket (5) with headed pin (2) and locking pin (1). Transmission valve operating range - 32°/30 min.


**NOTE**

**FOLLOW-ON MAINTENANCE:**  
 Install hull front slope plate (para 16-30)  
 Close and secure air intake grille  
 (TM 9-2350-314-10)

---

## Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED

---

### 5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR.

---

This task covers:            a. Removal            b. Disassembly            c. Assembly            d. Installation

---

#### **INITIAL SETUP**

##### Tools

General mechanic's tool kit  
(SC 5180-90-N26)

##### Materials/Parts

Cotter pins (2) (item 130, Appx E)  
Cotter pins (5) (item 8, Appx E)  
Cotter pin (item 127, Appx E)  
Spring pins (2) (item 134, Appx E)  
Spring pins (2) (item 133, Appx E)  
Spring pins (2) (item 135, Appx E)  
Spring pin (item 132, Appx E)  
Lockwashers (5) (item 3, Appx E)  
Lockwashers (8) (item 9, Appx E)  
Lockwire (item 160, Appx E)

##### Equipment Conditions

Air intake grille open and secured  
(TM 9-2350-314-10)  
Powerpack removed (para 4-1)  
(required for vertical rod assembly, lever,  
accelerator support assembly, and pedal and  
shaft assembly only)

##### Personnel Required

Four

##### Reference

TM 9-2350-314-10

---


#### a. Removal.

- 1 Remove locking pin (1) and headed pin (2) at bellcrank (3).
- 2 Remove two cotter pins (4), three flat washers (5), spring (6), and rod assembly (7) from throttle control lever (8). Discard cotter pins.
- 3 Remove throttle control lever (8), if damaged.
- 4 Remove wire (9), chain (10), and quick-release pin (11) at bellcrank (12). Discard wire.
- 5 Remove cotter pin (13) and two flat washers (14) from end of governor control rod assembly (15). Discard cotter pin.
- 6 Remove two cotter pins (16), two flat washers (17), and two headed pins (18) at bellcrank (12) and bellcrank (3) and remove rod assembly (19). Discard cotter pins.
- 7 Remove spring pin (20) and pin (21) and remove bellcrank (12). Discard spring pin.

Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED

5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR - CONTINUED

a. Removal - Continued



03ph092m




Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED

5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR - CONTINUED

a. Removal - Continued

- 8 Remove two cotter pins (22), two flat washers (23), two headed pins (24), and rod assembly (25). Discard cotter pins.
- 9 Remove three screws (26), three flat washers (27), three lockwashers (28), and bracket (29) from hull bulkhead.
- 10 Remove spring pin (30) and lever (31). Discard spring pin.
- 11 Remove three screws (32), three lockwashers (33), and accelerator support assembly (34) from bulkhead. Discard lockwashers.



03ph093m

---

**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED**


---


**5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR - CONTINUED**


---

**a. Removal - Continued**
**NOTE**

Throttle control rod is part of hand throttle control assembly.

- 12 Remove cotter pin (35), headed pin (36), and throttle control rod (37) from driver's compartment. Discard cotter pin.
- 13 Remove screw (38), star spring washer (39), and throttle control assembly (40).
- 14 Remove spring (41), two screws (42), two flat washers (43), two lockwashers (44), support bracket (45), and pedal and shaft assembly (46).
- 15 Twist pedal and shaft assembly (46) to clear bracket and withdraw from bulkhead.




03ph094m

Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED

5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR - CONTINUED

b. Disassembly.

- 1 Loosen seven nuts (47) and remove seven rod ends (48) from five shafts (49) on five rod assemblies (7, 15, 19, 25, and 37). Remove seven nuts (47) from five shafts (49).




03ph095m

**NOTE**

Bearings are to be removed only if damaged.

- 2 Remove two spring pins (50), lever (51), bellcrank (3), and shaft (52) from bracket (29). Remove two bearings (53 and 54) from bracket (29). Discard spring pins.




03ph096m

**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED**

**5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR - CONTINUED**


**b. Disassembly - Continued**

- 3 Remove two screws (55), two lockwashers (56), cap (57), and bearing (58) from bracket (59). Discard lockwashers.



03ph097m

- 4 Remove three screws (60), three lockwashers (61), cap (62), and bearings (63) from bracket (45). Discard lockwashers.
- 5 Remove two spring pins (64), collar (65), and pedal (46) from shaft (66). Discard spring pins.
- 6 Remove spring pin (67) and shaft (66) from lever (68). Discard spring pin.




03ph098m

Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED

5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR - CONTINUED


b. Disassembly - Continued

- 7 Separate cover (69) and two disks (70) from lever (71) with rod assembly (37).
- 8 Loosen nut (72) and remove lever (71) from shaft (49). Remove nut (72) from shaft (49).



03ph099m

- 9 Loosen nut (73) and remove screw (74) from accelerator stop. Separate nut (73) from screw (74).




03ph100m

**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED**

**5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR - CONTINUED**

**c. Assembly.**

- 1 Install nut (73) on screw (74) and install screw (74) in accelerator stop. Tighten nut (73) onto accelerator stop.




- 2 Install nut (72) on shaft (49) and install lever (71) on shaft (49).

**NOTE**

Make sure alignment holes are aligned properly during assembly.

- 3 Attach two disks (70) and cover (69) to lever (71) with rod assembly (37).



---

**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED**


---

**5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR - CONTINUED**

---


**c. Assembly - Continued**

- 4 Install shaft (66) in lever (68) with new spring pin (67).
- 5 Install pedal (46) on shaft (66) with collar (65) and two new spring pins (64).
- 6 Install bearing (63), if removed, in bracket (45) with cap (62), three screws (60), and three new lockwashers (61).



03ph098m

- 7 Install bearing (58), if removed, in bracket (59), with cap (57), two screws (55), and two new lockwashers (56).




03ph097m

Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED

5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR - CONTINUED


c. Assembly - Continued

- 8 Install two bearings (53 and 54), if removed, shaft (52), lever (51), and bell crank (3) on bracket (29) with two new spring pins (50).



- 9 Install seven nuts (47) on five shafts (49).

- 10 Install seven rod ends (48) on five rod assemblies (7, 15, 19, 25, and 37). Tighten nuts (47) against rod ends (48).





---

**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED**


---

**5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR - CONTINUED**

---

**d. Installation.**

- 1 Install pedal and shaft assembly (46) to support bracket (45) with spring (41), two screws (42), two new lockwashers (44), and two flat washers (43).
- 2 Install throttle control assembly (40) with screw (38) and star spring washer (39).
- 3 Install throttle control rod assembly (37) in driver's compartment with headed pin (36) and new cotter pin (35).




03ph094m

**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED**

**5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR - CONTINUED**

**d. Installation - Continued**

- 4 Install accelerator support assembly (34) at bulkhead with three screws (32) and three new lockwashers (33).
- 5 Install lever (31) and new spring pin (30).
- 6 Install bracket (29) to bulkhead with three screws (26), three lockwashers (28), and three flat washers (27).
- 7 Install rod assembly (25) in levers (51 and 31) with two headed pins (24), two flat washers (23), and two new cotter pins (22).




03ph103m

**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED**

**5-22 ACCELERATOR, THROTTLE, AND ENGINE CONTROL GOVERNOR - CONTINUED**

**d. Installation - Continued**

- 8 Install bellcrank (12) with pin (21) and new spring pin (20).
- 9 Install rod assembly (19) in bellcrank (12) and bellcrank (3) with two headed pins (18), two flat washers (17), and two new cotter pins (16).
- 10 Install two flat washers (14) and new cotter pin (13) at end of governor control rod assembly (15).
- 11 Install quick-release pin (11), new wire (9), and new chain (10), if necessary, at bellcrank (12).
- 12 Install throttle control lever (8), if removed due to damage.
- 13 Install rod assembly (7), spring (6), three flat washers (5), and two new cotter pins (4).
- 14 Install headed pin (2) and locking pin (1) at bellcrank (3).



03ph101m

**NOTE**

**FOLLOW-ON MAINTENANCE:**

- Install powerpack (para 4-1), if removed
- Close and secure air intake grille  
(TM 9-2350-314-10)
- Adjust hand throttle governor control rod (para 5-19)
- Adjust transmission throttle control (para 5-21)

---

**Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED**

---

**5-23 FUEL SHUTOFF IDENTIFICATION PLATE.**

---

This task covers:          a. Removal                                  b. Installation

---

**INITIAL SETUP**Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Electric drill (item 15, Appx F)  
Twist drill set (item 16, Appx F)

Materials/Parts

Drive screws (2) (item 136, Appx E)


---

**a. Removal.**

Remove two screws (1) and identification plate (2) from engine compartment bulkhead in driver's compartment. Discard drive screws.

**b. Installation.**

Install identification plate (2) on engine compartment bulkhead in driver's compartment with two new drive screws (1).



03ph113m

## Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED

---

### 5-24 FUEL SHUTOFF CONTROL.

---

This task covers:      a. Disassembly                      b. Assembly

---

#### **INITIAL SETUP**

##### Tools

General mechanic's tool kit  
(SC 5180-90-N26)

##### Equipment Conditions

Air intake grille open and secured  
(TM 9-2350-314-10)

##### Materials/Parts

Cotter pins (2) (item 137, Appx E)  
Lockwashers (3) (item 9, Appx E)  
Assembled screws (2) (item 298, Appx E)

##### References

TM 9-2350-314-10

---


#### **a. Disassembly.**

- 1 Remove cotter pin (1) and headed pin (2) from engine lever clevis (3). Discard cotter pin.
- 2 Remove chain (4) from cable (5).
- 3 Remove quick-release pin (6) and fuel shutoff clevis (3) from engine governor.
- 4 Remove hook (7) with chain (4) from quick-release pin (6).
- 5 Remove cotter pin (8) from headed pin (9). Discard cotter pin.
- 6 Remove flat washer (10), pulley (11), cable (5), headed pin (9), and spring (12) from bracket (13).
- 7 Remove two assembled screws (14) and bracket (13) from engine governor. Discard assembled screws.
- 8 Remove three screws (15), three lockwashers (16), and mounting plate (17) with cable (5) from engine bulkhead. Discard lockwashers.

Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED

5-24 FUEL SHUTOFF CONTROL - CONTINUED

a. Disassembly - Continued



## Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED

---

### 5-24 FUEL SHUTOFF CONTROL - CONTINUED

---


#### b. Assembly.

- 1 Insert cable (5) through engine bulkhead and install bracket (17) with three screws (15) and three new lockwashers (16).
- 2 Install bracket (13) with two new assembled screws (14) on engine governor.
- 3 Place cable (5) around pulley (11) and install pulley (11), flat washer (10), spring (12), headed pin (9), and new cotter pin (8) to bracket (13).
- 4 Attach chain (4) to quick-release pin (6) with hook (7).
- 5 Install fuel shutoff clevis (3) and quick-release pin (6) on engine governor.
- 6 Install cable (5) in fuel shutoff clevis (3) with headed pin (2).
- 7 Secure headed pin (2) with new cotter pin (1).
- 8 Install chain (4) around cable (5).

Section VI. ACCELERATOR, THROTTLE, OR CHOKE CONTROLS - CONTINUED

5-24 FUEL SHUTOFF CONTROL - CONTINUED

b. Assembly - Continued



**NOTE**

**FOLLOW-ON MAINTENANCE:**  
 Close and secure air intake grille  
 (TM 9-2350-314-10)



# CHAPTER 6

## EXHAUST SYSTEM

---

### GENERAL

This chapter illustrates and defines procedures for removal, disassembly, assembly, and installation of the exhaust system, insulation, and related components.

---

<u>CONTENTS</u>		<u>Page</u>
6-1	EXHAUST OUTLET PIPE AND INSULATION .....	6-2
6-2	EXHAUST DUCT, INSULATION BLANKET, AND HANGER .....	6-4
6-3	EXHAUST HEAT SHIELD AND INSULATION PAD .....	6-6



## 6-1 EXHAUST OUTLET PIPE AND INSULATION.

---

This task covers:      a. Removal    b. Installation

---

### **INITIAL SETUP**

#### Tools

General mechanic's tool kit  
(SC 5180-90-N26)

#### Equipment Conditions

Powerpack removed (para 4-1)

#### Materials/Parts

Cotter pins (2) (item 93, Appx E)

---

### a. Removal.

#### **WARNING**

Make sure engine and exhaust systems are cool enough to permit handling. Failure to do so may cause serious burns to personnel.

#### **NOTE**

To ease removal of flange, remove one cotter pin, castle nut, washer, spring, and screw; then rotate flange to access other castle nut.


- 1 Remove two cotter pins (1), two castle nuts (2), two screws (3), two flat washers (4), and two springs (5) from engine exhaust outlet pipe (6) and exhaust duct (7) flanges. Discard cotter pins.
- 2 Remove clamp (8) and remove exhaust outlet pipe (6) from turbocharger (9).
- 3 Remove three clamps (10) and two insulation blanket halves (11) from exhaust outlet pipe (6).

### b. Installation.

- 1 Install two insulation blanket halves (11) on exhaust outlet pipe (6) with three clamps (10).
- 2 Install exhaust outlet pipe (6) on turbocharger (9) with clamp (8).
- 3 Align and secure engine exhaust outlet pipe (6) and exhaust duct (7) flanges with two screws (3), two springs (5), two flat washers (4), two castle nuts (2), and two new cotter pins (1).

6-1 EXHAUST OUTLET PIPE AND INSULATION - CONTINUED

b. Installation - Continued



NOTE

FOLLOW-ON MAINTENANCE:  
Install powerpack (para 4-1)

## 6-2 EXHAUST DUCT, INSULATION BLANKET, AND HANGER.

---

This task covers:      a. Removal                                      b. Installation

---

### **INITIAL SETUP**

#### Tools

General mechanic's tool kit

(SC 5180-90-N26)

Wire twisting pliers (item 43, Appx F)

#### Materials/Parts

Lock wire (item 310, Appx E)

---

#### Equipment Conditions

Powerpack removed

(para 4-1)

#### **a. Removal.**


- 1 Disconnect two springs (1) from hanger (2) and remove exhaust duct (3).
- 2 Remove two springs (1) from exhaust duct (3).
- 3 Remove two screws (4), two flat washers (5), and hanger (2) from engine bulkhead.
- 4 Remove ten lock wires (6) and insulation blanket (7) from exhaust duct (3). Discard wires.

#### **b. Installation.**

- 1 Install insulation blanket (7) with ten new lock wires (6) on exhaust duct (3).
- 2 Install hanger (2) on engine bulkhead with two screws (4) and two flat washers (5).
- 3 Install two springs (1) on exhaust duct (3).
- 4 Position exhaust duct (3) at hanger (6) and connect two springs (1).

6-2 EXHAUST DUCT, INSULATION BLANKET, AND HANGER - CONTINUED

b. Installation - Continued



04ph010m

**NOTE**

**FOLLOW-ON MAINTENANCE:**  
Install powerpack (para 4-1)

### 6-3 EXHAUST HEAT SHIELD AND INSULATION PAD.

---

This task covers:    a. Removal                      b. Disassembly                      c. Assembly                      d. Installation

---

#### **INITIAL SETUP**

##### Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Hand riveter (item 55, Appx F)

##### Materials/Parts

Sealing compound (item 51, Appx C)  
Adhesive (item 3, Appx C)  
Dry-cleaning solvent (item 59, Appx C)  
Self-locking nuts (3) (item 118, Appx E)  
Self-locking nuts (4) (item 16, Appx E)  
Self-locking nuts (35) (item 120, Appx E)  
Lockwashers (17) (item 9, Appx E)  
Nonmetallic seal (item 140, Appx E)  
Seals (2) (item 141, Appx E)  
Seals (2) (item 142, Appx E)  
Seal (item 143, Appx E)  
Seal (item 144, Appx E)  
Seal (item 145, Appx E)  
Seal (item 146, Appx E)  
Seals (2) (item 147, Appx E)  
Solid rivets (18) (item 139, Appx E)  
Blind rivets (5) (item 138, Appx E)  
Seal (item 148, Appx E)  
Seal (item 149, Appx E)  
Insulation pad (item 150, Appx E)

##### Equipment Conditions

Fan access door removed (para 16-26)  
Hull exhaust grille removed (para 16-25)  
Exhaust outlet pipe removed (para 6-1)

##### Personnel Required


Two

---

## 6-3 EXHAUST HEAT SHIELD AND INSULATION PAD - CONTINUED

### a. Removal.

- 1 Remove two screws (1), two jamnuts (2), and two brackets (3).
- 2 Remove 11 screws (4) and 11 flat washers (5) from exhaust heat shield (6).
- 3 Remove screw (7), flat washer (8), and self-locking nut (9) to separate bracket (10) from support stiffener (11).
- 4 Remove screw (12) and flat washer (13) from bracket (14).
- 5 Remove exhaust heat shield (6) from vehicle.
- 6 Remove two screws (15), two flat washers (16), and bracket (10) from vehicle.




04ph004m

### 6-3 EXHAUST HEAT SHIELD AND INSULATION PAD - CONTINUED

b. Disassembly.

- 1 Remove two self-locking nuts (17), two flat washers (18), support stiffener (11), and bracket (14). Discard self-locking nuts.
- 2 Remove two screws (19), two flat washers (20), and two stiffeners (21).
- 3 Remove two screws (22), four flat washers (23), two self-locking nuts (24), and support (25). Discard self-locking nuts.




04ph005m



## 6-3 EXHAUST HEAT SHIELD AND INSULATION PAD - CONTINUED

### b. Disassembly - Continued

- 4 Remove 14 self-locking nuts (26), bar (27), two stiffeners (28), three seal segments (29), and three retainer segments (30). Discard self-locking nuts and seal segments.
- 5 Remove three screws (31), three lockwashers (32), and cover (33). Discard lockwashers.
- 6 Remove two self-locking nuts (34), two flat washers (35), and cover (36). Discard self-locking nuts.
- 7 Remove five self-locking nuts (37), five flat washers (38), plate (39), and seal (40). Discard self-locking nuts and seal.
- 8 Remove four self-locking nuts (41), four flat washers (42), plate (43), and seal (44). Discard self-locking nuts and seal.




04ph006m

## 6-3 EXHAUST HEAT SHIELD AND INSULATION PAD - CONTINUED

### b. Disassembly - Continued

- 9 Remove five self-locking nuts (45), five flat washers (46), baffle (47), plate (48), and seal (49). Discard self-locking nuts and seal.
- 10 Remove five screws (50), five self-locking nuts (51), five flat washers (52), separating plate (53), and seal (54) from baffle (47). Discard self-locking nuts and seal.
- 11 Remove four screws (55), two self-locking nuts (56), four flat washers (57), retainer (58), and two plug nuts (59). Discard self-locking nuts.
- 12 Remove seven rivets (60), seven flat washers (61), and seal (62) from retainer (58). Discard rivets and seal.




04ph007m

## 6-3 EXHAUST HEAT SHIELD AND INSULATION PAD - CONTINUED

### b. Disassembly - Continued

- 13 Remove insulation pad (63).
- 14 Remove retainer (64) and insulation (65).
- 15 Remove five rivets (66), retainer (67), and seal (68). Discard rivets and seal.
- 16 Remove seven rivets (69), seven flat washers (70), and seal (71). Discard rivets and seal.
- 17 Remove four rivets (72), four flat washers (73), and two seals (74). Discard rivets and seals.
- 18 Remove 14 screws (75), 14 lockwashers (76), retainer (77), and seal (78) from access cover (79). Discard lockwashers and seal.



04ph008m


## 6-3 EXHAUST HEAT SHIELD AND INSULATION PAD - CONTINUED

### c. Assembly.

#### NOTE

- Tighten all nuts and screws attaching rubber seals to show slight compression of seal.
- Apply a thin coating of sealing compound to threads of screws that do not use a self-locking nut.

- 1 Install new seal (78), retainer (77), 14 screws (75), and 14 new lockwashers (76) on access cover (79).
- 2 Install two new seals (74), four flat washers (73), and four new rivets (72).
- 3 Install new seal (71), seven flat washers (70), and seven new rivets (69).
- 4 Install new seal (68), retainer (67), and five new rivets (66).



04ph009m

---

## 6-3 EXHAUST HEAT SHIELD AND INSULATION PAD - CONTINUED


---

### c. Assembly - Continued

**WARNING**

Dry-cleaning solvent (P-D-680) is toxic and flammable. To avoid injury, wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes. Do not breathe vapors. Do not use near open flame or excessive heat. Do not smoke when using solvent. Failure to do so could cause **SERIOUS INJURY**. If you become dizzy while using dry-cleaning solvent, get fresh air immediately, and if necessary, get medical attention. If contact with skin or clothes is made, flush thoroughly with water. If the solvent contacts your eyes, wash them with water immediately and obtain medical aid (FM 21-11).


- 5 Clean insulation pad mounting surface with dry-cleaning solvent.
- 6 Install insulation (65) and retainer (64).
- 7 Install insulation pad (63) with adhesive.



### 6-3 EXHAUST HEAT SHIELD AND INSULATION PAD - CONTINUED

#### c. Assembly - Continued

- 8 Install new seal (62), seven flat washers (61), and seven new rivets (60) on retainer (58).
- 9 Install retainer (58), four screws (55), four flat washers (57), and two new self-locking nuts (56) and two plug nuts (59).
- 10 Install new seal (54), plate (53), five screws (50), five flat washers (52), and five new self-locking nuts (51) to baffle (47).
- 11 Install baffle (47) with plate (48) and seal (49), five flat washers (46), and five new self-locking nuts (45).




04ph007m

## 6-3 EXHAUST HEAT SHIELD AND INSULATION PAD - CONTINUED

### c. Assembly - Continued

- 12 Install new seal (44), plate (43), four flat washers (42), and four new self-locking nuts (41).
- 13 Install new seal (40), plate (39), five flat washers (38), and five new self-locking nuts (37).
- 14 Install cover (36), two flat washers (35), and two new self-locking nuts (34).
- 15 Install cover (33), three screws (31), and three new lockwashers (32).
- 16 Install three retainer segments (30), three new seal segments (29), two stiffeners (28), bar (27), and fourteen new self-locking nuts (26).




04ph006m

### 6-3 EXHAUST HEAT SHIELD AND INSULATION PAD - CONTINUED

#### c. Assembly - Continued

- 17 Install support (25), two screws (22), four flat washers (23), and two new self-locking nuts (24).
- 18 Install two stiffeners (21), two screws (19), and two flat washers (20).
- 19 Install support stiffener (11) and bracket (14), two flat washers (18), and two new self-locking nuts (17).




04ph005m



## 6-3 EXHAUST HEAT SHIELD AND INSULATION PAD - CONTINUED

### d. Installation.

- 1 Install bracket (10) on vehicle with two screws (15) and two flat washers (16).
- 2 Install exhaust heat shield (6) in vehicle.
- 3 Install bracket (14) with screw (12) and flat washer (13).
- 4 Install bracket (10) on support stiffener (11) with screw (7), flat washer (8), and new self-locking nut (9).
- 5 Install 11 screws (4) and 11 flat washers (5) securing exhaust heat shield (6).
- 6 Install two brackets (3), two screws (1), and two jamnuts (2).



### NOTE

#### FOLLOW-ON MAINTENANCE:

- Install hull exhaust grille (para 16-25)
- Install exhaust outlet pipe (para 6-1)
- Install fan access door (para 16-26)

## CHAPTER 7 COOLING SYSTEM

---

### GENERAL

This chapter illustrates and defines procedures for removal, disassembly, assembly, and installation of engine cooling system components.

---

<u>CONTENTS</u>	<u>Page</u>
Section I. RADIATOR	
7-1 RADIATOR .....	7-2
7-2 RADIATOR MOUNTS AND BRACKETS .....	7-9
7-3 RADIATOR SURGE TANK AND PRESSURE RELIEF VALVE .....	7-11
Section II. SHROUDS	
7-4 RADIATOR FAN SHROUD .....	7-14
Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING	
7-5 ENGINE COOLANT TUBES (MAIN) .....	7-18
7-6 ENGINE COOLANT TUBES (LOWER) .....	7-23
7-7 ENGINE COOLANT HOSES AND TUBES .....	7-26
7-8 INLET THERMOSTAT AND HOUSING ASSEMBLY .....	7-36
7-9 BYPASS THERMOSTAT AND HOUSING ASSEMBLY .....	7-40
7-10 LOW LEVEL COOLANT DETECTOR AND BRACKET .....	7-45
Section IV. FAN ASSEMBLY	
7-11 FAN DRIVE SHAFTS .....	7-52

---

## Section I. RADIATOR

---

### 7-1 RADIATOR.

---

This task covers:    a. Removal                      b. Disassembly                      c. Assembly                      d. Installation

---

#### **INITIAL SETUP**

Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Torque wrench (item 85, Appx F)

Materials/Parts

Adhesive (item 4, Appx C)  
Lockwashers (2) (item 151, Appx E)  
Gasket (item 152, Appx E)

Equipment Conditions

Cooling system drained  
(TM 9-2350-314-10)  
Fan access door removed (para 16-26)

Personnel Required

Two


References

TM 9-2350-314-10

---

**a. Removal.**

- 1 Loosen two clamps (1) and remove surge-tank-to-radiator hose (2) and radiator-to-aeration-detector hose (3) from radiator (4).
- 2 Remove two screws (5), two flat washers (6), two lockwashers (7) securing radiator (4). Discard lockwashers.



05ph046m

## Section I. RADIATOR - CONTINUED


**7-1 RADIATOR - CONTINUED****a. Removal - Continued**

- 3 Loosen clamp (8) and remove radiator outlet hose (9) from radiator (4).
- 4 Loosen two clamps (10) and remove two radiator vent hoses (11) from radiator (4).
- 5 Loosen clamp (12) and remove radiator inlet hose (13) from radiator (4).

**WARNING**

Radiator weighs 88 lbs (40 kg). Two persons are needed during removal to prevent serious injury to personnel.

- 6 Lift radiator (4) up and away from shroud (14) and two radiator mounts (15).
- 7 If damaged, remove two bushings (16) from shroud (14).
- 8 Remove radiator brackets from radiator (4) (para 7-2).



05ph047m

---

## Section I. RADIATOR - CONTINUED

---

### 7-1 RADIATOR - CONTINUED


---

#### b. Disassembly.

- 1 Remove radiator cap (17) and gasket (18) from radiator (4). Discard gasket.
- 2 Remove drain plug (19) from radiator (4).
- 3 Remove clamp (20) and cap (21) from radiator (4).

#### c. Assembly.

- 1 Install cap (21) and clamp (20) to radiator (4).
- 2 Install drain plug (19) in radiator (4).
- 3 Install new gasket (18) on cap (17) and install cap (17) on radiator (4).



05ph048m

---

**Section I. RADIATOR - CONTINUED**

---


**7-1 RADIATOR - CONTINUED**

---

**d. Installation.****WARNING**

Radiator weighs 88 lbs (40 kg). Two persons are needed during installation to prevent serious injury to personnel.

- 1 Install two radiator brackets on radiator (4) (para 7-2).
- 2 Install two bushings (16) in shroud (14), if removed.
- 3 Position radiator (4) on shroud (14) and two radiator mounts (15).



05ph049m

---

## Section I. RADIATOR - CONTINUED

---

### 7-1 RADIATOR - CONTINUED


---

#### d. Installation - Continued

#### NOTE

- Use adhesive at connectors between hoses and mating tubes or castings.
- Hoses must cover unpainted areas of tubes and fittings or be positioned evenly between red bands on tubes and housings.

- 4 Connect radiator inlet hose (13) to radiator (4) and tighten clamp (12).
- 5 Connect two radiator vent hoses (11) to radiator (4) and tighten two clamps (10).
- 6 Connect radiator outlet hose (9) to radiator (4) and tighten clamp (8).




05ph050m

Section I. RADIATOR - CONTINUED

7-1 RADIATOR - CONTINUED

d. Installation - Continued

- 7 Secure radiator (4) to shroud (14) with two new lockwashers (7), two flat washers (6), and two screws (5).
- 8 Connect radiator-to-aeration-detector hose (3) and surge-tank-to-radiator hose (2) to radiator (4) and tighten two clamps (1).
- 9 Fill cooling system (TM 9-2350-314-10).



05ph051m




**Section I. RADIATOR - CONTINUED**

**7-1 RADIATOR - CONTINUED**

**d. Installation - Continued**

- 10 Operate engine (TM 9-2350-314-10) a minimum of 5 minutes at 165° F (74° C) minimum coolant temperature.
- 11 Shut down engine (TM 9-2350-314-10) and check for leaks and level.
- 12 Torque six clamps (1, 8, 10, 12) as follows:

<u>Hose OD (in.)</u>	<u>Hose OD (mm)</u>	<u>lb-in.</u>	<u>N-m</u>
Less than 1.0	Less than 25.4	15 to 25	1.7 to 2.8
1.0 to 2.0	25.4 to 50.8	20 to 40	2.3 to 4.5
Greater than 2.0	Greater than 50.8	40 to 60	4.5 to 6.8



05ph052m

**NOTE**  
**FOLLOW-ON MAINTENANCE:**  
 Install fan access door (para 16-26)




Section I. RADIATOR - CONTINUED

7-2 RADIATOR MOUNTS AND BRACKETS - CONTINUED

b. Installation.

- 1 Install mount (8) with eight screws (13), eight new lockwashers (15), and eight flat washers (14).
- 2 Install mount (7) and new gasket (12) with nine screws (9), nine new lockwashers (11), and nine flat washers (10).
- 3 Install two radiator bracket bushings (6) in mounts (7 and 8).
- 4 Install two brackets (4) on radiator (5) with four screws (1), four new lockwashers (3), and four flat washers (2).



05ph070ma

**NOTE**

**FOLLOW-ON MAINTENANCE:**  
Install radiator (para 7-1)

Section I. RADIATOR - CONTINUED

7-3 RADIATOR SURGE TANK AND PRESSURE RELIEF VALVE.

This task covers:      a. Removal                              b. Installation

**INITIAL SETUP**

Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Torque wrench (item 85, Appx F)

Materials/Parts

Gasket (item 154, Appx E)  
Adhesive (item 4, Appx C)  
Antiseizing tape (item 60, Appx C)

Equipment Conditions


Hull front slope plate and exhaust grille support plate removed (para 16-30)  
Cooling system drained  
(TM 9-2350-314-10)

References

TM 9-2350-314-10

a. Removal.

- 1 Remove two screws (1), two flat washers (2), and retainer (3).
- 2 Loosen clamp (4) at elbow (5) and remove hose (6) from elbow (5).
- 3 Loosen two clamps (7 and 8) at two elbows (9 and 10) and remove two hoses (11 and 12) from two elbows (9 and 10).
- 4 Remove two hoses (13 and 14) from two elbows (15 and 16).
- 5 Lift surge tank (17) up and out of vehicle.
- 6 Remove five elbows (5, 9, 10, 15, and 16) and pipe coupling (18) from surge tank (17).



---

## Section I. RADIATOR - CONTINUED

---

### 7-3 RADIATOR SURGE TANK AND PRESSURE RELIEF VALVE - CONTINUED

---


#### a. Removal - Continued

- 7 Remove hose (14) and elbow (19) from relief valve block (20).
- 8 Remove four screws (21), relief valve (22), and gasket (23) from relief valve block (20). Discard gasket.

#### b. Installation.

#### NOTE

- Use adhesive at connectors between hoses and mating tubes or castings.
  - Hoses must cover unpainted areas of tubes and fittings or be positioned evenly between red bands on tubes and housings.
- 1 Install relief valve (22) with new gasket (23) and four screws (21) on relief valve block (20).
  - 2 Apply antiseizing tape to threads of elbow (19).
  - 3 Install elbow (19) and hose (14) in relief valve block (20).



05ph054m

---

**Section I. RADIATOR - CONTINUED**



---

**7-3 RADIATOR SURGE TANK AND PRESSURE RELIEF VALVE - CONTINUED**


---

**b. Installation - Continued**

- 4 Install pipe coupling (18) and five elbows (5, 9, 10, 15, and 16) into surge tank (17).
- 5 Place surge tank (17) in position.
- 6 Install two hoses (13 and 14) on two elbows (15 and 16).
- 7 Install two hoses (11 and 12) on two elbows (9 and 10) and tighten two clamps (7 and 8).
- 8 Install hose (6) on elbow (5) and tighten clamp (4).
- 9 Install retainer (3), two flat washers (2), and two screws (1).
- 10 Fill cooling system (TM 9-2350-314-10).
- 11 Operate engine (TM 9-2350-314-10) a minimum of 5 minutes at 165°F (74°C) minimum coolant temperature.
- 12 Shut down engine (TM 9-2350-314-10) and check for leaks and level.
- 13 Torque three clamps (4, 7, and 8) to 15-25 lb-in. (1.7-2.8 N-m).


**NOTE**

**FOLLOW-ON MAINTENANCE:**  
 Install hull front slope plate and exhaust grille support plate (para 16-30)

## Section II. SHROUDS

### 7-4 RADIATOR FAN SHROUD.

This task covers:    a. Removal                      b. Disassembly                      c. Assembly                      d. Installation

#### INITIAL SETUP

Tools

General mechanic's tool kit  
(SC 5180-90-N26)

Materials/Parts

Insulation tape (item 61, Appx C)  
Lockwashers (25) (item 9, Appx E)  
Rivets (36) (item 157, Appx E)  
Nonmetallic seals (2) (item 155, Appx E)  
Nonmetallic seals (2) (item 156, Appx E)  
Self-locking nuts (2) (item 29, Appx E)

Equipment Conditions


Powerpack removed (para 4-1)  
Radiator removed (para 7-1)  
Surge tank pressure relief  
valve hose disconnected (para 7-3)  
Fan drive shafts removed (para 7-11)  
Low level coolant detector bracket removed  
(para 7-10)

Personnel Required

Two

**a. Removal.**

- 1 Remove 22 screws (1), 22 flat washers (2), and 22 lockwashers (3) from shroud (4). Discard lockwashers.
- 2 Remove three screws (5), three flat washers (6), three lockwashers (7), and three clamps (8) from shroud (4). Discard lockwashers.
- 3 Remove shroud (4) from two fan assemblies (9).



---

**Section II. SHROUDS - CONTINUED**


---

**7-4 RADIATOR FAN SHROUD - CONTINUED**

---

**b. Disassembly.**

- 1 Remove 22 rivets (10) and two seals (11) from shroud (4). Discard rivets.
- 2 Remove two strips (12) from two seals (11). Discard seals.
- 3 Remove 14 rivets (13) and two seals (14) from shroud (4). Discard rivets.
- 4 Remove four strips (15) and two strips (16) from two seals (14). Discard seals.
- 5 Remove eight screws (17) and cover (18) from shroud (4).
- 6 Remove two screws (19), two locknuts (20), four flat washers (21), and relief valve block (22). Discard locknuts.



05ph084m



---

## Section II. SHROUDS - CONTINUED


---

### 7-4 RADIATOR FAN SHROUD - CONTINUED

---

c. Assembly.

- 1 Install relief valve block (22) with two screws (19), four flat washers (21), and two new locknuts (20).
- 2 Install cover (18) on shroud (4) with eight screws (17).
- 3 Install four strips (15) and two strips (16) in two new seals (14).
- 4 Install two new seals (14) on shroud (4) with 14 new rivets (13).
- 5 Install two strips (12) in two new seals (11).
- 6 Install two new seals (11) on shroud (4) with 22 new rivets (10).
- 7 Wrap each seal joint with tape (eight places).



05ph084m

---

**Section II. SHROUDS - CONTINUED**



---

**7-4 RADIATOR FAN SHROUD - CONTINUED**


---

**d. Installation.**

- 1 Install shroud (4) on two fan assemblies (9).
- 2 Install three screws (5), three new lockwashers (7), three flat washers (6), and three clamps (8) on shroud (4).
- 3 Install 22 screws (1), 22 new lockwashers (3), and 22 flat washers (2) on shroud (4).


**NOTE**
**FOLLOW-ON MAINTENANCE:**

- Install fan drive shafts (para 7-11)
- Install surge tank pressure relief valve hose (para 7-3)
- Install radiator (para 7-1)
- Install powerpack (para 4-1)
- Install low level coolant detector bracket (para 7-10)

---

## Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING

---

### 7-5 ENGINE COOLANT TUBES (MAIN).

---

This task covers: a. Removal b. Installation

---

#### **INITIAL SETUP**

##### Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Torque wrench (item 85, Appx F)

##### Materials/Parts

Adhesive (item 4, Appx C)  
Lockwasher (item 20, Appx E)

##### Equipment Conditions

Powerpack removed (para 4-1)  
Cooling system drained  
(TM 9-2350-314-10)


##### References

TM 9-2350-314-10

---

#### a. Removal.

- 1 Loosen clamp (1) on main coolant tube (2).
- 2 Loosen clamp (3) on surge tank tube-to-engine coolant main tube inlet hose (4) and remove hose (4).



05ph056m

---

### Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED


---

#### 7-5 ENGINE COOLANT TUBES (MAIN) - CONTINUED

---

##### a. Removal - Continued

- 3 Loosen two clamps (5) on lower end of bypass thermostat lower housing-to-engine coolant main tube inlet hose (6).
- 4 Loosen clamp (7) at radiator lower tube assembly (8).
- 5 Remove screw (9), nut (10), lockwasher (11), and clamp (12) from main coolant tube (2). Discard lockwasher.
- 6 Remove main coolant tube (2).
- 7 Remove valve (13) and plug (14) from main coolant tube (2).



05ph057m

---

## Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED

---

### 7-5 ENGINE COOLANT TUBES (MAIN) - CONTINUED

---


#### b. Installation.

- 1 Install plug (14) and valve (13) in main coolant tube (2).

#### NOTE

- Use adhesive at connectors between hoses and mating tubes or castings.
- Hoses must cover unpainted areas of tubes and fittings or be positioned evenly between red bands on tubes and housings.

- 2 Install main coolant tube (2) at hose clamp connections (1, 5, and 7).
- 3 Install clamp (12) on main coolant tube (2) with screw (9), new lockwasher (11), and nut (10).
- 4 Tighten clamp (7) at radiator lower tube assembly (8).
- 5 Tighten two clamps (5) on lower end of bypass thermostat lower housing-to-engine coolant main tube inlet hose (6).



05ph058m

---

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING -  
CONTINUED**


---

**7-5 ENGINE COOLANT TUBES (MAIN) - CONTINUED**

---

**b. Installation - Continued**

- 6 Install surge tank tube-to-engine coolant main tube inlet hose (4) and tighten clamp (3).
- 7 Tighten clamp (1) on main coolant tube (2).



05ph056m

---

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING -  
CONTINUED**


---

**7-5 ENGINE COOLANT TUBES (MAIN) - CONTINUED**

---

**b. Installation - Continued**

- 8 Fill cooling system (TM 9-2350-314-10).
- 9 Operate engine (para 4-1) a minimum of 5 minutes at 165°F (74°C) minimum coolant temperature.
- 10 Shut down engine (para 4-1) and check for leaks and level.
- 11 Torque clamp (1), clamp (7), and two clamps (5) to 40–60 lb-in. (4.5–6.8 N·m).
- 12 Torque clamp (3) to 20–40 lb-in. (2.3–4.5 N·m).



**NOTE**

**FOLLOW-ON MAINTENANCE:**  
Install powerpack (para 4-1)

---

## Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED

---

### 7-6 ENGINE COOLANT TUBES (LOWER).

---

This task covers:      a. Removal                              b. Installation

---

#### INITIAL SETUP

##### Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Torque wrench (item 85, Appx F)

##### Equipment Conditions

Powerpack removed (para 4-1)  
Cooling system drained  
(TM 9-2350-314-10)

##### Materials/Parts

Adhesive (item 4, Appx C)


##### References

TM 9-2350-314-10

---

#### a. Removal.

- 1 Loosen clamp (1) on engine coolant lower tube-to-engine coolant main hose (2).
- 2 Loosen clamp (3) on aeration detector hose (4) and remove hose (4) from tube (5).
- 3 Loosen clamp (6) on radiator outlet-to-engine coolant lower tube hose (7).
- 4 Remove engine coolant lower tube (5).





---

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING -  
CONTINUED**

---

**7-6 ENGINE COOLANT TUBES (LOWER) - CONTINUED**


---

**b. Installation.**

**NOTE**

- Use adhesive at connectors between hoses and mating tubes or castings.
- Hoses must cover unpainted areas of tubes and fittings or be positioned evenly between red bands on tubes and housings.

- 1 Install engine coolant lower tube (5).
- 2 Tighten clamp (6) on radiator outlet-to-engine coolant lower tube hose (7).
- 3 Install aeration detector hose (4) on tube (5) and tighten clamp (3).
- 4 Tighten clamp (1) on engine coolant lower tube-to-engine coolant main hose (2).
- 5 Fill cooling system (TM 9-2350-314-10).



05ph060m

---

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING -  
CONTINUED**


---

**7-6 ENGINE COOLANT TUBES (LOWER) - CONTINUED**

---

**b. Installation - Continued**

- 6 Operate engine (para 4-1) a minimum of 5 minutes at 165°F (74°C) minimum coolant temperature.
- 7 Shut down engine (para 4-1) and check for leaks.
- 8 Torque two clamps (1 and 6) to 40-60 lb-in. (4.5-6.8 N·m).
- 9 Torque clamp (3) to 15-25 lb-in. (1.7-2.8 N·m).



05ph061m

**NOTE**


**FOLLOW-ON MAINTENANCE:**  
Install powerpack (para 4-1)



Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED

7-7 ENGINE COOLANT HOSES AND TUBES - CONTINUED

a. Removal - Continued



05ph077m

---

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING -  
CONTINUED**


---

**7-7 ENGINE COOLANT HOSES AND TUBES - CONTINUED**

---

**a. Removal - Continued**

- 7 Remove four clamps (14), tube (10), and two hoses (15).




05ph078m

## Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED

### 7-7 ENGINE COOLANT HOSES AND TUBES - CONTINUED

#### a. Removal - Continued

- 8 Remove screw (16), flat washer (17), lockwasher (18), and clamp (19). Discard lockwasher.
- 9 Remove two clamps (20) and hose (21).
- 10 Remove hose (22) from two elbows (23 and 24).
- 11 Remove two screws (25), two flat washers (26), two lockwashers (27), two clamps (28), and three hoses (21, 22, and 11) from radiator fan shroud (29). Discard lockwashers.
- 12 Remove two clamps (30) and hose (31).
- 13 Remove two clamps (32) and hose (33).
- 14 Remove elbow (24) from valve (34).
- 15 Remove two clamps (35) and hose (36).



---

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING -  
CONTINUED**

---

**7-7 ENGINE COOLANT HOSES AND TUBES - CONTINUED**


---

**b. Installation.**

**NOTE**

- Use adhesive at connection between hoses and mating tubes.
- Hoses must cover unpainted areas of tubes and fittings or be positioned evenly between red bands on tubes and housings.
- Use tape on all male pipe threads.

- 1 Cut length of new hose (36) to  $32.00 \pm 0.25$  in. ( $812.8 \pm 6.3$  mm).
- 2 Install new hose (36) with two clamps (35).




05ph080m

### Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED

#### 7-7 ENGINE COOLANT HOSES AND TUBES - CONTINUED

##### b. Installation - Continued

- 3 Cut length of new hose (33) to  $16.25 \pm 0.25$  in. ( $412.7 \pm 6.3$  mm).
- 4 Install new hose (33) with two clamps (32).
- 5 Cut length of new hose (31) to  $6.25 \pm 0.25$  in. ( $158.7 \pm 6.3$  mm).
- 6 Install new hose (31) with two clamps (30).
- 7 Install elbow (24) on valve (34).
- 8 Install hose (22) on two elbows (23 and 24).
- 9 Secure hose (22) with clamp (28), screw (25), new lockwasher (27), and flat washer (26).
- 10 Cut length of new hose (21) to  $86.00 \pm 0.25$  in. ( $2184.4 \pm 6.3$  mm).
- 11 Install new hose (21) with two clamps (20).
- 12 Secure hose (21) with clamp (19), screw (16), new lockwasher (18), and flat washer (17).



05ph081m



---

### Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED

---

#### 7-7 ENGINE COOLANT HOSES AND TUBES - CONTINUED


---

##### b. Installation - Continued

13 Cut two lengths of new hose (15) to 4.75 in. (120.6 mm).

14 Install two new hoses (15) with two clamps (14).

15 Install tube (10) with two clamps (14).



05ph078m

---

## Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED


---

### 7-7 ENGINE COOLANT HOSES AND TUBES - CONTINUED

---

#### b. Installation - Continued

- 16 Install two elbows (9 and 12) in tube (10).
- 17 Connect hose (11) to elbows (12 and 13).
- 18 Secure three hoses (11, 21, and 22) to radiator shroud (29) with clamp (28), screw (25), new lockwasher (27), and flat washer (26).



05ph082m

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED**

**7-7 ENGINE COOLANT HOSES AND TUBES - CONTINUED**

**b. Installation - Continued**


- 19 Cut length of new hose (8) to  $30.00 \pm 0.25$  in. ( $762 \pm 6.3$  mm).
- 20 Install new hose (8) with two clamps (3).
- 21 Secure hose (8) to radiator fan shroud (29) with clamp (7), screw (4), new lockwasher (6), and flat washer (5).
- 22 Cut length of new hose (2) to  $7.50 \pm 0.12$  in. ( $190.5 \pm 3$  mm).
- 23 Install new hose (2) with two clamps (1).
- 24 Fill cooling system (TM 9-2350-314-10).
- 25 Operate engine (TM 9-2350-314-10) a minimum of 5 minutes at 165°F (74°C) minimum coolant temperature.
- 26 Shut down engine (TM 9-2350-314-10) and check for leaks and level.
- 27 Torque hose clamps (1, 3, 14, 20, 30, 32, and 35) as follows:

<u>Hose OD (in.)</u>	<u>Hose OD (mm)</u>	<u>lb-in.</u>	<u>N-m</u>
Less than 1.0	Less than 25.4	15 to 25	1.7 to 2.8
1.0 to 2.0	25.4 to 50.8	20 to 40	2.3 to 4.5
Greater than 2.0	Greater than 50.8	40 to 60	4.5 to 6.8

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING -  
CONTINUED**

**7-7 ENGINE COOLANT HOSES AND TUBES - CONTINUED**

**b. Installation - Continued**



05ph062m

**NOTE**


**FOLLOW-ON MAINTENANCE:**  
Install fan access door (para 16-26)



Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED

7-8 INLET THERMOSTAT AND HOUSING ASSEMBLY - CONTINUED

a. Removal - Continued



05ph063m

---

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED**


---

**7-8 INLET THERMOSTAT AND HOUSING ASSEMBLY - CONTINUED**

---

**b. Installation.**


- 1 Install two new seals (10) in thermostat housing (6), with leather facing outward, using installer and handle.



**NOTE**

- Use adhesive at connections between hoses and mating tubes or castings.
- Hoses must cover unpainted areas of tubes and fittings or be positioned evenly between red bands on tubes and housings.

- 2 Install thermostat housing (8) on connector hose (17) and tighten clamp (15).



---

## Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED


---

### 7-8 INLET THERMOSTAT AND HOUSING ASSEMBLY - CONTINUED

---

#### b. Installation - Continued

- 3 Install thermostat housing (8) and new gasket (16) in engine coolant manifold (14) with screw (11), two new lockwashers (12), and nut (13).
- 4 Install rear protective cover (para 8-50).
- 5 Install two thermostats (9).
- 6 Install thermostat housing (6) and new gasket (7) at thermostat housing (8) with six screws (3), six new lockwashers (5), and six flat washers (4).
- 7 Install housing-to-radiator hose (2) and tighten two clamps (1).
- 8 Fill cooling system (TM 9-2350-314-10).
- 9 Operate engine (TM 9-2350-314-10) a minimum of 5 minutes at 165°F (74°C) minimum coolant temperature.
- 10 Shut down engine (TM 9-2350-314-10) and check for leaks and level.
- 11 Torque clamp (15) and two clamps (1) to 40-60 lb-in. (4.5-6.8 N·m).



#### NOTE

**FOLLOW-ON MAINTENANCE:**  
Install fan access door (para 16-26)






**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED**

**7-9 BYPASS THERMOSTAT AND HOUSING ASSEMBLY - CONTINUED**

**a. Removal - Continued**

- 6 Separate upper thermostat housing (15) from lower thermostat housing (16).
- 7 Loosen two clamps (17) and remove lower thermostat housing (16) from connector hose (18).
- 8 Remove thermostat (19), gasket (20), and seal (21). Discard gasket and seal.



05ph066m

---

### Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED


---

#### 7-9 BYPASS THERMOSTAT AND HOUSING ASSEMBLY - CONTINUED

---

**b. Installation.**

- 1 Install new seal (21) in lower thermostat housing (16), using installer and handle.
- 2 Install lower thermostat housing (16) in connector hose (18) and tighten two clamps (17).
- 3 Install new gasket (20) and thermostat (19).
- 4 Connect upper thermostat housing (15) to lower thermostat housing (16) with three screws (12), three new lockwashers (14), and three flat washers (13).



05ph067m

---

## Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED

---

### 7-9 BYPASS THERMOSTAT AND HOUSING ASSEMBLY - CONTINUED


---

#### b. Installation - Continued

#### NOTE

- Use adhesive at connectors between hoses and mating tubes or castings.
- Hoses must cover unpainted areas of tubes and fittings or be positioned evenly between red bands on tubes and housings.

- 5 Install coolant hose (11) and tighten lower clamp (10).
- 6 Install housing (9) on coolant hose (11) and tighten upper clamp (8).
- 7 Install housing (9) and new gasket (6) on engine coolant manifold (7) with screw (3), two new lockwashers (4), and nut (5).
- 8 Install front protective cover (para 8-50).
- 9 Install connector hose (2) on housing (9) and tighten clamp (1).
- 10 Fill cooling system (TM 9-2350-314-10).



05ph068m

---

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING -  
CONTINUED**


---

**7-9 BYPASS THERMOSTAT AND HOUSING ASSEMBLY - CONTINUED**

---

**b. Installation - Continued**

- 11 Operate engine (TM 9-2350-314-10) a minimum of 5 minutes at 165°F (74°C) minimum coolant temperature.
- 12 Shut down engine (TM 9-2350-314-10) and check for leaks and level.
- 13 Torque clamps (1, 8, 10, and 17) to 40-60 lb-in. (4.5-6.8 N-m).



05ph069m

**NOTE**

**FOLLOW-ON MAINTENANCE:**  
Install powerpack (para 4-1)

---

### Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED

---

#### 7-10 LOW LEVEL COOLANT DETECTOR AND BRACKET.

---

This task covers:    a. Removal                    b. Disassembly                    c. Assembly                    d. Installation

---

#### **INITIAL SETUP**

##### Tools

General mechanic's tool kit  
(SC 5180-90-N26)  
Torque wrench (item 85, Appx F)  
Wire brush (item 7, Appx F)

##### Materials/Parts

Lockwashers (4) (item 44, Appx E)  
Lockwashers (2) (item 9, Appx E)  
Adhesive (item 4, Appx C)  
Sealing compound (item 50, Appx C)  
Dry-cleaning solvent (item 59, Appx C)

##### Equipment Conditions

Vehicle MASTER switch OFF  
(TM 9-2350-314-10)  
Battery ground leads disconnected  
(para 8-33)  
Transmission access doors opened  
(TM 9-2350-314-10)

##### References

TM 9-2350-314-10

---

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED**


**7-10 LOW LEVEL COOLANT DETECTOR AND BRACKET - CONTINUED**

**a. Removal.**

**NOTE**

Tag all electrical connections and electrical leads prior to removal to aid in installation.

- 1 Disconnect wiring harness W104 leads 352A (1) and 352B (2) from low level coolant detector wiring harness (3).
- 2 Remove screw (4) and flat washer (5) and disconnect ground lead (6) from VMS bracket.
- 3 Loosen two clamps (7 and 8) and disconnect two hoses (9 and 10). Remove clamps (7 and 8).
- 4 Remove four screws (11), four nuts (12), four lockwashers (13), four flat washers (14), and low level coolant detector (15) from bracket (16). Discard lockwashers.
- 5 Remove two screws (17), two nuts (18), two lockwashers (19), four flat washers (20), and bracket (16). Discard lockwashers.



05ph071m

---

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING -  
CONTINUED**

---

**7-10 LOW LEVEL COOLANT DETECTOR AND BRACKET - CONTINUED**

---


**b. Disassembly.**

- 1 Remove two screws (21) and cover (22) from low level coolant detector (15).

**NOTE**

Tag all electrical connections and electrical leads  
prior to removal to aid in installation.

- 2 Remove three leads (23, 24, and 25) from terminal block (26).
- 3 Remove adapter (27) from low level coolant detector (15) and adapter (28) from elbow (29).
- 4 Remove elbow (29) from low level coolant detector (15).



05ph072m



**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED**


**7-10 LOW LEVEL COOLANT DETECTOR AND BRACKET - CONTINUED**

c. Assembly.

**WARNING**

Dry-cleaning solvent (P-D-680) is toxic and flammable. To avoid injury, wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes. Do not breathe vapors. Do not use near open flame or excessive heat. Do not smoke when using solvent. Failure to do so could cause **SERIOUS INJURY**. If you become dizzy while using dry-cleaning solvent, get fresh air immediately, and if necessary, get medical attention. If contact with skin or clothes is made, flush thoroughly with water. If the solvent contacts your eyes, wash them with water immediately and obtain medical aid (FM 21-11).

- 1 Clean threads of two adapters (27 and 28), elbow (29), and low level coolant detector (15) with dry-cleaning solvent and wire brush.
- 2 Apply sealing compound to threads of two adapters (27 and 28) and elbow (29).
- 3 Install elbow (29) in low level coolant detector (15).
- 4 Install adapter (27) in low level coolant detector (15) and adapter (28) in elbow (29).
- 5 Install three leads (23, 24, and 25) on terminal block (26)
- 6 Install cover (22) on low level coolant detector (15) with two screws (21).



---

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING -  
CONTINUED**


---

**7-10 LOW LEVEL COOLANT DETECTOR AND BRACKET - CONTINUED**

---

**d. Installation.**

- 1 Install bracket (16) with two screws (17), four flat washers (20), two new lockwashers (19), and two nuts (18).
- 2 Install low level coolant detector (15) on bracket (16) with four screws (11), four flat washers (14), four new lockwashers (13), and four nuts (12).



05ph074m

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING -  
CONTINUED**

---

**7-10 LOW LEVEL COOLANT DETECTOR AND BRACKET - CONTINUED**

---

**d. Installation - Continued**

**NOTE**


- Use adhesive at connectors between hoses and mating tubes or castings.
- Hoses must cover unpainted areas of tubes and fittings or be positioned evenly between red bands on tubes and housings.

- 3 Connect two hoses (9 and 10) with two clamps (7 and 8).
- 4 Connect ground lead (6) to VMS bracket with screw (4) and flat washer (5).
- 5 Connect wiring harness leads W104 352B (2) and 352A (1) to low level coolant detector wiring harness (3).
- 6 Connect battery ground leads (para 8-33).
- 7 Check radiator coolant level (TM 9-2350-314-10).
- 8 Operate engine (TM 9-2350-314-10) a minimum of 5 minutes at 165°F (74°C) minimum coolant temperature.
- 9 Shut down engine (TM 9-2350-314-10) and check for leaks.
- 10 Torque two clamps (7 and 8) to 15 to 25 lb-in. (1.7 to 2.8 N·m).

**Section III. WATER MANIFOLD, HEADERS, THERMOSTATS, AND HOUSING - CONTINUED**

**7-10 LOW LEVEL COOLANT DETECTOR AND BRACKET - CONTINUED**

**d. Installation - Continued**



05ph075m

**NOTE**

**FOLLOW-ON MAINTENANCE:**  
 Close and secure transmission access doors  
 (TM 9-2350-314-10)



## ALPHABETICAL INDEX

### A

Accelerator, Throttle, and Engine Control Governor, 5-82

Accelerator, Throttle, or Choke Controls, 5-76

Accessory Control Box and Brackets, 8-62

Accessory Items, 18-2

Actuator Cable Assembly, 21-9

Administrative Storage, 23-2

  Auxiliary Equipment and Basic Issue Items, 23-3

  Corrections of Shortcomings and Deficiencies, 23-3

  General Cleaning, Painting, and Preservation, 23-3

  Lubrication, 23-3

  Maintenance Services and Inspections, 23-3

  Security, 23-2

  Storage Plan, 23-3

  Storage Site, 23-2

Air Box Pressure Transducer, 8-129

Air Cleaner, 5-21

Air Cleaner and Generator System Relay Switch, 8-136

Air Cleaner Assembly, 5-21

Air Cleaner Blower Relay and Mounting Bracket, 8-80

Air Cleaner Box Assembly, 5-28

Air Cleaner Bracket and Blower, 5-32

Air Cleaner Duct and Hoses, 5-30

Air Cleaner Pressure Transducer, 8-124

Air Intake and Exhaust Grille Covers and Strips, 19-22

Air Intake Grille, 16-98

Ammunition Racks, 16-192

Assembly of Equipment, 2-3

### B

Batteries, 2-4, 8-146, 8-148

Battery Access Door Seals, 16-78

Battery Access Doors, 16-76

Battery Compartment Access Port Cover and Gasket, 8-332

Battery Heater and Insulation Blankets, 19-9

Battery Supports, 8-150

Battery Terminal Lugs, 8-146

Bilge Pump, 18-8

Bilge Pump, Strainer, Hoses, Tubes, and Clamps, 18-8

Body, Cab, Hood, and Hull Assemblies, 16-4

Body, Chassis, or Hull Accessory Items, 18-1

Bolts, 2-9

Brake Controls, 11-2

Brake Pedal and Parking Brake Assembly, 11-10

Brakes, 11-1

Breather Tubes, 4-44

Breather, Tube, and Mount, 9-28

Bus Bar (Positive or Negative) and Power Receptacle Assembly (Rear), 8-311

Bypass Thermostat and Housing Assembly, 7-40

### C

Care Of Equipment In Administrative Storage Inspection, 23-4

  Maintenance Services, 23-4

Care Of Equipment in Administrative Storage, 23-4

Checking Unpacked Equipment, 2-2

Checking Vehicle Systems, 2-4

Circuit Breakers and Circuit Breaker Panels, 8-65

Classification of Fluid Leaks, 2-9

Combat Override Switch and Bracket, 8-82

Common Tools and Equipment, 2-2

Control Valves And Tube Assembly, 21-20

Coolant Hoses, 19-34

Coolant Pump and Bracket, 19-13

Coolant System Bleeding, 19-27

Coolant Temperature Switch, 8-144

Coolant Temperature Transmitter, 8-142

Corrosion Prevention and Control, 1-3, 2-9, G-1

## ALPHABETICAL INDEX - CONTINUED

Cradle Assembly, 8-25  
Cradle Mounting Bracket, 8-28  
Current Shunt and Ground Bus, 8-92  
Cylinder Assembly, 21-2  
Cylinder Cap Retaining Assemblies, 21-7  
Cylinder Retaining Straps, 21-5

### D

Data Plates and Instruction Holders, 18-34  
Decals, 18-34  
Definition of Administrative Storage, 23-2  
Deprocessing Unpacked Equipment, 2-3  
Destruction of Army Materiel to Prevent Enemy Use, 1-2  
Differences Between Models, 1-3  
Dome Light, 8-113  
Dome Light Mounting Bracket, 8-120  
Drain Fuel Tanks, 5-36  
Drain Plugs, 16-128  
Driver's Bulkhead Harness Cover, 8-91  
Driver's Full Function Crew Station Mounting Plate, 8-88  
Driver's Hatch and Periscopes, 16-111  
Driver's Hatch Armor Plate and Handgrips, 16-111  
Driver's Hatch Cover and Lock Components, 16-113  
Driver's Instrument Panel, 8-37  
Driver's Instrument Panel Support Assembly, 8-44  
Driver's Intercom Bracket, 8-89  
Driver's Portable Instrument Panel, 8-49  
Driver's Portable Instrument Panel Bracket (Outside Driver's Hatch and Crew Compartment), 8-55  
Driver's Seat, 16-139

### E

Electric Fuel Pump, 5-57  
Electrical Systems, 8-1

Electrical Troubleshooting, 3-2  
Electrical Wires and Connectors, 2-9  
Enclosure Assembly and Bracket - Crew Compartment Warning Light, 8-68  
Engine Assembly, 4-36  
Engine Compartment Access Cover, 16-18  
Engine Compartment Tubes, Nozzle and Mounting Hardware, 21-26  
Engine Coolant Heater Assembly and Brackets, 19-2  
Engine Coolant Hoses and Tubes, 7-26  
Engine Coolant Tubes (Lower), 7-23  
Engine Coolant Tubes (Main), 7-18  
Engine Dipstick Access Cover, 16-96  
Engine Fuel Lines, and Fittings, 5-52  
Engine Lubrication System, 4-46  
Engine Mounting Bracket, Lower Engine Bar, and Universal Joint, 4-38  
Engine Oil Filter, 4-49  
Engine Oil Filter Lines, Mounting Bracket, Fittings, Engine Oil Sampling Valve, and Engine Oil Sensor Fittings, 4-46  
Engine Oil Pressure Switch, 8-134  
Engine Oil Pressure Transmitter, 8-138  
Engine Starter, 8-33  
Engine Testing (STE/ICE), 3-354  
Engine Throttle Governor Control Rod, 5-77  
Engine Wiring Harness Mounting Bracket, 8-334  
Equipment Characteristics, Capabilities and Features, 1-3  
Equipment Data, 1-4  
Equipment Description and Data, 1-3  
Equipment Faults, 2-4  
Reporting Design and Material Faults, 2-4  
Equipment Installation Instructions, 2-3  
Equipment Operation and Description, 1-6  
Exhaust Deflectors, 16-90  
Exhaust Duct, Insulation Blanket, and Hanger, 6-4  
Exhaust Heat Shield and Insulation Pad, 6-6  
Exhaust Outlet Assembly, 19-8

## ALPHABETICAL INDEX - CONTINUED

Exhaust Outlet Pipe and Insulation, 6-2  
 Exhaust Tube and Support, 19-29  
 Expendable and Durable Items List, C-1  
 Explanation of Table Entries, 2-10  
 Extractor Assembly Stowage Clamps, 16-180

### F

Fan Access Door, 16-92  
 Fan Assembly, 7-52  
 Fan Drive Shafts, 7-52  
 Fenders, 16-109  
 Field Manuals, A-1  
 Final Drive Assembly, 10-4  
 Final Drive Breather Tubes and Breather, 10-2  
 Final Drive Hub, Quick-Disconnect, and Coupling Assembly, 10-9  
 Final Drive Skid Plates, 16-136  
 Final Drive Sprocket and Hub, 12-40  
 Fire Fighting Equipment, 21-1  
 Flashlight Holder, 16-179  
 Flexible Hoses And Fittings, 21-24  
 Floor, Subfloor, and Related Components, 16-130  
 Flywheel Housing Cover and Gasket, 4-42  
 Forms, A-1  
 Fuel Fill Access Door, 16-108  
 Fuel Filter, 19-16  
 Fuel Filters (Primary and Secondary), 5-60  
 Fuel Lines and Hoses, 19-31  
 Fuel Pressure Differential Transducer, 8-125  
 Fuel Pump and Fuel Filter Mounting Bracket, 19-30  
 Fuel Pump Assembly, 19-5  
 Fuel Pumps, 5-2  
 Fuel Shutoff Control, 5-96  
 Fuel Shutoff Identification Plate, 5-95  
 Fuel Supply Pressure Transducer, 8-127  
 Fuel Tank Filler Assembly (Cap, Seal, and Filler), 5-41

Fuel Tank Level Transmitters (Upper and Lower), 5-44  
 Full Function Crew Station, Driver's - Internal, 18-4

### G

Gages, 20-1  
 Gear Shift and Controls, 9-2  
 Gear Shift Control Linkage, 9-2  
 General, 2-2, 2-5, 23-2  
   Intervals (PMCS), 2-5  
   Lubrication Instructions, 2-5  
   Procedures, 2-8  
   Services, 2-8  
 General Information, 1-2  
 General Troubleshooting Instructions, 3-2  
 Generator, 8-5, 8-11  
 Generator Alignment, 8-20  
 Generator Drive Belt, 8-5  
 Generator Drive Belt Tensioner and Bracket, 8-7  
 Generator Drive Shaft and Shaft Screw, 8-23  
 Generator Oil Cooling Manifold, Hoses, Valves, and Fittings, 8-29  
 Generator Pulley Assembly, 8-9  
 Generator/Fuel Pump Relay and Mounting Bracket, 8-78  
 Grenade Box Assembly, 16-167  
 Grenade Box Assembly, 40MM, 16-169  
 Grille Adjustable Support Assembly, 16-105  
 Gun Barrel Bracket Assembly, 16-155  
 Gun Butt Bracket Assembly, 16-158  
 Gun Tube Travel Lock, 16-22  
 Gun Tube Travel Lock Actuator Adjustment, 16-48  
 Gun Tube Travel Lock Actuator and Pin Assembly, 16-43  
 Gun Tube Travel Lock Bumper Stop, 16-60  
 Gun Tube Travel Lock Control Box and Voltage Regulator Control Box Bracket, 8-61  
 Gun Tube Travel Lock Control Box Assembly, 8-57  
 Gun Tube Travel Lock Pin Assembly, 16-46  
 Gun Tube Travel Lock Quick-Release Pins and Wire Rope, 16-62



## ALPHABETICAL INDEX - CONTINUED

Gun Tube Travel Lock Support, 16-88  
Gun Tube Travel Lock Support Bracket Bearings,  
16-64  
Gun Tube Travel Lock Wiring Harness Connectors  
and Shield, 8-329

### H

Hand Brake, 11-2  
Hand Throttle Governor Control Rod, 5-76  
Headlight Assembly, 8-98  
Headlight Dimmer Switch, 8-84  
Headlight Mount, 8-108  
Headlight Sealed-Beam and Incandescent Lamps,  
8-96  
Heater Control Box and Bracket, 19-7  
Hinged and Triple Cradles, 16-198  
Horizontal Latch Assembly, 16-186  
Hoses and Fluid Lines, 2-9  
How to Use this Manual, iv  
Hull Exhaust Grille, 16-91  
Hull Expansion Plugs, 16-138  
Hull Front Slope and Exhaust Grille Support Plate,  
16-102  
Hull Rear Door Latch, 16-66  
Hull Rear Door Seal, 16-67  
Hull Rear Door, Hold-Open Rod, and Handle,  
16-69  
Hull Subfloor Access Covers, 16-134  
Hull Wiring Harness, 8-162  
Hydraulic Bumper and Bumper Brackets, 15-8

### I

Idler Arm Assembly, 12-35  
Idler Arm Housing, 12-34  
Idler Wheels and Idler Arm Hub and Cap Assembly,  
12-28  
Initial Procedures, 2-2  
Assembly of Equipment, 2-3

INDEX-4

Checking Unpacked Equipment, 2-2  
Deprocessing Unpacked Equipment, 2-3  
Equipment Installation Instructions, 2-3  
Initial Starting and Break-In, 2-4  
Inlet Thermostat and Housing Assembly, 7-36  
Inserts, 2-9  
Installation of Batteries, 2-4  
Instrument or Engine Control Panels, 8-37  
Intercom Box and Full Function Crew Station -  
External, 18-6  
Intercom Cable - External, 18-5  
Intercom Cable - Internal, 18-2  
Intervals, PMCS, 2-5

### L

Lead Assembly Circuit Breaker to Driver's MCS  
Heater, 8-314  
Lead Assembly, Accessory Control Box to Lead Filter  
Fan, 8-322  
Lead Assembly, Generator to Engine Block Ground,  
8-320  
Lead Assembly, Lead Filter Fan to Ground, 8-324  
Lead Assembly, Left Slip Ring Segment Rear  
Negative Terminal to Rear Power Receptacle,  
Negative Bus Bar, 8-302  
Lead Assembly, Left Slip Ring Segment Rear Positive  
Terminal to Rear Power Receptacle, Positive Bus  
Bar, 8-306  
Lead Assembly, Right Slip Ring Segment Rear  
Negative Terminal to Rear Power Receptacle,  
Negative Bus Bar, 8-304  
Lead Assembly, Right Slip Ring Segment Rear  
Positive Terminal to Rear Power Receptacle,  
Positive Bus Bar, 8-300  
Lead Assembly, Slip Ring Segment Front Negative  
Terminal to Slip Ring Segment Rear Negative  
Terminal, 8-298  
Lead Assembly, Slip Ring Segment Front Positive  
Terminal to Slip Ring Segment Rear Positive  
Terminal, 8-296  
Lead Filter, 16-8  
Lead Filter Drain Hoses and Clamps, 16-12  
Lead Filter Fan, 8-336

## ALPHABETICAL INDEX - CONTINUED

Lead Filter Grille Assembly, 16-14  
 Lead Filter Housing Hold-Down Latch, 16-16  
 Lead Filter Vent Tube, Fitting, and Elbow, 16-10  
 Lead, Battery Positive Terminal to Master Relay Terminal A1, 8-151  
 Lead, Battery Positive Terminal to Master Relay Terminal A1 and Wiring Harness W105, 8-159  
 Leads, Negative Terminal to Ground Bus and Battery Positive Terminal to Battery Negative Terminal, 8-154  
 Lights, 8-96  
 Lines and Fittings (Upper and Lower Fuel Tanks), 5-49  
 Location and Description of Major Components, 1-3  
 Lock Assembly (Ammunition Racks), 16-189  
 Low Level Coolant Detector and Bracket, 7-45  
 Lubrication Instructions, 2-5

### M

Maintenance Allocation Chart, B-1  
 Maintenance Allocation Chart for M109A6, B-4  
 Maintenance Forms, Records, and Reports, 1-2  
 Mandatory Replacement Parts List, E-1  
 Master Relay and Bracket, 8-70  
 MCS Connector Assembly (Supply Hose To Face Mask And Vest) and Bracket, 22-6  
 MCS Heater (M3), 22-8  
 MCS Heater (M3) Pilot Light Lens, Lamp, and Knob, 22-4  
 MCS Heater (M3) Supply Hose, 19-38  
 MCS Heater Bracket, 22-10  
 MCS Hose Assemblies and Hardware, 22-2  
 Mechanical Brake System, 11-10  
 Mechanical Fuel Pump, 5-10  
 Mechanical Fuel Pump Relief Valve, 5-13  
 Mechanical Fuel Pump Test, 5-16  
 Military Specifications, A-3  
 Miscellaneous Publications, A-3

### N

Net Assembly and Fasteners, 16-175  
 Night Viewer and M45 Periscope Cover and Gasket, 16-124  
 Night Viewer and M45 Periscope Cover Doors, Pins, Springs, and Seals, 16-122  
 Night Viewer and M45 Periscope Supports, Springs, Spacers, and Rods, 16-126  
 Night Viewer Stowage Bracket, 16-152  
 Night Viewer Stowage Bracket Support Plate, 16-154  
 Nomenclature Cross-Reference List, 1-3

### O

Oil Can Bracket and Mounting Plate, 16-181  
 Oil Sampling Valve, Transmission Oil Lines and, 9-36  
 Operational Procedures, 2-4  
   Initial Starting and Break-In, 2-4  
   Operational Test, 2-4  
   Road Test, 2-4

### P

Parking Brake Linkage, 11-4  
 Parking Brake Warning Switch, 11-8  
 Periscope Bracket and Shroud Assembly, 16-161  
 Personnel Heater, 18-24  
 Personnel Heater Exhaust Tube, 18-30  
 Personnel Heater Fuel Filter and Tubes, 18-16  
 Personnel Heater Fuel Hoses, Tubes, and Fittings, 18-20  
 Personnel Heater Fuel Pump, 18-18  
 Personnel Heater Mounting Hardware, Clamps, and Ducts, 18-12  
 Personnel Heater Support Assembly and Associated Hardware, 18-27  
 Portable Fire Extinguisher and Bracket, 16-182  
 Power Receptacle Guard, 8-310  
 Powerpack, 4-2

## ALPHABETICAL INDEX - CONTINUED

Powerpack Ground Lead, 8-316  
Preoperational Procedures, 2-4  
    Checking Vehicle Systems, 2-4  
    Installation of Batteries, 2-4  
Preparation for Storage or Shipment, 1-2  
Preventive Maintenance Checks and Services, 2-5  
Primary Fuel Filter and Bracket, 5-64  
Principles of Operation, 1-6  
Procedures for Semiannual and Annual Services, 2-8  
    Bolts, 2-9  
    Classification of Fluid Leaks, 2-9  
    Corrosion Prevention and Control, 2-9  
    Electrical Wires and Connectors, 2-9  
    Explanation of Table Entries, 2-10  
    Hoses and Fluid Lines, 2-9  
    Inserts, 2-9  
    Seals, 2-9  
    Warnings and Cautions, 2-10  
    Welds, 2-9  
Procedures, General, 2-8  
Projectile Stowage Straps, Spacers, and Strap Bracket, 16-196  
Protective Cover (Front and Rear), 8-140  
Protective Cover for Transmission Oil Temperature Transmitter and Transmission Oil High Temperature Switch, 9-33  
Pulse Tachometer, 20-10

### Q

Quality Assurance (QA), 1-2  
Quick Guide to Troubleshooting, 3-3

### R

Radiator, 7-2  
Radiator Cap Access Cover, 16-94  
Radiator Fan Shroud, 7-14  
Radiator Mounts and Brackets, 7-9  
Radiator Surge Tank and Pressure Relief Valve, 7-11  
Receipt For Storage, 23-5

INDEX-6

References, A-1  
Regulations, A-3  
Remarks, B-18  
Removal From Administrative Storage, 23-5  
Repair Parts, 2-2  
Repair Parts, Special Tools, TMDE and Support Equipment, 2-2  
Reporting Design and Material Faults, 2-4  
Reporting Equipment Improvement Recommendations, 1-3  
Resistor Module Block and Bracket, 8-86  
Rifle Clip, 16-178  
Right and Left Fuel Pump and Hanger Assemblies, 5-2  
Road Arm Assembly and Housing Assembly, 12-4  
Road Arm Assembly Stop Pins, 12-12  
Road Test, 2-4  
Roadwheel Hub and Cap Assembly, 12-14  
Roadwheels, 12-20- 12-33  
Rotation, 23-5

### S

Scope, 1-2  
Seals, 2-9  
Secondary Fuel Filter and Bracket, 5-66  
Sending Units and Warning Switches, 8-124  
Service and Blackout Taillights, Stoplights, and Lamps, 8-110  
Service Brake Linkage, 11-18  
Service Upon Receipt, 2-2  
Services, General, 2-8  
Servicing, 23-5  
Shock Absorber, Bearing, and Bracket, 15-2  
Shock Absorbers, 15-1  
Shock Mount and Engine Brackets, 4-36  
Simplified Test Equipment for Internal Combustion Engines (STE/ICE), 3-353  
    Description of STE/ICE Equipment, 3-353  
    Engine Testing, 3-354

## ALPHABETICAL INDEX - CONTINUED

Single Cradles, Cantilever Cradles, Cradle, and Latch Brackets, 16-201  
 Slave Receptacle Assembly and Mounting Bracket (Front), 8-308  
 Slave Starting, 2-50  
 Spacer, 16-176  
 Spade, 17-9  
 Spade Assemblies, 17-1  
 Spade Latch and Pin Assembly, 17-2  
 Spade Strut and Cable, 17-6  
 Spade Strut Latch and Pedal, 17-4  
 Spare Track Shoe Clamps, 16-177  
 Special Purpose Kits, 19-1  
 Special Tools, TMDE, and Support Equipment, 2-2  
 Speedometer And Tachometer Systems Mounting Bracket, 20-11  
 Speedometer System, 20-2  
 Starter Ground Strap, 8-318  
 Starter Protection Relay, Bilge Pump Relay, Bilge Pump Circuit Breaker, and Mount, 8-72  
 Starting Instructions, 2-50  
 Starting Motor, 8-33  
 STE Bracket, 8-90  
 STE/ICE Equipment Description, 3-353  
 STE/ICE Troubleshooting, 3-2  
 Steering, 13-1  
 Steering Control Linkage, 13-2  
 Steering Control Linkage Adjustment, 13-11  
 Stencil Locations, 18-36  
 Stoplight Switch, 11-20  
 Stowage Box Assembly (Driver's Compartment), 16-166  
 Stowage Box Latch (Driver's Compartment), 16-164  
 Stowage Box Seals (Driver's Compartment), 16-162  
 Strap with Removable Hook, 16-173  
 Straps, 16-172  
 Straps with Permanent Attached Hook, 16-174

Subfloor Drain Plugs, 16-128  
 Supercharger, Blower, or Turbocharger, 5-34  
 Suspension Bracket, 15-7

## T


Tachometer System, 20-6  
 Tanks, Lines, Fittings, and Headers, 5-36  
 Technical Bulletins, A-1  
 Technical Manuals, A-1  
 Telephone Cable Reel, Handcrank, and Bracket, 16-151  
 Tool Identification List, F-1  
 Tools and Test Equipment for M109A6, B-16  
 Torque Limits, D-1  
 Torsion Bar, 12-24  
 Torsion Bar Anchor Cover Plates, 16-130  
 Torsion Bar Anchors, Positions 1, 2, 4, 5, 6, and 7, 12-26  
 Torsion Bar, Anchor, Road Arm, and Roadwheel Hub and Cap Assembly Identification Chart, 12-2  
 Tow Hook, 14-4  
 Towing Attachments, 14-1  
 Towing Eye Bushing Replacement, 14-6  
 Towing Pintle, 14-2  
 Track, 12-50  
 Track Adjuster Assembly and Mounting Bracket, 12-38  
 Track Drive Sprocket, 12-40  
 Track Pad, 12-42  
 Track Shoe, 12-46  
 Track Tension, 12-44  
 Transmission Access Cover, 16-21  
 Transmission Access Door Seals, 16-85  
 Transmission Access Doors and Door Support Bracket, 16-82  
 Transmission Assembly and Associated Parts, 9-14  
 Transmission Gage Rod and Seal, 9-26  
 Transmission Hub Assembly, 9-31  
 Transmission Internal Brake, 9-23

## ALPHABETICAL INDEX - CONTINUED

- Transmission Oil Filter, 9-21  
Transmission Oil Lines and Oil Sampling Valve, 9-36  
Transmission Oil Pressure Transmitter and Transmission Oil Low Pressure Switch, 8-132  
Transmission Oil Temperature Transmitter and Transmission Oil High Temperature Switch, 8-130  
Transmission Pressure Checks, 9-14  
Transmission Throttle Control Adjustment, 5-80  
Troubleshooting Chart, 3-15  
Troubleshooting, General Instructions, 3-2  
    Electrical Troubleshooting, 3-2  
    STE/ICE Troubleshooting, 3-2  
    Wiring Harness Shorts Test, 3-2  
Troubleshooting, Quick Guide to, 3-3  
Turbocharger Oil Line, 5-34
- V**
- Vehicle Identification Plate, 18-38  
Ventilating Equipment, 8-336  
Ventilation Air Duct, 16-4  
Vertical Latch Assembly, 16-183  
Voltage Regulator, 8-32  
Voltage Regulator Control Box Assembly, 8-59
- W**
- Warning Light Assembly (Steering Shaft), 8-122  
Warnings and Cautions, 2-10  
Warranty Information, 1-3  
Water Manifold, Headers, Thermostats, and Housing, 7-18  
Welds, 2-9  
Wheels and Tracks, 12-1  
Winterization Equipment, 18-12  
Winterization Kit Wiring Harness (Bulkhead to Control Box), 19-18  
Winterization Kit Wiring Harness (Coolant Heater to Bulkhead), 19-24  
Wiring Harness and Cable Repair, 8-162  
Wiring Harness Hull Rear Access Covers, 8-328  
Wiring Harness Rear Access Guard, 8-326  
Wiring Harness Shorts Test, 3-2  
Wiring Harness W100, 8-166  
Wiring Harness W101, 8-172  
Wiring Harness W102, 8-182  
Wiring Harness W104, 8-187  
Wiring Harness W105, 8-194  
Wiring Harness W106, 8-200  
Wiring Harness W107, 8-206  
Wiring Harness W108, 8-211  
Wiring Harness W109, 8-213  
Wiring Harness W110, 8-217  
Wiring harness W111A, 8-221  
Wiring Harness W112, 8-225  
Wiring Harness W113, 8-230  
Wiring Harness W114, 8-238  
Wiring Harness W114 Access Guard, 8-327  
Wiring Harness W115, 8-246  
Wiring Harness W116, 8-254  
Wiring Harness W117, 8-260  
Wiring Harness W118, 8-266  
Wiring Harness W119, 8-269  
Wiring Harness W120, 8-276  
Wiring Harness W122, 8-280  
Wiring Harness W123, 8-284  
Wiring Harness W124, 8-286  
Wiring Harness W125, 8-290  
Wiring Harness W126, 8-295

**By Order of the Secretary of the Army:**

**DENNIS J. REIMER**  
*General, United States Army*  
*Chief of Staff*

  
**JOEL B. HUDSON**  
*Acting Administrative Assistant to the*  
*Secretary of the Army*  
05381

**DISTRIBUTION:** To be distributed in accordance with DA Form 12-37-E, block 1933 requirements for TM 9-2350-314-20-1-1.

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



**THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.**

**SOMETHING WRONG WITH THIS PUBLICATION?**

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 9-2350-314-20-1-1

PUBLICATION DATE

July 2002

PUBLICATION TITLE

UNIT MAINTENANCE MANUAL FOR 155MM, M109A6, SP HOWITZER

BE EXACT. . . PIN-POINT WHERE IT IS

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.
5-2	5-1		

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

Callout (3) in step 1 should be callout (2), and callout (2) in step 2 should be callout (5).

SAMPLE

TEAR ALONG PERFORATED LINE

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

Your name, your title, your phone number

SIGN HERE

Your signature

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



**THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.**

**SOMETHING WRONG WITH THIS PUBLICATION?**

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 9-2350-314-20-1-1

PUBLICATION DATE

July 2002

PUBLICATION TITLE

UNIT MAINTENANCE MANUAL FOR  
155MM, M109A6, SP HOWITZER

BE EXACT. . .PIN-POINT WHERE IT IS

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE



FILL IN YOUR  
UNIT'S ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY




OFFICIAL BUSINESS

NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

**BUSINESS REPLY MAIL**  
FIRST CLASS      BRM PERMIT NO. 82      ROCK ISLAND, IL

POSTAGE WILL BE PAID BY ROCK ISLAND ARSENAL



Technical Publication Information Office  
TACOM-RI  
1 Rock Island Arsenal  
Rock Island, IL 61299-7630

TEAR ALONG PERFORATED LINE



# CONVERSION TABLE

inch	decimal	mm	inch	decimal	mm	inch	decimal	mm
1/64	0.015625	0.3969	23/64	0.359375	9.1281			
1/32	0.031250	0.7938	3/8	0.375000	9.5250	45/64	0.703125	17.8594
3/64	0.046875	1.1906				23/32	0.718750	18.2562
1/16	0.062500	1.5875	25/64	0.390625	9.9219	47/64	0.734375	18.6531
			13/32	0.406250	10.3188	3/4	0.750000	19.050
5/64	0.078125	1.9844	27/64	0.421875	10.7156			
3/32	0.093750	2.3812	7/16	0.437500	11.1125	49/64	0.765625	19.4469
7/64	0.109375	2.7781				25/32	0.781250	19.8437
1/8	0.125000	3.1750	29/64	0.453125	11.5094	51/64	0.796875	20.2406
			15/32	0.468750	11.9062	13/16	0.812500	20.6375
9/64	0.140625	3.5719	31/64	0.484375	12.3031			
5/32	0.156250	3.9688	1/2	0.500000	12.7000	53/64	0.828125	21.0344
11/64	0.171875	4.3656				27/32	0.843750	21.4312
3/16	0.187500	4.7625	33/64	0.515625	13.0969	55/64	0.859375	21.8281
			17/32	0.531250	13.4938	7/8	0.875000	22.2250
13/64	0.203125	5.1594	35/64	0.546875	13.8906			
7/32	0.218750	5.5562	9/16	0.562500	14.2875	57/64	0.890625	22.6219
15/64	0.234375	5.9531				29/32	0.906250	23.0188
1/4	0.250000	6.3500	37/64	0.578125	14.6844	59/64	0.921875	23.4156
			19/32	0.593750	15.0812	15/16	0.937500	23.8125
17/64	0.265625	6.7469	39/64	0.609375	15.4781			
9/32	0.281250	7.1438	5/8	0.625000	15.8750	61/64	0.953125	24.2094
19/64	0.296875	7.5406				31/32	0.96750	24.6062
5/16	0.312500	7.9375	41/64	0.640625	16.2719	63/64	0.984375	25.0031
			21/32	0.656250	16.6688			
21/64	0.328125	8.3344	43/64	0.671875	17.0656	1	1.000000	25.4000
11/32	0.343750	8.7312	11/16	0.687500	17.4625			

## THE METRIC SYSTEM AND EQUIVALENTS

### LINEAR MEASURE

1 Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches  
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches  
 1 Kilometer = 1000 Meters = 0.621 Miles

### WEIGHTS

1 Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces  
 1 Kilogram = 1000 Grams = 2.2 Lb.  
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

### LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces  
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

### SQUARE MEASURE

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches  
 1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet  
 1 Sq. Kilometer = 1,000 Sq. Meters = 0.386 Sq. Miles

### CUBIC MEASURE

1 Cu. Centimeter = 1000 Cu. Millimeters = 0.06 Cu. Inches  
 1 Cu. Meter = 1,000,000 Cu. Centimeters = 35.31 Cu. Feet


### TEMPERATURE

$^{\circ}\text{C} = 5/9 (^{\circ}\text{F} - 32)$   
 212 $^{\circ}$  Fahrenheit is equivalent to 100 $^{\circ}$  Celsius  
 90 $^{\circ}$  Fahrenheit is equivalent to 32.2 $^{\circ}$  Celsius  
 32 $^{\circ}$  Fahrenheit is equivalent to 0 $^{\circ}$  Celsius  
 $(9/5 \times ^{\circ}\text{C}) + 32 = ^{\circ}\text{F}$

### APPROXIMATE CONVERSION FACTORS

TO CHANGE	TO	MULTIPLY BY
Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	0.914
Miles	Kilometers	1.609
Square Inches	Square Centimeters	6.451
Square Feet	Square Meters	0.093
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	0.405
Cubic Feet	Cubic Meters	0.028
Cubic Yards	Cubic Meters	0.765
Fluid Ounces	Millimeters	29.573
Pints	Liters	0.473
Quarts	Liters	0.946
Gallons	Liters	3.785
Ounces	Grams	28.349
Pounds	Kilograms	0.454
Short Tons	Metric Tons	0.907
Pound-Feet	Newton-Meters	1.356
Pounds per Square Inch	Kilopascals	6.895
Miles per Gallon	Kilometers per Liter	0.425
Miles per Hour	Kilometers per Hour	1.609

TO CHANGE	TO	MULTIPLY BY
Centimeters	Inches	0.394
Meters	Feet	3.280
Meters	Yards	1.094
Kilometers	Miles	0.621
Square Centimeters	Square Inches	0.155
Square Meters	Square Feet	10.764
Square Meters	Square Yards	1.196
Square Kilometers	Square Miles	0.386
Square Hectometers	Acres	2.471
Cubic Meters	Cubic Feet	35.315
Cubic Meters	Cubic Yards	1.308
Milliliters	Fluid Ounces	0.034
Liters	Pints	2.113
Liters	Quarts	1.057
Liters	Gallons	0.264
Grams	Ounces	0.035
Kilograms	Pounds	2.205
Metric Tons	Short Tons	1.102
Newton-Meters	Pound-Feet	0.738
Kilopascals	Pounds per Square Inch	0.145
Kilometers per Liter	Miles per Gallon	2.354
Kilometers per Hour	Miles per Hour	0.621



**PIN: 071825**