


**TECHNICAL MANUAL
OPERATOR'S, ORGANIZATIONAL, AND DIRECT SUPPORT
MAINTENANCE MANUAL**



**OUTBOARD MOTOR, GASOLINE
OMC MODEL AM-40A
NSN 2805-01-105-1680**

**INTRODUCTION
PAGE 1-1**

**OPERATING
INSTRUCTIONS
PAGE 2-1**

**OPERATORS'
MAINTENANCE
PAGE 3-1**

**ORGANIZATIONAL
MAINTENANCE
PAGE 4-1**

**DIRECT SUPPORT
MAINTENANCE
PAGE 5-1**

**APPENDICES
PAGE A1**

CHANGE }
NO. 2 }

TM 5-2805-261-13
C 2
HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 17 March 1989

Operator, Organizational and Direct Support
Maintenance Manual

OUTBOARD MOTOR, GASOLINE
OMC MODEL AM-40A
NSN 2805-01-105-1680

TM 5-2805-261-13, 3 May 1982, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

Insert pages

C-1 through C-7/C-8

C-1 through C-8

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

CARL E. VUONO
General, United States Army
Chief of Staff

Official:

WILLIAM J. MEEHAN, II
Brigadier General, United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25A, Operator, Unit, Direct Support and general Support Maintenance requirements for Motor, Outboard, Gasoline, Model AM-40A

CHANGE }
No. 1 }

TM 5-2805-261-13
HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 12 April 1985

OPERATOR, ORGANIZATIONAL AND DIRECT SUPPORT
MAINTENANCE MANUAL

OUTBOARD MOTOR, GASOLINE
OMC MODEL AM-40A
NSN 2805-01-105-1680

TM 5-2805-261-13, 3 May 1982, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

1-3 and 1-4
2-7 and 2-8

4-23 and 4-24
4-27 and 4-28
C-5 and C-6

Insert pages

1-3 and 1-4
2-7 and 2-8
2-8.1/2-8.2
4-23 and 4-24
4-27 and 4-28
C-5 and C-6

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official:

DONALD J. DELANDRO
Brigadier General, United States Army
The Adjutant General

JOHN A. WICKHAM, JR.
General, United States Army
Chief of Staff

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25D, Operator, Organizational and Direct Support and General Support Maintenance Requirements for Outboard Motors.

WARNING

Before starting engine or operating any of the components ensure that no loose bars, tools, or parts are lying in or on any part of the equipment, as they could cause serious damage to equipment or bodily injury to personnel.

WARNING

Never wear loose clothing, or loose objects or items on person or clothing, while inspecting running engine, moving shafts, or like machinery.

WARNING

Disconnect the spark plug cables prior to engine maintenance to prevent accidental starting and severe shock.

WARNING

Do not touch the ignition system harness during starting or while in operation. Severe shocks or burns could result, and personnel may be seriously injured.

WARNING

When handling gasoline, always provide a metal-to-metal contact between the container and tank. This will prevent a spark from being generated as gasoline flows over the metallic surface.

WARNING

Before refueling, ensure that adequate fire fighting equipment is serviceable and is standing by for immediate use in event of fire or explosion.

WARNING

Noise hazard. Operation of this equipment presents a noise hazard. Wear ear muff or ear plugs to avoid ear injury within 15 feet when operating outboard motor at high RPM.

WARNING

Do not refuel while engine is in operation.

WARNING

Never touch engine or engine accessories with bare hands during operation, or before they have cooled sufficiently. Severe burns can be caused through carelessness.

WARNING

Make certain any lifting device used has a capacity equal to the weight being lifted. Failure to observe this precaution could result in injury or death to personnel and damage to equipment.

WARNING

Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid repeated and prolonged skin contact by wearing rubber or non-porous gloves when handling the solvent or material wet with drycleaning solvent. Wash hands immediately after exposure with soap and water and use a lanolin based skin cream to prevent skin drying. Do not use near open flame or excessive heat. Flash point of solvent is 100°F (38°C). Do not work with solvent in a closed room. Be sure there is good ventilation or the solvent vapors will build up in the air and become a poisonous mixture which can cause physical injury or even death.

a/(b blank)

OPERATOR'S ORGANIZATIONAL AND DIRECT SUPPORT
MAINTENANCE MANUAL

OUTBOARD MOTOR, GASOLINE
OMC MODEL AM-40A
NSN 2805-01-105-1680

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistake or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2, located in the back of this manual direct to: Commander, U.S. Army Troop Support and Aviation Materiel Readiness Command, ATTN: DRSTS-MPSD, 4300 Goodfellow Blvd., St. Louis, MO 63120. A reply will be furnished directly to you.

TABLE OF CONTENTS

		Page
CHAPTER	1. INTRODUCTION	
Section I	General	1-1
Section II	Equipment Description	1-1
Section III	Technical Principles of Operation.....	1-5
CHAPTER	2. OPERATING INSTRUCTIONS	
Section I	Description and Use of Operator's Controls and Indicators	2-1
Section II	Preventive Maintenance Checks and Services (PMCS)	2-3
Section III	Operation Under Usual Conditions.....	2-4
Section IV	Operation Under Unusual Conditions	2-10
CHAPTER	3. OPERATOR'S MAINTENANCE INSTRUCTIONS	
Section I	Lubrication Instructions.....	3-1
Section II	Troubleshooting	3-4
Section III	Maintenance Procedures	3-7
Section IV	Starter Maintenance	3-8
Section V	Spark Plugs Maintenance	3-10
Section VI	Steering Handle Maintenance	3-13
Section VII	Gearcase Maintenance	3-15
Section VIII	Propeller Maintenance	3-17
Section IX	Fuel System Maintenance	3-20
Section X	Throttle Adjustment	3-25
Section XI	Screw Assembly Clamp Maintenance	3-28

CHAPTER	4. ORGANIZATIONAL MAINTENANCE INSTRUCTIONS	
Section I	Repair Parts, Special Tools, TMDE and Support Equipment	4-1
Section II	Service Upon Receipt	4-1
Section III	Preventive Maintenance Checks and Services (PMCS)	4-2
Section IV	Troubleshooting	4-3
Section V	Manual Starter	4-8
Section VI	Armature Plate (Magneto Assembly) Maintenance	4-16
Section VII	Ignition System Maintenance	4-24
Section VIII	Fuel System Maintenance	4-33
Section IX	Engine Maintenance	4-47
Section X	Lower Unit Maintenance	4-49
Section XI	Cooling System Maintenance	4-57
CHAPTER	5. DIRECT SUPPORT MAINTENANCE INSTRUCTIONS	
Section I	Repair Parts, Special Tools and Equipment	5-1
Section II	Motor Cover	5-2
Section III	Fuel System	5-9
Section IV	Engine Assembly	5-17
Section V	Exhaust Housing Assembly	5-36
Section VI	Gearcase	5-50
APPENDIX	A. REFERENCES	A-1
	B. BASIC ISSUE ITEM LIST	B-1
	C. MAINTENANCE ALLOCATION LIST	C-1
	D. ADDITIONAL AUTHORIZATION LIST	D-1
	E. EXPENDABLE SUPPLIES AND MATERIAL LIST	E-1
	F. ILLUSTRATED LIST OF MANUFACTURED ITEMS	F-1
	G. TORQUE LIMITS	G-1

LIST OF ILLUSTRATIONS

	Page
Figure 1-1.	Motor - starboard side 1-2
Figure 1-2.	Fuel tank and motor - port side 1-3
Figure 1-3.	View A 1-5
Figure 1-4.	View B 1-5
Figure 1-5.	View C 1-6
Figure 1-6.	Carburetor 1-6
Figure 1-7.	Leaf valves 1-7
Figure 1-8.	Fuel pump 1-7
Figure 1-9.	Operation of fuel pump 1-7
Figure 1-10.	Fuel tank 1-8
Figure 1-11.	Diagram A 1-8
Figure 1-12.	Diagram B 1-8
Figure 1-13.	Diagram C 1-8
Figure 1-14.	Diagram D 1-9
Figure 1-15.	Diagram E 1-9
Figure 1-16.	Diagram F 1-9
Figure 1-17.	Diagram G 1-9
Figure 1-18.	Spark plug 1-10
Figure 1-19.	View of rewind starter 1-10
Figure 1-20.	Forward and reverse gears 1-11
Figure 1-21.	Water pump 1-11
Figure 1-22.	Water pump impeller 1-11
Figure 1-23.	Ignition arrangement 1-12
Figure 1-24.	Power stroke 1-12
Figure 1-25.	Leaf plate operation 1-12
Figure 1-26.	Routing of exhaust gases 1-12
Figure 1-27.	Cooling system 1-13
Figure 1-28.	Gears arrangement 1-13
Figure 2-1.	Reverse lock 2-1
Figure 2-2.	Fuel connectors 2-1
Figure 2-3.	Primer bulb..... 2-1
Figure 2-4.	Throttle grip 2-1
Figure 2-5.	Shift lever 2-1
Figure 2-6.	Steering handle..... 2-2
Figure 2-7.	Choke knob 2-2
Figure 2-8.	Starter handle..... 2-2
Figure 2-9.	Water pump indicator 2-2
Figure 2-10.	Stop button..... 2-2
Figure 2-11.	Cover locking lever 2-2
Figure 2-12.	Tilt lock 2-2
Figure 2-13.	Motor angle adjustment 2-5
Figure 2-14.	Reverse lock 2-5
Figure 2-15.	Tilt adjusting rod 2-5
Figure 2-16.	Reverse lock 2-6
Figure 2-17.	Fuel connectors 2-6
Figure 2-18.	Primer bulb 2-6
Figure 2-19.	Throttle grip 2-6
Figure 2-20.	Shift lever 2-6
Figure 2-21.	Throttle grip 2-7

LIST OF ILLUSTRATIONS -Continued

	Page
Figure 2-22	Choke..... 2-7
Figure 2-23	Starter handle..... 2-7
Figure 2-24	Water pump indicator 2-7
Figure 2-25	Load distribution 2-8
Figure 2-26	Throttle grip 2-8
Figure 2-27	Shift lever 2-8
Figure 2-28	Stop button 2-8
Figure 2-29.	Motor cover locking lever 2-9
Figure 2-30.	Steering friction adjustment screw 2-9
Figure 2-31.	Tilt friction adjustment 2-9
Figure 2-32.	Idle speed adjustment..... 2-10
Figure 2-33.	Starter screws..... 2-11
Figure 3-1.	Neutral lockout lever 3-9
Figure 3-2.	Starter 3-9
Figure 3-3.	Spark plug and lead cover 3-11
Figure 3-4.	Steering handle lubrication..... 3-14
Figure 3-5.	Gearcase lubrication..... 3-16
Figure 3-6.	Propeller replacement 3-18
Figure 3-7.	Fuel pump 3-21
Figure 3-8.	Auxiliary filter (1 of 3)..... 3-23
Figure 3-8.	Auxiliary filter (2 of 3)..... 3-24
Figure 3-8.	Auxiliary filter (3 of 3)..... 3-24
Figure 3-9.	Idle speed adjustment 3-26
Figure 3-10.	Low speed adjustment 3-27
Figure 3-11.	Screw clamp assembly 3-29
Figure 4-1.	Crate and carrier 4-1
Figure 4-2.	Ignition spark test 4-5
Figure 4-3.	Ignition coil no.1 circuit test 4-6
Figure 4-4.	Ignition coil no.2 circuit test 4-7
Figure 4-5.	Rope anchor 4-9
Figure 4-6.	Starter rewind assembly 4-10
Figure 4-7.	Spring winder 4-12
Figure 4-8.	Spring cup 4-12
Figure 4-9.	Pulley and hosing 4-12
Figure 4-10.	View of assembled starter 4-13
Figure 4-11.	Threading the handle 4-14
Figure 4-12.	View of rope anchor 4-14
Figure 4-13.	Armature plate 4-18
Figure 4-14.	Flywheel 4-22
Figure 4-15.	Ignition coil 4-25
Figure 4-16.	Condenser 4-26
Figure 4-17.	Timing the engine 4-28
Figure 4-18.	Breaker point adjustment 4-29

LIST OF ILLUSTRATIONS -Continued

	Page
Figure 4-19.	Timing marks 4-30
Figure 4-20.	Motor stop (shorting) switch 4-31
Figure 4-21.	S34 pressure tester 4-35
Figure 4-22.	Pressure tester adapter 4-35
Figure 4-23.	Fuel tank and fuel lines 4-37
Figure 4-24.	Fuel pump 4-40
Figure 4-25.	Carburetor and needle valves 4-42
Figure 4-26.	Inlet needle valve and seat 4-43
Figure 4-27.	Slow speed needle valve 4-44
Figure 4-28.	Carburetor 4-45
Figure 4-29.	Intake manifold 4-46
Figure 4-30.	Steering handle 4-50
Figure 4-31.	Stern brackets 4-52
Figure 4-32.	Motor - starboard view 4-54
Figure 4-33.	Motor - starboard view 4-56
Figure 4-34.	Lower unit and water pump 4-59
Figure 4-35.	Water intake screen 4-62
Figure 4-36.	Markal thermomelt stik 4-63
Figure 5-1.	Upper and lower motor cover 5-4
Figure 5-2.	Carburetor 5-11
Figure 5-3.	Intake manifold 5-14
Figure 5-4.	Motor - port view..... 5-18
Figure 5-5.	Motor - starboard view 5-19
Figure 5-6.	Engine plate and gaskets 5-19
Figure 5-7.	Shifter lock 5-20
Figure 5-8.	Throttle control lever 5-20
Figure 5-9.	Throttle linkage..... 5-21
Figure 5-10.	Engine (1 of 2) 5-23
Figure 5-10.	Engine (2 of 2) 5-24
Figure 5-11.	Piston installation 5-27
Figure 5-12.	View of deflectors 5-27
Figure 5-13.	Cylinder head bolt tightening sequence 5-29
Figure 5-14.	Crankcase and piston assembly 5-31
Figure 5-15.	Piston - "loose" boss 5-32
Figure 5-16.	Driving out the wrist pin 5-32
Figure 5-17.	Crankshaft center bearings 5-32
Figure 5-18.	View of deflectors 5-33
Figure 5-19.	Micrometer check of pistons 5-34
Figure 5-20.	Lower unit 5-39
Figure 5-21.	Exhaust housing 5-46
Figure 5-22.	Steering handle 5-48
Figure 5-23.	Gearcase arrangement 5-52
Figure 5-24.	Gearcase 5-53
Figure 5-25.	Clutch dog shifter and shaft 5-56
Figure 5-26.	Gearcase pressure test..... 5-59

v/(vi blank)

CHAPTER 1

INTRODUCTION

Section I. GENERAL

1-1. **SCOPE.** This manual is for your use in operating and maintaining the model AM-40A outboard motor. Chapters 2 and 3 provide information on operation, preventive maintenance services, and operator's maintenance of equipment, accessories, components and attachments. Chapters 4 through 5 provide maintenance information for the organizational, and DS levels.

Also included are descriptions of all components.

1-2. **MAINTENANCE FORMS AND RECORDS.** Equipment maintenance forms and procedures for their use are contained in TM 38-750, The Army Maintenance Management System (TAMMS). These manuals are published to aid in property accountability and are available through: Commander, US Army Adjutant General 2800 Eastern Blvd., Baltimore, MD 21200.

1-3. **REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR'S).** EIR can and must be submitted by anyone who is aware of an unsatisfactory condition with the equipment design or use. It is not necessary to show a new design or list a better way to perform a procedure, just simply tell why the design is unfavorable or why a procedure is difficult. EIR may be submitted on SF 368 (Quality Deficiency Report). Instructions for preparing EIR's are provided in TM . The Army Maintenance Managements System. Mail directly to Commander Headquarters, U.S. Army Troop Support and Aviation Materiel Readiness Command, 38-750 Attn: DRSTS-MPDM, 4300 Goodfellow Blvd., St. Louis, MO 63120. A reply will be furnished directly to you.

1-4. **WARRANTY INFORMATION.** All components of the outboard motor are warranted by outboard marine corporation for a period of 180 days (6 months). Report all defects in material or workmanship to your supervisor, who will take appropriate action through your organizational maintenance shop.

1-5. **Hand Receipt.** Hand receipts for Components of End Item (COEI), Basic Issue Items (BI), and Additional Authorization List (AAL) items are published to aid in property accountability and is available through: Commander, US Army Adjutant General Publication Center, 2800 Eastern Blvd., Baltimore, MD 21200.

Section II. EQUIPMENT DESCRIPTION

1-6. **PURPOSE OF THE OUTBOARD MOTOR.** A propulsion unit for inflatable rafts and small boats (18' or less).

1-7. **CAPABILITIES AND FEATURES.**

- Uses gasoline for fuel (see LO 5-2805-261-12)
- Can be placed in position by two men
- Can be operated by one man
- Uses external gas tank
- Operational all weather
- Operational salt and fresh water
- Portable

NOTE

Sometimes the words "right" and "left" are very confusing when referring to the sides of an outboard motor. Therefore, the sides are referred to as starboard or port sides. Starboard means on the right hand while facing the bow (front) of the boat; port means left hand.

The outboard motor as a whole unit will be referred to as "motor". The component parts of the outboard motor will be referred to by their proper names, eg. "engine" refers to only the engine.

1-8. **LOCATION AND DESCRIPTION OF MOTOR COMPONENTS.** (Figures 1-1 and 1-2.)

SHIFT LEVER (1). Shifts gears to one of three positions: forward, neutral, reverse.

CARRYING HANDLE (2). For carrying motor.

TILT FRICTION NUT (3). For adjusting the friction needed to hold the motor in a tilted position.

TILT LOCK (4). Holds motor in a tilted position.

ANGLE ADJUSTING ROD (5). Allows the motor to be positioned in different attitudes relative to the crafts' transom.

OIL LEVEL PLUG (6). Access hole to check level of oil in gearcase.

WATER INTAKE (7). Inlet for cooling water.

SKEG (8). Protects the propeller.

OIL DRAIN/FILL PLUG (9). Access hole to drain and fill gearcase.

GEARCASE (10). Contains forward and reverse gears.




Figure 1-1. Starboard View of Motor

- | | |
|---|--|
| 1. Shift lever | 12. Clamp screws |
| 2. Steering bracket and carrying handle | 13. Reverse lock lever |
| 3. Tilt friction nut | 14. Identification plate |
| 4. Tilt lock | 15. Steering handle and throttle control |
| 5. Angle adjusting rod | 16. Stop button |
| 6. Oil level plug | 17. Choke |
| 7. Water intake | 18. Water pump indicator |
| 8. Skeg | 19. Starter handle |
| 9. Oil drain/fill plug | 20. Transom wedge |
| 10. Gearcase | |
| 11. Stern brackets | |




Figure 1-2. Port View of Motor

- | | |
|-----------------------------------|------------------|
| 21. Fuel connector | 30. Tilt grip |
| 22. Safety chain lug | 31. Fuel tank |
| 23. Idle speed adjusting screw | 32. Priming bulb |
| 24. Angle adjustment rod retainer | 33. Filler cap |
| 25. Propeller | 34. Handle |
| 26. Exhaust outlet | 35. Fuel line |
| 27. Anti-ventilation plate | 36. Fuel gauge |
| 28. Water discharge | 37. Drain screw |
| 29. Locking lever - cover | 38. Motor cover |

- STERN BRACKETS (11). Braces motor against transom.
- CLAMP SCREWS (12). Fastens motor to transom.
- REVERSE LOCK LEVER (13). Allows the motor to tilt when hitting an underwater obstruction.
- IDENTIFICATION PLATE (14). Contains model and serial number.
- STEERING HANDLE AND THROTTLE CONTROL (15).
Controls steering and speed.
- STOP (SHORTING) BUTTON (16). Stops motor.
- CHOKE (17). Adjusts butterfly valve of carburetor for cold weather starts.
- WATER PUMP INDICATOR (18). Provides visual evidence of water pump function.
- STARTER HANDLE (19). Provides handle for starter pull cord.
- TRANSOM WEDGE (20). Prevents clamp screws from damaging the transom.
- FUEL CONNECTOR (21). Connection for fuel tank.
- SAFETY CHAIN LUG (22). Connection for safety chain.
- IDLE SPEED ADJUSTING SCREW (23). Adjusts idle speed.
- ANGLE ADJUSTMENT ROD RETAINER (24). Prevents adjustment rod slipping out of holes.
- PROPELLER (25). Transfers engine power to water.
- EXHAUST OUTLET (26). Exit point for engine exhaust.
- ANTI-VENTILATION PLATE (27). Prevents air pockets around propeller.
- WATER DISCHARGE (28). Outlet for cooling water.
- LOCKING LEVER-COVER (29). Locks engine cover in place.
- TILT GRIP (30). Handle to tilt motor.
- FUEL TANK (31). Contains fuel for motor.
- PRIMING BULB (32). Primes fuel lines and carburetor.
- FILLER CAP (33). Pressure cap to secure fuel tank.
- HANDLE(34). Carrying handle for fuel tank.
- FUEL LINE (35). Carries fuel from tank to engine.

- FUEL GAGE (36). Indicates quantity of fuel left in tank.
- DRAIN SCREW (37). Used to drain fuel tank.
- MOTOR COVER (38). Prevents access to moving parts; covers and protects engine.

1-9. PERFORMANCE DATA.

- A. POWERHEAD (ENGINE)
 - Powerhead Two cylinder - two cycle, alternate firing, water-cooled
 - Full throttle operating range 4000 to 5000 RPM
 - Bore and stroke 80.96 x 69.85 mm (3.190" x 2.750")
 - Piston displacement 719.39 cc (43.90 cu in)
 - Horsepower 40 (28.3 kw @ 4500 RPM)
 - Starter Manual - Self-winding
 - Speed control On steering handle - Manual start. Synchronized throttle and spark

- B. FUEL SYSTEM
 - Carubretion Single barrel, float feed, fixed high speed/adjustable low-speed, manual choke
 - Float-level setting Flush with rim of casting
 - Inlet needle seat 1.65-1.57 mm (.065-.062") (Use No. 52 drill as gage)
 - Fuel tank capacity 22.7 litre (6 gallon) tank

- C. IGNITION SYSTEM
 - Ignition Low tension magneto
 - Breaker point gap 0.50 mm (0.020")
 - Spark plug Champion RL-82
 - Spark plug gap 0.76 mm (0.030")
 - Spark plug torque 24 to 27 N-m (17-1/2 to 20-1/2 lb ft).
 - Spark plug wrench size 21 mm (13/16")
 - Driver coil 1.45 ± 0.4 OHM
 - Condenser Part No. 581419
 - Capacity 0.25-0.29 Mfd.
 - Ignition coil Part No. 581786

- D. LOWER UNIT
 - Gear shift Forward-Neutral-Reverse
 - Gear ratio 0.57 (12:21)
 - Propeller 3 Blade, 27.3 cm (10-3/4") Dia x 27.9 cm (11") Pitch
 - Propeller nut socket size 20.64 mm (13/16")
 - Cooling system combination positive displacement and centrifugal pump

1-10. MAINTENANCE DATE.

- Transom Height 495 to 521 mm (19-1/2 to 20-1/2")
- Weight (without fuel tank) 61.3 kg (141 lbs)
- Fuel tank - empty 5.0 kg (11 lbs)
- Fuel Tank - Full 47 lb (21.3 kg)

1-11. REPAIR AND REPLACEMENT STANDARDS.

Table 1-1 lists the manufacturer's sizes and tolerances.

Table 1-1. Repair and Replacement Standards

POWERHEAD		LOWER UNIT	
Piston ring gap	0.007 - 0.017 in. (0.18 - 0.43 mm)	Propeller shaft in front gear bushing	0.001 - 0.002 in. (0.025 - 0.050 mm)
Piston ring groove clearance, lower	0.001 - 0.004 in. (0.038 - 0.102 mm)	Rear reverse gear to rear bushing	0.0005 - 0.002 in. (0.013 - 0.050 mm)
Piston pin to piston - loose end	0.001 in. (0.025 mm)	Reverse gear bushing to propeller shaft	0.0005 - 0.0010 in. (0.013 - 0.038 mm)
Cylinder and piston	0.0005 - 0.0030 in. (0.013 - 0.076 mm)	Propeller on shaft at drive pin hole	0.0007 - 0.0030 in. (0.018 - 0.076 mm)
Crankshaft end play	0.0011 - 0.0030 in. (0.028 - 0.76 mm)	Propeller on shaft - above the shoulder	0.0007 - 0.0034 in. (0.017 - 0.086 mm)

Section III. TECHNICAL PRINCIPLES OF OPERATION

1-12. SECTION OVERVIEW. this section contains a description of how the outboard motor works. Paragraph 1-13 describes the operation of the components. Paragraph 1-14 describes the unit as a whole.

1-13. OUTBOARD MOTOR FUNCTION.

- A. POWERHEAD. The engine component of the unit. Provides 40 horsepower to drive the propeller. The sequences (views) below give a brief description of engine operation.

View A shows the fuel intake and gas exhaust stage which occurs immediately after firing. Note that the exhaust and intake ports have been uncovered by the piston. Gas vapors resulting from the explosion are exiting through the exhaust port. At the same time a fuel-air mixture in the crankcase is being compressed and forced upward through the intake port, expelling any remaining gas vapor through the exhaust port. At this point the leaf valve is closed. The leaf valve controls the direction of flow of the fuel-air mixture from the carburetor into the crankcase cavity.

As the piston starts its upward or compression stroke, a partial vacuum is created in the crankcase and atmospheric pressure forces the leaf valve open, allowing the next combustible charge to enter the crankcase cavity. By this time the piston has compressed the intake mixture against the cylinder head preparatory to firing.




Figure 1-3. View A




Figure 1-4. View B

The compressed air-fuel mixture ... now highly combustible ... is ignited by the spark plug when a timed electric current jumps the gap between its electrodes. View C illustrates the downward or power stroke of the piston under the force of the explosion. As the piston ... in its downward travel ... uncovers the exhaust and intake ports, the intake and exhaust stage shown in View A again occurs. With an outboard motor engine running at full throttle this cycle may be repeated more than 4500 times per minute.




Figure 1-5. View C

B. FUEL SYSTEM. The function of the fuel system is to store, supply, filter and mix gasoline (and lubricant) with air for combustion in the cylinders. The fuel system is composed of the fuel tank, the fuel pump, the carburetor, the leaf plate assembly, and the lines, hoses, and connectors that carry fuel from component to component.

1. The carburetor is a single-barrel, float feed type with a manual choke, fixed high speed jet, and an adjustable slow speed needle valve. The throttle valve is synchronized with the ignition system by a throttle control cam located on the armature plate and the cam follower located on the carburetor body. The cam follower is linked to the throttle valve shaft.

The carburetor mixes fuel and air in proportions determined by engine speed requirements. Fuel is held in a small, bowl-like chamber. A cork float operates the inlet valve which allows fuel to be replaced as it is consumed.

Piston movement creates alternating conditions of pressure and partial vacuum in the crankcase. Atmospheric pressure trying to fill the partial vacuum creates a flow of air through the carburetor

throat or barrel. A narrowing in the carburetor throat called the venturi causes the air passing through to speed up. Because the speed of the air moving through the venturi is increased, the air pressure in the venturi is reduced.




Figure 1-6. Carburetor (1 of 2)

The difference in air pressure over the high speed nozzle and atmospheric pressure in the float chamber, causes the fuel to be pushed up the high speed nozzle and into the air stream in the throat of the carburetor.

The throttle and choke valves work together to control the amount of fuel-air mixture fed to the crankcase and the ratio of fuel to air. The choke valve is used to control the ratio of air to fuel by controlling the air intake. The throttle valve controls the amount of fuel fed to the crankcase.

The fixed high speed jet insures an even flow of fuel up the high speed nozzle. The fuel must pass through the high speed jet before it rises up the high speed nozzle.

The high speed jet is fixed and needs no adjustment in its orifice. The slow speed needle valve is adjustable.




Figure 1-6. Carburetor (2 of 2)

The slow speed needle valve operates when the engine is at idle and slow speeds. The throttle valve is closed and reduces the air flow into the carburetor. This cuts off the flow of fuel from the high speed nozzle. An adjustable flow of fuel is allowed to enter the slow speed reservoir, mix with a small amount of air, and go to the crankcase.

2. There are two leaf valves on the unit, one for each piston and crankcase compartment.

As piston movement creates alternating conditions of pressure and partial vacuum in each compartment, the leaf valves open and close. They open when there is partial vacuum in a crankcase compartment, and close when there is back pressure. This allows the fuel-air mixture to enter the crankcase and prevents it from backing out into the carburetor throat.




Figure 1-7. Leaf valves





Figure 1-8. Fuel pump

3. The diaphragm operated fuel pump is mounted directly over a port in the crankcase. The pressure and partial vacuum conditions created in the upper crankcase act on the diaphragm, causing it to move back and forth. This back and forth motion is the pumping action.

Two one-way valves in the pump control the direction of fuel flow so that it moves only toward the carburetor.

PARTIAL VACUUM IN POWERHEAD



PRESSURE IN POWERHEAD




Figure 1-9. Operation of fuel pump

4. The fuel tank has a capacity of six gallons and is portable. Attached to the tank is a bulb primer for priming the fuel pump, fuel hose and connector, a bracket arrangement to hold the fuel line when it is not in use, a handle, and a vent assembly in the filler cap. It also has a gage to show amount of fuel in the tank.




Figure 1-10. Fuel tank

C. IGNITION SYSTEM. The ignition system provides the spark needed to ignite the air/ fuel mixture in the cylinders. It is a capacitor discharge system which means the charge of electricity is generated by magnets in the flywheel rotating past the charge coil. The initial electrical charge is generated by the operator using the manual starter.

1. The magnets have North and South magnetic poles and the charge coil laminations have three legs. Each time one of the magnetic poles passes one of the legs of the charge coil, the laminations become magnetized. When the opposite pole of the magnet passes the same leg, the magnetism in the laminator collapses and reverses polarity. As you can see from diagram A, the magnets keep on rotating past all three legs of the ignition coil. Therefore, this changing magnetism in the coil laminations reverses three times in one pass of a magnet.




Figure 1-11. Diagram A

The coil of insulated wire wound around the middle leg of the laminations is affected by this fluctuating magnetism. This results in an electric current being set up in the coil.

Because the magnetism is alternating between North and South polarity, the current is also alternating between positive and negative. Diagram B illustrates the alternating current (AC).




Figure 1-12. Diagram B

This coil current is routed through wires into the power pack where it will be stored temporarily in a capacitor. A capacitor, however, will not store alternating current. Inside the power pack is a diode which is an electronic device that allows current to flow in only one direction. In other words, it only allows the positive current to pass. Diagram C illustrates what happens when the AC is passed through a diode. Only the positive portion of the current remains. The capacitor will accept this.




Figure 1-13. Diagram C

The capacitor in the power pack will hold this charge until it's released. Here's how that takes place:

The trigger coil is located on the armature plate opposite the charge coil. (Diagram D) It has only one point of close proximity to the spinning magnets (the charge coil had three). When a magnet passes this coil, an electric current is generated but not repeated three times as with the charge coil. This current or "trigger pulse" is also routed by wires to the power pack.





Figure 1-14. Diagram D

Another electronic device inside the power pack, called an SCR, receives the trigger pulse. (Diagram E) An SCR is an electronic switch. When the trigger pulse is applied to its "gate," the SCR allows the charge, which has been stored in the capacitor, to pass out of the power pack.



SILICON CONTROLLED RECTIFIER (SCR)

Figure 1-15. Diagram E

Once the SCR has been "turned on," the capacitor releases its charge very rapidly. This charge-discharge process can be compared to that of a spring. A spring may be compressed slowly, but when released, its energy is expended almost instantly.

The burst of electrical energy from the capacitor is routed through wires from the power pack to an ignition coil.

Ignition coils are a form of electrical transformer. (See Diagram F) They consist of a primary winding and a secondary winding encapsulated around an iron-laminated core. The primary winding consists of a few turns of heavy gage wire and the secondary winding has many turns of fine gage wire.




Figure 1-16. Diagram F

The capacitor charge flows through the primary winding and sets up a magnetic field in the core of the ignition coil. When the charge has dissipated, the magnetic field in the core breaks down. As it does so, the magnetic field passes through the secondary windings setting up a current in them. Since the secondary coil has many turns of wire for the field to pass through, the voltage established is very high.

The high tension lead from the ignition coil carries this high voltage current to the spark plug where it jumps the spark gap and ignites the fuel/air mixture in the cylinder.

Since this 40-horsepower outboard has two cylinders, it must have two spark plugs and also has two ignition coils. The charge for the capacitor must be routed to the proper coil at the proper time. This timing decision is made by magnetic polarity.




Figure 1-17. Diagram G

Notice in Diagram G that the two flywheel magnets are mounted into the rim of the flywheel with their magnetic polarity reversed from each other. As the flywheel spins past the trigger coil, the S-pole of one magnet passes the coil first and the N-pole of the other magnet passes first. The result of this polarity difference is that the electrical pulse generated in the trigger coil is positive in one instance and negative in the other. Inside the power pack of this 2-cylinder engine, there are two SCR's. Each is connected to a different ignition coil. The SCR's are set up so that one of them triggers on a positive pulse and the other on a negative pulse. In this way, the two spark plugs are alternately fired to provide proper engine timing.

2. The sparkplug must satisfy two engine requirements. It must hold cylinder compressions ... and it must provide a spark of sufficient intensity to insure full explosion of the combustible fuel-air mixture compressed in the cylinder by piston action.

The first requirement is fulfilled only when the threaded reach of the spark plug is fully tightened in the cylinder head. The degree of tightening is determined by the amount of torque specified by the manufacturer. A gasket is also employed to insure correct plug setting. A loosely installed spark plug will overheat and eventually become badly burned. Insufficient spark plug torque is responsible for a large number of engine troubles.

Fulfillment of the second requirement, fuel mixture ignition, is accomplished only when the correct spark plug is in satisfactory operating condition. Spark intensity is affected by fouled or burned electrode tips, cracked insulator porcelain, and by faulty high tension lead connection. Spark intensity can also be reduced by faulty operation of other component parts in the ignition system.




Figure 1-18. Spark plug

3. The manualstarter engages the power head flywheel ratchet with three pawls when the starter rope handle is pulled. A coil spring is wound as the rope unwinds and unwinds as the handle is returned to the starter housing.

This starter has a high speed interlock which prevents the starter from operating if the throttle is in the "FAST" position.




Figure 1-19. View of rewind starter

- D. LOWER UNIT. Includes the exhaust housing and gear case. The exhaust housing is basically an extension of the powerhead to the water. It contains the shift lever, upper shift rod, drive shaft, and channels for the exhaust and cooling system. The gear case transfers the power from the drive shaft and powerhead to the propeller. It transfers this power by engaging two level gears, forward or reverse, located on the propeller shaft. The gear case also contains the cooling water inlet and the cooling water pump.

The reciprocating power of the pistons is changed to rotary power by the crankshaft. The crankshaft turns the drive shaft by means of a splined coupling. The drive shaft extends through the lower unit to the gear case where a pinion gear fits on the splined end of the shaft. The pinion gear meshes with two bevel gears which rotate freely and in opposite directions on the propeller shaft. A shifter clutch dog is placed between the two bevel gears and is splined to the propeller shaft. The shifter clutch dog is shifted by the shifter lever fingers, which in turn are operated by the manual shift lever through the action of the shifter rod.




Figure 1-20. Forward and reverse gears

When the shift rod is in the neutral position, the clutch dog is centered between the two bevel gears and is not engaged with either one. Consequently, the propeller shaft remains motionless. When the shift rod is in the forward position, the clutch dog is moved on its splines by the shifter lever into engagement with the forward bevel gear and the propeller shaft is driven clockwise. When the shift rod is in the reverse position, the clutch dog is moved into engagement with the reverse gear and the propeller shaft is driven in a counterclockwise direction.

The water pump consists of an impeller housing, an impeller, an impeller plate and a bearing housing. The impeller is keyed to the driveshaft which passes completely through the water pump. As the driveshaft turns, so does the impeller.




Figure 1-21. Water pump

The impeller housing is offset. This design feature causes the synthetic rubber blades of the impeller to flex as they rotate, with the result that the space between the blades varies. The pump inlet port, in the impeller plate, is open to the impeller blades when the space between them increases. The pump outlet port, located in the impeller housing, is open to the blades when the space between them is decreasing. Consequently, at low engine RPM the impeller functions as a displacement pump by drawing water in and then pushing it up the water tube and through the cooling system channels in the cylinder block. At high engine RPM water resistance prevents the blades from touching the side of the housing and the impeller works as a centrifugal pump.




Figure 1-22. Water pump impeller

1-14. OPERATION OF THE UNIT.

The flywheel is rotated initially by pulling the rope on the manual starter. This action brings the pinion gear on the starter into engagement with the ring gear on the flywheel and turns the flywheel. After the engine has started, the pinion gear falls out of mesh with the ring gear.

As the flywheel is turned by the starter, one of the pistons moves upward in its compression stroke. This creates a partial vacuum in the crankcase that is lower than the air pressure in the carburetor throat. Under greater pressure, the leaf valve opens, allowing the next fuel-air charge to enter the crankcase.

As the flywheel spins, the magnets mounted in it spin by in close proximity to the charge coil and trigger coil. A large voltage is established in the charge coil and stored in the condensers until it is released by a pulse from the trigger coil. The ignition coils transform this stored charge into a very high voltage which is routed to the spark plugs where it jumps the spark plug gap and ignites the fuel air mixture.




Figure 1-23. Ignition arrangement

NOTE

Figures 1-24, 1-26 illustrate a typical power stroke (one cylinder).

The spark ignites the combustible fuel-air mixture compressed under the cylinder head and the resulting explosive force drives the piston downward. Now internal crankcase pressure is greater than carburetor pressure and the leaf valve is pushed closed.




Figure 1-24. Power stroke




Figure 1-25. Leaf plate operation

As the piston clears the intake and exhaust ports, cast-in deflectors on the piston head route the next charge from the intake port and guide gases, resulting from the explosion, through the exhaust port. Exhaust gases exit through channels in the lower unit and gearcase. By this time the other piston has completed its compression stroke and the second cylinder is fired.




Figure 1-26. Routing of exhaust gases

This cycling is repeated over and over again as long as the engine is running. At full throttle the sequential firing is so close together as to appear simultaneous.

During the engine start and warm-up the thermostatic valve in the cylinder head remains closed, preventing water displaced by the water pump from entering the cooling channels in the cylinder block. Instead, the water is routed through the by-pass channel and exits through the water outlet in the exhaust housing or the under water outlet in the gearcase. When the powerhead temperature gets too hot, the thermostatic valve opens and allows water to circulate through the cylinder block channels.




Figure 1-27. Cooling system

During the engine warm-up the shift lever is in the neutral position. The shifter clutch dog remains centered between the two bevel gears. The gears are constantly driven by the driveshaft pinion gear and rotate freely on the propeller shaft. When the shift lever is moved into the forward position, the fingers of the shifter lever move the clutch dog into engagement with the forward gear. When the shift lever is in the reverse position, the clutch dog is moved into engagement with the reverse gear.




Figure 1-28. Gears arrangement

CHAPTER 2
OPERATING INSTRUCTIONS

Section I. DESCRIPTION AND USE OF OPERATOR'S CONTROLS AND INDICATORS

2-1. GENERAL. The following paragraphs will show you the controls and indicators you will need to operate the outboard motor.

Key	CONTROL OR INDICATOR	FUNCTION
1	Reverse lock	Releases when motor strikes underwater object.
2	Fuel connectors	Connect engine to fuel tank.
3	Primer bulb	Charges fuel lines.
4	Throttle grip	Used to control engine speed.
5	Shift lever	Allows operator to shift gears; reverse, neutral, forward.
6	Steering handle	Allows operator to swivel engine, to steer craft.
7	Choke knob	Pull OUT for cold weather starts.
8	Starter handle	Pull to start unit. (See Starting and Operation, para 2-6).
9	Water pump indicator	Flow of water from water pump indicator shows operator if water pump is functioning
10	Stop button	Stops engine
11	Cover locking lever	Locks lever in place
12	Tilt lock	Holds motor in position when loading or launching craft.




Figure 2-1. Reverse lock




Figure 2-2. Fuel connectors




Figure 2-3. Primer bulb




Figure 2-4. Throttle grip




Figure 2-5. Shift lever




Figure 2-6. Steering handle




Figure 2-7. Choke knob




Figure 2-8. Starter handle




Figure 2-9. Water pump indicator




Figure 2-10. Stop button




Figure 2-11. Cover locking lever




Figure 2-12. Tilt lock

Section II. PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)

2-2. GENERAL. To ensure that the outboard motor is ready for operation at all times, it must be inspected systematically so that the defects may be discovered and corrected before they result in serious damage or failure. Defects discovered during operation of the unit shall be noted for future corrections, to be made as soon as an operation has ceased. Stop operation which would damage the equipment if operation were to continue. All deficiencies and shortcomings shall be recorded together with the corrective action taken on DA Form 2404, Equipment Inspection and Maintenance Worksheet, at the earliest opportunity. When performing your Before Operation (B) and During Operation (D) PMCS, always keep in mind the CAUTIONS and WARNINGS. After operation, be sure to perform your (A) PMCS. If your equipment fails to operate, troubleshoot with proper equipment. Report any deficiencies using the proper forms, see TM 38750.

2-3. OPERATOR/CREW PREVENTIVE MAINTENANCE CHECKS AND SERVICES. Refer to table 2-1 for Preventive Maintenance Checks and Services.

- A. Item Number Column. Checks and services are numbered in chronological order regardless of interval. This column will be used as a source of item numbers for the "TM Item Number" column on DA Form 2404 in recording results of PMCS.
- B. Interval Column. The columns headed B, D, A, W and M, will contain a dot (•) opposite the appropriate check indicating it is to be performed Before, During, After, Weekly, or Monthly.
- C. Item to be Inspected Column. The items listed in this column are divided into groups and identifies the items to be inspected.
- D. Procedures Column. This column contains a brief description of the procedure by which the check is to be performed.
- E. For Readiness Reporting, Equipment is Not Ready/Available If: Column. This column will contain the criteria which will cause the equipment to be classified as not Ready/Available because of inability to perform its primary mission.

NOTE

If the equipment must be kept in continuous operation, check and service only those items that can be checked and serviced without disturbing operation. Make the complete checks and services when the equipment can be shut down.

Table 2-1. Preventive Maintenance Checks and Services

NOTE

Within designated interval, these checks are to be performed in the order listed.

Item No.	Interval					Item To Be Inspected	Procedures	Equipment Will Be Reported Not Ready/ Available If:
	B	D	A	W	M			
1	•					Cover assembly	Inspect for: cracks, misaligned or torn gasket, faulty locking lever.	Cover is cracked. Gasket is torn. Locking lever is faulty.
2	•	•*				Manual starter	Check handle, rope.	Handle cannot be used, or rope is broken.
3	•					Fuel tank	Inspect tank assembly for: leaks, faulty hose, faulty primer bulb, fittings faulty fuel cap.	Tank leaks (ruptured). Hose leaks. Primer bulb faulty. Fuel cap faulty. Fittings leak.
* While starting outboard motor								

Table 2-1. Preventive Maintenance Checks and Services - continued

NOTE

Within designated interval, these checks are to be performed in the order listed.

Item No.	Interval					Item To Be Inspected	Procedures	Equipment Will Be Reported Not Ready/ Available If:
	B	D	A	W	M			
4	•	•				Steering handle throttle	Check for steering handle function. Check that throttle grip rotates.	Steering handle movement is restricted. Throttle grip movement is restricted.
5	•					Stern bracket	Check for cracks or breaks.	Cracked or broken.
6	•					Screw clamp	Check for stripped threads or broken handles.	Threads are stripped. Handles are broken.
7		•				Shifter lever	Be certain shifter changes gears.	Shifter will not shift gears.
8		•				Water pump	Check to see if a steady stream of water is coming from the water pump indicator.	No water or irregular spurts of water from the water pump indicator.
9	•		•			Water inlet screen	Check for debris clogging screen.	Clogged screen, or missing screen.
10	•		•			Propeller	Check for cracks, breaks, or bent propeller.	Propeller is cracked, broken or bent.
11			•			Motor		Rinse with fresh water.
12			•			Motor		Wipe dry with oily rag.

Section III. OPERATION UNDER USUAL CONDITIONS

- 2-4. OPERATING PROCEDURE. The operator must know how to correctly operate this equipment. This section gives instructions on starting, operating, and stopping the outboard motor.
- 2-5. PREPARATION FOR STARTING. Perform the necessary Before Operation Preventive Maintenance Services as indicated in table 2-1.
- 2-6. INSTALLING AND ADJUSTING THE MOTOR.

WARNING

To prevent possible fuel leakage, disconnect portable tank fuel line from motor when boat is trailered, docked or when motor is tilted for more than a few minutes.

NOTE

The transom height for this outboard motor must be 19-1/2" to 20-1/2" (495 mm to 521 mm).

- A. Be certain transom wedge (20, fig. 1-1) has been installed on the transom of your boat.

WARNING

To ensure proper mounting and prevent side movement of the motor, the transom wedge must be installed on the transom of your boat.

- B. Place motor on transom with stern brackets outboard and clamp screws inboard.
 - 1. Use front and rear lifting and carrying handles to perform this step.

2. If a suitable hoist and lift are available, attach to lifting bracket at rear of powerhead and use to position motor on transom.
- C. Center motor stern brackets in transom wedge and clamp screws in stern bracket clamp.
- D. Tighten clamp screws.
- E. Attach safety chains to eyebolts in transom, using clips on end of chains.

CAUTION

Clamp screws must be tightened **ONLY** by hand. Do not use tools of any kind to tighten clamp screws.

- F. Retighten clamp screws after 15 minutes of operation.

2-7. ADJUSTING THE MOTOR ANGLE.

WARNING

The motor must be up-right to the water when boat is underway.

MOTOR ANGLE ADJUSTMENT



INCORRECT
CAUSES BOAT
TO "SQUAT"

INCORRECT
CAUSES BOAT
TO "PLOW"



CORRECT
GIVES MAXIMUM
PERFORMANCE

Figure 2-13. Motor angle adjustment

NOTE

The stern bracket has four positions for adjusting motor angle. The vertical angle of motor on boat must be adjusted for best performance.

- A. Set reverse lock (1) in RELEASE position.




Figure 2-14. Reverse lock

- B. Tilt motor up.
- C. Turn tilt adjusting rod (2) up.
- D. Press rod in against spring and turn retainer (3) to horizontal position.
- E. Remove rod from stern brackets holes.
- F. Tilt motor to the most nearly vertical angle.
- G. Install tilt adjusting rod (2) in stern brackets holes and turn down.




Figure 2-15. Tilt adjusting rod

- H. Press tilt adjusting rod (2) against spring and lock retainer (3).
- I. Put reverse lock (1) in LOCK position.

2-8. STARTING THE UNIT.

- A. Place reverse lock in LOCK position.

CAUTION

During normal operation the reverse lock should be in LOCK (up) position. The RELEASE position (push lever down and to starboard) is used only when tilting the motor, or when operating in shallow or obstructed waters.

The reverse lock, when in LOCK position, will release when the motor strikes an underwater object while traveling forward at moderate speed.




Figure 2-16. Reverse lock

- B. Slide fuel line connectors into place, until locking lever snaps.




Figure 2-17. Fuel connectors

- C. Squeeze fuel line primer bulb several times, until you feel resistance.

NOTE

Hold outlet end up while squeezing. Never hold outlet end down while priming the system.




Figure 2-18. Primer bulb

- D. Turn throttle grip to SHIFT position.




Figure 2-19. Throttle grip

- E. Move shift lever to NEUTRAL position.




Figure 2-20. Shift lever

F. Turn throttle grip to START position.




Figure 2-21. Throttle grip

G. Choke. Pull out if motor is cold. Leave in if motor is warm.




Figure 2-22. Choke

H. Starter handle.
Pull slowly until you feel starter engage. Then pull hard. Repeat until motor starts.




Figure 2-23. Starter handle

NOTE

To avoid damaging the starter, allow starter cord to rewind before releasing the handle.

NOTE

If motor fails to start see Operator Troubleshooting para 3-5.

I. Check to see if water is coming from the water pump indicator.




Figure 2-24. Water pump indicator

2-9. OPERATION.

WARNING

Do not remove the motor cover while engine is running. The motor cover is a machinery guard. Its removal exposes the operator to moving parts.

WARNING

For best boat, motor performance and safety of personnel, the boat should be driven as nearly parallel to the water as possible. Personnel and equipment should be so distributed in the boat that it is evenly balanced both front to rear and side to side.

CAUTION

Damage to the engine will result if the engine is run in excess of its rated speed even for a short time.


CAUTION

Damage to the engine will result if the engine is run without a propeller or without sufficient load on the propeller. Be sure propeller is completely immersed in water.



INCORRECT
CAUSES BOAT
TO "PLOW"

INCORRECT
CAUSES BOAT
TO "SQUAT"



CORRECT
GIVES MAXIMUM
PERFORMANCE

Figure 2-25. Load distribution

- A. Perform starting steps A thru I para 2-8.
- B. Turn throttle grip to SHIFT position.




Figure 2-26. Throttle grip

CAUTION

Always place throttle in SHIFT position before shifting gears.

CAUTION

Never attempt to shift gears from neutral when motor is not running.

- C. When motor is running and throttle grip is in SHIFT position, shift into desired position.

CAUTION

Always snap the shift lever into position with a quick action.




Figure 2-27. Shift lever

- D. Turn throttle grip to FAST or SLOW position to select desired speed.

CAUTION

When operating in reverse, be very careful not to hit any underwater objects. The automatic tilt mechanism does not work in reverse.

CAUTION

Do not operate motor in reverse with reverse lock in RELEASE position. Motor may tilt into boat resulting in loss of control.

- E. Perform your During Operation preventive checks (table 2-1).

2-10. STOPPING.

- A. Turn throttle grip to reduce engine speed.
- B. Place throttle in SHIFT position.
- C. Put shift lever in NEUTRAL position.
- D. Press STOP button until engine stops.




Figure 2-28. Stop button

Change 1 2-8.1/(2-8.2 blank)

2-11. REMOVING THE MOTOR.

- A. Disconnect fuel line.

CAUTION

Always coil fuel line on top of tank when not in use. This will help protect fuel line and connectors from damage and help prevent sand or dirt from entering connectors.

- B. Disconnect safety chain.
- C. Loosen clamp screws.
- D. Lift motor vertically from boat using lifting handles, or if hoist is available, fasten to lifting bracket and lift out.
- E. Hold motor in an upright position to allow water to completely drain.

2-12. REMOVING THE MOTOR COVER.

- A. Rotate locking lever (29, fig. 1-2) 1/4 turn UP.
- B. Using tilt grip (30, fig. 1-2), tilt motor cover up.




Figure 2-29. Motor cover locking lever

- C. Slide motor cover back to disengage front hook from lower pan.

2-13. INSTALLING MOTOR COVER.

- A. Slide motor cover hook into aperture in lower pan.
- B. Press down on rear of cover (where tilt grip is).

- C. Rotate locking lever 1/4 turn down until it engages catch in lower motor cover.

2-14. STEERING FRICTION ADJUSTMENT.

- A. Locate steering friction adjustment screw.




Figure 2-30. Steering friction adjustment screw

- B. Using screwdriver, loosen or tighten screw until you feel a slight amount of drag when turning. This provides smooth steering.

WARNING

The steering friction adjustment is not intended to allow "hands off" steering. Loss of control could result.

2-15. TILT FRICTION ADJUSTMENT.

- A. Locate tilt friction adjusting nut (3, fig. 1-1).




Figure 2-31. Tilt friction adjustment

- B. Using a wrench, loosen or tighten nut just enough to hold motor in any position of tilt.

CAUTION

Do not overtighten. This will increase the pressure required to tilt the motor when an obstruction is hit. Failure to tilt when hitting an obstruction can do serious damage to your motor.

- C. Turn counterclockwise to decrease idle speed.




Figure 2-32. Idle speed adjustment

2-16. IDLE SPEED ADJUSTMENT.

- A. Locate idle speed adjustment screw (23, fig. 1-2).

NOTE

Before making adjustment be sure throttle is in **SLOW** position and engine is at normal operating temperature.

- B. Turn clockwise to increase idle speed.

Section IV. OPERATION UNDER UNUSUAL CONDITIONS

2-17. OPERATION IN SHALLOW WATER.

- A. Avoid operating in shallow water, if at all possible.
- B. Always proceed at slow speed in shallow water.
- C. Be certain reverse lock (13, fig. 1-1) is in **RELEASE** position. This will allow motor to tilt up more easily if it hits an underwater obstruction.
- D. If you hit an underwater obstruction:
 1. Slow engine to idle speed immediately.
 2. Stop engine.
 3. Tilt motor and check lower unit for damage.

NOTE

If motor vibrates excessively after striking an underwater obstruction, it may indicate a damaged propeller. Operate at slow speed. At the first opportunity replace damaged propeller.

2-18. OPERATION IN WEEDY WATER.

CAUTION

Weeds on the propeller will cause motor to vibrate and cooling water intake (7, fig. 1-1) will tend to become clogged.

- A. Run motor at slow speeds when weeds are thick.
- B. Stop and clear propeller and cooling water intake as often as necessary.
- C. When leaving weedy water for clear water, stop and clear propeller and cooling water intake.

2-19. OPERATION IN SALT WATER **NOTE** Your motor is built to operate in either salt or fresh water.

- A. When operation in salt water is ended, remove motor from salt water and rinse external parts with fresh water.

- B. Wipe external parts dry with a slightly oily rag after running. This step may be performed after operating in either salt or fresh water and will help preserve the finish of your motor.

2-20. OPERATION IN FREEZING WEATHER.

- A. Keep lower unit submerged in water at all times when operating. This will avoid freezing and possible damage to the unit.
- B. When operation is over and you are removing unit from water, allow the unit to stand upright and all water to completely drain.

2-21. EMERGENCY STARTING (IF MANUAL STARTER FAILS).

- A. Remove motor cover. (See Removing the Motor Cover, para 2-12.)
- B. Remove three screws attaching starter. (See para 3-9.)




Figure 2-33. Starter screws

- C. Lift starter off engine.
- D. If pull cord is broken it may still be long enough to use as an emergency cord.

- E. If pull cord is not long enough, proceed as follows:

1. Tie a knot in the end of a 1/4 inch (6 mm) thick rope.
2. Place knot in pulley notch and wrap rope around pulley in a clockwise direction.
3. Follow usual procedure for starting. (See Starting the unit, para 2-8).

- F. Notify organizational maintenance that the unit needs repair.

2-22. BREAK-IN PROCEDURE.

- A. OPERATION (FIRST HOUR): Do not operate engine at continuous full power for the first hour of operation. After 15 minutes of slow to half throttle operation, we recommend a short burst of full throttle operation every 5 to 10 minutes. Run at full throttle for about 90 seconds, then return to half throttle or less.

NOTE

Frequently check operation of cooling system during break-in. A steady stream of water discharged from the water pump indicator ensures proper water pump operation.

- B. OPERATION (SECOND HOUR): Reduce power to three-quarter throttle (approximate) while maintaining planing attitude. At intervals during the second hour, apply full power for periods of one to two minutes, returning throttle to original setting three quarter throttle for a cooling period.

Avoid continuous full throttle operation for extended periods during the next three hours.

2-23. MOTOR DROPPED OVERBOARD (NOT RUNNING). If motor is recovered from water immediately, it must be serviced within 3 hours after recovery. Notify organizational maintenance immediately.

2-24. MOTOR DROPPED OVERBOARD (RUNNING). Follow the same procedure as Motor Dropped Overboard (Not Running). However, if there is any binding when flywheel is rotated it indicates a bent connecting rod and no attempt should be made to start the motor. Have it serviced immediately.

2-25. MOTOR DROPPED OVERBOARD (IN SALT WATER). Follow same procedure as Motor Dropped Overboard (Not Running) and (Running) but take the motor to organizational maintenance as soon as possible, even if it can be started, as salt water can cause excessive corrosion of ignition system and internal parts.

2-26. PROLONGED SUBMERSION (FRESH OR SALT WATER). If motor has been dropped overboard and not recovered immediately, then motor must be serviced within 3 hours after recovery. Notify organizational maintenance.

If sand has entered the motor, no attempt at starting should be made. Notify direct support immediately.

NOTE

Since this motor is provided with needle bearings, it must be serviced within 3 hours after recovery to avoid costly repairs. Both fresh and salt water characteristically will start etching the highly machined bearing surfaces of the crankshaft and connecting rods as well as the bearings once exposed to the surrounding atmosphere.

If service is not readily available, proceed as follows:

- A. Remove motor cover and rinse motor with fresh water.
- B. Disconnect spark plug leads and remove spark plugs. Reattach leads and ground plugs on motor block. (See para 3-10.)

NOTE

To remove or attach leads, pull off or push on with a slight counterclockwise twist.

- C. Lay motor down (spark plug openings down) and work out all of the water by rotating flywheel with starter cord approximately 25 times.
- D. Place motor in upright position. Remove high speed needle valve and drain carburetor.
- E. Reassemble parts you removed and follow starting instructions (see para 2-8). After starting, permit motor to run 1/2 hour or longer on boat or in a test tank with test wheel.
- F. If motor fails to start, remove spark plugs again to see if water is present between electrodes. Blow out any water from between electrodes and reinstall or replace with new spark plugs. If the motor still fails to start, have it serviced immediately. Motors which have been submerged must be started or disassembled as soon as possible or extensive repairs will be necessary. To minimize damage, motor must be started or serviced within approximately 3 hours after recovery.

NOTE

If motor cannot be started and if service is not readily available, the motor should be re-submerged immediately in fresh water to avoid exposure to the atmosphere. Make arrangements to have it serviced with the least possible delay.

CHAPTER 3 OPERATOR'S MAINTENANCE INSTRUCTIONS

Section I. LUBRICATION INSTRUCTIONS

3-1. GENERAL LUBRICATION INFORMATION. This section contains lubrication instructions for the operator and a reproduction of the lube oil chart (LO 5-2805-261-12).

3-2. ENGINE LUBRICATION. Model AM-40A has a two cycle engine. It is lubricated by adding oil (TCW 50/1) to the gasoline. For proper lubrication of the engine, 50 parts of gasoline must be mixed with 1 part of lubricant.

3-3. FUEL MIXING INSTRUCTIONS.

CAUTION

Lubricant and gasoline must be properly mixed or serious damage will result to the engine.

CAUTION

Avoid the use of the following, as they will contribute to deterioration of your engine and shorten spark plug life:

Automotive oils
Premix fuel of unknown oil quality
Premix fuel richer than 50/1 ratio
Premix fuel leaner than 50/1 mixture ratio

A. RECOMMENDED GASOLINE.

Use gasoline with the following Minimum octane numbers:

ANTI-KNOCK INDEX NUMBER	67
Research Octane Number	69

Automotive gasolines, regular-leaded or lead-free, meeting these minimum octane numbers may be used; however, best results will be obtained by using lead-free gasoline.

B. FUEL MIXTURE

1 part approved lubricant to 50 parts gasoline.
8 fl. ozs. lubricant to 3 gallons of gasoline.
16 fl. ozs. lubricant to 6 gallons of gasoline.
20 millilitres lubricant to 1 litre gasoline.

NOTE

Always use fresh gasoline.

WARNING

Gasoline is extremely flammable and highly explosive.

- Always mix fuel outdoors. Never indoors.
- Never smoke or allow open flames or sparks when mixing or refueling.
- Always stop motor before refueling.
- Always maintain metal-to-metal contact between the fill can, funnel, and gas tank when pouring gasoline. (Use a metal funnel for this purpose). This will help avoid a static spark which might ignite the gas fumes.

C. Above 32°F (0°C) pour lubricant into tank, add gasoline. Replace filler cap securely. To mix fuel, tip tank on side and back to upright position.

D. Below 32°F (0°C) pour approximately one gallon into tank, add required lubricant. Replace filler cap securely. Thoroughly mix by shaking tank. Add balance of gasoline.

LUBRICATION ORDER **L05-2805-261-12**

OUTBOARD MOTOR, GASOLINE POWERED, OMC MODEL AM-40A, NSN 2805-01-105-1680


Intervals (on-condition or hard time) and the related man-hour times are based on normal operation. The man-hour time specified is the time you need to do all the services prescribed for a particular interval. On-condition (OC) oil sample intervals shall be applied unless changed by the Army Oil Analysis Program (AOAP) laboratory. Change the hard time interval if your lubricants are contaminated or if you are operating the equipment under adverse operating conditions, including longer-than-usual operating hours. The hard time interval may be extended during periods of low activity. If extended, adequate preservation precautions must be taken. Hard time intervals will be applied in the event AOAP laboratory support is not available.


Clean parts with dry cleaning solvent (SD), type II or equivalent. Dry before lubricating. The lowest level of maintenance authorized to lubricate a point is indicated by one of the following: (C) Operator/crew; or (O) Organizational Maintenance.

You can help improve this publication. If you find any mistake or if you know of a way to improve the procedures, please let us know. Your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms) should be mailed directly to: Commander, U.S. Army Troop Support & Aviation Materiel Readiness Command, ATTN: DRSTS-MPSD, 4300 Goodfellow Blvd., St. Louis, MO 63120. A reply will be furnished to you.

*The time specified is the time required to perform all services at the particular interval.

*TOTAL TASK-HR		*TOTAL TASK-HR	
INTERVAL	TASK-HR	INTERVAL	TASK-HR
M	2.0	20	1.5
Q	1.5	B	Biannually





Distribution: To be distributed in accordance with DA Form 12-25A, Operator maintenance requirements for outboard motors, 40 HP MIL STD.

Copy of this Lubrication Order will remain with the equipment at all times; instructions contained herein are mandatory.

BY ORDER OF THE SECRETARY OF THE ARMY:
 E.C. MEYER
 General, United States Army
 Chief of Staff

OFFICIAL:
 ROBERT M. JOYCE
 The Adjutant General

NOTES

*1. FUEL MIXTURE (C)

- 1 part approved lubricant to 50 parts gasoline.
- 8 fl. ozs. lubricant to 3 (three) gallons of gasoline.
- 16 fl. ozs. lubricant to 6 (six) gallons of gasoline.
- 20 millilitres lubricant to 1 litre gasoline.

CAUTION

Lubricant and gasoline must be properly mixed or serious damage will result to the engine.

CAUTION

Avoid the use of the following, they will contribute to deterioration of your engine and shorten spark plug life:

AVOID USE OF:

- Automotive oils
- Premix fuel of unknown oil quality
- Premix fuel richer than 50/1 ratio
- Premix fuel leaner than 50/1 mixture ratio

*2. GEARCASE (O)

Change after first 20 hours of operation and check after 50 hours of operation. Add lubricant if necessary.

Drain and refill every 100 hours of operation or every 6 months, whichever occurs first.

- KEY -

LUBRICANTS		REFILL CAPACITY (APP)	EXPECTED TEMPERATURES			For Arctic Operation Refer to TM 9-207	INTERVALS
			Above +32°F Above 0°C	+40°F to -10°F +5°C to -23°C	0°F to -65°F -18°C to -50°C		
B/A Grade TCW 50/1 NSN 9150-00-117-8791	Lubricating Oil, Engine	6 gals. (Gas Tank)	TCW 50/1	TCW 50/1	TCW 50/1	M = Monthly B = Biannually 20 = Hours	
GO MIL-L-2105	Gearcase	413 cc	GO	GO	GO		
GAA	Grease	O/C	GAA	GAA	GAA		
MIL-G-2104GR30 (Oil Can Points)	General Purpose Oil						

Section II. TROUBLESHOOTING

3-4. GENERAL.

- A. This section contains troubleshooting information for locating and correcting most of the operating troubles which may develop in the outboard motor. Each malfunction for an individual component, unit, or system is followed by a list of tests or inspections which will help you to determine corrective actions to take. You should perform the tests/inspections and corrective actions in the order listed.
- B. This manual cannot list all malfunctions that may occur, nor all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by listed corrective actions, notify your supervisor.

3-5. OPERATOR TROUBLESHOOTING. Perform troubleshooting functions in accordance with table 3-1.

Table 3-1. Troubleshooting

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

1. MOTOR WILL NOT START.

- Step 1. Check for throttle grip in start position.
 - Put throttle grip in start position.
- Step 2. Check for shift lever in neutral position.
 - Put shift lever in neutral position. (See starting the Unit, para 2-8.)
- Step 3. Check fuel tank.
 - Fill fuel tank. (See fuel mixing Instructions, para 3-3.)
- Step 4. Check fuel line connectors.
 - Be sure fuel line connections are properly connected (para 2-8).
- Step 5. Check that carburetor has been primed.
 - Squeeze primer bulb until you feel resistance. (See Starting the unit, para 2-8.)
- Step 6. Check for fuel line kinked or fuel tank resting on fuel line.
 - Move fuel line so it is not kinked or fuel tank not resting on line.
- Step 7. Check for damaged primer bulb.
 - If damaged, notify organizational maintenance to replace.
- Step 8. Choke improperly adjusted for cold motor.
 - Pull choke knob all the way out (para 1-7).
- Step 9. Choke improperly adjusted for warm motor.
 - Push choke knob all the way in (para 1-7).

Table 3-1. Troubleshooting - continued

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
1. MOTOR WILL NOT START - continued.	Step 10. Engine flooded.	<ul style="list-style-type: none"> a. Push choke knob all the way in. b. Disconnect fuel line connector at motor. c. Crank motor until it is cleared.
	Step 11. Check for water in fuel system.	Replace fuel. (See Fuel Mixing instructions, para 3-3.)
	Step 12. Fuel pump filter or auxiliary fuel filter is clogged.	Clean filter (para 3-15, 3-16).
	Step 13. Check for loose spark plug leads.	<ul style="list-style-type: none"> a. Tighten. b. Replace (para 3-10).
	Step 14. Spark plugs carboned, burned, or wet.	Replace or dry (para 3-10).
	Step 15. Check for loose spark plugs.	Tighten (para 3-10).
	Step 16. Spark plug gap is incorrect.	Regap (para 3-11).
2. MOTOR WILL NOT IDLE PROPERLY.	Step 1. Check for improper fuel mixture.	Dump fuel tank and replace fuel. (See Fuel Mixing Instructions para 3-3.)
	Step 2. Carburetor adjustment is improperly set.	Adjust. (See para 3-17.)
	Step 3. Defective spark plugs.	Replace (para 3-10).
3. MOTOR LOSES POWER.	Step 1. Check for obstruction at cooling water inlet.	Remove obstruction.

Table 3-1. Troubleshooting - continued

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
3. MOTOR LOSES POWER - continued	Step 2. Water pump not functioning.	Notify organizational maintenance.
	Step 3. Check for contaminated (dirty) fuel.	Replace fuel. (See Fuel Mixing Instructions, para 3-3.)
	Step 4. Defective spark plugs.	Replace (para 3-10).
	Step 5. Fuel pump filter or auxiliary fuel filter partially clogged.	Clean (para 3-15, 3-16).
4. MOTOR VIBRATES EXCESSIVELY.	Step 1. Check for weeds on propeller.	Remove weeds.
	Step 2. Check for loose steering friction screw.	Tighten screw. (See Steering Friction Adjustment, para 2-14.)
	Step 3. Damaged propeller.	Replace propeller (para 3-14).
	Step 4. Carburetor improperly adjusted.	Adjust (para 3-17).
5. MOTOR RUNS BUT MAKES LITTLE OR NO PROGRESS.	Step 1. Check for weeds on propeller.	Remove weeds.
	Step 2. Damaged propeller.	Replace (para 3-14).
	Step 3. Sheared propeller drive pin.	Replace (para 3-14).

Section III. MAINTENANCE PROCEDURES

3-6. GENERAL. Instructions in this section are published for the information and guidance of the operator to maintain the outboard motor.

3-7. FUEL TANK, LINES AND FITTINGS.

- A. Check all fittings for leaks and retighten if necessary.
- B. If leak is found in fuel tank, report to organizational maintenance.
- C. Be sure primer bulb works properly.

3-8. THE UNIT AS A WHOLE.

- A. Check cover gasket for leaks and notify organizational maintenance if necessary.
- B. Be sure starter rope is not frayed or knotted. Notify organizational maintenance if it needs to be replaced.
- C. Check propeller for nicks and breaks. Replace if damaged (para 3-14).
- D. Check gearcase for cracks and leaks. Notify organizational maintenance.
- E. Check clamp screws to be sure they are tight enough.
- F. Check for frayed or broken wiring. Notify organizational maintenance.
- G. Check fuel pump, clean strainer. (See para 3-15, 3-16).
- H. Check spark plugs. (See para 3-10.)
 - I. Check exhaust housing for cracks, damage. Notify organizational maintenance.
 - J. Inspect stern brackets for cracks, bends or breaks. Notify organizational maintenance.

Section IV. STARTER MAINTENANCE

MAINTENANCE SUMMARY.

This task covers:

Removal/Installation of the rewind starter

INITIAL SETUP:

Personnel Required

1

General Safety Instructions

None

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Removal/installation of the starter	Para 3-9	See Removing/installing the motor cover, para 2-12. See Emergency starting, para 2-21.

3-9. REWIND STARTER REMOVAL/INSTALLATION

This task covers:

Removal/Installation of rewind starter

INITIAL SETUP :

Tools:
TI 5180-00-177-7033

Materials/Parts:
As required

Personnel Required
1 operator

Equipment Condition:
Motor OFF

Approximate Time Required (minutes):
15

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

REMOVAL

- | | | |
|------------------------------|--------|--|
| 1. Bolt (1) | Remove | |
| 2. Neutral lockout lever (2) | Remove | |
| 3. Spring (3) washer (4) | Remove | |
| 4. Screws (5) | Remove | |




Figure 3-1. Neutral lockout lever

- | | | |
|----------------|--------|--|
| 5. Starter (6) | Remove | |
|----------------|--------|--|

INSTALLATION

- | | |
|--|----------------------------------|
| 1. Starter (6) | Place in position on power head. |
| 2. Screws (5) | Install. |
| 3. Lockout lever (2) washer (4) spring (3) | Place in position. |
| 4. Bolt (1) | Install. |




Figure 3-2. Starter

Section V. SPARK PLUGS MAINTENANCE

MAINTENANCE SUMMARY

This task covers:

Servicing the spark plugs.

INITIAL SETUP:

Personnel Required

1

General Safety Instructions

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Spark plugs Removal/ installation.	Para 3-10	Be careful not to get debris in spark plug hole when spark plugs are removed.
2	Adjust spark plugs. (Set gap).	Para 3-11	

3-10. SPARK PLUG REMOVAL/INSTALLATION

This task covers:

Removal/Installation of spark plugs

INITIAL SETUP:

Tools:

13/16 in. deep socket

Torque wrench

TI 5180-00-177-7033

Material/Parts:

RL-82 Champion spark plugs (2)

Personnel Required:

1 operator

Equipment Condition:

Motor OFF

Approximate Time Required (minutes):

15

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

REMOVAL

- | | | |
|---|---------|---|
| 1. Rubber spark plug cover (1) and lead | Remove | Twist slightly counterclockwise and pull. |
| 2. Spark plugs (2) and ratchet. | Remove. | Use spark plug socket wrench 13/16" (21 mm) |

INSTALLATION

- | | | |
|-------------------------------------|--------|--|
| 1. Spark plug seat in cylinder head | Clean. | |
|-------------------------------------|--------|--|

NOTE

Do not get dirt in spark plug holes.




Figure 3-3. Spark plug and lead cover

- | | | |
|--|----------------------------------|--|
| 2. Spark plug and gasket | Install fingertight. | |
| 3. Spark plug (2) | Turn 1/4 turn more using wrench. | If torque wrench is available, tighten to a torque of 17-1/2 to 20-1/2 lb ft (24 to 27 N-m). |
| CAUTION | | |
| Do not overtighten. Damage may result to cylinder head. | | |
| 4. Spark plug covers (1) and lead | Install. | Be sure that spring clip in spark plug covers make firm contact with spark plug terminals. |

3-11. SPARK PLUG GAP

This task covers:

Setting spark plug gap.

INITIAL SETUP :

Tools:

Feeler gage
 Spark plug cleaning machine
 Clean fine bristle, fibre brush
 TI 5180-00-177-7033

Materials/Parts:

None

Equipment Condition:

Engine OFF
 Spark plugs removed. See para 3-10

Personnel Required:

1 operator

Approximate Time Required (minutes):

15

LOCATION/ITEM	ACTION	REMARKS
SET SPARK PLUG GAP		
1. Spark plugs	Clean.	Use a sand blasting machine if possible. If not available, use a clean, fine bristle fiber brush.
2. Spark plug gap	Set for 0.030" (0.76mm).	Use a feeler gage to check the gap. Gently tap to close or spread to widen gap.
3. Spark plugs	Install.	See para 3-10.

Section VI. STEERING HANDLE MAINTENANCE

MAINTENANCE SUMMARY

This task covers:

Inspecting and lubricating the steering handle.

INITIAL SETUP:

Personnel Required

1

General Safety Instructions

None

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Inspect steering handle	Para 3-12	
2	Lubricate steering handle	Para 3-12	See LO 5-2805-261-12

3-12. STEERING HANDLE MAINTENANCE

This task covers:

- a. Steering handle inspection
- b. Steering handle lubrication

INITIAL SETUP :

Tools:
Grease gun

Equipment Condition:
Motor OFF

Materials/Parts:
GAA grease
Clean lint-free rag

Personnel Required:
1 operator

Approximate Time Required (minutes):
15

LOCATION/ITEM	ACTION	REMARKS
<p>INSPECTION Steering handle</p>	Inspect.	<p>Check for cracked, broken or bent handle. Check to be sure handle can be folded up. Check gears at joint for correct alignment and function. Be sure gears at joint are properly lubricated.</p>
<p>LUBRICATION Fitting (1).</p>	Fasten grease gun	<p>Inject grease until new grease appears. Wipe off excess with clean, lint-free rag. See LO 5-2805-261-12</p>

Figure 3-4. Steering handle lubrication

Section VII. GEARCASE MAINTENANCE

MAINTENANCE SUMMARY

This task covers:

Inspection and lubrication of gearcase.

INITIAL SETUP:

Personnel Required

1

General Safety Instructions

None

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Inspect gearcase	Para 3-13	
2	Lubricate gearcase	Para 3-13	See LO 5-2805-261-12

3-13. GEARCASE INSPECTION AND LUBRICATION

This task covers:

Inspecting and lubricating gearcase

INITIAL SETUP:

Tools:
Gear oil

Equipment Condition:
Motor OFF

Materials/Parts:
GO MIL-L-2105
Clean, lint-free rag
Personnel Required:
1 operator

Approximate Time Required (minutes):
15

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

INSPECTION

1. Gearcase	Inspect.	Look for cracks, loose screws and leaks.
2. Oil level (1)	Remove plug.	Check to be sure lubricant is up to oil level.

LUBRICATION

1. Oil level plug (1)	Remove.
2. Drain/fill plug (2)	Remove.




Figure 3-5. Gearcase lubrication

Squeeze container, forcing lubricant into gearcase until lubricant appears at oil level. An empty gearcase will use approximately 14 oz (413 cc) of lubricant.

3. Lubricant container (3)	Insert tip in drain/fill plug.	
4. Lubricant container (3)	Remove.	When you remove the container, quickly install the drain/fill plug (2) or lubricant will leak out.
5. Oil level plug (1)	Install.	
6. Excess lubricant	Wipe off with clean, lint-free rag.	

Section VIII. PROPELLER MAINTENANCE

MAINTENANCE SUMMARY

This task covers:

- a. Propeller removal/installation b. Propeller drive pin removal/installation

INITIAL SETUP:

Personnel Required
1

General Safety Instructions
When replacing propeller, disconnect spark plug leads from spark plugs to avoid accidentally starting motor. Be sure shift lever is in neutral.

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Propeller removal/installation	Para 3-14	See spark plugs service, para 3-10, 3-11.
2	Propeller drive pin removal/installation	Para 3-14	Part of propeller removal/installation procedure.

3-14. PROPELLER REMOVAL/INSTALLATION

This task covers:

Removal/Installation of propeller. (Removal/installation of drive pin is part of this procedure.)

INITIAL SETUP:

Tools:
TI 5180-00-177-7033

Equipment Condition:
Motor OFF

Materials/Parts:
Replacement parts as required

Personnel Required:
1 operator

Approximate Time Required (minutes):
20

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Spark plugs	Remove spark plug covers and leads.	See spark plug service, para 3-10.
2. Cotter pin (1)	Remove.	
3. Propeller nut (2)	Remove.	
	NOTE Propeller nut is not threaded. Pull off, do not tu rn.	
4. Drive pin (3) and washer (4)	Remove.	
	NOTE Old drive pin can be driven out of shaft with new pin.	
5. Propeller (5)	Slide off shaft (6)	

- 1. Cotter Pin
- 2. Propeller Nut
- 3. Drive Pin
- 4. Thrust Washer
- 5. Propeller
- 6. Shaft




Figure 3-6. Propeller replacement

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

3-14. PROPELLER REMOVAL/INSTALLATION (Cont)

INSTALLATION

- | | | |
|--------------------------------|--|--|
| 1. Propeller (5) | Slide on to shaft (6). | |
| | Lubricate shaft with GAA grease before installing propeller. | |
| 2. Washer (4) | Install on shaft. | |
| 3. Drive pin (3) | Install. | |
| 4. Propeller nut (2) | Install. | |
| 5. Cotter pin (1) | Install. | Bend projecting ends of cotter pin. |
| 6. Spark plug covers and leads | Install. | See spark plug installation para 3-10. |

Section IX. FUEL SYSTEM MAINTENANCE

MAINTENANCE SUMMARY. This task covers:
 a. Fuel pump inspection
 b. Cleaning fuel strainers

INITIAL SETUP:

Personnel Required
 1

General Safety Instructions

To prevent excessive fuel spillage disconnect fuel tank line plug-in connector at motor before disassembly.

Gasoline is extremely flammable. Do not smoke or allow sparks while working on fuel system.

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Fuel pump inspection	Para 3-15	If fuel pump gasket or diaphragm is damaged notify organizational maintenance.
2	Clean fuel pump strainer	Para 3-15	Part of fuel pump inspection.
3	Clean auxiliary fuel strainer	Para 3-16	

3-15. FUEL PUMP MAINTENANCE

This task covers:

Inspecting fuel pump and cleaning fuel filter.

INITIAL SETUP:

Tools:
TI 5180-00-177-7033

Equipment Condition:
Motor OFF

Materials/Parts:
Cleaning solvent

Personnel Required:
1 operator

Approximate Time Required (minutes):
15

LOCATION/ITEM	ACTION	REMARKS
INSPECTION	<p>WARNING Gasoline is highly flammable. Do not smoke or use open flames or strike sparks while working on the fuel system.</p>	
DISASSEMBLY		<p>1. Screw 2. Cover 3. Fuel Pump 4. Filter 5. Gasket 6. Diaphragm</p>
1. Mounting screw (1)	Remove.	
2. Cover (2)	Remove from fuel pump (3).	
3. Filter (4)	Remove.	
4. Gasket (5) and diaphragm (6)	Inspect for damage.	

Figure 3-7. Fuel pump

LOCATION/ITEM	ACTION	REMARKS
3-15. FUEL PUMP MAINTENANCE -continued		
CLEANING FUEL FILTER	<p>WARNING Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid repeated and prolonged skin contact by wearing rubber or non-porous gloves when handling the solvent or material wet with drycleaning solvent. Wash hands immediately after exposure with soap and water and use a lanolin based skin cream to prevent skin drying. Do not use near open flame or excessive heat. Flash point of solvent is 100°F (38°C). Do not work with solvent in a closed room. Be sure there is good ventilation or the solvent vapors will build up in the air and become a poisonous mixture which can cause physical injury or even death.</p>	
Filter element (4)	Wash in suitable solvent using a soft bristle brush.	
ASSEMBLY		
1. Filter element (4)	Install in pump cover (2).	
2. Pump cover (2)	Position on pump body (3).	
3. Mounting screw (1)	Install.	
4. Fuel line	Connect.	Clean up any spilled fuel with a clean lint-free rag.
5. Fuel system	Prime.	Check for any leaks. Repeat procedure if fuel pump leaks.

3-16. AUXILIARY FILTER CLEANING

This task covers:

Cleaning auxiliary filter

INITIAL SETUP:

Tools:
TI 5180-00-177-7033

Equipment Condition:
Motor OFF

Materials/Parts:
Clean lint-free rag

Personnel Required:
1 operator

Approximate Time Required (minutes):
10

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

CLEANING AUXILIARY FILTER

DISASSEMBLY

- | | | |
|------------------------|------------------------------------|---|
| 1. Filter assembly (1) | Remove from retaining spring clip. | It is not necessary to remove hose and clamps from filter assy. |
| 2. Cap (2) | Unscrew from base (3). | |




Figure 3-8. Auxiliary filter (1 of 3)

CLEANING

- | | | |
|-----------------------|--------|-----------------------------|
| Trap (4) and base (3) | Clean. | Use a clean, lint-free rag. |
|-----------------------|--------|-----------------------------|

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

3-16. CLEANING AUXILIARY FILTER - continued

ASSEMBLY

- | | |
|-------------------------|-----------------------------------|
| 1. Cap (2) and trap (4) | Screw into base (3). |
| 2. Filter assembly (1) | Install in retaining spring clip. |




Figure 3-8. Auxiliary filter (2 of 3)




Figure 3-8. Auxiliary filter (3 of 3)

Section X. THROTTLE ADJUSTMENT

MAINTENANCE SUMMARY. This task covers:

The throttle adjustment:

- a. Idle speed
- b. Low speed (carburetor) adjustment

INITIAL SETUP

Personnel Required

1

General Safety Instructions

Gasoline is extremely flammable. Do not smoke or allow sparks while working on fuel system.

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Idle speed adjustment	Para 3-17	NOTE
2	Low speed adjustment	Para 3-17	There is no high speed adjustment.

3-17. THROTTLE ADJUSTMENT

This task covers:

- a. Idle speed adjustment
- b. Low speed adjustment

INITIAL SETUP:

Tools:
TI 5180-00-177-7033

Equipment Condition:
Follow procedure

Materials/Parts:
None

Personnel Required:
1 operator

Approximate Time Required (minutes):
20

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

WARNING
Be extremely careful working around engine with motor cover off. Hair, hands or clothing can become caught in moving parts or air intake.

IDLE SPEED
ADJUSTMENT

Adjustment knob (1)

- a. Turn clockwise to increase idle speed.
- b. Turn counterclockwise to decrease idle speed.




Figure 3-9. Idle speed adjustment

LOCATION/ITEM	ACTION	REMARKS
3-17. THROTTLE ADJUSTMENT - continued		
LOW SPEED ADJUSTMENT		
1. Motor	Stop.	
2. Motor cover	Remove.	See para 2-12
3. Low speed adjustment screw (1)	a. Turn clockwise until needle valve gently seats.	
	b. Turn counterclockwise 1-1/4 turns.	See para 2-8
4. Motor	Start.	
5. Throttle	Set on normal idle speed.	
6. Low speed adjustment screw (1)	Adjust until best performance is obtained.	
	a. Clockwise to lean out fuel mixture.	
	b. Counterclockwise to enrich fuel mixture.	
7. Motor	Stop.	See para 2-10.
8. Cover	Install.	See para 2-12.




Figure 3-10. Low speed adjustment

Section XI. SCREW ASSEMBLY CLAMP MAINTENANCE

MAINTENANCE SUMMARY. This task covers:

Inspection and removal/installation of the screw assembly clamp

INITIAL SETUP

Personnel Required

1

General Safety Instructions

Be sure motor is adequately supported before removing screw assembly clamp.

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Screw assembly clamp inspection	Para 3-18	None
2	Screw assembly clamp removal/ installation	Para 3-18	

3-28

3-18. INSPECTION/REMOVAL/INSTALLATION OF SCREW ASSEMBLY CLAMP

This task covers:

Screw assembly clamp inspection/removal/installation

INITIAL SETUP:

Tools:
T1 5180-00-177-7033

Equipment Condition:
Motor OFF

Materials/Parts:
As required

Personnel Required:
1 operator

Approximate Time Required (minutes):
30

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

INSPECTION

Screw assembly clamp (1)	Inspect.	Look for stripped threads, split or bent swivel plate, or broken handle.
--------------------------	----------	--

REMOVAL

- | | |
|-----------------------------|---|
| 1. Capscrew (1) | Remove. Swivel plate (2) will come off. |
| 2. Screw assembly clamp (3) | Turn out of stern bracket assembly. |




Figure 3-11. Screw clamp assembly

INSTALLATION

- | | | |
|-----------------------------|--|--|
| 1. Screw assembly clamp (3) | Screw into stern bracket. | |
| 2. Swivel plate (2) | Place over capscrew (1). | Be sure concave surface is toward transom. |
| 3. Capscrew (1) | Install tightly in screw assembly clamp. | |

3-29/(3-30 blank)

CHAPTER 4

ORGANIZATIONAL MAINTENANCE INSTRUCTIONS

4-1. CHAPTER OVERVIEW. This chapter contains maintenance procedures for organizational maintenance personnel.

Section I. REPAIR PARTS, SPECIAL TOOLS, TMDE AND SUPPORT EQUIPMENT

4-2. COMMON TOOLS AND EQUIPMENT. For authorized common tools and equipment refer to the Modified Table of Organization and Equipment (MTOE) applicable to your unit.

4-4. SPARES AND REPAIR PARTS. Spares and repair parts are listed and illustrated in the repair parts and special tools list covering organizational and DS maintenance for this equipment (TM 5-2805-261-23P).

4-3. SPECIAL TOOLS. See appendix C for special tools.

Section II. SERVICE UPON RECEIPT

4-5. ASSEMBLY AND PREPARATION FOR USE.

A. UNLOADING.

1. Remove all tiedowns or blocking that secure the crate to the carrier.

WARNING

Make certain any lifting device used has a capacity equal to or greater than the weight being lifted. Failure to observe this precaution could result in injury or death to personnel and damage to equipment.

2. A forklift truck, pipe rollers, or a suitable hoist must be used when removing the motor from the carrier.

B. UNPACKING.

1. Place the outboard motor as close to the point of use as possible.
2. Prepare the motor for inspection and servicing as outlined on DA Form 2258, Depreservation Guide.
3. Remove the motor from the crate.

C. INSPECTION.

1. Make a complete visual inspection of the outboard motor for any loss or damage that may have occurred during shipment. If shipping crate has been damaged, pay particular attention to the motor areas adjacent to damage areas of the crate.




Figure 4-1. Crate and carrier

2. Inspect the motor for cracks, breaks and other defects.
3. Check the contents of the crate against the packing list to make sure no items are missing.
4. Correct all deficiencies or report them to the proper authority.

4-6. LUBRICATION. Check all lubrication points (see LO 52805-261-12) to be certain the outboard motor is properly lubricated.

Section III. PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)

4-7. INTRODUCTION. The preventive maintenance checks and services listed in the PMCS table 4-1 cover procedures to be performed by organizational maintenance personnel.

4-8. PMCS TABLE. Explanation of the columns:

- Item Number. Checks and services are numbered in sequence. This column shall be used as source of item numbers for the TM Number Column on DA Form 2404, Equipment Inspection and Maintenance Worksheet, in recording results of PMCS.
- Item To Be Inspected. This column gives the name of the item to be inspected or serviced.
- Procedures. This column lists inspection procedures.
- Equipment Will Be Reported Not Ready/Available If: This column contains the criteria which will cause the equipment to be classified as not ready or not available because of inability to perform its primary mission.

Table 4-1. Preventive Maintenance Checks and Services

Legend

W - Weekly

M - Monthly

Q - Quarterly

Item No.	INTERVAL			Item To Be Inspected	Procedures	Equipment Will Be Reported Not Ready/ Available If:
	W	M	Q			
1			•	Magneto, flywheel assembly	Inspect (para 4-16, 4-17).	Damaged.
2		•		Ignition coil	Test (para 4-11).	Failed.
3			•	Condenser	Test (para 4-11).	Failed.
4			•	Shorting switch assembly	Inspect (para 4-23).	Failed.
5		•		Spark plugs	Inspect (para 3-10).	Need replacement.
6		•		Breaker points	Inspect (para 4-11).	Need replacement.
7		•		Propeller drive pin	Inspect (para 3-14).	Need replacement.
8		•		Fuel tank	Inspect (para 4-24).	Leaks or cracks.
9			•	Carburetor needle valves	Inspect (para 4-27).	Need replacement.
10			•	Intake manifold	Inspect (para 4-29).	Manifold is damaged or gasket leaks.
11			•	Cylinder and crankcase assembly	Inspect (para 4-30).	Assembly is damaged.
12			•	Cylinder head	Inspect (para 4-30).	Cylinder head is damaged.
13		•		Steering bracket	Inspect (para 4-32).	Steering bracket is damaged.
14		•		Water pump	Inspect (para 4-36).	Engine runs hot.
15	•			Water inlet screen	Inspect (para 4-37).	Screen is damaged.

Section IV. TROUBLESHOOTING

4-9. GENERAL. This section contains troubleshooting procedures to be performed by organizational maintenance personnel.

The tests are grouped by what system they belong to. (The fuel system tests are with the fuel system.) Within each group the tests are arranged so that the easier tests come before the harder tests.

4-10. TROUBLESHOOTING CHART.

- A. MALFUNCTION. Malfunctions listed are the ones most likely to happen. Not all possible malfunctions can be foreseen and listed.
- B. TEST OR INSPECTION. Tests or inspections are listed to help you find the cause of the malfunction.

- C. CORRECTIVE ACTION. Corrective actions are listed to help you eliminate the malfunction. Where the corrective action is too complicated to be listed in full detail, the paragraph number of the detailed procedure is given in parentheses.

Table 4-2. Troubleshooting

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

MANUAL STARTER

1. STARTER DOES NOT ENGAGE FLYWHEEL WHEN TRYING TO START MOTOR.

Check for broken pawl.

Replace pawl (para 4-15).

IGNITION SYSTEM

2. IGNITION SYSTEM MALFUNCTIONING.

Step 1. Check ignition system (para 4-11).

Replace components as necessary.

FUEL SYSTEM

3. FUEL SYSTEM MALFUNCTIONING.

Step 1. Check fuel delivery (para 4-24).

a. Disconnect fuel hose at motor. Squeeze primer bulb until definite pressure is felt. Check hose for leaks. Replace if necessary (para 4-25).

b. Connect fuel hose at motor. Squeeze primer bulb until definite pressure is felt. Inspect for leaks at hoses, filter, fuel pump, and carburetor. Repair as necessary (para 4-24 thru 4-29).

c. If you cannot get a definite pressure on the primer bulb, and there is no leakage elsewhere, replace the primer bulb valve (para 4-25).

Step 2. Inspect carburetor throat for flooding (squeeze primer bulb and observe carburetor throat.)

Service carburetor (para 4-27).

Step 3. Test fuel pump.

Connect fuel pump gage to discharge side of fuel pump. Crank engine and observe gage. Gage should read a minimum pressure of 2.5 psi (17 kPa).

Replace fuel pump (para 4-26).

Table 4-2. Troubleshooting - continued

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
COOLING SYSTEM		
4. ENGINE OVERHEATS. (See Engine Temperature Test, para 4-38).	Inspect water pump.	Replace if necessary (para 4-36).
GEARCASE		
5. GEARCASE JUMPS OUT OF GEAR.	Inspect gearcase components.	Notify direct support.
6. GEAR SHIFT WON'T SHIFT.	Step 1. Check pivot pin missing or damaged.	Notify direct support.
	Step 2. Check shift rod adjustment.	Notify direct support.
	Step 3. Check shift rod connection.	Repair as necessary (para 4-34).
	Step 4. Inspect gearcase components.	Notify direct support.
7. GEARCASE SEIZED.	Step 1. Check for lubricant.	a. Lubricate per LO 5-2805-261-12.
		b. Notify direct support.

4-11. ELECTRICAL TROUBLESHOOTING/TESTING. To use this Troubleshooting section: read the question for each step. If the answer to question is yes, go to step number shown under "YES"; if answer is no, go to step number shown under "NO".


STEP	QUESTION/INSTRUCTION	ANSWER		REMARKS
		YES	NO	

IGNITION SYSTEM

1	Remove spark plug leads.			See para 3-10.
	Attach leads to spark plug gap test and set gap to 0.43 in. (11 mm). Crank engine with rope.			See fig. 4-2.

NOTE

Remove spark plugs for easier cranking. See para 3-10.




- 1. Drive Coil
- 2. Magnet No. 1
- 3. Point No. 1
- 4. Primary
- 5. Coil No. 1
- 6. Coil No. 2
- 7. Condenser
- 8. Point No. 2
- 9. Driver Coil
- 10. Point No. 1
- 11. Secondary
- 12. Magnet No. 2
- 13. Point No. 2
- 14. 0.43 in. (11 mm) Gap

Figure 4-2. Ignition spark test

	Is spark strong and steady and firing for each cylinder?	2	3	
2	Replace spark plugs.			See para 3-10.

ELECTRICAL TROUBLESHOOTING/TESTING - continued

STEP	QUESTION/INSTRUCTION	ANSWER		REMARKS
		YES	NO	
3	If no spark, check system with Stevens S-80 or Merc-o-Tronic neon light test. Disconnect blue primary lead of No. 1 ignition coil. Connect blue lead of neon tester to blue primary lead coming from armature plate. Connect black lead to ground.			See fig. 4-3.



- 1. Drive Coil
- 2. Magnet No. 1
- 3. Point No. 1
- 4. Coil No. 1
- 5. Coil No. 2
- 6. Condenser
- 7. Point No. 2
- 8. Driver Coil
- 9. Point No. 1
- 10. Magnet No. 2
- 11. Point No. 2
- 12. Blue
- 13. Black


Figure 4-3. Ignition coil no. 1 circuit test

Set neon test light switch to position No. 1. Crank engine.

	Is output good (light steady and bright)?	4	5	
	Is light dim?	5	4	
4	Replace No. 1 ignition coil.			See para 4-16.
5	Replace No. 1 condenser.			See para 4-16.
	No light?	6		
6	Check resistance reading of driver coil. Check both sets of breaker points for correct gap and condition of points.			See para 4-16.

ELECTRICAL TROUBLESHOOTING/TESTING - continued

STEP	QUESTION/INSTRUCTION	ANSWER		REMARKS
		YES	NO	
7	Connect blue primary lead of No. 1 ignition coil. Disconnect No. 2 ignition coil (blue/white stripe lead) coming from armature plate. Connect blue lead of neon tester to blue/white stripe lead from armature plate. Connect black lead to ground.			See fig. 4-4.



- 1. Driver Coil
- 2. Magnet No. 1
- 3. Point No. 1
- 4. Coil No. 1
- 5. Coil No. 2
- 6. Condenser
- 7. Point No. 2
- 8. Driver Coil
- 9. Point No. 1
- 10. Magnet No. 2
- 11. Point No. 2
- 12. Blue
- 13. Black
- 14. Blue/White

Figure 4-4. Ignition coil no. 2 circuit test

Set neon test light switch to position No. 1. Crank engine.

	Is output good (light steady and bright)?	8	9	
	Is light dim?	9	8	
8	Replace No. 2 ignition coil.			
9	Replace No. 1 condenser.			
	No light?	10	-	
10	Check resistance reading of driver coil. Check both sets of breaker points for correct gap and condition of points.			See para 4-16.

4-12. WIRE TESTING WITH MULTIMETER.

NOTE

The ohms scale is used for continuity and short circuit testing.

NOTE

Set up and zero the multimeter before each test and before testing each wire.

CAUTION

Always disconnect the circuit being tested. Failure to do this can damage the multimeter.

4-13. TESTING FOR CONTINUITY.

- A. Connect meter probes to both terminals of the circuit being tested.
- B. Watch needle movement.
 - 1. The circuit has continuity if the needle swings to the far right, over the 0 on the top scale.

- 2. The circuit is open (broken) if the needle doesn't move.
- 3. There is a loose connection in the circuit being tested if the needle jumps or flickers.

- C. Replace or repair the circuit if you see "2" or "3" above.

4-14. TESTING FOR SHORT CIRCUITS.

- A. Connect one probe to one circuit and the other probe to the other circuit, or ground.
- B. Watch needle movement.
 - 1. The circuits are short circuited if the needle swings to the far right over the 0 on the top scale.
 - 2. The circuits are intermittently short circuited if the needle jumps or flickers.
 - 3. The circuits are not short circuited if the needle doesn't move.
- C. Replace or repair the circuit if you see "1" or "2", above.

Section V. MANUAL STARTER MAINTENANCE

MAINTENANCE SUMMARY. This task covers:

Disassembly/assembly of the starter rewind

INITIAL SETUP

Personnel Required

1

General Safety Instructions

Safety glasses must be worn during this task because of tension in rewind spring.

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Disassembly/assembly of starter rewind	Para 4-15	
2	Cleaning and inspection	Para 4-15	

4-15. MANUAL STARTER DISASSEMBLY/CLEANING/INSPECTION/REASSEMBLY

This task covers:

Disassembly/cleaning/inspection/reassembly of manual starter .

INITIAL SETUP:

Tools:

- T1 5180-00-177-7033
- T2 4910-00-754-0705
- T4 Rope starter - 378774
- T5 Spring winder - 392093

Equipment Condition:

Motor OFF

Materials/Parts:

As required

Personnel Required:

1 Mechanic

Approximate Time Required (minutes):

180

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

WARNING

Safety glasses must be worn during this procedure because of danger to eyes from the rewind spring.

DISASSEMBLY

1. Starter	Remove.	See para 3-9.
2. Screw (1)	Remove.	
3. Pawl (2) and retainer (3)	Remove.	
4. Starter rope (4)	Pull to end of travel and tie a slip knot 1 foot from end. Release slowly.	
5. Starter rope (4)	Release slowly.	
6. Rope anchor (5)	Pry out of handle (6).	
7. Handle (6)	Remove.	
8. Starter rope (4)	Release knot in rope.	
9. Starter pulley (7)	Ease back until spring (8) is fully unwound.	
10. Nut (9)	Remove.	
11. Capscrew (10) and washer (11)	Remove from spindle (12).	
12. Bushing (13), friction ring (14), and spring washer (15)	Remove.	
13. Starter (16)	Turn over, legs down.	
14. Pulley (7)	Lift off.	
15. Rope (4)	Remove from pulley (7).	




Figure 4-5. Rope anchor

Move your fingers out of way and jar starter against bench top. Pulley (7) and spring (8) will dislodge.

If replacing only rope, no further disassembly is required.




Figure 4-6. Starter rewind assembly
 4-10

LOCATION/ITEM	ACTION	REMARKS
4-15. MANUAL STARTER DISASSEMBLY/CLEANING/INSPECTION/REASSEMBLY	- continued	
	WARNING	
	<p>Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid repeated and prolonged skin contact by wearing rubber or nonporous gloves when handling the solvent or material wet with drycleaning solvent. Wash hands immediately after exposure with soap and water and use a lanolin based skin cream to prevent skin drying. Do not use near open flame or excessive heat. Flash point of solvent is 100°F (38°C). Do not work with solvent in a closed room. Be sure there is good ventilation or the solvent vapors will build up in the air and become a poisonous mixture which can cause physical injury or even death.</p>	
CLEANING AND INSPECTION		
1. Components	Wash in solvent and dry with lint-free rags.	
2. Spring (8)	Inspect for broken end loops and weak tension.	
3. Pawl (2)	Check for wear.	
4. Rope (4)	Replace if frayed.	
5. Pulley (7) and housing (17)	Examine for sharp edges and rough surfaces.	File and polish smooth.
6. Components	Replace any components that are worn or broken.	
REASSEMBLY		
1. Spring winder (392093)	Position base tightly in vise.	

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

4-15. MANUAL STARTER DISASSEMBLY/INSPECTION/CLEANING/ASSEMBLY - continued

- | | | |
|------------------------|---|--|
| 2. Cup | Place inside spring winder base. | |
| 3. Spring (8) | Place spring as shown with inside loop in cup. | |
| 4. Crank | Place on winder engaging crank pin in inside loop of spring. | |
| 5. Bolt | Install in spring winder as shown. | |
| 6. Crank | Wind clockwise until all of spring except outside loop is inside cup. | |
| 7. Bolt | Remove. | |
| 8. Crank | Lift off carefully without dislodging spring. | |
| 9. Cup and spring (8) | Lift out of spring winder holding spring in place. | |
| 10. Cup and spring (8) | Place open side down over spring opening in starter housing. Locate outside loop directly over pin in housing and engage slightly onto pin. | |
| 11. Spring (8) | Press into housing through two openings in cup. | |
| 12. Cup | Remove. | |
| 13. Pulley (7) | Install in housing engaging pin with inside loop of spring. | |




Figure 4-7. Spring winder




Figure 4-8. Spring cup




Figure 4-9. Pulley and housing

LOCATION/ITEM	ACTION	REMARKS
4-15. MANUAL STARTER DISASSEMBLY/CLEANING/INSPECTION/REASSEMBLY - continued		

NOTE

Lubricate spindle with GAA grease before installation.

CAUTION

Be sure cup side of friction ring (14) faces flange on spindle (12). Flat side of friction ring must align with flat on spindle. Ribs in bushing (13) must engage corresponding slots in spindle.

14. Spindle (12) Assemble with spring washer (15), friction ring (14), and spindle bushing (13).

15. Spindle assembly Insert into pulley (7).

NOTE

Pulley may have to be moved slightly so spindle can drop over boss in housing.

16. Screw (10) and washer (11) Install in spindle (12).

17. Nut (9) Install.

After installing nut, be sure pulley does not bind.

18. Grommet (18) Install in starter housing (17).

19. Pulley (7) Turn counterclockwise until tight then back off until rope knot recess in pulley aligns with rope opening in housing. Place punch in hole in pulley to hold assembly in position. Punch will engage rib in housing and hold pulley in place. Do not jar assembly.

20. New rope Cut a length 6 feet (1.84 meters) of NSN-4020-01-011-0665 and fuse at each end with a flame.

NOTE

Ends of rope must be fused to a length of 1/2 inch (13mm).




Figure 4-10. View of assembled starter

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


4-15. MANUAL STARTER DISASSEMBLY/CLEANING/INSPECTION/REASSEMBLY -continued

21. Rope (4)
 Tie knot in one end of rope.
 Thread other end of rope into pulley and out housing opening through grommet (18). Tie slip knot in rope near grommet end. Hold rope, remove punch and ease rope in until knot contacts grommet.

22. Rope (4)
 Thread through grommet and handle (6).

Use starter rope threading tool, 378774.

23. Rope (4)
 Insert in channel in rope anchor (5).




24. Rope anchor (5)
 Insert in handle (6).

Figure 4-11. Threading the handle

25. Rope (4)
 Remove knot.

26. Starter pawl (2) and retainer (3)
 Place in position on pulley.



27. Capscrew (1)
 Install.

Figure 4-12. View of rope anchor

28. Pawl (2)
 Check operation.

Pawl should extend when rope is pulled out and retract when rope is released.

LOCATION/ITEM	ACTION	REMARKS
4-15. MANUAL STARTER DISASSEMBLY/CLEAING/INSPECTION/REASSEMBLY- continued		

29. Starter Install on powerhead. See para 3-9.

30. Starter Operate a few times and then
check timing marks.

NOTE

**When starter is properly
timed an arrow on the hous-
ing will aline within the limits
of a box marked on the
pulley.**

NOTE

**A new rope, because it is
stiff, may cause timing marks
to misaline slightly. This con-
dition will normally be cor-
rected by using the starter a
few times.**

Section VI. ARMATURE PLATE MAINTENANCE (MAGNETO ASSEMBLY)

MAINTENANCE SUMMARY. This task covers:

- a. Removal/disassembly/assembly/installation of armature plate (magneto assembly).
- b. Removal/installation of flywheel.

INITIAL SETUP

Personnel Required
1

General Safety Instructions

NO.	TASK	TASK SUMMARY REFERENCE	REMARKS
1	Armature plate removal/ disassembly/assembly and installation	Para 4-16	There is no need to remove armature plate unless you are replacing leads or other components. Breaker points, condensers, and coils can be checked and replaced without removal of armature plate. (See para 4-18, 19, 20.)
2	Flywheel removal/installation	Para 4-17	

4-16. ARMATURE PLATE REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION

This task covers:

Removal/disassembly/assembly/installation of armature plate

INITIAL SETUP:

Tools:
T1 5180-00-177-7033

Equipment Condition:
Motor OFF

Materials/Parts:
As required

Personnel Required:
1 Mechanic

Approximate Time Required (minutes):
160

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Starter	Remove.	See para 3-9.
2. Spark plug leads	Remove.	See para 3-10.
3. Flywheel	Remove.	See para 4-17.
4. Armature plate leads	Tag and disconnect by disconnecting the packard connector (1).	Lift up on tabs and slide connector apart.
5. Ground wire (2)	Tag and disconnect from by pass cover screw (3).	
6. Screw (4) clamping leads to arm on support plate (5)	Remove.	
7. Spring connecting cam and link assembly to control lever	Remove.	

NOTE

Don't lose washer and sleeve on control lever pin.

4-16. ARMATURE PLATE REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continued

- 1. Connector housing
- 2. Ground lead
- 3. Screw
- 4. Screw
- 5. Support plate
- 6. Ignition coil assembly
- 7. Screw, philips head
- 8. Armature plate
- 9. Retainer plate
- 10. Armature plate assembly
- 11. Support screw
- 12. Bearing
- 13. Coil and lamination
- 14. Condenser
- 15. Breaker assembly
- 16. Wick




Figure 4-13. Armature plate
4-18

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

4-16. ARMATURE PLATE REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continued

DISASSEMBLY

1. Ignition coils (6) Remove.

NOTE

Ignition coils and leads are removed as an assembly.

2. Five screws (7) attaching armature plate (8) to retainer plate (9) Remove.

3. Armature plate assembly (10) Remove.

4. Four screws (11) holding retainer plate (9) to support plate (5) Remove.

5. Support plate and retainer Remove.

6. Bearing (12) (9). Remove from retainer plate

7. Coil and laminations (13) Remove from armature plate (10).

8. Condenser (14) Remove.

9. Breaker assembly (15) Remove.

10. Oiler wick (16) Replace. Oiler wick must be replaced with new wick.

ASSEMBLY

1. Oiler wick (16) Install in breaker assembly (15).

2. Breaker assembly (15) Install.

3. Condenser (14) Install in armature plate.

LOCATION/ITEM	ACTION	REMARKS
4-16. ARMATURE PLATE REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continued		
4. Coil and laminations (13)	Installation on armature plate.	
5. Bearing (12)	Install on retainer plate (9).	Lubricate bearing with GAA grease before installation.
6. Retainer plate (9)	Attach to support plate (5).	
7. Retainer plate (9) and support plate (5)	Attach to crankcase with four screws (11).	Tighten four screws (11) to a torque of 8-10 lb ft (11-14 N.m).
8. Bearing (12)	Place on retainer plate.	
9. Armature plate (8)	Place in position over crankshaft, retainer plate, and bearing.	Be careful not to damage breaker arms.
10. Bearing (12)	Use a needle-nose pliers and compress the bearing.	
11. Armature plate	Locate over bearing.	
12. Armature plate	Aline armature plate holes with holes in support plate.	
13. Screws (7)	Install.	Tighten screws to a torque of 8-10 lb ft (11-14 N.m).
INSTALLATION		
1. Ignition coils (6)	Install.	
2. Spring connecting cam and link assembly to control lever	Install.	

LOCATION/ITEM	ACTION	REMARKS
4-16. ARMATURE PLATE REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continued		
3. Screws (4) clamping leads to arm on support plate (5)	Install.	
4. Ground wire (2)	Connect to by-pass cover screw (3).	
5. Armature plate lead	Connect, using packard connectors (1).	
6. Flywheel	Install.	See para 4-17.
7. Spark plug leads	Install.	See para 3-10.
8. Starter	Install.	See para 3-9.
9. Breaker point adjustment	Check.	See para 4-21.

4-17. FLYWHEEL REMOVAL/INSTALLATION

This task covers:

Removal/installation of flywheel.

INITIAL SETUP:

Tools:
 Universal puller
 T1 5180-00-177-7033

Equipment Condition:
 Motor OFF

Materials/Parts:

 As required
 Clean, lint free rag

Personnel Required:
 1 Mechanic

Approximate Time Required (minutes):
 45

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

CAUTION

Do not let cleaning solvent wash oil out of breaker point oiler wick.

REMOVAL

1. Starter Remove. (See para 3-9.)

NOTE

Use a strap wrench to hold the flywheel (4) in place.

2. Flywheel nut (1) Remove.

3. Capscrews (2) Remove.

4. Ratchet (3) Remove.

WARNING

You must wear safety glasses when using the hammer. A chip from the hammer could strike an eye.




Figure 4-14. Flywheel

LOCATION/ITEM	ACTION	REMARKS
4-17. FLYWHEEL REMOVAL/INSTALLATION - continued		

5. Flywheel (4)

Remove.

NOTE

Use a universal puller to remove flywheel. Install capscrews in holes for capscrews (2). Apply tension and pop flywheel loose by hitting center of pressing screw with a brass hammer.

WARNING

Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid repeated and prolonged skin contact by wearing rubber or non-porous gloves when handling the solvent or material wet with drycleaning solvent. Wash hands immediately after exposure with soap and water and use a lanolin based skin cream to prevent skin drying. Do not use near open flame or excessive heat. Flash point of solvent is 100°F (38°C). Do not work with solvent in a closed room. Be sure there is good ventilation or the solvent vapors will build up in the air and become a poisonous mixture which can cause physical injury or even death.

1. Crankshaft and flywheel

Clean tapers.

2. Ratchet (3)

Install on flywheel with capscrews (2).

3. Flywheel (4)

Place in position on crankshaft.

4. Flywheel nut (1)

Install and tighten to torque of 100-105 lb ft (135-140 N.m).

Use strap wrench to hold flywheel in place.

Do not let solvent wash oil out of breaker point oiler wick.

CAUTION

A loose flywheel nut will cause damage to the crankshaft.

Section VII. IGNITION SYSTEM MAINTENANCE

MAINTENANCE SUMMARY. This task covers:

- a. Ignition coil removal/installation
- b. Condenser removal/installation
- c. Breaker points removal/installation
- d. Breaker points adjustment
- e. Motor stop (shorting) switch removal/installation.
- f. Motor stop switch test

INITIAL SETUP

Personnel Required	General Safety Instructions
1	None

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Ignition coil removal/ installation	Para 4-18	Breaker points can become worn or corroded. Questionable breaker assemblies should be replaced.
2	Condenser removal/ installation	Para 4-19	Breaker point contacts must be kept clean from dirt and oil.
3	Breaker points removal/	Para 4-20	Clean breaker points with a strip of heavy paper or clean cloth.
4	Breaker points adjustment	Para 4-21	
5	Motor stop (shorting) switch removal/installation	Para 4-22	
6	Motor stop switch test	Para 4-23	

4-18. IGNITION COILS REMOVAL/INSTALLATION

This task covers:

Removal/installation of ignition coils

INITIAL SETUP:

Tools:
 Tools:
 T1 5180-00-177-7033

Equipment Condition:
 Motor OFF

Materials/Parts:
 As required


Personnel Required:
 1 Mechanic

Approximate Time Required (minutes):
 45

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

REMOVAL

- | | | |
|----------------------------------|--------------------------------|----------------|
| 1. Spark plug cover (1) | Remove from spark plug. | See para 3-10. |
| 2. Lead (2) | Disconnect from connector (3). | |
| 3. Capscrews (4) and washers (5) | Remove. | |
| 4. Coil (6) | Remove. | |



INSTALLATION

- | | | |
|----------------------------------|---------------------------|----------------|
| 1. Coil (6) | Place in position. | |
| 2. Capscrews (4) and washers (5) | Install. | |
| 3. Lead (2) | Connect to connector (3). | |
| 4. Spark plug cover (1) | Install. | See para 3-10. |

Figure 4-15. Ignition coil

4-19. CONDENSERS REMOVAL/INSTALLATION

This task covers:

Removal/installation of condensers.

INITIAL SETUP:

Tools:
 Universal puller
 TI 5180-00-177-7033

Equipment Condition:
 Motor OFF

Materials/Parts:
 As required

Personnel Required:
 1 Mechanic

Approximate Time Required (minutes):
 180

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

REMOVAL

1. Starter	Remove.	See para 3-9.
2. Flywheel	Remove.	See para 4-17.
3. Capscrew (1) and washer (2)	Remove from lead.	
4. Fastening capscrew (3)	Remove.	
5. Condenser (4)	Remove.	

INSTALLATION

1. Condenser (4)	Hold in position and install fastening capscrew (3).	
2. Lead	Fasten with capscrew (1) and washer (2).	
3. Flywheel	Install.	See para 4-17.
4. Starter	Install.	See para 3-9.




Figure 4-16. Condenser

4-20. BREAKER POINTS REMOVAL/INSTALLATION

This task covers:

Removal/installation of breaker points.

INITIAL SETUP:

Tools:
T1 5180-00-177-7033


Equipment Condition:
Motor OFF

Materials/Parts:
As required

Personnel Required:
1 Mechanic

Approximate Time Required (minutes):
180

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Starter	Remove.	See para 3-9.
2. Flywheel	Remove.	See para 4-17.
3. Fastening capscrew (1)	Remove.	
4. Breaker (2)	Remove.	
	NOTE	
	If breaker assembly is replaced, oiler wick must be replaced.	
5. Oiler wick (3)	Remove.	
INSTALLATION		
1. Oiler wick (3)	Install in breaker (2).	
2. Breaker (2)	Place in position.	
3. Fastening capscrew (1)	Install.	
4. Breaker points (3)	Adjust.	See para 4-21.
5. Flywheel	Install.	See para 4-17.
6. Starter	Install.	See para 3-9.



4-21. BREAKER POINT ADJUSTMENT

This task covers:

Adjustment of breaker points.

INITIAL SETUP:


Tools:
 Timing light-CD-85
 Feeler gage
 Timing fixture-386635

Equipment Condition:
 per procedure

Materials/Parts:
 None

Personnel Required:
 1 Mechanic

Approximate Time Required (minutes):
 30

LOCATION/ITEM	ACTION	REMARKS
1. Starter	Remove.	See para 3-9.
2. Flywheel	Remove.	See para 4-17.
3. Ignition coils	Remove.	See para 4-18.
4. Breaker point assemblies	Disconnect all leads.	Connect meter or test light between breaker plate and no. 1 breaker point screw terminal.
5. Timing fixture	Place on crankshaft.	Rotate crankshaft so side of fixture marked "T" is aligned with first timing mark on armature plate.
<p>NOTE Rotate crankshaft only in clockwise direction.</p>		
		
<p>Figure 4-17. Timing the engine</p>		
6. Timing fixture	Move slowly until light comes on.	The light will come on at the exact instant the breaker points open. The points should break open when timing fixture is midway between the two timing marks on the armature plate.

LOCATION/ITEM	ACTION	REMARKS
4-21. BREAKER POINT ADJUSTMENT - continued		

6. Timing fixture (cont.)		<p>If timing is not correct align timing fixture with first mark. Adjust points until light comes on (indicates an open circuit).</p> <p>If new breaker point assemblies were installed adjust so that points will open at first timing mark.</p>
---------------------------	--	---

7. Timing	Recheck as described in 5 and 6.	
-----------	----------------------------------	--

ALTERNATE METHOD

1. Feeler gage	Use to adjust breaker point gap.	<p>Use feeler gage if timing light is not available.</p> <p>Set gap to 0.020 in.(0.51mm) with breaker arm rubbing the block on the "set" mark of the cam (full open).</p> <p>If new points are used, set for 0.022 in. (0.56mm) to allow for seating of the fibre breaker block.</p>
----------------	----------------------------------	--

2. Crankshaft	Rotate 1800 and set points of second breaker assembly by same method.	
---------------	---	--




Figure 4-18. Breaker point adjustment

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

4-21. BREAKER POINT ADJUSTMENT - continued

	Finish either of two methods by:	
1. Ignition coils	Install.	See para 4-18.
2. Flywheel	Install.	See para 4-17.
3. Starter	Install.	See para 3-9.
4. Throttle	Check adjustment.	See para 3-17.
5. Engine	Start.	See para 2-8.
6. Timing	Check with timing light.	<p>If the breaker point settings are correct, the flywheel timing mark will line up between the two timing marks on the armature plate.</p> <p>Connect the timing light to each spark plug lead and run motor at low idle for this test.</p>




Figure 4-19. Timing marks

4-22. MOTOR STOP (SHORTING) SWITCH REMOVAL/INSTALLATION

This task covers:

Removal/installation of motor stop switch.

INITIAL SETUP:

Tools:
T1 5180-00-177-7033

Equipment Condition:
Motor OFF

Materials/Parts:
As required

Personnel Required:
One Mechanic

Approximate Time Required (minutes):
30

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

REMOVAL

- | | | |
|----------------------------|---|---|
| 1. Connectors (1) | Tag and disconnect. | Depress connector clips and pull out terminals (2). |
| 2. Capscrews and clamp (3) | Remove. | |
| 3. Stop switch (4) | Pull through hole in engine lower cover and remove. | |
| 4. Mounting ring (5) | Remove. | |




Figure 4-20. Motor stop (shorting) switch

INSTALLATION

- | | |
|----------------------------|---|
| 1. Terminals (2) and wires | Insert through hole and put switch (4) in position. |
| 2. Mounting ring (5) | Place in position. |
| 3. Capscrews and clamp (3) | Install on switch (4). |
| 4. Terminals (2) | Install in proper connectors (1). |

4-23. TEST STOP (SHORTING) SWITCH

This task covers:

Testing the stop switch.

INITIAL SETUP:

Tools:
Multimeter

Equipment Condition:
Motor OFF

Materials/Parts:
None

Personnel Required:
1 Mechanic

Approximate Time Required (minutes):
20

LOCATION/ITEM	ACTION	REMARKS
1. Multimeter	Set up and zero.	Follow manufacturers' directions on multimeter.
TEST FOR CONTINUITY		
1. Terminals	Disconnect.	See para 4-22.
2. Meter probes	Attach one to each end of wire.	Follow test directions as outlined in para 4-13.
3. Terminals	Replace if necessary.	
TEST FOR SHORT CIRCUIT		
1. Terminals	Disconnect.	See para 4-22.
2. Meter probes	Attach one to one terminal and one to the other terminal.	Follow test directions as outlined in para 4-14. In addition, test switch with button in two positions: a. Depressed. b. Not depressed.
3. Switch	Replace if necessary.	See para 4-22.

Section VIII. FUEL SYSTEM MAINTENANCE

MAINTENANCE SUMMARY. This task covers:

- a. Fuel tank inspection
- b. Fuel tank pressure test
- c. Fuel tank disassembly/assembly

INITIAL SETUP

Personnel Required	General Safety Instructions
1	Do not make or cause sparks while working on any part of the fuel system. Gasoline and fumes are extremely flammable. Carelessness can result in injury to personnel.

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Fuel tank inspection	Para 4-24	
2	Fuel tank pressure test	Para 4-24	
3	Fuel tank disassembly/assembly	Para 4-25	
4	Fuel pump removal/installation	Para 4-26	
5	Carburetor inspection/ cleaning. (Needle valve removal, inspection)	Para 4-27	
6	Carburetor removal/installation	Para 4-28	
7	Intake manifold inspection	Para 4-29	

4-24. FUEL TANK INSPECTION/TEST

This task covers:

Fuel tank inspection and pressure testing.

INITIAL SETUP:

Tools:
 T11 Pressure tester - S34
 T12 Adapter - 389945
 Syringe

Equipment Condition:
 Fuel tank drained

Materials/Parts:
 Tank of water

Personnel Required:
 1 Mechanic

Approximate Time Required (minutes):
 45

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

INSPECTION

Fuel tank and hoses	Inspect for leaks.	If leaks are suspected, pressure test tank and hose assembly.
---------------------	--------------------	---

PRESSURE TEST

- | | | |
|------------------|---------|---|
| 1. Fuel cap (1) | Remove. | Disengage cap anchor and completely remove cap from tank. |
| 2. Fuel tank (2) | Empty. | Fuel tank must be emptied completely. Use a syringe to remove the last of the fuel. |

NOTE

If any fuel remains in the tank during testing it could conceal a leak.

- | | | |
|--------------------------------|------------------------------------|--|
| 3. Pressure tester adapter (3) | Attach to fuel tank. | |
| 4. Fuel cap (1) | Install in adapter without anchor. | |

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

4-24. FUEL TANK INSPECTION/TEST - continued

5. Pressure tester (4) Screw into fitting (5) on adapter.

6. Air release valve (6) Open.

NOTE

Pump pressure tester in short bursts. This will minimize the chance of over-pressurizing. Over-pressurizing will permanently damage the tank.




Figure 4-21. S34 pressure tester

7. Pressure tester (4) Pump until pressure gage (7) reads 10 psi (69 kPa).

8. Fuel hose Hold end in container and depress ball check valve to expel any remaining fuel.

9. Pressure tester Pump until air is back up to 10 psi (69 kPa).

10. Air release valve (6) Close.

11. Pressure tester Remove.

12. Fuel tank check for air leaks. Submerge in water and Check all areas of tank carefully.

NOTE

Any air bubbles indicate a leak point and the tank must be replaced.

13. Fuel hose Disconnect from tank.

14. Fuel connector assembly Submerge in water and check for leaks. If assembly leaks, replace it. (See para 4-25.)

15. Release valve (6) Open and relieve pressure in tank.




Figure 4-22. Pressure tester adapter

4-25. FUEL TANK DISASSEMBLY/ASSEMBLY

This task covers:

Disassembly/assembly of fuel tanks and fuel line.

INITIAL SETUP:

Tools:
T1 5180-00-177-7033

Equipment Condition:
Fuel tank drained

Materials/Parts:
Gasket - 310984
Seal - 312192
Gasket - 312193

Personnel Required:
1 Mechanic

Approximate Time Required (minutes):
120

LOCATION/ITEM	ACTION	REMARKS
DISASSEMBLY		
1. Fuel cap (1)	Remove.	
2. Anchor link (2) and anchor (3)	Remove from fuel cap.	
3. Fuel hose (4).	Disconnect from housing and fuel line assembly (5).	
4. Capscrews (6) and washers (7)	Remove.	
5. Fuel line housing (5)	Lift out of tank.	
6. Capscrews (8)	Remove from indicator support.	
7. Fuel tank indicator assembly	Remove from housing (5).	
8. Seal (9), lens (10) gasket (11) and support (12)	Will come apart.	
9. Pin (13)	Remove from support (12).	
10. Indicator (15)	Remove from support (12).	
11. Core plugs (16)	Remove.	
12. Valve springs (17), release valves (18), and valve seat O-rings (19)	Will slide out of housing (5).	

4-25. FUEL TANK DISASSEMBLY/ASSEMBLY - continued




Figure 4-23. Fuel tank and fuel lines

LOCATION/ITEM	ACTION	REMARKS
4-25. FUEL TANK DISASSEMBLY/ASSEMBLY - continued		
13. Retainer (20)	Slip off guide pin (21).	
14. O-ring (22)	Remove.	
15. Retainer (23)	Remove.	
16. Disc valve spring (24) and disc valve (25)	Will come out of housing (5).	
DISASSEMBLY OF HOSE AND PRIMER BULB ASSEMBLY		
1. Hose clamps (1)	Remove.	
2. Hose clamp (2)	Remove.	
3. O-rings (3)	Remove.	
4. Hoses (5) and (6)	Slip off nipples.	Don't lose sleeve (7) to inlet fitting.
ASSEMBLY OF HOSE AND PRIMER BULB ASSEMBLY		
1. Hoses (5) and (6)	Slip over nipples of fittings.	Put sleeve (7) over inlet fitting before putting on hose.
2. O-rings (3)	Install.	
3. Hose clamp (2)	Install over primer bulb stem and outlet valve (6).	Hose is cut to desired length, from roll of bulb hose.
4. Hose clamps (1)	Use to clamp hoses (4) and (5) to nipples of fittings.	

LOCATION/ITEM	ACTION	REMARKS
4-25. FUEL TANK DISASSEMBLY/ASSEMBLY - continued		
ASSEMBLY OF FUEL TANK		
1. Disc valve (25) and spring (24)	Insert into housing (4) and secure with retainer (15).	
2. O-ring (22)	Slip over guide pin (21).	
3. Retainer (20)	Use to secure O-ring (9) on guide pin (21).	
4. Valve seat O-rings (19), release valves (18) and valve springs (17)	Slide into housing (5) and secure with core plugs (16).	
5. Indicator (15)	Place in position in support (12).	
6. Pin (13)	Install in support and indicator assembly.	
7. Gasket (11) lens (10) and seal (9)	Position on support (5).	
8. Indicator assembly	Secure to housing with capscrews (8).	
9. Gasket (11)	Position on fuel tank.	
10. Fuel line housing (5)	Position on gasket (14) and secure to fuel tank with capscrew (6) and washers (7).	

4-26. FUEL PUMP REMOVAL/INSTALLATION

This task covers:

Removal/installation of fuel pump

INITIAL SETUP:

Tools:
 T6 Tie strap wrench - 325043
 T1 5180-00-177-7033

Equipment Condition:
 Motor OFF

Materials/Parts:
 As required


Personnel Required:
 1 Mechanic

Approximate Time Required (minutes):
 30

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

REMOVAL

- | | |
|--|------------------------------|
| 1. Tie strap (1) | Remove from pump (2) outlet. |
| 2. Clamp strap (3) | Remove from pump inlet. |
| 3. Capscrew (4) | Remove. |
| 4. Filter cap (5), screen (6) gasket (7) | Remove from pump. |
| 5. Capscrews (8) | Remove from pump. |
| 6. Pump and gasket (9) | Remove. |



INSTALLATION

- | | |
|------------------|--|
| 1. Pump | Position on crankcase with gasket (9) |
| 2. Capscrews (8) | Install. Tighten to a torque of 24-36 in.lb. (2.84.0 N m). |

- | | |
|-----------------------|-----------|
| 1. Tie strap | 7. Gasket |
| 2. Fuel pump assembly | 8. Screw |
| 3. Clamp strap | 9. Gasket |
| 4. Capscrew | 10. Hose |
| 5. Filter cap | 11. Hose |
| 6. Filter screen | |

Figure 4-24. Fuel pump

LOCATION/ITEM	ACTION	REMARKS
4-26. FUEL PUMP REMOVAL/INSTALLATION - continued		

NOTE

Install a new filter screen element and gaskets when replacing fuel pump.

- | | |
|---|---------------------------------------|
| 3. Gasket (7) screen (6) and filter cap (5) | Position on pump. |
| 4. Capscrew (4) | Install. |
| 5. Clamp strap (3) pump inlet. | Install on hose (10) and |
| 6. Tie strap (1) | Install on hose (11) and pump outlet. |

4-27. CARBURETOR MAINTENANCE

This task covers:

- a. Carburetor inspection and cleaning
- b. This procedure includes needle valve inspection and replacement

INITIAL SETUP :

Tools:
 Flat end center punch
 T1 5180-00-177-7033
 T2 4910-00-754-0705
 T6 325043
 Materials/Parts:
 As required
 Personnel Required:
 1 Mechanic

Equipment Condition:
 Motor OFF

Approximate Time Required (minutes):
 60

LOCATION/ITEM	ACTION	REMARKS
INSPECTION		
1. Gasket (1)	Check for leaks. Replace if necessary.	<p>1. Gasket 2. Core plug 3. Core plug 4. Lead shot 5. Valve clip 6. Inlet valve assembly 7. Slow speed needle valve</p>
2. Core plugs (2) and (3)	Check for leaks. If leaks are found: a. A smart tap with a hammer and a flat end center punch in the center of the core plug will usually stop leaks. b. If leaks persist, drill a hole in core plug (no more than 0.059 in. (1.5mm) below surface) and pry out.	
CORE PLUG REPLACEMENT		
1. Casting opening	Inspect for damage.	Replace carburetor if damaged. (See para 4-28.)
2. Adhesive	Apply to edge of core plug (2) and (3).	

Figure 4-25. Carburetor and needle valves

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

4-27. CARBURETOR MAINTENANCE -continued

- | | | |
|-----------------------|--|---|
| 3. Core plug (2), (3) | Place in casting opening with convex side up. | |
| 4. Core plug | Use a hammer and a flat end center punch to rap into position. | Check for leakage after carburetor is installed. (See para 4-10.) |

LEAD SHOT REPLACEMENT

- | | | |
|------------------|---|---|
| 1. Lead shot (4) | Check for leaks. | Usually a sharp rap with a flat end center punch and a hammer will stop the leak. |
| 2. Lead shot (4) | Pry out with sharp tool. | |
| 3. Lead shot (4) | Place new lead shot in hole and rap into place with a flat end center punch and hammer. | |





Figure 4-26. Inlet needle valve and seat


NEEDLE VALVES

- | | | |
|--------------------------------|--------------------------------|--|
| 1. Inlet needle valve clip (5) | Remove. | |
| 2. Inlet needle valve (6) | Remove. | Check for grooves, nicks or scratches. Replace if necessary. |
| 3. Inlet needle valve seat | Inspect with magnifying glass. | Check for nicks, grooves or scratches. Turn out of casing and replace if necessary. |
| 4. Slow speed needle valve (7) | Turn out of casing. | Inspect for nicks, grooves, scratches, and off-centered condition. Replace if necessary. |

LOCATION/ITEM	ACTION	REMARKS
4-27. CARBURETOR MAINTENANCE - continued		



GOOD



BAD



BAD

Figure 4-27. Slow speed needle valve

4-28. CARBURETOR REMOVAL/INSTALLATION

This task covers:

Removal/installation of carburetor

INITIAL SETUP:


Tools:
 T1 5180-00-177-7033
 T2 4910-00-754-0705
 T6 325043

Equipment Condition:
 Motor OFF

Materials/Parts:
 Gasket - 325092

Personnel Required:
 1 Mechanic

Approximate Time Required (minutes):
 45

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Screw (1)	Back off until loose.	 <p>Figure 4-28. Carburetor</p> <p>1. Screw 2. Choke arm 3. Nut 4. Lockwasher 5. Gasket</p>
2. Choke arm (2)	Slide off shaft.	
3. Tie down on inlet hose	Remove.	
4. Inlet hose	Slide off carburetor inlet.	
5. Nuts (3) and lock-washers (4)	Remove.	
6. Carburetor and gasket (5)	Remove.	
		Replace gasket. Inspect flanges for nicks and cuts. Finish with fine emery cloth (120 and then 180 grit) if necessary.
INSTALLATION		
1. Carburetor and gasket (5)	Place in position.	
2. Nuts (3) and lock-washers (4)	Install.	
3. Inlet hose	Install on carburetor inlet and secure with tiedown.	
4. Choke arm (2)	Slide onto shaft and secure with capscrew (1).	
5. Motor	Start.	See para 2-8.
6. Carburetor	Adjust.	See para 3-17.
		Inspect carburetor for leaks.

4-29. INTAKE MANIFOLD INSPECTION

This task covers:

Inspection of intake manifold

INITIAL SETUP:

Tools:

Equipment Condition:

Materials/Parts:
None

Personnel Required:
1 Mechanic

Approximate Time Required (minutes):
5

LOCATION/ITEM	ACTION	REMARKS
1. Gaskets (1) and (2)	Inspect for leaks.	If you find any evidence of leakage, notify direct support maintenance to replace gaskets.
2. Manifold (3)	Inspect for cracks or damage.	If you see any signs of damage, notify direct support to replace manifold. 1. Gasket 2. Gasket 3. Manifold




Figure 4-29. Intake manifold

Section IX. ENGINE MAINTENANCE

MAINTENANCE SUMMARY. This task covers:

- a. Cylinder and crankcase inspection
- b. Cylinder head inspection

INITIAL SETUP

Personnel Required	General Safety Instructions
1	Keep hands, hair, and clothing away from starter, flywheel, and air intake.

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Cylinder and crankcase inspection	Para 4-30	
2	Cylinder head inspection	Para 4-30	

4-30. CYLINDERS, CYLINDER HEADS, AND CRANKCASE INSPECTION

This task covers:

Inspection of cylinders, cylinder heads and crankcase.

INITIAL SETUP:

Tools:
Flashlight

Equipment Condition:
Engine running

Materials/Parts:
None

Personnel Required:
1 Mechanic

Approximate Time Required (minutes):
10

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

WARNING

During the course of this inspection it will be necessary for you to remove the engine cover. Keep hands, hair and clothing away from flywheel, starter, and air intake.

Engine

While engine is running, inspect for leaks around the head gaskets and crankcase gaskets.

A flashlight can help by illuminating puffs of smoke.

If you detect any leaks, notify direct support.

Section X. LOWER UNIT MAINTENANCE

MAINTENANCE SUMMARY. This task covers:

- a. Steering handle/throttle shaft removal/installation
- b. Steering bracket inspection
- c. Stern bracket removal/installation
- d. Shift lever adjustment
- e. Shift lever removal/installation

INITIAL SETUP

Personnel Required	General Safety Instructions
1	

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Steering handle/throttle removal/installation.	Para 4-31	
2	Steering bracket inspection	Para 4-32	
3	Stern bracket removal/installation	Para 4-33	
4	Shift lever removal/installation	Para 4-34	
5	Shift lever adjustment	Para 4-35	

4-31. STEERING HANDLE REMOVAL/INSTALLATION

This task covers:

Removal/installation of steering handle and throttle shaft.

INITIAL SETUP

Tools:
T1 5180-00-177-7033

Equipment Condition:
Motor OFF

Materials/Parts:
As required

Personnel Required:
1 Mechanic

Approximate Time Required (minutes):
20

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

REMOVAL

- | | | |
|--|---|--|
| 1. Cotter pin (1) | | |
| 2. Nut (2) | Loosen. | |
| NOTE | | |
| Capscrew (3) is threaded into steering bracket (4). | | |
| 3. Capscrew (3) | Turn out of handle (5), steering bracket (4) and nut (2). | |
| 4. Spring washer (6) and washer (7) | Remove with capscrew (2). | |
| 5. Handle (5) and throttle shaft | Remove as an assembly. | |




Figure 4-30. Steering handle

INSTALLATION

- | | | |
|---|---------------------------------------|---|
| 1. Handle (5) and throttle shaft | Position on steering bracket (4). | Position throttle shaft gears by aligning the long space in each gear with the long tooth in each gear. |
| 2. Washer (7) and spring washer (6) | Place on capscrew (3) as shown. | |
| 3. Nut (2) | Place in position in steering handle. | |
| 4. Capscrew (3) (4), steering handle (5) and nut (2). | Turn into steering bracket | Tighten capscrew (3) and nut (2) until friction is enough to hold handle in any position. |
| 5. Cotter pin (1) | Install. | |

4-32. STEERING BRACKET INSPECTION

This task covers:

Inspecting steering bracket

INITIAL SETUP:

Tools:

Equipment Condition:
Motor OFF

Materials/Parts:

Personnel Required:
1 Mechanic

Approximate Time Required (minutes):
5

LOCATION/ITEM	ACTION	REMARKS
INSPECTION		
Steering bracket	Inspect for cracks, breaks and worn or missing rubber mounts.	Notify direct support to replace or repair as necessary.

4-33. STERN BRACKETS REMOVAL/INSTALLATION

This task covers:

Removal/installation of stern brackets

INITIAL SETUP:

Tools:
T1 5180-00-177-7033

Equipment Condition:
Motor tilted up on aft handles

Materials/Parts:
As required

Personnel Required:
1 Mechanic

Approximate Time Required (minutes):
45

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Thrust rod (1) and retainer	Remove with spring (2).	
2. Nut (3), washer (4) and spring (5)	Remove.	
3. Tilting shaft bolt (6) spring and reverse lock arm (7).	Slide out of stern brackets (8) and (9).	
4. Stern brackets (8) and (9)	Will come off swivel bracket assembly (10).	
5. Conical Tilting shaft washers (11)	Remove.	
INSTALLATION		
1. Conical tilting shaft washers (11)	Install in swivel bracket assembly (10).	
2. Stern bracket (9) assembly (10).	Position on swivel bracket assembly (10).	

- 1. Thrust rod
- 2. Spring
- 3. Nut
- 4. Washer
- 5. Spring
- 6. Tilting shaft bolt
- 7. Reverse lock arm
- 8. Stern bracket
- 9. Stern bracket
- 10. Swivel bracket assembly
- 11. Conical washer
- 12. Spring

Figure 4-31. Stern brackets

LOCATION/ITEM	ACTION	REMARKS
4-33. STERN BRACKETS REMOVAL/INSTALLATION -continued		
3. Tilting shaft bolt (6)	Insert through stern bracket (9) with spring (12) and reverse lock arm (7) and swivel bracket assembly.	
4. Stern bracket (8)	Position over tilting shaft bolt (6) and swivel bracket assembly (10).	
5. Spring (5), washer (4)	Secure to tilt shaft bolt with nut (3).	
6. Thrust rod and retainer (1)	Install with spring (2).	See para 2-7 for tilt adjustment.

4-34. SHIFT LEVER REMOVAL/INSTALLATION

This task covers:
Shift lever removal/installation

INITIAL SETUP:

Tools:
T1 5180-00-177-7033

Equipment Condition:
Motor OFF

Materials/Parts:
As required

Personnel Required:
1 Mechanic

Approximate Time Required (minutes):
30


LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Clamp screw (1)	Remove.	
2. Adjustment screw (2)	Remove.	
3. Shift lever (3)	Remove.	
NOTE		
<p>If shift bracket and shaft (4) must be replaced notify direct support maintenance.</p>		
INSTALLATION		
1. Shift lever (3)	Position on shaft (4).	1. Clamp screw 3. Shift lever
2. Adjustment screw (2)	Install but do not tighten completely.	2. Adjustment screw 4. Shaft
3. Clamp screw (1)	Install but do not tighten completely.	
4. Shift lever (1)	Adjust. (See shift lever adjustment, para 4-35.)	

Figure 4-32. Motor - starboard view

4-35. SHIFT LEVER ADJUSTMENT

This task covers:

Adjusting shift lever

INITIAL SETUP :

Tools:
T1 5180-00-177-7033

Equipment Condition:
Follow procedure

Materials/Parts:
None

Personnel Required:
1 Mechanic

Approximate Time Required (minutes):
20

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

WARNING

Remove spark plug leads before performing this procedure (see para 3-10).

ADJUSTMENT

1. Shift lever (1)	Place in neutral position.	After placing shift lever in neutral, propeller should turn freely.
2. Roller on shift lever	Should be centered on neutral detent of shifter lock lever.	
3. Shift lever (1)	Shift into forward gear.	You should feel a slight drag when turning propeller back and forth. This indicates full engagement between clutch dog and forward gear.
4. Shift lever	Shift into neutral if you don't feel drag.	Propeller should turn freely.
5. Shifter lever clamp (2)	Loosen.	
6. Adjustment screw (3)	Loosen.	
7. Shift lever (1)	Move into neutral detent on shifter lock lever.	


LOCATION/ITEM	ACTION	REMARKS
4-35. SHIFT LEVER ADJUSTMENT - Continued		
8. Clamp screw (2) and adjustment screw (3)	Tighten.	
9. Shift lever (1)	Move to forward gear and feel for drag as in step no. 3.	
10. Shift lever (1)	<p>If you do not feel drag:</p> <p>a. Loosen screws (3) and (2).</p> <p>b. Adjust shift lever slightly toward reverse position.</p> <p>c. Tighten screws.</p> <p>d. Again check for drag.</p>	

Figure 4-33. Motor - starboard view

NOTE

Repeat as many times as necessary. This slight drag in forward gear ensures that shifter dog and gear are correctly engaged.

Section XI. COOLING SYSTEM MAINTENANCE

MAINTENANCE SUMMARY. This task covers:

- a. Water pump removal/disassembly/assembly/installation
- b. Water intake screen service
- c. Engine temperature test

INITIAL SETUP

Personnel Required	General Safety Instructions
1	

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Water pump removal/disassembly/ assembly/installation	Para 4-36	
2	Water intake screen service	Para 4-37	
3	Engine temperature test	Para 4-38	

4-36. WATER PUMP REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION

This task covers:

Water pump replacement and repair.

INITIAL SETUP :

Tools:

T1 5180-00-177-7033

Equipment Condition:

Motor suspended with lower unit free.

Materials/Parts:

Gaskets (item 15, 325299),
(item 17, 325229)

Personnel Required:

1 Mechanic

Approximate Time Required (minutes):

120

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Long capscrew (1)	Remove from top of extension (2).	It is not necessary to remove extension (2) to perform procedure.
2. Capscrews (3)	Remove - both sides.	
3. Access cover and gasket.	Remove from exhaust housing.	Access cover is not shown. Located on starboard side. Be sure shift lever is in neutral position for easy accessibility through access cover.
4. Top connector screw (4) and lockwasher (5)	Remove so that upper shift rod can be disconnected from lower shift rod (6).	
5. Gearcase and bearing assembly (7)	Separate from extension (2).	
6. Water tube adapter (8)	Will separate from water pump housing outlet when gearcase is lowered.	
7. Gearcase (9)	Lower away from upper section and support on blocks.	Drive shaft (12) is connected to crankshaft by a splined coupling. Lower gearcase straight down so drive shaft will not bind on coupling.

4-36. WATER PUMP REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continued

- 1. Long capscrew
- 2. Extension
- 3. Capscrew
- 4. Capscrew
- 5. Lockwasher
- 6. Lower shift rod
- 7. Gearcase and bearing assembly
- 8. Water tube adapter
- 9. Gearcase and bearing assembly
- 10. Capscrew
- 11. Washer
- 12. Drive shaft
- 13. Housing
- 14. Impeller cup
- 15. Impeller
- 16. Gasket
- 17. Plate
- 18. Gasket
- 19. Seal
- 20. Key
- 21. Shift rod connector




Figure 4-34. Lower unit and water pump
4-59

LOCATION/ITEM	ACTION	REMARKS
4-36. WATER PUMP REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continued		

DISASSEMBLY

1. Capscrews (10) and washers (11)	Remove.	Lubricate drive shaft with light oil. This will make disassembly of water pump easier.
2. Drive shaft (12) and water pump assembly.	Lift out of gearcase.	
3. Housing (13)	Slide off shaft (12)	Inspect seal (19) and replace if necessary.
4. Impeller cup (14)	Slide off shaft.	
5. Impeller (15)	Slide off shaft.	Remove key (20) from drive shaft and put in a safe place when you remove impeller.
6. Gasket (16)	Remove and discard.	
7. Impeller housing plate (17)	Remove.	Inspect and replace all worn or damaged parts. Clean impeller housing plate thoroughly to remove all fragments of gasket material.
8. Gasket (18)		Remove and discard.

ASSEMBLY

1. Gasket (18)	Install in gearcase (9).	Be sure capscrew holes line up correctly.
2. Impeller housing plate (17)	Install in gearcase assembly.	
3. Gasket (16)	Install on impeller housing plate.	
4. Key (20)	Install in slot on drive shaft (12).	
5. Impeller (15)	Position on drive shaft so slot in impeller mates with key (20).	
6. Impeller cup (14)	Install.	
7. Housing (13)	Position on gearcase (9)	Replace seal (19) before installing housing.
8. Drive shaft and water pump assembly	Install in gearcase (9).	Rotate shaft to be sure pump assembly does not bind.
9. Capscrews (10) and washers (11)	Install.	

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

4-36. WATER PUMP REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continued

INSTALLATION

1. Gearcase and bearing assembly (7)	Position under extension (2).	
2. Flywheel	Rotate back and forth to engage splined coupling while carefully lifting gearcase assembly.	
3. Water tube adapter (8)	Install in water pump outlet.	
4. Shift rod connector (21)	Engage with upper shift rod.	
5. Gearcase and bearing assembly	Lift into position and install capscrews (3).	
6. Long capscrew (1)	Install.	
7. Shift rod connector (21)	Secure to upper shift rod with capscrew (4) and lockwasher (5).	Be sure capscrew (4) engages slot in upper shift rod (6).
8. Access cover and gasket.	Install over access hole.	

4-37. WATER INTAKE SCREEN SERVICE

This task covers:

Water intake screen service

INITIAL SETUP:

Tools:
Fiber brush

Equipment Condition:
Motor OFF

Materials/Parts:
Screen - 302521 (if necessary)

Personnel Required:
1 Mechanic

Approximate Time Required (minutes):
5

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

SERVICE

- | | | |
|-------------------|---|--|
| 1. Retaining plug | Remove. | |
| 2. Screen | Remove. | |
| 3. Screen | Clean. Use fiber brush.
Replace screen if damaged or corroded. | |




Figure 4-35. Water intake screen

4-38. ENGINE TEMPERATURE TEST

This task covers:

Testing engine temperature

INITIAL SETUP :

Tools:

163°F (73°C) markal thermomelt stik

Equipment Condition:

Follow procedure

Materials/Parts:

None

Personnel Required:

1 Mechanic

Approximate Time Required (minutes):

20

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

TEST

NOTE

This test is best performed on an operating engine, on a boat. If this is not possible run motor in test tank at 3/4 throttle for at least 5 minutes.

1. Engine

Make a mark on the surface with the stik.

NOTE

The mark will be dull and chalky in appearance. When the surface reaches the rated temperature of the stik, the mark will melt, becoming liquid and glossy in appearance.

2. Mark

If the mark melts, the cooling system of the motor is not functioning properly.

a. Check the inlet screen.

See para 4-37.

b. Replace the water pump.

See para 4-36.




Figure 4-36. Markal thermomelt stik

CHAPTER 5**DIRECT SUPPORT MAINTENANCE INSTRUCTIONS**

5-1. CHAPTER OVERVIEW. This chapter contains maintenance that will be performed by direct support maintenance personnel.

Section 1. REPAIR PARTS, SPECIAL TOOLS, TMDE AND SUPPORT EQUIPMENT

5-2. COMMON TOOLS AND EQUIPMENT. For authorized common tools and equipment refer to the Modified Table of Organization and Equipment (MTOE) applicable to your unit.

5-3. SPECIAL TOOLS. Special tools are listed in appendix C and in TM 5-2805-261-23P.

5-4. SPARES AND REPAIR PARTS. Spares and repair parts are listed and illustrated in the repair parts and special tools list covering organizational and DS maintenance for this equipment (TM 5-2805-261-23P).

Section II. MOTOR COVER

MAINTENANCE SUMMARY. This task covers:

Motor cover removal/disassembly/assembly/installation.

INITIAL SETUP

Personnel Required	General Safety Instructions
1	

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Motor cover removal/disassembly/ assembly/installation	Para 5-5	

5-5. MOTOR COVER REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION

This task covers:

Motor cover maintenance

INITIAL SETUP :

Tools:

- 1/4" drill
- Pop rivet tool
- T1 5180-00-177-7033
- T2 4910-00-754-0705

Equipment Condition:

Motor on motor stand

Materials/Parts:

As required


Personnel Required:

1 mechanic

Approximate Time Required (minutes):

180

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Upper motor cover (1)	Remove.	See para 2-12.
2. Engine	Remove.	See para 5-8
DISASSEMBLY-UPPER MOTOR COVER		
1. Capscrews (2) and washers (3)	Remove.	
2. Tilt handle (4)	Remove.	
3. Rivets (5)	Drill out.	
4. Hooks (6)	Remove.	
5. Capscrew (7) and washer (8)	Remove	
6. Latch (9), bushing washer (10) and bushing (11)	Remove from handle (12)	



- | | | | |
|-------------------------------|-----------------------|---------------------|--------------|
| 1. Upper motor cover assembly | 12. Handle | 23. Capscrew | 34. Capscrew |
| 2. Capscrew | 13. Rivet | 24. Nut | 35. Hook |
| 3. Washer | 14. Bracket | 25. Carrying handle | 36. Grommet |
| 4. Tilt handle | 15. Grommet | 26. Capscrew | 37. Grommet |
| 5. Rivet | 16. Washer | 27. Nut | 38. Grommet |
| 6. Hook | 17. Capscrew | 28. Lockwasher | 39. Capscrew |
| 7. Capscrew | 18. Nut | 29. Baffle | 40. Clamp |
| 8. Washer | 19. Washer | 30. Spacer | 41. Capscrew |
| 9. Latch | 20. Spacer | 31. Spacer | 42. Detent |
| 10. Washer | 21. Grommet | 32. Capscrew | 43. Capscrew |
| 11. Bushing | 22. Lower motor cover | 33. Bracket | 44. Lead |

Figure 5-1. Upper and lower motor cover
5-4

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

5-5. MOTOR COVER REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continueud

- | | | |
|------------------------|------------|--|
| 7. Handle (12) | Remove. | |
| 8. Bracket rivets (13) | Drill out. | |
| 9. Bracket (14) | Remove. | |
| 10. | | |

**ASSEMBLY - UPPER
MOTOR COVER**

- | | | |
|--------------------------------|---------------------------------|--|
| 1. Tilt handle (4) | Place in position on cover (1). | |
| 2. Capscrew (2) and washer (3) | Install. | |
| 3. Hook (6) | Place in position. | |

NOTE

Capscrews and lockwashers can be used to fasten hook and bracket to cover, but rivets are the recommended method.

- | | | |
|--------------------------------------|---|-----------------------|
| 4. Bracket (14) | Place in position and fasten to cover. | |
| 5. Handle (12) | Insert through hole in cover and bracket. | |
| 6. Bushing (11) | Insert in bracket. | |
| 7. Bushing washer (10) and latch (9) | Place in position on assembly and fasten with capscrew (7). | |
| 8. Motor cover (1) | Install. | See para 2-13. |

**REMOVAL - LOWER
MOTOR COVER**

- | | | |
|---|---------|--|
| 1. Four retaining assemblies (15 thru 17) and (18 thru 21) attaching lower motor cover (22) to exhaust housing. | Remove. | |
|---|---------|--|

LOCATION/ITEM	ACTION	REMARKS
5-5. MOTOR COVER REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continued		
2. Lower motor cover (22)	Remove.	
DISASSEMBLY - LOWER MOTOR COVER		
1. Capscrew (23) and nut (24)	Remove.	
2. Carrying handle (25)	Remove.	
3. Capscrews (26), nuts (27) and lockwashers (28)	Remove.	
4. Baffle (29) and spacers (30) (31)	Remove.	
5. Capscrew (32)	Remove.	
6. Bracket (33)	Remove.	
7. Capscrew (34)	Remove.	
8. Hook (35)	Remove.	
9. Grommets (36), (37) and (38)	Should be replaced if worn or cracked.	
10. Capscrews (39)	Remove.	
11. Clamp (40) and stop switch	Remove.	See para 4-22, removal/installation of stop (shorting) switch.
12. Detent screw (41) and choke knob detent (42)	Remove.	
13. Screw (43) and lead (44)	Remove.	

LOCATION/ITEM	ACTION	REMARKS
5-5. MOTOR COVER REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continued		
ASSEMBLY - LOWER MOTOR COVER		
1. Carrying handle (25)	Position on lower cover (22).	
2. Capscrew (23) and nut (24)	Install.	
3. Baffle (29) and spacers (30)	Use capscrews (26) to form an assembly. Insert capscrews into holes in lower cover.	
4. Nuts (27)	Install.	
5. Bracket (33)	Position on lower cover.	
6. Capscrews (32)	Install.	
7. Hook (35)	Place in position on lower cover.	
8. Capscrews (34)	Install.	
9. Grommets (36), (37) and (38)	Install.	
10. Cover clamp (40) and stop switch	Position on cover	
11. Capscrews (39)	Install.	See para 4-22, removal/installation of stop (shorting) switch.
12. Choke knob detent (42)	Position on cover.	
13. Ground wire (43) and screws (44)	Install.	
14. Detent screw (41)	Install.	

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

5-5. MOTOR COVER REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continued

INSTALLATION

1. Fuel hose	Insert through opening in lower motor cover.	
2. Lower cover (22)	Position on exhaust housing.	
3. Ground wire (44)	Install.	
4. Four retaining assemblies (15 thru 17) and (18 thru 21)	Install on exhaust housing studs, securing lower cover to exhaust housing.	
5. Engine	Install.	See para 5-8
6. Upper motor cover (1)	Install.	See para 2-13.

NOTE

Upper motor cover seal can be replaced, but it cannot be glued on. It must be fastened to the motor cover using stainless steel wire at regular spaces around the perimeter of the cover.

Section III. FUEL SYSTEM

MAINTENANCE SUMMARY. This task covers:

- a. Carburetor disassembly/assembly
- b. Intake manifold removal/installation
- c. Leaf plate assembly removal/inspection/installation

INITIAL SETUP

Personnel Required	General Safety Instructions
1	Do not smoke or allow sparks when working on fuel system. Gasoline is extremely flammable and can cause burns.

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Carburetor disassembly/assembly	Para 5-6	NOTE Leaf plate assembly/removal/inspection/and installation is part of the removal/installation procedure for the intake manifold.
2	Intake manifold removal/installation.	Para 5-7	
3	Leaf plate assembly removal/inspection/installation	Para 5-7	

5-6. CARBURETOR DISASSEMBLY/ASSEMBLY

This task covers:

Disassembly/assembly of the carburetor

INITIAL SETUP :

Tools:

- T1 5180-00-177-7033
- T2 4910-00-754-0705
- T6 325043

Equipment Condition:

Motor OFF

Materials/Parts:

As required

Personnel Required:

1 mechanic

Approximate Time Required (minutes):

60

LOCATION/ITEM	ACTION	REMARKS
DISASSEMBLY I		
1. Carburetor (1)	Remove.	See para. 4-28.
2. Needle valve (2) and retainer (3)	Remove.	See para. 4-27.
3. Needle valve assembly (4)	Remove.	See para. 4-27.
4. Core plugs (5) and (6)	Remove.	See para. 4-27.
5. Lead shot (7)	Remove.	See para. 4-27.
6. Roll pin (8)	Remove.	See illustration, page 5-11.
7. Throttle return spring (9) and retainer (10)	Remove.	
8. Capscrews (11)	Remove.	
9. Float chamber assembly (12) and gasket (13)	Remove.	Nozzle gasket (14) will come out with the float bowl assembly.
10. Choke arm and screw assembly (15)	Remove.	

5-6. CARBURETOR DISASSEMBLY/ASSEMBLY - continued




Figure 5-2. Carburetor

LOCATION/ITEM	ACTION	REMARKS
5-6. CARBURETOR DISASSEMBLY/ASSEMBLY - continued		
10. Float hinge pin (16)	Remove.	
11. Float (17)	Remove.	
CLEANING	<u>WARNING</u>	
	Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid repeated and prolonged skin contact by wearing rubber or non-porous gloves when handling the solvent or material wet with drycleaning solvent. Wash hands immediately after exposure with soap and water and use a lanolin based skin cream to prevent skin drying. Do not use near open flame or excessive heat. Flash point of solvent is 100°F (38°C). Do not work with solvent in a closed room. Be sure there is good ventilation or the solvent vapors will build up in the air and become a poisonous mixture which can cause physical injury or even death.	
1. Jets and passages	a. Clean with solvent. b. Dry with clean lint-free cloth.	Be sure to remove all gum and varnish.
2. Needle valves	a. Clean with solvent. b. Dry with clean lint-free cloth.	
ASSEMBLY		
1. Float (17)	Position hinge and insert float hinge pin (23).	Be sure hinge moves freely, with no binding.
2. Float chamber assembly (12) and gasket (13)	Position on carburetor.	
3. Capscrew (11)	Install.	
4. Throttle return spring (9) and retainer (10)	Install.	
5. Roll pin (8)	Install.	
6. Choke arm and screw assembly (15)	Remove.	
7. Lead shot (7)	Install.	See para. 4-27.
8. Core plugs (5) and (6)	Install.	See para. 4-27.
9. Needle valve assembly (4)	Install.	See para. 4-27.
10. Needle valve (2) and retainer (3)	Install.	See para. 4-27.
11. Carburetor (1)	Install.	See para. 4-28.

5-7. INTAKE MANIFOLD REMOVAL/INSTALLATION

This task covers:

Removal/Installation/Inspection of intake manifold and leaf plate assembly

INITIAL SETUP:

Tools:

- T1 5180-00-177-7033
- T2 4910-00-754-0705

Equipment Condition:

Motor OFF

Materials/Parts:

As required

Personnel Required:


mechanic

Approximate Time Required (minutes):

100

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Carburetor	Remove.	See para. 4-28.
2. Cotter pin (1) and washer (2)	Remove.	
3. Cam follower (3) and throttle lever (4)	Slide off shaft.	
4. Springs (5) and (6)	Remove.	When sliding the cam follower off the shaft, hold spring (5) in place.
5. Cam follower (3)	Disengage from rod (7).	
6. Capscrews (8), (9), and (10)	Remove.	Capscrews are of three different lengths. Take notice of where each length goes.
7. Intake manifold (11), and gasket (12)	Remove.	
8. Capscrew (13)	Remove.	
9. Leaf plate assembly (14)	Remove.	
10. Gasket (15)	Remove.	
11. Capscrew (16), nut (17) and lockwasher (18)	Remove.	

5-7. INTAKE MANIFOLD REMOVAL/INSTALLATION - continued



- | | | | |
|---------------------------|---------------------|-------------------------|---------------------|
| 1. Cotter pin | 7. Rod | 13. Capscrew | 18. Lockwasher |
| 2. Washer | 8. Long capscrew | 14. Leaf plate assembly | 19. Leaf valve |
| 3. Cam follower | 9. Short capscrew | 15. Retainer | 20. Leaf valve stop |
| 4. Throttle lever and pin | 10. Capscrew | 16. Capscrew | 21. Leaf plate |
| 5. Spring | 11. Intake manifold | 17. Nut | 22. Capscrew |
| 6. Spring | 12. Gasket | | |

Figure 5-3. Intake manifold

LOCATION/ITEM	ACTION	REMARKS
5-7. INTAKE MANIFOLD REMOVAL/INSTALLATION - continued		
INSTALLATION	CAUTION	
	Do not attempt to repair a distorted leaf valve.	
1. Leaf plate assembly (14)	Inspect.	
	NOTE	
	Leaf valves (19) must be free from all gum and varnish. They must be perfectly flat and without distortion, so that they form a perfect seal with the leaf plate.	
2. Leaf valves (19)	a. Replace if broken or distorted. b. Clean if necessary.	
	WARNING	
	Drycleaning solvent, P-D-680, used to clean parts is potentially dangerous to personnel and property. Avoid repeated and prolonged skin contact by wearing rubber or non-porous gloves when handling the solvent or material wet with drycleaning solvent. Wash hands immediately after exposure with soap and water and use a lanolin based skin cream to prevent skin drying. Do not use near open flame or excessive heat. Flash point of solvent is 100°F (38°C). Do not work with solvent in a closed room. Be sure there is good ventilation or the solvent vapors will build up in the air and become a poisonous mixture which can cause physical injury or even death.	
3. Leaf valve stop (20), leaf valve (19) and leaf valve plate (21)	Assemble using capscrew (16), nut (17) and lock-washer (18).	Be sure the leaf valves line up with the holes in the valve plate and the leaf valve stop arms are lined up correctly, behind the leaf valves.
4. Gasket (15)	Position on crankcase.	
5. Leaf plate assembly (14)	Position over gasket (15), on crankcase.	

LOCATION/ITEM	ACTION	REMARKS
5-7. INTAKE MANIFOLD REMOVAL/INSTALLATION - continued		
6. Capscrew (13)	Use to fasten leaf plate assembly and gasket to crankcase.	
7. Gasket (12)	Place on leaf plate assembly (14).	
8. Intake manifold (11)	Position over gasket (12) and leaf plate assembly.	
9. Capscrews (8), (9) and (10)	Install.	
10. Spring (5) assembly (3).	Position in cam follower	
11. Cam follower assembly (3) and throttle lever (4)	Slide onto shaft.	
12. Spring (13)	Install.	
13. Cam follower	Engage with rod (7).	
14. Washer (2) and cotter pin (1)	Install on shaft.	
15. Carburetor	Install.	See para. 4-28.

Section IV. ENGINE ASSEMBLY

MAINTENANCE SUMMARY. This task covers:

- a. Engine removal/installation.
- b. Engine disassembly/assembly.
- c. Crankshaft and pistons disassembly/assembly.
- d. Bearings removal/installation.
- e. Cylinder head removal/installation.

INITIAL SETUP

Personnel Required	General Safety Instructions
1	None

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Engine removal/installation	Para. 5-8	
2	Engine disassembly/assembly	Para. 5-9	Cylinder head removal/installation is part of Engine disassembly/assembly, para. 5-9.
3	Crankshaft and pistons disassembly/assembly.	Para. 5-10	Bearings replacement is part of para. 5-10, crankshaft and pistons disassembly/assembly.

5-8. ENGINE REMOVAL/INSTALLATION

This task covers:

Removal/Installation of engine

INITIAL SETUP:

Tools:

- T6 Tie strap wrench - 325043
- T1 5180-00-177-7033
- T2 4910-00-754-0705

Equipment Condition:

Motor in shop

Materials/Parts:

As required

Personnel Required:

1 mechanic

Approximate Time Required (minutes):

180

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Starter (1)	Remove.	See para. 3-9.
2. Flywheel (2)	Remove.	See para. 4-17.
3. Armature (3)	Remove.	See para. 4-16.
4. Carburetor (4)	Remove.	See para. 4-28.
5. Intake manifold and leaf valve assembly (5)	Remove.	See para. 5-7.
6. Fuel pump (6), auxiliary fuel filter (7), and fuel hoses (8)	Remove. (See para. 4-26.)	
7. Spark plugs (9)	Remove. (See para. 3-10.)	
8. Ignition coils (10)	Remove. (See para. 4-18.)	
9. Starter mounting brackets (11)	Remove.	
10. Throttle control rod assembly	Slide out of pivot pin. (See page 5-21.)	
11. Cam follower spring	Disconnect from intake manifold. (See page 5-21.)	
12. Throttle control lever (12)	Remove by: <ul style="list-style-type: none"> a. Remove two screws and clamps. (See page 5-20.) b. Lift lever from lower motor cover. 	




Figure 5-4. Motor - port view

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

5-8. ENGINE REMOVAL/INSTALLATION - continued

13. Shifter lock (13) and shifter lock spring

Remove. (See page 5-20.)

14. Water indicator line (14)

Remove at fitting.

15. Fuel return line (15)

Remove clamps and slide off fittings.

16. Two nuts, seven 3/8 capscrews, and two 1/2 capscrews attaching engine to exhaust housing

Remove.

17. Engine.

Remove




Figure 5-5. Motor- starboard view

NOTE
Pick engine straight up so the splined connection between crankshaft and drive shaft will not be harmed.

18. Two gaskets and engine plate

Remove from exhaust housing.

INSTALLATION

1. Two gaskets and engine plate

Position on exhaust housing.

NOTE
Line up splined coupling between crankshaft and drive shaft. Line up bolt holes correctly.

2. Engine

Position very carefully on exhaust housing.




Figure 5-6. Engine plate and gaskets

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

5-8. ENGINE REMOVAL/INSTALLATION - continued

- | | | |
|---|--|---|
| 3. Two nuts, seven 3/8 capscrews, and two 1/2 capscrews | Use to attach engine to exhaust housing. | |
| 4. Fuel return line (15) | Install on fitting. | Use pliers to squeeze the two projecting ends of the clamp. This will expand the clamp. |
| 5. Water indicator line (14) | Install on fitting. | |
| 6. Shifter lock (13) and shifter lock spring | Install. | |
| 7. Throttle control lever (12) | Place in position. | |
| 8. Two screws and clamps | Use to secure throttle control lever. | |




Figure 5-7. Shifter lock

- | | | |
|--|---|-----------------|
| 9. Starter mounting brackets (11) | Install. | |
| 10. Ignition coils (10) | Install. | See para. 4-18. |
| 11. Engine ground wire and clamp for stop switch leads | Fasten to bottom screw of port bracket. | |
| 12. Spark plugs (9) | Install. | See para. 3-10. |
| 13. Fuel pump (6) | Install. | See para. 4-26. |
| 14. Auxiliary fuel filter (7) and fuel hoses (8) | Install. | See para. 4-26. |
| 15. Intake manifold and leaf valve assembly (5) | Install. | See para. 5-7. |
| 16. Carburetor (4) | Install. | See para. 4-28. |
| 17. Armature (3) | Install. | See para. 4-16. |

Remove retaining pin from control lever. Remove grommet from lower motor cover and slide grommet onto control lever. Install retaining pin and engage pin in throttle control gear.




Figure 5-8. Throttle control lever

LOCATION/ITEM	ACTION	REMARKS
5-8. ENGINE REMOVAL/INSTALLATION - continued		
18. Throttle lever assembly, follower and follower spring	Assemble as shown and slide on shaft.	
19. Washer and cotter pin	Install.	
20. Spring	Connect to throttle lever and intake manifold as shown.	
21. Throttle link	Snap into throttle arm and lever assembly as shown.	
22. Flywheel (2)	Install.	See para. 4-17.
23. Starter (1)	Install.	See para. 3-9.




Figure 5-9. Throttle linkage

5-9. ENGINE DISASSEMBLY/ASSEMBLY

This task covers:

Engine disassembly/assembly and cylinder head removal/installation

INITIAL SETUP:

Tools:

- T8 Engine holder - 303605
- T10 Retaining ring pliers - 303859
- T9 Piston ring compressor - 326592
- T1 5180-00-177-7033
- T2 4910-00-754-0705

Equipment Condition:

- Engine removed from exhaust housing. (See para. 5-8.)
- Engine installed in engine holder 303605 and back of engine holder clamped securely in vise.

Materials/Parts:

- Sealant 327361

Personnel Required:

- 1 mechanic

Approximate Time Required (minutes):

330

LOCATION/ITEM	ACTION	REMARKS
DISASSEMBLY		
1. Capscrews (1)	Remove.	
2. Cylinder head cover (2) and gasket (3)	Remove.	
3. Capscrews (4) and lift bracket (5)	Remove from cylinder head (6).	
4. Cylinder head (6) and gasket (7)	Remove from cylinder block (8).	
5. Capscrews (9) and valve housing (10)	Remove.	
6. Capscrews (11), lock-washers (12) and bracket (13)	Remove.	
7. Taper pins (14)	Remove.	
8. Eight small capscrews (15)	Remove.	Tap out of crankcase from cylinder side of engine towards crankcase side.
9. Four large capscrews (16) and washers (17)	Remove.	
10. Two alien screws (18)	Remove.	
11. Crankcase (19)	Remove from cylinder block (8).	Tap on top of crankcase with rawhide mallet until it comes free.

CAUTION

Be careful not to scratch or mar any machined surfaces.

12. Lower main bearing seal housing.	Remove from crankshaft.	See para. 5-10.
13. Large retaining ring	Remove from crankshaft.	See para. 5-10.

5-9. ENGINE DISASSEMBLY/ASSEMBLY





Figure 5-10. Engine (1 of 2)

5-9. ENGINE DISASSEMBLY/ASSEMBLY - continued



- | | | |
|---------------------------------------|-------------------|-------------------------|
| 1. Capscrew | 12. Lockwasher | 24. Hose |
| 2. Cover | 13. Bracket | 25. Hose |
| 3. Gasket | 14. Taper pin | 26. Clamp |
| 4. Capscrew | 15. Capscrew | 27. Clamp |
| 5. Lift bracket | 16. Long capscrew | 28. Capscrew |
| 6. Cylinder head | 17. Washer | 29. Outer exhaust cover |
| 7. Gasket | 18. Allen screws | 30. Gaskets |
| 8. Cylinder block | 19. Crankcase | 31. Inner exhaust cover |
| 9. Capscrew | 20. Capscrew | 32. Gaskets |
| 10. Housing nipple and valve assembly | 21. By-pass cover | 33. Bumper |
| 11. Capscrew | 22. By-pass cover | 34. Capscrew |
| | 23. Gasket | 35. Nut |

Figure 5-10. Engine (2 of 2)

LOCATION/ITEM	ACTION	REMARKS
5-9. ENGINE DISASSEMBLY/ASSEMBLY - continued		
CAUTION		
<p>Pistons, connecting rods and caps are matched parts and seat with the operation of the motor. Because of this, it is essential to maintain their original positions at reassembly. Mark each connecting rod and cap, piston, and bearing component to assure correct mating when they are reassembled. Also mark the cylinders from which they are removed.</p>		
14. Connecting rod bearing caps	Remove. (See para. 5-10.)	
15. Sixteen needle bearings	Remove from connecting rod bearing caps. (See para. 5-10.)	
16. Crankshaft	Lift from cylinder block.	
NOTE		
<p>Be sure to match bearing caps with connecting rods.</p>		
17. Connecting rod bearing caps	Place back on connecting rods.	
18. Piston and connecting rods	Remove from cylinder block.	See para. 5-10 for disassembly/assembly of crankshaft, pistons and connecting rods.
19. Capscrews (20)	Remove.	

LOCATION/ITEM	ACTION	REMARKS
5-9. ENGINE DISASSEMBLY/ASSEMBLY - continued		
20. Upper (21) and lower (22) by-pass covers and gaskets (23)	Remove from cylinder block.	
21. Hoses (24), (25) and clamps (26) and (27)	Remove from by-pass covers.	
22. Capscrews (28)	Remove.	
23. Outer exhaust cover (29) and gasket (30) and inner exhaust cover (31) and gasket (32)	Remove from cylinder block as a unit.	
24. Inner and outer exhaust cover	Separate.	
25. Armature plate stop bumper (33)	Pull off capscrew (34).	
26. Capscrew (34) and nut (35)	Remove from cylinder block (8).	

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

5-9. ENGINE DISASSEMBLY/ASSEMBLY - continued

ASSEMBLY

- | | | |
|---|--|--|
| 1. Capscrew (34) and nut (33) | Install in cylinder block (8). | |
| 2. Armature plate stop bumper (33) | Install on capscrew (34). | |
| 3. Bracket (13) | Position on cylinder block (8). | |
| 4. Capscrew (11) and lockwasher (12) | Install. | |
| 5. Inner (31) and outer (29) exhaust cover and gaskets (30, 32) | Assemble and position on cylinder block. | |
| 6. Capscrews (27) | Install. | |
| 7. Upper (21) and lower (22) by-pass covers and gaskets (23) | Position on cylinder block. | |
| 8. Capscrews (20) | Install. | |
| 9. Hoses (24) and (25) with clamps (26) and (27). | Install on by-pass covers | |




Figure 5-11. Piston installation

CAUTION

Compress the piston ring with ring compressor (326592). Do not use an automotive type ring compressor. Be sure each piston goes back into the correct cylinder. Be sure the intake side of the piston deflector is toward the intake part.

- | | | |
|---|--|--|
| 10. Pistons and connecting rod assemblies | Coat with oil and install in cylinder block. | |
| 11. Connecting rod bearing caps. | Remove. | |

NOTE

Be sure both upper and lower main bearings seat in their locating dowels in the cylinder block.

- | | | |
|----------------|--|--|
| 12. Crankshaft | Position in cylinder block with connecting rod bearings against crankshaft journals. | |
|----------------|--|--|




Figure 5-12. View of deflectors

LOCATION/ITEM	ACTION	REMARKS
5-9. ENGINE DISASSEMBLY/ASSEMBLY - continued		
13. Needle bearings and retainers.	Install. CAUTION two end needles in positon. Rods and caps have fracture joints that must match perfectly. Snug rod cap screws and feel machined surface of rod with finger nail. If alignment is not perfect, tap rod cap lightly with a mallet from several directions and snug screws again when alignment is correct, torque screws to 29-31 ft. lb. (40-42 N•m).	Smear a little heavy grease in connecting rod. Place retainer half in con rod and install 6 needles. Bring up to crankshaft. Using grease to hold needles, place Put other retaining half in place and install remaining needles. Put rod cap in place and install screws finger-tight. Then install bearings in other rod the same way.
14. Connecting rod bearing caps	Install and tighten to a torque of 29-31 lb. ft. (40-42 N•m).	
15. Crankcase 327361 and position on cylinder block.	Apply sealant OMC no.	
16. Four large capscrews (16) and washers (17)	Install finger-tight.	
17. Two allen screws (18)	Install finger-tight.	

LOCATION/ITEM	ACTION	REMARKS
5-9. ENGINE DISASSEMBLY/ASSEMBLY - continued		
18. Eight small capscrews (15)	Install finger-tight.	
19. Taper pins (14)	Install snugly with light taps of a hammer.	This will align the crankcase to cylinder block.
20. Large capscrews (16)	Tighten to a torque of 18-20 lb. ft. (24-27 N•m).	
21. Allen screws (18)	Tighten.	
22. Large retaining ring	Install on crankshaft.	
23. Lower main bearing seal housing	Place on crankshaft.	
24. Cylinder head (6) and gasket (7)	Position on cylinder block.	
25. Capscrews (4)	Install.	Install lift bracket (5) when installing capscrews (4).
26. Cylinder head cover (2) and gasket (3)	Position on cylinder head.	
27. Capscrews (1)	Install and tighten to a torque of 14-16 lb. ft. (19-22 N•m) Tighten in the sequence shown at right.	
28. Engine	Install in exhaust housing.	See para. 5-8.




Figure 5-13. Cylinder head bolt tightening sequence

5-10. CRANKSHAFT AND PISTONS DISASSEMBLY/ASSEMBLY

This task covers:

Disassembly and assembly of crankshaft and pistons (including bearings).

INITIAL SETUP :

Tools:

- TB Engine holder - 303605
- T10 Retaining ring tool - 303859
- T9 Piston ring compressor - 326592
- Micrometer
- T1 5180-00-177-7033
- T2 4910-00-754-0705

Equipment Condition:

Engine removed and held in tool no. 303605.

Materials/Parts:

As required

Personnel Required:

1 mechanic

Approximate Time Required (minutes):

80

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

REMOVAL

Follow steps 1 thru 12, para. 5-9.

See para. 5-9, steps 1 thru 12.

Be careful not to scratch or mar components of the assembly when removing.

DISASSEMBLY

1. Retaining ring (1)	Remove.	Use tool no. 303859.
2. Crankcase head (2)	Remove.	
3. "O" ring (3)	Remove from head (2).	
4. Seals (4)	Remove.	
5. Snap ring (5)	Remove.	Use tool no. 303859.
6. Roller bearing (6)	Remove.	Use gear puller.
7. "O" ring (7)	Remove.	
8. Seal (8)	Remove	Support head on blocks and drive out with seal driver.
9. Roller bearing (9)	Remove.	

5-10. CRANKSHAFT AND PISTONS DISASSEMBLY/ASSEMBLY - continued

- 1. Snap ring
- 2. Head
- 3. O-ring
- 4. Seal
- 5. Retaining ring
- 6. Roller bearing
- 7. O-ring
- 8. Seal
- 9. Roller bearing
- 10. O-ring
- 11. Key
- 12. Capscrew
- 13. Retainer
- 14. Needles
- 15. Piston rings
- 16. Retaining ring
- 17. Wrist pin
- 18. Bearing
- 19. Split sleeve
- 20. Retainer and needles
- 21. Piston
- 22. Crankshaft.




Figure 5-14. Crankcase and piston assembly

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

5-10. CRANKSHAFT AND PISTONS DISASSEMBLY/ASSEMBLY - continued

- 10. "O" ring (10) Remove.
- 11. Key (11) Remove.
- 12. Connecting rod cap-screws (12) Remove.

CAUTION
 Pistons, connecting rods and caps are matched parts and seat with the operation of the motor. Because of this, it is essential to maintain their original positions at reassembly. Mark each connecting rod and cap, piston, and bearing component to assure correct mating when they are reassembled. Also mark the cylinders from which they are removed.




Figure 5-15. Piston - "loose" boss

- 13. Connecting rod caps Remove.
- 14. Needle bearing retainers (13) and bearings (14) Remove.
- 15. Piston rings (15) Remove and discard.
- 16. Retaining rings (16) Remove.

CAUTION
 One piston boss is bored larger than the other for a loose fit. The inside of the piston is marked with an "L" for "loose," on the larger side. Lay the piston down in a piston cradle with the loose side down and drive out the wrist pin from the tight side.




Figure 5-16. Driving out the wrist pin

- 17. Wrist pin (17) Remove.
- 18. Wrist pin bearing (18) Press out.
- 19. Center bearing retaining ring Lift out of groove and slide aside.
- 20. Center bearing split sleeve halves (19) Remove from crankshaft center journal.
- 21. Center bearing needle bearing retainers and needle bearings (20). Remove.




Figure 5-17. Crankshaft center bearings

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

5-10. CRANKSHAFT AND PISTONS DISASSEMBLY/ASSEMBLY - continued

ASSEMBLY

CAUTION
Oil all components with 50/1 lubricant before assembly.

- | | |
|--|--|
| 1. Center needle bearings and retainers (20) | Position on crankshaft center journal. |
| 2. Center bearing split sleeve halves (19) | Position over bearing retainers (20). |
| 3. Center bearing retainer ring | Install in groove in split sleeve. |
| 4. Wrist pin bearing (18) | Press into connecting rod. |

CAUTION
Be sure to install pistons on connecting rods so the intake side of the deflector will be toward the intake port of the cylinder block when pistons and crankshaft are installed.

- | | |
|--|---------------------|
| 5. Connecting rod and wrist pin bearing. | Position in piston. |
|--|---------------------|

CAUTION
Be sure to press in wrist pin from the loose side (marked "L," or "loose" inside piston to the tight side.

- | | |
|------------------------------|-----------------------------|
| 7. Retaining rings (16) pin. | Install in grooves in wrist |
|------------------------------|-----------------------------|




Figure 5-18 View of deflectors

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

5-10. CRANKSHAFT AND PISTONS DISASSEMBLY/ASSEMBLY - continued

ASSEMBLY

8. Pistons (21) Check with micrometer to see if piston has become distorted during assembly. the pistons at the bottom (skirt).

MICROMETER CHECK

Take micrometer readings of the outside diameter of Take two readings, 90° apart.

9. Pistons (21) Replace if the variation in the readings at the skirt are greater than 0.0025 in. (0.0064 cm).

CAUTION
Be sure rings fit freely. Be sure the retaining pin in the piston groove is in the center of the piston ring gap.




Figure 5-19. Micrometer check of pistons

10. Piston rings (15) Install on pistons.

11. "O" ring (10) Slide on to crankshaft (22).

12. Seal (8) Install.

13. Bearing (9) Slide on to crankshaft (22).

14. "O" ring (7) Install in crankshaft (22).

15. Bearing (6) Press on to crankshaft (22).

16. Snap ring (5) Install in groove behind bearing (6). Use snap ring tool no. 303859.

17. Seals (4) Install back-to-back in crankcase head (2).

18. "O" ring (3) Install in groove in crankcase head (2).

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

5-10. CRANKSHAFT AND PISTONS DISASSEMBLY/ASSEMBLY - continued

19. Crankcase head assembly (2)	Install on crankshaft.	
20. Snap ring (1)	Install.	Use retaining ring tool 303859.
21. Key (11)	Install in keyway.	
CAUTION Be sure of installing the correct bearings and bearing caps on the correct connecting rods and crankshaft journals.		
22. Needle bearings (14) and retainer (13)	Install one half of set in connecting rod.	
23. Piston connecting rod bearing assembly	Install on crankshaft journal.	Smear a little heavy grease in connecting rod. Place retainer half in con rod and install 6 needles. Bring rod up to crankshaft. Using grease to hold needles,
24. Needle bearings (14) and retainer (13) bearing cap.	Place bottom half on crankshaft journal and install	place two end needles in position. Put other retaining half in place and install remaining needles. Put rod cap in place and install screws finger-tight. Then install bearings in other rod the same way.
25. Capscrews (23) torque of 29-31 lb. ft. (40-42 N•m).	Install and tighten to a	

INSTALLATION

1. Piston and connecting rods assembly	Install in cylinder block.	
NOTE Lubricate cylinder walls and pistons before installation. Use ring compressor 326592 to compress piston rings.		
2. Follow steps 23-29, para. 5-9		CAUTION Rods and caps have fracture joints that must match perfectly. Snug rod cap screws and feel machined surface of rod with finger nail. If alignment is not perfect, tap rod cap lightly with a mallet from several directions and snug screws again when alignment is correct, torque screws to 29-31 ft. lb. (40-42 N•m).

Section V. EXHAUST HOUSING ASSEMBLY

MAINTENANCE SUMMARY. This task covers:

- a. Steering and swivel brackets removal/installation/disassembly/assembly
- b. Exhaust housing removal/installation
- c. Steering handle repair

INITIAL SETUP

Personnel Required	General Safety Instructions
1	None

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Steering and swivel bracket removal/ installation/disassembly/assembly	Para. 5-1 1	
2	Exhaust housing removal/ installation	Para. 5-12	
3	Steering handle disassembly/ assembly	Para. 5-13	

5-11. STEERING AND SWIVEL BRACKETS REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION

This task covers:

Removal/Disassembly/Assembly/Installation of the steering and swivel brackets.

INITIAL SETUP:

Tools:

- T1 5180-00-177-7033
- T2 4910-00-754-0705

Equipment Condition:

Motor suspended from lift bracket

Materials/Parts:

As required

Personnel Required:

1 mechanic

Approximate Time Required (minutes):

120

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Engine	Remove.	See para. 5-8.
2. Lower motor cover	Remove.	See para. 5-5.
3. Stern brackets (1) and (2)	Remove.	See para. 4-29.
4. Acorn nuts (3), cap-screws (4) and (5) and lockwashers (6)	Remove.	
5. Housings (7)	Remove.	
6. Both lower rubber mounts (8) and bumper (9)	Remove from housings (7).	Replace any rubber mounts that are worn or deteriorated.
7. Capscrew (10) and lockwasher (11)	Remove.	
8. Lower front rubber mount (12) and gasket (13)	Remove.	
9. Nuts (14) and washers (15)	Remove.	
10. Capscrews (16) and washers (17)	Remove.	

LOCATION/ITEM	ACTION	REMARKS
5-11. STEERING AND SWIVEL BRACKETS REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continued		
11. Nut (15) and washer (19)	Remove.	
12. Upper front rubber mount (20)	Remove from exhaust housing.	
13. Steering friction adjustment screw (21)	Loosen.	
14. Steering bracket assembly (22) and swivel bracket assembly (23)	Lift away from exhaust housing (24).	
15. Upper rubber side mounts (25)	Remove.	
16. Steering bracket (22)	Lift out of swivel bracket assembly (23)	

DISASSEMBLY

- Reverse lock spring (26) Stretch slightly, lift off retainer at top of swivel bracket and detach from reverse locking lever (27).
- Cotter pin (28) Remove.
- Reverse lock rod (29) Remove from swivel bracket and reverse locking lever (27).
- Reverse lock shaft (30) and link (31) Remove from swivel bracket and reverse lock links (32).

LOCATION/ITEM	ACTION	REMARKS
5-11. STEERING AND SWIVEL BRACKETS REMOVAL/DISASSEMBLY/ ASSEMBLY/INSTALLATION - continued		




Figure 5-20. Lower unit

LOCATION/ITEM	ACTION	REMARKS
5-11. STEERING AND SWIVEL BRACKETS REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continued		
1. Stern bracket		24. Exhaust housing assembly
2. Stern bracket		25. Mount
3. Acorn nut		26. Spring
4. Capscrew		27. Reverse locking lever
5. Capscrew		28. Cotter pin
6. Lockwasher		29. Rod
7. Housing		30. Shaft
8. Bumper		31. Link
9. Mount		32. Link
10. Capscrew		33. Spacer
11. Washer		34. O-ring
12. Mount		35. Liner
13. Gasket		36. Thrust washer
14. Nut		37. Liner
15. Washer		38. Plate
16. Capscrew		39. Spacer
17. Washer		40. Capscrew
18. Nut		41. Connector
19. Washer		42. Gear
20. Mount		43. Capscrew
21. Capscrew		44. Pinion
22. Steering bracket		45. Washer
23. Swivel bracket		46. Throttle shaft

LOCATION/ITEM	ACTION	REMARKS
5-11. STEERING AND SWIVEL BRACKETS REMOVAL/DISASSEMBLY/ ASSEMBLY/INSTALLATION - continued		
5. Spacer (33), "O" ring (34) and liner (35)	Remove from bottom of swivel bracket.	
6. Thrust washer (36) and liner (37)	Remove from top of swivel bracket.	
7. Plate (38) and spacer (39)	Remove.	
8. Capscrew (40)	Remove.	
9. Fuel connector (41)	Remove.	
10. Throttle control gear (42)	Slide up and out of steering bracket (22).	
11. Capscrew (43) control pinion (44).	Remove from throttle	
12. Throttle control pinion (44) and washer (45)	Slide off throttle shaft (46).	
ASSEMBLY		
1. Washer (45) and throttle control pinion (44)	Slide on throttle shaft (46).	
2. Capscrew (43)	Install but do not tighten.	
3. Throttle control gear (42)	Slide into position on steering bracket (22).	Mesh gears (42) and (44) and rotate back and forth a few times to seat teeth.
4. Capscrew (43)	Tighten.	

LOCATION/ITEM	ACTION	REMARKS
5-11. STEERING AND SWIVEL BRACKETS REMOVAL/DISASSEMBLY/ ASSEMBLY/INSTALLATION - continued		
5. Fuel connector (41)	Position on steering bracket.	
6. Capscrew (40)	Install.	
7. Spacer (39) and (38)	Install in swivel bracket (23).	
8. Liner (37) and thrust washer (36)	Install in top of swivel bracket.	
9. Liner (35), "O" ring (34) and spacer (33)	Install in bottom of swivel bracket.	
10. Reverse lock links (32)	Position on swivel bracket.	
11. Reverse lock shaft (30)	Install.	
12. Link (31)	Install.	
13. Reverse locking lever (27)	Position on swivel bracket,	
14. Reverse lock rod (29)	Install.	
15. Cotter pin (28)	Install.	
16. Spring (26)	Install.	
INSTALLATION		
1. Steering bracket (22)	Install in swivel bracket (23).	
2. Side mounts (25)	Position on exhaust housing (24).	

LOCATION/ITEM	ACTION	REMARKS
5-11. STEERING AND SWIVEL BRACKETS REMOVAL/DISASSEMBLY/ ASSEMBLY/INSTALLATION - continued		
3. Capscrews (16) and washers (17)	Install.	
4. Steering and swivel bracket assembly	Position on exhaust housing on rubber side mount (25).	
5. Nuts (14) and washers (15)	Install and tighten to a torque of 12-13 lb. ft. (17-18 N•m).	
6. Upper front rubber mount (20)	Install in exhaust housing and steering bracket with nut (18) and washer (19). Tighten to a torque of 21-26 lb. ft. (28-35 N•m).	
7. Lower front rubber mount (12) and gasket (13)	Install on exhaust housing.	
8. Rubber mounts (8), (9) and gaskets, bumper retainer and screw	Position in side mounts (7).	
9. Side mounts (7)	Position on exhaust housing and steering bracket.	
10. Capscrews (4), (5) and lockwashers (6) and nuts (3)	Install and tighten to a torque of 10-12 lb. ft. (14-16 N•m).	

LOCATION/ITEM	ACTION	REMARKS
5-11. STEERING AND SWIVEL BRACKETS REMOVAL/DISASSEMBLY/ASSEMBLY/INSTALLATION - continued		
11. Stern brackets (1) and (2)	Install.	See para. 4-29. Place unit on workstand.
12. Steering friction screw (21)	Tighten.	See para. 2-14.
13. Lower motor cover	Install.	See para. 5-5.
14. Engine	Install.	See para. 5-8.

5-12. EXHAUST HOUSING REMOVAL/INSTALLATION

This task covers:

Replacement of exhaust housing

INITIAL SETUP :

Tools:

T1 5180-00-177-7033
T2 4910-00-754-0705

Equipment Condition:

Follow procedure

Materials/Parts:

As required

Personnel Required:

1 mechanic

Approximate Time Required (minutes):

120

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

REMOVAL

1. Engine	Remove.	See para. 5-8.
2. Lower motor cover	Remove.	See para. 5-5.
3. Steering and swivel brackets	Remove.	See para. 5-11.
4. Gearcase and exhaust removal/disassembly/housing extension	Remove.	See para. 4-36, water pump assembly/installation.
5. Shift lever	Remove.	See para. 4-34.
6. Cotter pins (1)	Remove.	
7. Upper shift rod (2)	Disengage from connector (3) and remove.	
8. Connector (3)	Unscrew from shift bracket and shaft (4) and remove.	

NOTE


Do not let nut (5) fall into exhaust housing.

LOCATION/ITEM	ACTION	REMARKS
5-12. EXHAUST HOUSING REMOVAL/INSTALLATION - continued		

- | | | |
|----------------------------------|----------------------------------|--|
| 9. Bracket and shaft (4) | Remove. | |
| 10. "O" ring (6) and bushing (7) | Remove from exhaust housing (8). | |
| 11. Grease fitting (9) | Remove. | |
| 12. Capscrew (10) and cover (11) | Remove. | |
| 13. Water tube (12) | Remove. | |

ASSEMBLY

- | | | |
|--|--|------------------------------|
| 1. Cover (11) | Install and secure with capscrew (10). | |
| 2. Grease fitting (9) | Install. | |
| 3. Bushing (7) | Insert in exhaust housing | |
| 4. "O" ring (6) shaft (4). | Install on shift bracket | |
| 5. Shift bracket and shaft (4) | Install. | |
| 6. Connector (3) and nut (5) | Install on shift bracket shaft (4). | |
| 7. Upper shift rod (2) (3) with cotter pins (1). | Install. | Fasten to connector |
| 8. Water tube (12) | Install. | Figure 5-21. Exhaust housing |
| 9. Shift lever | Install. | See para. 4-34. |



1. Cotter pin
2. Upper shift rod
3. Connector
4. Bracket and shaft
5. Nut
6. O-ring
7. Bushing
8. Exhaust housing
9. Grease fitting
10. Capscrew and washer
11. Cover
12. Water tube

LOCATION/ITEM	ACTION	REMARKS
5-12. EXHAUST HOUSING REMOVAL/INSTALLATION - continued		
10. Gearcase and exhaust removal/disassembly/	Install.	See para. 4-36, water pump assembly/installation
11. Steering and swivel bracket	install.	See para. 5-11.
12. Lower motor cover	Install.	See para. 5-5.
13. Engine	Install.	See para. 5-8.

5-13. STEERING HANDLE DISASSEMBLY/ASSEMBLY

This task covers:

Steering handle repair

INITIAL SETUP :

Tools:

- T1 5180-00-177-7033
- T2 4910-00-754-0705

Equipment Condition:

Motor on repair stand

Materials/Parts:

As required

Personnel Required:

1 mechanic


Approximate Time Required (minutes):

60

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

DISASSEMBLY

- | | | |
|------------------------------|---------------------------|-----------------|
| 1. Steering handle (1) | Remove. | See para. 4-31. |
| 2. Phillips head screw (2) | Remove. | |
| 3. Grip (3) | Slide off end of arm (4). | |
| 4. Friction blocks (5) | Remove. | |
| 5. Spring (6) and washer (4) | Remove. | |
| 6. Bushing (8) | Remove. | |
| 7. Groove pin (9) | Remove. | |
| 8. Throttle shaft (10) | Slide out of arm. | |



LOCATION/ITEM	ACTION	REMARKS
5-13. STEERING HANDLE DISASSEMBLY/ASSEMBLY -continued		
ASSEMBLY		
1. Throttle shaft (10)	Slide into arm (4).	
2. Groove pin (9)	Install in throttle shaft (10).	
3. Bushing (8)	Install on arm.	
4. Washer (7) and spring (6)	Position on arm.	
5. Friction block (5)	Place in grip (3).	
6. Grip (3) and friction block (5)	Position on arm so screw holes line up.	
7. Phillips head screw (2)	Install.	
8. Steering handle (1)	Install.	See para. 4-31.

Section VI. GEARCASE

MAINTENANCE SUMMARY. This task covers:

- a. Gearcase disassembly/assembly.
- b. Shift rod removal/installation.
- c. Gearcase tests.
- d. Driveshaft removal/installation.

INITIAL SETUP

Personnel Required	General Safety Instructions
1	

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Gearcase disassembly/assembly	Para. 5-14	
2	Shifter rod removal/installation	Para.	Part of gearcase disassembly/assembly.
3	Gearcase pressure and vacuum tests	Para. 5-15	
4	Driveshaft removal/installation	Para. 5-16	

5-14. GEARCASE DISASSEMBLY/ASSEMBLY

This task covers:

Gearcase disassembly/assembly

INITIAL SETUP

Tools:

- Gear puller
- T1 5180-00-177-7033
- T1 4910-00-754-0705

Equipment Condition:

Motor suspended by hoist attached to lift bracket

Materials/Parts:

As required

Personnel Required:

1 mechanic

Approximate Time Required (minutes):

180

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

DISASSEMBLY

CAUTION

Support gearcase while removing capscrews.

1. Gearcase	Remove.	See para. 4-36, water pump
2. Water pump	Remove (para.	4-36).
3. Gearcase	Drain through drain/fill plug (1).	
4. Shift rod pivot pin (2) and seal (3)	Remove.	

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

5-14. GEARCASE DISASSEMBLY/ASSEMBLY - continued

- 5. Propeller assembly (4) Remove.
- 6. Capscrews (5) attaching gearcase halves Remove.
- 7. Lower gearcase assembly Separate from upper gear assembly.
- 8. Cradle (6) and shifter lever (7) Swing up and out of the way. Remove cradle (6).
- 9. Lower gearcase assembly Remove.
- 10. Propeller shaft (8) and components Lift out of gearcase as a unit.
- 11. Pinion (9) Remove.

NOTE

Use a suitable gear puller to remove bearings and gears.

- 12. Bearing (10)
- 13. Forward gear (11) and thrust washer (12)

- Remove.
- Remove.

NOTE

The detent balls (17) and spring (18) will pop free when the clutch dog shifter is removed.

- 14. Clutch dog shifter (13)
- 15. Oil retainer (14), housing (15) and O-ring (16)
- 16. Bearing (19), thrust washer (20), bushing (21), reverse gear (22), and thrust washer (23)

- Slide off shaft (8).
- Remove.
- Remove.




Figure 5-23. Gearcase arrangement

Slide housing assembly off shaft. Remove O-ring and pry oil retainer from housing.

LOCATION/ITEM	ACTION	REMARKS
5-14. GEARCASE DISASSEMBLY/ASSEMBLY - continued		




Figure 5-24. Gearcase

LOCATION/ITEM	ACTION	REMARKS
5-14. GEARCASE DISASSEMBLY/ASSEMBLY - continued		
1. Oil level plug and washer		20. Thrust washer
2. Shift rod pivot pin		21. Reverse gear bushing
3. Seal		22. Reverse gear
4. Propeller assembly		23. Thrust washer
5. Capscrew		24. Cotter pin
6. Clutch dog cradle		25. Shift rod pin
7. Shifter lever		26. Lower shift rod
8. Propeller shaft		27. Seal
9. Pinion		28. Pinion bearing
29. Pinion washer		29. Pinion washer
10. Roller bearing assembly		30. Thrust bearing
11. Forward gear and bushing		31. Pinion washer
12. Thrust washer		32. Pinion bearing assembly
13. Clutch dog shifter		33. Seals
14. Oil retainer		34. Bearing
15. Housing		35. Shift rod bushing
16. O-ring		36. Gasket
17. Detent ball		37. Gasket
18. Detent spring		
19. Ball bearing		

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

5-14. GEARCASE DISASSEMBLY/ASSEMBLY - continued

- | | | |
|--|--|--|
| 17. Cotter pin (24) and shift rod pin (25) | Remove from shifter lever (7). Remove shift rods (26) from gearcase. | |
| 18. Seal (27) | Remove from crankcase half. | |

NOTE

Use an internal bearing puller and remove (38), (37), (36), (35), (34).

- | | | |
|--|----------------------------------|--|
| 19. Bearing (28) and pinion washer (29) | Remove from upper gearcase half. | |
| 20. Thrust bearing (30) and pinion washer (31) | Remove. | |
| 21. Pinion bearing assembly (32) | Remove. | |
| 22. Seals (33) | Remove. | |
| 23. Bearing (34) | Remove. | |
| 24. Bushing (35) | Remove. | |
| 25. O-ring (36) and gasket (37) | Remove. | |

ASSEMBLY

- | | | |
|--------------------------------|--|---|
| 1. Gasket (37) and O-ring (36) | Insert in exhaust housing. | |
| 2. Bushing (35) | Install in exhaust housing on top of O-ring and bushing. | Use a suitable mandrel to drive bushing into place. |
| 3. Bearing (34) and seals (33) | Install. | Use a suitable driver and install seals back-to-back. |

LOCATION/ITEM	ACTION	REMARKS
5-14. GEARCASE DISASSEMBLY/ASSEMBLY - continued		

- 4. Pinion bearing assembly (32)
- 5. Pinion washer (31) and thrust bearing (30)
- 6. Pinion washer (29) and bearing (28)

Install.
 Install.
 Install.

Oil propeller shaft for easier assembly.

CAUTION

Aline notches in clutch dog shifter over the detent balls. If they appear off-center, rotate clutch dog 1800. The machined groove on the clutch dog must face forward (away from the propeller end) of the shaft.

Chamfer on pinion washer (29) must face pinion gear (9).

- 7. Detent balls (17) and spring (18)
- 8. Thrust washer (23) and
- 9. Bearing (10)
- 10. Thrust washer (23) and reverse gear (22)
- 11. Bushing (21) and thrust washer (20)
- 12. Bearing (19)
- 13. Oil retainer (14), housing (15), and O-ring (16)
- 14. Lower shift rod (26)

Install in shaft (8) and hold in position while sliding the clutch dog shifter (13) onto shaft and into place over detent balls.
 Install on shaft (8). forward gear (11)
 Install.
 Install.
 Install.
 Install.
 Assemble and install on shaft.
 Position in shifter lever (7) and secure with shift rod pin (25) and cotter pin (24). Place cradle (6) on assembly.




Figure 5-25. Clutch dog shifter and shaft

LOCATION/ITEM	ACTION	REMARKS
5-14. GEARCASE DISASSEMBLY/ASSEMBLY - continued		
15. Shifter lever and shift rod assembly	Position in lower gearcase.	
	CAUTION	
	Rotate housing (15) and bearing (19) so the alining hole in these components engages dowel (8) in lower gearcase.	
16. Propeller shaft and gear assembly	Position in lower gearcase so shift cradle (6) engages slot in clutch dog shifter (13).	
17. Gearcase seal (27)	Install on lower gearcase.	Cut from bulk roll to a length of 16.094 (40.88 cm). (See para.F-4.)
18. Shift rod pivot pin (2) and seal (3)	Install so pin engages shifter lever properly.	
19. Lower gearcase position more easily.	Position on upper gearcase.	Oil lower shift rod (26) so it will slide into
20. Capscrews (5) gearcase.	Install in upper and lower	
21. Propeller assembly (4)	Install.	See para. 3-14.
22. Drive shaft and water pump assembly	Install.	See para. 4-36.
23. Gearcase	Install.	See para. 4-36.
24. Gearcase	Lubricate.	See para. 3-13 and LO 5-2805-261-12.
25. Shifter	Shift a few times to check for free movement.	

5-15. GEARCASE PRESSURE AND VACUUM TESTS

This task covers:

Testing gearcase for air and water tightness.

INITIAL SETUP

Tools:

- T11 Pressure test group - S34
- T12 Adaptor 389945
- T1 5180-00-177-7033
- T2 4910-00-754-0705

Equipment Condition:

Motor on test stand

Materials/Parts:

Container of water large enough to hold gearcase

Personnel Required:

1 mechanic

Approximate Time Required (minutes):

60

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

PRESSURE TEST

NOTE

Pressure and vacuum tests are performed at the same time.

- | | | |
|-------------------------------------|---------|----------------------------|
| 1. Lower unit removal/installation. | Remove. | See para. 4-36, water pump |
| 2. Propeller | Remove. | See para. 3-14. |
| 3. Drain/fill plug | Remove. | |
| 4. Gearcase | Drain. | |

NOTE

Be sure gearcase is completely empty before testing. Screw into drain/fill plug

- | | | |
|---------------------------------------|------------------------------------|---|
| 5. Pressure test group hole. | | |
| 6. Pressure test group (21-42 kPa). | Pump pressure to 3-6 psi gearcase. | Watch gage. If pressure drops, there is a leak in the |
| 7. Gearcase water. | Submerge in container of | Look for bubbles at source of leak. |
| 8. Gearcase | Repair as necessary. | If there are no leaks proceed to step 9. |
| 9. Pressure test group (110-124 kPa). | Pump pressure to 16-18 psi | If gage pressure drops perform steps 7 and 8. |

LOCATION/ITEM	ACTION	REMARKS
5-15. GEARCASE PRESSURE AND VACUUM TESTS - continued		

VACUUM TEST

- | | | |
|----------------------|---|--|
| 1. Vacuum test group | Screw into drain/fill plug hole. | |
| 2. Vacuum test group | Pump out to 19-32 in. (76-127 mm) of mercury. | Watch gage. If mercury drops (vacuum doesn't hold) there is a leak in the gearcase. |
| 3. Oil | Put around area of suspected leak. | If oil is drawn in or if leak stops, the seal in that area is defective and must be replaced. If there are no leaks proceed to step 4. |
| 4. Vacuum test group | Pump out to 97 in. (381 mm) of mercury. | If gage pressure drops perform step 3. |
| 5. Gearcase | Repair as necessary. | |




Figure 5-26. Gearcase pressure test

5-16. DRIVESHAFT REMOVAL/INSTALLATION

This task covers:

Removal/installation of the driveshaft

INITIAL SETUP

Tools:

- T1 5180-00-177-7033
- T2 4910-00-754-0705

Equipment Condition:

Motor on stand

Materials/Parts:

As required

Personnel Required:

1 mechanic

Approximate Time Required (minutes):

60

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

REMOVAL

- | | | |
|---------------|---------|--|
| 1. Gearcase | Remove. | See para. 4-36, water pump removal/installation. |
| 2. Water pump | Remove. | See para. 4-36, water pump removal/installation. |
| 3. Driveshaft | Remove. | |

INSTALLATION

- | | | |
|---------------|----------|-----------------|
| 1. Driveshaft | Install. | |
| 2. Water pump | Install. | See para. 4-36. |
| 3. Gearcase | Install. | See para. 4-36. |

APPENDIX A

REFERENCES

A-1. SCOPE.

This appendix lists all forms, field manuals, and technical manuals referenced in this manual.

A-2. FORMS.

Equipment Inspection and Maintenance
 Work Sheet.....DA Form 2404
 Quality Deficiency ReportSF 368
 Recommended Changes to.....
 DA PublicationsDA Form 2028

A-3. TECHNICAL MANUALS.

Operator, Organizational and DS Maintenance
 Manual, Outboard Motor, Gasoline,
 Model AM-40A..... TM 5-2805-261-13
 Organizational and DS Maintenance Repair
 Parts and Special Tools List, Outboard
 Motor, Gasoline, Model AM40A..... TM 5-2805-261-23P
 The Army Maintenance Management
 System (TAMMS) TM 38-750

A4. MISCELLANEOUS PUBLICATIONS.

Lubrication Order, Outboard Motor
 Gasoline, Model AM-40A LO 5-2805-261-12



A-1/(A-2 blank)

APPENDIX B

BASIC ISSUE ITEMS AND INTEGRAL COMPONENTS OF END ITEM

Section I. INTRODUCTION

B-1. SCOPE. This appendix lists Outboard Motor Basic Issue Items (BII) for the Outboard Motor to help you inventory items required for safe and efficient operation.

B-2. GENERAL. Section II. Basic Issue Items. These are minimum essential items required to place the outboard motor in operation, to operate it and to perform emergency repairs. Although shipped separately packed, they must accompany the outboard motor during operation and whenever it is transferred between accountable officers.

Section III. Integral Components of End Item. These items are necessary for the function of the motor and must accompany it whenever it is transferred or turned in. This manual is your authority to requisition replacement BII based on Table(s) of Organization and Equipment (TOE)/Modification Table of Organization and Equipment (MTOE) authorization of the end item.

B-3. EXPLANATION OF COLUMNS.

- a. Illustration. This column is divided as follows:
 1. Figure Number. Indicates the figure number of the illustration on which the item is shown (if applicable).
 2. Item Number. The number used to identify item called out in the illustration (if applicable).
- b. National Stock Number (NSN). Indicates national stock number assigned to the end item which will be used for requisitioning (if applicable).
- c. Part Number (P/N). Indicates the primary number used by the manufacturer which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards and inspection requirements to identify an item or range of items.
- d. Description. Indicates the federal item name and, if required, a minimum description to identify the item.
- e. Location. The physical location of each item listed is given in this column. The lists are designed to inventory all items in one area of the major item before moving on to an adjacent area.
- f. Usable on Code. "Usable On" codes are included to help you identify which component items are used on the different models (if applicable).
- g. Quantity Required (Qty Reqd). This column lists B-1 the quantity of each item required for a complete major item.
- h. Quantity. This column is left blank for use during inventory. Under the received column, list the quantity you actually receive on your major TM 5-2805-261-13 item. The date columns are for use when you inventory the major item at a later date, such as Section II. BASIC ISSUE ITEMS for shipment to another site.

Section II. BASIC ISSUE ITEMS

(1) ILLUSTRATION		(2) NATIONAL STOCK NUMBER	(3) PART NO. AND FSCM	(4) DESCRIPTION	(5) LOCATION	(6) USABLE ON CODE	(7) QTY REQD	(8) QUANTITY			
(a) FIGURE NO.	(b) ITEM NO.							REV'D	DATE	DATE	DATE
		531500-089-8968	329400 (80256)	Plug, spark		2					
				306394 (32195)	Key, cotter		2				
		5120-00-104-4155	329585 (32195)	Propeller		1					
				GGG-P471 (81348)	Pliers		1				
		5120-00-227-7338	389933 (80256)	Wrench, spark plug		1					
				GGG-S-121 (81348)	Screw driver		1				
		7520-00-559-9618	MIL-L-11743 (81349)	Case, operation and maintenance publication Department of the Army Publications		1					
		5315-00-504-8826	TM 5-2805-261-13	Operator, organizational and direct support maintenance		1					
				LO 5-2805-261-12	Lubrication Order		1				
			304575 (32195)	Pin, propeller drive		1					

Section III. INTEGRAL COMPONENTS OF END ITEM

(1) ILLUSTRATION		(2) NATIONAL STOCK NUMBER	(3) PART NO. AND FSCM	(4) DESCRIPTION	(5) LOCATION	(6) USABLE ON CODE	(7) QTY REQD	(8) QUANTITY			
(a) FIGURE NO.	(b) ITEM NO.							REV'D	DATE	DATE	DATE
		2910-00-353-1794	377331 (32195)	Tank assembly	Motor chest	1					
		--	--	Chest, motor	--	1					

**APPENDIX C
MAINTENANCE ALLOCATION CHART
SECTION I
INTRODUCTION**

C-1. General

a. This section provides a general explanation of all maintenance and repair functions authorized at various maintenance levels.

b. The Maintenance Allocation Chart (MAC) in Section II designates overall authority and responsibility for the performance of maintenance functions on the identified end item or component. The application of the maintenance functions to the end item or component will be consistent with the capacities and capabilities of the designated maintenance levels.

c. Section III lists the tools and test equipment (both special tools and common tool set s) required for each maintenance function as referenced from Section II.

d. Section IV contains supplemental instructions and explanatory notes for a particular maintenance function.

C-2. Maintenance functions. Maintenance functions will be limited to and defined as follows:

a. **Inspect.** To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination (e.g, by sight, sound or feel).

b. **Test.** To verify serviceability by measuring the mechanical, pneumatic, hydraulic, or electrical characteristics of an item and comparing those characteristics with prescribed standards.

c. **Service.** Operations required periodically to keep an item in proper operating condition, i.e., to clean (includes decontaminate when required), to preserve, to drain, to paint, or to replenish fuel, lubricants, chemical fluids, or gases.

d. **Adjust.** To maintain or regulate, within prescribed limits, by bringing into proper or exact position, or by setting the operating characteristics to specified parameters.

e. **Aline.** To adjust specified variable elements of an item to bring about optimum or desired performance.

f. **Calibrate.** To determine and cause corrections to be made or to be adjusted on instruments or tests, measuring, and diagnostic equipments used in precision measurement. Consists of comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.

g. **Remove/Install.** To remove and install the same item when required to perform service or other maintenance functions. Install may be the act of emplacing, seating, or fixing into position a spare, repair part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.

h. **Replace.** To remove an unserviceable item and install a serviceable counterpart in its place. "Replace" is authorized by the MAC and is shown as the 3d position code of the SMR code.

i. Repair. The application of maintenance services, including fault location/troubleshooting, removal/installation, and disassembly/assembly procedures, and maintenance actions to identify troubles and restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.

j. Overhaul. That maintenance effort (service/action) prescribed to restore an item to a completely serviceable/operational condition as required by maintenance standards in appropriate technical publications (i.e., DMWR). Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like new condition.

k. Rebuild. Consists of those services/actions necessary for the restoration of unserviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of maintenance performed by the Army equipment. The rebuild operation includes the act of returning to zero those age measurements (hours/miles, etc.) considered in classifying Army equipment/components.

C-3. Explanation of Columns in the MAC, Section II.

a. Column 1, Group Number. Column 1 lists functional group code numbers, the purpose of which is to identify maintenance significant components, assemblies, sub-assemblies, and modules with the next higher assembly. End item group number shall be "00." b. Column 2, Component/Assembly. Column 2 contains the names of components, assemblies, subassemblies, and modules for which maintenance is authorized.

c. Column 3, Maintenance Function. Column 3 lists the functions to be performed on the item listed in Column 2. (For detailed explanation of these functions, see paragraph B-2).

d. Column 4, Maintenance Level. Column 4 specifies, by the listing of a work time figure in the appropriate subcolumn(s), the level of maintenance authorized to perform the function listed in Column 3. This figure represents the active time required to perform that maintenance function at the indicated level of maintenance. If the number or complexity of the tasks within the listed maintenance function vary at different maintenance levels, appropriate work time figures will be shown for each level. The work time figure represents the average time required to restore an item (assembly, subassembly, component, module, end item, or system) to a serviceable condition under typical field operating conditions. This time includes preparation time (including any necessary disassembly/assembly time), troubleshooting/fault location time, and quality assurance/quality control time in addition to the time required to perform the specific tasks identified for the maintenance functions authorized in the maintenance allocation chart. The symbol designations for the various maintenance levels are as follows:

- C Operator or crew
- O Unit Maintenance
- F Intermediate Direct Support Maintenance
- H Intermediate General Support Maintenance
- L Specialized Repair Activity (SRA)
- D Depot Maintenance

e. Column 5, Tools and Equipment. Column 5 specifies by code those common tool sets (not individual tools) and special tools, TMDE and support equipment required to perform the designated function.

f. Column 6, Remarks. This column shall, when applicable, contain a letter code in alphabetic order, which shall be keyed to the remarks contained in Section IV.

C-4. Explanation of Columns In Tool and Test Equipment Requirements, Section III.

- a. Column 1, Reference Code. The tool and test equipment reference code correlates with a code used in the MAC, Section II, Column 5.
- b. Column 2, Maintenance Category. The lowest category of maintenance authorized to use the tool or test equipment.
- c. Column 3, Nomenclature. Name or identification of the tool or test equipment.
- d. Column 4, National Stock Number. The National Stock Number of the tool or test equipment.
- e. Column 5, Tool Number. The manufacturer's part number.

C-5. Explanation of columns in Remarks, Section IV.

- a. Column 1, Reference Code. The code recorded in Column 6, Section II.
- b. Column 2, Remarks. This column lists information pertinent to the maintenance function being performed as indicated in the MAC, Section II.

Section II. MAINTENANCE ALLOCATION CHART

(1) GROUP NUMBER	(2) COMPONENT/ ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE LEVEL					(5) TOOLS AND EQUIPMENT	(6) REMARKS
			UNIT		INTERMEDIATE	DEPOT			
			C	O	F	H	D		
01	Cover Assembly Cover Motor	Inspect Replace Repair	.01 .01		3.0			T1 T1, T2	
02	Starting System- Starter Rewind	Inspect Replace Repair	01 02	1.0				T1, T3, T4, T5 T1, T3, T5, T6	
03	Magneto Flywheel Assy	Inspect Replace		02 05				1, T3 1, T7	A
	Ignition Coil Assy	Test Replace		02 07				1, T7	
	Condenser	Test Replace		02 05				T1	
	Break points	Test Replace		03 07				T1 T13	
	Wiring	Inspect Test Replace	01	02 04				T1, T7 T1, T7	
	Shorting Switch Assy	Inspect Test Replace		01 02 03				T1 T1	
04	Fuel Tank- Tank Assy	Inspect Test Replace		01 07 02				T, T11, T12 T1	
05	Fuel Pump Pump Assy	Inspect Replace	01	T1 02				T1	
06	Carburetor Carburetor Assy	Inspect Adjust Replace Repair Overhaul		01 01 08	1.0 1.0			T1 T1, T3, T6 T1, T2, T6 T1, T2, T6	A

Section II. MAINTENANCE ALLOCATION CHART

(1) GROUP NUMBER	(2) COMPONENT/ ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE LEVEL					(5) TOOLS AND EQUIPMENT	(6) REMARKS
			UNIT		INTERMEDIATE		DEPOT		
			C	O	F	H	D		
07	Needle Valve Assy	Inspect Replace		.01 .01				T1	
	Intake Manifold Assy	Inspect Replace		05	1.6			T1, T2	
08	Leaf Plate Assy	Inspect Replace			05 1.3			T1, T2	
	Crankshaft Crankshaft and Piston	Inspect Replace			1.3 5.5			T1, T2 T1, T2, T8, T9, T10	
09	Bearings	Inspect Replace			1.0 4.0				
	Cylinder and Crankcase Cylinder and Crankcase Assy	Inspect Replace Repair		0.2	06 4.0			T1, T2 T1, T2, T8, T9, T10	A
10	Spark Plug	Inspect Adjust Replace	.01 .03 .03					T1 T1	
	Cylinder Head	Inspect Replace		.02	.06				
10	Exhaust Housing Exhaust Housing Assy	Inspect Replace	.01		2.0			T1, T2	
	Steering/Handle Throttle	Inspect Service Adjust Replace Repair	.01 .01 .01	.05	1.0			T1 T1 T1, T2	
	Steering and Swivel Bracket	Inspect Replace		05	2.0			T1, T2	

Section II. MAINTENANCE ALLOCATION CHART

(1) GROUP NUMBER	(2) COMPONENT/ ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE LEVEL					(5) TOOLS AND EQUIPMENT	(6) REMARKS
			UNIT		INTERMEDIATE	DEPOT			
			C	O	F	H	D		
11	Stern Bracket	Inspect	.01					T1	
		Replace	.	05					
	Screw Assy Clamp	Inspect	.01					T1	
		Replace	.02						
	Shifter Lever	Inspect	.01					T1 T1	
		Adjust		.02					
		Replace		.05					
	Gearcase Assy	Inspect	.01					1, T2 T1, T2, T11 1, T2	
		Replace			1.0				
		Service	.02						
Test Repair				1.0 3.0					
Driveshaft	Inspect			.04			1, T2		
	Replace			.08					
Water Pump	Inspect		1.0				T1 T1		
	Replace		1.0						
	Repair		1.0						
Engine Temperature	Test		.5				Markai Thermomelt Stik		
Water Intake Screen	Inspect			.02			T1 T1		
	Replace			.02					
	Service			.02					
Shifter Rod and Shifter Shaft	Inspect			.01			1, T2		
	Replace			1.0					
Propeller	Inspect		.01				T1		
	Replace		.02						

Section III. TOOL AND TEST EQUIPMENT REQUIREMENTS

(1) Ref- ence Code	(2) Maintenance Level	(3) Nomenclature	(4) National/ NATO Stock Number	(5) Tool Number
T1	C,O,F,H	Tool Kit, General Mechanic, Automotive	5180-00-177-7033	
T2	F	Shop Set, Automotive Repair, Field Maintenance, Basic	4910-00-754-0705	
T3	O	Shop Equipment Automotive Maintenance and Repair: Organi- zation, Common No. 1	4910-00-754-0654	
T4	O	Spring winder	392093	
T5	O	Rope starter	378714	
T6	C,O,F	Hose clamp wrench	325043	
T7	O	Stevens S-80, or mercontronic tester, ignition, AC,DC circuit.	ST75C	
T8	F	Engine holder	303605	
T9	F	Piston ring compressor	326592	
T10	F	Retaining ring pliers	303859	
T11	O,F	Tester	S34	
T12	O,F	Adapter	389945	
T13	O	Timing fixture	386635	

SECTION IV, REMARKS

(1) Reference Code	(2) Remarks
A	Complete Kit is available

C-8 Change 2

APPENDIX D

ADDITIONAL AUTHORIZATION LIST

Section I. INTRODUCTION

D-1. SCOPE. This appendix lists additional items you are authorized for the support of the outboard motor

D-2. GENERAL. This list identifies items that do not have to accompany the outboard motor and that do not have to be turned in with it. These items are authorized to you by CTA, MTOE, TDA or JTA.

D-3. EXPLANATION OF LISTING. National stock number, descriptions, and quantities are provided to help you identify and request the additional items you require to support this equipment. "USABLE ON" codes are identified as follows:

Code	Used On
MAA	Model AM-40A

(1) National Stock Number	(2) Part Number & FSCM	Description	(3) Usable On Code	(4) U/M	Qty Auth
7520-00-559-9618		Cotton Duck Case	MAA	EA	1

D-1/(D-2 blank)

APPENDIX E

EXPENDABLE SUPPLIES AND MATERIALS LIST

Section I. INTRODUCTION

E-1. SCOPE. This appendix lists expendable supplies and materials you will need to operate and maintain the out-board motor.

These items are authorized to you by CTA 50-970, Expendable Items (except Medical, Class V, Repair Parts, and Heraldic Items).

E-2. EXPLANATION OF COLUMNS'

- a. Column 1 - Item Number. This number is assigned to the entry in the listing.
- b. Column 2 - Level. This column identifies the lowest level of maintenance that requires the listed item.

C Operator/Crew

O Organizational Maintenance

F Direct Support Maintenance

H General Support Maintenance

Column 3 - National Stock Number. This is the National stock number assigned to the item; use it to request or requisition the item.

d. Column 4 - Description. Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the part number followed by the Federal Supply Code for Manufacturer (FSCM) in parentheses, if applicable.

e. Column 5 - Unit of Measure (U/M). Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in., pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

Expendable Supplies and Materials List

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
1	C, O, F	6850-00-274-5421	Drycleaning Solvent, P-D-680	gal.
2	C	7920-00-205-1711	Rag, wiping	lb.
3	C, O, F	9150-00-190-0904	GAA Grease, Auto/Artillery MIL-G-10924 (81349)	lb.
4	C	9150-00-117-8791	50/1 lube oil, engine	gal.
5	C, O, F	9150-00-905-9100	GO lubricating oil, grade 90 MIL-L-2105 (81349)	gal.
6	C, O, F	9150-00-181 9858	Lubricating oil, Engine OE 30 MI L-L-2104 (81349)	gal.
7	O		Markal thermomelt stik	ea.
8	F	OMC 327361	Sealant	pt.

APPENDIX F

ILLUSTRATED LIST OF MANUFACTURED ITEMS

Section I. GENERAL

F-1. This appendix contains the procedures for fabricating the manufactured items you are authorized to make. Section II is the index. The index shows the RPSTL part number, the procedure page of the appendix and the

paragraph in the text in which it can be found. Section III contains the procedures, drawings and dimensions to fabricate these items.

Section II. INDEX

PART NUMBER	PAGE	PARA
319080	F-3	F-2
320417	F-4	F-3
305871	F-4	F-3
323090	F-4	F-3
319729	F-4	F-3
326449-1	F-4	F-3
326449-2	F-4	F-3
321890	F-4	F-3
322999	F-4	F-3
302604	F-5	F-4

Section III. MANUFACTURED ITEMS

MAINTENANCE SUMMARY. This task covers:

- a. Fabrication of starter rope
- b. Fabrication of hoses
- c. Fabrication of gearcase seal

INITIAL SETUP

Personnel Required	General Safety Instructions
1	

TASK SUMMARY

NO.	TASK	REFERENCE	REMARKS
1	Starter rope fabrication	F-2	
2	Hose fabrication	F-3	
3	Seal fabrication	F4	

F-2. STARTER ROPE FABRICATION

This task covers:

Fabrication of starter rope

INITIAL SETUP


Tools:
T-1

Materials/Parts:
Rope - 316705

Personnel Required
1 mechanic

Approximate Time Required (minutes):
10

LOCATION/ITEM	ACTION	REMARKS
1. Rope	Measure 68-3/4" (174.63 cm) and cut.	
2. Ends of rope	Fuse each end of rope a length of 1/2" (1.27 cm) from end.	This will prevent the ends of the rope unraveling.



NOTES

1. Fabricate from 316705.
2. All dimensions are inches.

F-3. HOSE FABRICATION

This task covers:

Fabrication of hoses

INITIAL SETUP

Tools:
T-1


Materials/Parts:
See graph below

Personnel Required:
1 mechanic

Approximate Time Required (minutes):
10

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

- | | | |
|-----------------------|----------------------------|--|
| 1. Hose part numbers. | Measure to length and cut. | The graph below has all necessary dimensions and |
|-----------------------|----------------------------|--|



BULK PART NUMBER	FABRICATED PART NUMBER	LENGTH	DIA. OD (In.)	DIA. ID (In.)
305872 305872	320417 320417	93 ± 1/2	1/2 ⁺⁰ / _{-1/64}	1/4 ^{+1/64} / ₋₀
305872 305872	305871 305871	3 ± 1/8	1/2 ⁺⁰ / _{-1/64}	1/4 ^{+1/64} / ₋₀
319719 319719	323090 323090	13 ± 1/8	1/2 ⁺⁰ / _{-1/64}	1/4 ^{+1/64} / ₋₀
319719 319719	319729 319729	16-1/2 ± 1/8	1/2 ⁺⁰ / _{-1/64}	1/4 ^{+1/64} / ₋₀
326449 326449	326449-1 326449-1	10-1/2 ± 1/8	1/4 ^{+1/64} / ₋₀	2/35 ⁻⁰ / _{+1/64}
326449 326449	326449-2 326449-2	9 ± 1/8	1/4 ^{+1/64} / ₋₀	2/35 ⁻⁰ / _{+1/64}
303617 303617	321890 321890	7-7/8 ± 1/8	1/2 ± 1/64	1/4 ^{+1/64} / ₋₀
303617 303617	322999 322999	7-7/8 ± 1/8	1/2 ± 1/64	1/4 ^{+1/64} / ₋₀

F-4. SEAL FABRICATION

This task covers:

Fabrication OF CRANKCASE SEAL

INITIAL SETUP


Tools:
T-1

Materials/Parts:
Seal - 309044

Personnel Required:
1 mechanic


Approximate Time Required (minutes):
10

LOCATION/ITEM	ACTION	REMARKS
1. Seal	Measure and cut to length.	Seal must be cut so it will overlap the casting 1/32 in. (.079 cm) at each end.



NOTES:

1. Fabricate from 309044.
2. All dimensions are in inches.



APPENDIX G

Torque Limits

POWER HEAD

Flywheel nut	100-105 lb ft (136-142 N-m)
Connecting rod screw	29.05-31 lb ft (40-42 N-m)
Cylinder head screws	14-16 lb ft (19-22 N-m)
Crank case to cylinder screws - upper and lower	12-13 lb ft (16-18 N-m)
center	18-20 lb ft (24-27 N-m)
Spark plug	18-20 lb ft (24-27 N-m)
Starter housing screws	8-10 lb ft (11-14 N-m)

LOWER UNIT

Side mounts - upper and lower nuts	12.5-13 lb ft (17-18 N-m)
Front mount - upper nut	21-26 lb ft (28-35 N-m)
Pilot shaft to steering bracket screws	10-12 lb ft (14-16 N-m)
Slip Clutch Propeller	180 lb ft (244 N-m)

G-1/(G-2 blank)

INDEX

	Paragraph Number
A	
Adjustments, Carburetor	3-17
Adjustments, Idle Speed	3-17
Adjustments, Motor Angle	2-17
Adjustments, Shifter Lever	4-3 5
Adjustments, Tilt Friction	2-16
B	
Bearings, Crankshaft	5-10
Bracket, Steering	5-11
Bracket, Stern	4-33
Bracket, Swivel	5-11
Breaker Points	4-20
C	
Carburetor	5-6
Carburetor Inspection/Cleaning	4-27
Carburetor, Adjustments	3-17
Carburetor, Repair	5-6
Carburetor, Replace	4-28
Clamp, Screw Assembly	3-18
Condenser, Replace	4-19
Condenser, Test	4-12
Cover, Motor	5-5
Crankshaft and Pistons	5-10
Crankshaft Bearings	5-10
Crankshaft Bearings, Replace	5-10
Crankshaft, Replace	5-10
Cylinder Head, Replace	5-9
D	
Drive Pin, Propeller	3-14
Driveshaft, Replace	5-16
E	
Engine, Repair	5-8
Engine, Replace	5-8
Exhaust Housing, Replace	5-12
.....	5-12
F	
Flywheel, Replace	4-17
Fuel Pump	4-26
Fuel Pump, Replace	4-26
Fuel Tank Inspection	4-24
Fuel Tank Pressure Test	4-24
Fuel Tank, Repair	4-25

Paragraph
Number

G

Gearcase3-13
 Gearcase Repair5-14
 Gearcase Service3-13
 Gearcase Test5-15

H

Handle, Steering5-13
 Head, Cylinder5-9
 Housing, Exhaust5-12

I

Ignition Coil, Replace4-18
 Ignition Coil, Test4-13
 Intake Manifold5-7
 Intake Manifold, Replace5-7

L

Leaf Plate Assembly5-7
 Leaf Plate Assembly, Replace5-7
 Lever, Shifter4-35

M

Magneto, Replace4-16
 Manifold, Intake4-29
 Motor Cover5-5
 Motor Cover, Repair5-5
 Motor Cover, Replace2-12

N

Needle Valve4-27
 Needle Valve, Replace4-27

P

Piston, Replace5-10
 Plate, Leaf Assembly5-7
 Plug, Spark3-10
 Points, Breaker4-20
 Propeller Drive Pin, Replace3-14
 Propeller, Inspect3-14
 Propeller, Replace3-14
 Pump, Fuel4-26
 Pump, Water4-36

R

Rewind Starter3-9
 Rewind Starter, Repair4-15
 Rewind Starter, Replace3-9
 Rod, Shifter5-14

**Paragraph
Number**

S

Screen, Water Intake	4-37
Screw Assembly Clamp, Replace	3-18
Shifter Lever, Adjust	4-35
Shifter Lever, Replace	4-35
Shifter Rod, Inspect	5-14
Shifter Rod, Replace	5-14
Shifter Shaft, Inspect	5-14
Shifter Shaft, Replace	5-14
Shorting Switch Test	4-23
Shorting Switch, Replace	4-22
Shorting, Switch	2-10
Spark Plugs	3-10
Spark Plugs, Adjustment	3-11
Spark Plugs, Replace	3-10
Starter, Rewind	3-9
Steering Bracket, Replace	5-11
Steering Friction, Adjustments	2-14
Steering Handle, Repair	5-13
Steering Handle, Replace	4-31
Stem Bracket, Replace	4-33
Switch, Shorting, Test	4-23
Swivel Bracket, Replace	5-11

T

Tank, Fuel	4-24
Temperature, Engine	4-38
Throttle Adjustments	3-17

V

Valve, Needle	4-27
---------------------	------

W

Water Intake Screen, Inspect	4-37
Water Intake Screen, Replace	4-37
Water Intake Screen, Service	4-37
Water Pump, Replace	4-36
Wiring, Replace	4-12
Wiring, Test	4-12

By Order of the Secretary of the Army:

E. C. MEYER
General, United States Army
Chief of Staff

Official:

ROBERT M. JOYCE
Brigadier General, United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25D, Operator Maintenance Requirements for Outboard Motors.

☆U.S. GOVERNMENT PRINTING OFFICE: 1982-564029/1099

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN...JOT DOWN THE
DOPE ABOUT IT ON THIS FORM.
CAREFULLY TEAR IT OUT, FOLD IT
AND DROP IT IN THE MAIL.

SOMETHING WRONG WITH PUBLICATION

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT PIN-POINT WHERE IT IS

PAGE
NO.

PARA-
GRAPH

FIGURE
NO.

TABLE
NO.

IN THIS SPACE, TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT.

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

THE METRIC SYSTEM AND EQUIVALENTS

Linear Measure

1 centimeter = 10 millimeters = .39 inch
 1 decimeter = 10 centimeters = 3.94 inches
 1 meter = 10 decimeters = 39.37 inches
 1 dekameter = 10 meters = 32.8 feet
 1 hectometer = 10 dekameters = 328.08 feet
 1 kilometer = 10 hectometers = 3.2808.8 feet

Square measure

1 sq. centimeter = 100 sq. millimeters = .155 sq. in.
 1 sq. decimeter = 100 sq. centimeters = 15.5 inches
 1 sq. meter (centare) = 100 sq. decimeters = 10.76 feet
 1 sq. dekameter (are) = 100 sq. meters = 1.076.4 sq. ft.
 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47 acres
 1 sq. kilometer = 100 hectometers = .386 sq. miles

Weights

1 centigram = 10 milligrams = .15 grain
 1 decigram = 10 centigrams = 1.54 grains
 1 gram = 10 decigram = .035 ounce
 1 dekagram = 10 grams = .35 ounce
 1 hectogram = 10 dekagrams = 3.52 ounces
 1 kilogram = 10 hectograms = 2.2 pounds
 1 quintal = 100 kilograms = 220.46 pounds
 1 metric ton = 10 quintals = 1.1 short tons

Liquid Measure

1 dekaliter = 10 liters = 2.64 gallons
 1 hectoliter = 10 dekaliters = 26.42 gallons
 1 kiloliter = 10 hectoliters = 264.18 gallons
 1 liter = 10 deciliters = 33.81 fl. ounces
 1 centiliter = 10 milliliters = .34 fl. ounce
 1 deciliter = 10 centiliters = 3.38 fl. ounces
 1 metric ton = 10 quintals = 1.1 short tons

Cubic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch
 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. in.
 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

Approximate Conversion Factors

To change	To	Multiply by	To change	To	Multiply by
inches	centimeters	2.540	ounce inches	newton-meters	.0070062
feet	meters	.305	centimeters	inches	.394
yards	meters	.914	meters	feet	3.280
miles	kilometers	1.609	meters	yards	1.094
sq. inches	sq. centimeters	6.451	kilometers	miles	.621
sq. feet	sq. meters	.093	sq. centimeters	sq. inches	.155
sq. yards	sq. meters	.836	sq. meters	sq. yards	10.764
sq. miles	sq. kilometers	2.590	sq. kilometers	sq. miles	1.196
acres	sq. hectometers	.405	sq. hectometers	acres	2.471
cubic feet	cubic meters	.028	cubic meters	cubic feet	35.315
cubic yards	cubic meters	.765	milliliters	fluid ounces	.034
fluid ounces	milliliters	29.573	liters	pints	2.113
pints	liters	.472	liters	quarts	1.057
quarts	liters	.946	grams	ounces	.035
gallons	liters	3.785	kilograms	pounds	2.205
ounces	grams	28.349	metric tons	short tons	1.102
pounds	kilograms	.454	pound-feet	newton-meters	1.356
short tons	metric tons	.907			
pound inches	newton-meters	.11296			

Temperature (Exact)

°F Fahrenheit temperature

5/9 (after subtracting 32)

Celsius Temperature °C

