


Supersedes TM 9-2815-225-34&P-1, TM 9-2815-225-34&P-2,
TM 9-2815-222-34&P and all changes.

**DIRECT SUPPORT AND GENERAL SUPPORT (DS/GS)
MAINTENANCE MANUAL INCLUDING
REPAIR PARTS AND SPECIAL TOOLS LIST (RPSTL)
FOR**

**ENGINE, DIESEL: 6 CYLINDER
IN-LINE, TURBOCHARGED,
CUMMINS MODEL NTC-400
M915-M920 AND
M915A4*/BIG CAM I
(NSN 2815-01-082-8125)
M915A1 AND M915A4*/BIG CAM III
(NSN 2815-01-142-2745)**



BIG CAM II SHOWN

*** M915A4 TRUCKS WILL BE EQUIPPED WITH
EITHER BIG CAM I OR BIG CAM III ENGINES**

HOW TO USE THIS MANUAL	viii
GENERAL INFORMATION	1-1
EQUIPMENT DESCRIPTION AND DATA	1-2
SERVICE UPON RECEIPT	2-1
TROUBLESHOOTING	2-2
GENERAL MAINTENANCE INSTRUCTIONS	3-1
TESTING	3-672
REPAIR PARTS AND SPECIAL TOOLS LIST	B-1
EXPENDABLE SUPPLIES AND MATERIALS LIST	C-1
TORQUE LIMITS	E-1
WEAR LIMITS AND TOLERANCES	F-1

DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited.

**HEADQUARTERS, DEPARTMENT OF THE ARMY
AUGUST 2001**

WARNING**CARBON MONOXIDE (EXHAUST GAS) CAN KILL YOU**

Carbon monoxide is without color or smell, but can kill you. Breathing air with carbon monoxide produces symptoms of headache, dizziness, loss of muscular control, a sleepy feeling, and coma. Brain damage or death can result from heavy exposure. Carbon monoxide occurs in the exhaust fumes of fuel-burning heaters and internal combustion engines. Carbon monoxide can become dangerously concentrated under conditions of no air movement. Precautions must be followed to ensure crew safety when the personnel heater or engine of any vehicle is operated for any purpose.

1. DO NOT operate personnel heater or engine of vehicle in a closed place unless the place has a lot of moving air.
2. DO NOT idle engine for long periods without ventilator blower operating.
3. DO NOT drive any vehicle with inspection plates, cover plates, or engine compartment doors removed unless necessary for maintenance purposes.
4. BE ALERT at all times during vehicle operation for exhaust odors and exposure symptoms. If either is present, IMMEDIATELY VENTILATE personnel compartments. If symptoms persist, remove affected crew to fresh air; keep warm; DO NOT PERMIT PHYSICAL EXERCISE. If necessary, give artificial respiration. FOR ARTIFICIAL RESPIRATION, REFER TO FM 21-11.
5. BE AWARE: the field protective mask for Chemical-Biological-Radiological (CBR) protection will not protect you from carbon monoxide poisoning.

THE BEST DEFENSE AGAINST CARBON MONOXIDE POISONING IS GOOD VENTILATION.

WARNING SUMMARY

- Compressed air used for cleaning purposes will not exceed 30 psi. Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Wear heat-resistant gloves when handling heated crankshaft gear. Failure to comply may result in injury to personnel.
- Perform operation out of doors or in a well-ventilated room. Failure to comply may result in injury to personnel.
- Remove pressure regulator assembly slowly to prevent spring tension from shooting assembly from oil pump body. Wear eye protection. Failure to comply may result in damage to equipment or injury to personnel.
- Eye protection must be worn when using wire brush for cleaning. Failure to comply may result in injury to personnel.
- The machined edges on turbine wheel are very sharp. Wear protective gloves. Failure to comply may result in injury to personnel.
- Wear rubber gloves when removing piston pin to prevent burns from boiling water or hot piston. Failure to comply may result in injury to personnel.
- Control valve cover is under pressure from control valve outer spring. Wear suitable eye protection and hold cover down when removing screw and cover. Failure to comply may result in injury to personnel.

WARNING SUMMARY (Contd)

- Improper cleaning methods and use of unauthorized cleaning solvents will not be used. Refer to TM 9-247 for proper cleaning methods and solvents. Failure to comply may result in damage to equipment or injury to personnel.
- The stamped steel oil pan on M915A1/Big Cam III or on M915/Big Cam I engines must not be used to support weight of engine; the pan will permanently deform and may collapse, allowing engine to fall over. Failure to comply may result in damage to equipment and injury to personnel.
- All personnel must stand clear during lifting operations. A snapped chain or swinging or shifting load may result in injury to personnel.
- Use extreme caution during disassembly or assembly; engine components are heavy. Failure to comply may result in damage to equipment or injury to personnel.
- Operation of a deadlined vehicle without preliminary inspection will cause further damage to a malfunctioning component and possible injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.
- Do not perform fuel system procedures while smoking or within 50 ft (15.2 m) of sparks or open flame. Diesel fuel is flammable and may explode. Failure to comply may result in injury to personnel.
- Allow adequate ventilation for engine exhaust gases. Failure to comply may result in brain damage or death to personnel.

LIST OF EFFECTIVE PAGES

REVISION SUPERSEDES COPIES DATED DECEMBER 1983, INCLUDING ALL CHANGES.

NOTE: The portion of the test affected by the revision is listed below.

Date of issue for original:

Original 0..... 28 August 2001

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 864, CONSISTING OF THE FOLLOWING:

Page No	*Change No.	Page No.....	*Change No.
Warning a - Warning b.....	0	52-2 Blank.....	0
A	0	I-1 - I-44.....	0
B Blank	0	C-1 - C-4.....	0
i - xi	0	D-1 - D-4.....	0
xii Blank.....	0	E-1 - E-4.....	0
1-1 - 1-6.....	0	F-1 - F-5.....	0
2-1 - 2-10.....	0	F-6 Blank	0
3-1 - 3-537.....	0	Glossary 1.....	0
3-538 Blank	0	Glossary 2 Blank.....	0
3-539 - 3-706	0	Index 1 - Index 6.....	0
A-1 - A-2.....	0		
B-1 - B-5.....	0		
Figure 1 - Page 52-1	0		

*Zero in this column indicates original page.

DIRECT SUPPORT AND GENERAL SUPPORT (DS/GS)
MAINTENANCE MANUAL INCLUDING
REPAIR PARTS AND SPECIAL TOOLS LIST (RPSTL)
FOR
ENGINE, DIESEL: 6 CYLINDER IN-LINE,
TURBOCHARGED, CUMMINS MODEL NTC-400
M915-M920/BIG CAM I (NSN 2815-01-082-8125)
M915A1/BIG CAM III (NSN 2815-01-142-2745)

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028 (Recommended Changes to Publications and Blank Forms), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <http://aeps.ria.army.mil>. If you need a password, scroll down and click on "ACCESS REQUEST FORM". The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax or E-mail your letter or DA Form 2028 direct to: AMSTA-LC-CI Tech Pubs, TACOM-RI, 1 Rock Island Arsenal, Rock Island, IL 61299-7630. The email address is TACOM-TECH-PUBS@ria.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

	PAGE
<u>HOW TO USE THIS MANUAL</u>	viii
CHAPTER 1 <u>INTRODUCTION</u>	1-1
Section I. GENERAL INFORMATION.....	1-1
1-1. Overview	1-1
1-2. Scope	1-1
1-3. Maintenance Forms, Records, and Reports	1-1
1-4. Destruction of Army Materiel to Prevent Enemy Use	1-1
1-5. Preparation for Storage and Shipment	1-2
1-6. Reporting Equipment Improvement Recommendations (EIRs)	1-2
1-7. Warranty Information	1-2

* This manual supersedes TM 9-2815-225-34&P-1, TM 9-2815-225-34&P-2, dated Dec 1983 and TM 9-2815-222-34&P dated Dec 1980 and all changes.

TABLE OF CONTENTS (Contd)

	PAGE
Section II. EQUIPMENT DESCRIPTION AND DATA	1-2
1-8. Equipment Characteristics, Capabilities, and Features	1-2
1-9. Location and Description of Major Components	1-3
1-10. Equipment Data	1-5
CHAPTER 2 <u>SERVICE AND TROUBLESHOOTING INSTRUCTIONS</u>	2-1
Section I. REPAIR PARTS, SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT	2-1
2-1. Overview	2-1
2-2. Common Tools and Equipment	2-1
2-3. Special Tools, TMDE, and Support Equipment	2-1
2-4. Repair Parts	2-1
Section II. SERVICE UPON RECEIPT OF EQUIPMENT.....	2-1
2-5. Engine Inspection	2-1
Section III. TROUBLESHOOTING	2-2
2-6. General	2-2
2-7. Troubleshooting Symptom Index	2-3
2-8. Mechanical Troubleshooting	2-3
CHAPTER 3 <u>MAINTENANCE</u>	3-1
Section I. GENERAL MAINTENANCE INSTRUCTIONS	3-1
3-1. Overview	3-1
3-2. General	3-1
3-3. Task Summary	3-2
3-4. Lifting Engine	3-3
3-5. Draining Engine.....	3-3
3-6. Cleaning	3-3
3-7. Inspection	3-4
3-8. Wear Limits and Tolerances.....	3-5
3-9. Repair	3-5
3-10. Assembly	3-7
Section II. DISASSEMBLY	3-8
3-11. General	3-8
3-12. Task Summary	3-8
3-13. Mounting Engine on Maintenance Stand	3-10
3-14. Vibration Damper and Crankshaft Pulley Removal	3-26
3-15. Accessory Drive Pulley Removal	3-28
3-16. Fuel Pump Removal	3-30
3-17. Air Compressor Removal.....	3-36
3-18. Accessory Drive Housing Assembly Removal	3-40
3-19. Oil Pump Removal	3-42

TABLE OF CONTENTS (Contd)

	PAGE
3-20. Air Aftercooler Removal.....	3-46
3-21. Engine Retarder Removal.....	3-48
3-22. Rocker Arm Housing Assembly and Pushrods Removal	3-50
3-23. Injector Assembly Removal	3-52
3-24. Cylinder Head Assembly Removal	3-54
3-25. Flexplate or Flywheel, Flywheel Housing, and Rear Cover Removal	3-56
3-26. Oil Pan Removal	3-62
3-27. Front Gear Cover Removal	3-64
3-28. Cam Follower Assemblies and Camshaft Removal	3-66
3-29. Piston, Connecting Rod, and Bearings Removal	3-68
3-30. Cylinder Liner Removal	3-72
3-31. Engine Crankshaft and Main Bearings Removal	3-74
Section III. REPAIR	3-78
3-32. General	3-78
3-33. Task Summary	3-78
3-34. Engine Block Repair	3-85
3-35. Cylinder Head and Valve Repair	3-112
3-36. Vibration Damper and Crankshaft Pulley Repair	3-148
3-37. Crankshaft Repair	3-150
3-38. Flexplate or Flywheel, Flywheel Housing, and Rear Cover Repair.....	3-170
3-39. Piston, Connecting Rod, and Bearing Repair	3-174
3-40. Camshaft, Cam Follower, and Pushrod Repair	3-188
3-41. Rocker Levers and Housing Repair	3-208
3-42. Oil Cooler Repair	3-218
3-43. Oil Pan, Dipstick, Oil Suction Tubes, and Dipstick Tube Repair	3-236
3-44. Oil Pump Repair	3-246
3-45. Air Aftercooler Repair	3-264
3-46. Exhaust Manifold Repair	3-272
3-47. Turbocharger Repair	3-276
3-48. Front Gear Cover Repair	3-292
3-49. Accessory Drive Repair	3-296
3-50. Engine Retarder Repair	3-304
3-51. Air Compressor Repair	3-312
3-52. Fuel Injector Repair	3-340
3-53. Fuel Injector Testing; Test No. 1	3-352
3-54. Fuel Injector Testing; Test No. 2	3-258
3-55. Fuel Injector Testing; Test No. 3	3-362
3-56. Fuel Pump Repair	3-384
3-57. Solenoid Valve Repair	3-388
3-58. Fuel Damper and Head Repair	3-394
3-59. Fuel Gear Pump Repair	3-398
3-60. Fuel Pump Governor Spring Repair	3-404
3-61. Fuel Pump Front Cover and Governor Repair	3-408
3-62. Fuel Pump Main Housing Repair	3-426
3-63. Fuel Pump Testing and Calibration	3-448

TABLE OF CONTENTS (Contd)

	PAGE
3-64. Water Pump Repair	3-518
Section IV. ASSEMBLY	3-539
3-65. General	3-539
3-66. Task Summary	3-539
3-67. Cylinder Liner Installation	3-542
3-68. Engine Crankshaft and Main Bearings Installation	3-544
3-69. Pistons, Connecting Rod, and Bearings Installation	3-552
3-70. Cam Follower Assemblies and Camshaft Installation	3-558
3-71. Cylinder Head Assembly and Pushrods Installation	3-562
3-72. Injection Timing	3-566
3-73. Accessory Drive Housing Assembly Installation	3-576
3-74. Oil Pump Installation	3-580
3-75. Front Gear Cover Installation	3-584
3-76. Accessory Drive Pulley Installation	3-590
3-77. Air Compressor Installation	3-592
3-78. Fuel Pump Installation	3-596
3-79. Vibration Damper and Crankshaft Pulley Installation	3-606
3-80. Flexplate or Flywheel, Flywheel Housing, and Rear Cover Installation	3-608
3-81. Oil Pan Installation	3-620
3-82. Injector Assembly Installation	3-632
3-83. Valve Crossheads Installation and Adjustment	3-636
3-84. Rocker Arm Housing Assembly Installation	3-640
3-85. Injector and Valve Adjustment	3-644
3-86. Engine Retarder Installation	3-650
3-87. Air Aftercooler Installation	3-656
3-88. Removing Engine from Maintenance Stand	3-660
Section V. TESTING	3-672
3-89. General	3-672
3-90. Task Summary	3-672
3-91. Starting Repaired Engine	3-674
3-92. Engine Dynamometer Testing	3-680
3-93. On-Engine Fuel Pump Adjustment	3-690
Section VI. STORAGE	3-704
3-94. General	3-704
3-95. Task Summary	3-704
3-96. Temporary Storage	3-704
3-97. Long-Term Storage	3-705
3-98. Preparing an Engine from Storage to Service	3-706
APPENDIX A REFERENCE	A-1
A-1. Publication Indexes	A-1
A-2. Forms	A-1
A-3. Other Publications	A-1

TABLE OF CONTENTS (Contd)

	PAGE	ILLUS FIG
APPENDIX B REPAIR PARTS AND SPECIAL TOOLS LIST	B-1	
Section I. INTRODUCTION	B-1	
B-1. Scope	B-1	
B-2. General	B-1	
B-3. Explanation of Columns (Sections II and III)	B-1	
B-4. Explanation of Columns (Section IV)	B-4	
B-5. Special Information	B-5	
B-6. How to Locate Repair Parts	B-5	
Section II. REPAIR PARTS LIST	1-1	1
GROUP 01 ENGINE		
0100 Dressed Engine and Container	1-1	1
0101 Engine Block	2-1	2
0101 Cylinder Head Assembly	3-1	3
0102 Crankshaft Assembly	4-1	4
0103 Flexdisk, Ring Gear, and Housing	5-1	5
0104 Piston and Connecting Rod Assembly	6-1	6
0105 Camshaft Assembly and Followers	7-1	7
0105 Rocker Arm Assembly	8-1	8
0105 Rocker Cover	9-1	9
0106 Oil Cooler and Filter, M915A1 Only	10-1	10
0106 Oil Cooler and Filter, M915 Only	11-1	11
0106 Oil Pan, Dipstick, and Breather Tube	12-1	12
0106 Oil Lubricating Pump	13-1	13
0108 Air Aftercooler	14-1	14
0108 Exhaust Manifold	15-1	15
0109 Gear Cover	16-1	16
0109 Accessory Drive Pulley and Fan Clutch	17-1	17
0112 Engine Retarder	18-1	18
0121 Air Compressor Lines and Fittings	19-1	19
0121 Air Compressor and Governor Assembly	20-1	20
GROUP 03 FUEL SYSTEM		
0301 Fuel Injector	21-1	21
0302 Fuel Lines and Fittings	22-1	22
0302 Fuel Pump	23-1	23
0302 Fuel Pump Main Housing	24-1	24
0302 Fuel Gear Pump	25-1	25
0305 Turbocharger and Component Parts	26-1	26
0305 Turbocharger Assembly	27-1	27
0306 Solenoid Valve	28-1	28
0308 Fuel Pump Front Cover, Governor, and Tach Drive	29-1	29
0309 Fuel Pump Damper, Head, and Fuel Filter	30-1	30
0311 Ether Quick-Start Kit	31-1	31
0312 Fuel Control Lever	32-1	32

TABLE OF CONTENTS (Contd)

	PAGE	ILLUS FIG
GROUP 05	COOLING SYSTEM	
0503	Thermostat Housing, Water Manifold, and Component Parts 33-1	33
0503	Water Filter and Component Parts 34-1	34
0504	Water Pump and Idler 35-1	35
GROUP 94	REPAIR KITS	
9401	Repair Kits Kit-1	
GROUP 95	BULK MATERIAL	
9501	Bulk Material Bulk-1	
Section III.	SPECIAL TOOLS	
GROUP 26	SPECIAL TOOLS	
2604	Direct Support Special Tools-1 36-1	36
2604	Direct Support Special Tools-2 37-1	37
2604	Direct Support Special Tools-3 38-1	38
2604	Direct Support Special Tools (Supplemental) 39-1	39
2604	General Support Special Tools-1 40-1	40
2604	General Support Special Tools-2 41-1	41
2604	General Support Special Tools-3 42-1	42
2604	General Support Special Tools (Supplemental)-1 43-1	43
2604	General Support Special Tools (Supplemental)-2 44-1	44
2604	General Support Special Tools (Supplemental)-3 45-1	45
2604	Direct and General Support Special Tools-1 46-1	46
2604	Direct Support Special Tools-2 47-1	47
2604	Direct Support Special Tools-3 48-1	48
2604	General Support Special Tools-1 49-1	49
2604	General Support Special Tools-2 50-1	50
2604	General Support Special Tools-3 51-1	51
2604	General Support Special Tools-4 52-1	52
Section IV.	CROSS-REFERENCE INDEXES	
	National Stock Number Index I-1	
	Part Number Index I-15	
APPENDIX C	EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST C-1	
Section I.	INTRODUCTION C-1	
C-1.	Scope C-1	
C-2.	Explanation of Columns C-1	
APPENDIX D	ILLUSTRATED LIST OF MANUFACTURED ITEMS D-1	
Section I.	INTRODUCTION D-1	

TABLE OF CONTENTS (Contd)


	PAGE	ILLUS FIG
D-1. General.....	D-1	
D-2. Manufactured Item Part Number Index	D-1	
Section II. ILLUSTRATED MANUFACTURING INSTRUCTIONS	D-2	
APPENDIX E TORQUE LIMITS	E-1	
Section I. STANDARD TORQUE SPECIFICATIONS	E-2	
Section II. ENGINE ASSEMBLY TIGHTENING SPECIFICATIONS	E-3	
APPENDIX F WEAR LIMITS AND TOLERANCES	F-1	
F-1. General	F-1	
F-2. Repair Standards	F-1	
GLOSSARY		Glossary-1
Section I. LIST OF ABBREVIATIONS		Glossary-1
Section II. DEFINITION OF UNUSUAL TERMS		Glossary-1
INDEX		Index-1

HOW TO USE THIS MANUAL

ABOUT YOUR MANUAL

Maintenance tasks in this manual are written in sequence for the complete disassembly of the engine. They can also be used in conjunction with troubleshooting to repair a specific engine component or part without performing a complete engine overhaul. In either event, always refer to the maintenance record (or attached instructions if the engine arrives for repair in a container). This will prevent any unnecessary work on your part. Follow the steps listed below under "Using Your Manual" to become familiar with how to use this book.


USING YOUR MANUAL



Task: The operator of an M915 series vehicle has complained the engine knocks under a load, and the vehicle has been assigned to you for repair.

TROUBLESHOOTING STEPS:

1. Look at the cover of this manual. You'll see chapter/section titles listed from top to bottom on the right-hand side.
2. Look at the right edge of the manual. On some of the pages you'll see black bars (edge indicators) that are aligned with the chapter/section bars on the cover. These are the locations of the chapters/section in the text.
3. Look for "TROUBLESHOOTING" in the chapter/section list on the cover.
4. Turn to those pages with the edge indicator matching the black bar for TROUBLESHOOTING. Page numbers are also listed next to chapter/section titles.
5. One of the first pages having the mechanical systems troubleshooting edge indicators is the "TROUBLESHOOTING SYMPTOM INDEX."
6. Look down the list until you find "ENGINE KNOCKS."
7. Turn to the page indicated: 2-5.



8. On page 2-5, steps/tests relating to resolving the problem of "Engine Knocks" are listed:

Step 1. You check for a possible damaged piston.

Step 2. During your inspection you discover that a piston is damaged. The part must be replaced. Chapter 3, paras. 29 and 69, are referenced.

9. Before turning to paras. 3-29 and 3-69, turn to chapter 3, section I, "GENERAL MAINTENANCE INSTRUCTIONS," and review the guidelines to be followed during maintenance of engine (paras. 3-2 through 3-10).

10. Because replacement of a piston is extensive, refer to chapter 3, section II, "DISASSEMBLY." Find "Piston, Connecting Rod, and Bearings Removal" in the task summary (para. 3-12.)

TM 9-2815-225-34&P

Table 2-5. Malfunction Troubleshooting (cont.)

Malfunction	Test or Inspection	Corrective Action
Step 1	Check for loose or worn timing belt	Replace or adjust timing belt (para. 3-65)
	Check for incorrect timing timing	Time injection system (para. 3-72)
B. LOW OIL PRESSURE		
Step 1	Check oil pressure regulator	Check oil pressure regulator or replace oil pump (para. 3-15 and 3-74)
Step 2	Check for worn mainshaft bearings	Replace worn mainshaft bearings (para. 3-31)
Step 3	Inspect oil pump pickup	Replace oil pump pickup (para. 3-74)
Step 4	Check for worn camshaft	Replace worn camshaft (para. 3-69)
Step 5	Check for worn crankshaft	Replace worn crankshaft and install new bearings (para. 3-31)
Step 6	Inspect main bearings	Replace worn bearings (para. 3-29)
Step 7	Inspect connecting rod bearings	Replace connecting rod bearings (para. 3-69)
Step 8	Inspect oil pump pump	Replace oil pump (para. 3-74 and 3-75)
Step 9	Check for high oil temperature	Inspect and clean oil cooler (para. 3-62)
Step 10	Check for worn main bearings, connecting rod bearings, and crankshaft main bearings	Check main bearings (para. 3-29 and 3-31)
9. ENGINE NOISES		
Step 1	Check for broken piston	Replace piston (para. 3-29 and 3-69)
Step 2	Check for broken injection pump	Replace injection pump (para. 3-67)
Step 3	Check for incorrect valve adjustment	Adjust valves (para. 3-10)
Step 4	Check for incorrect injection adjustment	Adjust injection (para. 3-72)
Step 5	Check for loose connecting rod cap screws	<ul style="list-style-type: none"> a. Torque connecting rod cap screws (para. 3-69) b. Check bearing (para. 3-31)
Step 6	Check for worn connecting rod bearings	Replace connecting rod bearings (para. 3-29, 3-31, and 3-69)

34

TM 9-2815-225-34&P

3-12. TASK SUMMARY (Contd)

Task	Procedure	Task Para.	Equipment/Tools (Ref. No., Para.)
10	Disassemble Bearings and Crankshaft Assembly	3-30	SA
11	Remove, Check and Reinstall Piston to Engine	3-29	SA
12	Install New Bearings	3-29	SA
13	Remove Crankshaft and Main Bearing Assembly	3-31	SA

35

TM 9-2815-225-34&P

3-29. PISTON, CONNECTING ROD, AND BEARINGS REMOVAL

THIS TASK COVERS:
Removal

INITIAL SETUP:

APPLICABLE MODELS: All	REFERENCES (TM): None
SPECIAL TOOLS: Torque wrench (SAE) 1/2" x 15/16" Piston ring expander 7/16-3/8 x 2 1/2"	TROUBLESHOOTING REFERENCES: Para. 3-29
TEST EQUIPMENT: None	EQUIPMENT CONDITION: Compliant and case documents (manual - para. 3-29)
MATERIALS/PARTS (P/N): Lubricant - Appendix C, Level 4	SPECIAL ENVIRONMENTAL CONDITIONS: Work area clean and away from blowing dirt and dust.
PERSONNEL REQUIRED: One Automotive Technician (A115-031)	GENERAL SAFETY INSTRUCTIONS: 1) Safety case must be worn if hot metal is in contact with clothing.

LOCATION/TBM	ACTION	EDWARDS
Removal		


WARNING:
Eye protection must be worn when using tools to break the connecting rod to do an easy removal in removal.

NOTE:
The task covers removal of the piston, connecting rod, and bearing assembly. Removal of the connecting rod, depending on the model. Parts are not interchangeable and should be identified with each assembly as it is removed.

- Engine back (1):
 - Place in vertical position with rear of block down.
 - Using a torque wrench set at manufacturer's torque, loosen all cylinder head bolts. (Do not support the wall of cylinder head.)
 - Remove head and set it in assembly.
- Two rod caps (1):
 - Loosen head cover at opposite ends of the block between head of cylinder (1) and rest of block (2).
 - Using a torque wrench, tip the head to remove it. Do not support the cap. Do not use a screwdriver to pry it out.
 - Inspect the piston and connecting rod assembly. Do not reuse.

Use the paper to remove the bolts from cylinder head.

3-8



11. Turn to para. 3-29 on page 3-89. Here you find the detailed procedure for removing the piston, connecting rod, and bearings.

DETAILED MAINTENANCE PROCEDURES:

12. Detailed procedures: Include everything you must do to accomplish a basic maintenance task.
- Before beginning the maintenance task, look through the procedure. You must familiarize yourself with the entire maintenance procedure before beginning the maintenance task. The entire procedure of para. 3-29, "Piston, Connecting Rod, and Bearings Removal," include the task REMOVAL under the heading "THIS TASK COVERS."
 - The ten basic headings listed under "INITIAL SETUP" outline the task conditions, materials, manpower requirements, and special conditions or tools. They are:
 - Applicable Models:** Any models that require that particular maintenance task.
 - Special Tools:** Those special tools required to finish a maintenance task. The use of common tools is not explained.
 - Test Equipment:** Test equipment required to complete a task.
 - Materials/Parts:** All materials or parts required to complete a task.
 - Personnel Required:** The number and type of personnel needed to accomplish a task.
NOTE: If you think an assistant will be necessary to correctly or safely complete a task (perhaps as the result of unusual conditions, etc.), alert your supervisor and ask for help.
 - References (TM):** Those manuals required to complete the task.
 - Troubleshooting References:** Specific troubleshooting symptom or those manuals required to complete the task.
 - Equipment Condition:** Notes the conditions that must exist prior to starting the task.
 - Special Environmental Conditions:** Outlines specific environmental conditions necessary to perform a task. For example: Work area clean and away from blowing dirt and dust.
 - General Safety Instructions:** Summarizes all safety warnings for the maintenance task.

- c. A step-by-step maintenance procedure follows the INITIAL SETUP. Three columns "Location/Item," "Action," and "Remarks" give detailed instructions for the procedure. They are:
- Location/Item: Indicates the general location and specific part(s) you are working on in a step. For example, the location/item of step 2 is the "crankshaft (10)." The number(s) in parentheses correspond to that part(s) callout number(s) in the accompanying illustration.
 - Action: Specifies the action to be taken with the part(s) listed in the Location/Item column. In our example, you are directed to "Rotate [the crankshaft (10)] until rod cap (7) is accessible."
 - Remarks: Provide additional information. Our example notes: "Use lint-free paper to remove loose debris from cylinder liner (9)."
- d. At the end of a procedure, "FOLLOW-ON TASK(S)" will list additional task(s) that must be performed to complete the procedure. The Follow-On Tasks for our example procedure is: "For repair or installation of piston, connecting rod, and bearings, refer to para. 3-69 or 3-39."
13. Refer to the example pages for para. 3-29, "Piston, Connecting Rod, and Bearings Removal," as we review the following points:
- a. **Modular Text**: Both pages of text and illustrations are to be used together. This manual was designed so the two pages would be visible at once, making part identification and procedure sequence easy to follow.
 - b. **Legend**: Use the legend found at bottom of each illustration page to find part name and callout number in relation to text and illustration.
 - c. **Illustrations**: A locator illustration of the cylinder block is provided. An exploded view of the component, removed from the cylinder block, shows specific part locations, attachments, and spatial relationships.
14. You can also use the Table of Contents (page ii) to find more information about the engine. For example: Appendix E, Torque Values.
15. Refer to Appendix B, Direct Support and General Support Maintenance Repair Parts and Special Tools List (RPSTL) when requisitioning parts, special tools, and equipment for organizational maintenance.
16. Your manual is easier to use once you understand its design and we hope this will encourage you to use it more often.

**CHAPTER 1
INTRODUCTION**

Section I. GENERAL INFORMATION

Section I. General Information (page 1-1)
Section II. Equipment Description and Data (page 1-2)

PARA. NO.	TITLE	PAGE NO.
1-1.	Overview	1-1
1-2.	Scope	1-1
1-3.	Maintenance Forms, Records, and Reports	1-1
1-4.	Destruction of Army Materiel to Prevent Enemy Use	1-1
1-5.	Preparation for Storage and Shipment	1-2
1-6.	Reporting Equipment Improvement Recommendations (EIRs)	1-2
1-7.	Warranty Information	1-2
1-8.	Equipment Characteristics, Capabilities, and Features	1-2
1-9.	Location and Description of Major Components	1-3
1-10.	Equipment Data	1-5

1-1. OVERVIEW

NOTE
All information contained in this manual applies to both M915 and M915A4/Big Cam I and M915A1 and M915A4/Big Cam III engines except where differences are specifically noted.

This chapter familiarizes the technician with standard forms, record data, and the equipment to be maintained at the direct support and general support maintenance levels. This information is covered in the following sections:

- Section I. General Information
- Section II. Equipment Description and Data

1-2. SCOPE

- a. Type of Manual: Direct Support and General Support Army Maintenance.
- b. Model Number and Name: NTC-400, Cummins, six-cylinder, in-line, turbocharged diesel engine.
- c. Purpose of Equipment:
 - Engine for M915 through M920 and M915A4 Truck, Big Cam I.
 - Engine for M915A1 and M915A4 Truck, Big Cam III.

1-3. MAINTENANCE FORMS, RECORDS, AND REPORTS

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA Pam 738-750, The Army Maintenance Management System (TAMMS).

1-4. DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE

Procedures for destruction of Army equipment to prevent enemy use can be found in TM 750-244-6.

1-5. PREPARATION FOR STORAGE AND SHIPMENT

Information concerning storage or shipment of equipment can be found in TM 740-90-1. Additional information concerning storage of Cummins NTC-400 engine can be found in Chapter 3, Maintenance.

1-6. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIRs)

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. You may mail, fax or email your letter, DA Form 2028, or DA Form 2028-2 direct to: Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-LC-CIP-WT, Rock Island, IL 61299-7630. The email address is TACOM-TECH-PUBS@ria.armv.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

1-7. WARRANTY INFORMATION

The Cummins diesel engine (model NTC-400) is warranted in accordance with TB 9-2300-295-15/21. The warranty starts on the date found in block 23, DA Form 2408-9, in logbook. Report all defects in material or workmanship to your supervisor, who will take appropriate action.

Section II. EQUIPMENT DESCRIPTION AND DATA**1-8. EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES****NOTE**

"M9151Big Cam I" is intended and will be written hereafter to mean M915 through M920 series and M915A4 trucks with Big Cam I engines.

a. The Cummins NTC-400 diesel engine is used on all M915 through M920, M915A1, and M915A4 trucks. It is a turbocharged, liquid-cooled, overhead valve, four-cycle engine of in-line six-cylinder design. The NTC-400 engine has a compression ratio of 13.5: 1 (M915) and 14.0: 1 (M915A1), and develops 400 horsepower at 2100 rpm. Peak torque is 1150 lb-ft at 1500 rpm (M915) and 1300 lb-ft at 1300 rpm (M915A1).

b. The following engine characteristics and features apply to both M915/Big Cam I and M915A1/Big Cam III engines, except where differences are noted.

Camshaft: 2-1/2-inch diameter camshaft with gear drive controlling all valve and injector movement. Made of induction-hardened alloy steel. Camshaft followers are roller type.

Connecting Rods: Drop-forged, rifle-drilled for pressure lubrication.

Crankshaft: High-tensile steel forging. Bearing journals and fillets-induction hardened. Fully counterweighted.

Cylinder Block: Alloy cast iron with removable wet liners.

Cylinder Heads: Each head serves two cylinders. Drilled fuel supply and return lines. High temperature inserts on exhaust valve seats.

Turbocharger: Model T-50 (M915/Big Cam I); Model T-46-B, which has a redesigned compressor wheel, compressor housing, turbine wheel and shaft, bearing housing assembly, location of oil inlet line, and vee bands (M915A1/Big Cam III).

Exhaust Manifold: Conventional log-type (M915/Big Cam I). Pulse-type for less restriction (M915A1/Big Cam III).

Fuel System: Integral flywheel-type governor.

Injectors: Camshaft actuated top-stop type.

1-8. EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES (Contd)

Intake Manifold: Conventional aftercooler (M915/Big Cam I). Triple-pass water aftercooler (M915A1/Big Cam III).

Lubrication Oil Cooler: Conventional oil cooler and filter with separately mounted bypass oil filter on engine firewall (M915/Big Cam I). Demand flow automatically regulates oil pressure, routes engine coolant through engine oil cooler twice. Engine and cooler core are made of cast aluminum and incorporates mounting adapters for spin-on type full-flow and bypass oil filters, and incorporates a bypass valve and pressure sending unit (M915A1/Big Cam III).

Oil Pan: Made of cast aluminum (M915/Big Cam I). Made of stamped steel (M915A1/Big Cam III).


Water Transfer Tube: Made of cast iron (M915/Big Cam I). Made of stamped, welded steel (M915A1/Big Cam III).

1-9. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS

Right and left views of the NTC-400 engine and its components are shown below and on the following page. Identification can be made from the engine identification plate located on the gear case mounting flange of the engine block. Because of changes made during production, some engines may have minor differences not shown in the following views.

NOTE

Below is a 3/4-view of right side of engine as viewed from front.


**LEGEND:**

- | | |
|------------------------------------------|--------------------------------------------|
| 1. CYLINDER HEAD ASSEMBLY (3) | 11. OIL PAN |
| 2. ROCKER ARM ASSEMBLY (3) | 12. FUEL PUMP |
| 3. ENGINE RETARDER (3) | 13. POWER STEERING PUMP AND RESERVOIR |
| 4. ENGINE LIFTING BRACKET (2) | 14. AIR COMPRESSOR |
| 5. AIR CROSSOVER | 15. LUBRICATION OIL PUMP |
| 6. DIAGNOSTIC CONNECTOR ASSEMBLY BRACKET | 16. FRONT ENGINE MOUNT |
| 7. AIR AFTERCOOLER | 17. VIBRATION DAMPER AND CRANKSHAFT PULLEY |
| 8. FLYWHEEL HOUSING | 18. ACCESSORY DRIVE PULLEY |
| 9. STARTER | 19. FAN |
| 10. CAM FOLLOWER ASSEMBLY (3) | 20. FAN CLUTCH |

1-9. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS (Contd)

NOTE

Below is a 3/4-view of left side of engine as viewed from front.



LEGEND:

21. TURBOCHARGER (AS SHOWN, MODEL T-50, M915/BIG CAM I); (MODEL T-46-B, M915A1/BIG CAM III)

22. CRANKCASE BREATHER TUBE

23. EXHAUST MANIFOLD

24. WATER MANIFOLD

25. THERMOSTAT HOUSING

26. WATER FILTER

27. WATER PUMP

28. ALTERNATOR

29. ENGINE OIL COOLER

30. FULL-FLOW OIL FILTER

31. BYPASS OIL FILTER (AS SHOWN, M915A1/BIG CAM III); (M915/BIG CAM I MAY BE MOUNTED ON FIREWALL)

32. HAND HOLE COVER

33. DIPSTICK AND TUBE

34. FLYWHEEL INDEX HOLE COVER

35. REAR ENGINE MOUNT

1-10. EQUIPMENT DATA

Manufacturer	Cummins Engine Company, Inc.
Model	NTC-400
Type	4-cycle, turbocharged diesel, compression ignition

DIMENSIONS

Length	58.88 in. (149.6 cm)
Width	33.63 in. (85.4 cm)
Height	50.91 in. (129.3 cm)
Net Weight, Dry	2,600 lbs (1,180.4 kg)

CYLINDERS

Number	6
Arrangement	In-line
Firing Order	1-5-3-6-2-4
Bore	5.5 in. (14 cm)
Stroke	6 in. (15.2 cm)
Displacement	855 cu-in. (14 L)
Compression Ratio	13.5:1 (M915/Big Cam I) 14.0:1 (M915A1/Big Cam III)

GOVERNED SPEED

Full Load	2100 rpm
No Load	2460 rpm
Idle Speed	600 rpm

LUBRICATION SYSTEM

Type	Force-fed
Operating Pressure (Normal)	35-45 psi (M915A1/Big Cam III) 50-70 psi (345-483 kPa) (M915/Big Cam I)
Operating Pressure (Minimum)	15 psi (100 kPa) @ idle
System Capacity Including Bypass Filter	44 qt (41.6 L) (M915A1) 46 qt (43.5 L) (M915)
Operating Temperature (Normal)	200-250°F (93-121°C)
Oil Pump	Gear-type

COOLING SYSTEM

Type	Liquid with fan and radiator
Operating Temperature (Normal)	175-195°F (79-91°C)
Thermostat	1

PERFORMANCE HEAD

Maximum Torque	1150 lb-ft @ 1500 rpm (M915/Big Cam I) 1300 lb-ft @ 1300 rpm (M915A1/Big Cam III)
Maximum Output	400 BHP
Piston Speed @ 2100 rpm.....	2100 ft/min

1-10. EQUIPMENT DATA (Contd)

Maximum No Load Governed Speed	2460 rpm
Maximum Approved Altitude, Transient Mode	12,000 ft (3658 m)
Maximum Approved Altitude, Continuous Operation	6000 ft (1829 m)
Ambient Air Temperature Above Which Output Should be Limited	100°F (37.8°C)
Air Flow @ 400 hp @ 2100 rpm	985 CFM
Exhaust Flow @ 400 hp @ 2100 rpm	2320 CFM
Nominal Fuel Consumption @ 2100 rpm	144 lb/hr
Nominal Fuel Consumption @ 500 rpm (Peak Torque)	116 lb/hr
Maximum Fuel Flow to Pump @ 2100 rpm	485 lb/hr
Maximum Allowable Restriction to Pump:	
Clean Filter	4.0 in. Hg
Dirty Filter	8.0 in. Hg
Maximum Allowable Return Line Restriction	2.5 in. Hg

CHAPTER 2 SERVICE AND TROUBLESHOOTING INSTRUCTIONS

- Section I. Repair Parts, Special Tools, TMDE, and Support Equipment (page 2-1)
- Section II. Service Upon Receipt of Equipment (page 2-1)
- Section III. Troubleshooting (page 2-2)

Section I. REPAIR PARTS, SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT

NOTE

All information contained in this manual applies to both M915 and M915A4/Big Cam I and M915A1 and M915A4/Big Cam III engines except where differences are specifically noted.

2-1. OVERVIEW

- a. This chapter provides information on common tools, special tools, service tools, service upon receipt, and troubleshooting.
- b. The information is divided up into the following sections:

- Section I. Repair Parts, Special Tools, Test Measurement and Diagnostic Equipment (TMDE), and Support Equipment
- Section II. Service Upon Receipt
- Section III. Troubleshooting

2-2. COMMON TOOLS AND EQUIPMENT

For authorized common tools and equipment, refer to the Modified Table of Organization and Equipment (MTOE) applicable to your unit.

2-3. SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT

Special tools and support equipment are listed in Appendix B of this manual.

2-4. REPAIR PARTS

Repair parts are listed and illustrated in Appendix B of this manual.

Section II. SERVICE UPON RECEIPT OF EQUIPMENT

2-5. ENGINE INSPECTION

- a. Inspect for any damage done to engine during its removal from vehicle. Refer to engine removal procedures in TM 9-2320-273-20 and TM 9-2320-273-34 for M915/Big Cam I and TM 9-2320-283-20 and TM 9-2320-283-34 for M915A1/Big Cam III.
- b. Inspect, upon receipt of engine, that all components are complete and that no engine subassemblies have been removed. Refer to information on engine dress upon removal in TM 9-2320-273-34 for M915/Big Cam I and TM 9-2320-283-34 for M915A1/Big Cam III.
- c. If the engine has been transferred to you from another DS/GS maintenance facility, check the equipment against the packing slip to see if the shipment is complete. Report all discrepancies in accordance with instructions in TM 38-750.

Section III. TROUBLESHOOTING**2-6. GENERAL**

a. This section provides troubleshooting information to diagnose and correct engine malfunctions in conjunction with troubleshooting procedures in TM 9-2320-273-20 and TM 9-2320-273-34 for M915/Big Cam I and TM 9-2320-283-20 and TM 9-2320-283-34 for M915A1/Big Cam III. For further engine troubleshooting information, refer to the Cummins troubleshooting and repair manual, NT 855 Engines, Bulletin No. 3810298-00.

b. The troubleshooting procedures are organized by malfunction, followed by steps instructing you to perform a test or inspection to determine the corrective action required. The corrective action is then provided and the appropriate procedure paragraph number(s) is given. The steps listed under each malfunction are in the order in which the causes are most likely to occur.

WARNING

Operation of a deadlined vehicle without preliminary inspection will cause further damage to a malfunctioning component and possible injury to personnel.

- c. Check all tags, service request forms, and vehicle logbooks for repair history. This may lead to the source of the problems.
- d. Debrief the operator (if possible) for a general description of the problem, then attempt to verify the fault. If the same fault is observed, refer to the troubleshooting symptom index for the precise troubleshooting malfunction and procedures.
- e. Before correcting a problem, diagnose the cause of the problem. Do not allow the same failure to occur again. Engines very often are disassembled in search of the problem and the real evidence to its cause is destroyed. Check again to ensure an easier solution has not been overlooked.
- f. When troubleshooting, always check the easiest and most obvious things first. This simple rule saves time and trouble. For example, low power complaints are often the result of loose throttle linkage, dirty fuel, or clogged air filters, and excessive oil consumption is often the result of leaky gaskets or loose line connections.
- g. Doublecheck before disassembly. The source of many engine problems can be traced to more than one part in a system. For example, excessive fuel consumption may not be caused by the fuel pump alone. Instead, the trouble could be a clogged air cleaner or a restricted exhaust passage causing severe back pressure.
- h. If a fault is not discovered until out-of-truck maintenance of the engine, refer to the troubleshooting procedures as necessary at a point where the fault is encountered for further diagnosis.

2-7. TROUBLESHOOTING SYMPTOM INDEX

MALFUNCTION NO.	MALFUNCTION	TRUBLESHOOTING PROCEDURE PAGE
1.	Engine will not crank	2-3
2.	Engine cranks but fails to start	2-3
3.	Engine starting motor operates but does not engage ring gear	2-4
4.	Engine stops	2-4
5.	Engine fails to stop	2-4
6.	Engine overheats	2-4
7.	Excessive exhaust smoke	2-4
8.	Low oil pressure	2-5
9.	Engine knocks	2-5
10.	Excessive fuel consumption	2-5
11.	Excessive oil consumption	2-5
12.	Excessive engine vibration	2-7
13.	Engine will not idle	2-7
14.	Fuel leaks at pump or injector	2-8
15.	Engine does not develop full power	2-8
16.	Engine misses or runs erratically	2-8
17.	Excessive gear noise	2-9
18.	Excessive oil loss	2-9
19.	Sludge formation in crankcase	2-9
20.	Lubricating oil diluted	2-9
21.	Low compression	2-10
22.	Engine overspeed	2-10

NOTE
 For further engine troubleshooting information, refer to the Cummins Troubleshooting and Repair Manual, NT 855 Engine, Bulletin No. 3810298-00.

2-8. MECHANICAL TROUBLESHOOTING

Table 2-1. Mechanical Troubleshooting.

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
1. ENGINE WILL NOT CRANK		
Step 1.	Remove rocker covers, and rotate engine by attaching a socket and breaker bar to accessory drive nut. Check for bent pushrod(s), and valve(s) not opening or closing.	
		If valve(s) fail to open or close, manually open valve with 3/4-in. wrench. If valve(s) are seized, remove corresponding cylinder head (para. 3-24).
Step 2.	Test for mechanical or hydraulic seizure. Remove the fuel injectors (para. 3-23). Turn the engine over several times to displace the liquid from cylinders through the injector openings.	
		If engine can be turned freely after all liquids have been displaced, install the injectors. If the engine cannot be turned over freely by hand, disassemble the engine and replace the defective parts.
2. ENGINE CRANKS BUT FAILS TO START		
Step 1.	Test for broken fuel supply pump driveshaft.	
		Replace the injectors (paras. 3-23 and 3-82).

Table 2-1. Mechanical Troubleshooting (Contd).

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
Step 2.	Test for dirty or damaged injectors.	Replace injectors (paras. 3-23 and 3-82).
Step 3.	Test for defective fuel solenoid valve.	Replace fuel solenoid valve (para. 3-57).
Step 4.	Test for faulty fuel pump (disconnect fuel outlet hose; crank engine to see if fuel comes out).	Replace fuel pump (paras. 3-16 and 3-78).
Step 5.	Test for incorrect adjustment.	Adjust injectors (para. 3-85).
Step 6.	Test for incorrect valve clearance.	Adjust valve(s) (para. 3-85).
Step 7.	Test for incorrect injector timing.	Adjust injector system timing (para. 3-72).
3. ENGINE STARTING MOTOR OPERATES BUT DOES NOT ENGAGE THE RING GEAR		
Step 1.	Inspect for defective starter pinion gear.	Replace starter pinion gear (TM 9-2320-283-34).
Step 2.	Inspect for defective ring gear.	Replace ring gear (paras. 3-25 and 3-80).
4. ENGINE STOPS		
Step 1.	Check if engine is overheated.	See malfunction 6.
Step 2.	Check for loose fuel solenoid wire and defective fuel solenoid valve.	Replace fuel solenoid valve (para. 3-57).
Step 3.	Check for faulty fuel pump.	Replace fuel pump (paras. 3-16 and 3-78).
5. ENGINE FAILS TO STOP		
Step 1.	Check for stuck fuel solenoid valve.	Replace solenoid valve (para. 3-57).
Step 2.	Check for turbocharger oil seal leak in compressor end.	Replace compressor oil seal (para. 3-47).
6. ENGINE OVERHEATS		
	Check for leaking or noisy water pump.	Repair water pump (para. 3-64).
7. EXCESSIVE EXHAUST SMOKE		
Step 1.	Check for incorrect injector adjustment.	Adjust injectors (para. 3-85).
Step 2.	Check for defective fuel injector(s).	Replace defective fuel injector(s) (paras. 3-23 and 3-82).
Step 3.	Check for blocked fuel return line in fuel system.	Repair fuel return line (TM 9-2320-283-20).

Table 2-1. Mechanical Troubleshooting (Contd).

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

- Step 4. Check for improperly seated valves.
Reseat or replace valves (para. 3-35).
- Step 5. Check for incorrect injection timing.
Adjust injection system timing (para. 3-72).

8. LOW OIL PRESSURE

- Step 1. Check pressure regulator.
Free up pressure regulator or replace oil pump (paras. 3-19 and 3-74).
- Step 2. Check for spun camshaft bushing.
Replace camshaft bushing (para. 3-34).
- Step 3. Inspect oil pump gasket.
Replace gasket (para. 3-44).
- Step 4. Check for worn camshaft.
Replace camshaft (para. 3-40).
- Step 5. Check for worn crankshaft.
Replace crankshaft and install new bearings (para. 3-37).
- Step 6. Inspect main bearings.
Replace main bearings (para. 3-29).
- Step 7. Inspect connecting rod bearings.
Replace connecting rod bearings (para. 3-68).
- Step 8. Inspect oil pump gears.
Replace oil pump (paras. 3-19 and 3-74).
- Step 9. Check for high oil temperature. Inspect and clean oil cooler (para. 3-42).
- Step 10. Check for worn main bearings, connecting rod bearings, and crankshaft. Install new bearings and check crankshaft (paras. 3-68 and 3-69).

9. ENGINE KNOCKS

- Step 1. Check for broken piston.
Replace piston (paras. 3-29 and 3-69).
- Step 2. Check for broken injector cup.
Repair injector (para. 3-52).
- Step 3. Check for incorrect valve adjustment.
Adjust valves (para. 3-85).
- Step 4. Check for incorrect injector adjustment.
Adjust injectors (para. 3-85).
- Step 5. Check for loose connecting rod capscrews.
 - a. Tighten connecting rod capscrews to proper torque (para. 3-69).
 - b. Check bearings (para. 3-39).
- Step 6. Check for worn connecting rod bearings.
Replace connecting rod bearings (paras. 3-29, 3-39, and 3-69).

Table 2-1. Mechanical Troubleshooting (Contd).

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

- Step 7. Check for loose main bearing capscrews.
 - a. Torque main bearing capscrews (para. 3-68).
 - b. Check "e" bearings (para. 3-37).
- Step 8. Check for worn main bearings.
Replace main bearings (paras. 3-31 and 3-68).
- Step 9. Check for excessive crankshaft end clearance.
Check crankshaft end clearance (para. 3-68).
- Step 10. Check for worn crankshaft.
Replace crankshaft and install new bearings (paras. 3-31 and 3-68).
- Step 11. Check for worn piston pins.
Replace worn piston pins and bushings or replace rods (paras. 3-29, 3-39, and 3-69).
- Step 12. Check for broken piston.
Replace piston (paras. 3-29 and 3-69).
- Step 13. Check for incorrect injection timing.
Adjust injector system timing (para. 3-72).

10. EXCESSIVE FUEL CONSUMPTION

- Step 1. Check for incorrect valve and injector adjustment.
Adjust valves and injectors (para. 3-85).
- Step 2. Check for excessive fuel pressure.
Test and calibrate fuel pump (para. 3-63).
- Step 3. Check for restricted fuel drain.
Repair fuel crossover tubes (para. 3-35).
- Step 4. Check for defective injector(s).
Replace defective injector(s) (paras. 3-23 and 3-82).
- Step 5. Check for leaking cylinder head gasket(s).
Replace cylinder head gasket(s) (paras. 3-24 and 3-71).
- Step 6. Check for incorrect injection timing.
Adjust injector system timing (para. 3-72).

11. EXCESSIVE OIL CONSUMPTION

- Step 1. Check for external leaks.
 - a. Tighten the external oil connections.
 - b. Replace damaged gasket(s).
- Step 2. Check turbocharger oil seals.
Replace turbocharger oil seals (para. 3-47).
- Step 3. Check for worn, stuck, or broken piston rings.
Replace piston rings (paras. 3-29 and 3-69).
- Step 4. Check for worn piston(s) and cylinder liner(s).
Install new pistons and cylinder liners (paras. 3-67 and 3-69).
- Step 5. Check for cracked piston.
Replace damaged piston (paras. 3-29, 3-39, and 3-69).

Table 2-1. Mechanical Troubleshooting (Contd).

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

12. EXCESSIVE ENGINE VIBRATION

- Step 1. Check for loose or worn engine insulators.
Replace mounts (TM 9-2320-283-34).
- Step 2. Check for loose or worn cab insulators.
Replace insulators (TM 9-2320-283-34).
- Step 3. Check for burned valves.
Replace valves (para. 3-35).
- Step 4. Check for excessive flexdisk and ring gear runout.
Correct flexdisk and ring gear runout (para. 3-80).
- Step 5. Check for loose flexdisk and ring gear mounting screws.
Tighten flexdisk and ring gear mounting screws (para. 3-80).
- Step 6. Check for loose flywheel housing screws.
Tighten flywheel housing screws (para. 3-80).
- Step 7. Check for misalignment of flywheel housing.
Align flywheel housing (para. 3-80).
- Step 8. Check for unbalanced flexdisk and ring gear.
Replace the flexdisk and ring gear (paras. 3-25 and 3-80).
- Step 9. Check for loose vibration damper.
Tighten vibration damper screws (para. 3-79).
- Step 10. Check for unbalanced vibration damper.
Install new vibration damper (para. 3-79).
- Step 11. Check adjustment of valves and injectors.
Adjust valves and injectors (para. 3-85).
- Step 12. Check timing for air compressor.
Adjust air compressor timing (para. 3-72).
- Step 13. Check for incorrect injection timing.
Adjust injector system timing (para. 3-72).
- Step 14. Check for excessive flywheel runout.
Correct flywheel runout (para. 3-38).
- Step 15. Check for unbalanced flywheel or one or more injectors not performing properly.
 - a. Replace flywheel (para. 3-38, step 16).
 - b. Replace faulty injectors (para. 3-52).

13. ENGINE WILL NOT IDLE

- Step 1. Check fuel pump idle setting.
Adjust idle setting (para. 3-93).
- Step 2. Check for improperly assembled governor spring.
Assemble governor spring correctly (para. 3-60).

Table 2-1. Mechanical Troubleshooting (Contd).

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
	Step 3.	Check for stuck governor spring plunger. Free governor spring plunger (para. 3-60).
	Step 4.	Check for plugged governor barrel. Clean governor barrel (para. 3-61).
14.	FUEL LEAKS AT FUEL PUMP OR INJECTOR	
	Step 1.	Check for faulty seals and O-rings in fuel pump. Install new seals and O-rings (para. 3-61).
	Step 2.	Check for mutilated injector O-rings. Replace injector mounting O-rings (paras. 3-23 and 3-82).
	Step 3.	Check for faulty fuel filter gasket. Replace gasket (paras. 3-58 and 3-62).
15.	ENGINE DOES NOT DEVELOP FULL POWER	
	Step 1.	Check for damaged turbocharger. Repair turbocharger (para. 3-47).
	Step 2.	Check for improperly adjusted valves and injectors. Adjust valves and injectors (para. 3-85).
	Step 3.	Check for worn or scored fuel pump components. Repair or replace fuel pump (paras. 3-16, 3-56, and 3-78).
	Step 4.	Check for dirty fuel injector(s). Clean fuel injector(s) (para. 3-52).
	Step 5.	Check for scuffed cylinder liners. Replace cylinder liners (paras. 3-30 and 3-67).
	Step 6.	Check for incorrect injection timing. Adjust injection system timing (para. 3-72).
	Step 7.	Check for plugged electric shutoff (solenoid) valve. Clean electric shutoff valve (solenoid) (para. 3-57).
	Step 8.	Check for plugged fuel pump throttle control shaft. Clean or replace the fuel pump throttle control shaft (para. 3-62).
	Step 9.	Check for burned valves. Reface or replace valves and valve seats (para. 3-57).
	Step 10.	Check for plugged Air Fuel Control (AFC) breather (check valve). Replace the AFC breather (para. 3-62).
16.	ENGINE MISSES OR RUNS ERRATICALLY	
	Step 1.	Check for improperly adjusted valves and injectors. Adjust valves and injectors (para. 3-85).
	Step 2.	Check injector for leaking middle O-ring. Replace injector middle O-ring (paras. 3-23 and 3-82).
	Step 3.	Check for damaged rocker arms. Replace rocker arms (paras. 3-22 and 3-84).

Table 2-1. Mechanical Troubleshooting (Contd).

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
Step 4.	Check for broken fuel injector plunger spring.	Replace fuel injector plunger spring (para. 3-52).
Step 5.	Check for broken or deformed injector cup.	Replace injector cup (para. 3-52).
Step 6.	Check for plugged injector cup spray holes.	Clean injector cups (para. 3-52).
Step 7.	Check for plugged metering or drain orifice in fuel injectors.	Clean fuel injectors (para. 3-52).
Step 8.	Check for burned or excessively pitted valves.	Reface or replace valves and valve seat inserts (para. 3-35).
Step 9.	Check for cracked or broken valve seat inserts.	Replace damaged valve seat inserts (para. 3-35).
Step 10.	Check for incorrect injection timing.	Adjust injection system timing (para. 3-72).
Step 11.	Check for leaking injector sleeves.	Replace injector sleeves (para. 3-53).
17.	EXCESSIVE GEAR NOISE	
Step 1.	Check for broken or worn gear teeth.	Replace gears or units having damaged teeth (refer to index for appropriate paragraphs).
Step 2.	Check for excessive gear backlash.	Replace defective gears or shafts (refer to index for appropriate paragraphs).
18.	EXCESSIVE OIL LOSS	
Step 1.	Check for cracked or broken front gearcase cover.	Replace front gearcase cover (paras. 3-27 and 3-75).
Step 2.	Check for defective seals and gaskets.	Replace faulty seals and gaskets as required.
Step 3.	Check for leaking rear cover oil seal or gaskets.	Replace rear cover oil seal or gaskets (paras. 3-25 and 3-80).
19.	SLUDGE FORMATION IN CRANKCASE	
	Check for moisture in crankcase.	Isolate the source and repair as required.
	Inspect for tears on head gaskets cylinder openings.	
20.	LUBRICATING OIL DILUTED	
Step 1.	Check for moisture in crankcase.	Isolate the source and repair as required.
	Inspect for tears at head gaskets cylinder openings.	
Step 2.	Check injector for damaged O-ring.	Replace injector O-ring (para. 3-52).

Table 2-1. Mechanical Troubleshooting (Contd).

MALFUNCTION	TEST OR INSPECTION	CORRECTIVE ACTION
-------------	--------------------	-------------------

Step 3. Check for defective injector(s).
 Repair or replace injectors (paras. 3-23, 3-52, and 3-82).

Step 4. Check for broken piston.
 Replace piston (paras. 3-29 and 3-69).

Step 5. Check for cracked or broken piston rings.
 Replace broken piston rings (para. 3-39).

21. LOW COMPRESSION

Step 1. Check adjustment of valve and injectors.
 Adjust valves and injectors (para. 3-85).

Step 2. Check for worn cylinder liners.
 Replace cylinder liners (paras. 3-30 and 3-67).

Step 3. Check for leaking cylinder head gasket.
 Replace gasket (paras. 3-24 and 3-71).

Step 4. Check for worn piston rings.
 Replace piston rings (paras. 3-29 and 3-69).

Step 5. Check for incorrect timing.
 Adjust injection system timing (para. 3-72).

Step 6. Check for valves not seating.
 Reface valves and seats (para. 3-35).

22. ENGINE OVERSPEED

Step 1. Check for improperly adjusted governor.
 Adjust governor (para. 3-93).

Step 2. Check for defective governor or fuel pump.
 Repair governor or fuel injection pump as necessary (paras. 3-61 and 3-56).

CHAPTER 3 MAINTENANCE

Section I.	General Maintenance Instructions
Section II.	Disassembly
Section III.	Repair
Section IV.	Assembly
Section V.	Testing
Section VI.	Storage

Section I. GENERAL MAINTENANCE INSTRUCTIONS

3-1. OVERVIEW

NOTE

All information contained in this manual applies to both M915 and M915A4/Big Cam I and M915A1 and M915A4/Big Cam III engines except where differences are specifically noted.

- a. This chapter provides maintenance instructions for repair of the engine and components/parts authorized for direct support and general support levels.
- b. Each section has a task summary listing procedures covered in that section.

3-2. GENERAL

- a. This section provides general instructions for lifting, draining, cleaning, inspection, wear limits and tolerances, repair, and assembly of the engine and component parts.
 - b. Use the following guidelines during maintenance of the engine:
 - (1) Physically check all tags and forms attached to the equipment to determine the reason for its removal from service, and check that all equipment changes or modifications from Technical Bulletins (TB) and Modification Work Orders (MWO) have been accomplished.
 - (2) Following the procedures provided, disassemble the equipment, and inspect and evaluate each component to determine extent of repair required to bring the equipment to the standards specified in this manual.
 - (3) As components and accessories are removed, note clearances and any fit problems. Record these to serve as a guide during repair and assembly.
 - (4) Repair and replacement standards for engine components are in Appendix F.
 - (5) Engine valve and injector adjustments are in paragraph 3-85.
 - (6) Engine retarder adjustments are in paragraph 3-86.
 - (7) On-engine fuel pump adjustments are in paragraph 3-93.
- c. Publications which provide additional information on general shop practice techniques, preservation, welding, sheet metal work, etc., are listed in Appendix A of this manual.
- d. To find a particular general maintenance instruction, use the task summary (para. 3-3).

3-3. TASK SUMMARY

TASK PARA	PROCEDURES
3-4.	Lifting Engine
3-5.	Draining Engine
3-6.	Cleaning <ul style="list-style-type: none"> a. General Instructions b. Importance of Cleaning c. External Engine Cleaning d. Disassembled Parts Cleaning e. Castings f. Oil Passages g. Oil Seals, Electrical Cables, and Flexible Hoses h. Ball-Roller Bearings
3-7.	Inspection <ul style="list-style-type: none"> a. General Instructions b. Castings c. Ball-Roller Bearings d. Studs, Bolts, and Screws e. Gears f. Bearings, Bushings, and Bushing-Type Bearings g. Oil Seals h. Core Hole Expansion Plugs
3-8.	Wear Limits and Tolerances
3-9.	Repair <ul style="list-style-type: none"> a. General Instructions b. Castings c. Ball-Roller Bearings d. Studs e. Gears f. Bushings and Bushing-Type Bearings g. Oil Seals h. Cylinder Block and Cylinder Head
3-10.	Assembly <ul style="list-style-type: none"> a. General b. Precautionary Rules c. Pipe Plugs

3-4. LIFTING ENGINE**WARNING**

The stamped, steel oil pan on M915A1/Big Cam III and M915/Big Cam I engines must not be used to support weight of engine; the pan will permanently deform and may collapse, allowing engine to fall over. Failure to comply may result in damage to equipment and injury to personnel.

Connect engine lifting fixture and a suitable sling to engine lifting brackets, and raise engine for draining, cleaning, and installation on maintenance stand. Refer to para. 3-13 and mount engine on maintenance stand.

3-5. DRAINING ENGINE

a. Remove oil drainplug from right rear side of oil pan. Drain engine oil completely, then replace drainplug. Tighten drainplug to 60-70 lb-ft (81-95 N•m). Remove oil filter (M915/Big Cam I) or bypass oil filter and full-flow oil filter (M915A1/Big Cam III) from oil cooler, and drain oil filter(s) and oil cooler housing.

b. Remove ether quick-start thermostat from right rear side of cylinder block. Open drainvalve on rear end of oil cooler. Open drainvalve on thermostat housing. Completely drain coolant from cylinder block and oil cooler, then close drainvalves and replace ether quick-start thermostat.

c. Open drainvalve on bottom of fuel/water separator. Completely drain fuel from separator, then close drainvalve.

3-6. CLEANING

a. **General Instructions.** Cleaning procedures will be the same for many of the parts and components that make up engine subassemblies. Follow general cleaning procedures detailed in steps b. through h.

b. **Importance of Cleaning.** Great care and effort are required in all cleaning operations. The presence of dirt and foreign material is a constant threat to satisfactory engine operation and maintenance. The following guidelines apply to all cleaning operations:

- (1) All parts must be cleaned prior to inspection, after repair, and before assembly.
- (2) Hands must be clean prior to handling cleaned parts.
- (3) After cleaning, all parts must be covered or wrapped in plastic or paper to protect them from dust and debris.

WARNING

- **Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.**
- **Compressed air used for cleaning purposes will not exceed 30 psi. Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.**

c. **External Engine Cleaning.** All electrical components or other parts that could become damaged by cleaning or moisture must be removed. Close all openings on the engine with waterproof tape or suitable plugs. Thoroughly clean all external parts and outer surfaces. Ensure no foreign material enters working parts of the engine. Wash the engine using water under pressure to remove mud and dirt. Remove oil and grease using a stiff brush and approved solvent. Dry engine with compressed air.

3-6. CLEANING (Contd)

d. **Disassembled Parts Cleaning.** Place all disassembled parts in suitable wire baskets for cleaning.

- (1) Dry and cover all cleaned parts.
- (2) Place cleaned parts in containers or holding racks for inspection or repair.
- (3) All parts subject to oxidation and rust must be lightly oiled and wrapped.
- (4) Keep all related parts and components together. Do not mix parts.

WARNING

Improper cleaning methods and use of unauthorized cleaning solvents will not be used. Refer to TM 9-247 for proper cleaning methods and solvents. Failure to comply may result in damage to equipment or injury to personnel.

e. **Castings.**

(1) Clean inner and outer surfaces of castings (and all areas subject to grease and oil) with cleaning solvents. Refer to TM 9-247.

- (2) Use a stiff brush to remove sludge and gum deposits.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.

- (3) Use compressed air to blow out all tapped screw holes and to dry castings after cleaning.

f. **Oil Passages.** Particular attention must be given to all oil passages in castings and machined parts. All oil passages must be clean and free of any obstructions.

- (1) Clean oil passages with wire brush probes to break up any sludge or gum deposits.
- (2) Wash passages by flushing with solvent. See TM 9-247.
- (3) Dry passages with compressed air.

CAUTION

Do not allow cleaning solvents to come in contact with seals, cables, or flexible hoses. Solvents can cause leather, rubber, and some synthetic materials to dry out, rot, and lose pliability, making them unserviceable.

g. **Oil Seals, Electrical Cables, and Flexible Hoses.** Clean with soap and water.

h. **Ball-Roller Bearings.**

(1) Bearings require special cleaning. After removing surface oil and gum deposits, place bearing in hot oil, 140°F (60°C), to loosen congealed oil and grease. Wipe bearings dry (do not use compressed air). After cleaning, coat bearings with oil, wrap in paper, and hold for inspection.

- (2) See TM 9-214 for information about care of bearings.

3-7. INSPECTION

a. **General Instructions.** Inspection procedures will be the same for many of the engine parts and components that make up the engine subassemblies. Follow the general procedures for inspection detailed in steps b. through h. Dimensional standards for various parts have been fixed at extremely close tolerances: use the repair standards specification tables in Appendix F. Use specified inspection equipment for inspection where cracks or other damage cannot be otherwise found. Exercise extreme care in all phases of inspection.

3-7. INSPECTION (Contd)**b. Castings.**

- (1) Inspect castings for cracks using a magnifying glass and bright lighting.
- (2) Refer to MIGI-68866 (Inspection Process, Penetrant Methods) and MIGG-6868 (Inspection Process, Magnetic Particles).
- (3) Closely check area around studs, pipe plugs, threaded inserts, and sharp corners. Replace all cracked castings.
- (4) Inspect machined surfaces for nicks, burrs, or raised metal. Mark damaged areas for repair or replacement.
- (5) Inspect all pipe plugs, pipe plug openings, screws, and screw openings for damaged or stripped threads.
- (6) Use a straightedge or surface plate and check all gasket mating surfaces, flanges on housings, and supports for warpage. Inspect mating flanges for discoloration, which may indicate persistent oil leakage.
- (7) Check all castings for conformance to applicable repair standards.

c. Ball-Roller Bearings. See TM 9-214 for inspection of bearings. Check all bearings for conformance to applicable repair standards (Appendix F).

d. Studs, Bolts, and Screws. Replace studs, bolts, and screws if bent, loose, or threads are stretched or damaged.

e. Gears.**NOTE**

There are no established gear teeth wear limits. Replace gears if any obvious physical damage to teeth or keyway slots is evident.

- (1) Inspect all gears for cracks using a magnifying glass and bright lighting. No cracks are allowed.
- (2) Inspect gear teeth for apparent excessive wear, sharp edges, chips, burrs, and galled or pitted surfaces.
- (3) Check keyway slots for wear and/or damage.

CAUTION

Engine connecting rod bearings and main bearings are supplied in sets. Replacement of a single bearing is not permitted. If one bearing has failed, all bearings must be replaced.

f. Bearings, Bushings, and Bushing-Type Bearings.

- (1) Check all bushings and bushing-type bearings for secure fit, evidence of heating, wear, burrs, nicks, and out-of-round condition.
- (2) Check for dirt in lubrication holes or grooves. Holes and grooves must be clean and free from damage.

g. Oil Seals. Oil seals should always be replaced.

h. Core Hole Expansion Plugs. Inspect for leakage. Replace plug when leakage is present.

3-8. WEAR LIMITS AND TOLERANCES

Refer to Appendix F for engine wear limits and tolerances.

3-9. REPAIR

a. General Instructions. General procedures for repair of engine parts and components are detailed in steps b. through h.

3-9. REPAIR (Contd)

CAUTION

Repaired items must be thoroughly cleaned to remove metal chips and abrasives to prevent them from entering working parts of engine. Refer to Cleaning, para. 3-6.

b. Castings.

- (1) All cracked castings will be replaced.
- (2) Only minor repairs to machined surfaces, flanges, and gasket mating surfaces are permitted. Remove minor nicks, burrs, and/or scratches with:
 - (a) Fine mill file.
 - (b) Crocus cloth dipped in cleaning solvent.
 - (c) Lapping across a surface plate.
- (3) Remachining of machined surfaces to repair damage, warpage, or uneven surfaces is not permitted. Replace casting.
- (4) Repair damaged pipe threads and machine threads in castings with the proper thread tap. Repair oversize holes with threaded inserts.

c. Ball-Roller Bearings. See TM 9-214.

d. Studs. Replace all bent or stretched studs. Repair minor thread damage with a thread chaser. Replace studs having stripped or damaged threads as outlined below:

- (1) Using a stud remover, remove stud. Back stud out slowly to avoid heat buildup and seizure, which can cause stud to break off.

CAUTION

See TM 9-237 (Welding Instructions) to avoid damage to castings if welding method is used.

- (2) If studs break off too short to use a stud remover, use an extractor or the "welding method."
- (3) Broken studs can be removed by welding bar stock or a nut to stud and removing with wrench.

NOTE

Standard studs may have a coarse thread on one end and a fine thread on the other end. The coarse threaded end is usually installed on the casting. Studs having coarse threads at both ends are used in some applications. The shorter threaded end is intended to be installed on the casting. See Appendix B for correct part number.

- (4) All replacement studs have a special coating and must have a small amount of antiseize compound (MIL-A-13881) applied to their threads before installing. Install replacement stud slowly to prevent heat buildup and snapping off.

e. Gears.

- (1) Remove gears using suitable pullers.
- (2) Use the same methods described in para. 3-9.b., step 2, to remove minor nicks, burrs, or scratches from gear teeth.
- (3) If keyways are worn or enlarged, replace gear.

f. Bushings and Bushing-Type Bearings. When bushings and bushing-type bearings become seized to a shaft or spin in a bore, they must be replaced along with their associated parts.

g. Oil Seals.

- (1) Remove oil seals by pressing or prying out, being careful not to damage casting or adapter bore.
- (2) Always install new oil seals using proper seal driver tool.

3-9. REPAIR (Contd)

h. Cylinder Block and Cylinder Head. Repair of cylinder block and cylinder head is limited to repair procedures outlined in paras. 3-34 and 3-35. Measurements found to be outside tolerance limits listed in Appendix F will require replacement of block or head.

3-10. ASSEMBLY

a. General. Extreme care must be exercised in all component assembly operations to ensure satisfactory engine performance. Precautionary rules for assembly are detailed in step b.

b. Precautionary Rules.

(1) Cleanliness is essential in all component assembly operations. Dirt and dust, even in very small quantities, are abrasive. Parts must be cleaned, as specified, and kept clean until assembly. Wrap or cover parts and components when assembly procedures are not immediately completed.

(2) Coat all bearings and contact surfaces with engine oil OE/HDO-10 (MIL-L2 104C) to ensure lubrication of parts during initial engine starting.

(3) Replace all gaskets and preformed packings during assembly.

c. Pipe Plugs. Certain pipe plugs require liquid thread sealant applied to pipe threads prior to installation of plug. This is done to provide a better seal, and will permit easier removal of pipe plug. Those pipe plugs requiring sealant will be identified in the task step prior to installation. The method of sealing these particular plugs is as follows:

(1) Ensure the pipe plug is thoroughly clean and dry prior to applying sealant. All dirt, grease, oil, and scale must be removed.

(2) Apply sealant one or two threads from the small or leading edge of plug.

(3) Apply sealant in the same direction as threads. Ensure sealant flows into inside diameter of threads.

(4) Tighten pipe plugs to their specified torque value. Do not use power tools. Torque limits for engine parts are provided in Appendix E.

Section II. DISASSEMBLY

3-11. GENERAL

a. This section provides maintenance procedures for preparation of engine for mounting on maintenance stand, removal of major components, and disassembly into subassemblies. The following procedures are for the engine removed from the vehicle.

b. In cases where it may only be necessary, or more time efficient, to partially disassemble the engine while installed in vehicle, follow the applicable portions of the tasks contained in this section to remove the part or component.

c. In the task summary listed below, a complete list of special tools, test equipment, materials, parts, and related information required to perform a complete engine disassembly is provided. To find a specific engine disassembly procedure contained in this section, see list of tasks below.

3-12. TASK SUMMARY

List of Tasks

TASK	PROCEDURES	TASK PARA.	TROUBLESHOOTING REF. NO. (PARA.)
1.	Mounting Engine on Maintenance Stand a. Lifting b. Draining c. Cleaning d. Inspection e. Component Removal f. Mounting to Maintenance Stand	3-13 3-13a 3-13b 3-13c 3-13d 3-13e 3-13f	2-8
2.	Vibration Damper and Crankshaft Pulley Removal	3-14	2-8
3.	Accessory Drive Pulley Removal	3-15	
4.	Fuel Pump Removal	3-16	2-8
5.	Air Compressor Removal	3-17	2-8
6.	Accessory Drive Housing Assembly Removal	3-18	2-8
7.	Oil Pump Removal	3-19	2-8
8.	Air Aftercooler Removal	3-20	2-8
9.	Engine Retarder Removal	3-21	2-8
10.	Rocker Arm Housing Assembly and Pushrods Removal	3-22	2-8
11.	Injector Assembly Removal	3-23	2-8
12.	Cylinder Head Assembly Removal	3-24	2-8
13.	Flexplate or Flywheel, Flywheel Housing, and Rear Cover Removal	3-25	2-8
14.	Oil Pan Removal	3-26	2-8
15.	Front Gear Cover Removal	3-27	2-8

3-12. TASK SUMMARY (Contd)

TASK	PROCEDURES	TASK PARA.	TROUBLESHOOTING REF. NO. (PARA.)
16.	Cam Follower Assemblies and Camshaft Removal	3-28	2-8
17.	Piston, Connecting Rod, and Bearings Removal	3-29	2-8
18.	Cylinder Liner Removal	3-30	2-8
19.	Engine Crankshaft and Main Bearing Removal	3-31	2-8

3-13. MOUNTING ENGINE ON MAINTENANCE STAND

THIS TASK COVERS:

- | | |
|---------------------------------------------------|------------------------------------------------------------------------------------|
| <p>a. Lifting
b. Draining
c. Cleaning</p> | <p>d. Inspection
e. Component Removal
f. Mounting to Maintenance Stand</p> |
|---------------------------------------------------|------------------------------------------------------------------------------------|

INITIAL SETUP:

APPLICABLE CONFIGURATIONS

All

SPECIAL TOOLS

Engine lifting fixture (15434) ST-125
Engine stand (NSN 1740-00-338-6673) or suitable stand

TEST EQUIPMENT

None

MATERIALS/PARTS

Solvent, SD-3 (Appendix C, Item 30)
Cap and plug set (Appendix C, Item 31)
Six gaskets (15434) 3020943
Eight lockwashers (15434) 109594
Six lockwashers (96906) MS35338-48
Two lockwashers (96906) MS35338-46
Six lockwashers (15434) S-604
Gasket (15434) 3031858
Gasket (15434) 3008017
Gasket (15434) 70089-1
Six preformed packings (15434) 3007442

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES

LO 9-2320-273-12
TM 9-2320-273-20
TM 9-2320-273-34
LO 9-2320-283-12
TM 9-2320-283-20
TM 9-2320-283-34

TROUBLESHOOTING REFERENCES

para. 2-8

EQUIPMENT CONDITION

- Engine removed from vehicle (TM 9-2320-273-34 or TM 9-2320-283-34).
- Starter motor and solenoid removed (TM 9-2320-273-20 or TM 9-2320-283-20).
- Alternator, belts, and bracket removed (TM 9-2320-273-20 or TM 9-2320-283-20).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

- All personnel must stand clear during lifting operations.
- Use extreme caution during disassembly; engine components are heavy.
- Diesel fuel is flammable.
- Use approved solvents in well-ventilated area.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Lifting

WARNING

All personnel must stand clear during lifting operations. A snapped chain or swinging or shifting load may result in injury to personnel.

- | | | |
|--------------------------------|---------------------------------------|-------------------------------------|
| 1. Dressed engine assembly (1) | a. Connect engine lifting fixture (2) | to two engine lifting brackets (3). |
|--------------------------------|---------------------------------------|-------------------------------------|


3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

NOTE
Assistant will help with step 1.

b. Using suitable sling and lifting device, lift engine for draining and cleaning,

Ensure lifting device and engine lifting fixture (2) distribute load equally on engine lifting brackets (3).



LEGEND:

- | | |
|------------------------------------|--------------------------------------------------------|
| 1. DRESSED ENGINE ASSEMBLY | 7. OIL COOLER WATER DRAINVALVE |
| 2. ENGINE LIFTING FIXTURE | 8. ETHER QUICK-START THERMOSTAT WIRE HARNESS CONNECTOR |
| 3. ENGINE LIFTING BRACKET (2) | 9. ETHER QUICK-START THERMOSTAT |
| 4. FUEL/WATER SEPARATOR DRAINVALVE | 10. THERMOSTAT HOUSING DRAINVALVE |
| 5. WASHER | |
| 6. OIL DRAINPLUG | |

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Draining

NOTE

Use separate containers for draining each system.

- | | | | |
|----|-------------------|-------------------------------------------------------------------------------------|-------------------------|
| 2. | Oil drainplug (6) | a. Remove from oil pan (13).
b. Install on oil pan (13) when oil stops draining. | Allow oil to drain out. |
|----|-------------------|-------------------------------------------------------------------------------------|-------------------------|

WARNING

Do not perform fuel system procedures while smoking or within 50 ft (15.2 m) of sparks or open flame. Diesel fuel is flammable and may explode. Failure to comply may result in injury to personnel and/or damage to equipment.

- | | | | |
|----|-----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|----------------------------------------------------|
| 3. | Fuel/water separator drainvalve (4) | a. Open.

b. Close when fuel stops draining. | Allow fuel to drain out. |
| 4. | Ether quick-start thermostat wire harness connector (8) and either quick-start thermostat (9) | a. Disconnect connector (8) from thermostat (9).

b. Remove from cylinder block (12). | Drain coolant from cylinder block (12). |
| 5. | Oil cooler water drainvalve (7) | Open. | Drain coolant from oil cooler. |
| 6. | Thermostat housing drainvalve (10) | Open. | Provides air vent for draining thermostat housing. |
| 7. | Ether quick-start thermostat (9) | Install on cylinder block (12) when coolant stops draining. | Do not tighten. |
| 8. | Drainvalves (7) and (10) | Close when coolant stops draining. | |

c. Cleaning

- | | | | |
|----|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------|
| 9. | Dressed engine assembly (1) | a. Cover all openings with water-proof tape or suitable caps or plugs.
b. Clean all external parts and outer surfaces.

c. Remove mud and dirt using water under pressure. | Ensure no foreign material enters the working parts of engine. |
|----|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------|

WARNING

Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

- | | |
|----|-----------------------------------------------------------------|
| d. | Remove oil and grease using a stiff brush and approved solvent. |
|----|-----------------------------------------------------------------|

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)

LOCATION/ITEM

ACTION


REMARKS

WARNING

The stamped steel oil pan on M915A1/Big Cam III or M915/Big Cam I engines must not be used to support weight of engine; the pan will permanently deform and may collapse allowing engine to fall over. Failure to comply may result in damage to equipment and injury to personnel.

e. After cleaning, set on engine stand or suitable blocks, and remove lifting fixture (2) from two lifting brackets (3).

Ensure engine is supported by cylinder block (12), flywheel housing (14), or front support (11). Do not support engine on oil pan (13).



LEGEND:

- 1. DRESSED ENGINE ASSEMBLY
- 2. ENGINE LIFTING FIXTURE
- 3. ENGINE LIFTING BRACKET (2)
- 4. FUEL/WATER SEPARATOR DRAINVALVE
- 5. WASHER
- 6. OIL DRAINPLUG
- 7. OIL COOLER WATER DRAINVALVE

- 8. ETHER QUICK-START THERMOSTAT WIRE HARNESS CONNECTOR
- 9. ETHER QUICK-START THERMOSTAT
- 10. THERMOSTAT HOUSING DRAINVALVE
- 11. FRONT SUPPORT
- 12. CYLINDER BLOCK
- 13. OIL PAN
- 14. FLYWHEEL HOUSING

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Inspection

10. Dressed engine assembly (1)	Inspect external surfaces and components for bent, broken, or otherwise damaged condition of parts.	Mark damaged areas to serve as a guide for repair or replacement of defective/damaged parts.
---------------------------------	-----------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------


e. Component Removal

11. Oil pressure gauge sending unit (16) and low oil pressure warning light sending unit (17)	Remove from cylinder block (12).	
-----------------------------------------------------------------------------------------------	----------------------------------	--

NOTE
Perform step 12 for M915/Big Cam I engines only.

12. Transmission control-body heating elements ON/OFF switch (15)	Remove from cylinder block (12).	
13. Heater return tube	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
14. Heater control valve, shutoff valve, and supply tube	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
15. Oil level dipstick	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
16. Screw (21), lockwasher (20), and washer (19)	Remove from cylinder block (12) and tube brace (18).	Discard lockwasher (20).
17. Remove nut (23), lockwasher (24), two washers (25), screw (30), clamp (26), and tube brace (18)	Remove from oil level dipstick tube and cover (22).	Discard lockwasher (24).
18. Four captive washer screws (27), washers (28), oil level dipstick tube and cover (22), and gasket (29)	Remove from cylinder block (12).	Discard gasket (29).
19. Oil breather tubes and hoses	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)



LEGEND:

- | | |
|-------------------------------------------------------------------------------|---------------------------------------|
| 1. DRESSED ENGINE ASSEMBLY | 22. OIL LEVEL DIPSTICK TUBE AND COVER |
| 12. CYLINDER BLOCK | 23. NUT |
| 15. TRANSMISSION CONTROL-BODY HEATING ELEMENTS ON/OFF SWITCH (BIG CAM I ONLY) | 24. LOCKWASHER |
| 16. OIL PRESSURE GAUGE SENDING UNIT | 25. WASHER (2) |
| 17. LOW OIL PRESSURE WARNING LIGHT SENDING UNIT | 26. CLAMP |
| 18. TUBE BRACE | 27. CAPTIVE WASHER SCREW (4) |
| 19. WASHER | 28. WASHER (4) |
| 20. LOCKWASHER | 29. GASKET |
| 21. SCREW | 30. SCREW |

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

e. Component Removal (Contd)

NOTE

Location of oil supply inlet port on turbochargers differs between models. M915A1/Big Cam III is shown.


20. Turbocharger air crossover connection	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
21. Screw (34), clamp (33), and turbocharger oil supply hose (32)	Remove from turbocharger (31), adapter (35), and elbow (36).	

NOTE

- Perform step 22 for M915/Big Cam I only.
- Perform steps 23 and 24 for M915A1/Big Cam III only.

22. Oil return tube (45), two clamps (46), and hose (47)	Remove from elbows (43) and (48).	
23. Oil return tube (41) and two bushings (42)	Remove from oil return tube (44) and filter head (49).	Retain bushings (42).
24. Oil return tube (44), two clamps (46), and hose (47)	Remove from elbows (40) and (48).	
25. Four nuts (39), turbocharger (31), and gasket (38)	Remove from studs (37) and exhaust manifold (50).	Discard gasket (38).

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)



NOTE

M915/Big Cam I engines have a single oil filter on engine and a bypass filter on firewall. M915A1/Big Cam III engine is shown.

LEGEND:

- | | | | |
|---------------------|--------------------------------|------------------------------------------|----------------------|
| 12. CYLINDER BLOCK | 37. STUD (4) | 42. BUSHING (M915A1/BIG CAM III)(2) | 46. CLAMP (2) |
| 31. TURBOCHARGER | 38. GASKET | 43. ELBOW (M915/BIG CAM I) | 47. HOSE |
| 32. OIL SUPPLY HOSE | 39. NUT (4) | 44. OIL RETURN TUBE (M915A1/BIG CAM III) | 48. ELBOW |
| 33. CLAMP | 40. ELBOW (M915A1/BIG CAM III) | 45. OIL RETURN TUBE (M915/BIG CAM I) | 49. FILTER HEAD |
| 34. SCREW | 41. OIL RETURN TUBE | | 50. EXHAUST MANIFOLD |
| 35. ADAPTER | | | |
| 36. ELBOW | | | |

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

e. Component Removal (Contd)


26. Water shutoff valves and hoses	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
27. Water filter and bracket	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.

NOTE

- Perform steps 28 and 29 for M915/Big Cam I only.
- Perform step 30 for M915A1/Big Cam III only.

28. Eight screws (55), lockwashers (54), and four lockplates (53)	Remove from cylinder heads (51) and exhaust manifold (52).	Discard lockwashers (54).
29. Four screws (56), lockplates (57), two dampers (58), and exhaust manifold (52)	Remove from cylinder heads (51) and six dowels (37).	Assistant will help hold exhaust manifold (52) during removal. Do not separate manifolds.
30. Twelve captive washer screws (59) and exhaust manifold (50)	Remove from cylinder heads (51).	Assistant will help hold exhaust manifold (50) during removal. Do not separate manifolds and spacer inserts (61).
31. Six gaskets (60)	Remove from cylinder heads (51) or exhaust manifold (52) or (50).	Discard gaskets (60).
32. Air compressor cooling tube	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
33. Water transfer tube and bracket	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
34. Fan clutch air valve and air lines	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
35. Thermostat and thermostat housing	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
36. Water manifolds	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
37. Lower water transfer tube	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
38. Engine oil filter elements	Remove and discard.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)



LEGEND:

- 37. DOWEL (4)
- 50. EXHAUST MANIFOLD (M915A1/BIG CAM III)
- 51. CYLINDER HEAD (3)
- 52. EXHAUST MANIFOLD (M915/BIG CAM I)
- 53. LOCKPLATE (4)
- 54. LOCKWASHER (8)
- 55. SCREW (8)

- 56. SCREW (4)
- 57. LOCKPLATE (4)
- 58. CLAMP (2)
- 59. CAPTIVE WASHER SCREW (12)
- 60. GASKET (6)
- 61. SPACER INSERTS (2) NEW DESIGN EXHAUST MANIFOLD (M915A1/BIG CAM III ONLY)

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

e. Component Removal (Contd)


39. Hot engine temperature switch	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
40. Water temperature sending unit	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.

NOTE

- Perform steps 41 through 43 for M915/Big Cam I only.
- Perform steps 44 and 45 for M915A1/Big Cam III only.

41. Screw (62) and lockwasher (63)	Remove from cylinder block (12) and support bracket (66).	Discard lockwasher (63).
42. Clamp (65)	Loosen at water transfer hose (64).	
43. Screw (71), two screws (67), screws (70), five lockwashers (63), oil cooler assembly (72), and gasket (68)	Remove from cylinder block (12), oil cooler support (69), and water transfer hose (64).	Free oil cooler assembly (72) by tapping with soft-nose hammer. Discard lockwashers (63) and gasket (68).
44. Two screws (73), lockwashers (74), and washers (75)	Remove from cylinder block (12) and support bracket (76).	Discard lockwashers (74).
45. Three screws (79), screws (81), six lockwashers (80), oil cooler assembly (82), and gasket (77)	Remove from cylinder block (12) and oil cooler support (78).	Free oil cooler support (78) by tapping with a soft-nose hammer.
46. Water pump bypass hose	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
47. Water pump to radiator connection	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
48. Water bypass tube	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
49. Air compressor discharge hose	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
50. Air compressor intake tube	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
51. Air compressor governor and air lines	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)



M915A1/BIG CAM III

M915/BIG CAM I

LEGEND:

- | | |
|-------------------------|-------------------------|
| 12. CYLINDER BLOCK | 72. OIL COOLER ASSEMBLY |
| 62. SCREW | 73. SCREW (2) |
| 63. LOCKWASHER (6) | 74. LOCKWASHER (2) |
| 64. WATER TRANSFER HOSE | 75. WASHER |
| 65. CLAMP | 76. SUPPORT BRACKET |
| 66. SUPPORT BRACKET | 77. GASKET |
| 67. SCREW (2) | 78. OIL COOLER SUPPORT |
| 68. GASKET | 79. SCREW (3) |
| 69. OIL COOLER SUPPORT | 80. LOCKWASHER (6) |
| 70. SCREW (2) | 81. SCREW (3) |
| 71. SCREW | 82. OIL COOLER ASSEMBLY |

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

e. Component Removal (Contd)


52. Modulator bracket and accelerator return spring	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
53. Ether quick-start cylinder, valve, and thermostat	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
54. Engine wiring harness connections	Tag for identification at reassembly, then disconnect.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
55. Engine wiring harness	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
56. Fan, fan clutch, and fan clutch drive belts	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
57. Fan brace, bracket, and spacers	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
58. Water pump and drive belts	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
59. Power steering pump and reservoir	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.

NOTE

- Perform steps 60 and 61 for M915/Big Cam I only.
- Perform steps 62 and 63 for M915A1/Big Cam III only.

60. Four clamps (65), two water transfer hoses (64), and water transfer tube (86)	Remove from flange (84).	
61. Six screws (83), flange (84), and gasket (85)	Remove from cylinder block (12).	Discard gasket (85).
62. Twelve captive washer screws (89), two water header covers (88), and gaskets (87)	Remove from cylinder block (12).	Discard gaskets (87).
63. Six self-locking screws (92), nozzles (91), and preformed packings (90)	Remove from cylinder block (12).	Discard preformed packings (90).

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)



LEGEND:

- 12. CYLINDER BLOCK
- 64. WATER TRANSFER HOSE (2)
- 65. CLAMPS (4)
- 83. SCREW (6)
- 84. FLANGE
- 85. GASKET
- 86. WATER TRANSFER TUBE

- 87. GASKET (2)
- 88. WATER HEADER COVER (2)
- 89. CAPTIVE WASHER SCREW (12)
- 90. PREFORMED PACKING (6)
- 91. PISTON COOLING NOZZLE (6)
- 92. SELF-LOCKING SCREW (6)

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)


LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

--

<p>64. Dressed engine assembly (1)</p>	<p>a. Connect lifting fixture (2) to two engine lifting brackets (3). b. Using suitable sling and lifting device, lift and move engine to a suitable maintenance stand (93). c. Install right side of cylinder block (12) on maintenance stand (93) with four mounting screws (94).</p>	<p>Ensure lifting device and engine lifting fixture (2) distribute load equally on engine lifting brackets (3).</p>
<p>65. Engine lifting fixture (2)</p>	<p>Remove from two engine lifting brackets (3).</p>	

FOLLOW-ON TASK: Proceed with engine maintenance.

3-13. MOUNTING ENGINE ON MAINTENANCE STAND (Contd)



LEGEND:

- 1. DRESSED ENGINE ASSEMBLY
- 2. ENGINE LIFTING FIXTURE
- 3. ENGINE LIFTING BRACKET (2)

- 12. CYLINDER BLOCK
- 93. MAINTENANCE STAND
- 94. MOUNTING SCREW (4)

3-14. VIBRATION DAMPER AND CRANKSHAFT PULLEY REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

None

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Engine mounted on maintenance stand (para. 3-13).

SPECIAL ENVIRONMENTAL CONDITION

Work area clean and away from blowing dust and dirt.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal

CAUTION

Do not pound on vibration damper with hammer or pry with other tools during removal. These tools may damage vibration damper.

Six hexagon screws (1), washers (2), vibration damper (3), and crankshaft pulley (4)


Remove from crankshaft (5).

Do not let crankshaft (5) turn when removing screws (1). Lock crankshaft (5) at flywheel end to keep from turning. Hold vibration damper (3) and crankshaft pulley (4) when removing last screw (1) to avoid dropping vibration damper (3).

FOLLOW-ON TASKS:

- For repair of vibration damper and crankshaft pulley (para. 3-36).
- For installation of vibration damper and crankshaft pulley (para. 3-79).

3-14. VIBRATION DAMPER AND CRANKSHAFT PULLEY REMOVAL (Contd)



LEGEND:

- 1. SCREW (6)
- 2. WASHER (6)
- 3. VIBRATION DAMPER

- 4. CRANKSHAFT PULLEY
- 5. CRANKSHAFT

3-15. ACCESSORY DRIVE PULLEY REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

REFERENCES (TM)

None

SPECIAL TOOLS

None

TROUBLESHOOTING REFERENCES

Para. 2-8

TEST EQUIPMENT

None

EQUIPMENT CONDITION

Vibration damper and crankshaft pulley removed (para. 3-14).

MATERIALS/PARTS

Locknut (15434) 3012526

SPECIAL ENVIRONMENTAL CONDITION

Work area clean and away from blowing dust and dirt.

PERSONNEL REQUIRED

Automotive repairman MOS 63H

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal

NOTE

Perform step 1 for M915A1/Big Cam III engines only.

1. Six screws (1) and accessory drive pulley (4)	Remove from accessory drive pulley assembly (6).	Do not let accessory drive pulley (4) rotate when removing screws (1). Hold onto accessory drive pulley (4) when removing last screw (1).
--------------------------------------------------	--------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------


CAUTION

- **Do not use jaw-type puller. Damage to pulley will result.**
- **When installing puller, ensure screws do not bottom out on front gear cover. Damage to cover may result.**

2. Locknut (2) and washer (3)	Remove from accessory driveshaft (7).	Discard locknut (2).
3. Accessory drive pulley assembly (6) (M915A1/ Big Cam III), accessory drive pulley (4) (M915/Big Cam I), keyway seal (5), and sleeve (8)	Using suitable puller, remove from accessory drive shaft (7).	Use caution not to damage accessory drive shaft (7). Do not use jaw-type puller; use puller as explained in above caution.

- FOLLOW-ON TASKS:**
- For repair of accessory drive pulley (para. 3-49).
 - For installation of accessory drive pulley (para. 3-76).

3-15. ACCESSORY DRIVE PULLEY REMOVAL (Contd)



LEGEND:

- 1. SCREW (6) (M915A1/BIG CAM III ONLY)
- 2. LOCKNUT
- 3. WASHER
- 4. ACCESSORY DRIVE PULLEY
- 5. KEYWAY SEAL

- 6. ACCESSORY DRIVE PULLEY ASSEMBLY (M915A1/BIG CAM III ONLY)
- 7. ACCESSORY DRIVE SHAFT
- 8. SLEEVE

3-16. FUEL PUMP REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Air compressor wrench (15434) 3375159

TEST EQUIPMENT

None

MATERIALS/PARTS

Cap and plug set (Appendix C, Item 31)

Lockwasher (12204) 116122

Lockwasher (96906) MS35338-46

Two lockwashers (96906) MS122032

Three lockwashers (15434) S-604

Gasket (15434) 3035053

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

TM 9-2320-273-20

TM 9-2320-283-20

TROUBLESHOOTING REFERENCES

None

EQUIPMENT CONDITION

- Accessory drive pulley removed (para. 3-15).
- Fuel pump engine retarder switch removed (TM 9-2320-273-20 or TM 9-2320-283-20).
- Fuel filter and water separator removed (TM 9-2320-273-20 or TM 9-2320-283-20).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dust and dirt.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal

NOTE

- **Cap or plug all openings immediately after removal to prevent contamination.**
- **Perform steps 1 through 4 for M915/Big Cam I equipped with Air Signal Attenuator (ASA) air tank. Some Big Cam I engines may or may not have an ASA air tank.**


1.	Four hose clamps (3) and two air supply hoses (6)	Remove from elbow (7), check valve (2), and two adapters (35).	
2.	Two adapters (35), check valve (2), and elbow (7)	Remove from fuel pump (33), air tank (12), and aftercooler (9).	
3.	Screw (11), lockwasher (5), washer (10), and air tank (12)	Remove from aftercooler (9) and clamp (1).	Discard lockwasher (5).
4.	Nut (4), lockwasher (5), screw (8), and clamp (1)	Remove from air tank (12).	Discard lockwasher (5).

NOTE

Perform step 5 for M915A1/Big Cam III only.

5.	Nut (4), lockwasher (13), washer (14), and screw (16)	Remove from bracket (15) and clamp (17).	Discard lockwasher (13).
6.	Air supply tube (18) and adapters (22) and (35)	Remove from fuel pump (33) and aftercooler (9).	

3-16. FUEL PUMP REMOVAL (Contd)



LEGEND:

- 1. CLAMP
- 2. CHECK VALVE
- 3. HOSE CLAMP (4)
- 4. NUT (2)
- 5. LOCKWASHER (2)
- 6. AIR SUPPLY HOSE (2)
(M915/BIG CAM I ONLY)
- 7. ELBOW
- 8. SCREW
- 9. AFTERCOOLER

- 10. WASHER
- 11. SCREW
- 12. ASA AIR TANK
(M915/BIG CAM I ONLY)
- 13. LOCKWASHER (2)
- 14. WASHER (2)
- 15. BRACKET
- 16. SCREW
- 17. CLAMP (2)
- 18. AIR SUPPLY TUBE

- (M915A1/BIG CAM III ONLY)
- 19. FUEL RETURN TUBE
- 20. CLAMP (3)
- 21. FUEL SUPPLY TUBE
- 22. ADAPTER
- 23. CYLINDER HEAD
- 24. ELBOW (2)
- 25. FUEL RETURN TUBE
- 26. SCREW (2)
- 27. TEE

- 28. FUEL RETURN TUBE
- 29. TEE
- 30. FUEL RETURN TUBE
- 31. ADAPTER
- 32. ADAPTER
- 33. FUEL PUMP
- 34. VALVE
- 35. ADAPTER (2)


3-16. FUEL PUMP REMOVAL (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal (Contd)

7. Two screws (26), washers (14), and lockwashers (13)	Remove from cylinder head (23) and clamps (17) and (20).	Discard lockwashers (13).
8. Fuel return tube (30)	Remove from tee (29) and fuel pump (33).	
9. Fuel return tubes (19), (25), (28), and tees (27) and (29)	Remove from valve (34) and elbow (24).	
10. Fuel supply tube (21)	Remove from adapter (32) and elbow (24).	
11. Two elbows (24), valve (34), and adapters (32) and (31)	Remove from cylinder head (23) and fuel pump (33).	

3-16. FUEL PUMP REMOVAL (Contd)



LEGEND:

- | | |
|----------------------|----------------------|
| 13. LOCKWASHER (2) | 26. SCREW (2) |
| 14. WASHER (2) | 27. TEE |
| 17. CLAMP (2) | 28. FUEL RETURN TUBE |
| 19. FUEL RETURN TUBE | 29. TEE |
| 20. CLAMP (3) | 30. FUEL RETURN TUBE |
| 21. FUEL SUPPLY TUBE | 31. ADAPTER |
| 23. CYLINDER HEAD | 32. ADAPTER |
| 24. ELBOW (2) | 33. FUEL PUMP |
| 25. FUEL RETURN TUBE | 34. VALVE |

3-16. FUEL PUMP REMOVAL (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal (Contd)


NOTE

- Perform step 12 for M915/Big Cam I only.
- Perform steps 13 and 14 for M915A1/Big Cam III only.

12. Four screws (40) and washers (39)	Remove from air compressor (36), fuel pump (33), and support bracket (43).	Ensure all fuel pump (33) openings are covered to prevent dirt from entering the fuel system. Use air compressor wrench (47) (3375159).
13. Screws (40) and (45) and and two washers (39)	Remove from air compressor (36), fuel pump (33), and support bracket (43).	Use air compressor wrench (47) (3375159) to remove screw (40).
14. Two screws (46) and washers (39)	Remove from air compressor (36) and fuel pump (33).	
15. Screw (41), lockwasher (42), and support bracket (43)	Remove from cylinder block (44).	Discard lockwasher (42).
16. Fuel pump (33)	Remove from air compressor (36).	Free fuel pump (33) by tapping with soft-nose hammer.
17. Fuel pump-to-compressor spider coupling (38)	Remove from fuel pump (33) or air compressor (36).	Coupling (38) may remain on either fuel pump (33) or air compressor (36) when separated.
18. Gasket (37)	Remove from fuel pump (33) or air compressor (36).	Gasket (37) may remain on either surface. Inspect each surface and discard gasket (37).

- FOLLOW-ON TASKS:
- For repair of fuel pump (para. 3-56).
 - For installation of fuel pump (para. 3-78).

3-16. FUEL PUMP REMOVAL (Contd)



LEGEND:

- 33. FUEL PUMP
- 36. AIR COMPRESSOR
- 37. GASKET
- 38. FUEL PUMP-TO-COMPRESSOR SPIDER COUPLING
- 39. WASHER (4)
- 40. SCREW (4)
- 41. SCREW

- 42. LOCKWASHER
- 43. SUPPORT BRACKET
- 44. CYLINDER BLOCK
- 45. SCREW
- 46. SCREW (2)
- 47. AIR COMPRESSOR WRENCH

3-17. AIR COMPRESSOR REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Air compressor wrench (15434) 3375159

TEST EQUIPMENT

None

MATERIALS/PARTS

Four lockwashers (12204) 116122
 Two lockwashers (96906) MS35338-45
 Gasket (15434) 157911
 Gasket (15434) 3005962

PERSONNEL REQUIRED

Automotive mechanic MOS 63H

REFERENCES (TM)

TM 9-2320-273-34

TM 9-2320-283-34

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

- Fuel pump removed (para. 3-16).
- Air compressor governor removed (TM 9-2320-273-34 or TM 9-2320-283-34).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


Removal

NOTE

Removal of air compressor coolant lines, air lines, and fittings is basically the same for M915/Big Cam I and M915A1/Big Cam III engines. The M915A1/Big Cam III is shown.

1. Coolant inlet tube (5) and coolant outlet tube (1)	Disconnect and remove from three adapters (3) and elbow (7).	Remove and discard bushings (2) if damaged.
2. Three adapters (3), elbow (7), and coupling (6)	Remove from compressor (4) and aftercooler.	
3. Air inlet hoses (9) and tube (11)	Loosen four clamps (10), and remove from air inlet connector (16) and elbow (8).	
4. Screws (12) and (15), two lockwashers (13), washers (14), plug (17), air inlet connector (16), and gasket (18)	Remove from compressor (4).	Discard lockwashers (13) and gasket (18).

3-17. AIR COMPRESSOR REMOVAL (Contd)



LEGEND:

- 1. COOLANT OUTLET TUBE
- 2. BUSHING (4)
- 3. ADAPTER (3)
- 4. COMPRESSOR
- 5. COOLANT INLET TUBE
- 6. COUPLING
- 7. ELBOW
- 8. ELBOW
- 9. HOSE (2)

- 10. CLAMP (4)
- 11. TUBE
- 12. SCREW
- 13. LOCKWASHER (2)
- 14. WASHER (2)
- 15. SCREW
- 16. AIR INLET CONNECTOR
- 17. PLUG
- 18. GASKET

3-17. AIR COMPRESSOR REMOVAL (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal (Contd)

5. Two screws (8) and lockwashers (5)	Remove from accessory drive housing (9) and air compressor (7).	Use air compressor wrench (10), (P/N 3375159). Discard lockwashers (5).
---------------------------------------	-----------------------------------------------------------------	-------------------------------------------------------------------------


NOTE

The M915/Big Cam I engines will not have washers as part of air compressor mounting hardware.

6. Two nuts (6) lockwashers (5), washers (4), gasket (3), and compressor (7)	Remove from accessory drive housing (9).	Hold air compressor (7) before removing last screw (1) and nut (6). Use air compressor wrench (10). Discard lockwashers (5) and gasket (3).
7. Drive coupling (2)	Remove from accessory drive housing (9) or compressor (7).	

- FOLLOW-ON TASKS:
- For repair of air compressor (para. 3-51).
 - For installation of air compressor (para. 3-77).

3-17. AIR COMPRESSOR REMOVAL (Contd)



LEGEND:

- | | |
|----------------------|----------------------------|
| 1. SCREW (2) | 6. NUT (2) |
| 2. DRIVE COUPLING | 7. AIR COMPRESSOR |
| 3. COMPRESSOR GASKET | 8. SCREW (2) |
| 4. WASHER (2) | 9. ACCESSORY DRIVE HOUSING |
| 5. LOCKWASHER (4) | 10. AIR COMPRESSOR WRENCH |

3-18. ACCESSORY DRIVE HOUSING ASSEMBLY REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

REFERENCE (TM)

None

SPECIAL TOOLS

None

TROUBLESHOOTING REFERENCES

Para. 2-8

TEST EQUIPMENT

None

EQUIPMENT CONDITION

Air compressor removed (para. 3-17).

MATERIALS/PARTS

Gasket (15434) 200809

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dust and dirt.

PERSONNEL REQUIRED

Automotive repairman MOS 63H

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal

Five captive washer screws (4), accessory drive housing assembly (3), and gasket (2)


Remove from front gear cover (1).

If loose, hold accessory drive housing assembly (3) when removing last screw (4). Otherwise, free housing (3) by tapping with soft-nose hammer. Discard gasket (2).

FOLLOW-ON TASKS:

- For repair of accessory drive housing assembly (para. 3-49).
- For installation of accessory drive housing assembly (para. 3-73).

3-18. ACCESSORY DRIVE HOUSING ASSEMBLY REMOVAL (Contd)



LEGEND:

- 1. FRONT GEAR COVER
- 2. HOUSING GASKET

- 3. ACCESSORY DRIVE HOUSING ASSEMBLY
- 4. CAPTIVE WASHER SCREW (5)

3-19. OIL PUMP REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Two lockwashers (96906) MS35338-46
 Seven lockwashers (96906) MS35338-47
 (M915/Big Cam I only)
 Nine lockwashers (15434) S-604 (M915A1/Big
 Cam III only)
 Gasket (15434) 121907 (M915/Big Cam I only)
 Gasket (15434) 3031434 (M915A1/Big
 Cam III only)
 Locknut (15434) S223
 Two preformed packings (15434) 3029847
 Gasket (15434) 3029846
 Gasket (15434) 157551

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Accessory drive housing assembly removed
 (para. 3-18).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and
 dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


Removal

NOTE

- Perform steps 1 through 6 to remove oil pump from M915A1/Big Cam III.
- Perform steps 7 through 12 to remove oil pump from M915/Big Cam I.

1. Two screws (12), lockwashers (11), and washers (10)	Remove from oil suction tube (9) and oil pan (13).	Discard lockwashers (11).
2. Two screws (14), lockwashers (11), and washers (10)	Remove from oil suction tube (9) and oil pump assembly (3).	Discard lockwashers (11).
3. Oil suction tube (9), two preformed packings (8), and gasket (7)	Remove from oil pan (13) and oil pump assembly (3).	Discard preformed packings (8) and gasket (7).
4. Oil transfer hose (4) (3) and cylinder block (1).	Remove from oil pump assembly	
5. Five screws (5) and lockwashers (6)	Remove from oil pump assembly (3).	Discard lockwashers (6).
6. Oil pump assembly (3) and gasket (2)	Remove from accessory drive housing (15).	Free oil pump assembly (3) by tapping with a soft-nose hammer. Discard gasket (2).

3-19. OIL PUMP REMOVAL (Contd)



M915A1/BIG CAM III ONLY

LEGEND:


- | | |
|--------------------------|-----------------------------|
| 1. CYLINDER BLOCK | 9. OIL SUCTION TUBE |
| 2. GASKET | 10. WASHER (4) |
| 3. OIL PUMP ASSEMBLY | 11. LOCKWASHER (4) |
| 4. OIL TRANSFER HOSE | 12. SCREW (2) |
| 5. SCREW (5) | 13. ENGINE OIL PAN |
| 6. LOCKWASHER (5) | 14. SCREW (2) |
| 7. GASKET | 15. ACCESSORY DRIVE HOUSING |
| 8. PREFORMED PACKING (2) | |

3-19. OIL PUMP REMOVAL (Contd)

LOCATION/ITEM	ACTION	REMARKS
Removal (Contd)		
7. Locknut (21), spacer (23), clamp (24), washer (25), lockwasher (6), and screw (26)	Remove from bracket (22) and oil suction hose (27).	Discard locknut (21) and lockwasher (6).
8. Screw (19), lockwasher (6), and bracket (22)	Remove from oil pan (31) and cylinder block (1).	Discard lockwasher (6).
9. Two screws (30), lockwashers (29), and gasket (28)	Remove from oil suction hose (27) and oil pan (31).	Discard lockwashers (29) and gasket (28).
10. Oil suction hose (27) and adapter (20)	Remove from oil pan (31) and oil pump assembly (17).	
11. Three screws (18), two screws (5), and five lockwashers (6)	Remove from accessory drive housing (15) and oil pump assembly (17).	Discard lockwashers (6).
12. Oil pump assembly (17) and gasket (16)	Remove from accessory drive housing (15).	Free oil pump assembly (17) by tapping with a soft-nose hammer. Discard gasket (16).

- FOLLOW-ON TASKS:
- For repair of oil pump (para. 3-44).
 - For installation of oil pump (para. 3-74).

3-19. OIL PUMP REMOVAL (Contd)



M915/BIG CAM I ONLY

LEGEND:

- | | | |
|-----------------------------|-------------|----------------------|
| 1. CYLINDER BLOCK | 19. SCREW | 26. SCREW |
| 5. SCREW (2) | 20. ADAPTER | 27. OIL SUCTION HOSE |
| 6. LOCKWASHER (7) | 21. LOCKNUT | 28. GASKET |
| 15. ACCESSORY DRIVE HOUSING | 22. BRACKET | 29. LOCKWASHER (2) |
| 16. GASKET | 23. SPACER | 30. SCREW (2) |
| 17. OIL PUMP ASSEMBLY | 24. CLAMP | 31. OIL PAN |
| 18. SCREW (3) | 25. WASHER | |

3-20. AIR AFTERCOOLER REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Three gaskets (15434) 3008591
 Three lockwashers (15434) S-604 (M915A1/Big Cam III only)
 Three lockwashers (96906) MS122032 (M915/Big Cam I only)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

TM 9-2320-273-20
 TM 9-2320-283-20

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

- Oil pump removed (para. 3-19).
- Water crossover tube and connections removed (TM 9-2320-273-20 or TM 9-2320-283-20).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dust and dirt.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal

NOTE


- Perform steps 1 and 2 for M915/Big Cam I only.
- Perform steps 3 and 4 for M915A1/Big Cam III only.

1.	Three screws (5), lockwashers (4), and washers (3)	Remove from cylinder heads (1) and air aftercooler (2).	Two screws (5) may have been previously removed. Discard lockwashers (4).
2.	Six screws (6) and washers (7)	Remove from cylinder heads (1) and air aftercooler (2).	Install one suitable guide pin at each end of air aftercooler (2) before removing last two screws (6).
3.	Screw (8), lockwasher (4), washer (3), two screws (5), lockwashers (4), and four washers (3)	Remove from cylinder heads (1) and air aftercooler (2).	Screws (5) may have been previously removed. Discard lockwashers (4).
4.	Six captive washer screws (6)	Remove from cylinder heads (1) and air aftercooler (2).	Install one suitable guide pin at each end of air aftercooler before removing last two screws.
5.	Air aftercooler (2)	Remove from cylinder heads (1) and lift off guide pins.	Remove guide pins from cylinder heads (1).
6.	Three gaskets (9)	Remove from cylinder heads (1) or air aftercooler (2).	Discard gaskets (9).

FOLLOW-ON TASKS:

- For repair of air aftercooler (para. 3-45).
- For installation of air aftercooler (para. 3-87).

3-20. AIR AFTERCOOLER REMOVAL (Contd)



LEGEND:

- | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1. CYLINDER HEAD (3)</p> <p>2. AIR AFTERCOOLER</p> <p>3. WASHER (3)</p> <p>4. LOCKWASHER (3)</p> <p>5. SCREW (3) (M915/BIG CAM I) OR (2) (M915A1/BIG CAM III)</p> | <p>6. SCREW (6) (M915/BIG CAM I ONLY), CAPTIVE WASHER SCREW (6) (M915A1/BIG CAM III ONLY)</p> <p>7. WASHER (6) (M915/BIG CAM I ONLY)</p> <p>8. SCREW (M915A1/BIG CAM III ONLY)</p> <p>9. GASKET (3)</p> |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

3-21. ENGINE RETARDER REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Gasket (75078) 010279

Preformed packing (75078) 010180

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

TM 9-2320-273-20

TM 9-2320-283-20

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

- Air aftercooler removed (para. 3-20).
- Rocker cover and gasket removed (TM 9-2320-273-20 or TM 9-2320-283-20).
- Engine lifting brackets removed (TM 9-2320-273-20 or TM 9-2320-283-20).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dust and dirt.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

NOTE

- The following procedure covers removal of one engine brake retarder.
- The removal of the remaining two engine brake retarders is similar.


Removal

1. Six nuts (3) and two locking plates (4)	Remove from six studs (1). Bend down tabs on locking plates (4) located on inside two studs (1) only.	If not removed, it will be necessary to remove fan support brace and spacers along with nuts (3).
2. Engine brake retarder (5)	Remove from rocker arm housing (7) by pulling straight up.	Mark location of each engine brake retarder (5) if more than one will be removed.
3. Gasket (2) and preformed packing (6)	Remove from rocker arm housing (7) or engine brake retarder (5).	Gasket (2) and preformed packing (6) may remain on engine brake retarder (5) or rocker arm housing (7). Discard gasket (2) and preformed packing (6).

FOLLOW-ON TASKS:

- For repair of engine retarder (para. 3-50).
- For installation of engine retarder (para. 3-86).

3-21. ENGINE RETARDER REMOVAL (Contd)



LEGEND:

- 1. ROCKER HOUSING STUD (6)
- 2. GASKET
- 3. NUT (6)
- 4. LOCKING PLATE (2)

- 5. ENGINE BRAKE RETARDER (HOUSING ONLY SHOWN)
- 6. PREFORMED PACKING
- 7. ROCKER ARM HOUSING

3-22. ROCKER ARM HOUSING ASSEMBLY AND PUSHRODS REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Gasket (15434) 3017750

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Engine retarder removed (para. 3-21).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dust and dirt.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

NOTE

The following procedure covers removal of one rocker arm housing assembly. Removal of remaining rocker arm housing assemblies is similar.

Removal

1. Six adjusting screw nuts (4) and adjusting screws (5)	Loosen by turning counterclockwise until tension on pushrods (2) and (3) is released.	
2. Six rocker arm housing studs (1) and washer bearings (9)	Remove from cylinder head (8) and rocker arm housing assembly (6).	
3. Rocker arm housing assembly (6)	Remove from cylinder head (8).	Mark each rocker arm housing assembly (6) to identify its location if more than one will be removed.
4. Gasket (7)	Remove from cylinder head (8) or rocker arm housing assembly (6).	Gasket (7) may remain on rocker arm housing assembly (6) or cylinder head assembly (8). Discard gasket (7).

NOTE


Place pushrods in a suitable rack in the order they are removed to ensure proper order for installation and protect them from damage.

5. Two intake pushrods (2), two exhaust pushrods (2), and two injector pushrods (3)	Remove from cylinder head (8).
-------------------------------------------------------------------------------------	--------------------------------

FOLLOW-ON TASKS:

- For repair of pushrods (para. 3-40).
- For repair of rocker levers and housing (para. 3-41).
- For installation of pushrods (para. 3-71).
- For installation of rocker levers and housing (para. 3-84).

3-22. ROCKER ARM HOUSING ASSEMBLY AND PUSHRODS REMOVAL (Contd)



LEGEND:

- | | |
|-----------------------------------|--------------------------------------------------------------|
| 1. ROCKER ARM HOUSING STUD (6) | 6. ROCKER ARM HOUSING ASSEMBLY (ONE CYL. SECTION ONLY SHOWN) |
| 2. INTAKE AND EXHAUST PUSHROD (4) | 7. GASKET |
| 3. INJECTOR PUSHROD (2) | 8. CYLINDER HEAD |
| 4. ADJUSTING SCREW NUT (6) | 9. WASHER BEARING (6) |
| 5. ADJUSTING SCREW (6) | |

3-23. INJECTOR ASSEMBLY REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Injector puller (15434) 3376872

TEST EQUIPMENT

None

MATERIALS/PARTS

None

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Rocker arm housing assembly and pushrods removed (para. 3-22).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dust and dirt.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal

CAUTION

Ensure injectors, injector links, and plungers are not intermixed. Keep all injector parts with individual injectors. After removal, put injectors in suitable rack to ensure proper order of installation and protect them from damage and dirt.


NOTE

The following procedure covers removal of one fuel injector. Removal of remaining fuel injectors is similar.

- | | | | |
|----|-------------------------------------------------------------------------------------------|-------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. | Two screws (5) and retaining plate (2) (M915/Big Cam I) or clamp (2) (M915A1/Big Cam III) | Remove from cylinder head assembly (4) and injector assembly (3). | |
| 2. | Detent plunger (1) | Remove from injector assembly (3). | |
| 3. | Injector assembly (3) | Remove from cylinder head assembly (4). | Use injector puller (3376872) for removal. After removal, place detent plunger (1) in injector assembly (3) and wrap injector assembly (3) in clean cloth. |

- FOLLOW-ON TASKS:
- For repair of fuel injector (para. 3-52).
 - For installation of injector assembly (para. 3-82).

3-23. INJECTOR ASSEMBLY REMOVAL (Contd)



LEGEND:

- | | |
|-------------------------------------------------------------------|------------------------------------------------------------------------------|
| 1. DETENT PLUNGER | 4. CYLINDER HEAD ASSEMBLY |
| 2. RETAINING PLATE (M915/BIG CAM I) OR CLAMP (M915A1/BIG CAM III) | 5. SELF-LOCKING SCREW (2) (M915/BIG CAM I) OR SCREW (2) (M915A1/BIG CAM III) |
| 3. INJECTOR ASSEMBLY | |

3-24. CYLINDER HEAD ASSEMBLY REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Four preformed packings (15434) 131026
Gasket (15434) 3047402

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-9

EQUIPMENT CONDITION

Injector assemblies removed (para. 3-23).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

None

Removal

NOTE

The following procedure covers the removal of one cylinder head assembly. The removal of the remaining cylinder head assemblies is similar.

- | | | | |
|----|---------------------------------------------------------------------------------|----------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. | Four screws (2), fuel crossover connection (1), and four preformed packings (3) | Remove from two cylinder head assemblies (7). | If you are removing the center cylinder head (7), it will be necessary to remove eight screws (2), two fuel crossover connections (1), and eight preformed packings (3). Discard preformed packings (3). |
| 2. | Twelve screws (4) and washers (5) | Remove from cylinder block (8) and cylinder head assembly (7). | Use screw removal sequence (6) as shown in illustration. |


NOTE

If more than one cylinder head assembly will be removed, mark location of each cylinder head assembly on the cylinder block for installation.

- | | | | |
|----|----------------------------|---------------------------------|------------------------------------------------------|
| 3. | Cylinder head assembly (7) | Lift from cylinder block (8). | Assistant will help lift cylinder head assembly (7). |
| 4. | Cylinder head gasket (9) | Remove from cylinder block (8). | Discard gasket (9). |

- FOLLOW-ON TASKS:
- For repair of cylinder head and valves (para. 3-35).
 - For installation of cylinder head assembly (para. 3-71).

3-24. CYLINDER HEAD ASSEMBLY REMOVAL (Contd)



LEGEND:

- 1. FUEL CROSSOVER CONNECTION
- 2. SCREW (4)
- 3. PREFORMED PACKING (4)
- 4. SCREW (12)
- 5. WASHER (12)

- 6. SCREW REMOVAL SEQUENCE
- 7. CYLINDER HEAD ASSEMBLY (2)
- 8. CYLINDER BLOCK
- 9. CYLINDER HEAD GASKET

3-25. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Gasket (15434) 40662-A
 Two lockwashers (96906) MS35338-46
 (M915/Big Cam I)
 Preformed packing (15434) 137075
 (M915/Big Cam I)
 Eleven preformed packings (15434) 172648
 (M915/Big Cam I)
 Seal (01212) M39807
 Four lockwashers (96906) MS35338-45

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Cylinder head assemblies removed (para. 3-24).

SPECIAL ENVIRONMENTAL CONDITION

Work area clean and away from blowing dirt and dust

GENERAL SAFETY INSTRUCTIONS

Use extreme caution during disassembly; engine components are heavy.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal

WARNING


Use extreme caution during disassembly; engine components are heavy. Failure to comply may result in injury to personnel.

NOTE

- M915/Big Cam I engines are equipped with a "wet" flywheel housing which is sealed with a preformed packing (O-ring seal) on crankshaft and eleven preformed packings between flywheel housing and cylinder block.
- Perform steps 1 through 4 for M915/Big Cam I only.
- Perform step 11 for M915A1/Big Cam III only.

1.	Six screws (11) and washers (12)	Remove from crankshaft (22) and flywheel (7).	
2.	Two 5/8-18 x 6 in. studs (23)	Install on two opposite holes on crankshaft (22) until fully seated.	The studs will provide support for flywheel (7) during removal.
3.	Two 1/2-13 x 6 in. screws (24)	Install on flywheel (7) in opposite threaded holes provided until in contact with face of crankshaft (22).	Screws (24) are used as jacking screws.
4.	Flywheel (7)	Remove from crankshaft (22) by alternately turning two 1/2-13 x 6 in. screws (24).	Have assistant hold on to flywheel during removal. Remove 5/8-18 x 6 in. studs (23) from crankshaft (22), and remove 1/2-13 x 6 in. screws (24) from flywheel (7).

3-25. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER REMOVAL (Contd)



LEGEND:

- | | | |
|-----------------------------------------------|----------------|--------------------|
| 1. CYLINDER BLOCK | 9. WASHER (12) | 17. SCREW (2) |
| 2. SCREW (2) | 10. SCREW (12) | 18. WASHER (4) |
| 3. GASKET | 11. SCREW (6) | 19. LOCKWASHER (2) |
| 4. ACCESS COVER | 12. WASHER (6) | 20. NUT (2) |
| 5. PREFORMED PACKING (11)
(M915/BIG CAM I) | 13. SCREW (9) | 21. DOWEL PIN (2) |
| 6. FLYWHEEL HOUSING | 14. WASHER (9) | 22. CRANKSHAFT |
| 7. FLYWHEEL | 15. SCREW (4) | 23. STUD (2) |
| 8. SPACER GEAR | 16. WASHER (4) | 24. SCREW (2) |

3-25. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER REMOVAL (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal (Contd)

5. Four screws (15), washers (16), two nuts (20), lockwashers (19), screws (17), and washers (18)	Remove from flywheel housing (6) and oil pan (25).	Discard lockwashers (19).
6. Nine screws (13) and washers (14)	Remove from cylinder block (1) and flywheel housing (6).	
7. Flywheel housing (6)	Remove from dowel pins (21) and cylinder block (1).	Support flywheel housing (6) during removal from dowel pins (21). Free flywheel housing (6) by driving off of dowel pins (21) with soft-nose hammer.
8. Two dowel pins (21) and eleven preformed packings (5)	Remove from flywheel housing (6).	Discard preformed packings (5).


NOTE

Perform step 9 if flywheel-to-clutch housing ring gear is to be removed for M915/Big Cam I only.

9. Twelve screws (10), washers (9), and spacer gear (8)	Remove from flywheel (7).	
10. Two screws (2), gasket (3), and access cover (4)	Remove from flywheel housing (6).	Access cover (4) may have been removed during engine removal. Discard gasket (3).

3-25. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER REMOVAL (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------



M915/BIG CAM I

LEGEND:

- | | | |
|---------------------------|----------------|--------------------|
| 1. CYLINDER BLOCK | 8. SPACER GEAR | 17. SCREW (2) |
| 2. SCREW (2) | 9. WASHER (12) | 18. WASHER (4) |
| 3. GASKET | 10. SCREW (12) | 19. LOCKWASHER (2) |
| 4. ACCESS COVER | 13. SCREW (9) | 20. NUT (2) |
| 5. PREFORMED PACKING (11) | 14. WASHER (9) | 21. DOWEL PIN (2) |
| 6. FLYWHEEL HOUSING | 15. SCREW (4) | 25. OIL PAN |
| 7. FLYWHEEL | 16. WASHER (4) | |

3-25. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER REMOVAL (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal (Contd)

NOTE
Perform step 11 for M915A1/Big Cam III only.


11. Six screws (33), washers (13), washer bearing (32), flexplate (31), and retaining plate (30)	Remove from crankshaft (22).	Lock flexplate (31) to prevent crankshaft (22) from rotating when removing screws (33).
--------------------------------------------------------------------------------------------------	------------------------------	-----------------------------------------------------------------------------------------

NOTE
Perform step 12 for M915/Big Cam I only.

12. Preformed packing (34)	Remove from crankshaft (22).	Discard preformed packing (34).
13. Four screws (38), lock-washers (37), and washers (36)	Remove from oil pan (25) and rear cover (27).	On steel oil pans (M915A1/Big Cam III), two of the four screws (38) have been eliminated.
14. Eight screws (28), rear cover (27), and gasket (26)	Remove from cylinder block (1) and crankshaft (22).	Discard gasket (26).
15. Rear main seal (35)	Remove from rear cover (27).	Discard seal (35).

- FOLLOW-ON TASKS:**
- For repair of flexplate or flywheel, flywheel housing, and rear cover (para. 3-38).
 - For installation of flexplate or flywheel, flywheel housing, and rear cover (para. 3-80).

3-25. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER REMOVAL (Contd)



LEGEND:

- 1. CYLINDER BLOCK
- 13. WASHER (6)
- 14. SCREW (9)
- 22. CRANKSHAFT
- 25. OIL PAN
- 26. GASKET
- 27. REAR COVER (M915/BIG CAM II), COVER (M915A1/BIG CAM III)
- 28. SCREW (8)

- 29. FLYWHEEL HOUSING
- 30. RETAINING PLATE
- 31. FLEXPLATE
- 32. WASHER BEARING
- 33. SCREW (6)
- 34. PREFORMED PACKING (M915 ONLY)
- 35. REAR MAIN SEAL
- 36. WASHER (4)
- 37. LOCKWASHER (4)
- 38. SCREW (4)

3-26. OIL PAN REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Gasket (15434) 3032861
Four lockwashers (96906) MS35338-45

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

LO 9-2320-273-12
LO 9-2320-283-12

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Engine oil drained (LO 9-2320-273-12 or LO 9-2320-283-12).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal

NOTE

- Removal of oil pan is basically the same for M915/Big Cam I and M915A1/Big Cam III. Big Cam I engines are equipped with a cast aluminum oil pan. Big Cam III engines are equipped with a stamped steel oil pan.
- Perform step 1 for M915A1/Big Cam III only.
- Perform step 2 for M915/Big Cam I only.

- | | | |
|----|-------------------------------------------------------------------|-------------------------------------------------|
| 1. | Four screw-assembled washers (10) and engine shipping support (9) | Remove from cylinder block (2) and oil pan (4). |
| 2. | Four screws (11) | Remove from cylinder block (2) and oil pan (1). |


NOTE

Two of the four screws may have been eliminated on newer M915A1/Big Cam III oil pans.

- | | | | |
|----|-----------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| 3. | Four screws (7), lockwashers (6), and washers (5) | Remove from oil pan (4) (M915A1/Big Cam III) or oil pan (1) (M915/Big Cam I). | Screws (7) may have already been removed if rear cover was removed. Discard lockwashers (6). |
| 4. | Twenty-eight screws (8), oil pan (4) (M915A1/Big Cam III) or oil pan (1) (M915/Big Cam I), and gasket (3) | Remove from cylinder block (2). | Assistant will hold oil pan (4) or (1) during removal of last screw (8). Discard gasket (3). |

- FOLLOW-ON TASKS:**
- For repair of oil pan (para. 3-43).
 - For installation of oil pan (para. 3-81).

3-26. OIL PAN REMOVAL (Contd)



**M915/BIG CAM I OIL PAN
(CAST ALUMINUM)**

**M915A1/BIG CAM III OIL PAN
(STAMPED STEEL)**

LEGEND:

- 1. OIL PAN (M915/BIG CAM I)
- 2. CYLINDER BLOCK
- 3. GASKET
- 4. OIL PAN (M915A1/BIG CAM III)
- 5. WASHER (4)
- 6. LOCKWASHER (4)

- 7. SCREW (4)
- 8. SCREW (28)
- 9. ENGINE SHIPPING SUPPORT
- 10. SCREW-ASSEMBLED WASHER (4) (M915A1/BIG CAM III)
- 11. SCREW (4) (M915/BIG CAM I)

3-27. FRONT GEAR COVER REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Gasket (15434) 3021704
 Preformed packing (15434) 215705
 Lockwasher (96906) MS35338-47
 (M915/Big Cam I)
 Three lockwashers (15434) S604
 (M915/Big Cam I)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

- Oil pan removed (para. 3-26).
- Vibration damper and crankshaft pulley removed (para. 3-14).
- Accessory drive pulley removed (para. 3-15).
- Accessory drive housing removed (para. 3-18).
- Oil pump removed (para. 3-19).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal

- | | | | |
|----|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------|------------------------------------------------------------------|
| 1. | Six screws (1), washers (2), two screws (16) (M915/Big Cam I) or two captive washer screws (16) (M915A1/Big Cam III only), two washers (17) (M915/Big Cam I only), and front engine support (3) | Remove from cylinder block (13) and gear cover (11). | Hold front engine support (3) during removal of last screw (16). |
|----|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------|------------------------------------------------------------------|

NOTE

- Perform step 2 for M915/Big Cam I only.
- Perform step 3 for M915A1/Big Cam III only.


- | | | | |
|----|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|
| 2. | Three screws (4), lockwashers (18), washers (19), camshaft support (5), shim pack (6) and preformed packing (7) | Remove from gear cover (11). | Use a soft-nose hammer and gently tap camshaft support (5) loose, if necessary. Discard lockwashers (18) and packing (7). |
| 3. | Three captive washer screws (4), camshaft support (5), shim pack (6), and preformed packing (7) | Remove from gear cover (11). | Use a soft-nose hammer and gently tap camshaft support (5) to loosen, if necessary. Discard packing (7). |
| 4. | Two screws (8) (M915/Big Cam I only) or two captive washer screws (8) (M915A1/Big Cam III only), lockwasher (9) and washer (10) (M915/Big Cam I only), nine captive washer screws (15), and captive washer screw (14) | Remove from cylinder block (13) and gear cover (11). | Discard lockwasher (9). |

3-27. FRONT GEAR COVER REMOVAL (Contd)

Removal (Contd)

- | | | |
|--------------------------------------------------------------|-----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5. Front gear cover (11) and gasket (12) | Remove front cylinder block (13). | Install one 4-in. stud on each side of gear cover (11) for support during removal. Use a soft-nose hammer to loosen gear cover (11). Discard gasket (12). |
| 6. Camshaft support (5), shim pack (6), and three screws (4) | Install on front gear cover (11). | This step is recommended to prevent damage or loss of shim pack (6). Do not tighten screws (4). |

- FOLLOW-ON TASKS:
- For repair of front gear cover (para. 3-48).
 - For installation of front gear cover (para. 3-75).



LEGEND:

- | | |
|---------------------------------------------------------------------------------|----------------------------------------------------------------------------------|
| 1. SCREW (6) | 11. GEAR COVER |
| 2. WASHER (6) | 12. GASKET |
| 3. FRONT ENGINE SUPPORT | 13. CYLINDER BLOCK |
| 4. SCREW (3) (M915/BIG CAM I),
CAPTIVE WASHER SCREW (3) (M915A1/BIG CAM III) | 14. CAPTIVE WASHER SCREW |
| 5. CAMSHAFT SUPPORT | 15. CAPTIVE WASHER SCREW (9) |
| 6. SHIM PACK | 16. SCREW (2) (M915/BIG CAM I),
CAPTIVE WASHER SCREW (2) (M915A1/BIG CAM III) |
| 7. PREFORMED PACKING | 17. WASHER (2) (M915/BIG CAM I) |
| 8. SCREW (2) (M915/BIG CAM I),
CAPTIVE WASHER SCREW (2) (M915A1/BIG CAM III) | 18. LOCKWASHER (3) (M915/BIG CAM I) |
| 9. LOCKWASHER (M915/BIG CAM I) | 19. WASHER (3) (M915/BIG CAM I) |
| 10. WASHER (M915/BIG CAM I) | |

3-28. CAM FOLLOWER ASSEMBLIES AND CAMSHAFT REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Gasket (as required) (15434) 3011878
(M915/Big Cam I)
Six lockwashers (15434) S604 (M915/Big Cam I)
Gasket (15434) 3020000 (M915A1/Big Cam III)
Gasket (as required) (15434) 3020001,
3020002, 3020003, 3020004 (M915A1/Big
Cam III)

REFERENCES (TM)

Automotive repairman MOS 63H

REFERENCE (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Front gear cover removed (para. 3-27).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFE INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal

NOTE

- Perform steps 1 and 2 to remove any one of the three cam follower assemblies. Mark each cam follower assembly during removal so it can be installed in its original position on cylinder block.
- All three cam follower assemblies must be removed from cylinder block before camshaft can be removed. Repeat steps 1 and 2 to remove each remaining cam follower assembly.

1. Six screws (5)	Remove from cam follower assembly (4) and cylinder block (2). Remove six lockwashers (6) (M915/Big Cam I).	Discard lockwashers (6) (M915/Big Cam I).
-------------------	------------------------------------------------------------------------------------------------------------	-------------------------------------------

NOTE

Measuring thickness of gasket or gaskets for each cam follower assembly is required for correct timing of injectors due to individual differences between castings.

2. Cam follower assembly (4) and gasket (3)	a. Carefully pry from dowels on cylinder block (2). b. Measure gasket (3) at points A, B, and C as shown. Record the average thickness of gasket or gaskets for each cam follower assembly (4).	Use a suitable micrometer to measure gaskets (3). Discard gasket(s) (3) after taking measurement. Refer to Appendix B, Figure 7 for additional gasket sizes available.
---------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-28. CAM FOLLOWER ASSEMBLIES AND CAMSHAFT REMOVAL (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

CAUTION


To avoid damaging camshaft bushings, use extreme caution when removing camshaft.

NOTE

Four camshaft pilot tools (3375268) may be used if available.

3. Camshaft (1)	Remove from cylinder block (2) by slowly turning gear on camshaft (1) and lightly pulling at same time.	Have assistant help during removal. Remove camshaft pilot tools from camshaft (1) if utilized.
-----------------	---------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------

- FOLLOW-ON TASKS:
- For repair of camshaft and cam follower assemblies (para. 3-40).
 - For installation of camshaft and cam follower assemblies (para. 3-70).



LEGEND:

- | | |
|-------------------|------------------------------------|
| 1. CAMSHAFT | 4. CAM FOLLOWER ASSEMBLY |
| 2. CYLINDER BLOCK | 5. SCREW (6) |
| 3. GASKET | 6. LOCKWASHER (6) (M915/BIG CAM I) |

3-29. PISTON, CONNECTING ROD, AND BEARINGS REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Two nylon guide screws (15434) 3375601
Piston ring expander (15434) ST-763

TEST EQUIPMENT

None

MATERIALS/PARTS

Cloth, crocus (Appendix C, Item 4)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Camshaft and cam followers removed (para. 3-28).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

Eye protection must be worn when using wire brush for cleaning.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal

WARNING


Eye protection must be worn when using wire brush for cleaning. Failure to do so may result in injury to personnel.

NOTE

This task covers removal of one piston, connecting rod, and bearing assembly. Removal of the remaining five assemblies is the same. Parts are not interchangeable and must be identified with each assembly as it is removed.

1. Cylinder block (11)	a. Place in vertical position with rear of block down. b. Using a rotary wire brush or aluminum bladed scraper, clean all carbon deposits from upper inside wall of cylinder liner (9).	This step is performed so rings will not snap or chip when piston and connecting rod assembly is removed. Use lint-free cloth to remove loose debris from cylinder liner (9).
2. Crankshaft (10)	Rotate until connecting rod cap (7) is accessible.	
3. Two rod screws (8)	a. Loosen until there is approximately 3/8 in. (9.5 mm) between head of screws (8) and connecting rod cap (7). b. Using soft-nose hammer, tap on heads of screws (8) until connecting rod cap (7) and piston and connecting rod assembly (5) are separated. c. Remove from piston and connecting rod assembly (5) and connecting rod cap (7).	

3-29. PISTON, CONNECTING ROD, AND BEARINGS REMOVAL (Contd)



LEGEND:

- | | |
|---------------------------------------|-----------------------|
| 1. COMPRESSION RING | 7. CONNECTING ROD CAP |
| 2. PISTON RING (COMPRESSION RING) | 8. ROD SCREW (2) |
| 3. COMPRESSION RING | 9. CYLINDER LINER |
| 4. PISTON RING (OIL CONTROL RING) | 10. CRANKSHAFT |
| 5. PISTON AND CONNECTING ROD ASSEMBLY | 11. CYLINDER BLOCK |
| 6. ROD BEARING HALF (2) | |

3-29. PISTON, CONNECTING ROD, AND BEARINGS REMOVAL (Contd)


LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal (Contd)

4. Connecting rod cap (7) and lower rod bearing half (6)	Remove from piston and connecting rod assembly (5) and crankshaft (10).	Ensure connecting rod and cap are identified together by cylinder number. Mark cylinder number and letter L on flat surface of bearing half (6).
5. Two nylon guide screws (12)	Install on piston and connecting rod assembly (5).	Use nylon guide screws (3375601) to prevent damage to cylinder liner (9).
6. Piston and connecting rod assembly (5)	Push out of cylinder liner (9) while holding assembly so it will not be dropped or damaged.	Mark cylinder number on top of piston at camshaft side of cylinder.
7. Two nylon guide screws (12)	Remove from piston and connecting rod assembly (5).	Mark cylinder number and letter U on flat surface of tang on rod bearing (6).
8. Upper rod bearing half (6)	Remove from piston and connecting rod assembly (5).	
9. Compression ring (1), piston ring (2), compression ring (3), and piston ring (4)	Remove from piston and connecting rod assembly (5).	Use piston ring expander (ST-763) (13). Discard rings (1), (2), (3), and (4).
10. Cylinder block (11)	Place in horizontal position.	

- FOLLOW-ON TASKS:
- For repair of piston, connecting rod, and bearings (para. 3-69).
 - For installation of piston, connecting rod, and bearings (para. 3-39).

3-29. PISTON, CONNECTING ROD, AND BEARINGS REMOVAL (Contd)



LEGEND:

- 1. COMPRESSION RING
- 2. PISTON RING (COMPRESSION RING)
- 3. COMPRESSION RING
- 4. PISTON RING (OIL CONTROL RING)
- 5. PISTON AND CONNECTING ROD ASSEMBLY
- 6. ROD BEARING HALF (2)
- 7. CONNECTING ROD CAP

- 8. ROD SCREW (2)
- 9. CYLINDER LINER
- 10. CRANKSHAFT
- 11. CYLINDER BLOCK
- 12. NYLON GUIDE SCREW (2)
- 13. PISTON RING EXPANDER

3-30. CYLINDER LINER REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

REFERENCES (TM)

None

SPECIAL TOOLS

Universal cylinder liner puller (15434) 3376015

TROUBLESHOOTING REFERENCES

Para. 2-8.

TEST EQUIPMENT

None

EQUIPMENT CONDITION

Piston, connecting rod, and bearings removed (para. 3-29).

MATERIALS/PARTS

Gasket (15434) 215090
 Preformed packing (black) (15434) 3008998
 Preformed packing (red) (15434) 183049

SPECIAL ENVIRONMENTAL CONDITION

Work area clean and away from blowing dirt and dust.

PERSONNEL REQUIRED

Automotive repairman MOS 63H

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal

CAUTION

If shims are used under the cylinder liner, do not discard the shims. The shims will be reused during assembly. If more than one cylinder liner is to be removed, identify and tag the location of each cylinder liner and shim (if used).


NOTE

The following procedure covers the removal of one cylinder liner. The removal of the remaining cylinder liners is the same.

1. Cylinder liner (1)	Remove from cylinder block (6)	Use universal cylinder liner puller (7), and impact wrench. Cylinder liner shim (2), gasket (crevice seal) (3), black packing ring (4), and red packing ring (5) will remain on cylinder liner (1) during removal.
2. Cylinder liner shim (2), gasket (crevice seal) (3), black packing ring (4), and red packing ring (5)	a. Remove from cylinder liner (1). b. Measure and record thickness of cylinder liner shim (2).	Discard gasket (crevice seal) (3), black packing ring (4), and red packing ring (5).

- FOLLOW-ON TASKS:**
- For repair of cylinder liner (para. 3-34).
 - For installation of cylinder liner (para. 3-67).

3-30. CYLINDER LINER REMOVAL (Contd)



LEGEND:

- | | |
|--------------------------------------|------------------------------------|
| 1. CYLINDER LINER | 5. RED PACKING RING |
| 2. CYLINDER LINER SHIM (IF REQUIRED) | 6. CYLINDER BLOCK |
| 3. GASKET (CREVICE SEAL) | 7. UNIVERSAL CYLINDER LINER PULLER |
| 4. BLACK PACKING RING | |

3-31. ENGINE CRANKSHAFT AND MAIN BEARINGS REMOVAL

THIS TASK COVERS:

Removal

INITIAL SETUP:

APPLICABLE MODELS

All

REFERENCES (TM)

None

SPECIAL TOOLS

Main bearing cap puller (15434) ST-1178

TROUBLESHOOTING REFERENCES

Para. 2-8

TEST EQUIPMENT

None

EQUIPMENT CONDITION

Piston connecting rods and connecting rod bearings removed (para. 3-29).

MATERIALS/PARTS

Fourteen lockplates (15434) 140218

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

PERSONNEL REQUIRED

Automotive repairman MOS 63H

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal

CAUTION

Cylinder block and main bearing caps are line bored. Before removing bearing caps, ensure all bearing caps are marked so they can be matched with their original position and location on cylinder block during installation. Installing the wrong cap in wrong position or location will damage engine.


- | | | |
|----|----------------------------------------|------------------------------------------------------|
| 1. | Cylinder block (7) | Place in upside down position. |
| 2. | Fourteen lockplates (1) | Bend edges down where necessary. |
| 3. | Fourteen screws (8) and lockplates (1) | Remove from bearing caps (2) and cylinder block (7). |

NOTE

When removing a bearing cap, hold onto the main bearing so it does not drop out of the bearing cap. Identify main bearing location with bearing cap.

- | | | | |
|----|-------------------------------|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 4. | Seven bearing caps (2) | Remove from cylinder block (7). | Use main bearing cap puller (3), (ST-1178). |
| 5. | Seven retaining rings (6) | Remove from cylinder block (7). | |
| 6. | Seven main bearing halves (4) | Remove from bearing caps (2). | Identify each for proper location. |
| 7. | Engine crankshaft (5) | Remove from cylinder block (7). | Use a hoist and hooks protected with a rubber hose or a lifting strap to remove engine crankshaft (5). Be careful not to damage surface of engine crankshaft (5). |

3-31. ENGINE CRANKSHAFT AND MAIN BEARINGS REMOVAL (Contd)



LEGEND:

- | | |
|----------------------------|------------------------------|
| 1. LOCKPLATE (14) | 6. RETAINING RING (7) |
| 2. BEARING CAP (7) | 7. CYLINDER BLOCK |
| 3. MAIN BEARING CAP PULLER | 8. SCREW (14) |
| 4. MAIN BEARING HALF (4) | 9. THRUST BEARING WASHER (4) |
| 5. ENGINE CRANKSHAFT | |

3-31. ENGINE CRANKSHAFT AND MAIN BEARINGS REMOVAL (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Removal (Contd)

NOTE

During thrust bearing washer removal, tag each thrust bearing washer to identify location.

- | | |
|------------------------------------|--------------------------------------------------------------------------|
| 8. Four thrust bearing washers (9) | Remove from engine crankshaft (5) and number seven main bearing cap (2). |
|------------------------------------|--------------------------------------------------------------------------|

NOTE

Tape the mating bearing halves together and label each pair and location for later reference.

- | | | |
|----------------------------------|---------------------------------|---------------------------------------------------------------|
| 9. Seven main bearing halves (4) | Remove from cylinder block (7). | Identify each with the previously removed bearing halves (4). |
|----------------------------------|---------------------------------|---------------------------------------------------------------|


NOTE

Prior to removing cylinder block from maintenance stand for cleaning, inspection, and repair, remove all cylinder block plugs and camshaft bushings.

- | | | |
|------------------------------------------------------|-------------------------------------|------------------------------------------|
| 10. Four mounting screws (10) and cylinder block (7) | Remove from maintenance stand (11). | Use a suitable chain and lifting device. |
|------------------------------------------------------|-------------------------------------|------------------------------------------|

- FOLLOW-ON TASKS:**
- For repair of crankshaft (para. 3-37).
 - For installation of engine crankshaft and main bearings (para. 3-68).

3-31. ENGINE CRANKSHAFT AND MAIN BEARINGS REMOVAL (Contd)



LEGEND:

- | | |
|----------------------------|------------------------------|
| 1. LOCKPLATE (14) | 7. CYLINDER BLOCK |
| 2. BEARING CAP (7) | 8. SCREW (14) |
| 3. MAIN BEARING CAP PULLER | 9. THRUST BEARING WASHER (4) |
| 4. MAIN BEARING HALF (4) | 10. MOUNTING SCREWS (4) |
| 5. ENGINE CRANKSHAFT | 11. MAINTENANCE STAND |
| 6. RETAINING RING (7) | |

Section III. REPAIR

3-32. GENERAL

a. This section provides repair for the engine and all major components and subassemblies. The procedures are for the engine removed from the vehicle.

b. In cases where it may be necessary or more time-efficient to repair the engine while installed in vehicle, follow applicable portions of tasks contained in this section to remove part or component.

c. In task summary listed below, a complete list of special tools, test equipment, materials, parts, and related information required to perform engine repair is provided. To find a specific engine repair procedure contained in this section, see list of tasks below.

3-33. TASK SUMMARY**INITIAL SETUP:****APPLICABLE MODELS**

All

SPECIAL TOOLS

Camshaft bushing driver kit (15434) 3376633

Liner driver (15434) ST-1229

Cylinder liner clamp (15434) ST-1184

Gauge block (15434) 3376220

Cylinder block

Counterbore tool (15434) 3375455

Camshaft bushing driver (15434) 3376637

Head holding fixture (15434) ST-583

Valve spring compressor (15434) ST-448

Fuel passage cleaning brush (15434) ST-876

Valve seat extractor (15434) S1-P27

Valve seat insert tool (15434) ST-257

Valve seat insert cutter (15434) ST-662

Valve guide arbor (15434) ST-663

Valve seat insert staking tool pilot (15434)
ST-1124Valve seat insert staking tool driver (15434)
ST-1122

Dowel pin extractor (15434) ST-1134

Crosshead guide spacer (15434) ST-633

Valve guide driver (15434) 3375252

Injector sleeve puller (15434) ST-1244

Bead cutting tool (15434) ST-788

Injector seat cutting tool (15434) ST-824

Injector sleeve driver (15434) ST-1227

Injector sleeve holding tool (15434) ST-1179

Injector sleeve expander (15434) ST-880

Injector seat cutter (15434) ST-884

Valve spring tester (15434) 3375182

Expansion plug drivers (3/4-in.) (15434)
3375190

Expansion plug driver (1-in.) (15434) 3375191

Expansion plug driver (1-1/4 in.) (15434)
3375192

Valve vacuum tester (15434) ST-1257-A

Connecting rod bushing driver (15434) ST-1242

Connecting rod checking fixture (15434) ST-
561

Connecting rod locating mandrel (15434) ST-563

Piston ring groove gauge (15434) ST-560

Rocker lever block and mandrel set (15434) ST-691

Spacer mandrel (15434) ST-1157

Air Fuel Control (AFC) pressure valve fixture
(15434) 3376011

Puller (15434) 3376663

Solenoid valve wrench (75018) 011494

Air compressor mounting plate (15434) ST-749

Ball joint vise (15434) ST-302

Coupling half puller (15434) 3376663

Air compressor bushing mandrel (15434) ST-1105

Injector stand (15434) ST-1298

Injector cup wrench (15434) ST-995

Crowfoot wrench (15434) ST-107

Injector adapter pot (15434) 3375086

Plug (15434) ST-669-14

Plunger extension (15434) ST-1089

Plunger bore plug assembly (15434) ST-668-5012

Test stand link (15434) ST-790-362

Master injector (15434) ST-1262

Conversion kit (15434) ST-1261

Top stop injector setting fixture (15434) 3375160

Fuel pump mounting plate (15434) 3375133

Pressurizing valve driver (15434) 3375959

Front cover and main shaft assembly tool kit
(15434) 3375175

Oil seal assembly tool (15434) ST-419

Plunger protrusion checking tool (15434) ST-1241

AFC barrel puller (15434) 3375599

Ream fixture (15434) ST-490

Lock-cup driver (15434) 3376136

Fuel pump idle adjusting tool (15434) 3375981

AFC fuel pump adjusting tool kit (15434) 3375189

Throttle lever travel template (15434) 3375855

Bearing disassembly fixture (15434) ST-1114

Seal wear sleeve mandrel (15434) ST-1159

Water pump bearing mandrel (15434) ST-658

Oil seal driver (15434) ST-1191

Puller (15434) 3375257

Oil seal pilot (15434) 3375180

Water pump seal mandrel (15434) 3376091

3-33. TASK SUMMARY (Contd)**INITIAL SETUP (Cont):****TEST EQUIPMENT**

Crack detection kit (15434) 3375432
 Injector leakage tester (15434) ST-990
 Injector test stand (15434) ST-790 or (05083)
 CD-3 (Refer to TM 9-4910-777-14&P)
 Spray test fixture (15434) ST-668
 Fuel injection tester 4910-00-817-7431

MATERIALS/PARTS

Solvent, SD-3 or suitable substitute
 (Appendix C, Item 30)
 Oil, lubricating, OE/HDO 10
 (Appendix C, Item 20)
 Cloth, emery, 290-grit (Appendix C, Item 5)
 Sealant, pipe (Appendix C, Item 26)
 Sealant, cup plug (Appendix C, Item 25)
 Oil, lubricating, OE/HDO 30
 (Appendix C, Item 21)
 Cloth, crocus (Appendix C, Item 4)
 Oil, cutting (Appendix C, Item 18)
 Compound, Prussian blue (Appendix C, Item 9)
 Compound, Prussian blue (Appendix C, Item 2)
 Sealant, thread (liquid) (Appendix C, Item 27)
 Developer, spot-check, SKD-NF
 (Appendix C, Item 10)
 Paper, aluminum oxide, 240-grit
 (Appendix C, Item 23)
 Acid, muriatic (Appendix C, Item 1)
 Acid, oxalic (Appendix C, Item 2)
 Pyridene (Appendix C, Item 24)
 Sodium carbonate (5 percent solution)
 (Appendix C, Item 28)
 Compound, antiseize (Appendix C, Item 7)
 Compound, lapping, 280-grit
 (Appendix C, Item 8)
 Mineral spirits (Appendix C, Item 17)
 Cloth, lint-free (Appendix C, Item 6)
 Lubricant, high-pressure (Appendix C, Item 15)
 Fluid, automatic transmission, type-A
 (Appendix C, Item 11)
 Oil, fuel: diesel, regular (Appendix C, Item 19)
 Fluid, calibration (Appendix C, Item 12)
 Loctite (Appendix C, Item 14)
 Six crevice seals (15434) 215090
 Six black packing rings (15434) 3008998
 Six red packing rings (15434) 183049
 Six O-rings (15434) 3007442
 Two water header cover gaskets (15434)
 D0089-1
 Cup plug (15434) 3011952
 Forty-eight valve collets (15434) 127554
 Four O-ring seals (15434) 131026
 3/4-in. expansion plug (15434) 213394
 1-in. expansion plug (15434) 213395
 Two 1-1/4 in. expansion plugs (15434) 216524
 Injector assembly (15434) 3030445

Injector clamp (15434) 3028171
 Two injector clamp screws (15434) 3028279
 Injector O-ring seal (15434) 3007759
 Rear main seal (15434) 211253
 Rear cover gasket (15434) 40662-A
 Six expansion plugs (15434) 213395
 Two O-ring seals (15434) 3000521
 Two expansion plugs (15434) 218736
 Special expansion plug (15434) 61825
 Gasket and seal kit (15434) 3801235
 Oil pan gasket (15434) 3027983
 O-ring seal (15434) 3029846
 Cover gasket (15434) 3013778
 Four O-rings (15434) 195952
 Aftercooler cover gasket (15434) 216486
 (M915A1/Big Cam III only)
 Water outlet connection gasket (15434) 215044
 Water inlet connection gasket (15434) 3032348
 Bearing insert (15434) 170510
 Two screws (15434) 194010
 Four plain washers (15434) 5-631
 Two clamp nuts (15434) 167299
 Insulation packing (15434) 1672990277
 Ring seal (15434) 154644
 Two turbocharger seals (15434) 032836
 O-ring (15434) 202456
 Impeller nut (15434) 3-222A
 Packing (15434) 215705
 Accessory gear cover bushing (15434) 32770
 Upper seal ring (15434) 001081
 Center seal ring (15434) 001082
 Lower seal ring (15434) 001083
 Unloader valve O-ring (15434) 128086
 Unloader cap seal (15434) 127936
 Intake valve O-ring (15434) 211315
 Exhaust valve O-ring (15434) 28085
 Four lockwashers (15434) 5-605
 Cover gasket (15434) 154996
 Head gasket (15434) 54018
 Piston ring kit (15434) AR-73350
 Support gasket (15434) 76027
 Four lockwashers (15434) 5-610
 Rectangular ring seal (15434) 129888
 Rectangular ring seal (15434) 154087
 O-ring seal (15434) 90876
 Four lockwashers (15434) 181466
 Rectangular ring seal (15434) 139988
 Rectangular ring seal (15434) 100099
 Rectangular ring seal (15434) 151900
 Rectangular ring seal (15434) 255622
 Four lockwashers (15434) 181466
 Gasket (15434) 110855
 Gasket (15434) 3016683
 Cover to fuel pump gasket (15434) 100764

3-33. TASK SUMMARY (Contd)

INITIAL SETUP (Contd):

MATERIALS/PARTS (Contd)

- Tachometer drive seal (15434) 212603
- Shaft seal (15434) 019962
- Two O-rings (15434) 68061-A
- O-ring (15434) 100478
- Gasket washer (15434) 3023870
- Bellows (15434) 3013811
- O-ring (15434) 45505
- O-ring (15434) 45504
- O-ring (15434) 70775
- O-ring (15434) 154088
- O-ring (15434) 213768
- Oil seal (15434) 203100
- Seat and seal assembly (15434) 3028294
- Oil seal (15434) 203101
- O-ring (15434) 145506

PERSONNEL REQUIRED

- Automotive repairman MOS 63H
- Fuel and electrical system repairman MOS 63G

REFERENCES (TM)

- TM 9-2320-283-20
- TM 9-2320-273-20

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

- Refer to specific paragraph for this information.
- Refer to TM 9-4910-777-14&P.
- Refer to TM 9-4910-778-14&P.

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dust and dirt.

GENERAL SAFETY INSTRUCTIONS

- Always wear eye protection when using compressed air.
- Eye protection required when removing control valve outer and inner springs. Eye protection required when removing slave piston retainer and spring.
- Diesel fuel is highly flammable. Do not perform fuel pump testing and calibration procedures near fire, flames, or sparks.
- Use toxic chemicals in well-ventilated area only. Always wear safety shield, gloves, etc.

List of Tasks

TASK PARA.	PROCEDURES	TASK REF.	TROUBLESHOOTING REF. NO. (PARA.)
1.	Engine Block Repair a. Disassembly b. Cleaning c. Inspection and Repair d. Assembly	3-34 3-34a 3-34b 3-34c 3-34d	2-8
2.	Cylinder Head and Valve Repair a. Disassembly b. Cleaning c. Inspection and Repair d. Assembly and Testing	3-35 3-35a 3-35b 3-35c 3-35d	2-8
3.	Vibration Damper and Crankshaft Pulley Repair a. Cleaning b. Inspection	3-36 3-36a 3-36b	2-8
4.	Crankshaft Repair a. Cleaning b. Inspection	3-37 3-37a 3-37b	2-8

3-33. TASK SUMMARY (Contd)

List of Tasks (Contd)

TASK PARA.	PROCEDURES	TASK REF.	TROUBLESHOOTING REF. NO. (PARA.)
5.	Flexplate or Flywheel, Flywheel Housing, and Rear Cover Repair a. Cleaning b. Inspection	3-38 3-38a 3-38b	2-8
6.	Piston, Connecting Rod, and Bearing Repair a. Disassembly b. Cleaning c. Inspection d. Assembly	3-39 3-39a 3-39b 3-39c 3-39d	2-8
7.	Camshaft, Cam Follower, and Pushrod Repair a. Disassembly b. Cleaning c. Inspection d. Assembly	3-40 3-40a 3-40b 3-40c 3-40d	2-8
8.	Rocker Levers and Housing Repair a. Disassembly b. Cleaning c. Inspection d. Assembly	3-41 3-41a 3-41b 3-41c 3-41d	2-8
9.	Oil Cooler Repair a. Disassembly b. Cleaning c. Inspection d. Assembly	3-42 3-42a 3-42b 3-42c 3-42d	2-8
10.	Oil Pan, Dipstick, Oil Suction Tubes, and Breather Tube Repair a. Disassembly b. Cleaning c. Inspection d. Assembly	3-43 3-43a 3-43b 3-43c 3-43d	2-8
11.	Oil Pump Repair a. Disassembly b. Cleaning c. Inspection d. Assembly	3-44 3-44a 3-44b 3-44c 3-44d	2-8

3-33. TASK SUMMARY (Contd)

List of Tasks (Contd)

TASK PARA.	PROCEDURES	TASK REF.	TROUBLESHOOTING REF. NO. (PARA.)
12.	Air Aftercooler Repair a. Disassembly b. Cleaning c. Inspection d. Assembly	3-45 3-45a 3-45b 3-45c 3-45d	2-8
13.	Exhaust Manifold Repair a. Disassembly b. Cleaning c. Inspection d. Assembly	3-46 3-46a 3-46b 3-46c 3-46d	2-8
14.	Turbocharger Repair a. Disassembly b. Cleaning and Inspection c. Assembly	3-47 3-47a 3-47b 3-47c	2-8
15.	Front Gear Cover Repair a. Disassembly b. Cleaning c. Inspection d. Assembly	3-48 3-48a 3-48b 3-48c 3-48d	2-8
16.	Accessory Drive Repair a. Disassembly b. Cleaning c. Inspection d. Assembly	3-49 3-49a 3-49b 3-49c 3-49d	2-8
17.	Engine Retarder Repair a. Disassembly b. Testing c. Assembly	3-50 3-50a 3-50b 3-50c	2-8
18.	Air Compressor Repair a. Disassembly b. Cleaning c. Inspection and Repair d. Assembly	3-51 3-51a 3-51b 3-51c 3-51d	2-8
19.	Fuel Injector Repair a. Disassembly b. Cleaning c. Inspection d. Assembly	3-52 3-52a 3-52b 3-52c 3-52d	2-8

3-33. TASK SUMMARY (Contd)

List of Tasks (Contd)

TASK PARA.	PROCEDURES	TASK REF.	TROUBLESHOOTING REF. NO. (PARA.)
20.	Fuel Injector Testing; Test No. 1 a. Cup to Plunger Seal Test b. Check Ball Leakage Test	3-53 3-53a 3-53b	2-8
21.	Fuel Injector Testing; Test No. 2 a. Setting Up Spray Pattern Tester b. Spray Pattern Test	3-54 3-54a 3-54b	2-8
22.	Fuel Injector Testing; Test No. 3 a. Setting Up Test Stand b. Setting Up Injector on Test Stand c. Testing Check Ball Seating d. Adjusting and Measuring Fuel Delivery e. Top-stop Injector Adjustment	3-55 3-55a 3-55b 3-55c 3-55d 3-55e	2-8
23.	Fuel Pump Repair a. Cleaning b. Inspection	3-56 3-56a 3-56b	2-8
24.	Solenoid Valve Repair a. Removal b. Disassembly c. Cleaning d. Inspection e. Assembly f. Installation	3-57 3-57a 3-57b 3-57c 3-57d 3-57e 3-57f	2-8
25.	Fuel Damper and Head Repair a. Removal b. Disassembly c. Cleaning d. Inspection e. Assembly f. Installation	3-58 3-58a 3-58b 3-58c 3-58d 3-58e 3-58f	2-8
26.	Fuel Gear Pump Repair a. Removal b. Disassembly c. Cleaning d. Inspection e. Assembly f. Installation	3-59 3-59a 3-59b 3-59c 3-59d 3-59e 3-59f	2-8

3-33. TASK SUMMARY (Contd)

List of Tasks (Contd)

TASK PARA.	PROCEDURES	TASK REF.	TROUBLESHOOTING REF. NO. (PARA.)
27.	Fuel Pump Governor Spring Repair a. Removal b. Cleaning c. Inspection d. Installation	3-60 3-60a 3-60b 3-60c 3-60d	2-8
28.	Fuel Pump Front Cover and Governor Repair a. Removal b. Disassembly c. Cleaning d. Inspection e. Assembly f. Installation	3-61 3-61a 3-61b 3-61c 3-61d 3-61e 3-61f	2-8
29.	Fuel Pump Main Housing Repair a. Disassembly b. Cleaning c. Inspection and Repair d. Assembly	3-62 3-62a 3-62b 3-62c 3-62d	2-8
30.	Fuel Pump Testing and Calibration a. Calibration Data b. Fuel Pump Nameplate Data c. Mounting Fuel Pump to Test Stand d. Fuel Pump Run-in e. Fuel Pump Vacuum and Seal Test f. Fuel Pump Vacuum Adjustment g. Governor Cut-off rpm Check h. Throttle Leakage Check i. Throttle Lever Travel Adjustment j. Fuel Pump Idle Speed Check k. Fuel Pump Main Pressure Adjustment l. Calibration Check Points m. AFC Plunger Setting Procedures n. No-Air Screw Adjustment o. Removing Fuel Pump from Test Stand	3-63 3-63a 3-63b 3-63c 3-63d 3-63e 3-63f 3-63g 3-63h 3-63i 3-63j 3-63k 3-63l 3-63m 3-63n 3-63o	2-8
31.	Water Pump Repair a. Disassembly b. Cleaning c. Inspection d. Assembly	3-64 3-64a 3-64b 3-64c 3-64d	2-8

3-34. ENGINE BLOCK REPAIR**THIS TASK COVERS:**

- a. Disassembly
- b. Cleaning

- c. Inspection and Repair
- d. Assembly

INITIAL SETUP:**APPLICABLE MODELS**

All

SPECIAL TOOLS

Camshaft bushing driver kit (15434) 3376633
 Cylinder sleeve driver (15434) ST-1229
 Cylinder sleeve clamp (15434) ST-1154
 Gauge block (15434) 3376220
 Engine block counterbore tool (15434) 3375455
 Bore alignment checking bar (15434) ST-1157

TEST EQUIPMENT

Crack detection kit (15434) 3375432

MATERIALS/PARTS

Solvent, SD-3 (Appendix C, Item 30)
 Oil, lubricating, OE/HDO 10
 (Appendix C, Item 20)
 Cloth, emery, 290-grit (Appendix C, Item 5)
 Sealant, pipe (Appendix C, Item 26)
 Sealant, cup plug (Appendix C, Item 25)
 Oil, lubricating, OE/HDO 30
 (Appendix C, Item 21)
 Silicone rubber (15434) MIL-A-46106
 (NSN 8040-00-851-0211) or suitable substitute
 Six gaskets (15434) 215090
 Six black preformed packings (15434) 3008998
 Six red preformed packings (15434) 183049
 Six preformed packings (15434) 3007442
 Two water header cover gaskets (15434) 70089-1

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

- Engine removed from vehicle (TM 9-2320-273-34 or TM 9-2320-283-34).
- Starter motor and solenoid removed (TM 9-2320-273-20 or TM 9-2320-283-20).
- Alternator, belts, and bracket removed (TM 9-2320-273-20 or TM 9-2320-283-20).
- Engine mounted on maintenance stand (para. 3-13).
- Vibration damper and crankshaft pulley removed (para. 3-14).
- Accessory drive pulley removed (para. 3-15).
- Fuel pump removed (para. 3-16).
- Air compressor removed (para. 3-17).
- Accessory drive housing assembly removed (para. 3-18).
- Oil pump removed (para. 3-19).
- Air aftercooler removed (para. 3-20).
- Engine retarders removed (para. 3-21).
- Rocker arm housing assemblies and pushrods removed (para. 3-22).
- Injector assemblies removed (para. 3-23).
- Cylinder head assemblies removed (para. 3-24).
- Flexplate or flywheel, flywheel housing, and rear cover removed (para. 3-25).
- Oil pan removed (para. 3-26).
- Front gear cover removed (para. 3-27).
- Camshaft and cam followers removed (para. 3-28).
- Pistons, connecting rods, and bearings removed (para. 3-29).
- Engine crankshaft and main bearings removed (para. 3-31).

SPECIAL ENVIRONMENTAL CONDITIONS

None

GENERAL SAFETY INSTRUCTIONS

- Improper cleaning methods and use of unauthorized cleaning solvents will not be used.
- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa).

3-34. ENGINE BLOCK REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly

- | | | |
|--------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|-----------------------------------------------------|
| 1. Six cylinder sleeves (2), cylinder sleeve shims (31 through 36), gasket (3), black preformed packing (4), and red preformed packing (5) | Remove from engine block (14) if not removed during engine disassembly. | Refer to para. 3-30. |
| 2. Five plugs (7), four plugs (26), plug (27), washer (28), two plugs (29), and five plugs (30) | Remove from engine block (14) if not removed during engine disassembly. | |
| 3. Fourteen screws (18), washers (17), and seven bearing caps (19), (20), and (21) | Remove from engine block (14) if installed after crankshaft removal. | Refer to para. 3-31. |
| 4. Cap (25) | Remove from engine block (14). | Use a hammer and punch to remove. Discard cap (25). |

b. Cleaning

WARNING

Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.


CAUTION

Do not immerse engine block in a hot cleaning solution without removing bearing sleeve and six camshaft bushings. Permanent damage to bearing sleeve and camshaft bearing surface will result.

- | | | |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5. Engine block (14) | Clean as follows:
a. Steam-clean exterior and interior surfaces. Clean area to be checked with SD-3 solvent.

b. Clean all oil and coolant passages.
c. Wire brush counterbore and lower bore. | Refer to para. 3-6. Scrape off any remaining gasket material from mating surfaces. Remove engine block (14) from maintenance stand if necessary (para. 3-13). Use suitable size brushes and extension rod to clear passages. Area where cylinder sleeves (2) are positioned. |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

3-34. ENGINE BLOCK REPAIR (Contd)



LEGEND:

- | | |
|----------------------------------------|---------------------------------------------|
| 1. CYLINDER SLEEVE ASSEMBLY (6) | 19. NO. 7 BEARING CAP |
| 2. CYLINDER SLEEVE (6) | 20. NO. 2, 4, AND 6 BEARING CAP (3) |
| 3. GASKET (6) | 21. NO. 1, 3, AND 5 BEARING CAP (3) |
| 4. BLACK PREFORMED PACKING (6) | 22. NO. 7 BEARING SLEEVE |
| 5. RED PREFORMED PACKING (6) | 23. NO. 1, 2, 4, AND 6 CAMSHAFT BUSHING (4) |
| 6. HEAD-TO-BLOCK PIN (6) | 24. NO. 3 AND 5 CAMSHAFT BUSHING (2) |
| 7. PLUG (5) | 25. CAP |
| 8. SELF-LOCKING SCREW (6) | 26. PLUG (4) |
| 9. PISTON COOLING NOZZLE (6) | 27. PLUG |
| 10. PREFORMED PACKING (6) | 28. WASHER |
| 11. CAPTIVE WASHER SCREW (12) | 29. PLUG (2) |
| 12. WATER HEADER COVER (2) | 30. PLUG (5) |
| 13. GASKET (2) | 31. CYLINDER SLEEVE SHIM 0.007 |
| 14. ENGINE BLOCK | 32. CYLINDER SLEEVE SHIM 0.008 |
| 15. CAM FOLLOWER PIN (6) | 33. CYLINDER SLEEVE SHIM 0.009 |
| 16. REAR MAIN BEARING-TO-BLOCK PIN (2) | 34. CYLINDER SLEEVE SHIM 0.020 |
| 17. WASHER (14) | 35. CYLINDER SLEEVE SHIM 0.031 |
| 18. SCREW (14) | 36. CYLINDER SLEEVE SHIM 0.062 |

3-34. ENGINE BLOCK REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Cleaning (Contd)


5. Engine block (14) (Contd)

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.

	d. Clean water pump cavity vent hole in No. 1 cylinder.	Use compressed air.
	e. Clear all dirt and cleaning solvent from threaded screw holes and areas of bearing sleeve (22) and camshaft bushings (23) and (24).	Use compressed air.
	f. Remove all scale from cylinder sleeve (2) counterbore area.	
6. Six cylinder sleeves (2)	Clean as follows: a. Clean with warm water and soap. b. Clean soap from cylinder sleeves (2) with steam. c. Apply a thick coat of OE/HDO 10 lubricating oil on inside bore of each and wait 10 minutes. d. Remove oil with clean paper towels. Clean each bore until no black or gray marks are on paper towel. e. Apply a light coat of OE/HDO 10 lubricating oil to each and set aside for inspection.	Use a bristle brush. Dry with compressed air.
7. All remaining parts	Clean with SD-3 solvent and dry.	Scrape off any remaining gasket material from mating surfaces. Dry with compressed air.

3-34. ENGINE BLOCK REPAIR (Contd)



LEGEND:

- | | |
|----------------------------------------|---------------------------------------------|
| 1. CYLINDER SLEEVE ASSEMBLY (6) | 19. NO. 7 BEARING CAP |
| 2. CYLINDER SLEEVE (6) | 20. NO. 2, 4, AND 6 BEARING CAP (3) |
| 3. GASKET (6) | 21. NO. 1, 3, AND 5 BEARING CAP (3) |
| 4. BLACK PREFORMED PACKING (6) | 22. NO. 7 BEARING SLEEVE |
| 5. RED PREFORMED PACKING (6) | 23. NO. 1, 2, 4, AND 6 CAMSHAFT BUSHING (4) |
| 6. HEAD-TO-BLOCK PIN (6) | 24. NO. 3 AND 5 CAMSHAFT BUSHING (2) |
| 7. PLUG (5) | 25. CAP |
| 8. SELF-LOCKING SCREW (6) | 26. PLUG (4) |
| 9. PISTON COOLING NOZZLE (6) | 27. PLUG |
| 10. PREFORMED PACKING (6) | 28. WASHER |
| 11. CAPTIVE WASHER SCREW (12) | 29. PLUG (2) |
| 12. WATER HEADER COVER (2) | 30. PLUG (5) |
| 13. GASKET (2) | 31. CYLINDER SLEEVE SHIM 0.007 |
| 14. ENGINE BLOCK | 32. CYLINDER SLEEVE SHIM 0.008 |
| 15. CAM FOLLOWER PIN (6) | 33. CYLINDER SLEEVE SHIM 0.009 |
| 16. REAR MAIN BEARING-TO-BLOCK PIN (2) | 34. CYLINDER SLEEVE SHIM 0.020 |
| 17. WASHER (14) | 35. CYLINDER SLEEVE SHIM 0.031 |
| 18. SCREW (14) | 36. CYLINDER SLEEVE SHIM 0.062 |

3-34. ENGINE BLOCK REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair

CAUTION

Cylinder sleeves do not require honing or deglazing to provide proper ring seating. To minimize damage, liner deglazing and honing are not recommended.


8. Six cylinder sleeves (2)	Inspect for the following:	Refer to Appendix F for wear limits.
	a. Check for cracks under top flange, at bottom of liner, and above grooves of preformed packings (4) and (5), and gasket (3).	Cracks can be checked by using magnetic method or by using crack detector dye. Discard if cracked.
	b. Check for excessive corrosion or erosion and pits.	Discard if pits are deeper than 1/16 in. (1.6 mm).
	c. Check underside of top flange for dents, pitting, or worn surfaces.	Discard if surface cannot be made smooth by lapping with medium grit emery cloth.
	d. Check diameter of inside bore at several places.	Discard if inside diameter is greater than 5.505 in. (139.827 mm). Use a suitable dial bore gauge.

NOTE

Piston cooling nozzles and water header covers were removed in para. 3-13.

9. Six piston cooling nozzles (9)	Inspect for cracks, chips, or distortion.	Discard if cracked, chipped, or distorted.
10. Two water header covers (12)	Inspect for cracks, excessive corrosion, or distortion.	Discard if cracked, corroded, or distorted.
11. Five plugs (7), four plugs (26), two plugs (29), and five plugs (30)	Inspect threads for damage.	Discard if damaged.
12. No. 7 bearing cap (19)	Inspect two rear main bearing-to-block pins (16) for damage.	Replace rear main bearing-to-block pins (16) if damaged. Remove by pulling out with gripping pliers. Install by tapping in.
13. Bearing cap (19), and three bearing caps (20) and (21)	Measure width of each and compare measurement with corresponding bearing support area of engine block (14).	Discard if width exceeds 0.004 in. (0.1016 mm).
14. Fourteen screws (18)	Inspect for stretched or damaged threads.	Discard if stretched or damaged.

3-34. ENGINE BLOCK REPAIR (Contd)



LEGEND:

- | | |
|--------------------------------|----------------------------------------|
| 2. CYLINDER SLEEVES (6) | 16. REAR MAIN BEARING-TO-BLOCK PIN (2) |
| 3. GASKET (6) | 18. SCREW (14) |
| 4. BLACK PREFORMED PACKING (6) | 19. NO. 7 BEARING CAP |
| 5. RED PREFORMED PACKING (6) | 20. NO. 2, 4, AND 6 BEARING CAP (3) |
| 7. PLUG (5) | 21. NO. 1, 3, AND 5 BEARING CAP (3) |
| 9. PISTON COOLING NOZZLE (6) | 26. PLUG (4) |
| 12. WATER HEADER COVER (2) | 29. PLUG (2) |
| 14. ENGINE BLOCK | 30. PLUG (5) |

3-34. ENGINE BLOCK REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)


15. Fourteen washers (17)	Inspect carefully for any cracks or indication of cracks.	Discard if any evidence or indication of cracks exist.
16. Six self-locking screws (8) and twelve captive washer screws (11)	Inspect threads for damage.	Discard if damaged.

NOTE

Ensure engine block is checked on a flat surface to prevent distortion. Do not inspect engine block on maintenance stand.

17. Engine block (14)	Inspect for the following:	
	a. Check for wear or damage.	Discard if damage is beyond repair.
	b. Check for cracks.	Clean area to be checked with SD-3 solvent. Use crack detection kit (3375432) to find cracks.
	c. Check for corrosion.	Check for corrosion on engine block (14) near cylinder sleeves (2). Discard if counterbore area cannot be cleaned or repaired.
	d. Check for flatness.	Check with straightedge and feeler gauge. If milling is required and 0.01-0.02 in. (0.25-0.51 mm) of metal is removed from top of engine block (14), use oversize gasket (3036126) to maintain correct distance between cylinder head and engine block (14).
	e. Inspect all threads.	Repair with suitable thread chaser. Use solid bushing-type thread insert for damaged cylinder head screw threads, and Heli-Coil insert for damaged main bearing screw threads.
	f. Check for wear or damage in area of six head-to-block pins (6).	Replace if damaged or worn.
	g. Check for wear or damage in area of six cam follower pins (15).	Replace if damaged or worn.

3-34. ENGINE BLOCK REPAIR (Contd)



LEGEND:

2. CYLINDER SLEEVES (6)

6. HEAD-TO-BLOCK PIN (6)

8. SELF-LOCKING SCREW (6)

11. CAPTIVE WASHER SCREW (12)

14. ENGINE BLOCK

15. CAM FOLLOWER PIN (6)

17. WASHER (14)

3-34. ENGINE BLOCK REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)


<p>18. Bearing cap (19), three bearing caps (20) and (21), fourteen washers (17), and screws (18)</p>	<p>Install on engine block (14) and tighten as follows:</p> <p>a. Tighten fourteen screws (18) to 85 lb-ft (115 N•m) in sequence shown. Then tighten each screw (18) to 250-260 lb-ft (339-353 N•m).</p> <p>b. Loosen fourteen screws (18) three to five threads or a minimum of three complete turns.</p> <p>c. Repeat step 18a.</p>	<p>Ensure bearing caps (19), (20), and (21) are in their correct location and position.</p>
<p>19. Bores of installed bearing caps (19), (20), and (21) of engine block (14)</p>	<p>Install bore alignment checking bar. Measure bore diameter of each at three different locations.</p>	<p>Use bore alignment checking bar (ST-1157). For greater accuracy, place engine block (14) on end before measuring bore diameter. Minimum bore is 4.7485 in. (120.6119 mm); maximum is 4.7505 in. (120.6627 mm). Discard if maximum is exceeded.</p>

CAUTION

Never use reamer in place of a check bar. Damage to cylinder block will result.

<p>20. Bore alignment of installed bearing caps (19), (20), and (21) of engine block (14)</p>	<p>a. Install suitable bore alignment checking bar. Inspect for burrs or slight binding.</p> <p>b. If necessary, remove 0.0002-0.003 in. (0.0051-0.076 mm) of stock from bottom milled surface of the main bearing caps which are out of alignment. Remove stock by lapping or surface grinding.</p>	<p>Bore alignment checking bar (ST-1157) should turn freely. Remove burrs with emery cloth. If a slight bind exists, perform step b.</p> <p>If alignment cannot be obtained, refer to step 21 and ream bore of installed bearing caps (19), (20), and (21).</p>
-----------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-34. ENGINE BLOCK REPAIR (Contd)



MAIN BEARING CAP TIGHTENING SEQUENCE

LEGEND:

- 14. ENGINE BLOCK
- 17. WASHER (14)
- 18. SCREW (14)

- 19. NO. 7 BEARING CAP
- 20. NO. 2, 4, AND 6 BEARING CAP (3)
- 21. NO. 1, 3, AND 5 BEARING CAP (3)

3-34. ENGINE BLOCK REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


c. Inspection and Repair (Contd)

NOTE

- Omit this step if replacement caps are being used.
- Reaming of bearing cap bore requires bearing caps be installed and tightened to specifications.

21. Bearing cap bore of engine block (14)	<p>Use suitable reamer; ream as follows:</p> <p>a. Position reamer bar on engine block (14) so rear of bar is piloted in two good bearing cap bores.</p> <p>b. Lubricate reamer with OE/HDO 10 lubricating oil.</p> <p>c. Use hand driver to turn reamer.</p> <p>d. Run reamer through all seven bearing cap bores without backing up or reversing.</p> <p>e. Check bearing cap bore with checking bar and measure diameter with dial indicator.</p>	<p>Clean block thoroughly after reaming.</p>
22. No. 7 bearing sleeve (22), four camshaft bushings (23), and two camshaft bushings (24)	<p>Inspect for the following:</p> <p>a. Chips, scoring, or scratches.</p> <p>b. Spun or turned within bore of engine block (14).</p> <p>c. Using inside micrometer or dial bore gauge, measure each inside diameter.</p>	<p>Replace if scratched, scored, or chipped. Proceed to step 23 for removal.</p> <p>If camshaft bushings have turned, oil passages will not be aligned. Remove and discard any camshaft bushing that has spun or turned. Proceed to step 23 for removal.</p> <p>Refer to Appendix F for wear limits. Mark each camshaft bushing for replacement if not within wear limits. Proceed to step 23 for removal.</p>

3-34. ENGINE BLOCK REPAIR (Contd)



LEGEND:

14. ENGINE BLOCK

22. NO. 7 BEARING SLEEVE

23. NO. 1, 2, 4, AND 6 CAMSHAFT BUSHING (4)

24. NO. 3 AND 5 CAMSHAFT BUSHING (2)

3-34. ENGINE BLOCK REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)


23. No. 7 bearing sleeve (22), four camshaft bushings (23), or two camshaft bushings (24)	Remove from engine block (14).	Use camshaft bushing driver kit (3376633). Discard after removal.
-------------------------------------------------------------------------------------------	--------------------------------	-------------------------------------------------------------------

NOTE

Before installation of bearing sleeve and camshaft bushing(s), inspect camshaft bushing bore of cylinder block.

24. Camshaft bushing bore in engine block (14)	Inspect for the following: a. Check for burrs or nicks. b. Check for concentricity of camshaft bushing bore. c. Open and clean oil passages.	Refer to Appendix F for wear limits. Remove with medium-grit emery cloth. Use suitable measuring device. Clean with suitable brush.
25. No. 7 bearing sleeve (22), four camshaft bushings (23), or two camshaft bushings (24)	Install on camshaft bushing bore of engine block (14) as follows: a. Ensure oil passages are open in camshaft bushing bore. b. Ensure there are no burrs in camshaft bushing bore of engine block (14). c. Install with oil holes aligned to holes in camshaft bushing bores. d. The alignment notch on No. 7 bearing sleeve (22) must align with oil drain opening in No. 7 camshaft bushing bore.	Use camshaft bushing driver kit (3376633). Apply a light coat of OE/HDO 10 lubricating oil to inside diameter of No. 7 bearing sleeve (22), camshaft bushing (23) or (24) after installation.

3-34. ENGINE BLOCK REPAIR (Contd)



LEGEND:

- 14. ENGINE BLOCK
- 22. NO. 7 BEARING SLEEVE

- 23. NO. 1, 2, 4, AND 6 CAMSHAFT BUSHING (4)
- 24. NO. 3 AND 5 CAMSHAFT BUSHING (2)

3-34. ENGINE BLOCK REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

26. Cylinder liner counterbore of engine block (14)	Inspect for the following: a. Check for dirty or rough edges. b. Check inside diameter and depth at four equally spaced positions. Refer to Appendix F for wear limits.	Remove trapped dirt and clean rough edges. Counterbore diameter must be measured in liner press fit area 0.100 in. (2.54 mm) maximum below deck. Repair and shim cylinder liner counterbore if the following conditions are not met. Refer to step 27 for counterbore repair. a. Difference in measurement around circumference must not exceed 0.001 in. (0.0254 mm). b. Ledge must be parallel with top of engine block (14) to within 0.0014 in. (0.0356 mm).
-----------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

NOTE


When checking cylinder liner protrusion, ensure shim(s) and cylinder sleeve correspond to cylinder being inspected as tagged during removal.

c. Check cylinder sleeve (2) protrusion. Measure depth of cylinder sleeve counterbore of engine block (14) and outside flange of cylinder sleeve (2) for corresponding cylinder. Subtract difference to determine amount of shims and/or depth of counterbore cut.	Installing cylinder sleeve (2) is not necessary. Cylinder sleeve shims (31), (32), (33), (34), (35), and (36) are available in the following thicknesses: 0.007, 0.008, 0.009, 0.020, 0.031, and 0.062 in.
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

NOTE

Cylinder head surface of engine block must be flat and without damage or distortion. Use a straightedge and a 0.002-in. feeler gauge to check cylinder head surface.

3-34. ENGINE BLOCK REPAIR (Contd)



LEGEND:

2. CYLINDER SLEEVE (6)

14. ENGINE BLOCK

31. CYLINDER SLEEVE SHIM 0.007

32. CYLINDER SLEEVE SHIM 0.008

33. CYLINDER SLEEVE SHIM 0.009

34. CYLINDER SLEEVE SHIM 0.020

35. CYLINDER SLEEVE SHIM 0.031

36. CYLINDER SLEEVE SHIM 0.062

3-34. ENGINE BLOCK REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

NOTE

The cylinder sleeve counterbore must be altered or repaired if:

- a. Material has been milled from top surface of cylinder block.
- b. Ledge of counterbore is not flat or even.
- c. Protrusion of cylinder liner is not correct.
- d. Cracks extend more than halfway out from radius.

27. Cylinder sleeve counterbore of engine block (14)

Repair as follows:


a. Position adapter plate on cylinder sleeve counterbore.

Use engine block counterbore tool (3375455). Check counterbore tool bit before boring operation. A correctly ground tool bit will leave counterbore surface completely flat or cupped to a 30-degree angle. The cup is preferred with a 0.005-0.015-in. (0.127-0.381-mm) radius as shown in cylinder sleeve counterbore cross section.

b. Tighten top and bottom locating pins by turning in screws.

c. Set tool adjustable sleeve so blade just contacts bottom of counterbore ledge.

3-34. ENGINE BLOCK REPAIR (Contd)



CYLINDER SLEEVE COUNTERBORE CROSS SECTION

LEGEND:
14. ENGINE BLOCK

3-34. ENGINE BLOCK REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

27. Cylinder sleeve counterbore of engine block (14) (Contd)

CAUTION

- **Never turn counterbore tool counterclockwise. Doing so will damage cutter blade.**
- **Do not remove more than a total of 0.062 in. (1.575 mm) of material when counterboring. Inside diameter of ledge should never be less than outside diameter of cylinder sleeve. A ledge that drops toward center of cylinder may cause cylinder sleeve to break during installation.**

d. Turn counterbore tool clockwise with even pressure.

e. Use a series of light cuts to clean up entire circumference of seat.

Do not remove more than 0.004 in. (0.102 mm) material per cut.

f. Check seat to determine if additional cuts are required.

g. Chamfer edge of counterbore ledge 45° after counterboring. Do not chamfer deeper than 0.013-0.024 in. (0.330-0.610 mm).

Use shims to compensate for metal removed and to restore cylinder sleeve (2) protrusion to 0.003-0.006 in. (0.076-0.152 mm). Use as few shims as possible. Where possible, use one thick shim in place of two or more thinner shims.

h. Remove counterboring tool.

28. Six cam follower pins (15)

Inspect for wear or damage.

Replace if worn or damaged. Force may be required to remove cam follower pins (15). They are a press fit. Install using a brass hammer.

29. Six head-to-block pins (6)

Inspect for wear or damage.

Replace if worn or damaged. Force may be required to remove head-to-block pins (6). They are a press fit. Install using a brass hammer.

d. Assembly

NOTE

- **Assembly steps 30 through 34 will to be completed prior to mounting engine block on maintenance stand.**
- **Apply pipe sealant to threads of plugs installed for water passages, and apply lubricating oil to plugs installed for oil galleys.**

30. Plug (7)

Install on engine block (14).


Tighten to 30 lb-ft (41 N•m).

31. Two plugs (29)


Install on engine block (14).

Balance of plugs are on opposite side of block. Tighten to 45 lb-ft (61 N•m).

3-34. ENGINE BLOCK REPAIR (Contd)



CYLINDER SLEEVE COUNTERBORE CROSS SECTION



LEGEND:

- 2. CYLINDER SLEEVE (6)
- 6. HEAD-TO-BLOCK PINS (6)
- 7. PLUG

- 14. ENGINE BLOCK
- 15. CAM FOLLOWER PINS (6)
- 29. PLUG (2)

3-34. ENGINE BLOCK REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)

32. Four plugs (26)	Install on engine block (14).	Balance of plugs are on opposite side of block. Tighten to 15 lb-ft (20 N•m).
33. Five plugs (30)	Install on engine block (14).	Tighten plugs (30) to 35 lb-ft (48 N•m). One is shown; four are on opposite side of block.
34. Plug (27) and washer (28)	Install on engine block (14).	Tighten plug (27) to 70 lb-ft (95 N•m). When step 34 is completed, mount engine block (14) on suitable maintenance stand.

CAUTION


- **Prior to installation, engine block counterbore must be free of sharp edges that would cut or damage cylinder sleeve preformed packings.**
- **If engine block counterbore and cylinder sleeve flange are not clean and free from oil prior to installation, improper sealing or protrusion may result.**

NOTE

Before final installation of cylinder sleeves, ensure protrusion of each cylinder sleeve is correct. Refer to step 26 for checking protrusion.

35. Cylinder sleeve shims (31) through (36)	Install on cylinder sleeve (2) as required.	Amount of shims required was determined during inspection.
36. New gasket (3), new black preformed packing (4), and new red preformed packing (5)	Install on cylinder sleeve (2).	Install new gasket (3) with chamfer down in top groove, new black preformed packing (4) on center groove, and new red preformed packing (5) on bottom groove. Repeat this step for remaining cylinder sleeves (2).

3-34. ENGINE BLOCK REPAIR (Contd)



LEGEND:

- | | |
|--------------------------------|--------------------------------|
| 2. CYLINDER SLEEVE (6) | 30. PLUG (5) |
| 3. GASKET (6) | 31. CYLINDER SLEEVE SHIM 0.007 |
| 4. BLACK PREFORMED PACKING (6) | 32. CYLINDER SLEEVE SHIM 0.008 |
| 5. RED PREFORMED PACKING (6) | 33. CYLINDER SLEEVE SHIM 0.009 |
| 14. ENGINE BLOCK | 34. CYLINDER SLEEVE SHIM 0.020 |
| 26. PLUG (4) | 35. CYLINDER SLEEVE SHIM 0.031 |
| 27. PLUG | 36. CYLINDER SLEEVE SHIM 0.062 |
| 28. WASHER | |

3-34. ENGINE BLOCK REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)

CAUTION


- Do not lubricate preformed packing until ready to install assembled cylinder sleeve. Preformed packing will increase in size once in contact with OE/HDO 10 lubricating oil for more than 10 minutes.
- Prior to installing a cylinder sleeve, apply a bead of inner sealer on counterbore of cylinder sleeve flange. Do not use an excessive amount of sealer. Excessive amounts can cause problems in cooling system.
- Do not permit lubricating oil once applied to preformed packing to come in contact with liner sealant. Oil will prevent sealant from adhering to liner flange and counterbore contact surface.

NOTE

Diameter of applied sealer bead must be at least 3/64 in. (1.2 mm) and not more than 1/16 in. (1.6 mm) wide. Cylinder sleeve must be installed within five minutes after sealer has been applied.

37. Six cylinder sleeve assemblies (1)	<p>Install on engine block (14) as follows:</p> <p>a. Place cylinder sleeve (2) on bore of engine block (14) by hand.</p> <p>b. Push downward with one quick stroke.</p> <p>c. Using cylinder sleeve driver and a mallet, drive flange against counterbore edge.</p> <p>d. Install two cylinder sleeve clamps (37) on engine block (14) and cylinder sleeve (2), and check sion after installation.</p> <p>e. Check inside diameter for out-of-round condition. Measure at several points within range of piston travel.</p>	<p>Lubricate black preformed packing (4), red preformed packing (5), and gasket (3) with OE/HDO 10 lubricating oil. Install assembled cylinder sleeves (2) within 10 minutes.</p> <p>Ensure preformed packings (4) and (5), and gasket (3) do not move from groove.</p> <p>Use sleeve driver (ST-1229).</p> <p>Tighten clamps to 50 lb-ft (68 N•m). Use cylinder sleeve clamps (ST-1154) (37) for securing protrusion cylinder sleeve assembly (1) on cylinder sleeve bore. Use gauge block (3376220) (38) to check protrusion. The amount of protrusion must not exceed 0.003-0.006 in. (0.076-0.152 mm).</p> <p>Bore must not be out-of-round more than 0.003 in. (0.076 mm) in top 1 in. (25.4 mm) area of piston travel and not more than 0.002 in. (0.051 mm) in area of gasket (3).</p>
----------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-34. ENGINE BLOCK REPAIR (Contd)



LEGEND:

- 1. CYLINDER SLEEVE ASSEMBLY (6)
- 2. CYLINDER SLEEVE (6)
- 3. GASKET (6)
- 4. BLACK PREFORMED PACKING (6)

- 5. RED PREFORMED PACKING (6)
- 14. ENGINE BLOCK
- 37. CYLINDER SLEEVE CLAMP (2)
- 38. GAUGE BLOCK

3-34. ENGINE BLOCK REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


d. Assembly (Contd)

38. Cap (25)	Install on rear of engine block (14).	Use suitable plug driver and pipe sealant around outside diameter of cap (25).
39. Fourteen screws (18), washers (17), No. 7 bearing cap (19), No. 2, 4, and 6 bearing caps (20), and No. 1, 3, and 5 bearing caps (21)	Install loosely on engine block (14).	Bearing caps will be removed at assembly during crankshaft installation.

FOLLOW-ON TASKS:

- Install engine crankshaft and main bearings (para. 3-68).
- Install pistons, connecting rods, and bearings (para. 3-69).
- Install camshaft and cam followers (para. 3-70).
- Install cylinder head assemblies and pushrods (para. 3-71).
- Install injector assemblies (para. 3-82).
- Perform injection timing (para. 3-72).
- Install accessory drive housing assembly (para. 3-73).
- Install oil pump (para. 3-74).
- Install front gear cover (para. 3-75).
- Install accessory drive pulley (para. 3-76).
- Install air compressor (para. 3-77).
- Install fuel pump (para. 3-78).
- Install vibration damper and crankshaft pulley (para. 3-79).
- Install flexplate or flywheel, flywheel housing, and rear cover (para. 3-80).
- Install oil pan (para. 3-81).
- Install and adjust valve crossheads (para. 3-83).
- Install rocker arm housing assemblies (para. 3-84).
- Adjust injectors and valves (para. 3-85).
- Install engine retarders (para. 3-86).
- Install air aftercooler (para. 3-87).
- Remove engine from maintenance stand (para. 3-88).
- Install starter motor and solenoid (TM 9-2320-273-20 or TM 9-2320-283-20).
- Install bracket, alternator, and belts (TM 9-2320-273-20 or TM 9-2320-283-20).
- Install engine on vehicle (TM 9-2320-273-34 or TM 9-2320-283-34).

3-34. ENGINE BLOCK REPAIR (Contd)



LEGEND:

14. ENGINE BLOCK

17. WASHER (14)

18. SCREW (14)

19. NO. 7 BEARING CAP

20. NO. 2, 4, AND 6 BEARING CAP (3)

21. NO. 1, 3, AND 5 BEARING CAP (3)

25. CAP

3-35. CYLINDER HEAD AND VALVE REPAIR

THIS TASK COVERS:

- a. Disassembly
- b. Cleaning

- c. Inspection and Repair
- d. Assembly and Testing

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

- Head holding fixture (15434) ST-583
- Valve spring compressor (15434) ST-448
- Fuel passage cleaning brush (15434) ST-876
- Valve seat extractor (15434) ST-1279
- Valve seat insert tool (15434) ST-257
- Valve seat insert cutter (15434) ST-662
- Valve guide arbor (15434) ST-663
- Valve seat insert staking tool (15434) ST-1124
- Valve seat insert staking tool driver (15434) ST-1122
- Dowel pin extractor (15434) ST-1134
- Crosshead guide spacer (15434) ST-633
- Valve guide driver (15434) 3375282
- Gauge block (15434) 3376220
- Injector sleeve puller (15434) ST-1244
- Bead cutting tool (15434) ST-788
- Injector seat cutting tool (15434) ST-824
- Injector sleeve driver (15434) ST-1227
- Injector sleeve holding tool (15434) ST-1179
- Injector sleeve expander (15434) ST-880
- Injector seat cutter (15434) ST-884
- Valve spring tester (15434) 3375182
- Expansion plug driver (3/4-in.) (15434) 3375190
- Expansion plug driver (1-in.) (15434) 3375191
- Expansion plug driver (1-1/4 in.) (15434) 3375192
- Valve vacuum tester (15434) ST-1257-A

TEST EQUIPMENT

None

MATERIALS/PARTS

- Solvent, SD-3 (Appendix C, Item 30)
- Cloth, crocus (Appendix C, Item 4)
- Oil, cutting (Appendix C, Item 18)
- Compound, Prussian blue (Appendix C, Item 9)
- Oil, lubricating, OE/HDO 30 (Appendix C, Item 21)
- Sealant, cup plug (Appendix C, Item 25)
- Liquid thread sealant (Appendix C, Item 27)
- Forty-eight valve collets (15434) 127554
- Four O-ring seals (15434) 131026
- Six 3/4-in. expansion plugs (15434) 213394
- 1-in. expansion plug (15434) 213395
- Two 1-1/4 in. expansion plugs (15434) 216524
- Injector assembly (15434) 3030445
- Injector clamp (15434) 3028171
- Two injector clamp screws (15434) 3028279
- Six injector preformed packings (15434) 3007759

PERSONNEL REQUIRED

Automotive repairman MOS 63H

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Cylinder head assembly removed (para. 3-24).

REFERENCES (TM)

None

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust

GENERAL SAFETY INSTRUCTIONS

- Always wear eye protection when using compressed air.
- Approved solvents may be flammable and will not be used near open flame.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


a. Disassembly

NOTE

This procedure covers repair of any one of three cylinder head assemblies. Quantities shown in legend are for one cylinder head assembly.

- | | |
|----------------------------------------------------|-------------------------------------------|
| 1. Two locking nuts (21) and adjusting screws (20) | Remove from intake valve crossheads (22). |
|----------------------------------------------------|-------------------------------------------|

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- | | |
|-----------------------------------|-------------------------------------|
| 1. CYLINDER HEAD ASSEMBLY | 16. EXPANSION PLUG |
| 2. VALVE COLLET (16) | 17. EXPANSION PLUG (2) |
| 3. VALVE SPRING GUIDE (8) | 18. VALVE STEM GUIDE (8) |
| 4. VALVE SPRING (8) | 19. INTAKE VALVE CROSSHEAD ASSEMBLY |
| 5. VALVE SPRING GUIDE (8) | 20. ADJUSTING SCREW (2) |
| 6. INJECTOR PREFORMED PACKING (2) | 21. LOCKING NUT (2) |
| 7. INJECTOR SLEEVE (2) | 22. INTAKE VALVE CROSSHEAD (2) |
| 8. VALVE CROSSHEAD GUIDE (4) | 23. FUEL CONNECTION (2) |
| 9. CYLINDER HEAD | 24. PREFORMED PACKING (2) |
| 10. EXPANSION PLUG (6) | 25. COVER PLATE |
| 11. DOWEL (2) | 26. SCREW (2) |
| 12. INTAKE VALVE INSERT (4) | 27. PIPE PLUG (4) |
| 13. INTAKE VALVE (4) | 28. EXHAUST VALVE CROSSHEAD (2) |
| 14. EXHAUST VALVE (4) | 29. LOCKING NUT (2) |
| 15. EXHAUST VALVE INSERT (4) | 30. ADJUSTING SCREW (2) |

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)

- | | | |
|-----------------------------------------------------------------------|--------------------------------------------------------------|--|
| 2. Two locking nuts (29) and adjusting screws (30) | Remove from exhaust valve crossheads (28). | |
| 3. Two intake valve crossheads (22) and exhaust valve crossheads (28) | Remove from valve crosshead guides (8) on cylinder head (9). | |

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.

- | | | |
|-------------------------------|----------------------------------------------------------------------------------|------------------------------------|
| 4. Cylinder head assembly (1) | a. Steam clean and dry with compressed air.
b. Put into head holding fixture. | Use head holding fixture (ST-583). |
|-------------------------------|----------------------------------------------------------------------------------|------------------------------------|

NOTE

Repeat steps 5, 6, and 7 for each intake or exhaust valve.

- | | | |
|-----------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5. Valve spring (4) | Compress. | Use valve spring compressor (ST-448) (32) and head holding fixture (ST-583). Stud of valve spring compressor (32) should be installed on screw hole (31). Keep a firm hold on valve spring compressor (32) until valve collets (2) are removed. |
| 6. Two valve collets (2) | a. Tap head of valve (13) or (14) lightly to loosen.


b. Remove from valve and valve spring guide (3). | Use magnet if needed. Discard valve collets (2). |
| 7. Intake valve (13), exhaust valve (14), valve spring (4), and valve spring guides (3) and (5), and spacers* (33), if used | Remove from cylinder head (9). | As each valve is removed, place on numbered board or stand. If spacers are used, cylinder head has been resurfaced at one time. |

NOTE

Step 8 does not apply to No. 2 cylinder head.

- | | | |
|---------------------------------------------------------------------------------|------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 8. Two screws (26), cover plate (25), and two preformed packings (24) | Remove from cylinder head (9). | Discard preformed packings (24). |
| 9. Four pipe plugs (27) | Remove two from each end of cylinder head (9). | No. 3 cylinder head has two pipe plugs in forward end only. |
| 10. Six expansion plugs (10), expansion plug (16), and two expansion plugs (17) | Remove from cylinder head (9). | a. Using hammer and punch, hit outside diameter of expansion plugs to force one side out.
b. Use screwdriver or pliers to remove expansion plug from hole. Discard expansion plugs (10), (16), and (17). |

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- | | |
|------------------------------|----------------------------------------------------|
| 1. CYLINDER HEAD ASSEMBLY | 21. LOCKING NUT (2) |
| 2. VALVE COLLET (16) | 22. INTAKE VALVE CROSSHEAD (2) |
| 3. VALVE SPRING GUIDE (8) | 24. PREFORMED PACKING (2) |
| 4. VALVE SPRING (8) | 25. COVER PLATE |
| 5. VALVE SPRING GUIDE (8) | 26. SCREW (2) |
| 8. VALVE CROSSHEAD GUIDE (4) | 27. PIPE PLUG (4) |
| 9. CYLINDER HEAD | 28. EXHAUST VALVE CROSSHEAD (2) |
| 10. EXPANSION PLUG (6) | 29. LOCKING NUT (2) |
| 13. INTAKE VALVE (4) | 30. ADJUSTING SCREW (2) |
| 14. EXHAUST VALVE (4) | 31. ROCKER LEVER SCREW HOLE |
| 16. EXPANSION PLUG | 32. VALVE SPRING COMPRESSOR |
| 17. EXPANSION PLUG (2) | 33. *SPACER (USED IF CYLINDER HEAD WAS RESURFACED) |
| 20. ADJUSTING SCREW (2) | |

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Cleaning

WARNING

Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.


11. Cylinder head assembly (1)	a. Clean by submerging in solvent SD-3. b. Clean internal passages and flush passages with solvent SD-3 to remove deposits.	Circulate solvent to increase effectiveness on salt, lime deposits, and grease, etc. Use fuel passage cleaning brush (ST-876). Ensure lubricating oil passages are open and clean.
--------------------------------	------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and personal protective equipment goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.

12. All other parts	c. Dry with compressed air. Clean by submerging in solvent SD-3 and dry with compressed air.	Refer to para. 3-6 for additional cleaning instructions.
---------------------	-----------------------------------------------------------------------------------------------------	----------------------------------------------------------

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- | | |
|-----------------------------------|-------------------------------------|
| 1. CYLINDER HEAD ASSEMBLY | 16. EXPANSION PLUG |
| 2. VALVE COLLET (16) | 17. EXPANSION PLUG (2) |
| 3. VALVE SPRING GUIDE (8) | 18. VALVE STEM GUIDE (8) |
| 4. VALVE SPRING (8) | 19. INTAKE VALVE CROSSHEAD ASSEMBLY |
| 5. VALVE SPRING GUIDE (8) | 20. ADJUSTING SCREW (2) |
| 6. INJECTOR PREFORMED PACKING (2) | 21. LOCKING NUT (2) |
| 7. INJECTOR SLEEVE (2) | 22. INTAKE VALVE CROSSHEAD (2) |
| 8. VALVE CROSSHEAD GUIDE (4) | 23. FUEL CONNECTION (2) |
| 9. CYLINDER HEAD | 24. PREFORMED PACKING (2) |
| 10. EXPANSION PLUG (6) | 25. COVER PLATE |
| 11. DOWEL (2) | 26. SCREW (2) |
| 12. INTAKE VALVE INSERT (4) | 27. PIPE PLUG (4) |
| 13. INTAKE VALVE (4) | 28. EXHAUST VALVE CROSSHEAD (2) |
| 14. EXHAUST VALVE | 29. LOCKING NUT (2) |
| 15. EXHAUST VALVE INSERT (4) | 30. ADJUSTING SCREW (2) |

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


c. Inspection and Repair

CAUTION

Do not use disk sander to polish cylinder head. Disk sander could cause serious damage to mating surface of head.

13. Cylinder head (9)	<ul style="list-style-type: none"> a. Polish mating surface. b. Inspect for cracks, breaks, distortion, and broken-out areas. c. Inspect for cracks using magnetic method. d. Check for scratches or unevenness on mating surface. e. Resurface mating surface. f. Inspect four valve inserts (12) and (15) for cracks, broken, or chipped areas. Remove if damaged. g. Polish mating surface. h. Measure cylinder head (9) height. 	<p>Use crocus cloth or orbital sander. Polish just enough to shine finish. This allows for a more complete inspection of mating surface.</p> <p>Discard cylinder head assembly (1) if cylinder head (9) is damaged.</p> <p>Discard cylinder head assembly (1) if any cracks are found.</p> <p>Use straightedge and feeler gauge. Perform steps 13e through 13i if mating surface is scratched or uneven more than 0.002 in. (0.051 mm).</p> <p>Do not remove more than 0.005 in. (0.127 mm) of material at one time. Total amount of material removed must not exceed 0.040 in. (1.016 mm).</p> <p>Refer to steps 15a through 15e for removal and installation. Discard damaged valve inserts (12) and (15).</p> <p>Use crocus cloth or orbital sander.</p> <p>Use suitable vernier depth gauge. Discard cylinder head assembly (1) if cylinder head is less than wear limit shown below:</p> <p>Wear Limit 4.340 in. (11.024 cm) New Minimum 4.370 in. (11.100 cm) New Maximum 4.380 in. (11.125 cm)</p>
	<ul style="list-style-type: none"> i. Remove two injector sleeves (7) from cylinder head (9). 	<p>Refer to steps 18d and 18e.</p>

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- 1. CYLINDER HEAD ASSEMBLY
- 7. INJECTOR SLEEVE (2)
- 9. CYLINDER HEAD
- 12. INTAKE VALVE INSERT (4)

- 13. INTAKE VALVE (4)
- 14. EXHAUST VALVE (4)
- 15. EXHAUST VALVE INSERT (4)
- 18. VALVE STEM GUIDE (8)


3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

14. Eight valve stem guides (18)	<p>a. Inspect for chips, cracks, burrs, broken-out sections, and extensive wear.</p> <p>b. Measure protrusion.</p> <p>c. Set small bore gauge to 0.4552 in. (11.562 mm) and attempt to insert it in bore of valve stem guide.</p> <p>Wear Limit 0.4550 in. (11.557 mm) New Minimum 0.4525 in. (11.494 mm) New Maximum 0.4532 in. (11.511 mm)</p> <p>d. Replace valve stem guide (18) as follows:</p> <p style="padding-left: 20px;">(1) Drive out valve stem guide (18) from underside of cylinder head (9).</p> <p style="padding-left: 20px;">(2) Install new valve stem guide (18).</p> <p style="padding-left: 20px;">(3) Using new valve (13) or (14), check bore of new valve stem guide.</p>	<p>Replace if damaged (refer to step 14d for replacement).</p> <p>Use suitable micrometer. Replace if not within 1.270-1.280 in. (3.226-3.251 cm). (Refer to step 14d for replacement.)</p> <p>Replace if gauge goes into bore or if bore is more than wear limit shown below. (Refer to step 14d for replacement.)</p> <p>Do not replace unless damaged or not within wear limits.</p> <p>Use suitable step punch. Discard valve stem guide.</p> <p>Use valve guide driver (3375282) (34). Ensure height of valve stem guide is between 1.270-1.280 in. (3.226-3.251 cm) after installation. If valve does not move freely in valve stem guide (18), ream valve stem guide (18) from bottom side of cylinder head (9) to specifications shown in step 14c.</p>
15. Four intake valve inserts (12) and four exhaust valve inserts (15)	<p>a. Check for looseness by carefully striking cylinder head (9) with wood block or rubber hammer.</p> <p>b. Measure valve seat area width (A or B in illustration).</p> <p>c. Check valve seat for concentricity with valve stem guide (18).</p> <p>d. Replace valve insert (12) or (15) as follows:</p> <p style="padding-left: 20px;">(1) Clean area around valve seat.</p> <p style="padding-left: 20px;">(2) Place valve seat extractor (35) into valve seat and expand until jaws are under valve insert (12).</p> <p style="padding-left: 20px;">(3) Remove valve insert (12) or (15) from cylinder head (9).</p> <p style="padding-left: 20px;">(4) Drive new valve insert (12) or (15) in valve seat insert counter-bore of cylinder head (9) until fully seated.</p>	<p>Perform step 15d only if width is less than 0.0625 in. (1.5875 mm) or more than 0.125 in. (3.175 mm) at any point.</p> <p>Total run out should not exceed 0.002 in. (0.051 mm).</p> <p>Use valve seat extractor (ST-1279) (35). Ensure extractor (35) is not canted.</p> <p>Use suitable slide hammer. Discard valve insert (12) or (15). Use valve seat insert staking tool (ST-1124) (36).</p>

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- 9. CYLINDER HEAD
- 12. INTAKE VALVE INSERT (4)
- 13. INTAKE VALVE (4)
- 14. EXHAUST VALVE (4)
- 15. EXHAUST VALVE INSERT (4)

- 18. VALVE STEM GUIDE (8)
- 34. VALVE GUIDE DRIVER
- 35. VALVE SEAT EXTRACTOR
- 36. VALVE SEAT INSERT STAKING TOOL
- 37. VALVE SEAT INSERT STAKING TOOL DRIVER


3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

<p>15. Four intake valve inserts (12) and four exhaust valve inserts (15) (Contd)</p>	<p>(5) Stake (peen) cylinder head (9).</p>	<p>Use valve seat insert staking tool (ST-1124) (36) and driver (37) If valve seat insert staking tool (36) and driver (37) are not available, a punch with round end can be used to stake cylinder head (9).</p>
	<p>e. Machine valve insert counterbore for installing oversize inserts (12) or (15) as follows:</p>	
	<p>(1) Clamp base of insert tool (40) to cylinder head (9).</p>	<p>Use valve seat insert tool (ST-257) (40).</p>
	<p>(2) Install cutter (39).</p>	<p>Use valve seat insert cutter (ST-662) (39). Ensure valve seat insert tool (40) is securely clamped before starting electric drill.</p>
	<p>(3) Using arbor (38), center cutter (39) on valve seat insert (12) or (15).</p>	<p>Use valve guide arbor (ST-663) (38).</p>
	<p>(4) Cut counterbore 0.006-0.010 in. (0.152-0.254 mm) deeper than valve insert thickness.</p>	<p>This allows room for peening of cylinder head (9) to secure valve insert (12) or (15). Allow cutter to turn several revolutions to make sure counterbore surface is even. Remove valve seat insert tool (40), valve seat insert cutter (39), and valve guide arbor (38).</p>
	<p>(5) Clean out all chips and debris from valve insert counterbore.</p>	

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- | | |
|------------------------------------|-------------------------------------------|
| 9. CYLINDER HEAD | 37. VALVE SEAT INSERT STAKING TOOL DRIVER |
| 12. INTAKE VALVE INSERT (4) | 38. VALVE GUIDE ARBOR |
| 15. EXHAUST VALVE INSERT (4) | 39. VALVE SEAT INSERT CUTTER |
| 36. VALVE SEAT INSERT STAKING TOOL | 40. VALVE SEAT INSERT TOOL |


3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

16. Four valve crosshead guides (8)	a. Inspect each for straightness and for being at a right angle to surface of cylinder head (9).	Replace valve crosshead guides (8) that are not straight or square to cylinder head (9). (Refer to step 16d for replacement.)
	b. Measure outside diameter.	Use suitable micrometer. Replace if less than wear limit shown below. (Refer to step 16d for replacement.)
	Wear Limit 0.4320 in. (10.973 mm)	
	New Minimum 0.4330 in. (10.998 mm)	
	New Maximum 0.4335 in. (11.011 mm)	
	c. Using suitable micrometer, measure protrusion.	Replace if not within 1.860-1.880 in. (4.724-4.775 cm). (Refer to step 16d for replacement.)
	d. Replace valve crosshead guides (8) as follows:	Do not replace unless bent or not within wear limits.
	(1) Remove guide (8) from cylinder head (9).	Use dowel pin extractor (ST-1134) (41). Discard valve crosshead guide (8).
	(2) Clean crosshead guide (8) holes thoroughly.	
	(3) Install new valve crosshead guide (8) on cylinder head (9).	Use arbor press and crosshead guide spacer (ST-633) (42). Ensure height of valve crosshead guide (8) is between 1.860-1.880 in. (4.724-4.775 cm) after installation.
17. Two dowels (11)	Inspect for cracks, breaks, bending, or looseness.	Replace if damaged or loose.

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- 8. VALVE CROSSHEAD GUIDE (4)
- 9. CYLINDER HEAD
- 11. DOWEL (2)

- 41. DOWEL PIN EXTRACTOR
- 42. CROSSHEAD GUIDE SPACER

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

18. Two injector sleeves (7)	a. Inspect for scratches on cup area and cracks at rolled seam. b. Check seating pattern as follows:	Replace if any scratches are found. (Refer to step 18d for replacement.)
------------------------------	-------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------

NOTE

Ensure injector assembly is new or condition of injector assembly cup is satisfactory prior to checking seating pattern.

(1) Lightly coat cup of injector assembly (43) with Prussian blue compound.

(2) Install injector assembly (43) on injector sleeve (7) and secure with injector damp (44) and two screws (45).


(3) Remove two screws (45), injector clamp (44), and injector assembly (43) from injector sleeve (7).

(4) Check seating pattern in cup seating area of injector sleeve (7).

Tighten screws (45) alternately in 48 lb-in. (5 N•m) increments to 10-12 lb-ft (14-16 N•m).

Seating pattern must cover completely around injector seat and must be at least 0.060 in. (1.524 mm) wide and 0.469 in. (11.913 mm) from bottom surface of cylinder head (9) (refer to illustration). Replace old injector sleeve (7) if not within above specifications (refer to step 18d for replacement). Recut new injector sleeve (7) if not within above specifications (refer to step 18e for recutting).

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- 7. INJECTOR SLEEVE (2)
- 9. CYLINDER HEAD
- 43. INJECTOR ASSEMBLY

- 44. INJECTOR CLAMP
- 45. INJECTOR CLAMP SCREW (2)

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

18. Two injector sleeves (7) (Contd)

c. Check protrusion of injector assembly (43) tip as follows:

NOTE
Ensure injector assembly is new or condition of injector assembly is known to be satisfactory prior to checking protrusion of tip.

(1) Install injector assembly (43) on injector sleeve (7) with injector clamp (44) and two screws (45).

Tighten screws (45) alternately in 48 lb-in. (5 N•m) increments to 10-12 lb-ft (14-16 N•m).

(2) Measure protrusion of tip.

Tip protrusion should be 0.060-0.070 in. (1.524-1.778 mm). Replace injector sleeve if protrusion is more than 0.070 in. (1.778 mm) (refer to step 18d for replacement). Recut injector sleeve (7) if protrusion is less than 0.060 in. (1.524 mm) (refer to step 18e for recutting).

d. Replace injector sleeve (7) as follows:

Replace if damaged or not within wear limits.

(1) Install puller (47) on injector sleeve (7) as shown in illustration.


Use injector sleeve puller (ST-1244) (47). Ensure puller (47) legs of support bridge are against surface of cylinder head (9) and both nuts are loose.

(2) Strike puller (47) with hammer to push puller (47) into injector sleeve (7).

(3) Tighten small nut on puller (47) to 50 lb-ft (68 N•m).

Do not tighten small nut more than 60 lb-ft (81 N•m).

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- 7. INJECTOR SLEEVE (2)
- 43. INJECTOR ASSEMBLY
- 44. INJECTOR CLAMP

- 45. INJECTOR CLAMP SCREW (2)
- 47. INJECTOR SLEEVE PULLER

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

c. Inspection and Repair (Contd)

18. Two injector sleeves (7) (Contd)

(4) Turn large nut clockwise on puller (47) and remove injector sleeve (7) from cylinder head (9).

(5) Remove injector sleeve (7) from injector sleeve puller (47).

(6) Remove injector preformed packing (6) from injector sleeve bore of cylinder head (9).

(7) Remove all foreign material from injector sleeve sealing area with steel brush.

(8) Inspect injector sleeve seat area of cylinder head (9) for any possible damage incurred during removal.

Loosen nuts. Tap small end of injector sleeve (7) to free from puller (47). Discard injector sleeve (7).

Discard preformed packing (6).

Use suitable steel brush. Refer to para. 3-6 for additional cleaning instructions.

NOTE

Perform step 18d, tasks 9 through 18, only if injector sleeve seat area is damaged or bead is not smooth.


(9) Install bead cutting tool (48), pilot (49), and holder (50) on drill press.

(10) Place cylinder head (9) on drill press table.

Use bead cutting tool (ST-788) (48). If drill press is not available, bead cutting tool (48) may also be turned by hand using tap wrench.

Adjust table height to allow for proper clearance so that end of bead cutter (48) will protrude below cylinder head (9) surface into pilot hole of injector sleeve (7) seat area.

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- 6. INJECTOR PREFORMED PACKING (2)
- 7. INJECTOR SLEEVE (2)
- 9. CYLINDER HEAD
- 47. INJECTOR SLEEVE PULLER

- 48. BEAD CUTTING TOOL
- 49. PILOT
- 50. HOLDER

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

18. Two injector sleeves (7) (Contd)

(11) Before starting drill press motor, insert bead cutting tool (48), pilot (49), and holder (50) in injector sleeve bore of cylinder head (9) to ensure proper alignment.

(12) Lubricate cutter (48) with cutting oil.

Raise cutter (48) high enough to lubricate.

CAUTION

- Use extreme caution when cutting injector sleeve seat.
- Do not run drill press at speeds higher than 75 rpm. Tool chatter may occur at speeds higher than 75 rpm, damaging injector sleeve bore.

NOTE

Do not cut more than 0.010 in. (0.254 mm) deep into cylinder head.

(13) Turn on drill press motor and make a very light cut.

When proper cut depth has been reached, allow cutter (48) to turn in position for about 10 seconds to ensure a good seat and clean grooves.

(14) Remove cutter (48), holder (50), and pilot (49) from drill press.

(15) Remove bead cutting tool (48) from holder (50) and pilot (49), and install injector seat cutting tool (51).

Use injector seat cutting tool (ST-824) (51) to cut a 70° chamfer at top edge of 60° seat. Apply Prussian blue compound to 60° seat to aid in determining amount of chamfer needed.

(16) Lubricate and position cutter (51), holder (50), and pilot (49) on seat.

Lubricate cutter (51) with cutting oil.

(17) Rotate cutter (51) while applying even pressure.


Use tap wrench. Remove cutter (51), holder (50), and pilot (49) when lower edge of 70° relief chamfer is about 0.125 in. (3.175 mm) from top of bead.

CAUTION

To prevent damage to injector sleeve during installation, ensure sleeve seat is free from oil, carbon, or any other foreign material.

(18) Remove any bluing compound left on injector seat surface.

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- 7. INJECTOR SLEEVE
- 9. CYLINDER HEAD
- 48. BEAD CUTTING TOOL

- 49. PILOT
- 50. HOLDER
- 51. INJECTOR SEAT CUTTING TOOL

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

18. Two injector sleeves (7) (Contd)	(19) Apply a light coat of lubricating oil to new injector preformed packing (6).	Shake off excess oil.
	(20) Install injector preformed packing (6) on groove of injector sleeve bore of cylinder head (9).	
	(21) Using driver (52), push injector sleeve (7) into injector sleeve bore until firmly seated.	Use injector sleeve driver (ST-1227) (52). Install injector sleeve (7) by striking driver (52).
	(22) Remove driver (52).	
	(23) Install holding tool (53) on injector sleeve (7).	Use injector sleeve holding tool (ST-1179) (53). Tighten nut on holding tool (53) to 35-40 lb-ft (48-54 N•m).
	(24) Insert driver (52) in injector sleeve (7), and strike with soft-nose hammer until injector sleeve (7) is seated properly against bottom of injector sleeve bore.	Tighten nut on holding tool (53) again to 35-40 lb-ft (48-54 N•m).
	(25) Remove driver (52).	

CAUTION

- To avoid distorting injector sleeve, do not roll lower area of sleeve.
- Over-rolling or peening injector sleeve will deform injector O-ring groove of sleeve.


(26) Install expander (54) on injector sleeve (7).	Use injector sleeve expander (ST-880) (54).
(27) Tighten expander (54) to 75 lb-in. (102 N•m).	
(28) Remove expander (54) and holding tool (53) from injector sleeve (7).	
e. Cut injector seat as follows:	

NOTE

Ensure injector assembly is new or is known to be satisfactory prior to checking protrusion of tip.

(1) Install injector assembly (43) on injector sleeve (7) with injector clamp (44) and two screws (45).	Tighten screws (45) alternately in 48 lb-in. (5 N•m) increments to 120-144 lb-in. (14-16 N•m).
---------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- 6. INJECTOR PREFORMED PACKING (2)
- 7. INJECTOR SLEEVE (2)
- 9. CYLINDER HEAD
- 43. INJECTOR ASSEMBLY
- 44. INJECTOR CLAMP

- 45. INJECTOR CLAMP SCREW (2)
- 52. INJECTOR SLEEVE DRIVER
- 53. INJECTOR HOLDING TOOL
- 54. INJECTOR SLEEVE EXPANDER


3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

18. Two injector sleeves (7) (Contd)	<p>(2) Using gauge block (46), measure protrusion of injector assembly (43) tip.</p> <p>(3) Remove two screws (45), injector clamp (44), and injector assembly (43) from injector sleeve (7).</p> <p>(4) Install cutter (55) and pilot (49) on drill press and cut injector sleeve (7).</p> <p>(5) Check injector (43) seating.</p> <p>(6) Check protrusion of injector assembly (43) tip.</p>	<p>Use this measurement to determine amount that must be cut from sleeve. The protrusion of injector tip must be 0.060-0.070 in. (1.524-1.778 mm).</p> <p>Use injector seat cutter (ST-884) (55). Ensure enough cutting oil is used to allow cutter (55) to cut freely without grabbing. When proper cut depth is reached, allow cutter (55) to turn in position for about 10 seconds to ensure a smooth seat.</p> <p>Refer to step 18b pattern.</p> <p>Refer to step 18c.</p>
19. Eight valve springs (4)	<p>a. Inspect for distortion, cracks, breaks, and collapsed coils.</p> <p>b. Using tester (56), compress to working length of 1.724 in. (4.379 cm).</p> <p>c. Record amount of force required to compress valve spring (4).</p>	<p>Discard valve spring (4) if damaged.</p> <p>Use valve spring tester (3375182) (56).</p> <p>Discard if less than wear limit shown below.</p>
	<p>Wear Limit 143.00 lb (64.92 kg)</p> <p>New Minimum 147.25 lb (66.85 kg)</p> <p>New Maximum 162.75 lb (73.89 kg)</p>	

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- 4. VALVE SPRING (8)
- 7. INJECTOR SLEEVE (2)
- 43. NEW INJECTOR ASSEMBLY
- 44. INJECTOR CLAMP
- 45. INJECTOR CLAMP SCREW (2)

- 46. GAUGE BLOCK
- 49. PILOT
- 55. INJECTOR SEAT CUTTER
- 56. VALVE SPRING TESTER

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

NOTE

Repeat step 20 for each intake and exhaust valve.


20. Valve (13) or (14)	a. Polish with crocus cloth.	
	b. Inspect head of valve (13) or (14) for cupping, cracking, pitting, and wear.	Discard if damaged or if valve head rim thickness is less than 0.105 in. (2.667 mm).
	c. Inspect stem of valve (13) or (14) for cracks, scoring, galling, wear or bends.	Discard if damaged or if stem diameter is less than wear limit shown below.
	Wear Limit	0.449 in. (11.405 mm)
	New Minimum	0.450 in. (11.430 mm)
	New Maximum	0.451 in. (11.455 mm)
	d. Check collet grooves on valve (13) or (14) stem for wear.	Use new valve collets (2) to check grooves. Discard valve (13) or (14) if collets fit loosely in grooves.
	e. Inspect for cracks using magnetic method:	
	(1) Magnetize valve (13) or (14) in coil at 100 to 300 amperes, and inspect with residual Magnaglo. If damaged, defects will show around circumference of valve.	Inspect area A (refer to illustration) and discard valve (13) or (14) with more than five indications, longer than 0.500 in. (12.7 mm), or indications spaced closer than 0.125 in. (3.175 mm).
	(2) Magnetize valve (13) or (14) by headshot magnetization at 500 to 700 amperes, and inspect with residual Magnaglo.	Inspect areas B, C, D, and E (refer to illustration). No visible or magnetic indication is acceptable. Discard. Demagnetize acceptable valves (13) or (14).

NOTE

Repeat step 21 for each intake and exhaust valve crosshead.

21. Valve crosshead (22) or (28)	a. Inspect for excessive wear, distortion, grooving, scoring, galling, stripped threads, broken areas, and out-of-round.	Discard if damaged.
	b. Inspect for cracks using magnetic method.	Discard if any cracks are found.

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- 2. VALVE COLLET (16)
- 13. INTAKE VALVE (4)
- 14. EXHAUST VALVE (4)

- 22. INTAKE VALVE CROSSHEAD (2)
- 28. EXHAUST VALVE CROSSHEAD (2)

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)


21. Valve crosshead (22) or (28) (Contd)	c. Use suitable bore gauge. Measure crosshead bore diameter.	Discard if not within wear limit shown below.
	Wear Limit	0.440 in. (11.176 mm)
	New Minimum	0.434 in. (11.024 mm)
	New Maximum	0.436 in. (11.074 mm)

CAUTION

To prevent damage to valve crosshead, do not use plug gauge during next step.

22. Two fuel connections (23)	d. Check crosshead bore at four points, spaced 90° apart, for out-of-round.	Use suitable bore gauge. Discard if out-of-round.
	e. Inspect rocker lever contact surface (area A) and valve stem contact surface (area B) for wear (refer to illustration).	Discard if excessively worn or if surface is damaged.
23. All other parts	a. Inspect for cracks, breaks, bends, excessive wear, and other damage.	Discard if damaged or worn.
	b. Inspect all threaded parts for stripped threads or cross-threading.	Discard any threaded parts that are stripped or cross-threaded.

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

22. INTAKE VALVE CROSSHEAD (2)
 23. FUEL CONNECTION (2)

28. EXHAUST VALVE CROSSHEAD (2)

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly and Testing


NOTE

Ensure all parts are clean prior to assembling.

24. Six new expansion plugs (10), new expansion plug (16), and two new expansion plugs (17)	<p>a. Apply a coat of cup plug sealant to expansion plugs and to inside diameter of water holes on cylinder head (9).</p> <p>b. Using drivers (57), install expansion plugs (10), (16), and (17) on cylinder head (9).</p>	<p>Use expansion plug drivers (3375190, 3375191, and 3375192) (56). If expansion plug drivers (57) are not available, use mandrel of correct size and ensure expansion plugs (10), (16), and (17) are installed even (flush) with, or not more than, 0.090 in. (2.286 mm) below chamfer (see illustration). Do not push expansion plugs to bottom of counterbore.</p>
25. Four pipe plugs (27)	<p>a. Coat threads of each pipe plug (27) with liquid thread sealant.</p> <p>b. Install two on each end of cylinder head (9).</p>	<p>No. 3 cylinder head has two pipe plugs (27) in forward end only. Tighten pipe plugs (27) to:</p>

<u>PLUG SIZE</u>	<u>TORQUE</u>
1/16 in.	3-6 lb-ft (4-8 N•m)
1/8 in.	5-10 lb-ft (7-14 N•m)
3/8 in.	35-45 lb-ft (48-61 N•m)
1/2 in.	60-70 lb-ft (81-95 N•m)
3/4 in.	65-75 lb-ft (88-102 N•m)
1 in.	135-145 lb-ft (183-197 N•m)

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- 9. CYLINDER HEAD
- 10. EXPANSION PLUG (6)
- 16. EXPANSION PLUG

- 17. EXPANSION PLUG (2)
- 27. PIPE PLUG (4)
- 57. EXPANSION PLUG DRIVER

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly and Testing (Contd)

NOTE

Step 26 does not apply to No. 2 cylinder head.

26. Cover plate (25) and two new preformed packings (24)	a. Install on cylinder head (9).	
	b. Secure with two screws (26).	
27. Four intake valves (13) and exhaust valves (14)	a. Dip valve stems into clean lubricating oil.	
	b. Install valves (13) or (14) on valve stem guides (18) from bottom side of cylinder head (9).	Ensure cylinder head is clean and valves are installed in their original locations as numbered in step 7. Ensure valve heads are fully seated on valve inserts (12) and (15).
28. Cylinder head (9)	Place on wooden bench or protective surface with machined surface down.	Wooden bench or protective surface will prevent damage to machined surface.

NOTE

A maximum of two 0.031 in. (0.794 mm) spacers may be used under lower valve spring guide when cylinder head has been resurfaced and valve seat has been reground. Do not use spacers to compensate for weak springs.


29. Eight upper valve spring guides (3), valve springs (4), and lower valve spring guides (5) (spacers (33) if necessary)	a. Place over valve stem guides (18) on cylinder head (9).	
	b. Compress valve springs (4) and install sixteen new valve collets (2) on stems of valves (13) and (14).	Use valve spring compressor (ST-448) (32) and head holding fixture (ST-583). Stud of valve spring compressor (32) should be installed on rocker lever screw hole (31).

NOTE

Ensure valves and valve seats are clean and dry.

30. Cylinder head assembly (1)	Check seal between valve (13) or (14) and valve seat as follows:	Use valve vacuum tester (ST-1257-A) (58).
	a. Select correct size vacuum cup for size of valve being tested.	
	b. Put vacuum cup over head of valve (13) or (14).	O-ring on vacuum cup must make seal on cylinder head (9) around valve (13) or (14). Grease can be applied to O-ring for a better seal.

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- 1. CYLINDER HEAD ASSEMBLY
- 2. VALVE COLLET (16)
- 3. VALVE SPRING GUIDE (8)
- 4. VALVE SPRING (8)
- 5. VALVE SPRING GUIDE (8)
- 9. CYLINDER HEAD
- 12. INTAKE VALVE INSERT (4)
- 13. INTAKE VALVE (4)
- 14. EXHAUST VALVE (4)

- 15. EXHAUST VALVE INSERT (4)
- 18. VALVE STEM GUIDE (8)
- 24. PREFORMED PACKING (2)
- 25. COVER PLATE
- 26. SCREW (2)
- 31. ROCKER LEVER SCREW HOLE
- 32. VALVE SPRING COMPRESSOR
- 33. SPACER
- 58. VALVE VACUUM TESTER

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly and Testing (Contd)

<p>30. Cylinder head assembly (1) (Contd)</p>	<p>c. Turn hand shutoff valve to open position and hold down push button to operate valve vacuum tester (58).</p> <p>d. Operate vacuum tester (58) until vacuum gauge indicates between 18 and 25 in. of vacuum.</p> <p>e. Record vacuum drop to determine satisfactory valve sealing.</p> <p>f. Tap stem end of valve (13) or (14) with soft-nose mallet and repeat vacuum test.</p> <p>g. Check for leaking connections in valve vacuum tester (58).</p> <p>h. Check for leaks between valve insert (12) or (15) and valve insert center bore in cylinder head (9).</p>	<p>Close hand shutoff valve and release push button to stop vacuum pump.</p> <p>1. Start timing as soon as gauge hand reaches 18 in. of vacuum. 2. Stop timing when gauge hand reaches 8 in. of vacuum. 3. If time is less than 10 seconds, valve seating is unsatisfactory. Perform step 30f if valve seating is unsatisfactory. Lapping valves is permissible, if necessary, to create an air-tight seal. Clean if necessary.</p> <p>1. Apply a coat of grease to outside diameter of insert to make a grade seal between insert and counterbore. 2. Vacuum test (refer to step 30d) and inspect grease seal. 3. If there is a break in grease seal, remove valve (13) or (14). Stake valve seat with valve seat insert staking tool (36) and driver (37).</p>
<p>31. Two adjusting screws (30) and nuts (29)</p> <p>32. Two adjusting screws (20) and nuts (21)</p> <p>33. Two exhaust valve crossheads (28) and intake valve crossheads (22)</p>	<p>Install on exhaust valve crossheads (28).</p> <p>Install on intake valve crossheads (22).</p> <p>Install on valve crosshead guides (8) on cylinder head (9).</p>	

NOTE


Step 34 is for M915/Big Cam I vehicles only.

<p>34. Plugpipes</p>	<p>Install all cylinder head pipe plugs and tighten to specifications shown below.</p>
----------------------	----------------------------------------------------------------------------------------

PIPE PLUG SIZE		MINIMUM		MAXIMUM	
INCH	(MM)	LB-FT	(N•m)	LB-FT	(N•m)
3/8	9.525	35	47	45	61
1/2	12.70	60	81	70	95
3/4	19	65	88	75	102
1	25	135	183	145	197

FOLLOW-ON TASK: Install cylinder head assembly (para. 3-71).

3-35. CYLINDER HEAD AND VALVE REPAIR (Contd)



LEGEND:

- | | |
|------------------------------|-------------------------------------------|
| 1. CYLINDER HEAD ASSEMBLY | 21. NUT (2) |
| 8. VALVE CROSSHEAD GUIDE (4) | 22. INTAKE VALVE CROSSHEAD (2) |
| 9. CYLINDER HEAD | 28. EXHAUST VALVE CROSSHEAD (2) |
| 12. INTAKE VALVE INSERT (4) | 29. NUT (2) |
| 13. INTAKE VALVE (4) | 30. ADJUSTING SCREW (2) |
| 14. EXHAUST VALVE (4) | 36. VALVE SEAT INSERT STAKING TOOL |
| 15. EXHAUST VALVE INSERT (4) | 37. VALVE SEAT INSERT STAKING TOOL DRIVER |
| 20. ADJUSTING SCREW (2) | 58. VALVE VACUUM TESTER |

3-36. VIBRATION DAMPER AND CRANKSHAFT PULLEY REPAIR

THIS TASK COVERS:

a. Cleaning

b. Inspection

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Solvent, SD-3 (Appendix C, Item 30)
 Developer, spotcheck, SKD-NF
 (Appendix C, Item 10)
 Cloth, emery, 290-grit (Appendix C, Item 5)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Vibration damper and crankshaft pulley removed (para. 3-14).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

- Always wear eye protection when working with compressed air.
- Use solvents away from flame and in well-ventilated area.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Cleaning

WARNING

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

1. Vibration damper (1) and crankshaft pulley (2)	Clean with solvent SD-3 and dry with compressed air.	Refer to para. 3-6 for additional cleaning instructions.
---------------------------------------------------	------------------------------------------------------	----------------------------------------------------------


b. Inspection

2. Crankshaft pulley (2)	Inspect for cracks, breaks, and other damage.	Discard if damaged.
3. Vibration damper (1)	a. Inspect for cracks, breaks, bends, and other damage.	Discard if damaged.

3-36. VIBRATION DAMPER AND CRANKSHAFT PULLEY REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
	b. Inspect for leaks as follows:	
	(1) Apply a spray of spotcheck developer.	
	(2) Put in oven heated to 200°F (93°C) for approximately 2 hours.	
	(3) Remove from oven when it reaches oven temperature.	Use protective gloves.
	(4) Inspect for oil leaks.	Discard if any leaks are found.
	c. Check thickness as follows:	
	(1) Using SD-3 solvent and 290-grit emery cloth, remove paint from four areas on each side.	Do not use coarse emery cloth or sharp tool to remove paint.
	(2) Measure thickness at four unpainted areas.	Use suitable micrometer. Measure approximately 0.125 in. (3.175 mm) from outside diameter of damper (1). Discard if difference between any two measurements is more than 0.010 in. (0.254 mm).

FOLLOW-ON TASK: Install vibration damper and crankshaft pulley (para. 3-79).



LEGEND:
 1. VIBRATION DAMPER
 2. CRANKSHAFT PULLEY

3-37. CRANKSHAFT REPAIR

THIS TASK COVERS:

a. Cleaning

b. Inspection

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Oil, lubricating, OE/HDO 30
(Appendix C, Item 21)
Solvent, SD-3 (Appendix C, Item 30)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Engine crankshaft and main bearings removed (para. 3-31).

SPECIAL ENVIRONMENTAL CONDITIONS

None

GENERAL SAFETY INSTRUCTIONS

- Compressed air used for cleaning purposes will not exceed 30 psi.
- Wear heat-resistant gloves when handling heated crankshaft gear.
- Use solvents away from flame and in well-ventilated area.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Cleaning

WARNING

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

CAUTION

Avoid heavy use of wire wheel or wire brush to clean rod bearing and main bearing journal surfaces. Failure to comply may result in an out-of-round condition to crankshaft journals.

1. Crankshaft (2)

Clean as follows:

a. Remove pipe plugs and clean all oil holes with nylon bristle brush soaked with SD-3 solvent.


Use SD-3 solvent to flush oil holes after cleaning.

b. Clean remaining surfaces with SD-3 solvent.

c. Dry with compressed air.

d. Install and tighten pipe plugs to 5 lb-ft (7 N•m).

3-37. CRANKSHAFT REPAIR (Contd)



LEGEND:

- 1. STANDARD MAIN BEARING SET
- 2. CRANKSHAFT
- 3. THRUST RING (4)
- 4. THRUST RING PIN (2)

- 5. RETAINING RING (7)
- 6. GEAR-TO-CRANKSHAFT KEY
- 7. CRANKSHAFT GEAR

3-37. CRANKSHAFT REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Cleaning (Contd)

NOTE

If inspection or installation of crankshaft will be performed later, coat all journal surfaces with a heavy film of OE/HDO 30 lubricating oil to prevent rust from forming.

- | | |
|------------------------------------------------------------------------------------------------------------------|---------------------------------------|
| 2. Standard main bearing set (1), seven retaining rings (5), four thrust rings (3), and two thrust ring pins (4) | Clean with SD-3 solvent and blow dry. |
|------------------------------------------------------------------------------------------------------------------|---------------------------------------|

b. Inspection

NOTE

Main bearings are provisioned as a set. If one main bearing half is not within specifications or is found to be defective, discard entire main bearing set.

- | | | |
|----------------------------------|------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| 3. Standard main bearing set (1) | Inspect each main bearing half for the following:

a. Pits, scratches, or grooves. | There are 14 main bearing halves to a standard main bearing set (1); inspect each half. Discard if pitted, scratched, or grooved. |
|----------------------------------|------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|

CAUTION

Never remove any metal from bearing shells to change oil clearance. After operation, a bearing shell that is fitted correctly will be gray. Light areas on shell indicate that metal is touching metal without enough oil clearance. Dark areas on shell indicate that the clearance is too large.

NOTE


Wear limits for undersized bearing halves may be determined by adding the correct amount (0.010 in. (0.254 mm), 0.020 in. (0.508 mm), and 0.030 in. (0.762 mm) to the minimum and maximum dimension of a standard bearing.

- | | | |
|-----------------------------|---------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 4. Four thrust rings (3) | b. Thickness of main bearing halves.

Measure thickness of each thrust ring (3) at different locations. | Use a micrometer that has a ball point. Minimum thickness is 0.123 in. (3.124 mm), maximum thickness is 0.1238 in. (3.144 mm), and wear limit is 0.1215 in. (3.0861 mm).

Prior to taking measurements, place crankshaft (2) on cylinder block with corresponding bearing halves and caps installed. A new crankshaft (2) and new thrust ring (3) will have an end clearance of 0.007-0.017 in. (0.179-0.432 mm). If the clearance exceeds 0.022 in. (0.559 mm), install oversize thrust rings (3). |
| 5. Two thrust ring pins (4) | Inspect for damage or wear. | Discard if damaged or worn. |

3-37. CRANKSHAFT REPAIR (Contd)



LEGEND:

- 1. STANDARD MAIN BEARING SET
- 2. CRANKSHAFT
- 3. THRUST RING (4)

- 4. THRUST RING PIN (2)
- 5. RETAINING RING (7)

3-37. CRANKSHAFT REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


b. Inspection (Contd)

NOTE

Perform step 6 for crankshaft dimensions and measurements for M915/Big Cam I only.

6. Crankshaft	<p>a. Measure crankshaft journals for wear (refer to Table 1). Journals worn out-of-round more than 0.002 in. (0.051 mm) will make it necessary to regrind crankshaft.</p> <p>b. Measure crankshaft thrust flange by checking dimensions (Table 1, No. 8). If wear does not exceed 0.003 in. (0.0762 mm) at any one point, flange condition is acceptable. If wear is 0.003 in. (0.0762 mm) or more, regrind flange to restore flatness.</p> <p>c. If total wear and regrinding does not exceed 0.005 in. (0.127 mm), standard thrust rings may be used.</p> <p>d. If worn more than 0.007 in. (0.1778 mm), flange should be ground for 0.010 or 0.020 in. (0.254 or 0.508 mm) oversize thrust rings or built up by electric arc welding and reground to specifications (Table 1, No. 8). Regrinding must clean up a minimum of 90 percent of thrust surface and result in maintaining an installed crankshaft end clearance below 0.015 in. (0.381 mm).</p> <p>e. Crankshafts with oversize thrust rings should be stamped on rear crankshaft counterweight. Both thrust ring size and ring location should be included in stamping. For example:</p> <p>Front 0.010 in. (0.254 mm) Rear 0.020 in. (0.508 mm)</p>	<p>Check crankshaft thrust flange at No. 7 main bearing for scoring, scratches, nicks, and breaks. If surface is scored or scratched, flange should be reground.</p>
---------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-37. CRANKSHAFT REPAIR (Contd)



1. 51.8125 IN. (1316.0375 MM)	9. 5.998-6.000 IN. (152.3492-152.4 MM)
2. 4.4965-4.500 IN. (114.262-114.3 MM)	10. 5.151-5.163 IN. (130.8354-131.1402 MM)
3. 2.4375 IN. (61.9125 MM)	11. 0.1728-0.1958 IN. (79.3369-79.375 MM)
4. 2.126-2.128 IN. (54.0004-54.0512 MM)	12. 3.1235-3.125 IN. (4.389-4.973 MM)
5. 2.000 IN. (50.8 MM)	13. 3.7607 IN. (95.5218 MM)
6. 2.500 IN. (63.5 MM)	14. 0.375 IN. (0.9525 MM)
7. 2.000 IN. (50.8 MM)	15. 3.625-3.626 IN. (92.075-93.0 MM)
8. 3.001-3.003 IN. (76.2254-76.2762 MM)	

TABLE 1. CRANKSHAFT DIMENSIONS AND POINTS OF MEASUREMENT

3-37. CRANKSHAFT REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Inspection (Contd)

f. Whenever structural damage to an engine has occurred, such as piston or valve breakage, a magnetic inspection should be performed on crankshaft as follows:

NOTE

Ampere turns in amperage flowing through coil are multiplied by number of turns in coil; the currents listed below are for 4-turn coil.

	DIRECTION OF DEFECT LONGITUDINAL	DIRECTION OF DEFECT CIRCUMFERENTIAL
DC or Rectified AC Equipment	1200 Amp 1400 Amp	3600-4000 amp turns 4200-4700 amp turns
Magnetizing Method	Head Shot	Coil Shot

g. Wet complete surface with magnetic particle suspension before applying currents.

h. Use the following directional magnetizing currents for crankshaft magnetic inspection or Magnaflux inspection:

i. Flow magnetic particle suspension over part in advance of placing part through coil.


Turn current on coil and move coil full length of part.

(1) If shaft parts are within 2 in. (5.1 cm) or 3 in. (7.6 cm) of the coil inside diameter, ample magnetism will be obtained if 3 shots of current are passed through coil at each end and center of part length.

(2) The limits of acceptability, unless otherwise stated, apply only to light slag or oxide stringers usually defined as inherent inclusions.

Obvious cracks and circumferential or transverse defects are not acceptable.

3-37. CRANKSHAFT REPAIR (Contd)



- | | |
|---------------------------------------------|---------------------------------------------------------------|
| 1. CRANKPIN WALL | 13. KNURLING |
| 2. CRANKPINS | 14. CHAMBER OF MAIN BEARING OIL HOLE |
| 3. CRANKPIN WALL | 15. MAIN BEARING JOURNAL SURFACES |
| 4. FILLETS-MAIN JOURNAL-DEEP | 16. COUNTERWEIGHT WELDS |
| 5. MAIN JOURNAL FILLETS | 17. WEBS |
| 6. CRITICAL REGION | 18. WEB SURFACES |
| 7. FILLET DEPTH | 19. CONNECTING ROD BEARING CRANKSHAFT JOURNAL SURFACES |
| 8. MAJOR AXIS OR CENTERLINE OF ADJACENT WEB | 20. CONNECTING ROD BEARING CRANKSHAFT JOURNAL SURFACE FILLETS |
| 9. JOURNAL SURFACE DEPTH | 21. WEB PERIPHERY |
| 10. JOURNAL SURFACE THICKNESS | 22. MAIN JOURNAL WALLS |
| 11. REAR SEAL SURFACE FACES | 23. FLANK CHEEK |
| 12. SEAL AREA | |

TABLE 2. CRANKSHAFT MAGNETIC INSPECTION

3-37. CRANKSHAFT REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Inspection (Contd)


7. Seven retaining rings (5)	Inspect for wear, out-of-round, or cracks.	Discard if worn, cracked, or out-of-round.
------------------------------	--------------------------------------------	--------------------------------------------

NOTE

It is unnecessary to remove crankshaft gear for inspection; remove only if excessively worn or damaged.

8. Crankshaft gear (7)	Inspect for the following: a. Worn, cracked, or broken gear teeth. b. Loose or worn keyway (9) in area of gear-to-crankshaft key (6). c. Remove from crankshaft (2). d. Buff all minor nicks and scratches using crocus cloth. e. Repair threads in threaded holes as required. f. If inspection shows crankshaft (2) is worn and must be reground and magnetic inspection reveals suitable for regrinding, grind crankshaft to next standard undersize.	Discard if cracked, worn, or broken. Refer to step 8c for removal. Remove. Refer to step 8c. Use a suitable puller and wrench. Remove only if necessary due to damage. Discard crankshaft gear (7) and gear-to-crankshaft key (6) after removal.
9. Crankshaft keyway (9)	Inspect only if gear (7) and key (6) are removed for the following: a. Looseness, wear, or damage. b. Width of keyway (9).	Discard crankshaft (2) or send to specialized repair station if worn, loose, or damaged in keyway (9) area. Discard crankshaft (2) or send to specialized repair station if width exceeds 0.375 in. (9.525 mm).
10. Crankshaft gear step (8)	Inspect for the following: a. Wear, grooves, or damage. b. Outside diameter should measure no less than 3.7607 in. (9.5522 cm).	Discard crankshaft (2), or send to specialized repair station, if worn, grooved, or damaged. Discard crankshaft (2), or send to specialized repair station, if outside diameter is less than 3.7607 in. (9.5522 cm).

3-37. CRANKSHAFT REPAIR (Contd)



LEGEND:

- 2. CRANKSHAFT
- 5. RETAINING RING (7)
- 6. GEAR-TO-CRANKSHAFT KEY

- 7. CRANKSHAFT GEAR
- 8. CRANKSHAFT GEAR STEP
- 9. CRANKSHAFT KEYWAY


3-37. CRANKSHAFT REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Inspection (Contd)

<p>11. Critical region (6), crankpin centerline (8), crankpin wall (1) and (3)</p>	<p>Limits listed in the following steps must be maintained within region C. Refer to Table 2.</p>	<p>Dimensional value of C is vertical distance measured downward from crankpin centerline (8) extending longitudinally for all webs (17) between crankpin walls (1) and (3).</p>
<p>12. Centerline (8), fillets (4), crankpin (2), main journal walls (22)</p>	<p>Indications located less than 1 in. (25 mm) from the major axis of centerline (8) of adjacent web (17) (measured circumferentially) must not exceed the following limits:</p> <p>a. Light indications in or entering fillets (4) are acceptable if not more than 0.125 in. (3.175 mm) long (open) or 0.250 in. (6.35 mm) long (subsurface).</p> <p>b. Light open indications on crankpin (2) and main journal walls (22) or bearing surface that extend closer than 0.125 in. (3.175 mm) to fillets (11), but do not enter fillets, are acceptable if 0.1875 in. (4.763 mm) long or less.</p>	<p>Light subsurface indications are acceptable.</p>
<p>13. Centerline (8), crankpin (2), main journal walls (22), fillets (4), corners of counterweight welds (16), webs (17), web periphery (21)</p>	<p>Indications located more than 1.00 in. (25.4 mm) from major axis or centerline (8) of adjacent web (17) (measure circumferentially) must not exceed following limits:</p> <p>a. Light open indication or entering fillets (4) are acceptable if 0.1875 in. (4.763 mm) long or less.</p> <p>b. Light open indications on crankpin (2) and main journal walls (22) or bearing surfaces that extend closer than 0.125 in. (3.175 mm) to fillet (11), but do not enter fillet, are acceptable if 0.250 in. (6.35 mm) or less.</p> <p>c. Nicks or sharp corners in counterweight welds (16) of webs (17) are not acceptable.</p> <p>d. Imperfections on web periphery (21) may be ground out to a depth of 0.125 in. (3.175 mm) maximum using a 1.50 in. (38.1 mm) minimum radius grinding wheel, provided balance limits are maintained.</p> <p>e. Light open indications that</p>	<p>Light subsurface indications are acceptable.</p> <p>Light subsurface indications are acceptable.</p> <p>Crankshaft will be acceptable if nicks can be removed by grinding a 0.125 in. (3.175 mm) radius on corner.</p> <p>All other subsurface</p>

3-37. CRANKSHAFT REPAIR (Contd)




- | | |
|---------------------------------------------|---------------------------------------------------------------|
| 1. CRANKPIN WALL | 13. KNURLING |
| 2. CRANKPIN | 14. CHAMBER OF MAIN BEARING OIL HOLE |
| 3. CRANKPIN WALL | 15. MAIN BEARING JOURNAL SURFACES |
| 4. FILLETS-MAIN JOURNAL-DEEP | 16. COUNTERWEIGHT WELDS |
| 5. MAIN JOURNAL FILLETS | 17. WEBS |
| 6. CRITICAL REGION | 18. WEB SURFACES |
| 7. FILLET DEPTH | 19. CONNECTING ROD BEARING CRANKSHAFT JOURNAL SURFACES |
| 8. MAJOR AXIS OR CENTERLINE OF ADJACENT WEB | 20. CONNECTING ROD BEARING CRANKSHAFT JOURNAL SURFACE FILLETS |
| 9. JOURNAL SURFACE DEPTH | 21. WEB PERIPHERY |
| 10. JOURNAL SURFACE THICKNESS | 22. MAIN JOURNAL WALLS |
| 11. REAR SEAL SURFACE FACES | 23. FLANK CHEEK |
| 12. SEAL AREA | |

TABLE 2. CRANKSHAFT MAGNETIC INSPECTION

3-37. CRANKSHAFT REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
b. Inspection (Contd)		
14. Chamber of main bearing oil hole (14)	<p>pass within 0.1875 in. (4.763 mm) of a crankpin wall (1) hole are acceptable if 0.50 in. (12.7 mm) long or less and does not enter oil hole chamfer or intersect 45° ± 10° diagonal. Only those subsurface indications that lay closer than 0.0625 in. (1.588 mm) to surface (measured at the chamfer at 45° + 10 diagonal) are not acceptable. Light open indications that enter chamfer of any chamber of main bearing oil hole (14) are acceptable if they are 3.125 in. (79 mm) or less. Subsurface indications ending in a main bearing oil hole (14) are acceptable.</p>	indications are acceptable.
15. Crankpin (2)	<p>Fine subsurface salt and pepper-type indications are permitted on upper and lower sides of crankpins (2) on the trimming line.</p>	
16. Main bearing journal surfaces (15) of crankpins (2)	<p>Open longitudinal indications within main bearing journal surfaces (15) which are less than 1.125 in. (29 mm) on main journals and 0.875 in. (22.225 mm) long on crankpins (2) are acceptable after sharp edges have been honed 0.002-0.004 in. (0.051-0.102 mm) below journal surface.</p>	
17. Main bearing journal surfaces (15) and connecting rod bearing crankshaft journal surfaces (19)	<p>Longitudinal surface indications within area (15) or (19) are acceptable.</p>	
18. Fillet (4)	<p>a. Parallel open indications that meet requirement of fillet (4) and other requirements on length and frequency are acceptable. b. Indications that contain loose or foreign particles or voids left by such particles are not acceptable.</p>	
19. Main bearing journal surfaces (15), crankpin (2), and fillet (4)	<p>a. Not more than three open indications are to appear on any one journal surfaces (15) or crankpin (2). Scattered small, open, or subsurface indications, four per crankpin (2), and six per main bearing journal surface (15), 0.125 in. (3.175 mm) long or less, if not forming part of a long intermittent indicator or entering an oil hole (1) or (14) or fillet (4), will not be counted as indications in arriving at the total number permitted. b. An inclusion which is</p>	<p>In addition to showing minimum number of acceptable indications for whole crankshaft, part also shows many widely scattered short indications, it must be rejected.</p>
19. Main bearing journal	<p>b. An inclusion which is</p>	

3-37. CRANKSHAFT REPAIR (Contd)



- | | |
|---------------------------------------------|---------------------------------------------------------------|
| 1. CRANKPIN WALL | 13. KNURLING |
| 2. CRANKPIN | 14. CHAMBER OF MAIN BEARING OIL HOLE |
| 3. CRANKPIN WALL | 15. MAIN BEARING JOURNAL SURFACES |
| 4. FILLETS-MAIN JOURNAL-DEEP | 16. COUNTERWEIGHT WELDS |
| 5. MAIN JOURNAL FILLETS | 17. WEBS |
| 6. CRITICAL REGION | 18. WEB SURFACES |
| 7. FILLET DEPTH | 19. CONNECTING ROD BEARING CRANKSHAFT JOURNAL SURFACES |
| 8. MAJOR AXIS OR CENTERLINE OF ADJACENT WEB | 20. CONNECTING ROD BEARING CRANKSHAFT JOURNAL SURFACE FILLETS |
| 9. JOURNAL SURFACE DEPTH | 21. WEB PERIPHERY |
| 10. JOURNAL SURFACE THICKNESS | 22. MAIN JOURNAL WALLS |
| 11. REAR SEAL SURFACE FACES | 23. FLANK CHEEK |
| 12. SEAL AREA | |

TABLE 2. CRANKSHAFT MAGNETIC INSPECTION


3-37. CRANKSHAFT REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Inspection (Contd)

surfaces (15), crankpin (2), and fillet (4) (Contd)	intermittently open to a subsurface shall be considered and measured as an open indication after original indication has been wiped off. The entire modification must first meet requirements for subsurface limits.	
	c. Open and subsurface indications on counterweights and crank throw bevel outside critical region are acceptable.	
20. Crankpin wall (1) and fillet (4)	Open seams on web periphery (21) that show visual depth on crankpin wall (1) may be removed from web periphery (21) with a 0.50 in. (12.7 mm) radius wheel, provided at least 0.0625 in. (1.588 mm) wall remains above crankpin fillet (4) after repair and balance limits are maintained.	
21. Crank web periphery (21)	Seams or indications outside the critical region (6) that extend over crank web periphery (21) but are not visible on crankpin wall are acceptable.	
22. Corner of flank cheek (23)	<p>a. Indications due to weld defects are not acceptable in counterweight welds. Indications at corner of flank cheek (23) may be ground out and blended to a depth not exceeding 0.25 x 0.625 in. (0.635 x 1.588 cm) long.</p> <p>b. Open longitudinal indications in flywheel and thrust flange fillets longer than 0.375 in. (9.525 mm) are not acceptable.</p> <p>c. Limits of indications on the oil seal surface which, when wiped clean to not show sharp edges, are acceptable.</p> <p>d. After inspection where coil shot is used, give crankshaft head shot to put magnetic poles at ends of crank, not throws. The residual magnetic field should not exceed two units on magnaflux indication or equal.</p>	

3-37. CRANKSHAFT REPAIR (Contd)



- | | |
|---------------------------------------------|---------------------------------------------------------------|
| 1. CRANKPIN WALL | 13. KNURLING |
| 2. CRANKPIN | 14. CHAMBER OF MAIN BEARING OIL HOLE |
| 3. CRANKPIN WALL | 15. MAIN BEARING JOURNAL SURFACES |
| 4. FILLETS-MAIN JOURNAL-DEEP | 16. COUNTERWEIGHT WELDS |
| 5. MAIN JOURNAL FILLETS | 17. WEBS |
| 6. CRITICAL REGION | 18. WEB SURFACES |
| 7. FILLET DEPTH | 19. CONNECTING ROD BEARING CRANKSHAFT JOURNAL SURFACES |
| 8. MAJOR AXIS OR CENTERLINE OF ADJACENT WEB | 20. CONNECTING ROD BEARING CRANKSHAFT JOURNAL SURFACE FILLETS |
| 9. JOURNAL SURFACE DEPTH | 21. WEB PERIPHERY |
| 10. JOURNAL SURFACE THICKNESS | 22. MAIN JOURNAL WALLS |
| 11. REAR SEAL SURFACE FACES | 23. FLANK CHEEK |
| 12. SEAL AREA | |

TABLE 2. CRANKSHAFT MAGNETIC INSPECTION

3-37. CRANKSHAFT REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


b. Inspection (Contd)

CAUTION

When repairing threads, be careful not to cause damage to crankshaft oil seal area.

23. Crankshaft (2)	Inspect for the following:	
	a. Cracks, breaks, damage, or wear.	Discard if cracked, broken, damaged, or worn.
	b. Surface scratches or burrs.	Remove with fine-grit emery cloth.
	c. Damaged or distorted threads at front and/or rear.	Repair with suitable thread chaser.
	d. Grooved or worn rear oil seal contact area (10) or front oil seal contact area (11). repair station.	Clean with fine-grit emery cloth. If unable to remove groove, send crankshaft (2) to a specialized repair station.
	e. Outside diameter of rear oil seal contact area (10) is 5.998-6.000 in. (152.349-152.4 mm).	Discard crankshaft (2) or send to specialized repair station if rear oil seal contact area (10) is not within stated range.
	f. Outside diameter of front oil seal contact area (11) is 3.625-3.626 in. (92.075-92.100 mm).	Discard crankshaft (2) or send to specialized repair station if front oil seal contact area (11) is not within stated range.
	g. Rod bearing journal diameter (13) is a minimum diameter of 3.1235 in. (79.337 mm) up to a maximum diameter of 3.125 in. (79.375 mm). Measure at three and six o'clock position.	Measure six rod bearing journal diameters (13). Discard crankshaft (2) or send to a specialized repair station if any of six rod bearing journal diameters (13) are less than 3.122 in (79.299 mm).
	h. Main bearing journal diameter (12) is a minimum diameter of 4.4985 in. (114.262 mm) up to a maximum diameter of 4.500 in. (114.3 mm). Measure at three and six o'clock position. Wear limit is 4.4975 in. (114.237 mm).	Measure seven main bearing journal diameters (12). Discard crankshaft (2) or send to a specialized repair station if any of the seven main bearing journal diameters (12) are less than 4.4975 in. (114.237 mm).

3-37. CRANKSHAFT REPAIR (Contd)



LEGEND:

- 2. CRANKSHAFT
- 6. GEAR-TO-CRANKSHAFT KEY
- 7. CRANKSHAFT GEAR
- 8. CRANKSHAFT GEAR STEP
- 9. CRANKSHAFT KEYWAY

- 10. REAR OIL SEAL CONTACT AREA
- 11. FRONT OIL SEAL CONTACT AREA
- 12. MAIN BEARING JOURNAL DIAMETER
- 13. ROD BEARING JOURNAL DIAMETER

3-37. CRANKSHAFT REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Inspection (Contd)

24. New crankshaft gear (7)
removed only if damaged

Install as follows:

- a. Install new gear-to-crankshaft key (6) on crankshaft keyway (9).

WARNING

Wear heat-resistant gloves when handling heated crankshaft gear. Failure to comply may result in injury to personnel.

CAUTION

Use caution when heating crankshaft gear. Make sure there is equal distribution of heat in oven. Do not let crankshaft gear become overheated. Overheating will change hardness of crankshaft.

- b. Heat new crankshaft gear (7) in oven at 400°F (204°C) for at least one hour. Then remove using heat-resistant gloves.

NOTE

The crankshaft gear must be installed with timing mark facing out.


- c. Liberally lubricate crankshaft gear step (8) of crankshaft (2) with OE/HDO 30 lubricating oil.
- d. Align keyway on crankshaft gear (7) with new gear-to-crankshaft key (6) on crankshaft (2).
- e. Drive crankshaft gear (7) on crankshaft gear step (8) with a piece of tubing.

Wear heat-resistant gloves similar to welding gloves when handling hot crankshaft gear (7).

Tubing should have an inside diameter corresponding to outside diameter of crankshaft gear step (8).

FOLLOW-ON TASK: Install engine crankshaft and main bearings (para. 3-68).

3-37. CRANKSHAFT REPAIR (Contd)



LEGEND:

- 2. CRANKSHAFT
- 6. GEAR-TO-CRANKSHAFT KEY
- 7. CRANKSHAFT GEAR

- 8. CRANKSHAFT GEAR STEP
- 9. CRANKSHAFT KEYWAY

3-38. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER REPAIR

THIS TASK COVERS

a. Cleaning

b. Inspection

INITIAL SETUP:

APPLICABLE MODELS

All

Automotive repairman MOS 63H

PREFERENCES (TM)

None

SPECIAL TOOLS

None

TROUBLESHOOTING REFERENCES

Para. 2-8

SPECIAL TOOLS

Magnetic crack detector, ST-1166

EQUIPMENT CONDITION

Flexplate or flywheel, flywheel housing, and rear cover removed (para. 3-25).

TEST EQUIPMENT

None

MATERIALS/PARTS

Solvent, SD-3 (Appendix C, Item 30)

Rear main seal (15434) 211253 (Big Cam III only)

Rear main seal (15434) 3006738 (Big Cam I only)

Rear cover gasket (15434) 40662-A

SPECIAL ENVIRONMENTAL CONDITIONS

None

GENERAL SAFETY INSTRUCTIONS

- Wear protective equipment when cleaning with compressed air.

PERSONNEL REQUIRED

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

- Use approved solvent in well-ventilated area.

a. Cleaning

WARNING

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

1. All parts	Clean with SD-3 solvent and dry with compressed air.	Scrape off any remaining gasket material from mating surfaces.
--------------	------------------------------------------------------	----------------------------------------------------------------


b. Inspection

NOTE

- Perform step 2 for M915/Big Cam I only.
- Perform step 3 for M915A1/Big Cam III only.

2. Flywheel (4) and spacer gear (5)	Inspect for distortion, cracks, and damaged gear teeth.	Use magnetic crack detector (ST-1166). Discard if distorted, cracked, or gear teeth are damaged.
3. Flexdisk and ring gear (7)	Inspect for the following:	

3-38. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER REPAIR
(Contd)



LEGEND:

- 1. REAR COVER (M915/BIG CAM I), COVER (M915A1/BIG CAM III)
- 2. FLYWHEEL INDEX HOLE COVER
- 3. FLYWHEEL HOUSING
- 4. FLYWHEEL (M915/BIG CAM I)

- 5. SPACER GEAR (M915/BIG CAM I)
- 6. WASHER BEARING
- 7. FLEXPLATE AND RING GEAR (M915A1/BIG CAM III)
- 8. RETAINING PLATE
- 9. DOWEL (2)

3-38. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER REPAIR (Contd)


LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Inspection (Contd)

	a. Distortion.	Discard if distorted.
3. Flexdisk and ring gear (7) (Contd)	b. Cracks in capscrew mounting area.	Use (ST-1166) magnetic crack detector. Discard if cracked.
	c. Inspect for distortion, cracks, and cracked or chipped gear teeth.	Use magnetic crack detector (ST-1166). Discard if distorted, cracked, or gear teeth are damaged.
4. Flywheel housing (3)	Inspect for the following:	
	a. Cracks.	Discard if cracked.
	b. Mating surfaces are clean and free from damage.	
	c. Damaged or distorted threads.	Repair stripped threads with suitable thread chaser or thread inserts.
5. Flywheel index hole cover (2)	Inspect for distortion or cracks.	Discard if cracked or distorted.
6. Two dowels (9)	Inspect for damaged surface or damaged threads.	Discard if damaged or distorted.
7. Rear cover (1) (M915/Big Cam I) or cover (1) (M915A1/Big Cam III)	Inspect for the following:	
	a. Cracks in mounting area.	Discard if cracked.
	b. Damage or cracks in surface area of rear cover gasket and area of rear main seal.	Discard if damaged or cracked.
	c. Worn holes in area of two dowels (9).	Discard if worn.
8. All mounting hardware	Inspect for stretched or damaged threads.	Discard if damaged.

FOLLOW-ON TASK: Install flexplate or flywheel, flywheel housing, and rear cover (para. 3-80).

3-38. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER REPAIR
(Contd)



LEGEND:

- 1. REAR COVER (M915/BIG CAM I), COVER (M915A1/BIG CAM III)
- 2. FLYWHEEL INDEX HOLE COVER
- 3. FLYWHEEL HOUSING
- 4. FLYWHEEL (M915/BIG CAM I)

- 5. SPACER GEAR (M915/BIG CAM I)
- 6. WASHER BEARING
- 7. FLEXPLATE AND RING GEAR (M915A1/BIG CAM III)
- 8. RETAINING PLATE
- 9. DOWEL (2)

3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR

THIS TASK COVERS:

- | | |
|---------------------------------------|--------------------------------------|
| <p>a. Disassembly
b. Cleaning</p> | <p>c. Inspection
d. Assembly</p> |
|---------------------------------------|--------------------------------------|

INITIAL SETUP:

APPLICABLE MODELS

All

Automotive repairman MOS 63H

SPECIAL TOOLS

- Connecting rod bushing driver (15434) ST-1242
- Connecting rod checking fixture (15434) ST-561
- Connecting rod locating mandrel (15434) ST-563
- Piston ring groove gauge (15434) ST-560

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Piston, connecting rod, and bearings removed (para. 3-69).

TEST EQUIPMENT

None

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

MATERIALS/PARTS

Cloth, crocus (Appendix C, Item 4)

GENERAL SAFETY INSTRUCTIONS

PERSONNEL REQUIRED

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Wear rubber gloves when removing piston pin to prevent burns from boiling water or hot piston.

NOTE

Use this procedure to repair any one of six piston, connecting rod, and bearing assemblies. Quantities shown in legend are for one piston, connecting rod, and bearing assembly.

a. Disassembly

- | | | |
|----|------------------------------------|-------------------------|
| 1. | Two piston pin retaining rings (3) | Remove from piston (1). |
|----|------------------------------------|-------------------------|

WARNING


Wear rubber gloves when removing piston pin to prevent burns from boiling water or hot piston. Failure to comply may result in injury to personnel.

CAUTION

To avoid damage to piston, do not use hammer or any other tool to remove piston pin.

- | | | | |
|----|---------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------|
| 2. | Piston pin (2) and connecting rod (5) | <p>a. Heat piston (1) 210°F (98.9°C) for 10 minutes in boiling water or oven.</p> <p>b. Push piston pin (2) from piston (1) and connecting rod (5) with</p> | Use tongs or hook to remove piston from hot water. |
|----|---------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------|

3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR (Contd)



LEGEND:

- | | |
|----------------------------------|-----------------------------|
| 1. PISTON | 6. CONNECTING ROD DOWEL (2) |
| 2. PISTON PIN | 7. CONNECTING ROD CAP |
| 3. PISTON PIN RETAINING RING (2) | 8. ROD SCREW (2) |
| 4. CONNECTING ROD ASSEMBLY | 9. ROD BUSHING |
| 5. CONNECTING ROD | 10. ROD BEARING HALF (2) |

3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)

fingers.

NOTE

Prior to performing steps 3 and 4, clean and inspect rod bushing and connecting rod dowels (steps 6, 16, and 18). Do not remove rod bushing or connecting rod dowels unless they are damaged or not within wear limits.

3. Rod bushing (9)	Using connecting rod bushing driver (ST-1242) (11), remove from connecting rod (5).	New bushing requires boring out of inside diameter.
4. Two connecting rod dowels (6)	Pull out of connecting rod cap (7).	

b. Cleaning

CAUTION

Do not exceed water boiling point 212°F (100°C) when heating piston during cleaning. Piston skirt is coated with plating that may blister if overheated.

5. Piston (1)	Clean.	Use solvent-cleaning bath that will not attack aluminum, or blast suitable material that will embed in or remove material from piston (1). Refer to para. 3-6 for additional cleaning instructions.
6. Piston pin (2), two retaining rings (3), connecting rod assembly (4), and two rod bearing halves (10)	Clean.	Refer to para. 3-6 for cleaning information and instructions. Do not remove dowels from connecting rod cap or rod bushing from connecting rod during cleaning.

c. Inspection


7. Piston (1) and piston pin (2)	Check for cracks, breaks, scoring, galling, and scratches. Small scratches may be removed with crocus cloth.	Discard if damaged.
8. Piston (1)	a. Inspect all ring grooves for missing sections, breaks, cracks, distortion, and galling.	Discard if damaged.

NOTE

There are two ways to check piston ring grooves. If using piston ring groove gauge ST-560, perform step 8b. If piston ring groove gauge ST-560 is not available, perform step 8c.

b. Using No. 2 piston ring groove gauge (12), check top and second ring grooves.	Ensure ring grooves are clean. Discard piston (1) if shoulder's widest part of guide touches it.
c. Hold segment of new piston ring (13) in ring groove, and insert 0.006 in. (0.15 mm) feeler	Ensure ring grooves are clean. Discard piston (1) if gauge enters groove force or disengaging ring.

3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR (Contd)



LEGEND:

- 1. PISTON
- 2. PISTON PIN
- 3. PISTON PIN RETAINING RING (2)
- 4. CONNECTING ROD ASSEMBLY
- 5. CONNECTING ROD
- 6. CONNECTING ROD DOWEL (2)
- 7. CONNECTING ROD CAP

- 8. ROD SCREW (2)
- 9. ROD BUSHING
- 10. ROD BEARING HALF (2)
- 11. CONNECTING ROD BUSHING DRIVER
- 12. PISTON RING GROOVE GAUGE
- 13. PISTON RING

3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

gauge.

8. Piston (1) (Contd)

d. Using suitable micrometer, measure piston skirt diameter at angles to piston pin bore.

Ensure temperature is between 70-90°F (21-32°C). Take measurements at points A, B, and C. Discard if not within limits shown below:


	MINIMUM	MAXIMUM
Point A	5.477 in (139.116 mm)	5.480 in. (139.192 mm)
Point C	5.489 in. (139.421 mm)	5.493 in. (139.522 mm)

e. Using suitable micrometer, measure piston pin bore.

Ensure temperature is between 70-90°F (21-32°C). Take measurement in area D. Discard if more than wear limit shown below at 70°F (21°C): Add 0.0005 in. (0.013 mm) per 10°F (-12°C) up to 90°F (32C).

Wear Limit	2.0000 in. (50.800 mm)
New Minimum	1.9985 in. (50.762 mm)
New Maximum	1.9990 in. (50.775 mm)

3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR (Contd)



LEGEND:
1. PISTON


3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

9. Piston pin (2)	Using suitable micrometer, measure outside diameter.	Discard if out-of-round more than 0.001 in. (0.025 mm), or if less than wear shown below:
	Wear Limit 1.9985 in. (50.762 mm)	
	New Minimum 1.9988 in. (50.769 mm)	
	New Maximum 1.9990 in. (50.775 mm)	
10. Connecting rod (5) and connecting rod cap (7)	Inspect surface area for nicks, dents, and gouges.	Discard all connecting rods (5) that have cuts, scratches, or other damage that is deeper than approximately 0.03125 in. (0.7938 mm) on I-beam.
11. Connecting rod (5), connecting rod cap (7), and two rod screws (8)	<p>a. Assemble.</p> <p>b. Inspect for cracks using magnetic method:</p> <p>(1) Check rods (5) for cracks using 1800 ampere AC current or 1500 ampere DC current applied longitudinally between plates.</p> <p>(2) Check rods (5) for cracks using 3000-3400 ampere AC or current 2600-2800 ampere turns DC.</p>	<p>Refer to step 19 and accompanying Illustrations with torque values.</p> <p>Apply 1-1/2 percent wet solution while current is on. Make visual inspection after each application of current. Pay particular attention to shaded critical areas shown in illustration. Discard connecting rod assembly (4) if any cracks are detected.</p>

3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR (Contd)



LEGEND:

- 2. PISTON PIN
- 4. CONNECTING ROD ASSEMBLY
- 5. CONNECTING ROD
- 7. CONNECTING ROD CAP
- 8. ROD SCREW (2)

3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


c. Inspection (Contd)

12. Two rod screws (8)	a. Inspect for distorted threads. b. Using suitable micrometer, measure smallest diameter.	Discard if threads are distorted. Discard if less than wear limit shown below:
Thread O.D. Wear Limit 0.540 in. Pilot O.D. Wear Limit 0.6242 in. (13.72 mm) (15.855 mm)		(Refer to item 8 in figure.)
New Minimum 0.541 in 0.6245 in. (13.74 mm) (15.862 mm)		
New Maximum 0.545 in 0.6250 in. (13.84 mm) (15.875 mm)		
13. Connecting rod (5)	Using suitable micrometer, measure pilot bore of holes for rod screws (8).	Discard connecting rod assembly (4) if pilot bore is more than 0.6252 in. (15.880 mm).



NOTE
See Appendix F for screw pilot outside diameter.

14. Connecting rod cap (7)	Using suitable micrometer, measure pilot bore of holes for rod screws (8).	Discard connecting rod assembly (4) if pilot bore is more than 0.6252 in. (15.880 mm).
15. Two connecting rod dowels (6)	a. Inspect for cracking and bending. b. Using suitable micrometer, measure diameter. c. Using suitable micrometer, measure protrusion.	Remove and discard if cracked or bent. Install new connecting rod dowels (6) if needed. Remove and discard if less than 0.3127 in. (7.943 mm). Install new connecting rod dowels (6) if needed. Remove and discard if not within limits shown below. Install new connecting rod dowels (6) if needed.
	New Minimum 0.220 in. (5.588 mm) New Maximum 0.250 in. (6.35 mm)	
16. Connecting rod (5)	Using suitable micrometer, measure diameter of dowel holes (11).	Discard connecting rod assembly (4) if not within limits shown below:
	New Minimum 0.3128 in. (7.946 mm) New Maximum 0.3133 in. (7.957 am)	
17. Rod bushing (9)	a. Inspect for nicks, gouges, and scoring. b. Using suitable micrometer, measure inside diameter.	Remove and discard if nicked, gouged or scored. Install new rod bushing (9) if needed. Remove and discard if less than wear limit shown below. Install new rod bushing (9) if needed.
	Wear Limit 2.0022 in. (50.856 mm) New Minimum 2.0010 in. (50.825 mm) New Maximum 2.0015 in. (50.838 mm)	
18. Connecting rod (5) and connecting rod cap (7)	a. Assemble. b. Secure with two rod stews (8).	Ensure connecting rod dowels (6) fit into dowel holes (11) in connecting rod (5). Alternately tighten screws (8) In order aid sequence shown in illustration.

3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR (Contd)



- (1) TIGHTEN (8) TO 70-75 LB-FT (95-102 N•m)
- (2) ADVANCE (8) TO 140-150 LB-FT (190-203 N•m)
- (3) LOOSEN ALL COMPLETELY
- (4) TIGHTEN (8) TO 25-30 LB-FT (34-41 N•m)
- (5) ADVANCE (8) TO 70-75 LB-FT (95-102 N•m)
- (6) ADVANCE (8) TO 140-150 LB-FT (190-203 N•m)



LEGEND:

- 4. CONNECTING ROD ASSEMBLY
- 5. CONNECTING ROD
- 6. CONNECTING ROD DOWEL (2)
- 7. CONNECTING ROD CAP
- 8. ROD SCREW (2)
- 9. ROD BUSHING
- 10. ROD BEARING HALF (2)
- 11. DOWEL HOLES

3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
c. Inspection (Contd)		
19. Connecting rod assembly (4)	Using suitable micrometer, measure crankpin bore diameter.	Do not measure where connecting rod (5) and connecting rod cap (7) meet. Discard if diameter is not within 3.3157 in. (84.219 mm) and 3.3171 in. (84.254 mm) up to 30° on either side of parting line, 3.3157 in. (84.219 mm) and 3.3167 in. (84.244 mm) 30° on either side of parting line.
20. Connecting rod checking fixture (ST-561) (14)	Calibrate.	<p>a. Use new connecting rod assembly (4) that has been checked for correct absolute center length of 12.00 in. (304.8 mm) between bore centers.</p> <p>b. Perform steps 18a and b.</p> <p>c. Place new connecting rod assembly (4) into fixture.</p> <p>d. Place correct piston pin mandrel (15) into piston pin bore.</p> <p>e. Install expanding arbor (16) into crankpin bore and tighten until snug. Ensure pin on expanding arbor (16) is down and locked in position in center of new connecting rod assembly (4).</p> <p>f. Move dial holder until contact points of indicators touch mandrel (15) in piston pin bore.</p> <p>g. Set indicator dials' checking fixture to zero.</p> <p>h. Remove new connecting rod assembly (4) from fixture. Turn rod assembly horizontally 180° and put back into fixture (14).</p> <p>i. If dial indicators show any change from first reading, adjust dials to divide difference. Fixture is now calibrated.</p>
21. Connecting rod (5)	<p>a. Assemble correct connecting rod assembly (4), pin mandrel (15), and expanding arbor (16).</p> <p>b. Put into calibrated connecting rod checking fixture (14).</p> <p>c. Take reading for length.</p> <p>d. Take reading for alignment of of bores. Turn connecting rod assembly (4) 180° and take reading again.</p>	Discard if longer than rod used to calibrate fixture or more than 0.002 in. (0.050 mm) shorter. Discard if difference in readings is more than 0.010 in. (0.254 mm) without bushing (9) installed, or 0.004 in. (0.101 mm) with rod bushing (9) installed.


3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

21. Connecting rod (5) (Contd)

e. Using feeler gauge between piston pin mandrel (15) and dial indicator holding plate, measure twist.

Discard if twist is more than 0.020 in. (0.508 mm) without bushing (9) installed, or 0.010 in. (0.254 mm) bushing (9) installed and machined to correct size.



LEGEND:

- 4. CONNECTING ROD ASSEMBLY
- 5. CONNECTING ROD
- 7. CONNECTING ROD CAP
- 9. ROD BUSHING
- 14. CONNECTING ROD CHECKING FIXTURE
- 15. PISTON PIN MANDREL
- 16. EXPANDING ARBOR

3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

CAUTION

If one rod bearing half is damaged or worn, both rod bearing halves must be discarded. Failure to do so could cause damage to equipment.

NOTE

Undersize bearing shells can be determined by adding correct amount 0.010, 0.020, 0.030 in. (0.254, 0.508, 0.762 mm) to minimum and maximum dimension of a standard bearing.

22. Rod bearing half (10)	a. Inspect for chipping, flaking, or scoring. b. Using suitable ballpoint micrometer, measure thickness.	Discard both if chipped, flaked, or scored. Discard both if less than wear limit of standard connecting rod bearing half (10) as shown below:
---------------------------	-------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------

Wear Limit	0.0930 in. (2.362 mm)
New Minimum	0.0942 in. (2.392 mm)
New Maximum	0.0947 in. (2.405 mm)

d. Assembly

23. Rod bushing (9)	Using connecting rod bushing driver (ST-1242) (11), install into connecting rod (5).	Ensure oil holes are aligned and that a 0.125 in. (3.175 mm) diameter rod can move freely through connecting rod (5) and rod bushing (9).
24. Two connecting rod dowels (6)	Install into connecting rod cap (7).	
25. Piston pin retaining ring (3)	Install only one retaining ring (3) into groove of piston pin bore in piston (1).	

WARNING

Wear rubber gloves when installing piston pin to prevent burns from boiling water or hot piston. Failure to comply may result in injury to personnel.

26. Piston (1) and piston pin (2)	a. Heat piston (1) for 15 minutes in boiling water or in oven set at 210°F (100°C).
-----------------------------------	-------------------------------------------------------------------------------------


CAUTION

Never use a hammer to install piston pin. This can cause distortion in piston and piston seizure in cylinder liner. Ensure edges of piston pin retaining rings are in groove of piston pin bore.

b. Install connecting rod (5) and piston pin (2) into piston (1) before it cools to 70°F (21°C). c. Install other piston pin retaining ring (3) in groove of piston pin bore in piston (1), opposite the one installed in step 25.	The piston pin (2) cannot be installed when temperature of piston (1) is below 70°F (21°C).
---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------

FOLLOW-ON TASK: Install piston, connecting rod, and bearings (para. 3-69).

3-39. PISTON, CONNECTING ROD, AND BEARING REPAIR (Contd)



LEGEND:

- 1. PISTON
- 2. PISTON PIN
- 3. PISTON PIN RETAINING RING (2)
- 5. CONNECTING ROD
- 6. CONNECTING ROD DOWEL (2)

- 7. CONNECTING ROD CAP
- 9. ROD BUSHING
- 10. ROD BEARING HALF
- 11. CONNECTING ROD BUSHING DRIVER

3-40. CAMSHAFT, CAM FOLLOWER, AND PUSHROD REPAIR

THIS TASK COVERS:

- | | |
|---------------------------------------|--------------------------------------|
| <p>a. Disassembly
b. Cleaning</p> | <p>c. Inspection
d. Assembly</p> |
|---------------------------------------|--------------------------------------|

INITIAL SETUP:

APPLICABLE MODELS
All

SPECIAL TOOLS
None

TEST EQUIPMENT
None

MATERIALS/PARTS
Compound, Prussian blue (Appendix C, Item 9)
Paper, aluminum oxide, 240-grit
(Appendix C, Item 23)
Sealant, cup plug (Appendix C, Item 25)
Six expansion plugs (15434) 175831

PERSONNEL REQUIRED
Automotive repairman MOS 63H

REFERENCES (TM)
None

TROUBLESHOOTING REFERENCES
Para. 2-8

EQUIPMENT CONDITION

- Pushrods removed (para. 3-22).
- Camshaft and cam follower housings removed (para. 3-28).

SPECIAL ENVIRONMENTAL CONDITIONS
Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS
Always wear eye protection when working with compressed air.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly

CAUTION

Do not use heating torch to remove camshaft gear from camshaft if camshaft gear is to be reused. Heating will damage camshaft gear.

NOTE

Prior to step 1, clean and inspect camshaft and camshaft gear (steps 6, 8, and 9). Do not separate camshaft and camshaft gear unless damaged or not within wear limits.


- | | | |
|-----------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|
| <p>1. Camshaft(5)</p> | <p>a. Put in press.
b. Put V-blocks under camshaft gear (2).
c. Using press, remove camshaft gear (2).
d. Remove gear-to-camshaft key (4).</p> | <p>Ensure V-blocks support hub area of camshaft gear (2).</p> |
| <p>2. Camshaft orifice plug (1) and thrust washer (3)</p> | <p>Remove from camshaft (5).</p> | |

NOTE

Repeat steps 3, 4, and 5 for each cam follower assembly.

- | | |
|-----------------------------------------|-----------------------------------------------|
| <p>3. Two shaft locking screws (10)</p> | <p>Remove from cam follower housing (13).</p> |
|-----------------------------------------|-----------------------------------------------|

3-40. CAMSHAFT CAM FOLLOWER, AND PUSHROD REPAIR (Contd)



LEGEND:

- | | |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> 1. CAMSHAFT ORIFICE PLUG 2. CAMSHAFT GEAR 3. THRUST WASHER 4. GEAR-TO-CAMSHAFT KEY 5. CAMSHAFT 6. INTAKE AND EXHAUST PUSHROD (12) 7. INJECTOR PUSHROD (6) | <ul style="list-style-type: none"> 8. INTAKE AND EXHAUST CAM FOLLOWER (12) 9. INJECTOR CAM FOLLOWER (6) 10. SHAFT LOCKING SCREW (6) 11. EXPANSION PLUG (6) 12. CAM FOLLOWER SHAFT (6) 13. CAM FOLLOWER HOUSING (3) |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

3-40. CAMSHAFT CAM FOLLOWER, AND PUSHROD REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)

4. Two expansion plugs (11)	Remove from ends of cam follower housing (13).	Use punch with sharp point to make hole in center of one expansion plug (11). Hit edge of same expansion plug to loosen it. Using pliers, remove expansion plug (11). Discard expansion plug (11).
5. Two cam follower shafts (12)	Push out of cam follower housing (13) and remove four intake and exhaust cam followers (8) and two injector cam followers (9).	Mark intake, exhaust, and injector cam followers (8) and (9) to identify their location in cam follower housing (13) as they are removed. Using mandrel and press, push both cam follower shafts (12) out opposite end of cam follower housing (13), forcing out other expansion plug (11). Discard expansion plug (11).

b. Cleaning

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.

6. Camshaft orifice plug (1), camshaft gear (2), thrust washer (3), gear-to-camshaft key (4), and camshaft (5) (assembled)	Steam clean and dry with compressed air.	Refer to para. 3-6 for additional cleaning instructions.
----------------------------------------------------------------------------------------------------------------------------	------------------------------------------	----------------------------------------------------------

NOTE


Repeat step 7 for each cam follower and pushrod assembly.

7. Six intake, exhaust, and injector pushrods (6) and (7), intake exhaust and injector cam followers (8) and (9), shaft locking screws (10), cam follower shafts (12), and three cam follower housings (13)	Clean.	Refer to para. 3-6 for cleaning information and instructions. Be sure to clean out small oil passages in cam followers, and ensure all gasket material has been removed from cam follower housing (13).
-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

c. Inspection

8. Camshaft (5)	a. Using suitable micrometer, measure diameter of journals. Wear Limit 2.495 in. (63.373 mm) New Minimum 2.496 in. (63.398 mm) New Maximum 2.497 in. (63.423 mm)	Disassemble and discard camshaft if less than wear limit shown below: Disassemble and discard camshaft (5) if lobes are scuffed, scored, or cracked.
	b. inspect injector and valve lobes for scuffing, scoring, and cracks.	

3-40. CAMSHAFT, CAM FOLLOWER, AND PUSHROD REPAIR (Contd)



LEGEND:

- | | |
|------------------------------------|-----------------------------------------|
| 1. CAMSHAFT ORIFICE PLUG | 8. INTAKE AND EXHAUST CAM FOLLOWER (12) |
| 2. CAMSHAFT GEAR | 9. INJECTOR CAM FOLLOWER (6) |
| 3. THRUST WASHER | 10. SHAFT LOCKING SCREW (6) |
| 4. GEAR-TO-CAMSHAFT KEY | 11. EXPANSION PLUG (6) |
| 5. CAMSHAFT | 12. CAM FOLLOWER SHAFT (6) |
| 6. INTAKE AND EXHAUST PUSHROD (12) | 13. CAM FOLLOWER HOUSING (3) |
| 7. INJECTOR PUSHROD (6) | |

3-40. CAMSHAFT CAM FOLLOWER, AND PUSHROD REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

8. Camshaft (5) (Contd)

c. Inspect for cracks using magnetic method. Apply 1500 amperes DC longitudinal magnetic current for locating open seams and presence of non-metallic inclusions. Apply 2000 amperes DC circular magnetizing current for detecting grinding checks.

(1) Subsurface longitudinal indications:

- None accepted on nose.
- Short longitudinal indications up to 0.625 in. (15.875 mm) long are acceptable in critical region on cam surface 0.500 in. (12.700 mm) before nose and 0.375 in. (9.525 mm) after nose.
- Not more than two indications are allowable in critical region of any one cam.
- Light longitudinal indications not exceeding two in number are allowable outside of critical region.
- Parallel indications must be separated by at least 0.625 in. (15.875 mm) of metal.


(2) Open longitudinal indications are not allowable except on base circle. A maximum of two longitudinal open indications 0.250 in. (6.350 mm) long or less will be allowed on base circle provided they are not closer than 0.250 in. (6.350 mm) and are visible only as tightly closed lines when surface is wiped clean. Open indications shall not be closer than 0.1875 in. (4.763 mm) to edge of cam (5). Circumferential indications, lying at an angle greater than 15° with longitudinal centerline, are not allowable.

(3) Subsurface longitudinal indications:

- 0.125 in. (3.715 mm) indications are allowable on nose.
- Light longitudinal indications up to 0.500 in. (12.700 mm) are allowable on ramp.
- Not more than two indications are allowable on ramp or nose of any one cam (5).

Whole surface of camshaft (5) must be wetted with magnetic particle suspension before magnetizing current is applied. Camshaft (5) must be magnetized by a single shot of current. Disassemble and discard camshaft if not within limits.

3-40. CAMSHAFT CAM FOLLOWER, AND PUSHROD REPAIR (Contd)



LEGEND:
5. CAMSHAFT


3-40. CAMSHAFT, CAM FOLLOWER, AND PUSHROD REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

<p>8. Camshaft (5) (Contd)</p>	<ul style="list-style-type: none"> • Light longitudinal indications not exceeding two in number are allowed on base circle of any one cam. • Parallel indications must be separated by at least 0.250 in. (6.350 mm) on ramp and nose, and by 0.0625 in. (15.875 mm) on base circle. <p>(4) Open longitudinal indications are not allowable except on base circle. A maximum of two longitudinal open indications 0.250 in. (6.350 mm) long or less will be allowed on base circle provided they are not closer together than 0.250 in. (6.350 mm) and are visible only as closed lines when surface is wiped clean. Open indications should not extend closer than 0.1875 in. (4.763 mm) to edge of cam.</p> <p>(5) Circumferential indications lying at an angle greater than 15° with longitudinal centerline are not allowable.</p> <p>(6) Subsurface indications are acceptable. Four open longitudinal indications are permitted in each section of bearing provided not more than half of them extend full width of bearing. Edges of such indications are to be stoned, not to exceed 0.005 in. (0.127 mm) deep.</p>	
<p>9. Camshaft gear (2)</p>	<p>Inspect for chipping, cracking, and visible wear.</p>	<p>Disassemble and discard camshaft gear if chipped, cracked, or visibly worn.</p>
<p>10. Thrust washer (3)</p>	<p>Inspect for flaking, burrs, distortion, and wear.</p>	<p>Discard if damaged or worn thinner than 0.083 in. (2.108 mm).</p>

3-40. CAMSHAFT, CAM FOLLOWER, AND PUSHROD REPAIR (Contd)



LEGEND:

- 2. CAMSHAFT GEAR
- 3. THRUST WASHER
- 5. CAMSHAFT
- 6. INTAKE AND EXHAUST PUSHROD (12)
- 7. INJECTOR PUSHROD (6)

3-40. CAMSHAFT CAM FOLLOWER, AND PUSHROD REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

NOTE

Intake, exhaust, and injector pushrods are inspected the same way. Perform step 11 for any intake, exhaust, or injector pushrod.


11. Pushrod (6) or (7)	<p>a. Using radius gauge, check ball end.</p> <p>b. Using ball end of new rocker lever adjusting screw (14), check diameter of socket.</p> <p>c. Inspect for bends or out-of-round.</p> <p>d. Check both ends for wear and looseness.</p> <p>e. Check for lubricating oil inside.</p>	<p>Radius of ball end must be 0.619-0.625 in. (15.723-15.875 mm). Discard pushrod if ball end is damaged or measures less than 0.619 in. (15.723 mm).</p> <p>Apply a coat of Prussian blue compound to adjusting screw. Put adjusting screw (14) into socket and rotate 180°. Discard pushrod if socket is damaged or has less than 80 percent contact with adjusting screw.</p> <p>Discard if bent or out-of-round more than 0.035 in. (0.889 mm). Discard if there is extreme wear on either end. Do not install pushrod with worn ball end into new cam follower socket.</p> <p>Discard if pushrod (6) or (7) has begun to fill with oil.</p>
------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

NOTE

Repeat step 12 for each cam follower shaft.

12. Cam follower shaft (12)	<p>a. Using suitable micrometer, measure outside diameter.</p> <p>b. Inspect for cracks, breaks, galling, surface imperfections, and broken out areas.</p>	<p>Cam follower shaft (12) diameter must measure 0.7485-0.7490 in. (19.012-19.025 mm). Discard cam follower shaft if outside diameter measures less than 0.748 in. (18.999 mm).</p> <p>Discard if damaged. Ensure grooves on shaft locking screw (10) are clean.</p>
-----------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-40. CAMSHAFT, CAM FOLLOWER, AND PUSHROD REPAIR (Contd)



LEGEND:

- 6. INTAKE AND EXHAUST PUSHROD (12)
- 7. INJECTOR PUSHROD (6)
- 10. SHAFT LOCKING SCREW (6)
- 12. CAM FOLLOWER SHAFT (6)
- 14. NEW ROCKER LEVER ADJUSTING SCREW (18)

3-40. CAMSHAFT CAM FOLLOWER, AND PUSHROD REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

NOTE

Repeat step 13 for each cam follower housing.


13. Cam follower housing (13)	a. Inspect for cracks, breaks, gasket surface imperfections, broken-out sections, distortion, excessive wear, and other damage. b. Inspect edges of expansion plug holes for sharp edges, nick, and other damage.	Discard if damaged or worn. If holes were damaged, use 240-grit aluminum paper to remove any sharp edges. Chamfer edge of holes to aid in installation of cam follower shaft (12).
-------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

NOTE

Intake, exhaust, and injector cam followers are inspected the same way. Do steps 14 through 19 for any intake, exhaust, or injector cam followers.

14. Cam follower (8) or (9)	a. Inspect cam follower bushing (15) for scratches, pitting, scoring, and other damage. b. Using suitable micrometer, measure inside diameter of cam follower bushing (15). c. Inspect for cracks using magnetic method. Apply coil magnetization; amperage at 300-500 with residual Magnaglo.	Discard cam follower (8) or (9) if cam follower bushing (15) is damaged. Cam follower bushing (15) diameter must measure 0.7501-0.7511 in. (19.053-19.078 mm). Discard cam follower if cam follower bushing (15) diameter measures more than 0.752 in. (19.101 mm). Discard cam follower (8) or (9) if any cracks are found. Be sure to check carefully for cracks on areas of cam follower (8) or (9) shown in illustration.
-----------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-40. CAMSHAFT, CAM FOLLOWER, AND PUSHROD REPAIR (Contd)



LEGEND:

- 8. INTAKE AND EXHAUST CAM FOLLOWER (12)
- 9. INJECTOR CAM FOLLOWER (6)
- 12. CAM FOLLOWER SHAFT (6)

- 13. CAM FOLLOWER HOUSING (3)
- 15. CAM FOLLOWER BUSHING (18)


3-40. CAMSHAFT, CAM FOLLOWER, AND PUSHROD REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

14. Cam follower (8) or (9) (Contd)	<p>d. Magnetization with Magnaglo is one of the best methods for this inspection. The part is magnetized and covered with a fine magnetic powder. In the vicinity of the crack, there is a disturbance of the Magnaglo which gathers in the crack and effectively marks it.</p> <p>e. Inspect pushrod insert (16) for scoring, galling, pitting, and excessive wear.</p> <p>f. Check pushrod insert (16) using ball end of new pushrod (6) or (7).</p>	<p>Apply a coat of Prussian blue compound to ball end of new pushrod (6) or (7). Put ball end of new pushrod (6) or (7) into pushrod insert (16) and rotate 80°. Replace cam follower (8) or (9) if pushrod insert (16) is damaged or has less than 80 percent contact with ball end of new pushrod (6) or (7).</p>
15. Roll pin (18)	<p>Using hammer and punch, drive out roll pin (18). Remove roller pin (17) and cam follower roller (19) from cam follower (8) or (9).</p>	
16. Cam follower roller (19)	<p>a. Inspect for cracks, breaks, and other damage.</p>	<p>Discard cam follower (8) or (9) if cam follower roller (19) is damaged.</p>

3-40. CAMSHAFT, CAM FOLLOWER, AND PUSHROD REPAIR (Contd)



LEGEND:

- | | |
|----------------------------------------|------------------------------|
| 6 INTAKE AND EXHAUST PUSHROD (12) | 16. PUSHROD INSERT (18) |
| 7. INJECTOR PUSHROD (6) | 17. ROLLER PIN (18) |
| 8 INTAKE AND EXHAUST CAM FOLLOWER (12) | 18. ROLL PIN (18) |
| 9. INJECTOR CAM FOLLOWER (6) | 19. CAM FOLLOWER ROLLER (18) |


3-40. CAMSHAFT CAM FOLLOWER, AND PUSHROD REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

<p>16. Cam follower roller (19) (Contd)</p>	<p>b. Using small bore gauge, measure inside diameter.</p> <p>c. Inspect cam follower roller (19) to ensure it is not out-of-round.</p> <p>d. Using suitable micrometer, measure outside diameter.</p> <p>e. Check concentricity of inside diameter with outside diameter.</p> <p>f. Check squareness of sides with bore.</p>	<p>Intake or exhaust cam follower roller (19) inside diameter must measure 0.5005-0.5015 in. (12.713-12.738 mm). Discard cam follower (8) if inside diameter measures more than 0.503 in. (12.776 mm). Injector cam roller inside diameter must measure 0.703-0.704 in. (17.856-17.882 mm). Discard injector cam follower (9) if inside diameter measures more than 0.705 in. (17.907 mm). Discard cam follower (8) or (9) if roller (19) is out-of-round. Outside diameter of roller (19) must measure 1.2495-1.2505 in. (31.737-31.763 mm). Discard intake, exhaust, or injector cam follower (8) or (9) if outside diameter measures less than 1.2485 in. (31.712 mm). Discard cam follower (8) or (9) if not within 0.0020 in. (0.051 mm). Discard cam followers (8) or (9) if sides are not parallel to each other or not square to bore within 0.0040 in. (0.102 mm).</p>
<p>17. Roller pin (17)</p>	<p>a. Inspect for cracks, breaks, and other damage.</p> <p>b. Using suitable micrometer, measure outside diameter.</p>	<p>Discard cam followers (8) or (9) if roller pin (17) is damaged. Intake or exhaust roller pin (17) outside diameter must measure 0.4997-0.500 in. (12.692-12.700 mm). Discard intake or exhaust cam follower (8) if outside diameter measures less than 0.497 in. (12.624 mm). Injector roller pin (17) outside diameter must measure 0.6997-0.7000 in. (17.772-17.780 mm). Discard injector cam follower (9) if outside diameter measures less than 0.997 in. (17.704 mm).</p>

3-40. CAMSHAFT, CAM FOLLOWER, AND PUSHROD REPAIR (Contd)



LEGEND:

- 8. INTAKE AND EXHAUST CAM FOLLOWER (12)
- 9. INJECTOR CAM FOLLOWER (6)

- 17. ROLLER PIN (18)
- 19. CAM FOLLOWER ROLLER (18)

3-40. CAMSHAFT CAM FOLLOWER, AND PUSHROD REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

18. Cam follower (8) or (9)	Using suitable micrometer, measure roller pin bore.	Discard intake and exhaust cam follower (8) if roller pin bore is not within 0.4990 and 0.4995 in. (12.675 and 12.687 mm). Discard injector cam follower (9) if roller pin bore is not within 0.6992 and 0.6997 in. (17.760 and 17.772 mm).
-----------------------------	-----------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

d. Assembly


19. Cam follower roller (19) and roller pin (17)	a. Install roller (19) on cam follower (8) or (9). b. Hold 0.006 in. (0.152 mm) feeler gauge between cam follower (8) or (9) and cam follower roller (19). c. Install roller pin (17) on cam follower (8) or (9) and cam follower roller (19). d. Secure roller pin (17) to cam follower (8) or (9) with roll pin (18).	
--------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

NOTE

Repeat steps 20 through 22 for each cam follower assembly.

20. Four intake and exhaust cam followers (8), two injector cam followers (9), and two cam follower shafts (12)	Install on cam follower housing (13).	Ensure injector cam follower (9) is in center position, and that cam follower pushrod sockets are on same side as dowel holes in housing.
21. Cam follower shaft (12)	Install dummy screw.	Dummy screw is used to prevent breaking shaft locking screw (10) when expansion plugs (11) are installed on cam follower housing (13).

3-40. CAMSHAFT CAM FOLLOWER, AND PUSHROD REPAIR (Contd)



LEGEND:

- 8. INTAKE AND EXHAUST CAM FOLLOWER (12)
- 9. INJECTOR CAM FOLLOWER (6)
- 10. SHAFT LOCKING SCREW (6)
- 11. EXPANSION PLUG (6)
- 12. CAM FOLLOWER SHAFT (6)


- 13. CAM FOLLOWER HOUSING (3)
- 17. ROLLER PIN (18)
- 18. ROLL PIN (18)
- 19. CAM FOLLOWER ROLLER (18)

3-40. CAMSHAFT CAM FOLLOWER, AND PUSHROD REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
d. Assembly (Contd)		
22. Cam follower housing (13)	a. Apply light coat of cup plug sealant to expansion plug hole in each end. b. Using suitable mandrel, install two new expansion plugs (11). c. Remove dummy screw and install two shaft locking screws (10).	Expansion plugs (11) should be at least flush with edge of hole or not more than 0.010 in. (0.254 mm) below edge of hole.
23. Camshaft orifice plug (1)	Install on camshaft (5).	Torque 5-10 lb-f (7-13 N•m).
24. Thrust washer (3)	Install on camshaft (5).	
25. Camshaft gear (2)	If removed in step 1, heat gear (2) evenly in oven to 400° F.	Do not use cutting torch to heat camshaft gear (2); damage to gear (2) will result.
26. Camshaft(5)	a. Put in press. b. Install gear-to-camshaft key (4). c. Press camshaft gear (2) on camshaft (5) while still hot	

FOLLOW-ON TASK: Install camshaft and cam follower assemblies (para. 3-70).

3-40. CAMSHAFT, CAM FOLLOWER, AND PUSHROD REPAIR (Contd)



LEGEND:

- 1. CAMSHAFT ORIFICE PLUG
- 2. CAMSHAFT GEAR
- 3. THRUST WASHER
- 4. GEAR-TO-CAMSHAFT KEY

- 5. CAMSHAFT
- 10. SHAFT LOCKING SCREW (6)
- 11. EXPANSION PLUG (6)
- 13. CAM FOLLOWER HOUSING (3)

3-41. ROCKER LEVERS AND HOUSING REPAIR

THIS TASK COVERS:

- a. Disassembly
- b. Cleaning

- c. Inspection
- d. Assembly

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Rocker lever block and mandrel set
(15434) ST-691

TEST EQUIPMENT

None

MATERIALS/PARTS

Solvent, SD-3 (Appendix C, Item 30)
Paper, aluminum oxide, 240-grit
(Appendix C, Item 23)
Compound, Prussian blue (Appendix C, Item 9)
Oil, lubricating, OE/HDO 30
(Appendix C, Item 21)
Two O-ring seals (15434) 2000521
Two plugs (15434) 218736
Two special expansion plugs (15434) 161825

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Rocker arm housing assembly removed (para. 3-22).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

Always wear eye protection when working with compressed air.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly

NOTE

Use this procedure to repair any one of the three rocker lever and housing assemblies. Quantities shown in legend are for one rocker lever and housing assembly.

- | | | | |
|----|---------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|
| 1. | Two adjusting screws (1), four adjusting screws (4), and six adjusting screw nuts (3) | Unscrew and remove from rocker levers (5), (8), (11), (13), and (15). | |
| 2. | Oil supply screw (22) | Unscrew and remove from rocker arm housing (21) and rocker lever shaft (20). | |
| 3. | Rocker lever shaft (20) and six rocker levers (5), (8), (11), (13), and (15) | Using suitable punch, press shaft (20) out of rocker arm housing (21) and remove rocker levers (5), (8), (11), (13), and (15). | Be careful not to damage bore in rocker arm housing (21). Tag each rocker lever as removed to ensure correct assembly. |
| 4. | Two O-ring seals (18) | Remove from plugs (17). | Discard O-ring seals (18). |
| 5. | Two plugs (17) | a. Put one plug (17) in vise.


b. Rotate and pull off rocker lever shaft (20).
c. Repeat steps 5a and 5b for other plug (17). | Do not put rocker lever shaft (20) in vise.

Discard plugs (17). |

3-41. ROCKER LEVERS AND HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

- | | | |
|-------------------------------------|---------------------------------------|-------------------------------|
| 6. Two special expansion plugs (19) | Punch out of rocker lever shaft (20). | Discard expansion plugs (19). |
|-------------------------------------|---------------------------------------|-------------------------------|



LEGEND:

- | | |
|---------------------------------------|-----------------------------------|
| 1. ADJUSTING SCREW (2) | 12. INTAKE ROCKER LEVER ASSEMBLY |
| 2. EXHAUST ROCKER LEVER ASSEMBLY | 13. INTAKE ROCKER LEVER |
| 3. ADJUSTING SCREW NUT (6) | 14. INTAKE ROCKER LEVER ASSEMBLY |
| 4. ADJUSTING SCREW (4) | 15. EXHAUST ROCKER LEVER |
| 5. EXHAUST ROCKER LEVER | 16. EXHAUST ROCKER LEVER ASSEMBLY |
| 6. BUSHING (4) | 17. PLUG (2) |
| 7. INJECTOR ROCKER LEVER ASSEMBLY (2) | 18. O-RING SEAL (2) |
| 8. INJECTOR ROCKER LEVER (2) | 19. SPECIAL EXPANSION PLUG (2) |
| 9. BUSHING (2) | 20. ROCKER LEVER SHAFT |
| 10. BALL SOCKET SEAT (2) | 21. ROCKER ARM HOUSING |
| 11. INTAKE ROCKER LEVER | 22. OIL SUPPLY SCREW |

3-41. ROCKER LEVERS AND HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Cleaning

7. Rocker lever shaft (20) Using bottle brush, clean bore in shaft.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.

8. All parts Clean in solvent SD-3 and blow dry with compressed air. Make sure all gasket material has been removed from sealing surfaces of rocker arm housing (21). Refer to para. 3-6 for additional cleaning instructions.

c. Inspection

9. All parts Inspect for cracks, breaks, distortion, and other damage. Discard damaged parts.


10. All threaded parts Inspect for crossthreading, stripping, and other damage. Discard damaged parts.

11. Rocker arm housing (21) a. Inspect opening of shaft bore for sharp edges, nicks, or burrs. Shaft bore opening should have slight radius. Sharp edges can be removed by using 240-grit aluminum oxide paper over a split rod, rotating in an electric drill.

b. Check breather vent hole (24) and rocker lever oil passage (23) to make sure they are free of dirt and other foreign material.

c. Using suitable micrometer, measure rocker lever shaft bore inside diameter. Discard rocker arm housing (21) if measurement is not between 1.1238 and 1.1246 in. (28.545 and 28.565 mm). (See Appendix F-2.)

3-41. ROCKER LEVERS AND HOUSING REPAIR (Contd)



LEGEND:

- 20. ROCKER LEVER SHAFT
- 21. ROCKER ARM HOUSING
- 23. ROCKER LEVER OIL PASSAGE
- 24. BREATHER VENT HOLE

3-41. ROCKER LEVERS AND HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


c. Inspection (Contd)

NOTE

Repeat step 12 for each exhaust, intake, or injector rocker lever.

12. Rocker levers (5), (8), (11), (13), or (15)	<p>a. Check for cracks using magnetic inspection.</p> <p>b. Using new adjusting screw (1) or (4), check condition of threads in rocker lever.</p> <p>c. Inspect ball socket seat of injector rocker levers (8) for damage. Apply Prussian blue compound with 0.500 in. (12.70 mm) check ball.</p> <p>d. Inspect bushings (6) or (9) for scratches, pitting, scoring, and excessive wear.</p> <p>e. Using suitable micrometer, measure bushing inside diameter.</p>	<p>Use coil magnetization with amperage at 300 to 500 residual Magnaglo. Most areas of crack indication shown in illustration. Replace rocker lever assembly (2) (7), (12), (14), or (16) if rocker lever has cracks. Demagnetize levers that are to be reused. Discard rocker lever assembly if adjusting screw does not move freely in rocker lever.</p> <p>If socket is damaged or if bluing pattern does not coat at least 80 percent of socket, drill small hole over ball socket seat and drive damaged ball socket seat (10) out of injector rocker lever (8). Stake hole and install a new ball socket seat (10) in injector rocker lever (8).</p> <p>Replace bushings (6) or (9) if damaged or worn (refer to step 12f for replacement).</p> <p>Replace bushings (6) or (9) if not within limits shown below (refer to step 12f for replacement).</p>
		<p>New Minimum 1.1245 in. (28.562 mm)</p> <p>New Maximum 1.1275 in. (28.638 mm)</p> <p>Wear Limit 1.1286 in. (28.666 mm)</p>
	<p>f. Replace bushings (6) or (9) as follows:</p> <p>(1) Using rocker lever block and mandrel set (25), press bushings (6) or (9) out.</p>	<p>Do this step only if bushings (6) or (9) are damaged or not within wear limits. Discard bushing(s).</p>

3-41. ROCKER LEVERS AND HOUSING REPAIR (Contd)



LEGEND:

- | | |
|---------------------------------------|----------------------------------------|
| 1. ADJUSTING SCREW (2) | 10. BALL SOCKET SEAT (2) |
| 2. EXHAUST ROCKER LEVER ASSEMBLY | 11. INTAKE ROCKER LEVER |
| 3. ADJUSTING SCREW NUT (6) | 12. INTAKE ROCKER LEVER ASSEMBLY |
| 4. ADJUSTING SCREW (4) | 13. INTAKE ROCKER LEVER |
| 5. EXHAUST ROCKER LEVER | 14. INTAKE ROCKER LEVER ASSEMBLY |
| 6. BUSHING (4) | 15. EXHAUST ROCKER LEVER |
| 7. INJECTOR ROCKER LEVER ASSEMBLY (2) | 16. EXHAUST ROCKER LEVER ASSEMBLY |
| 8. INJECTOR ROCKER LEVER (2) | 25. ROCKER LEVER BLOCK AND MANDREL SET |
| 9. BUSHING (2) | |

3-41. ROCKER LEVERS AND HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

CAUTION

- To avoid damaging engine, do the following:
- On injector and exhaust rocker levers, install bushing so oil holes to crosshead nose or injector link and adjusting screw are open for oil flow.
- On intake valve rocker levers with oil drilling to crosshead nose end, install bushing so nose hole is closed and slot hole is in line with adjusting screw oil hole.
- Do not cut a bore in steel bushings.

(2) Using rocker lever block and mandrel set (25) and arbor press, press new bushings (6) or (9) into rocker levers (5), (8), (11), (13), or (15).

g. Check rocker lever-to-crosshead contact surface on intake or exhaust rocker levers (5), (11), (13), or (15).

Replace intake or exhaust rocker lever assembly (2), (12), (14), or (16) if damaged or worn.

NOTE

Repeat step 13 for each adjusting screw.

13. Adjusting screws (1) or (4)

- a. Using a 0.250 in. (6.350 mm) radius gauge, check ball end.
- b. Check thread condition.

Discard adjusting screw if ball end is out-of-round or flat at bottom. Check carefully for thread distortion at assembly position of adjusting screw nut (3). Discard adjusting screws (1) or (4) if threads are damaged, or if it does not move freely in rocker levers (5), (8), (11), (13), or (15).


14. Rocker lever shaft (20)

- a. Inspect for scoring or excessive wear.
- b. Using suitable micrometer, measure outside diameter of shaft (20).

Discard if damaged, worn, or if it has ridges due to action of rocker levers (5), (8), (11), (13), or (15). Discard if outside diameter is not within limits shown below:

New Minimum	1.1230 in. (28.524 mm)
New Maximum	1.1240 in. (28.550 mm)
Wear Limit	1.1220 in. (28.499 mm)

3-41. ROCKER LEVERS AND HOUSING REPAIR (Contd)



LEGEND:

- | | |
|----------------------------------|----------------------------------------|
| 1. ADJUSTING SCREW (2) | 11. INTAKE ROCKER LEVER |
| 2. EXHAUST ROCKER LEVER ASSEMBLY | 12. INTAKE ROCKER LEVER ASSEMBLY |
| 3. ADJUSTING SCREW NUT (6) | 13. INTAKE ROCKER LEVER |
| 4. ADJUSTING SCREW (4) | 14. INTAKE ROCKER LEVER ASSEMBLY |
| 5. EXHAUST ROCKER LEVER | 15. EXHAUST ROCKER LEVER |
| 6. BUSHING (4) | 16. EXHAUST ROCKER LEVER ASSEMBLY |
| 8. INJECTOR ROCKER LEVER (2) | 20. ROCKER LEVER SHAFT |
| 9. BUSHING (2) | 25. ROCKER LEVER BLOCK AND MANDREL SET |
| 10. BALL SOCKET SEAT (2) | |

3-41. ROCKER LEVERS AND HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly

15. Two adjusting screws (1), four adjusting screws (4), and six adjusting screw nuts (3)	Screw into rocker levers (5), (8), (11), (13), and (15).	Be sure to install adjusting screws and nuts into correct rocker levers.
16. Two new special expansion plugs (19)	Press one into each end of rocker lever shaft (20).	
17. Two new plugs (17)	Using arbor press, install into rocker lever shaft (20).	Install both plugs (17) into shaft (20) at same time.
18. Rocker lever shaft (20)	<p>a. Coat with clean lubricating oil.</p> <p>b. Slide shaft (20) through rocker arm housing (21) and rocker lever assemblies (2), (7), (12), (14), and (16).</p> <p>c. Install lightly oiled new O-ring seal (18) into groove of shaft (20).</p> <p>d. Push shaft (20) into rocker arm housing (21) until other end extends about 0.500 in. (12.70 mm), and install other lightly oiled new O-ring seal (18) and push shaft (20) back into rocker arm housing (21).</p>	Let about 0.500 in. (12.70 mm) of shaft (20) extend out of housing (21).

CAUTION


Ensure rocker lever shaft is installed correctly. Setscrew hole must be on top and seven oil holes must be toward flat side of rocker arm housing.

19. Rocker lever shaft (20)	<p>e. Align shaft and housing locking holes and secure oil supply screw (22).</p> <p>f. Check all rocker levers (5), (8), (11), (13), or (15) for freedom of movement on shaft (20).</p>	This will prevent galling of shaft (20) and bushings (6) or (9).
-----------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------

NOTE

Install rocker arm housing assembly (para. 3-84).

3-41. ROCKER LEVERS AND HOUSING REPAIR (Contd)



LEGEND:

- | | |
|---------------------------------------|-----------------------------------|
| 1. ADJUSTING SCREW (2) | 14. INTAKE ROCKER LEVER ASSEMBLY |
| 2. EXHAUST ROCKER LEVER ASSEMBLY | 15. EXHAUST ROCKER LEVER |
| 3. ADJUSTING SCREW NUT (6) | 16. EXHAUST ROCKER LEVER ASSEMBLY |
| 4. ADJUSTING SCREW (4) | 17. PLUG (2) |
| 5. EXHAUST ROCKER LEVER | 18. O-RING SEAL (2) |
| 7. INJECTOR ROCKER LEVER ASSEMBLY (2) | 19. SPECIAL EXPANSION PLUG (2) |
| 8. INJECTOR ROCKER LEVER (2) | 20. ROCKER LEVER SHAFT |
| 11. INTAKE ROCKER LEVER | 21. ROCKER ARM HOUSING |
| 12. INTAKE ROCKER LEVER ASSEMBLY | 22. OIL SUPPLY SCREW |
| 13. INTAKE ROCKER LEVER | |

3-42. OIL COOLER REPAIR

THIS TASK COVERS:

- a. Disassembly
- b. Cleaning

- c. Inspection
- d. Assembly

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

- Solvent, SD-3 (Appendix C, Item 30)
- Acid, muriatic (Appendix C, Item 1)
- Acid, oxalic (Appendix C, Item 2)
- Pyridene (Appendix C, Item 24)
- Sodium, carbonate (5 percent solution) (Appendix C, Item 28)
- Oil, lubricating, OE/HDO 30 (Appendix C, Item 21)
- Expansion plug (15434) 142110
- Gasket and seal kit (15434) 3018762 (M915/Big Cam I)
- Ten lockwashers (96906) MS35338-48 (M915/Big Cam I)
- Lockwasher (15434) 70216 (M915/Big Cam I)
- Gasket and seal kit (15434) 3801235 (M915A1/Big Cam III)
- Eleven lockwashers (15434) S-604 (M915A1/Big Cam III)
- Three lockwashers (96906) MS122032 (M915A1/Big Cam III)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

- TM 9-2320-273-20
- TM 9-2320-283-20

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Oil cooler removed (para. 3-22).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

- Always wear eye protection when working with compressed air.
- Approved solvents may be flammable and will not be used near open flame. Use in well-ventilated area.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


a. Disassembly

NOTE

- Perform steps 1 through 7 for M915/Big Cam I only.
- Perform steps 8 through 16 for M915A1/Big Cam III only.

- | | |
|--------------------------------------------------------------------------------------------------|-------------------------------------------------------------|
| <p>1. Pipe plugs (7), (17), and (32), expansion plug (16) or elbow (31), and drainvalve (10)</p> | <p>Remove from cover (15), housing (12), and cover (3).</p> |
|--------------------------------------------------------------------------------------------------|-------------------------------------------------------------|

3-42. OIL COOLER REPAIR (Contd)



M915/BIG CAM I

LEGEND:

- | | | |
|--------------------------|--------------------|-----------------------|
| 1. SCREW (2) | 12. HOUSING | 23. DISC |
| 2. BRACKET | 13. GASKET | 24. SEAT |
| 3. COVER | 14. SCREW (6) | 25. SCREW |
| 4. RETAINING RING (2) | 15. COVER | 26. LOCKWASHER |
| 5. PREFORMED PACKING (2) | 16. EXPANSION PLUG | 27. WASHER |
| 6. FILTER ELEMENT | 17. PIPE PLUG | 28. HEAD |
| 7. PIPE PLUG | 18. PLUNGER | 29. GASKET |
| 8. LOCKWASHER (10) | 19. SPRING | 30. PREFORMED PACKING |
| 9. SCREW (4) | 20. SPACER | 31. ELBOW |
| 10. DRAINVALVE | 21. PLUG | 32. PIPE PLUG |
| 11. GASKET | 22. SPRING | |

3-42. OIL COOLER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)

- | | | | |
|----|----------------------------------------------------------------------------------------------|---------------------------|-------------------------------------------------------------------|
| 2. | Screw (25), lockwasher (26), washer (27), head (28), gasket (29), and preformed packing (30) | Remove from housing (12). | Discard lockwasher (26), gasket (29), and preformed packing (30). |
| 3. | Seat (24), disc (23), and spring (22) | Remove from housing (12). | |

NOTE

The pressure regulator valve is located on the oil cooler support. It controls oil pressure before oil passes through the filter element.

- | | | | |
|----|-------------------------------------------------------------------------------------------|---------------------------|------------------------------------------|
| 4. | Plug (21), spacer (20), spring (19), and plunger (18) | Remove from cover (15). | |
| 5. | Six screws (14), lockwashers (8), cover (15), and gasket (13) | Remove from housing (12). | Discard lockwashers (8) and gasket (13). |
| 6. | Two screws (1), bracket (2), four screws (9), lockwashers (8), cover (3), and gasket (11) | Remove from housing (12). | Discard lockwashers (8) and gasket (11). |

NOTE

To prevent hardening and drying of foreign substances, clean element as soon as possible after removal.

- | | | | |
|----|-------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 7. | Two retaining rings (4), preformed packings (5), and filter element (6) | To remove from housing (12):

a. Insert two long rods in outside row of element tubes opposite each other.


b. Place a flat bar on top of housing (12) and bundle face between rods, and rotate element in housing.

c. Remove retaining rings (4) and preformed packings (5).

d. Remove filter element (6) from housing (12). | Do not use a sharp object to remove preformed packings (5), or damage to housing (12) or retaining rings (4) may result. Discard preformed packings (5).

Do not use a sharp object to remove. Filter element (6) may become damaged. |
|----|-------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

3-42. OIL COOLER REPAIR (Contd)



M915/BIG CAM I


LEGEND:

- | | | |
|--------------------------|---------------|-----------------------|
| 1. SCREW (2) | 12. HOUSING | 23. DISC |
| 2. BRACKET | 13. GASKET | 24. SEAT |
| 3. COVER | 14. SCREW (6) | 25. SCREW |
| 4. RETAINING RING (2) | 15. COVER | 26. LOCKWASHER |
| 5. PREFORMED PACKING (2) | 18. PLUNGER | 27. WASHER |
| 6. FILTER ELEMENT | 19. SPRING | 28. HEAD |
| 8. LOCKWASHER (10) | 20. SPACER | 29. GASKET |
| 9. SCREW (4) | 21. PLUG | 30. PREFORMED PACKING |
| 11. GASKET | 22. SPRING | |

3-42. OIL COOLER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
a. Disassembly (Contd)		
8. Three screws (42), lockwashers (43), washers (44), and bracket (45)	Remove from head (46).	Screws (42), lockwashers (43), washers (44), and bracket (45) may have already been removed. Discard lockwashers (43).
9. Three screws (60), lockwashers (36), washers (51), head (46), preformed packing (47), and gasket (48)	Remove from housing (49).	Discard preformed packing (47) and gasket (48).
10. Low oil pressure switch	Remove.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
11. Spring (58), bypass valve piston (57), spring (56), bypass valve plunger (55), and pressure sensing piston (54)	Remove from housing (49) and separate.	
12. Six screws (50), lockwashers (36), washers (51), support (41), and gasket (34)	Remove from housing (49).	Discard lockwashers (36) and gasket (34).
NOTE To prevent hardening and drying of foreign substances, clean oil cooler core as soon as possible after removal.		
13. Cooler core (33) and gasket (52)	Remove from housing (49).	Discard gasket (52).
14. Two screws (35), lockwashers (36), valve (37), and preformed packing (38)	Remove from support (41).	Discard preformed packing (38) and lockwasher (36).
15. Pipe plugs (40) and (39)	Remove from support (41).	
16. Adapters (53) and (59)	Remove from housing (49) and head (46).	

3-42. OIL COOLER REPAIR (Contd)



M915A1/BIG CAM III

LEGEND:

- | | | |
|-----------------------|-----------------------|-----------------------------|
| 33. COOLER CORE | 43. LOCKWASHER (3) | 53. ADAPTER |
| 34. GASKET | 44. WASHER (3) | 54. PRESSURE SENSING PISTON |
| 35. SCREW (2) | 45. BRACKET | 55. BYPASS VALVE PLUNGER |
| 36. LOCKWASHER (11) | 46. HEAD | 56. SPRING |
| 37. VALVE | 47. PREFORMED PACKING | 57. BYPASS VALVE PISTON |
| 38. PREFORMED PACKING | 48. GASKET | 58. SPRING |
| 39. PIPE PLUG | 49. HOUSING | 59. ADAPTER |
| 40. PIPE PLUG | 50. SCREW (6) | 60. SCREW (3) |
| 41. SUPPORT | 51. WASHER (9) | |
| 42. SCREW (3) | 52. GASKET | |

3-42. OIL COOLER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Cleaning

WARNING


- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

NOTE

Cleaning procedures for the oil cooler assembly are the same for M915/Big Cam I and M915A1/Big Cam III. M915/Big Cam I is shown.

17. Housing (12)	Clean lubricating oil and contaminants by forcing solvent SD-3 through oil ports in reverse direction of normal flow.	Use compressed air.
18. Filter element (6)	<p>a. Immerse in solvent SD-3 and let stand for several minutes.</p> <p>b. After cleaning, flush thoroughly with hot water.</p> <p>c. Prepare solution containing one part muriatic acid and nine parts water. Add 1 lb (0.454 Kg) oxalic acid and 1.28 fl. oz. (37.85 ml) pyridene to each 5 gal. (18.9 L) of muriatic acid.</p> <p>d. Immerse in solution.</p> <p>e. Remove when foaming and bubbling stops.</p> <p>f. Immerse in 5 percent solution of sodium carbonate.</p> <p>g. Remove when bubbling stops. Pressure-flush with clean, warm water.</p>	<p>Force solvent around tubes and clean using compressed air.</p> <p>Reaction normally stops in 30 to 60 seconds.</p> <p>Flush inside of tubes with light oil after both oil and water sides of cooler core are clean and dry.</p>
19. All other parts	Clean.	Refer to para. 3-6 for cleaning instructions.

3-42. OIL COOLER REPAIR (Contd)



M915/BIG CAM I

LEGEND:

- | | | |
|--------------------------|--------------------|-----------------------|
| 1. SCREW (2) | 12. HOUSING | 23. DISC |
| 2. BRACKET | 13. GASKET | 24. SEAT |
| 3. COVER | 14. SCREW (6) | 25. SCREW |
| 4. RETAINING RING (2) | 15. COVER | 26. LOCKWASHER |
| 5. PREFORMED PACKING (2) | 16. EXPANSION PLUG | 27. WASHER |
| 6. FILTER ELEMENT | 17. PIPE PLUG | 28. HEAD |
| 7. PIPE PLUG | 18. PLUNGER | 29. GASKET |
| 8. LOCKWASHER (10) | 19. SPRING | 30. PREFORMED PACKING |
| 9. SCREW (4) | 20. SPACER | 31. ELBOW |
| 10. DRAINVALVE | 21. PLUG | 32. PIPE PLUG |
| 11. GASKET | 22. SPRING | |

3-42. OIL COOLER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection

NOTE

- Perform steps 20 and 21 for M915/Big Cam I only.
- Perform steps 22 and 23 for M915A1/Big Cam III only.


20. All parts	Inspect for cracks, damaged threads, and excessive corrosion.	Discard any part where cracks, stripped threads, or excessive corrosion is found.
---------------	---------------------------------------------------------------	-----------------------------------------------------------------------------------

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.

21. Filter element (6)	<p>Inspect and repair as follows:</p> <p>a. Seal one end of tube bundle. Install suitable air fitting on opposite end and connect compressed air supply line. Immerse tube bundle in water and apply approximately 40 psi (276 kPa) air pressure. If air bubbles are observed, mark bundle for repair or replacement.</p> <p>b. Inspect cover (15) for broken or cracked welds. Repair or replace as necessary.</p> <p>c. Header leaks may occur where tubes protrude through plate or where header is soldered in case.</p> <p>d. Repair damaged tubes by inserting a smaller outside diameter tube inside damaged tube. Cut, flare, and solder both ends.</p>	<p>Refer to steps 21c and d for repair.</p> <p>Use caution not to damage adjacent tubes or header material with heat while soldering. If more than 5 percent of the tubes are defective, discard filter element (6).</p>
------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-42. OIL COOLER REPAIR (Contd)



M915/BIG CAM I

LEGEND:

- | | | |
|--------------------------|--------------------|-----------------------|
| 1. SCREW (2) | 12. HOUSING | 23. DISC |
| 2. BRACKET | 13. GASKET | 24. SEAT |
| 3. COVER | 14. SCREW (6) | 25. SCREW |
| 4. RETAINING RING (2) | 15. COVER | 26. LOCKWASHER |
| 5. PREFORMED PACKING (2) | 16. EXPANSION PLUG | 27. WASHER |
| 6. FILTER ELEMENT | 17. PIPE PLUG | 28. HEAD |
| 7. PIPE PLUG | 18. PLUNGER | 29. GASKET |
| 8. LOCKWASHER (10) | 19. SPRING | 30. PREFORMED PACKING |
| 9. SCREW (4) | 20. SPACER | 31. ELBOW |
| 10. DRAINVALVE | 21. PLUG | 32. PIPE PLUG |
| 11. GASKET | 22. SPRING | |

3-42. OIL COOLER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)


22. All parts	Inspect for cracks, damaged threads, and excessive corrosion.	Discard any part where cracks, stripped threads, or excessive corrosion is found.
---------------	---------------------------------------------------------------	-----------------------------------------------------------------------------------

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.

23. Cooler core (33)	a. Seal one end and install suitable air fitting on opposite end. Connect compressed air supply line and apply air pressure.	Do not exceed 30 psi (207 kPa) for testing or cooler core (33) will rupture.
	b. Immerse in water and observe.	Discard cooler core (33) if air bubbles are present.
	c. Remove from water and disconnect air supply line and fitting.	

3-42. OIL COOLER REPAIR (Contd)



M915A1/BIG CAM III

LEGEND:

- | | | |
|-----------------------|-----------------------|-----------------------------|
| 33. COOLER CORE | 43. LOCKWASHER (3) | 53. ADAPTER |
| 34. GASKET | 44. WASHER (3) | 54. PRESSURE SENSING PISTON |
| 35. SCREW (2) | 45. BRACKET | 55. BYPASS VALVE PLUNGER |
| 36. LOCKWASHER (11) | 46. HEAD | 56. SPRING |
| 37. VALVE | 47. PREFORMED PACKING | 57. BYPASS VALVE PISTON |
| 38. PREFORMED PACKING | 48. GASKET | 58. SPRING |
| 39. PIPE PLUG | 49. HOUSING | 59. ADAPTER |
| 40. PIPE PLUG | 50. SCREW (6) | 60. SCREW (3) |
| 41. SUPPORT | 51. WASHER (9) | |
| 42. SCREW (3) | 52. GASKET | |

3-42. OIL COOLER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


d. Assembly

NOTE

- Perform steps 24 through 31 for M915/Big Cam I only.
- Perform steps 32 through 39 for M915A1/Big Cam III only.

24. Filter element (6)	<p>Install as follows:</p> <p>a. Lubricate new preformed packing (5). Using an appropriate mandrel, place preformed packing (5) in groove at bottom of housing (12). Ensure preformed packing (5) is fully seated, not twisted, and is free of cuts and nicks.</p> <p>b. Carefully push filter element (6) in housing (12), using aligning marks on housing (12) and filter element (6).</p> <p>c. Press second new preformed packing (5) around top of filter element (6) with equal pressure around preformed packing (5) circumference. Carefully seat filter element (6).</p> <p>d. Install two retaining rings (4) on preformed packing (5) and housing (12).</p>	<p>Use OE/HDO 30 lubricating oil.</p> <p>Do not fully seat filter element (6).</p>
25. New gasket (11), cover (3), bracket (2), two screws (1), four lockwashers (8), and screws (9)	<p>Install on housing (12).</p>	<p>Tighten screws (1) and (9) to 30-35 lb-ft (41-48 N•m).</p>
26. New gasket (13), cover (15), six new lockwashers (8), and screws (14)	<p>Install on housing (12).</p>	<p>Tighten screws (14) to 30-35 lb-ft (41-48 N•m).</p>

3-42. OIL COOLER REPAIR (Contd)



M915/BIG CAM I

LEGEND:

- | | |
|--------------------------|---------------|
| 1. SCREW (2) | 9. SCREW (4) |
| 2. BRACKET | 11. GASKET |
| 3. COVER | 12. HOUSING |
| 4. RETAINING RING (2) | 13. GASKET |
| 5. PREFORMED PACKING (2) | 14. SCREW (6) |
| 6. FILTER ELEMENT | 15. COVER |
| 8. LOCKWASHER (10) | |


3-42. OIL COOLER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)

27. Plunger (18), spring (19), spacer (20), and plug (21)	Install on cover (15).	
28. Spring (22), disc (23), and seat (24)	Install on housing (12).	
29. New preformed packing (30)	Lubricate and install on housing (12).	Use OE/HDO 30 lubricating oil.
30. New gasket (29), head (28), washer (27), new lockwasher (26), and screw (25)	Install on housing (12).	
31. Pipe plugs (7), (17), and (32), expansion plug (16) or pipe elbow (31), and drainvalve (10)	Install on cover (3), cover (15), and housing (12).	

3-42. OIL COOLER REPAIR (Contd)



M915/BIG CAM I

LEGEND:


- | | | |
|--------------------|----------------|-----------------------|
| 3. COVER | 19. SPRING | 27. WASHER |
| 7. PIPE PLUG | 20. SPACER | 28. HEAD |
| 10. DRAINVALVE | 21. PLUG | 29. GASKET |
| 12. HOUSING | 22. SPRING | 30. PREFORMED PACKING |
| 15. COVER | 23. DISC | 31. ELBOW |
| 16. EXPANSION PLUG | 24. SEAT | 32. PIPE PLUG |
| 17. PIPE PLUG | 25. SCREW | |
| 18. PLUNGER | 26. LOCKWASHER | |

3-42. OIL COOLER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
d. Assembly (Contd)		
32. Adapters (59) and (53)	Install on head (46) and housing (49).	
33. Pipe plugs (39) and (40)	Install on support (41).	Tighten pipe plug (39) to 60-84 lb-in. (7-10 N•m). Tighten pipe plug (40) to 15-25 lb-ft (20-34 N•m).
34. New preformed packing (38), valve (37), two new lockwashers (36), and screws (35)	Install on support (41).	Apply light coat of OE/HDO 30 lubricating oil to preformed packing (38). Tighten to 30-35 lb-ft (41-48 N•m).
35. New gasket (52), cooler core (33), gasket (34), support (41), six washers (51), new lockwashers (36), and screws (50)	Install on housing (49).	Tighten screws (50) to 30-35 lb-ft (41-48 N•m).
36. Pressure sensing piston (54), bypass valve plunger (55), spring (56), bypass valve piston (57), and spring (58)	Install on housing (49).	It will be necessary to hold in position at same time head (46) is installed.
37. New preformed packing (47), new gasket (48), head (46), three washers (51), new lockwashers (36), and screws (60)	Install on housing (49).	Apply light coat of OE/HDO 30 lubricating oil to preformed packing (47). Do not tighten screws (60).
38. Bracket (45), three washers (44), new lockwashers (43), and screws (42)	Install on head (46) and housing (49).	Tighten screws (42) and (60) to 30-35 lb-ft (41-48 N•m).
39. Low oil pressure switch	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.

FOLLOW-ON TASK: Install oil cooler (para. 3-88).

3-42. OIL COOLER REPAIR (Contd)



M915A1/BIG CAM III

LEGEND:

- 33. COOLER CORE
- 34. GASKET
- 35. SCREW (2)
- 36. LOCKWASHER (11)
- 37. VALVE
- 38. PREFORMED PACKING
- 39. PIPE PLUG
- 40. PIPE PLUG
- 41. SUPPORT
- 42. SCREW (3)

- 43. LOCKWASHER (3)
- 44. WASHER (3)
- 45. BRACKET
- 46. HEAD
- 47. PREFORMED PACKING
- 48. GASKET
- 49. HOUSING
- 50. SCREW (6)
- 51. WASHER (9)
- 52. GASKET

- 53. ADAPTER
- 54. PRESSURE SENSING PISTON
- 55. BYPASS VALVE PLUNGER
- 56. SPRING
- 57. BYPASS VALVE PISTON
- 58. SPRING
- 59. ADAPTER
- 60. SCREW (3)

3-43. OIL PAN, DIPSTICK, OIL SUCTION TUBES, AND BREATHER TUBE REPAIR

THIS TASK COVERS:

- a. Disassembly
- b. Cleaning
- c. Inspection
- d. Assembly

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

- Cloth, emery, 290-grit (Appendix C, Item 5)
- Compound, Prussian blue (Appendix C, Item 9)
- Solvent, SD-3 (Appendix C, Item 30)
- Oil pan gasket (Big Cam III only) (15434)
3027983
- O-ring seal (15434) 3029846
- O-ring seal (15434) 30314699

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

- TM 9-2320-273-20
- TM 9-2320-273-34
- TM 9-2320-283-20

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

- Oil suction tube removed (para. 3-19).
- Oil pan removed (para. 3-26).
- Oil breather tube removed (TM 9-2320-273-20 or TM 9-2320-283-20).
- Dipstick, dipstick tube, and cover removed (para. 3-13).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

- Always wear eye protection when using compressed air.
- Use approved solvents in well-ventilated area.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

NOTE

- Repair of oil pan is basically the same for M915/Big Cam I and M915A1/Big Cam III. Big Cam I engines are equipped with a cast aluminum oil pan. Big Cam III engines are equipped with a stamped steel oil pan.
- For M915/Big Cam I, it may be necessary to remove engine oil heater part of optional winterization kit. Refer to TM 9-2320-273-34. For engine oil heater thermostat removal, refer to TM 9-2320-273-20.

a. Disassembly

NOTE


- Perform steps 1 and 2 for M915A1/Big Cam III only.
- Perform steps 3 and 4 for M915/Big Cam I only.

- | | |
|--------------------------------------------------------------|-------------------------------------------|
| 1. Plug (2), spacer (1), and plug (5) | Remove from oil pan (6). |
| 2. Four screws (3) and strainer element (4) | Remove from oil pan (6). |
| 3. Three nuts (14), washers (13), clamps (12), and tube (11) | Remove from welded studs on oil pan (10). |


3-43. OIL PAN, DIPSTICK, OIL SUCTION TUBES, AND BREATHER TUBE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

- | | | |
|---------------------------------------------------------------------------|---------------------------|--|
| 4. Two pipe plugs (7), plugs (8) and (17), spacer (16), and pipe plug (9) | Remove from oil pan (10). | |
|---------------------------------------------------------------------------|---------------------------|--|



**M915/BIG CAM I OIL PAN
(CAST ALUMINUM)**



**M915A1/BIG CAM III OIL PAN
(STAMPED STEEL)**

LEGEND:

- | | |
|-----------------------------|----------------------------------|
| 1. SPACER | 10. OIL PAN (M915A1/BIG CAM III) |
| 2. PLUG | 11. TUBE |
| 3. SCREW (4) | 12. CLAMP (3) |
| 4. STRAINER ELEMENT | 13. WASHER (3) |
| 5. PLUG | 14. NUT (3) |
| 6. OIL PAN (M915/BIG CAM I) | 15. ENGINE SHIPPING SUPPORT |
| 7. PIPE PLUG (2) | 16. SPACER |
| 8. PLUG | 17. PLUG |
| 9. PIPE PLUG | |

3-43. OIL PAN, DIPSTICK, OIL SUCTION TUBES, AND BREATHER TUBE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Cleaning

WARNING

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

5. All parts and mounting hardware	Clean with SD-3 solvent and dry with compressed air.	It may be necessary to scrape gasket material from mating surfaces.
------------------------------------	------------------------------------------------------	---------------------------------------------------------------------

c. Inspection


6. Engine oil pan (6) (M915/Big Cam I) or oil pan (10) (M915A1/Big Cam III)	Inspect for the following: a. Cracks. b. Damaged or distorted threads. c. Gasket surfaces smooth and free from burrs or distortion.	Use detection dye. Discard if cracked. Repair with correct size die or thread chaser. Remove burrs with emery cloth.
-----------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------

NOTE


- Perform steps 7 and 8 for M915/Big Cam I only.
- Perform steps 9 thru 11 for M915A1/Big Cam III only.

7. Plugs (2) and (5), spacer (1), and four screws (3)	Inspect for damaged or worn threads and surface condition of drainplug spacer (1).	Discard if threads are worn or damaged and if seating surface of spacer (1) is worn.
8. Strainer element (4)	Inspect for damage.	Discard if damaged.
9. Two pipe plugs (7), plug (8), pipe plug (9), plug (17), and spacer (16)	Inspect for damage or worn threads and surface condition of drainplug spacer (16).	Discard if threads are worn or damaged and if seating surface of drainplug spacer (16) is worn.
10. Engine shipping support (15)	Inspect for cracks and distortion.	Discard if cracked.
11. Oil suction tube (11), three clamps (12), washers (13), and nuts (14)	Inspect for the following: a. Cracks. b. Gasket and O-ring seal surfaces free from burrs or distortion. c. Inspect for damaged threads.	Discard if cracked. Remove burrs with emery cloth. Discard if damaged.

3-43. OIL PAN, DIPSTICK, OIL SUCTION TUBES, AND BREATHER TUBE REPAIR (Contd)



**M915/BIG CAM I OIL PAN
(CAST ALUMINUM)**



**M915A1/BIG CAM III OIL PAN
(STAMPED STEEL)**

LEGEND:

- | | |
|-----------------------------|----------------------------------|
| 1. SPACER | 10. OIL PAN (M915A1/BIG CAM III) |
| 2. PLUG | 11. TUBE |
| 3. SCREW (4) | 12. CLAMP (3) |
| 4. STRAINER ELEMENT | 13. WASHER (3) |
| 5. PLUG | 14. NUT (3) |
| 6. OIL PAN (M915/BIG CAM I) | 15. ENGINE SHIPPING SUPPORT |
| 7. PIPE PLUG (2) | 16. SPACER |
| 8. PLUG | 17. PLUG |
| 9. PIPE PLUG | |

3-43. OIL PAN, DIPSTICK, OIL SUCTION TUBES, AND BREATHER TUBE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)



12. Oil level dipstick (20), oil level dipstick tube (19), clamp (21), and cover (22)	Inspect for the following: a. Cracks in area where clamp (21) is positioned around oil level dipstick tube (19). b. Stress cracks in area where oil level dipstick tube (19) fits in cover (22). c. Tightened seal where oil level dipstick (20) tightens against inside of oil level dipstick tube (19). d. Cracks in oil level dipstick (20).	Discard if cracked. This requires careful examination. Discard both if cracked. Do not separate oil level dipstick tube (19) from cover (22). Discard oil level dipstick (20) if seal is worn. Discard if cracked.
13. Tube brace (18)	Inspect for cracks.	Discard if cracked.

NOTE


- Perform step 14 for M915/Big Cam I only.
- Perform step 15 for M915A1/Big Cam III only.

14. Oil suction hose (24) (M915/Big Cam I), adapter (28), bracket (27), spacer (26), and clamp (25)	Inspect for cracks or damage caused by rubbing from vibration.	Discard if cracked, worn, or damaged.
15. Oil suction tube (23) (M915A1/Big Cam III)	Inspect for cracks or other damage.	Discard if cracked or damaged.

3-43. OIL PAN, DIPSTICK, OIL SUCTION TUBES, AND BREATHER TUBE REPAIR (Contd)



(M915/BIG CAM I)



(M915A1/BIG CAM III)

LEGEND:

- 18. TUBE BRACE
- 19. OIL LEVEL DIPSTICK TUBE
- 20. OIL LEVEL DIPSTICK
- 21. CLAMP
- 22. COVER

- 24. OIL SUCTION HOSE (M915/BIG CAM I)
- 25. CLAMP
- 26. SPACER
- 27. BRACKET
- 28. ADAPTER

- 23. OIL SUCTION TUBE (M915A1/BIG CAM III)

3-43. OIL PAN, DIPSTICK, OIL SUCTION TUBES, AND BREATHER TUBE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


c. Inspection (Contd)

NOTE


- Perform steps 16 and 17 for M915/Big Cam I only.
- Perform steps 18 and 19 for M915A1/Big Cam III only.

16. Breather tube (29), two clamps (30), and clamp (32)	Inspect for cracks and distortion.	Discard if cracked or distorted.
17. Hose (31)	Inspect for damage and deterioration caused by heat, oil, and rubbing from vibration.	Discard if worn or deteriorated.
18. Breather tube (33), two clamps (34), tube (37), clamps (38) and (39), and aftercooler bracket (40)	Inspect for cracks and distortion.	Discard if cracked or distorted.
19. Hoses (35) and (36)	Inspect for damage and deterioration caused by heat, oil, and rubbing from vibration.	Discard if worn or deteriorated.
20. All mounting hardware	Inspect for stripped threads, distortion, and extensive corrosion.	Discard if damaged.

3-43. OIL PAN, DIPSTICK, OIL SUCTION TUBES, AND BREATHER TUBE REPAIR (Contd)



M915/BIG CAM I



M915A1/BIG CAM III

LEGEND:

- 29. BREATHER TUBE (M915/BIG CAM I)
- 30. CLAMP (2)
- 31. HOSE
- 32. CLAMP
- 33. BREATHER TUBE (M915A1/BIG CAM III)
- 34. CLAMP (2)

- 35. HOSE
- 36. HOSE
- 37. TUBE
- 38. CLAMP
- 39. CLAMP
- 40. AFTERCOOLER BRACKET

3-43. OIL PAN, DIPSTICK, OIL SUCTION TUBES, AND BREATHER TUBE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly


NOTE

- Perform steps 21 and 22 for M915/Big Cam I only.
- Perform steps 23 and 24 for M915A1/Big Cam III only.


21. Strainer element (4) and four screws (3)	Install on oil pan (6).	
22. Plug (5), spacer (1), and plug (2)	Install on oil pan (6).	
23. Pipe plug (9), spacer (16), plugs (17) and (8), and two pipe plugs (7)	Install on oil pan (10).	
24. Tube (11), three clamps (12), washers (13), and nuts (14)	Install on welded studs on oil pan (10).	

FOLLOW-ON TASK: Install oil pan and oil suction tube (para. 3-81).

3-43. OIL PAN, DIPSTICK, OIL SUCTION TUBES, AND BREATHER TUBE REPAIR (Contd)



**M915/BIG CAM I OIL PAN
(CAST ALUMINUM)**



**M915A1/BIG CAM III OIL PAN
(STAMPED STEEL)**

LEGEND:

- 1. SPACER
- 2. PLUG
- 3. SCREW (4)
- 4. STRAINER ELEMENT
- 5. PLUG
- 6. OIL PAN (M915/BIG CAM I)
- 7. PIPE PLUG (2)
- 8. PLUG
- 9. PIPE PLUG

- 10. OIL PAN (M915A1/BIG CAM III)
- 11. TUBE
- 12. CLAMP (3)
- 13. WASHER (3)
- 14. NUT (3)
- 15. ENGINE SHIPPING SUPPORT
- 16. SPACER
- 17. PLUG

3-44. OIL PUMP REPAIR

THIS TASK COVERS:

- a. Disassembly
- b. Cleaning

- c. Inspection
- d. Assembly

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Spacer mandrel (15434) ST-1157
 DFC pressure valve fixture (15434) 3376011

TEST EQUIPMENT

None

MATERIALS/PARTS

Solvent, SD-3 (Appendix C, Item 30)
 Oil, lubricating, OE/HDO 10 (Appendix C, Item 20)
 Sealant, thread (liquid) (Appendix C, Item 27)
 Gasket (15434) 203145 (M915/Big Cam I)
 Gasket (15434) 3014778 (M915A1/Big Cam III)
 Three lockwashers (15434) S610
 (M915/Big Cam I)
 Two preformed packings (15434) 145504
 (M915A1/Big Cam III)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Oil pump removed (para. 3-19).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

- Wear eye protection when cleaning with compressed air and when removing pressure regulator assembly.
- Use solvents in well-ventilated area and away from open flame.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


a. Disassembly

NOTE

- Perform steps 1 through 10 for M915/Big Cam I only.
- Perform steps 11 through 18 for M915A1/Big Cam III only.

1. Gear (28) and woodruff key (9)	Remove from shaft (11).	Use a suitable gear puller.
2. Snapring (21) and coupling (20)	Remove from shaft (11).	
3. Screw (19), washer (18), screw (22), washer (24), screw (26), three screws (23), and lockwashers (25)	Remove from body (7) and housing (16).	Discard lockwashers (25).
4. Housing (16) and gasket (15)	Remove from pin (10) and body (7).	Use a soft-nose hammer to loosen housing (16).

3-44. OIL PUMP REPAIR (Contd)



M915/BIG CAM I

LEGEND:

- | | | |
|-----------------------|-----------------------|--------------------|
| 1. SCREW | 11. SHAFT | 21. SNAPRING |
| 2. LOCKPLATE | 12. OIL PUMPING GEAR | 22. SCREW |
| 3. RETAINING YOKE | 13. SPLIT BUSHING (2) | 23. SCREW (3) |
| 4. SPRING | 14. GEAR | 24. WASHER |
| 5. PLUNGER | 15. GASKET | 25. LOCKWASHER (3) |
| 6. PIPE PLUG | 16. HOUSING | 26. SCREW |
| 7. BODY | 17. CONNECTOR | 27. SHAFT |
| 8. SLEEVE BEARING (3) | 18. WASHER | 28. GEAR |
| 9. WOODRUFF KEY | 19. SCREW | |
| 10. PIN | 20. COUPLING | |

3-44. OIL PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)


5. Gear (14)	Remove from shaft (27).	Lift gear off shaft (27).
6. Shaft (11) and oil pumping gear (12)	Remove from body (7).	Use suitable arbor press.
7. Shaft (11)	Remove from oil pumping gear (12).	Use suitable arbor press.
8. Shaft (27)	Remove from body (7).	Use suitable arbor press.
9. Connector (17) and pipe plug (6)	Remove from housing (16) and body (7).	

WARNING

Remove pressure regulator assembly slowly to prevent spring tension from shooting regulator assembly from oil pump body. Wear eye protection. Failure to comply may result in damage to equipment or injury to personnel.

10. Screw (1), lockplate (2), retaining yoke (3), spring (4), and plunger (5)	Remove from body (7).	
-------------------------------------------------------------------------------	-----------------------	--

3-44. OIL PUMP REPAIR (Contd)



M915/BIG CAM I

LEGEND:

- | | |
|-------------------|----------------------|
| 1. SCREW | 10. PIN |
| 2. LOCKPLATE | 11. SHAFT |
| 3. RETAINING YOKE | 12. OIL PUMPING GEAR |
| 4. SPRING | 14. GEAR |
| 5. PLUNGER | 15. GASKET |
| 6. PIPE PLUG | 16. HOUSING |
| 7. BODY | 17. CONNECTOR |
| 9. WOODRUFF KEY | 27. SHAFT |

3-44. OIL PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)


11. Retaining ring (42) and steering pump coupling (43)	Remove from shaft (36).	
12. Gear (54) and woodruff key (34)	Remove from shaft (36).	Use a suitable gear puller.
13. Seven captive washer screws (44), cover (40), and gasket (39)	Remove from pin (35) and body (29).	Use a soft-nose hammer to loosen cover (40). Discard gasket (39).
14. Gear (46)	Remove from shaft (47).	Lift gear (46) off shaft (47).
15. Shaft (36) and gear (37)	Remove from body (29).	Use suitable arbor press.
16. Shaft (36)	Remove from gear (37).	Use suitable arbor press.
17. Shaft (47)	Remove from body (29).	

WARNING

Remove pressure regulator assembly slowly to prevent spring tension from shooting assembly from oil pump body. Wear eye protection. Failure to comply may result in damage to equipment or injury to personnel.

18. Screw (53), washer (52), retainer (51), two preformed packings (50), spring (49), and plunger (48)	Remove from body (29).	Discard preformed packings (50).
--------------------------------------------------------------------------------------------------------	------------------------	----------------------------------

3-44. OIL PUMP REPAIR (Contd)



M915A1/BIG CAM III

LEGEND:

- 29. BODY
- 30. BYPASS VALVE SPRING
- 31. WASHER
- 32. VALVE DISK
- 33. BYPASS VALVE SEAT
- 34. WOODRUFF KEY
- 35. PIN
- 36. SHAFT
- 37. OIL PUMPING GEAR

- 38. SLEEVE BEARING
- 39. GASKET
- 40. COVER
- 41. PIPE PLUG
- 42. RETAINING RING
- 43. STEERING PUMP COUPLING
- 44. CAPTIVE WASHER SCREW (7)
- 45. SLEEVE BEARING (2)
- 46. GEAR

- 47. SHAFT
- 48. PLUNGER
- 49. SPRING
- 50. PREFORMED PACKING (2)
- 51. RETAINER
- 52. WASHER
- 53. SCREW
- 54. GEAR
- 55. SLEEVE BEARING (2)

3-44. OIL PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)

19. Pipe plug (41)	Remove from cover (40).	
20. Bypass valve seat (33), valve disc (32), washer (31), and bypass valve spring (30)	Remove from body (29).	Use caution not to damage bypass valve seat (33) during removal.

b. Cleaning

WARNING


- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

NOTE

Cleaning procedures are the same for M915/Big Cam I and M915A1/Big Cam III oil pump assemblies. M915A1/Big Cam III is shown.

21. All parts	Clean with SD-3 solvent and dry with compressed air.	Refer to para. 3-6 for cleaning instructions. Ensure all drilled passages are opened and cleaned.
---------------	------------------------------------------------------	---------------------------------------------------------------------------------------------------

3-44. OIL PUMP REPAIR (Contd)



M915A1/BIG CAM III

LEGEND:

- 29. BODY
- 30. BYPASS VALVE SPRING
- 31. WASHER
- 32. VALVE DISC
- 33. BYPASS VALVE SEAT
- 34. WOODRUFF KEY
- 35. PIN
- 36. SHAFT
- 37. GEAR

- 38. SLEEVE BEARING
- 39. GASKET
- 40. COVER
- 41. PIPE PLUG
- 42. RETAINING RING
- 43. STEERING PUMP COUPLING
- 44. CAPTIVE WASHER SCREW (7)
- 45. SLEEVE BEARING (2)
- 46. GEAR

- 47. SHAFT
- 48. PLUNGER
- 49. SPRING
- 50. PREFORMED PACKING (2)
- 51. RETAINER
- 52. WASHER
- 53. SCREW
- 54. GEAR
- 55. SLEEVE BEARING (2)

3-44. OIL PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection

NOTE

Inspection procedures are the same, including all corresponding measurements, for M915/Big Cam I and M915A1/Big Cam III oil pump assemblies. M915A1/Big Cam III is shown.

22. Gears (37) and (46) and pump drive gear (54)	Inspect for excessive wear, cracks, chips, or missing gear teeth.	Replace if worn, cracked, chipped, or broken.
23. Two sleeve bearings (55) and sleeve bearing (38)	a. Measure inside diameter.	If inside diameter exceeds 0.879 in. (22.327 mm), replace sleeve bearing.

CAUTION

New sleeve bearings must be reamed to size after installation. Sleeve bearings in pump cover and body must be line-reamed with cover installed on body to ensure accuracy.

NOTE

Perform steps 23b through 23d only if bushings will be replaced.


24. Dowel pin (35)	b. Press out. c. Press in three new sleeve bearings (55) and (38) in body (29) and cover (40). d. Line-ream inside diameter of two new sleeve bearings (55) and (38) to 0.8767-0.8777 in. (22.268-22.294 mm). a. Inspect for damage.	Use suitable mandrel. Do not press sleeve bearings (55) and (38) more than 0.020 in. (0.508 mm) below top surface of body (29). After reaming, thoroughly clean body (29), sleeve bearings (55), and sleeve bearing (38).
--------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

NOTE

Perform steps 24b and 24c if dowel pin is damaged and will be replaced.

25. Body (29)	b. Remove using suitable dowel pin extractor. c. Install using suitable arbor press. Inspect for the following: a. Cracks or damage. b. Damaged or distorted threads. c. Gasket surface for scratches, wear, or damage.	Discard if cracked. Chase damaged or distorted threads with suitable tap. Replace if excessively worn or damaged.
26. Sleeve bearing (45) on gear (46)	a. Measure inside diameter.	One sleeve bearing (45) is located on gear (46). If inside diameter exceeds 0.879 in. (22.327 mm), replace sleeve bearing (45).

3-44. OIL PUMP REPAIR (Contd)



M915A1/BIG CAM III

LEGEND:

- | | |
|----------------------|------------------------------|
| 29. BODY | 40. COVER |
| 34. WOODRUFF KEY | 44. CAPTIVE WASHER SCREW (7) |
| 35. PIN | 45. SLEEVE BEARING (2) |
| 36. SHAFT | 46. GEAR |
| 37. OIL PUMPING GEAR | 47. SHAFT |
| 38. SLEEVE BEARING | 54. PUMP DRIVE GEAR |
| 39. GASKET | 55. SLEEVE BEARING (2) |

3-44. OIL PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

NOTE

Perform steps 26b through 26d if gear sleeve bearing will be replaced.


	b. Press out. c. Press in new sleeve bearing (45) more than 0.020 in. (0.508 mm). d. Line-ream new sleeve bearing (45) inner diameter to 0.8767-0.8777 in. (22.268-22.293 mm).	Use suitable mandrel. Do not press bushing below top surface of gear (46). Thoroughly clean gear (46) and sleeve bearing (45) after reaming.
27. Pump cover (40)	Inspect for the following: a. Cracks or damage. b. Gasket surface for scratches or damage.	Discard if cracked. Discard if damaged.
28. Sleeve bearing (45) on cover (40)	a. Measure inside diameter.	If inside diameter of sleeve bearing (45) exceeds 0.879 in. (22.327 mm), replace sleeve bearing (45).

NOTE

Perform steps 28b through 28d if pump cover assembly sleeve bearing will be replaced.

	b. Press out. c. Press in new sleeve bearing (45). d. Line-ream inner diameter of new sleeve bearing (45) to 0.8767-0.8777 in. (22.268-22-294 mm).	Use suitable mandrel. Thoroughly clean pump cover (40) and sleeve bearing (45) after reaming.
29. Drive shaft (36) and idler shaft (47)	Inspect for the following: a. Galling, breaks, or cracks. b. Check outside diameter using micrometer. c. Wear on woodruff key slot on shaft (36).	Replace, if galled, broken, or cracked. If outside diameter is less than 0.874 in. (22.20 mm), discard. Discard if woodruff key (34) fits loosely.
30. Pressure regulator plunger (48)	Verify it moves freely in bore of body (29).	Discard if it sticks, binds, or is excessively loose.
31. Valve disc (32)	Inspect for damage.	Discard if damaged.
32. Bypass valve spring (30)	Inspect for damage, breaks, or weakness.	Discard if damaged, broken, or weak.
33. Power steering pump coupling (43)	Inspect for internal wear or cracks in spline area.	Discard if worn or cracked.
34. Woodruff key (34)	Inspect for wear or cracks.	Discard if any wear or cracks are noticeable.

3-44. OIL PUMP REPAIR (Contd)



M915A1/BIG CAM III

LEGEND:

- | | |
|----------------------------------|---------------------------|
| 29. BODY | 45. SLEEVE BEARING (2) |
| 30. BYPASS VALVE SPRING | 46. GEAR |
| 31. WASHER | 47. SHAFT |
| 32. VALVE DISC | 48. PLUNGER |
| 33. BYPASS VALVE SEAT | 49. SPRING |
| 34. WOODRUFF KEY | 50. PREFORMED PACKING (2) |
| 36. DRIVE SHAFT | 51. RETAINER |
| 40. PUMP COVER | 52. WASHER |
| 42. RETAINING RING | 53. SCREW |
| 43. POWER STEERING PUMP COUPLING | |

3-44. OIL PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


d. Assembly

NOTE

- Perform steps 35 through 42 for M915/Big Cam I only.
- Perform steps 43 through 52 for M915A1/Big Cam III only.

35. Gear (12)	Install on shaft (11) 2.125-2.250 in. (53.975-57.15 mm) from splined end of shaft (11).	Use suitable arbor press.
36. Shaft (11)	Install on body (7). Place 0.060-0.070 in. (1.52-1.78 mm) feeler gauge between gear (12) and body (7) and further press gear (12) on shaft (11).	Oil pumping gear-to-body clearance must be 0.060-0.070 in. (1.52-1.78 mm).
37. Shaft (27)	Install on body (7) so that large diameter end protrudes 0.9375-1.0 in. (23.81-25.40 mm) above body on face of housing (16).	Use suitable arbor press.
38. Gear(14)	Install on shaft (27).	Lubricate gears, shafts, bushings, and gear pockets with OE/HDO 10 lubricating oil.
39. Plunger (5), spring (4), retaining yoke (3), lockplate (2), and screw (1)	Install on body (7).	
40. New gasket (15), housing (16), three new lockwashers (25), screws (23), washer (18), screw (19), washer (24), and screw (22)	Install on body (7).	Tighten screws (23), (19), and (22) to 35 lb-ft (48 N•m). Rotate shaft (11) to ensure gears turn free.
41. Woodruff key (9), drive gear (28), coupling (20), and snapping (21)	Install on shaft (11) and check shaft (11) end play.	Use suitable arbor press. End play should be 0.002-0.008 in. (0.05-0.20 mm).
42. Pipe plug (6) and connector (17)	Install on body (7) and housing (16).	Coat threads with liquid thread sealant.

3-44. OIL PUMP REPAIR (Contd)



M915/BIG CAM I

LEGEND:

- | | | |
|-----------------------|-----------------------|--------------------|
| 1. SCREW | 11. SHAFT | 21. SNAPRING |
| 2. LOCKPLATE | 12. OIL PUMPING GEAR | 22. SCREW |
| 3. RETAINING YOKE | 13. SPLIT BUSHING (2) | 23. SCREW (3) |
| 4. SPRING | 14. GEAR | 24. WASHER |
| 5. PLUNGER | 15. GASKET | 25. LOCKWASHER (3) |
| 6. PIPE PLUG | 16. HOUSING | 26. SCREW |
| 7. BODY | 17. CONNECTOR | 27. SHAFT |
| 8. SLEEVE BEARING (3) | 18. WASHER | 28. GEAR |
| 9. WOODRUFF KEY | 19. SCREW | |
| 10. PIN | 20. COUPLING | |

3-44. OIL PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


d. Assembly (Contd)

NOTE

Lubricate all moving parts prior to assembly with OE/HDO 10 lubricating oil.

43. Shaft (47)	Press large diameter end until it protrudes a minimum of 0.705 in. (17.907 mm) and a maximum of 0.735 in. (18.669 mm) from cover face of body (29).	Use suitable arbor press to install shaft (47). The cover face is at the opposite side of gasket surface.
44. Oil pumping gear (37)	Press on shaft (36) until it protrudes a minimum of 1.990 in. (50.546 mm) and a maximum of 2.010 in. (51.054 mm) from gasket surface of body (29).	Use suitable arbor press to install gear (37).
45. Shaft (36), gear (37), woodruff key (34), and gear (54)	<p>Install as follows:</p> <p>a. Slide shaft (36) and gear (37) through sleeve bearings (55) on body (29).</p> <p>b. Insert woodruff key (34) in keyway of shaft (36).</p> <p>c. Press gear (54) until shaft (36) protrudes a minimum of 0.050 in. (1.270 mm) and has a maximum end play of 0.070 in. (1.778 mm) from gear (54).</p>	Use shallow end of spacer mandrel (ST-1157).
46. Gear (46)	Install on shaft (47).	
47. Bypass valve spring (30), washer (31), valve disc (32), and bypass valve seat (33)	Install on body (29).	Use DFC pressure valve fixture (3376011) for installation. Ensure the prongs of valve disc (32) are pointing down during installation.

3-44. OIL PUMP REPAIR (Contd)



M915A1/BIG CAM III

LEGEND:

- 29. BODY
- 30. BYPASS VALVE SPRING
- 31. WASHER
- 32. VALVE DISC
- 33. BYPASS VALVE SEAT
- 34. WOODRUFF KEY
- 35. PIN
- 36. SHAFT

- 37. OIL PUMPING GEAR
- 38. SLEEVE BEARING
- 40. COVER
- 45. SLEEVE BEARING (2)
- 46. GEAR
- 47. SHAFT
- 54. GEAR
- 55. SLEEVE BEARING (2)

3-44. OIL PUMP REPAIR (Contd)


LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)

48. New gasket (39) and cover (40)	Install on dowel pin (35) and body (29).	It may be necessary to tap on the cover (40) lightly with a soft-nose hammer to seat cover on dowel pin (35).
49. Seven captive washer screws (44)	Install on cover (40) and body (29).	Tighten captive washer screws (44) to 35 lb-ft (48 N•m). Rotate shaft (36) to ensure gears turn free.
50. Plunger (48), spring (49), two new preformed packings (50), retainer (51), washer (52), and screw (53)	Install on body (29).	Tighten screw (53) to 35 lb-ft (48 N•m). Be certain pressure regulator plunger (48) slides freely within bore. Rotate shaft (36) and check end play to ensure it is within 0.002 in. (0.051 mm) minimum and 0.005 in. (0.127 mm) maximum range.
51. Pipe plug (41)	Install on cover (40).	Tighten pipe plug (41) to 30 lb-ft (41 N•m). Coat threads with liquid thread sealant.
52. Steering pump coupling (43) and retaining ring (42)	Install on shaft (36).	

FOLLOW-ON TASK: Install oil pump (para. 3-74).

3-44. OIL PUMP REPAIR (Contd)



M915A1/BIG CAM III

LEGEND:

- 29. BODY
- 35. DOWEL PIN
- 36. SHAFT
- 39. GASKET
- 40. COVER
- 41. PIPE PLUG
- 42. RETAINING RING
- 43. STEERING PUMP COUPLING

- 44. CAPTIVE WASHER SCREW (7)
- 48. PLUNGER
- 49. SPRING
- 50. PREFORMED PACKING (2)
- 51. RETAINER
- 52. WASHER
- 53. SCREW

3-45. AIR AFTERCOOLER REPAIR

THIS TASK COVERS:

- | | |
|-----------------------------------------------------|----------------------------------------------------|
| <p>a. Disassembly
b. Cleaning</p> | <p>c. Inspection
d. Assembly</p> |
|-----------------------------------------------------|----------------------------------------------------|

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Solvent, SD-3 (Appendix C, Item 30)
 Oil, lubricating, OE/HDO 10
 (Appendix C, Item 20)
 Four preformed packings (15434) 195952
 Aftercooler cover gasket (15434) 216486
 Water outlet connection gasket (15434) 215044
 Water inlet connection gasket (15434) 3032348
 Three lockwashers (96906) MS35338-45
 (M915A1/Big Cam III)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Air aftercooler removed (para. 3-20).

SPECIAL ENVIRONMENTAL CONDITIONS

None

GENERAL SAFETY INSTRUCTIONS

- Always wear eye protection when cleaning with compressed air.
- Use approved solvent in well-ventilated area.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly

- | | | |
|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------------|---------------------------------------------------|
| <p>1. Three screws (3), washers (M915/Big Cam I), or lockwashers (M915A1/Big Cam III) (2)</p> | <p>Remove from aftercooler cover (14).</p> | <p>Discard lockwashers (2).</p> |
| <p>2. Water outlet connection (1) and gasket (15)</p> | <p>Remove from aftercooler cover (14).</p> | <p>Pry out if necessary. Discard gasket (15).</p> |
| <p>3. Twenty-four screws (M915/Big Cam I) or captive washer screws (M915A1/Big Cam III) (4)</p> | <p>Remove from aftercooler cover (14) and intake manifold (12).</p> | |

NOTE

It may require some force to separate aftercooler cover from intake manifold.

- | | | |
|----------------------------------------------------------------------|-----------------------------------------------------------------------|----------------------------|
| <p>4. Aftercooler cover (14) and gasket (5) (M915A1/Big Cam III)</p> | <p>Remove from intake manifold (12) and aftercooler element (13).</p> | <p>Discard gasket (5).</p> |
|----------------------------------------------------------------------|-----------------------------------------------------------------------|----------------------------|


NOTE

Perform step 5 for M915A1/Big Cam III only.

- | | | |
|----------------------------------------------|-----------------------------------------------------------------------|--|
| <p>5. Eight screws (11) and washers (10)</p> | <p>Remove from aftercooler element (13) and intake manifold (12).</p> | |
|----------------------------------------------|-----------------------------------------------------------------------|--|

3-45. AIR AFTERCOOLER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
6. Two screws (M915/Big Cam I) or captive washer screws (M915A1/Big Cam III) (9)	Remove from intake manifold (12) and water inlet connection (8).	
7. Water inlet connection (8) and gasket (7)	Remove from intake manifold (12).	Discard gasket (7).
8. Aftercooler element (13) and gasket (5) (M915/Big Cam I)	Remove from intake manifold (12).	Discard gasket (5).
9. Four preformed packings (6)	Remove from aftercooler element (13).	Discard preformed packings (6).



LEGEND:

- 1. WATER OUTLET CONNECTION
- 2. WASHER (3) (M915/BIG CAM I), LOCKWASHER (3) (M915A1/BIG CAM III)
- 3. SCREW (3)
- 4. SCREW (24) (M915/BIG CAM I), CAPTIVE WASHER SCREW (24) (M915A1/BIG CAM III)
- 5. GASKET
- 6. PREFORMED PACKING (4)
- 7. GASKET

- 8. WATER INLET CONNECTION
- 9. SCREW (2) (M915/BIG CAM I), CAPTIVE WASHER SCREW (2) (M915A1/BIG CAM III)
- 10. WASHER (8)
- 11. SCREW (8)
- 12. INTAKE MANIFOLD
- 13. AFTERCOOLER ELEMENT
- 14. AFTERCOOLER COVER
- 15. GASKET

3-45. AIR AFTERCOOLER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Cleaning

WARNING

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

10. Water outlet connection (1), aftercooler cover (14), intake manifold (12), water inlet connection (8), and all mounting hardware	Steam clean and dry with compressed air.	Use SD-3 solvent.
--------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------	-------------------

CAUTION


The aftercooler element is made from a copper alloy. Using a cleaning solution not made for copper alloy may cause corrosion.

11. Aftercooler element (13)	Clean and dry with compressed air.	Use cleaning solution made especially for copper alloy.
------------------------------	------------------------------------	---------------------------------------------------------

c. Inspection

12. Water outlet connection (1), aftercooler cover (14), water inlet connection (8), and intake manifold (12)	Inspect for cracks, distortion, or damaged threads.	Discard if cracked or distorted. Repair damaged threads with correct thread tap.
13. Aftercooler element (13)	Inspect and test for leaks as follows: <ol style="list-style-type: none"> a. Cap one end air-tight. b. Connect a suitable pressure tester to remaining open end of aftercooler element (13). c. Apply 20 psi (138 kPa) and maintain pressure for two minutes. d. Immerse in water while maintaining 20 psi (138 kPa) and look for air bubbles. 	If a leak is detected, repairs should be made by an individual qualified in repairing radiator cores.

3-45. AIR AFTERCOOLER REPAIR (Contd)



LEGEND:

- 1. WATER OUTLET CONNECTION
- 8. WATER INLET CONNECTION
- 12. INTAKE MANIFOLD
- 13. AFTERCOOLER ELEMENT
- 14. AFTERCOOLER COVER

3-45. AIR AFTERCOOLER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly

- | | | |
|-------------------------------------|-------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|
| 14. Four new preformed packings (6) | Install on inlet and outlet fittings of aftercooler element (13). | Lubricate four new preformed packings (6) with OE/HDO 10 lubricating oil prior to installation. |
|-------------------------------------|-------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|

NOTE
Perform steps 15b and 16 for M915A1/Big Cam III only.

- | | | |
|------------------------------------------------------------------|---------------------------------------------|---------------------------------------------|
| 15. New gasket (5) (M915/Big Cam I) and aftercooler element (13) | Install on intake manifold (12) as follows: | Ensure holes in new gasket (5) are aligned. |
|------------------------------------------------------------------|---------------------------------------------|---------------------------------------------|

NOTE
The aftercooler element has a precision fit in intake manifold. Move element carefully during installation.


- | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> a. Position on intake manifold (12) and gasket (5) (M915/Big Cam I). b. Check clearance at two locations between aftercooler element (13) and intake manifold (12) as shown. | <p>When measuring clearance, hold aftercooler element (13) against side of intake manifold (12). Clearance must not be less than 0.003 in. (0.076 mm) or more than 0.013 in. (0.330 mm).</p> |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

- | | | |
|----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
| 16. Eight washers (10) and screws (11) | <p>Install on intake manifold (12) to secure aftercooler element (13) as follows:</p> <ul style="list-style-type: none"> a. Carefully align holes. b. Tighten four center screws to 15 lb-ft (20 N•m). c. Tighten four end screws to 15 lb-ft (20 N•m). d. Tighten four center screws to 25 lb-ft (34 N•m). e. Tighten four end screws to 25 lb-ft (34 N•m). | Use tightening sequence shown. |
|----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|

CAUTION
When installing water inlet connection and water outlet connection, be careful not to damage or distort new preformed packings.

- | | | |
|-----------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------|---------------------------------------------|
| 17. New gasket (7), water inlet connection (8), and two screws (M915/Big Cam I) or captive washer screws (M915A1/Big Cam III) (9) | Install on intake manifold (12) finger-tight. | |
| 18. New gasket (5) (M915A1/Big Cam III) and aftercooler cover (14) | Install on aftercooler element (13). | Ensure holes in new gasket (5) are aligned. |

3-45. AIR AFTERCOOLER REPAIR (Contd)



LEGEND:

- | | |
|---------------------------------------------------------------------------------|-------------------------|
| 5. GASKET | 10. WASHER (8) |
| 6. PREFORMED PACKING (4) | 11. SCREW (8) |
| 7. GASKET | 12. INTAKE MANIFOLD |
| 8. WATER INLET CONNECTION | 13. AFTERCOOLER ELEMENT |
| 9. SCREW (2) {M915/BIG CAM I}, CAPTIVE WASHER
SCREW (2) {M915A1/BIG CAM III} | 14. AFTERCOOLER COVER |

3-45. AIR AFTERCOOLER REPAIR (Contd)


LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)

19. Twenty-four screws (M915/Big Cam I) or captive washer screws (M915A1/Big Cam III) (4)	Install on aftercooler cover (14) and intake manifold (12).	Do not tighten at this time.
20. New gasket (15), water outlet connection (1), three washers (M915/Big Cam I) or new lockwashers (M915A1/Big Cam III) (2), and screws (3)	Install on aftercooler cover (14).	Use caution not to damage new preformed packings (6). Do not tighten screws (3) at this time.
21. Two screws (M915/Big Cam I) or captive washer screws (M915A1/Big Cam III) (9)	Tighten to 32 lb-ft (43 N•m).	
22. Twenty-four screws (M915/Big Cam I) or captive washer screws (M915A1/Big Cam III) (4)	Tighten to 25 lb-ft (34 N•m).	Use tightening sequence shown.
23. Three screws (3)	Tighten to 20 lb-ft (27 N•m).	

FOLLOW-ON TASK: Install air aftercooler on engine (para. 3-87).

3-45. AIR AFTERCOOLER REPAIR (Contd)



LEGEND:

- 1. WATER OUTLET CONNECTION
- 2. WASHER (3) (M915/BIG CAM I), LOCKWASHER (3) (M915A1/BIG CAM III)
- 3. SCREW (3)
- 4. SCREW (24) (M915/BIG CAM I), CAPTIVE WASHER SCREW (24) (M915A1/BIG CAM III)

- 5. SCREW (2) (M915/BIG CAM I), CAPTIVE WASHER SCREW (2) (M915A1/BIG CAM III)
- 6. INTAKE MANIFOLD
- 7. AFTERCOOLER COVER
- 8. GASKET

3-46. EXHAUST MANIFOLD REPAIR

THIS TASK COVERS:

- | | |
|-----------------------------------------------------|----------------------------------------------------|
| <p>a. Disassembly
b. Cleaning</p> | <p>c. Inspection
d. Assembly</p> |
|-----------------------------------------------------|----------------------------------------------------|

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Compound, antiseize (Appendix C, Item 7)
Sealant, pipe (Appendix C, Item 26)
Two spacer inserts (15434) 3020718

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

TM 9-2320-273-20
TM 9-2320-283-20

TROUBLESHOOTING REFERENCES

None

EQUIPMENT CONDITION

Exhaust manifold removed (para. 3-13).

SPECIAL ENVIRONMENTAL CONDITIONS

None

GENERAL SAFETY INSTRUCTIONS

Eye protection must be worn when using wire brush for cleaning.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

NOTE

M915/Big Cam I engines utilize a conventional log-type exhaust manifold. M915A1/Big Cam III engines utilize a pulse-type exhaust manifold and a new design exhaust manifold with two spacer inserts. Disassembly and repair of manifolds is basically the same.

a. Disassembly

- | | | |
|--------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------|
| <p>1. Rear exhaust manifold (1), center exhaust manifold (2), and front exhaust manifold (4)</p> | <p>Separate (1), (2), and (4) on early design and two spacer inserts (6) on new design for M915A1/Big Cam III only.</p> | <p>Exertion of force may be required to separate the three sections.</p> |
| <p>2. Two pipe plugs (3) (M915/Big Cam I only)</p> | <p>Remove from center exhaust manifold (2).</p> | |


b. Cleaning

WARNING


Eye protection must be worn when using wire brush for cleaning. Failure to comply may result in injury to personnel.

- | | | |
|--------------------------------------------------------------------------------------------------|---------------------------------------------------|------------------------------------------------------------|
| <p>3. Rear exhaust manifold (1), center exhaust manifold (2), and front exhaust manifold (4)</p> | <p>Remove carbon and rust with steam cleaner.</p> | <p>Use a suitable wire wheel to clean mating surfaces.</p> |
|--------------------------------------------------------------------------------------------------|---------------------------------------------------|------------------------------------------------------------|


3-46. EXHAUST MANIFOLD REPAIR (Contd)



M915/BIG CAM I



M915A1/BIG CAM III



M915A1/BIG CAM III - NEW DESIGN

LEGEND:

- | | |
|-----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| <p>1. REAR EXHAUST MANIFOLD</p> <p>2. CENTER EXHAUST MANIFOLD</p> <p>3. PIPE PLUG (2) (M915/BIG CAM I ONLY)</p> | <p>4. FRONT EXHAUST MANIFOLD</p> <p>5. STUD (4)</p> <p>6. SPACER INSERTS (2) NEW DESIGN EXHAUST MANIFOLD (M915A1/BIG CAM III ONLY)</p> |
|-----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|

3-46. EXHAUST MANIFOLD REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection


- | | | |
|-------------------------------------------------------------------------------------------|----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| 4. Rear exhaust manifold (1), center exhaust manifold (2), and front exhaust manifold (4) | Inspect for cracks or heat distortion at mating surfaces or flanges. | Discard if cracked or distorted. |
| 5. Four turbocharger mounting studs (5) | Inspect for damaged threads or wear around unthreaded area. | Chase threads if damaged. Replace if worn or threads are stripped. Coat threads of new stud(s) (5) with antiseize compound. |

d. Assembly


- | | | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------|---------------------------------------------------------------------|
| 6. Two pipe plugs (3) (M915/ Big Cam I only) | Install on center exhaust manifold (2). | Apply pipe sealant to threads of pipe plugs (3). |
| 7. Rear exhaust manifold (1), center exhaust manifold (2), front exhaust manifold (4), and two spacer inserts (6) (on M915A1/ Big Cam III with new design manifold only) | Assemble. | Apply antiseize compound to mating surfaces to facilitate assembly. |

FOLLOW-ON TASK: Install exhaust manifold (para. 3-88).


3-46. EXHAUST MANIFOLD REPAIR (Contd)



M915/BIG CAM I



M915A1/BIG CAM III



M915A1/BIG CAM III - NEW DESIGN

LEGEND:

- | | |
|-----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| <p>1. REAR EXHAUST MANIFOLD</p> <p>2. CENTER EXHAUST MANIFOLD</p> <p>3. PIPE PLUG (2) (M915/BIG CAM I ONLY)</p> | <p>4. FRONT EXHAUST MANIFOLD</p> <p>5. STUD (4)</p> <p>6. SPACER INSERTS (2) NEW DESIGN EXHAUST MANIFOLD (M915A1/BIG CAM III ONLY)</p> |
|-----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|

3-47. TURBOCHARGER REPAIR

THIS TASK COVERS:

- a. Disassembly
- b. Cleaning and Inspection

- c. Assembly

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

- Oil, lubricating, OE/HDO 30 (Appendix C, Item 21)
- Compound, antiseize (Appendix C, Item 7)
- Bearing insert pad (15434) 170510
- Two screws (15434) 194010
- Four washers (15434) 5-631
- Two locknuts (15434) 167299
- Insulation packing (15434) 202377
- Ring seal (15434) 154644
- Two turbocharger seals (15434) 3032836
- O-ring (15434) 202456
- Impeller locknut (15434) 3-222A

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

MI-I-6866

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Turbocharger removed (para. 3-13).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

- Machined edges on wheel and shaft and on turbocharger impeller are very sharp. Wear protective gloves.
- Always wear eye protection when using compressed air.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly

NOTE

The turbocharger used on the M915A1/Big Cam III has been changed for greater efficiency. The repair procedures for M915/Big Cam I and M915A1/Big Cam III turbocharger are the same. Only size and part numbers have changed.

1. Adapters (15) and (16)	Remove from housing (14).	
2. Housings (6), (14), and (21), and clamp (5)	Mark (5), (6), (14), and (21) to help in alignment during reassembly.	Make marks at convenient points with chalk or felt-tip marking pen (see illustration).
3. Two locknuts (7), screws (3), and four washers (4)	Remove from V-band clamp (5).	Discard screws (3), washers (4), and locknuts (7).
4. V-band clamp (5)	Remove from housing (14).	Retain damp (5) for reassembly.
5. Impeller housing (6)	Lift off housing (14).	Use soft-nose hammer to loosen impeller housing (6) from bearing housing (14).
6. Turbine housing (21) and bearing housing (14)	Position turbine housing (21) on workbench with mounting flange of exhaust manifold mating surface facing down.	Support bearing housing (14) with wood shim placed between workbench surface and bearing housing (14).

3-47. TURBOCHARGER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)


7. Wheel and shaft (20)	Insert brass drift or wood block through exhaust outlet end of turbine housing (21) and hold against balance lug nut on wheel end of wheel and shaft (20). Tap on drift or wood block to separate bearing housing (14) from turbine housing (21). Hold turbine housing (21) to prevent it from moving when striking wheel and shaft (20). Wheel and shaft (20), bearing housing (14), and turbocharger impeller (1) will separate from turbine housing (21).	Heat may cause turbine housing (21) and bearing housing (14) to seize. If necessary, install in press. Use shop rags to cushion wheel and shaft (20), bearing housing (14), and turbocharger impeller (1) as they drop from turbine housing (21).
8. Turbocharger impeller (1) and impeller locknut (2)	Partially remove impeller locknut (2).	Hold balance lug nut at wheel and shaft (20) end to keep turbocharger impeller (1) from turning.
9. Wheel and shaft (20), bearing housing (14), and turbocharger impeller (1)	Hold bearing housing (14) and tap impeller locknut (2) with soft hammer or install in press.	This will separate wheel and shaft (20) from bearing housing (14). If necessary to use press, remove impeller locknut (2).
10. Turbocharger impeller (1) and impeller locknut (2)	Remove and slide wheel and shaft (20), insulated packing (17), and heat shield (18) from bearing housing (14).	Discard impeller locknut (2).

CAUTION

Do not use sharp object to pry between diffuser plate and bearing housing. Failure to observe caution can result in damage to oil seal and turbocharger.

11. Bearing housing (14) and diffuser plate (10)	Remove diffuser plate (10) from bearing housing (14).	Use a 7/8-in. deepwell socket. Install at wheel and shaft (20) end and tap with soft hammer (see illustration).
12. Bearing housing (14), bearing (13), and bearing insert pad (12)	Remove bearing insert pad (12) and bearing (13).	Discard bearing insert pad (12).
13. Diffuser plate (10) and sleeve (8)	Remove sleeve (8).	Push out sleeve (8) with thumbs.
14. Diffuser plate (10) and O-ring (11)	Remove O-ring (11).	Discard O-ring (11).

3-47. TURBOCHARGER REPAIR (Contd)



LEGEND:

- 1. TURBOCHARGER IMPELLER
- 2. IMPELLER LOCKNUT
- 8. SLEEVE
- 10. DIFFUSER PLATE
- 11. O-RING
- 12. BEARING INSERT PAD

- 13. BEARING
- 14. BEARING HOUSING
- 17. INSULATED PACKING
- 18. HEAT SHIELD
- 20. WHEEL AND SHAFT
- 21. TURBINE HOUSING

3-47. TURBOCHARGER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)

15. Sleeve (8) and ring seal (9)	Remove ring seal (9) by spreading open with snapping pliers or small screwdriver.	Discard ring seal (9).
16. Wheel and shaft (20) and two turbocharger seals (19)	Remove two seals (19) with small screwdriver or snapping pliers.	Discard seals (19).

b. Cleaning and Inspection

17. All parts	Place in a divided wire basket. Clean with hot water and soap, mineral spirits, or steam clean. Use soft brush to clean parts.	Carbon deposits will form on turbocharger parts. Divided wire basket will keep parts from being damaged during cleaning. Leave parts in mineral spirits cleaning solvent for 12 to 24 hours for maximum cleaning.
---------------	--------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.


CAUTION

Never use a caustic solution solvent that may attack aluminum, Stellite, or nonresistant alloys.

18. Cleaned parts	Blow off excess water and dry with moisture-free compressed air.	Place parts in clean basket to avoid damage and dirt.
19. Bearing (13)	Inspect for: <ul style="list-style-type: none"> a. Minimum accepted length of 3.077 in. (78.156 mm). b. Outside diameter at two locations shown is a minimum of 1.272 in. (32.309 mm). c. Inside diameter of corresponding area is a maximum of 0.7525 in. (19.114 mm). d. Replace bearing if scratches, nicks, or dents are found in above areas. 	Discard bearing (13) if specifications below are not met.
20. Impeller housing (6)	Inspect for chips and scratches.	Use crocus cloth to smooth out small chips and scratches on machined surfaces of impeller housing (6).
21. Turbine housing (21)	Inspect for: <ul style="list-style-type: none"> a. Wheel to housing contact. 	Use crocus cloth to smooth out small chips and scratches on machined surfaces of turbine housing (21).

3-47. TURBOCHARGER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
21. Turbine housing (21) (Contd)	b. Cracks in mounting flange and V-band clamp (5) contact area.	Discard if cracked. Use straight-edge to check flange for distortion.
22. Bearing housing (14)	Inspect for: a. Cracks. b. Inside diameter of bore. c. Notches in dome area at wheel end of wheel and shaft (20).	Discard if cracked. Discard if diameter is 1.276 in. (32.410 mm) or greater. Discard if notches are found.



LEGEND:

- 5. V-BAND CLAMP
- 6. IMPELLER HOUSING
- 8. SLEEVE
- 9. RING SEAL
- 13. BEARING
- 14. BEARING HOUSING
- 19. SEAL (2)
- 20. WHEEL AND SHAFT
- 21. TURBINE HOUSING


3-47. TURBOCHARGER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Cleaning and Inspection (Contd)

22. Bearing housing (21) (Contd)	d. Measure from compressor housing stop to turbine housing stop at four equal locations.	Minimum length is 2.986 in. (75.844 mm). Discard if distorted (see illustration).
23. Diffuser plate (10)	Inspect for: a. Damage at contact point of bearing insert pad (12). b. Cracks, burrs, and distortion.	Discard if damaged or cracked.
24. Sleeve (8)	Inspect for: a. Uniform thickness of sleeve. b. Maximum clearance between sleeve (8) groove and new ring seal (9) is 0.009 in. (0.229 mm).	Measure for indication of wear. Discard if maximum is exceeded (see illustration).
25. Heat shield (18)	Inspect for: a. Cracks. b. Distortion.	Use a straightedge to check. Discard if cracked or distorted.
26. Turbocharger impeller (1)	Inspect for: a. Cracks. b. Damage to vane area. c. Damage caused by housing contact.	Use a dye solution for crack detection. Refer to MI-I-6866 for inspection and penetrant methods. Discard if cracked or damaged. Discard if damaged. Discard if damaged.

3-47. TURBOCHARGER REPAIR (Contd)



LEGEND:

- 1. TURBOCHARGER IMPELLER
- 8. SLEEVE
- 9. RING SEAL
- 10. DIFFUSER PLATE

- 12. BEARING INSERT PAD
- 14. BEARING HOUSING
- 18. HEAT SHIELD
- 20. WHEEL AND SHAFT
- 21. TURBINE HOUSING


3-47. TURBOCHARGER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Cleaning and Inspection (Contd)

<p>27. Wheel and shaft (20)</p>	<p>Inspect for:</p> <ul style="list-style-type: none"> a. Turbocharger seal groove damage. b. Thrust edge for scratches. c. Cracks. d. Damaged threads. 	<p>Use crocus cloth to smooth out small grooves and marks.</p> <p>Use dye solution. Refer to MI-I-6866 for inspection and penetrant methods. Discard if cracked.</p> <p>Discard if damaged.</p>
<p>28. Wheel and shaft (20) weld area</p>	<p>Inspect for:</p> <ul style="list-style-type: none"> a. Chips or scratches near weld area. b. One hole in welded area allowed. Maximum hole diameter of 0.080 in. (2.032 mm) is acceptable. c. Holes in weld area not to exceed 0.015 in. (0.381 mm). d. Cracks in weld area not to exceed 0.3750 in. (9.525 mm) in length. e. Not to exceed three cracks in weld area. f. Minimum distance of 0.250 in. (6.35 mm) between cracks. g. Cracks on circumference of welded area not to exceed 0.0625 in. (1.587 mm) in length. h. Discard if fails to meet any of the above conditions. 	<p>Discard if chipped or scratched.</p> <p>Visual inspection.</p> <p>Dye solution crack detection method. Very small holes that cannot be seen in visual inspection are allowed.</p> <p>Use a suitable crack detector other than visual inspection.</p>
<p>29. Wheel and shaft (20) circumference</p>	<p>Inspect for shaft runout. Not to exceed 0.0005 in. (0.0127 mm).</p>	<p>Remove aluminum deposit with crocus cloth before inspection. Rotate and support shaft in Vee-block and position dial indicator to determine runout. Discard if exceeded (see illustration).</p>

3-47. TURBOCHARGER REPAIR (Contd)



LEGEND:
20. WHEEL AND SHAFT

3-47. TURBOCHARGER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Assembly

CAUTION

All parts and work area must be free of grease, oil, and dirt to keep abrasives out of turbocharger during assembly.

30. Bearing housing (14)	a. Install bearing (13).	Lightly coat bearing surface with OE/HDO 30 oil.
	b. Install new bearing insert pad (12) over bearing (13) from diffuser plate (10) end.	Fold down edges of bearing insert pad (12) and coat mating surfaces with OE/HDO 30 oil before installing.
31. Sleeve (8)	Install new ring seal (9).	Lightly coat ring seal (9) with OE/HDO 30 oil. Expand ring seal (9) to clear sleeve (8). Do not expand ring seal (9) more than necessary.
32. Diffuser plate (10)	Insert end of sleeve (8) with ring seal (9) installed into bore of diffuser plate (10). Spiral grooves must face toward bearing (13).	Lightly coat bore of diffuser plate (10) with OE/HDO 30 oil before insertion. Use finger pressure when compressing ring seal (9). Push sleeve (8) in bore until flush with turbocharger impeller (1) end.
33. New O-ring (11)	Install on diffuser plate (10).	Lightly coat O-ring (11) with OE/HDO 30 oil.
34. Diffuser plate (10)	Install on bearing housing (14). Press on diffuser plate (10) with palms of hands.	Align bearing (13) flange with diffuser plate (10). Make certain bearing insert pad (12) is centered on bearing (13).

CAUTION


Do not rotate diffuser plate after assembly. Any rotation will displace and damage bearing insert pad.

NOTE

New insulated packing must be compressed approximately 0.050 in. (1.27 mm). Lightly tap packing at four locations with soft-nose hammer but avoid insulation contact with bearing housing.

35. Bearing housing (14) at wheel and shaft (20) end	Install new insulation packing (17).	Be sure flat side of insulated packing (17) is up.
36. Heat shield (18)	Install on top of insulated packing (17).	Align locating lugs on heat shield (18) with depressions on bearing housing (14) at wheel and shaft (20) end.
37. Wheel and shaft (20)	Install two new turbocharger seals (19).	Expand seals (19) to install. Rotate ring gaps 180° apart. Do not expand turbocharger seals (19) more than necessary.

3-47. TURBOCHARGER REPAIR (Contd)



LEGEND:

- 1. TURBOCHARGER IMPELLER
- 8. SLEEVE
- 9. RING SEAL
- 10. DIFFUSER PLATE
- 11. O-RING
- 12. BEARING INSERT PAD
- 13. BEARING

- 14. BEARING HOUSING
- 17. INSULATED PACKING
- 18. HEAT SHIELD
- 19. SEAL (2)
- 20. WHEEL AND SHAFT
- 21. TURBINE HOUSING

3-47. TURBOCHARGER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Assembly (Contd)

WARNING

The machined edges on the turbine wheel are very sharp. Wear protective gloves to avoid being cut.

38. Bearing housing (14)	a. Insert wheel and shaft (20) through bore in bearing (13). Hold sleeve (8) to keep it from slipping out.	Ensure sleeve (8) and heat shield (18) remain in position.
	b. Install turbocharger impeller (1) on wheel and shaft (20).	If necessary, mount bearing housing (14) in suitable press and press on center of turbocharger impeller (1).
39. Wheel and shaft (20) at turbocharger impeller (1) end	Install new impeller locknut (2) and tighten to 20-24 lb-ft (27-32 N•m).	Use a suitable socket and breaker bar at other end to prevent assembly from turning.

NOTE

Place turbine housing assembly on exhaust outlet end to perform steps 40, 41, and 42. Before installing bearing housing, lubricate turbine housing bore with antiseize compound.


40. Turbine housing (21)	Insert bearing housing (14) assembly into turbine housing (21).	Align marks made before disassembly.
41. Turbine housing (21) and bearing housing (14)	Install impeller housing (6) on bearing housing (14).	Align marks made before disassembly.

CAUTION

Do not exceed recommended torque. This causes V-band clamp distortion and loosening. Do not torque V-band clamp again during operation.

42. Turbocharger assembly	a. Install V-band clamp (5), two new screws (3), four new washers (4), and two new locknuts (7). Tighten to 58-68 lb-in. (6.6-7.7 N•m).	There must be a minimum of 0.035 in. (0.889 mm) clearance between turbine housing (21) and V-band clamp (5).
	b. Install and tighten adapter (16) to 20-25 lb-ft (27-34 N•m).	Coat with antiseize compound before installing.
	c. Install and tighten adapter (15) to 50 lb-ft (68 N•m).	Coat with antiseize compound before installing.
43. Turbocharger impeller (1)	Inspect for clearance between impeller (1) wheel vanes and side of impeller housing (6) bore. Minimum clearance is 0.006-0.025 in. (0.152-0.635 mm).	Push the shaft toward impeller housing (6) bore.

3-47. TURBOCHARGER REPAIR (Contd)



LEGEND:

- 1. TURBOCHARGER IMPELLER
- 2. IMPELLER LOCKNUT
- 3. SCREW (2)
- 4. WASHER (4)
- 5. V-BAND CLAMP
- 6. IMPELLER HOUSING
- 7. LOCKNUT (2)
- 8. SLEEVE

- 13. BEARING
- 14. BEARING HOUSING
- 15. ADAPTER
- 16. ADAPTER
- 18. HEAT SHIELD
- 20. WHEEL AND SHAFT
- 21. TURBINE HOUSING


3-47. TURBOCHARGER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
c. Assembly (Contd)		
44. Turbine housing (21)	Turn assembly over, and inspect for clearance between wheel and shaft (20) and turbine housing (21) bore. Minimum clearance is 0.005-0.043 in. (0.127-1.092 mm).	Push wheel and shaft (20) toward side of turbine housing (21) bore.
45. Impeller housing (6)	Check rotor end clearance with dial indicator. Clearance must be within 0.006-0.018 in. (0.152-0.457 mm).	Position dial indicator across impeller housing (6) opening and wheel and shaft (20). Measure by moving wheel and shaft (20) in and out. Turn compressor to check for binding. Tape opening to prevent dirt and abrasives from entering turbocharger after repair.

CAUTION
Remove tape from openings before installing turbocharger on vehicle.

FOLLOW-ON TASK: Install turbocharger (para. 3-88).

3-47. TURBOCHARGER REPAIR (Contd)



- LEGEND:
 6. IMPELLER HOUSING
 20. WHEEL AND SHAFT
 21. TURBINE HOUSING

3-48. FRONT GEAR COVER REPAIR

THIS TASK COVERS:

- a. Disassembly
- b. Cleaning

- c. Inspection
- d. Assembly

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Puller/installer (15434) ST-1259
 Oil seal expander (15434) 3375151
 Seal mandrel (15434) ST-113

TEST EQUIPMENT

None

MATERIALS/PARTS

Sealant, thread (liquid) (Appendix C, Item 27)
 Preformed packing (15434) 215705
 Accessory gear cover bushing (15434) 132770
 Oil seal (15434) 3004316
 Crankshaft oil seal (15434) 3006736

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Front gear cover removed (para. 3-27).

SPECIAL ENVIRONMENTAL CONDITIONS

None

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly

1. Oil seal (1)	Remove from gear cover (4).	Use puller/installer (ST-1259). Discard oil seal (1).
2. Crankshaft oil seal (6)	Remove from gear cover (4).	Use puller/installer (ST-1259). Discard crankshaft oil seal (6).
3. Three captive washer screws (7), camshaft support (8), shims (9), (10), (11), and (12), and preformed packing (13)	Remove from gear cover (4).	More than one shim may be used. Retain shims (9), (10), (11), and (12). Discard packing (13) if present.
4. Three pipe plugs (3), (5), and (14)	Remove from gear cover (4).	


b. Cleaning

5. Gear cover (4) and camshaft support (8)	a. Clean in accordance with instructions in para. 3-6. b. Remove all gasket material.	
--------------------------------------------	----------------------------------------------------------------------------------------------	--

c. Inspection

6. Gear cover (4)	Inspect for distortion and cracks. Remove imperfections on mating surface with crocus cloth.	Discard if cracked or distorted. Use surface plate to eliminate high and low areas on gear cover (4) mating surface.
-------------------	----------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------

3-48. FRONT GEAR COVER REPAIR (Contd)



LEGEND:

- | | |
|-----------------------------|-----------------------|
| 1. OIL SEAL | 8. CAMSHAFT SUPPORT |
| 2. SLEEVE BEARING | 9. INSERT SHIM |
| 3. PIPE PLUG | 10. SHIM 0.010 |
| 4. GEAR COVER | 11. SHIM 0.050 |
| 5. PIPE PLUG | 12. SHIM 0.002 |
| 6. CRANKSHAFT OIL SEAL | 13. PREFORMED PACKING |
| 7. CAPTIVE WASHER SCREW (3) | 14. PIPE PLUG |

3-48. FRONT GEAR COVER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

- | | | | |
|----|----------------------------------|-----------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| 7. | Sleeve bearing (2) | a. Inspect for scoring and pitting.
b. Using suitable micrometer, measure inside diameter. | Discard if scored or pitted. Remove and discard if inside diameter is not within limits shown below. Use suitable arbor press to remove sleeve. |
| | Minimum | 1.565 in. (39.751 mm) | |
| | Maximum | 1.569 in. (39.853 mm) | |
| | Limit | 1.571 in. (39.903 mm) | |
| 8. | Bore for crankshaft oil seal (6) | Inspect for:
a. Nicks, burrs, and gouges.

b. Cracks. | Small nicks, burrs, and gouges can be smoothed out with crocus cloth or fine-cut mill file.

Discard if cracked. |

CAUTION

Discard camshaft support if removal of shims will not allow for correct camshaft end play.

- | | | | |
|-----|-------------------------------------|---------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| 9. | Camshaft support (8) | Inspect for:
a. Scoring, pitting, or cracks.

b. Using suitable micrometer, measure inside diameter. | Discard if scored, pitted, or cracked.

Inside diameter is not to exceed 1.757 in. (44.628 mm). Discard if limits are exceeded. |
| 10. | Three pipe plugs (3), (5), and (14) | Inspect for damaged threads. | Discard if threads are damaged. |

d. Assembly


CAUTION

All surfaces in contact with oil seals must be completely free of oil. Oil on a Teflon seal will destroy its sealing properties.

- | | | | |
|-----|------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| 11. | New sleeve bearing (2) and new oil seal (1) | Install on gear cover (4). | Use mandrel (ST-1173) for installation of sleeve bearing (2). Ensure oil holes are aligned. Oil seal must be flush with gear cover (4). |
| 12. | New crankshaft oil seal (6) | Install on gear cover (4). | Use puller/installer (ST-1259) and oil seal expander (3375151). |
| 13. | Three pipe plugs (3), (5), and (14) | Apply liquid thread sealant and install on gear cover (4). | |
| 14. | New preformed packing (13), shims (9), (10), (11), and (12), camshaft support (8), and three captive washer screws (7) | Install on gear cover (4). | The number of shims used will be determined by camshaft end play. Tighten captive washer screws (7) to 25 lb-ft (34 N•m). |

FOLLOW-ON TASK: Install front gear cover (para. 3-75).

3-48. FRONT GEAR COVER REPAIR (Contd)



LEGEND:

- | | |
|-----------------------------|-----------------------|
| 1. OIL SEAL | 8. CAMSHAFT SUPPORT |
| 2. SLEEVE BEARING | 9. INSERT SHIM |
| 3. PIPE PLUG | 10. SHIM 0.010 |
| 4. GEAR COVER | 11. SHIM 0.050 |
| 5. PIPE PLUG | 12. SHIM 0.002 |
| 6. CRANKSHAFT OIL SEAL | 13. PREFORMED PACKING |
| 7. CAPTIVE WASHER SCREW (3) | 14. PIPE PLUG |

3-49. ACCESSORY DRIVE REPAIR

THIS TASK COVERS:

- a. Disassembly
- b. Cleaning

- c. Inspection
- d. Assembly

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Puller (15434) 3376663

TEST EQUIPMENT

None

MATERIALS/PARTS

Solvent, SD-3 (Appendix C, Item 30)

Oil, lubricating, OE/HDO 10

(Appendix C, Item 20)

Self-locking screw (15434) 3000173

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

None

EQUIPMENT CONDITION

- Accessory drive pulley removed (para. 3-15).
- Accessory drive housing assembly removed (para. 3-18).

SPECIAL ENVIRONMENTAL CONDITIONS

None

GENERAL SAFETY INSTRUCTIONS


None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly

1. Self-locking screw (8) and washer (9)	Remove from accessory drive shaft (6).	Install self-locking screw (8) to prevent damage to shaft (6) when using puller (3376663).
2. Spline coupling hub (10)	Remove from accessory drive shaft (6).	Use puller (3376663). Remove and discard self-locking screw (8) after removal of spline coupling hub (10).
3. Washer (11) and thrust bearing (12)	Remove from accessory drive shaft (6).	
4. Accessory drive shaft (6) and accessory drive gear (4)	Remove from accessory drive housing (15).	
5. Front dowel pin (7)	Remove from accessory drive shaft (6).	
6. Accessory drive gear (4) and thrust bearing (5)	Remove from accessory drive shaft (6).	Use suitable arbor press. Put housing side of gear (4) on a support.
7. Rear dowel pin (7)	Remove from accessory drive shaft (6).	
8. Plug (14)	Remove from accessory drive housing (15).	

3-49. ACCESSORY DRIVE REPAIR (Contd)



LEGEND:

- 1. KEYWAY SEAL
- 2. ACCESSORY DRIVE PULLEY
- 3. HOUSING GASKET
- 4. ACCESSORY DRIVE GEAR
- 5. THRUST BEARING
- 6. ACCESSORY DRIVE SHAFT
- 7. DOWEL PIN (2)
- 8. SELF-LOCKING SCREW
- 9. WASHER
- 10. SPLINE COUPLING HUB

- 11. WASHER
- 12. THRUST BEARING
- 13. BUSHING
- 14. PLUG
- 15. ACCESSORY DRIVE HOUSING
- 16. WEAR SLEEVE
- 17. SCREW
- 18. FLANGE NUT
- 19. WASHER
- 20. ACCESSORY DRIVE PULLEY

3-49. ACCESSORY DRIVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Cleaning

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.

9. All parts	Clean in SD-3 cleaning solvent and dry with compressed air.	Remove housing gasket (3) material from accessory drive housing (15) assembly.
--------------	-------------------------------------------------------------	--------------------------------------------------------------------------------

c. Inspection

10. Accessory drive housing (15), bushing (13), and plug (14)	Inspect for the following: a. Cracks around area of bushing (13). b. Inside diameter of bushing (13). c. Out-of-round. d. Inspect mating threads on plug (14).	Refer to Appendix F for wear limits and tolerances. Discard if cracked. Remove and discard if dimension exceeds 1.321 in. (33.553 mm). Use suitable arbor press. Remove and discard if out-of-round exceeds 0.002 in. (0.051 mm). Use suitable arbor press. Chase threads or use thread insert.
11. Accessory drive shaft (6)	Inspect for the following: a. Distortion or damage. b. Outside diameter of bushing (13) location. c. Excessive wear at area of dowel pins (7).	Discard if distorted or damaged. Discard if dimension is less than 1.310 in. (33.274 mm). Discard if excessive wear is detected.
12. Accessory drive gear (4) and spline coupling hub (10)	Inspect for cracked or chipped teeth and uneven wear.	Discard if cracked, chipped, or uneven wear is detected.
13. Thrust bearings (5) and (12) and washer (11)	Inspect for wear or galling.	Discard if worn or galled.

NOTE


Accessory drive pulleys on M915/Big Cam I and M915A1/Big Cam III are similar. M915A1/Big Cam III configuration is shown.

14. Accessory drive pulleys (20) and (2)	Inspect for: a. Cracks and chips in hub (10). b. Wear in grooves. c. Distorted thread holes. d. Excessive play or wobble in area of wear sleeve (16).	Discard if cracked or chipped. Discard if excessively worn. Discard if excessively distorted. Discard if excessive play evident.
------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------

3-49. ACCESSORY DRIVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

15. Wear sleeve (16)	Inspect for wear in grooves.	Discard if worn. To remove wear sleeve (16), use a round-nose punch through one of the threaded puller holes and drive wear sleeve (16) off. Installation requires the use of a mandrel and arbor press. Press to 0.015 in. (0.381 mm) below face of accessory drive pulley (2) with chamfered end away from pulley (2).
----------------------	------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



LEGEND:

- | | |
|---------------------------|-----------------------------|
| 1. KEYWAY SEAL | 11. WASHER |
| 2. ACCESSORY DRIVE PULLEY | 12. THRUST BEARING |
| 3. HOUSING GASKET | 13. BUSHING |
| 4. ACCESSORY DRIVE GEAR | 14. PLUG |
| 5. THRUST BEARING | 15. ACCESSORY DRIVE HOUSING |
| 6. ACCESSORY DRIVE SHAFT | 16. WEAR SLEEVE |
| 7. DOWEL PIN (2) | 17. SCREW (6) |
| 8. SELF-LOCKING SCREW | 18. FLANGE NUT |
| 9. WASHER | 19. WASHER |
| 10. SPLINE COUPLING HUB | 20. ACCESSORY DRIVE PULLEY |

3-49. ACCESSORY DRIVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

16. Keyway seal (1), washer (19), flange nut (18), and six screws (17)	Inspect for distortion, burrs, or damaged threads.	Discard and replace if distorted, burred, or damaged.
------------------------------------------------------------------------	----------------------------------------------------	-------------------------------------------------------

d. Assembly

17. Two dowel pins (7)	Install on accessory drive shaft (6).	
18. Accessory drive gear (4)	Install on accessory drive shaft (6).	Use suitable arbor press. Press until accessory drive gear (4) is against shoulder.

NOTE

Perform step 19 if original bushing was removed.

19. New bushing (13)	a. Line up oil holes. b. Install on bore of accessory drive housing (15).	Use suitable arbor press. Bore must be clean before bushing (13) is installed. Lubricate bore of bushing (13) after installation with OE/HDO 10 lubricating oil.
----------------------	----------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------

CAUTION


Install grooved side of thrust bearings away from housing. The steel backing against cast iron housing will keep thrust bearings from turning. Incorrect installation will result in excessive wear and increased end play, which causes early failure of the accessory drive housing assembly.

NOTE

Apply a thin coat of OE/HDO 10 lubricating oil to parts listed in steps 20 and 21 prior to installation on accessory drive housing.

20. Thrust bearing (5)	Install on accessory drive housing (15).	Ensure grooved side of thrust bearing (5) is away from housing (15).
21. Accessory drive gear (4) and accessory drive shaft (6)	Install on thrust bearing (5), bushing (13), and accessory drive housing (15) assembly.	

3-49. ACCESSORY DRIVE REPAIR (Contd)



LEGEND:

- | | |
|---------------------------|-----------------------------|
| 1. KEYWAY SEAL | 11. WASHER |
| 2. ACCESSORY DRIVE PULLEY | 12. THRUST BEARING |
| 3. HOUSING GASKET | 13. BUSHING |
| 4. ACCESSORY DRIVE GEAR | 14. PLUG |
| 5. THRUST BEARING | 15. ACCESSORY DRIVE HOUSING |
| 6. ACCESSORY DRIVE SHAFT | 16. WEAR SLEEVE |
| 7. DOWEL PIN (2) | 17. SCREW (6) |
| 8. SELF-LOCKING SCREW | 18. FLANGE NUT |
| 9. WASHER | 19. WASHER |
| 10. SPLINE COUPLING HUB | 20. ACCESSORY DRIVE PULLEY |

3-49. ACCESSORY DRIVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)

22. Accessory drive housing (15)	Turn over so accessory drive gear (4) is face down.	Ensure thrust bearing (5) remains in position.
23. Thrust bearing (12)	Install on accessory drive shaft (6).	Grooved side of thrust bearing (5) is away from housing (15).
24. Washer (11)	Install onto accessory drive shaft (6).	


CAUTION

Exercise caution not to damage threads on accessory drive shaft when pressing on spine coupling hub.

25. Spline coupling hub (10)	Install on accessory drive shaft (6).	Use suitable arbor press.
26. Accessory drive gear (4) and accessory drive housing (15)	Using feeler gauge, check end clearance between gear (4) and housing (15).	Allowable end clearance is 0.002-0.012 in. (0.051-0.305 mm).
27. Washer (9) and new self-locking screw (8)	Install on accessory drive shaft (6).	Tighten to 30-35 lb-ft (41-48 N•m).
28. Plug (14)	Install on accessory drive housing (15).	

- FOLLOW-ON TASKS:
- Install accessory drive housing assembly (para. 3-73).
 - Install accessory drive pulley (para. 3-76).

3-49. ACCESSORY DRIVE REPAIR (Contd)



LEGEND:

- | | |
|---------------------------|-----------------------------|
| 1. KEYWAY SEAL | 11. WASHER |
| 2. ACCESSORY DRIVE PULLEY | 12. THRUST BEARING |
| 3. HOUSING GASKET | 13. BUSHING |
| 4. ACCESSORY DRIVE GEAR | 14. PLUG |
| 5. THRUST BEARING | 15. ACCESSORY DRIVE HOUSING |
| 6. ACCESSORY DRIVE SHAFT | 16. WEAR SLEEVE |
| 7. DOWEL PIN (2) | 17. SCREW (6) |
| 8. SELF-LOCKING SCREW | 18. FLANGE NUT |
| 9. WASHER | 19. WASHER |
| 10. SPLINE COUPLING HUB | 20. ACCESSORY DRIVE PULLEY |

3-50. ENGINE RETARDER REPAIR

THIS TASK COVERS:

- a. Disassembly
- b. Testing

- c. Assembly

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Solenoid valve wrench (75078) 011494
 Spring tester (15434) 3375182
 Jake brake socket B1465A

TEST EQUIPMENT

None

MATERIALS/PARTS

Oil, lubricating, OE/HDO 30
 (Appendix C, Item 21)
 Upper seal ring (15434) 001081
 Center seal ring (15434) 001082
 Lower seal ring (15434) 001083

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

TM 9-2320-273-20
 TM 9-2320-283-20

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Engine retarder removed (para. 3-21).

SPECIAL ENVIRONMENTAL CONDITIONS

None

GENERAL SAFETY INSTRUCTIONS

Eye protection is required when removing control valve outer and inner springs, slave piston retainer, and spring.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

NOTE

All three engine retarders are disassembled and repaired the same way. This procedure covers repair of one engine retarder.


a. Disassembly

WARNING

Control valve cover is under pressure by control valve outer spring. Move cover down when removing screw. Wear suitable eye protection. Failure to comply may result in injury to personnel.

- | | | | |
|----|---------------------------------------------|------------------------------------------|------------------------------------------------------------------------------------------------|
| 1. | Two screws (2) and control valve covers (1) | Remove from brake housing (20). | |
| 2. | Two control valve outer springs (22) | Remove from control valve (21). | |
| 3. | Two control valve inner springs (23) | Remove from control valve (21). | Retain control valve inner springs (23) for testing. |
| 4. | Two control valves (21) | Remove from brake housing (20). | Use needle-nose pliers to remove. Pull control valves (21) straight up and out of their bores. |
| 5. | Harness (3) | Remove from solenoid valve assembly (4). | |
| 6. | Solenoid valve assembly (4) | Remove from brake housing (20). | Use solenoid valve wrench (011494). |

3-50. ENGINE RETARDER REPAIR (Contd)



LEGEND:

- | | |
|------------------------------|--------------------------------------------------|
| 1. CONTROL VALVE COVER (2) | 13. WASHER (2) |
| 2. SCREW (2) | 14. SCREW (2) |
| 3. HARNESS | 15. RETAINING RING (2) |
| 4. SOLENOID VALVE ASSEMBLY | 16. SLAVE PISTON RETAINER (2) |
| 5. UPPER SEAL RING | 17. SLAVE PISTON SPRING (2) |
| 6. CENTER SEAL RING | 18. SLAVE PISTON (2) |
| 7. LOWER SEAL RING | 19. SLAVE PISTON (2) (FOR MILLED CYLINDER HEADS) |
| 8. LOCKNUT (2) | 20. BRAKE HOUSING |
| 9. SETSCREW (2) | 21. CONTROL VALVE (2) |
| 10. TERMINAL | 22. CONTROL VALVE OUTER SPRING (2) |
| 11. MASTER PISTON (2) | 23. CONTROL VALVE INNER SPRING (2) |
| 12. MASTER PISTON SPRING (2) | |

3-50. ENGINE RETARDER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)


7. Center seal ring (6) and upper seal ring (5)	Remove from brake housing assembly (20).	Discard seal rings (5) and (6).
8. Lower seal ring (7)	Remove from solenoid valve assembly bore on brake housing assembly (20).	Discard lower seal ring (7).
9. Two screws (14), washers (13), and master piston springs (12)	Remove from bottom of brake housing assembly (20).	
10. Two master pistons (11)	Remove from brake housing assembly (20).	Slide out of bores.
11. Two locknuts (8)	Loosen.	Locknuts (8) must be loosened to remove setscrews (9).
12. Two setscrews (9)	Remove from brake housing assembly (20).	Keep locknuts (8) on setscrews (9).

WARNING

Retaining ring, spring, and slave piston retainer are under heavy compression. Wear eye protection. Use deepwell socket and C-clamp (or vise) to remove. Failure to comply may result in injury to personal.

13. Two retaining rings (15)	Remove from brake housing assembly (20).	Slowly remove tension on retaining rings (15) by using deep-well socket and C-clamp (or vise).
------------------------------	------------------------------------------	------------------------------------------------------------------------------------------------

3-50. ENGINE RETARDER REPAIR (Contd)



LEGEND:

- | | |
|------------------------------|------------------------------------|
| 5. UPPER SEAL RING | 15. RETAINING RING (2) |
| 6. CENTER SEAL RING | 16. SLAVE PISTON RETAINER (2) |
| 7. LOWER SEAL RING | 17. SLAVE PISTON SPRING (2) |
| 8. LOCKNUT (2) | 20. BRAKE HOUSING ASSEMBLY |
| 9. SETSCREW (2) | 21. CONTROL VALVE (2) |
| 11. MASTER PISTON (2) | 22. CONTROL VALVE OUTER SPRING (2) |
| 12. MASTER PISTON SPRING (2) | 23. CONTROL VALVE INNER SPRING (2) |
| 13. WASHER (2) | 24. SOLENOID VALVE WRENCH |
| 14. SCREW (2) | |

3-50. ENGINE RETARDER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


a. Disassembly (Contd)

14. Two slave piston retainers (16)	Remove from brake housing (20).	
15. Two slave piston springs (17)	Remove from two pistons (18) or (19).	Retain slave piston springs (17) for testing.
16. Two slave pistons (18) or (19)	Remove from brake housing (20).	Piston (19) is for milled cylinder heads.
17. Harness (3)	Disconnect from terminal (10).	
18. Terminal (10)	Remove from brake housing (20).	Inspect. Discard if insulation is cracked.

b.

19. Two control valve inner springs (23)	Mount in spring tester (3375182) (25) and check.	Load at 1.625 in. (4.128 cm) 62.5-69.5 lb (28.4-31.6 kg). Load at 1.478 in. 71.5-80.5 lb (32.5-36.6 kg). Free length 2.58 in. (6.553 cm). Number of coils is approximately 13. If operation does not meet specifications, replace control valve inner spring (23).
20. Two slave piston springs (17)	Mount in spring tester (3375782) (25) and check.	Load at 0.5 in. (12.7 mm): 4.7-5.3 lb (2.1-2.4 kg). Load at 0.812 in. (2.062 cm) 0.7-1.3 lb. Free length 0.9 in. (2.286 cm). Number of coils is approximately 15. If operation does not meet specifications, replace slave piston spring (17).
21. Two control valves (21)	Must move freely in their bores.	Replace if worn or damaged.
22. Two slave pistons (18) or (19)	Must move freely in their bores.	Replace if worn or damaged.
23. Two slave piston retainers (16)	Check for wear and damage.	Replace if worn or damaged.
24. Two control valve outer springs (22)	Check for wear and damage.	Replace if worn or damaged.

3-50. ENGINE RETARDER REPAIR (Contd)



LEGEND:


- | | |
|--------------------------------------------------|------------------------------------|
| 3. HARNESS | 20. BRAKE HOUSING |
| 10. TERMINAL | 21. CONTROL VALVE (2) |
| 16. SLAVE PISTON RETAINER (2) | 22. CONTROL VALVE OUTER SPRING (2) |
| 17. SLAVE PISTON SPRING (2) | 23. CONTROL VALVE INNER SPRING (2) |
| 18. SLAVE PISTON (2) | 25. SPRING TESTER |
| 19. SLAVE PISTON (2) (FOR MILLED CYLINDER HEADS) | |

3-50. ENGINE RETARDER REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
c. Assembly		
25. Two slave pistons (18) or (19)	Install on brake housing (20).	Slave piston (19) is for milled cylinder heads.
26. Two springs (17), retainers (16), and retaining rings (15)	Depress slave piston springs (17) and slave piston retainers (16) with deepwell socket and C-clamp. Install retaining rings (15).	Make certain slave piston retainers (16) are positioned in grooves of slave pistons (18) or (19).
27. Two setscrews (9) and locknuts (8)	Install on brake housing (20).	Setscrews (9) and locknuts (8) are tightened during clearance adjustment during engine assembly.
28. Two master pistons (11)	Install on brake housing (20).	
29. Two master piston springs (12), washers (13), and screws (14)	Install on master pistons (11) and brake housing (20).	Assemble spring (12) to piston (11) with concave part of spring (12) toward piston (11) and centered on turned boss on piston (11) top.
30. Three new rings (5), (6), and (7)	Lubricate with OE/HDO 30 lubricating oil.	
31. New lower seal ring (7)	Install on bottom of bore on brake housing (20).	
32. New upper seal ring (5) and center seal ring (6)	Install on solenoid valve assembly (4).	
33. Solenoid valve assembly (4)	Install on brake housing (20) and tighten with solenoid valve wrench.	Use solenoid valve wrench (011494). Do not disturb position of upper seal ring (5) or center seal ring (6).
34. Harness (3)	Connect to solenoid valve assembly (4).	
35. Terminal (10)	Install on brake housing (20).	
36. Harness (3)	Connect to terminal (10).	
37. Two control valves (21)	Install on brake housing (20).	
38. Two control valve inner springs (23)	Install on control valves (21).	
39. Two control valve outer springs (22)	Install on control valves (21).	
40. Two control valve covers (1) and screws (2)	Position control valve covers (1) over valve bore and secure with screws (2).	

FOLLOW-ON TASK: Install engine retarder and adjust slave piston (para. 3-86).

3-50. ENGINE RETARDER REPAIR (Contd)



LEGEND:

- | | |
|------------------------------|--------------------------------------------------|
| 1. CONTROL VALVE COVER (2) | 13. WASHER (2) |
| 2. SCREW (2) | 14. SCREW (2) |
| 3. HARNESS | 15. RETAINING RING (2) |
| 4. SOLENOID VALVE ASSEMBLY | 16. SLAVE PISTON RETAINER (2) |
| 5. UPPER SEAL RING | 17. SLAVE PISTON SPRING (2) |
| 6. CENTER SEAL RING | 18. SLAVE PISTON (2) |
| 7. LOWER SEAL RING | 19. SLAVE PISTON (2) (FOR MILLED CYLINDER HEADS) |
| 8. LOCKNUT (2) | 20. BRAKE HOUSING |
| 9. SETSCREW (2) | 21. CONTROL VALVE (2) |
| 10. TERMINAL | 22. CONTROL VALVE OUTER SPRING (2) |
| 11. MASTER PISTON (2) | 23. CONTROL VALVE INNER SPRING (2) |
| 12. MASTER PISTON SPRING (2) | |

3-51. AIR COMPRESSOR REPAIR

THIS TASK COVERS:

- a. Disassembly
- b. Cleaning

- c. Inspection and Repair
- d. Assembly

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

- Air compressor mounting plate (15434) ST-749
- Ball joint vise (15434) ST-302
- Coupling half puller (15434) ST-1249 or (15434) 3376663
- Air compressor bushing mandrel (15434) ST-1105 or ST-1143

TEST EQUIPMENT

None

MATERIALS/PARTS (P/N)

- Solvent, SD-3 (Appendix C, Item 30)
- Cloth, crocus (Appendix C, Item 4)
- Compound, Prussian blue (Appendix C, Item 9)
- Oil, lubricating: OE/HDO 30 (Appendix C, Item 21)
- Compound, antiseize (Appendix C, Item 7)
- Compound, lapping, 280-grit (Appendix C, Item 8)
- Preformed packing (15434) 128086
- Preformed packing (15434) 127936
- Preformed packing (15434) 128085
- Preformed packing (15434) 3043995
- Gasket (15434) 3047159
- Gasket (15434) 154018
- Gasket (15434) 176027
- Piston ring kit (15434) AR-73350
- Four lockwashers (96906) MS35338-47
- Four lockwashers (96906) MS35338-45

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCE (TM)

- TM 9-2320-273-20
- TM 9-2320-283-20

TROUBLESHOOTING REFERENCES

None

EQUIPMENT CONDITION

Air compressor removed (para. 3-17).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area dean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS


- Always wear eye protection when using compressed air.
- Approved solvents may be flammable and will not be used near open flame. Use in well-ventilated area.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly

1. Air compressor (2)	Install on air compressor mounting plate (50) and ball joint vise (51).	Use air compressor mounting plate (ST-749) (50) and ball joint vise (ST-302) (51).
2. Two captive washer screws (3)	Unscrew and remove two washers (4) and valve body (5) from cover (22).	
3. Preformed packings (6) and (7) and cap (8)	Remove from valve body (5).	Discard preformed packings (6) and (7).
4. Spring (9)	Remove from cover (22).	Spring (9) may have come out with valve body (5).
5. Seat (10), valve (11), and spring (12)	Remove from inside of cylinder head (24).	

3-51. AIR COMPRESSOR REPAIR (Contd)




LEGEND:

- | | | |
|-----------------------------|-----------------------------|-----------------------------------|
| 1. DRIVE COUPLING | 19. SCREW (4) | 37. HOUSING |
| 2. AIR COMPRESSOR | 20. LOCKWASHER (4) | 38. CAPTIVE WASHER SCREW (2) |
| 3. CAPTIVE WASHER SCREW (2) | 21. WASHER (4) | 39. PLATE |
| 4. WASHER (2) | 22. COVER | 40. SCREW (2) |
| 5. VALVE BODY | 23. GASKET | 41. CRANKSHAFT ASSEMBLY |
| 6. PREFORMED PACKING | 24. CYLINDER HEAD | 42. PIPE PLUG |
| 7. PREFORMED PACKING | 25. GASKET | 43. CRANKSHAFT |
| 8. CAP | 26. RING | 44. GASKET |
| 9. SPRING | 27. RING | 45. SUPPORT |
| 10. SEAT | 28. RING | 46. LOCKWASHER (4) |
| 11. VALVE | 29. PISTON | 47. SCREW (4) |
| 12. SPRING | 30. RETAINING RING (2) | 48. THRUST BEARING |
| 13. PREFORMED PACKING | 31. PIN | 49. HALF COUPLING |
| 14. SEAT | 32. CONNECTING ROD ASSEMBLY | 50. AIR COMPRESSOR MOUNTING PLATE |
| 15. PREFORMED PACKING | 33. BUSHING | 51. BALL JOINT VISE |
| 16. DISC | 34. CONNECTING ROD | |
| 17. SPRING | 35. CRANKCASE ASSEMBLY | |
| 18. SHIM | 36. BEARING | |

3-51. AIR COMPRESSOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
a. Disassembly (Contd)		
6. Cylinder head (24)	Unscrew and remove four screws (19), lockwashers (20), washers (21), cover (22), and gasket (23).	Discard gasket (23).
7. Cylinder head (24) and gasket (25)	Remove from housing (37).	Discard gasket (25).
8. Seat (14)	Press out from bottom side of cylinder head (24).	Preformed packings (13) and (15) are attached to seat (14) when removed.

3-51. AIR COMPRESSOR REPAIR (Contd)



LEGEND:

- | | |
|-----------------------|--------------------|
| 2. AIR COMPRESSOR | 20. LOCKWASHER (4) |
| 10. SEAT | 21. WASHER (4) |
| 11. VALVE | 22. COVER |
| 12. SPRING | 23. GASKET |
| 13. PREFORMED PACKING | 24. CYLINDER HEAD |
| 14. SEAT | 25. GASKET |
| 15. PREFORMED PACKING | 37. HOUSING |
| 19. SCREW (4) | |

3-51. AIR COMPRESSOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)


9. Preformed packings (13) and (15)	Remove from seat (14).	Discard preformed packings (13) and (15).
10. Disc (16), spring (17), and shim (18)	Remove from cylinder head (24).	Disc (16) might be attached to seat (14).
11. Drive coupling (1)	Remove from half coupling (49), if not already removed.	

NOTE

Assistant may be required for the following step.

12. Half coupling (49)	Remove from crankshaft (43).	Use coupling half puller (ST-1249) or (3376663) (52). Use locating key in puller (52) to index puller teeth behind coupling (49) teeth.
13. Thrust bearing (48)	Remove from crankshaft (43).	
14. Two captive washer screws (38) and four screws (47)	Unscrew and remove four lockwashers (46), support (45), and gasket (44) from housing (37).	Discard lockwashers (46) and gasket (44).
15. Crankshaft (43)	<p>a. Rotate until piston (29) is about 90° before or after top dead center.</p> <p>b. Move crankshaft (43) around while pulling it out of connecting rod (34).</p>	Piston (29) and crankshaft (43) must be in this position before crankshaft (43) can be removed.

3-51. AIR COMPRESSOR REPAIR (Contd)



LEGEND:

- | | |
|-----------------------|------------------------------|
| 1. DRIVE COUPLING | 37. HOUSING |
| 13. PREFORMED PACKING | 38. CAPTIVE WASHER SCREW (2) |
| 14. SEAT | 43. CRANKSHAFT |
| 15. PREFORMED PACKING | 44. GASKET |
| 16. DISC | 45. SUPPORT |
| 17. SPRING | 46. LOCKWASHER (4) |
| 18. SHIM | 47. SCREW (4) |
| 24. CYLINDER HEAD | 48. THRUST BEARING |
| 29. PISTON | 49. HALF COUPLING |
| 34. CONNECTING ROD | 52. COUPLING HALF PULLER |

3-51. AIR COMPRESSOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)


16. Two screws (40)	Unscrew and remove plate (39) from housing (37).	
17. Housing (37)	Using a suitable ridge reamer, remove any carbon deposits or worn ridges from top of cylinder.	Make sure carbon deposits and ridges are removed before air compressor piston (29) is pushed through cylinder of housing (37).
18. Piston (29) and connecting rod (34) (assembled)	Push out through cylinder of housing (37).	
19. Two retaining rings (30)	Remove from piston (29).	Discard retaining rings (30) if damaged during removal.

CAUTION

Driving piston pin from piston pin bore could damage piston. If piston pin cannot be removed by hand pressure, place piston in hot water to expand piston pin bore and allow piston pin to be removed.

20. Piston pin (31)	Remove by pushing through connecting rod (34) and piston (29) with hand pressure.	Use gloves if piston (29) has been in hot water.
---------------------	-----------------------------------------------------------------------------------	--------------------------------------------------

3-51. AIR COMPRESSOR REPAIR (Contd)



LEGEND:

- 29. AIR COMPRESSOR PISTON
- 30. RETAINING RING (2)
- 31. PISTON PIN
- 34. CONNECTING ROD

- 37. HOUSING
- 39. PLATE
- 40. SCREW (2)

3-51. AIR COMPRESSOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)

21. Piston (29) Remove from connecting rod (34).

CAUTION

Be very careful not to score or scratch piston when removing rings. Scoring and scratching can cause damage to piston.

22. Three rings (26), (27), and (28) Remove from piston (29). Discard rings (26), (27), and (28).

b. Cleaning

WARNING

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

23. Cover (22) and cylinder head (24)

- a. Immerse in SD-3 solvent to remove carbon and scale.
- b. Remove carbon from valve cavities, and remove rust and scale from water cavities.
- c. Blow dry with compressed air.

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.

24. Crankshaft (43)

- a. Unscrew and take out pipe plug (42).
- b. Using SD-3 solvent, thoroughly clean oil drilling and blow dry with compressed air.
- c. Screw in pipe plug (42).

25. All other parts Clean in SD-3 solvent and blow dry with compressed air. Ensure all gasket surfaces are clean and smooth.


c. Inspection and Repair

26. All parts Inspect for cracks, breaks, and other damage. Discard any damaged parts.

27. Cylinder head (24) and cover (22) Inspect mating surfaces for scratches, scoring, and other damage. Discard if damaged. Do not grind top surface of cylinder head (24). Top surface is contoured and grinding will cause cylinder head (24) to leak.

28. Seat(14) Using suitable micrometer, measure height of seating area. Discard if height is less than 0.485 in. (12.319 mm).

3-51. AIR COMPRESSOR REPAIR (Contd)





LEGEND:

- | | |
|-------------------|--------------------|
| 14. SEAT | 28. RING |
| 22. COVER | 29. PISTON |
| 24. CYLINDER HEAD | 34. CONNECTING ROD |
| 26. RING | 42. PIPE PLUG |
| 27. RING | 43. CRANKSHAFT |

3-51. AIR COMPRESSOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
c. Inspection and Repair (Contd)		
29. Seat (10)	Using suitable micrometer, measure height of seating area.	Discard if height is less than 0.270 in. (6.858 mm).
30. Seat (14) and disc (16)	a. Using Prussian blue compound, check seating surfaces.	Do step 30b only if surfaces are not 100 percent true.
	b. Using lapping compound, lap seating surfaces.	If lapping will reduce valve seat height beyond wear limits, discard disc (16) and seat (14). Disc (16) must be flat within 0.001 in. (0.025 mm) of total indicator reading.
31. Seat (10) and valve (11)	Repeat steps 30a and 30b.	
32. Cap (8)	a. Inspect upper part where preformed packing (7) seats for scoring and excessive wear.	Discard if damaged or worn.
	b. Inspect lower seating area for distortion, pitting, and excessive wear.	Discard if damaged or worn.
33. Valve body (5) and cap (8)	a. Install new preformed packing (7) on valve body (5).	Position so the 'V' is at top of valve body (5).
	b. Move cap (8) in and out of valve body (5) to check for smooth operation.	If top of cap (8) sticks to bottom of valve body (5), file a cross on top of cap (8) (see illustration). Discard cap (8) if it has already been filed and still sticks.

3-51. AIR COMPRESSOR REPAIR (Contd)



LEGEND:

- | | |
|----------------------|-----------|
| 5. VALVE BODY | 11. VALVE |
| 7. PREFORMED PACKING | 14. SEAT |
| 8. CAP | 16. DISC |
| 10. SEAT | |

3-51. AIR COMPRESSOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

34. Springs (9), (12), and (17)	Test each spring on a spring tester that is capable of very accurate measurements of spring length and load.	Discard any spring not within limits shown below.
---------------------------------	--------------------------------------------------------------------------------------------------------------	---------------------------------------------------

Approximate Free Length:

Unloader Valve Spring (9) 1.65 in. (41.91 mm)
 Intake Valve Spring (12)..... 0.5 in. (12.7 mm)
 Exhaust Valve Spring (17)..... 0.67 in. (17.02 mm)

No. of Coils:

Spring (9) 12.0
 Spring (12) 2.80
 Spring (17) 3.0

Wire Diameter:

Spring (9) 0.072 in. (1.83 mm)
 Spring (12) 0.062 in. (1.58 mm)
 Spring (17) 0.080 in. (2.03 mm)

Working Length:

Spring (9) 0.98 in. (24.89 mm)
 Spring (12) 0.280 in. (7.11 mm)
 Spring (17) 0.280 in. (7.11 mm)

New Minimum:

Spring (9) 18 lb (8.07 kg)
 Spring (12) 0.65 lb (0.30 kg)
 Spring (17) 8.50 lb (3.86 kg)

New Maximum:

Spring (9) 22 lb (9.98 kg)
 Spring (12) 1.10 lb (0.50 kg)
 Spring (17) 10.4 lb (4.72 kg)

Wear Limit:

Spring (9) 17.0 lb (7.72 kg)
 Spring (12) 0.55 lb (0.25 kg)
 Spring (17) 8.0 lb (3.63 kg)

35. Crankshaft assembly (41)	a. Inspect for scratches and scoring.	Discard if damaged.
	b. Using suitable micrometer, measure diameter of the following items:	Discard if not within limits shown below.

New Minimum:

Front Support Journal (53) 1.872 in. (47.549 mm)
 Connecting Rod Journal (54) 1.9345 in. (49.1363 mm)
 Rear Coupling Journal (55) 1.872 in. (47.549 mm)
 Half Coupling Shaft (56)..... 1.003 in. (25.476 mm)


New Maximum:

Front Support Journal (53) 1.873 in. (47.574 mm)
 Connecting Rod Journal (54) 1.9355 in. (49.1617 mm)
 Rear Coupling Journal (55) 1.873 in. (47.574 mm)
 Half Coupling Shaft (56) 1.0035 in. (25.4889 mm)

Wear Limit:

Front Support Journal (53) 1.871 in. (47.523 mm)
 Connecting Rod Journal (54) 1.9330 in. (49.0982 mm)
 Rear Coupling Journal (55) 1.871 in. (47.523 mm)

3-51. AIR COMPRESSOR REPAIR (Contd)



LEGEND:

- 9. SPRING
- 12. SPRING
- 17. SPRING
- 41. CRANKSHAFT ASSEMBLY

- 53. FRONT SUPPORT JOURNAL
- 54. CONNECTING ROD JOURNAL
- 55. REAR COUPLING JOURNAL
- 56. HALF COUPLING SHAFT


3-51. AIR COMPRESSOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

36. Support (45)	a. Inspect for scratches and scoring.	Discard if damaged.
	b. Using suitable depth micrometer, measure support thrust flange (see illustration).	Discard if not within 1.307-1.310 in. (33.198-33.274 mm).
	c. Using suitable micrometer, measure inside diameter of support bearing.	Discard support (45) if inside diameter of bearing is not within limits shown below.
	New Minimum	1.8740 in. (47.5996 mm)
	New Maximum	1.8760 in. (47.6504 mm)
	Wear Limit	1.8775 in. (47.6885 mm)
37. Thrust bearing (48)	Using suitable micrometer, measure thickness.	Discard if not within 0.2400-0.2480 in. (6.096-6.2992 mm).
38. Drive coupling (1) and half coupling (49)	a. Inspect for excessive wear, scoring, and other damage.	Discard if worn or damaged.
	b. Using suitable micrometer, measure inside diameter of half coupling (49).	Discard if inside diameter is not within 1.000-1.001 in. (25.4-25.425 mm).
39. Connecting rod assembly (32)	a. Inspect inside diameter of both ends for scoring and other damage.	Discard if damaged.
	b. Using suitable micrometer, measure inside diameter of crankshaft end.	Discard if more than 1.935 in. (49.149 mm).
	c. Using suitable micrometer, measure inside diameter of bushing (33).	Remove and discard bushing (33) if more than 0.6895 in. (17.5133 mm).
	d. Check for bend and twist.	Discard if bend is more than 0.002 in. (0.508 mm) or twist is more than 0.004 in. (0.102 mm).

3-51. AIR COMPRESSOR REPAIR (Contd)



LEGEND:

- 1. DRIVE COUPLING
- 32. CONNECTING ROD ASSEMBLY
- 33. BUSHING

- 45. SUPPORT
- 48. THRUST BEARING
- 49. HALF COUPLING

3-51. AIR COMPRESSOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

40. Piston pin (31)	Using suitable micrometer, outside diameter.	Discard if not within limits measure shown below.
---------------------	----------------------------------------------	---------------------------------------------------

New Minimum	0.6875 in. (17.4625 mm)
New Maximum	0.6876 in. (17.465 mm)
Wear Limit	0.6872 in. (17.4549 mm)

41. Piston (29)	a. Inspect for scoring, cracks, wear, and other damage.	Discard if damaged or worn.
-----------------	---------------------------------------------------------	-----------------------------

b. Using suitable micrometer, measure outside diameter 1 in. (25.4 mm) below and at a right angle to pin bore.	Discard if not within limits shown below at 70°F (21°C).
----------------------------------------------------------------------------------------------------------------	----------------------------------------------------------

New Minimum	3.619 in. (91.923 mm)
New Maximum	3.620 in. (91.948 mm)
Wear Limit	3.6165 in. (91.8591 mm)

c. Using suitable micrometer, measure pin bore.	Discard if not within limits shown below at 70°F (21°C).
-------------------------------------------------	----------------------------------------------------------

New Minimum	0.6880 in. (17.4752 mm)
New Maximum	0.6885 in. (17.4879 mm)
Wear Limit	0.6890 in. (17.5006 mm)

d. Check ring grooves as follows:

(1) Install new rings (26), (27), and (28) on piston ring grooves.

(2) Insert a 0.004 in. (0.1016 mm) feeler gauge between ring and ring groove.



(3) Compress ring into ring groove.	Discard piston (29) if ring goes below piston land surface with feeler gauge in place.
-------------------------------------	----------------------------------------------------------------------------------------

e. Check piston ring end gap as follows:

(1) Install new rings (26), (27), and (28) on cylinder bore of housing (37).	Use piston head to seat rings squarely on an unworn portion of cylinder bore. Repeat this step until all three rings have been installed.
------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------

(2) Measure piston ring end gap with feeler gauge.	Discard any ring with gap not within 0.010-0.020 in. (0.254-0.508 mm).
----------------------------------------------------	------------------------------------------------------------------------

3-51. AIR COMPRESSOR REPAIR (Contd)



LEGEND:

- 26. RING
- 27. RING
- 28. RING
- 29. PISTON

- 31. PISTON PIN
- 33. BUSHING
- 37. HOUSING

3-51. AIR COMPRESSOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

42. Crankcase assembly (35)	a. Inspect for scoring and other damage. b. Hone cylinder bore as required to remove glaze. Clean with SD-3 solvent. c. Using suitable dial bore gauge, check cylinder bore for out-of-round and wear.	Discard if damaged. Discard if not within limits shown below.
-----------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------

Out-of-Round (Maximum) 0.0015 in. (0.0381 mm)
 Bore Diameter (Maximum) 3.6285 in. (92.1639 mm)


d. Using suitable micrometer, measure inside diameter of bearing (36).	Do step 42e only if more than 1.8780 in. (47.7012 mm).
------------------------------------------------------------------------	--------------------------------------------------------

CAUTION

To avoid damage, always support housing when removing or installing bearing.

e. Replace bearing (36) as follows: (1) Press bearing (36) out of housing (37). (2) Lubricate bushing bore in housing (37) and press in new bearing (36).	Do this step only if bearing (36) is damaged or not within wear limits. Use air compressor bushing mandrel (ST-1105 or ST-1143) (57). Bearing (36) should be flush with bore surface of housing (37).
-------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-51. AIR COMPRESSOR REPAIR (Contd)



LEGEND:

- 35. CRANKCASE ASSEMBLY
- 36. BEARING

- 37. HOUSING
- 57. AIR COMPRESSOR BUSHING MANDREL

3-51. AIR COMPRESSOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly

- | | |
|---------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 43. Piston (29), two retaining rings (30), pin (31), and connecting rod assembly (32) | <ul style="list-style-type: none"> a. Install one retaining ring (30) on retaining ring groove on piston (29). b. Position and align connecting rod assembly (32) with piston (29). |
|---------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

CAUTION

Driving pin in pin bore could damage piston. If pin cannot be installed by hand pressure, place piston in hot water to expand pin bore and allow pin to be installed.


- | | | |
|----------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 44. New ring (28) | <ul style="list-style-type: none"> c. Install pin (31) through pin bore and connecting rod assembly (32) until it seats against installed retaining ring (30). d. Install other retaining ring (30) on retaining ring groove on piston (29). | Use gloves if piston (29) has been in hot water. |
| 45. New rings (26) and (27) | Install in top and middle piston ring grooves. | Be careful not to scratch piston (29) as ring (28) is installed. |
| 46. New rings (26), (27), and (28) | Stagger ring gaps until they are about 180° apart and are not located over pin bore. | Be careful not to scratch piston (29) as rings (26) and (27) are installed. Rings are installed with word "top" toward crown of piston (29). Top and middle rings are different and are not interchangeable. |
| 47. Piston (29), connecting rod assembly (32), and crankcase assembly (35) | <ul style="list-style-type: none"> a. Lubricate rings (26), (27), and (28), and crankcase assembly (35) with lubricating oil. b. Install a standard ring compressor on piston (29) to compress rings. | Make sure rings are in grooves of piston (29) and are not in a bind. |

CAUTION

Any difficulty in installing piston and connecting rod assembly into cylinder bore of housing may indicate that a ring is in a bind. To avoid cracking a ring and damaging cylinder wall, do not force piston into cylinder bore.

- | | | |
|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
| 48. Plate (39) | <ul style="list-style-type: none"> c. Install piston (29) and connecting rod assembly (32) into cylinder bore of housing (37). a. Place on housing (37). b. Secure with two screws (40). | Use a suitable tool with soft face to carefully push piston (29) from ring compressor into cylinder bore. |
|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|

3-51. AIR COMPRESSOR REPAIR (Contd)



LEGEND:

- | | |
|------------------------|-----------------------------|
| 26. RING | 32. CONNECTING ROD ASSEMBLY |
| 27. RING | 35. CRANKCASE ASSEMBLY |
| 28. RING | 37. HOUSING |
| 29. PISTON | 39. PLATE |
| 30. RETAINING RING (2) | 40. SCREW (2) |
| 31. PIN | |

3-51. AIR COMPRESSOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)


<p>49. Crankshaft assembly (35) and support (45)</p>	<p>a. Lubricate front support journal of crankshaft (43) and bearing (36) on support (45) with lubricating oil. b. Install crankshaft assembly (41) on support (45). c. Secure support (45) to crankcase assembly (35) with two captive washer screws (38), four screws (47), and four new lockwashers (46).</p>	<p>Tighten captive washer screws (88) and (47) to 30-35 lb-ft (41-47 N•m).</p>
<p>50. Thrust bearing (48)</p>	<p>a. Lubricate slotted end with lubricating oil. b. Install over end of crankshaft (43) and on support (45).</p>	<p>Slotted side of thrust bearing (48) is installed toward crankshaft (43) and support (45).</p>

CAUTION

To avoid damaging air compressor support, make sure crankshaft is properly secured before using press.

<p>51. Half coupling (49)</p>	<p>Press on crankshaft (43) until it bottoms out.</p>
-------------------------------	-------------------------------------------------------

3-51. AIR COMPRESSOR REPAIR (Contd)



LEGEND:

- 35. CRANKCASE ASSEMBLY
- 36. BEARING
- 38. CAPTIVE WASHER SCREW (2)
- 41. CRANKSHAFT ASSEMBLY
- 43. CRANKSHAFT

- 45. SUPPORT
- 46. LOCKWASHER (4)
- 47. SCREW (4)
- 48. THRUST BEARING
- 49. HALF COUPLING


3-51. AIR COMPRESSOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)

52. Crankshaft (43), support (45), new gasket (44), and crankcase assembly (35)	a. Position piston (29) at 90° after top dead center to allow crankshaft (43) to be installed through connecting rod (34). b. Install crankshaft (43) on crankcase assembly (35) and through crankshaft bore end of connecting rod (34).	
53. Disc (16)	Position on seat (14).	
54. New preformed packings (13) and (15)	Install seat (14).	Lubricate preformed packings (13) and (15) with clean lubricating oil.
55. Shim (18), spring (17), and seat (14)	Install on cylinder head (24).	Use thumb pressure to press seat (14) in position with cylinder head (24).
56. Spring (12), valve (11), and seat (10)	Install seat (14) on cylinder head(24).	
57. New gasket (25), cylinder head (24), new gasket (23), and cover (22)	a. Position on cylinder bore of crankcase assembly (35). b. Secure with four screws (19), four new lockwashers (20), and four washers (21).	Tighten screws (19) to 15-19 lb-ft (20-26 N•m).

3-51. AIR COMPRESSOR REPAIR (Contd)



LEGEND:

- | | |
|-----------------------|------------------------|
| 10. SEAT | 21. WASHER (4) |
| 11. VALVE | 22. COVER |
| 12. SPRING | 23. GASKET |
| 13. PREFORMED PACKING | 24. CYLINDER HEAD |
| 14. SEAT | 25. GASKET |
| 15. PREFORMED PACKING | 29. PISTON |
| 16. DISC | 34. CONNECTING ROD |
| 17. SPRING | 35. CRANKCASE ASSEMBLY |
| 18. SHIM | 43. CRANKSHAFT |
| 19. SCREW (4) | 44. GASKET |
| 20. LOCKWASHER (4) | 45. SUPPORT |

3-51. AIR COMPRESSOR REPAIR (Contd)


LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)

58. New preformed packings (6) and (7)	Install on cap (8).	Lubricate preformed packing (6) with clean lubricating oil, and use antiseize compound on preformed packing (7).
59. Valve body (5)	Install on cap (8).	
60. Spring (9)	Place on cylinder head (24).	
61. Valve body (5) and cap (8)	a. Install over spring (9) and on cover (22). b. Secure with two captive washer screws (3) and two washers (4).	Align three prongs on cap (8) with openings on seat (10). Tighten captive washer screws (3) to 96-132 lb-in. (11-15 N•m).

FOLLOW-ON TASK: Install air compressor (para. 3-77).

3-51. AIR COMPRESSOR REPAIR (Contd)



LEGEND:

- 3. CAPTIVE WASHER SCREW (2)
- 4. WASHER (2)
- 5. VALVE BODY
- 6. PREFORMED PACKING
- 7. PREFORMED PACKING

- 8. CAP
- 9. SPRING
- 10. SEAT
- 22. COVER
- 24. CYLINDER HEAD

3-52. FUEL INJECTOR REPAIR

THIS TASK COVERS:

- a. Disassembly
- b. Cleaning

- c. Inspection
- d. Assembly

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Injector stand (15434) ST-1298
 Injector cup wrench (15434) ST-995
 Crowfoot wrench (15434) ST-1072

TEST EQUIPMENT

None

MATERIALS/PARTS

Mineral spirits (Appendix C, Item 17)
 Solvent, SD-3 (Appendix C, Item 4)
 Diesel fuel, regular (Appendix C, Item 19)
 Lapping compound, 280-grit (Appendix C, Item 8)
 Compound, Prussian blue (Appendix C, Item 9)
 Oil, lubricating, OE/HDO 10
 (Appendix C, Item 20)
 Gasket (15434) 173086
 Three gaskets (15434) 193736

PERSONNEL REQUIRED

Fuel and electrical systems repairman MOS 63G

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Injector assembly removed (para. 3-23).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

- Diesel fuel is flammable.
- Always wear eye protection when cleaning with compressed air.
- Use approved solvent in well-ventilated area.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly

NOTE

- Injector barrels and plungers are not interchangeable.
- Use this procedure to repair any of the six fuel injector assemblies.


1. Plunger (2)	Lift out.	Store plunger (2) by standing it on coupling end.
2. Top-stop locknut (4) and top-stop screw (3)	Remove.	
3. Washer(5) and injector spring (6)	Lift out.	
4. Three gaskets (8)	Remove.	Discard gaskets (8).
5. Filter screen clip (14), filter screen (15), and gasket (16)	Remove from top-stop adapter (7). screen (15) only if damaged.	Discard gasket (16). Discard filter

NOTE

Do not remove or turn adjustable orifice plug located behind filter screen. The orifice plug has been pre-set. Fuel delivery is adjusted by changing orifice plug or by burnishing plug in its operating position.

6. Top-stop adapter (7) and cup retainer (11)	Loosen.	Secure injector assembly (1) into injector stand (ST-1298). Using body and injector cup wrench (ST-995), loosen retainer (11) but do not remove. When loose, remove injector from stand.
-----------------------------------------------	---------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-52. FUEL INJECTOR REPAIR (Contd)



LEGEND:

- 1. INJECTOR ASSEMBLY
- 2. PLUNGER
- 3. TOP-STOP SCREW
- 4. TOP-STOP LOCKNUT
- 5. WASHER
- 6. INJECTOR SPRING
- 7. TOP-STOP ADAPTER
- 8. GASKET (3)

- 9. BARREL
- 10. INJECTOR CUP
- 11. CUP RETAINER
- 12. CHECK BALL
- 13. ROLL PIN (2)
- 14. FILTER SCREEN CLIP
- 15. FILTER SCREEN
- 16. GASKET

3-52. FUEL INJECTOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)

- | | | |
|----|--------------------------------------------|-----------|
| 7. | Top-stop adapter (7) and cup retainer (11) | Separate. |
|----|--------------------------------------------|-----------|

CAUTION

- Do not pry against machined surface when removing two roll pins. Damage to machine surface may result
- Do not lose check ball.

- | | | |
|----|------------------------------------------------------------------------|---------|
| 8. | Barrel (9), injector cup (10), check ball (12), and two roll pins (13) | Remove. |
|----|------------------------------------------------------------------------|---------|

CAUTION

Do not use drills or other instruments to clean cup holes that will alter size of holes. Wires may be used if a smaller size wire is used than spray hole. Do not use a wire brush or crocus cloth to clean cup tip area, or damage to cup tip may result.

NOTE

Most injector failures occur because of dirt. Clean parts thoroughly before assembly.


b. Cleaning

WARNING

Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

- | | | | |
|----|----------------------------------------------------------------------------------------|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 9. | Injector spring (6), top-stop locknut (4), top-stop adapter (7), and cup retainer (11) | Clean. | Soak parts in a suitable cleaning solvent, such as SD-3, to remove carbon varnish. This may require several hours of soaking. Neutralize solvent after cleaning by dipping parts in mineral spirits. |
|----|----------------------------------------------------------------------------------------|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

3-52. FUEL INJECTOR REPAIR (Contd)



LEGEND:

- 4. TOP-STOP LOCKNUT
- 6. INJECTOR SPRING
- 7. TOP-STOP ADAPTER
- 9. BARREL

- 10. INJECTOR CUP
- 11. CUP RETAINER
- 12. CHECK BALL
- 13. ROLL PIN (2)

3-52. FUEL INJECTOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Cleaning(Contd)

CAUTION

Injector barrels and plungers are not interchangeable. To avoid equipment damage, do not mix injector barrels and plungers.

10. Plunger (2), barrel (9), and injector cup (10)	Clean.	The use of an ultrasonic cleaner is recommended for plunger, barrel, and injector cup.
----------------------------------------------------	--------	----------------------------------------------------------------------------------------

WARNING

Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.

11. All cleaned parts	Dry with compressed air.	Place all cleaned injector assembly (1) part under cover to prevent contamination.
-----------------------	--------------------------	------------------------------------------------------------------------------------


c. Inspection

CAUTION

Handle injector plunger with care to prevent damage.

12. Plunger (2)	Inspect for: a. Scuffing or scoring. b. Bright spots at machined area bottom and mid-point. c. Surface defects. d. Cracks or looseness.	Replace plunger (2) and barrel (9) if scuffed or scored. This is a normal condition. Replace if evident. Replace if cracked or loose. Rotate by hand to determine looseness.
13. Injector spring (6)	Inspect for: a. Excessive wear. b. Spring compression. c. Spring squareness.	Use suitable spring tester. Discard if 138 lb (62.65 kg) or less at 1.663 in. (42.240 mm) spring height. Use dial indicator. Rotate spring and measure at top and bottom of spring (6). Discard if 0.016 in. (0.406 mm) is exceeded.
14. Injector cup (10)	Inspect spray holes and tip for: a. Abrasive wear. b. Corrosion and erosion. c. Enlarged or distorted spray holes.	Use magnifying glass. Compare to new cup. Internally and externally. If hole size has not changed, reuse. Discard if holes are enlarged.

3-52. FUEL INJECTOR REPAIR (Contd)



LEGEND:

- 1. INJECTOR ASSEMBLY
- 2. PLUNGER
- 6. INJECTOR SPRING

- 9. BARREL
- 10. INJECTOR CUP

3-52. FUEL INJECTOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection (Contd)

CAUTION

The injector plunger must seat in cup from 1/4 of upper cone area to full cone area. Reject a cup that seats in lower 14 cup tip area. If a cup seats in the tip area, it must seat more than 1/2 of cone area to be accepted.

d. Plunger seat pattern.	Using new injector plunger (2), coat with Prussian blue and rotate 90°. If 40 percent continuous coverage is maintained, it may be reused but must pass the cup-to-plunger test.
--------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

15. Cup retainer (11)	Inspect for a. Damaged threads. b. Nicks and burrs on outside heat seating area and inside seating ledge.	Nicks and burrs will prevent proper seating.
-----------------------	-----------------------------------------------------------------------------------------------------------------	----------------------------------------------

NOTE


If injector passes leakage test, barrel is usable. If leakage is high, barrel and plunger must be replaced.

16. Barrel (9)	Inspect for: a. Scoring of bore area. b. Burrs, carbon, and distorted radius in the orifice. c. Loose or cracked fuel passage plugs. d. Damage and flatness at mating surfaces.	Lap with a grade A 280-grit lapping compound to remove mutilation or unevenness. Use a surface plate to check surface flatness.
----------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------

17. Check ball (12) and ball seat	Inspect for: a. Nicks and burrs on ball (12). b. Depth of ball seat.	Discard if burred or nicked. Maximum is 0.050 in. (1.27 mm) below surface of barrel (9).
-----------------------------------	----------------------------------------------------------------------------	------------------------------------------------------------------------------------------

18. Top-stop adapter (7)	Inspect for: a. Burrs or obstructions around orifice. b. Obstructions in fuel passage openings. c. Damaged threads. d. Gasket area for nicks or burrs. e. Mating surface for nicks or burrs. f. Damage and flatness at mating surfaces.	Discard if unable to remove. Clean. Rethread. Remove nicks or burrs, or gaskets (8) will be damaged. Discard if unable to remove.
--------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------

3-52. FUEL INJECTOR REPAIR (Contd)



LEGEND:

- 2. PLUNGER
- 7. TOP-STOP ADAPTER
- 8. GASKET (3)

- 9. BARREL
- 11. CUP RETAINER
- 12. CHECK BALL

3-52. FUEL INJECTOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly

CAUTION

Be certain all mating surface parts are clean and free of burrs or defects which will result in incorrect flow or torque.

- | | | |
|------------------------|----------------------------------|--|
| 19. Check ball (12) | Insert in barrel (9). | |
| 20. Two roll pins (13) | Install on top-stop adapter (7). | |

CAUTION

Be aware that check ball could fall out during assembly of barrel and injector cup which could render injector useless.

- | | | |
|------------------------------------------------|-------------------------------------------|--------------------------------------------------------------------------------------|
| 21. Barrel (9) and injector cup (10) | Insert in top-stop adapter (7). | Apply a light coat of OE/HDO 10 lubricating oil to barrel (9) and injector cup (10). |
| 22. Cup retainer (11) and top-stop adapter (7) | Screw down finger-tight. Loosen 1/4 turn. | |

WARNING

Do not perform fuel system procedures while smoking or within 50 ft (15.2 m) of sparks or open flame. Diesel fuel is flammable and may explode. Failure to comply may result in injury to personnel.

- | | | |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| 23. Plunger(2) | Insert in injector assembly (1). | Immerse plunger (2) in clean diesel fuel. |
| 24. Injector assembly (1) | Place in injector stand (17) as follows:
a. Position base with single pin in center of injector stand (17).
b. Back off stud (22) from injector stand (17) and slide clamp bar (21) over injector assembly flats (20).
c. Place retainer cup wrench (19) on cup retainer (11).
d. Tighten stud (22) in injector stand (17) to 75 lb-in. (8. N•m). | Lubricate threads on stud (22) and screw in injector stand (17) with OE/HDO 10 lubricating oil.

This aligns cup and injector plunger. |

CAUTION

When removing injector from injector stand, do not hit cup retainer on stud.


- | | | |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 25. Plunger (2) | e. Tighten cup retainer (11) with crowfoot wrench to 53-57 lb-ft (72-77 N•m).

Check injector cup (10) to plunger (2) alignment as follows:
a. Coat plunger (2) with clean diesel fuel. | Use crowfoot wrench (ST-1072). Remove from injector stand (ST-1298) (17) when task is completed.

Hold injector assembly (1) with injector cup (10) down and allow plunger (2) to drip a few drops of diesel fuel. |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

3-52. FUEL INJECTOR REPAIR (Contd)

- b. Insert in barrel (9) so plunger (2) remains 0.50 in. (12.7 mm) from edge of top-stop adapter (7).
- c. Jam plunger (2) with palm of hand to seat in injector cup (10). Hold plunger (2) firmly against seat and rotate 90°.



LEGEND:

- | | | |
|----------------------|-------------------------|-----------------------------|
| 1. INJECTOR ASSEMBLY | 11. CUP RETAINER | 20. INJECTOR ASSEMBLY FLATS |
| 2. PLUNGER | 12. CHECK BALL | 21. CLAMP BAR |
| 7. TOP-STOP ADAPTER | 13. ROLL PIN (2) | 22. STUD |
| 9. BARREL | 17. INJECTOR STAND | |
| 10. INJECTOR CUP | 19. RETAINER CUP WRENCH | |

3-52. FUEL INJECTOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)

CAUTION

Do not allow plunger to fall out when holding injector assembly with cup facing up.

	<p>d. With one hand, turn injector assembly (1) so injector cup (10) faces upward. Plunger (2) should slide out immediately.</p>	<p>If plunger (2) does not slide out immediately, injector assembly (1) is not aligned and must be reassembled as outlined in steps 19 through 25.</p>
<p>26. Three new gaskets (8)</p>	<p>Install on grooves.</p>	
<p>27. New gasket (16), filter screen (15), and filter screen clip (14)</p>	<p>Install on top-stop adapter (7).</p>	<p>Replace gasket (16) if required.</p>


NOTE

After assembly, store injector in a clean place until ready for testing and calibration.

<p>28. Injector spring (6) and washer (5)</p>	<p>Install on plunger (2) and insert in top-stop adapter (7) on injector assembly (1).</p>	<p>Do not install top-stop locknut (4) and top-stop screw (3) at this time. Store with injector assembly (1).</p>
-----------------------------------------------	--------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------

FOLLOW-ON TASK: Perform fuel injector testing; Test No. 1 (para. 3-53).

3-52. FUEL INJECTOR REPAIR (Contd)



LEGEND:

- 1. INJECTOR ASSEMBLY
- 2. PLUNGER
- 3. TOP-STOP SCREW
- 4. TOP-STOP LOCKNUT
- 5. WASHER
- 6. INJECTOR SPRING

- 7. TOP-STOP ADAPTER
- 8. GASKET (3)
- 10. INJECTOR CUP
- 14. FILTER SCREEN CLIP
- 15. FILTER SCREEN
- 16. GASKET

3-53. FUEL INJECTOR TESTING; TEST NO. 1

THIS TASK COVERS:

a. Cup to Plunger Seal Test

c. Check Ball Leakage Test

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Injector adapter pot (15434) 3375086
 Plug (15434) ST-668-14
 Plunger extension (15434) ST-1089

TEST EQUIPMENT

Injector leakage tester (15434) 3375375

MATERIALS/PARTS

Oil, lubricating, OE/HDO 10
 (Appendix C, Item 20)

PERSONNEL REQUIRED

Fuel and electrical system repairman
 MOS 63G

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Injector assembly removed (para. 3-23).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Cup to Plunger Seal


NOTE

The assembled injector is tested and calibrated without the top-stop screw and top-stop locknut.

- | | | | |
|----|-----------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| 1. | Plunger(8), retainer (7), injector spring (6), filter screen clip (9), and filter screen (10) | Remove. | |
| 2. | Plunger extension (2) | Install on plunger (8) and place in injector assembly (1). | |
| 3. | Injector assembly (1) | a. Align injector delivery orifice (11) with burnishing hole (5).
b. Using hand pressure, press into adapter (4) until it bottoms.
c. Insert and tighten locating screw (3) in adapter (4).
d. Plug fuel inlet port. | Lubricate three gaskets (12) with OE/HDO 10 lubricating oil.

Use plug (ST-668-14). |

3-53. FUEL INJECTOR TESTING; TEST NO. 1 (Contd)



LEGEND:

- | | |
|----------------------|-------------------------------|
| 1. INJECTOR ASSEMBLY | 7. RETAINER |
| 2. PLUNGER EXTENSION | 8. PLUNGER |
| 3. LOCATING SCREW | 9. FILTER SCREEN CLIP |
| 4. ADAPTER | 10. FILTER SCREEN |
| 5. BURNISHING HOLE | 11. INJECTOR DELIVERY ORIFICE |
| 6. INJECTOR SPRING | 12. GASKET (3) |

3-53. FUEL INJECTOR TESTING; TEST NO. 1 (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Cup to Plunger Seal Test (Contd)


	e. Install on leakage tester (13) and clamp in position.	Support plate (14) may be tilted for easier installation. Use spacer (22).
4. Knurled knob (17)	Adjust to obtain proper clearance with feeler gauge (19).	Do not adjust locknut (18).
5. Transfer line (24)	Install and tighten on drain port of injector assembly (1).	This is port on right when facing front of leakage tester (13).
6. T-handle clamp (15)	Tighten.	
7. Retractor lever (16)	Shift from position A to position B.	Ensure plunger retracts. The plunger may stick in cup seat.

NOTE

Disregard presence of bubbles in bubble checker. Read air flow meter at top of ball flat.

8. Spacer (22)	<p>a. Rotate in clockwise direction in small increments while reading air flow meter (25). Stop rotating when highest reading is obtained.</p> <p>b. Air flow meter (25) should not indicate over 4.5.</p>	<p>Do not touch plunger top under spacer (22) or any part of the cleaning mechanism while taking reading. External forces will disturb plunger from its normal position and may affect barrel-to-plunger leakage in cup area. If reading is over 4.5, replace plunger and barrel in injector assembly (1).</p>
9. Retractor lever (16)	Shift from B to A.	
10. T-handle clamp (15)	<p>a. Loosen.</p> <p>b. Check for injector cup leakage as follows: (1) Observe bubble checker (23). Bubbles should not appear during first 10 seconds of testing. (2) Once a bubble does appear, observe time it takes for next one to appear. Not more than one bubble can appear every five seconds.</p>	<p>This will apply 200 lbs (889 kg) load to spacer (22).</p> <p>If bubbling is too high, replace cup in injector assembly (1).</p>

3-53. FUEL INJECTOR TESTING; TEST NO. 1 (Contd)



LEGEND:

- 1. INJECTOR ASSEMBLY
- 13. LEAKAGE TESTER
- 14. SUPPORT PLATE
- 15. T-HANDLE CLAMP
- 16. RETRACTOR LEVER
- 17. KNURLED KNOB

- 18. LOCKNUT
- 19. FEELER GAUGE
- 22. SPACER
- 23. BUBBLE CHECKER
- 24. TRANSFER LINE
- 25. AIR FLOW METER

3-53. FUEL INJECTOR TESTING; TEST NO. 1 (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Cup to Plunger Seal Test (Contd)


- | | | |
|-----------------------------------|--------------------------------------------------|--|
| 11. Transfer line (24) | Remove from adapter (4). | |
| 12. Cylinder actuation valve (21) | Release air pressure. | |
| 13. Injector assembly (1) | Remove from leakage tester (13) and adapter (4). | |
| 14. Locating screw (3) | Remove from adapter (4). | |

b. Check Ball Leakage

- | | | |
|-----------------------------------|---------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| 15. Transfer line (24) | Install on inlet port of adapter (4). | |
| 16. Adapter (4) | Install plug. | This is plug ST-668-14. |
| 17. Pressure regulator (20) | Adjust to 80 psi (551 kPa). | |
| 18. Cylinder actuation valve (21) | Direct air flow to plug. | |
| 19. Air flow meter (25) | Observe reading. | Maximum reading of 12 units is acceptable. If reading exceeds 12, rework injector seat. In some cases, replacing check ball is all that is required. |

FOLLOW-ON TASK: Perform fuel injector testing: Test No. 2 (para. 3-54).

3-53. FUEL INJECTOR TESTING; TEST NO. 1 (Contd)



LEGEND:

- 1. INJECTOR ASSEMBLY
- 3. LOCATION SCREW
- 4. ADAPTER
- 13. LEAKAGE TESTER

- 20. PRESSURE REGULATOR
- 21. CYLINDER ACTUATION VALVE
- 24. TRANSFER LINE
- 25. AIR FLOW METER

3-54. FUEL INJECTOR TESTING; TEST NO. 2

THIS TASK COVERS:

a. Setting Up Spray Pattern Tester

b. Spray Pattern Test

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Plunger bore plug assembly (15434) ST-668-5012

TEST EQUIPMENT

Injector test stand (15434) ST-790
Spray test fixture (15434) ST-668

MATERIALS/PARTS

None

PERSONNEL REQUIRED

Fuel and electrical systems repairman
MOS 63G

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Table 2-8

EQUIPMENT CONDITION

Fuel injector test No. 1 performed (para. 3-53).

SPECIAL ENVIRONMENTAL CONDITION

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS


None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Setting Up Spray Pattern Tester

1. Injector assembly (5)	a. Remove plunger (2), injector spring (4), and spring retainer (3). b. Install on adapter (14).	Store plunger (2), spring retainer (3), and injector spring (4) in a safe place.
2. Injector plunger bore of injector assembly (5)	Install plunger bore plug with rubber seal.	The correct type of plunger bore plug and rubber seal is determined by the type of injector.
3. Knurled plug (13)	Install on adapter (14) drain opening.	
4. Seat bracket bore (11)	Install applicable seat spacer.	Use an 18° cup with spacer marking H-18. Seat spacer is part of spray test fixture.
5. Target ring (12)	Place in spray pattern adapter base (10).	Select correct target ring (12). Target rings (12) are marked on handle.
6. Injector assembly (5)	Place in spray pattern tester (8) and tighten inlet hose connector (7).	
7. Holddown bracket (15)	Position injector assembly (5) in holddown bracket (15) and secure with knurled plug (13).	
8. Spray pattern tester (8)	Locate near or on injector test stand (1).	Any source of 22 psi (152 kPa) constant fuel pressure will operate spray pattern tester.

3-54. FUEL INJECTOR TESTING; TEST NO. 2 (Contd)



LEGEND:

- | | |
|-------------------------|-----------------------|
| 1. INJECTOR TEST STAND | 9. DRAIN HOSE |
| 2. PLUNGER | 10. ADAPTER BASE |
| 3. SPRING RETAINER | 11. SEAT BRACKET BORE |
| 4. INJECTOR SPRING | 12. TARGET RING |
| 5. INJECTOR ASSEMBLY | 13. KNURLED PLUG |
| 6. KNOB | 14. ADAPTER |
| 7. INLET HOSE CONNECTOR | 15. HOLDDOWN BRACKET |
| 8. SPRAY PATTERN TESTER | |

3-54. FUEL INJECTOR TESTING; TEST NO. 2 (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Setting Up Spray Pattern Tester (Contd)


- | | | |
|-----------------------------|---------------------------------------------------------------------------|--|
| 9. Inlet hose connector (7) | Connect to adapter (14) from injector test stand (1). | |
| 10. Drain hose (9) | Connect to adapter base (10) and place loose end in test stand drain pan. | |

b. Spray Pattern

- | | | |
|---------------------------------------------------------------|--------------------------------------------------------------------|-------------------------------------------------------------------------|
| 11. Injector test stand (1) | Apply 22 psi (152 kPa) fuel pressure. | |
| 12. Target ring (12) | a. Shift so one spray stream hits center of No. 1 or index window. | This can be observed through window and is next to target slide handle. |
| | b. Each spray stream must hit a window in target ring (12). | |
| 13. Holddown bracket (15) | Loosen knob (6). | |
| 14. Injector assembly (5) | Remove from spray pattern tester (8). | |
| 15. Knurled plug (13) | Remove from adapter (14). | |
| 16. Injector assembly (5) | Remove from adapter (14). | |
| 17. Injector spring (4), spring retainer (3), and plunger (2) | Install on injector assembly (5). | |

FOLLOW-ON TASK: Perform fuel injector testing; Test No. 3 (para. 3-55).

3-54. FUEL INJECTOR TESTING; TEST NO. 2 (Contd)



LEGEND:

- | | |
|-------------------------|-------------------------|
| 1. INJECTOR TEST STAND | 8. SPRAY PATTERN TESTER |
| 2. PLUNGER | 9. DRAIN HOSE |
| 3. SPRING RETAINER | 10. ADAPTER BASE |
| 4. INJECTOR SPRING | 12. TARGET RING |
| 5. INJECTOR ASSEMBLY | 13. KNURLED PLUG |
| 6. KNOB | 14. ADAPTER |
| 7. INLET HOSE CONNECTOR | 15. HOLDDOWN BRACKET |

3-55. FUEL INJECTOR TESTING; TEST NO. 3

THIS TASK COVERS:

- | | |
|----------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------|
| <p>a. Setting Up Test Stand
 b. Setting Up Injector on Test Stand
 c. Testing Check Ball Seating</p> | <p>d. Adjusting and Measuring Fuel Delivery
 e. Top-stop Injector Adjustment</p> |
|----------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------|

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Test stand link (15434) ST 790-331
 Master injector (15434) ST-1262

TEST EQUIPMENT

Injector test stand (15434) ST-790

MATERIALS/PARTS

Fluid, automatic transmission, type A
 (Appendix C, Item 11)
 Oil, lubricating, OE/HDO 30
 (Appendix C, Item 21)

PERSONNEL REQUIRED

Fuel and electrical systems repairman
 MOS 63G

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Fuel injector test No. 2 performed (para. 3-54).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Setting Up Test

NOTE

Check fluid levels on injector test stand. The cam box is filled to the top level of sight glass with OE/HDO 30 lubricating oil. Refill when oil level drops to bottom level of sight glass. Fill hydraulic fluid reservoir to bulb level with type A automatic transmission fluid. Be careful not to allow oil to enter standpipe in center of reservoir. The test oil level in stand must be kept at least 3/4 full of test fuel.

- | | |
|------------------------------------------------------------|-------------------------------------------------------------------|
| <p>1. Timing wheel (11)</p> <p>2. Hydraulic valve (20)</p> | <p>Rotate so wheel mark and pointer are aligned.</p> <p>Open.</p> |
|------------------------------------------------------------|-------------------------------------------------------------------|

CAUTION

Do not operate test stand with load cell in position or damage may result.

- | | | |
|-----------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
| <p>3. Load cell tester (17)</p> <p>4. Air pressure regulator (22)</p> | <p>Position on test stand (27) and secure by opening air valve (21).</p> <p>a. Adjust by turning knurled knob (24) until load cell tester (17) registers within coded range markings.</p> <p>b. Lock in place with locknut (23).</p> | <p>Load cell tester (17) must be between 370 and 390 when adjusted within marked band on dial.</p> |
|-----------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


5. Load cell tester (17)

Remove as follows:

a. Place air valve (21) to center position.

b. Remove load cell tester (17).

With cylinder down, hydraulic fluid level should show in hydraulic fluid level sight bulb (1). If fluid level is low, add type A Automatic transmission fluid.



LEGEND:

- 1. HYDRAULIC FLUID LEVEL SIGHT BULB
- 2. AIR GAUGE
- 3. FUEL PRESSURE GAUGE
- 4. VIAL GRADUATE
- 5. VIAL LIGHT SWITCH
- 6. START-STOP SWITCH
- 7. FLOW START SWITCH
- 8. TEMPERATURE GAUGE

- 9. SOLENOID
- 10. COUNTER
- 11. TIMING WHEEL
- 12. SIGHT GLASS
- 13. CAM BOX
- 14. INLET
- 15. PRESSURE REGULATOR
- 16. OUTLET
- 17. LOAD CELL TESTER
- 18. ORIFICE HOLDER

- 19. DRAIN PAN
- 20. HYDRAULIC VALVE
- 21. AIR VALVE
- 22. AIR PRESSURE REGULATOR
- 23. LOCKNUT
- 24. KNURLED KNOB
- 25. HYDRAULIC FLUID SIGHT GLASS
- 26. HYDRAULIC FLUID RESERVOIR
- 27. INJECTOR TEST STAND

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Setting Up Test Stand (Contd)

6. Air valve (21)	Open with cylinder at top of its travel; no air should show in hydraulic fluid sight glass (25).	If air is indicated, tighten all line connections.
-------------------	--------------------------------------------------------------------------------------------------	----------------------------------------------------

CAUTION

The master injector is precalibrated and must never be reset or accuracy of test will be affected.


7. Adapter (28)	Place on master injector (31).	Ensure timing marks are aligned at timing wheel (step 1).
-----------------	--------------------------------	-----------------------------------------------------------

CAUTION

Ensure injector seat contains 0.020 in. (0.508 mm) restrictor orifice or damage to injector seat may result.

8. Test stand link (29)	Position over plunger link (35). Place master injector (31) in injector seat (32).	Tip back until test stand link (29) is below test stand pushrod (34) and not rubbing.
9. Air valve (21)	Open to clamp master injector (31) in place.	Ensure test stand link (29) is aligned.
10. Hydraulic valve (20)	Close to lock master injector (31) in place.	
11. Fuel drain connector (33)	Connect to adapter (28).	
12. Fuel inlet connector (30)	Connect to adapter (28).	

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)



LEGEND:

- 1. HYDRAULIC FLUID LEVEL SIGHT BULB
- 17. LOAD CELL TESTER
- 20. HYDRAULIC VALVE
- 21. AIR VALVE
- 23. LOCKNUT
- 25. HYDRAULIC FLUID SIGHT GLASS
- 28. ADAPTER

- 29. TEST STAND LINK
- 30. FUEL INLET CONNECTOR
- 31. MASTER INJECTOR
- 32. INJECTOR SET
- 33. FUEL DRAIN CONNECTOR
- 34. PUSHROD
- 35. PLUNGER LINK

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Setting Up Test Stand (Contd)

CAUTION

Test oil must be a minimum 90°F (32°C). If temperature is not up to 90°F (32°C), test stand must be warmed up on a standard injector, not a master injector. If temperature exceeds 95°F (35°C), increase cold water flow. If temperature exceeds 135°F (57°C), drain and replace with new test oil.

13. Start-stop switch (6)	Place in start position.	Temperature gauge (8) should read 90-95°F (32-35°C).
14. Pressure regulator (15)	Adjust by turning until fuel pressure gauge (3) reads 120 psi (827 kPa).	Pressure must be maintained at 120 psi (827 kPa) during injector calibration.
15. Counter (10)	Set as follows: a. Shift silver counter wheels (38) to the right. b. Rotate to indicate 1,020 strokes and release. c. Clear counter (10) by rotating thumbscrew (36) one complete revolution.	All white counter wheels (37) must read zero.
16. Flow start switch (7)	Press in and out until counter (10) reads 1,020 strokes.	Stir fuel with a rod to settle out foam. Check amount of fuel collected in vial graduate (4) at end of 1,020 counter strokes.
17. Vial graduate (4)	Look directly into vial graduate (4) and observe reading.	Look directly into vial graduate (4) at fuel to avoid parallax. Correct reading is 178 cc at 80 percent of stroke travel.

NOTE

Reading of 178 cc at 80 percent of stroke travel indicates test stand is in calibration. If reading is more than 178 cc, test stand is not set up properly. Repeat set-up steps if reading is below 178 cc.


18. Counter (10)	a. Roll counter (10) back. b. Set counter (10) up seven strokes for each cc less than 178 cc.	Refer to step 15.
19. Vial graduate (4)	Dump fuel.	
20. Flow start switch (7)	Press in and out until counter (10) sets strokes to obtain 178 cc.	

NOTE

If counter is set beyond 1,050 strokes to obtain 178 cc, test stand is not properly calibrated. Repeat set-up steps. If counter reads 1,050 or below, test stand is in calibration.

21. Start-stop switch (6)	Place in stop position.	
---------------------------	-------------------------	--

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)



LEGEND:

- | | |
|------------------------|---------------------------|
| 3. FUEL PRESSURE GAUGE | 15. PRESSURE REGULATOR |
| 4. VIAL GRADUATE | 20. HYDRAULIC VALVE |
| 6. START-STOP SWITCH | 21. AIR VALVE |
| 7. FLOW START SWITCH | 36. THUMBSCREW |
| 8. TEMPERATURE GAUGE | 37. WHITE COUNTER WHEELS |
| 9. SOLENOID | 38. SILVER COUNTER WHEELS |
| 10. COUNTER | |


3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Setting Up Test Stand (Contd)

22. Fuel inlet connector (30)	Remove from adapter (28).	
23. Hydraulic valve (20)	Open.	
24. Air valve (21)	Close.	
25. Master injector (31)	Remove.	
26. Test stand link (29)	Slide off plunger link (35).	
27. Adapter (28)	a. Remove test stand fuel inlet connector (30). b. Remove adapter (28) from master injector (31).	

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)



LEGEND:

- 6. START-STOP SWITCH
- 20. HYDRAULIC VALVE
- 21. AIR VALVE
- 28. ADAPTER

- 29. TEST STAND LINK
- 30. FUEL INLET CONNECTOR
- 31. MASTER INJECTOR
- 35. PLUNGER LINK

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


b. Setting Up Injector on Test

NOTE

- The top-stop adjustment is made after top-stop type injector is calibrated.
- Install 0.020 in. (0.508 mm) restriction orifice in cup seat and tighten to 6 lb-in. (0.9 N•m).

28. Filter and screen clip (43) and filter screen (44)	Remove.	
29. Plunger (40) and injector spring (42)	Remove.	
30. Plunger (40)	Place in injector assembly (39) without injector spring (42).	
31. Adapter (28)	Lubricate inside with diesel fuel.	Lubrication permits O-rings to slide more easily in adapter (28).
32. Injector assembly (39)	<p>a. Position in adapter (28) so injector assembly (39) inlet port and adapter (28) inlet holes are aligned.</p> <p>b. Secure by tightening locating screw (41) on adapter (28).</p>	
33. Fuel inlet connector (30)	Connect to adapter (28).	

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)



LEGEND:

- 28. ADAPTER
- 30. FUEL INLET CONNECTOR
- 39. INJECTOR ASSEMBLY
- 40. PLUNGER

- 41. LOCATING SCREW
- 42. INJECTOR SPRING
- 43. FILTER AND SCREEN CLIP
- 44. FILTER SCREEN

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


c. Testing Check Ball Seating

NOTE

Hold injector in hand; do not place in test stand holding device.

34. Plunger (40)	Hold plunger (40) down in injector assembly (39).	Injector assembly (39) must be in vertical position.
35. Start-stop switch (6)	Place in start position.	
36. Pressure regulator (15)	Adjust to 150 psi (1034 kPa) on fuel pressure gauge (3).	
37. Orifice plug inlet opening (45)	Check for leakage.	Plunger (40) must be seated in cup. If leakage is observed, check ball must be replaced. Slight seepage is acceptable.
38. Start-stop switch (6)	Place in stop position.	
39. Fuel inlet connector (30)	Disconnect from adapter (28).	

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)



LEGEND:

- 3. FUEL PRESSURE GAUGE
- 6. START-STOP SWITCH
- 15. PRESSURE REGULATOR
- 28. ADAPTER

- 30. FUEL INLET CONNECTOR
- 39. INJECTOR ASSEMBLY
- 40. PLUNGER
- 45. ORIFICE PLUG INLET OPENING

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Adjusting and Measuring Fuel Delivery


40. Plunger (40)	Remove from injector assembly (39).	
41. Injector spring (42) and plunger (40)	Place in injector assembly (39).	
42. Retainer plate (47)	Place over injector assembly (39).	
43. Two pins (46)	Screw on adapter (28).	
44. Test stand link (29)	Place on adapter (28) so contact is made with top plunger (40).	Use test stand link (29) 6.50 in. (165 mm) long.

NOTE

All tests on test stand are performed without an inlet screen in injector.

45. Injector assembly (39)	Place on test stand so injector assembly is in injector seat (32).	
----------------------------	--------------------------------------------------------------------	--

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)



LEGEND:

- 28. ADAPTER
- 29. TEST STAND LINK
- 32. INJECTOR SEAT
- 39. INJECTOR ASSEMBLY

- 40. PLUNGER
- 42. INJECTOR SPRING
- 46. PIN (2)
- 47. RETAINER PLATE


3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Adjusting and Measuring Fuel Delivery (Contd)

46. Burnishing tool (51)	Install on test stand fuel inlet connector (30).	
47. Burnishing tool needle (50)	Retract by pulling small knob (49) out.	With needle (50) retracted, burnishing tool (51) may be left in adapter during all test operations.
48. Fuel inlet connector (30)	Connect to adapter (28) inlet hole.	Connect by turning in large knob (48).
49. Fuel drain connector (33)	Turn screw on adapter (28).	
50. Injector assembly (39)	Run through test cycle.	Check cc delivery. If 600 stroke delivery is lower than 175-176 cc with top-stop set at 0.224 in. (5.670 mm), turn knob with indicator point until it is spaced 0.375 in. (9.525 mm) from large knob.

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)



LEGEND:

- 28. ADAPTER
- 30. FUEL INLET CONNECTOR
- 33. FUEL DRAIN CONNECTOR
- 39. INJECTOR ASSEMBLY

- 48. LARGE KNOB
- 49. SMALL KNOB
- 50. BURNISHING TOOL NEEDLE
- 51. BURNISHING TOOL

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Adjusting and Measuring Fuel Delivery (Contd)

NOTE


The following instructions are for ST-790 test stand only. Refer to operating instructions for any other test stand.

CAUTION

When seating burnishing tool, use care not to push small knob in too hard or overtighten indicator knob. Stop when slight contact is made. Damage can be caused to injector assembly. Test stand must be running while burnishing.

51. Burnishing tool (51)	Burnish as follows:	
	a. Turn indicating knob (52) until there is a space 0.375 in. (9.525 mm) from large knob (48).	
	b. Slowly push small knob (49) in until slight contact is made on injector assembly (39).	
	c. Turn small knob (49) counterclockwise to lock with large knob (48) and indicating knob (52).	
	d. Slowly turn indicating knob (52) in until slightly seated in injector assembly (39).	Do not overtighten.
	e. Index indicator knob (52) with mark on large knob (48).	
	f. Advance indicator knob (52) one mark and back off until spaced 0.375 in. (9.525 mm).	Check fuel delivery. After each four cycles, reclamp injector assembly to ensure accuracy.

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)



LEGEND:

- 39. INJECTOR ASSEMBLY
- 48. LARGE KNOB
- 49. SMALL KNOB

- 51. BURNISHING TOOL
- 52. INDICATING KNOB

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Adjusting and Measuring Fuel Delivery (Contd)


NOTE

- If fuel delivery is more than 176 cc, a new adjustable orifice must be installed in the injector. Tighten orifice plug to 8-10 lb-in. (11-14 N•m).
- Orifice plugs have flanges and require a gasket between flange and adapter.

g. Replacement inlet orifice plugs on burnishing tool (51) contain enough stock in inside diameter so a small displacement of metal by burnishing will increase fuel delivery.

52. Fuel inlet connector (30), fuel drain connector (33), and burnishing tool (51)	Disconnect from adapter (28).	Turn out large knob (48) on burnishing tool (51).
53. Injector assembly (39)	Remove from test stand link (29).	
54. Plunger (40) and injector spring (42)	Remove from injector assembly (39).	
55. Adapter (28)	Remove from injector assembly (39).	
56. Test stand link (29)	Slide out of adapter (28).	
57. Two pins (46) and retainer plate (47)	Remove from adapter (28).	
58. Filter and screen clip (43) and filter screen (44)	Install on orifice plug inlet opening (45) of injector assembly (39).	
59. Plunger (40) and injector spring (42)	Install on injector assembly (39).	

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)



LEGEND:

- 28. ADAPTER
- 29. TEST STAND LINK
- 30. FUEL INLET CONNECTOR
- 33. FUEL DRAIN CONNECTOR
- 39. INJECTOR ASSEMBLY
- 40. PLUNGER
- 42. INJECTOR SPRING
- 43. FILTER AND SCREEN CLIP
- 44. FILTER SCREEN


- 45. ORIFICE PLUG INLET OPENING
- 46. PIN (2)
- 47. RETAINER PLATE
- 48. LARGE KNOB
- 49. SMALL KNOB
- 50. BURNISHING TOOL NEEDLE
- 51. BURNISHING TOOL

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)

LOCATION/ITEM	ACTION	REMARKS
e. Top-stop Injector		
60. Top-stop screw (53) and top-stop locknut (54)	Install on injector assembly (39).	Install with two threads of top-stop screw (53) protruding above top-stop locknut (54). This is a reference point only.
61. Injector assembly (39)	Install on setting fixture (55) and tighten.	Be certain that seat and cup of injector assembly (39) is centered over cup retainer (56).
62. Cup retainer (56)	Adjust and tighten upward to 100-115 lb-in. (11.3-12.5 N•m).	
63. Plunger (40)	a. Bottom in cup seat (60) with fixture handle (57).	Set dial indicator at zero. Weight (61) should be 10.1875 in. (258.76 mm) from centerline of dowel (62).
	b. Release slowly.	Observe travel required until plunger (40) spring washer contacts injector top-stop screw (53). Bottom plunger again and adjust stop (58) up or down as required until travel equals 0.224 in. (5.690 mm) ± 0.0005 in. ± (0.0127 mm).
64. Top-stop locknut (54)	Using torque wrench (59), tighten to 55 lb-ft (75 N•m).	Recheck travel after torquing.

FOLLOW-ON TASK: Install injector assembly (para. 3-82).

3-55. FUEL INJECTOR TESTING; TEST NO. 3 (Contd)



LEGEND:

- 39. INJECTOR ASSEMBLY
- 40. PLUNGER
- 53. TOP-STOP SCREW
- 54. TOP-STOP LOCKNUT
- 55. SETTING FIXTURE
- 56. CUP RETAINER

- 57. FIXTURE HANDLE
- 58. STOP
- 59. TORQUE WRENCH
- 60. CUP SEAT
- 61. WEIGHT
- 62. DOWEL

3-56. FUEL PUMP REPAIR

THIS TASK COVERS:

- a. Installing Fuel Pump on Vise
- b. Cleaning

- c. Inspection
- d. Removing Fuel Pump From Vise

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Fuel pump mounting plate (15434) 3375133
 Ball joint vise (15434) ST-302

TEST EQUIPMENT

None

MATERIALS/PARTS

Solvent, SD-3 (Appendix C, Item 30)

PERSONNEL REQUIRED

Fuel and electrical systems repairman
 MOS 63G

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Fuel pump removed (para. 3-16).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

- Always wear eye protection when using compressed air.
- Use approved solvent in well-ventilated area and away from open flame.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Installing Fuel Pump on Vise

1. Fuel pump (2)	Install fuel pump (2) on fuel pump mounting plate (3) with two screws and nuts.	
2. Ball joint vise (4)	Install fuel pump (2) and fuel pump mounting plate (3) on ball joint vise (4) with two screws.	Fuel pump mounting plate (3375133) (3) may be mounted on ball joint vise (ST-302) (4) before installing fuel pump (2).

b. Cleaning

WARNING

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

NOTE


Fuel pumps used on M915/Big Cam I and M915A1/Big Cam III diesel engines are very similar but not identical. Adjust for change accordingly.

3-56. FUEL PUMP REPAIR (Contd)

- | | | |
|----|---------------------------------------------|-------------------------------------------------|
| 1. | Fuel pump-to-compressor spider coupling (1) | Clean with solvent and dry with compressed air. |
|----|---------------------------------------------|-------------------------------------------------|

CAUTION
Cleaning solvent can cause damage if it gets inside fuel pump. Ensure all fuel pump port plugs are secure so cleaning solvent does not get inside.

- | | | | |
|----|---------------|--------------------------------------------------------------|----------------------------------------------------------|
| 2. | Fuel pump (2) | Clean outside with SD-3 solvent and dry with compressed air. | Refer to para. 3-6 for additional cleaning instructions. |
|----|---------------|--------------------------------------------------------------|----------------------------------------------------------|



LEGEND:

- | | |
|--------------------------------------------|----------------------------------------|
| 1. FUEL PUMP-TO-COMPRESSOR SPIDER COUPLING | 6. FUEL PUMP DAMPER AND HEAD |
| 2. FUEL PUMP | 7. FUEL GEAR PUMP |
| 3. FUEL PUMP MOUNTING PLATE | 8. FUEL PUMP GOVERNOR SPRING PACK |
| 4. BALL JOINT VISE | 9. FUEL PUMP MAIN HOUSING |
| 5. SOLENOID VALVE | 10. FUEL PUMP FRONT COVER AND GOVERNOR |

3-56. FUEL PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection


3. Fuel pump-to-compressor spider coupling (1)	Inspect for cracks, breaks, bending, and other damage.	Discard if damaged.
4. Fuel pump (2)	Inspect for cracks, breaks, bending, corrosion, and other damage.	Repair component parts if necessary.
	Solenoid valve (5) repair	Para. 3-57
	Fuel pump damper and head (6) repair	Para. 3-58
	Fuel gear pump (7) repair	Para. 3-59
	Fuel pump governor spring pack (8) repair	Para. 3-60
	Fuel pump front cover and governor (10) repair	Para. 3-61
	Fuel pump main housing (9) repair	Para. 3-62

d. Removing Fuel Pump From Vise

1. Fuel pump mounting plate (3)	Remove two screws and fuel pump (2) with fuel pump mounting plate (3) from ball joint vise (4).	Fuel pump (2) may be removed from mounting without removing plate (3) from ball joint vise (4).
2. Fuel pump (2)	Remove two screws, nuts, and fuel pump (2) from fuel pump mounting plate (3).	

FOLLOW-ON TASK: Install fuel pump (para. 3-78).

3-56. FUEL PUMP REPAIR (Contd)



LEGEND:

- 1. FUEL PUMP-TO-COMPRESSOR SPIDER COUPLING
- 2. FUEL PUMP
- 3. FUEL PUMP MOUNTING PLATE
- 4. BALL JOINT VISE
- 5. SOLENOID VALVE

- 6. FUEL PUMP DAMPER AND HEAD
- 7. FUEL GEAR PUMP
- 8. FUEL PUMP GOVERNOR SPRING PACK
- 9. FUEL PUMP MAIN HOUSING
- 10. FUEL PUMP FRONT COVER AND GOVERNOR

3-57. SOLENOID VALVE REPAIR

THIS TASK COVERS:

- a. Removal
- b. Disassembly
- c. Cleaning

- d. Inspection
- e. Assembly
- f. Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

- Cloth, lint-free (Appendix C, Item 6)
- Solvent, SD-3 (Appendix C, Item 30)
- Oil, lubricating, OE/HDO 30 (Appendix C, Item 21)
- Rectangular ring seal (15434) 129888
- Rectangular ring seal (15434) 154087
- O-ring seal (15434) 190876
- Two lockwashers (15434) 181466

PERSONNEL REQUIRED

Fuel and electrical systems repairman
MOS 63G

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Fuel pump removed (para. 3-16).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

- Always wear eye protection when using compressed air.
- Use approved solvent in well-ventilated area and away from open flame.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


a. Removal

1. Two screws (1), lockwashers (2), washers (3), solenoid valve (4), and rectangular ring seal (16)	Remove from fuel pump (17).	Discard rectangular ring seal (16) and lockwashers (2).
-----------------------------------------------------------------------------------------------------	-----------------------------	---------------------------------------------------------

b. Disassembly

2. Four solenoid mounting screws (5)	Remove electrical solenoid (6) from valve body (14).	
3. Shutoff valve shield (7), rectangular ring seal (8), shutoff valve spring (9), and valve disk (10)	Remove from valve body (14).	Discard rectangular ring seal (8).
4. Shutoff valve knob (15)	Remove from shutoff valve shaft (12).	This is done by turning knob and shaft clockwise. Threads on shaft will act as a puller.
5. Shutoff valve shaft (12), plug (13), and O-ring seal (11)	Remove from valve body (14).	Discard O-ring seal (11).

3-57. SOLENOID VALVE REPAIR (Contd)



LEGEND:

- | | |
|--------------------------------|---------------------------|
| 1. SCREW (2) | 10. VALVE DISK |
| 2. LOCKWASHER (2) | 11. O-RING SEAL |
| 3. WASHER (2) | 12. SHUTOFF VALVE SHAFT |
| 4. SOLENOID VALVE | 13. PLUG |
| 5. SOLENOID MOUNTING SCREW (4) | 14. VALVE BODY |
| 6. ELECTRICAL SOLENOID | 15. SHUTOFF VALVE KNOB |
| 7. SHUTOFF VALVE SHIELD | 16. RECTANGULAR RING SEAL |
| 8. RECTANGULAR RING SEAL | 17. FUEL PUMP |
| 9. SHUTOFF VALVE SPRING | |

3-57. SOLENOID VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Cleaning

6. Electrical solenoid (6)	Wipe clean with lint-free cloth.	Do not use solvent.
----------------------------	----------------------------------	---------------------

WARNING

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

7. All parts except electrical solenoid (6)	Clean with SD-3 solvent and dry with compressed air.	Refer to para. 3-6 for additional cleaning instructions.
---------------------------------------------	------------------------------------------------------	----------------------------------------------------------

d. Inspection

8. All parts	Inspect for cracks, breaks, excessive wear, and other damage.	Discard any parts that are damaged or worn.
--------------	---------------------------------------------------------------	---------------------------------------------

9. Valve body (14)	a. Inspect valve seat for wear, bonding separation, failure, and corrosion.	Discard if damaged or worn.
--------------------	-----------------------------------------------------------------------------	-----------------------------

	b. Using suitable micrometer, measure width of valve seat.	Discard valve body if width of valve seat is less than 0.015 in. (0.381 mm).
--	------------------------------------------------------------	------------------------------------------------------------------------------

10. Electrical solenoid (6)	Using multimeter, check resistance between long terminal and base.	Discard electrical solenoid if resistance is not within 28-32 ohms.
-----------------------------	--------------------------------------------------------------------	---------------------------------------------------------------------

e. Assembly


11. New O-ring seal (11)	Install on shutoff valve shaft (12).	Apply a light coat of lubricating oil on O-ring seal (11) at installation.
--------------------------	--------------------------------------	----------------------------------------------------------------------------

12. Shutoff valve shaft (12)	a. Turn in valve body (14) until it reaches bottom of bore.	
	b. Using depth micrometer set at 0.118 in. (2.997 mm), check distance from face of valve body (14) to tip of shutoff valve shaft (12).	Distance should be 0.118 in. (2.997 mm). If necessary, back out shutoff valve shaft (12) until it is 0.118 in. (2.997 mm) below valve body (14) face.

13. Valve disk (10)	c. Without moving shutoff valve, press on shutoff valve knob (15). Place in valve body (14) with rubber side toward valve body (14).	Shutoff valve knob (15) acts as a stop.
---------------------	--------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------

14. New rectangular ring seal (8)	Coat with lubricating oil and seat in groove on valve body (14).	
-----------------------------------	------------------------------------------------------------------	--

3-57. SOLENOID VALVE REPAIR (Contd)



LEGEND:

- | | |
|--------------------------------|---------------------------|
| 1. SCREW (2) | 10. VALVE DISK |
| 2. LOCKWASHER (2) | 11. O-RING SEAL |
| 3. WASHER | 12. SHUTOFF VALVE SHAFT |
| 4. SOLENOID VALVE | 13. PLUG |
| 5. SOLENOID MOUNTING SCREW (4) | 14. VALVE BODY |
| 6. ELECTRICAL SOLENOID | 15. SHUTOFF VALVE KNOB |
| 7. SHUTOFF VALVE SHIELD | 16. RECTANGULAR RING SEAL |
| 8. RECTANGULAR RING SEAL | 17. FUEL PUMP |
| 9. SHUTOFF VALVE SPRING | |

3-57. SOLENOID VALVE REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

e. Assembly (Contd)


15. Shutoff valve spring (9)	Place in valve body (14) with concave side up.	
16. Electrical solenoid (6) and shutoff valve shield (7)	a. Place on valve body (14). b. Secure with four solenoid mounting screws (5).	Tighten to 25-30 lb-ft (34-40 N•m).

f. Installation

17. New rectangular ring seal (16)	Install on solenoid valve (4).	Apply a light coat of lubricating oil on rectangular ring seal (16) at installation.
18. Solenoid valve (4)	a. Install on fuel pump (17). b. Secure with two screws (1), new lockwashers (2), and washers (3).	
19. Plug (13)	Install on valve body (14).	

FOLLOW-ON TASK: Install fuel pump (para. 3-78).

3-57. SOLENOID VALVE REPAIR (Contd)



LEGEND:

- | | |
|--------------------------------|---------------------------|
| 1. SCREW (2) | 10. VALVE DISK |
| 2. LOCKWASHER (2) | 11. O-RING SEAL |
| 3. WASHER (2) | 12. SHUTOFF VALVE SHAFT |
| 4. SOLENOID VALVE | 13. PLUG |
| 5. SOLENOID MOUNTING SCREW (4) | 14. VALVE BODY |
| 6. ELECTRICAL SOLENOID | 15. SHUTOFF VALVE KNOB |
| 7. SHUTOFF VALVE SHIELD | 16. RECTANGULAR RING SEAL |
| 8. RECTANGULAR RING SEAL | 17. FUEL PUMP |
| 9. SHUTOFF VALVE SPRING | |

3-58. FUEL DAMPER AND HEAD REPAIR

THIS TASK COVERS:

- a. Removal
- b. Disassembly
- c. Cleaning

- d. Inspection
- e. Assembly
- f. Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Solvent, SD-3 (Appendix C, Item 30)
 Oil, lubricating, OE/HDO 30
 (Appendix C, Item 21)
 Four lockwashers (15434) 181466
 Rectangular ring seal (15434) 139988
 Rectangular ring seal (15434) 100099
 Rectangular ring seal (15434) 151900
 Rectangular ring seal (15434) 255622

PERSONNEL REQUIRED

Fuel and electrical systems repairman
 MOS 63G

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Fuel pump removed (para. 3-16).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust

GENERAL SAFETY INSTRUCTIONS

- Always wear eye protection when using compressed air.
- Use approved solvent in well-ventilated area and away from open flame.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


a. Removal

- | | | |
|---------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|-------------------------------------------------------------------|
| 1. Two screws (10), screws (11) and (13), four lockwashers (9), and washers (8) | Remove filter head (2) and rectangular ring seals (14) and (15) from fuel pump (16). | Discard lockwashers (9) and rectangular ring seals (14) and (15). |
|---------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|-------------------------------------------------------------------|

b. Disassembly

- | | | |
|----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------|
| 2. Two captive washer screws (1) | Remove plate (7), nylon washer (6), rectangular ring seal (5), fuel pump damper diaphragm (4), and rectangular ring seal (3) from filter head (2). | Discard rectangular ring seals (3) and (5). |
| 3. Pipe plug (12) | Remove from filter head (2). | |

3-58. FUEL DAMPER AND HEAD REPAIR (Contd)



LEGEND:

- | | |
|-------------------------------|---------------------------|
| 1. CAPTIVE WASHER SCREW (2) | 9. LOCKWASHER (4) |
| 2. FILTER HEAD | 10. SCREW (2) |
| 3. RECTANGULAR RING SEAL | 11. SCREW |
| 4. FUEL PUMP DAMPER DIAPHRAGM | 12. PIPE PLUG |
| 5. RECTANGULAR RING SEAL | 13. SCREW |
| 6. NYLON WASHER | 14. RECTANGULAR RING SEAL |
| 7. PLATE | 15. RECTANGULAR RING SEAL |
| 8. WASHER (4) | 16. FUEL PUMP |

3-58. FUEL DAMPER AND HEAD REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Cleaning

WARNING

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

4. All parts	Clean with SD-3 solvent and blow dry with compressed air.	Refer to para. 3-6 for additional cleaning instructions.
--------------	-----------------------------------------------------------	----------------------------------------------------------

d. Inspection

5. All parts	Inspect for corrosion, excessive wear, and cracks.	Discard damaged or worn parts.
6. Fuel pump damper diaphragm (4)	Check for hidden cracks by dropping on a hard, flat surface.	Diaphragm (4) should have a clear ring. Discard if it has a flat sound.

e. Assembly


7. Pipe plug (12)	Install on filter head (2).	
8. New rectangular ring seal (5) and nylon washer (6)	Install in plate (7).	
9. New rectangular ring seal (3)	Install on filter head (2).	
10. Fuel pump damper diaphragm (4)	a. Coat with lubricating oil. b. Install in plate (7).	Ensure diaphragm (4) is clean.
11. Plate (7)	a. Install on filter head (2). b. Secure with two captive washer screws (1).	Tighten screws (1) to 11-13 lb-ft (15-18 N•m).

f. Installation

12. New rectangular ring seals (14) and (15)	Install on filter head (2).	Apply a light coat of lubricating oil on rectangular ring seals (14) and (15) at installation.
13. Filter head (2)	a. Install on fuel pump (16). b. Secure with two screws (10), and screws (11) and (13), four new lockwashers (9), and washers (8).	Screw (13) is longest and screw (11) is shortest. Tighten all screws to 11-13 lb-ft (15-18 N•m).

FOLLOW-ON TASK: Install fuel pump (para. 3-78).

3-58. FUEL DAMPER AND HEAD REPAIR (Contd)



LEGEND:

- | | |
|-------------------------------|---------------------------|
| 1. CAPTIVE WASHER SCREW (2) | 9. LOCKWASHER (4) |
| 2. FILTER HEAD | 10. SCREW (2) |
| 3. RECTANGULAR RING SEAL | 11. SCREW |
| 4. FUEL PUMP DAMPER DIAPHRAGM | 12. PIPE PLUG |
| 5. RECTANGULAR RING SEAL | 13. SCREW |
| 6. NYLON WASHER | 14. RECTANGULAR RING SEAL |
| 7. PLATE | 15. RECTANGULAR RING SEAL |
| 8. WASHER (4) | 16. FUEL PUMP |

3-59. FUEL GEAR PUMP REPAIR

THIS TASK COVERS:

- a. Removal
- b. Disassembly
- c. Cleaning

- d. Inspection
- e. Assembly
- f. Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Pressurizing valve driver (15434) 3375959

TEST EQUIPMENT

None

MATERIALS/PARTS

Solvent, SD-3 (Appendix C, Item 30)
 Oil lubricating, OE/HDO 30
 (Appendix C, Item 21)
 Four lockwashers (15434) 181466
 Gasket (15434) 110855
 Gasket (15434) 3016683

PERSONNEL REQUIRED

Fuel and electrical systems repairman
 MOS 63G

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Fuel damper and head removed (para. 3-58).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust

GENERAL SAFETY INSTRUCTIONS

- Always wear eye protection when using compressed air.
- Use approved solvent in well-ventilated area and away from open flame.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Removal

1. Four screws (4), lockwashers (3), fuel gear pump assembly (7), and gasket (19)	Remove from fuel pump (20).	Tap sides of fuel gear pump assembly (7) with plastic-faced hammer to help loosen. Discard lockwashers (3) and gasket (19).
-----------------------------------------------------------------------------------	-----------------------------	-----------------------------------------------------------------------------------------------------------------------------

b. Disassembly


NOTE

The fuel supply elbow contains a check ball. Do not replace with a standard elbow.

2. Fuel supply elbow (1) and adapter (2)	Remove from gear body (13).	
3. Two screws (5), washers (6), and lockwashers (3)	Remove from gear body (13).	Discard lockwashers (3).
4. Gear body (13)	a. Install two screws (4) on threaded holes of gear body (13). b. Tap screws (4) with soft-nose hammer to separate gear body (13) from gear cover (9).	Discard gasket (16).
5. Idler shaft (12), drive shaft (17), and two gears (11)	Remove from gear body (13).	Do not separate gears (11) from shafts (12) and (17) at this time.

3-59. FUEL GEAR PUMP REPAIR (Contd)

- | | | | |
|----|--------------------------------------------------------------------|------------------------------------------------|--------------------------------------------------------------------------|
| 6. | Pressure valve (18), dowel ring (8), and four bearing sleeves (15) | Remove from gear cover (9) and gear body (13). | Only remove dowel ring (8) and bearing sleeves (15) if damaged or loose. |
| 7. | Pipe plug (14) | Remove from gear body (13). | |



LEGEND:

- | | |
|----------------------------|------------------------|
| 1. FUEL SUPPLY ELBOW | 11. GEAR (2) |
| 2. ADAPTER | 12. IDLER SHAFT |
| 3. LOCKWASHER (6) | 13. GEAR BODY |
| 4. SCREW (4) | 14. PIPE PLUG |
| 5. SCREW (2) | 15. BEARING SLEEVE (4) |
| 6. WASHER (2) | 16. GASKET |
| 7. FUEL GEAR PUMP ASSEMBLY | 17. DRIVE SHAFT |
| 8. DOWEL RING | 18. PRESSURE VALVE |
| 9. GEAR COVER | 19. GASKET |
| 10. COVER DOWEL (2) | 20. FUEL PUMP |

3-59. FUEL GEAR PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Cleaning

WARNING


- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

8. Fuel gear pump assembly (7) and all mounting hardware	Clean with SD-3 solvent and dry with compressed air.	Refer to para. 3-6 for additional cleaning instructions.
----------------------------------------------------------	------------------------------------------------------	----------------------------------------------------------

d. Inspection

9. Idler shaft (12) and drive shaft (17)	a. Check for scoring, wear, and other damage. b. Using suitable micrometer, measure outside diameter.	If bearing sleeves (15) are worn or damaged, remove gears (11) and discard shaft (12) or (17) and bearing sleeves (15). If bearing sleeves (15) are not within 0.4998-0.5001 in. (12.695-12.703 mm), discard shaft (12) or (17) and bearing sleeves (15).
10. Two gears (11)	a. Inspect for scoring, wear, and other damage. b. Using suitable micrometer, measure width (see illustration).	Remove and discard if damaged or worn. Remove and discard if width is not within 0.7483 and 0.7486 in. (19.007 and 19.014 mm).
11. Gear cover (9) and gear body (13)	a. Inspect for scoring, wear, and other damage. b. Using suitable micrometer, measure gear pocket depth in gear body (13). c. Using suitable micrometer, measure shaft bores in gear cover (9) and gear body (13). d. Check lubrication holes in gear cover (9) and gear body (13).	Discard fuel gear pump assembly (7) if scored, damaged, or worn. Discard fuel gear pump assembly (7) if gear pocket depth is not within 0.7478 and 0.7481 in. (18.994 and 19.002 mm). Discard fuel gear pump assembly (7) if any shaft bore measurements are not within 0.5011 and 0.5016 in. (12.728 and 12.741 mm). Lubrication holes must be clean.
12. All other parts	Inspect for cracks, breaks, and other damage.	Discard any damaged parts.

3-59. FUEL GEAR PUMP REPAIR (Contd)



LEGEND:

- 7. FUEL GEAR PUMP ASSEMBLY
- 9. GEAR COVER
- 11. GEAR (2)
- 12. IDLER SHAFT

- 13. GEAR BODY
- 14. PIPE PLUG
- 15. BEARING SLEEVE (4)
- 17. DRIVE SHAFT

3-59. FUEL GEAR PUMP REPAIR (Contd)


LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

e. Assembly

NOTE

Prior to assembly, place gear cover and gear body on bench.

13. Four bearing sleeves (15) and dowel ring (8)	Install on gear cover (9) and gear body (13).	Perform this step only if bearing sleeves (15) and dowel ring (8) were removed from gear body (13) and gear cover (9).
14. Pipe plug (14)	Install on gear body (13).	Tighten plug (14) to 10-13 lb-ft (14-18 N•m).
15. Two gears (11)	Press on idler shaft (12) and drive shaft (17) 0.680-0.690 in. (17.272-17.526 mm) away from gear body end of shaft.	Perform this step only if gear was removed from shaft. Repeat this step for each gear.
16. Pressure valve (18)	Using pressurizing valve driver, install on gear cover (9).	Use pressurizing valve driver (3375959). Pressure valve must be even to 0.015 in. (0.381 mm) below face of gear cover (9). If valve is damaged at all during installation, replace with new valve.



NOTE

- Location of notches or ridges and drive shaft determine pump rotation.
- When a right-hand rotation pump is being assembled, place driven gear shaft of gear pump in pocket nearest locating notches or ridges. Place driving gear shaft in other pocket. The dowel ring is always located around drive shaft.

17. Idler shaft (12), drive shaft (17), and two gears (11)	Lubricate and install on gear body (13).	Ensure all parts are clean.
18. Gear cover (9) and new gasket(16)	a. Install on gear body (13). b. Install two screws (5), washers (6), and new lockwashers (3).	Ensure location notches are aligned.

NOTE

Drive shaft must protrude 2.370-2A12 in. (60.198-61.265 mm) from gear body. End clearance should not exceed 0.0015 in. (0.0381 mm), nor be less than 0.0009 in. (0.0228 mm). Gaskets are available in 0.0020 and 0.0015 in. (0.0509 mm and 0.0381 mm). If pump binds, has excessive play or gear backlash, check for error in assembly which must be corrected to prevent early pump failure. Total gear backlash must be 0.001-0.004 in. (0.0254-0.1016 mm).

3-59. FUEL GEAR PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


f. Installation

19. Fuel supply elbow (1) and adapter (2) Install on gear body (13).

NOTE

Use correct gasket in step 20 and ensure that it is positioned correctly. Be certain main housing fuel holes match gear pump holes.

20. Fuel gear pump assembly (7) and new gasket (19)
- a. Install on fuel pump (20).
- b. Secure with four screws (4) and new lockwashers (3).
- Locate notch to upper right-hand corner (looking from behind fuel pump). Tighten screws (4) and (5) to 11-13 lb-ft (15-18 N•m). Check that gear pump shaft rotates freely.



LEGEND:

- | | |
|----------------------------|-------------------------|
| 1. FUEL SUPPLY ELBOW | 12. IDLER SHAFT |
| 2. ADAPTER | 13. GEAR BODY |
| 3. LOCKWASHER (6) | 14. PIPE PLUG |
| 4. SCREW (4) | 15. BEARING SLEEVES (4) |
| 5. SCREW (2) | 16. GASKET |
| 6. WASHER (2) | 17. DRIVE SHAFT |
| 7. FUEL GEAR PUMP ASSEMBLY | 18. PRESSURE VALVE |
| 8. DOWEL RING | 19. GASKET |
| 9. GEAR COVER | 20. FUEL PUMP |
| 11. GEAR (2) | |

3-60. FUEL PUMP GOVERNOR SPRING REPAIR

THIS TASK COVERS:

- | | |
|-------------------------------------------------|--------------------------------------------------------|
| <p>a. Removal
b. Cleaning</p> | <p>c. Inspection
d. Installation</p> |
|-------------------------------------------------|--------------------------------------------------------|

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Solvent, SD-3 (Appendix C, Item 30)
Seal and wire (15434) 3003156
Gasket (15434) 70705

PERSONNEL REQUIRED

Fuel and electrical systems repairman
MOS 63G

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Fuel pump removed (para. 3-16).

SPECIAL ENVIRONMENTAL CONDITIONS


Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

- Always wear eye protection when using compressed air.
- Use approved solvent in well-ventilated area and away from open flame.

LOCATION/ITEM	ACTION	REMARKS
a. Removal		
1. Adjusting screw seal and wire (10)	Remove.	Discard adjusting screw seal and wire (10).
2. Three captive washer screws (9), screw (12), four washers (8), spring pack cover (7), and spring pack cover-to-fuel pump gasket (6)	Remove from fuel pump (17).	Discard gasket (6).
3. Cover plug (11)	Remove from spring pack cover (7).	
4. Snapping (13)	Remove from fuel pump (17).	Discard snapping (13) if damaged during removal.
5. High-speed spring retainer (14), shim (15), and compression spring (16)	Remove from guide (4).	
6. Guide (4)	Remove from fuel pump (17).	
7. Idle adjusting screw (5)	Remove from guide (4).	
8. Idle spring plunger (1), idling spring (2), adjusting screw washer (3), and lead seal (18)	Remove from guide (4).	Lead seal (18) is used on M915/Big Cam I only.

3-60. FUEL PUMP GOVERNOR SPRING REPAIR (Contd)



LEGEND:

- | | |
|------------------------------------------|-------------------------------------|
| 1. IDLE SPRING PLUNGER | 10. ADJUSTING SCREW SEAL AND WIRE |
| 2. IDLING SPRING | 11. COVER PLUG |
| 3. ADJUSTING SCREW WASHER | 12. SCREW |
| 4. GUIDE | 13. SNAPRING |
| 5. IDLE ADJUSTING SCREW | 14. HIGH-SPEED SPRING RETAINER |
| 6. SPRING PACK COVER-TO-FUEL PUMP GASKET | 15. SHIM (AS REQUIRED) |
| 7. SPRING PACK COVER | 16. COMPRESSION SPRING |
| 8. WASHERS (4) | 17. FUEL PUMP |
| 9. CAPTIVE WASHER SCREW (3) | 18. LEAD SEAL (M915/BIG CAM I ONLY) |

3-60. FUEL PUMP GOVERNOR SPRING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Cleaning

WARNING

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

9. All parts	Clean with SD-3 solvent and dry with compressed air.	Refer to para. 3-6 for additional cleaning instructions.
--------------	------------------------------------------------------	----------------------------------------------------------

c. Inspection

10. All parts	Inspect for cracks, breaks, and other damage.	Discard any damaged parts.
11. All threaded parts	Inspect for crossthreading, stripped threads, and other damage.	Discard any damaged parts.

d. Installation


12. Idle adjusting screw (5)	Install on guide (4).	
13. Adjusting screw washer (3)	Place over idle adjusting screw (5) in guide (4).	
14. Idling spring (2)	Slide in guide (4) and over idle adjusting screw (5).	
15. Idle spring plunger (1)	Place in guide (4) against idling spring (2).	
16. Compression spring (16), shim (15), and high-speed spring retainer (14)	Slide on guide (4).	Final number of shims (15), is determined at calibration.
17. Guide (4) and attached parts	a. Place in fuel pump (17). b. Secure with snapping (13).	
18. Idle adjusting screw (5)	Turn clockwise by hand until contact is made with seat.	Final adjustment is made at calibration.
19. Cover plug (11)	Install on spring pack cover (7).	
20. Cover (7) and new spring pack cover-to-fuel pump gasket (6)	a. Install on fuel pump (17). b. Secure with three captive washer screws (9), screw (12), and four washers (8).	Put screw with lockwire hole in lower right corner. Torque all screws to 9-11 lb-ft (12-15 N•m).

3-60. FUEL PUMP GOVERNOR SPRING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

21. New adjusting screw seal and wire (10)	Do not install at this time.	Final calibration and on-engine fuel pump adjustments must be made prior to installation of seal and wire (10).
--------------------------------------------	------------------------------	-----------------------------------------------------------------------------------------------------------------

- FOLLOW-ON TASKS:
- Perform fuel pump testing and calibration (para. 3-63).
 - Perform on-engine fuel pump adjustments (para. 3-93).



LEGEND:

- | | |
|------------------------------------------|-----------------------------------|
| 1. IDLE SPRING PLUNGER | 10. ADJUSTING SCREW SEAL AND WIRE |
| 2. IDLING SPRING | 11. COVER PLUG |
| 3. ADJUSTING SCREW WASHER | 12. SCREW |
| 4. GUIDE | 13. SNAPRING |
| 5. IDLE ADJUSTING SCREW | 14. HIGH-SPEED SPRING RETAINER |
| 6. SPRING PACK COVER-TO-FUEL PUMP GASKET | 15. SHIM (AS REQUIRED) |
| 7. SPRING PACK COVER | 16. COMPRESSION SPRING |
| 8. WASHERS (4) | 17. FUEL PUMP |
| 9. CAPTIVE WASHER SCREW (3) | |

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR

THIS TASK COVERS:

- | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> a. Removal b. Disassembly (M915A1/Big Cam III) c. Cleaning d. Inspection (M915A1/Big Cam III) e. Assembly (M915A1/Big Cam III) | <ul style="list-style-type: none"> f. Installation g. Disassembly (M915/Big Cam I) h. Inspection (M915/Big Cam I) i. Assembly (M915/Big Cam I) |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Fuel pump mounting plate (15434) 3375133
 Ball joint vise (15434) ST-302
 Front cover and main shaft assembly tool kit (15434) 3375175
 Oil seal assembly tool (15434) ST-419
 Plunger protrusion checking tool (15434) ST-1241

TEST EQUIPMENT

None

MATERIALS/PARTS

Solvent, SD-3 (Appendix C, Item 30)
 Diesel fuel, regular (Appendix C, Item 19)
 Cover-to-fuel pump gasket (15434) 100754
 Tachometer drive seal (15434) 212603
 Two shaft seals (15434) 3019962

PERSONNEL REQUIRED

Fuel and electrical systems repairman MOS 63G

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Fuel pump removed (para. 3-16).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

Always wear eye protection when using compressed air.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


a. Removal

NOTE

- Steps 5 through 36 are performed in repairing fuel pump front cover and governor for fuel pumps used on the M915A1/Big Cam III engine.
- Steps 37 through 58 are performed in repairing fuel pump front cover and governor for fuel pumps used on the M915/Big Cam I engine.

1. Fuel pump front cover assembly (1)	Install on fuel pump mounting plate (32) and ball joint vise (33).	Use fuel pump mounting plate (3375133) (32) and ball joint vise (ST-302) (33).
2. Screw (30) and plastic bushing seal (31)	Remove from fuel pump front cover assembly (1).	Discard plastic bushing seal (31).
3. Screw (29), washer (27), and lockwashers (28)	Remove from fuel pump front cover assembly (1).	
4. Five captive washer screws (26), fuel pump main housing (34), and cover-to-fuel pump gasket (21)	Remove from fuel pump front cover assembly (1).	Tap fuel pump main housing (34) with plastic-face hammer to loosen. Discard cover-to-fuel pump gasket (21).

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)



LEGEND:

- | | | |
|-----------------------------------|-------------------------------|------------------------------|
| 1. FUEL PUMP FRONT COVER ASSEMBLY | 12. FUEL PUMP DRIVE GEAR | 24. SPRING |
| 2. TACHOMETER DRIVE SHAFT | 13. COUPLING | 25. GOVERNOR ASSEMBLY |
| 3. TACHOMETER DRIVE HOUSING | 14. SHAFT SEAL (2) | 26. CAPTIVE WASHER SCREW (5) |
| 4. TACHOMETER DRIVE SEAL | 15. COUPLING KEY | 27. WASHER |
| 5. TACHOMETER DRIVE SPACER | 16. SCREW | 28. LOCKWASHER |
| 6. TACHOMETER DRIVE BUSHING | 17. WASHER | 29. SCREW |
| 7. TACHOMETER DRIVE GEAR | 18. FUEL PUMP DRIVE COUPLING | 30. SCREW |
| 8. COVER ASSEMBLY | 19. TACHOMETER DRIVE GEAR | 31. PLASTIC BUSHING SEAL |
| 9. GOVERNOR BUSHING | 20. FUEL PUMP DRIVE SHAFT | 32. FUEL PUMP MOUNTING PLATE |
| 10. BEARING | 21. COVER-TO-FUEL PUMP GASKET | 33. BALL JOINT VISE |
| 11. RETAINING RING | 22. WEIGHT ASSIST PLUNGER | 34. FUEL PUMP MAIN HOUSING |
| | 23. SHIM (3) | |

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


b. Disassembly (M915A1/Big Cam III)

CAUTION

Exercise caution when removing weight-assist plunger. A slight nick can cause extensive damage. After removal, place plunger where it will not be damaged.

5. Governor assembly (25)	<p>a. Before removing, check shaft of governor assembly (25) for excessive wear.</p> <p>b. Check gear backlash between gear of governor assembly (25) and fuel pump drive gear (12).</p> <p>c. Remove governor bushing (9) from cover assembly (8).</p>	<p>Shaft has excessive wear if it can be moved from side to side in governor bushing (9). Discard governor assembly (25) and governor bushing (9) if there is excessive wear.</p> <p>Normal backlash is 0.005-0.009 in. (0.127-0.228 mm). Discard governor assembly (25) and fuel pump drive gear (12) if backlash is more than 0.009 in. (0.228 mm).</p> <p>Use internal engaging puller to remove bushing (9).</p>
6. Weight-assist plunger (22), shims (23), and spring (24)	Remove from governor assembly (25).	Be careful not to lose spring (24) and shims (23) during removal of plunger (22). Keep plunger (22), shims (23), and spring (24) together.
7. Screw (16) and washer (17)	Remove from fuel pump drive coupling (18) and fuel pump drive shaft (20).	
8. Fuel pump drive coupling (18), tachometer drive gear (19), and coupling key (15)	Using suitable puller, remove from fuel pump drive shaft (20).	
9. Retaining ring (11)	Remove from fuel pump drive shaft (20).	Use hose clamp pliers.
10. Fuel pump drive shaft (20), bearing (10), fuel pump drive gear (12), and coupling (13) (assembled)	Press out of cover assembly (8).	
11. Two shaft seals (14)	Press out of cover assembly (8) or remove from fuel pump drive shaft (20).	Discard two shaft seals (14).
12. Coupling (13) and gear (12)	Press from fuel pump drive shaft (20).	Do not press bearing (10) from fuel pump drive shaft (20) at this time.
13. Tachometer drive housing (3)	Remove from cover assembly (8).	
14. Shaft (2), seal (4), spacer (5), bushing (6), and gear (7)	Using brass punch, remove from cover assembly (8).	Discard tachometer drive seal (4).
15. Gear (7) and bushing (6)	Remove from tachometer drive shaft (2).	

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)



LEGEND:

- | | |
|-----------------------------|------------------------------|
| 2. TACHOMETER DRIVE SHAFT | 14. SHAFT SEAL (2) |
| 3. TACHOMETER DRIVE HOUSING | 15. COUPLING KEY |
| 4. TACHOMETER DRIVE SEAL | 16. SCREW |
| 5. TACHOMETER DRIVE SPACER | 17. WASHER |
| 6. TACHOMETER DRIVE BUSHING | 18. FUEL PUMP DRIVE COUPLING |
| 7. TACHOMETER DRIVE GEAR | 19. TACHOMETER DRIVE GEAR |
| 8. COVER ASSEMBLY | 20. FUEL PUMP DRIVE SHAFT |
| 9. GOVERNOR BUSHING | 22. WEIGHT-ASSIST PLUNGER |
| 10. BEARING | 23. SHIM (3) |
| 11. RETAINING RING | 24. SPRING |
| 12. FUEL PUMP DRIVE GEAR | 25. GOVERNOR ASSEMBLY |
| 13. COUPLING | |

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Cleaning

WARNING


Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.

16. All parts	Clean with solvent SD-3 and dry with compressed air.	Refer to para. 3-6 for additional cleaning instructions.
---------------	------------------------------------------------------	----------------------------------------------------------

d. Inspection (M915A1/Big Cam)

17. All parts	Inspect for cracks, breaks, excessive wear, and other damage.	Discard any damaged or worn parts.
18. Governor bushing (9)	Using suitable micrometer, measure inside diameter.	Remove from cover assembly (8) and discard if more than 0.504 in. (12.801 mm).
19. Fuel pump drive shaft (20) and bearing (10)	a. Inspect shaft (20) for scoring, wear grooves, and other damage.	Remove bearing (10) (step 20c.) and discard fuel pump drive shaft (20) if damaged. Install bearing (10) (step 20d.) on new shaft (20) as needed.
	b. Inspect bearing (10) for roughness and ease of operation.	Remove bearing (10) (step 20c.) and discard if rough or not easy to operate. Install new bearing (10) (step 20d.) as needed.
	c. Press bearing (10) from fuel pump drive shaft (20).	
	d. Lubricate shaft (20) with clean diesel fuel and, using main shaft gear and bearing installation tool, press bearing (10) onto fuel pump drive shaft (20).	Main shaft gear and bearing installation tool are part of front cover and main shaft assembly tool kit (3375175). Be sure to press against inner race of bearing.

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)




LEGEND:

- 8. COVER ASSEMBLY
- 9. GOVERNOR BUSHING
- 10. BEARING
- 20. FUEL PUMP DRIVE SHAFT

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
e. Assembly (M915A1/Big Cam)		
20. Bushing (6) and gear (7)	<p>a. Install bushing on tachometer drive shaft (2).</p> <p>b. Put a 0.004 in. (0.101 mm) feeler gauge on top of bushing (6).</p> <p>c. Press gear onto tachometer drive shaft (2).</p>	There should be 0.002-0.005 in. (0.050-0.127 mm) clearance between bushing (6) and gear (7).
21. Shaft (2), bushing (6), and gear (7) (assembled)	<p>a. Line up oil groove in top of bushing (6) with fuel pump drive shaft (20).</p> <p>b. Press into cover assembly (8) until bushing (6) bottoms.</p>	
22. Tachometer drive spacer (5)	Install on top of tachometer drive bushing (6) with slotted edge down.	Spacer (5) must bottom on bushing (6).
23. Tachometer drive seal (4)	Using front cover tachometer seal driver (36), install with spring side down.	Front cover tachometer seal driver (36) is part of front cover and main shaft assembly tool kit (3375175).
24. Tachometer drive housing (3)	Screw into cover assembly (8).	Do not overtighten housing. This will compress tachometer drive spacer (5) too much and will reduce its effectiveness.
25. Fuel pump drive gear (12)	Using main shaft gear and bearing installation tool (35), press onto fuel pump drive shaft (20) until against bearing (10).	Use front cover and main shaft assembly tool kit (3375175). Flat side of gear should face away from bearing.
26. Fuel pump drive coupling (13)	<p>a. Lubricate fuel pump drive shaft (20) and bore of coupling.</p> <p>b. Press onto fuel pump drive shaft (20) until against fuel pump drive gear (12).</p>	

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)



LEGEND:


- 2. TACHOMETER DRIVE SHAFT
- 3. TACHOMETER DRIVE HOUSING
- 4. TACHOMETER DRIVE SEAL
- 5. TACHOMETER DRIVE SPACER
- 6. TACHOMETER DRIVE BUSHING
- 7. TACHOMETER DRIVE GEAR
- 8. COVER ASSEMBLY

- 10. BEARING
- 12. FUEL PUMP DRIVE GEAR
- 13. FUEL PUMP DRIVE COUPLING
- 20. FUEL PUMP DRIVE SHAFT
- 35. MAIN SHAFT GEAR AND BEARING INSTALLATION TOOL
- 36. FRONT COVER TACHOMETER SEAL DRIVER

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
e. Assembly (M915A1/Big Cam III) (Contd)		
27. Two new shaft seals (14)	a. Using main shaft seal driver (37), press first shaft seal on cover assembly (8) with lip toward back of cover assembly (8).	Main shaft seal driver (37) is part of front cover and main shaft assembly tool kit (3375175).
	b. Using main shaft seal driver (37), press second shaft seal on cover assembly (8) with lip toward front of cover assembly.	Use front cover and main shaft assembly tool kit (3375175). Shaft seals must be spaced so weep hole is not covered.
28. Fuel pump drive shaft (20) and attached parts	a. Install oil seal assembly tool (38) on shaft (20).	Use oil seal assembly tool (ST-419) (38).
	b. Carefully press shaft (20) on cover assembly (8) until bearing (10) is against bottom of cover assembly (8) hole.	Be careful not to move shaft seals (14).
29. Retaining ring (11)	Install on fuel pump drive shaft (20) between fuel pump drive gear (12) and bearing (10).	Look through holes in gear to ensure retaining ring (11) is in groove.
30. Coupling key (15)	Install on fuel pump drive shaft (20).	
31. Tachometer drive gear (19) and fuel pump drive coupling (18)	a. Position on fuel pump drive shaft (20).	Ensure tachometer gear teeth are aligned.
	b. Press slowly and straight onto shaft (20).	
	c. Secure with screw (16) and washer (17).	Hold fuel pump drive coupling (18) in copper-jawed vise. Tighten screw to 5 lb-ft (7 N•m).
32. Governor assembly (25)	a. Slide on governor bushing (9).	
	b. Rotate with weights opened out to ensure it will turn completely in housing.	
33. Weight-assist plunger (22), shims (23), and spring (24)	a. Install between governor weights in bore of governor assembly (25).	Always install weight-assist plunger (22) with smallest end toward governor weights.

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)



LEGEND:

- | | |
|--------------------------|------------------------------|
| 8. COVER ASSEMBLY | 18. FUEL PUMP DRIVE COUPLING |
| 9. GOVERNOR BUSHING | 19. TACHOMETER DRIVE GEAR |
| 10. BEARING | 20. FUEL PUMP DRIVE SHAFT |
| 11. RETAINING RING | 22. WEIGHT-ASSIST PLUNGER |
| 12. FUEL PUMP DRIVE GEAR | 23. SHIMS (3) |
| 14. SHAFT SEAL (2) | 24. SPRING |
| 15. COUPLING KEY | 25. GOVERNOR ASSEMBLY |
| 16. SCREW | 37. MAIN SHAFT SEAL DRIVER |
| 17. WASHER | 38. OIL SEAL ASSEMBLY TOOL |

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


e. Assembly (M915A1/Big Cam III) (Contd)

33. Weight-assist plunger (22), shims (23), and spring (24) (Contd)	b. Add enough shims (23) to back of spring (24) to make weight-assist plunger (22) protrude above gasket face of cover assembly (8).	
	c. Check protrusion of weight-assist plunger (22) as follows:	
	(1) Put plunger protrusion checking tool (39) on surface of cover assembly (8).	Use plunger protrusion checking tool (ST-1241).
	(2) Put contact point of dial indicator on 12-in. diameter, 1-in. long gauge pin and zero dial indicator.	
	(3) Measure protrusion of weight-assist plunger (22).	Dial indicator will give weight direct reading of protrusion. If protrusion is below 0.800 in. (20.32 mm), add shims. If protrusion is above 0.800 in. (20.32 mm), remove shims or grind end of weight-assist plunger (22) if no shims (23) are in use.

f. Installation

34. New cover-to-fuel pump gasket (21)	Place on dowel pins of fuel pump main housing (34).	See illustration.
35. Fuel pump main housing (34) with cover-to-fuel pump gasket (21)	a. Install on fuel pump front cover assembly (1).	Position governor weight housing carrier horizontally and hold governor weights while installing fuel pump main housing (34). Ensure governor weights are properly engaged with tang on governor plunger.
	b. Secure with screw (30), new plastic bushing seal (31), screw (29), lockwasher (28), washer (27), and five captive washer screws (26).	Tighten all screws to 9-11 lb-ft (12-15 N•m).
36. Fuel pump front cover assembly (1)	Remove from mounting plate (32) and ball joint vise (33).	

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)



LEGEND:

- 1. FUEL PUMP FRONT COVER ASSEMBLY
- 8. COVER ASSEMBLY
- 21. COVER-TO-FUEL PUMP GASKET
- 22. WEIGHT-ASSIST PLUNGER
- 23. SHIM (3)
- 24. SPRING
- 26. CAPTIVE WASHER SCREW (5)
- 27. WASHER

- 28. LOCKWASHER
- 29. SCREW
- 30. SCREW
- 31. PLASTIC BUSHING SEAL
- 32. MOUNTING PLATE
- 33. BALL JOINT VISE
- 34. FUEL PUMP MAIN HOUSING
- 39. PLUNGER PROTRUSION CHECKING TOOL

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
g. Disassembly (M915/Big Cam I)		
37. Governor drive shaft (12)	a. Before removing, check drive shaft (12) for excessive wear.	Drive shaft (12) has excessive wear if it can be moved from side to side in governor housing (14). Discard governor housing (14) if there is excessive wear.
	b. Check gear backlash between gear (9) and drive gear (26).	Normal backlash is 0.005-0.009 in. (0.127-0.228 mm). Discard collar (13), gear (9), and drive gear (26) if backlash is more than 0.009 in. (0.228 mm).
38. Governor drive assembly snpring (11), ball key (30), and collar (13)	Remove.	
39. Drive shaft (12)	Press on opposite gear end and remove all units from housing (14).	
40. Drive gear (2) and support (3)	Remove from reservoir (21). Remove drain plug, dipstick, vent plug, and elbow.	
41. Locknut (22) and washer (23)	Remove from shaft (31).	
42. Coupling gear (24)	Press on small end of sham (31) to remove shaft from support (3) and large end of shaft to remove drive gear (26).	Use coupling puller (ST-1249).
43. Spacers (25) and governor drive gear (26)	Remove.	
44. Two keys (32)	Remove from shaft (31) keyways.	
45. Snpring (27) and support (3)	Remove and invert support and press out rear bearing (28) and oil seal (29).	


h. Inspection (M915/Big Cam)

NOTE

After disassembly, check bearing for worn race or rough action. Check gears for chipped, broken teeth, or uneven wear. Inspect governor shaft housing oil holes to make certain they are open and clear of foreign matter.

46. Support (3) and reservoir (21)	Inspect for cracks, breaks, or rough mating surfaces.	Replace all damaged, worn, or defective parts as necessary.
------------------------------------	-------------------------------------------------------	-------------------------------------------------------------

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)



BIG CAM I

LEGEND:

- | | | | |
|-------------------|----------------------|-------------------|----------------|
| 1. SLINGER | 9. GEAR | 17. STUD (4) | 25. SPACER (2) |
| 2. DRIVE GEAR | 10. GASKET | 18. COUPLING | 26. DRIVE GEAR |
| 3. SUPPORT | 11. SNAPRING | 19. SNAPRING | 27. SNAPRING |
| 4. SCREW (4) | 12. DRIVE SHAFT | 20. SNAPRING | 28. BEARING |
| 5. LOCKWASHER (4) | 13. COLLAR | 21. RESERVOIR | 29. OIL SEAL |
| 6. GASKET | 14. GOVERNOR HOUSING | 22. LOCKNUT | 30. BALL KEY |
| 7. PIPE PLUG | 15. NUT (4) | 23. WASHER | 31. SHAFT |
| 8. GASKET | 16. LOCKWASHER (4) | 24. COUPLING GEAR | 32. KEY (2) |

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

i. Assembly (M915/Big Cam I)


47. Oil seal (29) and support (3)	Lubricate outside of seal (29) and press into support from large end.	Open end of seal must be facing down.
48. Bearing (28) and snapping (27)	Lubricate rear bearing (28) and press into support (3). Insert snapping (27) with flat side down.	
49. Drive shaft (31) and keys (32)	Lubricate drive shaft (31) and place key (32) in drive shaft (31) keyway. Press drive shaft (31) into flat side of drive gear (2) until shoulder seats on gear face.	
50. Support (3) and drive gear (26)	Press small end of shaft assembly into large end of support (3). Press governor drive gear (26) onto drive shaft (31) until it bottoms on bearing (28).	
51. Ball key (30) and coupling gear (24)	Insert key (30) and press on coupling gear (24). Shoulder of coupling goes against drive gear (26) unless a spacer (25) is used.	
52. Washer (23) and locknut (22)	Install.	Tighten locknut (22).
53. Reservoir (21) and studs (17)	Position reservoir (21) in vise and, with governor's drive studs (17) up, install dipstick, vent plug, drain plug, and elbow.	

NOTE

Use the following assembly instructions for governors with 2:1 gear ratio.

54. Drive shaft (12) and snapping (11)	a. Install drive shaft (12), with splined end up, and collar (13) on housing (14).	
	b. Lubricate ball key (30) and insert in drive shaft (31) and install snapping (11).	Align ball key (30) with collar (13).
55. Gear (9)	Invert assembly and press on gear (9).	Allow clearance of 0.003-0.006 in. (0.08-0.15 mm).

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)



BIG CAM I

LEGEND:

- | | | | |
|--------------------|----------------------|-------------------|-----------------|
| 1. SLINGER | 9. GEAR | 17. STUD (4) | 25. SPACER (2) |
| 2. DRIVE GEAR | 10. GASKET | 18. COUPLING | 26. DRIVE GEAR |
| 3. SUPPORT | 11. SNAPRING | 19. SNAPRING | 27. SNAPRING |
| 4. SCREWS (4) | 12. DRIVE SHAFT | 20. SNAPRING | 28. BEARING |
| 5. LOCKWASHERS (4) | 13. COLLAR | 21. RESERVOIR | 29. OIL SEAL |
| 6. GASKET | 14. GOVERNOR HOUSING | 22. LOCKNUT | 30. BALL KEY |
| 7. PIPE PLUG | 15. NUTS (4) | 23. WASHER | 31. DRIVE SHAFT |
| 8. GASKET | 16. LOCKWASHERS (4) | 24. COUPLING GEAR | 32. KEY (2) |

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

i. Assembly (M915/Big Cam I) (Contd)


NOTE

Use the following assembly instructions for governors with 3:1 gear ratio.

56. Drive shaft (12)	<p>a. Press governor two-piece drive shaft (12) on washer flush with bottom side.</p> <p>b. Press shaft assembly on cylinder until shoulder on drive shaft (12) is flush with end of cylinder. Slide assembly into governor housing (14) so washer rests on bronze bushing.</p> <p>c. Invert assembly and install ball key (30), collar (13), and snapping (11). Press on end of cylinder until flat washer is against bronze bushing.</p> <p>Press gear into position allowing end clearance of 0.003 to 0.006 in. (0.08 to 0.15 mm).</p>	Note relief in washer to start shaft.
57. Gasket (8)	Position and install drive gear and housing assembly on serial number side of reservoir (21).	Large oil hole in housing must be at top.
58. Slinger (1)	Install on gear end of drive shaft (12).	

FOLLOW-ON TASK: For M915/Big Cam I engines only, proceed to follow-on tasks listed at the end of para. 3-62.

3-61. FUEL PUMP FRONT COVER AND GOVERNOR REPAIR (Contd)



BIG CAM I

LEGEND:

- 1. SLINGER
- 8. GASKET
- 11. SNAPRING
- 12. DRIVE SHAFT

- 13. COLLAR
- 14. GOVERNOR HOUSING
- 21. RESERVOIR
- 30. BALL KEY

3-62. FUEL PUMP MAIN HOUSING REPAIR

THIS TASK COVERS:

- a. Disassembly
- b. Cleaning

- c. Inspection and Repair
- d. Assembly

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

- AFC barrel puller (15434) 3375599
- Installer tool (15434) 3375416
- Ream fixture (15434) ST-490
- Lock-clip driver (15434) 3376136

TEST EQUIPMENT

None

MATERIALS/PARTS

- Solvent, SD-3 (Appendix C, Item 30)
- Lubricant, high-pressure (Appendix C, Item 15)
- Oil, cutting (Appendix C, Item 18)
- Cloth, crocus (Appendix C, Item 4)
- Oil, lubricating, OE/HDO 30 (Appendix C, Item 21)
- O-ring (94135) 12Z9026-5
- O-ring (15434) 145505
- O-ring (15434) 145504
- O-ring (15434) 70775
- Cap seal ring (15434) 154088
- O-ring (15434) 213768
- O-ring (15434) 190876
- Two O-rings (15434) 68061-A (M915/Big Cam I)
- O-ring (15434) 100478
- Gasket washer (15434) 3023870
- Bellows (15434) 3013811
- Throttle shaft ball (15434) 213796

PERSONNEL REQUIRED

Fuel and electrical systems repairman MOS 63G

REFERENCES (TM)

- TM 9-2320-273-20
- TM 9-2320-273-34
- TM 9-2320-283-20
- TM 9-2320-283-34

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

- Water pump removed (TM 9-2320-273-20, TM 9-2320-273-34 or TM 9-2320-283-20, TM 9-2320-283-34).
- Fuel pump mounted on ball joint vise (para. 3-56).
- Solenoid valve removed (para. 3-57).
- Fuel gear pump removed (para. 3-59).
- Fuel pump governor spring removed (para. 3-60).
- Fuel pump front cover and governor removed (para. 3-61).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS


- Always wear eye protection when using compressed air.
- Use approved solvent in well-ventilated area and away from flame.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly

1. Two drive screws (24)	Remove from throttle shaft cover (52).	
2. Throttle shaft cover (52)	Remove from housing (38).	
3. Retaining ring (55)	Remove from throttle shaft (50).	Discard retaining ring (55) if damaged during removal.
4. Throttle shaft (50) and O-ring (51)	Remove from housing (38).	Discard O-ring (51).
5. Throttle shaft ball (53)	Drill out of throttle shaft (50).	Be careful not to damage throttle shaft (50) when drilling. Discard ball (53).

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)




LEGEND:

- | | | |
|-----------------------------------|-------------------------------|------------------------------|
| 1. SCREW (2) | 21. BARREL SPRING | 41. SPRING PACK HOUSING |
| 2. DRILLED-HEAD SCREW | 22. PIPE PLUG (4) | 42. GOVERNOR BARREL |
| 3. WASHER (3) | 23. NAMEPLATE | 43. TACHOMETER DRIVE BUSHING |
| 4. FUEL CONTROL COVER | 24. DRIVE SCREW (4) | 44. AFC PLUG BALL (2) |
| 5. NUT | 25. FUEL FILTER SCREEN | 45. THROTTLE SHAFT ASSEMBLY |
| 6. AIR FUEL CONTROL PISTON INSERT | 26. FILTER SPRING | 46. SETSCREW |
| 7. GASKET WASHER | 27. CAP SEAL RING | 47. STOP |
| 8. RETAINER WASHER | 28. FILTER SCREEN CAP | 48. O-RING |
| 9. BELLOWS | 29. AFC NEEDLE VALVE | 49. FUEL ADJUSTING SCREW |
| 10. AFC PISTON | 30. O-RING (2) | 50. THROTTLE SHAFT |
| 11. PISTON SPACER | 31. NUT | 51. O-RING |
| 12. JAMNUT (3) | 32. THREADED STUD | 52. THROTTLE SHAFT COVER |
| 13. THROTTLE PLUNGER | 33. GOVERNOR PLUNGER ASSEMBLY | 53. THROTTLE SHAFT BALL |
| 14. SPRING | 34. SHIM (3) | 54. TAPERED STUD |
| 15. AFC SHIM | 35. GOVERNOR SPACER | 55. RETAINING RING |
| 16. RETAINING RING | 36. GOVERNOR PLUNGER | 56. TORQUE SPRING |
| 17. O-RING | 37. GOVERNOR PLUNGER DRIVER | 57. PIPE PLUG |
| 18. O-RING (2) | 38. HOUSING | 58. CHECK VALVE |
| 19. O-RING | 39. ROLL PIN | |
| 20. BARREL | 40. DOWEL (2) | |

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
a. Disassembly (Contd)		
6. Fuel adjusting screw (49) and O-ring (48)	Remove from throttle shaft (50).	Discard O-ring (48).
7. Setscrew (46)	Remove from stop (47).	
8. Throttle shaft (50)	Remove from stop (47).	
9. AFC needle valve (29)	a. Loosen nut (31).	
	b. Remove valve (29) and O-ring (30).	Discard O-ring (30).
	c. Remove nut (31) from valve (29).	
10. Threaded stud (32)	a. Remove from housing (38).	
	b. Remove from jamnut (12).	
11. Jamnut (12)	Remove from tapered stud (54).	
12. Tapered stud (54)	Remove from housing (38).	
13. Filter screen cap (28), cap seal ring (27), filter spring (26), and fuel filter screen (25)	Remove from filter housing (38).	Discard cap seal ring (27).
14. Check valve (58)	Remove from fuel control cover (4).	
15. Two screws (1), drilled head screw (2), and three washers (3)	Remove fuel control cover (4) from housing (38).	
16. Bellows (9)	Carefully lift away from sealing surface of housing (38) and remove with attached parts.	
17. Spring (14) and AFC shim (15)	Remove from housing (38).	
18. Retaining ring (16)	Remove from housing (38).	Discard retaining ring (16) if damaged during removal.
19. Barrel (20) and four O-rings (17), (18), and (19)	Remove from housing (38).	Use AFC barrel puller (3375599) Discard O-rings (17), (18), and (19).
20. Barrel spring (21)	Remove from housing (38).	Earlier pump models did not require a barrel spring (21).
21. Jamnut (12)	Remove from throttle plunger (13).	
22. Throttle plunger (13) and O-ring (30)	Remove from air fuel control piston insert (6).	Discard O-ring (30).
23. Nut (5), air fuel control piston insert (6), gasket washer (7), retainer washer (8), AFC piston (10), and piston spacer (11)	Remove nut (5) from air fuel control piston insert (6) and separate all parts.	Discard gasket washer (7) and bellows (9).

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)



LEGEND:

- 1. SCREW (2)
- 2. DRILLED-HEAD SCREW
- 3. WASHER (3)
- 4. FUEL CONTROL COVER
- 5. NUT
- 6. AIR FUEL CONTROL PISTON INSERT
- 7. GASKET WASHER
- 8. RETAINER WASHER
- 9. BELLOWS
- 10. AFC PISTON
- 11. PISTON SPACER
- 12. JAMNUT (3)
- 13. THROTTLE PLUNGER
- 14. SPRING
- 15. AFC SHIM
- 16. RETAINING RING
- 17. O-RING
- 18. O-RING (2)

- 19. O-RING
- 20. BARREL
- 21. BARREL SPRING
- 22. PIPE PLUG (4)
- 23. NAMEPLATE
- 24. DRIVE SCREW (4)
- 25. FUEL FILTER SCREEN
- 26. FILTER SPRING
- 27. CAP SEAL RING
- 28. FILTER SCREEN CAP
- 29. AFC NEEDLE VALVE
- 30. O-RING (2)
- 31. NUT
- 32. THREADED STUD
- 33. GOVERNOR PLUNGER ASSEMBLY
- 34. SHIMS
- 35. GOVERNOR SPACER
- 36. GOVERNOR PLUNGER
- 37. GOVERNOR PLUNGER DRIVER

- 38. HOUSING
- 39. ROLL PIN
- 40. DOWEL (2)
- 41. SPRING PACK HOUSING
- 42. GOVERNOR BARREL
- 43. TACHOMETER DRIVE BUSHING
- 44. AFC PLUG BALL (2)
- 45. THROTTLE SHAFT ASSEMBLY
- 46. SETSCREW
- 47. STOP
- 48. O-RING
- 49. FUEL ADJUSTING SCREW
- 50. THROTTLE SHAFT
- 53. THROTTLE SHAFT BALL
- 54. TAPERED STUD
- 58. CHECK VALVE
- 59. AFC BARREL PULLER

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)

24. Governor plunger assembly (33), shims (34), and torque spring (56) (assembled)	Remove from housing (38).	
25. Torque spring (56) and shims (34)	Remove from governor plunger assembly (33), spacer (35), and driver (37).	It may be necessary to twist spring (56) off plunger (36) to remove it. Do not pull spring off. Pulling spring will expand it beyond its elastic limit, requiring its replacement.
26. Five pipe plugs (22) and (57)	Remove from housing (38).	

b. Cleaning

WARNING

- **Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.**
- **Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.**

27. All parts	Clean with SD-3 solvent and dry with compressed air.	Refer to para. 3-6 for additional cleaning instructions.
---------------	------------------------------------------------------	----------------------------------------------------------

c. Inspection and Repair

28. Tachometer drive bushing (43)	a. Inspect for scoring, burrs, and other damage.	Replace bushing (43) if damaged (refer to step 28b.1 for replacement).
	b. Using suitable micrometer, measure inside diameter.	Replace bushing (43) if inside diameter is more than 0.7525 in. (19.114 mm) (refer to step 28b.1 for replacement).
	Replace bushing (43) as follows:	Do this step only if bushing (43) is damaged or worn beyond limits.
	(1) Remove bushing (43).	Using 1/2 in. pipe tap, put a thread in bushing (43). Install punch through rear of housing (38) until it is against pipe tap. Hit punch and remove bushing (43).
	(2) Apply a thin coat of high-pressure lubricant to new bushing (43).	
	(3) Using arbor press, drive bushing (43) into housing (38).	Bushing (43) must be even with housing bore.


3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

28. Tachometer drive bushing (43) (Contd)

(4) Using ream fixture (60) and well oiled 0.750-in. (19.05 mm) reamer line, ream bushing (43) to 0.7495-0.7505 in. (19.037-19.063 mm).

Use reamer fixture (ST-490). Check bushing inside diameter after reaming. Bushing must be less than 0.7525 in. (19.114 mm).



LEGEND:

- 22. PIPE PLUG (4)
- 33. GOVERNOR PLUNGER ASSEMBLY
- 34. SHIMS
- 35. GOVERNOR SPACER
- 36. GOVERNOR PLUNGER
- 37. GOVERNOR PLUNGER DRIVER

- 38. HOUSING
- 43. TACHOMETER DRIVE BUSHING
- 56. TORQUE SPRING
- 57. PIPE PLUG
- 60. REAM FIXTURE

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Inspection and Repair (Contd)

29. Governor barrel (42)	a. Inspect for wear.	Governor barrel (42) is hardened and wears very little. If barrel is worn or if governor plunger assembly (33) shows signs of damage, governor barrel (42) and spring pack housing (41) must be replaced (refer to step 29b. for replacement).
	b. Replace governor barrel (42) and spring pack housing (41) as follows:	Do this step only if governor and barrel (42) is worn or damaged.
	(1) Remove roll pin (39).	Using a wire hook, pull roll pin (39) out through plug hole in bottom of housing (38).
	(2) Heat housing (38) in oven to 300°F (149°C).	This will permit governor barrel (42) to be pressed out with less damage to housing bore.
	(3) Press out of housing (38).	Discard housing (38) if bore is not at least 0.002 in. (0.051 mm) smaller than governor barrel (42) outside diameter.
	(4) Using suitable governor barrel (42) outside micrometer, measure barrel diameter of bore in housing (38) and outside diameter of a new governor barrel (42).	
	(5) Check bore of housing (38) for score marks.	Remove slight score marks with crocus cloth. Discard housing (38) if deeply scored.

NOTE

Steps 29b.(6) and 29b.(7) refer to M915/Big Cam I older-style fuel pumps only.


(6) If governor barrel (42) is worn or shows signs of scoring, heat the housing (38) in an oven to 300°F (149° C) and press out governor barrel (42).	Heat will expand aluminum housing and permit steel barrel to be pressed out with less chance of damaging housing bore.
-------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------

NOTE

Check through-plug hole in bottom of pump for spring dowel which secures barrel in fuel pumps before attempting to remove governor barrel. Sometimes a wire hook, inserted into hole provided, will pull the spring dowel.

(7) Check barrel bore in housing (38) to determine whether standard and 1.5020-1.5025 in. (38.15-38.16 mm) or 0.020 in. (0.51 mm) oversize must be used. Minimum 0.002 in. (0.05 mm) interference fit is required.	Check the bore for score marks; remove marks if found.
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)



LEGEND:

- 33. GOVERNOR PLUNGER ASSEMBLY
- 38. HOUSING
- 39. ROLL PIN

- 41. SPRING PACK HOUSING
- 42. GOVERNOR BARREL

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)


LOCATION/ITEM	ACTION	REMARKS
c. Inspection and Repair (Contd)		
29. Governor barrel (42) (Contd)	<p>(8) Scribe a centerline on new governor barrel (42) and housing (38) as shown in figures A and B.</p> <p>(9) Heat housing (38) in oven to 300°F (149°C).</p> <p>(10) Apply a thin coat of high-pressure lubricant on new governor barrel (42).</p> <p>(11) Place spring pack housing (41) into housing (38).</p> <p>(12) Place governor barrel (42) in bore of housing (38) with chamfered end first and location pin on bottom side.</p> <p>(13) Press into housing (38) using an arbor press if necessary, until it bottoms against spring pack housing (41).</p> <p>(14) Using governor barrel lock-clip driver (61), install roll pin (39) with ST-853 driver through plug hole in bottom of housing (38) with the slot of the pin to front of housing.</p>	<p>This mark is used to line up fuel passages so fuel flow will not have any restrictions.</p> <p>Line up location scribe marks on barrel (42) and governor housing (38).</p> <p>Ensure retaining pin holes of barrel (42) and housing (38) are aligned.</p> <p>Use lock-clip driver (3376136). Slot of roll pin (39) must be toward front of housing (38).</p>
30. Governor plunger assembly (33)	<p>a. Inspect for damage or wear. If only the thrust washer is worn, drive retainer from end of plunger assembly (33) and pull the governor plunger drive from the plunger assembly (33). If it is necessary to remove the stop sleeve, press the stop sleeve off the shaft.</p> <p>b. Selecting a new class size plunger (36). See chart.</p>	<p>If governor plunger (36) outside diameter is worn, replace it with a new plunger of the same class size as etched on barrel face. Replace damaged or worn plunger assembly (33).</p> <p>Select a new class 2 (green color code) plunger and attempt to fit it in the barrel; if plunger enters, try a class 3 (yellow). Keep trying larger sizes until one will not fit, then select a plunger two sizes smaller. The plunger must drop into the bore of its own weight. Remark governor barrel with the new class size of the plunger.</p>
31. Housing (38)	<p>Inspect throttle shaft sleeve in shaft housing (38) for damage.</p>	<p>Discard housing (38) if throttle sleeve is damaged.</p>
32. Nameplate (23)	<p>a. Inspect for damage.</p> <p>b. Remove two drive screws (24) and discard nameplate (23).</p> <p>c. Install new nameplate (23) and drive screws (24).</p>	<p>If damaged, do step 32b.</p> <p>Be sure to transfer information from damaged nameplate (23) to new nameplate.</p>

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
33. Two dowels (40)	Inspect for damage.	Replace if damaged.
34. Fuel filter screen (25)	Inspect for holes or embedded metal particles in mesh.	Discard if damaged.
35. All parts	Inspect for cracks, breaks, and other damage.	Discard any damaged parts. Do not remove two AFC plug balls (44) from housing (38). Discard housing (38) if balls (44) are damaged.

Class and Size PTG-AFC Governor Plungers.

CODE	Red	Blue	Green	Yellow	Orange	Black	Gray	Purple
SIZE	0	1	2	3	4	5	6	7



LEGEND:

- | | |
|-------------------------------|--------------------------------------|
| 23. NAMEPLATE | 39. ROLL PIN |
| 24. DRIVE SCREW | 40. DOWEL (2) |
| 25. FUEL FILTER SCREEN | 41. SPRING PACK HOUSING |
| 33. GOVERNOR PLUNGER ASSEMBLY | 42. GOVERNOR BARREL |
| 36. GOVERNOR PLUNGER | 44. AFC PLUG BALL (2) |
| 38. HOUSING | 61. GOVERNOR BARREL LOCK-CLIP DRIVER |

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly

- | | | | |
|-----|--------------------------------------------------------------------------------|--------------------------------------------|------------------------------------------------------------------------------------------------------------------|
| 36. | Five pipe plugs (22) and (57) | Install on housing (38). | Tighten to 5-8 lb-ft (7-11 N•m). |
| 37. | Torque spring (56) and shims (34) | Install on governor plunger assembly (36). | Put small diameter of spring (56) on shoulder end of plunger (33) with twisting motion to avoid damaging spring. |
| 38. | Governor plunger assembly (33), shims (34), and torque spring (56) (assembled) | Install on housing (38). | |

NOTE

For fuel pump used in M915/Big Cam I engine, perform step 38a.

- | | | |
|----|----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|
| a. | If governor spacer (35) was removed, press governor spacer (35) on plunger (36). | Ensure notched end goes on plunger (36) first with notches facing toward governor barrel (42). |
|----|----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|

CAUTION

The governor plunger has a Lubrite finish. Protect it by laying governor plunger on a copper-jawed vise or V-block to prevent damage to finish when installing pin.

- b. Assemble governor plunger driver (37) through governor spacer (35) and drive into plunger (36). Driver (37) must have interference fit in plunger.

- c. Drive retainer pin through plunger (36) and plunger driver (37).

NOTE


The chamfered side of governor spacer must be installed next to driver. There must be at least 0.002-0.005 in. (0.05-0.13 mm) clearance between spacer face and driver so spacer will "float."

- | | | |
|----|------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------|
| d. | Install the torque spring (56) and shims (34) as required. | Put small end of spring (56) on shoulder end of plunger (36) with a twisting motion to avoid distorting spring (56). |
|----|------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------|

Springs and Specifications Table

COLOR CODE	WIRE DIA. INCHES(MM)	NUMBER	POUNDS LOAD (KG)	LENGTH INCHES (MM)	FREE LENGTH INCHES (MM)
Red/Yellow	0.051 (1.30)	5.5	6.601-7.04 (3.0-3.2)	0.340 (8.64)	0.640-0.660 (16.26-16.76)
Red/Purple	0.148 (3.76)	3.7	47.0-51.0 (21.34-23.15)	0.850 (21.59)	1.200 (30.48)

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)



LEGEND:

- | | |
|-------------------------------|-----------------------------|
| 22. PIPE PLUG (4) | 38. HOUSING |
| 33. GOVERNOR PLUNGER ASSEMBLY | 42. GOVERNOR BARREL |
| 34. SHIMS | 44. AFC PLUG BALL (2) |
| 35. GOVERNOR SPACER | 45. THROTTLE SHAFT ASSEMBLY |
| 36. GOVERNOR PLUNGER | 56. TORQUE SPRING |
| 37. GOVERNOR PLUNGER DRIVER | 57. PIPE PLUG |

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)


39. New gasket washer (7), retainer washer (8), new bellows (9), AFC piston (10), and piston spacer (11)	a. Install on air fuel control piston insert (6). b. Secure with nut (5).	Round end of retainer washer (8) must be against bellows (9) when assembled. If bellows has a part number, it must face toward piston (10). Ensure all parts are aligned. Do not twist bellows (9). Torque nut (5) to 30-40 lb-ft (41-54 N•m).
40. Throttle plunger (13) and new O-ring (30)	Install on air fuel control piston insert (6).	Lubricate O-ring (30). Threaded end of plunger (13) should be flush with outer edge of piston insert (6).
41. Jamnut (12)	Turn on throttle plunger (13) until finger-tight.	
42. Barrel spring (21), barrel (20), and new O-rings (17), (18), and (19)	a. Install barrel spring (21) on housing (38). b. Apply a light coat of lubricating oil to O-rings (17), (18), and (19), and install on barrel (20). c. Press barrel (20) into housing (38). d. Secure with retaining ring (16).	

NOTE

- For M915A1/Big Cam III engine fuel pumps, proceed to step 43 after completing step 42d.
- For M915/Big Cam I engine fuel pumps, perform steps 42e through 42o. Do not perform steps 43 or 44.

e. Lubricate barrel O-rings (17), (18), and (19), and install in grooves in barrel (20). Press barrel into housing (38) and secure with retaining ring (16).

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)



LEGEND:

- | | |
|-----------------------------------|--------------------|
| 5. NUT | 16. RETAINING RING |
| 6. AIR FUEL CONTROL PISTON INSERT | 17. O-RING |
| 7. GASKET WASHER | 18. O-RING |
| 8. RETAINER WASHER | 19. O-RING |
| 9. BELLOWS | 20. BARREL |
| 10. AFC PISTON | 21. BARREL SPRING |
| 11. PISTON SPACER | 30. O-RING (2) |
| 12. JAMNUT (3) | 38. HOUSING |
| 13. THROTTLE PLUNGER | |

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


d. Assembly (Contd)

- 42. Barrel spring (21), barrel (20), and new O-rings (17), (18), and (19) (Contd)

(OLDER-STYLE PUMPS ONLY)

NOTE


If barrel is loose, remove barrel and place barrel spring behind barrel. Secure with flat retaining ring (see illustration below).



AFC BARREL, WITH SPRING, IN FUEL PUMP HOUSING

- f. Place AFC shim (15) in diaphragm spring (14) set groove.
- g. Install barrel spring (21) with small end in housing (38).
- h. Lubricate O-ring and install over control plunger using installer tool (3375146), then install glide ring over tool and plunger on top of O-ring.

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)



LEGEND:

- 14. SPRING
- 15. AFC SHIM
- 17. O-RING
- 18. O-RING
- 19. O-RING

- 20. BARREL
- 21. BARREL SPRING
- 38. HOUSING
- 55. RETAINING RING

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)

42. Barrel spring (21), barrel (20), and new O-rings (17), (18), and (19) (Contd)

NOTE

If barrel contains a 15° plunger lead in chamfer, do not use glide ring forming tool.

i. Assemble gasket washer (7), retainer washer (8) with rounded edge toward bellows (9) (bellows with part number toward piston), piston (10), retainer washer (8), and jamnut (12) on air fuel control piston insert (6).

j. Hold assembly by hex on air fuel control piston insert (5) and center bellows AFC piston (10) and retainer washer (8) without twisting bellows (9). Ensure parts are centered.

Tighten nut (5) to 30-40 lb-in. (3.4-4.5 N•m).

k. Wrap throttle plunger (13) threads with Teflon tape and install throttle plunger (13) into center bolt until threaded end of throttle plunger (13) is flush with center bolt surface. Install jamnut (12), but leave loose.

l. Slide throttle plunger (13) and piston bellows assembly in barrel (20). Insert assembly very carefully to avoid damage to glide ring.

m. Cup bellows (9) between piston (10) and housing (38) to ensure bellows (9) do not wrinkle when cover is installed.

n. Line up bellows holes with housing and cover plate holes. Install screws and washers.

Screws are to be tightened to 30-33 lb-in. (3.4-3.7 N•m). Tighten after setting AFC on test stand.

o. Install lubricated O-ring (30) on AFC needle valve (29) using assembly tool (3375148).

p. Install check valve (58) on cover plate.

43. Spring (14) and AFC shim (15)

a. Check spring as follows:


(1) Put 10 lb (4.54 kg) of load on spring (14).

(2) Compress spring 0.300 in. (7.62 mm) more than dimension of step 1.

Discard spring (14) if not within 37.5-42.4 lb (17.0-19.2 kg) of step 1.

b. Install AFC shim (15) and spring (14) on housing (38).

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)



LEGEND:


- 5. NUT
- 6. AIR FUEL CONTROL PISTON INSERT
- 7. GASKET WASHER
- 8. RETAINER WASHER
- 9. BELLOWS
- 10. AFC PISTON
- 12. JAMNUT (3)
- 13. THROTTLE PLUNGER

- 14. SPRING
- 15. AFC SHIM
- 20. BARREL
- 29. AFC NEEDLE VALVE
- 30. O-RING (2)
- 38. HOUSING
- 45. THROTTLE SHAFT ASSEMBLY
- 58. CHECK VALVE

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
d. Assembly (Contd)		
44. Throttle plunger (13) (with attached parts)	Install on barrel (20).	Insert very carefully to avoid damage to plunger (13).
45. Bellows (9)	a. Carefully push down between AFC piston (10) and housing (38). b. Line up holes in bellows (9) with holes in housing (38).	Ensure bellows (9) is flat where it touches housing (38). Ensure bellows (9) is flat where it touches housing (38).
46. Fuel control cover (4)	a. Install on bellows (9) and housing (38). b. Secure with two screws (1), drilled-head screw (2), and three washers (3).	Do not tighten screws (1). This will be done after AFC is set on test stand.
47. Check valve (58)	a. Ensure check ball is loose and hole near bottom of valve (58) is not plugged. b. Turn on top of fuel control cover (4).	Tighten to 5 lb-ft (7 N•m).
48. Fuel filter screen (25), spring (26), new cap seal ring (27), and filter screen cap (28)	Install on housing (38).	Ensure hole in fuel filter screen (25) faces down. Tighten filter screen cap (28) to 8-12 lb-ft (11-16 N•m).
49. Tapered stud (54)	Install on housing (38).	
50. Jamnut (12)	Install on tapered stud (54).	
51. Threaded stud (32) and jamnut (12)	a. Assemble together. b. Install on housing (38).	
52. AFC needle valve (29) and new O-ring (30)	a. Lubricate O-ring (30) and install on AFC needle valve (29). b. Install on housing (38) until AFC needle valve (29) bottoms out.	
53. Throttle shaft (50)	a. Install on stop (47). b. Secure with setscrew (46).	Do not tighten at this time.
54. Fuel adjusting screw (49) and new O-ring (48)	a. Lubricate O-ring (48) and install on fuel adjusting screw (49). b. Insert fuel adjusting screw (49) in throttle shaft (50) about six rotations.	Ensure fuel hole in throttle shaft (50) is open.
55. Throttle shaft (50) and new O-ring (51)	a. Lubricate O-ring (51) and install on throttle shaft (50). b. Insert throttle shaft (50) into housing (38) with counterbore of fuel port facing down. c. Tighten setscrew (46) to 7-9 lb-ft (9-12 N•m).	Setscrew (46) in stop (47) faces upward.

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)



LEGEND:

- | | |
|------------------------|--------------------------|
| 1. SCREW (2) | 29. AFC NEEDLE VALVE |
| 2. DRILLED-HEAD SCREW | 30. O-RING (2) |
| 3. WASHER (3) | 32. THREADED STUD |
| 4. FUEL CONTROL COVER | 38. HOUSING |
| 9. BELLOWS | 46. SETSCREW |
| 10. AFC PISTON | 47. STOP |
| 12. JAMNUT (3) | 48. O-RING |
| 13. THROTTLE PLUNGER | 49. FUEL ADJUSTING SCREW |
| 20. BARREL | 50. THROTTLE SHAFT |
| 25. FUEL FILTER SCREEN | 51. O-RING |
| 26. FILTER SPRING | 54. TAPERED STUD |
| 27. CAP SEAL RING | 58. CHECK VALVE |
| 28. FILTER SCREEN CAP | |

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)


LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)

56. Retaining ring (55)	Install on end of throttle shaft (50).	
57. New throttle shaft ball (53), throttle shaft cover (52), and two drive screws (24)	Do not install at this time.	These parts will be installed after fuel pump has been calibrated.

- FOLLOW-ON TASKS:
- Install fuel pump front cover and governor (para. 3-61).
 - Install fuel pump governor spring (para. 3-60).
 - Install fuel gear pump (para. 3-59).
 - Install solenoid valve (para. 3-57).
 - Remove fuel pump from mounting plate and ball joint vise (para. 3-56).
 - Perform fuel pump testing and calibration (para. 3-3).

3-62. FUEL PUMP MAIN HOUSING REPAIR (Contd)



LEGEND:

- 24. DRIVE SCREW (2)
- 50. THROTTLE SHAFT
- 52. THROTTLE SHAFT COVER
- 53. THROTTLE SHAFT BALL
- 55. RETAINING RING

3-63. FUEL PUMP TESTING AND CALIBRATION

THIS TASK COVERS:

- a. Calibration Data
- b. Fuel Pump Nameplate Data
- c. Mounting Fuel Pump to Test Stand
- d. Fuel Pump Run-in (Big Cam I and Big Cam III)
- e. Fuel Pump Vacuum and Seal Test
- f. Fuel Pump Vacuum Adjustment
- g. Governor Cutoff RPM Check Stand
- h. Throttle Leakage
- i. Throttle Lever Travel Adjustment
- j. Fuel Pump Idle Speed Check
- k. Fuel Pump Main Pressure Adjustment
- l. Calibration Check Points
- m. AFC Plunger Setting Procedures
- n. No-Air Screw Adjustment
- o. Removing Fuel Pump From Test

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Fuel pump idle adjusting tool (15434) 3375981
 AFC fuel pump adjusting tool kit (15434) 3375189
 Level and angle indicator (15434) 3375855

TEST EQUIPMENT

Fuel injection pump test stand (19204) 11020200
 Fuel injection pump test stand (use with Model A8020 FITS only) (59678) DFP-156

MATERIALS/PARTS

Fluid, calibration (Appendix C, Item 12)
 Lubricant, high-pressure (Appendix C, Item 15)

PERSONNEL REQUIRED

Fuel and electrical systems repairman MOS 63G

REFERENCES (TM)

TM 9-4910-778-14&P

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Fuel pump removed (para. 3-16).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust

GENERAL SAFETY INSTRUCTIONS


Diesel fuel is highly flammable. Do not perform fuel pump testing and calibration procedures near fire, flames, or sparks.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Calibration Data

1. PT (type G) AFC fuel pump (see page 3-461 and 3-462 for identification of fuel pump major components)	Test and calibrate on fuel pump test stand (see pages 3-450 through 3-460) using the following calibration data:	Fill fuel pump test stand with calibration fluid (if calibration fluid is not available, use diesel fuel).
----------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- | | | |
|---------------------------|---------------------------|------------------------------|
| 1. TEST STAND | 14. FUEL RETURN | 27. LUBE OIL PRESSURE OUTLET |
| 2. FUEL PRESSURE GAUGE | 15. START COUNT BUTTON | 28. PRIMER PRESSURE OUTLET |
| 3. NO. 2 VACUUM GAUGE | 16. COUNT "ON" LIGHT | 29. NO. 1 ACCUMULATOR |
| 4. FUEL TEMPERATURE GAUGE | 17. COUNT SELECTOR SWITCH | 30. FUEL INPUT CONNECTOR |
| 5. DUMPING LEVER | 18. FUEL HEAT "ON" LIGHT | 31. FUEL OUTLET CONNECTOR |
| 6. BURETTES | 19. FUEL HEAT SWITCH | 32. PRESSURE GAUGE OUTLET |
| 7. TACHOMETER | 20. SPEED SHIFTING CRANK | 33. AUXILIARY RETURN |
| 8. PRESSURE GAUGE | 21. POWER "ON" LIGHT | 34. LEAK TEST CONNECTOR |
| 9. PRESSURE REGULATOR | 22. MOTOR SWITCH | 35. BYPASS VALVE |
| 10. MANIFOLD INLET | 23. SLOW SWITCH | 36. SELECTOR VALVE |
| 11. DRIVE SHAFT COUPLING | 24. STOP BUTTON | 37. FLOW CONTROL VALVE |
| 12. MOUNTING RAILS | 25. FAST BUTTON | 38. FLOWMETER GLASS TUBE |
| 13. LUBE OIL RETURN | 26. START BUTTON | |

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Pump code; Date; CPL		3894-F; 6-82; 0531 (Big Cam III)
Test Hp Rated RPM		400 @ 2100
Engine Fuel		148-164 PSI(1020-1130 kPa)
Fuel Rate lb/hr		139-145
Auto Governor Cut Off RPM		2130-2150
Throttle Leakage cc/1000 RPM		45 to 69
Throttle Travel Degrees		27-29
Idle Speed @ RPM		32 PSI(220 kPa) @ 500
Intake Manifold		39-47
Calibration @ RPM (Flow)		157 PSI (1082 kPa) @ 2100 (470)
Check Point 1		
PSI @ RPM (Flow)		109-115 PSI(751-793 kPa) @ 1,000 1300 (380)
Check Point 2		
PSI @ RPM (Flow)		76-84 PSI(524-579 kPa) @ 1,000 (300)
AFC Setting		
In-Hg RPM		10 @ 1,600
Fuel (Flow)		85 PSI(586 kPa) (325)
No-Air Set RPM Flow		1600 39 PSI(269 kPa) (220)
Weight Assist Setting		0.800 in.
Weight Assist Spring		P/N 143854
Idle Plunger		Code 25 - P/N 141631
Idle Spring		P/N 3018767
Torque Spring.....		P/N 3002048
Torque Spring Shims (Thickness)		0.005 in. (0.127 mm) P/N 101841 0.010 in. (0.254 mm) P/N 101842 0.020 in. (0.508 mm) P/N 101843
Governor Might		P/N 146437
Governor Spring		P/N 143753
AFC Spring		P/N 179826

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Pump code; Date; CPL		4333-B 89; 0891 (Big Cam III)
Test Hp Rated RPM		400 @ 2100
Engine Fuel		155-172 PSI(1068-1185 kPa)
Torque Rise % Curve		25%
Fuel Rate lb/hr		142-148
Auto Governor Cutoff RPM		2130-2150
Throttle Leakage cc/1000 RPM		110 cc/mim
Throttle Travel Degrees		27-29
Idle Speed @ RPM		37 PSI (255 kPa) @ 500
Idle Speed cc @ RPM		210-215cc @ 630
Intake Mfd. Press		42-50 In./Hg.
Calibration @ RPM (Flow)		164 PSI(1130 kPa) @ 2100
Calibration Flow Lb./Hr		482
Check Point 1		
PSI @ RPM		108-116 (744-799 kPa) @ 1300
Calibration Flow Lb./Hr		390
AFC Setting		
In-Hg PSI.....		8
AFC or Aneroid RPM		1600
Fuel (Flow)		59 PSI (406 kPa) (272)
Certified-Year-By		1989-EPA
Engine Model		NTC-400 Big Cam III
No-Air Set RPM (Flow)		1600 42 PSI(289 kPa) (224)
Weight-Assist Setting- Spring.		0.800 in. (20.3 mm)
Weight-Assist Spring		P/N 143854
Idle Plunger		Code 27- P/N 141632
Auto. Idle Spring		P/N 3018767
Torque Spring Shims (Thickness)		0.020 in. (0.508 mm) P/N 139586
Auto Governor Spring		P/N 153238
Gear Pump Size		3/4 in.
Auto. Governor Weights		P/N 146437
Auto. Governor Plunger		P/N 3040750
AFC Spring		P/N 179834

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Pump code; Date; CPL		0324 9-77; 4-78; 3643 (Big Cam I)
Test Hp Rated RPM		400 @ 2100
Engine Fuel		149-155 PSI (1027-1068 kPa)
Fuel Rate lb/hr		144-150
Auto Governor Cutoff RPM		2130-2150
Throttle Leakage cc/1000 RPM		12 1/2 to 16 12 cc/mim
Throttle Travel Degrees		27-29
Idle Speed @ RPM		20 PSI (138 kPa) @ 500
Calibration @ RPM (Flow)		155 PSI (1068 kPa) @ 2100 (495)
Check Point 1		
PSI @ RPM (Flow)		115-121 PSI (793-834 kPa) @ 1500 (410)
Check Point 2		
PSI @ RPM (Flow)		51-63 PSI (351-434 kPa) @ 1000 (265)
AFC Setting		
In-Hg RPM		6 @ 1600
Fuel (Flow)		72 PSI (496 kPa) (335)
No-Air Set RPM (Flow)		1600 32 PSI (220 kPa) (200)
Weight-Assist Setting		0.870 in. (22.09 mm)
Weight-Assist Spring		P/N 143849
Idle Plunger		Code 37 - P/N 140418
Idle Spring.....		P/N 3018767
Torque Spring.....		P/N 138780
Torque Spring Shims (Thickness)		0.005 in. (0.127 mm) P/N 101841 0.010 in. (0.254 mm) P/N 101842 0.020 in. (0.508 mm) P/N 101843
Governor Might		P/N 143251
Governor Spring		P/N 143751
AFC Spring.....		P/N 179820

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Pump code; Date; CPL	1 33859-77; 0324 4-78; 3619 (Big Cam I)	
Test Hp Rated RPM.....	400 @ 2100	
Engine Fuel	154-170 PSI (1061-1172 kPa)	
Fuel Rate lb/hr	144-150	
Auto Governor Cutoff RPM	2,130-2,150	
Throttle Leakage cc/1000 RPM	12 1/2 to 16 1/2 cc/mim	
Throttle Travel Degrees	27-29	
Idle Speed @ RPM.....	20 PSI (138 kPa) @ 500	
Calibration @ RPM (Flow).....	164 PSI (1130 kPa) @ 2100 (505)	
Check Point 1		
PSI @ RPM (Flow)	118-124 PSI (813-855 kPa) @ 1500 (415)	
AFC Setting		
In-Hg RPM.....	6 @ 1600	
Fuel (Flow)	62 PSI (427 kPa) (285)	
No-Air Set RPM (Flow)	1600 33 PSI (227 kPa) (210)	
Weight-Assist Setting	0.840 in. (21.33 mm)	
Weight-Assist Spring	P/N 143848	
Idle Plunger	Code 40 -P/N 137370	
Idle Spring.....	P/N 3018767	
Torque Spring	P/N 138781	
Torque Spring Shims (Thickness)	0.005 in. (0.127 mm) P/N 101841 0.010 in. (0.254 mm) P/N 101842 0.020 in. (0.508 mm) P/N 101843	
Governor Might	P/N 146437	
Governor Spring	P/N 143252	
AFC Spring.....	P/N 179822	

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Pump code; Date; CPL		0324 9-77; 4-78; 3894 (Big Cam I)
Test Hp Rated RPM		400 @ 2100
Engine Fuel		148-164 PSI(1020-1130 kPa)
Fuel Rate lb/hr		140-146
Auto Governor Cutoff RPM		2130-2150
Throttle Leakage cc/1000 RPM		12 1/2 to 16 1/2 cc/mim
Throttle Travel Degrees		27-29
Idle Speed @ RPM		32 PSI (220 kPa) @ 500
Calibration @ RPM (Flow)		162 PSI (1117 kPa) @ 2100 (473)
Check Point 1		
PSI @ RPM (Flow)		112-118 PS I(772-813 kPa) @ 1300 (389)
AFC Setting		
In-Hg RPM		10 @ 1600
Fuel (Flow)		85 PSI (586 kPa) (325)
No-Air Set RPM (Flow)		1600 39 PSI (269 kPa) (220)
Weight-Assist Setting		0.800 in. (20.3 mm)
Weight-Assist Spring		P/N 143854
Idle Plunger		Code 22- P/N 141630
Idle Spring		P/N 3018767
Torque Spring		P/N 3002048
Torque Spring Shims (Thickness)		0.005 in. (0.127 mm) P/N 101841 0.010 in. (0.254 mm) P/N 101842 0.020 in. (0.508 mm) P/N 101843
Governor Might		P/N 146437
Governor Spring		P/N 153235
AFC Spring		P/N 179826

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Pump code; Date; CPL		0324 9-77; 4-78; 4128 (Big Cam I)
Test Hp Rated RPM		400 @ 2100
Engine Fuel		154-170 PSI (1061-1172 kPa)
Fuel Rate lb/hr		144-150
Auto Governor Cutoff RPM		2130-2150
Throttle Leakage cc/1000 RPM		12 1/2 to 16 1/2 cc/mim
Throttle Travel Degrees		27-29
Idle Speed @ RPM		38 PSI (262 kPa) @ 500
Calibration @ RPM (Flow)		165 PSI (1137 kPa) @ 2100 (490)
Check Point 1		
PSI @ RPM (Flow)		128-136 PSI (882-937 kPa) @ 1500 (430)
AFC Setting		
In-Hg RPM		12 @ 1600
Fuel (Flow)		65 PSI (448 kPa) (267)
No-Air Set RPM (Flow)		1600 45 PSI (310 kPa) (220)
Weight-Assist Setting		0.870 in. (22.09 mm)
Weight-Assist Spring		P/N 143847
Idle Plunger		Code 25- P/N 141631
Idle Spring 144195 Torque Spring		P/N 138783
Torque Spring Shims (Thickness)		0.005 in. (0.127 mm) P/N 101841 0.010 in. (0.254 mm) P/N 101842 0.020 in. (0.508 mm) P/N 101843
Governor Might		P/N 146437
Governor Spring		P/N 3001148
AFC Spring		P/N 179834

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Pump code; Date; CPL		0324 9-77; 4-78; 3449 (Big Cam I)
Test Hp Rated RPM		400 @ 2100
Fuel Rate lb/hr.....		149-165
Auto Governor Cutoff RPM		2130-2150
Throttle Leakage cc/1000 RPM		12 1/2 to 16 1/2 cc/mim
Throttle Travel Degrees		27-29
Idle Speed @ RPM		32 PSI (220 kPa) @ 500
Calibration @ RPM (Flow)		155 PSI (1068 kPa) @ 2100 (500)
Check Point 1		
PSI @ RPM (Flow).....		117-123 PSI (806-848 kPa) @ 1500 (425)
Check Point 2		
PSI @ RPM (Flow).....		69-77 PSI (475-530 kPa) @ 1000 (315)
AFC Setting		
In-Hg RPM		12 @ 1600
Fuel (Flow)		65 PSI (448 kPa) (267)
No-Air Set RPM (Flow)		1600 45 PSI (310 kPa) (235)
Weight-Assist Setting		0.900 in. (22.8 mm)
Weight-Assist Spring.....		P/N 143848
Idle Plunger		Code 40 - P/N 137370
Idle Spring		P/N 144195
Torque Spring		P/N 138769
Torque Spring Shims (Thickness)		0.005 in. (0.127 mm) P/N 101841 0.010 in. (0.254 mm) P/N 101842 0.020 in. (0.508 mm) P/N 101843
Governor Might.....		P/N 146437
Governor Spring		P/N 143251

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Pump code; Date; CPL		4567-A 87; 0531 (Big Cam III)
Engine Fuel		148-164 PSI (1020-1130 kPa)
Torque Rise % Curve		25%
Fuel Rate lb/hr		140-146
Idle Speed @ RPM		40 PSI (275 kPa) @ 500
Idle Speed cc @ RPM		190-195cc @ 650
Intake Mfd. Press		39-47 In./Hg.
Calibration @ RPM (Flow)		162 PSI(1117 kPa) @ 2100
Calibration Flow Lb./Hr		473
Check Point 1		
PSI @ RPM		111-118 PSI (765-813 kPa) @ 1300
Calibration Flow Lb./Hr		389
AFC Setting		
In-Hg PSL		10
Fuel (Flow)		85 PSI (586 kPa) (325)
Certified-Year-By		1987-EPA
Engine Model		NTC-400 Big Cam III
No-Air Set RPM (Flow)		32 (220 kPa) (220)
Idle Plunger		Code 22 - P/N 141630
Torque Spring Shims (Thickness)		0.025 m (0.635 mm) P/N 3002058
Auto Governor Spring		P/N 3000941
AFC Spring		P/N 179826

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Pump code; Date; CPL		3619-G 87; 0393 (Big Cam I)
Test Hp Rated RPM		400 @ 2100
Engine Fuel		154-170 PSI (1061-1172 kPa)
Torque Rise % Curve		15%
Fuel Rate lb/hr		144-150
Auto Governor Cutoff RPM		2130-2150
Throttle Leakage cc/1000 RPM		110 cc
Throttle Travel Degrees		27-29
Idle Speed @ RPM		20 PSI (138 kPa) @ 500
Idle Speed cc @ RPM.....		200-215 cc @ 600
Intake Mfd. Press		43-51 In./Hg.
Calibration @ RPM.....		164 PSI (1130 kPa) @ 2100
Calibration Flow Lb./Hr		505
Check Point 1		
PSI @ RPM		118-124 PSI (813-855 kPa) @ 1500
Calibration Flow Lb./Hr		415
Weight-Assist Setting- Spring.....		0.800 in. (20.3 mm)
Weight-Assist Spring		P/N 143848
Calibration Flow Lb./Hr		389
AFC Setting		
In-Hg PSI		6
Fuel (Flow)		62 PSI (427 kPa) (285)
Certified-Year-By		1987-EPA
Engine Model		NTC-400 Big Cam I
No-Air Set RPM (Flow)		32 PSI (220 kPa) (220)
Idle Plunger		P/N 137370
Auto. Idle Spring		P/N 3018767
Torque Spring Shims (Thickness)		P/N 138781
Auto Governor Spring		P/N 143252
Gear Pump Size		3/4 in.
Auto. Governor Weights		P/N 146437
Auto. Governor Plunger		P/N 3009380
AFC Spring		P/N 179822
No-Air Set RPM (Flow)		1600 33 PSI (227 kPa) (210)

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Pump code; Date; CPL		4128-C 82; 0267 (Big Cam I)
Idle Speed @ RPM		38 PSI (262 kPa) @ 500
Idle Speed cc @ RPM		17015 cc @ 590
Intake Mfd. Press		41-49 In./Hg.
Calibration @ RPM (Flow)		165 (1137 kPa) @ 2100
Calibration Flow Lb./Hr		490
Check Point 1		
PSI @ RPM		128-136 PSI (882-937 kPa) @ 1300
Calibration Flow Lb./Hr		430
Weight-Assist Setting - Spring		0.870 in. (22.09 mm)
Weight-Assist Spring		P/N 143847
AFC Setting		
In-Hg PSI		12
Fuel (Flow)		65 PSI (1137 kPa) (267)
Certified-Year-By		1982-EPA
Engine Model		NTC-400 Big Cam I
No-Air Set RPM (Flow)		32 PSI (220 kPa) 220
Idle Plunger		Code 25-P/N 141631
Auto. Idle Spring		P/N 144195
Torque Spring Shims (Thickness)		0.020 in. (0.508 mm) P/N 138783
Auto Governor Spring		P/N 3001148
AFC Spring		P/N 179834



NOTE

For other pump codes not listed, use Cummins Fuel Pump PT (Type G) Calibration Values.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Pump code; Date; CPL		0324 9-77; 4-78; 3257 (Big Cam I)
Test Hp Rated RPM		400 @ 2100
Engine Fuel		154-170 PSI (1061-1172 kPa)
Fuel Rate lb/hr		144-150
Auto Governor Cutoff RPM		2130-2150
Throttle Leakage cc/1000 RPM		12 1/2 to 16 1/2 cc/mim
Throttle Travel Degrees		27-29
Idle Speed @ RPM		38 PSI (262 kPa) @ 500
Calibration @ RPM (Flow)		165 PSI (1137 kPa) @ 2100 (480)
Check Point 1		
PSI @ RPM (Flow)		130-136 PSI (896-937 kPa) @ 1500 (410)
Check Point 2		
PSI @ RPM (Flow)		71-77 PSI (489-531 kPa) @ 1000 (290)
AFC Setting		
In-Hg RPM		14 @ 1600
Fuel PSI (Flow)		65 PSI (448 kPa) (267)
No-Air Set RPM (Flow).....		1600 PSI (310 kPa) 45 PSI (310 kPa) (220)
Weight-Assist Setting		0.870 in. (22.09 mm)
Weight-Assist Spring		P/N 143847
Idle Plunger		Code 25 -P/N 141631
Idle Spring		P/N 144195
Torque Spring		P/N 138783
Torque Spring Shims (Thickness)		0.005 in. (0.127 mm) P/N 101841 0.010 in. (0.254 mm) P/N 101842 0.020 in. (0.508 mm) P/N 101843
Governor Might		P/N 146437
Governor Spring		P/N 143752
AFC Spring		P/N 179834

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)





LEGEND:

- 39. CHECK VALVE
- 40. SHUTDOWN SOLENOID VALVE
- 41. AFC SIGNAL ATTENUATOR
- 42. RESTRICTOR
- 43. AFC CASE VENT
- 44. AFC COVER PLATE
- 45. GOVERNOR SPRING PACK HOUSING
- 46. EXTERNAL FUEL FILTER HOUSING
- 47. PULSATION DAMPER
- 48. CASE FILL PLUG
- 49. SHUTDOWN SOLENOID MANUAL OVER-RIDE KNOB
- 50. FUEL FILTER SCREEN
- 51. GEAR PUMP
- 52. THROTTLE LEVER
- 53. DRIVE PIN (2)
- 54. THROTTLE SHAFT
- 55. FUEL PUMP MAIN HOUSING
- 56. THROTTLE SHAFT COVER
- 57. FRONT COVER
- 58. TACHOMETER DRIVE

M915/BIG CAM I
FUEL PUMP COMPONENTS

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)




LEGEND:

- 39. CHECK VALVE
- 40. SHUTDOWN SOLENOID VALVE
- 42. RESTRICTOR
- 44. AFC COVER PLATE
- 45. GOVERNOR SPRING PACK HOUSING
- 46. EXTERNAL FUEL FILTER HOUSING
- 48. CASE FILL PLUG
- 49. SHUTDOWN SOLENOID MANUAL OVER-RIDE KNOB
- 50. FUEL FILTER SCREEN
- 51. GEAR PUMP
- 52. THROTTLE LEVER
- 53. DRIVE PIN (2)
- 54. THROTTLE SHAFT
- 55. FUEL PUMP MAIN HOUSING
- 56. THROTTLE SHAFT COVER
- 57. FRONT COVER
- 58. TACHOMETER DRIVE

M915A1/BIG CAM III
FUEL PUMP COMPONENTS

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- | | | |
|---------------------------|---------------------------|------------------------------|
| 1. TEST STAND | 14. FUEL RETURN | 27. LUBE OIL PRESSURE OUTLET |
| 2. FUEL PRESSURE GAUGE | 15. START COUNT BUTTON | 28. PRIMER PRESSURE OUTLET |
| 3. NO. 2 VACUUM GAUGE | 16. COUNT "ON" LIGHT | 29. NO. 1 ACCUMULATOR |
| 4. FUEL TEMPERATURE GAUGE | 17. COUNT SELECTOR SWITCH | 30. FUEL INPUT CONNECTOR |
| 5. DUMPING LEVER | 18. FUEL HEAT "ON" LIGHT | 31. FUEL OUTLET CONNECTOR |
| 6. BURETTES | 19. FUEL HEAT SWITCH | 32. PRESSURE GAUGE OUTLET |
| 7. TACHOMETER | 20. SPEED SHIFTING CRANK | 33. AUXILIARY RETURN |
| 8. PRESSURE GAUGE | 21. POWER "ON" LIGHT | 34. LEAK TEST CONNECTOR |
| 9. PRESSURE REGULATOR | 22. MOTOR SWITCH | 35. BYPASS VALVE |
| 10. MANIFOLD INLET | 23. SLOW SWITCH | 36. SELECTOR VALVE |
| 11. DRIVE SHAFT COUPLING | 24. STOP BUTTON | 37. FLOW CONTROL VALVE |
| 12. MOUNTING RAILS | 25. FAST BUTTON | 38. FLOWMETER GLASS TUBE |
| 13. LUBE OIL RETURN | 26. START BUTTON | |


3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Fuel Pump Nameplate Data

<p>2. Fuel pump nameplate (54)</p>	<p>Make sure nameplate properly describes fuel pump to be calibrated.</p>	<p>a. First set of digits on top line provides pump control parts list (55). b. Next four spaces on top line provide base fuel pump code (56). c. Next eight spaces on top line provide fuel pump serial number (57). d. Last space on top line provides latest fuel pump revision code (58). e. First space on bottom line provides fuel pump direction of rotation (59) (right-hand rotation pump is not marked and this space will be blank if pump has right-band rotation). Use REVERSE position on fuel pump test stand to drive fuel pump clockwise for right rotation. f. Next seven spaces on bottom line provide fuel pump assembly number (60). g. Last five spaces on bottom line provide engine shop order number (61).</p>
------------------------------------	---------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- 54. FUEL PUMP NAMEPLATE
- 55. CONTROL PARTS LIST
- 56. FUEL PUMP CODE
- 57. FUEL PUMP SERIAL NUMBER

- 58. LATEST FUEL PUMP REVISION CODE
- 59. FUEL PUMP ROTATION
- 60. FUEL PUMP ASSEMBLY NUMBER
- 61. ENGINE SHOP ORDER NUMBER

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Mounting Fuel Pump to Test


3. Fuel damper and head	Remove.	Refer to para. 3-58.
4. Fuel damper from 5-ton injection pump (62)	Install on gear pump (47).	Make sure to plug fuel damper outlet with suitable plug.
5. Case fill plug (44)	a. Remove from fuel pump main housing (51). b. Fill main housing (51) with clean calibration fluid. c. Install case fill plug (44) into main housing (51).	Tighten enough to make sure no leakage will occur during air test.

NOTE

If the throttle shaft cover has not already been removed, remove to gain access to the no-air adjustment screw. Adjusting the screw is necessary to properly calibrate fuel pump. Complete steps 6 through 10 to remove the throttle shaft cover.

6. Two screws (49)	Carefully remove from throttle shaft cover (52).	Use channel-lock pliers or chisel to remove screws (49). Use care to prevent damage to fuel pump main housing (51).
--------------------	--------------------------------------------------	---------------------------------------------------------------------------------------------------------------------

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:
 44. CASE FILL PLUG
 47. GEAR PUMP
 49. SCREWS (2)

51. FUEL PUMP MAIN HOUSING
 52. THROTTLE SHAFT COVER
 62. FUEL DAMPER FROM 5-TON INJECTION PUMP

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


c. Mounting Fuel Pump to Test Stand (Contd)

NOTE

Scribe position of throttle shaft and throttle lever before removing.

7. Jamnut (63), washer (64), and screw (65)	Remove from throttle lever (48).	
8. Throttle lever (48)	Remove from throttle shaft (50).	
9. Throttle shaft cover (52)	Remove from fuel pump main housing (51).	
10. Throttle shaft (50)	a. Install on throttle lever (48). b. Install and tighten screw (65), washer (64), and jamnut (63).	
11. Test stand adapter ring (67)	a. Install on test stand adapter bracket (66). b. Secure with four screws (69) and washers (68).	Word "TOP" (or adapter ring part number) must be visible on top side of ring (67) when assembled.
12. Test stand adapter ring (67) and test stand adapter bracket (66) (assembled)	a. Install on test stand mounting rails (12). b. Secure to rails (12) with clamp bar (70).	Tighten clamp bar (70) finger-tight only at this time.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- 12. TEST STAND MOUNTING RAIL (2)
- 48. THROTTLE LEVER
- 50. THROTTLE SHAFT
- 51. FUEL PUMP MAIN HOUSING
- 52. THROTTLE SHAFT COVER
- 63. JAMNUT
- 64. WASHER

- 65. SCREW
- 66. TEST STAND ADAPTER BRACKET
- 67. TEST STAND ADAPTER RING
- 68. WASHER (4)
- 69. SCREW (4)
- 70. CLAMP BAR

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


c. Mounting Fuel Pump to Test Stand (Contd)

NOTE

Lubricate tachometer drive gears in front cover to protect them from excessive wear during calibration.

13. Fuel pump assembly (71)	a. Mount on test stand adapter ring (67). b. Secure with four screws (72) and washers (73). c. Rotate main shaft so that one lug on drive flange is located at 12 o'clock position.	
14. Test stand coupling insert (74)	Place into test stand drive shaft coupling (11) so that one lug of insert is at 11 o'clock position and another lug is at 1 o'clock position.	It may be necessary to hand rotate drive shaft coupling (11) to attain this positioning of insert lugs. This is to assure easy engagement of fuel pump drive flange lugs into test stand coupling insert (74).
15. Clamp bar (70)	Loosen and slide fuel pump assembly (71), test stand adapter ring (67), and test stand adapter bracket (66) on mounting rails (12) until they engage with test stand coupling insert (74).	Allow 0.0625 in. (1.5875 mm) end clearance between drive coupling on fuel pump assembly (71) and coupling insert (74) on test stand. Tighten clamp bar (70) when fuel pump assembly (71) is properly engaged.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- 11. TEST STAND DRIVE SHAFT COUPLING
- 12. MOUNTING RAIL (2)
- 66. TEST STAND ADAPTER BRACKET
- 67. TEST STAND ADAPTER RING
- 70. CLAMP BAR

- 71. FUEL PUMP ASSEMBLY
- 72. SCREW (4)
- 73. WASHER (4)
- 74. TEST STAND COUPLING INSERT


3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Mounting Fuel Pump to Test Stand (Contd)

16. Throttle shaft (50)	Rotate toward test stand (1) (to wide-open position) and retain with a spring between throttle lever (48) and adapter ring (67).	Use test stand (11020200) (1).
17. Inlet adapter assembly (75)	Install on gear pump (47).	
18. Fuel suction hose (76)	Connect from suction control valve (77) to inlet adapter assembly (75).	
19. Primer pressure outlet (28)	Plug with suitable pipe plug.	
20. Fuel return hose (78)	Connect from lube oil pressure outlet (27) to lube oil return (13).	
21. Fuel manifold hose (79)	Connect from No. 2 vacuum gauge (3) to side connection on inlet adapter assembly (75).	
22. Pump discharge fitting assembly (80)	Install on top of shutdown solenoid valve (40).	
23. Fuel pressure hose (81)	Connect from pressure gauge outlet (32) to pump discharge fitting assembly (80).	

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- | | |
|------------------------------|-------------------------------------|
| 1. TEST STAND | 50. THROTTLE SHAFT |
| 3. NO. 2 VACUUM GAUGE | 67. ADAPTER RING |
| 13. LUBE OIL RETURN | 75. INLET ADAPTER ASSEMBLY |
| 27. LUBE OIL PRESSURE OUTLET | 76. FUEL SUCTION HOSE |
| 28. PRIMER PRESSURE OUTLET | 77. SUCTION CONTROL VALVE |
| 32. PRESSURE GAUGE OUTLET | 78. FUEL RETURN HOSE |
| 40. SHUTDOWN SOLENOID VALVE | 79. FUEL MANIFOLD HOSE |
| 47. GEAR PUMP | 80. PUMP DISCHARGE FITTING ASSEMBLY |
| 48. THROTTLE LEVER | 81. FUEL PRESSURE HOSE |


3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Mounting Fuel Pump to Test Stand (Contd)

24. Fuel input hose (82)	Connect from fuel input connector (30) to pump discharge fitting assembly (80).	
25. Fuel hose (83)	Connect from fuel outlet connector (31) to fuel return (14).	
26. Flexible hose (84)	Connect from leak test connector (34) to No. 1 accumulator (29).	
27. Tee fitting (85)	Install on bleed drain fitting (87).	
28. Leakage accumulator hose (86)	Connect from auxiliary return (33) to tee fitting (85).	
29. Check valve (39)	Install into AFC vent cooling outlet on fuel pump main housing (51).	
30. Flexible hose (88)	Connect from bleed drain fitting (87) to tee fitting (85).	
31. Governor spring pack housing (43)	a. Remove plug (89).	

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- | | |
|----------------------------------|-------------------------------------|
| 14. FUEL RETURN | 80. PUMP DISCHARGE FITTING ASSEMBLY |
| 29. NO. 1 ACCUMULATOR | 82. FUEL INPUT HOSE |
| 30. FUEL INPUT CONNECTOR | 83. FUEL HOSE |
| 31. FUEL OUTLET CONNECTOR | 84. FLEXIBLE HOSE |
| 33. AUXILIARY RETURN | 85. TEE FITTING |
| 34. LEAK TEST CONNECTOR | 86. LEAKAGE ACCUMULATOR HOSE |
| 39. CHECK VALVE | 87. BLEED DRAIN FITTING |
| 43. GOVERNOR SPRING PACK HOUSING | 88. FLEXIBLE HOSE |
| 51. FUEL PUMP MAIN HOUSING | 89. PLUG |

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Mounting Fuel Pump to Test Stand (Contd)

31. Governor spring pack housing (43) (Contd)	b. Install fuel pump idle adjusting tool (90) on governor spring pack housing (43).	Use fuel pump idle adjusting tool (3375981). To assure that governor has enough clearance to cut off during calibration adjustments, carefully pull tool shaft out so that snapping is lightly resting against stop. If too much force is put on tool, snapping may be pushed off tool shaft and down into fuel pump main housing (51).
32. AFC cover plate (42) and restrictor (41)	Remove from fuel pump main housing (51) and replace with AFC adjusting tool (91).	AFC adjusting tool is part of AFC fuel pump adjusting tool kit (3375189). Pull out knobs on tool to disengage sockets. Relief cuts on tool must face toward rear of pump to allow clearance for AFC fuel passage pipe plug (92).
33. Regulated shop air source	Connect to test stand (1).	Maximum pressure should not exceed 40 psi (275 kPa).
34. Aneroid AFC adjusting line (93)	Connect to AFC adjusting tool (91).	

NOTE

Some Big Cam I engines may have fuel pumps having the Air Signal Attenuator (ASA). For those pumps, perform step 35. Big Cam III engine fuel pumps do not require step 35 to be performed.

35. Air Signal Attenuator (ASA) and restrictor. (The ASA and restrictor are collectively called the smoke control valve.)	a. Calibrate the fuel pump without the smoke control valve. Valve is threaded into AFC cover plate (42). See illustration on next page.	Smoke control valve produces a delay in intake manifold pressure signal to the AFC, resulting in a reduction of accelerated smoke.
---------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------

CAUTION

When removing the ASA from the AFC cover plate, do not disassemble by placing the wrench on top of the ASA. Place the wrench on the hex at the bottom of the ASA, just above the top of the restrictor for disassembly.


b. Check valve by blowing through each side of valve.	There should be free air flow when blowing through the 1/8-NPT end of valve (AFC cover plate end) and restricted flow when blowing through intake manifold end (almost no air flow). Check ball is located in the restrictor (41) to prevent a reverse fuel flow to the intake manifold if AFC bellows ruptures.
c. Check restrictor check ball for sticking by shaking it and listening for check ball to rattle in restrictor (41). If check ball is stuck and not moving when restrictor is shaken, replace the unit.	
d. Check restrictor orifice by connecting it to an air line. Immerse restrictor (41) in clean test fluid and pressurize it with	If no air bubbles are coming out of orifice, restrictor (41) is plugged or contaminated and should be replaced.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)





LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

10 psi (69 kPa).

NOTE



AIR SIGNAL ATTENUATOR AND RESTRICTOR



LEGEND:

- 1. TEST STAND
- 41. RESTRICTOR
- 42. AFC COVER PLATE
- 43. GOVERNOR SPRING PACK HOUSING
- 51. FUEL PUMP MAIN HOUSING

- 90. FUEL PUMP IDLE ADJUSTING TOOL
- 91. AFC ADJUSTING TOOL
- 92. AFC FUEL PASSAGE PIPE PLUG
- 93. ANEROID AFC ADJUSTING LINE

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Fuel Pump Run-in (Big Cam I and Big Cam III)


CAUTION

- The test stand motor switch (22) is marked "REVERSE" and "FORWARD." For all testing of this pump, the test stand motor switch (22) must be set to the "REVERSE" position. This position corresponds to the right-hand drive rotation requirements for this fuel pump. If the motor switch (22) is in the incorrect position, the pump will run dry and could be damaged.
- Be certain the fuel filter screen (46) is clean and installed correctly. Foreign material in the pump could damage seals, gears, or shafts, and plug up the fuel passages. Check to see that the fuel filter screen (46) is installed with the hole in the screen at the bottom. If the fuel filter screen (46) is installed upside down, it will cut off all fuel flow to the pump. The pump will then run dry and could be damaged.

NOTE

For a complete description and location of the test stand controls, refer to TM 9-4910-387-14&P, Tester, Fuel Injection, Single End Drive, 150 to 3000 RPM.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)




LEGEND:
22. MOTOR SWITCH
46. FUEL FILTER SCREEN

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
d. Fuel Pump Run-in (Big Cam I and Big Cam III) (Contd)		
36. Shutdown solenoid manual override knob (45)	Open by turning clockwise.	This step is needed to cancel out the normal electrical shutdown through the solenoid and allow fuel flow for testing purposes.
37. Bypass valve (35), suction control valve (77), and flow control valve (37)	Open.	
38. All other valves on test stand (1)	Backseat to prevent leakage.	
39. Speed-shifting crank (20)	Set to HIGH range.	After crank has been set to HIGH range, turn it back (counterclockwise) about one turn so that the handle load is neutralized.
40. Throttle lever (48)	Make sure it is in the wide-open position and secured with a spring.	
41. Selector valve (36)	Turn to ROTAMETER position.	

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- | | |
|--------------------------|--------------------------------------------|
| 1. TEST STAND | 37. FLOW CONTROL VALVE |
| 20. SPEED-SHIFTING CRANK | 45. SHUTDOWN SOLENOID MANUAL OVERRIDE KNOB |
| 35. BYPASS VALVE | 48. THROTTLE LEVER |
| 36. SELECTOR VALVE | 77. SUCTION CONTROL VALVE |

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


d. Fuel Pump Run-in (Big Cam I and Big Cam III) (Contd)

42. Power switch on test stand (1)	Turn to ON position.	Power "ON" light (21) should light up.
43. Fuel heat switch (19)	Turn to ON position and observe fuel temperature on fuel temperature gauge (4).	Fuel heat "ON" light (18) should light up. Proper operating temperature for calibration fluid is 90-100°F (32.2-37.8°C). The test stand (1) built-in thermometer will automatically maintain this temperature once the fluid has been circulated.
44. Pressure regulator (9)	Adjust until a reading of 50.00 Hg (180,000 kPa) registers on pressure gauge (8).	
45. Start button (26)	Depress to start test stand (1).	
46. Fast switch (25) and slow switch (23)	Depress and release as necessary until exactly 500 rpm is indicated on tachometer (7).	

NOTE

Check the flowmeter glass tube for air in the fuel flow. If air bubbles are present, work the fuel pump throttle lever from full-open to idle several times to relieve any trapped air in the pump. If air bubbles persist, it is an indication of an air leak in the system. Turn the test stand off and check all line connections between the test stand and fuel pump for tightness. Check the rating of gear pump to main housing and check to see that test stand reservoir is full of fluid.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- | | |
|---------------------------|----------------------|
| 1. TEST STAND | 19. FUEL HEAT SWITCH |
| 4. FUEL TEMPERATURE GAUGE | 21. POWER "ON" LIGHT |
| 7. TACHOMETER | 23. SLOW SWITCH |
| 8. PRESSURE GAUGE | 25. FAST SWITCH |
| 9. PRESSURE REGULATOR | 26. START BUTTON |
| 18. FUEL HEAT "ON" LIGHT | |

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


d. Fuel Pump Run-in (Big Cam I and Big Cam III) Contd)

47. Fuel pump assembly (71)	Run at 500 rpm for five minutes.	This step is done to purge all air from the system. The gear pump (47) must be able to pick up fluid at this speed without the aid of priming. If no fluid pickup is indicated in the flowmeter glass tube (38), check the fuel filter screen (46) for proper installation; check that the test stand motor switch is set to the correct position; check that the test stand suction control valve is open; and check all hose connections and gear pump (47) for condition.
-----------------------------	----------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

e. Fuel Pump Vacuum and Seal

48. Case fill plug (44)	<p>a. Remove from fuel pump main housing (51).</p> <p>b. Look on fuel pump main housing (51) and make sure fuel is present.</p> <p>c. Install plug (44) on main housing (51).</p>	
49. Fuel pump assembly (71)	Check mating surfaces and weep hole (94) for leaks.	Replace seals as required.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- 38. FLOWMETER GLASS TUBE
- 44. CASE FILL PLUG
- 46. FUEL FILTER SCREEN
- 47. GEAR PUMP

- 51. FUEL PUMP MAIN HOUSING
- 71. FUEL PUMP ASSEMBLY
- 94. WEEP HOLE


3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

f. Fuel Pump Vacuum

50. Bypass valve (35)	Close.	
51. Suction control valve (77)	Open completely.	
52. Fast button (25)	Depress until fuel pump speed is 2000 rpm.	
53. Suction control valve (77)	Adjust to obtain exactly 8.00 in. Hg. (28,800 kPa) reading on No. 2 vacuum gauge (3) at 2000 rpm pump speed.	Once this suction control valve setting is attained, it must not be changed during later calibration procedures.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)




LEGEND:

- 3. NO. 2 VACUUM GAUGE
- 25. FAST BUTTON
- 35. BYPASS VALVE
- 77. SUCTION CONTROL VALVE

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
g. Governor Cutoff RPM Check		
54. Fast button (25)	Depress until pump speed is 2100 rpm as indicated on tachometer (7).	Make sure flow control valve (37) is open and selector valve (36) is set at the ROTAMETER position.
55. Flow control valve (37)	Adjust to 470 pph.	Fuel pump throttle lever (48) should remain in wide-open position and be secured by a spring.
56. Fast button (25)	While watching fuel pressure gauge (2), gradually increase pump speed until pressure drops slightly instead of rising.	Pressure should drop when reading on tachometer (7) is between 2130 and 2150 rpm. If governor cutoff point (as indicated by the tachometer) is not within above limits, do steps 57 through 60. If governor cutoff point is within limits, go to step 61.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- 2. FUEL PRESSURE GAUGE
- 7. TACHOMETER
- 25. FAST BUTTON

- 36. SELECTOR VALVE
- 37. FLOW CONTROL VALVE
- 48. THROTTLE LEVER


3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

g. Governor Cutoff RPM Check (Contd)

57. Slow button (23) and stop button (24)	a. Depress slow button (23) to slow test stand to minimum speed. b. Depress stop button (24) to stop test stand.	
58. Governor spring pack housing (43) and snapping (95)	Remove from fuel pump main housing (51).	
59. Shims (96)	Remove to decrease governor cutoff speed and add to increase governor cutoff speed.	Each 0.001 in. (0.025 mm) thickness of shim will change the governor cutoff speed about 2 rpm. Shims are available in 0.005, 0.010, and 0.020 in. (0.127, 0.254, and 0.508 mm) thickness. They should be placed between governor spring (97) and retainer (98). If more than 0.150 in. (3.81 mm) total shim thickness is required, replace governor spring (97).
60. Snapping (95) and governor spring pack housing (43)	Install on fuel pump main housing (51).	After installing shims, snapping, and spring pack housing, purge the fuel pump of air as described in step 47. When fluid in flowmeter glass tube is clear again, recheck governor cutoff point as described in steps 54 through 56.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

23. SLOW BUTTON

24. STOP BUTTON

43. GOVERNOR SPRING PACK HOUSING

51. FUEL PUMP MAIN HOUSING

95. SNAPPING

96. SHIM (1 TO 3)

97. GOVERNOR SPRING

98. RETAINER

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


h. Throttle Leakage

NOTE

This setting is important because it controls the deceleration time of the engine.

61. Fast button (25) and slow button (23)	Depress and release until fuel pump speed is at 2100 rpm as indicated on the tachometer (7).	
62. Flowmeter glass tube (38)	Check fuel flow at exactly 470 pph.	If balance has changed between rpm speed and fuel flow, it must be reset. Also, selector valve (36) must be at ROTAMETER position.
63. Selector valve (36)	Turn to LEAKAGE TEST position.	
64. Count selector switch (17)	Turn to OFF position.	
65. Dumping lever (5)	Pull out so that fuel will be retained in the No. 1 burette (6).	

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- 5. DUMPING LEVER
- 6. NO. 1 BURETTE
- 7. TACHOMETER
- 17. COUNT SELECTOR SWITCH

- 23. SLOW BUTTON
- 25. FAST BUTTON
- 36. SELECTOR VALVE
- 38. FLOWMETER GLASS TUBE

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

h. Throttle Leakage (Contd)


66. Throttle lever (48)	Move to full fuel position, and press start count button (15) to start the fuel count.	Count "ON" light (16) should light up.
67. Dumping lever (5)	Push in when No. 1 burette (6) is full to dump fuel collected.	By operating count selector for one cycle before measuring fuel flow, the inside of the burette will be wet. This makes a more accurate reading possible.
68. Count selector switch (17)	Turn to "1000" position.	

CAUTION

Do not hold the fuel pump throttle lever in the idle position any longer than necessary to complete the tests. The pump may overheat since fuel flow is used to cool and lubricate the pump.

69. Throttle lever (48)	a. Move to idle position until pressure gauge (8) stabilizes at lowest reading.	Allow No. 1 burette (6) to fill.
	b. Press start count button (15).	

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)




LEGEND:

- | | |
|------------------------|---------------------------|
| 5. DUMPING LEVER | 16. COUNT "ON" LIGHT |
| 6. NO. 1 BURETTE | 17. COUNT SELECTOR SWITCH |
| 8. PRESSURE GAUGE | 48. THROTTLE LEVER |
| 15. START COUNT BUTTON | |

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
h. Throttle Leakage (Contd)		
70. No. 1 burette (6)	When count cycle ends and count "ON" light (16) goes out, release lever. Read amount of fuel delivered.	The scale on the burette is measured in cubic centimeters (cc). Normal throttle leakage for this pump is 45 to 59 cc at 1000 rpm. Repeat steps 67 through 70 at least three times to ensure accuracy. (For Big Cam I engine fuel pumps, 12.5 to 16.5 cc throttle linkage is normal). If throttle leakage is not within limits shown above, do step 71. If throttle leakage is within limits shown above, go to step 72.
71. Rear throttle stopscrew (99) and locknut (100)	Loosen locknut (100) and adjust rear throttle stopscrew (99) to adjust fuel delivery.	Turning stopscrew (99) in will increase fuel flow, and turning stopscrew (99) out will decrease fuel flow. Even a slight movement of stopscrew (99) will make several cubic centimeters difference in fuel flow. Sometimes just loosening and retightening the locknut (100) will be enough.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- 6. NO. 1 BURETTE
- 16. COUNT "ON" LIGHT

- 99. REAR THROTTLE STOPSCREW
- 100. LOCKNUT

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

i. Throttle Lever Travel Adjustment


72. Slow switch (23)	Depress until 500 rpm is indicated on tachometer (7).	
73. Level and angle indicator (101)	Position on fuel pump main housing (51).	Use level and angle indicator (3375855) (101).

NOTE

Do not adjust rear throttle stop from the position it was adjusted to under THROTTLE LEAKAGE ADJUSTMENT. The rear throttle stopscrew has already been set to provide the proper deceleration time for the engine, and any change at this point will require recalibration of throttle leakage.

74. Throttle lever (48)	<p>a. Using level and angle indicator (101), set the idle position centerline of throttle lever (48) at 55° from the vertical on the centerline of throttle shaft (50).</p> <p>b. Move to full-throttle position. At this position, the centerline of the throttle lever must be 27° as shown on level and angle indicator (101).</p> <p>c. Checking and adjusting throttle lever (48) travel using tool 3375355, throttle lever travel template (116).</p> <p>d. Position template (116) on fuel pump housing as shown in figure A.</p> <p>e. Move throttle lever (48) to full throttle position.</p>	<p>The throttle lever (48) may be repositioned on the throttle shaft (50) as required to attain 55°.</p> <p>Check centerline travel of throttle lever (48). Centerline travel from idle position to full-throttle position must be 27°. If throttle lever (48) travel is not correct, loosen jamnut (102) and adjust front throttle stopscrew (103) to attain 27° travel, then lock setting with jamnut (102).</p> <p>The throttle lever travel template has two sets of matched holes for lever alinement that may be used. The first and third holes, moving clockwise from MAX to IDLE on the template, will set lever travel for 27°-29° movement. The second and fourth holes, moving clockwise from MAX to IDLE will also set lever travel for 27°-29° movement. Either set of holes may be used, but do not use the first and last hole in combination or the second and third holes; otherwise an erroneous reading will result. See figure B. Move the throttle lever to idle position, and line up the hole on the throttle shaft lever with the idle hole on the template. The throttle shaft lever may be repositioned on the throttle shaft as required to line up the holes.</p> <p>Line up the hole on the throttle lever (48) with the appropriate MAX hole on the template. If throttle lever travel is not correct, loosen the jamnut (102) and adjust the front throttle stopscrew (103) to line up the holes.</p>
-------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:


- 7. TACHOMETER
- 23. SLOW SWITCH
- 48. THROTTLE LEVER
- 50. THROTTLE SHAFT
- 51. FUEL PUMP MAIN HOUSING

- 101. LEVEL AND ANGLE INDICATOR
- 102. JAMNUT
- 103. FRONT THROTTLE STOPSCREW
- 116. THROTTLE LEVER TRAVEL TEMPLATE 3375355

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
j. Fuel Pump Idle Speed Check		
75. Selector valve (36)	Turn to IDLE position.	
76. Fuel pump assembly (71)	Run at 500 rpm.	
77. Throttle lever (48)	Hold at idle position.	Pressure reading on fuel pressure gauge (2) should be 32 psi (220 kPa). If fuel pressure is incorrect, do step 78. If fuel pressure is correct, go to step 79.
78. Governor spring pack housing (43)	Using fuel pump idle adjusting tool (90), turn idle adjusting screw in housing (43) until proper fuel pressure is obtained.	Turn fuel pump idle adjusting tool (3375981) (90) clockwise to raise fuel pressure or counterclockwise to lower fuel pressure. If adjusting screw bottoms out, stop the test stand, remove the housing (43), and add washers to spring end of screw.
79. Fuel pump idle adjusting tool (90)	Depress stop button (24) and disengage from governor spring pack housing (43).	Reinstall plug (89) after adjusting tool (90) has been removed.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- 2. FUEL PRESSURE GAUGE
- 24. STOP BUTTON
- 36. SELECTOR VALVE
- 43. GOVERNOR SPRING PACK HOUSING

- 48. THROTTLE LEVER
- 71. FUEL PUMP ASSEMBLY
- 89. PLUG
- 90. FUEL PUMP IDLE ADJUSTING TOOL


3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

k. Fuel Pump Main Pressure Adjustment

80. Selector valve (36)	Turn to ROTAMETER position.	
81. Fast button (25)	Depress until pump speed is at 2100 rpm as indicated on tachometer (7).	Pressure gauge (8) must be maintained at 50.00 in. Hg. (180,000 kPa).
82. Flow control valve (37)	Adjust until exactly 470 pph is indicated by the flowmeter glass tube (38).	Pressure indicated on the fuel pressure gauge (8) should be 157 psi (1082 kPa) at 470 pph. If pressure is not correct, perform steps 82 through 84. If pressure is correct, go to step 85.
83. Throttle shaft (50)	Remove throttle ball (104) if not already removed.	Center punch and drill out with 1/4-in. drill bit. Be careful when drilling so bore of throttle shaft (50) does not get damaged. Discard throttle ball (104).
84. Throttle shaft internal fuel adjusting screw (105)	Adjust until proper fuel pressure is obtained.	Turn adjusting screw (105) counterclockwise to increase pressure or clockwise to decrease pressure. If torque required to turn adjusting screw (105) is less than 100-112 lb-in. (11-12 N•m), a new screw should be installed.
85. Throttle shaft (50)	Install new throttle ball (104) with throttle ball installation tool (106).	Throttle ball installation tool (106) is part of AFC fuel pump adjusting tool kit (3375189). Recheck governor cutoff rpm, steps 50 through 56, after making main pressure adjustment.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- | | |
|--------------------------|---------------------------------------------------|
| 7. TACHOMETER | 50. THROTTLE SHAFT |
| 8. PRESSURE GAUGE | 104. THROTTLE BALL |
| 25. FAST BUTTON | 105. THROTTLE SHAFT INTERNAL FUEL ADJUSTING SCREW |
| 36. SELECTOR VALVE | 106. THROTTLE BALL INSTALLATION TOOL |
| 37. FLOW CONTROL VALVE | |
| 38. FLOWMETER GLASS TUBE | |

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


I. Calibration Check Points

NOTE

There are two calibration check points. Steps 86 through 88 are for calibration check point No. 1 which checks torque spring accuracy. Steps 89 through 92 are for calibration check point No. 2 which checks weight-assist plunger.

86. Slow switch (23)	Depress until 1300 rpm is indicated on tachometer (7).	Throttle lever (48) should be held at full-throttle position.
87. Flow control valve (37)	Adjust until fuel flow through flowmeter glass tube (38) is exactly 380 pph as indicated by float in tube.	
88. Fuel pressure gauge (2)	Check fuel pressure reading. (See Table 3-8; check point 1 for both Big Cam I and Big Cam III fuel pumps, based on their CPLs.) Before performing steps 89 and 91, use values shown.	Proper reading should be between 109 and 115 psi (751 and 793 kPa) at 380 pph fuel flow. If reading is correct, go to step 91. If pressure reading is above or below desired range, do steps 91 through 94 and repeat steps 86 through 89. If pressure reading is still above or below desired range, do step 90.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- 2. FUEL PRESSURE GAUGE
- 7. TACHOMETER
- 23. SLOW SWITCH

- 37. FLOW CONTROL VALVE
- 38. FLOWMETER GLASS TUBE
- 48. THROTTLE LEVER




3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

I. Calibration Check Points (Contd)

89. Front cover (53) and governor plunger (107)	a. Stop test stand (1) and remove cover (53) and plunger (107).	Refer to para. 3-61 for removal.
	b. Check torque spring (108) and shims (109).	Incorrect spring may have been used or spring may be improperly seated or shimmed. Install correct spring and shims as needed. Torque spring shims are available in 0.005, 0.010, and 0.020 in. (0.127, 0.254 and 0.508 mm) thickness. If new torque spring or shims are installed, recalibrate pump.
	c. Install cover (53) and plunger (107) and start test stand (1).	Refer to para. 3-61 for installation.
90. Slow switch (23) and fast button (25)	Depress and release until pump speed is at 1000 rpm as indicated on tachometer (7).	Throttle lever (48) should still be in full-throttle position.
91. Flow control valve (37)	Adjust until fuel flow through flowmeter glass tube (38) is exactly 300 pph as indicated by float in tube.	
92. Fuel pressure gauge (2)	Check fuel pressure reading. (See Table 3-8 for Big Cam I fuel pump values only).	Proper reading should be between 73 and 81 psi (503 and 558 kPa) at 300 pph fuel flow. If pressure reading is incorrect, do step 93. If pressure reading is correct, go to step 94.
93. Front cover (53) and weight-assist plunger (110)	a. Stop test stand (1) by depressing stop button (24) and remove front cover (53) and weight-assist plunger (110).	Refer to para. 3-61 for removal.
	b. Add or remove shim (114) until correct fuel pressure reading is obtained.	Add shims to increase pressure and remove shims to decrease pressure. Shims are available in 0.007 and 0.015 in. (0.177 and 0.381 mm) thickness.
	c. Install front cover (53) and weight-assist plunger (110). Start test stand (1) by depressing start button (26) and repeat calibration beginning with step 54.	Refer to para. 3-61 for installation.

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:


- 1. TEST STAND
- 2. FUEL PRESSURE GAUGE
- 7. TACHOMETER
- 23. SLOW SWITCH
- 24. STOP BUTTON
- 25. FAST BUTTON
- 26. START BUTTON
- 37. FLOW CONTROL VALVE

- 38. FLOWMETER GLASS TUBE
- 48. THROTTLE LEVER
- 53. FRONT COVER
- 107. GOVERNOR PLUNGER
- 108. TORQUE SPRING
- 109. SHIM (3)
- 110. WEIGHT-ASSIST PLUNGER
- 114. SHIM (3)

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
m. AFC Plunger Setting Procedures		
94. Selector valve (36)	Ensure it is set at ROTAMETER position.	Throttle lever (48) should remain at full position.
95. No-air adjusting screw (111) and locknut (112)	Using no-air adjusting tool (113), loosen locknut (112) and turn no-air adjusting screw (111) until it bottoms on fuel pump main housing (51).	No-air adjusting tool (113) is part of AFC fuel pump adjusting tool kit (3375189). All adjustments to the AFC plunger setting must be made when the no-air adjusting screw (111) is bottomed on the main housing (51). Also ensure that the AFC plunger threads are sealed with liquid thread sealant.
96. Fast button (25)	Depress until pump speed is 1600 rpm as indicated on tachometer (7).	
97. Pressure regulator (9)	Adjust to reduce air pressure reading on pressure gauge (8) to 10.00 in. Hg. (36,000 kPa).	

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- | | |
|-----------------------|-----------------------------|
| 7. TACHOMETER | 48. THROTTLE LEVER |
| 8. PRESSURE GAUGE | 51. FUEL PUMP MAIN HOUSING |
| 9. PRESSURE REGULATOR | 111. NO-AIR ADJUSTING SCREW |
| 25. FAST BUTTON | 112. LOCKNUT |
| 36. SELECTOR VALVE | 113. NO-AIR ADJUSTING TOOL |

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

m. AFC Plunger Setting Procedures (Contd)

98. Flowmeter glass tube (38) Allow fuel to escape until float in tube stabilizes at or near zero.

NOTE

Air pressure during AFC plunger setting procedures must always be reached while increasing air pressure on the AFC bellows. If specified pressure reading is overshoot, reduce the pressure to 0 in. Hg. (0 kPa) on fuel pressure gauge (2), and wait until the fuel flow stabilizes at or near zero in flowmeter glass tube before increasing or decreasing the setting.

99. Pressure regulator (9) Adjust to increase air pressure reading on pressure gauge (8) to exactly 10.00 in. Hg. (36,000 kPa).

100. Flow control valve (37) Adjust until fuel flow through flowmeter glass tube (38) is exactly 385 pph as indicated by float in tube.

CAUTION

- The AFC adjusting tool must be used with care. The large movable center hex socket engages the nut that retains the AFC bellows to the plunger. Use a hex-head socket wrench to move the plunger in and out to attain the proper adjustment.
- If large hex socket is not properly engaged, the AFC bellows can be torn or ripped. The proper sequence is to first engage the large hex socket, then the smaller hex socket, and finally the hex-head socket wrench.

NOTE

If adjustment is required, reduce air pressure to 9 psi (62 kPa).

101. AFC adjusting tool (91)	a. Using adjusting tool, adjust fuel pressure reading on fuel pressure gauge (2) to a reading of 83-87 psi (572-599 kPa).	AFC adjusting tool (91) is part of AFC fuel pump adjusting tool kit (3375189). During this adjustment, it may be necessary to adjust the flow control valve (37) to maintain the fuel flow rate of 385 pph. Use extreme care; fuel flow rate must be maintained during tightening to an approximate value of 25-35 lb-in. (2.8-3.9 N•m).
------------------------------	---------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

CAUTION

The AFC plunger can be very easily broken when tightening the jamnut. Use extreme care when tightening three jamnuts to the required 25-35 lb-in. (2.8-3.9 N•m) torque. The large and small hex sockets must be fully retracted after loosening the plunger jamnut to avoid interfering with the AFC piston travel. If the AFC piston position is disturbed while adjusting the plunger, repeat the entire adjustment sequence (steps 94 through 101).


3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

m. AFC Plunger Setting Procedures (Contd)

101. AFC adjusting tool (91)
(Contd)

- b. When AFC control plunger adjustment is correct, use adjusting tool (91) to tighten jamnut to 25-35 lb-in. (2.8-3.9 N•m).
- c. Carefully recheck fuel pressure on the fuel pressure gauge (2) and fuel flow on flowmeter glass tube (38) to ensure they have remained within specified limits.

Fuel pressure gauge (2) should read 83-87 psi (572-599 kPa) and flowmeter glass tube (38) should read 385 pph.



LEGEND:


- 2. FUEL PRESSURE GAUGE
- 8. PRESSURE GAUGE
- 9. PRESSURE REGULATOR

- 37. FLOW CONTROL VALVE
- 38. FLOWMETER GLASS TUBE
- 91. AFC ADJUSTING TOOL

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
n. No-Air Screw		
102. Slow switch (23) and fast button (25)	Depress and release until pump speed is 1600 rpm as indicated on tachometer (7).	Throttle lever (48) should be held at full-throttle position. Air pressure reading on pressure gauge (8) should be 0.00 in. Hg. (0 kPa).
103. Selector valve (36)	Ensure it is set to ROTAMETER position.	
104. No-air adjusting screw (111) and locknut (112)	a. Loosen locknut (112). b. Using no-air adjustment tool (113), adjust no-air adjusting screw (111) until 39 psi (268 kPa) fuel pressure is indicated on fuel pressure gauge (2). c. When proper adjustment has been reached, tighten locknut (112).	Fuel flow of 220 pph must be maintained during this adjustment. Reset flow control valve (37) as necessary to maintain 220 pph.
105. Slow switch (23) and stop button (24)	When all calibration checks have been completed, slow down test stand (1) to minimum speed, then stop test stand.	

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:


- 1. TEST STAND
- 2. FUEL PRESSURE GAUGE
- 7. TACHOMETER
- 8. PRESSURE GAUGE
- 23. SLOW SWITCH
- 24. STOP BUTTON
- 25. FAST BUTTON

- 36. SELECTOR VALVE
- 37. FLOW CONTROL VALVE
- 48. THROTTLE LEVER
- 111. NO-AIR ADJUSTING SCREW
- 112. LOCKNUT
- 113. NO-AIR ADJUSTMENT TOOL

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
o. Removing Fuel Pump From Test Stand		
106. AFC adjusting tool (91)	Remove from fuel pump main housing (51).	
107. AFC cover plate (42) and restrictor (41)	a. Install on fuel pump main housing (51). b. Secure with three screws (115).	Bottom screw (115) should have a hole drilled in it. Tighten screws (115) to 30-45 lb-in. (3.3-5.0 N•m).
108. All hoses	Remove from fuel pump assembly (71) and test stand (1).	
109. Check valve (39)	Remove from fuel pump main housing (51).	
110. Tee fitting (85)	Remove from bleed drain fitting (87).	
111. Pump discharge fitting assembly (80)	Remove from shutdown solenoid valve (40).	
112. Inlet adapter assembly (75)	Remove from gear pump (47).	
113. Throttle lever (48) and adapter ring (67)	Remove spring.	
114. Fuel pump assembly (71), adapter ring (67), and adapter bracket (66)	a. Remove from test stand (1). b. Separate.	

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- | | |
|-----------------------------|-------------------------------------|
| 1. TEST STAND | 67. ADAPTER RING |
| 39. CHECK VALVE | 71. FUEL PUMP ASSEMBLY |
| 40. SHUTDOWN SOLENOID VALVE | 75. INLET ADAPTER ASSEMBLY |
| 41. RESTRICTOR | 80. PUMP DISCHARGE FITTING ASSEMBLY |
| 42. AFC COVER PLATE | 85. TEE FITTING |
| 47. GEAR PUMP | 87. BLEED DRAIN FITTING |
| 48. THROTTLE LEVER | 91. AFC ADJUSTING TOOL |
| 51. FUEL PUMP MAIN HOUSING | 115. SCREW |
| 66. ADAPTER BRACKET | |

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

o. Removing Fuel Pump from Test Stand (Contd)

115. Test stand coupling insert (74)	Remove from test stand (1).	
116. Throttle shaft cover (52) and two screws (49)	Do not install on fuel pump main housing (51) at this time.	Throttle shaft cover (52) must be removed to perform on-engine fuel pump adjustment. A cover will be installed after on-engine fuel adjustment has been made.
117. Throttle lever (48)	a. Remove from throttle shaft (50). b. Installed on throttle shaft (50) in on-engine operating position.	

- FOLLOW-ON TASKS:
- Install fuel pump (para. 3-78).
 - Perform on-engine fuel pump adjustment (para. 3-93).

3-63. FUEL PUMP TESTING AND CALIBRATION (Contd)



LEGEND:

- 1. TEST STAND
- 48. THROTTLE LEVER
- 49. SCREW (2)
- 50. THROTTLE SHAFT

- 51. FUEL PUMP MAIN HOUSING
- 52. THROTTLE SHAFT COVER
- 74. TEST STAND COUPLING INSERT

3-64. WATER PUMP REPAIR

THIS TASK COVERS:

- a. Disassembly
- b. Cleaning

- c. Inspection
- d. Assembly

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

- Bearing disassembly fixture (15434) ST-1114
- Seal wear sleeve mandrel (15434) ST-1159
- Water pump bearing mandrel (15434) ST-658
- Oil seal driver (15434) ST-1191
- Puller (15434) 3375265
- Oil seal pilot (15434) 3375180
- Water pump seal mandrel (15434) 3375448

TEST EQUIPMENT

None

MATERIALS/PARTS

- Loctite (Appendix C, Item 14)
- Oil, lubricating, OE/HDO 10 (Appendix C, Item 20)
- Solvent, SD-3 (Appendix C, Item 30)
- Sealant, thread (liquid) (Appendix C, Item 27)
- Gasket (15434) 3038997
- Seat and seal assembly (15434) 3028294
- Six lockwashers (15434) S604
- Prefomed packing (15434) 145506
- Gasket and seal kit (15434) 3801350 (M915/Big Cam I)
- Gasket and seal kit (15434) 3801235 (M915A1/Big Cam III)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

- TM 9-2320-273-20
- TM 9-2320-283-20

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Water pump removed (TM 9-2320-273-20 or TM 9-2320-283-20).

SPECIAL ENVIRONMENTAL CONDITIONS

None

GENERAL SAFETY INSTRUCTIONS


- Always wear eye protection when using compressed air.
- Use approved solvent in well-ventilated area and away from open flame.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly

1. Screw (15), shaft (24), nut (17), and washer (18)	Remove.	
2. Pulley (13) and impeller (2)	Remove from shaft (7).	Use puller (3375265).
3. Seal (12)	Remove from water pump assembly (1).	Discard seal (12). Use a prybar for easy removal.
4. Retaining ring (11)	Remove from water pump assembly (1).	
5. Shaft (7) and two bearings (8)	Remove from water pump assembly (1).	To remove, push on shaft (7) from impeller (2) side of pump assembly (1).
6. Seat and seal assembly (3) and gasket (6)	Remove.	Use a drift punch to push parts out. Discard seat and seal assembly (3) and gasket (6).

3-64. WATER PUMP REPAIR (Contd)




LEGEND:

- | | |
|---------------------------|-----------------------|
| 1. WATER PUMP ASSEMBLY | 14. BEARING |
| 2. IMPELLER | 15. SCREW |
| 3. SEAT AND SEAL ASSEMBLY | 16. GASKET |
| 4. PIPE PLUG (2) | 17. NUT |
| 5. PIPE PLUG | 18. WASHER |
| 6. GASKET | 19. SEAL |
| 7. SHAFT | 20. RETAINING RING |
| 8. BEARING (2) | 21. SPACER |
| 9. RETAINING RING | 22. PREFORMED PACKING |
| 10. SPACER | 23. BEARING |
| 11. RETAINING RING | 24. SHAFT |
| 12. SEAL | 25. PULLEY |
| 13. PULLEY | 26. PIPE PLUG |

3-64. WATER PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
a. Disassembly (Contd)		
7. Bearing (8) and spacer (10)	Remove from shaft (7).	The outer bearing (8) is removed first. Use bearing disassembly fixture (ST-1114) for removal of bearing (8).
8. Retaining ring (9)	Remove from shaft (7).	
9. Bearing (8)	Remove from shaft (7).	The inner bearing (8) nearest the impeller (2) is removed next. Use bearing disassembly fixture (ST-1114) for removal of bearing (8).
10. Spacer (21)	Remove from shaft (24) by lightly tapping shaft (24) with plastic hammer.	Hold spacer (21) in the jaws of a vise with copper protector plates to prevent damage.
11. Seal (19)	Remove from pulley (25).	Use round end of prybar. Discard seal (19).

3-64. WATER PUMP REPAIR (Contd)



LEGEND:

- | | |
|------------------------|------------|
| 1. WATER PUMP ASSEMBLY | 10. SPACER |
| 2. IMPELLER | 19. SEAL |
| 7. SHAFT | 21. SPACER |
| 8. BEARING (2) | 24. SHAFT |
| 9. RETAINING RING | 25. PULLEY |

3-64. WATER PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Disassembly (Contd)


12. Retaining ring (20)	Remove from shaft (24).	
13. Prefomed packing (22)	Remove and discard.	
14. Bearing (23) and pipe plug (26)	Remove from pulley (25).	Hold pulley (25) in vise and lightly hit bearing (23) with flat punch through hole for pipe plug (26).
15. Bearing (23) and shaft (24)	Separate.	Use a press and mandrel (ST-658).
16. Two pipe plugs (4) and pipe plug (5)	Remove.	

b. Cleaning**WARNING**

- Compressed air used for cleaning purposes will not exceed 30 psi (207 kPa). Use only with effective chip guarding and protective equipment such as goggles or shield, gloves, etc. Failure to comply may result in injury to personnel.
- Approved solvents may be flammable and will not be used near open flame. Use only in well-ventilated area. Failure to comply may result in injury to personnel.

17. Gasket (16)	Scrape from mounting surface of water pump housing.	
18. All other parts	Clean and dry with compressed air.	Use SD-3 solvent.

3-64. WATER PUMP REPAIR (Contd)



LEGEND:


- 4. PIPE PLUG (2)
- 5. PIPE PLUG
- 16. GASKET
- 20. RETAINING RING
- 22. PREFORMED PACKING

- 23. BEARING
- 24. SHAFT
- 25. PULLEY
- 26. PIPE PLUG

3-64. WATER PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
c. Inspection		
19. Two bearings (8) and bearing (23)	Inspect for wear and damage.	Replace if worn or damaged.
20. Shaft (7) and shaft (24)	Inspect for: a. Wear on outside diameter of bearing surfaces. b. Straightness and damage. c. Measure impeller (2) end of shaft (7).	Replace if worn or damaged. Replace if bent or damaged. Outside diameter of impeller (2) end of shaft (7) should be 0.001 in. (0.025 mm) bigger than bore of impeller (2). Replace shaft (7) if less than 0.001 in. (0.025 mm).
21. Impeller (2)	a. Inspect for cracks, corrosion, or wear. b. Measure the bore.	Replace if cracked, corroded, or worn. Refer to step 20c.

3-64. WATER PUMP REPAIR (Contd)



LEGEND:


- 2. IMPELLER
- 7. SHAFT
- 8. BEARING (2)

- 23. BEARING
- 24. SHAFT

3-64. WATER PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
c. Inspection (Contd)		
22. Water pump assembly (1)	Inspect for the following: a. Cracks in housing. b. Bearing bore diameter. c. Weep hole is open.	Replace if cracked. Discard the housing if bearing bore is larger than 2.4494 in. (62.2148 mm). Hole directly below bearing bore.
23. Bearing (14)	Inspect for wear or damage.	Replace if damaged or worn. Replacement is covered in step 41.
24. Pulley (13) and pulley (25)	Inspect the following: a. Pulley grooves for wear or damage. b. Bore diameters.	Replace if worn or damaged. There must be at least 0.001 in. (0.025 mm) press fit between pulley bores and outside diameter of shaft (7) and shaft (24).

3-64. WATER PUMP REPAIR (Contd)



LEGEND:

- 1. WATER PUMP ASSEMBLY
- 7. SHAFT
- 13. PULLEY

- 14. BEARING
- 24. SHAFT
- 25. PULLEY

3-64. WATER PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly

25. Shaft (24)	a. Install bearing (23) on shaft (24).	Apply a thin coat of OE/HDO 10 lubricating oil to shaft (24) for easier installation. Use water pump bearing mandrel (ST-658).
----------------	----------------------------------------	--------------------------------------------------------------------------------------------------------------------------------

CAUTION

Ensure Loctite does not migrate to inside diameter of bearing. Bearing failure could result.


	b. Install on pulley (25).	Use suitable press and water pump bearing mandrel (ST-658). Apply a light coat of Loctite to outside diameter of bearing (23) before installation. Press until it bottoms.
--	----------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------

26. Retaining ring (20)	Install on shaft (24).	Install flat side of retaining ring (20) toward bearing (23).
-------------------------	------------------------	---------------------------------------------------------------

CAUTION

Prior to installing the pipe plug, install a grease fitting and lubricate until you can see the grease through the bearing. Remove the grease fitting and install the pipe plug.

3-64. WATER PUMP REPAIR (Contd)



LEGEND:


- 20. RETAINING RING
- 23. BEARING

- 24. SHAFT
- 25. PULLEY

3-64. WATER PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
d. Assembly (Contd)		
27. Pipe plug (26)	Install on pulley (25).	Coat pipe plug (26) with liquid thread sealant prior to installation.
28. New seal (19)	Install on pulley (25).	Install lip of new seal (19) toward pulley (25). Use oil seal driver (ST-1191) and oil seal pilot (3375180).
29. New preformed packing (22)	Install on shaft (24).	Lubricate new preformed packing (22) with OE/HDO 10 lubricating oil prior to installing.
30. Spacer (21)	Install on shaft (24).	Push until spacer (21) is against bearing (23). Pulley (25), with assembled parts, should be set aside for later use.
31. New gasket (6)	Install on water pump assembly (1).	Use oil seal driver (ST-1191) and oil seal pilot (3375180). Install lip of seal toward oil seal driver (ST-1191). Push new gasket (6) until at bottom of bore.
32. Bearing(8)	Install on shaft (7).	Apply a film of OE/HDO 10 lubricating oil to shaft (7) for easier installation. Use water pump bearing mandrel (ST-658) for installation.

3-64. WATER PUMP REPAIR (Contd)



LEGEND:

- 1. WATER PUMP ASSEMBLY
- 6. GASKET
- 7. SHAFT
- 8. BEARING (2)
- 19. SEAL
- 21. SPACER

- 22. PREFORMED PACKING
- 23. BEARING
- 24. SHAFT
- 25. PULLEY
- 26. PIPE PLUG

3-64. WATER PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

d. Assembly (Contd)

- 33. Retaining ring (9) Install on shaft (7).

CAUTION

To prevent damage to the ball bearing, make sure the inner face of the ball bearing is not pressed tight against the bearing spacer.


- 34. Spacer (10) and bearings (8) Install on shaft (7).
Use water pump bearing mandrel (ST-658). Make sure bearings (8) turn freely after installation.

CAUTION

Ensure Loctite does not migrate to inside diameter of bearing. Bearing failure could result.

- 35. Two bearings (8) and shaft (7) Install in bore of water pump assembly (1).
Apply a thin coat of Loctite to outer surface of two bearings (8). Use water pump bearing mandrel (ST-658). Press on impeller end of shaft (7).
- 36. Retaining ring (11) Install on shaft (7).
Install flat side of retaining ring (11) toward bearings (8).

3-64. WATER PUMP REPAIR (Contd)



LEGEND:

- 1. WATER PUMP ASSEMBLY
- 7. SHAFT
- 8. BEARING (2)

- 9. RETAINING RING
- 10. SPACER
- 11. RETAINING RING

3-64. WATER PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


d. Assembly (Contd)

CAUTION

Prior to installing the pipe plugs in the bearing bore of the water pump assembly, install a grease fitting and lubricate the ball bearings until you can see grease through the outer ball bearing.

37. Two pipe plugs (4)	Install on water pump assembly (1).	Coat with liquid thread sealant.
38. Pipe plug (5)	Install on water pump assembly (1).	Coat with liquid thread sealant.
39. New seal (12)	Install on water pump assembly (1).	Lip of new seal (12) must be toward bearings (8) and installed even with top edge of bore. Use oil seal driver (ST-1191) and oil seal pilot (3375180).
40. New seat and seal assembly (3)	Install on water pump assembly (1).	Coat brass part of outside diameter with Loctite. Apply one drop only of Loctite between new seat and seal assembly (3) and shaft (7). Use water pump seal mandrel (3375448).

3-64. WATER PUMP REPAIR (Contd)



LEGEND:

- 1. WATER PUMP ASSEMBLY
- 3. SEAT AND SEAL ASSEMBLY
- 4. PIPE PLUG (2)
- 5. PIPE PLUG


- 7. SHAFT
- 8. BEARING (2)
- 12. SEAL

3-64. WATER PUMP REPAIR (Contd)

LOCATION/ITEM	ACTION	REMARKS
d. Assembly (Contd)		
41. Bearing (14)	Install on pulley (13).	Use oil seal driver (ST-1191) for installation.
42. Pulley (13) and bearing (14)	Install on shaft (7).	Apply a light coat of Loctite to the bore of pulley (13). Use suitable press and install until pulley (13) is against large diameter of shaft (7).
43. Impeller (2)	Install on shaft (7).	Apply a light coat of Loctite to the bore of impeller (2). Check clearance after installation; should be 0.020-0.040 in. (0.508-1.016 mm).
44. Pulley (25) with assembled parts	a. Install on water pump assembly (1). b. Secure with screw (15), washer (18), and nut (17).	

FOLLOW-ON TASK: Install water pump (TM 9-2320-273-20 or TM 9-2320-283-20).

3-64. WATER PUMP REPAIR (Contd)



LEGEND:

- 1. WATER PUMP ASSEMBLY
- 2. IMPELLER
- 7. SHAFT
- 13. PULLEY
- 14. BEARING

- 15. SCREW
- 17. NUT
- 18. WASHER
- 25. PULLEY

Section IV. ASSEMBLY

3-65. GENERAL

a. This section provides maintenance procedures for assembly of subassemblies, installation of major components, and removal of engine from maintenance stand. These procedures are for the engine removed from the vehicle.

b. In cases where it may only be necessary, or more time efficient, to assemble the engine while installed in vehicle, follow the applicable portions of the tasks contained in this section to install the part or component.

c. In the task summary listed below, a complete list of special tools, test equipment, materials, parts, and related information required to perform a complete engine assembly is provided. To find a specific engine assembly procedure contained in this section, see list of tasks.

3-66. TASK SUMMARY**INITIAL SETUP:****APPLICABLE MODELS**

All

SPECIAL TOOLS

Piston ring expander (15434) ST-763
 Two connecting rod guide pins (15434) 3375601
 Piston ring compressor (15434) 3375162
 Oil seal installer (15434) ST-1259
 Oil seal expander (15434) 3375151
 Fuel pump drive oil seal mandrel (15434) ST-1173
 Pulley installation assembly tool (15434) 3376326
 Air compressor wrench (15434) 3375159
 Crankshaft rear oil seal driver (15434) ST-997
 Dial gauge attachment (15434) ST-1325
 Dial indicator and sleeve assembly (15434) 3376050
 Injector puller (15434) 3375161
 Torque wrench adapter (15434) ST-669

TEST EQUIPMENT

Injection timing fixture (15434) 3375522

MATERIALS/PARTS

Oil, lubricating, OE/HDO 30 (Appendix C, Item 21)
 Oil, lubricating gear, 60-80/140 (Appendix C, Item 22)
 Lubricant, high-pressure (Appendix C, Item 15)
 Lubricant, rust preventative (Appendix C, Item 16)
 Sealant, pipe (Appendix C, Item 26)
 Solvent, SD-3 (Appendix C, Item 30)
 Grease, GAA (Appendix C, Item 13)
 Oil, lubricating, OE/HDO 10 (Appendix C, Item 20)

Compound, antiseize (Appendix C, Item 7)

MATERIALS/PARTS (Contd)

Sealant, thread (liquid) (Appendix C, Item 27)
 Main bearing set, standard: (15434) AR-7110
 0.010 under: (15434) AR-711
 0.020 under: (15434) 157282
 Thrust ring, standard: (15434) 157280
 0.010 under: (15434) 157281
 0.020 under: (15434) 157282
 Piston ring set (15434) 3014149
 Cam follower housing gasket (15434) 3020000
 Cam follower housing gasket (as required) (15434) 3020001,3020002, 3020003,3020004
 Cylinder head gasket (15434) 3001667
 Four O-ring seals (15434) 131026
 Housing gasket (15434) 200809
 Pump mounting gasket (15434) 3031434
 Crankshaft oil seal (15434) 3006736
 Accessory drive oil seal (15434) 3004316
 Compressor gasket (15434) 3005962
 Four lockwashers (15434) S-609
 Fuel pump mounting gasket (15434) 200817
 Rear cover gasket (15434) 40662-A
 Rear main seal (15434) 211253
 Suction tube gasket (15434) 157551
 Oil pan gasket (15434) 3027983
 O-ring seal (15434) 3029846
 O-ring seal (15434) 3029847
 Gasket, rocker housing (15434) 3017750
 Gasket, brake housing (75078) 010279
 Three intake manifold gaskets (15434) 3008591
 Three lockwashers (15434) S-602
 Two water header cover gaskets (15434) 70089-1
 Six piston cooling nozzle O-rings (15434) 3007442
 Support gasket (15434) 3031858
 Two grommets (15434) S-1003-A
 Six exhaust manifold gaskets (15434) 3020943
 Turbocharger mounting gasket (15434) 190849

3-66. TASK SUMMARY (Contd)

INITIAL SETUP (Contd):

Cover gasket (15434) 65274

Refer to specific paragraph for this information.

PERSONNEL REQUIRED

Automotive repairman MOS 63H

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dust and dirt.

REFERENCES (TM)

None

GENERAL SAFETY INSTRUCTIONS

Engine components are heavy. Use extreme caution during assembly to prevent injury to personnel and/or damage to equipment.

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

List of Tasks

TASK PARA.	PROCEDURES	TASK REF.	TROUBLESHOOTING REF. NO. (PARA.)
1.	Cylinder Liner Installation	3-67	2-8
2.	Engine Crankshaft and Main Bearings Installation	3-68	2-8
3.	Piston, Connecting Rod, and Bearing Installation	3-69	2-8
4.	Camshaft and Cam Followers Installation	3-70	2-8
5.	Cylinder Head Assembly and Pushrods Installation	3-71	2-8
6.	Injection Timing	3-72	2-8
	a. Setup	3-72a	
	b. Injection Timing Cylinder No. 1	3-72b	
	c. Changing Injection Timing	3-72c	
	d. Injection Timing Cylinder No. 3	3-72d	
	e. Injection Timing Cylinder No. 5	3-72e	
7.	Accessory Drive Housing Assembly Installation	3-73	2-8
8.	Oil Pump Installation	3-74	2-8
9.	Front Gear Cover Installation	3-75	2-8
10.	Accessory Drive Pulley Installation	3-76	2-8
11.	Air Compressor Installation	3-77	2-8
12.	Fuel Pump Installation	3-78	2-8
13.	Vibration Damper and Crankshaft Pulley Installation	3-79	2-8
14.	Flexplate or Flywheel, Flywheel Housing, and Rear Cover Installation	3-80	2-8
15.	Oil Pan Installation	3-81	2-8
16.	Injector Assembly Installation	3-82	2-8

3-66. TASK SUMMARY (Contd)

List of Tasks (Contd)

TASK PARA.	PROCEDURES	TASK REF.	TROUBLESHOOTING REF. NO. (PARA.)
17.	Valve Crossheads Installation and Adjustment	3-83	2-8
	a. Installation	3-83a	
	b. Adjustment	3-83b	
18.	Rocker Arm Housing Assembly Installation	3-84	2-8
19.	Injector and Valve Adjustment	3-85	2-8
20.	Engine Retarder Installation	3-86	2-8
	a. Installation	3-86a	
	b. Slave Piston Adjustment	3-86b	
21.	Air Aftercooler Installation	3-87	2-8
22.	Removing Engine from Maintenance Stand	3-88	2-8
	a. Removal from Maintenance Stand	3-88a	
	b. Component Installation	3-88b	

3-67. CYLINDER LINER INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Oil, lubricating, OE/HDO 30
(Appendix C, Item 21)
Oil, lubricating, gear 60-80/140
(Appendix C, Item 22)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Cylinder liners removed (para. 3-30).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


Installation

NOTE

- Installation of cylinder liners is carried out during cylinder block repair. This is necessary to check cylinder liner counterbore diameter, depth, protrusion, sealant application procedure, and type of packing ring lubricant used.
- Refer to para. 3-34, Cylinder Block Repair, for complete installation procedure of cylinder liners.

FOLLOW-ON TASK: Install engine crankshaft and main bearings (para. 3-68).

3-67. CYLINDER LINER INSTALLATION (Contd)



LEGEND:

- 1. CYLINDER LINER
- 2. CYLINDER LINER SHIM (IF REQUIRED)
- 3. GASKET (CREVICE SEAL)

- 4. BLACK PACKING RING
- 5. RED PACKING RING
- 6. CYLINDER BLOCK

3-68. ENGINE CRANKSHAFT AND MAIN BEARINGS INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Oil, lubricating, OE/HDO 30
(Appendix C, Item 21)

Oil, lubricating, gear 60-80/140
(Appendix C, Item 22)

Fourteen lockplates (15434) 140218

Main bearing set

Standard: (15434) 3801260

0.010 Under: (15434) 3801261

0.020 Under: (15434) 3801262

Four thrust bearing washers

Standard: (15434)

0.010 Over: (15434)

0.020 Over: (15434)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Engine crankshaft and main bearings removed
(para. 3-31).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

Use extreme caution during assembly; engine components are heavy.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation

CAUTION


- The cylinder block saddle and cap mating surfaces must be clean and dry when bearing halves are installed or engine damage may result.
- Wipe main bearing bores, main bearings, engine crankshaft, and related parts with a clean cloth. Ensure cloth does not leave any particles or lint in or on parts and bores or engine damage may result.

NOTE

- The upper main bearings have a groove and oil hole to permit lubrication of engine crankshaft; the lower main bearing halves do not. The upper main bearings for No. 2, 4, and 6 are the same. The groove in upper main bearing half for No. 7 is not in the center. Install the No. 7 main bearing so wider part of bearing (from groove) is toward flywheel end of the cylinder block. Each main bearing has a groove. Install main bearings so grooves will fit retaining rings.
- Check for marks on crankshaft to determine size of main bearings and thrust rings. If there are no marks, use standard-size parts.

3-68. ENGINE CRANKSHAFT AND MAIN BEARINGS INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
1. Seven new upper main bearing halves (2)	Install on cylinder block (1).	Lubricate main bearing contact surface with OE/HDO 30 lubricating oil.
2. Seven retaining rings (3)	Install on cylinder block (1).	



LEGEND:

- 1. CYLINDER BLOCK
- 2. UPPER MAIN BEARING HALF (7)
- 3. RETAINING RING (7)
- 4. CRANKSHAFT
- 5. THRUST BEARING WASHER (2)

- 6. LOWER MAIN BEARING HALF (7)
- 7. NO. 7 BEARING CAP
- 8. BEARING CAP (6)
- 9. LOCKPLATE (14)
- 10. SCREW (14)

3-68. ENGINE CRANKSHAFT AND MAIN BEARINGS INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


Installation (Contd)

WARNING

Use extreme caution during assembly; engine components are heavy. Failure to comply may result in damage to equipment or injury to personnel.

3. Crankshaft (4)	Install on cylinder block (1).	Assistant will help lift crankshaft (4). Use a suitable lifting device and hooks protected with a rubber hose or a lifting strap to lower crankshaft (4) on cylinder block (1).
4. New upper thrust bearing washers (5)	Roll into position on the No. 7 journal of crankshaft (4).	Ensure grooved thrust side of thrust bearing washers (5) are against the flange of crankshaft (4). The upper thrust rings are not doveled to cylinder block (1). The lower thrust bearing washers (5) are doveled to No. 7 bearing cap.
5. Seven new lower main bearing halves (6)	Install on main bearing journals of crankshaft (4).	Lubricate contact surface of seven lower main bearing halves (6) and main bearing journal surface of crankshaft (4) with OE/HDO lubricating oil prior to installation. Make certain lower main bearing halves (6) are aligned with retaining rings (3).
6. No. 1 through No. 6 bearing caps (8)	Install on cylinder block (1) over crankshaft (4).	Ensure each bearing cap (8) is in its correct location and position.
7. Lower thrust bearing washers (5)	Install on No. 7 bearing cap (7).	The grooved side of two lower thrust bearing washers (5) must be toward flange of crankshaft (4).
8. No. 7 bearing cap (7) with thrust bearing washers (5)	Install on cylinder block (1) over No. 7 main bearing journal of crankshaft (4).	
9. Fourteen screws (10) and new lockplates (9)	Install on bearing caps (7) and (8) on cylinder block (1) finger-tight.	Coat threads with OE/HDO 30 lubricating oil and lockplates (9) with gear 60-80/140 lubricating oil. Allow excess oil to drain off prior to installing screws (10) on cylinder block (1).

3-68. ENGINE CRANKSHAFT AND MAIN BEARINGS INSTALLATION (Contd)



LEGEND:

- 1. CYLINDER BLOCK
- 3. RETAINING RING (7)
- 4. CRANKSHAFT
- 5. THRUST BEARING WASHER (4)
- 6. LOWER MAIN BEARING HALF (7)

- 7. NO. 7 BEARING CAP
- 8. BEARING CAP (6)
- 9. LOCKPLATE (14)
- 10. SCREW (14)

3-68. ENGINE CRANKSHAFT AND MAIN BEARINGS INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------



Installation (Contd)

CAUTION

When striking bearing caps, ensure bearing halves and retaining rings do not move or damage may result.

10. No. 7 bearing cap (7) and No. 1 through No. 6 bearing caps (8)	Strike with rubber mallet to push into position on cylinder block (1).	Ensure dowel pins and thrust bearing washers (5) for No. 7 bearing cap (7) are correctly aligned.
11. Fourteen screws (10)	a. Tighten each screw (10) to 85 lb-ft (115 N•m) at a time in sequence shown until each screw is tightened to 250-260 lb-ft (339-353 N•m). b. Loosen fourteen screws (10) three to five threads or a minimum of three complete turns. c. Repeat step 11a.	

3-68. ENGINE CRANKSHAFT AND MAIN BEARINGS INSTALLATION (Contd)



LEGEND:

1. CYLINDER BLOCK

5. THRUST BEARING WASHER (4)

7. NO. 7 BEARING CAP

8. BEARING CAP (6)

10. SCREW (14)

3-68. ENGINE CRANKSHAFT AND MAIN BEARINGS INSTALLATION (Contd)


LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

<p>12. Crankshaft (4)</p>	<p>a. Use hands to rotate. If crankshaft (4) does not rotate freely, refer to para. 3-37, Engine Crankshaft Repair.</p> <p>b. Install a dial indicator on rear of cylinder block (1) with contact tip resting on crankshaft flange end face.</p> <p>c. Pry crankshaft (4) toward front of cylinder block (1).</p> <p>d. Remove prybar and set dial indicator to zero.</p> <p>e. Pry crankshaft (4) toward rear of the cylinder block (1).</p> <p>f. If clearance is less than 0.007 in., (0.178 mm) proceed as follows:</p> <p style="padding-left: 20px;">(1) Loosen fourteen screws (10) one turn.</p> <p style="padding-left: 20px;">(2) Pry crankshaft (4) toward front and rear of cylinder block (1).</p> <p style="padding-left: 20px;">(3) Tighten fourteen screws (10) according to steps 11 a, b, and c.</p> <p style="padding-left: 20px;">(4) Recheck end clearance.</p> <p>g. If clearance is more than 0.022 in. (0.559 mm), use oversize thrust bearing washers.</p>	<p>Use a suitable prybar.</p> <p>The total end clearance for a new crankshaft (4) and new thrust bearing washers should be 0.007-0.018 in. (0.178-0.457 mm). Maximum clearance for worn parts is 0.022 in. (0.559 mm).</p>
<p>13. Fourteen lockplates (9)</p>	<p>Bend tangs against heads of fourteen screws (10).</p>	

FOLLOW-ON TASK: Install piston, connecting rod, and bearings (para. 3-69).

3-68. ENGINE CRANKSHAFT AND MAIN BEARINGS INSTALLATION (Contd)



LEGEND:

- 1. CYLINDER BLOCK
- 4. CRANKSHAFT

- 9. LOCKPLATE (14)
- 10. SCREW (14)

3-69. PISTON, CONNECTING ROD, AND BEARINGS INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Piston ring expander (15434) ST-763
 Two connecting rod guide pins (15434) 3375601
 Piston ring compressor (15434) 3375162

TEST EQUIPMENT

None

MATERIALS/PARTS

Oil, lubricating, OE/HDO 30
 (Appendix C, Item 21)
 Piston ring set (15434) 3801056

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

- Cylinder liners installed (para. 3-67).
- Crankshaft and main bearings installed (para. 3-68).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


Installation

NOTE

- Use this procedure to install any one of the six piston, connecting rod, and bearings assemblies.
- Parts are not interchangeable. Do not mix parts from one assembly with another.
- Always replace bearing halves in pairs (upper and lower).
- Check for marks on crankshaft to determine bearing size. If there are no marks, use standard-size parts.

1.	Two new compression rings (1) and (3) and two new piston rings (2) and (4)	a. Using piston ring expander (12), install on piston and connecting rod assembly (5). b. Stagger ring gaps so they are not in line with each other or with piston pin.	Use piston ring expander (ST-763). To avoid damaging rings, do not overexpand during installation. Rings should only be expanded enough to allow them to fit over piston. Install rings with word "top" toward top of piston.
2.	Upper rod bearing half (6)	Install on piston and connecting rod assembly (5).	Tang of bearing half (6) must be into slot of connecting rod. Ensure oil hole in bearing half (6) lines up with oil hole in connecting rod.
3.	Lower rod bearing half (6)	Install on connecting rod cap (7).	Tang of bearing half (6) must be into slot of connecting rod cap (7). Cap (7) does not have an oil hole.

3-69. PISTON, CONNECTING ROD, AND BEARINGS INSTALLATION (Contd)



LEGEND:

- 1. COMPRESSION RING
- 2. PISTON RING (COMPRESSION RING)
- 3. COMPRESSION RING
- 4. PISTON RING (OIL CONTROL RING)
- 5. PISTON AND CONNECTING ROD ASSEMBLY
- 6. ROD BEARING HALF (2)

- 7. CONNECTING ROD CAP
- 8. ROD SCREW (2)
- 9. CYLINDER LINER
- 10. CRANKSHAFT
- 11. CYLINDER BLOCK
- 12. PISTON RING EXPANDER


3-69. PISTON, CONNECTING ROD, AND BEARINGS INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

4. Two rod bearing halves (6)	Lubricate with clean lubricating oil.	Use OE/HDO 30 lubricating oil (Appendix C, Item 21).
5. Piston and connecting rod assembly (5)	<p>a. Immerse piston and rings (1), (2), (3), (4), and (5), into container of clean lubricating oil.</p> <p>b. Install two connecting rod guide pins (13).</p> <p>c. Using piston ring compressor (14), compress rings.</p>	<p>Use connecting rod guide pin (3375601).</p> <p>Use piston ring compressor (3375162) (14). Ensure piston rings are correctly located in grooves of piston.</p>
6. Cylinder block (11)	Place in vertical position with rear of block (11) down.	
7. Crankshaft (10)	Rotate until journal for piston and connecting rod assembly (5) being installed is at bottom dead center.	
8. Piston and connecting rod assembly (5)	<p>a. Position numbered side of connecting rod assembly (5) toward camshaft side of cylinder block (11).</p> <p>b. Push piston through piston ring compressor (14) and into cylinder liner (9).</p> <p>c. Ensure piston moves freely in cylinder liner (9).</p>	<p>Guide connecting rod on journal of crankshaft (10) as piston is installed on cylinder liner (9).</p> <p>If not, remove and check for broken or damaged rings.</p>

3-69. PISTON, CONNECTING ROD, AND BEARINGS INSTALLATION (Contd)



LEGEND:

- 1. COMPRESSION RING
- 2. PISTON RING (COMPRESSION RING)
- 3. COMPRESSION RING
- 4. PISTON RING (OIL CONTROL RING)
- 5. PISTON AND CONNECTING ROD ASSEMBLY
- 6. ROD BEARING HALF (2)

- 9. CYLINDER LINER
- 10. CRANKSHAFT
- 11. CYLINDER BLOCK
- 13. CONNECTING ROD GUIDE PIN (2)
- 14. PISTON RING COMPRESSOR

3-69. PISTON, CONNECTING ROD, AND BEARINGS INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)


	d. Using connecting rod guide pins (13), pull connecting rod in position against crankshaft (9).	
	e. Remove two connecting rod guide pins (13).	
9. Connecting rod cap (7)	a. Install on crankshaft (9) and on piston and connecting rod assembly (5).	Ensure numbered side of connecting rod cap (7) is on same side as numbered side of connecting rod.
	b. Lubricate two screws (8) with clean lubricating oil.	Use OE/HDO 30 lubricating oil (Appendix C, Item 21).

STEP NO.	MINIMUM	MAXIMUM
1. Tighten to	70 lb-ft (95 N•m)	75 lb-ft (102 N•m)
2. Tighten to	140 lb-ft (190 N•m)	150 lb-ft (203 N•m)
3. Loosen completely	—	—
4. Tighten to	25 lb-ft (34 N•m)	30 lb-ft (41 N•m)
5. Tighten to	70 lb-ft (95 N•m)	75 lb-ft (102 N•m)
6. Tighten to	140 lb-ft (190 N•m)	150 lb-ft (203 N•m)

	c. Install screws (8) on connecting rod cap (7) and connecting rod.	Tighten in sequence listed below.
10. Piston and connecting rod assembly (5)	a. Check side-to-side movement.	Piston and connecting rod assembly (5) must move freely on crankshaft journal with hand pressure. If connecting rod does not move freely, remove connecting rod cap (7) and check for dirt, damage, or improper bearing half (6).
	b. Using feeler gauge, check side clearance as shown.	Side clearance must be between 0.004-0.013 in. (0.102-0.330 mm).

FOLLOW-ON TASK: Install camshaft and cam followers (para. 3-70).

3-69. PISTON, CONNECTING ROD, AND BEARINGS INSTALLATION (Contd)



LEGEND:

- 5. PISTON AND CONNECTING ROD ASSEMBLY
- 6. ROD BEARING HALF (2)
- 7. CONNECTING ROD CAP

- 8. SCREW (2)
- 9. CRANKSHAFT
- 13. CONNECTING ROD GUIDE PIN (2)

3-70. CAM FOLLOWER ASSEMBLIES AND CAMSHAFT INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Lubricant, high-pressure (Appendix C, Item 15)

Gasket (as required) (15434) 3011878

(M915/Big Cam I)

(M915/Big Cam I)

Six lockwashers (15434) S604

(M915/Big Cam I)

Gasket (15434) 3020000 (M915A1/Big Cam III)

Gasket (as required) (15434) 3020001,

3020002, 3020003, 3020004

(M915A1/Big Cam III)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Camshaft and main bearing installed (para. 3-68).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation

CAUTION

The oil grooves on thrust washer must be installed facing camshaft gear or thrust washer failure will result.

NOTE

Four camshaft pilot tools, Part No. 3375268, may be used to assist with camshaft installation if available.

- | | | |
|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|
| <p>1. Thrust washer (3)</p> | <p>a. Coat both sides with high-pressure lubricant.</p> <p>b. Slide over end of camshaft (2) until seated next to camshaft gear (1).</p> | <p>Ensure oil grooves in thrust washer (3) are toward camshaft gear (1).</p> |
| <p>2. Camshaft (2)</p> | <p>a. Lubricate cam lobes with high-pressure lubricant.</p> <p>b. Install on cylinder block (4) while rotating slowly.</p> <p>c. Line up timing mark "O" on camshaft gear (1) with timing mark "O" on crankshaft gear (9) and fully seat camshaft (2) and thrust washer (3) against cylinder block (4). Remove camshaft pilot tools from camshaft (2) if utilized.</p> <p>d. Check camshaft-to-crankshaft</p> | <p>Be careful not to damage lobes on camshaft (2) or bushings on cylinder block (4) during installation.</p> |

3-70. CAM FOLLOWER ASSEMBLIES AND CAMSHAFT INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

backlash as follows:


(1) Install a dial indicator on front of cylinder block (4), and position tip of indicator against a tooth on camshaft gear (1).

See illustration.

(2) Rotate camshaft gear (1) as far as it will freely move.

Ensure crankshaft gear (9) does not move.

(3) Turn dial indicator to zero.



LEGEND:

- | | |
|---------------------------------|------------------------------------|
| 1. CAMSHAFT GEAR | 6. CAM FOLLOWER ASSEMBLY |
| 2. CAMSHAFT | 7. SCREW (6) |
| 3. THRUST WASHER | 8. LOCKWASHER (6) (M915/BIG CAM I) |
| 4. CYLINDER BLOCK | 9. CRANKSHAFT GEAR |
| 5. CAM FOLLOWER ASSEMBLY GASKET | |

3-70. CAM FOLLOWER ASSEMBLIES AND CAMSHAFT INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

2. Camshaft (2) (Contd)	(4) Rotate camshaft gear (1) in opposite direction as far as it will freely move. The reading on indicator shows amount of backlash between gears.	Normal backlash is 0.004-0.016 in. (0.102-0.406 mm) between a new camshaft gear (1) and a new crankshaft gear (9). Minimum backlash for a new camshaft gear is 0.002 in. (0.051 mm). Gears will begin to make noise if backlash exceeds 0.010 in. (0.254 mm). If noise is acceptable, do not replace gears unless backlash exceeds 0.020 in. (0.508 mm).
-------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


NOTE

Perform steps 3 and 4 to install any one of the three cam follower assemblies. Repeat steps 3 and 4 as required to install each additional cam follower assembly.

3. New cam follower assembly gasket (5)	Install on dowel pins and cylinder block (4).	Use gasket or gaskets with same thickness as those removed (refer to para. 3-28). Total gasket thickness must be between 0.014-0.080 in. (0.356-2.032 mm). Install gasket (P/N 3020000) (M915A1/ Big Cam III) so that it is against cylinder block (4) and sealing bead faces cam follower assembly (6).
4. Cam follower assembly (6)	<p>a. Install on cylinder block (4).</p> <p>b. Secure with six screws (7). Six lockwashers (8) are also used on M915/Big Cam I engines.</p>	<p>Strike housing with soft-nose hammer to push it onto dowel pins on cylinder block (4).</p> <p>Tighten to 15 lb-ft (20 N•m) in tightening sequence (10) shown in illustration, then tighten to 30-35 lb-ft (41-48 N•m).</p>

FOLLOW-ON TASK: Install cylinder head assembly and pushrods (para. 3-71).

3-70. CAM FOLLOWER ASSEMBLIES AND CAMSHAFT INSTALLATION (Contd)



LEGEND:

- | | |
|---------------------------------|--------------------------------------------------|
| 1. CAMSHAFT GEAR | 7. SCREW (6) |
| 2. CAMSHAFT | 8. LOCKWASHER (6) (M915/BIG CAM I) |
| 3. THRUST WASHER | 9. CRANKSHAFT GEAR |
| 4. CYLINDER BLOCK | 10. SCREW TORQUE SEQUENCE, CAM FOLLOWER ASSEMBLY |
| 5. CAM FOLLOWER ASSEMBLY GASKET | |
| 6. CAM FOLLOWER ASSEMBLY | |

3-71. CYLINDER HEAD ASSEMBLY AND PUSHRODS INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Lubricant, rust preventative
(Appendix C, Item 16)

Oil, lubricating, gear GO-80/140
(Appendix C, Item 22)

Cylinder head gasket (15434) 3047402
Four preformed packings (15434) 131026

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Pistons, connecting rods, and bearings installed
(para. 3-69).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation

NOTE

- The following procedure involves installation of one cylinder head assembly. Installation of remaining cylinder heads is similar. Repeat steps 1 through 9 to install each additional cylinder head assembly as required.
- Ensure marks made on each cylinder head and cylinder block during removal are matched together during installation so that each cylinder head assembly is installed in its original position on cylinder block.

1. New cylinder head gasket (8)	Install on dowel pins of cylinder block (7).	Ensure new cylinder head gasket (8) has the side with word TOP facing upwards.
2. Cylinder head assembly (6)	Install on cylinder block (7).	Assistant will help lift cylinder head assembly (6). Use T-handles to assist in positioning cylinder head assembly (6).


CAUTION

Cylinder head screws on turbocharged engines are made of hardened material. The letters NT are stamped on the head of these screws. Do not use any other screws to secure cylinder heads. Engine damage may result.

3-71. CYLINDER HEAD ASSEMBLY AND PUSHRODS INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

- | | | |
|----------------------|--------------------------------------------------------------------------------------------------------------------|--|
| 3. Twelve screws (3) | Lubricate with rust preventative lubricant. Allow excess lubricant to drip from screw threads before installation. | |
|----------------------|--------------------------------------------------------------------------------------------------------------------|--|



LEGEND:

- | | |
|----------------------------------|----------------------------------------|
| 1. FUEL CROSSOVER CONNECTION (2) | 8. CYLINDER HEAD GASKET |
| 2. SCREW (4) | 9. INTAKE AND EXHAUST CAM FOLLOWER (4) |
| 3. SCREW (12) | 10. INJECTOR CAM FOLLOWER (2) |
| 4. WASHER (12) | 11. INTAKE AND EXHAUST PUSHROD (4) |
| 5. TIGHTENING SEQUENCE | 12. INJECTOR PUSHROD (2) |
| 6. CYLINDER HEAD ASSEMBLY | 13. PREFORMED PACKING (4) |
| 7. CYLINDER BLOCK | |

3-71. CYLINDER HEAD ASSEMBLY AND PUSHRODS INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

- | | | |
|----|----------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 4. | Twelve screws (3) and washers (4) | Install on cylinder head assembly (6) and cylinder block (7) and tighten as follows:

a. Tighten to 25 lb-ft (34 N•m) as shown in tightening sequence (5).

b. Tighten to 100 lb-ft (136 N•m) as shown in tightening sequence (5).

c. Tighten to 305 lb-ft (414 N•m) (M915/Big Cam I) or 285 lb-ft (387 N•m) (M915A1/Big Cam III) as shown in tightening sequence (5). |
| 5. | Four new preformed packings (13) | Install on counterbores of cylinder head assembly (6). |
| 6. | Two fuel crossover connections (1) head assembly (6). | Install on new preformed packings (13) and cylinder |
| 7. | Four screws (2) | Install on fuel crossover connections (1) and tighten to 38 lb-in. (4.3 N•m). |
| 8. | Four intake and exhaust pushrods (11) and two injector pushrods (12) | Lubricate ball ends with gear GO-80/140 lubricating oil. |


NOTE

- **The injector pushrods are larger in diameter than the valve pushrods. The valve pushrods are 0.007 in. (0.178 mm) longer than injector pushrods.**
- **Ensure each pushrod is installed in same position as noted during removal.**

- | | | | |
|----|----------------------------------------------------------------------|----------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 9. | Four intake and exhaust pushrods (11) and two injector pushrods (12) | Install on cam followers (9) and (10). | Ball end of pushrods (11) and (12) must fit into socket of cam followers (9) and (10). The injector pushrod (12) is installed on center injector cam follower (10). |
|----|----------------------------------------------------------------------|----------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|

FOLLOW-ON TASK: Perform injection timing (para. 3-72).

3-71. CYLINDER HEAD ASSEMBLY AND PUSHRODS INSTALLATION (Contd)



LEGEND:

- 1. FUEL CROSSOVER CONNECTION (2)
- 2. SCREW (4)
- 3. SCREW (12)
- 4. WASHER (12)
- 5. TIGHTENING SEQUENCE
- 6. CYLINDER HEAD ASSEMBLY
- 7. CYLINDER BLOCK

- 8. CYLINDER HEAD GASKET
- 9. INTAKE AND EXHAUST CAM FOLLOWER (4)
- 10. INJECTOR CAM FOLLOWER (2)
- 11. INTAKE AND EXHAUST PUSHROD (4)
- 12. INJECTOR PUSHROD (2)
- 13. PREFORMED PACKING (4)

3-72. INJECTION TIMING

THIS TASK COVERS:

- a. Setup
- b. Injection Timing Cylinder No. 1
- c. Changing Injection Timing
- d. Injection Timing Cylinder No. 3
- e. Injection Timing Cylinder No. 5

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

Injection timing fixture (15434) 3375522

MATERIALS/PARTS

Gasket (as required) (15434) 3011878
 (M915/Big Cam I)
 Gasket (15434) 302000 (M915A1/Big Cam III)
 Gasket (as required) (15434) 3020001,
 3020002, 3020003, 3020004
 (M915A1/Big Cam III)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Cylinder head assemblies and pushrods installed (para. 3-71).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS


None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Setup

1. Injection timing fixture (14)	Install as follows: a. Loosen piston and pushrod dial indicator setscrews (1) and (4). Slide both dial indicators (6) and (16) to the uppermost position and tighten setscrews (1) and (4). b. Position timing fixture sleeve (13) with piston follower rod (11) into injector sleeve (10) of No. 1 cylinder. c. Secure in two threaded holes with two knurled holddowns (2). d. Align pushrod follower rod (8) with injector pushrod (9).	Use injection timing fixture (3375522). This is necessary to prevent damage to both dial indicators during tool installation, and when trying to locate Top Dead Center (TDC). Ensure injection timing fixture (14) is mounted straight on cylinder head (12).
----------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-72. INJECTION TIMING (Contd)



LEGEND:

- | | |
|--------------------------------------|--------------------------------|
| 1. PISTON DIAL INDICATOR SETSCREW | 9. INJECTOR PUSHROD |
| 2. KNURLED HOLDDOWN (2) | 10. INJECTOR SLEEVE |
| 3. PISTON DIAL INDICATOR THUMBSCREW | 11. PISTON FOLLOWER ROD |
| 4. PUSHROD DIAL INDICATOR SETSCREW | 12. CYLINDER HEAD |
| 5. PUSHROD DIAL INDICATOR THUMBSCREW | 13. TIMING FIXTURE SLEEVE |
| 6. PUSHROD DIAL INDICATOR | 14. INJECTION TIMING FIXTURE |
| 7. PUSHROD DIAL INDICATOR STEM | 15. PISTON DIAL INDICATOR STEM |
| 8. PUSHROD FOLLOWER ROD | 16. PISTON DIAL INDICATOR |

3-72. INJECTION TIMING (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Injection Timing Cylinder No.

CAUTION





Injection timing for No. 1 cylinder requires that No. 1 piston be set at TDC. TDC will occur during both compression stroke and exhaust stroke. Injection timing is performed when piston is at TDC on compression stroke.

NOTE

- Adjustments to injection timing are made by altering thickness of cam follower assembly gaskets.
- Injection timing may be advanced or retarded by adding or removing cam follower assembly gaskets.
- Use cylinder Nos. 1, 3, and 5 to check injection timing.
- Dial indicators used in injection timing must have a total travel of at least 0.25 in. (6.350 mm).
- Ensure camshaft is pushed in every time crankshaft is rotated.
- Use only the crankshaft to rotate engine. The use of gears will result in false measurements. Gear lash must be closed up in the direction of normal rotation (crankshaft rotating clockwise when facing crankshaft front pulley).

2.	Two screws (18)	Install on threaded holes on front of crankshaft (17). See view A.	The two screws (18) will be used for turning crankshaft (17) to locate TDC (19).
3.	Crankshaft (17)	Rotate clockwise to TDC (19) on compression stroke, using a suitable bar between two screws (18). Refer to view B.	TDC can be determined when both rods (9) and (11) start moving upward. Continue rotating until piston follower rod (11) reaches its uppermost travel position. When TDC (19) is determined, remove two screws (18) and install on locations shown in view A.
4.	Piston dial indicator (16) and pushrod dial indicator (6)	Adjust as follows: a. Move both downward until seated on piston follower rod (11) in their fully compressed position. b. Raise both approximately 0.02 in. (0.508 mm). c. Lock in place with piston dial indicator setscrew (1) and pushrod dial indicator setscrew (4).	

3-72. INJECTION TIMING (Contd)



LEGEND:

- | | |
|------------------------------------|---------------------------|
| 1. PISTON DIAL INDICATOR SETSCREW | 16. PISTON DIAL INDICATOR |
| 4. PUSHROD DIAL INDICATOR SETSCREW | 17. CRANKSHAFT |
| 6. PUSHROD DIAL INDICATOR | 18. SCREW (2) |
| 9. INJECTOR PUSHROD | 19. TOP DEAD CENTER (TDC) |
| 11. PISTON FOLLOWER ROD | |

3-72. INJECTION TIMING (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Injection Timing Cylinder No. 1 (Contd)






5. Crankshaft (17)	Slowly rotate several degrees clockwise and counterclockwise to ensure piston is at TDC (19) and pushrod dial indicator (6) is at TDC. Refer to view B.	The piston dial indicator (16) and pushrod dial indicator (6) will move in the same direction when piston is on compression stroke.
--------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------

NOTE

Always set dial indicator at zero at TDC with crankshaft having just been rotated in the direction of normal rotation (clockwise).

6. Piston dial indicator thumbscrew (3)	Loosen and adjust face of piston dial indicator (16) to align zero with pointer. Tighten piston dial indicator thumbscrew (3).	
7. Crankshaft (17)	Rotate clockwise 90° after TDC (20). Refer to view C.	Piston follower rod (11) will be near bottom of its travel.
8. Pushrod dial indicator thumbscrew (5)	Loosen and adjust face of pushrod dial indicator (6) to align zero with the pointer. Tighten piston rod dial indicator thumbscrew (5).	
9. Crankshaft (17)	<p>a. Rotate counterclockwise past TDC to 45° before TDC (21). Refer to view D.</p> <p>b. Slowly rotate clockwise to 19° before TDC (22) until piston follower rod (11) is almost in contact with piston dial indicator stem (15). Refer to view E.</p>	This step is necessary to remove gear backlash and provide more accurate dial indicator readings for the next step.

3-72. INJECTION TIMING (Contd)



LEGEND:

- 3. PISTON DIAL INDICATOR THUMBSCREW
- 5. PUSHROD DIAL INDICATOR THUMBSCREW
- 6. PUSHROD DIAL INDICATOR
- 11. PISTON FOLLOWER ROD
- 15. PISTON DIAL INDICATOR STEM
- 16. PISTON DIAL INDICATOR

- 17. CRANKSHAFT
- 19. TOP DEAD CENTER (TDC)
- 20. 90° AFTER TDC
- 21. 45° BEFORE TDC
- 22. 19° BEFORE TDC

3-72. INJECTION TIMING (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Injection Timing Cylinder No. 1 (Contd)

9. Crankshaft (17) (Contd)	<p>c. Slowly rotate crankshaft (17) clockwise until piston dial indicator (16) reads 0.0032 in. (0.0813 mm) before zero.</p> <p>d. Read total travel of pointer on pushrod dial indicator (6).</p>	<p>This reading of 0.0032 in. (0.0813 mm) is actually 0.2032 in. (5.1613 mm) before zero since piston dial indicator (16) will have reached over 0.200 in. (5.08 mm) as the crankshaft (17) was moved to 45 degrees before TDC (21). Refer to view E. Each revolution of the dial indicator hand represents 0.100 in. (2.54 mm).</p> <p>Each mark on pushrod dial indicator (6) represents 0.001 in. (0.025 mm).</p>
----------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

NOTE

- Engine assembly, as described in this section, is with the assumption that all units have been repaired or are new and are ready to be assembled. During assembly operations, it is important to closely inspect each unit to make sure nothing has been overlooked during inspection and repair. Plugs should be checked for tightness, parts kept clean, openings covered, and machined surfaces protected. Application of any type lubricant should be performed from covered containers.
- The timing code for this engine is **BM** Big Cam I or **BY** Big Cam III, reference the engine data plate. Code **BM** is used for CPL 324 and 327. Code **BY** is used for CPL 393.

BM Big Cam I (CPL 324 and 327)

BY Big Cam III (CPL 393)

Nominal	0.053 in. (1.35 mm)	0.070 in. (1.78 mm)
Fast	0.052 in. (1.32 mm)	0.069 in. (1.75 mm)
Slow	0.054 in. (1.37 mm)	0.070 in. (1.78 mm)

e. Reading on pushrod dial indicator (6) should be within 0.069-0.071 in. (1.752-1.803 mm) for Big Cam III or 0.053-0.054 in. (1.35-1.37 mm) for Big Cam I.

If reading is not within limits, follow the procedures in task c., Changing Injection Timing.

f. If push rod travel is greater than limits indicated above, engine timing is slow. If the push rod travel is less, timing is fast.

c. Changing Injection Timing

CAUTION

Never change cam follower assembly gaskets to correct injection timing until checking the following:

- Timing tool is correctly installed.
- Dial indicators are correctly adjusted.
- Crankshaft has been rotated in the correct direction.
- Screws for cam follower assemblies have been tightened to 30-35 lb-ft (41-48 N•m).

3-72. INJECTION TIMING (Contd)

c. Changing Injection Timing

NOTE




Do not increase the total gasket thickness to more than 0.080 in. (2.032 mm). The minimum total thickness must be at least 0.014 in. (0.356 mm).

- 10. Cam follower assembly gasket (23)

Advance or retard timing as follows:

- a. Advance timing by increasing thickness of cam follower assembly gasket (23).

Cam follower assembly gaskets are available in three thicknesses. Thickness sizes vary between M915/Big Cam I and M915A1/Big Cam III engine series.



LEGEND:

- 6. PUSHROD DIAL INDICATOR
- 16. PISTON DIAL INDICATOR
- 17. CRANKSHAFT

- 21. 45° BEFORE TDC
- 22. 19° BEFORE TDC
- 23. CAM FOLLOWER ASSEMBLY GASKET

3-72. INJECTION TIMING (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Changing Injection Timing (Contd)

b. Retard timing by decreasing thickness of cam follower assembly gasket (23).

Refer to para. 3-28 for cam follower assembly gasket removal, and para. 3-70 for cam follower assembly gasket installation.

Refer to para. 3-28 for cam follower assembly gasket removal, and para. 3-70 for cam follower assembly gasket installation.

d. Injection Timing Cylinder No. 3

NOTE

The injection timing procedure for cylinder No. 3 is similar to timing No. 1 cylinder with one exception; the timing fixture must be moved to cylinder No. 3 and piston No. 3 must be used as the reference for determining Top Dead Center (TDC).


e. Injection Timing Cylinder No. 5

NOTE

The injection timing procedure for cylinder No. 5 is similar to timing No. 1 cylinder with one exception; the timing fixture must be moved to cylinder No. 5 and piston No. 5 must be used as reference for determining TDC.

FOLLOW-ON TASK: Install accessory drive housing assembly (para. 3-73).

3-72. INJECTION TIMING (Contd)



LEGEND:

- 1. PISTON DIAL INDICATOR SETSCREW
- 2. KNURLED HOLDDOWN (2)
- 3. PISTON DIAL INDICATOR THUMBSCREW
- 4. PUSHROD DIAL INDICATOR SETSCREW
- 5. PUSHROD DIAL INDICATOR THUMBSCREW
- 6. PUSHROD DIAL INDICATOR
- 7. PUSHROD DIAL INDICATOR STEM
- 8. PUSHROD FOLLOWER ROD

- 9. INJECTOR PUSHROD
- 10. INJECTOR SLEEVE
- 11. PISTON FOLLOWER ROD
- 12. CYLINDER HEAD
- 13. TIMING FIXTURE SLEEVE
- 14. INJECTION TIMING FIXTURE
- 15. PISTON DIAL INDICATOR STEM
- 16. PISTON DIAL INDICATOR
- 23. CAM FOLLOWER ASSEMBLY GASKET (3)

3-73. ACCESSORY DRIVE HOUSING ASSEMBLY INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

Dial gauge attachment (15434) ST-1325
Dial indicator and sleeve assembly (15434)
3376050

MATERIALS/PARTS

Gasket (15434) 200809

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Camshaft and cam followers installed (para. 3-70).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS


None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation

1. Crankshaft (5)	a. Turn in direction of engine rotation until No. 1 cylinder is at Top Dead Center (TDC) of compression stroke (6). b. Turn in direction of engine rotation to 90° after (TDC) (7).	Rotate crankshaft clockwise when facing front of crankshaft (5).
2. Accessory drive housing assembly (3) and new gasket (2)	Position on cylinder block (1).	Ensure timing mark on accessory drive gear (9) lines up with timing mark on camshaft gear (8). This alignment is necessary so that valve and injector adjustment marks on accessory drive pulley will be correctly aligned.
3. Five captive washer screws (4)	Install on accessory drive housing assembly (3), gasket (2), and cylinder block (1).	Tighten to 40-45 lb-ft (54-61 N•m).
4. Accessory drive gear (9) and camshaft gear (8)	Check accessory drive gear-to-camshaft gear backlash as follows: a. Install dial indicator on front of cylinder block (1), and position tip of indicator against a tooth of accessory drive gear (9).	Use dial gauge attachment (ST-1325) and dial indicator and sleeve assembly (3376050).

3-73. ACCESSORY DRIVE HOUSING ASSEMBLY INSTALLATION (Contd)



LEGEND:


- | | |
|-------------------------------------|------------------------------------------------|
| 1. CYLINDER BLOCK | 6. TOP DEAD CENTER (TDC) OF COMPRESSION STROKE |
| 2. GASKET | 7. 90° AFTER TOP DEAD CENTER |
| 3. ACCESSORY DRIVE HOUSING ASSEMBLY | 8. CAMSHAFT GEAR |
| 4. CAPTIVE WASHER SCREW (5) | 9. ACCESSORY DRIVE GEAR |
| 5. CRANKSHAFT | |

3-73. ACCESSORY DRIVE HOUSING ASSEMBLY INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Installation (Contd)		
4. Accessory drive gear (9) and camshaft gear (8) (Contd)	b. Rotate accessory drive gear (9) as far as it will freely move. c. Turn dial on indicator to zero. d. Rotate accessory drive gear (9) in opposite direction. Reading on indicator shows amount of backlash between gears.	Ensure camshaft gear (8) does not move. Normal backlash between a new accessory drive gear (9) and a new camshaft gear (8) is 0.004-0.016 in. (0.102-0.406 mm). Backlash for new accessory drive gear (8) must be at least 0.002 in. (0.051 mm). If backlash is more than 0.016 in. (0.406 mm), remove accessory drive housing assembly (3) and replace accessory drive gear (9) (para. 3-49).

FOLLOW-ON TASK: Install oil pump (para. 3-74).

3-73. ACCESSORY DRIVE HOUSING ASSEMBLY INSTALLATION (Contd)



LEGEND:

- 3. ACCESSORY DRIVE HOUSING ASSEMBLY
- 8. CAMSHAFT GEAR
- 9. ACCESSORY DRIVE GEAR

3-74. OIL PUMP INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

Dial gauge attachment (15434) ST-1325
Dial indicator and sleeve assembly (15434)
3376050

MATERIALS/PARTS

Sealant, pipe (Appendix C, Item 26)
Gasket (15434) 121907 (M915/Big Cam I)
Gasket (15434) 3031434 (M915A1/Big Cam III)
Five lockwashers (15434) S610
Five lockwashers (96906) MS35338-47

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Accessory drive housing assembly installed
(para. 3-73).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


Installation

NOTE

Perform steps 1 through 6 for M915A1/Big Cam III only.

1. Elbow (2) (M915A1/Big Cam III)	Install on cylinder block (1).	Coat threads with pipe sealant.
2. Oil transfer hose (3) (M915A1/Big Cam III)	Install on elbow (2).	Coat threads with pipe sealant.
3. New gasket (8) (M915A1/Big Cam III)	Install on oil pump assembly (6).	
4. Oil pump assembly (6) (M915A1/Big Cam III)	Position in mounting hole of cylinder block (1).	Ensure that pump drive gear (7) of oil pump assembly (6) aligns with teeth of camshaft gear (9).
5. Five screws (4) and new lockwashers (5) (M915A1/Big Cam III)	Install on oil pump assembly (6) and cylinder block (1).	Tighten to 45 lb-ft (61 N•m).
6. Oil transfer hose (3) (M915A1/Big Cam III)	Install loose end of oil transfer hose (3) to oil pump assembly (6).	Coat threads with pipe sealant.

3-74. OIL PUMP INSTALLATION (Contd)



M915A1/BIG CAM III ONLY

LEGEND:

- | | |
|-------------------------------------------|-------------------------------------------|
| 1. CYLINDER BLOCK | 6. OIL PUMP ASSEMBLY (M915A1/BIG CAM III) |
| 2. ELBOW (M915A1/BIG CAM III) | 7. PUMP DRIVE GEAR |
| 3. OIL TRANSFER HOSE (M915A1/BIG CAM III) | 8. GASKET (M915A1/BIG CAM III) |
| 4. SCREW (5) (M915A1/BIG CAM III) | 9. CAMSHAFT GEAR |
| 5. LOCKWASHER (5) (M915A1/BIG CAM III) | |

3-74. OIL PUMP INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

NOTE

Perform steps 7 through 9 for M915/Big Cam I only.

7.	New gasket (10) (M915/Big Cam I)	Install on oil pump assembly (11).	
8.	Oil pump assembly (11) (M915/Big Cam I)	Position in mounting hole of cylinder block (1).	Ensure pump drive gear (7) of oil pump assembly (11) aligns with teeth on camshaft gear (9).
9.	Three screws (12), two screws (14), and five new lockwashers (13) (M915/Big Cam I)	Install on oil pump assembly (11) and cylinder block (1).	Tighten to 40 lb-ft (54 N•m).


NOTE

The oil pump gear backlash check procedure is identical for both M915/Big Cam I and M915A1/Big Cam III engines.


10.	Pump drive gear (7) (M915/Big Cam I and M915A1/Big Cam III)	Check for backlash against camshaft gear (9) as follows: (1) Install dial indicator and sleeve assembly (16) and dial gauge attachment (15) on front of cylinder block (1), and position tip of indicator (16) against a tooth of pump drive gear (7). (2) Rotate pump drive gear (7) as far as it will freely move. (3) Turn dial of indicator to zero. (4) Rotate pump drive gear (7) in opposite direction. The reading on indicator (16) shows amount of backlash between gears.	Use dial gauge attachment (15) (ST-1325) and dial indicator and sleeve assembly (16) (3376050). Ensure camshaft gear (9) does not move. Minimum backlash is 0.002 in. (0.051 mm) and maximum backlash is 0.016 in. (0.406 mm). Replace pump drive gear (7) if not within specifications. Refer to para. 3-44 for pump drive gear (7) removal and installation.
-----	-------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

FOLLOW-ON TASK: Install front gear cover (para. 3-75).

3-74. OIL PUMP INSTALLATION (Contd)



OIL PUMP GEAR BACKLASH CHECK
(BOTH M915/BIG CAM I AND
M915A1/BIG CAM III ENGINE SERIES)



M915/BIG CAM I ONLY

LEGEND:

- | | |
|----------------------------------------|----------------------------------------|
| 1. CYLINDER BLOCK | 12. SCREW (3) (M915/BIG CAM I) |
| 7. PUMP DRIVE GEAR | 13. LOCKWASHER (5) (M915/BIG CAM I) |
| 9. CAMSHAFT GEAR | 14. SCREW (2) (M915/BIG CAM I) |
| 10. GASKET (M915/BIG CAM I) | 15. DIAL GAUGE ATTACHMENT |
| 11. OIL PUMP ASSEMBLY (M915/BIG CAM I) | 16. DIAL INDICATOR AND SLEEVE ASSEMBLY |

3-75. FRONT GEAR COVER INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Dial gauge attachment (15434) ST-1325
 Dial indicator and sleeve assembly (15434) 3376050

TEST EQUIPMENT

None

MATERIALS/PARTS

Lubricant, high-pressure (Appendix C, Item 15)
 Gasket (15434) 3021704
 Lockwasher (96906) MS35338-47 (M915/Big Cam I)
 Preformed packing (15434) 215705
 Shim (as required) (15434) 185573, 65259-A, 65259-B, 65259-C
 Three lockwashers (15434) S-604 (M915/Big Cam I)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Table 2-1

EQUIPMENT CONDITION

Oil pump installed (para. 3-74).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation

NOTE

- To replace crankshaft and accessory drive oil seals, refer to para. 3-48.
- Perform step 1 for M915/Big Cam I only.
- Perform step 2 for M915A1/Big Cam III only.


1. Three screws (4), lockwashers (22), and washers (23)	Remove from camshaft support (5). Remove camshaft support (5), shim pack (6), and preformed packing (7) from gear cover (11).	These parts must be removed before installing gear cover (11).
2. Three captive washer screws (4)	Remove from camshaft support (5). Remove camshaft support (5), shim pack (6), and preformed packing (7) from gear cover (11).	These parts must be removed before installing gear cover (11).

CAUTION

All surfaces in contact with oil seals must be completely free of oil. Oil on a Teflon seal will destroy its sealing properties.

3. New gasket (12)	a. Coat with high-pressure lubricant. b. Install on gear cover (11).
4. Gear cover (11) with gasket (12)	Install on two dowels (13) and cylinder block (14).

3-75. FRONT GEAR COVER INSTALLATION (Contd)



LEGEND:

- | | |
|--------------------------------------------------------------------------------|---------------------------------------------------------------------------------|
| 1. SCREW (6) | 13. DOWEL (2) |
| 2. WASHER (6) | 14. CYLINDER BLOCK |
| 3. FRONT ENGINE SUPPORT | 15. CAPTIVE WASHER SCREW |
| 4. SCREW (3) (M915/BIG CAM I)
CAPTIVE WASHER SCREW (3) (M915A1/BIG CAM III) | 16. ENGINE SHIPPING SUPPORT |
| 5. CAMSHAFT SUPPORT | 17. CAPTIVE WASHER SCREW (4) (M915A1/BIG CAM III) |
| 6. SHIM PACK | 18. SCREW (4) (M915/BIG CAM I) |
| 7. PREFORMED PACKING | 19. CAPTIVE WASHER SCREW (9) |
| 8. SCREW (M915/BIG CAM I)
CAPTIVE WASHER SCREW (2) (M915A1/BIG CAM III) | 20. WASHER (2) (M915/BIG CAM I) |
| 9. LOCKWASHER (M915/BIG CAM I) | 21. SCREW (2) (M915/BIG CAM I)
CAPTIVE WASHER SCREW (2) (M915A1/BIG CAM III) |
| 10. WASHER (M915/BIG CAM I) | 22. LOCKWASHER (3) (M915/BIG CAM I) |
| 11. GEAR COVER | 23. WASHER (3) (M915/BIG CAM I) |
| 12. GASKET | |

3-75. FRONT GEAR COVER INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

NOTE

- Perform step 5 for M915/Big Cam I only.
- Perform step 6 for M915A1/Big Cam III only.


5.	Screw (8), lockwasher (9), washer (10), captive washer screw (15), and nine captive washer screws (19)	Install on gear cover (11) and cylinder block (14).	Tighten screw (8), and captive washer screws (15) and (19) to 45-55 lb-ft (61-75 N•m).
6.	Three captive washer screws (8), captive washer screw (15), and nine captive washer screws (19)	Install on gear cover (11) and cylinder block (14).	Tighten captive washer screws (8), (15), and (19) to 45-55 lb-ft (61-75 N•m).
7.	Front engine support (3)	Position on gear cover (11).	

NOTE

- Perform step 8 for 1M915/Big Cam I only.
- Perform step 9 for M915A1/Big Cam III only.

8.	Six screws (1), washers (2), two screws (21), and washers (20)	Install on front engine support (3) and gear cover (11).	Tighten screws (1) and (21) to 45-55 lb-ft (61-75 N•m).
9.	Six screws (1), washers (2), two captive washer screws (21)	Install on front engine support (3) and gear cover (11).	Tighten screw (1) and captive washer screws (21) to 45-55 lb-ft (61-75 N•m).
10.	New gasket (12)	Trim off excess gasket material so gasket (12) is even with oil pan mounting flange.	
11.	Gear cover (11)	<p>a. Using straightedge and feeler gauge, check alignment of oil pan mounting flange on gear cover (11) with oil pan mounting flange on cylinder block (14).</p> <p>b. Check for difference between centers of crankshaft and crankshaft seal bore in gear cover (11) as follows:</p> <p>(1) Install a dial indicator on front of crankshaft, and position tip of indicator against inner surface of crankshaft seal bore.</p> <p>(2) Turn dial of indicator to zero.</p> <p>(3) Rotate crankshaft one complete revolution. Reading on indicator shows difference.</p>	<p>Gear cover flange must be even with front cylinder block flange within 0.004 in. (0.102 mm).</p> <p>Use dial gauge attachment (ST-1325) and dial indicator and sleeve assembly (3376050).</p> <p>If total indicator reading exceeds 0.010 in. (0.254 mm), remove, clean, and relocate between common centers.</p>

3-75. FRONT GEAR COVER INSTALLATION (Contd)



LEGEND:

- | | |
|------------------------------------------------------------------------|---------------------------------------------------------------------------------|
| 1. SCREW (6) | 12. GASKET |
| 2. WASHER (6) | 13. DOWEL (2) |
| 3. FRONT ENGINE SUPPORT | 14. CYLINDER BLOCK |
| 8. SCREW (M915/BIG CAM I)
CAPTIVE WASHER SCREW (M915A1/BIG CAM III) | 15. CAPTIVE WASHER SCREW |
| 9. LOCKWASHER (M915/BIG CAM I) | 19. CAPTIVE WASHER SCREW (9) |
| 10. WASHER (M915/BIG CAM I) | 20. WASHER (2) (M915/BIG CAM I) |
| 11. GEAR COVER | 21. SCREW (2) (M915/BIG CAM I)
CAPTIVE WASHER SCREW (2) (M915A1/BIG CAM III) |

3-75. FRONT GEAR COVER INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

12. Camshaft support (5), shim pack (6), and preformed packing (7)	<p>a. Remove shim pack (6) and preformed packing (7) from camshaft support (5).</p> <p>b. Install camshaft support (5) on gear cover (11), and hold it against end of camshaft.</p> <p>c. Using feeler gauge, measure space between mounting flange of camshaft support (5) and gear cover (11).</p> <p>d. Remove camshaft support (5) from gear cover (11).</p> <p>e. Install shim pack (6) and preformed packing (7) on camshaft support (5).</p> <p>f. Install camshaft support (5), shim pack (6), and preformed packing (7) on gear cover (11).</p>	<p>Ensure camshaft is pushed back against cylinder block (14).</p> <p>Use measurement to determine thickness of shim pack needed to provide 0.008-0.13 in. (0.203-3.302 mm) clearance. Shim packs are available in four different thicknesses.</p>
--------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

NOTE

- Perform step 13 for M915/Big Cam I only.
- Perform step 14 for M915A1/Big Cam III only.

13. Three screws (4), new lockwashers (22), and washers (23)	Install on camshaft support (5), shim pack (6), and gear cover (11).	Tighten screws (4) to 15-20 lb-ft (20-27 N•m).
14. Three captive washer screws (4)	Install on camshaft support (5), shim pack (6), and gear cover (11).	Tighten captive washer screws (4) to 15-20 lb-ft (20-27 N•m).


NOTE

Perform steps 15 and 16 if oil pan is installed.

15. Engine shipping support (16)	Position on bottom front of engine oil pan.	
16. Four captive washer screws (17) (M915A1/Big Cam III) or four screws (18) (M915/Big Cam I)	Install on engine shipping support (16), engine oil pan, and gear cover (11).	Tighten captive washer screws or screws (18) to 35-40 lb-ft (48-54 N•m).

FOLLOW-ON TASK: Install accessory drive pulley (para. 3-76).

3-75. FRONT GEAR COVER INSTALLATION (Contd)



LEGEND:

- | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>4. SCREW (3) (M915/BIG CAM I)
CAPTIVE WASHER SCREW (3) (M915/BIG CAM III)</p> <p>5. CAMSHAFT SUPPORT</p> <p>6. SHIM PACK</p> <p>7. PREFORMED PACKING</p> <p>11. GEAR COVER</p> <p>14. CYLINDER BLOCK</p> | <p>16. ENGINE SHIPPING SUPPORT</p> <p>17. CAPTIVE WASHER SCREW (4) (M915A1/BIG CAM III)</p> <p>18. SCREW (4) (M915/BIG CAM I)</p> <p>22. LOCKWASHER (3) (M915/BIG CAM I)</p> <p>23. WASHER (3) (M915/BIG CAM I)</p> |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

3-76. ACCESSORY DRIVE PULLEY INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Pulley installation assembly tool
(15434) 3376326

TEST EQUIPMENT

None

MATERIALS/PARTS

Lubricant, high-pressure (Appendix C, Item 15)
Locknut (15434) 3012526

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Front gear cover installed (para. 3-75).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area dean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation

NOTE

Remove pipe plug from front gear cover and ensure timing marks on camshaft gear and accessory drive gear are aligned. Reinstall pipe plug in front gear cover and torque to 35-45 lb-ft (48-61 N•m).

1. Accessory drive shaft (7)	Coat with high-pressure lubricant.	Refer to Appendix C, Item 15.
2. Accessory drive pulley (4) (M915/Big Cam I) or accessory drive pulley assembly (6) (M915A1/Big Cam III)	a. Line up keyway with dowel pin (8) in accessory drive shaft (7). b. Position on dowel pin (8) and drive shaft (7). c. Install on accessory drive shaft (7) until seated.	Use pulley installation assembly tool (3376326).

NOTE

Discard and replace keyway seal if it is deteriorated or damaged.

3. Keyway seal (5)	Install on keyway of accessory drive pulley (4) (M915/Big Cam I) or accessory drive pulley assembly (6) (M915A1/Big Cam III).	Ensure short leg of keyway seal (5) faces toward inside of accessory drive shaft (7) and washer (3) will crush against "L" of seal (5).
4. New locknut (2) and washer (3)	Install and tighten on accessory drive shaft (7).	Tighten locknut (2) to 300-310 lb-ft (407-420 N•m). Hold crankshaft at flywheel end when applying torque.


3-76. ACCESSORY DRIVE PULLEY INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

NOTE
Perform steps 5 and 6 for M915A1/Big Cam III only.

- | | | |
|-------------------------------------------------------|--------------------------------------------------|------------------------------------------------|
| 5. Accessory drive pulley (4)
(M915A1/Big Cam III) | Position on accessory drive pulley assembly (6). | |
| 6. Six screws (1) (M915A1/
Big Cam III) | Install on accessory drive pulley assembly (6). | Tighten screws (1) to 40-45 lb-ft (54-61 N•m). |

FOLLOW-ON TASK: Install air compressor (para. 3-77).



LEGEND:

- | | |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> 1. SCREW (6) (M915A1/BIG CAM III ONLY) 2. LOCKNUT 3. WASHER 4. ACCESSORY DRIVE PULLEY (M915/BIG CAM I ONLY) 5. KEYWAY SEAL | <ul style="list-style-type: none"> 6. ACCESSORY DRIVE PULLEY ASSEMBLY (M915A1/BIG CAM III ONLY) 7. ACCESSORY DRIVE SHAFT 8. DOWEL PIN 9. SLEEVE |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

3-77. AIR COMPRESSOR INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Air compressor wrench (15484) 3375159

TEST EQUIPMENT

None

MATERIALS/PARTS

Pipe sealant (Appendix C, Item 26)
Compressor gasket (15434) 3005962
Four lockwashers (15434) S-609

PERSONNEL REQUIRED

Automotive repairman MOS 63H

EQUIPMENT CONDITION

Oil pump installed (para. 3-74).

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dust and dirt.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation


NOTE

Air compressor must be timed to engine firing order.

- | | | |
|------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
| 1. Crankshaft (1) | Rotate until valve set mark A on accessory drive pulley (2) is aligned with pointer (13) on front gear cover (3). | |
| 2. Air compressor (10) | Look at hub end and rotate air compressor crankshaft until scribe mark on hub is positioned halfway between 9 and 10 o'clock. | |
| 3. Drive coupling (5) | Install on air compressor (10). | |
| 4. Air compressor (10) and new compressor gasket (6) | a. Install on accessory drive housing (11).

b. Secure with two screws (4) and (12), washers (7), four new lockwashers (8), and two nuts (9). | Tighten screws to 40-45 lb-ft (54-62 N•m). Use air compressor wrench (14). |

3-77. AIR COMPRESSOR INSTALLATION (Contd)



LEGEND:

- 1. CRANKSHAFT
- 2. ACCESSORY DRIVE PULLEY
- 3. FRONT GEAR COVER
- 4. SCREW (2)
- 5. DRIVE COUPLING
- 6. COMPRESSOR GASKET
- 7. WASHER (2)

- 8. LOCKWASHER (4)
- 9. NUT (2)
- 10. AIR COMPRESSOR
- 11. ACCESSORY DRIVE HOUSING
- 12. SCREW (2)
- 13. POINTER
- 14. AIR COMPRESSOR WRENCH

3-77. AIR COMPRESSOR INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)



NOTE

- **Installation of air compressor coolant lines, air lines, and fittings is basically the same. The M915A1/Big Cam III is shown.**
- **Not all engines are equipped with Air Supply Attenuators (ASAs).**

5. Air inlet connector (10)	Install on compressor (1) with new gasket (12), two washers (8), new lockwashers (7), screws (9) and (6), and plug (11).	Apply pipe sealant to male pipe threads.
6. Two air inlet hoses (3) and tube (5)	Install on air inlet connector (10) and elbow (2) with four clamps (4).	
7. Three adapters (15), coupling (17), and elbow (18)	Install on compressor (1) and aftercooler.	Apply pipe sealant to male pipe threads.
8. Four bushings (14), coolant outlet tube (13), and coolant inlet tube (16)	Install on three adapters (15) and elbow (18).	

- FOLLOW-ON TASKS:
- Install air compressor governor (TM 9-2320-273-34 or TM 9-2320-283-34).
 - Install fuel pump (para. 3-78).

3-77. AIR COMPRESSOR INSTALLATION (Contd)



LEGEND:

- 1. COMPRESSOR
- 2. ELBOW
- 3. AIR INLET HOSE (2)
- 4. CLAMP (4)
- 5. TUBE
- 6. SCREW
- 7. LOCKWASHER (2)
- 8. WASHER (2)
- 9. SCREW

- 10. AIR INLET CONNECTOR
- 11. PLUG
- 12. GASKET
- 13. COOLANT OUTLET TUBE
- 14. BUSHING (4)
- 15. ADAPTER (3)
- 16. COOLANT INLET TUBE
- 17. COUPLING
- 18. ELBOW

3-78. FUEL PUMP INSTALLATION

THIS TASK COVERS:

- a. Fuel Pump Installation
- b. Fuel Supply Line Installation

- c. Attenuator Air Tank Installation
(M915/Big Cam I Only)

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Air compressor wrench (15434) 3375159

TEST EQUIPMENT

None

MATERIALS/PARTS

- Gasket (15434) 3035053
- Lockwasher (12204) 116122
- Lockwasher (96906) MS353388-46
- Two lockwashers (96906) MS122032
(M915/Big Cam I only)
- Three lockwashers (15434) S604
(M915A1/Big Cam III only)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Air compressor installed (para. 3-77).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS


None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Fuel Pump Installation

1. Fuel pump to compressor spider coupling (3)	Install on air compressor (1).	
2. Fuel pump (10) and new gasket (2)	Position on air compressor (1).	
3. Two screws (11) and washers (4)	Install on fuel pump (10), gasket (2), and into air compressor (1).	Tighten screws (11) finger-tight only.
4. Support bracket (8)	Position on fuel pump (10) and cylinder block (13).	
5. Screw (7) and new lockwasher (6)	Install on support bracket (8) and cylinder block (13).	Tighten screws (11) and (7).

3-78. FUEL PUMP INSTALLATION (Contd)



LEGEND:

- | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> 1. AIR COMPRESSOR 2. GASKET 3. FUEL PUMP TO COMPRESSOR SPIDER COUPLING 4. WASHER (4) 5. SCREW (1) (M915A1/BIG CAM III), (2) (M915/BIG CAM I) 6. LOCKWASHER | <ul style="list-style-type: none"> 7. SCREW 8. SUPPORT BRACKET 9. SCREW (M915A1/BIG CAM III ONLY) 10. FUEL PUMP 11. SCREW (2) 12. AIR COMPRESSOR WRENCH 13. CYLINDER BLOCK |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

3-78. FUEL PUMP INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


a. Fuel Pump Installation (Contd)

NOTE

- **Perform step 6 for M915/Big Cam I only.**
- **Perform steps 7 and 8 for M915A1/Big Cam III only.**

6. Two screws (5) and washers (4) (M915/Big Cam I)	Install on support bracket (8), fuel pump (10), gasket (2), and air compressor (1).	Use air compressor wrench (3375159) (12). Do not tighten screws (5) at this time.
7. Screw (9) and washer (4) (M915A1/Big Cam III)	Install on support bracket (8), fuel pump (10), gasket (2), and air compressor (1).	Use air compressor wrench (3375159) (12). Do not tighten screw (9) at this time.
8. One screw (5) and washer (4) (M915A1/Big Cam III)	Install on fuel pump (10), gasket (2), and air compressor (1).	Use air compressor wrench (3375159) (12).
9. Screws (5) and (9) (M915A1/Big Cam III)	Tighten to 30-35 lb-ft (41-48 N•m).	If air compressor wrench (12) is used, tighten screws until tight.
10. Tachometer drive	Connect to fuel pump (10).	Refer to TM 9-2320-283-20.

3-78. FUEL PUMP INSTALLATION (Contd)



LEGEND:

- | | |
|------------------------------------------------------------|------------------------------------|
| 1. AIR COMPRESSOR | 8. SUPPORT BRACKET |
| 2. GASKET | 9. SCREW (M915A1/BIG CAM III ONLY) |
| 4. WASHER (4) | 10. FUEL PUMP |
| 5. SCREW (1) (M915A1/BIG CAM III), (2)
(M915/BIG CAM I) | 11. SCREW (2) |
| | 12. AIR COMPRESSOR WRENCH |

3-78. FUEL PUMP INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


b. Fuel Supply Line Installation

NOTE

- Apply Teflon tape or equivalent to fuel fittings. Use care not to contaminate or block fuel lines or fittings.
- If a fitting is not in alignment with the fuel tubing once torque has been performed, turn the fitting in the tightening direction until aligned. Do not loosen fitting to align.
- Tighten tubing nuts as follows: Tighten 5/16-in. tubing nuts to 17 lb-ft (23 N•m) and tighten 1/2-in. tubing nuts to 28 lb-ft (38 N•m).

11. Two elbows (37)	Install on cylinder head (36).
12. Valve (46) and adapters (45) and (44)	Install on fuel pump (10).
13. Fuel supply tube (33)	Install on adapter (45) and elbow (37).
14. Fuel return tubes (31), (38), and (41), and tees (40) and (42)	Install on valve (46) and elbow (37).
15. Fuel return tube (43)	Install on tee (42) and fuel pump (10).

3-78. FUEL PUMP INSTALLATION (Contd)



NOTE: AIR AFTERCOOLER
MAY NOT YET BE INSTALLED;
REFER TO PARA. 3-87.

LEGEND:

- | | | | |
|----------------------------------------------|-----------------------------------------------------|----------------------|----------------------|
| 10. FUEL PUMP | 22. WASHER | 31. FUEL RETURN TUBE | 41. FUEL RETURN TUBE |
| 14. CLAMP | 23. SCREW | 32. CLAMP (3) | 42. TEE |
| 15. CHECK VALVE | 24. AIR TANK | 33. FUEL SUPPLY TUBE | 43. FUEL RETURN TUBE |
| 16. HOSE CLAMP (4) | 25. LOCKWASHER (3) | 34. ADAPTER | 44. ADAPTER |
| 17. NUT (2) | 26. WASHER (3) | 35. AIR AFTERCOOLER | 45. ADAPTER |
| 18. LOCKWASHER (2) | 27. BRACKET | 36. CYLINDER HEAD | 46. VALVE |
| 19. AIR SUPPLY HOSE
(M915/BIG CAM I ONLY) | 28. SCREW | 37. ELBOW (2) | 47. ADAPTER (3) |
| 20. ELBOW | 29. CLAMP (2) | 38. FUEL RETURN TUBE | |
| 21. SCREW | 30. AIR SUPPLY TUBE
(M915A1/BIG CAM III
ONLY) | 39. SCREW (2) | |
| | | 40. TEE | |

3-78. FUEL PUMP INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Fuel Supply Line Installation (Contd)


16. Two screws (39), new lockwashers (25), and washers (26)	Install on three clamps (32), clamp (29), and cylinder head (36).	
17. Adapter (47)	Install on fuel pump (10).	
18. Adapter (34)	Install on air aftercooler (35).	Air aftercooler (35) may not yet be installed. Refer to para. 3-87.
19. Air supply tube (30)	Install on adapters (47) and (34).	Air aftercooler (35) may not yet be installed. Refer to para. 3-87.

NOTE

Perform step 20 for M915A1/Big Cam III only.

20. Nut (17), new lockwasher (25), washer (26), and screw (28) (M915A1/Big Cam III)	Install on clamp (29) and bracket (27).	
21. Bracket (27)	Install on air aftercooler (35).	Air aftercooler (35) and ether starting kit must be installed prior to installation of bracket (27). Refer to para. 3-87 for air aftercooler (35) installation. Refer to TM 9-2320-283-20 for ether starting kit installation.

3-78. FUEL PUMP INSTALLATION (Contd)



NOTE: AIR AFTERCOOLER
MAY NOT YET BE INSTALLED;
REFER TO PARA. 3-87.

LEGEND:

- 10. FUEL PUMP
- 17. NUT (2)
- 25. LOCKWASHER (3)
- 26. WASHER (3)
- 27. BRACKET
- 28. SCREW
- 29. CLAMP (2)

- 30. AIR SUPPLY TUBE (M915A1/BIG CAM III ONLY)
- 32. CLAMP (3)
- 34. ADAPTER
- 35. AIR AFTERCOOLER
- 36. CYLINDER HEAD
- 39. SCREW (2)
- 47. ADAPTER (3)

3-78. FUEL PUMP INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Attenuator Air Tank Installation (M915/Big Cam I Only)


NOTE

- Perform steps 22 through 28 for M915/Big Cam I equipped with air supply attenuator air tank. Some Big Cam I engines may or may not have an ASA air tank.
- Air aftercooler must be installed to install air supply attenuator air tank. Refer to para. 3-87.

22. Clamp (14), screw (21), new lockwasher (18), and nut (17) (M915/Big Cam I)	Install on air tank (24).
23. Clamp (14) and air tank (24) (M915/Big Cam I)	Position on air aftercooler (35).
24. Screw (23), new lockwasher (18), and washer (22) (M915/Big Cam I)	Install on clamp (14) and air aftercooler (35).
25. Elbow (20) (M915/Big Cam I)	Install on air aftercooler (35).
26. Adapter (47) and checkvalve (15) (M915/Big Cam I)	Install on air tank (24).
27. Adapter (47) (M915/Big Cam I)	Install on fuel pump (10).
28. Two air supply hoses (19) and four hose clamps (16) (M915/Big Cam I)	a. Install one air supply hose (19) with two hose clamps (16) between adapter (47) on air tank (24) and adapter (47) on fuel pump (10). b. Install one air supply hose (19) with two hose clamps (16) between checkvalve (15) on air tank (24) and elbow (20) on air aftercooler (35).

- FOLLOW-ON TASKS:**
- Install fuel filter and water separator (TM 9-2320-273-20 or TM 9-2320-283-20).
 - Install fuel pump engine retarder switch (TM 9-2320-283-20).
 - Install vibration damper and crankshaft pulley (para. 3-79).

3-78. FUEL PUMP INSTALLATION (Contd)



NOTE: AIR AFTERCOOLER
MAY NOT YET BE INSTALLED;
REFER TO PARA. 3-87.

LEGEND:

- | | |
|-----------------------------------------------|---------------------|
| 10. FUEL PUMP | 20. ELBOW |
| 14. CLAMP | 21. SCREW |
| 15. CHECKVALVE | 22. WASHER |
| 16. HOSE CLAMP (4) | 23. SCREW |
| 17. NUT (2) | 24. AIR TANK |
| 18. LOCKWASHER (2) | 25. NUT (2) |
| 19. AIR SUPPLY HOSE (2) (M915/BIG CAM I ONLY) | 26. WASHER |
| | 27. SCREW |
| | 28. ELBOW |
| | 29. SCREW |
| | 30. SCREW |
| | 31. SCREW |
| | 32. SCREW |
| | 33. SCREW |
| | 34. SCREW |
| | 35. AIR AFTERCOOLER |
| | 36. SCREW |
| | 37. SCREW |
| | 38. SCREW |
| | 39. NUT (2) |
| | 40. SCREW |
| | 41. SCREW |
| | 42. SCREW |
| | 43. SCREW |
| | 44. SCREW |
| | 45. SCREW |
| | 46. SCREW |
| | 47. ADAPTER (3) |

3-79. VIBRATION DAMPER AND CRANKSHAFT PULLEY INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

REFERENCES (TM)

None

SPECIAL TOOLS

Two vibration damper guide pins
(Appendix D, Item 2)

TROUBLESHOOTING REFERENCES

Para. 2-8

TEST EQUIPMENT

None

EQUIPMENT CONDITION

Front gear cover installed (para. 3-75).

MATERIALS/PARTS

Oil, lubricating, OE/HDO 30
(Appendix C, Item 21)

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

PERSONNEL REQUIRED

Automotive repairman MOS 63H

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation

CAUTION

To avoid engine damage, ensure mounting surfaces of vibration damper and crankshaft are clean and dry. Do not get any lubricating oil on these surfaces.

1. Two vibration damper guide pins (5)	Install on two opposite holes in face of crankshaft (6).	See Item 2, Appendix D.
2. Crankshaft pulley (4) and vibration damper (3)	Install on two guide pins (5) and push onto crankshaft (6) until seated.	
3. Six screws (1) and washers (2)	a. Apply a coat of clean lubricating oil to threads of screws (1) and face of washers (2). b. Install on vibration damper (3), crankshaft pulley (4), and crankshaft (6).	Use OE/HDO 30 lubricating oil. Install four screws (1) and washers (2), then remove two guide pins (5) and install remaining two screws (1) and washers (2). Tighten screws (1) to 190 lb-ft (258 N•m).
4. Vibration damper (3)	a. Using dial indicator, measure movement on vibration damper (3) circumference by rotating crankshaft (6).	Total indicator reading must not exceed 0.004 in. (0.102 mm) per 1.0 in. (25.4 mm) of the damper diameter. Remove and discard vibration damper (3) if not within limits.


3-79. VIBRATION DAMPER AND CRANKSHAFT PULLEY INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Using dial indicator gauge, measure movement of vibration damper (3) face by rotating crankshaft (6).

Crankshaft (6) must be kept at front or rear limit of thrust clearance while measuring movement of vibration damper (3) face. Total indicator reading must not exceed 0.007 in. (0.178 mm) per 1.0 in. (25.4 mm) of the damper radius. Remove and discard vibration damper (3) if not within limits.

FOLLOW-ON TASK: Install flexplate or flywheel, flywheel housing, and rear cover (para. 3-80).



LEGEND:

- | | |
|---------------------|-----------------------------------|
| 1. SCREW (6) | 4. CRANKSHAFT PULLEY |
| 2. WASHER (6) | 5. VIBRATION DAMPER GUIDE PIN (2) |
| 3. VIBRATION DAMPER | 6. CRANKSHAFT |

3-80. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Crankshaft oil seal driver (15434) ST-997
 Dial gauge attachment (15434) ST-1325
 Dial indicator and sleeve assembly (15434) 3376050
 Two flywheel housing guide pins (Appendix D, Item 3)

TEST EQUIPMENT

None

MATERIALS/PARTS

Solvent, cleaning,
 Oil, lubricating, OE/DO 30 (Appendix C, Item 21)
 Gasket (15434) 40662-A
 Seal (15434) 211253
 Preformed packing (15434) 137075 (M915/Big Cam I)
 Eleven preformed packings (15434) 172648 (M915/Big Cam I)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Vibration damper and crankshaft pulley installed (para. 3-79).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation

CAUTION

All surfaces in contact with rear main seal must be completely free of oil. Oil on rear main seal will destroy its sealing properties.

<p>1. Rear cover (M915/Big Cam I) or cover (M915A1/Big Cam III) (2) and new gasket (1)</p>	<p>a. Clean oil seal area on crankshaft with an approved solvent. Refer to para. 3-6 for cleaning solvents.</p> <p>b. Install rear cover (M915/Big Cam I) or cover (M915A/Big Cam III) (2) and gasket (1) on cylinder block (11).</p> <p>c. Secure with eight screws (3).</p> <p>d. Using crankshaft oil seal driver (12), align rear cover (M915/Big Cam I) or cover (M915A1/Big Cam III) (2) with crankshaft.</p>	<p>Tighten screws (3) only enough to hold rear cover (M915/Big Cam I) or cover (M915A1/Big Cam III) (2) in position. Use crankshaft oil seal driver (ST-997) (12). Remove pins (10) from driver before using.</p>
--------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-80. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------




e. Using dial indicator (13), check alignment of rear cover (M915/Big Cam I) or cover (M915A1/Big Cam III) (2).

Must be on a common center with crankshaft within 0.010 in. (0.254 mm). Must be square to centerline of crankshaft within 0.010 in. (0.254 mm). Must be within 0.004 in. (0.102 mm) of being flat with oil pan flange of cylinder block (11).

f. Tighten eight screws (3) to 30-35 lb-ft (41-48 N•m).

g. Cut off excess gasket (1) material.

Gasket (1) must be even with or not more than 0.010 in. (0.254 mm) above oil pan flange.



LEGEND:

- 1. GASKET
- 2. REAR COVER (M915/BIG CAM I), COVER (M915A1/BIG CAM III)
- 3. SCREW (8)
- 4. SEAL
- 5. PREFORMED PACKING (11) (M915/BIG CAM I)
- 6. FLYWHEEL HOUSING

- 7. SCREW (9)
- 8. WASHER (9)
- 9. PREFORMED PACKING (M915/BIG CAM I)
- 10. DOWEL PIN (2)
- 11. CYLINDER BLOCK
- 12. CRANKSHAFT OIL SEAL DRIVER
- 13. DIAL INDICATOR

3-80. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

NOTE

- **New rear main seals have an assembly tool which protects seal lip during shipment and installation.**
- **Do not use any lubricant to install seal. Oil seal must be installed with lip of seal and crankshaft clean and dry.**

2. New seal (4) (with assembly tool)	a. Install on crankshaft. b. Push seal (4) from assembly tool onto crankshaft. c. Using crankshaft rear oil seal driver (12), drive seal (4) on rear cover (M915/Big Cam I) or cover (M915A1/Big Cam III) (2).	Position largest diameter of assembly tool toward cylinder block (11). Remove and discard assembly tool. Use crankshaft oil seal driver (ST-997) (12). Install pins on driver before using.
--------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

CAUTION

If a new flywheel housing is being installed, dowel pins must be removed from cylinder block prior to installing housing to prevent damage to housing. The housing must be doweled with oversize dowel pins after alignment.

3. Two dowel pins (10)	Remove dowel pins (10) if installing new flywheel housing (6) and dowel is damaged or outside diameter is less than 0.5005 in. (12.713 mm).	
------------------------	---------------------------------------------------------------------------------------------------------------------------------------------	--

NOTE

- **M915/Big Cam I engines are equipped with a wet flywheel housing which utilizes preformed packings between flywheel housing and cylinder block.**
- **Perform steps 4b and 4c for M915/Big Cam I only.**


4. Flywheel housing (6)	a. Install two flywheel housing guide pins on cylinder block (11). b. For wet-type flywheel housings (M915/Big Cam I), install new preformed packing (9) on crankshaft flange.	Guide pins are used to support flywheel housing (6) (see Appendix D, Item 3). Lubricate preformed packing (9) with OE/HDO 30 oil prior to installation.
-------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------

CAUTION

If engine is to be tested with dynamometer, preformed packing must not be installed on crankshaft until after test. Dry-running will destroy this seal.

c. For wet-type flywheel housing (M915/Big Cam I), install eleven new preformed packings (5) on flywheel housing (6) (M915/Big Cam I). d. Install flywheel housing (6) on cylinder block (11) with seven screws (7) and washers (8).	Use an approved gasket adhesive to seal preformed packings (5) to flywheel housing (6) and cylinder block (11). Tighten screws (7) to 10-20 lb-ft (14-27 N•m).
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-80. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER INSTALLATION (Contd)



LEGEND:

- 2. REAR COVER (M915/BIG CAM I), COVER (M915A1/BIG CAM III)
- 4. SEAL
- 5. PREFORMED PACKING (11) (M915/BIG CAM I)
- 6. FLYWHEEL HOUSING
- 7. SCREW (9)
- 8. WASHER (9)

- 9. PREFORMED PACKING (M915/BIG CAM I)
- 10. DOWEL PIN (2)
- 11. CYLINDER BLOCK
- 12. CRANKSHAFT OIL SEAL DRIVER
- 13. DIAL INDICATOR AND SLEEVE ASSEMBLY
- 14. DIAL GAUGE ATTACHMENT


3-80. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

<p>4. Flywheel housing (6) (Contd)</p>	<p>e. Remove two flywheel housing guide pins and install two remaining screws (7) and washers (8).</p> <p>f. Check location of bore as follows:</p> <p>(1) Install dial gauge attachment (14) and dial indicator and sleeve assembly (13).</p> <p>(2) Using chalk, mark housing at 12, 3, 6, and 9 o'clock positions.</p> <p>(3) Check readings at 3 o'clock and 9 o'clock positions.</p> <p>(4) Check readings at 12 o'clock and 6 o'clock positions.</p> <p>(5) Check circumference of bore. Use a prybar to move the housing.</p> <p>(6) After readings are within limits, tighten screws (7) to 140-160 lb-ft (190-217 N•m) as shown in tightening sequence (15).</p> <p>g. Check alignment of flywheel housing (6) as follows:</p> <p>(1) Adjust dial indicator and sleeve assembly (13) to measure alignment of face on flywheel housing (6).</p> <p>(2) Push crankshaft toward front of cylinder block (11) to remove crankshaft end clearance.</p> <p>(3) Rotate crankshaft and check alignment of face on flywheel housing (6).</p> <p>h. If dowel pins (10) were removed from cylinder block (11), use a drill and fixture to ream dowel holes to next oversize and install two new dowel pins (10) if required.</p>	<p>Tighten screws (7) to 10-20 lb-ft (14-27 N•m).</p> <p>Use dial gauge attachment (ST-1325) (14) and dial indicator and sleeve assembly (3376050) (13).</p> <p>If runout exceeds 0.008 in. (0.203 mm), move flywheel housing (6) horizontally one-half distance of total indicator reading. Use prybars to move housing.</p> <p>If runout exceeds 0.008 in. (0.203 mm), move flywheel housing (6) vertically one-half distance of total indicator reading. Use prybars to move housing.</p> <p>Total indicator reading must not exceed 0.008 in. (0.203 mm). Adjust flywheel housing (6) until within limit.</p> <p>Use prybars to move flywheel housing (6).</p> <p>Ensure crankshaft is pushed toward front of cylinder block (11) when checking alignment. Total indicator reading must not exceed 0.008 in. (0.203 mm). If alignment is not within limits, remove flywheel housing (6) and check mating surfaces.</p>
----------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-80. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER INSTALLATION (Contd)



LEGEND:

- 6. FLYWHEEL HOUSING
- 7. SCREW (9)
- 8. WASHER (9)
- 10. DOWEL PIN (2)

- 11. CYLINDER BLOCK
- 13. DIAL INDICATOR AND SLEEVE ASSEMBLY
- 14. DIAL GAUGE ATTACHMENT
- 15. TIGHTENING SEQUENCE (FLYWHEEL HOUSING SCREWS)

3-80. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

NOTE

- M915A1/Big Cam III engines are equipped with a flexplate-type flywheel with retaining plate and washer bearing. Perform step 5 for M915A1/Big Cam III only.
- Perform steps 6, 7, 8, and 9 for M915/Big Cam I only.


5. Retaining plate (16), flexplate (17), and washer bearing (18)	a. Install on crankshaft. b. Install six screws (20) and washers (19).	Apply thin coat of lubricating oil to threads of screws (20) and face of washers (19) prior to installing. Tighten screws to 200-220 lb-ft (271-298 N•m) as shown in tightening sequence (21).
------------------------------------------------------------------	-------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

CAUTION

If engine is to be tested with dynamometer, wet seal must not be installed until after test. Dry-running will destroy this seal.

6. Wet clutch seal and seal carrier (M915/Big Cam I)	a. Press new seal on seal carrier with spring-loaded sealing lip facing flywheel until seated in carrier. b. Install seal carrier with new gasket on flywheel housing (6) with Nylok screws. Using indicator, center seal carrier to crankshaft. Carrier must be centered within 0.006 in. (0.152 mm) Total Indicator Reading (TIR). c. Tighten screws for seal carrier-to-flywheel housing to 97 lb-in. (11 N•m). If access cover plate was removed, install with copper washers and screws.	
------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

3-80. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER INSTALLATION (Contd)



M915A1/BIG CAM III
SHOWN

LEGEND:

- | | |
|-----------------------------------------|---------------------------------------------------------------|
| 6. FLYWHEEL HOUSING | 19. WASHER (6) |
| 16. RETAINING PLATE (M915/BIG CAM I) | 20. SCREW (6) (M915/BIG CAM I) |
| 17. FLEXPLATE (M915A1/BIG CAM III) | 21. TIGHTENING SEQUENCE (FLEXPLATE TO CRANK-
SHAFT SCREWS) |
| 18. WASHER BEARING (M915A1/BIG CAM III) | |

3-80. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER INSTALLATION (Contd)


LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

<p>7. Flywheel (22) and ring gear (23)</p>	<p>a. Install two 5/8-18 x 6 in. studs on opposite holes on crankshaft to function as guides. Install studs on crankshaft until fully seated.</p> <p>b. Lubricate threads of screws (26) and face of washers (27) with lubricating oil. Allow excess oil to drain from screw threads.</p> <p>c. Install four screws (26) and washers (27) on flywheel (22) and crankshaft flange. Tighten screws (26) as shown in tightening sequence (21) until flywheel (22) is seated against crankshaft flange.</p> <p>d. Remove two 5/8-18 x 6 in. studs from crankshaft flange and flywheel (22). Install two remaining screws (26) and washers (27) through flywheel (22) and into crankshaft flange until seated.</p> <p>e. Using tightening sequence (21), tighten all screws (26) to 70 lb-ft (95 N•m), then to 140 lb-ft (190 N•m), and finally to 200-220 lb-ft (271-298 N•m).</p>	<p>Use OE/HDO 30 lubricating oil.</p>
--------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------

3-80. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER INSTALLATION (Contd)

M915/BIG CAM I
SHOWN



LEGEND:

21. TIGHTENING SEQUENCE (FLYWHEEL TO CRANK-SHAFT SCREWS)

22. FLYWHEEL (M915/BIG CAM I)

23. RING GEAR (M915/BIG CAM I)

26. SCREW (6) (M915/BIG CAM I)

27. WASHER (6)

3-80. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)



NOTE

- The flywheel must be pushed toward front of engine to remove crankshaft end clearance when crankshaft is rotated and measurements are taken.
- If total indicator readings exceed limits listed in steps 8 and 9, remove flywheel; clean flywheel and crankshaft flange faces, install, and repeat runout checks.


8.	Inspect flywheel (22) bore runout (M915/Big Cam I)	a. Install dial gauge attachment (14) and dial indicator and sleeve assembly (13) on flywheel housing (6). Position contact tip of dial indicator against wide diameter of flywheel bore and set dial indicator to zero. b. Use accessory drive shaft to rotate crankshaft one complete revolution.	Use dial gauge attachment (ST-1325) and dial indicator and sleeve assembly (3376050). Total indicator reading must not exceed 0.005 in. (0.127 mm).
9.	Inspect flywheel (22) face runout (M915/Big Cam I)	a. Install or reposition dial indicator and sleeve assembly (13) on flywheel housing (6). Position contact tip of dial indicator against face of flywheel (22) as close to outside diameter as possible. b. Use accessory drive shaft to rotate crankshaft one complete revolution.	Use dial indicator and sleeve assembly (3376050). Total indicator reading must not exceed 0.005 in. (0.127 mm).

FOLLOW-ON TASK: Install oil pan (para. 3-81).

3-80. FLEXPLATE OR FLYWHEEL, FLYWHEEL HOUSING, AND REAR COVER INSTALLATION (Contd)



**M915/BIG CAM I FLYWHEEL
BORE RUNOUT CHECK**



**M915/BIG CAM I FLYWHEEL
FACE RUNOUT CHECK**

LEGEND:

- 6. FLYWHEEL HOUSING
- 13. DIAL INDICATOR AND SLEEVE ASSEMBLY

- 14. DIAL GAUGE ATTACHMENT
- 22. FLYWHEEL (M915/BIG CAM I)

3-81. OIL PAN INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

- Grease, automotive and artillery, GAA (Appendix C, Item 13)
- Gasket and seal kit (15434) 3801235
- Four lockwashers (96906) MS35338-45
- Four lockwashers (96906) MS35338-47 (M915A1/Big Cam III), (one M915/Big Cam I)
- Two lockwashers (96906) MS35338-48
- Two lockwashers (15434) S-608 (M915/Big Cam I)
- Lockwasher (15434) S-610 (M915/Big Cam I)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

- TM 9-2320-273-20
- TM 9-2320-273-34

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

- Front gear cover installed (para. 3-75).
- Flexdisk or flywheel, flywheel housing, and rear cover installed (para. 3-80).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------



Installation

NOTE


- Do not rotate engine more than 90 from an upright position during oil pan installation. Otherwise, pushrods could fall out. If any pushrods fall out, refer to para. 3-71 to install.
- For M915/Big Cam I only, it may be necessary to refer to TM 9-2320-273-34, installation of engine oil heater. For engine oil heater thermostat installation, refer to TM 9-2320-273-20.
- Installation of oil pan is similar between M915/Big Cam I and M915A1/Big Cam III engines. M915/Big Cam I engines use a cast aluminum oil pan that is mounted to the flywheel housing with additional fasteners. M915A1/Big Cam III engines use a stamped steel oil pan that does not mount with flywheel housing.
- Perform steps 7, 9, 12, 13, and 14 for M915/Big Cam I only.

- | | |
|---------------------------|-----------------------------------------------------------------------------------|
| 1. Cylinder block (1) | Apply a thin coat of GAA grease to oil pan mounting surface. |
| 2. New oil pan gasket (2) | Line up holes with holes in cylinder block (1) and install on cylinder block (1). |

3-81. OIL PAN INSTALLATION (Contd)



M915/BIG CAM I OIL PAN (CAST ALUMINUM)



M915A1/BIG CAM III OIL PAN (STAMPED STEEL)

LEGEND:

- | | | |
|--------------------------------------------------------------|-----------------------------------------------------|-------------------------------------|
| 1. CYLINDER BLOCK | 13. SCREW (2) (M915A1/BIG CAM III) | 26. SCREW (2) (M915/BIG CAM I) |
| 2. OIL PAN GASKET | 14. SCREW (4) (M915A1/BIG CAM III) | 27. LOCKWASHER (2) (M915/BIG CAM I) |
| 3. OIL PAN (M915A1/BIG CAM III) | 15. ENGINE SHIPPING SUPPORT | 28. SCREW (M915/BIG CAM I) |
| 4. WASHER (4) | 16. OIL PUMP | 29. CLAMP (M915/BIG CAM I) |
| 5. LOCKWASHER (4) | 17. GASKET | 30. SPACER (M915/BIG CAM I) |
| 6. SCREW (4) | 18. SCREW (4) (M915/BIG CAM I) | 31. BRACKET (M915/BIG CAM I) |
| 7. SCREW (2) (M915A1/BIG CAM III) | 19. WASHER (4) (M915/BIG CAM I) | 32. SCREW (M915/BIG CAM I) |
| 8. LOCKWASHER (1) (M915/BIG CAM I), (4) (M915A1/BIG CAM III) | 20. FLYWHEEL HOUSING | 33. LOCKWASHER (M915/BIG CAM I) |
| 9. WASHER (1) (M915/BIG CAM I), (4) (M915A1/BIG CAM III) | 21. SCREW (2) (M915/BIG CAM I) | 34. NUT (M915/BIG CAM I) |
| 10. OIL SUCTION TUBE (METALLIC) (M915A1/BIG CAM III) | 22. WASHER (4) (M915/BIG CAM I) | 35. ADAPTER (M915/BIG CAM I) |
| 11. PREFORMED PACKING (2) (M915A1/BIG CAM III) | 23. LOCKWASHER (2) (M915/BIG CAM I) | 36. SCREW (4) (M915/BIG CAM I) |
| 12. SCREW (28) | 24. NUT (2) (M915/BIG CAM I) | 37. OIL PAN (M915/BIG CAM I) |
| | 25. OIL SUCTION HOSE (NONMETALLIC) (M915/BIG CAM I) | |

3-81. OIL PAN INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)


- | | | | |
|----|-----------------------------------------------------------|-----------------------------------------------------------------------------------------------|-------------------------------------|
| 3. | Oil pan (3) (M915A1/Big Cam III) or (37) (M915/Big Cam I) | Position on oil pan gasket (2) and cylinder block (1). | |
| 4. | Twenty-eight screws (12) | Install on oil pan (3) (M915A11 Big Cam III) or (37) (M915/Big Cam I) and cylinder block (1). | Do not tighten screws at this time. |
| 5. | Four screws (6), new lock-washers (5), and washer (4) | Install on oil pan (3) (M915A1/Big Cam III) or (37) (M915/Big Cam I) and rear cover. | Do not tighten screws at this time. |

NOTE

Two of the four screws may have been eliminated on newer M915A1/Big Cam III oil pans.

- | | | | |
|----|---------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 6. | Engine shipping support (15) | Install on front of oil pan (3) (M915A1/Big Cam III) or (37) (M915/Big Cam I) with four screws (14) (M915A1/Big Cam III) or four screws (36) (M915/Big Cam I). | Do not tighten screws at this time. |
| 7. | Two screws (18) and washers (19) (M915/Big Cam I) | Install on middle holes of flywheel housing (20) and oil pan (37). | Use middle three holes on each side of flywheel housing (20). This step ensures proper location of oil pan (37) during initial assembly. Do not tighten screws at this time. |
| 8. | Two screws (12) | Finger-tighten one screw (12) on each side of oil pan flange, in a position located halfway between front and rear of oil pan (3) (M915A1/Big Cam III) or (37) (M915/Big Cam I). | |
| 9. | Two screws (18) and washers (19) (M915/Big Cam I) | Remove from middle holes of flywheel housing (20) and oil pan (37). | This step is necessary to provide clearance to perform step 10. |

3-81. OIL PAN INSTALLATION (Contd)



M915/BIG CAM I OIL PAN (CAST ALUMINUM)

LEGEND:

- 1. CYLINDER BLOCK
- 2. OIL PAN GASKET
- 3. OIL PAN (M915A1/BIG CAM III)
- 4. WASHER (4)
- 5. LOCKWASHER (4)
- 6. SCREW (4)
- 12. SCREW (28)


M915A1/BIG CAM III OIL PAN (STAMPED STEEL)

- 14. SCREW (4) (M915A1/BIG CAM III)
- 15. ENGINE SHIPPING SUPPORT
- 18. SCREW (4) (M915/BIG CAM I)
- 19. WASHER (4) (M915/BIG CAM I)
- 20. FLYWHEEL HOUSING
- 36. SCREW (4) (M915/BIG CAM I)
- 37. OIL PAN (M915/BIG CAM I)

3-81. OIL PAN INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Installation (Contd)		
10. Four screws (12)	Finger-tighten two screws (12) on each side of oil pan rear corner.	
11. Twenty-eight screws (12) and four screws (14) (M915AII Big Cam III) or (36) (M915/Big Cam I)	Tighten on oil pan (3) (M915/Big Cam III) or (37) (M915/Big Cam I) to cylinder block (1) and front cover.	Tighten screws to 35-40 lb-ft (41-48 N•m).
12. Four screws (18) and washers (19)	Install on flywheel housing (20) (M915/Big Cam I) and oil pan (37).	Do not tighten screws at this time.
13. Two screws (21), four washers (22), new lock-washers (23), and nuts (24) (M915/Big Cam I)	Install on oil pan (37) and flywheel housing (20).	
14. Four screws (18) and two nuts (24) (M915/Big Cam I)	Install on flywheel housing (20) and oil pan (37).	Tighten screws to 70-80 lb-ft (95-109 N•m).
15. Four screws (6), new lockwashers (5), and washers (4)	Install on oil pan (37).	Tighten screws to 15-20 lb-ft (20-27 N•m).

3-81. OIL PAN INSTALLATION (Contd)



M915/BIG CAM I OIL PAN (CAST ALUMINUM)

M915A1/BIG CAM III OIL PAN (STAMPED STEEL)

LEGEND:

- 1. CYLINDER BLOCK
- 3. OIL PAN (M915A1/BIG CAM III)
- 4. WASHER (4)
- 5. LOCKWASHER (4)
- 6. SCREW (4)
- 12. SCREW (28)
- 14. SCREW (4) (M915A1/BIG CAM III)
- 18. SCREW (4) (M915/BIG CAM I)

- 19. WASHER (4) (M915/BIG CAM I)
- 20. FLYWHEEL HOUSING
- 21. SCREW (2) (M915/BIG CAM I)
- 22. WASHER (4) (M915/BIG CAM I)
- 23. LOCKWASHER (2) (M915/BIG CAM I)
- 24. NUT (2) (M915/BIG CAM I)
- 26. SCREW (4) (M915/BIG CAM I)
- 27. SCREW (4) (M915/BIG CAM I)
- 28. SCREW (4) (M915/BIG CAM I)
- 29. SCREW (4) (M915/BIG CAM I)
- 30. SCREW (4) (M915/BIG CAM I)
- 31. SCREW (4) (M915/BIG CAM I)
- 32. SCREW (4) (M915/BIG CAM I)
- 33. SCREW (4) (M915/BIG CAM I)
- 34. SCREW (4) (M915/BIG CAM I)
- 35. SCREW (4) (M915/BIG CAM I)
- 36. SCREW (4) (M915/BIG CAM I)

3-81. OIL PAN INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


Installation (Contd)

NOTE

- M915/Big Cam I engines use a two-piece nonmetallic oil suction hose assembly consisting of an oil pan mounting flange and a flexible oil suction hose. M915A1/Big Cam III engines use a metallic oil suction tube.
- Perform steps 16 and 17 for M915A1/Big Cam III only.
- Perform steps 18 through 26 for M915/Big Cam I only.

16. New gasket (17) and two new preformed packings (11) (M915A1/Big Cam III)	Position on oil suction tube (10) and position assembly on oil pan (3) and oil pump (16).	
17. Oil suction tube (10), two screws (7), screws (13), four new lockwashers (8), and washers (9) (M915A1/Big Cam III)	a. Install on oil pan (3) and oil pump (16). b. Tighten screws to 30-35 lb-ft (41-48 N•m).	Tighten screws (7) before screws (13).
18. Oil suction hose (25) and new gasket (17) (M915/Big Cam I)	Install on oil pan (37) with two new lockwashers (27) and screws (26).	Do not tighten screws (26) at this time.

3-81. OIL PAN INSTALLATION (Contd)



M915/BIG CAM I OIL PAN (CAST ALUMINUM)

M915A1/BIG CAM III OIL PAN (STAMPED STEEL)

LEGEND:

- 3. OIL PAN (M915A1/BIG CAM III)
- 7. SCREW (2) (M915A1/BIG CAM III)
- 8. LOCKWASHER (1) (M915/BIG CAM I), (4) (M915A1/BIG CAM III)
- 9. WASHER (1) (M915/BIG CAM I), (4) (M915A1/BIG CAM III)
- 10. OIL SUCTION TUBE (METALLIC) (M915A1/BIG CAM III)
- 11. PREFORMED PACKING (2) (M915A1/BIG CAM III)

- 13. SCREW (2) (M915A1/BIG CAM III)
- 16. OIL PUMP
- 17. GASKET
- 25. OIL SUCTION HOSE (NONMETALLIC) (M915/BIG CAM I)
- 26. SCREW (2) (M915/BIG CAM I)
- 27. LOCKWASHER (2) (M915/BIG CAM I)
- 37. OIL PAN (M915/BIG CAM I)


3-81. OIL PAN INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

19. Adapter (35) and oil suction hose (25) (M915/Big Cam I)	Install on oil pump (16) and hand-tighten hose nut until snug, then tighten nut an additional 1 to 1-1/4 turn.	
20. Two screws (26) (M915/Big Cam I)	Tighten to 30-35 lb-ft (41-48 N•m).	
21. Oil suction hose (25) (M915/Big Cam I)	Tighten nut on oil suction hose (25) mounting flange until nut is against stop on mounting flange.	
22. Screw (12) (M915/Big Cam I)	Remove one screw (12) from left side flange of oil pan (37).	Remove sixth screw from front of flange on left side of oil pan (37).
23. Bracket (31), screw (32), and new lockwasher (33) (M915/Big Cam I)	<p>a. Install on sixth hole from front on left side of oil pan (37).</p> <p>b. Tighten screw to 35-40 lb-ft (41-48 N•m).</p>	

3-81. OIL PAN INSTALLATION (Contd)



M915/BIG CAM I OIL PAN (CAST ALUMINUM)

M915A1/BIG CAM III OIL PAN (STAMPED STEEL)

LEGEND:

- 12. SCREW (28)
- 16. OIL PUMP
- 25. OIL SUCTION HOSE (NONMETALLIC) (M915/BIG CAM I)
- 26. SCREW (2) (M915/BIG CAM I)


- 31. BRACKET (M915/BIG CAM I)
- 32. SCREW (M915/BIG CAM I)
- 33. LOCKWASHER (M915/BIG CAM I)
- 35. ADAPTER (M915/BIG CAM I)
- 37. OIL PAN (M915/BIG CAM I)

3-81. OIL PAN INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
Installation (Contd)		
24. Clamp (29) (M915/Big Cam I)	Position on oil suction hose (25).	
25. Spacer (30) (M915/Big Cam I)	Position between bracket (31) and clamp (29).	
26. Screw (28), new lockwasher (8), washer (9), and nut (34) (M915/Big Cam I)	Install on bracket (31) and clamp (29).	Ensure oil suction hose (25) is supported properly and is not pinched or binding.

FOLLOW-ON TASK: Install injector assemblies (para. 3-82).

3-81. OIL PAN INSTALLATION (Contd)



M915/BIG CAM I OIL PAN (CAST ALUMINUM)

M915A1/BIG CAM III OIL PAN (STAMPED STEEL)

LEGEND:

- 8. LOCKWASHER (M915/BIG CAM I)
- 9. WASHER (M915/BIG CAM I)
- 25. OIL SUCTION HOSE (NONMETALLIC) (M915/BIG CAM I)
- 28. SCREW (M915/BIG CAM I)

- 29. CLAMP (M915/BIG CAM I)
- 30. SPACER (M915/BIG CAM I)
- 31. BRACKET (M915/BIG CAM I)
- 34. NUT (M915/BIG CAM I)

3-82. INJECTOR ASSEMBLY INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Injector puller (15434) 3376872

TEST EQUIPMENT

None

MATERIALS/PARTS

Oil, lubricating OE/HDO 10
(Appendix C, Item 20)

Three preformed packings (15434) 193736

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Injection timing completed (para. 3-72).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

CAUTION

If injector assembly fails to seat completely, remove and check for a twisted or damaged preformed packing (O-ring).


NOTE

- Inspect fuel cooling sleeve in cylinder head prior to installing injector. Remove any dirt with a lint-free cloth.
- The following procedure involves installation of one injector assembly. Installation of remaining five is similar.
- Ensure injector assemblies are installed in same location as noted during removal.

Installation

- | | | | |
|----|------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. | Three new preformed packings (3) and injector assembly (M915/Big Cam I) or fuel injection nozzle assembly (M915A1/Big Cam III) (7) | Lubricate lightly with OE/HDO 10 lubricating oil. | |
| 2. | Injector assembly (M915/Big Cam I) or fuel injection nozzle assembly (M915/Big Cam III) (7) | Install on fuel cooling sleeve (4) of cylinder head assembly (5). | Align filter screen of fuel inlet (6) hole so that it is toward exhaust side of the cylinder head assembly (5). Use injector puller (3376872) for installation. A snap should be heard and felt as injector assembly (M915/Big Cam I) or fuel injection nozzle assembly (M915A1/Big Cam III) (7) seats in fuel cooling sleeve (4) of cylinder head assembly (5). |

3-82. INJECTOR ASSEMBLY INSTALLATION (Contd)



LEGEND:

- | | |
|-------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| 1. DETENT PLUNGER | 5. CYLINDER HEAD ASSEMBLY |
| 2. RETAINING PLATE (M915/BIG CAM I) OR CLAMP (M915A1/BIG CAM III) | 6. FUEL INLET |
| 3. PREFORMED PACKING (3) | 7. INJECTOR ASSEMBLY (M915/BIG CAM I) OR FUEL INJECTION NOZZLE ASSEMBLY (M915A1/BIG CAM III) |
| 4. FUEL COOLING SLEEVE | 8. SCREW (2) |

3-82. INJECTOR ASSEMBLY INSTALLATION (Contd)


LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

- | | | |
|------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| 3. Retaining plate (M915/
Big Cam I) or clamp
(M915A1/Big Cam III) (2) | Install on injector assembly
(M915A1/Big Cam I) or fuel
injection nozzle assembly (M915A1/
Big Cam III) (7). | |
| 4. Detent plunger (1) | Install on top of injector
assembly (M915/Big Cam I) or
fuel injection nozzle assembly
(M915A1/Big Cam III) (7). | |
| 5. Two screws (8) | Install and tighten in steps of
5 lb-ft (7 N•m) until a final torque
of 12 lb-ft (16 N•m) is obtained. | |
| 6. Detent plunger (1) | Check for free movement after
tightening. If detent plunger (1)
does not move freely, loosen two
screws (8) and retighten. Detent
plunger (1) must move freely. | |

FOLLOW-ON TASK: Install and adjust valve crossheads (para. 3-83).

3-82. INJECTOR ASSEMBLY INSTALLATION (Contd)



LEGEND:

1. DETENT PLUNGER
2. RETAINING PLATE (M915/BIG CAM I) OR CLAMP (M915A1/BIG CAM III)
7. INJECTOR ASSEMBLY (M915/BIG CAM I) OR FUEL INJECTION NOZZLE ASSEMBLY (M915A1/BIG CAM III)
8. SCREW (2)

3-83. VALVE CROSSHEADS INSTALLATION AND ADJUSTMENT

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

REFERENCES (TM)

None

SPECIAL TOOLS

Torque driver (15434) ST-669

TROUBLESHOOTING REFERENCES

Para. 2-8

TEST EQUIPMENT

None

EQUIPMENT CONDITION

Injectors installed (para. 3-82).

MATERIALS/PARTS

Oil, lubricating, OE/HDO 10
(Appendix C, Item 20)

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

PERSONNEL REQUIRED

Automotive repairman MOS 63H

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation

NOTE

- There is one intake valve crosshead and one exhaust valve crosshead per cylinder, or two each per cylinder head.
- The following procedure involves installation and adjustment of one exhaust and one intake valve crosshead. Installation and adjustment of remaining valve crossheads is similar.


- | | | |
|----|-----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|
| 1. | Four valve stems (1), intake valve crosshead guide (7), and exhaust valve crosshead guide (8) | Lubricate valve stem ends and entire valve crosshead guides (7) and (8) with OE/HDO 10 lubricating oil. |
|----|-----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|

CAUTION

The exhaust valve crossheads and intake valve crossheads are different. The exhaust valve crosshead is wider and has a drilled oil passage hole through the top. Improper installation may result in engine damage.

- | | | | |
|----|-----------------------------|-----------------------------------------------|----------------------------------------------------------------------------------|
| 2. | Exhaust valve crosshead (2) | Install on exhaust valve crosshead guide (8). | Adjusting screw (3) and locking nut (4) must be towards exhaust and water ports. |
| 3. | Intake valve crosshead (5) | Install on intake valve crosshead guide (7). | Adjusting screw (3) and locking nut (4) must be towards exhaust and water ports. |

3-83. VALVE CROSSHEADS INSTALLATION AND ADJUSTMENT (Contd)



LEGEND:

- 1. VALVE STEM (4)
- 2. EXHAUST VALVE CROSSHEAD
- 3. ADJUSTING SCREW
- 4. LOCKING NUT

- 5. INTAKE VALVE CROSSHEAD
- 6. CROSSHEAD CLEARANCE (4)
- 7. INTAKE VALVE CROSSHEAD GUIDE
- 8. EXHAUST VALVE CROSSHEAD GUIDE

3-83. VALVE CROSSHEADS INSTALLATION AND ADJUSTMENT (Contd)


LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

4. Two locking nuts (4) and adjusting screws (3)	Loosen one full turn.	
5. Two exhaust valves and two intake valve adjusting screws (3)	Adjust as follows:	
	a. Using light pressure, hold exhaust valve crosshead (2) or intake valve crosshead (5) against valve stem (1). Turn exhaust or intake valve adjusting screw (3) until it touches valve stem (1), but does not raise exhaust valve crosshead (2) or intake valve crosshead (5).	The adjustment procedure for exhaust valve crosshead (2) is the same for intake valve crosshead (5).
	b. Hold adjusting screw (3) and tighten locking nut (4) to 25 lb-ft (34 N•m).	Use a round and a flat feeler gauge to check the crosshead clearances (6) at four locations. Refer to illustration. There must be a minimum of 0.025 in. (0.635 mm) clearance (6) between exhaust valve crosshead (2), intake valve crosshead (5), and valve spring retainers.
	c. Recheck clearance.	

FOLLOW-ON TASK: Install rocker arm housing assembly (para. 3-84).

3-83. VALVE CROSSHEADS INSTALLATION AND ADJUSTMENT (Contd)



LEGEND:

- 1. VALVE STEM (4)
- 2. EXHAUST VALVE CROSSHEAD
- 3. ADJUSTING SCREW (2)

- 4. LOCKING NUT (2)
- 5. INTAKE VALVE CROSSHEAD
- 6. CROSSHEAD CLEARANCE (4)

3-84. ROCKER ARM HOUSING ASSEMBLY INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Gasket (15434) 3017750

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Valve crossheads installed and adjusted (para. 3-83)

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


Installation

NOTE

The following procedure covers the installation of one rocker arm housing assembly. The installation of the remaining rocker arm housing assemblies is similar.

- | | | | |
|----|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|
| 1. | New gasket (4) | Install on cylinder head assembly (5). | |
| 2. | Six adjusting screws (2) | Loosen three complete turns. | The six adjusting screws (2) must be loose before installing rocker arm housing assembly (3). |
| 3. | Rocker arm housing assembly (3) | Install on new gasket (4) and cylinder head assembly (5). Position the six rocker assembly levers (9) so ball end of adjusting screw (2) drops into sockets of six pushrods (8). | |

3-84. ROCKER ARM HOUSING ASSEMBLY INSTALLATION (Contd)



LEGEND:

- | | |
|----------------------------------------------------|----------------------------------------------------------|
| 1. ROCKER HOUSING STUD 8-5/8 IN. (2 PER ENGINE) | 8. PUSHROD (6 PER ROCKER HOUSING ASSEMBLY) |
| 2. ADJUSTING SCREW (6 PER ROCKER HOUSING ASSEMBLY) | 9. ROCKER ASSEMBLY LEVER (6 PER ROCKER HOUSING ASSEMBLY) |
| 3. ROCKER ARM HOUSING ASSEMBLY | 10. WASHER BEARING (6 PER ROCKER HOUSING ASSEMBLY) |
| 4. GASKET | 11. INSTALLATION SEQUENCE |
| 5. CYLINDER HEAD ASSEMBLY | 12. TIGHTENING SEQUENCE |
| 6. ROCKER HOUSING STUD 7 IN. (12 PER ENGINE) | |
| 7. ROCKER HOUSING STUD 8-1/8 IN. (4 PER ENGINE) | |

3-84. ROCKER ARM HOUSING ASSEMBLY INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

- | | | |
|-----------------------------|---------------------------------------------|--|
| 4. Six washer bearings (10) | Install on rocker arm housing assembly (3). | |
|-----------------------------|---------------------------------------------|--|


CAUTION

There are three different sizes of rocker housing studs. Install correct rocker housing stud in correct rocker arm housing assembly. Damage to rocker housing stud threads will result if substitution of length is made. See illustration for proper locations.

- | | | |
|-----------------------------------------------|---------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| 5. Six rocker housing studs (1), (6), and (7) | Install and tighten to 65 lb-ft (88 N•m) as shown in installation sequence (11) and tightening sequence (12). | The center and rear rocker arm housing assemblies do not use the 8-5/8 in. long rocker housing stud (1). |
|-----------------------------------------------|---------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|

FOLLOW-ON TASK: Perform injector and valve adjustment (para. 3-85).

3-84. ROCKER ARM HOUSING ASSEMBLY INSTALLATION (Contd)



LEGEND:

- 1. ROCKER HOUSING STUD 8-5/8 IN. (2 PER ENGINE)
- 3. ROCKER ARM HOUSING ASSEMBLY
- 6. ROCKER HOUSING STUD 7 IN. (12 PER ENGINE)
- 7. ROCKER HOUSING STUD 8-1/8 IN. (4 PER ENGINE)

- 10. WASHER BEARING (6 PER ROCKER HOUSING ASSEMBLY)
- 11. INSTALLATION SEQUENCE
- 12. TIGHTENING SEQUENCE

3-85. INJECTOR AND VALVE ADJUSTMENT

THIS TASK COVERS:

Adjustment

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Torque driver (15434) ST-669

TEST EQUIPMENT

None

MATERIALS/PARTS

None

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Rocker arm housing assembly installed (para. 3-84).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Adjustment

CAUTION

Injector specifications and valve clearances given are for a cold engine only. Do not use these specifications or clearances for a warm or hot engine or damage will result to related parts.

NOTE


- Engine cylinders are numbered in sequence, starting at front with No. 1 cylinder. The engine firing order is 1-5-3-6-2-4.
- The valves and injectors for the same cylinder are not adjusted at same index mark on accessory drive pulley. One pair of valves from one cylinder and one injector on a different cylinder are adjusted at each pulley index mark before rotating accessory drive to next index mark.
- Two crankshaft revolutions are required to adjust all valves and injectors.

1. Accessory drive pulley assembly (1)	a. Remove paint on timing marks A (2), B (3), and C (4). b. Rotate engine crankshaft clockwise until line in front of timing mark A (2) aligns with pointer (6) on front gear cover (7).	Use a medium-grit emery cloth. Only the A (2), B (3), and C (4) timing marks will be used for injector and valve adjustment. Do not use nut (5) on the accessory drive pulley assembly (1) to rotate. The intake and exhaust rocker lever assemblies (10) for cylinder No. 5 will be loose. If they are not, rotate crankshaft another 360° and realign the A mark (2).
----------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-85. INJECTOR AND VALVE ADJUSTMENT (Contd)

Injector and Valve Set Position

Rotate in Clockwise Direction	Pulley Position	Cylinder Firing	Set Cylinder	
			Injector	Valve
Start	A	or 1	3	5
Advance to	B	or 5	6	3
Advance to	C	or 3	2	6
Advance to	A	or 6	4	2
Advance to	B	or 2	1	4
Advance to	C	or 4	5	1



LEGEND:

- 1. ACCESSORY DRIVE PULLEY ASSEMBLY
- 2. TIMING MARK A
- 3. TIMING MARK B
- 4. TIMING MARK C
- 5. NUT
- 6. POINTER

- 7. FRONT GEAR COVER
- 8. ADJUSTING SCREW NUT
- 9. ADJUSTING SCREW
- 10. ROCKER LEVER ASSEMBLY
- 11. CROSSHEAD
- 12. TORQUE DRIVER

3-85. INJECTOR AND VALVE ADJUSTMENT (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Adjustment (Contd)

2. Injector adjustment for cylinder No. 3	<p>Adjust as follows:</p> <p>a. Loosen the adjusting screw nut (8) several turns.</p> <p>b. Tighten adjusting screw (9) until all clearance is removed between rocker lever assembly (10) and injector detent plunger. Then tighten adjusting screw (9) one additional turn.</p> <p>c. Loosen the adjusting screw (9) one complete turn until the spring washer inside the injector is against the stop of the injector.</p> <p>d. Tighten the adjusting screw (9) to 5-6 lb-in. (0.6-0.7 N•m).</p> <p>e. Keep adjusting screw (9) from turning and torque adjusting screw nut (8) to 45 lb-ft (61 N•m).</p>	<p>The rocker lever assembly (10) for the injector is between the intake and exhaust valves.</p> <p>Turn counterclockwise to loosen. The spring washer cannot be seen. When tension is removed from adjusting screw (9), this usually indicates that the spring washer is against the stop of the injector.</p> <p>Repeat step 2d several times to make certain that it is correctly tightened.</p> <p>If torque driver (ST-669) (12) is used, tighten adjusting screw nut (8) to 35 lb-ft (48 N•m).</p>
-------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

NOTE


The adjustment procedure for the intake valve is similar to the exhaust valve, except for valve clearance difference.

3. Intake and exhaust valve adjustment for cylinder No. 5	<p>Adjust as follows:</p> <p>a. Loosen adjusting screw nut (8).</p> <p>b. Put a feeler gauge between the rocker lever assembly (10) and the crosshead (11).</p> <p>c. Slowly tighten the adjusting screw (9) until the rocker lever assembly (10) touches the feeler gauge.</p> <p>d. Hold the adjusting screw (9) in place and torque adjusting screw nut (8) to 45 lb-ft (61 N•m).</p>	<p>Do not rotate engine crankshaft until completing all of step 3.</p> <p>Cold valve clearance for the exhaust valve is 0.023 in. (0.584 mm) and valve clearance for the intake valve is 0.011 in. (0.279 mm).</p> <p>If torque driver (ST-669) (12) is used, tighten adjusting screw nut (8) to 40 lb-ft (54 N•m).</p>
-----------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-85. INJECTOR AND VALVE ADJUSTMENT (Contd)

Injector and Valve Set Position

Rotate in Clockwise Direction	Pulley Position	Cylinder Firing	Set Cylinder	
			Injector	Valve
Start	A	or 1	3	5
Advance to	B	or 5	6	3
Advance to	C	or 3	2	6
Advance to	A	or 6	4	2
Advance to	B	or 2	1	4
Advance to	C	or 4	5	1



LEGEND:


- 1. DRIVE PULLEY
- 8. ADJUSTING SCREW NUT
- 9. ADJUSTING SCREW
- 10. ROCKER LEVER ASSEMBLY
- 11. CROSSHEAD
- 12. TORQUE DRIVER

3-85. INJECTOR AND VALVE ADJUSTMENT (Contd)

LOCATION/ITEM	ACTION	REMARKS
Adjustment (Contd)		
4. Accessory drive pulley assembly (1)	Slowly rotate clockwise until the line in front of timing mark B (3) aligns with the pointer (6) on the front gear cover (7).	Use engine crankshaft to rotate.
5. Injector adjustment for cylinder No. 6	Repeat step 2.	
6. Intake and exhaust valve adjustment for cylinder No. 3	Repeat step 3.	
7. Accessory drive pulley assembly (1)	Slowly rotate clockwise until the line in front of timing mark C (4) aligns with the pointer (6) on the front gear cover (7).	Use engine crankshaft to rotate.
8. Injector adjustment for cylinder No. 2	Repeat step 2.	
9. Intake and exhaust valve adjustment for cylinder No. 6	Repeat step 3.	
10. Accessory drive pulley assembly (1)	Slowly rotate clockwise until the line in front of timing mark A (2) aligns with pointer (6) on the front gear cover (7).	Use engine crankshaft to rotate.
11. Injector adjustment for cylinder No. 4	Repeat step 2.	
12. Intake and exhaust valve adjustment for cylinder No. 2	Repeat step 3.	
13. Accessory drive pulley assembly (1)	Slowly rotate clockwise until the line in front of timing mark B (3) aligns with pointer (6) on the front gear cover (7).	Use engine crankshaft to rotate.
14. Injector adjustment for cylinder No. 1	Repeat step 2.	
15. Intake and exhaust valve adjustment for cylinder No. 4	Repeat step 3.	
16. Accessory drive pulley assembly (1)	Slowly rotate clockwise until line in front of timing mark C (4) aligns with pointer (6) on the front gear cover (7).	Use engine crankshaft to rotate.
17. Injector adjustment for cylinder No. 5	Repeat step 2.	
18. Intake and exhaust valve adjustment for cylinder No. 1	Repeat step 3.	

FOLLOW-ON TASK: Install engine retarder (para. 3-86).

3-85. INJECTOR AND VALVE ADJUSTMENT (Contd)



LEGEND:

- 1. ACCESSORY DRIVE PULLEY ASSEMBLY
- 2. TIMING MARK A
- 3. TIMING MARK B
- 4. TIMING MARK C

- 5. NUT
- 6. POINTER
- 7. FRONT GEAR COVER

3-86. ENGINE RETARDER INSTALLATION

THIS TASK COVERS:

a. Installation

b. Slave Piston Adjustment

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Gasket (75078) 010279
 Preformed packing (75078) 010180

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

TM 9-2320-273-20
 TM 9-2320-283-20

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

- Rocker arm housing installed (para. 3-84).
- Injector and valve adjustment performed (para. 3-85).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Installation

NOTE


- The following procedure involves installation of one engine brake retarder. Installation of remaining engine brake retarders is similar.
- The engine retarder over cylinders No. 1 and 2 requires installation of a fan bracket assembly. The fan bracket assembly is installed in steps 9 and 10. Omit steps 3 and 4 if installing engine retarders over cylinders No. 3 and 4, or No. 5 and 6.
- If studs were removed from rocker housings, replace and tighten to 65-75 lb-ft (88-102 N•m); tighten in sequence as shown.

1. Slave piston (30), slave piston spring (28), helical retainer (27), and retaining ring (26)	Install on engine brake retarder assembly (31), if not installed.
2. Master piston (29) and flat spring (15)	Install on engine brake retarder assembly (31) with washer (16) and screw (17), if not installed.
3. Weighted valve (33), control valve outer spring (34), and control valve inner spring (35)	Install on engine brake retarder assembly (31) with control valve cover plate (4) and screw (3), if not installed.

CAUTION

Ensure preformed packing (rubber seal ring) in oil inlet supply bore on underside of engine brake retarder remains in place during installation or brake retarder will not operate properly.

3-86. ENGINE RETARDER INSTALLATION (Contd)



LEGEND:

- | | |
|----------------------------------------|------------------------------------|
| 1. FAN BRACKET ASSEMBLY | 19. GASKET |
| 2. NUT (6) | 20. EXTERNAL BOLT (2) |
| 3. SCREW (2) | 21. PREFORMED PACKING (3) |
| 4. CONTROL VALVE COVER PLATE (2) | 22. LOCKSHAFT SCREW (3) |
| 5. SOLENOID ARMATURE | 23. ROCKER ARM HOUSING |
| 6. SPADE END (OF SOLENOID HARNESS) | 24. BEARING WASHER (18) |
| 7. PREFORMED PACKING | 25. ROCKER HOUSING STUD (6) |
| 8. PREFORMED PACKING | 26. RETAINING RING (2) |
| 9. PREFORMED PACKING | 27. HELICAL RETAINER (2) |
| 10. SOLENOID HARNESS | 28. SLAVE PISTON SPRING (2) |
| 11. RECEIVER END (OF SOLENOID HARNESS) | 29. MASTER PISTON (2) |
| 12. LOCKNUT | 30. SLAVE PISTON (2) |
| 13. SETSCREW | 31. ENGINE BRAKE RETARDER ASSEMBLY |
| 14. TERMINAL | 32. SHORT SPACER (2) |
| 15. FLAT SPRING (2) | 33. WEIGHTED VALVE (2) |
| 16. WASHER (2) | 34. CONTROL VALVE OUTER SPRING (2) |
| 17. SCREW (2) | 35. CONTROL VALVE INNER SPRING (2) |
| 18. TIGHTENING SEQUENCE | 36. SOLENOID VALVE ASSEMBLY |

3-86. ENGINE RETARDER INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
a. Installation (Contd)		
4. Solenoid valve assembly (36) and new preformed packing (7), (8), and (9)	Install on engine brake retarder (31), if not installed.	
5. Lockshaft screw (22), bolt (20), and preformed packing (21)	Install on rocker arm housing (23), if not installed.	
6. Terminal (14)	Install on engine brake retarder (31), if not installed.	
7. New gasket (19)	Position on rocker arm housing (23) and engine brake retarder (31).	
8. Engine brake retarder assembly (31)	Install on rocker arm housing (23).	
9. Two short spacers (32)	Install on two rocker housing studs (25).	Two short spacers (32) are needed for fan bracket assembly (1) which mounts on two front rocker housing studs (25) of engine brake retarder (31) for No. 1 and 2 cylinders.
10. Fan bracket assembly (1)	Install on two rocker housing studs (25) on top of two short spacers (32) on engine brake retarder (31).	The fan bracket assembly (1) fits on two front rocker housing studs (25) on top of two short spacers (32) on brake retarder (31) for cylinders No. 1 and 2.
11. Six nuts (2)	Install on rocker housing studs (25) and tighten to 60 lb-ft (81 N•m) as shown in tightening sequence (18).	


b. Slave Piston**CAUTION**

Adjusting slave piston by any other method than specified in this procedure will cause damage to related parts.

NOTE

- The following procedure involves adjustment for one slave piston. There are two slave pistons per brake retarder, or one per cylinder. The adjustment for the remaining five slave pistons is similar. Ensure locknuts are loose before adjusting setscrew.
- Slave piston adjustment must be made with engine stopped and cold. Exhaust valve on cylinder to be adjusted must be fully closed.
- The adjustment procedure for slave piston requires engine crankshaft to be rotated and accessory drive pulley assembly positioned on timing mark A, B, or C. When positioned at timing mark A, cylinders No. 5 or 2 can be adjusted. When positioned at timing mark B, cylinders No. 3 or 4 can be adjusted. When positioned at timing mark C, cylinders No. 6 or 1 can be adjusted.

3-86. ENGINE RETARDER INSTALLATION (Contd)



LEGEND:

- | | |
|----------------------------------------|------------------------------------|
| 1. FAN BRACKET ASSEMBLY | 19. GASKET |
| 2. NUT (6) | 20. EXTERNAL BOLT (2) |
| 3. SCREW (2) | 21. PREFORMED PACKING (3) |
| 4. CONTROL VALVE COVER PLATE (2) | 22. LOCKSHAFT SCREW (3) |
| 5. SOLENOID ARMATURE | 23. ROCKER ARM HOUSING |
| 6. SPADE END (OF SOLENOID HARNESS) | 24. BEARING WASHER (18) |
| 7. PREFORMED PACKING | 25. ROCKER HOUSING STUD (6) |
| 8. PREFORMED PACKING | 26. RETAINING RING (2) |
| 9. PREFORMED PACKING | 27. HELICAL RETAINER (2) |
| 10. SOLENOID HARNESS | 28. SLAVE PISTON SPRING (2) |
| 11. RECEIVER END (OF SOLENOID HARNESS) | 29. MASTER PISTON (2) |
| 12. LOCKNUT | 30. SLAVE PISTON (2) |
| 13. SETSCREW | 31. ENGINE BRAKE RETARDER ASSEMBLY |
| 14. TERMINAL | 32. SHORT SPACER (2) |
| 15. FLAT SPRING (2) | 33. WEIGHTED VALVE (2) |
| 16. WASHER (2) | 34. CONTROL VALVE OUTER SPRING (2) |
| 17. SCREW (2) | 35. CONTROL VALVE INNER SPRING (2) |
| 18. TIGHTENING SEQUENCE | 36. SOLENOID VALVE ASSEMBLY |

3-86. ENGINE RETARDER INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Slave Piston Adjustment (Contd)

12. Slave piston (30)	Adjust clearance as follows: a. Loosen locknut (6). b. Loosen setscrew (7) several turns. c. Insert feeler gauge between slave piston (30) and crosshead. Adjust clearance to 0.018 in. (0.457 mm).	 Turn counterclockwise to loosen until there is no pressure or tension. A slight drag should be felt on the feeler gauge when setscrew (7) is properly adjusted.
-----------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

CAUTION

After slave piston adjusting screw locknut has been tightened to specified value, check clearance with feeler gauge again. Do not overtighten adjusting screw locknut or clearance may change and result in damage to engine.

13. Solenoid harness (10)	d. Tighten locknut (6) to 40 lb-ft (54 N•m). e. Recheck clearance between slave piston (30) and crosshead with feeler gauge.	 Refer to CAUTION before step 6d. Repeat steps 6a through 6d if any change in clearance is found.
	Connect spade end (6) to solenoid valve assembly (36). Connect receiver end (11) to terminal (14) inside of engine brake retarder assembly (31).	


NOTE

If engine will be started after installation and adjustment of engine retarder, it will then be necessary to bleed air from engine retarder assembly and proceed with step 14. If it will not be started, proceed with follow-on tasks.

14. Engine brake retarder assembly (31)	When engine is installed on dynamometer test stand, bleed and purge air as follows: a. Start engine and run for several minutes. b. Rev engine to 1800 rpm and release throttle. c. Push down on solenoid armature (5) five or six times to permit engine lubricating oil to fill engine brake retarder housing oil passages.	
-----------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

- FOLLOW-ON TASKS:
- Install engine lifting brackets (TM 9-2320-273-20 or TM 9-2320-283-20).
 - Install rocker covers and gaskets (TM 9-2320-273-20 or TM 9-2320-283-20).
 - Install air aftercooler (para. 3-87).

3-86. ENGINE RETARDER INSTALLATION (Contd)



LEGEND:

- | | |
|----------------------------------------|------------------------------------|
| 1. FAN BRACKET ASSEMBLY | 19. GASKET |
| 2. NUT (6) | 20. EXTERNAL BOLT (2) |
| 3. SCREW (2) | 21. PREFORMED PACKING (3) |
| 4. CONTROL VALVE COVER PLATE (2) | 22. LOCKSHAFT SCREW (3) |
| 5. SOLENOID ARMATURE | 23. ROCKER ARM HOUSING |
| 6. SPADE END (OF SOLENOID HARNESS) | 24. BEARING WASHER (18) |
| 7. PREFORMED PACKING | 25. ROCKER HOUSING STUD (6) |
| 8. PREFORMED PACKING | 26. RETAINING RING (2) |
| 9. PREFORMED PACKING | 27. HELICAL RETAINER (2) |
| 10. SOLENOID HARNESS | 28. SLAVE PISTON SPRING (2) |
| 11. RECEIVER END (OF SOLENOID HARNESS) | 29. MASTER PISTON (2) |
| 12. LOCKNUT | 30. SLAVE PISTON (2) |
| 13. SETSCREW | 31. ENGINE BRAKE RETARDER ASSEMBLY |
| 14. TERMINAL | 32. SHORT SPACER (2) |
| 15. FLAT SPRING (2) | 33. WEIGHTED VALVE (2) |
| 16. WASHER (2) | 34. CONTROL VALVE OUTER SPRING (2) |
| 17. SCREW (2) | 35. CONTROL VALVE INNER SPRING (2) |
| 18. TIGHTENING SEQUENCE | 36. SOLENOID VALVE ASSEMBLY |

3-87. AIR AFTERCOOLER INSTALLATION

THIS TASK COVERS:

Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

None

MATERIALS/PARTS

Lubricant, high-pressure (Appendix C, Item 15)

Three gaskets (15434) 3008591

Two lockwashers (15434) S-604
(M915A1/Big Cam III only)

Three lockwashers (96906) MS122032
(M915/Big Cam I only)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

TM 9-2320-273-20

TM 9-2320-283-20

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Engine retarders installed (para. 3-86).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

None

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


Installation

NOTE

- Perform steps 2 and 5 for M915/Big Cam I.
- Perform steps 3 and 6 for M915A1/Big Cam III.

1. Three new gaskets (9)	Install on three cylinder heads (1).	Use a small amount of high-pressure lubricant to hold gaskets (9) in place.
2. Three screws (5), new lockwashers (4), and washers (3) (M915/Big Cam I)	Install on bottom hole of each cylinder head (1).	Thread in three to five turns.
3. Screw (8), two screws (5), three new lockwashers (4), and washers (3) (M915A1/Big Cam III)	Install on bottom hole of each cylinder head (1).	Thread in three to five turns.

3-87. AIR AFTERCOOLER INSTALLATION (Contd)



LEGEND:

- | | |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> 1. CYLINDER HEAD (3) 2. AIR AFTERCOOLER 3. WASHER (3) 4. LOCKWASHER (3) 5. SCREW (3) (M915/BIG CAM I) OR (2) (M915A1/BIG CAM III) | <ul style="list-style-type: none"> 6. SCREW (6) (M915/BIG CAM I ONLY) OR CAPTIVE WASHER SCREW (6) (M915A1/BIG CAM III ONLY) 7. WASHER (6) (M915/BIG CAM I ONLY) 8. SCREW (M915A1/BIG CAM III ONLY) 9. GASKET (3) |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

3-87. AIR AFTERCOOLER INSTALLATION (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

Installation (Contd)

- | | | |
|----|-------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| 4. | Air aftercooler (2) and three gaskets (9) | Install on three cylinder heads (1) with three screws (5) or screw (8) (M915A1/Big Cam III) and three washers (3) and new lockwashers (4). |
|----|-------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|


NOTE

- Two middle holes in air aftercooler are used for mounting ether starting kit.
- Refer to TM 9-2320-273-20 or TM 9-2320-283-20 to install ether starting kit.
- Tighten screws from the center outwards. Tighten all screws (M915A1/Big Cam III) to 20-25 lb-ft (27-34 N•m).

- | | | | |
|----|--------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5. | Three screws (5), new lockwashers (4), and washers (3) (M915/Big Cam I) | Install on three outside holes in air aftercooler (2), three gaskets (9), and three outer cylinder heads (1). | Tighten, but do not torque, screws (5). Install two remaining screws (5) once ether starting kit has been installed. Refer to TM 9-2320-283-20. |
| 6. | Screw (8), two screws (5), three new lockwashers (4), and washers (3) (M915A1/Big Cam III) | Install on four outside holes in air aftercooler (2), three gaskets (9), and three cylinder heads (1). | Tighten, but do not torque, screws (5) and screw (8). Install two remaining screws (5) once ether starting kit has been installed. Refer to TM 9-2320-283-20. |

- FOLLOW-ON TASKS:
- Install water crossover tube and connection (TM 9-2320-273-20 or TM 9-2320-283-20).
 - Remove engine from maintenance stand (para. 3-88).

3-87. AIR AFTERCOOLER INSTALLATION (Contd)



LEGEND:

- | | |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> 1. CYLINDER HEAD (3) 2. AIR AFTERCOOLER 3. WASHER (3) 4. LOCKWASHER (3) 5. SCREW (3) (M915/BIG CAM I) OR (2) (M915A1/BIG CAM III) | <ul style="list-style-type: none"> 6. SCREW (6) (M915/BIG CAM I ONLY) OR CAPTIVE WASHER SCREW (6) (M915A1/BIG CAM III ONLY) 8. SCREW (M915A1/BIG CAM III ONLY) 9. GASKET (3) |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

3-88. REMOVING ENGINE FROM MAINTENANCE STAND

THIS TASK COVERS:

a. Removal

b. Component Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Engine lifting fixture (15434) ST-125

TEST EQUIPMENT

None

MATERIALS/PARTS

Compound, antiseize (Appendix C, Item 7)

Sealant, thread (liquid) (Appendix C, Item 27)

Oil, lubricating, OE/HDO 10
(Appendix C, Item 20)

Two water header cover gaskets (15434) 70089-1

Six piston cooling nozzle O-rings (15434)
3007443

Gasket (15434) 3031858

Two grommets (15434) S-1003-A

Six exhaust manifold gaskets (15434) 3020943

Turbocharger mounting gasket (15434) 190849

Cover gasket (15434) 65274

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

LO 9-2320-273-12

TM 9-2320-273-20

TM 9-2320-273-34

LO 9-2320-283-12

TM 9-2320-283-20

TM 9-2320-283-34

TROUBLESHOOTING REFERENCES

None

EQUIPMENT CONDITION

None

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

- All personnel must stand clear during lifting operations.
- Use extreme caution during disassembly or assembly; engine components are heavy.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

WARNING

Use extreme caution during disassembly or assembly; engine components are heavy. Failure to comply may result in damage to equipment or injury to personnel.

a. Removal


1. Dressed engine assembly (3)	a. Connect engine lifting fixture (1) to two engine lifting brackets (2).	Use engine lifting fixture (ST-125) (1).
	b. Using suitable sling and lifting device, raise engine just enough to take weight off maintenance stand (4).	Ensure lifting device and engine lifting fixture (1) distribute load equally on engine lifting brackets (2).

WARNING

All personnel must stand clear during lifting operations. A snapped chain or swinging or shifting load may result in injury to personnel.

	c. Remove four mounting screws (5) and maintenance stand (4), and set on suitable blocks.	Ensure engine is supported by cylinder block (6), flywheel housing, or front support. Do not support engine on oil pan.
2. Engine lifting fixture (1)	Remove from two engine lifting brackets (2).	

3-88. REMOVING ENGINE FROM MAINTENANCE STAND (Contd)



LEGEND:

- | | |
|-------------------------------|-----------------------|
| 1. ENGINE LIFTING FIXTURE | 4. MAINTENANCE STAND |
| 2. ENGINE LIFTING BRACKET (2) | 5. MOUNTING SCREW (4) |
| 3. DRESSED ENGINE ASSEMBLY | 6. CYLINDER BLOCK |

3-88. REMOVING ENGINE FROM MAINTENANCE STAND (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Component Installation

NOTE

- Perform steps 3 and 4 for M915/Big Cam I only.
- Perform steps 5 through 7 for M915A1/Big Cam III only.


- | | | |
|------------------------------------------------------------------------------------------|--------------------------------|--|
| 3. New gasket (9), flange (8), and six screws (7) | Install on cylinder block (6). | |
| 4. Water transfer tube (12), two water transfer hoses (11), and four clamps (10) | Install on flange (8). | |
| 5. Two new gaskets (13), water header covers (14), and twelve captive washer screws (15) | Install on cylinder block (6). | |

NOTE

Do not soak piston cooling nozzle O-rings in lubricating oil for any length of time or O-rings will swell.

- | | | |
|----------------------------------------------------------------------|-------------------------------------------------------------------------------------------|---------------------------------------------------------------|
| 6. Six new preformed packings (16) | Lubricate with OE/HDO 10 lubricating oil and position on six piston cooling nozzles (17). | Ensure piston cooling nozzles (17) are not twisted in groove. |
| 7. Six piston cooling nozzles (17) and self-locking screws (18) | Install on cylinder block (6). | Tighten to 140 lb-in. (16 N•m). |
| 8. Power steering pump and reservoir | Install. | Refer to TM 9-2320-273-20 or TM 9-2320-283-20. |
| 9. Water pump and drivebelts | Install. | Refer to TM 9-2320-273-20 or TM 9-2320-283-20. |
| 10. Fan brace, bracket, and spacers | Install. | Refer to TM 9-2320-273-20 or TM 9-2320-283-20. |
| 11. Fan, fan clutch, and fan clutch drivebelts | Install. | Refer to TM 9-2320-273-20 or TM 9-2320-283-20. |
| 12. Engine wiring harness | Install. | Refer to TM 9-2320-273-20 or TM 9-2320-283-20. |
| 13. Ether quick-start cylinder, valve, safety switch, and thermostat | Install. | Refer to TM 9-2320-273-20 or TM 9-2320-283-20. |

3-88. REMOVING ENGINE FROM MAINTENANCE STAND (Contd)



LEGEND:

- | | |
|-----------------------------|-------------------------------|
| 6. CYLINDER BLOCK | 13. GASKET (2) |
| 7. SCREW (6) | 14. WATER HEADER COVER (2) |
| 8. FLANGE | 15. CAPTIVE WASHER SCREW (12) |
| 9. GASKET | 16. PREFORMED PACKING (6) |
| 10. CLAMP (4) | 17. PISTON COOLING NOZZLE (6) |
| 11. WATER TRANSFER HOSE (2) | 18. SELF-LOCKING SCREW (6) |
| 12. WATER TRANSFER TUBE | |

3-88. REMOVING ENGINE FROM MAINTENANCE STAND (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Component Installation (Contd)


14. Modulator bracket and accelerator return spring	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
15. Air compressor governor and air lines	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
16. Air compressor intake tube	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
17. Air compressor discharge hose	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
18. Water bypass tube	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
19. Water pump-to-radiator connection	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
20. Water pump bypass hose	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.

NOTE

- Perform steps 21 through 23 for M915/Big Cam I only.
- Perform steps 24 and 25 for M915A1/Big Cam III only.

21. Gasket (23), oil cooler assembly (27), five new lockwashers (20), two screws (25), two screws (22), and screw (26)	Install on water transfer hose (11), cylinder block (6), and oil cooler support (24).	Tighten screws (25), (22), and (26) to 30-35 lb-ft (41-48 N•m).
22. Clamp (10)	Tighten at water transfer hose (11).	
23. New lockwasher (20) and screw (19)	Install on support bracket (21) and cylinder block (6).	Tighten screw (19) to 30-35 lb-ft (41-48 N•m).
24. Gasket (32), oil cooler assembly (37), six new lockwashers (35), three screws (36), and screws (34)	Install on oil cooler support (33) and cylinder block (6).	Tighten screws (36) and (34) to 30-35 lb-ft (41-48 N•m).
25. Two washers (30), new lockwashers (29), and screws (28)	Install on support bracket (31) and cylinder block (6).	Tighten screws (28) to 30-35 lb-ft (41-48 N•m).

3-88. REMOVING ENGINE FROM MAINTENANCE STAND (Contd)



LEGEND:

- | | |
|-------------------------|-------------------------|
| 6. CYLINDER BLOCK | 27. OIL COOLER ASSEMBLY |
| 10. CLAMP | 28. SCREW (2) |
| 11. WATER TRANSFER HOSE | 29. LOCKWASHER (2) |
| 19. SCREW | 30. WASHER (2) |
| 20. LOCKWASHER (6) | 31. SUPPORT BRACKET |
| 21. SUPPORT BRACKET | 32. GASKET |
| 22. SCREW (2) | 33. OIL COOLER SUPPORT |
| 23. GASKET | 34. SCREW (3) |
| 24. OIL COOLER SUPPORT | 35. LOCKWASHER (6) |
| 25. SCREW (2) | 36. SCREW (3) |
| 26. SCREW | 37. OIL COOLER ASSEMBLY |

3-88. REMOVING ENGINE FROM MAINTENANCE STAND (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Component Installation (Contd)

26. New engine oil filter elements	Fill and install.	Refer to TM 9-2320-273-20 and LO 9-2320-273-12 or TM 9-2320-283-20 or LO 9-2320-283-12.
27. Lower water transfer tube	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
28. Alcohol evaporator	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
29. Engine retarder microswitch	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
30. Water manifolds	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
31. Thermostat and thermostat housing	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
32. Engine temperature sending units and fuel line fittings	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
33. Fan clutch air valve and air lines	Connect.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
34. Water transfer tube and bracket	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
35. Air compressor cooling tube	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
36. Six new gaskets (48)	Install on cylinder heads (38).	Install gaskets (48) with the word OUT facing exhaust manifold.

NOTE

- Perform steps 37 and 38 for M915/Big Cam I only.
- Perform step 39 for M915A1/Big Cam III only.


37. Exhaust manifold (39), two clamps (45), four lockplates (44), and screws (43)	Install on six dowels (49) and three cylinder heads (38).	Coat threads of screws (43) with antiseize compound. Assistant will help hold exhaust manifold (39) during installation. Do not tighten screws (43).
-----------------------------------------------------------------------------------	-----------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------

NOTE

M915A1/Big Cam III engines utilize two types of exhaust manifolds, an early pulse type and a new design with two spacer inserts placed between center exhaust manifold and two end exhaust manifolds. Installation of manifolds is basically the same.

38. Four lockplates (40), eight new lockwashers (41), and screws (42)	Install on exhaust manifold (39) and cylinder heads (38).	Tighten screws (42) and (43) alternately and evenly to 15-20 lb-ft (20-27 N•m) and then to 40-45 lb-ft (54-61 N•m).
39. Exhaust manifold (46) and twelve captive washer screws (47)	Install on cylinder heads (38).	Coat threads of captive washer screws (47) with antiseize compound. Tighten alternately and evenly to 15-20 lb-ft (20-27 N•m) and then to 40-45 lb-ft (54-61 N•m).

3-88. REMOVING ENGINE FROM MAINTENANCE STAND (Contd)



LEGEND:

- 38. CYLINDER HEAD (3)
- 39. EXHAUST MANIFOLD (M915/BIG CAM I)
- 40. LOCKPLATE (4)
- 41. LOCKWASHER (8)
- 42. SCREW (8)
- 43. SCREW (4)

- 44. LOCKPLATE (4)
- 45. CLAMP (2)
- 46. EXHAUST MANIFOLD (M915A1/BIG CAM III)
- 47. CAPTIVE WASHER SCREW (12)
- 48. GASKET (6)
- 49. DOWEL (6)

3-88. REMOVING ENGINE FROM MAINTENANCE STAND (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Component Installation (Contd)


40. Water filter and bracket	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
41. Water shutoff valves and hoses	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
42. New gasket (57)	Install on studs (56).	Install gasket (57) with bead facing turbocharger (50). Coat threads of studs (56) with anti-seize compound.
43. Turbocharger (50) and four nuts (58)	Install on studs (56) and exhaust manifold (46).	Tighten nuts (58) to 20-25 lb-ft (27-34 N•m).

NOTE

- Perform step 44 for M915/Big Cam I only.
- Perform steps 45 and 46 for M915A1/Big Cam III only.

44. Hose (66), two clamps (65), and oil return tube (64)	Install on elbows (67) and (62).	Tighten clamps (65) to 35-45 lb-ft (48-61 N•m).
45. Hose (66), two clamps (65), and oil return tube (63)	Install on elbows (67) and (59).	Tighten clamps (65) to 35-45 lb-ft (48-61 N•m).
46. Two bushings (61) and oil return tube (60)	Install on filter head (68) and oil return tube (63).	Tighten fittings on oil return tube (60) to 50-60 lb-ft (68-81 N•m).
47. Oil supply hose (51)	Install on adapter (54) and elbow (55).	Tighten fittings on oil supply hose (51) to 50-60 lb-ft (68-81 N•m).
48. Clamp (52) and screw (53)	Install on oil supply hose (51) and turbocharger (50).	Tighten screw (53) to 14 lb-ft (19 N•m).
49. Turbocharger air crossover connection	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
50. Oil breather tubes and hoses	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.

3-88. REMOVING ENGINE FROM MAINTENANCE STAND (Contd)



NOTE

M915/Big Cam I engines have a single oil filter. M915A1/Big Cam III engine is shown.

LEGEND:

- | | | | |
|-------------------------------------------------------|-----------------------------------|---------------------------------------------|-----------------|
| 6. CYLINDER BLOCK | 54. ADAPTER | 60. OIL RETURN TUBE | 65. CLAMP (2) |
| 46. EXHAUST MANIFOLD
(M915A1/BIG CAM III
SHOWN) | 55. ELBOW | 61. BUSHING (2) | 66. HOSE |
| 50. TURBOCHARGER | 56. STUD (4) | 62. ELBOW (M915/BIG
CAM I) | 67. ELBOW |
| 51. OIL SUPPLY HOSE | 57. GASKET | 63. OIL RETURN TUBE
(M915A1/BIG CAM III) | 68. FILTER HEAD |
| 52. CLAMP | 58. NUT (4) | 64. OIL RETURN TUBE
(M915/BIG CAM I) | |
| 53. SCREW | 59. ELBOW (M915A1/BIG
CAM III) | | |

3-88. REMOVING ENGINE FROM MAINTENANCE STAND (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

b. Component Installation (Contd)


51. New gasket (83), oil level dipstick tube and cover (76), four washers (82), and captive washer screws (81)	Install on cylinder block (6).	Tighten captive washer screws (81) to 30-35 lb-ft (41-48 N•m).
52. Tube brace (72), clamp (80), two washers (79), screw (84), new lockwasher (78), and nut (77)	Install on oil level dipstick tube and cover (76).	
53. Washer (73), new lockwasher (74), and screw (75)	Install on tube brace (72) and cylinder block (6).	
54. Oil level dipstick	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
55. Heater control valve, shutoff valve, and supply tube	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.
56. Heater return tube	Install.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.

NOTE**Perform step 57 for M915/Big Cam I only.**

57. Transmission control-body heating elements ON/OFF switch (69)	Install on cylinder block (6).	
58. Oil pressure gauge sending unit (70) and low oil pressure warning light sending unit (71)	Install on cylinder block (6).	
59. Engine wiring harness leads	Connect.	Refer to TM 9-2320-273-20 or TM 9-2320-283-20.

- FOLLOW-ON TASKS:
- Install starter motor and solenoid (TM 9-2320-273-20 or TM 9-2320-283-20).
 - Install alternator, belts, and bracket (TM 9-2320-273-20 or TM 9-2320-283-20).
 - Start repaired engine (para. 3-91).
 - Install STE/ICE harness, receptacle, and bracket (TM 9-2320-273-20 or TM 9-2320-283-20).

3-88. REMOVING ENGINE FROM MAINTENANCE STAND (Contd)



LEGEND:

- 6. CYLINDER BLOCK
- 69. TRANSMISSION CONTROL-BODY HEATING ELEMENTS ON/OFF SWITCH
- 70. OIL PRESSURE GAUGE SENDING UNIT
- 71. LOW OIL PRESSURE WARNING LIGHT SENDING UNIT
- 72. TUBE BRACE
- 73. WASHER
- 74. LOCKWASHER
- 75. SCREW

- 76. OIL LEVEL DIPSTICK TUBE AND COVER
- 77. NUT
- 78. LOCKWASHER
- 79. WASHER (2)
- 80. CLAMP
- 81. CAPTIVE WASHER SCREW (4)
- 82. WASHER (4)
- 83. GASKET
- 84. SCREW

Section V. TESTING

3-89. GENERAL

a. This section provides procedures for starting a new or rebuilt engine, engine break-in, dynamometer testing, and on-engine fuel pump adjustment. The testing procedures in this section are accomplished with the engine removed from the vehicle.

b. If repair operations are performed without removing engine from vehicle, follow the applicable portions of instructions and use a suitable chassis-type engine dynamometer.

3-90. TASK SUMMARY**INITIAL SETUP:****APPLICABLE MODELS**

All

SPECIAL TOOLS

Blow-by measuring tool (15434) 3375150
 Idle speed adjusting tool (15434) 3375981
 Throttle shaft ball installing tool (15434)
 3375204

TEST EQUIPMENT

Dynamometer (NSN 4910-01-180-6171) or
 suitable dynamometer
 Opacity meter

MATERIALS/PARTS

Antifreeze, permanent ethylene glycol -60°F
 (-51.1°C) inhibited (Appendix C, Item 3)
 Oil, lubricating, OD/HDO 30
 (Appendix C, Item 21)
 Oil, fuel, diesel, regular (Appendix C, Item 19)
 Gasket (15434) 70705
 Throttle shaft ball (15434) 213769
 Lockwire and seal (15434) 3003156
 Throttle shaft cover (15434) 300466
 Two drive screws (15434) S-2286

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

LO 9-2320-273-12
 LO 9-2320-283-12

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

Refer to specific paragraph for this information.

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dust and dirt.

GENERAL SAFETY INSTRUCTIONS

- Allow adequate ventilation for engine exhaust gases.
- Diesel fuel is highly flammable. Do not perform fuel pump adjustments near fire, flames, or sparks.

List of Tasks

TASK PARA.	PROCEDURES	TASK REF.	TROUBLESHOOTING REF. NO. (PARA.)
1	Starting Repaired Engine a. Installation of Engine on Dynamometer b. Priming Cooling System c. Priming Fuel System d. Priming Lubricating System e. Prerun Startup	3-91 3-91a 3-91b 3-91c 3-91d 3-91e	2-8
2	Engine Dynamometer Testing a. Setup b. Break-in Running c. Power Check d. Smoke Level Check e. Final Check	3-92 3-92a 3-92b 3-92c 3-92d 3-92e	2-8
3	On-Engine Fuel Pump Adjustment a. Preadjustment Checks b. Idle Speed Adjustment c. High Speed Adjustment d. High Idle Speed Adjustment e. Checking and Adjusting Fuel Rate Pressure f. Checking and Adjusting Engine Fuel Rate g. Checking and Adjusting Throttle Leakage h. Checking Engine Power i. Checking Fuel Filter Restriction j. Fuel Pump Seal Installation k. Throttle Shaft Cover Plate Installation	3-93 3-93a 3-93b 3-93c 3-93e 3-93f 3-93g 3-93h 3-93h 3-93i 3-93j 3-93k	2-8

3-91. STARTING REPAIRED ENGINE

THIS TASK COVERS:

- a. Installation of Engine on Dynamometer
- b. Priming Cooling System
- c. Priming Fuel System
- d. Priming Lubricating System
- e. Prerun Startup

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

None

TEST EQUIPMENT

Dynamometer test stand (15434) 3375710

MATERIALS/PARTS

Antifreeze, permanent ethylene glycol -60°F (-51.1°C) inhibited (Appendix C, Item 3)
 Oil, lubricating, OE/HDO 30 (Appendix C, Item 21)
 Oil, fuel, diesel, regular (Appendix C, Item 19)

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

LO 9-2320-273-12
 TM 9-2320-273-20
 LO 9-2320-283-12
 TM 9-2320-283-20

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

- Throttle linkage disconnected (TM 9-2320-273-20 or TM 9-2320-283-20).
- Cooling system drainplugs and drainvalves closed (TM 9-2320-273-20 or TM 9-2320-283-20).
- Starter electrical leads connected (TM 9-2320-273-20 or TM 9-2320-283-20).

SPECIAL ENVIRONMENTAL CONDITIONS

None

GENERAL SAFETY INSTRUCTIONS

- Allow adequate ventilation for engine exhaust gases.
- Diesel fuel is flammable.


LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Installation of Engine on Dynamometer

NOTE

Engine break-in will take place during dynamometer testing. Break-in on a new or rebuilt engine provides a short running period where moving parts acquire their final finish and mating surfaces reach a full seat. Engine dynamometer testing helps to find assembly errors, determine where adjustments are necessary after engine break-in, and test-runs engine long enough so final adjustments can be made.

1. Engine assembly (1)	a. Secure to suitable dynamometer test stand (4). b. Connect all instruments on control panel of dynamometer test stand.	Check dynamometer capacity. Ensure capacity is enough to permit testing at 96 percent of maximum engine horsepower. Dynamometer must be accurately calibrated.
2. Engine flexplate or flywheel, ring gear assembly (2) and dynamometer drive shaft flange (3)	Connect.	Check for proper alignment per dynamometer manufacturer's instructions.

3-91. STARTING REPAIRED ENGINE (Contd)**LEGEND:**

1. ENGINE ASSEMBLY
2. FLEXPATE OR FLYWHEEL, RING GEAR ASSEMBLY
3. DYNAMOMETER DRIVE SHAFT FLANGE
4. DYNAMOMETER TEST STAND

3-91. STARTING REPAIRED ENGINE (Contd)

LOCATION/ITEM	ACTION	REMARKS
3. Water supply and return hose	Secure to engine cooling system inlet and outlet connections.	
4. Fuel consumption gauge	Connect to fuel pump.	Refer to manufacturer's instructions.
5. Throttle linkage instrument	Connect to lever control.	Refer to manufacturer's instructions.
6. Turbocharger assembly	a. Connect suitable exhaust piping to exhaust side. b. Connect suitable filtered air intake piping to intake side.	

b. Priming Cooling System

7. Drainvalve (5)	Open.	Fill cooling system with a 50/50 mixture of permanent ethylene glycol antifreeze and water until it flows from drainvalve (5), then close and complete priming of cooling system.
-------------------	-------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

c. Priming Fuel System**WARNING**

Do not perform fuel system procedures while smoking or within 50 ft (15.2 m) of sparks or open flame. Diesel fuel is flammable and may explode. Failure to comply may result in injury to personnel.

8. Spin-on fuel filter (7)	Fill with clean diesel fuel.	
9. Fuel pump (9)	a. Remove case fill plug (10). b. Fill fuel pump (9) with clean diesel fuel. c. Reinstall case fill plug (10).	

d. Priming Lubricating System



10. Full-flow oil filter element (13) and bypass oil filter element (12)	Fill with clean OE/HDO 30 oil.	
--------------------------------------------------------------------------	--------------------------------	--

CAUTION

Remove turbocharger oil supply hose from turbocharger adapter, and lubricate bearing with approximately 2-3 oz (59-89 ml) of clean engine oil. Also, fill oil supply hose with engine lubricating oil. Connect oil supply hose. Failure to prelubricate turbocharger may result in bearing damage.

11. Crankcase	Fill to low mark (L) on dipstick.	Refer to LO 9-2320-273-12 or LO 9-2320-283-12.
12. Internal hexagon plug (11)	Remove.	Internal hexagon plug (11) is located on cylinder block flange at oil pump.

3-91. STARTING REPAIRED ENGINE (Contd)



LEGEND:

- 5. DRAINVALVE
- 7. SPIN-ON FUEL FILTER
- 8. FUEL PUMP PRESSURE SENDING UNIT
- 9. FUEL PUMP

- 10. CASE FILL PLUG
- 11. INTERNAL HEXAGON PLUG
- 12. BYPASS OIL FILTER ELEMENT
- 13. FULL-FLOW OIL FILTER ELEMENT

3-91. STARTING REPAIRED ENGINE (Contd)


LOCATION/ITEM	ACTION	REMARKS
13. Priming pump oil supply	Connect to internal hexagon plug hole.	Use a hand or motor line driven priming pump and a source of clean lubricating oil. Prime until a 30 psi (207 kPa) maximum pressure is reached.
14. Fuel shutoff solenoid wiring harness connector (6)	Disconnect.	Prevents engine from starting.
15. Crankshaft	Rotate with starter for 15 seconds.	Keep external oil pressure at a minimum of 15 psi (103 kPa).
16. Wiring harness connector (6)	Connect to fuel shutoff solenoid.	
17. Priming pump oil supply line	Remove.	
18. Internal hexagon plug (11)	Install.	Tighten plug (11) to 60-70 lb-ft (81-95 N•m).
19. Crankcase	Fill to high mark (H) on dipstick.	Refer to LO 9-2320-273-12 or LO 9-2320-283-12. Check for leaks.
20. Turbocharger drain tube (15)	Remove from 45° adapter (14).	

e. Prerun Startup

21. Engine assembly (1)	Start.	Maintain low rpm.
22. 45° adapter (14)	Check for oil flow.	Oil must drain from turbocharger in 10-15 seconds. If no oil flows in 10-15 seconds, stop engine and troubleshoot problem. Refer to troubleshooting para. 2-8. Connect turbocharger drain tube (15) to 45° adapter (14) once oil flow is established. Tighten fitting to 50-60 lb-ft (68-81 N•m).
23. Dynamometer test stand (4)	Add water per manufacturer's instructions.	
24. Tubes, hoses, fittings, and plugs	Check for leaks.	Correct as necessary.
25. Engine assembly (1)	Stop.	

FOLLOW-ON TASK: Perform engine dynamometer testing (para. 3-92).

3-91. STARTING REPAIRED ENGINE (Contd)



LEGEND:

- 1. ENGINE ASSEMBLY
- 4. DYNAMOMETER TEST STAND
- 6. WIRING HARNESS CONNECTOR

- 11. INTERNAL HEXAGON PLUG
- 14. 45° ADAPTER
- 15. TURBOCHARGER DRAIN TUBE

3-92. ENGINE DYNAMOMETER TESTING

THIS TASK COVERS:

- | | |
|---------------------|----------------------|
| a. Setup | d. Smoke Level Check |
| b. Break-in Running | e. Final Check |
| c. Power Check | |

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Blow-by measuring tool (15434) 3375150

TEST EQUIPMENT

Opacity meter

MATERIALS/PARTS

None

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (TM)

None

TROUBLESHOOTING REFERENCES

None

EQUIPMENT CONDITION

Engine mounted to dynamometer test stand (para. 3-91).

SPECIAL ENVIRONMENTAL CONDITIONS

None

GENERAL SAFETY INSTRUCTIONS

Allow adequate ventilation for engine exhaust gases.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


WARNING

Allow adequate ventilation for engine exhaust gases. Failure to comply may result in brain damage or death to personnel.

a. Setup

1. Breather tube (2)	Cover or plug.	
2. Blow-by measuring tool (4)	Install in place of oil filler cap (1).	Use blow-by measuring tool (3375150) (4) and water manometer. Fill to 0 mark at middle of scale. Close all other engine openings that would allow blow-by pressure to escape.
3. Air compressor (7)	Connect to a 0.125-0.130 in. (3.175-3.302 mm) diameter orifice adapter (5) located downstream from a 150 psi (1034 kPa) pressure relief valve (6).	Provides dynamic load for air compressor (7).

3-92. ENGINE DYNAMOMETER TESTING (Contd)



LEGEND:

- 1. FILLER CAP
- 2. BREATHER TUBE
- 3. DYNAMOMETER TEST STAND
- 4. BLOW-BY MEASURING TOOL

- 5. ORIFICE ADAPTER
- 6. PRESSURE RELIEF VALVE
- 7. AIR COMPRESSOR
- 8. ENGINE

3-92. ENGINE DYNAMOMETER TESTING (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


CAUTION

- Lubricating oil pressure should remain at or near a constant figure at constant engine speed and load after normal operating temperature is reached. Acceptable lubricating oil pressures are 5-20 psi (34-138 kPa) at idle speed and 35-45 psi (241-310 kPa) for Big Cam III and 40-75 psi (276-517 kPa) for Big Cam I at rated speed. Abnormally high pressures may indicate blocked lubricating oil lines. Abnormally low pressures indicate an insufficient supply of lubricating oil from the pump or increased engine clearances which may be due to bearing failure. Damage to engine may occur if oil pressure falls outside of acceptable range at indicated speeds.
- Lubricating oil temperature must not rise sharply above 225°F (107°C). Shut down engine and correct as necessary. Damage to engine may occur if oil temperature rises above acceptable limit.
- Check temperature of coolant. Temperature should not exceed 200°F (93°C) or drop below 160°F (71°C) during engine tests. Do not turn engine off immediately after a load run. Heat stored in engine will boil coolant in the water jackets if air and coolant circulation are immediately stopped while engine is hot. Allow engine to idle a minimum of three minutes before shutting down.
- Do not idle engine for prolonged periods of time before completing break-in running.

b. Break-in Running

4. Engine (8)	Start engine (8) and check oil pressure, oil temperature, and water temperature. Check for leaks. Operate air compressor (7) in pumping mode.	Idle at approximately 1200 rpm no-load for 5 to 10 minutes.
---------------	-----------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------

3-92. ENGINE DYNAMOMETER TESTING (Contd)



LEGEND:

- 7. AIR COMPRESSOR
- 8. ENGINE

3-92. ENGINE DYNAMOMETER TESTING (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

NOTE


- At each phase, record crankcase pressure blow-by, engine speed, and load at one minute intervals. Watch for increases or wide shifts in blow-by pressure. If a sudden increase in blow-by pressure occurs or if blow-by exceeds 12" H₂O, return to the previous phase test or repeat phase 1 test and operate engine an additional 15 minutes. If blow-by does not reach an acceptable level after repeating test for 15 minutes, discontinue test and determine cause. If blow-by is within an acceptable level, proceed to next phase test.
- After each test, check for fuel, air, water, oil, or exhaust leaks and correct as necessary.
- Lubricating oil level is checked only when engine is shut down or incorrect readings on dipstick will result.

5. Dynamometer test stand (3)	<p>a. Perform phase 1 test. Apply load to engine (8) at ±10 percent horsepower, ±5 percent speed. Check crankcase pressure with blow-by measuring tool (4). Operate engine (8) until normal oil operating temperature is attained. Stop engine (8) and check lubricating oil level. Add lubricating oil to bring level up to H (high) on dipstick. Allow oil temperature to stabilize. Operate air compressor (7) in pumping mode.</p>	Refer to phase 1 test in test chart.
-------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------

Table 3-1. Dynamometer Test Chart

ENGINE	HP @ RPM	RATED HP @ RPM 500 FT-ALT	FUEL RATE LB/HR	AIR MANIFOLD PRESSURE IN/HG	ALTITUDE MAX. HP ALT.	CRANKCASE PRESSURE W/TURBO T46B	PHASE 1 TO 160°F HP @ RPM	PHASE 2 2 MIN. HP @ RPM	PHASE 3 5 MIN. HP @ RPM	PHASE 4 4 MIN. HP @ RPM	POWER CHECK 4 MIN. HP @ RPM
NTC 400	400 @ 2100	400 @ 2100	139-145	39/47	12,000	12"H ₂ O	100 @ 1200	160 @1200	260 @1600	Full Load @1200	384 @ 2100

3-92. ENGINE DYNAMOMETER TESTING (Contd)



LEGEND:

- 3. DYNAMOMETER TEST STAND
- 4. BLOW-BY MEASURING TOOL

- 7. AIR COMPRESSOR
- 8. ENGINE

3-92. ENGINE DYNAMOMETER TESTING (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

NOTE

- At each phase, record crankcase pressure blow-by, engine speed, and load at one-minute intervals. Watch for increases or wide shifts in blow-by pressure. If a sudden increase in blow-by pressure occurs or if blow-by exceeds 12" H₂O, return to the previous phase test or repeat phase 1 test and operate engine an additional 15 minutes. If blow-by does not reach an acceptable level after repeating test for 15 minutes, discontinue test and determine cause. If blow-by is within an acceptable level, proceed to next phase test.
- After each test, check for fuel, air, water, oil, or exhaust leaks and correct as necessary.

b. Perform phase 2 test. Apply load to engine (8) at ±10 percent horsepower, ±5 percent speed. Check pressure with blow-by measuring tool (4). Set idle speed to 600 rpm and set full load governed speed to 2100 rpm. Adjust load and rpm until specified readings are obtained. Set fuel rate. Operate air compressor (7) in pumping mode.

Refer to phase 2 test in test chart.

Return fuel from injector drain is routed through float tank so when float tank is filled, float valve opens and allows return fuel flow to flowmeter. The amount of fuel being consumed by engine will flow through flowmeter and show rate of fuel consumption in pounds per hour. Turbocharger engines do not require fuel deaerating below maximum altitudes shown in table 3-1. Above maximum altitudes, deaerate at 4 percent for each 1000 ft (305 m) additional altitude and 1 percent for each 10°F (-12°C) air temperature rise above 12°F (-11°C).

Refer to phase 3 test on table 3-1.

c. Perform phase 3 test. Apply load to engine (8) at ±10 percent horsepower, ±5 percent speed. Check crankcase pressure with blow-by measuring tool (4). Operate air compressor (7) in pumping mode.

CAUTION

After phase 4 test is completed, allow engine to run at low idle for a minimum of three minutes before shutting down.

d. Perform phase 4 test. Apply load to engine at ±10 percent horsepower ±5 percent speed. Check crankcase pressure with blow-by measuring tool (4). Check for leaks and retighten all external screws to correct specifications. Operate air compressor (7) in non-pumping mode.

Refer to phase 4 test in test chart.

NOTE

Readjustment of valves and injectors after one hour of operation is necessary to assure lowest smoke potential and avoid excessive injector loads.

6. Valves	Recheck valves.	Refer to para. 3-85.
7. Injectors	Recheck injectors.	Refer to para. 3-85.

3-92. ENGINE DYNAMOMETER TESTING (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Power Check

CAUTION

Do not shut engine down immediately after power check is complete. Serious engine damage will result.

- | | | |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|
| 8. Engine (8) | a. Run at 2100 rpm for 4 minutes. Check crankcase pressure with blow-by measuring tool (4). Repeat procedure until engine (8) develops 96-100% rated horsepower at standard fuel rate within permissible crankcase pressure limit. Operate air compressor (7) in non-pumping mode. | Refer to power check in test chart. |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|


NOTE

At each phase, record crankcase pressure (blow-by), engine speed, and load at one-minute intervals. Watch for increases or wide shifts in blow-by pressure. If sudden increase happens, or if it is more than 12" H₂O, do the preceding test over again and run engine 15 more minutes. When blow-by is OK, do next test. If not OK, stop the test and find reason for too much blow-by. Check engine for fuel, oil, water, air, or exhaust leaks after each test and fix as needed.

- Phase 1 - 25% HP @1200 RPM @160° water temperature.
- Phase 2 - 40% HP @1200 RPM
- Phase 3 - 65% HP @1600 RPM
- Phase 4 - 100% HP @ Nominal torque peak RPM *(1200) RPM
- Power Check - 96-100% HP @1600 RPM
- *100 RPM below torque peak RPM

Table 3-1. Dynamometer Test Chart

ENGINE	HP @ RPM	RATED HP @ RPM 500 FT-ALT	FUEL RATE LB/HR	AIR MANIFOLD PRESSURE IN/HG	ALTITUDE MAX. HP ALT.	CRANKCASE PRESSURE W/TURBO T46B	PHASE 1 TO 160°F HP @ RPM	PHASE 2 2 MIN. HP @ RPM	PHASE 3 5 MIN. HP @ RPM	PHASE 4 4 MIN. HP @ RPM	POWER CHECK 4 MIN. HP @ RPM
NTC 400	400 @ 2100	400 @ 2100	139-145	39/47	12,000	12"H ₂ O	100 @ 1200	160 @1200	260 @1600	Full Load @1200	384 @ 2100



- LEGEND:
- 3. DYNAMOMETER TEST STAND
 - 4. BLOW-BY MEASURING TOOL
 - 7. AIR COMPRESSOR
 - 8. ENGINE

3-92. ENGINE DYNAMOMETER TESTING (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

c. Power Check (Contd)

NOTE

After each test, check for fuel, air, water, oil, or exhaust leaks and correct as necessary.

b. Apply dynamometer test stand (3) load as engine (8) rpm is increased until rated rpm and horsepower are reached and load is stabilized.	Engine (8) at normal oil operating temperature.
--------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------

d. Smoke Level Check

NOTE

An accurate smoke reading can usually be obtained in 10 to 15 seconds.

9. Opacity meter	Zero and place at exhaust side of turbocharger. Record reading.	Use 0-20 scale on opacity meter. Remove opacity meter after reading is taken. (12.84 percent) (3.6 percent Bosch)
10. Engine (8)	Increase dynamometer test stand (3) load until rpm is reduced to 60 percent of rated rpm.	
11. Opacity meter	Zero and place at exhaust side of turbocharger. Record reading.	Use 0-20 scale on opacity meter. Remove meter after reading is taken. (3.87 percent) (1.0 percent Bosch)
12. Engine (8)	Reduce dynamometer test stand (3) load and engine (8) rpm. Accelerate engine (8) to rated rpm, no-load. Return to idle.	Full acceleration should occur in 3-5 seconds.
13. Opacity meter	Zero and place at exhaust side of turbocharger.	Use 0-100 scale.
14. Engine (8)	Accelerate engine (8) to rated rpm, no-load. Record highest reading. Return engine (8) to idle.	Remove opacity meter after reading is taken. (22 percent) (4.3 percent Bosch)

e. Final Check

15. Crankcase pressure blow-by measuring tool (4)	Check pressure at end of testing procedure. If pressure is greater than specification listed in test chart, run engine (8) for additional 30 minutes at 96-100 percent rated load and rpm.	If there is no rapid change in excess of 2 in. of water and reading does not exceed 100 percent of representative pressure, blow-by is acceptable. Manometer readings not exceeding 0.3 in. (7.62 mm) surge are desirable.
---------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

3-92. ENGINE DYNAMOMETER TESTING (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

e. Final Check (Contd)

- 16. Orifice adapter (5) and air compressor (7) Remove from air compressor relief valve (6).
- 17. Blow-by measuring tool (4) and manometer Remove from engine (8) and install filler cap (1).
- 18. Breather tube (2) Unplug.

NOTE


At each phase, record crankcase pressure (blow-by), engine speed, and load at one minute intervals. Watch for increases or wide shifts in blow-by pressure. If sudden increase happens, or if it is more than 12" H₂O, do the preceding test over again and run engine 15 more minutes. When blow-by is OK, do next test. If not OK, stop the test and find reason for too much blow-by. Check engine for fuel, oil, water, air, or exhaust leaks after each test and fix as needed.

- Phase 1 - 25% HP @ 1200 RPM @ 160° water temperature.
- Phase 2 - 40% HP @ 1200 RPM
- Phase 3 - 65% HP @ 1600 RPM
- Phase 4 - 100% HP @ Nominal torque peak RPM *(1200) RPM
- Power Check - 96-100% HP @ 1600 RPM
- *100 RPM below torque peak RPM

FOLLOW-ON TASK: Perform on-engine fuel pump adjustment (para. 3-93).

Table 3-1. Dynamometer Test Chart

ENGINE	HP @ RPM	RATED HP @ RPM 500 FT-ALT	FUEL RATE LB/HR	AIR MANIFOLD PRESSURE IN/HG	ALTITUDE MAX. HP ALT.	CRANKCASE PRESSURE W/TURBO T46B	PHASE 1 TO 160°f HP @ RPM	PHASE 2 2 MIN. HP @ RPM	PHASE 3 5 MIN. HP @ RPM	PHASE 4 4 MIN. HP @ RPM	POWER CHECK 4 MIN. HP @ RPM
NTC 400	400 @ 2100	400 @ 2100	139-145	39/47	12,000	12" H ₂ O	100 @ 1200	160 @ 1200	260 @ 1600	Full Load @ 1200	384 @ 2100



LEGEND:

- 1. FILLER CAP
- 2. BREATHER TUBE
- 3. DYNAMOMETER TEST STAND
- 4. BLOW-BY MEASURING TOOL
- 5. ORIFICE ADAPTER
- 6. RELIEF VALVE
- 7. AIR COMPRESSOR
- 8. ENGINE

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT

THIS TASK COVERS:

- a. Preadjustment Checks
- b. Idle Speed Adjustment
- c. High Speed Adjustment
- d. High Idle Speed Adjustment
- e. Checking and Adjusting Fuel Rail Pressure
- f. Checking and Adjusting Engine Fuel Rate
- g. Checking and Adjusting Throttle Leakage
- h. Checking Engine Power
- i. Checking Fuel Filter Restriction
- j. Fuel Pump Seal Installation
- k. Throttle Shaft Cover Plate Installation

INITIAL SETUP:

APPLICABLE MODELS

All

SPECIAL TOOLS

Fuel pump idle adjusting tool (15434) 3315981
 Throttle shaft ball installing tool (15434) 3315204

TEST EQUIPMENT

Dynamometer

MATERIALS/PARTS

Gasket (15434) 10105
 Throttle shaft ball (15434) 213159
 Lockwire and seal (15434) 3003156
 Throttle shaft cover (15434) 3000466
 Two drive screws (15434) 5-2286

PERSONNEL REQUIRED

Automotive repairman MOS 63H

REFERENCES (FM)

LO 9-2320-273-12
 TM 9-2320-273-20
 TM 9-2320-273-34
 LO 9-2320-283-12
 TM 9-2320-283-20
 TM 9-2320-283-34

TROUBLESHOOTING REFERENCES

Para. 2-8

EQUIPMENT CONDITION

- Fuel control lever and throttle linkage adjusted (TM 9-2320-273-34 or TM 9-2320-283-34).
- Fuel lines connected (TM 9-2320-273-20 or TM 9-2320-283-20).
- Engine mounted to dynamometer (para. 3-91).
- Fuel pump primed (para. 3-91).
- Engine at operating temperature. Fuel temperature not above 110°F (43°C) (para. 3-91).
- Tachometer connected to tachometer drive shaft connection (para. 3-91).
- Shutoff valve electrical connection made. Manual control valve dosed (screwed out) (para. 3-88).
- Injection timing adjusted (para. 3-72).
- Valves and injectors adjusted. Fuel manifold pressure gauge connected (para. 3-85).
- Throttle shaft ball removed if fuel rail pressure adjustment is needed (para. 3-62).

SPECIAL ENVIRONMENTAL CONDITIONS

Work area clean and away from blowing dirt and dust.

GENERAL SAFETY INSTRUCTIONS

- Diesel fuel is highly flammable. Do not perform fuel pump adjustments near fire, flames, or sparks.
- Allow adequate ventilation for engine exhaust.

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

WARNING


- Allow adequate ventilation for engine exhaust gases. Failure to comply may result in brain damage or death to personnel.
- Do not perform fuel system procedures while smoking or within 50 ft (15.2 m) of sparks or open flame. Diesel fuel is flammable and may explode. Failure to comply may result in injury to personnel.

a. Preadjustment Checks

CAUTION

Do not alter pump settings to match gauges and tachometers of unknown accuracy.

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT (Contd)



LEGEND:

- | | |
|-----------------------------|--------------------------|
| 1. ENGINE | 9. SPRING PACK COVER |
| 2. DYNAMOMETER | 10. GASKET |
| 3. FUEL PUMP ASSEMBLY | 11. SNAPRING |
| 4. IDLE ADJUSTING TOOL | 12. SPRING RETAINER |
| 5. WASHER (4) | 13. SHIM(S) |
| 6. CAPTIVE WASHER SCREW (3) | 14. SPRING |
| 7. PLUG | 15. GUIDE |
| 8. SCREW | 16. IDLE ADJUSTING SCREW |

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

a. Preadjustment Checks (Contd)

NOTE

- Vehicle fuel control lever and throttle stop linkage should have a maximum throttle stop, so when fuel pump full throttle is obtained, override pressure will not be on throttle shaft.
- When fuel pump has been properly calibrated, very little adjustment should be required after installation on engine except idle, since this setting is dependent on parasitic loads. Fine adjustment of governor settings and fuel manifold pressure is permissible within the limits specified if justified by engine performance tests.

1. Throttle control linkage	Check and adjust for: a. Full throttle operation. b. Throttle released operation with throttle stopped by throttle leakage adjusting screw.	Refer to TM 9-2320-283-34 or TM 9-2320-273-34.
-----------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------

b. Idle Speed Adjustment

NOTE

Idle speed adjustment should never be made on a cold engine. Engine must be operated a sufficient period of time to purge all air from the fuel system and to bring the engine up to operating temperature (at least 165°F (74°C) oil temperature).

2. Spring pack cover (9)	Remove plug (7).	
3. Engine (1)	Start.	Engine (1) mounted to dynamometer (2).
4. Idle adjusting screw (16)	Adjust while engine (1) is running. Use idle adjusting tool (4) to set idle to 600 ± 2 rpm.	Turn idle adjusting screw (16) in to increase engine (1) rpm; out to decrease rpm. Fuel pump idle adjusting tool (3375981) (4) will not let the spring pack cover (9) leak when the idle is adjusted.
5. Spring pack cover (9)	Install plug (7).	


c. High Speed Adjustment

NOTE

A means of loading the engine must be used to perform this check. The tachometer and fuel manifold pressure gauge must be of high accuracy. The engine fuel system must be purged of all air and at operating temperature. If spring pack cover is opened to make adjustment, fuel pump must be purged of air before attempting cutoff setting adjustment. The preferred method of loading engine is on an engine or chassis dynamometer.

6. Spring pack cover (9), three captive washer screws (6), screw (8), and four washers (5)	Remove from fuel pump assembly (3).	
7. Fuel pump gasket (10)	Remove.	Discard gasket (10).
8. Snapping (11)	Remove.	Use snapping pliers.

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT (Contd)



LEGEND:

- | | |
|-----------------------------|--------------------------|
| 1. ENGINE | 7. PLUG |
| 2. DYNAMOMETER | 8. SCREW |
| 3. FUEL PUMP ASSEMBLY | 9. SPRING PACK COVER |
| 4. IDLE ADJUSTING TOOL | 10. FUEL PUMP GASKET |
| 5. WASHER (4) | 11. SNAPRING |
| 6. CAPTIVE WASHER SCREW (3) | 16. IDLE ADJUSTING SCREW |

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT (Contd)

LOCATION/ITEM	ACTION	REMARKS
9. Spring retainer (12)	Remove.	
10. New shim(s) (13)	Add or remove from behind spring (14). High speed adjustment should be 2130 to 2150 rpm.	Each 0.001 in. (0.025 mm) shim thickness will change speed approximately two rpm.
11. Spring retainer (12) and snapping (11)	Install on guide (15).	Use snapping pliers. Make certain shim(s) (13) do not slip off of guide (15).
12. Spring pack cover (9)	Secure with three captive washer screws (6), screw (8), and four washers (5).	Tighten screws (6) and (8) to 9-11 lb-ft (12-15 N•m). Screw (8) has hole drilled through head for sealing wire insertion.

d. High Idle Speed Adjustment**NOTE**

Do not use this check to make governor speed adjustments. If no-load speed is much greater than specifications, examine governor for malfunction or faulty parts.


13. Engine (1)	a. Operate to purge air from fuel system and bring up to operating temperature. b. Bring to full throttle and hold. Note maximum rpm.	Speed should be 10-12 percent greater than governor speed cutoff point. If on-engine fuel pump adjustments made with engine mounted in vehicle, rpm will depend on engine parasitic loads (fan, pumps, etc.).
----------------	------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

e. Checking and Adjusting Fuel Rail**NOTE**

- It should not be necessary to adjust fuel rail pressure on a newly calibrated fuel pump more than ± 2 psi (± 14 kPa). If adjustments greater than this are required, fuel pump test stand, injector test stand, or engine problems may exist. Do not remove throttle shaft ball unless fuel rail pressure adjustment needs to be performed.
- The correct method of checking engine fuel rail pressure is with engine installed on a chassis or engine dynamometer.

14. Governor speed cutoff	Check setting point.	Adjust, if necessary.
15. Fuel rail pressure gauge (19)	Install between fuel supply elbow (18) on fuel pump assembly (3) and female union tee (17).	
16. Engine(1)	Bring to full throttle load until rpm falls to rated speed.	Accurate tachometer must be used to measure rpm.
17. Fuel rail pressure gauge (19) Note reading.		If pressure is above or below the minimum specification, do step 18. If OK, go to step 19.

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT (Contd)



LEGEND:

- | | |
|-----------------------------|------------------------------|
| 1. ENGINE | 12. SPRING RETAINER |
| 3. FUEL PUMP ASSEMBLY | 13. SHIM(S) |
| 5. WASHER (4) | 14. SPRING |
| 6. CAPTIVE WASHER SCREW (3) | 15. GUIDE |
| 8. SCREW | 17. FEMALE UNION TEE |
| 9. SPRING PACK COVER | 18. FUEL SUPPLY ELBOW |
| 11. SNAPRING | 19. FUEL RAIL PRESSURE GAUGE |

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

18. Threaded stud (24) To adjust fuel rail pressure:

CAUTION

Do not turn threaded stud out beyond maximum throttle travel. The fuel hole in the throttle shaft will begin to close. Never adjust fuel rail pressure above maximum specifications. This will void engine warranty and violate EPA requirements.

- | | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> a. Turn out to get maximum throttle travel. Secure with jamnut (23). b. Remove throttle shaft ball (20). c. Turn fuel adjusting screw (22) in throttle shaft (21) in to increase or out to decrease pressure while watching fuel rail pressure gauge (19). d. It should not be necessary to adjust fuel manifold pressure on a newly calibrated pump more than ± 2 psi ($\pm .14$ kPa). If adjustments greater than these are required, fuel pump test, injector test stand, or engine problems may exist. e. Install throttle shaft ball (20) into end of throttle shaft (21) with throttle shaft ball installing tool (3375204) (25) after adjustment. | <ul style="list-style-type: none"> This will reduce throttle restriction. Refer to para. 3-62. |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|

f. Checking and Adjusting Engine Fuel


19. Fuel pump assembly (3) Connect suitable fuel rate meter (26).

NOTE

The fuel rate specified on fuel pump calibration specifications is at full throttle and rated speed. An engine or chassis dynamometer must be used. Accurate fuel rail pressure and speed readings must also be taken.

- | | |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>20. Engine (1)</p> | <ul style="list-style-type: none"> a. Bring engine (1) to full throttle and increase dynamometer load until engine rpm falls to rated speed. b. Check governor speed cut-off while a load is on engine (1). c. Check fuel rail pressure gauge (19) at maximum speed. d. Hold engine speed and load at maximum speed long enough for fuel rate meter (26) to stabilize. e. Verify correct fuel rate measurement with fuel rate meter (26). |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT (Contd)



LEGEND:

- | | |
|------------------------------|-----------------------------------------|
| 1. ENGINE | 22. FUEL ADJUSTING SCREW |
| 3. FUEL PUMP ASSEMBLY | 23. JAMNUT |
| 19. FUEL RAIL PRESSURE GAUGE | 24. THREADED STUD |
| 20. THROTTLE SHAFT BALL | 25. THROTTLE SHAFT BALL INSTALLING TOOL |
| 21. THROTTLE SHAFT | 26. FUEL RATE METER |

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------


g. Checking and Adjusting Throttle

NOTE

If throttle leakage is adjusted correctly on fuel pump test stand, fuel pump will not need to be adjusted on engine. Vehicle throttle linkage must be adjusted so that threaded stud of throttle leakage adjusting screw (rear screw) just contacts stop on pump throttle.

21. Engine (1)	<p>a. Bring engine to full throttle and allow engine to run at maximum no-load speed.</p> <p>b. Release or move throttle quickly and start a suitable timer or stopwatch at the same time.</p> <p>c. Stop timer when 1000 rpm is reached and check deceleration time. Repeat this check several times.</p> <p>d. Increase leakage if engine (1) begins to stall (idle governor does catch engine after deceleration from high idle).</p>	<p>The purpose of the throttle leakage is to keep the fuel lines and injector drilling full of fuel during closed throttle operation. The correct throttle leakage will help acceleration when the throttle is opened after going down a grade. Throttle leakage will also prevent stalling when it slows down to the idle speed. (Too much leakage will cause slow deceleration.)</p>
22. Threaded stud (27)	<p>a. Increase leakage by turning in.</p> <p>b. Recheck engine (1) deceleration until time is increased 1-2 seconds.</p> <p>c. Lock threaded stud (27) with jamnut (28).</p> <p>d. Recheck idle speed and readjust as necessary.</p> <p>e. Set engine to high idle.</p> <p>f. Check deceleration time when shutoff valve is closed (engine (1) is shut down).</p>	<p>If deceleration time is not faster by this method, throttle leakage is not the problem. If the deceleration time is faster by this method, throttle leakage must be reduced.</p>

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT (Contd)



- LEGEND:
 1. ENGINE
 27. THREADED STUD
 28. JAMNUT

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT (Contd)

LOCATION/ITEM	ACTION	REMARKS
23. Threaded stud (27)	a. Decrease leakage by turning out until engine (1) tends to stall after deceleration to high idle. b. Turn in until deceleration is increased 1-2 seconds. Lock threaded stud (27) with jamnut (28). c. Recheck idle speed and readjust as necessary.	

NOTE

Engine power cannot be set accurately in any other way except on engine dynamometer. Fuel pump adjustments must not be made on an engine when the engine power comes from an estimate. Before any adjustments on the fuel pump are made, the following engine performance data must be checked so that adjustments are justified.

24. Fuel rail pressure, fuel rate, speed setting, smoke, coolant temperature, combustion smoothness, exhaust restriction, fuel quality, air intake restriction, engine oil level, engine power reducing factors	Check.	Under no circumstances should specifications be exceeded.
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------	-----------------------------------------------------------


h. Checking Engine Power

25. Governor speed cutoff	Recheck setting point.	Readjust if necessary.
---------------------------	------------------------	------------------------

i. Checking Fuel Filter Restriction

26. Vacuum gauge (30)	Connect to fuel inlet (29) on damper (31).	Use suitable adapter.
27. Engine (1)	Bring engine (1) to full throttle and full load on dynamometer (2) and check vacuum gauge (30).	If restriction reads 8 in. (203 mm) of vacuum while engine (1) is running at full throttle and full load, change fuel filter. Refer to LO 9-2320-273-12 and LO 9-2320-283-12. Also check other sources of restriction. Use sight glass to check for moving bubbles and possible gasket or other leaks. If air bubbles are still seen after above checks, check float valve in float tank used for test. Fuel pump may be pumping more fuel than float valve will allow to pass into the float tank.

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT (Contd)



LEGEND:

- 1. ENGINE
- 2. DYNAMOMETER
- 27. THREADED STUD
- 28. JAMNUT

- 29. FUEL INLET
- 30. VACUUM GAUGE
- 31. DAMPER

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT (Contd)

LOCATION/ITEM	ACTION	REMARKS
---------------	--------	---------

j. Fuel Pump Seal Installation

NOTE

Fuel pump must be sealed after final adjustments are made to prevent tampering.


28. Spring pack cover (9), screw (8), threaded stud (27), and plug (7)	a. Using lockwire and seal (34), insert lockwire through screw (8), plug (7), and threaded stud (27). b. Twist lockwires together until connection is secure and lockwire is tight. c. Bend twisted lockwire into seal and press on top half of seal.	Seals spring pack cover (9) and threaded stud (27).
29. Spring pack cover (9), screw (8), cover assembly (32), captive washer screw (33), and drilled fillister head screw (35)	a. Using lockwire and seal (34), insert lockwire through screw (8), drilled fillister head screw (35), and captive washer screw (33). b. Twist lockwires together until connection is secure and lockwire is tight. c. Bend twisted lockwire into seal and press on top half of seal.	Seals cover assembly (32).

k. Throttle Shaft Cover Plate Installation

30. Throttle shaft cover plate (36) and two drive screws (37)	a. Position new throttle shaft cover plate (36) on housing (38). b. Drill two new holes on opposite sides of throttle shaft cover plate (36) 0.235 in. (5.969 mm) into pump housing. Do not attempt to drill out and reuse old mounting holes. c. Secure new throttle shaft cover plate (36) with two drive screws (37).	Use No. 44 0.086 in. (2.184 mm) drill. Use etching tool or steel stamp and imprint date of repair on backside of throttle shaft cover plate (36) for future reference.
---------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------

FOLLOW-ON TASK: Install engine in vehicle if tests done on engine dynamometer (TM 9-2320-273-34).

3-93. ON-ENGINE FUEL PUMP ADJUSTMENT (Contd)



LEGEND:

- | | |
|--------------------------|----------------------------------|
| 7. PLUG | 34. LOCKWIRE AND SEAL |
| 8. SCREW | 35. DRILLED FILLISTER HEAD SCREW |
| 9. SPRING PACK COVER | 36. THROTTLE SHAFT COVER PLATE |
| 27. THREADED STUD | 37. DRIVE SCREWS (2) |
| 32. COVER ASSEMBLY | 38. HOUSING |
| 33. CAPTIVE WASHER SCREW | |

Section VI. GENERAL MAINTENANCE INSTRUCTIONS

3-94. GENERAL

This section provides general instructions for temporary storage, long-term storage, and preparing an engine from storage to service. Additional information concerning storage of equipment can be found in TM 740-90-1.

3-95. TASK SUMMARY

TASK PARA	PROCEDURES
3-96.	Temporary Storage <ul style="list-style-type: none"> a. General Instructions b. Out-of-Service Engines
3-97.	Long-Term Storage <ul style="list-style-type: none"> a. General Instructions b. Out-of-Service Engines
3-98.	Preparing an Engine from Storage to Service <ul style="list-style-type: none"> a. General Instructions b. Cleaning the Engine c. Inspecting the Engine d. Additional Inspection

3-96. TEMPORARY STORAGE

a. General Instructions. All surfaces of an engine will rust or corrode if they are not protected. Ensure all outside surfaces of engine are painted before placing it in storage. Protect inside of engine during storage as described below.

b. Out-of-Service Engines. If an engine remains out of service from three or four weeks, to a maximum of six months, take steps to prevent rust. The operations listed below are required to prevent damage to engines in temporary storage.

(1) Start engine and gradually increase speed to 1200 rpm with no load. Operate engine until water temperature is at least 160°F (71°C).

(2) Stop engine and disconnect both fuel lines at fuel supply tank. Fill two portable containers, one with diesel fuel and a second with preservative oil, U.S. Military Specification VV-L-800, Type P-9.

(3) Start engine with fuel inlet line pulling fuel from can with diesel fuel. Let drain line flow into same container with inlet diesel fuel. After engine is started and is running at idle, move fuel line to container with preservative oil. Operate engine 5 to 10 minutes on preservative oil. Stop engine and reconnect fuel lines to supply tank.

(4) The oil sump (crankcase) fuel filter and fuel tank must be drained and drainplugs installed. New oil can be added to the sump.

(5) Rotate engine crankshaft while applying a spray of LOW oil into intake manifold and air compressor.

(6) Put tape over all intake manifold openings to keep out dirt and moisture.

(7) Put tape over all engine openings including coolant inlet, cylinder block, oil breather, and crankcase.

- (8) Drain coolant from cooling system unless permanent antifreeze with rust inhibitor is present.
- (9) Put engine in a place protected from the weather. Air should be dry and temperature even.
- (10) Rotate engine crankshaft two or three revolutions every three or four weeks.
- (11) Protect flexdisk with a rust preventative.

3-97. LONG-TERM STORAGE

NOTE

After engine has been in storage for 24 months, flush it with solvent and repeat preparation for storage.

a. General Instructions. When an engine is to be in storage for six months or more, it must be protected against rust and corrosion. Ensure all outside surfaces of engine are painted before placing it in storage.

b. Out-of-Service Engines. If an engine remains out of service for six months or more, take steps listed below to prevent damage:

(1) Start engine and gradually increase speed to 1200 rpm with no load. Operate engine until water temperature is at least 160°F (71°C). Stop engine and drain oil.

(2) Drain and fill crankcase to full mark on dipstick with preservative oil, U.S. Military Specification MIL-L-21260, Type P-10, type II, SAE 30.

(3) Disconnect both fuel lines at fuel supply tank. Fill two portable containers, one with diesel fuel and the second with preservative oil, U.S. Military Specifications VV-L-800, Type P-9.

(4) Start engine with fuel inlet and drain lines in can with diesel fuel. After engine is started and is running at idle, move fuel inlet line to container with preservative oil. Operate engine 5 to 10 minutes on preservative oil. Stop engine and reconnect fuel lines.

(5) Drain fuel and oil pumps, compressor, cooler, filters, and crankcase. Replace all plugs after draining.

(6) Remove intake and exhaust manifolds. Apply preservative oil in a spray into the intake and exhaust ports of the engine. Also apply it into intake port of the air compressor. Install intake and exhaust manifolds.

(7) Inspect coolant in cooling system. If coolant contains rust, drain and flush the system and fill it with a rust preventative. Use an oil which has rust inhibitors that will mix with water. Flush cooling system before returning it to service.

(8) Ensure all outside surfaces of engine are painted.

(9) Remove valve covers and apply preservative oil to rocker levers, valve stem, springs, guide, crossheads, and push tubes. Install valve covers.

(10) All engine openings must be covered with heavy paper and tape.

(11) Protect flexdisk with a rust preventative.

(12) Put a tag on engine to show the following:

(a) Engine has been prepared for storage.

(b) Coolant has been removed.

(c) Crankshaft must not be rotated.

(d) Date engine was prepared for storage.

(e) Compound used for storage must be removed before running engine.

(13) Put engine in a place protected from the weather and where the air is dry and temperature is even.

(14) Keep all rust-preventing compounds clean.

3-98. PREPARING AN ENGINE FROM STORAGE TO SERVICE**CAUTION**

Excess preservative oil in the combustion chamber can cause a hydraulic lock. Engine damage will occur if started before oil is removed.

a. General Instructions. When an engine is removed from storage and put into service, operations listed below must be completed.

b. Cleaning the Engine. Do the following to prepare engine for service:

- (1) Remove all dirt from the outside of engine.
- (2) Remove all paper covers and tape.
- (3) Use solvent to remove rust preventative from engine exterior.
- (4) Fill crankcase with clean oil.
- (5) Flush cooling system and refill with permanent-type antifreeze in a mixture suitable for appropriate temperature range.

c. Inspecting the Engine. Check for proper adjustment of injectors, valves, and belts if engine was held in storage for six months or less. Also check the oil filters, air filters, hose connections, and cylinder-head screws.

d. Additional Inspection. When engine has been in storage for six months or more, the following specific procedures must be followed:

- (1) Flush fuel system with fuel oil until fuel system is clean.
- (2) Remove plug from oil filter head and run hot, light, mineral oil through oil passages. Rotate engine by hand three or four times during the flushing operations.
- (3) Remove all filter screens and make sure they are clean before starting the engine.
- (4) Apply oil under pressure to lubricating system before starting engine.
- (5) Ensure all preservative oil is flushed away.

FOLLOW-ON TASK: Perform procedures under Starting Repaired Engine (para. 3-91).

**APPENDIX A
REFERENCES**

A-1. PUBLICATIONS INDEXES

Indexes should be consulted frequently for latest changes or revisions of references given in this appendix and for new publications relating to material covered in this publication.

- a. Military Publication Indexes.
 - Consolidated Index of Army Publications and Blank Forms DA Pam 310-1
 - Index of Blank Forms DA Pam 310-2
 - Index of Doctrinal, Training, and Organizational Publications DA Pam 310-3
 - Index of Technical Manuals, Technical Bulletins, Supply Manuals
(Types 7, 8, and 9), Supply Bulletins, and Lubrication Orders DA Pam 310-4
 - Index of Graphic Training Aids and Devices DA Pam 310-5
 - Index of Army Motion Pictures and Related Audiovisual Aids DA Pam 108-1
 - U.S. Army Equipment Index of Modification Work OrdersDA Pam 750-10

- b. General References.
 - Catalog of Abbreviations and Brevity CodesAR 310-50
 - How to Prepare and Conduct Military Training FM 21-6
 - Military Symbols FM 21-30

A-2. FORMS

Refer to DA Pam 738-750, The Army Maintenance Management System (TAMMS), for instructions on the use of maintenance forms pertaining to the materials.

A-3. OTHER PUBLICATIONS

The following publications contain information pertinent to the major item material and associated equipment:

- a. Vehicle.
 - Lubrication Order, Truck Tractor, M915, M916, and M920 LO 9-2320-273-12
 - Lubrication Order, Truck Tractor, M915A1 LO 9-2320-283-12
 - Lubrication Order, Dump Truck, M917 LO 5-3805-274-12
 - Lubrication Order, Bituminous Distributor, M918 LO 5-3895-224-12
 - Lubrication Order, Concrete Mobile, M919 LO 5-3895-372-12
 - Operators Manual, Truck Tractor, M915 TM 9-2320-273-10
 - Operator's Manual, Truck Tractor, M915A1 TM 9-2320-283-10
 - Organizational Maintenance, Truck Tractor, M915 TM 9-2320-273-20
 - Organizational Maintenance, Truck Tractor, M915A1 TM 9-2320-283-20
 - Organizational Maintenance Repair Parts and
Special Tools List, Truck Tractor, M915 TM 9-2320-273-20P
 - Organizational Maintenance Repair Parts and
Special Tools List, Truck Tractor, M915A1 TM 9-2320-283-20P
 - Direct and General Support Maintenance, Truck Tractor, M915 TM 9-2320-273-34
 - Direct and General Support Maintenance, Truck Tractor, M915A1 TM 9-2320-283-34

A-3. OTHER PUBLICATIONS (Contd)

Direct and General Support Repair Parts and Special Tools List, Truck Tractor, M915	TM 9-2320-273-34P
Direct and General Support Repair Parts and Special Tools List, Truck Tractor, M915A1	TM 9-2320-283-34P
b. Camouflage.	
Camouflaged	FM 5-20
c. Decontamination.	
Chemical, Biological, and Radiological (CBR) Decontamination	TM 3-220
NBC (Nuclear, Biological, and Chemical) Defense	FM 21-40
d. General.	
Basic Cold Weather Manual	FM 31-70
Cooling System: Tactical Vehicles	TM 750-254
Manual for Wheeled Vehicles Driver	FM 21-305
Driver Selection and Training (Wheeled Vehicle)	FM 55-30
Northern Operations	FM 31-71
Operation and Maintenance of Ordnance Material in Extreme Cold Weather (0° to -65°F)	TM 9-207
Principles of Automotive Vehicles	TM 9-8000
Prevention of Motor Vehicle Accidents	AR 385-55
Procedures for Destruction of Tank-Automotive Equipment to Prevent Enemy Use	TM 750-244-6
e. Maintenance and Repair.	
Description, Use, Bonding Techniques, and Properties of Adhesives	TB ORD 1032
Inspection, Care, and Maintenance of Antifriction Bearings	TM 9-214
Materials Used for Cleaning, Preserving, Abrading, and Cementing Ordnance Materiel and Related Materials including Chemicals .TM	TM 9-247
Metal Body Repair and Related Operations	FM 43-2
Operation and Organizational, Field and Depot Maintenance: Storage Batteries, Lead-Acid Type	TM 9-6140-200-12
Painting Instructions for Field Use	TM 43-0139
Use of Antifreeze Solutions and Cleaning Compounds in Engine Cooling System	TM 43-0139
Welding Theory and Application	TM 9-237
f. Administrative Storage.	
General Packaging Instructions for Field Units	TM 746-10

APPENDIX B

DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE
REPAIR PARTS AND SPECIAL TOOLS LIST

Section I. INTRODUCTION

B-1. Scope.

This Repair Parts and Special Tools List (RPSTL) lists and authorizes spares and repair parts; special tools; Test, Measurement, and Diagnostic Equipment (TMDE); and other special support equipment required for performance of direct support, and general support maintenance of the NTC-400 Cummins Big Cam I and Big Cam III engines. It authorizes the requisitioning, issue, and disposition of spares, repair parts, and special tools as indicated by the Source, Maintenance, and Recoverability (SMR) codes.

B-2. General.

This RPSTL is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in their own functional group within section II. Repair parts for repairable special tools are also listed in this section. Items listed are shown on the associated illustration(s)/figure(s).


b. Section III. Special Tools List. A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL (as indicated by Basis of Issue (BOI) information in DESCRIPTION AND USABLE ON CODE column) for the performance of maintenance.

c. Section IV. National Stock Number and Part Number Index. A list, in ascending National Item Identification Number (NIIN) (last nine numerals) sequence, of all National stock numbered items appearing in the listing, followed by a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

B-3. Explanation of Columns (Sections II and III).

a. Item No. (Column (1)). Indicates the number used to identify items called out in the illustration.

b. SMR Code (Column (2)). The Source, Maintenance, and Recoverability (SMR) code is a 5-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout:



* Complete Repair: Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the "repair" function in a use/user environment in order to restore serviceability to a failed item.

(1) Source Code. The source code tells you how to get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follow:

Code	Explanation
PA } PB } PC** } PD } PE } PF } PG }	Stocked items: use the applicable NSN to request/requisition items with these source codes. They are authorized to the category indicated by the code entered in the 3d position of the SMR code. ** NOTE: Items coded PC are subject to deterioration.
KD } KF } KB }	Items with these codes are not to be requested/requisitioned individually. They are part of a kit which is authorized to the maintenance category indicated in the 3d position of the SMR code. The complete kit must be requisitioned and applied.
MO - (Made at Unit Level) } MF - (Made at DS Level) } MH - (Made at GS Level) } ML - (Made at Specialized } Repair Activity (SPA)) } MD - (Made at Depot) }	Items with these codes are not to be requested/requisitioned individually. They must be made from bulk material which is identified by the part number in the DESCRIPTION AND USABLE ON CODE (UOC) column and listed in the bulk material group of the repair parts list in the RPSTL. If the item is authorized to you by the 3d position code of the SMR code, but the source code indicates it is made at a higher level, order the item from the higher level of maintenance.
AO - (Assembled by Unit Level) } AF - (Assembled by DS Level) } AH - (Assembled by GS Level) } AL - (Assembled by SRA) } AD - (Assembled by Depot) }	Items with these codes are not to be requested/requisitioned individually. The parts that make up the assembled item must be requisitioned or fabricated and assembled at the level of maintenance indicated by the source code. If the 3d position code of the SMR code authorizes you to replace the item, but the source code indicates the item is assembled at a higher level, order the item from the higher level of maintenance.

- XA - Do not requisition an XA-coded item. Order its next higher assembly. (Also refer to the note below.)
- XB - If an XB-coded item is not available from salvage, order it using the CAGEC and part number given.
- XC - Installation drawing, diagram, instruction sheet, field service drawing, that is identified by manufacturer's part number.
- XD - Item is not stocked. Order an XD-coded item through normal supply channels using the CAGEC and part number given if no NSN is available.

NOTE

Cannibalization or controlled exchange, when authorized, may be used as a source of supply for items with the above source codes, except for those source-coded XA.

(2) Maintenance Code. Maintenance codes tell you the level(s) of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the 3d and 4th positions of the SMR code as follows:

(a) The maintenance code entered in the 3d position tells you the lowest maintenance level authorized to remove, replace, and use an item. The maintenance code entered in the 3d position will indicate authorization to one of the following levels of maintenance.

Code	Application/Explanation
C	- Crew or operator maintenance done within unit maintenance.
O	- Unit level can remove, replace, and use the item.
F	- Direct support level can remove, replace, and use the item.
H	- General support level can remove, replace, and use the item.
L	- Specialized repair activity can remove, replace, and use the item.
D	- Depot level can remove, replace, and use the item.

(b) The maintenance code entered in the 4th position tells you whether or not the item is to be repaired and identifies the lowest maintenance level with the capability to do complete repair (i.e., perform all authorized repair functions). **(NOTE: Some limited repair may be done on the item at a lower level of maintenance if authorized by the Maintenance Allocation Chart (MAC) and SMR codes.)** This position will contain one of the following maintenance codes:

Code	Application/Explanation
O	- Unit is the lowest level that can do complete repair of the item.
F	- Direct support is the lowest level that can do complete repair of the item.
H	- General support is the lowest level that can do complete repair of the item.
L	- Specialized repair activity (designate the specialized repair activity) is the lowest level that can do complete repair of the item.
D	- Depot is the lowest level that can do complete repair of the item.
Z	- Nonreparable. No repair is authorized.
B	- No repair is authorized. (No parts or special tools are authorized for the maintenance of a B-coded item.) However, the item may be reconditioned by adjusting, lubricating, etc., at the user level.

(3) **Recoverability Code.** Recoverability codes are assigned to items to indicate the disposition action on unserviceable items. The recoverability code is entered in the 5th position of the SMR code as follows:

Recoverability Code	Application/Explanation
Z	- Nonreparable item. When unserviceable, condemn and dispose of the item at the level of maintenance shown in 3d position of SMR code.
O	- Repairable item. When uneconomically repairable, condemn and dispose of the item at unit level.
F	- Repairable item. When uneconomically repairable, condemn and dispose of the item at the direct support level.
H	- Repairable item. When uneconomically repairable, condemn and dispose of the item at the general support level.
D	- Repairable item. When beyond lower level repair capability, return to depot. Condemnation and disposal of item not authorized below depot level.
L	- Repairable item. Condemnation and disposal not authorized below SRA.
A	- Item requires special handling or condemnation procedures because of specific reasons (e.g., precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals/directives for specific instructions.

c. **National Stock Number (Column (3)).** This column indicates the National Stock Number (NSN) assigned to the item. Use the NSN for requests/requisitions.

d. **CAGE Code (Column (4)).** The Commercial and Government Entity Code (CAGEC) is a 5-digit numeric code which is used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

e. **Part Number (Column (5)).** Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify an item or range of items.

NOTE

When you use a NSN to requisition an item, the item you receive may have a different part number from the part ordered.

f. **Description and Usable on Codes (UOC) (Column (6)).** This column includes the following information:

- (1) The Federal item name and, when required, a minimum description to identify the item.
- (2) Items that are included in kits and sets are listed below the name of the kit or set.
- (3) Spare/repair parts that make up an assembled item are listed immediately following the assembled item line entry.
- (4) Part numbers for bulk materials are referenced in this column in the line item entry for the item to be manufactured/fabricated.
- (5) When the item is not used with all serial numbers of the same model, the effective serial numbers are shown on the last line(s) of the description (before UOC).
- (6) The usable on code, when applicable (refer to paragraph 5, Special Information).
- (7) In the Special Tools List section, the Basis of Issue (BOI) appears as the last line(s) in the entry for each special tool, special TMDE, and other special support equipment. When density of equipment supported exceeds density spread indicated in the basis of issue, the total authorization is increased proportionately.
- (8) The statement END OF FIGURE appears just below the last item description in column 6 for a given figure in both section II and section III.


g. **QTY (Column (7)).** The Quantity Incorporated in Unit (QTY INC IN UNIT) indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in place of a quantity indicates that no specific quantity is applicable (e.g., shims, spacers).

B-4. Explanation of Columns (Section IV).

a. **National Stock Number (NSN) Index.**

(1) **Stock number column.** This column lists the NSN by National Item Identification Number (NIIN)

sequence. The NIIN consists of the last nine digits of the NSN (i.e., 5305-01-674-1467). When using this column



to locate an item, ignore the first 4 digits of the NSN. However, the complete NSN should be used when ordering items by stock number.

(2) **Fig. Column.** This column lists the number of the figure where the item is identified/located. The figures are in numerical order in section II and section III.

(3) **Item Column.** The item number identifies the item associated with the figure listed in the adjacent FIG. column. This item is also identified by the NSN listed on the same line.

b. **Part Number Index.** Part numbers in this index are listed by part number in ascending alphanumeric sequence (i.e., vertical arrangement of letter and number combination which places the first letter or digit of each group in order A through Z, followed by the numbers 0 through 9 and each following letter or digit in like order).

(1) **CAGEC Column.** The Commercial and Government Entity Code (CAGEC) is a 5-digit numeric code used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

(2) **Part Number Column.** Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements to identify an item or range of items.

(3) **Stock Number Column.** This column lists the NSN for the associated part number and manufacturer identified in the PART NUMBER and CAGEC columns to the left.

(4) **Fig. Column.** This column lists the number of the figure where the item is identified/located in section II and section III.

(5) **Item Column.** The item number is that number assigned to the item as it appears in the figure referenced in the adjacent figure number column.

B-5. Special Information.

Usable on Code. Not Applicable.

B-6. How to Locate Repair Parts.

a. When National Stock Number or Part Number is Not Known.

(1) **First.** Using the table of contents, determine the assembly group or subassembly group to which the item belongs. This is necessary since figures are prepared for assembly groups and subassembly groups, and listings are divided into the same groups.

(2) **Second.** Find the figure covering the assembly group or subassembly group to which the item belongs.

(3) **Third.** Identify the item on the figure and use the Figure and Item Number Index to find the NSN.

b. When National Stock Number or Part Number is Known.

(1) **First.** Using the Index of National Stock Numbers and Part Numbers, find the pertinent National Stock Number or Part Number. The NSN index is in National Item Identification Number (NIIN) sequence (see 4.a.(1)). The part numbers in the Part Number index are listed in ascending alphanumeric sequence (see 4.b.). Both indexes cross-reference you to the illustration figure and item number of the item you are looking for.

(2) **Second.** After finding the figure and item number, verify that the item is the one you're looking for, then locate the item number in the repair parts list for the figure.




Figure 1. Dressed Engine and Container.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 01 ENGINE	
					GROUP 0100 ENGINE ASSEMBLY	
					FIG. 1 DRESSED ENGINE AND CONTAINER	
1	PAFHH	2815014381517	19207	57K3603	ENGINE, DIESEL DRESSED, W/CONTAINER, M915A1, BIG CAM III	1
1	PAFHH	2815014373901	19207	57K3602	ENGINE, DIESEL DRESSED, W/CONTAINER, M915, BIG CAM I	1
2	PAOZZ	5310011446115	75078	001094	.NUT, PLAIN, CONE SEAT	4
3	PAOZZ	5310005845272	96906	MS35338-48	.WASHER, LOCK	4
4	PAOZZ	5365011475030	75078	001234	.SPACER, SLEEVE	4
5	PAOZZ	5342004042946	15434	170226	.BRACKET, ENGINE LIFT.....	2
6	XBOZZ		15434	3003480	.LABEL M915.....	1
7	PAOZZ	5305008046318	15434	S-2286	.SCREW.....	5
8	PAOZZ	7690010946720	15434	3045551	.MARKER, IDENTIFICATI M915 BIG CAM I.....	1
8	PAOZZ	9905011470933	15434	3027282	.PLATE, IDENTIFICATIO M915A1 BIG..... CAM III	1
9	PAFHH	2815011422745	19207	11669835	.ENGINE, DIESEL DRESSED, W/O CONTAINER, M915A1	1
9	PAFHH	2815010843447	34623	MA87-21005	.ENGINE, DIESEL DRESSED, W/O CONTAINER, M915.....	1
10	PAFFF	8145014458271	19207	12389942-1	.SHIPPING AND STORAG WITHOUT ENGINE.....	1

END OF FIGURE




Figure 2. Engine Block.

SECTION II

TM 9-2815-225-34&P


(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 0101 CRANKCASE, BLOCK, CYLINDER HEAD	
					FIG. 2 ENGINE BLOCK	
1	PAHHH	2815000117786	15434	3801826	CYLINDER SLEEVE ASSEMBLY	6
2	XBHZZ		15434	213740	.CYLINDER SLEEVE	1
3	PCHZZ	5330000644399	15434	215090	.GASKET.....	1
4	PCHZZ	5330010490466	15434	3008998	.PACKING BLACK.....	1
5	PCHZZ	5331000581767	15434	149105PC183049	.O-RING RED	1
6	PAHHH	2815011058768	15434	3013909	ENGINE BLOCK, DIESEL M915	1
6	PAHHH	2815011419370	15434	3801310	ENGINE BLOCK, DIESEL M915A1	1
7	PAHZZ	5315002817610	15434	68445	.PIN, GROOVED, HEADLES HEAD TO BLOCK.	6
8	PAHZZ	4730012147081	15434	3008469	.PLUG, PIPE 3/4"	1
9	PAHZZ	4730000819618	79470	C3159X2	.PLUG, PIPE 1/8-27 NPTF	7
10	PAHZZ	4730009541281	02978	MS49005-4	.PLUG, PIPE 1/4-18 NPTF	3
11	PAHZZ	5305011129021	15434	3013904	.SCREW WITH CAPTIVE WASHER, 1/4-20	6
					X 5/8	
12	PAHZZ	5340007990843	15434	132019	.COVER, ACCESS WATER HEADER	1
13	PFHZZ	5330005372382	15434	70089-1	.GASKET WATER HEADER COVER PART OF.....	1
					KIT P/N 3801235	
14	PAHZZ	4730002030549	15434	S-966E	.PLUG, PIPE 1-1/2 NPT	1
15	PAHZZ	5340000501600	96906	MS35648-8	.PLUG, EXPANSION 1-1/8"	1
16	PAHZZ	4730011615115	15434	3013786	.PLUG, PIPE 3/8 NPT	6
17	PAHZZ	5340011459362	15434	3011952	.CAP, PROTECTIVE, DUST CAM HOLE	1
18	PAHZZ	5315000141195	15434	68585	.PIN, STRAIGHT, HEADLE CAM FOLLOWER.....	6
19	PAHZZ	4730002212139	96906	MS20913-4S	.PLUG, PIPE 1/2-14 NPT	2
20	PAHZZ	5315005329388	64104	B2568	.PIN, STRAIGHT, HEADLE REAR MAIN	2
					BEARING CAP TO BLOCK.....	
21	PAHZZ	5310003561447	15434	3009213	.WASHER, LOCK BLOCK, DIESEL ENGINE,	14
					M915 ONLY.....	
21	PAHZZ	5310000821882	15434	140218	.WASHER, FLAT BLOCK, DIESEL ENGINE.	14
					M915A1 ONLY	
22	PAHZZ	5306008042468	15434	105953	.BOLT, MACHINE M915 ONLY	14
22	PAHZZ	5305011792380	15434	208346	.SCREW, CAP, HEXAGON H M915A1 ONLY.....	14
23	PAHZZ	2815004848360	15434	42647	.CAP, MAIN BEARING NUMBER 7, BLOCK,	1
					DIESEL ENGINE. M915 ONLY.....	
23	PAHZZ	3130011461228	15434	3008049	.CAP, PILLOW BLOCK NUMBER 7. M915A1	1
					ONLY	
24	PAHZZ	3130004089041	15434	42646	.CAP, PILLOW BLOCK MAIN 2, 4 AND 6,	3
					BLOCK, DIESEL ENGINE. M915 ONLY	
24	PAHZZ	3130011464504	15434	3008048	.CAP, BEARING NUMBER 2, 4 AND 6.	3
					M915A1 ONLY.....	
25	PAHZZ	2815004848359	15434	42645	.CAP, MAIN BEARING MAIN 1, 3 AND 5,	3
					BLOCK, DIESEL ENGINE. M915 ONLY	
25	PAHZZ	3130011461150	15434	3008047	.CAP, PILLOW BLOCK NUMBER 1, 3 AND	3
					5. M915A1 ONLY	
26	PAHZZ	4730008018186	15434	S-915-A	.PLUG, PIPE	2
27	PAHZZ	4730000189566	15434	S911B	PLUG, PIPE 1/8-27 NPT	2
28	PAHZZ	5365011506257	15434	210884	.PLUG, MACHINE THREAD HEXAGON HEAD,	1
					7/8-18 UNS-2A	
29	PAHZZ	5310001975304	15434	66292	.WASHER, FLAT	1
30	PFHZZ	3120010796823	15434	3011951	.BEARING, SLEEVE CAMSHAFT, NUMBER 7.....	1

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
30	PFHZZ	3120012088102	15434	3028075	M915A1 PART OF KIT P/N 3801106BUSHING, CAMSHAFT, NUMBER 1, 2, 4 AND 6. M915A1 PART OF KIT P/N 3801106.	4
30	PFHZZ	3120022088103	15434	3028269	.BUSHING, CAMSHAFT, NUMBER 3 AND 5. M915A1 PART OF KIT P/N 3801106BEARING, SLEEVE CAMSHAFT M915.....	2
30	PFHZZ	3120010796823	15434	3011951	.PLUG, EXPANSION.....	7
31	PAHZZ	5340002765847	15434	S719	GASKET.....	1
32	PAHZZ	5330001717267	15434	67963	FLANGE, PIPE, BLIND	1
33	PFHZZ	4730004042909	15434	13264800	WASHER, LOCK 3/8.....	2
34	PAHZZ	5310002617340	15434	S604	SCREW, CAP, HEXAGON H.....	2
35	PAHZZ	5305005466698	15434	S129	SEALING COMPOUND (3 OZ TUBE).....	1
36	PCHZZ	8030011478661	15434	3801048	SCREW , SELF-LOCKING	6
37	PAHZZ	5305011446204	34623	5731317	NOZZLE, PISTON COOLI.....	6
38	PAHZZ	2910011467955	15434	3013591	O-RING COOLING NOZZLE PART	6
39	PCHZZ	5331011455377	15434	3007442	OF KIT P/N 3801235.....	6
40	PBHZZ	5365011479802	15434	3019955	GASKET CYLINDER LINER, 0.007	6
40	PBHZZ	5365004880799	15434	3019956	SPACER, RING CYLINDER LINER, 0.008.....	6
40	PBHZZ	5365011472495	15434	3019960	SHIM CYLINDER LINER, 0.062.....	6
40	PBHZZ	5365011472497	15434	3019958	SPACER, RING CYLINDER LINER, 0.020.....	6
40	PBHZZ	5365011472496	15434	3019957	SHIM CYLINDER LINER, 0.009.....	6
40	PBHZZ	5365011488353	15434	3019959	SHIM CYLINDER LINER, 0.031.....	6

END OF FIGURE



* a PART OF ITEM 23

Figure 3. Cylinder Head Assembly.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 0101 CRANKCASE, BLOCK, CYLINDER HEAD	
					FIG. 3 CYLINDER HEAD ASSEMBLY	
1	PAFFD	2815010858282	15434	3041993	CYLINDER HEAD, DIESE	3
2	PAFZZ	2805002939699	77220	H231	.LOCK, VALVE SPRING R	16
3	PAFZZ	5340009333009	15434	170296	.SEAT, HELICAL COMPRE	8
4	PAFZZ	5360000099270	15434	211999	.SPRING, HELICAL, COMP	8
5	PAFZZ	5340006326239	15434	172034	.SEAT, HELICAL COMPRE	8
6	PCFZZ	5331010724436	15434	3007759	.O-RING PART OF KIT P/N 3804280	2
7	PAFZZ	2910000857442	15434	147056	.SLEEVE, COOLING, FUEL HEAD M915 ONLY	2
7	PAFZZ	2910011460048	15434	3011934	.SLEEVE, COOLING, FUEL M915A1 ONLY	2
8	PAFZZ	5315008665015	15434	123558	.PIN, STRAIGHT, HEADLE VALVE	4
					CROSSHEAD	
9	PAFZZ	5340010870681	15434	213395	.PLUG, EXPANSION 1.010-1.012	6
10	PAFZZ	2815000857434	15434	3017759	.INSERT, ENGINE VALVE INTAKE AND	8
					EXHAUST	
10	PAFZZ	2815001320240	15434	3014622	.INSERT, ENGINE VALVE 0.010 OVERSIZE	V
10	PAFZZ	2815011271060	15434	3014623	.INSERT, VALVE SEAT 0.020 OVERSIZE	V
10	PAFZZ	2815011273597	15434	3014624	.INSERT, ENGINE VALVE 0.030 OVERSIZE	V
10	PAFZZ	2815011273598	15434	3014625	.INSERT, VALVE SEAT 0.040 OVERSIZE	V
11	XDFZZ		15434	3000926	.VALVE, POPPET, ENGINE INTAKE M915	4
					ONLY	
11	PAFZZ	2815013542702	15434	3803512	.VALVE, POPPET, ENGINE INTAKE M915A1	4
					ONLY	
12	PAFZZ	2815009625623	15434	3803524	.VALVE, POPPET, ENGINE EXHAUST	4
13	PAFZZ	5340010870682	15434	213394	.PLUG, EXPANSION 3/4	1
14	PAFZZ	5340010866193	15434	216524	.PLUG, EXPANSION 1-1/4	2
15	PAFZZ	2815010852618	15434	3006456	.GUIDE, VALVE STEM INTAKE AND	8
					EXHAUST STANDARD	
15	XDFZZ		15434	3006457	.GUIDE, VALVE STEM 0.010 OVERSIZE	V
15	XDFZZ		15434	3006458	.GUIDE, VALVE STEM 0.020 OVERSIZE	V
16	PAFZZ	2815011591789	15434	3030038	VALVE, CROSSHEAD ASS INTAKE AND	12
					EXHAUST	
17	PAFZZ	5305000624378	15434	147389	.SETSCREW 3/8-24 UNF-2A THREAD	1
18	PAFZZ	5310004263990	15434	203131	.NUT, CROSS HD	1
19	PAFZZ	2815010853733	75078	011573	.CROSSHEAD, VALVE	1
20	PAFZZ	5305004776769	15434	70772	SCREW, ASSEMBLED WAS 1/4-20 X 1/2	12
21	PAFZZ	2910009283505	15434	147100	CROSSOVER, FUEL	2
22	PCFZZ	5331001438485	15434	131026	O-RING PART OF KIT P/N 3804280 PART	12
					OF KIT P/N 3804275	
23	PAFZZ	5330010805021	15434	3076189	GASKET CYLINDER HEAD STANDARD PART	3
					OF KIT P/N 3804280 PART OF KIT P/N	
					3804275	
23	XDFZZ		15434	3040180	GASKET, CYLINDER HEA 0.010-0.020	3
					OVERSIZE	
24	PAFZZ	4730000189566	15434	S-911-B	PLUG, PIPE 1/8-27 NPT	10
25	PAFZZ	4730004441710	15434	181213	ELBOW, PIPE TO TUBE FUEL LINE TO	2
					HEAD	
26	PAFZZ	2815011464164	15434	135308	PLATE, FUEL CROSSOVE	2
27	PAFZZ	5310002858833	15434	538174	WASHER, FLAT 0.708-0.710	36
28	PAFZZ	5305011458379	15434	3013623	SCREW, CAP, HEXAGON H	36

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
29	PAFZZ		15434	68803-A	VALVE SPRING SPACER	V

END OF FIGURE




Figure 4. Crankshaft Assembly.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0102 CRANKSHAFT						
FIG. 4 CRANKSHAFT ASSEMBLY						
1	PCFZZ	5330003612955	15434	3067616	GASKET PART OF KIT P/N 3801235	V
2	PAHZZ	2990011202883	15434	216165	COVER, REAR CAMSHAFT M915 ONLY.....	1
2	PAFZZ	2815011465925	15434	209919	COVER, TIMING GEAR, I CAMSHAFT	1
3	PAFZZ	5305011306100	15434	3010594	M915A1 ONLY	8
4	PCHZZ	5330010866112	15434	3006738	SCREW, CAP, HEXAGON H WITH CAPTIVE	1
4	PAFZZ	5330000050858	01212	M39807	WASHER, 3/8-24 X 1.500	1
5	PCHZZ	5331004209624	15434	137075	GASKET M915 ONLY	1
6	PAHZH	2815013034224	15434	3608833	SEAL REAR CAMSHAFT OIL M915A1 ONLY	1
7	PAHZZ	3120012147779	15434	3019218	PART OF KIT P/N 3801235	1
7	XDHZZ		15434	157281	O-RING REAR CAMSHAFT OIL SEAL.....	1
7	XDHZZ		15434	157282	CRANKSHAFT, ENGINE.....	1
8	PAHZZ	5315010584551	15434	202903	BEARING, WASHER, THRU STANDARD	4
9	PAHZZ	5365004286201	15434	60575	BEARING, WASHER, THRU 0.010 OVERSIZE.	V
10	PAHZZ	5330000050856	15434	3006736	BEARING, WASHER, THRU 0.020 OVERSIZE.	V
11	PAFZZ	3020010774411	15434	211918	PIN STRAIGHT HEXAGO 0.219 X 0.5475-.....	2
12	PAFZZ	2815010791632	15434	21732300	0.5775	7
13	PAFZZ	5305007959336	15434	204165	SPACER, RING	1
14	PAFZZ	5310000818500	15434	127316	SEAL PART OF KIT P/N 3801235	1
15	PAHZZ	3020010772229	15434	215965	PULLEY, GROOVE.....	1
15	PAFZZ	3020011460107	15434	3014614	DAMPENER, VIBRATION	1
16	PAFZZ	5315010796740	15434	210179	SCREW, CAP 1-5/8 LONG	6
17	PAHZZ	3120003496444	15434	44383	WASHER, RECESSED	6
18	XDHZZ		15434	195210	GEAR, HELICAL M915 ONLY	1
19	PAHZZ	3120000905504	15434	44387	GEAR, HELICAL M915A1 ONLY	1
20	PAHZF	3120006951232	15434	3019180	KEY, MACHINE GEAR TO CRANKSHAFT.....	1
21	PAHZZ	3120000050602	01212	1962CPA	BEARING HALF, SLEEVE NUMBER 1, 3 AND	3
22	PAHZZ	3120005931507	15434	3019204	BEARING HALF, SLEEVE NUMBER 1, 3 AND	3
23	PFHZZ	3120002195461	15434	AR07110	5 UPPER PART OF KIT P/N 3801260	3
23	PFHZZ	3120011439547	15434	3801261	BEARING HALF, SLEEVE NUMBER 2, 4 AND	3
23	PBHZZ	3120011459132	15434	3801263	6 LOWER PART OF KIT P/N 3801260	3
23	PFHZZ	3120011937083	01212	5116M40	BEARING HALF, SLEEVE NUMBER 7 UPPER	1
23	PAHZZ	3120011448882	15434	3801262	PART OF KIT P/N 3801260.....	1
23	PAHZZ	3120011448882	15434	3801262	BEARING HALF SET, SL STANDARD	1
23	PAHZZ	3120011448882	15434	3801262	BEARING HALF SET, SL 0.010 UNDERSIZE.....	1
23	PAHZZ	3120011448882	15434	3801262	BEARING HALF SET, SL 0.030 UNDERSIZE.....	1
23	PAHZZ	3120011448882	15434	3801262	BEARING SET, SLEEVE 0.040 UNDERSIZE.	1
23	PAHZZ	3120011448882	15434	3801262	BEARING HALF SET, SL 0.020 UNDERSIZE.....	1

END OF FIGURE




Figure 5. Flexdisk, Ring Gear, and Housing.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0103 FLYWHEEL ASSEMBLY						
FIG. 5 FLEXDISK, RING GEAR, AND HOUSING						
1	XDFZZ		15434	3031751	DISC, FLEX ASSEMBLY USE ONLY FOR INTERFACING BIG CAM III ENG W/ ALLISON HT-750 CRD TRANSMISSION.....	1
2	PAFZZ	5305002693240	80204	B1821BH038F150N	.SCREW, CAP, HEXAGON H 3/8-24 X 1.50 M915A1 ONLY	12
3	PBFZZ	3040011460028	15434	3031752	.PLATE, RETAINING, SHA M915A1 ONLY.....	1
4	XDFZZ		15434	3031750	.DISKS, FLEXPLATE USE ONLY FOR INTERFACING BIG CAM III ENG W/ ALLISON HT-750 CRD TRANSMISSION	1
5	PBFZZ	2815011460102	15434	3031749	.FLYWHEEL, ENGINE M915A1 ONLY	1
6	PBFZZ	3120011478118	15434	3031753	.BEARING, WASHER, THRU M915A1 ONLY	1
7	PAFZZ	5310000806004	96906	MS27183-14	WASHER, FLAT 3/8 M915A1 ONLY	12
8	PAFZZ	5310001344171	15434	200861	WASHER, FLAT	6
9	PAFZZ	5305011129698	15434	180175	SCREW, CAP, HEXAGON H 1.44 LONG M915A1 ONLY.....	6
10	PAFZZ	5305007959336	15434	204165	SCREW, CAP M915 ONLY	6
11	PAFFF	2815010851881	15434	3021660	FLYWHEEL, ENGINE M915 ONLY.....	1
12	PAFZZ	3020005285053	15434	4797	.GEAR, SPUR M915 ONLY.....	1
13	PAFZZ	5305000914009	15434	106289	SCREW, CAP, HEXAGON H FLYWHEEL HS'G TO CRANKCASE M915 ONLY.....	2
14	PAFZZ	5310000818500	15434	127316	WASHER, RECESSED 0.630-0.650 X. 1.185-1.195	9
15	PAFZZ	5305011458380	15434	S-189-B	SCREW, CAP, HEXAGON H.....	9
16	PAFZZ	5305011146386	15434	3012483	SCREW, CAP, HEXAGON H 1/2-13 X 2.00 FLYWHEEL HS'G TO BLOCK M915 ONLY	4
17	PAFZZ	5310001344168	15434	S601	WASHER, FLAT FLYWHEEL HS'G TO BLOCK M915 ONLY	1
18	PBFZZ	4730011060202	15434	3008469	PLUG, PIPE 3/4 NPT FLYWHEEL HS'G MOUNTED M915 ONLY	1
19	PAFZZ	2815011605820	15434	3016637	HOUSING, FLYWHEEL M915 ONLY.....	1
19	PBFZZ	2815011410845	15434	3036005	HOUSING, FLYWHEEL M915A1 ONLY	1
20	PAFZZ	5310005845272	96906	MS35338-48	WASHER, LOCK 3/8 FLYWHEEL HS'G TO BLOCK M915 ONLY	2
21	PAFZZ	5310004693998	15434	S200	NUT, PLAIN, HEXAGON FLYWHEEL HS'G TO BLOCK M915 ONLY	2
22	PAFZZ	5315000141284	24617	141284	PIN, STRAIGHT, HEADLE FLYWHEEL HS'G MOUNTING	2
23	PAFZZ	4730000189566	15434	S911B	PLUG, PIPE FLYWHEEL HS'G MOUNTED, 1/4-NPT, M915 ONLY	1
24	PAFZZ	5305011474025	15434	3001646	SCREW, TAPPING FLYWHEEL INDEX HOLE COVER 1/4-20 X 5/8.....	2
25	PAFZZ	5330010826985	15434	3021735	GASKET FLYWHEEL INDEX HOLE COVER, M915 ONLY.....	2
26	PBFZZ	5340011228002	15434	70657	COVER, ACCESS FLYWHEEL INDEX HOLE.....	1
27	PCFZZ	5330004042920	15434	172648	PACKING, PREFORMED M915 ONLY.....	11

END OF FIGURE




Figure 6. Piston and Connecting Rod Assembly.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0104 PISTONS, CONNECTING RODS						
FIG. 6 PISTON AND CONNECTING ROD ASSEMBLY						
1	PFHZZ	2815009944427	15434	3012331	RING, TOP PART OF KIT P/N 3801056	6
2	PFHZZ	2815012416580	15434	301233200	RING, PISTON PART OF KIT P/N 3801056.....	6
3	PFHZZ	2815012416581	15434	214730	RING, PISTON PART OF KIT P/N 3801056.....	6
4	PFHZZ	2815009944429	15434	218732	RING, PISTON, PART OF KIT P/N.....	6
					3801056	
5	PAHZZ	2815010771482	15434	3051555	PISTON, INTERNAL COM M915 ONLY	6
5	PAHZZ	2815012103426	15434	3028685	PISTON, INTERNAL COM M915A1 ONLY	6
					PART OF KIT P/N 3801058	
6	PAHZZ	5325012414318	15434	175755	RING, RETAINING PISTON PIN (OLD).....	12
					M915 ONLY	
6	PBHZZ	5325008042784	96906	MS16625-1200	RING, RETAINING PISTON PIN PART OF.....	12
					KIT P/N 3801058	
7	PFHZZ	2815004804347	15434	191970	PIN, PISTON PART OF KIT P/N 3801058	6
8	PAHHZ	2815010864508	15434	3013930	CONNECTING ROD, PIST ASSEMBLY	6
9	PAHZZ	5365001320273	15434	187420	.BUSHING, PISTON PIN	1
10	PBHZZ	2815011240232	15434	70550	.PIN, PISTON CONNECTING ROD 5/16 X	2
					1/2	
11	PAHZZ	5306010797027	15434	219153	.BOLT, MACHINE	2
12	PAHZZ	3120011554442	15434	214951	BEARING, SLEEVE 0.010 UNDERSIZE	12
12	PAHZZ	3120011573316	15434	214952	BEARING, SLEEVE 0.020 UNDERSIZE	12
12	PAHZZ	3120010873004	15434	214950	BEARING STANDARD	12
12	PAHZZ	3120011558707	01212	3725CP-30	BEARING, SLEEVE .030 UNDERSIZE	12

END OF FIGURE




Figure 7. Camshaft Assembly and Followers.

SECTION II

TM 9-2815-225-34&P


(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 0105 VALVES, CAMSHAFTS AND TIMING SYSTEM	
					FIG. 7 CAMSHAFT ASSEMBLY AND FOLLOWERS	
1	PAHZZ	5340004042944	15434	68193	PLUG, VENT CAMSHAFT ORIFICE, SPECIAL.....	1
2	PAHZZ	3020004249995	15434	215966	GEAR, CAMSHAFT M915 ONLY.....	1
2	PAHZZ	3020011458568	15434	3002901	GEAR, HELICAL M915A1 ONLY.....	1
3	PAHZZ	3120010798194	15434	215233	BEARING, WASHER, THRU M915 ONLY.....	1
3	XDHZZ		15434	3021602	BEARING, WASHER, THRU M915A1 ONLY.....	1
4	PAHZZ	5315010866187	15434	3012328	KEY, WOODRUFF GEAR TO CAMSHAFT, M915.....	1
					ONLY.....	
4	PAHZZ	5315011456080	15434	3021596	KEY, WOODRUFF GEAR TO CAMSHAFT,.....	1
					M915A1 ONLY.....	
5	PAHZZ	2815010793380	15434	3801047	CAMSHAFT, ENGINE M915 ONLY.....	1
5	PAHZZ	2815011461049	15434	3049024	CAMSHAFT, ENGINE M915A1 ONLY.....	1
6	PAHZZ	2815010855190	15434	217929	PUSH ROD, ENGINE POP INTAKE AND.....	12
					EXHAUST, CAM FOLLOWER ASSY, M915	
					ONLY.....	
6	PAFZZ	2815011461041	15434	3012462	PUSH ROD, ENGINE POP INTAKE AND.....	12
					EXHAUST, CAM FOLLOWER ASSY, M915A1	
					ONLY.....	
7	PAFZZ	2815010852615	15434	3032681	PUSH ROD, ENGINE POP.....	6
8	PCHZZ	5330011453983	15434	3074401	GASKET CAM FOLLOWER HOUSING,.....	3
					STANDARD, M915A1 ONLY PART OF KIT P/N	
					3801235.....	
8	PCHZZ	5330011453984	15434	3074404	GASKET CAM FOLLOWER HOUSING, 0.027-.....	V
					0.033, PART OF KIT P/N 3801235.....	
8	PFHZZ	5330011469928	15434	3074403	GASKET CAM FOLLOWER HOUSING, 0.020-.....	V
					0.024 PART OF KIT P/N 3801235.....	
8	PFHZZ	5330011467172	15434	3074400	GASKET CAM FOLLOWER HOUSING, PRINT-.....	V
					O-SEAL, 0.014-0.020, PART OF KIT P/N	
					3801235.....	
8	PCHZZ	5330011469775	15434	3074402	GASKET CAM FOLLOWER HOUSING, 0.014-.....	V
					0.020 PART OF KIT P/N 3801235.....	
8	PAHZZ	5330010665349	15434	3011878	GASKET CAM FOLLOWER HOUSING,.....	3
					STANDARD, M915 ONLY PART OF KIT P/N	
					3018762.....	
9	PAHZZ	5310002617340	15434	S604	WASHER, LOCK 3/8.....	18
10	PAHZZ	5305005466698	15434	S-129	SCREW, CAP, HEXAGON H.....	18
11	PFHZZ	2815011663415	15434	3066796	HOUSING ASSEMBLY, CA.....	3
12	PAHZZ	5340004850945	15434	175831	.PLUG, EXPANSION 3/4 INCH.....	2
13	PAHZZ	3040011460075	15434	3017031	.SHAFT, SHOULDERED CAM FOLLOWER.....	2
					ASSEMBLY.....	
14	PBHZZ	2815011467039	15434	3016887	.COVER, ENGINE POPPET CAM FOLLOWER.....	1
15	PAHZZ	5305003391415	15434	69736	.SCREW, MACHINE SHAFT LOCKING, 5/16-.....	2
					18 UNC-2A CAM FOLLOWER.....	
16	PAHZZ	2815011467914	15434	3036935	.ROCKER ARM, ENGINE P CAM FOLLOWER.....	4
					ASSY, INTAKE & EXHAUST.....	
17	PFHZZ	3120006597808	15434	118378	..BEARING, SLEEVE CAM FOLLOWER ASSY,.....	4
					INTAKE & EXHAUST.....	
18	PAHZZ	2815010486702	15434	213559	..SOCKET, CAM FOLLOWER INTAKE &.....	4

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
19	XBHZZ		15434	3002069	EXHAUST	
					..PIN, STRAIGHT, HEADED CAM FOLLOWER	4
					ASSY, INTAKE & EXHAUST, M915 ONLY	
19	PAHZZ	5315012100616	15434	3013331	..PIN, STRAIGHT, HEADED CAM FOLLOWER	4
					ASSY, INTAKE & EXHAUST, M915A1 ONLY	
20	PAHZZ	5315007773544	15434	118939	..PIN, STRAIGHT, HEADLE CAM FOLLOWER.....	4
					ASSY, INTAKE & EXHAUST	
21	PAHZZ	3120012124472	15434	3036933	..ROLLER, LINEAR-ROTAR CAM FOLLOWER	4
					ASSY, INTAKE & EXHAUST	
22	PAHZZ	2910010869757	15434	3056569	..ROCKER ARM, ENGINE P CAM FOLLOWER.....	2
					ASSY, INJECTOR.....	
23	PFHZZ	3120007911440	15434	118377	..BEARING, SLEEVE CAM FOLLOWER ASSY,	2
					INJECTOR.....	
24	PAHZZ	2815005055119	15434	107738	..SOCKET, CAM FOLLOWER INJECTOR	2
25	XBHZZ		15434	219107	..PIN, STRAIGHT, HEADED CAM FOLLOWER	2
					ASSY, INJECTOR.....	
26	PAHZZ	5315007773544	15434	118939	..PIN, STRAIGHT, HEADLE CAM FOLLOWER.....	2
					ASSY, INJECTOR.....	
27	PFHZZ	3120010795451	15434	3036934	..ROLLER, LINEAR-ROTAR CAM FOLLOWER	2
					ASSY, INJECTOR.....	

END OF FIGURE



- * a PART OF ITEM 2
- * b PART OF ITEM 6
- * c PART OF ITEM 12
- * d PART OF ITEM 16
- * e PART OF ITEM 20

Figure 8. Rocker Arm Assembly.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 0105 VALVES, CAMSHAFTS AND TIMING SYSTEM	
					FIG. 8 ROCKER ARM ASSEMBLY	
1	PAFFF	2815010852569	15434	3035961	HOUSING AND ROCKER ROCKER ARM.....	3
2	PAFZZ	2815010969198	15434	BM95161	ASSEMBLY	
3	PAFZZ	5310007320560	96906	MS51968-14	..ROCKER ARM, ENGINE P EXHAUST	1
					..NUT, PLAIN, HEXAGON ROCKER ARM.....	1
					ADJUSTING SCREW, EXHAUST 1/2-20 UNF- 2B R/H	
4	PAFZZ	5305009473437	15434	168306	..SETSCREW ROCKER ARM, EXH, HEADLESS	1
					W/SLOT 1/2-20X2.045 UNF-3A R/H	
5	PAFZZ	3120005893537	15434	140330	..BUSHING, SLEEVE ROCKER ARM EXHAUST.....	1
6	PAFZZ	2815000057431	15434	AR-2308	..LEVER, INJECTOR, FUEL.....	2
7	PAFZZ	5310007320560	96906	MS51968-14	..NUT, PLAIN, HEXAGON ROCKER ARM.....	1
					ADJUSTING SCREW, INJECTOR 1/2-20 UNF- 2B R/H.....	
8	PAFZZ	5305009473437	15434	168306	..SETSCREW ROCKER ARM, INJ, HEADLESS	1
					W/SLOT 1/2-20X2.045 UNF-3A R/H	
9	PAFZZ	3120010795208	15434	218153	..BUSHING, SLEEVE ROCKER ARM.....	1
					INJECTOR.....	
10	PAFZZ	5340004042940	15434	194037	..SEAT, BALL SOCKET ROCKER ARM.....	1
					INJECTOR.....	
11	PAFZZ	5340002082083	75272	PC0625	..PLUG, EXPANSION SPECIAL	
12	PAFZZ	2815001955894	15434	BM95159	..ROCKER ARM, ENGINE P INTAKE	1
13	PAFZZ	5310007320560	96906	MS51968-14	..NUT, PLAIN, HEXAGON ROCKER ARM.....	1
					ADJUSTING SCREW, INTAKE 1/2-20 UNF- 2B R/H.....	
14	PAFZZ	5305009473437	15434	168306	..SETSCREW ROCKER ARM, INT, HEADLESS.....	1
					W/SLOT 1/2-20X2.045 UNF-3A R/H	
15	PAFZZ	3120005893537	15434	140330	..BUSHING, SLEEVE ROCKER ARM INTAKE.....	1
16	PAFZZ	2815001955897	15434	BM95160	..ROCKER ARM, ENGINE P INTAKE	1
17	PAFZZ	5310007320560	96906	MS51968-14	..NUT, PLAIN, HEXAGON ROCKER ARM.....	1
					ADJUSTING SCREW, INTAKE 1/2-20 UNF- 2B R/H	
18	PAFZZ	5305009473437	15434	168306	..SETSCREW ROCKER ARM, INT, HEADLESS.....	1
					W/SLOT 1/2-20X2.045 UNF-3A R/H	
19	PAFZZ	3120005893537	15434	140330	..BUSHING, SLEEVE ROCKER ARM INTAKE.....	1
20	PAFZZ	2815008517637	15434	BM96162	..ROCKER ARM, ENGINE P EXHAUST	1
21	PAFZZ	5310007320560	96906	MS51968-14	..NUT, PLAIN, HEXAGON ROCKER ARM.....	1
					ADJUSTING SCREW, EXHAUST 1/2-20 UNF- 2B R/H	
22	PAFZZ	5305009473437	15434	168306	..SETSCREW ROCKER ARM, EXH, HEADLESS	1
					W/SLOT 1/2-20X2.045 UNF-3A R/H	
23	PAFZZ	3120005893537	15434	140330	..BUSHING, SLEEVE ROCKER ARM EXHAUST.....	1
24	PAFZZ	5305002974022	15434	168319	..SETSCREW ROCKER ARM SHAFT	1
25	PAFZZ	5330011456083	75078	010180	..PACKING, PREFORMED.....	1
26	PAFZZ	5340011637118	15434	216296	..PLUG, VENT ROCKER ARM HOUSING	1
27	PAFZZ	4730011240293	15434	218736	..PLUG, QUICK DISCONN ROCKER ARM.....	2
					SHAFT	
28	PCFZZ	5331009843756	19207	7374401	..O-RING ROCKER ARM SHAFT	2
29	PAFZZ	3040010791799	15434	3801433	..SHAFT, STRAIGHT ROCKER ARM HOUSING.....	1

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
30	PBFZZ	2815012106947	15434	3036285	.HOUSING, ROCKER ARM.....	1
31	PAFZZ	5305011296901	15434	3010589	SCREW, ASSEMBLED WAS ROCKER ARM	18
					HOUSING ASSY 1/2-13 X 4.750 UNC-2A.....	
32	PFFZZ	5330008618592	15434	3017750	GASKET ROCKER ARM HOUSING ASSEMBLY.....	3
					PART OF KIT P/N 3804280 PART OF KIT.....	
					P/N 3804275.....	

END OF FIGURE




Figure 9. Rocker Cover.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 0105 VALVES, CAMSHAFTS AND TIMING SYSTEM	
					FIG. 9 ROCKER COVER	
1	PAOZZ	2590005907378	15434	101322	CAP, FILLER OPENING	1
2	PAOZZ	5305011188826	15434	3006182	SCREW, CAP, HEXAGON H CAPTIVE WASHER, 3/8-16UNC-2A X 0.845-0.875.....	15
3	PBOZZ	2815011646103	15434	3006349	COVER, ENGINE POPPET ROCKER AND.....	1
					RETARDER, M915 ONLY	
3	PAOZZ	2815011591737	15434	3006187	COVER, ENGINE POPPET M915A1 ONLY	1
4	PAOZZ	2815011421732	15434	3006183	COVER, ENGINE POPPET	1
5	PAOZZ	2815011461024	15434	3006358	COVER, ENGINE POPPET	1
6	PCOZZ	5330011453985	15434	3044514	GASKET ROCKER COVER, M915A1 ONLY	3
7	PBOZZ	5365012413903	15434	64709	SPACER, SLEEVE	15

END OF FIGURE

1 — 2
thru
29




Figure 10. Oil Cooler and Filter, M915A1 Only.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0106 ENGINE LUBRICATION SYSTEM						
FIG. 10 OIL COOLER AND FILTER, M915A1 ONLY						
1	PAFHH	2930011410918	15434	3032307	COOLER, LUBRICATING OIL	1
2	PAHZZ	5305000914006	15434	137795	.SCREW, CAP, HEXAGON H 3/8-16 X 5/8	2
3	PAHZZ	5310006379541	96906	MS35338-46	.WASHER, LOCK 3/8	12
4	PAHZZ	2930011459537	15434	3023512	.VALVE, BYPASS	1
5	PCHZZ	5331011456085	15434	3045979	.O-RING PART OF KIT P/N 3801235	1
6	PFHZZ	4730000428988	6N299	0907859	.PLUG, PIPE 1/4	1
7	PAHZZ	4730000575555	15434	S-908	.PLUG, PIPE 3/8	2
8	PBHZZ	2930011459538	15434	3027460	.SUPPORT, OIL COOLER	1
9	PFHZZ	5330011456911	15434	3018696	.GASKET OIL COOLER CORE PART OF KIT	1
					P/N 3801235.....	
10	PCHZZ	5330011456910	15434	3018693	.GASKET PART OF KIT P/N 3801235	1
11	XDHZZ		15434	3018690	.HOUSING, OIL COOLER	1
12	PAOZZ	2940011459398	15434	3034578	.ADAPTER, FILTER HEAD	1
13	PAHZZ	2940011459399	15434	3030804	.PISTON, BYPASS VALVE PRESSURE,	1
					SENSING	
14	PAHZZ	2940011459400	15434	3030806	.PLUNGER, BYPASS VALV	1
15	PAHZZ	5360011453974	15434	3030803	.SPRING, HELICAL, COMP COMPRESSION.....	1
16	PAHZZ	4820012103573	15434	3030805	.PISTON, BYPASS VALVE	1
17	PAHZZ	5360011453975	15434	3039296	.SPRING, HELICAL, COMP	1
18	PAOZZ	5331011456086	15434	3030808	.O-RING PART OF KIT P/N 3801235	1
19	PAOZZ	5305011446232	15434	3031005	.SCREW, CAP, HEXAGON H	1
20	XDOZZ		15434	101996	.CAPSCREW 18-32 X 3/8	1
21	PAOZZ	5930011770346	15434	3035028	.SWITCH, PRESSURE	1
22	PCHZZ	5330011456909	15434	3027496	.GASKET PART OF KIT P/N 3801235	1
23	PFHZZ	5331011454316	15434	3018695	.O-RING PART OF KIT P/N 3801235	1
24	PAOZZ	4330011461082	15434	3021656	.ADAPTER, FILTER HEAD	1
25	PAHZZ	2940011465846	15434	3018700	.HEAD, FLUID FILTER	1
26	PAHZZ	5305007252317	80204	B1821BH038C150N	.SCREW, CAP, HEXAGON H 3/8-16 X 1.50.	4
27	PAHZZ	5310000806004	96906	MS27183-14	.WASHER, FLAT 13/32	12
28	PAHZZ	2930011461081	15434	3018692	.CORE, OIL COOLER	1
29	PAHZZ	5305007829489	80204	B1821BH038C200N	.SCREW, CAP, HEXAGON H 3/8-16 X 2.00.	6
30	PFFZZ	5330011456912	15434	3031858	GASKET PART OF KIT P/N 3801235	1
31	PAFZZ	5305000680511	80204	B1821BH038C125N	SCREW, CAP, HEXAGON H 3/8-16 X 1.25	3
32	PAFZZ	5305004041388	15434	S-199-B	SCREW, CAP, HEXAGON H 3/8-16 X 3.75	3
33	PAOZZ	2940010194513	15434	299670	FILTER ELEMENT, FLUI SPIN ON	1
34	PAOZZ	2940011459455	01637	FL797-A	FILTER ELEMENT, FLUI SPIN ON	1
35	PAOZZ	4820002769041	15434	107947	COCK, DRAIN	1
36	PAFZZ	5310001596209	96906	MS122032	WASHER, LOCK 1/4	2
37	PAFZZ	5305006388920	80204	B1821BH038C225N	SCREW, CAP, HEXAGON H 3/8-16 X 2.25	2
38	PAFZZ	5305000712517	80204	B1821BH025C350N	SCREW, CAP, HEXAGON H 1/4-20 X 1.00	2
39	PAFZZ	5310006379541	96906	MS35338-46	WASHER, LOCK 3/8	8
40	PAFZZ	5310005626560	15434	S-631	WASHER, FLAT 9/32	2
41	PBFZZ	5340011450772	15434	3018697	BRACKET, ANGLE	1
42	PFOZZ	4730003652690	15434	S-1002-A	ADAPTER, STRAIGHT, TU	2
43	PAOZZ	5330012222306	15434	3034579	SEAL	2
44	PAOZZ	4710011587507	15434	3035595	TUBE ASSEMBLY, METAL	1
45	PAOZZ	5310011036042	24617	120392	WASHER, FLAT 3/8	2

END OF FIGURE




Figure 11. Oil Cooler and Filter, M915 Only.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0106 ENGINE LUBRICATION SYSTEM						
FIG. 11 OIL COOLER AND FILTER, M915 ONLY						
1	PAFZZ	5305011355344	15434	3011342	SCREW.....	6
2	PFFZZ	4730012417258	15434	3011233	ELBOW, FLANGE TO HOS	1
3	PAFZZ	5330005372382	15434	70089-1	GASKET PART OF KIT P/N 3018762	2
4	PAFZZ	4730011637192	15434	3008690	CLAMP, HOSE	4
5	PCFZZ	4720010852571	15434	3031560	HOSE, NONMETALLIC.....	2
6	PFFZZ	4710011811956	15434	3000907	TUBE, WATER TRANSFER	1
7	PBFZZ	5305012036444	15434	S145	SCREW, CAP, HEXAGON H 1/2-13 X 1.25	1
8	PAFZZ	5310005845272	96906	MS35338-48	WASHER, LOCK 1/2.....	1
9	PBFZZ	5305010858197	15434	3010595	SCREW, MACHINE W/LOCKWASHER 3/8-16	2
					X 1.00.....	
10	PAFZZ	5340012420805	15434	210966	BRACKET, ANGLE	1
11	PAFHH	2520010904473	15434	3003814	COOLER ASSEMBLY, OIL	1
12	PAFZZ	4820002769041	15434	107947	.COCK, DRAIN	1
13	PAHZZ	2930012311661	15434	217315	.COVER, COOLER	1
14	PFFZZ	5365007083434	15434	110907	.PLUG, MACHINE THREAD 1-18 X1-1/16.....	1
					UNS R/H EXTERNAL	
15	PAFZZ	5305010886019	15434	3010596	.SCREW, ASSEMBLED WAS 3/8-16 X 3.75.....	10
16	PAFZZ	5330010463144	15434	3010030	.GASKET PART OF KIT P/N 3018762.....	1
17	PAFZZ	5310002617340	96906	MS35338-8	.WASHER, LOCK 3/8	1
18	PAFZZ	5305001775552	15434	S126	.SCREW, CAP, HEXAGON H	1
19	PFHZZ	5340013423610	15434	210967	.COVER, ACCESS.....	1
20	XBHZZ		15434	142110	.PLUG, EXPANSION	1
21	PBHZZ	4730011603579	15434	S-910-B	.PLUG, PIPE 1/4, EXTERNAL R/H NPT,	1
					RECESSED HEX HEAD	
22	PAHZZ	2815007911453	15434	127558	.PLUNGER, OIL PUMP RE	1
23	PAHZZ	5360006645343	15434	68274	.SPRING, HELICAL, COMP	1
24	PCHZZ	5365001979327	15434	67946	.SPACER, RING PART OF KIT P/N 3018762	1
25	PBFZZ	4730013093321	15434	3060882	.PLUG, TUBE FITTING, T	1
26	PAFZZ	5330010461991	15434	218245	.GASKET PART OF KIT P/N 3018762	1
27	PBFHZ	2930011654581	15434	AR-09999	.COOLER, LUBRICATING	1
28	PAFZZ	5325011396738	15434	3006745	..RING, RETAINING.	2
29	PCHZZ	5330010866197	15434	3007713	..PACKING, PREFORMED PART OF KIT P/N	2
					3018762	
30	PAFZZ	2930010657113	15434	3021581	..FILTER ELEMENT, FLUI.....	1
31	PFHZZ	2815012414719	15434	210915	..HOUSING, OIL COOLER.....	1
32	PFHZZ	5360012000323	15434	202128	..SPRING, HELICAL, COMP	1
33	XAHZZ		15434	210707	..DISC, BY-PASS	1
34	PAHZZ	2940011461995	15434	179063	..SEAT, BYPASS FILTER	1
35	PAHZZ	4730000189566	15434	S911B	..PLUG, PIPE.....	1
36	PCFZZ	5331010775228	15434	212161	O-RING	2
37	PAFZZ	4710011463086	15434	3024666	TUBE, BENT, METALLIC	1
38	PAFZZ	5305010886019	15434	3010596	SCREW, ASSEMBLED WAS 3/8-16 X 1.25.....	2
39	PAFZZ	5330010796514	15434	3008017	GASKET PART OF KIT P/N 3018762.....	1
40	PFFZZ	5310002617340	96906	MS35338-8	WASHER, LOCK 3/8	2
41	PAFZZ	5305001658157	72582	450517	SCREW, CAP, HEXAGON H 3/8-16 X 4.75.....	2
42	PAFZZ	5305010867036	15434	3010597	SCREW WITH LOCKWASHER, 3/8-16 X	2
					3.75	
43	PAOZZ	2940010194513	15434	299670	FILTER ELEMENT, FLUI SPIN ON	1

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
44	XBHZZ		15434	S152B	SCREW, CAP, HEX HEAD	1
45	PFHZZ	5310008206653	96906	MS35338-50	WASHER, LOCK 5/8	1
46	PFHZZ	5310001344171	15434	200861	WASHER, FLAT 5/8	1
47	PAOZZ	2940010657076	33457	3300922S	HEAD, FLUID FILTER.....	1
48	PAOZZ	5330011640944	33457	3308958	GASKET PART OF KIT P/N 3018762	1
49	PAFZZ	5330001320248	15434	173368	PACKING, PREFORMED PART OF KIT P/N.....	1
					3018762	
50	XDFZZ		79470	49X6X2	ELBOW, PIPE TO TUBE.....	1

END OF FIGURE

2 — 3
thru
12




Figure 12. Oil Pan, Dipstick, and Breather Tube.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0106 ENGINE LUBRICATION SYSTEM						
FIG. 12 OIL PAN, DIPSTICK, AND BREATHER TUBE						
1	PFFZZ	5330011470748	15434	3032861	GASKET PART OF KIT P/N 3801235	1
2	PAFZZ	2815011332445	15434	193625	OIL PAN M915 ONLY	1
2	PBFFF	2815011410919	15434	3031959	OIL PAN M915A1 ONLY	1
3	PBFZZ	5310008284827	15434	69832	.NUT, GOVERNOR STUD 5/16-18	3
4	PAFZZ	5310005626558	15434	S-626	.WASHER, FLAT 0.344 X 0.688	3
5	PAFZZ	5340011469992	15434	3032708	.CLAMP, LOOP	3
6	PBFZZ	4710011461052	15434	3032707	.TUBE, BENT, METALLIC	1
7	XAFZZ		15434	3030257	.PAN, ENGINE OIL	1
8	PAOZZ	4730000103867	77640	103879	.PLUG, PIPE M915 ONLY	2
8	PAOZZ	4730011472223	15434	3008468	.PLUG, PIPE M915A1 ONLY	2
9	PAFZZ	5342011436045	15434	3008470	.PLUG 1-11 1/2	1
10	PAFZZ	4730000444715	15434	S962	.PLUG, PIPE 1 INCH NPTF	1
11	PAOZZ	5365001979327	15434	67946	.SPACER, RING	1
12	PAOZZ	5365006951247	15434	69962	.PLUG, MACHINE THREAD	1
13	PAOZZ	4730011463111	15434	3008596	CLAMP, HOSE	2
14	PCOZZ	4720002784890	28835	2CA647	HOSE, NONMETALLIC	1
15	PBOZZ	4710012158158	15434	3008599	TUBE ASSEMBLY, METAL M915 ONLY	1
15	PFOZZ	4710011460049	15434	3038035	TUBE, BENT, METALLIC M915A1 ONLY	1
16	PAOZZ	5310004516643	15434	S-213-A	NUT 5/8-18	1
17	PAFZZ	5310002617340	15434	S604	WASHER, LOCK M915 ONLY	4
17	PAOZZ	5310008206653	15434	S-603	WASHER, LOCK M915A1 ONLY	4
18	PAOZZ	5310008238803	96906	MS27183-21	WASHER, FLAT	4
19	PAOZZ	5340008390653	15434	68425	CLAMP, LOOP	1
20	PFOZZ	5342011459540	15434	217934	BRACKET, AFTERCOOLER	1
21	PAOZZ	5305009448292	96906	MS35308-458	SCREW, CAP, HEXAGON H	1
22	PAOZZ	5310002617340	15434	S-604	WASHER, LOCK	1
23	PAOZZ	5305005466698	15434	S-129	SCREW, CAP, HEXAGON H 3/8-24 X 1.00	1
24	PAOZZ	6680011087410	15434	3017292	GAGE ROD, LIQUID LEV	1
25	PAFZZ	4710011421667	15434	3022377	BREATHER TUBE, OIL	1
26	PAOZZ	5310011269404	24617	9422277	NUT, SELF-LOCKING, HE 3/8-16	1
27	PAOZZ	5340004175800	15434	200064	CLAMP, LOOP	1
28	PAFZZ	5310000806004	96906	MS27183-14	WASHER, FLAT	4
29	PAFZZ	5305005434372	80204	B1821BH038C075N	SCREW, CAP, HEXAGON H 3/8-16 X 3/4	4
29	PAFZZ	5305010858197	15434	3010595	M915 ONLY	4
30	PAFZZ	5342011407158	15434	178074	SCREW, MACHINE WITH CAPTIVE WASHER,	4
30	PBFZZ	5342011459539	15434	41044	3/8-16 X 1.00, M915A1 ONLY	1
30	PAFZZ	5342011459539	15434	41044	BRACKET M915 ONLY	1
31	PCFZZ	5330002460309	15434	65274	BRACKET, OIL GAGE M915A1 ONLY	1
32	PAHZZ	5305005434372	80204	B1821BH038C075N	GASKET PART OF KIT P/N 3801235	1
33	PFOZZ	5340011475389	15434	134561	SCREW, CAP, HEXAGON H M915 ONLY	5
34	PAOZZ	5305010322311	80204	B1821BH044C425N	BRACKET, ANGLE	1
35	PAOZZ	5310002090965	96906	MS35338-47	SCREW, CAP, HEXAGON H	1
36	PAOZZ	5310008094085	96906	MS27183-16	WASHER, LOCK	5
37	PAHZZ	5305012125210	15434	3008069	WASHER, FLAT	1
37	PAFZZ	5305011458358	15434	3017049	SCREW, CAP, HEXAGON H M915 ONLY	4
38	PFFZZ	5340011506248	15434	218813	SCREW, ASSEMBLED WAS M915A1 ONLY	4
39	PAFZZ	5305011451113	15434	3032674	PLATE, MENDING ENGINE SHIPPING	1
					SCREW HEXAGON	28

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
40	PAFZZ	5305000429478	96906	MS90725-90	SCREW, CAP, HEXAGON H 7/16-14 X 1 3/4	4
41	PAFZZ	5310004079566	96906	MS35338-45	WASHER, LOCK.	4
42	PAFZZ	5310000814219	96906	MS27183-12	WASHER, FLAT	4
43	MOOZZ		19207	8710557-10	HOSE, RUBBER, MAKE FROM HOSE, NONMETALLIC, 10 IN. MAKE FROM P/N 8710557	1
44	PAOZZ	4710010920109	34623	MB320-20011	TUBE, METALLIC BREATHER EXTENSION.....	1
45	PAOZZ	5340011539425	75272	COV-1109	CLAMP, LOOP	1
46	PAOZZ	5305011129021	15434	3013904	SCREW	1
47	PAOZZ	5310006379541	96906	MS35338-46	WASHER, LOCK 3/8	4
48	PAFZZ	5305008046454	15434	S1354	SCREW, TAPPING	2
49	PAFZZ	4730003386839	34623	MA207-21139	STRAINER ELEMENT, SE	1

END OF FIGURE




Figure 13. Oil Lubricating Pump.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0106 ENGINE LUBRICATION SYSTEM						
FIG. 13 OIL LUBRICATING PUMP						
1	PAFHH	2815010852573	15434	AR10172	OIL PUMP ASSEMBLY, E M915 ONLY	1
1	PAFHH	2815011415299	15434	3821572	PUMP ASSEMBLY, OIL M915A1 ONLY	1
2	PFHZZ	5330011471274	15434	3014778	.GASKET M915A1 ONLY PART OF KIT P/N	1
					3801235	
2	PAFZZ	5330010663910	15434	203145	.GASKET OIL COVER TO PUMP, M915 ONLY	1
					PART OF KIT P/N 3018762.....	
3	XBHZZ		15434	AR8667	.HSG, HYDR ADAPTER M915 ONLY	1
3	PAHZZ	5340011459451	15434	3014964	.COVER, ACCESS M915A1 ONLY	1
4	PAHZZ	3120006276697	15434	69521	..BEARING, SLEEVE	1
5	PAHZZ	4730011060202	15434	3008469	.PLUG, PIPE M915 ONLY	1
5	PAHZZ	4730011615115	15434	3013786	.PLUG, PIPE M915A1 ONLY	1
6	PAHZZ	5305011294214	15434	3022590	.SCREW, CAPTIVE WITH CAPTIVE WASHER,	7
					5/16 - 18 X 1.00	
7	PAHZZ	3120005660480	15434	68365	.BUSHING, SLEEVE M915 ONLY	2
7	PAHZZ	3120011495414	15434	199586	.BUSHING, SLEEVE M915A1 ONLY	2
8	PAHZZ	3020011460108	15434	3014788	.GEAR, SPUR.....	1
9	PAHZZ	5305010102362	96906	MS18154-59	.SCREW, CAP, HEXAGON H M915 ONLY	1
9	PAHZZ	5305005434372	80204	B1821BH038C075N	.SCREW, CAP, HEXAGON H M915A1 ONLY	5
10	PAHZZ	5310010750991	15434	146161	.WASHER, FLAT	1
11	PAHZZ	5342011450645	15434	3012726	.RETAINER	1
12	PCHZZ	5330010514243	15434	145504	.PACKING, PREFORMED PART OF KIT P/N	2
					3010242	
13	PAHZZ	5360010384659	15434	211939	.SPRING, HELICAL, COMP M915 ONLY	1
13	PAHZZ	5360011457554	15434	3010146	.SPRING, HELICAL, COMP M915A1 ONLY	1
14	PAHZZ	2815007052856	15434	109333	.PLUNGER, PRESSURE RE M915 ONLY	1
14	PAHZZ	5340011450802	15434	3012529	.PLUNGER, DETENT M915A1 ONLY	1
15	PAHZZ	5360011480303	15434	3014756	.SPRING, HELICAL, COMP BYPASS VALVE.....	1
16	PAHZZ	5310011446224	15434	3014754	.WASHER, FLAT	1
17	PAHZZ	4820011459457	15434	3014755	.DISK, VALVE.....	1
18	PAHZZ	2940011461995	15434	179063	.SEAT, BYPASS FILTER	1
19	PAHZZ	3020010849640	15434	3014783	.GEAR, SPUR M915 ONLY	1
19	PAHZZ	3020011460109	15434	3014787	.GEAR, SPUR M915A1 ONLY.....	1
20	PAHZZ	3040010791748	15434	199587	.SHAFT, SHOULDERED M915 ONLY	1
20	PAHZZ	3040011459637	15434	3012532	.GEARSHAFT, SPUR M915A1 ONLY.....	1
21	PAHZZ	5315004752574	15434	69519	.PIN, STRAIGHT, HEADLE	1
22	PAHZZ	5315000431787	96906	MS35756-34	.KEY, WOODRUFF M915 ONLY	1
22	XBHZZ		15434	183695	.KEY, WOODRUFF M915A1 ONLY	1
23	PAHZZ	3040010793469	15434	177419	.SHAFT, SHOULDERED M915 ONLY	1
23	XDHZZ		15434	3012531	.SHAFT, STRAIGHT M915A1 ONLY	1
24	PAHZZ	3020010853779	15434	204832	.GEAR, HELICAL	1
25	XDHZZ		15434	AR09832	.BODY, OIL PUMP WITH M915 ONLY	1
25	PAHZZ	3040011465935	15434	3014798	.HOUSING, MECHANICAL M915A1 ONLY.....	1
26	PAHZZ	3120006276697	15434	69521	..BEARING, SLEEVE M915A1 ONLY	2
27	PAFZZ	5310002090965	96906	MS35338-47	WASHER, LOCK M915 ONLY	9
27	PAFZZ	5310002617340	15434	S-604	WASHER, LOCK M915A1 ONLY.....	13
28	PAHZZ	5305000680511	96906	MS90728-62	SCREW, CAP, HEXAGON H M915 ONLY	3
28	PAFZZ	5305001373269	15434	S-108-A	SCREW M915A1 ONLY	3
29	PAFZZ	5325010849033	15434	100475	RING, RETAINING.....	1
30	PAHZZ	3010010791788	15434	199589	COUPLING, SHAFT, RIGI PUMP ASSY, OIL.....	1

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
30	PAFZZ	3010011460113	15434	3023506	LUBRICATING, M915 ONLY	1
					COUPLING, SHAFT, RIGI POWER STEERING.....	
					PUMP, M915A1 ONLY	
31	PAHZZ	5305004264142	15434	S105	SCREW, CAP, HEXAGON H.....	2
32	PAHZZ	5310006379541	96906	MS35338-46	WASHER, LOCK	2
33	PAHZZ	4720010793285	34623	MA145B21000	HOSE ASSEMBLY, NONME M915 ONLY	1
33	PAFZZ	4710011460050	15434	3031962	TUBE, BENT, METALLIC M915A1 ONLY	1
34	PFFZZ	5330011456913	15434	3029846	GASKET PART OF KIT P/N 3801235	2
					ONLY	
34	PCFZZ	5330001438376	15434	157551	GASKET PART OF KIT P/N 3801235.....	2
					M915A1 ONLY.....	
35	PAFZZ	5305000680511	80204	B1821BH038C125N	SCREW, CAP, HEXAGON H.....	2
36	PFHZZ	5310005626557	15434	S622	WASHER, FLAT M915 ONLY	4
36	PAFZZ	5310000806004	96906	MS27183 -14	WASHER, FLAT M915A1 ONLY	4
37	PAHZZ	5340010856269	15434	105182	CLAMP, LOOP PUMP ASSY, OIL	1
					LUBRICATING, M915 ONLY	
38	XBHZZ		15434	9674F	SPACER CLAMP TO HOSE TO SUPPORT	1
					OIL PAN, PUMP ASSY, OIL LUBRICATING	
39	PAHZZ	5340010662947	15434	68038	BRACKET, ANGLE PUMP ASSY, OIL.....	1
					LUBRICATING.....	
40	PAFZZ	5310005218595	15434	S223	NUT HE,AGON OUTLET PIPE TO BRACE	1
41	XDHZZ		15434	300869	SCREW.....	1
42	PAHZZ	4730002028470	01276	2021-20-20S	ADAPTER, STRAIGHT, PI PUMP ASSY, OIL.....	1
					LUBRICATING, M915 ONLY	
43	PAHZZ		15434	AR9832	BODY AND SPRING.....	1
44	PAHZZ	2815008287013	15434	126304	YOKE, CAP RETAINING PUMP ASSY, OIL	1
					LUBRICATING, M915 ONLY	
45	PAHZZ	2815004068936	15434	109319	LOCK PLATE YOKE TO HOUSING, PUMP.....	1
					ASSY, OIL LUBRICATING	
46	PAFZZ	5305007959352	15434	3012479	SCREW, CAP, HEXAGON H M915 ONLY.....	2
46	PAFZZ	5305011472443	15434	S-142-A	SCREW, CAP, HEXAGON H M915A1 ONLY.....	2
47	PCFZZ	5331011450715	15434	3029847	O-RING PART OF KIT P/N 3801235	2
48	PAFZZ	5305005434372	80204	B1821BH038C075N	SCREW, CAP, HEXAGON H M915A1 ONLY.....	2
48	PAFZZ	5305009422196	96906	MS18154-60	SCREW, CAP, HEXAGON H M915 ONLY	6
49	PFFZZ	5330011474071	15434	3031434	GASKET PUMP MOUNTING PART OF KIT	1
					P/N 3801235.....	
50	PAFZZ	4720011520156	15434	AS0401100MS	HOSE ASSEMBLY, NONME	1
51	PAFZZ	4730011428524	15434	68139	ELBOW, PIPE TO TUBE.....	1

END OF FIGURE




Figure 14. Air Aftercooler.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0108 MANIFOLDS						
FIG. 14 AIR AFTERCOOLER						
1	PAOZZ	4730005558263	53496	5561 1-2A	CLAMP, HOSE 13/16-1 1/2.....	8
2	PFFZZ	4730011461065	15434	3013295	ELBOW, FLANGE TO HOS WATER OUTLET, M915A1 ONLY.....	1
3	PCFZZ	5330010665351	15434	215044	GASKET WATER OUTLET CONNECTION PART OF KIT P/N 3804275.....	1
4	PBFZZ	2930011461083	15434	3046170	COVER, INTERCOOLER.....	1
5	PAFZZ	5305011472444	15434	3005508	SCREW, CAP, HEXAGON H WITH CAPTIVE WASHER.....	24
6	PAFZZ	5330010665352	15434	216486	GASKET AFTERCOOLER COVER.....	1
7	PFOZZ	5330010663904	15434	195952	PACKING, PREFORMED PART OF KIT P/N..... 3804275.....	4
8	PFOZZ	5330011474072	15434	3032348	GASKET WATER INLET CONNECTION PART..... OF KIT P/N 3804275.....	1
9	XBOZZ		15434	211222	CONNECTOR, WATER M915 ONLY.....	1
9	PAOZZ	2930011461996	15434	3028282	CONNECTOR, WATER INL WATER INLET, M915A1 ONLY.....	1
10	PAOZZ	5305000680511	96906	B1821BH038C125N	SCREW, CAP, HEXAGON H M915 ONLY.....	2
10	PAOZZ	5305010728818	15434	3012471	SCREW WITH CAPTIVE WASHER, 3/8-16..... X 1 1/8, M915A1 ONLY.....	2
11	PCOZZ	4720010856131	15434	155789	HOSE, NONMETALLIC.....	4
12	PAOZZ	5305005434372	80204	B1821BH038C075N	SCREW, CAP, HEXAGON H HEXAGON CAP, 3/..... 8 - 16 X 1.00, M915A1 ONLY.....	2
13	PAOZZ	5310001596209	96906	MS122032	WASHER, LOCK M915 ONLY.....	6
13	PAOZZ	5310002617340	15434	S-604	WASHER, LOCK M915A1 ONLY.....	6
14	PAOZZ	4710011464083	15434	217933	TUBE, BENT, METALLIC WATER CROSSOVER.....	1
15	PAFZZ	5305011471215	15434	3019572	SCREW, CAP, HEXAGON H WITH CAPTIVE WASHER, M915A1 ONLY.....	3
16	PAOZZ	4730011463109	15434	217932	ELBOW, FLANGE TO TUB WATER OUTLET, M915A1 ONLY.....	1
17	PCOZZ	5330010826984	15434	215045	GASKET WATER OUTLET.....	1
18	PFOZZ	4730011461064	15434	215587	ADAPTER, STRAIGHT, FL WATER OUTLET.....	1
19	PAOZZ	5340000877486	15434	107460	CLAMP, LOOP.....	2
20	PAOZZ	5305009448292	15434	S-190	SCREW, CAP, HEXAGON H.....	1
21	PAOZZ	5310008206653	15434	S-603	WASHER, LOCK.....	1
22	PAOZZ	5342011459540	15434	217934	BRACKET, AFTERCOOLER.....	1
23	PAOZZ	5310005218595	15434	S-223	NUT HE, AGON 3/8 - 16.....	2
24	PAOZZ	5305005434372	80204	B1821BH038C075N	SCREW, CAP, HEXAGON H M915 ONLY.....	1
24	PAOZZ	5305011376706	15434	3012473	SCREW 3/8 - 16 X 1 3/4, M915A1 ONLY.....	2
25	PAOZZ	5310004862505	15434	108330	WASHER, FLAT M915A1 ONLY.....	1
25	PAOZZ	5310002617340	15434	S-604	WASHER, LOCK M915 ONLY.....	1
26	PAOZZ	5310000806004	96906	MS27183-14	WASHER, FLAT.....	1
27	PAFZZ	5310011458403	15434	3011610	WASHER, FLAT.....	8
28	PAFZZ	5305011472445	15434	3030286	SCREW, CAP, HEXAGON H 5/8-18 X 1.50.....	8
29	PAFZZ	5305011467285	15434	69047-A	SCREW, CAP, SOCKET HE SOCKET HEAD..... CAP, 3/8-16 X 1.50.....	1
30	PAFZZ	5305004041390	15434	S149A	SCREW, CAP, HEXAGON H M915 ONLY.....	6
30	PAFZZ	5305011478729	15434	3028967	SCREW, CAP, HEXAGON H WITH CAPTIVE..... WASHER, 3/8-16 X 1.125, M915A1 ONLY.....	6
31	PAOZZ	5340011450773	15434	3035607	BRACKET, ANGLE TUBE SUPPORT, M915A1.....	1

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					ONLY	
32	PBFZZ	2930011460111	15434	3008425	MANIFOLD, FLUID COOL M915A1 ONLY.....	1
33	PCFZZ	5330010863523	15434	3008591	GASKET INTAKE MANIFOLD PART OF KIT	3
					P/N 3804280 PART OF KIT P/N 3804275.....	
34	XBFZZ		15434	214836	CORE, AFTERCOOLER M915 ONLY.....	1
34	PAFZZ	2930011419277	15434	3028997	CORE, AFTERCOOLER AFTERCOOLER,.....	1
					M915A1 ONLY.....	
35	PAOZZ	4710010856132	15434	215041	TUBE, BENT, METALLIC M915 ONLY	1
35	PAOZZ	4710011461053	15434	3018099	TUBE, BENT, METALLIC WATER TRANSFER,	1
					M915A1 ONLY.....	
36	PAFZZ	5330000031771	15434	S684	GASKET M915 ONLY	3
36	PAFZZ	5310004079566	96906	MS35338-45	WASHER, LOCK	3
37	PAFZZ	5306002258499	96906	MS90725-34	BOLT, MACHINE 5/16 - 18 X 1.00.....	3
38	PAFZZ	5310001344169	15434	63842	WASHER, FLAT	3
39	PAHZZ	5305007252317	80204	B1821BH038C150N	SCREW, CAP, HEXAGON H.....	3
40	PAFZZ	4730000189566	15434	S911B	PLUG, PIPE.....	1

END OF FIGURE






Figure 15. Exhaust Manifold.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0108 MANIFOLDS						
FIG. 15 EXHAUST MANIFOLD						
1	PAFZZ	2815011461103	15434	3031186	MANIFOLD, EXHAUST REAR, M915A1 ONLY.....	1
2	PAFZZ	2815010774463	15434	200566	MANIFOLD, CENTER SEC REAR, EXHAUST.....	1
2	PAFZZ	2815011463159	15434	3029614	MANIFOLDS ASSEMBLY, M915 ONLY.....	1
3	PAFZZ	2815009202073	15434	151478	MANIFOLD, EXHAUST EXHAUST MANIFOLDS,	1
3	PAFZZ	2815011460112	15434	3031187	M915 ONLY.....	1
4	PAFZZ	5330006593178	15434	3020943	MANIFOLD, EXHAUST FRONT, M915A1 ONLY.	1
5	PAFZZ	5305010288869	15434	S155	GASKET MANIFOLD PART OF KIT P/N.....	6
5	PAFZZ	5305011478730	15434	3043647	3804280 PART OF KIT P/N 3804275	8
6	PAFZZ	2815008295227	15434	105199	SCREW, CAP, HEXAGON H M915 ONLY	12
7	PAFZZ	5305004770395	15434	110266	SCREW, CAP, HEXAGON H CAPTIVE WASHER,	6
8	PAFZZ	5310008878325	15434	114638	M915A1 ONLY.....	4
8	PAFZZ		15434	3027653	DOWEL, MANIFOLD.....	4
9	PAFZZ	5340001323203	15434	200919	SCREW M915 ONLY	4
10	PAFZZ	3120010796527	15434	109594	WASHER, KEY M915 ONLY	1
11	PAFZZ	5340007674012	15434	116982	RING, EXHAUST M915A1 ONLY	2
12	PAFZZ	4730010857328	15434	217632	STRAP, RETAINING M915 ONLY	8
13	PAFZZ	5307009222626	15434	3006289	BEARING, SLEEVE M915 ONLY	4
					LOCKING PLATE, NUT A M915 ONLY.....	2
					PLUG, PIPE M915 ONLY	4
					STUD, PLAIN M915 ONLY	2

END OF FIGURE



* a PART OF ITEM 1

Figure 16. Gear Cover

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 0109 ACCESSORY DRIVING MECHANISMS	
					FIG. 16 GEAR COVER	
1	PAFZZ	2815011590872	15434	3024442	GEAR COVER ASSEMBLY.....	1
2	PAFZZ	3120008772213	15434	3029852	.BEARING, SLEEVE	1
3	PFFZZ	4710012096742	15434	210416	TUBE, METALLIC.....	1
4	PAFZZ	5365005073254	15434	65259-C	SHIM 0.002.....	V
4	PAFZZ	5365010867788	15434	185573	SHIM INSERT.....	V
4	PAFZZ	5365011470912	15434	65259-A	SHIM 0.010	V
4	PAFZZ	5365011470913	15434	65259-B	SHIM 0.005.....	V
5	PCFZZ	5331011450716	15434	215705	O-RING PART OF KIT P/N 3801235	1
6	PAFZZ		15434	211255	SEAL, PLAIN ENCASED PART OF KIT P/N 3801235	1
7	PAFZZ	5305011458381	15434	3011713	SCREW, CAP, HEXAGON H W/CAPTIVE	1
					WASHERS 7/16-20 X 2-5/8.....	
8	PAFZZ	2815007729434	15434	70653	DOWEL, METALLIC	1
9	PAFZZ	5315002380882	15434	60408	PIN, STRAIGHT, HEADLE	1
10	PFFZZ	4730000189566	15434	S911B	PLUG, PIPE 1/8 NPTF	2
11	PCFZZ	5330011456914	15434	3021704	GASKET FRONT ENGINE GEAR COVER PART	1
					OF KIT P/N 3801235.....	
12	PFFZZ	5305011474033	15434	3011711	SCREW, CAP, HEXAGON H W/CAPTIVE	9
					WASHERS 7/16 - 20 X 1 -3 /8. M915.....	
12	PFFZZ	5305012407155	15434	3011712	SCREW, ASSEMBLED WAS 7/16 - 20 X 2 - 3/	9
					16. M915A1	
13	PAFZZ	4730000103867	24617	219191	PLUG, PIPE 3/8 NPT	1
13	PAFZZ	4730000428988	11862	117244	PLUG, PIPE 1/4 NPT. M915 ONLY.....	3
14	PFFZZ	5305011653300	15434	S-119-C	SCREW, CAP, HEXAGON H.....	1
15	XBFZZ		15434	218716	SPACER, PLATE.....	8
16	PFFZZ	5310011124306	15434	203760	WASHER, FLAT 15/32.....	2
16	PAFZZ	5310011458404	15434	3000082	WASHER, FLAT 15/32.....	6
17	PAFZZ	5305011478731	15434	213456	SCREW, CAP, HEXAGON H 7/16 - 20 X 2 - 3/4	6
18	PAFZZ	2815010799146	15434	214306	SUPPORT, FRONT, ENGIN.....	1
19	PAFZZ	5306011469866	15434	3058664	BOLT, MACHINE TWELVE POINT CAP, 7/	2
					16 - 20 X 2.500	
20	PAFZZ	5305011653892	15434	3011714	SCREW HEXAGON HEAD, WITH CAPTIVE	3
					WASHERS, 7/16 - 20 X 3.00	
21	PAFZZ	5310002090965	96906	MS35338-47	WASHER, LOCK 7/16 M915.	1
22	PAFZZ	5305010728816	15434	3011715	SCREW HEXAGON HEAD W/CAPTIVE.....	3
					WASHERS, 3/8-16 X 13/16	
23	PAFZZ	2815011459401	15434	3008530	SUPPORT, CAMSHAFT	1

END OF FIGURE




Figure 17. Accessory Drive Pulley and Fan Clutch.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 0109 ACCESSORY DRIVING MECHANISMS	
					FIG. 17 ACCESSORY DRIVE PULLEY AND FAN CLUTCH	
1	PAOZZ	5305011458382	75078	012647	SCREW, CAP, HEXAGON H WITH CAPTIVE	1
					WASHER, SEE GROUP 0112	
2	PAOZZ	2930010976755	15434	217034	BRACE, FAN BRACKET	1
3	PAOZZ	5310011446115	75078	001094	NUT, PLAIN, CONE SEAT	2
4	PAOZZ	5365011475030	75078	001234	SPACER, SLEEVE SEE GROUP 0112	1
5	PAOZZ	5305010912498	15434	166777	SCREW 1/2 - 13	1
6	PAOZZ	5310004706154	15434	S-285	NUT, PLAIN, HEXAGON 1/2 - 13	1
7	PBOZZ	5342010980175	15434	208829	BRACKET, FAN SUPPORT	1
8	PAOZZ	5305011450776	15434	3019574	SCREW, CAP, HEXAGON H WITH CAPTIVE	2
					WASHER	
9	PAOZZ	5365010955666	75078	003251	SPACER, SLEEVE FAN BRACE, SEE GROUP	2
					0112	
10	PAOZZ	5310011458405	75078	001030	WASHER, FLAT	1
11	PAFFH	4310010929815	15434	3005133	DRIVE ACCESSORY, COM	1
12	PAFZZ	5305011458383	15434	175833	.SCREW, CAP, HEXAGON H 3/8-16 X 1 1/8	6
13	PAFZZ	5310011261045	15434	3012526	.NUT, SELF-LOCKING, HE	1
14	PAFZZ	5310011246463	15434	193136	.WASHER, FLAT	1
15	PAFZZ	3020011463773	15434	3013336	.PULLEY, CONE ACCESSORY DRIVE	1
16	PCFZZ	5330011296541	15434	3008947	.RUBBER STRIP	1
17	PAFZZ	3020011463163	15434	3023473	.PULLEY, FLAT ACCESSORY DRIVE	1
18	PAFZZ	2930004019531	15434	190397	.SLEEVE, PULLEY, PUMP	1
19	PCFZZ	5330000262931	15434	200809	.GASKET PART OF KIT P/N 3801235	1
20	PAFZZ	3020001609092	15434	142689	.GEAR, HELICAL ACCESSORY DRIVE	1
21	PAFZZ	3120011475275	15434	3026556	.BEARING, WASHER, THRU	1
22	PAFZZ	4310010929816	15434	3000171	.SHAFT, AIR COMPRESSO ACCESSORY	1
					DRIVE	
23	PAFZZ	2815011240232	15434	70550	.PIN, PISTON	2
24	PAFZZ	5306011194271	15434	3000173	.BOLT, INTERNALLY REL SELF-LOCKING,	1
					3/8-16 X 1.00	
25	PAFZZ	5310004862507	15434	170664	.WASHER, FLAT	1
26	PAFZZ	3010010852732	15434	3000174	.COUPLING HALF, SHAFT SPLINE	1
					COUPLING	
27	PAFZZ	5310000819292	15434	3014103	.WASHER, FLAT	1
28	PAFZZ	3120011447368	15434	3026557	.BEARING, WASHER, THRU	1
29	PAFZZ	5305011198621	15434	3010590	.SCREW WITH CAPTIVE WASHER, 7/16-	5
					20 X 1.125/1.063	
30	PAFZZ	3040011294302	15434	AR-45724	.HOUSING, MECHANICAL ACCESSORY DRIVE	1
31	PAFZZ	4730000189566	15434	S-911-B	..PLUG, PIPE	2
32	PAFZZ	3120007929834	15434	116391	..BEARING, SLEEVE	1

END OF FIGURE





Figure 18. Engine Retarder.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0112 ENGINE BRAKE						
FIG. 18 ENGINE RETARDER						
1	PAFHH	2815010852574	75078	016053	BRAKE ASSEMBLY, ENGI ENGINE BRAKE	1
2	PAFHH	2815011413261	75078	009917	..HOUSING, ENGINE RETA BRAKE	3
3	PCHZZ	6150011147119	75078	002390	..LEAD, ELECTRICAL	1
4	PAHZZ	4810010890534	75078	004205	..CARTRIDGE, SOLENOID SOLENOID	1
5	PCHZZ	5331010861013	75078	001081	..O-RING	1
6	PCHZZ	5331010853105	75078	001082	..O-RING	1
7	PCHZZ	5330010866196	75078	001083	..PACKING, PREFORMED	1
8	PAHZZ	5310011573762	75078	001026	..NUT, PLAIN, HEXAGON M915 ONLY	2
8	PAHZZ	5310011467302	75078	009353	..NUT, SELF-LOCKING, EX M915A1 ONLY	2
9	PAHZZ	5305011867042	75078	001031	..SETSCREW 0.375-24X0.75IN.LG,	2
					RETARDER, ENGINE-JACOBS BR.M915 ONLY	
9	PAHZZ	5305011446206	75078	009916	..SETSCREW M915A1 ONLY	2
10	PAHZZ	5940010854426	75078	002299	..TERMINAL, FEEDTHRU, I	1
11	PAHZZ	5360011457607	75078	007447	..SPRING, FLAT MASTER PISTON	2
12	PAHZZ	5310011458405	75078	001030	..WASHER, FLAT	1
13	PAHZZ	5305011458384	75078	001492	..SCREW, CAP, HEXAGON H	2
14	PAHZZ	2815010887328	75078	004089	..PISTON, MASTER	2
15	PAHZZ	5325010878727	75078	001023	..RING, RETAINING	2
16	PAHZZ	5340010854439	75078	008895	..RETAINER, HELICAL CO SLAVE PISTON	2
17	PAHZZ	5360010849066	75078	001022	..SPRING, HELICAL, COMP	2
18	PAHZZ	2815010986755	75078	001484	..PISTON, SLAVE M915 ONLY	2
18	PAHZZ	2815010986755	75078	007623	..PISTON, SLAVE M915A1 ONLY	2
19	PAHZZ	2815011461997	75078	007696	..PISTON, SLAVE SLAVE, FOR MILLED	2
					CYLINDER HEADS	
20	PAHZZ	4820010893939	75078	001521	..CARTRIDGE, CHECK VAL M915 ONLY	2
20	PAHZZ	4820011464593	75078	007505	..VALVE, CHECK M915A1 ONLY	2
21	PAHZZ	5360010899103	75078	001519	..SPRING CONTROL VALVE, OUTER	2
22	PAHZZ	5360011457555	75078	007500	..SPRING, HELICAL, COMP CONTROL	2
					VALVE, INNER	
23	PAHZZ	2815011459402	75078	004136	..PLATE, COVER, VALVE, D CONTROL VALVE	2
24	PCFZZ	5330010863996	75078	13294	..GASKET BRAKE HOUSING	3
25	PCFZZ	5330011456083	75078	010180	..PACKING, PREFORMED	3
26	PAFZZ	2520010856128	75078	002969	..SCREW SHAFT LOCK	2
27	PAFZZ	5307011095972	75078	1764	..STUD, SHOULDERED AND M915 ONLY	2
27	PAFZZ	5306011076371	75078	003678	..BOLT, EXTERNALLY REL M915A1 ONLY	1
28	PAFZZ	5310011475072	75078	002514	..WASHER, BEARING	1
29	PFFZZ	5307011471316	75078	2856	..STUD, SHOULDERED M915 ONLY	2
29	PAFZZ	5307011471316	75078	002856	..STUD, SHOULDERED M915A1 ONLY	1
30	PAFZZ	5307011472821	75078	001232	..STUD, SHOULDERED	4
31	PAFZZ	5307011458449	75078	001199	..STUD, SHOULDERED	8
32	PAOZZ		15434	3045534	RECTANGULAR SEAL	1
33	PAOZZ	5365011475030	75078	001234	SPACER, SLEEVE	6
34	PAOZZ	5310011446115	75078	001094	NUT, PLAIN, CONE SEAT	6
35	PAOZZ		75078	002680	LOCK, PLATE	6

END OF FIGURE







Figure 19. Air Compressor Lines and Fittings.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0121 COMPRESSOR ASSEMBLY						
FIG. 19 AIR COMPRESSOR LINES AND FITTINGS						
1	PAOZZ	4730010793273	15434	3002074	ELBOW, PIPE TO HOSE AIR INTAKE	1
2	PCOZZ	4720009189634	15434	61554	HOSE, PREFORMED	2
3	PAOZZ	4730005558263	70403	A11	CLAMP, HOSE M915 ONLY.....	8
3	PAOZZ	4730005558263	53496	5561 1-2A	CLAMP, HOSE M915A1 ONLY	4
4	PAOZZ	4710011463085	15434	217939	TUBE, BENT, METALLIC	1
5	PAOZZ	5305002264831	80204	B1821BH031C150N	SCREW, CAP, HEXAGON H 5/16 - 18 X 1.50.....	1
6	PAOZZ	5310004079566	96906	MS35338-45	WASHER, LOCK	2
7	PAOZZ	5310005626558	15434	S-626	WASHER, FLAT	2
8	PAOZZ	5305011294214	15434	3022590	SCREW, CAPTIVE	1
9	PAOZZ	4730010854156	15434	196282	ELBOW, FLANGE TO HOS AIR COMPRESSOR	1
					INTAKE	
10	PAOZZ	4730000189566	15434	S-911-B	PLUG, PIPE.....	1
11	PAOZZ	5330011810630	15434	3201386	GASKET.....	1
12	PAOZZ	4730003652690	15434	S-1002-A	ADAPTER, STRAIGHT, TU.....	3
13	PAOZZ	4710010958683	15434	21609300	TUBE, BENT, METALLIC OUTLET M915A1	1
13	PAOZZ	4710010793492	15434	3038060	TUBE ASSEMBLY, METAL COMPRESSOR	1
					COOLING M915	
14	PCOZZ	5365005985255	15434	S-1003-A	.BUSHING, NONMETALLIC.....	2
15	PAOZZ	4730001383906	15434	187317	COUPLING, PIPE PLAIN STRAIGHT, 3/8	1
					NPT.....	
16	PAOZZ	4730003744282	15434	S-1005-A	ELBOW, PIPE TO TUBE.....	1
17	PAOZZ	4710011461112	15434	3026999	TUBE, BENT, METALLIC OUTLET M915A1	1
17	PAOZZ	4710011463168	15434	3028642	TUBE ASSEMBLY, METAL COMPRESSOR	1
					COOLING M915	
18	PCOZZ	5365005985255	15434	S-1003-A	.BUSHING, NONMETALLIC.....	2

END OF FIGURE



- * a PART OF ITEM 20
- * b PART OF ITEM 25
- * c PART OF ITEM 30

Figure 20. Air Compressor and Governor Assembly (Sheet 1 of 2).




Figure 20. Air Compressor and Governor Assembly (Sheet 2 of 2).

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0121 COMPRESSOR ASSEMBLY						
FIG. 20 AIR COMPRESSOR AND GOVERNOR ASSEMBLY						
1	PAFZZ	5310000116122	12204	116122	WASHER, LOCK	4
2	PAFZZ	5305011474034	15434	S-122-C	SCREW, CAP, HEXAGON H.....	2
3	XBFZZ		96906	MS90725-90	SCREW, CAP, HEXAGON H.....	2
4	PAFZZ	3010010793461	15434	199349	COUPLING, SHAFT, RIGI.....	1
5	PAFZZ	5330011810631	15434	320-1850	GASKET.....	1
6	PAFZZ	5310011124307	15434	69324	WASHER, FLAT	2
7	PAFZZ	5310006500187	15434	S-217	NUT, PLAIN, HEXAGON.....	2
8	PAFFD	4310011410879	15434	3024365	COMPRESSOR, RECIPROC	1
9	PAFZZ	5305002258507	96906	MS90725-43	.SCREW, CAP, HEXAGON H.....	4
10	PAFZZ	5310004079566	96906	MS35338-45	.WASHER, LOCK	2
11	PAFZZ	5310005626558	15434	S-626	.WASHER, FLAT	2
12	PFFZZ	4310011465921	15434	153964	.COVER, AIR COMPRESSO.....	1
13	PCFZZ	5330001317072	15434	3047159	.GASKET.....	1
14	PFFZZ	4310011461097	15434	218793	.CYLINDER HEAD, COMPR	1
15	PCFZZ	5330008527347	15434	154018	.GASKET.....	1
16	XBFFZ		15434	3018488	.PISTON, COMPRESSOR	1
17	PAFZZ	4310010796938	15434	165430	.PISTON, COMPRESSOR	1
18	PAFZZ	4310009037174	15434	119810	..PIN, PISTON	1
19	PAFZZ	5325009229101	15434	119859	..RING, RETAINING.....	2
20	PAFZZ	2815003697846	15434	3558655	..CONNECTING ROD, PIST.....	1
21	PAFZZ	3120011467196	15434	3018153	..BUSHING, SLEEVE.....	1
22	KFFZZ		15434	180810	..RING, PISTON PART OF KIT P/N AR- 73350	1
23	KFFZZ		15434	1875350	RING, COMPRESSION, PART OF KIT P/N AR-73350	1
24	KFFZZ		15434	650330	..RING, PISTON PART OF KIT P/N AR- 73350	1
25	PAFZZ	4310010793319	15434	3558653	..HOUSING, AIR COMPRES	1
26	PAFZZ	3120010164883	15434	147610	..BEARING, SLEEVE	1
27	PFFZZ	9905004737260	15434	136403	..PLATE, MARKING, BLANK	1
28	PFFZZ	5305008046318	15434	S-2286	..SCREW	2
29	PAFZZ	4310010793383	15435	AR-10922	..CRANKSHAFT, COMPRESS	1
30	PAFZZ	4730009647548	21450	444683	..PLUG, PIPE.....	1
31	PFFZZ	5330001299389	15434	176027	.GASKET.....	1
32	PAFZZ	2530011302339	15434	3005152	.SUPPORT, AIR COMPRES	1
33	PAFZZ	5310002090965	96906	MS35338-47	.WASHER, LOCK	4
34	PAFZZ	5305011294384	15434	3015282	.SCREW, CAP, HEXAGON H.....	4
35	PAFZZ	3120011297659	15434	211662	.BEARING, WASHER, THRU	1
36	PAFZZ	3010010852732	15434	3000174	.COUPLING HALF, SHAFT	1
37	PAFZZ	5305011458359	15434	3019573	.SCREW, ASSEMBLED WAS	2
38	PAFZZ	5365003694729	15434	183429	.SHIM	1
39	PAFZZ	5360008953216	15434	128080	.SPRING, HELICAL, COMP EXHAUST VALVE	1
40	PAFZZ	4820004450610	15434	127940	.DISK, VALVE.....	1
41	PCFZZ	5331009052679	15434	128085	.O-RING EXHAUST VALVE	1
42	PAFZZ	4820009094174	15434	144714	.SEAT, VALVE.....	1
43	PCFZZ	5330010609061	15434	211315	.PACKING, PERFORMED.....	1
44	PAFZZ	5360001299415	15434	190334	.SPRING, HELICAL, COMP INTAKE VALVE	1
45	PAFZZ	3805009555320	15434	144948	.VALVE INTAKE COMPRE	1

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
46	PAFZZ	4820009094175	15434	145028	.SEAT, VALVE.....	1
47	PAFZZ	5360010863480	15434	3023101	.SPRING, HELICAL, COMP UNLOADER VALVE.....	1
48	PAFZZ	4310010847148	8X479	191037	.CAP, UNLOADER.....	1
49	PCFZZ	5331009413762	15434	127936	.O-RING.....	1
50	PCFZZ	5331004410145	15434	128086	.O-RING UNLOADER VALVE.....	1
51	PAFZZ	4310011464155	15434	185847	.BODY, UNLOADING VALV UNLOADER VALVE.....	1
52	PAFZZ	5310010561371	28265	14978	.WASHER, FLAT.....	2
53	PAFZZ	5305011446233	15434	3021470	.SCREW, CAP, HEXAGON H WITH CAPTIVE..... WASHER, 5/16.....	2
54	PAFFZ	2530008275934	06853	275707	GOVERNOR ASSEMBLY, A.....	1
55	PFFZZ	2530010930872	06853	275230	HOUSING, AIR BRAKE G.....	1
56	PAFZZ	4730006023707	25511	P49787	.PLUG, PIPE.....	3
57	PAFZZ	4730002250710	06853	240346	STRAINER ELEMENT, SE.....	2
58	PAFZZ	5360002250709	06853	240336	SPRING, HELICAL, COMP.....	1
59	PAFZZ	4820002250708	06853	240334	DISK, VALVE.....	1
60	PAFZZ	5331002250707	06853	239658	PACKING, PREFORMED.....	2
61	PFFZZ	2530006031532	06853	103840	PISTON, LINEAR ACTUA.....	1
62	XAFZZ		06853	240331	.PISTON, GOVERNOR, COM.....	1
63	PAFZZ	5331003119188	06853	230175	.PACKING, PREFORMED.....	1
64	PAFZZ	5310001435722	04998	WA1248	.WASHER, FLAT.....	1
65	PAFZZ	5360000791940	06853	240338	SPRING, HELICAL, COMP.....	1
66	PAFZZ	4820001179103	06853	240339	STEM, EXHAUST.....	1
67	PAFZZ	5340009223522	06853	240347	COVER, ACCESS.....	1
68	PAFZZ	5340007387552	06853	240345	CLIP, RETAINING.....	1
69	PFFZZ	4310002250706	06853	275202	PARTS KIT, GASOLINE.....	1
70	PAFZZ	5310004037731	06853	202961	.NUT, PLAIN, HEXAGON.....	1
71	PAFZZ	5310011577361	06853	246075	.WASHER, FLAT.....	1
72	PAFZZ	5340001179102	06853	240344	.SEAT, HELICAL COMPRE.....	1
73	PAFZZ	5360006031518	06853	240343	.SPRING, HELICAL, COMP.....	1
74	PAFZZ	5340001166767	06853	240341	.SEAT, HELICAL COMP RE.....	2
75	PAFZZ	2530001169953	06853	240342	.GUIDE, SPRING.....	1
76	PAFZZ	5305008396230	06853	240340	.SETSCREW.....	1
77	PCFZZ	5330010977791	06853	237303	GASKET.....	1
78	PAFZZ	5310010978039	24617	9417953	WASHER, LOCK.....	2
79	PAFZZ	5305011184285	24617	9418993	SCREW, CAP, HEXAGON H.....	2
80	PAFZZ	4730002778269	79470	400X3	ELBOW, PIPE TO TUBE.....	1

END OF FIGURE




Figure 21. Fuel Injector.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 03 FUEL SYSTEM						
GROUP 0301 CARBURETOR, FUEL INJECTOR						
FIG. 21 FUEL INJECTOR						
1	PAFZZ	5340002385435	15434	191916	PLUNGER, DETENT.....	6
2	PAFZZ	3040010774976	15434	3003682	PLATE, RETAINING, SHA INJECTOR TO.....	6
CYLINDER HEAD, INJECTOR, FUEL, M915 ONLY						
2	PAFZZ	5342011450646	15434	3028171	CLAMP M915A1 ONLY	6
3	PAFZZ	5305010867285	15434	202069	SCREW, CAP, SOCKET HE INJECTOR TO.....	12
CYLINDER HEAD, INJECTOR, FUEL, M915 ONLY						
3	PAFZZ	5305011450777	15434	3028279	SCREW, CAP, HEXAGON H INJECTOR CLAMP,	12
M915A1 ONLY.....						
4	PAFHH	2910011127712	15434	3054071	INJECTOR ASSEMBLY, F M915 ONLY.....	6
4	PAFHH	2910011459403	15434	3030445	NOZZLE, FUEL INJECTI M915A1 ONLY	6
5	PAHZZ	5340011450647	15434	3047963	.PLUNGER, QUICK RELEA	1
6	PAHZZ	5315010796506	15434	203426	..PIN, SPRING	2
7	PAHZZ	5310010796529	15434	208525	.WASHER, SHOULDERED A M915 ONLY	1
7	PAHZZ	5310011451114	15434	3015469	.WASHER M915A1 ONLY	1
8	PAHZZ	5360001320245	15434	166009	.SPRING, HELICAL, COMP	1
9	PCHZZ	5330001320276	15434	193736	.GASKET PART OF KIT P/N 3804280 PART	3
OF KIT P/N 3804275.....						
10	PAHZZ	5342010794678	15434	185138	.RETAINER, CUP	1
11	PAHZZ	2910010863974	15434	3012538	.CUP, INJECTOR INJECTOR, FUEL, M915.....	1
ONLY						
11	PAHZZ	2910011461998	15434	3023556	.CUP, INJECTOR, FUEL M915A1 ONLY	1
12	PAHZZ	4820010709710	15434	167157	.BALL CHECK, FUEL INJ.....	1
13	PAHZZ	5365008151137	15434	174299	.RING, RETAINING.....	1
14	PAHZZ	4730010772016	15434	3008706	.STRAINER ELEMENT, SE.....	1
15	PCHZZ	5330001320247	15434	173086	.GASKET.....	1
16	PAHZZ	2910010768632	15434	3000464	.ADAPTER, INJECTOR.....	1
17	PAHZZ	5310010796708	15434	3000465	.NUT, PLAIN, DODECAGON.....	1
18	PAHZZ	5305010797028	15434	212954	.SCREW.....	1

END OF FIGURE




Figure 22. Fuel Lines and Fittings.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0302 FUEL PUMP						
FIG. 22 FUEL LINES AND FITTINGS						
1	PAOZZ	5310005218595	15434	S-223	NUT HE, AGON.....	2
2	PAOZZ	5310001596209	96906	MS122032	WASHER, LOCK M915 ONLY.....	2
2	PAOZZ	5310002617340	15434	S-604	WASHER, LOCK M915A1 ONLY.....	3
3	PAFZZ	5310005626560	15434	S631	WASHER, FLAT M915 ONLY.....	4
3	PAOZZ	5310004862505	15434	108330	WASHER, FLAT M915A1 ONLY.....	3
4	PFOZZ	5342008583507	15434	147135	BRACKET, TUBE SUPPOR.....	1
5	PAOZZ	5305010291193	15434	S-117	SCREW 3/8-16 X 3/4.....	1
6	PAOZZ	5340010798097	15434	180371	CLAMP, LOOP.....	2
7	PAOZZ	5306012043297	15434	137796	BOLT, MACHINE M915 ONLY.....	1
7	PAOZZ	5305007959345	15434	S190C	SCREW, CAP 3/8 - 24 X 5/8 M915 ONLY.....	2
8	PAOZZ	5340007194601	15434	180372	CLAMP, LOOP.....	3
9	PBOZZ	4710010859348	15434	3015373	TUBE ASSEMBLY, METAL M915 ONLY.....	1
9	PAOZZ	4710011463779	15434	3022821	TUBE ASSEMBLY, METAL M915A1 ONLY.....	1
10	PAOZZ	4710011461115	15434	3038037	TUBE ASSEMBLY, METAL M915A1 ONLY.....	1
10	MOOZZ	19207	5414243-20		HOSE, NONMETALLIC M915 ONLY, MAKE FROM P/N 28430 PART OF KIT P/N 302112400.....	2
11	PBOZZ	4710010793493	15434	216128	TUBE ASSEMBLY, METAL M915 ONLY.....	1
11	PAOZZ	4710011461114	15434	202185	TUBE ASSEMBLY, METAL M915A1 ONLY.....	1
12	PAOZZ	4730011314884	15434	S-1097	ADAPTER, STRAIGHT, PI WITH ADAPTER..... AND PLUG.....	1
13	PAOZZ	4730004441710	15434	181213	ELBOW, PIPE TO TUBE.....	2
14	PBOZZ	4710011068068	15434	3009848	TUBE ASSEMBLY, METAL M915 ONLY.....	1
14	PAOZZ	4710011461116	15434	3013161	TUBE ASSEMBLY, METAL M91A1 ONLY.....	1
15	PAOZZ	4730011463633	15434	3014398	TEE, TUBE.....	1
16	PBOZZ	4710010856134	15434	3015393	TUBE ASSEMBLY, METAL M915 ONLY.....	1
16	PAOZZ	4710011461113	15434	3015389	TUBE ASSEMBLY, METAL M915A1 ONLY.....	1
17	PAOZZ	4730011098501	15434	3014397	TEE, TUBE.....	1
18	PBOZZ	4710010859349	15434	3015375	TUBE ASSEMBLY, METAL M915 ONLY.....	1
18	PAOZZ	4710011463169	15434	3015387	TUBE ASSEMBLY, METAL M915A1 ONLY.....	1
19	PAOZZ	4730011064700	15434	129866	ADAPTER, STRAIGHT, TU.....	1
20	PAOZZ	4730011428524	15434	68139	ELBOW, PIPE TO TUBE.....	1
21	PAOZZ	2910011460093	15434	3020760	VALVE.....	1
22	PAOZZ	4730011463040	15434	3018889	ADAPTER, STRAIGHT, PI.....	1
23	PAOZZ	4730002789200	88044	AN737TW22	CLAMP, HOSE M915 ONLY PART OF KIT..... P/N 302112400.....	4
24	KFOZZ		15434	3020754	BODY, CHECK VALVE M915 ONLY PART OF..... KIT P/N 302112400.....	1
25	PAOZZ	5310006379541	96906	MS35338-46	WASHER, LOCK M915 ONLY PART OF KIT..... P/N 302112400.....	2
26	KFOZZ		15434	S689	WASHER, PLAIN M915 ONLY PART OF KIT..... P/N 302112400.....	1
27	KFOZZ		15434	S-109	SCREW, CAP, HEXAGON M915 ONLY PART OF..... KIT P/N 302112400.....	1
28	KFOZZ		15434	170970	CLAMP M915 ONLY PART KIT P/N..... 302112400.....	1
29	KFOZZ		15434	S-151C	SCREW, CAP, HEXAGON M915 ONLY PART OF..... KIT P/N 302112400.....	1
30	KFOZZ		15434	3020753	TANK, AIR PART OF KIT P/N 302112400.....	1

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
31	PAOZZ	4730009003296	72983	248X4	ADAPTER, STRAIGHT, PI PART OF KIT P/N 302112400	2

END OF FIGURE






Figure 23. Fuel Pump.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0302 FUEL PUMP						
FIG. 23 FUEL PUMP						
1	PAFZZ	5305011474034	15434	S-122-C	SCREW, CAP, HEXAGON H 9/16-18 X 7/8	1
2	PAFZZ	5310000116122	12204	116122	WASHER, LOCK	1
3	PFFZZ	5342010854153	15434	3001296	BRACKET, AIR COMPRES	1
4	PAFZZ	5305011478732	15434	3012481	SCREW, CAP, HEXAGON H 7/16-14 X 1 1/	1
					2, M915A1 ONLY	
5	PAFZZ	5310011124307	15434	69324	WASHER, FLAT	4
6	PAFHH	2910011419372	15434	3060202-3894	PUMP, FUEL, METERING "BUSHED GEAR."	1
					CAN BE USED W/ALL DIESEL FUELS. M915A1	
6	PAFHH	2910010653979	15434	3060199-4128	PUMP, FUEL, ENGINE "NON-BUSHED GEAR"	1
					M915 ONLY	
7	PAFZZ	5305011294384	15434	3015282	SCREW, CAP, HEXAGON H M915 ONLY	2
7	PAFZZ	5305011450777	15434	3028279	SCREW, CAP, HEXAGON H M915A1 ONLY	1
8	PAHZZ	5330011607460	15434	3035053	GASKET	1
9	PAFZZ	3010004479799	15434	162426	INSERT, FLEXIBLE COU FUEL PUMP TO.....	1
					AIR COMPRESSOR	
10	PAFZZ	5305011131179	15434	206326	SCREW, CAP, HEXAGON H 7/16-14 X 1 1/4	1

END OF FIGURE



* a PART OF ITEM 35

Figure 24. Fuel Pump Main Housing.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0302 FUEL PUMP						
FIG. 24 FUEL PUMP MAIN HOUSING						
1	PAHZZ	5305011294385	15434	70772-B	SCREW, CAP, HEXAGON H FILSTER HEAD, 1/4-20 X 1.00	2
2	PAHZZ	5305011294218	15434	3012558	SCREW DRILLED FILSTER HEAD, 1/4-20..... X 1.00.....	1
3	PAHZZ	5310005626560	15434	S-631	WASHER, FLAT	3
4	PAHZZ	4820010793241	15434	3015522	CARTRIDGE, VALVE, CHE	1
5	PAHZZ	2910011414967	15434	3015520	COVER, FUEL CONTROL	1
6	PAHZZ	5310004516643	15434	S-213-A	NUT, FLYWHEEL	1
7	PAHZZ	2910011414029	15434	3023171	HOUSING, SPRING PUMP.....	1
8	PAHZZ	5330011422784	15434	3023870	GASKET PART OF KIT P/N 3010242	1
9	PAHZZ	5310011450761	15434	214150	WASHER, FLAT	1
10	PAHZZ	4820010793320	15434	3013811	DIAPHRAGM, VALVE	1
11	PAHZZ	5330010728830	15434	3003156	SEAL, SPECIAL PART OF KIT P/N 3010242.....	1
12	PAHZZ	2910011427455	15434	3013810	PISTON, AIR FLOW	1
13	PAHZZ	5310011422812	15434	3023088	WASHER, FLAT	1
14	PCHZZ	5331009703461	15434	68061-A	O-RING PART OF KIT P/N 3010242	2
15	PAHZZ	2910011269053	15434	3021676	PLUNGER, AIR FLOW.....	1
16	PAHZZ	5360010866113	15434	179834	SPRING, HELICAL, COMP M915 ONLY.....	1
16	PAHZZ	5360011470054	15434	179822	SPRING, HELICAL, COMP M915A1 ONLY	1
17	PAHZZ	5365010798373	15434	3001707	SHIM	1
18	PAHZZ	5325005589412	96906	MS16629-1100	RING, RETAINING.....	1
19	PAHZZ	5330010728982	15434	145505	PACKING, PREFORMED PART OF KIT P/N..... 3010242	1
20	PAHZZ	5330010514243	15434	145504	PACKING, PREFORMED PART OF KIT P/N..... 3010242	1
21	PCHZZ	5330004039896	15434	193734	PACKING, PREFORMED M915 ONLY.....	1
21	PAHZZ	5330005992962	94135	12Z9026-5	PACKING, PREFORMED M915A1 ONLY.....	1
22	PAHZZ	3040010861651	15434	214146	CYLINDER, ACTUATING M915 ONLY	1
22	PAHZZ	2910011424953	15434	3021068	BARREL, AIR FLOW M915A1 ONLY.....	1
23	PAHZZ	5360011345602	15434	3018655	SPRING, HELICAL, COMP	1
24	PAHZZ	5325002562846	96906	MS16632-1050	RING, RETAINING	1
25	PAFZZ	5305004264146	15434	S105X	SCREW, CAP.....	6
26	PAFZZ	5310004841718	15434	181466	WASHER, LOCK	6
27	PAFZZ	4730011243762	15434	3025460	PLUG, PIPE.....	4
28	PFHZZ	9905007337622	15434	105375	PLATE, IDENTIFICATIO	1
29	PFHZZ	5305008046318	15434	S-2286	SCREW.....	4
30	PAHZZ	4730005558292	24617	444704	PLUG, PIPE M915A1 ONLY	1
30	PAFZZ	4730000428988	11862	117244	PLUG, PIPE M915 ONLY	1
31	PAOZZ	5365005073271	15434	157088	PLUG, MACHINE THREAD	1
32	PCOZZ	5330009619470	15434	154088	SEAL CAP PART OF KIT P/N 3010242	1
33	PAOZZ	5360005974570	15434	70700	SPRING, HELICAL, COMP	1
34	PAOZZ	2910007908736	15434	146483	FILTER ELEMENT, FLUI	1
35	XDHZZ		15434	AR41022	HOSING, FUEL PUMP M915 ONLY	1
35	PAHZZ	2910011461084	15434	3010042	BARREL, GOVERNOR M915A1 ONLY	1
36	PAHZZ	3120010803275	15434	209760	.BUSHING, SLEEVE.	1
37	PAHZZ	5342004005178	15434	163733	.CLIP, GOVERNOR BARRE.....	1
38	PAHZZ	5315008440140	15434	118227	.PIN, HOLLOW	4
39	PAHZZ	2910010985118	15434	217798	.HOUSING, SPRING PACK	1
40	PAHZZ	2910011479913	15434	3001847	.BARREL ASSEMBLY, GOV	1

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
41	PAHZZ	3120008106032	15434	100193	.BEARING, SLEEVE TACHOMETER DRIVE	1
42	PAHZZ	2910011414028	15434	214139	.BALL, PLUG BRASS	2
43	PAHZZ	5310009717989	96906	MS35691-5	NUT, PLAIN, HEXAGON.....	3
44	PAHZZ	5340007164975	15434	110058	POST, ELECTRICAL-MEC	1
45	PAHZZ	5305011099307	15434	195755	SCREW	1
46	PAHZZ	5325002562846	96906	MS16632-1050	RING, RETAINING.....	1
47	PAHZZ	2910010917507	15434	214144	VALVE, NEEDLE CARBUR	1
48	PFHZZ	5310000056052	15434	S248	NUT, PLAIN, HEXAGON	1
49	PAHHZ	2910010803149	15434	AR-41010	SHAFT ASSEMBLY, THRO	1
50	PFHZZ	5305011355446	15434	3006344	.SETSCREW 1/4-28UNF-3A	1
51	PFHZZ	3040010861449	15434	3006343	.END, CONTROL R	1
52	PCHZZ	5331010728983	15434	213768	.O-RING PART OF KIT P/N 3010242	1
53	PAHZZ	5305010728826	15434	3006175	.SCREW FUEL ADJUSTING	1
54	PAHZZ	3040011504926	15434	3006350	.SHAFT, THROTTLE	1
55	PAHZZ	5331000819289	15434	100478	.O-RING	1
56	PAHZZ	4320010985115	15434	3000446	COVER THROTTLE SHAFT	1
57	PAHZZ	3110010798190	15434	213769	BALL, BEARING	1
58	PAHZZ	4730010786364	15434	20063500	PLUG, PIPE M915 ONLY	2
59	PAHZZ	5315000820448	15434	144178	PIN, SHOULDER, HEADLE M915A1 ONLY.....	1
60	PAHZZ	5310007278353	15434	144179	WASHER, FLAT M915A1 ONLY	3
61	PAHZZ	5360010953661	15434	143848	SPRING, HELICAL, COMP M915A1 ONLY	1
62	PFHZZ	2910010709712	15434	3039070	PLUNGER ASSEMBLY, GO M915 ONLY	1
62	PAHZZ	5342011451549	15434	3010810	PLUNGER M915A1 ONLY	1
63	PAHZZ	2910010805570	15434	203350	.PLUNGER, GOVERNOR M915 ONLY	1
63	PAHZZ	5365008295604	15434	144302	.SPACER, FUEL PUMP M915A1 ONLY	1
63	PAHZZ	2910011363331	15434	3009380	.PLUNGER, GOVERNOR M915A1 ONLY	1
63	PAHZZ	2990007721778	15434	70690	.DRIVER, PLUNGER, GOVE GOVERNOR.....	1
					PLUNGER	
64	PAHZZ	5365005073224	15434	101841	.SHIM	V
64	PAHZZ	5365005073225	15434	101842	.SHIM	V
64	PAHZZ	5365005433744	15434	101843	.SPACER, RING	V
64	XDHZZ		15434	3026733	.SHIM M915A1 ONLY	V
65	PAHZZ	5360010866114	15434	138769	SPRING, HELICAL, COMP M915 ONLY	1
65	PAHZZ	5360011386638	15434	138781	SPRING, HELICAL, COMP M915A1 ONLY	1
66	PAHZZ	5305000635043	88044	AN565F428H24	SETSCREW	1

END OF FIGURE

- 1 — 2 thru 19
- 3 — 4 thru 9




Figure 25. Fuel Gear Pump.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0302 FUEL PUMP						
FIG. 25 FUEL GEAR PUMP						
1	PAFHD	3020012915753	15434	3034243	GEAR, PUMP ASSEMBLY "BUSHED." CAN BE USED W/ALL DIESEL FUELS	1
2	PCHZZ	5330005673463	15434	110855	.GASKET PART OF KIT P/N 3010242	1
3	PAHHH	2910010969200	15434	BM97497	.HOUSING AND COVER	1
4	PAHZZ	5315000141244	24617	141244	..PIN, STRAIGHT, HEADLE 3/8 X 1.00.....	2
5	XAHZZ		15434	175867	..COVER	1
6	XAHZZ		15434	175860	..HOUSING.....	1
7	PAHZZ	5306004850790	15434	70790	..BOLT, MACHINE 1/4-20 X 2.50.....	2
8	PAHZZ	5310004841718	15434	181466	..WASHER, LOCK	4
9	PAHZZ	4730002782973	96906	MS27769U2	..PLUG, PIPE.....	1
10	PAHZZ	4820012422579	15434	3050624	.VALVE, REGULATING, FL	1
11	PAHZZ	3020007023882	15434	119363	.GEAR, SPUR	2
12	PAHZZ	3040009333012	15434	175864	.SHAFT, IDLER, GEAR PU	1
13	PCHZZ	5330011368569	15434	3026163	.GASKET PART OF KIT P/N 3010242	1
14	XDHZZ		15434	3045049	.PLUG	1
15	PAHZZ	4820011647002	15434	3033740	.VALVE, CHECK	1
16	PAOZZ	5310001411795	88044	AN960-416	.WASHER, FLAT	1
17	PAHZZ	3120012159157	15434	3033724	.BEARING, SLEEVE	4
18	PAHZZ	3040005674354	15434	100215	.SHAFT, SHOULDERED	1
19	PAHZZ	3120011858586	15434	3033719	.BUSHING, SLEEVE	1
20	PAOZZ	5310001411795	88044	AN960-416	WASHER, FLAT	4
21	PAFZZ	5305007213698	15434	100129	SCREW, CAP, SOCKET HE	4

END OF FIGURE





Figure 26. Turbocharger and Component Parts.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 0305 SUPERCHARGER, BLOWER, TURBOCHARGER, OR ALTITUDE COMPENSATOR	
					FIG. 26 TURBOCHARGER AND COMPONENT PARTS	
1	PCOZZ	5330010728998	15434	216487	GASKET CROSSOVER MOUNTING, PART OF KIT P/N 3804280 PART OF KIT P/N 3804275	1
2	PAOZZ	5310006843463	96906	MS51092-1	WASHER, FLAT	4
3	PAOZZ	5305000680511	80204	B1821BH038C125N	SCREW, CAP, HEXAGON H 3/8-16 X 1 1/4.	4
4	PAOZZ	4730012946019	15434	200488	ADAPTER, STRAIGHT, P1 M915 ONLY	1
4	PAOZZ	2815011461102	15434	3018686	MANIFOLD, INTAKE AIR CROSSOVER, M915A1 ONLY.....	1
5	PAOZZ	4730004774160	15434	208326	CLAMP, HOSE	2
6	PCOZZ	4720010708149	55683	851-202994	HOSE, PREFORMED	1
7	PAFZZ	5307009222626	15434	3006289	STUD, PLAIN TURBOCHARGER MOUNTING	4
8	PCFZZ	5330001948385	15434	190849	GASKET PART OF KIT P/N 3804280 PART OF KIT P/N 3804275.....	1
9	PAFZZ	4730011276104	15434	3014354	ADAPTER, STRAIGHT, PI.....	1
10	PCHZZ	4720010856293	15434	215195	HOSE ASSEMBLY, NONME M915 ONLY	1
10	PAFZZ	4720011461071	15434	209955	HOSE ASSEMBLY, NONME M915A1 ONLY	1
11	PAFZZ	4730005558263	53496	5561 1-2A	CLAMP, HOSE	2
12	PAHZZ	5305002301939	15434	S118A	SCREW M915 ONLY	1
12	PAFZZ	5305000680502	96906	MS90725-6	SCREW, CAP, HEXAGON H WITH CAPTIVE	1
13	PAFZZ	5310012879737	15434	3056158	WASHER, 1/4-20 X 3/4, M915A1 ONLY	4
14	PAFZZ	4730011463631	15434	3025611	NUT, SLEEVE TURBOCHARGER MOUNTING, 3/8-24, M915A1 ONLY	2
15	PAFZZ	4730011467047	15434	3000560	ELBOW, TUBE OIL SUPPLY HOSE, M915A1	2
16	PAHZZ	4710010793487	15434	3016456	ONLY	1
16	PAFZZ	4710011463167	15434	3035600	ELBOW, PIPE TO TUBE M915A1 ONLY	1
17	PAHZZ	5340004003449	15434	108722	TUBE ASSEMBLY, METAL. M915 ONLY	1
17	PAFZZ	4730005558263	53496	5561 1-2A	TUBE ASSEMBLY, METAL TURBOCHARGER	1
18	PCFZZ	4720010851316	15434	AC1600300NF	DRAIN TUBE, M915A1 ONLY	2
19	PAFZZ	4730010793274	15434	3003536	CLAMP, LOOP M915 ONLY.....	2
20	PAFZZ	4710011587507	15434	3035595	CLAMP, HOSE M915A1 ONLY	1
21	PCFZZ	5365005985255	15434	S-1003-A	HOSE, NONMETALLIC.....	1
22	PAFHH	2990011557284	15434	3801904	ELBOW, PIPE TO HOSE TURBOCHARGER	1
22	PAFHH	2950011410844	15434	3029514	DRAIN	1
22	PFFHH	2990011723005	15434	3801942	TUBE ASSEMBLY, METAL M915A1 ONLY	1
23	PAHZZ	5305008046318	15434	S2286	.BUSHING, NONMETALLIC	2
24	KFHZZ		15434	128936	TURBOCHARGER M915 ONLY MODEL T-50.....	1
25	PAFZZ	4730003652690	15434	S-1002-A	TURBOSUPERCHARGER, N ASSEMBLY, T46-	1
					B, M915A1 ONLY	1
					TURBOCHARGER, ENGINE M915 ONLY	1
					MODEL #NTC400	4
					.SCREW	1
					.PLATE	2
					ADAPTER, STRAIGHT, TU BY-PASS FILTER.....	2
					TUBE	

END OF FIGURE




Figure 27. Turbocharger Assembly.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 0305 SUPERCHARGER, BLOWER, TURBOCHARGER, OR ALTITUDE COMPENSATOR	
					FIG. 27 TURBOCHARGER ASSEMBLY	
1	PAHZZ	5330010853580	15434	216802	SEAL, OIL, SLEEVE	1
2	KFHZZ		15434	156444	SEAL, TURBO PART OF KIT P/N 3801096	1
3	PAHZZ	4140010852607	15434	3002731	IMPELLER, FAN, CENTRI M915 ONLY	1
3	PAHZZ	4140011461035	15434	3031980	IMPELLER, FAN, CENTRI TURBOCHARGER,	1
					M915A1 ONLY.....	
4	XBHZZ		15434	S-222-A	NUT, SELF-LOCKING, HE	1
5	PAHZZ	5310006806874	15434	167299	NUT, SELF-LOCKING, HE PART OF KIT P/N	2
					3801096	
6	PAHZZ	5310005626560	15434	S-631	WASHER, FLAT PART OF KIT P/N 3801096.....	4
7	XBHZZ		15434	156416	STRAP, RETAINING	2
8	PAHZZ	2990010854768	15434	3027308	HOUSING, COMPRESSOR M915 ONLY	1
8	XDHZZ		15434	201250	HOUSING, CENTRIFUGAL M915A1 ONLY	1
9	PAHZZ	5305004119340	15434	194010	SCREW, CAP, HEXAGON H HEXAGON HEAD	2
					CAP PART OF KIT P/N 3801096	
10	KFHZZ		15434	217736	PLATE, DIFFUSER VANE , M915 ONLY PART	1
					OF KIT P/N 3801096.....	
11	KFHZZ		15434	202456	PACKING, PREFORMED PART OF KIT P/N.....	1
					3801096	
12	KFHZZ		15434	170510	GASKET PART OF KIT P/N 3801096.....	1
13	PAHZZ	3120006827706	15434	156420	BEARING, SLEEVE	1
14	PAHZZ	3130012941400	15434	3038745	HOUSING, BEARING UNI M915 ONLY	1
14	PFHZZ	3130011466120	15434	3026034	HOUSING, BEARING UNI M915A1 ONLY	1
15	KFHZZ		15434	202377	PACKING, FLAT FIBER PART OF KIT P/N	1
					3801096	
16	PAHZZ	2990004776159	15434	171570	SHIELD, HEAT	1
17	KFHZZ		15434	3034736	SEAL, PLAIN PART OF KIT P/N 3801096	2
18	PAHZA	2835010861447	15434	214086	SHAFT, TURBINE, NONAI M915 ONLY	1
18	PAHZZ	2950011456822	15434	3032835	WHEEL AND SHAFT, IMP M915A1 ONLY	1
19	PAHZZ	3040010861448	15434	204244	HOUSING, MECHANICAL M915 ONLY	1
19	PFHZZ	2990011463911	15434	3026993	TURBINE HOUSING M915A1 ONLY	1

END OF FIGURE

4 — 5
thru
17




Figure 28. Solenoid Valve.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 0306 TANKS, LINES, FITTINGS AND HEADERS	
					FIG. 28 SOLENOID VALVE	
1	PAOZZ	5305005098106	15434	S189C	SCREW, CAP, SOCKET HE	2
2	PAFZZ	5310004841718	15434	181466	WASHER, LOCK	2
3	PAFZZ	5310002622986	15434	67684	WASHER, FLAT	2
4	PAFZZ	4810011874925	15434	3035362	VALVE, SOLENOID	1
5	PAFZZ	5305001389848	15434	187556	.SCREW, MACHINE SOLENOID MOUNTING	4
6	PAFZZ	2910000857436	15434	134074	.COIL ASSEMBLY, SHUT M915	1
6	PAFZZ	2920011218859	15434	302109000	.COIL, ELECTRICAL	1
7	PAFZZ	5340000847787	15434	129839	.COVER, ACCESS SHUT OFF VALVE	1
8	PCFZZ	5331000819299	15434	129888	.O-RING RECTANGULAR RING PART OF	1
9	PAFZZ	5310000821888	15434	129768	KIT P/N 3010242	
10	PCFZZ	5331001320274	15434	190876	.WASHER, SPRING TENSIS SHUT OFF VALVE.....	1
11	PAFZZ	4820011461048	15434	3030970	.O-RING PART OF KIT P/N 3010242	1
12	PAFZZ	3040010852616	15434	3000266	.DISK, VALVE	1
13	PAFZZ	4730000113175	15434	70295	.SHAFT, SHOULDERED SHUT OFF VALVE,	1
14	PAFZZ	4820008295600	15434	129826	.PLUG, PIPE	1
15	PAFZZ	5355000821189	15434	129838	.BODY, VALVE	1
16	PAFZZ	5310009222017	30379	120217	.KNOB SHUT OFF VALVE	1
17	PCFZZ	5330009513538	15434	154087	.WASHER, LOCK	4
					GASKET RECTANGULAR RING PART OF KIT.....	1
					P/N 3010242.....	

END OF FIGURE




Figure 29. Fuel Pump Front Cover, Governor, and Tach Drive.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 0308 ENGINE SPEED GOVERNOR AND CONTROL	
					FIG. 29 FUEL PUMP FRONT COVER, GOVERNOR, AND TACH DRIVE	
1	PAHZZ	6680010852870	15434	3030267	COVER AND TACHOMETE M915 ONLY	1
1	PAHHH	2910011461999	15434	3030269	COVER ASSEMBLY, FRON FUEL PUMP	1
					FRONT, M915A1 ONLY	
2	PFFZZ	5342010854153	15434	3001296	.BRACKET, AIR COMPRES	1
3	PAFZZ	5310002090965	96906	MS35338-47	.WASHER, LOCK COVER, GOVERNOR AND	4
					TACHOMETER DRIVE	
4	XBFZZ		15434	S151	.SCREW COVER, GOVERNOR AND	4
					TACHOMETER DRIVE	
5	PAFZZ	5310011124307	15434	69324	.WASHER, FLAT COVER, GOVERNOR AN	1
					.TACHOMETER DRIVE	
6	PAHZZ	5310007278353	15434	144179	.WASHER, FLAT	1
7	PAFZZ	5305011131179	15434	206326	.SCREW, CAP, HEXAGON H	1
8	PAHZZ	2910010867715	15434	3002110	.HOUSING, DRIVE ASSEM	1
9	PAHZZ	3040010852871	15434	212607	.SHAFT, TACHOMETER DR M915 ONLY	1
9	PAHZZ	3040011519348	15434	216908	.SHAFT, TACHOMETER DR M915A1 ONLY	1
10	PCHZZ	5330010728828	15434	212603	.SEAL PART OF KIT P/N 3010242	1
11	PAHZZ	5365011263334	15434	3004724	.SPACER	1
12	PAHZZ	3120010872539	15434	212609	.BEARING, SLEEVE	1
13	PAHZZ	3020010868780	15434	212610	.GEAR, HELICAL	1
14	PAHZZ	3010010885727	15434	212639	.COUPLING, SHAFT, RIGI	1
15	PAHZZ	3020010709003	15434	212605	.GEAR, FUEL PUMP DRIV	1
16	PAHZZ	5325010810662	15434	212604	.RING, RETAINING	1
17	PAHZZ	3110005165289	15434	S-16052	.BEARING, BALL, ANNULA	1
18	PAHZZ	3120009049595	15434	163944	.BUSHING, SLEEVE	1
19	PAHZZ	6680010852870	15434	3030267	.COVER AND TACHOMETE M915 ONLY	1
19	PAHZZ	2910011414337	15434	3028368	.HOUSING, FUEL PUMP M915A1 ONLY	1
20	PAHZZ	5305010728831	15434	203619	.SCREW M915 ONLY	8
20	PAHZZ	5305011129110	15434	3017051	.SCREW, CAP, HEXAGON H M915A1 ONLY	8
21	XDHZZ		15434	3045173	.SEAL, OIL PART OF KIT P/N 3010242	2
22	PAHZZ	3040010709004	15434	212601	.SHAFT, SHOULDERED	1
23	PAHZZ	5315010870534	15434	212668	.KEY, MACHINE	1
24	PAHZZ	3020010864158	15434	212602	.GEAR, HELICAL	1
25	PAHZZ	3010010801529	15434	212613	.COUPLING HALF, SHAFT	1
26	PAHZZ	5310008093078	15434	146160	.WASHER, FLAT M915A1 ONLY	1
26	PAFZZ	5310008093078	96906	MS27183-11	.WASHER, FLAT M915 ONLY	2
27	PAHZZ	5305011149279	15434	S110	.SCREW, CAP, HEXAGON H 5/16-18 X 5/8.	1
28	PAHZZ	5310004079566	96906	MS35338-45	.WASHER, LOCK	1
29	PAFZZ	3010004479799	15434	162426	.INSERT, FLEXIBLE COU	1
30	PCHZZ	5330004710370	15434	200817	.GASKET	1
31	PCHZZ	5330005064866	15434	100764	GASKET PART OF KIT P/N 3010242	1
32	PAHZZ	5315000820448	15434	144178	PIN, SHOULDER, HEADLE	1
33	PAHZZ	5310000867859	15434	144179	SHIM, WEIGHT ASSIST	1
34	PAHZZ	5360010953661	15434	143848	SPRING, HELICAL, COMP	1
35	PAHZZ	2910010909346	15434	3024991	CARRIER ASSEMBLY	1
36	PAHZZ	5305011129110	15434	3017051	SCREW, CAP, HEXAGON H	3
37	PAHZZ	5310001411795	88044	AN960-416	WASHER, FLAT	4
38	PBHZZ	2910008583522	15434	44678	COVER, SPRING PACK	1

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
39	PAHZZ	5330010728830	15434	3003156	SEAL, SPECIAL	2
40	PAHZZ	5342011436046	15434	3025459	PLUG, COVER	1
41	PAHZZ	5305011261128	15434	3017052	SCREW, CAP, HEXAGON H M915A1 ONLY	1
41	PAHZZ	5305004264142	15434	S105	SCREW, CAP, HEXAGON H M915 ONLY	1
42	PCHZZ	5330005621176	15434	70705	GASKET PART OF KIT P/N 3010242	1
43	PAHZZ	5325008072636	96906	MS16625-1100	RING, RETAINING	1
44	PAHZZ	5340008981497	15434	70713	RING, RETAINING	1
45	PAHZZ	5365005073261	15434	70717A	SHIM	V
45	PAHZZ	5365005073261	15434	70717-A	SHIM	V
45	PAHZZ	5365005073262	15434	70717-B	SHIM	V
45	PAHZZ	5365004624504	15434	189800	SHIM	V
46	PAHZZ	5365005073260	15434	70717	SPACER, RING	1
47	PAHZZ	5360004615738	15434	143251	SPRING, HELICAL, COMP M915 ONLY	1
47	PAHZZ	5360009019644	15434	143253	SPRING, HELICAL, COMP M915A1 ONLY	1
48	PAHZZ	5340009078964	15434	137370	PLUNGER, DETENT IDLE SPRING	1
49	PAHZZ	2910008032631	15434	BM70796	SPRING GUIDE, ASSEMB	1
50	PAHZZ	5360011474846	15434	3018767	.SPRING, HELICAL, COMP	1
51	PAHZZ	5310005073259	15434	70715	.WASHER, FLAT	1
52	PAHZZ	2910001320769	15434	3038218	.GUIDE, CLIP	1
53	PAHZZ	5305005065722	15434	70716	.SETSCREW, IDLE ADJUS	1

END OF FIGURE




Figure 30. Fuel Pump Damper, Head, and Fuel Filter.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0309 FUEL FILTER						
FIG. 30 FUEL PUMP DAMPER, HEAD, AND FUEL FILTER						
1	PAFFF	2910010852570	15434	3026198	DAMPER AND HEAD ASSE	1
2	PAFZZ	5305000680509	96906	MS90728-10	.SCREW, CAP, HEXAGON H M915 ONLY	2
2	PAFZZ	5305011129110	15434	3017051	.SCREW, CAP, HEXAGON H M915A1 ONLY	2
3	PAFZZ	5310004841718	15434	181466	.WASHER, LOCK	4
4	XAFZZ		15434	215787	.HEAD, FILTER	2
5	PAFZZ	5305002072715	15434	S174C	.SCREW, CAP, SOCKET HE	2
6	PCFZZ	5331008093276	15434	139988	.O-RING RECTANGULAR RING PART OF	1
					KIT P/N 3010242	
7	PCFZZ	5340009513536	15434	202897	.DISK, SOLID, PLAIN FUEL PUMP DAMPER.....	1
8	PCFZZ	5331008092667	15434	100099	.O-RING RECTANGULAR RING PART OF	1
					KIT P/N 3010242	
9	PAFZZ	5365009650870	15434	160514	.SPACER, RING	1
10	PAFZZ	5340008295617	15434	153338	.COVER, ACCESS	1
11	PAFZZ	5305011332060	15434	133538	.SCREW, CAP, SOCKET HE	1
12	PAFZZ	5310001596209	96906	MS122032	.WASHER, LOCK	2
13	PAFZZ	5310001411795	88044	AN960-416	.WASHER, FLAT	2
14	PAFZZ	5305011478726	15434	153346	.SCREW, CAP, SOCKET HE	1
15	PAFZZ	4730011243762	15434	3025460	.PLUG, PIPE	1
16	PCFZZ	5330002528888	16954	691-10014	.GASKET RECTANGULAR RING PART OF	1
					KIT P/N 3010242	
17	PAOZZ	2910011461099	33457	FS1212	FILTER ELEMENT, FLUI M915A1 ONLY.....	1
17	PAOZZ	2910003043427	15434	BM78793	FILTER ELEMENT, FLUI M915 ONLY	1
18	PCOZZ	5330010849068	15434	213079	.PACKING, PREFORMED DAMPER, FUEL	1
					FILTER, M915 ONLY	
18	PCOZZ	5330002860487	33457	255622	.PACKING, PREFORMED M915A1 ONLY	1
19	PAFZZ	4730011064700	15434	129866	ADAPTER, STRAIGHT, TU	1
20	PAFZZ		15434	AR12228	FITTING FUEL INLET	1

END OF FIGURE

- | | |
|---|-----------------|
| 1 | 2
thru
18 |
| 2 | 3 |
| 4 | 5
and
6 |




Figure 31. Ether Quick-Start Kit.


SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0311 WHEEL ASSEMBLY						
FIG. 31 ETHER QUICK-START KIT						
1	PFOOO	2815010874740	06991	8294151	QUICK START KIT ENGINE, SUPPRESSED	1
2	PAOZZ	2910006469727	53203	20000	.CYLINDER, ENGINE STA.....	1
3	PCOZZ	5330011478754	06991	111025	..GASKET	1
4	PAOZZ	2910010840243	6Y402	829-4151	.PARTS KIT, ETHER, STA ASSEMBLY	1
5	PAOZZ	5340011451181	06991	913020	..CLAMP, LOOP	1
6	PAOZZ	4730011461059	06991	125049	..ELBOW, PIPE TO TUBE	1
7	PAOZZ	5310011466150	06991	103031	.WASHER, FLAT	2
8	PAOZZ	5310011466147	06991	102030	.NUT, PLAIN, HEXAGON 5/16-18	1
9	PCOZZ	4720011464126	06991	501096-04	.TUBING, NONMETALLIC 24 INCHES	1
10	PAOZZ	5930012950912	6Y402	8293635	.SWITCH, THERMOSTATIC M915 ONLY	1
10	PAOZZ	5930010959823	06991	309015	.SWITCH, PUSH ETHER START, SEE TM9- 2320-283-20P, M915A1 ONLY	1
11	PAOZZ	7690010807335	34623	M-A162-20018	.MARKER, IDENTIFICATI M915A1 ONLY	1
11	PAOZZ	7690010807335	34623	M-A162-20018	.MARKER, IDENTIFICATI M915 ONLY	1
12	PAOZZ	5365011450760	06991	501088-02	.SPACER, SLEEVE	2
13	PAOZZ	5342011469816	06991	108289	.CLAMP	1
14	PAOZZ	5306011511023	06991	101037-05	.BOLT, MACHINE 5/16-18 X 1.00	1
15	PAOZZ	2910011125797	06991	913024-06	.ATOMIZER, QUICK STAR	1
16	PAOZZ	5310011467303	34623	MB362-20001	.WASHER, FLAT	2
17	PAOZZ	5306004182276	24617	272547	.BOLT, MACHINE 3/8-16 X 6 1/2	2
18	PAOZZ	5310006379541	96906	MS35338-46	.WASHER, LOCK	2
19	PAOZZ	5310013123859	24617	9422273	NUT, SELF-LOCKING, CA	1
20	PAOZZ	5305010979886	24617	9419002	SCREW, CAP, HEXAGON H	2
21	PAOZZ	5310011023270	24617	2436161	WASHER, FLAT	1
22	PAOZZ	5340008091490	96906	MS21333-98	CLAMP, LOOP	1

END OF FIGURE

- 1 — 2 thru 10
- 11 — 12 thru 18



* a PART OF ITEM 12

Figure 32. Fuel Control Lever.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 0312 ACCELERATOR, THROTTLE OR CHOKE CONTROLS	
					FIG. 32 FUEL CONTROL LEVER	
1	PAOZZ	2910011462000	15434	218867	LEVER ASSEMBLY, THRO FUEL CONTROL	1
2	PAOZZ	2910004102268	34623	MA207-21-642	.STOP, THROTTLE LEVER	1
3	PAOZZ	5360004367340	15434	173717	.SPRING, HELICAL, TORS	1
4	XDOZZ		15434	173709	.LINK, THROTTLE LEVER	1
5	PAOZZ	5305004933959	15434	S-159-B	.SCREW, CAP, HEXAGON H 1/4-28 X 1 1/2	1
6	PAOZZ	5310005626552	15434	S600	.WASHER, LOCK	2
7	PAOZZ	2930003539164	15434	S2876	.WASHER, FLAT M915 ONLY	1
8	PAOZZ	5310000114492	15434	S251	.NUT, PLAIN, HEXAGON.....	1
9	PAOZZ	3120004933913	15434	166485	.SWIVEL, THROTTLE LEV	1
10	XDOZZ		15434	173708	.LEVER, THROTTLE	1
11	PAOZZ	2910004321945	15434	AR51323	LEVER, REMOTE CONTROL	1
12	PAOZZ	5310009717989	15434	MS35691-5	.NUT, PLAIN, HEXAGON	1
13	PAOZZ	5310001596209	15434	MS122032	.WASHER, LOCK	1
14	PAOZZ	5310001411795	15434	AN960416	.WASHER, FLAT	1
15	PBOZZ	5340012089319	34623	MB70-20107	.BRACKET, ACCELERATOR.....	1
16	PAOZZ	5310011027356	29617	9421077	.NUT, PLAIN	1
17	PAOZZ	5305010886019	15434	3010596	.SCREW, ASSEMBLED, WAS	1
18	PAOZZ	5306011023599	29617	9421196	.BOLT, MACHINE	1

END OF FIGURE

5 — 6
thru
20




Figure 33. Thermostat Housing, Water Manifold, and Component Parts.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 05 COOLING SYSTEM						
GROUP 0503 WATER MANIFOLD, HEADERS THERMOSTATS, AND HOUSING GASKET						
FIG. 33 THERMOSTAT HOUSING, WATER MANIFOLD, AND COMPONENT PARTS						
1	PAOZZ	2930009283595	15434	130118	MANIFOLD, FLUID COOL WATER	1
2	PCOZZ	5331005064874	15434	70624	O-RING PART OF KIT P/N 3804280 PART	4
					OF KIT P/N 3804275	
3	PAOZZ	2815010832123	15434	215042	MANIFOLD, WATER M915 ONLY	1
3	PAOZZ	2930011464212	15434	3015114	MANIFOLD, FLUID COOL M915A1 ONLY	1
4	PAOZZ	4820012109571	15434	214345	COCK, DRAIN	1
5	PBOZZ	2930010853579	15434	AR10124	HOUSING ASSEMBLY, TH	1
6	PFOZZ	5330010402087	15434	208128	.GASKET THERMOSTAT HOUSING PART OF.....	1
					KIT P/N 3804280 PART OF KIT P/N	
					3804275	
7	PAOZZ	6685010472811	15434	204586	.THERMOSTAT, FLOW CON M915 ONLY	1
7	PAOZZ	6685011410907	15434	201737	.THERMOSTAT, FLOW CON M915A1 ONLY	1
8	PAOZZ	5330008645422	15434	186780	.SEAL, THERMO	1
9	PAOZZ	5305010858197	15434	3010595	.SCREW, MACHINE	2
10	XDOZZ		15434	3018764	.ELBOW, FLANGED TO BOSS M915 ONLY	1
10	PAOZZ	2930011461085	15434	3018764	.WATER OUTLET, ENGINE WATER OUTLET,	1
					M915A1 ONLY.....	
11	PFOZZ	5330011455380	15434	3019158	.GASKET PART OF KIT P/N 3084280.....	1
12	PAOZZ	2930010846011	15434	211435	.WATER OUTLET, ENGINE M915 ONLY	1
12	PFOZZ	2930011507596	15434	3017748	.WATER OUTLET, ENGINE M915A1 ONLY	1
13	PAOZZ	4730010854156	15434	196282	.ELBOW, FLANGE TO HOS M915 ONLY	1
13	PAOZZ	4730011461060	15434	S-932-B	.ADAPTER, STRAIGHT, PI M915A1 ONLY	1
14	PAOZZ	5305010867036	15434	3010597	.SCREW WITH CAPTIVE WASHER, 3/8-16	4
					X3-3/4	
15	PAOZZ	4730009098627	96906	MS35842-13	.CLAMP, HOSE	2
16	PAOZZ	4710010793198	15434	213485	.TUBE, BENT, METALLIC M915 ONLY	1
16	PAOZZ	4710011461054	15434	3018098	.TUBE, BENT, METALLIC M915A1 ONLY	1
17	PCOZZ	5331001591464	15434	43463-A	O-RING PART OF KIT P/N 3804280	1
18	PAOZZ	5340011357250	15434	214617	.CLAMP, RIM CLENCHING	1
19	PAOZZ	5306011198870	15434	3022589	.BOLT, MACHINE	1
20	PCOZZ	4720010856129	15434	102522	.HOSE, NONMETALLIC.....	1
21	PCOZZ	5330011467314	15434	3024960	GASKET WATER CONNECTION PART OF KIT.....	1
					P/N 3801235.....	
22	PAOZZ	5305010858197	15434	3010595	SCREW, MACHINE	4
23	PAOZZ	2815010793317	15434	216467	CONNECTION, WATER TR M915 ONLY	1
23	PAOZZ	2930011463033	15434	3028281	HOUSING, WATER INLET WATER PUMP TO	1
					RADIATOR, M915A1 ONLY	
24	PAOZZ	5305011149279	15434	S110	SCREW, CAP, HEXAGON H M915 ONLY	1
24	PAOZZ	5305011130408	15434	3012470	SCREW, ASSEMBLED WAS M915A1 ONLY	2
25	PAOZZ	5310000814219	96906	MS27183-12	WASHER, FLAT M915A1 ONLY	2
25	PAOZZ	5310004079566	96906	MS35338-45	WASHER, LOCK M915 ONLY.....	1
26	PCOZZ	5331010775228	15434	212161	O-RING M915A1 ONLY PART OF KIT P/N.....	2
					3804280	
27	PAOZZ	4710011463086	15434	3024666	TUBE, BENT, METALLIC	1

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
28	PAOZZ	4730004042906	15434	130394	COUPLING, MANIFOLD	2
29	PCOZZ	5330001438369	15434	148203	GASKET M915 ONLY PART OF KIT P/N	6
					3804280	
29	PCOZZ	5330011455381	15434	3024709	GASKET M915A1 ONLY PART OF KIT P/N	6
					3804280 PART OF KIT P/N 3804275	
30	PAOZZ	4730002212139	96906	MS20913-4S	PLUG, PIPE M915 ONLY	2
30	PAOZZ	4730011472223	15434	3008468	PLUG, PIPE M915A1 ONLY	1
31	PAOZZ	2930010878749	15434	3013000	MANIFOLD, FLUID COOL	1
32	PAOZZ	5305010886019	15434	3010596	SCREW, ASSEMBLED 3/8-16X1-1/4	5

END OF FIGURE





Figure 34. Water Filter and Component Parts.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 0503 WATER MANIFOLD, HEADERS THERMOSTATS AND HOUSING GASKET	
					FIG. 34 WATER FILTER AND COMPONENT PARTS	
1	PAOZZ	5305010886019	15434	3010596	SCREW, ASSEMBLED WAS HEXAGON HEAD.....	4
					WITH CAPTIVE WASHER, 3/8-16 X 1-1/4.	
2	PAOZZ	5340011451597	15434	211448	BRACKET, ANGLE FILTER MOUNTING,	1
					M915A1 ONLY.....	
2	PAOZZ	5340011451597	34623	5730758	BRACKET, ANGLE M915 ONLY PART OF KIT	1
					P/N 5739124.....	
3	PAOZZ	3120010796527	15434	109594	BEARING, SLEEVE	4
4	PAOZZ	4820010456080	15434	179901	VALVE, ANGLE M915A1 ONLY	2
4	PAOZZ	4820012277141	34623	5730765	VALVE, ANGLE M915 ONLY	2
5	PAOZZ	4730011650749	15434	70470	ELBOW, TUBE	2
6	PAOZZ	4730009083195	96906	MS35842-10	CLAMP, HOSE M915 ONLY PART OF KIT.....	4
					P/N 5739124.....	
6	PAOZZ	4730011464016	15434	179904	CLAMP, HOSE M915A1 ONLY	4
7	MOOZZ		15434	179912.	HOSE M915A1 ONLY, MAKE FROM HOSE P/N	1
					2580-6, LENGTH TO SUIT	
7	MOOZZ		34623	5710454	HOSE M915 ONLY, MAKE FROM HOSE, P/N	1
					2580-6, LENGTH TO SUIT.....	
8	PAOZZ	4730010453083	15434	179903	ELBOW, PIPE TO HOSE M915A1 ONLY	1
8	PAOZZ	4730011650749	34623	5730761	ELBOW, TUBE M915 ONLY	1
9	PAOZZ	4330002744712	33457	3305367	FILTER ELEMENT, FLUI	1
10	PAOZZ	4330010203666	15434	204163	HEAD, FLUID FILTER M915A1 ONLY	1
10	PAOZZ	2940012277445	34623	5730769	HEAD, FLUID FILTER M915 ONLY PART OF	1
					KIT P/N 5739124	
11	PAOZZ	5305013199287	15434	3043649	SCREW, CAP, HEXAGON H	2
12	PAOZZ	4730009549510	03990	A3804	COUPLING HALF, QUICK M915A1 ONLY	1
13	MOOZZ		15434	179902	HOSE MAKE FROM HOSE, P/N 2580-6,	1
					LENGTH TO SUIT	

END OF FIGURE



* a PART OF ITEM 13

Figure 35. Water Pump and Idler.

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 0504 WATER PUMP						
FIG. 35 WATER PUMP AND IDLER						
1	PAOFF	2930011463912	15434	3801708	PUMP, COOLING SYSTEM BOTH M915 AND M915A1	1
2	PAFZZ	4320010793454	15434	3000888	.IMPELLER, PUMP, CENTR 4.50" DIA.	1
3	PCFZZ		15434	3071085	.PACKING WITH RETAIN	2
4	PAFZZ	4730000189566	15434	S-911-B	.PLUG, PIPE.....	2
5	PAFZZ	4730000103867	81348	WW-P-471AASBUC	.PLUG, PIPE M915 ONLY	1
5	PAFZZ	4730011615115	15434	3013786	.PLUG, PIPE M915A1 ONLY	1
6	PAFZZ	5330012401630	15434	3038997	.SEAL, PLAIN	1
7	PAFZZ	3040012879736	15434	3050394	.SHAFT, SHOULDERED	1
8	PAFZZ	3110001448828	24617	3305L1A	.BEARING, BALL, ANNULA	2
9	PAFZZ	5325004209696	15434	112302	.RING, RETAINING	1
10	PAFZZ	5365011321984	15434	196844	.SPACER	1
11	PAFZZ	2815008150355	15434	S16255	.RING, BEARING RETAIN	1
12	PCFZZ	5330010802992	15434	3038998	.SEAL, PLAIN ENCASED PART OF KIT P/N 3801235	1
13	PAFZZ	3020012416905	15434	302586100	.PULLEY, GROOVE 4-5/16 DIA. M915 ONLY	1
13	PAFZZ	3020010863417	15434	300550700	.PULLEY, GROOVE 4-11/16 DIA. BOTH M915 AND M915A1	1
14	PAFZZ	3120010836411	15434	203097	..BEARING, SLEEVE	1
15	PAOZZ	5305000586604	15434	182706	SCREW, CAP, HEXAGON H	1
16	PFOZZ	5330010665350	15434	3002385	GASKET PART OF KIT P/N 3801235	1
17	PAOZZ	5310007638920	96906	MS51967-20	NUT, PLAIN, HEXAGON.....	1
18	PAOZZ	5310011450762	15434	213082	WASHER, FLAT	1
19	PAOZZ	2930010969199	15434	3064919	IDLER ASSEMBLY, WATE	1
20	PCFZZ	5330010802992	15434	3038998	.SEAL, PLAIN ENCASED	1
21	PAFZZ	2815008150355	15434	S-16255	.RING, BEARING RETAIN	1
22	PAFZZ	5365010800409	15434	208120	.SPACER, SLEEVE	1
23	PCFZZ	5331010863991	15434	145506	.O-RING	1
24	PAFZZ	3110001448828	24617	3305L1A	.BEARING, BALL, ANNULA	1
25	PAFZZ	3040010793468	15434	208119	.SHAFT, SHOULDERED	1
26	PAFZZ	3020010794206	15434	215397	.PULLEY, GROOVE	1
27	PAFZZ	5365004042934	15434	S-965-E	.PLUG, MACHINE THREAD	1
28	PAOZZ	3030010659404	24161	K060436	BELT, V 45.50 INCHES LONG	1
29	PAOZZ	5305011294386	15434	3012468	SCREW, CAP, HEXAGON H WITH CAPTIVE WASHER, 3/8-24 X 2-1/4	5
30	PAHZZ	5330011467314	15434	3024960	GASKET PART OF KIT P/N 3801235	1
31	PAOZZ	5305011474035	15434	3012469	SCREW, CAP, HEXAGON H WITH CAPTIVE WASHER, 3/8-24 X 3-1/4	2
32	PAOZZ	5310002617340	15434	S604	WASHER, LOCK	7

END OF FIGURE

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 94 REPAIR KITS	
					GROUP 9401 REPAIR KITS	
					FIG. KIT	
PAFZF		2815009132074	15434	AR-73350	RING SET, PISTON.....	1
					RING, COMPRESSION, (1) 20-23	
					RING, PISTON (1) 20-22	
					RING, PISTON (1) 20-24	
PCHZZ		5330010750948	15434	3010242	GASKET SET FUEL PUMP GASKET.....	1
					GASKET (1) 24-8	
					GASKET (1) 25-2	
					GASKET (1) 25-13	
					GASKET (1) 29-31	
					GASKET (1) 29-42	
					GASKET (1) 28-17	
					GASKET (1) 30-16	
					O-RING (2) 24-14	
					O-RING (1) 24-52	
					O-RING (1) 28-8	
					O-RING (1) 28-10	
					O-RING (1) 30-6	
					O-RING (1) 30-8	
					PACKING, PREFORMED (2) 13-12	
					PACKING, PREFORMED (1) 24-19	
					PACKING, PREFORMED (1) 24-20	
					SEAL (1) 29-10	
					SEAL CAP (1) 24-32	
					SEAL, OIL (2) 29-21	
					SEAL, SPECIAL (1) 24-11	
PAHZZ		5330010924143	15434	3018762	GASKET SET M915 ONLY.....	1
					GASKET (1) 11-39	
					GASKET (3) 7-8	
					GASKET (1) 11-26	
					GASKET (1) 11-16	
					GASKET (1) 11-48	
					GASKET (1) 13-2	
					GASKET (2) 11-3	
					PACKING, PREFORMED (2) 11-29	
					PACKING, PREFORMED (1) 11-49	
					SPACER, RING (1) 11-24	
PAHZZ		4820011580555	15434	302112400	VALVE CHECK.....	1
					ADAPTER, STRAIGHT (1) 22-31	
					BODY, CHECK VALVE (1) 22-24	
					CLAMP (1) 22-28	
					CLAMP, HOSE (4) 22-23	
					HOSE (2) 22-10	
					SCREW, CAP, HEXAGON H (1) 22-27	
					SCREW, CAP, HEXAGON H (1) 22-29	
					TANK, AIR (1) 22-30	
					WASHER, PLAIN (2) 22-26	
					WASHER, LOCK (2) 22-25	
PAHZZ		3120011329339	15434	3801260	BEARING SET, SLEEVE STANDARD.....	1

KIT-1

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					BEARING HALF, SLEEVE (3)	4-17
					BEARING HALF, SLEEVE (3)	4-18
					BEARING HALF, SLEEVE (1)	4-19
					BEARING HALF, SLEEVE (3)	4-20
					BEARING HALF, SLEEVE (3)	4-21
					BEARING HALF, SLEEVE (2)	4-22
PAHZZ		2815011650765	15434	3801056	RING SET, PISTON	6
					RING, (6)	6-1
					RING, PISTON, (6)	6-4
					RING, PISTON (6)	6-3
					RING, PISTON (6)	6-2
PAHZZ		2990012710316	15434	3801096	PARTS KIT, SUPERCHAR M915A1 ONLY..... V	
					GASKET (1)	27-12
					NUT, SELF-LOCKING, HE (2)	27-5
					PACKING, PREFORMED (1)	27-11
					PACKING, FLAT FIBER (1)	27-15
					PLATE, DIFFUSER (1)	27-10
					SCREW, CAP, HEXAGON H (2)	27-9
					SEAL, TURBO (1)	27-2
					SEAL, PLAIN (2)	27-17
					WASHER, FLAT (4)	27-6
PAHZZ		2815011683742	15434	3801058	PISTON, INTERNAL COM.....	6
					PIN, PISTON (6)	6-7
					PISTON (6)	6-5
					RING, RETAINING (12)	6-6
					PLATE, DIFFUSER VANE (1)	27-10
PFHZZ		3120011552531	15434	3801106	BEARING SET, SLEEVE CAMSHAFT.....	1
					BEARING, SLEEVE (1)	2-30
					BUSHING, CAMSHAFT, (4)	2-30
					BUSHING, CAMSHAFT, (2)	2-30
PAHZZ		5330011509812	15434	3801235	GASKET AND SEAL SET M915A1 ONLY.....	1
					GASKET (1)	2-13
					GASKET (V)	4-1
					GASKET (3)	7-8
					GASKET (V)	7-8
					GASKET (V)	7-8
					GASKET (V)	7-8
					GASKET (V)	7-8
					GASKET (1)	10-22
					GASKET (1)	10-10
					GASKET (1)	10-9
					GASKET (1)	10-30
					GASKET (1)	12-1
					GASKET (1)	12-31
					GASKET (1)	13-2
					GASKET (1)	13-49
					GASKET (1)	13-34
					GASKET (1)	13-34
					GASKET (1)	16-11
					GASKET (1)	17-19
					GASKET (1)	33-21
					GASKET (1)	35-16
					GASKET AND SEAL SET (1)	35-30

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					O-RING (1) 2-39	
					O-RING (1) 10-5	
					O-RING (1) 10-23	
					O-RING (1) 10-18	
					O-RING (1) 13-47	
					O-RING (1) 16-5	
					SEAL (1) 4-4	
					SEAL (1) 4-10	
					SEAL, PLAIN ENCASED (1) 16-6	
					SEAL, PLAIN ENCASED (2) 35-12	
PCFZZ		2815011529219	15434	3804275	PARTS KIT, CYLINDER SINGLE HEAD	1
					GASKET.....	
					GASKET (3) 3-23	
					GASKET (3) 8-32	
					GASKET (1) 14-3	
					GASKET (3) 14-33	
					GASKET (1) 14-8	
					GASKET (6) 15-4	
					GASKET (3) 21-9	
					GASKET (1) 26-8	
					GASKET (1) 26-1	
					GASKET (6) 33-29	
					GASKET (1) 33-6	
					O-RING (12) 3-22	
					O-RING (4) 33-2	
					PACKING, PREFORMED (4) 14-7	
PCFZZ		5330010867790	15434	3804280	GASKET SET UPPER ENGINE GASKET, VALVE GRIND	
					GASKET (3) 3-23	
					GASKET (3) 8-32	
					GASKET (3) 14-33	
					GASKET (6) 15-4	
					GASKET (3) 21-9	
					GASKET (1) 26-8	
					GASKET (1) 26-1	
					GASKET (1) 33-11	
					GASKET (6) 33-29	
					GASKET (1) 33-6	
					O-RING (2) 3-6	
					O-RING (12) 3-22	
					O-RING (4) 33-2	
					O-RING (1) 33-17	
					O-RING (2) 33-26	
PAHZZ		2940011841877	34623	5739124	FILTER, FLUID	1
					BRACKET, ANGLE (1) 34-2	
					CLAMP, HOSE (4) 34-6	
					HEAD, FLUID FILTER (1) 34-10	

END OF FIGURE

SECTION II

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 95 GENERAL USE STANDARDIZED PARTS	
					GROUP 9501 BULK MATERIEL	
					FIG. BULK	
1	PCOZZ	4720005414243	24161	28430	HOSE, NONMETALLIC.....	V
2	PCOZZ	4720011147728	19207	8710557	HOSE, NONMETALLIC.....	V
3	PCOZZ	4720001874102	01276	2580-6	HOSE, NONMETALLIC	V

END OF FIGURE




Figure 36. Direct Support Special Tools-1.

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 26 SPECIAL TOOLS						
GROUP 2604 SPECIAL TOOLS						
FIG. 36 DIRECT SUPPORT SPECIAL TOOLS-1						
1	PEOZZ	6620011479954	15434	ST-1273	GAGE, PRESSURE, DIAL M915A2 ONLY PART OF KIT P/N 5704995.....	
2	PEOZZ	4910010976948	15434	ST-1225	MANDREL, SEAL, THERMO THERMOSTAT SEAL PART OF KIT P/N 5704990.....	
3	PEFZZ	5120008968097	15434	ST-419	FRONT SEAL ASSEMBLY PART OF KIT P/N 5704990	
4	PEFZZ	4910010981914	15434	ST-1242	PARTS KIT PUSHING D PART OF KIT P/N 5704990	
5	PEFZZ	4910011127509	15434	ST-1242-3	.TOOL, EMBEDDING BLOC.....	
6	PEFZZ	4910011131066	15434	ST-1242-2	.CUP, BUSHING DRIVER	
7	PEFZZ	5315011107835	15434	ST-1242-6	.PIN, COTTER	
8	PEFZZ	5120011192743	15434	ST-1242-4	.DRIVER, BEARING AND	
9	PEFZZ	4910010991487	15434	ST-1242-5	.KNOCK OUT RING TAPE	
10	PEFZZ	4910011174885	15434	ST-1242-7	.RING, KNOCK OUT	
11	PEFZZ	4910011182878	15434	ST-1242-8	.DRIVER, BEARING AND	
12	PEFZZ	4910011089130	15434	ST-1242-1	.MANDREL	
13	PEFZZ	5133009322089	15434	ST-788	CUTTING TOOL, BEAD PART OF KIT P/N 5704990	
14	PEFZZ	4910001505858	15434	3375425	EXTRACTOR, SLEEVE IN PART OF KIT P/N 5704990	
15	PEFZZ	5120009813108	15434	ST-1227	DRIVER PART OF KIT P/N 5704990.....	
16	PEFFZ	4910009813105	15434	ST-884	CUTTER, INJECTOR SLE PART OF KIT P/N 5704990	
17	PEFZA	4910010976957	15434	ST-884-1	.HOLDER	
18	PEFZA	4910010985088	15434	ST-884-3	.CUTTER PART.....	
19	PEFZA	4910010976958	15434	ST-884-6	.PILOT	
20	PEFFZ	3441009226699	15434	ST-880	EXPANDER, TUBE PART OF KIT P/N 5704990	
21	PEFZZ	5210010996339	15434	ST-880-1	.GAGE	
22	PEFZZ	4910010976955	15434	ST-880-2	.ROLL	
23	XAFZZ		15434	ST-880-3	.COLLAR	
24	PEFZZ	5310011044549	15434	ST-880-6	.NUT.....	
25	PEFZZ	4910010976956	15434	ST-880-7	.MANDREL	
26	PEFZZ	4910010859211	15434	3375150	CHECKING TOOL, BLOWB PART OF KIT P/N 5704990	
27	PEFZZ	5210009991209	15434	ST-560	GAGE, PISTON RING GR PART OF KIT P/N 5704990	
28	PEFZZ	5120001041795	15434	ST-1179	HOLDING TOOL, INJECT PART OF KIT P/N 5704990	

END OF FIGURE




Figure 37. Direct Support Special Tools-2.

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2604 DS SPECIAL TOOLS						
FIG. 37 DIRECT SUPPORT SPECIAL TOOLS-2						
1	PEOZZ	5120011608863	15434	3375049	WRENCH, OIL FILTER OIL AND FUEL FILTER, SPIN-ON PART OF KIT P/N 5704990	
2	PEFZZ	4910009991506	15434	ST-302	WISE, BALL JOINT PART OF KIT P/N 5704990	
3	PEFZZ	4910010976987	15434	ST-1114	FIXTURE BEARING PART OF KIT P/N 5704990	
4	PEFZZ	5120009991504	15434	ST-709	PULLER, MECHANICAL PART OF KIT P/N 5704990	
5	PEFZZ	4910010976930	15434	3375108	.PULLER BUSHING PART OF KIT P/N 5704990	
6	PEFZZ	4910010976989	15434	3375180	DRIVER WATER PUMP PART OF KIT P/N 5704990	
7	PEFZZ	5120010722952	15434	3376845	WRENCH, BOX AIR COMPRESSOR PART OF KIT P/N 5704990	
8	PEFFZ	5120001034687	15434	ST-669	ADAPTER, TORQUE WREN TORQUE WRENCH PART OF KIT P/N 5704990.....	
9	PEFZZ	5120002886514	15434	F-40A	.HANDLE, SOCKET WRENC	
10	PEFZZ	5120011226014	15434	ST-669-13	.SCREWDRIVER BIT.....	
11	PEFZZ	5120008650226	15434	TM-82	.BIT, SCREWDRIVER.....	
12	XAFZZ		15434	M-1302B-24	.SOCKET	
13	XAFZZ		15434	M1302B18	.SOCKET	
14	XAFZZ		15434	ST-6991	.DRIVER	
15	PEFZZ	4910010976988	15434	ST-1159	MANDREL, SEAL, SLEEVE SEAL-WEAR SLEEVE PART OF KIT P/N 5704990	
16	PEFZZ	4910010976972	15434	ST-1325	ATTACHMENT DIAL PART OF KIT P/N 5704990	

END OF FIGURE




Figure 38. Direct Support Special Tools-3.

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2604 SPECIAL TOOLS						
FIG. 38 DIRECT SUPPORT SPECIAL TOOLS-3						
1	PEFZZ	5120001135271	15434	ST-1244	PULLER, MECHANICAL PART OF KIT P/N 5704990	
2	PFFZZ	4910010976970	15434	3375825	.TIP EXTRACTOR	
3	PEFZZ	5120011203682	15434	3375616	.ROD, INJECTOR SLEEVE	
4	XAFZZ		15434	3375615	.COLLAR	
5	PEFZA	4910010976969	15434	3375614	.COLLAR FORMING	
6	PEFZZ	5365011037835	15434	ST-1244-9	.SPACER, RING	
7	XAFZZ		15434	ST-1244-1	.SUPPORT	
8	PEFZZ	3120011038752	15434	ST-1244-5	.BEARING, WASHER, THRU	
9	PEFZZ	5310011044550	15434	ST-1244-4	.NUT	
10	KFFZZ		15434	ST-1244-3	.NUT	
11	PEFZZ	5120010996341	15434	ST-1244-8	.HAMMER, HAND	
12	PEFZZ	4910010976971	15434	3375282	DRIVER VALVE GUIDE PART OF KIT P/N 5704990	
13	PEFFF	3460009991210	15434	ST-691	MANDREL SET, MACHINE PART OF KIT P/N 5704990	
14	XAFZZ		15434	ST-691-1	.MANDREL	
15	XAFZZ		15434	ST-691-2	.BLOCK	
16	XAFZZ		34623	MA326-21286	.MANDREL	
17	PEFZZ	4910010976986	15434	ST-658	MANDREL WATER PUMP PART OF KIT P/N 5704990	
18	PEFZZ	5120011564183	15434	3376326	PULLER, MECHANICAL PART OF KIT P/N 5704987	
19	PEFZZ	4910010976977	15434	ST-386-2	.ARBOR	
20	PEFZZ	5310010976978	15434	ST-386-3	.NUT, PLAIN, HEXAGON	
21	PEFZZ	4910010976984	15434	ST-386-11	.BALL THRUST BEARING	
22	PEFZZ	4910010976979	15434	ST-386-5	.SPACER	
23	PEFZZ	4910010976985	15434	3375205	.ADAPTER	
24	PEFZZ	4910010976983	15434	ST-386-10	.ADAPTER	
25	PEFZZ	4910010976982	15434	ST-386-9	.ADAPTER	
26	PEFZZ	4910010976981	15434	ST-386-8	.ADAPTER	
27	PEFZZ	4910010976980	15434	ST-386-6	.ADAPTER	
28	PEFZZ	4910001505797	15434	ST-633	HEAD, GUIDE, SPACER PART OF KIT P/N 5704990	
	PEFZZ	5180011419276	15434	5704990	TOOL KIT, GENERAL ME	

END OF FIGURE

3 — 4
thru
14






Figure 39. Direct Support Special Tools (Supplemental), (Sheet 1 of 2).

16 — 17
thru
20







Figure 39. Direct Support Special Tools (Supplemental), (Sheet 2 of 2).

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2604 SPECIAL TOOLS						
FIG. 39 DIRECT SUPPORT SPECIAL TOOLS (SUPPLEMENTAL)						
1	PEFZZ	4910007120537	15434	ST593	INDICATOR, ENGINE TI M915 ONLY PART	
2	PEFZZ	5110009807347	15434	ST-646	OF KIT P/N 5704993	
3	PEFZZ	5120001780948	15434	ST-1100	REAMER M915 ONLY PART OF KIT P/N.....	
4	PEFZZ	4910010976964	15434	ST-1100-10	5704993	
5	PEFZZ	5310010976961	15434	ST-1100-7	TOOL, GROOVING M915 ONLY PART OF KIT	
6	XAFZZ		15434	ST-1100-5	P/N 5704993	
7	XAFZZ		15434	ST-1100-1	.BODY M915 ONLY	
8	PEFZZ	4910010976962	15434	ST-1100-8	.NUT, PLAIN, KNURLED.....	
9	PEFZZ	4910010976960	15434	ST-1100-6	.NUT, PLAIN, KNURLED.....	
10	PEFZZ	4910010976965	15434	ST-1100-11	.BODY	
11	PEFZZ	4910010976963	15434	ST-1100-9	.SLEEVE ROD.....	
12	PEFZZ	4910010976968	15434	ST-1100-14	.CAPSCREW.....	
13	PEFZZ	5130010976967	15434	ST-1100-13	.ROD TOOL ADJUSTING	
14	PEFZA	4910010976966	15434	ST-1100-12	.SPRING ROD PART.....	
15	PEFZZ	4910010976976	15434	ST-1218	.CAP TOOL SETTING.....	
16	PEFZZ	5180009161813	15434	ST-249	.HONING UNIT, CYLINDR	
17	XAFZZ		15434	ST-249-4	.SPRING TOOL	
18	PEFZZ	5120011069174	15434	ST-249-3	MANDREL O RING PART OF KIT P/N	
19	PEFZZ	5120010973204	15434	ST-249-2	5704993	
20	PEFZZ	5120011069173	15434	ST-249-1	MANDREL-BLOCK, CAM F PART OF KIT P/N	
21	PEFZZ	5120001598916	15434	ST-659	5704993	
22	PEFZZ	5120008650933	93389	2304	.BLOCK	
	PEFZZ	5180010710707	19207	5704993	.SLEEVE, MANDREL.....	
					.MANDREL	
					.MANDREL	
					INSERTER, SEAL PART OF KIT P/N.....	
					5704993	
					REMOVAL TOOL, OIL FI PART OF KIT P/N.....	
					5704993	
					TOOL KIT, GENERAL ME.....	

END OF FIGURE




Figure 40. General Support Special Tools-1.

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2604 SPECIAL TOOLS						
FIG. 40 GENERAL SUPPORT SPECIAL TOOLS-1						
1	PEHZZ	5120009991505	15434	ST-835	INSERTER, PREFORMED PART OF KIT P/N 5704991	
2	PEHZZ	4910001505801	15434	ST-853	DRIVER, GOVERNOR, CYL PART OF KIT P/N..... 5704991	
3	PEHZZ	5120008968087	15434	ST-1032	INSERTER, SEAL PART OF KIT P/N..... 5704991	
4	PEFZZ	5120001505810	15434	ST-997	DRIVER, SEAL CRANKSH PART OF KIT P/N..... 5704991	
5	PEHZZ	4910010976915	15434	ST-997-6	.PINS	
6	PEHZZ	4910011183747	15434	3375204	THROTTLE SHAFT BALL PART OF KIT P/N..... 5704991	
7	PEHZZ	5180011028418	15434	3375189	TOOL KIT, FUEL PUMP PART OF KIT P/N..... 5704991	
8	PEHZZ	4910010976943	15434	3375148	.INSTALLING TOOL	
9	PEHZZ	4910010976940	15434	3375140	.TOOL AFC NO AIR ADJ	
10	PEHZZ	4910010976941	15434	3375146	.INSTALLING TOOL	
11	XAHZZ		15434	3375147	.FORMING TOOL	
12	PEHZA	4910010976939	15434	3375137	.TOOL AFC ADJUSTING	
13	PEHZZ	5120001507489	15434	ST1065	HOLDER, TOOL PART OF KIT P/N 5704991	
14	PEHHZ	5120000554013	15434	ST-1228	MANDREL, CAMSHAFT BU PART OF KIT P/N..... 5704991	
15	PEHZZ	4910010981917	15434	ST-1228-3	.MANDREL SHANK BUSHI PART OF KIT P/N 5704991	
16	PEHZZ	4910011006191	15434	ST-1228-9	.DRIVER PART OF KIT P/N ST-1228.....	
17	PEHZA	4910010976910	15434	ST-1228-13	.PULLEY ASSEMBLY BUS PART OF KIT P/N..... 5704991	
18	PEHZA	4910010981919	15434	ST-1228-5	.GUIDE BUSHING DRIVE	
19	PEHZZ	4910010976912	15434	3375154	.GUIDE	
20	PEHZA	4910010981918	15434	ST-1228-4	.SHAFT ASSEMBLY	
21	PEHZZ	4910010976911	15434	ST-1228-14	.ROLL PIN	
22	PEHZZ	4910010981916	15434	ST-1228-2	.ROD BUSHING DRIVER.....	
23	PEHZZ	4910010981915	15434	ST-1228-1	.HAMMER.....	
24	PEHZZ	4910001505805	15434	ST-984	ADJUSTING TOOL.....	
	PEHZZ	5120000554013	15434	ST-1228	MANDREL, CAMSHAFT BU.....	

END OF FIGURE




Figure 41. General Support Special Tools-2.

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2604 SPECIAL TOOLS						
FIG. 41 GENERAL SUPPORT SPECIAL TOOLS-2						
1	PEHZZ	5120001507488	15434	ST-1295	TOOL, COUNTERBORE PART OF KIT P/N 5704991	
2	PEHZZ	5120011205760	15434	ST-1059-17	TOOL BIT, COUNTER	
3	PEHZZ	5110009813107	15434	3376903	REAM FIXTURE PART OF KIT P/N 5704991	
4	PEHZZ	6625012325469	15434	3376619	PARTS KIT, GAGE TEST PART OF KIT P/N..... 5704991	
5	XDHZZ		15434	ST-1177	GAGE, CHECKING BAR, M PART OF KIT P/N..... 5704991	
6	PEHZZ	5220011686878	15434	ST-903	GAGE, RING, PLAIN PART OF KIT P/N..... 5704991	
7	PEHZZ	5120001041816	15434	3376669	CLAMP, CYLINDER LINE PART OF KIT P/N..... 5704991	

END OF FIGURE





Figure 42. General Support Special Tools-3.

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2604 SPECIAL TOOLS						
FIG. 42 GENERAL SUPPORT SPECIAL TOOLS-3						
1	PEHHH	4910011060492	15434	ST-1259	PULLER-INSTALLER PART OF KIT P/N	
2	PEHZZ	4910010976919	15434	ST-1259-4	5704991	
3	PEHZZ	4910010976916	15434	ST-1259-1	.TOOL SPACER RING	
4	PEHZA	4910010976917	15434	ST-1259-2	.PLATE TOP	
5	PEHZZ	5305010976918	15434	ST-1259-3	.TOOL SPACER RING	
6	PEHZZ	5305010981913	15434	ST-1259-7	.SETSCREW	
7	PEHZZ	5305010976920	15434	ST-1259-5	.SCREW, CAP, HEXAGON H.....	
8	PEHZZ	5305010976921	15434	ST-1259-6	.SETSCREW	
9	PEHZZ	4910010976926	15434	3375160	.SCREW, CAP, HEXAGON H.....	
10	PEHZZ	4910010976927	15434	3375165	FIXTORE TOP STOP PART OF KIT P/N	
11	PEHZZ	4910010976928	15434	3375166	5704991	
12	PEHZZ	5180010740019	15434	3376720	.TOOL ADJUSTING	
13	PEHZZ	4910010976936	15434	3375172	.WRENCH CROWSFOOT	
14	KFHZZ	4910010976937	15434	3375173	TOOL KIT, FUEL PUMP	
15	PEHZZ	4910010976938	15434	3375174	5704991	
16	PEHZZ	4910009991269	15434	3375522	.INSTALLING TOOL	
	PEHZZ	5180011419274	15434	5704991	.DRIVER MAIN SHAFT	
					.DRIVER FRONT COVER	
					TESTER, INTERNAL COM	
					TOOL KIT, GENERAL ME	

END OF FIGURE




Figure 43. General Support Special Tools-1 (Supplemental).

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2604 SPECIAL TOOLS						
FIG. 43 GENERAL SUPPORT SPECIAL TOOLS-1 (SUPPLEMENTAL)						
1	PEHHH		15434	ST-1168	BORING TOOL LINER COUNTER BORE	
					PART OF KIT P/N 5704994.....	
2	PEHZZ	3120010850762	15434	ST-1168-4	.BEARING, DRIVE	
3	PEHZZ	5305010844596	15434	ST-1168-6	.SETSCREW	
4	PEHZZ	4910010850763	15434	ST-1168-3	.SHAFT, CHAIN DRIVE	
5	PEHZZ	3020010850761	15434	ST-1168-5	.SPROCKET WHEEL SEGM.....	
6	PEHZZ	3020010847007	15434	ST-1168-7	.CHAIN, ROLLER	
7	PEHZZ	3020010868269	15434	ST-1168-10	.SPROCKET, DRIVEN	
8	PEHZZ	4910010981912	15434	ST-1168-19	.TOOL BIT	
9	PEHZZ	4910010868268	15434	ST-1168-8	.SNAP RING, SHAFT	
10	PEHZZ	4910010887904	15434	ST-1168-9	.SNAP RING, BEARING	
11	PEHZZ	5120000651031	15434	ST-544	PULLER, MECHANICAL M915 ONLY PART OF.....	
					KIT P/N 5704994	
12	PEHZZ	4910010850765	15434	3376904	BORING TOOL, CYLINDE PART OF KIT P/N.....	
					5704994	
13	PEHZZ	5133010846008	15434	ST-1287-10	.TOOL BIT	
14	PEHZZ	4910010976914	15434	ST-1158	BUSHING MANDREL PART OF KIT P/N.....	
					5704994	
15	PEHZZ	5120011205759	15434	3375834	GEAR PULLER ASSEMBL PART OF KIT P/N.....	
					5704994	
16	PEHZZ	4910010976909	15434	3375839	.PULLER JAW PART OF KIT P/N 5704994	
17	PEHZZ	4910010850766	15434	ST-1318	CHAMFER TOOL, LOWER PART OF KIT P/N	
					5704994	
18	PEHZZ	5133010846009	15434	ST-1318-23	.BIT, LOWER LINER.....	

END OF FIGURE




Figure 44. General Support Special Tools-2 (Supplemental).

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2604 SPECIAL TOOLS						
FIG. 44 GENERAL SUPPORT SPECIAL TOOLS-2 (SUPPLEMENTAL)						
1	PEHZZ	4910011059165	15434	3375153	DRIVER PART OF KIT P/N 5704994	
2	PEHHH		15434	3375206	BUSHING TOOL LUBRICATION PUMPBODY	
3	PEHZZ	4910010850751	15434	3375223	COVER PART OF KIT P/N 5704994.....	
4	PEHZZ	4910010846979	15434	3375229	.GUIDE, BUSHING BORIN.....	
5	PEHZZ	4930010853728	15434	3375220	.DRIVE ADAPTER, BORTO.....	
6	PEHZZ	5355010977072	15434	3375228	.HOUSING, BORING	
7	PEHZZ	5355010970157	15434	3375227	.KNOB	
8	PEHZZ	4910010857269	15434	3375226	.DIAL, INDICATOR	
9	PEHZZ	4910010847222	15434	3375225	.BIT, BORING TOOL, BUS	
10	PEHZZ	4910010847221	15434	3375207	.CUTTER BIT, BORING M	
11	PEHZZ	5355010845323	15434	3375224	.CUTTER BIT, BORING M	
12	PEHZZ	4910010846977	15434	3375221	.KNOB	
13	PEHZZ	4910010846978	15434	3375222	.GUIDE, BUSHING BORIN.....	
14	PEHZZ	5120011203681	15434	3376177	.GUIDE, BUSHING	
15	PEHZZ	5120010722955	15434	ST-1090	TORQUE WRENCH, INJEC PART OF KIT P/N	
16	PEHZZ	5305010976924	15434	ST-1090-4	5704994	
17	XAHZZ		15434	3376197	.WRENCH, TORQUE.....	
18	PEHZZ	4910010976923	15434	ST-1090-3	.SET SCREW	
19	PEHZZ	4910010976925	15434	ST-1145	.SCREWDRIVER	
20	PEHHH	5120010976932	15434	ST-1326	.WRENCH ALLEN	
21	PEHZA	4910010976934	15434	ST-1326-2	TORQUING TOOL PART OF KIT P/N	
22	PEHZZ	4910010976933	15434	ST-1326-1	5704994	
23	PEHZZ	5330011071841	15434	3375015	PULLER SET, MECHANIC PART OF KIT P/N	
24	PEHZZ	4910010976944	15434	3375230	5704994	
25	PEHZZ	5120008968089	15434	ST-422	.COLLAR PART OF KIT P/N 5704994	
26	PEHZA	4910010976935	15434	3375014	.COLLET PART OF KIT P/N 5704994.....	
27	PEHZZ	4910000976931	15434	ST-1231	GASKET PART OF KIT P/N 5704994.....	
					INSTALLING TOOL PART OF KIT P/N.....	
					5704994	
					INSERTER, PREFORMED.....	
					ADAPTER PLATE FUEL PART OF KIT P/N	
					5704994	
					BLOCK WEIGHT	

END OF FIGURE

4 — 5
and
6




Figure 45. General Support Special Tools-3 (Supplemental).

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2604 SPECIAL TOOLS						
FIG. 45 GENERAL SUPPORT SPECIAL TOOLS-3 (SUPPLEMENTAL)						
1	PEHZZ	4910010976945	15434	3375271	MANDREL PART OF KIT P/N 5704994	
2	PEHZZ	4910010869766	15434	ST-608	TURBO SUPPORT BLOCK PART OF KIT P/N	
3	PEHZZ	5120001167625	15434	ST-1095	5704994	
4	PEHHH	5120000651031	15434	ST-544	SOCKET, SOCKET WRENC PART OF KIT P/N	
5	XAHZZ		15434	ST-544-2	5704994	
6	PEHZZ	5120011000135	15434	ST-544-1	PULLER ASSEMBLY PART OF KIT P/N	
7	PEHZZ	5120009230856	15434	ST-851	5740494	
8	PEHZZ	4910010740020	15434	3375855	.SCREW VALVE	
	ADHHH	5180011419274	19207	5704991	.REMOVER, BEARING AND	
	ADHHH	5180010696998	19207	5704994	HOLDER PART OF KIT P/N 5704994.....	
					TEMPLATE, FUEL PUMP PART OF KIT P/N.....	
					5704991	
					TOOL KIT, GENERAL ME.....	
					TOOL KIT, GENERAL ME	

END OF FIGURE




Figure 46. Direct and General Support Special Tools-1.

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2604 SPECIAL TOOLS						
FIG. 46 DIRECT AND GENERAL SUPPORT SPECIAL TOOLS-1						
1	PEFZZ	2815003622042	15434	ST-125	FIXTURE ENGINE LIFTING PART OF KIT P/N 5704987.....	
2	PEFZZ	4910003453708	15434	ST-257	INSERT KIT, VALVE SE PART OF KIT P/N..... 5704987	
3	PEFZZ	5120011457293	15434	ST-448	COMPRESSOR, VALVE SP PART OF KIT P/N..... 5704987	
4	PEFZZ	4920007119307	15434	ST583	FIXTURE, HOLDING, CYL PART OF KIT P/N 5704987	
5	PEHZZ	4910011509713	15434	3375455	BORING MACHINE, ENGI CYLINDER BLOCK..... COUNTERBORE	
6	PEFZZ	4910011598701	15434	ST-749	PLATE, MOUNTING, AIR AIR COMPRESSOR..... MOUNTING PART OF KIT P/N 5704987	
7	PEFZZ	5120011643265	15434	ST-1105	INSERTER AND REMOVE AIR COMPRESSOR	
8	PEFZZ	3460009991173	15434	ST-663	BUSHING PART OF KIT P/N 5704987	
9	PEFZZ	4910009991208	15434	ST662	ARBOR SET, VALVE GUI PART OF KIT P/N 5704987	
					CUTTER SET, COUNTERB PART OF KIT P/N..... 5704987	

END OF FIGURE




Figure 47. Direct Support Special Tools-2.

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2604 SPECIAL TOOLS						
FIG. 47 DIRECT SUPPORT SPECIAL TOOLS-2						
1	PAFZA	4910009250755	15434	ST824	DEP REPORTED STK-NO INJECTOR SEAT CUTTING PART OF KIT P/N 5704987.....	
2	PEFZZ	7920001683244	15434	ST-876	BRUSH, FUEL PASSAGE FUEL PASSAGE CLEANING PART OF KIT P/N 5704987	
3	PEFZZ	4910001505843	15434	ST-1122	DRIVER, VALVE, INSERT VALVE SEAT INSERT STAKING TOOL PART OF KIT P/N 5704987	
4	PEFZZ	4910001505844	15434	ST-1124	DRIVER, ASSEMBLY, INS VALVE SEAT INSERT STAKING TOOL PART OF KIT P/N 5704987	
5	PEFZZ	4910011612115	15434	ST-1173	MANDREL, SEAL PART OF KIT P/N 5704987	
6	PEFZZ	5120011608867	15434	ST-1191	INSERTER, SEAL PART OF KIT P/N 5704987	
7	PEFZZ	5120011282678	15434	3376663	PULLER, COUPLING PART OF KIT P/N 5704987	
8	PEFZZ	4910011282691	15434	ST-1257-A	TESTER, VALVE VAC VALVE VACUUM PART OF KIT P/N 5704987.....	
9	PEFZZ	5120011282679	15434	ST-1279	EXTRACTOR, VALVE, SEA VALVE SEAT PART OF KIT P/N 5704987.....	
10	PEFZZ	5120001167604	15434	3376872	PULLER, INJECTOR, DIE PART OF KIT P/N 5704987	

END OF FIGURE




Figure 48. Direct Support Special Tools-3.

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2406 SPECIAL TOOLS						
FIG. 48 DIRECT SUPPORT SPECIAL TOOLS-3						
1	PEFZZ	4910011424929	15434	3375182	TESTER VALVE SPRING PART OF KIT P/N 5704987	
2	PEFZZ	4910011432023	15434	3375192	EXPANSION PLUG DRIV 1 1/4 INCH PLUG PART OF KIT P/N 5704987	
3	PEFZZ	4910011433337	15434	3376816	EXPANSION PLUG DRIV EXPANSION PLUG, 1 INCH PLUG PART OF KIT P/N 5704987	
4	PEFZZ	4910011433336	15434	3376815	EXPANSION PLUG DRIV EXPANSION PLUG, 3/4 INCH PLUG PART OF KIT P/N 5704987	
5	PEFZZ	5120011553795	15434	3375265	PULLER, WATER PUMP I PART OF KIT P/N 5704987	
6	PEFZZ	5120011282675	15434	3375448	DRIVER, SEAL, WP PART OF KIT P/N 5704987	
7	PEFZZ	5210011572291	15434	3376050	INDICATOR, DIAL PART OF KIT P/N 5704987	
8	PEFZZ	5120011564183	15434	3376326	PULLER, MECHANICAL P.....	
9	PEFZZ	5130011558327	55719	SINL-200	SOCKET, SOCKET WRENC 5/8 INCH X 1/2 DRIVE PART OF KIT P/N 5704987	
10	PEFZZ	5120011631349	75078	011494	SOCKET, SOCKET WRENC SOLENOID VALVE PART OF KIT P/N 5704987.....	
11	PEFZZ	4910011654541	15434	3375151	EXPANDER, OIL SEAL PART OF KIT P/N 5704987	
	ADHHH		19207	5704987	TOOL KIT, GENERAL ME.....	

END OF FIGURE




Figure 49. General Support Special Tools-1.

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2504 SPECIAL TOOLS						
FIG. 49 GENERAL SUPPORT SPECIAL TOOLS-1						
1	PEHZZ	4910009777507	15434	ST-561	FIXTURE ASSEMBLY, CH CONNECTING ROD CHECKING PART OF KIT P/N 5704988.....	
2	PEHZZ	4910011467130	15434	ST-563	MANDREL PART OF KIT P/N 5704988	
3	PEHZZ	5120009991503	15434	ST-708	BURNISHER, AJDUSTABL PART OF KIT P/N 5704988	
4	PEHZZ	5120001507486	15434	ST-763	EXPANDER, PISTON RIN PISTON RING PART OF KIT P/N 5704988	
5	PEHZZ	4910011418388	15434	ST-1241	PLUNGER PROTUSION PLUNGER PROTRUSION CHECKING PART OF KIT P/N 5704988	
6	PEHZZ	4910001505819	15434	ST-1089	EXTENSION, INJECTOR PART OF KIT P/N 5704988	
7	PEHZZ	4910001505848	15434	ST-1134	EXTRACTOR, VALVE PIN DOWEL PIN PART OF KIT P/N 5704988.....	
8	PEHZZ	5120009991206	15434	ST-1229	DRIVER, CYLINDER LIN PART OF KIT P/N 5704988	

END OF FIGURE




Figure 50. General Support Special Tools-2.

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
GROUP 2604 SPECIAL TOOLS						
FIG. 50. GENERAL SUPPORT SPECIAL TOOLS-2						
1	PEHZZ	4910011477896	15434	ST-1261	CONVERSION KIT, INJE PART OF KIT P/N 5704988	
2	PEHZZ	4910011546406	15434	ST-1262	MASTER INJECTOR MASTER "K" PART OF KIT P/N 5704988	
3	PEHZZ	4910010821346	15434	ST-1298	STAND ASSEMBLY, INJE PART OF KIT P/N 5704988	
4	PEHZZ	5120011282758	15434	3375162	COMPRESSOR, PISTON R PISTON RING PART OF KIT P/N 5704988.....	
5	PEHZZ	6850001450255	15434	3375432	INSPECTION PENETRAN CRACK DETECTION PART OF KIT P/N 5704988	
6	PEHZZ	4910011656016	15434	3375601	GUIDE PIN, SPECIAL, C CONNECTING ROD GUIDE PART OF KIT P/N 5704988.....	
7	PEHZZ	4910011432034	15434	3375959	VALVE DRIVER PRESS PRESSURIZING VALVE PART OF KIT P/N 5704988.....	
8	PEHZZ	4910011522743	15434	3376011	FIXTURE, VALVE INSTA AFC PRESSURE VALVE PART OF KIT P/N 5704988.....	

END OF FIGURE




Figure 51. General Support Special Tools-3.

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
					GROUP 2604 SPECIAL TOOLS	
					FIG. 51 GENERAL SUPPORT SPECIAL TOOLS-3	
1	PEHZZ	5120011432032	15434	3376015	PULLER, CYLINDER CYLINDER LINER, UNIVERSAL PART OF KIT P/N 5704988	
2	PEHZZ	5210011573091	15434	3376220	GAGE BLOCK PART OF KIT P/N 5704988	
3	PEHZZ	5120011282688	15434	3375599	PULLER, AFC BARREL PART OF KIT P/N 5704988	
4	PEHZZ	5120010296861	15434	ST-990	INJECTOR, LEAKAGE DE INJECTOR LEAKAGE PART OF KIT P/N 5704988.....	
5	PEHHH	4910011289810	05083	MODEL CD3	CALIBRATOR, INJECTOR INJECTOR TEST PART OF KIT P/N 5704988.....	
6	PEHZZ	4910010976929	15434	3375232	WRENCH TORQUE PART OF KIT P/N 5704988	

END OF FIGURE




Figure 52. General Support Special Tools-4.

SECTION III

TM 9-2815-225-34&P

(1) ITEM NO	(2) SMR CODE	(3) NSN	(4) CAGEC	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODES (UOC)	(7) QTY
FIG. 52 GENERAL SUPPORT SPECIAL TOOLS-4						
1	PEHZZ	3465009991501	15434	ST-668	FIXTURE, HOLD-DOWN INJECTOR CUP SPRAY PART OF KIT P/N 5704988	
2	PEHZZ	4910011755215	15434	ST790-362	LINK, FUEL INJECTOR PART OF KIT P/N 5704988	
3	PEHZZ	4730011745944	15434	ST790-363	ORIFICE, FUEL INJECT PART OF KIT P/N 5704988	
4	PFHZZ	4910011698045	15434	ST-1254	INJECTOR, ADAPTER, PO PART OF KIT P/N 5704988	
5	PFHZZ ADHHH	5180011774415	33287 19207	J 33113 5704988	KIT, K-CAM PART OF KIT P/N 5704988..... TOOL KIT , GENERAL ME	

END OF FIGURE

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5330-00-003-1771	14	36	5360-00-079-1940	20	65
5330-00-005-0407	35	3	5310-00-080-6004	5	7
3120-00-005-0602	4	21		10	27
5330-00-005-0856	4	10		12	28
5330-00-005-0858	4	4		13	36
5310-00-005-6052	24	48		14	26
2815-00-005-7431	8	6	5310-00-081-4219	12	42
5360-00-009-9270	3	4		33	18
4730-00-010-3867	12	8	5310-00-081-8500	4	14
	16	13		5	14
	35	5	5331-00-081-9289	24	55
			5310-00-081-9292	17	27
4730-00-011-3175	28	13	5331-00-081-9299	28	8
5310-00-011-4492	32	8			
5310-00-011-6122	20	1	4730-00-081-9618	2	9
	23	2	5315-00-082-0448	24	59
2815-00-011-7786	2	1		29	32
5310-00-013-1245	31	21	5355-00-082-1189	28	15
5315-00-014-1195	2	18	5310-00-082-1882	2	21
5315-00-014-1244	25	4	5310-00-082-1888	28	9
5315-00-014-1284	5	22	5340-00-084-7787	28	7
4730-00-018-9566	2	27	2815-00-085-7434	3	10
	3	24	2910-00-085-7436	28	6
	5	23	2910-00-085-7442	3	7
	11	35	5340-00-087-7486	14	19
	14	40	3120-00-090-5504	4	19
	16	10	5305-00-091-4006	10	2
	17	31	5305-00-091-4009	5	13
	19	10	5120-00-103-4687	37	8
	35	4	5120-00-104-1795	36	30
5330-00-026-2931	17	19	5120-00-113-5271	38	1
4730-00-042-8988	10	6	5340-00-116-6767	20	74
	16	13	5120-00-116-7604	47	10
	24	30	5120-00-116-7625	45	3
5315-00-043-1787	13	22	2530-00-116-9953	20	75
4730-00-044-4715	12	10	5340-00-117-9102	20	72
5340-00-050-1600	2	15	4820-00-117-9103	20	66
5120-00-055-4013	40	14	5330-00-129-9389	20	31
4730-00-057-5555	10	7	5360-00-129-9415	20	44
5331-00-058-1767	2	5	5330-00-131-7072	20	13
5305-00-058-6604	35	15	2815-00-132-0240	3	10
5305-00-062-4378	3	17	5360-00-132-0245	21	7
5305-00-063-5043	24	66	5330-00-132-0247	21	15
5330-00-064-4399	2	3	5330-00-132-0248	11	49
5120-00-065-1031	43	11	5365-00-132-0273	6	9
5305-00-068-0502	26	12	5331-00-132-0274	28	10
5305-00-068-0509	30	2	5330-00-132-0276	21	8
5305-00-068-0511	10	31	2910-00-132-0769	29	52
	13	28	5340-00-132-3203	15	9
	13	35	5310-00-134-4168	5	17
	26	3	5310-00-134-4169	14	38
5305-00-071-2517	10	38	5310-00-134-4171	5	8

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5310-00-134-4171	11	46	5365-00-197-9327	11	24
5330-00-135-6382	16	6		12	11
5305-00-137-3269	13	28	4730-00-202-8470	13	42
4730-00-138-3906	19	15	4730-00-203-0549	2	14
5305-00-138-9848	28	5	5305-00-207-2715	30	5
5310-00-141-1795	25	14		30	5
	25	16	5340-00-208-2083	8	11
	29	37	5310-00-209-0965	12	35
	30	13		13	27
	32	14		16	21
5310-00-143-5722	20	64		20	33
5330-00-143-8369	33	29		29	3
5330-00-143-8376	13	34	3120-00-219-5461	4	23
5331-00-143-8485	3	22	4730-00-221-2139	2	19
3110-00-144-8828	35	8		33	30
	35	24	4310-00-225-0706	20	69
6850-00-145-0255	50	5	5306-00-225-8499	14	37
4910-00-150-5797	38	28	5305-00-225-8507	20	9
4910-00-150-5801	40	2	5305-00-226-4831	19	5
5120-00-150-5810	40	4	5305-00-230-1939	26	12
4910-00-150-5819	49	6	5315-00-238-0882	16	9
4910-00-150-5843	47	3	5340-00-238-5435	21	1
4910-00-150-5844	47	4	5330-00-246-0309	12	31
4910-00-150-5848	49	7	5325-00-256-2846	24	24
4910-00-150-5858	36	14		24	46
5120-00-150-7486	49	4	5310-00-261-7340	2	34
5120-00-150-7488	41	1		7	9
5120-00-150-7489	40	13		10	3
5120-00-150-7492	36	29		11	17
5331-00-159-1464	33	20		11	40
5310-00-159-6209	10	36		12	17
	14	13		12	22
	22	2		13	27
	30	12		14	13
	32	13		14	25
				22	2
5120-00-159-8916	39	21		35	32
3020-00-160-9092	17	20	5310-00-262-2986	28	3
5305-00-165-8157	11	41	5305-00-269-3240	5	2
7920-00-168-3244	47	2	4330-00-274-4712	34	9
5330-00-171-7267	2	32	5340-00-276-5847	2	31
5305-00-177-5552	11	18	4820-00-276-9041	10	35
5120-00-178-0948	39	3		11	12
4720-00-187-4102	34	12	4730-00-277-8269	20	80
	34	13			
	BULK	3			
5330-00-194-8385	26	8	4720-00-278-4890	12	14
2815-00-195-5894	8	12	4730-00-278-9200	22	23
2815-00-195-5897	8	16	5315-00-281-7610	2	7
5310-00-197-5304	2	29	5330-00-286-0487	30	18

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5120-00-288-6514	37	9	5365-00-428-6201	4	9
2805-00-293-9699	3	2	2910-00-432-1945	32	5
5305-00-297-4022	8	24		32	12
2910-00-304-3427	30	17	5360-00-436-7340	32	3
4730-00-338-6839	12	49	5331-00-441-0145	20	50
5305-00-339-1415	7	15	4730-00-444-1710	3	25
4910-00-345-3708	46	2		22	13
3120-00-349-6444	4	17	4820-00-445-0610	20	40
3120-00-353-9164	32	7	3010-00-447-9799	23	9
5310-00-356-1447	2	21		29	29
5330-00-361-2955	4	1	3040-00-449-7397	32	6
2815-00-362-2042	46	1	5310-00-451-6643	12	16
4730-00-365-2690	10	42		24	6
	19	12	5360-00-461-5738	29	47
	26	25	5365-00-462-4504	29	45
5365-00-369-4729	20	38	5310-00-469-3998	5	21
2815-00-369-7846	20	20	5310-00-470-6154	17	6
4730-00-374-4282	19	16	5330-00-471-0370	29	30
5340-00-400-3449	26	17	9905-00-473-7260	20	27
5342-00-400-5178	24	37	5315-00-475-2574	13	21
2930-00-401-9531	17	18	5305-00-477-0395	15	7
5310-00-403-7731	20	70	4730-00-477-4160	26	5
5330-00-403-9896	24	21	2990-00-477-6159	27	16
5305-00-404-1388	10	32	5305-00-477-6769	3	20
5305-00-404-1390	14	30	2815-00-480-4347	6	7
4730-00-404-2906	33	28	5310-00-484-1718	24	26
4730-00-404-2909	2	33		25	20
5330-00-404-2920	5	27		28	2
				30	3
5365-00-404-2934	35	27	2815-00-484-8359	2	25
5340-00-404-2940	8	10	2815-00-484-8360	2	23
5340-00-404-2944	7	1	5306-00-485-0790	25	7
5342-00-404-2946	1	5	5340-00-485-0945	7	12
2815-00-406-8936	13	45	5310-00-486-2505	14	25
5310-00-407-9566	12	41		22	3
	14	36	5310-00-486-2507	17	25
	19	6	5365-00-488-0799	2	40
	20	10	3120-00-493-3913	32	9
	29	28	5305-00-493-3959	32	5
	33	18	2815-00-505-5119	7	24
			5330-00-506-4866	29	31
3130-00-408-9041	2	24	5331-00-506-4874	33	2
2910-00-410-2268	32	2	5305-00-506-5722	29	53
5305-00-411-9340	27	9	5365-00-507-3224	24	64
5340-00-417-5800	12	27			
5306-00-418-2276	31	17	5365-00-507-3225	24	64
5331-00-420-9624	4	5			
5325-00-420-9696	35	9	5365-00-507-3254	16	4
3020-00-424-9995	7	2	5310-00-507-3259	29	51
5310-00-426-3990	3	18	5365-00-507-3260	29	46
5305-00-426-4142	13	31		29	46
	29	41	5365-00-507-3261	29	45
5305-00-426-4146	24	25			

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5365-00-507-3261	29	45	2590-00-590-7378	9	1
5365-00-507-3262	29	45	3120-00-593-1507	4	22
5365-00-507-3271	24	31	5360-00-597-4570	24	33
5305-00-509-8106	28	1	5365-00-598-5255	19	14
				19	18
3110-00-516-5289	29	17		26	21
			5330-00-599-2962	24	21
5310-00-521-8595	13	40	4730-00-602-3707	20	56
	14	23	5360-00-603-1518	20	73
	22	1	2530-00-603-1532	20	61
3020-00-528-5053	5	12	3120-00-627-6697	13	4
5315-00-532-9388	2	20		13	26
5330-00-537-2382	2	13	5340-00-632-6239	3	5
	11	3	5310-00-637-9541	10	39
5365-00-543-3744	24	64		12	47
				13	32
5305-00-543-4372	12	29		22	25
	12	32		31	18
	13	9	5305-00-638-8920	10	37
	13	48	2910-00-646-9727	31	2
	14	12	5310-00-650-0187	20	7
	14	24	5330-00-659-3178	15	4
5305-00-546-6698	2	35	3120-00-659-7808	7	17
	7	10	5360-00-664-5343	11	23
	12	23	5310-00-680-6874	27	5
4730-00-555-8263	14	1	3120-00-682-7706	27	13
	19	3	5310-00-684-3463	26	2
	19	3	3120-00-695-1232	4	20
	26	11	5365-00-695-1247	12	12
	26	17	3020-00-702-3882	25	11
4730-00-555-8292	24	30	2815-00-705-2856	13	14
5325-00-558-9412	24	18	5365-00-708-3434	11	14
5330-00-562-1176	29	42	4920-00-711-9307	46	4
5310-00-562-6557	13	36	5340-00-716-4975	24	44
5310-00-562-6552	32	6			
5310-00-562-6558	12	4	5365-00-716-5496	16	
	19	7	5340-00-719-4601	22	8
	20	11	5305-00-721-3698	25	21
5310-00-562-6560	10	40	5305-00-725-2317	10	26
	22	3		14	39
	24	3	5310-00-727-8353	24	60
	27	6		29	6
3120-00-566-0480	13	7	5310-00-732-0560	8	3
5330-00-567-3463	25	2		8	7
3040-00-567-4354	25	18		8	13
5310-00-584-5272	1	3		8	17
	5	20		8	21
	11	8	9905-00-733-7622	24	28
3120-00-589-3537	8	5	5340-00-738-7552	20	68
	8	15	5310-00-763-8920	35	17
	8	19	5340-00-767-4012	15	11
			2990-00-772-1778	24	63
	8	23	2815-00-772-9434	16	8

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
53Z5-00-777-3544	7	20	5120-00-865-0933	39	22
	7	26	5315-00-866-5015	3	8
5305-00-782-9489	10	29	3120-00-877-2213	16	2
2910-00-790-8736	24	34	5310-00-887-8325	15	8
3120-00-791-1440	7	23	5360-00-895-3216	20	39
2815-00-791-1453	11	22	5120-00-896-8087	40	3
3120-00-792-9834	17	32	5120-00-896-8097	36	3
5305-00-795-9336	4	13	5340-00-898-1497	29	44
	5	10	4730-00-900-3296	22	31
5305-00-795-9345	22	7	5360-00-901-9644	29	47
5305-00-795-9352	13	46	4310-00-903-7174	20	18
5340-00-799-0843	2	12	3120-00-904-9595	29	18
4730-00-801-8186	2	26	5331-00-905-2679	20	41
2910-00-803-2631	29	49	5340-00-907-8964	29	48
5306-00-804-2468	2	22	4730-00-908-3195	34	6
5325-00-804-2784	6	6	4820-00-909-4174	20	42
5305-00-804-6318	1	7	4820-00-909-4175	20	46
	20	28	4730-00-909-8627	33	15
	24	29	2815-00-913-2074	KIT	
5325-00-807-2636	29	43	5180-00-916-1813	39	16
5340-00-809-1490	31	22	4720-00-918-9634	19	2
5331-00-809-2667	30	8	2815-00-920-2073	15	3
5310-00-809-3078	29	26	5310-00-922-2017	28	16
	29	26	5307-00-922-2626	15	13
5331-00-809-3276	30	6		26	7
5310-00-809-4085	12	36	3441-00-922-6699	36	21
3120-00-810-6032	24	41	5325-00-922-9101	20	19
2815-00-815-0355	35	11	5120-00-923-0856	45	7
	35	21	4910-00-925-0755	47	1
5365-00-815-1137	21	13	2910-00-928-3505	3	21
5310-00-820-6653	12	17	2930-00-928-3595	33	1
	14	21	5133-00-932-2089	36	13
5310-00-823-8803	12	18	5340-00-933-3009	3	3
2530-00-827-5934	20	54	3040-00-933-3012	25	12
5310-00-828-4827	12	3	5331-00-941-3762	20	49
2815-00-828-7013	13	44	5305-00-942-2196	13	48
2815-00-829-5227	15	6	5305-00-944-8292	12	21
	18	16		14	20
4820-00-829-5600	28	14	5305-00-947-3437	8	4
5365-00-829-5604	24	63			
5340-00-829-5617	30	10		8	8
5340-00-839-0653	12	19		8	14
5305-00-839-6230	20	76		8	18
5315-00-844-0140	24	38		8	22
			5340-00-951-3536	30	7
5330-00-852-7347	20	15	5330-00-951-3538	28	17
5342-00-858-3507	22	4	4730-00-954-1281	2	10
2910-00-858-3522	29	38	4730-00-954-9510	34	12
5330-00-861-8592	8	32	3805-00-955-5320	20	45
5330-00-864-5422	33	8	5330-00-961-9470	24	32
5120-00-865-0226	37	11	2815-00-962-5623	3	12

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
4730-00-964-7548	20	30	5330-01-066-3904	14	7
5365-00-965-0870	30	9	5330-01-066-3910	13	2
5331-00-970-3461	24	14	5330-01-066-5349	7	8
5310-00-971-7989	24	43	5330-01-066-5350	35	16
	32	12	5330-01-066-5351	14	3
4910-00-977-7507	49	1	5330-01-066-5352	14	6
5110-00-980-7347	39	2	4720-01-070-8149	26	6
4910-00-981-3105	36	16	3020-01-070-9003	29	15
5110-00-981-3107	41	3	3040-01-070-9004	29	22
5120-00-981-3108	36	15	4820-01-070-9710	21	11
5331-00-984-3756	8	28	2910-01-070-9712	24	62
2815-00-994-4427	6	1	5120-01-072-2952	37	7
2815-00-994-4429	6	4	5120-01-072-2955	44	15
3460-00-999-1173	46	8	5331-01-072-4436	3	6
5120-00-999-1206	49	8	2930-01-072-8056	35	1
4910-00-999-1208	46	9	5305-01-072-8816	16	23
5210-00-999-1209	36	28	5305-01-072-8818	14	10
			5305-01-072-8826	24	53
3460-00-999-1210	38	13	5330-01-072-8828	29	10
3465-00-999-1501	52	1	5330-01-072-8830	24	11
5120-00-999-1503	49	3		29	39
5120-00-999-1504	37	4		29	44
5120-00-999-1505	40	1	5305-01-072-8831	29	20
4910-00-999-1506	37	2	5330-01-072-8982	24	19
5305-01-010-2362	13	9	5331-01-072-8983	24	45
3120-01-016-4883	20	26	5330-01-072-8998	26	1
2940-01-019-4513	10	33	5180-01-074-0019	42	12
	11	43	4910-01-074-0020	45	8
4330-01-020-3666	34	10	5330-01-075-0948	24	19
5305-01-028-8869	15	5		KIT	
5305-01-029-1193	22	5		KIT	
5120-01-029-6861	51	4	5310-01-075-0991	13	10
5305-01-032-2311	12	34	2910-01-076-8632	21	16
5360-01-038-4659	13	13	2815-01-077-1482	6	5
5330-01-040-2087	33	6	4730-01-077-2016	21	14
4730-01-045-3083	34	8	3020-01-077-2229	4	15
4820-01-045-6080	34	5	3020-01-077-4411	4	11
5330-01-046-1991	11	26	2815-01-077-4463	15	2
5330-01-046-3144	11	16	3040-01-077-4976	21	2
6685-01-047-2811	33	12	5331-01-077-5228	11	36
2815-01-048-6702	7	18		33	26
			4730-01-078-6364	24	58
5330-01-049-0466	2	4	2815-01-079-1632	4	12
5330-01-051-4243	13	12	3010-01-079-1788	13	30
5330-01-051-4243	24	20			
5310-01-056-1371	20	52	3040-01-079-1799	8	29
5315-01-058-4551	4	8	4710-01-079-3198	33	16
5330-01-060-9061	20	43	4820-01-079-3241	24	4
2910-01-065-3979	23	6	4730-01-079-3273	19	1
2940-01-065-7076	11	47	4730-01-079-3274	26	19
2930-01-065-7113	11	30	4720-01-079-3285	13	33
3030-01-065-9404	35	28	2815-01-079-3317	33	23
5340-01-066-2947	13	39	4310-01-079-3319	20	25

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
4820-01-079-3320	24	10	5305-01-084-4596	43	3
2815-01-079-3380	7	5	5355-01-084-5323	44	11
4320-01-079-3454	35	2	5133-01-084-6008	43	13
3010-01-079-3461	20	4	5133-01-084-6009	43	18
3040-01-079-3468	35	25	2930-01-084-6011	33	21
3040-01-079-3469	13	23	4910-01-084-6977	44	12
4710-01-079-3487	26	16	4910-01-084-6978	44	13
4710-01-079-3492	19	13	4910-01-084-6979	44	4
4710-01-079-3493	22	11	3020-01-084-7007	43	6
3020-01-079-4206	35	26	4310-01-084-7148	20	48
5342-01-079-4678	21	9	4910-01-084-7221	44	10
3120-01-079-5208	8	9	4910-01-084-7222	44	9
3120-01-079-5451	7	27	5325-01-084-9033	13	29
5315-01-079-6506	21	12	5360-01-084-9066	18	17
5330-01-079-6514	11	39	5330-01-084-9068	30	18
3120-01-079-6527	15	10	3020-01-084-9640	13	19
	34	3	4910-01-085-0751	44	3
5310-01-079-6529	21	6	3020-01-085-0761	43	5
5310-01-079-6708	21	17	3120-01-085-0762	43	2
5315-01-079-6740	4	16	4910-01-085-0763	43	4
3120-01-079-6823	2	30	4910-01-085-0764	43	11
	2	30	4910-01-085-0765	43	12
4310-01-079-6938	20	17	4910-01-085-0766	43	17
5306-01-079-7027	6	11	4720-01-085-1316	26	18
5305-01-079-7028	21	18	2815-01-085-1881	5	11
5340-01-079-8097	22	6	2815-01-085-2569	8	1
3110-01-079-8190	24	57	2910-01-085-2570	30	1
3120-01-079-8194	7	3	4720-01-085-2571	11	5
5365-01-079-8373	24	17	2815-01-085-2573	13	1
2815-01-079-9146	16	18	2815-01-085-2574	18	1
5365-01-080-0409	35	22	4140-01-085-2607	27	3
3010-01-080-1529	29	25	2815-01-085-2615	7	7
5330-01-080-2992	35	12	3040-01-085-2616	28	12
	35	20	2815-01-085-2618	3	15
2910-01-080-3149	24	49	3010-01-085-2732	17	26
				20	36
			6680-01-085-2870	29	1
3120-01-080-3275	24	36		29	19
5330-01-080-5021	3	23	3040-01-085-2871	29	9
2910-01-080-5570	24	63	5331-01-085-3105	18	6
7690-01-080-7335	31	11	2930-01-085-3579	33	5
	31	11	5330-01-085-3580	27	1
5325-01-081-0662	29	16	4930-01-085-3728	44	5
4910-01-082-1346	50	3	2815-01-085-3733	3	19
5330-01-082-6984	14	17	3020-01-085-3779	13	24
5330-01-082-6985	5	25	5342-01-085-4153	23	3
2815-01-083-2123	33	3		29	2
3120-01-083-6411	35	14	4730-01-085-4156	19	9
2910-01-084-0243	31	4		33	13
2815-01-084-3447	1	9	5940-01-085-4426	18	10

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5340-01-085-4439	18	16	5315-01-087-0534	29	23
2990-01-085-4768	27	8	5340-01-087-0681	3	9
2815-01-085-5190	7	6	5340-01-087-0682	3	13
2520-01-085-6128	18	13	3120-01-087-2539	29	12
4720-01-085-6129	33	20	3120-01-087-3004	6	12
4720-01-085-6131	14	11	2815-01-087-4740	31	1
4710-01-085-6132	14	35			
4710-01-085-6134	22	16	5325-01-087-8727	18	15
5340-01-085-6269	13	37	2930-01-087-8749	33	31
4720-01-085-6293	26	10	3010-01-088-5727	29	14
4910-01-085-7269	44	8	5305-01-088-6019	11	15
4730-01-085-7328	15	12		11	38
5305-01-085-8197	11	9		32	17
	12	29		33	29
	33	9		33	32
2815-01-085-8282	3	1		34	1
4910-01-085-9211	36	27	2815-01-088-7328	18	14
4710-01-085-9348	22	9	4910-01-088-7904	43	10
4710-01-085-9349	22	18	4810-01-089-0534	18	4
5331-01-086-1013	18	5	4820-01-089-3939	18	20
2835-01-086-1447	27	18	5360-01-089-9103	18	21
3040-01-086-1448	27	19	2520-01-090-4473	11	11
3040-01-086-1449	24	51	2910-01-090-9346	29	35
3040-01-086-1651	24	22			
3020-01-086-3417	35	13	5305-01-091-2498	17	5
5360-01-086-3480	20	47	2910-01-091-7507	24	47
5330-01-086-3523	14	33	4710-01-092-0109	12	44
2910-01-086-3974	21	10	5330-01-092-4143	KIT	
5331-01-086-3991	35	23	4310-01-092-9815	17	11
5330-01-086-3996	18	24	4310-01-092-9816	17	22
3020-01-086-4158	29	24	2530-01-093-0872	20	55
2815-01-086-4508	6	8	7690-01-094-6720	1	8
5330-01-086-6112	4	4	5360-01-095-3661	24	61
5306-01-086-6113	24	16			
5360-01-086-6114	24	65		29	34
5315-01-086-6187	7	4	5365-01-095-5666	17	9
5340-01-086-6193	3	14	4710-01-095-8683	19	13
5330-01-086-6196	18	7	5930-01-095-9823	31	10
5330-01-086-6197	11	29	2815-01-096-9198	8	2
5305-01-086-7036	11	42	2910-01-096-9200	25	3
	33	14	5120-01-097-3204	39	19
5305-01-086-7285	21	3	2930-01-097-6755	17	2
2910-01-086-7715	29	8	4910-01-097-6909	43	16
	29	8	4910-01-097-6910	40	17
5365-01-086-7788	16	4	4910-01-097-6911	40	21
5330-01-086-7790	KIT		4910-01-097-6912	40	19
	KIT			40	19
4910-01-086-8268	43	9	4910-01-097-6913	44	3
3020-01-086-8269	43	7	4910-01-097-6914	43	14
3020-01-086-8780	29	13	4910-01-097-6915	40	5
2910-01-086-9757	7	22	4910-01-097-6916	42	3
4910-01-086-9766	45	2	4910-01-097-6917	42	4

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5305-01-097-6918	42	5	4910-01-097-6984	38	21
4910-01-097-6919	42	2	4910-01-097-6985	38	23
5305-01-097-6920	42	7	4910-01-097-6986	38	17
5305-01-097-6921	42	8	4910-01-097-6987	37	3
4910-01-097-6923	44	18	4910-01-097-6988	37	15
5305-01-097-6924	44	16	4910-01-097-6989	37	6
4910-01-097-6925	44	19		38	2
4910-01-097-6926	42	9	5355-01-097-7072	44	6
4910-01-097-6927	42	10	5330-01-097-7791	20	77
4910-01-097-6928	42	11	5310-01-097-8039	20	78
4910-01-097-6929	51	6		20	78
			5305-01-097-9886	31	20
4910-01-097-6930	37	5	5342-01-098-0175	17	7
5120-01-097-6932	44	20	4910-01-098-1912	43	8
4910-01-097-6933	44	22	5305-01-098-1913	42	6
4910-01-097-6934	44	21	4910-01-098-1914	36	4
4910-01-097-6935	44	26	4910-01-098-1915	40	23
4910-01-097-6936	42	15	4910-01-098-1916	40	22
4910-01-097-6938	42	13	4910-01-098-1917	40	15
4910-01-097-6939	40	12	4910-01-098-1918	40	20
4910-01-097-6940	40	9	4910-01-098-1919	40	18
4910-01-097-6941	40	10	4910-01-098-5088	36	17
4910-01-097-6943	40	8	4320-01-098-5115	24	56
4910-01-097-6944	44	24	2910-01-098-5118	24	39
4910-01-097-6945	45	1	2815-01-098-6755	18	18
4910-01-097-6948	36	2		18	18
4910-01-097-6955	36	23	4910-01-099-1487	36	9
4910-01-097-6956	36	26	5210-01-099-6339	36	22
4910-01-097-6957	36	18	5120-01-099-6341	38	11
4910-01-097-6958	36	20	5120-01-100-0135	45	6
4910-01-097-6960	39	9	4910-01-100-6191	40	16
5310-01-097-6961	39	5	5310-01-102-3270	31	23
			5306-01-102-3599	32	18
			5310-01-102-7356	32	16
4910-01-097-6962	39	8	5180-01-102-8418	40	7
4910-01-097-6963	39	11	5365-01-103-7835	38	6
4910-01-097-6964	39	4	3120-01-103-8752	38	8
4910-01-097-6965	39	10	5310-01-104-4549	36	25
4910-01-097-6966	39	14	5310-01-104-4550	38	9
5130-01-097-6967	39	13	2815-01-105-8768	2	6
4910-01-097-6968	39	12	4910-01-105-9165	44	1
4910-01-097-6969	38	5	4730-01-106-0202	5	18
4910-01-097-6970	38	2		13	5
4910-01-097-6971	38	12	4910-01-106-0492	42	1
4910-01-097-6972	37	16	4730-01-106-4700	22	19
4910-01-097-6976	39	15		30	19
4910-01-097-6977	38	19	4710-01-106-8068	22	14
5310-01-097-6978	38	20	5120-01-106-9173	39	20
4910-01-097-6979	38	22	5120-01-106-9174	39	18
4910-01-097-6980	38	27	5330-01-107-1841	44	23
4910-01-097-6981	38	26	5306-01-107-6371	18	27
4910-01-097-6982	38	25	6680-01-108-7410	12	24
4910-01-097-6983	38	24		BULK	1

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
4910-01-108-9130	36	12	5310-01-124-6463	17	14
5307-01-109-5972	18	27	5310-01-126-1045	17	13
4730-01-109-8501	22	17	5305-01-126-1128	29	41
5305-01-109-9307	24	45	5365-01-126-3334	29	11
5315-01-110-7835	36	7	2910-01-126-9053	24	15
5310-01-112-4306	16	16	5310-01-126-9404	12	26
5310-01-112-4307	20	6	2815-01-127-1060	3	10
	23	5	2815-01-127-3597	3	10
	29	5	2815-01-127-3598	3	10
2910-01-112-5797	31	15	4730-01-127-6104	26	9
4910-01-112-7509	36	5	5120-01-128-2675	48	6
2910-01-112-7712	21	4	5120-01-128-2678	47	7
5305-01-112-9021	2	11	5120-01-128-2679	47	9
	12	46	5120-01-128-2688	51	3
5305-01-112-9110	29	20	4910-01-128-2691	47	8
	30	2	5120-01-128-2758	50	4
5305-01-112-9698	5	9	4910-01-128-9810	51	5
5305-01-113-0408	33	24	5305-01-129-4214	13	6
4910-01-113-1066	36	6		19	8
5305-01-113-1179	23	10	5305-01-129-4218	24	2
	29	7	3040-01-129-4302	17	30
5305-01-114-6386	5	16	5305-01-129-4384	20	34
6150-01-114-7119	18	3		23	7
4720-01-114-7728	BULK	2	5305-01-129-4385	24	1
5305-01-114-9279	29	27	5305-01-129-4386	35	29
	33	8	5330-01-129-6541	17	16
	33	22	5305-01-129-6901	8	31
4910-01-117-4885	36	10	3120-01-129-7659	20	35
4910-01-118-2878	36	11	2530-01-130-2339	20	32
4910-01-118-3747	40	6	5305-01-130-6100	4	3
5305-01-118-4285	20	79	4730-01-131-4884	22	12
5305-01-118-8826	9	2	5365-01-132-1984	35	10
9999-01-119-2743	36	8	3120-01-132-9339	KIT	
5306-01-119-4271	17	24	5305-01-133-2060	30	11
5305-01-119-8621	17	29	2815-01-133-2445	12	2
5306-01-119-8870	33	22	5360-01-134-5602	24	23
2990-01-120-2883	4	2	5305-01-135-5344	11	1
5120-01-120-3681	44	14	5305-01-135-5446	24	50
5120-01-120-3682	38	3	5340-01-135-7250	33	21
	38	3	2910-01-136-3331	24	63
			5330-01-136-8569	25	13
5120-01-120-5759	43	15	5305-01-137-6706	14	24
			5360-01-138-6638	24	65
5120-01-120-5760	41	2	5325-01-139-6738	11	28
2920-01-121-8859	28	6	5342-01-140-7158	12	30
5120-01-122-6014	37	10	2950-01-141-0844	26	22
5340-01-122-8002	5	26	2815-01-141-0845	5	19
2815-01-124-0232	6	10	4310-01-141-0879	20	8
	17	23	6685-01-141-0907	33	7
4730-01-124-0293	8	27	2930-01-141-0918	10	1
4730-01-124-3762	24	27	2815-01-141-0919	12	2
	30	15	2815-01-141-3261	18	2

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
2910-01-141-4028	24	42	5340-01-145-0802	13	14
2910-01-141-4029	24	7	5305-01-145-1113	12	39
2910-01-141-4337	29	19	5310-01-145-1114	21	6
2910-01-141-4967	24	5	5340-01-145-1181	31	5
2815-01-141-5299	13	1	5342-01-145-1549	24	62
5120-01-141-5777	44	4	5340-01-145-1597	34	2
4910-01-141-8388	49	5		34	2
2930-01-141-9277	14	34	5360-01-145-3974	10	15
2815-01-141-9370	2	6	5360-01-145-3975	10	17
2910-01-141-9372	23	6	5330-01-145-3983	7	8
4710-01-142-1667	12	25	5330-01-145-3984	7	8
2815-01-142-1732	9	4	5330-01-145-3985	9	6
2815-01-142-2745	1	9	5331-01-145-5377	2	39
5330-01-142-2784	24	8	5330-01-145-5380	33	11
5310-01-142-2812	24	13	5330-01-145-5381	33	29
4910-01-142-4929	48	1	5315-01-145-6080	7	4
2910-01-142-4953	24	22	5330-01-145-6083	8	25
2910-01-142-7455	24	12		18	12
4730-01-142-8524	13	51	5331-01-145-6085	10	5
	22	20	5331-01-145-6086	10	18
4910-01-143-2023	48	2	2950-01-145-6822	27	18
4910-01-143-2034	50	7	5330-01-145-6909	10	22
4910-01-143-3336	48	4	5330-01-145-6910	10	10
4910-01-143-3337	48	3	5330-01-145-6911	10	9
5342-01-143-6045	12	9	5330-01-145-6912	10	30
5342-01-143-6046	29	40	5330-01-145-6913	13	34
3120-01-143-9547	4	23	5330-01-145-6914	16	11
5310-01-144-6115	1	2	5360-01-145-7554	13	13
	17	3	5360-01-145-7555	18	22
	18	34	5360-01-145-7607	18	11
5305-01-144-6204	2	37	5305-01-145-8358	12	37
5305-01-144-6206	18	9	5305-01-145-8359	20	37
5310-01-144-6224	13	16	5305-01-145-8379	3	28
5305-01-144-6232	10	19	5305-01-145-8380	5	15
5305-01-144-6233	20	53	5305-01-145-8381	16	7
3120-01-144-7368	17	28	5305-01-145-8382	17	1
3120-01-144-8882	4	23	5305-01-145-8383	17	12
5342-01-145-0645	13	11	5305-01-145-8384	18	13
5342-01-145-0646	21	2	5310-01-145-8403	14	27
5340-01-145-0647	21	5	5310-01-145-8404	16	16
5331-01-145-0715	13	47	5310-01-145-8405	17	10
5331-01-145-0716	16	5		18	12
5365-01-145-0760	31	12	5307-01-145-8449	18	31
5310-01-145-0761	24	9		18	31
5310-01-145-0762	35	18	3020-01-145-8568	7	2
5340-01-145-0772	10	41	3120-01-145-9132	4	23
5340-01-145-0773	14	31	5340-01-145-9362	2	17
5305-01-145-0776	17	8	2940-01-145-9398	10	12
5305-01-145-0777	21	3	2940-01-145-9399	10	13
	23	6	2940-01-145-9400	10	14

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
2815-01-145-9401	16	24	4710-01-146-1115	22	10
2815-01-145-9402	18	23	4710-01-146-1116	22	14
2910-01-145-9403	21	4	3130-01-146-1150	2	25
5340-01-145-9451	13	3	3130-01-146-1228	2	23
2940-01-145-9455	10	34	2940-01-146-1995	11	34
4820-01-145-9457	13	17		13	18
2930-01-145-9537	10	4	2930-01-146-1996	14	9
2930-01-145-9538	10	8	2815-01-146-1997	18	19
5342-01-145-9539	12	30	2910-01-146-1998	21	10
5342-01-145-9540	12	20	2910-01-146-1999	29	1
	14	22	2910-01-146-2000	32	1
3040-01-145-9637	13	20	2930-01-146-3033	33	17
3040-01-146-0028	5	3		33	23
2910-01-146-0048	3	7	4730-01-146-3040	22	22
4710-01-146-0049	12	15	4710-01-146-3085	19	4
4710-01-146-0050	13	33	4710-01-146-3086	11	37
3040-01-146-0075	7	13		33	27
2910-01-146-0093	22	21	4730-01-146-3109	14	16
2815-01-146-0102	5	5	4730-01-146-3111	12	13
3020-01-146-0107	4	15	2815-01-146-3159	15	2
3020-01-146-0108	13	8	3020-01-146-3163	17	17
3020-01-146-0109	13	19	4710-01-146-3167	26	16
2930-01-146-0111	14	32	4710-01-146-3168	19	17
2815-01-146-0112	15	3	4710-01-146-3169	22	18
3010-01-146-0113	13	30	4730-01-146-3631	26	14
2815-01-146-1024	9	5	4730-01-146-3633	22	15
4140-01-146-1035	27	3	3020-01-146-3773	17	15
2815-01-146-1041	7	6	4710-01-146-3779	22	9
4820-01-146-1048	28	11	2990-01-146-3911	27	19
2815-01-146-1049	7	5	2930-01-146-3912	35	1
4710-01-146-1052	12	6	4730-01-146-4016	34	5
4710-01-146-1053	14	35	4710-01-146-4083	14	14
4710-01-146-1054	33	16	4720-01-146-4126	31	9
4730-01-146-1059	31	6	4310-01-146-4155	20	51
4730-01-146-1060	33	13	2815-01-146-4164	3	26
4730-01-146-1064	14	18	2930-01-146-4212	33	3
4730-01-146-1065	14	2	3130-01-146-4504	2	24
4720-01-146-1071	26	10	4820-01-146-4593	18	20
2930-01-146-1081	10	28	2940-01-146-5846	10	25
4330-01-146-1082	10	24	4310-01-146-5921	20	12
2930-01-146-1083	14	4	2815-01-146-5925	4	2
2910-01-146-1084	24	35	3040-01-146-5935	13	25
			3130-01-146-6120	27	14
2930-01-146-1085	33	10	5310-01-146-6147	31	8
4310-01-146-1097	20	14	5310-01-146-6150	31	7
2815-01-146-1102	26	4	2815-01-146-7039	7	14
2815-01-146-1103	15	1	4730-01-146-7047	26	15
4710-01-146-1112	19	17	4910-01-146-7130	49	2
4710-01-146-1113	22	16	5330-01-146-7172	7	8
4710-01-146-1114	22	11	3120-01-146-7196	20	21

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
5305-01-146-7285	14	29	5330-01-147-8754	31	3
5310-01-146-7302	18	8	5365-01-147-9802	2	40
5310-01-146-7303	31	16	2910-01-147-9913	24	40
5330-01-146-7314	33	21	6620-01-147-9954	36	1
2815-01-146-7914	7	16	5360-01-148-0303	13	15
2910-01-146-7955	2	38	5365-01-148-8353	2	40
5330-01-146-9775	7	8	3120-01-149-5414	13	7
5342-01-146-9816	31	13	2815-01-150-2702	15	7
5306-01-146-9866	16	19	3040-01-150-4926	24	54
5330-01-146-9928	7	8	5340-01-150-6248	12	38
5340-01-146-9992	12	5	5365-01-150-6257	2	28
5360-01-147-0054	24	16	2930-01-150-7596	33	12
5330-01-147-0748	12	1	4910-01-150-9713	46	5
5365-01-147-0912	16	4	5330-01-150-9812	35	30
5365-01-147-0913	16	4		KIT	
9905-01-147-0933	1	8	5306-01-151-1023	31	14
5305-01-147-1215	14	15	3040-01-151-9348	29	9
5330-01-147-1274	13	2	4720-01-152-0156	13	50
5307-01-147-1316	18	29	4910-01-152-2743	50	8
4730-01-147-2223	12	8	2815-01-152-9219	KIT	
5305-01-147-2443	13	46	5340-01-153-9425	12	45
5305-01-147-2444	14	5	5331-01-154-4316	10	23
5305-01-147-2445	14	28	4910-01-154-6406	50	2
5365-01-147-2495	2	40	3120-01-155-2531	KIT	
5365-01-147-2496	2	40	3120-01-155-4442	6	12
5365-01-147-2497	2	40	2990-01-155-7284	26	22
5307-01-147-2821	18	30	3120-01-155-8707	6	12
5305-01-147-4025	5	24	5120-01-156-4183	38	18
5305-01-147-4033	16	12	5210-01-157-2291	48	7
5305-01-147-4034	20	2	5210-01-157-3091	51	2
5305-01-147-4035	35	31	3120-01-157-3316	6	12
5330-01-147-4071	13	49	5310-01-157-3762	18	8
5330-01-147-4072	14	8	5310-01-157-7361	20	71
5360-01-147-4846	29	50	4710-01-158-7507	26	20
5365-01-147-5030	1	4	2815-01-159-0872	16	1
5310-01-147-5072	18	28	2815-01-159-1737	9	3
3120-01-147-5275	17	21	2815-01-159-1789	3	16
5340-01-147-5389	12	33	4910-01-159-8701	46	6
4910-01-147-7896	50	1	4730-01-160-3579	11	21
3120-01-147-8118	5	6	2815-01-160-5820	5	19
5305-01-147-8726	30	14	5120-01-160-8863	37	1
5305-01-147-8729	14	30	5120-01-160-8867	47	6
5305-01-147-8730	15	5	4910-01-161-2115	47	5
5305-01-147-8731	16	17	4730-01-161-5115	2	16
5305-01-147-8732	23	4		13	5
				35	5
			5120-01-163-1349	48	10
			5320-01-163-2277	8	11
			5340-01-163-7118	8	26
			4730-01-163-7192	11	4
			5330-01-164-0944	11	48
			5120-01-164-3265	46	7

CROSS-REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX					
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM
2815-01-164-6103	9	3	5325-01-241-4318	6	6
4820-01-164-7002	25	15	2815-01-241-4719	11	31
4730-01-165-0749	34	5	2815-01-241-6580	6	2
	34	8	2815-01-241-6581	6	3
2815-01-165-0765	KIT		3020-01-241-6905	35	13
5305-01-165-3300	16	22	4730-01-241-7258	11	2
5305-01-165-3892	16	20	5340-01-242-0805	11	10
4910-01-165-4541	48	11	4820-01-242-2579	25	10
2930-01-165-4581	11	27	2930-01-262-5153	0035	
4910-01-165-6016	50	6	2990-01-271-0316	KIT	
2815-01-166-3415	7	11		KIT	
2815-01-168-3742	KIT		2930-01-287-9733	0035	
5220-01-168-6878	41	6	3040-01-287-9736	35	7
2990-01-172-3005	26	22	5310-01-287-9737	26	13
4730-01-174-5944	52	3	2815-01-291-5753	25	1
4910-01-175-5215	52	2	3130-01-294-1400	27	14
5930-01-177-0346	10	21	4730-01-294-6019	26	4
5180-01-177-4415	52	5	5930-01-295-0912	31	10
5305-01-179-2380	2	22	2815-01-303-4224	4	6
5330-01-181-0630	19	11	4730-01-309-3321	11	25
			5310-01-312-3859	31	19
5330-01-181-0631	20	5	5305-01-319-9287	34	11
4710-01-181-1956	11	6	5340-01-342-3610	11	19
3120-01-185-8586	25	19	2815-01-354-2702	3	11
5305-01-186-7042	18	9	2815-01-437-3901	1	1
4810-01-187-4925	28	4	2815-01-438-1517	1	1
3120-01-193-7083	4	23	8145-01-445-8271	1	10
5360-01-200-0323	11	32			
6620-01-203-4301	31	16			
5305-01-203-6444	11	7			
5306-01-204-3297	22	7			
4730-01-205-8587	25	9			
3120-01-208-8102	2	30			
3120-01-208-8103	2	30			
5340-01-208-9319	32	15			
4710-01-209-6742	16	3			
5315-01-210-0616	7	19			
4820-01-210-3573	10	16			
2815-01-210-6947	8	30			
4820-01-210-9571	33	4			
3120-01-212-4472	7	21			
5305-01-212-5210	12	37			
3120-01-214-7779	4	7			
4710-01-215-8158	12	15			
3120-01-215-9157	25	17			
4820-01-227-7141	34	5			
2930-01-231-1661	11	13			
6625-01-232-5469	41	4			
5330-01-240-1630	35	6			
5305-01-240-7155	16	12			
5365-01-241-3903	9	7			

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	AC1600300NF		4720-01-085-1316	26	18
88044	AN565F428H24		5305-00-063-5043	24	66
88044	AN737TW22		4730-00-278-9200	22	23
88044	AN960-416		5310-00-141-1795	25	14
				25	16
				29	37
				30	13
				32	14
15434	AR-09999		2930-01-165-4581	11	27
15435	AR-10922			20	29
15434	AR-2308		2815-00-005-7431	8	6
15434	AR-41010		2910-01-080-3149	24	49
15434	AR-45724		3040-01-129-4302	17	30
15434	AR-73350		2815-00-913-2074	KIT	
15434	AR01176		5365-00-716-5496	16	
15434	AR07110		3120-00-219-5461	4	23
15434	AR09832			13	25
15434	AR10124		2930-01-085-3579	33	5
15434	AR10172		2815-01-085-2573	13	1
15434	AR12228			30	20
15434	AR41010		2910-01-080-3149	24	45
15434	AR41022			24	35
15434	AR51323		2910-00-432-1945	32	5
				32	12
15434	AR8667			13	3
15434	AR9832			13	43
15434	AS0401100MS		4720-01-152-0156	13	50
70403	A11		4730-00-555-8263	19	3
03990	A3804		4730-00-954-9510	34	12
15434	BM70796		2910-00-803-2631	29	49
15434	BM78793		2910-00-304-3427	30	17
15434	BM95159		2815-00-195-5894	8	12
15434	BM95160		2815-00-195-5897	8	16
15434	BM95161		2815-01-096-9198	8	2
15434	BM96162			8	20
15434	BM97497		2910-01-096-9200	25	3
80204	B1821BH025C350N		5305-00-071-2517	10	38
80204	B1821BH031C150N		5305-00-226-4831	19	5
80204	B1821BH038C075N		5305-00-543-4372	12	29
				12	32
				13	9
				13	48
				14	12
				14	24
80204	B1821BH038C125N		5305-00-068-0511	10	31
				13	35
				14	10
				26	3
80204	B1821BH038C150N		5305-00-725-2317	10	26

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
80204	B1821BH038C150N		5305-00-725-2317	14	39
80204	B1821BH038C200N		5305-00-782-9489	10	29
80204	B1821BH038C225N		5305-00-638-8920	10	37
80204	B1821BH038F150N		5305-00-269-3240	5	2
80204	B1821BH044C425N		5305-01-032-2311	12	34
64104	B2568		5315-00-532-9388	2	20
75272	COV-1109		5340-01-153-9425	12	45
79470	C3159X2		4730-00-081-9618	2	9
15434	F-40A		5120-00-288-6514	37	9
01637	FL797-A		2940-01-145-9455	10	34
33457	FS1212			30	17
77220	H231		2805-00-293-9699	3	2
33287	J 33113		5180-01-177-4415	52	5
24161	K060436		3030-01-065-9404	35	28
34623	M-A162-20018		7690-01-080-7335	31	11
				31	11
15434	M-1302B-24			37	12
34623	MA145B21000		4720-01-079-3285	13	33
34623	MA207-21-642		2910-00-410-2268	32	2
34623	MA207-21139		4730-00-338-6839	12	49
34623	MA326-21286			38	16
34623	MA87-21005		2815-01-084-3447	1	9
34623	MB320-20011		4710-01-092-0109	12	44
34623	MB362-20001		5310-01-146-7303	31	16
34623	MB70-20107		5340-01-208-9319	32	15
05083	MODEL CD3		4910-01-128-9810	51	5
96906	MS122032		5310-00-159-6209	10	36
				14	13
				22	2
				30	12
				32	13
96906	MS16625-1100		5325-00-807-2636	29	43
96906	MS16625-1200		5325-00-804-2784	6	6
96906	MS16629-1100		5325-00-558-9412	24	18
96906	MS16632-1050		5325-00-256-2846	24	24
				24	46
96906	MS18154-59		5305-01-010-2362	13	9
96906	MS18154-60		5305-00-942-2196	13	48
96906	MS20913-4S		4730-00-221-2139	2	19
				33	30
96906	MS21333-98		5340-00-809-1490	31	22
96906	MS27183-11		5310-00-809-3078	29	26
96906	MS27183-12		5310-00-081-4219	12	42
				33	18
96906	MS27183-14		5310-00-080-6004	5	7
				10	27
				12	28
				13	36

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
96906	MS27183-14		5310-00-080-6004	14	26
96906	MS27183-16		5310-00-809-4085	12	36
96906	MS27183-21		5310-00-823-8803	12	18
96906	MS27769U2		4730-01-205-8587	25	9
96906	MS35308-458		5305-00-944-8292	12	21
96906	MS35338-45		5310-00-407-9566	12	41
				14	36
				19	6
				20	10
				29	28
				33	18
96906	MS35338-46		5310-00-637-9541	10	39
				12	47
				13	32
				22	25
				31	18
96906	MS35338-47		5310-00-209-0965	12	35
				13	27
				16	21
				20	33
				29	3
96906	MS35338-48		5310-00-584-5272	1	3
				5	20
				11	8
96906	MS35338-50			11	45
96906	MS35338-8		5310-00-261-7340	11	17
				11	40
96906	MS35648-8		5340-00-050-1600	2	15
96906	MS35691-5		5310-00-971-7989	24	43
				32	12
96906	MS35756-34		5315-00-043-1787	13	22
96906	MS35842-10		4730-00-908-3195	34	6
96906	MS35842-13		4730-00-909-8627	33	15
02978	MS49005-4		4730-00-954-1281	2	10
96906	MS51092-1		5310-00-684-3463	26	2
96906	MS51967-20		5310-00-763-8920	35	17
96906	MS51968-14		5310-00-732-0560	8	3
				8	7
				8	13
				8	17
				8	21
96906	MS90725-34		5306-00-225-8499	14	37
96906	MS90725-43		5305-00-225-8507	20	9
96906	MS90725-6		5305-00-068-0502	26	12
96906	MS90725-90			12	40
				20	3
96906	MS90728-10		5305-00-068-0509	30	2
96906	MS90728-62		5305-00-068-0511	13	28
15434	M1302B18			37	13
01212	M39807		5330-00-005-0858	4	4

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
75272	PC0625		5340-00-208-2083	8	11
25511	P49787		4730-00-602-3707	20	56
15434	S-1002-A		4730-00-365-2690	10	42
				19	12
				26	25
15434	S-1003-A		5365-00-598-5255	19	14
				19	18
				26	21
15434	S-1005-A		4730-00-374-4282	19	16
15434	S-108-A		5305-00-137-3269	13	28
15434	S-109			22	27
15434	S-1097		4730-01-131-4884	22	12
15434	S-117		5305-01-029-1193	22	5
15434	S-119-C		5305-01-165-3300	16	22
15434	S-122-C		5305-01-147-4034	20	2
				23	1
15434	S-129		5305-00-546-6698	7	10
				12	23
15434	S-142-A		5305-01-147-2443	13	46
15434	S-151C			22	29
15434	S-159-B		5305-00-493-3959	32	5
15434	S-16052		3110-00-516-5289	29	17
15434	S-16255		2815-00-815-0355	35	21
15434	S-174-C		5305-00-207-2715	30	5
15434	S-189-B		5305-01-145-8380	5	15
15434	S-189-C		5305-00-509-8106	28	1
15434	S-190		5305-00-944-8292	14	20
15434	S-199-B		5305-00-404-1388	10	32
15434	S-213-A		5310-00-451-6643	12	16
				24	6
15434	S-217		5310-00-650-0187	20	7
15434	S-222-A			27	4
15434	S-223		5310-00-521-8595	14	23
				22	1
15434	S-2286		5305-00-804-6318	1	7
				20	28
				24	29
15434	S-285		5310-00-470-6154	17	6
15434	S-603		5310-00-820-6653	12	17
				14	21
15434	S-604		5310-00-261-7340	10	3
				12	22
				13	27
				14	13
				14	25
				22	2
15434	S-626		5310-00-562-6558	12	4
				19	7
				20	11
15434	S-631		5310-00-562-6560	10	40
				24	3

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	S-631		5310-00-562-6560	27	6
15434	S-908		4730-00-057-5555	10	7
15434	S-910-B		4730-01-160-3579	11	21
15434	S-911-B		4730-00-018-9566	3	24
				17	31
				19	10
				35	4
15434	S-915-A		4730-00-801-8186	2	26
15434	S-932-B		4730-01-146-1060	33	13
15434	S-965-E		5365-00-404-2934	35	27
15434	S-966E		4730-00-203-0549	2	14
55719	SINL-200			48	9
15434	ST-1032		5120-00-896-8087	40	3
15434	ST-1059-17		5120-01-120-5760	41	2
15434	ST-1089		4910-00-150-5819	49	6
15434	ST-1090		5120-01-072-2955	44	15
15434	ST-1090-3		4910-01-097-6923	44	18
15434	ST-1090-4		5305-01-097-6924	44	16
15434	ST-1095		5120-00-116-7625	45	3
15434	ST-1100		5120-00-178-0948	39	3
15434	ST-1100-1			39	7
15434	ST-1100-10		4910-01-097-6964	39	4
15434	ST-1100-11		4910-01-097-6965	39	10
15434	ST-1100-12		4910-01-097-6966	39	14
15434	ST-1100-13		5130-01-097-6967	39	13
15434	ST-1100-14		4910-01-097-6968	39	12
15434	ST-1100-5			39	6
15434	ST-1100-6		4910-01-097-6960	39	9
15434	ST-1100-7		5310-01-097-6961	39	5
15434	ST-1100-8		4910-01-097-6962	39	8
15434	ST-1100-9		4910-01-097-6963	39	11
15434	ST-1105		5120-01-164-3265	46	7
15434	ST-1114		4910-01-097-6987	37	3
15434	ST-1122		4910-00-150-5843	47	3
15434	ST-1124		4910-00-150-5844	47	4
15434	ST-1134		4910-00-150-5848	49	7
15434	ST-1145		4910-01-097-6925	44	19
15434	ST-1157		4910-01-097-6913	44	3
15434	ST-1158		4910-01-097-6914	43	14
15434	ST-1159		4910-01-097-6988	37	15
15434	ST-1168-10		3020-01-086-8269	43	7
15434	ST-1168-19		4910-01-098-1912	43	8
15434	ST-1168-3		4910-01-085-0763	43	4
15434	ST-1168-4		3120-01-085-0762	43	2
15434	ST-1168-5		3020-01-085-0761	43	5
15434	ST-1168-6		5305-01-084-4596	43	3
15434	ST-1168-7		3020-01-084-7007	43	6
15434	ST-1168-8		4910-01-086-8268	43	9
15434	ST-1168-9		4910-01-088-7904	43	10
15434	ST-1173		4910-01-161-2115	47	5
15434	ST-1177			41	5

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	ST-1178		5120-01-141-5777	44	4
15434	ST-1179		5120-00-104-1795	36	30
15434	ST-1191		5120-01-160-8867	47	6
15434	ST-1218		4910-01-097-6976	39	15
15434	ST-1225		4910-01-097-6948	36	2
15434	ST-1227		5120-00-981-3108	36	15
15434	ST-1228		5120-00-055-4013	40	14
15434	ST-1228-1		4910-01-098-1915	40	23
15434	ST-1228-13		4910-01-097-6910	40	17
15434	ST-1228-14		4910-01-097-6911	40	21
15434	ST-1228-2		4910-01-098-1916	40	22
15434	ST-1228-3		4910-01-098-1917	40	15
15434	ST-1228-4		4910-01-098-1918	40	20
15434	ST-1228-5		4910-01-098-1919	40	18
15434	ST-1228-9		4910-01-100-6191	40	16
15434	ST-1229		5120-00-999-1206	49	8
15434	ST-1241		4910-01-141-8388	49	5
15434	ST-1242		4910-01-098-1914	36	4
15434	ST-1242-1		4910-01-108-9130	36	12
15434	ST-1242-2		4910-01-113-1066	36	6
15434	ST-1242-3		4910-01-112-7509	36	5
15434	ST-1242-4		9999-01-119-2743	36	8
15434	ST-1242-5		4910-01-099-1487	36	9
15434	ST-1242-6		5315-01-110-7835	36	7
15434	ST-1242-7		4910-01-117-4885	36	10
15434	ST-1242-8		4910-01-118-2878	36	11
15434	ST-1244		5120-00-113-5271	38	1
15434	ST-1244-1			38	7
15434	ST-1244-3			38	10
15434	ST-1244-4		5310-01-104-4550	38	9
15434	ST-1244-5		3120-01-103-8752	38	8
15434	ST-1244-8		5120-01-099-6341	38	11
15434	ST-1244-9		5365-01-103-7835	38	6
15434	ST-125		2815-00-362-2042	46	1
15434	ST-1254			52	4
15434	ST-1255		4910-01-085-0764	43	11
15434	ST-1257-A		4910-01-128-2691	47	8
15434	ST-1259		4910-01-106-0492	42	1
15434	ST-1259-1		4910-01-097-6916	42	3
15434	ST-1259-2		4910-01-097-6917	42	4
15434	ST-1259-3		5305-01-097-6918	42	5
15434	ST-1259-4		4910-01-097-6919	42	2
15434	ST-1259-5		5305-01-097-6920	42	7
15434	ST-1259-6		5305-01-097-6921	42	8
15434	ST-1259-7		5305-01-098-1913	42	6
15434	ST-1261		4910-01-147-7896	50	1
15434	ST-1262		4910-01-154-6406	50	2
15434	ST-1273		6620-01-147-9954	36	1
15434	ST-1279		5120-01-128-2679	47	9
15434	ST-1287-10		5133-01-084-6008	43	13
15434	ST-1295		5120-00-150-7488	41	1

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	ST-1298		4910-01-082-1346	50	3
15434	ST-1318		4910-01-085-0766	43	17
15434	ST-1318-23		5133-01-084-6009	43	18
15434	ST-1325		4910-01-097-6972	37	16
15434	ST-1326		5120-01-097-6932	44	20
15434	ST-1326-1		4910-01-097-6933	44	22
15434	ST-1326-2		4910-01-097-6934	44	21
15434	ST-249		5180-00-916-1813	39	16
15434	ST-249-1		5120-01-106-9173	39	20
15434	ST-249-2		5120-01-097-3204	39	19
15434	ST-249-3		5120-01-106-9174	39	18
15434	ST-249-4			39	17
15434	ST-257		4910-00-345-3708	46	2
15434	ST-302		4910-00-999-1506	37	2
15434	ST-386-10		4910-01-097-6983	38	24
15434	ST-386-11		4910-01-097-6984	38	21
15434	ST-386-2		4910-01-097-6977	38	19
15434	ST-386-3		5310-01-097-6978	38	20
15434	ST-386-5		4910-01-097-6979	38	22
15434	ST-386-6		4910-01-097-6980	38	27
15434	ST-386-8		4910-01-097-6981	38	26
15434	ST-386-9		4910-01-097-6982	38	25
15434	ST-419		5120-00-896-8097	36	3
15434	ST-448			46	4
15434	ST-544		5120-00-065-1031	43	11
15434	ST-544-1		5120-01-100-0135	45	6
15434	ST-544-2			45	5
15434	ST-560		5210-00-999-1209	36	28
15434	ST-561		4910-00-977-7507	49	1
15434	ST-563		4910-01-146-7130	49	2
15434	ST-608		4910-01-086-9766	45	2
15434	ST-633		4910-00-150-5797	38	28
15434	ST-646		5110-00-980-7347	39	2
15434	ST-658		4910-01-097-6986	38	17
15434	ST-659		5120-00-159-8916	39	21
15434	ST-663		3460-00-999-1173	46	8
15434	ST-668		3465-00-999-1501	52	1
15434	ST-669		5120-00-103-4687	37	8
15434	ST-669-13		5120-01-122-6014	37	10
15434	ST-691		3460-00-999-1210	38	13
15434	ST-691-1			38	14
15434	ST-691-2			38	15
15434	ST-6991			37	14
15434	ST-708		5120-00-999-1503	49	3
15434	ST-709		5120-00-999-1504	37	4
15434	ST-749		4910-01-159-8701	46	6
15434	ST-763		5120-00-150-7486	49	4
15434	ST-788		5133-00-932-2089	36	13
15434	ST-835		5120-00-999-1505	40	1
15434	ST-851		5120-00-923-0856	45	7
15434	ST-853		4910-00-150-5801	40	2

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	ST-876		7920-00-168-3244	47	2
15434	ST-880		3441-00-922-6699	36	21
15434	ST-880-1		5210-01-099-6339	36	22
15434	ST-880-2		4910-01-097-6955	36	23
15434	ST-880-3			36	24
15434	ST-880-6		5310-01-104-4549	36	25
15434	ST-880-7		4910-01-097-6956	36	26
15434	ST-884		4910-00-981-3105	36	16
15434	ST-884-1		4910-01-097-6957	36	18
15434	ST-884-3		4910-01-098-5088	36	17
15434	ST-884-5			36	19
15434	ST-884-6		4910-01-097-6958	36	20
15434	ST-903		5220-01-168-6878	41	6
15434	ST-990		5120-01-029-6861	51	4
15434	ST-995		5120-00-150-7492	36	29
15434	ST-997		5120-00-150-5810	40	4
15434	ST-997-6		4910-01-097-6915	40	5
15434	ST1065		5120-00-150-7489	40	13
15434	ST583		4920-00-711-9307	46	4
15434	ST593			39	1
15434	ST662		4910-00-999-1208	46	9
15434	ST790-362		4910-01-175-5215	52	2
15434	ST790-363		4730-01-174-5944	52	3
15434	ST824		4910-00-925-0755	47	1
15434	S105		5305-00-426-4142	13	31
				29	41
15434	S105X		5305-00-426-4146	24	25
15434	S110		5305-01-114-9279	29	27
				33	8
				33	22
15434	S118A		5305-00-230-1939	26	12
15434	S126		5305-00-177-5552	11	18
15434	S129		5305-00-546-6698	2	35
15434	S1354			12	48
15434	S145		5305-01-203-6444	11	7
15434	S149A		5305-00-404-1390	14	30
15434	S151			29	4
15434	S152B			11	44
15434	S155		5305-01-028-8869	15	5
15434	S16255		2815-00-815-0355	35	11
15434	S174C		5305-00-207-2715	30	5
15434	S189C		5305-00-509-8106	28	1
15434	S190C		5305-00-795-9345	22	7
15434	S200		5310-00-469-3998	5	21
15434	S222A			27	4
15434	S223		5310-00-521-8595	13	40
15434	S2286			26	23
15434	S248		5310-00-005-6052	24	48
15434	S251		5310-00-011-4492	32	8
15434	S2876		3120-00-353-9164	32	7
15434	S600		5310-00-562-6552	32	6

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	S601		5310-00-134-4168	5	17
15434	S604		5310-00-261-7340	2	34
				7	9
				12	17
				35	32
15434	S622		5310-00-562-6557	13	36
15434	S631		5310-00-562-6560	22	3
15434	S684		5330-00-003-1771	14	36
15434	S689			22	26
15434	S719		5340-00-276-5847	2	31
15434	S911B		4730-00-018-9566	2	27
				5	23
				11	35
				14	40
				16	10
15434	S962		4730-00-044-4715	12	10
15434	TM-82		5120-00-865-0226	37	11
04998	WA1248		5310-00-143-5722	20	64
81348	WW-P-471AASBUC		4730-00-010-3867	35	5
75078	001022		5360-01-084-9066	18	17
75078	001023		5325-01-087-8727	18	15
75078	001026		5310-01-157-3762	18	8
75078	001030		5310-01-145-8405	17	10
				18	12
75078	001031		5305-01-186-7042	18	9
75078	001081		5331-01-086-1013	18	5
75078	001082		5331-01-085-3105	18	6
75078	001083		5330-01-086-6196	18	7
75078	001094		5310-01-144-6115	1	2
				17	3
				18	34
75078	001199		5307-01-145-8449	18	31
				18	31
75078	001232		5307-01-147-2821	18	30
75078	001234		5365-01-147-5030	1	4
				17	4
				18	33
75078	001484		2815-01-098-6755	18	18
75078	001492		5305-01-145-8384	18	13
75078	001519		5360-01-089-9103	18	21
75078	001521		4820-01-089-3939	18	20
75078	002299		5940-01-085-4426	18	10
75078	002390		6150-01-114-7119	18	3
75078	002514		5310-01-147-5072	18	28
75078	002856		5307-01-147-1316	18	29
75078	002969		2520-01-085-6128	18	13
75078	003251		5365-01-095-5666	17	9
75078	003678		5306-01-107-6371	18	27
75078	004089		2815-01-088-7328	18	14
75078	004136		2815-01-145-9402	18	23
75078	004205		4810-01-089-0534	18	4

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
75078	007447		5360-01-145-7607	18	11
75078	007500		5360-01-145-7555	18	22
75078	007505		4820-01-146-4593	18	20
75078	007623		2815-01-098-6755	18	18
75078	007696		2815-01-146-1997	18	19
75078	008895		5340-01-085-4439	18	16
75078	009353		5310-01-146-7302	18	8
75078	009916		5305-01-144-6206	18	9
75078	009917		2815-01-141-3261	18	2
75078	010180		5330-01-145-6083	8	25
				18	12
75078	011494		5120-01-163-1349	48	10
75078	011573		2815-01-085-3733	3	19
75078	012647		5305-01-145-8382	17	1
75078	016053		2815-01-085-2574	18	1
6N299	0907859		4730-00-042-8988	10	6
15434	100099		5331-00-809-2667	30	8
15434	100129		5305-00-721-3698	25	21
15434	100193		3120-00-810-6032	24	41
15434	100215		3040-00-567-4354	25	18
15434	100475		5325-01-084-9033	13	29
15434	100478		5331-00-081-9289	24	55
15434	100764		5330-00-506-4866	29	31
06991	101037-05		5306-01-151-1023	31	14
15434	101322		2590-00-590-7378	9	1
15434	101841		5365-00-507-3224	24	64
15434	101842		5365-00-507-3225	24	64
15434	101843		5365-00-543-3744	24	64
15434	101996			10	20
06991	102030		5310-01-146-6147	31	8
15434	102522		4720-01-085-6129	33	20
06991	103031		5310-01-146-6150	31	7
06853	103840		2530-00-603-1532	20	61
77640	103879		4730-00-010-3867	12	8
15434	105182		5340-01-085-6269	13	37
15434	105199		2815-00-829-5227	15	6
				18	16
15434	105375		9905-00-733-7622	24	28
15434	105953		5306-00-804-2468	2	22
15434	106289		5305-00-091-4009	5	13
15434	107460		5340-00-087-7486	14	19
15434	107738		2815-00-505-5119	7	24
15434	107947		4820-00-276-9041	10	35
				11	12
06991	108289		5342-01-146-9816	31	13
15434	108330		5310-00-486-2505	14	25
				22	3
15434	108722		5340-00-400-3449	26	17
15434	109319		2815-00-406-8936	13	45

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	109333		2815-00-705-2856	13	14
15434	109594		3120-01-079-6527	15	10
				34	3
15434	110058		5340-00-716-4975	24	44
15434	110266		5305-00-477-0395	15	7
15434	110855		5330-00-567-3463	25	2
15434	110907		5365-00-708-3434	11	14
06991	111025		5330-01-147-8754	31	3
15434	112302		5325-00-420-9696	35	9
15434	114638		5310-00-887-8325	15	8
12204	116122		5310-00-011-6122	20	1
				23	2
15434	116391		3120-00-792-9834	17	32
19207	11669835		2815-01-142-2745	1	9
15434	116982		5340-00-767-4012	15	11
11862	117244		4730-00-042-8988	16	13
				24	30
15434	118227		5315-00-844-0140	24	38
15434	118377		3120-00-791-1440	7	23
15434	118378		3120-00-659-7808	7	17
15434	118939		5315-00-777-3544	7	20
				7	26
15434	119363		3020-00-702-3882	25	11
15434	119810		4310-00-903-7174	20	18
15434	119859		5325-00-922-9101	20	19
94135	12Z9026-5		5330-00-599-2962	24	21
30379	120217		5310-00-922-2017	28	16
15434	123558		5315-00-866-5015	3	8
19207	12389942-1		8145-01-445-8271	1	10
06991	125049		4730-01-146-1059	31	6
15434	126304		2815-00-828-7013	13	44
15434	127316		5310-00-081-8500	4	14
				5	14
15434	127558		2815-00-791-1453	11	22
15434	127936		5331-00-941-3762	20	49
15434	127940		4820-00-445-0610	20	40
15434	128080		5360-00-895-3216	20	39
15434	128085		5331-00-905-2679	20	41
15434	128086		5331-00-441-0145	20	50
15434	128936			26	24
15434	129768		5310-00-082-1888	28	9
15434	129826		4820-00-829-5600	28	14
15434	129838		5355-00-082-1189	28	15
15434	129839		5340-00-084-7787	28	7
15434	129866		4730-01-106-4700	22	19
				30	19
15434	129888		5331-00-081-9299	28	8
15434	130118		2930-00-928-3595	33	1
15434	130394		4730-00-404-2906	33	28
15434	131026		5331-00-143-8485	3	22

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	132019		5340-00-799-0843	2	12
15434	13264800		4730-00-404-2909	2	33
75078	13294		5330-01-086-3996	18	24
15434	133538		5305-01-133-2060	30	11
15434	134074		2910-00-085-7436	28	6
15434	134561		5340-01-147-5389	12	33
15434	135308		2815-01-146-4164	3	26
15434	136403		9905-00-473-7260	20	27
15434	137075		5331-00-420-9624	4	5
15434	137370		5340-00-907-8964	29	48
15434	137795		5305-00-091-4006	10	2
15434	137796		5306-01-204-3297	22	7
15434	138769		5360-01-086-6114	24	65
15434	139988		5331-00-809-3276	30	6
15434	140218		5310-00-082-1882	2	21
15434	140330		3120-00-589-3537	8	5
				8	15
				8	19
				8	23
24617	141244		5315-00-014-1244	25	4
24617	141284		5315-00-014-1284	5	22
15434	142110			11	20
15434	142689		3020-00-160-9092	17	20
15434	143251		5360-00-461-5738	29	47
15434	143253		5360-00-901-9644	29	47
15434	143848		5360-01-095-3661	24	61
				29	34
15434	144178		5315-00-082-0448	24	59
				29	32
15434	144179		5310-00-727-8353	24	60
				29	6
15434	144302		5365-00-829-5604	24	63
15434	144714		4820-00-909-4174	20	42
15434	144948		3805-00-955-5320	20	45
15434	145028		4820-00-909-4175	20	46
15434	145504		5330-01-051-4243	13	12
15434	145504		5330-01-051-4243	24	20
15434	145505		5330-01-072-8982	24	19
15434	145506		5331-01-086-3991	35	23
15434	146160		5310-00-809-3078	29	26
15434	146161		5310-01-075-0991	13	10
15434	146483		2910-00-790-8736	24	34
15434	147056		2910-00-085-7442	3	7
15434	147100		2910-00-928-3505	3	21
15434	147135		5342-00-858-3507	22	4
15434	147389		5305-00-062-4378	3	17
15434	147610		3120-01-016-4883	20	26
15434	148203		5330-00-143-8369	33	29
15434	149105PC183049		5331-00-058-1767	2	5
28265	14978		5310-01-056-1371	20	52
15434	151478		2815-00-920-2073	15	3
15434	153338		5340-00-829-5617	30	10

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	153346		5305-01-147-8726	30	14
15434	153964		4310-01-146-5921	20	12
15434	154018		5330-00-852-7347	20	15
15434	154087		5330-00-951-3538	28	17
15434	154088		5330-00-961-9470	24	32
15434	155789		4720-01-085-6131	14	11
15434	156416			27	7
15434	156420		3120-00-682-7706	27	13
15434	156444			27	2
15434	157088		5365-00-507-3271	24	31
15434	157281			4	7
15434	157282			4	7
15434	157551		5330-00-143-8376	13	34
15434	160514		5365-00-965-0870	30	9
15434	162426		3010-00-447-9799	23	9
				29	29
15434	163733		5342-00-400-5178	24	37
15434	163944		3120-00-904-9595	29	18
15434	165430		4310-01-079-6938	20	17
15434	166009		5360-00-132-0245	21	7
15434	166485		3120-00-493-3913	32	9
15434	166777		5305-01-091-2498	17	5
15434	167157		4820-01-070-9710	21	11
15434	167299		5310-00-680-6874	27	5
15434	168306		5305-00-947-3437	8	4
				8	8
				8	14
				8	18
				8	22
15434	168319		5305-00-297-4022	8	24
15434	170226		5342-00-404-2946	1	5
15434	170296		5340-00-933-3009	3	3
15434	170510			27	12
15434	170664		5310-00-486-2507	17	25
15434	170970			22	28
15434	171570		2990-00-477-6159	27	16
15434	172034		5340-00-632-6239	3	5
15434	172648		5330-00-404-2920	5	27
15434	173086		5330-00-132-0247	21	15
15434	173368		5330-00-132-0248	11	49
15434	173708			32	10
15434	173709			32	4
15434	173717		5360-00-436-7340	32	3
15434	174299		5365-00-815-1137	21	13
15434	175755		5325-01-241-4318	6	6
15434	175831		5340-00-485-0945	7	12
15434	175833		5305-01-145-8383	17	12
15434	175860			25	6
15434	175864		3040-00-933-3012	25	12
15434	175867			25	5

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	176027		5330-00-129-9389	20	31
75078	1764		5307-01-109-5972	18	27
15434	177419		3040-01-079-3469	13	23
15434	178074		5342-01-140-7158	12	30
15434	179063		2940-01-146-1995	11	34
				13	18
15434	179822		5360-01-147-0054	24	16
15434	179834			24	16
15434	179901		4820-01-045-6080	34	5
15434	179903		4730-01-045-3083	34	8
15434	179904		4730-01-146-4016	34	5
15434	179912			34	7
15434	180175		5305-01-112-9698	5	9
15434	180371		5340-01-079-8097	22	6
15434	180372		5340-00-719-4601	22	8
15434	180810			20	22
15434	181213		4730-00-444-1710	3	25
				22	13
15434	181466		5310-00-484-1718	24	26
				25	20
				28	2
				30	3
15434	182706		5305-00-058-6604	35	15
15434	183429		5365-00-369-4729	20	38
15434	183695			13	22
15434	185138		5342-01-079-4678	21	9
15434	185573		5365-01-086-7788	16	4
15434	185847		4310-01-146-4155	20	51
15434	186780		5330-00-864-5422	33	8
15434	187317		4730-00-138-3906	19	15
15434	187420		5365-00-132-0273	6	9
15434	1875350			20	23
15434	187556		5305-00-138-9848	28	5
15434	189800		5365-00-462-4504	29	45
15434	190334		5360-00-129-9415	20	44
15434	190397		2930-00-401-9531	17	18
15434	190849		5330-00-194-8385	26	8
15434	190876		5331-00-132-0274	28	10
8X479	191037		4310-01-084-7148	20	48
15434	191916		5340-00-238-5435	21	1
15434	191970		2815-00-480-4347	6	7
15434	193136		5310-01-124-6463	17	14
15434	193625		2815-01-133-2445	12	2
15434	193734		5330-00-403-9896	24	21
15434	193736		5330-00-132-0276	21	8
15434	194010		5305-00-411-9340	27	9
15434	194037		5340-00-404-2940	8	10
15434	195210			4	18
15434	195755		5305-01-109-9307	24	45
15434	195952		5330-01-066-3904	14	7
01212	1962CPA		3120-00-005-0602	4	21
15434	196282		4730-01-085-4156	19	9
				33	13

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	196844		5365-01-132-1984	35	10
15434	199349		3010-01-079-3461	20	4
15434	199586		3120-01-149-5414	13	7
15434	199587			13	20
15434	199589		3010-01-079-1788	13	30
28835	2CA647		4720-00-278-4890	12	14
53203	20000		2910-00-646-9727	31	2
15434	200064		5340-00-417-5800	12	27
15434	200488		4730-01-294-6019	26	4
15434	200566		2815-01-077-4463	15	2
15434	20063500		4730-01-078-6364	24	58
15434	200809		5330-00-026-2931	17	19
15434	200817		5330-00-471-0370	29	30
15434	200861		5310-00-134-4171	5	8
				11	46
15434	200919		5340-00-132-3203	15	9
15434	201250			27	8
15434	201737		6685-01-141-0907	33	7
15434	202069		5305-01-086-7285	21	3
01276	2021-20-20S		4730-00-202-8470	13	42
15434	202128		5360-01-200-0323	11	32
15434	202185		4710-01-146-1114	22	11
15434	202377			27	15
15434	202456			27	11
15434	202897		5340-00-951-3536	30	7
15434	202903		5315-01-058-4551	4	8
06853	202961		5310-00-403-7731	20	70
15434	203097		3120-01-083-6411	35	14
15434	203131		5310-00-426-3990	3	18
15434	203145		5330-01-066-3910	13	2
15434	203350		2910-01-080-5570	24	63
15434	203426		5315-01-079-6506	21	12
15434	203619		5305-01-072-8831	29	20
15434	203760		5310-01-112-4306	16	16
15434	204163		4330-01-020-3666	34	10
15434	204165		5305-00-795-9336	4	13
				5	10
15434	204244		3040-01-086-1448	27	19
15434	204586		6685-01-047-2811	33	12
15434	204832		3020-01-085-3779	13	24
15434	206326		5305-01-113-1179	23	10
				29	7
15434	208084		5320-01-163-2277	8	11
15434	208119		3040-01-079-3468	35	25
15434	208120		5365-01-080-0409	35	22
15434	208128		5330-01-040-2087	33	6
15434	208326		4730-00-477-4160	26	5
15434	208346		5305-01-179-2380	2	22
15434	208525		5310-01-079-6529	21	6
15434	208829		5342-01-098-0175	17	7
15434	209760		3120-01-080-3275	24	36

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	209919		2815-01-146-5925	4	2
15434	209955		4720-01-146-1071	26	10
15434	210179		5315-01-079-6740	4	16
15434	210416		4710-01-209-6742	16	3
15434	210707			11	33
15434	210884		5365-01-150-6257	2	28
15434	210915		2815-01-241-4719	11	31
15434	210966		5340-01-242-0805	11	10
15434	210967		5340-01-342-3610	11	19
15434	211222			14	9
15434	211255		5330-00-135-6382	16	6
15434	211315		5330-01-060-9061	20	43
15434	211435		2930-01-084-6011	33	21
15434	211448		5340-01-145-1597	34	2
15434	211662		3120-01-129-7659	20	35
15434	211918		3020-01-077-4411	4	11
15434	211939		5360-01-038-4659	13	13
15434	211999		5360-00-009-9270	3	4
15434	212161		5331-01-077-5228	11	36
				33	26
15434	212601		3040-01-070-9004	29	22
15434	212602		3020-01-086-4158	29	24
15434	212603		5330-01-072-8828	29	10
15434	212604		5325-01-081-0662	29	16
15434	212605		3020-01-070-9003	29	15
15434	212607		3040-01-085-2871	29	9
15434	212609		3120-01-087-2539	29	12
15434	212610		3020-01-086-8780	29	13
15434	212613		3010-01-080-1529	29	25
15434	212639		3010-01-088-5727	29	14
15434	212668		5315-01-087-0534	29	23
15434	212954		5305-01-079-7028	21	18
15434	213079		5330-01-084-9068	30	18
15434	213082		5310-01-145-0762	35	18
15434	213394		5340-01-087-0682	3	13
15434	213395		5340-01-087-0681	3	9
15434	213456		5305-01-147-8731	16	17
15434	213485		4710-01-079-3198	33	16
15434	213559		2815-01-048-6702	7	18
15434	213740			2	2
15434	213768		5331-01-072-8983	24	45
15434	213769		3110-01-079-8190	24	57
15434	214086		2835-01-086-1447	27	18
15434	214139		2910-01-141-4028	24	42
15434	214144		2910-01-091-7507	24	47
15434	214146		3040-01-086-1651	24	22
15434	214150		5310-01-145-0761	24	9
15434	214306		2815-01-079-9146	16	18
15434	214345		4820-01-210-9571	33	4
15434	214617		5340-01-135-7250	33	21
15434	214730		2815-01-241-6581	6	3
15434	214836			14	34

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	214950		3120-01-087-3004	6	12
15434	214951		3120-01-155-4442	6	12
15434	214952		3120-01-157-3316	6	12
15434	215041		4710-01-085-6132	14	35
15434	215042		2815-01-083-2123	33	3
15434	215044		5330-01-066-5351	14	3
15434	215045		5330-01-082-6984	14	17
15434	215090		5330-00-064-4399	2	3
15434	215195		4720-01-085-6293	26	10
15434	215233		3120-01-079-8194	7	3
15434	215397		3020-01-079-4206	35	26
15434	215587		4730-01-146-1064	14	18
15434	215705		5331-01-145-0716	16	5
15434	215787			30	4
15434	215965		3020-01-077-2229	4	15
15434	215966		3020-00-424-9995	7	2
15434	21609300		4710-01-095-8683	19	13
15434	216128		4710-01-079-3493	22	11
15434	216165		2990-01-120-2883	4	2
15434	216296		5340-01-163-7118	8	26
15434	216467		2815-01-079-3317	33	23
15434	216486		5330-01-066-5352	14	6
15434	216487		5330-01-072-8998	26	1
15434	216524		5340-01-086-6193	3	14
15434	216802		5330-01-085-3580	27	1
15434	216908		3040-01-151-9348	29	9
15434	217034		2930-01-097-6755	17	2
15434	217315		2930-01-231-1661	11	13
15434	21732300		2815-01-079-1632	4	12
15434	217632		4730-01-085-7328	15	12
15434	217736			27	10
15434	217798		2910-01-098-5118	24	39
15434	217929		2815-01-085-5190	7	6
15434	217932		4730-01-146-3109	14	16
15434	217933		4710-01-146-4083	14	14
15434	217934		5342-01-145-9540	12	20
				14	22
15434	217939		4710-01-146-3085	19	4
15434	218153		3120-01-079-5208	8	9
15434	218245		5330-01-046-1991	11	26
15434	218716			16	15
15434	218732		2815-00-994-4429	6	4
15434	218736		4730-01-124-0293	8	27
15434	218793		4310-01-146-1097	20	14
15434	218813		5340-01-150-6248	12	38
15434	218867		2910-01-146-2000	32	1
15434	219107			7	25
15434	219153		5306-01-079-7027	6	11
24617	219191		4730-00-010-3867	16	13
06853	230175			20	63

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
93389	2304		5120-00-865-0933	39	22
06853	237303		5330-01-097-7791	20	77
06853	239658			20	60
06853	240331			20	62
06853	240334			20	59
06853	240336			20	58
06853	240338		5360-00-079-1940	20	65
06853	240339		4820-00-117-9103	20	66
06853	240340		5305-00-839-6230	20	76
06853	240341		5340-00-116-6767	20	74
06853	240342		2530-00-116-9953	20	75
06853	240343		5360-00-603-1518	20	73
06853	240344		5340-00-117-9102	20	72
06853	240345		5340-00-738-7552	20	68
06853	240346			20	57
06853	240347			20	67
24617	2436161		5310-01-102-3270	31	21
06853	246075		5310-01-157-7361	20	71
72983	248X4		4730-00-900-3296	22	31
33457	255622		5330-00-286-0487	30	18
01276	2580-6		4720-00-187-4102	34	12
				34	13
				BULK	3
24617	272547		5306-00-418-2276	31	17
06853	275202		4310-00-225-0706	20	69
06853	275230		2530-01-093-0872	20	55
06853	275707		2530-00-827-5934	20	54
75078	2856		5307-01-147-1316	18	29
15434	299670		2940-01-019-4513	10	33
				11	43
15434	3000082		5310-01-145-8404	16	16
15434	3000171		4310-01-092-9816	17	22
15434	3000173		5306-01-119-4271	17	24
15434	3000174		3010-01-085-2732	17	26
				20	36
15434	3000266		3040-01-085-2616	28	12
15434	3000446		4320-01-098-5115	24	56
15434	3000464		2910-01-076-8632	21	16
15434	3000465		5310-01-079-6708	21	17
15434	3000560		4730-01-146-7047	26	15
15434	3000888		4320-01-079-3454	35	2
15434	3000907		4710-01-181-1956	11	6
15434	3000926			3	11
15434	3001296		5342-01-085-4153	23	3
				29	2
15434	3001646		5305-01-147-4025	5	24
15434	3001707		5365-01-079-8373	24	17
15434	3001847		2910-01-147-9913	24	40
15434	3002048			24	57
15434	3002069			7	19
15434	3002074		4730-01-079-3273	19	1
15434	3002110		2910-01-086-7715	29	8

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	3002110		2910-01-086-7715	29	8
15434	3002385		5330-01-066-5350	35	16
15434	3002731		4140-01-085-2607	27	3
15434	3002901		3020-01-145-8568	7	2
15434	3003156		5330-01-072-8830	24	11
				29	39
				29	44
15434	3003480			1	6
15434	3003536		4730-01-079-3274	26	19
15434	3003682		3040-01-077-4976	21	2
15434	3003814		2520-01-090-4473	11	11
15434	3004724		5365-01-126-3334	29	11
15434	3005133		4310-01-092-9815	17	11
15434	3005152		2530-01-130-2339	20	32
15434	300550700		3020-01-086-3417	35	13
15434	3005508		5305-01-147-2444	14	5
15434	3006175		5305-01-072-8826	24	53
15434	3006182		5305-01-118-8826	9	2
15434	3006183		2815-01-142-1732	9	4
15434	3006187		2815-01-159-1737	9	3
15434	3006289		5307-00-922-2626	15	13
				26	7
15434	3006343		3040-01-086-1449	24	51
15434	3006344		5305-01-135-5446	24	50
15434	3006349		2815-01-164-6103	9	3
15434	3006350		3040-01-150-4926	24	54
15434	3006358		2815-01-146-1024	9	5
15434	3006456		2815-01-085-2618	3	15
15434	3006457			3	15
15434	3006458			3	15
15434	3006736		5330-00-005-0856	4	10
15434	3006738		5330-01-086-6112	4	4
15434	3006745		5325-01-139-6738	11	28
15434	3007442		5331-01-145-5377	2	39
15434	3007713		5330-01-086-6197	11	29
15434	3007759		5331-01-072-4436	3	6
15434	3008017		5330-01-079-6514	11	39
15434	3008047		3130-01-146-1150	2	25
15434	3008048		3130-01-146-4504	2	24
15434	3008049		3130-01-146-1228	2	23
15434	3008069		5305-01-212-5210	12	37
15434	3008425		2930-01-146-0111	14	32
15434	3008468		4730-01-147-2223	12	8
				33	30
15434	3008469			2	8
			4730-01-106-0202	5	18
				13	5
15434	3008470		5342-01-143-6045	12	9
15434	3008530		2815-01-145-9401	16	24
15434	3008591		5330-01-086-3523	14	33
15434	3008596		4730-01-146-3111	12	13

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	3008599		4710-01-215-8158	12	15
15434	3008690		4730-01-163-7192	11	4
15434	3008706		4730-01-077-2016	21	14
15434	3008947		5330-01-129-6541	17	16
15434	3008998		5330-01-049-0466	2	4
15434	3009213		5310-00-356-1447	2	21
15434	3009380		2910-01-136-3331	24	63
15434	3009848		4710-01-106-8068	22	14
15434	3010030		5330-01-046-3144	11	16
15434	3010042		2910-01-146-1084	24	35
				24	63
15434	3010146		5360-01-145-7554	13	13
15434	3010242		5330-01-075-0948	24	19
				KIT	
				KIT	
15434	3010589		5305-01-129-6901	8	31
15434	3010590		5305-01-119-8621	17	29
15434	3010594		5305-01-130-6100	4	3
15434	3010595		5305-01-085-8197	11	9
				12	29
				33	9
15434	3010596		5305-01-088-6019	11	15
				11	38
				32	17
				33	29
				33	32
				34	1
15434	3010597		5305-01-086-7036	11	42
				33	14
15434	3010810		5342-01-145-1549	24	62
15434	3011233		4730-01-241-7258	11	2
15434	3011342		5305-01-135-5344	11	1
15434	3011610		5310-01-145-8403	14	27
15434	3011711		5305-01-147-4033	16	12
15434	3011712		5305-01-240-7155	16	12
15434	3011713		5305-01-145-8381	16	7
15434	3011714		5305-01-165-3892	16	20
15434	3011715		5305-01-072-8816	16	23
15434	3011878		5330-01-066-5349	7	8
15434	3011934		2910-01-146-0048	3	7
15434	3011951		3120-01-079-6823	2	30
				2	30
15434	3011952		5340-01-145-9362	2	17
15434	3012328		5315-01-086-6187	7	4
15434	3012331		2815-00-994-4427	6	1
15434	301233200		2815-01-241-6580	6	2
15434	3012462		2815-01-146-1041	7	6
15434	3012468		5305-01-129-4386	35	29
15434	3012469		5305-01-147-4035	35	31
15434	3012470		5305-01-113-0408	33	24
15434	3012471		5305-01-072-8818	14	10

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	3012473		5305-01-137-6706	14	24
15434	3012479		5305-00-795-9352	13	46
15434	3012481		5305-01-147-8732	23	4
15434	3012483		5305-01-114-6386	5	16
15434	3012526		5310-01-126-1045	17	13
15434	3012529		5340-01-145-0802	13	14
15434	3012531			13	23
15434	3012532		3040-01-145-9637	13	20
15434	3012538		2910-01-086-3974	21	10
15434	3012558		5305-01-129-4218	24	2
15434	3012726		5342-01-145-0645	13	11
15434	3013000		2930-01-087-8749	33	31
15434	3013161		4710-01-146-1116	22	14
15434	3013295		4730-01-146-1065	14	2
15434	3013331		5315-01-210-0616	7	19
15434	3013336		3020-01-146-3773	17	15
15434	3013591		2910-01-146-7955	2	38
15434	3013623		5305-01-145-8379	3	28
15434	3013786		4730-01-161-5115	2	16
				13	5
				35	5
15434	3013810		2910-01-142-7455	24	12
15434	3013811		4820-01-079-3320	24	10
15434	3013904		5305-01-112-9021	2	11
				12	46
15434	3013909		2815-01-105-8768	2	6
15434	3013930		2815-01-086-4508	6	8
15434	3014103		5310-00-081-9292	17	27
15434	3014354		4730-01-127-6104	26	9
15434	3014397		4730-01-109-8501	22	17
15434	3014398		4730-01-146-3633	22	15
15434	3014614		3020-01-146-0107	4	15
15434	3014622		2815-00-132-0240	3	10
15434	3014623		2815-01-127-1060	3	10
15434	3014624		2815-01-127-3597	3	10
15434	3014625		2815-01-127-3598	3	10
15434	3014754		5310-01-144-6224	13	16
15434	3014755		4820-01-145-9457	13	17
15434	3014756		5360-01-148-0303	13	15
15434	3014778		5330-01-147-1274	13	2
15434	3014783		3020-01-084-9640	13	19
15434	3014787		3020-01-146-0109	13	19
15434	3014788		3020-01-146-0108	13	8
15434	3014798		3040-01-146-5935	13	25
15434	3014964		5340-01-145-9451	13	3
15434	3015114		2930-01-146-4212	33	3
15434	3015282		5305-01-129-4384	20	34
				23	7
15434	3015373		4710-01-085-9348	22	9
15434	3015375		4710-01-085-9349	22	18
15434	3015387		4710-01-146-3169	22	18

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	3015389		4710-01-146-1113	22	16
15434	3015393		4710-01-085-6134	22	16
15434	3015469		5310-01-145-1114	21	6
15434	3015520		2910-01-141-4967	24	5
15434	3015522		4820-01-079-3241	24	4
15434	3016456		4710-01-079-3487	26	16
15434	3016637		2815-01-160-5820	5	19
15434	3016887		2815-01-146-7039	7	14
15434	3017031		3040-01-146-0075	7	13
15434	3017049		5305-01-145-8358	12	37
15434	3017051		5305-01-112-9110	29	20
				30	2
15434	3017052		5305-01-126-1128	29	41
15434	3017292		6680-01-108-7410	12	24
				BULK	1
15434	3017748		2930-01-150-7596	33	12
15434	3017750		5330-00-861-8592	8	32
15434	3017759		2815-00-085-7434	3	10
15434	3018098		4710-01-146-1054	33	16
15434	3018099		4710-01-146-1053	14	35
15434	3018153		3120-01-146-7196	20	21
15434	3018488			20	16
15434	3018655		5360-01-134-5602	24	23
15434	3018686		2815-01-146-1102	26	4
15434	3018690			10	11
15434	3018692		2930-01-146-1081	10	28
15434	3018693		5330-01-145-6910	10	10
15434	3018695		5331-01-154-4316	10	23
15434	3018696		5330-01-145-6911	10	9
15434	3018697		5340-01-145-0772	10	41
15434	3018700		2940-01-146-5846	10	25
15434	3018762		5330-01-092-4143	KIT	
15434	3018764		2930-01-146-1085	33	10
15434	3018767		5360-01-147-4846	29	50
15434	3018889		4730-01-146-3040	22	22
15434	3019158		5330-01-145-5380	33	11
15434	3019180		3120-00-695-1232	4	20
15434	3019204		3120-00-593-1507	4	22
15434	3019218		3120-01-214-7779	4	7
15434	3019572		5305-01-147-1215	14	15
15434	3019573		5305-01-145-8359	20	37
15434	3019574		5305-01-145-0776	17	8
15434	3019955		5365-01-147-9802	2	40
15434	3019956		5365-00-488-0799	2	40
15434	3019957		5365-01-147-2496	2	40
15434	3019958		5365-01-147-2497	2	40
15434	3019959		5365-01-148-8353	2	40
15434	3019960		5365-01-147-2495	2	40
15434	3020718		2815-01-150-2702	15	7
15434	3020753			22	30
15434	3020754			22	24

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	3020760		2910-01-146-0093	22	21
15434	3020943		5330-00-659-3178	15	4
15434	3021068		2910-01-142-4953	24	22
15434	302109000		2920-01-121-8859	28	6
15434	3021470		5305-01-144-6233	20	53
15434	3021581		2930-01-065-7113	11	30
15434	3021596		5315-01-145-6080	7	4
15434	3021602			7	3
15434	3021656		4330-01-146-1082	10	24
15434	3021660		2815-01-085-1881	5	11
15434	3021676		2910-01-126-9053	24	15
15434	3021704		5330-01-145-6914	16	11
15434	3021735		5330-01-082-6985	5	25
15434	3022377		4710-01-142-1667	12	25
15434	3022589		5306-01-119-8870	33	22
15434	3022590		5305-01-129-4214	13	6
				19	8
15434	3022821		4710-01-146-3779	22	9
15434	3023088		5310-01-142-2812	24	13
15434	3023101		5360-01-086-3480	20	47
15434	3023171		2910-01-141-4029	24	7
15434	3023473		3020-01-146-3163	17	17
15434	3023506		3010-01-146-0113	13	30
15434	3023512		2930-01-145-9537	10	4
15434	3023556		2910-01-146-1998	21	10
15434	3023870		5330-01-142-2784	24	8
15434	3024165		3040-00-449-7397	32	6
15434	3024365		4310-01-141-0879	20	8
15434	3024442		2815-01-159-0872	16	1
15434	3024666		4710-01-146-3086	11	37
				33	27
15434	3024709		5330-01-145-5381	33	29
15434	3024960		5330-01-146-7314	33	21
15434	3024991		2910-01-090-9346	29	35
15434	3025459		5342-01-143-6046	29	40
15434	3025460		4730-01-124-3762	24	27
				30	15
15434	3025611		4730-01-146-3631	26	14
15434	302586100		3020-01-241-6905	35	13
15434	3026034		3130-01-146-6120	27	14
15434	3026163		5330-01-136-8569	25	13
15434	3026198		2910-01-085-2570	30	1
15434	3026556		3120-01-147-5275	17	21
15434	3026557		3120-01-144-7368	17	28
15434	3026733			24	64
15434	3026993		2990-01-146-3911	27	19
15434	3026999		4710-01-146-1112	19	17
15434	3027282		9905-01-147-0933	1	8
15434	3027308		2990-01-085-4768	27	8
15434	3027460		2930-01-145-9538	10	8
15434	3027496		5330-01-145-6909	10	22

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	3027653			15	8
15434	3028075		3120-01-208-8102	2	30
15434	3028171		5342-01-145-0646	21	2
15434	3028269		3120-01-208-8103	2	30
15434	3028279		5305-01-145-0777	21	3
				23	6
15434	3028281		2930-01-146-3033	33	17
				33	23
15434	3028282		2930-01-146-1996	14	9
15434	3028368		2910-01-141-4337	29	19
15434	3028642		4710-01-146-3168	19	17
15434	3028685			6	5
15434	3028967		5305-01-147-8729	14	30
15434	3028997		2930-01-141-9277	14	34
15434	3029514		2950-01-141-0844	26	22
15434	3029614		2815-01-146-3159	15	2
15434	3029846		5330-01-145-6913	13	34
15434	3029847		5331-01-145-0715	13	47
15434	3029852		3120-00-877-2213	16	2
15434	3030038		2815-01-159-1789	3	16
15434	3030257			12	7
15434	3030267		6680-01-085-2870	29	1
				29	19
15434	3030269		2910-01-146-1999	29	1
15434	3030286		5305-01-147-2445	14	28
15434	3030445		2910-01-145-9403	21	4
15434	3030803		5360-01-145-3974	10	15
15434	3030804		2940-01-145-9399	10	13
15434	3030805		4820-01-210-3573	10	16
15434	3030806		2940-01-145-9400	10	14
15434	3030808		5331-01-145-6086	10	18
15434	3030970		4820-01-146-1048	28	11
15434	3031005		5305-01-144-6232	10	19
15434	3031186		2815-01-146-1103	15	1
15434	3031187		2815-01-146-0112	15	3
15434	3031434		5330-01-147-4071	13	49
15434	3031560		4720-01-085-2571	11	5
15434	3031749		2815-01-146-0102	5	5
15434	3031750			5	4
15434	3031751			5	1
15434	3031752		3040-01-146-0028	5	3
15434	3031753		3120-01-147-8118	5	6
15434	3031858		5330-01-145-6912	10	30
15434	3031959		2815-01-141-0919	12	2
15434	3031962		4710-01-146-0050	13	33
15434	3031980		4140-01-146-1035	27	3
15434	3032307		2930-01-141-0918	10	1
15434	3032348		5330-01-147-4072	14	8
15434	3032674		5305-01-145-1113	12	39
15434	3032681		2815-01-085-2615	7	7
15434	3032707		4710-01-146-1052	12	6

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	3032708		5340-01-146-9992	12	5
15434	3032835		2950-01-145-6822	27	18
15434	3032861		5330-01-147-0748	12	1
15434	3033719		3120-01-185-8586	25	19
15434	3033724		3120-01-215-9157	25	17
15434	3033740		4820-01-164-7002	25	15
15434	3034243		2815-01-291-5753	25	1
15434	3034578		2940-01-145-9398	10	12
15434	3034579			10	43
15434	3034736			27	17
15434	3035028		5930-01-177-0346	10	21
15434	3035053			23	8
				29	46
15434	3035362		4810-01-187-4925	28	4
15434	3035595			10	44
			4710-01-158-7507	26	20
15434	3035600		4710-01-146-3167	26	16
15434	3035607		5340-01-145-0773	14	31
15434	3035961		2815-01-085-2569	8	1
15434	3036005		2815-01-141-0845	5	19
15434	3036285		2815-01-210-6947	8	30
15434	3036933		3120-01-212-4472	7	21
15434	3036934		3120-01-079-5451	7	27
15434	3036935		2815-01-146-7914	7	16
15434	3038035		4710-01-146-0049	12	15
15434	3038037		4710-01-146-1115	22	10
15434	3038060		4710-01-079-3492	19	13
15434	3038218		2910-00-132-0769	29	52
15434	3038745		3130-01-294-1400	27	14
15434	3038997		5330-01-240-1630	35	6
15434	3038998		5330-01-080-2992	35	12
				35	20
15434	3039070		2910-01-070-9712	24	62
15434	3039296		5360-01-145-3975	10	17
15434	3040180			3	23
15434	3041993		2815-01-085-8282	3	1
15434	3043647		5305-01-147-8730	15	5
15434	3043649		5305-01-319-9287	34	11
15434	3044514		5330-01-145-3985	9	6
15434	3045049			25	14
15434	3045173			29	21
15434	3045551		7690-01-094-6720	1	8
15434	3045979		5331-01-145-6085	10	5
15434	3046170		2930-01-146-1083	14	4
15434	3047159		5330-00-131-7072	20	13
15434	3047963		5340-01-145-0647	21	5
15434	3049024		2815-01-146-1049	7	5
15434	3050394		3040-01-287-9736	35	7
15434	3050624		4820-01-242-2579	25	10
15434	3051555		2815-01-077-1482	6	5
15434	3054071		2910-01-112-7712	21	4

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	3056158		5310-01-287-9737	26	13
15434	3056569		2910-01-086-9757	7	22
15434	3058664		5306-01-146-9866	16	19
15434	3060199-4128		2910-01-065-3979	23	6
15434	3060202-3894		2910-01-141-9372	23	6
15434	3060882		4730-01-309-3321	11	25
15434	3064919			35	19
15434	3066796		2815-01-166-3415	7	11
15434	3067616		5330-00-361-2955	4	1
15434	3071085		5330-00-005-0407	35	3
15434	3074400		5330-01-146-7172	7	8
15434	3074401		5330-01-145-3983	7	8
15434	3074402		5330-01-146-9775	7	8
15434	3074403		5330-01-146-9928	7	8
15434	3074404		5330-01-145-3984	7	8
15434	3076189		5330-01-080-5021	3	23
06991	309015		5930-01-095-9823	31	10
15434	320-1850		5330-01-181-0631	20	5
15434	3201386		5330-01-181-0630	19	11
06991	321030-02		6620-01-203-4301	31	16
33457	3300922S		2940-01-065-7076	11	47
24617	3305L1A		3110-00-144-8828	35	8
				35	24
33457	3305367		4330-00-274-4712	34	9
33457	3308958		5330-01-164-0944	11	48
15434	3375014		4910-01-097-6935	44	26
15434	3375015		5330-01-107-1841	44	23
15434	3375049		5120-01-160-8863	37	1
15434	3375108		4910-01-097-6930	37	5
15434	3375137		4910-01-097-6939	40	12
15434	3375140		4910-01-097-6940	40	9
15434	3375146		4910-01-097-6941	40	10
15434	3375147			40	11
15434	3375148		4910-01-097-6943	40	8
15434	3375150		4910-01-085-9211	36	27
15434	3375151		4910-01-165-4541	48	11
15434	3375153		4910-01-105-9165	44	1
15434	3375154		4910-01-097-6912	40	19
				40	19
15434	3375160		4910-01-097-6926	42	9
15434	3375162		5120-01-128-2758	50	4
15434	3375165		4910-01-097-6927	42	10
15434	3375166		4910-01-097-6928	42	11
15434	3375172		4910-01-097-6936	42	15
15434	3375173			42	14
15434	3375174		4910-01-097-6938	42	13
15434	3375180		4910-01-097-6989	37	6
				38	2
15434	3375182		4910-01-142-4929	48	1
15434	3375189		5180-01-102-8418	40	7
15434	3375192		4910-01-143-2023	48	2

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	3375204		4910-01-118-3747	40	6
15434	3375205		4910-01-097-6985	38	23
15434	3375207		4910-01-084-7221	44	10
15434	3375220		4930-01-085-3728	44	5
15434	3375221		4910-01-084-6977	44	12
15434	3375222		4910-01-084-6978	44	13
15434	3375223		4910-01-085-0751	44	3
15434	3375224		5355-01-084-5323	44	11
15434	3375225		4910-01-084-7222	44	9
15434	3375226		4910-01-085-7269	44	8
15434	3375227			44	7
15434	3375228		5355-01-097-7072	44	6
15434	3375229		4910-01-084-6979	44	4
15434	3375230		4910-01-097-6944	44	24
15434	3375232		4910-01-097-6929	51	6
15434	3375265			48	5
15434	3375271		4910-01-097-6945	45	1
15434	3375282		4910-01-097-6971	38	12
15434	3375425		4910-00-150-5858	36	14
15434	3375432		6850-00-145-0255	50	5
15434	3375448		5120-01-128-2675	48	6
15434	3375455		4910-01-150-9713	46	5
15434	3375522			42	16
15434	3375599		5120-01-128-2688	51	3
15434	3375601		4910-01-165-6016	50	6
15434	3375614		4910-01-097-6969	38	5
15434	3375615			38	4
15434	3375616		5120-01-120-3682	38	3
				38	3
15434	3375825		4910-01-097-6970	38	2
15434	3375834		5120-01-120-5759	43	15
15434	3375839		4910-01-097-6909	43	16
15434	3375855		4910-01-074-0020	45	8
15434	3375959		4910-01-143-2034	50	7
15434	3376011		4910-01-152-2743	50	8
15434	3376015			51	1
15434	3376050		5210-01-157-2291	48	7
15434	3376177		5120-01-120-3681	44	14
15434	3376197			44	17
15434	3376220		5210-01-157-3091	51	2
15434	3376326		5120-01-156-4183	38	18
15434	3376619		6625-01-232-5469	41	4
15434	3376663		5120-01-128-2678	47	7
15434	3376669			41	7
15434	3376720		5180-01-074-0019	42	12
15434	3376815		4910-01-143-3336	48	4
15434	3376816		4910-01-143-3337	48	3
15434	3376845		5120-01-072-2952	37	7
15434	3376872		5120-00-116-7604	47	10
15434	3376903		5110-00-981-3107	41	3
15434	3376904		4910-01-085-0765	43	12

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	3558653		4310-01-079-3319	20	25
15434	3558655		2815-00-369-7846	20	20
15434	3608833		2815-01-303-4224	4	6
01212	3725CP-30		3120-01-155-8707	6	12
15434	3801047		2815-01-079-3380	7	5
15434	3801048			2	36
15434	3801056		2815-01-165-0765	KIT	
15434	3801058		2815-01-168-3742	KIT	
15434	3801096		2990-01-271-0316	KIT	
15434	3801106		3120-01-155-2531	KIT	
15434	3801235		5330-01-150-9812	35	30
15434	3801260		3120-01-132-9339	KIT	
15434	3801261		3120-01-143-9547	4	23
15434	3801262		3120-01-144-8882	4	23
15434	3801263		3120-01-145-9132	4	23
15434	3801310		2815-01-141-9370	2	6
15434	3801433		3040-01-079-1799	8	29
15434	3801708		2930-01-146-3912	35	1
15434	380171000		2930-01-287-9733	0035	
15434	380171200		2930-01-262-5153	0035	
15434	3801788		2930-01-072-8056	35	1
15434	3801826		2815-00-011-7786	2	1
15434	3801904		2990-01-155-7284	26	22
15434	3801942		2990-01-172-3005	26	22
15434	3803512		2815-01-354-2702	3	11
15434	3803524		2815-00-962-5623	3	12
15434	3804275		2815-01-152-9219	KIT	
15434	3804280		5330-01-086-7790	KIT	
15434	3821572		2815-01-141-5299	13	1
79470	400X3		4730-00-277-8269	20	80
15434	41044		5342-01-145-9539	12	30
15434	42645		2815-00-484-8359	2	25
15434	42646		3130-00-408-9041	2	24
15434	42647		2815-00-484-8360	2	23
15434	43463-A		5331-00-159-1464	33	20
15434	44383		3120-00-349-6444	4	17
15434	44387		3120-00-090-5504	4	19
72582	444042		4730-00-278-4822	31	17
21450	444683		4730-00-964-7548	20	30
24617	444704		4730-00-555-8292	24	30
15434	44678		2910-00-858-3522	29	38
72582	450517		5305-00-165-8157	11	41
15434	4797		3020-00-528-5053	5	12
79470	49X6X2			11	50
06991	501088-02		5365-01-145-0760	31	12
06991	501096-04		4720-01-146-4126	31	9
01212	5116M40		3120-01-193-7083	4	23

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	538174			3	27
19207	5414243-20			22	10
53496	5561 1-2A		4730-00-555-8263	14	1
				19	3
				26	11
				26	17
19207	57K3602		2815-01-437-3901	1	1
19207	57K3603		2815-01-438-1517	1	1
19207	5704995			51	6
34623	5710454			34	7
34623	5730758		5340-01-145-1597	34	2
34623	5730761		4730-01-165-0749	34	8
34623	5730765		4820-01-227-7141	34	5
34623	5730769			34	10
34623	5731317		5305-01-144-6204	2	37
15434	5995177			32	7
15434	60408		5315-00-238-0882	16	9
15434	60575		5365-00-428-6201	4	9
15434	61554		4720-00-918-9634	19	2
15434	63842		5310-00-134-4169	14	38
15434	64709		5365-01-241-3903	9	7
15434	650330			20	24
15434	65259-A		5365-01-147-0912	16	4
15434	65259-B		5365-01-147-0913	16	4
15434	65259-C		5365-00-507-3254	16	4
15434	65274		5330-00-246-0309	12	31
15434	66292		5310-00-197-5304	2	29
15434	67684		5310-00-262-2986	28	3
15434	67946		5365-00-197-9327	11	24
				12	11
15434	67963		5330-00-171-7267	2	32
15434	68038		5340-01-066-2947	13	39
15434	68061-A		5331-00-970-3461	24	14
15434	68139		4730-01-142-8524	13	51
				22	20
15434	68193		5340-00-404-2944	7	1
15434	68274		5360-00-664-5343	11	23
15434	68365		3120-00-566-0480	13	7
15434	68425		5340-00-839-0653	12	19
15434	68445		5315-00-281-7610	2	7
15434	68585		5315-00-014-1195	2	18
15434	68803-A			3	29
15434	69047-A		5305-01-146-7285	14	29
16954	691-10014			30	16
15434	69324		5310-01-112-4307	20	6
				23	5
				29	5
15434	69519		5315-00-475-2574	13	21
15434	69521		3120-00-627-6697	13	4
				13	26

CROSS-REFERENCE INDEXES

CAGEC	PART NUMBER	PART NUMBER INDEX		FIG.	ITEM
			STOCK NUMBER		
15434	69736		5305-00-339-1415	7	15
15434	69832		5310-00-828-4827	12	3
15434	69962		5365-00-695-1247	12	12
15434	70089-1		5330-00-537-2382	2	13
				11	3
15434	70295		4730-00-011-3175	28	13
15434	70470		4730-01-165-0749	34	5
15434	70550		2815-01-124-0232	6	10
				17	23
15434	70624		5331-00-506-4874	33	2
15434	70653		2815-00-772-9434	16	8
15434	70657		5340-01-122-8002	5	26
15434	70690		2990-00-772-1778	24	63
15434	70700		5360-00-597-4570	24	33
15434	70705		5330-00-562-1176	29	42
15434	70713		5340-00-898-1497	29	44
15434	70715		5310-00-507-3259	29	51
15434	70716		5305-00-506-5722	29	53
15434	70717		5365-00-507-3260	29	46
				29	46
15434	70717-A		5365-00-507-3261	29	45
15434	70717-B		5365-00-507-3262	29	45
15434	70717A		5365-00-507-3261	29	45
15434	70772		5305-00-477-6769	3	20
15434	70772-B		5305-01-129-4385	24	1
15434	70790		5306-00-485-0790	25	7
19207	7374401		5331-00-984-3756	8	28
6Y402	829-4151		2910-01-084-0243	31	4
6Y402	8293635		5930-01-295-0912	31	10
06991	8294151		2815-01-087-4740	31	1
55683	851-202994		4720-01-070-8149	26	6
19207	8710557		4720-01-114-7728	BULK	2
19207	8710557-10			12	43
06991	913020		5340-01-145-1181	31	5
06991	913024-06		2910-01-112-5797	31	15
24617	9417953		5310-01-097-8039	20	78
				20	78
24617	9418993		5305-01-118-4285	20	79
24617	9419002			31	22
29617	9421077		5310-01-102-7356	32	16
29617	9421196		5306-01-102-3599	32	18
24617	9422273		5310-01-312-3859	31	19
24617	9422277		5310-01-126-9404	12	26
15434	9674F			13	38

**APPENDIX C
EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST**

Section I. INTRODUCTION

C-1. SCOPE

This appendix lists expendable/durable supplies and materials you will need to maintain the NTC-400 Big Cam I or Big Cam III Diesel Engine. These items are authorized by CTA 50-970, Expendable Items (Except Medical, Class V, Repair Parts, and Heraldic Items).

C-2. EXPLANATION OF COLUMNS

a. Column (1) - Item Number. This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the material (e.g., "Use antiseize compound, Appendix C, Item 7").

b. Column (2) - Level. This column identifies the lowest level of maintenance that requires the listed item.

C - Operator/Crew
O - Organizational Maintenance
F - Direct Support Maintenance
H - General Support Maintenance

c. Column (3) - National Stock Number (NSN). This is the National Stock Number assigned to the item; use it to request or requisition the item.

d. Column (4) - Description. Indicates the federal item name and, if required, a description to identify the item. The last line for each item indicates the Commercial and Government Entity Code (CAGEC) in parentheses followed by a part number.

e. Column (5) - Unit of Measure (U/C). Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g.; ea, in., pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST

(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) DESCRIPTION	(5) UNIT OF MEASURE
1	F		ACID: muriatic	PT
2	F		ACID: oxalic	PT
3	O		ANTIFREEZE, permanent	
		6850-01-441-3218	ethylene glycol -60°F inhibited, (0-A-548), type I, heavy duty, single package (58536) (A-A-52624)	
		6850-01-441-3221	1 gallon container	GAL.
		6850-01-441-3223	5 gallon can	
			55 gallon drum	
4	O		CLOTH, ABRASIVE (crocus): 9 in. x 11 in. sheets, (58536) A-A-1206	
		5350-00-221-0872	50 sheets/package	PG
5	F	5390-00-584-4554	CLOTH: emery, 290-grit A-A-1049	SH
6	O		CLOTH, CLEANING: lint-free, general purpose, white, (81359) MIL-C-85043	
		7920-00-044-9281	10 pound box	LB
7	O		ANTISEIZE COMPOUND: temperature-resistant lubricant, MIL-A-907, Loctite antiseize, 200°F (93°C), with brush top (05972) 76764	
		8030-00-251-3980	1 pound can	LB
8	F	5350-00-224-6692	COMPOUND: lapping 280-grit SSL-1682	
			1 pound can	LB
9	F	6850-00-664-9067	COMPOUND: Prussian blue MIL-L-83795	
			1 pint can	PT
10	F	6850-01-241-0651	DEVELOPER: spotcheck, SKD-NF	
			1 pint can	PT
11	F	9150-00-698-2382	FLUID: automatic transmission, type A, AOATF1562A	
			1 quart can	QT
12	F	6850-00-974-3788	FLUID, CALIBRATION- INJECTOR TEST STAND, 45A	
			1 pint can	PT
13	C		GREASE, AUTOMOTIVE AND ARTILLERY: (MIL-G-10924) (81349)	
		9150-01-197-7698	2-1/4 oz tube	OZ
		9150-01-197-7690	1-3/4 pound can	LB
		9150-01-197-7689	6-1/2 pound can	LB
		9150-01-197-7692	35 pound can	LB
		9150-00-190-7369	120 pound drum	LB

EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST (Contd)

(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) DESCRIPTION	(5) UNIT OF MEASURE
14	F	8030-00-081-2330	LOCTITE MIL-S-22473 (grade CV) 1 50 cubic centimeter bottle	CC
15	F	9150-00-458-0075	LUBRICANT, high-pressure Brayco 300 1/16 ounce	OZ
16	F	9150-00-231-9045	LUBRICANT: rust preventative 1 gallon can	GAL.
17	F	8010-00-837-7969	MINERAL SPIRITS TT-T-291	GAL.
18	F	9150-00-265-9406	CUTTING FLUID: (81348) C-O-376 1 gallon can	GAL.
19	C	9140-00-286-5294 9140-00-286-5295 9140-00-286-5296 9140-00-256-5297	OIL, FUEL: diesel, regular DF-2, VV-F-800 bulk 5 gallon can 55 gallon drum, 16-gauge 55 gallon drum, 18-gauge	GAL. GAL. GAL. GAL.
20	C	9150-00-189-6727 9150-00-186-6668 9150-00-191-2772 9150-00-183-7807	OIL, LUBRICATING: OE/HDO 10 MIL-L-2104C 1 quart can 5 gallon drum 55 gallon drum, 18-gauge bulk	QT GAL. GAL. GAL.
21	C	9150-00-186-6681 9150-00-188-9858 9150-00-265-9476 9150-00-189-6729 9150-00-183-7808	OIL, LUBRICATING: OE/HDO 30 MIL-L-2104C 1 quart can 5 gallon drum 55 gallon drum, 16-gauge 55 gallon drum, 18-gauge bulk	QT GAL. GAL. GAL. GAL.
22	O		OIL, LUBRICATING: gear 60-80/140, MIL-L-2105C 1 quart can 5 gallon drum 55 gallon drum	QT GAL. GAL.
23	F	5350-00-543-3600	PAPER: aluminum oxide 240-grit ALOXGRIT 80 90 pound per ream	LB
24	F	6810-00-227-0407	PYRIDINE 1 16 ounce bottle	OZ

EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST (Contd)

(1) ITEM NUMBER	(2) LEVEL	(3) NATIONAL STOCK NUMBER	(4) DESCRIPTION	(5) UNIT OF MEASURE
25	F	8030-00-247-2524	SEALANT: gasket MIL-S-45180 2 ounce tube	OZ
26	O	8030-00-204-9149	SEALING COMPOUND, pipe sealant (05972) 59241 250-cubic centimeter bottle	CC
27	O	8030-01-104-5392	SEALING COMPOUND: liquid, type II, grade N, Loctite 242 (05972) 24221 10-cubic centimeter bottle	CC
28	F	6810-00-985-7129	SODIUM CARBONATE (5 percent solution) MIL-R-23679 2 ounce bottle	OZ
29	C	N/A	SOLUTION: soap	N/A
30	C	6850-01-277-0595 6850-01-244-3207	SOLVENT, DRYCLEANING, SD-3: type III, biodegradable (81348) 134 Hi-Solv 5 gallon 55 gallon drum	GAL. GAL.
31	O	5340-00-450-5718	CAP AND PLUG SET: (19207) 10935405 1 SET	EA

**APPENDIX D
ILLUSTRATED LIST OF MANUFACTURED ITEMS**

Section I. INTRODUCTION

D-1. GENERAL

- a. This appendix includes complete instructions for authorizing items to be manufactured or fabricated at Direct Support and General Support maintenance levels.
- b. A part number index in alphanumeric order is provided. The index cross-references the part number of the item to be manufactured to the figure. The figure covers fabrication criteria.
- c. All bulk materials needed for manufacture of an item are listed by part number or specification number in a tabular list on the illustration.

D-2. MANUFACTURED ITEMS PART NUMBER INDEX

ITEM NO.	PART NO.	DESCRIPTION	FIGURE NO.
1	199453	Oil level dipstick	D-1
2	—	Vibration damper guide pin (Two required)	D-2
3	—	Flywheel housing guide pin (Two required)	D-3

Section II. ILLUSTRATED MANUFACTURING INSTRUCTIONS




Figure D-1. Oil Level Dipstick.

INSTRUCTIONS:

1. Fabricate from NSN 6680-01-108-7410.
2. Measure 39.13 in. (994 mm) down dipstick from bottom of rubber stopper and cut dipstick. Round off tip of dipstick as shown above.

NOTE

Use an electric engraver to perform etching in steps 3, 4, and 5. Etch dipstick to a depth of 0.005 to 0.010 in. (0.127 to 0.254 mm).

3. Measure 36.31 in. (992 mm) down dipstick from bottom of rubber stopper and etch a line on dipstick at this length. Etch an "H" next to this line as shown above.
4. Measure 2.06 in. (52 mm) down dipstick from line etched in step 3 and etch another line at this length. Etch an "L" next to this line as shown above.
5. Etch part number "199453" on dipstick near rubber stopper as shown above.




Figure D-2. Vibration Damper Guide Pin.

INSTRUCTIONS:

1. Fabricate from NSN 5305-00-795-9336.
2. Cut off head of screw.
3. Round off edge of nonthreaded end as shown above.
4. Cut a slit approximately 0.062 in. (1.57 mm) wide and 0.125 in. (3.17 mm) deep in nonthreaded end as shown above.
5. Remove any burrs after cutting.









Figure D-3. Flywheel Housing Guide Pin.

INSTRUCTIONS:

1. Fabricate from NSN 5305-01-145-8380.
2. Cut off head of screw.
3. Round off edge of nonthreaded end as shown above.
4. Cut a slit approximately 0.062 in. (1.57 mm) wide and 0.0125 in. (3.17 mm) deep in non-threaded end as shown above.
5. Remove any burrs after cutting.

APPENDIX E
TORQUE LIMITS

USAGE	MUCH USED	MUCH USED	USED AT TIMES	USED AT TIMES				
Capscrew diameter and minimum tensil strength (PSI)	To 1/2-69,000 (475,755 kPa)	To 3/4-120,000 (827,400 kPa)	To 5/8-140,000 (965,300 kPa)	150,000 (1,034,250 kPa)				
	To 3/4-64,000 (441,280 kPa)	To 1-115,000 (792,925 kPa)	To 3/4-133,000 (917,035 kPa)					
	To 1-55,000 (379,225 kPa)							
QUALITY MATERIAL	INDETERMINATE	MINIMUM COMMERCIAL	MEDIUM COMMERCIAL	BEST COMMERCIAL				
SAE GRADE NUMBER	1 OR 2	5	6 OR 7	8				
CAPSCREW HEAD MARKINGS: Manufacturer's marks may vary. These are all SAE Grade 5:								
								
CAPSCREW BODY SIZE (INCHES) - (THREAD)	TORQUE (LB-FT) (N·m)		TORQUE (LB-FT) (N·m)		TORQUE (LB-FT) (N·m)			
1/4 - 20	5	6.8	8	10.8	10	13.6	12	16.3
- 28	6	8.1	10	13.6			14	18.9
5/16 - 18	11	14.9	17	23.1	19	25.8	24	32.5
- 24	13	17.6	19	25.8			27	36.6
3/8 - 16	18	24.4	31	42.0	34	46.1	44	59.7
- 24	20	27.1	35	47.5			49	66.4
7/16 - 14	28	37.9	49	66.4	55	74.6	70	94.9
- 20	30	40.7	55	74.6			78	105.8
1/2 - 13	39	52.9	75	101.7	85	115.3	105	142.4
- 20	41	55.6	85	115.3			120	162.7
9/16 - 12	51	69.2	110	149.1	120	162.7	155	210.1
- 18	55	74.6	120	162.7			170	230.5
5/8 - 11	83	112.5	150	203.3	167	226.4	210	284.7
- 18	95	128.8	170	230.5			240	325.4
3/4 - 10	105	142.4	270	366.1	280	379.6	375	508.4
- 16	115	155.9	295	400.0			420	569.4
7/8 - 9	160	216.9	395	535.5	440	596.6	605	820.3
- 14	175	237.3	435	589.8			675	915.2
1 - 8	235	318.6	590	799.9	660	894.8	910	1,233.8
- 14	250	339.0	660	894.8			990	1,342.2

Section I. STANDARD TORQUE SPECIFICATIONS

1. Always use the torque values listed on previous page when specifications are not available.

NOTE

Do not use listed values in place of those specified in this manual; special attention should be observed in case of SAE Grade 6, 7, and 8 screw.

2. Torques are based on use of clean and dry threads.
3. Reduce torque by 10 percent when oil is used as a lubricant.
4. Reduce torque by 20 percent if newly plated screws are used.

CAUTION

Screws threaded into aluminum may require reductions in torque of 30 percent or more unless inserts are used.

Section II. ENGINE ASSEMBLY TIGHTENING SPECIFICATIONS

PART NAME OR LOCATION	LB-FT	N•m
Main Bearing Capscrews		
Step 1 Torque to	85	115.3
Step 2 Torque to	250-260	339.0-352.5
Step 3 Loosen all	3 to 5 threads	
Step 4 Torque to	85	115.3
Step 5 Torque to	250-260	339.0-352.5
Connecting Rod Nut		
Step 1 Torque to	70-75	94.9-101.7
Step 2 Torque to	140-150	189.8-203.3
Step 3 Loosen all	Completely	
Step 4 Torque to	25-30	33.9-40.7
Step 5 Torque to	70-75	94.9-101.7
Step 6 Torque to	140-150	189.8-203.3
Vibration Damper Mounting Capscrews	180-200	244.0-271.2
Piston Cooling Nozzle Hex-Head Screw	NOTE: 100-140 lb-in.	11.3-15.8
Front Cover	45-55	61.0-74.6
Front Support	55	74.6
Cylinder Head Capscrews		
Step 1	20-25	27.1-33.9
Step 2	80-100	108.5-135.6
Step 3	265-305	359.3-413.5
Valve Crosshead Nuts with ST-669 Adapter	22-26	29.9-35.3
Fuel Fittings	NOTE: 150 lb-in.	16.9
Fuel Crossover Capscrews	NOTE: 34-38 lb-in.	3.8-4.3
Rocker Lever Housing Capscrews	55-65	74.6-88.1
Injector Adjusting Screw	NOTE: 72 lb-in.	8.1
Locknuts with ST-669 Adapter	30-35	40.7-47.5
Valve Locknuts	40-45	54.2-61.0
Rocker Cover Capscrews		
Cork Gasket	12-17	16.3-23.1
Cork and Rubber Gasket	NOTE: 75-95 lb-in.	8.5-10.7
Cam Follower Capscrews	30-35	40.7-47.5
Fuel Pump Front Cover Capscrews	9-11	12.2-14.9
Governor Spring Pack Capscrews	9-11	12.2-14.9
Brass Filter Fittings	30-40	40.7-54.2
Gear Pump Capscrews	11-13	14.9-17.6
Throttle Shaft Plug	NOTE: 40-55 lb-in.	4.5-6.2
Fuel Filter Bracket Capscrews	25	33.9
Fuel Pump Mounting Capscrews	30-35	40.7-47.5
Fuel Injector Orifice Plug	NOTE: 8-10 lb-in.	10.8-13.6
Oil Pan		
Captive Washer Screws	35-40	47.5-54.2
Hex-Head Screws	15-20	20.3-27.1

PART NAME OR LOCATION	LB-FT	N•m
Oil Pan Drainplug	60-70	81.4-94.9
Oil Suction Tube Mounting Capscrews	30-35	40.7-47.5
Oil Cooler Mounting Capscrew	30-35	40.7-47.5
Oil Pump Mounting Capscrews	35-45	47.5-61.0
Adjustable Water Pump Pulley		
Hex-Head Screw	12-15	16.3-20.3
Locknut	45-55	61.0-74.6
Water Header Plates	NOTE: 72-96 lb-in.	8.1-10.8
Hose Clamps		
Water Pump Mounting	30-35	40.7-47.5
Water Manifold	30-35	40.7-47.5
Exhaust Manifold		
7/16 in. Capscrews with Washer	40-45	54.2-61.0
3/8 in. Studs	20-25	27.1-33.9
ST-46 Turbocharger		
Band	NOTE: 32-36 lb-in.	3.6-4.1
Diffuser Plate	NOTE: 60-84 lb-in.	6.8-9.5
Air Crossover Hose Clamp	NOTE: 30-35 lb-in.	3.4-3.9
Oil Drain Fitting	50	67.8
Oil Inlet Fitting	20-25	27.1-33.9
Rotor Locknut	20-24	27.1 32.5
Mounting Locknut	22-48	29.9-65.1
Intake Manifold	20-25	27.1 33.9
Air Compressor		
Support	30-35	40.7-47.5
Compact Head Capscrews	15-19	20.3-25.8
Unloader Body Capscrews	NOTE: 96-120 lb-in.	10.8-13.6
Mounting Capscrews		
Flywheel Capscrews	190-200	257.6-271.2
Flywheel Capscrews with Hardened Washers	200-220	271.2-298.3
Flywheel Housing Capscrews	140-160	189.8-216.9
Accessory Drive Pulley Assembly	300-310	406.8-420.3
Accessory Drive Pulley	40-45	54.2-61.0
Aftercooler		
Cover Capscrews	25	33.9
Water Inlet and Outlet Flange Mounting Capscrews	27-32	36.6-43.4
Water Outlet Connection	15-20	20.3-27.1
Mounting Capscrews	20-25	27.1-33.9

**APPENDIX F
WEAR LIMITS AND TOLERANCES**

F-1. GENERAL

a. All parts, components, or assemblies which do not meet the minimum wear standards specified in this appendix will be replaced with new material.

b. All used parts, components, or assemblies considered for reuse must comply with the minimum wear, fit, and tolerance standards specified in this appendix. Parts must be closely inspected to ensure there is no damage in areas not listed in the wear limits, which would make them unfit for further use.

F-2. REPAIR STANDARDS

MEASUREMENT	WEAR LIMIT	NEW MINIMUM	NEW MAXIMUM
CYLINDER BLOCK SPECIFICATIONS			
Camshaft Bushing			
Inside Diameter	2.5023 (6.3558 cm)	2.4983 (6.3457 cm)	2.5013 (6.3533 cm)
Camshaft Bushing Bore			
Inside Diameter	2.6265 (6.6764 cm)	2.6245 (6.6662 cm)	2.6255 (6.6688 cm)
Cylinder Liner Counterbore			
Inside Diameter		6.5615 (16.6662 cm)	6.6255 (16.8288 cm)
Depth	0.412 (10.465 mm)	0.350 (8.89 mm)	0.352 (8.941 mm)
Liner to Block Clearance			
Lower Bore		0.002 (0.0508 mm)	0.006 (0.152 mm)
Lower Liner Bore			
Inside Diameter		6.124 (15.555 cm)	6.126 (15.560 cm)
Main Bearing Bore			
Inside Diameter	4.7505 (12.066 cm)	4.7485 (12.0612 cm)	4.750 (12.065 cm)
Block			
Height from Main Bearing Centerline	18.994 (48.245 cm)	19.003 (48.268 cm)	19.007 (48.278 cm)
Height from Installed Alignment	16.619 (42.212 cm)	16.628 (42.235 cm)	16.632 (42.245 cm)
Cylinder Liner			
Inside Diameter	5.505 (13.983 cm)	5.4995 (13.9687 cm)	5.501 (13.973 cm)
NOTE			
New cylinder liner dimensions at 60°-70°F (16°-21°C); may be 0.0002-0.0006 in. (0.00508-0.01524 mm) smaller than indicated due to the lubricating oil coating.			
Protrusion (installed)		0.003 (0.076 mm)	0.006 (0.152 mm)
Crankshaft			
Connecting Rod Journal			
Outside Diameter	3.122 (7.930 cm)	3.1235 (7.9337 cm)	3.125 (7.938 cm)
Main Bearing Journal			
Outside Diameter	4.4975 (11.4237 cm)	4.4985 (11.4262 cm)	4.500 (11.4 cm)
Thrust Bearing Surface-to-Rear Counterweight			
	3.006 (7.635 cm)	3.001 (7.623 cm)	3.003 (7.628 cm)

MEASUREMENT	WEAR LIMIT	NEW MINIMUM	NEW MAXIMUM
CYLINDER BLOCK SPECIFICATIONS (Contd)			
Main and Rod Journals Out-of-Round TIR*	0.002 (0.0508 mm)		
Main and Rod Journal Taper (Length of Journal)	0.005 (0.127 mm)		
Main Bearings			
Shell Thickness	0.1215 (3.0861 mm)	0.123 (3.124 mm)	0.1238 (3.1445 mm)
Journal Clearance	0.007 (0.1778 mm)	0.0015 (0.0381 mm)	0.005 (0.127 mm)
Rod Bearings Shell Thickness	0.093 (2.372 mm)	0.00942 (0.23927 mm)	0.0947 (2.4054 mm)
Crankshaft Thrust Ring 157280 Std Thickness (Measured Midway Between Oil Grooves)			
	**	0.245 (6.223 mm)	0.247 (6.274 mm)
Crankshaft End Clearance (Installed)	0.022 (0.559 mm)	0.007 (0.178 mm)	0.017 (0.432 mm)
Connecting Rod			
Crankpin Bore Inside Diameter		3.3157 (8.4219 cm)	3.3167 (8.4244 cm)
Center-to-Center Length		11.998 (30.475 cm)	12.000 (30.5 cm)
Piston Pin Bushing			
Inside Diameter	2.0022 (5.0856 cm)	2.0010 (5.0825 cm)	2.0015 (5.0838 cm)
Connecting Rod			
Bend (w/o bushing)	0.010 (0.254 mm)		0.010 (0.254 mm)
Bend (w/bushing)	0.004 (0.102 mm)		0.004 (0.102 mm)
Twist (w/o bushing)	0.020 (0.51 mm)		0.020 (0.51 mm)
Twist (w/bushing)	0.010 (0.25 mm)		0.010 (0.25 mm)
Connecting Rod Capscrew			
Minimum Outside Diameter	0.583 (14.808 mm)	0.584 (14.834 mm)	0.590 (14.99 mm)
Pilot Outside Diameter	0.637 (16.180 mm)	0.638 (16.205 mm)	0.643 (16.332 mm)
Dowel and Pilot (2-Capscrew Rod)			
Dowel Diameter		0.3127 (7.9426 mm)	
Rod Dowel Hole		0.3128 (7.9451 mm)	0.3133 (7.9578 mm)
Dowel Protrusion		0.220 (5.59 mm)	0.250 (6.35 mm)
Dowel Press Fit in Cap		0.0001 (0.0025 mm)	0.0006 (0.0152 mm)
Piston			
Skirt Diameter at 70°F	5.483 (13.972 cm)	5.487 (13.937 cm)	5.488 (13.930 cm)
Piston Pin Bore Inside Diameter at 70°F	2.0000 (5.08 cm)	1.9985 (5.0762 cm)	1.9990 (5.077 cm)
Piston Pin			
Outside Diameter	1.9985 (5.0762 cm)	1.99875 (5.07683 cm)	1.9990 (5.077 cm)
Gap in Ring Travel Area of Liner			
Piston Ring Part No. 3012331	**	0.023 (0.584 mm)	0.033 (0.838 mm)
Piston Ring Part No. 3012332	**	0.019 (0.483 mm)	0.029 (0.737 mm)
Piston Ring Part No. 214730	***	0.019 (0.483 mm)	0.029 (0.737 mm)
Piston Ring Part No. 218732	***	0.01 (0.25 mm)	0.025 (0.635 mm)

* TIR = Total Indicated Runout

** Use Crankshaft End Clearance

*** Add 0.003-in. (0.076 mm) ring gap to new maximum limit for each 0.001-in. (0.025 mm) wear in cylinder liner wall

MEASUREMENT	WEAR LIMIT	NEW MINIMUM	NEW MAXIMUM
CYLINDER BLOCK SPECIFICATIONS (Contd)			
Camshaft Journal			
Outside Diameter	2.495 (6.337 cm)	2.496 (6.340 cm)	2.497 (6.342 cm)
Thrust Bearing Thickness	0.083 (2.108 mm)	0.093 (2.362 mm)	0.098 (2.489 mm)
Support Bushing			
Inside Diameter	1.370 (3.480 cm)	1.3725 (3.4862 mm)	1.3755 (3.4938 cm)
Outboard Bearing Support			
Inside Diameter	1.757 (4.463 cm)	1.751 (4.448 cm)	1.754 (4.455 cm)
Gear Case Cover Accessory			
Drive Bushing (132770) (Std)			
Inside Diameter	1.571 (3.990 cm)	1.565 (3.975 cm)	1.569 (3.985 cm)
Cylinder Head			
Height	4.430 (11.25 cm)	4.370 (11.100 cm)	4.380 (11.130 cm)
Valve Stem			
Outside Diameter	0.449 (11.405 mm)	0.450 (11.430 mm)	0.451 (11.455 mm)
Face Angle		30°	30°
Valve Guide			
Inside Diameter	0.455 (11.557 mm)	0.4525 (11.4935 mm)	0.4532 (11.5113 mm)
Assembled Height		1.270 (3.230 cm)	1.280 (3.250 cm)
Valve Seat Insert			
Outside Diameter		2.0025 (5.0864 cm)	2.0035 (5.0889 cm)
Cylinder Head			
Inside Diameter		1.9995 (5.0787 cm)	2.0005 (5.0813 cm)
Insert Height		0.278 (7.061 mm)	0.282 (7.163 mm)
Seat to Guide Bore	0.002 (0.051 mm)		
Concentricity			
Refaced Seat Width		0.063 (1.600 mm)	0.125 (3.175 mm)
Valve Spring			
Assembled Height			2.250 (5.720 cm)
Crosshead Guide			
Outside Diameter	0.432 (10.973 mm)	0.433 (10.998 mm)	0.4335 (11.0109 mm)
Assembled Height		1.860 (4.724 cm)	1.880 (4.780 cm)
Crosshead Bore	0.440 (11.180 mm)	0.434 (11.024 mm)	0.436 (11.074 mm)
Injector Tip			
Protrusion		0.060 (1.520 mm)	0.070 (1.780 cm)
ROCKER LEVER SPECIFICATIONS			
Bushing			
Inside Diameter	1.1286 (2.866 cm)	1.1245 (2.8562 cm)	1.1275 (2.8639 cm)
Shaft			
Outside Diameter	1.122 (2.850 cm)	1.123 (2.852 cm)	1.124 (2.855 cm)
Shaft			
Outside Diameter	0.748 (18.999 mm)	0.7485 (19.0119 mm)	0.7490 (19.0250 mm)

MEASUREMENT	WEAR LIMIT	NEW MINIMUM	NEW MAXIMUM
CYLINDER BLOCK SPECIFICATIONS (Contd)			
Bushing			
Inside Diameter	0.752 (19.101 mm)	0.7501 (19.0525 mm)	0.7511 (19.0779 mm)
Injector Cam Roller			
Inside Diameter	0.705 (17.907 mm)	0.703 (17.856 mm)	0.704 (17.882 mm)
Valve Cam Roller			
Inside Diameter	0.503 (12.776 mm)	0.5005 (12.7127 mm)	0.5015 (12.7381 mm)
Outside Diameter	1.2485 (3.1712 cm)	1.2495 (3.1737 cm)	1.2505 (3.1763 cm)
Cam Roller Pin Diameter			
Valve	0.497 (12.624 mm)	0.4997 (12.692 mm)	0.500 (12.7 mm)
Injector	0.697 (17.704 mm)	0.6997 (17.7724 mm)	0.700 (17.780 mm)
Diameter of Bore for Roller Pin			
Valve		0.4990 (12.6746 mm)	0.4995 (12.6873 mm)
Injector		0.6992 (17.7597 mm)	0.6997 (17.7725 mm)
LUBRICATING OIL PUMP SPECIFICATIONS			
Bushing			
Inside Diameter	0.8785 (22.3139 mm)	0.8765 (22.2631 mm)	0.8775 (22.2885 mm)
Idler and Drive Shaft			
Outside Diameter	0.8740 (22.1996 mm)	0.8745 (22.2123 mm)	0.8750 (22.2250 mm)
Idler Shaft Protrusion (Above Body to Cover Face)			
		0.705 (17.907 mm)	0.735 (18.669 mm)
Drive Shaft from Pump Body Protrusion			
		1.990 (5.055 cm)	2.010 (5.105 cm)
Drive Shaft from Pump Drive Gear			
		0.050 (1.27 mm)	0.070 (1.778 mm)
Piston Cooling Oil Tube Protrusion Above Body (Mounting Face)			
		2.970 (7.544 cm)	3.000 (7.620 cm)
Filter/Cooler Pressure Regulator Spring Free Length			
			3.410 (8.661 cm)
Recommended Oil Pressure (PSI)			
		35 (241 kPa)	45 (310 kPa)
COOLING SYSTEM SPECIFICATIONS			
Water Pump			
Impeller to Shaft Press-Fit		0.001 (0.025 mm)	
Pulley to Shaft Press-Fit		0.001 (0.025 mm)	
Impeller to Body Clearance (Phenolic)		0.030 (0.762 mm)	0.050 (1.27 mm)
DRIVE UNIT SPECIFICATIONS			
Shaft			
Outside Diameter	1.310 (3.327 cm)	1.3115 (3.3312 cm)	1.312 (3.332 cm)
Bushing			
Inside Diameter	1.321 (3.355 cm)	1.316 (3.343 cm)	1.319 (3.350 cm)

MEASUREMENT	WEAR LIMIT	NEW MINIMUM	NEW MAXIMUM
CYLINDER BLOCK SPECIFICATIONS (Contd)			
Accessory Drive			
End Clearance		0.002 (0.051 mm)	0.012 (0.305 mm)
Main Bearing			
Journal Clearance	0.007 (0.178 mm)	0.0015 (0.0381 mm)	0.005 (0.172 mm)
Connecting Rod Bearing			
Journal Clearance	0.007 (0.178 mm)	0.0015 (0.0381 mm)	0.0045 (0.1143 mm)
Crankshaft			
End Clearance	0.022 (0.559 mm)	0.007 (0.178 mm)	0.017 (0.432 mm)
Cylinder Liner			
Protrusion		0.003 (0.076 mm)	0.006 (0.152 mm)
Out-of-Round (Top 1 In.)			0.003 (0.076 mm)
Out-of-Round (Lower Packing Ring Area)			0.002 (0.051 mm)
Connecting Rod			
Side Clearance		0.0045 (0.1143 mm)	0.013 (0.330 mm)
Gear Train (Gear-to-Gear), Crankshaft, Camshaft, Accessory Drive, and Lubricating Oil Pump Backlash			
	0.020 (0.508 mm)	0.0045 (0.1143 mm)	0.0105 (0.2667 mm)
Camshaft			
End Clearance		0.008 (0.203 mm)	0.013 (0.330 mm)

GLOSSARY
Section I. LIST OF ABBREVIATIONS

AFC.....	Air Fuel Control	in.....	inch
ASA.....	Air Signal Attenuator	lb-ft.....	pound foot
C°.....	Celsius Degrees	lb-hr.....	pounds per hour
CFM.....	Cubic Feet per Minute	lb-in.....	pound inch
EPA.....	Environmental Protection Agency	N•m.....	Newton meter
f.....	foot	pph.....	pounds per hour
ft alt.....	feet altitude	PSI.....	Pounds per Square Inch
F°.....	Fahrenheit degrees	PT.....	Pressure Timed
Hg.....	Mercury	rpm.....	revolutions per minute
hp.....	horsepower	STE/ICE.....	Simplified Test Equipment for Internal Combustion Engines
kPa.....	kilopascal		

Section II. DEFINITION OF UNUSUAL TERMS

Not applicable to this technical manual.

INDEX

A	Para.	Page	C	Para.	Page
Accessory drive housing assembly:			Cam follower:		
Installation	3-73	3-576	Assembly	3-40d	3-204
Removal	3-18	3-40	Cleaning	3-40b	3-190
Accessory drive pulley:			Disassembly	3-40a	3-188
Installation	3-76	3-590	Inspection	3-40c	3-190
Removal	3-15	3-28	Cam follower assemblies:		
Accessory drive:			Installation	3-70	3-558
Assembly	3-49d	3-300	Removal	3-28	3-66
Cleaning	3-49b	3-296	Camshaft:		
Disassembly	3-49a	3-298	Assembly	3-40d	3-204
Inspection	3-49c	3-298	Cleaning	3-40b	3-190
Air aftercooler:			Disassembly	3-40a	3-188
Assembly	3-45d	3-268	Inspection	3-40c	3-190
Cleaning	3-45b	3-266	Installation	3-70	3-558
Disassembly	3-45a	3-264	Removal	3-28	3-66
Inspection	3-45c	3-266	Connecting rod:		
Installation	3-87	3-656	Assembly	3-39d	3-186
Removal	3-20	3-46	Cleaning	3-39b	3-176
Air compressor:			Disassembly	3-39a	3-174
Assembly	3-51d	3-332	Inspection	3-39c	3-176
Cleaning	3-51b	3-320	Installation	3-69	3-552
Disassembly	3-51a	3-312	Removal	3-29	3-68
Inspection and Repair	3-51c	3-320	Crankshaft:		
Installation	3-77	3-592	Cleaning	3-37a	3-150
Removal	3-17	3-36	Inspection	3-37b	3-152
Appendix A, references		A-1	Crankshaft pulley:		
Appendix B, repair parts and special tools list		B-1	Cleaning	3-36a	3-148
Appendix C, expendable/durable supplies and materials list		C-1	Inspection	3-36b	3-148
Appendix D, illustrated list of manufactured items		D-1	Installation	3-79	3-606
Appendix E, torque limits		E-1	Removal	3-14	3-26
Appendix F, wear limits and tolerances		F-1	Cylinder head and valve:		
Assembly:			Assembly and testing	3-35d	3-142
General	3-65	3-539	Cleaning	3-35b	3-116
Task summary	3-66	3-539	Disassembly	3-35a	3-112
B			Inspection and repair	3-35c	3-118
Bearings, connecting rod:			Cylinder head assembly:		
Assembly	3-39d	3-186	Installation	3-71	3-562
Cleaning	3-39b	3-174	Removal	3-24	3-54
Disassembly	3-39a	3-174	Cylinder liner:		
Inspection	3-39c	3-176	Installation	3-67	3-542
Installation	3-69	3-552	Removal	3-30	3-72
Removal	3-29	3-68	D		
Breather tube, engine:			Dipstick, oil pan:		
Assembly	3-43d	3-244	Assembly	3-43d	3-244
Cleaning	3-43b	3-238	Cleaning	3-43b	3-238
Disassembly	3-43a	3-236	Disassembly	3-43a	3-236
Inspection	3-43c	3-238	Inspection	3-43c	3-238
			Disassembly:		
			General	3-11	3-8
			Task summary	3-12	3-8
			Drive pulley, accessory:		
			Installation	3-73	3-590
			Removal	3-76	3-28

INDEX (Contd)

	Para.	Page		Para.	Page
E			F		
Engine block:			Flexplate or flywheel:		
Assembly	3-34d	3-104	Cleaning	3-38a	3-170
Cleaning	3-34b	3-86	Inspection	3-38b	3-170
Disassembly	3-34a	3-86	Installation	3-80	3-608
Inspection and repair	3-34c	3-90	Removal	3-25	3-56
Engine crankshaft:			Flywheel housing:		
Assembly	3-37b	3-150	Cleaning	3-38a	3-170
Disassembly	3-37a	3-150	Inspection	3-38b	3-170
Engine crankshaft and main bearings:			Installation	3-80	3-608
Installation	3-68	3-544	Removal	3-25	3-56
Removal	3-31	3-74	Front gear cover:		
Engine, dynamometer testing:			Assembly	3-48d	3-294
Break-in running	3-92b	3-682	Cleaning	3-48b	3-292
Final check	3-92e	3-688	Disassembly	3-48a	3-292
Power check	3-92c	3-687	Inspection	3-48c	3-292
Setup	3-92a	3-680	Installation	3-75	3-584
Smoke level check	3-92d	3-688	Removal	3-27	3-64
Engine, removing from maintenance stand:			Fuel damper and head:		
Component installation	3-88b	3-662	Assembly	3-58e	3-396
Removal	3-88a	3-660	Cleaning	3-58c	3-396
Engine retarder:			Disassembly	3-58b	3-394
Assembly	3-50c	3-310	Inspection	3-58d	3-396
Disassembly	3-50a	3-304	Installation	3-58f	3-396
Installation	3-86a	3-650	Removal	3-58a	3-394
Removal	3-21	3-48	Fuel gear pump:		
Slave piston adjustment	3-86b	3-652	Assembly	3-59e	3-402
Testing	3-50b	3-308	Cleaning	3-59c	3-400
Engine, starting repaired:			Disassembly	3-59b	3-398
Installation of engine on dynamometer	3-91a	3-674	Inspection	3-59d	3-400
Prerun startup	3-91e	3-678	Installation	3-59f	3-403
Priming cooling system	3-91b	3-676	Removal	3-59a	3-398
Priming fuel system	3-91c	3-676	Fuel injector:		
Priming lubricating system	3-91d	3-676	Assembly	3-52d	3-348
Equipment description and data:			Cleaning	3-52b	3-342
Equipment characteristics, capabilities and features	1-8	1-2	Disassembly	3-52a	3-340
Equipment data	1-10	1-5	Inspection	3-52c	3-344
Location and description of major components	1-9	1-3	Fuel injector testing; test No. 1:		
Exhaust manifold:			Check ball leakage test	3-53b	3-356
Assembly	3-46d	3-274	Cup-to-plunger seal test	3-53a	3-352
Cleaning	3-46b	3-272	Fuel injector testing; test No. 2:		
Disassembly	3-46a	3-272	Setting up spray pattern tester	3-54a	3-358
Inspection	3-46c	3-274	Spray pattern test	3-54b	3-360
Expendable/durable supplies and materials list:			Fuel injector testing; test No. 3:		
Explanation of columns	C-2	C-1	Adjusting and measuring fuel delivery	3-55d	3-374
Scope	C-1	C-1	Setting up injector on teststand	3-55b	3-370
			Setting up test stand	3-55a	3-362
			Testing check ball seating	3-55c	3-372
			Top-stop injector adjustment	3-55e	3-382

INDEX (Contd)

F (Contd)	Para.	Page	Para.	Page
Fuel pump:			Fuel pump governor spring:	
Attenuator air tank installation			Cleaning	3-60b 3-406
(M915/big cam I only.....)	3-78c	3-604	Inspection	3-60c 3-406
Cleaning	3-56b	3-384	Installation	3-60d 3-406
Fuel supply line installation	3-78b	3-600	Removal	3-60a 3-404
Inspection	3-56c	3-386	Fuel pump main housing:	
Installation	3-78a	3-596	Assembly	3-62d 3-436
Installing fuel pump on vise	3-56a	3-384	Cleaning	3-62b 3-430
Removal	3-16	3-30	Disassembly	3-62a 3-426
Removing fuel pump from vise	3-56d	3-386	Inspection and repair	3-62c 3-430
Fuel pump adjustment, on-engine:			Fuel pump testing:	
Checking and adjusting engine			AFC plunger setting	
fuel rate	3-93f	3-696	procedures	3-63m 3-508
Checking and adjusting fuel			Calibration check points	3-63l 3-504
rail pressure	3-93e	3-694	Calibration data	3-63a 3-448
Checking and adjusting throttle			Fuel pump idle speed check	3-63j 3-500
leakage	3-93g	3-694	Fuel pump main pressure	
Checking engine power	3-93h		adjustment	3-63k 3-502
Checking fuel filter restriction	3-93i		Fuel pump nameplate data	3-63b 3-464
Fuel pump seal installation	3-93j	3-702	Fuel pump run-in	
High idle speed adjustment	3-93d	3-694	(Big Cam I and Big Cam III).	3-63d 3-478
High speed adjustment	3-93c	3-692	Fuel pump vacuum and seal	
Idle speed adjustment	3-93b	3-692	test	3-63e 3-484
Preadjustment checks	3-93a	3-690	Fuel pump vacuum adjustment	3-63f 3-486
Throttle shaft cover plate			Governor cut off rpm check	3-63g 3-488
installation	3-93k	3-702	Mounting fuel pump to	
Fuel pump calibration:			test stand	3-63c 3-466
AFC plunger setting			No-air screw adjustment	3-63n 3-512
procedures	3-63m	3-508	Removing fuel pump from	
Calibration check points	3-63l	3-504	test stand	3-63o 3-514
Calibration data	3-63a	3-448	Throttle leakage	3-63h 3-492
Fuel pump idle speed check	3-63j	3-500	Throttle lever travel	
Fuel pump main pressure			adjustment	3-63i 3-498
adjustment	3-63k	3-502		
Fuel pump nameplate data	3-63b	3-464	G	
Fuel pump run-in	3-63d	3-478	Gear cover, front:	
Fuel pump vacuum adjustment	3-63f	3-486	Assembly	3-48d 3-294
Fuel pump vacuum and seal			Cleaning	3-48b 3-292
test	3-63e	3-484	Disassembly	3-48a 3-292
Governor cut off rpm check	3-63g	3-488	Inspection	3-48c 3-292
Mounting fuel pump to			Installation	3-75 3-584
test stand	3-63c	3-466	Removal	3-27 3-64
No-air screw adjustment	3-63n	3-512	General information:	
Removing fuel pump from			Destruction of Army materiel to	
test stand	3-63o	3-514	prevent enemy use	1-4 1-1
Throttle leakage check	3-63h	3-492	Maintenance forms, records,	
Throttle lever travel			and reports	1-3 1-1
adjustment	3-63i	3-498	Overview	1-1 1-1
Fuel pump front cover and			Preparation for storage and	
governor:			shipment	1-5 1-2
Assembly	3-61e	3-414	Reporting Equipment Improvement	
Assembly (M915/big cam I)	3-61i	3-422	Recommendations (EIRs)	1-6 1-2
Cleaning	3-61c	3-412	Scope	1-2 1-1
Disassembly	3-61b	3-410	Warranty information	1-7 1-2
Disassembly (M915/big cam I)	3-61g	3-420	Glossary, list of abbreviations	Glossary-1
Inspection	3-61d	3-412		
Inspection (M915/big cam I)	3-61h	3-420		
Installation	3-61f	3-418		
Removal	3-61a	3-408		

INDEX (Contd)

	Para.	Page		Para.	Page
G (Contd)					
Governor, fuel pump:			Mounting engine on maintenance stand:		
Assembly	3-61e	3-414	Component removal	3-13e	3-14
Cleaning	3-61c	3-412	Cleaning	3-13c	3-12
Disassembly	3-61b	3-410	Draining	3-13b	3-12
Inspection	3-61d	3-412	Inspection	3-13d	3-14
Installation	3-61f	3-418	Lifting	3-13a	3-10
Removal	3-61a	3-408	Mounting on maintenance stand	3-13f	3-24
H					
Head, fuel damper and:			O		
Assembly	3-58e	3-396	Oil cooler:		
Cleaning	3-58c	3-396	Assembly	3-42d	3-230
Disassembly	3-58b	3-394	Cleaning	3-42b	3-224
Inspection	3-58d	3-396	Disassembly	3-42a	3-218
Installation	3-58f	3-396	Inspection	3-42c	3-226
Removal	3-58a	3-394	Oil pan:		
I					
Injection timing:			Installation	3-81	3-620
Changing injection timing	3-72c	3-572	Removal	3-26	3-62
Injection timing cylinder No. 1	3-72b	3-568	Oil pan, dipstick, and oil suction tube:		
Injection timing cylinder No. 3	3-72d	3-574	Assembly	3-43d	3-244
Injection timing cylinder No. 5	3-72e	3-574	Cleaning	3-43b	3-238
Setup	3-72a	3-566	Disassembly	3-43a	3-236
Injector and valve:			Inspection	3-43c	3-238
Adjustment	3-85	3-644	Oil pump:		
Injector assembly:			Assembly	3-44d	3-258
Installation	3-82	3-632	Cleaning	3-44b	3-252
Removal	3-23	3-52	Disassembly	3-44a	3-246
M					
Main bearings, engine crankshaft:			Inspection	3-44c	3-254
Assembly	3-37b	3-150	Installation	3-74	3-580
Disassembly	3-37a	3-150	Removal	3-19	3-42
Installation	3-68	3-544	Oil suction tubes, oil pan:		
Removal	3-31	3-74	Assembly	3-43d	3-244
Maintenance instructions:			Cleaning	3-43b	3-238
Assembly	3-10	3-7	Disassembly	3-43a	3-236
Cleaning	3-6	3-3	Inspection	3-43c	3-238
Draining engine	3-5	3-3	On-engine fuel pump adjustment:		
General	3-2	3-1	Checking and adjusting engine fuel rate	3-93f	3-696
Inspection	3-4	3-2	Checking and adjusting fuel rail pressure	3-93e	3-694
Lifting engine	3-7	3-4	Checking and adjusting throttle leakage	3-93g	3-698
Overview	3-1	3-1	Check engine power	3-93h	3-700
Repair	3-9	3-5	Checking fuel filter restriction	3-93i	3-700
Task summary	3-3	3-2	Fuel pump seal installation	3-93j	3-702
Wear limits and tolerances	3-8	3-5	High idle speed adjustment	3-93d	3-694
Manufactured items, illustrated list of			High speed adjustment	3-93c	3-692
General	D-1	D-1	Idle speed adjustment	3-93b	3-692
Manufactured items part number index	D-2	D-2	Preadjustment checks	3-93a	3-690
			Throttle shaft cover plate installation	3-93k	3-702

INDEX (Contd)

	Para.	Page		Para.	Page
P					
Piston:			Rocker arm housing assembly and pushrods:		
Installation	3-69	3-552	Installation	3-84	3-640
Removal	3-29	3-68	Removal	3-22	3-50
Piston, connecting rod, and bearing:			Rocker levers and housing:		
Assembly	3-39d	3-186	Assembly	3-41d	3-216
Cleaning	3-39b	3-176	Cleaning	3-41b	3-210
Disassembly	3-39a	3-174	Disassembly	3-41a	3-208
Inspection	3-39c	3-176	Inspection	3-41c	3-210
Pushrod, camshaft, and cam follower:			S		
Assembly	3-40d	3-204	Service upon receipt of equipment:		
Cleaning	3-40b	3-190	Engine inspection	2-5	2-1
Disassembly	3-40a	3-188	Solenoid valve:		
Inspection	3-40c	3-190	Assembly	3-57e	3-390
Pushrods:			Cleaning	3-57c	3-390
Installation	3-71	3-562	Disassembly	3-57b	3-388
Removal	3-22	3-50	Inspection	3-57d	3-390
R			Installation	3-57f	3-392
Rear cover:			Removal	3-57a	3-388
Cleaning	3-38a	3-170	Starting repaired engine:		
Inspection	3-38b	3-170	Installation of engine on dynamometer	3-91a	3-674
Installation	3-80	3-608	Prerun startup	3-91e	3-678
Removal	3-25	3-56	Priming the cooling system	3-91b	3-676
References:			Priming the fuel system	3-91c	3-676
Forms	A-2	A-1	Priming the lubricating system	3-91d	3-676
Other publications	A-3	A-1	Storage, engine:		
Publications indexes	A-1	A-1	General	3-94	3-704
Removing engine from maintenance stand:			Long-term	3-97	3-705
Component installation	3-88	3-662	Preparing an engine from storage to service	3-98	3-706
Removal	3-88	3-660	Task summary	3-94	3-704
Repair:			Temporary	3-96	3-704
General	3-32	3-78	T		
Cleaning	3-33	3-78	Torque limits:		
Repair parts and special tools list:			Engine assembly tightening specifications		E-1
Explanation of columns	B-3	B-1	Standard torque specifications		E-2
Explanation of columns (Section IV)	B-4	B-4	Troubleshooting:		
General	B-2	B-1	General	2-6	2-2
How to locate repair parts	B-6	B-5	Mechanical, table 2-1	2-8	2-3
Scope	B-1	B-1	Symptom index	2-7	2-3
Special information	B-5	B-5	Turbocharger:		
Repair parts, special tools, TMDE, and support equipment:			Assembly	3-47c	3-286
Common tools and equipment	2-3	2-1	Cleaning and inspection	3-47b	3-280
Overview	2-1	2-1	Disassembly	3-47a	3-276
Repair parts	2-4	2-1	V		
Special tools, TMDE, and support equipment	2-3	2-1	Valve and cylinder head:		
			Assembly and testing	3-35d	3-142
			Cleaning	3-35b	3-116
			Disassembly	3-35a	3-112
			Inspection and repair	3-35c	3-118

INDEX (Contd)

Para. Page

V (Contd)

Valve and injector:		
Adjustment	3-85	3-644
Valve crossheads:		
Installation	3-83	3-636
Vibration damper and crankshaft pulley:		
Cleaning	3-36a	3-148
Inspection	3-36b	3-148
Installation	3-79	3-606
Removal	3-14	3-26

W

Water pump:		
Assembly	3-64d	3-528
Cleaning	3-64b	3-522
Disassembly	3-64a	3-518
Inspection	3-64c	3-524
Wear limits and tolerances:		
General	F-1	F-1
Repair standards	F-2	F-1

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS						Use Part II (reverse) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE
For use of this form, see AR 25-30; the proponent agency is ODISC4.							
TO: (Forward to proponent of publication or form) (Include ZIP Code)				FROM: (Activity and location) (Include ZIP Code)			
AMSTA-LC-CI/TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630				125th Transportation Company ATTN: Motor SGT (SGT Wilson) Ft. Riley, KA 78665-4000			
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER				DATE	TITLE		
TM 9-2815-225-34&P				28 Aug 2001	M915/M915A1 DS/GS Maintenance Manual		
ITEM	PAGE	PARA-	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON	
	0020 00-2					Part number for item 4, detergent, is incorrect	
SAMPLE							
* Reference to line numbers within the paragraph or subparagraph.							
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE	
Johnny Wilson, E-5, MOTOR SGT				DSN 867-7967			

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS						Use Part II (<i>reverse</i>) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM).	DATE
For use of this form, see AR 25-30; the proponent agency is ODISC4.							
TO: (<i>Forward to proponent of publication or form</i>) (<i>Include ZIP Code</i>) AMSTA-LC-CI/TECH PUBS, TACOM-RI 1 Rock Island Arsenal Rock Island, IL 61299-7630				FROM: (<i>Activity and location</i>) (<i>Include ZIP Code</i>)			
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER TM 9-2815-225-34&P				DATE 28 Aug 2001		TITLE M915/M915A1 DS/GS Maintenance Manual	
ITEM	PAGE	PARA-	LINE	FIGURE NO.	TABLE	RECOMMENDED CHANGES AND REASON	
* Reference to line numbers within the paragraph or subparagraph.							
TYPED NAME, GRADE OR TITLE				TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION		SIGNATURE	

TO: <i>(Forward direct to addressee listed in publication)</i>	FROM: <i>(Activity and location) (Include ZIP Code)</i>	DATE
----------------------------------------------------------------	---------------------------------------------------------	------

PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER			DATE		TITLE			
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOC NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MA OR ITEMS SUPPORTED	RECOMMENDED ACTION

PART III - REMARKS *(Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)*

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE
----------------------------	--------------------------------------------	-----------

By Order of the Secretary of the Army:

ERIC K. SHINSEKI
General, United States Army
Chief of Staff

Official:

JOEL B. HUDSON
Administrative Assistant to the
Secretary of the Army
0123313

DISTRIBUTION: To be distributed in accordance with the initial distribution requirements for IDN: 371461, TM 9-2815-225-34&P.

THE METRIC SYSTEM AND EQUIVALENTS

LINEAR MEASURE

1 Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
 1 Kilometer = 1000 Meters = 0.621 Miles

SQUARE MEASURE

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches
 1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet
 1 Sq. Kilometer = 1,000,000 Sq. Meters = 0.386 Sq. Miles

CUBIC MEASURE

1 Cu Centimeter = 1000 Cu Millimeters = 0.06 Cu Inches
 1 Cu Meter = 1,000,000 Cu Centimeters = 35.31 Cu. Feet

LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

TEMPERATURE

$5/9 (°F - 32) = °C$
 212° Fahrenheit is equivalent to 100° Celsius
 90° Fahrenheit is equivalent to 32° Celsius
 32° Fahrenheit is equivalent to 0° Celsius
 $9/5 (°C + 32) = °F$

WEIGHTS

1 Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces
 1 Kilogram = 1000 Grams = 2.2 Lb
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

APPROXIMATE CONVERSION FACTORS

TO CHANGE

Inches.....
 Feet.....
 Yards.....
 Miles.....
 Square Inches.....
 Square Feet.....
 Square Yards.....
 Square Miles.....
 Acres.....
 Cubic Feet.....
 Cubic Yards.....
 Fluid.....
 Pints.....
 Quarts.....
 Quarts.....
 Gallons.....
 Ounces.....
 Pounds.....
 Short Tons.....
 Pound-Feet.....
 Pounds per Square Inch.....
 Miles per Gallon.....
 Miles per Hour.....

TO

Centimeters.....
 Meters.....
 Meters.....
 Kilometers.....
 Square Centimeters.....
 Square Meters.....
 Square Meters.....
 Square Kilometers.....
 Square Hectometers.....
 Cubic Meters.....
 Cubic Meters.....
 Ounces Milliliters.....
 Liters.....
 Liters.....
 Liters.....
 Liters.....
 Grams.....
 Kilograms.....
 Metric Tons.....
 Newton-Meters.....
 Kilopascals.....
 Kilometers per Liter.....
 Kilometers per Hour.....

MULTIPLY BY

2.540
 0.305
 0.914
 1.609
 6.451
 0.093
 0.836
 2.590
 0.405
 0.028
 0.765
 29.573
 0.473
 0.946
 0.946
 3.785
 28.349
 0.45
 0.0907
 1.356
 6.895
 0.425
 1.609

TO CHANGE

Centimeters.....
 Meters.....
 Meters.....
 Meters.....
 Kilometers.....
 Square Centimeters.....
 Square Meters.....
 Square Meters.....
 Square Kilometers.....
 Square Hectometers.....
 Cubic Meters.....
 Cubic Meters.....
 Milliliters Fluid.....
 Liters.....
 Liters.....
 Liters.....
 Grams.....
 Kilograms.....
 Metric Tons.....
 Newton-Meters.....
 Kilopascals.....
 Kilometers per Liter.....
 Kilometers per Hour.....

TO

Inches.....
 Feet.....
 Yards.....
 Yards.....
 Miles.....
 Square Inches.....
 Square Feet.....
 Square Yards.....
 Square Miles.....
 Acres.....
 Cubic Feet.....
 Cubic Yards.....
 Ounces.....
 Pints.....
 Quarts.....
 Gallons.....
 Ounces.....
 Pounds.....
 Short Tons.....
 Pound-Feet.....
 Pounds per Square Inch.....
 Miles per Gallon.....
 Miles per Hour.....

MULTIPLY BY

0.394
 3.280
 1.094
 1.094
 0.621
 0.155
 10.764
 1.195
 0.386
 2.471
 35.315
 1.308
 0.034
 2.113
 1.057
 0.264
 0.035
 2.205
 1.102
 0.738
 0.145
 2.354
 0.621

