


TECHNICAL MANUAL
UNIT, DIRECT SUPPORT, AND
GENERAL SUPPORT MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST
FOR
ENGINE ASSEMBLY, DIESEL
HATZ 2G 40
(NSN 2815-01-446-3500)
(NSN 2815-01-465-4321)



HOW TO USE THIS MANUAL	iv
INTRODUCTION	1-1
UNIT MAINTENANCE PROCEDURES	2-7
DIRECT SUPPORT AND GENERAL SUPPORT TROUBLESHOOTING	3-1
DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE PROCEDURES	3-12
TESTS AND ADJUSTMENTS	3-56
REFERENCES	A-1
MAINTENANCE ALLOCATION CHART	B-1
REPAIR PARTS AND SPECIAL TOOLS LIST	C-1
EXPENDABLE AND DURABLE ITEMS LIST	D-1
TORQUE VALUES FOR THREADED FASTENERS	E-1
MANDATORY REPLACEMENT PARTS	F-1
TOOL IDENTIFICATION LIST	G-1
INDEX	INDEX-1

Approved for public release; distribution is unlimited

HEADQUARTERS, DEPARTMENT OF THE ARMY

SEPTEMBER 1998

FOR INFORMATION ON FIRST AID, REFER TO FM 4-25.11.

WARNING


CARBON MONOXIDE



- Carbon monoxide is a colorless, odorless, deadly poisonous gas that, when breathed, deprives the body of oxygen and causes suffocation. Exposure to carbon monoxide can cause headache, dizziness, loss of muscle control, drowsiness, and coma. Permanent brain damage or death can result from serious exposure.
- Carbon monoxide is present in the exhaust fumes of diesel engines; inadequate ventilation causes dangerous concentrations of this gas. Precautions must be observed to ensure the safety of personnel whenever the diesel engine is operated for maintenance or tactical reasons. Do not operate the engine in an enclosed area without adequate ventilation.


WARNING

DRYCLEANING SOLVENT




- Drycleaning solvent (P-D680) is TOXIC and flammable. Wear protective goggles and gloves; use only in a well-ventilated area; avoid contact with skin, eyes, and clothes; and DO NOT breathe vapors. Keep away from heat or flame. Never smoke when using drycleaning solvent. Failure to follow this warning may result in injury or death to personnel.
- If personnel become dizzy while using drycleaning solvent, immediately get fresh air and medical help. If solvent contacts skin or clothes, flush with cold water. If solvent contacts eyes, immediately flush them with water and get immediate medical attention.
- When drycleaning solvent is used, notify the local medical authority (preventive medicine) and environmental coordinator concerning medical surveillance, respiratory protection, and disposal requirements.

WARNING
COMPRESSED AIR



Compressed air used for cleaning or drying purposes, or for clearing restrictions, should never exceed 30 psi (207 kPa). Wear protective clothing (gloves, etc.) and use caution, particularly when drying or cleaning metal parts, to avoid injury to personnel. It is particularly important to wear eye protection (goggles or a face shield) to protect eyes from blowing particles and prevent serious eye injury.

WARNING
LIFTING



Use extreme caution when handling heavy parts. The diesel engine weighs about 200 pounds (90 kg). Use a suitable lifting device to place the engine on the stand. Failure to follow this warning may result in serious injury or death to personnel.

CHANGE
NO. 1

**TECHNICAL MANUAL
UNIT, DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST)
FOR
ENGINE ASSEMBLY, DIESEL
HATZ 2G 40
(NSN 2815-01-446-3500)
(NSN 2815-01-465-4321)**

TM 9-2815-250-24&P, September 1998, is changed as follows:

1. The purpose of this change is to update TM 9-2815-250-24&P.
2. New or changed material is indicated by a vertical bar in the outside margin of text changes and by a hand symbol beside illustration changes.
3. Remove the old page and insert the new page as indicated below:

Remove Pages

a and b
A and B
i and ii
1-3 and 1-4
1-7 and 1-8
2-7 thru 2-10
2-13 and 2-14
2-19 thru 2-32
3-11 thru 3-14
3-15 and 3-16
3-19 thru 3-22
3-27 thru 3-32
3-37 thru 3-40
3-45 and 3-46
3-47 thru 3-56
3-59 and 3-60
3-63 thru 3-70
A-1 and A-2
C-5 and C-6
C-7 thru 17-1
I-1 thru I-9
D-1 and D-2
F-3/F-4 blank
Index-1 thru Index-4
Cover/Blank

Insert Pages

a and b
A and B
i and ii
1-3 and 1-4
1-7 and 1-8
2-7 thru 2-10
2-13 and 2-14
2-19 thru 2-32
3-11 thru 3-14.1/3-14.2 blank
3-15 and 3-16
3-19 thru 3-22
3-27 thru 3-32
3-37 thru 3-40
3-45 and 3-46
3-47/3-48 blank thru 3-56
3-59 and 3-60
3-63 thru 3-70
A-1 and A-2
C-5 and C-6
C-7 thru 17-1/17-2 blank
I-1 thru I-6
D-1 thru D-3/D-4 blank
F-3 and F-4
Index-1 thru Index-4
Cover/Pin

Distribution Statement A: Approved for public release; distribution is unlimited.

4. File this change in front of the publication.

By Order of the Secretary of the Army:

PETER J. SCHOOMAKER
General, United States Army
Chief of Staff

Official:

A handwritten signature in black ink that reads "Sandra R. Riley". The signature is written in a cursive style with a large, looping 'S' at the beginning.

SANDRA R. RILEY
Administrative Assistant to the
Secretary of the Army
0524301

DISTRIBUTION: To be distributed in accordance with the Initial Distribution Number (IDN)
381080, requirements for TM 9-2815-250-24&P.

INSERT LATEST CHANGED PAGES.
DESTROY SUPERSEDED PAGES

LIST OF EFFECTIVE PAGES

Note: The portion of the text affected by the changes is indicated by a vertical line in the outer margin of the page. Changes to illustrations are indicated by miniature pointing hands. Changes to wiring diagrams are indicated by shaded areas.

Date of issue for original and changed pages are:

Original 0 11 September 1998
Change 1 31 December 2005

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 232, CONSISTING OF THE FOLLOWING:

Page No.	*Change No.	Page No.	*Change No.	Page No.	*Change No.
Cover	1	2-19	0	3-23	0
a	1	2-20	1	3-24	0
b	0	2-21	1	3-25	0
i	1	2-22	1	3-26	0
ii	0	2-23	1	3-27	1
iii	0	2-24	1	3-28	1
iv	0	2-25	1	3-29	1
v	0	2-26	1	3-30	1
vi	0	2-27	1	3-31	1
vii/viii blank	0	2-28	1	3-32	1
1-1	0	2-29	1	3-33	0
1-2	0	2-30	1	3-34	0
1-3	1	2-31	1	3-35	0
1-4	1	2-32	1	3-36	0
1-5	0	3-1	0	3-37	1
1-6	0	3-2	0	3-38	1
1-7	0	3-3	0	3-39	1
1-8	1	3-4	0	3-40	0
1-9	0	3-5	0	3-41	0
1-10 blank	0	3-6	0	3-42	0
2-1	0	3-7	0	3-43	0
2-2	0	3-8	0	3-44	0
2-3	0	3-9	0	3-45	0
2-4	0	3-10	0	3-46	1
2-5	0	3-11	1	3-47	1
2-6	0	3-12	1	3-48 blank (added)	1
2-7	1	3-13	1	3-48.1 (added)	1
2-8	1	3-14	1	3-48.2 (added)	1
2-9	0	3-14.1	1	3-48.3 (added)	1
2-10	1	3-14.2 blank (added)	1	3-48.4 (added)	1
2-11	0	3-15	1	3-49	1
2-12	0	3-16	0	3-50	1
2-13	1	3-17	0	3-51	0
2-14	1	3-18	0	3-52	1
2-15	0	3-19	1	3-53	1
2-16	0	3-20	0	3-54	1
2-17	0	3-21	0	3-55	1
2-18	0	3-22	1	3-56	0

*Zero in this column indicates an original page

Page No.	*Change No.	Page No.	*Change No.	Page No.	*Change No.
3-57.....	0	4-1	1	I-3	1
3-58.....	0	Figure 5	1	I-4	1
3-59.....	0	5-1	1	I-5	1
3-60.....	1	Figure 6	1	I-6	1
3-61.....	0	6-1	1	I-7 (deleted).....	1
3-62.....	0	Figure 7	1	I-8 (deleted).....	1
3-63.....	0	7-1	1	I-9/I-10 blank (deleted).....	1
3-64.....	1	Figure 8	1	D-1	0
3-65.....	1	8-1	1	D-2.....	1
3-66.....	1	Figure 9	1	D-3/D-4 blank	1
3-67.....	0	9-1	1	E-1	0
3-68.....	1	Figure 10	0	E-2.....	0
3-69.....	1	10-1	1	E-3.....	0
3-70.....	0	Figure 11	0	E-4.....	0
3-71.....	0	11-1	1	E-5.....	0
3-72 blank.....	0	Figure 12	1	E-6 blank	0
A-1	1	12-1	1	F-1	0
A-2	1	12-2 blank (added).....	1	F-2.....	0
B-1	0	Figure 13 (SH 1 of 2).....	1	F-3	1
B-2	0	Figure 13 (SH 2 of 2) (added) .	1	F-4	1
B-3	0	13-1	1	G-1	0
B-4	0	13-2 blank (added)	1	G-2	0
B-5	0	Figure 14 (SH 1 of 2).....	0	G-3	0
B-6	0	Figure 14 (SH 2 of 2).....	0	G-4 blank.....	0
C-1	0	14-1	1	Index-1	1
C-2	0	Figure 15	0	Index-2	1
C-3	0	15-1	1	Index-3	1
C-4	0	Figure 16	0	Index-4	1
C-5	0	16-1	1	Index-5	0
C-6.....	1	16-2 (added).....	1	Index-6 blank.....	0
C-7	1	Kits-1	1	2028 Sample	0
Figure 1.....	0	Kits-2 (added).....	1	2028 Sample Address.....	0
1-1.....	0	Bulk-1	1	2028	0
Figure 2.....	1	Figure 17	0	2028 Address	0
2-1.....	1	17-1	1	Metric Page	0
Figure 3.....	1	17-2 blank (added)	1	PIN	1
3-1.....	1	I-1.....	1		
Figure 4.....	1	I-2.....	1		

*Zero in this column indicates an original page

UNIT, DIRECT SUPPORT, AND
GENERAL SUPPORT MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST)
FOR
ENGINE ASSEMBLY, DIESEL
HATZ 2 G 40
NSN 2815-01-446-3500
NSN 2815-01-465-4321

REPORTING OF ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028 (Recommended Changes to Equipment Technical Publications), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <https://aeeps.ria.army.mil>. The DA Form 2028 is located under the Public Applications section in the AEPS Public Home Page. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax or E-mail your letter or DA Form 2028 direct to: AMSTA-LC-LMIT / TECH PUBS, TACOM-RI, 1 Rock Island Arsenal, Rock Island, IL 61299-7630. The email address is TACOM-TECH-PUBS@ria.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

	Page
HOW TO USE THIS MANUAL	iv
CHAPTER 1 INTRODUCTION	
Section I General Information	1-1
Section II Equipment Description and Data	1-4
Section III Principles of Operation	1-9

Table of Contents (continued)

		Page	
CHAPTER 2	UNIT MAINTENANCE		
Section I	Repair Parts; Special Tools; Test, Measurement, and Diagnostic Equipment (TMDE); and Support Equipment	2-1	
Section II	Service upon Receipt	2-2	
Section III	General Maintenance Procedures	2-3	
Section IV	Unit Maintenance Procedures	2-7	
CHAPTER 3	DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE		
Section I	Direct Support and General Support Troubleshooting	3-1	
Section II	Direct Support and General Support Maintenance Procedures	3-12	
Section III	Tests and Adjustments	3-56	
APPENDIX A	REFERENCES		A-1
APPENDIX B	MAINTENANCE ALLOCATION CHART		
Section I	Introduction		B-1
Section II	Maintenance Allocation Chart for Engine Assembly, Diesel, Hatz 2 G 40		B-4
Section III	Tools and Test Equipment Requirements		B-6
APPENDIX C	REPAIR PARTS AND SPECIAL TOOLS LIST		
Section I	Introduction		C-1
Section II	Repair Parts List		
		Page	Illus Fig
Group 22	Body, Chassis, and Hull Accessory Items		
Group 2210	Data Plates and Instruction Holders		
	2210 Engine Identification Plate	1-1	1
Group 29	Auxiliary Generator and Engine, and Controls		
2910	Engine Assembly		
	Engine Diesel	2-1	2
2911	Crankcase, Cylinder Sleeve, and Cylinder Head		
	Cylinder Head	3-1	3
	Crankcase Assembly	4-1	4
2912	Crankcase Assembly		
	Crankshaft Assembly	5-1	5
2913	Flywheel Assembly		
	Flywheel and Related Components	6-1	6

Table of Contents (continued)

	Page	Illus Fig
2914 Pistons and Connecting Rods		
Pistons and Connecting Rods.....	7-1	7
2915 Valves, Camshaft, and Timing System		
Camshaft and Valves.....	8-1	8
2916 Engine Lubrication System		
Engine Lubrication System.....	9-1	9
2918 Manifolds		
Exhaust Manifold Mounting Hardware.....	10-1	10
Intake Manifold and Related Components.....	11-1	11
2932 Engine Fuel System		
Injection Pump, Nozzles, and Fuel Lines.....	12-1	12
2936 Engine Speed Governor and Controls		
Governor and Controls.....	13-1	13
2952 Engine Cowling Deflectors, Air Ducts, and Shrouds		
Engine Cowling, Ducts, and Shroud.....	14-1	14
2960 Sending Units		
Sending Units.....	15-1	15
2968 Switches, Circuit Breakers, and Fuses		
Fuel-Shutoff Solenoid.....	16-1	16
 Group 94 Repair Kits		
9401 Repair Kits		
Repair Kits.....	KITS-1	
 Group 95 General Use Standard Parts		
9501 Bulk Material		
Bulk Material.....	BULK-1	
 Section III Special Tools List		
 Group 26 Tools and Test Equipment		
2604 Special Tools		
Special Tools.....	17-1	17
 Section IV Cross Reference Indexes		
National Stock Number Index.....	I-1	
Part Number Index.....	I-4	
		Page
APPENDIX D EXPENDABLE AND DURABLE ITEMS LIST		
Section I Introduction.....		D-1
Section II Expendable and Durable Items List.....		D-2
 APPENDIX E TORQUE VALUES FOR THREADED FASTENERS		E-1
APPENDIX F MANDATORY REPLACEMENT PARTS		F-1
APPENDIX G TOOL IDENTIFICATION LIST		G-1
INDEX		Index 1

HOW TO USE THIS MANUAL

SCOPE.

This technical manual contains Unit, Direct Support, and General Support maintenance procedures for the Diesel Engine Assembly, Hatz 2 G 40. Chapter 1 contains general information; Chapter 2 describes and illustrates Unit troubleshooting and maintenance procedures; and Chapter 3 describes and illustrates Direct Support and General Support troubleshooting and maintenance procedures. Seven appendixes and a subject index are also included in this manual.

INDEXING.

Four Indexing procedures are used to help you locate information quickly:

- Cover index. Lists chapter titles and important parts of this manual, with corresponding page numbers. Each chapter or part listed is boxed in, with a black outer edge that is in line with the first page of that chapter or part.
- Table of contents. The table of contents follows the summary of warnings. The table of contents lists all chapters and sections numerically, with corresponding page numbers.
- Section indexes. Each section starts with a numerical listing of all paragraphs in that section.
- Alphabetical index. The alphabetically arranged subject index starts on page Index 1.

TEXT AND ILLUSTRATIONS.

1. Each chapter is divided into sections; each section begins with a numerical listing of all paragraphs.
2. Each paragraph in the maintenance chapters (2 and 3) contains the following information, as appropriate:
 - The common or special tools and test equipment required to perform the procedures are listed under the heading "Tools/Test Equipment." Information (e.g., part numbers and national stock numbers) for all common and special tools is given in Appendix G.
 - Materials and mandatory replacement parts that will be discarded during performance of the procedure are listed under the heading "Materials/Parts." A materials/parts list does not contain items that may be replaced if found defective during inspection. Also, the list does not contain the item cited in the paragraph title. Information on the materials is in Appendix D, and information on the mandatory replacement parts is in Appendix F.
 - If more than one person is required to perform the procedure, the number is specified under the heading "Personnel Required."
 - Procedures that must be followed prior to performing the engine maintenance procedure are listed under the heading "Equipment Conditions."

TEXT AND ILLUSTRATIONS (continued).

3. Maintenance procedures are to be performed in the sequence given in the text and illustrations.
4. Illustrations are numbered clockwise, beginning at the 11 o'clock position. Because an illustration is keyed to the text, parts that are removed sequentially may not have sequential numbers. For example:

Remove screw (4), lockwasher (6), washer (7), and bracket (5) from crankcase (2).

5. Be sure to read the entire paragraph before beginning a maintenance procedure. Also, read the general information in Chapter 1 before beginning a procedure

WARNINGS, CAUTIONS, AND NOTES.

1. Throughout this manual you will see WARNING, CAUTION, and NOTE headings. There are good reasons for every one of these notices.

WARNING

A warning is used to alert the user to hazardous operating and maintenance procedures, practices, or conditions that could result in injury or death. Warnings must be strictly observed.

CAUTION

A caution is used to alert the user to hazardous operating and maintenance procedures, practices, or conditions that could result in damage to, or destruction of, equipment or mission effectiveness. Cautions must be strictly observed.

NOTE

A note highlights an essential operating or maintenance procedure, condition, or statement.

2. Warnings and cautions appear immediately preceding the step to which they pertain. It is important to read and thoroughly understand the warnings and/or cautions before beginning maintenance.
3. Notes may precede or follow the steps to which they pertain, depending on what makes the most sense.

SAFETY SUMMARY

This safety summary contains general safety precautions and hazardous materials warnings that must be understood and applied during maintenance to protect personnel and U.S. Department of Defense property. Portions of this summary may be repeated elsewhere for emphasis.

WARNING and CAUTION statements appear throughout this manual prior to procedures, practices, or conditions that may endanger personnel (WARNING) or cause equipment and property damage (CAUTION). A warning or caution will apply each time the related step is repeated. Before starting any task, review and understand the warnings and cautions included in the text for that task.

This manual contains procedures that may require using chemicals, solvents, paints, or other commercially available material that may pose a health or safety hazard. Refer to the "Materials/Parts" list at the beginning of a task to see which materials will be used during the task. Obtain material safety data sheets (Occupational Safety and Health Act [OSHA] Form 20 or equivalent) from the manufacturer or supplier of the material to be used. Become completely familiar with the information and manufacturer/supplier procedures, recommendations, warnings, and cautions for the safe use, handling, storage, and disposal of these materials.


Following the "General Safety Precautions" list is a list of "Hazardous Materials Warnings." These warnings are designed to warn personnel of dangers associated with hazardous materials. For each hazardous material used, a material safety data sheet is required to be provided and available for review by personnel. Consult your local safety and health staff concerning questions on hazardous chemicals, personnel protective equipment requirements, and appropriate handling and emergency procedures.

GENERAL SAFETY PRECAUTIONS

- Always use the same fastener part number (or equivalent) when replacing fasteners. Do not risk using a fastener of less quality; do not mix metric and inch (customary) fasteners. Mismatched or incorrect fasteners can result in damage, malfunction, or injury.
- Fuel and oil are slippery and can cause falls. To avoid injury, wipe up spilled fuel or oil with rags.
- Make sure equipment will not move while repairing or inspecting it. For powered equipment, block or chock wheels or tracks and red-tag the starter. Prevent a quick fix from becoming a quick injury.
- When adjustment or service requires a running engine, two people are needed, one at the controls and one at the service point. This helps prevent accidental movement of controls.
- Sharp edges can cut hands. Use rags or a brush to lubricate parts.
- Do not use equipment for other than its intended use, unless authorized by the National Inventory Control Point/commodity command.
- Remove rings, bracelets, wristwatches, and neck chains before working on the engine. Jewelry can catch on equipment and result in injury.

GENERAL SAFETY PRECAUTIONS (continued)

- Keep clear of equipment when it is being raised or lowered. Equipment may fall and cause serious injury or death to personnel.
- Do not work on any item supported only by lift jacks or a hoist. Always use blocks or trestles to support the item prior to any work. Equipment may fall and cause injury or death to personnel.
- Do not allow heavy components to swing while hanging from a lifting device. Equipment may strike personnel and cause injury or death.
- Exercise extreme caution when working near a cable or chain under tension. A snapped cable or a swinging or shifting load may result in injury or death to personnel.
- When working on a running engine, provide shielding for exposed rotating parts. Tools, clothing, or hands can get caught and cause serious injury to personnel.

HAZARDOUS MATERIALS WARNINGS

- Adhesive causes immediate bonding on contact with eyes, skin, or clothing and also gives off harmful vapors. Wear protective goggles and use in a wellventilated area. If adhesive gets in your eyes, try to keep them open; flush with water for 15 minutes and get immediate medical attention.
- Adhesive sealant MIL-S-46163 (Loctite) can damage your eyes. Wear safety goggles/glasses when using sealant, and avoid contact with eyes. If sealant contacts your eyes, flush them with water and get immediate medical attention.
- Drycleaning solvent (P-D-680) is TOXIC and flammable. Wear protective goggles and gloves; use only in a well-ventilated area; avoid contact with skin, eyes, and clothes; and do not breathe vapors. Keep away from heat or flame. Never smoke when using drycleaning solvent. Failure to follow this warning may result in injury or death to personnel.
- If personnel become dizzy while using cleaning solvent, immediately get fresh air and medical help. If solvent contacts skin or clothes, flush with cold water. If solvent contacts eyes, immediately flush with water and get immediate medical attention.

**CHAPTER 1
INTRODUCTION**

Section I. GENERAL INFORMATION

Paragraph Number	Paragraph Title	Page Number
1-1	Scope	1-1
1-2	Maintenance Forms, Records, and Reports.....	1-1
1-3	Destruction of Army Materiel To Prevent Enemy Use.....	1-1
1-4	Preparation for Storage or Shipment.....	1-1
1-5	Quality Assurance.....	1-1
1-6	Reporting Equipment Improvement Recommendations	1-2
1-7	List of Abbreviations and Acronyms	1-2
1-8	Warranty Information	1-3
1-9	Safety, Care, and Handling.....	1-3
1-10	Corrosion Prevention and Control.....	1-3

1-1. SCOPE.

This technical manual describes Unit, Direct Support, and General Support maintenance for the Diesel Engine Assembly, Hatz 2 G 40. The manual also contains the repair parts and special tools list (RPSTL) for the engine assembly.

1-2. MAINTENANCE FORMS, RECORDS, AND REPORTS.

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA Pam 738-750.

1-3. DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE.

Refer to TM 750-244-6 for procedures on the destruction of military vehicles to prevent enemy use.

1-4. PREPARATION FOR STORAGE OR SHIPMENT.

Refer to TM 743-200-1 for information on preparing the Diesel Engine Assembly, Hatz 2 G 40, for storage or shipment.

1-5. QUALITY ASSURANCE.

- a. No specific quality assurance manual pertains to the Diesel Engine Assembly, Hatz 2 G 40.

1-5. QUALITY ASSURANCE (continued).

- b. Defective material received through the supply system should be reported on SF Form 368. Instructions for preparing the reports are provided in AR 702-7. Mail your completed form directly to:

Commander
 U.S. Army Tank-automotive and Armaments Command
 ATTN: AMSTA-TR-E/MPA/267
 Warren, MI 48397-5000

1-6. REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS.

If your Diesel Engine Assembly, Hatz 2 G 40, needs improvement, let us know. Send us an equipment improvement recommendation (EIR). You, the user, are the only one who can tell us what you do not like about the equipment. Let us know why you don't like the design or performance. Put it on an SF Form 368 and mail it to:

Commander
 U.S. Army Tank-automotive and Armaments Command
 ATTN: AMSTA-TR-E/MPA/267
 Warren, MI 48397-5000

1-7. LIST OF ABBREVIATIONS AND ACRONYMS.

approx.	approximately
APU	auxiliary power unit
AR	Army regulation
ATTN	attention
BT	bottle
BX	box
C	Celsius
CAGEC	commercial and government entity code
cc	cubic centimeter
cm	centimeter
CN	can
CPC	corrosion prevention and control
cu in	cubic inch
DA	Department of the Army
DD Form	Department of Defense Form
DOD	Department of Defense
DSN	defense switching network
EIR	equipment improvement recommendation
F	Fahrenheit
ft	foot
ft-lb	foot-pound
GL	gallon
in.	inch
kg	kilogram
km	kilometer
kPa	kilopascal
L	liter

1-7. LIST OF ABBREVIATIONS AND ACRONYMS (continued).

lb, LB	pound
MAC	maintenance allocation chart
min	minimum, minute
mm	millimeter
MTOE	Modified Table of Organization and Equipment
NIIN	national item identification number
N•m	newton meter
NSN	national stock number
OZ	ounce
p.	page
Pam	pamphlet
para	paragraph
psi	pounds per square inch
qt, QT	quart
rpm	revolutions per minute
RPSTL	repair parts and special tools list
SF	standard form
SMR	source, maintenance, and recoverability
TC	technical circular
TM	technical manual
TMDE	test, measurement, and diagnostic equipment
TU	tube
U/M	unit of measure
UOC	usable on code

1-8. WARRANTY INFORMATION.

The Diesel Engine Assembly, Hatz 2 G 40, is not covered by a warranty.

1-9. SAFETY, CARE, AND HANDLING.

For information on general safety precautions and regulations, review the warning summary and the safety summary at the beginning of this manual. In addition, observe all warnings and cautions that appear in the maintenance procedures.

1-10. CORROSION PREVENTION AND CONTROL.

- a. Corrosion prevention and control (CPC) of Army materiel is a continuing concern. It is important that any corrosion problem be reported so it can be corrected and improvements can be made to prevent the problem in the future.
- b. While corrosion is typically associated with the rusting of metals, it can also include deterioration of other materials, such as rubber and plastic. Unusual cracking, softening, swelling, or breaking of materials may indicate a corrosion problem.
- c. If a corrosion problem is identified, it can be reported using an SF Form 368. The use of key words, such as "corrosion," "rust," "deterioration," or "cracking," will ensure that the information is identified as a CPC problem. The form should be submitted to the address specified in DA Pam 738-750.


SECTION II. EQUIPMENT DESCRIPTION AND DATA

Paragraph Number	Paragraph Title	Page Number
1-11	Equipment Characteristics, Capabilities, and Features	1-4
1-12	Location and Description of Major Components	1-5
1-13	Equipment Data	1-8


1-11. EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES.

- a. The Diesel Engine Assembly, Hatz 2 G 40, is an air-cooled four-stroke diesel engine with vertical cylinders and direct fuel injection.
- b. The engine is a lightweight, all-purpose industrial engine.
- c. Later models of Hatz 2 G 40 come EPA version 1 compliant. Differences in configuration affect fuel control on these engines. Examine the serial number on the ID plate to determine which style you have. Also look for statement "EPA compliant" at bottom of tag.

EXAMPLE: 091 XX 02028520




1-12. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS.




Key	Component	Description
1	Intake Manifold	Provides fresh air to cylinders for combustion.
2	Fuel Injectors (2)	Supply fuel to cylinders.
3	Rocker Arm Covers (2)	Protect rocker arm assemblies.
4	Fuel Pressure Pipes (2)	Provide fuel to fuel injectors.
5	Filler Cap	Allows access to filler neck.
6	Filter Element	Removes impurities from lubrication system.
7	Solenoid	Opens and closes fuel supply.
8	Filler Neck	Allows oil to be added to lubrication system.
9	Airflow Deflectors (6)	Provide and direct cooling air.

1-12. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS (continued).



Key	Component	Description
10	Oil Tube Assemblies (2)	Supply oil to various parts of engine.
11	Oil Switch	Shuts off engine if oil pressure is not high enough.
12	Engine Mounts (2)	Secure engine to auxiliary power unit (APU).

1-12. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS (continued).



Key	Component	Description
13	Fuel Hose	Removes excess fuel from engine.
14	Injection Pump	Pumps fuel to injectors.
15	Governor Control Assembly	Controls engine speed.

1-13. EQUIPMENT DATA.

GENERAL SPECIFICATIONS

Model	2 G 40
Manufacturer	Hatz Diesel of America
Mode of Operation	4 cycle
Combustion	Method direct injection
Number of Cylinders	2
Bore/Stroke	3.622/2.935 in. (92/75 mm)
Cubic Capacity	60.79 cu in (997 cc)
Compression Ratio	18:1
Ignition Sequence (Cylinder 1-Flywheel Side)†	1-2
Direction of Rotation	Crankshaft power takeoff rotation is counterclockwise when facing power takeoff shaft
Net Weight	approx. 196 lb (90 kg)
Cooling air Required at 3000 rpm	4.13 in/min (10.5 cm/min)
Combustion Air Required at 3000 rpm	0.56 in/mim (1.42 cm/min)
Oil Capacity (Including Filter Replacement)	approx. 2.65 qt (2.5 L)
Oil Pressure	min 14.5 psi/900 rpm (min 1 bar/900 rpm)
Injection Pressure	3625-3741 psi (250-258 bar)
Tappet Clearance	0.004 in. (0.10 mm)
Governor Speed	2200U±50 rpm
Thermostatic Switch	Closes at 446° F±18F (230° C±10° C)
Horsepower (UOC APP)	13.3 hp at 2000 rpm at 328-ft elevation at 77° F (25° C) ambient temperature
Horsepower (UOC APJ)	17.5 hp at 2650 rpm at 328 foot elevation at 77° F (25° C) ambient temperature

Section III. PRINCIPLES OF OPERATION

1-14. PRINCIPLES OF OPERATION.

The Diesel Engine Assembly, Hatz 2 G 40, is an internal combustion power unit that converts heat energy to work energy inside the cylinders. This particular engine has a four-stroke cycle. A four-stroke engine completes one cycle every other time the piston goes up and down (up being one stroke, down being the return stroke).

- The first stroke is intake; the piston goes down in the cylinder and the intake valve opens, allowing air to flow into the cylinder.
- The second stroke is compression; the piston comes up and both valves close, so the air in the cylinder is compressed. While the air is compressed, the fuel injector releases a spray of fuel into the cylinder.
- The compression heats the air enough to ignite the fuel.
- The third stroke is power; the fuel burns, forcing the piston down.
- The fourth stroke is exhaust; the piston comes up in the cylinder and the exhaust valve opens, allowing exhaust gas to escape.

**CHAPTER 2
UNIT MAINTENANCE**

**Section I. REPAIR PARTS; TOOLS; SPECIAL TOOLS; TEST, MEASUREMENT, AND DIAGNOSTIC
EQUIPMENT (TMDE); AND SUPPORT EQUIPMENT**

Paragraph Number	Page Paragraph Title	Number
2-1	General.....	2-1
2-2	Common Tools and Equipment.....	2-1
2-3	Special Tools, TMDE, and Support Equipment	2-1
2-4	Repair Parts.....	2-1

2-1. GENERAL.

This chapter describes the Unit maintenance tasks to be performed on the Diesel Engine Assembly, Hatz 2 G 40.

2-2. COMMON TOOLS AND EQUIPMENT.

Common tools and equipment are issued to Unit maintenance personnel for maintaining the Diesel Engine Assembly, Hatz 2 G 40. Common tools and equipment should not be used for purposes other than those prescribed and should be properly stored when not in use. For authorized common tools and equipment, refer to the Modified Table of Organization and Equipment (MTOE), CTA 50-970, or CTA 8-100, as applicable to your unit.

2-3. SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT.

Special tools are listed and illustrated in Appendix C of this manual.

2-4. REPAIR PARTS.

Repair parts are listed and illustrated in Appendix C of this manual.

Section II. SERVICE UPON RECEIPT

Paragraph Number	Page Paragraph Title	Number
2-5	General.....	2-2
2-6	Inspection Instructions	2-2

2-5. GENERAL.

When a new, used, or reconditioned Diesel Engine Assembly, Hatz 2 G 40, is received, determine whether it has been properly prepared for service and is capable of accomplishing its mission by performing the inspection instructions in paragraph 2-6.

2-6. INSPECTION INSTRUCTIONS.

- a. Refer to DD Form 1397 for procedures on unpacking the Diesel Engine Assembly, Hatz 2 G 40.I
- b. Remove all straps, plywood, tape, seals, and wrappings.

WARNING

Drycleaning solvent P-D-680 is toxic and flammable. Always wear protective goggles and gloves, and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes, and DO NOT breathe vapors. DO NOT use near open flame or excessive heat.

- c. Remove rust-preventive compound from coated exterior parts of the engine using drycleaning solvent (Item 4, Appendix D) and rags (Item 7, Appendix D).
- d. Inspect engine for damage incurred during shipment.

Section III. GENERAL MAINTENANCE PROCEDURES

Paragraph Number	Paragraph Title	Page Number
2-7	General.....	2-3
2-8	Work Safety	2-4
2-9	Cleaning Instructions	2-4
2-10	Inspection Instructions	2-5
2-11	Repair Instructions.....	2-6
2-12	Hose and Tube Tagging.....	2-6
2-13	Lubrication Instructions	2-6
2-14	Torque Values	2-6

2-7. GENERAL.

- a. These general maintenance procedures and instructions contain general shop practices and specific methods you must be familiar with to properly maintain your Diesel Engine Assembly, Hatz 2 G 40. You should read and understand these practices and methods before performing any maintenance task.
- b. Before beginning a task find out how much repair, modification, or replacement is needed to fix the equipment as described in this manual. Sometimes the reason for equipment failure can be seen right away and complete tear down is not necessary. Disassemble equipment only as far as necessary to repair or replace damaged or broken parts.
- c. The following applies to the "Initial Setup" section contained in all the maintenance-task paragraphs.
 - (1) Materials, parts, and tools are not listed unless they apply to the procedure.
 - (2) Personnel are listed under "Personnel Required" only if more than one technician is needed in order to complete the task. If "Personnel Required" is not listed, it means that one technician can perform the task.
- d. Check all tags and forms attached to the Diesel Engine Assembly for any information about the reason it was removed from service. Modification work orders and technical bulletins must also be checked for equipment changes and updates.
- e. In some cases, a part may be damaged by removal. If the part appears to be good and other parts behind it are not defective, leave it on and continue with the procedure. Here are a few simple rules:
 - (1) Do not remove dowel pins or studs unless loose, bent, broken, or otherwise damaged.
 - (2) Do not remove bearings or bushings unless damaged. If you need to remove them to access parts, pull out bearings and bushings carefully.
 - (3) Replace all gaskets, seals, lockwashers, cotter pins, preformed packings, and other locking hardware.

2-8. WORK SAFETY.

- a. Observe all WARNINGS and CAUTIONS. Always use power tools carefully.
- b. Protect yourself against injury. Wear protective gear, such as safety goggles or lenses, safety shoes, a rubber apron, and gloves.
- c. When lifting heavy parts, have someone help you. Make sure lifting and jacking equipment is working properly, is suitable for the assigned task, and is secure against slipping.

2-9. CLEANING INSTRUCTIONS.

WARNING

Improper cleaning methods and the use of unauthorized cleaning liquids or solvents can injure personnel and damage equipment. To prevent this, refer to TM 9-247 for further instructions.

- a. **General.** Cleaning instructions will be the same for a majority of the parts and components that make up the Diesel Engine Assembly, Hatz 2 G 40. The following should apply to all cleaning, inspection, repair, and assembly operations:
 - (1) Clean all parts before inspection, after repair, and before assembly.
 - (2) Keep hands free of grease, which can collect dust, dirt, and grit.
 - (3) After cleaning, cover or wrap all parts to protect them from dust and dirt. Parts that are subject to rust should be lightly oiled.
- b. **Steam-Cleaning.**
 - (1) Before steam-cleaning exterior of engine, protect all electrical equipment that could be damaged by steam or moisture.
 - (2) Place disassembled parts in a suitable container to steam-clean. Parts that are subject to rust should be dried and lightly oiled after cleaning.
- c. **Castings, Forgings, and Machined Metal Parts.**

WARNING

Drycleaning solvent P-D-680 is toxic and flammable. Always wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes, and DO NOT breathe vapors. DO NOT use near open flame or excessive heat.

- (1) Clean inner and outer surfaces with drycleaning solvent (Item 4, Appendix D) and rag (Item 7, Appendix D).
- (2) Remove grease and accumulated deposits with a stiff-bristled brush.

2-9. CLEANING INSTRUCTIONS (continued).

WARNING

Compressed air used for cleaning or drying purposes, or for clearing restrictions, should never exceed 30 psi (207 kPa). Wear protective clothing (goggles/shield, gloves, etc.) and use caution to avoid injury to personnel.

- (3) Clear out all threaded holes with compressed air to remove dirt and cleaning fluids.

CAUTION

Do not wash oil seals, electrical cables, and flexible hoses with drycleaning solvent or mineral spirits. Serious damage or destruction of material would result.

- d. Oil Seals, Electrical Cables, and Flexible Hoses. Wash electrical cables and flexible hoses with a solution of water and dishwashing soap, and wipe dry.
- e. Bearings. Clean bearings in accordance with TM 9-214.

2-10. INSPECTION INSTRUCTIONS.

NOTE

All damaged areas should be marked for repair or replacement.

- a. All components and parts must be checked carefully to determine if they are serviceable for reuse, can be repaired, or must be scrapped.
- b. Inspect drilled and tapped (threaded) holes for the following:
- (1) In or around holes-wear, distortion (stretching), cracks, and any other damage.
 - (2) Threaded areas-wear, distortion (stretching), and evidence of cross-threading.
- c. Inspect metal lines (tubes), flexible lines (hoses), and metal fittings and connectors for the following:
- (1) Metal lines-sharp kinks, cracks, bad bends, and dents.
 - (2) Flexible lines-fraying, evidence of leakage, and loose metal fittings or connectors.
 - (3) Metal fittings and connectors-thread damage and worn or rounded hex heads.
- d. Inspect castings, forgings, and machined metal parts for the following:
- (1) Machined surfaces-nicks, burrs, raised metal, wear, and other damage.
 - (2) Inner and outer surfaces-breaks and cracks.
- e. Inspect bearings in accordance with TM 9-214.

2-11. REPAIR INSTRUCTIONS.

- a. Any repair procedure peculiar to a specific part or component is covered in the section or paragraph relating to that item. After repair, clean all parts thoroughly to prevent dirt, metal chips, or other foreign material from entering any working parts.
- b. Repair castings, forgings, and machined parts using the following instructions:
 - (1) Refer to TC 9-237 for instructions on repairing minor cracked castings or forgings.

WARNING

Drycleaning solvent P-D-680 is toxic and flammable. Always wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes, and DO NOT breathe vapors. DO NOT use near open flame or excessive heat.

- (2) Repair minor damage to machined surfaces with a fine mill file or abrasive cloth dipped in drycleaning solvent (Item 4, Appendix D).
- (3) Replace any deeply nicked machined surface that could affect the operation of the Diesel Engine Assembly.
- (4) Repair minor damage to a threaded capscrew hole with thread tap of same size, to prevent cutting the hole too large.

2-12. HOSE AND TUBE TAGGING.

- a. As soon as the first hose or tube is disconnected, write the number "1" on two tags. Secure one tag to the hose or tube and the other tag to the nipple or fitting. After disconnecting the second hose or tube, write the number "2" on two tags. Secure one tag to the hose or tube and the other tag to the nipple or fitting. Do the same for all hoses and tubes.
- b. Note which numbers you used, in pencil, on the art in this manual. This will help you retag properly when you remove tags from some parts to perform cleaning and maintenance work.
- c. Remove all tags when finished.

2-13. LUBRICATION INSTRUCTIONS.

To prevent corrosion, apply a light coat of lubricating oil to metal parts after they are cleaned and before they are assembled.

2-14. TORQUE VALUES.

Follow the torque values given in the maintenance procedures, which apply to unlubricated threads. If no torque value is given, refer to Appendix E.

SECTION IV. UNIT MAINTENANCE PROCEDURES

Paragraph Number	Page Paragraph Title	Number
2-15	Identification Plate Replacement	2-7
2-16	Eye Bolt Replacement (UOC: APP)	2-8
2-17	Rocker Arm Cover and O-ring Replacement	2-9
2-18	Filler Opening Cap Replacement (UOC: APP)	2-10
2-19	Oil Tube Assemblies Replacement	2-11
2-20	Filter Element Replacement (UOC: APP)	2-13
2-21	Intake Manifold Replacement	2-15
2-22	Valve Vent Repair	2-18
2-23	Fuel Pressure Pipe Assemblies and Return Fuel Hose Replacement	2-20
2-24	Airflow Deflectors Replacement (UOC: APP)	2-24
2-25	Oil Pressure Switch Replacement	2-28
2-26	Thermostatic Switch Replacement	2-29
2-27	Solenoid Replacement and Adjustment (UOC: APP)	2-30

2-15. IDENTIFICATION PLATE REPLACEMENT.

This Task Covers:

- a. Removal
- b. Installation

Initial Setup:

Tools/Test Equipment:

- Blind hand riveter (Item 2, Appendix G)
- Cable assembly (Item 3, Appendix G)
- Drill set (Item 10, Appendix G)
- Electric drill (Item 11, Appendix G)
- General mechanic's tool kit, automotive (Item 15, Appendix G)

Materials/Parts:

- Blind rivet (4) (Item 12, Appendix F)

Equipment Conditions:

- Airflow deflector removed from engine (UOC: APP) (para 2-24, removal steps 1-3).
- Airflow deflector removed from engine (UOC: APJ) (TM 9-2350-292-20-2).

a. REMOVAL


Remove four rivets (2) and identification plate (1) from airflow deflector (3).

b. INSTALLATION

Install identification plate (1) on airflow deflector (3) and secure with four rivets (2).

FOLLOW-ON TASKS:

- Install airflow deflector on engine (para 2-24, installation steps 11-13).



2-16. EYEBOLT REPLACEMENT (UOC: APP)

This Task Covers:

a. Removal

b. Installation

Initial Setup:

Tools/Test Equipment:


- General mechanic's tool kit, automotive (Item 14, Appendix G)
-

a. REMOVAL

Remove eyebolt (1) and shim (2) from collar nut (3).

b. INSTALLATION

Install shim (2) and eyebolt (1) in collar nut (3).



FOLLOW-ON TASKS:

- None

2-17. ROCKER ARM COVER AND O-RING REPLACEMENT.

This Task Covers:

- a. Removal
- b. Installation

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)

Materials/Parts:

- Grease, automotive (Item 5, Appendix D)
- O-ring (Item 33, Appendix F)
- Washer (2) (Item 29, Appendix F)

NOTE


The Diesel Engine Assembly has two rocker arm covers. Use this procedure to remove either one.

a. REMOVAL

1. Remove two screws (1) and washers (2) from rocker arm cover (3) and cylinder head (5). Discard washers.
2. Remove rocker arm cover (3) from cylinder head (5).
3. Remove O-ring (4) from groove in rocker arm cover (3). Discard O-ring.

b. INSTALLATION

1. Lightly coat new O-ring (4) with grease and install in groove in rocker arm cover (3).
2. Install rocker arm cover (3) on cylinder head (5).
3. Install two screws (1) and new washers (2) on rocker arm cover (3) and cylinder head (5).



FOLLOW-ON TASKS:

- None

2-18. FILLER OPENING CAP REPLACEMENT (UOC: APP).

This Task Covers:

a. Removal

b. Installation

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, (Item 14, Appendix G)

Materials/Parts:


- Grease, automotive (Item 5, Appendix D)
- O-ring (Item 28, Appendix F)

a. REMOVAL

1. Remove filler opening cap (1) and O-ring (3) from filler neck (2).
2. Remove O-ring (3) from cap (1). Discard O-ring.

b. INSTALLATION

1. Lightly coat new O-ring (3) with grease. Install O-ring (3) on cap (1).
2. Install cap (1) on filler neck (2).

**FOLLOW-ON TASKS:**

- None

2-19. OIL TUBE ASSEMBLIES REPLACEMENT.

This Task Covers:

a. Removal

b. Installation

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)
- Oil switch removed (para 2-25).

Materials/Parts:


- O-ring (Item 46, Appendix F)
- Washer (12) (Item 18, Appendix F)

Equipment Conditions:

- Airflow deflectors removed (only as many as needed to allow access to oil tubes) (para 2-24).
- Fuel pressure pipe assemblies removed (para 2-23).


a. REMOVAL

1. Remove fluid passage bolt (14) and two washers (12) from plate (11) and oil tube assembly (15). Discard washers.
2. Remove two screws (13) and plate (11) from timing cover (7). Remove O-ring (10) from plate (11). Discard O-ring.
3. Remove two fluid passage bolts (4) and four washers (5) from two cylinder heads (6) and oil tube assembly (9). Discard washers.
4. Remove screw (1), fluid passage bolt (3), connector (17), bushing (16), six washers (2), and two oil tube assemblies (9 and 15) from crankcase (8). Discard washers.



2-19. OIL TUBE ASSEMBLIES REPLACEMENT (continued).**b. INSTALLATION**

1. Install two oil tube assemblies (9 and 15), fluid passage bolt (3), connector (17), bushing (16), and six new washers (2) on crankcase (8). Loosely install screw (1) in fluid passage bolt (3).
2. Install four new washers (5) on two cylinder heads (6) and oil tube assembly (15) and secure loosely with two fluid passage bolts (4).
3. Install new O-ring (10) on plate (11). Install plate (11) and two screws (13) on timing cover (7).
4. Install two new washers (12) and fluid passage bolt (14) on plate (11) and oil tube assembly (15).
5. Tighten screw (1) and two fluid passage bolts (4).

**FOLLOW-ON TASKS:**

- Install fuel pressure pipe assemblies (para 2-23).
- Install oil switch (para 2-25).
- Install airflow deflectors (para 2-24), if any were removed.

2-20. FILTER ELEMENT REPLACEMENT (UOC: APP).

This Task Covers:

- a. Removal
- b. Cleaning
- c. Installation

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)
- Strap wrench (Item 29, Appendix G)

- Rag (Item 7, Appendix D)


- Filter element (Item 35, Appendix F)

Materials/Parts:

- Drycleaning solvent (Item 4, Appendix D)
 - Lubricating oil (Item 6, Appendix D)
-

a. REMOVAL

1. Remove filter element (4) from filter mount (3). Discard filter element).
2. Remove strainer element (1) from safety relief valve (2).



2-20. FILTER ELEMENT REPLACEMENT (UOC: APP) (continued).**b. CLEANING****WARNING**

Compressed air used for cleaning or drying purposes, or for clearing restrictions, should never exceed 30 psi (207 kPa). Wear protective clothing (goggles/shield, gloves, etc.) and use caution to avoid injury to personnel.

1. Clean strainer element (1) with compressed air.


WARNING

Drycleaning solvent P-D-680 is toxic and flammable. Always wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes, and DO NOT breathe vapors. DO NOT use near open flame or excessive heat.

2. Clean sealing surface (5) with drycleaning solvent and rag.

c. INSTALLATION

1. Install strainer element (1) on safety relief valve (2).
2. Apply light coat of oil to sealing ring of new filter element (4).
3. Install filter element (4) on filter mount (3).

**FOLLOW-ON TASKS:**

- None

2-21. INTAKE MANIFOLD REPLACEMENT.*This Task Covers:*

- a. Removal b. Installation

*Initial Setup:***Tools/Test Equipment:**

- General mechanic's tool kit, automotive (Item 15, Appendix G)
- Screwdriver attachment, 6 mm (Item 24, Appendix G)
- Socket wrench set, 3/8-inch drive (Item 27, Appendix G)

Materials/Parts:

- Gasket set (2) (Item 4, Appendix F)


- Gasket (2) (Item 8, Appendix F)
- Self-locking nut (4) (Item 15, Appendix F)
- Spring tension washer (4) (Item 25, Appendix F)
- Spring tension washer (8) (Item 31, Appendix F)

Equipment Conditions:

- Valve vent removed (para 2-22).
- Airflow deflectors removed as needed to permit replacement of air intake manifold (para 2-24).

a. REMOVAL

1. Remove four socket head screws (5) and spring tension washers (4), adapter (3), and four-part gasket (2) from Intake manifold (1). Discard spring tension washers and gasket.




2-21. INTAKE MANIFOLD REPLACEMENT (continued).

2. Remove two socket head screws (8) and socket head screws (9), four washers (7), spring tension washers (15), and nuts (16), access cover (14), and four-part gasket (6) from intake manifold (1). Discard spring tension washers and gasket.
3. Remove four self-locking nuts (10) and spring tension washers (11), intake manifold (1), and two gaskets (12) from four studs (13). Discard self-locking nuts, spring tension washers, and gaskets.


b. INSTALLATION

1. Install two new gaskets (12), intake manifold (1), and four new spring tension washers (11) and new self-locking nuts (10) on four studs (13).
2. Install new four-part gasket (6), access cover (14), four nuts (16), new spring tension washers (15), and washers (7), and two socket head screws (8) and socket head screws (9) on intake manifold (1).



2-21. INTAKE MANIFOLD REPLACEMENT (continued).

3. Install new four-part gasket (2), adapter (3), and four new spring tension washers (4) and socket head screws (5) on intake manifold (1).

**FOLLOW-ON TASKS:**

- Install valve vent (para 2-22).
- Install airflow deflectors (para 2-24), if removed.

2-22. VALVE VENT REPAIR.

This Task Covers:

- | | |
|-------------|-----------------|
| a. Removal | b. Disassembly |
| c. Assembly | d. Installation |

Initial Setup:

Tools/Test Equipment:


- General mechanic's tool kit, automotive (Item 15, Appendix G)

Materials/Parts:

- Grease, automotive (Item 5, Appendix D)
- O-ring (2) (Item 45, Appendix F)

a. REMOVAL

1. Remove valve vent (2) from intake manifold (5).
2. Remove hose (3) from hose coupling (4).



2-22. VALVE VENT REPAIR (continued).

b. DISASSEMBLY

1. Remove two O-rings (1) from valve vent (2). Discard O-rings.
2. Remove hose (3) from valve vent (2).

c. ASSEMBLY

1. Install hose (3) on valve vent (2).
2. Apply light coat of grease on two new O-rings (1). Install two O-rings (1) on valve vent (2).

d. INSTALLATION

1. Install hose (3) on hose coupling (4).
2. Install valve vent (2) on intake manifold (5).

FOLLOW-ON TASKS:

- None

2-23. FUEL PRESSURE PIPE ASSEMBLIES AND RETURN FUEL HOSE REPLACEMENT.

This Task Covers:

- a. Removal
- b. Installation

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, (Item 14, Appendix G)
- Torque wrench, 1/2-inch drive (Item 31, Appendix G)
- Wrench (Item 36, Appendix G)

Materials/Parts:


- Gasket (2) (Item 19, Appendix F)
- Gasket (4) (Item 40, Appendix F)
- Spring tension washer (Item 31, Appendix F)
- Washer (2) (Item 18, Appendix F)

a. REMOVAL

NOTE

Fuel pressure pipe nuts will stay on fuel pressure pipe assemblies when they are removed.

1. Loosen two fuel pressure pipe nuts on each of two fuel pressure pipe assemblies (9 and 12).
2. Remove two fuel pressure pipe assemblies (9 and 12) and clamp (7) from two injection pump fittings (11) and fuel injector fittings (10).
3. Remove screw (8) and nut (6) from clamp (7). Remove clamp (7) from two fuel pressure pipe assemblies (9 and 12).



NOTE: ITEMS 1 THROUGH 5 DELETED
 NOTE: FOR PURPOSES OF CLARITY, AIRFLOW DEFLECTORS ARE NOT SHOWN.

29i206m


2-23. FUEL PRESSURE PIPE ASSEMBLIES AND RETURN FUEL HOSE REPLACEMENT (continued).

NOTE

Steps 6-7 are done only if equipment has dual banjo fittings. Steps 8 and 9 are done only for single banjo fittings.

4. Remove fluid passage bolt (13), two washers (14), strap clamp (14.1), return fuel hose (4), adapter (15), two gaskets (23), and fitting (16) and fitting (20) from injection pump (22). Discard washers and gaskets.
5. Remove strap clamp (18.1) and hose (4) from fitting (21) or tee (21.1).
6. Remove two fluid passage bolts (17), four gaskets (18), and fuel hose (4.1) from two fuel injectors (19). Discard gaskets.
7. Remove two hose nipples (21) and two strap clamps (18.1) from return fuel hose (4.1).
8. Remove two fluid passage bolts (17), four gaskets (18) and two single banjo fittings (21.2) from two fuel injectors (19). Discard gaskets.
9. Remove six strap clamps (18.1) securing fuel return hoses (24 and 25) to tees (21.1) and separate hoses (24 and 25) from tees (21.1) and single banjo fitting (21.2).

NOTE: FOR PURPOSES OF CLARITY, AIRFLOW DEFLECTORS ARE NOT SHOWN.



29i207m

2-23. FUEL PRESSURE PIPE ASSEMBLIES AND RETURN FUEL HOSE REPLACEMENT (continued).


NOTE

Steps 1 and 2 are done only if equipment has dual banjo fittings. Steps 3.2 and 3.3 are done only if equipment has single banjo fittings.

b. INSTALLATION

1. Install two hose nipples (21) on return fuel hose (4.1) and secure with two strap clamps (18.1).
2. Install return fuel hose (4.1) and two fittings (21) on two fuel injectors (19) and secure with two fluid passage bolts (17) and four new gaskets (18).
3. Install two new gaskets (23), fitting (16), adapter (15), two new washers (14), return fuel hose (4) and fitting (20) and fluid passage bolt (13) on injection pump (22). Torque adapter to 26 ft-lb (35 N•m). Torque fluid passage bolt to 18.5 ft-lb (25 N•m). Secure return fuel hose (4) to fitting (20) with strap clamp (14.1).
- 3.1 Connect fuel hose (4) to fitting (21) or tee (21.1) and secure with strap clamps (18.1).
- 3.2 Install six strap clamps (18.1) to secure fuel return hoses (24 and 25) to tees (21.1) and single banjo (21.2).
- 3.3 Install two fluid passage bolts (17), four gaskets (18), and single banjo fittings (21.2) to two fuel injectors (19).


NOTE: FOR PURPOSES OF CLARITY, AIRFLOW DEFLECTORS ARE NOT SHOWN.



29i207m

**2-23. FUEL PRESSURE PIPE ASSEMBLIES AND RETURN FUEL HOSE REPLACEMENT
(continued).**

4. Install clamp (7) onto fuel pressure pipe assemblies (9 and 12) and secure with nut (6) and screw (8).
5. Install two fuel pressure pipe assemblies (9 and 12) and clamp (7) on two injection pump fittings (11) and fuel injector fittings (10). Secure by tightening two fuel pressure pipe nuts on each of two fuel pressure pipe assemblies (9 and 12).



NOTE: ITEMS 1 THROUGH 5 DELETED
NOTE: FOR PURPOSES OF CLARITY,
AIRFLOW DEFLECTORS ARE NOT SHOWN.

29i206m

2-24. AIRFLOW DEFLECTORS REPLACEMENT (UOC: APP).

This Task Covers:

- a. Removal
- b. Installation

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)

- Spring tension washer (6) (Item 30, Appendix F)
- Spring tension washer (2) (Item 31, Appendix F)

Materials/Parts:


- Split washer (3) (Item 41, Appendix F)

Equipment Conditions:

- Valve vent removed (para 2-22)

a. REMOVAL

1. Remove five screws (7) and washers (8) from airflow deflector (4).
2. Remove three screws (6) and split washers (5) from airflow deflector (4). Discard split washers.
3. Remove airflow deflector (4) from engine (3).
4. Remove two screws (10) and spring tension washers (11) and airflow deflector (9) from engine (3). Discard spring tension washers.




2-24. AIRFLOW DEFLECTORS REPLACEMENT (UOC: APP) (continued).

5. Remove three screws (17) from air duct bracket (12).
6. Remove two screws (15) and spring tension washers (16) from air duct bracket (12). Discard spring tension

CAUTION

Be careful not to damage fuel line when removing air duct.

7. Remove two screws (14) and spring tension washers (13), clip (1), fuel hose (2), and air duct bracket (12) from engine (3). Discard spring tension washers.
8. Remove three screws (24) from air duct bracket (23).
9. Remove two screws (26) and spring tension washers (25) from air duct bracket (23). Discard spring tension washers.
10. Remove two screws (19), washers (18), and spacers (32) and airflow deflector (22) from airflow deflector (21).
11. Remove two screws (20) and airflow deflector (21) from engine (3).
12. Remove air duct bracket (23) from engine (3).
13. Remove four screws (30), washers (29), and nuts (27) and airflow deflector (31) from flywheel (28).




2-24. AIRFLOW DEFLECTORS REPLACEMENT (UOC: APP) (continued).

b. INSTALLATION

NOTE

Install screws loosely, to allow some movement of air ducts brackets and air-flow deflectors during installation procedure.

1. Install four screws (30), washers (29), and nuts (27) and airflow deflector (31) on flywheel (28).
2. Install air duct bracket (23) on engine (3).
3. Install airflow deflector (21) and two screws (20) on engine (3).
4. Install two spacers (32), washers (18), and screws (19) and airflow deflector (22) on airflow deflector (21).




2-24. AIRFLOW DEFLECTORS REPLACEMENT (UOC: APP) (continued).

5. Install two new spring tension washers (25) and screws (26) on air duct bracket (23).
6. Install three screws (24) on air duct bracket (23).

CAUTION

Be careful not to damage fuel line when installing air duct bracket on engine.

7. Install air duct bracket (12) on engine (3) and secure with two new spring tension washers (16) and screws (15).
8. Position clip (1) and fuel hose (2) on air duct bracket (12). Install two new spring tension washers (13) and screws (14) on air duct bracket (12).
9. Install three screws (17) on air duct bracket (12).
10. Install airflow deflector (9) on engine (3) and secure with two new spring tension washers (11) and screws (10).
11. Install airflow deflector (4) on engine (3) and secure with five washers (8) and screws (7).
12. Install three new split washers (5) and screws (6) on airflow deflector (4).
13. Tighten all screws.



FOLLOW-ON TASKS:

- Install valve vent (para 2-22).

2-25. OIL PRESSURE SWITCH REPLACEMENT.

This Task Covers:

a. Removal

b. Installation

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)

Materials/Parts:

- Sealing compound (Item 17, Appendix D)
-

a. REMOVAL


NOTE

For easy access to oil switch, it may be necessary to loosen the screw (1) to turn manifold. (UOC: APP).

- Remove oil switch (2) from adapter (3).

b. INSTALLATION

- Coat threads of oil switch (2) with sealing compound (Item 17, Appendix D). Install switch (2) on adapter (3).



FOLLOW-ON TASKS:

- None

2-26. THERMOSTATIC SWITCH REPLACEMENT.

This Task Covers:

a. Removal

b. Cleaning

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)

Materials/Parts:


- Airflow deflectors removed as needed (UOC: APP) (para 2-24).
 - Airflow deflectors removed as needed (UOC: APJ) (TM 9-2350-292-20-2)
-

a. REMOVAL

Remove thermostatic switch (2) from cylinder head (1) on auxiliary drive side of engine.

b. INSTALLATION

Install thermostatic switch (2) in cylinder head (1) on auxiliary drive side of engine.



FOLLOW-ON TASKS:

- Install airflow deflectors (para 2-24), if any were removed (UOC:APP).
- Install airflow deflectors (TM 9-2350-292-20-2), if any were removed (UOC:APJ).

2-27. SOLENOID REPLACEMENT AND ADJUSTMENT (UOC:APP).

This Task Covers:

- | | |
|---|---|
| <ul style="list-style-type: none"> a. Removal c. Adjustment | <ul style="list-style-type: none"> b. Installation |
|---|---|

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)
- Screwdriver attachment, 6 mm (Item 24, Appendix G)


- Socket wrench set, 3/8-inch drive (Item 27, Appendix G)

Materials/Parts:

- O-ring (Item 32, Appendix F)

a. REMOVAL

1. Remove two clips (2) from connecting link (1). Remove connecting link (1) from governor lever (4), plunger (3), and solenoid (8).
2. Remove two screws (7) and washers (6) and solenoid (8) from bracket (5).
3. Remove stud (10) from solenoid (8). Remove connector (12) and two nuts (9 and 11) from stud (10).




2-27. SOLENOID REPLACEMENT AND ADJUSTMENT (UOC:APP) (continued).

4. Remove screw (17) and plunger (3) from bracket (5).
5. Remove bellows (19) and O-ring (18) from plunger (3). Discard O-ring.
6. Remove screw (16) from bracket (5) and crankcase (20).
7. Remove nut (15), washer (14), and bracket (5) from screw (13) and crankcase (20).


b. INSTALLATION

1. Install bracket (5), washer (14), and nut (15) on screw (13) and crankcase (20).
2. Install screw (16) on bracket (5) and crankcase (20).
3. Install new O-ring (18) and bellows (19) on plunger (3).
4. Install plunger (3) and screw (17) on bracket (5).




2-27. SOLENOID REPLACEMENT AND ADJUSTMENT (UOC:APP) (continued).

5. Install two nuts (9 and 11) and connector (12) on stud (10). Install stud (10) on solenoid (8).
6. Install solenoid (8) and two washers (6) and screws (7) on bracket (5).
7. Install connecting link (1) in plunger (3), governor lever (4), and solenoid (8). Secure connecting link (1) with two clips (2).



c. ADJUSTMENT

1. Loosen two nuts (9 and 11) on stud (10).
2. Remove top clip (2) from connecting link (1). Remove connecting link (1) from governor lever (4) and plunger (3).
3. Rotate governor lever (4) fully counterclockwise, to the off position, and push stud (10) all the way down.
4. Turn stud (10) until connecting link (1) reaches governor lever (4) while stud (10) remains pushed all the way down. Install connecting link (1) in governor lever (4) and plunger (3).
5. Tighten two nuts (9 and 11).
6. Install top clip (2) on connecting link (1).



FOLLOW-ON TASKS:

- None

**CHAPTER 3
DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE**

Section I. DIRECT SUPPORT AND GENERAL SUPPORT TROUBLESHOOTING

Paragraph Number	Paragraph Title	Page Number
3-1	General.....	3-1
3-2	Quick Guide to Troubleshooting.....	3-2
3-3	Troubleshooting Chart.....	3-3

3-1. GENERAL.

- a. This section provides information for identifying and correcting malfunctions that may develop while operating or maintaining the Diesel Engine Assembly, Hatz 2 G 40.
- b. The Quick Guide to Troubleshooting (para 3-2) lists common malfunctions of the diesel engine or its components and refers you to the appropriate paragraph in the Troubleshooting Chart (para 3-3). You should perform the tests/inspections and corrective actions in the order listed in the chart.
- c. If you are unsure of the location of an item mentioned in troubleshooting, refer to paragraph 1-12 or to the maintenance task where the item is replaced.
- d. Before performing troubleshooting, read and follow all safety instructions listed in the warning summary at the beginning of this manual.
- e. This section cannot list all malfunctions that may occur, or all tests or inspections and corrective actions. If a malfunction is not listed or is not corrected by the corrective action listed, notify your supervisor.
- f. When troubleshooting a malfunction:
 - In the Quick Guide to Troubleshooting, locate the symptom or symptoms that best describe the malfunction.
 - Turn to the subparagraph in the Troubleshooting Chart where the troubleshooting procedures for the malfunction in question are described.
 - Perform each step in the order listed until the malfunction is corrected. DO NOT perform any maintenance task unless the troubleshooting procedure tells you to do so.
- g. When troubleshooting any electrical system or component, exercise extreme care in order to prevent electric shock.

WARNING

- **To prevent injury due to electric shock throughout troubleshooting of the electrical system or electrical components, be certain MASTER switch is turned off between every step unless otherwise directed.**
- **To prevent injury due to electric shock, remove all jewelry and metal objects when working on the electrical system.**
- h. The multimeter is used throughout troubleshooting of the electrical system. When using the multimeter, make sure it is used with a probe kit.
- i. When performing a continuity check, connect the meter probes to both terminals of the circuit you are testing. Read the meter and interpret the results. If the needle swings to near 0 on the top scale, the circuit has continuity. If the needle does not move, the circuit is open. If the needle jumps or flickers, there is a loose connection.




3-2. QUICK GUIDE TO TROUBLESHOOTING.

ITEM	SYMPTOM	PARAGRAPH
ENGINE	ENGINE CRANKS, BUT STARTS HARD OR FAILS TO START.	para 3-3a(i)
	OIL CONSUMPTION IS EXCESSIVE.	para 3-3a(2)
	FUEL CONSUMPTION IS EXCESSIVE, AND THERE IS BLACK EXHAUST SMOKE.	para 3-3a(3)
	ENGINE HAS LOW POWER OR MISFIRES.	para 3-3a(4)
	ENGINE MAKES A KNOCKING SOUND.	para 3-3a(5)
GOVERNOR	ENGINE SPEED IS ERRATIC.	para 3-3b

3-3. TROUBLESHOOTING CHART.

a. ENGINE

(1) ENGINE CRANKS, BUT STARTS HARD OR FAILS TO START.




FOR PURPOSES OF CLARITY, AIRFLOW DEFLECTORS AND INTAKE MANIFOLD ARE NOT SHOWN.

3-3. TROUBLESHOOTING CHART (continued).

a. ENGINE

(1) ENGINE CRANKS, BUT STARTS HARD OR FAILS TO START (continued).

CONTINUED FROM STEP C






END OF TASK

3-3. TROUBLESHOOTING CHART (continued).

a. ENGINE

(2) OIL CONSUMPTION IS EXCESSIVE.




3-3. TROUBLESHOOTING CHART (continued).

a. ENGINE

(2) OIL CONSUMPTION IS EXCESSIVE (continued).

CONTINUED FROM STEP C





END OF TASK

3-3. TROUBLESHOOTING CHART (continued).

a. ENGINE




(3) FUEL CONSUMPTION IS EXCESSIVE, AND THERE IS BLACK EXHAUST SMOKE.



3-3. TROUBLESHOOTING CHART (continued).

a. ENGINE

(4) ENGINE HAS LOW POWER OR MISFIRES.






FOR PURPOSES OF CLARITY, AIRFLOW DEFLECTORS AND INTAKE MANIFOLD ARE NOT SHOWN.

3-3. TROUBLESHOOTING CHART (continued).

a. ENGINE

(5) ENGINE MAKES A KNOCKING SOUND.




FOR PURPOSES OF CLARITY, AIRFLOW DEFLECTORS AND INTAKE MANIFOLD ARE NOT SHOWN.


3-3. TROUBLESHOOTING CHART (continued).

a. ENGINE

(5) ENGINE MAKES A KNOCKING SOUND (continued).




END OF TASK




3-3. TROUBLESHOOTING CHART (continued).

b. GOVERNOR


ENGINE SPEED IS ERRATIC.



END OF TASK



FOR PURPOSES OF CLARITY, AIRFLOW DEFLECTORS AND INTAKE MANIFOLD ARE NOT SHOWN.



SECTION II. DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE PROCEDURES

Paragraph Number	Paragraph Title	Page Number
3-4	Mounting Plates Replacement	3-12
3-4.1	Auxiliary Drive Adapter Replacement	3-14.1
3-5	Cylinder Heads Repair	3-15
3-6	Crankcase Repair	3-20
3-7	Crankshaft and Bearings Repair	3-26
3-8	Flywheel and Housing Replacement	3-28
3-9	Piston and Combustion Chamber Liner Repair	3-32
3-10	Rocker Arm Assemblies Repair	3-38
3-11	Camshaft Repair	3-40
3-12	Filler Neck Replacement (UOC: APP)	3-46
3-13	Oil Pan and Gasket Replacement (UOC: APP)	3-47
3-13.1	Deep Oil Pan and Gasket Replacement (UOC: APJ)	3-47.1
3-14	Fuel Injector Replacement	3-48
3-15	Injection Pump Replacement	3-50
3-16	Governor Control Assembly Repair	3-54

3-4. MOUNTING PLATES REPLACEMENT.

This Task Covers:

- a. Removal
- b. Cleaning
- c. Installation

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)
- Screwdriver attachment, 6 mm (Item 24, Appendix G)
- Socket wrench set, 3/8-inch drive (Item 27, Appendix G)
- Grease, automotive (Item 5, Appendix D)
- Rag (Item 7, Appendix D)
- Sealing compound (Item 10, Appendix D)
- Sealing compound (Item 12, Appendix D)
- Lockwasher (8) (Item 23, Appendix F)
- Seal (Item 48, Appendix F)

Materials/Parts:

- Drycleaning solvent (Item 4, Appendix D)

Equipment Conditions

- Auxiliary Drive Adapter Removed (para 3-4.1)

a. REMOVAL

NOTE

Mark position of engine mounting plate on crankcase before removing mounting plate from crankcase.

1. Remove eight screws (6) and lockwashers (7) and engine mounting plate (5) from crankcase (1). Discard lockwashers.
2. Remove four screws (3) and mounting plate (2) from crankcase (1).
3. Remove seal (4) from mounting plate (2). Discard seal.


3-4. MOUNTING PLATES REPLACEMENT (continued).

b. CLEANING

WARNING

Drycleaning solvent P-D-680 is toxic and flammable. Always wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes, and DO NOT breathe vapors. DO NOT use near open flame or excessive heat.

Using drycleaning solvent and a rag, clean sealing compound from both mounting plates.



29i210ma

3-4. MOUNTING PLATES REPLACEMENT (continued).

c. INSTALLATION

1. Apply light coat of grease to new seal (4). Install seal (4) on mounting plate (2) with secondary sealing lip facing inboard and primary sealing lip facing outboard.
2. Apply sealing compound (Item 10, Appendix D) under four screws (3) and designated surface of crankcase (1) that will come in contact with mounting plate (2).
- 2.1 Apply loctite 242 (Item 13, Appendix D) to threads of screws (3).

CAUTION


Use extreme caution not to damage new seal when installing mounting plate on crankcase.

3. Install mounting plate (2) on crankcase (1) and secure with four screws (3). Torque screws (35-38 ft-lbs (47-52 N•m)).

NOTE

Use marks made during removal to install engine mounting plate correctly.

4. Apply sealing compound (Item 12, Appendix D) to eight screws (6). Install engine mounting plate (5) on crankcase (1) and secure with eight new lockwashers (7) and screws (6). Torque screws (35-38 ft-lbs (47-52 N•m)).



FOLLOW-ON TASKS:

- install drive adapter (para 3-4.1)

29i210m

3-4.1 AUXILIARY DRIVE ADAPTER REPLACEMENT

This Task Covers:

- a. Removal b. Installation
-

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)

Materials/Parts:


- Sealing compound (Item 13, Appendix D)
-

a. REMOVAL

Remove socket screw (1), lockwasher (2), woodruff key (3) and drive adapter (4) from crankshaft (5).

b. INSTALLATION

1. Install drive adapter (4) with woodruff key (3) onto crankshaft (5).
2. Apply sealing compound (Item 13, Appendix D) to threads of socket screw (1).
3. Install socket screw (1), lockwasher (2) into crankshaft (5). Torque screw to 37 ft-lb (50 N•m).



3-5. CYLINDER HEADS REPAIR

This Task Covers:

- a. Removal
- b. Cleaning and Inspection
- c. Adjustment
- d. Machining
- e. Installation.

Initial Setup:

Tools/Test Equipment:

- Cylinder alignment bracket (Item 6, Appendix G)
- Depth gage rule (Item 9, Appendix G)
- General mechanic's tool kit, automotive (Item 15, Appendix G)
- Torque wrench, 1/2-inch drive (Item 31, Appendix G)
- Valve face grinding machine (Item 33, Appendix G)
- Valve seat grinding kit (Item 34, Appendix G)
- Valve spring lifter (Item 35, Appendix G)

Materials/Parts:


- Carbon-removing compound (Item 3, Appendix D)
- Drycleaning solvent (Item 4, Appendix D)
- Rag (Item 7, Appendix D)
- Head gasket set (Item 3, Appendix F)

Equipment Conditions:

- Eyebolt removed (UOC: APP) (para 2-16).
- Lifting bracket removed (UOC: APJ) (TM 9-2350-292-20-2)
- Rocker arm assemblies removed (para 3-10).
- Airflow deflectors removed (UOC: APP) (para 2-24).
- Air flow deflectors removed (UOC: APJ) (TM 9-2350-292-20-2)
- Intake manifold removed (para 2-21).
- Fuel injectors removed (para 3-14).
- Oil tube assemblies removed (para 2-19).
- Exhaust manifold removed (UOC: APJ)
- Thermostatic switch removed (para 2-26).

a. REMOVAL

1. Remove two push rods (2) from each of two guides (1).
2. Remove five extended plain nuts (4), three plain nuts (5), and eight washers (3) from eight studs (8).
3. Remove two cylinder heads (6) and gaskets (7) from two combustion chamber liners (9). Discard gaskets.



3-5. CYLINDER HEADS REPAIR (continued).

4. Remove two guides (1) from two recesses in crankcase (11).
5. Remove two O-rings (10) from two grooves in each of two guides (1). Discard O-rings.

NOTE

- There are two valves, intake and exhaust, in each of two cylinder heads. Follow steps 6 and 7 for each of them.
- Part numbers are different for the intake and exhaust valves, but the valves are removed the same way. This procedure describes the removal of an exhaust valve.

6. Using a valve spring lifter, compress valve spring (14) and remove two valve spring retainer locks (12) from valve spring (14) and exhaust valve (16).
7. Remove valve spring retainer washer (13), valve spring (14), and base spring washer (15) from exhaust valve (16). Remove exhaust valve (16) from bottom of cylinder head (6).



b. CLEANING AND INSPECTION

1. Inspect four push rods for bends or wear on four sockets at ends of push rods. Replace any push rods if bent or if sockets are worn.
2. Clean valves and valve seats with carbon removing compound.

WARNING

Drycleaning solvent P-D-680 is toxic and flammable. Always wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes, and DO NOT breathe vapors. DO NOT use near open flame or excessive heat.

3. Using drycleaning solvent and rag, clean valves, springs, washers, locks, and valve seat.



3-5. CYLINDER HEADS REPAIR (continued).

4. Inspect valves and valve seats for cracks, burns, or bends. Replace any cracked, burned, or bent valves. If valve seats are cracked or burned, replace cylinder head.

c. ADJUSTMENT**CAUTION**


If, after removing the cylinder head, you have replaced the combustion chamber liner, piston, connecting rod, or crankshaft, the valve-to-piston clearance must be checked.

Too little clearance will result in damage to pistons, cylinder heads, and valves. Too much clearance will cause the engine to lose power and be difficult to start.

NOTE

- There are two pistons on the engine. Follow steps 1 through 4 to adjust the valve-to-piston clearance on each of them.
- Gaskets come in various thicknesses. It may be necessary to try several different gaskets to achieve the desired valve-to-piston clearance. Use only one gasket on each combustion chamber liner.

1. Install new gasket (7), with a thickness of 0.60 mm, and cylinder alignment bracket (18) on combustion chamber liner (9).

**NOTE**


Make sure piston is as high as possible in the combustion chamber.

2. Place bottom of depth gage rule (17) across piston (20) and gasket (7). Loosen screw (19) and slide depth gage rule (17) down to crown of piston (20). Be sure to measure highest part of piston (20). Tighten screw (19) and read measurement. Clearance should be no less than 0.024 inch (0.61 mm) and no greater than 0.026 inch (0.66 mm).
3. If clearance is incorrect, repeat steps 1 and 2 using a gasket with a different thickness.
4. When clearance is correct, remove cylinder alignment bracket (18) from combustion chamber liner (9), leaving gasket (7) in place.

3-5. CYLINDER HEADS REPAIR (continued).

d. MACHINING

Grind exhaust valve (16) and valve seat (21) to a 45-degree angle. If necessary, repeat for other valves.





e. INSTALLATION

NOTE


- There are two valves, intake and exhaust, in each of two cylinder heads. Follow steps 1 and 2 for each of them.
- Part numbers are different for the intake and exhaust valves, but the valves are installed the same way. This procedure describes the installation of an exhaust valve.

1. Install exhaust valve (16) in cylinder head (6). Place base spring washer (15) over exhaust valve (16). Install valve spring (14) over exhaust valve (16) so it is seated on base spring washer (15). Place valve spring retainer washer (13) on valve spring (14).
2. Using a valve spring lifter, compress valve spring (14) and install two valve spring retainer locks (12) in valve spring retainer washer (13).
3. Install two new O-rings (10) in two grooves on each of two guides (1).
4. Install two guides (1) in two recesses in crankcase (11).



3-5. CYLINDER HEADS REPAIR (continued).


5. Install two push rods (2) in two guides (1). Make sure each push rod (2) rests on a tappet (22).
6. Place two cylinderheads (6) on two combustion chamber liners (9), making sure two gaskets (7) are in place.



7. Install eight washers (3), five extended plain nuts (4), and three plain nuts (5) on eight studs (8). Torque nuts to 40 ft-lb (55 Nom). See diagram below for correct placement of extended plain nuts (4) and plain nuts (5).

FOLLOW-ON TASKS:

- Install thermostatic switch (para 2-26).
- Install exhaust manifold (UOC: APJ) (TM 9-2350-292-20-2)
- Install oil tube assemblies (para 2-19).
- Install fuel injectors (para 3-14).
- Install intake manifold (para 2-21).
- Install airflow deflectors (UOC: APP) (para 2-24).
- Install airflow deflectors (UOC: APJ) (TM 9-2350-292-20-2)
- Install rocker arm assemblies (para 3-10).
- Install eyebolt (UOC: APP) (para 2-16).
- Install lifting bracket (UOC: APJ) (TM 9-2350-292-20-2)



3-6. CRANKCASE REPAIR

This Task Covers:

- | | |
|---|---|
| <ul style="list-style-type: none"> a. Disassembly c. Test | <ul style="list-style-type: none"> b. Assembly |
|---|---|
-

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)
- Steel rule (Item 28, Appendix G)

Materials/Parts:

- Grease, automotive (Item 5, Appendix D)
- Lubricating oil (Item 6, Appendix D)
- Sealing compound (Item 10, Appendix D)
- Crankcase gasket set (Item 1, Appendix F)
- Shim (Item 5 or 6, Appendix F)
- Spring tension washer (2) (Item 31, Appendix F)


Personnel Required: Two

Equipment Conditions:

- Pistons and combustion chamber liners removed (para 3-9)
 - Flywheel, auxiliary drive hardware, and flywheel housing removed (para 3-8)
 - Solenoid removed (para 2-27)
 - Governor control assembly removed (para 3-16)
-

a. DISASSEMBLY


1. Remove shim (2) from camshaft gear (1).



2. Remove hose coupling (6) and gasket (7) from upper crankcase (23). Discard gasket.
3. Remove two screws (18) and spring tension washers (17), access cover (16), and gasket (15) from upper crankcase (23). Discard gasket and spring tension washers.


3-6. CRANKCASE REPAIR (continued).

4. Remove nut (21), two washers (3), and screw (4) from upper crankcase (23) and lower crankcase (22) on injection-pump side of engine.
5. Remove three nuts (5), washers (20), and screws (19) from upper crankcase (23) and lower crankcase (22) on injection-pump side of engine.
6. Remove three nuts (14), six washers (9), and three screws (8) from upper crankcase (23) and lower crankcase (22) on starter side of engine.
7. Remove two nuts (10), four washers (11), two screws (13), and air duct bracket (12) from upper crankcase (23) and lower crankcase (22).





3-6. CRANKCASE REPAIR (continued).

8. Remove upper crankcase (23) from eight studs (24) on lower crankcase (22). Set upper crankcase (23) top down on work surface.
9. Inspect eight studs (24) and remove any bent or damaged studs from lower crankcase (22). Discard removed studs.
10. Remove two gaskets (25 and 26) from upper crankcase (23). Discard gaskets.
11. Remove eight O-rings (27) from eight grooves in upper crankcase (23). Discard O-rings.



b. ASSEMBLY

1. Apply grease to eight new O-rings (27). Install eight O-rings (27) on eight grooves in upper crankcase (23).
2. Apply sealing compound to ends of two new gaskets (25 and 26). Lightly coat the rest of each gasket (25 and 26) with lubricating oil. Install two gaskets (25 and 26) on upper crankcase (23).



3. Apply GAA (Item 5, Appendix D) to threads of studs (24). Install eight new studs (24), if removed.


CAUTION

During installation of upper crankcase, rotate crank gear so timing mark on crank gear is between two timing marks on camshaft gear. Failure to align timing marks correctly may cause damage to the engine.

4. With the aid of an assistant, install upper crankcase (23) on eight studs (24) and lower crankcase (22). Make sure timing marks on crankshaft gear (28) and camshaft gear (1) are aligned and that two gaskets (25 and 26) and eight O-rings (27) stay in place.

3-6. CRANKCASE REPAIR (continued).


5. Install air duct bracket (12) on upper crankcase (23) and lower crankcase (22). Secure loosely with two screws (13), four washers (11), and two nuts (10)
6. Install three screws (8), six washers (9), and three nuts (14) loosely securing upper crankcase (23) to lower crankcase (22) on starter side of engine.
7. Install three screws (19), washers (20), and nuts (5) loosely securing upper crankcase (23) to lower crankcase (22) on injection-pump side of engine.
8. Install screw (4), two washers (3), and nut (21) loosely securing upper crankcase (23) to lower crankcase (22) on injection-pump side of engine.
9. Tighten nine screws (13, 8, 19, and 4), starting with the center front and back of the engine.
10. Install new gasket (15), access cover (16), and two new spring tension washers (17) and screws (18) on upper crankcase (23).
11. Install new gasket (7) and hose coupling (6) on upper crankcase (23).




3-6. CRANKCASE REPAIR (continued).**c. TEST****NOTE**

- This test procedure determines the offset between the camshaft gear and the crankshaft gear and gives instruction about how to correct the offset, if necessary.
- Perform this test only if the camshaft, camshaft gear, crankshaft, or crankshaft gear has been replaced.

1. Place steel rule (29) across crankshaft gear (28) and camshaft gear (1). Using feeler gage, measure any distance at point A between steel rule (29) and camshaft gear (1). There should be 0.00-inch gap.




2. On camshaft gear (1), install shim(s) (2) of appropriate thickness to completely fill any distance measured in step 1.



3-6. CRANKCASE REPAIR (continued).**NOTE**

When correct size and number of shim(s) are used, steel rule will be in contact with both crankshaft gear and top shim on camshaft gear.

- Place steel rule (29) across crankshaft gear (28) and camshaft gear (1). Measure the distance at point B and point C between crankcase sealing surfaces (30) and steel rule (29). If measurement is between 0.00 inch and 0.0039 inch (0.00 mm and 0.10 mm), install gasket on flywheel housing (para 3-8). If measurement is between 0.0043 inch and 1.18 inches (0.11 and 0.30 mm), install two gaskets on flywheel housing (para 3-8).

**FOLLOW-ON TASKS:**

- Install governor control assembly (para 3-16).
- Install solenoid (para 2-27).
- Install flywheel, auxiliary drive hardware, and flywheel housing (para 3-8).
- Install pistons and combustion chamber liners (para 3-9).

3-7. CRANKSHAFT AND BEARINGS REPAIR.

This Task Covers:

- a. Removal
- b. Inspection
- c. Installation

Initial Setup:

Tools/Test Equipment:

- Crank gear driver (Item 4, Appendix G)
- Crank gear puller (Item 5, Appendix G)
- General mechanic's tool kit (Item 14, Appendix G)
- Relief valve puller (Item 23, Appendix G)
- Screwdriver attachment, 8 mm (Item 25, Appendix G)
- Socket wrench set, 3/8-inch drive (Item 27, Appendix G)

Materials/Parts:

- Lubricating oil (Item 6, Appendix D)
- Sealing compound (Item 12, Appendix D)
- Crankcase gasket set (Item 1, Appendix F)
- Sleeve bearing (3) (Item 34, Appendix F)

Equipment Conditions:

- Crankcase disassembled (para 3-6).
- Camshaft removed (para 3-11).


a. REMOVAL

1. Remove seal (3) from auxiliary drive end of crankshaft (2). Discard seal.

CAUTION

To prevent warping, crankshaft must be placed standing up in flywheel.

2. Remove crankshaft (2) from lower crankcase (5).
3. Remove three sleeve bearing halves (4) from three upper crank supports (9) (upper crankcase), and remove three sleeve bearing halves (4) from three lower crank supports (6) (lower crankcase). Discard sleeve bearing halves.
4. Remove flow control valve (8) from lower crankcase (5).
5. Using crank gear puller, remove crank gear (1) from crankshaft (2).
6. Using relief valve puller, remove relief valve (7) from lower crankcase (5).



3-7. CRANKSHAFT AND BEARINGS REPAIR (continued).


b. INSPECTION

Inspect crankshaft for scoring, nicks, and excessive wear. Replace if necessary.

Inspect bushing (2.1) internal threads for damage. Bushing (2.1) should not be removed unless damaged.

c. INSTALLATION

1. Install relief valve (7) in lower crankcase (5) with grooved side facing auxiliary drive side of engine.
2. Install crank gear (1) on crankshaft (2). Make sure timing mark is facing end of crankshaft (2).
- 2.1 If installing bushing (2.1), apply primer (Item 19, Appendix D) to threads of bushing.
- 2.2 Apply loctite 271 (Item 20, Appendix D) to threads of bushing (2.1). Torque to 20 lb-ft (27 N•m). Allow to cure for 6 hours before assembly.
3. Apply sealing compound (Item 10, Appendix D) to new seal (3). Install seal (3) on crankshaft (2) with lip facing inward.
4. Install flow control valve (8) in lower crankcase (5) with eccentric at approximately the 11 o'clock position. Tighten flow control valve (8) into lower crankcase (5) until it projects 3/4 inch (19.1 mm) from lower crankcase (5).
5. Apply sealing compound (Item 21, Appendix D) to sleeve bearing halves (4) and bearing surfaces. Install three new sleeve bearing halves (4) in three upper crank supports (9), and install three sleeve bearing halves (4) in three lower crank supports (6). Keep matching bearings together.
6. Apply light coat of lubricating oil to crankshaft (2). Install crankshaft (2) in lower crankcase (5).



FOLLOW-ON TASKS:

- Install camshaft (para 3-11).
- Assemble crankcase (para 3-6).
- Adjust engine speed (para 3-18).

3-8. FLYWHEEL AND HOUSING REPLACEMENT.*This Task Covers:*

a. Removal

b. Installation

*Initial Setup:***Tools/Test Equipment:**

- General mechanic's tool kit automotive (Item 15, Appendix G)
- Mechanical gear and bearing puller kit (Item 17, Appendix G)
- Torque wrench, 1/2-inch drive (Item 31, Appendix G)

Materials/Parts:

- Crankcase gasket set (Item 1, Appendix F)


- O-ring (item 44, Appendix F)
- Spring tension washer (Item 27, Appendix F)

Equipment Conditions:

- **Oil tube assemblies removed (para 2-19).**
- Airflow deflectors removed (UOC:APP) (para 2-24).
- Airflow deflectors removed (UOC:APJ) (TM 9-2350-292-20-2).

a. REMOVAL

1. Remove nut (1) and washer (2) from crankshaft (8).
2. Using mechanical gear puller, remove flywheel (3) from crankshaft (8).
3. Remove key (9) from crankshaft (8).



3-8. FLYWHEEL AND HOUSING REPLACEMENT (continued).

4. Remove oil drain plug (17) and gasket (18) from flywheel housing (19). Discard gasket.

NOTE


Pin for intermediate gear may come off with flywheel housing.

5. Remove screw (14), 18 screws (15), 19 washers (13), and flywheel housing (19) from crankcase (10).

NOTE

There may be one or two gaskets on flywheel housing. Remove all of them, and note how many gaskets are removed from flywheel housing.


6. Remove one or two gaskets (11) from flywheel housing (19). Discard gasket(s).
7. Remove O-ring (12) from flywheel housing (19). Discard O-ring.
8. Remove seal (16) from crankshaft opening (20). Discard seal.
9. Remove two screws (23) and washers (22) and plate (21) from flywheel housing (19).



3-8. FLYWHEEL AND HOUSING REPLACEMENT (continued).


b. INSTALLATION

1. Install two screws (23) and washers (22) and plate (21) on flywheel housing (19).
2. Install new seal (16) in crankshaft opening (20), with lip of seal (16) facing inward.
3. Install new O-ring (12) on flywheel housing (19).
4. Apply sealing compound (Item 17, Appendix D) to surfaces of gasket(s) (11). Depending on the number removed, install one or two new gaskets (11) on flywheel housing (19).
5. Install flywheel housing (19) on crankcase (10) and secure with screw (14), 18 screws (15), and 19 washers (13).
6. Install oil drain plug (17) and new gasket (18) in flywheel housing (19) and crankcase (10).



3-8. FLYWHEEL AND HOUSING REPLACEMENT (continued).

7. Install key (9) in crankshaft (8). Install flywheel (3), washer (2), and nut (1) on crankshaft (8). Torque nut to 148 ft-lb (200 N·m).

**FOLLOW-ON TASKS:**

- Install airflow deflectors (UOC:APP) (para 2-24).
- Install airflow deflectors (UOC:APJ) (TM 9-2350-292-20-2).
- Install oil tube assemblies (para 2-19).

3-9. PISTON AND COMBUSTION CHAMBER LINER REPAIR.

This Task Covers:

- | | |
|-----------------|----------------|
| a. Removal | b. Disassembly |
| c. Cleaning | d. Assembly |
| e. Installation | |

Initial Setup:

Tools/Test Equipment:

- Cylinder ridge reamer (Item 8, Appendix G)
- General mechanic's tool kit, automotive (Item 15, Appendix G)
- Piston ring compressor (Item 21, Appendix G)
- Piston ring expander (Item 22, Appendix G)
- Screwdriver attachment, 6 mm (Item 24, Appendix G)
- Snapping pliers (Item 26, Appendix G)
- Socket wrench set, 3/8-inch drive (Item 27, Appendix G).
- Torque wrench, 3/8-inch drive (Item 30, Appendix G)

- Drycleaning solvent (Item 4, Appendix D)
- Lubricating oil (Item 6, Appendix D)
- Rag (Item 7, Appendix D)
- Cap-plug (2) (Item 10, Appendix F)
- Cap-plug (4) (Item 11, Appendix F)
- Piston ring set (2) (Item 2, Appendix F)
- Retaining ring (4) (Item 47, Appendix F)
- Shim (2) (Item 9, Appendix F)
- Sleeve bearing (2) (Item 7, Appendix F)

Materials/Parts:

- Carbon-removing compound (Item 3, Appendix D)

Personnel Required:

Equipment Conditions:


- Cylinder heads removed (para 3-5).
- Engine placed on side.
- Oil pan removed (UOC: APP) (para 3-13).
- Oil pan removed (UOC: APJ) (para 3-13.1).

a. REMOVAL

NOTE

There are two connecting rod caps on the engine. Repeat steps 1 and 2 to remove each of them.


1. Turn crankshaft (4) so crankshaft journal for connecting rod cap (5) to be removed is in its lowest position.
2. Remove two connecting rod screws (6) and connecting rod cap (5) from connecting rod (1).
3. Remove two combustion chamber liners (2), with two pistons inside, from crankcase (3).



3-9. PISTON AND COMBUSTION CHAMBER LINER REPAIR (continued).**CAUTION**

Each connecting rod and connecting rod cap is stamped with a number, and each also has a notch on one side. Each connecting rod cap must be installed on the connecting rod stamped with the same number and with the notches on the same side.

4. Using the numbers stamped on the two connecting rods (1) and connecting rod caps (5), loosely install connecting rod cap (5) and two screws (6) on each connecting rod (1), making sure the notches are on the same side.
5. Loosen screw (7) on bracket (8) and clamping sheet (10). Remove bracket (8) and clamping sheet (10) by lifting them straight up until they are free of two studs (13).
6. Remove two cap-plugs (11) and four cap-plugs (12) from eight studs (13). Discard cap-plugs.
7. Remove two shims (9) from crankcase (3). Discard shims.



3-9. PISTON AND COMBUSTION CHAMBER LINER REPAIR (continued).

8. Remove two pistons (15) and connecting rods (1) from two combustion chamber liners (2)


b. DISASSEMBLY

1. Remove two connecting rod caps (5) and four screws (6) from two connecting rods (1). Remove two sleeve bearing halves (18) from each of two connecting rods (1) and connecting rod caps (5). Discard bearing halves. Loosely install two connecting rod caps (5) and four screws (6) on two connecting rods (1).
2. Remove three piston rings (14) from each of two pistons (15). Discard piston rings.

NOTE

If any pistons, piston pins, retaining rings, or connecting rods are damaged and need to be replaced, do steps 3 and 4. Otherwise, go to step 3 in subparagraph d.

3. Remove two retaining rings (17) and piston pin (16) from piston (15) and connecting rod (1). Discard retaining rings.
4. Remove piston (15) from connecting rod (1). Replace piston, piston pin, and/or connecting rod if damaged. Repeat for other piston, if necessary.

**c. CLEANING****WARNING**

Drycleaning solvent P-D-680 is toxic and flammable. Always wear protective goggles and gloves and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes, and DO NOT breathe vapors. DO NOT use near open flame or excessive heat.

1. Remove carbon from pistons, piston ring grooves, and combustion chamber liners with carbon-removing compound. Clean all parts with drycleaning solvent and rag.
2. Using cylinder ridge reamer, remove ridge from top of combustion chamber liner.

3-9. PISTON AND COMBUSTION CHAMBER LINER REPAIR (continued).

d. ASSEMBLY

NOTE



Piston head must be installed so the pocket is on the same side of the piston assembly as the notches in the connecting rod and connecting rod cap.

1. If piston (15) is being replaced, place piston (15) on connecting rod (1) with pocket in piston (15) facing the same direction as notches in connecting rod (1). Install piston pin (16) in piston (15) and connecting rod (1) and secure with two new retaining rings (17). Repeat for other piston, if necessary.

NOTE

There are two pistons on the engine. Repeat steps 2 and 3 for each of them.

2. Install three piston rings (14) on piston (15). See diagram for correct location and orientation of piston rings. Stagger three ring gaps so they are 120 degrees apart and no ring gap is over piston pin (16) or directly above or below other ring gaps.




PLACEMENT OF PISTON RINGS

3. Remove two screws (6) and connecting rod cap (5) from connecting rod (1). Place two new sleeve bearing halves (18) in connecting rod (1) and connecting rod cap (5).

3-9. PISTON AND COMBUSTION CHAMBER LINER REPAIR (continued).**e. INSTALLATION**


1. Install two new shims (9) on crankcase (3).
2. Install two new cap-plugs (11) and four new cap-plugs (12) on eight studs (13).
3. Install bracket (8) and clamping sheet (10) on two studs (13). Tighten screw (7) to secure.

**NOTE**

There are two pistons and combustion chamber liners on the engine. Follow steps 4 through 9 for each of them.

4. Apply light coat of lubricating oil to three piston rings (14) and piston (15). Clamp piston ring compressor over piston rings (14). Tighten piston ring compressor.
5. Install combustion chamber liner (2) in crankcase (3). Make sure notched corners on combustion chamber liner (2) are facing injection-pump side of engine.
6. Turn crankshaft (4) so crankshaft journal for piston to be installed is at the bottom of crankcase (3).

3-9. PISTON AND COMBUSTION CHAMBER LINER REPAIR (continued).

**CAUTION**

Pocket in piston and notches in connecting rod must face starter access plate side of engine.

7. Slide piston (15) into combustion chamber liner (2). Make sure pocket in piston (15) is facing toward starter access plate side of engine.
8. Tap piston (15) into combustion chamber liner (2) with hammer handle. Make sure connecting rod (1) is aligned with crankshaft journal.

CAUTION

Each connecting rod and connecting rod cap is stamped with a number and also has a notch on one side. Each connecting rod cap must be installed on the connecting rod stamped with the same number and with the notches on the same side.

9. Install two connecting rod caps (5) on two connecting rods (1) and secure loosely with two screws (6). Torque screws to 30 ft-lb (40 N•m).

FOLLOW-ON TASKS:

- Install oil pan (UOC: APP) (para 3-13).
- Install oil pan (UOC: APJ) (para 3-13.1).
- Turn engine upright.
- Install cylinder heads (para 3-5).

3-10. ROCKER ARM ASSEMBLIES REPAIR.

This Task Covers:

- a. Removal
- b. Installation

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)
- Snapping pliers (Item 26, Appendix G)
- Torque wrench, 1/2-inch drive (Item 31, Appendix G)

- Sealing compound (Item 16, Appendix D)
- Self-locking nut (4) (Item 15, Appendix F)
- Shim (1 or 2) (Item 42 or 43, Appendix F)

Equipment Conditions:

- Rocker arm covers and gaskets removed (para 2-17).

Materials/Parts:


- Retaining ring (4) (Item 20, Appendix F)

a. REMOVAL

NOTE

There are two rocker arm assemblies on the engine, each containing two rocker arms. Repeat steps 1 through 4 to remove both assemblies.

1. Remove two self-locking nuts (7) and rocker arm bracket (8) from two studs (10). Discard self-locking nuts.
2. Remove two retaining rings (1) and any shims (2 or 3) from rocker arm bracket (8). Discard retaining rings and shims.



3-10. ROCKER ARM ASSEMBLIES REPAIR (continued).

3. Remove two rocker arms (6 and 9) from rocker arm bracket (8).

NOTE

Remove nuts and adjusting screws only if damaged.

4. Remove two nuts (4) and adjusting screws (5) from two rocker arms (6 and 9). If damaged, discard nuts and adjusting screws.


b. INSTALLATION

NOTE

- **There are two rocker arm assemblies on the engine. Repeat steps 1 through 4 to install both of them.**
- **If nuts or adjusting screws need to be replaced, do step 1. If not, go to step 2.**

1. Install two new nuts (4) on two new adjusting screws (5). Install two adjusting screws (5) on two rocker arms (6 and 9).
2. Place two rocker arms (6 and 9) on rocker arm bracket (8) and secure with two new retaining rings (1).

3. To determine if shims (2 or 3) are needed, use a feeler gage to measure play between rocker arm bracket (8) (point A) and inside edge of rocker arm (6 or 9) (point B). This measurement should be between 0.004 and 0.008 inch (0.1 mm and 0.2 mm). Remove two retaining rings (1) from rocker arm bracket (8), and install shims (2 or 3) as needed to achieve this distance. Reinstall retaining rings (1) in rocker arm bracket (8).



CAUTION

To ensure adequate lubrication, rocker arm bracket must be installed with the oil hole on the bottom.

4. Apply sealing compound (Item 16, Appendix D) to threads of studs (10). Install rocker arm bracket (8) on two studs (10) and secure with two new self-locking nuts (7). Torque nuts to 17 ft-lb (23 N·m).

FOLLOW-ON TASKS:

- Adjust valves (para 3-18).
- Install rocker arm covers and gaskets (para 2-17).

3-11. CAMSHAFT REPAIR

This Task Covers:

a. Removal

b. Installation

Initial Setup:

Tools/Test Equipment:

- Arbor press (Item 1, Appendix G)
- General mechanic's tool kit (Item 14, Appendix G)
- Snapping pliers (Item 26, Appendix G)

- Crankcase gasket set (Item 1, Appendix F)
- Retaining ring (Item 21, Appendix F)
- Retaining ring (Item 36, Appendix F)
- Retaining ring (Item 39, Appendix F)

Materials/Parts:


- Clip (Item 38, Appendix F)

Equipment Conditions:

- Crankcase disassembled (para 3-6):

a. REMOVAL

1. Remove three screws (14) and washers (13) and oil pump cover (12) from upper crankcase (15).
2. Remove O-ring (11) from oil pump cover (12). Discard O-ring.
3. Remove rotor (9) and oil pump gear (10) from upper crankcase (15).
4. Remove clip (2) from governor spring (1). Remove governor spring (1) from governor control lever assembly (3) and accelerator lever (8). Discard clip.




3-11. CAMSHAFT REPAIR (continued).

5. Remove governor control lever assembly pin (6) and governor control lever assembly (3) from upper crankcase (15).
6. Remove two O-rings (7) from pin (6). Discard O-rings.
7. Remove camshaft assembly (5) from upper crankcase (15): Position the timing marks on camshaft gear (4) at the 10 o'clock position. Pull camshaft assembly (5) toward you until it stops. Turn camshaft gear (4) until timing marks are in the 12 o'clock position. Pull camshaft assembly (5) the rest of the way out of upper crankcase (15).

CAUTION


Do not lay camshaft flat on table while it is attached to camshaft gear. Stand camshaft and camshaft gear assembly on camshaft gear, to prevent warping.

8. Remove three screws (21) and nuts (19) and mounting plate (20) from camshaft gear (4).
9. Remove retaining ring (24) from groove on camshaft (16), and slide spacer (18) and washer (17) away from camshaft gear (4). Discard retaining ring.
10. Remove camshaft gear (4) and key (23) from camshaft (16).
11. Remove retaining ring (22) from groove on camshaft (16). Discard retaining ring.
12. Remove spacer (18) and washer (17) from camshaft (16).




3-11. CAMSHAFT REPAIR (continued).

13. Remove four tappets (25) from upper crankcase (15).
14. Remove retaining ring (28) from acceleration lever (26). Discard retaining ring.
15. Remove acceleration lever (26) from upper crankcase (15). Remove O-ring (27) from acceleration lever (26). Discard O-ring.

**NOTE**

Pin for pinion assembly may have come off with flywheel housing (para 3-8).


16. Remove pin (29), pinion assembly (30), and washer (31) from upper crankcase (15).

**b. INSTALLATION**


1. Install washer (31), pinion assembly (30), and pin (29) in upper crankcase (15).

3-11. CAMSHAFT REPAIR (continued).

2. Install new O-ring (27) on acceleration lever (26). Install acceleration lever (26) on upper crankcase (15).
3. Install new retaining ring (28) on acceleration lever (26).
4. Install four tappets (25) in upper crankcase (15).




5. Install washer (17) and spacer (18) on camshaft (16). Make sure tapered end of spacer (18) is facing away from washer (17).
6. Install new retaining ring (22) in groove on camshaft (16).



3-11. CAMSHAFT REPAIR (continued).


7. Install key (23) on camshaft (16). Using arbor press, install camshaft gear (4) on camshaft (16), making sure timing marks on camshaft gear (4) are facing toward near end of camshaft (16). Press camshaft gear(4) onto camshaft (16) until camshaft gear (4) seats against retaining ring (22).
8. Slide spacer (18) and washer (17) toward camshaft gear (4). Install new retaining ring (24) in groove on camshaft (16).
9. Install mounting plate (20) on camshaft gear (4) and secure with three screws (21) and nuts (19).



10. Set upper crankcase (15) on end on work surface with opening for camshaft (16) facing up. Install camshaft assembly (5) in upper crankcase (15): Position the timing marks on camshaft gear (4) in the 12 o'clock position, and insert camshaft assembly (5) into bearing bore. When the first cam lobe drops down behind bearing bore, turn camshaft gear (4) counterclockwise until timing marks are in the 10 o'clock position; insert camshaft assembly (5) the rest of the way.
11. Lay upper crankcase (15) on work surface. Install two new O-rings (7) on governor control lever assembly pin (6).
12. Position governor control lever assembly (3) in upper crankcase (15).

3-11. CAMSHAFT REPAIR (continued).

13. Install pin (6) on governor control lever assembly (3) and upper crankcase (15).
14. Install governor spring (1) on governor control lever assembly (3) and accelerator lever (8). Secure governor spring (1) with new clip (2).
15. Place oil pump gear (10) and rotor (9) in upper crankcase (15). Make sure beveled edge of rotor (9) is facing toward inside of upper crankcase (15).
16. Install new O-ring (11) in oil pump cover (12).
17. Install oil pump cover (12) on upper crankcase (15) and secure with three screws (14) and washers (13). Turn camshaft gear (4) to be sure camshaft assembly (5) turns freely.



FOLLOW-ON TASKS:

- Assemble crankcase (para 3-6).

3-12. FILLER NECK REPLACEMENT (UOC: APP).

This Task Covers:

- a. Removal
- b. Installation

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit automotive (item 15, Appendix G)

Materials/Parts:

- Grease compound (Item 5, Appendix D)
- Sealing compound (Item 13, Appendix D)

- Crankcase gasket set (Item 1, Appendix F)

Equipment Conditions:

- Filler cap removed (para 2-18).
- Airflow deflectors removed as needed to allow access to oil filler assembly (para 2-24).

a. REMOVAL


1. Remove four nuts (2) and washers (1) from four studs (4).
2. Remove filler neck (3) from crankcase (5).
3. Remove O-ring (6) from groove of filler neck (3). Discard O-ring.

b. INSTALLATION

1. Lightly coat new O-ring (6) with grease. Install O-ring (6) in groove in filler neck (3).
2. Apply sealing compound (Item 13, Appendix D) to four studs (4).
3. Install filler neck (3) on crankcase (5).
4. Install four washers (1) and nuts (2) on four studs (4).

FOLLOW-ON TASKS:

- Install airflow deflectors (para 2-24).
- Install filler cap (para 2-18).



3-13. OIL PAN AND GASKET REPLACEMENT (UOC: APP).*This Task Covers:*

a. Removal

b. Installation

*Initial Setup:***Tools/Test Equipment:**

- General mechanic's tool kit, automotive (item 15, Appendix G)

Equipment Conditions:

- Engine mounting plate removed (para 3-4)

Materials/Parts:


- Crankcase gasket set (item 1, Appendix F)
- Lockwasher (10) (Item 24, Appendix F)

a. REMOVAL

1. Remove 10 screws (5) and lockwashers (6) and oil pan (4) from crankcase (1). Discard lockwashers.
2. Remove strainer element (2) from crankcase (1).
3. Remove gasket (3) from oil pan (4). Discard gasket.

b. INSTALLATION

1. Install strainer element (2) in crankcase (1).
2. Install new gasket (3) on oil pan (4).
3. Install oil pan (4) on crankcase (1) and secure with 10 new lockwashers (6) and screws (5).

**FOLLOW-ON TASKS:**

- Install engine mounting plate (para 3-4).

3-13.1. DEEP OIL PAN AND GASKET REPLACEMENT (UOC: APJ).

This Task Covers:

a. Removal

b. Installation

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (item 14, Appendix G)

Equipment Conditions:

- Engine mounting plate removed (para 3-4)

Materials/Parts:


- Crankcase gasket set (item 1, Appendix F)

a. REMOVAL

1. Place a suitable container under drain plug (5) to catch oil then remove drain plug (5) from deep oil pan (4).
2. Remove 10 screws (6) and flat washers (7) and oil pan (4) from crankcase (1). Discard lockwashers.
3. Remove strainer element (2) from crankcase (1).
4. Remove gasket (3) from deep oil pan (4). Discard gasket.

b. INSTALLATION

1. Install strainer element (2) in crankcase (1).
2. Install new gasket (3) on deep oil pan (4).
3. Install deep oil pan (4) on crankcase (1) and secure with two new flat washers (7) and screws (6).
4. Install drain plug (5).



FOLLOW-ON TASKS:

- Install engine mounting plate (para 3-4).
- Refill with oil (TM 9-2350-292-20-2).

291188m

3-14. FUEL INJECTOR REPLACEMENT.

This Task Covers:

- | | |
|---------------|-----------------|
| a. Removal | b. Cleaning |
| c. Inspection | d. Installation |

*Initial Setup:***Tools/Test Equipment:**

- General mechanic's tool kit (item 14, Appendix G)
- Socket wrench set, 3/8-inch drive (Item 27, Appendix G)
- Torque wrench, 3/8-inch drive (Item 30, Appendix G)
- Rag (Item 7, Appendix D)
- Head gasket set (Item 3, Appendix F)
- Spring tension washer (2) (Item 31, Appendix F)

Materials/Parts:

- Drycleaning solvent (Item 4, Appendix D)
- Fuel pressure pipe assemblies and return fuel hose removed (para 2-23).

Equipment Conditions:

NOTE

There are two fuel injectors on the engine. Use this procedure to replace either one. The injector on the flywheel side of the engine is shown.

a. REMOVAL

1. Remove nut (1), spring tension washer (2), spacer (3), and hose clamp (4) from fuel injector (5) and stud (9). Discard spring tension washer.
2. Remove fuel injector (5) from bore in cylinder head (8).

NOTE

Gasket may stay in bore in cylinder head. check bore if gasket is not on the end of the fuel injector.


3. Remove gasket (6) from fuel injector (5) or bore in cylinder head (8). Discard gasket.

b. CLEANING

Drycleaning solvent P-D-680 is toxic and flammable. Always wear protective goggles and gloves, and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes and do not breathe vapors. Do not use near open flame or excessive heat.


1. Clean bore in cylinder head (8) with drycleaning solvent and rag.

3-14. FUEL INJECTOR REPLACEMENT (continued).




3-14. FUEL INJECTOR REPLACEMENT (continued).**c. INSPECTION**

1. Remove the nozzle retaining nut (1) from the fuel injector body (2).
2. Check the nozzle body (3) and nozzle needle (4) for overheating damage, scoring and coked-up spray holes.
3. Immerse the nozzle needle (4) in clean fuel. The nozzle needle (4) must slide down under its own weight into the seat of nozzle body (3).
4. Replace the nozzle needle (4) and the nozzle body (3) as an assembly if defective. If other parts are defective, replace entire fuel injector.
5. Assemble fuel injector parts (1) through (8) together as shown. Torque nozzle retaining nut (1) to 44 ft-lb (60 N•m).
6. Test fuel injector spray pattern (para 3-21).



29I212m

3-14. FUEL INJECTOR REPLACEMENT (continued).



d. INSTALLATION

NOTE

Make sure that the soft, graphite-coated surface of the gasket is facing fuel injector.

1. Install new gasket (6) on fuel injector (5).
2. Install fuel injector (5) in bore in cylinder head (8). Make sure opening for screw faces rocker arm cover (7).

NOTE

Make sure tapered side of spacer is toward hose clamp and that tapered side of hose clamp is facing up.

3. Install hose clamp (4), spacer (3), new spring tension washer (2), and nut (1) on stud (9) and fuel injector (5). Torque nut to 17 ft-lb (23 N•m).

FOLLOW-ON TASKS:

- Install fuel pressure pipe assemblies and return fuel hose (para 2-23).

3-15. INJECTION PUMP REPLACEMENT.

This Task Covers:

- a. Removal
- b. Cleaning and Inspection
- c. Installation

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (item 14, Appendix G)

Materials/Parts:

- Drycleaning solvent (Item 4, Appendix D)
- Rag (Item 7, Appendix D)
- Cotter pin (Item 22, Appendix F)


- Sealing compound (Item 17, Appendix D)
- Crankcase gasket set (Item 1, Appendix F)
- Head gasket set (Item 3, Appendix F)

Equipment Conditions:

- Airflow deflectors removed (UOC:APP) (para 2-24).
- Airflow deflectors removed (UOC:APJ) (TM 9-2350-292-20-2).
- Fuel pressure pipe assemblies and return fuel hose removed (para 2-23).

a. REMOVAL

1. Remove three screws (5), nut (1), and governor plate (2) shown or extra fuel device, if equipped, from crankcase (4).
2. Remove gasket (3) from governor plate (2). Discard gasket.



3-15. INJECTION PUMP REPLACEMENT (continued).

3. Remove cotter pin (6) from control rack of injection pump (7). Discard cotter pin.
4. Remove end of governor lever (8) from control rack of injection pump (7).
5. Remove four nuts (9) from injection pump (7).

NOTE

- To remove injection pump from crankcase, control rack of injection pump must be positioned under cutout in crankcase.
- The number of gaskets (10) to be removed will vary. Refer to the first note in subparagraph c.


6. Position control rack of injection pump (7) under cutout in crankcase (4), and remove injection pump (7) and gaskets (10) from crankcase (4). Discard gaskets.

b. CLEANING AND INSPECTION


WARNING

Drycleaning solvent P-D-680 is toxic and flammable. Always wear protective goggles and gloves, and use only in a well-ventilated area. Avoid contact with skin, eyes, and clothes, and do not breathe vapors. Do not use near open flame or excessive heat.

1. Clean injection pump and cavity in crankcase with drycleaning solvent and rag.



2. Measure governor lever (8). It should measure 3.88 inches + 0.03 inch (98.5 mm + 0.8 mm). If measurement is not correct, adjust it by loosening jamnut and turning governor lever (8) in or out to shorten or lengthen it. Tighten jamnut when length is correct.



3-15. INJECTION PUMP REPLACEMENT (continued).

c. INSTALLATION

NOTE


The thickness of the gasket(s) to be installed is determined by the number stamped on the side of the crankcase next to the injection pump. For example, if the number "6" is stamped on the crankcase, the total thickness of the gaskets should be 0.60 mm. Gaskets come in sets of three gaskets of varying thickness.

1. Install enough new gaskets (10) on crankcase (4) to reach the thickness indicated by the number stamped on crankcase (4).

NOTE


To install injection pump in crankcase, control rack of injection pump must be positioned over cutout in crankcase.

2. Position control rack of injection pump (7) over cutout, and install injection pump (7) on crankcase (4). Turn flywheel (11) to allow injection pump (7) to sit all the way down in the opening.
3. Apply sealing compound (Item 17, Appendix D) to threads of studs. Install four nuts (9) on injection pump (7).




3-15. INJECTION PUMP REPLACEMENT (continued).

4. Install end of governor lever (8) on control rack of injection pump (7) and secure with new cotter pin (6).



5. Install new gasket (3) on governor plate (2).
6. Install governor plate (2) shown or extra fuel device if equipped on crankcase (4) and secure with nut (1) and three screws (5).



FOLLOW-ON TASKS:

- Install fuel pressure pipe assemblies and return fuel hose (para 2-23).
- Install airflow deflectors (para 2-24).

3-16. GOVERNOR CONTROL ASSEMBLY REPAIR

This Task Covers:

- | | |
|-------------|-----------------|
| a. Removal | b. Disassembly |
| c. Assembly | d. Installation |

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (item 15, Appendix G)
- Snapping pliers (Item 26, Appendix G)
- Seal (Item 13, Appendix F)
- Spring tension washer (Item 30, Appendix F)
- Wire mesh (Item 14, Appendix F)

Materials/Parts:


- Lockwasher (Item 26, Appendix F)
- O-ring (Item 37, Appendix F)

References:

- para 3-15
- para 3-22

a. REMOVAL

1. Remove governor plate ((para 3-15).
2. Remove screw (1), lockwasher (2), washer (3), lever (4), and spring (5) from speed control lever (6). Discard lockwasher.
3. Remove seal (7) and wire mesh (8) from speed control lever (6). Discard seal and wire mesh.
4. Remove screw (9) and speed control lever (6) from crankcase (10).
5. Remove two nuts (11) and two screws (12) from speed control lever (6).
6. Remove nut (13) and screw (14) (UOC:APP).



29i214m


3-16. GOVERNOR CONTROL ASSEMBLY REPAIR (continued).

b. DISASSEMBLY

1. Remove screw (15), spring tension washer (16), two levers (17 and 18), and bushing (19) from mounting plate (20). Discard spring tension washer.
2. Remove stop lever (21) and spring (22) from mounting plate (20).
3. Remove O-ring (23) from stop lever (21). Discard O-ring.
- *4. Remove spring pin (24), lever (25), and spring (26) from extra fuel device (27).


c. ASSEMBLY

1. Install new O-ring (23) to stop lever (21).
2. Install stop lever (21) and spring (22) into mounting plate (20).
3. Install screw (15), new spring tension washer (16), two levers (17 and 18), and bushing (19) into mounting plate (20).
- *4. Install spring (26), lever (25), and spring pin (24) to extra fuel device (27).



d. INSTALLATION

1. Install two screws (12) and two nuts (11) on speed control lever (6).
2. Install screw (14) and nut (13) (UOC:APP).
3. Install screw (9) and speed control lever (6) on crankcase (10).
4. Install spring (5), lever (4), washer (3), new lockwasher (2), and screw (1) on speed control lever (6).
5. Install governor plate (para 3-15).
6. Adjust engine speed (para 3-22).



7. Install new wire mesh (8) and new seal (7) on speed control lever (6).

FOLLOW-ON TASKS:

- None

SECTION III. TESTS AND ADJUSTMENTS

Paragraph Number	Page Paragraph Title	Number
3-17	Cylinder Compression Test	3-56
3-18	Valve Adjustment	3-58
3-19	Flow Control Valve Adjustment	3-60
3-20	Injection Pump Test	3-65
3-21	Fuel Injector Test	3-66
3-22	Engine Speed Adjustment	3-69
3-23	Oil Pressure Test	3-70
	Table 3-1	3-71

3-17. CYLINDER COMPRESSION TEST.

This Task Covers:

Test

Initial Setup:

Tools/Test Equipment:

- Cylinder compression tester (Item 7, Appendix G)
- General mechanic's tool kit (Item 14, Appendix G)

TEST

NOTE

The cylinder compression test is used to determine the condition of valves, pistons, piston rings, and cylinders. Any pressure difference between cylinders indicates a problem with one or more of these components.


- Run engine until thoroughly warm.
- Remove fuel injectors (para 3-14).

NOTE

Compression tester gage reading for a new engine turning at about 300 rpm should be approximately 350 to 400 psi (2410 to 2758 kPa). If there is a pressure difference between cylinders, refer to paragraphs 3-5 and 3-9 for repair procedures for valves, pistons, piston rings, and cylinders.

- Insert compression tester into fuel injector bore near cylinder no. 1 (2) (on flywheel side of engine).
- Crank engine and note compression reading on compression tester gage.

3-17. CYLINDER COMPRESSION TEST (continued).



- e. Remove compression tester from fuel injector bore for cylinder no. 1 (2), and repeat steps c and d for fuel injector bore for cylinder no. 2 (1) (on auxiliary drive side of engine).
- f. Remove compression tester from fuel injector bore for cylinder no. 2 (1).
- g. Install fuel injectors (para 3-14).

FOLLOW-ON TASKS:

- None

3-18. VALVE ADJUSTMENT.

This Task Covers:

Adjustment

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)


Equipment Conditions:

- Rocker arm cover removed (para 2-17).
-

ADJUSTMENT**NOTE**


- Cylinder no. 1 is on the flywheel side of the engine. Cylinder no. 2 is on the auxiliary drive side of the engine.
- Allow engine to cool to room temperature (approximately 75°F [24°C]) before adjusting the valves.
- Valves are in rocking position when the rocker arms are level and can be moved slightly.

- a. Turn flywheel (1) clockwise until valves in cylinder no. 2 are in rocking position, then turn flywheel 180 degrees further.



3-18. VALVE ADJUSTMENT (continued).

- b. Using feeler gage, measure the clearance between rocker arm (4) and valve stem (5) on intake valve (3) and exhaust valve (6) of cylinder no. 1. Clearance should be 0.004 inch (0.102 mm).
- c. To adjust clearance, loosen nut (7) and turn adjusting screw (2) so that, after tightening nut (7), clearance is correct.
- d. Rotate flywheel (1) clockwise 180 degrees. Intake valve (3) and exhaust valve (6) of cylinder no. 2 will be fully closed. Repeat steps b and c for both valves (3 and 6) in cylinder no. 2.

**FOLLOW-ON TASKS:**

- Install rocker arm cover (para 2-17).

3-19. FLOW CONTROL VALVE ADJUSTMENT.*This Task Covers:*

Adjustment

*Initial Setup:***Tools/Test Equipment:**

- Fuel-test set (Item 12, Appendix G)
- Fuel-testing device (Item 13, Appendix G)
- General mechanic's tool kit (Item 14, Appendix G)
- Indicator dial (Item 16, Appendix G)
- Wrench (Item 36, Appendix G)

Materials/Parts:

- Rubber band (Item 8, Appendix D)
- Crankcase gasket set (Item 1, Appendix F)

- Gasket (2) (Item 16, Appendix F)
- O-ring (2) (Item 17, Appendix F)


Equipment Conditions:

- Airflow deflectors removed as needed (UOC: APP) (para 2-24).
- Airflow deflectors removed as needed (UOC: APJ) (TM 9-2350-292-20-2)
- Fuel pressure pipes removed (para 2-23).
- Vehicle fuel supply connected to injection pump (refer to TM 9-2350-293-20) (UOC: APP).
- Vehicle fuel supply connected to injection pump (UOC: APJ) (TM 9-2350-292-20-2)

ADJUSTMENT**NOTE**


- **The flow control valve should be adjusted only if any of the following conditions exist: The flow control valve has been replaced; the engine lacks power; or the engine emits smoke after start-up, during operation.**
- **The fuel quantity injected is determined by the travel of the pump plunger between start and end of delivery. This dimension is specified in millimeters on the engine data plate located on the flywheel air duct.**

- Turn flywheel (2) clockwise until 26-degree mark on flywheel (2) is aligned with "PM" mark on flywheel airflow deflector (1).




3-19. FLOW CONTROL VALVE ADJUSTMENT (continued).

- b. Remove injector line fitting (3), O-ring (4), spring guide (5), shim (6), spring (7), gasket (8), and delivery valve (9) from injection pump outlet port (10). Discard O-ring and gasket.




- c. Install fuel-testing device (13), adapter rod (12), and indicator dial (11) in injection pump outlet port (10).

- d. Remove three screws (18), nut (19), mounting plate (17), and gasket (16) from crankcase (14). Install screw (18) on auxiliary drive side of mounting plate opening (15). Discard gasket.



3-19. FLOW CONTROL VALVE ADJUSTMENT (continued).

- e. Place rubber band (20) around governor lever pad (21) and screw (18), to position line on control rod rack at edge of opening.
- f. Open fuel shutoff valve (refer to technical manual for vehicle).
- g. Set indicator dial (11) at "0." Turn flywheel (2) clockwise until the dimension specified on engine data plate (23) is reached. In this position, fuel should come out of spill device outlet (22) at the rate of approximately one drop every five seconds.





3-19. FLOW CONTROL VALVE ADJUSTMENT (continued).

NOTE

If fuel comes out of spill device outlet before the dimension specified on engine data plate is reached, fuel quantity is set too low. If no fuel comes out of the spill device outlet at the specified dimension, fuel quantity is set too high.

- h. If fuel quantity is incorrect, loosen nut on flow control valve (24). Turn knob to the right to increase fuel quantity or to the left to decrease fuel quantity.
- i. Tighten nut and repeat steps g and h until fuel quantity is correct.




- j. Close fuel shutoff valve (refer to technical manual for vehicle).
- k. Remove rubber band (20) from governor lever pad (21) and screw (18). Remove screw (18) from crankcase (14).


3-19. FLOW CONTROL VALVE ADJUSTMENT (continued).

l. Install mounting plate (17) and new gasket (16) on crankcase (14). Secure with three screws (18) and nut (19).

m. Remove fuel-testing device (13), adapter rod (12), and indicator dial (11) from injection pump outlet port (10).



n. Install delivery valve (9), new gasket (8), spring (7), shim (6), spring guide (5), new O-ring (4), and injector line fitting (3) on injection pump outlet port (10).



FOLLOW-ON TASKS:

- Disconnect vehicle fuel supply from injection pump (UOC: APP) (refer to TM 9-2350-293-20).
- Disconnect vehicle fuel supply from injection pump (UOC: APJ) (TM 9-2350-292-20-2)
- Install fuel pressure pipes (para 2-23).
- Install airflow deflectors (UOC: APP) (para 2-24).
- Install airflow deflectors (UOC: APJ) (TM 9-2350-292-20-2).

3-20. INJECTION PUMP TEST.*This Task Covers:*

Test

*Initial Setup:***Tools/Test Equipment:**

- Fuel-test set (Item 12, Appendix G)
- General mechanic's tool kit, automotive (Item 15, Appendix G)
- Wrench (Item 36, Appendix G)

Equipment Conditions:

- Airflow deflectors removed as needed (UOC: APP) (para 2-24).
- Air flow deflectors removed as needed (UOC: APJ) (TM 9-2350-292-20-2).


TEST

- Remove fuel pressure pipe clamp and fuel pressure pipe assembly from fuel injector on flywheel side of engine (para 2-23).
- Remove fuel injector from flywheel side of engine (para 3-14).
- Install extension tube (4), tube assembly (5), and indicator dial (1) from fuel-test set on flywheel-side port (2) of injection pump (3).

WARNING

Fuel spray on hot components is an extreme fire hazard. Control leakage immediately, to prevent serious injury to personnel.

- Crank engine and observe indicator dial (1). Reading should be between 250 and 258 bars. If reading is incorrect, replace injection pump (para 3-15).
- Remove indicator dial (1), tube assembly (5), and extension tube (4) from flywheel side port (2) of injection pump (3).
- Install fuel injector on engine (para 3-14).
- Install fuel pressure pipe assembly and fuel pressure pipe clamp (para 2-23).
- Repeat steps a through g for port on auxiliary drive side of injection pump.

**FOLLOW-ON TASKS:**

- Install airflow deflectors (UOC:APP) (para 2-24).
- Install airflow deflectors (UOC:APJ) (TM 9-2350-292-20-2).

3-21. FUEL INJECTOR TEST.

This Task Covers:

Test

Initial Setup:

Tools/Test Equipment:

- Fuel-test set (Item 12, Appendix G)
- General mechanic's tool kit, automotive (Item 15, Appendix G)

Equipment Conditions:


- Airflow deflectors removed as needed (UOC: APP) (para 2-24).
- Air flow deflectors removed as needed (UOC: APJ) (TM 9-2350-292-20-2)
- Injection pump test performed (para 3-20).

TEST

NOTE

There are two fuel injectors on the engine. Use this procedure to test either one.

- Remove fuel pressure pipe clamp and fuel pressure pipe assembly from fuel injector to be tested (para 2-23).
- Remove fuel injector to be tested (para 3-14).
- Remove two blank plugs (1) from test tube (2).



- Install extension tube (4) of fuel-test set on injection pump port (5).
- Install test tube (2) on extension tube (4).
- Install indicator dial (3) of fuel-test set on test tube (2).


3-21. FUEL INJECTOR TEST (continued).

- g. Install fuel injector (6) on test tube (2).

WARNING


- Fuel spray on hot components is an extreme fire hazard. Control leakage immediately, to prevent serious injury to personnel.
- Keep hands away from fuel injector after installing it on test tube. Fuel spray can penetrate the skin, causing blood poisoning. Failure to follow this warning may result in serious injury or death.

- h. Crank engine.
- i. Check pressure reading at indicator dial (3). Correct pressure is 250 to 258 bar.
- j. If pressure is not correct, replace fuel injector (para 3-14).
- k. Check spray pattern. Fuel should spray evenly, in a diffuse pattern, rather than in a stream or dripping.
- l. If spray pattern is not correct, replace fuel injector (6) (para 3-14).
- m. Remove fuel injector (6) from test tube (2).



3-21. FUEL INJECTOR TEST (continued).

- n. Remove indicator dial (3) from test tube (2).
- o. Remove test tube (2) from extension tube (4)
- p. Remove extension tube (4) from injection pump port (5).



- q. Install blank two plugs (1) on test tube (2).
- r. Install fuel injector (para 3-14).
- s. Install fuel pressure pipe assembly and fuel pressure pipe clamp (para 2-23).

FOLLOW-ON TASKS:

- Install airflow deflectors (UOC: APP) (para 2-24).
- Install airflow deflectors (UOC: APJ) (TM 9-2350-292-20-2).

3-22. ENGINE SPEED ADJUSTMENT.

This Task Covers:

Adjustment

Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)
- Mechanical hand-held tachometer (Item 18, Appendix G)

Personnel Required:



- Two

ADJUSTMENT

NOTE

Engine speed is measured in revolutions per minute (rpm).

- a. Start engine and let it run until warm.
- b. Have an assistant hold a hand-held mechanical tachometer on end of crankshaft (1) on flywheel side of engine.
- c. The rpm reading on tachometer should be 2200 ± 50 rpm (UOC: APP) or 2650 ± 50 rpm (UOC: APJ). If it is not, loosen two nuts (2) and turn two adjusting screws (3) to move speed control lever (4), while assistant watches tachometer gage, until correct rpm reading is reached. Moving speed control lever (4) to the left will decrease engine speed; moving speed control lever (4) to the right will increase engine speed.
- d. Hold two adjusting screws (3) in place and tighten two nuts (2).



- e. Recheck engine speed by repeating steps b through d.

FOLLOW-ON TASKS:

- None

3-23. OIL PRESSURE TEST.

This Task Covers:

Test


Initial Setup:

Tools/Test Equipment:

- General mechanic's tool kit, automotive (Item 15, Appendix G)
 - Oil pressure test set (Item 20, Appendix G)
-


TEST

- a. Remove screw (1) and washer (2) from fluid passage bolt (3).



3-23. OIL PRESSURE TEST (continued).

- b. Install oil pressure gage (4) on flexible connector (5), and install flexible connector (5) on fluid passage bolt (3).



- c. Start the engine and allow it to warm up. Run the engine at the speeds indicated in Table 3-1, and check the oil pressure gage.

Table 3-1. Oil Pressure

Speed in rpm	Normal Oil Pressure	Minimum Oil Pressure
900	1.2 to 2.5 bar (17.4 to 36.3 psi)	0.4 bar (5.8 psi)
1500	1.8 to 3.5 bar (26.1 to 50.8 psi)	1.0 bar (14.5 psi)
2300	2.5 to 4.5 bar (36.3 to 65.3 psi)	1.8 bar (26.1 psi)
3000	3.5 to 5.0 bar (50.8 to 72.5 psi)	2.5 bar (36.3 psi)

FOLLOW-ON TASKS:

- None

**APPENDIX A
REFERENCES**

Paragraph Number	Paragraph Title	Page Number
A-1	General	A-1
A-2	Forms	A-1
A-3	Manuals	A-1
A-4	Pamphlets and Circulars	A-1
A-5	Regulations	A-2

A-1. GENERAL.

This appendix lists all forms, pamphlets, and regulations that are referenced in this technical manual. DA Pam 25-30 should be consulted frequently for the latest changes or revisions and for new publications relevant to material covered in this manual.

A-2. FORMS.

Refer to DA Pam 738-750 for instructions on the use of maintenance forms.

Recommended Changes to Publications and Blank Forms	DA Form 2028
Recommended Changes to Equipment Technical Publications	DA Form 2028-2
Processing and Deprocessing Record for Shipment, Storage and Issue of Vehicles and Spare Engines	DD Form 1397
Product Quality Deficiency Report	SF Form 368

A-3. MANUALS.

First Aid for Soldiers	
Army	FM 4-25.11
Marine Corps	MCRP 3-02G
Inspection, Care and Maintenance of Antifriction Bearings	TM 9-214
Materials Used for Cleaning, Preserving, Abrading and Cementing Ordnance Materiel and Related Materials Including Chemicals	TM 9-247
Operator's Manual for Carrier, Ammunition, Tracked, M992A2 (NSN 2350-01-368-9500)	TM 9-2350-293-10
Unit Maintenance Manual for Carrier, Ammunition, Tracked, M992A2 (NSN 2350-01-368-9500)	TM 9-2350-293-20-1 and -2
Unit, Direct Support and General Support Maintenance Repair Parts and Special Tools List for Carrier, Ammunition, Tracked, M992A2 (2350-01-368-9500)	TM 9-2350-293-24P
Direct Support and General Support Maintenance Manual: for Carrier, Ammunition, Tracked, M992A2 (NSN 2350-01-368-9500)	TM 9-2350-293-34
Storage and Materials Handling	TM 743-200-1
Procedures for Destruction of Tank-Automotive Equipment to Prevent Enemy Use	TM 750-244-6

A-3. MANUALS (CONTINUED)

Operator's Manual: Recovery Vehicle, Heavy, Full-Tracked: M88A2	TM 9-2350-292-10
Unit Maintenance Manual: Recovery Vehicle, Heavy, Full-Tracked: M88A2	TM 9-2350-292-20
Direct and General Support Maintenance Manual: Recovery Vehicle, Full-Tracked, Heavy: M88A2 (NSN 2350-01-390-4683)	TM 9-2350-292-34
Unit, Direct Support and General Support Maintenance Repair Parts and Special Tools List for Recovery Vehicle, Heavy, Full-Tracked: M88A2	TM 9-2350-292-24P

A-4. PAMPHLETS AND CIRCULARS.

Consolidated Index of Army Publications and Blank Forms	DA Pam 25-30
Functional User's Manual for The Army Maintenance Management System (TAMMS)	DA Pam 738-750
Operator's Circular Welding Theory and Application	TC 9-237

A-5. REGULATIONS.

Product Quality Deficiency Report Program	AR 702-7
Army Medical Department Expendable/Durable Items	CTA 8-100
Expendable/Durable Items (Except: Medical, Class V, Repair Parts and Heraldic Items)	CTA 50-970
Abbreviations for Use on Drawings, Specifications, Standards, and in Technical Documents	MIL-STD-12

**APPENDIX B
MAINTENANCE ALLOCATION CHART**

Section I. INTRODUCTION

Paragraph Number	Page Paragraph Title	Number
B-1	General.....	B-1
B-2	Maintenance Functions	B-1
B-3	Explanation of Columns in Section II, Maintenance Allocation Chart for Engine Assembly, Diesel, Hatz 2 G 40.....	B-2
B-4	Explanation of Columns in Section III, Tools and Test Equipment Requirements	B-3

B-1. GENERAL.

Appendix B consists of three sections:

- a. Section I provides a general explanation of all maintenance and repair functions authorized at the various maintenance levels.
- b. Section II, the maintenance allocation chart (MAC), designates overall authority and responsibility for the performance of maintenance functions on the identified end item or component. The application of the maintenance functions to the end item or component will be consistent with the capacities and capabilities of the designated maintenance levels.
- c. Section III lists the tools and test equipment (both special tools and common tool sets) required for each maintenance function as referenced from Section II.

B-2. MAINTENANCE FUNCTIONS.

Maintenance functions are limited to and defined as follows:

- a. **Inspect.** To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination (e.g., by sight, sound, or feel).
- b. **Test.** To verify serviceability by measuring the mechanical, pneumatic, hydraulic, or electrical characteristics of an item and comparing those characteristics with prescribed standards.
- c. **Service.** To keep an item in proper operating condition by periodically cleaning (including decontaminating, when required), preserving, draining, painting, or replenishing fuel, lubricants, chemical fluids, or gases.
- d. **Adjust.** To maintain or regulate, within prescribed limits, by bringing into proper or exact position or by setting the operating characteristics to specified parameters.
- e. **Align.** To adjust specified variable elements of an item to bring about optimum or desired performance.

B-2. MAINTENANCE FUNCTIONS (continued).

- f. **Calibrate.** To determine the accuracy of and cause corrections or adjustments to be made on instruments or test, measuring, and diagnostic equipment (TMDE) used in precision measurement. Calibration consists of comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.
- g. **Remove/Install.** To remove and Install the same item when required to perform service or other maintenance functions. "Install" may be the act of emplacing, seating, or fixing into position a spare, repair part, or module (component or assembly) in a manner to allow the proper functioning of an end item or system.
- h. **Replace.** To remove an unserviceable item and install a serviceable counterpart in its place. "Replace" is authorized by the MAC and is shown as the third position of the source, maintenance, and recoverability (SMR) code.
- i. **Repair.** To apply maintenance services-including fault location/troubleshooting, removal/installation, and disassembly/assembly procedures-and maintenance actions to identify troubles and restore serviceability to an item by correcting any specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.
- j. **Overhaul.** To perform that maintenance effort (service/action) required to restore an item to a completely serviceable/operational condition as required by maintenance standards in an appropriate technical publication (e.g., depot maintenance work requirement). Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like-new condition.
- k. **Rebuild.** To perform those services/actions necessary for the restoration of unserviceable equipment to a like-new condition in accordance with original manufacturing standards. Rebuild is the highest degree of materiel maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (e.g., hours, miles) considered in classifying Army equipment/components.

B-3. EXPLANATION OF COLUMNS IN SECTION II, MAINTENANCE ALLOCATION CHART FOR ENGINE ASSEMBLY, DIESEL, HATZ 2 G 40.

- a. **(1) Group Number.** Column 1 lists functional group code numbers, whose purpose is to identify maintenance-significant components, assemblies, subassemblies, and modules with the next higher assembly. The end item group number is "00."
- b. **(2) Component/Assembly.** Column 2 contains the names of components, assemblies, subassemblies, and modules for which maintenance is authorized.
- c. **(3) Maintenance Function.** Column 3 lists the functions to be performed on the item listed in Column 2. (For a detailed explanation of these functions, refer to para B-2.)
- d. **(4) Maintenance Level.** Column 4 specifies, by the listing of a work-time figure in the appropriate subcolumn(s), the level of maintenance authorized to perform the function listed in Column 3. This figure represents the active time required to perform that maintenance function at the indicated level of maintenance. If the number or complexity of the tasks within the listed maintenance function varies at different maintenance levels, appropriate work-time figures will be shown for each level. The work-time figure represents the average time required to restore an item (assembly, subassembly, component, module, end item, or system) to a serviceable condition under typical field operating conditions. This time includes preparation time (including any necessary disassembly/assembly

B-3. EXPLANATION OF COLUMNS IN SECTION II, MAINTENANCE ALLOCATION CHART FOR ENGINE ASSEMBLY, DIESEL, HATZ 2 G 40 (continued).

troubleshooting/fault location time, and quality assurance/quality control time in addition to the time required to perform the specific tasks identified for the maintenance functions authorized in the MAC. The symbol designations for the various maintenance levels are as follows:

- C.....Operator/Crew
- O.....Unit
- F.....Direct Support
- H.....General Support
- D.....Depot

- e. **(5) Tools and Test Equipment Reference Code.** Column 5 specifies, by code, those common tool sets (not individual tools), common TMDE, special tools, special TMDE, and special support equipment required to perform the designated maintenance function. Codes are keyed to tools and test equipment listed in Section III.
- f. **(6) Remarks.** When applicable, this column contains a lettercode, in alphabetical order, which is keyed to remarks contained in Section IV. If there is nothing in the Remarks column, there is no Section IV.

B-4. EXPLANATION OF COLUMNS IN SECTION III, TOOLS AND TEST EQUIPMENT REQUIREMENTS.

- a. **Column 1, Tools and Test Equipment Reference Code.** This code correlates with the code used in Section II, Column 5.
- b. **Column 2, Maintenance Level.** The symbol designation shown indicates the lowest level of maintenance authorized to use the tool or test equipment.
- c. **Column 3, Nomenclature.** This is the name or identification of the tool or test equipment.
- d. **Column 4, National Stock Number.** This is the national stock number of the tool or test equipment.
- e. **Column 5, Tool Number.** This is the manufacturer's part number.

**Section II. MAINTENANCE ALLOCATION CHART
FOR ENGINE ASSEMBLY, DIESEL, HATZ 2 G 40**

(1) Group No.	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Level				(5) Tools and Equipment	(6) Remarks
			O	F	H	D		
22	BODY, CHASSIS AND HULL ACCESSORY ITEMS							
2210	Engine Identification Plate	Replace	0.5				1, 2, 7	
29	AUXILIARY GENERATOR AND ENGINE, AND CONTROLS							
2910	Engine Assembly	Inspect Service Test Adjust Repair	0.1 0.5 1.0 1.0 2.0	3.0 3.0 16			2 3, 9 2, 6,10, 15,16 2, 6, 10 15, 16	
2911	Crankcase, Cylinder Sleeve, Cylinder Head, and Block	Replace Repair		8.0 2.0			2, 5, 7, 8 2, 4, 6,11	
2912	Crankshaft	Replace		1.0			3, 5, 8, 12, 14	
2913	Flywheel Assembly	Replace		1.0			2, 5	
2914	Pistons and Connecting Rods	Replace Repair		2.0 2.0			2, 7 2, 5, 6, 8	
2915	Valves, Camshaft, and Timing System	Adjust Replace Repair		1.0 3.0 2.0			2 2 2, 5, 8	
2916	Engine Lubrication System	Test Replace		0.5 2.0			2, 17 2, 5, 13	
	Oil Filter	Replace	0.2				2, 7	
2918	Manifolds	Replace	1.0				2, 5	
2932	Injector Pump, Nozzles, and Fuel Lines	Adjust Replace		2.0 3.0			2, 3, 10, 16 2, 5,10	

**Section II. MAINTENANCE ALLOCATION CHART
FOR ENGINE ASSEMBLY, DIESEL, HATZ 2 G 40 (continued)**

(1) Group No.	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Level				(5) Tools and Equipment	(6) Remarks
			O	F	H	D		
2936	Engine Speed Governor and Controls	Adjust		2.0			2, 5	
		Replace		5.0			3, 8	
2952	Engine Cowling, Deflectors, Air Ducts, and Shrouds	Replace	1.0				3	
2960	Sending Units	Test	0.5				5	
		Replace	1.0				2	
2968	Switches, Circuit Breakers, and Fuses							
	Fuel Shutoff Solenoid	Adjust	1.0				2, 5, 8	
		Replace	0.5				2, 5, 8	

Section III. TOOLS AND TEST EQUIPMENT REQUIREMENTS

(1) Tools and Test Equipment Reference Code	(2) Maintenance Level	(3) Nomenclature	(4) National Stock Number	(5) Tool Number
1	O	Shop Equipment, Automotive Maintenance and Repair Organizational Maintenance, Common No. 2, Less Power	4910-00-754-0650	SC 4910-95-CL-A72
2	O, F	Tool Kit, General Mechanic's: Automotive	5180-00-177-7033	SC 5180-90-N26
3	F	Tool Kit, General Mechanic's	5180-00-699-5273	SC 5180-90-CL-N05
4	F	Shop Equipment, Machine Shop: Field Maintenance, Basic	3470-00-754-0708	SC 3470-95-A02
5	F	Shop Equipment, Automotive Maintenance and Repair: Field Maintenance Basic, Less Power	4910-00-754-0705	SC 4910-95-A31
6	F	Shop Equipment, Automotive Maintenance and Repair: Field Maintenance Supplemental No. 2	4910-00-754-0707	SC 4910-95-CL-A63
7	O	Shop Equipment, Automotive Maintenance and Repair Organizational Maintenance, Common No. 1	4910-00-754-0654	SC4910-95-A74
8	F	Tool Kit, Automotive Fuel and Electrical Systems Repair	5180-00-754-0655	SC5180-95-B08
9	F	Tester, Cylinder Compression	4910-00-808-4300	SC 4940-95-B02
10	F	Wrench		61372800
11	F	Bracket, Cylinder Alignment		62574200
12	F	Puller, Crank Gear		62574801
13	F	Puller, Relief Valve		62569902
14	F	Driver, Crank Gear		62574700
15	F	Testing Device, Fuel		66503091
16	F	Test Set, Fuel		60462890
17	F	Test Set, Oil Pressure		62092692

**APPENDIX C
REPAIR PARTS AND SPECIAL TOOLS LIST**

Section I. INTRODUCTION

Paragraph Number	Paragraph Title	Page Number
C-1	Scope	C-1
C-2	General.....	C-1
C-3	Explanation of Columns (Sections II and III)	C-2
C-4	Explanation of Columns (Section IV).....	C-6
C-5	Special Information	C-6
C-6	How To Locate Repair Parts.....	C-7
C-7	Abbreviations	C-7

C-1. SCOPE.

This repair parts and special tools list (RPSTL) lists and authorizes spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE); and other special support equipment required for the performance of Unit, Direct Support, and General Support maintenance of the Diesel Engine Assembly, Hatz 2 G 40. This RPSTL authorizes the requisitioning, issue, and disposition of spares, repair parts, and special tools as indicated by the source, maintenance, and recoverability (SMR) code.


C-2. GENERAL.

In addition to Section I, this RPSTL is divided into the following sections:

- a. **Section II. Repair Parts List.** A list of spares and repair parts authorized by this RPSTL for use in the performance of maintenance. The list also includes parts that must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in ascending alphanumeric sequence, with the parts in each group listed in ascending figure and item number sequence. Bulk materials are listed in item name sequence. Repair parts kits are listed separately in their own functional group within Section II.
- b. **Section III. Special Tools List.** A list of special tools, special TMDE, and other special support equipment authorized by this RPSTL for the performance of maintenance.
- c. **Section IV. Cross-reference Indexes.** There are two indexes. The first is a list, in national item identification number (NIIN) sequence, of all national stock numbered items appearing in the listings; the second is a list, in alphanumeric sequence, of all part numbers appearing in the listings. National stock numbers (NSNs) and part numbers are cross-referenced to each illustration/figure and item number appearance.

C-3. EXPLANATION OF COLUMNS (SECTIONS II AND III).

- a. **ITEM NO. [Column (1)].** Indicates the number used to identify items called out in the illustration.
- b. **SMR CODE [Column (2)].** The SMR code is a five-position code containing supply/requisitioning information, maintenance category authorization criteria, and disposition instruction, as shown in the following breakout:



* *Complete Repair.* Maintenance capacity, capability, and authority to perform all corrective maintenance tasks of the Repair function in a use/user environment in order to restore serviceability to a failed item.

- (1) **Source Code.** The source code tells you how to get an item needed for maintenance, repair, or overhaul of an end item/equipment. Explanations of source codes follow:

<u>Code</u>	<u>Application/Explanation</u>
<div style="border: 1px solid black; padding: 5px; display: inline-block;"> PA PB PC PD PE PF PG </div>	<p>Stocked Items; use the applicable NSN to request/requisition items with these source codes. They are authorized to the category indicated by the code entered in the third position of the SMR code.</p> <p style="text-align: center;"><i>**Items coded PC are subject to deterioration.</i></p>
<div style="border: 1px solid black; padding: 5px; display: inline-block;"> KD KF KB </div>	<p>Items with these codes are not to be requested/requisitioned individually. They are part of a kit that is authorized to the maintenance category indicated in the third position of the SMR code. The complete kit must be requisitioned and applied.</p>
<div style="border: 1px solid black; padding: 5px; display: inline-block;"> MO - Made at UNIT/AVUM Level MF - Made at DS/AVUM Level MH - Made at GS Level MD - Made at Depot </div>	<p>Items with these codes are not to be requested/requisitioned individually. They must be made from bulk material that is identified by the part number in the DESCRIPTION AND USABLE ON CODE (UOC) column and listed in the bulk material group of the repair parts list in this RPSTL. If the item is authorized to you by the third-position code of the SMR code, but the source code indicates it is made at a higher level, order the item from the higher level of maintenance.</p>
<div style="border: 1px solid black; padding: 5px; display: inline-block;"> AO - Assembled by UNIT/A VUM Level AF - Assembled by DS/AVUM Level AH - Assembled by GS Level AD - Assembled at Depot </div>	<p>Items with these codes are not to be requested/requisitioned individually. The parts that make up the assembled item must be requisitioned or fabricated and assembled at the level of maintenance indicated by the source code. If the third-position code of the SMR code authorizes you to replace the item, but the source code indicates that the item is assembled at a higher level, order the item from the higher level of maintenance.</p>

C-3. EXPLANATION OF COLUMNS (SECTIONS II AND III) (continued).

NOTE

Cannibalization or controlled exchange, when authorized, may be used as a source of supply for items with the preceding source codes, except for those source-coded "XA".

- XA - DO NOT requisition an "XA"-coded item. Order its next higher assembly.
- XB - If an "XB" item is not available from salvage, order it using the CAGEC and part number given.
- XC - Installation drawing, diagram, instruction sheet, or field service drawing that is identified by manufacturer's part number.
- XD - Item is not stocked. Order an "XD"-coded item through normal supply channels using the CAGEC and part number given if no NSN is available.

(2) **Maintenance Code.** Maintenance codes tell you the level(s) of maintenance authorized to use and repair support items. The maintenance codes are entered in the third and fourth positions of the SMR code as follows:

- (a) The maintenance code entered in the third position tells you the lowest maintenance level authorized to remove, replace, and use an item. The maintenance code entered in the third position will indicate authorization to one of the following levels of maintenance:

<u>Code</u>	<u>Application/Explanation</u>
C	Crew or Operator maintenance done within Unit maintenance or Aviation Unit maintenance.
O	Unit maintenance or Aviation Unit can remove, replace, and use the item.
F	Direct Support or Aviation Intermediate level can remove, replace, and use the item.
H	General Support level can remove, replace, and use the item.
L	Specialized repair activity (SRA) can remove, replace, and use the item.
L	Depot level can remove, replace, and use the item.
D	

NOTE

If authorized by the maintenance allocation chart (MAC) and SMR codes, some limited repair may be done on an item at a lower level of maintenance.

- (b) The maintenance code entered in the fourth position tells whether the item is to be repaired and identifies the lowest maintenance level with the capability to do complete repair (i.e., perform all authorized "Repair" functions). This position will contain one of the following maintenance codes:

C-3. EXPLANATION OF COLUMNS (SECTIONS II AND III) (continued).

<u>Code</u>	<u>Application/Explanation</u>
O	Unit maintenance or Aviation Unit is the lowest level that can do complete repair of the item.
F	Direct Support or Aviation Intermediate is the lowest level than can do complete repair of the item.
H	General Support is the lowest level that can do complete repair of the item.
L	SRA is the lowest level that can do complete repair of the Item.
D	Depot is the lowest level that can do complete repair of the item.
D	Nonrepairable. No repair is authorized.
Z	No repair is authorized. (No parts or special tools are authorized for the maintenance of a "B"-coded item.) However, the item may be reconditioned by adjusting, lubricating, and so on, at the user level.
B	

- (3) **Recoverability Code.** Recoverability codes are assigned to Items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the SMR code as follows:

<u>Code</u>	<u>Application/Explanation</u>
Z	Nonrepairable item. When unserviceable, condemn and dispose of the item at the level of maintenance shown in the third position of the SMR code.
O	Repairable item. When uneconomically repairable, condemn and dispose of the item at Unit maintenance or Aviation Unit level.
F	Repairable item. When uneconomically repairable, condemn and dispose of the item at the Direct Support or Aviation Intermediate level.
H	Repairable item. When uneconomically repairable, condemn and dispose of the item at the General Support level.
D	Repairable Item. When beyond lower-level repair capability, return to Depot. Condemnation and disposal of the item is not authorized below Depot level.
L	Repairable item. Condemnation and disposal of the Item is not authorized below SRA.
A	Item requires special handling or condemnation procedures for specific reasons (e.g., precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals/directives for specific instructions.

- c. **NSN [Column (3)].** The NSNs for the Items are listed in this column.

C-3. EXPLANATION OF COLUMNS

- d. **CAGEC [Column (4)].** The commercial and government entity code (CAGEC) is a five-digit alphanumeric code used to identify the manufacturer, distributor, or Government agency, etc., that supplies the item.

NOTE

When you use an NSN to requisition an item, the item you receive may have a part number different from the part ordered.

- e. **PART NUMBER [COLUMN (5)].** Indicates the primary number used by the manufacturer (individual, company, firm, corporation, of Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements, to identify an item or range of items.
- f. **DESCRIPTION AND USABLE-ON CODE (UOC) [Column (6)].** This column includes the following information:
- (1) The Federal item name and, when required, a minimum description to identify the item.
 - (2) Physical security classification. Not applicable (3) Items that are included in kits and sets are listed below the name of the kit or set on Figure KIT.
 - (3) Spare/repair parts that make up an assembled item are listed immediately following the assembled item line entry.
 - (4) Part numbers for bulk materials are referenced in this column in the line item entry for the item to be manufactured/fabricated.
 - (5) When the item is not used with all serial numbers of the same model, the effective serial numbers are shown on the last line(s) of the description (before the UOC) (7) The UOC, when applicable (see para C-5, Special Information) (8) In the Special Tools List section, the Basis of Issue (BOI) appears as the last line(s) in the entry for each special tool, special TMDE, and other special support equipment. when density of equipments supported exceeds density spread indicated in the BOI, the total authorization is increased proportionately.
 - (6) The statement "END OF FIGURE" appears just below the last item description in Column 5 for a given figure in both Section II and Section III.
- g. **QTY [Column (7)].** The QTY (quantity per figure) column indicates the quantity of the item used in the breakout shown on the illustration/figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of a quantity indicates that the quantity is variable and may vary from application to application.

C-4. EXPLANATION OF COLUMNS (SECTION IV).

a. National Stock Number (NSN) Index.

- (1) **STOCK NUMBER Column.** This column lists the NSN by NIN sequence. The NUN consists of the last nine digits of the NSN (i.e.,

$$\frac{\text{NSN}}{5305-01-674-1467}$$
). When using this column to locate an item, ignore the first four digits

$$\text{NIIN}$$
of the NSN. However, the complete NSN should be used when ordering items by stock number.
- (2) **FIG. Column.** This column lists the number of the figure where the item is identified/located. The figures are in numerical order in Section II and Section III.
- (3) **ITEM Column.** The item number identifies the item associated with the figure listed in the adjacent FIG. column. This item is also identified by the NSN listed on the same line.

b. Part Number Index. Part numbers in this index are listed by part number in ascending alphanumeric sequence (i.e., vertical arrangement of letter and number combination that places the first letter or digit of each group in order a through Z, followed by the numbers 0 through 9 and each following letter or digit in like order).

- (1) **CAGEC Column.** The CAGEC is a five-digit alphanumeric code used to identify the manufacturer, distributor, or Government agency, tc., that supplies the item.
- (2) **PART NUMBER Column.** Indicates the primary number used by the manufacturer (individual, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications standards, and inspection requirements, to identify an item or range of items.
- (3) **STOCK NUMBER Column.** This column lists the NSN for the associated part number and manufacturer identified in the PART NUMBER and CAGEC columns to the left.
- (4) **FIG. Column.** This column lists the number of the figure where the item is identified/located in Section II and Section III.
- (5) **ITEM Column.** The item number is that number assigned to the item as it appears in the figure referenced in the adjacent figure number column.

C-5. SPECIAL INFORMATION.

- a. **Usable-on Code.** Uncoded items are applicable to all models. usable on code for the M88A2 HERCULES items is APJ. Usable on code for all other applications is APP.
- b. **Fabrication Instructions.** Not applicable.
- c. **Assembly Instructions.** Not applicable.
- d. **Kits.** Not applicable.
- e. **Index Numbers.** Not applicable.

C-5. SPECIAL INFORMATION (continued).

- b. **Fabrication Instructions.** Not applicable.
- c. **Assembly Instructions.** Not applicable.
- d. **Kits.** Not applicable.
- e. **Index Numbers.** Not applicable.
- f. **Associated Publications.**

<p>Operator’s Manual, Unit Maintenance Manual, Direct Support and General Support Maintenance Manual, and Repair Parts and Special Tools List For Carrier, Ammunition, Tracked M992A2 (NSN 2350-01-368-9500)</p>	<p>TM 9-2350-293-10 TM 9-2350-293-20-1 and -2 TM 9-2350-293-34 TM 9-2350-293-24P</p>
<p>Operator’s Manual, Unit Maintenance Manual, Direct Support and General Support Maintenance Manual, and Repair Parts and Special Tools List For Recovery Vehicle, Full Tracked: Heavy M88A2 (NSN 2350-01-390-4683)</p>	<p>TM 9-2350-292-10 TM 9-2350-292-20-1 and -2 TM 9-2350-292-34 TM 9-2350-292-24P</p>

C-6. HOW TO LOCATE REPAIR PARTS.

- a. When the NSN or part number is not known, you can locate a repair part by following these steps:
 - (1) **First.** Using the Table of Contents, determine the assembly group or subassembly group to which the item belongs. This is necessary because figures are prepared for assembly groups and subassembly groups, and listings are divided into the same groups.
 - (2) **Second.** Find the figure covering the assembly group or subassembly group to which the item belongs.
 - (3) **Third.** Identify the item on the figure and note the item number of the item.
 - (4) **Fourth.** Refer to the Repair parts List for the figure to find the line item entry for the item number noted on the figure.
- b. When the NSN or part number is known, you can locate a repair part by following these steps.
 - (1) **First.** Using the National Stock Number Index or the Part Number Index, find the pertinent NSN or part number. the National Stock Number Index is in NIIN sequence. The part numbers in the Part Number Index are listed in ascending alphanumeric sequence. Both indexes cross-reference you to the figure number and item number of the item you are looking for.
 - (2) **Second.** After finding the figure and item numbers, verify that the item is the one you’re looking for; then locate the item number in the Repair Parts List for the figure.

C-7. ABBREVIATIONS.

For standard abbreviations see MIL-STD-12, Military Standard Abbreviations for Use on Drawings, Specifications, Standards, and in Technical Documents.





Figure 1. Engine Identification Plate

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 22 BODY, CHASSIS, AND HULL ACCESSORY ITEMS	
					GROUP 2210 DATA PLATES AND INSTRUCTION HOLDERS	
					FIGURE 1 ENGINE IDENTIFICATION PLATE	
1	PAOZZ	9905-01-456-3828	61080	03225504	PLATE, IDENTIFICATIO.....	1
2	PAOZZ	5315-01-070-5656	61080	40002500	PIN, GROOVED, HEADED.....	4

END OF FIGURE




291101

Figure 2. Engine, Diesel

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 29 AUXILIARY GENERATOR AND ENGINE, AND CONTROLS	
					GROUP 2910 ENGINE ASSEMBLY	
					FIGURE 2 ENGINE, DIESEL	
*	1	PAFFD	2815-01-465-4321	19207 12367094	ASSEMBLY,ENGINE,APU.....	1
	1	PAOFD	2815-01-446-3500	19207 12463204	UOC:APJ, ENGINE,DIESEL.....	
*	2	PAFZZ	5935-01-480-9543	19207 12367105	UOC:APP, .SPACER,SPECIAL SHAP.....	1
	2	PFZZ	5340-01-454-8631	61080 99400639	UOC:APJ, .PLATE,MOUNTING.....	1
	3	PAFZZ	5305-01-455-2207	61080 99400642	UOC:APP, .SCREW,CAP,SOCKET HE.....	4
	4	PAFZZ	5330-01-455-7822	61080 99400641	.SEAL,PLAIN ENCASED.....	1
*	5	PAFZZ		19207 12478240	PLATE,MOUNTING.....	1
	5	PFZZ	2990-01-454-8843	61080 99400640	UOC:APJ, .PLATE,MOUNTING,ENGI.....	1
*	6	PAFZZ	5305-12-146-1760	4B948 DIN7984-M10X30-1	UOC:APP, .SCREW,LOW HEAD CAP.....	8
	6	PAFZZ	5305-01-455-2206	61080 50054300	UOC:APJ, .SCREW,CAP,SOCKET HE.....	8
	7	PAFZZ	5310-01-274-4387	61080 50061700	UOC:APP, .WASHER,SPRING TENSI.....	8
*	7	PAFZZ	5310-12-130-4938	D8286 DIN7980-10-FST	UOC:APP, .WASHER,LOCK.....	8
					UOC:APJ,	

END OF FIGURE



29i098


Figure 3. Cylinder Head

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 2911 CRANKCASE, CYLINDER SLEEVE, AND CYLINDER HEAD	
					FIGURE 3 CYLINDER HEAD	
** 1	PAOZZ	5306-01-455-2212	61080	50315500	BOLT,EYE.....	1
** 2	PAOZZ	5365-01-399-5013	61080	03787300	UOC:APP, SHIM.....	1
3	PAFZZ	5310-01-455-8479	61080	03784501	UOC:APP, NUT,PLAIN,EXTENDED.....	5
4	PAFZZ	5310-01-399-8358	61080	03791400	WASHER,FLAT.....	8
5	PAFZZ	5310-01-399-7312	61080	03171800	NUT,PLAIN,HEXAGON.....	3
* 6	PAFZZ		61080	50405200	SEAL CAP,VALVE STEM.....	4
6.1	PAFFF	2815-01-455-0371	61080	01247200	CYLINDER HEAD,DIESE.....	2
***6.1	PAFFF		61080	01247210	CYLINDER HEAD,DIESE.....	2
* 6.2	PAFZZ	2815-01-455-0056	61080	03785201	.GUIDE,VALVE STEM.....	4
7	PAFZZ	5307-01-405-9899	61080	50038400	.STUD,PLAIN.....	2
8	PAFZZ	5307-01-406-5443	61080	50065100	.STUD,PLAIN.....	2
9	PAFZZ	5307-01-405-9997	61080	50128100	.STUD,PLAIN.....	2
9.1	PAFZZ	5307-01-405-9907	61080	50231900	.STUD,PLAIN.....	4
9.2	PAFZZ	5307-01-405-9909	61080	50279200	.STUD,PLAIN.....	4
11	KFFZZ		61080	03792800	GASKET,0.60 MM PART OF KIT P/N 01247702.....	1
11	KFFZZ		61080	03792900	GASKET,0.70 MM PART OF KIT P/N 01247702.....	1
11	PAFZZ		61080	03793000	GASKET,0.80 MM.....	V
11	PAFZZ		61080	03793100	GASKET,0.90 MM.....	V
11	PAFZZ		61080	03793200	GASKET,1.00 MM.....	V
11	PAFZZ		61080	03793300	GASKET,1.10 MM.....	V
11	PAFZZ		61080	03793400	GASKET,1.20 MM.....	V
11	PAFZZ		61080	03971200	GASKET,0.65 MM.....	V
11	PAFZZ		61080	03971300	GASKET,0.75 MM.....	V
11	PAFZZ		61080	04090600	GASKET,0.85 MM.....	V
11	PAFZZ		61080	04090700	GASKET,0.95 MM.....	V
*** 11	PAFZZ		61080	04110800	GASKET,0.50 MM.....	V
*** 11	PAFZZ		61080	04110900	GASKET,0.55 MM.....	V
12	PAFZZ	5307-01-455-2210	61080	03781000	STUD,PLAIN.....	8

END OF FIGURE

** Refer to TM 9-2350-292-24P and TM 9-2350-292-20-2 for UOC: APJ Item.

*** EPA Version 1 Compliant Only



29i099


Figure 4. Crankcase Assembly

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 2911 CRANKCASE, CYLINDER SLEEVE, AND CYLINDER HEAD	
					FIGURE 4 CRANKCASE ASSEMBLY	
*	1	PAFFF		61080 01227410	CRANKCASE ASSEMBLY 2G40.13, 2G40.14, 2G40.15.....	1
*	1	PAFFF		61080 01227420	CRANKCASE ASSEMBLY 2G40.16, 2G40.17, 2G40.18.....	1
	2	PAFZZ	5315-01-399-6105	61080 50290500	.PIN, STRAIGHT, HEADLE.....	2
	3	PAFZZ	5307-01-405-9997	61080 50128100	.STUD, PLAIN.....	2
	4	PAFZZ	5307-01-405-9905	61080 50098300	.STUD, PLAIN.....	4
	5	PAFZZ	5305-01-406-0014	61080 50137000	.SCREW, MACHINE.....	10
	6	PAOZZ	5310-12-149-4353	61080 50144500	.WASHER, FLAT.....	21
	7	PAFZZ	5310-01-405-9890	61080 50144400	.NUT, PLAIN, HEXAGON.....	10
	8	PAFZZ	5315-01-400-0444	61080 50300700	.PIN, STRAIGHT, HEADLE.....	2
	9	PAFZZ	4730-01-454-7542	61080 50302700	.NIPPLE, PIPE.....	1
*	10	PAOZZ	4730-01-454-7545	61080 05034900	.STRAINER ELEMENT, SE.....	1
*	11	PAFZZ	4820-01-455-5017	61080 01221803	.VALVE, SAFETY RELIEF.....	1
***	12	PAFZZ		61080 50139201	.STUD, M6 X 16.....	1
	12	PAFZZ	5307-01-455-2205	61080 50307000	.STUD, PLAIN.....	1
	13	PAFZZ	5315-01-399-6106	61080 50301000	.PIN, SPRING.....	1
	14	PAFZZ	5340-01-454-9272	61080 04038200	CAP-PLUG, PROTECTIVE.....	2
	15	PAFZZ	5340-01-454-9273	61080 04039100	CAP-PLUG, PROTECTIVE.....	4
	16	KFFZZ		61080 50301200	GASKET PART OF KIT P/N 01228002.....	1
**	17	PAFZZ	5305-01-455-1615	61080 50052100	SCREW, CAP, SOCKET HE.....	2
	18	PAOZZ	5310-01-399-7303	61080 50208500	UOC:APP, WASHER, SPRING TENSI.....	2
**	19	PAFZZ	5340-01-455-2343	61080 99400645	COVER, ACCESS.....	1
	20	PAFZZ	5330-01-400-5766	61080 50291400	UOC:APP, GASKET.....	1
	21	KFFZZ		61080 50301100	GASKET PART OF KIT P/N 01228002.....	1
	22	KFFZZ		61080 50275000	O-RING PART OF KIT P/N 01228002.....	8

END OF FIGURE

** Refer to TM 9-2350-292-24P and TM 9-2350-292-20-2 for UOC: APJ Item.

*** EPA Version 1 Compliant Only




29i100

Figure 5. Crankshaft Assembly

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 2912 CRANKCHSAFT ASSEMBLY	
					FIGURE 5 CRANKSHAFT ASSEMBLY	
1	PAFZZ		61080	50347500	SHIM.....	1
1	PAFZZ		61080	50347600	SHIM.....	1
2	PAFZZ	3020-01-455-2798	61080	50304400	GEAR, HELICAL.....	1
* 3	PAFFF	2815-01-455-0423	61080	01262701	CRANKSHAFT, ENGINE.....	1
4	PAFZZ	5315-01-103-1522	61080	50011200	.KEY.....	2
5	PAFZZ	5315-01-400-0441	61080	50304300	.KEY, MACHINE.....	1
6	PAFZZ	5340-01-455-0010	61080	50304100	.PLUG, MACHINE THREAD.....	4
7	PAFZZ	5365-01-406-4171	61080	50333900	BUSHING, MACHINE THR.....	1
8	PAFZZ	5330-01-400-5773	61080	50304500	SEAL, PLAIN PART OF KIT P/N 01228002.	1
9	XDFZZ		61080	99400638	HUB, BODY.....	1
* 9.1	PAFZZ	5315-00-616-5530	96906	MS35756-15	KEY, WOODRUFF.....	1
10	PAFZZ	5310-01-400-2138	61080	50146000	WASHER, SPRING TENSI.....	1
* 11	PAFZZ	5305-01-101-4830	21969	M10X55DIN912-8.8	SCREW, CAP, SOCKET HE.....	1
					UOC:APJ,	
11	PAFZZ	5305-01-455-1245	61080	50055100	SCREW, CAP, SOCKET HE.....	1
					UOC:APP,	
12	XDFZZ		61080	50302100	BEARING, SLEEVE.....	3
* 12.1	XDFZZ		61080	50324200	BEARING, SLEEVE.....	3

END OF FIGURE




29102

Figure 6. Flywheel and Related Components

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 2913 FLYWHEEL ASSEMBLY	
					FIGURE 6 FLYWHEEL AND RELATED COMPONENTS	
1	PAFZZ	5310-01-400-2140	61080	04031300	NUT, PLAIN, HEXAGON.....	1
2	PAFZZ	5310-01-400-2141	61080	03975300	WASHER, FLAT.....	1
3	PAFZZ	2815-01-455-0376	61080	03792100	FLYWHEEL, ENGINE.....	1
4	KFFZZ		61080	50311200	O-RING PART OF KIT P/N 01228002.....	1
5	PAFZZ	2815-01-454-9103	61080	50310810	HOUSING, FLYWHEEL.....	1
* 5.1	PAFFF	5340-01-494-6423	61080	99400644	COVER, ACCESS.....	1
6	PAOZZ	5340-01-454-9940	61080	99400646	. COVER, ACCESS.....	1
7	PAFZZ	5310-01-405-9911	61080	50145900	. WASHER, FLAT.....	2
8	PAOZZ	5305-01-406-0005	61080	50093400	. SCREW, MACHINE.....	2
9	KFFZZ		61080	50311500	GASKET PART OF KIT P/N 01228002.....	2
10	PAFZZ	5305-01-405-9908	61080	50310900	SCREW, MACHINE.....	3
11	PAFZZ	5310-01-400-1002	61080	50195800	WASHER, FLAT.....	1
12	XDFZZ		61080	01239901	ROD, PINION.....	1
13	PAFZZ	5315-01-455-8935	61080	50303610	PIN, STRAIGHT, HEADLE.....	1
14	XDFZZ		61080	50336200	O-RING.....	1
15	PAOZZ	5310-12-149-4353	61080	50144500	WASHER, FLAT.....	22
16	PAFZZ	5305-01-406-0000	61080	50092100	SCREW, MACHINE.....	18
17	PAFZZ	5310-01-405-9890	61080	50144400	NUT, PLAIN, HEXAGON.....	3
18	PAFZZ	5305-01-463-1028	61080	50026400	SCREW, MACHINE.....	1

END OF FIGURE




291095

Figure 7. Pistons and Connecting Rods

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 2914 PISTONS AND CONNECTING RODS	
					FIGURE 7 PISTONS AND CONNECTING RODS	
***	1	PAFFF	2835-01-414-8480	61080 01247100	LINER, COMBUSTION CH.....	2
	1	PAFFF		61080 01247110	LINER, COMBUSTION CH.....	2
	2	PAFZZ	5365-01-455-0011	61080 03958000	.SHIM.....	1
*	3	PAFFF		61080 01240203	.PISTON, INTERNAL COM.....	1
***	3	PAFFF		61080 01240211	.PISTON, INTERNAL COM.....	1
*	3	PAFFF		61080 01248303	.PISTON, INTERNAL COM OVERSIZE 0.5 MM.....	1
***	3	PAFFF		61080 01248311	.PISTON, INTERNAL COM OVERSIZE 0.5 MM.....	1
*	4	PAFZZ	2815-01-455-0428	61080 01240301	..RING SET, PISTON.....	1
*	4	PAFZZ		61080 01248701	..RING SET, PISTON OVERSIZE 0.5 MM..	1
	5	PAFZZ	5325-01-455-8936	61080 50359110	..RING, RETAINING.....	2
*	5.1	PAFZZ		61080 50359000	..PIN, PISTON 2G40.10.....	1
*	5.1	PAFZZ		61080 50359010	..PIN, PISTON.....	1
	6	PAFFF	2815-01-414-1273	61080 01262200	CONNECTING ROD, PIST.....	2
*	6.1	PAFZZ		61080 03785300	.BEARING, SLEEVE.....	1
*	6.2	XDFZZ		61080 03781300	.BEARING, SLEEVE.....	1
*	6.2	XDFZZ		61080 03785600	.BEARING, SLEEVE OVERSIZE 0.5 MM....	1
	7	PAFZZ	5305-01-406-0001	61080 03781100	SCREW, MACHINE.....	4

END OF FIGURE

*** EPA Version 1 Compliant Only



*Part of Item 20

Figure 8. Camshaft and Valves

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 2915 VALVES, CAMSHAFT, AND TIMING SYSTEM	
					FIGURE 8 CAMSHAFT AND VALVES	
1	PAFZZ	5325-01-399-4615	61080	50019800	RING,RETAINING.....	4
2	PAFZZ	5365-01-399-5011	61080	50315900	SHIM.....	V
3	PAFZZ	5365-01-455-0012	61080	50316000	SHIM.....	V
3.1	PAFFF	2815-01-455-0054	61080	01224400	ROCKER ARM,ENGINE P.....	2
4	PAFZZ	5310-01-078-8066	61080	03173100	.NUT,PLAIN,HEXAGON PART OF KIT P/N 01228202.....	1
5	PAFZZ	5305-01-405-9904	61080	03783000	.SCREW,MACHINE.....	1
7	PAFZZ	5310-01-101-2028	61080	40028400	NUT,SELF-LOCKING,HE.....	4
8	PAFZZ	2815-01-455-0046	61080	01224600	BRACKET,ROCKER ARM.....	2
8.1	PAFFF	2815-01-455-0043	61080	01224500	ROCKER ARM,ENGINE P.....	2
* 8.2	PAFZZ	5310-01-078-8066	61080	03173100	.NUT,PLAIN,HEXAGON PART OF KIT P/N 01228202.....	1
* 8.3	PAFZZ	5305-01-405-9904	61080	03783000	.SCREW,MACHINE.....	1
10	PAOZZ	5305-01-405-9903	61080	50177500	SCREW,MACHINE.....	4
11	PAOZZ	5310-01-415-2649	61080	50162900	WASHER,FLAT PART OF KIT P/N 01228202 , 01247702.....	4
12	PAOZZ	2815-01-454-8841	61080	03783800	COVER,ENGINE POPPET.....	2
13	PAOZZ	5330-01-400-5772	61080	50290200	O-RING PART OF KIT P/N 01228202, 01247702.....	2
14	PAFZZ	2815-01-455-0364	61080	03786300	LOCK,VALVE SPRING R.....	4
15	PAFZZ	5310-01-456-2275	61080	03783600	WASHER,SPRING TENSI.....	4
16	PAFZZ	5360-01-414-8475	61080	03783500	SPRING,HELICAL,COMP.....	4
17	PAFZZ	5310-01-399-7311	61080	03783401	WASHER,SPRING TENSI.....	4
* 18	PAFZZ	4820-01-407-0705	61080	03783300	VALVE,EXHAUST CONTR.....	2
*** 18	PAFZZ		61080	03783301	VALVE,EXHAUST CONTR.....	2
* 19	PAFZZ	2805-01-407-0706	61080	03783200	VALVE,POPPET,ENGINE.....	2
*** 19	PAFZZ		61080	03783210	VALVE,POPPET,ENGINE.....	2
20	PAFFF	3010-01-455-2856	61080	01222100	GEAR ASSY,CAMSHAFT.....	1
21	PAFZZ	5310-01-400-3721	61080	50305400	.NUT,PLAIN,HEXAGON.....	3
22	PAFZZ	5340-01-400-1000	61080	01244800	.PLATE,MOUNTING.....	1
23	PAFZZ	5305-01-406-0013	61080	50305300	.SCREW,MACHINE.....	3
24	PAFZZ	5365-01-100-5415	61080	03233200	SHIM.....	1
24	PAFZZ	5365-01-100-5416	61080	03233300	SHIM.....	1
25	PAFZZ	5325-01-245-3517	61080	50020000	RING,RETAINING.....	1
26	PAFZZ	5365-01-400-3717	61080	50305700	SPACER,SLEEVE.....	1
27	PAFZZ	5310-01-399-6981	61080	50306001	WASHER,FLAT.....	1
28	PAFZZ	5315-01-102-7922	61080	50010500	KEY.....	1
29	PAFZZ	5325-01-399-4618	61080	50305000	RING,RETAINING.....	1
* 30	PAFZZ	2815-01-454-8842	61080	04092800	CAMSHAFT,ENGINE.....	1
*** 30	PAFZZ		61080	04092810	CAMSHAFT,ENGINE.....	1
* 30	PAFZZ		61080	50304900	CAMSHAFT,ENGINE 2G40.10, 2G40.11...	1
31	PAFZZ	2815-01-455-0085	61080	50302000	TAPPET,ENGINE POPPE.....	4
32	KFFZZ		61080	50290100	O-RING PART OF KIT P/N 01247702.....	2
33	PAFZZ	2815-01-454-8839	61080	03781800	GUIDE,ENGINE POPPET.....	2
34	KFFZZ		61080	50208400	O-RING PART OF KIT P/N 01247702.....	2
35	PAFZZ	2815-12-330-5421	61080	01224001	PUSH ROD,ENGINE POP.....	4

END OF FIGURE

*** EPA Version 1 Compliant Only




Figure 9. Engine Lubrication System

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 2916 ENGINE LUBRICATION SYSTEM	
					FIGURE 9 ENGINE LUBRICATION SYSTEM	
1	PAOZZ	5305-01-405-9906	61080	50033300	SCREW, MACHINE.....	1
2	PAOZZ	5310-01-090-0938	61080	50000900	WASHER, FLAT PART OF KIT P/N 01247702	12
3	PAOZZ	4730-01-454-7549	61080	03790001	BOLT, FLUID PASSAGE.....	1
4	PAOZZ	4730-01-454-7692	61080	03932100	CONNECTOR, MULTIPLE.....	1
5	PAOZZ	4730-01-454-7693	61080	03790100	BUSHING, BOSS.....	1
6	PAOZZ	4730-01-103-3202	61080	50006100	BOLT, FLUID PASSAGE.....	3
7	PAOZZ	4710-01-454-7687	61080	01224900	TUBE ASSEMBLY, METAL.....	1
* 8	PAFZZ	2805-01-488-7755	61080	01227910	OIL PUMP ASSEMBLY, E.....	1
9	KFFZZ		61080	50310500	O-RING PART OF KIT P/N 01228002.....	1
10	PAFZZ	5340-01-454-9280	61080	50310400	COVER, ACCESS.....	1
11	PAFZZ	5310-01-400-2139	61080	50216300	WASHER, FLAT.....	3
12	PAFZZ	5305-01-406-0004	61080	50025200	SCREW, MACHINE.....	3
13	PAFZZ	4730-01-454-7461	61080	50301400	STRAINER ELEMENT, SE.....	1
14	KFFZZ		61080	50301500	GASKET PART OF KIT P/N 01228002.....	1
* 15	PAFZZ		61080	03938610	SUMP, OIL DEEP.....	1
					UOC: APJ,	
					OIL PAN.....	1
					UOC: APP,	
* 15.1	PAOZZ		61080	50341900	PLUG.....	1
					UOC: APJ,	
16	PAFZZ	5305-01-455-1243	61080	50207900	SCREW, MACHINE.....	10
					UOC: APP,	
* 16	PAFZZ	5305-01-492-8775	61080	50342000	SCREW, MACHINE.....	10
					UOC: APJ,	
17	PAFZZ	5310-01-239-2390	61080	500 812 00	WASHER, LOCK.....	10
					UOC: APP,	
* 17	PAFZZ	5310-12-149-4353	61080	50144500	WASHER, FLAT.....	1
					UOC: APJ,	
* 17.1	PAOZZ		61080	50043800	PLUG, RECESS.....	1
					UOC: APJ,	
* 17.2	PAOZZ		61080	50548200	PLUG.....	2
					UOC: APJ,	
* 17.3	PAOZZ		61080	50448100	WASHER.....	2
					UOC: APJ,	
** 18	PAOZZ	2940-01-383-9739	61080	50302800	FILTER ELEMENT, FLUI PART OF KIT P/N 01228202.....	1
					UOC: APP,	
21	PAOZZ	5330-01-101-8076	61080	50001200	GASKET PART OF KIT P/N 01228202.....	1
22	PAOZZ	4820-01-406-0343	61080	50311000	COCK, POPPET DRAIN PART OF KIT P/N 01228202.....	1
23	PAFZZ	5310-01-399-8386	61080	03788800	WASHER, FLAT.....	4
** 24	PAFZZ	5310-01-400-3719	61080	50335300	NUT, PLAIN, HEXAGON.....	4
					UOC: APP,	
** 25	PAFZZ		61080	50321900	STUD, PLAIN.....	2
					UOC: APP,	
** 26	KFFZZ	5331-01-400-5778	61080	50323500	O-RING PART OF KIT P/N 01228002.....	1
					UOC: APP,	
** 27	PAFZZ	2590-01-454-8941	61080	03908201	FILLER NECK, VEHICUL.....	1
					UOC: APP,	
**27.1	PAOFF		61080	01613100	CAP, FILLER OPENING PART OF KIT P/N 01228202.....	1
					UOC: APP,	
** 28	PAOZZ		61080	04125000	.O-RING PART OF KIT P/N 01228002.....	1
					UOC: APP,	
30	PAOZZ	4710-01-454-7688	61080	50336300	TUBE ASSEMBLY, METAL.....	1
31	PAOZZ	5305-01-405-9998	61080	50274500	SCREW, MACHINE.....	2
32	PAOZZ	5340-01-454-9281	61080	50336400	COVER, ACCESS.....	1
33	PAOZZ	5330-01-399-6976	61080	50336500	O-RING.....	1

END OF FIGURE
9-1

** Refer to TM 9-2350-292-24P and TM 9-2350-292-20-2 for UOC: APJ Item.




Figure 10. Exhaust Manifold Mounting Hardware

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC) GROUP 2918 MANIFOLDS FIGURE 10 EXHAUST MANIFOLD MOUNTING HARDWARE	(7) QTY
1	PAOZZ	5310-01-101-2028	61080	40028400	NUT, SELF-LOCKING, HE.....	4
2	PAOZZ	5330-01-455-7566	61080	01285500	GASKET SET PART OF KIT P/N 01247702.	2

END OF FIGURE




Figure 11. Intake Manifold and Related Components

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 2918 MANIFOLDS	
					FIGURE 11 INTAKE MANIFOLD AND RELATED COMPONENTS	
1	PAOZZ	2815-01-455-0041	61080	03787402	MANIFOLD, INTAKE.....	1
2	PAOZZ	5310-01-455-8480	61080	50148100	WASHER, FLAT.....	4
3	PAOZZ	5305-01-455-1242	61080	50175900	SCREW, CAP, SOCKET HE.....	2
4	PAOZZ	5305-01-455-1247	61080	50183100	SCREW, CAP, SOCKET HE.....	2
5	PAOZZ	5310-01-399-7305	61080	50095100	WASHER, SPRING TENSI.....	4
6	PAOZZ	5310-01-101-2028	61080	40028400	NUT, SELF-LOCKING, HE.....	4
7	PAOZZ	5330-01-455-7823	61080	01285600	GASKET.....	2
**	8	PAOZZ	2815-01-454-8626	61080	01198900 ADAPTER, INTAKE MANI..... UOC:APP,	1
9	PAOZZ	5310-01-399-7303	61080	50208500	WASHER, SPRING TENSI.....	8
10	PAOZZ	5305-01-455-1613	61080	50206300	SCREW, CAP, SOCKET HE.....	4
11	PAOZZ	5330-01-455-7819	61080	03783902	GASKET PART OF KIT P/N 01247702.....	2
12	PAOZZ		61080	50326200	O-RING.....	2
13	PAOZZ	5330-01-080-1776	61080	50001100	GASKET PART OF KIT P/N 01228002.....	1
14	PAOZZ	4730-01-399-6267	61080	50303000	COUPLING, HOSE.....	1
*	15	PAOZZ		61080	03784001 HOSE, PREFORMED..... UOC:APJ,	1
16	PAOZZ	4820-01-399-5579	61080	01225610	VALVE, VENT.....	1
17	PAOZZ	5340-01-454-9271	61080	03939700	COVER, ACCESS.....	1
*	18	PAFZZ	5310-01-400-3720	61080	50148000 NUT, PLAIN, HEXAGON.....	4

END OF FIGURE

** Refer to TM 9-2350-292-24P and TM 9-2350-292-20-2 for UOC: APJ Item.





Figure 12. Injection Pump, Nozzles, and Fuel Lines

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 2932 ENGINE FUEL SYSTEM FIGURE 12 INJECTION PUMP, NOZZLES AND FUEL LINES	
1	PAOZZ	4710-01-399-7358	61080	01240900	PIPE ASSEMBLY, METAL.....	1
*** 1	PAOZZ	4710-01-518-8127	61080	01240910	TUBE ASSEMBLY, METAL.....	1
2	PAOZZ	4710-01-399-7359	61080	01241000	PIPE ASSEMBLY, METAL.....	1
*** 2	PAOZZ	4710-01-518-8125	61080	01241010	TUBE ASSEMBLY, METAL.....	1
3	PAFZZ	5310-01-400-3720	61080	50148000	NUT, PLAIN, HEXAGON.....	6
4	PAFZZ	5310-01-399-7303	61080	50208500	WASHER, SPRING TENSILE.....	2
5	PAFZZ	5310-01-400-0995	61080	04035700	WASHER, FLAT.....	2
6	PAFZZ	4730-01-399-4252	61080	03792400	CLAMP, HOSE.....	2
* 6.1	PAFZZ	5307-01-405-9899	61080	50038400	STUD, PLAIN.....	2
* 7	PAFFF	2910-12-337-7727	61080	50355500	INJECTOR ASSEMBLY, F.....	2
*** 7	PAFFF		61080	50493300	INJECTOR ASSEMBLY.....	2
* 7.1	PAFZZ		61080	50355600	.NOZZLE.....	1
*** 7.1	PAFZZ		61080	50493400	.NOZZLE.....	1
*** 8	PAFZZ		61080	04025800	.JOINT PART OF KIT P/N 01247702.....	2
8	PAFZZ		61080	04085001	.JOINT PART OF KIT P/N 01247702.....	2
8	KFFZZ		61080	40085001	GASKET PART OF KIT P/N 01247702.....	2
9	PAOZZ	4730-01-399-4253	61080	03780800	NIPPLE, HOSE.....	2
* 9.1	PAOZZ		81343	J1508-M-04	CLAMP, HOSE.....	8
*** 9.2	MOOZZ		19207	12478232-4	HOSE, 2.2" MAKE FROM HOSE P/N 12478232.....	2
*** 9.3	PAOZZ		61080	50157800	NIPPLE, HOSE.....	2
*** 9.4	MOOZZ		19207	12478232-3	HOSE, 4.0" MAKE FROM HOSE, P/N 12478232.....	1
*** 9.5	PAOZZ		61080	50333400	NIPPLE, HOSE.....	2
10	PAOZZ	5330-01-405-9900	61080	50313100	GASKET PART OF KIT P/N 01247702.....	4
11	PAOZZ	4730-01-399-4254	61080	50313000	BOLT, FLUID PASSAGE.....	2
12	PAFFF	2910-12-338-8683	61080	50355400	PUMP, FUEL, METERING.....	1
*** 12	PAFFF		61080	50493200	PUMP, FUEL, METERING.....	1
13	PAFZZ	4820-01-406-6143	61080	49061200	.BODY, VALVE.....	2
14	PAFZA	5331-01-101-8063	61080	49004700	.O-RING.....	2
15	PAFZZ	5340-01-100-4991	61080	49003900	.PLUG, VENT.....	2
16	PAFZZ	5365-01-101-5938	61080	49004300	.SHIM.....	2
17	PAFZZ	5360-01-458-0666	61080	49003500	.SPRING, HELICAL, COMP.....	2
18	PAFZA	5330-01-101-7264	61080	49004400	.GASKET.....	2
19	PAFZZ	4820-01-407-1908	53867	3418502037	.VALVE, PRESSURE EQUA.....	2
20	PAFZZ		61080	50312500	GASKET, 0.30 MM.....	V
*** 21	KFFZZ		61080	50312400	GASKET, 0.20 MM PART OF KIT P/N 01228002.....	1
21	PAFZZ		61080	50552200	GASKET, 0.30 MM 2G40.17, 2G40.18 PART OF KIT P/N 01228002.....	1
22	KFFZZ		61080	50312300	GASKET, 0.10 MM PART OF KIT P/N 01228002.....	2
* 22.1	PAFZZ	5307-01-405-9905	61080	50098300	STUD, PLAIN.....	4
23	PAFZZ	5315-01-400-0445	61080	50312200	PIN, STRAIGHT, HEADLE.....	1
24	PAFZZ	4820-01-455-5018	61080	01231501	VALVE, FLOW CONTROL.....	1
25	PAOZZ	5330-01-080-1776	61080	50001100	GASKET PART OF KIT P/N 01228002..... UOC:APP,	2
25	PAOZZ	5330-01-080-1776	61080	50001100	GASKET PART OF KIT P/N 01228002..... UOC:APJ,	3
* 25.1	PAOZZ	5310-01-494-3769	61080	03966300	WASHER, FLAT..... UOC:APJ,	1
26	PAOZZ	4730-01-454-7573	61080	40092600	FITTING, RING PIECE..... UOC:APP,	1
26	PAOZZ	4730-01-494-7219	61080	50015800	CONNECTOR, MULTIPLE,..... UOC:APJ,	1
27	PAOZZ	4730-01-454-7560	61080	01223200	ADAPTER, STRAIGHT, TU.....	1
28	PAOZZ	5310-01-090-0938	61080	50000900	WASHER, FLAT PART OF KIT P/N 01247702	2
29	PAOZZ	4730-01-454-7567	61080	50015700	FITTING, RING PIECE.....	1
30	PAOZZ	4730-01-454-7569	61080	50311700	BOLT, FLUID PASSAGE.....	1
* 31	MOOZZ		19207	12478232-2	HOSE ASSEMBLY, NONME MAKE FROM HOSE, P/N 12478232.....	1
* 35	MOOZZ		19207	12478232-5	HOSE ASSEMBLY, NONME MAKE FROM HOSE, P/N 12478232.....	1
36	PAOZZ	5340-01-406-1646	61080	50314100	CLAMP, LOOP.....	1


END OF FIGURE

12-1/12-2 Ian



29I069

Figure 13. Governor and Controls (SH 1 of 2)



Note: EPA Compliant
Version 1 Shown

29i105

Figure 13. Governor and Controls (SH 2 of 2)

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 2936 ENGINE SPEED GOVERNOR AND CONTROLS						
FIGURE 13 GOVERNOR AND CONTROLS						
1	PAFZZ	2990-01-454-7609	61080	01222400	LEVER ASSEMBLY, POWE.....	1
2	PAFZZ	5315-01-399-6107	61080	50036000	PIN, COTTER.....	1
3	PAFZZ	5360-01-399-5014	61080	04020200	SPRING, HELICAL, COMP.....	1
*	3	PAFZZ	61080	04086300	UOC:APP, SPRING, HELICAL, COMP.....	1
					UOC:APJ,	
4	PAFZZ	2990-01-454-8630	61080	04088300	LEVER, THROTTLE.....	1
5	PAFZZ	5331-01-399-6978	61080	50306500	O-RING PART OF KIT P/N 01228002.....	2
6	PAFZZ	5325-01-400-0999	61080	50308800	RING, RETAINING.....	1
7	PAFZZ	5305-01-406-0000	61080	50092100	SCREW, MACHINE.....	1
8	PAFZZ	2990-01-454-9173	61080	50308901	LEVER, SPEED CONTROL.....	1
* 8.1	PAFZZ	5305-01-406-0009	61080	50309100	SCREW, MACHINE UOC:APP.....	1
9	PAFZZ	5310-01-405-9890	61080	50144400	NUT, FLAIN, HEXAGON.....	3
10	PAFZZ	5305-01-455-1246	61080	50309200	SCREW, MACHINE.....	1
11	PAFZZ	5360-01-399-5016	61080	50309300	SPRING, HELICAL, COMP.....	1
12	PAFZZ	2990-01-454-9177	61080	50309400	LEVER, SPEED CONTROL.....	1
13	PAFZZ	5310-01-405-9912	61080	50309500	WASHER, FLAT.....	1
14	PAFZZ	5310-01-455-8481	61080	50114300	WASHER, LOCK.....	2
15	PAFZZ	5305-01-274-1064	61080	500-254-00	SCREW, MACHINE.....	1
16	PAFZZ	5330-01-120-2966	61080	40021400	SEAL.....	1
17	PAFZZ	5999-01-116-8286	61080	40021500	WIRE MESH, KNITTED.....	1
18	PAFZZ	5305-01-406-0011	61080	03791600	SCREW, MACHINE.....	1
*	18	PAFZZ	61080	50344900	UOC:APP, SCREW, MACHINE.....	1
					UOC:APJ,	
19	PAFZZ	5305-01-406-0006	61080	50146300	SCREW, MACHINE.....	3
20	PAFZZ	5305-01-406-0007	61080	50306900	SCREW, MACHINE.....	1
21	PAFZZ	5305-01-455-1248	61080	50170800	SCREW, CAP, SOCKET HE.....	1
22	PAFZZ	5310-01-399-7301	61080	50170900	WASHER, SPRING TENSI.....	1
23	PAFZZ	2990-01-454-9202	61080	05063900	LEVER, GOVERNOR.....	1
24	PAFZZ	5365-01-455-0004	61080	03125800	SPACER, STRAIGHT.....	1
25	PAFZZ	2990-01-454-9214	61080	01266500	LEVER, GOVERNOR.....	1
26	PAFZZ	5360-01-399-5017	61080	50306600	SPRING, HELICAL, COMP.....	1
27	PAFZZ	5340-01-454-9278	61080	50306200	PLATE, MOUNTING.....	1
28	KFFZZ		61080	50307100	GASKET PART OF KIT P/N 01247702.....	1
29	PAFZZ	2990-01-454-8635	61080	01222300	STOP LEVER, GOVERNOR.....	1
29.1	PAFZZ		61080	50139201	STUD, M6 X 16.....	1
30	PAFZZ	5340-01-406-1645	61080	50308500	CLIP, SPRING TENSION.....	1
31	KFFZZ		61080	50308100	O-RING PART OF KIT P/N 01228002.....	2
32	PAFZZ	2990-01-455-0084	61080	01222510	LEVER ASSEMBLY, POWE.....	1
*** 33	PAFFF		61080	01665610	EXTRA FUEL DEVICE A.....	1
*** 34	PAFZZ		61080	01665600	.EXTRA FUEL DEVICE A.....	1
					SSEMBLY, 2G40.14	
35	PAFZZ	5315-01-081-4488	61080	50034100	.PIN, SPRING.....	1
36	PAFZZ		61080	01665000	.LEVER.....	1
37	PAFZZ		61080	04021800	.SPRING.....	1
38	PAFZZ	4730-01-103-3202	61080	50006100	BOLT, FLUID PASSAGE.....	1
39	PAFZZ	5310-01-090-0938	61080	50000900	WASHER, FLAT.....	2
40	PAFZZ		61080	01670100	PIPE, OIL.....	1
40.1	PAFZZ		61080	05184200	SCREW, CLOS.....	1
41	PAFZZ		61080	05186900	SUPPORT.....	1
42	PAFZZ	5305-01-406-0007	61080	50306900	SCREW, MACHINE.....	1
43	PAFZZ	5305-01-455-1250	61080	50149100	SCREW, CAP, SOCKET HE.....	1
*** 44	PAFZZ	5340-01-526-2574	61080	50500800	CLIP, RETAINING.....	1
*** 45	PAFZZ		61080	50511000	STUD, M6 X 30.....	1
*** 46	PAFZZ		61080	05185400	STOP.....	1
*** 47	PAFZZ		61080	05184800	BRACKET.....	1
*** 48	PAFZZ	5310-01-525-7457	61080	50328300	NUT, FLAIN, HEXAGON.....	1
*** 49	PAFZZ		61080	50507800	SCREW, GRUB.....	1
*** 50	PAFZZ		61080	50286300	SCREW, GRUB.....	1
*** 51	PAFZZ	5305-01-264-6247	61080	50052000	SCREW, ALLEN.....	1
52	PAFZZ		61080	50323800	SCREW, SOCKET HEAD.....	3




Figure 14. Engine Cowling, Ducts, and Shroud (SH 1 of 2)




Figure 14. Engine Cowling, Ducts, and Shroud (SH 2 of 2)

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 2952 ENGINE COWLING FIGURE 14 ENGINE COWLING, DUCTS, AND SHROUD	
					SCREW, MACHINE.....	3
					WASHER, SPLIT.....	3
					WASHER, FLAT.....	15
					SCREW, MACHINE.....	5
**	5	PAOZZ	2815-01-455-0040	61080 03784400	DEFLECTOR, AIRFLOW.....	1
					UOC: APP,	
**	6	PAOZZ	5340-01-459-1403	61080 01133200	BRACKET, AIR DUCT.....	1
					UOC: APP,	
					WASHER, SPRING TENSI.....	10
					SCREW, MACHINE.....	10
					WASHER, SPRING TENSI.....	2
					SCREW, MACHINE.....	2
					SCREW, MACHINE.....	8
**	12	PAOZZ	2815-01-454-9237	61080 01129900	DEFLECTOR, AIRFLOW.....	1
					UOC: APP,	
**	13	PAOZZ	3120-01-455-7311	61080 03920100	SPACER, SLEEVE.....	2
					UOC: APP,	
**	14	PAOZZ	2815-01-454-9210	61080 99400648	DEFLECTOR, AIRFLOW.....	1
					UOC: APP,	
**	15	PAOZZ	5340-01-458-8159	61080 01133300	BRACKET, AIR DUCT.....	1
					UOC: APP,	
					SLEEVE, REINFORCING,	1
**	17	PAOZZ	5305-01-455-1619	61080 50317800	SCREW, CAP, HEXAGON H.....	2
					UOC: APP,	
					SCREW, CAP, HEXAGON H.....	1
					BRACKET, AIR DUCT.....	1
					SHEET, CLAMPING.....	1
**	21	PAOZZ	2815-01-454-9344	61080 01445200	DEFLECTOR, AIRFLOW.....	1
					UOC: APP,	
**	22	PAOZZ	5310-01-405-9890	61080 50144400	NUT, PLAIN, HEXAGON.....	6
					UOC: APP,	
					CONSOLE, REGULATOR.....	1
					SCREW, MACHINE.....	2
					DEFLECTOR, AIRFLOW.....	1
					SCREW, MACHINE.....	1
					NUT, PLAIN, CLINCH.....	3

END OF FIGURE

** Refer to TM 9-2350-292-24P and TM 9-2350-292-20-2 for UOC: APJ Item.




Figure 15. Sending Units

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC) GROUP 2960 SENDING UNITS FIGURE 15 SENDING UNITS	(7) QTY
1	PAOZZ	2990-01-497-9561	61080	01160500	SWITCH,ENGINE TEMPE.....	1
* 1	PAOZZ	5930-01-348-9797	61080	50268600	UOC:APJ, SWITCH,THERMOSTATIC.....	1
2	PAOZZ	5930-01-441-0097	61080	50293810	UOC:APP, SWITCH,PRESSURE.....	1

END OF FIGURE




Figure 16. Fuel-Shutoff Solenoid

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
GROUP 2968 SWITCHES, CIRCUIT BREAKERS AND FUSES						
FIGURE 16 FUEL-SHUTOFF SOLENOID						
** 1	PAOZZ	3040-01-455-2816	61080	05063800	CONNECTING LINK,RIG..... UOC:APP,	1
2	PAOZZ	5340-01-454-9284	61080	50365600	CLIP,RETAINING.....	2
3	PAOZZ	5340-01-454-9277	61080	50180400	BELLOWS,PROTECTION.....	1
4	PAOZZ	5331-01-457-3350	61080	50225501	O-RING.....	1
5	PAOZZ	5945-01-454-8223	61080	50431300	PLUNGER,SOLENOID.....	1
** 6	PAOZZ	5305-01-401-3694	61080	50328500	SCREW,MACHINE..... UOC:APP,	4
7	PAOZZ	5310-12-149-4353	61080	50144500	WASHER,FLAT.....	5
** 8	PAOZZ	5310-01-405-9890	61080	50144400	NUT,PLAIN,HEXAGON..... UOC:APP,	3
** 9	PAOZZ	5945-01-454-8230	61080	01516900	BRACKET,SOLENOID..... UOC:APP,	1
** 10	PAOZZ	5305-01-455-1251	61080	50290300	SCREW,CAP,SOCKET HE..... UOC:APP,	1
** 11	PAOZZ	5945-01-454-8238	61080	01509110	SOLENOID,ELECTRICAL..... UOC:APP,	1
** 12	PAOZZ	5305-01-455-1250	61080	50149100	SCREW,CAP,SOCKET HE..... UOC:APP,	2
** 13	PAOZZ	5305-01-274-1064	61080	500-254-00	SCREW,MACHINE..... UOC:APP,	1
** 14	PAOZZ	5307-01-455-1249	61080	05094600	STUD,PLAIN..... UOC:APP,	1
** 15	PAOZZ	5310-01-456-0736	61080	50446700	NUT,PLAIN,HEXAGON..... UOC:APP,	1
** 16	PAOZZ	5340-01-454-9275	61080	05064010	CONNECTOR,ROD END..... UOC:APP,	1

END OF FIGURE

** Refer to TM 9-2350-292-24P and TM 9-2350-292-20-2 for UOC: APJ Item.

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 94 REPAIR KITS GROUP 9401 REPAIR KITS FIGURE KITS REPAIR KITS	
* 1	PAFZZ	5330-01-415-6721	61080	01247702	GASKET SET.....	1
					GASKET, 0.70 MM (1) 3-11	
					GASKET, 0.60 MM (1) 3-11	
					WASHER, FLAT (4) 8-11	
					O-RING (2) 8-13	
					O-RING (2) 8-32	
					O-RING (2) 8-34	
					WASHER, FLAT (2) 9-2	
					GASKET SET (2) 10-2	
					GASKET (2) 11-11	
					GASKET (2) 12-8	
					JOINT (2) 12-8	
					JOINT (2) 12-8	
					GASKET (4) 12-10	
					GASKET (1) 13-28	
					GASKET (1) 13A-20	
* 2	PAFZZ		61080	01228002	GASKET SET.....	1
					GASKET (1) 4-15	
					O-RING (8) 4-16	
					GASKET (1) 4-15.1	
					SEAL, PLAIN (1) 5-8	
					O-RING (1) 6-4	
					GASKET (2) 6-9	
					O-RING (1) 9-9	
					GASKET (1) 9-14	
					O-RING (1) 9-26	
					O-RING (1) 9-28	
					GASKET (1) 11-13	
					GASKET, 0.20 MM (1) 12-21	
					GASKET, 0.30 MM (1) 12-21	
					GASKET, 0.10 MM (2) 12-22	
					GASKET (2) 12-25	
					GASKET (3) 12-25	
					O-RING (2) 13-5	
					O-RING (2) 13-31	
					O-RING (1) 13A-7	
* 3	PAFZZ		61080	01228202	MAINTENANCE KIT.....	1
					NUT, PLAIN, HEXAGON (1) 8-4	
					WASHER, FLAT (4) 8-11	
					O-RING (2) 8-13	
					NUT, PLAIN, HEXAGON (1) 8-8.2	
					FILTER ELEMENT, FLUI (1) 9-18	
					GASKET (1) 9-21	
					COCK, POPPET DRAIN (1) 9-22	
					CAP, FILLER OPENING (1) 9-27.1	

END OF FIGURE

(1) ITEM NO	(2) SMR	(3) NSN	(4) CAGE	(5) PART NUMBER	(6) DESCRIPTION AND USABLE ON CODE (UOC)	(7) QTY
					GROUP 95 GENERAL USE STANDARDIZED PARTS	
					GROUP 9501 BULK MATERIAL	
					FIGURE BULK MATERIAL	
*	1	PAFZZ		19207 12478232	HOSE, NONMETALLIC.....	1

END OF FIGURE




Figure 17. Special Tools

(1)	(2)	(3)	(4)	(5)	(6)	(7)
ITEM	SMR	NSN	CAGE	PART	DESCRIPTION AND	QTY
NO				NUMBER	USABLE ON CODE (UOC)	
					GROUP 26 TOOLS AND TEST	
					EQUIPMENT	
					GROUP 2604 SPECIAL TOOLS	
					FIGURE 17 SPECIAL TOOLS	
* 1	PEOZZ	5120-01-428-5525	1CV05	3715M	WRENCH, OPEN END BOX.....	1
* 2	PEFZZ	5120-01-454-5887	61080	62574200	BRACKET, CYL, ALINE.....	1
* 3	PEFZZ	5120-01-454-5888	61080	62574801	PULLER, CRANK GEAR.....	1
* 4	PEFZZ	5120-01-454-5885	61080	62574700	DRIVER, CRANK GEAR.....	1
* 5	PEFZZ	5120-01-458-3944	61080	66503091	TESTING DEVICE, FUEL.....	1
* 6	PEFZZ	5120-01-454-5886	61080	62568902	PULLER, RELIEF VALVE.....	1
* 7	PEFZZ	5120-01-454-5890	19207	57K3263	TEST SET, OIL PRESSU.....	1
* 8	PEFZZ	4910-01-454-5889	19207	57K3264	TESTER, FUEL INJETOR.....	1

END OF FIGURE

CROSS REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX

STOCK NUMBER	FIGURE NO	ITEM NO	STOCK NUMBER	FIGURE NO	ITEM NO
5315-00-616-5530	5	9.1	4710-01-399-7358	12	1
5315-01-070-5656	1	2	4710-01-399-7359	12	2
5310-01-078-8066	8	4	5310-01-399-8358	3	4
	8	8.2	5310-01-399-8386	9	23
5330-01-080-1776	11	13	5315-01-400-0441	5	5
	12	25	5315-01-400-0444	4	8
5315-01-081-4488	13	35	5315-01-400-0445	12	23
5310-01-090-0938	9	2	5310-01-400-0995	12	5
	12	28	5325-01-400-0999	13	6
	13	39	5340-01-400-1000	8	22
5340-01-100-4991	12	15	5310-01-400-1002	6	11
5365-01-100-5415	8	24	5310-01-400-2138	5	10
5365-01-100-5416	8	24	5310-01-400-2139	9	11
5310-01-101-2028	8	7	5310-01-400-2140	6	1
	10	1	5310-01-400-2141	6	2
	11	6	5310-01-400-3715	14	2
5305-01-101-4830	5	11	5365-01-400-3717	8	26
5365-01-101-5938	12	16	5310-01-400-3719	9	24
5330-01-101-7264	12	18	5310-01-400-3720	11	18
5331-01-101-8063	12	14		12	3
5330-01-101-8076	9	21	5310-01-400-3721	8	21
5315-01-102-7922	8	28	5330-01-400-5766	4	20
5315-01-103-1522	5	4	5330-01-400-5772	8	13
4730-01-103-3202	9	6	5330-01-400-5773	5	8
	13	38	5331-01-400-5778	9	26
5999-01-116-8286	13	17	5305-01-401-3694	16	6
5330-01-120-2966	13	16	5310-01-405-9890	4	7
5310-01-239-2390	9	17		6	17
5325-01-245-3517	8	25		13	9
5305-01-264-6247	13	51		14	22
5305-01-274-1064	13	15		16	8
	16	13	5305-01-405-9892	14	18
5310-01-274-4387	2	7	5305-01-405-9894	14	4
5930-01-348-9797	15	1	5305-01-405-9895	14	1
2940-01-383-9739	9	18	5305-01-405-9897	14	8
4730-01-399-4252	12	6	5305-01-405-9898	14	26
4730-01-399-4253	12	9	5307-01-405-9899	3	7
4730-01-399-4254	12	11		12	6.1
5325-01-399-4615	8	1	5330-01-405-9900	12	10
5325-01-399-4618	8	29	5305-01-405-9901	14	10
5365-01-399-5011	8	2	5305-01-405-9903	8	10
5365-01-399-5013	3	2	5305-01-405-9904	8	5
5360-01-399-5014	13	3		8	8.3
5360-01-399-5016	13	11	5307-01-405-9905	4	4
5360-01-399-5017	13	26		12	22.1
4720-01-399-5578	14	16	5305-01-405-9906	9	1
4820-01-399-5579	11	16	5307-01-405-9907	3	9.1
5315-01-399-6105	4	2	5305-01-405-9908	6	10
5315-01-399-6106	4	13	5307-01-405-9909	3	9.2
5315-01-399-6107	13	2	5310-01-405-9911	6	7
4730-01-399-6267	11	14	5310-01-405-9912	13	13
5330-01-399-6976	9	33	5307-01-405-9997	3	9
5331-01-399-6978	13	5		4	3
5310-01-399-6981	8	27	5305-01-405-9998	9	31
5310-01-399-7301	13	22	5305-01-406-0000	6	16
	14	7		13	7
5310-01-399-7303	4	18	5305-01-406-0001	7	7
	11	9	5305-01-406-0003	14	24
	12	4	5305-01-406-0004	9	12
	14	9	5305-01-406-0005	6	8
5310-01-399-7305	11	5	5305-01-406-0006	13	19
5310-01-399-7311	8	17	5305-01-406-0007	13	20
5310-01-399-7312	3	5		13	42

CROSS REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX

STOCK NUMBER	FIGURE NO	ITEM NO	STOCK NUMBER	FIGURE NO	ITEM NO
5305-01-406-0009	13	8.1	5340-01-454-9271	11	17
5305-01-406-0010	13	18	5340-01-454-9272	4	14
5305-01-406-0011	13	18	5340-01-454-9273	4	15
5305-01-406-0013	8	23	5340-01-454-9275	16	16
5305-01-406-0014	4	5	5340-01-454-9277	16	3
4820-01-406-0343	9	22	5340-01-454-9278	13	27
5340-01-406-1645	13	30	5340-01-454-9280	9	10
5340-01-406-1646	12	36	5340-01-454-9281	9	32
5365-01-406-4171	5	7	5340-01-454-9284	16	2
5307-01-406-5443	3	8	2815-01-454-9344	14	21
4820-01-406-6143	12	13	5340-01-454-9940	6	6
4820-01-407-0705	8	18	5365-01-455-0004	13	24
2805-01-407-0706	8	19	5340-01-455-0010	5	6
4820-01-407-1908	12	19	5365-01-455-0011	7	2
2815-01-414-1273	7	6	5365-01-455-0012	8	3
5360-01-414-8475	8	16	2815-01-455-0039	14	25
2835-01-414-8480	7	1	2815-01-455-0040	14	5
5310-01-415-2649	8	11	2815-01-455-0041	11	1
5330-01-415-6721	KITS	1	2815-01-455-0042	9	15
4730-01-415-7923	14	20	2815-01-455-0043	8	8.1
5120-01-428-5525	17	1	2815-01-455-0046	8	8
2815-01-439-3916	14	23	2815-01-455-0054	8	3.1
5930-01-441-0097	15	2	2815-01-455-0056	3	6.2
2815-01-446-3500	2	1	2990-01-455-0084	13	32
5120-01-454-5885	17	4	2815-01-455-0085	8	31
5120-01-454-5886	17	6	2815-01-455-0364	8	14
5120-01-454-5887	17	2	2815-01-455-0371	3	6.1
5120-01-454-5888	17	3	2815-01-455-0376	6	3
4910-01-454-5889	17	8	2815-01-455-0423	5	3
5120-01-454-5890	17	7	2815-01-455-0428	7	4
4730-01-454-7461	9	13	5305-01-455-1242	11	3
4730-01-454-7542	4	9	5305-01-455-1243	9	16
4730-01-454-7545	4	10	5305-01-455-1245	5	11
4730-01-454-7549	9	3	5305-01-455-1246	13	10
4730-01-454-7560	12	27	5305-01-455-1247	11	4
4730-01-454-7567	12	29	5305-01-455-1248	13	21
4730-01-454-7569	12	30	5307-01-455-1249	16	14
4730-01-454-7573	12	26	5305-01-455-1250	13	43
2990-01-454-7609	13	1		16	12
4710-01-454-7687	9	7	5305-01-455-1251	16	10
4710-01-454-7688	9	30	5305-01-455-1613	11	10
4730-01-454-7692	9	4	5305-01-455-1615	4	17
4730-01-454-7693	9	5	5305-01-455-1619	14	17
5945-01-454-8223	16	5	5305-01-455-1622	14	11
5945-01-454-8230	16	9	5307-01-455-2205	4	12
5945-01-454-8238	16	11	5305-01-455-2206	2	6
2815-01-454-8626	11	8	5305-01-455-2207	2	3
2990-01-454-8630	13	4	5307-01-455-2210	3	12
5340-01-454-8631	2	2	5306-01-455-2212	3	1
2990-01-454-8635	13	29	5340-01-455-2343	4	19
2815-01-454-8839	8	33	3020-01-455-2798	5	2
2815-01-454-8841	8	12	3040-01-455-2816	16	1
2815-01-454-8842	8	30	3010-01-455-2856	8	20
2990-01-454-8843	2	5	4820-01-455-5017	4	11
2590-01-454-8941	9	27	4820-01-455-5018	12	24
2815-01-454-9103	6	5	3120-01-455-7311	14	13
2990-01-454-9173	13	8	5330-01-455-7566	10	2
2990-01-454-9177	13	12	5330-01-455-7819	11	11
2990-01-454-9202	13	23	5330-01-455-7822	2	4
2815-01-454-9210	14	14	5330-01-455-7823	11	7
2990-01-454-9214	13	25	5310-01-455-8479	3	3
2815-01-454-9237	14	12	5310-01-455-8480	11	2
5340-01-454-9270	14	19	5310-01-455-8481	13	14

CROSS REFERENCE INDEXES

NATIONAL STOCK NUMBER INDEX

STOCK NUMBER	FIGURE NO	ITEM NO	STOCK NUMBER	FIGURE NO	ITEM NO
5310-01-455-8482	14	27	5340-01-494-6423	6	5.1
5315-01-455-8935	6	13	4730-01-494-7219	12	26
5325-01-455-8936	7	5	2990-01-497-9561	15	1
5310-01-456-0736	16	15	4710-01-518-8125	12	2
5310-01-456-2275	8	15	4710-01-518-8127	12	1
9905-01-456-3828	1	1	5310-01-525-7457	13	48
5331-01-457-3350	16	4	5340-01-526-2574	13	44
5360-01-458-0666	12	17	5310-12-130-4938	2	7
5120-01-458-3944	17	5	5305-12-146-1760	2	6
5340-01-458-8159	14	15	5310-12-149-4353	4	6
5340-01-459-1403	14	6		6	15
5305-01-463-1028	6	18		9	17
2815-01-465-4321	2	1		14	3
5935-01-480-9543	2	2		16	7
2805-01-488-7755	9	8	2815-12-330-5421	8	35
5305-01-492-8775	9	16	2910-12-337-7727	12	7
5310-01-494-3769	12	25.1	2910-12-338-8683	12	12

CROSS REFERENCE INDEXES

PART NUMBER INDEX

PART NUMBER	FIG.	ITEM	PART NUMBER	FIG.	ITEM
01129900	14	12	03781800	8	33
01133200	14	6	03783000	8	5
01133300	14	15		8	8.3
01160500	15	1	03783200	8	19
01198900	11	8	03783210	8	19
01221803	4	11	03783300	8	18
01222100	8	20	03783301	8	18
01222300	13	29	03783401	8	17
01222400	13	1	03783500	8	16
01222510	13	32	03783600	8	15
01223200	12	27	03783800	8	12
01224001	8	35	03783902	11	11
01224400	8	3.1	03784001	11	15
01224500	8	8.1	03784300	14	19
01224600	8	8	03784400	14	5
01224900	9	7	03784501	3	3
01225610	11	16	03785201	3	6.2
01226100	14	20	03785300	7	6.1
01227410	4	1	03785600	7	6.2
01227420	4	1	03786300	8	14
01227910	9	8	03787300	3	2
01228002	KITS	2	03787402	11	1
01228202	KITS	3	03788800	9	23
01231501	12	24	03790001	9	3
01239901	6	12	03790100	9	5
01240203	7	3	03791400	3	4
01240211	7	3	03791600	13	18
01240301	7	4	03792100	6	3
01240900	12	1	03792400	12	6
01240910	12	1	03792800	3	11
01241000	12	2	03792900	3	11
01241010	12	2	03793000	3	11
01244800	8	22	03793100	3	11
01247100	7	1	03793200	3	11
01247110	7	1	03793300	3	11
01247200	3	6.1	03793400	3	11
01247210	3	6.1	03908201	9	27
01247702	KITS	1	03920100	14	13
01248303	7	3	03932100	9	4
01248311	7	3	03938610	9	15
01248701	7	4	03939700	11	17
01262200	7	6	03958000	7	2
01262701	5	3	03958100	14	23
01266500	13	25	03966300	12	25.1
01285500	10	2	03971200	3	11
01285600	11	7	03971300	3	11
01445200	14	21	03975300	6	2
01509110	16	11	04020200	13	3
01516900	16	9	04021800	13	37
01613100	9	27.1	04025800	12	8
01665000	13	36	04031300	6	1
01665600	13	34	04035700	12	5
01665610	13	33	04038200	4	14
01670100	13	40	04039100	4	15
03125800	13	24	04085001	12	8
03171800	3	5	04086300	13	3
03173100	8	4	04088300	13	4
	8	8.2	04090600	3	11
03225504	1	1	04090700	3	11
03233200	8	24	04092800	8	30
03233300	8	24	04092810	8	30
03780800	12	9	04110800	3	11
03781000	3	12	04110900	3	11
03781100	7	7	04125000	9	28
03781300	7	6.2	05034900	4	10

CROSS REFERENCE INDEXES

PART NUMBER INDEX

PART NUMBER	FIG.	ITEM	PART NUMBER	FIG.	ITEM
05063800	16	1		13	7
05063900	13	23	50093400	6	8
05064010	16	16	50095100	11	5
05094600	16	14	50098300	4	4
05184200	13	40.1		12	22.1
05184800	13	47	50098500	14	10
05185400	13	46	50114300	13	14
05186900	13	41	50128100	3	9
12367094	2	1		4	3
12367105	2	2	50137000	4	5
12463204	2	1	50139201	4	12
12478232	BULK	1		13	29.1
12478232-2	12	31	50144400	4	7
12478232-3	12	9.4		6	17
12478232-4	12	9.2		13	9
12478232-5	12	35		14	22
12478240	2	5		16	8
3418502037	12	19	50144500	4	6
3715M	17	1		6	15
40002500	1	2		9	17
40021400	13	16		14	3
40021500	13	17		16	7
40028400	8	7	50145900	6	7
	10	1	50146000	5	10
	11	6	50146300	13	19
40085001	12	8	50148000	11	18
40092600	12	26		12	3
49003500	12	17	50148100	11	2
49003900	12	15	50149100	13	43
49004300	12	16		16	12
49004400	12	18	50157800	12	9.3
49004700	12	14	50162900	8	11
49061200	12	13	50165500	14	18
500 812 00	9	17	50170600	14	26
500-254-00	13	15	50170700	14	8
	16	13	50170800	13	21
50000900	9	2	50170900	13	22
	12	28		14	7
	13	39	50175900	11	3
50001100	11	13	50177500	8	10
	12	25	50180400	16	3
50001200	9	21	50183100	11	4
50006100	9	6	50195800	6	11
	13	38	50206300	11	10
50010500	8	28	50207900	9	16
50011200	5	4	50208400	8	34
50015700	12	29	50208500	4	18
50015800	12	26		11	9
50019800	8	1		12	4
50020000	8	25		14	9
50025200	9	12	50216300	9	11
50026400	6	18	50225501	16	4
50033300	9	1	50231900	3	9.1
50034100	13	35	50268600	15	1
50036000	13	2	50274500	9	31
50038400	3	7	50275000	4	22
	12	6.1	50279200	3	9.2
50043800	9	17.1	50286300	13	50
50052000	13	51	50289200	14	11
50052100	4	17	50290100	8	32
50054300	2	6	50290200	8	13
50055100	5	11	50290300	16	10
50061700	2	7	50290500	4	2
50065100	3	8	50291400	4	20
50092100	6	16	50293200	14	24

CROSS REFERENCE INDEXES

PART NUMBER INDEX

PART NUMBER	FIG.	ITEM	PART NUMBER	FIG.	ITEM
50293810	15	2	50324200	5	12.1
50300700	4	8	50326200	11	12
50301000	4	13	50328300	13	48
50301100	4	21	50328500	16	6
50301200	4	16	50333400	12	9.5
50301400	9	13	50333800	14	4
50301500	9	14	50333900	5	7
50301601	9	15	50334600	14	1
50302000	8	31	50334800	14	16
50302100	5	12	50335300	9	24
50302700	4	9	50336200	6	14
50302800	9	18	50336300	9	30
50303000	11	14	50336400	9	32
50303610	6	13	50336500	9	33
50304100	5	6	50341900	9	15.1
50304300	5	5	50342000	9	16
50304400	5	2	50344900	13	18
50304500	5	8	50347500	5	1
50304900	8	30	50347600	5	1
50305000	8	29	50355400	12	12
50305300	8	23	50355500	12	7
50305400	8	21	50355600	12	7.1
50305700	8	26	50359000	7	5.1
50306001	8	27	50359010	7	5.1
50306200	13	27	50359110	7	5
50306500	13	5	50365600	16	2
50306600	13	26	50405200	3	6
50306900	13	20	50405600	14	25
	13	42	50408500	14	27
50307000	4	12	50431300	16	5
50307100	13	28	50446700	16	15
50308100	13	31	50448100	9	17.3
50308500	13	30	50493200	12	12
50308800	13	6	50493300	12	7
50308901	13	8	50493400	12	7.1
50309100	13	8.1	50500800	13	44
50309200	13	10	50507800	13	49
50309300	13	11	50511000	13	45
50309400	13	12	50548200	9	17.2
50309500	13	13	50552200	12	21
50310400	9	10	57K3263	17	7
50310500	9	9	57K3264	17	8
50310810	6	5	62568902	17	6
50310900	6	10	62574200	17	2
50311000	9	22	62574700	17	4
50311200	6	4	62574801	17	3
50311500	6	9	66503091	17	5
50311700	12	30	99400638	5	9
50312200	12	23	99400639	2	2
50312300	12	22	99400640	2	5
50312400	12	21	99400641	2	4
50312500	12	20	99400642	2	3
50313000	12	11	99400644	6	5.1
50313100	12	10	99400645	4	19
50314100	12	36	99400646	6	6
50315400	14	2	99400648	14	14
50315500	3	1	DIN7980-10-FST	2	7
50315900	8	2	DIN7984-M10X30-1	2	6
50316000	8	3	0.9-A3P		
50317800	14	17	J1508-M-04	12	9.1
50321900	9	25	M10X55DIN912-8.8	5	11
50323500	9	26	MS35756-15	5	9.1
50323800	13	52			

**APPENDIX D
EXPENDABLE AND DURABLE ITEMS LIST**

Section I. INTRODUCTION

Paragraph Number	Paragraph Title	Page Number
D-1	Scope	D-1
D-2	Explanation of Columns	D-1

D-1. SCOPE.

This appendix lists expendable/durable supplies and materials you will need to operate and maintain the Diesel Engine Assembly, Hatz G 2 40. This listing is for informational purposes only and is not authority to requisition the listed items. These items are authorized to you by CTA 50-970 or CTA 8-100.

D-2. EXPLANATION OF COLUMNS.

There are five columns in Section II, Expendable and Durable Items List:

- (1) **Item Number.** This number is assigned to the entry in the listing and is referenced in the "Initial Setup" of maintenance paragraphs or narrative instructions to identify the material needed (e.g., Drycleaning Solvent, Item 4, Appendix D).

- (2) **Level.** This column identifies the lowest level of maintenance that requires the listed item.
 - C - Operator/Crew
 - O - Unit
 - F - Direct Support
 - H - General Support

- (3) **National Stock Number.** This is the national stock number assigned to the item; use it to request or requisition the item.

- (4) **Description (CAGEC).** This column contains the Federal item name and, if required, a description to identify the item. The last line for each item indicates the commercial and government entity code (CAGEC) in parentheses followed by the part number, if applicable.

- (5) **U/M (Unit of Measure).** Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation: BT (bottle), BX (box), CN (can), GL (gallon), LB (pound), OZ (ounce), PT (pint), QT (quart), and TU (tube). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

Section II. EXPENDABLE AND DURABLE ITEMS LIST

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description (CAGEC)	(5) (U/M)
1	F	8040-00-833-9563	Adhesive Kit (71984) RTV 732	BT
2	O	8030-00-597-5367	Antiseize Compound, 2.5-Pound Can (73165) 51008	LB
3	F	6850-01-085-1423	Carbon-Removing Compound, 13-Ounce Aerosol Can (01326) 7450	OZ
4	O	6850-00-281-1985	Drycleaning Solvent, 1-Gallon Can (58536) A-A-59601	GL
5	F	9150-01-197-7690	Grease, Automotive, 1.75-Pound Can (81349) M-10924-C	CN
6	O	9150-00-186-6681	Lubricating Oil, 1-Quart Can (15958) ALLIEDC030	QT
7	O	7920-00-205-1711	Rag, Wiping, 50-Pound Bale (80244) 7920-00-205-1711	LB
8	F	7510-00-243-3437	Rubber Band, 1/4-Pound Box (88001) 0385B	BX
9	F	1015-01-255-4144	Sealant, Pipe, Teflon, 50-Milliliter Tube (19207) 12297953	TU
10	F	8030-00-252-3391	Sealing Compound, 11-Ounce Tube (80064) 1756371	TU
11	F	8030-00-081-2335	Sealing Compound, 10 Cubic Centimeter bottle (05970) 85-14	BT
12	O	8030-00-275-8115	Sealing Compound, 1-Pint Can (81349) MIL-S-46163	PT
13	O	8040-01-250-3969	Sealing Compound (05972) 242	ML
14	F		Primer, Grade N, 500 ML (05972) 50223001	ML
15	F	8030-01-060-0015	Sealing Compound (05972) 573	ML
16	F	8030-01-231-7156	Sealing Compound (05972) 601	ML
17	F		Sealing Compound (05972) 221	ML
18	F	8030-01-475-2445	Sealing Compound (05972) 648	ML
19	F	8030-01-388-5604	Sealing Compound (05972) T7471	ML

Section II. EXPENDABLE AND DURABLE ITEMS LIST (continued)

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description (CAGEC)	(5) (U/M)
20	F	8030-00-148-9833	Sealing Compound (05972) 27121	ML
21	F	5330-01-399-7318	Silicon Sealer (61080) 50282501	ML

**APPENDIX E
TORQUE VALUES FOR THREADED FASTENERS**

Paragraph Number	Page Paragraph Title	Number
E-1	General.....	E-1
E-2	Torque Limits	E-1
E-3	How To Use Torque Table.....	E-1
E-4	Tightening Metal Fasteners	E-3
E-5	Fastener Size and Thread Pattern	E-4
E-6	Fastener Grade	E-5

E-1. GENERAL.



This section provides general torque limits for screws used on the Diesel Engine Assembly, Hatz 2 G 40. Special torque limits are indicated in the maintenance procedures for applicable components. The general torque limits given in this appendix shall be used when specific torque limits are not indicated in the maintenance procedure. These general torque limits cannot be applied to screws that retain rubber components. The rubber components will be damaged before the correct torque limit is reached. If a special torque limit is not given in the maintenance instructions, tighten the screw or nut until it touches the metal bracket, then tighten it one more turn.

E-2. TORQUE LIMITS.

Table E-1 (p. E-2) lists dry torque limits. Dry torque limits are used on screws that do not have lubricants applied to threads. Table E-2 (p. E-3) lists wet torque limits. Wet torque limits are used on screws that have high-pressure lubricants applied to threads.

E-3. HOW TO USE TORQUE TABLE.

1. Measure the diameter of the screw to be installed.
2. Count the number of threads per inch or use a pitch gage.
3. Under the heading SIZE (Tables E-1 and E-2), look down the left-hand column until the diameter of the screw to be installed is found (there will usually be two lines beginning with the same size).
4. In the second column under SIZE, find the number of threads per inch that matches the number of threads counted in step 2.



E-3. HOW TO USE TORQUE TABLE (continued).

5. To find the grade of the screw that is to be installed, match the markings on the head to the correct picture of CAPSCREW HEAD MARKINGS on the table.

CAPSCREW HEAD MARKINGS


Manufacturer's marks may vary.
These are all SAE Grade No. 5 (3 lines).



6. Look down the column under the picture found in step 5 until the torque limit in foot-pounds for the diameter and threads per inch of the screw being installed is found.

Table E-1. Torque Limits for Dry Fasteners

SAE CAPSCREW HEAD MARKINGS




SIZE			TORQUE							
			SAE GRADE No. 1 or 2		SAE GRADE No. 5		SAE GRADE No. 6 or 7		SAE GRADE No. 8	
DIA. (IN.)	THREADS PER INCH	MM	FOOT- POUNDS	N•m	FOOT- POUNDS	N•m	FOOT- POUNDS	N•m	FOOT- POUNDS	N•m
1/4	20	6.35	5	6.78	8.0	10.85	10	13.56	12.0	16.27
1/4	28	6.35	6	8.14	10.0	13.56	—	—	14.0	18.98
5/16	18	7.94	11	14.92	17.0	23.05	19	25.76	24.0	32.52
5/16	24	7.94	13	17.63	19.0	25.76	—	—	27.0	36.61
3/8	16	9.53	18	24.41	31.0	42.04	34	46.10	44.0	59.66
3/8	24	9.53	20	27.12	35.0	47.46	—	—	49.0	66.44
7/16	14	11.11	28	37.97	49.0	66.44	55	74.58	70.0	94.92
7/16	20	—	30	40.68	55.0	74.58	—	—	78.0	105.77
1/2	13	12.70	39	52.88	75.0	101.70	85	115.26	105.0	142.38
1/2	20	—	41	55.60	85.0	115.26	—	—	120.0	162.78
9/16	12	14.28	51	69.16	110.0	149.16	120	162.72	155.0	210.18
9/16	18	—	55	74.58	120.0	162.72	—	—	170.0	230.52
5/8	11	15.88	63	85.43	150.0	203.40	167	226.45	210.0	284.76
5/8	18	—	95	128.82	170.0	230.52	—	—	240.0	325.44
3/4	10	19.05	105	142.38	270.0	356.12	280	379.68	375.0	506.50
3/4	16	—	115	155.94	295.0	400.02	—	—	420.0	596.52
7/8	9	22.23	160	216.96	375.0	536.62	440	596.64	605.0	820.38
7/8	14	—	175	237.30	435.0	599.85	—	—	675.0	915.30
1	8	25.40	235	318.66	590.0	800.04	660	694.96	910.0	1233.96
1	14	—	250	338.00	660.0	894.96	—	—	990.0	1342.44
1 1/8	—	25.58	—	—	800.0	1064.80	—	—	1280.0	1735.70
					880.0	1193.30			1444.0	1952.80
1 1/4	—	31.75	—	—	—	—	—	—	1820.0	2467.90
									2000.0	2712.00
1 3/8	—	34.93	—	—	1460.0	1979.80	—	—	2300.0	3227.30
					1680.0	2278.10			2720.0	3688.30
1 1/2	—	38.10	—	—	1940.0	2630.60	—	—	3160.0	4285.00
					2200.0	2963.20			3560.0	4827.40

E-3. HOW TO USE TORQUE TABLE (continued).

Table E-2. Torque Limits for Wet Fasteners

SAE CAPSCREW HEAD MARKINGS



SIZE			TORQUE							
			SAE GRADE No. 1 or 2		SAE GRADE No. 5		SAE GRADE No. 6 or 7		SAE GRADE No. 8	
DIA. (IN.)	THREADS PER INCH	MM	FOOT- POUNDS	N•m	FOOT- POUNDS	N•m	FOOT- POUNDS	N•m	FOOT- POUNDS	N•m
1/4	20	6.35	4.9	6.10	7.2	9.76	9.0	12.00	10.8	14.64
1/4	28	6.35	5.4	7.33	9.0	12.20	—	—	12.6	17.08
5/16	18	7.94	9.9	13.34	15.3	22.54	17.1	23.18	21.6	29.27
5/16	24	7.94	11.7	15.87	17.1	23.18	—	—	24.3	32.95
3/8	16	9.53	16.2	21.97	27.9	37.84	30.6	41.49	39.6	53.69
3/8	24	9.53	18.0	24.41	31.5	42.71	—	—	44.1	59.80
7/16	14	11.11	25.2	34.17	44.1	59.80	49.5	67.12	63.0	85.42
7/16	20	—	27.0	36.61	49.5	67.12	—	—	70.2	95.19
1/2	13	12.70	35.1	47.58	67.5	91.53	76.5	103.73	94.5	128.14
1/2	20	—	36.9	50.04	76.5	103.73	—	—	106.0	146.50
9/16	12	14.29	45.9	62.24	99.0	134.24	108.0	146.45	139.5	189.16
9/16	18	—	45.5	67.12	106.0	146.45	—	—	153.0	207.47
5/8	11	15.88	56.7	76.89	135.0	183.06	150.3	203.80	189.0	256.28
5/8	18	—	85.5	115.94	153.0	207.47	—	—	216.0	296.90
3/4	10	19.05	94.5	128.14	243.0	329.51	252.0	341.71	337.5	457.65
3/4	16	—	103.5	140.35	265.5	360.20	—	—	378.0	536.87
7/8	9	22.23	144.0	195.26	355.5	482.06	396.0	536.98	544.5	738.34
7/8	14	—	157.5	213.57	391.5	530.87	—	—	607.5	823.77
1	8	25.40	211.5	286.79	531.0	720.04	594.0	805.46	819.0	1110.56
1	14	—	225.0	305.10	594.0	805.46	—	—	891.0	1208.20
1-1/8	—	25.58	—	—	720.0	976.32	—	—	1152.0	1562.13
					792.0	1073.97	—	—	1296.0	1757.52
1-1/4	—	31.75	—	—	—	—	—	—	1638.0	2221.11
									1800.0	2440.80
14-3/8	—	34.93	—	—	1314.0	1781.82	—	—	2142.0	2904.57
					1512.0	2050.29	—	—	2448.0	3319.47
1-1/2	—	38.10	—	—	1746.0	2367.54	—	—	2844.0	3856.50
					1980.0	2684.88	—	—	3204.0	4344.66

E-4. TIGHTENING METAL FASTENERS.

When torquing a fastener, select a torque wrench whose range (Table E-3, p. E-4) fits the required torque value. A torque wrench is most accurate from 25 percent to 75 percent of its stated range. A torque wrench with a stated range of 0 to 100 will be most accurate from 25 to 75 foot-pounds. The accuracy of readings will decrease as you approach 0 foot-pounds or 100 foot-pounds. The ranges in Table E-3 are based on this principle.

E-4. TIGHTENING METAL FASTENERS (continued).

Table E-3. Torque Ranges


STATED RANGE	MOST EFFECTIVE RANGE
0-600 ft-lb	150-450 ft-lb
0-170 ft-lb	44-131 ft-lb
15-75 ft-lb	30-60 ft-lb

E-5. FASTENER SIZE AND THREAD PATTERN.


Threaded fasteners are categorized according to diameter of the fastener shank. Thread styles are divided into broad groups, the two most common being coarse (Unified Coarse-UNC) and fine (Unified Fine-UNF). These groups are defined by the number of threads per inch on the bolt shanks. In addition, threads are categorized by thread class (Table E-4), which is a measure of the degree between threads of bolt or screw (external threads) and threads of the attaching nut or tapped hole (internal threads of the attaching nut or tapped hole) (internal threads). The most common thread class for bolts and screws is Class 2.

Table E-4. Thread Classes and Description

EXTERNAL	INTERNAL	INTERNAL
1A	1B	LOOSE FIT
2A	2B	MEDIUM FIT
3A	3B	CLOSE FIT



NOTE: Unless followed with -LH (e.g., 3/4-10 UNC-2A-LH), threads are right-hand.



E-6. FASTENER GRADE.

In addition to being classified by thread type, thread fasteners are also classified by material. The most familiar fastener classification system is the SAE grading system (Table E-5).

<i>Table E-5. SAE Screw and Bolt Markings</i>	
SCREWS	BOLTS
SAE GRADE 2 NO MARKING	SAE GRADE 6 4 RADIAL DASHES 90° APART
SAE GRADE 3 2 RADIAL DASHES 180° APART	SAE GRADE 7 5 RADIAL DASHES 72° APART
SAE GRADE 5 3 RADIAL DASHES 120° APART	SAE GRADE 8 6 RADIAL DASHES 60° APART

Markings on Hex Locknuts

GRADE A - No Marks
 GRADE B - 3 Marks
 GRADE C - 6 Marks

GRADE A - No Marks
 GRADE B - Letter B
 GRADE C - Letter C

GRADE A - No Notches
 GRADE B - 1 Notch
 GRADE C - 2 Notches

**APPENDIX F
MANDATORY REPLACEMENT PARTS**

Paragraph Number	Page Paragraph Title	Number
F-1	General.....	F-1
F-2	Explanation of Columns	F-1
Table F-1	Mandatory Replacement Parts List	F-2

F-1. GENERAL.

This appendix is a cross-reference of item numbers to part numbers and is included for that purpose only.

F-2. EXPLANATION OF COLUMNS .

There are five columns in Table F-1, Mandatory Replacement Parts List (p. F-2):

- (1) **Item Number.** This number is assigned to the entry in Table F-1 for cross-referencing to the part number. The item number appears in the Materials/Parts listing of a maintenance procedure.
- (2) **Part Number.** This is the primary number used by the manufacturer, which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or a range of items.
- (3) **National Stock Number.** When available, the national stock number is listed for each part.
- (4) **Item Name.** This is the name given each item in the Materials/Parts listing of a maintenance procedure.
- (5) **Reference.** This is the Repair Parts and Special Tools List (RPSTL) appendix in which the referenced replacement part can be found. The RPSTL is the authorization for requisitioning replacement parts.

Table F-1. MANDATORY REPLACEMENT PARTS LIST

(1) Item Number	(2) National Part Number	(3) Stock Number	(4) Item Name	(5) Reference
1	01228000	5330-01-415-6723	Crankcase Gasket Set	Appendix C
2	01240300	2815-01-455-0428	Piston Ring Set	Appendix C
3	01247700	5330-01-415-6721	Head Gasket Set	Appendix C
4	01285600		Gasket Set	Appendix C
5	03233200	5365-01-100-5416	Shim, 0.2 mm	Appendix C
6	03233300	5365-01-100-5417	Shim, 0.3 mm	Appendix C
7	03781300	3120-01-416-3110	Sleeve Bearing	Appendix C
8	03783902		Gasket	Appendix C
9	03958000	5365-01-455-0011	Shim, 0.3 mm	Appendix C
10	04038200	5340-01-454-9272	Cap-Plug	Appendix C
11	04039100	5340-01-454-9273	Cap-Plug	Appendix C
12	40002500		Blind Rivet	Appendix C
13	40021400	5330-01-120-2966	Seal	Appendix C
14	40021500	5999-01-116-8286	Wire Mesh	Appendix C
15	40028400	5310-01-101-2028	Self-Locking Nut	Appendix C
16	49004400	5330-01-101-7264	Gasket	
17	49004700		O-Ring	
18	50000900	5310-01-090-0938	Washer	Appendix C
19	50001100	5330-01-080-1776	Gasket	Appendix C
20	50019800	5360-01-399-4615	Retaining Ring	Appendix C
21	50020000	5365-01-245-3517	Retaining Ring	Appendix C
22	50036000	5315-01-399-6107	Cotter Pin	Appendix C
23	50061700	5310-01-274-4387	Lockwasher	Appendix C
24	50081200	5130-01-274-3165	Lockwasher	Appendix C
25	50095100	5310-01-399-7305	Spring Tension Washer	Appendix C
26	50114300		Lockwasher	Appendix C
27	50146000	5310-01-400-2138	Spring Tension Washer	Appendix C

Table F-1. MANDATORY REPLACEMENT PARTS LIST (continued)

(1) Item Number	(2) Part Number	(3) National Stock Number	(4) Item Name	(5) Reference
28	50153800	5330-01-070-7136	O-Ring	Appendix C
29	50162900	5301-01-415-2649	Washer	Appendix C
30	50170900	5310-01-399-7301	Spring Tension Washer	Appendix C
31	50208500	5310-01-399-7307	Spring Tension Washer	Appendix C
32	50225501		O-Ring	Appendix C
33	50290200	5330-01-400-5772	O-Ring	Appendix C
34	50302100	3120-01-4161-3105	Sleeve Bearing	Appendix C
35	50302800	2940-01-383-9739	Filter Element	Appendix C
36	50305000	5365-01-399-4618	Retaining Ring	Appendix C
37	50306500		O-Ring	Appendix C
38	50308500	5340-01-406-1645	Clip	Appendix C
39	50308800	5365-01-400-0999	Retaining Ring	Appendix C
40	50313100		Gasket	Appendix C
41	50315400	5310-01-400-3715	Split Washer	Appendix C
42	50315900	5365-01-399-5011	Shim, 0.2 mm	Appendix C
43	50316000	5365-01-455-0012	Shim, 0.3 mm	Appendix C
44	50326200	5330-01-399-8354	O-Ring	Appendix C
45	50336200	5330-01-399-8357	O-Ring	Appendix C
46	50336500	5330-01-399-6979	O-Ring	Appendix C
47	50359110		Retaining Ring	Appendix C
48	99400641		Seal	Appendix C
49	05185802		Spring, Return	Appendix C
50	50153900		O-Ring	Appendix C
51	50224200		CIRCLIP, 16x1	Appendix C
52	50195800	5310-01-400-1002	Shim	Appendix C

Table F-1. MANDATORY REPLACEMENT PARTS LIST (continued)

(1) Item Number	(2) Part Number	(3) National Stock Number	(4) Item Name	(5) Reference
53	50499900	5315-01-081-4488	Spring, Pressure	Appendix C
54	50499800		O-Ring	Appendix C
55	50500000		Spring, Pressure	Appendix C
56	50034100		Pin, Spring	Appendix C
57	04021800		Spring	Appendix C
58	50519800		O-Ring	Appendix C

**APPENDIX G
TOOL IDENTIFICATION LIST**

Section I. INTRODUCTION

Paragraph Number	Page Paragraph Title	Number
G-1	General.....	G-1
G-2	Explanation of Columns in Section II.....	G-1

G-1. GENERAL.

This appendix lists all of the common and special tools required to maintain the Diesel Engine Assembly, Hatz 2 G 40. This appendix is for reference only. To requisition special tools, refer to Appendix C, Repair Parts and Special Tools List (RPSTL).

G-2. EXPLANATION OF COLUMNS IN SECTION II.

- a. Column (1) - Item Number. This number is assigned to the entry in the listing and is referenced in the initial setup in each maintenance procedure to identify the item (e.g., General mechanic's tool kit, Item 11, Appendix G).
- b. Column (2) Item Name. This column lists the item by nomenclature and other descriptive features, such as measurement.
- c. Column (3) National Stock Number. This is the national stock number assigned to the item; use it to requisition or request an item.
- d. Column (4) Part Number. This indicates the primary number used by the manufacturer who controls the design and characteristics of the item by means of engineering drawings, specification, standards, and inspection requirements.
- e. Column (5) Reference. This column identifies the authorizing supply catalog (SC) or RPSTL for items listed in this appendix.

Section II. TOOL IDENTIFICATION LIST

(1) Item Number	(2) National Part Number	(3) Stock Number	(4) Item Name	(5) Reference
1	Arbor press	3444-00-449-7295	A-A-51194	SC- 4910-95-A31
2	Blind hand riveter	5120-00-017-2849	98	SC 4910-95-CL-A74
3	Cable assembly	6150-00-682-3460	11647741	SC 4910-95-CL-A74
4	Crank gear driver		62574700	TM 9-2815-250-24&P
5	Crank gear puller		62574801	TM 9-2815-250-24&P
6	Cylinder alignment bracket		62574200	NA
7	Cylinder compression tester	4910-00-808-4300	MIL-G-5353, Type 2	SC-4940-95-B02
8	Cylinder ridge reamer	5110-00-237-8598	MIL-C-82069	SC-4910-95-A63
9	Depth gage rule	5210-00-221-1902	MC103A	SC-3470-95-A02
10	Drill set	5133-00-293-0983	DB129B	SC 4910-95-CL-A72
11	Electric drill	5130-00-889-9004	WD00661	SC 4910-95-CL-A74
12	Fuel-test set		60462890	TM 9-2815-250-24&P
13	Fuel-testing device		66503191	TM 9-2815-250-24&P
14	General mechanic's tool kit	5180-00-699-5273	SC-5180-90-CL-N05	SC-5180-90-CL-N05
15	General mechanic's tool kit, automotive	5180-00-177-7033	SC-5180-90-CL-N26	SC-5180-90-CL-N26
16	Indicator dial	5210-00-277-8840	196A	SC-4910-95-A63
17	Mechanical gear and bearing puller kit	5180-00-423-1569	GGG P 781	SC-4910 95 A31
18	Mechanical hand-held tachometer	6680-00-171-4584	4800	SC-4910 95 A31
19	Multimeter	6625-01-139-2512	T00377	SC-4910 95 A31
20	Oil pressure test set		62092692	TM 9-2815-250-24&P

Section II. TOOL IDENTIFICATION LIST (continued)

(1) Item Number	(2) National Part Number	(3) Stock Number	(4) Item Name	(5) Reference
21	Piston ring com- pressor	5120-00-223-8848	J3272-03	SC-4910-95-A63
22	Piston ring expander	5120-00-857-3190	PRS 8	SC-4910 95 A31
23	Relief valve puller		62568902	TM 9-2815-250-24&P
24	Screwdriver attachment, 6 mm	5120-01-102-1670	J3516-A	SC-4910-95-A31
25	Screwdriver attachment, 8 mm	5120-01-101-1943	GIT-17595	SC-4910 95 A31
26	Snapping pliers	5120-00-789-0492	4440R	SC-5180-95-B08
27	Socket wrench set, 3/8-inch drive	5120-00-322-6231	512000 17510	SC-5181-95-B08
28	Steel rule, 12-inch	5210-00-234-5224	GGG-R-791	SC-3470-95-A02
29	Strap wrench	5120-00-020-2947	A91C	SC-4910-95-A74
30	Torque wrench, 3/8-inch drive	5120-00-554-7292	GGG-W-00686	SC-4910-95-A74
31	Torque wrench, 1/2-inch drive	5120-00-640-6364	1753 LDF	SC-4910 95 A31
*32	Torque wrench, 3/8-inch drive	5120-01-112-9531	TESI60	SC-4910 95 A31
33	Valve face grinding machine	44910-00-540-4679	K403CM	SC-4910-95-A63
34	Valve seat grinding kit	4910-00-060-9983	WG690	SC-4910-95-A63
35	Valve spring lifter	5120-00-239-8686	GGG-L-350	SC-4910-95-A63
36	Wrench	51230-01-309-2048	3715M	TM 9-2815-250-24&P

*This torque wrench may be used instead of Item 30 if a metric torque reading is preferred.

INDEX

SUBJECT	PAGE
A	
Abbreviations and Acronyms	1-2
Adjustment	
Engine Speed	3-69
Flow Control Valve	3-60
Solenoid (UOC: APP)	2-30
Valve	3-58
Valve-to-Piston Clearance	3-40
Airflow Deflectors Replacement (UOC: APP)	2-24
Auxiliary Drive Adapter Replacement	3-14.1
B	
Bearings Repair, Crankshaft and	3-26
C	
Camshaft Repair	3-40
Cautions, Notes, and Warnings	v
Cleaning Instructions	2-4
Combustion Chamber Liner Repair, Piston and	3-32
Common Tools and Equipment	2-1
Components, Major, Location and Description	1-5
Corrosion Prevention and Control	1-3
Crankcase Repair	3-20
Crankshaft and Bearings Repair	3-26
Cylinder Compression Test	3-56
Cylinder Heads Repair	3-15
D	
Deep Oil Pan and Gasket Replacement (UOC: APJ)	3-48.1
Destruction of Army Materiel To Prevent Enemy Use	1-1
Direct Support and General Support	
Maintenance Procedures	3-12
Quick Guide to Troubleshooting	3-2
Troubleshooting Chart	3-3
Troubleshooting, General	3-1
Durable Items List, Expendable and	D-2
E	
Engine Speed Adjustment	3-69
Equipment Characteristics, Capabilities and Features	1-4
Equipment Data	1-8
Equipment Improvement Recommendations, Reporting	1-2
Equipment, Support	2-1

SUBJECT	PAGE
E (continued)	
Errors, Reporting	i
Expendable and Durable Items List	D-2
■ Eyebolt Replacement (UOC: APP)	2-8
F	
Fastener Grade	E-5
Fastener Size and Thread Pattern	E-4
■ Filler Neck Replacement (UOC: APP)	3-46
■ Filler Opening Cap Replacement (UOC: APP)	2-10
■ Filter Element Replacement (UOC: APP)	2-13
Flow Control Valve Adjustment	3-60
■ Flywheel and Housing Replacement	3-28
Forms	1-1, A-1
Fuel Injector	
Replacement	3-48.2
Test	3-66
Fuel Pressure Pipe Assemblies and Return Fuel Hose Replacement	2-20
G	
Governor Control Assembly Repair	3-54
H	
Hose and Tube Tagging	2-6
I	
Identification Plate Replacement	2-7
Indexing	iv
Injection Pump	
Replacement	3-50
Test	3-65
Inspection Instructions	2-2, 2-5
Intake Manifold Replacement	2-15
L	
Lubrication Instructions	2-6
M	
Maintenance Allocation Chart	B-4
Maintenance Forms, Records, and Reports	1-1
Maintenance Functions	B-1
Maintenance Procedures, Direct Support and General Support	
■ Auxiliary Drive Adapter Replacement	3-14.1
Camshaft Repair	3-40
Crankcase Repair	3-20

SUBJECT	PAGE
M (continued)	
Crankshaft and Bearings Repair	3-26
Cylinder Heads Repair	3-15
Deep Oil Pan and Gasket Replacement (UOC: APJ)	3-48.1
Filler Neck Replacement (UOC: APP)	3-46
Flywheel and Housing Replacement	3-28
Fuel Injector Replacement	3-48.2
Governor Control Assembly Repair	3-54
Injection Pump Replacement	3-50
Mounting Plates Replacement	3-12
Oil Pan and Gasket Replacement (UOC: APP)	3-47
Piston and Combustion Chamber Liner Repair	3-32
Rocker Arm Assemblies Repair	3-38
Maintenance Procedures, Unit	
Airflow Deflectors Replacement (UOC: APP)	2-24
Eyebolt Replacement (UOC: APP)	2-8
Filter Opening Cap Replacement (UOC: APP)	2-10
Filter Element Replacement (UOC: APP)	2-13
Fuel Pressure Pipe Assemblies and Return Fuel Hose Replacement	2-20
General	2-3
Identification Plate Replacement	2-7
Intake Manifold Replacement	2-15
Oil Switch Replacement	2-28
Oil Tube Assemblies Replacement	2-11
Rocker Arm Cover and O-Ring Replacement	2-9
Solenoid Replacement and Adjustment (UOC: APP)	2-30
Thermostatic Switch Replacement	2-29
Valve Vent Repair	2-18
Major Components, Location and Description of	1-5
Mandatory Replacement Parts List	F-2
Manual, How To Use	iv
Manuals	A-1
Materiel, Destruction of	1-1
Mounting Plates Replacement	3-12
N	
Notes, Warnings, and Cautions	v
O	
Oil Pan and Gasket Replacement (UOC: APP)	3-47
Oil Pressure Test	3-70
Oil Switch Replacement	2-28
Oil Tube Assemblies Replacement	2-11
Operation, Principles of	1-9

SUBJECT	PAGE
P	
Pamphlets and Circulars	A-2
Piston and Combustion Chamber Liner Repair	3-32
Principles of Operation	1-9
Pump Replacement, Injection	3-50
Pump Test, Injection	3-65
Q	
Quality Assurance	1-1
Quick Guide to Troubleshooting	3-2
R	
Records and Reports, Maintenance	1-1
References	A-1
Regulations	A-2
Repair Instructions	2-6
Repair Parts	2-1, C-1
Repair Parts and Special Tools List	
Abbreviations	C-7
Explanation of Columns	C-2
Repair Parts, How To Locate	C-7
Scope	C-1
Special Information	C-6
Return Fuel Hose and Fuel Pressure Pipes Replacement	2-20
Rocker Arm Assemblies Repair	3-38
Rocker Arm Cover and O-Ring Replacement	2-9
S	
Safety, Care, and Handling	1-3
Safety Summary	vi
Safety, Work	2-4
Service upon Receipt	2-2
■ Solenoid Replacement And Adjustment (UOC: APP)	2-30
Special Tools, TMDE, and Support Equipment	2-1
Storage or Shipment, Preparation for	1-1
T	
Tagging, Hose and Tube	2-6
Technical Manuals	A-1
Test, Measurement, and Diagnostic Equipment (TMDE)	2-1
Tests	
Cylinder Compression	3-56
Fuel Injector	3-66
Injection Pump	3-65
Oil Pressure	3-70

SUBJECT **PAGE**

T (continued)

Text and Illustrations iv

Thermostatic Switch Replacement 2-29

Tightening Metal Fasteners E-3

Tool Identification List G-1

Tools and Equipment, Common..... 2-1

Tools and Test Equipment Requirements..... B-6

Tools, Special..... 2-3

Torque Limits E-1

Torque Table, How To Use..... E-1

Torque Values 2-6

Troubleshooting, Direct Support and General Support

 Chart 3-3

 General..... 3-1

 Quick Guide to..... 3-2

Tube and Hose Tagging..... 2-6

V

Valve Adjustment..... 3-58

Valve-to-Piston Clearance Adjustment 3-40

Valve Vent Repair..... 2-18

W

Warnings, Cautions, and Notes v

Warning Summary a

Warranty Information 1-3

Work Safety 2-4

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?



THEN...JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 9-2815-250-24&P

PUBLICATION DATE

PUBLICATION TITLE

ENGINE ASSEMBLY, DIESEL, HATZ 2 G 40

BE EXACT. PIN-POINT WHERE IT IS

PAGE NO	PARA-GRAPH	FIGURE NO	TABLE NO
---------	------------	-----------	----------

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

FILL IN YOUR
UNITS ADDRESS



DEPARTMENT OF THE ARMY




OFFICIAL BUSINESS

NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 82 ROCK ISLAND IL

POSTAGE WILL BE PAID BY ROCK ISLAND ARSENAL

Director
Armament and Chemical Acquisition
and Logistics Activity
ATTN: AMSTA-AC-NML
Rock Island, IL 61201-9948




TEAR ALONG PERFORATED LINE



By Order of the Secretary of the Army:

DENNIS J. REIMER
General, United States Army
Chief of Staff

Official:



JOEL B. HUDSON
Administrative Assistant to the
Secretary of the Army
05170

DISTRIBUTION: To be distributed in accordance with the initial distribution number (IDN) 381080, requirements for TM 9-2815-250-24&P.

THE METRIC SYSTEM AND EQUIVALENTS

LINEAR MEASURE

1 Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
 1 Kilometer = 1000 Meters = 0.621 Miles

WEIGHTS

1 Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces
 1 Kilogram = 1000 Grams = 2.2 Lb.
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

SQUARE MEASURE

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches
 1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet
 1 Sq. Kilometer = 1,000 Sq. Meters = 0.386 Sq. Miles

CUBIC MEASURE

1 Cu. Centimeter = 1000 Cu. Millimeters = 0.06 Cu. Inches
 1 Cu. Meter = 1,000,000 Cu. Centimeters = 35.31 Cu. Feet

TEMPERATURE

$5/9 (^{\circ}\text{F} - 32) = ^{\circ}\text{C}$
 212° Fahrenheit is equivalent to 100° Celsius
 90° Fahrenheit is equivalent to 32.2° Celsius
 32° Fahrenheit is equivalent to 0° Celsius
 $(9/5 \times ^{\circ}\text{C}) + 32 = ^{\circ}\text{F}$

APPROXIMATE CONVERSION FACTORS

TO CHANGE	TO	MULTIPLY BY
Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	0.914
Miles	Kilometers	1.609
Square Inches	Square Centimeters	6.451
Square Feet	Square Meters	0.093
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	0.405
Cubic Feet	Cubic Meters	0.028
Cubic Yards	Cubic Meters	0.765
Fluid Ounces	Millimeters	29.573
Pints	Liters	0.473
Quarts	Liters	0.946
Gallons	Liters	3.785
Ounces	Grams	28.349
Pounds	Kilograms	0.454
Short Tons	Metric Tons	0.907
Pound–Feet	Newton–Meters	1.356
Pounds per Square Inch	Kilopascals	6.895
Miles per Gallon	Kilometers per Liter	0.425
Miles per Hour	Kilometers per Hour	1.609

TO CHANGE	TO	MULTIPLY BY
Centimeters	Inches	0.394
Meters	Feet	3.280
Meters	Yards	1.094
Kilometers	Miles	0.621
Square Centimeters	Square Inches	0.155
Square Meters	Square Feet	10.764
Square Meters	Square Yards	1.196
Square Kilometers	Square Miles	0.386
Square Hectometers	Acres	2.471
Cubic Meters	Cubic Feet	35.315
Cubic Meters	Cubic Yards	1.308
Milliliters	Fluid Ounces	0.034
Liters	Pints	2.113
Liters	Quarts	1.057
Liters	Gallons	0.264
Grams	Ounces	0.035
Kilograms	Pounds	2.205
Metric Tons	Short Tons	1.102
Newton–Meters	Pound–Feet	0.738
Kilopascals	Pounds per Square Inch	0.145
Kilometers per Liter	Miles per Gallon	2.354
Kilometers per Hour	Miles per Hour	0.621

