

TECHNICAL MANUAL
AVIATION UNIT AND
AVIATION INTERMEDIATE
MAINTENANCE MANUAL

ENGINE, GAS TURBINE
MODEL T55-L-714
NSN 2840-01-353-7635

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY
1 DECEMBER 1994

CHANGE
NO. 1

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 31 January 2003

TECHNICAL MANUAL

Aviation Unit and Aviation Intermediate
Maintenance Manual

ENGINE, GAS TURBINE, MODEL T55-L-714
(NSN 2840-01-353-7635)

OZONE DEPLETING CHEMICAL INFORMATION

This document has been reviewed for the presence of class I ozone depleting chemicals. As of the basic, dated 1 December 1994, all references to Class I ozone depleting chemicals have been removed from this document by substitution with chemicals by the Engineering, Environment, and Logistics Oversight Office that do not cause atmospheric ozone depletion.

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 1-2840-252-23-3, 1 December 1994, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

--

i and ii

A-1 and A-2

C-3 and C-4

C-7 and C-8(blank)

G-123 and G-124

Index-3 and Index-4

Insert pages

A and B

i and ii

A-1 and A-2

C-3 and C-4

C-7 and C-8(blank)


G-123 and G-124

Index-3 and Index-4

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official: _____



JOEL B. HUDSON
*Administrative Assistant to the
Secretary of the Army*

0233002

ERIC K. SHINSEKI
*General, United States Army
Chief of Staff*

DISTRIBUTION:

To be distributed in accordance with Initial Distribution Number (IDN) 313466, requirements for TM 1-2840-252-23-3.

LIST OF EFFECTIVE PAGES

Insert latest changed pages; dispose of superseded pages in accordance with regulations.

NOTE: On a changed page, the portion of the text affected by the latest change is indicated by a vertical line, or other change symbol, in the outer margin of the page. Changes to illustrations are indicated by miniature pointing hands. Changes to wiring diagrams are indicated by shaded areas.

Dates of issue for original and changed pages are:

Original	1 Dec 1994	Change 1	31 Jan 2003
Page No.	*Change No.	Page No.	*Change No.
A and B Blank	1	9-3 through 9-12	0
i	1	A-1	1
ii through iv	0	A-2 through C-2	0
6-183 through 6-265	0	C-3	1
6-266 blank	0	C-4 through C-6	0
7-1 through 7-57	0	C-7	1
7-58 blank	0	C-8 blank	0
7-59 through 7-161	0	D-1 through D-3	0
7-162 blank	0	D-4 blank	0
8-1 through 8-5	0	Ei through E-25	0
8-6 blank	0	E-26 blank	0
8-7 through 8-25	0	F-1 through F-3	0
8-26 blank	0	F-4 blank	0
8-27 through 8-61	0	G-i through G-122	0
8-62 blank	0	G-123	1
8-63 through 8-265	0	G-124 through Index 2	0
8-266 blank	0	Index 3 and Index 4	1
8-267 through 9-1	0	Index 5 through Index 34	0
9-2 blank	0		

*Zero in this column indicates an original page.

Technical Manual
 NO. 1-2840-252-23

HEADQUARTERS
 DEPARTMENT OF THE ARMY
 WASHINGTON D.C., 1 December 1994

TECHNICAL MANUAL
 Aviation Unit and Aviation Intermediate Maintenance Manual

ENGINE, GAS TURBINE
 MODEL T55-L-714
 (NSN 2840-01-353-7635)

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes, or if you know of a way to improve these procedures, please let us know. Mail your letter or DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual directly to: Commander, US Army Aviation and Missile Command, ATTN: AMSAM-MMC-MA-NP, Redstone Arsenal, AL 35898-5000. A reply will be furnished to you. You may also provide DA Form 2028 information to AMCOM via e-mail, fax, or the World Wide Web. Our fax number is: DSN788-6546. Our e-mail address is: 2028@redstone.army.mil. Instructions for sending an electronic 2028 may be found at the back of this manual immediately preceding the hard copy 2028. For the World Wide Web use: <https://amcom2028.redstone.army.mil>.

OZONE DEPLETING CHEMICAL INFORMATION

This document has been reviewed for the presence of class I ozone depleting chemicals. As of the basic, dated 1 December 1994, all references to Class I ozone depleting chemicals have been removed from this document by substitution with chemicals by the Engineering, Environment, and Logistics Oversight Office that do not cause atmospheric ozone depletion.

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

NOTE

This manual is printed in three volumes as follows:
 TM 1-2840-252-23-1, consisting of Table of Contents, Chapter 1, Chapter 2, pages 2-1 through 2-322
 TM 1-2840-252-23-2, consisting of Table of Contents, Chapter 2, pages 2-323 through 2-425/(2-426 blank), Chapter 3, Chapter 4, Chapter 5, Chapter 6, pages 6-1 through 6-182.
 TM 1-2848-252-23-3, consisting of Table of Contents, Chapter 6, pages 6-183 through 6-265/(6-266 blank), Chapter 7, Chapter 8, and Chapter 9, Appendix A through Appendix G, and an Alphabetical Index. The Appendices and Index are applicable to Volumes 1 through 3.

TABLE OF CONTENTS

	PAGE
HOW TO USE THIS MANUAL	VII
CHAPTER I. INTRODUCTION	1-1
Chapter Overview	1-1
Section I General Information	1-1
Section II Equipment Description and Data	1-3
Section III Principles of Operation	1-13
Section IV Repair Parts; Special Tools; Test, Measurement, and Diagnostic Equipment (TMDE); and Support Equipment	1-47
Section V Service Upon Receipt	1-49
Section VI Hoisting	1-111
Section VII Troubleshooting	1-121
Section VIII Servicing	1-297
Section IX Preventive Maintenance Checks and Services	1-317
Section X Maintenance Procedures	1-487
Section XI Preparation for Storage and Shipment	1-509
Section XII Standard Torque Limits	1-567
Section XIII Standard Practices and Procedures	1-571

TABLE OF CONTENTS (Continued)

	PAGE	
CHAPTER 2	COMPRESSOR SECTION-MAINTENANCE INSTRUCTIONS.....	2-1
	Chapter Overview	2-1
Section I	Interstage Air-Bleed Actuator	2-5
Section II	Compressor bleed Band.....	2-37
Section III	Anti-Icing Air Gallery Cover.....	2-47
Section IV	Compressor Housing.....	2-63
Section V	Stator Vane Assemblies	2-181
Section VI	Compressor Rotor Blades	2-235
Section VII	Air Diffuser Assembly.....	2-321
Section VIII	Output Shaft Seal and Housing Assembly.....	2-325
Section IX	Inlet Housing Cover Assembly	2-345
Section X	Air Inlet Housing Assembly.....	2-355
Section XI	T1 Temperature Sensor	2-359
Section XII	Air lines.....	2-367
CHAPTER 3	COMBUSTION SECTION-MAINTENANCE INSTRUCTIONS	3-1
	Chapter Overview	3-3
Section I	Fuel Drain Valve	3-3
Section II	Combustion Section and Power Turbine.....	3-9
Section III	Combustion Section	3-117
Section IV	Combustion Chamber Vane Assembly	3-135
Section V	Combustion Chamber Liner	3-145
Section VI	Combustion Chamber Housing.....	3-171
CHAPTER 4	TURBINESECTION-MAINTENANCE INSTRUCTIONS.....	4-1
	Chapter Overview	4-5
Section I	Thermocouple Jumper Lead.....	4-5
Section II	Left- and Right-Hand Bus Bar Assemblies.....	4-25
Section III	Fireshield Assembly	4-55
Section IV	Fireshield Section	4-65
Section V	Thermocouple Harness Assemblies	4-81
Section VI	Third Turbine Nozzle and Support.....	4-107
Section VII	Fourth Stage Power Turbine Rotor.....	4-131
Section VIII	No . 4 and 5 Bearing Package.....	4-165
Section IX	Fourth Stage Power Turbine Nozzle.....	4-247
Section X	Third Stage Power Turbine Rotor	4-279
Section XI	Second Turbine Disc Assembly	4-289
Section XII	Second Turbine Nozzle, Spacer, Case, and Bumper.....	4-313
Section XIII	First Turbine Disc Assembly.....	4-361
Section XIV	First Turbine Rotor Case	4-389
Section XV	Field Replacement First and Second Turbine Disc Assembly.....	4-407
Section XVI	Tailpipe Assembly.....	4-415

TABLE OF CONTENTS (Continued)

	PAGE	
CHAPTER 5	ACCESSORY GEAR SECTION-MAINTENANCE INSTRUCTIONS	5-1
	Chapter Overview	5-1
Section I	Accessory Gearbox Assembly	5-3
Section II	PT Speed Pickup	5-41
Section III	PT Speed Pickup Drive Assembly	5-49
Section IV	Starter Drive Assembly	5-57
Section V	Overspeed Drive and Outlet Cover Assembly	5-75
CHAPTER 6	FUEL SYSTEM-MAINTENANCE INSTRUCTIONS	6-1
	Chapter Overview	6-1
Section I	Hydromechanical Assembly (HMA)	6-5
Section II	Hydromechanical Assembly (HMA) - Preparation for Storage or Shipment	6-27
Section III	Fuel Boost Pump Assembly	6-35
Section IV	Fuel Boost Pump Assembly - Preparation for Storage or Shipment	6-47
Section V	Left- and Right-Hand Fuel Manifold Assemblies	6-49
Section VI	Primer Tube Assembly	6-89
Section VII	Start Fuel Nozzles	6-97
Section VIII	Main Fuel Filter and Bracket	6-103
Section IX	In-Line Fuel Filter Assembly	6-121
Section X	Pressurizing Valve	6-135
Section XI	Flow Divider and Bracket	6-143
Section XII	Fuel Check Valve	6-153
Section XIII	Overspeed Solenoid Valve	6-159
Section XIV	Starting Fuel Solenoid Valve	6-167
Section XV	Fuel Lines	6-177
CHAPTER 7	ELECTRICAL AND IGNITION SYSTEMS-MAINTENANCE INSTRUCTIONS	7-1
	Chapter Overview	7-1
Section I	Ignition Coil and Cable Assembly	7-3
Section II	Spark Igniters	7-59
Section III	Ignition Exciter	7-71
Section IV	Primary Electrical Harness Assembly	7-81
Section V	Reversionary Electrical Harness Assembly	7-109
Section VI	Accessory Electrical Harness Assembly	7-137

TABLE OF CONTENTS (Continued)

	PAGE
CHAPTER 8 LUBRICATION SYSTEM-MAINTENANCE INSTRUCTIONS.....	8-1
Chapter Overview	8-1
Section I Main Oil Pump, Speed Pickup Drive Assembly, Scavenge Oil Screen, and Related Parts	8-7
Section II Gas Producer Speed Pickup	8-27
Section III Oil Cooler Assembly.....	8-35
Section IV Flow Programming Valve	8-53
Section V Oil Temperature Transmitter	8-63
Section VI Oil Filler Assembly and Oil Filler Strain	8-69
Section VII Oil Filter Cover Assembly and Oil Filter Element	8-83
Section VIII Dual Chip Detector.....	8-91
Section IX Oil Lines.....	8-107
Section X Starter Gearbox Filter	8-237
Section XI No . 2 Bearing Pressure Oil Connector.....	8-243
Section XII No . 2 Bearing Pressure Oil Strainer.....	8-249
Section XIII No . 4 and 5 Bearing Filter	8-255
Section XIV Oil Drain Cock.....	8-267
Section XV Chip Detector	8-273
Section XVI Oil Level Detector	8-283
Section XVII Oil Level Float Assembly.....	8-309
CHAPTER 9 TORQUEMETER SYSTEM-MAINTENANCE INSTRUCTIONS	9-1
Chapter Overview	9-1
Section I Torquemeter Sensor	9-3
APPENDIX A REFERENCES	A-1
APPENDIX B MAINTENANCE ALLOCATION CHART.....	B-1
APPENDIX C EXPENDABLE SUPPLIES AND MATERIALS LIST	C-1
APPENDIX D WIRING DIAGRAMS	D-1
APPENDIX E ILLUSTRATED LIST OF MANUFACTURED ITEMS	E-1
APPENDIX F ABBREVIATIONS	F-1
APPENDIX G DECU FAULT ISOLATION.....	G-1
GLOSSARY	GLOSSARY-1
SUBJECT INDEX.....	INDEX-1

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**


Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE


6-64 REMOVE HOSE ASSEMBLY (HMA TO OIL COOLER) (Continued)**6-64**

1. Cut and remove tiedown straps and lift hose assembly (1) out of cushions (2, 3, and 4).
2. Remove nut (5), bolt (6), and clamp (7).

**GO TO NEXT PAGE**

6-64 REMOVE HOSE ASSEMBLY (HMA TO OIL COOLER) (Continued)**6-64**

3. Remove two nuts (8) and clamps (9 and 10) and two nuts (11) and clamps (12 and 13).
4. Disconnect and remove hose assembly (1).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All


Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

Tiedown Strap (3)

Personnel Required:


Aircraft Powerplant Repairer

Aircraft Powerplant Inspector



GO TO NEXT PAGE


1. Install hose assembly (1) on reducers (2 and 3).



GO TO NEXT PAGE


6-65 INSTALL HOSE ASSEMBLY (HMA TO OIL COOLER) (Continued)**6-65**

2. Install clamps (4 and 5) and two nuts (6), and clamps (7 and 8) and two nuts (9).



GO TO NEXT PAGE

3. Install clamp (10), bolt (11), and nut (12).
4. Install hose assembly (1) into cushions (13, 14, and 15) and secure with tiedown straps.

**INSPECT****FOLLOW-ON MAINTENANCE:**

None

END OF TASK

6-66 REMOVE HOSE ASSEMBLY (IN-LINE FUEL FILTER TO OVERSPEED SOLENOID VALVE)

6-66

INITIAL SETUP

*General Safety Instructions:***Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

WARNING


Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

**GO TO NEXT PAGE**


6-66 REMOVE HOSE ASSEMBLY (IN-LINE FUEL FILTER TO OVERSPEED SOLENOID VALVE) (Continued)

6-66

1. Remove nut (1), screw (2), and clamp (3).



2. Disconnect and remove hose assembly (4).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

6-67 INSTALL HOSE ASSEMBLY (IN-LINE FUEL FILTER TO OVERSPEED SOLENOID VALVE)

6-67

INITIAL SETUP

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Applicable Configurations:

All

Tools:


Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

None

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector




GO TO NEXT PAGE

6-67 INSTALL HOSE ASSEMBLY (IN-LINE FUEL FILTER TO OVERSPEED SOLENOID VALVE) (Continued)

6-67


1. **Install hose assembly (1) on reducers (2 and 3).**



2. **Install clamp (4) on hose assembly (1), and install screw (5) and nut (6).**

INSPECT

FOLLOW-ON MAINTENANCE:
None



END OF TASK

6-68 REMOVE HOSE ASSEMBLY (OVERSPEED SOLENOID VALVE TO PRESSURIZING VALVE)

6-68

INITIAL SETUP

*General Safety Instructions:***Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

WARNING


Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take Internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE

6-68 REMOVE HOSE ASSEMBLY (OVERSPEED SOLENOID VALVE TO PRESSURIZING VALVE) (Continued)**6-68**

- 1 Disconnect and remove hose assembly (1).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

6-69 INSTALL HOSE ASSEMBLY (OVERSPEED SOLENOID VALVE TO PRESSURIZING VALVE)

6-69

INITIAL SETUP

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Applicable Configurations:

All

Materials:


None

Tools

Powerplant Mechanic's Tool Kit
NSN 5180-00-323-4944

Personnel Required:


Aircraft Powerplant Repairer
Aircraft Powerplant Inspector



GO TO NEXT PAGE

6-69 INSTALL HOSE ASSEMBLY (OVERSPEED SOLENOID VALVE TO PRESSURIZING VALVE)**6-69**

1. Install hose assembly (1) on flow divider (2) and reducer (3).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

6-70 REMOVE HOSE ASSEMBLY (PRESSURIZING VALVE TO FUEL FLOW DIVIDER RETURN TEE)

6-70

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**


Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE

6-70 REMOVE HOSE ASSEMBLY (PRESSURIZING VALVE TO FUEL FLOW DIVIDER RETURN TEE) (Continued)**6-70**

1. Disconnect and **remove hose assembly (1)**.



FOLLOW-ON MAINTENANCE:
None

END OF TASK

6-71 INSTALL HOSE ASSEMBLY (PRESSURIZING VALVE TO FUEL FLOW DIVIDER RETURN TEE)

6-71

INITIAL SETUP

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Applicable Configurations:

All

Tools:


Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

None

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector




GO TO NEXT PAGE

**6-71 INSTALL HOSE ASSEMBLY (PRESSURIZING VALVE TO FUEL FLOW
DIVIDER RETURN TEE) (Continued)**

6-71

1. Install hose assembly (1) on tee (2) and reducer (3).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

6-72 REMOVE HOSE ASSEMBLY (FUEL BOOST PUMP TO MAIN FUEL FILTER)

6-72

INITIAL SETUP

*General Safety Instructions:***Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Open-End Wrench, 1-Inch
Container, 1 Quart**Materials:**



Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

WARNING

Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.




B-6-60/1


GO TO NEXT PAGE

6-72 REMOVE HOSE ASSEMBLY (FUEL BOOST PUMP TO MAIN FUEL FILTER) (Continued)

1 Remove nut (1), screw (2), and clamp (3).




2. Remove nut (4), screw (5), and clamp (6).




GO TO NEXT PAGE

6-72 REMOVE HOSE ASSEMBLY (FUEL BOOST PUMP TO MAIN FUEL FILTER) (Continued)

3. Remove nut (7), screw (8), and clamp (9).



4. Remove nut (10), screw (11), and clamp (12).




GO TO NEXT PAGE

6-72 REMOVE HOSE ASSEMBLY (FUEL BOOST PUMP TO MAIN FUEL FILTER) (Continued)

6-72

5. Disconnect and **remove hose assembly (13)** using 1-inch open-end wrench.



FOLLOW-ON MAINTENANCE:
None

END OF TASK

6-73 INSTALL HOSE ASSEMBLY (FUEL BOOST PUMP TO MAIN FUEL FILTER)

6-73

INITIAL SETUP

Materials:

None


Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114Crowfoot Attachment, 1-InchTorque Wrench, 700-1600 Inch-Pounds**Personnel Required:**

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector




GO TO NEXT PAGE


6-73 INSTALL HOSE ASSEMBLY (FUEL BOOST PUMP TO MAIN FUEL FILTER) (Continued)

6-73

1. **Install hose assembly (1)** on nipples (2 and 3), using 1-inch crowfoot attachment.



2. **Install clamp (4)** on hose assembly (1), and install screw (5) and nut (6).




GO TO NEXT PAGE


6-73 INSTALL HOSE ASSEMBLY (FUEL BOOST PUMP TO MAIN FUEL FILTER) (Continued)

6-73

3. **Install clamp (7)** on hose assembly (1), and install screw (8) and nut (9).




4. **Install clamp (10)** on hose assembly (1), and install screw (11) and nut (12).



GO TO NEXT PAGE

6-73 INSTALL HOSE ASSEMBLY (FUEL BOOST PUMP TO MAIN FUEL)**6-73**

5. Install clamp (13) on hose assembly (1), and install screw (14) and nut (15).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

6-74 REMOVE HOSE ASSEMBLY (FUEL FLOW DIVIDER TO FUEL CHECK VALVE)

6-74

INITIAL SETUP

*General Safety Instructions:***Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

WARNING


Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE


6-74 REMOVE HOSE ASSEMBLY (FUEL FLOW DIVIDER TO FUEL CHECK)**6-74**

1. Remove nut (1), screw (2), and clamp (3).

**GO TO NEXT PAGE**

6-74 REMOVE HOSE ASSEMBLY (FUEL FLOW DIVIDER TO FUEL CHECK VALVE) (Continued)**6-74**


- 2 Remove nut (4), screw (5), and clamp (6).



GO TO NEXT PAGE

6-74 REMOVE HOSE ASSEMBLY (FUEL FLOW DIVIDER TO FUEL CHECK VALVE (Continued)**6-74**

3. Disconnect and remove hose assembly (7).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

6-75 INSTALL HOSE ASSEMBLY (FUEL FLOW DIVIDER TO FUEL CHECK VALVE)

6-75

INITIAL SETUP


Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Applicable Configurations:**

All

Materials:

None


Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Personnel Required:**Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

**GO TO NEXT PAGE**

6-75 INSTALL HOSE ASSEMBLY (FUEL FLOW DIVIDER TO FUEL CHECK VALVE) (CONTINUED)


6-75

1. Install hose assembly (1) on check valve (2) and tee (3).

**GO TO NEXT PAGE**

6-75 INSTALL HOSE ASSEMBLY (FUEL FLOW DIVIDER TO FUEL CHECK VALVE) (Continued)**6-75**

2. Install clamp (4), screw (5), and nut (6).




B-6-63 3

GO TO NEXT PAGE

6-75 INSTALL HOSE ASSEMBLY (FUEL FLOW DIVIDER TO FUEL CHECK VALVE) (Continued)

6-75

3. Install clamp (7), screw (8), and nut (9).



B-6-63 4

INSPECT

FOLLOW-ON MAINTENANCE:
None

END OF TASK

**6-76 REMOVE HOSE ASSEMBLY (FUEL FLOW DIVIDER LEFT SIDE
PRIMARY TO MANIFOLD ASSEMBLY)**

6-76

INITIAL SETUP

*General Safety Instructions:***Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

WARNING


Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin, and do not take internally. Wash contacted areas of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE

**6-76 REMOVE HOSE ASSEMBLY (FUEL FLOW DIVIDER LEFT SIDE
PRIMARY TO MANIFOLD ASSEMBLY) (Continued)****6-76**

1. Disconnect and remove hose assembly (1).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

**6-77 INSTALL HOSE ASSEMBLY (FUEL FLOW DIVIDER LEFT SIDE
PRIMARY TO MANIFOLD ASSEMBLY)**

6-77


INITIAL SETUP

Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Applicable Configurations**

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Materials:**

None


Personnel RequiredAircraft Powerplant Repairer
Aircraft Powerplant Inspector

GO TO NEXT PAGE

**6-77 INSTALL HOSE ASSEMBLY (FUEL FLOW DIVIDER LEFT SIDE
PRIMARY TO MANIFOLD ASSEMBLY) (Continued)**

6-77

1. Install hose assembly (1) on nipple (2) and elbow (3).

**INSPECT**

FOLLOW-ON MAINTENANCE:

None

END OF TASK

**6-78 REMOVE HOSE ASSEMBLY (FUEL FLOW DIVIDER RIGHT SIDE
PRIMARY TO MANIFOLD ASSEMBLY)**

6-78

INITIAL SETUP

*General Safety Instructions:***Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

WARNING


Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention for eyes.



GO TO NEXT PAGE

**6-78 REMOVE HOSE ASSEMBLY (FUEL FLOW DIVIDER RIGHT SIDE
PRIMARY TO MANIFOLD ASSEMBLY) (Continued)****6-78**

1. Disconnect and remove hose assembly (1).



B-6-66 2

FOLLOW-ON MAINTENANCE:
None

END OF TASK

**6-79 INSTALL HOSE ASSEMBLY (FUEL FLOW DIVIDER RIGHT SIDE
PRIMARY TO MANIFOLD ASSEMBLY)**

6-79


INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**


None

Personnel Required:Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

GO TO NEXT PAGE

**6-79 INSTALL HOSE ASSEMBLY (FUEL FLOW DIVIDER RIGHT SIDE
PRIMARY TO MANIFOLD ASSEMBLY) (Continued)****6-79**

1. Install hose assembly (1) on nipple (2) and elbow (3).

**INSPECT****FOLLOW-ON MAINTENANCE:**

None

END OF TASK

**6-80 REMOVE HOSE ASSEMBLY (FUEL FLOW DIVIDER LEFT SIDE
SECONDARY TO MANIFOLD ASSEMBLY)**

6-80

INITIAL SETUP

*General Safety Instructions:***Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

WARNING

Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical for eyes




GO TO NEXT PAGE


**6-80 REMOVE HOSE ASSEMBLY (FUEL FLOW DIVIDER LEFT SIDE
SECONDARY TO MANIFOLD ASSEMBLY) (Continued)**

6-80

1. Remove nut (1), screw (2) and clamp (3).



2. Disconnect and remove hose assembly (4).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

**6-81 INSTALL HOSE ASSEMBLY (FUEL FLOW DIVIDER LEFT SIDE
SECONDARY TO MANIFOLD ASSEMBLY)**

6-81

INITIAL SETUP

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Applicable Configurations

All

Materials:


None

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector




GO TO NEXT PAGE


6-81 INSTALL HOSE ASSEMBLY (FUEL FLOW DIVIDER LEFT SIDE SECONDARY TO MANIFOLD ASSEMBLY) (Continued)

6-81

1. Install hose assembly (1) on reducer (2) and elbow (3).



2. Install clamp (4), screw (5), and nut (6).



INSPECT

FOLLOW-ON MAINTENANCE:
None

END OF TASK

**6-82 REMOVE HOSE ASSEMBLY (FUEL FLOW DIVIDER RIGHT SIDE
SECONDARY TO MANIFOLD ASSEMBLY)**

6-82

INITIAL SETUP

*General Safety Instructions:***Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

WARNING


Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE


**6-82 REMOVE HOSE ASSEMBLY (FUEL FLOW DIVIDER RIGHT SIDE
SECONDARY TO MANIFOLD ASSEMBLY) (Continued)****6-82**

1. Remove lockwire, screw (1), and clamp (2).

**GO TO NEXT PAGE**

**6-82 REMOVE HOSE ASSEMBLY (FUEL FLOW DIVIDER RIGHT SIDE
SECONDARY TO MANIFOLD ASSEMBLY) (Continued)****6-82**

2. Disconnect and **remove hose assembly (3)**.



FOLLOW-ON MAINTENANCE:
None

END OF TASK

**6-83 INSTALL HOSE ASSEMBLY (FUEL FLOW DIVIDER RIGHT SIDE
SECONDARY TO MANIFOLD ASSEMBLY)****6-83**


INITIAL SETUP

Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Applicable Configurations**

All


Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Materials:**

Lockwire (E33)

Personnel Required:Aircraft Powerplant Repairer
Aircraft Powerplant Inspector**GO TO NEXT PAGE**


**6-83 INSTALL HOSE ASSEMBLY (FUEL FLOW DIVIDER RIGHT SIDE
SECONDARY TO MANIFOLD ASSEMBLY (Continued))****6-83**

1. Install hose assembly (1) on reducer (2) and elbow (3).

**GO TO NEXT PAGE**

**6-83 INSTALL HOSE ASSEMBLY (FUEL FLOW DIVIDER RIGHT SIDE
SECONDARY TO MANIFOLD ASSEMBLY) (Continued)****6-83**

2. Install clamp (4) and screw (5). Lockwire screw (5). Use lockwire (E33).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

*General Safety Instructions:***Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Open-End Wrench, 1-Inch

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

WARNING

Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.




B-6-72.1


GO TO NEXT PAGE

6-84 REMOVE HOSE ASSEMBLY (MAIN FUEL FILTER TO HMA)
(Continued)

1. Remove nuts (1), screws (2), and clamps (3) from hose assembly (4).



2. Remove nut (5), screw (6), and clamp (7) from hose assembly (4).




GO TO NEXT PAGE

6-84 REMOVE HOSE ASSEMBLY (MAIN FUEL FILTER TO HMA)
(Continued)

6-84

3. Disconnect and remove hose assembly (4) using 1-inch open-end wrench.



FOLLOW-ON MAINTENANCE:
None

END OF TASK

6-85 INSTALL HOSE ASSEMBLY (MAIN FUEL FILTER TO HMA)**6-85**


INITIAL SETUP

Torque Wrench 700-1600 Inch-Pounds
Crowfoot Attachment, 1-inch**Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool Kit
NSN 5180-00-323-4944
Technical Inspection Tool Kit
NSN 5180-00-323-5114**Materials**


None

Personnel Required:Aircraft Powerplant Repairer
Aircraft Powerplant Inspector**GO TO NEXT PAGE**


**6-85 INSTALL HOSE ASSEMBLY (MAIN FUEL FILTER TO HMA)
(Continued)**

6-85

1. **Install hose assembly (1)** on unions (2 and 3) using 1-inch crowfoot attachment.




2. **Install clamp (4)** on hose assembly (1), and install screw (5) and nut (6).

**GO TO NEXT PAGE**

**6-85 INSTALL HOSE ASSEMBLY (MAIN FUEL FILTER TO HMA)
(Continued)****6-85**

3. Install clamps (7) onto hose assembly (1), and install screws (8) and nuts (9).

**INSPECT**

FOLLOW-ON MAINTENANCE:

None

END OF TASK

6-86 REMOVE HOSE ASSEMBLY (HMA TO STARTING FUEL SOLENOID VALVE)

6-86

INITIAL SETUP

*General Safety Instructions:***Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

WARNING

Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.




GO TO NEXT PAGE


6-86 REMOVE HOSE ASSEMBLY (HMA TO S3ARTING FUEL SOLENOID VALVE) (Continued)

6-86

1. Remove nut (1), screw (2), and clamp (3).



2. Remove nut (4), screw (5), and clamp (6).




GO TO NEXT PAGE

6-86 REMOVE HOSE ASSEMBLY (HMA TO STARTING FUEL SOLENOID VALVE) (Continued)

6-86

3. Disconnect and remove hose assembly (7).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

6-87 INSTALL HOSE ASSEMBLY (HMA TO STARTING FUEL SOLENOID VALVE)

6-87


INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

None


Personnel Required:Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

GO TO NEXT PAGE


6-87 INSTALL HOSE ASSEMBLY (HMA TO STARTING FUEL SOLENOID VALVE) (Continued)

6-87

1. Install hose assembly (1) on elbow (2) and nipple (3).




2. Install clamp (4), screw (5), and nut (6).



GO TO NEXT PAGE

6-87 INSTALL HOSE ASSEMBLY (HMA TO STARTING FUEL SOLENOID VALVE) (Continued)**6-87**

3. Install clamp (7), screw (8), and nut (9).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

6-88 REMOVE HOSE ASSEMBLY (STARTING FUEL SOLENOID VALVE TO TUBE ASSEMBLY)

6-88

INITIAL SETUP

*General Safety Instructions:***Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

WARNING


Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results. Get medical attention for eyes

**GO TO NEXT PAGE**


6-88 REMOVE HOSE ASSEMBLY (STARTING FUEL SOLENOID VALVE TO TUBE ASSEMBLY) (Continued)

6-88

1. Remove nut (1), screw (2), and clamp (3).



2. Remove lockwire, screw (4) and clamp (5).




GO TO NEXT PAGE


6-88 REMOVE HOSE ASSEMBLY (STARTING FUEL SOLENOID VALVE TO TUBE ASSEMBLY) (Continued)

6-88

3. Remove two nuts (6) and clamps (7 and 8).



4. Remove two nuts (9) and clamps (10 and 11).




GO TO NEXT PAGE

6-88 REMOVE HOSE ASSEMBLY (STARTING FUEL SOLENOID VALVE TO TUBE ASSEMBLY) (Continued)

6-88

5. Disconnect and remove hose assembly (12).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

6-89 INSTALL HOSE ASSEMBLY (STARTING FUEL SOLENOID VALVE TO TUBE ASSEMBLY)

6-89


INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

Lockwire (E33)


Personnel Required:Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

GO TO NEXT PAGE


6-89 INSTALL HOSE ASSEMBLY (STARTING FUEL SOLENOID VALVE TO TUBE ASSEMBLY) (Continued)

6-89

1. Install hose assembly (1) on starting fuel solenoid valve (2) and tube assembly (3).



2. Install clamps (4 and 5) and two nuts (6).




GO TO NEXT PAGE


6-89 INSTALL HOSE ASSEMBLY (STARTING FUEL SOLENOID VALVE TO TUBE ASSEMBLY) (Continued)

6-89

3. Install clamps (7 and 8) and two nuts (9).




4. Install clamp (10) and screw (11). Lockwire screw (11). Use lockwire (E33).



GO TO NEXT PAGE

6-89 INSTALL HOSE ASSEMBLY (STARTING FUEL SOLENOID VALVE TO TUBE ASSEMBLY) (Continued)**6-89**

5. Install clamp (12), screw (13), and nut (14).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

6-90 REMOVE TUBE ASSEMBLY (HOSE ASSEMBLY TO PRIMER TUBE ASSEMBLY)

6-90

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**


Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE

6-90 REMOVE TUBE ASSEMBLY (HOSE ASSEMBLY TO PRIMER TUBE ASSEMBLY) (Continued)**6-90**

1. Remove three nuts (1) and clamp (2).




B-6-78 2

GO TO NEXT PAGE

6-90 REMOVE TUBE ASSEMBLY (HOSE ASSEMBLY TO PRIMER TUBE ASSEMBLY) (Continued)**6-90**

2. Remove two nuts (3) and clamps (4 and 5).




B-6-783

GO TO NEXT PAGE

6-90 REMOVE TUBE ASSEMBLY (HOSE ASSEMBLY TO PRIMER TUBE ASSEMBLY) (Continued)**6-90**


3. Remove lockwire, screw (6) and clamp (7).



GO TO NEXT PAGE

6-90 REMOVE TUBE ASSEMBLY (HOSE ASSEMBLY TO PRIMER TUBE ASSEMBLY) (Continued)**6-90**

4. Disconnect and remove tube assembly (8).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Applicable Configurations:

All

Tools:



Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

Lockwire (E33)


Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector



GO TO NEXT PAGE

1. Install tube assembly (1) on hose assembly (2) and primer tube assembly (3).




GO TO NEXT PAGE


6-91 INSTALL TUBE ASSEMBLY (HOSE ASSEMBLY TO PRIMER TUBE ASSEMBLY) (Continued)

6-91

2. Install clamp (4) on tube assembly (1) and install screw (5). Lockwire screw (5). Use lockwire (E33).


**GO TO NEXT PAGE**

3. Install two clamps (6 and 7) and two nuts (8).



GO TO NEXT PAGE

4. Install clamp (9) and three nuts (10).



INSPECT

FOLLOW-ON MAINTENANCE:

None

END OF TASK

CHAPTER 7

ELECTRICAL AND IGNITION SYSTEMS -
MAINTENANCE INSTRUCTIONSCHAPTER
OVERVIEW

This chapter contains maintenance procedures for the electrical and ignition systems. It is divided into the following sections and tasks:

<u>SECTION</u>	<u>TASK NO.</u>	<u>TITLE</u>	<u>PAGE</u>
I		IGNITION COIL AND CABLE ASSEMBLY	
	7-1	Remove Ignition Coil and Cable Assembly	7-3
	7-2	Clean Ignition Coil and Cable Assembly	7-26
	7-3	Inspect Ignition Coil and Cable Assembly	7-28
	7-4	Repair Ignition Coil and Cable Assembly	7-31
	7-5	Install Ignition Coil and Cable Assembly	7-36
II		SPARK IGNITERS	
	7-6	Remove Spark Igniters	7-59
	7-7	Clean Spark Igniters	7-62
	7-8	Inspect Spark Igniters	7-63
	7-9	Repair Spark Igniters	7-64
	7-10	Install Spark Igniters	7-65
III		IGNITION EXCITER	
	7-11	Remove Ignition Exciter	7-71
	7-12	Clean Ignition Exciter	7-75
	7-13	Inspect Ignition Exciter	7-76
	7-14	Repair Ignition Exciter	7-77
	7-15	Install Ignition Exciter	7-78
IV		PRIMARY ELECTRICAL HARNESS ASSEMBLY	
	7-16	Remove Primary Electrical Harness Assembly	7-81
	7-17	Clean Primary Electrical Harness Assembly	7-85
	7-18	Inspect Primary Electrical Harness Assembly	7-87
	7-19	Repair Primary Electrical Harness Assembly	7-89
	7-20	Test Primary Electrical Harness Assembly	7-90
	7-21	Install Primary Electrical Harness Assembly	7-105

<u>SECTION</u>	<u>TASK NO.</u>	<u>TITLE</u>	<u>PAGE</u>
V		REVERSIONARY ELECTRICAL HARNESS ASSEMBLY	
	7-22	Remove Reversionary Electrical Harness Assembly	7-109
	7-23	Clean Reversionary Electrical Harness Assembly	7-115
	7-24	Inspect Reversionary Electrical Harness Assembly	7-116
	7-25	Repair Reversionary Electrical Harness Assembly	7-118
	7-26	Test Reversionary Electrical Harness Assembly	7-119
	7-27	Install Reversionary Electrical Harness Assembly	7-131
VI		ACCESSORY ELECTRICAL HARNESS ASSEMBLY	
	7-28	Remove Accessory Electrical Harness Assembly	7-137
	7-29	Clean Accessory Electrical Harness Assembly	7-143
	7-30	Inspect Accessory Electrical Harness Assembly	7-144
	7-31	Repair Accessory Electrical Harness Assembly	7-146
	7-32	Test Accessory Electrical Harness Assembly	7-147
	7-33	Install Accessory Electrical Harness Assembly	7-156

SECTION I

IGNITION COIL AND CABLE ASSEMBLY

7-1 REMOVE IGNITION COIL AND CABLE ASSEMBLY

7-1

INITIAL SETUP**Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Materials:**


None

Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:


The ignition exciter stores very high and possibly fatal voltage. Use extreme care when working around ignition exciter. Serious Injury could result if exciter is accidentally grounded. Do not probe inside of output receptacles with fingers or metal object. Discharge exciter only with insulated screwdriver. In case of shock or injury, get medical attention.

WARNING

B-7-1/1

GO TO NEXT PAGE

1. Remove nut (1), screw (2), and two clamps (3).




E-7-12

GO TO NEXT PAGE

WARNING

The Ignition exciter stores very high and possibly fatal voltage. Use extreme care when working around ignition exciter. Serious Injury could result if exciter is accidentally grounded. Do not probe inside of output receptacles with fingers or metal object. Discharge exciter only with Insulated screwdriver. In case of shock or injury, get medical attention.

2. Remove lockwire and **disconnect two coil and cable assembly leads (4)**. Place leads to one side.



GO TO NEXT PAGE


WARNING

When discharging ignition exciter, re- move one lead at a time and discharge receptacle that lead was removed from. Failure to do so may result in serious shock when you are removing second lead. In case of serious shock, get medical attention.

NOTE


Step 3 applies to both output receptacles.

3. **Discharge ignition exciter (5)** by placing tip of insulated screwdriver (6) against pin (7) and edge (8) of receptacle (9).




GO TO NEXT PAGE

4. Remove two nuts (10), screws (11), bracket (12), and two clamps (13).




GO TO NEXT PAGE

5. Remove nut (14), screw (15), and two clamps (16).




GO TO NEXT PAGE

6. Remove nut (17), screw (18), and two clamps (19).




GO TO NEXT PAGE

7. Remove nut-(20), screw (21), and two clamps (22).




GO TO NEXT PAGE

8. Remove two nuts (23) and retaining strap (24).




GO TO NEXT PAGE

9. Remove lockwire, screw (25), and two clamps (26).




GO TO NEXT PAGE

10. Remove lockwire, screw (27), and two clamps (28).




GO TO NEXT PAGE

11. Remove two nuts (29) and clamps (30 and 31).



GO TO NEXT PAGE

12. Remove lockwire, screw (32), and two clamps (33).




13. Remove lockwire. **Disconnect and remove ignition lead (34).**

NOTE


Spark igniter may remain in combustion chamber housing or on ignition lead.

14. Remove spark igniter (35).




GO TO NEXT PAGE

15. Remove lockwire, screw (36), and two clamps (37).



GO TO NEXT PAGE

- 16. Remove three nuts (38), bolts (39), and clamps (40).



GO TO NEXT PAGE


7-1 REMOVE IGNITION COIL AND CABLE ASSEMBLY (Continued)

17. Remove lockwire. Disconnect and remove ignition lead (41).


NOTE

Spark igniter may remain in combustion chamber housing or on ignition lead.

18. Remove spark igniter (42).




19. Remove two nuts (43), bolts (44), and four clamps (45).




GO TO NEXT PAGE

20. Remove nut (46), screw (47), and two clamps (48).




21. Remove three nuts (49) and clamp (50).




GO TO NEXT PAGE

22. Remove two nuts (51) and clamps (52 and 53).



23. Remove lockwire, screw (54), and two clamps (55).




GO TO NEXT PAGE

24. Remove lockwire. **Disconnect and remove ignition lead (56).**

NOTE


Spark igniter may remain in combustion chamber housing or on ignition lead.

25. **Remove spark igniter (57).**




GO TO NEXT PAGE

26. Remove nut (58), screw (59), and two clamps (60).



B-7-1 24


27. Remove lockwire, screw (61), and clamp (62).




B-7-1 25

GO TO NEXT PAGE

28. Remove nut (63), bolt (64), and clamps (65).



29. Remove two nuts (66), bolts (67), and clamps (68).




GO TO NEXT PAGE

30. Remove lockwire. **Disconnect and remove ignition lead (69).**

NOTE


Spark igniter may remain in combustion chamber housing or on igniter lead.

31. **Remove spark igniter (70).**



GO TO NEXT PAGE

32. Remove two nuts (71) and bolts (72).
33. Remove ignition coil and cable assembly (73).



FOLLOW-ON MAINTENANCE:

None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Goggles

Dry, Compressed Air Source

Materials:

Dry Cleaning Solvent (E19)

Gloves (E24)

Lint-Free Cloth (E30)

Personnel Required:

Aircraft Powerplant Repairer


Equipment Condition:

Off Engine Task

General Safety Instructions:**WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Wear gloves (E24). **Clean ignition coil and cable assembly (1)** with lint-free cloth (E30) and brush dampened in dry cleaning solvent (E19).




E-7-2

GO TO NEXT PAGE

WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of Injury, get medical attention.

2. Wear goggles. **Blow dry four spark plug connectors (2) and two exciter connectors (3)** thoroughly using clean, dry, compressed air.

**FOLLOW-ON MAINTENANCE:**

Inspect Ignition Coil and Cable Assembly (Task 7-3).

END OF TASK

7-3 INSPECT IGNITION COIL AND CABLE ASSEMBLY

7-3

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit
 NSN 5180-00-323-4944
 Multimeter

Materials:

None

Personnel Required:


Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

1. **Inspect ignition coil and cable assembly (1)** as follows:


- a. There shall be no burned insulation (2).
- b. Check connectors (3) attached to sheathing. There shall be no loose connectors (3).
- c. Frayed or worn outer steel braid is acceptable up to $\frac{3}{4}$ of the cable circumference; $\frac{1}{4}$ of the cable circumference shall remain intact to provide continuity for ground. Repair frayed or broken wires (4) on sheathing (Ref. Task 7-4). Replace coil and cable assembly if damage is exceeded.
- d. The outer steel braid shall not be frayed or worn over more than $\frac{3}{4}$ of the cable circumference. Remaining continuity for ground shall be over at least $\frac{1}{4}$ of the braid.
- e. There shall be no cracked or broken insulators (5).




GO TO NEXT PAGE

2. Measure insulation resistance on ignition coil and cable assembly (1) as follows:

- a. Set multimeter range switch to R x 1000. Touch red probe (6) to electrical connector conductor (7).
- b. Touch black probe (8) to electrical connector outer housing (9).
- c. Meter shall indicate 1000 ohms minimum.




- d. Touch red probe (6) to electrical connector conductor (7).
- e. Touch black probe (8) to electrical connector outer housing (10).
- f. Meter shall indicate 1000 ohms minimum.




GO TO NEXT PAGE

3. Measure continuity on ignition coil and cable assembly (1) as follows:

- a. Set multimeter range switch to R x 1. Touch red probe (6) to electrical connector conductor (7).
- b. Touch black probe (8) to electrical connector conductors (11).
- c. Meter shall indicate 1 ohm maximum.



- d. Touch red probe (6) to electrical connector conductor (7).
- e. Touch black probe (8) to electrical connector center conductors (12).
- f. Meter shall indicate 1 ohm maximum.



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114
Retaining Ring Pliers

Materials:

Lockwire (E32)
Spiral Chafing Sleeve (E55)

Parts:

Retaining Ring
Insulator
Retaining Ring
Sleeve
Packing
Washer

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P


Equipment Condition :

Off Engine Task

GO TO NEXT PAGE

1. Repair fraying (broken) individual cable leads (1) as follows:

- a. Wrap individual broken wires (2) in cable lead (1) with spiral chafing sleeve (E55) (3). Be sure that spiral chafing sleeve (3) extends beyond damaged area.





INSPECT

GO TO NEXT PAGE

NOTE

This cable assembly consists of a transformer and shielded cabling which has six leads. Two leads are connected to the ignition exciter which carry high voltages to the transformer to be distributed equally to four individual cable leads. Two repairs total shall be allowed to the two shorter individual cable leads and three repairs total shall be allowed to the two longer individual cable leads.

- b. If three or more wires (4) of individual cable leads are broken, flatten broken wires (4) without damaging insulation of individual cable lead (1) at damaged area. The outer steel braid shall have a minimum of 1/4 of its circumference intact to provide continuity of grounding purposes. Damaged area shall be 3 inches minimum from either the transformer or spark igniter end of each cable lead (1). Damaged areas on each cable lead (1) shall be a minimum of 6 inches apart.
- c. Use lockwire (E32) (5) to wind clockwise around damaged cable lead (1). Lockwire (5) should cover damaged area by 3/8 inch. Do not pass wrapping limits of 1-1/4 inch length.




GO TO NEXT PAGE

NOTE

In following step, use care when pulling end C. Pull only far enough to firmly anchor end A beneath several wraps of the lockwire.


- d. Finish wrap by inserting lockwire (5) end A through loop B. Hold A tight while pulling C to close loop. Release A and carefully pull C until end A is anchored beneath wrapping. Cut excess wire ends.




B-7-4 4

INSPECT

- 2. **Replace cracked insulator (6)** as follows:
 - a. Remove retaining ring (7).
 - b. Remove insulator (6) from wire (8) and out of sleeve (9).
 - c. Insert new insulator (10) in sleeve (9) and over wire (8).
 - d. Install new retaining ring (11).





B-7-5



B-7-6

GO TO NEXT PAGE

3. **Replace cracked sleeve (12) as follows:**
 - a. Remove retaining ring (13).
 - b. Remove sleeve (12) with packing (14) and washer (15) from wire (16) and out of sleeve (17).
 - c. Remove washer (18) and washer (19) from wire (16) and out of sleeve (17).
 - d. Insert new washer (20) and new washer (21) over wire (16).
 - e. Insert new washer (22) and new packing (23) on new sleeve (24). Insert over wire (16).
 - f. Install new retaining ring (25).

**INSPECT****FOLLOW-ON MAINTENANCE:**

None

END OF TASK

7-5 INSTALL IGNITION COIL AND CABLE ASSEMBLY

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114


Torque Wrench, 30-150 lch-Pounds
Crowfoot Attachment, 7/8 inch

Materials:

Anti-Seize Compound (E6)
Lockwire (E33)


Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector




GO TO NEXT PAGE

1. Install ignition coil and cable assembly (1), two bolts (2), and nuts (3) on bracket (4).





2. Route ignition coil and cable assembly (1) as shown.



GO TO NEXT PAGE

2. (Continued)



GO TO NEXT PAGE


3. Install spark Igniter (5) on ignition lead (6).

CAUTION


To prevent shorting of ignition lead, do not allow anti-seize compound to touch electrical contacts and insulators.

4. Coat threads of ignition lead (6) with anti-seize compound (E6).

5. Install ignition lead (6). Torque to 135 inch-pounds. Use crowfoot attachment. Lockwire ignition lead (6). Use lockwire (E33).




6. Install two clamps (7), bolts (8), and nuts (9).




GO TO NEXT PAGE

7. Install clamp (10), bolt (11), and nut (12).




8. Install clamp (13) and screw (14). Lockwire screw (14). Use lockwire (E33).



GO TO NEXT PAGE

9. Install two clamps (15), screw (16), and nut (17).




10. Install spark igniter (18) on ignition lead (19).

CAUTION

To prevent shorting of ignition lead, do not allow anti-seize compound to touch electrical contacts and insulators.


11. Coat threads of ignition lead (19) with anti-seize compound (E6).
12. Install ignition lead (19). Torque to **135 inch-pounds**. Use crowfoot attachment. Lockwire ignition lead (19). Use lockwire (E33).



GO TO NEXT PAGE


7-5 INSTALL IGNITION COIL AND CABLE ASSEMBLY (Continued)

13. Install two clamps (20) and screw (21). Lockwire screw (21). Use lockwire (E33).



B-7-5 12


14. Install clamps (22 and 23) and two nuts (24).




B-7-5 13

GO TO NEXT PAGE

15. Install clamp (25) and three nuts (26).




16. Install two clamps (27), screw (28), and nut (29).



GO TO NEXT PAGE

17. Install four clamps (30), two bolts (31), and nuts (32).




18. Install spark igniter (33) on ignition lead (34).

CAUTION

To prevent shorting of ignition lead, do not allow anti-seize compound to touch electrical contacts and insulators.


19. Coat threads of ignition lead (34) with anti-seize compound (E6).

20. Install ignition lead (34). Torque to 135 inch-pounds. Use crowfoot attachment. Lockwire ignition lead (34). Use lockwire (E33).




GO TO NEXT PAGE

21. Install three clamps (35), bolts (36), and nuts (37).



GO TO NEXT PAGE

22. Install clamp (38) and screw (39). Lockwire screw (39). Use lockwire (E33).




GO TO NEXT PAGE

23. Install spark Igniter (40) on ignition lead (41).


CAUTION

To prevent shorting of ignition lead, do not allow anti-seize compound to touch electrical contacts and insulators.

24. Coat threads of ignition lead (41) with anti-seize compound (E6).
25. Install ignition lead (41). Torque to **135 inch-pounds**. Use crowfoot attachment. Lockwire ignition lead (41). Use lockwire (E33).




26. Install two clamps (42) and screw (43). Lockwire screw (43). Use lockwire (E33).




GO TO NEXT PAGE

27. Install clamps (44 and 45) and two nuts (46).




GO TO NEXT PAGE

28. Install two clamps (47) and screw (48). Lockwire screw (48). Use lockwire (E33).




GO TO NEXT PAGE

29. Install two clamps (49) and screw (50). Lockwire screw (50). Use lockwire (E33).




GO TO NEXT PAGE

30. Install retaining strap (51) and two nuts (52) to bracket (53).




GO TO NEXT PAGE

31. Install two clamps (54), screw (55), and nut (56).




GO TO NEXT PAGE

32. Install two clamps (57), screw (58), and nut (59).




GO TO NEXT PAGE

33. Install two clamps (60), screw (61), and nut (62).




GO TO NEXT PAGE

34. Install two clamps (63), bracket (64), two screws (65), and nuts (66).




GO TO NEXT PAGE

35. Install two clamps (67), screw (68), and nut (69).



GO TO NEXT PAGE

36. Connect two coil and cable assembly leads (70) to ignition exciter (71). Lockwire leads (70). Use lockwire (E33).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

7-57/(7-58 blank)

**SECTION II
SPARK IGNITERS**

7-6 REMOVE SPARK IGNITERS

7-6

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

None



Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:

WARNING

The ignition exciter stores very high and possibly fatal voltage. Use extreme care when working around ignition exciter. Serious injury could result if exciter is accidentally grounded. Do not probe inside of output receptacles with fingers or metal object. Discharge exciter only with insulated screwdriver. In case of shock or injury, get medical attention.



B-7-6 1

GO TO NEXT PAGE

WARNING

When discharging ignition leads, remove one lead at a time and discharge to combustor housing. Failure to do so may result in serious shock when you are removing other leads. In case of serious shock, get medical attention.


NOTE

The procedure for removal of four spark igniters located at the 3-, 6-, 9-, and 12-o'clock positions is the same. Only the 3-o'clock position is shown.


- 1. **Remove** lockwire and **ignition lead (1)** from combustor housing (2).

NOTE

If spark igniter stays with ignition lead, do steps 2 and 3. If spark igniter stays in combustor housing do steps 4 and 5.




- 2. **Discharge** ignition lead (1) and spark igniter (3) by touching to combustor housing (2).




GO TO NEXT PAGE


3. Remove spark igniter (3) from ignition lead (1).



4. Discharge ignition lead (1) by touching to combustor housing (2).



5. Remove spark igniter (3) from combustor housing (2).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP**Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

Dry Cleaning Solvent (E19)
Gloves (E24)
Lint-Free Cloth (E30)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task
Spark Igniters Removed (Task 7-6)


General Safety Instructions:**WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Wear gloves (E24). **Clean four spark igniters (1)**, using dry cleaning solvent (E19) and brush.
2. **Remove any remaining solvent** using clean, dry, lint-free cloth (26).

FOLLOW-ON MAINTENANCE:

Inspect Spark Igniters (Task 7-8).



B-7-7-1

END OF TASK

INITIAL SETUP**Applicable Configurations:**

All

Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

None

Personnel Required:

Aircraft Powerplant Inspector

Equipment Condition:


Off Engine Task

1. Inspect four spark igniters (1).

- a. There shall be no cracks or gouges in shank (2). Chafing allowed to 0.010 inch depth.
- b. There shall be no chips or cracks in ceramic surface (3).
- c. Pin (4) shall not be bent or broken.

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

INITIAL SETUP**Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114
Goggles
Dry, Compressed Air Source

Materials:

Crocus Cloth (E16)

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

Equipment Condition:

Off Engine Task

NOTE

This repair is allowed provided it does not cause pin to break or crack.

1. **Straighten bent pin (1)** of spark igniter (2). Using long-nose pliers, gently move pin (1) until straight.
2. **Remove corrosion from pin (1)** of spark igniter (2). Polish pin, using in and out motion over entire length of pin until corrosion is removed. Use crocus cloth (E16).



WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

3. Wear goggles. Remove loosened particles from pin (1), using clean, dry, compressed air.

INSPECT**FOLLOW-ON MAINTENANCE:**

Clean Spark Igniters (Task 7-7).

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Torque Wrench, 30-150 Inch-Pounds
Crowfoot Attachment, 7/8 Inch

Materials:



Anti-Seize Compound (E6)

Lockwire (E33)

Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector



B-7-10 1

GO TO NEXT PAGE

NOTE

The procedure for installing four spark igniters at 3-, 6-, 9-, and 12-o'clock positions is the same except for lockwiring. Only the 3-o'clock position is shown for installation.


NOTE

Install gently by hand until fully engaged.


- 1. Install spark igniter (1) on ignition lead (2).

CAUTION


To prevent shorting of ignition lead, do not allow anti-seize compound to touch electrical contacts and insulators.




- 2. Apply a light coat of anti-seize compound (E6) to ignition lead threads (3).



3. Install ignition lead (2) in combustor housing (4). Torque ignition lead connector (5) to 135 inch-pounds. Use crowfoot attachment.




4. Lockwire connector (5) at 3-o'clock position. Use lockwire (E33).




GO TO NEXT PAGE

5. Lockwire connector (5) at 12-o'clock position. Use lockwire (E33).




GO TO NEXT PAGE

6. Lockwire connector (5) at 9-o'clock position. Use lockwire (E33).



GO TO NEXT PAGE

7. Lockwire connector (5) at 6-o'clock position. Use lockwire (E33).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

SECTION III IGNITION EXCITER

7-11 REMOVE IGNITION EXCITER

7-11

INITIAL SETUP**Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Materials:**


None

Personnel Required:


Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**

The ignition exciter stores very high and possibly fatal voltage. Use extreme care when working around ignition exciter. Serious injury could result if exciter is accidentally grounded. Do not probe inside of output receptacles with fingers or metal object. Discharge exciter only with insulated screwdriver. In case of shock or injury, get medical attention.

**GO TO NEXT PAGE**

1. Remove lockwire and disconnect electrical connector (1).



GO TO NEXT PAGE


WARNING

When discharging ignition exciter, remove one lead at a time and discharge receptacle that lead was removed from. Failure to do so may result in serious shock when you are removing second lead. In case of serious shock, get medical attention.

NOTE


Step 2 applies to both output receptacles.

- 2. Remove lockwire and **disconnect coil and cable assembly leads (2).**
- 3. **Discharge ignition exciter (3)** by placing tip of insulated screwdriver (4) against pin (5) and edge (6) of receptacle (7).




GO TO NEXT PAGE

4. Remove lockwire, screw (8), and clamp (9).



5. Remove lockwire, screw (10), clamp (11), and ignition exciter (3).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

None

Materials:

Dry Cleaning Solvent (E19)

Gloves (E24)

Lint-Free Cloth (E30)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:


Off Engine Task

Ignition Exciter Removed (Task 7-11)

WARNING

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Wear gloves (E24). Clean ignition exciter (1) with clean lint-free cloth (E30) dampened in dry-cleaning solvent (E19).



FOLLOW-ON MAINTENANCE:

Inspect Ignition Exciter (Task 7-13).

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

None

Personnel Required:


Aircraft Powerplant Inspector

1. Inspect ignition exciter (1).

- a. There shall be no cracks or dents in housing (2).
- b. There shall be no bent or broken pins (3).
- c. There shall be no cracks in insulators (4).
- d. There shall be no corrosion.

FOLLOW-ON MAINTENANCE:

None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

- Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
- Technical Inspection Tool Kit,
NSN 5180-00-323-5114
- Goggles
- Dry, Compressed Air Source

Materials:

Crocus Cloth (E16)

Personnel Required:

- Aircraft Powerplant Repairer
- Aircraft Powerplant Inspector


Equipment Condition:

Off Engine Task

NOTE

This repair is allowed provided it does not cause pins to break or crack.

1. **Straighten bent pins (1)** of ignition exciter (2). Using long-nose pliers, gently move pins (1) until they are straight.




2. **Remove corrosion from pins (1)** of ignition exciter (2). Polish pins, using in and out motion over entire length of pin until corrosion is removed. Use crocus cloth (E16).

WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

3. Wear goggles. **Remove loosened particles from pins (1)** using clean, dry, compressed air.



INSPECT

FOLLOW-ON MAINTENANCE:

None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All


Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

Lockwire (E33)

Personnel Required:


Aircraft Powerplant Repairer

Aircraft Powerplant Inspector




GO TO NEXT PAGE

- 1. Install ignition exciter (1) on brackets (2 and 3).
 - a. Loosely install clamp (4) and screw (5) on ignition exciter (1) and bracket (3).




- b. Loosely install clamp (6) and screw (7) on ignition exciter (1) and bracket (2).




GO TO NEXT PAGE

- c. Align slots (8) in clamps (4 and 6) with locating lugs (9) on ignition exciter (1). Tighten screws (5 and 7) and lockwire. Use lockwire (E33).




- 2. Connect two coil and cable assembly leads (10) to ignition exciter output receptacles (11). Lockwire leads. Use lockwire (E33).



- 3. Connect electrical connector (12) to input receptacle (13). Lockwire electrical connector (12). Use lockwire (E33).

INSPECT

FOLLOW-ON MAINTENANCE:
None



END OF TASK

SECTION IV
 PRIMARY ELECTRICAL HARNESS ASSEMBLY

7-16 REMOVE PRIMARY ELECTRICAL HARNESS ASSEMBLY

7-16

INITIAL SETUP

Applicable Configurations:

All

Tools:


Powerplant Mechanic's Tool Kit
 NSN 5180-00-323-4944

Materials:

None


Personnel Required:

Aircraft Powerplant Repairer




GO TO NEXT PAGE

- 1. Disconnect electrical connector (1) from torque sensor (2).
- 2. Cut two straps (3) and remove harness (4) from two cushions (5).
- 3. Cut strap (6) and remove harness from cushion (7).




GO TO NEXT PAGE

4. Disconnect electrical connector (8) from hydromechanical assembly (9).
5. Remove screw (10), nut (11), and clamp (12) from bracket (13).
6. Disconnect electrical connector (14) from starting fuel solenoid valve (15).



GO TO NEXT PAGE

- 7. Disconnect electrical connector (16) from electrical connector (17).
- 8. Cut lockwire, remove nut (18), packing (19), and connector (17) from bracket (20).
- 9. Disconnect electrical connector (21) from speed pickup (22) on accessory gearbox assembly (23). Remove primary electrical harness assembly (4).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Goggles

Dry, Compressed Air Source

Materials:

Gloves (E24)

Lint-Free Cloth (E30)

Denatured Alcohol (E17)

Personnel Required:

Aircraft Powerplant Repairer


Equipment Condition:

Off Engine Task

Primary Electrical Harness Assembly Removed
(Task 7-16)**General Safety Instructions:****WARNING**

Denatured alcohol (E17) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Wear gloves (E24). **Clean primary electrical harness assembly (1)**. Use lint-free cloth (E30) dampened with denatured alcohol (E17). Wipe dry using clean, dry, lint-free cloth (E30).



GO TO NEXT PAGE

2. Clean six electrical connectors (2). Use denatured alcohol (E17) and brush.


WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

3. Wear goggles. Blow dry electrical connectors (2). Use clean, dry, compressed air.

FOLLOW-ON MAINTENANCE:

Inspect Primary Electrical Harness Assembly (Task 7-18).



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

None


Personnel Required:

Aircraft Powerplant Inspector

Equipment Condition:


Off Engine Task

- 1. **Inspect primary electrical harness assembly (1).** There shall be no frayed or burned insulation. There shall be no loose connections or broken wires.



B-7-18.1


- 2. **Inspect sleeving (2).** There shall be no frayed or broken sleeving.




B-7-18.2

GO TO NEXT PAGE

3. Inspect electrical connector (3). There shall be no corrosion, broken or bent pins (4), or cracked insulation (5).



4. Inspect five electrical connectors (6). There shall be no corrosion, broken or bent sleeves (7) or cracked insulation (8).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

- Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
- Technical Inspection Tool Kit
NSN 5180-00-323-5114
- Hand File Set

Materials:

Crocus Cloth (E1 6)

Personnel Required:

- Aircraft Powerplant Repairer
- Aircraft Powerplant Inspector

Equipment Condition:

Off Engine Task

NOTE


This repair is allowed provided it does not cause pin to break or crack.

1. **Straighten bent pin (1)** of electrical connector (2). Use long nose pliers to gently move pin (1) until it is straight.
2. **Remove corrosion from pin (1)** of electrical connector (2). Use crocus cloth (E16).
3. **Remove corrosion from sleeve (3)** of electrical connectors (4). Use round hand file.

INSPECT

FOLLOW-ON MAINTENANCE:

None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Multimeter


Materials:

None

Personnel Required:


Aircraft Powerplant Repairer

1. Using multimeter, **measure continuity and insulation resistance of electrical harness assembly (1)** as follows:
 - a. Set multimeter range switch to R x 1.
 - b. Touch red probe (2) to electrical connector (3), sleeve A (4).
 - c. Touch black probe (5) to electrical connector (6), pin W (7).
 - d. Meter shall indicate **zero ohms**.
 - e. Set multimeter range switch to R x 1000.
 - f. Touch black probe (5) to all other pins on electrical connector (6).
 - g. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- h. Set multimeter range switch to R x 1.
- i. Touch red probe (2) to electrical connector (3), sleeve B (8).
- j. Touch black probe (5) to electrical connector (6), pin V (9).
- k. Meter shall indicate zero ohms.




- l. Set multimeter range switch to R x 1.
- m. Touch red probe (2) to electrical connector (10), sleeve 1 (11).
- n. Touch black probe (5) to electrical connector (6), pin U (12).
- o. Meter shall indicate zero ohms.
- p. Set multimeter range switch to R x 1000.
- q. Touch black probe (5) to all other pins on electrical connector (6).
- r. Meter shall indicate 1000 ohms minimum.




GO TO NEXT PAGE

- s. Set multimeter range switch to R x 1.
- t. Touch red probe (2) to electrical connector (10), sleeve 2 (13).
- u. Touch black probe (5) to electrical connector (6), pin T (14).
- v. Meter shall indicate **zero ohms.**
- w. Set multimeter range switch to R x 1000.
- x. Touch black probe (5) to all other pins on electrical connector (6).
- y. Meter shall indicate **1000 ohms** minimum.




- z. Set multimeter range switch to R x 1.
- aa. Touch red probe (2) to electrical connector (10), sleeve 3 (15).
- ab. Touch black probe (5) to electrical connector (6), pin S (16).
- ac. Meter shall indicate **zero ohms.**
- ad. Set multimeter range switch to R x 1000.
- ae. Touch black probe (5) to all other pins on electrical connector (6).
- af. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- ag. Set multimeter range switch to R x 1.
- ah. Touch red probe (2) to electrical connector (10), sleeve 4 (17).
- ai. Touch black probe (5) to electrical connector (6), pin R (18).
- aj. Meter shall indicate **zero ohms**.
- ak. Set multimeter range switch to R x 1000.
- al. Touch black probe (5) to all other pins on electrical connector (6).
- am. Meter shall indicate **1000 ohms** minimum.




- an. Set multimeter range switch to R x 1.
- ao. Touch red probe (2) to electrical connector (19), sleeve A (20).
- ap. Touch black probe (5) to electrical connector (6), pin b (21).
- aq. Meter shall indicate **zero ohms**.
- ar. Set multimeter range switch to R x 1000.
- as. Touch black probe (5) to all other pins on electrical connector (6).
- at. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- au. Touch red probe (2) to electrical connector (19), sleeve B (22).
- av. Touch black probe (5) to electrical connector (6), pin a (23).
- aw. Meter shall indicate zero ohms.
- ax. Set multimeter range switch to R x 1000.
- ay. Touch black probe (5) to all other pins on electrical connector (6).
- az. Meter shall indicate 1000 ohms minimum.




- ba. Set multimeter range switch to R x 1.
- bb. Touch red probe (2) to electrical connector (19), sleeve C (24).
- bc. Touch black probe (5) to electrical connector (6), pin z (25).
- bd. Meter shall indicate zero ohms.
- be. Set multimeter range switch to R x 1000.
- bf. Touch black probe (5) to all other pins on electrical connector (6).
- bg. Meter shall indicate 1000 ohms minimum.




GO TO NEXT PAGE

- bh. Touch red probe (2) to electrical connector (19), sleeve D (26).
- bi. Touch black probe (5) to electrical connector (6), pin y (27).
- bj. Meter shall indicate **zero ohms**.
- bk. Set multimeter range switch to R x 1000.
- bl. Touch black probe (5) to all other pins on electrical connector (6).
- bm. Meter shall indicate **1000 ohms** minimum.




- bn. Set multimeter range switch to R x 1.
- bo. Touch red probe (2) to electrical connector (19), sleeve E (28).
- bp. Touch black probe (5) to electrical connector (6), pin x (29).
- bq. Meter shall indicate **zero ohms**.
- br. Set multimeter range switch to R x 1000.
- bs. Touch black probe (5) to all other pins on electrical connector (6).
- bt. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- bu. Set multimeter range switch to R x 1.
- bv. Touch red probe (2) to electrical connector (3U), sleeve S (31).
- bw. Touch black probe (5) to electrical connector (6), pin A (32).
- bx. Meter shall indicate **zero ohms**.
- by. Set multimeter range switch to R x 1000.
- bz. Touch black probe (5) to all other pins on electrical connector (6).
- ca. Meter shall indicate **1000 ohms** minimum.



B-7-20/12


- cb. Set multimeter range switch to R x 1.
- cc. Touch red probe (2) to electrical connector (30), sleeve R (33).
- cd. Touch black probe (5) to electrical connector (6), pin B (34).
- ce. Meter shall indicate **zero ohms**.
- cf. Set multimeter range switch to R :x 1000.
- cg. Touch black probe (5) to all other pins on electrical connector (6).
- ch. Meter shall indicate **1000 ohms** minimum.



B-7-20 '13


GO TO NEXT PAGE

- ci. Set multimeter range switch to R x 1.
- cj. Touch red probe (2) to electrical connector (30), sleeve F (35).
- ck. Touch black probe (5) to electrical connector (6), pin C (36).
- cl. Meter shall indicate **zero ohms**.
- cm. Set multimeter range switch to R x 1000.
- cn. Touch black probe (5) to all other pins on electrical connector (6).
- co. Meter shall indicate **1000 ohms** minimum.



B-7-20 14


- cp. Set multimeter range switch to R x 1.
- cq. Touch red probe (2) to electrical connector (30), sleeve E (37).
- cr. Touch black probe (5) to electrical connector (6), pin D (38).
- cs. Meter shall indicate **zero ohms**.
- ct. Set multimeter range switch to R x 1000.
- cu. Touch black probe (5) to all other pins on electrical connector (6).
- cv. Meter shall indicate **1000 ohms** minimum.



B-7-20 15


GO TO NEXT PAGE

- cw. Set multimeter range switch to R x 1.
- cx. Touch red probe (2) to electrical connector (30), sleeve U (39).
- cy. Touch black probe (5) to electrical connector (6), pin E (40).
- cz. Meter shall indicate **zero ohms**.
- da. Set multimeter range switch to R x 1000.
- db. Touch black probe (5) to all other pins on electrical connector (6).



B-7-20 16


- dc. Meter shall indicate **1000 ohms** minimum.
- dd. Set multimeter range switch to R x 1.
- de. Touch red probe (2) to electrical connector (30), sleeve V (41).
- df. Touch black probe (5) to electrical connector (6), pin F (42).
- dg. Meter shall indicate **zero ohms**.
- dh. Set multimeter range switch to R x 1000.
- di. Touch black probe (5) to all other pins on electrical connector (6).
- dj. Meter shall indicate **1000 ohms** minimum.



B-7-20 17


GO TO NEXT PAGE

- dk. Set multimeter range switch to R x 1.
- dl. Touch red probe (2) to electrical connector (30), sleeve T (43).
- dm. Touch black probe (5) to electrical connector (6), pin G (44).
- dn. Meter shall indicate **zero ohms**.
- do. Set multimeter range switch to R x 1000.
- dp. Touch black probe (5) to all other pins on electrical connector (6).
- dq. Meter shall indicate **1000 ohms** minimum.



B-7-20 18


- dr. Set multimeter range switch to R x 1.
- ds. Touch red probe (2) to electrical connector (30), sleeve A (45).
- dt. Touch black probe (5) to electrical connector (6), pin H (46).
- du. Meter shall indicate **zero ohms**.
- dv. Set multimeter range switch to R x 1000.
- dw. Touch black probe (5) to all other pins on electrical connector (6).
- dx. Meter shall indicate **1000 ohms** minimum.




B-7-20 19

GO TO NEXT PAGE

- dy. Set multimeter range switch to R x 1.
- dz. Touch red probe (2) to electrical connector (30), sleeve B (47).
- ea. Touch black probe (5) to electrical connector (6), pin J (48).
- eb. Meter shall indicate **zero ohms.**
- ec. Set multimeter range switch to R x 1000.
- ed. Touch black probe (5) to all other pins on electrical connector (6).
- ee. Meter shall indicate **1000 ohms** minimum.




- ef. Set multimeter range switch to R x 1.
- eg. Touch red probe (2) to electrical connector (30), sleeve C (49).
- eh. Touch black probe (5) to electrical connector (6), pin K (50).
- ei. Meter shall indicate **zero ohms.**
- ej. Set multimeter range switch to R x 1000.
- ek. Touch black probe (5) to all other pins on electrical connector (6).
- el. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- em. Set multimeter range switch to R x 1.
- en. Touch red probe (2) to electrical connector (30), sleeve D (51).
- eo. Touch black probe (5) to electrical connector (6), pin L (52).
- ep. Meter shall indicate **zero ohms**.
- eq. Set multimeter range switch to R x 1000.
- er. Touch black probe (5) to all other pins on electrical connector (6).
- es. Meter shall indicate **1000 ohms** minimum.




- et. Set multimeter range switch to R x 1.
- eu. Touch red probe (2) to electrical connector (30), sleeve P (53).
- ev. Touch black probe (5) to electrical connector (6), pin M (54).
- ew. Meter shall indicate **zero ohms**.
- ex. Set multimeter range switch to R x 1000.
- ey. Touch black probe (5) to all other pins on electrical connector (6).
- ez. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- fa. Set multimeter range switch to R x 1.
- fb. Touch red probe (2) to electrical connector (30), sleeve N (56).
- fc. Touch black probe (5) to electrical connector (6), pin N (57).
- fd. Meter shall indicate **zero ohms**.
- fe. Set multimeter range switch to R x 1000.
- ff. Touch black probe (5) to all other pins on electrical connector (6).
- fg. Meter shall indicate **1000 ohms** minimum.



B-7-20 24


- fh. Set multimeter range switch to R x 1.
- fi. Touch red probe (2) to electrical connector (30), sleeve M (58).
- fj. Touch black probe (5) to electrical connector (6), pin P (59).
- fk. Meter shall indicate **zero ohms**.
- fl. Set multimeter range switch to R x 1000.
- fm. Touch black probe (5) to all other pins on electrical connector (6).
- fn. Meter shall indicate **1000 ohms** minimum.




B-7-20 25

GO TO NEXT PAGE

- fo. Set multimeter range switch to R x 1.
- fp. Touch red probe (2) to electrical connector (30), sleeve Z (61).
- fq. Touch black probe (5) to electrical connector (60), pin A (62).
- fr. Meter shall indicate **zero ohms**.
- fs. Set multimeter range switch to R x 1000.
- ft. Touch black probe (5) to all other pins on electrical connector (60).
- fu. Meter shall indicate **1000 ohms** minimum.



- fv. Set multimeter range switch to R x 1.
- fw. Touch red probe (2) to electrical connector (30), sleeve Y (63).
- fx. Touch black probe (5) to electrical connector (60), pin B (64).
- fy. Meter shall indicate **zero ohms**.
- fz. Set multimeter range switch to R x 1000.
- ga. Touch black probe (5) to all other pins on electrical connector (60).
- gb. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- gc. Set multimeter range switch to R x 1.
- gd. Touch red probe (2) to electrical connector (30), sleeve X (65).
- ge. Touch black probe (5) to electrical connector (60), pin C (66).
- gf. Meter shall indicate **zero ohms**.
- gg. Set multimeter range switch to R x 1000.
- gh. Touch black probe (5) to all other pins on electrical connector (60).
- gi. Meter shall indicate **1000 ohms** minimum.

FOLLOW-ON MAINTENANCE:

None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

- Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
- Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

- Lockwire (E33)

Parts:


- Strap

Personnel Required:

- Aircraft Powerplant Repairer
- Aircraft Powerplant Inspector


References:

- TM 1-2840-252-23P



GO TO NEXT PAGE

1. Install electrical connector (1), to speed pickup (2) on accessory gearbox assembly (3).
2. Install packing (4), connector (5), and nut (6) to bracket (7). Lockwire nut (6). Use lockwire (E33).
3. Install electrical connector (8) to electrical connector (5).



GO TO NEXT PAGE


4. Install electrical connector (9) to starting fuel solenoid valve (10).

NOTE

Make sure that nut (13) is securely fastened to bracket with long section of nut perpendicular to slot.

5. Install clamp (11), screw (12), and nut (13) to bracket (14).

6. Install electrical connector (15) to hydromechanical assembly (16).




GO TO NEXT PAGE

- 7. Install harness (17) to cushion (18) and install strap (19) to cushion (18).
- 8. Install harness (17) to two cushions (20) and install straps (21) to cushions (20).
- 9. Install electrical connector (22) to torque sensor (23).

INSPECT

FOLLOW-ON MAINTENANCE:
None



END OF TASK

SECTION V

REVERSIONARY ELECTRICAL HARNESS ASSEMBLY

7-22 REMOVE REVERSIONARY ELECTRICAL HARNESS ASSEMBLY

7-22

INITIAL SETUP

Applicable Configurations:

All

Tools:


Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

None


Personnel Required:

Aircraft Powerplant Repairer




GO TO NEXT PAGE

- 1. Disconnect electrical connector (1) from T1 sensor (2).
- 2. Remove nut (3), screw (4), and clamps (5).




GO TO NEXT PAGE

3. Disconnect electrical connector (6) from primary electrical connector (7).
4. Cut two straps (8) and remove harness (9) from two cushions (10).




GO TO NEXT PAGE

- 5. Disconnect electrical connector (11) from PT speed pickup (12).
- 6. Remove nut (13) and clamp (14) from bracket (15).



GO TO NEXT PAGE

7. Disconnect electrical connector (16) from stepper motor (17).
8. Disconnect electrical connector (18) from alternator (19), located on rear of HMA.




GO TO NEXT PAGE

9. Disconnect electrical connector (20) from solenoid valve (21). Remove reversionary electrical harness assembly (9).

FOLLOW-ON MAINTENANCE:

None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Goggles

Dry, Compressed Air Source

Materials:

Gloves (E24)

Lint-Free Cloth (E30)

Denatured Alcohol (E17)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task


Reversionary Electrical Harness Assembly Re-
moved (Task 7-22)

General Safety Instructions:

WARNING

Denatured alcohol (E17) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Wear gloves (E24). **Clean reversionary electrical harness assembly (1).** Use lint-free cloth dampened with Denatured alcohol (E17). Wipe dry using clean, dry, lint-free cloth (E30).




2. **Clean seven electrical connectors (2).** Use denatured alcohol (E17) and brush.

WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

3. Wear goggles. **Blow dry electrical connectors (2).** Use clean, dry, compressed air.



FOLLOW-ON MAINTENANCE:

Inspect Reversionary Electrical Harness Assembly (Task 7-24).

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

None


Personnel Required:

Aircraft Powerplant Inspector


Equipment Condition:

Off Engine Task

1. **Inspect reversionary electrical harness assembly (1).** There shall be no frayed or burned insulation. There shall be no loose connections or broken wires.




2. **Inspect sleeving (2).** There shall be no frayed or broken sleeving.




GO TO NEXT PAGE

3. Inspect electrical connector (3). There shall be no corrosion, broken or bent pins (4), or cracked insulation (5).



4. Inspect six electrical connectors (6). There shall be no corrosion, broken or bent sleeves (7) or cracked insulation (8).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit
NSN 5180-00-323-5114
Hand File Set

Materials:

Crocus Cloth (E1 6)

Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector


Equipment Condition:

Off Engine Task

NOTE

This repair is allowed provided it does not cause pin to break or crack.

1. **Straighten bent pin (1)** of electrical connector (2). Use long nose pliers to gently move pin (1) until it is straight.
2. **Remove corrosion from pin (1)** of electrical connector (2). Use crocus cloth (E16).
3. **Remove corrosion from sleeve (3)** of electrical connectors (4). Use round hand file.

**INSPECT****FOLLOW-ON MAINTENANCE:**

None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Multimeter


Materials:

None


Personnel Required:

Aircraft Powerplant Repairer


1. Using multimeter, **measure continuity and insulation resistance of electrical harness assembly (1)** as follows:
 - a. Set multimeter range switch to R x 1.
 - b. Touch red probe (2) to electrical connector (3), sleeve A (4).
 - c. Touch black probe (5) to electrical connector (6), pin b (7).
 - d. Meter shall indicate **zero ohms**.
 - e. Set multimeter range switch to R x 1000.
 - f. Touch black probe (5) to all other pins on electrical connector (6).
 - g. Meter shall indicate **1000 ohms** minimum.

**GO TO NEXT PAGE**

- h. Set multimeter range switch to R x 1.
- i. Touch red probe (2) to electrical connector (3), sleeve B (8).
- j. Touch black probe (5) to electrical connector (6), pin a (9).
- k. Meter shall indicate **zero ohms**.
- l. Set multimeter range switch to R x 1000.
- m. Touch black probe (5) to all other pins on electrical connector (6).
- n. Meter shall indicate **1000 ohms** minimum.




- o. Set multimeter range switch to R x 1.
- p. Touch red probe (2) to electrical connector (3), sleeve C (10).
- q. Touch black probe (5) to electrical connector (6), pin 2 (11).
- r. Meter shall indicate **zero ohms**.
- s. Set multimeter range switch to R x 1000.
- t. Touch black probe (5) to all other pins on electrical connector (6).
- u. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- v. Set multimeter range switch to R x 1.
- w. Touch red probe (2) to electrical connector (12), sleeve 1 (13).
- x. Touch black probe (5) to electrical connector (6), pin X (14).
- y. Meter shall indicate **zero ohms**.
- z. Set multimeter range switch to R x 1000.
- aa. Touch black probe (5) to all other pins on electrical connector (6).
- ab. Meter shall indicate **1000 ohms** minimum.




- ac. Set multimeter range switch to R x 1.
- ad. Touch red probe (2) to electrical connector (12), sleeve 2 (15).
- ae. Touch black probe (5) to electrical connector (6), pin W (16).
- af. Meter shall indicate **zero ohms**.
- ag. Set multimeter range switch to R x 1000.
- ah. Touch black probe (5) to all other pins on electrical connector (6).
- ai. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- aj. Set multimeter range switch to R x 1.
- ak. Touch red probe (2) to electrical connector (12), sleeve 3 (17).
- al. Touch black probe (5) to electrical connector (6), pin V (18).
- am. Meter shall indicate **zero ohms**.
- an. Set multimeter range switch to R x 1000.
- ao. Touch black probe (5) to all other pins on electrical connector (6).
- ap. Meter shall indicate **1000 ohms** minimum.




- aq. Set multimeter range switch to R x 1.
- ar. Touch red probe (2) to electrical connector (12), sleeve 4 (19).
- as. Touch black probe (5) to electrical connector (6), pin V (20).
- at. Meter shall indicate **zero ohms**.
- au. Set multimeter range switch to R x 1000.
- av. Touch black probe (5) to all other pins on electrical connector (6).
- aw. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- ax. Set multimeter range switch to R x 1.
- ay. Touch red probe (2) to electrical connector (21), sleeve 2 (22).
- az. Touch black probe (5) to electrical connector (6), pin H (23).
- ba. Meter shall indicate **zero ohms**.
- bb. Set multimeter range switch to R x 1000.
- bc. Touch black probe (5) to all other pins on electrical connector (6).
- bd. Meter shall indicate **1000 ohms** minimum.




- be. Set multimeter range switch to R x 1.
- bf. Touch red probe (2) to electrical connector (21), sleeve 3 (24).
- bg. Touch black probe (5) to electrical connector (6), pin G (25).
- bh. Meter shall indicate **zero ohms**.
- bi. Set multimeter range switch to R x 1000.
- bj. Touch black probe (5) to all other pins on electrical connector (6).
- bk. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE


- bl. Set multimeter range switch to R x 1.
- bm. Touch red probe (2) to electrical connector (21), sleeve 4 (26).
- bn. Touch black probe (5) to electrical connector (6), pin F (27).
- bo. Meter shall indicate **zero ohms**.
- bp. Set multimeter range switch to R x 1000.
- bq. Touch black probe (5) to all other pins on electrical connector (6).
- br. Meter shall indicate **1000 ohms** minimum.




- bs. Set multimeter range switch to R x 1.
- bt. Touch red probe (2) to electrical connector (21), sleeve 5 (28).
- bu. Touch black probe (5) to electrical connector (6), pin E (29).
- bv. Meter shall indicate **zero ohms**.
- bw. Set multimeter range switch to R x 1000.
- bx. Touch black probe (5) to all other pins on electrical connector (6).
- by. Meter shall indicate **1000 ohms** minimum.



- bz. Set multimeter range switch to R x 1.
- ca. Touch red probe (2) to electrical connector (21), sleeve 6 (30).
- cb. Touch black probe (5) to electrical connector (6), pin D (31).
- cc. Meter shall indicate **zero ohms**.
- cd. Set multimeter range switch to R x 1000.
- ce. Touch black probe (5) to all other pins on electrical connector (6).
- cf. Meter shall indicate **1000 ohms** minimum.




- cg. Set multimeter range switch to R x 1.
- ch. Touch red probe (2) to electrical connector (32), sleeve A (33).
- ci. Touch black probe (5) to electrical connector (6), pin A (34).
- cj. Meter shall indicate **zero ohms**.
- ck. Set multimeter range switch to R x 1000.
- cl. Touch black probe (5) to all other pins on electrical connector (6).
- cm. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE


- cn. Set multimeter range switch to R x 1.
- co. Touch red probe (2) to electrical connector (32), sleeve B (35).
- cp. Touch black probe (5) to electrical connector (6), pin B (36).
- cq. Meter shall indicate **zero ohms**.
- cr. Set multimeter range switch to R x 1000.
- cs. Touch black probe (5) to all other pins on electrical connector (6).
- ct. Meter shall indicate **1000 ohms** minimum.




- cu. Set multimeter range switch to R x 1.
- cv. Touch red probe (2) to electrical connector (32), sleeve C (37).
- cw. Touch black probe (5) to electrical connector (6), pin C (38).
- cx. Meter shall indicate **zero ohms**.
- cy. Set multimeter range switch to R x 1000.
- cz. Touch black probe (5) to all other pins on electrical connector (6).
- da. Meter shall indicate **1000 ohms** minimum.



- db. Set multimeter range switch to R x 1.
- dc. Touch red probe (2) to electrical connector (39), sleeve A (40).
- dd. Touch black probe (5) to electrical connector (6), pin J (41).
- de. Meter shall indicate **zero ohms**.
- df. Set multimeter range switch to R x 1000.
- dg. Touch black probe (5) to all other pins on electrical connector (6).
- dh. Meter shall indicate **1000 ohms** minimum.




- di. Set multimeter range switch to R x 1.
- dj. Touch red probe (2) to electrical connector (39), sleeve B (42).
- dk. Touch black probe (5) to electrical connector (6), pin K (43).
- dl. Meter shall indicate **zero ohms**.
- dm. Set multimeter range switch to R x 1000.
- dn. Touch black probe (5) to all other pins on electrical connector (6).
- do. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- dp. Set multimeter range switch to R x 1.
- dq. Touch red probe (2) to electrical connector (39), sleeve C (44).
- dr. Touch black probe (5) to electrical connector (6), pin L (45).
- ds. Meter shall indicate **zero ohms**.
- dt. Set multimeter range switch to R x 1000.
- du. Touch black probe (5) to all other pins on electrical connector (6).
- dv. Meter shall indicate **1000 ohms** minimum.




- dw. Set multimeter range switch to R x 1.
- dx. Touch red probe (2) to electrical connector (39), sleeve E (46).
- dy. Touch black probe (5) to electrical connector (6), pin M (47).
- dz. Meter shall indicate **zero ohms**.
- ea. Set multimeter range switch to R x 1000.
- eb. Touch black probe (5) to all other pins on electrical connector (6).
- ec. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- ed. Set multimeter range switch to R x 1.
- ee. Touch red probe (2) to electrical connector (39), sleeve F (48).
- ef. Touch black probe (5) to electrical connector (6), pin N (49).
- eg. Meter shall indicate **zero ohms**.
- eh. Set multimeter range switch to R x 1000.
- ei. Touch black probe (5) to all other pins on electrical connector (6).
- ej. Meter shall indicate **1000 ohms** minimum.




- ek. Set multimeter range switch to R x 1.
- el. Touch red probe (2) to electrical connector (50), sleeve A (51).
- em. Touch black probe (5) to electrical connector (6), pin R (52).
- en. Meter shall indicate **zero ohms**.
- eo. Set multimeter range switch to R x 1000.
- ep. Touch black probe (5) to all other pins on electrical connector (6).
- eq. Meter shall indicate **1000 ohms** minimum.



GO TO NEXT PAGE

- er. Set multimeter range switch to R x 1.
- es. Touch red probe (2) to electrical connector (50), sleeve B (53).
- et. Touch black probe (5) to electrical connector (6), pin P (54).
- eu. Meter shall indicate **zero ohms**.
- ev. Set multimeter range switch to R x 1000.
- ew. Touch black probe (5) to all other pins on electrical connector (6).
- ex. Meter shall indicate **1000 ohms** minimum.



FOLLOW-ON MAINTENANCE:

None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

- Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
- Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Parts:


Strap

Personnel Required:

- Aircraft Powerplant Repairer
- Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P




GO TO NEXT PAGE

NOTE

In following step, it may be necessary to remove lockwire from electrical connector and reorient connector for proper installation. Be sure to lockwire electrical connector if lockwire was removed.

1. **Install electrical connector (1) to solenoid valve (2).**




GO TO NEXT PAGE

**7-27 INSTALL REVERSIONARY ELECTRICAL HARNESS ASSEMBLY
(Continued)**

7-27


2. Install electrical connector (3) to alternator (4).
3. Install electrical connector (5) to stepper motor (6).

**GO TO NEXT PAGE**


**7-27 INSTALL REVERSIONARY ELECTRICAL HARNESS ASSEMBLY
(Continued)**

7-27

4. **Install clamp (7) and nut (8) to bracket (9).**
5. **Install electrical connector (10) to PT speed pickup (11).**


**GO TO NEXT PAGE**

- 6. Install harness (12) to two cushions (13) and install straps (14) to cushions (13).
- 7. Install electrical connector (15) to primary electrical connector (16).



GO TO NEXT PAGE

8. Install clamps (17), screw (18), and nut (19).
9. Install electrical connector (20) to T1 sensor (21).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

SECTION VI
 ACCESSORY ELECTRICAL HARNESS ASSEMBLY

7-28 REMOVE ACCESSORY ELECTRICAL HARNESS ASSEMBLY

7-28

INITIAL SETUP

Applicable Configurations:

All

Tools:


Powerplant Mechanic's Tool Kit,
 NSN 5180-00-323-4944

Materials:

None


Personnel Required:

Aircraft Powerplant Repairer




GO TO NEXT PAGE

1. Disconnect electrical connector (1) from ignition exciter (2).
2. Remove screw (3), nut (4), and clamp (5) from bracket (6).




GO TO NEXT PAGE

3. **Disconnect electrical connector (7)** from oil temperature bulb (8).
4. Cut two straps (9) and **remove harness (10)** from two cushions (11).
5. **Cut strap (12)** and **remove harness (10)** from cushion (13).
6. **Disconnect electrical connector (14)** from pick-up assembly (15).




GO TO NEXT PAGE

7. Disconnect electrical connector (16) from accessory gearbox chip detector (17).
8. Cut two straps (18) and remove harness (10) from two cushions (19).




GO TO NEXT PAGE

9. Disconnect electrical connector (20) from oil level indicator (21).
10. Remove screw (22), nut (23), and clamp (24).
11. Remove two screws (25), two nuts (26), and two clamps (27).



GO TO NEXT PAGE

12. Disconnect electrical connector (28) from dummy connector (29).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Goggles

Dry, Compressed Air Source

Materials:

Gloves (E24) burns.
Lint-Free Cloth (E30)
Denatured Alcohol (E17)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task


Accessory Electrical Harness Assembly Removed
(Task 7-28)

General Safety Instructions:

WARNING

Denatured alcohol (E17) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Wear gloves (E24). **Clean accessory electrical harness assembly (1).** Use lint-free cloth (E30) dampened with denatured alcohol (E17). Wipe dry using clean, dry, lint-free cloth (E30).




2. **Clean eight electrical connectors (2).** Use denatured alcohol (E17) and brush.

WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

3. Wear goggles. **Blow dry electrical connector (2).** Use clean, dry, compressed air.



FOLLOW-ON MAINTENANCE:

Inspect Accessory Electrical Harness Assembly
(Task 7-30).

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

None


Personnel Required:

Aircraft Powerplant Inspector


Equipment Condition:

Off Engine Task

1. **Inspect accessory electrical harness assembly (1).** There shall be no frayed or burned insulation. There shall be no loose connections or broken wires.




2. **Inspect sleeving (2).** There shall be no frayed or broken sleeving.




GO TO NEXT PAGE

3. **Inspect electrical connector (3).** There shall be no corrosion, broken or bent pins (4), or cracked insulation (5).



4. **Inspect seven electrical connectors (6).** There shall be no corrosion, broken or bent sleeves (7) or cracked insulation (8).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

Applicable Configurations

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114
Hand File Set

Materials:

Crocus Cloth (E16)

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector


Equipment Condition:

Off Engine Task

NOTE

This repair is allowed provided it does not cause pin to break or crack.

1. **Straighten bent pin (1)** of electrical connector (2). Use long nose pliers to gently move pin (1) until it is straight.
2. **Remove corrosion from pin (1)** of electrical connector (2). Use crocus cloth (E16).
3. **Remove corrosion from sleeve (3)** of electrical connectors (4). Use round hand file.

**INSPECT****FOLLOW-ON MAINTENANCE:**

None

END OF TASK

INITIAL SETUP**Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Multimeter


Materials:

None


Personnel Required:

Aircraft Powerplant Repairer


1. Using multimeter, **measure continuity and insulation resistance of cable harness assembly (1)** as follows:
 - a. Set multimeter range switch to R x 1.
 - b. Touch red probe (2) to electrical connector (3), center sleeve (4).
 - c. Touch black probe (5) to electrical connector (6), pin G (7).
 - d. Meter shall indicate **zero ohms**.
 - e. Set multimeter range switch to R x 1000.
 - f. Touch black probe (5) to all other pins on electrical connector (6).
 - g. Meter shall indicate **1000 ohms** minimum.

**GO TO NEXT PAGE**

- h. Set multimeter range switch to R x 1.
- i. Touch red probe (2) to electrical connector (3), shell (8).
- j. Touch black probe (5) to electrical connector (6), pin H (9).
- k. Meter shall indicate zero ohms.





- l. Set multimeter range switch to R x 1.
- m. Touch red probe (2) to electrical connector (10), sleeve A (11).
- n. Touch black probe (5) to electrical connector (6), pin M (12).
- o. Meter shall indicate zero ohms.
- p. Set multimeter range switch to R x 1000.
- q. Touch black probe (5) to all other pins on electrical connector (6).
- r. Meter shall indicate 1000 ohms minimum.




GO TO NEXT PAGE

- s. Set multimeter range switch to R x 1.
- t. Touch red probe (2) to electrical connector (10), sleeve B (13).
- u. Touch black probe (5) to electrical connector (6), pin N (14).
- v. Meter shall indicate **zero ohms.**
- w. Set multimeter range switch to R x 1000.
- x. Touch black probe (5) to all other pins on electrical connector (6).
- y. Meter shall indicate **1000 ohms** minimum.
- z. Set multimeter range switch to R x 1.
- aa. Touch red probe (2) to electrical connector (14), sleeve A (15).
- ab. Touch black probe (5) to electrical connector (6), pin A (16).
- ac. Meter shall indicate **zero ohms.**
- ad. Set multimeter range switch to R x 1000.
- ae. Touch black probe (5) to all other pins on electrical connector (6).
- af. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- ag. Set multimeter range switch to R x 1.
- ah. Touch red probe (2) to electrical connector (14), sleeve B (17).
- ai. Touch black probe (5) to electrical connector (6), pin B (18).
- aj. Meter shall indicate **zero ohms**.
- ak. Set multimeter range switch to R x 1000.
- al. Touch black probe (5) to all other pins on electrical connector (6).




- am. Meter shall indicate **1000 ohms** minimum.
- an. Set multimeter range switch to R x 1.
- ao. Touch red probe (2) to electrical connector (14), shell (19).
- ap. Touch black probe (5) to electrical connector (6), pin L (20).
- aq. Meter shall indicate **zero ohms**.
- ar. Set multimeter range switch to R x 1000.
- as. Touch black probe (5) to all other pins on electrical connector (6).
- at. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- au. Set multimeter range switch to R x 1.
- av. Touch red probe (2) to electrical connector (21), pin A (22).
- aw. Touch black probe (5) to electrical connector (6), pin K (23).
- ax. Meter shall indicate **zero ohms**.
- ay. Set multimeter range switch to R x 1000.
- az. Touch black probe (5) to all other pins on electrical connector (6).
- ba. Meter shall indicate **1000 ohms** minimum.




- bb. Set multimeter range switch to R x 1.
- bc. Touch red probe (2) to electrical connector (21), pin B (24).
- bd. Touch black probe (5) to electrical connector (6), pin J (25).
- be. Meter shall indicate **zero ohms**.
- bf. Set multimeter range switch to R x 1000.
- bg. Touch black probe (5) to all other pins on electrical connector (6).
- bh. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- bi. Set multimeter range switch to R x 1.
- bj. Touch red probe (2) to electrical connector (26), center sleeve (27).
- bk. Touch black probe (5) to electrical connector (6), pin E (28).
- bl. Meter shall indicate **zero ohms**.
- bm. Set multimeter range switch to R x 1000.
- bn. Touch black probe (5) to all other pins on electrical connector (6).
- bo. Meter shall indicate **1000 ohms** minimum.




- bp. Set multimeter range switch to R x 1.
- bq. Touch red probe (2) to electrical connector (26), shell (29).
- br. Touch black probe (5) to electrical connector (6), pin F (30).
- bs. Meter shall indicate **zero ohms**.




GO TO NEXT PAGE

- bt. Set multimeter range switch to R x 1.
- bu. Touch red probe (2) to electrical connector (31), sleeve A (32).
- bv. Touch black probe (5) to electrical connector (6), pin D (33).
- bw. Meter shall indicate **zero ohms.**
- bx. Set multimeter range switch to R x 1000.
- by. Touch black probe (5) to all other pins on electrical connector (6)
- bz. Meter shall indicate **1000 ohms** minimum.




- ca. Set multimeter range switch to R x 1.
- cb. Touch red probe (2) to electrical connector (31), sleeve B (34).
- cc. Touch black probe (5) to electrical connector (6), pin C (35).
- cd. Meter shall indicate **zero ohms.**
- ce. Set multimeter range switch to R x 1000.
- cf. Touch black probe (5) to all other pins on electrical connector (6).
- cg. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- ch. Set multimeter range switch to R x 1.
- ci. Touch red probe (2) to electrical connector (36), sleeve A (37).
- cj. Touch black probe (5) to electrical connector (6), pin U (38).
- ck. Meter shall indicate **zero ohms.**
- cl. Set multimeter range switch to R x 1000.
- cm. Touch black probe (5) to all other pins on electrical connector (6).
- cn. Meter shall indicate **1000 ohms** minimum.




- co. Set multimeter range switch to R x 1.
- cp. Touch red probe (2) to electrical connector (36), sleeve B (39).
- cq. Touch black probe (5) to electrical connector (6), pin P (40).
- cr. Meter shall indicate **zero ohms.**
- cs. Set multimeter range switch to R x 1000.
- ct. Touch black probe (5) to all other pins on electrical connector (6).
- cu. Meter shall indicate **1000 ohms** minimum.




GO TO NEXT PAGE

- cv. Set multimeter range switch to R x 1.
- cw. Touch red probe (2) to electrical connector (36), sleeve C (41).
- cx. Touch black probe (5) to electrical connector (6), pin S (42).
- cy. Meter shall indicate **zero ohms**.
- cz. Set multimeter range switch to R x 1000.
- da. Touch black probe (5) to all other pins on electrical connector (6).
- db. Meter shall indicate **1000 ohms** minimum.



- dc. Set multimeter range switch to R x 1.
- dd. Touch red probe (2) to electrical connector (36), sleeve D (43).
- de. Touch black probe (5) to electrical connector (6), pin R (44).
- df. Meter shall indicate **zero ohms**.
- dg. Set multimeter range switch to R x 1000.
- dh. Touch black probe (5) to all other pins on electrical connector (6).
- di. Meter shall indicate **1000 ohms** minimum.

FOLLOW-ON MAINTENANCE:
None



END OF TASK

INITIAL SETUP

Applicable Configurations

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 51 80-00-323-5114

Parts:


Strap

Personnel Required:


Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P


**GO TO NEXT PAGE**

1. Connect electrical connector (1) to dummy connector (2).



GO TO NEXT PAGE


2. Install two clamps (3), two screws (4), and two nuts (5).
3. Install screw (6), clamps (7), and nut (8).
4. Install electrical connector (9) to oil level indicator (10).



B-7-27 3

GO TO NEXT PAGE

5. Install harness assembly (11) to two cushions (12) and two straps (13).
6. Install electrical connector (14) to accessory gearbox chip detector (15).




GO TO NEXT PAGE

NOTE

In following step, it may be necessary to remove lockwire from electrical connector and reorient connector for proper installation. Be sure to lockwire electrical connector if lockwire was removed.

7. Install electrical connector (16) to pickup assembly (17).
8. Install harness assembly (11) to cushion (18) and strap (19).
9. Install harness assembly (11) to two cushions (20) and straps (21).
10. Install electrical connector (22) to oil temperature bulb (23).




GO TO NEXT PAGE

NOTE

Make sure that nut (26) is securely fastened to bracket with long section of nut perpendicular to slot.

11. Install clamp (24), screw (25), and nut (26) to bracket (27).
12. Install electrical connector (28) to ignition igniter (29).

**INSPECT****FOLLOW-ON MAINTENANCE:**

None

END OF TASK

CHAPTER 8

LUBRICATION SYSTEM - MAINTENANCE INSTRUCTIONS

CHAPTER OVERVIEW

This chapter contains maintenance procedures for the lubrication system. It is divided into the following sections and tasks:

<u>SECTION</u>	<u>TASK NO.</u>	<u>TITLE</u>	<u>PAGE</u>
I		MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY, SCAVENGE OIL SCREEN. AND RELATED PARTS	
	8-1	Remove Main Oil Pump, Speed Pickup Drive Assembly, Scavenge Oil Screen, and Related Parts	8-7
	8-2	Disassemble Main Oil Pump. Speed Pickup Drive Assembly, Scavenge Oil Screen, and Related Parts	8-13
	8-3	Clean Main Oil Pump, Speed Pickup Drive Assembly, Scavenge Oil Screen, and Related Parts	8-14
	8-4	Inspect Main Oil Pump, Speed Pickup Drive Assembly. Scavenge Oil Screen, and Related Parts	8-16
	8-5	Assemble Main Oil Pump. Speed Pickup Drive Assembly, Scavenge Oil Screen, and Related Parts	8-18
	8-6	Install Main Oil Pump, Speed Pickup Drive Assembly. Scavenge Oil Screen, and Related Parts	8-19
II		GAS PRODUCER SPEED PICKUP	
	8-7	Remove Gas Producer Speed Pickup	8-27
	8-8	Clean Gas Producer Speed Pickup	8-29
	8-9	Inspect Gas Producer Speed Pickup	8-30
	8-10	Repair Gas Producer Speed Pickup	8-31
	8-11	Install Gas Producer Speed Pickup	8-32
III		OIL COOLER ASSEMBLY	
	8-12	Remove Oil Cooler Assembly	8-35
	8-13	Disassemble Oil Cooler Assembly	8-40
	8-14	Clean Oil Cooler Assembly	8-42
	8-15	Inspect Oil Cooler Assembly	8-43
	8-16	Repair Oil Cooler Assembly	8-44
	8-17	Assemble Oil Cooler Assembly	8-45
	8-18	Install Oil Cooler Assembly	8-47
IV		FLOW PROGRAMMING VALVE	
	8-19	Remove Flow Programming Valve	8-53
	8-20	Clean Flow Programming Valve	8-56
	8-21	Inspect Flow Programming Valve	8-57
	8-22	Install Flow Programming Valve	8-58

<u>SECTION</u>	<u>TASK NO.</u>	<u>TITLE</u>	<u>PAGE</u>
V		OIL TEMPERATURE TRANSMITTER	
	8-23	Remove Oil Temperature Transmitter	8-63
	8-24	Clean Oil Temperature Transmitter	8-65
	8-25	Inspect Oil Temperature Transmitter	8-66
	8-26	Install Oil Temperature Transmitter	8-67
VI		OIL FILLER ASSEMBLY AND OIL FILLER STRAINER	
	8-27	Remove Oil Filler Assembly and Oil Filler Strainer	8-69
	8-28	Disassemble Oil Filler Assembly and Oil Filler Strainer	8-71
	8-29	Clean Oil Filler Assembly and Oil Filler Strainer	8-73
	8-30	Inspect Oil Filler Assembly and Oil Filler Strainer	8-75
	8-31	Repair Oil Filler Assembly and Oil Filler Strainer	8-77
	8-32	Assemble Oil Filler Assembly and Oil Filler Strainer	8-78
	8-33	Install Oil Filler Assembly and Oil Filler Strainer	8-80
VII		OIL FILTER COVER ASSEMBLY AND OIL FILTER ELEMENT	
	8-34	Remove Oil Filter Cover Assembly and Oil Filter Element	8-83
	8-35	Clean Oil Filter Cover Assembly and Oil Filter Element	8-85
	8-36	Inspect Oil Filter Cover Assembly and Oil Filter Element	8-86
	8-37	Repair Oil Filter Cover Assembly and Oil Filter Element	8-87
	8-38	Install Oil Filter Cover Assembly and Oil Filter Element	8-88
VIII		DUAL CHIP DETECTOR	
	8-39	Remove Dual Chip Detector	8-91
	8-40	Disassemble Dual Chip Detector	8-94
	8-41	Clean Dual Chip Detector	8-96
	8-42	Inspect Dual Chip Detector	8-97
	8-43	Repair Dual Chip Detector	8-99
	8-44	Assemble Dual Chip Detector	8-100
	8-45	Test Dual Chip Detector	8-101
	8-46	Install Dual Chip Detector	8-102
IX		OIL LINES	
	8-47	Remove Hose Assembly (Flow Programming Valve Tee to Inlet Housing)	8-107
	8-48	Install Hose Assembly (Flow Programming Valve Tee to Inlet Housing)	8-109
	8-49	Remove Hose Assembly (Flow Programming Valve to Inflight Filling Port Tee)	8-111

<u>SECTION</u>	<u>TASK NO.</u>	<u>TITLE</u>	<u>PAGE</u>
IX	OIL LINES (CONTINUED)		
	8-50	Install Hose Assembly (Flow Programming Valve to Inflight Filling Port Tee)	8-113
	8-51	Remove Hose Assembly (Accessory Gearbox Assembly to Oil Cooler)	8-115
	8-52	Install Hose Assembly (Accessory Gearbox Assembly to Oil Cooler)	8-117
	8-53	Remove Hose Assembly (Oil Cooler to Flow Programming Valve)	8-119
	8-54	Install Hose Assembly (Oil Cooler to Flow Programming Valve)	8-121
	8-55	Remove Hose Assembly (Flow Programming Valve Tee to No. 2 Bearing Pressure Connector)	8-123
	8-56	Install Hose Assembly (Flow Programming Valve Tee to No. 2 Bearing Pressure Connector)	8-125
	8-57	Remove Hose Assembly (Dual Chip Detector to Accessory Gearbox Assembly)	8-127
	8-58	Install Hose Assembly (Dual Chip Detector to Accessory Gearbox Assembly)	8-132
	8-59	Remove Hose Assembly (Dual Chip Detector to Accessory Gearbox Collector)	8-136
	8-60	Install Hose Assembly (Dual Chip Detector to Accessory Gearbox Collector)	8-138
	8-61	Remove Hose Assembly (Dual Chip Detector to Air Diffuser Assembly)	8-140
	8-62	Install Hose Assembly (Dual Chip Detector to Air Diffuser Assembly)	8-142
	8-63	Remove Hose Assembly (Main Oil Pump to Dual Chip Detector)	8-144
	8-64	Install Hose Assembly (Main Oil Pump to Dual Chip Detector)	8-146
	8-65	Remove Tube Assembly (Inlet Housing to Main Oil Pump)	8-148
	8-66	Install Tube Assembly (Inlet Housing to Main Oil Pump)	8-151
	8-67	Remove Tube Assembly (Main Oil Pump to Inlet Housing Oil Scavenge Tee)	8-159
	8-68	Install Tube Assembly (Main Oil Pump to Inlet Housing Oil Scavenge Tee)	8-161
	8-69	Remove Tube Assembly (No. 4 and 5 Bearing Scavenge Tube Assembly to Main Oil Pump Flange)	8-163
	8-70	Install Tube Assembly (No. 4 and 5 Bearing Scavenge Tube Assembly to Main Oil Pump Flange)	8-165
	8-71	Remove Tube Assembly (No. 4 and 5 Bearing Scavenge Connector to Tube Assembly)	8-167
	8-72	Install Tube Assembly (No. 4 and 5 Bearing Scavenge Connector to Tube Assembly)	8-171

<u>SECTION</u>	<u>TASK NO.</u>	<u>TITLE</u>	<u>PAGE</u>
IX	OIL LINES (CONTINUED)		
	8-73	Remove Tube Assembly (No. 2 Bearing Pressure Connector to Tee and Snubber)	8-175
	8-74	Install Tube Assembly (No. 2 Bearing Pressure Connector to Tee and Snubber)	8-177
	8-75	Remove Hose Assembly (Pressure Connector to No. 4 and 5 Bearing Filter)	8-179
	8-76	Install Hose Assembly (Pressure Connector to No. 4 and 5 Bearing Filter)	8-190
	8-77	Remove Hose Assembly (Inlet Housing to Oil Scavenge Tee)	8-201
	8-78	Install Hose Assembly (Inlet Housing to Oil Scavenge Tee)	8-203
	8-79	Remove Hose Assembly (Inlet Housing to Oil Drain Cock)	8-205
	8-80	Install Hose Assembly (Inlet Housing to Oil Drain Cock)	8-208
	8-81	Remove Hose Assembly (Starter Drive to Oil Filler)	8-211
	8-82	Install Hose Assembly (Starter Drive to Oil Filler)	8-213
	8-83	Remove Hose Assembly (Starter Drive to Tube and Hose Assembly)	8-215
	8-84	Install Hose Assembly (Starter Drive to Tube and Hose Assembly)	8-217
	8-85	Remove Tube and Hose Assembly (Accessory Gearbox Collector to Tube Assembly)	8-219
	8-86	Install Tube and Hose Assembly (Accessory Gearbox Collector to Tube Assembly)	8-225
	8-87	Remove Tube Assembly (Tube and Hose Assembly to Accessory Gearbox Assembly)	8-231
	8-88	Install Tube Assembly (Tube and Hose Assembly to Accessory Gearbox Assembly)	8-234
X	STARTER GEARBOX FILTER		
	8-89	Remove Starter Gearbox Filter	8-237
	8-90	Clean Starter Gearbox Filter	8-239
	8-91	Inspect Starter Gearbox Filter	8-240
	8-92	Install Starter Gearbox Filter	8-241
XI	NO. 2 BEARING PRESSURE OIL CONNECTOR		
	8-93	Remove No. 2 Bearing Pressure Oil Connector	8-243
	8-94	Clean No. 2 Bearing Pressure Oil Connector	8-245
	8-95	Inspect No. 2 Bearing Pressure Oil Connector	8-246
	8-96	Install No. 2 Bearing Pressure Oil Connector	8-247
XII	NO. 2 BEARING PRESSURE OIL STRAINER		
	8-97	Remove No. 2 Bearing Pressure Oil Strainer	8-249
	8-98	Clean No. 2 Bearing Pressure Oil Strainer	8-249
	8-99	Inspect No. 2 Bearing Pressure Oil Strainer	8-250
	8-100	Install No. 2 Bearing Pressure Oil Strainer	8-253

<u>SECTION</u>	<u>TASK NO.</u>	<u>TITLE</u>	<u>PAGE</u>
XIII		NO. 4 AND 5 BEARING FILTER	
	8-101	Remove No. 4 and 5 Bearing Filter	8-255
	8-102	Clean No. 4 and 5 Bearing Filter	8-259
	8-103	Inspect No. 4 and 5 Bearing Filter	8-260
	8-104	Install No. 4 and 5 Bearing Filter	8-261
XIV		OIL DRAIN COCK	
	8-105	Remove Oil Drain Cock	8-267
	8-106	Clean Oil Drain Cock	8-269
	8-107	Inspect Oil Drain Cock	8-270
	8-108	Install Oil Drain Cock	8-271
XV		CHIP DETECTOR	
	8-109	Remove Chip Detector	8-273
	8-110	Clean Chip Detector	8-276
	8-111	Inspect Chip Detector	8-277
	8-112	Test Chip Detector	8-279
	8-113	Install Chip Detector	8-280
XVI		OIL LEVEL INDICATOR	
	8-114	Remove Oil Level indicator	8-283
	8-115	Disassemble Oil Level Indicator	8-286
	8-116	Clean Oil Level Indicator	8-289
	8-117	Inspect Oil Level Indicator	8-290
	8-118	Repair Oil Level Indicator	8-292
	8-119	Assemble Oil Level Indicator	8-293
	8-120	Install Oil Level Indicator	8-298
	8-121	Adjust Oil Level Indicator	8-303
XVII		OIL LEVEL FLOAT ASSEMBLY	
	8-122	Remove Oil Level Float Assembly (AVIM)	8-309
	8-123	Disassemble Oil Level Float Assembly (AVIM)	8-312
	8-124	Clean Oil Level Float Assembly (AVIM)	8-313
	8-125	Inspect Oil Level Float Assembly (AVIM)	8-314
	8-126	Repair Oil Level Float Assembly (AVIM)	8-315
	8-127	Assemble Oil Level Float Assembly (AVIM)	8-316
	8-128	Install Oil Level Float Assembly (AVIM)	8-318

SECTION I

MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY, SCAVENGE OIL SCREEN, AND RELATED PARTS

8-1 REMOVE MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY, SCAVENGE OIL SCREEN, AND RELATED PARTS

8-

INITIAL SETUP

Applicable Configurations:

All

Tools:

- Powerplant Mechanic's Tool Kit, NSN 5180-00-323-4944
- Container, 1 Quart
- Crowfoot Attachment, 7/8 inch

Materials:

- Lockwire (E33)
- Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer


Equipment Condition:

Tube Assembly Removed (Inlet Housing to Main Oil Pump) (Task 8-65)

General Safety Instructions:

WARNING


Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.




GO TO NEXT PAGE

8-1 REMOVE MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY, SCAVENGE OIL SCREEN, AND RELATED PARTS (Continued)

1. Disconnect electrical connector (1).



2. Cut three straps (2) and remove three cushions (3). Reposition two harness assemblies (4), and one fuel hose assembly (5).





**8-1 REMOVE MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY,
SCAVENGE OIL SCREEN, AND RELATED PARTS**

8-1

WARNING


Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

3. Disconnect fuel hose assembly (6).**4. Disconnect tube assembly (7).****GO TO NEXT PAGE**

**8-1 REMOVE MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY,
SCAVENGE OIL SCREEN, AND RELATED PARTS (Continued)**

8-1


5. Remove lockwire, two bolts (8), end of tube assembly (9), and packing (10).




GO TO NEXT PAGE

8-1 REMOVE MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY, SCAVENGE OIL SCREEN, AND RELATED PARTS (Continued)

6. Disconnect tube assembly (11). Use 7/8 inch crowfoot attachment.



7. Remove lockwire, four bolts (12), washers (13), main oil pump (14), and packings (15, 16, and 17).




GO TO NEXT PAGE

**8-1 REMOVE MAIN OIL PUMP, S PEED PICKUP DRIVE ASSEMBLY,
SCAVENGE OIL SCREEN, AND RELATED PARTS (Continued)**


8-1

8. Insert 9 inch length of lockwire (E33) (18) through center of screen (19) near base (20) and form loop by twisting ends.



9. Using lockwire (18), **remove screen (19)**. Remove lockwire (18).

FOLLOW-ON MAINTENANCE:
None



END OF TASK

**8-2 DISASSEMBLE MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY,
SCAVENGE OIL SCREEN, AND RELATED PARTS**

8-2

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Crowfoot Attachment, 5/16 - inch

Materials:

None

Personnel Required:

Aircraft Powerplant Repairer


Equipment Condition:

Off Engine Task
Engine Oil System Drained (Task 1-69)
Remove Main Oil Pump Speed Pickup Drive As-
sembly. Scavenge Oil Screen and Related Parts
(Task 8-1)

1. Remove four nuts (1), washers (2), **speed pick-up drive assembly** (3), and gasket (4) from main oil pump (5).
2. **Remove three nuts (6) and cover (7)** from speed pickup drive assembly (3).

FOLLOW-ON MAINTENANCE:

None



END OF TASK

8.3 CLEAN MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY, SCAVENGE OIL SCREEN, AND RELATED PARTS

8.3

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Goggles
Dry, Compressed Air Source

Materials:

Dry Cleaning Solvent (E19)
Gloves (E24)
Lint-Free Cloth (E30)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

Main Oil Pump, Speed Pickup Drive Assembly,
Scavenge Oil Screen, and Related Parts Removed
(Task 8-1)



Main Oil Pump, Speed Pickup Drive Assembly,
Scavenge Oil Screen, and Related Parts Disassembled
(Task 8-2)

General Safety Instructions:

WARNING

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Wear gloves (E24). **Clean oil pump (1)** using dry cleaning solvent (E19) and brush.
2. **Clean exterior of pickup drive assembly (2), and cover (3).** Use dry cleaning solvent (E19) and brush.
3. **Remove any remaining solvent** using clean, dry, lint-free cloth (E30).



GO TO NEXT PAGE

**8-3 CLEAN MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY,
SCAVENGE OIL SCREEN, AND RELATED PARTS (Continued)**

8-3

4. **Clean scavenge oil screen (4).** Use dry cleaning solvent (E19) and brush.


WARNING

When using compressed air for cleaning, use approved protective equipment or eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

5. Wear goggles. **Blow dry screen (4)** using clean, dry, compressed air.

FOLLOW-ON MAINTENANCE:

Inspect Main Oil Pump, Speed Pickup Drive Assembly, Scavenge Oil Screen, and Related Parts (Task 8-4).

**END OF TASK**

8-4 INSPECT MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY, SCAVENGE OIL SCREEN, AND RELATED PARTS

8-4

INITIAL SETUP

Applicable Configurations:

All

Tools:

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

None

Personnel Required:

Aircraft Powerplant inspector




References:

Task 1-111

Equipment Condition:

Off engine Task

1. **Inspect main oil pump (1).** There shall be no cracks in housing (2) or, nicks or cracks in splines of gearshaft (3).
2. **Inspect gearshaft (3).** There shall be no improper wear pattern. Inspect gearshaft (3) for wear (Ref. Task 1-109).
3. **Inspect speed pickup drive assembly (4).** There shall be no cracks in housing (5), or nicks or cracks in splines of driveshaft (6).
4. **Inspect driveshaft (6).** There shall be no improper wear pattern. Inspect driveshaft (6) for wear (Ref. Task 1-109).
5. **Inspect** for missing teeth (7) on **wheel (8)** in air gap adjustment hole (9).
6. **Inspect cover (10).** There shall be no cracks.
7. Inspect scavenge oil screen (11). There shall be no tears in screen.



FOLLOW-ON MAINTENANCE:

None

END OF TASK

**8-5 ASSEMBLE MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY,
SCAVENGE OIL PUMP, AND RELATED PARTS**

8-5

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114
Crowfoot Attachment, 5/16 - inch

Materials:

None

Parts:

Gasket

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P

Equipment Condition:


Off Engine Task
Disassemble Main Oil Pump, Speed Pickup Drive
Assembly, Scavenge Oil Screen and Related Parts
(Task 8-2)

1. **Install** gasket (1), **speed pickup drive assembly (2)**, four washers (3), and nuts (4) on serviceable main oil pump (5).
2. **Install cover (6)**, three nuts (7), on speed pickup drive assembly (2).

INSPECT

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

8-6 INSTALL MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY,
SCAVENGE OIL SCREEN, AND RELATED PARTS

8-6

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114
Torque Wrench, 30-150 Inch-Pounds
Crowfoot Attachment, 5/16 inch
Crowfoot Attachment, 7/8 inch

Materials:

Lockwire (E33)

Parts:

Packings
Gasket
Straps

Personnel Required:


Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE



**8-6 INSTALL MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY,
SCAVENGE OIL SCREEN, AND RELATED PARTS (Continued)**

8-6

NOTE

If main oil pump is a replacement, do steps 1 thru 6. If same oil pump that was removed is to be installed, omit steps 1 thru 6.


1. **Remove nipple (1), and packing (2).**
2. **Remove two bolts (3), flange assembly (4), and packing (5).**
3. **Remove nuts (6), washers (7), speed pickup drive assembly (8), and gasket (9).**
4. **Install gasket (9), speed pickup drive assembly (8), four washers (7), and nuts (6) on serviceable main oil pump (10).**
5. **Install packing (5), flange assembly (4), and two bolts (3) on serviceable main oil pump (10) and lockwire. Use lockwire (E33).**
6. **Install packing (2) and nipple (1) on serviceable main oil pump (10).**
7. **Install scavenge oil screen (11) in hole (12) in accessory gearbox assembly (13).**



GO TO NEXT PAGE

8-6 **INSTALL MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY,
SCAVENGE OIL SCREEN, AND RELATED PARTS (Continued)**

8. Install three packings (14, 15, and 16) on main oil pump (10).





GO TO NEXT PAGE

**8-6 INSTALL MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY,
SCAVENGE OIL SCREEN, AND RELATED PARTS (Continued)**

8-6

9. Position main oil pump (10) over accessory gearbox assembly (13).
10. If required, rotate main oil pump (10) slightly left or right to align splines (17) with coupling in hole (18).
11. **Install main oil pump (10)** on accessory gearbox assembly (13).
12. **Install bolt (19), bolt (20), two self-locking bolts (21), and four washers (22).** Torque bolts (19, 20, and 21) to 70 to 75 inch-pounds. Lockwire bolts (19 and 20). Use lockwire (E33).





GO TO NEXT PAGE

8-6 **INSTALL MAIN OIL. PUMP, SPEED PICKUP DRIVE ASSEMBLY, SCAVENGE OIL SCREEN. AND RELATED PARTS (Continued-**

13. **Connect tube assembly (23) to flange assembly (24).** Use 7/8 inch crowfoot attachment.

14. **Install packing (25), end of tube assembly (26), and two bolts (27) on main oil pump (10).** Lockwire bolts (27). Use lockwire (E33).





GO TO NEXT PAGE

15. Connect tube assembly (28) to nipple (1).

WARNING

Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.


16. Connect fuel hose assembly (29) to check valve (30).



GO TO NEXT PAGE

8-6 **INSTALL MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY,
SCAVENGE OIL SCREEN, AND RELATED PARTS (Continued)**

17. **Install two harness assemblies (31 and 32) and fuel hose assembly (33) into three cushions(34, 35, and 36). Install strap (37) on each cushion (34, 35, and 36).**



GO TO NEXT PAGE


**8-6 INSTALL MAIN OIL PUMP, SPEED PICKUP DRIVE ASSEMBLY,
SCAVENGE OIL SCREEN, AND RELATED PARTS (Continued)**

8-6

18. Connect electrical connector (38) to GP speed pickup (39).

INSPECT**FOLLOW-ON MAINTENANCE:**

Install Tube Assembly (Inlet Housing to Main Oil Pump) (Task 8-66).

**END OF TASK**

8-25/(8-26 blank)

SECTION II

GAS PRODUCER SPEED PICKUP

8-7 REMOVE GAS PRODUCER SPEED PICKUP

8-7

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Materials:**


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.





GO TO NEXT PAGE

1. Disconnect electrical connector (1) from gas producer speed pickup (2).
2. Remove lockwire and gas producer speed pickup (2) from housing (3).

FOLLOW-ON MAINTENANCE:

None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

- Powerplant Mechanic's Tool Kit, NSN 5180-00-323-4944
- Goggles
- Dry, Compressed Air Source

Materials:

- Dry Cleaning Solvent (E19)
- Gloves (E24)
- Lint-Free Cloth (E30)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

- Off Engine Task
- Remove Gas Producer Speed Pickup (Task 8-7)

General Safety Instructions:

WARNING

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

- Clean gas producer speed pickup (1) as follows:
 - Wear gloves (E24) and clean gas producer speed pickup (1). Use lint-free cloth (E30) dampened with dry cleaning solvent (E19).
 - Use dry, lint-free cloth (E30) to remove solvent.


WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

- Wear goggles. Blow dry electrical connector (2) and inside surfaces (3). Use clean, dry, compressed air.

FOLLOW-ON MAINTENANCE:

Inspect Gas Producer Speed Pickup (Task 8-9).



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Technical Inspection Tool Kit,
NSN 5180-00-323-5114
Multimeter

Materials:

None

Personnel Required:

Aircraft Powerplant Inspector

Equipment Condition:




Off Engine Task

1. **Inspect gas producer speed pickup (1)** as follows:

- a. **Inspect body of gas producer speed pickup (1).** There shall be no cracks, distortion or damaged threads.
- b. **Inspect two electrical pins (2).** There shall be no broken, corroded or bent pins (2) or damaged insulation (3).
- c. **Inspect tip (4) of gas producer speed pickup (1).** There shall be no broken or worn tips (4) or cracks in insulation (5).
- d. **Inspect coil resistance of gas producer speed pickup (1).** Use multimeter with function switch set to ohms and range set to R x 10. Place one lead to pin A and the other lead to pin B. The multimeter should not read less than 98 ohms and not greater than 132 ohms resistance.

FOLLOW-ON MAINTENANCE:

None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114
Goggles
Dry, Compressed Air Source

Materials:

Crocus Cloth (E16)

Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector

Equipment Condition:

Off Engine Task

NOTE

This repair is allowed provided it does not cause pins to break or crack.

1. Straighten bent pins (1) of electrical connector (2). Using long-nose pliers, gently move pins (1) until they are straight.
2. Remove corrosion from pins (1) of electrical connector (2). Polish pins using in and out motion over entire length of pin until corrosion is removed. Use crocus cloth (E16).

WARNING


When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

3. Wear goggles. Remove loosened particles from electrical connector (2), using clean, dry, compressed air.

INSPECT

FOLLOW-ON MAINTENANCE:

None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

- Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
- Technical Inspection Tool Kit,
NSN 5180-00-323-5114
- Feeler Gage, 1/4 Wide. 0.010 Inch

Materials:


Lockwire (E33)

Personnel Required:

- Aircraft Powerplant Repairer
- Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P





GO TO NEXT PAGE

1. Install gas producer speed pickup (1) as follows:
 - a. Screw on locknut (2) on gas producer speed pickup (1) until locknut stops.
 - b. Engage threads of gas producer speed pickup (1) and housing (3).
 - c. Establish proper air gap as follows:
 - (1) Remove three nuts (4) and cover (5) from housing (3).

NOTE

In following step (2), gear tooth must be aligned under center of speed pickup.

- (2) Insert 1/4 inch wide, 0.010 inch feeler gage (6) into housing adjustment hole (7).




GO TO NEXT PAGE

- (3) Screw in gas producer speed pickup (1) until light drag is felt against feeler gage (6) when moved in and out of housing adjustment hole (7).
 - (4) Hold gas producer speed pickup (1) stationary and screw down locknut (2) against housing (3) and snug tighten locknut.
 - (5) Check for light drag on feeler gage (6). If gap is incorrect, loosen locknut (2) and repeat steps (2) thru (5).
 - (6) Lockwire locknut (2) to housing lockwire hole (8). Use lockwire (E33).
 - (7) Install cover (5) and three nuts (4).
- d. Connect electrical connector (9) to gas producer speed pickup (1).

INSPECT**FOLLOW-ON MAINTENANCE:**

None

**END OF TASK**

SECTION III

OIL COOLER ASSEMBLY

8-12 REMOVE OIL COOLER ASSEMBLY

8-12

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Container, 2 Quart

Materials:

Wiping Rag (E64)

Personnel Required:


Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



WARNING

Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE



1. Disconnect hose assembly (1).



2. Disconnect hose assembly (2).

GO TO NEXT PAGE



3. Disconnect hose assembly (3).



4. Disconnect hose assembly (4).

GO TO NEXT PAGE

5. Remove nut (5), bolt (6), and two washers (7).





6. Remove lockwire, bolt (8), and washer (9).

GO TO NEXT PAGE

NOTE

If flow programming valve has already been removed, do step 7. If flow programming valve has not been removed, omit step 7.

7. Remove lockwire, bolt (10), washer (11), oil cooler assembly (12), bracket (13), and bracket (14).



8. Remove lockwire, bolt (10), washer (11) and oil cooler assembly (12).

FOLLOW-ON MAINTENANCE:

None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Deep-Style Socket, 1-Inch
Machinist's Vise
Jaw Caps

Materials:

Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task
Oil Cooler Assembly Removed (Task 8-12)

General Safety Instructions:**WARNING**




Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

WARNING |

Turbine fuels are very flammable. They may cause drying and irritation of skin or eyes. Handle only in well-ventilated areas away from heat and open flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

GO TO NEXT PAGE

1. Remove tube assembly (1) and packing (2). Use vise with jaw caps.
2. Using 1-inch deep-style socket, remove reducer (3) and packing (4).



3. Using 1-inch deep-style socket, remove reducer (5) and packing (6).
4. Remove nipple (7) and packing (8).

FOLLOW-ON MAINTENANCE:

None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All



Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Materials:**Dry Cleaning Solvent (E19)
Gloves (E24)**Personnel Required:**

Aircraft Powerplant Repairer

Equipment Condition:Off Engine Task
Oil Cooler Assembly Removed (Task 8-12)
Oil Cooler Assembly Disassembled (Task 8-13)**General Safety Instructions:****WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Wear gloves (E24). Flush internal passages of oil cooler (1) with dry cleaning solvent ((E19).
2. Clean external surfaces of oil cooler (1). Use dry cleaning solvent (E19) and brush.
3. Allow to drain and air-dry.
4. Clean tube assembly (2). Use dry cleaning solvent (E19).

**FOLLOW-ON MAINTENANCE:**

Inspect Oil Cooler Assembly (Task 8-15).

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**



None

Personnel Required:

Aircraft Powerplant Inspector

Equipment Condition:

Off Engine Task



1. Inspect oil cooler (1). There shall be no cracks.
2. Inspect tube assembly (2). There shall be no cracks, dents or bends.

FOLLOW-ON MAINTENANCE:

None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All


Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**Acid Swabbing Brush
Engine Gray Enamel (E26)**Personnel Required:**Aircraft Powerplant Repairer
Aircraft Powerplant Inspector**References:**

Task 1-110

Equipment Condition:

Off Engine Task

-
1. Repair damaged paint on oil cooler assembly (1) (Ref. Task 1-110). Use engine gray enamel (E26).

**INSPECT****FOLLOW-ON MAINTENANCE:**

None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit.

NSN 5180-00-323-4944

Technical Inspection Tool Kit,

NSN 5180-00-323-5114

Deep Style Socket, 1-Inch

Machinist's Vise

Jaw Caps

Materials:

None

Parts:

Packings

Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector



References:

TM 1-2840-252-23P


Equipment Condition:

Off Engine Task

1. Install packing (1) and nipple (2) in oil cooler (3). Use vise and jaw caps.
2. Install packing (4) and reducer (5) in oil cooler (3). Use 1-inch deep-style socket.
3. Install packing (6) and reducer (7) in oil cooler (3). Use 1-inch deep-style socket.

**GO TO NEXT PAGE**

4. Install packing (8) and tube assembly (9) in oil cooler (3).



INSPECT

FOLLOW-ON MAINTENANCE:

None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit

NSN 5180-00-323-4944

Technical Inspection Tool Kit.

NSN 5180-00-323-5114


Materials:

Lockwire (E33)

Personnel Required:

Aircraft Powerplant Repairer



Aircraft Powerplant Inspector

**GO TO NEXT PAGE**

NOTE



If flow programming valve is not installed, do step 1.. If flow programming valve is installed, omit step 1..

1. Install oil cooler assembly (1) on interstage airbleed actuator (2) and bracket (3). Position bracket (4), and bracket (5) on air bleed actuator (2). Loosely install bolt (6) and washer (7).
2. Install oil cooler assembly (1) on interstage-airbleed actuator (2) and bracket (3). Loosely install bolt (6) and washer (7).





GO TO NEXT PAGE

3. Install bolt (8), two washers (9), and nut (10).
4. Install bolt (11), washer (12), and tighten bolt (6). Lockwire bolts (6) and (11). Use lockwire (E33).





GO TO NEXT PAGE

5. Connect hose assembly (13) to nipple (14).
6. Connect hose assembly (15) to reducer (16).



GO TO NEXT PAGE

7. Connect hose assembly (17) to reducer (18).
8. Connect hose assembly (19) to tube assembly (20).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

SECTION IV

FLOW PROGRAMMING VALVE

8-19 REMOVE FLOW PROGRAMMING VALVE

8-19

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's-Tool Kit,
NSN 5180-00-323-4944

Materials:

Wiping Rag (E64)


Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:




WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted areas of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE

1. Disconnect hose assembly (1).
2. Disconnect hose assemblies (2) and (3).
3. Disconnect hose assembly (4).





GO TO NEXT PAGE

NOTE

If oil cooler assembly has already been removed, do step 4.. If oil cooler assembly has not been removed, omit step 4..

4. **Remove** three nuts (5), three bolts (6), three washers (7), flow programming valve (8), bracket (9), and bracket (10).
5. **Remove** three nuts (5), three bolts (6), three washers (7), and flow programming valve (8).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Goggles

Dry, Compressed Air Source

Materials:

Dry Cleaning Solvent (E19)

Gloves (E24)

Lint-Free Cloth (E30)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

Flow Programming Valve Removed (Task 8-19)

General Safety Instructions:**WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Wear gloves (E24). **Clean flow programming valve (1)**. Use dry cleaning solvent (E19) and brush.


WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

2. Wear goggles. **Blow dry flow programming valve (1)**, using clean, dry, compressed air.

FOLLOW-ON MAINTENANCE:

Inspect Flow Programming Valve (Task 8-21).

**END OF TASK**

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Materials:**

None

Personnel Required:


Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

1. Inspect flow programming valve (1).

- a. There shall be no nicks, scratches, or gouges on sealing surface.
- b. There shall be no damaged threads on unions (2 and 3), and tee (4).
- c. Unions (2 and 3) shall not be loose. If unions are loose, tighten unions.



FOLLOW-ON MAINTENANCE:

None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:


Lockwire (E33)

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P



GO TO NEXT PAGE

NOTE



If flow programming valve is a replacement, do steps 1. thru 5.. If same flow programming valve that was removed is to be installed, omit steps 1. thru 5..

1. **Remove two unions (1) and packings (2) from removed flow programming valve (3).**
2. **Remove tee (4), nut (5), and packing (6) from removed flow programming valve (3).**
3. **Install nut (5) on tee (4). Install packing (6) on tee (4).** Position nut to. make sure packing is in groove between two sets of threads on tee.
4. **Install tee (4) on serviceable flow programming valve (3).**
5. **Install two packings (2) and unions (1) on serviceable flow programming valve (3).**

NOTE




If oil cooler assembly is not installed, do step 6.. If oil cooler assembly is installed, omit step 6..

6. **Install flow programming valve (3), bracket (7) , bracket (8), three bolts (9), three washers (10), and three nuts (11).**




GO TO NEXT PAGE

7. Install flow programming valve (3), three bolts (9), three washers (10), and three nuts (11).
8. Connect hose assembly (12) to union (1).
9. Connect hose assemblies (13) and (14) to tee (4).



GO TO NEXT PAGE

10. Connect hose assembly (15) to union (1).



INSPECT

FOLLOW-ON MAINTENANCE:
None

END OF TASK

SECTION V

OIL TEMPERATURE TRANSMITTER

8-23 REMOVE OIL TEMPERATURE TRANSMITTER**8-23**

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Materials:**


None

Personnel Required:



Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

**GO TO NEXT PAGE**

1. Remove electrical connector (1).
2. Remove lockwire, oil temperature transmitter (2), and gasket (3).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

Dry Cleaning Solvent (E19)
Gloves (E24)
Lint-Free Cloth (E30)

Personnel Required:


Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task
Oil Temperature Transmitter Removed (Task
8-23)

General Safety Instructions:**WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes: Get medical attention for eyes.



1. Wear gloves (E24). **Clean oil temperature transmitter (1)**. Use dry cleaning solvent (E19) and brush.
2. **Wipe dry** using clean, dry, lint-free cloth (E30).

FOLLOW-ON MAINTENANCE:

Inspect Oil Temperature Transmitter (Task 8-25).

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

None

Personnel Required:


Aircraft Powerplant Inspector

Equipment Condition:

Off Engine Task

1. **Inspect oil temperature transmitter (1).** as follows:

- a. There shall be no cracks.
- b. There shall be no damaged threads.



FOLLOW-ON MAINTENANCE:

None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:


Lockwire (E33)

Personnel Required:



Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P

**GO TO NEXT PAGE**

1. **Install gasket (1) and oil temperature transmitter (2) in accessory gearbox assembly (3).** Lockwire oil temperature transmitter (2). Use lockwire (E33).
2. **Install electrical connector (4) on oil temperature transmitter (2).**

**INSPECT****FOLLOW-ON MAINTENANCE:**

None

END OF TASK

SECTION VI

OIL FILLER ASSEMBLY AND OIL FILLER STRAINER

8-27 REMOVE OIL FILLER ASSEMBLY AND OIL FILLER STRAINER

8-27

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft

Powerplant

Repairer





GO TO NEXT PAGE

1. Remove lockwire, three bolts (1) and oil filler assembly (2).

CAUTION

If tools must be used to remove strainer care must be exercised to prevent damage to mating surfaces.

2. Remove oil filler strainer (3) and packing (4).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Materials:**

None

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:



Off Engine Task

Oil Filler Assembly and Oil Filler Strainer

Removed (Task8-27)


1. **Remove cap assembly (1)** as follows:

- a. Lift handle (2).
- b. Turn handle (2) counterclockwise and remove cap assembly (1).



GO TO NEXT PAGE

- c. Remove packing (3).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

8-29 CLEAN OIL FILLER ASSEMBLY AND OIL FILLER STRAINER (Continued)

8-29

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Goggles

Dry, Compressed Air Source

Materials:

Dry Cleaning Solvent (E19)

Gloves (E24)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

Oil Filler Assembly and Oil Filler Strainer Removed
(Task 8-27)

Oil Filler Assembly and Oil Filler Strainer Disassembled (Task 8-28)

General Safety Instructions:**WARNING**


Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

1. Clean oil filter assembly (1) as follows:

- a. Wear gloves (E24). Immerse filler assembly (1) in dry cleaning solvent (E19) and agitate. Use brush on inner surface.
- b. Wear goggles. Blow dry any remaining solvent. Use clean, dry, compressed air.




GO TO NEXT PAGE

2. Clean oil filler strainer (2) as follows:

- a. Immerse in dry cleaning solvent (E19) and agitate. Use brush on screen (3).
- b. Blow dry screen (3). Use clean, dry, compressed air.

FOLLOW-ON MAINTENANCE:

Inspect Oil Filler Assembly and Oil Filler Strainer (Task 8-30).

**END OF TASK**

8-30 INSPECT OIL FILLER ASSEMBLY AND OIL FILLER STRAINER**8-30**

INITIAL SETUP

Applicable Configurations:

All

Tools:

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

None

Personnel Required:



Aircraft Powerplant Inspector

Equipment Condition:

Off Engine Task


1. Inspect pan mounting surface (1). There shall be no cracks.

2. Inspect packing sealing surface (2). There shall be no nicks, dents and scratches greater than 0.015 inch. Inspect cap assembly (3). Spring (4) shall not be broken. There shall be no nicks, dents or scratches deeper than 0.015 inch in packing groove (5). Locking tabs (6) shall not be bent or distorted.



GO TO NEXT PAGE

3. Inspect oil filler strainer (7). There shall be no broken wires (8).



FOLLOW-ON MAINTENANCE:

None

END OF TASK

8-31 REPAIR OIL FILLER ASSEMBLY AND OIL FILLER STRAINER**8-31****INITIAL SETUP****Applicable Configurations:**

All

Tools:

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

Crocus Cloth (E16)

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

Equipment Condition:


Off Engine Task

1. Repair nicks, dents and scratches in packing sealing surface (1) or in packing groove (2) as follows:

NOTE

Repair is allowed only if depth after repair is not more than 0.015 inch.

- a. Blend-repair using file.
- b. Polish repaired area. Use crocus cloth (E16).

**INSPECT****FOLLOW-ON MAINTENANCE:**

None

END OF TASK

8-32 ASSEMBLE OIL FILLER ASSEMBLY AND OIL FILLER STRAINER**8-32**

INITIAL SETUP

Applicable Configurations:

All

Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

None

Personnel Required:Aircraft Powerplant Repairer
Aircraft Powerplant Inspector**Parts:**

Packing



References:

TM 1-2840-252-23P

Equipment Condition:

Off Engine Task

1. **Install packing (1)** in groove (2) of cap assembly (3).
2. Align ends of lug (4) with slots (5) and **install cap assembly (3)** in pan (6).




GO TO NEXT PAGE

**8-32 ASSEMBLE OIL FILLER ASSEMBLY AND OIL FILLER STRAINER
(Continued)**

8-32

3. Turn handle (7) 1/8-turn clockwise and press down.

**INSPECT****FOLLOW-ON MAINTENANCE:**

None

END OF TASK

8-33 INSTALL OIL FILLER ASSEMBLY AND OIL FILLER STRAINER**8-33**

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Technical Inspection Tool Kit,

NSN 5180-00-323-5114

Materials:

Lockwire (E33)

Parts:

Packing


Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector



References:

TM 1-2840-252-23P



GO TO NEXT PAGE

- 1. Install packing (1) in groove (2) in housing (3).
- 2. Install oil filler strainer (4) in housing (3).




3. Install oil filler assembly (5) and three bolts (6) on housing (3). Lockwire bolts (6). Use lockwire (E33)

INSPECT

FOLLOW-ON MAINTENANCE:

None



END OF TASK

SECTION VII
OIL FILTER COVER ASSEMBLY AND OIL FILTER ELEMENT

8-34 REMOVE OIL FILTER COVER ASSEMBLY AND OIL FILTER ELEMENT

8-34

INITIAL SETUP

General Safety Instructions:

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
 NSN 5180-00-323-4944
 Container, 1-Quart

Materials:

Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

References:


Task 1-80

Equipment Condition:

Engine Oil System Drained (Task 1-69)

WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE



**8-34 REMOVE OIL FILTER COVER ASSEMBLY AND OIL FILTER ELEMENT
(Continued)**

8-34

1. **Disconnect hose assembly (1)** and remove gasket (2) from tee (3).
2. **Remove** three nuts (4) and three washers (5). Remove lockwire and oil filtercover assembly (6).
3. Remove packing (7) from accessory gearbox assembly (8).
4. **Remove oil filter element (9)** from oil filter cover assembly (6) and remove packings (10 and 11).
5. **Inspect oil filter element (9)**. There shall be no contamination. If contamination is found, inspect contaminated oil system (Ref. Task 1-80).

FOLLOW-ON MAINTENANCE:

None


END OF TASK

8-35 CLEAN OIL FILTER COVER ASSEMBLY (VBL) AND OIL FILTER ELEMENT**8-35****INITIAL SETUP****Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Goggles

Dry, Compressed Air Source

Materials:

Dry Cleaning Solvent (E19)

Gloves (E24)

Lint-Free Cloth (E30)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

Engine Oil System Drained (Task 1-69)

Oil Filter Cover Assembly and Oil Filter

Element Removed (Task 8-34)

General Safety Instructions:**WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Clean oil filter cover assembly (1) as follows:

- a. Wear gloves (E24). Immerse and agitate oil filter cover assembly (1) in dry cleaning solvent (E19). Use brush on outside surfaces.
- b. Wipe outside surfaces dry with clean, dry, lint-free cloth (E30).


WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

- c. Wear goggles. Blow dry internal and external surfaces using clean, dry, compressed air.

FOLLOW-ON MAINTENANCE:

Inspect Oil Filter Cover Assembly and Oil Filter Element (Task 8-36).

**END OF TASK**

8-36 INSPECT OIL FILTER COVER ASSEMBLY AND OIL FILTER ELEMENT**8-36**

INITIAL SETUP

Applicable Configurations:

All

Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

None

Personnel Required:

Aircraft Powerplant Inspector

Equipment Condition:

Off Engine Task

1. Inspect oil filter cover assembly (1) as follows:


- a. There shall be no cracks.
- b. There shall be no nicks, dents or scratches deeper than 0.015 inch.
- c. There shall be no nicks, dents or scratches deeper than 0.010 inch on packing grooves (3 and 4).

2. Inspect oil filter element (2) as follows:

- a. There shall be no damage.
- b. There shall be no contamination. If contamination is found, inspect contaminated oil system (Ref. Task 1-80).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

8-37 REPAIR OIL FILTER COVER ASSEMBLY AND OIL FILTER ELEMENT**8-37****INITIAL SETUP****Applicable Configurations:**

All


Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**Carborundum Stone (E11)
Crocus Cloth (E16)**Personnel Required:**Aircraft Powerplant Repairer
Aircraft Powerplant Inspector**Equipment Condition:**

Off Engine Task

1. **Repair nicks, dents, and scratches on oil filter cover assembly (1)** up to 0.015 inch deep. Blend repair. Use carborundum stone (E11).
2. Final polish using crocus cloth (E16).

INSPECT**FOLLOW-ON MAINTENANCE:**

None

**END OF TASK**

8-38 INSTALL OIL FILTER COVER ASSEMBLY AND OIL FILTER ELEMENT**8-38**

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Torque Wrench, 30-150Inch-Pounds

Materials:

Lockwire (E33)

Parts:

Gasket

Oil Filter Element

Packings


Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P




GO TO NEXT PAGE

NOTE

If oil filter cover assembly is a replacement, do steps 1 and 2. If same oil filter cover assembly that was removed is to be installed, omit steps 1 and 2.

- 1. **Remove plug (1) and packing (2) from removed oil filter cover assembly (3).**
- 2. **Install plug (1) and packing (2) on serviceable oil filter cover assembly (3).**
- 3. Install packings (4 and 5) on oil filter element(6).
- 4. **Install oil filter element (6) into accessory gearbox assembly (7).**
- 5. Install packing (8) into oil filter cover assembly packing groove (9).
- 6. **Install oil filter cover assembly (3),** on accessory gearbox assembly (7). Install three washers (10) and three nuts (11).




8-38 INSTALL OIL FILTER COVER ASSEMBLY AND OIL FILTER ELEMENT

7. **Check if plug (1) is tight** , and re-lockwire if required. Use lockwire (E33).
8. Install gasket (12) on tee (13) and **connect hose assembly (14) to tee (13)**.

INSPECT**FOLLOW-ON MAINTENANCE:**

Service Engine Oil System (Task 1-68).

**END OF TASK**

SECTION VIII DUAL CHIP DETECTOR

8-39 REMOVE DUAL CHIP DETECTOR

8-39

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Container, 1-Quart

Materials:

Wiping Rag (E64)


Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:

WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.






GO TO NEXT PAGE

8-39. REMOVE DUAL CHIP DETECTOR (Continued)

8-39



1. Disconnect hose assembly (1).
2. Disconnect hose assembly (2).
3. Disconnect hose assembly (3).



GO TO NEXT PAGE

- 4. Disconnect hose assembly (4).
- 5. Remove lockwire, three bolts (5), and dual chip detector (6).

FOLLOW-ON MAINTENANCE:
None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Vise

Jaw Caps

Materials:

Wiping Rag (E64)

Personnel Required:

Aircraft-Powerplant Repairer

Equipment Condition:

Off Engine Task

Dual Chip Detector Removed (Task 8-39)

References:

Task 1-80

General Safety Instructions:

WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

1. Remove lockwire, two magnetic chip detectors (1) and packings (2). Use vise with jaw caps.



CAUTION

When removing filter from connector, be careful not to push in or deform screen of filter. Pushed in or deformed screen are cause for rejection.

NOTE

The following step applies to both magnetic chip detectors.

2. Unscrew and remove filter (3) from connector (4).




GO TO NEXT PAGE

8-40 DISASSEMBLE DUAL CHIP DETECTOR (Continued)**8-40**

3. Inspect chip detector filter (3). There shall be no visible chips on screen. If numerous chips are found on the screen, it is an indication of component distress. Inspect the oil system for contamination (Ref. Task 1-80).
4. Inspect chip detector connector (4). There shall be no visible chips on the magnetic probe. If chips are found on the probe, it is an indication of component distress. Inspect the oil system for contamination (Ref. Task 1-80).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

8-41 CLEAN DUAL CHIP DETECTOR**8-41****INITIAL SETUP****Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Goggles

Dry, Compressed Air Source

Materials:

Dry Cleaning Solvent (E19)

Gloves (E24)

Lint-Free Cloth (E30)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

Dual Chip Detector Removed (Task 8-39)

Dual Chip Detector Disassembled (Task 8-40)

General Safety Instructions:**WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Wear gloves (E24). Clean housing (1) and two filters (2). Use dry cleaning solvent (E19) and brush.



WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

2. Wear goggles. Blow dry housing (1) and filters (2), using clean, dry, compressed air.
3. Clean two connectors (3) with lint-free cloth (E30) dampened in dry cleaning solvent (E19)

FOLLOW-ON MAINTENANCE:

Inspect Dual Chip Detector (Task 8-42).

**END OF TASK**

8-42 INSPECT DUAL CHIP DETECTOR**8-42****INITIAL SETUP****Applicable Configurations:**

All

Tools:

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

None

Personnel Required:

Aircraft Powerplant Inspector

References:

Task 1-80

Equipment Condition:

Off Engine Task

1. Inspect housing (1). There shall be no cracks.



NOTE

Following steps apply to both filters.

2. Inspect filter (2).
 - a. There shall be no tears, punctures, or broken wires in screen (3).
 - b. Screen (3) shall not be pushed in or broken away from filter (2).
 - c. There shall be no contamination.

NOTE

If there is contamination, further inspection of oil system must be done to determine cause. Inspect contaminated oil system (Ref. Task 1-80).

**GO TO NEXT PAGE**


NOTE

Following steps apply to both connectors.

- 3. Inspect connector (4).
 - a. There shall be no cracks in phenolic insert (5).
 - b. Pin (6) shall not be broken or bent.
 - c. There shall be no corrosion on pin (6).

FOLLOW-ON MAINTENANCE:

None



8-43 REPAIR DUAL CHIP DETECTOR**8-43****INITIAL SETUP****Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Technical Inspection Tool Kit,

NSN 5180-00-323-5114

Goggles

Dry, Compressed Air Source

Materials:

Crocus Cloth (E16)

Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector

Equipment Condition:

Off Engine Task

NOTE

This repair is allowed, provided it does not cause pin to break or crack.

1. Straighten bent pin (1) of connector (2). Use long-nose pliers to gently move pin (1) until it is straight.
2. Remove corrosion from pin (1) of connector (2). Polish pin, using in and out motion over entire length of pin until corrosion is removed. Use crocus cloth (E16).



WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

3. Wear goggles. Remove loosened particles, using clean, dry, compressed air.

INSPECT**FOLLOW-ON MAINTENANCE:**

None

**END OF TASK**

8-44 ASSEMBLE DUAL CHIP DETECTOR**8-44****INITIAL SETUP****Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Technical Inspection Tool Kit,

NSN 5180-00-323-5114

Vise

Jaw Caps

Materials:

Lockwire (E33)

Parts:

Packings

Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P

Equipment Condition:

Off Engine Task

NOTE

The following step applies to both magnetic chip detectors.



CAUTION

When installing filter on connector, be careful not to push in or deform screen or filter. Pushed in or deformed screen may cause false chip indications.

1. Install filter (1) on connector (2).
2. Install two packings (3) and magnetic chip detectors (4) in housing (5). Lockwire chip detector (4). Use lockwire (E33). Use vise with jaw caps.

INSPECT**FOLLOW-ON MAINTENANCE:**

Test Dual Chip Detector (Task 8-45).

**END OF TASK**

8-45 TEST DUAL CHIP DETECTOR**8-45**

INITIAL SETUP

Applicable Configurations:

All

Tools:

Multimeter

Materials:

None

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

1. Measure insulation resistance of magnetic chip detectors (1) as follows: Use multimeter.


NOTE

The following steps apply to both magnetic chip detectors.

- a. Set multimeter range switch to R x 1000.
- b. Touch red probe (2) to pin (3).
- c. Touch black probe (4) to threads (5).
- d. Meter shall indicate 10 000 ohms, minimum.

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

8-46 INSTALL DUAL CHIP DETECTOR**8-46**

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

Lockwire (E33)

Parts:


Packing

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P






GO TO NEXT PAGE

NOTE



If dual chip detector is a replacement, do steps 1 through 4. If same dual chip detector that was removed is to be installed, skip steps 1 through 4.

- 1. Remove three unions (1) and packings (2) from removed dual chip detector (3).
- 2. Remove reducer (4) and packing (5) from removed dual chip detector (3).
- 3. Install packing (5) and reducer (4) in serviceable dual chip detector (6).



8-46 INSTALL DUALCHIP DETECTOR (Continued)




4. Install three packings (2) and unions (1) in serviceable dual chip detector (6).
5. Install dual chip detector (6) and three bolts (7). Lockwire bolts (7). Use lockwire (E33).



GO TO NEXT PAGE

8-46 INSTALL DUAL CHIP DETECTOR (Continued)**8-46**

6. Connect hose assembly (8) to union (9).
7. Connect hose assembly (10) to union (11).
8. Connect hose assembly (12) to reducer (13).


**GO TO NEXT PAGE**

8-46 INSTALL DUAL CHIP DETECTOR (Continued)**8-46**

9. Connect hose assembly (14) to union (15).

INSPECT**FOLLOW-ON MAINTENANCE:**

None

**END OF TASK**

SECTION IX OIL LINES

8-47 REMOVE HOSE ASSEMBLY (FLOW PROGRAMMING VALVE TEE TO INLET HOUSING)

8-47

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit.

NSN 5180-00-323-4944

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

General Safety Instructions:

WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.





GO TO NEXT PAGE

8-47 REMOVE HOSE ASSEMBLY (FLOW PROGRAMMING VALVE TEE TO INLET HOUSING) (Continued)**8-47**

1. Remove two nuts (1), two bolts (2), and two brackets (3).
2. Disconnect and remove hose assembly (4).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

8-48 INSTALL HOSE ASSEMBLY (FLOW PROGRAMMING VALVE TEE TO INLET HOUSING)**8-48**

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Technical Inspection Tool Kit.

NSN 5180-00-323-5114


Materials:

None

Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector



GO TO NEXT PAGE



8-48 INSTALL HOSE ASSEMBLY (FLOW PROGRAMMING VALVE TEE TO INLET HOUSING) (Continued)

8-48

1. Install hose assembly (1) on tee (2) and union (3).
2. Install two brackets (4), two bolts (5), and two nuts (6).

INSPECT**FOLLOW-ON MAINTENANCE:**

None

**END OF TASK**

8-49 REMOVE HOSE ASSEMBLY (FLOW PROGRAMMING VALVE TO INFLIGHT FILLING PORT TEE)

8-49

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanics Tool Kit

NSN 5180-00-323-4944

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE



**8-49 REMOVE HOSE ASSEMBLY (FLOW PROGRAMMING VALVE TO
INFLIGHT FILLING PORT TEE) (Continued)**

8-49

3. Remove two nuts (1), two bolts (2), and bracket assembly (3).
4. Disconnect and remove hose assembly (4).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

**8-50 INSTALL HOSE ASSEMBLY (FLOW PROGRAMMING VALVE TO
INFLIGHT FILLING PORT TEE)**

8-50


INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**


None

Personnel Required:Aircraft Powerplant Repairer
Aircraft Powerplant Inspector


GO TO NEXT PAGE

**8-50 INSTALL HOSE ASSEMBLY (FLOW PROGRAMMING VALVE TO
INFLIGHT FILLING PORT TEE) (Continued)**
8-50

1. Install hose assembly (1) on tee (2), and union (3).



2. Install bracket assembly (4), two bolts (5), and two nuts (6).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

8-51 REMOVE HOSE ASSEMBLY (ACCESSORY GEARBOX ASSEMBLY TO OIL COOLER)

8-51

INITIAL SETUP**Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.




GO TO NEXT PAGE


8-51 REMOVE HOSE ASSEMBLY (ACCESSORY GEARBOX ASSEMBLY TO OIL COOLER) (Continued)

8-51

1. Remove nut (1), screw (2), and clamp (3).



2. Disconnect and remove hose assembly (4).



FOLLOW-ON MAINTENANCE:
None


END OF TASK

8-52 INSTALL HOSE ASSEMBLY (ACCESSORY GEARBOX ASSEMBLY TO OIL COOLER)**8-52****INITIAL SETUP**Technical Inspection Tool Kit.
NSN 5180-00-323-5114**Applicable Configurations:**

All

Materials:


None

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Personnel Required:**Aircraft Powerplant Repairer
Aircraft Powerplant Inspector**GO TO NEXT PAGE**


8-52 INSTALL HOSE ASSEMBLY (ACCESSORY GEARBOX ASSEMBLY TO OIL COOLER) (Continued)

8-52

1. Install hose assembly (1) on union (2) and reducer (3).



2. Install clamp (4) on hose assembly (1), and install screw (5) and nut (6).



INSPECT

FOLLOW-ON MAINTENANCE:
None

END OF TASK

8-53 REMOVE HOSE ASSEMBLY (OIL COOLER TO FLOW PROGRAMMING VALVE)

8-53

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit
NSN 5180-00-323-4944
Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.




GO TO NEXT PAGE

8-53 REMOVE HOSE ASSEMBLY (OIL COOLER TO FLOW PROGRAMMING VALVE) (Continued)

8-53

1. Disconnect and remove hose assembly (1).



FOLLOW-ON MAINTENANCE:
None

END OF TASK**8-120**

8-54 INSTALL HOSE ASSEMBLY (OIL COOLER TO FLOW PROGRAMMING VALVE)**8-54**


INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

None


Personnel Required:Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

GO TO NEXT PAGE

8-121

**8-54 INSTALL HOSE ASSEMBLY (OIL COOLER TO FLOW PROGRAMMIN
VALVE) (Continued)****8-54**

1. Install hose assembly (1) on union (2) and reducer (3).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

8-55 REMOVE HOSE ASSEMBLY (FLOW PROGRAMMING VALVE TEE TO NO. 2 BEARING PRESSURE CONNECTOR)

8-55

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.




GO TO NEXT PAGE

**8-55 REMOVE HOSE ASSEMBLY (FLOW PROGRAMMING VALVE TEE TO
NO. 2 BEARING PRESSURE CONNECTOR (Continued)**

8-55

1. Disconnect and remove hose assembly (1).



FOLLOW-ON MAINTENANCE:
None

END OF TASK**8-124**

8-56 INSTALL HOSE ASSEMBLY (FLOW PROGRAMMING VALVE TEE TO NO. 2 BEARING PRESSURE CONNECTOR)

8-56

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944


Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

None

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector




GO TO NEXT PAGE

**8-56 INSTALL HOSE ASSEMBLY (FLOW PROGRAMMING VALVE TEE TO
NO. 2 BEARING PRESSURE CONNECTOR) (Continued)**

8-56

1. Install hose assembly (1) on tee (2) and No. 2 bearing pressure connector (3).

**INSPECT****FOLLOW-ON MAINTENANCE:**

None

END OF TASK

8-57 REMOVE HOSE ASSEMBLY (DUAL CHIP DETECTOR TO ACCESSORY GEARBOX ASSEMBLY)

8-57

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**


Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE


**8-57 REMOVE HOSE ASSEMBLY (DUAL CHIP DETECTOR TO ACCESSORY
GEARBOX ASSEMBLY) (Continued)****8-57**

1. Remove nut (1), screw (2), and clamp (3).

**GO TO NEXT PAGE**

**8-57 REMOVE HOSE ASSEMBLY (DUAL CHIP DETECTOR TO ACCESSORY
GEARBOX ASSEMBLY) (Continued)****8-57**


2. Remove nut (4), screw (5), and clamp (6).



GO TO NEXT PAGE

**8-57 REMOVE HOSE ASSEMBLY (DUAL CHIP DETECTOR TO ACCESSORY
GEARBOX ASSEMBLY) (Continued)****8-57**

3. Remove nut (7), screw (8), and clamp (9).


**GO TO NEXT PAGE**

**8-57 REMOVE HOSE ASSEMBLY (DUAL CHIP DETECTOR TO ACCESSORY
GEARBOX ASSEMBLY) (Continued)****8-57**

4. Disconnect and remove hose assembly (10).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK****8-131**

8-58 INSTALL HOSE ASSEMBLY (DUAL CHIP DETECTOR TO ACCESSORY GEARBOX ASSEMBLY)

8-58

INITIAL SETUP

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Applicable Configurations:

All

Materials:


None

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944



Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector




8-58 INSTALL HOSE ASSEMBLY (DUAL CHIP DETECTOR TO ACCESSORY GEARBOX ASSEMBLY) (Continued)**8-58**

1. Install hose assembly (1) on reducer (2) and adapter (3).
2. Install clamp (4), screw (5), and nut (6).

**GO TO NEXT PAGE**

**8-58 INSTALL HOSE ASSEMBLY (DUAL CHIP DETECTOR TO ACCESSORY
GEARBOX ASSEMBLY) (Continued)****8-58**

3. Install clamp (7), screw (8), and nut (9).

**GO TO NEXT PAGE**


8-58 INSTALL HOSE ASSEMBLY (DUAL CHIP DETECTOR TO ACCESSORY GEARBOX ASSEMBLY) (Continued)**8-58**

4. Install clamp (10), screw (11), and nut (12).

INSPECT

FOLLOW-ON MAINTENANCE:

None



END OF TASK

8-59 REMOVE HOSE ASSEMBLY (DUAL CHIP DETECTOR TO ACCESSORY GEARBOX COLLECTOR)

8-59

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944


Container, 1 Quart

Materials:

Wiping Rag (E64)

Personnel Required:**General Safety Instructions:****WARNING**

Prolonged contact with lubricating oil may irritate the skin. Use in ventilated areas and minimize breathing vapor, mist or fumes. Do not store near heat, sparks or flame. Avoid prolonged contact with skin. Wash contacted areas with soap and water. If irritation of skin results, get medical attention. In case of eye contact, flush with water and get medical attention. Do not take internally. If ingested, get medical attention. Do not induce vomiting.




GO TO NEXT PAGE

**8-59 REMOVE HOSE ASSEMBLY (DUAL CHIP DETECTOR TO ACCESSORY
GEARBOX COLLECTOR) (Continued)****8-59**

1. Disconnect and remove hose assembly (1).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

**8-60 INSTALL HOSE ASSEMBLY (DUAL CHIP DETECTOR TO ACCESSORY
GEARBOX COLLECTOR)****8-60**


INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

None


Personnel Required:Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

GO TO NEXT PAGE

8-60 INSTALL HOSE ASSEMBLY (DUAL CHIP DETECTOR TO ACCESSORY GEARBOX COLLECTOR) (Continued)**8-60**

1. Install hose assembly (1) on union (2) and nipple (3).

FOLLOW-ON MAINTENANCE:
None

**END OF TASK**

8-61 REMOVE HOSE ASSEMBLY (DUAL CHIP DETECTOR TO AIR DIFFUSER ASSEMBLY)

8-61

INITIAL SETUP

Applicable Configurations:

All

Tools:


Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Container 1 Quart

Materials:

Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer



**8-61 REMOVE HOSE ASSEMBLY (DUAL CHIP DETECTOR TO AIR
DIFFUSER ASSEMBLY) (Continued)**

8-61


WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

1. Disconnect and remove hose assembly (1).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

8-62 INSTALL HOSE ASSEMBLY (DUAL C HIP DETECTOR TO AIR DIFFUSER ASSEMBLY)

8-62

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944


Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

None

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector




**8-62 INSTALL HOSE ASSEMBLY (DUAL CHIP DETECTOR TO AIR
DIFFUSER ASSEMBLY) (Continued)****8-62**

1. Install hose assembly (1) to unions (2 and 3).

INSPECT

FOLLOW-ON MAINTENANCE:

None



END OF TASK

8-63 REMOVE HOSE ASSEMBLY (MAIN OIL PUMP TO DUAL CHIP DETECTOR)

8-63

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

Wiping Rag (E64)


Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Main Oil Pump, Speed Pickup Assembly, Scavenge Oil Screen, and Related Parts Removed (Task 8-1)

Tube Assembly Removed (Inlet Housing to Main Oil Pump) (Task 8-65)



GO TO NEXT PAGE

8-63 REMOVE HOSE ASSEMBLY (MAIN OIL PUMP TO DUAL CHIP DETECTOR (Continued))

8-63


WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

1. Disconnect and remove hose assembly (1).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

8-64 INSTALL HOSE ASSEMBLY (MAIN OIL PUMP TO DUAL CHIP DETECTOR)

8-64

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944


Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

None

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector



8-64 INSTALL HOSE ASSEMBLY (MAIN OIL PUMP TO DUAL CHIP DETECTOR) (Continued)**8-64**


1. Install hose assembly (1) on union (2).

INSPECT

FOLLOW-ON MAINTENANCE:

Install Main Oil Pump, Speed Pickup Assembly,
Scavenge Oil Screen, and Related Parts (Task 8-6).

Install Tube Assembly (Inlet Housing to Main Oil Pump) (Task 8-66).



END OF TASK

8-65 REMOVE TUBE ASSEMBLY (INLET HOUSING TO MAIN OIL PUMP)

8-65

INITIAL SETUP

General Safety Instructions:

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Container, 1 Quart

Materials:

Wiping Rag (E64)

Personnel Required:


Aircraft Powerplant Repairer

Equipment Condition:

Engine Oil System Drained (Task 1-69)

WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.





GO TO NEXT PAGE

8-65 REMOVE TUBE ASSEMBLY (INLET HOUSING TO MAIN OIL PUMP)
(Continued)

8-65

1. Remove nut (1), screw (2), and clamp (3).
2. Remove lockwire, two bolts (4), two washers (5), connector (6), and two packings (7).



GO TO NEXT PAGE


8-65 REMOVE TUBE ASSEMBLY (INLET HOUSING TO MAIN OIL PUMP)
(Continued)

8-65

3. Remove tube assembly (8) and packing (9).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

8-66 INSTALL TUBE ASSEMBLY (INLET HOUSING TO MAIN OIL PUMP)

8-66

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

Lockwire (E33)

Parts:


Packings

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

References:



TM 1-1520-252-10
Task 8-65



GO TO NEXT PAGE

**8-66 INSTALL TUBE ASSEMBLY (INLET HOUSING TO MAIN OIL PUMP)
(Continued)**



1. Install packing (1) in groove (2) in cover assembly (3).
2. Install tube assembly (4) in cover assembly (3) and bracket (5).



GO TO NEXT PAGE

8-66 **INSTALL TUBE ASSEMBLY (INLET HOUSING TO MAIN OIL PUMP)**
(Continued)

- 3. Install packing (6) in groove (7) and packing (8) in groove (9) of connector (10).
- 4. **Install connector (10)** on tube assembly (4), and oil pump (11). Install two washers (12), bolt (13), and bolt (14).



GO TO NEXT PAGE

**8-66 INSTALL TUBE ASSEMBLY (INLET HOUSING TO MAIN OIL PUMP)
(Continued)**

8-66



5. Check for proper installation of tube assembly (4) as follows:

a. Check clearance between tube assembly (4) and washer (15). Clearance shall be 0.002 inch minimum.

b. Check tube assembly (4) for freedom of movement in all directions. Tube assembly (4) shall be free to move forward and aft a total of 3/32 inch minimum. Tube assembly (4) shall be free to move sideways a total of 0.002 inch minimum. Tube Assembly (4) shall be free to move radially a total of 0.004 inch minimum.

INSPECT**NOTE**

If clearance is not obtained or if tube assembly is not free to move, go to step 6. If proper clearance is obtained and tube assembly is free to move, go to step 9.

**GO TO NEXT PAGE**

8-66 **INSTALL TUBE ASSEMBLY (INLET HOUSING TO MAIN OIL PUMP)**
 (Continued)



8-66

- Remove lockwire and loosen bolts (16).

CAUTION

In following step 7, make sure bracket is positioned properly. This will ensure that tube assembly does not hit housing at either end when engine is hot. This could cause tube assembly to bend and result in oil leakage.

- Reposition bracket (5) to obtain equal clearance at points A, B, and C between bracket (5) and tube assembly (4).



GO TO NEXT PAGE

**8-66 INSTALL TUBE ASSEMBLY (INLET HOUSING TO MAIN OIL PUMP)
(Continued)**



8-66

8. Check for proper installation of tube assembly (4) as follows:

- a. Check clearance between tube assembly (4) and washer (15). Clearance shall be 0.002 inch minimum.
- b. Check tube assembly (4) for freedom of movement in all directions. Tube assembly (4) shall be free to move forward and aft a total of 3/32 inch minimum. Tube assembly (4) shall be free to move sideways a total of 0.002 inch minimum. Tube assembly (4) shall be free to move radially a total of 0.004 inch minimum.

NOTE



If proper clearance and freedom of movement is still not obtained, remove tube assembly (Ref. Task 8-65) and install serviceable tube assembly (Steps 1 thru 8).

**GO TO NEXT PAGE**

**8-66 INSTALL TUBE ASSEMBLY (INLET HOUSING TO MAIN OIL PUMP)
(Continued)**

8-66

9. Install two bolts (16) and lockwire. Use lockwire (E33).
10. Lockwire bolts (13) and plug (15). Use lockwire (E33).

**GO TO NEXT PAGE**


8-66 INSTALL TUBE ASSEMBLY (INLET HOUSING TO MAIN OIL PUMP)
(Continued)

8-66

11. Install clamp (17), screw (18), and nut (19).

INSPECT**FOLLOW-ON MAINTENANCE:**

Service Engine Oil System (Task1-68)

**END OF TASK**

**8-67 REMOVE TUBE ASSEMBLY (MAIN OIL PUMP TO INLET HOUSING OIL
SCAVENGE TEE)**

8-67

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Engine Oil System Drained (Task 1-69)



GO TO NEXT PAGE

**8-67 REMOVE TUBE ASSEMBLY (MAIN OIL PUMP TO INLET HOUSING OIL
SCAVENGE TEE) (Continued)**

8-67


WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

1. Disconnect and remove tube assembly (1) and gasket (2).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

**8-68 INSTALL TUBE ASSEMBLY (MAIN OIL PUMP TO INLET HOUSING OIL
SCAVENGE TEE)**

8-68

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

None

Parts:


Gasket

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P



GO TO NEXT PAGE


**8-68 INSTALL TUBE ASSEMBLY (MAIN OIL PUMP TO INLET HOUSING OIL
SCAVENGE TEE) (Continued)**

8-68

1. Install gasket (1) on tee (2) and install **tube assembly (3)** on nipple (4) and tee (2).

INSPECT**FOLLOW-ON MAINTENANCE:**

Service Engine Oil System (Task1-68)

**END OF TASK**

8-69 REMOVE TUBE ASSEMBLY (NO. 4 AND 5 BEARING SCAVENGE TUBE ASSEMBLY TO MAIN OIL PUMP FLANGE)

8-69

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Container, 1 Quart

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE


8-69 REMOVE TUBE ASSEMBLY (NO. 4 AND 5 BEARING SCAVENGE TUBE ASSEMBLY TO MAIN OIL PUMP FLANGE) (Continued)

8-69

1. Disconnect and remove hose assembly (1).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

8-70 INSTALL TUBE ASSEMBLY (NO. 4 AND 5 BEARING SCAVENGE TUBE ASSEMBLY TO MAIN OIL PUMP FLANGE)

8-70

INITIAL SETUP

Applicable Configurations:

All


Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector




8-70 INSTALL TUBE ASSEMBLY (NO. 4 AND 5 BEARING SCAVENGE TUBE ASSEMBLY TO MAIN OIL PUMP FLANGE) (Continued)

8-70

1. Install hose assembly (1) on tube assembly (2) and flange (3).

INSPECT**FOLLOW-ON MAINTENANCE:**

None

**END OF TASK**

8-71 REMOVE TUBE ASSEMBLY (NO. 4 AND 5 BEARING SCAVENGE CONNECTOR TO TUBE ASSEMBLY)

8-71

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Container, 1 Quart

Open-End Wrench (T24)

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**

Prolonged contact with lubricating oil may irritate the skin. Use in ventilated areas and minimize breathing vapor, mist or fumes. Do not store near heat, sparks or flame. Avoid prolonged contact with skin. Wash contacted areas with soap and water. If irritation of skin results, get medical attention. In case of eye contact, flush with water and get medical attention. Do not take internally. If ingested, get medical attention. Do not induce vomiting




GO TO NEXT PAGE

8-71 REMOVE TUBE ASSEMBLY (NO. 4 AND 5 BEARING SCAVENGE CONNECTOR TO TUBE ASSEMBLY) (Continued)

8-71

1. Remove lockwire, screw (1), and clamp (2).
2. Remove nut (3), screw (4), and clamp (5).




GO TO NEXT PAGE

8-71 REMOVE TUBE ASSEMBLY (NO. 4 AND 5 BEARING SCAVENGE CONNECTOR TO TUBE ASSEMBLY) (Continued)

8-71

3. Remove three nuts (6) and strap (7).



GO TO NEXT PAGE

8-71 REMOVE TUBE ASSEMBLY (NO. 4 AND 5 BEARING SCAVENGE CONNECTOR TO TUBE ASSEMBLY) (Continued)

8-71


CAUTION

In following step, hold No. 4 and 5 bearing scavenge adapter using open-end wrench (T24). Failure to use wrench may result in damage and mislocation of oil transfer tube resulting in oil leaks.

4. Place open-end wrench (T24) (8) on No. 4 and 5 bearing scavenge adapter (9).
5. Disconnect tube assembly (10) from reducer (11).
6. Disconnect tube assembly (10) from tube assembly (12) and remove tube assembly (10).

FOLLOW-ON MAINTENANCE:

None



END OF TASK

8-72 INSTALL TUBE ASSEMBLY (NO. 4 AND 5 BEARING SCAVENGE CONNECTOR TO TUBE ASSEMBLY)

8-72

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Open-End Wrench (T24)

Torque Wrench


Materials:

Lockwire (E33)

Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector



GO TO NEXT PAGE

8-72 INSTALL TUBE ASSEMBLY (NO. 4 AND 5 BEARING SCAVENGE CONNECTOR TO TUBE ASSEMBLY)


8-72

CAUTION

In following step, hold No. 4 and 5 bearing and scavenge adapter using open-end wrench (T24). Failure to use wrench may result in damage and mislocation of oil transfer tube resulting in oil leaks.

1. Install tube assembly (1) as follows:


- a. Place open-end wrench (T24) (2) on No. 4 and 5 bearing scavenge adapter (3).
- b. Connect tube assembly (1) to reducer (4).
- c. Connect tube assembly (1) to tube assembly (5).

**GO TO NEXT PAGE**

8-72 INSTALL TUBE ASSEMBLY (NO. 4 AND 5 BEARING SCAVENGE CONNECTOR TO TUBE ASSEMBLY) (Continued)


8-72

2. Install strap (6) and three nuts (7).

**GO TO NEXT PAGE**

8-72 INSTALL TUBE ASSEMBLY (NO. 4 AND 5 BEARING SCAVENGE CONNECTOR TO TUBE ASSEMBLY) (Continued)**8-72**

3. Install clamp (8), screw (9), and nut (10).
4. Install clamp (11) on tube assembly (1) and install screw (12). Lockwire screw. Use lockwire (E33).

**INSPECT****FOLLOW-ON MAINTENANCE:**
None**END OF TASK**

8-73 REMOVE TUBE ASSEMBLY (NO. 2 BEARING PRESSURE CONNECTOR TO TEE AND SNUBBER)

8-73

INITIAL SETUP

General Safety Instructions:**Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool kit,
NSN 5180-00-323-4944**Materials:**


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

WARNING


Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted areas of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.




GO TO NEXT PAGE

8-73 REMOVE TUBE ASSEMBLY (NO. 2 BEARING PRESSURE CONNECTOR TO TEE AND SNUBBER) (Continued)**8-73**

1. Remove nut (1), bolt (2), and clamp (3).



2. Disconnect and remove tube assembly (4).



FOLLOW-ON MAINTENANCE:
None


END OF TASK

**8-74 INSTALL TUBE ASSEMBLY (NO. 2 BEARING PRESSURE
CONNECTOR TO TEE AND SNUBBER)**

8-74

INITIAL SETUP


Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Applicable Configurations:**
All**Tools:**Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Materials:**
None**Personnel Required:**Aircraft Powerplant Repairer
Aircraft Powerplant Inspector




GO TO NEXT PAGE

8-74 INSTALL TUBE ASSEMBLY (NO. 2 BEARING PRESSURE CONNECTOR TO TEE AND SNUBBER) (Continued)

1. Install tube assembly (1) on tee and snubber (2) and No. 2 bearing pressure oil connector (3).



2. Install clamp (4), bolt (5), and nut (6), onto bracket (7).



INSPECT

FOLLOW-ON MAINTENANCE:
None

END OF TASK

8-75 REMOVE HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4 AND 5 BEARING FILTER)

8-75

INITIAL SETUP**General Safety Instructions:****Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Container, 1 Quart
Open-End Wrench (T24)

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer


WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical

**GO TO NEXT PAGE**


8-75 REMOVE HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4 AND 5 BEARING FILTER) (Continued)**8-75**

1. Remove nut (1), bolt (2), and clamp (3).

**GO TO NEXT PAGE**

8-75 REMOVE HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4 AND 5 BEARING FILTER) (Continued)

2. Remove three nuts (4), bolts (5), and clamps (6).




GO TO NEXT PAGE

8-75 REMOVE HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4 AND 5 BEARING FILTER) (Continued)


8-75

3. Remove lockwire, screw (7), and clamp (8).



GO TO NEXT PAGE

4. Remove two nuts (9) and clamps (10 and 11).




GO TO NEXT PAGE

8-75 REMOVE HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4 AND 5 BEARING FILTER) (Continued)

8-75

5. Remove lockwire, screw (12), and clamp (13).




GO TO NEXT PAGE

8-75 REMOVE HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4 AND 5 BEARING FILTER) (Continued)

8-75

6. Remove nut (14), screw (15), and clamp (16).




GO TO NEXT PAGE

8-75 REMOVE HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4 AND 5 BEARING FILTER) (Continued)

8-75

7. Remove two nuts (17) and clamp (18).




GO TO NEXT PAGE

8-75 REMOVE HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4 AND 5 BEARING FILTER) (Continued)

8-75


8. Remove nut (19), screw (20), and clamp (21).



GO TO NEXT PAGE

8-75 REMOVE HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4 AND 5 BEARING FILTER) (Continued)

- Remove nut (22), screw (23), and clamp (24).



GO TO NEXT PAGE


8-75 REMOVE HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4 AND 5 BEARING FILTER) (Continued)

8-75

CAUTION

In following step, hold No. 4 and 5 bearing lube adapter using open-end wrench (T24). Failure to use wrench may result in damage and mislocation of oil transfer tube resulting in oil leaks.

10. Place open-end wrench (T24) (25) on No. 4 and 5 bearing lube adapter (26).
11. Disconnect hose assembly (27) from reducer (28).
12. Disconnect hose assembly (27) from oil tee and snubber (29) and remove hose assembly (27).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

8-76 INSTALL HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4 AND 5 BEARING FILTER)

8-76

INITIAL SETUP

Applicable Configurations:

All

Tools:


Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114
Open-End Wrench (T24)

Materials:

Lockwire (E33)

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector




GO TO NEXT PAGE

8-76 **INSTALL HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4 AND 5 BEARING FILTER)**

CAUTION

In following step, hold No. 4 and 5 bearing lube adapter, using open-end wrench (T24). Failure to use wrench may result in damage and mislocation of oil transfer tube resulting in oil leaks.

- 1. Install hose assembly (1) as follows:
 - a. Place open-end wrench (T24) (2) on No. 4 and 5 bearing lube adapter (3).
 - b. Connect hose assembly (1) to reducer (4).
 - c. Connect hose assembly (1) to tee and snubber (5).




GO TO NEXT PAGE

8-76 INSTALL HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4 AND 5 BEARING FILTER)

8-76


2. Install clamp (6) on hose assembly (1), and install screw (7) and nut (8).



GO TO NEXT PAGE

8-76 INSTALL HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4. AND 5 BEARING FILTER) (Continued)

- 3. Install clamp (9) on hose assembly (1), and install screw (10) and nut (11).




GO TO NEXT PAGE

**8-76 INSTALL HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4. AND
5 BEARING FILTER) (Continued)**

8-76


4. Install clamp (12) and two nuts (13) on bracket (14).

**GO TO NEXT PAGE**

8-76 INSTALL HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4. AND 5 BEARING FILTER) (Continued)


8-76

5. Install clamp (15) on hose assembly (1), and install screw (16) and nut (17).

**GO TO NEXT PAGE**

8-76 INSTALL HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4. AND 5 BEARING FILTER) (Continued)**8-76**

6. Install clamp (18) on hose assembly (1), and install screw (19). Lockwire screw. Use lockwire (E33).




GO TO NEXT PAGE

8-76 INSTALL HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4. AND 5 BEARING FILTER) (Continued)

8-76


7. Install clamps (20 and 21) and two nuts (22).



GO TO NEXT PAGE

**8-76 INSTALL HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4. AND
5 BEARING FILTER) (Continued)****8-76**


8. Install clamp (23) on hose assembly (1) and install screw (24). Lockwire screw. Use lockwire (E33).

**GO TO NEXT PAGE**

**8-76 INSTALL HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4. AND
5 BEARING FILTER) (Continued)**

8-76

9. Install three clamps (25) on hose assembly (1), and install three bolts (26) and nuts (27).




GO TO NEXT PAGE

8-76 INSTALL HOSE ASSEMBLY (PRESSURE CONNECTOR TO NO. 4. AND 5 BEARING FILTER) (Continued)

8-76

10. Install clamp (28) on hose assembly (1), and install bolt (29) and nut (30).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:


Powerplant Mechanic's Tool Kit,
NSN
5180-00-323-4944
Container, 1 Quart

Materials:

Wiping Rag (E64)

Personnel Required:


Aircraft Powerplant Repairer

**GO TO NEXT PAGE**

WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

1. Disconnect and remove hose assembly (1) and gasket (2).

**FOLLOW-ON MAINTENANCE:**

None

END OF TASK

INITIAL SETUP


Applicable Configurations:
All

Tools:
Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:
None

Parts:
Gasket


Personnel Required:
Aircraft Powerplant Repairer
Aircraft Powerplant Inspector



GO TO NEXT PAGE

**8-78 INSTALL HOSE ASSEMBLY (INLET HOUSING TO OIL SCAVENGE TEE)
(Continued)****8-78**

1. Install washer (1) on oil scavenge tee (2) and install hose assembly (3) on oil scavenge tee (2) and fluid passage bolt (4).

**INSPECT****FOLLOW-ON MAINTENANCE:**
None**END OF TASK**

INITIAL SETUP

General Safety Instructions:

Applicable Configurations:
All

WARNING



Tools:
Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Container, 1 Quart

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

Materials:
Wiping Rag (E64)

Personnel Required:
Aircraft Powerplant Repairer


Equipment Condition:
Engine Oil System Drained (Task 1-69)




GO TO NEXT PAGE

8-79 REMOVE HOSE ASSEMBLY (INLET HOUSING TO OIL DRAIN COCK)
(Continued)

1. Remove oil drain cock (1).



2. Remove cable tie (2).




GO TO NEXT PAGE

**8-79 REMOVE HOSE ASSEMBLY (INLET HOUSING TO OIL DRAIN COCK)
(Continued)**

8-79

3. Disconnect and remove hose assembly (3).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

INITIAL SETUP


Applicable Configurations:
All

Tools:
Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:
None

Parts:
Cable Tie


Personnel Required:
Aircraft Powerplant Repairer
Aircraft Powerplant Inspector




GO TO NEXT PAGE

**8-80 INSTALL HOSE ASSEMBLY (INLET HOUSING TO OIL DRAIN COCK)
(Continued)**

- 1. Install hose assembly (1) on nipple (2).



- 2. Install cable tie (3) on hose assembly (1) and hose assembly (4).




GO TO NEXT PAGE

**8-80 INSTALL HOSE ASSEMBLY (INLET HOUSING TO OIL DRAIN COCK)
(Continued)**

8-80

3. Install oil drain cock (5) on hose assembly (1).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

8-81 REMOVE HOSE ASSEMBLY (STARTER DRIVE TO OIL FILLER)

8-81

INITIAL SETUP**Applicable Configurations:**

All

Tools:


Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Container, 1 Quart

Materials:

Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

**GO TO NEXT PAGE**


**8-81 REMOVE HOSE ASSEMBLY (STARTER DRIVE TO OIL FILLER)
(Continued)**

8-81

WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

1. Disconnect and remove hose assembly (1).



FOLLOW-ON MAINTENANCE:
None

END OF TASK


INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit.
NSN 5180-00-323-5114**Materials:**

None

Personnel Required:Aircraft Powerplant Repairer
Aircraft Powerplant Inspector


GO TO NEXT PAGE

8-82 INSTALL HOSE ASSEMBLY (STARTER DRIVE TO OIL FILLER) (Continued)

1. Install hose assembly (1) on tee (2) and fitting (3).

INSPECT**FOLLOW-ON MAINTENANCE:**

None

**END OF TASK**

INITIAL SETUP

Applicable Configurations:

All

Tools:


- Open-End Wrench, 1-Inch
- Container, 1 Quart

Materials:

Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer




GO TO NEXT PAGE

WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

- 1. Disconnect and **remove hose assembly (1)**, using 1-inch, open-end wrench.

FOLLOW-ON MAINTENANCE:
None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Open-End Wrench, 1-Inch

Crowfoot Attachment, 1-inch


Materials:

None

Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector




GO TO NEXT PAGE

1. Install hose assembly (1) on tube and hose assembly (2) and reducer (3) Use 1-inch crowfoot attachment.

INSPECT

FOLLOW-ON MAINTENANCE:
None



END OF TASK

8-85 REMOVE TUBE AND HOSE ASSEMBLY (ACCESSORY GEARBOX COLLECTOR TO TUBE ASSEMBLY)

8-85

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Open-End Wrench, 1-inch

Materials:

Wiping Rag (E64)



Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally.



Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE

8-85 REMOVE TUBE AND HOSE ASSEMBLY (ACCESSORY GEARBOX COLLECTOR TO TUBE ASSEMBLY) (Continued)



1. Remove nuts (1), screws (2), and clamps (3).
2. Remove nut (4), screw (5), and clamp (6).



GO TO NEXT PAGE

8-85 REMOVE TUBE AND HOSE ASSEMBLY (ACCESSORY GEARBOX COLLECTOR TO TUBE ASSEMBLY) (Continued)



3. Remove nut (7), screw (8) and clamp (9).
4. Remove nut (10), screw (11), and clamp (12).



GO TO NEXT PAGE

8-85 REMOVE TUBE AND HOSE ASSEMBLY (ACCESSORY GEARBOX COLLECTOR TO TUBE ASSEMBLY) (Continued)

5. Remove nut (13), screw (14), and clamp (15).
6. Remove nut (16), screw (17), and clamp (18).





GO TO NEXT PAGE

8-85 REMOVE TUBE AND HOSE ASSEMBLY (ACCESSORY GEARBOX COLLECTOR TO TUBE ASSEMBLY) (Continued)

8-85

7. Remove nut (19), screw (20), and clamp (21).
8. Disconnect tube and hose assembly (22) from tube assembly (23), Use 1-inch open-end wrench.

**GO TO NEXT PAGE**



8-85 REMOVE TUBE AND HOSE ASSEMBLY (ACCESSORY GEARBOX COLLECT OR TO TUBE ASSEMBLY) (Continued)

8-85

9. Disconnect hose assembly (24) from tube and hose assembly (22).
10. Disconnect tube and hose assembly (22) from nipple (25) Remove tube and hose assembly (22).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

8-86 INSTALL TUBE AND HOSE ASSEMBLY (ACCESSORY GEARBOX COLLECTOR TO TUBE ASSEMBLY)

8-86

INITIAL SETUP**Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Technical Inspection Tool Kit,

NSN 5180-00-323-5114

Crowfoot Attachment, 1-Inch


Materials:

None

Personnel Required:



Aircraft Powerplant Repairer

Aircraft Powerplant Inspector

**GO TO NEXT PAGE**

8-86 INSTALL TUBE AND HOSE ASSEMBLY (ACCESSORY GEARBOX COLLECTOR TO TUBE ASSEMBLY) (Continued)



- 1. Connect tube and hose assembly (1) to nipple (2).
- 2. Connect hose assembly (3) to tube and hose assembly (1).



GO TO NEXT PAGE

8-86 INSTALL TUBE AND HOSE ASSEMBLY (ACCESSORY GEARBOX COLLECTOR TO TUBE ASSEMBLY) (Continued)



- 3. Connect tube and hose assembly (1) to tube assembly (4). Use 1-inch crowfoot attachment.
- 4. Install clamp (5) on tube and hose assembly (1), and install screw (6) and nut (7).



GO TO NEXT PAGE

8-86 INSTALL TUBE AND HOSE ASSEMBLY (ACCESSORY GEARBOX COLLECTOR TO TUBE ASSEMBLY) (Continued)



- 5. Install clamp (8) on tube and hose assembly (1) and install screw (9) and nut (10).
- 6. Install clamp (11) on tube and hose assembly (1) and install screw (12) and nut (13).



GO TO NEXT PAGE

8-86 INSTALL TUBE AND HOSE ASSEMBLY (ACCESSORY GEARBOX COLLECTOR TO TUBE ASSEMBLY) (Continued)

- 7. Install clamp (14) on tube and hose assembly (1) .and install screw (15) and nut (16).
- 8. Install clamp (17) on tube and hose assembly (1) and install screw (18) and nut (19).



GO TO NEXT PAGE

8-86 INSTALL TUBE AND HOSE ASSEMBLY (ACCESSORY GEARBOX COLLECTOR TO TUBE ASSEMBLY) (Continued)



9. Install clamp (20) on tube and hose assembly (1) and install screw (21) and nut (22).

10. Install clamps (23) on tube and hose assembly (1) and install screws (24) and nuts (25).

INSPECT

FOLLOW-ON MAINTENANCE:

None



END OF TASK

8-87 REMOVE TUBE ASSEMBLY (TUBE AND HOSE ASSEMBLY TO ACCESSORY GEARBOX ASSEMBLY)

8-87

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tools: Kit,
NSN 5180-00-323-4944
Container, 1 Quart
Open-End Wrench, 1-Inch
Socket Head Screw Key, 1/2-Inch

Materials:

Wiping Rag (E64)

Personnel Required:


Aircraft Powerplant Repairer

References:

PT Speed Pickup Drive Assembly Removed
Task (5-13)

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.





GO TO NEXT PAGE

8-87 REMOVE TUBE ASSEMBLY (TUBE AND HOSE ASSEMBLY TO ACCESSORY GEARBOX ASSEMBLY) (Continued)

8-87

1. **Disconnect tube and hose assembly (1) from tube assembly (2).** Using a 1-inch open-end wrench.
2. **Remove lockwire and bolt (3).** Using a 1/2-inch socket head screw key. **Remove tube assembly (2).**


**GO TO NEXT PAGE**

8-87 REMOVE TUBE ASSEMBLY (TUBE AND HOSE ASSEMBLY TO ACCESSORY GEARBOX ASSEMBLY) (Continued)

8-87

3. Remove packings (4 and 5).

FOLLOW-ON MAINTENANCE:
None



END OF TASK

8-88 INSTALL TUBE ASSEMBLY (TUBE AND HOSE ASSEMBLY TO ACCESSORY GEARBOX ASSEMBLY)

8-88

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114
Open-End Wrench, 1-Inch

Socket Head Screw Key, 1/2-Inch
Crowfoot Attachment

Materials:


Lockwire (E33)

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

References:



TM 1-2840-252-23P

**GO TO NEXT PAGE**

8-88 INSTALL TUBE ASSEMBLY (TUBE AND HOSE ASSEMBLY TO ACCESSORY GEARBOX ASSEMBLY) (Continued)

8-88

1. Install packings (1 and 2) into tube assembly (3).
2. Install tube assembly (3) and bolt (4) on accessory gearbox assembly (5) Use 1/2-inch socket head screw key Lockwire bolt (4). Use lockwire (E33).

**GO TO NEXT PAGE**


8-88 INSTALL TUBE ASSEMBLY (TUBE AND HOSE ASSEMBLY TO ACCESSORY GEARBOX ASSEMBLY) (Continued)

8-88

3. Connect tube and hose assembly (6) to tube assembly (3). Use 1-inch crowfoot attachment.

INSPECT**FOLLOW-ON MAINTENANCE:**

None

**END OF TASK**

SECTION X

STARTER GEARBOX FILTER

8-89 REMOVE STARTER GEARBOX FILTER

8-89

INITIAL SETUP

Applicable Configurations:

All

Tools:


Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer




GO TO NEXT PAGE

WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.

- 1. Remove lockwire, starter gearbox filter (1), washer (2), and packing (3).

FOLLOW-ON MAINTENANCE:
None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Goggles

Dry, Compressed Air Source

Materials:

Dry Cleaning Solvent (E19)

Gloves (E24)

Lint-Free Cloth (E30)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition

Off Engine Task

Starter Gearbox Filter Removed (Task 8-89)

General Safety Instructions**WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. **Clean starter gearbox filter (1)** as follows:

- a. Wear gloves (E24). Immerse filter in dry cleaning solvent (E19) and agitate. Use brush on external surfaces (2).
- b. Use lint-free cloth (E30) to remove solvent.


WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

- c. Wear goggles. Blow dry internal passage (3). Use clean, dry, compressed air.

FOLLOW-ON MAINTENANCE:

Inspect starter gearbox filter (Task 8-91).



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

None

Personnel Required:

Aircraft Powerplant Inspector

Equipment Condition:


Off Engine Task

1. Inspect starter gearbox filter (1).

- a. There shall be no cracks.
- b. There shall be no clogged holes (2).
- c. There shall be no clogged threads (3).

FOLLOW-ON MAINTENANCE:

None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

- Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
- Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

Lockwire (E33)

Parts:


- Packing
- Washer

Personnel Required:

- Aircraft Powerplant Repairer
- Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P





GO TO NEXT PAGE

- 1. **Install packing (1)** in groove (2) on starter gearbox filter (3).
- 2. **Install washer (4)** and **starter gearbox filter (3)** in housing (5). Tighten starter gearbox filter (1) to 22-inch-pounds. Lockwire starter gearbox filter (3). Use lockwire (E33).

INSPECT

FOLLOW-ON MAINTENANCE:
None



END OF TASK

SECTION XI

NO. 2 BEARING PRESSURE OIL CONNECTOR

8-93 REMOVE NO. 2 BEARING PRESSURE OIL CONNECTOR

8-93

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

None

Personnel Required:


Aircraft Powerplant Repairer

Equipment Condition:

Tube Assembly (No. 2 Bearing Pressure Connector to Tee and Snubber) Removed (Task 8-73)

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted areas of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.





GO TO NEXT PAGE

1. Disconnect hose assembly (1).
2. Remove lockwire, two screws (2) and two washers (3).
3. Remove screw (4), bracket (5), two washers (6), No. 2 bearing pressure connector (7), and packing (8).

FOLLOW-ON MAINTENANCE:

None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Dry, Compressed Air Source
Goggles**Materials:**Dry Cleaning Solvent (E19)
Gloves (E24)**Personnel Required:**

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

No. 2 Bearing Pressure Oil Connector Removed
(Task 8-93)**General Safety Instructions:****WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Wear gloves (E24). **Clean No. 2 bearing pressure oil connector (1)**, using brush and dry cleaning solvent (E19).


WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

2. Wear goggles. **Blow dry No. 2 bearing pressure oil connector (1)**, using clean, dry, compressed air.

FOLLOW-ON MAINTENANCE:

Inspect No. 2 Bearing Pressure Oil Connector (Task 8-95).



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:**Powerplant** Mechanic's Tool Kit,
NSN 5180-00-323-4944**Materials:**

None

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:


Off Engine Task

1. **Inspect No. 2 bearing pressure oil connector (1) as follows:**

- a. There shall be no nicks, scratches, and gouges on sealing surfaces (2).
- b. There shall be no damaged threads (3).

FOLLOW-ON MAINTENANCE:

None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

- Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
- Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

None

Parts:


Packing

Personnel Required:

- Aircraft Powerplant Repairer
- Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P





GO TO NEXT PAGE

- 1. Install packing (1), No. 2 bearing pressure connector (2), two washers (3), bracket (4), and screw (5).
- 2. Install two washers (6) and two screws (7).
- 3. Connect hose assembly (8) to No. 2 bearing pressure oil connector (2).

INSPECT

FOLLOW-ON MAINTENANCE:

Install Tube Assembly (No. 2 Bearing Pressure Connector to Tee and Snubber) (Task 8-74).



END OF TASK

SECTION XII

NO. 2 BEARING PRESSURE OIL STRAINER

8-97 REMOVE NO. 2 BEARING PRESSURE OIL STRAINER

8-97

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

None


Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:

WARNING



Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE

1. Disconnect oil tee and snubber (1).
2. Remove nut (2), bolt (3) and clamp (4).
3. Loosen tube assembly (5) and swing tube assembly to side.
4. Remove lockwire, No. 2 bearing pressure oil strainer (6) and packing (7) from No. 2 bearing pressure oil connector (8).

FOLLOW-ON MAINTENANCE:
None



END OF TASK

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Dry, Compressed Air Source
Goggles

Materials:

Dry Cleaning Solvent (E19)
Gloves (E24)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task
No. 2 Bearing Pressure Oil Strainer Removed
(Task 8-97)

General Safety Instructions:**WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Wear gloves (E24). **Clean strainer (1)**, using brush and dry cleaning solvent (E19).


WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

2. Wear goggles. **Blow dry strainer (1)**, using clean, dry, compressed air.

FOLLOW-ON MAINTENANCE:

Inspect No. 2 Bearing Pressure Oil Strainer (Task 8-99).

**END OF TASK**

INITIAL SETUP

Applicable Configurations:

All

Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

None

Personnel Required:

Aircraft Powerplant Inspector


Equipment Condition:

Off Engine Task

1. **Inspect No. 2 bearing pressure oil strainer (1).** There shall be no cracks.

FOLLOW-ON MAINTENANCE:

one



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Technical Inspection Tool Kit,

NSN 5180-00-323-5114

Materials:

Lockwire (E33)

Parts:

Packing


Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector



References:

TM 1-2840-252-23P



GO TO NEXT PAGE

1. **Install** packing (1) and **No. 2 bearing pressure oil strainer** (2) in No. 2 bearing pressure oil connector (3). Lockwire strainer (2). Use lockwire (E33).
2. Swing tube assembly (4) to clamp position and **install clamp** (5), bolt (6), and nut (7).
3. **Connect tube assembly** (4) to No. 2 bearing pressure oil connector (3) and oil tee and snubber (8).

**INSPECT**

FOLLOW-ON MAINTENANCE:
None

END OF TASK

SECTION XIII

NO. 5 AND 5 BEARING FILTER

8-101 REMOVE NO. 4 AND 5 BEARING FILTER

8-101

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Open-End Wrench (T24)
Container, 1-Quart
Goggles
Slave Screw, Part Number NAS1352-01-6,
NSN 5305-00-224-1168

Materials:


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.




GO TO NEXT PAGE

CAUTION

In following step, hold No. 4 and 5 bearing lube adapter using open-end wrench (T24). Failure to use wrench may result in damage and mislocation of oil transfer tube resulting in oil leaks.

- 1. Place open-end wrench (T24) (1) on No. 4 and 5 bearing lube adapter (2).
- 2. **Disconnect hose assembly (3) from reducer (4).**



GO TO NEXT PAGE


WARNING

In following step, wear goggles when removing spring. Spring may fly apart when removed. Failure to comply may cause serious eye injury. If eye injury occurs, get medical attention.

- 3. Remove spring (5).
- 4. Remove filter (6) from reducer (4). Use slave screw (7).

NOTE

If it is not possible to remove filter from reducer, do steps 5 thru 7.





GO TO NEXT PAGE

5. Place open-end wrench (T24) (1) on No. 4 and 5 bearing lube adapter (2).
6. **Remove reducer (4), washer (8), and shim (9) from adapter (2).**
7. **Discard reducer (4) and filter (6).**

FOLLOW-ON MAINTENANCE:

None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Goggles

Dry, Compressed Air Source

Materials:

Dry Cleaning Solvent (E19)

Gloves (E24)

Lint-Free Cloth (E30)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

No. 4 and 5 Bearing Filter Removed (Task 8-101)

General Safety Instructions:**WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Wear gloves (E24). **Clean No. 4 and 5 bearing filter (1)**. Use brush and dry cleaning solvent (E19).
2. **Clean spring (2)**. Immerse in dry cleaning solvent (E19) and agitate.


WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

3. Wear goggles. **Blow dry No. 4 and 5 bearing filter (1)**. Use clean, dry, compressed air.
4. **Blow dry spring (2)**. Use clean, dry, compressed air).

FOLLOW-ON MAINTENANCE:

Inspect No. 4 and 5 Bearing Filter (Task 8-103).



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

None

Personnel Required:

Aircraft Powerplant Inspector


Equipment Condition:

Off Engine Task

1. **Inspect No. 4 and 5 bearing filter (1).** There shall be no nicks, tears, or broken segments.
2. **Inspect spring (2).** Spring shall not be broken.

FOLLOW-ON MAINTENANCE:

None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114
Open-End Wrench (T24)


Torque Wrench, 30-150 Inch-Pounds
Outside Micrometer Caliper Set
Goggles

Materials:

Lockwire (E33)

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

**GO TO NEXT PAGE**

NOTE

If reducer was removed in Task 8-101, perform steps 1 thru 3. If reducer was not removed, omit steps 1 thru 3.

- 1. **Determine shims needed under reducer (1) as follows:**

CAUTION



Do not tighten reducer in following step. Tightening of reducer may damage Internal oil tube.

- a. Thread reducer (1) in adapter (2) until it is seated.

CAUTION

In following step, fireshield must be seated against adapter to obtain correct measurement. Failure to do so will result in incorrect gap.

- b. Seat fireshield section (3) against adapter (2) and measure gap between fireshield section and reducer (1).




GO TO NEXT PAGE

c. Find gap measured in shim selection table. Read across table to find shim thickness needed

IF GAP MEASURES INCH	SHIM THICKNESS REQUIRED INCH
0.060	NONE
0.061	NONE
0.062	0.003 to 0.005
0.063	0.003 to 0.005
0.064	0.003 to 0.005
0.065	0.006 to 0.010
0.066	0.006 to 0.010
0.067	0.006 to 0.010
0.068	0.008 to 0.012
0.069	0.008 to 0.012
0.070	0.008 to 0.012
0.071	0.009 to 0.015
0.072	0.011 to 0.017
0.073	0.011 to 0.017
0.074	0.011 to 0.017
0.075	0.012 to 0.020
0.076	0.014 to 0.022
0.077	0.014 to 0.022
0.078	0.016 to 0.024
0.079	0.016 to 0.024
0.080	0.016 to 0.024
0.081	0.016 to 0.024
0.082	0.019 to 0.029
0.083	0.019 to 0.029
0.084	0.019 to 0.029
0.085	0.022 to 0.034
0.086	0.022 to 0.034
0.087	0.022 to 0.034
0.088	0.022 to 0.034
0.089	0.024 to 0.036
0.090	0.024 to 0.036

d. Measure thickness of shims (4). Check against shim selection table. Use outside micrometer caliper.



B-6-83 4

GO TO NEXT PAGE

CAUTION

Concave side of washer must face fire- shield section. Failure to comply will place wrong tension on internal oil tube.

CAUTION



Do not tighten reducer in following step. Tightening of reducer may damage internal oil tube.

- 2. Remove reducer (1). Loosely install shims (4), washer (5), concave side down, and reducer (1).

CAUTION

Adapter must be held firmly when tightening reducer. Failure to comply will cause damage to internal tube assembly.

- 3. Hold adapter (2) with open-end wrench (T24) (6). Torque reducer (1) to 115 inch-pounds and lockwire. Use lockwire (E33).



GO TO NEXT PAGE

WARNING

In following step, wear goggles when installing spring. Spring may fly apart when installing. Failure to comply may cause serious eye injury. If eye injury occurs, get medical attention.

CAUTION

In following step, be sure that filter is installed in reducer with small diameter hole facing up. Failure to comply will cause less oil flow to bearings and result in bearing failure.

- 4. Wear goggles. Install No. 4 and 5 bearing filter (7) and spring (8) in reducer (1).



CAUTION

In following step, hold No. 4 and 5 bearing lube adapter using open-end wrench (T24). Failure to use wrench may result in damage and mislocation of oil transfer tube resulting in oil leaks.

- 5. Place open-end wrench (T24) (6) on adapter (2).
- 6. Install hose assembly (9) on reducer (1).

INSPECT

FOLLOW-ON MAINTENANCE:
None



END OF TASK

SECTION XIV

OIL DRAIN COCK

8-105 REMOVE OIL DRAIN COCK

8-105

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Container, 1-Quart

Materials:

Wiping Rag (E64)

Personnel Required:


Aircraft Powerplant Repairer

Equipment Condition:

Engine Oil System Drained (Task 1-69)

General Safety Instructions:**WARNING**

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.




GO TO NEXT PAGE

1. Remove oil drain cock (1) from hose assembly (2).

FOLLOW-ON MAINTENANCE:

None



END OF TASK

INITIAL SETUP

Applicable Configurations:

All

Tools:

Goggles

Dry, Compressed Air Source

Materials:

Dry Cleaning Solvent (E19)

Gloves (E24)

Lint-Free Cloth (E30)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

Oil Drain Cock Removed (Task 8-105)

General Safety Instructions:**WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Remove cap (1).

NOTE

Make sure valve is in open position in following step 2.

2. **Clean oil drain cock (2)** as follows:

- a. Wear gloves (E24). Immerse in dry cleaning solvent (E19) and agitate. Use brush on external surfaces.
- b. Use lint-free cloth (E30) to remove solvent.


WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

- c. Wear goggles and **blow dry internal passage**. Use clean, dry, compressed air.

FOLLOW-ON MAINTENANCE:

Inspect Oil Drain Cock (Task 8-107).



END OF TASK

8-107 INSPECT OIL DRAIN COCK**8-107**

INITIAL SETUP

Applicable Configurations:

All

Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

None


Personnel Required:

Aircraft Powerplant Inspector

1. **Inspect oil drain cock (1)** as follows:
 - a. Inspect housing (2). There shall be no cracks.
 - b. Turn valve (3). There shall be no binding.
 - c. Inspect chain (4). There shall be broken links.
2. Install cap (5).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

INITIAL SETUP

Applicable Configurations:

All

Tools:

- Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
- Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:-

Wiping Rag (E64)


Personnel Required:

- Aircraft Powerplant Repairer
- Aircraft Powerplant Inspector

General Safety Instructions:

WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.




GO TO NEXT PAGE

1. Install oil drain cock (1) on hose assembly (2).

INSPECT**FOLLOW-ON MAINTENANCE:**

Service Engine Oil System (Task 1-68).

**END OF TASK**

SECTION XV CHIP DETECTOR

8-109 REMOVE CHIP DETECTOR

8-109

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanics' Tool Kit,
NSN 5180-00-323-4944

Materials:

Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer


Equipment Condition:

Engine Oil System Drained (Task 1-69)

General Safety Instructions:


WARNING

Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.




GO TO NEXT PAGE


1. Disconnect electrical connector (1).



2. Remove nut (2), screw (3), and clamp (4).




3. Push plug (5) in and turn counterclockwise.




GO TO NEXT PAGE

8-109 REMOVE CHIP DETECTOR (Continued)**8-109**

4. Remove plug (5) and packing (6) from housing (7).
5. Inspect plug (5). There shall be no contamination, or chips. If contamination or chips are found, Inspect Contaminated Oil System (Ref. Task 1-80).



6. Remove lockwire, housing (7) and packing (8).

**FOLLOW-ON MAINTENANCE:**

None

END OF TASK**8-275**

8-110 CLEAN CHIP DETECTOR

8-110

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Goggles

Dry, Compressed Air Source

Materials:

Dry Cleaning Solvent (E19)

Gloves (E24)

Lint-Free Cloth (E30)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

Engine Oil System Drained (Task 1-69)

Chip Detector Removed (Task 8-109)

General Safety Instructions:**WARNING**


Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.


1. Clean plug (1) as follows:

- a. Wear gloves (E24). Clean plug (1) with dry cleaning solvent (E19) and agitate. Use brush on external surfaces.
- b. Use lint-free cloth (E30) to remove solvent.
- c. Wear goggles. Blow dry plug. Use clean, dry, compressed air.



2. Clean housing (2) as follows:

- a. Immerse in dry cleaning solvent (E19) and agitate. Use brush on external surfaces.
- b. Use lint-free cloth (E30) to remove solvent.
- c. Wear goggles. Blow dry internal passage. Use clean, dry, compressed air.



FOLLOW-ON MAINTENANCE:

Inspect Chip Detector (Task 8-111).

END OF TASK

8-111 INSPECT CHIP DETECTOR

8-111

INITIAL SETUP

Applicable Configurations:

All

Tools:

Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Steel Nut, 1/4-28

Materials:

None


Personnel Required:

Aircraft Powerplant Inspector


Equipment Condition:

Off Engine Task


1. Inspect plug (1) and housing (2). There shall be no cracks.
2. Check strength of magnet (3) on plug (1) by placing 1/4-28 steel nut (4) against it. Magnet (3) shall be strong enough to support weight of steel nut (4).
3. Inspect cable assembly (5). There shall be no frayed or burned installation. There shall be no loose connections or broken wires.



E-8-91




E-8-91 2




E-8-91 3

GO TO NEXT PAGE

4. Inspect sleeving (6). There shall be no frayed or broken sleeving.



5. Inspect electrical connector (7). There shall be no corrosion, broken or bent sleeves (8) or cracked insulation (9).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

8-112 TEST CHIP DETECTOR**8-112**

INITIAL SETUP

Applicable Configurations:

All

Tools:

Multimeter

Materials:

None

Personnel Required:


Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

1. Measure insulation resistance of chip detector (1) as follows: Use multimeter.

- a. Set multimeter range switch to R X 1000.
- b. Touch red probe (2) to pin A (3).
- c. touch black probe (4) to pin B (5).
- d. Meter shall indicate 10.000 ohms minimum.



FOLLOW-ON MAINTENANCE:

None

END OF TASK**8-279**

8-113 INSTALL CHIP DETECTOR**8-113**

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114Crowfoot Attachment, 7/8-Inch
Torque Wrench, 30-150 Inch-Pounds**Materials:**

Lockwire (E33)

Packings


Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector


References:

TM 1-2840-252-23P




GO TO NEXT PAGE


1. Install packing (1) in groove (2) on chip detector housing (3).



2. Install chip detector (3) in housing (4). Torque to 95 inch-pounds. Use crowfoot attachment.




3. Lockwire chip detector (3) to bolt (5). Use lock-wire (E33).




4. Install packing (6) in groove (7) on plug (8).

GO TO NEXT PAGE


5. Install plug (8) in chip detector housing (3). Lock plug (8) by pushing in and turning clockwise.



6. Insert electrical connector (9) into clamp (10).
7. Install clamp (10), screw (11), and nut (12) to bracket (13).



8. Connect electrical connector (14) to chip detector (15).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

SECTION XVI OIL LEVEL INDICATOR

8-114 REMOVE OIL LEVEL INDICATOR

8-114

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

Twine (E52)


Wiping Rag (E64)

Personnel Required:

Aircraft Powerplant Repairer


Equipment Condition:

Engine Oil System Drained (Task 1-69)




8-114 REMOVE OIL LEVEL INDICATOR (Continued)**8-114**

1. Disconnect electrical connector (1).




2. Remove lockwire, two bolts (2), two washers (3), cover (4), and two spacers (5).

**GO TO NEXT PAGE**


CAUTION

In following steps 3 and 4, do not let shaft of float slip back into housing. Failure to comply will result in engine damage.

- Remove nut (6), washer (7), bolt (8), pointer (9), and washer (10).



- Remove nut (11), washer (12), bolt (13), washer (14), housing assembly (15), and packing (16).
- Secure shaft (17) with twine (E52) to keep it from slipping back into inlet housing (18).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

8-115 DISASSEMBLE OIL LEVEL INDICATOR**8-115**

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Soldering Iron, 15/32-Pound

Twist Drill, 15/64-Inch

Retaining Ring Pliers

Materials:

None

Personnel Required:

Aircraft Powerplant Repairer


Aircraft Electrician

Equipment Condition:


Off Engine Task

Oil Level Indicator Removed (Task 8-114)

1. **Remove** two nuts (1), two washers (2), two screws (3), two washers (4), and pull switch (5) clear of housing (6).




2. Unsolder two wires (7 and 8) from two switch terminals (9) and **remove** switch (5).




GO TO NEXT PAGE


3. Slide insulation sleeving (10) back along wire (7). Unsolder and remove wire (7) from electrical connector pin (11).



4. Unsolder and remove wire (8) from bracket (12).
5. Remove tape (13).




6. Remove retaining ring (14). Use retaining ring pliers.




GO TO NEXT PAGE

7. Remove seal (15). Push out from rear of housing (6). Use shaft of twist drill (16) as pusher.



8. Remove packing (17).



FOLLOW-ON MAINTENANCE:
None

END OF TASK

8-116 CLEAN OIL LEVEL INDICATOR

8-116

INITIAL SETUP**Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Goggles

Dry, Compressed Air Source

Materials:

Dry Cleaning Solvent (E19)

Gloves (E24)

Lint-Free Cloth (E30)

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

Oil Level Indicator Removed (Task 8-114)

Oil Level Indicator Disassembled (Task 8-115)

General Safety Instructions:**WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.


WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.


1. Wear gloves (E24) and **clean housing (1)**. Use dry cleaning solvent (E19) and brush.
2. Wipe dry using lint-free cloth (E30).
3. Wear goggles. **Blow dry internal passage (2)**. Use clean, dry compressed air.
4. **Clean switch (3)** using lint-free cloth (E30) dampened in dry cleaning solvent (E19).
5. **Blow dry switch (3)** using clean, dry, compressed air.

FOLLOW-ON MAINTENANCE:

Inspect Oil Level Indicator (Task 8-117).



B-6-97.1



B-6-97.2

END OF TASK

8-117 INSPECT OIL LEVEL INDICATOR**8-117**

INITIAL SETUP

Applicable Configurations:

All

Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

None


Personnel Required:

Aircraft Powerplant Inspector

Equipment Condition:


Off Engine Task

1. **Inspect housing (1).** There shall be no cracks.



2. **Inspect electrical connector (2).**


- a. There shall be no cracks, corrosion, or looseness at joint (3).
- b. Pin (4) shall not be bent, broken, or corroded.

**GO TO NEXT PAGE**


8-117 INSPECT OIL LEVEL INDICATOR (Continued)

8-117

3. Inspect bracket (5). There shall be no cracks or loose rivets (6).



4. Inspect switch (7). There shall be no cracks.



FOLLOW-ON MAINTENANCE:
None

END OF TASK

8-118 REPAIR OIL LEVEL INDICATOR**8-118****INITIAL SETUP****Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114
Soldering Iron, 15/32-Pound
Stainless Steel Wire Brush

Materials:

Black Baking Enamel (E9)
Crocus Cloth (E16)
Solder (E54)

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Electrician
Aircraft Powerplant Inspector

Equipment Condition:

Off Engine Tank

1. Repair loose electrical connector (1) as follows:
 - a. Remove all surface contamination near joint (2). Use stainless steel wire brush.
 - b. Solder joint (2). Use solder (E54) and soldering iron.
2. Repair electrical connector pin (3) as follows:



NOTE

This repair is allowed provided it does not cause pin to break or crack.

- a. Straighten bent pin (3). Use long nose pliers to gently move pin (3) until it is straight.
 - b. Remove corrosion from pin (3). Polish pin (3), using in and out motion over entire length of pin until corrosion is removed. Use crocus cloth (E16).
3. Repair damaged paint on outside of housing (4) and bracket (5). Use black baking enamel (E9).

INSPECT**FOLLOW-ON MAINTENANCE:**

None

**END OF TASK**

8-119 ASSEMBLE OIL LEVEL INDICATOR

8-119

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,

NSN 5180-00-323-4944

Technical Inspection Tool Kit,

NSN 5180-00-323-5114

Twist Drill, 15/64-Inch

Retaining Ring Pliers

Soldering Iron, 15/32-Pound

Materials:

Insulation Sleeving (E28)

Pressure Sensitive Teflon Tape (E46)

Solder (E54)

Wire (E65)

Parts:

Packing

Seal

Personnel Required:

Aircraft Powerplant Repairer

Aircraft Electrician

Aircraft Powerplant Inspector


References:

TM 1-2840-252-23P

Equipment Condition:



Off Engine Task

1. Install packing (1) in groove (2) in housing (3).



GO TO NEXT PAGE

2. Install seal (4) in housing (3). Use shaft of twist drill (5) to push seal (4) into housing until fully seated.
3. Install retaining ring (6) in groove (7) in housing (3). Use retaining ring pliers.






GO TO NEXT PAGE

CAUTION

In following step 4, do not cover drain hole with tape. Failure to comply could cause accumulation of oil. This could cause faulty oil level indication.

4. Install teflon tape (8) inside housing (3). Use Pressure sensitive teflon tape (E46). Do not cover drain hole (9). Center teflon tape between switch mounting holes (10).
5. Install two wires (11 and 12) as follows:
 - a. Cut wires (11 and 12) to 1-1/2-inch length. Use wire ((E65).
 - b. Strip both ends of wires (11 and 12) to 1/4-inch length.
 - c. Tin both ends of wires (11 and 12). Use solder (E54) and soldering iron.
 - d. Cut 1/2-inch piece of insulation sleeving (E28). Slide sleeving (13) over wire (12).
 - e. Solder wire (11) to bracket (14). Use solder (E54) and soldering iron.





GO TO NEXT PAGE

8-119 ASSEMBLE OIL LEVEL INDICATOR (Continued)**8-119**

f. Solder wire (12) to electrical connector pin (15). Use solder (E54) and soldering iron. Slide insulation sleeving (13) over pin (15).

g. Solder wire (11) to switch terminal (16). Use solder (E54) and soldering iron.

h. Solder wire (12) to switch terminal (17). Use solder (E54) and soldering iron.

**GO TO NEXT PAGE**

CAUTION


In following step 6, do not strain or kink wires. Defective wiring could cause faulty oil level indication.

6. Install switch (18), two washers (19), two screws (20), two washers (21), and two nuts (22).

INSPECT

FOLLOW-ON MAINTENANCE:

None



END OF TASK

8-120 INSTALL OIL LEVEL INDICATOR**8-120**

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Torque Wrench, 0-30 Inch-Pounds

Materials:

Lockwire (E33)

Parts:

Packing

Personnel Required:


Aircraft Powerplant Repairer

Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P

Task 8-121





GO TO NEXT PAGE

1. Install packing (1) in groove (2) in shaft (3).

NOTE



In following steps 2 thru 5, do not let shaft of float slip back into inlet housing.

2. Remove twine. Install assembly (4), washer (5), bolt (6), washer (7), and nut (8).



GO TO NEXT PAGE


3. Install washer (9) on shaft (10) with smaller diameter (11) facing out.
4. Install pointer (12) on shaft (10) with white stripe (13) facing out.



GO TO NEXT PAGE

8-120 INSTALL OIL LEVEL INDICATOR (Continued)**8-120**

5. Position pointer (12) on shaft (10), so hole (14) is aligned with notch (15).
6. Install bolt (16) with flat (17) against notch (15). Install washer (18) and nut (19).



**GO TO NEXT PAGE**

8-120 INSTALL OIL LEVEL INDICATOR (Continued)**8-120**

7. Adjust oil level indicator (Ref. Task 8-121, steps 3 thru 7).
8. Install two spacers (20), cover (21), two washers (22), and bolts (23). Torque two bolts (23) to 15 inch-pounds. Lockwire bolts (23). Use lockwire (E33).
9. Connect electrical connector (24).

INSPECT**FOLLOW-ON MAINTENANCE:**

Service Engine Oil System (Task1-68).

**END OF TASK**

8-121 ADJUST OIL LEVEL INDICATOR**8-121**

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114
Oil Level Test Light (T9)
Torque Wrench, 0-30 Inch-Pounds

Materials:


Lockwire (E33)

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector



Equipment Condition:

Engine Oil System Drained (Task 1-69)

**GO TO NEXT PAGE**

8-121 ADJUST OIL LEVEL INDICATOR (Continued)**8-121**



1. Disconnect electrical connector (1).
2. Remove lockwire, two bolts (2), two washers (3), cover (4), and two spacers (5).

**GO TO NEXT PAGE**

8-121 ADJUST OIL LEVEL INDICATOR (Continued)

8-121

3. Connect oil level test light (T9) (6) to electrical connector (7) and turn switch (8) on.
4. Move pointer (9) from full position (10) toward empty position (11). Test light (T9) (6) shall come on at low oil level warning position (12).




GO TO NEXT PAGE

NOTE



If test light indicates adjustment is needed, do steps 5 and 6. If test light indicates adjustment is not needed, omit steps 5 and 6.

5. Loosen two screws (13) and two nuts (14). Move switch (15) until test light (T9) (6) comes on at low oil level warning position (12).
6. Tighten two nuts (14) and two screws (13).



GO TO NEXT PAGE

7. Turn switch (8) off and disconnect test light (T9) (6) from electrical connector (7).
8. Install two spacers (5), cover (4), two washers (3), and two bolts (2). Torque two bolts (2) to 15 inch-pounds. Lockwire two bolts (2). Use lockwire (E33).




GO TO NEXT PAGE

9. Connect electrical connector (1).

INSPECT**FOLLOW-ON MAINTENANCE:**

Service Engine Oil System (Task 1-68).

**END OF TASK**

SECTION XVII
OIL LEVEL FLOAT ASSEMBLY

8-122 REMOVE OIL LEVEL FLOAT ASSEMBLY (AVIM)

8-122

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

Wiping Rag (E64)

Personnel Required:


Aircraft Powerplant Repairer

Equipment Condition:

Engine Oil System Drained (Task 1-69)


Output Shaft Seal and Housing Assembly Re-
moved (Task 2-39)

Inlet Housing Cover Assembly Removed (Task
2-44)



GO TO NEXT PAGE

1. Remove lockwire, two bolts (1), two washers (2), cover (3), and two spacers (4).





GO TO NEXT PAGE

8-122 REMOVE OIL LEVEL FLOAT ASSEMBLY (AVIM) (Continued)**8-122**

2. Remove nut (5), washer (6), bolt (7), pointer (8), and washer (9).
3. Remove oil level float assembly (10).

FOLLOW-ON MAINTENANCE:

None

**END OF TASK****8-311**

8-123 DISASSEMBLE OIL LEVEL FLOAT ASSEMBLY (AVIM)**8-123**

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Materials:**

None

Personnel Required:

Aircraft Powerplant Repairer

Equipment Condition:

Off Engine Task

Engine Oil System Drained (Task 1-69)


Output Shaft Seal and Housing Assembly Re-
moved (Task 2-39)Inlet Housing Cover Assembly Removed (Task
2-44)

Oil Level Float Assembly Removed (Task 8-122)

1. Remove cotter pin (1), nut (2), washer (3), and float (4).

FOLLOW-ON MAINTENANCE:

None



END OF TASK

8-124 CLEAN OIL LEVEL FLOAT ASSEMBLY (AVIM)**8-124****INITIAL SETUP****Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944**Materials:**Dry Cleaning Solvent (E19)
Gloves (E24)
Lint-Free Cloth (E64)**Personnel Required:**



Aircraft Powerplant Repairer

Equipment Condition:Off Engine Task
Engine Oil System Drained (Task 1-69)
Output Shaft Seal and Housing Assembly Re-
moved (Task 2-39)Inlet Housing Cover Assembly Removed (Task
2-44)
Oil Level Float Assembly Removed (Task 8-122)
Oil Level Float Assembly Disassembled (Task
8-123)**General Safety Instructions:****WARNING****Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.**

1. Wear gloves (E24) and clean float (1). Use dry cleaning solvent (E19) and brush.
2. Wipe dry using lint-free cloth (E64).
3. Clean shaft (2). Use dry cleaning solvent (E19) and brush.
4. Wipe dry using lint-free cloth (E64).

FOLLOW-ON MAINTENANCE:

Inspect Oil Level Float Assembly (Task 8-125).

**END OF TASK**

8-125 INSPECT OIL LEVEL FLOAT ASSEMBLY (AVIM)**8-125****INITIAL SETUP****Applicable Configurations:**

All

Tools:

Technical Inspection Tool Kit,
NSN 5180-00-323-5114
Outside Micrometer Caliper Set

Materials:

None

Personnel Required:

Aircraft Powerplant Inspector



Equipment Condition:

Off Engine Task

1. Inspect float (1). There shall be no cracks.
2. Inspect hole (2) in float (1). Hole diameter shall be 0.240 inch maximum.
3. Inspect shaft (3). There shall be no cracks.
4. Inspect notch (4). There shall be no nicks, burrs, or scratches deeper than 0.020 inch on flat surface (5).
5. Inspect float mounting area (6). Use outside micrometer caliper. Shaft diameter shall be 0.184 inch minimum.
6. Inspect washer (7). Washer (7) shall not be cracked, loose, or missing.

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

8-126 REPAIR OIL LEVEL FLOAT ASSEMBLY (AVIM)**8-126**

INITIAL SETUP

Applicable Configurations:

All

Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**Carborundum Stone (E11)
Crocus Cloth (E16)**Personnel Required:**Aircraft Powerplant Repairer
Aircraft Powerplant Inspector**Equipment Condition:**

Off Engine Task

1. Repair nicks, burrs, and scratches on flat surface (1) of float shaft notch (2) as follows:


NOTE

Repair is allowed only if depth of defect after repair is not more than 0.020 inch.

- a. Blend all raised edges (3). Use carborundum stone (E11).
- b. Polish to smooth finish. Use crocus cloth (E16).

INSPECT**FOLLOW-ON MAINTENANCE:**

None

**END OF TASK****8-315**

8-127 ASSEMBLE OIL LEVEL FLOAT ASSEMBLY (AVIM)**8-127****INITIAL SETUP****Applicable Configurations:**

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

None

Parts:

Cotter Pin

Personnel Required:

Aircraft Powerplant Repairer
Aircraft Powerplant Inspector

References:

TM 1-2840-252-23P


Equipment Condition:

Off Engine Task

CAUTION

When installing float, tighten nut only enough to seat float against washer. If nut is overtightened, damage to float will occur.

1. Install float (1), washer (2), and nut (3) on shaft (4).
2. Hand-tighten nut (3) until float (1) is seated against washer (5).


**GO TO NEXT PAGE**

3. Back off nut (3), a maximum of one slot, until slot (6) in nut (3) aligns with shaft hole (7).
4. Install cotter pin (8).

INSPECT

FOLLOW-ON MAINTENANCE:

None

**END OF TASK**

8-317

8-128 INSTALL OIL LEVEL FLOAT ASSEMBLY (AVIM)

8-128

INITIAL SETUP

Applicable Configurations:

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Torque Wrench, 0-30 Inch-Pounds

Materials:

Lockwire (E33)


Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector

References:


Task 8-121




B-6-109/1

GO TO NEXT PAGE

1. Install oil level float assembly (1) in hole (2) in inlet housing (3).





2. Hold shaft (4) in place. Install washer (5) on shaft (4) with smaller diameter (6) facing out.



GO TO NEXT PAGE

8-128 INSTALL OIL LEVEL FLOAT ASSEMBLY (AVIM) (Continued)**8-128**

3. Install pointer (7) on shaft (4) with white stripe (8) facing out.
4. Position pointer (7) on shaft (4) with hole (9) aligned with notch (10).
5. Install bolt (11) with flat (12) against notch (10). Install washer (13) and nut (14).


**GO TO NEXT PAGE**

8-128 INSTALL OIL LEVEL FLOAT ASSEMBLY (AVIM) (Continued)**8-128**

6. Adjust oil level indicator (Ref. Task 8-121, steps 3 thru 7).
7. Install two spacers (15), cover (16), two washers (17), and two bolts (18). Torque bolts (18) to 15 inch-pounds. Lockwire bolts (18). Use lockwire (E33).

INSPECT**FOLLOW-ON MAINTENANCE:**

- Install Inlet Housing Cover Assembly (Task 2-48).
- Install Output Shaft Seal and Housing Assembly (Task 2-43).
- Service Engine Oil System (Task 1-68).

**END OF TASK****8-322**

CHAPTER 9
TORQUEMETER SYSTEM - MAINTENANCE SYSTEM

CHAPTER OVERVIEW

This chapter contains maintenance procedures for the torquemeter system. It is divided into the following sections and tasks:

<u>SECTION</u>	<u>TASK NO.</u>	<u>TITLE</u>	<u>PAGE</u>
I		TORQUEMETER SENSOR	
	9-1	Remove Torquemeter Sensor	9-3
	9-2	Clean Torquemeter Sensor	9-6
	9-3	Inspect Torquemeter Sensor	9-7
	9-4	Repair Torquemeter Sensor	9-8
	9-5	Install Torquemeter Sensor	9-9

SECTION I TORQUEMETER SENSOR

9-1 REMOVE TORQUEMETER SENSOR

9-1

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944

Materials:

Wiping Rag (E64)


Personnel Required:

Aircraft Powerplant Repairer

General Safety Instructions:

WARNING



Lubricating oils cause paralysis if swallowed. Prolonged contact with them may irritate the skin. Handle only in well-ventilated areas away from heat and flame. Drain and store in approved metal safety containers. Avoid prolonged or repeated contact with skin and do not take internally. Wash contacted area of skin thoroughly after handling. If irritation of skin results, get medical attention. Get medical attention for eyes.



GO TO NEXT PAGE

9-1 REMOVE TORQUEMETER SENSOR (Continued)**9-1**

1. Disconnect hose assembly (1).
2. Disconnect electrical connector (2).


**GO TO NEXT PAGE**

9-1 REMOVE TORQUEMETER SENSOR (Continued)**9-1**

3. Remove lockwire, four screws (3), data plate (4), two washers (5), torque meter sensor (6), and packing (7).

FOLLOW-ON MAINTENANCE:

None



B-9-14

END OF TASK

9-2 CLEAN TORQUEMETER SENSOR**9-2****INITIAL SETUP****Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Goggles
Compressed Air Source**Materials:**Dry Cleaning Solvent (E19)
Gloves (E24)
Lint-Free Cloth (E30)**Personnel Required:**

Aircraft Powerplant Repairer

Equipment Condition:Off Engine Task
Torquemeter Sensor Removed (Task 9-1)**General Safety Instructions:****WARNING**

Dry cleaning solvent (E19) is flammable and toxic. It can irritate skin and cause burns. Use only in well-ventilated area, away from heat and open flame. In case of contact, immediately flush skin or eyes with water for at least 15 minutes. Get medical attention for eyes.

1. Clean torquemeter sensor (1) as follows:

a. Wear gloves (E24) and clean torquemeter sensor (1). Use lint-free cloth (E30) dampened with dry cleaning solvent (E19).

b. Use dry, lint-free cloth (E30) to remove solvent.


WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

c. Wear goggles. Blow dry electrical connector (2) and inside surfaces (3). Use clean, dry compressed air.

FOLLOW-ON MAINTENANCE:

Inspect Torquemeter Sensor (Task 9-3).

**END OF TASK**

9-3 INSPECT TORQUEMETER SENSOR**9-3**

INITIAL SETUP

Applicable Configurations:

All

Tools:Technical Inspection Tool Kit,
NSN 5180-00-323-5114**Materials:**

None

Personnel Required:

Aircraft Powerplant Inspector

Equipment Condition:



Off Engine Task

1. Inspect torquemeter sensor (1) as follows:

- a. Inspect body (2). There shall be no cracks, distortion, or dents (3).
- b. Inspect electrical connector (4). There shall be no broken, corroded or bent pins (5), or damaged insulation (6).

FOLLOW-ON MAINTENANCE:

None



END OF TASK

9-4 REPAIR TORQUEMETER SENSOR**9-4****INITIAL SETUP****Applicable Configurations:**

All

Tools:Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Goggles

Dry, Compressed Air Source

Materials:

Crocus Cloth (E16)

Personnel Required:

Aircraft Powerplant Repairer

Aircraft Powerplant Inspector

Equipment Condition:

Off Engine Task

NOTE

This repair is allowed provided it does not cause pins to break or crack.

1. Straighten bent pins (1) of electrical connector (2). Using long-nose pliers, gently move pins (1) until they are straight.
2. Remove corrosion from pin (1) of electrical connector (2). Polish pins using in and out motion over entire length of pin until corrosion is removed. Use crocus cloth (E16).



WARNING

When using compressed air for cleaning, use approved protective equipment for eyes and face. Do not use more than 30 psig air pressure. Do not direct air toward yourself or another person. Failure to comply could result in injury to eyes or skin. In case of injury, get medical attention.

3. Wear goggles. Remove loosened particles from connector (2), using clean, dry, compressed air.

INSPECT**FOLLOW-ON MAINTENANCE:**

None

**END OF TASK**

9-5 INSTALL TORQUEMETER SENSOR

9-5

INITIAL SETUP

Applicable Configurations:

All

Tools:

Powerplant Mechanic's Tool Kit,
NSN 5180-00-323-4944
Technical Inspection Tool Kit,
NSN 5180-00-323-5114

Materials:

Lockwire (E33)
Anti-Seize Compound (E6)

Parts:


Packing

Personnel Required:

Aircraft Powerplant Repairer (2)
Aircraft Powerplant Inspector

References:



TM 1-2840-252-23P



GO TO NEXT PAGE

9-5 INSTALL TORQUEMETER SENSOR (Continued)**9-5**

1. Install packing (1) in groove (2) of flange (3).
2. Position torquemeter sensor (4) with electrical connector (5) at 7-o'clock location.

**GO TO NEXT PAGE**



CAUTION

Torque meter sensor is spring-loaded into housing and must be installed squarely and evenly. Failure to do so could result in damage to sensor.

NOTE

Do not lockwire over data plate.

3. Install torque meter sensor (4), four screws (6), data plate (7), and two washers (8). Stagger-tighten and lockwire screws (6). Use lockwire (E33).
4. Connect electrical connector (9) to torque meter sensor (4).




GO TO NEXT PAGE

9-5 INSTALL TORQUEMETER SENSOR (Continued)**9-5**

5. Connect hose assembly (10) to adapter nipple (11).

INSPECT**FOLLOW-ON MAINTENANCE:**

None

**END OF TASK**

APPENDIX A

REFERENCES

PUBLICATION NUMBER	TITLE
AR 750-50	Army Material Maintenance Concepts and Policies.
TM 1 1520-252-MTF	Maintenance Test Flight Manual Army Model MH47E Helicopter
TM 1-1520-252-T	Aviation Unit and Aviation Intermediate Troubleshooting Manual Army MH47E Helicopter.
TM 1-1520-252-10	Operator's Manual Army MH47E Helicopter Aircraft.
TM 1-1520-252-23	Aviation Unit and Aviation Intermediate Maintenance Manual Army MH47E Helicopter.
TM 1-2840-252-23	Aviation Unit and Aviation Intermediate Maintenance Repair Parts and Special Tools List.
CTA 50-970	Expendable Items (Except Medical, Class V, Repair Parts, and Heraldic Items).
TB 43-0106	Spectrographic Oil Analysis.
TB 43-0142	Lifting Devices, Inspection, Testing and Maintenance.
TB 1-1500-341-01	Aircraft Components Requiring Maintenance Management and Historical Data.
TB 55-8100-200-25	Maintenance of Specialized Reusable Containers for Aircraft Equipment.
TB 55-9150-200-25	Engine and Transmission Oils, Fuels, and additives for Army Aircraft.
DA PAM 738-751	The Army Maintenance Management System (TAMMS).
TM 1-1500-335-23	Non Destructive Inspection Methods
TM 1-1500-204-23	General Aircraft Maintenance Manual
TM 55-1500-328-25	Aeronautical Equipment Maintenance Management Policies and Procedures.

**APPENDIX A (Continued)
REFERENCES**

PUBLICATION NUMBER	TITLE
TM 55-4920-328-13	Modular Engine Test Systems Maintenance Manual.
FM 1-511	Maintenance Quality Control and Technical Inspection Guide for Army Aircraft.
TM 750-244-1-5	Procedures for the Destruction of Aircraft and Associated Equipment to Prevent Enemy Use.

**APPENDIX B
MAINTENANCE ALLOCATION CHART**

SECTION I. INTRODUCTION

B-1 MAINTENANCE ALLOCATION CHART

a. This Maintenance Allocation Chart (MAC) assigns maintenance functions in accordance with the Three Levels of Maintenance concept for Army aviation. These maintenance levels (categories) Aviation Unit Maintenance (AVUM), Aviation intermediate Maintenance (AVIM), and Depot Maintenance are depicted on the MAC as:

AVUM, which corresponds to an O Code in the Repair Parts and Special Tools List (RPSTL).

AVIM, which corresponds to an F Code in the Repair Parts and Special Tools List (RPSTL).

DEPOT, which corresponds to a D Code in the Repair Parts and Special Tools List (RPSTL).

b. The maintenance to be performed below depot and in the field is described as follows:

(1) Aviation Unit Maintenance (AVUM) activities will be staffed and equipped to perform high frequency "On-Aircraft" maintenance tasks required to retain or return aircraft systems to a serviceable condition. The maintenance capability of the AVUM will be governed by the Maintenance Allocation Chart (MAC) and limited by the amount and complexity of ground support equipment (GSE), facilities required, authorized manning strength, and critical skills available. The range and quantity of authorized spare modules/components will be consistent with the mobility requirements dictated by the air mobility concept. (Assignments of maintenance tasks to divisional company size aviation units will consider the overall maintenance capability of the division, the requirement to conserve personnel and equipment resources, and air mobility requirements.)

(a) Company Size Aviation Units: Perform those tasks which consist primarily of preventive maintenance and maintenance repair and replacement functions associated with sustaining a high level of aircraft operational readiness. Perform maintenance inspections and servicing to include preflight, daily, intermediate, periodic (or phased), and special inspections as authorized by the MAC or high headquarters. Identify the cause of equipment/system malfunctions using applicable technical manual troubleshooting instructions, built-in test equipment (BITE), installed aircraft instruments, or test, measurement, and diagnostic equipment (TMDE). Replace worn or damaged modules/components that do not require complex adjustments or system alignment and which can be removed/installed with available skills, tools, and ground support equipment. Perform operational and continuity checks and make minor repairs to the electrical system. Inspect, service and make operational, capacity, and pressure checks to hydraulic systems. Perform servicing, functional adjustments, and minor repair/ replacement to the flight control, propulsion, power train, and fuel systems. Accomplish airframe repair that does not require extensive disassembly, jiggling, or alignment. The manufacture of airframe repair will be limited to those items which can be fabricated with tools and equipment found in current air mobile tool and shop sets. Evacuate unserviceable modules/components and end items beyond the repair capability of AVUM to the supporting AVIM.

(b) Less than Company Size Aviation Units: Aviation elements organic to brigade, group, battalion headquarters, and detachment size units are normally small and have less than ten aircraft assigned. Maintenance tasks performed by these units will be those which can be accomplished by the aircraft crew chief or assigned aircraft repairman and will normally be limited to preventive maintenance, inspections, servicing, spot painting, stop drilling, application of nonstress patches, minor adjustments, module/component fault diagnosis, and replacement of selected modules/components. Repair functions will normally be accomplished by the supporting AVIM unit.

(2) Aviation Intermediate Maintenance (AVIM) provides mobile, responsive "One-Stop" maintenance support. (Maintenance functions which are not conducive to sustaining air mobility will be assigned to depot maintenance). AVIM may perform all maintenance functions authorized to be done at AVUM. Repair of equipment for return to user will emphasize support or operational readiness requirements. Authorized maintenance includes replacement and repair of modules/components and end items which can be accomplished efficiently with available skills, tools, and equipment. AVIM establishes the Direct Exchange (DX) program for AVUM units by repairing selected items for return to stock when such repairs cannot be accomplished at the AVUM level. The AVIM level inspects, troubleshoots, performs diagnostic tests, repairs, adjusts, calibrates, and aligns aircraft system modules/components. AVIM units will have capability to determine the serviceability of specified modules/components removed prior to the expiration of the Time Between Overhaul (TBO) or finite life. Module/component disassembly and repair will support the DX program and will normally be limited to tasks requiring cleaning and the replacement of seals, fittings, and items of common hardware. Airframe repair and fabrication of parts will be limited to those maintenance tasks which can be performed with available tools and test equipment. Unserviceable repairable modules/components and end items which are beyond the capability of AVIM to repair will be evacuated to Depot Maintenance. AVIM will perform aircraft weight and balance inspections and other special inspections which exceed AVUM capability. Provides quick response maintenance support, including aircraft recovery and air evacuation, on-the job training, and technical assistance through the use of mobile maintenance contact teams. Maintains authorized operational readiness float aircraft. Provides collection and classification services for serviceable/unserviceable material. Operates a cannibalization activity in accordance with AR 750-1. (The aircraft maintenance company within the maintenance battalion of a division will perform AVIM functions consistent with air mobility requirements and conservation of personnel and equipment resources. Additional intermediate maintenance support will be provided by the supporting nondivisional AVIM unit.)

B-2 USE OF THE MAINTENANCE ALLOCATION CHART (SECTION II)

NOTE

Nomenclatures used throughout the MAC are approved item names. Those terms/nomenclatures expressed in parentheses are generic in nature and are not to be considered as official terminology.

a. The Maintenance Allocation Chart assigns maintenance functions based on past experience and the following consideration:

- (1) Skills available.
- (2) Work time required.
- (3) Tools and test equipment required and/or available.

- b. The assigned levels of maintenance authorized to perform a maintenance function are indicated.
- c. A maintenance function assigned to a maintenance category will automatically be authorized to be performed at any higher maintenance category.
- d. A maintenance function that cannot be performed at the assigned category of maintenance for any reason may be evacuated to the next higher maintenance category. Higher maintenance categories will perform the maintenance functions of lower maintenance categories when required or directed by the commander that has the authority to direct such tasking.
- e. The assignment of a maintenance function will not be construed as authorization to carry the related repair parts or spares in stock. Information to requisition or otherwise secure the necessary repair parts will be as specified in the associated Repair Parts and Special Tools List (RPSTL).
- f. Normally there will be no deviation from the assigned level of maintenance. In cases of operational necessity, maintenance functions assigned to a maintenance level may, on a one-time basis and at the request of the lower maintenance level, be specifically authorized by the maintenance officer of the level of maintenance to which the function is assigned. The special tools, equipment, etc., required by the lower level of maintenance to perform this function will be furnished by the maintenance level to which the function is assigned. This transfer of a maintenance function to a lower maintenance level does not relieve the higher maintenance level of the responsibility for the function. The higher level of maintenance will provide technical supervision and inspection of the function being performed at the lower level.
- g. Changes to the Maintenance Allocation Chart will be based on continuing evaluation and analysis by responsible technical personnel and on reports received from field activities.

B-3 MAINTENANCE FUNCTIONS

Maintenance functions will be limited to and defined as follows:

- a. Inspect. To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination (e.g. , by sight, sound, or feel).
- b. Test. To verify serviceability by measuring the mechanical, pneumatic, hydraulic, or electrical characteristics of an item and comparing those characteristics with prescribed standards.
- c. Service. Operations required periodically to keep an item in proper operating condition, i.e., to clean (includes decontaminate, when required), to preserve, to drain, to paint, or to replenish fuel, lubricants, chemical fluids, or gases.
- d. Adjust. To maintain or regulate, within prescribed limits, by bringing into proper or exact position, or by setting the operating characteristics to specified parameters.
- e. Align. To adjust specified variable elements of an item to bring about optimum or desired performance.
- f. Calibrate. To determine and cause corrections to be made or to be adjusted on instruments or test, measuring, and diagnostic equipment used in precision measurement. Consists of comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.

g. Remove/Install. To remove and install the same item when required to perform service or other maintenance functions. Install may be the act of emplacing, seating, or fixing into position a spare, repair part, or module (component or assembly) in a manner to allow the proper functioning of equipment or system.

h. Replace. To remove an unserviceable item and install a serviceable counterpart in its place. "Replace" is authorized by the MAC and is shown as the third position code of the SMR code.

i. Repair. The application of maintenance services¹, including fault location/troubleshooting², removal/installation, and disassembly/assembly³ procedures, and maintenance actions⁴ to identify troubles and restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.

j. Overhaul. That maintenance effort (service/action) prescribed to restore an item to a completely serviceable/operational condition as required by maintenance standards in appropriate technical publications (i.e., DMWR). Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like new condition.

k. Rebuild. Consists of those services/actions necessary for the restoration of unserviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of material maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (hours/miles, etc.) considered in classifying Army equipment/components.

1. Services - inspect, test, service, adjust, align, calibrate, and/or replace.

2. Fault locate/troubleshoot - The process of investigating and detecting the cause of equipment malfunctioning; the act of isolating a fault within a system or unit under test (UUT).

3. Disassemble/assemble - encompasses the step-by-step taking apart (or breakdown) of a spare/functional group coded item to the level of its least componency identified as maintenance significant (i.e., assigned an SMR code) for the category of maintenance under consideration.

4. Actions - welding, grinding, riveting, straightening, facing, remachining and/or resurfacing.

B-4 FUNCTIONAL GROUPS (COLUMNS 1 AND 2)

The functional groupings shown in the sample below identify maintenance significant components, assemblies, subassemblies, and modules with the next higher assembly.

GROUP NUMBER	DESCRIPTION	GROUP NUMBER	DESCRIPTION
04	POWERPLANT	0406	FUEL SYSTEM
0401	ENGINE GENERAL Servicing, handling, inspection requirements, lubrication charts, overhaul and retirement schedules, External lines & hoses. (As applicable)	0407	ELECTRICAL SYSTEM
0402	COMPRESSOR SECTION (COLD SECTION MODULE) Rotor, blades, vanes, impeller, Stators, inlet guide vanes, main frame, particle separator, bleed valve, bearings, seals, external lines & hoses.	0408	OIL SYSTEM
0403	COMBUSTION SECTION (HOT SECTION MODULE) Liners, nozzles, stators, rotor, seals, couplings, blades.	0409	DRIVE SYSTEM
0404	POWER-TURBINE (POWER TURBINE MODULE) Nozzles, rotors, blades, exit guide vanes, exhaust frame, drive shaft, bearings, seals, external lines and hoses.	0410	MISCELLANEOUS EQUIPMENT (As applicable)
0405	ACCESSORY GEAR SECTION Input/and output gears, seals, chip detector, housings, drive shaft, bearings, and seals.		

B-5 MAINTENANCE FUNCTION (COLUMN 3)

Column 3 lists the functions to be performed on the items listed in column 2.

B-6 MAINTENANCE CATEGORIES AND WORK TIMES (COLUMN 4)

The maintenance categories (levels) AVUM, AVIM, and DEPOT are listed on the Maintenance Allocation Chart with individual columns that include the work times for maintenance functions at each maintenance level. Work time presentations such as "0.1" indicate the average time it requires a maintenance level to perform a specified maintenance function. If a work time has not been established, the columnar presentation shall indicate "-.Maintenance levels higher than the level of maintenance indicated are authorized to perform the indicated function.

B-7 TOOLS AND TEST EQUIPMENT (COLUMN 5 AND SECTION III)

Common tool sets (not individual tools), special tools, test, and support equipment required to perform maintenance functions are listed alphabetically in Section III with a reference number to permit cross-referencing to column 5 in the MAC. In addition, the maintenance category authorized to use the device is listed along with the item National stock number (NSN), and, if applicable, the tool number to aid in identifying the tool/device.

B-8 REMARKS (COLUMN 6 AND SECTION IV)

Remarks (identified by an alphabetic code in column 6) and other notes (identified by a number in parentheses in the applicable column) are listed in Section IV to provide a ready reference to the definition of the remark/note.

SECTION II

MAINTENANCE ALLOCATION CHART

NOMENCLATURE OF END ITEMS

T55-L-714

(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
NOTE							
<p>The maintenance functions identified herein, are restricted to company size units. These units are authorized (AVUM #2) Tool Set SC4920-49-CL-A92 and have 10 or more aircraft assigned. Refer to paragraph B-1.</p>							
0400	POWERPLANT AND RELATED SYSTEMS						
0401	ENGINE, COMPLETE ASSEMBLY	INSPECT	--			51,52	
	(METS) TRAILER	TEST	--	--			A B
		ADJUST	--			51,52	H, I
		SERVICE	--			51,52	
		REPLACE	--			47,51,52	C
		REPAIR	--			51,52	C,D,E,K
				--		44,45,46	
0402	COMPRESSOR SECTION	OVERHAUL			--		
040201	INTERSTAGE AIR-BLEED ACTUATOR	INSPECT	--			51,52,53	
		ADJUST	--			51,52	A,H,I
		REPLACE	--			51,52	C
		REPAIR	--			51,52	D,E,G
		OVERHAUL			--		
040202	COMPRESSOR BLEED BAND	INSPECT	--			51,52,53	
		REPLACE	--			51,52	A

MAINTENANCE ALLOCATION CHART							
NOMENCLATURE OF END ITEMS							
T55-L-714							
(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
040203	ANTI-ICING, AIR GALLERY	INSPECT	--			51,52,53	
		REPLACE	--			51,52	C
		REPAIR	--			51,52	C,D,E,G
040204	COMPRESSOR HOUSING	INSPECT	--			51,52,53	
		REPLACE	--			37,43,45,52	
		REPAIR	--			51,52	C,D,E,G
040205	STATOR VANE ASSEMBLIES	INSPECT	--			51,52,53	
		REPLACE	--			29,32,36,43,51,52	
		REPAIR	--			51,52	C,D,E,G
040206	COMPRESSOR ROTOR BLADES	INSPECT	--			51,52,53	
		REPLACE	--			10,48,50,52	
		REPAIR	--			52	
040207	OUTPUT SHAFT SEAL AND HOUSING ASSEMBLY	INSPECT	--			51,52,53	
		REPLACE	--			2,27,51,52	C,K
		REPAIR	--			26,51	M
040208	INLET HOUSING COVER ASSEMBLY	INSPECT	--			51,52,53	
		REPLACE		--		24,51,52	
		REPAIR		--		51,52	
040209	AIR INLET HOUSING ASSEMBLY	INSPECT	--			51,52,53	
		REPLACE		--			
		REPAIR	--			51	D,E,F,G
040210	T1 TEMPERATURE SENSOR	INSPECT	--			51,52,53	
		REPLACE	--			51,52	
		REPAIR	--			51,52	

MAINTENANCE ALLOCATION CHART							
NOMENCLATURE OF END ITEMS							
T55-L-714							
(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
040211	AIR LINES	INSPECT	--			51,52,53	
		REPLACE	--			51,52	
0403	COMBUSTION SECTION						
040301	FUEL DRAIN VALVE	INSPECT	--			51,52,53	
		REPLACE	--			51,52	
		OVER-HAUL			--		
040302	COMBUSTION CHAMBER VANE ASSEMBLY	INSPECT		--		45,51,52,53	
		REPLACE		--		45,52	
		REPAIR		--		45,52	D,E,F,G
040303	COMBUSTION CHAMBER LINER	INSPECT	--			45,51,52,53	
		REPLACE		--		45,52	
		REPAIR		--		45,52	D,E,F,G
040304	COMBUSTION CHAMBER HOUSING	INSPECT	--			51,52,53	
		REPLACE		--		18,44,45	
		REPAIR		--		44,45,46	D,E,F,G
0404	TURBINE SECTION						
040401	THERMOCOUPLE JUMPER LEAD	INSPECT	--			51,52,53	
		TEST	--			51,54	
		REPLACE	--			51,52	C
040402	LEFT- AND RIGHT-HAND BUS BAR ASSEMBLIES	INSPECT	--			51,52,53	
		TEST	--			51,53	
		REPLACE	--			51,52	C
040403	FIRESHIELD ASSEMBLY	INSPECT	--			51,52,53	
		REPLACE	--			51,52	C

MAINTENANCE ALLOCATION CHART							
NOMENCLATURE OF END ITEMS							
T55-L-714							
(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
040404	FIRESHIELD SECTION	INSPECT	--			51,52,53	C
040405	THERMOCOUPLE HARNESS ASSEMBLIES	REPLACE INSPECT	--	--		51,52 45,51,53	
040406	THERMOCOUPLE HARNESS ASSEMBLIES	TEST REPLACE INSPECT		--		45,52 45 45,51,52, 53	D,E,F,G
040407	FOURTH STAGE POWER TURBINE ROTOR	REPLACE REPAIR INSPECT		--		20,45,52 44,45,46 45,51,52, 53	
040408	NO. 4 AND 5 BEARING PACKAGE	REPAIR INSPECT REPLACE		--	--	3,5,11,16, 20,25,28, 34,42,52, 53 45,49,51, 52,56 5,15,17, 25,28,34, 36,45,46, 49,51,52, 54,56	
040409	FOURTH STAGE POWER TURBINE NOZZLE	INSPECT REPLACE OVER-HAUL		--	--	45,51,52, 53	K
040410	THIRD STAGE POWER TURBINE ROTOR	INSPECT REPLACE REPAIR		--		45,51,52, 53 11,45,51, 52,53	
					--		

MAINTENANCE ALLOCATION CHART							
NOMENCLATURE OF END ITEMS							
T55-L-714							
(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
040411	SECOND TURBINE DISC ASSEMBLY	INSPECT		--		51,52,53	
		REPLACE		--		3,5,11,12,21,34,41,52,53	
040412	FIRST TURBINE DISC ASSEMBLY	REPAIR		--		44,52	D,E
		INSPECT		--		51,52,53	
040413	SECOND TURBINE NOZZLE, SPACER, CASE, AND BUMPER	REPLACE		--		3,5,11,12,21,34,38,52,53	D,E
		REPAIR		--		44,52	
040414	TAILPIPE ASSEMBLY	INSPECT	--	--		51,52,53	D,E,F,G
		REPLACE	--	--		51,52	
040501	ACCESSORY GEAR SECTION ACCESSORY GEARBOX ASSEMBLY	REPAIR		--		51,52	C,G
		INSPECT	--	--		51,52,53	
040502	PT SPEED PICKUP	REPLACE	--	--		2,3,14,19,23,24,34,51,52	D,E C,D,E,G, J,K
		REPAIR	--	--		15,52,44,45	
		INSPECT	--	--		51,52,53	E
		REPLACE	--	--		51,52	
		REPAIR	--	--		52,53.	

MAINTENANCE ALLOCATION CHART							
NOMENCLATURE OF END ITEMS							
T55-L-714							
(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
040503	PT SPEED PICKUP DRIVE ASSEMBLY	INSPECT		--		51,52,53	
		REPLACE		--		51,52	
		REPAIR		--		53	D
040504	ACCESSORY GEAR ASSEMBLY	INSPECT	--			51,52,53	
		REPLACE	--			2,3,19,23,34,35,36	
040505	STARTER DRIVE ASSEMBLY	INSPECT	--			51,52,53	
		REPLACE	--			51,52	C
		REPAIR	--			3,24,30,51,52	D,E,G,J,M
040506	OVERSPEED DRIVE AND OUTLET COVER ASSEMBLY	INSPECT	--			51,52,53	
		REPLACE	--			51,52	
		REPAIR	--			51,52,53	
0406	FUEL SYSTEM						
040601	HYDROMECHANICAL ASSEMBLY	INSPECT	--			51,52,53	
		REPLACE	--			51,52	
		OVERHAUL	--				
040602	FUEL BOOST PUMP ASSEMBLY	INSPECT	--			51,52,53	
		REPLACE	--			51,52	
		REPAIR	--			51,52	D,E,G,M
		OVERHAUL	--				
040603	LEFT- AND RIGHT-HAND FUEL MANIFOLD ASSEMBLIES	INSPECT	--		--	51,52,53	
		REPLACE	--			51,52,55	C
		REPAIR	--			45	K
		OVERHAUL	--		--		
040604	PRIMER TUBE ASSEMBLY	INSPECT	--			51,52,53	

MAINTENANCE ALLOCATION CHART							
NOMENCLATURE OF END ITEMS							
T55-L-714							
(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
040605	START FUEL NOZZLES	REPLACE	--			51,52	C
		INSPECT	--			51,52,53	
040606	MAIN FUEL FILTER AND BRACKET	REPLACE	--			51,52	C
		INSPECT	--			51,52,53	
040607	IN-LINE FUEL FILTER ASSEMBLY	REPLACE	--			51,52	C
		INSPECT	--			51,52,53	
040608	PRESSURIZING VALVE	REPLACE	--			51,52	C,D,E,J
		INSPECT	--			51,52,53	
040609	FLOW DIVIDER AND BRACKET	REPLACE	--			51,52	C
		INSPECT	--			51,52,53	
040610	FUEL CHECK VALVE	REPLACE	--			51,52	C
		INSPECT	--			51,52,53	
040611	OVERSPEED SOLENOID VALVE	REPLACE	--			51,52	C
		INSPECT	--			51,52,53	
040612	STARTING FUEL SOLENOID VALVE	REPLACE	--			51,52	C,D
		INSPECT	--			51,52,53	
040613	FUEL LINES	REPLACE	--			51,52	C
0407	ELECTRICAL AND IGNITION SYSTEMS	INSPECT	--			51,52	
040701	IGNITION COIL AND CABLE ASSEMBLY	INSPECT	--			51,52,53	A
040702	SPARK IGNITERS	REPLACE	--			51,52	C
		INSPECT	--			51,52,53	A
040703	PRIMARY ELECTRICAL HARNESS ASSEMBLY	REPLACE	--			51,52	C
		INSPECT	--			51,52,53	

MAINTENANCE ALLOCATION CHART							
NOMENCLATURE OF END ITEMS							
T55-L-714							
(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
040704	REVERSIONARY ELECTRICAL HARNESS ASSEMBLY	REPLACE INSPECT	-- --			51,52 51,52,53	C
040705	ACCESSORY ELECTRICAL HARNESS ASSEMBLY	REPLACE INSPECT	-- --			51,52 51,52,53	C
0408 040801	LUBRICATION SYSTEM MAIN OIL PUMP, SPEED PICK-UP DRIVE ASSEMBLY, SCAVENGE OIL SCREEN, AND RELATED PARTS	REPLACE INSPECT	-- --			51,52 51,52,53	C
		ADJUST REPLACE REPAIR OVERHAUL	-- -- -- --	--		51,52 51,52 51,52	C D,G,J,M
040802	GAS PRODUCER SPEED PICK-UP	INSPECT	--		--	51,52,53	
040803	OIL COOLER ASSEMBLY	REPLACE INSPECT REPLACE REPAIR OVERHAUL	-- -- -- --			51,52 51,52,53 51,52 51,52	C D,E
040804	FLOW PROGRAMMING VALVE	INSPECT ADJUST	-- --		--	51,52,53	
040805	OIL TEMPERATURE TRANSMITTER	REPLACE INSPECT	-- --			51,52 51,52,53	

MAINTENANCE ALLOCATION CHART							
NOMENCLATURE OF END ITEMS							
T55-L-714							
(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
040806	OIL FILLER ASSEMBLY AND OIL FILLER STRAINER	REPLACE	--			51,52	C
		INSPECT	--			51,52,53	
040807	OIL FILLER COVER ASSEMBLY AND OIL FILLER ELEMENT	SERVICE	--			51,52	
		REPLACE	--			51,52	
		INSPECT	--			51,52,53	
040808	DUAL CHIP DETECTOR	SERVICE	--			51,52	C
		REPLACE	--			51,52	C
		INSPECT	--			51,52,53	
040809	OIL LINES	SERVICE	--			51,52	C
		REPLACE	--			51,52	C
040810	STARTER GEARBOX FILTER	INSPECT	--			51,52,53	
		REPLACE	--			51,52	C
040811	NO. 2 BEARING PRESSURE OIL CONNECTOR	INSPECT	--			51,52,53	
		SERVICE	--			51,52	C
		REPLACE	--			51,52	C
040812	NO. 2 BEARING PRESSURE OIL STRAINER	INSPECT	--			51,52,53	
		REPLACE	--			51,52	
040813	NO. 4 AND 5 BEARING FILTER	SERVICE	--			51,52	
		REPLACE	--			51,52	
		INSPECT	--			51,52,53,56	
040814	OIL DRAIN COCK	SERVICE	--			51,52,56	C
		REPLACE	--			51,52,56	C
		INSPECT	--			51,52,53	

MAINTENANCE ALLOCATION CHART							
NOMENCLATURE OF END ITEMS							
T55-L-714							
(1) GROUP NUMBER	(2) COMPONENT/ASSEMBLY	(3) MAINTENANCE FUNCTION	(4) MAINTENANCE CATEGORY			(5) TOOLS AND EQUIPMENT	(6) REMARKS
			AVUM	AVIM	DEPOT		
040815	CHIP DETECTOR	REPLACE	--			51,52	
		INSPECT	--			51,52,53	
		SERVICE	--			51,52	C
040816	OIL LEVEL INDICATOR	REPLACE	--			51,52	C
		INSPECT	--			33,51,52, 53	
		ADJUST	--			33,51,52	
		SERVICE	--			33,51,52	C
040817	OIL LEVEL FLOAT	REPLACE	--			33,51,52	C
		INSPECT		--		45,51,52, 53	
		REPLACE		--		45,51,52	
0409	DRIVE SYSTEM	REPAIR		--		44,45,46	
040901	TORQUEMETER SENSOR	INSPECT	--			45,51,52, 53	
		REPLACE	--			45,51,52	L

SECTION III

TOOL AND TEST EQUIPMENT REQUIREMENTS

NOMENCLATURE OF END ITEMS

Tool and Test Equipment Requirements. T55-L-714 Turbine Engine

TOOL OR TEST EQUIPMENT REF CODE	MAINTENANCE CATEGORY	NOMENCLATURE	NATIONAL/NATO STOCK NUMBER	TOOL NUMBER
1	AVIM	Alignment Pin	5120-00-898-0974	LTCT13038
2	AVIM	Alignment Pin	5120-00-898-0697	LTCT387-01
3	AVIM	Bar, Locating	5120-00-671-2129	LTCT153
4	AVIM	Clinching Tool	5120-00-481-3117	LTCT13411-01
5	AVIM	Control Unit	6110-00-631-7196	LTCT14547-01
6	AVIM	Coupling Half, Clamp	5340-00-156-1191	LTCT9917
7	AVIM	Cover, Aircraft Group	1730-00-134-0979	LTCT6271
8	AVIM	Cover, Aircraft Group	1730-00-133-9550	LTCT3936
9	AVUM	Cover, Protective Engine	4920-00-916-2448	LTCT1278
10	AVUM	Drift Assembly	4920-00-891-4653	LTCT1643
11	AVIM	EHRT Computer		LTCT29014-01
12	AVIM	Fixture, Assembling (Bore Heater)	4920-00-134-0162	LTCT6354
13	AVIM	Fixture, Holding Gear	4920-00-012-9091	LTCT1184
14	AVUM	Fixture, Holding Gear	4920-00-872-7858	LTCT1260
15	AVIM	Fixture, Holding Tube	4920-01-137-3557	LTCT7202-01
16	AVIM	Fixture, Holding	4920-01-115-6995	LTCT14616-01
17	AVIM	Fixture, Pressure Check	4920-00-866-0849	LTCT13442
18	AVIM	Fixture, Power Turbine	4920-00-834-2182	LTCT14360-01
19	AVIM	Fixture, Torque	4920-00-834-2178	LTCT13771
20	AVIM	Fixture, Torque	4920-00-372-4596	LTCT13857-01
21	AVIM	Fixture, Torque	4920-00-866-0863	LTCT13344
22	AVIM	Gage, Backlash	5220-00-015-6982	LTCT1229
23	AVUM	Handling Tool	5120-00-959-7636	LTCT1431-01

TOOL AND TEST EQUIPMENT REQUIREMENTS				
NOMENCLATURE OF END ITEMS				
Tool and Test Equipment Requirements. T55-L-714 Turbine Engine				
TOOL OR TEST EQUIPMENT REF CODE	MAINTENANCE CATEGORY	NOMENCLATURE	NATIONAL/NATO STOCK NUMBER	TOOL NUMBER
24	AVUM	Handling Tool	5120-00-959-7633	LTCT1428-01
25	AVIM	Heater, Induction	4920-00-372-4595	LTCT13873-01
26	AVUM	Installation Tool	4920-00-475-2552	LTCT1228
27	AVUM	Installation Tool	4920-00-509-8087	LTCT1230
28	AVIM	Installing Tool, Bearing	5120-00-370-3939	LTCT13874-01
29	AVIM	Kit, Application (RTV)		LTCT11527-01
30	AVUM	Kit, Blade Installation	5180-00-125-4106	LTCT7660-01
31	AVIM	Kit, Maintenance (Skimming)	4920-00-134-0163	LTCT6629-03
32	AVUM	Kit, Masking (RTV)		LTCT7612-01
33	AVUM	Light, Test, Oil Level	4920-00-940-2910	LTCT1259
34	AVIM	Multiplier Torque	5120-00-382-2543	PD2501-SD
35	AVIM	Plate, Wrenching Pin	4920-00-509-8060	LTCT1252
36	AVIM	Puller, Mechanical	5120-00-012-8865	LTCT1009-01
37	AVUM	Puller, Mechanical	5120-00-509-2965	LTCT1218
38	AVIM	Puller, Mechanical	5120-00-110-4235	LTCT1379-01.
39	AVIM	Puller, Mechanical	5120-00-370-3934	LTCT1 3877-01
40	AVIM	Puller, Mechanical	5120-00-109-4674	LTCT6173
41	AVIM	Puller, GP Spacer		LTCT7923-01
42	AVIM	Puller, Wheel, Hydraulic	5130-01-115-6996	LTCT14672-01
43	AVUM	Punch, Drive Pin	5120-00-951-8622	LTCT1960
44	AVIM	Shop Set, Machine	4920-00-405-9279	SC492099CLA91- MMAM
45	AVIM	Shop Set, Turbine Engine	4920-00-224-3684	SC492099CLA91- ENTAM
46	AVIM	Shop Set, Welding	4920-00-163-5093	SC492099CLH91- WEAM
47	AVUM	Sling, Aircraft Maintenance	1730-01-007-6990	LTCT14700-40

TOOL AND TEST EQUIPMENT REQUIREMENTS				
NOMENCLATURE OF END ITEMS				
Tool and Test Equipment Requirements. T55-L-714 Turbine Engine				
TOOL OR TEST EQUIPMENT REF CODE	MAINTENANCE CATEGORY	NOMENCLATURE	NATIONAL/NATO STOCK NUMBER	TOOL NUMBER
48	AVIM	Support, Dial Indicator	4920-00-110-9986	LTCT6098
49	AVIM	Tester, Seal Leakage	4920-00-444-2362	LTCT13606-01
50	AVUM	Tool, Installing	4920-00-898-7925	LTCT1644
51	AVUM	Tool Kit, AVUM #2	4920-00-567-0476	SC492099LA92
52	AVUM	Tool Kit, Engine RMS	5180-00-323-4944	SC518099CLA07
53	AVUM	Tool Kit, Technical Inspect	5180-00-323-5114	
54	AVUM	Tool Set, Seal Removal	4920-00-866-0858	LTCT13868
55	AVIM	Torque Adapter, Wrench	5120-00-792-8191	LTCT1409
56	AVUM	Wrench, Open End	5120-00-834-2141	LTCT13911-01

SECTION IV

REMARKS

REFERENCE CODE	REMARKS/NOTES
A	Functional Test at AVUM - Engine in Airframe
B	Functional Test at AVIM - Engine in METS/FEDS
C	Repairs at AVUM includes minor repair of the engine and minor repair/replacement of components and accessories
D	Blend Repair
E	Corrosion Control, Pitting
F	Magnetic-Particle Inspection
G	Nicks, Dents, Burrs, Cracks & Distortion
H	Adjust, Engine in Airframe
I	Bleed Band, Ground Idle, Maximum Power, Engine in Airframe
J	O-Rings, Drive Shaft Seal, Solenoid Valve
K	Seals and O-Rings
L	Torque Sensor, Output Shaft, and Signal Conditioner Unit are individually replaceable, but the Output Shaft calibration must be set into the Signal Conditioner Unit (Refer to TM 1-1520-252-23).
M	Repair is limited to Blend Repair and Seal/O-Ring Replacement

**APPENDIX C
EXPENDABLE SUPPLIES AND MATERIAL LIST**

SECTION I. INTRODUCTION

C-1 SCOPE

This appendix lists expendable supplies and materials you will need to operate and maintain the engine. These items are authorized to you by CTA 50-970, Expendable Items (Except Medical, Class V, Repair Parts, and Heraldic Items).

C-2 EXPLANATION OF COLUMNS

- a. Column 1 - Item number. This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the material, e.g., "Use dry cleaning solvent (E19)."
- b. Column 2 - National Stock Number. This is the National Stock Number assigned to the item; use it to request or requisition the item.
- c. Column 3 - Description. Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the part number followed by the Commercial and Government Entity Code (CAGEC) in parenthesis, if applicable.

SECTION II.
EXPENDABLE SUPPLIES AND MATERIAL LIST

(1) ITEM NUMBER	(2) NATIONAL STOCK NUMBER	(3) DESCRIPTION
E1	6810-00-184-4796	Acetone, Technical (O-A-51)
E2	7920-00-514-2417	Acid Swabbing Brush
E3	5350-00-224-7201	Aluminum Oxide Abrasive Paper (180 to 320 Grit)
E4	5350-00-161-9715	Aluminum Oxide Cloth Carborundum Co. Niagara Falls, NY
E5		Anti-Detonating Injection Fluid Mix- ture Lyndhurst Chemical Corp. (or equivalent)
E6	8030-00-105-0270	Anti-Seize Compound Nickel Ease, Nickel Special Fel-Pro Inc. Division of Felt Product Manufacturing Co. Skokie, IL
E7	8335-00-224-8885	Barrier Material MIL-B-121, Grade A
E8	8135-00-282-0565	Barrier Material MIL-B-130
E9	8030-00-664-6146	Black Baking Enamel (AMS3120)
E10	5340-00-292-0886	Bonding Seal
E11		Carborundum Stone Carborundum Co. Niagara Falls, NY
E12	6850-00-181-7594	Cleaning Solution B&B 3100 B&B Chemical Co. Miami, FL
E13		Clear Synthetic Sealant Reliance 456 Reliance Varnish Co. Irvington, NJ
E14	8030-00-231-2354	Corrosion Preventive Compound MIL-C-11796, Class 3

EXPENDABLE SUPPLIES AND MATERIALS LIST (Continued)

(1) Item Number	(2) National Stock Number	(3) Description
E15	8030-00-838-7789	Corrosion Preventative Compound, WD40 WD40 Co. San Diego, CA OR LPS Research Laboratories Inc. Los Angeles, CA
E16	5350-00-221-0872	Crocus Cloth (P-C-458)
E17	6810-00-281-2785	Denatured Alcohol, (Ethanol) (O-E-760) MIL-STD-1201
E18	6850-00-264-6562	Desiccant Bag MIL-D-3464, Type III W.R. Grace & Co. Davison Chemical Div. Baltimore, MD 21203
E19	6850-00-285-8011	Dry Cleaning Solvent (P-D-680) Type II
E20		Emery Cloth (No. 500) Carborundum Co. Niagara Falls, NY
E21	DELETED	Refer to Item # E73
E22	3030-00-213-3079	Gear Marking Compound, Non-Lead Compound G2 Stutz Co. Chicago, IL OR No. 89 Organic Products Co. P.O. Box 428 1963 E. Irving Blvd., Irving TX 75060

EXPENDABLE SUPPLIES AND MATERIALS LIST (Continued)

(1) ITEM NUMBER	(2) NATIONAL STOCK NUMBER	(3) DESCRIPTION
E23	8415-00-227-1220	Gloves, Small MIL-G-10902
	8415-00-227-1221	Gloves, Medium MIL-G-10902
	8415-00-227-1222	Gloves, Large MIL-G-10902
E 24	8415-00-266-8677	Gloves ZZ-G-381
E25	6810-00-264-6548	Glycerol (O-G-491)
E26	8010-00-584-3078	Gray Enmel (TT-E-489)
E27	9150-00-269-8255	Grease, MIL-G-4343 Dow Corning Corp. Midland, MI
E28	5970-00-929-8595	Insulation Sleeving for <u>No. 18</u> wire MIL-I-23053/12 Flexite HT105C
E29	8010-00-007-8164	Iron Blue Pigment (TT-P-385)
E30	7920-00-205-3453	Lint-Free Cloth (CCC-C-46A)
E31	8520-00-141-2519	Liquid Soap (P-S-624)
E32	9505-00-221-2650	Lockwire, MS20995C20
E33	9505-00-847-1663	Lockwire, MS20995C32
E34	9150-00-141-4481	Lubricant Plastilube Moly No. 3 Waren Refining and Chemical Co., Cleveland, OH
E35	9150-00-273-2388	Lubricating Oil MIL-L-6081, Grade 1010
E36	9150-00-782-2627	Lubricating Oil MIL-L-7808
E37	9150-00-180-6266	Lubrication Oil MIL-L-23699
E38	7510-00-465-0994	Marking Pencil, Yellow Colorbrite No. 2127, 4127, or 2101 Eberhard Faber Inc. Crestwood Industrial Park, Wilkes-Barre, PA 18707
E39	7510-00-266-6712	Masking Tape (UU-T-106)

EXPENDABLE SUPPLIES AND MATERIAL LIST (Continued)

(1) ITEM NUMBER	(2) NATIONAL STOCK NUMBER	(3) DESCRIPTION
E23	8415-00-227-1220 8415-00-227-1221 8415-00-227-1222	Gloves, Small MIL-G-10902 Gloves, Medium MIL-G-10902 Gloves, Large MIL-G-10902
E24	8415-00-266-8677	Gloves ZZ-G-381
E25	6810-00-264-6548	Glycerol (O-G-491)
E26	8010-00-584-3078	Gray Enamel (TT-E-489)
E27	9150-00-269-8255	Grease, MIL-G-4343 Dow Corning Corp. Midland, MI
E28	5970-00-929-8595	Insulation Sleeving for No. 18 Wire- MIL-1-23053/12 Flexite HT1 05C
E29	8010-00-007-8164	Iron Blue Pigment (TT-P-385)
E30	7920-00-205-3453	Lint-Free Cloth (CCC-C-46A)
E31	8520-00-141-2519	Liquid Soap (P-S-624)
E32	9505-00-221-2650	Lockwire, MS20995C20
E33	9505-00-847-1663	Lockwire, MS20995C32
E34	9150-00-141-4481	Lubricant, Plastilube Moly No. 3 Warren Refining and Chemical Co., Cleveland, OH
E35	9150-00-273-2388	Lubricating Oil MIL-L-6081, Grade 1010
E36	9150-00-782-2627	Lubricating Oil MIL-L-7808
E37	9150-00-180-6266	Lubricating Oil MIL-L-23699
E38	7510-00-465-0994	Marking Pencil, Yellow Colorbrite No. 2127,4127, or 2101 Eberhard Faber Inc. Crestwood Industrial Park, Wilkes-Barre, PA 18707
E39	7510-00-266-6712	Masking Tape (U U-T-1 06)

EXPENDABLE SUPPLIES AND MATERIAL LIST (Continued)

(1) ITEM NUMBER	(2) NATIONAL STOCK NUMBER	(3) DESCRIPTION
E40 E41	6810-00-275-6010 8030-01-064-4951	Methanol (O-M-232) Mold Release Compound Freekote No.1, P/N RAMN0225 Hysol Div., Subsidiary of The Dexter Corporation 170 Spanish River Blvd. West Boca Raton, FL 33431 OR Dexter Adhesives and Structural Materials Division One Dexter Dr., Seabrook, NH 03874 CAGE#22401
E42 E43 E44 E45 E46	6810-00-237-2918 9150-00-261-7899 9150-00-250-0926 1730-00-181-4202 5970-00-833-1702	Nitric Acid (O-N-350) Penetrating Oil (VV-P-216) Petrolatum (VV-P-236) Plastic Cover (PSK 3355) Pressure Sensitive Teflon Tape, <u>3/8-inch</u> wide by <u>0.006 inch</u> thick with temperature range of <u>-65 to</u> <u>350°F</u> Connecticut Hard Rubber Co. New Haven, Connecticut 06509
E47	8040-00-902-3871	RTV Silicone Rubber Adhesive Sealant RTV106 General Electric Co., Silicone Products Div., Waterford, NY 12188
E48	8030-00-744-1293	Rust Inhibitor and Preservative MIL-C-23411
E49		Safety Cable AS3510-0206L
E50 E51	5350-00-214-7203 8945-01-066-8210	Sandpaper (P-P-101) Shortening Compound (A-A-20100)


EXPENDABLE SUPPLIES AND MATERIAL LIST (Continued)

(1) ITEM NUMBER	(2) NATIONAL STOCK NUMBER	(3) DESCRIPTION
E52		Sisal Twine 2 ply hard fiber, light manila color, 265 pound tensile strength (minimum)
E53	6810-00-143-2000	Sodium Dichromate (O-S-595)
E54	3439-00-224-3567	Solder, 60/40 Tin Lead (QQ-S-571 D)
E55	2835-01-120-2884	Spiral Chafing Sleeve 94835-1 Titeflex Co. Inc. Springfield, MA
E56	9330-00-688-7856	Spiral Chafing Sleeve 94835-2 Titeflex Co. Inc. Springfield, MA
E57	9330-00-688-7857	Spiral Chafing Sleeve 94835-3 Titeflex Co. Inc. Springfield, MA
E58	8135-00-066-0043	Tag (UU-T-81)
E59	7510-00-079-7906	Tape (PPP-T-60) Type IV
E60	4470-01-011-3748	Tape, Acetate Fiber, 3 inch (PPP-T-60B, Class 2, Scratch 27), Minnesota Mining & Manufacturing, St. Paul MN
E61	6505-01-050-8714	Tar Ashland Petroleum Co. Division of Ashland Oil Inc. Ashland, KY 41101
E62		Vexar Nylon Webbing E.I. Dupont de Nemours Wilmington, DE
E63	8010-00-515-1596	White Enamel (TT-E-489)
E64	7920-00-205-1711	Wiping Rag 50 Pound Bale (A-A-531)

EXPENDABLE SUPPLIES AND MATERIALS LIST (Continued)

(1) Item Number	(2) National Stock Number	(3) Description
E65		Wire, <u>22 Gauge</u> Standard No. 8522-1 Type 4 (71002) Birnbach Co. Inc. Freeport, NY 11520
E66	3439-00-166-9584	Wire, Welding AMS5786
E67	3439-00-882-7350	Wire Welding AMS5794
E68	8010-00-155-2208	Zinc Chromate Primer MIL-P-8585, or MIL-P-6899 Type II
E69	6850-01-372-6303	MIL-C-85704 Type II, 5 Gal
E70	6850-01-372-8304	MIL-C-85704 Type II, 55 Gal
E71	6850-01-370-5245	MIL-C-85704 Type IIA, 5 Gal
E72	6850-01-370-5244	MIL-C-85704 Type IIA, 55 Gal
E73		Penetrant Inspection Material AMS2644 Level 3 or Higher
E74	6850-01-450-6162	N-Propyl Bromide Type IIA, 55 Gal
E75	7930-01-367-0995	DS-108
E76	6850-01-375-5553	Electron Dielectric Solvent
E77	6850-01-412-0026	Positron Dielectric Solvent
E78	6810-00-855-6160	Isopropyl Alcohol TT-I-735


APPENDIX D
WIRING DIAGRAM



B-D 1

Electrical System Schematic


WIRING DIAGRAM



B-D/2

Electrical System Schematic

WIRING DIAGRAM



B-D/3

Electrical System Schematic

APPENDIX E
ILLUSTRATED LIST OF MANUFACTURED ITEMS

APPENDIX E

TABLE OF CONTENTS

Nomenclature	Reference Task No.	Page No.
Bent Wire Gage (0.053 inch) (AVIM)	4-62	E-1
Bent Wire Gage (0.100 inch) (AVIM)	4-67	E-2
Bent Wire Gage (0.104 inch) (AVIM)	4-36	E-3
Bent Wire Gage (0.115 inch) (AVIM)	4-36	E-4
Bent Wire Gage (0.225 inch) (AVIM)	4-57	E-5
Bent Wire Gage (0.228 inch) (AVIM)	4-36	E-6
Bent Wire Gage (0.290 inch) (AVIM)	4-36	E-7
Chain With Hooks	1-26,1-103, 1-104	E-8
Drain Hose	1-28,1-102	E-9
Drain Hose	1-102	E-10
Hose Assembly	1-102	E-11
Hose Assembly	6-6	E-12
Hose Assembly	6-6	E-13
Oil Seal Installation Tool	5-21	E-14
Oil Seal Removal Tool	5-21	E-15
Phenolic Drift (AVIM)	3-9	E-16
Pressure Gage Tube Assembly	1-101	E-17
Sleeve	2-42	E-18
Sleeve Bushing	5-21	E-19
Stirring Rod	1-110	E-20
Swirler Installation Tool (AVIM)	3-18	E-21
Thickness Gage (AVIM)	1-87, 4-58, 4-62	E-22
Third Turbine Rotor Support Block (AVIM)	4-37	E-23
Wood Block (AVIM)	3-15	E-24
Wrench	5-24	E-25

APPENDIX E

ILLUSTRATED LIST OF MANUFACTURED ITEMS

Nomenclature	Reference Task No.	Material Required
Bent Wire Gage (0.053 Inch) (AVIM)	4-62	AMS5645 QQ-S-763 (CRES321) or AMS5754 (Hastelloy X)


Fabrication Instructions:

Fabricate bent wire gage out of specified material as follows:

1. Form in accordance with sketch shown below.
2. Break all sharp edges.

NOTE: All dimensions are in inches.

Sketch or Diagram:



ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Bent Wire Gage (0.100 Inch) (AVIM)	4-67	AMS5645 QQ-S-763 (CRES321) or AMS5754 (Hastelloy X)


Fabrication Instructions:

Fabricate bent wire gage out of specified material as follows:

1. Form in accordance with sketch shown below.
2. Break all sharp edges.

NOTE: All dimensions are in inches.

Sketch or Diagram:



ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Bent Wire Gage (0.104 Inch) (AVIM)	4-36	AMS5645 QQ-S-763 (CRES321) or AMS5754 (Hastelloy X)


Fabrication Instructions:

Fabricate bent wire gage out of specified material as follows:

1. Form in accordance with sketch shown below.
2. Break all sharp edges.

NOTE: All dimensions are in inches.

Sketch or Diagram:



ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Bent Wire Gage (0.115 Inch) (AVIM)	4-36	AMS5645 QQ-S-763 (CRES321) or AMS5754 (Hastelloy X)


Fabrication Instructions:

Fabricate bent wire gage out of specified material as follows:

1. Form in accordance with sketch shown below.
2. Break all sharp edges.

NOTE: All dimensions are in inches.

Sketch or Diagram:



ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Bent Wire Gage (0.225 Inch) (AVIM)	4-57	AMS5645 QQ-S-763 (CRES321) or AMS5754 (Hastelloy X)


Fabrication Instructions:

Fabricate bent wire gage out of specified material as follows:

1. Form in accordance with sketch shown below.
2. Break all sharp edges.

NOTE: All dimensions are in inches.

Sketch or Diagram:



ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Bent Wire Gage (0.228 Inch) (AVIM)	4-36	AMS5645 QQ-S-763 (CRES321) or AMS5754 (Hastelloy X)


Fabrication Instructions:

Fabricate bent wire gage out of specified material as follows:

1. Form in accordance with sketch shown below.
2. Break all sharp edges.

NOTE: All dimensions are in inches.

Sketch or Diagram:



B-E 6

ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Bent Wire Gage (0.290 Inch) (AVIM)	4-36	AMS5645 QQ-S-763 (CRES321) or AMS5754 (Hastelloy X)


Fabrication Instructions:

Fabricate bent wire gage out of specified material as follows:

1. Form in accordance with sketch shown below.
2. Break all sharp edges.

NOTE: All dimensions are in inches.

Sketch or Diagram:



ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Chain with Hooks	1-26,1-103,1-104	(1) Slip hooks (2 ea.), (2) pins (2 ea.), (3) <u>3/8 inch</u> welded link steel alloy chain (2ea.),(4) couplings (2), (5) crosby 1/2 oblong link (1). (See sketch).


Fabrication Instructions:

NOTE: The chain and hooks must have a certified 1 ton load limit capacity. Therefore it is suggested that only certified vendors be used to procure this item. The specifications require a 1 ton steel heavy duty chain hoist.

Suggested certified vendors are: (1) Paul's Wire, Rope & Sling Inc., 4 Indian Neck Ave., Branford, CT 06405.
 (2) McMaster-Carr Supply, P.O. Box 4355, Chicago, Ill., 60680.

NOTE: All dimensions are in inches.

Sketch or Diagram:



B-E/8


ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Drain Hose	1-28,1-102	Scrap flexible hose with -6 fittings

Fabrication Instructions:

NOTE: Use suitable scrap hose (see sketch). If no such hose is available use any scrap hose providing priming task can be accomplished successfully.

Sketch or Diagram:



B-E/9


ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Drain Hose	1-102	Scrap flexible hose with -4 fittings

Fabrication Instructions:

NOTE: Use suitable scrap hose (see sketch). If no such hose is available, use any scrap hose providing draining task can be successfully accomplished.

Sketch or Diagram:



B-E/10

ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)


Nomenclature	Reference Task No.	Material Required
Hose Assembly	1-102	(8 Feet) No. 10 Hose, (1) MS9355-10 Packing (1) MS9355-12 Packing, (1) AN919-20D Reducer (1) 10Q10FJD Anchor Fitting

Fabrication Instructions:


Assemble hose assembly from material required and sketch shown below as follows:

1. Install 10Q1 OFJD Anchor fitting (2) on No. 10 hose (1).
2. Coat MS9355-10 Packing (3) and MS9355-12 Packing (4) with silicone grease MIL-G-4343.
3. Install Packing (3) and Packing (4) on AN919-20D Reducer (5).
4. Connect reducer (5) to anchor fitting (2).

Sketch or Diagram:



NOTE THE FOLLOWING ITEMS MAY BE USED IF THE ITEMS LISTED ABOVE ARE NOT AVAILABLE



8-E.12


ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Hose Assembly	6-6	Scrap flexible hose with -6 fittings

Fabrication Instructions:

NOTE: Use suitable scrap hose (see sketch). If no such hose is available use any scrap hose providing preservation task can be successfully accomplished.

Sketch or Diagram:




ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Hose Assembly	6-6	Scrap flexible hose with -10 fittings

Fabrication Instructions:

NOTE: Use suitable scrap hose (see sketch). If no such hose is available use any scrap hose providing preservation task can be successfully accomplished.

Sketch or Diagram:



B-E/14

ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Oil Seal Installation Tool	5-21	Aluminum QQ-A-200/8T6


Fabrication Instructions:

Fabricate oil seal installation tool out of aluminum stock as follows:

1. Machine in accordance with sketch shown below.
2. Surface treat with anodize MIL-A-8625 Type II.

NOTE: All dimensions are inches.

Sketch or Diagram:



ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Oil Seal Removal Tool	5-21	Aluminum QQ-A-225/8T6


Fabrication Instructions:

Fabricate oil seal removal tool out of aluminum stock as follows:

1. Machine in accordance with sketch shown below.
2. Surface treat with anodize per MIL-A-8625 Type I.

NOTE: All dimensions are in inches.

Sketch or Diagram:



B-E.20

ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Phenolic Drift (AVIM)	3-9	AMS3903 - Cloth Organic Fiber - Epoxy Resin Impregnated


Fabrication Instructions:

Fabricate phenolic drift out of specified material as follows:

1. Machine in accordance with sketch shown below.

NOTE: All dimensions are in inches.

Sketch or Diagram:



B-E 21

ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)


Nomenclature	Reference Task No.	Material Required
Pressure Gage Tube Assembly	1-101	(2) MS28741-4-120 Hose Assembly (2) MS28778 Packing (2) MS51503A4-4S Adapter

Fabrication Instructions:

Assemble two pressure gage tube assemblies from material required and sketch shown below as follows:

1. Coat MS28778 packing (2) with silicone grease MIL-G-4343.
2. Install packing (2) on MS51503A4-4S adapter (3).
3. Connect adapter (3) to MS28741-4-120 hose assembly (1).

Sketch or Diagram:



B-E/22

ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Sleeve	2-42	Aluminum QQ-A-200/8T6


Fabrication Instructions:

Fabricate sleeve bushing out of aluminum stock as follows:

1. Machine in accordance with sketch shown below.
2. Surface treat with anodize MIL-A-8625 Type II.

NOTE: All dimensions are in inches.

Sketch or Diagram:



B-E 24

ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Sleeve Bushing	5-21	Aluminum QQ-A-200/8T6


Fabrication Instructions:

Fabricate sleeve bushing out of aluminum stock as follows:

1. Machine in accordance with sketch shown below.
2. Surface treat with anodize per MIL-A-8625 Type II.

NOTE: All dimensions are in inches.

Sketch or Diagram:



B-E129

ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Stirring Rod	1-110	Hardwood Stock


Fabrication Instructions:

Fabricate stirring rod from hardwood stock as follows:

1. Machine wood in accordance with sketch shown below.
2. Remove all rough edges with fine grain sandpaper.

NOTE: All dimensions are in inches.

Sketch or Diagram:



B-E 30

ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Swirler Installation Too (AVIM)	3-18	Hardwood Stock


Fabrication Instructions:

Fabricate swirler installation tool out of hardwood stock as follows:

1. Saw wood in accordance with sketch shown below.
2. Remove all rough edges with fine grain sandpaper.

NOTE: All dimensions are in inches.

Sketch or Diagram:



B-E/31

ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Thickness Gage (AVIM)	1-87, 4-58, 4-62	AMS5519 (CRES301) Steel


Fabrication Instructions:

Fabricate feeler gage out of steel as follows:

1. Fabricate in accordance with sketch shown below.
2. Break all sharp edges.

NOTE: All dimensions are in inches.

Sketch or Diagram:



B-E/32

ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Third Turbine Rotor Support Block (AVIM)	4-37	Hardwood Stock


Fabrication Instructions:

Fabricate third turbine rotor support block out of hardwood stock as follows:

1. Saw wood in accordance with sketch shown below.
2. Remove all rough edges with fine grain sandpaper.

NOTE: Size of required block may vary with distance from floor to turbine shaft. All dimensions are in inches.

Sketch or Diagram:



B-E 33

ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Wood Block (AVIM)	3-15	Hardwood Stock


Fabrication Instructions:

Fabricate wood block out of hardwood stock as follows:

1. Saw wood in accordance with sketch shown below.
2. Remove all rough edges with fine grain sandpaper.

NOTE: All dimensions are in inches.

Sketch or Diagram:



ILLUSTRATED LIST OF MANUFACTURED ITEMS (Continued)

Nomenclature	Reference Task No.	Material Required
Wrench	5-24	Crowfoot Wrench NSN 5120-00-541-4071


Fabrication Instructions:

Fabricate crowfoot wrench out of specified material as follows:

1. Machine in accordance with sketch shown below.
2. Break all sharp edges.

NOTE: All dimensions are in inches.

Sketch or Diagram:



APPENDIX F

ABBREVIATIONS

NOTE

See Appendix G, Paragraph G-12, for additional abbreviations pertinent to FADEC.

A	
A/F	Airframe
ALT	Alternator
AVIM.....	Aviation Intermediate Maintenance
AVUM.....	Aviation Unit Maintenance
B	
BITE	Built-in Test Equipment
C	
°C	Degrees Celsius
C/P	Cockpit
CC	Cubic Centimeters
D	
DECU	Digital Electronic Control Unit
DMWR	Depot Maintenance Work Requirement
DSRB	Data Set Ready-Channel B
DX	Direct Exchange
E	
ECL.....	Engine Control Lever
EHRT	Engine History Recording Terminal
EIR	Equipment Improvement Recommendations
EM	Emergency
EOI	Engine Out Indicator
F	
°F	Degrees Fahrenheit
FADEC	Full Authority Digital Electronic Control
FEDS	Flexible Engine Diagnostic System
FI	Flight Idle
FOD	Foreign Object Damage
FSCM	Federal Supply Code for Manufacturers
FWD	Forward
G	
GI	Ground Idle
GNDB	Ground-Channel B
GP	Gas Producer
GSE	Ground Support Equipment
GT	Gas Turbine

APPENDIX F

ABBREVIATIONS (Continued)

H	
Hg.....	Mercury
HMA	Hydromechanical Assembly
HMU	Hydromechanical Unit
Hz	Hertz
L	
LCCS.....	Life Cycle Contractor Support
L/H.....	Left Hand
M	
MAC.....	Maintenance Allocation Chart
Max	Maximum
METS.....	Modular Engine Test Systems
MFD.....	Multi-Function Display
MFP	Main Fuel Pump
Min.....	Minimum
MOS	Military Occupation Specialty
MTOE	Modified Table of Organization and Equipment
N	
N ₁	Compressor Rotor RPM
N ₂	Power Turbine RPM
NATO.....	North Atlantic Treaty Organization
No	Number
NSN	National Stock Number
P	
P ₃	Air Pressure (Air Diffuser)
PAS	Power Assurance Switch
PHR.....	Pounds per Hour
P _m	Air Pressure (Modulated)
PMG	Permanent Magnet Output Generator
PSI.....	Pounds per Square Inch
PSIG.....	Pounds per Square Inch Gage
PT.....	Power Turbine
PTIT.....	Power Turbine Inlet Temperature
Q	
QA	Quality Assurance
QC	Quality Control

APPENDIX F
ABBREVIATIONS (Continued)

R	
R/H	Right Hand
RETB	Return-Channel B
REV	Reversionary
RPM	Revolutions per Minute
RPSTL	Repair Parts and Special Tool List
RTSB	Request to Send-Channel B
RTU	Remote Terminal Unit
RTV	Room Temperature Vulcanizing
RXTB	Receive Data-Channel B
S	
SCU	Signal Conditioning Unit
SHP	Shaft Horsepower
SMR	Source, Maintenance and Recoverability
STF	Start Fuel
T	
T ₁	Inlet Air Temperature
TBO	Time Between Overhaul
TM	Technical Manual
TMDE	Test Measurement and Diagnostic Equipment
TQ	Torque
TXDB	Transmit Data-Channel B
U	
UUT	Unit Under Test
V	
Vac	Volts Alternating Current
Vdc	Volts Direct Current
W	
WF or W _f	Fuel Flow

APPENDIX G

FAULT ISOLATION MANUAL

APPENDIX G

TABLE OF CONTENTS

Subject	Page
Introduction	G-1
G-1 General	G-1
G-2 Description	G-1
G-3 Test Equipment	G-2
G-4 Resistance and Insulation Tests	G-2
G-5 High Fuel Consumption	G-2
G-6 Fault Isolation	G-3
G-7 Display of Fault Codes	G-4
G-8 Power Supply Interrupt	G-7
G-9 Operational Problems Without Codes	G-8
G-10 Using the Fault Isolation Diagrams	G-8
G-11 Diagrams	G-9
G-12 Abbreviations	G-10
G-13 Fault Trees	G-11
G-14 Diagrams	G-11
G-15 Fault Code F1, N1A Sensor Expanded Instructions	G-14
G-16 Fault Code F2, N1B Sensor Expanded Instructions	G-17
G-17 Fault Code F3, N1A/N1B Difference Expanded Instructions	G-20
G-18 Fault Code F4, MV Potentiometer Expanded Instructions	G-23
G-19 Fault Code F5 Wf/Stepcount Difference Expanded Instructions	G-27
G-20 Fault Code F6, PLA Potentiometer Expanded Instructions	G-30
G-21 Fault Code F7, Bleed Valve Solenoid Expanded Instructions	G-34
G-22 Fault Code F8, Primary/Reversionary Solenoid Expanded Instruction	G-37
G-23 Fault Code F9, Alternator Expanded Instructions	G-40
G-24 Fault Code FA, Start Fuel Solenoid Expanded Instructions	G-43

TABLE OF CONTENTS (CONTINUED)

Subject	Page	
G-25	Fault Code FB, Reversionary Step Count Expanded Instructions	G-46
G-26	Fault Code A1, Q Sensor Expanded Instructions	G-49
G-27	Fault Code A2, N2 Set Potentiometer Expanded Instructions	G-52
G-28	Fault Code A3, Collective Pitch Angle LVDT Expanded Instructions	G-56
G-29	Fault Code A4, NR Sensor Expanded Instructions	G-59
G-30	Fault Code A5, ECL Resolver Expanded Instructions	G-62
G-31	Fault Code A6, Airframe Emergency 28V DC Expanded Instructions	G-65
G-32	Fault Code A7 (Or No Display), Airframe +28V DC Supply Expanded Instructions	G-67
G-33	Fault Codes D0, D3, D6, DA, DB, DD Internal DECU Faults Expanded Instructions	G-69
G-34	Fault Codes D4, D5, D7, D8, D9, DC, DF Internal DECU Faults Expanded Instructions	G-69
G-35	Fault Code D1, P3 Transducer Expanded Instructions	G-71
G-36	Fault Code D2, P1 Transducer Expanded Instructions	G-72
G-37	Fault Code De, <u>400 Hz</u> Resolver Reference Expanded Instructions	G-75
G-38	Fault Code EI, T4.5 Sensor Expanded Instructions	G-79
G-39	Fault Code E2, T1 Sensor Expanded Instructions	G-83
G-40	Fault Code E3, N2A Sensor Expanded Instructions	G-87
G-41	Fault Code E4, N2B Sensor Expanded Instructions	G-90
G-42	Fault Code E5, N2A/N2B Sensor Expanded Instructions	G-93
G-43	Fault Codes C1-C3, C5-C8, Communication Line Faults Expanded Instructions	G-95
G-44	Fault Codes C4, Communication Line Fault Q (0) Signal Expanded Instructions	G-97
G-45	Fault Code C9, N1 B (0) Sensor Signals From Other DECU Expanded Instructions	G-99
G-46	Fault Code CF, Loss Of Load Share Signals Expanded Instructions	G-101
G-47	Fault Code B2, N1 B Sensor Expanded Instructions	G-104
G-48	Fault Code B3, N2B Sensor Expanded Instructions	G-107
G-49	Fault Code B4, T4.5 Sensor Expanded Instructions	G-110
G-50	Fault Code B5, Collective Pitch Angle LVDT Expanded Instructions	G-113
G-51	Fault Code B6, ECL Resolver Expanded Instructions	G-116

TABLE OF CONTENTS (CONTINUED)

Subject	Page	
G-52	Fault Code B7, PLA Potentiometer Expanded Instructions	G-120
G-53	Fault Codes B9, BA, BB, Internal DECU Faults Expanded Instructions	G-121
G-54	Fault Code BC, <u>400 Hz</u> Resolver Reference Expanded Instructions	G-122
G-55	Fault Codes 10-1 F, Internal DECU Faults Expanded Instructions	G-123
G-56	Unable To Switch To Reversionary Mode Expanded Instructions	G-126
G-57	Unable To Switch To Primary Mode Expanded Instructions	G-129
G-58	System Toggles Between Primary And Reversionary Mode Expanded Instructions	G-132
G-59	Q Load Share Selected, Os Not Matched Expanded Instructions	G-135
G-60	T4.5 Load Share Selected, T4.5s Not Matched Expanded Instructions	G-139
G-61	Ignition Relay Does Not Function Expanded Instructions	G-142
G-62	Bleed Band Does Not Function Properly Expanded Instructions	G-144
G-63	Engine Out Indicator (EOI) Does Not Illuminate During Normal Shutdown Expanded Instructions	G-146
G-64	No Observed Engine Speed Reduction During Overspeed Test Expanded Instructions	G-149
G-65	No Beeper Switch Response In Reversion Expanded Instructions	G-152
G-66	Unable To Perform Power Assurance Test (Results Not Indicated On Hex Display) Expanded Instructions	G-154
G-67	Moving ECL To Stop Causes Increase In Engine Power Expanded Instructions	G-157
G-68	Moving ECL To Flight Causes Decrease In Engine Power Expanded Instructions	G-161
G-69	Engine Out Indicator (EOI) Is Always Illuminated Expanded Instructions	G-164
G-70	F/R Lamp Does Not Illuminate When Reversion Is Selected Expanded Instructions	G-166
G-71	F/R Lamp Is Illuminated When Primary Is Selected Expanded Instructions	G-168
G-72	Fault Codes Not Defined In Table 1 Expanded Instructions	G-170
G-73	Insulation/Voltage Check Expanded Instructions	G-172

DECU TROUBLESHOOTING

SECTION I. INTRODUCTION

G-1 GENERAL

- a. This Appendix provides fault isolation instructions for the Model EMC-32T Full Authority Digital Electronic Control (FADEC) supplied by Chandler Evans, Control Systems Division, Coltec Industries, Inc., Charter Oak Blvd., Box 330651, West Hartford, CT 06133-0651.
- b. In subsequent revisions to this manual, changes or additions to the text, tables or illustrations will be indicated by a vertical line in the left margin of affected material.

G-2 DESCRIPTION

- a. The EMC-32T Full Authority Digital Electronic Control (FADEC) includes all control functions required for proper and complete control of the Textron Lycoming T55 turboshaft engine. The EMC-32T version operates the T55-L-714 engine on the MH47E helicopter.
- b. Fuel Control System. The control system consists of a digital electronic control unit (DECU) and a hydromechanical assembly (HMA) manufactured by Chandler Evans, and Lycoming-supplied sensors and electrical harnesses. The system requires signal inputs from airframe components and utilizes airframe harnesses for inter-connection between HMA, DECU, engine, and airframe components (see figure 201). The system provides two operating modes: primary and reversionary. The primary mode is the normal mode of operation. In the event of a primary failure, the system automatically switches to the reversionary backup mode. Reversionary mode can also be selected by the pilot.
- c. Hydromechanical Assembly (HMA). The HMA consists of two units: The hydromechanical metering unit (HMU) and the fuel pumping unit (FPU). The HMU includes all fuel metering components to support both primary and reversionary fuel metering, a self-contained alternator for powering the electronics, both primary and reversionary compressor bleed air control, and redundant core speed sensing. The FPU includes a jet-induced boost into a main stage gear section. When operating in primary mode, the HMU receives actuation signals from the DECU that operate the primary stepper motor. The stepper motor controls the position of the fuel metering valve. A potentiometer connected to the rotary portion of the metering valve provides closed-loop feedback to the DECU. When operating in reversionary mode, the primary stepper motor is de-energized, and fuel flow is determined by the hydromechanical Wf/P3 reversionary control. The scheduled Wf/P3 is multiplied by P3 to give altitude-sensitive control of metered fuel flow. A mechanical P3 transducer, mechanical Wf/P3 times P3 multiplier, Wf/P3 servomechanism and reversionary stepper motor comprise this function. The output of the mechanical multiplier drives the fuel metering valve to the required flow.
- d. Digital Electronic Control Unit (DECU). The DECU includes a microcomputer-based primary control section and an independent reversionary section, controlled through an independent microcomputer for backup. In primary mode, the DECU provides engine load matching through either shaft torque or engine temperature as selected by the pilot. The DECU sends signals to the HMU to control fuel flow based on the required engine load match. The DECU's primary section also provides automatic start logic, surge detection and recovery, torque sharing and management, control of the bleed valve actuator, and self-diagnostic capabilities. In the event of a serious failure within the primary section, the system automatically switches to the redundant electronic reversionary control. Engine load anticipation is provided using rotor thrust lever position, with trimming provided by beep up and beep down switches. The DECU's reversionary section operates with the hydromechanical Wf/P3 manual system by controlling the reversionary stepper motor and changeover solenoid.

G-3 TEST EQUIPMENT

- a. Some fault isolation procedures require the use of a volt-ohmmeter to indicate resistance across the wire harnesses or across component connector pins. To avoid unstringing harnesses, use test cables with size 20 pins to mate with the harness plugs and sockets.
- b. The voltmeter used for measuring voltages shall have an accuracy of 0.1 percent full scale or better on the 200V range.
- c. The ohmmeter used for measuring all resistances except ground strap resistance shall have an accuracy of 0.05 percent full scale or better on the 2000 range and 0.5 percent full scale or better on all other ranges. The ohmmeter used for measuring ground strap resistance during the insulation/voltage check shall be capable of measuring 50m Ω with an accuracy of $\pm 5m\Omega$, using a four wire configuration. The meter should always be set to the lowest possible range for the specified limits. If the autoscale function is used, an automatic switch from one range to another can appear to be a discontinuity in the component being measured. If this occurs, turn off the autoscale function and manually set the meter to the appropriate range.

CAUTION

DO NOT USE A METER THAT WILL SUPPLY MORE THAN 5mA WHEN MEASURING PLA OR METERING VALVE POTENTIOMETER RESISTANCES (FAULT CODES B7, F4 AND F6) AS THIS CAN DAMAGE THE POTENTIOMETER.

G-4 RESISTANCE AND INSULATION TESTS

- a. Components which fail the resistance and insulation test specified herein are suspected to be faulty. Consult the manufacturer's procedure for diagnosis and troubleshooting of these components before replacing. Note that conductive solvents may cause temporary resistance and insulation shorts or failure. If wetting is a possible cause of the problem, allow the affected component to dry out, then recheck the resistance.

G-5 HIGH FUEL CONSUMPTION

- a. The engine HMA cannot cause high fuel consumption. Fuel consumption depends upon turbine engine condition, fuel characteristics or operating conditions. No troubleshooting of the HMA system is required.

G-6 FAULT ISOLATION

- a. Effective fault isolation is the determination of the actual problem by an intelligent analysis of the symptoms of the fault, followed by a systematic series of checks to isolate the fault and to correct the cause. Fault isolation is not complete until the symptom(s) has been proven to be cured. Replacement of the fuel control hydromechanical assembly (HMA) or the electronic control unit (DECU) for fault isolation purposes should be attempted as a last resort. If the symptoms are not corrected by this method, reinstall the original HMA or DECU on the engine. If the new components completely correct the fault, make certain to include complete symptom data together with accumulated operating time on maintenance forms returned with the component. If such data is not supplied, the item must be returned to overhaul, regardless of condition.
- b. For faults related to signals supplied from components external to FADEC, it is recommended that these external components be functionally tested per manufacturer specified procedures. Fault isolation procedures for the FADEC system may not detect all problems occurring in external signal sources.

WARNING

THE EMC-32T FADEC FAULT DETECTION SYSTEM IS A LIMITED DIAGNOSTIC TOOL. IT MONITORS CRITICAL INPUT AND OUTPUT SIGNALS OF THE FADEC SYSTEM AND INTERNAL FUNCTIONS OF THE DECU. THE FAULT LOGIC DOES NOT MONITOR ALL COMPONENTS OR FUNCTIONS OF THE T55-L-714 HMA SYSTEM SINCE MANY TYPES OF FAILURES ARE NOT ELECTRONICALLY (BIT) DETECTABLE. THE FAULT LOGIC MONITORS ONLY THOSE COMPONENTS AND FUNCTIONS AS SPECIFIED IN THE CECO SYSTEM SPECIFICATION 109597.

THEREFORE, THE ABSENCE OF FAULT CODES DOES NOT GUARANTEE HMA SYSTEM INTEGRITY. ANY HMA SYSTEM PROBLEM OR ANOMALY SHOULD BE FULLY INVESTIGATED BY MAINTENANCE PERSONNEL FOR CAUSE AND RESOLUTION PRIOR TO DETERMINING READINESS FOR FLIGHT. READINESS FOR FLIGHT SHOULD NOT BE DETERMINED SOLELY ON THE ABSENCE OF FAULT CODES.

CAUTION

DIRECTION IN THIS MANUAL TO REPLACE HMA OR DECU COMPONENTS IS IN SOME CASES BASED ON DEFAULT, THAT IS, IT IS CONCLUDED TO BE THE ONLY REMAINING POSSIBILITY OF PROBLEM CAUSE WITHIN THE SYSTEM AFTER ALL OTHER CAUSES HAVE BEEN ELIMINATED.

IF THE SYSTEM PROBLEM IS NOT ALLEVIATED BY REPLACEMENT OF THE DECU OR HMA, IT IS LIKELY THAT THESE COMPONENTS WERE NOT DISCREPANT. IN SUCH CASE IT SHOULD BE VERIFIED THAT ALL PRECEDING FAULT ISOLATION STEPS WERE CONDUCTED CORRECTLY. IT SHOULD ALSO BE INVESTIGATED WHETHER THE PROBLEM HAS CAUSES EXTERNAL TO THE HMA SYSTEM OR CAUSES DUE TO INCORRECT OPERATING PROCEDURE.

CAUTION

DIRECTION TO REPLACE AIRFRAME OR ENGINE COMPONENTS WHICH ARE NOT MANUFACTURED BY CECO IS BASED ON THE LIM-

ITED INFORMATION WHICH CAN BE DETERMINED WITH SIMPLE VOLT-OHMMETER CHECKS. THE INTENT IS TO ISOLATE A SUSPECTED PROBLEM AREA RATHER THAN MAKE A FINAL DETERMINATION TO REJECT THESE COMPONENTS. APPLICABLE CHECKOUT PROCEDURES FOR THESE COMPONENTS SPECIFIED BY THE AIRFRAME OR ENGINE MANUFACTURER SHOULD BE APPLIED TO DETERMINE THE INTEGRITY OF THESE COMPONENTS.

CAUTION

ELECTRICAL PARAMETERS GIVEN IN THIS MANUAL REFLECT CHARACTERISTICS OF ACTUAL AIRCRAFT COMPONENTS. WHEN USING THIS MANUAL IN A TEST CELL INSTALLATION, IT SHOULD BE NOTED THAT SIGNAL INPUTS FOR AIRCRAFT COMPONENTS MAY BE PROVIDED BY REPRESENTATIVE TEST CELL EQUIPMENT. IN SOME INSTANCES, THE ELECTRICAL CHARACTERISTICS OF THE TEST CELL EQUIPMENT MAY NOT BE THE SAME AS THOSE OF THE ACTUAL AIRCRAFT COMPONENTS. THIS CAN RESULT IN FAULTS BEING LOGGED BY THE DECU AND CAN POSSIBLY DAMAGE THE DECU. IF DIFFERENCES ARE FOUND, THE TEST CELL EQUIPMENT SHOULD BE REPLACED BEFORE FADEC TESTING CONTINUES.

NOTE

Before replacing any component, be sure that a contaminated or corroded connector is not the cause of the fault. Clean connectors with contact cleaner and blow-dry using compressed nitrogen (preferred) or filtered dry air.

G-7 DISPLAY OF FAULT CODES

- a. Code Display. All faults are classified into two main categories of criticality. Hard faults are failures which could cause unacceptable engine and/or aircraft performance if operation were to continue in the normal primary mode of control. Soft faults are failures which do not impact normal control of the engine or aircraft. Fault information is logged in an electrically erasable nonvolatile memory (EEPROM), and is available through a two-digit hexadecimal display on the DECU. See figure 201 for location of the display. The most significant digit is used to identify the source of the faulty component, as defined below:

F -- Fluid Controller (HMU/Pump)
 A -- Airframe-Supplied Sensor
 D, 1, or B -- DECU
 E-- Engine-Supplied Sensor
 C -- Communication Between DECUs

The least significant digit is used to identify the specific fault. The codes are listed in Table 1 in numeric/ alpha order with their descriptions and fault isolation procedure numbers.

TABLE 1. FAULT CODE INDEX

Fault Code	Fault Description	Procedure Figure No.
10	Microprocessor Hard Fault	141
11	Non-volatile RAM Checksum Hard Fault	141
12	Non-volatile RAM Engine History Data Soft Fault	141
13	Non-volatile RAM Fault Data Soft Fault	141
14	Non-volatile RAM Accumulated Fault Data Soft Fault	141
15	Non-volatile RAM Write Test Soft Fault	141
16	Non-volatile RAM Storage Incomplete	141
17	Non-volatile RAM History Data Inconsistent	141
18	Minor Cycle Not Completed Hard or Soft Fault	141
1B	EMS Cycle Not Completed Soft Fault	141
1C	A/D Conversion Not Completed Hard or Soft Fault	141
1E	RAM Failure Hard Fault	141
1F	Opcode Error Hard Fault	141
A1	Q Sensor Soft Fault	112
A2	N2 Set Potentiometer Soft Fault	113
A3	Primary and Reversionary C/P Angle LVDT Soft Fault	114
A4	NR Sensor Soft Fault	115
A5	Primary and Reversionary ECL Resolver Soft Fault	116
A6	Airframe Emergency +28V DC Supply Soft Fault	117
A7	Airframe +28V DC Supply Soft Fault	118
B2	Primary or Reversionary N1 B Sensor Soft Fault	133
B3	Primary or Reversionary N2B Sensor Soft Fault	134
B4	Primary or Reversionary T4.5 Sensor Soft Fault	135
B5	Primary or Reversionary C/P Angle LVDT Soft Fault	136
B6	Primary or Reversionary ECL Resolver Soft Fault	137
B7	Primary or Reversionary PLA Potentiometer Soft Fault	138
B9	Primary or Reversionary CJC Soft Fault	139
BA	Reversionary +28V Soft Fault	139
BB	Reversionary T4.5 Calibration Soft Fault	139
BC	Primary or Reversionary 400Hz Resolver Reference Soft Fault	140
C1	Communication Line Soft Fault on T4.5 (O) Signal	129
C2	Communication Line Hard or Soft Fault on P1 (O) Signal	129
C3	Communication Line Hard or Soft Fault on T1 (O) Signal	129
C4	Communication Line Soft Fault on Q (O) Signal	130
C5	Communication Line Soft Fault on N2 SET (O) Signal	129
C6	Communication Line Soft Fault on C/P (O) Signal	129
C7	Communication Line Soft Fault on NR (O) Signal	129
C8	Communication Link Soft Fault	129
C9	Communication Line Soft Fault on N1B (O) Signal	131
CF	Loss of Load Share Signals Hard Fault	132
DO	Overspeed Drive Soft Fault	119
D1	P3 Transducer Soft Fault	121
D2	P1 Transducer Soft Fault	122
D3	28V "OR" Diodes Soft Fault	119

TABLE 1. FAULT CODE INDEX (CONT)

Fault Code	Fault Description	Procedure Figure No.
D4	+10V Reference Hard Fault	120
D5	+/-15V Hard Fault	120
D6	+12V Reversionary or +/-12V Overspeed Soft Fault	119
D7	+5V Hard Fault	120
D8	Primary and Reversionary CJC Soft Fault	120
D9	+24V Regulator Soft Fault	120
DA	+5V Reversionary Soft Fault	119
DB	Reversionary System Soft Fault or Idle Check Soft Fault	119
DC	T4.5 Calibration Soft Fault	120
DD	Overspeed Check Soft Fault	119
DE	Primary and Reversionary 400Hz Resolver Reference Soft Fault	123
DF	Watchdog Timer Test Hard Fault	120
E1	Primary and Reversionary T4.5 Sensor Soft Fault	124
E2	T1 Sensor Soft Fault	125
E3	N2A Sensor Soft Fault	126
E4	Primary and Reversionary N2B Sensor Hard Fault	127
E5	N2A/N2B Difference Soft Fault	128
F1	N1A Sensor Soft Fault	101
F2	Primary or Reversionary N1 B Sensor Hard Fault	102
F3	N1A/N1B Difference Soft Fault	103
F4	MV Potentiometer Hard or Soft Fault	104
F5	Wf/Stepcount Difference Hard Fault	105
F6	Primary and Reversionary PLA Potentiometer Soft Fault	106
F7	Bleed Valve Solenoid Hard Fault	107
F8	Primary/Reversionary Solenoid Hard Fault	108
F9	Alternator Voltage Soft Fault	109
FA	Start Fuel Solenoid Soft Fault	110
FB	Reversionary Step Count Soft Fault	111
None	Unable to Switch to Reversionary Mode	142
None	Unable to Switch to Primary Mode	143
None	System Toggles Between Primary and Reversionary Mode	144
None	Q Load Share Selected, Qs Not Matched	145
None	T4.5 Load Share Selected, T4.5 Not Matched	146
None	Ignition Relay Does Not Function	147
None	Bleed Band Does Not Function Properly	148
None	Engine Out Indicator (EOI) Does Not Illuminate During Normal Shutdown	149
None	No Observed Engine Speed Reduction During Overspeed Test	150
None	No Beeper Switch Response in Reversion	151
None	Unable to Perform Power Assurance Test (Results Not Indicated on Hex Display)	152
None	Moving ECL Lever to Stop Causes Increase in Engine Power	153
None	Moving ECL Lever to Flight Causes Engine Shutdown	154
None	Engine Out Indicator (EOI) Is Always Illuminated	155
None	F/R Lamp Does Not Illuminate When Reversion Is Selected	156
None	F/R Lamp Is Illuminated When Primary Is Selected	157
NOTE		
If fault code displayed is not listed in Table 1, follow procedures in Figure 158.		

- b. To View Current Faults and Faults From Last Engine Run. Faults displayed in shutoff cannot be cleared until the engine is run above 48 percent N1.
- (1) Turn on power to DECU.
 - (2) Set engine condition lever (ECL) to stop position.
 - (3) The display will indicate current fault codes and fault codes from the last engine run in sequence. After all applicable fault codes have been displayed, the sequence will repeat. If there are no applicable fault codes, an "88" will be displayed. Record all codes displayed.

NOTE

If an ECL fault occurs, the DECU holds the second to last good ECL value until DECU power is removed. If the ECL fault is still present when DECU power is reapplied, the ECL value defaults to GROUND. Therefore, if the second to last good ECL value is FLIGHT, the hex display will not display any faults until DECU power is cycled. If the second to last good ECL value is GROUND, the hex display will display both current faults and faults from the last engine run until DECU power is cycled. In either case, when DECU power is reapplied, the ECL value will default to GROUND, and only current faults can be displayed until the ECL fault has been cleared.

G-8 POWER SUPPLY INTERRUPT

- a. The DECU is designed to operate normally with three separate power buses. The primary control lane is powered by either the engine HMA alternator (28V ALT) at engine speeds greater than idle, or the 28V airframe DC bus (28V AF) whichever is higher. The reversionary control lane is powered by either 28V AF or the 28V emergency bus (28V EM), whichever is higher. During pilot generator switching actions, which normally take place at flight idle conditions before and then subsequent to a flight, simultaneous aircraft bus interrupts on the 28V AF and 28V EM can occur, causing the reversion control lane to be depowered. The primary control lane continues operating normally since it is receiving its power from 28V ALT.
- b. The primary lane monitors specific reversionary lane signals. When both power supplies to reversionary are interrupted, these signals are temporarily seen as out of range by the primary lane. If the interrupts are of sufficient duration (>50ms), the primary lane will latch the faults. The faults remain latched in primary until primary lane power is removed, even if a reversionary reset has cleared the reversionary lane of all faults. The end result is one or more nuisance faults that are due to the power interruption, not to an actual FADEC problem. The possible faults are listed below. The actual combination of faults will depend on both the operating conditions at the time of the interrupt and the duration of the interrupt. FADEC faults caused by power interrupts are expected to be an occasional random occurrence, not a regular occurrence.

<u>FAULT CODE</u>	<u>FAULT</u>
A1	Q
A6	<u>28V EM</u>
A7	<u>28V EM</u>
B2	N1B
B3	N2B
B5	C/P LVDT
B6	ECL
B7	PLA
BC	RESOLVER REFERENCE
DO	OVERSPEED DRIVE
D3	OR DIODES
D6	<u>+12V REVERSIONARY</u>
DA	<u>+5V REVERSIONARY</u>
DB	REVERSIONARY SYSTEM
DD	OVERSPEED CHECK
E5	N2A/N2B DIFFERENCE
F3	N1A/N1B DIFFERENCE

- c. If any of the above faults occur, the engine must be shut down and power to the DECU cycled to clear the faults. After power is cycled, the appropriate action must be taken to confirm the fault (run engine with ECL at GROUND, run engine with ECL at FLIGHT, etc.) If the faults clear (hex display of "88" with ECL in ground), the faults are to be considered due to power interrupts, and not indicative of a FADEC system fault. If the faults do not clear, then the appropriate fault isolation action should be taken.

G-9 OPERATIONAL PROBLEMS WITHOUT CODES

There are some operational problems that may be noted that do not result in fault codes on the diagnostic display, such as, engine torques not matched, no response to cockpit switch, etc. Refer to fault isolation procedure figures 142 through 157 for these problems.

G-10 USING THE FAULT ISOLATION DIAGRAMS

- a. Display current fault codes using the procedure defined in paragraph G-7. Record all fault codes. If a system fault has been observed that does not result in a fault code, record the symptom(s).

NOTE

Under specific conditions, it is possible for an undefined fault code not listed in Table 1 to appear on the hex display. In this event, the procedure given in figure 158 shall be followed.

- b. If only one fault is noted, locate the fault by fault code or description in Table 1. Go to the figure listed for that fault and follow the procedure.

- c. If multiple fault codes and/or symptoms are noted, use the following guidelines to determine the order of troubleshooting. Faults listed in step c.(1) should be investigated first, then faults listed in step c.(2), etc. Faults listed within the same item may generally be investigated in any order with respect to each other; exceptions are given at the beginning of the affected fault code procedures.
- (1) All fault codes beginning with '1'.
 - (2) B9, BA, BB, and BC.
 - (3) All fault codes beginning with "D" except D1, D2, DE, and DF.
 - (4) D1, D2, and DE.
 - (5) All remaining fault codes beginning with "B".
 - (6) All fault codes beginning with "A".
 - (7) All fault codes beginning with "E".
 - (8) All fault codes beginning with "C" except CF.
 - (9) All fault codes beginning with "F".
 - (10) CF.
 - (11) DF.
 - (12) Any symptoms noted that do not cause a fault code.
- d. Once the first fault to be investigated has been determined, locate the fault in table 1. Go to the figure listed for that fault and follow the procedure. Once the fault has been cleared, check to see if any other faults still exist. If there are still faults, use the guidelines above to determine which fault to troubleshoot next. Continue investigating faults one at a time until all faults are cleared.
- e. If the engine exhibits erratic behavior but no fault codes are displayed, perform the insulation/voltage check per figure 159 to determine if a bad ground connection is causing the problem.

G-11 DIAGRAMS

- a. Fuel Control System Harness Connections. See figure 201.
- b. Electrical Connector Pin Locations. See figure 202.
- c. HMU Schematic Diagram. See figure 203.
- d. Interface wiring diagram (Ref. APPENDIX D).

G-12 ABBREVIATIONS

A/D	Analog-to-digital	N2A	N2 signals from
AL	Alumel	N2B	dual magnetic pickup
BLD	Bleed	N2SET	Power turbine set speed
C/P	Collective pitch angle (same as RTL)	O/S	Overspeed
CDP	Compressor discharge pressure	O/STAT	Overspeed status
CJC	Cold junction compensation for temperature signal	Paf	Metering head regulator bypass return pressure
CR	Chromel	Pbc	Mechanical speed sensor pressure out-put
DC	Direct current	Pf	Pump discharge pressure
DECU	Digital Electronic Control Unit	Pfm	Pump discharge pressure metered
EEPROM	Electrically erasable programmable read-only memory	PLA	Power lever angle
ECL	Engine control lever	Pm	Bleed system pressure
ECLEX	ECL excitation	Pme	Metering valve discharge pressure
EGT	Exhaust gas temperature	Pn	Fuel pressure to engine
EMS	Engine monitoring system	Pot.	potentiometer
EX	Excitation	PSM	Primary stepper motor
E01	Engine out indicator #1	Pw	Windmill bypass valve pressure
E02'	Engine out indicator #2	P1	Atmospheric air pressure
FADEC	Full Authority Digital Electronic Control	P3	Compressor discharge pressure
F/R	Failure/reversionary selected	Q	Torque
FPU	Fuel Pump Unit	RAM	Random access memory
GND	Ground	REF	Reference
HMA	Hydromechanical Assembly	RET	Return
HMU	Hydromechanical Unit	RSM	Reversion stepper motor
IGN	Ignition	RTL	Rotor thrust lever (same as collective pitch)
LRU	Line Replaceable Unit	REV	Reversionary control mode
LVDT	Linear variable displacement transformer	SEL	Select
MAG	Magnetic	SIG	Signal
MV	Metering valve	SOL	Solenoid
NR	Sensed rotor speed	T1	Ambient temperature
NVM	Non-volatile memory	T4.5	Power turbine inlet temperature
N1	Sensed core speed	VDC	Volts direct current
N1A	N1 from magnetic speed pickup	VEM	Emergency voltage
N1B	N1 from alternator	Wf	Fuel flow
N2	Sensed power turbine speed	Ω	Ohms
TBD	To be determined		

FAULT ISOLATION TREES

G-13 FAULT TREES

a. The maintenance procedures required to isolate the fault codes displayed on the DECU to line replaceable units (LRUs) are depicted in the following fault tree diagrams. Fault trees are listed according to fault codes. The procedures are biased against removing the HMU until other more accessible possibilities have been eliminated.

b. In the fault trees, "DECU #1" is used to indicate the FADEC under investigation, be it the right-hand or left-hand engine. "DECU #2" is used to indicate the FADEC on the opposite-side engine.

c. Each of the fault trees is accompanied by a facing page that contains expanded instructions for some of the steps. The expanded instructions contain more detail for certain steps, reference to helpful diagrams (which are at the end of this manual), and resistance limits.

d. The term "manufacturer" as stated in this manual refer to either Textron Lycoming or Boeing Helicopters. dependent on whether the context refers to an airframe component or an engine component.

G-14 DIAGRAMS

The following diagrams appear in this manual.


a. Figure 201, Fuel Control System Harness Connections. This diagram shows the physical location of each harness connector and component connector. It can be used to locate the connectors as called out in the charts.

b. Figure 202, Electrical Connector Pin Locations. This diagram can be used to identify the physical location of each connector pin of the component (DECU or HMA) connectors. Note that the socket locations for the harness connectors are the same except that they are reversed to form a mirror image.

c. Electrical System Schematic (Ref. APPENDIX D). This diagram can be used to trace the termination of each terminal on each connector. For instance, find the N1 A SPEED PICKUP at lower right corner of the diagram on page D-3. The diagram shows that it is in the HMU at J4 connector terminals R and S. Follow up to top to trace through harness P1 7/J75 connector to harness PL1 connector to DECU PL1 connector terminals MM and FF.


d. Figure 203, HMA Schematic Diagram. This diagram gives an operational overview of the HMU.

FAULT CODE F1
N1A SENSOR



Fault Code F1, N1A Sensor
Figure 101 (Sheet 1 of 2)

FAULT CODE F1
N1A SENSOR



Fault Code F1, N1A Sensor
Figure 101 (Sheet 2 of 2)

G-15 FAULT CODE F1, N1A SENSOR EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 101.

- Step 3. Check harness connector PL1 (figure 201) at DECU, and P4 at HMA for tight connections.
- Step 4. Disconnect connectors PL1 and P4 to check pins and sockets.
- Step 6. With PL1 disconnected, check resistance of HMA (N1A sensor) at harness PL1 connector sockets MM and FF (figure 202). Limit is 200-550Q.
- Step 7. With P4 disconnected, check resistance of HMA (N1A sensor) at HMA J4 connector pins R and S. Limit is 200-550Q.
- Step 8. Refer to manufacturer's procedure for checking drive pad and spline.
- Step 9. Before tightening harness connectors PL1 and P4, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 13. Refer to manufacturer's procedure for checking drive pad and spline.
- Step 15. Refer to manufacturer's procedure for checking drive pad and spline.
- Step 18. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 21. Refer to manufacturer's procedure for checking drive pad and spline
- Step 23. Refer to manufacturer's procedure for diagnosing and replacing harness.

RESISTANCE-CHECK SUMMARY


Component	No.	Connector	Resistance (Ω)	
		Contacts	Limits	Nominal*
HMA - N1A Sensor *At <u>25°C</u>	PL1	MM & FF	<u>200-550</u>	<u>390</u>
	J4	R & S	<u>200-550</u>	<u>390</u>

FAULT CODE F2
N1B SENSOR



Fault Code F2, N1B Sensor
Figure 102 (Sheet 1 of 2)

FAULT CODE F2
N1B SENSOR



Fault Code F2, N1B Sensor
Figure 102 (Sheet 2 of 2)

G-16 FAULT CODE F2, NIB SENSOR EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 102.

- Step 3. Check harness connector PL3 (figure 201) at DECU, and P6 at HMA for tight connections.
- Step 4. Disconnect connectors PL3 and P6 to check pins and sockets.
- Step 7. With PL3 disconnected, check resistance of N1 B sensor at harness PL3 connector sockets A and c (figure 202). Limit is 0.3-3.55.
- Step 8. With P6 disconnected, check resistance of HMA (N1B sensor) at HMA J6 connector pins E and F. Limit is 0.3-3.0Q.
- Step 9. Before tightening harness connectors PL3 and P6, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 13. Refer to manufacturer's procedure for checking drive pad and spline.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 21. Refer to manufacturer's procedure for replacing drive pad or spline.
- Step 23. Refer to manufacturer's procedure for diagnosing and replacing harness.


RESISTANCE-CHECK SUMMARY

Component	No.	Connector Contacts	Resistance (Ω)	
			Limits	Nominal
HMA - NIB Sensor *At <u>25°C</u>	PL3	A & c	<u>0.3 - 3.5</u>	<u>0.7</u>
	J6	E & F	<u>0.3 - 3.0</u>	<u>0.7</u>

FAULT CODE F3
N1A/N1B DIFFERENCE



Fault Code F3, N1/N1B Difference
Figure 103 (Sheet 1 of 2)



Fault Code F3, N1/N1B Difference
Figure 103 (Sheet 2 of 2)

G-17 FAULT CODE F3, NIA/NIB DIFFERENCE EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 103.

- Step 4. Check harness connectors PL1 and PL3 (figure 201) at DECU, and P4 and P6 at HMA for tight connections.
- Step 5. Disconnect connectors PL1, PL3, P4 and P6 to check pins and sockets.
- Step 7. With PL1 disconnected, check resistance of HMA (N1A sensor) at harness PL1 connector sockets MM and FF (figure 202). Limit is 200-550Q. With PL3 disconnected, check resistance of HMA (N1 B sensor) at harness PL3 connector sockets A and c. Limit is 0.3-3.5o2.
- Step 8. With P4 disconnected, check resistance of HMA (N1A sensor) at HMA J4 connector pins R and S. Limit is 200-550Q. With P6 disconnected, check resistance of HMA (N1 B sensor) at HMA T. J6 connector pins E and F. Limit is 0.3-3.3Q.
- Step 9. Before tightening harness connectors PL1, PL3, P4 and P6, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 13. Refer to manufacturer's procedure for checking drive pad and spline.
- Step 18. Refer to manufacturer's procedure for diagnosis and replacing harness.
- Step 21. Refer to manufacturer's procedure for replacing drive pad or spline.
- Step 23. Refer to manufacturer's procedure for diagnosing and replacing harness.

RESISTANCE-CHECK SUMMARY


Component	No.	Connector Contacts	Resistance (Ω)	
			Limits	Nominal *
HMA - N1A Sensor	PL1	MM &FF	<u>200 - 550</u>	<u>390</u>
	J4	R & S	<u>200 - 550</u>	<u>390</u>
HMA - N1A Sensor	J4	A-c	<u>0.3 - 3.5</u>	<u>0.7</u>
*At <u>25°C</u>	J6	E & F	<u>0.3 - 3.0</u>	<u>0.7</u>

FAULT CODE F4
MV POTENTIOMETER



Fault Code F4, MV Potentiometer
Figure 104 (Sheet 1 of 2)

FAULT CODE F4
MV POTENTIOMETER



Fault Code F4, MV Potentiometer
Figure 104 (Sheet 2 of 2)

G-18 FAULT CODE F4, MV POTENTIOMETER EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 104.

Step 2. Check harness connector PL1 (figure 201) at DECU, and P4 at HMA for tight connections.

Step 3. Disconnect connectors PL1 and P4 to check pins and sockets.

Step 5. **CAUTION: DO NOT USE AN OHMMETER THAT CAN APPLY MORE THAN 5 mA WHEN MEASURING RESISTANCES, TO AVOID DAMAGING THE FUEL METERING VALVE POTENTIOMETER.**

With PL1 disconnected, check resistance of HMA (fuel metering valve potentiometer) at harness

PL1 connector sockets Q and y (results are "a") and y and KK (results are "b"). Limit for "a" and "b" is 300 - 5800Ω. Check resistance at sockets g and KK (results are "c"). Limit for "c" is 4250 - 5750Ω. Use the following equation to check wiper resistance:

$$a + b - c \div 2 = d$$

Limit for "d" is ≤ 300 . Use the following equation to check if the high or low limit of the metering valve potentiometer has been exceeded:

$$b - d \div c = e$$

Limit for "e" is 0.0710 - 0.9573

Step 6. **CAUTION: DO NOT USE AN OHMMETER THAT CAN APPLY MORE THAN 5 mA WHEN MEASURING RESISTANCES, TO AVOID DAMAGING THE FUEL METERING VALVE POTENTIOMETER.**

With P4 disconnected, check resistance of HMA (fuel metering valve potentiometer) at HMA J4 connector pins M and N (results are "f") and N and P (results are "g"). Limit for "f" and "g" is 300 - 5800Ω. Check resistance at pins M and P (results are "h"). Limit for "h" is 4250 - 5750Ω. Use the following equation to check wiper resistance.

$$f + g - h \div 2 = i$$

Limit for "i" is ≤ 30052 . Use the following equation to check if the high or low limit of the metering valve potentiometer has been exceeded:

$$g - i \div h = j$$

Limit for "j" is 0.0710 - 0.9573

Step 7. Before tightening harness connectors PL1 and P4, be sure that keyways in harness connectors are aligned with keyways in component connectors.

Step 12. Refer to manufacturer's procedure for diagnosing and replacing harness.


Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness.

G-18 FAULT CODE F4, MV POTENTIOMETER EXPANDED INSTRUCTIONS (CONTINUED)

RESISTANCE-CHECK SUMMARY

Component	No.	Connector Contacts	Resistance (Ω)	
			Limits	Nominal*
HMA - Fuel Metering Valve Potentiometer	PL1	g & y (a)	<u>300 - 5800</u>	*
		y & K (b)	<u>300 - 5800</u>	**
		g and KK (c)	<u>4250 - 5750</u>	<u>5000</u>
		$a + b - c \div 2$ (d)	≤ 300	<u>195</u>
		$b - d \div c$ (e)	<u>0.0710-0.9573</u>	**
	J4	M & N (f)	<u>300- 5800</u>	
		N & P. (g)	<u>300 - 5800</u>	
		M & P (h)	<u>4250-5750</u>	<u>5000</u>
		$f + g - h \div 2$ (i)	≤ 300	<u>195</u>
		$g - i \div h$ (j)	<u>0.0710-0.9573</u>	**


* At 25°C
 ** Dependent on MMV Position



Fault Code F5, Wf/Stepcount Difference
Figure 105 (Sheet 1 of 2)

FAULT CODE F5
WF/STEP-COUNT DIFFERENCE

(CONTINUED)



Fault Code F5, Wf/Stepcount Difference
Figure 105 (Sheet 2 of 2)

G-19 FAULT CODE F5 Wf/STEP/COUNT DIFFERENCE EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 105.

- Step 2. Check harness connector PL1 (figure 201) at DECU, and P4 at HMA for tight connections.
- Step 3. Disconnect connectors PL1 and P4 to check pins and sockets.
- Step 5. With PL1 disconnected, check resistance of HMA (primary stepper motor) at harness PL1 connector sockets T and X (figure 202), U and X, V and X, and W and X. In each case limit is 45-111Q.
- Step 6. With P4 disconnected, check resistance of (primary stepper motor) at HMA J4 connector pins D and T, C and T, B and T, and A and T. In each case, limit is 45-111Q.
- Step 7. Before tightening harness connectors PL1 and P4, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 12. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness.

RESISTANCE-CHECK SUMMARY


Component	No.	Connector Contacts	Resistance (Ω)	
			Limits	Nominal*
HMA - Primary Stepper Motor	PL1	T & X	45 - 111	73
		U & X	45 - 111	73
		V & X	45 - 111	73
		W & X	45 - 111	73
	J4	D & T	45 - 111	73
		C & T	45 - 111	73
		B & T	45 - 111	73
		A & T	45 - 111	73
* At 25°C				

FAULT CODE F6
PLA POTENTIOMETER



Fault Code F6, PLA Potentiometer
Figure 106 (Sheet 1 of 2)

FAULT CODE F6
PLA POTENTIOMETER



Fault Code F6, PLA Potentiometer
Figure 106 (Sheet 2 of 2)

G-20 FAULT CODE F6, PLA POTENTIOMETER EXPANDED INSTRUCTIONS
--

Refer to numbered steps in figure 106.

Step 2. Check harness connector PL3 (figure 201) at DECU, and P4 at HMA for tight connections.

Step 3. Disconnect connectors PL3 and P4 to checkpins and sockets.

Step 5. **CAUTION: DO NOT USE AN OHMMETER THAT CAN APPLY MORE THAN 5 mA WHEN MEASURING RESISTANCES, TO AVOID DAMAGING THE PLA POTENTIOMETER.**

With PL3 disconnected, check resistance of HMA (PLA potentiometer) at harness PL3 connector sockets U and T (results are "a") and T and S (results are "b"). Limit for "a" and "b" is 510 - 5750Ω. Check resistance at sockets U and S (results are "c"). Limit for "c" is 4250 - 5750Ω. Use the following equation to check wiper resistance:

$$a + b - c \div 2 = d$$

Limit for "d" is $\leq 300\Omega$. Use the following equation to check if the high or low limit of the PLA potentiometer has been exceeded:

$$b - d \div c = e$$

Limit for "e" is 0.120 - 0.950.

Step 6. **CAUTION: DO NOT USE AN OHMMETER THAT CAN APPLY MORE THAN 5 mA WHEN MEASURING RESISTANCES, TO AVOID DAMAGING THE PLA POTENTIOMETER.**

With P4 disconnected, check resistance of HMA (PLA potentiometer) at HMA J4 connector pins X and Y (results are "f") and Y and Z (results are "g"). Limit for "f" and "g" is 510 - 5750Ω. Check resistance at pins X and Z (results are "h"). Limit for "h" is 4250 - 5750Ω. Use the following equation to check wiper resistance.

$$f + g - h \div 2 = i$$

Limit for "i" is $\leq 300\Omega$. Use the following equation to check if the high or low limit of the metering valve potentiometer has been exceeded:

$$g - i \div h = j$$

Limit for "j" is 0.120 - 0.950.

Step 7. Before tightening harness connectors PL3 and P4, be sure that keyways in harness connectors are aligned with keyways in component connectors.

Step 12. Refer to manufacturer's procedure for diagnosing and replacing harness.

Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness.

G-20 FAULT CODE F6, PLV POTENTIOMETER EXPANDED INSTRUCTIONS (CONTINUED)


RESISTANCE-CHECK SUMMARY

Component	No.	Connector	Resistance (Ω)	
		Contacts	Limits	Nominal *
HMA - PLA Potentiometer	PL3	U & T (a)	<u>510 - 5750</u>	**
		T & S (b)	<u>510 - 5750</u>	**
		U & S (c)	<u>4250 - 5750</u>	<u>5000</u>
		a + b - c - 2 (d)	<u><-300</u>	<u>195</u>
		b - d + c (e)	<u>0.120 - 0.950</u>	**
	J4	X & Y (f)	<u>510 - 5750</u>	**
		Y & Z (g)	<u>510 - 5750</u>	**
		X & Z (h)	<u>4250-5750</u>	<u>5000</u>
		f + g - h \div 2 (i)	<u><300</u>	<u>195</u>
		g - i \div h (j)	<u>0.120 - 0.950</u>	**

* At 25°C

** Dependent on PLA Position


FAULT CODE F7
BLEED VALVE SOLENOID



Fault Code F7, Bleed Valve Solenoid
Figure 107 (Sheet 1 of 2)

FAULT CODE F7
BLEED VALVE SOLENOID

(CONTINUED)



Fault Code F7, Bleed Valve Solenoid
Figure 107 (Sheet 2 of 2)

G-21 FAULT CODE F7, BLEED VALVE SOLENOID EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 107.

Step 2. Check harness connector PL1 (figure 201) at DECU, and P4 at HMA for tight connections.

Step 3. Disconnect connectors PL1 and P4 to check pins and sockets.

Step 5. With PL1 disconnected, check resistance of HMA (bleed valve solenoid) at harness PL1 connector sockets r and s (figure 202). Limit is 27 - 62Ω.

Step 6. With P4 disconnected, check resistance of HMA (bleed valve solenoid) at HMA J4 connector pins E and F. Limit is 27 - 62Ω.

Step 7. Before tightening harness connectors PL1 and P4, be sure that keyways in harness connectors are aligned with keyways in component connectors.


Step 12. Refer to manufacturer's procedure for diagnosing and replacing harness.

Step 14. Refer to manufacturer's procedure for diagnosing and replacing harness.

RESISTANCE-CHECK SUMMARY


Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal *
HMA - Bleed Valve Solenoid *At <u>25°C</u>	PL1	r & s	<u>27 - 62</u>	<u>42</u>
	J4	E & F	<u>27 - 62</u>	<u>42</u>

FAULT CODE F8
PRIMARY/REVERSIONARY SOLENOID



Fault Code F8, Primary/Reversionary Solenoid
Figure 108 (Sheet 1 of 2)

FAULT CODE F8
PRIMARY/REVERSIONARY SOLENOID



Fault Code F8, Primary/Reversionary Solenoid
Figure 108 (Sheet 2 of 2)

G-22 FAULT CODE F8, PRIMARY/REVERSIONARY SOLENOID EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 108.

- Step 2. Check harness connector PL1 (figure 201) at DECU, and P4 and HMA for tight connections.
- Step 3. Disconnect connectors PL1 and P4 to check pins and sockets.
- Step 5. With PL1 disconnected, check resistance of HMA (primary/reversionary solenoid) at harness PL1 connector sockets I and EE (figure 202). Limit is 27 - 62Ω.
- Step 6. With P4 disconnected, check resistance of HMA (primary/reversionary solenoid) at HMA J4 connector pins V and U. Limit is 27 - 62Ω.
- Step 7. Before tightening harness connectors PL1 and P4, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 12. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal *
HMA - Primary/Reversionary Solenoid	PL1	g & EE	<u>27 - 62</u>	<u>42</u>
*At <u>25°C</u>	J4	U & V	<u>27 - 62</u>	<u>42</u>


FAULT CODE F9
ALTERNATOR



Fault Code F9, Alternator
Figure 109 (Sheet 1 of 2)

FAULT CODE F9
ALTERNATOR

(CONTINUED)



Fault Code F9, Alternator
Figure 109 (Sheet 2 of 2)

G-23 FAULT CODE F9, ALTERNATOR EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 109.

- Step 3. Check harness connector PL3 (figure 201) at DECU, and P6 at HMA for tight connections.
- Step 4. Disconnect connectors PL3 and P6 to check pins and sockets.
- Step 6. With PL3 disconnected, check resistance of HMA (alternator) at harness PL3 connector sockets K and L (figure 202), and sockets M and L. In each case, limit is 0.5 - 10.5Ω.
- Step 7. With P6 disconnected, check resistance of HMA (alternator) at HMA J6 connector pins B and C. and pins A and C. In each case, limit is 0.5 - 10.5Ω.
- Step 8. Before tightening harness connectors PL3 and P6, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 12. Refer to manufacturer's procedure for checking drive pad and spline.
- Step 16. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 19. Refer to manufacturer's procedure for replacing drive pad or spline.
- Step 21. Refer to manufacturer's procedure for diagnosing and replacing harness.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal *
HMA - Alternator	PL3	K & L	<u>0.5 - 10.5</u>	<u>3.0</u>
		M & L	<u>0.5 - 10.5</u>	<u>3.0</u>
	J6	B & C	<u>0.5 - 10.5</u>	<u>3.0</u>
		A&C	<u>0.5 - 10.5</u>	<u>3.0</u>


*At 25°C



Fault Code FA, Start Fuel Solenoid Valve
Figure 110 (Sheet 1 of 2)

FAULT CODE FA
START FUEL SOLENOID

(CONTINUED)



Fault Code FA, Start Fuel Solenoid Valve
Figure 110 (Sheet 2 of 2)

G-24 FAULT CODE FA, START FUEL SOLENOID EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 110.


- Step 3. Check harness connector PL1 (figure 201) at DECU, and P12 at start fuel valve assembly for tight connections.
- Step 4. Disconnect connectors PL1 and P12 to check pins and sockets.
- Step 6. With PL1 disconnected, check resistance of start fuel solenoid at harness PL1 connector sockets S and R (figure 202). Limit is 10.0 - 40.5Ω.
- Step 7. With P12 disconnected, check resistance of start fuel solenoid at start fuel valve assembly J12 connector pins A and B. Limit is 10.0 - 40.0Ω.
- Step 8. Before tightening harness connectors PL1 and P12., be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 11. Refer to manufacturer's procedure for checking operation of start fuel solenoid.
- Step 15. Refer to manufacturer's procedure for diagnosing and replacing harness or start fuel solenoid.
- Step 18. Refer to manufacturer's procedure for diagnosing and replacing start fuel solenoid.
- Step 19. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 20. Refer to manufacturer's procedure for diagnosing and replacing start fuel solenoid.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
Start Fuel Solenoid	PL1	S & R	<u>10.0 - 40.5</u>	<u>21.5</u>
	J12	A & B	<u>10.0 - 40.0</u>	<u>21.5</u>

*At 25°C


FAULT CODE FB
REVERSIONARY STEP COUNT



Fault Code FB, Reversionary Step Count
Figure 111 (Sheet 1 of 2)

FAULT CODE FB
REVERSIONARY STEP COUNT

(CONTINUED)



Fault Code FB, Reversionary Step Count
Figure 111 (Sheet 2 of 2)

G-25 FAULT CODE FB, REVERSIONARY STEP COUNT EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 111.

- Step 2. Check harness connector PL3 (figure 201) at DECU, and P5 at HMA for tight connections.
- Step 3. Disconnect connectors PL3 and P5 to check pins and sockets.
- Step 5. With PL3 disconnected, check resistance of HMA (reversionary stepper motor) at harness PL3 connector sockets F and E (figure 202), G and E, H and E, and J and E. In each case, limit is 11.0 - 24.5Ω.
- Step 6. With P5 disconnected, check resistance of HMA (reversionary stepper motor) at HMA J5. connector pins 2 and 6, 3 and 6, 4 and 6, and 5 and 6. In each case, limit is 11.0 - 24.0Ω.
- Step 7. Before tightening harness connectors PL3 and P5, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 12. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness.

RESISTANCE-CHECK SUMMARY


Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
HMA - Primary Stepper Motor	PL3	F & E	<u>11.0 - 24.5</u>	<u>17.0</u>
		G & E	<u>11.0 - 24.5</u>	<u>17.0</u>
		H & E	<u>11.0 - 24.5</u>	<u>17.0</u>
		J & E	<u>11.0 - 24.5</u>	<u>17.0</u>
	J5	2 & 6	<u>11.0 - 24.0</u>	<u>17.0</u>
		3 & 6	<u>11.0 - 24.0</u>	<u>17.0</u>
		4 & 6	<u>11.0 - 24.0</u>	<u>17.0</u>
		5 & 6	<u>11.0 - 24.0</u>	<u>17.0</u>
	*At <u>25°C</u>			

FAULT CODE A1
Q SENSOR



Fault Code A1, Q Sensor
Figure 112 (Sheet 1 of 2)

FAULT CODE A1
Q SENSOR



Fault Code A1, Q Sensor
Figure 112 (Sheet 2 of 2)

G-26 FAULT CODE AI, Q SENSOR EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 112.

- Step 3. Check harness connector PL1 (figure 201) at DECU, and P2 at signal conditioner for tight connections.
- Step 4. Disconnect connectors PL1 and P2 to check pins and sockets.
- Step 6. With PL1 and P2 disconnected, short P2 connector sockets D and K together. Check resistance at harness PL1 connector sockets H and J (figure 202). Limit is < 1Ω.
- Step 7. Refer to manufacturer's procedure for checking operation of engine torquemeter components.
- Step 8. Before tightening harness connectors PL1 and P2, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 14. Refer to manufacturer's procedure for diagnosing and replacing harness or signal conditioner.
- Step 16. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 18. Refer to manufacturer's procedure for diagnosing and replacing engine torquemeter components.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
Q Sensor Harness *At 25°C	PL1	H & J (with P2 D & K shorted)	≤1	≤1


FAULT CODE A2
N2 SET POTENTIOMETER



Fault Code A2, N2 Set Potentiometer
Figure 113 (Sheet 1 of 2)

FAULT CODE A2
N2 SET POTENTIOMETER

(CONTINUED)



Fault Code A2, N2 Set Potentiometer
Figure 113 (Sheet 2 of 2)

G-27 FAULT CODE A2, N2 SET POTENTIOMETER EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 113.

Step 2. Check harness connector PL1 (figure 201) at DECU and FADEC control panel connector for tight connections.

Step 3. Disconnect connector PL1 and FADEC control panel connector to check pins and sockets.

Step 5. Set the N2 set potentiometer to its lowest setting. With PL1 disconnected, check resistance of N2 set potentiometer at harness PL1 connector sockets h and z. Limit is 3600 - 4200Ω. Check resistance at sockets z and AA (results are "a"). Limit is 800 - 1400Ω. Check resistance at sockets h and AA (results are "b"). Limit is 4500 - 5500Ω. Use the following equation to check if the low limit of the N2 set potentiometer has been exceeded:

$$a \div b = c$$

Limit on "c" is > 0.10.

Set the N2 set potentiometer to its highest setting. Check resistance at sockets h and z. Limit is 800 - 1400Ω. Check resistance at sockets z and AA (results are "d"). Limit is 3600 - 4200Ω. Check resistance at sockets h and AA (results are "e"). Limit is 4500 - 5500Ω. Use the following equation to check if the high limit of the N2 set potentiometer has been exceeded:

$$d \div e = f$$

Limit on "f" is < 0.90.

Step 6. Set the N2 set potentiometer to its lowest setting. With FADEC control panel connector disconnected, check resistance at panel connector pins A and B. Limit is 3600 - 4200Ω. Check resistance at pins B and C (results are g). Limit is 800 - 1400Ω. Check resistance at pins A and C (results are "h"). Limit is 4500 - 5500Ω. Use the following equation to check if the low limit of the N2 set potentiometer has been exceeded:

$$g \div h = i$$

Limit on "i" is > 0.10.

Set the N2 set potentiometer to its highest setting. Check resistance at panel connector pins A and B. Check resistance at pins B and C (results are "j"). Limit is 3600 - 4200Ω. Check resistance at pins A and C (results are "k"). Limit is 4500 - 5500Ω. Use the following equation to check if the low limit of the potentiometer has been exceeded.

$$j \div k = l$$

Limit on "l" is < 0.90.

Step 7. Before tightening harness connector PL1 and FADEC control panel connector, be sure that keyway in harness connectors is aligned with keyways in component connectors.

G-27 FAULT CODE A2, N2 SET POTENTIOMETER EXPANDED INSTRUCTIONS(CONTINUED)


- Step 12 Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 15 Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 16 Refer to manufacturer's procedure for diagnosing and replacing potentiometer.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
N2 Set Potentiometer Lowest Setting	PL1	<u>h & z</u> (a)	<u>3600 - 4200</u>	<u>4000</u>
		<u>z & AA</u> (b)	<u>800 - 1400</u>	<u>1000</u>
		<u>h & AA</u> (c)	<u>4500 - 5500</u>	<u>5000</u>
		<u>a ÷ b</u> (c)	<u>>0.10</u>	<u>0.20</u>
N2 Set Potentiometer Highest Setting	PL1	<u>h & z</u>	<u>800 - 1400</u>	<u>1000</u>
		<u>z & AA</u> (d)	<u>3600 - 4200</u>	<u>4000</u>
		<u>h & AA</u> (e)	<u>4500 - 5500</u>	<u>5000</u>
		<u>d ÷ e</u> (f)	<u><0.90</u>	<u>0.80</u>
N2 Set Potentiometer Lowest Setting	FADEC Control Panel	A & B	<u>3600 - 4200</u>	<u>4000</u>
		B & C (g)	<u>800 - 1400</u>	<u>1000</u>
		A & C (h)	<u>4500 - 5500</u>	<u>5000</u>
		<u>g ÷ h</u> (i)	<u><0.10</u>	<u>0.20</u>
N2 Set Potentiometer Highest Setting	FADEC Control Panel	A & B	<u>800 - 1400</u>	<u>1000</u>
		B & C (j)	<u>3600 - 4200</u>	<u>4000</u>
		A & C (k)	<u>4500 - 5500</u>	<u>5000</u>
		<u>j ÷ k</u> (l)	<u><0.90</u>	<u>0.80</u>

*At 25°C


FAULT CODE A3
COLLECTIVE PITCH ANGLE LVDT



Fault Code A3, Collective Pitch Angle LVDT
Figure 114 (Sheet 1 of 2)

FAULT CODE A3
COLLECTIVE PITCH ANGLE LVDT

(CONTINUED)



Fault Code A3, Collective Pitch Angle LVDT
Figure 114 (Sheet 2 of 2)

G-28 FAULT CODE A3, COLLECTIVE PITCH ANGLE LVDT EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 114.


- Step 2. Check harness connector PL3 (figure 201) at DECU and LVDT for tight connections.
- Step 3. Disconnect connector PL3 and LVDT to check pins and sockets.
- Step 5. With LVT connector disconnected, check resistance of RTL sensor at sensor connector pins 1 and 2. Limit is 110 - 140Ω. Check resistance at pins 3 and 4. Limit is 210 - 260Ω. Check resistance at pins 3 and 5, and pins 4 and 5. Limit is < 230Ω.
- Step 6. Before tightening harness connector PL3 and LVDT connector, be sure that keyway in harness connectors is aligned with keyways in component connectors.
- Step 9. With PL3 disconnected, check resistance of RTL sensor at harness PL3 connector sockets q and p (figure 202). Limit is 210 - 260Ω. Check resistance at sockets z and AA. Limit is 110 - 140Ω.
- Step 10. Refer to manufacturer's procedure for checking operation of RTL sensor.
- Step 13. Refer to manufacturer's procedure for diagnosing and replacing harness or RTL sensor.
- Step 15. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing RTL sensor.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
RTL Sensor C/P Signal	LVDT	3 & 4	<u>210 - 260</u>	<u>225</u>
		3 & 5	<u><230</u>	-
		4 & 5	<u><230</u>	-
C/P Excitation	PL3	q & p	<u>210 - 260</u>	-
		z & AA	<u>110 - 140</u>	<u>120</u>

*At 25°C


FAULT CODE A4
NR SENSOR



Fault Code A4. NR Sensor
Figure 115 (Sheet 1 of 2)

FAULT CODE A4
NR SENSOR

(CONTINUED)



Fault Code A4, NR Sensor
Figure 115 (Sheet 2 of 2)

G-29 FAULT CODE A4, NR SENSOR EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 115.

- Step 2. Check harness connector PL1 (figure 201) at DECU for tight connections.
- Step 3. Disconnect connector PL1 to check pins and sockets.
- Step 5. With PL1 disconnected, check resistance of NR sensor at harness PL1 connector sockets k and N (figure 202). Limit is 110 - 130Ω.
- Step 6. Before tightening harness connector PL1, be sure that keyway in harness connectors is aligned with keyway in DECU connector.
- Step 9. Refer to manufacturer's procedure for checking operation of NR sensor.
- Step 12. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 15. Refer to manufacturer's procedure for diagnosing and replacing NR sensor.
- Step 16. Refer to manufacturer's procedure for diagnosing and replacing harness or NR sensor.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
NR Sensor *At <u>25°C</u>	PL1	<u>k & N</u>	<u>110 - 130</u>	<u>120</u>


FAULT CODE A5
ECL RESOLVER



Fault Code A5, ECL Resolver
Figure 116 (Sheet 1 of 2)

FAULT CODE A5
ECL RESOLVER

(CONTINUED)



Fault Code A5, ECL Resolver
Figure 116 (Sheet 2 of 2)

G-30 FAULT CODE A5, ECL RESOLVER EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 116.


- Step 2. Check harness connector PL3 (figure 201) at DECU, and connector at ECL quadrant for tight connections.
- Step 3. Disconnect PL3 and ECL quadrant connectors to check pins and sockets.
- Step 5. Set ECL to STOP. With PL3 disconnected, check resistance of ECL quadrant (excitation) at harness PL3 connector sockets h and i (figure 202). Limit is 35 - 42Ω. Check resistance of ECL quadrant (signal) at sockets EE and DD. Limit is 90 102Ω. Monitor resistance of ECL quadrant (interlock discrete) at sockets f and LL while moving ECL from STOP to GROUND to FLIGHT. Limits are defined in table below. Monitor resistance of ECL quadrant (gain discrete) at sockets MM and LL while moving ECL from STOP to GROUND to FLIGHT. Limits are as defined in table below. (Note: Gain discrete resistance is not checked at GROUND because switch can be open or closed at that point.)
- Step 6. Set ECL to STOP. With ECL quadrant connector disconnected, check resistance of ECL quadrant (excitation) at quadrant pins 1 and 2. Limit is 35 - 40Ω. Check resistance of ECL quadrant (signal) at quadrant pins 3 and 4. Limit is 90 100Ω. Monitor resistance of ECL quadrant (interlock discrete) at pins 11 and 12 while moving ECL from STOP to GROUND to FLIGHT. Limits are as defined in table below. Monitor resistance of ECL quadrant (gain discrete) at pins 5 and 11 while moving ECL from STOP to GROUND to FLIGHT. Limits are as defined in table below. (Note: Gain discrete resistance is not checked at GROUND because switch can be open or closed at that point.)
- Step 7. Before tightening harness connector PL3 and connector at ECL resolver, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 10. Refer to manufacturer's procedure for checking operation of ECL quadrant.
- Step 13. Refer to manufacturer's procedure for diagnosing and replacing harness or ECL quadrant.
- Step 16. Refer to manufacturer's procedure replacing ECL quadrant.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness
- Step 18. Refer to manufacturer's procedure for diagnosing and replacing ECL quadrant.

G-30 FAULT CODE A5, ECL RESOLVER EXPANDED INSTRUCTIONS(CONTINUED)
--

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
ECL Quadrant - Excitation	PL3	<u>h & i</u>	<u>35 - 42</u>	-
	ECL Quadrant	1 & 2	<u>35 - 40</u>	-
ECL Quadrant - Signal	PL3	EE & DD	<u>90 - 102</u>	-
	ECL Quadrant	3 & 4	<u>90 - 100</u>	-
ECL Quadrant - Interlock Discrete: ECL at STOP ECL between STOP and GROUND ECL at GROUND ECL between GROUND and FLIGHT ECL at FLIGHT	PL3	<u>f & LL</u>	<u>>150K</u>	∞
		<u>f & LL</u>	<u><50</u>	<u>1</u>
		<u>f & LL</u>	<u>>150K</u>	∞
		<u>f & LL</u>	<u><50</u>	<u>1</u>
		<u>f & LL</u>	<u>>140K</u>	∞
ECL Quadrant - Interlock Discrete: ECL at STOP ECL between STOP and GROUND ECL at GROUND ECL between GROUND and FLIGHT ECL at FLIGHT	ECL Quadrant	12 & 11	<u>>150K</u>	∞
		12 & 11	<u><50</u>	<u>1</u>
		12 & 11	<u>>150K</u>	∞
		12 & 11	<u><50</u>	<u>1</u>
		12 & 11	<u>>150K</u>	∞
ECL Quadrant - Gain Discrete ECL at STOP ECL between STOP and GROUND ECL between GROUND and FLIGHT ECL at Flight	PL3	MM & LL	<u><50</u>	<u>1</u>
		MM & LL	<u><50</u>	<u>1</u>
		MM & LL	<u>>150K</u>	∞
		MM & LL	<u>>150K</u>	∞
ECL Quadrant - Gain Discrete ECL at STOP ECL between STOP and GROUND ECL between GROUND AND FLIGHT ECL at FLIGHT	ECL Quadrant	5 & 11	<u><50</u>	<u>1</u>
		5 & 11	<u><50</u>	<u>1</u>
		5 & 11	<u>>150K</u>	∞
		5 & 11	<u>>150k</u>	∞
*At <u>25°C</u>				

FAULT CODE A6
AIRFRAME EMERGENCY 28V DC




Fault Code A6, Airframe Emergency 28V DC
Figure 117

G-31 FAULT CODE A6, AIRFRAME EMERGENCY 28V DC EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 117.

- Step 4. Check harness connector PL3 (figure 201) at DECU for tight connections.
- Step 5. Disconnect connector PL3 to check pins and sockets.
- Step 8. Before tightening harness connector PL3, be sure that keyway in harness connector is aligned with keyway in DECU connector.
- Step 14. Refer to manufacturer's procedure for diagnosing and replacing harness.

FAULT CODE A7 (OR NO DISPLAY)
AIRFRAME +28V DC SUPPLY



NOTE FAULT A7 CAN ONLY BE ILLUMINATED WHEN THE ENGINE IS RUNNING. SINCE THE DECU WILL BE UNPOWERED (PRIMARY) AT SHUTDOWN IF THE AIRFRAME +28V IS NOT PRESENT


Fault Code A7 (or No Display), Airframe +28V DC Supply
Figure 118

G-32 FAULT CODE A7 (OR NO DISPLAY), AIRFRAME +28V DC SUPPLY EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 118.

- Step 3. Check harness connector PL1 (figure 201) at DECU for tight connections.
- Step 4. Disconnect connector PL1 to check pins and sockets.
- Step 6. Before tightening harness connector PL1, be sure that keyway in harness connector is aligned with keyway in DECU connector.
- Step 11. Refer to manufacturer's procedure for diagnosing and replacing harness.

FAULT CODES D0 OVERSPEED DRIVE
 D3 28V "OR" DIODES
 D6 +12V REVERSIONARY OR ± 12V OVERSPEED
 DA +5V REVERSIONARY
 DB REVERSIONARY SYSTEM
 DD OVERSPEED CHECK



Fault Codes D0, D3, D6, DA, DB, DD Internal DECUs Faults
 Figure 119

FAULT CODES D4 +10V DC
 D5 +15V SUPPLY
 D7 +5V SUPPLY
 D8 COLD JUNCTION COMPENSATION
 D9 +24V REGULATOR
 DC T4.5 CALIBRATION
 DF WATCHDOG TIMER TEST

1 TURN DECU POWER
 OFF. REPLACE DECU.

NOTE: FAULT CODE DF CAN OCCUR AS A RESULT OF A PRE-EXISTING HARD FAULT WHEN THE WATCHDOG TIMER TEST IS PERFORMED AT POWER-UP. IF DF OCCURS IN CONJUNCTION WITH ANOTHER HARD FAULT, FOLLOW THE PROCEDURE FOR THE OTHER FAULT CODE FIRST.

Faults Codes D4, D5, D7, D8, D9, DC, DF Internal DECUs Faults
 Figure 120

G-33 FAULT CODES DO, D3, D6, DA, DB, DD INTERNAL DECU FAULTS EXPANDED IN INSTRUCTIONS

Refer to numbered steps in figure 119.


- Step 1. Cycle DECU power to determine if fault is a DECU problem or was caused by an interrupt to both reversionary power supplies.
- Step 3. An internal DECU fault exists. No further troubleshooting is possible.
-

G-34 FAULT CODES D4, D5, D7, D8, D9, DC, DF INTERNAL DECU FAULTS EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 120.

These codes indicate internal DECU problems. No further troubleshooting is possible.

FAULT CODE D1
P3 TRANSDUCER



Fault Code D1, P3 Transducer
Figure 121

G-35 FAULT CODE D1, P3 TRANSDUCER EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 121.

Step 3. Refer to manufacturer's procedure to check line for blockage and leaks.


Step 5. Tighten fittings to torque as specified by the manufacturer.

Step 7. Refer to manufacturer's procedure for repairing/replacing P3 line.

Step 8. Refer to manufacturer's procedure for checking the water drain check valve.

Step 13. Refer to manufacturer's procedure for replacing the water drain check valve.

FAULT CODE D2
P1 TRANSDUCER



Fault Code D2, P1 Transducer
Figure 122


G-36 FAULT CODE D2, P1 TRANSDUCER EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 122.

Step 2. Check P1 cap for blockage or damage.

Step 3. Tighten cap to torque.


FAULT CODE DE
400 HZ RESOLVER REFERENCE



Fault Code DE, 400 Hz Resolver Reference
Figure 123 (Sheet 1 of 2)

FAULT CODE DE
400 HZ RESOLVER REFERENCE

(CONTINUED)



Fault Code DE, 400 Hz Resolver Reference
Figure 123 (Sheet 2 of 2)

G-37 FAULT CODE DE, 400 HZ RESOLVER REFERENCE EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 123.

- Step 2. Check harness connector PL3 (figure 201) at DECU, ECL quadrant connector and LVDT connector for tight connections.
- Step 3. Disconnect PL3, ECL quadrant and LVDT connectors to check pins and sockets.
- Step 5. With LVDT connector disconnected, check resistance of RTL sensor at sensor connector pins 1 and 2. Limit is 110 - 140Ω. Check resistance at pins 3 and 4. Limit is 210 - 260Ω. Check resistance at pins 3 and 5, and pins 4 and 5. Limit is < 230Ω.
- Step 6. With ECL quadrant connector disconnected, check resistance of ECL quadrant at quadrant pins 1 and 2. Limit is 35 - 40Ω. Check resistance at pins 3 and 4. Limit is 90 - 1 00Ω.
- Step 7. With PL3 disconnected, check resistance of ECL quadrant at harness PL3 connector sockets h and i (figure 202). Limit is 35 - 42Ω. Check resistance at sockets EE and DD. Limit is 90 - 1 00Ω. Check resistance of RTL sensor at sockets g and p. Limit is 210 - 260Ω. Check resistance of sockets z and AA. Limit is 110 - 140Ω.
- Step 8. Before tightening PL3, ECL quadrant and LVDT connectors, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 13. Refer to manufacturer's procedure for checking operation of ECL quadrant and RTL sensor.
- Step 15. Refer to manufacturer's procedure for diagnosing and replacing harness, ECL quadrant or RTL sensor.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing RTL sensor.
- Step 19. Refer to manufacturer's procedure for diagnosing and replacing ECL quadrant.
- Step 23. Refer to manufacturer's procedure for diagnosing and replacing harness.

G-37 FAULT CODE DE, 400 HZ RESOLVER REFERENCE EXPANDED INSTRUCTIONS (CONTINUED)

RESISTANCE-CHECK SUMMARY


Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
ECL Quadrant	PL3	<u>h & i</u>	<u>35 - 42</u>	-
		<u>EE & DD</u>	<u>90 - 102</u>	-
	ECL Quadrant	1 & 2	<u>35 - 40</u>	-
		3 & 4	<u>90 - 100</u>	-
RTL Sensor	PL3	<u>z & AA</u>	<u>110 - 140</u>	-
		<u>q & p</u>	<u>210 - 260</u>	-
	LVDT	1 & 2	<u>110 - 140</u>	-
		3 & 4	<u>210 - 260</u>	-
		3 & 5	< 230	-
		4 & 5	< <u>230</u>	-
*At <u>25°C</u>				-



Fault Code E1, T4.5 Sensor
Figure 124 (Sheet 1 of 2)

FAULT CODE E1
T4 5 SENSOR

(CONTINUED)



Fault Code E1, T4.5 Sensor
Figure 124 (Sheet 2 of 2)

G-38 FAULT CODE E1, T4.5 SENSOR EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 124.


- Step 3. Check harness connector PL3 (figure 201) at DECU, and J19 at T4.5 harness for tight connections.
- Step 4. Disconnect connectors PL3 and J19 to check pins and sockets.
- Step 6. With PL3 disconnected, check resistance of T4.5 sensor at harness PL3 connector sockets v and GG (figure 202). Limit is 3.5 - 20Ω.
- Step 7. To measure resistance of T4.5 thermocouple probe, disconnect one leg of probe from the bus bar. Measure resistance. Reverse polarity and measure resistance again. Average the two readings to obtain final results. (Note: An analog ohmmeter is recommended for measuring probe resistance.)
- Step 8. With PL3 and T4.5 gauge disconnected, check resistance of T4.5 harness at harness PL3 connector sockets u and a (figure 202). Limit is >1 MΩ.
- Step 9. Before tightening harness connectors PL3 and P19, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 12. With J19 disconnected, check resistance of T4.5 sensor at sensor P19 connector sockets A and B (figure 202). Limit is 3.5 - 5.5Ω.
- Step 17. Refer to airframe manufacturer's procedure for diagnosing and replacing harness.
- Step 19. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 20. Refer to manufacturer's procedure for diagnosing and replacing T4.5 sensor.
- Step 23. Refer to manufacturer's procedure for diagnosing and replacing harness or T4.5 gauge.
- Step 24. Refer to manufacturer's procedure for diagnosing and replacing harness.

G-38 FAULT CODE E1, T4.5 SENSOR EXPANDED INSTRUCTIONS (CONTINUED)

RESISTANCE-CHECK SUMMARY


Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
T4.5 Gauge Harness	PL3	<u>u</u> & <u>a</u>	>1 M	>1 M
T4.5 Sensor	PL3	<u>v</u> & GG	3.5 - 20.0	10.0
	P19	A & B	3.5 - 5.5	4.0
T4.5 Thermocouple Probe *At 25°C	-	-	≥ 4.0	-

FAULT CODE E2
T1 SENSOR



Fault Code E2, T1 Sensor
Figure 125 (Sheet 1 of 2)

FAULT CODE E2
T1 SENSOR



Fault Code E2, T1 Sensor
Figure 125 (Sheet 2 of 2)

G-39 FAULT CODE E2, T1 SENSOR EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 125.


- Step 2. Check harness connector PL3 (figure 201) at DECU, and P10 at T1 sensor for tight connections.
- Step 3. Disconnect connectors PL3 and P10 to check pins and sockets.
- Step 5. With PL3 disconnected, check resistance of T1 sensor at harness PL3 connector sockets r and t (figure 202), and s and t. Limit in each case is 356 - 637Ω.
- Step 6. Refer to the T12 Temp vs. Resistance graph to determine the expected resistance for the ambient temperature.
- Step 7. Before tightening harness connectors PL3 and P10, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 10. With P10 disconnected, check resistance of T1 sensor at T1 sensor J10 connector pins C and A (figure 202), and B and A. Limit in each case is 356 - 637Ω.
- Step 14. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 15. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing T1 sensor.

RESISTANCE-CHECK SUMMARY


Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
T1 Sensor	PL3	<u>r & t</u>	<u>356 - 637</u>	<u>549</u>
		<u>s & t</u>	<u>356 - 637</u>	<u>549</u>
	J10	<u>C & A</u>	<u>356 - 637</u>	<u>549</u>
		<u>B & A</u>	<u>356 - 637</u>	<u>549</u>

*At 25°C

G-39 FAULT CODE E2, T1 SENSOR EXPANDED INSTRUCTIONS (CONTINUED)




FAULT CODE E3
N2A SENSOR



Fault Code E3, N2A Sensor
Figure 126 (Sheet 1 of 2)

FAULT CODE E3
N2A SENSOR



Fault Code E3, N2A Sensor
Figure 126 (Sheet 2 of 2)

G-40 FAULT CODE E3, N2A SENSOR EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 126.

- Step 2. Check harness connector PL1 (figure 201) at DECU, and P7 at N2A sensor for tight connections.
- Step 3. Disconnect connectors PL1 and P7 to check pins and sockets.
- Step 5. With PL1 disconnected, check resistance of N2A sensor at harness PL1 connector sockets BB and m (figure 202). Limit is 10.0 - 45.5Ω.
- Step 6. With P7 disconnected, check resistance of N2A sensor at N2A sensor J7 connector pins 1 and 2 (figure 202). Limit is 10.0 - 45.5Ω
- Step 7. Before tightening harness connectors PL1 and P7, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 10. Refer to manufacturer's procedure for checking operation of N2 pickup, wheel and drive pad.
- Step 11. Refer to manufacturer's procedure for checking operation of N2 pickup, wheel and drive pad.
- Step 13. Refer to manufacturer's procedure for diagnosing and replacing harness or N2A sensor.
- Step 16. Refer to manufacturer's procedure for diagnosing and replacing N2 components.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 18. Refer to manufacturer's procedure for diagnosing and replacing N2A sensor.
- Step 21. Refer to manufacturer's procedure for diagnosing and replacing N2 components.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
N2A Sensor	PL1	BB & <u>m</u>	<u>10.0 - 45.5</u>	<u>25.5</u>
	J7	1 & 2	<u>10.0 - 45.5</u>	<u>25.5</u>
At <u>25°C</u>				


FAULT CODE E4
N2B SENSOR



Fault Code E4, N2B Sensor
Figure 127 (Sheet 1 of 2)

FAULT CODE E4
N2B SENSOR

(CONTINUED)



Fault Code E4, N2B Sensor
Figure 127 (Sheet 2 of 2)

G-41 FAULT CODE E4, N2B SENSOR EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 127.

- Step 2. Check harness connector PL3 (figure 201) at DECU, and P8 at N2B sensor for tight connections.
- Step 3. Disconnect connectors PL3 and P8 to check pins and sockets.
- Step 5. With PL3 disconnected, check resistance of N2B sensor at harness PL3 connector sockets B and d (figure 202). Limit is 10.0 - 45.5Ω.
- Step 6. With P8 disconnected, check resistance of N2B sensor at sensor J8 connector pins 1 and 2 (figure 202). Limit is 10.0 - 45.5Ω.
- Step 7. Before tightening harness connectors PL3 and P8, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 10. Refer to manufacturer's procedure for checking operation of N2 pickup, wheel and drive pad.
- Step 11. Refer to manufacturer's procedure for checking operation of N2 pickup, wheel and drive pad.
- Step 13. Refer to manufacturer's procedure for diagnosing and replacing harness or N2B sensor.
- Step 16. Refer to manufacturer's procedure for diagnosing and replacing N2 components.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 18. Refer to manufacturer's procedure for diagnosing and replacing N2B sensor.
- Step 21. Refer to manufacturer's procedure for diagnosing and replacing N2 components.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
N2B Sensor	PL3	B & d	<u>10.0 - 45.5</u>	<u>25.5</u>
	J8	1 & 2	<u>10.0 - 45.5</u>	<u>25.5</u>
At <u>25°C</u>				


FAULT CODE E5,
N2A/N2B DIFFERENCE



Fault Code E5, N2A/N2B Sensor
Figure 128 (Sheet 1 of 2)

FAULT CODE E5,
N2A/N2B DIFFERENCE

(CONTINUED)



Fault Code E5, N2A/N2B Sensor
Figure 128 (Sheet 2 of 2)

G-42 FAULT CODE E5, N2A/N2B SENSOR EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 128.


- Step 4. Check harness connector PL1 and PL3 (figure 201) at DECU, P7 at N2A sensor and P8 at N2B sensor for tight connections.
- Step 5. Disconnect connectors PL1, PL3, P7 and P8 to check pins and sockets.
- Step 7. With PL3 disconnected, check resistance of N2A sensor at harness PL1 connector sockets B and m (figure 202). With PL3 disconnected, check resistance of N2B sensor at harness PL3 connector sockets B and m. In each case, limit is 10.0 - 45.5Ω.
- Step 8. With P7 disconnected, check resistance of N2A sensor at sensor J7 connector pins 1 and 2. With P8 disconnected, check resistance of N2B sensor at sensor J8 connector pins 1 and 2. In each case limit is 10.0 - 45.5Ω.
- Step 9. Before tightening harness connectors PL1, PL3, P7 and P8, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 10. Refer to manufacturer's procedure for checking operation of N2 pickup, wheel and drive pad.
- Step 13. Refer to manufacturer's procedure for checking operation of N2 pickup, wheel and drive pad.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness or N2A and N2B sensor.
- Step 20. Refer to manufacturer's procedure for diagnosing and replacing N2 components.
- Step 21. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 22. Refer to manufacturer's procedure for diagnosing and replacing N2A or N2B sensor.
- Step 25. Refer to manufacturer's procedure for diagnosing and replacing N2 components.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
N2A Sensor	PL1	B & m	<u>10.0 - 45.5</u>	<u>25.5</u>
	J7	1 & 2	<u>10.0 - 45.5</u>	<u>25.5</u>
N2B Sensor	PL3	B & d	<u>10.0 - 45.5</u>	<u>25.5</u>
	J8	1 & 2	<u>10.0 - 45.5</u>	<u>25.5</u>

At 25°C

FAULT CODES C1-C3, C5-C8
COMMUNICATION LINE FAULTS



Fault Codes C1-C3, C5-C8, Communication Line Faults
Figure 129

G-43 FAULT CODES C1-C3, C5-C8, COMMUNICATION LINE FAULTS EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 129.

- Step 2. Check harness connector PL1 (figure 201) at each DECU for tight connection.
- Step 3. Disconnect connector PL1 at each DECU to check pins and sockets.
- Step 4. With PL1 disconnected at both DECUs, check the resistance of the harness between the two DECUs at the following pins:

<u>DECU #1</u>	<u>DECU #2</u>
C	<u>e</u>
D	<u>d</u>
<u>c</u>	<u>x</u>
<u>d</u>	D
<u>e</u>	C
<u>x</u>	<u>c</u>


Limit in each case is < 1Ω.

- Step 6. Before tightening harness connector PL1 at each DECU, be sure that keyway in harness connector is aligned with keyway in component connector.
- Step 11. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 13. Refer to manufacturer's procedure for diagnosing and replacing harness.

RESISTANCE-CHECK SUMMARY

Component	Connector				Resistance Limits (Ω)
	DECU #1		DECU #2		
	No.	Contact	No.	Contact	
Harness	PL1	C	PL1	<u>e</u>	< 1
	PL1	D	PL1	<u>d</u>	< 1
	PL1	<u>c</u>	PL1	<u>x</u>	< 1
	PL1	<u>d</u>	PL1	D	< 1
	PL1	<u>e</u>	PL	C	< 1
	PL1	<u>x</u>	PL1	<u>c</u>	< 1

FAULT CODE C4
COMMUNICATION LINE FAULT



Fault Code C4, Communication Line Fault
Figure 130

G-44 FAULT CODES C4, COMMUNICATION LINE FAULT Q (O) SIGNAL EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 130.

Step 2. Check harness connector PL1 (figure 201) at each DECU for tight connection.

Step 3. Disconnect connector PL1 at each DECU to check pins and sockets.

Step 4. With PL1 disconnected at both DECUs, check the resistance between the two DECUs at the following harness PL1 sockets:

<u>DECU #1</u>	<u>DECU #2</u>
C	<u>e</u>
D	<u>d</u>
<u>c</u>	<u>x</u>
<u>d</u>	D
<u>e</u>	C
<u>x</u>	<u>c</u>
Limit in each case is < 1.	-

Step 6. Before tightening harness connector PL1 at each DECU, be sure that keyway in harness connector is aligned with keyway in component connector.


Step 11. Refer to manufacturer's procedure for diagnosing and replacing harness.

Step 13. Refer to manufacturer's procedure for diagnosing and replacing harness.

RESISTANCE-CHECK SUMMARY

Component	Connector				Resistance Limits (Ω)
	DECU #1		DECU #2		
	No.	Contact	No.	Contact	
Harness	PL1	C	PL1	<u>e</u>	< <u>1</u>
	PL1	D	PL1	<u>d</u>	< <u>1</u>
	PL1	<u>c</u>	PL1	<u>x</u>	< <u>1</u>
	PL1	<u>d</u>	PL1	D	< <u>1</u>
	PL1	<u>e</u>	PL	C	< <u>1</u>
	PL1	<u>x</u>	PL1	<u>c</u>	< <u>1</u>

FAULT CODE C9,
N1B (0) SENSOR SIGNALS FROM OTHER DECU



Fault Code C9, N1B (0) Sensor Signals From Other DECU
Figure 131

G-45 FAULT CODE C9, N1B (O) SENSOR SIGNALS FROM OTHER DECU EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 131.

Step 3. Check harness connector PL1 (figure 201) at each DECU for tight connection.

Step 4. Disconnect connector PL1 at each DECU to check pins and sockets.

Step 5. With PL1 disconnected at both DECUs, check the resistance between the two DECUs at the following harness PL1 sockets:

<u>DECU #1</u>	<u>DECU #2</u>
a	GG
b	NN
GG	a
NN	b
Limit in each case < 1 Ω	—

Step 7. Before tightening harness connector PL1 at each DECU, be sure that keyway in harness connector is aligned with keyway in component connector.

Step 12. Refer to manufacturer's procedure for diagnosing and replacing harness.'

Step 14. Refer to manufacturer's procedure for diagnosing and replacing harness.

RESISTANCE-CHECK SUMMARY

Component	Connector				Resistance Limits (Ω)
	DECU #1		DECU #2		
	No.	Contact	No.	Contact	
Harness	PL1	a	PL1	GG	< 1
	PL1	b	PL1	NN	< 1
	PL1	GG	PL1	a	< 1
	PL1	NN	PL1	b	< 1

FAULT CODE CF
LOSS OF LOAD SHARE SIGNALS

1	NOTE OTHER FAULT CODES ON DECU #1 AND DECU #2. FOLLOW FAULT ISOLATION PROCEDURES FOR THESE FAULT CODES
---	--


Fault Code CF, Loss of Load Share Signals
Figure 132

G-46 FAULT CODE CF, LOSS OF LOAD SHARE SIGNALS EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 132.


Step 1. In combination with a CF fault code there must exist both an engine torque signal and an N1 speed signal fault code on either or both DECU's. Fault isolation procedures should continue normally using the directions specified for these fault codes.

FAULT CODE B2
N1B SENSOR



Fault Code B2, N1B Sensor
Figure 133 (Sheet 1 of 2)

FAULT CODE B2
N1B SENSOR



*Fault Code B2, N1B Sensor
Figure 133 (Sheet 2 of 2)*

G-47 FAULT CODE B2, N1B SENSOR EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 133.


- Step 4. Check harness connector PL3 (figure 201) at DECU, and P6 at HMA.. for tight connections.
- Step 5. Disconnect connectors PL3 and P6 to check pins and sockets.
- Step 8. With PL3 disconnected, check resistance of HMA (N1B sensor) at harness PL3 connector sockets A and c (figure 202). Limit is 0.3 - 3.5Ω
- Step 9. With P6 disconnected, check resistance of HMA (N1 B sensor) at HMA J6 connector pins E and F. Limit is 0.3 - 3.0Ω..
- Step 10. Before tightening harness connectors PL3 and P6, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 13. Refer to manufacturer's procedure for checking drive pad and spline.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 20. Refer to manufacturer's procedure for replacing drive pad or spline.
- Step 22. Refer to manufacturer's procedure for diagnosing and replacing harness.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No	Contacts	Limits	Nominal *
HMA – N1B Sensor	PL3	A & c	<u>0.3 – 3.5</u>	<u>0.7</u>
	J6	E & F	<u>0.3 – 3.0</u>	<u>0.7</u>


*At 25°C

FAULT CODE B3
N2B SENSOR



Fault Code B3, N2B Sensor
Figure 134 (Sheet 1 of 2)

FAULT CODE B3
N2B SENSOR



Fault Code B3, N2B Sensor
Figure 134 (Sheet 2 of 2)

G-48 FAULT CODE B3, N2B SENSOR EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 134.

- Step 4. Check harness connector PL3 (figure 201) at DECU, and P8 at N2B sensor for tight connections.
- Step 5. Disconnect connectors PL3 and P8 to check pins and sockets.
- Step 7. With PL3 disconnected, check resistance of N2B sensor at harness PL3 connector sockets B and d. (figure 202). Limit is 10.0 - 45.5Ω.
- Step 8. With P8 disconnected, check resistance of N2B sensor at sensor J8 connector pins 1 and 2. Limit is 10.0 - 45.0Ω.
- Step 9. Before tightening harness connectors PL3 and P8, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 12. Refer to manufacturer's procedure for checking operation of N2 pickup, wheel and drive pad.
- Step 13. Refer to manufacturer's procedure for checking operation of N2 pickup, wheel and drive pad.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness or N2B sensor.
- Step 20. Refer to manufacturer's procedure for replacing N2 components.
- Step 21. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 22. Refer to manufacturer's procedure for diagnosing and replacing N2B sensor.
- Step 25. Refer to manufacturer's procedure for replacing N2 components.

RESISTANCE-CHECK SUMMARY


Component	Connector		Resistance (Ω)	
	No	Contacts	Limits	Nominal *
N2B Sensor	PL3	B & d	<u>10.0 - 45.5</u>	<u>25.5</u>
	J8	1 & 2	<u>10.0 - 45.0</u>	<u>25.5</u>
*At 25°C				

FAULT CODE B4
T4.5 SENSOR



Fault Code B4, T4.5 Sensor
Figure 135 (Sheet 1 of 2)

FAULT CODE B4
T4.5 SENSOR



Fault Code B4, T4.5 Sensor
Figure 135 (Sheet 2 of 2)

G-49 FAULT CODE B4, T4.5 SENSOR EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 135.

- Step 3. Check harness connector PL3 (figure 201) at DECU, and J19 at T4.5 harness for tight connections.
- Step 4. Disconnect connectors PL3 and J19 to check pins and sockets.
- Step 6. With PL3 disconnected, check resistance of T4.5 sensor at harness PL3 connector sockets v and GG (figure 202). Limit is 3.5 - 20.0Ω.
- Step 7. To measure resistance of T4.5 thermocouple probe, disconnect one leg of probe from the bus bar. Measure resistance. Reverse polarity and measure resistance again. Average the two readings to obtain final results. (Note: An analog ohmmeter is recommended for measuring probe resistance.)
- Step 8. With PL3 and T4.5 gauge disconnected, check resistance of T4.5 harness at harness connector sockets v and a (figure 202). Limit is > 1MΩ.
- Step 9. Before tightening harness connectors PL3 and P19, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 12. With J19 disconnected, check resistance of T4.5 sensor at sensor P19 connector sockets A and B (figure 202). Limit is 3.5 - 5.5Ω.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 19. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 20. Refer to manufacturer's procedure for diagnosing and replacing T4.5 sensor.
- Step 23. Refer to manufacturer's procedure for diagnosing and replacing harness or T4.5 gauge.
- Step 24. Refer to manufacturer's procedure for diagnosing and replacing harness.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No	Contacts	Limits	Nominal *
T4.5 Gauge Harness	PL3	<u>v</u> & <u>a</u>	> <u>1MΩ</u>	> <u>1MΩ</u>
T4.5 Sensor	PL3	<u>v</u> & GG	<u>3.5 - 20.0</u>	<u>10.0</u>
	P19	A & B	<u>3.5 - 5.5</u>	<u>4.0</u>
T4.5 Thermocouple Probe *At 25°C	-	-	< <u>4.0</u>	-

FAULT CODE B5
COLLECTIVE PITCH ANGLE LVDT




(CONTINUED)

*Fault Code B5, Collective Pitch Angle LVDT
Figure 136 (Sheet 1 of 2)*

FAULT CODE B5
COLLECTIVE PITCH ANGLE LVDT

(CONTINUED)



Fault Code B5, Collective Pitch Angle LVDT
Figure 136 (Sheet 2 of 2)

G-50 FAULT CODE B5, COLLECTIVE PITCH ANGLE LVDT EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 136.

- Step 4. Check harness connector PL3 (figure 201) at DECU and LVDT connector for tight connections.
- Step 5. Disconnect connector PL3 and LVDT connector to check pins and sockets.
- Step 7. With LVDT connector disconnected, check resistance of RTL sensor at sensor connector pins 1 and 2. Limit is 110 - 140Ω. Check resistance at pins 3 and 4. Limit is 210 - 260Ω. Check resistance at pins 3 and 5, and pins 4 and 5. Limit is <230Ω.
- Step 8. Before tightening harness connector PL3 and LVDT connector, be sure that keyway in harness connectors are aligned with keyways in component connectors.
- Step 11. With PL3 disconnected, check resistance of RTL sensor at harness PL3 connector sockets q and p (figure 202). Limit is 220 - 260Ω. Check resistance at sockets z and AA. Limit is 110 - 140Ω.
- Step 12. Refer to manufacturer's procedure for checking RTL sensor operation.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness or RTL sensor.
- Step 19. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 21. Refer to manufacturer's procedure for replacing RTL sensor.

RESISTANCE-CHECK SUMMARY


Component	Connector		Resistance (Ω)	
	No	Contacts	Limits	Nominal *
RTL Sensor (C/P Signal)	LVDT	3 & 4	<u>210 - 260</u>	<u>225</u>
		3 & 5	<u>< 230</u>	-
		4 & 5	<u>< 230</u>	
RTL Sensor (C/P Excitation)	PL3	q & p	<u>210 - 260</u>	<u>225</u>
		z & AA	<u>110 - 140</u>	<u>120</u>
*At <u>25°C</u>				

FAULT CODE B6
ECL RESOLVER



Fault Code B6, ECL Resolver
Figure 137 (Sheet 1 of 2)

FAULT CODE B6
ECL RESOLVER



Fault Code B6. ECL Resolver
Figure 137 (Sheet 2 of 2)

G-51 FAULT CODE B6, ECL RESOLVER EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 137.

- Step 4. Check harness connector PL3 (figure 201) at DECU, and connector at ECL quadrant for tight connections.
- Step 5. Disconnect PL3 and ECL quadrant connectors to check pins and sockets.
- Step 7. Set ECL to STOP. With PL3 disconnected, check resistance of ECL quadrant (excitation) at harness PL3 connector sockets h and i (figure 202). Limit is 35 - 42Ω. Check resistance of ECL quadrant (signal) at sockets EE and DD. Limit is 90-102Ω. Monitor resistance of ECL quadrant (interlock discrete) at sockets f and LL while moving ECL from STOP to GROUND to FLIGHT. Limits are defined in table below. Monitor resistance of ECL quadrant (gain discrete) at sockets MM and LL while moving ECL from STOP to GROUND to FLIGHT. Limits are as defined in table below. (Note: Gain discrete resistance is not checked at GROUND because switch can be open or closed at that point.)
- Step 8. Set ECL to STOP. With ECL quadrant connector disconnected, check resistance of ECL quadrant (excitation) at quadrant pins 1 and 2. Limit is 35-40Ω. Check resistance of ECL quadrant (signal) at quadrant pins 3 and 4. Limit is 90 -1 00Ω. Monitor resistance of ECL quadrant (interlock discrete) at pins 11 and 12 while moving ECL from STOP to GROUND to FLIGHT. Limits are as defined in table below. Monitor resistance of ECL quadrant (gain discrete) at pins 5 and 11 while moving ECL from STOP to GROUND to FLIGHT. Limits are as defined in table below. (Note: discrete resistance is not checked at GROUND because switch can be open or closed at that point.)
- Gain
- Step 9. Before tightening harness connector PL3 and connector at ECL resolver, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 12. Refer to manufacturer's procedure for checking operation of ECL quadrant.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness or ECL quadrant.
- Step 20. Refer to manufacturer's procedure replacing ECL quadrant.
- Step 21. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 22. Refer to manufacturer's procedure for diagnosing and replacing ECL quadrant.


G-51 FAULT CODE B6, ECL RESOLVER EXPANDED INSTRUCTIONS(CONTINUED)

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No	Contacts	Limits	Nominal *
ECL Quadrant – Excitation	PL3	h & i	35 – 42	–
	ECL Quadrant	1 & 2	35 – 40	–
ECL Quadrant – Signal	PL3	EE & DD	90 – 102	–
	ECL Quadrant	3 & 4	90 – 100	–
ECL Quadrant – Interlock Discrete	PL3	f & LL	> 150K	∞
ECL at STOP		f & LL	< 50	1
ECL between STOP and GROUND		f & LL	> 150K	∞
ECL at GROUND		f & LL	< 50	1
ECL between GROUND and FLIGHT		f & LL	> 150K	∞
ECL at FLIGHT	ECL Quadrant	12 & 11	> 150K	∞
ECL at STOP		12 & 11	< 50	1
ECL between STOP and GROUND		12 & 11	> 150K	∞
ECL at GROUND		12 & 11	< 50	1
ECL between GROUND and FLIGHT		12 & 11	> 150K	∞
ECL at FLIGHT	PL3	MM & LL	< 50	1
ECL at STOP		MM & LL	< 50	1
ECL between STOP and GROUND		MM & LL	> 150K	∞
ECL between GROUND and FLIGHT		MM & LL	> 150K	∞
ECL at FLIGHT	ECL Quadrant	5 & 11	< 50	1
ECL at STOP		5 & 11	< 50	1
ECL between STOP and GROUND		5 & 11	> 150K	∞
ECL between GROUND and FLIGHT		5 & 11	> 150K	∞
ECL at FLIGHT				

*At 25°C


FAULT CODE B7
PLA POTENTIOMETER



Fault Code B7, PLA Potentiometer
Figure 138 (Sheet 1 of 2)

FAULT CODE B7
PLA POTENTIOMETER

(CONTINUED)



Fault Code B7, PLA Potentiometer
Figure 138 (Sheet 2 of 2)

G-52 FAULT CODE B7, PLA POTENTIOMETER EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 138.

Step 4. Check harness connector PL3 (figure 201) at DECU, and P4 at HMA for tight connections.

Step 5. Disconnect connectors PL3 and P4 to check pins and sockets.

Step 7. CAUTION: DO NOT USE AN OHMMETER THAT CAN APPLY MORE THAN 5 mA WHEN MEASURING RESISTANCES, TO AVOID DAMAGING THE PLA POTENTIOMETER

With PL3 disconnected, check resistance of HMA (PLA potentiometer) at harness PL3 connector sockets U and T (results are "a") and T and S (results are "b"). Limit for "a" and "b" is 510-5750Ω. Check resistance at sockets U and S (results are "c"). Limit for "c" is 4250-5750Ω. Use the following equation to check wiper resistance:

$$a + b - c \div 2 = d$$

Limit for "d" is $\leq 300\Omega$. Use the following equation to check if the high or low limit of the PLA potentiometer has been exceeded:

$$b - d \div c = e$$

Limit for "e" is 0.120 - 0.950.

Step 8. CAUTION: DO NOT USE AN OHMMETER THAT CAN APPLY MORE THAN 5 mA WHEN MEASURING RESISTANCES, TO AVOID DAMAGING THE PLA POTENTIOMETER.

With P4 disconnected, check resistance of HMA (PLA potentiometer) at HMA J4 connector pins X and Y (results are "f") and Y and Z (results are "g"). Limit for "f" and "g" is 510 - 5750Ω. Check resistance at pins X and Z (results are "h"). Limit for "h" is 4250 - 5750Ω. Use the following equation to check wiper resistance.

equation

$$f + g - h \div 2 = i$$

Limit for "i" is $\leq 300\Omega$. Use the following equation to check if the high or low limit of the PLA potentiometer has been exceeded:

$$g - i \div h = j$$

Limit for "j" is 0.120 - 0.950.

Step 9. Before tightening harness connectors PL3 and P4, be sure that keyways in harness connectors are aligned with keyways in component connectors.

Step 15. Refer to manufacturer's procedure for diagnosing and replacing harness.

Step 20. Refer to manufacturer's procedure for diagnosing and replacing harness.

G-52 FAULT CODE B7, PLA POTENTIOMETER EXPANDED INSTRUCTIONS(CONTINUED)

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No	Contacts	Limits	Nominal *
HMA - PLA Potentiometer	PL3	U & T (a)	510 - 5750	**
		T & S (b)	510 - 5750	**
		U & S (c)	4250 - 5750	5000
		a + b - c - 2 (d)	≤ 300	195
		b - d - c (e)	0 120 - 0 950	**
	J4	X & Y (f)	510 - 5750	**
		Y & Z (g)	510 - 5750	**
		X & Z (h)	4250-5750	5000
		f + g - h - 2 (i)	≤ 300	195
		g - i - h (j)	0 120 - 0 950	**

* At 25°C
 ** Dependent on PLA Position

FAULT CODES B9 COLD JUNCTION COMPENSATION
 BA REVERSIONARY +28V
 BB REVERSIONARY T4 5 CALIBRATION

1	TURN DECU POWER OFF REPLACE DECU
---	-------------------------------------


**Fault Codes B9, BA, BB, Internal DECU Faults
 Figure 139**

G-53 FAULT CODES B9, BA, BB, INTERNAL DECU FAULTS EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 139.

These codes indicate internal DECU problems. No further troubleshooting is possible.

**FAULT CODE BC
400 Hz RESOLVER REFERENCE**



**Fault Code BC, 400 Hz Resolver Reference
Figure 140**

G-54 FAULT CODE BC, 400 Hz RESOLVER REFERENCE EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 140.

- Step 1. Cycle DECU power to determine if fault is due to a DECU problem or was caused by an interrupt to both reversionary power supplies.
- Step 3. An internal DECU fault exists. No further troubleshooting is possible.

FAULT CODES	10	MICROPROCESSOR
	11	NVM CHECKSUM
	12	NVM ENGINE HISTORY
	13	NVM FAULT DATA
	14	NVM ACCUMULATED FAULT DATA
	15	NVM WRITE TEST
	16	NVM STORAGE INCOMPLETE
	17	NVM HISTORY DATA INCONSISTENT
	18	MINOR CYCLE NOT COMPLETED
	1B	EMS CYCLE NOT COMPLETED
	1C	A/D CONVERSION NOT COMPLETED
	1E	RAM FAILURE
	1F	Op CODE ERROR

1 | REPLACE DECU

**Fault Codes 10-1 F, Internal DECU Faults
Figure 141**

G-55 FAULT CODES 10-1F, INTERNAL DECU FAULTS EXPANDED INSTRUCTIONS

With power to DECU and before starting engine, if code "10" or "10 and 1F" are displayed, refer to figure 141A.

For all other faults or combinations, refer to numbered steps in figure 141.

These codes indicate internal DECU problems. No further troubleshooting is possible.






Figure 141a. Procedure to Clear Fault code "10" and/or "1F" Before Engine Start

FAULT CODE - NONE
 UNABLE TO SWITCH TO REVERSIONARY MODE



Unable to Switch to Reversionary Mode (Sheet 1 of 2)
 Figure 142

FAULT CODE - NONE
UNABLE TO SWITCH TO REVERSIONARY MODE



Unable to Switch to Reversionary Mode (Sheet 2 of 2)
Figure 142

G-56 UNABLE TO SWITCH TO REVERSIONARY MODE EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 142.


- Step 2. Check harness connector PL3 (figure 201) at DECU for tight connection.
- Step 3. Disconnect connectors PL3 to check pins and sockets.
- Step 5. With PL3 disconnected and primary mode selected, check resistance of primary/reversionary switch at harness PL3 connector sockets x and e (figure 202). Limit is >150KΩ. With reversionary mode selected, check resistance again. Limit is <50Ω.
- Step 6. Before tightening harness connectors PL3, be sure that keyway in harness connector is aligned with keyway in component connector.
- Step 10. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 12. Refer to manufacturer's procedure for diagnosing and replacing switch or harness.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No	Contacts	Limits	Nominal *
Cockpit Primary/Reversionary Switch Primary	PL3	x & e	> <u>150K</u>	∞
Reversionary	PL3	x & e	< <u>50</u>	1

*At 25°C


FAULT CODE - NONE
UNABLE TO SWITCH TO PRIMARY MODE



Unable to Switch to Primary Mode (Sheet 1 of 2)
Figure 143

FAULT CODE - NONE
UNABLE TO SWITCH TO PRIMARY MODE

(CONTINUED)



Unable to Switch to Primary Mode (Sheet 2 of 2)
Figure 143

G-57 UNABLE TO SWITCH TO PRIMARY MODE EXPANDED INSTRUCTIONS


Refer to numbered steps in figure 143.

- Step 2.. Check harness connector PL3 (figure 201) at DECU for tight connection.
- Step 3. Disconnect connector PL3 to check pins and sockets.
- Step 5. With PL3 disconnected and primary mode selected, check resistance of primary/reversionary switch at harness PL3 connector sockets x and e (figure 202). Limit is >150KW. With reversionary mode selected, check resistance again. Limit is <50W.
- Step 6. Before tightening harness connector PL3, be sure that keyway in harness connector is aligned with keyway in component connector.
- Step 10. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 12. Refer to manufacturer's procedure for diagnosing and replacing switch or harness.

RESISTANCE-CHECK SUMMARY


Component	Connector		Resistance (Ω)	
	No	Contacts	Limits	Nominal *
Cockpit Primary/Reversionary Switch Primary	PL3	x & e	> 150K	∞
Reversionary * At 25°C	PL3	x & e	< 50	1

FAULT CODE - NONE
 SYSTEM TOGGLES BETWEEN PRIMARY AND REVERSIONARY MODE



System Toggles Between Primary and Reversionary Mode
 Figure 144 (Sheet 1 of 2)

FAULT CODE - NONE
 SYSTEM TOGGLE BETWEEN PRIMARY AND REVERSIONARY MODE



System Toggles Between Primary and Reversionary Mode
 Figure 144 (Sheet 2 of 2)

G-58 SYSTEM TOGGLES BETWEEN PRIMARY AND REVERSIONARY MODE EXPANDED INSTRUCTIONS
--

Refer to numbered steps in figure 144.


- Step 2. Check harness connector PL3 (figure 201) at DECU for tight connection.
- Step 3. Disconnect connector PL3 to check pins and sockets.
- Step 5. With PL3 disconnected and primary mode selected, check resistance of primary/reversionary switch at harness PL3 connector sockets x and e (figure 202). Limit is $\geq 150K\Omega$. With reversionary mode selected, check resistance again. Limit is $< 50\Omega$.
- Step 6. Before tightening harness connector PL3, be sure that keyway in harness connector is aligned with keyway in component connector.
- Step 10. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 12. Refer to manufacturer's procedure for diagnosing and replacing switch or harness.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal*
Cockpit Primary/Reversionary Switch Primary	PL3	<u>x</u> & <u>e</u>	>150K	∞
Reversionary	PL3	<u>x</u> & <u>e</u>	< <u>50</u>	1


*At 25°C

FAULT CODE - NONE
Q LOAD SHARE SELECTED, Qs NOT MATCHED



Q Load Share Selected, Qs Not Matched
Figure 145 (Sheet 1 of 2)

FAULT CODE - NONE
 Q LOAD SHARE SELECTED, Qs NOT MATCHED



Q Load Share Selected, Qs Not Matched
 Figure 145 (Sheet 2 of 2)

G-59	Q LOAD SHARE SELECTED, Qs NOT MATCHED EXPANDED INSTRUCTIONS
-------------	--

Refer to numbered steps in figure 145.


- Step 2. Check harness connector PL1 (figure 201) at each DECU and P2 at each signal conditioner for tight connection.
- Step 3. At each DECU and signal conditioner, disconnect connectors PL1 and P2 to check pins and sockets.
- Step 5. At each DECU, with PL1 disconnected and load share switch in Q position, check resistance of load share switch at harness PL1 connector sockets L and j. (figure 202). Limit is $<50\Omega$. Check resistance at sockets M and i. Limit is $>150K\Omega$. With load share switch in T4.5 position, check resistance at sockets L and j. Limit is $>150K\Omega$. Check resistance at sockets M and j. Limit is $<50\Omega$. With load share switch in N1 position, check resistance at sockets L and i. and M and j. In each case, limit is $\leq 150K\Omega$.
- Step 6. Before tightening harness connectors PL1 and P2, be sure that keyway in harness connector is aligned with keyway in component connector.
- Step 10. Swap DECU locations on engines, such that DECU #1 is on engine #2, and DECU #2 is on engine #1. Compare Q mismatch to determine if the engine with lower Q is the same engine that had lower Q before the swap.
- Step 13. Refer to manufacturer's procedure for diagnosing and replacing harness and signal conditioner.
- Step 15. Refer to manufacturer's procedure for diagnosing and replacing harness or switch.
- Step 17. Swap DECU locations on engines, such that DECU #1 is on engine #1, and DECU #2 is on engine #2. Refer to manufacturer's procedure for diagnosing and replacing signal conditioner.
- Step 18. Return DECU #2 to engine #2. Install replacement DECU on engine #1.

G-59 Q LOAD SHARE SELECTED, Qs NOT MATCHED EXPANDED INSTRUCTIONS(CONTINUED)
--

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal
Load Share Switch	PL1	L &	< <u>50</u>	<u>1</u>
Q Position		M &j	> <u>150K</u>	∞
Load Share Switch -	PL1	L & j	> <u>150K</u>	∞
T4.5 Position		M & j	< <u>50</u>	<u>1</u>
Load Share Switch	PL1	L & j	> <u>150K</u>	∞
N1 Position *At <u>25°C</u>		M &j	> <u>150K</u>	∞


FAULT CODE - NONE
 T4.5 LOAD SHARE SELECTED, T4.5s NOT MATCHED



(CONTINUED)

T4.5 Load Share Selected. T4.5s Not Matched
 Figure 146 (Sheet 1 of 2)

FAULT CODE - NONE
 T4.5 LOAD SHARE SELECTED, T4.5s NOT MATCHED
 (CONTINUED)



T4.5 Load Share Selected, T4.5s Not Matched
 Figure 146 (Sheet 2 of 2)

G-60	T4.5 LOAD SHARE SELECTED, T4.5s NOT MATCHED EXPANDED INSTRUCTIONS
-------------	--

Refer to numbered steps in figure 146.


- Step 1. Refer to manufacturer's procedure to check for power limiting.
- Step 3. Check harness connectors PL1 and PL3 (figure 201) at each DECU, and J19 at each T4.5 harness for tight connections.
- Step 4. At each DECU and T4.5 harness, disconnect connectors PL1, PL3 and J19 to check pins and sockets.
- Step 5. Refer to manufacturer's procedure for checking operation and accuracy of T4.5 gauge and harness assemblies.
- Step 7. At each DECU, with PL1 disconnected and load share switch in Q position, check resistance of load share switch at harness PL1 connector sockets L and j. (figure 202). Limit is $\leq 50\Omega$. Check resistance at sockets M and j. Limit is $> 150K\Omega$. With load share switch in T4.5 position, check resistance at sockets L and j. Limit is $> 150K\Omega$. Check resistance at sockets M and j. Limit is $\leq 50\Omega$. With load share switch in N1 position, check resistance at sockets L and i., and M and j. In each case, limit is $\leq 50K\Omega$.
- Step 8. Before tightening harness connectors PL1, PL3 and J19, be sure that keyway in harness connectors are aligned with keyways in component connectors.
- Step 14. Refer to manufacturer's procedure for diagnosing and repairing engine.
- Step 16. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 20. Refer to manufacturer's procedure for diagnosing and replacing switch or harness.
- Step 22. Refer to manufacturer's procedure for diagnosing and replacing harness or T4.5 gauge.

G-60	T4.5 LOAD SHARE SELECTED, T4.5S NOT MATCHED EXPANDED INSTRUCTIONS (CONTINUED)
-------------	--

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal *
Load Share Switch Q Position	PL1	L & j M & j	< <u>50</u> > <u>150K</u>	<u>1</u> ∞
Load Share Switch	PL1	L & j	> <u>150K</u>	∞
T4.5 Position		M & j	< <u>50</u>	<u>1</u>
Load Share Switch	PL1	L & j	> <u>150K</u>	∞
N1 Position *At 25°C		M & j	> <u>150K</u>	∞

FAULT CODE - NONE
IGNITION REPLAY DOES NOT FUNCTIN



Ignition Relay Does Not Function
Figure 147

G-61 IGNITION RELAY DOES NOT FUNCTION EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 147.


- Step 2. Check harness connector PL1 (figure 201) at DECU for tight connections.
- Step 3. Disconnect harness connector PL1 to check pins and sockets.
- Step 5. With PL1 disconnected, check resistance of ignition relay at harness PL1 connector sockets n and p (figure 202). Limit is 190 - 430Ω.
- Step 6. Before tightening harness connector PL1, be sure that keyway in harness connector is aligned with keyway in component connector.
- Step 9. Refer to manufacturer's procedure for checking operation of ignition relay.
- Step 12. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 15. Refer to manufacturer's procedure for replacing ignition relay.
- Step 16. Refer to manufacturer's procedure for diagnosing and replacing harness or relay.

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal
Ignition Relay	PL1	<u>n</u> & <u>p</u>	<u>190 - 430</u>	<u>310</u>

*At 25°C

FAULT CODE - NONE
BLEED BAND DOES NOT FUNCTION PROPERLY



Bleed Band Does Not Function Properly
Figure 148


G-62 BLEED BAND DOES NOT FUNCTION PROPERLY EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 148.

Step 4. Refer to manufacturer's procedure for diagnosing engine bleed band.

FAULT CODE - NONE

ENGINE OUT INDICATOR (EOI) DOES NOT ILLUMINATE DURING NORMAL SHUTDOWN




Engine Out Indicator (EOI) Does Not Illuminate During Normal Shutdown
Figure 149

G-63 ENGINE OUT INDICATOR (EOI) DOES NOT ILLUMINATE DURING NORMAL SHUTDOWN EXPANDED INSTRUCTIONS.

Refer to numbered steps in figure 149.

- Step 3. Check harness connector PL1 (figure 201) at each DECU for tight connections.
- Step 4. Disconnect connector PL1 to check pins and sockets.
- Step 5. With PL1 and PL3 disconnected, turn on power to caution panel. Short harness PL1 connector socket DD (figure 202) to airframe ground. EOI should illuminate when DD is grounded.
- Step 6. Before tightening harness connector PL1, be sure that keyway in harness connector is aligned with keyway in component connector.
- Step 9. Refer to manufacturer's procedure for diagnosing and replacing of EOI.
- Step 11. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 14. Refer to manufacturer's procedure for diagnosing and replacing harness or caution panel.


FAULT CODE - NONE
 NO OBSERVED ENGINE SPEED REDUCTION DURING OVERSPEED TEST



(CONTINUED)

No Observed Engine Speed Reduction During Overspeed Test (Sheet 1 of 2)
 Figure 150

FAULT CODE - NONE
 NO OBSERVED ENGINE SPEED REDUCTION DURING OVERSPEED TEST



No Observed Engine Speed Reduction During Overspeed Test (Sheet 2 of 2)
 Figure 150

G-64 NO OBSERVED ENGINE SPEED REDUCTION DURING OVERSPEED TEST EXPANDED INSTRUCTIONS.

- Step 2. Check harness connectors PL1 AND PL3 (figure 201) at DECU, and P9 at overspeed solenoid for tight connection.
- Step 3. Disconnect connectors PL1, PL3 and P9 to check pins and sockets.
- Step 5. With PL1 disconnected and overspeed test not selected, check resistance of overspeed switch at harness PL1 connector sockets A and B (figure 202). Limit is >150K Ω . With overspeed test selected, check resistance again. Limit is <50 Ω .
- Step 6. With PL3 disconnected, check resistance of overspeed solenoid at harness PL3 connector sockets P and R (figure 202). Limit is 15.0 - 55.0 Ω .
- Step 7. With PL3 disconnected at both DECUs, check the resistance between the DECUs at the following harness PL3 sockets:

<u>DECU #1</u>	<u>DECU #2</u>
<u>g</u>	<u>Y</u>
<u>Y</u>	<u>g</u>

Limit in each case is <1 Ω .


- Step 8. Before tightening harness connectors PL1, PL3 and P9, be sure that keyways in harness connectors are aligned with keyways in component connectors.
- Step 12. With P9 disconnected, check resistance of overspeed solenoid at solenoid J9 connector pins A and B. Limit is 15.0 - 55.0 Ω .
- Step 14. Refer to manufacturer's procedure for checking overspeed valve operation.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing harness or overspeed solenoid.
- Step 19. Refer to manufacturer's procedure for diagnosing and replacing harness or switch.
- Step 21. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 22. Refer to manufacturer's procedure for diagnosing and replacing overspeed solenoid.
- Step 24. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 25. Refer to manufacturer's procedure for diagnosing and replacing overspeed valve.

G-64 NO OBSERVED ENGINE SPEED REDUCTION DURING OVERSPEED TEST EXPANDED INSTRUCTIONS.(CONTINUED)

RESISTANCE-CHECK SUMMARY

Component	Connector				Resistance Limits (Ω)
	DECU #1		DECU #2		
	No.	Contacts	No.	Contacts	
Overspeed Test Switch Test Not Selected	PL1	A & B	--	--	>150K
		A & B	--	--	< 50
Overspeed Solenoid	PL3	P & R	--	--	<u>15.0 - 55.5</u>
	J9	A & B	--	--	<u>15.0 - 55.0</u>
Harness	PL3	<u>g</u>	PL3	<u>Y</u>	<1
	PL3	<u>y</u>	PL3	<u>g</u>	<1

FAULT CODE - NONE
NO BEEPER SWITCH RESPONSE IN REVERSION



Beeper Switch Does Not Function in Reversion
Figure 151

G-65 NO BEEPER SWITCH RESPONSE IN REVERSION EXPANDED INSTRUCTIONS
--

Refer to numbered steps in figure 151.

Step 2. Check harness connector PL3 (figure 201) at each DECU for tight connection.

Step 3. Disconnect connector PL3 to check pins and sockets.

Step 5. With PL3 disconnected and beeper switch in increase position, check resistance of beeper switch at harness PL3 connector sockets JJ and KK (figure 202). Limit is $<50\Omega$. Check resistance at sockets w and KK. Limit is $>150K\Omega$. With beeper switch in decrease position, check resistance at sockets JJ and KK. Limit is $>150K\Omega$. Check resistance at sockets w and KK. Limit is $<50\Omega$. With beeper switch in neutral position, check resistance at sockets JJ and KK, and w and KK. In each case limit is $>150K\Omega$.

Step 6. Before tightening harness connector PL3, be sure that keyway in harness connector is aligned with keyway in component connector.

Step 10. Refer to manufacturer's procedure for diagnosing and replacing harness.

Step 12. Refer to manufacturer's procedure for diagnosing and replacing harness or switch.


RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Q)	
	No.	Contacts	Limits	Nominal *
Beeper Switch Increase Position	PL3	JJ & KK w & KK	< 50 $> 150K$	$\frac{1}{\infty}$
Beeper Switch Decrease Position	PL3	JJ & KK w & KK	$> 150K$ < 50	∞ $\frac{1}{\infty}$
Beeper Switch Neutral Position	PL3	JJ & KK w & KK	$> 150K$ $> 150K$	∞ ∞

*At 25°C

FAULT CODE - NONE

UNABLE TO PERFORM POWER ASSURANCE TEST (RESULTS NOT INDICATED ON HEX DISPLAY)



Unable to Perform Power Assurance Test (Results Not Indicated On Hex Display)

Figure 152

**G-66 UNABLE TO PERFORM POWER ASSURANCE TEST (RESULTS NOT INDICATED ON HEX DISPLAY)
EXPANDED INSTRUCTIONS**

Refer to numbered steps in figure 152.

- Step 2. Check harness connector PL1 (figure 201) at DECU for tight connection.
- Step 3. Disconnect connector PL1 to check pins and sockets.
- Step 5. With PL1 disconnected, and power assurance switch in PAS not selected position, check resistance of power assurance switch at harness PL1 connector sockets HH and w (figure 202). Limit is >150K Ω . With switch in PAS selected position, check resistance again. Limit is <50 Ω .
- Step 6. Before tightening harness connector PL1, be sure that keyway in harness connector is aligned with keyway in component connector.
- Step 10. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 12. Refer to manufacturer's procedure for diagnosing and replacing harness or switch.


RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Q)	
	No.	Contacts	Limits	Nominal *
Power Assurance Switch Test Not Selected	PL1	HH & <u>w</u>	<u>> 150K</u>	∞
Test Selected	PL1	HH & <u>w</u>	<u><50</u>	<u>1</u>

*At 25°C


FAULT CODE - NONE
MOVING ECL TO STOP CAUSES INCREASE IN ENGINE POWER

NOTE The engine shall not be run following any repairs until all electrical checks have been completed. The pilot may experience loss of control on an unexpected event if a problem with the ECL system still exists.



Moving ECL to Stop Causes Increase in Engine Power (Sheet 1 of 2)
 Figure 153

FAULT CODE - NONE
 MOVING ECL TO STOP CAUSES INCREASE IN ENGINE POWER
 (CONTINUED)



Moving ECL to Stop Causes Increase in Engine Power (Sheet 2 of 2)
 Figure 153

G-67 MOVING ECL TO STOP CAUSES INCREASE IN ENGINE POWER EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 153.

- Step 2. Disconnect PL3 and ECL quadrant connectors to check pins and sockets.
- Step 3. Follow instructions as required in figure 159, except do not check system for original fault after any repairs are made. After all checks from figure 159 are completed, go to step 4 of this procedure.
- Step 4. Set ECL to STOP. With PL3 disconnected, check resistance of ECL quadrant (excitation) at harness PL3 connector sockets h and j (figure 202). Limit is 35 - 42Ω. Check resistance of ECL quadrant (signal) at sockets EE and DD. Limit is 90 - 102 Ω. Monitor resistance of ECL quadrant (interlock discrete) at sockets f and LL while moving ECL from STOP to GROUND to FLIGHT. Limits are defined in table below. Monitor resistance of ECL quadrant (gain discrete) at sockets MM and LL while moving ECL from STOP to GROUND to FLIGHT. Limits are as defined in table below. **(NOTE:** Gain discrete resistance is not checked at GROUND because switch can be open or closed at that point.)
- Step 5. Refer to manufacturer's procedure for checking operation of ECL quadrant.
- Step 7. Set ECL to STOP. With ECL quadrant connector disconnected, check resistance of ECL quadrant (excitation) at quadrant pins 1 and 2. Limit is 35 - 40Ω. Check resistance of ECL quadrant (signal) at quadrant pins 3 and 4. Limit is 90 - 100Ω. Monitor resistance of ECL quadrant (interlock discrete) at pins 11 and 12 while moving ECL from STOP to GROUND to FLIGHT. Limits are as defined in table below. Monitor resistance of ECL quadrant (gain discrete) at pins 5 and 11 while moving ECL from STOP to GROUND to FLIGHT. Limits are as defined in table below. **(NOTE:** Gain discrete resistance is not checked at GROUND because switch can be open or closed at that point.)
- Step 8. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 13. Refer to manufacturer's procedure for diagnosing and replacing harness or ECL quadrant.
- Step 14. Refer to manufacturer's procedure replacing ECL quadrant.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing ECL quadrant.


G-67 MOVING ECL TO STOP CAUSES INCREASE IN ENGINE POWER EXPANDED INSTRUCTIONS(CONTINUED)

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No.	Contacts	Limits	Nominal
ECL Quadrant - Excitation	PL3	<u>h</u> & <u>i</u>	<u>35 - 42</u>	--
	ECL Quadrant	1 & 2	<u>35 - 40</u>	--
ECL Quadrant- Signal	PL3	EE & DD	<u>90 - 102</u>	--
	ECL Quadrant	3 & 4	<u>90 - 100</u>	--
ECL Quadrant - Interlock Discrete:				
ECL at STOP	PL3	<u>f</u> & <u>LL</u>	> <u>150K</u>	∞
ECL between STOP and GROUND		<u>f</u> & <u>LL</u>	< <u>50</u>	<u>1</u>
ECL at GROUND		<u>f</u> & <u>LL</u>	> <u>150K</u>	∞
ECL between GROUND and FLIGHT		<u>f</u> & <u>LL</u>	< 50	<u>1</u>
ECL at FLIGHT		<u>f</u> & <u>LL</u>	> <u>150K</u>	∞
ECL Quadrant - Interlock Discrete:				
ECL at STOP	ECL Quadrant	12 & 11	> <u>150K</u>	∞
ECL between STOP and GROUND		12 & 11	< 50	
ECL at GROUND		12 & 11	> <u>150K</u>	∞
ECL between GROUND and FLIGHT		12 & ii	< <u>50</u>	<u>1</u>
ECL at FLIGHT		12 & 11	> <u>150K</u>	∞
ECL Quadrant - Gain Discrete				
ECL at STOP	PL3	MM & LL	< <u>50</u>	<u>1</u>
ECL between STOP and GROUND		MM & LL	< <u>50</u>	<u>1</u>
ECL between GROUND and FLIGHT		MM & LL	> <u>150K</u>	∞
ECL at FLIGHT		MM & LL	> <u>150K</u>	∞
ECL Quadrant - Gain Discrete				
ECL at STOP	ECL Quadrant	5 & 11	< <u>50</u>	<u>1</u>
ECL between STOP and GROUND		5 & 11	< <u>50</u>	<u>1</u>
ECL between GROUND and FLIGHT		5 & 11	> <u>150K</u>	∞
ECL at FLIGHT		5 & 11	> <u>150K</u>	∞
*At <u>25°C</u>				


FAULT CODE - NONE
MOVING ECL TO FLIGHT CAUSES DECREASE IN ENGINE POWER

NOTE The engine shall not be run following any repairs until all electrical checks have been completed. The pilot may experience loss of control on an unexpected event if a problem with the ECL system still exists.



Moving ECL to Flight Causes Decrease in Engine Power (Sheet 1 of 2)
Figure 154

FAULT CODE - NONE
 MOVING ECL TO FLIGHT CAUSES DECREASE IN ENGINE POWER



Moving ECL to Flight Causes Decrease in Engine Power (Sheet 2 of 2)
 Figure 154

G-68 MOVING ECL TO FLIGHT CAUSES DECREASE IN ENGINE POWER EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 154.


- Step 2. Disconnect PL3 and ECL quadrant connectors to check pins and sockets.
- Step 3. Follow instructions as required in figure 159, except do not check system for original fault after any repairs are made. After all checks from figure 159 are completed, go to step 4 of this procedure.
- Step 4. Set ECL to STOP. With PL3 disconnected, check resistance of ECL quadrant (excitation) at harness PL3 connector sockets h and i (figure 202). Limit is $35\text{--}42\Omega$. Check resistance of ECL quadrant (signal) at sockets EE and DD. Limit is $90\text{--}102\Omega$. Monitor resistance of ECL quadrant (interlock discrete) at sockets f and LL while moving ECL from STOP to GROUND to FLIGHT. Limits are defined in table below. Monitor resistance of ECL quadrant (gain discrete) at sockets MM and LL while moving ECL from STOP to GROUND to FLIGHT. Limits are as defined in table below. (Note: Gain discrete resistance is not checked at GROUND because switch can be open or closed at that point.)
- Step 5. Refer to manufacturer's procedure for checking operation of ECL quadrant.
- Step 7. Set ECL to STOP. With ECL quadrant connector disconnected, check resistance of ECL quadrant (excitation) at quadrant pins 1 and 2. Limit is $35\text{--}40\Omega$. Check resistance of ECL quadrant (signal) at quadrant pins 3 and 4. Limit is $90\text{--}100\Omega$. Monitor resistance of ECL quadrant (interlock discrete) at pins 11 and 12 while moving ECL from STOP to GROUND to FLIGHT. Limits are as defined in table below. Monitor resistance of ECL quadrant (gain discrete) at pins 5 and 11 while moving ECL from STOP to GROUND to FLIGHT. Limits are as defined in table below. (Note: Gain discrete resistance is not checked at GROUND because switch can be open or closed at that point.)
- Step 8. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 13. Refer to manufacturer's procedure for diagnosing and replacing harness or ECL quadrant.
- Step 14. Refer to manufacturer's procedure replacing ECL quadrant.
- Step 17. Refer to manufacturer's procedure for diagnosing and replacing ECL quadrant.

G-68 MOVING ECL TO FLIGHT CAUSES DECREASE IN ENGINE POWER EXPANDED INSTRUCTIONS(CONTINUED)

RESISTANCE-CHECK SUMMARY

Component	Connector		Resistance (Ω)	
	No	Contacts	Limits	Nominal *
ECL Quadrant – Excitation	PL3	h & i	35 – 42	–
	ECL Quadrant	1 & 2	35 – 40	–
ECL Quadrant – Signal	PL3	EE & DD	90 – 102	–
	ECL Quadrant	3 & 4	90 – 100	–
ECL Quadrant – Interlock Discrete	PL3	f & LL	> 150K	∞
ECL at STOP		f & LL	< 50	1
ECL between STOP and GROUND		f & LL	> 150K	∞
ECL at GROUND		f & LL	< 50	1
ECL between GROUND and FLIGHT		f & LL	> 150K	∞
ECL at FLIGHT	ECL Quadrant	12 & 11	> 150K	∞
ECL at STOP		12 & 11	< 50	1
ECL between STOP and GROUND		12 & 11	> 150K	∞
ECL at GROUND		12 & 11	< 50	1
ECL between GROUND and FLIGHT		12 & 11	> 150K	∞
ECL at FLIGHT	PL3	MM & LL	< 50	1
ECL at STOP		MM & LL	< 50	1
ECL between STOP and GROUND		MM & LL	> 150K	∞
ECL between GROUND and FLIGHT		MM & LL	> 150K	∞
ECL at FLIGHT	ECL Quadrant	5 & 11	< 50	1
ECL at STOP		5 & 11	< 50	1
ECL between STOP and GROUND		5 & 11	> 150K	∞
ECL between GROUND and FLIGHT		5 & 11	> 150K	∞
ECL at FLIGHT	*At 25°C			

FAULT CODE – NONE
 ENGINE OUT INDICATOR (EOI) IS ALWAYS ILLUMINATED




Engine Out Indicator (EOI) Is Always Illuminated
 Figure 155

G-69 ENGINE OUT INDICATOR (EOI) IS ALWAYS ILLUMINATED EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 155.

- Step 2. Check harness connector PL1 (figure 201) at DECU for tight connection.
- Step 3. Disconnect connector PL1 to check pins and sockets.
- Step 4. With PL1 and PL3 disconnected, turn on power to caution panel.
- Step 5. Before tightening harness connector PL1, be sure that keyway in harness connector is aligned with keyway in component connector.
- Step 9. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 12. Refer to manufacturer's procedure for diagnosing and replacing harness or caution panel.

FAULT CODE - NONE
 F/R LAMP DOES NOT ILLUMINATE WHEN REVERSION IS SELECTED




F/R Lamp Does Not Illuminate When Reversion Is Selected
 Figure 156

G-70 F/R LAMP DOES NOT ILLUMINATE WHEN REVERSION IS SELECTED EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 156.

- Step 3. Check harness connector PL3 (figure 201) at DECU for tight connection.
- Step 4. Disconnect connector PL3 to check pins and sockets.
- Step 5. With PL1 and PL3 disconnected, turn on power to caution panel.
- Step 6. Before tightening harness connector PL3, be sure that keyway in harness connector is aligned with keyway in DECU connector.
- Step 9. Refer to manufacturer's procedure for diagnosing and replacing F/R lamp.
- Step 11. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 14. Refer to manufacturer's procedure for diagnosing and replacing harness or caution panel.

FAULT CODE - NONE
 F/R LAMP IS ILLUMINATED WHEN PRIMARY IS SELECTED




F/R Lamp is Illuminated When Primary Is Selected
 Figure 157

G-71 F/R LAMP IS ILLUMINATED WHEN PRIMARY IS SELECTED EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 157.

- Step 3. Check harness connector PL3 (figure 201) at DECU for tight connection.
- Step 4. Disconnect connector PL3 to check pins and sockets.
- Step 5. With PL1 and PL3 disconnected, turn on power to caution panel. Short harness PL3 connector socket k to airframe ground. F/R lamp should not illuminate when k is grounded.
- Step 6. Before tightening harness connector PL3, be sure that keyway in harness connector is aligned with keyway in component connector.
- Step 11. Refer to manufacturer's procedure for diagnosing and replacing harness.
- Step 14. Refer to manufacturer's procedure for diagnosing and replacing harness or caution panel.

FAULT CODE - UNDEFINED
FAULT CODES NOT DEFINED IN TABLE 1



*Fault Codes Not Defined in Table 1
Figure 158*


G-72 FAULT CODES NOT DEFINED IN TABLE 1 EXPANDED INSTRUCTIONS

Refer to figure 158.

Step 1. Cycle DECU power to verify fault code.

Step 3. An internal DECU fault exists. No further troubleshooting is necessary.

INSULATION/VOLTAGE CHECK



Insulation/Voltage Check
Figure 159

G-73 INSULATION/VOLTAGE CHECK EXPANDED INSTRUCTIONS

Refer to numbered steps in figure 159.

- Step 1. Check the resistance between the DECU case at the ground strap and airframe ground using a 4-wire configuration. Limit is $< 50\Omega$.
- Step 2.. With PL1 and PL3 (figure 201) disconnected, check the resistance between each harness PL1 and PL3 connector socket (except PL1 -Y, PL1-t and PL3-N) and airframe ground. For PL1 sockets Z and u (figure 202), and PL3 sockets R and m, limit is $< 2\Omega$. For PL3 sockets v and GG, limit is $> 1000\Omega$. For all others, limit is $> 1M\Omega$.
- Step 3. With PL1 and PL3 disconnected, check the resistance between the pin pairs listed in the table below at harness PL1 and PL3 connector sockets. Limit in each case is $> 1 M\Omega$
- Step 4. With PL1 and PL3 disconnected. turn on airframe supply and emergency supply. Check voltage of the airframe supply at harness PL1 connector sockets Y and Z, and t and u. Limit is 16-30V. Check voltage of the emergency supply at harness PL3 connector sockets N and m. Limit is 16 -30V.
- Step 9. Refer to manufacturer's procedure for diagnosing and replacing ground strap. See instructions for fault check defined by original procedure being followed.
- Step 11. Refer to manufacturer's procedure for diagnosing and replacing harness or component. See instructions for fault check defined by original procedure being followed.
- Step 13. Refer to manufacturer's procedure for diagnosing and replacing harness or component. See instructions for fault check defined by original procedure being followed.
- Step 15. Refer to manufacturer's procedure for diagnosing and replacing harness or component. See instructions for fault check defined by original procedure being followed.

RESISTANCE-CHECK SUMMARY - STEP 1

Connection	Measurement Locations	Resistance Limits (m Ω)
Ground Strap	DECU case and airframe ground	<u><50</u>

G-52 INSULATION/VOLTAGE CHECK EXPANDED INSTRUCTIONS(CONTINUED)

RESISTANCE-CHECK SUMMARY – STEP 2

Signal	Connector		Resistance Limits (Ω)
	No	Contact to Airframe Ground	
OV A/F	PL1	Z	< <u>2</u>
		<u>u</u>	< <u>2</u>
OV EM	PL3	<u>m</u>	< <u>2</u>
O/S – OUT	PL3	R	< <u>2</u>
T4 5 Sensor	PL3	<u>v</u>	> <u>1000</u>
		GG	> <u>1000</u>
All others	PL1, PL3	All others*	> <u>1M</u>
*Except PL1–Y, PL1– <u>i</u> , and PL3–N			


RESISTANCE-CHECK SUMMARY – STEP 3

Component	Connector		Resistance Limits (Ω)
	No	Contacts	
T4 5 Gauge	PL3	Z & <u>a</u>	> <u>1M</u>
		Z & <u>u</u>	> <u>1M</u>
RTL Sensor	PL3	<u>n</u> & <u>p</u>	> <u>1M</u>
		<u>n</u> & <u>q</u>	> <u>1M</u>
		<u>n</u> & <u>z</u>	> <u>1M</u>
		<u>n</u> & AA	> <u>1M</u>
ECL Quadrant	PL3	CC & <u>h</u>	> <u>1M</u>
		CC & <u>l</u>	> <u>1M</u>
		CC & DD	> <u>1M</u>
		CC & EE	> <u>1M</u>
T1 Sensor	PL3	FF & <u>r</u>	> <u>1M</u>
		FF & <u>s</u>	> <u>1M</u>
		FF & <u>t</u>	> <u>1M</u>
T4 5 Harness	PL3	HH & <u>v</u>	> <u>1M</u>
		HH & GG	> <u>1M</u>


G-52 INSULATION/VOLTAGE CHECK EXPANDED INSTRUCTIONS(CONTINUED)

VOLTAGE-CHECK SUMMARY - STEP 3


Component	Connector		Voltage (V)	
	No.	Contacts	Limits	Nominal *
Airframe Power Supply	PL1	Y & Z	<u>16 - 30</u>	<u>28</u>
		<u>t</u> & <u>u</u>	<u>16 - 30</u>	<u>28</u>
Airframe Emergency Supply *At <u>25°C</u>	PL3	N & <u>m</u>	<u>16 - 30</u>	<u>28</u>




Fuel Control System Harness Connections
Figure 201




HMU J4




HMU J6



HMU J5




DECU PL1 & PL3



DECU PL2

NOTE These are pin locations for connectors on the HMU and DECU. Note that the socket locations for the harness connectors are the same except that they are reversed to form a mirror image.



HMU Schematic Diagram
Figure 203

GLOSSARY

Definition

A

Abrasion..... A roughened surface.

B

Bend..... Distortion in a part.
 Binding To confine and restrict the liberty of a free moving part, material, or component. May cause serious damage if a chafing force is being imposed.
 Break..... Separation of a part.
 Buckling..... A large-scale deformation of the original contour of a part, usually due to pressure or impact from a foreign object, structural stresses, excessive localized heating, high-pressure differentials, or to any combination of these.
 Burn A rapid destructive oxidizing action usually caused by higher temperatures than the material can withstand structurally. Change in color and appearance often indicates this condition.
 Burr A rough or sharp edge on a hole or corner, usually caused by machining, sometimes by wearing.

C

Carborundum..... The trade name for a manufactured aluminum oxide abrasive similar to natural emery. It is used for grinding wheels and for abrasive papers.
 Chafing..... A worn or rubbed area caused by friction: refers to the wear produced by parts such as fuel, air, and oil lines rubbing against other parts.
 Chipping..... Breaking away of metallic particles.
 Chordal..... Progressing in a straight line from one edge to another on a curved surface. Typically, on an airfoil, a direction or measurement from leading to trailing edge.
 Concave..... A hollow surface curved like the inside of a bowl.
 Contamination (Foreign Material)..... Any foreign substance such as metal chips, lint, rust, and water that would be harmful to the functioning of a part or system.
 Converging..... Tending to move toward one point or another.
 Convex..... A surface shaped like the outside of a sphere or a ball.
 Corrosion..... A mass of small pits which cumulatively create a large cavity (usually shallow) in the surface of the parent metal.

GLOSSARY (Continued)

Definition

C (Continued)

- Corrosion Pitting..... Irregular surface depressions having ragged edges due to metal removed caused by corrosive substance adhering to exposed surfaces.
- Corrugated The forming and shaping of sheet metal into wrinkles or folds or into alternating ridges and grooves.
- Crack..... Parting of parent metal.

D

- Dent A completely smooth surface depression caused by pressure or impact from a smooth ball-like foreign object. The parent material is displaced, but usually none is separated.
- Desiccant..... A drying agent; usually placed in containers along with parts being stored, to absorb moisture and prevent corrosion.
- Diagnostic Equipment..... Test equipment used to determine what the defective part is.
- Distortion Twisting or bending out of a normal, natural or original shape, usually caused from being exposed to excessive pressure or temperature either when restrained or unrestrained.

F

- Fatigue The progressive weakening of a material under repeated cycles of stress.
- Foreign Material See Contamination.
- Foreign Object..... Any object such as a tool, piece of equipment, engine part (nut, bolt, lockwire) that could in any way damage the engine.
- Fraying Wearing or rubbing of areas, generally used in reference to damage on wire-braid covering (of Teflon hose) or on thermocouple harness.
- Fretting..... Discoloration or damage caused by rubbing, chafing, or wearing away of original surface material resulting from movement of contacting surfaces. Can cause grooving in severe cases.

G

- Gouge A wide rough scratch or group of scratches, usually, with one or more sharply impressed corners, and frequently accompanied by deformation or removal of parent metal.

GLOSSARY (Continued)

Definition

G (Continued)

Grooving Wearing away of material, caused by movement of contacting surfaces, in such a manner as to cause a long, thin, sharp depression in the surface. Can cause steps in severe cases..

H

Heat Discoloration Characterized by a discoloring film. Color varies from light straw, tan, or light brown changing to red purple, purple or blue. Caused by high temperature operation.

I

Insulation A material or device used to prevent passage of heat, electricity, or sound from one medium to another.

K

Kinks Short, tight twists or curls caused by a doubling or winding of a hose or line upon itself. Likely to cause difficulties in the operation.

L

Loose Abnormal movement of a part.

N

Nick A surface impression with sharp corners or bottom, usually caused by pressure or impact from a sharp-edged foreign body. The parent material is displaced but usually none is separated.

O

Overhaul To restore an item to a completely serviceable condition as prescribed by serviceability standards developed and published by the Government.

Overshooting When the expected N1 or N2 speed is exceeded momentarily and then drops below the expected level.

Overspeed When the expected N1 or N2 speed is exceeded.

Oxidation A chemical action in which a metallic element is united with oxygen causing deterioration of the metal or material.

GLOSSARY (Continued)

Definition

P

Parent Metal.....	The basic metal of a part, sometimes referred to as a base metal; the term is used particularly in connection with welding, where the parent metal is that being welded rather than that used in welding rod.
Peening.....	Surface deformation.
Phenolic.....	A thermosetting resin or plastic made especially for molding and insulating, coatings and adhesives.
Pitting.....	Very shallow depressions in a surface, usually caused by chemical reaction (rusting chemical corrosion).
Popping.....	Sharp abrupt noise normally caused by erratic bleed band operation.
Protrusion.....	Projection sticking out from the rest of the surrounding material or surface.
Puncture.....	A hole that is pierced in a material.

R

Repair.....	To restore a defective part, component, subassembly or assembly to a serviceable condition.
Rollover.....	A curl usually on the leading edge of a blade, resulting from deformation by the peening action of foreign objects.
Rub.....	When one component contacts another and is moved in relationship to it causing material to be removed from it.
Rust.....	Oxidation of iron. A red, crusty product which forms on iron or steel when it unites with oxygen.

S

Scoring.....	Multiple scratches, usually parallel and resulting from the same cause.
Scratch.....	A long, narrow sharp-cornered impression caused by the movement of a sharp object across the surface of parent material.
Serviceable.....	Equipment or parts that are in condition which allows them to be returned to operational status on an aircraft.
Step.....	Wearing away of material, caused by movement of contacting surfaces, in such a manner as to cause sharp edged ridges or depressions. Usually a severe form of grooving.
Subassembly.....	A self-contained unit of an assembly that can be removed, replaced, and repaired separately; turbine nozzles and combustion liner are typical subassemblies.

GLOSSARY (Continued)

Definition

T

- Tear..... A forcible, somewhat crude pulling or wrenching away of material so that ragged or irregular edges result.
- Testing Testing of equipment to determine that the unit functions properly within specified limits.
- Tight-Lipped Type of crack in which edges have separated enough to allow visibility of inner edges. Usually, in vanes, core will be visible.
- Tolerance The range of variation allowed in maintaining a specified dimension in making part.
- Torque..... To tighten a nut, bolt, or fitting, using a torque wrench, to a specified torque value expressed as inch-pounds or as foot-pounds.

U

- Undershooting..... When the expected N1 or N2 speed is not reached and then creeps up to the expected level.
- Underspeed..... When the expected N1 or N2 speed is not reached.
- Upset..... A part of a rod (as a head on a bolt) that is upset.

V

- Void A continuous lack of braze material through a braze joint cross-section caused by improper repair.

W

- Wear Relatively slow removal of parent material from any cause, frequently not visible to the naked eye.

INDEX

Subject	Para/ Task	Page	Subject	Para/ Task	Page
A			Adjust Oil Pump	1-101	1-499
Abbreviations		F-1	Air-Bleed Actuator, Interstage - See Interstage Air-Bleed Actuator		
Abbreviations	G-12	G-10	Air Diffuser Assembly Repair	2-38	2-321
Abnormal Engine Coastdown Noise or Time (Less than 23 Seconds)	1-66	1-293	Air Gallery Cover, Anti-Icing - See Anti-Icing Air Gallery Cover		
Accessory Electrical Harness Assembly			Air Inlet Housing Assembly		
Clean	7-29	7-143	Clean	2-49	2-355
Inspect	7-30	7-144	Inspect	2-50	2-356
Install	7-33	7-156	Repair.....	2-51	2-357
Remove	7-28	7-137			
Repair	7-31	7-146	Air Lines - See Hose Assembly		
Test	7-32	7-147			
Accessory Gear Section	1-17	1-25	Alloys, Touch Up Magnesium and Magnesium - See Touch Up Magnesium and Magnesium Alloys		
Accessory Gearbox Assembly			Anti-Icing Air Gallery Cover		
Assemble.....	5-6	5-23	Clean	2-15	2-47
Clean	5-3	5-17	Inspect	2-17	2-52
Disassemble	5-2	5-12	Install	2-19	2-56
Inspect	5-4	5-20	Remove	2-16	2-50
Install	5-7	5-28	Repair	2-18	2-54
Remove	5-1	5-3			
Repair	5-5	5-22	Army Material to Prevent Enemy Use, Destruction of Army Material to Prevent Enemy Use		
Activate Engine After Storage	1-28	1-94	Assemble		
Actuator, Interstage Air-Bleed - See Interstage Air-Bleed Actuator			Accessory Gearbox Assembly	5-6	5-23
Adjust			Combustion Section	3-12	3-134
Interstage Air-Bleed Actuator	2-9	2-26	(AVIM) Combustion Section	3-10	3-123
Oil Level Indicator	8-121	8-303	(AVIM) Combustion Section and Power Turbine	3-7	3-62
Adjust			Dual Chip Detector	8-44	8-100
Interstage Air-Bleed Actuator	2-9	2-26	In-Line Fuel Filter Assembly	6-39	6-128
Oil Level Indicator	8-121	8-303	Interstage Air-Bleed Actuator	2-6	2-16

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Main Fuel Filter and Bracket	6-33	6-115	Bearing Oil Tubes (AVIM), No 4 and		
Main Oil Pump, Speed Pickup Drive			5 - See No 4 and 5 Bearing Oil		
Assembly, Scavenge Oil Screen, ..			Tubes (AVIM)		
and Related Parts	8-5	8-17	Bearing Package (AVIM), Check for		
Oil Cooler Assembly	8-17	8-45	Seal Leakage (No 2) - See		
Oil Filler Assembly and Oil Filler ...			Check for Seal Leakage (No 2		
Strainer	8-32	8-78	Bearing Package) (AVIM)		
Oil Level Float Assembly	8-127	8-316	Bearing Package Seals (AVIM), No.		
Oil Level Indicator	8-119	8-293	4 and 5 - See No 4 and 5		
Overspeed Drive and Outlet Cover			Bearing Package Seals (AVIM)		
Assembly	5-28	5-84	Bearing Pressure Oil Strainer, No. 2		
Tailpipe Assembly	4-75	4-426	- See No. 2 Bearing Pressure Oil		
Third Turbine Nozzle and Support .	4-31	4-123	Strainer		
Assurance/Quality Control (QA/QC),...			Bearing Pressure Oil Strainer,		
Quality - See Quality Assurance,...			Service No.2 - See Service No 2		
Quality Control (QA/QC)			Bearing Pressure Oil Strainer		
B			Blades, Compressor Rotor - See		
Backlash Check - Overspeed Drive			Compressor Rotor Blades		
and Outlet Cover Assembly	5-30	5-90	Bleed Band, Compressor - See		
Band Closure Check, Bleed - See			Compressor Bleed Band		
Bleed Band Closure Check			Bleed Band Does Not Function Properly		
Band, Compressor Bleed - See			Expanded Instructions	G-62	G-144
Compressor Bleed Band			Boost Pump Assembly, Fuel - See		
Bar Assemblies, Left- and			Fuel Boost Pump Assembly		
Right-Hand Bus - See Left- and.....			Bracket, Main Fuel Filter and - See		
Right-Hand Bus Bar Assemblies			Main Fuel Filter and Bracket		
Bearing (AVIM), Check for Seal			Bus Bar Assemblies, Left- and		
Leakage (No. 4 and 5) - See			Right-Hand - See Left- and		
Check for Seal Leakage (No. 4			Right-Hand Bus Bar Assemblies		
and 5 Bearing) (AVIM)					
Bearing Filter, No. 4 and 5 - See No...					
4 and 5 Bearing Filter					
Bearing Oil Filter, Service No. 4 and ..					
5 - See Service No. 4 and 5					
Bearing Oil Filter					

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
C					
Cable Assembly, Ignition Coil and – See Ignition Coil and Cable Assembly			Characteristics, Capabilities, and Features, Equipment – see Equipment characteristics, Capabilities, and Features		
Capabilities, and Features, Equipment Characteristics – See Equipment characteristics, Capabilities and Features			Chart, Maintenance Allocation – See Maintenance Allocation Chart		
Care, and Handling, Safety – See Safety, Care, and Handling			Check, Bleed Band Closure – See Bleed Band Closure Check		
Case (AVIM), Second Turbine Nozzle, Spacer, and Bumper – See Second Turbine Nozzle, Spacer, Case and Bumper (AVIM)			Check Engine Coastdown Time . . . 1-75		1-323
Chafing, Denting, Scratching, Gouging, or Wear, Determine Depth of Damage from – See Determine Depth of Damage from Chafing, Denting, Scratching, Gouging, or Wear			Check Flight Idle – See Flight Idle Check		
Chafing Sleeve on Hoses, Install Spiral – See Install Spiral Chafing Sleeve on Hoses			Check for Seal Leakage (No. 2 Bearing Package) (AVIM) 1-81		1-348.3
Chamber Housing (AVIM), Combustion – See Combustion Chamber Housing (AVIM)			Check for Seal Leakage (No. 4 and 5 Bearing) (AVIM) 1-82		1-356
Chamber Liner (AVIM), Combustion – See Combustion Chamber Liner (AVIM)			Check for Static Oil Leakage 1-83		1-367
Change from MIL-L-7808 to MIL-L-23699 Lubricating Oil . . . 1-70		1-313	Check Overspeed Drive and Outlet Cover Assembly, Backlash		
Change from MIL-L-23699 to MIL-L-7807 Lubricating Oil 1-71		1-315	Check Valve (Air Diffuser to Interstage Air-Bleed Actuator) Clean 2-74		2-412
			Install 2-75		2-413
			Remove 2-73		2-410
			Check Valve (Water Wash Tee to Interstage Air-Bleed Actuator PM Inlet) Clean 2-80		2-423
			Install 2-81		2-424
			Remove 2-79		2-421
			Check Valve (Water Wash Tee to Interstage Air-Bleed Actuator P3 Inlet) Clean 2-77		2-418
			Install 2-78		2-419
			Remove 2-76		2-416

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Chip Detector			Inlet Housing Cover Assembly	2-45	2-348
Clean	8-110	8-276	In-Line Fuel Filter Assembly	6-37	6-126
Contamination	1-80.1	1-348	Interstage Air-Bleed Actuator	2-3	2-13
Inspect	8-111	8-277	Left- and Right-Hand Bus Bar		
Install	8-113	8-280	Assemblies	4-8	4-32
Remove	8-109	8-273	Left- and Right-Hand Fuel Manifold		
Test	8-112	8-279	Assemblies	6-16	6-60
Clean			Main Fuel Filter and Bracket	6-30	6-109
Accessory Electrical harness			Main Oil pump, Speed Pickup		
Assembly	7-29	7-143	Drive Assembly, Scavenge Oil		
Accessory Gearbox Assembly	5-3	5-17	Screen and Related Parts	8-3	8-14
Air Inlet Housing Assembly	2-49	2-355	No. 2 Bearing Pressure Oil		
Anti-Icing Gallery Cover	2-15	2-47	Connector	8-94	8-245
Chip Detector	8-110	8-276	No. 2 Bearing Pressure Oil		
Combustion Chamber Housing	3-1	3-171	Strainer	8-98	8-249
Combustion Chamber Liner	3-16	3-145	No. 4 and 5 Bearing Filter	8-102	8-259
Combustion Chamber Vane			No. 4 and 4 Bearing Oil Tubes		
Assembly	3-13	3-135	(AVIM)	4-43	4-229
Compressor Bleed Band	2-11	2-40	No. 4 and 5 Bearing Package		
Compressor Housing	2-22	2-120	(AVIM)	4-38	4-177
Compressor Rotor Blades	2-34	2-254	Oil Cooler Assmebly	8-14	8-42
Dual Chip Detector	8-41	8-96	Oil Drain Cock	8-106	8-269
Fireshield Assembly	4-13	4-58	Oil Filler Assembly and Oil Filler		
Fireshield Section	4-17	4-70	Strainer	8-29	8-73
First Turbine Disc Assembly	4-64	4-369	Oil Filter Cover Assembly and		
Flow Divider and Bracket	6-46	6-146	Oil Filter Element	8-35	8-85
Flow Programming Valve	8-20	8-56	Oil Level Float Assembly	8-124	8-313
Fourth Stage Power Turbine			Oil Level Indicator	8-116	8-289
Nozzle	4-47	4-249	Oil Temperature Transmitter	8-24	8-65
Fourth Stage Power Turbine			Output Shaft Seal and Housing		
Rotor	4-34	4-138	Assembly	2-40	2-328
Fuel Boost Pump Assembly	6-9	6-37	Overspeed Drive and Outlet Cover		
Fuel Check Valve	6-50	6-155	Assembly	5-25	5-80
Fuel Drain Valve	3-2	3-5	Overspeed Solenoid Valve	6-53	6-161
Gas Producer Speed Pickup	8-8	8-29	Pressurizing Valve	6-42	6-137
Hydromechanical Assembly			Primary Electrical Harness		
(HMA)	6-2	6-12	Assembly	7-17	7-85
Ignition Coil and Cable Assembly	7-2	7-26	Primer Tube Assembly	6-21	6-92
Ignition Exciter	7-12	7-75	PT Speed Pickup	5-9	5-43
			PT Speed Pickup Drive Assembly	5-14	5-51
			Reversionary Electrical Harness		
			Assembly	7-23	7-115

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Second Turbine Disc Assembly.....	4-55	4-298	Assemble (AVIM).....	3-10	3-123
Second Turbine Nozzle, Spacer, Case, and Bumper	4-59	4-320	Disassemble	3-11	3-133
Spark Igniters	7-7	7-62	Disassemble (AVIM)	3-9	3-117
Start Fuel Nozzles	6-25	6-99	Combustion Section and Power Turbine		
Starter Drive Assembly	5-19	5-61	Assemble (AVIM)	3-7	3-62
Starter Gearbox Filter	8-90	8-239	Disassemble (AVIM)	3-6	3-30
Starting Fuel Solenoid Valve.....	6-58	6-170	Install (AVIM)	3-8	3-96
Stator Vane Assemblies	2-28	2-189	Remove (AVIM)	3-5	3-9
Tailpipe Assembly	4-72	4-422	Common Tools and Equipment.....	1-22	1-47
Thermocouple Harness Assemblies	4-21	4-85	Components, Location and Description of Major - See Location and Description of Major Components		
Thermocouple Jumper Lead	4-2	4-8	Compressor Bleed Band		
Third Stage Power Turbine Rotor...4-51	4-279		Clean.....	2-11	2-40
Third Turbine Nozzle and Support.4-28	4-113		Inspect	2-12	2-41
T1 Temperature Sensor.....	2-53	2-361	Install	2-14	2-43
Torquemeter Sensor.....	9-2	9-6	Remove	2-10	2-37
Clean, Inspect and Repair Splines and Gears	1-109	1-574	Repair	2-13	2-42
Combustion Chamber Housing			Compressor Bleed Band Operation		
Clean	3-19	3-171	Abnormal- Primary Mode	1-47	1-217
Inspect	3-20	3-173	Compressor Bleed Band Operation		
Repair	3-21	3-175	Abnormal - Reversionary Mode	1-48	1-221
Combustion Chamber Liner			Compressor Housing		
Clean	3-16	3-145	Clean	2-22	2-120
Inspect	3-17	3-146	Inspect	2-23	2-121
Repair	3-18	3-158	Install (Upper)	2-25	2-124
Combustion Chamber Vane Assembly			Install (Lower)	2-26	2-154
Clean	3-13	3-135	Remove (Upper)	2-20	2-63
Inspect	3-14	3-136	Remove (Lower)	2-21	2-94
Repair	3-15	3-143	Repair	2-24	2-122
Combustion Section	1-15	1-21	Compressor Rotor Blades		
Combustion Section Assemble.....	3-12	3-134	Clean	2-34	2-254
			Inspect	2-35	2-256

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Install	2-37	2-291	Cooler Assembly, Oil - See Oil Cooler Assembly		
Remove	2-33	2-235	Cover, Anti-Icing Air Gallery - See Anti-Icing Air Gallery Cover		
Repair	2-36	2-286			
Compressor Section	1-14	1-16	Cover Assembly (AVIM), Inlet Housing - See Inlet Housing Cover Assembly (AVIM)		
Compressor Surges.....	1-46	1-214			
Compressor, Wash - See Wash Compressor			D		
Container, Inspect Pressurized Shipping and Storage - See Inspect Pressurized Shipping and Storage Container			Data, Equipment - See Equipment Data		
Container, Install Engine Into Shipping and Storage - See Install Engine Into Shipping and Storage Container			Data, Equipment Description and - See Equipment Description and Data		
Container, Mark Shipping and Storage - See Mark Shipping and Storage Container			Denting, Scratching, Gouging, or Wear, Determine Depth of Damage from Chafing - See Determine Depth of Damage from Chafing, Denting; Scratching, Gouging, or Wear		
Container, Prepare and Inspect Storage and Shipping - See Prepare and Inspect Storage and Shipping Container			Depth of Damage from Chafing, Denting, Scratching, Gouging, or Wear, Determine - See Determine Depth of Damage from Chafing, Denting, Scratching, Gouging, or Wear		
Container, Remove Engine from Shipping and Storage - See Remove Engine from Shipping and Storage Container Data			See Equipment Description and		
Contaminated Fuel System, Inspect See Inspect Contaminated Fuel System			Description of Major Components, Location and - See Location and Description of Major Components		
Contaminated Oil System, Inspect - See Inspect Contaminated Oil System			Designations, Official Nomenclature, Names and - See Official Nomenclatures, Names, and Designations		
Control (QA/QC), Quality Assurance/ Quality - See Quality Assurance/ Quality Control (QA/QC)			Destruction of Army Materiel to Prevent Enemy Use	1-3	1-2

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Determine Depth of Damage from Chafing, Denting, Scratching, Gouging, or wear	1-111	1-587	Disc Assembly (AVIM), First and Second Turbine Disc Assembly, Place in Service Field Replacement - See Place in Service Field Replacement First and Second Turbine Disc Assembly		
Diagrams	G-11	G-9	Display of Fault Codes	G-7	G-4
Diagrams	G-14	G-11	Divider and Bracket, Flow - See Flow Divider and Bracket		
Diffuser Assembly (AVIM), Air - See Air Diffuser Assembly (AVIM)			Drain Cock, Oil - See Oil Drain Cock		
Directional References	1-10	1-10	Drain Engine Oil System	1-69	1-303
Disassemble			Drive Assembly, Starter- See Starter Drive Assembly		
Accessory Gearbox Assembly	5-2	5-12	Dropped Engine, Inspect - See Inspect Dropped Engine		
(AVIM) Combustion Section	3-9	3-117	Dual Chip Detector		
(AVIM) Combustion Section and Power Turbine	3-6	3-30	Assemble	8-44	8-100
Combustion Section.....	3-11	3-133	Clean	8-41	8-96
Dual Chip Detector	8-40	8-94	Disassemble	8-40	8-94
In-Line Fuel Filter Assembly	6-36	6-124	Inspect	8-42	8-97
Interstage Air-Bleed Actuator	2-2	2-11	Install	8-46	8-102
Main Fuel Filter and Bracket	6-29	6-106	Remove	8-39	8-91
Main Oil Pump, Speed Pickup Drive Assembly, Scavenge Oil Screen, and Related Parts	8-2	8-13	Repair.....	8-43	8-99
Oil Cooler Assembly	8-13	8-40	Test.....	8-45	8-101
Oil Filler Assembly and Oil Filler Strainer	8-28	8-71	Dual Chip Detector, Service - See Service Dual Chip Detector		
Oil Level Float Assembly	8-123	8-312	E		
Oil Level Indicator	8-115	8-286	Electrical and Ignition System	1-19	1-36
Overspeed Drive and Outlet Cover Assembly	5-24	5-77	Element, Oil Filter Cover Assembly and Oil Filter - See Oil Filter Cover Assembly and Oil Filter Element		
Tailpipe Assembly	4-71	4-419	Element, Service Oil Filter Cover Assembly and Oil Filter - See		
Third Turbine Nozzle and Support	4-27	4-111			
Disc Assembly (AVIM), First Turbine - See First Turbine Disc Assembly (AVIM)					
Disc Assembly (AVIM), Second Turbine - See Second Turbine Disc Assembly (AVIM)					

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Service Oil Filter Cover Assembly and Oil Filter Element			F		
Enemy Use, Destruction of Army Material to Prevent - See Destruction of Army Material to Prevent Enemy Use			Fault Code AI, Q Sensor Expanded Instructions	G-26	G-49
Engine	1-13	1-13	Fault Code A2, N2 Set Potentiometer Expanded Instructions	G-27	G-52
Engine Does Not Start - Ignition Not Firing	1-36	1-129	Fault Code A3, Collective Pitch Angle LVDT Expanded Instructions	G-28	G-56
Engine Out Indicator (EOI) Does Not Illuminate During Normal Shutdown Expanded Instructions	G-63	G-146	Fault Code A4, NR Sensor Expanded Instructions	G-29	G-59
Engine Out Indicator (EOI) Is Always Illuminated Expanded Instructions	G-69	G-164	Fault Code A5, ECL Resolver Expanded Instructions	G-30	G-62
Equipment Characteristics, Capabilities, and Features	1-8	1-3	Fault Code A6, Airframe Emergency <u>28V DC</u> Expanded Instructions	G-31	G-65
Equipment, Common Tools and - See Common Tools and Equipment			Fault Code A7 (Or No Display), Airframe <u>+28V DC</u> Supply Expanded Instructions	G-32	G-67
Equipment Data	1-11	1-11	Fault Code BC, <u>400 Hz</u> Resolver Reference Expanded Instructions...	G-54	G-122
Erratic or Oscillating N1 Speed While Engine is Governing on N1 - Primary Mode	1-49	1-224	Fault Code B2, N1B Sensor Expanded Instructions	G-47	G-104
Erratic or Oscillating N1 Speed While Engine is Governing on N1 - Reversionary Mode	1-50	1-240	Fault Code B3, N2B Sensor Expanded Instructions	G-48	G-107
Erratic or Oscillating N2, PTIT, Torque, or N1 While Governing on N2	1-51	1-255	Fault Code B4, T4.5 Sensor Expanded Instructions	G-49	G-110
Excessive Chips Found on Oil Filter Element and/or Chip Detectors.....	1-61	1-281	Fault Code B5, Collective Pitch Angle LVDT Expanded Instructions	G-50	G-113
Exciter Ignition - See Ignition Exciter			Fault Code B6, ECL Resolver Expanded Instructions	G-51	G-116
Expendable Supplies And Material List.....	C-1		Fault Code 7, PLA Potentiometer Expanded Instructions	G-52	G-120
			Fault Code CF, Loss Of Load Share Signals Expanded Instructions	G-46	G-101

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Fault Code C9, N1 B (0) Sensor Signals From Other DECU Expanded Instructions	G-45	G-99	Fault Code F5 Wf/Stepcount Difference Expanded Instructions	G-19	G-27
Fault Code De, 400 Hz Resolver Reference Expanded Instructions.....	G-37	G-75	Fault Code F6, PLA Potentiometer Expanded Instructions	G-20	G-30
Fault Code D1, P3 Transducer Expanded Instructions	G-35	G-71	Fault Code F7, Bleed Valve Solenoid Expanded Instructions	G-21	G-34
Fault Code D2, P1 Transducer Expanded Instructions	G-36	G-72	Fault Code F8, Primary/Reversionary Solenoid Expanded Instructions	G-22	G-37
Fault Code E1, T4.5 Sensor Expanded Instructions	G-38	G-79	Fault Code F9, Alternator Expanded Instructions	G-23	G-40
Fault Code E2, T1 Sensor Expanded Instructions	G-39	G-83	Fault Codes B9, BA, BB, Internal DECU Faults Expanded Instructions	G-53	G-121
Fault Code E3, N2A Sensor Expanded Instructions	G-40	G-87	Fault Codes C1-C3, C5-C8, Communication Line Faults Expanded Instructions	G-43	G-95
Fault Code E4, N2B Sensor Expanded Instructions	G-41	G-90	Fault Codes C4, Communication Line Fault Q (0) Signal Expanded Instructions	G-44	G-97
Fault Code E5, N2A/N2B Sensor Expanded Instructions	G-42	G-93	Fault Codes DO, D3, D6, DA, DB, DD Internal DECU Faults Expanded Instructions	G-33	G-69
Fault Code FB, Reversionary Step Count Expanded Instructions	G-25	G-46	Fault Codes D4, D5, D7, D8, D9, DC, DF Internal DECU Faults Expanded Instructions	G-34	G-69
Fault Code FA, Start Fuel Solenoid Expanded Instructions	G-24	G-43	Fault Codes Not Defined In Table 1 Expanded Instructions	G-72	G-170
Fault Code F1, N1A Sensor Expanded Instructions	G-15	G-14	Fault Code 10-1F, Internal DECU Faults	G-55	G-123
Fault Code F2, N1 B Sensor Expanded Instructions	G-16	G-17	Fault Isolation	G-6	G-3
Fault Code F3, N1A/N1B Difference Expanded Instructions	G-17	G-20	Fault Trees.....	G-13	G-11
Fault Code F4, MV Potentiometer Expanded Instructions	G-18	G-23	Features, Equipment Characteristics, Capabilities, and - See Equipment Characteristics, Capabilities, and Features		

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Field Replacement First and Second Turbine Disc Assembly Place in Service Field Replacement First and Second Turbine Disc Assembly (AVIM)	4-69	4-407	Filter, Service No. 4 and 5 Bearing Oil Filter - See Service No. 4 and 5 Bearing Oil Filter		
			Firesield Assembly		
Filler Assembly and Oil Filler Strainer, Oil - See Oil Filler Assembly and Oil Filler Strainer			Clean	4-13	4-58
			Inspect	4-14	4-59
			Install	4-15	4-60
			Remove	4-12	4-55
Filler Strainer, Oil Filler Assembly and Oil - See Oil Filler Assembly and Oil Filler Strainer					
			Firesield Section		
Filler Strainer, Service Oil - See Service Oil Filler Strainer			Clean	4-17	4-70
			Inspect	4-18	4-71
			Install	4-19	4-72
			Remove	4-16	4-65
Filter and Bracket, Main Fuel - See Main Fuel Filter and Bracket					
			First and Second Turbine Disc Assembly (AVIM), Place in Service Field Replacement - See Place in Service Field Replacement First and Second Turbine Disc Assembly (AVIM)		
Filter Assembly, In-Line Fuel - See In-Line Fuel Filter Assembly					
			First Turbine Disc Assembly		
Filter Cover Assembly and Oil Filter Element, Oil - See Oil Filter Cover Assembly and Oil Filter Element			Clean	4-64	4-369
			Inspect	4-65	4-370
			Install	4-67	4-373
			Remove	4-63	4-361
			Repair	4-66	4-372
Filter Element, Oil Filter Cover Assembly and Oil - See Oil Filter Cover Assembly and Oil Filter Element					
			First Turbine Rotor Case Repair	4-68	4-389
Filter Element, Service Oil Filter Cover Assembly and Oil - See Service Oil Filter Cover Assembly and Oil Filter Element					
			Flameout	1-52	1-257
Filter, No. 4 and 5 Bearing - See No. 4 and 5 Bearing Filter					
			Float Assembly (AVIM), Oil Level - See Oil Level Float Assembly (AVIM)		

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Flow Divider and Bracket			Install	6-12	6-42
Clean	6-46	6-146	Remove	6-8	6-35
Inspect	6-47	6-147	Repair	6-11	6-39
Install	6-48	6-148	Fuel Boost Pump Assembly - Preparation for Storage or Shipment		
Remove	6-45	6-143	Package	6-14	6-48
Flow Programming Valve			Preserve	6-13	6-47
Clean	8-20	8-56	Fuel Check Valve		
Inspect	8-21	8-57	Clean	6-50	6-155
Install	8-22	8-58	Install	6-51	6-156
Remove	8-19	8-53	Remove	6-49	6-153
Foreign Object Ingestion, Inspect Engine after - See Inspect Engine after Foreign Object Ingestion			Fuel Drain Valve		
Forms, Records and Reports, Maintenance - See Maintenance Forms, Records and Reports			Clean	3-2	3-5
Fourth Stage Power Turbine Nozzle			Inspect	3-3	3-6
Clean	4-47	4-249	Install	3-4	3-7
Inspect	4-48	4-250	Remove	3-1	3-3
Install	4-50	4-259	Fuel Filter and Bracket, Main - See Main Fuel Filter and Bracket		
Repair	4-49	4-257	Fuel Filter Assembly, In-Line-See In-Line Fuel Filter Assembly		
Fourth Stage Power Turbine Rotor			Fuel Lines - See Hose Assembly and Tube Assembly		
Clean	4-34	4-138	Fuel Manifold Assemblies - See Left- and Right-Hand Fuel Manifold Assemblies		
Inspect	4-35	4-139	Fuel Nozzles, Start - See Start Fuel Nozzles		
Install	4-36	4-143	Fuel Solenoid Valve, Starting - See Starting Fuel Solenoid Valve		
Remove	4-33	4-131	Fuel System	1-18	1-32
F/R Lamp Does Not Illuminate When Reversion Is Selected Expanded Instructions	G-70	G-166	Fuel System, Inspect Contaminated - See Inspect Contaminated Fuel System		
F/R Lamp Is Illuminated When Primary Is Selected Expanded Instructions	G-71	G-168	Functional Groups (Columns 1 And 2).....	B-4	B-5
Fuel Boost Pump Assembly					
Clean	6-9	6-37			
Inspect	6-10	6-38			

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
G			H		
G-Loads, Inspect Engine Subjected to Excessive - See Inspect Engine Subjected to Excessive G-Loads			Handling, Safety, Care and - See Safety, Care, and Handling		
Gallery Cover, Anti-icing Air - See Anti-Icing Air Gallery Cover			Harness Assembly, Accessory Electrical - See Accessory Electrical Harness Assembly		
Gas Producer Speed Pickup			Harness Assembly, Primary Electrical - See Primary Electrical Harness Assembly		
Clean	8-8	8-29	Harness Assembly, Reversionary Electrical - See Reversionary Electrical Harness Assembly		
Inspect	8-9	8-30	Harness Assemblies (AVIM), Thermocouple - See Thermocouple Harness Assemblies (AVIM)		
Install	8-11	8-32	High Fuel Consumption	G-5	G-2
Remove	8-7	8-27	High Oil Consumption (More Than 2 Quarts Per Hour)	1-63	1-285
Repair	8-10	8-31	High Oil Temperature Indication	1-58	1-277
Gears, Clean, Inspect and Repair Splines and - See Clean, Inspect and Repair Splines and Gears			High Oil Temperature Indication - Visual Check	1-57	1-276
Gearbox Assembly, Accessory - See Accessory Gearbox Assembly			High or Erratic PTIT	1-62	1-282
General Information	1-1	1-1	Hoisting.....		1-111
Glossary	Glossary-1		Hose Assembly (Accessory Gearbox Assembly to Oil Cooler)		
Ground Idle Speed is Incorrect - Primary Mode	1-42	1-164	Install	8-52	8-117
Ground Idle Speed is Incorrect - Reversionary Mode	1-43	1-177	Remove	8-51	8-115
			Hose Assembly (Air Diffuser Assembly to HMA)		
			Install	2-64	2-390
			Remove	2-63	2-388

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Hose Assembly (Check Valve to Inter-stage Air-Bleed Actuator P3 Inlet)			Install	6-73	6-206
Install	2-66	2-394	Remove	6-72	6-202
Remove	2-65	2-392			
Hose Assembly (Compressor Housing to Inlet Housing)			Hose Assembly (Fuel Flow Divider to Fuel Check Valve)		
Install	2-62	2-383	Install	6-75	6-214
Remove	2-61	2-377	Remove	6-74	6-210
Hose Assembly (Dual Chip Detector to Accessory Gearbox Assembly)					
Install	8-58	8-132	Hose Assembly (Fuel Flow Divider Left Side Primary to Manifold Assembly)		
Remove	8-57	8-127	Install	6-77	6-220
Hose Assembly (Dual Chip Detector to Accessory Gearbox Collector)			Remove	6-76	6-218
Install	8-60	8-138			
Remove	8-59	8-136	Hose Assembly (Fuel Flow Divider Left Side Secondary to Manifold Assembly)		
Hose Assembly (Dual Chip Detector to Air Diffuser Assembly)			Install	6-81	6-228
Install	8-62	8-142	Remove	6-80	6-226
Remove	8-61	8-140			
Hose Assembly (Flow Programming Valve to Inflight Filling Port Tee)			Hose Assembly (Fuel Flow Divider Right Side Primary to Manifold Assembly)		
Install	8-50	8-113	Install	6-79	6-224
Remove	8-49	8-111	Remove	6-78	6-222
Hose Assembly (Flow Programming Valve Tee to Inlet Housing)					
Remove	8-47	8-107	Hose Assembly (Fuel Flow Divider Right Side Secondary to Manifold Assembly)		
Install	8-48	8-109	Install	6-83	6-233
Hose Assembly (Flow Programming Valve Tee to No. 2 Bearing Pressure Connector)			Remove	6-82	6-230
Instal	8-56	8-125			
Remove	8-55	8-123			
Hose Assembly (Fuel Boost Pump to Main Fuel Filter)					

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Hose Assembly (HMA to Aircraft Bulk-head)			Hose Assembly (Main Oil Pump to Dual Chip Detector)		
Remove	2-71	2-404	Install	8-64	8-146
Install	2-72	2-407	Remove	8-63	8-144
Hose Assembly (HMA to Oil Cooler)			Hose Assembly (Oil Cooler to Flow Programming Valve)		
Install	6-65	6-186	Install	8-54	8-121
Remove	6-64	6-183	Remove	8-53	8-119
Hose Assembly (HMA to Starting Fuel Solenoid Valve)			Hose Assembly (Oil Cooler to In-Line Fuel Filter)		
Install	6-87	6-245	Install	6-63	6-180
Remove	6-86	6-242	Remove	6-62	6-177
Hose Assembly (Hose Assembly to Primer Tube Assembly)			Hose Assembly (Overspeed Solenoid Valve to Pressurizing Valve)		
Install	6-91	6-261	Install	6-69	6-196
Remove	6-90	6-256	Remove	6-68	6-194
Hose Assembly (In-Line Fuel Filter to Overspeed Solenoid Valve)			Hose Assembly (Pressure Connector to No. 4 and 5 Bearing Filter)		
Install	6-67	6-192	Install	8-76	8-190
Remove	6-66	6-190	Remove	8-75	8-179
Hose Assembly (Interstage Air-Bleed Actuator to HMA)			Hose Assembly (Pressurizing Valve to Fuel Flow Divider Return Tee)		
Install	2-58	2-370	Install	6-71	6-200
Remove	2-57	2-367	Remove	6-70	6-198
Hose Assembly (Inlet Housing to Oil Scavenge Tee)			Hose Assembly (Starter Drive to Oil Filler)		
Install	8-78	8-203	Install	8-82	8-213
Remove	8-77	8-201	Remove	8-81	8-211
Hose Assembly (Inlet Housing to Oil Drain Cock)			Hose Assembly (Starter Drive to Tube and Hose Assembly)		
Install	8-80	8-208	Install	8-84	8-217
Remove	8-79	8-205	Remove	8-83	8-215
Hose Assembly (Main Fuel Filter to HMA)			Hose Assembly (Starting Fuel Solenoid Valve to Tube Assembly)		
Install	6-85	6-239	Install	6-89	6-252
Remove	6-84	6-236	Remove	6-88	6-248

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Hose Assembly (Water Wash Tee Check Valve to Interstage Air- Bleed Actuator PM Inlet)			Hydromechanical Assembly (HMA) - Preparation for Storage or Shipment Package	6-7	6-32
Install	2-70	2-402	Preserve	6-6	6-27
Remove	2-69	2-400			
I					
Hose Assembly (Water Wash Tee Check Valve to Interstage Air- Bleed Actuator P3 Inlet)			Identification, Engine - See Engine Identification		
Install	2-68	2-398	Igniters, Spark - See Spark Igniters		
Remove	2-67	2-396	Ignition Coil and Cable Assembly		
Hoses, Install Spiral Chafing Sleeve on - See Install Spiral Chafing Sleeve on Hoses			Clean	7-2	7-26
			Inspect	7-3	7-28
			Install	7-5	7-36
			Remove	7-1	7-3
			Repair	7-4	7-31
Hot End (AVIM), Inspect Engine - See Inspect Engine Hot End (AVIM)			Ignition Exciter		
Housing (AVIM), Combustion Chamber - See Combustion Chamber Housing (AVIM)			Clean	7-12	7-75
Housing, Compressor- See Compressor Housing			Inspect	7-13	7-76
			Install	7-15	7-78
			Remove	7-11	7-71
			Repair	7-14	7-77
Housing Cover Assembly (AVIM), Inlet - See Inlet Housing Cover Assembly (AVIM)			Ignition Relay Does Not Function Expanded Instructions	G-61	G-142
Hot Hung or Torching Starts - Primary Mode	1-40	1-148	Ignition System, Electrical and - See Electrical and Ignition System		
Hot Hung or Torching Start - Reversionary Mode	1-41	1-161	Illustrated List of Manufactured Items		E-i
Hydromechanical Assembly (HMA)			Improvement Recommendations (EIR), Reporting Equipment - See Reporting Equipment Improvement Recommendations (EIR)		
Clean	6-2	6-12	Index, Symptom - See Symptom Index		
Inspect	6-3	6-13	Indicator, Oil Level - See Oil Level Indicator		
Install	6-5	6-17			
Remove	6-1	6-5			
Repair	6-4	6-15			

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Information, General - See General Information			Dual Chip Detector	8-42	8-97
Ingestion, Inspect Engine After Foreign Object - See Inspect Engine After Foreign Object Ingestion			Fireshield Assembly	4-14	4-59
Inlet Housing Assembly (AVIM), Air - See Air Inlet Housing Assembly (AVIM)			Fireshield Section	4-18	4-71
Inlet Housing Cover Assembly			First Turbine Disc Assembly	4-65	4-370
Clean	2-45	2-348	Flow Divider and Bracket	6-47	6-147
Inspect	2-46	2-349	Flow Programming Valve	8-21	8-57
Install	2-48	2-351	Fourth Stage Power Turbine Nozzle	4-48	4-250
Remove	2-44	2-345	Fourth Stage Power Turbine Rotor	4-35	4-139
Repair	2-47	2-350	Fuel Boost Pump Assembly	6-10	6-38
In-Line Fuel Filter Assembly			Fuel Drain Valve	3-3	3-6
Assemble	6-39	6-128	Gas Producer Speed Pickup	8-9	8-30
Clean	6-37	6-126	Hydromechanical Assembly (HMA)	6-3	6-13
Disassemble	6-36	6-124	Ignition Coil and Cable Assembly	7-3	7-28
Inspect	6-38	6-127	Ignition Exciter	7-13	7-76
Install	6-40	6-130	Inlet Housing Cover Assembly	2-46	2-349
Remove	6-35	6-121	In-Line Fuel Filter Assembly	6-38	6-127
Inspect			Interstage Air-Bleed Actuator	2-4	2-14
Accessory Electrical Harness Assembly	7-30	7-144	Left- and Right-Hand Bus Bar Assemblies	4-9	4-33
Accessory Gearbox Assembly	5-4	5-20	Main Fuel Filter and Bracket	6-31	6-110
Air Inlet Housing Assembly	2-50	2-356	Main Oil Pump, Speed Pickup Drive Assembly, Scavenge Oil Screen, and Related Parts	8-4	8-16
Anti-Icing Air Gallery Cover	2-17	2-52	No. 2 Bearing Pressure Oil Connector	8-95	8-246
Chip Detector	8-111	8-277	No. 2 Bearing Pressure Oil Strainer	8-99	8-250
Combustion Chamber Housing	3-20	3-173	No. 4 and 5 Bearing Filter	8-103	8-260
Combustion Chamber Liner	3-17	3-146	Oil Cooler Assembly	8-15	8-43
Combustion Chamber Vane Assembly	3-14	3-136	Left- and Right-Hand Fuel Manifold Assemblies	6-17	6-61
Compressor Bleed Band	2-12	2-41	Oil Drain Cock	8-107	8-270
Compressor Housing	2-23	2-121	Oil Filler Assembly and Oil Filler Strainer	8-30	8-75
Compressor Rotor Blades	2-35	2-256	Oil Filter Cover Assembly and Oil Filter Element	8-36	8-86
			Oil Level Float Assembly	8-125	8-314
			Oil Level Indicator	8-117	8-290

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Oil Temperature Transmitter	8-25	8-66	Inspect Dropped Engine	1-77	1-327
Output Shaft Seal and Housing Assembly	2-41	2-329	Inspect Engine After Check Runs	1-85	1-376
Overspeed Drive and Outlet Cover Assembly	5-26	5-81	Inspect Engine After Compressor Stall (Surge)	1-84	1-374
Overspeed Solenoid Valve	6-54	6-162	Inspect Engine After Foreign Object Ingestion	1-86	1-377
Pressurizing Valve	6-43	6-138	Inspect Engine After N1 Overspeed (AVIM)	1-73	1-319
Primary Electrical Harness As- sembly	7-18	7-87	Inspect Engine After N2 Overspeed (AVIM)	1-74	1-321
Primer Tube Assembly	6-22	6-93	Inspect Engine After Power Turbine Overtorque (AVIM)	1-78	1-331
PT Speed Pickup	5-10	5-44	Inspect Engine Hot End (AVIM)	1-87	1-381
PT Speed Pickup Drive Assembly	5-15	5-52	Inspect Engine Subjected to Exces- sive G-Loads	1-76	1-325
Reversionary Electrical Harness Assembly	7-24	7-116	Inspect Pressurized Shipping and Storage Container	1-25	1-50
Second Turbine Disc Assembly	4-56	4-299	Install Accessory Electrical Harness Assembly	7-33	7-156
Second Turbine Nozzle, Spacer, Case, and Bumper	4-60	4-322	Accessory Gearbox Assembly	5-7	5-28
Second Turbine Nozzle, Spacer, Case, and Bumper	7-8	7-63	Anti-Icing Air Gallery Cover	2-19	2-56
Start Fuel Nozzles	6-26	6-100	Chip Detector	8-113	8-280
Starter Drive Assembly	5-20	5-62	(AVIM) Combustion Section and Power Turbine	3-8	3-96
Starter Gearbox Filter	8-91	8-240	Compressor Bleed Band	2-14	2-43
Starting Fuel Solenoid Valve	6-59	6-171	(Upper) Compressor Housing	2-25	2-124
Stator Vane Assemblies	2-29	2-190	(Lower) Compressor Housing	2-26	2-154
Tailpipe Assembly	4-73	4-423	Compressor Rotor Blades	2-37	2-291
Thermocouple Harness Assemblies.....	4-22	4-86	Dual Chip Detector	8-46	8-102
Thermocouple Jumper Lead	4-3	4-9	Fireshield Assembly	4-15	4-60
Third Stage Power Turbine Rotor	4-52	4-280	Fireshield Section	4-19	4-72
Third Turbine Nozzle and Support	4-29	4-114	First Turbine Disc Assembly	4-67	4-373
T1 Temperature Sensor	2-54	2-362	Flow Divider and Bracket	6-48	6-148
Torquemeter Sensor	9-3	9-7			
Inspect and Repair Splines and Gears, Clean - See Clean, Inspect and Repair Splines and Gears					
Inspect Contaminated Fuel System	1-79	1-333			
Inspect Contaminated Oil System	1-80	1-340			

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Flow Programming Valve	8-22	8-58	Overspeed Drive and Outlet Cover Assembly	5-29	5-87
Fourth Stage Power Turbine			Overspeed Solenoid Valve	6-56	6-164
Nozzle	4-50	4-259	Pressurizing Valve	6-44	6-139
Fourth Stage Power Turbine			Primary Electrical Harness As- sembly	7-21	7-105
Rotor	4-36	4-143	Primer Tube Assembly	6-23	6-94
Fuel Boost Pump Assembly	6-12	6-42	PT Speed Pickup	5-12	5-46
Fuel Check Valve	6-51	6-156	PT Speed Pickup Drive Assembly ...	5-17	5-54
Fuel Drain Valve	3-4	3-7	Reversionary Electrical Harness Assembly	7-27	7-131
Gas Producer Speed Pickup	8-11	8-32	Second Turbine Disc Assembly	4-57	4-301
Hydromechanical Assembly (HMA)	6-5	6-17	Second Turbine Nozzle, Spacer		
Ignition Coil and Cable Assembly	7-5	7-36	Case, and Bumper.....	4-62	4-354
Ignition Exciter	7-15	7-78	Second Turbine Nozzle, Spacer		
Inlet Housing Cover Assembly	2-48	2-351	Case, and Bumper	7-10	7-65
In-Line Fuel Filter Assembly	6-40	6-130	Start Fuel Nozzles	6-27	6-101
Interstage Air-Bleed Actuator	2-8	2-20	Starter Drive Assembly	5-22	5-70
Left- and Right-Hand Bus Bar Assemblies	4-11	4-41	Starter Gearbox Filter	8-92	8-241
Left- and Right-Hand Fuel Manifold Assemblies	6-19	6-68	Starting Fuel Solenoid Valve	6-61	6-173
Main Fuel Filter and Bracket	6-34	6-118	(First Stage) Stator Vane Assemblies	2-31	2-194
Main Oil Pump, Speed Pickup Drive Assembly, Scavenge Oil Screen, and Related Parts	8-6	8-18	(Second thru Seventh Stage) Stator Vane Assemblies	2-32	2-215
No. 2 Bearing Pressure Oil Connector.....	8-96	8-247	Tailpipe Assembly	4-76	4-430
No. 2 Bearing Pressure Oil Strainer	8-100	8-253	Thermocouple Harness		
No. 4 and 5 Bearing Filter	8-104	8-261	Assemblies	4-25	4-95
Oil Cooler Assembly	8-18	8-47	Third Turbine Nozzle and Support... 4-32	4-32	4-125
Oil Drain Cock	8-108	8-271	T1 Temperature Sensor	2-56	2-364
Oil Filler Assembly and Oil Filler Strainer	8-33	8-80	Torquemeter Sensor	9-5	9-9
Oil Filter Cover Assembly and Oil Filter Element	8-38	8-88	Install Engine Into Shipping and Storage Container	1-104	1-537
Oil Level Float Assembly	8-128	8-318	Install Engine Maintenance Sling	1-31	1-112
Oil Level Indicator	8-120	8-298	Install Engine on Maintenance Stand	1-29	1-103
Oil Temperature Transmitter	8-26	8-67	Install Spiral Chafing Sleeve on Hoses	1-112	1-592
Output Shaft Seal and Housing Assembly	2-43	2-338			

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Insulation/Voltage Check Expanded Instructions	G-73	G-172	Remove	4-7	4-25
			Test	4-10	4-34
Interstage Air-Bleed Actuator			Left- and Right-Hand Fuel Manifold Assemblies		
Adjust	2-9	2-26	Clean	6-16	6-60
Assemble	2-6	2-16	Inspect	6-17	6-61
Clean	2-3	2-13	Install	6-19	6-68
Disassemble	2-2	2-11	Remove	6-15	6-49
Inspect	2-4	2-14	Repair	6-18	6-63
Install	2-8	2-20	Level Float Assembly (AVIM), Oil - See Oil Level Float Assembly (AVIM)		
Remove	2-1	2-5	Level Indicator, Oil - See Oil Level Indicator		
Repair	2-5	2-15	Limits, Standard Torque - See Standard Torque Limits		
Test	2-7	2-18	Liner (AVIM), Combustion Chamber - See Combustion Chamber Liner (AVIM)		
J			Location and Description of Major Components	1-9	1-5
Jumper Lead, Thermocouple, See Thermocouple Jumper Lead			Lubricating Oil, Change from MIL-L-7808 to MIL-L-23699 - See Change from MIL-L-7808 to MIL-L-23699 Lubricating Oil		
L			Lubricating Oil, Change from MIL-L-23699 to MIL-L-7808 - See Change from MIL-L-23699 to MIL-L-7808 Lubricating Oil		
Lead, Thermocouple Jumper- See Thermocouple Jumper Lead			Lubrication System	1-20	1-40
Leakage, Check for Static Oil - See Check for Static Oil Leakage			M		
Leakage (No. 2 Bearing Package) (AVIM), Check for Seal - See Check for Seal Leakage (No. 2 Bearing Package) (AVIM)			Magnesium Alloys, Touch Up Magnesium and - See Touch Up Magnesium and Magnesium Alloys		
Leakage (No. 4 and 5 Bearing) (AVIM), Check for Seal - See Check for Seal					
Leakage (No. 4 and 5 Bearing) (AVIM) Left- and Right-Hand Bus Bar Assemblies					
Left- and Right-Hand Bus Bar Assemblies					
Clean	4-8	4-32			
Inspect	4-9	4-33			
Install	4-11	4-41			

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Magnesium and Magnesium Alloys, Touch Up - See Touch Up Magnesium and Magnesium Alloys			Maintenance Practices, Standard - See Standard Maintenance Practices		
Main Fuel Filter and Bracket			Maintenance Procedures		1-487
Assemble	6-33	6-115	Maintenance Sling, Install Engine - See Install Engine Maintenance Sling		
Clean	6-30	6-109	Maintenance Sling, Remove Engine - See Remove Engine Maintenance Sling		
Disassemble	6-29	6-106	Maintenance Stand, Install Engine on - See Install Engine on Maintenance Stand		
Inspect	6-31	6-110	Maintenance Stand, Remove Engine from - See Remove Engine from Maintenance Stand		
Install	6-34	6-118	Major Components, Location and Description of - See Location and Description of Major Components		
Remove	6-28	6-103	Manifold Assemblies - See Left- and Right-Hand Fuel Manifold Assemblies		
Repair	6-32	6-114	Manufactured Items, Illustrated List of - See Illustrated List of Manufactured Items		
Main Oil Pump, Speed Pickup Drive Assembly, Scavenge Oil Screen, and Related Parts			Mark Shipping and Storage Container....	1-105	1-558
Assemble	8-5	8-17	Materials List, Expendable Supplies and - See Expendable Supplies and Materials List		
Clean	8-3	8-14	Minor Servicing	1-88	1-431
Disassemble	8-2	8-13	Months, Represerve Engine in Storage Over Six - See Reserve Engine in Storage Over Six Months		
Inspect	8-4	8-16	Moving ECL To Flight Causes Decrease In Engine Power Expanded Instructions	G-68	G-161
Install	8-6	8-18			
Remove	8-1	8-7			
Maintenance Allocation Chart		B-1			
Maintenance Categories And Work Times (Column 4)	B-6	B-6			
Maintenance Checks and Services, Preventive - See Preventive Maintenance Checks and Services					
Maintenance Forms, Records, and Reports	1-2	1-1			
Maintenance Function (Column 3)	B-5	B-6			
Maintenance Functions	B-3	B-3			

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Moving ECL To Stop Causes Increase In Engine Power Expanded Instructions	G-67	G-157	Clean No. 4 and 5 Bearing Oil Tubes (AVIM).....	4-43	4-229
N			Clean No. 4 and 5 Bearing Package (AVIM)	4-38	4-177
Names, and Designations, Official Nomenclature - See Official Nomenclature, Names and Designations			Inspect No. 4 and 5 Bearing Oil Tubes (AVIM)	4-44	4-230
No Beeper Switch Response In Reversion Expanded Instructions	G-65	G-152	Inspect No. 4 and 5 Bearing Package (AVIM)	4-39	4-178
No Lightoff or Lean Hung Start - Reversionary Mode	1-39	1-146	Install No. 4 and 5 Bearing Oil Tubes (AVIM)	4-45	4-231
No Lightoff or Lean Hung Start - Visual Check	1-37	1-132	Install No. 4 and 5 Bearing Package Seals (AVIM)	4-40	4-179
No Observed Engine Speed Reduction During Overspeed Test Expanded Instructions	G-64	G-149	Pressure Test No. 4 and 5 Bearing Oil Tubes and Bearing Package (AVIM)	4-41	4-218
No. 2 Bearing Pressure Oil Connector Clean	8-94	8-245	Remove	4-46	4-247
Inspect	8-95	8-246	Remove No. 4 and 5 Bearing Oil Tubes (AVIM).....	4-42	4-226
Install	8-96	8-247	Remove No. 4 and 5 Bearing Package Seals (AVIM)	4-37	4-165
Remove	8-93	8-243	N2 Overspeed With No Load Loss	1-64	1-286
No. 2 Bearing Pressure Oil Strainer Clean	8-98	8-249	N2 Overspeed System Test Failure	1-65	1-289
Inspect	8-99	8-250	Nomenclature, Names and Designations, Official - See Official Nomenclature, Names, and Designations		
Install	8-100	8-253	Nozzle and Support (AVIM), Third Turbine - See Third Turbine Nozzle and Support (AVIM)		
Remove	8-97	8-249	Nozzle (AVIM), First Turbine - See First Turbine Nozzle (AVIM)		
No. 4 and 5 Bearing Filter Clean	8-102	8-259	Nozzle (AVIM), Fourth Stage Power Turbine - See Fourth Stage Power Turbine Nozzle (AVIM)		
Inspect	8-103	8-260	Nozzle, Spacer, and Case (AVIM), Second Turbine - See Second Turbine Nozzle, Spacer, Case and Bumper (AVIM)		
Install	8-104	8-261	Nozzles, Start Fuel - See Start Fuel Nozzles		
Remove	8-101	8-255			
No. 4 and 5 Bearing Package					

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
0			Repair	8-37	8-87
Object Ingestion, Inspect Engine after Foreign - See Inspect Engine after Foreign Object Ingestion			Oil Filter, Service No. 4 and 5 Bearing - See Service No. 4 and 5 Bearing Oil Filter		
Official Nomenclature, Names and Designations	1-6	1-2	Oil Leakage, Check for Static - See Check for Static Oil Leakage		
Oil Cooler Assembly			Oil Level Float Assembly		
Assemble.....	8-17	8-45	Assemble	8-127	8-316
Clean	8-14	8-42	Clean	8-124	8-313
Disassemble	8-13	8-40	Disassemble	8-123	8-312
Inspect	8-15	8-43	Inspect	8-125	8-314
Install	8-18	8-47	Install	8-128	8-318
Remove	8-12	8-35	Remove	8-122	8-309
Repair	8-16	8-44	Repair	8-126	8-315
Oil Drain Cock			Oil Level Indicator		
Clean	8-106	8-269	Adjust	8-121	8-303
Inspect	8-107	8-270	Assemble	8-119	8-293
Install	8-108	8-271	Clean	8-116	8-289
Remove	8-105	8-267	Disassemble	8-115	8-286
Oil Filler Assembly and Oil Filler Strainer			Inspect	8-117	8-290
Assemble	8-32	8-78	Install	8-120	8-298
Clean	8-29	8-73	Remove	8-114	8-283
Disassemble	8-28	8-71	Repair	8-118	8-292
Inspect	8-30	8-75	Oil Lines - See Hose Assembly and Tube Assembly		
Install	8-33	8-80	Oil Pressure Fluctuation (Total Needle Oscillation of More Than 10 PSI)	1-56	1-274
Remove	8-27	8-69	Oil Pressure Fluctuation (Total Needle Oscillation of More Than 10 PSI) - Visual Check	1-55	1-273
Repair	8-31	8-77	Oil Pressure Indicating Low or High	1-54	1-270
Oil Filter Cover Assembly and Oil Filter Element			Oil Pressure Indicating Low or High - Visual Check	1-53	1-268
Clean	8-35	8-85	Oil Pump and Scavenge Oil Screen, Main - See Main Oil Pump and Scavenge Oil Screen		
Inspect	8-36	8-86			
Install	8-38	8-88			
Remove	8-34	8-83			

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Oil Screen, Main Oil Pump and Scavenge - See Main Oil Pump and Scavenge Oil Screen			Overspeed (AVIM), Inspect Engine after N2 - See Inspect Engine after N2 Overspeed (AVIM)		
Oil Screen, Service Scavenge - See Service Scavenge Oil Screen			Overspeed Drive and Outlet Cover Assembly		
Oil Strainer, No. 2 Bearing Pressure - See No. 2 Bearing Pressure Oil Strainer			Assemble	5-28	5-84
Oil Strainer, Service No. 2 Bearing Pressure - See Service No. 2 Bearing Pressure Oil Strainer			Backlash	5-30	5-90
			Clean	5-25	5-80
			Disassemble	5-24	5-77
			Inspect	5-26	5-81
			Install	5-29	5-87
			Remove	5-23	5-75
			Repair	5-27	5-83
Oil System, Drain Engine - See Drain Engine Oil System			Overspeed Solenoid Valve		
Oil Temperature Transmitter			Clean	6-53	6-161
Clean	8-24	8-65	Inspect.....	6-54	6-162
Inspect	8-25	8-66	Install	6-56	6-164
Install	8-26	8-67	Remove	6-52	6-159
Remove	8-23	8-63	Repair	6-55	6-163
Oil Tubes (AVIM), No. 4 and 5 Bearing - See No. 4 and 5 Bearing Oil Tubes (AVIM)			Overtorque (AVIM), Inspect Engine after Power Turbine - See Inspect Engine after Power Turbine Overtorque (AVIM)		
Operational Problems Without Codes	G-9	G-8			
Output Shaft Seal and Housing Assembly			P		
Clean.....	2-40	2-328	Package		
Inspect	2-41	2-329	Fuel Boost Pump Assembly	6-14	6-48
Install	2-43	2-338	Hydromechanical Assembly (HMA)	6-7	6-32
Remove	2-39	2-325	Parts, Repair - See Repair Parts		
Repair	2-42	2-330	Place in Service Field Replacement First and Second Turbine Disc Assembly (AVIM)		
Overhaul and Retirement Schedule	1-98	1-485	Post Shutdown Rumble or Relight	1-67	1-295
Overspeed (AVIM), Inspect Engine after N1 - See Inspect Engine after N1 Overspeed (AVIM)			Power Limited - Primary Mode	1-44	1-190
			Power Limited - Reversionary Mode	1-45	1-202

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Power Supply Interrupt	G-8	G-7	Pressure Oil Strainer, No. 2 Bearing - See No. 2 Bearing Pressure Oil Strainer		
Power Turbine (AVIM), Combustion Section and - See Combustion Section and Power Turbine (AVIM)			Pressure Oil Strainer, Service No. 2 Bearing - See Service No. 2 Bearing Pressure Oil Strainer		
Power Turbine Nozzle (AVIM), Fourth stage - See Fourth stage Power Turbine Nozzle (AVIM)			Pressure Test Interstage Air-Bleed Actuator	1-100	1-496
Power Turbine Overtorque (AVIM), Inspect Engine after - See Inspect Engine after Power Turbine Overtorque (AVIM)			Pressurized Shipping and Storage Container, Inspect - See Inspect Pressurized Shipping and Storage Container		
Power Turbine Rotor (AVIM), Fourth Stage - See Fourth Stage Power Turbine Rotor (AVIM)			Pressurizing Valve Clean	6-42	6-137
Power Turbine Rotor (AVIM), Third Stage - See Third Stage Power Turbine Rotor (AVIM)			Inspect.....	6-43	6-138
Practices and Procedures, Standard - See Standard Practices and Procedures			Install	6-44	6-139
Practices, Standard Maintenance - See Standard Maintenance Practices			Remove	6-41	6-135
Preparation for Storage and Ship- ment	1-4	1-2	Prevent Enemy Use, Destruction of Army Material to - See Destruction of Army Material to Prevent Enemy Use		
Prepare and Inspect Shipping and Storage Container	1-103	1-530	Preventive Maintenance Checks and Services		
Preserve Fuel Boost Pump Assembly	6-13	6-47	Primary Electrical Harness Assembly Clean	7-17	7-85
Hydromechanical Assembly (HMA)	6-6	6-27	Inspect	7-18	7-87
Preserve and Prepare Engine for Ship- ment or Storage	1-102	1-510	Install	7-21	7-105
			Remove	7-16	7-81
			Repair	7-19	7-89
			Test.....	7-20	7-90
			Primer Tube Assembly Clean	6-21	6-92
			Inspect	6-22	6-93
			Install	6-23	6-94
			Remove	6-20	6-89
			Principles of Operation		1-13

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
PT Speed Pickup			Accessory Electrical Harness		
Clean	5-9	5-43	Assembly	7-28	7-137
Inspect	5-10	5-44	Accessory Gearbox Assembly	5-1	5-3
Install	5-12	5-46	Anti-Icing Air Gallery Cover	2-16	2-50
Remove	5-8	5-41	Chip Detector	8-109	8-273
Repair	5-11	5-45	(AVIM) Combustion Section and		
PT Speed Pickup Drive Assembly			Power Turbine	3-5	3-9
Clean	5-14	5-51	Compressor Bleed Band	2-10	2-37
Inspect	5-15	5-52	(Upper) Compressor Housing.....	2-20	2-63
Install	5-17	5-54	(Lower) Compressor Housing	2-21	2-94
Remove	5-13	5-49	Compressor Rotor Blades	2-33	2-235
Repair	5-16	5-53	Dual Chip Detector	8-39	8-91
Pump and Scavenge Oil Screen, Main Oil - See Main Oil Pump and Scavenge Oil Screen			Fireshield Assembly	4-12	4-55
Pump Assembly, Fuel Boost - See Fuel Boost Pump Assembly			Fireshield Section	4-16	4-65
Q			First Turbine Disc Assembly	4-63	4-361
Q Load Share Selected, Qs Not Matched			Flow Divider and Bracket	6-45	6-143
Expanded Instructions	G-59	G-135	Flow Programming Valve	8-19	8-53
Quality Assurance/Quality Control (QA/QC)	1-5	1-2	Fourth Stage Power Turbine Rotor	4-33	4-131
R			Fuel Boost Pump Assembly	6-8	6-35
Records and Reports, Maintenance Forms - See Maintenance Forms, Records and Reports			Fuel Check Valve	6-49	6-153
References	A-1		Fuel Drain Valve	3-1	3-3
References, Directional - See Directional References			Gas Producer Speed Pickup	8-7	8-27
Remarks (Column 6 And Section iv)	B-8	B-6	Hydromechanical Assembly (HMA)	6-1	6-5
Remove			Ignition Coil and Cable Assembly	7-1	7-3
			Ignition Exciter	7-11	7-71
			Inlet Housing Cover Assembly	2-44	2-345
			In-Line Fuel Filter Assembly	6-35	6-121
			Interstage Air-Bleed Actuator	2-1	2-5
			Left- and Right-Hand Bus Bar Assemblies	4-7	4-25
			Left- and Right-Hand Fuel Manifold Assemblies	6-15	6-49
			Main Fuel Filter and Bracket	6-28	6-103
			Main Oil Pump, Speed Pickup Drive Assembly, Scavenge Oil Screen, and Related Parts	8-1	8-7
			No. 2 Bearing Pressure Oil Connector.....	8-93	8-243

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
No. 2 Bearing Pressure Oil Strainer	8-97	8-249	Third Turbine Nozzle and Support ...	4-26	4-107
No. 4 and 5 Bearing Filter	8-101	8-255	T1 Temperature Sensor	2-52	2-359
Oil Cooler Assembly	8-12	8-35	Torque-meter Sensor	9-1	9-3
Oil Drain Cock	8-105	8-267	Remove Engine from Maintenance Stand	1-30	1-108
Oil Filler Assembly and Oil Filler Strainer	8-27	8-69	Remove Engine from Shipping and Storage Container	1-26	1-65
Oil Filter Cover Assembly and Oil Filter Element	8-34	8-83	Remove Engine Maintenance Sling	1-32	1-117
Oil Level Float Assembly	8-122	8-309	Remove Tailpipe Kit, DECU Kit, and Signal Conditioning Unit from Shipping Container	1-27	1-88
Oil Level Indicator	8-114	8-283	Repair		
Oil Temperature Transmitter	8-23	8-63	Accessory Electrical Harness Assembly	7-31	7-146
Output Shaft Seal and Housing Assembly	2-39	2-325	Accessory Gearbox Assembly	5-5	5-22
Overspeed Drive and Outlet Cover Assembly	5-23	5-75	Air Diffuser Assembly	2-38	2-321
Overspeed Solenoid Valve	6-52	6-159	Air Inlet Housing Assembly	2-51	2-357
Pressurizing Valve	6-41	6-135	Anti-Icing Air Gallery Cover	2-18	2-54
Primary Electrical Harness Assembly	7-16	7-81	Combustion Chamber Housing	3-21	3-175
Primer Tube Assembly	6-20	6-89	Combustion Chamber Liner	3-18	3-158
PT Speed Pickup	5-8	5-41	Combustion Chamber Vane Assembly	3-15	3-143
PT Speed Pickup Drive Assembly	5-13	5-49	Compressor Bleed Band	2-13	2-42
Reversionary Electrical Harness Assembly	7-22	7-109	Compressor Housing	2-24	2-122
Second Turbine Disc Assembly	4-54	4-289	Compressor Rotor Blades	2-36	2-286
Second Turbine Nozzle, Spacer, Case, and Bumper	4-58	4-313	Dual Chip Detector	8-43	8-99
Second Turbine Nozzle, Spacer, Case, and Bumper	7-6	7-59	First Turbine Disc Assembly	4-66	4-372
Start Fuel Nozzles	6-24	6-97	First Turbine Rotor Case	4-68	4-389
Starter Drive Assembly	5-18	5-57	Fourth Stage Power Turbine Nozzle	4-49	4-257
Starter Gearbox Filter	8-89	8-237	Fuel Boost Pump Assembly	6-11	6-39
Starting Fuel Solenoid Valve	6-57	6-167	Gas Producer Speed Pickup	8-10	8-31
(Lower) Stator Vane Assemblies	2-27	2-181	Hydromechanical Assembly (HMA)	6-4	6-15
Tailpipe Assembly	4-70	4-415	Ignition Coil and Cable Assembly	7-4	7-31
Thermocouple Harness Assemblies	4-20	4-81	Ignition Exciter	7-14	7-77
Thermocouple Jumper Lead	4-1	4-5	Inlet Housing Cover Assembly	2-47	2-350

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Interstage Air-Bleed Actuator	2-5	2-15	Reporting Equipment Improvement Recommendations (EIR)	1-7	1-3
Left- and Right-Hand Fuel Mani- fold Assemblies	6-18	6-63	Represerve Engine in Storage Over <u>Six Months</u>	1-106	1-563
Main Fuel Filter and Bracket	6-32	6-114	Resistance and Insulation Tests	G-4	G-2
Oil Cooler Assembly	8-16	8-44	Retirement Schedule, Overhaul and - See Overhaul and Retirement Schedule		
Oil Filler Assembly and Oil Filler Strainer	8-31	8-77	Reversionary Electrical Harness Assembly		
Oil Filter Cover Assembly and Oil Filter Element	8-37	8-87	Clean	7-23	7-115
Oil Level Float Assembly	8-126	8-315	Inspect.....	7-24	7-116
Oil Level Indicator	8-118	8-292	Install	7-27	7-131
Output Shaft Seal and Housing Assembly	2-42	2-330	Remove	7-22	7-109
Overspeed Drive and Outlet Cover Assembly	5-27	5-83	Repair	7-25	7-118
Overspeed Solenoid Valve	6-55	6-163	Test	7-26	7-119
Primary Electrical Harness As- sembly	7-19	7-89	Right- and Left-Hand Bus Bar Assemblies - See Left- and Right-Hand Bus Bar Assemblies		
PT Speed Pickup	5-11	5-45	Rotor (AVIM), Fourth Stage Power Turbine - See Fourth Stage Power Turbine Rotor (AVIM)		
PT Speed Pickup Drive Assembly	5-16	5-53	Rotor (AVIM). Third Stage Power Turbine - See Third Stage Power Turbine Rotor (AVIM)		
Reversionary Electrical Harness Assembly	7-25	7-118	Rotor Blades, Compressor - See Compressor Rotor Blades		
Second Turbine Nozzle, Spacer, Case, and Bumper	4-61	4-337	Rotor Case (AVIM), First Turbine - See First Turbine Rotor Case (AVIM)		
Starter Drive Assembly	5-21	5-63	S		
Starting Fuel Solenoid Valve	6-60	6-172	Safety, Care, and Handling	1-12	1-11
Stator Vane Assemblies	2-30	2-192	Scope	1-1	1-1
Tailpipe Assembly	4-74	4-425	Schedule, Overhaul and Retirement - See Overhaul and Retirement Schedule		
Thermocouple Harness Assemblies	4-23	4-88			
Thermocouple Jumper Lead	4-4	4-11			
Third Stage Power Turbine Rotor	4-53	4-284			
Third Turbine Nozzle and Support	4-30	4-122			
T1 Temperature Sensor	2-55	2-363			
Torquemeter Sensor	9-4	9-8			
Second Turbine Nozzle, Spacer, Case, and Bumper	7-9	7-64			
Repair Parts.....	1-24	1-24			

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Scratching, Gouging, or Wear, Determine Depth of Damage from Chafing, Denting, - See Determine Depth of Damage from Chafing, Denting, Scratching, Gouging, or Wear			Service Interstage Air-Bleed Actuator Strainer	1-97	1-479
Seal Leakage (No. 2 Bearing Package) (AVIM), Check for- See Check for Seal Leakage (No. 2 Bearing Package) (AVIM)			Service In-Line Fuel Filter	1-96	1-475
Seal Leakage (No. 4 and 5 Bearing) (AVIM), Check for - See Check for Seal Leakage (No. 4 and 5 Bearing) (AVIM)			Service Main Fuel Filter	1-95	1-472
Seals (AVIM), No. 4 and 5 Bearing Package - See No. 4 and 5 Bearing Package Seals (AVIM)			Service No. 2 Bearing Pressure Oil Strainer	1-91	1-439
Second Turbine Disc Assembly			Service No. 4 and 5 Bearing Oil Filter	1-92	1-443
Clean	4-55	4-298	Service Oil Filler Strainer	1-90	1-435
Inspect	4-56	4-299	Service Oil Filter Cover Assembly and Oil Filter Element	1-93	1-454
Install	4-57	4-301	Service Scavenge Oil Screen	1-94	1-459
Remove	4-54	4-289	Service Starter Gearbox Filter	1-89	1-432
Second Turbine Nozzle, Spacer, Case, and Bumper			Service Upon Receipt		1-49
Clean	4-59	4-320	Services, Preventive Maintenance Checks and - See Preventive Maintenance Checks and Services		
Inspect	4-60	4-322	Servicing.....		1-297
Install	4-62	4-354	Shaft Seal and Housing Assembly, Output- See Output Shaft Seal and Housing Assembly		
Remove	4-58	4-313	Shipment, Fuel Boost Pump Assembly, Preparation for Storage or - See Fuel Boost Pump Assembly Preparation for Storage or Shipment		
Repair	4-61	4-337	Shipment, HMA, Preparation for Storage or - See HMA Preparation for Storage or Shipment		
Section, Accessory Gear- See Accessory Gear Section			Shipment or Storage, Preserve and Prepare Engine for- See		
Section, Combustion - See Combustion Section					
Section, Compressor- See Compressor Section					
Service Engine Oil System	1-68	1-298			

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Preserve and Prepare Engine for Shipment or Storage			Spark Igniters		
Shipment, Preparation for Storage and - See Preparation for Storage and Shipment			Clean	7-7	7-62
			Inspect	7-8	7-63
			Install	7-10	7-65
			Remove	7-6	7-59
			Repair	7-9	7-64
Shipping and Storage Container, Inspect Pressurized - See Inspect Pressurized Shipping and Storage Container			Special Inspections	1-72	1-317
Shipping and Storage Container, Install Engine into - See Install Engine into Shipping and Storage Container			Special Tools, TMDE, and Support Equipment	1-23	1-47
Shipping and Storage Container, Mark - See Mark Shipping and Storage Container			Spiral Chafing Sleeve on Hoses, Install - See Install Spiral Chafing Sleeve on Hose		
Shipping and Storage Container, Prepare and Inspect - See Prepare and Inspect Shipping and Storage Container			Splines and Gears, Clean, Inspect and Repair - See Clean, Inspect and Repair Splines and Gears		
Shipping and Storage Container, Remove Engine from - See Remove Engine from Shipping and Storage Container			Stall (Surge), Inspect Engine after Compressor- See Inspect Engine after Compressor Stall (Surge)		
Six Months, Represerve Engine in Storage Over - See Represerve Engine in Storage Over Six Months			Stand, Install Engine on Maintenance - See Install Engine on Maintenance Stand		
Sleeve on Hoses, Install Spiral Chafing - See Install Spiral Chafing Sleeve on Hoses			Stand, Remove Engine from Maintenance - See Remove Engine from Maintenance Stand		
Solenoid Valve, Overspeed - See Overspeed Solenoid Valve			Standard Maintenance Practices	1-108	1-571
Spacer, and Case (AVIM), Second Turbine Nozzle - See Second Turbine Nozzle, Spacer, and Bumper Case (AVIM)			Standard Practices and Procedures		1-571
			Standard Torque Limits		1-567
			Standard Torque Values	1-107	1-567
			Start Fuel Nozzles		
			Clean	6-25	6-99
			Inspect	6-26	6-100
			Install	6-27	6-101
			Remove	6-24	6-97

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Starter Drive Assembly			Remove (Lower)	2-27	2-18
Clean	5-19	5-61	Repair	2-30	2-192
Inspect	5-20	5-62	Storage, Activate Engine after- See		
Install	5-22	5-70	Activate Engine after Storage		
Remove	5-18	5-57	Storage and Shipment, Preparation		
Repair	5-21	5-63	for - See Preparation for Storage		
			and Shipment		
Starter Drive Does Not Turn Engine or Engine Cranking Speed is Too Slow	1-35	1-126	Storage Container, Inspect		
Starter Gearbox Filter			Pressurized Shipping and - See		
Clean	8-90	8-239	Inspect Pressurized Shipping and		
Inspect	8-91	8-240	Storage Container		
Install	8-92	8-241	Storage Container, Install Engine into		
Remove	8-89	8-237	Shipping and - See Install Engine		
			into Shipping and Storage		
			Container		
Starting Fuel Solenoid Valve			Storage Container, Mark Shipping		
Clean	6-58	6-170	and - See Mark Shipping and		
Inspect	6-59	6-171	Storage Container		
Install	6-61	6-173	Storage Container, Prepare and		
Remove	6-57	6-167	Inspect Shipping and - See		
Repair	6-60	6-172	Prepare and Inspect Shipping and		
			Storage Container		
Static Oil Leakage at Combustion Chamber Drain Valve or Bleed Band Caused by Internal Oil Seepage - Visual Check	1-59	1-279	Storage Container, Remove Engine		
			From Shipping and - See		
			Remove Engine from Shipping		
			and Storage Container		
Static Oil Leakage at Combustion Chamber Drain Valve or Bleed Band Caused by Internal Oil Seepage	1-60	1-280	Storage or Shipment, Fuel Boost		
			Pump Assembly, Preparation for -		
			See Fuel Boost Pump Assembly		
			Preparation for Storage or		
			Shipment		
Static Oil Leakage, Check for - See Check for Static Oil Leakage			Storage or Shipment,		
			Hydromechanical Assembly,		
			Preparation for - See		
			Hydromechanical Assembly		
			Preparation for Storage or		
			Shipment		
Stator Vane Assemblies			Storage Over Six Months, Engine in		
Clean	2-28	2-189	- See Engine in Storage Over Six		
Inspect	2-29	2-190	Months		
Install (First Stage)	2-31	2-194			
Install (Second thru Seventh Stage)	2-32	2-215			

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Storage, Preserve and Prepare Engine for Shipment or Storage - See Preserve and Prepare Engine for Shipment or Storage			System, Inspect Contaminated Oil - See Inspect Contaminated Oil System		
Strainer, No. 2 Bearing Pressure Oil - See No. 2 Bearing Pressure Oil Strainer			System, Lubrication - See Lubrication System		
Strainer, Oil Filler Assembly and Oil Filler - See Oil Filler Assembly and Oil Filler Strainer			System, Service Engine Oil - See Service Engine Oil System		
Strainer, Service No. 2 Bearing Pressure Oil - See Service No. 2 Bearing Pressure Oil Strainer			System, Torquemeter - See Torquemeter System		
Strainer, Service Oil Filler- See Service Oil Filler Strainer			T		
(Support (AVIM), Third Turbine Nozzle and - See Third Turbine Nozzle and Support (AVIM)			Tailpipe Assembly		
Support Equipment, Special Tools, TMDE, and - See Special Tools, TMDE, and Support Equipment			Assemble 4-75	4-426	
Surge), Inspect Engine after Compressor Stall - See Inspect Engine after Compressor Stall (Surge)			Clean 4-72	4-422	
Symptom Index 1-33	1-121		Disassemble 4-71	4-419	
System, Drain Engine Oil - See Drain Engine Oil System			Inspect 4-73	4-423	
System, Electrical and Ignition - See Electrical and Ignition System			Install 4-76	4-430	
System, Fuel - See Fuel System			Remove 4-70	4-415	
System, Inspect Contaminated Fuel - See Inspect Contaminated Fuel System			Repair 4-74	4-425	
			Test		
			Accessory Electrical Harness Assembly 7-32	7-147	
			Chip Detector 8-112	8-279	
			Dual Chip Detector 8-45	8-101	
			Interstage Air-Bleed Actuator 2-7	2-18	
			Left- and Right-Hand Bus Bar Assemblies 4-10	4-34	
			Primary Electrical Harness Assembly 7-20	7-90	
			Reversionary Electrical Harness Assembly 7-26	7-119	
			Thermocouple Harness Assemblies (AVIM) 4-24	4-91	
			Thermocouple Jumper Lead 4-5	4-13	
			Temperature Transmitter, Oil - See Oil Temperature Transmitter		
			Test Equipment G-3	G-2	

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Thermocouple Harness Assemblies			Tools, TMDE and Support, Special - See Special Tools, TMDE, and Support Equipment		
Clean	4-21	4-85	Torque Limits, Standard - See Standard Torque Limits		
Inspect	4-22	4-86	Torque Values, Standard - See Standard Torque Values		
Install	4-25	4-95			
Remove	4-20	4-81			
Repair	4-23	4-88			
Test	4-24	4-91			
Thermocouple Jumper Lead			T1 Temperature Sensor		
Clean	4-2	4-8	Clean	2-53	2-361
Inspect	4-3	4-9	Inspect	2-54	2-362
Install	4-6	4-17	Install	2-56	2-364
Remove	4-1	4-5	Remove	2-52	2-359
Repair	4-4	4-11	Repair	2-55	2-363
Test	4-5	4-13			
Third Stage Power Turbine Rotor			Torquemeter Sensor		
Clean	4-51	4-279	Clean	9-2	9-6
Inspect	4-52	4-280	Inspect	9-3	9-7
Repair	4-53	4-284	Install	9-5	9-9
Third Turbine Nozzle and Support			Remove	9-1	9-3
Assemble	4-31	4-123	Repair	9-4	9-8
Clean	4-28	4-113	Torquemeter System	1-21	1-46
Disassemble	4-27	4-111	Touch Up Magnesium and Magnesium Alloys	1-110	1-583
Inspect	4-29	4-114	Transmitter, Oil Temperature - See Oil Temperature Transmitter		
Install	4-32	4-125	Troubleshooting		1-121
Remove	4-26	4-107	Troubleshooting Procedures	1-34	1-123
Repair	4-30	4-122	Tube Assembly(Accessory Gearbox Collector to Tube Assembly)		
Time, Check Engine Coastdown - See Check Engine Coastdown Time			Install	8-86	8-225
Tools and Equipment, Common - See Common Tools and Equipment			Remove	8-85	8-219
Tools And Test Equipment (Column 5 And Section iii)	B-7	B-6			

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
Tube Assembly (Air Diffuser Assembly to Check Valve)			Turbine Disc Assembly (AVIM), Second - See Second Turbine Disc Assembly (AVIM)		
Install	2-60	2-375			
Remove	2-59	2-373			
Tube Assembly (Inlet Housing to Main Oil Pump)			Turbine Nozzle and Support (AVIM) Third - See Third Turbine Nozzle and Support (AVIM)		
Install	8-66	8-151			
Remove	8-65	8-148			
Tube Assembly (Main Oil Pump to Inlet Housing Oil Scavenge Tee)			Turbine Nozzle (AVIM), First - See First Turbine Nozzle (AVIM)		
Install	8-68	8-161			
Remove	8-67	8-159			
Tube Assembly (No. 2 Bearing Pressure Connector to Tee and Snubber)			Turbine Nozzle (AVIM), Fourth Stage Power - See Fourth Stage Power Turbine Nozzle (AVIM)		
Install	8-74	8-177			
Tube Assembly (No. 4 and 5 Bearing Scavenge Tube Assembly to Main Oil Pump Flange)			Turbine Nozzle, Spacer, and Case (AVIM), Second - See Second Turbine Nozzle, Spacer, Case, and Bumper (AVIM)		
Install	8-70	8-165			
Remove	8-69	8-163			
Tube Assembly (No. 4 and 5 Bearing Scavenge Connector to Tube Assembly)			Turbine Rotor (AVIM), Fourth Stage Power - See Fourth Stage Power Turbine Rotor (AVIM)		
Install	8-72	8-171			
Remove	8-71	8-167			
Remove	8-73	8-175			
Tube Assembly (Tube and Hose Assembly to Accessory Gearbox Assembly)			Turbine Rotor (AVIM), Third Stage Power - See Third Stage Power Turbine Rotor (AVIM)		
Install	8-88	8-234			
Remove	8-87	8-231			
Tubes (AVIM), No. 4 and 5 Bearing Oil-See No. 4 and 5 Bearing Oil			Turbine Rotor Case (AVIM), First - See First Turbine Rotor Case (AVIM)		
Turbine Disc Assembly (AVIM), First - See First Turbine Disc Assembly (AVIM)			Turbine Section	1-16	1-22
			T4.5 Load Share Selected, T4.5s Not Matched Expanded Instructions	G-60	G-139

INDEX (Continued)

Subject	Para/ Task	Page	Subject	Para/ Task	Page
U					
Unable To Perform Power Assurance Test (Results Not Indicated On Hex Display) Expanded Instructions	G-66	G-154	Valve, starting Fuel Solenoid - See Starting Fuel Solenoid Valve		
Unable To Switch To Primary Mode Expanded Instructions	G-57	G-129	Vane Assemblies, Stator- See Stator Vane Assemblies		
Unable To Switch To Reversionary Mode Expanded Instructions	G-56	G-126	Vane Assembly (AVIM), Combustion Chamber - See Combustion Chamber Vane Assembly		
Use Of The Maintenance Allocation Chart (Section II)	B-2	B-2	W		
Using the Fault Isolation Diagrams	G-10	G-8	Wiring Diagram		D-1
V					
Values, Standard Torque - See Standard Torque Values			Wear, Determined Depth of Damage from Chafing, Denting, Scratching, Gouging, or - See Determine Depth of Damage from Chafing, Denting, Scratching, Gouging, or Wear		
Valve, Fuel Check - See Fuel Check Valve					
Valve, Fuel Drain - See Fuel Drain Valve			Wash Compressor	1-99	1-488

By Order of the Secretary of the Army:

Official:



MILTON H. HAMILTON
*Administrative Assistant to the
Secretary of the Army*

07688

GORDON R. SULLIVAN
*General, United States Army
Chief of Staff*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-31-E, block no. 3466, requirements for TM 1-2840-252-23-3.

These are the instructions for sending an electronic 2028

The following format must be used if submitting an electronic 2028. The subject line must be exactly the same and all fields must be included; however only the following fields are mandatory: 1, 3, 4, 5, 6, 7, 8, 9, 10, 13, 15, 16, 17, and 27.

From: "Whomever" <whomever@wherever.army.mil>

To: 2028@redstone.army.mil

Subject: DA Form 2028

1. **From:** Joe Smith
2. **Unit:** home
3. **Address:** 4300 Park
4. **City:** Hometown
5. **St:** MO
6. **Zip:** 77777
7. **Date Sent:** 19-OCT-93
8. **Pub no:** 55-2840-229-23
9. **Pub Title:** TM
10. **Publication Date:** 04-JUL-85
11. **Change Number:** 7
12. **Submitter Rank:** MSG
13. **Submitter FName:** Joe
14. **Submitter MName:** T
15. **Submitter LName:** Smith
16. **Submitter Phone:** 123-123-1234
17. **Problem:** 1
18. **Page:** 2
19. **Paragraph:** 3
20. **Line:** 4
21. **NSN:** 5
22. **Reference:** 6
23. **Figure:** 7
24. **Table:** 8
25. **Item:** 9
26. **Total:** 123
27. **Text:**

This is the text for the problem below line 27.

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS For use of this form, see AR 25-30; the proponent agency is ODISC4.						Use Part II (reverse) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM)	DATE 8/30/02
TO: (Forward to proponent of publication or form)(Include ZIP Code) Commander, U.S. Army Aviation and Missile Command ATTN: AMSAM-MMC-MA-NP Redstone Arsenal, AL 35898						FROM: (Activity and location)(Include ZIP Code) MSG, Jane Q. Doe 1234 Any Street Nowhere Town, AL 34565	
PART 1 - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER TM 9-1005-433-24						DATE 16 Sep 2002	TITLE Organizational, Direct Support, And General Support Maintenance Manual for Machine Gun, .50 Caliber M3P and M3P Machine Gun Electrical Test Set Used On Avenger Air Defense Weapon System
ITEM NO.	PAGE NO.	PARA-GRAPH	LINE NO. *	FIGURE NO.	TABLE NO.	RECOMMENDED CHANGES AND REASON	
1	WP0005 PG 3		2			Test or Corrective Action column should identify a different WP number.	
<i>* Reference to line numbers within the paragraph or subparagraph.</i>							
TYPED NAME, GRADE OR TITLE MSG, Jane Q. Doe, SFC						TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION 788-1234	SIGNATURE

EXAMPLE

TO: (Forward direct to addressee listed in publication) Commander, U.S. Army Aviation and Missile Command ATTN: AMSAM-MMC-MA-NP Redstone Arsenal, AL 35898	FROM: (Activity and location) (Include ZIP Code) MSG, Jane Q. Doe 1234 Any Street Nowhere Town, AL 34565	DATE 8/30/02
--	--	------------------------

PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER			DATE	TITLE				
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

PART III - REMARKS (Any general remarks, corrections, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)

EXAMPLE

TYPED NAME, GRADE OR TITLE MSG, Jane Q. Doe, SFC	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION 788-1234	SIGNATURE
---	---	-----------

RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS <small>For use of this form, see AR 25-30; the proponent agency is ODISC4.</small>						Use Part II (reverse) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/SM)	DATE
TO: (Forward to proponent of publication or form)(Include ZIP Code) Commander, U.S. Army Aviation and Missile Command ATTN: AMSAM-MMC-MA-NP Redstone Arsenal, AL 35898						FROM: (Activity and location)(Include ZIP Code)	
PART 1 - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS							
PUBLICATION/FORM NUMBER						DATE	TITLE
ITEM NO.	PAGE NO.	PARA-GRAPH	LINE NO. *	FIGURE NO.	TABLE NO.	RECOMMENDED CHANGES AND REASON	
<i>* Reference to line numbers within the paragraph or subparagraph.</i>							
TYPED NAME, GRADE OR TITLE						TELEPHONE EXCHANGE/ AUTOVON, PLUS EXTENSION	SIGNATURE

TO: (Forward direct to addressee listed in publication) Commander, U.S. Army Aviation and Missile Command ATTN: AMSAM-MMC-MA-NP Redstone Arsenal, AL 35898	FROM: (Activity and location) (Include ZIP Code)	DATE
--	---	-------------

PART II - REPAIR PARTS AND SPECIAL TOOL LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS

PUBLICATION NUMBER			DATE	TITLE				
PAGE NO.	COLM NO.	LINE NO.	NATIONAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION

PART III - REMARKS (Any general remarks or recommendations, or suggestions for improvement of publications and blank forms. Additional blank sheets may be used if more space is needed.)

--

TYPED NAME, GRADE OR TITLE	TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION	SIGNATURE

The Metric System and Equivalents

Linear Measure

1 centimeter = 10 millimeters = .39 inch
 1 decimeter = 10 centimeters = 3.94 inches
 1 meter = 10 decimeters = 39.37 inches
 1 dekameter = 10 meters = 32.8 feet
 1 hectometer = 10 dekameters = 328.08 feet
 1 kilometer = 10 hectometers = 3,280.8 feet

Weights

1 centigram = 10 milligrams = .15 grain
 1 decigram = 10 centigrams = 1.54 grains
 1 gram = 10 decigrams = .035 ounce
 1 decagram = 10 grams = .35 ounce
 1 hectogram = 10 decagrams = 3.52 ounces
 1 kilogram = 10 hectograms = 2.2 pounds
 1 quintal = 100 kilograms = 220.46 pounds
 1 metric ton = 10 quintals = 1.1 short tons

Liquid Measure

1 centiliter = 10 milliliters = .34 fl. ounce
 1 deciliter = 10 centiliters = 3.38 fl. ounces
 1 liter = 10 deciliters = 33.81 fl. ounces
 1 dekaliter = 10 liters = 2.64 gallons
 1 hectoliter = 10 dekaliters = 26.42 gallons
 1 kiloliter = 10 hectoliters = 264.18 gallons

Square Measure

1 sq. centimeter = 100 sq. millimeters = .155 sq. inch
 1 sq. decimeter = 100 sq. centimeters = 15.5 sq. inches
 1 sq. meter (centare) = 100 sq. decimeters = 10.76 sq. feet
 1 sq. dekameter (are) = 100 sq. meters = 1,076.4 sq. feet
 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47 acres
 1 sq. kilometer = 100 sq. hectometers = .386 sq. mile

Cubic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch
 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches
 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

Approximate Conversion Factors

<i>To change</i>	<i>To</i>	<i>Multiply by</i>	<i>To change</i>	<i>To</i>	<i>Multiply by</i>
inches	centimeters	2.540	ounce-inches	Newton-meters	.007062
feet	meters	.305	centimeters	inches	.394
yards	meters	.914	meters	feet	3.280
miles	kilometers	1.609	meters	yards	1.094
square inches	square centimeters	6.451	kilometers	miles	.621
square feet	square meters	.093	square centimeters	square inches	.155
square yards	square meters	.836	square meters	square feet	10.764
square miles	square kilometers	2.590	square meters	square yards	1.196
acres	square hectometers	.405	square kilometers	square miles	.386
cubic feet	cubic meters	.028	square hectometers	acres	2.471
cubic yards	cubic meters	.765	cubic meters	cubic feet	35.315
fluid ounces	milliliters	29.573	cubic meters	cubic yards	1.308
pints	liters	.473	milliliters	fluid ounces	.034
quarts	liters	.946	liters	pints	2.113
gallons	liters	3.785	liters	quarts	1.057
ounces	grams	28.349	liters	gallons	.264
pounds	kilograms	.454	grams	ounces	.035
short tons	metric tons	.907	kilograms	pounds	2.205
pound-feet	Newton-meters	1.356	metric tons	short tons	1.102
pound-inches	Newton-meters	.11296			

Temperature (Exact)

°F	Fahrenheit temperature	5/9 (after subtracting 32)	Celsius temperature	°C
----	------------------------	----------------------------	---------------------	----

