

TM 5-3431-203-15

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

OPERATOR, ORGANIZATIONAL, DIRECT AND
GENERAL SUPPORT, AND DEPOT MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS)

WELDING MACHINE, ARC, INERT SHIELDED: TRANSFORMER;
300 AMP; 10 TO 400 AMP AC STRAIGHT POLARITY;
10 TO 00 AMP DC REVERSE POLARITY (MIDSTATES
MODEL MAG 00 AC/DC T 14) FSN 3431-862-6670



HEADQUARTERS, DEPARTMENT OF THE ARMY

FEBRUARY 1967

SAFETY PRECAUTIONS

BEFORE OPERATION

See that the ground terminal lug is connected through the input cable or by separate conductor to the power system ground. An ungrounded machine can cause death by electrocution to personnel coming in contact with it.

Do not reposition the voltage bars while power source is connected to the machine. To do so could cause a serious electrical shock and possible death.

DURING OPERATION

Do not make or break any connections or perform any maintenance while the welding machine is in operation. The high voltage created by this machine can cause death by electrocution.

Do not come in contact with the electrode while the machine is in operation. The high voltage generated by the machine can cause death by electrocution.

Be very careful when the unit or surrounding area is wet or damp. Coming in contact with a wet or damp unit can cause a serious electrical shock and possible death.

When malfunction of the selenium rectifier occurs, thoroughly ventilate the area to prevent inhalation of poisonous fumes. Do not handle the damaged rectifier while it is warm so as not to absorb poisonous selenium oxide compound through the skin. Failure to observe this warning can result in serious injury or possible death.

AFTER OPERATION

When making a test on the high-frequency transformer, make sure that the transformer is on an insulated bench. Do not touch an activated transformer or the wires leading from it. To do so may cause a serious electrical shock or possible death to personnel performing the test.

Short the capacitor connections to ground before removal. Failure to do this may result in a serious electrical shock.

Change }
No. 1 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D. C., 11 December 1972

**OPERATOR, ORGANIZATIONAL, DIRECT
AND GENERAL SUPPORT AND DEPOT
MAINTENANCE MANUAL (INCLUDING REPAIR PARTS)**

**WELDING MACHINE, ARC; INERT SHIELDED; TRANSFORMER, 300 AMP; 10 TO 400
AMP AC, STRAIGHT POLARITY; 10 TO 300 AMP DC, REVERSE
POLARITY (MIDSTATES MODEL MAG300 AC/DC T134) FSN 3431-862-6670**

TM 5-3431-203-15, 14 February 1967, is changed as follows:

Page B-1. Appendix B is superseded as follows:

**APPENDIX B
BASIC ISSUE ITEMS LIST AND ITEMS
TROOP INSTALLED OR AUTHORIZED**

Section I. INTRODUCTION

B-1. Scope

This appendix lists items required by the operator for operation of the welding machine.

B-2. General

This list is divided into the following sections:

a. Basic Issue Items List-Section II. Not applicable.

b. Items Troop Installed or Authorized List-Section III. A list of items in alphabetical sequence, which at the discretion of the unit commander may accompany the welding machine. These items are NOT SUBJECT TO TURN-IN with the welding machine when evacuated.

B-3. Explanation of Columns

The following provides an explanation of columns in the tabular list of Basic Issue Items List, section II, and Items Troop Installed or Authorized, section III.

a. Source, Maintenance and Recoverability Code (SMR). Not applicable.

b. Federal Stock Number. This column indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. Description. This column indicates the Federal item name and any additional description of the item required.

d. Unit of Measure (U/M). A two character alphabetic abbreviation indicating the amount or quantity of the item upon which the allowances are based, e.g., ft, ea, pr, etc.

e. Quantity Furnished with Equipment (BILL). Not applicable.

f. Quantity Authorized (Items Troop Installed or Authorized). This column indicates the quantity of the item authorized to be used with the equipment.

Section III. ITEMS TROOP INSTALLED OR AUTHORIZED LIST

(1) SMR code	(2) Federal stock number	(3) Description Ref No. & Mfr code	(4) Usable of meas on code	(5) Qty auth
	7520-559-9618	CASE, Maintenance and Operation manual	EA	1
	5975-243-5866	CLAMP, Electrical	EA	1
	5120-642-8937	ROD, GROUND	EA	1
	6145-189-6695	WIRE, Electrical, 10 Ft.	EA	1

By Order of the Secretary of the Army:

Official:

VERNE L. BOWERS
Major General, United States Army
The Adjutant General

CREIGHTON W. ABRAMS
General, United States Army
Chief of Staff

Distribution:

To be distributed in accordance with DA Form 12-25A (qty rqr block No. 182) Organizational Maintenance requirements for Welding.

**Operator, Organizational, Direct and General Support
and Depot Maintenance Manual (Including Repair Parts)**

**WELDING MACHINE, ARC, INERT GAS SHIELDED:
TRANSFORMER; 300 AMP; 10 TO 400 AMP AC
STRAIGHT POLARITY; 10 TO 300 AMP DC REVERSE
POLARITY (MIDSTATES MODEL MAG 300 AC/DC T134)
FSN 3431-862-6670**

	Paragraph	Page
CHAPTER 1. INTRODUCTION		
Section I. General -----	1-1, 1-2	1-1
II. Description and data -----	1-3 - 1-5	1-1 - 1-4
CHAPTER 2. INSTALLATION AND OPERATION INSTRUCTIONS		
Section I. Service upon receipt of equipment -----	2-1 - 2-5	2-1 - 2-3
II. Movement to a new worksite -----	2-6, 2-7	2-3
III. Controls and instruments -----	2-8, 2-9	2-4
IV. Operation of equipment -----	2-10 - 2-18	2-6 - 2-9
CHAPTER 3. OPERATOR AND ORGANIZATIONAL MAINTENANCE INSTRUCTIONS		
Section I. Operator and organizational maintenance tools and equipment -----	3-1 - 3-3	3-1
II. Lubrication -----	3-4, 3-5	3-1
III. Preventive maintenance services -----	3-6 - 3-8	3-2
IV. Operator's maintenance -----	3-9, 3-10	3-5
V. Troubleshooting -----	3-11 - 3-20	3-5 - 3-6
VI. Field expedient repairs -----	3-21 - 3-24	3-6
VII. Welding machine top, housing doors, and panels -----	3-25 - 3-28	3-6 - 3-7
VIII. Pilot lights, switches, timers, remote receptacles, and dummy plug ----	3-29 - 3-43	3-10 - 3-14
IX. Spark gap adjuster, voltage change bars, and ground and electrode terminal board -----	3-44 - 3-47	3-14 - 3-15
X. Gas and water solenoid valves -----	3-48 - 3-50	3-16
XI. Ventilating-cooling system -----	3-51 - 3-55	3-16 - 3-17
CHAPTER 4. DIRECT AND GENERAL SUPPORT AND DEPOT MAINTENANCE INSTRUCTIONS		
Section I. General -----	4-1, 4-2	4-1
II. Description and data -----	4-3, 4-4	4-1
III. Special tools and equipment -----	4-5 - 4-7	4-2
IV. Troubleshooting -----	4-8 - 4-15	4-2 - 4-3
V. Control panel and timer receptacles -----	4-16, 4-17	4-3
VI. Range switch, polarity switch, control rheostat and intensity selector ----	4-18 - 4-21	4-4 - 4-6
VII. Control rectifier, rectifier assembly, diodes, capacitors and resistors ----	4-22 - 4-26	4-6 - 4-8
VIII. Timer relay, switching panel, filter reactor, reactor coil, and tesla coil ----	4-27 - 4-31	4-15 - 4-16
IX. Accessory transformer, high frequency transformer, and main transformer -----	4-32 - 4-34	4-18 - 4-19
X. Wiring harness and high frequency panel wiring harnezss -----	4-35 - 4-37	4-20 - 4-21
XI. Frame and main transformer support assembly -----	4-38 - 4-39	4-21 - 4-22

*This manual supersedes TM 5-3431-203-15, 5 December 1962, including C1, 16 August 1963.

	Page
APPENDIX A. REFERENCES -----	A-1
B. BASIC ISSUE ITEMS LIST -----	B-1
C. MAINTENANCE ALLOCATION CHART -----	C-1
D. ORGANIZATIONAL, DIRECT AND GENERAL SUPPORT AND DEPOT MAINTENANCE REPAIR PARTS -----	D-1
INDEX -----	I-1

CHAPTER 1

INTRODUCTION

Section I. GENERAL

1-1. Scope

a. These instructions are published for the use of the personnel to whom the Midstates Model MAG 300 AC/DC T134 Welding Machine is issued. Chapters 1 through 3 provide information on the operation, daily preventive maintenance services, and organizational maintenance of the equipment, accessories, components, and attachments. Chapter 4 provides information for direct and general support and depot maintenance. This manual also provides descriptions of the main units and their functions in relationship to other components.

b. Appendix A contains a list of publications applicable to this manual. Appendix B contains the list of basic issue items authorized for the initial operation. Appendix C contains the maintenance allocation chart. The organizational, direct and general support and depot maintenance repair parts lists are found in Appendix D.

c. Numbers in parentheses on illustrations indicate quantity.

d. DA Form 2028 (Recommended Changes

to DA Publication) will be used for reporting discrepancies and recommendations for improving this equipment manual. This form will be completed by the individual using the manual and forwarded direct to Commanding General, U.S. Army Mobility Equipment Command, ATTN: AMSME-MPD, 4300 Goodfellow Blvd. St. Louis, Mo. 63120.

e. Report all equipment improvement recommendations as prescribed by TM 38-750.

1-2. Record and Report Forms

a. DA Form 2258 (Depreservation Guide for Vehicles and Equipment).

b. DA Form 1397 (processing and Deprocessing Record for Shipment, Storage, and Issue of Vehicle and Spare Engines).

c. For other record and report forms applicable to the operator and organizational maintenance, refer to TM 38-750.


Note. Applicable forms, excluding Standard Form 46 (United States Government Motor Vehicles Operator's Identification Card) which is carried by the operator shall be kept in a canvas bag mounted on the equipment.

Section II. DESCRIPTION AND DATA

1-3. Description

The Midstates Model MAG 300 AC/DC inert welding machine (figs. 1-1 and, 1-2) is operated from an external power source of either 230- or 460-volt, alternating current, and by single phase or three phase connections. This welder provides an electrically

controlled current output for use in either shielded inert gas welding or metallic arc welding. The entire control section is located in a drawer-type frame at the top of the welding machine. The panel permits the entire section to be disconnected and removed for ease of servicing.




SHIPPING DIMENSIONS

HEIGHT	41 1/2	INCHES
WIDTH	24 3/8	INCHES
LENGTH	22 1/4	INCHES
WEIGHT	700	POUNDS

EMC 3431-203-15 1

Figure 1-1. Welding machine, tight front, three-quarter view with shipping dimensions.



EMC 3431-203-15 2

Figure 1-2. Welding machine, left rear, three-quarter view.

1-4. Identification and Tabulated Data

a. *Identification.* The welding machine has two identification plates, which are the Corps of Engineers' plate, and the manufacturer's identification and data plate. The Corps of Engineers' plate is located on the upper right side of the housing near the front of the welding machine. It specifies the nomenclature, make, model, serial number, and contract number. The manufacturer's identification and data plate is located on the upper front panel. It specifies the nomenclature, manufacturer, model, serial number, secondary rated output amperage, load voltage, duty cycle percent, open circuit voltage, primary input voltage, input amperage, rated kilo-volt amperage, power factor percent, and cycles.

b. *Tabulated Data.*

(1) *Corps of engineers' plate.*

Nomenclature ----- Welding Machine: ARC;
300 amp (amperes)
Make ----- Midstates
Model -----MAG 300 AC/DC T134
Serial Number -----
Contract Number ----- DA-11-199-ORD-297 S
427

(2) *Manufacturer's identification and data plate.*

Manufacturer ----- Midstates Welder Mfg.
c o
Model ----- MAG 300 AC/DC T134

Secondary	AC	DC
Rated output amps -----	300	300
Load volts -----	40	40
Duty cycle (percent) -----	60	60
open circuit volts -----	80	72
Primary		
Input -----	230/460	
Input amps -----	90/45	
Rated kva (kilovolt amperes)	21	

Power factor (percent) -----80
Cycles -----50/60 single phase

(3) *Solenoid valve.*

Manufacturer -----Automatic Switch Co.
Part number ----- 82623
Voltage -----230 v (volts)
Psi (pounds per square
inch) -----110
Wattage -----10.5 W (watts)

(4) *Fan motor.*

Manufacturer ----- Universal Electric Co
Model number -----16-166
Rpm (Revolutions per
minute) 1550
Voltage -----230 v
Cycles -----60
Amperage -----1.25 amp

(5) *Contactors.*

Manufacturer ----- Cutler-Hammer Inc.
Model number ----- 6-3-2
Voltage -----208/220 v, 60 cycles
Amperage (open air) -----30 amp
Amperage (enclosed) -----27 amp

(6) *Dimensions and weight.*

Height -----41 1/2 in. (inches)
Width -----24 3/8 in.
Length -----22 1/4 in.
Weight -----700 lb (pounds)

(7) *Adjustments.*

Spark gap adjuster -----0.005 in.

(8) *Base plan.* Refer to figure 1-3.

(9) *Wiring diagram.* Refer to figure 1-4.

1-5. Difference in Models

This manual covers only the Midstates Model 300 AC/DC T134 welding machine. No known unit differences exist for the model covered by this manual.




Figure 1-3. Base plan.

Figure 1-4. Practical wiring diagram.
(Located in back of manual)

CHAPTER 2

INSTALLATION AND OPERATION INSTRUCTIONS

Section I. SERVICE UPON RECEIPT OF EQUIPMENT

2-1. Unloading the Equipment

a. Shipment by Tractor. When the welding machine is received, by tractor, remove all securing devices and, with a forklift or other suitable lifting device, remove it from the truck.

Warning: When using a lifting device to move the welding machine, make sure it has a lifting capacity of no less than 1,000 pounds. Do not allow the welding machine to swing or sway while suspended. Failure to observe this warning may result in damage to the equipment or serious injury to personnel.

b. Shipment by Rail. When the welding machine is received by rail, remove all securing devices and with a forklift or other suitable lifting device, remove it from the freight car.

2-2. Unpacking the Equipment

a. Unpacking. The welding machine has heavy paper or cardboard around it to protect it from damage. This is packed in a wooden box.

- (1) Remove all metal banding with a suitable tool.
- (2) Remove the wooden box with a claw hammer, pry bar, nail puller, or other suitable tools.

Note. Be careful not to damage the welding machine while removing the wooden box

b. Description. Prepare the welding machine for inspection and operation as outlined on DA Form 2258, attached on or near the control panel.

2-3. Inspecting and Servicing Equipment

a. Check packing list for missing parts.

b. Inspect for damaged parts. Check welding machine for dents, scratches, and damaged housing.

c. Inspect for damaged or broken controls and switches.


d. Inspect for loose and missing hardware, lifting eyes, panels and fittings.

e. Perform the daily preventive maintenance services (para 3-7).


2-4. Installation or Setting-Up Instructions

a. Ground and Electrode Cable Connections. Refer to figure 2-1 and connect the work cables to the ground terminal stud and electrode terminal stud located on the front of the welder.


b. External Power and Ground Connections. The welding machine must be grounded prior to operation. The ground can be, in order of preference, an underground metallic water piping system, a driven metal rod, or a buried metal plate. The ground rod must have a minimum diameter of 5/8 inch if solid, or 3/4 inch if pipe, and, must be driven to a minimum depth of 8 feet. A ground plate must have a minimum area of 9 square feet and be buried to a minimum depth of 4 feet. The ground lead must be a No. 6 AWG (American Wire Gage) copper wire or larger, and be bolted or clamped, to the rod, plate, or piping system. Refer to figure 2-1B and connect the external power and ground wire.



A. LOAD CONNECTIONS



B. EXTERNAL POWER AND GROUND CONNECTIONS.



C. GAS AND WATER CONNECTIONS.

Figure 2-1. Load, ground, external power source, gas, and water connections.

Warning: Before operating the unit, see that the ground terminal lug is properly connected by one of the methods referenced in paragraph 2-4b. An ungrounded machine can cause death by electrocution of personnel coming in contact with it.

c. *Water Connections.* Refer to figure 2-1C and connect suitable pipe and fittings to the welding machine.

d. *Gas Connections.* Refer to figure 2-1 and connect suitable pipe and fittings to the welding machine.

Note. When installing the welding machine, allow at least 18 inches clearance on all sides for proper ventilation.

2-5. Equipment Conversion

a. *General.* The welding machine can operate on either 230 or 460 volts by the correct positioning of the voltage change bars.

b. *Voltage Change Bar Positioning.*

- (1) Remove the screws on the contractor and voltage change bar access panel and open door.
- (2) Refer to figure 2-2 and place the voltage change bars in the desired position.

Warning: Do not reposition voltage change bars while power source is connected to the machine. To do so could cause a serious electrical shock and possible death.




Figure 2-2. Voltage change bars for 230 or 460 volts.

Section II. MOVEMENT TO A NEW WORKSITE

2-6. Dismantling for Movement

a. Disconnect cables from load connection, external power source ground connections, and hoses and/or piping from gas and water connections (para 2-4).

b. If the welding machine is to be moved within a building, it can be skidded or moved with a forklift. If the welding machine is to be moved other than a short distance, cover the water and gas connection fittings and load it on a truck or other suitable carrier with a suitable lifting device.

Warning: When using a lifting device to lift the welding machine, make sure it has a safe lifting capacity of at least 1,000 pounds. Do not allow the welding machine to swing freely when being lifted. Failure to observe this warning may cause damage to the equipment or serious injury to personnel.

2-7. Reinstallation After Movement

Refer to paragraph 2-4 for reinstallation instructions after movement to a new worksite.

Section III. CONTROLS AND INSTRUMENTS


2-8. General

This section describes, locates, illustrates and furnishes the operator, crew, or organizational maintenance personnel sufficient information about the various controls and in-


struments for proper operation of the welding machine.

2-9. Controls and Instruments

Refer to figure 2-3 for the purpose, use, and normal position of the controls and instruments.



A. CONTROL PANEL.



B. HIGH FREQUENCY PANEL.

EMC 3431-203-15/7

Figure 2-3. Controls and instruments.

Section IV. OPERATION OF EQUIPMENT

2-10. General

a. The instructions in this section are published for the information and guidance of the personnel responsible for the operation of the welding machine.

b. The operator must know how to perform every operation of which the welding machine is capable. This section gives instructions on starting and stopping the welding machine, and various settings of controls to enable the welding machine to perform different types of welding for which it is designed. Since nearly every job presents a different problem, the operator may have to vary given procedures to fit the individual job.

Caution: When using the machine for high frequency welding, high frequency emission may result in communication interference if the machine is not properly grounded.

2-11. Starting

a. Preparation for Starting.

- (1) Perform the daily preventive maintenance Services (para 3-7).
- (2) Clean area on item to be welded to insure a good connection.
- (3) Connect the ground clamp of the load (work) cable to the work table or item to be welded.

b. *Starting.* Refer to figure 2-4 for starting instructions.

2-12. Stopping


a. Refer to figure 2-5 for stopping instructions.

b. Remove the ground clamp from the item being welded.

2-13. Welding Machine Operation

a. Start the welding machine (para 2-11).

b. Refer to table 1-1 and select the proper electrode for inert gas welding.



STARTING.

- STEP 1. MAKE SURE THAT EXTERNAL POWER IS CONNECTED TO THE WELDING MACHINE.
- STEP 2. MAKE SURE THAT GAS AND WATER ARE CONNECTED TO THE WELDING MACHINE IF HIGH FREQUENCY WELDING IS TO BE DONE.
- STEP 3. PLACE POWER SWITCH TO ON POSITION TO START THE WELDING MACHINE.

EMC 3431-203-15/8

Figure 2-4. Starting the welding machine.

Table 1-1. Electrode Size for Applied Current

Tungsten electrode size (diameter)	Welding current (amperes)
0.040 in.	40 - 60
3/32	50 - 100
1/16	100 - 160
1/8	150 - 210
5/32	200 - 275
3/16	250 - 350
1/4	325 - 475




Figure 2-5. Stopping the welding machine.

Note. Refer to TM 9-237 for metallic arc welding theory and application.

c. Use a sample piece of metal, like the metal to be welded and adjust the welding amperage to produce the correct arc necessary for the welding to be done.

Warning: Do not come in contact with the electrode while the welding machine is operating. The high voltage generated by the machine can cause death by electrocution.

d. Refer to figure 2-6 and operate the welding machine.

Warning: Before operating the welding machine, see that the ground terminal lug is connected through the input cable or by separate conductor to the power system ground. An ungrounded welding machine can cause death by electrocution to personnel coming in contact with it.

Note. The welding machine is equipped with a remote receptacle and can be operated by remote control. When using the remote control, the contactor and amperage switches must be in the remote position. When the remote amperage control is used, the maximum current available will be limited by the setting of the panel rheostat. If full range is necessary, the panel rheostat control must be set wide open.

2-14. Operation in Extreme Cold (Below 0° F)

a. Frequently inspect for frozen water pipes or lines.

b. If freezing is evident, disconnect the water system from the welding machine and use only for regular arc welding.

2-15. Operation in Extreme Heat

a. Frequently inspect the fan motor and lubricate as necessary in accordance with the current lubrication order.

b. Make sure the welding machine has adequate ventilation.

2-16. Operation in Dusty or Sandy Areas

a. Keep dust and sand cleaned from welding machine as much as possible,

b. If dust or sand is blowing, provide a panel or shelter to give as much protection as possible to the welding machine.

c. Keep welding machine covered when not in use.


2-17. Operation Under Rainy or Humid Conditions

a. Provide as much protection as possible to keep rain from welding machine.

b. Keep the welding machine covered when not in use.

c. If water comes in contact with the high frequency panel, remove the panel and dry thoroughly before installing it in the welding machine.

Warning: Be extremely careful when the unit or surrounding area is damp or wet. Coming in contact with a wet or damp unit can cause a serious electrical shock or death.



STEP 1. PLACE POWER SWITCH IN ON POSITION.

STEP 2. TURN ON SOURCES OF GAS AND WATER.

STEP 3. PLACE GAS-WATER AND HIGH-FREQUENCY SWITCH IN ON POSITION. THE INDICATOR LIGHTS ASSOCIATED WITH THESE SWITCHES WILL NOT GLOW UNTIL GAS AND WATER BEGIN TO FLOW AND HIGH-FREQUENCY OSCILLATION BEGINS.

NOTE: WHEN TURNING GAS-WATER SWITCH ON, THERE IS A MOMENTARY FLOW OF GAS AND WATER.


STEP 4. DETERMINE WELDING RANGE BY SIZE OF WORK TO BE DONE AND SELECT THE PROPER ELECTRODE SIZE. ADJUST RANGE CONTROL TO PROPER POSITION.

STEP 5. SET POLARITY SWITCH IN ACCORDANCE WITH TYPE OF WELDING TO BE DONE AND TYPE OF ELECTRODE USED.

NOTE: FOR METALLIC ARC WELDING, FOLLOW STEPS 1,4, AND 5 ONLY AND SET THE CONTACTOR AND AMPERAGE SWITCHES IN THE CONTROL PANEL POSITION.

A. PANEL CONTROLS.

NOTE: IF EITHER HIGH-FREQUENCY DROPOUT TIMER OR SPOT ARC TIMER ARE NOT REQUIRED, TURN THE ASSOCIATED SWITCH TO THE OFF POSITION.



STEP 6. SET POST FLOW TIMER TO THE DESIRED POSITION.

STEP 7. SET HIGH-FREQUENCY DROPOUT TIMER TO DESIRED POSITION AND PLACE THE HIGH-FREQUENCY DROPOUT SWITCH TO ON POSITION.

STEP 8. CLOSE PANEL DOOR AND OPERATE THE WELDING MACHINE.

NOTE: FOR SPOT ARC WELDING, FOLLOW STEPS 1,4,5, AND 8, ONLY. PLACE THE HIGH-FREQUENCY AND SPOT ARC SWITCHES IN THE ON POSITION AND SET THE SPOT ARC TIMER TO THE DESIRED SETTING (0 TO 3 SECONDS).

NOTE: TO SET TIMERS, ROTATE THE COLORED DIAL (MARKED 0-A-B-C-D-E) TO THE DESIRED POSITION, DEPENDING ON THE JOB TO BE PERFORMED.

B. HIGH-FREQUENCY CONTROLS.

EMC 3431-203-15/10

Figure 2-6. Welding machine operation.

2-18. Operation in Saltwater Areas

- a.* Keep the welding machine protected as much as possible but do not block ventilation.
- b.* Inspect all connections, terminals, and fittings for corrosion.
- c.* Keep welding machine covered when not in use.

CHAPTER 3

OPERATOR AND ORGANIZATIONAL MAINTENANCE INSTRUCTIONS

Section I. OPERATOR AND ORGANIZATIONAL MAINTENANCE TOOLS AND EQUIPMENT

3-1. Special Tools and Equipment

No special tools or equipment are required by the operator or organizational maintenance personnel for the maintenance of the welding machine.

3-2. Basic Issue Tools and Equipment

Tools and repair parts issued with or au-

thorized, for the welding machine are listed in the basic issue items list, Appendix B of this manual.

3-3. Organizational Maintenance Repair Parts

Organizational maintenance repair parts are listed and illustrated in Appendix D of this manual.

Section II. LUBRICATION

3-4. General Lubrication Information

The only lubrication required for the welding machine is the lubrication of the fan motor. This section contains instructions for the lubrication of the fan motor.

3-5. Fan Motor Lubrication

Refer to figure 3-1 and lubricate the fan motor.

Note. Use engine oil MIL-L-2104 for lubricating the fan motor.




Figure 3-1. Fan motor, lubrication points.

Section III. PREVENTIVE MAINTENANCE SERVICES

3-6. General

To insure that the welding machine is ready for operation at all times, it must be inspected systematically, so that defects may be discovered and corrected before they result in serious damage and failure. The necessary preventive maintenance services to be performed are listed and described in paragraphs 3-7 and 3-8. The item numbers indicate the sequence of minimum inspection requirements. Defects discovered during operation of the unit shall be noted for future correction, to be made as soon as operation has ceased. Stop operation immediately if a deficiency is noted during operation which would damage the equipment if operation were continued. All deficiencies and shortcomings will be recorded, together with the corrective action taken, on DA Form 2404 (Equipment Inspection and Maintenance Worksheet) at the earliest possible opportunity.

3-7. Daily Preventive Maintenance Services

This paragraph contains an illustrated tabulated listing of preventive maintenance services which must be performed by the operator. The item numbers are listed consecutively and indicate the sequence of minimum inspection requirements. Refer to figure 3-2 for the daily preventive maintenance services.

3-8. Quarterly Preventive Maintenance Services

a. This paragraph contains an illustrated tabulated listing of preventive maintenance services which must be performed, by organizational maintenance personnel at quarterly intervals. A quarterly interval is equal to 3 calendar months or 250 hours of operation, whichever occurs first.

b. The item numbers are listed consecutively and indicate the sequence of minimum inspection requirements. Refer to figure 3-3 for the quarterly preventive maintenance services.


PREVENTIVE MAINTENANCE SERVICES

DAILY

TM5-3431-203-15

(MIDSTATES MODEL MAG 300 AC/DC T134)

WELDING MACHINE



ITEM		PAR REF
1	<u>SCREEN.</u> Clean a dirty screen.	
2	<u>GROUND TERMINAL.</u> Check for proper ground. A proper ground will consist of a 3/4-inch-dia. hollow rod or 5/8-inch-dia. solid rod, 9 feet long. The cable will be No. 6 AWG copper wire, bolted or clamped to the rod and attached to the ground terminal of the welder set.	
3	<u>CONTROLS.</u> Inspect for damage and loose mounting. With unit operating, check for proper operation.	14
	<u>NOTE 1. OPERATION.</u> During operation observe for any unusual noise or vibration.	

MEC 3431-203-15/3-2

Figure 3-2. Daily preventive maintenance services.


PREVENTIVE MAINTENANCE SERVICES

QUARTERLY

TM5-3431-203-15

WELDING MACHINE

(MIDSTATES MODEL MAG 300 AC/DC T134)



ITEM	PAR REF
1	<p>FAN MOTOR, FAN, AND SCREEN. Clean a dirty screen. Tighten loose motor and fan mounting and electrical connections. Lubricate fan motor every 500 hours. Replace defective fan motor or fan</p> <p style="text-align: right;">28 75 thru 79</p>
2	<p>CONTACTOR. Tighten loose mounting and electrical connections. Replace defective contactor.</p> <p style="text-align: right;">65</p>
3	<p>GROUND TERMINAL. Check for proper ground. A proper ground will consist of a 3/4-inch-dia. hollow rod or 5/8-inch-dia. solid rod 9 feet long. The cable will be No. 6 AWG copper wire, bolted or clamped to the rod and attached to the ground terminal of the welding set.</p>
4	<p>SOLENOID VALVES AND FITTINGS. Tighten loose mounting and electrical connections. Replace defective valves and fittings.</p> <p style="text-align: right;">72 to 74</p>
5	<p>CONTROLS. Replace damaged controls. Tighten loose mounting. With the unit operating, check for proper operation.</p> <p style="text-align: right;">14 53 thru 67</p>
	<p>NOTE 1. OPERATIONAL TEST. During operation observe for any unusual noise or vibration.</p> <p>NOTE 2. ADJUSTMENTS. Make all necessary adjustments during operational test.</p>

MEC 3431-203-15/3-3

Figure 3-3. Quarterly preventive maintenance services.

Section IV. OPERATOR'S MAINTENANCE

3-9. General

The instructions in this section are published for the information and guidance of personnel responsible for the operator's maintenance of the welding machine and are in addition to those listed in paragraph 3-7.

3-10. Pilot Lamps

Refer to figure 3-4 and remove and install the pilot lamps.




Figure 3-4. Pilot lamps, removal and installation.

Section V. TROUBLESHOOTING

3-11. General

This section provides information useful in diagnosing and correcting unsatisfactory operation or failure of the welding machine and its components. Each trouble symptom stated is followed by a list of probable causes of the trouble. The possible remedy recommended is described opposite the probable cause. Any trouble beyond the scope of organizational maintenance shall be reported to direct support maintenance.

3-12. Welding Machine Fails to Start

Probable cause	Possible remedy
Contractor open -----	Reset contractor.
Power switch defective ----	Replace switch (para 3-31).

Probable cause	Possible remedy
Interlock switch defective ----	Replace switch (para 3-35).

3-13. Cooling Fan Does Not Operate

Probable cause	Possible remedy
Lead broken or terminal loose.	Repair or tighten terminal (para 4-36).
Fan motor defective -----	Replace motor (para 3-52).

3-14. Fan Assembly Noisy

Probable cause	Possible remedy
Mounting hardware loose ----	Tighten hardware (para 3-52).
Fan blade loose -----	Tighten fan blade setscrew (para 3-52).

3-15. Gas Insufficient

Probable cause	Possible remedy
Lines or fittings obstructed.	Clean lines and/or fittings (para 3-49).
Solenoid defective -----	Replace solenoid (para 3-49).

3-16. Water Insufficient

Probable cause	Possible remedy
Lines or fittings obstructed.	Clean lines and/or fittings (para 3-50).
Solenoid defective -----	Replace solenoid (para 3-50).

3-17. Pilot Lights Inoperative

Probable cause	Possible remedy
Lamp burned out -----	Replace lamp (para 3-10).
Lead broken or connection loose.	Repair lead or tighten connection (para 3-30).
Socket defective -----	Replace socket (para 3-30).

3-18. Welding Machine Operates Erratically

Probable cause	Possible remedy
Spark gap improperly adjusted.	Clean adjusting screws and adjust spark gap (para 3-45).

3-19. Remote Control Does Not Function Properly

Probable cause	Possible remedy
Wires loose at receptacle	Tighten wires (para 3-38).
Receptacle defective -----	Replace receptacle (para 3-38).
Remote contactor switch defective.	Replace switch (para 3-39).
Remote amperage switch defective.	Replace switch (para 3-40).

3-20. Contactor Breaks Circuit

Probable cause	Possible remedy
Thermostatic switch defective.	Replace switch (para 3-42)

Section VI. FIELD EXPEDIENT REPAIRS

3-21. General

Operator and organizational maintenance troubles may occur while the welding machine is operating in the field where supplies and repair parts are not available and normal corrective action cannot be performed. When this condition exists, the following expedient repairs may be used in emergencies, upon the decision of the unit commander. Equipment so repaired must be removed, from operation as won as possible and properly repaired before being placed in operation again.

3-22. Loss of Water

Trouble	Expedient remedy
Pipe or fitting cracked -----	Tape cracked pipe or fitting until defective pipe or fittings can be replaced.

3-23. High Frequency Inoperative

Trouble	Expedient remedy
Timer defective -----	Exchange timers until defective timer can be replaced (para 3-34).

3-24. Power Failure

Trouble	Expedient remedy
Interlock switch defective.	Use jumper wire to bypass interlock switch until it can be replaced (para 3-35).
Contactor broken or defective.	Provide jumper wire around contactor until it can be replaced (para 3-41).

Section VII. WELDING MACHINE TOP, HOUSING, DOORS, AND PANELS

3-25. General

The welding machine housing is constructed

of a heavy metal top, sides, back section and front section. This section contains information on the maintenance of these components.

3-26. Welding Machine Top and Housing*a. Removal.*

- (1) Refer to figure 3-5 and remove the welding machine top.
- (2) Remove the fan, motor, and guard assembly (para 3-52).
- (3) Remove the gas and water solenoid valves (para 3-49 and 3-50).
- (4) Refer to figure 3-5 and remove the housing.

b. Installation.

- (1) Refer to figure 3-5 and install the housing.
- (2) Install the gas and water solenoid valves (para 3-49).
- (3) Install the fan, motor, and guard assembly (para 3-52).
- (4) Refer to figure 3-5 and install the welding machine top.

3-27. High Frequency Panel Assembly*a. Removal.*

- (1) Unlock and open panel door.

- (2) Disconnect jack tip terminals and panel wiring harness quick-disconnect plug.

- (3) Refer to figure 3-6 and remove the high frequency panel assembly.

b. Installation.

- (1) Refer to figure 3-6 and install the high frequency panel assembly.

- (2) Connect the jack tip terminals and the wiring harness quick-disconnect lug.

- (3) Close and lock the panel door.

3-28. Panel Door Lock*a. Removal.*


- (1) Unlock and open the high frequency panel door.

- (2) Refer to figure 3-7 and remove the panel door lock.

b. Installation.

- (1) Refer to figure 3-7 and install the panel door lock.

- (2) Close and lock the high frequency panel door.



EMC 3431-203-15/14

Figure 3-5. Welding machine top and housing, removal and installation.

NOTE: DISCONNECT QUICK DISCONNECT PLUGS FROM BEHIND PANEL AS NECESSARY.




Figure 3-6. High frequency panel assembly, removal and installation.




Figure 3-7. Panel door lock, removal and installation.

Section VIII. PILOT LIGHTS, SWITCHES, TIMERS, REMOTE RECEPTACLES, AND DUMMY PLUG

3-29. General

The pilot lights indicate the phase of operation that the machine is performing. The switches control the power, gas, water, and high frequency. The timers have plug-in type sockets for easy removal and maintenance; they control the postflow of gas and water, the preflow of gas and water, shut off high frequency oscillation at a predetermined time, and control the length of time the welding power is on. The dummy plugs are used when timers are not in the socket.

3-30. Pilot Lights

a. Removal.

- (1) Remove the pilot lamps (para 3-10).
- (2) Remove the high frequency panel assembly (para 3-27).
- (3) Refer to figure 3-8 and remove the pilot lights.

b. Installation.

- (1) Refer to figure 3-8 and, install the pilot lights.
- (2) Install the high frequency panel assembly (para 3-27).
- (3) Install the pilot lamps (para 3-10).

3-31. Power Switch

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).
- (2) Refer to figure 3-8 and remove the power switch.

b. Installation.

- (1) Refer to figure 3-8 and install the power switch.
- (2) Install the high frequency panel assembly (para 3-27).

3-32. Gas-Water Switch

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).
- (2) Refer to figure 3-8 and remove the gas-water switch.

b. Installation.

- (1) Refer to figure 3-8 and install the gas-water switch.
- (2) Install the high frequency panel assembly (para 3-27).

3-33. High Frequency Switch

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).
- (2) Refer to figure 3-8 and remove the high frequency switch.

b. Installation.

- (1) Refer to figure 3-8 and install the high frequency switch.
- (2) Install the high frequency panel assembly (para 3-27).

3-34. Timers

a. Removal.

- (1) Unlock and lower the high frequency panel door.
- (2) Refer to figure 3-9 and remove the timers.




Figure 3-8. Pilot lights and gas, water, power, and high frequency switches, removal and installation.

NOTE: PULL TIMER STRAIGHT OUT TO REMOVE FROM RECEPTACLE.

NOTE: REMOVE POST FLOW TIMER AND SPOT ARC TIMER IN A SIMILAR MANNER.




Figure 3-9. Timers and dummy plug, removal and installation.

b. Installation

Refer to figure 3-9 and, install the timers.

Close and lock the high frequency panel door.

Warning: Performances of any field expedient repair creates a condition possibly dangerous to the equipment or personnel. A welding machine so repaired should be taken out of service as soon as possible for replacement of the defective part.

3-35. Interlock Switch

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).
- (2) Refer to figure 3-10 and remove the interlock switch.

b. Installation.

- (1) Refer to figure 3-10 and install the interlock switch.
- (2) Install the high frequency panel assembly (para 3-27).

c. Field Expedient Repair. If the interlock switch is defective, place a jumper wire across the terminals and bypass the switch.

3-36. High Frequency Spot ARC Switch

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).
- (2) Refer to figure 3-10 and remove the high frequency spot arc switch.

b. Installaion.

- (1) Refer to figure 3-10 and install the high frequency spot arc switch.
- (2) Install the high frequency panel assembly (para 3-27).




Figure 3-10. Interlock, spot arc, and drop out switch, removal and installation.

3-37. High Frequency Dropout Switch

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).
- (2) Refer to figure 3-10 and remove the high frequency dropout switch.

b. Installation.

- (1) Refer to figure 3-10 and install the high frequency dropout switch.
- (2) Install the high frequency panel assembly (para 3-27).

3-38. Remote Receptacle

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).
- (2) Refer to figure 3-11 and remove the remote receptacle.

b. Installation.

- (1) Refer to figure 3-11 and install the remote receptacle.
- (2) Install the high frequency panel assembly (para 3-27).




Figure 3-11. Remote contactor switch, amperage switch, and receptacle, removal and installation.

3-39. Remote Contractor Switch

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).
- (2) Refer to figure 3-11 and remove the remote contactor switch.

b. Installation.

- (1) Refer to figure 3-11 and install the remote contactor switch.
- (2) Install the high frequency panel assembly (para 3-27).

3-40. Remote Amperage Switch

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).
- (2) Refer to figure 3-11 and remove the remote amperage switch.

b. Installation.

- (1) Refer to figure 3-11 and, install the remote amperage switch.
- (2) Install the high frequency panel assembly (para 3-27).

3-41. Contactor

a. Removal.

- (1) Remove the welder top housing (para 3-26).

- (2) Refer to figure 3-12 and remove the contactor.

b. Installation.

- (1) Refer to figure 3-12 and install the contactor.
- (2) Install the welder top and housing (para 3-26).

c. Field Expedient Repair. If the contactor becomes defective, place a jumper wire across the terminals and bypass the contactor.

Caution: Performance of any field expedient repair creates a condition possibly dangerous to equipment and personnel. A welding machine so repaired must be taken out of service as soon as possible for replacement of the defective part.

3-42. Thermostatic Switch

a. Removal.

- (1) Remove the welder top and housing (para 3-26).
- (2) Refer to figure 3-13 and remove the thermostatic switch.




Figure 3-12. Contactor, removal and installation.




Figure 3-13. Thermostatic switch, removal and installation.

b. Installation.

- (1) Refer to figure 3-13 and install the thermostatic switch.
- (2) Install the welder top and housing (para 3-26).

3-43. Dummy Plug

a. Removal.

- (1) Unlock and lower the high frequency panel door.
- (2) Refer to figure 3-9 and remove the dummy plug.

b. Installation.

- (1) Refer to figure 3-9 and install the dummy plug.
- (2) Close and lock the high frequency panel door.

Section IX. SPARK GAP ADJUSTER, VOLTAGE CHANGE BARS, AND GROUND AND ELECTRODE TERMINAL BOARD

3-44. General

The primary purpose of the spark gap adjuster is to control the stability of the high frequency arc. The purpose of the voltage change bars is to allow the welding machine to operate from either 230 or 460 volts by the correct changing of the bars. The ground, and electrode cable terminal lugs are connected by brass nuts to the studs on the ground and electrode terminal board.

3-45. Spark Gap Adjuster

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).
- (2) Refer to figure 3-14 and remove the spark gap adjuster.

b. Installation.

- (1) Refer to figure 3-14 and install the spark gap adjuster.
- (2) Install the high frequency panel assembly (para 3-27).

c. Adjustment. Refer to figure 3-14 and adjust the spark gap.


3-46. Voltage Change Bars

a. Removal.

- (1) Remove the two securing screws and raise the voltage change bar access door on the rear of the welding machine.
- (2) Refer to figure 3-15 and remove the voltage change bars.

b. Installation.

- (1) Refer to figure 3-15 and install the voltage change bars.



- STEP 1. LOOSEN LOCKSCREW
- STEP 2. INSERT A 0.005-IN. FEELER GAGE BETWEEN SPARK GAP ADJUSTING SCREW POINTS.
- STEP 3. TURN ADJUSTING SCREW COUNTERCLOCKWISE TO INCREASE GAP AND CLOCKWISE TO DECREASE GAP.
- STEP 4. ADJUST SCREW POINTS UNTIL A SLIGHT DRAG IS FELT AS FEELER GAGE IS REMOVED. TIGHTEN LOCKSCREW.

EMC 3431-203-15/23

Figure 3-14. Spark gap adjuster, removal, installation, and adjustment.

- (2) Close the access door and replace the two securing screws.

3-47. Ground and Electrode Terminal Board

a. Removal.

- (1) Remove the welder top and housing (para 3-26).
- (2) Refer to figure 3-16 and remove the ground and electrode terminal board.

b. Installation.

- (1) Refer to figure 3-16 and install the ground and electrode terminal board.
- (2) Install the welder top and housing (para 3-26).




Figure 3-15. Voltage change bars, removal and installation.




Figure 3-16. Ground and electrode terminal board, removal and installation.

Section X. GAS AND WATER SOLENOID VALVES

3-48. General


The gas solenoid valve is used when the operator is performing inert-gas welding. The solenoid valve is operated electrically through the timer control. The water solenoid valve is used when a water-cooled torch is used. The water solenoid valve is operated electrically through the timer control.

3-49. Gas Solenoid Valve

Refer to figure 3-17 and remove and install the gas solenoid valve.

3-50. Water Solenoid Valve

Refer to figure 3-17 and remove and install the water solenoid valve.



- STEP 1. REMOVE SCREW (4) AND LAY PANEL FORWARD.
- STEP 2. TAG AND DISCONNECT ELECTRICAL LEADS FROM SOLENOID VALVES.
- STEP 3. TURN FITTING (4) COUNTERCLOCKWISE AND REMOVE.
- STEP 4. REMOVE SOLENOID VALVES FROM REAR OF PANEL.

EMC 3431-203-15/26

Figure 3-17. Gas and water solenoid valves, removal and installation.

Section XI. VENTILATING-COOLING SYSTEM

3-51. General

The welding machine is cooled by a fan motor assembly which operates from the accessory power transformer. It has four aluminum blades which pull the air through the welder and out the back. The ballast resistors are mounted on the fan guard so that they can be cooled by the air as it passes through them. To make any repairs on the motor fan blade, or guard, the complete assembly must be removed.

3-52. Fan, Motor, and Guard Assembly

a. Removal.

- (1) Remove the welding machine top and housing (para 3-26).
- (2) Disconnect the motor leads from the top and bottom terminals of the accessory transformer.
- (3) Refer to figure 3-1 and remove the fan, motor, and guard as a complete unit.




Figure 3-18. Fan, motor, and guard assembly, removal and installation.

b. *Disassembly and Reassembly.* Refer to figure 3-19 and disassemble and reassemble the fan, motor, and guard assembly.

c. *Installation.*

- (1) Refer to figure 3-18 and install the fan, motor, and guard assembly.
- (2) Connect the motor leads to the top and bottom terminal of the accessory transformer.
- (3) Install the welder top and housing (para 3-26).

3-53. Motor

a. *Removal.*

- (1) Refer to figure 3-18 and remove the fan, motor, and guard assembly.
- (2) Refer to figure 3-19 and remove the fan motor.

b. *Installation.*

- (1) Refer to figure 3-19 and install the fan motor.

- (2) Refer to figure 3-18 and install the fan, motor, and guard assembly.

3-54. Fan

a. *Removal.*

- (1) Refer to figure 3-18 and remove the fan motor, and guard assembly
- (2) Refer to figure 3-19 and remove the fan.

b. *Installation.*

- (1) Refer to figure 3-19 and install the fan.
- (2) Refer to figure 3-18 and install the fan, motor, and guard assembly.

3-55. Guard

a. *Removal.*

- (1) Refer to figure 3-18 and remove the fan, motor, and guard assembly,




Figure 3-19. Fan, motor, and guard assembly, disassembly and reassembly.

(2) Refer to figure 3-19 and remove the guard.

(2) Refer to figure 3-18 and install the fan, motor, and guard assembly.

b. Installation.

(1) Refer to figure 3-19 and install the guard.

CHAPTER 4

DIRECT AND GENERAL SUPPORT AND DEPOT MAINTENANCE INSTRUCTIONS

Section I. GENERAL

4-1. Scope

a. The following instructions are for direct and general support and depot maintenance personnel. They contain information on equipment maintenance that is beyond the scope of the tools, equipment, personnel, or supplies normally available to organizational maintenance.

b. Appendix A includes the list of publications applicable to direct and general support and depot maintenance. Appendix C contains the maintenance allocation chart. The direct

and general support and depot maintenance repair parts and special tool lists are in Appendix D.

4-2. Record and Report Forms

For record and report forms applicable to direct and general support and depot maintenance, refer to TM 38-750.

Note. Applicable forms, excluding Standard Form 46 (United States Government Motor Vehicles Operator's Identification Card) which is carried by the operator, shall be kept in a canvas bag mounted on the equipment.

Section II. DESCRIPTION AND DATA

4-3. Description

For a complete description of the welding machine, refer to paragraph 1-3.

4-4. Tabulated Data

a. *General.* This paragraph contains all the overhaul data pertinent to direct and general support and depot maintenance personnel. A wiring diagram (fig. 4-1) is also included.

*Figure 4-1. Schematic wiring diagram.
(Located in back of manual)*

b. Accessory Transformer.

Primary ----- 230/460V
Cycles -----60

c. Nut and Bolt Torque Data.

Diodes -----35-70 ft-lbs (foot- pounds).

d. *Time Standards.* Table 2-1 lists the number of man-hours required under normal conditions to perform the indicated maintenance and repair for the welding machine. Un-

der adverse conditions, the operations will take longer; but under ideal conditions, with highly-skilled mechanics, most of the operations can be accomplished in considerably less time.

Table 4-1. Time Standards

	Man-hours
<i>Lubrication and Service.</i>	
40 ELECTRIC MOTORS	
4000 Electric Motors	
Motor, fan -----	0.1
(lubricate.)	
<i>Remove and Replace</i>	
22 ACCESSORY ITEMS	
2210 Data Plates and Instruction Holders	
Plates, Instruction -----	0.3
40 ELECTRIC MOTORS	
4000 Electric Motors	
Motor, fan -----	1.3
(Includes removal and installation of top cover and guard)	

Table 4-1. Time Standards -Continued

	Man-hours
44 WELDING EQUIPMENT	
4400 Arc Welder	
Welder, arc -----	0.5
4405 Frame Support and Housing	
Lifting eye -----	0.2
Cover, top -----	0.3
Door rear terminal -----	0.3
Housing welder -----	0.5
Plate, Valve -----	0.4
4406 Ventilating, Cooling System	
Blade, fan -----	1.0
Guard, fan -----	1.4
(includes R & I of motor and fan)	
4407 Control Panels	
Light, pilot -----	0.4
Lamp -----	0.2
Switch, control -----	0.5
4408 Connecting Devices Receptacle	
Remote control -----	0.6
Panel -----	0.3
Stud, terminal -----	0.6
Remote control -----	0.7
4409 Protective Devices	
Switch, interlock -----	0.6
Switch, thermostatic -----	0.6
4410 Switching and Timing Speed	
Switch, control -----	0.6
Timer, plug-in -----	0.4
Relay, timer -----	0.4
Spark gap assembly -----	1.4
Contactor -----	0.6

Table 4-1. Time Standards - Continued

	Man-hours
Valve, solenoid -----	0.4
Plug dummy -----	0.4
Switch range - -----	1.0
Capacitor -----	1.8
Switch, polarity -----	0.7
4411 Resistor Components	
Resistor -----	0.6
Rheostat -----	0.8
(includes R & I of top cover)	
4412 Transformer Components	
Transformer, main -----	1.6
(includes complete disassembly of unit)	
Capacitor, power -----	1.2
(Includes R & I of top cover and housing)	
Reactor assembly -----	2.0
(includes R & I of top cover and housing)	
Coil assembly, filter reactor --	2.0
(includes R & I of top cover and housing)	
Transformer -----	1.0
(includes removal and instal- lation of top cover and housing)	
Coil, tesla -----	1.0
Transformer, control -----	2.6
4413 Rectifier Components	
Rectifier, main -----	1.5
(includes R & I of top cover and housing)	
Rectifier, control -----	1.0

Section III. SPECIAL TOOLS AND EQUIPMENT

4-5. Special Tools and Equipment

No special tools or equipment are required by direct and general support and depot maintenance for the maintenance of the welding machine.

4-6. Direct and General Support and Depot Maintenance Repair Parts

Direct and general support and depot main-

tenance repair parts are listed and illustrated in Appendix D of this manual.

4-7. Specially Designed Tools and Equipment

No specially designed tools and equipment are required by direct and general support and depot maintenance for the maintenance of the welding machine.

Section IV. TROUBLESHOOTING

4-8. General

This section provides information useful in diagnosing and correcting unsatisfactory operation or failure of the welding machine or

any of its components. Each trouble symptom stated is followed by a list of probable causes of the trouble. The possible remedy recommended is described opposite the probable cause.

4-9. Welding Machine Smokes Excessively

Probable cause	Possible remedy
Main transformer defective.	Replace transformer (para 4-34).
Accessory transformer defective.	Replace transformer (para 4-32).

4-10. Polarity Cannot be Selected

Probable cause	Possible remedy
Polarity switch defective	Replace switch (para 4-19) .

4-11. Range Cannot be Selected

Probable cause	Possible remedy
Range switch defective	Replace switch (para 4-18),

4-12. Welding Machine has Internal Arcing

Probable cause	Possible remedy
Diode connections loose	Tighten diode connections (para 4-24).

4-13. Welding Machine Fails to Start

Probable cause	Possible remedy
Main transformer defective.	Replace transformer (para 4-34).
Wiring defective	Repair or replace wiring (para 4-34).

4-14. Welding Machine Operates Erratically

Probable cause	Possible remedy
Diodes defective	Replace diodes (para 4-24).
Control rheostat defective,	Replace rheostat (para 4-20) .
Range switch contacts dirty, greasy, or bent.	Clean or straighten contacts or replace switch (para 4-18) .

4-15. Contactor Breaks Circuit

Probable cause	Possible remedy
Wiring shorted	Repair or replace wiring (para 4-36).
Main transformer shorted.	Replace transformer (para 4-34).

Section V. CONTROL PANEL AND TIMER RECEPTACLES

4-16. Control Panel

a. Removal.

- (1) Remove the welder top and housing (para 3-26).
- (2) Remove the high frequency panel assembly (para 3-27).
- (3) Remove the control rheostat (para 4-20).
- (4) Remove the range switch (para 4-18).
- (5) Remove the polarity switch (para 4-19).
- (6) Remove the ground and electrode terminal board (para 3-47).
- (7) Remove the remote receptacle (para 3-38).
- (8) Remove the contactor switch (para 3-41).
- (9) Remove the amperage switch (para 3-40).
- (10) Refer to figure 4-2 and remove the control panel.

b. Installation.

- (1) Refer to figure 4-2 and install the control panel.

- (2) Install the amperage switch (para 3-40).
- (3) Install the contactor switch (para 3-41).
- (4) Install the remote receptacle (para 3-38).
- (5) Install the ground and electrode terminal board (para 3-7).
- (6) Install the polarity switch (para 4-19).
- (7) Install the range switch (para 4-18).
- (8) Install the control rheostat (para 4-20).
- (9) Install the high frequency panel assembly (para 3-27).
- (10) Install the welder top and housing (para 3-26).

4-17. Timer Receptacles

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).




Figure 4-2. Control panel, removal and installation.




Figure 4-3. Timer receptacles, removal and installation.

- (2) Refer to figure 4-3 and remove the timer receptacles

b. Installation.

- (1) Refer to figure 4-3 and install the timer receptacles.
- (2) Install the high frequency panel assembly (para 3-27).

Section VI. RANGE SWITCH, POLARITY SWITCH, CONTROL RHEOSTAT, AND INTENSITY SELECTOR

4-18. Range Switch


a. Removal.

- (1) Remove the welding machine top and housing (para 3-26).
- (2) Remove the high frequency panel assembly (para 3-27).
- (3) Loosen control panel from frame (para 4-16).

- (4) Refer to figure 4-4 and remove the range switch.

b. Installation.

- (1) Refer to figure 4-4 and install the range switch.
- (2) Secure the control panel to the frame (para 4-16).
- (3) Install the high frequency panel assembly (para 3-27).



NOTE: REMOVE POLARITY SWITCH IN A SIMILAR MANNER AS RANGE SWITCH.
 NOTE: REMOVE CONTROL RHEOSTAT, RANGE SWITCH, AND POLARITY SWITCH FROM REAR OF PANEL.

EMC 3431-203-15/33

Figure 4-4. Range switch, polarity switch, and control rheostat, removal and installation.

- (4) Install the welding machine top and housing (para 3-26).

4-19. Polarity Switch

a. Removal.

- (1) Remove the welding machine top and housing (para 3-26).
- (2) Remove the high frequency panel assembly (para 3-27).
- (3) Loosen the control panel from the frame (para 4-16).
- (4) Refer to figure 4-4 and remove the polarity switch.

b. Installation.

- (1) Refer to figure 4-4 and install the polarity switch.

- (2) Secure the control panel to the frame (para 4-16).
- (3) Install the high frequency panel assembly (para 3-27).
- (4) Install the welder top and housing (para 3-26).

4-20. Control Rheostat

a. Removal.

- (1) Remove the welding machine top and housing (para 3-26).
- (2) Remove the high frequency panel assembly (para 3-27).
- (3) Loosen the control panel from the frame (para 4-16).
- (4) Refer to figure 4-4 and remove the control rheostat.

b. Testing.

- (1) Connect an ohmmeter to the two outer terminals of the rheostat and set the meter on RX1 scale. The reading should be 32 ohms. If the reading is more or less than 32 ohms, replace the rheostat.
- (2) Connect an ohmmeter to the center terminal and either outside terminal of the rheostat. Set the meter on the RX1 scale. Turn the rheostat in either direction until it stops, then turn it in the opposite direction slowly and evenly until it stops again. The indicator on the meter should increase or decrease evenly according to the speed in which the rheostat is turned. If the meter indicator does not function as described, replace the rheostat.

Note. Make sure the ohmmeter used for the above tests is in proper working condition.

c. Installation.

- (1) Refer to figure 4-4 and install the control rheostat.
- (2) Secure the control panel to the frame (para 4-16).
- (3) Install the high frequency panel assembly (para 3-27).
- (4) Install the welding machine top and housing (para 3-26).

4-21. Intensity Selector

a. Removal.

- (1) Unlock the lower panel door.
- (2) Refer to figure 4-5 and remove the intensity selector.

b. Testing.

- (1) Connect an ohmmeter to the outside terminals of the selector, and set the meter on the RX1 scale. The reading should be 2 ohms. If the reading is more or less than 2 ohms replace the intensity selector.
- (2) Connect the ohmmeter to the center terminal and either outside terminal. Set the meter on the RX1 scale. Turn the intensity selector in a clockwise direction until it stops; the meter should have a zero reading. Then turn the intensity selector in a counterclockwise direction until it stops. The reading should be 2 ohms. If the readings are not as described, replace the intensity selector.

Note. Make sure that the ohmmeter used for the above tests is in proper working condition.

c. Installation.

- (1) Refer to figure 4-5 and install the intensity selector.
- (2) Close and lock the panel door.




Figure 4-5. Intensity selector, removal and installation.

Section VII. CONTROL RECTIFIER, RECTIFIER ASSEMBLY, DIODES, CAPACITORS, AND RESISTORS

4-22. Control Rectifier

a. Removal.

- (1) Remove the welding machine top and housing (para 3-26),
- (2) Refer to figure 4-6 and remove the control rectifier.

Warning: When malfunction of the selenium rectifier occurs, thoroughly ventilate the area to prevent inhalation of poisonous fumes. Do not handle the damaged rectifier while it is warm, to avoid absorption of the poisonous selenium oxide compound through the skin. Failure to observe this warning can result in serious injury or death.

b. Installation.

- (1) Refer to figure 4-6 and install the control rectifier.
- (2) Install the welding machine top and housing (para 3-26).

4-23. Rectifier Assembly

a. Removal.

- (1) Remove the welding machine top and housing (para 3-26).
- (2) Refer to figure 4-7 and remove the rectifier assembly.

b. Disassembly and Reassembly. Refer to figure 4-8 and disassemble and reassemble the rectifier assembly.

c. Installation.

- (1) Refer to figure 4-7 and install the rectifier assembly.




Figure 4-6. Control rectifier, removal and installation.

- (2) Install the welding machine top and housing (para 3-26).

4-24. Diodes

a. Removal.

- (1) Remove the welding machine top and housing (para 3-26).
- (2) Refer to figure 4-7 and remove the diodes.

b. Installation.

- (1) Refer to figure 4-7 and install the diodes.
- (2) Install the welding machine top and housing (para 3-26).

4-25. Capacitors

a. Removal.

- (1) Remove and welding machine top and housing (para 3-26).




Figure 4-7. Rectifier assembly and diodes, removal and installation.

- (2) Remove the high frequency panel assembly (para 3-27).
- (3) Refer to figure 4-9 and remove the capacitors.

b. Testing. Connect a suitable capacitor tester to the wire leads and check the capacitors for open or shorted circuit.

c. Installation.

- (1) Refer to figure 4-9 and install the capacitors.
- (2) Install the high frequency panel assembly (para 3-27).
- (3) Install the welding machine top and housing (para 3-26).

4-26. Resistors

a. Removal.


- (1) Remove the welding machine top and housing (para 3-26).

- (2) Remove the high frequency panel assembly (para 3-27).
- (3) Refer to figure 4-10 and remove the resistors.

b. Testing. Connect an ohmmeter to the resistor leads and check the resistance. The meter reading must conform with the resistor values shown on the wiring diagram (fig. 4-1).

c. Installation.

- (1) Refer to figure 4-10 and install the resistors.
- (2) Install the high frequency panel assembly (para 3-27).
- (3) Install the welding machine top and housing (para 3-26).



EMC 3431-203-15/37

Figure 4-8. Rectifier assembly, disassembly and reassembly.

- 1 Nut, hex 3/8-16 (12)
- 2 Washer, flat 7/16 in. (8)
- 3 Washer, insulating, 9/16 in. (6)
- 4 Rectifier plate (4)

- 5 Spacer 9/16 x 2 3/4 in. (4)
- 6 Spacer 3/4 x 2 1/4 in. (4)
- 7 Rod, threaded, 3/8 x 21 in. (2)
- 8 Capscrew, hex-hd, 1/4-20 x 5/8 in. (2)

- 9 Nut, hex, 1/4-20 (2)
- 10 Washer, lock, 1/4 in. (2)
- 11 Copper bar
- 12 Washer, lock 3/8 in.

Figure 4-8—Continued





Figure 4-9 (1). Capacitors, removal and installation.


NOTE: TAG AND DISCONNECT ELECTRICAL LEADS AS NECESSARY



WARNING: SHORT THE CAPACITOR CONNECTIONS TO GROUND BEFORE REMOVAL. FAILURE TO DO THIS MAY RESULT IN A SERIOUS ELECTRICAL SHOCK.

B. HIGH FREQUENCY AND BYPASS CAPACITORS.

NOTE: TAG AND DISCONNECT LEADS AT BOTH ENDS.




C. RECTIFIER ASSEMBLY WAFER CAPACITOR.

EMC 3431-203-15/38 (2)

Figure 4-9 (2). - Continued.



NOTE: TAG AND DISCONNECT ELECTRICAL LEADS AS NECESSARY.





A. RECTIFIER ASSEMBLY RESISTORS.

NOTE: TAG AND DISCONNECT ELECTRICAL LEADS AS NECESSARY.

NOTE: REMOVE NUT (2) FROM INSIDE OF FAN GUARD.



B. BALLAST RESISTORS.



C. BYPASS RESISTOR.

Figure 4-10. Resistors, removal and installation.

Section VIII. TIMER RELAY, SWITCHING PANEL, FILTER REACTOR, REACTOR COIL AND TESLA COIL

4-27. Timer Relay

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).
- (2) Refer to figure 4-11 and remove the timer relay.

b. Installation.

- (1) Refer to figure 4-11 and install the timer relay.
- (2) Install the high frequency panel assembly (para 3-27).

4-28. Switching Panel

a. Removal.

- (1) Remove the welding machine top and housing (para 3-26).
- (2) Remove the contactor screws (para 3-41).
- (3) Refer to figure 4-12 and remove the switching panel.

b. Installation.

- (1) Refer to figure 4-12 and install the switching panel.
- (2) Install the contactor screws (para 3-41).
- (3) Install the welding machine top and housing (para 3-26).

4-29. Filter Reactor

a. Removal.

- (1) Remove the welding machine top and housing (para 3-26).
- (2) Remove the rectifier assembly (para 4-23).
- (3) Disconnect the filter reactor lead from the polarity switch (para 4-19).
- (4) Refer to figure 4-13 and remove the filter reactor.

b. Testing. Connect an ohmmeter to the filter reactor leads and check from an open circuit.

c. Installation.

- (1) Refer to figure 4-13 and install the filter reactor.
- (2) Connect the filter reactor lead to the polarity switch (para 4-19).
- (3) Install the rectifier assembly (para 4-23).
- (4) Install the welding machine top and housing (para 3-26).





Figure 4-11. Timer relay, removal and installation.

4-30. Reactor Coil

a. Removal.

- (1) Remove the welding machine top and housing (para 3-26).
- (2) Remove the rectifier assembly (para 4-23).
- (3) Disconnect the coil lead from the polarity switch (para 4-19).
- (4) Refer to figure 4-13 and remove the reactor coil.

b. Testing. Connect a multiimeter to the tail leads and set the meter on ohms. If the indicator gives no reading, the coil has an open circuit and must be replaced.



EMC 3431-203-15/41

Figure 4-12. Switching panel, removal and installation.

c. Installation.

- (1) Refer to figure 4-13 and install the reactor coil.
- (2) Connect the coil lead to the polarity switch (para 4-19).
- (3) Install the rectifier assembly (para 4-23).
- (4) Install the welding machine top and housing (para 3-26).

- (2) Refer to figure 4-14 and remove the tesla coil.

b. Testing.

- (1) Connect a multimeter to the coil leads and test for continuity.
- (2) If there is no reading on the multimeter, replace the coil.
- (3) Connect a megohmmeter to the coil and test the insulation breakdown.


c. Installation.

- (1) Refer to figure 4-14 and install the tesla coil.
- (2) Install the welding machine top and housing (para 3-26).

4-31. Tesla Coil

a. Removal.

- (1) Remove the welding machine top and housing (para 3-26).



EMC 3431-203-15 45

Figure 4-13. Main transformer reactor coil and filter reactor, removal and installation.




Figure 4-14. Tesla coil and bracket, removal and installation.

Section IX. ACCESSORY TRANSFORMER, HIGH FREQUENCY CONTROL TRANSFORMER, AND MAIN TRANSFORMER

4-32. Accessory Transformer

a. Removal.

- (1) Remove the welding machine top and housing (para 3-26).
- (2) Refer to figure 4-15 and remove the accessory transformer.

h. Testing.

- (1) Connect a 230-volt power source to the yellow input lead and black center tap lead, as indicated on the lead.
- (2) Connect a voltmeter to the common terminal and the center tap. The meter reading should be 24 volts.
- (3) Connect the voltmeter to the common terminal and the 230-volt terminal. The reading should be 230 volts.

- (4) If the meter reading is other than that specified above, the transformer must be replaced.

c. Installation.

- (1) Refer to figure 4-15 and install the accessory transformer.
- (2) Install the welding machine top and housing (para 3-26).

4-33. High Frequency Control Transformer

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).
- (2) Refer to figure 4-16 and remove the high frequency control transformer.

b. Testing.

- (1) Connect a voltmeter to the secondary leads.




Figure 4-15. Accessory transformer, removal and installation.

- (2) Connect a 230-volt power source to the primary winding of the transformer.
- (3) The meter should read 3,500 volts. If the indicated reading is not obtained, the transformer must be replaced.

Warning: When making a test on the high frequency control transformer, make sure the transformer is on an insulated bench. Do not touch the transformer or wires leading from it. To do so may cause serious electrical shock or possible death to personnel performing the test.




Figure 4-16. High frequency control transformer, removal and installation.

c. Installation.

- (1) Refer to figure 4-16 and install the high frequency control transformer.
- (2) Install the high frequency panel assembly (para 3-27).

4-34. Main Transformer

a. Removal.

- (1) Remove the welding machine top and housing (para 3-26).
- (2) Remove the control panel (para 4-16).
- (3) Remove the control rectifier (para 4-22).
- (4) Remove the rectifier assembly (para 4-23).
- (5) Remove the filter reactor (para 4-29).
- (6) Remove the tesla coil (para 4-31).
- (7) Remove the accessory transformer (para 4-32).
- (8) Remove the switching panel (para 4-28).

- (9) Refer to figure 4-13 and remove the main transformer.

b. *Installation.*

- (1) Refer to figure 4-13 and install the main transformer.
- (2) Install the switching panel (para 4-28).
- (3) Install the accessory transformer (para 4-32).
- (4) Install the tiesla coil (para 4-31).

- (5) Install the filter reactor (para 4-29).
- (6) Install the rectifier assembly (para 4-23).
- (7) Install the control rectifier (para 4-22).
- (8) Install the control panel (para 4-16).
- (9) Install the welding machine top and housing (para 3-26).

Section X. WIRING HARNESS AND HIGH FREQUENCY PANEL

WIRING HARNESS

4-35. General

The welding machine has a wiring harness separate from the high frequency panel. The two separate wire groups are connected through a quick-disconnect type plug, to complete the electrical circuits.

4-36. Wiring and Wiring Harness

a. *Removal.*

- (1) Remove the welding machine top and housing (para 3-26).
- (2) Remove the high frequency panel assembly (para 3-27).
- (3) Remove the harness wires from the polarity switch (para 4-19).
- (4) Remove the wires from the control rheostat (para 4-20).
- (5) Remove the wines from the remote receptacle (para 3-38).
- (6) Remove the thermostatic switch (para 3-42).
- (7) Remove the wires from the control rectifier (para 4-22).
- (8) Remove the harness wires from the accessory transformer (para 4-32).
- (9) Remove the wires from the contactor (para 3-41).
- (10) Remove the red and purple wires from the switching panel (para 4-28).
- (11) Remove the quick-disconnect receptacle from the control panel (para 4-16).
- (12) Remove the tape which secures the harness to the frame and remove the harness.

b. *Testing.* To test a wire for continuity, disconnect each end of the wire from the component or components to which it is connected. Touch the test probes of a multimeter to each end of the wire. If continuity is not indicated, the wire is defective and must be repaired or replaced (*c* and *d* below).

c. *Repair.* Shave the insulation on the wire to expose one-half inch of bare wire at both ends of the break. Twist the bare wire together and solder the connection. Cover the repaired break with electrical tape. Do not leave any bare wire exposed. If a terminal lug is damaged, or breaks off a wire, replace it using an exact duplicate terminal lug.

d. *Replacement.* Replace a wire by disconnecting it from the component or components to which it is connected and remove the wire. Install a new wipe and connect it to the component or components. If a broken wire is part of a wiring harness, disconnect the wire at both ends and tape the ends with electrical tape. Install a new wire and attach it to the exterior of the wiring harness.

e. *Installation.*

- (1) Place the wiring harness in the welding machine and tape it to the frame.
- (2) Install the quick-disconnect receptacle on the control panel (para 4-16).
- (3) Connect the red and purple wires to the switching panel (para 4-28).
- (4) Connect the wines to the contactor (para 3-41).
- (5) Connect harness wires to the accessory transformer (para 4-32).

- (6) Connect the wires to the control rectifier (para 4-22).
- (7) Install the thermostatic switch (para 3-42)
- (8) Connect the wires to the remote receptacle (para 3-38).
- (9) Connect the wires to the control rheostat (para 4-20).
- (10) Connect the wires to the polarity switch (para 4-19).
- (11) Install the high frequency panel assembly (para 3-27).
- (12) Install the welding machine top and housing (para 3-26).

4-37. High Frequency Panel Wiring and Wiring Harness

a. Removal.

- (1) Remove the high frequency panel assembly (para 3-27).
- (2) Refer to figure 4-17 and remove the high frequency panel wiring harness.

b. Installation.

- (1) Refer to figure 4-17 and install the high frequency panel wiring harness.
- (2) Install the high frequency panel assembly (para 3-27).




Figure 4-17. High frequency panel wiring harness, removal and installation.

Section XI. FRAME AND MAIN TRANSFORMER SUPPORT ASSEMBLY

4-38. General

The welding machine frame and main transformer support assembly is of one piece and constructed of heavy metal. It has two skids which are welded to the bottom and are de-

signed for bolting the welding machine to the floor. The skids also hold the welding machine approximately four inches above the floor to allow for circulation of air through the welding machine for cooling. The main transformer is mounted to the frame with four

bolts; the vertical bars are used for mounting of component parts and the top.

4-39. Frame and Main Transformer Support Assembly

a. Removal.

- (1) Remove the main transformer (para 3-34).

- (2) After the main transformer is removed, the frame and transformer support assembly (fig. 4-16) is free.

b. Installation. Install the main transformer on the frame and transformer support assembly (para 4-39).

APPENDIX A

REFERENCES

A-1. Fire Protection

TB 5-4200-200-10 Hand Portable, Fire Extinguishers for Army Users.

A-2. Painting

TM 9-213 Painting Instructions for Field Use.

A-3. Preventive Maintenance

TM 38-750 Army Equipment Record Procedures.

APPENDIX B

BASIC ISSUE ITEMS LIST AND OPERATING SUPPLIES

Section I. INTRODUCTION

B-1. Scope

This appendix lists items which accompany the Welding Machine or are required for installation, operation, or operator's maintenance. Section II lists the accessories, tools, and publications required for the maintenance and operation by the operator, initially issued or authorized with the equipment.

B-2. Explanation of Columns

The following provides an explanation of columns in the tabular list in Section II.

a. Source, Maintenance and Recoverability Codes (Column 1).

- (1) Source code, column 1a, indicates the selection status and source for the listed item. Source codes are:

Code	Explanation
P	Applied to repair parts which are stocked in or supplied from the GSA/DSA Army Supply System, and authorized for use at indicated maintenance categories.
M	Applied to repair parts which are not procured or stocked but are to be manufactured at indicated maintenance categories.
X2	Applied to repair parts which are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain them through cannibalization. If not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels

- (2) Maintenance code, column 1b, indicates the lowest category of maintenance

authorized to install the listed item. The maintenance level code is:

Code	Explanation
0	Organizational maintenance (operator/crew).

- (3) Recoverability code, column 1c, indicates whether unserviceable items should be returned for recovery or salvage. Items not coded are expendable.

b. Federal Stock Number, column 2, indicates the Federal stock number for the item.

c. Description, column 3 indicates the Federal item name and any additional description required. A fivedigit manufacturer's code or other service code and part number is included in parentheses for reference. Repair parts quantities included in kits, sets, and assemblies are shown in front of the repair part name.

d. Unit of Issue, column 4, indicates the unit used as a basis for issue, e.g., ea, pr, ft, yd, etc.

e. Quantity Incorporated in Unit Pack, column 5, indicates the actual quantity contained in the unit pack.

f. Quantity Incorporated in Unit, column 6, indicates the total quantity of the item used on the equipment.

g. Quantity authorized, column 7, indicates the total quantity of an item required to be on hand and necessary for operation and maintenance of the equipment. Items to be requisitioned as required are indicated by an asterisk.

h. Illustration, column 8.

(1) Figure Number, column 8a indicates the figure number of the illustration in which the item is shown.

(2) Item or Symbol Number, column 8b

indicates the callout number used to reference the item in the illustration.

Section II. BASIC ISSUE ITEMS LIST

(1) Source maint and recov code			(2) Federal stock number	(3) Description	(4) Uni of issu	(5) Qty inc in unit pac	(6) Qty inc in unit	(7) Qty auth	(8) Illustration	
(a) Source	(b) Maint	(c) Recov							(a) Fig no.	(b) Item or sym no.
				GROUP 31 — BASICISSUEITEMS, MANUFACTURER INSTALLED						
				3100 — BASIC ISSUE ITEMS MANU- FACTURER OR DEPOT INSTALLED						
P	0		520-559-9618	CASE, MAINTENANCE AND OPERATIONAL MANUALS: cotton duck, water repellent, mildew resistant			1	1		
X2	0		5975-243-5861	CLAMP, ELECTRICAL: ground rod, 1/2 in. to 1 in. id.	EA		1	1		
				DEPARTMENT OF THE ARMY OPERATOR, ORGANIZATIONAL, FIELD AND DEPOT MAINTEN- ANCE MANUAL (Including Repair parts and Special Tool List) TM 5-3431-203-15			1	1		
X2	0		5120-642-8937	ROD, GROUND: 9 ft lg, 5/8 in. dia cone point 3 section	EA		1	1		
P	0			SWITCH AND CABLE ASSEMBLY, REMOTE CONTROL (96073) (29)			1	1		
M	0			WIRE, ELECTRICAL: ground MANUFACTURE FROM :	EA		1	1		
P	0		6145-189-6695	WIRE, ELECTRICAL: No. 6 AWG (10 ft required)	FT					

APPENDIX C

MAINTENANCE ALLOCATION CHART

Section I. INTRODUCTION

C-1. General

a. Section I provides a general explanation of all maintenance and repair functions authorized at various maintenance levels.

b. Section II designates overall responsibility for the performance of maintenance operations on the identified end item or component. The implementation of the maintenance tasks upon the end item or component will be consistent with the assigned maintenance operations.

c. Section III lists the special tools and test equipment required for each maintenance operation as referenced from Section II.

d. Section IV contains supplemental instructions, explanatory notes and/or illustrations required for a particular maintenance function.

C-2. Explanation of Columns in Section II

a. Functional Group Number. The functional group is a numerical group set up on a functional basis. The applicable functional grouping indexes (obtained from TB 750-93-1 Functional Grouping Codes) are listed on the MAC (Maintenance Allocation Chart) in the appropriate numerical sequence. These indexes are normally set up in accordance with their function and proximity to each other.

b. Component Assembly Nomenclature. This column contains a brief description of the components of each functional group.

c. Maintenance Operations and Maintenance Levels. This column lists the various maintenance operations (A through J) and indicates the lowest maintenance level author-

ized to perform these operations. The symbol designations for the various maintenance levels are as follows:

- C - Operator or crew
- O - Organizational maintenance
- F - Direct, support maintenance
- H - General support maintenance
- D - Depot maintenance

The maintenance operations are defined as follows:

- A - SERVICE: Operations required periodically to keep the item in proper operating condition, i.e., to clean, preserve, drain, paint, and replenish fuel, lubricants, hydraulic, and deicing fluids, or compressed air supplies.
- B - ADJUST: Regulate periodically to prevent malfunction. Adjustments will be made commensurate with adjustment procedures and associated equipment specifications.
- C - ALINE: Adjust two or more components of an electrical or mechanical system so that their functions are properly synchronized or adjusted.
- D - CALIBRATE: Determine, check, or rectify the graduation of an instrument, weapon, or weapons system or components of a weapons system.

E - INSPECT: Verify serviceability and detect incipient electrical or mechanical failure by close visual examination.

F - TEST: Verify serviceability and detect incipient electrical or mechanical failure by measuring the mechanical or electrical characteristics of the item and comparing those characteristics with authorized standards. Tests will be made commensurate with test procedures and with calibrated tools and/or test equipment referenced in the MAC.

G - REPLACE: Substitute serviceable components, assemblies and sub-assemblies for unserviceable counterparts or remove and install the same item when required for the performance of other maintenance operations.

H - REPAIR: Restore to a serviceable condition by replacing unserviceable parts or by any other action required using available tools, equipment and skills to include welding, grinding, riveting, straightening, adjusting and facing.

I - OVERHAUL: Restore an item to a completely serviceable condition (as prescribed by serviceability standards developed and published by the commodity commands) by employing techniques of "Inspect and Repair Only as Necessary" (IROAN). Maximum use of diagnostic and test equipment is combined with minimum disassembly during overhaul. "OVERHAUL" may be assigned to any level of maintenance

except organizational, provided the time, tools, equipment, repair parts authorization, and technical skills are available at that level. Normally, overhaul as applied to end items, is limited to depot maintenance level.

J - REBUILD: Restore to a condition comparable to new by disassembling to determine the condition of each component part and reassembling using serviceable, rebuilt, or new assemblies, subassemblies, and parts.

d. Reference Note. This column, subdivided into columns K and L, is provided for referencing the SPECIAL TOOLS AND TEST EQUIPMENT REQUIREMENTS (Sec. III) and REMARKS (Sec. IV) that may be associated with maintenance operations (Sec. II).

C-3. Explanation of Columns in Section III

a. Reference Code. This column consists of a number and a letter separated by a dash. The number references the T & TE requirements column on the MAC. The letter represents the specific maintenance operation the item is to be used with. The letter is representative of columns A through J on the MAC.

b. Maintenance Level. This column shows the lowest level of maintenance authorized to use the special tool or test equipment.

c. Nomenclature. This column lists the name or identification of the tool or test equipment.

d. Tool Number. This column lists the manufacturer's code and part number, or Federal stock number, of tools and test equipment.

C-4. Explanation of Columns in Section IV

a. *Reference Code.* This column consists of two letters separated by a dash, both of which are references to Section II. The first letter references Column L and the second letter refer-

ences a maintenance operation, Column A through J.

b. *Remarks.* This column lists information pertinent to the Maintenance Operation being performed, as indicated on the MAC Section

II.

Section II. MAINTENANCE ALLOCATION CHART

Functional group number	Component assembly nomenclature	Essentiality	Maintenance operations						Maintenance levels				Note ref			
			A	B	C	D	E	F	G	H	I	J	K	L		
			Service	Adjust	Align	Calibrate	Inspect	Test	Replace	Repair	Overhaul	Rebuild	T&TE reqmt	Remarks		
22	ACCESSORY ITEMS															
2210	Data Plates, and Instruction Holders:															
	Plates, data -----	--	--	--	--	--	--	F								
	Plates, instruction -----	--	--	--	--	--	--	O								
44	WELDING EQUIPMENT															
4400	Arc Welder -----	--	--	--	--	--	F		O	H						
4405	Frame Support, Housing:															
	Lifting, eye; cover, top; panel,															
	housing, front -----	--	--	--	--	--	--	O								
4408	Connecting Devices:															
	Receptacle, remote control -----	--	--	--	--	--	--	F								
	Panel, stud, terminal -----	--	--	--	--	--	--	O								
	Stud, terminal -----	--	--	--	--	--	--	O								
	Switch and cable assembly, remote															
	control -----	--	--	--	--	--	--	O								
4409	Protective Devices:															
	Switches, interlock and thermostatic															
4410	Switching and Timing Speed:															
	Switch control; cable assembly, change-															
	over board; receptacle plug in timer															
4410	Switching and Timing Speed-Continued															
	Relay, timer; switch, range;															
	switch, polarity -----	--	--	--	--	--	--	F								
	Spark gap assembly -----	--	--	O	--	--	--	O								
	Contactors; valve, solenoid; plug, dummy															
	Capacitor -----	--	--	--	--	--	--	F								
4411	Resistor Components:															
	Resistor -----	--	--	--	--	--	--	F								
	Rheostat -----	--	--	--	--	--	--	F								
4412	Transformer Components:															
	Transformer, Main -----	--	--	--	--	--	--	H								
	Reactor assembly, filter; transformer,															
	control -----	--	--	--	--	--	--	F								
	Coil assembly, filter reactor; transformer															
	230 volts; coil tesla; capacitor, power															
4413	Rectifier Components:															
	Rectifier, main -----	--	--	--	--	--	--	F		F						
	Rectifier, control -----	--	--	--	--	--	--	F		F						

**Section III. SPECIAL TOOL AND SPECIAL TEST EQUIPMENT
REQUIREMENTS**

Reference code	Maintenance level	Nomenclature	Tool number
		NONE REQUIRED	

Section IV. REMARKS

Reference Code	Remarks
	None

APPENDIX D

ORGANIZATIONAL, DIRECT AND GENERAL SUPPORT AND DEPOT MAINTENANCE REPAIR PARTS

Section I. INTRODUCTION

D-1. Scope

This appendix contains a list of repair parts required for the performance of organizational, direct support general support, and depot maintenance of the welding machine.

D-2. General

This repair parts list is divided into the following principal sections.

a. Section 2, Prescribed Load Allowance List (PLA), is a consolidated listing of repair parts quantitatively allocated for initial stockage at the organizational level. This is a mandatory minimum stockage allowance.

b. Section 3, Repair Parts List, is a list of repair parts authorized for the performance of maintenance at the organizational level.

c. Section 4, Repair Parts List, is a list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level.

D-3. Explanation of Columns

The following provides an explanation of columns in the tabular lists.

a. Source, Maintenance, and Recoverability Codes.

- (1) Source Code indicates the selection status and source for the listed item. Source codes used are:

Code	Explanation
P	Applied to repair parts which are stocked in or supplied from DSA/GSA or Army supply system, and authorized for use at indicated maintenance categories.

Code	Explanation
M	Applied to repair parts which are not procured or stocked but are to be manufactured at indicated maintenance categories
X1	Applied to repair parts which are not procured or stocked, the requirement for which will be supplied by use of the next higher assembly or components
X2	Applied to repair parts which are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain them through cannibalization; if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.

Note. Source code is not shown on common hardware items known to be readily available in Army supply channels and through local procurement.

- (2) Maintenance Code indicates the lowest category of maintenance authorized to install the listed item. The maintenance level codes are:

Code	Explanation
O	Organizational maintenance
F	Direct support maintenance
H	General support maintenance

b. Federal Stock Number indicates the Federal stock number for the item.

c. Description column indicates the Federal item name and brief description of the item. A five-digit manufacturer's or other service code is shown in parentheses followed by the manufacturer's part number. Repair parts quantities included in kits, sets, and assemblies that differ from the actual quantity used

in the specific item, are listed in parentheses following the repair part name.

d. Unit of Issue indicates the unit used as a basis of issue, e.g., ea, pr, ft, yd, etc.

e. Quantity Incorporated in Unit Pack indicates the actual quantity contained in the unit pack.

f. Quantity Incorporated in Unit indicates the actual number of parts used in the application. A zero is shown when components of kits or sets are listed that are not applicable to the specific end item.

g. Fifteen-Day Organizational Maintenance Allowance.

(1) The allowance columns are divided into four subcolumns. Indicated in each subcolumn is the quantity of items authorized for the number of equipments supported. Items authorized for use as required but not for initial stockage are identified with an asterisk in the allowance column.

(2) The quantitative allowances for organizational level of maintenance represents one initial prescribed load for a 15-day period for the number of equipments supported. Units and organizations authorized additional prescribed loads will multiply the number of prescribed loads authorized by the quantity of repair parts reflected in the appropriate density column to obtain the total quantity of repair parts authorized.

(3) Items identified by an asterisk may be requisitioned as required. Subsequent changes and/or additions to allowances will be limited to the provisions of AR 735-35. The range of items authorized will be made by this Command based upon engineering experience, demand data, or TAERS information.

(4) Allowances are based on 1500 hours of operation per year.

h. Thirty-Day DS/GS Maintenance Allowance.

(1) The allowance columns are divided into three subcolumns, Indicated in each subcolumn is the quantity of

items authorized for a number of equipments supported. Items authorized for use as required but not for initial stockage are identified with an asterisk in the allowance column.

(2) The quantitative allowances for DS/GS levels of maintenance will represent initial stockage for a 30-day period for the number of equipments supported.

i. One-Year Allowance Per 100 Equipments/Contingency Planning Purposes indicates the quantity of items required for distribution and contingency planning purposes.

j. Depot Maintenance Allowance Per 100 Equipments indicates the total quantity of items recommended for depot maintenance of 100 equipments. Items recommended for immediate use only are identified with an asterisk in the allowance column.

k. Illustration.

(1) Figure Number indicates the figure number of the illustration in which the item is shown.

(2) Item or Symbol Number indicates the callout number used to reference the item in the illustration.

D-4. Abbreviations

ac	-----	alternate current
amp	-----	ampere (s)
AWG	-----	American Wire Gage
dia	-----	diameter
ea	-----	each
ft	-----	foot(feet)
id	-----	insidediameter
in	-----	inch (es)
kc	-----	kilWyclele (s)
lg	-----	long (length)
lh	-----	left hand
mtg	-----	amounting (s)
no.	-----	number
od	-----	outside diameter
rh	-----	right hand
rpm	-----	revolutions per minute
sh	-----	shwt
sp	-----	strip
thd	-----	thread(s) (ed)
thk	-----	thick (ness)
uf	-----	microfarad (s)
v	-----	volt (s)
w	-----	wide (width)
W/	-----	with

D-5. Index to Federal Supply Code for Manufacturer's

00000 ----- Ordnance Corps
 08081 -----Ohio Auto Parts Co
 14655 ----- Cornell-Dubilier Electric Corp.
 24446 ----- General Electric Co.
 44655 ----- Ohmite Mfg. Co.

54978 ---- Simplex Time Recorder Co.
 62119 ----- Universal Electric Co
 71843 ---- Porter, H. K., Co., Inc., Forge and Fittings Division
 72169 ---- Ellsworth Pipe and Supply Co
 81483 ---- International Rectifier Corp
 96073 ---- Mid-States Welder Mfg. Co.

Section 2. PRESCRIBED LOAD ALLOWANCE

(1) Federal stock number	(2) Description	(3) 15-day org maint alw			
		(A) 1-5	(B) 6-20	(C) 21-50	(D) 51-100
3431-083-2652	CONTRACTOR: model (96073) 18	*	*	*	2
5949-061-6964	RELAY, ARMATURE: (96073) 18	*	*	*	2
3431-061-5940	VALVE, SOLENOID: gas and water (96073) 23	*	*	2	2
9535-231-8256	COPPER SHEET	*	*	*	2
9535-232-2293	COPPER STRIP	*	*	*	2
5970-644-2629	INSULATION SLEEVING, ELECTRICAL	*	2	2	3
6145-548-2350	WIRE, ELECTRICAL: copper	*	*	*	2
6145-284-0659	WIRE, ELECTRICAL: copper	*	*	*	2
6145-660-8933	WIRE, ELECTRICAL: copper	*	2	3	5
6145-263-6982	WIRE, ELECTRICAL: copper	2	4	7	15
5930-655-1515	SWITCH, TOGGLE	*	*	2	2

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUS-TRATION			
	(a) SOURCE	(b) MAINT.	(c) RECOV.						MANUFACTURER'S		(a)	(b)	(c)	(d)	FIG. NO.	ITEM OR SYM. NO.
	CODE	PART NUMBER	1-5						6-20	21-50	51-100					
0001					SECTION 3 - REPAIR PARTS FOR ORGANIZATIONAL MAINTENANCE											
0002					GROUP 22 - BODY, CHASSIS OR HULL, AND ACCESSORY ITEMS											
0003					2210 - DATA PLATES AND INSTRUCTION HOLDERS											
0005	X2	0			PLATE, INSTRUCTION: HIGH FREQUENCY DRAWER	EA		1	*	*	*	*				
0006	X2	0			PLATE, INSTRUCTION: PLUG IN TIMERS	EA		1	*	*	*	*				
0007	X2	0			PLATE, INSTRUCTION: WELDER FRONT HOUSING	EA		1	*	*	*	*				
0009					GROUP 40 - ELECTRIC MOTORS AND GENERATORS											
0009A					4000 - ELECTRIC MOTOR											
0010	X2	0			MOTOR, FAN: VENTILATING 230v, 1550 RPM MODEL 16-166, 60 CYCLE, 1.25 AMP SERIAL No. 1U299T8	EA		1	*	*	*	*	D5	12		
0011	0		5310-298-9261		NUT, PLAIN, HEXAGON: MOTOR MTG	EA		4	*	*	*	*	D5	3		
0012	0		5310-010-6497		WASHER, LOCK: MOTOR MTG	EA		4	*	*	*	*	D5	4		
0013					GROUP 44 - WELDING, METALIZING, METAL HEATING AND PLATING EQUIPMENT											
0014					4405 - FRAME SUPPORT, HOUSING											
0016	X2	0			COVER, TOP	EA		1	*	*	*	*	D4	1		
0017	X2	0			HOUSING, WELDER	EA		1	*	*	*	*	D4	4		
0018	X2	0	5935-818-1126		JACK, TIP: NYLON TIP FOR 1/4 IN. HOLE, 1/8 IN. JACK	EA		2	*	*	*	*	D10	4		
0019	M	0			LEAD ASSEMBLY, ELECTRICAL: MOUNTED REAR OF FRONT HOUSING PANEL	EA		2					D10	5		
0019A	X2	0	5940-050-6208		MANUFACTURE FROM: TERMINAL, LUG: COPPER, TINNEO FINISH, No. 16 TO 14 AWG, FOR No. 10 SCREW	EA		1	*	*	*	*				
0019B	P	0	6145-660-8933		WIRE, ELECTRICAL (15 IN. REQUIRED FOR EACH LEAD)	FT			SEE	GRP 9501						
0020	X2	0			LIFTING EYE	EA			*	*	*	*	D4	2		
0021	0		5310-262-6169		NUT, PLAIN, HEXAGON: LEAD ASSEMBLY MTG	EA		2	*	*	*	*	D10	7		
0022	0		5310-685-1429		NUT, PLAIN, HEXAGON: LIFTING EYE	EA		2	*	*	*	*	D4	3		
0023	0		5310-685-1429		NUT, PLAIN, HEXAGON: SUPPORT AND LIFTING EYE MTG	EA		2	*	*	*	*	D1	8		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUS-TRATION			
	(a) SOURCE	(b) MAINT.	(c) RECOV.						MANUFACTURER'S		(e) 1-5	(f) 6-20	(g) 21-50	(h) 51-100	(a) FIG. NO.	(b) ITEM OR SYM. NO.
									CODE	PART NUMBER						
0024	X2	0			PANEL, HOUSING FRONT	EA		1	*	*	*	*	D10	1		
0025	X2	0			PLATE, VALVE MOUNTING	EA		1	*	*	*	*	D4	8		
0026		0	5305-271-2566		SCREW, MACHINE: LEAD ASSEMBLY MTG	EA		2	*	*	*	*	D10	3		
0027		0	5305-840-6694		SCREW, TAPPING, THREAD FORMING: ACCESS DOOR, VALVE, PLATE AND COVER TO HOUSING	EA		24	*	*	*	*	D4	9		
0028		0	5305-067-9896		SCREW, TAPPING, THREAD FORMING: WELDER HOUSING TO FRAME	EA		8	*	*	*	*	D4	12		
0029	X2	0			SUPPORT: BASE AND COVER	EA		1	*	*	*	*	D1	7		
0030		0	5310-013-1044		WASHER, LOCK: LEAD ASSEMBLY MTG	EA		2	*	*	*	*	D10	5		
0031					4406 - VENTILATING, COOLING SYSTEM											
0032	X2	0			BLADE, FAN, TORRINGTON: 4 BLADE, 3/8 IN. ID HUB, 15/16 IN. OD HUB, 1 IN. LG GUARD, FAN	EA		1	*	*	*	*	D5	2		
0033	X2	0			NUT, PLAIN, HEXAGON: FAN GUARD MTG	EA		1	*	*	*	*	D5	5		
0034		0	5310-619-3555		SCREW, MACHINE: FAN GUARD MTG	EA		4	*	*	*	*	D5	11		
0035		0	5305-988-1725		SETScrew: FAN BLADE MTG	EA		4	*	*	*	*	D5	14		
0036		0	5305-013-9009		WASHER, LOCK: FAN GUARD MTG	EA		1	*	*	*	*	D5	1		
0037		0	5310-010-3319			EA		4	*	*	*	*	D5	10		
0038					4407 - CONTROL PANELS											
0039	X2	0	5340-200-8503		CLAMP, LOOP: WIRE MTG, PLASTIC	EA		4	*	*	*	*	D7	25		
0040	X2	0			DRAWER, HIGH FREQUENCY PANEL	EA		1	*	*	*	*	D7	27		
0041	X2	0	6240-682-3411		GLOW LAMP: PILOT LIGHT	EA		3	*	*	*	*	D8	13		
0044	X2	0	6210-840-1057		LIGHT, PILOT	EA		3	*	*	*	*	D8	7		
0045	X2	0			LOCK, DRAWER: W/KEY	EA		1	*	*	*	*	D8	9		
0047		0	5310-262-6169		NUT, PLAIN, HEXAGON: CLAMP MTG	EA		4	*	*	*	*	D7	9		
0048		0	5310-207-9272		NUT, PLAIN, HEXAGON: PANEL TO DRAWER MTG	EA		4	*	*	*	*	D7	20		
0049	M	0			PANEL, HIGH FREQUENCY DRAWER	EA		1					D7	18		
0049A	P	0	5970-254-4038		MANUFACTURE FROM: INSULATION, SHEET, ELECTRICAL (7 1/4 IN. X 14 IN. REQUIRED)	SH			SEE GRP 9501							
0052		0	5305-271-2566		SCREW, MACHINE: CLAMP MTG	EA		4	*	*	*	*	D7	12		
0053		0	5305-282-9458		SCREW, MACHINE: DRAWER MTG	EA		6	*	*	*	*	D7	28		
0054		0	5305-206-3339		SCREW, MACHINE: PANEL TO DRAWER MTG	EA		4	*	*	*	*	D7	24		
0055		0	5310-167-0816		WASHER, FLAT: CLAMP MTG	EA		4	*	*	*	*	D7	10		
0056		0	5310-011-4986		WASHER, FLAT: PANEL TO DRAWER MTG	EA		8	*	*	*	*	D7	19		
0057					4408 - CONNECTING DEVICES											
0058	M	0			INSULATION, PLASTIC TUBING: LEAD INSULATING	EA		1					D10	9		
0058A	P	0	5970-644-2629		MANUFACTURE FROM: INSULATION SLEEVING, ELECTRICAL (20 IN. REQUIRED)	FT			SEE GRP 9501							

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION		
	(a) SOURCE	(b) MAINT.	(c) RECOV.										(a)	(b)	
									CODE	PART NUMBER	1-5	6-20	21-50	51-100	FIG. NO.
0059	M	0			INSULATION, PLASTIC TUBING: LEAD	EA		1						D10	15
0059A	P	0	5970-644-2629		INSULATION MANUFACTURE FROM: INSULATION SLEEVING, ELECTRICAL (17 IN. REQUIRED)	FT			SEE GRP 9501						
0060	M	0			LEAD, COPPER: TERMINAL STUD, FLAT	EA		3						D10	10
0060A	P	0	9535-232-2293		COPPER MANUFACTURE FROM: COPPER STRIP (20 IN. x 1 IN. REQUIRED FOR EACH LEAD)	SP			SEE GRP 9501						
0061	M	0			LEAD, COPPER: TERMINAL STUD FLAT	EA		3						D10	14
0061A	P	0	9535-232-2293		COPPER MANUFACTURE FROM: COPPER STRIP (17 IN. x 1 IN. REQUIRED FOR EACH LEAD)	SP			SEE GRP 9501						
0062	0		5310-020-5186		NUT, PLAIN, HEXAGON: TERMINAL STUD	EA		4	*	*	*	*		D10	19
0063	X2	0			PANEL, BAKELITE: GROUND AND ELECTRODE STUD MTG	EA		1	*	*	*	*		D10	16
0064	X2	0			RECEPTACLE, REMOTE CONTROL	EA		1	*	*	*	*		D10	2
0065	0		5305-954-9543		SCREW, CAP, HEXAGON HEAD: LEAD TO TERMINAL STUD	EA		2	*	*	*	*		D10	13
0066	0		5305-271-2566		SCREW, MACHINE: REMOTE CONTROL RECEPTACLE MTG	EA		2	*	*	*	*		D10	3
0067	0		5305-017-0471		SCREW, TAPPING, THREAD FORMING: BAKELITE PANEL TO CONTROL PANEL MTG	EA		4	*	*	*	*		D10	20
0069	X2	0			STUD, TERMINAL: GROUND AND ELECTRODE, BRASS (SPECIAL)	EA		2	*	*	*	*		D10	11
0070	X2	0			SWITCH AND CABLE ASSEMBLY, REMOTE CONTROL	EA		1	*	*	*	*		D10	23
0071	0		5310-044-6221		WASHER, FLAT: TERMINAL STUD INSULATING	EA		4	*	*	*	*		D10	17
0072	0		5310-637-9541		WASHER, LOCK: LEAD TO TERMINAL STUD	EA		2	*	*	*	*		D10	12
0073	0		5310-584-5272		WASHER, LOCK: TERMINAL STUD	EA		2	*	*	*	*		D10	18
0074					4409 - PROTECTIVE DEVICES										
0075	M	0			INSULATOR	EA		1						D7	30
0075A	P	0	5970-284-7201		MANUFACTURE FROM: INSULATION, SHEET, ELECTRICAL: FIBER 1 IN. W, 0.125 IN. THK, 5.562 IN. LG	FT			SEE GRP 9501						
0076	M	0			LEAD, ELECTRICAL: INTERLOCK SWITCH TO POWER SWITCH	EA		1						D7	32
0076A	P	0	6145-263-6982		MANUFACTURE FROM: WIRE, ELECTRICAL (8 IN. REQUIRED)	FT			SEE GRP 9501						
0077	0		5310-262-6169		NUT, PLAIN, HEXAGON: INTERLOCK SWITCH MOUNTING	EA		2	*	*	*	*		D7	9

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACY	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUS-TRATION			
	(a) SOURCE	(b) MAINT.	(c) RECOV.						MANUFACTURER'S		(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM OR SYM. NO.
									CODE	PART NUMBER						
0078		0		5305-013-2719	SCREW, MACHINE: INTERLOCK SWITCH MTG	EA		2	*	*	*	*	D7	29		
0079	P	0		5930-259-8619	SWITCH, INTERLOCK: MICRO SWITCH, SPST	EA		1	*	*	*	*	D7	31		
0080	P	0		5930-083-2718	SWITCH, THERMOSTATIC	EA	96073 24R1141	1	*	*	*	*	D6	7		
0081		0		5310-167-0016	WASHER, FLAT: INTERLOCK SWITCH MTG	EA	96073 24R1594	2	*	*	*	*	D7	10		
0082		0		5310-013-1044	WASHER, LOCK: INTERLOCK SWITCH MTG	EA		2	*	*	*	*	D7	11		
0083					4410 - SWITCHING, TIMING AND SPEED CONTROL											
0084	X2	0			ADAPTER, STRAIGHT, PIPE TO TUBE: GAS TO TORCH, PIPE TO SOLENOID, ONE END MALE, 1/4-18 THD SIZE, OTHER END FEMALE, 5/8-18 THD SIZE, LH THD (SPECIAL)	EA	08081 15AWL	2	*	*	*	*	D4	10		
0085	X2	0			ADAPTER, STRAIGHT, PIPE TO TUBE: WATER TO TORCH, PIPE TO SOLENOID, ONE END MALE, 1/4-18 THD SIZE, OTHER END FEMALE, 5/8-18 THD SIZE, RH THD (SPECIAL)	EA	08081 15AR	2	*	*	*	*	D4	11		
0088	M	0			BOARD, FIBER: CONTACTOR TO CHANGE OVER BOARD	EA		1					D2	20		
0088A	P	0		5970-284-7201	MANUFACTURE FROM: INSULATION, SHEET, ELECTRICAL (3 IN. x 3 1/2 IN. REQUIRED)	SH			SEE GRP 9501							
0089	M	0			BRACKET, SPARK CAP	EA		1					D7	6		
0089A	P	0		9520-517-0531	MANUFACTURE FROM: STEEL, ANGLE (1 IN. REQUIRED)	FT			SEE GRP 9501							
0090	M	0			CABLE ASSEMBLY, ELECTRICAL: CHANGE OVER BOARD	EA		1					D2	19		
0090A	X2	0			MANUFACTURE FROM: TERMINAL, LUG	EA	00000 AN8-23	2	*	*	*	*				
0090B	P	0		6145-284-0659	WIRE, ELECTRICAL (12 IN. REQUIRED)	FT			SEE GRP 9501							
0091	M	0			CABLE ASSEMBLY, ELECTRICAL: CONTACTOR	EA		1					D2	15		
0091A	X2	0			MANUFACTURE FROM: TERMINAL, LUG	EA	00000 AN8-23	2	*	*	*	*				
0091B	P	0		6145-284-0659	WIRE, ELECTRICAL (6 IN. REQUIRED)	FT			SEE GRP 9501							
0096	P	0		3431-083-2652	CONTACTOR: MODEL 6-3-2 (No. 804)	EA	96073 18R1719	1	*	*	*	2	D2	13		
0097	X2	0		4730-253-4412	ELBOW, PIPE: SOLENOID TO ADAPTER	EA		4	*	*	*	*	D4	6		
0098	X2	0			HANDLE, CONTROL: POLARITY SWITCH AND RANGE SWITCH	EA	96073 1G1983	2	*	*	*	*	D9	2		
0099	M	0			INSULATION, PLASTIC: JUMPER LEAD, POLARITY AND RANGE SWITCHES	EA		2					D9	15		
0099A	P	0		5970-644-2629	MANUFACTURE FROM: INSULATION SLEEVING, ELECTRICAL (4 1/2 IN. REQUIRED FOR EACH INSULATION)	FT			SEE GRP 9501							

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION	
	(a) SOURCE	(b) MAINT.	(c) RECOV.						(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM OR SYM. NO.
CODE		PART NUMBER												
0101	M	O			INSULATION, PLASTIC: RANGE AND POLARITY SWITCH TO TRANSFORMER LEAD MANUFACTURE FROM:	EA		2					D9	6
0101A	P	O		5970-644-2629	INSULATION SLEEVING, ELECTRICAL (10 IN. REQUIRED FOR EACH INSULATION)	FT			SEE GRP 9501					
0102	M	O			INSULATION, PLASTIC: RANGE SWITCH LEAD MANUFACTURE FROM:	EA		1					D9	14
0102A	P	O		5970-644-2629	INSULATION SLEEVING, ELECTRICAL (24 IN. REQUIRED)	FT			SEE GRP 9501					
0103	M	O			INSULATION, PLASTIC: RANGE SWITCH TO POLARITY SWITCH LEAD MANUFACTURE FROM:	EA		1					D9	12
0103A	P	O		5970-644-2629	INSULATION SLEEVING, ELECTRICAL (15 IN. REQUIRED)	FT			SEE GRP 9501					
0105	M	O			LEAD, COPPER: RANGE AND POLARITY SWITCH TO TRANSFORMER MANUFACTURE FROM:	EA		6					D9	8
0105A	P	O		9535-232-2293	COPPER STRIP (1 IN. X 11 IN. REQUIRED FOR EACH LEAD)	SP			SEE GRP 9501					
0106	M	O			LEAD, COPPER: RANGE SWITCH MANUFACTURE FROM:	EA		3					D9	13
0106A	P	O		9535-232-2293	COPPER STRIP (1 IN. X 27 IN. REQUIRED FOR EACH LEAD)	SP			SEE GRP 9501					
0107	M	O			LEAD, COPPER: RANGE SWITCH TO POLARITY SWITCH MANUFACTURE FROM:	EA		3					D9	9
0107A	P	O		9535-232-2293	COPPER STRIP (1 IN. X 17 IN. REQUIRED FOR EACH LEAD)	SP			SEE GRP 9501					
0110	M	O			LEAD, ELECTRICAL: SPARK GAP TO CAPACITOR MANUFACTURE FROM:	EA		1					D7	4
0110A	P	O		5940-681-9713	TERMINAL, LUG: COPPER, TINNED FINISH, No. 16 TO 14 AWG, STRANDED CONDUCTOR	EA		2	*	*	*	*		
0110B	P	O		6145-660-8933	WIRE, ELECTRICAL (6 IN. REQUIRED)	FT			SEE GRP 9501					
0111	M	O			LEAD, ELECTRICAL: SPARK GAP TO RHEOSTAT MANUFACTURE FROM:	EA		1					D7	3
0111A	X2	O		5940-681-9713	TERMINAL, LUG	EA		1	*	*	*	*		
0111B	P	O		6145-660-8933	WIRE, ELECTRICAL (12 IN. REQUIRED)	FT			SEE GRP 9501					

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION		
	(a)	(b)	(c)						(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) FIG. NO.	(b) ITEM OR SYM. NO.	
	MANUFACTURER'S														
	CODE	PART NUMBER													
0112	M	0			LEAD, JUMPER, COPPER: POLARITY AND RANGE SWITCH MANUFACTURE FROM: COPPER STRIP (1/2 IN. X 6 IN. REQUIRED FOR EACH LEAD)	EA		6						D9	16
0112A	P	0	9535-232-2293			SP			SEE	GRP	9501				
0113	M	0			LEAD, JUMPER: POLARITY AND RANGE SWITCH MANUFACTURE FROM: COPPER SHEET (1/2 IN. X 2 1/2 IN. REQUIRED FOR EACH LEAD)	EA		2						D9	17
0113A	P	0	9535-231-8256			SH			SEE	GRP	9501				
0116		0	5310-754-4299		NUT, PLAIN, HEXAGON: CHANGE OVER BOARD	EA		17	*	*	*	*		D2	10
0117		0	5310-012-0622		NUT, PLAIN, HEXAGON: CONTACTOR MTG	EA		3	*	*	*	*		D2	17
0118		0	5310-584-5005		NUT, PLAIN, HEXAGON: LEADS TO SWITCHES	EA		12	*	*	*	*		D9	4
0119		0	5310-207-9272		NUT, PLAIN, HEXAGON: SPARK GAP AND BRACKET MTG	EA		2	*	*	*	*		D7	8
0120	X2	0	5315-664-6439		PIN, SPRING: POLARITY AND RANGE SWITCH HANDLE	EA		2	*	*	*	*		D9	3
0121	X2	0			PLUG, DUMMY: RED PRE-FLOW AMPHENAL, 6 POINT	EA		1	*	*	*	*		D8	1
0122	X2	0			RECEPTACLE, PLUG IN TIMER	EA	96073	9G1593	*	*	*	*		D8	2
0124	P	0	5945-061-6965		RELAY, ARMATURE: TYPE DEG-12	EA	96073	9R1598	*	*	*	*		D8	4
0125	P	0	5949-061-6964		RELAY, ARMATURE: TYPE DEG-12	EA	96073	18G1718	*	*	*	*		D8	3
0126		0	5305-550-3934		SCREW, CAP, HEXAGON HEAD: CHANGE OVER BOARD	EA	96073	18G1715	*	*	*	2		D8	7
0127		0	5305-068-7837		SCREW, CAP, HEXAGON HEAD: LEADS TO SWITCHES	EA		9	*	*	*	*		D2	11
0128		0	5305-068-0500		SCREW, CAP, HEXAGON HEAD: POLARITY SWITCH AND RANGE SWITCH MTG	EA		12	*	*	*	*		D9	1
0132		0	5305-013-2768		SCREW, MACHINE: CONTACTOR MTG	EA		4	*	*	*	*		D9	12
0133		0	5305-012-2159		SCREW, MACHINE: PLUG IN TIMER MTG	EA		3	*	*	*	*		D2	5
0135		0	5305-013-2915		SCREW, MACHINE: SPARK GAP AND BRACKET MOUNTING	EA		6	*	*	*	*		D8	1
0136		0	5305-226-9268		SCREW, MACHINE: SPARK GAP LEADS	EA		2	*	*	*	*		D7	2
0137	X2	0			SPARK GAP ASSEMBLY	EA	96073	11G129	*	*	*	*		D7	5
0138	P	0	5930-519-4544		SWITCH, GAS, WATER, HIGH FREQUENCY, SPOT ARC, HIGH FREQUENCY DROP OUT TIMER (ST40A)	EA		1	*	*	*	*		D7	6
0139	P	0	5930-519-4544		SWITCH, PANEL, REMOTE (ST40A)	EA		4	SEE	GRP	9901			D8	9
0141	P	0	5930-655-1582		SWITCH, POWER (ST50K)	EA		2	SEE	GRP	9901			D6	8
0143	P	0	3431-061-5940		VALVE, SOLENOID: GAS AND WATER	EA	96073	22R1711	*	*	*	*		D8	5
0144		0	5310-044-6234		WASHER, FLAT: ADAPTER TO ELBOW	EA		2	*	*	2	2		D4	7
0147		0	5310-823-8804		WASHER, FLAT: LEADS TO SWITCHES	EA		4	*	*	*	*		D4	10
0150		0	5310-010-3319		WASHER, LOCK: CHANGE OVER BOARD SCREW	EA		14	*	*	*	*		D9	9
						EA		9	*	*	*	*		D2	

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 15 DAY ORG. MAINT. ALW.				(8) ILLUSTRATION			
	(a) SOURCE	(b) MAINT.	(c) RECOV.						MANUFACTURER'S		(a)	(b)	(c)	(d)	(a)	(b)
									CODE	PART NUMBER	1-5	6-20	21-50	51-100	FIG. NO.	ITEM OR SYM. NO.
0151		0		5310-012-1841	WASHER, LOCK: CONTACTOR MTG	EA		3	*	*	*	*		D2	16	
0152		0		5310-582-5965	WASHER, LOCK: LEADS TO SWITCHES	EA		12	*	*	*	*		D9	5	
0153		0		5310-043-2226	WASHER, LOCK: SPARK GAP AND BRACKET MTG	EA		2	*	*	*	*		D7	7	
0154	M	0			WIRE, COPPER, SOLID: CONTACTOR MANUFACTURE FROM:	EA		2						D2	14	
0154A	P	0		6145-548-2350	WIRE, ELECTRICAL (8 IN. REQUIRED FOR EACH WIRE)	FT			SEE	GRP	9501					
0155					4411 - RESISTOR COMPONENTS											
0157	X2	0			KNOB, RHEOSTAT	EA		1	*	*	*	*		D8	12	
0173		0		5305-014-0854	SETScrew: RHEOSTAT KNOB	EA		1	*	*	*	*		D8	11	
0228					GROUP 95 - GENERAL USE STANDARDIZED PARTS											
0229					9501 - BULK MATERIAL											
0230	P	0		9535-231-8256	COPPER SHEET: 0.1250 IN. TH, 24 IN. W, 48 IN. LG	SH			*	*	*	*			2	
0231	P	0		9535-232-2293	COPPER STRIP: 0.032 IN. TH, 12 IN. W, 36 IN. LG	SP			*	*	*	*			2	
0231A	P	0		5970-254-4038	INSULATION, SHEET, ELECTRICAL	SH			*	*	*	*			*	
0232	P	0		5970-284-7201	INSULATION SHEET, ELECTRICAL: FIBER 48 IN. W, 72 IN. LG, 0.125 IN. THK	SH			*	*	*	*			*	
0233	P	0		5970-284-7201	INSULATION SHEET, ELECTRICAL: FIBER 48 IN. W, 60 IN. LG, 1/8 IN. THK	SH			*	*	*	*			*	
0234	P	0		5970-644-2629	INSULATION SLEEVING, ELECTRICAL: 1.125 IN. DIA, 0.032 IN. THK	FT			*	2	2	3			3	
0239	P	0		9520-517-0531	STEEL ANGLE: 1/8 IN. THK, 1 1/2 IN. LEGS	FT			*	*	*	*			*	
0241	P	0		6145-548-2350	WIRE, ELECTRICAL: COPPER, No. 10 AWG, SOLID CONDUCTOR	FT			*	*	*	*			2	
0242	P	0		6145-284-0659	WIRE, ELECTRICAL: COPPER, TINNED FINISH, No. 8 AWG, STRANDED CONDUCTOR	FT			*	*	*	*			2	
0243	P	0		6145-660-8933	WIRE, ELECTRICAL: COPPER, TINNED FINISH, No. 14 AWG, STRANDED CONDUCTOR	FT			*	2	3	5				
0244	P	0		6145-263-6982	WIRE, ELECTRICAL: COPPER, TINNED FINISH, No. 18 STRANDED CONDUCTOR	FT			2	4	7	15				
0245					GROUP 99 - PARTS PECULIAR											
0245A					9901 - PARTS PECULIAR WITH MORE THAN ONE APPLICATION											
0247	P	0		5930-655-1515	SWITCH, TOGGLE	EA		6	*	*	2	2				

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CITYGCY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION		
	(a)	(b)	(c)						(a)	(b)	(c)			(a)	(b)	
	SOURCE	MAINT.	RECOV.						1-20	21-50	51-100			FIG. NO.	ITEM OR SYM. NO.	
					MANUFACTURER'S											
					CODE	PART NUMBER										
0001					SECTION 4 - REPAIR PARTS FOR DS, GS, AND DEPOT MAINTENANCE											
0002					GROUP 22 - BODY, CHASSIS OR HULL, AND ACCESSORY ITEMS											
0003					2210 - DATA PLATES AND INSTRUCTION HOLDERS											
0004	X2	F		9905-807-3712	PLATE, IDENTIFICATION: U.S. ARMY			1	*	*	*	*	*			
0005	X2	O			PLATE, INSTRUCTION: HIGH FREQUENCY DRAWER		96073 14R1597	1	*	*	*	*	*			
0006	X2	O			PLATE, INSTRUCTION: PLUG IN TIMERS		96073 14R1150	1	*	*	*	*	*			
0007	X2	O			PLATE, INSTRUCTION: WELDER FRONT HOUSING		96073 14R1597	1	*	*	*	*	*			
0008		F		5305-017-3185	SCREW DRIVE: U.S. ARMY PLATE MTG			4	*	*	*	*	*			
0009					GROUP 40 - ELECTRIC MOTORS AND GENERATORS											
0009A					4000 - ELECTRIC MOTOR											
0010	X2	O			MOTOR, FAN: VENTILATING 230V, 1550 RPM MODEL 16-166, 60 CYCLE, 1.25 AMP SERIAL No. 1U299T8		62119 1U299T8	1	*	*	*	*	*		D5	12
0011		O		5310-298-9261	NUT, PLAIN, HEXAGON: MOTOR MTG			4	*	*	*	*	*		D5	3
0012		O		5310-010-6497	WASHER, LOCK: MOTOR MTG			4	*	*	*	*	*		D5	4
0013					GROUP 44 - WELDING, METALIZING, METAL HEATING AND PLATING EQUIPMENT											
0014					4405 - FRAME SUPPORT, HOUSING											
0015	X2	H			BASE, WELDER		96073 13G1811	1	*	*	*	*	*		D1	12
0016	X2	O			COVER, TOP		96073 8G1817	1	*	*	*	*	*		D4	1
0017	X2	O			HOUSING, WELDER		96073 3G1829	1	*	*	*	*	*		D4	4
0018	X2	O		5935-818-1126	JACK, TIP: NYLON TIP FOR 1/4 IN. HOLE, 1/8 IN. JACK			2	*	*	*	*	*		D10	4
0019	M	O			LEAD ASSEMBLY, ELECTRICAL: MOUNTED REAR OF FRONT HOUSING PANEL			2							D10	5
0019A	X2	O		5940-050-6208	MANUFACTURE FROM: TERMINAL, LUG: COPPER, TINNED FINISH, No. 16 TO 14 AWG, FOR No. 10 SCREW											
0019B	P	O		6145-660-8933	WIRE, ELECTRICAL (15 IN. REQUIRED FOR EACH LEAD)			1	*	*	*	*	*			
0020	X2	O			LIFTING EYE		71843 2404L									
0021		O		5310-262-6169	NUT, PLAIN, HEXAGON: LEAD ASSEMBLY MTG			2	*	*	*	*	*		D4	2
0022		O		5310-685-1429	NUT, PLAIN, HEXAGON: LIFTING EYE			2	*	*	*	*	*		D10	7
															D4	3

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CTYGCY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION			
	SOURCE	MAINT.	RECOV.						MANUFACTURER'S		(a) 1-20			(b) 21-50	(c) 51-100	(a) FIG. NO.	(b) ITEM OR SYM. NO.
									CODE	PART NUMBER							
0023		0		5310-685-1429	NUT, PLAIN, HEXAGON: SUPPORT AND LIFTING EYE MTG	EA		2	*	*	*	*	*	D1	8		
0024	X2	0			PANEL, HOUSING FRONT	EA		1	*	*	*	*	*	D10	1		
0025	X2	0			PLATE, VALVE MOUNTING	EA		1	*	*	*	*	*	D4	8		
0026		0		5305-271-2566	SCREW, MACHINE: LEAD ASSEMBLY MTG	EA		2	*	*	*	*	*	D10	3		
0027		0		5305-840-6694	SCREW, TAPPING, THREAD FORMING: ACCESS DOOR, VALVE, PLATE AND COVER TO HOUSING	EA		24	*	*	*	*	*	D4	9		
0028		0		5305-067-9896	SCREW, TAPPING, THREAD FORMING: WELDER HOUSING TO FRAME	EA		8	*	*	*	*	*	D4	12		
0029	X2	0			SUPPORT: BASE AND COVER	EA		1	*	*	*	*	*	D1	7		
0030		0		5310-013-1044	WASHER, LOCK: LEAD ASSEMBLY MTG	EA		2	*	*	*	*	*	D10	5		
0031					4406 - VENTILATING, COOLING SYSTEM												
0032	X2	0			BLADE, FAN, TORRINGTON: 4 BLADE, 3/8 IN. ID HUB, 15/16 IN. OD HUB, 1 IN. LG GUARD, FAN	EA		1	*	*	*	*	*	D5	2		
0033	X2	0				EA		1	*	*	*	*	*	D5	5		
0034		0		5310-619-3555	NUT, PLAIN, HEXAGON: FAN GUARD MTG	EA		4	*	*	*	*	*	D5	11		
0035		0		5305-988-1725	SCREW, MACHINE: FAN GUARD MTG	EA		4	*	*	*	*	*	D5	14		
0036		0		5305-013-9009	SETSCREW: FAN BLADE MTG	EA		1	*	*	*	*	*	D5	1		
0037		0		5310-010-3319	WASHER, LOCK: FAN GUARD MTG	EA		4	*	*	*	*	*	D5	10		
0038					4407 - CONTROL PANELS												
0039	X2	0		5340-200-8503	CLAMP, LOOP: WIRE MTG, PLASTIC	EA		4	*	*	*	*	*	D7	25		
0040	X2	0			DRAWER, HIGH FREQUENCY PANEL	EA		1	*	*	*	*	*	D7	27		
0041	X2	0		6240-682-3411	GLOW LAMP: PILOT LIGHT	EA		3	*	*	*	*	*	D8	13		
0042	M	F			HARNESS ASSEMBLY, WIRING: CONTROL PANEL MANUFACTURE FROM:	EA		1						D6	8		
0042A	X2	F		5940-050-6209	TERMINAL, LUG: COPPER, TINNED FINISH, No. 16 TO 14 AWG, FOR 1/4 IN. BOLT	EA		2	*	*	*	*	*				
0042B	X2	F		5940-230-8117	TERMINAL, LUG: COPPER, TINNED FINISH, No. 16 TO 22 AWG, 0.281 IN. DIA, 47/64 IN. LG	EA		2	*	*	*	*	*				
0042C	X2	F		5940-201-2849	TERMINAL, LUG: COPPER, TINNED FINISH, No. 22 TO 18 AWG, FOR No. 10 SCREW	EA		2	*	*	*	*	*				
0042D	P	F		6145-263-6982	WIRE, ELECTRICAL (62 FT REQUIRED)	EA		10	*	*	*	*	*				
0042E	P	F		6145-660-8933	WIRE, ELECTRICAL (11 FT 8 IN. REQUIRED)	FT				SEE GRP 9501							
0043	X2	F			JACK, PLASTIC, FEMALE: FOR AWG No. 18 WIRE, FOR 3/8 IN. HOLE, SOLENOID VALVE	EA		2	*	*	*	*	*	D6	12		
0044	X2	0		6210-840-1057	LIGHT, PILOT	EA		3	*	*	*	*	*	D8	7		
0045	X2	0			LOCK, DRAWER: W/KEY	EA		1	*	*	*	*	*	D8	9		
0047		0		5310-262-6169	NUT, PLAIN, HEXAGON: CLAMP MTG	EA		4	*	*	*	*	*	D7	9		
0048		0		5310-207-9272	NUT, PLAIN, HEXAGON: PANEL TO DRAWER MTG	EA		4	*	*	*	*	*	D7	20		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CITY GCY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUS-TRATION			
	(a) SOURCE	(b) MAIN	(c) RECOV.						MANUFACTURER'S		(a) 1-20			(b) 21-50	(c) 51-100	(a) FIG. NO.	(b) ITEM OR SYM. NO.
									CODE	PART NUMBER							
0049	M	O			PANEL, HIGH FREQUENCY DRAWER MANUFACTURE FROM:	EA		1						D7	18		
0049A	P	O		5970-254-4038	INSULATION, SHEET, ELECTRICAL (7 1/4 IN. X 14 IN. REQUIRED)	SH			SEE GRP 950								
0050	X2	F			PLUG, 12 PIN	EA		1	*	*	*	*	*	D7	26		
0051	X2	F			RECEPTACLE, 12 PIN: w/CLIPS	EA		1	*	*	*	*	*	D6	10		
0052	O	O		5305-271-2566	SCREW, MACHINE: CLAMP MTG	EA		4	*	*	*	*	*	D7	12		
0053	O	O		5305-282-9458	SCREW, MACHINE: DRAWER MTG	EA		6	*	*	*	*	*	D7	28		
0054	O	O		5305-206-3339	SCREW, MACHINE: PANEL TO DRAWER MTG	EA		4	*	*	*	*	*	D7	24		
0055	O	O		5310-167-0016	WASHER, FLAT: CLAMP MTG	EA		4	*	*	*	*	*	D7	10		
0056	O	O		5310-011-4986	WASHER, FLAT: PANEL TO DRAWER MTG	EA		8	*	*	*	*	*	D7	19		
0057					4408 - CONNECTING DEVICES												
0058	M	O			INSULATION, PLASTIC TUBING: LEAD INSULATING	EA											
0058A	P	O		5970-644-2629	MANUFACTURE FROM: INSULATION SLEEVING, ELECTRICAL (20 IN. REQUIRED)	FT			SEE GRP 950					D10	9		
0059	M	O			INSULATION, PLASTIC TUBING: LEAD INSULATION	EA											
0059A	P	O		5970-644-2629	MANUFACTURE FROM: INSULATION SLEEVING, ELECTRICAL (17 IN. REQUIRED)	FT			SEE GRP 950								
0060	M	O			LEAD, COPPER: TERMINAL STUD, FLAT COPPER	EA											
0060A	P	O		9535-232-2293	MANUFACTURE FROM: COPPER STRIP (20 IN. X 1 IN. REQUIRED FOR EACH LEAD)	SP		3	SEE GRP 950					D10	10		
0061	M	O			LEAD, COPPER: TERMINAL STUD FLAT COPPER	EA											
0061A	P	O		9535-232-2293	MANUFACTURE FROM: COPPER STRIP (17 IN. X 1 IN. REQUIRED FOR EACH LEAD)	SP		3	SEE GRP 950					D10	14		
0062	O	O		5310-020-5186	NUT, PLAIN, HEXAGON: TERMINAL STUD	EA		4	*	*	*	*	*	D10	19		
0063	X2	O			PANEL, BAKELITE: GROUND AND ELECTRODE STUD MTG	EA		1	*	*	*	*	*	D10	16		
0064	X2	O			RECEPTACLE, REMOTE CONTROL	EA		1	*	*	*	*	*	D10	2		
0065	O	O		5305-954-9543	SCREW, CAP, HEXAGON HEAD: LEAD TO TERMINAL STUD	EA		2	*	*	*	*	*	D10	13		
0066	O	O		5305-271-2566	SCREW, MACHINE: REMOTE CONTROL RECEPTACLE MTG	EA		2	*	*	*	*	*	D10	3		
0067	O	O		5305-017-0471	SCREW, TAPPING, THREAD FORMING: BAKELITE PANEL TO CONTROL PANEL MTG	EA		4	*	*	*	*	*	D10	20		

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CTY GCY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUS-TRATION	
	(a)	(b)	(c)						(a)	(b)	(c)			(a)	(b)
	SOURCE	MAINT.	RECOV.						CODE	PART NUMBER	1-20			21-50	51-100
0069	X2	0			STUD, TERMINAL: GROUND AND ELECTRODE, BRASS (SPECIAL)			2	*	*	*	*	*	D10	11
0070	X2	0			SWITCH AND CABLE ASSEMBLY, REMOTE CONTROL	96073	11G1705	1	*	*	*	*	*	D10	23
0071		0		5310-044-6221	WASHER, FLAT: TERMINAL STUD INSULATING	96073	29G1935	4	*	*	*	*	*	D10	17
0072		0		5310-637-9541	WASHER, LOCK: LEAD TO TERMINAL STUD			2	*	*	*	*	*	D10	12
0073		0		5310-504-5272	WASHER, LOCK: TERMINAL STUD			2	*	*	*	*	*	D10	18
0074					4409 - PROTECTIVE DEVICES										
0075	M	0			INSULATOR			1						D7	30
0075A	P	0		5970-284-7201	MANUFACTURE FROM: INSULATION, SHEET, ELECTRICAL: FIBER 1 IN. W, 0.125 IN. THK, 5.562 IN. LG										
0076	M	0			LEAD, ELECTRICAL: INTERLOCK SWITCH TO POWER SWITCH					SEE GRP 950				D7	32
0076A	P	0		6145-263-6982	MANUFACTURE FROM: WIRE, ELECTRICAL (8 IN. REQUIRED)					SEE GRP 950					
0077		0		5310-262-6169	NUT, PLAIN, HEXAGON: INTERLOCK SWITCH MOUNTING			2	*	*	*	*	*	D7	9
0078		0		5305-013-2719	SCREW, MACHINE: INTERLOCK SWITCH MTG			2	*	*	*	*	*	D7	29
0079	P	0		5930-259-8619	SWITCH, INTERLOCK: MICRO SWITCH, SPST	96073	24R1141	1	*	*	2	7	3	D7	31
0080	P	0		5930-083-2718	SWITCH, THERMOSTATIC	96073	24R1594	1	*	*	2	7	3	D6	7
0081		0		5310-167-0816	WASHER, FLAT: INTERLOCK SWITCH MTG			2	*	*	*	*	*	D7	10
0082		0		5310-013-1044	WASHER, LOCK: INTERLOCK SWITCH MTG			2	*	*	*	*	*	D7	11
0083					4410 - SWITCHING, TIMING AND SPEED CONTROL										
0084	X2	0			ADAPTER, STRAIGHT, PIPE TO TUBE: GAS TO TORCH, PIPE TO SOLENOID, ONE END MALE, 1/4-18 THD SIZE, OTHER END FEMALE, 5/8-18 THD SIZE, LH THD (SPECIAL)									D4	10
0085	X2	0			ADAPTER, STRAIGHT, PIPE TO TUBE: WATER TO TORCH, PIPE TO SOLENOID, ONE END MALE, 1/4-18 THD SIZE, OTHER END FEMALE, 5/8-18 THD SIZE, RH THD (SPECIAL)	08081	15AWL	2	*	*	*	*	*	D4	10
0086	M	F			BAR, VOLTAGE CHANGE	08081	15AR	2	*	*	*	*	*	D4	11
0086A	P	F		9535-231-8256	MANUFACTURE FROM: COPPER SHEET (3/4 IN. x 2 1/4 IN. REQUIRED FOR EACH BAR)	96073	11G1281	4						D2	11
0087	X2	F			BOARD, CHANGE COVER: BAKELITE, 3 IN. WIDE, 9 IN. LG, 1/4 IN. THK	96073	8G1285	1	*	*	*	*	*	D2	8

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CTYGCY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION			
	(a) SOURCE	(b) MAINT.	(c) RECOV.						MANUFACTURER'S		(a)			(b)	(c)	(a)	(b)
									CODE	PART NUMBER							
0088	M	O			BOARD, FIBER: CONTACTOR TO CHANGE OVER BOARD	EA		1							D2	20	
0088A	P	O		5970-284-7201	MANUFACTURE FROM: INSULATION, SHEET, ELECTRICAL (3 IN. X 3 1/2 IN. REQUIRED)	SH			SEE GRP 9501								
0089	M	O			BRACKET, SPARK CAP	EA		1							D7	6	
0089A	P	O		9520-517-0531	MANUFACTURE FROM: STEEL, ANGLE (1 IN. REQUIRED)	FT			SEE GRP 9501								
0090	M	O			CABLE ASSEMBLY, ELECTRICAL: CHANGE OVER BOARD	EA		1							D2	19	
0090A	X2	O			MANUFACTURE FROM: TERMINAL, LUG	EA		2	*	*	*	*	*				
0090B	P	O		6145-284-0659	WIRE, ELECTRICAL (12 IN. REQUIRED)	FT			SEE GRP 9501								
0091	M	O			CABLE ASSEMBLY, ELECTRICAL: CONTACTOR	EA		1							D2	15	
0091A	X2	O			MANUFACTURE FROM: TERMINAL, LUG	EA		2	*	*	*	*	*				
0091B	P	O		6145-284-0659	WIRE, ELECTRICAL (6 IN. REQUIRED)	FT			SEE GRP 9501								
0092	P	F		5910-581-8494	CAPACITOR, FIXED, CERAMIC DIELECTRIC: ON COPPER BAR, WAFFER	EA		1	SEE GRP 9901						D3	17	
0093	P	F		5910-581-8494	CAPACITOR, FIXED, CERAMIC DIELECTRIC: ON POLARITY SWITCH, WAFFER	EA		1	SEE GRP 9901						D9	25	
0094	P	F		5910-280-6333	CAPACITOR, FIXED, PAPER DIELECTRIC: CAN, HIGH FREQUENCY DRAWER	EA		1	2	2	3	30	10	D7	21		
0095	P	F		5910-083-2712	CAPACITOR: MICA, TYPE F28, 5.1 AMPS, 1000 KC, UF 0015, 5000V	EA		1	2	2	3	30	10	D7	15		
0096	P	O		3431-083-2652	CONTACTOR: MODEL 6-3-2 (No. 804)	EA		1	*	2	2	15	5	D2	13		
0097	X2	O		4730-253-4412	ELBOW, PIPE: SOLENOID TO ADAPTER	EA		4	*	*	*	*	*	D4	6		
0098	X2	O			HANDLE, CONTROL: POLARITY SWITCH AND RANGE SWITCH	EA		2	*	*	*	*	*	D9	2		
0099	M	O			INSULATION, PLASTIC: JUMPER LEAD, POLARITY AND RANGE SWITCHES	EA		2						D9	15		
0099A	P	O		5970-644-2629	MANUFACTURE FROM: INSULATION SLEEVING, ELECTRICAL (4 1/2 IN. REQUIRED FOR EACH INSULATION)	FT			SEE GRP 9501								
0101	M	O			INSULATION, PLASTIC: RANGE AND POLARITY SWITCH TO TRANSFORMER LEAD	EA		2						D9	6		
0101A	P	O		5970-644-2629	MANUFACTURE FROM: INSULATION SLEEVING, ELECTRICAL (10 IN. REQUIRED FOR EACH INSULATION)	FT			SEE GRP 9501								

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CTYGCY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUS-TRATION			
	(a) SOURCE	(b) MAINT.	(c) RECOV.						MANUFACTURER'S		(a)			(b)	(c)	(a) FIG. NO.	(b) ITEM OR SYM. NO.
									CODE	PART NUMBER							
0102	M	O			INSULATION, PLASTIC: RANGE SWITCH LEAD MANUFACTURE FROM:	EA		1							D9	14	
0102A	P	O		5970-644-2629	INSULATION SLEEVING, ELECTRICAL (24 IN. REQUIRED)	FT			SEE GRP 9501								
0103	M	O			INSULATION, PLASTIC: RANGE SWITCH TO POLARITY SWITCH LEAD MANUFACTURE FROM:	EA		1							D9	12	
0103A	P	O		5970-644-2629	INSULATION SLEEVING, ELECTRICAL (15 IN. REQUIRED)	FT			SEE GRP 9501								
0104	X2	F		5935-259-6765	JACK, MALE: 1/8 IN. PIN	EA		1	*	*	*	*	*		D7	17	
0105	M	O			LEAD, COPPER: RANGE AND POLARITY SWITCH TO TRANSFORMER MANUFACTURE FROM:	EA		6							D9	8	
0105A	P	O		9535-232-2293	COPPER STRIP (1 IN. x 11 IN. REQUIRED FOR EACH LEAD)	SP			SEE GRP 9501								
0106	M	O			LEAD, COPPER: RANGE SWITCH MANUFACTURE FROM:	EA		3							D9	13	
0106A	P	O		9535-232-2293	COPPER STRIP (1 IN. x 27 IN. REQUIRED FOR EACH LEAD)	SP			SEE GRP 9501								
0107	M	O			LEAD, COPPER: RANGE SWITCH TO POLARITY SWITCH MANUFACTURE FROM:	EA		3							D9	9	
0107A	P	O		9535-232-2293	COPPER STRIP (1 IN. x 17 IN. REQUIRED FOR EACH LEAD)	SP			SEE GRP 9501								
0108	M	F			LEAD, COPPER STRAP: CHANGE OVER BOARD MANUFACTURE FROM:	EA		2							D2	18	
0108A	P	F		9535-232-2293	COPPER STRIP (1/2 IN. x 4 IN. REQUIRED FOR EACH LEAD)	SH			SEE GRP 9501								
0109	M	F			LEAD, ELECTRICAL: CAPACITOR TO MALE JACK MANUFACTURE FROM:	EA		1							D7	16	
0109A	X2	F		5940-681-9713	TERMINAL, LUG	EA		1	*	*	*	*	*				
0109B	P	F		6145-660-8933	WIRE, ELECTRICAL (12 IN. REQUIRED)	FT			SEE GRP 9501								
0110	M	O			LEAD, ELECTRICAL: SPARK GAP TO CAPACITOR MANUFACTURE FROM:	EA		1							D7	4	
0110A	P	O		5940-681-9713	TERMINAL, LUG: COPPER, TINNED FINISH, NO. 16 TO 14 AWG, STRANDED CONDUCTOR	EA		2	*	*	*	*	*				
0110B	P	O		6145-660-8933	WIRE, ELECTRICAL (6 IN. REQUIRED)	FT			SEE GRP 9501								

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CTYGCY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUS-TRATION		
	(a)	(b)	(c)						(a)	(b)	(c)			(a) FIG. NO.	(b) ITEM OR SYM. NO.	
	SOURCE	MAINT.	RECOV.						1-20	21-50	51-100					
					MANUFACTURER'S											
					CODE	PART NUMBER										
0111	M	0			LEAD, ELECTRICAL: SPARK GAP TO RHEOSTAT	EA		1							D7	3
0111A	X2	0		5940-681-9713	MANUFACTURE FROM:	EA		1	*	*	*	*	*			
0111B	P	0		6145-660-8933	TERMINAL, LUG WIRE, ELECTRICAL (12 IN. REQUIRED)	FT			SEE GRP 950							
0112	M	0			LEAD, JUMPER, COPPER: POLARITY AND RANGE SWITCH	EA		6							D9	16
0112A	P	0		9535-232-2293	MANUFACTURE FROM: COPPER STRIP (1/2 IN. X 6 IN. REQUIRED FOR EACH LEAD)	SP			SEE GRP 950							
0113	M	0			LEAD, JUMPER: POLARITY AND RANGE SWITCH	EA		2							D9	17
0113A	P	0		9535-231-8256	MANUFACTURE FROM: COPPER SHEET (1/2 IN. X 2 1/2 IN. REQUIRED FOR EACH LEAD)	SH			SEE GRP 950							
0114	F			5310-262-6169	NUT, PLAIN, HEXAGON: CAPACITOR MTG	EA		4	*	*	*	*	*		D7	9
0115	F			5310-262-6169	NUT, PLAIN, HEXAGON: CAPACITOR MTG	EA		1	*	*	*	*	*		D3	19
0116	O			5310-754-4299	NUT, PLAIN, HEXAGON: CHANGE OVER BOARD	EA		17	*	*	*	*	*		D2	10
0117	O			5310-012-0622	NUT, PLAIN, HEXAGON: CONTACTOR MTG	EA		3	*	*	*	*	*		D2	17
0118	O			5310-584-5005	NUT, PLAIN, HEXAGON: LEADS TO SWITCHES	EA		12	*	*	*	*	*		D9	4
0119	O			5310-207-9272	NUT, PLAIN, HEXAGON: SPARK GAP AND BRACKET MTG	EA		2	*	*	*	*	*		D7	8
0120	X2	0		5315-664-6439	PIN, SPRING: POLARITY AND RANGE SWITCH HANDLE	EA		2	*	*	*	*	*		D9	3
0121	X2	0			PLUG, DUMMY: RED PRE-FLOW AMPHENAL, 6 POINT	EA		1	*	*	*	*	*		D8	1
0122	X2	0			RECEPTACLE, PLUG IN TIMER	EA	96073	9G1593							D8	2
0123	P	F		3431-083-2653	RELAY	EA	96073	9R1598							D7	34
0124	P	0		5945-061-6965	RELAY, ARMATURE: TYPE DEG-12	EA	96073	18R1600			2	8	3		D8	4
0125	P	0		5949-061-6964	RELAY, ARMATURE: TYPE DEG-12	EA	96073	18G1718			2	8	3		D8	3
0126	O			5305-550-3934	SCREW, CAP, HEXAGON HEAD: CHANGE OVER BOARD	EA	96073	18G1715			2	2	15		D2	7
0127	O			5305-068-7837	SCREW, CAP, HEXAGON HEAD: LEADS TO SWITCHES	EA		9	*	*	*	*	*		D9	11
0128	O			5305-068-0500	SCREW, CAP, HEXAGON HEAD: POLARITY SWITCH AND RANGE SWITCH MTG	EA		12	*	*	*	*	*		D9	1
0129	F			5305-272-5306	SCREW, MACHINE: CAPACITOR MTG	EA		4	*	*	*	*	*		D3	16
0130	F			5305-271-2566	SCREW, MACHINE: CAPACITOR MTG	EA		1	*	*	*	*	*		D7	12
0131	F			5305-013-2715	SCREW, MACHINE: CAPACITOR MTG	EA		2	*	*	*	*	*		D7	14
0132	O			5305-013-2768	SCREW, MACHINE: CONTACTOR MTG	EA		2	*	*	*	*	*		D2	12
0133	O			5305-012-2159	SCREW, MACHINE: PLUG IN TIMER MTG	EA		3	*	*	*	*	*		D8	5
0134	F			5305-543-5763	SCREW, MACHINE: RELAY MTG	EA		6	*	*	*	*	*		D7	33

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CTYGCY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION	
	(a)	(b)	(c)						(a)	(b)	(c)			FIG. NO.	(b) ITEM OR SYM. NO.
	SOURCE	MAINT.	RECOV.												
0135		O		5305-013-2915	SCREW, MACHINE: SPARK GAP AND BRACKET MOUNTING	EA		2	*	*	*	*	*	D7	1
0136		O		5305-226-9268	SCREW, MACHINE: SPARK GAP LEADS	EA		2	*	*	*	*	*	D7	2
0137	X2	O			SPARK GAP ASSEMBLY	EA		1	*	*	*	*	*	D7	5
0138	P	O		5930-519-4544	SWITCH, GAS, WATER, HIGH FREQUENCY, SPOT ARC, HIGH FREQUENCY DROP OUT TIMER (ST40A)										
0139	P	O		5930-519-4544	SWITCH, PANEL, REMOTE (ST40A)	EA		4	SEE GRP 9901					D8	6
0140	P	F		3431-083-2650	SWITCH, POLARITY	EA		2	SEE GRP 9901					D8	9
0141	P	O		5930-655-1582	SWITCH, POWER (ST50K)	EA		1	*	*	*	2	3	D8	26
0142	P	F		3431-083-2651	SWITCH, RANGE	EA		1	*	*	*	2	3	D9	7
0143	P	O		3431-061-5940	VALVE, SOLENOID: GAS AND WATER	EA		2	2	2	2	3	3	D4	5
0144		O		5310-044-6234	WASHER, FLAT: ADAPTER TO ELBOW	EA		4	*	*	*	*	3	D4	7
0145		F		5310-167-0816	WASHER, FLAT: CAPACITOR MTG	EA		2	*	*	*	*	*	D3	18
0146		F		5310-011-4986	WASHER, FLAT: CAPACITOR MTG	EA		2	*	*	*	*	*	D7	19
0147		O		5310-823-8804	WASHER, FLAT: LEADS TO SWITCHES	EA		14	*	*	*	*	*	D9	10
0148		F		5310-167-0816	WASHER, FLAT: RELAY MTG AND CAPACITOR MOUNTING	EA		4	*	*	*	*	*	D7	10
0149		F		5310-013-1044	WASHER, LOCK: CAPACITOR MTG	EA		2	*	*	*	*	*	D7	11
0150		O		5310-010-3319	WASHER, LOCK: CHANGE OVER BOARD SCREW	EA		9	*	*	*	*	*	D2	9
0151		O		5310-012-1841	WASHER, LOCK: CONTACTOR MTG	EA		3	*	*	*	*	*	D2	16
0152		O		5310-582-5965	WASHER, LOCK: LEADS TO SWITCHES	EA		12	*	*	*	*	*	D9	5
0153		O		5310-043-2226	WASHER, LOCK: SPARK GAP AND BRACKET MTG	EA		2	*	*	*	*	*	D7	7
0154	M	O			WIRE, COPPER, SOLID: CONTACTOR MANUFACTURE FROM:	EA		2						D2	14
0154A	P	O		6145-548-2350	WIRE, ELECTRICAL (8 IN. REQUIRED FOR EACH WIRE)	FT			SEE GRP 9501						
0155					4411 - RESISTOR COMPONENTS										
0156	X2	F			HANDLE, CONTROL, RHEOSTAT	EA		1	*	*	*	*	*	D10	22
0157	X2	O			KNOB, RHEOSTAT	EA		1	*	*	*	*	*	D8	12
0158	M	F			LEAD, COPPER: RESISTOR TO RECTIFIER MANUFACTURE FROM:	EA		3						D5	8
0158A	P	F		9535-232-2293	COPPER STRIP (1 IN. x 6 IN. REQUIRED FOR EACH LEAD)	SP			SEE GRP 9501						
0159	M	F			LEAD, COPPER: RESISTOR TO RESISTOR MANUFACTURE FROM:	EA		4							
0159A	P	F		9535-232-2293	COPPER STRIP (1/2 IN. x 9 IN. REQUIRED FOR EACH LEAD)	SP			SEE GRP 9501					D5	9
0160	M	F			LEAD, ELECTRICAL: RESISTOR TO RECTIFIER MANUFACTURE FROM:	EA		4						D3	14
0160A	X2	F		5940-050-6204	TERMINAL, LUG: COPPER, TINNED FINISH, No. 22 TO 18 AWG, FOR 1/4 IN. BOLT	EA		4	*	*	*	*	*		
0160B	P	F		6145-263-6982	WIRE, ELECTRICAL (5 IN. REQUIRED FOR EACH LEAD)	FT			SEE GRP 9501						

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS. GS MAINT. ALW.			(8) 1-YR. ALW. PER 100 EQUIP. CITYGCY. PLANNING	(9) DEPOT MAINT. ALW. PER 100 EQUIP.	(10) ILLUS-TRATION	
	(a) SOURCE	(b) MAINT.	(c) RECOV.						(a) 1-20	(b) 21-50	(c) 51-100			(a) FIG. NO.	(b) ITEM OR SYM. NO.
	MANUFACTURER'S		CODE						PART NUMBER						
0161		F		5310-619-3555	NUT, PLAIN, HEXAGON: LEAD TO RESISTOR	EA		5	*	*	*	*	*	D5	11
0162		F		5310-262-6169	NUT, PLAIN, HEXAGON: RESISTOR MTG	EA		2	*	*	*	*	*	D7	9
0163		F		5310-298-9261	NUT, PLAIN, HEXAGON: RESISTOR MTG	EA		4	*	*	*	*	*	D5	3
0164	P	F		5905-280-1597	RESISTOR, ADJUSTABLE: 1000 OHMS RECTIFIER										
0165	P	F		5905-081-2898	PLATE RESISTOR, FIXED: NON-INDUCTIVE	EA		2	2	3	5	60	20	D3	15
0166	X2	F		5905-755-2432	RESISTOR, VARIABLE	EA	96073 19R1746	1	2	2	3	30	10	D7	13
0167	X2	F		5905-083-2713	RESISTOR ASSEMBLY: RECTIFIER, MOUNTED ON FAN BRACKET	EA	44655 0310	1	*	*	*	*	*	D8	10
0168	P	F		5905-083-8225	RHEOSTAT	EA	96073 19R1764	2	*	*	*	*	*	D5	13
0169		F		5305-021-3616	SCREW, CAP, HEXAGON HEAD: LEAD MTG, RESISTOR TO RESISTOR	EA	96073 19R1550	1	2	2	3	30	10	D10	8
0170		F		5305-271-2566	SCREW, MACHINE: RESISTOR MTG	EA		5	*	*	*	*	*	D5	6
0171		F		5305-988-9265	SCREW, MACHINE: RHEOSTAT MTG	EA		2	*	*	*	*	*	D7	12
0172		F		5305-010-2571	SETSCREW: RHEOSTAT HANDLE	EA		2	*	*	*	*	*	D10	21
0173		O		5305-014-0854	SETSCREW: RHEOSTAT KNOB	EA		2	*	*	*	*	*	D10	24
0174	M	F			SPACER, RHEOSTAT	EA		1	*	*	*	*	*	D8	11
0174A	P	F		4710-278-5380	MANUFACTURE FROM: PIPE, STEEL (1 IN. REQUIRED FOR EACH SPACER)	FT				SEE GRP 950				D10	25
0175		F		5310-014-7577	WASHER, FLAT: LEAD TO RESISTOR	EA		10	*	*	*	*	*	D5	7
0176		F		5310-167-0816	WASHER, FLAT: RESISTOR MTG	EA		2	*	*	*	*	*	D7	10
0177		F		5310-010-3319	WASHER, LOCK: LEAD TO RESISTOR	EA		5	*	*	*	*	*	D5	10
0178		F		5310-010-6497	WASHER, LOCK: RESISTOR MTG	EA		4	*	*	*	*	*	D5	4
0179					4412 - TRANSFORMER, COMPONENTS										
0180		F		5306-680-6004	BOLT, MACHINE: LEAD TO COIL	EA		2	*	*	*	*	*	D9	20
0181	X2	H		5306-680-6004	BOLT, MACHINE: MAIN TRANSFORMER TO FRAME	EA		4	*	*	*	*	*	D1	13
0182	P	F		5910-083-2715	CAPACITOR, POWER: 1555547 KGT 4300-4, 30 UF, 440V, AC	EA	96073 4R419	2	2	3	5	60	20	D2	6
0183	X2	F			CLAMP, HOLD DOWN: CAPACITOR	EA	96073 4R2159	4	*	*	*	*	*	D2	1
0184	P	F		3431-083-2654	COIL, TESLA	EA	96073 2661748	1	*	*	2	8	2	D9	18
0185	M	F			INSULATION, PLASTIC: TESLA COIL LEAD MANUFACTURE FROM:	EA		1						D9	24
0185A	P	F		5970-644-2629	INSULATION SLEEVING, ELECTRICAL (8 IN. REQUIRED)	FT				SEE GRP 950					
0186	M	F			LEAD, COPPER: TESLA COIL MANUFACTURE FROM:	EA		3						D9	21
0186A	P	F		9535-232-2293	COPPER STRIP (1 IN. x 9 IN. REQUIRED FOR EACH LEAD)	SP				SEE GRP 950					
0187		H		5310-545-2629	NUT, PLAIN, HEXAGON: MAIN TRANSFORMER TO FRAME	EA		4	*	*	*	*	*	D1	10

LINE NO.	(1) SOURCE, MAINT. AND RECOV. CODE			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC IN UNIT PACK	(6) QTY INC IN UNIT	(7) 30-DAY DS/GS MAINT. ALW.			(8) 1-YR. ALW. PER. 100 EQUIP. CTYGCY. PLANNING	(9) DEPOT MAINT. ALW. PER. 100 EQUIP.	(10) ILLUSTRATION			
	(a) SOURCE	(b) MAINT.	(c) RECOV.						MANUFACTURER'S		(a)			(b)	(c)	(a)	(b)
									CODE	PART NUMBER							
0214		F		5310-012-0377	NUT, PLAIN, HEXAGON: RECTIFIER MTG	EA		16	*	*	*	*	*	D3	1		
0215		F		5310-012-0377	NUT, PLAIN, HEXAGON: RECTIFIER TO FRAME MTG	EA		1	*	*	*	*	*	D6	3		
0216	X2	F		6130-553-6218	RECTIFIER ASSEMBLY	EA		1	*	*	*	*	*	D3	5		
0217	P	F		5960-083-2716	SEMI CONDUCTOR DEVICE, DIODE: 300 AMP	EA		4	2	2	3	30	12	D3	2		
0218	P	F		6130-553-6218	RECTIFIER, METALLIC	EA		1	*	2	2	15	5	D6	5		
0219	M	F			ROD, RECTIFIER	EA		2						D3	11		
0219A	P	F		9510-288-6059	MANUFACTURE FROM: STEEL BAR, ALLOY, COLD FINISHED (23 IN. REQUIRED FOR EACH ROD)	FT			SEE GRP 950								
0220		F		5305-068-0505	SCREW, CAP, HEXAGON HEAD: BAR TO RECTIFIER, DIODE TERMINAL MTG	EA		5	*	*	*	*	*	D3	8		
0221	M	F			SPACER, PLASTIC: RECTIFIER MTG (LARGE)	EA		4						D3	6		
0221A	P	F		4710-838-9382	MANUFACTURE FROM: PLASTIC, TUBING (2 1/4 IN. REQUIRED FOR EACH SPACER)	FT			SEE GRP 950								
0222	M	F			SPACER, PLASTIC: RECTIFIER MTG (SMALL)	EA		4						D3	7		
0222A	P	F		4710-599-9479	MANUFACTURE FROM: PLASTIC, TUBING (2 3/4 IN. REQUIRED FOR EACH SPACER)	FT			SEE GRP 950								
0223		F		5310-209-0711	WASHER, FLAT: RECTIFIER MTG	EA		8	*	*	*	*	*	D3	3		
0224		F		5310-582-5965	WASHER, LOCK: BAR TO RECTIFIER AND DIODE TERMINAL MTG	EA		5	*	*	*	*	*	D3	9		
0225		F		5310-637-9541	WASHER, LOCK: RECTIFIER MTG	EA		2	*	*	*	*	*	D3	12		
0226		F		5310-637-9541	WASHER, LOCK: RECTIFIER TO FRAME MTG	EA		1	*	*	*	*	*	D6	4		
0227	X2	F			WASHER, INSULATING	EA		8						D3	4		
0227A	P	F		5970-284-7201	MANUFACTURE FROM: INSULATION, SHEET, ELECTRICAL: FIBER 1/2 IN. ID, 7/8 IN. OD, 1/8 IN. THK	FT			SEE GRP 950								
0228					GROUP 95 - GENERAL USE STANDARDIZED PARTS												
0229					9501 - BULK MATERIAL												
0230	P	O		9535-231-8256	COPPER SHEET: 0.1250 IN. THK, 24 IN. W, 48 IN. LG	SH			*	2	2	15	3				
0231	P	O		9535-232-2293	COPPER STRIP: 0.032 IN. THK, 12 IN. W, 36 IN. LG	SP			*	2	2	15	3				
0231A	P	O		5970-254-4038	INSULATION, SHEET, ELECTRICAL	SH			*	*	2	10	2				





Figure D1. Main Transformer and Base.




EMC 3431-203-15/48

Figure D2. Contactors and Capacitors.

INDEX TO PARTS, FIGURE D2

REF No.	FUNCT GROUP	ITEM NAME	REF No.	FUNCT GROUP	ITEM NAME
1	4412	CLAMP	11	4410	BAR
2	4412	TERMI NAL	12	4410	SCREW
3	4412	SCREW	13	4410	CONTACTOR
4	4412	WI RE	14	4410	WI RE
5	4412	WI RE	15	4410	CABLE AY
6	4412	CAPACI TOR	16	4410	WASHER
7	4410	SCREW	17	4410	NUT
8	4410	BOARD	18	4410	LEAD
9	4410	WASHER	19	4410	CABLE AY
10	4410	NUT	20	4410	BOARD




INDEX TO PARTS, FIGURE D3

REF NO.	FUNCT GROUP	ITEM NAME
1	4413	NUT
2	4413	SEMICONDRDVICE
3	4413	WASHER
4	4413	WASHER
5	4413	RECTIFIER AY
6	4413	SPACER
7	4413	SPACER
8	4413	SCREW
9	4413	WASHER
10	4413	NUT
11	4413	ROD
12	4413	WASHER
13	4413	BAR
14	4411	LEAD
15	4411	RESISTOR
16	4410	SCREW
17	4410	CAPACITOR
18	4410	WASHER
19	4410	NUT

EMC 3431-203-15/49

Figure D3. Rectifier.




EMC 3431-203-15/50

Figure D4. Housing and Solenoid Valve.

INDEX TO PARTS, FIGURE D4

REF NO.	FUNCT GROUP	ITEM NAME	REF NO.	FUNCT GROUP	ITEM NAME
1	4405	COVER	7	4410	WASHER
2	4405	LIFTING EYE	8	4405	PLATE
3	4405	NUT	9	4405	SCREW
4	4405	HOUSING	10	4410	ADAPTER
5	4410	VALVE	11	4410	ADAPTER
6	4410	ELBOW	12	4405	SCREW



INDEX TO PARTS, FIGURE D5


REF NO.	FUNCT GROUP	ITEM NAME
1	4406	SETSCREW
2	4407	BLADE
3	4000	NUT
3	4411	NUT
4	4000	WASHER
4	4411	WASHER
5	4406	GUARD
6	4411	SCREW
7	4411	WASHER
8	4411	LEAD
9	4411	LEAD
10	4406	WASHER
10	4411	WASHER
11	4406	NUT
11	4411	NUT
12	4000	MOTOR
13	4411	RESISTOR AY
14	4406	SCREW

EMC 3431-203-15/51

Figure D5. Fan and Motor.


INDEX TO PARTS, FIGURE D6

REF NO.	FUNCT GROUP	ITEM NAME	REF NO.	FUNCT GROUP	ITEM NAME
1	4412	NUT	7	4409	SWITCH
2	4412	WASHER	8	4407	HARNESS AY
3	4413	NUT	9	4410	SWITCH
4	4413	WASHER	10	4407	RECEPTACLE
5	4413	RECTIFIER	11	4412	SCREW
6	4412	TRANSFORMER	12	4407	JACK



EMC 3431-203-15/52

Figure D6. Transformer, Rectifier, and Wiring Harness.




EMC 3431-203-1:

Figure D7. High Frequency Drawer.

INDEX TO PARTS, FIGURE D7

REF No.	FUNCT GROUP	ITEM NAME	REF NO.	FUNCT GROUP	ITEM NAME	REF NO.	FUNCT GROUP	ITEM NAME
1	4410	SCREW	11	4409	WASHER	21	44.0	CAPACITOR
2	4410	SCREW	11	4410	WASHER	22	441.2	TRANSFORMER
3	4410	LEAO	12	4407	SCREW	23	441.2	WASHER
4	4410	LEAO	12	4410	SCREW	24	4407	SCREW
5	4410	SPARK GAP AY	12	4411	SCREW	24	441.2	SCREW
6	4410	BRACKET	13	4411	RESISTOR	25	4407	CLAMP
7	4410	WASHER	14	4410	SCREW	76	4407	PLUG
8	44.0	NUT	15	4410	CAPACITOR	27	4407	DRAWER
9	4407	NUT	16	4410	LEAO	28	4407	SCREW
9	4409	NuT	17	4410	JACK	29	4409	SCREW
9	4410	NuT	18	4407	PANEL	30	4409	INSULATOR
9	4411	NUT	19	4407	WASHER	31	4409	SWITCH
10	4407	WASHER	19	4407	WASHER	32	4409	LEAD
10	4409	WASHER	20	4407	NUT	33	4410	SCREW
10	4410	WASHER	20	4412	NUT	34	4410	RELAY
10	4411	WASHER						



EMC 3431-203-15/54

Figure D3. High Frequency Panel and Related Parts

INDEX, TO PARTS, FIGURE D8

REF No.	FUNCT GROUP	ITEM NAME	REF NO.	FUNCT GROUP	ITEM NAME
1	4410	PLUG	8	4410	SWI TCH
2	4410	RECEPTACLE	9	4407	LOCK
3	4410	RELAY	10	4411	RESI STOR
4	4410	RELAY	11	4411	SETSCREW
5	4410	SCREW	12	4411	KNOB
6	4410	SWI TCH	13	4407	GLOW LAMP
7	4407	LI GHT			





Figure D9. Switches and Coils.

INDEX TO PARTS, FIGURE D9

REF No.	FUNCT GROUP	ITEM NAME	REF No.	FUNCT GROUP	ITEM NAME	REF No.	FUNCT GROUP	ITEM NAME
	4410	SCREW	10	4410	WASHER	19	4412	WASHER
2	4410	HANDLE	11	4410	SCREW	20	4412	BOLT
3	4410	PIN	12	4410	INSULATION	21	4417	LEAD
4	4410	NUT	13	4410	LEAD	22	4412	WASHER
5	4410	WASHER	14	4410	INSULATION	23	4412	NUT
6	4410	INSULATION	15	4410	INSULATION	24	4412	INSULATION
7	4410	SWITCH	16	4410	LEAD	25	4410	CAPACITOR
8	4410	LEAD	17	4410	LEAD	26	4410	SWITCH
9	4410	LEAD	18	4412	COIL			



EMC 3431-203-15/56

Figure D10. Front Housing Panel and Rheostat.

INDEX TO PARTS, FIGURE D10

REF No.	FUNCT GROUP	ITEM NAME	REF No.	FUNCT GROUP	ITEM NAME	REF No.	FUNCT GROUP	ITEM NAME
1	4405	PANEL	9	4408	INSULATION	18	4408	WASHER
2	4408	RECEPTACLE	10	4408	LEAD	19	4408	NUT
3	4405	SCREW	11	4408	STUD	20	4408	SCREW
3	4408	SCREW	12	4408	WASHER	21	4411	SCREW
4	4405	JACKTIP	13	4408	SCREW	22	4411	HANDLE
5	4405	LEAD WIRE	14	4408	LEAD	23	4408	SWITCH-CABLE WIRE
6	4405	WASHER	15	4408	INSULATION	24	4411	SETSCREW
7	4405	NUT	16	4408	PANEL	25	4411	SPACER
8	4411	RHEOSTAT	17	4408	WASHER			

INDEX

	Paragraph	Page
Accessory transformer	4-32	4-18
Basic issue tools and equipment	3-2	3-1
Capacitors	4-25	4-7
Contactors	3-41	3-13
Control panel	4-16	4-3
Control rectifier	4-22	4-6
Control rheostat	4-20	4-5
Controls and instruments	2-9	2-4
Description	1-3,4-3	1-1, 4-1
Difference in models	1-5	1-4
Diodes	4-24	4-7
Direct and general support and maintenance repair parts	4-6	4-2
Dismantling for movement	2-4	2-3
Dummy plug	3-43	3-14
Equipment conversion	2-5	2-3
Fan	3-54	3-17
Fan, motor, and guard assembly	3-52	3-16
Fan motor lubrication	3-5	3-1
Field expedient repairs:		
General	3-31	3-10
High frequency inoperative	3-23	3-6
Loss of water	3-22	3-6
Power failure	3-24	3-6
Filter reactor	4-20	4-15
Frame	4-39	4-22
General lubrication information	3-4	3-1
Gas solenoid valve	3-49	3-16
Gas-water switch	3-32	3-10
Ground and electrode terminal board	3-47	3-15
Guard	3-55	3-17
High frequency control transformer	4-33	4-18
High frequency dropout switch	3-37	3-12
High frequency panel assembly	3-27	3-7
High frequency spot arc switch	3-36	3-11
High frequency switch	3-33	3-10
Inspecting and servicing equipment	2-3	2-1
Installation or setting-up instructions	2-4	2-1
Intensity selector	4-21	4-6
Interlock switch	3-35	3-11
Main transformer	4-34	4-19
Main transformer support assembly	4-39	4-22
Motor	3-53	3-17
Operation:		
In extreme dusty or sandy areas	2-16	2-7

	Paragraph	Page
In extreme cold -----	2-14	2-7
In extreme heat -----	2-15	2-7
In salt water areas -----	2-18	2-9
Under rainy or humid conditions -----	2-17	2-7
Organizational maintenance repair parts -----	3-3	3-1
Panel door lock -----	3-28	3-7
Pilot lamps -----	3-10	3-5
Pilot lights -----	3-30	3-10
Polarity switch -----	4-19	4-5
Power switch -----	3-31	3-10
Preventive maintenance services:		
Daily -----	3-7	3-2
General -----	3-6	3-2
Quarterly -----	3-8	3-2
Range switch -----	4-18	4-4
Reactor coil -----	4-30	4-15
Record and report forms -----	1-2, 4-2	1-1, 4-1
Rectifier assembly -----	4-23	4-6
Reinstallation after movement -----	2-7	2-3
Remote amperage switch -----	3-40	3-13
Remote contactor switch -----	3-39	3-13
Remote receptacle -----	3-38	3-12
Resistors -----	4-26	4-2
Scope -----	1-1, 4-1	1-1, 4-1
Spark gap adjustor -----	3-45	3-14
Specially designed tools and equipment -----	4-7	4-2
Special tools and equipment -----	3-1, 4-5	3-1, 4-2
Starting -----	2-11	2-4
Stopping -----	2-12	2-4
Switching panel -----	4-28	4-15
Tabulated data -----	1-4, 4-4	1-4, 4-1
Tesla coil -----	4-31	4-16
Thermostatic switch -----	3-42	3-13
Timer receptacles -----	4-17	4-3
Timer relay -----	4-27	4-15
Timers -----	3-34	3-10
Troubleshooting:		
Contactor breaks circuit -----	3-20, 4-15	3-6, 4-3
Cooling fan does not operate -----	3-13	3-5
Fan assembly noisy -----	3-14	3-5
Gas insufficient -----	3-15	3-6
General -----	3-11, 4-8	3-5, 4-2
Pilot light inoperative -----	3-17	3-6
Polarity cannot be selected -----	4-10	4-3
Range cannot be selected -----	4-11	4-3
Remote control does not function properly -----	3-19	3-6
Water insufficient -----	3-16	3-6
Welding machine fails to start -----	3-12, 4-13	3-5, 4-3
Welding machine has internal arcing -----	4-12	4-3
Welding machine operates erratically -----	3-18, 4-14	3-6, 4-3
Welding machine smokes excessively -----	4-9	4-3
Unloading the equipment -----	2-1	2-1
Unpacking the equipment -----	2-2	2-1
Voltage change bars -----	3-46	3-14
Water solenoid valve -----	3-50	3-16
Welding machine operation -----	2-13	2-4
Welding machine top and housing -----	3-26	3-7
Wiring -----	4-36, 4-37	4-20, 4-21

By Order of the Secretary of the Army:

HAROLD K. JOHNSON,
*General, United States Army,
 Chief of Staff.*

Official.

KENNETH G. WICKHAM,
*Major General United States Army,
 The Adjutant General.*

Distribution:


Active Army:

USASA (2)	USAMEC (46)
ACSI (1)	Engr Cen (5)
DCSLOG (1)	AME (3)
CNGB (1)	MAAG (1)
TSG (1)	JBUSMC (1)
Cof Engrs (3)	Engr FLDMS (2)
CC-E (1)	Ft Knox FLDMS (10)
Dir of Trans (1)	USACOMZEUR (2)
Cofspts (1)	Fld Cored, DASA (8)
USAMB (1)	USAREUR Engr Proc Cen (2)
USA Arty Bd (2)	USAREUR Engr Sup Con Agcy (10)
USA Armor Bd (2)	Units org under fol TOE : -2 ea. UNOINDC
USAIB (2)	5-5
USARADB (2)	5-6
USAAESWBD (2)	5-15
USAAVNTBD (2)	5-16
USCONARC (3)	5-48
OS Maj Comd (5) except	5-145
USARJ (1)	5-146
USASETAF (2)	5-155
USAMC (1)	5-156
USACDCEC (10)	5-237 (5)
MDW (1)	5-262 (5)
Armies (2)	5-267 (1)
corps (2)	5-278 (5)
USAC (1)	5-279
Div (2)	7
Engr Bde (1)	9-87
USMA (2)	9-510
Svc Colleges (2)	17
Br Svc Sch (2)	29-16
Gen Dep (10)	29-17
Engr Dep (10)	29-26
Army Dep (2) except	29-27
TOAD (3)	29-36
USA Tml Cored (2)	29-37
Army Tml (1)	37
Div Engr (2)	55-158
Engr Dist (2)	57-100
USA Engr R&D Lab (3)	


NG: State AG (3)

USAR: Same as Active Army except allowance is one (1) copy for each unit.

For explanation of abbreviations used, see AR 320-50




- SYMBOL LEGEND**
- V VOLT
 - AC ALTERNATING CURRENT
 - DC DIRECT CURRENT
 - + POSITIVE
 - NEGATIVE
- WIRE CODE**
- | | |
|------------|------------|
| R (RED) | BLU (BLUE) |
| B (BLACK) | BR (BROWN) |
| Y (YELLOW) | G (GREEN) |
| W (WHITE) | O (ORANGE) |
| DR (DARK) | LT (LIGHT) |
- R-1 OR R1- ETC., DENOTES COLOR AND CIRCUIT IDENTIFICATION



- DEVICE LEGEND**
- A SECONDARY COILS (MAIN TRANSFORMER)
 - C CONTROL COILS (MAIN TRANSFORMER)
 - D PRIMARY COILS (MAIN TRANSFORMER)
 - E BOOSTER COILS (MAIN TRANSFORMER)
 - F MAIN CONTACTOR
 - H MAIN CONTACTOR COIL
 - C1 CAPACITOR, (.01 UF, 1,000 WORKING VOLTS DC)
 - C2 CAPACITOR (30 UF, 440 VOLTS)
 - I1 HIGH FREQUENCY INDICATING LAMP
 - I2 GAS AND WATER INDICATING LAMP
 - I3 POWER INDICATING LAMP
 - P1 SPOT ARC TIMER SOCKET
 - P2 HIGH FREQUENCY DROP OUT TIMER SOCKET
 - P3 PRE FLOW TIMER SOCKET
 - P4 POST FLOW TIMER SOCKET
 - R1 RESISTOR, 1000 OHMS 10 WATT
 - S1 PANEL AND REMOTE AMPERAGE SWITCH
 - S2 PANEL AND REMOTE CONTACTOR SWITCH

Figure 1-4. Practical wiring diagram.



SYMBOL LEGEND		DEVICE LEGEND	
	II PIN PLUG CONNECTION		SILICON DIODE RECTIFIER
	SINGLE PLUG CONNECTION		CAPACITOR
	COIL OR WINDING	COM	COMMON
	NORMALLY CLOSED CONTACTS	AC	ALTERNATING CURRENT
	NORMALLY OPEN CONTACTS	DC	DIRECT CURRENT
	RESISTOR	S	START OF WINDING
	SINGLE POLE, SINGLE THROW SWITCH	E	END OF WINDING
	DOUBLE POLE, SINGLE THROW SWITCH	+	POSITIVE
	RELAY CONTACTS	-	NEGATIVE
		UF	MICROFARAD
		C1	CAPACITOR (.01 UF/1000 WORKING VOLTS DC)
		C2	CAPACITOR (.0015 UF/5000 VOLTS/5.5 AMPS.)
		C3	CAPACITOR (4 UF/600 VOLTS)
		C4	CAPACITOR (30 UF/440 VOLTS/AC)
		C5	CAPACITOR (30 UF/440 VOLTS/AC)
		C6	CAPACITOR (30 UF/440 VOLTS/AC)
		R1	ADJUSTABLE TAP RESISTOR (1000 OHMS 10 WATTS)
		R2	ADJUSTABLE TAP RESISTOR (1000 OHMS 10 WATTS)
		R3	FIXED RESISTOR (25 OHMS 25 WATTS NON INDUCTIVE)
		R4	BALLAST RESISTOR
		R5	AMPERAGE CONTROL RHEOSTAT (32 OHMS 300 WATTS)
		R6	INTENSITY SELECTOR RHEOSTAT (2 OHMS 50 WATTS 5 AMPERE)
		S8	AMPERAGE PANEL OR REMOTE SWITCH
		S9	MAIN CONTACTOR PANEL OR REMOTE SWITCH
		T1	MAIN TRANSFORMER
		T2	CONTROL TRANSFORMER
		T3	HIGH FREQUENCY TRANSFORMER
		TB	VOLTAGE CHANGE BOARD
		V1	GAS SOLENOID VALVE
		V2	WATER SOLENOID VALVE
		K1	RELAY (24 V/AC)
		L	SMOOTHING REACTOR
		L1	AC POWER INPUT CONNECTIONS
		L2	AC POWER INPUT CONNECTIONS
		M1	FAN MOTOR (230 VOLTS AC, 1.25 AMPERE, 1550 RPM)
		R1	ADJUSTABLE TAP RESISTOR (1000 OHMS 10 WATTS)
		R2	ADJUSTABLE TAP RESISTOR (1000 OHMS 10 WATTS)
		RT1	SPOT ARC TIMER
		RT2	HIGH FREQUENCY DROP OUT TIMER
		RT3	PREFLOW TIMER
		RT4	POST FLOW TIMER
		S1	PANEL INTERLOCK SWITCH
		S2	POWER SWITCH
		S3	MAIN TRANSFORMER THERMOSTATIC SWITCH
		S4	HIGH FREQUENCY SWITCH
		S5	GAS AND WATER SWITCH
		S6	HIGH FREQUENCY DROP OUT TIMER SWITCH
		S7	SPOT ARC TIMER SWITCH

Figure 4-1. Schematic wiring diagram.

TM 5-3431-203-15 WELDING MACHINE, ARC, INERT SHIELDED-1967