

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

ORGANIZATIONAL, DS, GS,
AND DEPOT MAINTENANCE MANUAL
INCLUDING REPAIR PARTS

WELDING MACHINE, ARC:
GENERATOR; ELECTRIC MOTOR DRIVEN,
300-AMP DC ARC, 220 / 440-V, 60-CYCLE,
3-PHASE, WHEEL MOUNTED
(HARNISCHFEGER MODEL W300 MG)
FSN 3431-226-1569

This reprint includes all changes in effect at the
time of publication; changes 1 and 2.

HEADQUARTERS, DEPARTMENT OF THE ARMY

APRIL 1965

SAFETY PRECAUTIONS

BEFORE OPERATION

Provide adequate ventilation for removal and dilution of fumes and gases.

When connecting to outside power source, make sure main disconnect switch is in OFF position.

Always check voltage rating of welding machine against power line voltage before making any connections.

The welder frame must be grounded by connecting to a good electrical ground, such as a water pipe.

Always disconnect welder from power line before inspecting it.

DURING OPERATION

Provide adequate ventilation for removal and dilution of fumes and gases.

When connecting to outside power source, make sure main disconnect switch is in OFF position.

Always check voltage rating of welding machine against power line voltage before making any connections.

On initial start of the machine, immediately check direction of rotation as indicated by arrow on the nameplate. Direction of rotation may be changed by interchanging any two input leads on the three-phase motors.

The welder frame must be grounded by connecting to a good electrical ground such as a water pipe.

Do not perform any welding operation without a welder's helmet. The flash of the welding arc can cause injury to the eye.

Do not adjust welding controls while maintaining arc.

Always disconnect welder from power line before inspecting it.

AFTER OPERATION

Always disconnect welder from power line before inspecting it.

CHANGE }
No. 1 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 24 January 1969

Organizational, DS, OS, and Depot Maintenance Manual

Including Repair Parts and Special Tools List

WELDING MACHINE, ARC: GENERATOR: ELECTRIC MOTOR

DRIVEN, 300-AMP DC ARC, 220/440-V, 60-CYCLE, 3-PHASE, WHEEL

MOUNTED (HARNISCHFEGER MODEL W300 MG) FSN 3431-226-1569

TM 5-3431-217-15, 9 April 1965, is changed as follows:
Page 2, section I. Paragraph 1*d* is superseded as follows:

d. Reporting of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be

submitted on DA Form 2028 (Recommended Changes to DA Publications) and forwarded direct to Commanding General, U. S. Army Mobility Equipment Command, ATTN: AMSME-MPP, 4300 Goodfellow Boulevard, St. Louis, Mo. 63120.

Page 45. Appendix I is superseded as follows:

APPENDIX I

REFERENCES

1. Fire Protection

TM -687

Repairs and Utilities: Fire Protection Equipment and Appliances Inspections, Operations and Preventive Maintenance.

2. Painting

TM 9-213

Painting Instructions for Field Use.

3. Maintenance

TB ENG 347

TM 5-764

TM 9-207

TM 38-750

Winterization Techniques for Engineer Equipment.

Electric Motor and Generator Repair.

Operation and Maintenance of Ordnance Material in Extreme Cold (° to -65°F.)

Army Equipment Record Procedures.

4. Shipment and Limited Storage

TM 38-230

Preservation, Packaging, and Packing of Military Supplies and Equipment.

**APPENDIX II
MAINTENANCE ALLOCATION CHART**

Section I. INTRODUCTION

1. General

a. This section provides a general explanation of all maintenance and repair functions authorized at various maintenance levels.

b. Section II designates overall responsibility for the performance of maintenance functions on the identified end item or component. The implementation of the maintenance functions upon the end item or component will be consistent with the assigned maintenance functions.

c. Section III. Special Tool and Special Test Equipment Requirements. Not applicable.

d. Section IV. Remarks. Not applicable.

2. Explanation of Columns in Section II

a. *Group Number*, Column (1). The functional group is a numerical group set up on a functional basis. The applicable functional grouping indexes (obtained from TB 750-93-1, Functional Grouping Codes) are listed on the MAC (Maintenance Allocation Chart) in the appropriate numerical sequence. These indexes normally are set up in accordance with their function and proximity to each other.

b. *Functional Group*, Column (2). This column contains a brief description of the component of each functional group.

c. *Maintenance Functions*, Column (3). This column lists the various maintenance functions (A through K) and indicates the lowest maintenance category authorized to perform these functions. The symbol designations for the various maintenance categories are as follows:

- C - Operator or crew
- O - Organizational maintenance
- F - Direct support maintenance
- H - General support maintenance
- D - Depot maintenance

The maintenance functions are defined as follows:

- A - Inspect: To determine serviceability of an item by comparing its physical, mechanical, and electrical characteristics with established standards.
- B- Test: To verify serviceability and to detect electrical or mechanical failure by use of test equipment.
- C - Service: To clean, to preserve, to charge, to paint, and to add fuel, lubricants, cooling agents, and air.
- D - Adjust: To rectify to the extent necessary to bring into proper operating range.
- E- Align: To adjust specified variable elements of an item to bring to optimum performance.

F - Calibrate: To determine the corrections to be made in the readings of instruments or test equipment used in precise measurement. Consists of the comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared with the certified standard.

G - Install: To set up for use in an operational environment such as an emplacement, site, or vehicle.

H - Replace: To replace unserviceable items with serviceable assemblies, subassemblies, or parts.

I - Repair: To restore an item to serviceable condition. This includes, but is not limited to, inspection, cleaning, preserving, adjusting, replacing, welding, riveting, and strengthening.

J - Overhaul: To restore an item to a completely serviceable condition as prescribed by maintenance serviceability standards using the Inspect and Repair Only as Necessary (IROAN) technique.

K - Rebuild: To restore an item to a standard as nearly as possible to original or new condition in appearance, performance, and life expectancy. This is accomplished through complete disassembly of the item, inspection of all parts or components, repair or replacement of worn or unserviceable elements (items) using original manufacturing tolerances and specifications, and subsequent reassembly of the item.

d. *Tools and Equipment*, Column (4). This column is provided for referencing by code the special tools and test equipment, (sec. III) required to perform the maintenance function (sec. II).

e. *Remarks*, Column (5). This column is provided for referencing by code the remarks (sec. IV) pertinent to the maintenance functions.

3. Explanation of Columns in Section III

a. *Reference Code*. This column consists of a number and a letter separated by a dash. The number references the T&TE requirements column on the MAC. The letter represents the specific maintenance function the item is to be used with. The letter is representative of columns A through K on the MAC.

b. *Maintenance Category*. This column shows the lowest level of maintenance authorized to use the special tool or test equipment.

c. *Nomenclature*. This column lists the name or identification of the tool or test equipment.

d. *Tool Number*. This column lists the manufacturer's code and part number, or Federal stock number of tools and test equipment.

4. Explanation of Columns in Section IV

a. *Reference Code.* This column consists of two letters separated by a dash, both of which are references to section II. The first letter references

column 5 and the second letter references a maintenance function, column 3, A through K.

b. *Remarks.* This column lists information pertinent to the maintenance function being performed, as indicated on the Maintenance Allocation Chart, section II.

Section II. MAINTENANCE ALLOCATION CHART

(1) Group No.	(2) Functional Group	(3) Maintenance functions											(4) Tools and equipment	(5) Remarks			
		A	B	C	D	E	F	G	H	I	J	K					
		Inspect	Test	Service	Adjust	Align	Calibrate	Install	Replace	Repair	Overhaul	Rebuild					
10	FRONT AXLE																
1000	Front Axle Assembly																
	Tongue											O	O				
11	REAR AXLE																
1100	Rear Axle Assembly											O					
13	WHEELS AND TRACKS																
1311	Wheel Assembly											O					
15	FRONT TOWING ATTACHMENT, AND DRAWBARS																
1501	Frame Assembly											O	H				
22	ACCESSORY ITEMS																
2202	Accessory Items																
	Remote control assembly.....											O	F				
	Cables											O	O				
2210	Data Plates											O					
44	WELDING EQUIPMENT																
4400	Arc Welders																
	Welder assembly			O	O								F	D			
4401	Rotor Assembly																
	Armature assembly				H							H	D				
	Armature exciter				F							F					
4402	Stator Assembly																
	Stator assembly, motor				H							F	D				
	Coil set, exciter field.....				F							F					
	Coils, generator stator				H							H					
	Cable and wiring.....											H	O				
4403	Brush Holder Assembly																
	Brushes		O									O					
	Brush holder assemblies.....											F	F				
4405	Frame Support, Housing Carrier																
	Bearings, ball				O							H					
4406	Ventilating, Cooling System																
	Fan, cooling.											F					
4407	Control Panels, Housing																
	Control box assembly											F					
	Wiring.....											F					
	Meter, shunt, receptacle.....											F					
4408	Connecting Devices																
	Terminal assemblies.....											O					
	Cable assembly.....											O	O				
	Bus bars											F					
4409	Protective Devices, Electrical																
	Thermostat											F					
4410	Switching Control																
	Switches.....											F					
	Starter assembly												F				
4411	Resistor Components																
	Resistor				F							F					
	Rheostat											F					

**APPENDIX III
BASIC ISSUE ITEMS LIST**

Section I. INTRODUCTION

1. Scope

This appendix lists items which accompany the welding machine or are required for installation, operation, or operator's maintenance.

2. General

This basic issue items list is divided into the following sections:

a. Basic Issue Items - Section II. A list of items which accompany the welding machine or are required for the installation, operation, or operator's maintenance.

b. Maintenance and Operating Supplies - Section III. A listing of maintenance and operating supplies required for initial operation.

3. Explanation of Columns

The following provides an explanation of columns in the tabular list of basic issue items, section II.

a. Source, Maintenance, and Recoverability Codes (SMR), Column (1).

(1) Source Code, indicates the selection status and source for the listed item. Source codes are -

Code	Explanation
P	Applied to repair parts which are stocked in or supplied from GSA/DSA or Army supply system, and authorized for use at indicated maintenance categories.
M	Applied to repair parts which are not procured or stocked but are to be manufactured at indicated maintenance categories.
A	Applied to assemblies which are not procured or stocked as such, but made up of two or more units, each, of which carry individual stock numbers and descriptions and are procured and stocked and can be assembled by units at indicated maintenance categories.
X	Applied to parts and assemblies which are not procured or stocked, the mortality of which normally is below that of the applicable end item, and the failure of which should result in retirement of the end item from the supply system.
X1	Applied to repair parts which are not procured or stocked. the requirement for which will be supplied by use of the next higher assembly or components.
X2	Applied to repair parts which are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain them through cannibalization; if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.
C	Applied to repair parts authorized for local procurements. If not obtainable from local procurement, such repair parts will be requisitioned through normal supply channels with a supporting statement of nonavailability from local procurement.

Code	Explanation
-------------	--------------------

G	Applied to major assemblies that are procured with PEMA (Procurement Equipment Missile Army) funds for initial issue only to be used as exchange assemblies at DSU and GSU level or returned to depot supply level.
---	---

Note. Source code and level of maintenance are not shown on common hardware items known to be readily available in Army supply channels and through local procurement.

(2) Maintenance code, indicates the lowest category of maintenance authorized to install the listed item. The maintenance level code is -

Code	Explanation
-------------	--------------------

C	Operator/crew
O	Organizational maintenance

(3) Recoverability code, indicates whether unserviceable items should be returned for recovery or salvage. Items not coded are expendable. Recoverability codes -

Code	Explanation
-------------	--------------------

R	Applied to repair parts and assemblies which are economically repairable at DSU and GSU activities and are normally furnished by supply on an exchange basis.
---	---

T	Applied to high-dollar value recoverable repair parts which are subject to special handling and are issued on an exchange basis. Such repair parts normally are repaired or overhauled at depot maintenance activities.
---	---

U	Applied to repair parts specifically selected for salvage by reclamation units because of precious metal content, critical materials, high-dollar value reusable casing and castings.
---	---

b. Federal Stock Number, Column (2). This column indicates the Federal stock number for the item.

c. Description, Column (3). This column indicates the Federal item name and any additional description of the item required. A part number or other reference number is followed by the applicable five-digit Federal supply code for manufacturers in parentheses. Repair parts quantities included in kits, sets, and assemblies are shown in front of the repair part name.

d. Unit of Issue, Column (4). This column indicates the unit used as a basis for issue, e.g., ea, pr, ft, yd, etc.

e. Quantity Incorporated in Unit Pack, Column (5). This column indicates the actual quantity contained in the unit pack.

f. *Quantity Incorporated in Unit*, Column (6). This column indicates the quantity of the item used in the functional group.

g. *Quantity Furnished with Equipment* Column (7). This column indicates the quantity of an item furnished with the equipment.

h. *Quantity Authorized* Column (8). This column indicates the quantity of an item authorized the operator/crew to have on hand or to obtain as required. As required items are indicated with an asterisk.

i. *Illustration* Column (9). This column is divided as follows:

(1) *Figure number, column (9)(a)*. Indicates the figure number of the illustration in which the item is shown.

(2) *Item number column (9)(b)*. Indicates the callout number used to reference the item in the illustration.

4. Explanation of Columns in the Tabular List of Maintenance and Operating Supplies - Section III

a. *Component Application* Column (1). This column identifies the component application of each maintenance or operating supply item.

b. *Federal Stock Number* Column (2). This column indicates the Federal stock number for the item and will be used for requisitioning purposes.

c. *Description* Column (3). This column indicates the item and brief description.

d. *Quantity Required for Initial Operation* Column (4). This column indicates the quantity of each maintenance or operating supply item required for initial operation of the equipment.

e. *Quantity Required for 8 Hours Operation* Column (5). This column indicates the estimated quantities required for an average eight hours of operation.

f. *Notes* Column (6). This column indicates informative notes keyed to data appearing in a preceding column.

Section II. BASIC ISSUE ITEMS

(1) SMR Code	(2) Federal Stock Number	(3) Description Ref no. & mfr Code Usable on code	(4) Unit of Issue	(5) Qty inc in unit pack	(6) Qty inc in unit	(7) Qty furn with equip	(8) Qty auth	(9) Illustration	
								(A) Fig no.	(B) Item No.
P C	7520-559-9618	31- BASIC ISSUE ITEMS, MANUFACTURER INSTALLED 3100 - BASIC ISSUE ITEMS MANUFACTURER OR DEPOT INSTALLED CASE: maintenance and operational manuals, cotton, duck, water repellent, mildew-resistant, MIL-B-117438. DEPARTMENT OF THE ARMY, OPERATOR, ORGANIZATIONAL, DIRECT AND GENERAL SUPPORT AND DEPOT MANUAL, INCLUDING REPAIR PARTS TM 5-3431-217-15.	ea			1	1		
P C	7510-889-3494	BINDER: loose leaf, U.S. Army Equipment Log Book	ea			1	1		
P C	4210-555-8837	32- BASIC ISSUE ITEMS, TROOP INSTALLED 3200 - BASIC ISSUE ITEMS, TROOP INSTALLED OR AUTHORIZED EXTINGUISHER. Fire, dry chemical, charged hand, pressurized w/dry air or nitrogen gas, Clam 4-B, C, 2½ lb. w/universal bracket (Repair Part Manual Group 7608).	ea			*	1		

**APPENDIX IV
REPAIR PARTS LIST**

Section I. INTRODUCTION

1. Scope

This manual lists repair parts required for the performance of organizational, direct support, general support, and depot maintenance of the welding machine.

2. General

a. The repair parts list is arranged as follows:

(1) Individual parts and major assemblies are listed by item name within the numbered functional groups.

(2) Assembly components and subassemblies are indented and listed by item name under major assemblies.

b. This repair parts list is divided into the following sections:

(1) *Prescribed Load Allowance (PLA) - Section II.* A consolidated listing of repair parts quantitatively allocated for initial stockage at the organizational level. This is a mandatory minimum stockage allowance.

(2) *Repair Parts - Section III.* A list of repair parts authorized for the performance of maintenance at the organizational level.

(3) *Repair Parts - Section IV.* A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level.

3. Explanation of Columns

The following provides an explanation of columns in the tabular lists in sections II through IV.

a. *Source, Maintenance, and Recoverability Codes (SMR).*

Note. Common hardware items known to be readily available in Army supply channels will be assigned Maintenance codes only. Source codes, recoverability codes, and Maintenance Allowance will not be assigned to this category.

(2) Source code. Indicates the selection status and source for the listed item. Source codes used are-

Code	Explanation
P	Applied to repair parts which are stocked in or supplied from DSA/GSA or Army supply system, and authorized for use at indicated categories.
M	Applied to repair parts which are not procured or stocked but are to be manufactured at indicated maintenance categories.
A	Applied to assemblies which are not procured or stocked as such but made up of two or more units, each of which carry individual stock numbers and descriptions and are procured and stocked and can be assembled by units at indicated maintenance categories.

Code

Explanation

- X Applied to parts and assemblies which are not procured or stocked, the mortality of which normally is below that of the applicable end item, and the failure of which should result in retirement of the end item from the supply system.
- X1 Applied to repair parts which are not procured or stocked, the requirement for which will be supplied by use of the next higher assembly or components.
- X2 Applied to repair parts which are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain them through cannibalization; if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.
- C Applied to repair parts authorized for local procurements. If not obtainable from local procurement, such repair parts will be requisitioned through normal supply channels with a supporting statement of nonavailability from local procurement.
- G Applied to major assemblies that are procured with PEMA (Procurement Equipment Missile Army) funds for initial issue only to be used as exchange assemblies at DSU and GSU maintenance level. These assemblies will not be stocked above DSU and GSU level or returned to depot supply level.

(2) *Maintenance code.* Indicates the lowest category of maintenance authorized to install the listed item. The maintenance level codes are-

Code	Explanation
O	Organizational maintenance
F	Direct support maintenance
H	General support maintenance
D	Depot maintenance

(3) *Recoverability code.* Indicates whether unserviceable items should be returned for recovery or salvage. Items not coded are expendable. Recoverability codes are-

Code	Explanation
-------------	--------------------

R Applied to repair parts and assemblies which are economically repairable at DSU and GSU activities and normally are furnished by supply on an exchange basis.

T Applied to high-dollar value recoverable repair parts which are subject to special handling and are issued on an exchange basis. Such repair parts normally are repaired or overhauled at depot maintenance activities.

U Applied to repair parts specifically selected for salvage by reclamation units because of precious metal content, critical materials, high-dollar value reusable casings or castings.

b. *Federal Stock Number.* Indicates the Federal stock number for the item.

c. *Description.* Indicates the Federal item name and any additional description of the item required. A part number or other reference number is preceded by the applicable five-digit Federal supply code for manufacturers in parentheses. Repair parts quantities included in the kits, sets, and assemblies are shown in front of the repair part name.

d. *Unit of Issue.* Indicates the unit used as a basis for issue, e.g., ea, pr, ft, yd, etc.

e. *Quantity Incorporated in Unit Pack.* Indicates the actual quantity contained ;!,, the unit pack.

f. *Quantity Incorporated in Unit.* Indicates the quantity of the item used in the functional group.

g. *Fifteen-Day Organizational Maintenance Allowances.*

(1) The allowance columns are divided into four subcolumns. Indicated in each subcolumn opposite the first appearance of each item is the total quantity of items authorized for the number of equipments supported. Subsequent appearances of the same item will have no entry in the allowance columns but will have in the description column a reference to the first appearance of the item. Items authorized for used as required but not for initial stockage are identified with an asterisk in the allowance column.

(2) The quantitative allowances for organizational level of maintenance represents one initial prescribed load for a 15-day period for the number of equipments supported. Units and organizations authorized additional prescribed loads will multiply the number of prescribed loads authorized by the quantity of repair parts reflected in the appropriate density column to obtain the total quantity of repair parts authorized.

(3) Organizational units providing maintenance for more than 100 of these equipments shall determine the total quantity of parts required by converting the equipment quantity to a decimal factor by placing a decimal point before the next to last digit of the number to indicate hundredths, and multiplying the decimal factor by the parts quantity in the 51-100 allowance column.

Example authorized allowance for 51-100 equipments is 12; for 140 equipments multiply 12 by 1.

or 16.80 rounded off to 17 parts required.

(4) Subsequent changes to allowances will be limited as follows: No change in the range of items is authorized. If additional items are considered necessary, recommendation should be forwarded to U.S. Army Mobility Equipment Command for exception or revision to the allowance list. Revisions to the range of items authorized will be made by this Command based upon engineering experience, demand data, or TAERS information.

h. *Thirty-Day DS/GS Maintenance Allowances.*

(1) The allowance columns are divided into three subcolumns. Indicated in each subcolumn, opposite the first appearance of each item, is the total quantity of items authorized for the number of equipments supported. Subsequent appearances of the same item will have no entry in the allowance column, but will have in the description column a reference to the first appearance of the item. Items authorized for use as required but not for initial stockage are identified with an asterisk in the allowance column.

(2) The quantitative allowances for DS/GS levels of maintenance will represent initial stockage for a 30-day period for the number of equipments supported.

(3) Determination of the total quantity of parts required for maintenance of more than 100 of these equipments can be accomplished by converting the equipment quantity to a decimal factor by placing a decimal point before the next to last digit of the number to indicated hundredths, and multiplying the decimal factor by the parts quantity authorized in the 51-100 allowance column.

Example: authorized allowance for 51-100 equipments is 40; for 150 equipments multiply 40 by 1. or 60 parts required.

i. *One-Year Allowances Per 100 Equipments/Contingency Planning Purposes.* Indicates opposite the first appearance of each item the total quantity required for distribution and contingency planning purposes. The range of items indicates total quantities of all authorized items required to provide for adequate support of 100 equipments for 1 year.

j. *Depot Maintenance Allowance Per 100 Equipments.* Indicates opposite the first appearance of each item the total quantity authorized for depot maintenance of 100 equipments. Subsequent appearances of the same item will have no entry in this column, but will have in the description column a reference to the first appearance of the item. Items authorized for use but not for initial stockage are identified with an asterisk in the allowance column.

k. *Illustration.*

(1) *Figure Number.* Indicates the figure number of the illustration in which the item is shown.

(2) *Item number.* Indicates the callout number used to reference the item in the illustration.

4. Special Information

a. Repair parts mortality has been based on 1,500 hours of operation per year.

b. Parts which require manufacture or assembly at a category higher than that authorized for installation will indicate in the source column the higher category

5. Abbreviations

ar as required
 ft feet (foot)
 d inside diameter
 n inch (es)
 lg long (length)
 lg..... mounting
 N..... number (s)
 d outside diameter
 rl roll
 thd thread (ed) (s)

Code Manufacturer
 08288 Military Supply Standards
 12946..... Neilson Wheel Co.
 15605..... Cutler-Hammer, Inc.
 21335..... Fafnir Bearing Co., The
 27315..... Pawling and Harnischfeger Co.
 28250..... Heyan Mfg. Co.
 44655..... Ohmite Mfg. Co.
 55026..... Simpson Electric Co.
 59730..... Thomas and Betts Co.
 66289..... Wisconsin Motor Corp.
 70485..... Atlantic India Rubber Works, Inc.
 72962..... Elastic Stop Nut Corp. Of

America

6. Federal Supply Codes for Manufacturers

Code Manufacturer
 00761..... Burndy Midwest, Inc.
 00779..... Aircraft Marine Products, Inc.
 02295..... General Electric Co., General Purpose
 Control Department of Switch-gear
 and Control Division.
 04009..... Hart and Hegeman Mfg. Co.

79497..... Western Rubber Co.
 80756..... Ramsey Corp.
 81349..... Military Specifications
 82214..... National Carbon Co.
 83315..... Hubbel Corp.
 96906..... Military Standard Promulgated By
 Standardization Div. Directorate
 of
 Logistic Services DSA.
 98124..... Hunt Wilde Corp.

Section II. PRESCRIBED LOAD ALLOWANCE

(1) Federal Stock Number	(2) Description	Qty inc in unit pack	(3) 15-Day Org Maint. Alw			
			(A) 1-5	(B) 6-20	(C) 21-50	(D) 51-100
5977-423-5329	4403---BRUSH HOLDER ASSEMBLY BRUSH, ELECTRICAL: main (82214) 549	6	2	7	12	25
5977-588-4301	BRUSH, ELECTRICAL: exciter (27315) 273H3D1	1	*	2	2	4

Section III. REPAIR PARTS FOR ORGANIZATIONAL MAINTENANCE

(1) Source Maint. and recov. code			(2) Federal Stock Number	(3) Description	(4) Unit of issue	(5) Qty inc in unit pack	(6) Qty. inc. in unit	(7) 15-Day organizational maint. allowances				(8) Illustrations	
Source	Maint- enance	Recover- ability						(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(a) Fig. No.	(b) Item or Symbol No.
X2	0			GROUP 10- FRONT AXLE 1000- FRONT AXLE ASSEMBLY			1					14	3
X2	0			AXLE, FRONT (27315) 210H18D1			1					14	9
	0			FORK, SWIVEL: front axle (12946) 8-11X			1					14	8
	0			SCREW, CAP, HEXAGON: fork mounting (27315) 082V079			1					14	6
	0		5310-761-6882	NUT, PLAIN, HEXAGON: fork mtg screw (27315) 2145V005			1					14	7
	0			WASHER, LOCK: fork mtg screw (27315) 3616V011			1					14	5
X2	0			HANDLE, TOWING (27315) 206F8D1			1					14	18
X2	0			GRIP, HANDLE (98124) 1443R			2					14	21
X2	0			BAG, CLOTH (27315) 32264			1					14	1
X2			5340-598-1357	RING, RETAINING: front axle			2					14	

(1) Source Maint. and recov. code			(2) Federal Stock Number	(3) Description	(4) Unit of issue	(5) Qty inc in unit pack	(6) Qty. inc. in unit	(7) 15-Day organizational maint. allowances				(8) Illustrations	
Source	Maint- enance	Recover- ability						(a)	(b)	(c)	(d)	(a) Fig. No.	(b) Item or Symbol No.
								1-5	6-20	21-50	51-100		
X2	O			WASHER, FLAT front :axle (27315) 3682V008			4					14	2
M	O			CHAIN:handle retaining			1					14	20
P	O			MANUFACTURE FROM: CHAIN, WELDLESS (12 in. required)	FT.....		(SEE GROUP 9501)						
M	O			(00000) 42C15120-205 HOOKS: handle retaining chain			1					14	19
P	O		9505-186-9137	MANUFACTURE FROM: WIRE, STEEL, CARBON (08288) MSS9505-1	RL.....		(SEE GROUP 9501)						
X2	O			GROUP 11- REAR AXLE 1100 - REAR AXLE.ASSEMBLY									
X2	O			AXLE, REAR (27315) 210H18D2		1					14	16	
X2	O		5340-598-1357	RING, RETAINING: rear axle (80756) RR675			4					14	1
X2	O			WASHER, FLAT: rear axle (27315) 3682V008			8					14	2
X2	O			GROUP 13- WHEELS AND TRACKS 1311 - WHEEL ASSEMBLY									
X2	O			WHEEL, RUBBER TIRE: portable mount (12946) A118N			4					14	4
X2	O			GROUP 15- FRAME, TOWING ATTACHMENTS, AND DRAWBARS 1501 - FRAME ASSEMBLY									
X2	O			PORTABLE MOUNT ASSEMBLY (27315) 2100E147F26			1					14	
X2	O			FRAME: portable mount (27315) 216E93D5			1					14	17
X2	O			PLATE, INSTRUCTION : portable mount (27315) 232H96			1	(SEE GROUP 2210)					
X2	O		2990-310-7664	CLIP, SPRING: towing handle retaining (66289) PK87			1					14	13
	O		5305-988-1723	SCREW, MACHINE: clip mountin g			1					14	12
	O		5310-619-3555	NUT, PLAIN, HEXAGON: clip mtg screw			1					14	10
	O		5310-010-3319	WASHER, LOCK: clip mtg screw			1					14	11
M	O			GROUP 22- ACCESSORY ITEMS 2202 - ACCESSORY ITEMS									
P	O		6145-174-1123	CABLE ASSEMBLY: ground with clamp (27315) 9279F295-1	FT.....		AR	(SEE GROUP 9501)				20	1
X2	O			MANUFACTURE FROM: WIRE ELECTRICAL (50 ft required)			1						
X2	O			CLAMP, GUARD: ground cable (27315) 295Z2D3			2						
M	O			TERMINAL LUG: ground cable . (00779) 325405			1					20	3
P	O		6145-174-1123	CABLE ASSEMBLY: electrode, with holder (27315) 9279F296-2	FT.....		(SEE GROUP 9501)						
X2	O			MANUFACTURE FROM: WIRE, ELECTRICAL (50 it required)			1					20	4
X2	O			HOLDER, ELECTRODE: cable (00779) A38			2						
X2	O	R	3431-930-6003	TERMINAL, LUG: cable (00779) 325405			1					20	2
				RHEOSTAT ASSEMBLY: remote control (27315) 9279E150									

(1) Source Maint. and recov. code			(2) Federal Stock Number	(3) Description	(4) Unit of issue	(5) Qty inc in unit pack	(6) Qty. inc. in unit	(7) 15-Day organizational maint. allowances				(8) Illustrations	
Source	Maint- enance	Recover- ability						(a)	(b)	(c)	(d)	(a) Fig. No.	(b) Item or Symbol No.
								1-5	6-20	21-50	51-100		
X2	O			PLATE, INSTRUCTION: rheostat remote control (27315) 232H95			1	(SEE GROUP 2210)					
	O		5310-286-1495	SCREW, MACHINE: rheostat instruction plate mtg			2	(SEE GROUP 2210)					
	O		5310-010-3319	WASHER, LOCK: rheostat instruction plate mtg screw			2	(SEE GROUP 2210)					
X2	O			BRACKET: remote control cable tiedown (27315) 216H599			1					10	22
X2	O			HANGER, PLASTIC: remote control cable (00761) HPI0N			1					10	23
X2	O			STRAP: remote control cable (27315) 232H407			1					10	24
	O		5310-889-2606	NUT, PLAIN, WING: remote control cable tie-down. 2210- DATA PLATES			1					10	25
X2	O			PLATE, INSTRUCTION: rheostat remote control (27315) 232H95			1					17(2)	5
	O		5305-286-1495	SCREW, MACHINE: rheostat instruction plate mtg			2					17(2)	3
	O		5310-010-3319	WASHER, LOCK: rheostat instruction plate mtg screw.			2					17(2)	4
X2	O			PLATE, IDENTIFICATION: control panel (27315) 232E116			1					17(1)	65
X2	O			PLATE, IDENTIFICATION: remote control (27315) 232E397			1					17(1)	16
X2	O			PLATE, INSTRUCTION: terminal block (27315) 232H396			1					10	17
X2	O			PLATE, INSTRUCTION: portable mount assembly. (27315) 232H96			1					14	15
X2	O			PLATE, INSTRUCTION: welding operation (27315) 210SF70			1						
X2	O			PLATE, INSTRUCTION: wiring diagram (27315) 2101E501			1						
X2	O		9905-807-3712	PLATE, IDENTIFICATION: corps of engineers.			1						
	O		5305-207-5512	SCREW, MACHINE: plate mtg, round head . type A, No. 6 X 3/8 in. lg.			18						
	O		5305-286-1495	SCREW, MACHINE: control panel nameplate			6						
	O		5310-275-1706	NUT, PLAIN, HEXAGON: control panel nameplate.			6						
	O		5310-010-6495	WASHER, LOCK: control panel nameplate (96906) MS35338-3			6						
	O		5305-253-5620	SCREW, DRIVE: portable mount instruction plate.			2					14	14
				GROUP 44 - WELDING EQUIPMENT 4403 -- BRUSH HOLDER ASSEMBLY									
P	O		5977-423-5329	BRUSH, ELECTRICAL: main (minimum stockage of 6 is authorized). (82214) 549			6	2	7	12	25	19	52
P	O		5977-588-4301	BRUSH, ELECTRICAL: exciter (27315) 273H3D1			1	*	2	2	4	19	46
	O		5977-588-4301	brush mtg screw (96906) MS35338-6			8					19	29
	O		5305-988-1723	SCREW, MACHINE: brush holder mtg (08288) MSS5305-14			8					19	44

(1) Source Maint. and recov. code			(2) Federal Stock Number	(3) Description	(4) Unit of issue	(5) Qty inc in unit pack	(6) Qty. inc. in unit	(7) 15-Day organizational maint. allowances				(8) Illustrations	
Source	Maint- enance	Recover- ability						(a)	(b)	(c)	(d)	(a) Fig. No.	(b) Item or Symbol No.
								1-5	6-20	21-50	51-100		
				4405- FRAME SUPPORT, HOUSING, CARIRER									
X2	O			COVER ASSEMBLY: housing top (27315) 227F423			1					10	3
X2	O			INSULATION (27315) 275H92D2			4					10	7
X2	O			DOOR, ACCESS: generator inspection (27316) 227H51			1					10	19
X2	O			TIE ROD: bearing housing (27315) 220H57			4					19	41
X2	O			SPACER: housing tie rod (27315) 218H129								19	39
X2	O			COUPLING: tie rod spacer (27316) 0928V004			4					19	40
X2	O			NUT, LOCK: tie rod spacer (27315) 0944V003			4					19	42
X2	O			WASHER, "C": tie rod (27315) 218H97								19	38
X2	O			WASHER, SPECIAL: air tube to tie rod screw (27316) 218H98D1			8					19	7
X2	O			DOOR ASSEMBLY: cable terminal (27315) 279H255D2			1					10	
X1				DOOR (27315) 279F160			1					10	12
X1				BUMPER, RUBBER (70486) 829			2					10	18
M	O			BRACKET: mounting			2					19	86
P	O		9520-517-0534	MANUFACTURE FROM: ANGLE STEEL (24 in. required for each BRACKET)	FT			(SEE GROUP 90D1)					
	O		5305-068-0502	SCREW, CAP, HEXAGON HEAD: housing to mtg angle.			6					19	87
	O		5310-010-3319	WASHER, LOCK: housing to mtg angle screw (96906) MS36338-6			6					19	88
	O		5310-619-3556	NUT, PLAIN, HEXAGON: housing to mtg angle screw. (08288) MSS5310-9			6					19	89
	O		5305-068-0502	SCREW, CAP, HEXAGON HEAD: angle to base plate.			2					19	90
	O		5310-010-3323	WASHER, LOCK: angle to be plate screw			2					19	91
	O		5310-202-8552	NUT, PLAIN, HEXAGON: angle to base plate screw.			2					19	92
	O		5306-988-1723	SCREW, MACHINE: cover to panel			13					10	1
	O		5310-010-3319	WASHER, LOCK: cover to panel screw (96906) MS35338-6 4407 - CONTROL PANELS, HOUSING			13					10	2
X2	O			SHUNT (27315) 86223D3 19 84			1					19	84
X2	O			GUARD, CABLE (27315) 2164614			1					10	16
	O		5310-877-5797	NUT, SELF-LOCKING: cable guard (72962) 22NM02 4408- CONNECTING DEVICES			8					10	14
X2	O			RECEPTACLE, ELECTRICAL: remote control. (83315) 7410GT			1					17(1)	14
	O		5305-010-0737	SCREW, MACHINE: receptacle mtg			2					17(1)	12
	O		5310-010-6495	WASHER, LOCK: receptacle mtg screw			2					17(1)	13
	O		5305-988-1727	SCREW, MACHINE: junction block (08288) MSS5305-14			2					17(1)	19

(1) Source Maint. and recov. code			(2) Federal Stock Number	(3) Description	(4) Unit of issue	(5) Qty inc in unit pack	(6) Qty. inc. in unit	(7) 15-Day organizational maint. allowances				(8) Illustrations	
Source	Maint- enance	Recover- ability						(a)	(b)	(c)	(d)	(a) Fig. No.	(b) Item or Symbol No.
								1-5	6-20	21-50	51-100		
	O		5310-619-3555.....	NUT PLAIN,HEXAGON: junction block screw (08288) MSS5310-9			2					17(1)	20
X2	O		5604-983-6115.....	TERMINAL BOARD (08288) MSS6940-1			1					17(1)	18
X2	O			TERMINAL ASSEMBLY: welding cables (27315) 9279H25F2			1					17(1)	22
X2	O			TERMINAL (27315) 279H230			1					17(1)	27
	O		5305-637-7782.....	SCREW, MACHINE: cable connecting			2					17(1)	24
	O		5310-816-1030.....	NUT, PLAIN, HEXAGON: cable screw			2					17(1)	23
M	O		5310-010-3131.....	NUT, PLAIN, WING:-cable connecting			2					17(1)	22
	O			CABLE ASSEMBLY: jumper (27315) 279F239D151			1					17(1)	25
P	O		6145-174-1123.....	MANUFACTURE FROM: WIRE, ELECTRICAL (16 in. required)	FT.....			(SEE GROUP 9501)					
X2	O		5940-976-0904.....	TERMINAL, LUG: jumper cable (00761) YAV276			1						
X2	O		5940-976-0903.....	TERMINAL, LUG: jumper-cable (00761) YAV2761			1						
	O			GROUP 95- GENERAL USE STANDARDIZED PARTS 9501 - BULK MATERIAL									
P	O			CHAIN, WELDLESS (00000) 42C165120=206	FT.....			*	*	*	*		
P	O		9505-186-9137.....	WIRE, STEEL, CARBON (08288) MSS9506-1	RL.....			*	*	*	*		
P	O		6145-174-1123.....	WIRE, ELECTRICAL	FT.....			*	*	*	*		
P	O		9520-517-0534.....	ANGLE. STEEL	FT.....			*	*	*	*		

Section IV. REPAIR PARTS LIST FOR DS, GS, AND DEPOT MAINTENANCE

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC. IN UNIT PACK	(6) QTY. INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCTY	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION	
	(a)	(b)	(c)						(a)	(b)	(c)	(a)	(b)	(c)			(a)	(b)
	S	M	R						1-20	21-50	51-100	1-20	21-50	51-100			FIGURE NO.	ITEM NO/
	Manufacturer's																	
		Code	Part No.															
X2	O				1000- FRONT AXLE ASSEMBLY AXLE, FRONT			1								14	3	
X2	O				(27315) 210H18D1 FORK, SWIVEL: front axle			1								4	9	
	O				(12946) 8-IIX SCREW, CAP, HEXAGON: fork mounting			1								14	8	
	O		5310-761-6882		(27315) 0826V079 NUT, PLAIN, HEXAGON: fork mtg. Screw			1								14	6	
	O				(27315) 2145V005 WASHER, LOCK: fork mtg. Screw			1								14	7	
X2	O				(27315) 3616V011 HANDLE, TOWING			1								14	5	
X2	O				(27315) 206F8D1 GRIP, HANDLE			2								14	18	
X2	O				(98124) 1443R BAG, CLOTH			1								14	21	
X2	O		5340-598-1357		(27315) 32264 RING, RETAINING: front axle			2								14	1	
X2	O				(80756) RR675 WASHER, FLAT: front axle			4								14	2	
M	O				(27315) 3632V008 CHAIN: handle retaining			1								14	20	
					MANUFACTURE FROM: CHAIN, WELDLESS	FT			(SEE GROUP 9501)									
					(12 in. required). (00000) 42C1512o0-205													
M	O				HOOKS: handle retaining chain			1								14	19	
P	O		9505-186-9137		MANUFACTURE FROM: WIRE, STEEL, CARBON	RL			(SEE GROUP 9501)									
					(6 in. required). (08288) MSS9505-1													
X2	O				GROUP 11 -REAR AXLE 1100 -REAR AXLE ASSEMBLY			1								14	16	
X2	O		5340-598-1357		(27315) 210H18D2 RING, RETAINING: rear axle			4								14	1	
X2	O				(80756) RR676 WASHER, FLAT: rear axle			8								14	2	
					(27315) 363V008													

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC. IN UNIT PACK	(6) QTY. INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCY	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION	
	(a)	(b)	(c)						(a)	(b)	(c)	(a)	(b)	(c)			(a)	(b)
	S	M	R						1-20	21-50	51-100	1-20	21-50	51-100			FIGURE NO.	ITEM NO/
	Manufacturer's																	
Code		Part No.																
X2	O			GROUP 13- WHEELS AND TRACKS 1311 - WHEEL ASSEMBLY WHEEL, RUBBER TIRE: portable mount (12946) A118N			4									14	4	
X2	O			GROUP 15--FRAME, TOWING ATTACHMENTS, AND DRAWBARS 1501 -- FRAME ASSEMBLY PORTABLE MOUNT ASSEMBLY (27315) 2100E147F26			1									14		
X2	O			FRAME: portable mount (27315) 216E93D5			1									14	17	
X2	O			PLATE, INSTRUCTION: portable mount assembly (27315) 232H96			1	(SEE GROUP 2210)										
X2	O		2990-310-7664	CIP, SPRING: towing handle retaining (66289) PK87			1									14	13	
	O		5305-988-1723	SCREW, MACHINE: clip mounting			1									14	12	
	O		5310-619-3555	NUT, PLAIN, HEXAGON: clip mtg. Screw			1									14	10	
	O		5310-010-3319	WASHER, LOCK: clip mtg screw			1									14	11	
M	O			GROUP 22 -- ACCESSORY ITEMS 2202 - ACCESSORY ITEMS CABLE ASSEMBLY: ground with clamp (27315) 9279F295-1 MANUFACTURE FROM			1									20	1	
P	O		61456-174-1123	WIRE, ELECTRICAL (50 ft. required).	FT			(SEE GROUP 9501)										
X2	O			CLAMP, GUARD: ground cable (27315) 29522D3			1											
X2	O			TERMINAL, LUG: ground cable (00779) 325405			2											
M	O			CABLE ASSEMBLY: Electrode, with holder (27315) 9279F296-2 MANUFACTURE FROM:			1									20	3	
P	O		6145-174-1123	WIRE, ELECTRICAL (50 ft required).	FT			(SEE GROUP 9501)										
X2	O			HOLDER, ELECTRODE: cable (00779) A38			1									20	4	
X2	O			TERMINAL, LUG: cable (00779) 325405			2											
X2	OR		3431-930-6003	RHEOSTAT ASSEMBLY: remote control (27315) 9279E150			1									20	2	
X2	F		5905-646-7687	RHEOSTAT: remote control (44655) 40513			1									17 (2)	18	

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY INC. IN UNIT PACK	(6) QTY. INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCV	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION	
	(a) S	(b) M	(c) R						(a)	(b)	(c)	(a)	(b)	(c)			(a)	(b)
									1-20	21-50	51-100	1-20	21-50	51-100			FIGURE NO.	ITEM NO/
X2	F				CABLE ASSEMBLY: remote control (27315) 279H421			1										
X1			6145-734-4554		WIRE, ELECTRICAL: No. 14-3 (51 ft required) (81349) MILC3432B	FT											17 (2)	24
X1					TERMINAL, LUB: remote control cable (00779) 41332			1									17 (2)	22
X1					TERMINAL, LUG: remote control cable (00779) 41333			1									17 (2)	23
X1					PLUG, ELECTRICAL: remote control cable (04009) 7411			1									17 (2)	21
X2	F		5935-062-6124		CLAMP, CABLE, ELECTRICAL: remote control (59730) 3303			1									17 (2)	19
X2	F				HANDLE: rheostat control (27315) 206H15D1			1									17 (2)	2
X2	F				PIN, ROLL: handle mtg (72962) 59-028-125-625			1									17 (2)	1
X2	F				PLATE, JUMPER: rheostat (27315) 279H251D1			1									17 (2)	17
X2	O				PLATE, INSTRUCTION: rheostat remote control (27315) 232H95			1	(SEE GROUP 2210)									
X2	F				COVER: rheostat (27315) 214F250D01			1									17 (2)	12
X2	F				HOUSING: rheostat (27315) 214H89			1									17 (2)	20
X2	F				COVER, BOTTOM: rheostat (27315) 214H90			1									17 (2)	13
	O		5310-286-1495		SCREW, MACHINE: rheostat instruction plate mtg			2	(SEE GROUP 2210)									
	O		5310-010-3319		WASHER, LOCK: rheostat instruction plate mtg screw			2	(SEE GROUP 2210)									
	F		5310-202-8549		SPEEDNUT: housing cover screw			8									17(2)	11
	F		5305-879-7941		SCREW, THREAD FORMING: housing cover			8									17(2)	10
	F		3815-425-7821		WASHER, FLAT: rheostat housing cover.			9									17(2)	7
	F		5305-984-6193		SCREW, MACHINE: plate mtg			3									17	1
	F		5310-050-3568		NUT, PLAIN, HEXAGON: plate mtg			3									17(2)	15
	F		5310-010-6496		WASHER, LOCK: plate mtg screw			3									17(2)	16
	F		5305-989-7434		SCREW, MACHINE: rheostat cover mtg			1									17(2)	6
	F		3815-425-7821		WASHER, LOCK: rheostat assembly.			1									17(2)	9
	F		5310-012-0614		NUT, PLAIN, HEXAGON: rheostat assembly.			1									17(2)	8
X2	O				BRACKET: remote control cable tie-down (27315) 216H599			1									10	22
X2	O				HANGER, PLASTIC: remote control cable (00761) HP10N			1									10	23

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION Manufacturer's Code Part No.	(4) UNIT OF ISSUE	(5) QTY INC. IN UNIT PACK	(6) QTY. INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCY	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION		
	(a)	(b)	(c)						(a)	(b)	(c)	(a)	(b)	(a)			(b)		
	S	M	R						1-20	21-50	51-100	1-20	21-50	100			100	FIGURE NO.	ITEM NO/
X2	O			STRAP: remote control cable (27315) 232H407			1									10	24		
	O		5310-889-2606	NUT, PLAIN, WING: remote control cable tie-down 2210 - DATA PLATES			1									10	25		
X2	O			PLATE, INSTRUCTION: rheostat remote control (27315) 232H95			1									17	5		
	O		5305-286-1495	SCREW, MACHINE: rheostat instruction plate mtg			2									17(2)	3		
	O		5310-010-3319	WASHER, LOCK: rheostat instruction plate mtg, screw			2									17(2)	4		
X2	O			PLATE, IDENTIFICATION: Control panel (27315) 232E116			1									17	65		
X2	O			PLATE, IDENTIFICATION: remote control (27315) 232E397												17	16		
X2	O			PLATE, INSTRUCTION: terminal block (27315) 232H396			1									(1)	17		
X2	O			PLATE, INSTRUCTION: portable mount assembly (27315) 232H96			1									14	15		
X2	O			PLATE, INSTRUCTION: welding operation (27315) 2105F70			1												
X2	O			PLATE, INSTRUCTION: wiring diagram (27315) 2101E501			1												
X2	O		9905-807-3712	PLATE, IDENTIFICATION: Corps of Engineers			1												
	O		5305-207-5512	SCREW, MACHINE: plate mtg, round head, Type A No. 6 x 3/8 in. lg.			18												
	O		5305-286-1495	SCREW, MACHINE: control panel nameplate			6												
	O		5310-275-1706	NUT, PLAIN, HEXAGON: control panel nameplate			6												
	O		5310-010-6495	WASHER, LOCK: control panel nameplate (96906) MS35338-3			6												
	O		5305-253-5620	SCREW, DRIVE: portable mount instruction plate GROUP 44 - WELDING EQUIPMENT			2									14	14		
X2	H			4401 - ROTOR ASSEMBLY ROTOR ASSEMBLY (27315) 274H7D2			1									19	17		
X1				CASTING, ROTOR (27315) 274E3D2			1												
X2	H	U	5310-164-8848	WASHER, FLAT: rotor ARMATURE ASSEMBLY: rotor (27315) 2100F43			1									19	43		
X2	F			FAN: armature cooling (27315) 274E2			1									19	23		
X2	F			COVER, DUST: bearing housing (27315) 214H39			1									19	33		

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION Manufacturer's Code Part No.	(4) UNIT OF ISSUE	(5) QTY UNIT OF MEAS	(6) INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCTY	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION												
	(a) S	(b) M	(c) R						(a)	(b)	(c)	(a)	(b)	(c)			(a)	(b)	(c)	(a)	(b)								
																						1-20	21-50	51-100	1-20	21-50	51-100	FIGURE NO.	ITEM NO/
X2	H				WASHER, FLAT: armature shaft drive end (27315) 218H98D3		1									19	13												
X2	H				SPACER: armature shaft drive end (27315) 218H108D2		1									19	14												
X2	H				KEY, MACHINE: rotor to armature shaft (27315) 20H138D15		1									19	24												
	H		5306-299-2366		BOLT, MACHINE, HEXAGON HEAD: armature shaft drive end		1									19	11												
X2	H				KEY, SQUARE: fan mounting, .246 in. to .252 in., 1 1/8 in. Lg (27315) 20H138D13		1									19	25												
	H		5310-261-734		WASHER:, LOCK: armature shaft, drive end (96906) MS36338-8		1									19	12												
X2	F				HOUSING: armature shaft bearing, commutator end (27315) 272E5 4402- STATOR ASSEMBLY		1									19	37												
X2	H				STATOR, ASSEMBLY (27315) 9271H1		1									19	16												
X2	H	R			FRAME AND FIELD: magnet (27315) 9271E4F3 X1 FRAME: magnet 1 19 83 (27315) 271A3D4		1									19	83												
X1	H				COIL, COMMUTATOR (27315) 9275F103F4		2									19	79												
X2	H				POLE PIECE: main, No. (27316) 271F7D2		1									19	66												
X2	H				POLE PIECE: main, No.2 (27316) 271F7D1		1									19	75												
X2	H				POLE PIECE: cross, No. (27315) 271F7D3		1									19	80												
X2	H				POLE PIECE: cross, No. (27315) 271F7D4		1									19	74												
X2	H				INSULATION: magnet frame (27315) 275H72D1		4									19	60												
X2	H				INSULATION: magnet frame (27315) 275H72D2		4									19	81												
X2	H				INSULATION: magnet frame (27315) 275H71D1		8									19	61												
X2	F				COIL ASSEMBLY, MAIN (27315) 9275F96		1									19	65												
X2	F				TERMINAL LUG: coil lead (00761) YAV14T4		1									19	64												

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY UNIT OF MEAS	(6) INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCV	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION					
	(a) S	(b) M	(c) R						Manufacturer's		(a)	(b)	(c)	(a)			(b)	(c)	(a)	(b)	(a)	(b)
									Code	Part No.												
X2	F				COIL: cross field, No. 1 (27315) 9275E134			1									19	82				
X2	F		5940-243-0404		TERMINAL, LUG: coil lead (00761) YAV14			1									19	56				
X2	F				COIL: cross field, No. 2 (27315) 9275E140			1									19	73				
X2	F		5940-155-7630		TERMINAL, LUG: coil lead (00761) YAV14			1									19	72				
X2	F				CLAMP: coil retaining (27315) 275H76			4									19	76				
X2	F				COLLAR: commutator coil (27315) 9275H7F1			4									19	78				
X2	F				CLAMP: reactor core and coil lead (27315) 232H248			1									19	59				
X2	F				SCREW, MACHINE: clamp mtg (27315) 202325D88			6									19	58				
X2	F				COIL, REACTOR (27315) 9280F2F3			1									19	57				
X2	F		5940-243-0404		TERMINAL, LUG: reactor coil lead (00761) YAV14			1									19	56				
X2	F		5940-230-9911		CONNECTOR, ELECTRICAL WIRING (00779) 34138			3									19	63				
X2	F				SLEEVE, INSULATION: electrical wiring (27315) 851			3									19	62				
X2	F		6150-603-1567		BUS BAR: commutator coil (27315) 27911253D33			4									19	77				
X2	F				BUS BAR: magnet frame and field (27315) 279H254D1			1									19	71				
X2	F				SLEEVE, INSULATION: bus bar (27315) 275H86D15			1									19	70				
	F		5310-010-3323		WASHER, LOCK: reactor coil mtg screw (96906) MS35338-10			1									19	55				
	F		5305-071-1774		SCREW, CAP, HEXAGON HEAD: reactor coil mtg (96906) MS35295-121			1									19	54				
	F		5305-275-9123		SCREW, MACHINE: bus bar and lead mtg (08288) MSS5305-15			12									19	67				
	F		5310-021-9431		NUT, PLAIN. HEXAGON: bus bar and lead screw (08288) MSS5310-9			12									19	68				
	F		5310-010-3320		WASHER: LOCK: bus bar and lead screw (96906) MS35338-7			12									19	69				

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY OF MEAS	(6) INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCY	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION			
	(a) S	(b) M	(c) R						Manufacturer's		(a) 1-20	(b) 21-50	(c) 51-100	(a) 1-20			(b) 21-50	(c) 51-100	(a) FIGURE NO.	(b) ITEM NO/
									Code	Part No.										
X2	F				4403 -BRUSH HOLDER ASSEMBLY HOLDER, BRUSH: main (27315) 273F4D2			2									19	53		
X2	F				HOLDER, BRUSH: exciter (27315) 273F5			1									19	47		
P	F		5977-227-6503		SPRING, TENSION: main brush (27315) 17ZI22			6	2	2	3	2	2	3		30	19	51		
P	F		5977-227-6501		SPRING, TENSION: exciter brush (27315) 17ZI23			1	*	2	2	*	2	2		20	19	45		
P	O		5977-423-5329		BRUSH, ELECTRICAL: main (minimum stockage of 6 is authorized) (82214) 549			6	12	26	50	12	26	50		600	19	52		
P	O		5977-588-4301		BRUSH, ELECTRICAL: exciter (27315) 273H3D1			1	2	4	8	2	4	8		100	19	46		
	O		5310-010-3319		WASHER, LOCK: Brush holder mtg screw (96906) MS35338-6			8									19	29		
	O		5305-988-1723		SCREW, MACHINE: brush holder mtg (08288) MSS5305-14			8									19	44		
X2	H				4405--FRAME SUPPORT, HOUSING, CARRIER GIRDLE, BEARING: generator end (27315) 232H235			1									19	36		
X2	H				SLEEVE, BEARING: generator end (27315) 225H2D2			1									19	35		
P	H		3110-198-1975		BEARING, BALL: generator end (21335) W305PP			1				*	*	2		10	19	34		
P	H		3110-227-4110		BEARING, BALL: motor end (21335) W309PP			1				*	*	2		10	19	20		
X2	H				SLEEVE, BEARING: motor end (27315) 225H3			1									19	21		
X2	H				GIRDLE, BEARING: motor end (27315) 232H237			1									19	22		
X2	H				BASEPLATE: welding unit mounting (27315) 216H326D1			1									19	85		
X2	H				PLATE ASSEMBLY: lifting (27315) 229H98			1									10	6		
X2	H				SEAL, RUBBER: lifting plate (27315) 218H174D3			1									10	11		
X2	F				PANEL ASSEMBLY: housing back cover (26315) 9227F19F4			1									10			
X2	F				PANEL: housing back cover (27315) 227F159D8			1									10	8		

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION Manufacturer's Code Part No.	(4) UNIT OF ISSUE	(5) QTY UNIT OF MEAS	(6) INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCY	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION												
	(a) S	(b) M	(c) R						(a)	(b)	(c)	(a)	(b)	(c)			(a)	(b)	(c)	(a)	(b)								
																						1-20	21-50	51-100	1-20	21-50	51-100	FIGURE NO.	ITEM NO/
X2	F			INSULATION: rear panel (27315) 275H92D1			1									10	9												
X2	F			PLATE ASSEMBLY: housing end cover (27316) 227H53F1			2									10													
X2	F			PLATE: housing end cover (27315) 227H54D1			1									10	10												
X2	F			SEAL, RUBBER: housing end cover (27315) 218H107D1			4									10	21												
X2	O			COVER ASSEMBLY: housing top (27315) 227F423			1									10	3												
X2	O			INSULATION 4 (27315) 275H92D2			4									10	7												
X2	O			DOOR, ACCESS: generator inspection (27315) 227H51			1									10	19												
X2	O			TIE ROD: bearing housing (27315) 220H57			4									19	41												
X2	O			SPACER: housing tie rod (27315) 218H129			4									19	39												
X2	O			COUPLING: tie rod spacer (27315) 0928V004			4									19	40												
X2	O			NUT, LOCK: tie rod spacer (27315) 0944V003			4									19	42												
X2	O			WASHER "C": Tie rod (27315) 218H197			8									19	38												
X2	F			SPACER: stator to air tube (27315) 218H108D1			4									19	15												
X2	O			WASHER, SPECIAL: air tube to tie rod screws (27315) 218H98D1			8									19	7												
	F		5306-722-8450	BOLT, MACHINE: stator to air tube			4									19	5												
	F		5305-044-4153	BOLT, MACHINE: bearing housing to air tube			4									19	26												
	F		5310-010-3323	WASHER, LOCK: air tube bolt (96906) MS35338-10			8									19	6												
	F		5306-021-3665	BOLT, MACHINE: generator			6									19	28												
	F		5310-164-8848	WASHER, FLAT: generator bolt			6									10	2												
	F		5305-013-2723	SCREW, MACHINE			2									17	66												
	F		5310-275-1706	NUT, PLAIN, HEXAGON			2									17(1)	66												
	F		5310-275-1706	NUT, PLAIN, HEXAGON			2									17(1)	67												
	F		5310-010-3320	WASHER, LOCK			15									10	5												
X2	F			SCREW, THREAD CUTTING: 5/16-18thd size. ¾ in. Lg (27315) 20Z632D2			7									10	4												
X2	F			SCREW, THREAD CUTTING: 5-/16-18thd size. 11/8l in. lg (27315) 20Z630D5			2																						

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY UNIT OF MEAS	(6) QTY INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCY	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION		
	(a) S	(b) M	(c) R						(a)	(b)	(c)	(a)	(b)	(c)			(a)	(b)	
	Manufacturer's Code		Part No.						1-20	21-50	51-100	1-20	21-50	51-100			FIGURE NO.	ITEM NO/	
X2	F			5305-276-9123	SCREW, CAP, HEXAGON HEAD			6									17(1)	71	
	F			5310-021-9431	NUT, PLAIN, HEXAGON			6									17(1)	69	
	O				DOOR ASSEMBLY: cable terminal (27315) 279H255D2			1									10		
X1				DOOR (27315) 279F160			1										10	12	
X1				5340-684-6566	BUMPER, RUBBER (70485) 829			2									10	13	
M	O				BRACKET: mounting			2									19	86	
P	O			9520-517-0534	MANUFACTURE FROM: ANGLE, STEEL (24 in. required for each BRACKET)	FT			(SEE GROUP 9501)										
	O			5305-068-0502	SCREW, CAP, HEXAGON HEAD: housing to mtg angle			6									19	87	
	O			5310-010-3319	WASHER, LOCK: housing to mtg angle screw (96906) MS35338-6			6									19	88	
	O			5310-619-3555	NUT, PLAIN HEXAGON: housing to mtg angle screw (08288) MSS5310-9			6									19	89	
	O			5305-068-0502	SCREW, CAP, HEXAGON HEAD: angle to base plate			2									19	90	
	O			5310-010-3323	WASHER, LOCK: angle to base plate screw			2									19	91	
	O			5310-202-8552	NUT, PLAIN, HEXAGON: angle to base plate screw			2									19	92	
	O			5305-988-1723	SCREW, MACHINE: cover to panel			13									10	1	
	O			5310-010-3319	WASHER, LOCK: cover to panel screw (96906) MS35338-6			13									10	2	
	X2	F			4406- VENTILATING, COOLING SYSTEM BAFFLE: air tube, meter end (27315) 227H58			1									19	10	
	X2	F			5320-528-3304	RIVET: air tube baffle (08288) MSS5320-1			10										
		F				HOUSING: ventilating fan (27315) 272A3D1			1									19	18
X2	F				SEAL: fan housing (27315) 218H103D2			1									19	19	
X2	F				TUBE, AIR: generator end (27315) 227H55			1									19	27	
X2	F				TUBE ASSEMBLY, AIR: meter end (27315) 9227H2F6			1									19	8	
X2	O				4407- CONTROL PANELS, HOUSING SHUNT (27315) 86223D3			1									19	84	
X2	F	R			PANEL ASSEMBLY, CONTROL (27315) 9279F296			1											

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION Manufacturer's Code Part No.	(4) UNIT OF ISSUE	(5) QTY UNIT OF MEAS	(6) INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCTY	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION			
	(a) S	(b) M	(c) R						(a)	(b)	(c)	(a)	(b)	(c)			(a)	(b)	(a)	(b)
X2	F				PANEL: front, housing and control (27315) 279F159D1C			1									10	20		
	F		5305-013-2900		SCREW, MACHINE: panel mtg			2									17(1)	53		
X2	F		3815-425-7821		WASHER, LOCK: panel mtg			2									17(1)	54		
	F		5305-988-1721		SCREW, MACHINE: panel mtg (08288) MSS5305-14			4									17	52		
	F		5310-010-3319		WASHER, LOCK: panel mtg			6									17(1)	21		
X2	F				BUSHING: control panel (28520) S8875-6			1									17	17		
	O				GUARD, CABLE (27315) 2164614			1									10	16		
	O		5310-877-5797		NUT, SELF-LOCKING: cable guard (72962) 22NM02			8									10	14		
X2	F				MOUNT ASSEMBLY: meter (27315) 9279H376			1												
X2	F				PLATE: meter mounting (27315) 279H422			1									17	6		
					WASHER, "C"			1									17(1)	10		
X1					RIVET			1									17(1)	15		
X1	F		6625-736-8586		VOLTMETER (55026) 125-100VDC			1	*	*	*	*	*	2		6	17	8		
P	F		6625-736-8585		AMMETER (55026) 125-400ADC			1	*	*	*	*	*	2		6	17	9		
	F				GROMMET: mtg plate (79497) G1006			4									17	5		
X2	F				SCREW, MACHINE: meter to panel			6									17(1)	7		
	F		5310-010-6495		WASHER, LOCK: meter mtg screw (96906) MS35338-3			6												
	F		5310-275-1706		NUT, PLAIN, HEXAGON: meter mtg screw (96906) MS35649-61			6												
	F		5310-877 5797		NUT, SELF-LOCKING: meter plate screw (96906) MS23365-1032A			4									17	4		
	F		5305-993-1848		SCREW, MACHINE: meter plate mtg (0828.8) M.SS5305-33			4									17	1		
	F		3815 425-7821		WASHER, LOCK: plate mtg screw			8									17(1)	2		
X2	F				SPACER: meter plate (27315) 218H166			4									17	3		
	F				RECEPTACLE ELECTRICAL: remote control (83315) 7410GT			1			(SEE GROUP 4408)						17	14		
X2	F		5310-786-3999		WASHER, LOCK: cable guard			2									10	15		

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION Manufacturer's Code Part No.	(4) UNIT OF ISSUE	(5) QTY UNIT OF MEAS	(6) INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCY	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION	
	(a)	(b)	(c)						(a)	(b)	(c)	(a)	(b)	(c)			(a)	(b)
	S	M	R						1-20	21-50	51-100	1-20	21-50	51-100			FIGURE NO.	ITEM NO/
X2	O				4408 -CONNECTING DEVICES RECEPTACLE, ELECTRICAL: remote control (83315) 7410GT			1								17	14	
	O		5305-010-0737		SCREW, MACHINE: receptacle mtg			2								17(1)	12	
	O		5310-010-6495		WASHER, LOCK: receptacle mtg screw			2								17(1)	13	
	O		5305-988-1727		SCREW, MACHINE: junction block (08288) MSS5305-14			2								17	19	
	O		5310-619-3555		NUT, PLAIN, HEXAGON: junction block screw (08288) MSS5310-9			2								17	20	
	F		5305-275-9123		SCREW, MACHINE: bus bar mtg (08288) MSS5305-15			3								17	50	
	F		5310-021-9431		NUT, PLAIN, HEXAGON: bus bar mtg crew (08288) MSS6310-9			3								17	48	
	F		5310-010-3320		WASHER, LOCK: bus bar mtg screw (96906) MS35338-7			3								17	49	
X2	O		5940-983-6116		TERMINAL BOARD (08288) MSS5940-1			1								17	18	
X2	O				TERMINAL ASSEMBLY: welding cables (27315) 9279H25F2			1								17	22	
X2	O				TERMINAL (27315) 279H230			1								17	27	
X2	F				BUS BAR (27316) 279H239			1								17	26	
	O		5305-637-7782		SCREW, MACHINE: cable connecting			2								17(1)	24	
	O		5210-816-1030		NUT, PLAIN, HEXAGON: cable screw			2								17(1)	23	
	O		5310-010-3131		NUT, PLAIN, WING: cable connecting			2								17(1)	22	
M	O				CABLE ASSEMBLY: jumper (27315) 279F239D151			1								17	25	
P	O		6145-174-1123		MANUFACTURE FROM: WIRE ELECTRICAL (16 in. required)	FT			(SEE GROUP 9501)									
X2	O		5940-976-0904		TERMINAL LUG: jumper cable (00761) YAV276			1										
X2	O		5940-976-0903		TERMINAL LUG: jumper cable (00761) YAV27LI			1										
X2	F				BUS BAR: selector switch (27315) 279H256			1								17	51	
X2	F				BUS BAR: rheostat (27315) 279H251DI			1								17	58	
	F		5310-208-4072		NUT, PLAIN, HEXAGON: rheostat bus bar screw			2								17(1)	56	
	F		5305-275-9123		SCREW, MACHINE: rheostat bus bar mtg			2								17(1)	55	
	F		5310-010-6496		WASHER, LOCK: rheostat bus bar screw (96306) MS35338-4			2								17	57	

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY UNIT OF MEAS	(6) INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCY	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION			
	(a) S	(b) M	(c) R						Manufacturer's		(a) 1-20	(b) 21-50	(c) 51-100	(a) 1-20			(b) 21-50	(c) 51-100	(a) FIGURE NO.	(b) ITEM NO/
									Code	Part No.										
X2	F				BUS BAR: generator 2 (27315) 279H253D24			2								19	50			
	F		5306-225-9497		BOLT, MACHINE: bus bar mtg (27315) 20T5439D1			4								19	48			
	F		5310-010-3320		WASHER, LOCK: bus bar mtg			4								19	49			
X2	F				BUS BAR: selector switch (27315) 279H258			1								17	72			
	F		5305-275-9123		SCREW, CAP, HEXAGON HEAD: bus bar mtg			1								(1)	7			
	F		5310-21-9431		NUT, PLAIN, HEXAGON: bur bar mtg screw			1								17(1)	69			
	F		5310-010-3320		WASHER, LOCK: bus bar mtg screw 4409 - PROTECTIVE DEVICES, ELECTRICAL			1								17(1)	70			
X2	F				PLATE, INSULATION: brush holder (27315) 275H84			3								19	32			
X2	F				INSULATION: control panel (27315) 275H92D1			1								10	9			
X2	F				BUSHING, INSULATION: control panel (27315) 275H83			1								10	18			
X2	F				4410 - SWITCHING CONTROL HANDLE, TAP SWITCH (27315) 206F3D3			1								17	62			
X2	F				HANDLE, REVERSING SWITCH (27315) 206F4D2			1								(1)	29			
X2	F		5315-814-3531		PIN, SPRING: handle retaining (08288) MSS5315-9			1								(1)	28			
P	F		5930-227-6507		SWITCH ASSEMBLY, REVERSING SELECTOR (27315) 2100F46 (Same as Switch Assembly, stock No. 5930-227-6508, except where individual components are annotated)			1	*	*	*	*	*	*		5	17			
																(1)				
P	F		5930-227-6508		SWITCH ASSEMBLY SELECTOR (27315) 2100F48			1	*	*	*	*	*	*		5	17			
																(1)				
X1					PLATE: back, reversing switch (27315) 279H242D1 (Used on Switch Assembly, stock No. 5930-227-6507 only)			1								17	44			
																(1)				
X1					PLATE: front selector switch (27315) 279H241			1								17	38			
																(1)				
X1					PLATE: back selector switch (27315) 279H242D2 (Used on Switch Assembly, stock No. 593-227-6508 only).			1								17	63			
																(1)				
X1					INSULATOR: switch shaft (27315) 279H243			5								17	41			
																(1)				

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION	(4) UNIT OF ISSUE	(5) QTY OF MEAS	(6) INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCV	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION			
	(a) S	(b) M	(c) R						Manufacturer's		(a) 1-20	(b) 21-50	(c) 51-100	(a) 1-20			(b) 21-50	(c) 51-100	(a) FIGURE NO.	(b) ITEM NO/
									Code	Part No.										
X1					SHAFT: selector switch (27315) 279H294D5 (Used on Switch Assembly, stock No. 5930-227-6508 only).			1									17 (1)	64		
X1					WASHER, SPRING: selector switch 0.18 in. id. x 1.18 in. od. (27316) 220H45 (Used on Switch Assembly, stock No. 5930-227-6508 only).			2									17 (1)	39		
X1					SPACER: selector switch (27315) 279H248D3			1									17 (1)	40		
X1					INSULATOR: select switch spacer (27316) 279H244			8									17 (1)	45		
X1					BLADE, MOVABLE: selector switch (27316) 279H247			6									17 (1)	42		
X1					CONTACT: selector switch (27315) 279H245			3									17 (1)	46		
X1					CONTACT: selector switch (27315) 279H246			4									17 (1)	47		
X1				5305-215-3909	SCREW, MACHINE: selector switch binding (08288) MSS5305-14 (Used on Switch Assembly, stock No. 5930-227-6508 only).			2									17 (1)	32		
X1				5310-010-3319	WASHER, LOCK: switch binding screw (96906) MS35338-6 (Used on Switch Assembly, stock No. 5930-227-6508 only)			3									17 (1)	31		
X1				5310-164-8848	WASHER, FLAT: switch binding screw (08288) MSS5310-8 (Used on Switch Assembly, stock No. 5930-227-6508 only)			2									17 (1)	34		
X1				5305-468-3703	SCREW, MACHINE selector switch back plate (08288) MSS6306-2 (Used on Switch Assembly, stock No. 5930-227-6508 only).			2									17 (1)	30		
X1					SHAFT: reversing switch . (27315) 279H294D3 (Used on Switch Assembly, stock No. 5930-227-607 only)			1									17 (1)	43		
X1				5305-017-5170	SCREW, MACHINE: reversing switch blinding (08288) MSS630-14 (Used on Switch Assembly, stock No. 5930-227-6507 only)			2									17 (1)	32		

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION Manufacturer's Code Part No.	(4) UNIT OF ISSUE	(5) QTY UNIT OF MEAS	(6) INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCY	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION	
	(a) S	(b) M	(c) R						(a)	(b)	(c)	(a)	(b)	(c)			(a)	(b)
									1-20	21-50	51-100	1-20	21-50	51-100			FIGURE NO.	ITEM NO/
X1				5306-226-8503	BOLT, MACHINE: reversing switch . (08288) MS306-16 (Used on Switch Assembly, stock No. 5930-227-6607 only)			1									17 (1)	36
X1				5310-021-9431	NUT, PLAIN, HEXAGON: reversing switch (08288) MSS6310-9 (Used on Switch Assembly, stock No. 5930-2274607 only)			1									17 (1)	35
X1				5310-010-3320	WASHER, LOCK: reversing switch (96906) MS36338-7 (Used on Switch Assembly, stock No. 5930-227-6507 only)			1									17 (1)	33
X1					SPACER: reversing switch (27316) 218H104D3 (Used on Switch Assembly, stock No. 598S0-227-6607 only)			1									17 (1)	37
X2	F				STARTER ASSEMBLY, MOTOR (27315) 9279H237F6			1									19	4
P	F			2920-227-6604	STARTER ASSEMBLY (04009) 51345			1	*	*	*	*	*	*		3	19	4
X1					COIL (04009) 32620-513			1									18	4
X1					CONTACT (04009) 51364-15			1									18	6
X1					BLOCK, OVERLOAD (04009) 33209-8			2									18	2
X2	F				BUSHING, INSULATION: starter mtg (27316) 275H83			6									10	18
P	F			5930-548-7850	SWITCH, TOGGLE (15606) 8690K1			1	*	*	*	*	*	2		6	17 (1)	11
	F			5306989-7435	SCREW, MACHINE: starter assembly (08288) MSS5306-33			3									19	2
	F			5310-786-3999	WASHER, FLAT: starter assembly (08288) MSS5310-29			3									19	3
	F			5310-877-5797	NUT, SELF-LOCKING, HEXAGON (96906) MS20365-1032A			3									19	1
X2	F				SWITCH, PUSH: starter (02295) M4982698 4411 - RESISTOR COMPONENTS			1									17 (1)	68
P	F			5905-227-6506	RHEOSTAT (44655) 41876			1	*	*	2	*	2	2		20	17 (1)	59
X2	F				HANDLE: rheostat (27315) 206H15D2			1									17 (1)	61
X2	F				PIN, SPRING: rheostat handle attaching (72962) 59-022-094-625			1									17 (1)	60

Line No.	(1) Source, maint. and Recov. code			(2) FEDERAL STOCK NUMBER	(3) DESCRIPTION <table border="1" style="margin-left: 20px;"> <tr> <th colspan="2">Manufacturer's</th> </tr> <tr> <th>Code</th> <th>Part No.</th> </tr> </table>	Manufacturer's		Code	Part No.	(4) UNIT OF ISSUE	(5) QTY UNIT OF MEAS	(6) INC IN UNIT	(7) 30 DAY DS MAINT ALLOWANCE			(8) 30 DAY GS MAINT ALLOWANCE			(9) 1-YR ALW PER 100 EQUIP CNTGCY	(10) DEPOT MAINT ALW PER 100 EQUIP	(11) ILLUSTRATION	
	Manufacturer's																					
	Code	Part No.																				
(a)	(b)	(c)	(a)	(b)	(c)	(a)	(b)															
S	M	R	1-20	21-50	51-100	1-20	21-50	51-100	FIGURE NO.	ITEM NO/												
					GROUP 95 -GENREAL USE STANDARDIZED PARTS																	
P	O				9501 - BULK MATERIAL CHAIN, WELDLESS (00000) 42C15120-205	FT			*	*	*	*	*	*								
P	O		9505-186-9137		WIRE, STEEL, CARBON (08288) MSS9505-1	RI			*	*	*	*	*	*								
P	O		6145-174-1123		WIRE, ELECTRICAL	FT			*	*	*	*	*	*								
P	O		9520-517-0534		ANGLE, STEEL	FT			*	*	*	*	*	*								




Figure 20. Accessory items

By Order of the Secretary of the Army:

Official:
KENNETH G. WICKHAM,
Major General, United States Army,
The Adjutant General.

W. C. WESTMORELAND,
General, United States Army,
Chief of Staff.

Distribution:

To be distributed in accordance with DA Form 12-25, Sec I (qty rqr Block No 182), Organizational maintenance requirements for Welding

Change }
No. 2 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D.C., 26 June 1973

**Organizational, DS, GS, and Depot
Maintenance Manual Including Repair
Parts and Special Tools List**

**WELDING MACHINE, ARC: GENERATOR
ELECTRIC MOTOR DRIVEN, 300-AMP DC ARC,
220/440-V, 60-CYCLE, 3-PHASE, WHEEL MOUNTED
(HARNISCHFEGER MODEL W300 MG)
FSN 3431-2261569**

TM 5-3431-217-15, 9 April 1965, is changed as follows:
Page 50. APPENDIX III is superseded as follows:

**APPENDIX III
BASIC ISSUE-ITEMS-LIST-AND ITEMS TROOP
INSTALLED OR AUTHORIZED LIST**

Section I. INTRODUCTION

1. Scope

This appendix lists items required by the operator for operation of the welding machine.

2. General

This list is divided into the following sections:

- a. *Basic Issue Items List-Section II.* Not applicable.
- b. *Items Troop Installed or Authorized List-Section III.*

A list of items in alphabetical sequence, which at the discretion of the unit commander may accompany the welding machine. These items are NOT SUBJECT TO TURN-IN with the welding machine when evacuated.

3. Explanation of Columns

The following provides an explanation of columns in the tabular list of Basic Issue Items List, Section II, and Items Troop Installed or Authorized List, Section III.

a. *Source, Maintenance and Recoverability Code(s) (SMR):* (Not applicable).

b. *Federal Stock Number.* This column indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. *Description.* This column indicates the Federal item name and any additional description of the item required.

d. *Unit of Measure (UIM).* A two character alphabetic abbreviation indicating the amount or quantity of the item upon which the allowances are based, e.g., ft, ea, pr, etc. e. *Quantity Furnished with Equipment (BILL).* (Not applicable).

f. *Quantity Authorized (Items Troop Installed or Authorized).* This column indicates the quantity of the item authorized to be used with the equipment.

Section III. ITEMS TROOP INSTALLED OR AUTHORIZED LIST

(1) SMR Code	(2) Federal Stock Number	(3) Description	(4) Unit of Meas.	(5) Qty Auth
	752559-9618	Case, Manual	EA	1

By Order of the Secretary of the Army:

Official:

VERNE L. BOWERS,
*Major General, United States Army,
The Adjutant General.*

CREIGHTON W. ABRAMS
*General, United States Army
Chief of Staff*

Distribution:

To be distributed in accordance with DA Form 12-25A (qty rqr block No. 182) organizational maintenance requirements for Welding.

TECHNICAL MANUAL }
 No. 5-3431-217-15

HEADQUARTERS
 DEPARTMENT OF THE ARMY
 WASHINGTON, D.C., 9 April 1965

**ORGANIZATIONAL, DS, GS, AND DEPOT MAINTENANCE MANUAL
 INCLUDING REPAIR PARTS**

**WELDING MACHINE, ARC: GENERATOR: ELECTRIC MOTOR DRIVEN, 300-AMP DC
 ARC, 220/440-V, 60.CYCLE, 3-PHASE, WHEEL MOUNTED
 (HARNISCHFEGER MODEL W300 MG) FSN 3431-2261569**

		<i>Paragraph</i>	<i>Page</i>
CHAPTER 1.	INTRODUCTION		
Section I.	General.....	1-2	2
Section II.	Description and data	3-5	4
CHAPTER 2.	INSTALLATION AND OPERATING INSTRUCTIONS		
Section I.	Service upon receipt of equipment.....	6-12	9
Section II.	Movement to a new worksite.....	13-14	11
Section III.	Controls and instruments	15-24	11
Section IV.	Operation of equipment	26-29	12
Section V.	Operation of material used in conjunction with the equipment.....	30	15
CHAPTER 3.	OPERATOR AND ORGANIZATIONAL MAINTENANCE INSTRUCTIONS		
Section I.	Special tools and lubricants	31-34	16
Section II.	Preventive maintenance services	35-37	16
Section III.	Operator maintenance	38, 39	18
Section IV.	Troubleshooting	40-52	21
Section V.	Housing assembly.....	53, 54	23
Section VI.	Motor-generator	55-59	24
Section VII.	Controls, instruments, wiring, and components	60-66	25
Section VIII.	Handtruck assembly.....	67, 68	28
CHAPTER 4.	DEMOLITION, SHIPMENT, AND LIMITED STORAGE		
Section I.	Demolition of the equipment to prevent enemy use.....	69-73	30
Section II.	Shipment and limited storage.....	74-77	31
CHAPTER 5.	DIRECT AND GENERAL SUPPORT AND DEPOT MAINTENANCE INSTRUCTIONS		
Section I.	General.....	78, 79	33
Section II.	Description and data	80, 81	33
CHAPTER 6.	GENERAL MAINTENANCE INSTRUCTIONS		
Section I.	Special tools and equipment	82-84	37
Section II.	Troubleshooting	85-89	37
CHAPTER 7.	REPAIR INSTRUCTIONS		
Section I.	Control panel and components.....	90-92	38
Section II.	Motor-generator	93-98	39
APPENDIX I.	REFERENCES		45
APPENDIX II.	MAINTENANCE ALLOCATION CHART.....		50
APPENDIX III.	BASIC ISSUE ITEMS LIST		47
APPENDIX IV.	REPAIR PARTS		54

CHAPTER 1 INTRODUCTION

Section I. GENERAL

1. Scope

a. These instructions are published for the use of the personnel to whom the arc welding machine Model W300 MG is issued. Chapters 1 through 4 provide information on the operation, preventive maintenance services, and organizational maintenance of the equipment, accessories, components, and attachments. Chapters 5 and 6 provide information for direct and general support and depot maintenance. Also included are descriptions of main units and their functions in relationship to other components.

b. Appendix I contains a list of publications applicable to this manual. Appendix II contains the maintenance allocation chart. Appendix III contains the list of basic issue items authorized the operator of this equipment. The organizational, direct and general support, and depot maintenance repair parts and special tools are listed in appendix IV.

c. Numbers in parentheses on illustrations indicate quantity. Numbers preceding nomenclature callouts on illustrations indicate the preferred maintenance sequence.

d. the direct reporting by the individual user, of errors, omissions, and recommendations for improving this manual is authorized and encouraged. DA Form 2028 (Recommended Changes to DA Publications) will be used for reporting these improvements. This form will be completed in triplicate using pencil, pen, or typewriter. The original and one copy will be forwarded direct to Commanding General, U.S. Army Mobility Equipment Center, ATTN: SMOME-MMP, P.O. Drawer 58, St. Louis, Mo. 63166. One information copy will be provided the individual's immediate supervisor.

e. Report all equipment improvement recommendations as prescribed by TM 38-750.

2. Record and Report Forms

a. DA Form 2258 (Depreservation Guide of Engineer Equipment).

b. For record and report forms, applicable to operator, crew, and organizational maintenance, refer to TM 38-750.

Note. Applicable forms, excluding Standard Form 46 which is carried by the operator, will be kept in a canvas bag mounted on the equipment.

AGO 8244A



Figure 1. Arc welder rear, three-quarter view with shipping dimensions.

Section II. DESCRIPTION AND DATA

3. Description

a. *General.* The Harnischfeger Model W300 MG arc welding machine (figs. 1 and 2) is a self-contained, wheel-mounted, semi-enclosed unit. The welding machine is equipped with the necessary controls, instruments, and accessories for operation. All accessories and controls are mounted at the top of the machine and are readily accessible. The welding

machine is equipped with a lifting eye located at top center of the machine. A tongue or handle is provided for maneuvering the machine from place to place.

b. *Motor-Generator.* The motor-generator is an electric ac (alternating current) unit with a dc (direct current) output. The unit is rated at




Figure 2. Arc welder front, three-quarter view.

a nominal 300 amperes at 32 volts while operating at 60 percent duty cycle. The ac motor is controlled and protected by a magnetic across-the-line contactor that is operated by a pushbutton on the control panel. This starter incorporates an automatic reset thermal-overload relay. This relay protects the welding machine against severe and continuous overloads, low line voltage, stalled single-phase conditions, and locked rotor conditions. The thermal-overload relay automatically resets when the motor returns to a safe temperature and no manual operations are required to restart the machine except pushing the start button.

c. *Control Panel.* The control panel (fig. 3) contains all the switches and indicators necessary for the operation of the unit. Included in this group are the reversing switch, rheostat current selector, electrode selector, stop-start switch, current voltmeter and ammeter indicators.

4. Identification and Tabulated Data

a. *Identification.* The welding machine has four major identification plates. The information contained on these plates is listed below.

- (1) The Corps of Engineers identification plate specifies the name of the manufacturer,

make, model number, date of manufacture, serial number, and the Federal stock number of the welding machine. It is located on the welder housing.

- (2) The main name plate specifies the name of the manufacturer, serial number, model number, manufacturer's specification number, ampere rating, volts, duty cycle, rpm (revolutions per minute) and control instructions. It is located on the control panel.
- (3) The instruction nameplate specifies detail operating instructions and is located on the machine housing near the control panel.
- (4) The wiring diagram plate is a reproduction of the electrical wiring diagram of the welding machine and is located on the underside of the front cover.

b. *Tabulated Data.*

(1) *Motor-generator.*

Manufacturer	Harnischfeger-P & H
Model.....	W300MG
Type	ac with dc Output
Speed	3,500 rpm





Figure 3. Control panel.

CONTROL PANEL - FROM INSIDE



A - Generator Connection Diagram





MEC 3431-217-15/4 ①

Figure 4. Electrical wiring diagrams.

(2) Welder.
 Manufacturer Harnischfeger-P & H
 Rating 300 amperes at 32 volts
 Duty cycle 60%(percent)

Voltage 220 or 440 volts
 Type..... 3 phase
 (3) Dimensions and weight (fig. 1).
 Length..... 37 inches*

AGO 8244A



- L1
- L2 3 PHASE POWER INPUT
- L3
- C1 - CONTACTOR CONTROL
- J1 - JUMPER LEAD FOR 220/440 OPERATION CONTACTOR COIL

- C9 - CIRCUIT TERMINAL
- T1 - THRU - INDUCTION MOTOR STATOR WINDING LEADS
- T9
- OL - CONTACTOR OVERLEAD RELAY CONTACT

B - Motor and Starter Diagram

MEC 3431-217-15/4 (2)

Figure 4 Continued




Figure 5. Base plan.

Width 22 inches*
 Height 43 inches*
 Weight 920 pounds*
 *Welder on portable truck less wheel, plus remote control, welding cable, O-kit, and wheels.

(5) *Base plan.* The base plan is shown in figure 5.

5. Differences in Models

This manual covers only the Harnischfeger Model WU300 MG welding machine. No known unit differences exist for the model covered by this manual.

(4) *Wiring diagram.* The electrical wiring diagrams (fig. 4) show generator connection diagram and motor starter connection diagram.

AGO8244A

CHAPTER 2

INSTALLATION AND OPERATING INSTRUCTIONS

Section I. SERVICE UPON RECEIPT OF EQUIPMENT

6. Unloading Equipment

- a. Remove all tiedowns and blocking that secure the crate to the carrier.
- b. A forklift truck or suitable hoist must be used when removing the crate from the carrier.

Warning: Make certain any lifting device used has a capacity to handle weight being lifted. Failure to observe this precaution could result in injury to personnel and damage to the equipment.

7. Unpacking the Equipment

- a. Place the welding machine as close to the point of installation as possible. Remove the box containing remote rheostat current selector assembly, electrode cable with holder, and ground cable with clamp. A publications case and copies of this manual are also included.
- b. Remove the tape and protective material from the instruments and controls.
- c. Remove the tiedowns and blocking that secure the welding machine to the bottom of the crate and remove the welding machine.

8. Inspection and Servicing

- a. Make a complete visual inspection of the welding machine for any loss or damage that may have occurred during shipment. Prior to inspection of operation of the welding machine, accomplish depreservation of the welding machine as outlined on DA Form 2258.
- b. Refer to paragraph 36 for daily preventive maintenance services.
- c. Correct all deficiencies or report them to the proper authority.

9. Installation of Separately Packed Components

- a. The welding machine is delivered with the remote rheostat current selector assembly, electrode cable with holder, and ground cable with clamp packed separately.
- b. Install the remote rheostat current selector assembly in its correct position on the welding machine and secure with the fasteners provided. When in use, the unit is removed from its mounting, plugged into the remote control plug and set at the desired setting.
- c. Connect the ground and electrode cable assemblies to the terminal block provided as shown in figure 6.

10. Installation or Setting-Up Instructions

- a. *Location.* The welding machine should be located in a clean, dry, well ventilated area. The machine should be set on a foundation as free from vibration as practical. If the unit is to be located on soft or muddy footing a suitable platform of planks or similar material should be provided. The machine should be maintained as level as possible at all times. Position the welding machine as close and as convenient to the work as possible. The welding machine is of a drip-proof construction. If the machine is to be left out in the rain or snow, protection should be provided that will shield the entire unit from the weather, and provide ready access to the controls. The canopy should not interfere with ventilation.
- b. *Indoor Installation.* When the welding machine is installed in an enclosed area it should be well ventilated with a maximum supply of fresh air. When a vapor degreaser using trichloroethylene or other chlorinated

hydrocarbons is being employed or such solvents are used in any manner, the welding operation should be located in an area sufficiently remote so that there is no possibility of these vapors entering the area covered by the light from the welding arc. The ultra-violet light can decompose these vapors at considerable distance from the arc into toxic gases even though the concentration is low enough to be undetectable by odor.

11. Inspection of Used Equipment

Inspect the welding machine, following the instructions in paragraph 8. Correct or report all deficiencies to the proper authority.

12. Servicing Used Equipment

Perform the procedures described in paragraph 8. Clean the exterior of the unit thoroughly. Coat the exposed metal surfaces with a film of oil or grease. Correct all deficiencies or report them to the proper authority.




Figure 6. Welding cables and remote rheostat current selector assembly connection., removal and installation.

Section II. MOVEMENT TO A NEW WORKSITE

13. Dismantling for Movement

a. Preparation for Movement.

- (1) Disconnect all electrical power leading to the welding machine.
- (2) Disconnect welding cables and remote rheostat control if used (fig. 6).
- (3) Refer to the basic issue items list and make sure all items listed are on or with the equipment.

b. *Short Distance Movement.* The welding machine may be pulled by hand, or towed relatively short

distances. Secure a suitable towing device to the tongue and proceed slowly to a new worksite.

c. *Long Distance Movement.* The welding machine should be recrated and transported by a suitable carrier to a new long distance workingsite.

14. Reinstallation After Movement

The welding machine should be installed or set up after movement in accordance with procedures outlined in paragraph 10.

Section III. CONTROLS AND INSTRUMENTS

15. General

This section describes, locates, illustrates and furnishes the operator, crew, or organizational maintenance personnel sufficient information pertaining to the various controls and instruments provided for the proper operation of the welding machine.

16. Controls and Instruments

The controls and instruments and the normal and maximum reading of the instruments are illustrated in figure 7.

17. Stop-Start Switch

The stop-start switch (fig. 7) is used to start or stop the current flow directed to the motor generator of the welding machine causing the machine to run or stop running.

18. Magnetic Starter

The motor starter is a magnetic across-the line contactor that is operated by the stop-start switch on the control panel. This starter incorporates an automatic reset thermal-overloading relay. This relay protects the welding machine against severe and continuous overloads, low line voltages, stalled single-phase conditions and locked rotor conditions. Do not attempt to change the overload setting. This has been set at the factory to insure accurate tripping

characteristics. If the overload relay should trip it is an indication that one of the above-mentioned malfunctions exists. Find the cause and remedy it before attempting further operation. It may be necessary to allow the welding machine to cool a few minutes before it can be restarted.

19. Reversing Switch

The reversing switch (fig. 7) provides a means of reversing the polarity by setting the lever at "straight" or "reverse" polarity.

20. Rheostat Current Selector

The rheostat current selector (fig. 7) varies the current output of the welding machine and has a range of 0 to 10 amperes.

21. Electrode Selector

The electrode selector (fig. 7) varies the voltage of the welding current suitable to the size (diameter) of the welding electrode being used. It has a range of 3/32 to 5/16 inch.

22. Remote Control Switch

The remote control switch (fig. 7) switches the control of the open circuit voltage of the welding machine from the rheostat current selector on the control panel to the remote control rheostat assembly.




Figure 7. Control and instruments.

23. Voltmeter Gage The voltmeter gage (fig. 7) indicates the output direct current voltage of the welding machine. It has a range of 0 to 100.

24. Ammeter Gage The ammeter gage (fig. 7) indicates the output amperage of the welding machine. It has a range of 0 to 400.

Section IV. OPERATION OF EQUIPMENT

25. General

a. The instructions in this section are published for the information and guidance of the personnel responsible for the operation of the welding machine.

b. The operator must know how to perform every operation of which the welding machine is capable.

AGO 8244A

This section gives instructions on starting and stopping the welding machine, basic motions of the welding machine, and on co-ordinating the basic motions, to perform the specific tasks for which the equipment is designed. Since nearly every job presents a different problem, the operator may have to vary given procedures to fit an individual job.

26. Starting

a. *Preparation for Starting.*

- (1) Perform the necessary daily preventive maintenance services (para 36).
- (2) Connect welding machine to power supply as follows:
 - (a) Approximate full load amperes, and recommended fuse and power cable sizes are listed in table 1.

Table 1. Wiring Data

Three-phase, 60 cycle, ac				
Rating	Input voltage	Full load line amperes	Power lead size B and S	Min. Fuse size in amperes
300 Ampere	230	57.5	4	125
300 Ampere	460	28.8	8	75

- (b) A tag on the welding machine indicates the line voltage for which the unit is connected at the factory. Be sure it corresponds with the power supply voltage to be used. If connection changes are required, change motor leads and contactor coil leads and jumpers as described in the wiring diagram (fig. 4).

Warning: Make sure the main power supply disconnect switch is shut off before making any connections.

- (c) Remove the top cover (para 54), run power supply leads through the hole in the back panel and connect to the motor starter terminals in accordance

with the wiring diagram (fig. 4). Make certain all connections are secure, make good contact, and have ample clearance.

- (d) Attach supply ground wire to welder housing and replace the top cover. This cover must be in place when operating the welding machine.
- (e) Check for proper direction of rotation on the initial start as described below.

b. *Starting.*

- (1) Push START button (fig. 7).
- (2) On the initial start check the direction of rotation as indicated by the arrow on the name plate. If rotation is incorrect, press STOP button, shut off main power supply disconnect switch, and interchange any two line leads (fig. 4).

27. Stopping

Push STOP button (fig. 7) to stop welding machine operation.

28. Operation Under Usual Conditions

- a. Connect electrode and ground cable (para 9).
- b. Attach clamp of ground cable to work metal making sure it is at a clean, paint and rust free spot for good contact.
- c. Set reversing switch at "straight" or "reverse" position and check the polarity of the electrode.
- d. Set electrode selector for the size of electrode to be used (para 21). If unusually high or low currents are required for a particular electrode, it may be necessary to turn the electrode selector to the next higher or lower setting.
- e. Set rheostat current selector to the desired current in amperes (para 20). The remote rheostat current selector controls the welding machine for remote work.

Warning: Do not perform any welding operation without a welder's helmet. The flash of the welding arc can cause injury to the eyes.

- f. The approximate current range for bare

and lightly coated electrodes is shown in table 2. Table 3 gives similar information for gaseous and slag types of electrodes.

Table 2. Current Setting Range for Bare or Lightly Coated Electrodes

Electrode diameter (in.)	Current minimum (Amps.)	Electrode maximum (Amps.)	Lengths (in.)
3/32	70	90	11 1/2
1/8	110	135	14 or 18
5/32	150	180	14 or 18
3/16	150	220	14 or 18
1/4	250	300	14 or 18
5/16	300	425	14 or 18
3/8	450	550	14 or 18

Table 3. Comparison of Current Used with Gaseous and Slag Types of Electrodes

Electrode diameter (in.)	Gaseous types		Slag type flat position (amperes)
	Flat position (amperes)	Vertical and overhead position (amperes)	
3/32	60	60	
1/8	120	110	130
5/32	150	140	160
3/16	175	160	200
1/4	200		300
5/16	325		400
3/8	425		500

g. Strike an arc.

h. If the arc is weak, turn the electrode selector one setting higher. If the arc is too cold turn the rheostat current selector up and turn the electrode selector down.

Warning: Do not adjust welding controls while maintaining arc.

i. Parallel Operation.

- (1) Two welding sets of the same type and rating can be operated in parallel to obtain twice the capacity of one set. When connecting welders together for parallel operation, it is necessary to use two paralleling and two equalizer connections

(B, fig. 3). Existing connections should not be changed.

- (2) All connections must be made before starting either set and they should not be broken until both sets are shut down.
- (3) Reversing switches must indicate the same polarity at all times, and must never be changed if either set is running.
- (4) Electrode selectors should indicate the same electrode size so as to divide the load equally between the two generators.
- (5) Current selector dials should always indicate the same current, otherwise it will be difficult to adjust for the desired current, and one rheostat might become overloaded.

Warning: Do not attempt to weld with two welding sets in parallel unless both are running. Both must be started and stopped simultaneously, both driving motors must be on the line, or both off. Do not make or break any connections while either set is running.

29. Operation Under Unusual Conditions

a. Operation in Extreme Cold (Below 0°F.).

- (1) Before starting the welding machine, disconnect its source of power and wipe the electrical components free of ice and moisture. Do not disturb the wiring as it becomes brittle with extreme cold.
- (2) Connect the power source.
- (3) Start welding machine (para 26).
- (4) Begin usual welding operations (para 28).

b. Operation in Extreme Heat.

- (1) Erect a shelter to shade the machine and provide as much ventilation as possible to keep operating temperature of the welding machine as low as possible.
- (2) Connect the power source.
- (3) Start the welding machine (para 26).
- (4) Begin usual welding operations (para 28).

c. Operation in Dusty or Sandy Areas.

- (1) If the installation is to be permanent, provide protective cover to keep the unit as clean as possible paying special

attention to the control panel. The covering should not interfere with ventilation.

- (2) Connect the welding machine to the power source.
- (3) Start welding machine (para 26).
- (4) Begin usual welding operations (para 28).

d. Operation Under Rainy or Humid Conditions.

- (1) When the welding machine is operated outside, erect a shelter or protective covering when possible. If the erection of a shelter is not practical, protect the machine with a canvas. The covering should not interfere with ventilation. Remove the covering during dry periods and allow the unit to dry thoroughly.
- (2) Connect the welding machine to power source.
- (3) Start the welding machine (para 26).

- (4) Begin usual welding operations (para 28).

e. Operation in Salt Water Areas.

- (1) Salt water causes corrosive action on metal. Care must be taken to avoid contact of equipment with salt water. If contact is made, or if the unit is exposed to salt spray, wash the unit with clean, fresh water.

Warning: The welder must be disconnected from the power source before washing and must be thoroughly dry before reconnecting to power source.

- (2) Coat all exposed surfaces with an approved rust proofing material or cover parts with a thin coat of grease.
- (3) Connect the welding machine to the power source.
- (4) Start welding machine (para 26).
- (5) Begin usual welding operations (para 28).

Section V. OPERATION OF MATERIEL USED IN CONJUNCTION WITH THE EQUIPMENT

30. Fire Extinguisher

(dry chemical type)

a. Description. The dry, chemical type fire extinguisher is suitable for use on all types of fire and is effective in areas where ambient temperature is -25°F . The fire extinguisher is a 2 1/2-pound, stored pressure, lever-operated extinguisher.

b. Operation. Remove the fire extinguisher from its location, lift the handle, press lever, and direct the powder at the base of the flame using a side-to-side sweeping motion.

c. Maintenance. Weigh the fire extinguisher every 6 months and replace the extinguisher if weight is less than 4 1/2 pounds, or if pressure is below 125 pounds. Refer to SB 5-111. The dry chemical fire extinguishers will be serviced at installation level through repair and utilities facilities, with the filling agent supplied by local procurement through troop supply channels.

CHAPTER 3

OPERATOR AND ORGANIZATIONAL MAINTENANCE INSTRUCTIONS

Section I. SPECIAL TOOLS AND LUBRICANTS

31. Special Tools and Equipment

No special tools or equipment are required by the operator or organizational maintenance personnel for the maintenance of the welding machine.

32. Basic Issue Tools and Equipment

Tools and repair parts issued with or authorized for the welding machine are listed in the basic issue items list, appendix III of this manual.

33. Organizational Maintenance Repair Parts

Organizational maintenance repair parts are listed in appendix IV.

34. Lubrication

There are no lubricants or lubrication necessary for initial operation of the welding machine.

Section II. PREVENTIVE MAINTENANCE SERVICES

35. General

To insure that the welding machine is ready for operation at all times, it must be inspected systematically, so that defects may be discovered and corrected before they result in serious damage or failure. The necessary preventive maintenance services to be performed are listed and described in paragraphs 36 and 37. The item numbers indicate the sequence of minimum inspection requirements. Defects discovered during operation of the unit will be noted for future correction, to be made as soon as operation has ceased. Stop operation immediately if a deficiency is noticed during operation which would damage the equipment if operation were continued. All deficiencies and shortcomings will be recorded together with the corrective action taken on DA Form 2404 (Equipment Inspection and Maintenance Worksheet) at the earliest possible opportunity.

36. Daily Preventive Maintenance Services

This paragraph contains an illustrated tabulated listing of preventive maintenance services which must be performed by the operator. The item numbers are listed consecutively and indicate the sequence of minimum requirements. Refer to figure 8 for the daily preventive maintenance services.

37. Quarterly Preventive Maintenance Services

a. This paragraph contains an illustrated tabulated listing of preventive maintenance services which must be performed by organizational maintenance personnel at quarterly intervals. A quarterly interval is equal to 3 calendar months, or 250 hours of operation, whichever occurs first.

b. The item numbers are listed consecutively and indicate the sequence of minimum requirements. Refer to figure 9 for the quarterly preventive maintenance services.


PREVENTIVE MAINTENANCE SERVICES

DAILY

TM5-3431-217-15

HARNISCHFEGER - P&H
MODEL W300 MG

WELDING MACHINE, ARC



ITEM

PAR REF

1	<u>FIRE EXTINGUISHER.</u> Inspect for broken seal (Weekly).	30
2	<u>BRUSHES.</u> Inspect to see that brushes move freely in brush holder and make firm contact.	56
3	<u>CABLE ASSEMBLIES.</u> Inspect cable assemblies. If damage is apparent repair or replace immediately.	
4	<u>ELECTRODE HOLDER ASSEMBLY.</u> Inspect electrode for general condition. Replace if defective.	
5	<u>TERMINAL BOARD CONNECTIONS.</u> Tighten loose cables or mountings.	63
6	<u>CONTROLS AND INSTRUMENTS.</u> Inspect for damage and loose mountings. With unit operating check for proper operation. Replace defective instruments.	60
	<u>NOTE 1: OPERATION.</u> During operation observe for any unusual noise or vibration.	

MEC 3431-217-15/8

Figure 8. Daily preventive maintenance services..

Section III. OPERATOR MAINTENANCE

38. General

The instructions in this section are published for the information and guidance of the operator to maintain the welding machine.

39. Correcting Polarity

The welding generator terminals have been marked for straight polarity (electrode terminal negative). If the polarity should become reversed, it may be corrected after the motor has stopped.

a. Adjust the current selector for maximum current with electrode selector on any setting.

- b. Remove the generator end cover (para 53).
- c. Raise the excitation brush from the commutator (para 56).
- d. Connect the negative terminal of a 6- to 12-volt battery to the excitation brush stud.
- e. Touch the positive terminal of the battery to the bottom main brush stud for approximately 2 seconds.
- f. Lower the excitation brush and replace the generator end cover. The polarity will be correct when the welding machine is next used.
- g. Remove the cause of reversal in polarity. (Refer to Troubleshooting para 40).


PREVENTIVE MAINTENANCE SERVICES

QUARTERLY

TM5-3431-217-15

HARNISCHFEGER - P&H
MODEL W300 MG

WELDING MACHINE, ARC



ITEM		PAR REF
1	<u>FIRE EXTINGUISHER.</u> Inspect for broken seal. Inspect for full charge by weight and/or proper pressure.	30
2	<u>ARC WELDER.</u> Inspect and clean by blowing out dust with air.	
3	<u>COMMUTATOR AND BRUSHES.</u> Inspect brush rigging and commutator. Brush holders should be tight and clear commutator by 1/16 inch. Brushes should ride freely in holders. Inspect brush springs for proper tension. Tighten all loose electrical connections or mounting hardware. Brushes worn under 1 inch, discard and replace. Replace worn or damaged brushes and springs as necessary.	56-59
4	<u>WIRING, SWITCHES, RECEPTACLE.</u> Inspect switches and receptacle for proper operation. Inspect wiring for frayed, broken, deteriorated insulation, and loose or damaged connections. Clean corroded and tighten loose connections. Replace defective switch or receptacle.	61

MEC 3431-217-15/9 ①

Figure 9. Quarterly preventive maintenance services.

ITEM		PAR REF
5	<u>SELECTOR AND POLARITY SWITCH.</u> Inspect the mounting, wiring and operation. Keep switch blades clean and free of dirt and corrosion. Lubricate blades with a light coating of Molykote or vaseline. Inspect for defective wiring, broken, or loose connections. Replace defective parts as necessary.	64
6	<u>CONTROL PANEL AND INSTRUMENTS.</u> Inspect instruments for cracked or broken glass. Inspect for insecure mountings, loose connections, and improper operation. Inspect control handles for cracks, breaks, or other damage. Tighten all loose mountings and electrical connections. Replace defective or damaged parts as necessary.	61-62
7	<u>TRUCK FRAME AND WHEELS.</u> Inspect wheels and tires for general condition. Inspect frame and handle for cracks, breaks or loose mounting hardware. Replace or repair parts as necessary.	67
	<u>NOTE 1: OPERATION.</u> During operation observe for any unusual noise or vibration.	

MEC 3431-217-15/9 ②

Figure 9-Continued.

Section IV. TROUBLESHOOTING

40. General

This section provides information useful in diagnosing and correcting unsatisfactory operation or failure of the welding machine and its components. Each trouble symptom stated is followed by a list of probable causes of trouble. The possible remedy recommended is described opposite the probable cause. Any trouble beyond the scope of organizational maintenance shall be reported to direct support maintenance.

41. Welder Will Not Start (Starter Not Operating)

<i>Probable cause</i>	<i>Possible remedy</i>
Power circuit dead	Check voltage.
Broken power lead	Replace or repair.
Wrong voltage	Check nameplate against power supply.
Incorrect connections to starter	Check connections against wiring diagram (fig. 4).
Open power switch	Close switch.
Blown power source fuses.....	Replace (refer to wiring data table 1).
Overload relay tripped	Allow welding machine to cool. Remove cause of overload.
Open circuit to starter button.....	Check connections against wiring diagram (fig. 4).
Mechanical obstruction on starter.....	Remove obstructions.

42. Starter Chatters

<i>Probable cause</i>	<i>Possible remedy</i>
Line leads too small	Install larger leads (refer to wiring data table 1).
Power supply inadequate	Report to proper authority.
Low line voltage	Report to proper authority.
Sticky operation	Replace starter (para 66).

43. Welder Will Not Start

<i>Probable cause</i>	<i>Possible remedy</i>
Wrong motor connections to starter	Check connections against wiring diagram (fig. 4).
Wrong supply voltage	Check nameplate and connections against power supply. Report to proper authority.
Rotor stuck	Try turning by hand.
Power source line circuit single-phased.....	Replace fuse. Report open line to proper authority.
Poor motor connections to starter	Tighten connections.

44. Starter Operates and Blows Fuse

<i>Probable cause</i>	<i>Possible remedy</i>
Power source fuse size too small	Refer to wiring data table 1 for recommended fuse size.
Short circuit in motor connections	Check starter and motor leads insulation for ground.

45. Welder Starts but Will Not Deliver Welding Current

<i>Probable cause</i>	<i>Possible remedy</i>
Wrong direction of rotation.....	Refer to paragraph 26.
Brushes worn or missing; brush springs broken or missing.....	Check that all brushes bear on commutator with sufficient pressure (para 56).
Brush connections loose	Tighten connections (para 56).
Open field circuit.....	Check connection to rheostat and to excitation brush studs (fig. 56).
Welding terminal shorted	Electrode holder or welding cable may be grounded.
Brushes binding in holder.....	Remove obstruction (para 57).



46. Welder Generating but Current Falls Off

<i>Probable cause</i>	<i>Possible remedy</i>
Electrode or ground connections loose.....	Clean and tighten all connections.
Poor ground.....	Check ground-return circuit.
Brushes worn off.....	Replace brushes (para 56).
Weak brush spring pressure	Replace brush springs (para 57).
Brush not properly fitted	Sand brushes to fit (para 56).
Brushes in backwards.....	Reverse, sand to fit (para 56).
Wrong brushes used.....	Replace with correct brushes (para 56).
Brush pigtails damaged	Replace brushes (para 56).
Motor connection single phased.....	Check all connections against wiring diagram (fig. 4).
Insufficient cooling air	Remove obstructions that may block ventilating air or cause the exhaust air to recirculate.

47. Welder Runs but Soon Stops

<i>Probable cause</i>	<i>Possible remedy</i>
Wrong overload relay.....	Check rating of starter overload relay (para 92).
Welder overloaded.....	Check control settings (para 28).
Duty cycle too high	Do not operate continuously at overload currents.
Line leads too long or too small in cross section.....	Lines should be large enough to carry welding current requirement without excessive voltage drop. Report to proper authority.
Power circuit single phased.....	Check for one dead fuse at power source or line.
Ambient temperature too high	Operate at reduced loads when temperatures exceed 100°F.
Ventilation blocked.....	Check air inlet and exhaust openings.

48. Welding Arc Is Loud and Spatters Excessively

<i>Probable cause</i>	<i>Possible remedy</i>
Polarity wrong.....	Check polarity, try reversing, or using an electrode of opposite polarity (para 39).

49. Welding Arc Sluggish

<i>Probable cause</i>	<i>Possible remedy</i>
Current too low	Check output and current recommended for electrode being used (para 28).
Poor connections	Check electrode holder, cable, and ground connections para 28).
Cable too long or too small	Check cable voltage drop and change cable (paras 26 and 28).

50. Touching Machine Gives Shock

<i>Probable cause</i>	<i>Possible remedy</i>
Frame not grounded	Ground solidly.
Internal components grounded.....	Report to proper authority.

51. Generator Control Fails To Vary Current

<i>Probable cause</i>	<i>Possible remedy</i>
Any part of field circuit may be short circuited	Report to proper authority.
Faulty rheostat	Replace rheostat (para 65).

52. Excessive Brush Sparking

<i>Probable cause</i>	<i>Possible remedy</i>
Faulty brush spring (broken or worn).....	Replace springs (para 57).
Incorrect, broken or chipped brushes.....	Replace brushes (para 56).
Contaminated atmosphere, such as carbontetrachloride..... fumes.	Remove contaminant and improve ventilation.

Section V. HOUSING ASSEMBLY

53. General


The welding machine is enclosed in a sheet metal housing. Removable louvered doors and end panels provide access to the motor-generator and components. Sheet metal panels and a top cover complete the housing assembly.

54. Housing, Doors, Cover, and Panels

a. Removal.

- (1) Remove remote control assembly (para 9).
- (2) Disconnect ground and electrode cables (para 9).
- (3) Remove and disassemble the housing, doors, cover, and panels as illustrated in figure 10.

b. Cleaning, Inspection, and Repair.



MEC 3431-217-15/10

- | | | |
|----------------------|----------------|---------------------|
| 1 Machine screw | 9 Insulation | 17 Nameplate |
| 2 Lockwasher | 10 End plate | 18 Grommet |
| 3 Top cover | 11 Rubber seal | 19 Access door |
| 4 Self-tapping screw | 12 Door | 20 Panel |
| 5 Lockwasher | 13 Bumper | 21 Rubber seal |
| 6 Lifting bail | 14 Hex nut | 22 Mounting bracket |
| 7 Insulation | 15 Lockwasher | 23 Plastic hanger |
| 8 Back panel | 16 Guard | 24 Cable strap |
| | | 25 Wingnut |

Figure 10. Housing, cover and panels, removal, disassembly, and installation.

- (1) Clean all parts in an approved cleaning solvent and dry thoroughly.
 - (2) Inspect for cracks, breaks, or other damage.
 - (3) Repair or replace defective parts as necessary.
- c. *Installation.*

- (1) Reassemble and install housing, doors, cover and panels as shown in figure 10.
- (2) Connect ground and electrode cables (para 9).
- (3) Replace remote control assembly (para 9).

Section VI. MOTOR-GENERATOR

55. General

In normal use the motor-generator brushes wear and the spring tension is lessened causing arcing of the brushes and may cause pitting of the commutator bars.

56. Brushes

a. *Removal.* The worn brushes are removed by disconnecting the leads and removing them from the brush holders as shown in figure 11.

b. *Installation.*

- (1) Brushes should be discarded and replaced




Figure 11. Brushes, brush springs, and holders, removal and installation.

when worn under 1 inch or before the limit of spring travel is reached. New brushes must be seated before they can be used.

- (2) Place new brushes in position with a piece of medium grade sandpaper under the brush toe on the commutator.
- (3) Hold the brush in its normal position and draw the sandpaper back and forth under the brush with the back (smooth side) of the sandpaper held closely in contact with the curve of the commutator. This will sand the brush down to the curve of the commutator.
- (4) Blow out all carbon dust from commutator. Position brush springs and connect leads as shown in figure 11.

57. Brush Springs

a. Inspection.

- (1) Check the brush springs to make sure they are holding brushes on the commutator with a firm, even pressure. Brush spring tension pressure should be approximately 32 ounces (plus or minus 2 ounces).
- (2) Tension readings are taken with a spring-scale gauge at the instant the brush spring releases contact on the brush. Replace defective or weak springs as necessary.

b. *Removal and Installation.* Remove and install brush springs as shown in figure 11.

58. Brush Holders

a. Removal.

- (1) Remove brushes and springs (paras 56 and 57).
- (2) Remove brush holders as shown in figure 11.

b. *Cleaning, Inspection, and Repair.*

- (1) Clean all parts in an approved cleaning solvent and dry thoroughly.
- (2) Inspect for cracks, breaks, or other damage. Replace damaged or defective parts as necessary.

c. *Installation.*

- (1) Install brush holders as shown in figure 11.
- (2) Install brushes and brush springs (paras 56 and 57).

59. Cleaning Commutator

Clean commutator with a clean rag or, while running with a piece of fine grade sandpaper.

Important: Never use emery cloth or emery paper to clean commutator.

Warning: Care should be exercised in cleaning commutator awhile running to prevent injury to personnel.

Section VII. CONTROLS, INSTRUMENTS, WIRING AND COMPONENTS

60. General

All controls and instruments necessary for operation of the Model W300 MG welding machine are mounted on the front panel with the exception of the remote control assembly which is a separately contained unit.

61. Receptacle and Switch

a. *General.* The receptacle and switch (fig. 12) are used in conjunction with the remote control assembly. Both are mounted in a common mounting plate and are removed and installed in a similar manner. If either is found to be damaged or defective it should be replaced.
AGO 8244A

b. *Removal and Installation.*

- (1) Remove mounting screws which attach receptacle and switch mounting plate to front panel.
- (2) Tag and disconnect electrical lead.
- (3) Remove attaching hardware and remove switch or receptacle.
- (4) Install by reversing above procedure.

62. Voltmeter and Ammeter

a. *General.* The voltmeter and ammeter (fig. 12) are mounted in a common mounting and




Figure 12. Controls and instruments, removal and installation.

are removed and installed in a similar manner. If either is found to be damaged or defective it should be replaced.

b. Removal and Installation.

- (1) Remove screws which attach meter mounting assembly to front panel.
- (2) Tag and disconnect electrical leads.
- (3) Remove attaching hardware and remove meter.
- (4) Install by reversing above procedure.

63. Terminal Blocks

a. Removal and Disassembly.

- (1) Disconnect electrode and ground cables (para 9).
- (2) Tag and disconnect all remaining electrical leads from terminal blocks.
- (3) Remove attaching hardware and remove terminal block assemblies.

b. Cleaning, Inspection, and Repair.

- (1) Clean all parts in an approved solvent and dry thoroughly.
- (2) Inspect all insulation material for cracks or breaks. Replace any part found defective.
- (3) Inspect all electrical terminals for corrosion, damaged threads, or any condition preventing good electrical contact. Replace damaged or defective parts as necessary.

c. Reassembly and Installation.

- (1) Attach terminal block assemblies in position with attaching hardware.
- (2) Attach electrical leads to proper terminals.
- (3) Connect electrode and ground cables (para 9).

64. Electrode Selector and Polarity Reversing Switches

a. General. The electrode selector and polarity reversing switch are quite similar in construction and are removed and installed in the same manner.

b. Removal and Installation.

- (1) Tag and disconnect electrical leads.
- (2) Remove control handles from switches as shown in figure 12.

- (3) Remove attaching screws and remove switches as shown in figure 12.
 - (4) Install by reversing above procedure.
- c. Cleaning, Inspection, and Repair.*
- (1) Clean all parts in an approved cleaning solvent and dry thoroughly.
 - (2) Inspect contact blades for burnt or corroded condition.
 - (3) Replace a damaged or defective switch.

65. Current Selector

a. Removal and Installation.

- (1) Tag and disconnect electrical leads.
- (2) Remove control handle from current selector switch as shown in figure 12.
- (3) Remove attaching screws and remove switch as shown in figure 12.
- (4) Install by reversing above procedure.

b. Cleaning, Inspection, and Repair.

- (1) Clean all parts in an approved cleaning solvent and dry thoroughly.




Figure 13. Magnetic starter, removal and installation

68. Wheels and Tongue

a. Removal and Installation. Remove and install truck wheels and tongue as shown in figure 14.

b. Cleaning, Inspection, and Repair.

- (1) Clean all parts in an approved cleaning solvent and dry thoroughly.
- (2) Replace damaged or defective parts as necessary.

AGO 8244A

DEMOLITION, SHIPMENT, AND LIMITED STORAGE

Section I. DEMOLITION OF THE EQUIPMENT TO PREVENT ENEMY USE

69. General

When capture or abandonment of the welding machine to an enemy is imminent, the responsible unit commander must make the decision either to destroy the equipment or to render it inoperative. Based on this decision, orders are issued which cover the desired extent of destruction. Whatever method of demolition is employed, it is essential to destroy the same vital parts of all welding machines and all corresponding repair parts.

70. Demolition by Mechanical Means to Render the Equipment Inoperative

Use sledge hammers, crowbars, picks, axes, or other heavy tools which may be available to destroy the following:

- a. Motor-generator.
- b. Starter.
- c. All Controls and Instruments.

71. Demolition by Explosives or Weapon's Fire

a. *Explosives.* Place as many of the following charges (fig. 15) as the situation permits and detonate them simultaneously with a detonating cord and a suitable detonator.

- (1) One 1/2-pound charge below the generator assembly.
- (2) One 1/2-pound charge behind the control panel.
- (3) One 1/2-pound charge below the electric motor.

b. *Weapon's Fire.* Fire on the welding machine with the heaviest practical weapons available.

72. Other Demolition Methods

a. *Scattering and Concealment.* Remove all easily accessible parts such as brushes, starter, electrode and ground cables. Scatter them through dense foliage.

b. *Burning.* Pack rags, clothing, or canvas under, around and inside the welding machine. Saturate this packing with gasoline, oil, or diesel fuel and ignite.

c. *Submersion.* Totally submerge the welding machine in a body of water to provide water damage and concealment. Salt water will damage metal parts more than fresh water.

73. Training

All operators should receive thorough training in the destruction of the welding machine. Refer to FM 5-25. Simulated destruction, using all of the methods listed above, should be included in the operator training program. It must be emphasized in training that demolition operations are usually necessitated by critical situations when time available for carrying out destruction is limited. For this reason it is necessary that operators be thoroughly familiar with all methods of destruction of equipment, and be able to carry out demolition instructions without reference to this or any other manual.




Figure 15. Placement of demolition charges

Section II. SHIPMENT AND LIMITED STORAGE

74. Preparation of Equipment for Shipment

a. *General.* Detailed instructions for the preparation of the welding machine for domestic shipment are outlined within this paragraph. Preservation will be accomplished in sequence that will not require the operation of previously preserved components.

b. *Inspection.* The welding machine will be inspected for any unusual conditions such as damage, rusting, accumulation of water, and pilferage. Inspection of individual components and assemblies will be as outlined on the "Preventive

Maintenance Service, Quarterly," paragraph 37.

c. *Cleaning and Drying.* All contamination will be removed from the welding machine by an approved method. Approved methods of cleaning, drying, types of preservatives, and methods of application are described in TM 38-230.

d. *Painting.* Paint all surfaces where the paint has been removed or damaged. Refer to TM 9-213 for detailed cleaning and painting instructions.

e. *Depreservation Guide.* DA Form 2258 (Depreservation Guide of Engineer Equipment).

(1) A properly annotated depreservation guide will be completed concurrently with preservation for each item of mechanical equipment. Any peculiar requirements will be outlined in the blank spaces on the form. The completed depreservation guide will be placed with the equipment in a water-proof envelope marked "Depreservation Guide, " and fastened in a conspicuous location on or near the operator's controls.

(2) Prior to placing equipment in operation or to the extent necessary for inspection depreservation of the item shall be performed as outlined on the depreservation guide.

f. *Sealing of Openings.* Openings that will permit the direct entry of water into the interior or the welding machine will be sealed with pressure-sensitive tape conforming to specification PPP-T-60, type III, class 1.

g. *Exterior Surface.* Coat exposed machined ferrous metal surfaces with type P-6 preservative conforming to Specification MIL-C-11796, class 3. If preservative is not available, cup grease may be used.

h. *Marking.* Will conform to MIL-STD-129.

i. *Electrode and Ground Cables.* Cables will be disconnected, vent holes sealed and all terminals wrapped and secured with type III, class I, pressure-sensitive tape conforming to Specification PPP-T-60.

j. *Disassembly, Disassembled Parts and Basic Issue Items.*

(1) Disassembly will be limited to the removal of parts and projecting components that tend to increase the overall

profile of the welding machine and that which is subject to pilferage.

(2) Disassembled items will be packed with the publications in a suitable container and secured to the welding machine to prevent loss or pilferage.

Note. If packing is required to provide adequate protection against damage during shipment, refer to TM 38-230 for guidance in crate fabrication.

75. Loading Equipment for Shipment

Use appropriate materials handling equipment of sufficient capacity to lift the welding machine onto the carrier. Block and tie the unit to the carrier to assure that it will not move during transit.

76. Preparation of Equipment for Storage

a. Detailed instructions for preparation of the welding machine for limited storage are provided in paragraph 74. Limited storage is defined as storage not to exceed 6 months. Refer to AR 743-505.

b. Every effort should be made to provide covered storage for the welding machine. If this is impossible, select a firm, level, well-drained storage location, protected from prevailing winds. Position the welding machine on heavy planking. Cover the welding machine with a tarpaulin or other suitable waterproof covering and secure in a manner that will provide the welding machine maximum protection from the elements.

77. Inspection and Maintenance of Equipment in Storage

Every 90 days, the welding machine will be inspected as outlined in "Preventive Maintenance Services, Quarterly" (para 37) and operated long enough to assure complete lubrication of bearings. After each inspection period, the welding machine will be represerved as outlined in paragraph 76.

CHAPTER 5

DIRECT AND GENERAL SUPPORT AND DEPOT MAINTENANCE INSTRUCTIONS

Section I. GENERAL

78. Scope

a. These instructions are published for the use of direct and general support and depot maintenance personnel maintaining the P&H Model W300 MG Welding machine. They provide information on the maintenance of the equipment which is beyond the scope of the tools, equipment, personnel, or supplies normally available to using organizations.

b. The direct reporting of errors, omissions, and recommendations for improving this manual is authorized and encouraged. DA Form 2028 (Recommended Changes to DA Publications) will be used for reporting these improvements. This form will be completed in triplicate, using pencil, pen, or typewriter. The original and one copy will be forwarded

direct to the Commanding General, U.S. Army Mobility Equipment Center, ATTN: SMOME-MMP, P. O. Drawer 58, St. Louis, Mo. 63166. One information copy will be provided to the individual's immediate supervisor.

c. Report all equipment improvement recommendations as prescribed by TM 38-750.

79. Record and Report Forms

For record and report forms applicable to field and depot maintenance, refer to TM 38-750.

Note. Applicable forms, excluding Standard Form 46 which is carried by the operator, will be kept in a canvas bag mounted on the equipment.

Section II. DESCRIPTION AND DATA

80. Description

A general description of the welding machine, the location and description of the identification and instruction plates are contained in chapter 1.

Lubrication Sealed bearings
Duty classification 60%
Degree of enclosure Full
Drive Direct
Type..... Induction motor
Temperature rise..... 50°C. (Centigrade)

81. Tabulated Data

a. General. This paragraph contains all the overhaul data pertinent to direct and general support and depot maintenance personnel. A wiring diagram (fig. 16) is also included.

b. Generator Classification and Rating.
Rating 300 amperes
Voltage 220/440
Phase..... 3 phase
Frequency 60 cycle
Cooling Fan


c. Exciter Classification and Rating.

Type..... Self-excited
Rated speed.....3,500 rpm (revolutions per minute)
Field winding..... Shunt
Cooling Fan
Duty classification 60%
Degree of enclosure Full
Temperature rise50°C
Mounting.....Integral

d. Generator Repair and Replacement Standard.

(1) Type of winding--armature.
 Number of poles..... 2
 Shots per core..... 38
 No..... (160 pieces
 Lamination..... (0.025 inches thick
 Diameter..... 7.5


Bars..... 38
 Coils..... 38-2 Cond/coil
 Turns..... 1
 Wire..... No. 61/2
 Wedge form..... Rectangular
 Span..... 18 and 20 slots




A - GENERATOR CONNECTION DIAGRAM

MEC 3431-217-15/16 ①


Figure 16. Electrical wiring diagrams.





220 OR 230 VOLTS 9 LEAD STRATOR PARALLEL DELTA



NOTE: FOR 440 OR 460 VOLTS,
CONNECT LEAD J1 TO
"HIGH" TERMINAL



440 OR 460 VOLTS 9 LEAD STRATOR SERIES DELTA



- L1
- L2 3 PHASE POWER INPUT
- L3
- C1 - CONTACTOR CONTROL
- J1 - JUMPER LEAD FOR 220/440 OPERATION CONTACTOR COIL
- C2 - CIRCUIT TERMINAL
- T1 - THRU - INDUCTION MOTOR STATOR WINDING LEADS
- T9
- OL - CONTACTOR OVERLEAD RELAY CONTACT

B - MOTOR AND STARTER DIAGRAM

MEC 3431-217-15/16 ②

Figure 16-Continued.

Groups 38
Pounds..... 13.5 lb. (coils)
(2) Type of winding-shunt.
Poles.....2 main, 2 cross
Used with arm2100F43
Volts.....7 min 14 max 2.5 min 6 max
Amps 6.8 13.5 6.8 13.5
Turns250 112
Wire..... No. 13 1/2 rd No. 13 1/3 rd
Pounds 4.72 lb. 2.05 lb.

(3) Type of winding-Stator.

Volts.....220/440
Phase..... 3
Cycles..... 60
Poles..... 2
RPM.....3500
Slots..... 48
Turns 12 per coil

Wire.....No. 17 1/2 heavy
Coils.....48 total
Pounds..... 14.8 lb. (coils)
e. Nut and Bolt Torque Data.

Table 4. Torque Wrench Tensions

Diameter	Foot-pounds
3/8 in.....	60-70
7/16 in.....	75-85
1/2 in.....	95-105
9/16 in.....	125-135
5/8 in.....	150-160
11/16 in.....	195-200
3/4 in.....	210-230
3/16 in.....	230-250
7/8.....	245-275
1 in.....	285-315
1 1/8.....	325-250

f. Repair and Replacement Standards. Table 5 lists manufacturer's sizes, tolerances, desired clearances, and maximum allowable wear and clearances.

Table 5. Repair and Replacement, Standards

Component	Manufacturer's dimensions and tolerances in inches		Desired clearance		Maximum allowable wear and clearance
	Minimum	Maximum	Minimum	Maximum	
Bearing (motor end)	I.D. 1.7717 in.-.0005 in. O.D. 3.9370 in.-.0006 in.	+ .0000 in. + .0000 in.			
Bearing (generator end)	I.D. 1.1811 in.-.0004 in. O.D. 2.8346 in.-.0005 in.	+ .0000 in. + .0000 in.	N/A-Because bearings are cushion mounted		
Shaft seats (motor end) for (generator)	1.7718 in.	1.7721 in.			
Bearing (end)	1.1812 in.	1.1815 in.			

CHAPTER 6

GENERAL MAINTENANCE INSTRUCTIONS

Section I. SPECIAL TOOLS AND EQUIPMENT

82. Special Tools and Equipment

No special equipment is required by direct and general support and depot maintenance personnel for performing maintenance on the welding machine.

83. Direct and General Support and Depot Maintenance Repair Parts

Direct and general support and depot maintenance repair parts are listed in appendix IV.

84. Specially Designed Tools and Equipment

No specially designed tools or equipment are required by direct and general support and depot maintenance personnel performing maintenance on the welding machine.

Section II. TROUBLESHOOTING

85. General

This section provides information useful in diagnosing and correcting unsatisfactory operation or failure of the welding machine or its components.

Each trouble symptom stated is followed by a list of probable causes of trouble. The possible remedy recommended is described opposite the probable cause.

86. Welding Will Not Start (Starter Not Operating)

<i>Probable cause</i>	<i>Possible remedy</i>
Defective operating coil	Replace (para 92).

87. Starter Chatters

<i>Probable cause</i>	<i>Possible remedy</i>
Power supply inadequate	Provide power supply which will provide adequate voltage under load.
Low line voltage	Check power source and increase voltage.

88. Welder Will Not Start

<i>Probable cause</i>	<i>Possible remedy</i>
Power source line circuit single-phased	Replace fuse; repair open line.
Starter single-phased	Check motor phase voltages.
Open circuit in windings	Repair or replace stator (para 93).

89. Welder Starts but Will Not Deliver Welding Current

<i>Probable cause</i>	<i>Possible remedy</i>
Series field and armature circuit open	Check with test lamp or bell ringer.
Wrong driving speed	Check generator nameplate against speed of motor.
Dirt grounding field coils.....	Clean and re-insulate (para 93).

CHAPTER 7

REPAIR INSTRUCTIONS

Section I. CONTROL PANEL AND COMPONENTS

90. Control Panel Assembly

a. General. The control panel assembly is a part of the machine housing and contains all controls, switches, and gauges of the welding machine.

b. Removal. Remove control panel (para 54).

c. Disassembly. Disassemble control panel in numerical sequence shown in figure 17.

d. Cleaning, Inspection, and Repair.

(1) Clean all parts in an approved cleaning solvent and dry thoroughly.

(2) Clean switches with compressed air. Inspect panel for dents and cracks. Straighten panel if dented or warped. Replace a damaged or defective panel as necessary.

(3) Inspect meters and gauges for cracked or defaced dials. Replace damaged or defective parts.

(4) Inspect electrical terminals and wiring for corrosion and general condition. Replace any defective parts.

(5) Inspect rheostat and switches for pitted or corroded contacts and general condition. Replace damaged or defective parts as necessary.

e. Reassembly. Reassemble control panel assembly in reverse order of numerical sequence as shown in figure 18.

f. Installation. Install control panel (para 54).

91. Electrode Selector and Polarity Reversing Switches

a. Disassembly. Disassemble the electrode selector and polarity reversing switches as shown in figure 17.

b. Cleaning, Inspection, and Repair.

(1) Clean all parts in an approved cleaning solvent and dry thoroughly.

(2) Inspect contact blades for burnt or corroded condition. Replace damaged or defective parts as necessary.

c. Reassembly. Reassemble the electrode and polarity reversing switches in reverse order as shown in figure 17.

92. Starter Assembly

a. Disassembly. Disassemble the starter in numerical sequence as shown in figure 18.

b. Cleaning, Inspection, and Repair.

(1) Clean all parts in an approved cleaning solvent and dry thoroughly.

(2) Inspect all parts for defects and damage. Replace or repair defective or damaged parts.

c. Reassembly. Reassemble starter in reverse order of the numerical sequence shown in figure 18.

Section II. MOTOR-GENERATOR

93. General

The motor-generator is an electric alternating current unit with a direct current output. The unit is rated at a nominal 300 amperes at a 60 percent duty cycle. The motor-generator set should be placed on a sturdy bench, at a convenient height for disassembly, and located so a suitable lifting device can be operated over the unit. Vertical assembly is recommended for the convenience it provides, and minimizes the danger of bearing damage.

94. Removal

- a. Remove the welding machine housing (para 54).
- b. Remove attaching hardware and remove motor-generator from truck frame.

95. Disassembly

Disassemble the motor-generator in numerical sequence as shown in figure 19.

Note. The rubber air seals between the fan housing and the magnet frame must be placed when reassembling to assure proper air flow. The reactor air baffle must be replaced to provide proper cooling of the coils.

Remove the armature and fan assembly as a unit, taking special care to avoid damaging the commutator end bearing. If bearings need replacing a bearing puller that presses against the inner race should be used. If it is necessary to remove a bearing by pulling on the outer race, it is imperative that a new bearing be replaced. If it is necessary to replace a coil, preheating the magnet frame to 1500 F. maximum, will help to loosen the varnish and make disassembly easier. The coil and pole piece assembly can be pushed directly out of the magnet frame. It will be necessary, before reassembly, to clean

all varnish off the pole piece and off the internal dovetail of the magnet frame.

96. Cleaning, Inspection, and Repair

a. Clean all parts in an approved cleaning solvent and dry thoroughly. Loose dirt can be removed from the windings with compressed air or vacuum. Oil or grease mixed with dirt can be dissolved with an approved cleaning solvent and then blown out. After cleaning, dry by heating at 900 to 1000 C. for 2 hours.

b. The commutator should be cleaned and, if worn in grooves, it should be turned down smooth, and the mica undercut.

c. Inspect brushes and brush holders. Inspect bearings for wear and general condition. Inspect studs and terminals for burned or otherwise damaged threads. Repair or replace defective parts as necessary.

97. Reassembly

Reassemble the motor-generator in reverse order of the numerical sequence shown in figure 19.

Note. An arbor press should be used when replacing bearings. Always press on the inner race. Always replace rubber bearing girdle when replacing bearings.


When replacing brush holders, make certain the insulated bushings are in their correct location. Reseat all brushes after assembly.

98. Installation

a. Install motor-generator on truck with attaching hardware.

b. Install welding machine housing (para 54).


c. Re-check all wiring before starting welding machine.



MEC 3431-217-15/17 ①

1	Machine screw	13	Lockwasher	25	Cable	37	Spacer	49	Lockwasher	61	Handle
2	Plain washer	14	Receptacle	26	Bus bar	38	Front plate	50	Capscrew	62	Handle
3	Spacer	15	Rivet	27	Terminal block	39	Spring washer	51	Bus bar	63	Back plate
4	Stop nut	16	Nameplate	28	Pin	40	Spacer	52	Phillips head screw	64	Shaft
5	Grommet	17	Bushing	29	Handle	41	Shaft insulation	53	Machine screw	65	Nameplate
6	Mounting plate	18	Junction block	30	Capscrew	42	Movable blade	54	Lockwasher	66	Machine screw
7	Machine screw	19	Machine screw	31	Lockwasher	43	Shaft	55	Machine screw	67	Hex nut
8	Voltmeter	20	Hex nut	32	Capscrew	44	Back plate	56	Hex nut	68	Stop-start-switch
9	Ammeter	21	Lockwasher	33	Lockwasher	45	Insulation spacer	57	Lockwasher	69	Hex nut
10	"C" washer	22	Wingnut	34	Plain washer	46	Contact blade	58	Bus bar	70	Lockwasher
11	Switch	23	Jamnut	35	Hex nut	47	Contact blade	59	Rheostat	71	Capscrew
12	Machine screw	24	Capscrew	36	Capscrew	48	Hex nut	60	Pin	72	Bus bar

Figure 17. Control panel assembly, exploded view.




MEC 3431-217-15/17 (2)

- | | | |
|-----------------|-----------------------|--------------|
| 1 Pin | 9 Lockwasher | 17 Jumper |
| 2 Handle | 10 Self-tapping screw | 18 Rheostat |
| 3 Machine screw | 11 Speednut | 19 Connector |
| 4 Lockwasher | 12 Cover | 20 Housing |
| 5 Data plate | 13 Bottom cover | 21 Plug |
| 6 Machine screw | 14 Machine screw | 22 Terminal |
| 7 Plain washer | 15 Hex nut | 23 Terminal |
| 8 Hex nut | 16 Lockwasher | 24 Cable |


Figure 17.-Continued.

AGO 8244A



- | | | | |
|---|----------------|---|---------------|
| 1 | Machine screw | 4 | Coil |
| 2 | Overload block | 5 | Machine screw |
| 3 | Machine screw | 6 | Contacts |

Figure 18. Magnetic starter, exploded view.



MEC 3431-217-15/19

Figure 19. Motor-generator, exploded view.

1	Stop nut	33	Dust cover	64	Terminal
2	Machine screw	34	Bearing, generator end	65	Main coil assembly
3	Shakeproof washer	35	Bearing, sleeve	66	Pole piece (main No. 1)
4	Starter assembly	36	Bearing, griddle	67	Machine screw
5	Bolt	37	Bearing housing	68	Hex nut
6	Lockwasher	38	"C" washer	69	Lockwasher
7	Washer	39	Pipe spacer	70	Sleeving
8	Air tube	40	Pipe coupling	71	Bus bar
9	Grommet	41	Tie rod	72	Terminal
10	Baffle	42	Locknut	73	Cross field coil No. 2
11	Bolt	43	Armature assembly	74	Pole piece (cross No. 2)
12	Lockwasher	44	Machine screw	75	Pole piece (main No. 2)
13	Washer	45	Brush spring	76	Clamp
14	Spacer	46	Exciter brush	77	Bus bar
15	Spacer	47	Brush holder	78	Collar assembly
16	Stator assembly	48	Bolt	79	Commutator coil
17	Rotor assembly	49	Lockwasher	80	Pole piece (cross No. 1)
18	Fan housing	50	Bus bar	81	Field coil insulation
19	Air seal	51	Brush spring	82	Cross field coil No. 1
20	Bearing, motor end	52	Main brush	83	Magnet frame
21	Bearing sleeve	53	Brush holder	84	Shunt
22	Bearing griddle	54	Capscrew	85	Base plate
23	Fan	55	lockwasher	86	Angle (2)
24	Key	56	Terminal	87	Bolt (6)
25	Key	57	Reactor core and coil assembly	88	Lockwasher (6)
26	Bolt	58	Screw	89	Nut (6)
27	Air tube	59	Lead clamp	90	Bolt (2)
28	Bolt	60	Field coil insulation	91	Lockwasher (2)
29	Lockwasher	61	Side insulation	92	Nut (2)
30	Plain washer	62	Sleeving		
31	Insulation bushing	63	Connector		
32	Insulation plate				

Figure 19-Continued.

APPENDIX I

REFERENCES

1. Dictionaries of Terms and Abbreviations

AR 320-5 Dictionary of United States Army Terms.
AR 320-50 Authorized Abbreviations and Brevity Codes.

2. Fire Protection

SB 5-111 Extinguisher, Fire, Monobromotrifluormethane (CB:Br) Charged.
TM 5-687 Repair and Utilities: Fire Protection Equipment and Appliances: Inspections, Operations, and Preventive Maintenance.

3. Operating Instructions

4. Painting

TM 9-213 Painting Instructions for Field Use.

5. Preventive Maintenance

AR 750-5 Organization, Policies and Responsibilities for Maintenance Operation.
TB ENG 347 Winterization Techniques for Engineer Equipment.
TM 5-764 Electric Motor and Generator Repair.
TM -207 Operation and Maintenance of Ordnance Material in Extreme Cold (0° to -65°F.).
TM 9-6140-200-15 Operation and Organizational, Field and Depot Maintenance: Storage Batteries, Lead-Acid Type.
TM 38-750 Army Equipment Record Procedures.

6. Publication Indexes

DA Pam 108-1 Index of Army Motion Pictures, Film, Strips, Slides, Phono-Recordings.
DA Pam 310-1 Index of Administrative Publications.
DA Pam 310-2 Index of Blank Forms.
DA Pam 310-3 Index of Doctrinal, Training, and Organizational Publications.
DA-Pam 310-4 Index of Technical Manuals, Technical Bulletins, Supply Manuals (types 4, 6, 7, 8, and 9), Supply Bulletins, Lubrication Orders, and Modification Work Orders.
DA Pam 310-5 Index of Graphic Training Aids and Devices.
DA Pam 310-25 Index of Supply Manuals-Engineer Type Items.

AGO 8244A

7. Shipment and Limited Storage

AR 743-505	Limited Storage of Engineers' Mechanical Equipment.
TM 38-230	Preservation, Packaging, and Packing of Military Supplies and Equipment.

8. Supply Publications

FSC C9100-IL	FSC Group 91; Fuels, Lubricants, Oils, and Waxes.
--------------	---

9. Training Aids

FM 5-25	Explosives and Demolitions.
FM 215	Military Training Management.
FM 21-6	Techniques of Military Instruction.
FM 21-30	Military Symbols.

APPENDIX II

MAINTENANCE ALLOCATION. CHART

Section I. INTRODUCTION

1. General

This appendix contains the explanations of all the maintenance and repair functions authorized the various maintenance levels. Section II MAC (maintenance allocation chart) designates overall responsibility for the performance of maintenance operations. The implementation of maintenance tasks upon the end item or component will be consistent with the assigned maintenance operations.

2. Maintenance Operations

Maintenance is any section taken to keep material in a serviceable condition or to restore it to serviceability when it is unserviceable. Maintenance of material includes the following:

a. Service. Operations required periodically to keep the item in proper operating condition, i.e., to clean, preserve, drain, paint, and replenish fuel, lubricants, hydraulic, and deicing fluids or compressed air supplies.

b. Adjust. Regulate periodically to prevent malfunction. Adjustments will be made commensurate with adjustment procedures and associated equipment specifications.

c. Aline. Adjust two or more components of an electrical or mechanical system so that their functions are properly synchronized or adjusted.

d. Calibrate. Determine, check, or rectify the graduation of an instrument, weapon, or weapons system or components of a weapons system.

e. Inspect. Verify serviceability and detect incipient electrical or mechanical failure by close visual examination.

f. Test. Verify serviceability and detect incipient electrical or mechanical failure by measuring the mechanical or electrical characteristics of the item and comparing those characteristics with authorized standards. Test will be made commensurate with test procedures and with calibrated tools and/or test equipment referenced on the MAC.

g. Replace. Substitute serviceable components, assemblies, and subassemblies for unserviceable counter parts or remove and install the same item when required for the performance of other maintenance operations.

h. Repair. Restore to a serviceable condition by replacing unserviceable parts or by any other action required using available tools, equipment, and skills to include welding, grinding, riveting, straightening, adjusting, and facing.

i. Overhaul. Restore an end item to completely serviceable condition as prescribed by serviceability standards developed and published by national maintenance points having maintenance responsibility for the item. This is accomplished through employment of the technique of "Inspection and repair only as necessary" (IROAN). Maximum use combined with minimum disassembly during overhaul, "overhaul" may be assigned to any level of maintenance except organizational, provided the time, tools, equipment, repair parts authorization, and technical skills are available at that level. Normally, overhaul as applied to end items, is limited to depot maintenance level.

j. Rebuild. Restore to a condition comparable to new, by disassembling to determine the condition of each component part and reassembly using serviceable, rebuilt, or new assemblies, subassemblies, and parts.

AGO 8244A

3. Explanation of Columns
(Sec II)

a. *Functional Group Number.* The functional group is a numerical group set up on a functional basis. The applicable functional grouping indexes (obtained from TB 750-93-1 Functional Grouping Codes) are listed on the MAC in the appropriate numerical sequence. These indexes normally are set up in accordance with their function and proximity to each other.

b. *Component Assembly Nomenclature.* This column contains the functional grouping index heading, subgroups heading, and a brief description of the part.

c. *Essentiality.* The essentiality. column reflects whether or not an assembly, or repair part, is combat essential to the tactical use of the end item. The letter E in this column indicates the Items are combat essential.

d. *Maintenance Operations and Maintenance Levels.* This column contains the various maintenance operations A through J service, adjust, etc. A symbol indicating the maintenance level placed in the

appropriate column in lines with an indicated maintenance operation authorizes that level to perform the function. The symbol indicates the lowest level of maintenance responsible for performing the function, but does not necessarily indicate repair parts stockage at that level. Higher levels of maintenance are authorized to perform the indicated functions of lower levels. The symbol designation for. The various maintenance levels are as follows:

- O/C-Operator or Crew
- O -Organizational
- DS -Direct Support
- GS -General Support
- D -Depot

Section II. MAINTENANCE ALLOCATION CHART

Functional group No.	Component assembly nomenclature	Essentiality	Maintenance operations					Maintenance levels					Note ref			
			A	B	C	D	E	F	G	H	I	J	K	L		
			Service	Adjust	Align	Calibrate	Inspect	Test	Replace	Repair	Overhaul	Rebuild	T&TE rgmt	Remarks		
10 1000	FRONT AXLE Front Axle Assembly Tongue.....							O								
11 1100	REAR AXLE Rear Axle Assembly							O								
13 1311	WHEELS AND TRACKS Wheel Assembly.....							O								
15 1501	FRAME, TOWING ATTACH- MENTS, AND DRAWBARS Frame Assembly							O	GS							
22 2202	ACCESSORY ITEMS Accessory Items Remote control assembly							O	O							
	Cables.....							O	O							
	Holder, publication							O								
2210	Data Plates Plate, data.....								DS							
	Plate, identification.....								O							
	Diagram, wiring: instruction sheet.....								O/C							

Section II. MAINTENANCE ALLOCATION CHART-Continued

Functional group No.	Component assembly nomenclature	Essentiality	Maintenance operations						and Maintenance levels					Note ref			
			A	B	C	D	E	F	G	H	I	J	K	L			
			Service	Adjust	Align	Calibrate	Inspect	Test	Replace	Repair	Overhaul	Rebuild	T&TE rgmt	Remarks			
26	ACCESSORIES, PUBLICATIONS																
2605	Publications																
	Publications.....										O/C						
44	WELDING EQUIPMENT																
4400	Arc Welders																
	Welder assembly.....		O/C							O		O	D				
4401	Rotor Assembly																
	Armature assembly.....									GS	GS	D					
	Armature, exciter.....									DS	DS						
4402	Stator Assembly																
	Stator assembly, motor.....									GS	GS	D					
	Coil set, exciter field.....									DS	DS						
	Coils, generator stator.....									GS	GS						
	Poles, generator.....										GS						
	Poles, exciter field.....										DS						
	Cable and wiring.....										GS	O					
4403	Brush Holder Assembly																
	Brushes.....										O						
	Bracket, main brush holder.....										GS						
	Brush holder assemblies.....										O	O					
4405	Frame Support, Housing Carrier																
	Bearings, ball.....		O								GS						
	Frame assembly, generator.....										D						
	Covers.....										O						
4406	Ventilating, Cooling System																
	Fan, cooling.....										DS						
4407	Control Panels, Housing																
	Control box assembly.....										DS						
	Wiring.....										O						
	Meter; shunt; receptacle.....										O						
4408	Connecting Devices																
	Terminal assembly.....										O						
	Cable assembly.....										O	O					
	Bus bars.....										O						
4409	Protective Devices, Electrical																
	Thermostat.....										GS						
4410	Switching Control																
	Circuit breaker; switches.....		O														
	Starter, assembly.....											DS					
	Selector switch assembly.....											DS					
	Push button switch.....											DS					
4411	Resistor Components																
	Resistor.....										O	O					
	Rheostat.....											O					
76	FIRE FIGHTING EQUIPMENT																
7603	COMPONENTS																
	Extinguisher, fire.....										O						

**APPENDIX III
BASIC ISSUE ITEMS LIST**

Section I. INTRODUCTION

1. General

Section II lists the accessories, tools, and publications required for maintenance and operation by the operator, initially issued with, or authorized for the Harnischfeger Model W300 MG Welding Machine.

2. Explanation of Columns Contained in Section II

a. Source Codes. The information provided in each column is as follows:

- (1) *Matériel*. This column lists the basic materiel code number of the supply service assigned responsibility for the part. Blank spaces denote supply responsibility of the preparing agency. General Engineer Supply parts are identified by the letters GE in parentheses, following the nomenclature in the description column. Other basic materiel code numbers are -

9-Ordnance Materiel

10-Quartermaster Materiel

(2) *Source*. The selection status and source of supply for each part are indicated by one of the following code symbols:

- (a) P-applied to high-mortality repair parts which are stocked in or supplied from the supply service depot system, and authorized for use at indicated maintenance level.
- (b) PI-applied to repair parts which are low-mortality parts, stocked in or supplied from supply service depots, and authorized for installation at indicated maintenance level.
- (c) X2-applied to repair parts which 50 are not stocked. The indicated maintenance echelon requiring such repair parts will attempt to obtain them through cannibalization; if not obtainable through

cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.

- (3) *Maintenance*. The lowest maintenance level authorized to use, stock, install, or manufacture the part is indicated by the following code symbol:

O-Organizational Maintenance

- (4) *Recoverability*. When no code is shown in the recoverability column the part is considered expendable.

b. *Federal Stock Number*. The Federal stock number will be shown in this column, and will be used for requisitioning purposes.

c. *Description*.


- (1) The item name and a brief description of the part are shown.

- (2) A five-digit Federal supply code for manufacturers and/or other supply services is shown in parentheses followed by the manufacturer's part number. This number will be used for requisitioning purposes when no Federal stock number is indicated in the Federal stock number column.

Example: (08645) 86543.

- (3) The letters GE, shown in parentheses immediately following the description, indicates General Engineer supply responsibility for the part.

d. *Unit of Issue*. If no abbreviation is shown in this column, the unit of issue is "each."



MEC 3431-217-15/20

- | | | | |
|---|----------------------------|----|-------------------|
| 1 | Ground cable assembly | 9 | Rheostat assembly |
| 2 | Cable | 10 | Publications case |
| 3 | Clamp | 11 | Manual |
| 4 | Lug | 12 | Hammer |
| 5 | Electrode cable and holder | 13 | Pliers |
| 6 | Cable | 14 | Screwdriver |
| 7 | Electrode holder | 15 | Adjustable wrench |
| 8 | Lug | 16 | Fire extinguisher |

Figure 20. Basic issue items.

e. *Quantity Authorized.* This column lists the quantities of repair parts, accessories, tools, or publications authorized for issue to the equipment operator or crew as required.

f. *Quantity Issued with Equipment.* This column lists the quantities of repair parts, accessories, tools, or publications that are initially issued with each item of equipment. Those indicated by an asterisk are to be requisitioned through normal supply channels as required.

g. *Illustrations.* This column is subdivided into two columns which provide the following information:

(1) *Figure number.* Provides the identifying number of the illustration.

(2) *Item number.* Provides the referenced number for the parts shown in the illustration.

3. Index to Federal Supply Code for Manufacturers

00779 Amp Inc., Harrisburg, Pa.

27315 Harnischfeger Corporation, Milwaukee, Wis.

Section II. BASIC ISSUE ITEMS LIST

Source codes				Federal stock No.	Description	Unit of Issue	Quantity authorized	Quantity issued with equipment	Illustration	
Materiel	Source	Maintenance	Recoverability						Figure	Item
					31-BASIC ISSUE ITEMS, MANUFACTURER INSTALLED 3100-BASIC ISSUE ITEMS MANUFACTURER OR DEPOT INSTALLED					
	P1	0		3439-603-4780	CABLE ASSEMBLY: ground (Repair Parts Manual Group 2202).		1	1	20	1
	P1	0		3439-603-4781	CABLE ASSEMBLY: electrode (Repair Parts Manual Group 2202).		1	1	20	5
9	X2	0			ELECTRODE HOLDER: (00779) A-38 (Repair Parts Manual Group 2202).		1	1	20	7
	X2	0			REMOTE CONTROL ASSEMBLY: 9279 E150 (27315) (Repair Parts Manual Group 2202).		1	1	20	9
10	P	0		7520-559-9618	CASE: maintenance and operational manuals, cotton duck, water-repellent, mil-dew-resistant, MIL-B-117438.		1	1	20	10
12					DEPARTMENT OF THE ARMY, OPERATOR, ORGANIZATIONAL, DIRECT AND GENERAL SUPPORT AND DEPOT MANUAL, INCLUDING REPAIR PARTS, TM 5-3431-217-15, 32-BASIC ISSUE ITEMS, TROOP INSTALLED		2	2		
10	P	0		5120-252-3917	3200-BASIC ISSUE ITEMS, TROOP INSTALLED OR AUTHORIZED		1	(*)	20	12
10	P	0		5120-223-7390	HAMMER: machinist, 1-lb ball peen		1	(*)	20	13
10	P	0		5120-278-1283	PLIERS: combination, slip joint w/cutter		1	(*)	20	14
					SCREWDRIVER: 6-in. blade, 3/4 in. tip.					

AGO 8244A

Section II. BASIC ISSUE ITEMS LIST-Continued

Materiel	Source codes			Federal stock No.	Description	Unit of Issue	Quantity authorized	Quantity issued with equipment	Illustration	
	Source	Maintenance	Recoverability						Figure	Item
10	P	0		5120-264-3795	WRENCH, ADJUSTABLE: open end, 6 in.	1		(*)	20	15
10	P1	0		4210-893-1092	EXTINGUISHER: fire, dry chemical, charged, hand, pressurized w/dry air or nitrogen gas; w/pressure gauge; squeeze grip control; steel cylinder; enameled red; factory mutual or UL approved, class 4-B, C; 21/2 lb; w/ universal bracket (Repair Parts Manual Group 7603).					

* Requisition as required.

**APPENDIX IV
REPAIR PARTS LIST**

Section I. INTRODUCTION

1. General

a. This manual lists repair parts for organizational, direct and general support, and depot maintenance. It indicates the quantity of repair parts required to be stocked by organizational maintenance as their prescribed load. It indicates the guide quantity factors to be used for initial repair parts stockage by direct and general support, and recommends quantities of repair parts for depot maintenance. Information and data contained herein serve as requisitioning reference material, and as a guide to determine stockage quantities of repair parts.

b. Price information for stock-type repair parts may be obtained from applicable Department of the Army type 2-series supply manuals and/or Supply Management Data and Price List (ML) of the Department of Defense Section of the Federal Supply Catalog.

c. Repair parts lists are arranged as follows:

- (1) Individual parts and major assemblies are listed alphabetically by item name within the functional groups.
- (2) Assembly components and subassemblies are indented and listed alphabetically by item name under major assemblies.
- (3) Bulk material is listed in functional group 9501.

d. Allowances are bases on 1,500 hours operational per year.

2. Explanation of Repair Parts and Prescribed Load Listing (Table 1)

a. *Source Codes.* This column is subdivided into four columns. The titles and information provided in each column are as follows:

(1) *Materiel.* This column lists the basic materiel code number of the supply service assigned responsibility for the part. Blank spaces denote supply responsibility of the preparing agency.

Other basic materiel code numbers are -

9-Ordnance Materiel

11-Signal Materiel

(2) *Source.* The selection status and source of supply for each part are indicated by one of the following code symbols:

(a) P-applied to high-mortality repair parts which are stocked in or supplied from the supply service depot system and authorized for use at indicated maintenance levels.

(b) P1-applied to repair parts which are low-mortality parts, stocked in or supplied from supply service depots, and authorized for installation at indicated maintenance levels.

(c) M-applied to repair parts which are not procured or stocked but are to be manufactured at indicated maintenance levels.

(d) X1-applied to repair parts which are not procured or stocked, the requirement for which will be supplied by use of next higher assembly or components.

(e) X2-applied to repair parts which are not stocked. The indicated maintenance level requiring such repair parts will attempt to obtain them through cannibalization; if not obtainable through cannibalization,

AGO 8244A

such repair parts will be requisitioned with supporting justification through normal supply channels.

(3) *Maintenance.*

- (a) The lowest maintenance level authorized to manufacture, assemble, and/or install the part is indicated by one of the following code symbols:

O-Organizational Maintenance
F-Direct Support Maintenance (DS)
H-General Support Maintenance (GS)
D-Depot Maintenance

- (b) This column is blank when components of kits or sets are listed that are not applicable to the item of equipment, or when an item is source coded X1.

(4) *Recoverability.* Repair parts and/or tool and equipment items that are recoverable are indicated by one of the following code symbols:

- (a) R-applied to repair parts and assemblies which are economically repairable at direct and general support maintenance activities and normally are furnished by supply on an exchange basis.

- (b) U-applied to repair parts specifically selected for salvage by reclamation units because of precious metal content, critical materials, high-dollar value reusable casings, castings, and the like.

Note. When no code is shown in the recoverability column the part is considered expendable.

- b. *Federal Stock Number.* The Federal stock number will be shown in this column and will be used for requisitioning purposes.

c. *Description.*

- (1) The item name and a brief description of the part are shown.
- (2) A five-digit Federal supply code for manufacturers and/or other supply service is shown in parentheses, followed by the manufacturer's part number. This number will be used for requisitioning purposes

when no Federal stock number is indicated in the Federal stock number column.

Example: (08645) 86453.

- (3) Repair part quantities included in kits, sets, and assemblies, that differ from the actual quantity used in this specific end item, are listed in parentheses.

Note. When a minimum stockage sufficient to repair one item and/or assembly is authorized, this quantity will be indicated in the Description column with the notation "minimum stockage of ----- is authorized."

- d. *Unit of Issue.* If no abbreviation is shown in this column, the unit of issue is "each."

- e. *Quantity Incorporated in Unit.* The actual number of parts used in the application indicated is shown in this column. A zero (0) is shown when components of kits or sets are listed that are not applicable to this specific end item.

- f. *15-Day Organizational Maintenance Allowance.* Shown for each repair part is either a quantity or an asterisk allocation which indicates the following:

- (1) A guide quantity factor is shown for each repair part authorized to be stocked by organizational maintenance. This quantity is based on past experience with similar items and the latest mortality data for 1,500 hours operation per year. It is the average quantity required to provide one prescribed load for 1-5 and/or 6-10 items of equipment for a 15-day period under average combat conditions.
- (2) The quantity of repair parts authorized for stockage in accordance with the number of prescribed loads authorized by the major commander are determined by using table 1.
- (3) Table 1 is a consolidation of items quantitatively allocated in this manual. Quantities listed are for one prescribed load for a 15-day period. A minimum stockage sufficient to repair one item and/or assembly is authorized (e.g., if 3 belts are required, then

Table 1. Prescribed Load Listing

Federal stock No.	Description	Functional Group	Minimum stockage authorization	Unit of issue	15-day organizational maintenance allowances	
					1-5	6-10
5977-227-6500	BRUSH, ELECTRICAL: main (82214) 549	4403	6		6	12

3 belts are allocated as the min stockage). This quantity will be indicated in the minimum stockage authorization column.

- (4) Units and organizations authorized more than one prescribed load will multiply the quantity listed in the appropriate end item density spread column of 1-5 or 6-10 by the number of prescribed loads.
- (5) When more than 10 equipments require support, multiply the quantity listed in the 6-10 column by the number of equipments and the number of authorized prescribed loads, divide by 10, and round to the nearest whole number.

Example: If the quantity listed in the 6-10 column is 4, the number of equipments is 17, and the number of authorized prescribed loads is 1, the following formula would be used:

$$4 \times 17 \times 1 \div 10 = 6.8$$

The resulting fraction is .08; therefore the authorized stockage is 7.

Example: If the quantity listed in the 6-10 column is 4, the number of equipments is 17, and the number of authorized prescribed loads is 3, the following formula would be used:

$$4 \times 17 \times 3 \div 10 = 20.4$$

The resulting fraction is 0.4; therefore the authorized stockage is 20.

Note. An exception is made for those units and organizations required to have on hand, boxed or packaged prescribed load(s) pursuant to a special mission assignment. Such prescribed load(s) will be computed or selected separately from quantities authorized for stockage at permanent station.

- (6) Repair parts required to perform or organizational maintenance, which are not authorized for stockage are identified by an asterisk, and are to be requisitioned for immediate use only.

- (7) Subsequent changes to allowances will be limited as follows:

- (a) No change in the range of items is authorized. If exception to the prescribed load listing or revision to allowances is considered necessary, a recommendation should be forwarded to the U.S. Army Mobility Equipment Center (para 6).
- (b) Decreases in the stated quantity of items are authorized to a minimum quantity sufficient to repair one item and/or assembly and increases in the stated quantity are authorized for all items when justified by demand and usage experience. Detailed procedures for performing these adjustments are prescribed in AR 735-35.

g. Guide Quantities Per 100 Equipments. Shown for each repair part applicable direct and general support, and/or depot maintenance is either an allowance factor or an asterisk allocation which indicates the following:

- (1) A guide quantity factor is shown for each part authorized to be stocked by direct and general support maintenance and supply support activities, and the number of repair parts recommended for depot maintenance. This factor is based on the latest mortality data for 1,500 hours operation per year and is the average quantity required by the various maintenance activities to provide maintenance and supply support for 100 items of equipment for a 15-day period under average combat conditions.
- (2) The quantities of repair parts authorized for stockage are determined using the following mathematical formula

Quantity of equipment to be supported, multiplied by the listed allowance factor divided by 100.

Fractions derived from the use of the above formula will be rounded to whole numbers as follows: If the result is 1 or more and includes a fraction that is 0.5 or more, the quantity is rounded to the next higher number.

Example: If the number of equipment supported is 30 and the allowance factor for 100 equipments is 5, the following formula would be used:

$$30 \times 5 \div 100 = 1.5$$

The resulting fraction is 0.5; therefore, the stockage is 2. If the result is 1 or more and includes a fraction of less than 0.5, the quantity is rounded to the next lower number. When the computed result is less than 0.5, no quantity is authorized for direct and general support, and depot maintenance.

Example: If the number of equipment supported is 30 and the allowance factor for 100 equipments is 28, the following formula would be used:

$$30 \times 28 \div 100 = 8.4$$

The resulting fraction is less than 0.5; therefore, the stockage is 8.

- (3) In the guide quantity columns for direct and general support maintenance, additional repair parts authorized for use but not for initial stockage, are listed without a guide quantity factor. These items are identified by an asterisk and may be added to or deleted from stock when recorded demand experience justifies a change in stockage objective.
- (4) Parts that may be required for depot maintenance, in addition to those allocated, are identified by an asterisk. These parts are to be requisitioned, when required, if not obtainable from reclamation, fabrication, or local procurement.

h. Direct and General Support Maintenance 15-Day Level.

- (1) *Direct Support (DS).* This column lists the initial guide quantity allowance factors of repair parts authorized for initial stockage by direct support maintenance activities to provide direct support maintenance for Mobility Command equipment and to provide organizational maintenance repair parts for supported units for a 15-day period. Additional repair parts identified by an asterisk are explained in g above. Upon establishment of supply records, recorded demand experience will be used to compute stockage objectives on authorized repair parts. Review of stockage objectives will be performed in the time cycle prescribed by major commanders.
- (2) *General Support (GS).* This column lists initial guide quantity allocation factors of repair parts authorized for initial stockage by general support maintenance activities to provide general support maintenance for Mobility Command equipment for a 15-day period. Additional repair parts identified by an asterisk are explained in g above. Upon establishment of supply records, recorded demand experience will be used to compute stockage objectives on authorized repair parts. Review of the stockage objectives will be performed in the time cycle prescribed by major commanders.
- (3) *Units with TOE capability of performing partial or complete Direct and General Support maintenance for organic Mobility Command equipment.* Units with the TOE capability of performing partial or complete direct and general support maintenance for organic Mobility Command equipment will be authorized to stock direct and/or general support repair parts only when specific agreements are made between the commander of the designated parts supply activity, normally Direct Support Units (DSU) and using unit. Parts so furnished are in addition to the prescribed load and will be adjusted as demands indicate.

AGO 8244A

(4) *Units with TOE Mission to provide maintenance for Mobility Command equipment of supported units.* Units organized under TOE's with the assigned mission to provide direct and general support maintenance for Mobility Command equipment of supported units are authorized to stock direct and general support repair parts. These repair parts will be issued from the appropriate parts supply activity (parts depot and/or DSU). Such stockage is in addition to the prescribed load and will be adjusted as demand indicate.

i. *Depot Maintenance.* This column lists the quantity of repair parts recommended for depot maintenance shops (non-TOE) to provide depot maintenance for 100 equipments. Additional repair parts are allocated by an asterisk, for immediate use only. Explanation of the asterisk allowance is contained in g above.

j. *Illustrations.* This column is subdivided into two columns as follows:

- (1) *Figure number.* Indicates the number of the illustration in which the part is shown.
- (2) *Item number.* Indicates the reference number used to point out the part in the illustration.

3. Abbreviations

ar-----as required
 ft -----feet (foot)
 id-----inside diameter
 in-----inches (es)
 lg-----long (length)
 mtg-----mounting

No----- number (s)
 od----- outside diameter
 rl----- roll
 thd ----- thread (ed) (s)

4. Federal Supply Code for Manufacturers

00761 ----- Burndy Midwest Inc.
 00779 ----- Aircraft Marine Products, Inc.
 02295 ----- General Electric Co. General Purpose Control Department of Switch-gear and Control Division.
 04009 ----- Hart and Hegeman Mfg. Co.
 07707 ----- United Shoe Machinery Corp.
 12946 ----- Neilson Wheel Co.
 15605 ----- Cutler-Hammer Inc.
 21335 ----- Fafnir Bearing Co. The
 27315 ----- Pawling and Harnischfeger Co.
 28250 ----- Heyman Mfg. Co.
 44655 ----- Ohmite Mfg. Co.
 55026 ----- Simpson Electric Co.
 59730 ----- Thomas and Betts Co.
 66289 ----- Wisconsin Motor Corp.
 70485 ----- Atlantic India Rubber Works, Inc.
 71785 ----- Cinch Mfg. Co., Division of United Carr Fastener Corp.
 72962 ----- Elastic Stop Nut Corp. of America.
 78553 ----- Tinnerman Products Inc.
 79497 ----- Western Rubber Co.
 80756 ----- Ramsey Corp.
 81349 ----- Military Specifications
 82214 ----- National Carbon Co.
 83315 ----- Hubbell Corp.
 98124 ----- Hunt Wilde Corp.

CODES			FEDERAL STOCK NUMBER	DESCRIPTION	MANUFACTURER'S CODE PART NO.	UNIT OF ISSUE	QTY INCORPORATED IN UNIT	GUIDE QTY(S) SUPER MAJOR EQUIPS				ILLUST		
MATERIAL	SOURCE	MAINT RECOGNIZABILITY						18 DAYS MAINT.		DEPOT		FIGURE NO.	ITEM NO.	
								ORGAN-IZATIONAL	DS	SS	MAINT.			
			1-5	6-10	100 EQUIPMENTS									
SECTION II - REPAIR PARTS LIST														
GROUP 10-FRONT AXLE 1000- FRONT AXLE ASSEMBLY														
X20				AXLE, FRONT	(27315) 210H18D1		1	*	*	*	*	14	3	
X20				FORK, SWIVEL: front axle	(12946) 8-11X		1	*	*	*	*	14	9	
0	5305-017-9885			SCREW, CAP, HEXAGON HEAD: fork mounting	(27315) 0826V079		1	*	*	*	*	14	8	
0	5310-202-8552			NUT, PLAIN, HEXAGON: fork mtg. screw	(27315) 2145V005		1	*	*	*	*	14	6	
0	5310-010-3323			WASHER, LOCK: fork mtg. screw	(27315) 3616V011		1	*	*	*	*	14	7	
X20				HANDLE, TOWING	(27315) 206F3D1		1	*	*	*	*	14	5	
X20				GRIP, HANDLE	(398124) 1443R		2	*	*	*	*	14	18	
X20				BAG, CLOTH	(227315) 32Z64		1	*	*	*	*	14	21	
X20	5340-598-1357			RING, RETAINING: front axle	(80756) RR675		2	*	*	*	*	14	1	
X20				WASHER, FLAT: front axle	(27315) 3632V008		4	*	*	*	*	14	2	
0				CHAIN: handle retaining			1							
P 0	4010-257-0772			MANUFACTURE FROM: CHAIN, WELDLESS (12 in. required)		FT						(SEE GROUP 9501)	14	20
M 0				HOOKS: handle retaining chain			1							
P 0	950,-1C6-9137			MANUFACTURE FROM: WIRE, STEEL, CARBON (6 in. required)		RL						(SEE GROUP 9501)	14	19
GROUP 11 - REAR AXLE 1100 - REAR AXLE ASSEMBLY														
X20				AXLE, REAR	(27315) 21011LD2		1	*	*	*	*	14	16	
X20	5340-598-1357			RING, RETAINING: rear axle	(80756) RR675		4	*	*	*	*	14	1	
X20				WASHER, FLAT: rear axle	(27315) 3632V008		8	*	*	*	*	14	2	
GROUP 13 - WHEELS AND TRACKS 1311 - WHEEL ASSEMBLY														
X20				WHEEL, RUBBER TIRE: portable mount	(12946) A116N		4	*	*	*	*	14	4	
GROUP 15 - FRAME, TOWING ATTACHMENTS, AND DRAWBARS 1501 - FRAME ASSEMBLY														
X20				PORTABLE MOUNT ASSEMBLY	(27315) 2100.141?26		1	*	*	*	*	14		
X20				FRAME: portable mount	(27315) 216793D5		1	*	*	*	*	14	17	
X20				PLATE, INSTRUCTION: portable mount assembly	(27315) 2321		1					(SEE GROUP 9501)	14	15
X20				CLIP, SPRING: towing handle retraining	(66289) PK87		1	*	*	*	*	14	13	
0	5305-275-9838			SCREW, MACHINE: clip mounting	(27315)		1	*	*	*	*	1	12	
0	5310-010-9084			NUT, PLAIN, HEXAGON: clip mtg. screw	(27315)		1	*	*	*	*	14	10	
0	5310-010-3319			WASHER, LOCK: clip mtg. Screw	(27315)		1	*	*	*	*	14	11	
GROUP 22 - ACCESSORY ITEMS 2202 - ACCESSORY ITEMS														
M 0				CABLE ASSEMBLY: ground, with clamp	(27315) 9Z79F295-1		1					20	1	
P 0	6145-174-1123			MANUFACTURE FROM: WIRE, ELECTRICAL (50 ft required)		FT						(SEE GROUP 9501)	20	2
X20				CLAMP, GUARD: ground cable	(27315) 2952D3		1	*	*	*	*	20	3	
X20				TERMINAL, LUG: ground cable	(00779) 325405		2	*	*	*	*	20	4	
M 0				CABLE ASSEMBLY: electrode, with holder	(27315) 9279296-2		1					20	5	
P 0	6145-174-1123			MANUFACTURE FROM: WIRE, ELECTRICAL (50 ft required)		FT						(SEE GROUP 9501)	20	6
X20				HOLDER, ELECTRODE: cable	(00779) A38		1	*	*	*	*	20	7	
X20				TERMINAL, LUG: cable	(00779) 325405		2	*	*	*	*	20	8	
X20				RHEOSTAT ASSEMBLY: remote control	(27315) 92793150		1	*	*	*	*	20	9	
X20	5905-646-7687			RHEOSTAT: remote control	(44655) 40513		1	*	*	*	*	17	18	
X20				CABLE ASSEMBLY: remote control	(27315) 279421		1	**	*	*	*	17B		
X1				WIRE ELECTRICAL: no. 14-3 (51 ft 6 in. required)	(81349) MIIC3432B		1					17B	24	
X1				TERMINAL, LUG: remote control cable	(00779) 41332		2	*	*	*	*	17B	22	
X1				TERMINAL, LUG: remote control cable	(00779) 41333		1	*	*	*	*	17B	23	
X1				PLUG, ELECTRICAL: remote control cable	(04009) 7411		1	*	*	*	*	17B	21	
X20	5935-062-5124			CLAMP, CABLE, ELECTRICAL:	(59730) 3303		1	*	*	*	*	17B	19	
X20				HANDLE: rheostat control	(27315) 206X5D1		1	*	*	*	*	17B	2	
X20				PIN, ROLL: handle mtg.	(72962) 59-028-125-625		1	*	*	*	*	17B	1	
X20				PLATE, JUMPER: rheostat	(27315) 279H251D1		1	*	*	*	*	17B	17	
X20				PLATE, INSTRUCTION: rheostat remote control	(27315) 232H95		1					(SEE GROUP 2210)	17B	5

CODES			FEDERAL STOCK NUMBER	DESCRIPTION	MANUFACTURER'S CODE PART NO.	UNIT OF ISSUE	QTY INCORPORATED IN UNIT	GUIDE QTY(S) PER MAJOR EQUIPS					ILLUST	
MATERIAL	SOURCE MAINT	RECOVERABILITY						18 DAYS MAINT.					FIGURE NO.	ITEM NO.
								ORGAN-IZATIONAL		DEPOT				
								1-5	6-10	100	SS	MAINT.		
2202 - ACCESSORY ITEMS (cont)														
X20				COVER: rheostat	(27315)	214F2501	1	*	*	*	*	*	17B	12
X20				HOUSING: rheostat	(27315)	214H89	1	*	*	*	*	*	17B	20
X20				COVER BOTTOM: rheostat	(27315)	214H90	1	*	*	*	*	*	17B	13
0	5310-286-1495			SCREW, MACHINE: rheostat instruction plate mtg			2		(SEE GROUP	2210)			17B	3
0	5310-010-3319			WASHER, LOCK: rheostat instruction plate mgt. screw			2		(SEE GROUP	2210)			17B	4
0	5310-202-8549			SPEEDNUT: housing cover screw	(27553)	01793-10Z4	8	*	*	*	*	*	17B	11
0	5305-282-1063			SCREW, THREAD FORMING: housing cover	(27315)	20Z4OD14	8	*	*	*	*	*	17B	10
X20	3815-425-7821			WASHER, FLAT: rheostat housing cover			9	*	*	*	*	*	17B	7
0	5305-010-0751			SCREW, MACHINE: plate mtg			3	*	*	*	*	*	17B	14
0	5310-050-3568			NUT, PLAIN, HEXAGON: plate mtg			3	*	*	*	*	*	17B	15
0	5310-010-6496			WASHER LOCK: plate mtg screw			3	*	*	*	*	*	17B	16
0	5305-86-1934			SCREW, MACHINE: rheostat cover mtg.			1	*	*	*	*	*	17B	6
X20	3815-425-7821			WASHER, LOCK: rheostat assembly			1	*	*	*	*	*	17B	9
0	5310-012-0614			NUT, PLAIN, HEXAGON: rheostat assembly			1	*	*	*	*	*	17B	8
X20				BRACKET: remote control cable tie-down	(27315)	216H599	1	*	*	*	*	*	10	22
X20				HANGER, PLASTIC: remote control cable	(00761)	HP10N	1	*	*	*	*	*	10	23
X20				STRAP: remote control cable	(27315)	232H407	1	*	*	*	*	*	10	24
0	5310-050-3456			NUT, PLAIN, WING: remote control cable tie-down	(27315)	20H168D10	1	*	*	*	*	*	10	25
2210 - DATA PLATES														
X20				PLATE INSTRUCTION: rheostat remote control	(27315)	232H95	1	*	*	*	*	*	17B	5
0	5310-286-1495			SCREW, MACHINE: rheostat instruction plate mtg.			2	*	*	*	*	*	17B	3
0	5310-010-3319			WASHER, LOCK: rheostat instruction plate mtg. screw			2	*	*	*	*	*	17B	4
X20				PLATE, IDENTIFICATION: control panel	(27315)	232E116	1	*	*	*	*	*	17A	65
X20				PLATE IDENTIFICATION: remote control	(27315)	232H397	1	*	*	*	*	*	17A	16
X20				PLATE, INSTRUCTION: terminal block	(27315)	232H396	1	*	*	*	*	*	10	17
X20				PLATE, INSTRUCTION: portable mount assembly	(27315)	232H96	1	*	*	*	*	*	14	15
X20				PLATE, INSTRUCTION: welding operation	(27315)	2105F70	1	*	*	*	*	*	16	
X20				PLATE, INSTRUCTION: wiring diagram	(27315)	2101E501	1	*	*	*	*	*	16	
X2F	9905-807-3712			PLATE, IDENTIFICATION: corps of engineers			1	*	*	*	*	*		
X20				SCREW, MACHINE: plate mtg, round head, Type A, no. 6 x3/8 in. lg.			18	*	*	*	*	*		
0	5305-010-0737			SCREW, MACHINE: control panel name plate			6	*	*	*	*	*		
0	5310-275-1706			NUT, PLAIN, HEXAGON: control panel name plate			6	*	*	*	*	*		
0	5310-010-6495			WASHER LOCK: control panel name plate			6	*	*	*	*	*		
0	5305-010-7637			SCREW, DRIVE: portable mount instruction plate	(27315)	20ZH0D7	2	*	*	*	*	*	14	14
GROUP 44 - WELDING EQUIPMENT														
4401 - ROTOR ASSEMBLY														
X2H				ROTOR ASSEMBLY	(27315)	274702	1			*	*		19	17
X1				CASTING, ROTOR	(27315)	274E3D2	1			*	*			
9 H	5310-164-8848			WASHER, FLAT	(27315)	218H145D1	AR			*	*			
X2H U				ARMATURE ASSEMBLY: rotor	(27315)	2100F43	1			*	*		19	43
X2F				FAN: armature cooling	(27315)	274E2	1			*	*		19	23
X2F				COVER, DUST: bearing housing	(27315)	214H39	1			*	*		19	33
X2H				WASHER, FLAT: armature shaft, drive end	(27315)	218H98D3	1			*	*		19	13
X2H				SPACER: armature shaft, drive end	(27315)	218H108D2	1			*	*		19	14
X2H				KEY, MACHINE: rotor to armature shaft	(27315)	20H138H15	1			*	*		19	24
H	5306-042-7929			BOLT, MACHINE, HEXAGON HEAD: armature shaft, drive end			1			*	*		19	11
X2H				KEY, SQUARE: fan mounting, .246 in. to .252 in., 1-1/8 in. lg.	(37315)	20H1380D13	1			*	*		20	25
H				5310-261-7340 WASHER, LOCK: armature shaft, drive end			1			*	*		19	12
X2F				HOUSING: armature shaft bearing, commutator end	(27315)	272E5	1			*	*		19	37
4402 - STATOR ASSEMBLY														
X2H				STATOR ASSEMBLY	(27315)	9271H1	1			*	*		19	16
X2H R				FRAME AND FIELD: magnet	(27315)	9271E4F3	1			*	*		19	83
X1				FRAME: magnet	(27315)	271A3D4	1			*	*		19	83
X2H				COIL, COMMUTATOR	(27315)	9275F103F4	2			*	*		19	79
X2H				POLE PIECE: main, no. 1	(27315)	271F7D2	1			*	*		19	66
X2H				POLE PIECE: main, no. 2	(27315)	271F7D1	1			*	*		19	75

CODES	FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	QTY INCORPORATED PER UNIT	GUIDE QTY(S) PER MAJOR EQUIPS						ILLUST		
					15 DAYS MAINT.			DEPOT			FIGURE NO.	ITEM NO.	
					ORGANIZATIONAL			SS MAINT.					
					1-5	6-10	100 EQUIPMENTS	1-5	6-10	100 EQUIPMENTS			
MANUFACTURER'S		UNIT OF ISSUE	QTY INCORPORATED PER UNIT	GUIDE QTY(S) PER MAJOR EQUIPS						ILLUST			
CODE	PART NO.			1-5	6-10	100 EQUIPMENTS	1-5	6-10	100 EQUIPMENTS	FIGURE NO.	ITEM NO.		
4402 - STATOR ASSEMBLY (cont)													
X2H		POLE PIECE: cross, no. 1	(27315)	271F7D3	1				*	*	19	80	
X2H		POLE PIECE: cross, no. 2	(27315)	271F7D4	1				*	*	19	74	
X2H		INSULATION: magnet frame	(27315)	275H72D1	4				*	*	19	60	
X2H		INSULATION: magnet frame	(27315)	275H72D2	4				*	*	19	81	
X2H		INSULATION: magnet frame	(27315)	275H71D1	8				*	*	19	61	
X2F		COIL ASSEMBLY, MAIN	(27315)	9275F96	1				*	*	19	65	
X20		TERMINAL, LUG: coil lead	(00761)	YAV14T4	1	*	*		*	*	19	64	
X2F		COIL: cross field, no. 1	(27315)	9275E134	1				*	*	19	82	
X20	5940-243-0404	TERMINAL, LUG: coil lead	(00761)	YAV14	1	*	*		*	*	19	56	
X2F		COIL: cross field, no. 2	(27315)	9275E140	1				*	*	19	73	
X20	5940-155-7630	TERMINAL, LUG: coil lead	(00761)	YAV14T2	1	*	*		*	*	19	72	
X2F		CLAMP: coil retaining	(27315)	275H76	4				*	*	19	76	
X2F		COLLAR: commutator coil	(27315)	9275H7F1	4				*	*	19	78	
X2F		CLAMP: reactor core and coil lead	(27315)	232H248	1				*	*	19	59	
X2F		SCREW, MACHINE: clamp mtg.	(27315)	20Z325D88	6				*	*	19	58	
X2F		COIL, REACTOR	(27315)	9280F2F3	1				*	*	19	57	
X20	5940-243-0404	TERMINAL, LUG: reactor coil lead	(00761)	YAV14	1	*	*		*	*	19	56	
X20	5940-230-9911	CONNECTOR, ELECTRICAL WIRING	(00779)	34138	3	*	*		*	*	19	63	
X20		SLEEVE, INSULATION: electrical wiring	(27315)	851	3				*	*	19	62	
X20		BUS BAR: Commutator coil	(27315)	279H253D33	4	*	*		*	*	19	77	
X20		BUS BAR magnet frame and field	(27315)	279H254D1	1	*	*		*	*	19	71	
X20		SLEEVE, INSULATION: bus bar	(27315)	275H86D15	1	*	*		*	*	19	70	
F	5310-010-3323	WASHER, LOCK: reactor coil mtg screw			1				*	*	19	55	
9 F	5305-017-9895	SCREW, CAP, HEXAGON HEAD: reactor coil mtg			1				*	*	19	54	
9 O	5305-275-9123	SCREW, MACHINE: bus bar and lead mtg			12	*	*		*	*	19	67	
O	5310-021-9431	NUT, PLAIN, HEXAGON: bus bar and lead screw			12	*	*		*	*	19	68	
O	5310-010-3320	WASHER, LOCK: bus bar and lead screw			12	*	*		*	*	19	69	
4403 - BRUSH HOLDER ASSEMBLY													
X20		HOLDER, BRUSH: main	(27315)	273F4D2	2	*	*		*	*	19	53	
X20		HOLDER, BRUSH: exciter	(27315)	273F5	1	*	*		*	*	19	47	
P F	5977-227-6503	SPRING, TENSION: main brush	(27315)	17Z122	6			2	*	30	19	51	
P1F	5977-227-6501	SPRING, TENSION: exciter brush	(27315)	17Z123	1				*	20	19	45	
P O	5977-227-6500	BRUSH, ELECTRICAL: main (minimum stockage of 6 is authorized)	(82214)	549	6	6	12	19	*	600	19	52	
P O	5977-227-6499	BRUSH, ELECTRICAL: exciter	(27315)	273H3D1	1	*	*		3	*	100	19	46
O	5310-010-3319	WASHER, LOCK: brush holder mtg. Screw			8	*	*		*	*	19	29	
9 O	5305-275-9838	SCREW, MACHINE: brush holder mtg.			8	*	*		*	*	19	44	
4405 - FRAME SUPPORT, HOUSING, CARRIER													
X2H		GIRDLE, BEARING: generator end	(27315)	232H235	1				*	*	19	36	
X2H		SLEEVE, BEARING: generator end	(27315)	225H2D2	1				*	*	19	35	
P1H	3110-198-1975	BEARING, BALL: generator end	(27335)	W306PP	1				*	10	19	34	
P1H	3110-227-4110	BEARING, BALL: motor end	(27335)	W309PP	1	*			*	10	19	20	
X2H		SLEEVE, BEARING: motor end	(27315)	225H3	1	*			*	*	19	21	
X2H		GIRDLE, BEARING: motor end	(27315)	232H237	1	*			*	*	19	22	
X20		BASEPLATE: welding unit mounting	(27315)	216H326D1	1	*	*		*	*	19	85	
X20		PLATE ASSEMBLY: lifting	(27315)	229H98	1	*	*		*	*	10	6	
X20		SEAL, RUBBER: lifting plate	(27315)	218H174D3	1	*	*		*	*	10	11	
X2F		PANEL ASSEMBLY: housing back cover	(27315)	9227F19F4	1	*			*	*	10		
X2F		PANEL: housing back cover	(27315)	227F159D8	1	*			*	*	10	8	
X20		INSULATION: rear panel	(27315)	275H92D1	1	*	*		*	*	10	9	
X2F		PLATE ASSEMBLY: housing end cover	(27315)	227H53F1	2				*	*	10		
X2F		PLATE: housing end cover	(27315)	227H54D1	1				*	*	10	10	
X20		SEAL, RUBBER: housing end cover	(27315)	218H107D1	4	*	*		*	*	10	21	
X20		COVER ASSEMBLY: housing top	(27315)	227F423	1	*	*		*	*	10	3,7	
X20		INSULATION	(27315)	275H92D2	4	*	*		*	*	10	7	
X20		DOOR, ACCESS: generator inspection	(27315)	227H51	1	*	*		*	*	10	19	
X20		TIE ROD: bearing housing	(27315)	220H57	4	*	*		*	*	19	41	
X20		SPACER: housing tie rod	(27315)	218H129	4	*	*		*	*	19	39	
X20		COUPLING: tie rod spacer	(27315)	0928V004	4	*	*		*	*	19	40	
X20		NUT, LOCK: tie rod spacer	(27315)	0944V003	4	*	*		*	*	19	42	
X20		WASHER, "C": tie rod	(27315)	218H97	8	*			*	*	19	38	
X2F		SPACER: stator to air tube	(27315)	218H108D1	4				*	*	19	15	
X20		WASHER, SPECIAL: air tube to tie rod screws	(27315)	218H98D1	8	*	*		*	*	19	7	
F	5306-722-8450	BOLT, MACHINE: stator to air tube	(27315)	207544202	4	*			*	*	19	5	
9 F	5306-617-4131	BOLT, MACHINE: bearing housing to air tube	(27315)	2075442D1	4	*			*	*	19	26	
F	5310-010-3323	WASHER, LOCK: air tube bolt			8	*			*	*	19	6	
9 F	5306-021-3665	BOLT, MACHINE: generator	(27315)	20Z630D1	6				*	*	19	28	

CODES	FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	QTY INCORPORATED IN UNIT	GUIDE QTY(S) PER MAJOR EQUIPS				ILLUSTR		
					IS DAYS MAINT.				DEPOT MAINT.	FIGURE NO.	ITEM NO.
					ORGAN-IZATIONAL	DS	CS	MAINT.			
MATERIAL SOURCE AVAILABILITY		MANUFACTURER'S CODE PART NO.			1-5	6-10	100 EQUIPMENTS				
4405 - FRAME SUPPORT, HOUSING, CARRIER (cont)											
9 F	5310-164-8848	WASHER, FLAT: generator bolt		6				*		10 2	
9 F	5305-013-2723	SCREW, MACHINE		2				*		17A 66	
9 F	5310-275-1706	NUT, PLAIN, HEXAGON		2				*		17A 67	
F	5310-010-3320	WASHER, LOCK		15				*		10 5	
X2F		SCREW, THREAD CUTTING: 5/16-18 thd size, 3/4 in. lg.(27315)	20Z632D2	7				*		10 4	
X2F		SCREW, THREAD CUTTING: 5/16-18 thd size, 1-1/8 in. lg.	(27315) 20Z630D5	2				*			
Z2F		SCREW, THREAD CUTTING: 5/16-18 thd size,						*			
F	5305-275-9123	SCREW, CAP, HEXAGON HEAD		6				*		17A 71	
F	5310-021-9431	NUT, PLAIN, HEXAGON		6				*		17A 69	
X20		DOOR ASSEMBLY: cable terminal	(27315) 279H255D2	1	*	*	*	*		10	
X1		DOOR	(27315) 279F160	1				*		10 12	
X1	5340-266-0759	BUMPER, RUBBER	(70485) 829	2				*		10 13	
M 0		BRACKET: mounting		2				*		19 86	
		MANUFACTURE FROM:									
P 0	9520-517-0534	ANGLE, STEEL		FT	(SEE GROUP 9501)						
0	5305-010-0109	SCREW, CAP, HEXAGON HEAD: housing to mtg angle		6	*	*	*	*		19 87	
0	5310-010-3319	WASHER, LOCK: housing to mtg angle screw		6	*	*	*	*		19 88	
0	5310-010-9084	NUT, PLAIN, HEXAGON: housing to mtg angle screw		6	*	*	*	*		19 89	
0	5305-017-9885	BOLT, MACHINE: angle to base plate		2	*	*	*	*		19 90	
0	5310-010-3323	WASHER, LOCK: angle to base plate screw		2	*	*	*	*		19 91	
0	5310-202-8552	NUT, PLAIN, HEXAGON: angle to base plate screw		2	*	*	*	*		19 92	
0	5305-275-9838	SCREW, MACHINE: cover to panel		13	*	*	*	*		10 1	
0	5310-010-3319	WASHER, LOCK: cover to panel screw		13	*	*	*	*		10 2	
4406 - VENTILATING, COOLING SYSTEM											
X2F		BAFFLE: air tube, meter end	(27315) 227H58	1				*		19 10	
F	5320-270-2781	RIVET: air tube baffle	(07707) AD42BS	10				*			
X2F		HOUSING: ventilating fan	(27315) 272A3D1	1				*		19 18	
X2F		SEAL: fan housing	(27315) 218H103D2	1				*		19 19	
X2F		TUBE, AIR: generator end	(27315) 227H55	1				*		19 27	
X2F		TUBE ASSEMBLY, AIR: meter end	(27315) 9227H2F6	1				*		19 8	
4407 - CONTROL PANELS, HOUSING											
X20		SHUNT	(27315) 86Z23D3	1	*	*	*	*		19 84	
X2F R		PANEL ASSEMBLY, CONTROL	(27315) 9279F296	1				*		17A	
X2F		PANEL: front, housing and control	(27315) 279F159D10	1				*		10 20	
9 F	5305-013-2900	SCREW, MACHINE: panel mtg		2				*		17A 53	
X2F	38815-425-7821	WASHER, LOCK: panel mtg		2				*		17A 54	
9 F	5305-016-0505	SCREW, MACHINE: panel mtg	(27315) 0856V107	4				*		17A 52	
F	5310-010-3319	WASHER, LOCK: panel mtg		6				*		17A	
X2F		BUSHING: control panel	(28520) SB875-6	1				*		17A 17	
X20		GUARD, CABLE	(27315) 2164614	1	*	*	*	*		10 16	
0	5310-174-7400	NUT, SELF-LOCKING: cable guard	(72962) 22NM02	8	*	*	*	*		10 14	
X20		MOUNT ASSEMBLY: meter	(27315) 9279H376	1	*	*	*	*		17A	
X1		WASHER, "C"		1				*		17A 10	
X1		RIVET		1				*		17A 15	
X20		PLATE: meter mounting	(27315) 279H422	1	*	*	*	*		17A 6	
P10	6625-736-8586	VOLTMETER	(55026) 125-100VDC	1	*	*	*	*	6	17A 8	
P10	6625-736-8585	AMMETER	(55026) 125-400ADC	1	*	*	*	*	6	17A 9	
X20		GROMMET: mtg plate	(79497) G1006	4	*	*	*	*		17A 5	
0	5305-010-0737	SCREW, MACHINE: meter to panel		6	*	*	*	*		17A 7	
0	5310-010-6495	WASHER, LOCK: meter mtg screw		6	*	*	*	*			
0	5310-275-1706	NUT, PLAIN, HEXAGON: meter mtg screw		6	*	*	*	*			
0	5310-174-7400	NUT, SELF-LOCKING: meter plate screw	(72962) 22NM02	4	*	*	*	*		17A 4	
0	5305-151-2769	SCREW, MACHINE: meter plate mtg.		4	*	*	*	*		17A 1	
X20	3815-425-7821	WASHER, LOCK: plate mtg screw		8	*	*	*	*		17A 2	
X20		SPACER: meter plate	(27315) 218H166	4	*	*	*	*		17A 3	
X20		RECEPTACLE, ELECTRICAL: remote control	(83315) 7410GT	1	(SEE GROUP 4408)						17A 14
0	5310-050-2231	WASHER, LOCK: cable guard		2	*	*	*	*		10 15	
4408 - CONNECTING DEVICES											
X20		RECEPTACLE, ELECTRICAL: remote control	(83315) 7410GT	1	*	*	*	*		17A 14	
9 0	5305-010-0737	SCREW, MACHINE: receptacle mtg		2	*	*	*	*		17A 12	
0	5310-010-6495	WASHER, LOCK: receptacle mtg screw		2	*	*	*	*		17A 13	
9 0	5305-011-3959	SCREW, MACHINE: junction block		2	*	*	*	*		17A 19	

CODES	FEDERAL STOCK NUMBER	DESCRIPTION	UNIT OF ISSUE	QTY INCORPORATED IN UNIT	GUIDE QTY(S) PER MAJOR EQUIPS				ILLUSTR	
					18 DAYS MAINT.				FIGURE NO.	ITEM NO.
					ORGAN-IZATIONAL	DS	CS	DEPOT MAINT.		
MATERIAL SOURCE MAINT RECOVERY		MANUFACTURER'S CODE PART NO.			1-5	6-10	100 EQUIPMENTS			
4408 - CONNECTING DEVICES (cont)										
0	5310-010-9084	NUT, PLAIN, HEXAGON: junction block screw		2	*	*	*	*	*	17A 20
0	5305-275-9123	SCREW, MACHINE: bus bar mtg		3	*	*	*	*	*	17A 50
0	5310-021-9431	NUT, PLAIN, HEXAGON: bus bar mtg screw		3	*	*	*	*	*	17A 48
0	5310-010-3320	WASHER, LOCK: bus bar mtg screw		3	*	*	*	*	*	17A 49
X20		TERMINAL BOARD	(71785) 2-141	1	*	*	*	*	*	17A 18
X20		TERMINAL ASSEMBLY: welding cables	(27315) 9279H25F2	1	*	*	*	*	*	17A 22
										27
X20		TERMINAL	(27315) 279H230	1	*	*	*	*	*	17A 27
X20		BUS BAR	(27315) 279H239	1	*	*	*	*	*	17A 26
90	5305-637-7782	SCREW, MACHINE: cable connecting		2	*	*	*	*	*	17A 24
90	5310-011-4505	NUT, PLAIN, HEXAGON: cable screw		2	*	*	*	*	*	17A 23
0	5310-010-3131	NUT, PLAIN, WING: cable connecting		2	*	*	*	*	*	17A 22
M0		CABLE ASSEMBLY: JUMPER	(27315) 279F239D151	1	*	*	*	*	*	17A 25
		MANUFACTURE FROM:								
P0	6145-174-1123	WIRE, ELECTRICAL (16 in. required)		FT	(SEE GROUP 9501)					
X20	5940-976-0904	TERMINAL, LUG: jumper cable	(00761) YAV276	1	*	*	*	*	*	
X20	5940-976-0903	TERMINAL, LUG: jumper cable	(00761) YAV2711	1	*	*	*	*	*	
X20		BUS BAR: selector switch	(27315) 279H256	1	*	*	*	*	*	17A 51
X20		BUS BAR: rheostat	(27315) 279H251D1	1	*	*	*	*	*	17A 58
0	5310-208-4072	NUT, PLAIN, HEXAGON: rheostat bus bar screw		2	*	*	*	*	*	17A 55
0	5310-010-6496	WASHER, LOCK: rheostat bus bar screw		2	*	*	*	*	*	17A 57
X20		BUS BAR: generator	(27315) 279H253D24	2	*	*	*	*	*	19 50
0	5306-021-6920	BOLT, MACHINE: bus bar mtg	(27315) 20T5439D1	4	*	*	*	*	*	19 48
0	5310-010-3320	WASHER, LOCK: bus bar mtg		4	*	*	*	*	*	19 49
X20		BUS BAR: selector switch	(27315) 279H258	1	*	*	*	*	*	17A 72
0	5305-275-9123	SCREW, CAP, HEXAGON HEAD: bus bar mtg		1	*	*	*	*	*	17A 71
0	5310-021-9431	NUT, PLAIN, HEXAGON: bus bar mtg screw		1	*	*	*	*	*	17A 69
0	5310-010-3320	WASHER, LOCK: bus bar mtg screw		1	*	*	*	*	*	17A 70
4409 - PROTECTIVE DEVICES, ELECTRICAL										
X20		PLATE, INSULATION: brush holder	(27315) 275H84	3	*	*	*	*	*	19 32
X20		INSULATION: control panel	(27315) 275H92D1	1	*	*	*	*	*	10 9
X2F		BUSHING, INSULATION: control panel	(27315) 275H83	1	*	*	*	*	*	10 18
4410 - SWITCHING CONTROL										
X20		HANDLE, TAP SWITCH	(27315) 206F3d3	1	*	*	*	*	*	17A 62
X20		HANDLE, REVERSING SWITCH	(27315) 206F4D2	1	*	*	*	*	*	17A 29
9X20	5315-058-5968	PIN, SPRING: handle retaining	(72962) 59-040-187-1000	1	*	*	*	*	*	17A 28
P1F	5930-227-6507	SWITCH ASSEMBLY, REVERSING SELECTOR (Same as SWITCH ASSEMBLY, stock no. 5930227-6508, except where individual components are annotated.)	(27315) 2100F46	1	*	*	*	*	5	17A
P1F	5930-227-6508	SWITCH ASSEMBLY, SELECTOR	(27315) 2100F48	1	*	*	*	*	5	17A
X1		PLATE: back, reversing switch (Used on SWITCH ASSEMBLY, stock no. 5930-227-6507 only.)	(27315) 279H24D1	1	*	*	*	*	*	17A 44
X1		PLATE: front, selector switch	(27315) 279H241	1	*	*	*	*	*	17A 38
X1		PLATE: back, selector switch (used on SWITCH ASSEMBLY, stock no. 5930-227-6508 only.)	(27315) 279H242D2	1	*	*	*	*	*	17A 63
X1		INSULATOR: switch shaft	(27315) 279H243	5	*	*	*	*	*	17A 41
X1		SHAFT: selector switch (Used on SWITCH ASSEMBLY, stock no. 5930-227-6508 only.)	(27315) 279H274D5	1	*	*	*	*	*	17A 64
X1		WASHER, SPRING: selector switch 0.18 in. id x 1.18 in. od (Used on SWITCH ASSEMBLY, stock no. 5930-227-6508 only.)	(27315) 220H45	2	*	*	*	*	*	17A 39
X1		SPACER: selector switch	(27315) 279H248D3	2	*	*	*	*	*	17A 40
x1		INSULATOR: selector switch spacer	(27315) 279H244	8	*	*	*	*	*	17A 45
X1		BLADE, MOVEABLE: selector switch	(27315) 279H247	6	*	*	*	*	*	17A 42
X1		CONTACT: selector switch	(27315) 279H245	3	*	*	*	*	*	17A 46
X1		CONTACT: selector switch	(27315) 279H246	4	*	*	*	*	*	17A 47
9X1	5305-215-3909	SCREW, MACHINE: selector switch binding (Used on SWITCH ASSEMBLY, stock no. 5930-227-6508 only.)		2	*	*	*	*	*	17A 32
X1	5310-010-3319	WASHER, LOCK: switch binding screw (Used on SWITCH ASSEMBLY, stock no. 5930-227-6508 only.)		3	*	*	*	*	*	17A 31

CODES			FEDERAL STOCK NUMBER	DESCRIPTION	MANUFACTURER'S CODE PART NO.	UNIT OF ISSUE	QTY INCORPORATED IN UNIT	GUIDE QTY(S) PER MAJOR EQUIPS				ILLUST	
MATERIAL SOURCE	SUBMIT	RECOGNIZABILITY						15 DAYS MAINT.		DEPOT MAINT.		FIGURE NO.	ITEM NO.
								ORGAN-IZATIONAL	DS	SS	MAINT.		
			1-5	6-10	100 EQUIPMENTS								
4410 - SWITCHING CONTROL (cont)													
X1			5310-164-8848	WASHER, FLAT: switch binding screw (Used on SWITCH ASSEMBLY, stock no. 5930-227-6508 only.)			2						17A 34
9X1			5305-468-3703	SCREW, MACHINE: selector switch back plate (Used on SWITCH ASSEMBLY, stock no. 5930-227-6508 only.)			2						17A 30
X1				SHAFT: reversing switch (Used on SWITCH ASSEMBLY, stock no. 5930-227-6507 only.)	(27315)	279H294D3	1						17A 43
9X1			5305-017-5170	SCREW, MACHINE: reversing switch binding (Used on SWITCH ASSEMBLY, stock no. 5930-227-6507 only.)			2						17A 32
X1			5306-017-9824	BOLT, MACHINE: reversing switch (Used on SWITCH ASSEMBLY, stock no. 5930-227-6507 only.)	(27315)	0826V026	1						17A 36
X1			5310-021-9431	NUT, PLAIN, HEXAGON: reversing switch (Used on SWITCH ASSEMBLY, stock no. 5930-227-6507 only.)			1						17A 35
X1			5310-010-3320	WASHER, LOCK: reversing switch (Used on SWITCH ASSEMBLY, stock no. 5930-227-6507 only.)			1						17A 33
X1				SPACER: reversing switch (Used on SWITCH ASSEMBLY, stock no. 5930-227-6507 only.)	(27315)	218H104D3	1						17A 37
X2F				STARTER ASSEMBLY, MOTOR	(37315)	9279h237f5	1			*	*	*	19 4
P1F			5950-224-6504	STARTER ASSEMBLY	(04009)	51354	1			*	*	*	19 4
X1				COIL	(04009)	32620-513	1						18 4
X1				CONTACT	(04009)	51351-15	1						18 6
X1				BLOCK, OVERLOAD	(04009)	33209-8	2						18 2
X2F				BUSHING, INSULATION: starter mtg	(27315)	275H83	6			*	*	*	10 1
11P10			5930-112-5203	SWITCH, TOGGLE	(15605)	8690K1	1	*	*	*	*	*	17A 11
9 F			5305-010-0765	SCREW, MACHINE: starter assembly			3			*	*	*	19 2
F			5310-050-2231	WASHER, FLAT: starter assembly			3			*	*	*	19 3
9 F			5310-174-7400	NUT, SELF-LOCKING, HEXAGON	(72962)	22NM02	3			*	*	*	19 1
X2F				SWITCH, PUSH: starter	(02295)	M4982698	1			*	*	*	17A 68
4411 - RESISTOR COMPONENTS													
P10			5905-227-6506	RHEOSTAT	(44655)	41876	1	*	*	*	*	*	17A 59
X20				HANDLE: rheostat	(27315)	206H15D2	1	*	*	*	*	*	17A 61
X20				PIN, SPRING: rheostat handle attaching	(72692)	59-022-094-625	1	*	*	*	*	*	17A 60
GROUP 76 - FIRE FIGHTING EQUIPMENT COMPONENTS 9501 - BULK MATERIAL													
P0			4010-257-0772	CHAIN, WELDLESS			FT	*	*	*	*	*	
P0			9505-186-9137	WIRE, STEEL, CARBON			RL	*	*	*	*	*	
P0			6145-174-1123	WIRE, ELECTRICAL			FT	*	*	*	*	*	
P0			9520-517-0534	ANGLE, STEEL			FT	*	*	*	*	*	

INDEX

	Paragraph	Page		Paragraph	Page
Ammeter gage	24	12	General	15, 25, 35, 38, 40, 53	11, 12, 16,
Ammeter, voltmeter and	62	25		55, 60, 67, 69, 85, 93	18, 21, 23,
				24, 25, 28,	
				30, 37, 39	
Basic Issue tools and equipment	32	16	Holders, brush	58	25
Blocks, terminal	63	27	Housing, doors, covers, and panels..	54	23
Brush holders.....	58	25	Identification and tabulated data.....	4	5
Brush springs	57	25	Inspection and maintenance of		
Brushes	56	24	equipment in storage.....	77	32
			Inspection and servicing	8	9
Cleaning, inspection and repair	96	39	Inspection of used equipment.....	11	10
Commutator	59	25	Installation	98	39
Controls and instruments	16	11	Installation of separately packed		
Control panel assembly	90	38	components	9	9
Correcting polarity	39	18	16Installation or setting-up instructions		10 9
Current selector	65	27	Loading equipment for shipment	75	32
			Lubrication	34	16
Daily preventive maintenance services		36	Magnetic starter	18, 66	11
Data, identification and tabulated	4	5	Models, differences in	5	8
Data, tabulated	81	33	Movement, dismantling for	13	11
Demolition by explosives or			Movement, reinstallation after	14	11
weapon's fire	71	30	Operation under unusual conditions .	29	14
Demolition, other methods	72	30	Operation under usual conditions	28	13
Demolition to render equipment			Organizational maintenance repair		
inoperative.....	70	30	parts.....	33	16
Description.....	3, 80	4, 33	Other demolition methods	72	30
Differences in models	5	8	Panel assembly, control	90	38
Direct and general support and			Polarity, correcting	39	18
depot maintenance repair parts.....	83	37	Preparation of equipment for		
Disassembly.....	95	39	shipping	74	31
Dismantling for movement	13	11	Preparation of equipment for		
			storage.....	76	32
Electrode selector	21	11	Preventive maintenance services,		
Electrode selector and polarity			daily	36	16
reversing switches.....	64, 91	27, 38	Preventive maintenance services,		
Equipment:			quarterly.....	37	16
Basic issue tools and	32	16	Quarterly preventive maintenance		
Demolition to render inoperative ..	70	30	services.....	37	16
			Reassembly	97	39
Inspection and maintenance in.....			Record and report forms	2, 79	2, 33
storage	77	32	Receptacle and switch.....	61	25
Loading for shipment	75	32	Reinstallation after movement.....	14	11
.....			Remote control switch	22	11
Preparation for shipment.....	74	31	Removal	94	39
Preparation for storage	76	32	Repair parts, direct and general		
Special tools and	31, 82, 84	16, 37, 37	support and depot maintenance	83	37
Excessive brush sparking.....	52	22			
Extinguisher, fire	30	15			
Fire extinguisher	30	15			
Gage, ammeter	24	12			
Gage, voltmeter	23	12			
Generator control fails to vary					
current	51	22			
AGO 8244A					

	Paragraph	Page		Paragraph	Page
Repair parts, organizational	33	16	Switches, electrode selector and		
Reversing switch	19	11	polarity reversing	64, 91	27, 38
Rheostat current selector	20	11	Tabulated data	81	33
.....			Terminal blocks.....	63	27
Scope	1, 78	2, 33			
Selector, current	65	27	Torque, wheels and	68	29
Selector, electrode	21	11	Tools and equipment, basic issue.....	32	16
Selector, rheostat current	20	11	Tools and equipment, special	31, 82	16, 37
.....			Tools and equipment, specially de-		
Separately packed components,			signed.....	84	37
installation of	9	9			
Servicing used equipment.....	12	10	Touching machine gives shock.....	50	22
Setting-up instructions, installation	10	9	Training.....	73	30
Shipment, loading equipment for	75	32	Unloading equipment	6	9
Shipment, preparation of equip-			Unusual conditions, operation		
ment for	74	31	under	29	14
Special tools and equipment	1, 82	16, 37	Used equipment, inspection of	11	10
Specially designed tools and			Used equipment, servicing	12	10
equipment.....	84	37	Usual conditions, operations under...	28	13
Springs, brush	57	25			
Starting	26	13	Voltmeter and ammeter.....	62	25
Starter assembly	92	38	Voltmeter gage.....	23	12
Starter chatters	42	87	Welder generating but current		
Starter magnetic.....	18, 66	11, 28	falls off.....	46	22
Starter operates and blows fuse	44	21	Welder runs but soon stops.....	47	22
Stopping.....	27	13	Welder starts but will not deliver -		
Storage, inspection and mainte-			welding current.....	45, 89	21, 37
nance of equipment in.....	77	32	Welder will not start	43, 88	21, 37
Storage, preparation of equipment	76	32	Welder will not start (starter		
Start-stop switch	17	11	not operating)	41, 86	21, 37
Switch, receptacle and	61	25	Welding arc is loud and sputters		
Switch, remote control.....	22	11	excessively	48	22
Switch, reversing	19	11	Welding arc sluggish.....	49	22
Switch, start-stop	17	11	Wheels and torque	68	29

By Order of the Secretary of the Army:

HAROLD K. JOHNSON,
General, United States Army,
Chief of Staff.

Official:

J. C. LAMBERT,
Major General, United States Army,
The Adjutant General.

Distribution:

Active Army:

USASA (2)	USAES (100)
ACSI (1)	USAARMS (4)
DCSLOG (1)	USMA (2)
CNGB (1)	GENDEP (10)
TSG (1)	Engr Dep (10)
CofEngrs (3)	Army Dep (2)
CC-E (1)	USA Tml Comd (2)
Dir of Trans (1)	Army Tml (1)
CofSptS (1)	Div Engr (2)
USAMB (1)	Engr Dist (2)
USAARTYBD (2)	USA Engr Rsch & Dev Lab (3)
USAARMBD (2)	USA Mob Equip Cen (46)
USAIB (2)	Engr Cen (5)
USARADB (2)	USAREUR Engr Proc Cen (2)
USAAESWBD (2)	USAREUR Engr Sup Con Agcy (10)
ISAAVNBD (2)	Chicago Proc Ofc (10)
USCONARC (3)	Engr Fld Maint Shops (2)
OS Maj Comd (6) except	Fld Comd, DASA (8)
USASETAF (2)	AMS (3)
USARJ (10)	USAREURCOMZ (2)
USAMOCOM (2)	MAAG (1)
USASMC (1)	JBUSMC (1)
MDW (1)	Units org under fol TOE:
Armies (2)	5-48 (2)
Corps (2)	5-237 (5)
USA Corps (1)	5-262 (5)
Div (2)	5-267 (1)
Engr Bde (1)	5-278 (5)
Svc Colleges (2)	5-279 (2)
Br Svc Sch (2) except	

NG: State AG (3).

USAR: Same as active Army except allowance is one copy to each unit.

For explanation of abbreviations used, see AR 320-0.

*U.S. GOVERNMENT PRINTING OFFICE: 1994 - 300-421/00144

AGO 8244A

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT... PIN-POINT WHERE IT IS

PAGE NO.

PARA-GRAPH

FIGURE NO.

TABLE NO.

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

