

TECHNICAL MANUAL

**OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT
AND GENERAL SUPPORT MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS LIST)**

FOR

**WELDING MACHINE, ARC
MODEL SAE-400
(LINCOLN ELECTRIC COMPANY)
(NSN 3431-00-498-6258)**

HEADQUARTERS, DEPARTMENT OF THE ARMY

JULY 1981

SAFETY PRECAUTIONS

In order to protect yourself and others from possible serious injury read and observe all Instructions and specific safety precautions included in this manual as well as the following general safety precautions.

1. Protect yourself from possible dangerous electrical shock.
 - a. The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Never permit contact between "hot" parts of the circuits and bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
 - b. Always insulate yourself from ground using dry insulation when welding in damp locations, on metal floors, gratings or scaffolds, and particularly when in positions (such as sitting or lying) where large areas of your body can be in contact with possible grounds.
 - c. Maintain the electrode holder, ground clamp, welding cable and welding machine in good, safe operating condition.
 - d. Never dip the electrode holder in water for cooling.
 - e. Never simultaneously touch electrically "hot" parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
 - f. If using the welder as a power source for mechanized welding, these precautions for the electrode holder also apply for the automatic electrode, electrode reel, welding head, nozzle or semiautomatic welding gun.
2. When working above floor level, protect yourself from a fall should you get a shock. Never wrap the electrode cable around any part of your body.
3. Arcburn may be more severe than sunburn Therefore:
 - a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Filter lens should conform to ANSI Z87 1 standards.
 - b. Use suitable clothing to protect your skin and that of your helpers from the arc rays.
 - c. Protect other nearby personnel with suitable non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.
4. Droplets of molten slag and metal are thrown or fall from the welding arc. Protect yourself with oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and caps over your hair. Wear ear plugs when welding out of position or in confined places.
5. Always wear safety glasses when in a welding area. Use glasses with side shields when near slag chipping operations.
6. Remove fire hazards well away from the area. If this is not possible cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot

materials from welding can easily go through small cracks and openings to adjacent areas.

7. When not welding, place the holder where it is insulated from the ground system. Accidental grounding can cause overheating and create a fire hazard.
8. Be sure the work cable is connected to the work as close to the welding area as practical. Work cables connected to the building framework or other locations some distance from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
9. Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. Use adequate ventilation. This is particularly important when welding on galvanized, lead or cadmium plated steel and other metals which produce toxic fumes.
10. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas and other irritating products.
11. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned." For information purchase "Safe Practices for Welding and Cutting Containers That Have Held Combustibles." A6.0-65, from the American Welding Society.
12. Vent hollow castings or containers before heating, cutting or welding. They may explode.
13. For more detailed safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" for \$5.00 from the American Welding Society, Miami, Florida 33125.

Motor-Generator Welder Safety Precautions

1. Ground the frame of the welder in accordance with the National Electrical Code and the manufacturer's recommendations. The fixture or metal being welded must also be connected to a good electrical ground.
2. Have a qualified electrician do the needed installation, troubleshooting and maintenance work.
3. Turn the welder off using the disconnect switch at the fuse box before doing maintenance work inside the machine.
4. Keep all covers and safety devices in position and good repair.
5. Keep hands, hair, clothing and tools away from all moving parts when operating or repairing equipment.

Technical Manual
No. 9-3431-260-14&P



HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC, 10 July 1981

**OPERATOR'S, ORGANIZATIONAL, DIRECT SUPPORT
AND GENERAL SUPPORT MAINTENANCE MANUAL
(INCLUDING REPAIR PARTS LIST)
FOR
WELDING MACHINE, ARC
MODEL SAE-400
(NSN 3431-00-498-6258)**

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2, located in the back of this manual direct to: Commander, US Army Armament Materiel Readiness Command, ATTN: DRSAR-MAS, Rock Island, IL 61299. A reply will be furnished direct to you.

NOTE

This manual is published for the purpose of identifying an authorized commercial manual for the use of the personnel to whom this welder is issued.

Manufactured by: Lincoln Electric Co.
22801 St. Clair Ave.
Cleveland, OH 44117

Procured under Contract No. DAAA09-79-C-2073

This technical manual is an authentication of the manufacturers' commercial literature and does not conform with the format and content specified in AR 310-3, Military Publications. This technical manual does, however, contain available information that is essential to the operation and maintenance of the equipment.

	<u>PAGE</u>
DAMAGE CLAIMS	1
INSTALLATION	2-3
INPUT CONNECTION	2
OUTPUT CABLE SIZES	2
CURRENT CONTROL	2
SETTING CONTROLS	3
MAINTENANCE AND TROUBLESHOOTING	3-5
GENERAL INSTRUCTIONS	3
MOTOR PROTECTION	3
BEARINGS	3
COMMUTATOR AND BRUSHES	3
ILLUSTRATIONS	6-15
MOTOR GENERATOR (AC)	6
MOTOR GENERATOR (DC)	7
WELDING GENERATOR	8
GENERATOR BRUSH HOLDER (OLD)	8
GENERATOR BRUSH HOLDER (NEW)	9
EXCITER BRUSH HOLDER	9
BASIC CONTROL BOX	10-11
GDC STARTER BOX	12
GXL STARTER	13
S-45 AND S-67 STARTER	14
GAC STARTER BOX	14
OPTIONAL REMOTE CURRENT CONTROL	15
SAFETY PRECAUTIONS	16

INSTRUCTIONS FOR REQUISITIONING PARTS

NOT IDENTIFIED BY NSN

When requisitioning parts not identified by National Stock Number, it is mandatory that the following information be furnished the supply officer.

- 1 - Manufacturer's Federal Supply Code Number - 36232
- 2 - Manufacturer's Part Number exactly as listed herein.
- 3 - Nomenclature exactly as listed herein, including dimensions, if necessary.
- 4 - Manufacturer's Model Number - Model SAE-400
- 5 - Manufacturer's Serial Number (End Item)
- 6 - Any other information such as Type, Frame Number, and Electrical Characteristics, if applicable.
- 7 - If DD Form 1348 is used, fill in all blocks except 4, 5, 6, and Remarks field in accordance with AR 725-50.

Complete Form as Follows:

- (a) In blocks 4, 5, 6, list manufacturer's Federal Supply Code Number - 36232 followed by a colon and manufacturer's Part Number for the repair part.

- (b) Complete Remarks field as follows:
Noun: (nomenclature of repair part)
For: NSN: 3431-00-498-6258
Manufacturer: Lincoln Electric Co.

Model: SAE-400
Serial: (of end item)


Any other pertinent information such as Frame Number, Type, Dimensions, etc.

iii/(iv blank)

OPERATING MANUAL


SAE DC Welders

Motor and Belt Driven




AC MOTOR DRIVEN

SAE 200*, 300, 400, 600*



DC MOTOR DRIVEN

SAE 200*, 300*, 400



BELT DRIVEN

SAE 200*, 300, 400, 600*, 900*-B

*Discontinued Models

DAMAGE CLAIMS

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

SAFETY DEPENDS ON YOU

These welders are designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation on your part. Read and observe all instructions and specific safety precautions included in this manual as well as the common machine operating and welding safety precautions outlined on the back of this manual. And, most importantly, think before you act and be careful.

INPUT CONNECTION: Motor-Generator

Install the welder in a dry location where there is free circulation of air. Place the air intake end of the machine to minimize the amount of smoke and fumes from welding which are drawn into the welder.

Be sure the voltage, phase and frequency of the input power is as specified on the welder nameplate. On single voltage machines, connections between the control box and motor are made at the factory. Dual voltage machines are shipped with the NVR coil and stator leads not connected. Connect these leads for the available voltage as indicated on the wiring diagram in the control box.

Have a qualified electrician connect power to the input panel or starter, as appropriate, in accordance with the National Electrical Code, all local codes and the wiring diagram glued to the inside of the door on the start button side of the control box.

The welder frame must be grounded. A stud marked with the symbol \equiv located inside the control box is provided for this purpose. See the National Electrical Code for details on proper grounding -methods. (If an old machine does not have a grounding stud, connect the grounding wire to an unpainted frame screw or bolt.)

Recommended Input Wire, Ground Wire and Fuse Sizes Based on National Electrical Code

For 60 Hertz, 3 Phase Welders at 60% Duty Cycle

Welder Size	Input Voltage	Input Ampere Rating	Copper Wire Size Type 75° C in Conduit		Fuse Size (Super Lag)
			3 Input Wires	1 Ground Wire	
AC Motor SAE 200	230	44	8	8	80
	460	22	12	10	40
	575	18	14	10	30
AC Motor SAE 300	230	62	6	8	100
	460	31	10	10	50
	575	25	10	10	40
AC Motor SAE 400	230	78	6	6	125
	460	39	8	8	70
	575	31	10	10	50
AC Motor SAE 500	220	106	3	6	200
	440	53	8	8	100
	550	42.5	8	8	80
DC -DC SAE 600	230	120	3	6	175
	460	60	6	8	90
	575	48	8	8	70


Start the welder and check the direction of rotation. Proper direction is shown by an arrow attached to the welder frame. On 3 phase AC motor driven models, the direction of rotation can be changed by interchanging any two input leads. DC motor driven models rotate in the proper direction but the input leads must be connected as marked on the instruction plate on the starter box so the output studs have the correct polarity.

After the machine has been in operation for some time, check all lead connections and tighten if necessary.

RECOMMENDED OUTPUT CABLE SIZES

Machine Size in Amps	Cable Sizes for Combined Length of Electrode Plus Ground Cable (Copper) - 60% Duty Cycle		
	Up to 150 ft.	150 to 200 ft.	200 to 250 ft.
260	2	1	1/0
300	1/0	2/0	3/0
400	2/0	3/0	4/0
600	3/0	4/0	2-3/0

CONTROL OF WELDING CURRENT



CONTINUOUS CURRENT CONTROL

The Continuous Current Control provides the major adjustment of welding current to suit each particular application. On most machines the Continuous Current Control has a single dial calibrated in amperes and three colored pointers. On the SAE-300, above Code 5006 and the SAE-400, this control has three separate colored scales. The

"BELTED" MODELS

These machines consist of the same generator and controls as the motor-generator models but are driven by a PTO, electric motor or an engine.

The appropriate operating and maintenance instructions in this manual apply to the belted welders.

INSTALLATION

The welder frame must be grounded. A stud marked with the symbol \equiv located on the welding generator support frame is provided for this purpose. See the National Electrical Code for details on proper-grounding methods. The ground connector must be No. 8 or larger wire. (If an older welder does not have a

grounding stud, connect the ground wire to an unpainted frame screw or bolt.)

Design the driving system to operate the generator at a steady full load speed (1800 or 1500 RPM as indicated on the nameplate). Build a rigid mounting which maintains accurate alignment through the driving system and minimizes vibrations transmitted to the welder. Use a flexible type coupling when connecting the generator shaft directly to the power source shaft. For belt driven installations, prevent excessive bearing wear by using only enough belt tension to avoid slipping.

colored pointers (or scales) correspond to the yellow, black and red sections of the Job Selector dial. When the Job Selector is set on the yellow section of its dial, the approximate welding current is indicated by the yellow pointer (or scale) on the Continuous Current Control dial.

DO NOT change the Continuous Current Control setting while welding.

DUTY CYCLE

60 Hertz machines are NEMA rated at a 60% duty cycle. This means they can be operated at rated output for 6 minutes out of every 10 minute period. 50 hertz machines are rated 50% duty cycle.

JOB SELECTOR

The Job Selector is both the fine current adjustment and the voltage control of your welder. With this control you can obtain the exact current you desire. Also, by means of this control, you can vary the open circuit voltage to adjust the arc characteristics to different welding situations.

The Job Selector dial is divided into four sections. The yellow section marked "Large Electrode" provides a high open circuit voltage. The black section marked "Normal Welding Range" gives a medium-high open circuit voltage.

The red section marked "Overhead and Vertical" is a medium-low open circuit voltage. The section marked "Special Applications" provides a low open circuit voltage which is used in conjunction with a minimum setting on the Continuous Current Control.

HOW TO SET THE CONTROLS

Example: Assume you want to weld with a 5/32" electrode at about 135 amps using the soft arc (medium-high open circuit voltage) recommended for most applications:

1. Set the Job Selector to the black section of the dial marked "Normal Welding Range."
2. Set the Continuous Current Control to read 135 amperes under the black pointer (or the black dial).
3. Strike the arc.
4. If the arc is too weak, set the Job Selector up (counter clockwise) to increase the current. If a still higher current is desired, turn the Continuous Current Control up 10 or 20 amps. In the final adjustment, be certain the Job Selector is still set in the black range to get the smooth arc recommended.

POLARITY SWITCH

Turn the Arc Polarity Switch to Electrode Negative or Electrode Positive as required for the particular application.

To change polarity on DC motor driven models, interchange the welding cables.

AUXILIARY POWER OUTLET (Optional)

AC motor and belt driven models (except SAE-200) can be furnished with a 1 KW exciter. This exciter provides 120 volt DC power for operating lights or power tools. When using a belted welder as a power source for tools, run the engine at the normal welding speed.

MAINTENANCE AND TROUBLESHOOTING

Have a qualified electrician do the maintenance and troubleshooting work. Turn the power off using the disconnect switch at the fuse box before working inside the machine.

GENERAL INSTRUCTIONS

1. Blow out the welder and controls with an air hose at least once every two months. In particularly dirty locations this cleaning may be necessary once every week. Use low pressure air to avoid driving dirt into the insulation.
2. Reactor brushes are silver graphite and should not be greased. Keep the contacts clean.
3. Rotate the Current Control through its entire range each morning. This cleans the contacts to lessen the possibility of the contact "freezing". Do not do this while welding.
4. The starter on motor driven models should be inspected every six months. Any accumulated dust should be blown out of the starter.
5. Keep electrode and ground connections tight.

MOTOR PROTECTION (AC Motor Driven Only)

The AC motor is protected by a special device operated by both temperature and current. This device stops the machine if the windings reach the maximum safe operating temperature because of frequent overloads, high room temperature plus overload, or abnormally high or low input voltage. Protection is also assured against excessive currents resulting from single phase or unbalanced line conditions.

The thermostat automatically resets when the temperature reaches a safe operating level. Restart the motor by pushing the start button.

Cooling of the motor can be speeded by holding in the start button and operating the machine idle. Models prior to code 3500 equipped with the optional two voltage switch cannot be cooled in this manner without burning out the NVR coil. If the reason for the disconnection was single phase or unbalanced line conditions, correct the situation before attempting to restart the motor. Serious damage will result if the start button is held in with these conditions present.

BEARINGS

Your welder is equipped with double-shield ball bearings having sufficient grease to last indefinitely under normal conditions. Where the welder is used constantly or in excessively dirty locations, it may be necessary to add one ounce of grease per year.

When greasing the bearings, keep all dirt out of the area. Wipe the fittings completely clean and use clean grease and equipment. More failures are caused by dirt introduced while greasing than from insufficient grease.

COMMUTATOR AND BRUSHES

The generator brushes are properly adjusted when the welder is shipped. They require no particular attention. DO NOT SHIFT THE BRUSHES or adjust the rocker setting.

Periodically inspect the commutators and brushes by removing the commutator covers. DO NOT remove or replace these covers while the machine is running.

Commutators require little attention. However, if they are black or appear uneven, have an experienced maintenance man clean them with fine sandpaper or a commutator stone. Never use emery cloth or paper for this purpose.

Have an experienced maintenance man replace brushes when they wear within 1/4" of the pigtail. A complete set of replacement brushes should be kept on hand. These brushes have a curved face to fit the commutator. Seat these brushes by lightly stoning the commutator as the armature rotates at full speed until

contact is made across the full face of the brushes. After stoning, blow out the dust with low pressure air.

WARNING: Uncovered rotating equipment can be dangerous. Use care so your hands, hair, clothing or tools do not catch in the rotating parts. Protect your self from particles that may be thrown out by the rotating armature when stoning the commutator.

THE LINCOLN EXCHANGE PLAN gives you fast repairs at modest cost. Here's how:

Factory remanufactured replacements for the major parts indicated in this manual are available for

most models. These exchange parts are available only through the local authorized Field Service Shops. To get your welder back into operation quickly, replace the faulty part with a rebuilt part - often from the service shop's stock. The cost is less than a normal rewinding job.

The service shop will ship the removed part to the factory for inspection. If it can be rebuilt, a credit will be issued to the shop. They, in turn, will pass this credit to you, thus further reducing the net cost of the repair. And all exchange parts carry the same one year guarantee as new welders.

TROUBLESHOOTING

Have a qualified electrician do the troubleshooting work. Turn the input power off using the disconnect switch at the fuse box before working inside the machine.

TROUBLE	CAUSES	WHAT TO DO
Machine fails to hold the "heat" constantly.	Rough or dirty commutator. Brushes may be worn down to limit of adjustment or life (1/4 inch from the pigtail). Brush springs may have lost adjustment or may be broken. Field circuit may have variable resistance connection or intermittent open-circuit, due to loose connection or broken wire. Electrode lead or work lead connections may be poor. Wrong grade of brushes may have been installed on generator. Field rheostat may be making poor contact and overheating. Current control brushholder contact springs may be worn out or bent. Contact surface may be dirty, rough or pitted. Current control brushholder support stud and mating contact surfaces may be dirty or pitted and burned.	Commutator should be trued or cleaned. Replace brushes. Replace brush springs. Check field current with ammeter to discover varying current. This applies to both the main generator and exciter. Tighten all connections. Use new brushes. Inspect rheostat and clean the contact. Inspect, replace needed parts, clean internal contact surface of control device. Do not lubricate. Smooth up roughened surface. If brushholder internal contact surface is pitted and burned, replace the brushholder and support stud. If the contact surface is dirty clean off the brushholder stud and internal contact surface. Apply mixture of three parts silicone grease and one part zinc powder (by weight) to stud.
Welding arc is loud and spatters excessively.	Current setting may be too high. Polarity may be wrong.	Check setting and current output with ammeter. Check polarity. Try reversing polarity or try an electrode of the opposite polarity.
Welder starts but fails to generate current.	May be running the wrong way. Generator or exciter brushes may be loose or missing. Exciter may not be operating. Field circuit of generator or exciter may be open. Polarity reversing switch may be in the neutral position.	Check direction of rotation with direction arrow. On three-phase motors direction of rotation may be changed by interchanging any two input leads. Be sure that all brushes bear on the commutator and have proper spring tension. Check exciter output voltage with voltmeter or lamp. Check for open circuits in rheostat, field leads, field coils and resistors. Some machines give less output when fields are open. Put handle in positive or negative position.

TROUBLESHOOTING

TROUBLE	CAUSES	WHAT TO DO
Welder starts but fails to generate current (Continued) circuted.	Exciter may have lost excitation. Series field or armature circuit may be open-circuted.	Flash the exciter fields.* Check circuit with ringer or voltmeter.
Welding current too great or too small compared to indication on the dial.	Current Control, shaft and handle may have turned slightly in the insulated bushing of the current control brushholder, caused by turning handle too hard against one of the stops. Exciter output low causing low output compared to dial indication. Current Control set to minimum and welder output so great that motor stalls when arc is struck.	See that Current Control Indicator yellow arrow is in the horizontal position when handle is turned against stop in the minimum direction. For the newer SAE-300's, set the control against the minimum stop and be sure the pointer is at the minimum mark on the dial plate. Field discharge resistor that is wired to the reversing switch may be open circuited. Check for circuit through it. Motor is probably running backward or series fields connected reversed to make a cumulative series generator. Check rotation.
Motor trips off the line.	Power circuit may be single phase. Thermostat may have tripped. Welding electrode or work leads may be too long or too small in cross-section. operating at rated current. Ambient temperature may be too high. Motor input voltage too low (or high) under load. Unbalanced input voltage. Ventilation may be impaired.	Check for one blown fuse or dead line. Check for overload condition. Check terminal voltage while machine is loaded, it should not exceed 40 volts when Make sure that temperature in motor-generator room or housing does not exceed 100 degrees F. and that there is no interference with normal ventilation of the machine Motor supply voltages should not fall below 90% of normal voltage. Have power company check transformer and line capacity. The supply leads may be too long or too small. Blow out and clean.
Machine fails to start.	Power circuit may be completely dead. Power circuit may be single phased. Power-line voltage may not be suitable for motor, or may be extremely low; may be accompanied by chattering of the motor starter. Machine may be jammed. Motor starter may be single-phased. Overload protecting device may be tripped or contacts open-circuted.	Look for open disconnect switch, fuses removed from clips, or blown fuses. Look for one blown fuse or one dead line. Check voltage with voltmeter. particularly at the moment of attempted starting. See that armature turns over easily by hand, and look for foreign material in air gaps. Check to see that all fingers on starter make contact simultaneously when closed. If machine has had time to cool after tripping due to overload, or is cold and starter fails to close, check for circuit through push button, NVR coil and thermostats to find the open-circuted part. See wiring diagram for normally closed and open contacts on the pushbutton.


* Flashing the exciter fields consists of passing current through the fields using an external source of 6 to 125 volts of DC power from a storage battery or DC generator. If using a DC generator, keep the generator turned off except when actually applying the flashing current. To flash the fields:

1. Turn the welder off, close the Electrode Polarity switch and raise one exciter brush off the commutator.
2. Attach the positive lead from the DC source to the right hand

- brushholder.
- Carefully holding an insulated section of the negative lead from the DC source, touch its lug or clamp to the left hand brushholder for 5 seconds. Pull it away quickly to minimize arcing.
Remove the leads from the brushholder, replace the brush on the commutator, start the welder and the generator voltage should build up.


MOTOR GENERATOR - AC MOTOR DRIVEN

WHEN ORDERING GIVE: Item No., Part Name, Parts List No., and Welder Code.



SAE-200 Parts List P-31-C SAE-300 Parts List P-32-C			SAE-400 Parts List P-33-C SAE-600 Parts List P-34-C		
ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.	ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.
1	Screw, Fan Guard	3	33	Armature Assembly, Includes: Armature Coil	1 1
2	Fan Guard	1	34	Dust Cap, Inner	1
3	Cover, End Bracket	1	35	Gasket, Dust Cap	2
4	Screw, Round Head	4	36	Bearing	1
5	Nut, Square Head	4	37	Wound Stator, Includes: Stator Coil	1 1
6	Nut, Blower	1	38	Thermostat Assembly	1
7	Washer, Blower	1	39	Screw, Thermo Mounting	2
8A	Blower	1	40	Screw, Frame	4
9	Retaining Ring Tube, Bearing Clamp (Used on Code 2433 and Below)	1 1	41	Bracket, Exciter	1
10	Screw, Dust Cap	4	41	Bracket, Exciter (Oversize Exciter Only)	1
11	Dust Cap, Outer	1	42	Screw, Exciter Bracket	4
12	Pipe Plug	1	43	Brush Holder, Exciter	2
13	Gasket, Dust Cap	2		Exciter Brush Holder Parts See P-25-M	
14	Bracket, Generator End	1	44	Screw, Exciter Brush Holder Mounting	4
15	Screw, Bracket	4	45	Washer, Brush Holder Mounting	4
16	Rocker	1	46	Brush, Exciter	2
17	Screw, Round Head	1	47	Dust Cap, Outer	1
18	Lockwasher	1	48	Pipe Plug	1
19	Brush Holder Assembly - Old Style (Prior to Code 275) Old Style Brush holder Parts See P-32-F	4	49	Screw	2
19	Brush Holder Assembly - New Style New Style Brush holder parts See P-25-L	4	50	Screw, Exciter Pole Piece	4
20	Brush Generator	8	51	Exciter Field Coil	7
21	Nameplate	1	52	Pole Piece	2
22	Drive Screw - Nameplate	2	52	Pole Piece, Exciter (Oversize Exciter Only)	2
23	Lead Block	1	53	Shield, Exciter lead	1
24	Drive Screw, Lead Block	4	53	Shield, Exciter Lead (Oversize Exciter Only)	1
25	Generator Frame Assembly Interpole and Coil Assembly. Includes:	1 4	54	Armature, Exciter	
26	Interpole Coil	4	55	Collar, Spacer	1
27	Pole Piece	4	56	Washer, Exciter Nut	1
28	Shunt Coil	2	57	Nut, Exciter	1
29	Main Pole Piece	4	58	Bracket, Exciter Cover	1
30	Series Coil	2	58	Bracket, Exciter Cover (Oversize Exciter Only)	1
31	Bearing	1	59	Cover, Motor Frame	1
32	Dust Cap, Inner	1	60	Cover, Exciter End	1
			61	Washer	1
			62	Screw	1

MOTOR GENERATOR - DC MOTOR DRIVEN




WHEN ORDERING GIVE: Item No., Part Name, Parts List No., and Welder Code.

Parts List P-35-C


ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.	ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.
1	Blower	1	22M	Brushholder Assembly - Old Style, Prior to Code 322	2
2	Fan Guard Shield	1		old Style Brushholder Parts	See P-32-E
3	Self-Tapping Screws	4	22M	Brushholder Assembly - New Style	2
4G	Brushes (200 and 300 Amp Models)	3		New Style Brushholder Parts	See P-25-L
4G	Brushes (400 Amp Models)	12	23M	Interpole Coil	4
6G	Series Field Coil	2	24	Armature Coil	1
6G	Shunt Field Coil	2	26G	Interpole Coil	4
7G	Frame	1	27	Armature - Complete	1
8G	Armature Coil	1	28G	Bracket Cover	1
9M	Shunt and Series Field Coils	4	29G	Brushholder Assembly - Old Style, Prior to Code 322	4
10M	Frame	1		Old Style Brushholder Parts	See P-32-E
12M	Brush	4	29G	Brushholder Assembly - New Style	4
13M	Bracket	1		New Style Brushholder Parts	See P-25-L
14	Ball Bearing	1	30G	Inner Dust Cap	1
15M	Outer Dust Cap	1	31G	Bracket	1
16M	Inner Dust Cap	1	32G	Ball Bearing	1
19	Dust Cap Gasket	4	33G	Outer Dust Cap	1
20	Rockers	2	34	Bearings Clamp Tube	1
21	End Shell	1	35	Lockwasher	1
			36	Bearing Nut	1
				M- Indicates Motor End	
				G- Indicates Welder End	

WELDING GENERATOR - BELT DRIVEN




SAE-200-B Parts List P-36C			SAE-300-B to 900-B Parts List P-36-D		
ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.	ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.
1	Brushholder Assembly - Old Style, Prior to Code 340	4	17	Bearing	1
1	Brushholder Assembly - New Style	4	18	End Bracket - Exciter End	1
	Old Style Brushholder Parts	See P-32-E	19	Inner Dust Cap	1
	New Style Brushholder Parts	See P-25-L	20	Commutator	1
4	Cover	1	21	Armature Coils	1
7	Rocker Includes: Clamp Screw	1 1	22	Series Coils	2
8	Exciter Field Coils	2	22	Shunt Coils	2
9	Exciter Field Poles	2	22A	Pole Piece	4
10	Exciter Brushholder	2	23	Blower Assembly	1
	Exciter Brushholder Parts	See P-25-M	24	End Bracket - Pulley End	1
11	Exciter Sleeve Collar	1	25	Inner Dust Cap	1
12	Exciter Sleeve Lock Nut	1	26	Bearing	1
13	Exciter End Shield	1	27	Outer Dust Cap	1
14	Exciter Armature	1	29	Interpole Field Coil	2
15	Outer Dust Cap - Commutator End	1	30	Brushes	
16	Bearing Lock Nut	1	31	Frame	1
			32	Exciter Brushes	2
			34	Armature Assembly	1

GENERATOR BRUSH HOLDER - OLD STYLE




All Models prior to Code 275 Parts List P-32-E		
ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.
1	Brush Holder Assembly Includes: Brush holder - Includes:	1 per brush
2	Finger	1
3	Finger Spring	1
4	Finger Stud	1
5	Socket Head Screw, Cup Point	1
6	Nut	1
7	Stud	1
8	Washer	1
9	Insulating Washer	2
10	Insulating Tube	1
11	Washer	1
12	Lockwasher	1
1	Hex Head Nut	2

GENERATOR BRUSH HOLDER - NEW STYLE




All Models Parts List P-32-E		
ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.
	Brush Holder Assembly Includes:	
1	Spring and Clip Assembly	4
2	Round Head Cap Screw	4
3	Plate and Retainer Assembly	1
4	Round Head Cap Screw	4
5	Hex Head Cap Screw	1
6	Stud	1
7	Clamping Washer	1
8	Insulating Washer	1
9	Insulating Tube	1
10	Clamping Washer	1
11	Hex Head Cap Screw	1

EXCITER BRUSH HOLDER



All Models Parts List P-25-M		
ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.
	Exciter Brush Holder Assembly Includes:	1
1	Spring	1
2	Brush holder	1
4	Hex Nut	1
5	Insulating Washer	2
6	Bushing	2



BASIC CONTROL BOX



WHEN ORDERING GIVE: Item No., Part Name, Parts List No., and Welder Code.

SAE-200 AC-Motor Parts List P-31-D SAE-300 AC-Motor Parts List P-32-D SAE-400 AC-Motor Parts List P-33-D			SAE-600 AC-Motor Parts List P-34-D SAE DC-Motor Parts List P-35-D SAE Belted Parts List P-36-E		
ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.	ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.
1	Case Assembly			Output Stud Assembly Includes:	2
2	Rheostat	1	49	Stud	2
3	Voltage Dial Plate	1	50	Insulating Bushing	2
4	Rheostat Handle	1	51	Insulating Washer	4
5	Headless Set Screw, Cup Point	1	52	Plain Washer	4
6	Screw, Rheostat Mounting	2	53	Lock Washer	2
	Volt - Ammeter (Optional)	1	54	Hex Jam Nut	4
7#	Reversing Switch Plate	1	55	Hex Flanged Weld Nut	2
8	Screw	9	56	Connection Strap	1
9#	Reversing Switch	1	57	Connection Strap Insulation	1
10	Current Dial Plate	1	58	Self Tapping Screw	1
11	Rivets, Dial Plate Mounting	4	59	Connection Strap (Without Meter)	1
12	Reactor Handle	1	59	Shunt (With Meter Only)	1
13	Set Screw, Hollow, Half Dog Point	1	60	Insulation	1
14	Plug, Oversize Exciter Only	1	61	Sub Panel	1
15	Receptacle, Oversize Exciters Only	1	62	End Cover (Without Two Voltage Switch)	1
16	Terminal Strip, SAE-600 Only	1	63*#	Hinge Pin	1
17	Terminal Strip Number Plate, SAE-600 Only	1	64*#	Push Button Assembly	1
18	Self Tapping Screw, SAE-600 Only	2	65*#	Screw and Nut	2
19	Cover Assembly	1	66*#	Harness, Push Button	1
20#	Resistance Tube-500 OHMS Standard	1	67	Screw Reactor Mounting	6
20#	Resistance Tube-200 OHMS Automatic Duty	1	68	Lock Washer, Reactor Mounting	6
22#	Stove Bolt	1	69	Screw	R
23#	Lockwasher	1	70*#	GXL Starter Assembly (Less NVR Coil)	1
24#	Insulation, Resistance Tube	1		GXL Starter Parts	See P28-F
25	Reactor		71*#	S-45 Starter (600 Amp AC Motor) (Less NVR Coil)	1
26	Hex Head Cap Screw	1		S-45 Starter Parts	See P-28-E
	Reactor Brush Holder Assembly Includes:	1	*#	GAC Starter Box	See P-28-G
27	Brush Holder	1	*#	Dual Voltage Switch Assembly, Includes:	1
28	Hex Head Cap Screw	2	85*#	Dual Voltage Switch	1
29	Insulation Tube	1	86*#	End Cover	1
31	Shaft	1	87*#	Nameplate	1
34	Finger Spring	4	88*#	Locking Cover	1
35	Contact Finger	4	89*#	Case Cover	1
36	Round Head Screw	4	90*#	Case	1
37	Lockwasher	4	*#	Condensers, Optional (Not Illustrated)	3
30	Washer	2			
32	Spring	1			
33	Reactor Spring Clip	1			
	Stud and Bracket Assembly Includes:	1			
38	Bracket	1			
39	Stud	1			
40	Copper Washer	1			
41	Insulating Washer	2			
42	Insulating Bushing	1			
43	Lockwasher	1			
44	Knead Brass Nut	1			
45	Plain Washer	1			
	Sub Panel Assembly Includes: (Without Meter)	1			
	Sub Panel Assembly Includes: (With Meter)	1			
46	"Electrode" Marker	1			
46	"Positive" Marker (DC Motor Over 200V				
47	Input) "To Work" Marker	1			
47	"Negative" Marker (DC Motor Over 300V				
48	Input) Hollow Rivet	4			

GDC STARTER BOX




WHEN ORDERING GIVE: Item No., Part Name, Parts List No., and Welder Code.

SAE DC-Motor Parts List P-35-E

ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.	ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.
1	Polarity Switch (Less than 300 Volt Input Only)	1		Input Lead Clamp	1
	Round Head Screw, Switch Mounting	2		Round Head Screw, Clamp Mounting	1
	Hex Nut	2		Hex Nut, Clamp Mounting	1
	Polarity Switch Flat Spring	1	9	#1 S-45 Starter (Used on Codes Below 6400)	1
1	Switch Hole Cover Plate (Over 300 Volt input)	1		S-45 Starter Parts	See P-28-E
1	Polarity Switch Plate	1	9	#1 S-67 Starter (Used on Codes Above 6400)	1
2	Polarity Switch Handle	1		S-67 Starter Parts	See P-28-H
	Switch Lever and Shaft Assembly	1	9	#1 GDC* Starter, Prior to Code 2148	
	Groove Pin - Handle to Shaft	1		GDC Starter Parts	See P-28-F
3	Push Button	1	10	#2 S-45 Starter (Used on Codes Below 6400)	1
	Push Button Harness	1		S-45 Starter Parts	See P-28-E
4	Resistance Tube - Polarity Switch Discharge Tube	1	10	#2 S-67 Starter (Used on Codes Above 6400)	1
	Tube Insulation (Glastic)	2		S-67 Starter Parts	See P-28-H
	Tube Insulation (Duro)	1	10	#2 GDC* Starter, Prior to Code 2148	
	Insulating Washer	1		GDC* Starter Parts	See P-28-F
	Stove Bolt, Tube Mounting	1		#1 GDC* Starter Interlock Parts - Not Illustrated	
	Hex Nut, Tube Mounting	1		Interlock Assembly	1
5	Resistor, Specify Welder Input Voltage	1		Interlock Block	1
6	End Cover	1		Plunger	1
7	Resistance Tubes, Specify Welder Input Voltage	2		Insulation	1
	Fiber Washers	2		Coil Spring	1
	Tube Insulation (Duro)	2		Insulation	1
	Tube Insulation (Glastic)	4		Support Plate	1
	Stove Bolt; Tube Mounting	2		Time Delay Relay, Mount on #1 S-45	1
	Hex Nut, Tube Mounting	2		Bracket and Rocker Arm. Relay Mounting	1
8	Case	1		#1 GDC* Starter Mercury Switch Parts - Not Illustrated	
	Nameplate, Input Leads	1		Mercury Switch	1
	Self Tapping Screw, Nameplate Mounting	2		Trunnion	1
				Delay Arm	1
				*This GDC Starter, used on machines prior to Code 2148, is basically a GXL Starter. Spare parts are listed on the GXL Starter carts list.	


GXL STARTER



SAE-200, 300 and 400 AC-Motor Parts List P-28-F


ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.	ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.
	GDC* Starter, Includes: (Includes NVR Coil) DC Motor Driven Welders Only	2	126	Contact Block Stationary Contact (Not Illustrated)	1
101	GXL Starter, Includes: (Less NVR Coil) Interlock Insulation	1		GDC Only Moving Contact (Not Illustrated) GDC Only	1
	Interlock Support Plate	1	129	Jumper	2
102	Sems Round Head Screw	2	130	Hex Nut	4
103	Square Shaft	1	131	Square Nut	3
104	Sems Round Head Screw	6	132	Clamp. NVR Coil	1
105	Shaft Insulation	1	133	Fiber Retainer, NVR Coil	1
106	Contact Arm Clamp	3	134	Moving Lamination, Note I	1
107	Contact Arm	1	135	NVR Arm Pin	1
108	Bearing, Nylon	2	136	Stationary Lamination	1
109	Cotter Pin	2	137	Tinnerman Nut	2
110	Hex Head Cap Screw - Contact Mounting (Lower)	3	138	Hex Nut Shakeproof Washer	4
110	Hex Head Cap Screw - Contact Mounting (Upper)	3	139	Movable NVR Crossing Arm	1
112	Shakeproof Washer	6	140	Side Panel - Right Hand	1
112	Contact Spring	3	141	Sems Round Head Screw, Lamination Mounting	4
113	Side Panel. Left Side	1		*Interlock Assembly, Includes: Not On All Starters	1 or 2
114	Sems Round Head Screw	3	142	Plain Washer	1
115	Lead With Lugs	3	143	Plunger	1
116	Moving Contact	3	144	Coil Spring	1
117	Rivet, Contact Assembly	3	145	Sems Phillips Head Screw	2
118	Headless Slotted Set Screw	3	146	Interlock Block	1
119	Hex Nut	t	146	NVR Arm Stop - Without Interlock	1
122	Barrier	1	147	Hex Nut	2
123	Hex Nut, Side Panel Mounting	4	148	Sems Round Head Screw - Interlock Mounting	2
124	Sems Round Head Cap Screw - Contact Block Mounting (Lower)	2	148	Sems Round Head Screw - Arm Stop Mounting	2
124	Sems Round Head Cap Screw - Contact Block Mounting (upper)	2		Lug	3
	Shakeproof Washer	4	149	Round Head Screw - Lug Mounting NVR Coil (Specify Input Voltage)	3
125	Contact Block Assembly, Includes: Stationary Contact	1		Note 1: To obtain proper moving lamination (Item 134) specify input line cycles.	1
		3		*GDC Starter Interlock or Mercury Switch,	See P-15-E.

S-45 AND S-67 STARTER



SAE-600 AC-Motor and SAE DC-Motor S45 Parts List P-28-E S-67 Parts List P-28-H			
ITEM	PART NAME AND DESCRIPTION	NO	
	S-45 & S-67 Starter Assembly, Includes: (Less NVR Coil)	1	
1	Moving Lamination Assembly	1	
2	Screw - Lamination mounting	1	
3	Lockwasher	1	
4	*	1	
5	Lamination and Panel Assembly (Specify Input Hertz)	1	
6	Plastic Insert	1	
7	Contact Block Cover	1	
8	Plain Washer	2	
9	Hug Nut	2	
10	Stationary Interlock Contact Assembly	1	
11	Stationary Interlock -Contact Assembly	1	
12	Screw - Lead Connections	4	
13	Contactor Assembly	1	
14	Moving Contactor Block	1	
15	Moving Interlock Contact Assembly	1	
16	Moving Interlock Contact Assembly	1	
17	Round Head Screw	1	
18	Spring - Main Contact	3	
19	Moving Contact	3	
20	Lockwasher	1	
21	Main Contact Block Assembly	1	
22	Main Contact Block	1	
23	Main Stationary Contact:	6	
24	Hex Jam Nut - Brass	As	Needed
25	Hex Jam Nut - Brass	As	Needed
26	Terminals	3	
27	Spacer Washer	4	
28	*	1	
29	NVR Coil (Specify Input Voltage)	1	


GAC STARTER BOX (Optional)



SAE AC-Motor Parts List P-35-C

ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.	ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.
	GAC Starter, Includes:	1	17	Hex Nut	3
3	Insulation	1	18	Lockwasher	3
4	Lockwasher	1	19	GXL Starter	1
5	Round Head Screw	1		GXL Starter Parts	See P-28-F
6	Round Head Screw	1	20	Round Head Screw	2
7	Hex Nut	1	21	Lockwasher	2
8	Lockwasher	1	22	Hex Nut	2
9	Lead Clip	1	23	Round Head Screw	2
10	Resistor	1	24	Hex Nut	4
13	Square Nut	1	25	Case	1
14	Self-Tapping Screw	1	26	Reactance Coil With Lamination	1
15	Cross Brace	1	27	Hex Head Screw	2
16	Round Head Screw	3	28	Lockwasher	2
			36	Barrier	

Optional Remote Current Control



Parts List P-32-F		
ITEM	PART NAME AND DESCRIPTION	NO. REQ'D.
1	Case Assembly	1
2	Case Cover Plate	1
3	Handle Assembly	1
4	Handle Shaft	1
5	Pinion Gear Assembly	1
6	Spun Gear Assembly	1
7	Clutch and Pinion Shaft	1
8	Clutch Disc.	1
9	Pinion support Bushing Assembly	1
10	Thrust Washer	2
11	Spring	1
12	Motor	1
13	Receptacle	1
14	Support Rushing	1
15	Set Screw	2
16	Flat Head Screw	2
17	Flat Head Screw	2
18	Self Tapping Screw	10
19	Gotter Pin	1
20	Set Screw	1
21	Groove Pin	2
22	Nameplate	1
23	Set Screw	1
26	Grommet	1

By Order of the Secretary of the Army:

Official:


E. C. MEYER
General, United States Army
Chief of Staff

ROBERT M. JOYCE
Major General, United States Army
The Adjutant General

Distribution:

To be distributed in accordance with Special List.

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



SOMETHING WRONG WITH THIS PUBLICATION?

THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT... PIN-POINT WHERE IT IS				IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:
PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.	

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

TEAR ALONG PERFORATED LINE

DA FORM 2028-2
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

