


TECHNICAL MANUAL

**UNIT, DIRECT SUPPORT
AND GENERAL SUPPORT MAINTENANCE MANUAL**

**HYDRAULIC EXCAVATOR
JOHN DEERE
MODEL 230LCR
NSN 3805-01-463-0804**

AND

**MODEL 230LCRD WITH ROCK DRILL
NSN 3805-01-463-0806**



DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited.

Reproduced by permission of Deere & Company, Moline, IL © 2000.
All rights reserved.

HEADQUARTERS, DEPARTMENT OF THE ARMY

15 FEBRUARY 2000

INSERT LATEST UPDATED PAGES. DESTROY SUPERSEDED DATA.

LIST OF EFFECTIVE PAGES

Note: The portion of text or illustration affected by the updates is indicated by a vertical line in the outer margins of the page. Updates to wiring diagrams are indicated by shaded areas.

Dates of issue for original and updated pages are:

Original .. 0 .. 15 February 2000

TOTAL NUMBER OF PAGES IN THIS MANUAL IS 2366 CONSISTING OF THE FOLLOWING:

Page No.	*Revision No.	Page No.	*Revision No.	Page No.	*Revision No.
TM 5-3805-280-24-1		Foldout 18 blank.....	0	TM 5-3805-280-24-2	
Cover.....	0	Foldout 19.....	0	Cover	0
A.....	0	Foldout 20 blank.....	0	A.....	0
B blank	0	Foldout 21.....	0	B blank.....	0
i — xxxii.....	0	Foldout 22 blank.....	0	i — xx.....	0
1-1 — 1-44	0	Foldout 23.....	0	13-1 — 13-612.....	0
2-1 — 2-38	0	Foldout 24 blank.....	0	14-1 — 14-44.....	0
3-1 — 3-63	0	Foldout 25.....	0	15-1 — 15-4.....	0
3-64 blank	0	Foldout 26 blank.....	0	16-1 — 16-97.....	0
4-1 — 4-179	0	Foldout 27.....	0	16-98 blank	0
4-180 blank	0	Foldout 28 blank.....	0	17-1 — 17-6.....	0
5-1 — 5-18	0	Foldout 29.....	0	18-1 — 18-59.....	0
6-1 — 6-270	0	Foldout 30 blank.....	0	18-60 blank	0
7-1 — 7-41	0	Foldout 31.....	0	19-1 — 19-2.....	0
7-42 blank	0	Foldout 32 blank.....	0	20-1 — 20-34.....	0
8-1 — 8-9	0	Foldout 33.....	0	21-1 — 21-216.....	0
8-10 blank	0	Foldout 34 blank.....	0	22-1 — 22-55.....	0
9-1 — 9-3	0	Foldout 35.....	0	22-56 blank	0
9-4 blank	0	Foldout 36 blank.....	0	23-1 — 23-209.....	0
10-1 — 10-36	0	Foldout 37.....	0	23-210 blank	0
11-1 — 11-58	0	Foldout 38 blank.....	0	24-1 — 24-12.....	0
12-1 — 12-60	0	Foldout 39.....	0	A-1 — A-39.....	0
Foldout 1	0	Foldout 40 blank.....	0	A-40 blank.....	0
Foldout 2 blank.....	0	Foldout 41.....	0	B-1 — B-20.....	0
Foldout 3	0	Foldout 42 blank.....	0	C-1 — C-3.....	0
Foldout 4 blank.....	0	Foldout 43.....	0	C-4 blank	0
Foldout 5	0	Foldout 44 blank.....	0	Foldout 57.....	0
Foldout 6 blank.....	0	Foldout 45.....	0	Foldout 58 blank	0
Foldout 7	0	Foldout 46 blank.....	0	Foldout 59.....	0
Foldout 8 blank.....	0	Foldout 47.....	0	Foldout 60 blank	0
Foldout 9	0	Foldout 48 blank.....	0	Foldout 61.....	0
Foldout 10 blank	0	Foldout 49.....	0	Foldout 62 blank	0
Foldout 11	0	Foldout 50 blank.....	0	Foldout 63.....	0
Foldout 12 blank	0	Foldout 51.....	0	Foldout 64 blank	0
Foldout 13	0	Foldout 52 blank.....	0	Foldout 65.....	0
Foldout 14 blank	0	Foldout 53.....	0	Foldout 66 blank	0
Foldout 15	0	Foldout 54 blank.....	0		
Foldout 16 blank	0	Foldout 55.....	0		
Foldout 17	0	Foldout 56 blank.....	0		

*Zero in this column indicates an original page.

BLANK

HEADQUARTERS,
DEPARTMENT OF THE ARMY
Washington, DC, 15 February 2000

UNIT, DIRECT SUPPORT
AND GENERAL SUPPORT
MAINTENANCE MANUAL

HYDRAULIC EXCAVATOR
JOHN DEERE
MODEL 230LCR
NSN 3805-01-463-0804

AND

MODEL 230LCRD WITH ROCK DRILL
NSN 3805-01-463-0806

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028-2 (Recommended Changes to Equipment Technical Publications), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <http://aeprs.ria.army.mil>. If you need a password, scroll down and click on "ACCESS REQUEST FORM". The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax or email your letter, DA Form 2028, or DA Form 2028-2 direct to: Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-LC-CI, Rock Island, IL 61299-7630. The email address is AMSTA-LC-CI@ria.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

TM 5-3805-280-24-1

			Page
Chapter 1	Section 9000	General Information	
	01	Safety.....	1-1
		Follow Safe Procedures.....	1-1
		Prepare for Emergencies	1-1
		Handle Fluids Safely—Avoid Fires	1-1
		Prevent Battery Explosions	1-2
		Handle Chemical Products Safely	1-2
		Prevent Acid Burns	1-3
		Avoid High-Pressure Fluids	1-4
		Warn Others of Service Work	1-4
		Park Machine Safely	1-5
		Support Machine Properly.....	1-5
		Operate Only From Operator's Seat.....	1-5

TABLE OF CONTENTS (Continued)

	Page
Stay Clear of Moving Parts	1-6
Avoid Power Lines	1-6
Use Handholds and Steps	1-6
Keep Riders Off Machine.....	1-7
Move and Operate Machine Safely	1-7
Wear Protective Clothing	1-7
Protect Against Flying Debris	1-8
Protect Against Noise	1-8
Illuminate Work Area Safely.....	1-8
Service Machines Safely	1-8
Remove Paint Before Welding or Heating	1-9
Avoid Heating Near Pressurized Fluid Lines	1-9
Beware of Exhaust Fumes	1-10
Use Proper Lifting Equipment.....	1-10
Service Cooling System Safely	1-10
Dispose of Waste Properly	1-11
Work in a Clean Area.....	1-11
Use Tools Properly.....	1-12
Replace Safety Signs	1-12
Live With Safety	1-12
Battery Terminals, Lifting Equipment, Dry Cleaning, Solvent and Compressed Air	1-13
Compressor Equipment Hazards	1-14
Rock Drill Precautions	1-16
02 General Specifications	1-19
03 Torque Values.....	1-20
Unified Inch Bolt and Cap Screw Torque Values	1-20
Metric Bolt and Cap Screw Torque Values.....	1-21
Additional Metric Cap Screw Torque Values	1-22
Check Oil Lines and Fittings.....	1-23
Service Recommendations for O-Ring Boss Fittings.....	1-24
Service Recommendations for Flat Face O-Ring Seal Fittings	1-26
Service Recommendations for 37° Flare and 30° Cone Seat Connectors	1-27
Service Recommendations for Flared Connections— Straight or Tapered Threads	1-28
Service Recommendations for Inch Series Four Bolt Flange Fittings.....	1-29
Service Recommendations for Metric Series Four Bolt Flange Fitting....	1-31
04 Fuels and Lubricants.....	1-32
Diesel Fuel	1-32
Lubricity of Diesel Fuels.....	1-32
Low Sulfur Diesel Fuel Conditioner	1-33
Diesel Fuel Storage	1-33
Fuel Tank	1-34
Do Not Use Galvanized Containers	1-34
Diesel Engine and Pump Gearbox Oils	1-35
Hydraulic Oil.....	1-36
Swing Gearbox and Propel Gearbox Oils.....	1-37
Track Roller, Front Idler, and Carrier Roller Oil	1-37
Track Adjuster, Working Tool Pivot, Swing Bearing, and Swing Bearing Gear Grease.....	1-38
Oil Filters	1-38
Rock Drill Lubricants Specifications	1-39
Lubricant Storage	1-41
Alternative and Synthetic Lubricants	1-41

TABLE OF CONTENTS (Continued)

			Page
		Mixing of Lubricants.....	1-42
		Air Compressor Lubrication.....	1-43
Chapter 2	Section 9005	Operational Checkout Procedure	
	10	Operational Checkout Procedure.....	2-1
		Operational Checkout.....	2-1
		Operator Station Checks—Key Switch On, Engine Off.....	2-2
		Operator Station Checks—Engine On.....	2-5
		Hydraulic System Checks.....	2-11
		Undercarriage Checks.....	2-19
		Accessories Checks.....	2-21
		Seat, Doors, Windows, Latches, and Locks Checks.....	2-23
		Engine Cooling System Checks.....	2-29
		Air Intake System Checks.....	2-33
		Fuel System Checks.....	2-36
		Visual Inspection.....	2-38
Chapter 3	Section 9010	Engine	
	05	Theory of Operation.....	3-1
		Engine—Sectional View.....	3-1
		Fan Drive.....	3-2
		Engine Speed Control	
		System Operation.....	3-3
		Engine RPM Dial.....	3-5
		E (Economy) Mode.....	3-7
		HP (High Power) Mode.....	3-8
		Auto-Idle Mode.....	3-10
		Engine Speed Learning.....	3-11
	10	System Operational Checks.....	3-13
		Engine Operational Checks.....	3-13
		Cooling System Checks.....	3-13
		Air Intake System Checks.....	3-18
		Lubrication System Checks.....	3-21
		Fuel System Checks.....	3-23
		Engine Speed and Performance Checks.....	3-25
	15	Diagnostic Information.....	3-28
		Diagnose Engine Malfunctions.....	3-28
	20	Adjustments.....	3-40
		JT05801 Clamp-On Electronic Tachometer Installation.....	3-40
		Fuel Shut-Off Solenoid Linkage, Check and Adjust.....	3-41
		Engine Speed Check.....	3-44
		Injection Pump Fast and Slow Idle Stops.....	3-45
		Engine Control Motor and Sensor.....	3-48
		Engine Speed Learning Procedure.....	3-49
		Cooling System Fill and Deaeration.....	3-51
	25	Tests.....	3-52
		Fuel Line Leakage.....	3-52
		Air Filter Restriction Indicator Switch.....	3-53
		Air Intake System Leakage.....	3-54
		Radiator Air Flow.....	3-55
		Engine Power Test Using Turbocharger Boost Pressure.....	3-58
		Torsional Dampener, Inspect.....	3-62

TABLE OF CONTENTS (Continued)

	Page
Chapter 4	
Section 9015 Electrical System	
05 System Information	4-1
Visually Inspect Electrical System.....	4-1
Circuit Malfunctions	
Circuit Malfunctions	4-2
Definition.....	4-3
Location	4-8
Troubleshooting.....	4-9
Circuit Shorted to Power and Circuit Shorted to Itself.....	4-11
Using Test Equipment	
Multimeter	4-14
Seven Step Electrical Test Procedure	4-15
System Functional Schematic Information.....	4-16
Reading a System Functional Schematic Diagram.....	4-17
Reading a Harness Component Location Diagram	4-19
Electrical Schematic Symbols	4-23
10 System Diagrams.....	4-26
Fuse Specifications.....	4-26
Fuse (Blade-Type) Color Codes.....	4-27
Component Identification Table.....	4-27
Functional Schematic and Component Location Legend.....	4-29
System Functional Schematic Section Legend.....	4-33
System Functional Schematic (SE1—SE3).....	4-34
System Functional Schematic (SE4—SE6).....	4-35
System Functional Schematic (SE7—SE9).....	4-36
System Functional Schematic (SE10—SE12).....	4-37
System Functional Schematic (SE13—SE15).....	4-38
System Functional Schematic (SE16—SE18).....	4-39
System Functional Schematic (SE19)	4-40
Engine and Frame Harness (W1)	
Component Location	4-41
Connectors, Wire and Pin Location	4-45
Air Compressor and Rock Drill Harness (W10) Component Location....	4-49
Cab Harness (W2)	
Component Location	4-50
Component Location—Detail A (Harness Mating Connectors).....	4-51
Component Location—Detail B (Fuse Block).....	4-53
Connectors, Wire and Pin Location	4-54
Monitor and Relay Harness (W3)	
Component Location	4-60
Component Location—Detail A (Monitor Controller Connectors).....	4-61
Component Location—Detail B (Monitor Controller Indicators)	4-62
Connectors, Wire and Pin Location	4-63
Air Conditioner Harness (W9)	
Component Location—See Group 9031-15	4-65
Connectors, Wire and Pin Location—See Group 9031-15.....	4-65
15 Sub-System Diagnostics	4-66
Power Circuit	
Operational Information	4-66
Theory of Operation	4-67
Schematic.....	4-68
Power Circuit Diagnostic Procedures.....	4-69
Charging Circuit	
Operational Information	4-73
Theory of Operation	4-73

TABLE OF CONTENTS (Continued)

	Page
Schematic.....	4-74
Alternator Theory of Operation.....	4-75
Charging Circuit Diagnostic Procedures	4-76
Starting and Fuel Shutoff Circuit	
Operational Information	4-80
Theory of Operation	4-80
Schematic.....	4-81
Starting Circuit Diagnostic Procedures	4-82
Windshield Wiper and Washer Circuit	
Operational Information	4-88
Theory of Operation	4-89
Schematic.....	4-91
Windshield Wiper and Washer Circuit Diagnostic Procedures.....	4-92
Work and Drive Light Circuit	
Operational Information	4-97
Theory of Operation	4-97
Schematic.....	4-98
Work and Drive Light Circuit Diagnostic Procedures	4-99
Accessory Circuits	
Operational Information	4-102
Theory of Operation	4-102
Schematic.....	4-103
Accessory Circuits Diagnostic Procedures.....	4-104
Quick Hitch Circuit	
Operational Information	4-106
Theory of Operation	4-106
Schematic.....	4-107
Quick Hitch Circuit Diagnostic Procedures	4-107
Heater Circuit (Machines Without Air Conditioner).....	4-108
Heater Circuit (Machines With Air Conditioner).....	4-109
Monitor Controller and Display Circuit	
Specifications.....	4-110
Operational Information	4-111
Theory of Operation	4-112
Schematic.....	4-115
Monitor Controller and Display Circuit Diagnostic Procedures	4-116
Engine and Pump Controller Circuit	
Operational Information	4-133
Theory of Operation	4-134
Schematic.....	4-136
Engine and Pump Controller Circuit Diagnostic Procedures	4-137
Travel Alarm Circuit	
Operational Information	4-160
Theory of Operation	4-160
Schematic.....	4-161
Travel Alarm Circuit Diagnostic Procedures	4-162
Overload Alarm Circuit	
Operational Information	4-165
Theory of Operation	4-165
Schematic.....	4-166
Overload Alarm Circuit Diagnostic Procedures.....	4-166
20 References	4-169
Battery	
Operation	4-169
Specifications.....	4-170

TABLE OF CONTENTS (Continued)

			Page
		Diagnose Malfunctions	4-171
		Check Electrolyte Level and Terminals	4-172
		Batteries	
		Procedure for Testing	4-174
		Using Booster Batteries—24 Volt System	4-175
		Replacing	4-176
		Adding 12 or 24 Volt Accessories	4-177
		Travel Alarm, Changing Volume	4-178
		Test Harness	
		Proportional Solenoid	4-179
		Pump Control	4-179
		Pump Pressure Sensor	4-179
Chapter 5	Section 9020	Power Train	
	05	Theory of Operation	5-1
		Track Adjuster	5-1
		Propel Gearbox	5-2
	15	Diagnostic Information	5-4
		Diagnose Undercarriage Components Malfunctions	5-4
		Track Chain	
		Measure Bushing Wear	5-6
		Measure Link Wear	5-7
		Measure Pitch	5-8
		Track Shoe Grouser	
		Measure Wear (SN —599999)	5-9
		Measure Wear (SN 600000—)	5-10
		Track Roller, Measure Wear	5-11
		Track Carrier Roller, Measure Wear	5-12
		Front Idler, Measure Wear	5-13
		Swing Bearing, Measure Wear	5-14
	20	Adjustments	5-16
		Track Sag	5-16
Chapter 6	Section 9025	Hydraulic System	
	05	Theory of Operation	6-1
		Hydraulic System Diagram	6-1
		Pilot Pump Operation	6-2
		Pilot Pressure Regulating Valve and Filter Operation	6-3
		Pilot Shut-Off Valve Operation	6-4
		Pilot Controller	
		Neutral	6-6
		Metering and Full Stroke	6-7
		Propel Pilot Controller	6-8
		Pilot Controller Operation of Control Valve	6-10
		Flow Regulator Valve	6-11
		Hydraulic Pump and Drive Gearbox	6-13
		Hydraulic Pump Operation	6-15
		Hydraulic Pump Regulator	
		Component Operation	6-17
		Operation	6-19
		Increasing, Maximum, and Decreasing	6-21
		Summation and Speed Sensing	6-23
		Proportional Solenoid Valve	
		Manifold Operation	6-25

TABLE OF CONTENTS (Continued)

	Page
Arm Regenerative, Speed Sense, Propel Speed Change, and Power Boost	6-27
Engine Speed Sensing Control Circuit	6-29
Control Valve	
Component Identification Operation	6-30
Circuit Schematic	6-34
Pilot Pressure Signal Passage	6-36
Neutral and Power Passages	6-38
System Relief and Power Boost Valve	6-40
Power Boost Control Circuit	6-41
Circuit Relief Valve	6-42
Pump Control Valve	6-43
Flow Combiner Valve	6-45
Arm Regenerative Valve	6-47
Boom and Arm Reduced Leakage Valves	6-49
Bucket Flow Control Valve	6-50
Propel Flow Control Valve	6-52
Propel-Boom Down Selector Valve	6-53
Boom Regenerative Valve	6-54
Propel and Arm In Combined	6-55
Swing and Boom Up Combined	6-57
Swing Gearbox	6-59
Swing Motor	
Operation	6-61
Crossover Relief Valve	6-63
Make-Up Valve	6-64
Park Brake Release Valve	6-65
Rotary Manifold	6-67
Propel Motor	
Operation	6-68
Slow Speed	6-70
Fast Speed	6-71
Speed Change Circuit	6-72
Park Brake Valve Housing	6-74
Park Brake Release Circuit	6-76
Counterbalance Valve	6-78
Cylinder Boom, Arm, and Bucket	6-80
Return Filter	6-81
Boom Cylinder Controlled Load Lowering Valve Operation	6-82
Auxiliary Hydraulics Operation	6-84
Hydraulic System Circuit Symbols	6-86
Schematic	
Pilot Controllers Circuit	6-87
Hydraulic Pump and Control Valve	6-88
Swing and Propel Motor	6-89
15 Diagnostic Information	6-90
Diagnostic Procedure	6-90
Diagnose Malfunctions	
Electronic and Control Valve Component	6-91
Hydraulic System	6-101
Pilot Circuit	6-104
Dig Circuit	6-106
Swing Circuit	6-108
Propel System	6-110
Control Lever Pattern Conversion	6-113

TABLE OF CONTENTS (Continued)

	Page
Control Valve Line Identification	
Left Front.....	6-114
Right Rear.....	6-116
Bottom.....	6-118
Control Valve Component Identification	
Left Front.....	6-119
Right Rear.....	6-121
Bottom.....	6-123
Component Location	
Main Hydraulic System.....	6-124
Pilot Controllers-to-Flow Regulator—SAE Pattern.....	6-125
Pilot Controllers-to-Flow Regulator—John Deere Pattern.....	6-126
Pilot Flow Regulator-to-Control Valve.....	6-127
Propel System.....	6-128
Pressure and Return System.....	6-129
20 Adjustment.....	6-130
Pilot Shut-Off Valve Linkage.....	6-130
25 Tests.....	6-131
Laptop Computer General Description.....	6-131
Excavator Diagnostics Program	
Overview.....	6-131
Install.....	6-132
Uninstall.....	6-137
Starting.....	6-137
Feature—Service Codes.....	6-141
Feature—Monitor Data.....	6-143
Feature—Saving Monitor Data.....	6-145
Special Function—Engine Speed Adjustment.....	6-146
Service Codes List.....	6-150
Monitor Data Items.....	6-151
Special Function—Engine Speed Factory Settings Parameters.....	6-152
Engine Speed to Pump Flow Rate Chart.....	6-153
Excavator Diagnostics Program Troubleshooting.....	6-155
Reading Service Codes Without Excavator Diagnostics Program.....	6-156
Engine and Pump Controller Functions.....	6-158
JT05801 Clamp-On Electronic Tachometer Installation.....	6-159
JT05800 Digital Thermometer Installation.....	6-160
JT02156A Digital Pressure and Temperature Analyzer Installation.....	6-160
Start-Up Procedure	
Hydraulic Pump.....	6-161
Swing Motor.....	6-162
Swing Gearbox.....	6-163
Propel Motor.....	6-164
Hydraulic Oil Filter Inspection Procedure.....	6-164
Hydraulic Oil Cleanup Procedure Using Portable Filter Caddy.....	6-165
Hydraulic System Warm-Up Procedure.....	6-166
Lower Boom With Engine Stopped (Using Boom Cylinder Load Lowering Valve).....	6-167
Lower Boom With Engine Stopped (When Not Equipped With Boom Cylinder Load Lowering Valve).....	6-169
Harness Test	
Arm Regenerative Proportional Solenoid Valve (SC).....	6-171
Speed Sensing Solenoid Valve (SD).....	6-173
Propel Speed Change Proportional Solenoid Valve (SI).....	6-175
Power Boost Proportional Solenoid Valve (SG).....	6-177

TABLE OF CONTENTS (Continued)

		Page
	Engine Control Sensor (EC Sensor)	6-179
	Engine Control Motor (EC Motor)	6-182
	Miscellaneous Component.....	6-184
	Cycle Time	6-185
	Swing Dynamic Braking	6-188
	Pilot Pressure Regulating Valve.....	6-190
	Valve Spool Actuating Pilot Pressure	6-194
	System Relief and Power Boost Valve.....	6-197
	Circuit Relief Valve	6-202
	Swing Motor Crossover Relief Valve	6-208
	Propel Motor Crossover Relief Valve	6-211
	Proportional Solenoid Valve	6-215
	Pump Control Valve.....	6-220
	Hydraulic Pump Regulator	
	Adjustments	6-225
	Minimum Flow	6-228
	Maximum Flow	6-232
	Engine Pulldown.....	6-235
	Hydraulic Pump Flow	6-248
	Pilot Pump Flow.....	6-252
	Propel System Tracking	6-255
	Cylinder Drift—Boom, Arm, and Bucket	6-257
	Swing Motor Leakage	6-260
	Propel Motor Leakage.....	6-264
	Boom Cylinder Controlled Load Lowering Valve	6-268
	Hose Reel	6-270
Chapter 7	Section 9031 Air Conditioning System	
	05 Theory of Operation	7-1
	Proper Refrigerant Handling	7-1
	R134a Refrigerant Cautions	7-1
	Refrigerant Theory of Operation.....	7-2
	Heater and Air Conditioner Circuit	
	Operational Information	7-3
	Theory of Operation	7-4
	Functional Schematic.....	7-5
	Heater Circuit (Machines Without Air Conditioner)	
	Operational Information	7-6
	Theory of Operation	7-6
	Functional Schematic.....	7-7
	Receiver/Dryer Operation	7-8
	Compressor Relief Valve Operation	7-9
	Temperature Control	7-9
	10 System Operational Checks.....	7-10
	Air Conditioning Operational Checks	7-10
	Visual Inspection of Components	7-10
	System Operating Checks	7-12
	Heater Circuit Checks (Machines Equipped With Heater Only).....	7-14
	Heater and Air Conditioner Circuit Checks	7-15
	15 Diagnostic Information.....	7-17
	Diagnose Air Conditioning Electrical Malfunctions	7-17
	Air Conditioner Harness (W9)	
	Component Location	7-18
	Connectors, Wire and Pin Location	7-20

TABLE OF CONTENTS (Continued)

			Page
20	Adjustments.....		7-22
	Refrigerant		
	Proper Handling.....		7-22
	R134a Cautions.....		7-22
	Compressor		
	R134a Oil Charge Check.....		7-23
	R134a Oil Removal.....		7-23
	R134a Component Oil Charge.....		7-24
	R134a Refrigerant Recovery, Recycling, and Charging Station Installation Procedure.....		7-26
	R134a System		
	Recover.....		7-27
	Evacuate.....		7-28
	Charge.....		7-31
	Compressor Belt, Check and Adjust Tension.....		7-33
25	Tests.....		7-34
	Refrigerant		
	Proper Handling.....		7-34
	R134a Cautions.....		7-34
	R134a Air Conditioning System Test.....		7-35
	Operating Pressure Diagnostic Chart.....		7-38
	High and Low Pressure Switch Test.....		7-39
	Leak Testing.....		7-40
	Refrigerant Hoses and Tubing Inspection.....		7-41
Chapter 8	Section 9035 Arctic/Cold Weather Heater		
	05 Theory of Operation.....		8-1
	Arctic/Cold Weather Heater		
	Cautions.....		8-1
	Theory of Operation.....		8-2
	Wiring Diagram.....		8-4
	10 Operational Checks.....		8-6
	Arctic/Cold Weather Heater Checks.....		8-6
	15 Diagnostic Information.....		8-7
	Arctic/Cold Weather Heater		
	Diagnose Malfunctions.....		8-7
	Diagnostic Procedure.....		8-7
Chapter 9	Section 9040 Air Compressor		
	25 Troubleshooting.....		9-1
Chapter 10	Section 9045 Rock Drill Attachment		
	01 Components.....		10-1
	05 Drifter Maintenance.....		10-2
	Shank Replacement.....		10-2
	Flushing Seal Replacement.....		10-3
	Guide Ring Replacement.....		10-4
	Accumulator Check.....		10-5
	Accumulator Repairs.....		10-6
	Dust Collector Theory of Operation.....		10-7
	10 Adjusting of Drilling Automatism.....		10-10
	Location of Adjusting Screws.....		10-10
	E.53734 Pressure Gauges.....		10-11
	Presetting Before Drilling.....		10-12
	Presetting While Drilling.....		10-12

TABLE OF CONTENTS (Continued)

		Page
	Setting While Drilling	10-12
	Exceptional Adjustments.....	10-13
15	Thread Coupling/Uncoupling Adjustments	10-14
20	Diagrams.....	10-15
25	Troubleshooting.....	10-24
	Too Low Penetration Rate.....	10-25
	Troubleshooting Procedure for Rod Changer.....	10-28
	Troubleshooting Hydraulic Dust Collector	10-33
Chapter 11	Section 01 Tracks Repair	
0130	Track System.....	11-1
	Service Equipment and Tools.....	11-1
	Other Material	11-5
	Specifications	11-6
	Track Roller, Measure Wear	11-8
	230LC Carrier Roller Tread Diameter	11-9
	Track Roller	
	Remove and Install	11-10
	Disassemble and Assemble.....	11-12
	Test for Oil Leakage	11-14
	Track Carrier Roller, Measure Wear	11-14
	792 Carrier Roller Tread Diameter.....	11-15
	Track Carrier Roller	
	Remove and Install	11-16
	Disassemble and Assemble.....	11-18
	Metal Face Seals, Inspect	11-20
	Track Shoe Grouser, Measure Wear	11-21
	1010	
	Three Bar Grouser Height.....	11-22
	Front Idler Flange Height	11-23
	230LC Front Idler Flange Height	11-24
	Track Shoe, Remove and Install.....	11-25
	Track Chain Link, Measure Wear	11-26
	230LCR/230LCRD Link Height	11-27
	Track Chain Bushing, Measure Wear	11-27
	230LC Bushing Outer Diameter.....	11-28
	Track Chain, Measure Pitch	11-29
	230LC Pitch 190.50 mm (7.50 in.).....	11-30
	Track Chain	
	Remove.....	11-31
	Install	11-33
	Disassemble and Assemble.....	11-35
	Disassemble and Assemble to Replace Broken Part.....	11-36
	Track Sag, Adjust.....	11-39
	Sprocket, Remove and Install.....	11-42
	Front Idler	
	Measure Wear.....	11-43
	230LC Flange Height	11-44
	Remove and Install	11-45
	Disassemble	11-46
	Assemble	11-47
	Test for Oil Leakage	11-49
	Track Adjuster and Recoil Spring	
	Remove and Install	11-50
	Disassemble and Assemble.....	11-52
	Track Adjuster Cylinder, Disassemble and Assemble	11-56

TABLE OF CONTENTS (Continued)

		Page
Chapter 12	Section 02	Axles and Suspension Systems (Propel) Repair
	0250	Axle Shaft, Bearings, and Reduction Gears..... 12-1
		Service Equipment and Tools..... 12-1
		Other Material 12-2
		Specifications 12-3
		Towing the Excavator 12-4
		Propel Gearbox
		Remove and Install 12-5
		Disassemble 12-7
		Metal Face Seals, Inspect 12-14
		Planet Carrier
		Disassemble and Assemble First and Second 12-15
		Disassemble and Assemble Third..... 12-17
		Propel Gearbox, Assemble 12-18
	0260	Hydraulic System 12-26
		Essential Tools 12-26
		Service Equipment and Tools..... 12-26
		Other Material 12-28
		Specifications 12-29
		Propel Motor and Brake
		Remove and Install 12-30
		Start-Up Procedure 12-33
		Disassemble 12-34
		Assemble 12-41
		Propel Motor Brake Valve Housing, Disassemble and Assemble..... 12-49
		Rotary Manifold
		Remove and Install 12-51
		Disassemble and Assemble..... 12-58
		Air Test..... 12-60

TM 5-3805-280-24-2

Chapter 13	Section 04	Engine Repair
	0400	Removal and Installation 13-1
		Essential Tools 13-1
		Service Equipment and Tools..... 13-2
		Other Material 13-2
		Specifications 13-3
		Engine
		Remove..... 13-4
		Install 13-8
		Oil Pan
		Remove..... 13-10
		Install 13-11
		In-Line Fuel Injection Pump
		Remove..... 13-11
		Repair 13-14
		Install 13-14
		Bleed Fuel System..... 13-18
		Engine Crankcase Ventilation Tube, Clean..... 13-19
		Engine Valve Lash (Clearance), Check and Adjust 13-19
		Firing Order, 6-Cylinder Engine 13-22
		Starter, Remove and Install 13-23
		PowerTech® 4.5 L Engine 13-24
		PowerTech® 6.8 L Engine 13-25

TABLE OF CONTENTS (Continued)

	Page
General Information	13-26
Unified Inch Bolt and Cap Screw Torque Values	13-26
Metric Bolt and Cap Screw Torque Values.....	13-27
Engine Model Designation.....	13-28
Engine Serial Number Plate Information	13-29
General OEM Engine Specifications.....	13-30
Fuels, Lubricants and Coolant	13-31
Diesel Fuel	13-31
Lubricity of Diesel Fuels.....	13-31
Engine Break-In Oil	13-32
Diesel Engine Oil	13-33
Alternative and Synthetic Lubricants	13-34
Mixing of Lubricants.....	13-34
Grease.....	13-35
Diesel Engine Coolant Recommendations	13-36
Engine Coolant Specifications	13-37
Testing Diesel Engine Coolant.....	13-40
Replenishing Supplemental Coolant Additives (SCA's)	
Between Coolant Changes	13-41
Operating in Warm Temperature Climates	13-42
Flush and Service Cooling System.....	13-43
Disposing of Coolant.....	13-44
Engine Mounting	13-45
Engine Repair Stand.....	13-45
Safety Precautions	13-46
Install Adapters on Engine Repair Stand.....	13-47
Engine Lifting Procedure	13-48
Clean Engine	13-49
Disconnect Turbocharger Oil Inlet Line.....	13-50
Mount Engine on Repair Stand	13-51
Engine Mounted on Repair Stand.....	13-52
Engine Rebuild Guide	13-53
Engine Disassembly Sequence	13-53
Sealant Application Guidelines	13-55
Engine Assembly Sequence	13-57
Cylinder Head and Valves	13-59
Essential Tools	13-59
Service Equipment and Tools.....	13-62
Other Material	13-64
Cylinder Head and Valves Specifications	13-65
Valve Clearance, Check and Adjust.....	13-68
Valve Lift, Measure.....	13-71
Cylinder Head, Remove	13-73
Rocker Arm Shaft Assembly, Disassemble and Inspect	13-79
Rocker Arm Assembly, Assemble	13-80
Fuel Supply Pump Push Rod—If Applicable	
Inspect, Measure, and Install	13-80
Camshaft Followers—Inspect, Measure, and Assemble	13-82
Valve Recess in Cylinder Head, Measure	13-83
Preliminary Cylinder Head and Valve Checks	13-84
Valve Assembly, Remove	13-85
Valve Springs, Inspect and Measure	13-86
Valve Rotators, Inspect	13-86

TABLE OF CONTENTS (Continued)

	Page
Valves	
Clean.....	13-87
Inspect and Measure	13-87
Grind.....	13-88
Cylinder Head	
Inspect and Clean.....	13-89
Check Flatness	13-89
Measure Thickness	13-90
Clean Injection Nozzle Bores.....	13-90
Valve Guides	
Clean.....	13-91
Measure	13-91
Knurl.....	13-92
Valve Seats	
Clean and Inspect.....	13-92
Grind.....	13-93
Remove Inserts	13-96
Measure Bore in Cylinder Head	13-99
Install Inserts.....	13-100
Valves, Install.....	13-100
Cylinder Head Cap Screws, Clean and Inspect	13-101
Exhaust Manifold, Inspect and Clean.....	13-101
Top Deck of Cylinder Block, Clean and Inspect.....	13-102
Cylinder Liner Standout (Height Above Block), Measure	13-103
Cylinder Head, Install.....	13-104
Torque-Turn Method for Proper Torque	13-106
Rocker Arm Assembly, Install	13-107
Ventilator Outlet Hose, Inspect and Clean	13-107
Rocker Arm Cover, Install	13-108
Complete Final Assembly	13-109
Perform Engine Break-In	13-113
Cylinder Block, Liners, Pistons and Rods	13-114
Essential Tools	13-114
Service Equipment and Tools.....	13-117
Other Material	13-118
Cylinder Block, Liners, Pistons and Rods Specifications	13-119
Connecting Rods—General Information.....	13-125
Pistons and Connecting Rods, Remove.....	13-126
Cylinder Liners, Remove	13-129
Complete Disassembly of Cylinder Block (If Required)	13-131
Preliminary Liner, Piston and Rod Checks	13-132
Piston and Rod Assembly, Disassemble.....	13-133
Pistons	
Clean.....	13-134
Visually Inspect	13-135
Cylinder Liners	
Clean.....	13-136
Visually Inspect	13-137
Piston	
Check Ring Groove Wear.....	13-139
Measure Pin Bore	13-140
Measure Skirt.....	13-140
Measure Height.....	13-140
Determine Piston-to-Liner Clearance.....	13-141
Cylinder Liners, Deglaze.....	13-142

TABLE OF CONTENTS (Continued)

	Page
Piston and Liner Sets, Replace	13-143
Inspect and Measure Connecting Rod Bearings	
(Rods Removed From Engine)	13-143
(Rod and Crankshaft in Engine)	13-144
Rod and Cap, Inspect	13-145
Piston Pins and Bushings, Inspect	13-147
Piston Pin Bushing, Remove	13-148
Connecting Rod Pin Bore, Clean and Inspect	13-150
Piston Pin Bushing in Connecting Rod, Install	13-151
Rod Center-to-Center Bores, Measure	13-152
Cylinder Block, Inspect and Clean	13-153
Cylinder Liner O-Ring Bore, Clean	13-155
Measure	
Cylinder Block Main Bearing Bore	13-155
Camshaft Follower Machined Bore in Block	13-156
Camshaft Bushing Bores in Block	13-156
Balancer Shaft Bushing ID in Block—4-Cylinder Engines	13-158
Cylinder Liners and Block Bores	13-159
Liner Flange Counterbore Depth in Block	13-160
Liner Flange Thickness	13-160
Cylinder Block Top Deck Flatness	13-161
Piston Cooling Orifices— Remove, Inspect, and Install	13-162
Fuel Supply Pump Push Rod Bore and Push Rod OD, Measure	13-163
Cylinder Liner Standout (Height Above Block), Measure	13-164
Install Packing on Cylinder Liner and O-Rings in Block	13-166
Install Cylinder Liner in Block	13-167
Piston and Connecting Rod, Assemble	13-168
Piston Rings, Install	13-170
Piston and Connecting Rod Assembly, Install	13-171
Torque-Turn Connecting Rod Cap Screws	13-175
Check Engine Rotation for Excessive Tightness	13-176
Piston Protrusion, Measure	13-177
Complete Final Assembly	13-178
Crankshaft, Main Bearings and Flywheel	13-179
Essential Tools	13-179
Service Equipment and Tools	13-182
Other Material	13-184
Crankshaft, Main Bearings and Flywheel Specifications	13-185
Crankshaft and Main Bearing Failure Analysis	13-187
Vibration Damper (6-Cylinder Engine), Inspect	13-188
Pulley or Vibration Damper and Pulley, Remove	13-189
Pulley or Vibration Damper Pulley, Install	13-191
Checking Vibration Damper or Pulley	13-193
Front Crankshaft Oil Seal and Wear Sleeve, Replace	13-193
Crankshaft End Play, Check	13-198
Flywheel, Inspect	13-199
Flywheel Face, Check Flatness	13-200
Pilot Bearing Bore, Check Concentricity	13-200
Flywheel	
Check Housing Face Runout	13-201
Remove	13-202
Replace Ring Gear	13-202
Replace Pilot Bearing—If Equipped	13-204
Install	13-205

TABLE OF CONTENTS (Continued)

	Page
Crankshaft Rear Oil Seal and Wear Sleeve	
Handling Precautions.....	13-206
Remove.....	13-206
Crankshaft Flange, Clean and Inspect.....	13-209
Crankshaft Rear Oil Seal and Wear Sleeve, Install.....	13-210
Flywheel Housing, Remove.....	13-213
Crankshaft Main Bearings, Remove.....	13-213
Check Main Bearing Oil Clearance.....	13-215
Crankshaft Gear (Crankshaft Installed in Engine)	
Remove and Install.....	13-216
Crankshaft, Remove.....	13-218
Crankshaft, Inspect.....	13-219
Crankshaft Journals and Main Bearing ID, Measure.....	13-220
Main Thrust Journal and Thrust Bearing, Measure Width.....	13-221
Crankshaft Grinding Guidelines.....	13-222
Crankshaft Grinding Specifications.....	13-223
Main Bearing Caps, Measure Assembled ID.....	13-224
Piston Cooling Orifices—Remove, Inspect, and Install.....	13-225
Main and Thrust Bearing Inserts, Install in Block.....	13-226
Crankshaft, Install.....	13-228
Flywheel Housing, Install.....	13-231
Complete Final Assembly.....	13-232
Camshaft, Balancer Shafts and Timing Gear Train.....	13-233
Essential Tools.....	13-233
Service Equipment and Tools.....	13-236
Other Material.....	13-237
Camshaft, Balancer Shafts and Timing Gear Train Specifications.....	13-238
Measure Valve Lift.....	13-243
Timing Gear Cover, Remove.....	13-245
Camshaft Bushing With Front Plate Installed, Remove and Install.....	13-248
Camshaft Gear-Driven Auxiliary Drive, Remove and Install.....	13-251
Measure End Play	
Camshaft.....	13-252
Balancer Shaft (4-Cylinder Engines).....	13-252
Idler Gear.....	13-253
Timing Gear, Measure Backlash.....	13-254
Camshaft	
Remove.....	13-255
Visually Inspect.....	13-257
Measure Thrust Plate Clearance and Thickness.....	13-258
Inspect and Measure Bushing ID and Journal OD.....	13-259
Measure Lobe Height.....	13-260
Remove and Install Gear.....	13-260
Inspect Followers.....	13-262
Fuel Supply Pump Push Rod—Inspect, Measure, and Install.....	13-263
Electronic Tachometer (Magnetic Pick-Up) Sensor, Replace.....	13-264
Mechanical Tachometer Adapter, Replace.....	13-265
Balancer Shaft	
Remove—If Equipped (4-Cylinder Engines).....	13-266
Inspect and Measure Bushings and Journals.....	13-267
Remove and Install Bushings (4-Cylinder Engines).....	13-268
Inspect Gears and Thrust Plates.....	13-268
Remove and Install Gears.....	13-269
Cylinder Block Front Plate, Remove.....	13-270

TABLE OF CONTENTS (Continued)

	Page
Idler Gear Bushings	
Measure Bushing and Shaft	13-272
Remove	13-273
Install	13-274
Lower and Upper Idler Shafts, Remove	13-275
Front Plate, Clean and Inspect.....	13-275
Transfer Fuel Injection Pump Timing Mark	
Onto Replacement Front Plate	13-276
Idler Shaft Spring Pins (If Equipped), Install	13-277
Upper Idler Shaft, Install in Front Plate	13-277
Lower Idler Shaft, Install in Front Plate.....	13-278
Engine Front Plate, Install	13-278
Balancer Shafts (4-Cylinder Engines), Install and Time	13-280
Camshaft and Rotary Fuel Injection Pump, Install and Time.....	13-284
Timing Gear Cover, Clean and Inspect	13-287
Timing Gear Cover, Install.....	13-288
Crankshaft Front Wear Sleeve and Oil Seal, Install	13-290
Complete Final Assembly	13-293
Lubrication System.....	13-294
Essential Tools	13-294
Service Equipment and Tools.....	13-296
Other Material	13-297
Lubrication System Specifications	13-298
General Lubrication System Information	13-300
Remove, Inspect, and Install	
Oil Filter Base.....	13-300
Oil Cooler	13-303
Oil Bypass Valve	13-307
Remove and Install	
Oil Pressure Regulating Valve and Seat	13-307
Oil Fill Tube	13-309
Dipstick Tube With Oil Pan Installed.....	13-310
Dipstick Tube With Fitting	13-311
Oil Pump Pick-Up Tube Assembly—Remove, Inspect, and Install.....	13-312
Engine Oil Pump Assembly	13-313
Engine Oil Pump, Remove.....	13-313
Inspect and Measure Clearances	13-315
Complete Oil Pump Disassembly.....	13-318
Engine Oil Pump, Assemble	13-318
Engine Oil Pump, Install	13-319
Oil Pan, Install.....	13-322
Cooling System.....	13-324
Essential Tools	13-324
Service Equipment and Tools.....	13-324
Other Material	13-325
Cooling System Specifications	13-326
Diagnosing Cooling System Malfunctions.....	13-328
Water Manifold/Thermostat Cover and Thermostat, Remove	13-329
Water Manifold/Thermostat Cover and Thermostat, Install.....	13-330
Water Manifold and Thermostats	
(Dual Thermostats), Remove and Install	13-332
Test Thermostat(s).....	13-333
Water Pump	
Remove.....	13-334
Assembly	13-335

TABLE OF CONTENTS (Continued)

	Page
Disassemble	13-335
Inspect, Clean, and Measure Parts	13-338
Assemble	13-339
Install	13-341
Cooling System Deaeration	13-343
Automatic (Spring) Belt Tensioner, Remove and Install	13-343
Checking Belt Tensioner Spring Tension and Belt Wear	13-344
Manual Belt Tensioner Adjustment	13-346
Fan Assembly, Inspect and Install	13-347
Fan Drive Assembly, Remove and Inspect	13-347
Adjustable Fan Drive Assembly, Replace Bearings	13-350
Fan Drive Assembly, Install	13-353
Coolant Heater—If Equipped, Remove and Install	13-355
Temperature Switch (Cold Start Advance), Remove and Install	13-356
Air Intake and Exhaust System	13-357
Other Material	13-357
Air Intake and Exhaust System Specifications	13-358
Turbocharger	
Extending Life	13-359
Remove	13-361
Failure Analysis	13-362
Seven-Step Inspection	13-364
Perform Radial Bearing Clearance Test	13-370
Perform Axial Bearing End Play Test	13-371
Turbocharger	
Adjust Wastegate Actuator	13-372
Repair	13-373
Prelube	13-373
Install	13-374
Break-In	13-375
Recommendations for Use	13-376
Exhaust Manifold—Remove, Inspect, and Install	13-376
Air-to-Air Aftercooler, Remove and Install	13-378
Air Intake Pipe, Remove and Install	13-378
Air Heater, Remove and Install	13-379
Fuel System	13-380
Essential Tools	13-380
Service Equipment and Tools	13-383
Other Material	13-384
Fuel System Specifications	13-385
Fuel System—General Information	13-388
Relieve Fuel System Pressure	13-389
Final Fuel Filter and/or Primary Fuel	
Filter/Water Separator Base, Remove	13-390
Primary Fuel Filter/Water Separator Assembly	13-392
Final Fuel Filter Assembly	13-393
Final Fuel Filter and Primary Fuel Filter/Water Separator, Replace	13-394
Fuel Supply Pump	
Remove	13-396
Bench Test	13-397
Install	13-399
Remove on In-Line Fuel Injection Pump	13-400
Test In-Line Pump for Leaks	13-401
Disassemble	13-402
Inspect and Repair Components	13-405

TABLE OF CONTENTS (Continued)

	Page
Assemble	13-407
Install on In-Line Fuel Injection Pump	13-408
Service Injection Pump Overflow Valve	13-408
Fuel Shutoff Solenoid, Remove and Install	13-410
Rotary Fuel Injection Pump Timing	13-411
In-Line Fuel Injection Pump Timing	13-412
Stanadyne Model DB2 and DB4 Injection Pump, Remove	13-413
Injection Pump Drive Gear I.D. and Shaft O.D., Inspect	13-415
Stanadyne Fuel Injection Pump, Repair	13-416
Stanadyne Model DB2 and DB4 Injection Pump, Install	13-417
Lucas Fuel Injection Pump	
Remove	13-420
Repair	13-423
Install	13-423
In-Line Fuel Injection Pump	
Remove	13-427
Repair	13-430
Install	13-430
Repair Aneroid	13-435
Transfer Fuel Injection Pump Timing Mark	
Onto Replacement Front Plate	13-436
Fuel Injection Nozzles	
Remove	13-437
Clean Nozzle Bore	13-438
Clean	13-439
Diagnose Malfunction	13-440
Test	13-441
Disassemble	13-446
Inspect and Clean Nozzle Body	13-449
Valve and Valve Seat, Inspect and Clean	13-450
Valve Adjusting Mechanism, Inspect	13-452
Fuel Injection Nozzles	
Assemble	13-453
Adjust	13-454
Install Seals	13-458
Install	13-459
Starting and Charging Systems	13-461
Essential Tools	13-461
Starting and Charging System Specifications	13-461
Starter, Remove and Install	13-462
Alternator, Remove and Install	13-463
Engine Tune-Up and Break-In	13-464
Effects of Altitude and Temperature on Engine Performance	13-464
Preliminary Engine Testing	13-465
General Tune-Up Recommendations	13-466
Dynamometer Test	13-467
Dynamometer Test Specifications	13-467
Engine Break-In Guidelines	13-470
Perform Engine Break-In	13-471
Engine Oil Consumption	13-472
Crankcase Ventilation System, Check	13-473
Air Intake System, Check	13-474
Exhaust System, Check	13-475
Cooling System, Check and Service	13-476
Electrical System, Check	13-478

TABLE OF CONTENTS (Continued)

	Page
Engine System Operation and Tests	13-479
Essential Tools	13-479
Engine Test Specifications	13-480
Engine—Sectional View	13-481
General Engine Description	13-482
How the Engine Lubrication System Works	13-483
How the Cooling System Works	13-485
Head Gasket Joint Construction and Operation	13-487
Diagnosing Head Gasket Joint Failures.....	13-489
Head Gasket Inspection and Repair Sequence	13-493
Diagnosing Engine Malfunctions	13-495
Test Engine Compression Pressure	13-498
Check Engine Oil Pressure.....	13-500
Check for Excessive Engine Crankcase Pressure (Blow-By).....	13-502
Pressure Test Cooling System and Radiator Cap	13-503
Inspect Thermostat and Test Opening Temperature.....	13-505
Engine Cranking Speed Test	13-506
Air Intake and Exhaust System Operation and Tests.....	13-507
Essential Tools	13-507
Service Equipment and Tools.....	13-507
Diagnosing Air Intake Malfunctions	13-509
How the Air Intake and Exhaust System Works	13-510
Air Cleaner Operation	13-511
Air Filter Restriction Indicator Switch Test	13-512
Intake Air Leak Test.....	13-513
Exhaust Leak Check (Turbocharged Engines)	13-514
Intake and Exhaust Restriction Check.....	13-515
Diagnosing Turbocharger Malfunctions.....	13-516
Turbocharger Operation	13-517
How the Turbocharger is Lubricated.....	13-517
Check Intake Manifold Pressure (Turbocharger Boost).....	13-518
Intake Manifold Pressure (Turbocharger Boost) Specifications.....	13-520
Turbocharger Wastegate Test.....	13-526
Turbocharger Oil Seal Leak Test	13-527
Fuel System Operation and Tests	13-528
Essential Tools	13-528
Service Equipment and Tools.....	13-529
Fuel System Test Specifications.....	13-531
Rotary Fuel Injection Pump Specifications	13-532
Fuel Injection Pump—General Information.....	13-542
Using TIME TRAC® as a Tachometer	13-543
Rotary Injection Pump Dynamic Timing, Check and Adjust.....	13-543
In-Line Injection Pump Static Timing, Check and Adjust	13-550
Fuel System Operation—Rotary Fuel Injection Pump	13-551
Fuel System Operation—In-Line Fuel Injection Pump	13-553
Diagnose Fuel System Malfunctions.....	13-555
Fuel Supply Quality Check	13-559
Air in Fuel Test	13-560
Restricted Fuel Return Line Check	13-561
Rotary Injection Pump	
Fuel Supply Pump Operation.....	13-562
Diagnose Fuel Supply Pump Malfunctions	13-563
Measure Fuel Supply Pump Pressure	13-564

TABLE OF CONTENTS (Continued)

Page

In-Line Injection Pump	
Fuel Supply Pump Operation.....	13-565
Measure Fuel Supply Pump Pressure	13-567
Diagnose Fuel Supply Pump Malfunctions	13-568
Test Fuel Supply Pump for Leaks.....	13-569
Check Fuel Supply Pump Operation.....	13-570
Service Fuel Supply Pump	13-572
Rotary Pumps	
Cold Start Advance System Operation	13-573
Cold Start Switch Operational Check.....	13-574
Cold Start Advance System Operational Check	13-575
Light Load Advance Operation	13-577
Light Load Advance Operational Checkout	13-577
Fuel Shut-Off Solenoid Operational Check	
(In-Line Injection Pumps).....	13-578
Fuel Shut-Off Solenoid Resistance Test (Nippondenso Pump).....	13-579
Fuel Shut-Off Solenoid Resistance Test (Lucas Pump)	13-580
Fuel Shut-Off Solenoid Linkage Adjustment	
(In-Line Injection Pumps).....	13-581
Final Fuel Filter/Water Separator Operation.....	13-582
Bleed the Fuel System.....	13-583
Stanadyne Rotary Fuel Injection Pump Operation	13-587
Lucas Rotary Fuel Injection Pump Operation	13-589
Diagnose Rotary Fuel Injection Pump Malfunctions	13-591
Check and Adjust Engine Speeds on Lucas Pump	13-592
Adjust Variable Speed on Generator Set Engines	
(Lucas Pumps Only)	13-593
Check and Adjust Engine Speeds on Stanadyne Pump.....	13-594
Adjust Variable Speed (Droop) on Generator Set Engines (3—5%	
Governor Regulation)—Stanadyne DB2 and DB4 Injection Pumps ..	13-595
In-Line Fuel Injection Pump Operation.....	13-596
Diagnose In-Line Fuel Injection Pump Malfunctions	13-597
Check Fast Idle Speed—In-Line Fuel Injection Pump.....	13-598
Check and Adjust Slow Idle Speed—In-Line Fuel Injection Pump.....	13-599
Change Engine Rated Speed and Adjust	
Droop—In-Line Injection Pumps	13-601
How the Aneroid Works (If Equipped)	13-603
Diagnose Aneroid Malfunctions.....	13-604
Fuel Injection Nozzles—General Information and Operation.....	13-605
Diagnose Fuel Injection Nozzle Malfunctions	13-607
Test Fuel Injection Nozzles (Engine Running)	13-608
Fuel Drain Back Test Procedure	13-609
Dealer Fabricated Tools.....	13-610
How to Make Tools.....	13-610
DFRG3—Cylinder Liner Holding Fixture	13-610
DFRG5—Injection Pump Front Plate Timing Mark Transfer Tool.....	13-611
Engine Oil Dipstick Tube Driver	
(6010—6910 Series Tractor Engines)	13-612
Chapter 14 Section 05 Engine Auxiliary System Repair	
0505B Cold Weather Starting Aids.....	14-1
Engine Coolant Heater	
Remove and Install	14-1
Disassemble and Assemble.....	14-3

TABLE OF CONTENTS (Continued)

		Page
0510	Cooling System.....	14-5
	Specifications	14-5
	Radiator, Oil Cooler, and Fan Shroud—Remove and Install	14-5
	Fan and Fan Guard, Remove and Install	14-7
	Fan Belt, Remove and Install	14-8
	Thermostats, Remove and Install	14-9
	Cooling System Fill and Deaeration.....	14-11
0515	Speed Controls.....	14-12
	Service Equipment and Tools.....	14-12
	Specifications	14-13
	Injection Pump Fast and Slow Idle Stops Adjustment	14-14
	Engine Speed Control Cable, Remove and Install.....	14-17
	Engine Control Motor and Sensor	
	Remove and Install	14-18
	Adjustment.....	14-19
	Engine Speed Learning Procedure	14-20
	Fuel Shut-Off Solenoid Linkage	
	Remove and Install	14-22
	Check and Adjust.....	14-23
0520	Intake System	14-25
	Essential Tools	14-25
	Service Equipment and Tools.....	14-25
	Specifications	14-26
	Air Intake System Leakage Test.....	14-27
	Air Cleaner	
	Remove and Install	14-28
	Disassemble and Assemble.....	14-29
	Charge Air Cooler, Remove and Install	14-31
0560	External Fuel Supply System.....	14-33
	Other Material	14-33
	Specifications	14-33
	Fuel Tank, Remove and Install.....	14-34
	Primary Fuel Filter (Water Separator)	
	Remove and Install	14-36
	Element, Remove and Install	14-38
	Final Fuel Filter	
	Remove and Install	14-40
	Element, Remove and Install	14-41
	Bleed Fuel System.....	14-43
	Arctic/Cold Weather Heater Fuel Supply Pump, Remove and Install...	14-44
Chapter 15	Section 07 Dampener Drive (Flex Coupling) Repair	
	0752 Elements	15-1
	Service Equipment and Tools.....	15-1
	Other Material	15-1
	Specifications	15-2
	Dampener Drive (Flex Coupling), Remove and Install.....	15-2
Chapter 16	Section 16 Electrical System Repair	
	1671 Batteries, Support, and Cables.....	16-1
	Service Equipment and Tools.....	16-1
	Specifications	16-2
	Batteries	
	Handle Safely.....	16-3
	Procedure for Testing	16-4

TABLE OF CONTENTS (Continued)

	Page
Check Battery Electrolyte Level and Terminals.....	16-5
Using Booster Batteries—24-Volt System.....	16-6
Battery, Charge.....	16-8
Engine Speed Learning Procedure	16-10
Batteries, Remove and Install.....	16-12
Adding 12-Volt Accessories	16-13
24-Volt Slave Receptacle, Remove and Install	16-14
1672 Alternator, Regulator, and Charging System Wiring.....	16-15
Service Equipment and Tools.....	16-15
Specifications	16-15
Fan Belt—Inspect, Remove, and Install.....	16-16
Alternator, Remove and Install.....	16-17
Function of Alternator.....	16-19
Special or Essential Tools	16-21
Robert Bosch Charging Circuit Specifications.....	16-22
Alternator, Section View.....	16-23
Alternator—Removal	16-23
Removing Brush Holder With Regulator	16-24
Alternator—Disassembly	16-24
Stator—Removal.....	16-24
Diode Plate—Removal.....	16-24
Alternator, Exploded View.....	16-25
Testing Rotor for Short Circuit.....	16-26
Testing Rotor for Ground.....	16-26
Testing Slip Rings and Rotor Shaft for Radial Runout	16-26
Turning Down Slip Rings.....	16-27
Testing Stator Coil for Short Circuit	16-27
Testing Stator Coil for Grounds	16-27
Replacing Carbon Brushes	16-28
Replacing Ball Bearings.....	16-28
Checking Positive Diodes	16-28
Checking Negative Diodes.....	16-29
Testing Exciting Diodes	16-29
Diode Plate Installation	16-30
Soldering Stator Coils	16-30
Pressing Ball Bearing Onto Rotor Shaft.....	16-30
Pressing Rotor Into Drive End Frame	16-31
Alternator—Assembly.....	16-31
Installing Brush Holder With Regulator.....	16-31
Fan and Belt Pulley—Installation	16-31
1674 Wiring Harness and Switches	16-32
Excavator Overview.....	16-32
Component Location Drawing	
Legend	16-33
Cab.....	16-37
Engine and Frame Harness	16-38
Air Compressor and Rock Drill Harness	16-40
Fuses	
Replacing.....	16-41
(Blade-Type) Color Codes.....	16-43
Remove and Install	
Control Panel Switches.....	16-44
Dome Light Switch.....	16-45
Propel Alarm Cancel Switch and Start Aid Switch	16-46
Starter Switch.....	16-46

TABLE OF CONTENTS (Continued)

	Page
Cab Ground Straps.....	16-47
Engine Temperature Switch.....	16-48
Charge Air Temperature Switch.....	16-48
Coolant Level Switch.....	16-49
Engine Oil Pressure Switch.....	16-49
Engine Oil Level Switch.....	16-50
Engine Coolant Temperature Sensor.....	16-50
Fuel Level Switch.....	16-51
Fuel Level Sensor.....	16-51
Travel Alarm	
Remove and Install.....	16-52
Changing Volume.....	16-52
Remove and Install	
Propel Pressure Switch.....	16-53
Dig Pressure Switch.....	16-54
Rear Pump Pressure Sensor.....	16-54
Front Pump Pressure Sensor.....	16-55
Engine Speed Sensor.....	16-55
Pump Control Pressure Sensor.....	16-56
Proportional Solenoids.....	16-56
Engine Hourmeter Switch.....	16-57
Windshield Wiper Enable Switch.....	16-57
Air Cleaner Restriction Indicator Switch.....	16-58
Engine and Pump Controller (EPC)	
Connecting Harness Connector.....	16-58
Remove and Install.....	16-59
Monitor Panel and Switch Panel Bulb, Replace.....	16-60
Monitor Panel, Remove and Install.....	16-60
Hour Meter, Remove and Install.....	16-62
Propel Alarm Volume, Changing.....	16-62
Spring Wire Retainer Connectors, Disconnecting.....	16-63
Tab Retainer Connectors, Disconnecting.....	16-63
Remove and Install	
Battery Relay.....	16-64
Starter Relay.....	16-65
Fuel Shutoff Relay.....	16-66
Hydraulic Oil Filter Restriction Switch (230LCRD).....	16-67
Overload Alarm Relay.....	16-68
Overload Alarm Pressure Switch.....	16-69
Overload Alarm Proximity Switch.....	16-70
1675 System Controls.....	16-71
Specifications.....	16-71
Welding on Machine.....	16-71
Engine and Pump Controller (EPC)	
Connecting Harness Connector.....	16-73
Remove and Install.....	16-73
Engine Speed Learning Procedure.....	16-74
Remove and Install	
Monitor Controller.....	16-76
Rockdrill Control Console.....	16-77
Rock Drill Start—Stop Selector Control Box.....	16-79
Compressor Remote Control Panel.....	16-80
1677 Starting Motors.....	16-81
General Information.....	16-81
Typical Starting Circuit Operation.....	16-81

TABLE OF CONTENTS (Continued)

		Page
	Typical Starting Motor Operation	16-82
	Special or Essential Tools	16-83
	Robert Bosch Starting Motor Specifications	16-84
	Make No-Load Test	16-85
	Diagnosing Starting Motor Malfunctions	16-86
	Robert Bosch Starting Motor	16-87
	Starting Motor, Exploded View	16-88
	Disassembly	16-89
	Solenoid Switch—Removal	16-89
	Carbon Brush Plate—Removal	16-89
	Armature—Removal	16-90
	Snap Ring—Removal	16-90
	Cleaning Parts	16-90
	Testing Armature for Grounds	16-90
	Testing Armature for Short Circuit	16-91
	Testing Armature for Open Circuit	16-91
	Turning Commutator Down	16-92
	Testing Commutator for Out-of-Roundness	16-92
	Testing Field Winding for Ground Circuits	16-93
	Field Winding—Removal	16-93
	Make Open Circuit Test for Field Windings	16-94
	Lubrication of Starting Motor (Before and During Assembly)	16-94
	Field Winding—Installation	16-95
	Checking Carbon Brush Plate for Grounds	16-95
	Testing Carbon Brushes	16-96
	Replace Carbon Brushes	16-96
	Engaging Lever—Installation	16-96
	Testing Armature End Play	16-97
	Installing Starting Motor	16-97
Chapter 17	Section 17	Frame or Supporting Structure Repair
	1740	Frame Installation
		Specifications
		Welding on Machine
		Welding Repair of Major Structure
	1749	Chassis Weights
		Service Equipment and Tools
		Specifications
		Counterweight, Remove and Install (Model 230LCR)
		Compressor, Remove and Install (Model 230LCRD)
Chapter 18	Section 18	Operator's Station Repair
	1800	Operator's Station
		Specifications
		Cab, Remove and Install
	1810	Operator Enclosure
		Service Equipment and Tools
		Other Material
		Windowpane
		Remove and Install Two Piece Molding
		Remove and Install One Piece Molding
		Sliding Windows, Remove and Install
		Windowpane Dimensions
	1821	Seat and Seat Belt
		Specifications

TABLE OF CONTENTS (Continued)

	Page
Seat	
Check Adjustments	18-12
Remove and Install	18-13
Seat Belt	
Remove and Install	18-19
Inspect.....	18-20
1830 Heating and Air Conditioning	18-21
Essential Tools	18-21
Service Equipment and Tools.....	18-22
Other Material	18-22
Specifications	18-23
R134a Refrigerant	
Proper Handling.....	18-23
Cautions	18-24
R134a Compressor Oil	
Charge Check.....	18-25
Removal.....	18-25
R134a Component Oil Charge	18-26
R134a Refrigerant Recovery, Recycling and Charging	
Station Installation Procedure.....	18-27
R134a System	
Recover.....	18-28
Evacuate.....	18-29
Charge.....	18-30
Air Conditioning Compressor	
Check and Adjust Belt Tension	18-31
Remove and Install	18-32
Disassemble and Inspect.....	18-33
Assemble	18-44
Inspect Manifolds	18-47
Remove and Install	
Receiver Dryer.....	18-48
Evaporator	18-50
Condenser	18-52
Heater Core—Machine With Air Conditioning.....	18-54
Heater Core and Blower Motor	18-56
Heater Hoses.....	18-58
Chapter 19 Section 19 Sheet Metal and Styling Repair	
1910 Hand Rails, Remove and Install	19-1
1919 Boom Cylinder Guard, Remove and Install.....	19-2
Chapter 20 Section 22 Compressor Repair	
2200 Disassembly and Assembly	20-1
Separator Tank	
Separator Tank.....	20-1
Remove and Install	20-3
Disassemble and Assemble.....	20-4
Disassemble and Assemble Cooling System.....	20-5
Unloader Valve Assembly	
Remove and Install	20-8
Disassemble and Assemble.....	20-10
Oil Temperature Bypass Valve Assembly	
Remove and Install	20-11
Disassemble and Assemble.....	20-14

TABLE OF CONTENTS (Continued)

Page

Oil Filter Assembly
 Remove and Install 20-14
 Disassemble and Assemble..... 20-16
 Minimum Pressure Valve
 Remove and Install 20-17
 Disassemble and Assemble..... 20-19
 Air Intake
 Remove and Install 20-20
 Disassemble and Assemble..... 20-22
 Disassemble and Assemble Air Cleaner Assembly..... 20-23
 Instrument Panel Assembly
 Remove and Install 20-24
 Disassemble and Assemble..... 20-26
 Disassemble and Assemble Air Piping..... 20-28
 Disassemble and Assemble Oil Piping..... 20-31

Chapter 21 Section 33 Excavator Repair

3302 Buckets 21-1
 Specifications 21-1
 Bucket Tooth, Replace 21-1
 Bucket Tooth Tip—Heavy-Duty Bucket, Replace..... 21-3
 Welding on Machine 21-3
 Tooth Shank, Remove and Install 21-5
 Cutting Edge
 Replace Welded 21-8
 Repair Cracked 21-9
 Bucket, Disassemble and Assemble 21-10
 Hydraulic Thumb
 Remove and Install (Model 230LCR)..... 21-12
 Lock-Up Procedure..... 21-14
 Quick-Disconnect Hitch
 Remove and Install (Model 230LCRD)..... 21-15
 Remove and Install (Model 230LCR)..... 21-17
 Disassemble 21-19
 Assemble 21-21
 3340 Frames 21-23
 Service Equipment and Tools..... 21-23
 Other Material 21-23
 Specifications 21-24
 Remove and Install
 Bucket Links..... 21-27
 Arm..... 21-29
 Boom 21-31
 Boom, Arm, and Bucket Pins, Bushings and Bosses—Inspect 21-36
 Bushings and Seals, Remove and Install 21-39
 3360 Hydraulic System 21-40
 Essential Tools 21-40
 Service Equipment and Tools..... 21-41
 Other Material 21-45
 Specifications 21-46
 Control Lever Pattern Conversion..... 21-56
 Hydraulic System Warm-Up Procedure 21-57
 Lower Boom With Engine Stopped (Using Boom Cylinder
 Load Lowering Valve)..... 21-59

TABLE OF CONTENTS (Continued)

	Page
Lower Boom With Engine Stopped (When Not Equipped With Boom Cylinder Load Lowering Valve)	21-60
Hydraulic Oil Cleanup Procedure Using Portable Filter Caddy	21-62
Hydraulic Pump and Drive Gearbox	
Remove and Install	21-63
Start-Up Procedure	21-65
Disassemble	21-66
Pilot Pump Drive Shaft and Gear, Disassemble and Assemble.....	21-79
Hydraulic Pump and Drive Gearbox, Assemble.....	21-80
Hydraulic Pump Regulator, Disassemble and Assemble	21-88
Pilot Pump	
Remove and Install	21-91
Disassemble and Assemble.....	21-92
Pilot Pressure Regulating Valve and Filter	
Remove and Install	21-94
Disassemble and Assemble.....	21-96
Pilot Shut-Off Valve	
Remove and Install	21-96
Linkage Adjustment.....	21-98
Disassemble and Assemble.....	21-99
Proportional Solenoid Valve	
Manifold, Remove and Install	21-100
Disassemble and Assemble.....	21-103
Dig Function Pilot Controller	
Remove and Install	21-106
Disassemble and Assemble.....	21-109
Propel Pilot Controller	
Remove and Install	21-112
Disassemble and Assemble.....	21-114
Flow Regulator Valve	
Remove and Install	21-117
Disassemble and Assemble.....	21-119
Control Valve	
Remove and Install	21-120
Disassemble and Assemble.....	21-128
System Relief Valve, Disassemble and Assemble	21-145
Circuit Relief and Anti-Cavitation Valve, Disassemble and Assemble.....	21-147
Hydraulic Oil Tank	
Remove and Install	21-148
Disassemble and Assemble.....	21-154
Return Filter and Bypass Valve, Remove and Install.....	21-155
Suction Strainer, Remove and Install	21-158
Hydraulic Oil Tank Relief Valve and Breather Filter Cap	
Disassemble and Assemble.....	21-162
Remove and Install	
Swing Motor Make-Up Oil Restriction Valve	21-163
Oil Cooler Bypass Valve	21-165
Oil Cooler	21-167
230 Left Boom Cylinder Controlled Load Lowering Valve	21-171
230 Right Boom Cylinder Controlled Load Lowering Valve.....	21-173
Boom Cylinder	21-175
Arm Cylinder.....	21-179
Bucket Cylinder.....	21-182
Hydraulic Cylinder Bleed Procedure.....	21-187

TABLE OF CONTENTS (Continued)

			Page
		Boom, Arm or Bucket Cylinder	
		Disassemble	21-188
		Assemble	21-198
		Hydraulic Thumb Cylinder	
		Remove and Install	21-212
		Disassemble and Assemble.....	21-214
		Hydraulic Hose Reel, Remove and Install.....	21-215
Chapter 22	Section 43	Swing or Pivoting System Repair	
	4350	Mechanical Drive Elements.....	22-1
		Service Equipment and Tools.....	22-1
		Other Material	22-3
		Specifications	22-4
		Swing Gearbox	
		Remove and Install	22-5
		Start-Up Procedure	22-8
		Disassemble and Assemble.....	22-9
		Upperstructure	
		Remove.....	22-18
		Install	22-24
		Swing Bearing	
		Remove and Install	22-28
		Disassemble and Assemble.....	22-30
		Install Upper Seal	22-34
		Install Lower Seal	22-35
	4360	Hydraulic System	22-36
		Specifications	22-36
		Swing Motor and Park Brake	
		Remove and Install	22-36
		Start-Up Procedure	22-38
		Disassemble	22-39
		Assemble	22-45
		Swing Motor Make-Up and Crossover Relief Valves	
		Disassemble and Assemble.....	22-52
		Swing Park Brake Orifice and Check Valve, Remove and Install	22-54
		Swing Park Brake Release Valve, Remove and Install	22-55
Chapter 23	Section 44	Rock Drill Repair	
	4400	Rock Drill	23-1
		Service Equipment and Tools.....	23-1
		Other Material	23-5
		Torque Specifications.....	23-6
		Rock Drill, Disassemble.....	23-7
		Hydraulic Drifter, Disassemble and Assemble.....	23-28
		HP Accumulator	
		Central, Disassemble and Assemble	23-46
		Disassemble and Assemble.....	23-47
		LP Accumulator, Disassemble and Assemble	23-48
		Hydraulic Drifter Inspection	23-49
		Disassemble and Assemble	
		GCX 14/12 Feed.....	23-74
		Rod Changer	23-96
		Cradle and Articulation.....	23-109
		Cross-Tilting Cylinder	23-111
		Electro-Hydraulic Equipment	23-112

TABLE OF CONTENTS (Continued)

		Page
	Dust Collector	23-160
	Hydraulic Drifter Control	23-165
	Remote Control Assembly	23-185
	Rock Drill, Assemble	23-190
Chapter 24	Section 99 Dealer Fabricated Tools	
	9900 Dealer Fabricated Tools.....	24-1
	ST4920 Track Recoil Spring Disassembly and Assembly Tool	24-1
	DFT1087 Track Recoil Spring Disassembly and Assembly Guard Tool.....	24-5
	DFT1110 Spacer	24-6
	DFT1036A Propel Gearbox Nut Wrench.....	24-7
	DFT1109 Holding Bar	24-8
	Rotary Manifold Lifting Tool.....	24-9
	DFT1089 Barrel Support.....	24-10
	DFT1144 Guide Pin	24-11
	DFT1119 Pump Support	24-12
Appendix A	Unit Preventive Maintenance Checks and Services (PMCS).....	A-1
Appendix B	Maintenance Allocation Chart for Hydraulic Excavator 230LCR and 230LCRD.....	B-1
Appendix C	References	C-1

WARRANTY

- 1. General.** This section explains the contractor's warranty for the Hydraulic Excavator (HYEX), including all of its components and subassemblies. It also contains information, instructions, methods and forms required to obtain services and/or supplies and for processing claims for items covered under warranty for the HYEX. If additional warranty information is required for the HYEX, contact your local Warranty Control Office/Officer (WARCO) or TACOM-WRN Logistics Assistance Representative (LAR). If your WARCO or TACOM LAR is not available, contact TACOM-WRN. The numbers at TACOM to call are DSN 786-7215/(810) 574-7215, DSN 786-7420/(810) 574-7420, or DSN 786-8297/(810) 574-8297. The caller should be prepared to provide: (1) name, (2) telephone number and/or electronic address, (3) complete unit designation, (4) identification of the vehicle to include serial number(s) and (5) a brief description of the problem.
- 2. Coverage Specific.** The information and data contained in this Technical Manual applies to the U.S. Army's Hydraulic Excavator (HYEX), model number 230LCR, NSN 3805-01-463-0804 and model number 230LCRD, NSN 3805-01-463-0806. The HYEX is manufactured by Deere & Company, Moline, IL under contract number DAAE07-98-D-S009.
- 3. Claim Procedures.** DA Form 2407, along with information and instructions provided by the contractor at time of delivery of the HYEX, shall be used to process warranty claims.
- 4. Claim Denial/Disputes.** All denials or disputes will be handled by TACOM. The contact point for warranty claim denials or disputes is:

Commander
U.S. Army Tank-Automotive and Armaments Command
ATTN: AMSTA-LC-CJBB
Warren, MI 48397-5000

Telephone: DSN 786-5314
Commercial: (810) 574-5314

- 5. Local WARCO.** Upon completion of warranty actions by the contractor, the WARCO shall complete and provide a copy of DA Form 2407 to TACOM for information and warranty tracking purposes only. **NOTE:** The DA Form 2407 shall be stamped or otherwise clearly marked "**FOR INFORMATION ONLY**". Send the completed DA Form 2407 to:

Commander
U.S. Army Tank-Automotive and Armaments Command
ATTN: AMSTA-LC-CJCB
Warren, MI 48397-5000

Telephone: DSN 786-7215
Commercial: (810) 574-7215

Forms may also be faxed to TACOM. Fax the forms to: DSN 786-5605, Commercial - (810) 574-5605. Include ATTN: AMSTA-LC-CJCB on all related materials being faxed to TACOM.

INTRODUCTION

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may also be available in other languages. (See your John Deere dealer to order.)

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction of forward travel.

SECTION NUMBERS (e.g., 01, 02, 16) of the Repair Chapters 11 through 24 refer to

the John Deere Functional Group Coding system.

WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate, which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

CALIFORNIA PROPOSITION 65 WARNING

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.

CHAPTER 1
SECTION 9000
GENERAL INFORMATION

BLANK

FOLLOW SAFE PROCEDURES

Unsafe work practices are dangerous. Understand service procedure before doing work; do not attempt shortcuts.



TS231 -19-07OCT88


TX,05,FF1611 -19-14JUN90-1/1

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291 -UN-23AUG88

DX,FIRE2 -19-03MAR93-1/1

HANDLE FLUIDS SAFELY—AVOID FIRES

Handle fuel with care; it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks. Always stop engine before refueling machine. Fill fuel tank outdoors.



TS202 -UN-23AUG88

TX,05,FF1622 -19-14JUN90-1/2

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



TS227 -UN-23AUG88

TX,05,FF1622 -19-14JUN90-2/2

Safety

PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



TS204 -UN-23AUG88

DX,SPARKS -19-03MAR93-1/1


HANDLE CHEMICAL PRODUCTS SAFELY

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with your machine include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

See your authorized dealer for MSDS's on chemical products used with your machine.



TS1132 -UN-26NOV90

TX,05,DH2500 -19-02OCT92-1/1

Safety

9000
01
3**PREVENT ACID BURNS**

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.



TS203 -JUN-23AUG88

DX_POISON -19-21APR93-1/1

Safety

9000
01
4


AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.




X9811 -UN-23AUG88

DX,FLUID -19-03MAR93-1/1

WARN OTHERS OF SERVICE WORK

Unexpected machine movement can cause serious injury.

Before performing any work on the machine, attach a "Do Not Operate" tag on the right control lever.



T7273AP -UN-08JUN90

TX,05,RR,566 -19-23JUL91-1/1

PARK MACHINE SAFELY

Before working on the machine:


- Park machine on a level surface.
- Lower bucket to the ground.
- Turn auto-idle switch off.
- Run engine with engine RPM dial at 1/3 position for 2 minutes.
- Move engine RPM dial to slow idle position.
- Turn key switch to OFF. Remove key from switch.
- Pull pilot control shutoff lever to locked position.
- Allow engine to cool.

TX,05,DH5002 -19-28MAY96-1/1

SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.




TS229 -UN-23AUG88

DX,LOWER -19-04JUN90-1/1

OPERATE ONLY FROM OPERATOR'S SEAT

Avoid possible injury or machine damage. Do not start engine by shorting across starter terminals.

NEVER start engine while standing on ground. Start engine only from operator's seat.



T6607AO -UN-18OCT88

TX,05,FF1615 -19-14JUN90-1/1


Safety

9000
01
6

STAY CLEAR OF MOVING PARTS

Entanglements in moving parts can cause serious injury.

To prevent accidents, use care when working around rotating parts.




T7273AS -UN-08JUN90

TX,05,RR,572 -19-12JUN90-1/1

AVOID POWER LINES

Serious injury or death can result from contact with electric lines.

Never move any part of the machine or load closer to electric line than 3 m (10 ft) plus twice the line insulator length.



T7273AD -UN-08JUN90

TX,05,RR,594 -19-12JUN90-1/1

USE HANDHOLDS AND STEPS

Falling is one of the major causes of personal injury.

When you get on and off the machine, always maintain a three point contact with the steps and handrails and face the machine. Do not use any controls as handholds.

Never jump on or off the machine. Never mount or dismount a moving machine.

Be careful of slippery conditions on platforms, steps, and handrails when leaving the machine.



T6981AN -UN-15JUN89

TX,05,DH832 -19-16MAR92-1/1


Safety

9000
01
7

KEEP RIDERS OFF MACHINE

Only allow the operator on the machine. Keep riders off.

Riders on machine are subject to injury such as being struck by foreign objects and being thrown off the machine. Riders also obstruct the operator's view resulting in the machine being operated in an unsafe manner.



T7273AH -JUN-08JUN90


TX,05,RR,560 -19-05OCT90-1/1

MOVE AND OPERATE MACHINE SAFELY

Bystanders can be run over. Know the location of bystanders before moving, swinging, or operating the machine.

Always keep the travel alarm in working condition. It warns people when the machine starts to move.

Use a signal person when moving, swinging, or operating the machine in congested areas. Coordinate hand signals before starting the machine.




T7273AL -JUN-08JUN90

TX,05,FF1806 -19-05OCT90-1/1

WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



TS206 -JUN-23AUG88


DX,WEAR2 -19-03MAR93-1/1

Safety

9000
01
8

PROTECT AGAINST FLYING DEBRIS

Guard against injury from flying pieces of metal or debris; wear goggles or safety glasses.




T6642DK -UN-18OCT88

TX,05,FF1613 -19-14JUN90-1/1

PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.




TS207 -UN-23AUG88

DX,NOISE -19-03MAR93-1/1

ILLUMINATE WORK AREA SAFELY

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.




TS223 -UN-23AUG88

TX,05,FF1623D -19-09JUL90-1/1

SERVICE MACHINES SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.



TS228 -UN-23AUG88

DX,LOOSE -19-04JUN90-1/1

Safety

REMOVE PAINT BEFORE WELDING OR HEATING


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

9000
01
9

TS220 -UN-23AUG88

DX,PAINT -19-03MAR93-1/1

AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.



TS953 -UN-15MAY90

DX,TORCH -19-03MAR93-1/1

Safety

9000
01
10

BEWARE OF EXHAUST FUMES

Prevent asphyxiation. Engine exhaust fumes can cause sickness or death.

If you must operate in a building, be positive there is adequate ventilation. Either use an exhaust pipe extension to remove the exhaust fumes or open doors and windows to bring enough outside air into the area.




T6458AO -UN-18OCT88

02T,05,J9 -19-07JAN91-1/1

USE PROPER LIFTING EQUIPMENT

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.




TS226 -UN-23AUG88

DX,LIFT -19-04JUN90-1/1

SERVICE COOLING SYSTEM SAFELY

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.



TS281 -UN-23AUG88

DX,RCAP -19-04JUN90-1/1

*Safety*9000
01
11**DISPOSE OF WASTE PROPERLY**


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with your machine include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your authorized dealer.



TS1133 -JUN-26NOV90

TX,05,DH2502 -19-26AUG92-1/1

WORK IN A CLEAN AREA

Before starting a job, clean the work area. Remove objects that may be a safety hazard to the mechanic or bystanders.

TX,05,FF1624 -19-14JUN90-1/1

Safety

9000
01
12

USE TOOLS PROPERLY

Use tools appropriate to the work. Makeshift tools, parts, and procedures can create safety hazards.

Use power tools only to loosen threaded tools and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only recommended replacement parts. (See Parts Catalog.)



TS779 -UN-08NOV89

TX,05,FF1614 -19-14JUN90-1/1

REPLACE SAFETY SIGNS

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.



TS201 -UN-23AUG88

DX,SIGNS1 -19-04JUN90-1/1

LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.



TS231 -19-07OCT88

DX,LIVE -19-25SEP92-1/1

BATTERY TERMINALS, LIFTING EQUIPMENT, DRY CLEANING SOLVENT AND COMPRESSED AIR

WARNING: Avoid possible injury. Disconnect the negative terminal first and reconnect the negative terminal last when disconnecting/reconnecting battery terminals.

WARNING: When lifting equipment, ensure that the lifting device is capable of supporting the desired weights and the inspection date stamped on the lifting device has not expired.

WARNING: Dry cleaning solvent PD-680 Type III is toxic and flammable. Wear protective goggles and gloves and use only in a well ventilated area. Avoid contact with skin, eyes, and clothes and don't breathe vapors. Do not use near open flames or excessive heat. The flash point is 200°F (93°C). If you become dizzy while using solvent, get fresh air immediately and get medical aid. If contact with eyes is made, wash your eyes with water and get medical aid immediately.

WARNING: Compressed air used for cleaning purposes shall not exceed 30 psi. Use only with effective chip guarding and personnel protective equipment (goggles/shield/gloves, etc.).

Safety Signs

Look for these signs on machine, which points out potential hazards to the safety of you and others. Read and understand thoroughly. Heed warnings and follow instructions. If you do not understand, inform your supervisor.



(Red Background)

Indicates the presence of a hazard which **WILL** cause serious injury, death or property damage, if ignored.



(Orange Background)

Indicates the presence of a hazard which **CAN** cause serious injury, death or property damage, if ignored.



(Yellow Background)

Indicates the presence of a hazard which **WILL** or can cause injury or property damage, if ignored.



(Blue Background)

Indicates important set-up, operating or maintenance information.

DANGER

Air discharged from this machine can contain carbon monoxide or other contaminants which will cause serious injury or death. Do not breathe this air.

WARNING


Trapped air pressure. Can cause serious injury or death.
Close service valve and operate tool to vent trapped air before performing any service.

WARNING



Hot pressurized fluid.
Can cause serious burns.
Do not open radiator while hot.


WARNING



High pressure air. Can cause serious injury or death.

Relieve pressure before removing filler plugs/caps, fittings or covers.

WARNING



Disconnected Air Hoses Whip. CAN cause serious injury or death.

When using air tools attach safety device (OSHA Valve) at source of air supply for each tool.

WARNING



Combustible Gas. CAN cause serious burns, blindness or death.


Keep sparks and open flames away from batteries.

Safety

DRILLING

Before starting work, the operator will make sure there are no buried electrical, gas, water or other pipes or lines.

Always be aware of previously drilled holes, and where they are located : any open hole can cause severe injury to the operator or someone else. The loss of tools, drill rods, drill bits or any other item can occur.



When rising the guide, take care of any overhead lines.

Always maintain a minimum distance of 25 Ft. (7.6 m) distance between the machine and any overhead lines during any operation.

The operator will make sure that everybody stands clear from the machine in operation and stays at a distance of 7 meters (25 ft.).

Nevertheless, some operations may need people to enter the restricted area (checking of coupling temperature during feed thrust adjustment for instance).

On such an occasion :


- the operator must supervise, from the cabin, the safety of the service man doing the work. He must

be ready to activate the cabin emergency stop if need be.

- communication must be established in a reliable manner.

Make sure any hand signal will be perfectly understood.

- the operator must make sure the following safety decal is affixed on the drill guide to warn the service man of risks incurred.



- the service man must be informed about the use of the emergency stop mounted on the guide.

Always have the cabin door closed and the dust collector running when drilling to prevent respiratory damage.

Keep all work areas clean and orderly.

MAINTENANCE

Keep hands, arms, legs and clothing away from moving or rotating parts.

Only use genuine replacement parts.

Stopping the drill for maintenance or bit change etc...


Prior to leaving the operators compartment, the excavators hydraulic safety arm must be raised to lock in the machines safety switch. This renders all controls inoperable thus preventing any unwanted movement.

Hydraulic cylinder

The hydraulic cylinder is equipped with 2 load-sustaining valves.

The load-sustaining valves allow the disconnecting of the hydraulic hoses from the cylinder if they need to be changed. But :

Safety



Never disconnect a valve from the cylinder without supporting the controlled element (drill guide ...).

Burn prevention

At operating temperature, the hydraulic tank, circuit and components are hot and can be under pressure. Any contact can cause severe burns.

Always release the pressure and wait for cooling before intervening on the hydraulic circuit.



Fire prevention

Fuel or hydraulic oil leaked or spilled onto hot surfaces or electrical components can cause a fire.

Repair immediately any leaks.

Regularly clean the machine to remove all flammable materials such as fuel, oil and other debris.

Always use approved safety solvent when cleaning parts or the machine.

Have all loose electrical wires connected and tight before operating the machine.

Prior to any welding operation, make sure that the surfaces and their environment are free of flammable debris.

Respiratory damage prevention

Dust coming out from the dust collector fan indicates that one or several filter elements are damaged.

Change the damaged elements immediately.

Always dismantle all the filters elements to check the functioning of the automatic filter cleaning sequence.

Compressed air


Compressed air can be dangerous.

Never point an air hose at yourself or co-workers.

Be sure all hoses and fittings are tightly secured.


A loose hose not only leaks but can come completely off and while whipping under pressure, can injure the operator and others in the area.

Never disconnect a pressurized air hose.



EMERGENCY STOPS

The CPA remote control assembly incorporates an emergency stops selector with allows to connect the CPA emergency stops to the machine circuit.




– When the CPA is installed, place the selector on position A to have the CPA emergency stops active.

– Place the selector on position B to refund the normal excavator safety circuit when the CPA is not used.

Safety


The CPA safety circuit incorporates 2 emergency stops.



One mushroom type push-button is located in the cabin on the remote control panel.

Pressing on this button shuts down the engine.

Unlock the knob by pulling it up to be in position to restart the engine.



The second emergency stop is located on the guide rail, and stops the engine when pulling on the wire attached along the guide.

To unlock the safety device and be in position to restart the engine, press on the button.

WARNING: Take all necessary steps to safely start the engine after emergency stop.












Group 02
General Specifications

9000
02
1

Refer to TM 5-3805-280-10 for General Specifications.

CED.OUOE003.4 -19-16NOV99-1/1

UNIFIED INCH BOLT AND CAP SCREW TORQUE VALUES

SAE Grade and Head Markings	NO MARK	1 or 2 ^b 	5 	5.1 	5.2 	8 	8.2 
SAE Grade and Nut Markings	NO MARK	2 	5 	5 	8 	8 	

Size	Grade 1				Grade 2 ^b				Grade 5, 5.1, or 5.2				Grade 8 or 8.2			
	Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft
1/4	3.7	2.8	4.7	3.5	6	4.5	7.5	5.5	9.5	7	12	9	13.5	10	17	12.5
5/16	7.7	5.5	10	7	12	9	15	11	20	15	25	18	28	21	35	26
3/8	14	10	17	13	22	16	27	20	35	26	44	33	50	36	63	46
7/16	22	16	28	20	35	26	44	32	55	41	70	52	80	58	100	75
1/2	33	25	42	31	53	39	67	50	85	63	110	80	120	90	150	115
9/16	48	36	60	45	75	56	95	70	125	90	155	115	175	130	225	160
5/8	67	50	85	62	105	78	135	100	170	125	215	160	240	175	300	225
3/4	120	87	150	110	190	140	240	175	300	225	375	280	425	310	550	400
7/8	190	140	240	175	190	140	240	175	490	360	625	450	700	500	875	650
1	290	210	360	270	290	210	360	270	725	540	925	675	1050	750	1300	975
1-1/8	400	300	510	375	400	300	510	375	900	675	1150	850	1450	1075	1850	1350
1-1/4	570	425	725	530	570	425	725	530	1300	950	1650	1200	2050	1500	2600	1950
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2150	1550	2700	2000	3400	2550
1-1/2	1000	725	1250	925	990	725	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

^b Grade 2 applies for hex cap screws (not hex bolts) up to 152 mm (6-in.) long. Grade 1 applies for hex cap screws over 152 mm (6-in.) long, and for all other types of bolts and screws of any length.


Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

Torque Values

METRIC BOLT AND CAP SCREW TORQUE VALUES



Size	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft
M6	4.8	3.5	6	4.5	9	6.5	11	8.5	13	9.5	17	12	15	11.5	19	14.5
M8	12	8.5	15	11	22	16	28	20	32	24	40	30	37	28	47	35
M10	23	17	29	21	43	32	55	40	63	47	80	60	75	55	95	70
M12	40	29	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	47	80	60	120	88	150	110	175	130	225	165	205	150	260	190
M16	100	73	125	92	190	140	240	175	275	200	350	255	320	240	400	300
M18	135	100	175	125	260	195	330	250	375	275	475	350	440	325	560	410
M20	190	140	240	180	375	275	475	350	530	400	675	500	625	460	800	580
M22	260	190	330	250	510	375	650	475	725	540	925	675	850	625	1075	800
M24	330	250	425	310	650	475	825	600	925	675	1150	850	1075	800	1350	1000
M27	490	360	625	450	950	700	1200	875	1350	1000	1700	1250	1600	1150	2000	1500
M30	675	490	850	625	1300	950	1650	1200	1850	1350	2300	1700	2150	1600	2700	2000
M33	900	675	1150	850	1750	1300	2200	1650	2500	1850	3150	2350	2900	2150	3700	2750
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2750	4750	3500

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.

Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

TS1657 -19-02APR97

Torque Values

ADDITIONAL METRIC CAP SCREW TORQUE VALUES

⚠ CAUTION: Use only metric tools on metric hardware. Other tools may not fit properly. They may slip and cause injury.

Check tightness of cap screws periodically. Torque values listed are for general use only. Do not use these values if a different torque value or tightening procedure is listed for a specific application.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Make sure fastener threads are clean and you properly start thread engagement. This will prevent them from failing when tightening.

Tighten cap screws having lock nuts to approximately 50 percent of amount shown in chart.



T6873AA



T6873AB



T6873AC

T6873AA -JUN-18OCT88

T6873AB -JUN-18OCT88

T6873AC -JUN-18OCT88

METRIC CAP SCREW TORQUE VALUES^a

Nominal Dia	T-Bolt		H-Bolt		M-Bolt	
	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft
8	29	21	20	15	10	7
10	63	46	45	33	20	15
12	108	80	88	65	34	25
14	176	130	137	101	54	40
16	265	195	206	152	78	58
18	392	289	294	217	118	87
20	539	398	392	289	167	125
22	735	542	539	398	216	159
24	931	687	686	506	274	202
27	1372	1012	1029	759	392	289
30	1911	1410	1421	1049	539	398
33	2548	1890	1911	1410	735	542
36	3136	2314	2401	1772	931	687


^aTorque tolerance is ±10%.

Torque Values

9000
03
4

CHECK OIL LINES AND FITTINGS

CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.



X9811 -UN-23AUG88

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.



T85401 -UN-24JAN89

Check all oil lines, hoses and fittings regularly for leaks or damage. Make sure all clamps are in position and tight. Make sure hoses are not twisted or touching machine parts which are moving.

Tubing with dents may cause the oil to overheat. If you find tubing with dents, install new tubing immediately.


IMPORTANT: Tighten fittings as specified in torque chart.

When you tighten connections, use two wrenches to prevent bending or breaking tubing and fittings.

T82,FLMA,AI -19-14MAR90-1/1

*Torque Values***SERVICE RECOMMENDATIONS FOR O-RING
BOSS FITTINGS****STRAIGHT FITTING**

1. Inspect O-ring boss seat for dirt or defects.
2. Lubricate O-ring with petroleum jelly. Place electrical tape over threads to protect O-ring. Slide O-ring over tape and into O-ring groove of fitting. Remove tape.
3. Tighten fitting to torque value shown on chart.



T6243AE -JN-18OCT88

9000
03
5

Continued on next page

04T,90,K66 -19-19MAR96-1/2

Torque Values


9000
03
6

ANGLE FITTING

1. Back-off lock nut (A) and back-up washer (B) completely to head-end (C) of fitting.
2. Turn fitting into threaded boss until back-up washer contacts face of boss.
3. Turn fitting head-end counterclockwise to proper index (maximum of one turn).

NOTE: Do not allow hoses to twist when tightening fittings.

4. Hold fitting head-end with a wrench and tighten locknut and back-up washer to proper torque value.



A—Lock Nut
B—Back-Up Washer
C—Fitting Head End

T6520/AB -UN-18OCT88

STRAIGHT FITTING OR SPECIAL NUT TORQUE CHART

Thread Size	N•m	lb-ft
3/8-24 UNF	8	6
7/16-20 UNF	12	9
1/2-20 UNF	16	12
9/16-18 UNF	24	18
3/4-16 UNF	46	34
7/8-14 UNF	62	46
1-1/16-12 UN	102	75
1-3/16-12 UN	122	90
1-5/16-12 UN	142	105
1-5/8-12 UN	190	140
1-7/8-12 UN	217	160

NOTE: Torque tolerance is ± 10%.


04T,90,K66 -19-19MAR96-2/2

Torque Values

9000
03
7

SERVICE RECOMMENDATIONS FOR FLAT FACE O-RING SEAL FITTINGS

1. Inspect the fitting sealing surfaces. They must be free of dirt or defects.
2. Inspect the O-ring. It must be free of damage or defects.
3. Lubricate O-rings and install into groove using petroleum jelly to hold in place.
4. Push O-ring into the groove with plenty of petroleum jelly so O-ring is not displaced during assembly.
5. Index angle fittings and tighten by hand pressing joint together to insure O-ring remains in place.
6. Tighten fitting or nut to torque value shown on the chart per dash size stamped on the fitting. Do not allow hoses to twist when tightening fittings.



T6243AD -JN-18OCT88

FLAT FACE O-RING SEAL FITTING TORQUE

Nominal Tube O.D.		Dash Size	Thread Size in.	Swivel Nut		Bulkhead Nut	
mm	in.			N•m	lb-ft	N•m	lb-ft
6.35	0.250	-4	9/16-18	16	12	5.0	3.5
9.52	0.375	-6	11/16-16	24	18	9.0	6.5
12.70	0.500	-8	13/16-16	50	37	17.0	12.5
15.88	0.625	-10	1-14	69	51	17.0	12.5
19.05	0.750	-12	1 3/16-12	102	75	17.0	12.5
22.22	0.875	-14	1 3/16-12	102	75	17.0	12.5
25.40	1.000	-16	1 7/16-12	142	105	17.0	12.5
31.75	1.250	-20	1 11/16-12	190	140	17.0	12.5
38.10	1.500	-24	2-12	217	160	17.0	12.5

NOTE: Torque tolerance is +15 -20%.

04T,90,K67 -19-01AUG94-1/1

Torque Values

9000
03
8

**SERVICE RECOMMENDATIONS FOR 37°
FLARE AND 30° CONE SEAT CONNECTORS**

1. Inspect flare and flare seat. They must be free of dirt or obvious defects.
2. Defects in tube flare cannot be repaired. Overtightening a defective flared fitting will not stop leaks.
3. Align tube with fitting before attempting to start nut.
4. Lubricate male threads with hydraulic fluid or petroleum jelly.
5. Index angle fittings and tighten by hand.
6. Tighten fitting or nut to torque value shown on torque chart. Do not allow hoses to twist when tightening fittings.



T6234AC -UN-18OCT88

STRAIGHT FITTING OR SPECIAL NUT TORQUE CHART

Thread Size	N•m	lb-ft
3/8 - 24 UNF	8	6
7/16 - 20 UNF	12	9
1/2 - 20 UNF	16	12
9/16 - 18 UNF	24	18
3/4 - 16 UNF	46	34
7/8 - 14 UNF	62	46
1-1/16 - 12 UN	102	75
1-3/16 - 12 UN	122	90
1-5/16 - 12 UN	142	105
1-5/8 - 12	190	140
1-7/8 - 12 UN	217	160


NOTE: Torque tolerance is $\pm 10\%$.

T82,BHMA,EL -19-19MAR96-1/1

Torque Values


SERVICE RECOMMENDATIONS FOR FLARED CONNECTIONS—STRAIGHT OR TAPERED THREADS

1. Inspect flare and flare seat. They must be free of dirt or obvious defects.
2. Defects in the tube flare cannot be repaired. Overtightening a defective flared fitting will not stop leaks.
3. Align the tube with the fitting before attempting to start the nut.
4. Lubricate the male threads with hydraulic fluid or petroleum jelly.
5. Index angle fittings and tighten by hand.
6. Tighten fitting or nut to torque value shown on the chart. Do not allow hoses to twist when tightening fittings.



T6873AE

Straight Thread



T6873AD

Tapered Thread

TORQUE CHART^a

Thread Size	Straight Thread ^b		Tapered Thread	
	N•m	lb-ft	N•m	lb-ft
1/8	15	11		
1/4	20	15	45	33
3/8	29	21	69	51
1/2	49	36	93	69
3/4	69	51	176	130
1	157	116	343	253
1-1/2	196	145	539	398
2	255	188	588	434

^aTorque tolerance is ±10%.

^bWith seat face.


NOTE: If female thread is cast iron (control valves, brake valves motors, etc.), torque must be reduced approximately 10%.

T6873AE -UN-18OCT88

T6873AD -UN-18OCT88

9000
03
10

SERVICE RECOMMENDATIONS FOR INCH SERIES FOUR BOLT FLANGE FITTINGS



A—Sealing Surface

B—Split Flange

C—Pinched O-Ring

D—Single Piece Flange

1. Clean sealing surfaces (A). Inspect. Scratches cause leaks. Roughness causes seal wear. Out-of-flat causes seal extrusion. If defects cannot be polished out, replace component.
2. Install O-ring (and backup washer if required) into groove using petroleum jelly to hold it in place.
3. Split flange: Loosely assemble split flange (B) halves. Make sure split is centrally located and perpendicular to port. Hand tighten cap screws to hold parts in place. Do not pinch O-ring (C).
4. Single piece flange (D): Place hydraulic line in center of flange and install cap screws. Flange

must be centrally located on port. Hand tighten cap screws to hold flange in place. Do not pinch O-ring.

5. Tighten one cap screw, then tighten the diagonally opposite cap screw. Tighten two remaining cap screws. Tighten all cap screws as specified in the chart below.

DO NOT use air wrenches. DO NOT tighten one cap screw fully before tightening the others. DO NOT over tighten.

T6890BB -UN-01MAR90

Continued on next page

04T,90,K174 -19-01AUG94-1/2

Torque Values

9000
03
11

TORQUE CHART^a


Nominal Flange Size	Cap Screw Size	N•m		lb-ft	
		Min	Max	Min	Max
1/2	5/16-18 UNC	20	31	15	23
3/4	3/8-16 UNC	28	54	21	40
1	3/8-16 UNC	37	54	27	40
1-1/4	7/16-14 UNC	47	85	35	63
1-1/2	1/2-13 UNC	62	131	46	97
2	1/2-13 UNC	73	131	54	97
2-1/2	1/2-13 UNC	107	131	79	97
3	5/8-11 UNC	158	264	117	195
3-1/2	5/8-11 UNC	158	264	117	195
4	5/8-11 UNC	158	264	117	195
5	5/8-11 UNC	158	264	117	195

^aTolerance \pm 10%. The torques given are enough for the given size connection with the recommended working pressure. Torques can be increased to the maximum shown for each cap screw size if desired. Increasing cap screw torque beyond this maximum will result in flange and cap screw bending and connection failures.

04T,90,K174 -19-01AUG94-2/2

Torque Values

SERVICE RECOMMENDATIONS FOR METRIC SERIES FOUR BOLT FLANGE FITTING



A—Sealing Surface

B—Split Flange

C—Pinched O-Ring

D—Single Piece Flange

1. Clean sealing surfaces (A). Inspect. Scratches cause leaks. Roughness causes seal wear. Out-of-flat causes seal extrusion. If defects cannot be polished out, replace component.
2. Install the correct O-ring (and back-up washer if required) into groove using petroleum jelly to hold it in place.
3. Split flange: Loosely assemble split flange (B) halves. Make sure split is centrally located and perpendicular to the port. Hand tighten cap screws to hold parts in place. Do not pinch O-ring (C).
4. Single piece flange (D): Place hydraulic line in center of flange and install four cap screws. Flange must be centrally located on port. Hand tighten cap screws to hold flange in place. Do not pinch O-ring.
5. After components are properly positioned and cap screws are hand tightened, tighten one cap screw, then tighten the diagonally opposite cap screw. Tighten two remaining cap screws. Tighten all cap screws as specified in the chart below.

DO NOT use air wrenches. DO NOT tighten one cap screw fully before tightening the others. DO NOT over tighten.

TORQUE CHART ^a		
Thread ^b	N•m	lb-ft
M6	12	9
M8	30	22
M10	57	42
M12	95	70
M14	157	116
M16	217	160
M18	334	246
M20	421	318

^aTolerance $\pm 10\%$. The torques given are enough for the given size connection with the recommended working pressure. Increasing cap screw torque beyond these amounts will result in flange and cap screw bending and connection failures.

^bMetric standard thread.

T6890BB -UN-01MAR90

DIESEL FUEL

Consult your local fuel distributor for properties of the diesel fuel available in your area.

In general, diesel fuels are blended to satisfy the low temperature requirements of the geographical area in which they are marketed.

Diesel fuels specified to A-A-52557, EN 590 or ASTM D975 are recommended.

In all cases, the fuel shall meet the following properties:

- **Cetane Number 40** minimum. Cetane number greater than 50 is preferred, especially for temperatures below -20°C (-4°F) or elevations above 1500 m (5000 ft).
- **Cold Filter Plugging Point (CFPP)** below the expected low temperature OR **Cloud Point** at least 5°C (9°F) below the expected low temperature.

- **Fuel Lubricity** should pass a minimum of 3100 gram load level as measured by the SL BOCLE scuffing test.
- **Sulfur content:**
 - Sulfur content should not exceed 0.5% Sulfur content less than 0.05% is preferred.
 - If diesel fuel with sulfur content greater than 0.5% sulfur content is used, reduce the service interval for engine oil and filter by 50%.
 - **DO NOT** use diesel fuel with sulfur content greater than 1.0%.

Bio-diesel fuels with properties and meeting DIN 51606 or equivalent specifications may be used.

Aviation fuel Grade JP-8 may be used.

DO NOT mix used engine oil or any other type of lubricant with diesel fuel.

CED,OUOE020,2 -19-11FEB99-1/1

LUBRICITY OF DIESEL FUELS

Diesel fuel must have adequate lubricity to ensure proper operation and durability of fuel injection system components.

Diesel fuels for highway use in the United States and Canada now require sulfur content less than 0.05%. Diesel fuel in the European Union will require sulfur content less than 0.05% by 1 October 1996.

Experience shows that some low sulfur diesel fuels may have inadequate lubricity and their use may reduce performance in fuel injection systems due to inadequate lubrication of injection pump components. The lower concentration of aromatic compounds in these fuels also adversely affects injection pump seals and may result in leaks.

Use of low lubricity diesel fuels may also cause accelerated wear, injection nozzle erosion or corrosion,

engine speed instability, hard starting, low power, and engine smoke.

Fuel lubricity should pass a minimum of 3100 gram load level as measured by the SL BOCLE scuffing test.

A-A-52557, ASTM D975 and EN 590 specifications do not require fuels to pass a fuel lubricity test.

If fuel of low or unknown lubricity is used, add John Deere PREMIUM DIESEL FUEL CONDITIONER or Inhibitor, Corrosion/Lubricity Improver, Fuel Soluble (MIL-PRF-25017) at the recommended concentration. John Deere PREMIUM DIESEL FUEL CONDITIONER is available in winter and summer formulas. Consult your John Deere engine distributor or servicing dealer for more information.

TX,45,JC1771 -19-08JAN97-1/1

*Fuels and Lubricants*9000
04
2**LOW SULFUR DIESEL FUEL CONDITIONER**

When possible, use existing fuel formulations for engines used off-highway. This fuel will not require any additives to provide good performance and engine reliability. However, many local fuel distributors will not carry both low and regular sulfur diesel fuels.

If only low sulfur fuel is available, Inhibitor, Corrosion/Lubricity Improver, Fuel Soluble should be added at the recommended concentration (MIL-PRF-25017). Nearly all other diesel fuel conditioners only improve cold weather flow and stabilize long-term fuel storage. They do not contain the lubrication additives needed by rotary fuel injection pumps.

TX,45,DH5857 -19-15AUG97-1/1

DIESEL FUEL STORAGE

Proper fuel storage is critically important. Use clean storage and transfer tanks. Periodically drain water and sediment from bottom of tank. Store fuel in a convenient place away from buildings.

IMPORTANT: DO NOT store diesel fuel in galvanized containers. Diesel fuel stored in galvanized containers reacts with zinc coating on container to form zinc flakes. If fuel contains water, a zinc gel will also form. The gel and flakes will quickly plug fuel filters, damage injection nozzles and injection pump.

DO NOT use brass-coated containers for fuel storage. Brass is an alloy of copper and zinc.

Store diesel fuel in plastic, aluminum, and steel containers specially coated for diesel fuel storage.

Avoid storing fuel over long periods of time. If fuel is stored for more than a month prior to use, or there is a slow turnover in fuel tank or supply tank, add a fuel conditioner such as John Deere PREMIUM DIESEL FUEL CONDITIONER or fuel conditioner meeting MIL-S-53021 to stabilize the fuel and prevent microbial growth in the fuel. John Deere PREMIUM DIESEL FUEL CONDITIONER is available in winter and summer formulas. Fuel conditioner also reduces fuel gelling and controls wax separation during cold weather.

Consult your John Deere engine distributor or servicing dealer for recommendations and local availability. Always follow manufacturer's directions on label.

TX,45,JC1772 -19-08JAN97-1/1

FUEL TANK



CAUTION: Handle fuel carefully. If the engine is hot or running, do not fill the fuel tank. Do not smoke while you fill fuel tank or work on fuel system.

To avoid condensation, fill the fuel tank at the end of each day's operation. Capacity is 560 L (148 gal).

Fuel Tank—Specification

Capacity..... 560 L (148 gal)

CED,TX14740,6018 -19-28JAN98-1/1

DO NOT USE GALVANIZED CONTAINERS

IMPORTANT: Diesel fuel stored in galvanized containers reacts with zinc coating on the container to form zinc flakes. If fuel contains water, a zinc gel will also form. The gel and flakes will quickly plug fuel filters and damage fuel injectors and fuel pumps.

DO NOT USE a galvanized container to store diesel fuel.

Store fuel in:


- plastic containers.
- aluminum containers.
- specially coated steel containers made for diesel fuel.

DO NOT USE brass-coated containers: brass is an alloy of copper and zinc.

DX,FLBT,C -19-04JUN90-1/1

9000
04
4

DIESEL ENGINE AND PUMP GEARBOX OILS



T125427

T125427 -19-28OCT99

Use oil viscosity based on the expected air temperature range during the period between oil changes.

- MIL-PRF-46167C
- API CG-4
- API CF-4


Other oils may be used if they meet one or more of the following:

- MIL-PRF-2104G
- MIL-L-46167B

Multi-viscosity diesel engine oils are preferred.

If diesel fuel with sulfur content greater than 0.5% is used, reduce the service interval by 50%.

HYDRAULIC OIL



T125428

T125428 -19-12NOV99


Depending upon the expected air temperature range between oil changes, use oil viscosity shown on the temperature chart above.

Use oils meeting one or more of the following:

- MIL-PRF-2104G¹
- MIL-L-46167B
- MIL-PRF-46167C
- API CG-4¹
- API CF-4¹

¹Must contain a minimum zinc additive of 0.09 percent.

SWING GEARBOX AND PROPEL GEARBOX OILS



T125429

Depending upon the expected air temperature range between oil changes, use oil viscosity shown on the temperature chart above.

- Oils meeting MIL-PRF-2105. MIL-PRF-2105E is updated.
- Oils meeting API Service GL-5 (MIL-L-2105E).

The following oils are recommended:

CED,OUOE020,5 -19-12FEB99-1/1

T125429 -19-12NOV99

TRACK ROLLER, FRONT IDLER, AND CARRIER ROLLER OIL

Use oil viscosity based on the expected air temperature range during the period between oil changes.

The following oils are recommended:

- MIL-PRF-2105E (80W90).
- API Service Classification GL-5 gear oil (SAE 80W90).
- Arctic oil such as MIL-PRF-2105E (75W) should be used at temperatures below -30°C (-11°F).

CED,OUOE020,6 -19-12FEB99-1/1

TRACK ADJUSTER, WORKING TOOL PIVOT, SWING BEARING, AND SWING BEARING GEAR GREASE

AIR TEMPERATURE RANGE	
Fahrenheit (F)	-67 -40 -22 -4 14 32 50 68 86 104 122
Celsius (C)	-55 -40 -30 -20 -10 0 10 20 30 40 50

T120320 -19-25MAR99

T120320

Use grease based on NLGI consistency numbers and the expected air temperature range during the service interval.

Lithium complex grease containing high temperature, extreme pressure properties with 3-5 percent molybdenum disulfide is preferred, although those without the molybdenum disulfide are acceptable.

Use greases meeting MIL-PRF-10924G.

CED.OUOE020.7 -19-12FEB99-1/1

OIL FILTERS

Filtration of oils is critical to proper operation and lubrication. Always change filters regularly as specified in this manual.

Use filters meeting John Deere performance specifications.

DX,FILT -19-18MAR96-1/1

Lubricant specifications

ROCK DRILL LUBRICANTS SPECIFICATIONS

We recommend the use of the **MOBIL** lubricants. These are selected to get the best performances out of our equipments.

If the **MOBIL** products are not available, our warranty will apply only if high quality lubricants are used according to the following specifications and under the responsibility of your supplier.

HYDRAULIC CIRCUIT

Oil ISO VG 32 (*ISO VG 46 when $10^{\circ}\text{C} < t < 45^{\circ}\text{C}$*) with stabilized anti-wear additive

Specifications :

Viscosity at 40°C: 30 to 33 cSt (*46 cSt*)

Viscosity index VI: ≥ 150 (*140*)

Pour point: $< -40^{\circ}\text{C}$

De aïring: ≤ 5 mn

Performances :

Homologation: DENISON HFO

Anti wear: FZG ≥ 12

VICKERS 35 VQ 25 : total wear < 50 mg

ASTM D 130 : cotation 1 a

Anti corrosion: CINCINNATI P 70 – pass

Filterability: DENISON TP 02-100 :
t < 200 seconds with water 2%

Oxydation stability NFT 60150 t > 2200 h
for 1 a ≤ 2 ASTM D 943

Performances :

specifications: MIL-PRF-2105E

PNEUMATIC CIRCUIT

Anti wear oils for pneumatic equipment

ISO VG 46 for : t $\leq 0^{\circ}\text{C}$

ISO VG 100 for : t $> 0^{\circ}\text{C}$

Performances :

film resistance

reinforced anti-wear

anti-corrosion

anti-freeze (for : t $\leq 0^{\circ}\text{C}$)

Specifications :

Pour point $< -24^{\circ}\text{C}$

Flash point 218°C

Viscosity at 40° C: 150 cSt

Viscosity index Vi: 140

GEAR BOX

High pressure oil SAE 80 W 90 for transmissions.

Performances :

specifications: MIL-PRF-2105E

GREASE

MIL-PRF-10924G

SECTOR	0°C to -45°C PRODUCT	+30°C to -20°C PRODUCT	+45°C to +10°C PRODUCT
Hydraulic	MOBIL SHC 524	MOBIL DTE 13 M	MOBIL DTE 15 M
Pneumatic	MOBIL SHC 524	MOBIL ALMO 527 (t > 0°C) ALMO 325 (t < 0°C)	ALMO 527
Grease	MOBILTEMP SHC 100 SPECIAL	MOBILGREASE SPECIAL	MOBILGREASE SPECIAL
GCL/GCX reducer	MOBIL SHC 630	MOBIL SHC 630	MOBILGEAR 629 MOBIL SHC 630

*Fuels and Lubricants*9000
04
8**LUBRICANT STORAGE**

Your equipment can operate at top efficiency only when clean lubricants are used.

Use clean containers to handle all lubricants.

Whenever possible, store lubricants and containers in an area protected from dust, moisture, and other contamination. Store containers on their side to avoid water and dirt accumulation.

Make certain that all containers are properly marked to identify their contents.

Properly dispose of all old containers and any residual lubricant they may contain.

DX,LUBST -19-18MAR96-1/1

ALTERNATIVE AND SYNTHETIC LUBRICANTS

Conditions in certain geographical areas may require lubricant recommendations different from those printed in this manual. Some John Deere brand coolants and lubricants may not be available in your location. Consult your John Deere dealer to obtain information and recommendations.

Synthetic lubricants may be used if they meet the performance requirements as shown in this manual.

The temperature limits and service intervals shown in this manual apply to both conventional and synthetic oils.

Re-refined base stock products may be used if the finished lubricant meets the performance requirements.

DX,ALTER -19-18MAR96-1/1

MIXING OF LUBRICANTS

In general, avoid mixing different brands or types of oil. Oil manufacturers blend additives in their oils to meet certain specifications and performance requirements. Mixing different oils can interfere with the proper functioning of these additives and degrade lubricant performance.

Consult your John Deere dealer to obtain specific information and recommendations.

DX,LUBMIX -19-18MAR96-1/1

AIR COMPRESSOR - LUBRICATION

GENERAL INFORMATION

Lubrication is an essential part of preventive maintenance, affecting to a great extent the useful life of the unit. Different lubricants are needed and some components in the unit require more frequent lubrication than others. Therefore, it is important that the instructions regarding types of lubricants and the frequency of their application be explicitly followed. Periodic lubrication of the moving parts reduces to a minimum the possibility of mechanical failures.

The Preventive Maintenance Schedule shows those items requiring regular service and the interval in which they should be performed. A regular service program should be developed to include all items and fluids. These intervals are based on average operating conditions. In the event of extremely severe (hot, cold, dusty or wet) operating conditions, more frequent lubrication than specified may be necessary. Details concerning lubrication of the running gear are in Maintenance Section.

All filters and filter elements for air and compressor lubricant must be obtained through Ingersoll-Rand to assure the proper size and filtration for the compressor.

COMPRESSOR OIL CHANGE

These units are normally furnished with an initial supply of oil sufficient to allow operation of the unit for approximately 6 months or 1000 hours, whichever comes first. If a unit has been completely drained of all oil, it must be refilled with new oil before it is placed in operation. Refer to specifications in Lubrication Table.

NOTICE

Some oil types are incompatible when mixed and result in the formation of varnishes, shellacs, or lacquers which may be insoluble. Such deposits can cause serious troubles including clogging of the filters. Where possible, do NOT mix oils of different types and avoid mixing different brands. A type or brand change is best made at the time of a complete oil drain and refill.

If the unit has been operated for the time/ hours mentioned above, it should be completely drained of oil. If the unit has been operated under adverse conditions, or after long periods in storage, an earlier change period may be necessary as oil deteriorates with time as well as by operating conditions.

WARNING

High pressure air can cause severe injury or death from hot oil and flying parts. Always relieve pressure before removing caps, plugs, covers or other parts from pressurized air system. Ensure the following conditions are met:

- Discharge air pressure gauge reads zero (0).
- No air discharging from an "open" manual blowdown valve.

An oil change is good insurance against the accumulation of dirt, sludge, or oxidized oil products.

Completely drain the receiver- separator, piping, and oil cooler. If the oil is drained immediately after the unit has been run for some time, most of the sediment will be in suspension and, therefore, will drain more readily. However, the fluid will be hot and care must be taken to avoid contact with the skin or eyes.

After the unit has been completely drained of all old oil, close the drain valve. Add oil in the specified quantity at the filler plug. Tighten the filler plug and run the machine to circulate the oil. Check the oil level WHEN RUNNING AT FULL LOAD. If not near the middle of the sight tube, stop the unit and make corrections. DO NOT OVERFILL.

NOTICE

Ingersoll-Rand provides compressor oil specifically formulated for Portable Compressors and requires the use of these fluids in order to obtain extended limited airtend warranty. Refer to Section 2 and 6, Warranty and Compressor Oil respectively.

AIR COMPRESSOR LUBRICANTS

FLUIDS AND LUBRICANTS TABLE

ITEM	FLUID	AMBIENT TEMP.	SPECIFICATION
Compressor Models: VHP - (200 + psi) HP - (150 psi) XP - (125 psi) P - (100 psi)	Airend Lubricant	-10°F to 125°F (-23°C to 52°C)	★ IR Pro-Tec™ MIL-PRF-2104G • A-A-52039 SAE 10W
		-40°F to 125°F (-40°C to 52°C)	★ IR Perform ance 500
		-40°F to 65°F (-40°C to 18°C)	• MIL-PRF-46167
NXP (Oil Free)	Refer to Opera tor's Manual		
★ Recommended Ingersoll-Rand Fluids - Use of these fluids with o rigin al I-R filter s can extend airend warranty. Refer to opera tor's manual warr anty section for details or contact your I-R r epresentative.			
Recommended Fluid	1 Gal. (3.8 lit re)	5 Gal. (19.0 litre)	55 Gal. (208.2 lit re)
IR Pro-TecR	36899698	36899706	36899714
IR Perform ance 500	35382928	35382936	35382944

DexronR - Reg. T.M. of General Motors Corp.

Pro-Tec™ - T.M. of Ingersoll-Rand

For Parts, Service & nearest Distributor call 1-800-633-5206

CHAPTER 2

SECTION 9005

OPERATIONAL CHECKOUT PROCEDURE

BLANK

Group 10 Operational Checkout Procedure

9005
10
1

OPERATIONAL CHECKOUT

Use this procedure to check all systems and functions on the machine. It is designed so you can make a quick check of machine operation while doing a walk around inspection and performing specific checks from the operator's seat.

Should you experience a problem with your machine, you will find helpful diagnostic information in this checkout that will pinpoint the cause. This information may allow you to perform a simple adjustment yourself which will reduce the down time of your machine. Use the table of contents to help find adjustment procedures.

The information you provide after completing the operational checkout will allow you or your authorized dealer to pinpoint a specific test or repair needed to restore the machine to design specifications.

A location will be required which is level and has adequate space to complete the checks. No tools or equipment are needed to perform the checkout.

Complete the necessary visual checks (oil levels, oil condition, external leaks, loose hardware, linkage, wiring, etc.) prior to doing the checkout. The machine must be at operating temperature for many of the checks.

Start at the top of the left column and read completely down column before performing check. Follow this sequence from left to right. In the far right column, if no problem is found, you will be instructed to go to next check. If a problem is indicated, you will be referred to either a section in this manual or to your authorized dealer for repair.

TX,9005,GG2708 -19-11AUG98-1/1


Operational Checkout Procedure

① OPERATOR STATION CHECKS—KEY SWITCH ON, ENGINE OFF

9005
10
2

---1/1

GAUGES, MONITOR,
AND BATTERY
DISCONNECT RELAY
CHECKS



T125196

T125196 -UN-29OCT99

A—Engine Temperature Gauge

B—Fuel Gauge

NOTE: Monitor buzzer is not checked during this procedure.

If engine coolant temperature is below 30°C (86°F), engine temperature gauge needle may not move to the right. Run engine a few minutes to warm coolant before check.

Engine OFF.

Key switch ON.

Does battery relay click?

Do engine temperature gauge (A) and fuel gauge (B) needles move to the right?

Do all 10 monitor lights come on and after 2—3 seconds only the alternator indicator and engine oil pressure indicator remain on?

YES: Go to next check.


NO: Check monitor fuse.

NO: Check and replace bulb if any bulb fails to come on. Go to Group 9015-15.

---1/1

Operational Checkout Procedure

**FLUID LEVEL
(COOLANT, HYDRAULIC
OIL, AND ENGINE OIL)
INDICATOR CIRCUIT
CHECKS**



T102097 -UN-26JUL96

- A—Level Check Switch
- B—Engine Oil Level Indicator
- C—Engine Coolant Level Indicator
- D—Hydraulic Oil level Indicator

Engine OFF.

Key switch ON.

Push and hold level check switch (A).

Are the hydraulic oil level (D), coolant level (C), and engine oil level (B) indicator lights ON?

YES: Go to next check.

NO: Check monitor fuse. If OK, check fluid levels in radiator, recovery tank, hydraulic oil tank, or engine. If OK, check fluid level switch or wiring. Go to Group 9015-15.


9005
10
3

Operational Checkout Procedure

ENGINE OIL LEVEL AND
CONDITION CHECK



T6488GH -19-23FEB89



T103525 -UN-10SEP96

A—Pre-Operation Level Check Switch

B—Engine Oil Level Indicator

Engine OFF.

Remove dipstick and check oil level and condition.

Is oil above "full" mark or below "add" mark on dipstick?

Does the oil look milky or grainy?

If oil level is high, check for fuel or anti-freeze. Drain a small amount of engine oil into a clear container. Watch oil in container to see if anti-freeze or water accumulates at the bottom. If oil is milky, moisture or anti-freeze may be present.

If oil is grainy, carbon may be present. Carbon in oil may result when engine runs at slow idle too long.

If oil level is low, check for oil leaks or oil seal problems in engine.

Adjust oil level to between "add" and "full" marks on dipstick.

Key switch ON.

Push pre-operation level check switch (A).

Is green light for engine oil level indicator (B) ON?

YES: Add oil if low.


Change oil and filter if too high, milky or grainy. Go to Group 9000-04. Check oil level after a few hours operation to determine if a problem exists. Go to Diagnose Engine Malfunctions Group 9010-15.

NO: If engine oil level indicator does not come ON, go to Monitor Diagnostic Information in Group 9015-15.

If oil level is OK, go to next check.

Operational Checkout Procedure

PROPEL LEVER AND PEDAL CUSHION CYLINDER CHECKS



T7531AO -UN-07JUN91

- A—Propel Lever and Pedal Forward
- B—Propel Lever and Pedal Rearward

Engine OFF.

Push each propel lever and pedal forward (A), then release.

Pull each propel lever and pedal rearward (B), then release.

Does each lever and pedal have equal effort to operate forward and reverse?

Does each lever and pedal return to neutral at the same time when released?

YES: Go to next check.

NO: Repair or repair cushion cylinders. Go to Group 3360.


--1/1

9005
10
5

OPERATOR STATION CHECKS—ENGINE ON

--1/1

MONITOR CIRCUIT, GAUGE CHECKS



T102096 -UN-26JUL96

- A—Coolant Temperature Gauge
- B—Fuel Gauge

Start engine.

Are all monitor indicator lights OFF after engine starts?

Is coolant temperature gauge needle (A) in normal operating zone after a few minutes?

Does fuel gauge (B) indicate fuel level?

Stop engine.

YES: Go to next check.

NO: Check engine lubrication system if engine oil pressure indicator is on after engine starts. Go to Group 9010-15 or Engine Repair chapter.

Check alternator belt if battery light is on after engine starts. Go to Group 0510. If OK, check fuses, alternator, and gauges. Go to Group 9015-15.


Check switches, sensors, and gauges. Go to Group 9015-15.

Check fluid levels.

--1/1

Operational Checkout Procedure

POWER MODE INDICATORS CIRCUIT CHECKS



T102098 -UN-26JUL96

- A—HP (High Power) Mode Switch
- B—E (Economy) Mode Switch

Start engine.

Auto-idle switch OFF.

Pilot shutoff lever in LOCKED position.

Push HP (high power) mode (A) and E (economy) mode (B) select switches one at a time.


Do corresponding indicator lights come on as each switch is pushed?

YES: Go to next check.

NO: Check controller fuse. Go to Group 9015-15.

-- -1/1

WORK MODE CIRCUIT CHECKS



T102099 -UN-26JUL96

- A—Work Mode Switch
- B—Dig Mode Indicator
- C—Grading Mode Indicator
- D—Precision Mode Indicator
- E—Attachment Mode Indicator

Start engine.

Auto-idle switch OFF.

Pilot shutoff lever in LOCKED position.

Push work mode select switch (A) to select desired work mode.


Do corresponding indicator lights come on as switch is pushed?

YES: Go to next check.

NO: Check fuse. If OK, check monitor and wiring harness. Go to Group 9015-15.



-- -1/1

Operational Checkout Procedure

<p>TRAVEL ALARM STOP CIRCUIT CHECK</p>	 <p>T102919 -UN-08AUG96</p>	<p>A—Travel Alarm Cancel Switch</p> <p>CAUTION: Machine will move during this check. Make sure area is clear, and large enough to operate the machine.</p> <p><i>NOTE:</i> Travel alarm must operate for this check.</p> <p>Push propel pedals or levers and allow travel alarm to operate for a minimum of 12 seconds.</p> <p>While continuing travel, push travel alarm cancel switch (A).</p> <p>Does travel alarm stop sounding?</p>	<p>YES: Go to next check.</p> <p>NO: Check switch and wiring harness. Go to Group 9015-15.</p>
---	--	--	--

9005
10
7


--1/1

<p>PILOT SHUT-OFF VALVE CHECKS</p>	 <p>T7351CC -UN-22AUG90</p>	<p>CAUTION: Machine may move during this check. Make sure area is clear and large enough to operate all machine functions.</p> <p>Run engine at slow idle.</p> <p>Pilot shut-off lever in LOCKED (rearward) position.</p> <p>Actuate controls for dig and propel functions.</p> <p>Do any dig or propel functions operate?</p>	<p>YES: Check adjustment. Go to Group 9025-20. Repair or replace pilot shut-off valve. Go to Group 3360.</p> <p>NO: Continue check.</p>
	 <p>T7351CB -UN-22AUG90</p>	<p>Push pilot shut-off lever to UNLOCKED position (forward).</p> <p>Actuate controls for dig and propel functions.</p> <p>Do all functions operate?</p>	<p>YES: Go to next check.</p> <p>NO: Check adjustment. Go to Group 9025-20. Repair or replace pilot shut-off valve. Go to Group 3360.</p>

--1/1

Operational Checkout Procedure

TRAVEL ALARM CHECK



T7850AF -UN-22OCT92

- A—Pilot Shut-Off Lever
- B—Propel Pedals or Levers Forward
- C—Propel Pedals or Levers Rearward



CAUTION: Machine will move during this check. Make sure area is clear and large enough to operate the machine.

Engine running.

Pilot shut-off lever (A) in UNLOCKED position (forward).

Push propel pedals or levers forward (B) for forward travel.

Does travel alarm sound?

Push propel pedals or pull levers rearward (C) for reverse travel.


Does travel alarm sound?

YES: Go to next check.

NO: Check travel (motion) alarm fuse. Check motion alarm and wiring harness. Go to Group 9015-15.

--1/1

ENGINE RPM DIAL CHECKS



T102100 -UN-26JUL96

- A—Engine RPM Dial

Start engine.

Auto-idle switch OFF.

Pilot shutoff lever in LOCKED position.

Turn engine rpm dial (A) clockwise.

Does engine speed increase?

Turn engine rpm dial counterclockwise.

Does engine speed decrease?


YES: Go to next check.

NO: Check dial and wiring harness. Go to Group 9015-15. If OK, check for control signal to EC motor. Go to harness test in Group 9025-25. Check that cable from EC motor to injection pump lever moves freely. Go to Group 0515.

--1/1

Operational Checkout Procedure

AUTO-IDLE CIRCUIT CHECK



T102101 -UN-26JUL96

A—Auto-Idle Switch
B—Auto-Idle Indicator

- Engine at fast idle.
- HP and E mode switches OFF.
- Auto-idle switch OFF.
- Pilot shutoff lever in UNLOCKED position.
- Push auto-idle switch (A) to ON.
- Does auto-idle indicator (B) come on?
- Does engine speed decrease after 4—6 seconds?
- Slowly actuate any dig function control lever.
- Does engine speed return to fast idle?


YES: Go to next check.

NO: Check fuse. Check switches and wiring harness. Go to Group 9015-15.


9005
10
9

--1/1

E (ECONOMY) MODE CHECK



T103545 -UN-09SEP96



T103546 -UN-09SEP96

A—E (Economy) Mode Switch
B—E (Economy) Mode Indicator

- Start the engine.
- Auto-idle switch OFF.
- Turn engine rpm dial clockwise to fast idle.
- Push E (economy) mode switch (A) on.
- Did you hear a decrease in engine speed?
- Did the E (economy) mode indicator (B) come on?
- Push the E mode switch again to turn it OFF.
- Did E mode indicator go out and engine speed increase to fast idle?


YES: Go to next check.

NO: Check switch, indicator, and harness. Go to Group 9015-15.


--1/1

Operational Checkout Procedure

**HP (HIGH POWER)
MODE CHECK**



T111983 -UN-27OCT97



T112183 -UN-13NOV97

- A—HP (High Power) Mode Switch**
- B—HP (High Power) Mode Indicator**

Start the engine.

Auto-idle switch OFF.

Turn engine rpm dial clockwise to fast idle.

Push HP (high power) mode switch (A) on.

Did HP (high power) mode indicator (B) come on?

Operate the arm in function over relief (arm cylinder fully extended).

Is there some engine speed increase?

Push HP mode switch again to turn it OFF.

Does HP mode indicator go out?


YES: Go to next check.

NO: Check switch, indicator, arm in sensor, pump pressure sensor, and harness. Go to Group 9015-15.

Check linkage and fast idle speed stop at the injection pump. Go to Group 9010-20.

---1/1

**ENGINE BLOW-BY
CHECK**



T7700AC -UN-10FEB92

Run engine at fast idle and check engine blow-by tube.

Are fumes barely visible at the blow-by tube at fast idle, with no load?

NOTE: Excessive blow-by indicates that piston rings and cylinder liners do not seal off the combustion chamber. This is a comparative check that requires some experience to determine excessive blow-by.

YES: Go to next check.

NO: If blow-by is excessive. Go to Compression Pressure Test in Group 9010-25.

---1/1

Operational Checkout Procedure

<p>ENGINE PARTS LOOSE OR WORN CHECK</p>	<p>Run engine at slow idle.</p> <p>Move hydraulic control lever to operate a hydraulic function over relief to put engine under load.</p> <p>Does engine run smooth, no knocking or rattling noise?</p>	<p>YES: Operational Checkout complete.</p> <p>NO: Go to Abnormal Engine Noise, in Group 9010-15.</p>
--	---	--

9005
10
11

--1/1

④ HYDRAULIC SYSTEM CHECKS

--1/1

<p>HYDRAULIC OIL TANK PRESSURIZATION CHECK</p>	<div data-bbox="430 903 657 1102" data-label="Image"> </div> <p>T7884AG -UN-12NOV92</p> <p>Raise boom to full height, then lower boom to ground.</p> <p><i>NOTE: Ensure that engine is properly shut down.</i></p> <p>Slowly loosen vent plug on hydraulic oil tank.</p> <p>Is air heard escaping from vent plug?</p> <p><i>NOTE: The pressurized oil tank creates pressure at the inlet to the hydraulic pumps. If filler cap does not seal, hydraulic pumps could cavitate and be damaged.</i></p>	<p>YES: Go to next check.</p> <p>NO: Replace cap.</p>
---	--	---


--1/1

<p>PUMP GEARBOX OIL LEVEL CHECK</p>	<div data-bbox="397 1344 649 1575" data-label="Image"> </div> <p>T8187BB -UN-08MAR94</p> <p><i>NOTE: Ensure that engine is properly shut down.</i></p> <p>Pull dipstick from tube, check oil level.</p> <p>Is oil level between marks?</p>	<p>YES: Go to next check.</p> <p>NO: Add oil if low.</p>
--	--	--

--1/1

Operational Checkout Procedure

SWING GEARBOX OIL LEVEL CHECK



T8187BF -UN-08MAR94

NOTE: Ensure that engine is properly shut down.

Pull dipstick from tube, check oil level.

Is oil between marks?

YES: Go to next check.

NO: Add oil if low.

--1/1

PILOT CONTROLLER PATTERN CHECK—SAE PATTERN



T102070 -UN-16JUL96

Left Control Lever



T102071 -UN-16JUL96

Right Control Lever

Run engine at slow idle.

Operate machine in clear area.

Push pilot shutoff lever to UNLOCKED position. Slowly move control levers to all positions on decals.

Do bucket, boom, arm, and swing move as decals show?

YES: Go to next check.

NO: Install correct decals for control pattern. To change control pattern, go to Control Lever Pattern Conversion in Group 9025-15.

--1/1

Operational Checkout Procedure


<p>PILOT CONTROLLER PATTERN CHECK— JOHN DEERE PATTERN</p>	<div data-bbox="412 281 915 365" data-label="Image"> </div> <p>T102197 -UN-19JUL96 <i>Left Control Lever</i></p> <div data-bbox="412 567 915 651" data-label="Image"> </div> <p>T102198 -UN-19JUL96</p> <p>Run engine at slow idle.</p> <p>Operate machine in clear area.</p> <p>Push pilot shutoff lever to UNLOCKED position. Slowly move hydraulic levers to all positions on decals.</p> <p>Do bucket, boom, arm, and swing move as decals show?</p>	<p>YES: Go to next check.</p> <p>NO: Install correct decals for control pattern. To change control pattern, go to Control Lever Pattern Conversion in Group 9025-15.</p> <p style="text-align: right;">-- -1/1</p>
--	--	--


9005
10
13


<p>SWING DYNAMIC BRAKE CHECK</p>	<div data-bbox="422 1113 657 1333" data-label="Diagram"> </div> <p>T6479AY -UN-19OCT88</p> <div data-bbox="682 1134 738 1197" data-label="Image"> </div> <p>CAUTION: Make sure area is clear and large enough to swing extended arm and bucket. Machine must be on level ground.</p> <p>Position upperstructure with boom in front.</p> <p>Put arm and bucket in fully extended position with bucket 900 mm (3 ft) above ground level.</p> <p>Operate engine at fast idle.</p> <p>Actuate swing control valve to full stroke. Swing around 90 degrees and release lever.</p> <p>Does upperstructure stop within 45 degrees (1/8 turn) after releasing lever?</p> <p>Repeat procedure in opposite direction.</p>	<p>YES: Go to next check.</p> <p>NO: Check swing motor leakage. Check swing motor crossover relief valve. Go to Group 9025-25. Check swing valve spool. Go to Group 3360.</p> <p style="text-align: right;">-- -1/1</p>
---	--	---

Operational Checkout Procedure

9005
10
14

<p>SWING CIRCUIT LEAKAGE CHECK</p>	 <p>T6479AZ -UN-19OCT88</p> <p>Run engine at slow idle.</p> <p>Position machine on a side hill or raise one side of machine 300 mm (1 ft) with the boom and put blocks under track.</p> <p>Position bucket 300 mm (1 ft) off the ground at maximum reach.</p> <p>Actuate bucket curl function over relief.</p> <p><i>NOTE: Actuating the bucket function releases the mechanical swing park brake.</i></p> <p>Does upperstructure move only slightly?</p>	<p>YES: Go to next check.</p> <p>NO: Check swing circuit leakage. Go to Group 9025-25.</p> <p style="text-align: right;">-- -1/1</p>
---	--	--

<p>DIG FUNCTION DRIFT CHECK</p>	 <p>T6290AF -UN-19OCT88</p> <p>Run engine at slow idle.</p> <p>Fill bucket with dirt. Position bucket at maximum reach with bucket 2 in. (50 mm) above ground.</p> <p>Observe bucket for 1 minute.</p> <p>Does bucket drift down to ground within 1 minute?</p>	<p>YES: Check cylinder drift. Go to Group 9025-25. Inspect reduced leakage valves for boom down and arm in functions. Go to Group 3360.</p> <p>NO: Go to next check.</p> <p style="text-align: right;">-- -1/1</p>
--	---	--

<p>CONTROL VALVE LIFT CHECK TEST</p>	 <p>T6292AZ -UN-19OCT88</p> <p>Run engine at slow idle.</p> <p>Position machine as illustrated.</p> <p>Slowly actuate pilot controller to lower boom, extend arm (retract cylinder), and dump bucket (retract cylinder).</p> <p>Do functions move in opposite direction as control levers are moved, then change direction as levers are moved further?</p>	<p>YES: If functions move in opposite direction first, a leak at the lift check valve is indicated. Inspect lift check valves. Go to Group 3360.</p> <p>NO: Go to next check.</p> <p style="text-align: right;">-- -1/1</p>
---	--	---

Operational Checkout Procedure

<p>BOOM UP, ARM IN, AND BUCKET COMBINED OPERATION CHECK</p>	<p>Engine at fast idle.</p> <p>Work mode selector in dig mode.</p> <p>Actuate the boom up function, arm in function and then the bucket function.</p> <p>Does boom continue to move at approximately the same speed after bucket function is actuated?</p>	<p>YES: Go to next check.</p> <p>NO: Inspect bucket flow control valve in control valve if boom speed slows excessively. Go to Group 3360.</p>
--	--	--

9005
10
15

--1/1

<p>ARM REGENERATIVE VALVE OPERATION CHECK</p>	<p>Engine at fast idle</p> <p>Work mode selector in dig mode.</p> <p>Extend the arm to full extension and then lower boom so bucket is on the ground.</p> <p>Actuate the boom up and arm in functions in combined operation.</p> <p>Does the arm move smoothly through the complete cycle and not hesitate when it goes through the vertical position?</p>	<p>YES: Go to next check.</p> <p>NO: Check the rear pump pressure sensor, arm in pressure sensor, boom up pressure switch, and arm regenerative solenoid valve. Go to Group 9015-15.</p> <p>IF OK: Check the arm regenerative valve in the control valve. Go to Group 3360.</p>
--	--	--

--1/1

<p>PROPEL SYSTEM TRACKING CHECKS WHILE PROPELLING</p>	<p>Engine at fast idle.</p> <p>Propel speed switch in fast speed (rabbit).</p> <p>Propel machine at full speed forward on a flat and level area.</p> <p>Repeat procedure in reverse.</p> <p>Do both tracks move and machine does not mistrack excessively in forward or reverse?</p>	<p>YES: Go to next check.</p> <p>NO: Note which track does not move or if machine mistracks and the mistrack pattern. Go to Propel System Tracking Test in Group 9025-25.</p>
--	--	---

--1/1

Operational Checkout Procedure

9005
10
16

<p>PROPEL SYSTEM TRACKING CHECKS WHILE OPERATING A DIGGING FUNCTION</p>	<p>Engine at fast idle.</p> <p>Propel speed switch in fast speed (rabbit).</p> <p>Propel machine at full speed forward on a flat and level area.</p> <p>After machine is moving, slowly move the arm control lever from neutral to full actuation to extend the arm.</p> <p>Does machine mistrack excessively when the arm is extended?</p> <p><i>NOTE: Machine will slow down during this test.</i></p>	<p>YES: Inspect flow combiner valve, propel flow control valve, and propel-boom down selector valve in the control valve. Go to Group 3360.</p> <p>NO: Go to next check.</p> <p style="text-align: right;">-- -1/1</p>
--	--	--

<p>PROPEL SYSTEM MANEUVERABILITY CHECK</p>	<p>Engine at fast idle.</p> <p>Propel speed switch in fast speed (rabbit).</p> <p>Propel machine at full speed forward down a slope.</p> <p>Turn in each direction.</p> <p>Repeat the procedure in reverse.</p> <p>Does each track slow down in response to pedal or lever movement in order to turn?</p>	<p>YES: Go to next check.</p> <p>NO: Inspect counterbalance valve. Go to Group 0260.</p> <p style="text-align: right;">-- -1/1</p>
---	---	--

<p>PROPEL SPEED SELECTION CHECK</p>	<div data-bbox="381 1123 576 1648" data-label="Diagram"> <p>The diagram shows a rotary switch with four main positions: OFF, ON, INT, and A/I. A specific position is labeled 'A'. An inset shows a similar switch with positions 1 and 2.</p> </div> <p>A—Propel Speed Switch</p> <p>Engine at fast idle.</p> <p>Turn propel speed switch (A) to slow speed (turtle).</p> <p>Actuate propel function to full speed.</p> <p>Turn propel speed switch to fast speed (rabbit).</p> <p>Does machine travel speed increase?</p> <p>Actuate a dig function and then return to neutral.</p> <p>Does machine travel speed decrease and then increase?</p> <p>Turn propel speed switch to slow speed (turtle).</p> <p>Does machine travel speed decrease?</p> <p>T102104 -UN-26JUL96</p>	<p>YES: Go to next check.</p> <p>NO: Check propel pressure switches and sensors. Go to Group 9015-15. Go to Propel Motor Speed Change Circuit Operation in Group 9025-05.</p> <p style="text-align: right;">-- -1/1</p>
--	---	---

Operational Checkout Procedure

CYCLE TIMES CHECK



CAUTION: Make sure area is clear and large enough to operate all functions of machine.

IMPORTANT: Warm hydraulic oil to operating temperature for this check.

Engine at fast idle.

Auto-idle switch OFF.



T6477AQ -UN-19OCT88
Boom

9005
10
17

Operational Checkout Procedure

9005
10
18



T7884AE -UN-10NOV92
Arm, Bucket, Swing,
Propel

Move machine to position shown for each test.

Record cycle time for each function.

Boom Up—Specification

Cycle Time 3.1 ± 0.3 sec

Boom Down—Specification

Cycle Time 2.5 ± 0.3 sec

Arm In—Specification

Cycle Time 3.9 ± 0.3 sec

Arm Out—Specification

Cycle Time 2.6 ± 0.3 sec

Bucket Load—Specification

Cycle Time 4.1 ± 0.3 sec

Bucket Dump—Specification

Cycle Time 2.5 ± 0.3 sec

Swing 3 Revolutions From a Running Start—Check Time Left and Right—Specification

Cycle Time 14.4 ± 1.0 sec

Fast Speed Propel 20 m (65 ft) From a Running Start—Check Time Forward and Reverse—Specification

Cycle Time 13.4 ± 1.0 sec

Slow Speed Propel 20 m (65 ft) From a Running Start—Check Forward and Reverse—Specification

Cycle Time 20.6 ± 2.0 sec

Does machine perform within specifications?

YES: Go to next check.

NO: Check engine speed. Check hydraulic pump flow. Go to Group 9010-20 and 9025-25.

Operational Checkout Procedure

④ UNDERCARRIAGE CHECKS


---1/1

9005
10
19

TRACK SAG ROLLER AND IDLER LEAKAGE CHECKS



T6915AN -UN-07APR89



T7850AI -UN-22OCT92

Swing upperstructure to side and raise track off ground.

Operate track in reverse.

Stop engine.

Measure distance between top of track shoe to center of lower surface of track frame.

Track sag specifications:

Normal Soil—Specification

Track Sag 300—335 mm (11-13/16—13-3/16 in.)

Check rollers and idlers for oil leaks.

Is oil leaking from rollers or idlers?

Raise other side of machine and repeat checks.

NOTE: If track sag is less than specified, track chain wear will be accelerated. If it is more or less than specified on one side only, the machine may mistrack.


YES: Repair or replace idlers or rollers that are leaking. Go to Group 0130.


NO: Go to next check.


---1/1

Operational Checkout Procedure

9005
10
20

<p>SPROCKET WEAR CHECK</p>	 <p>T6981AC -UN-13MAR89</p> <p>Inspect drive sprocket.</p> <p>Is tooth wear excessive?</p> <p><i>NOTE: Do not evaluate sprocket by condition of tooth tip. Tooth tip wear does not affect sprocket operation if it does not extend into the bushing contact area.</i></p> <p><i>NOTE: Reverse drive side wear is generally more than forward drive side wear.</i></p>	<p>YES: Replace sprocket. Go to Group 0130.</p> <p>NO: Go to next check.</p> <p style="text-align: right;">-- -1/1</p>
-----------------------------------	--	--

<p>GROUSER WEAR, BENT TRACK SHOE, AND LOOSE HARDWARE CHECKS</p>	 <p>T7322AF -UN-21JUN90</p> <p>Inspect for worn grousers, bent track shoes, and loose shoe hardware.</p> <p>Are grouser bars worn excessively?</p> <p>Are track shoes bent?</p> <p>Is track shoe width appropriate for ground condition?</p> <p>Is track shoe hardware tight?</p> <p><i>NOTE: Excessive grouser wear weakens track shoes and may result in track shoes bending.</i></p>	<p>YES: If shoe hardware is loose, remove shoe and clean joint before tightening. Go to Remove and Install Track Shoe in Group 0130.</p> <p>NO: Go to next check.</p> <p style="text-align: right;">-- -1/1</p>
--	--	---

<p>TRACK LINK ROLLER AND FRONT IDLER WEAR CHECKS</p>	 <p>T6484AZ -UN-19OCT88</p> <p>Inspect track links for pin boss wear.</p> <p>Do link pin boss areas indicate contact with roller flanges or track guides?</p> <p><i>NOTE: Some contact or wear is normal. Excessive contact or wear indicates excessive rail wear.</i></p> <p>Inspect front idler flanges.</p> <p>Do idler flanges contact bushings?</p> <p><i>NOTE: Idler contact with bushings indicates excessive chain rail wear and idler tread surface wear.</i></p>	<p>YES: Go to Undercarriage Appraisal Manual SP326 for more information and specifications.</p> <p>NO: Go to next check.</p> <p style="text-align: right;">-- -1/1</p>
---	---	--


Operational Checkout Procedure

6 ACCESSORIES CHECKS

--1/1

9005
10
21

LIGHT CIRCUIT CHECKS



T102105 -UN-26JUL96

A—Light Switch

NOTE: All accessories are powered from the fuse block. If any accessories do not function, check fuses in fuse block.

Turn key switch ON.

Turn light switch (A) to 1st position.

Are monitor panel back lights and front driving lights on?

Turn light switch to 2nd position.


Do work lights on boom come on also?

YES: Go to next check.

NO: Check fuses, monitor panel back light bulbs, switches, and wiring. Go to Group 9015-15.

--1/1

WINDSHIELD WIPER CIRCUIT CHECK



T102106 -UN-26JUL96

A—Windshield Wiper Switch

Key switch ON.

Turn wiper switch (A) to INT position.

Does wiper operate intermittently?

Turn wiper switch to ON position.

Does wiper operate continuously?

Move wiper switch to OFF position.

Does wiper arm stop in park position?




YES: Go to next check.

NO: Check that upper right window lock pin engages hole in cab frame and is turned to engage the lock to close windshield enable switch. Check fuse, switch, and wiper harness. Go to Group 9015-15.

--1/1


Operational Checkout Procedure

9005
10
22

<p>WINDSHIELD WASHER CIRCUIT CHECK</p>	 <p>T102107 -UN-26JUL96</p> <p>A—Windshield Washer Switch</p> <p>IMPORTANT: Washer motor may be damaged if washer switch is held for more than 20 seconds, or continually operated with no fluid in the windshield washer tank.</p> <p>Key switch ON</p> <p>Push washer switch (A).</p> <p>Does washer fluid squirt on windshield?</p>	<p>YES: Go to next check.</p> <p>NO: Check washer fluid level. Check wiper fuse and wiring harness. Go to Group 9015-15.</p> <p style="text-align: right;">-- -1/1</p>
<p>CAB DOME LIGHT CIRCUIT CHECK</p>	 <p>T102183 -UN-26JUL96</p> <p>A—Cab Dome Light Switch</p> <p>Key switch ON.</p> <p>Move switch (A) to on position.</p> <p>Does cab dome light come on?</p>	<p>YES: Go to next check.</p> <p>NO: Check fuse and wiring harness. Go to Group 9015-15.</p> <p style="text-align: right;">-- -1/1</p>
<p>HORN CIRCUIT CHECK</p>	 <p>T102195 -UN-26JUL96</p> <p>A—Horn Button</p> <p>Key switch ON.</p> <p>Push horn button (A) on top of left control lever.</p> <p>Does horn sound?</p>	<p>YES: Go to next check.</p> <p>NO: Check fuse and wiring harness. Go to Group 9015-15.</p> <p style="text-align: right;">-- -1/1</p>

Operational Checkout Procedure

HEATER CONTROLS CHECK



T102108 -UN-26JUL96

A—Blower Control Switch
B—Temperature Control Lever

Engine running and at normal operating temperature.

Turn blower control switch (A) to all four speed positions, then back to OFF.

Does fan run in all four positions, then stop in OFF position.

With fan running at any speed, move temperature control lever (B) to warm temperature position (rearward).

Does warm air exit from vents?

YES: Go to next check.

NO: Check heater fuse, wiring harness, and motor. Go to Group 9015-15.

--1/1


9005
10
23

SEAT, DOORS, WINDOWS, LATCHES, AND LOCKS CHECKS

--1/1

Operational Checkout Procedure

SEAT CONTROL CHECKS



T102507 -UN-29JUL96

- A—Weight Adjustment Knob
- B—Seat Height and Angle Adjustment Lever
- C—Console and Seat Fore-Aft Adjustment Lever
- D—Seat Fore-Aft Adjustment Lever
- E—Backrest Adjustment Lever

Push down lever (B) and raise and lower seat.

Does seat raise and lower easily?

Push down lever (B) and adjust angle of seat.

Does seat angle change easily?

Push down lever (C). Move seat and both side consoles forward and rearward. Release lever to lock seat and side consoles in position.

Does lever unlock easily and then lock to hold seat and consoles in position?

Pull up lever (D). Move seat forward and rearward. Release lever to lock seat in any position.

Does lever move easily to unlock seat support?

Does seat move forward and rearward easily?

Does lever lock seat support in position when released?

Pull up lever (E). Tilt seat back forward and rearward. Release lever to lock seat back in any position.

Does seat back tilt forward and rearward easily?

Does lever unlock and lock easily to hold seat back in position?


YES: Go to next check.

NO: Inspect and repair or replace any parts that do not operate properly. Go to Group 1821.

9005
10
24

Operational Checkout Procedure

UPPER FRONT WINDOW CHECK



T102109 -UN-26JUL96

T102110 -UN-26JUL96

- A—Lock Pins**
- B—Rear Latch**
- C—Cab Frame Rear Holes**

Move lock pins (A) toward center of window.

Pull window up and back until it catches in latch (B) for convenient storage overhead.

Slide the two lock pins (C) into the cab frame boss holes and turn to lock.

Do pins move smoothly to lock and unlock window?

Does rear latch operate freely?

Do pins engage rear holes and lock window securely in full open position?


YES: Go to next check.

NO: Inspect. Repair. Go to Group 1810.

9005
10
25

--1/1

LOWER FRONT WINDOW STORAGE CHECK



T102111 -UN-26JUL96

T102112 -UN-26JUL96

- A—Lock Pins**
- B—Brackets**
- C—Holes**

NOTE: Upper front window must be raised before lower window can be removed from window frame.

Pull in on lock pins (A) to unlock window.

Lift the lower front window from the frame.

Store window behind rear console. Slide lock pins into hole (C) in brackets (B).

Do the springs push the lock pins out?

Does window lock securely into bracket?


YES: Go to next check.


NO: Inspect. Repair. Go to Group 1810.

--1/1


Operational Checkout Procedure

9005
10
26


<p>RIGHT REAR SIDE AND LEFT SIDE WINDOW CHECKS</p>	 <p>T102113 -UN-26JUL96</p> <p>A—Latch</p> <p>Right rear side window: Unlatch lock (A). Push joint part of lock to open window.</p> <p>Does latch operate smoothly?</p> <p>Does window remain opened when latched open?</p> <p>Left side cab window: Slide both window panes open and closed?</p> <p>Do both windowpanes slide freely to left and right?</p>	<p>YES: Go to next check.</p> <p>NO: Inspect. Repair. Go to Group 1810.</p> <p style="text-align: right;">-- -1/1</p>
---	--	---


<p>ROOF EXIT COVER CHECK</p>	 <p>T102205 -UN-26JUL96</p> <p>A—Lock Pins B—Handle</p> <p>Move lock pins (A) toward center of roof exit.</p> <p>Push on handle (B) until cover is held in open position by air cylinders.</p> <p>Pull on handle to pull cover down until lock pins “click” into position and hold cover closed.</p> <p>Does cover open and close freely?</p> <p>Does air cylinder hold cover in the open position?</p> <p>Do lock pins “click” into position and hold cover closed?</p>	<p>YES: Go to next check.</p> <p>NO: Inspect. Repair. Go to Group 1810.</p> <p style="text-align: right;">-- -1/1</p>
-------------------------------------	--	---

Operational Checkout Procedure

<p>CAB DOOR LATCH CHECK</p>	 <p>T102114 -UN-26JUL96</p> <p>A—Lever</p> <p>Open cab door.</p> <p>Lock cab door in open position.</p> <p>Push down on lever (A) to release door from locked open position.</p> <p>Close door.</p> <p>Does door unlatch easily, lock in open position securely, unlock from open position easily, and latch closed securely?</p>	<p>YES: Go to next check.</p> <p>NO: Inspect. Repair. Go to Group 1810.</p> <p style="text-align: right;">-- --1/1</p>
------------------------------------	---	--


9005
10
27

<p>CAB DOOR LOCK CHECK</p>	 <p>T7425AH -UN-10DEC90</p> <p>From outside cab, close cab door.</p> <p>Insert ignition key into door lock, turn clockwise 1/4 turn to lock.</p> <p>Allow key to return to vertical.</p> <p>Try to open door.</p> <p>Turn key 1/4 turn counterclockwise to unlock.</p> <p>Allow key to return to vertical.</p> <p>Remove key from lock.</p> <p>Does lock turn easily?</p> <p>Does lock prevent door from opening when locked?</p>	<p>YES: Go to next check.</p> <p>NO: Inspect. Repair.</p> <p style="text-align: right;">-- --1/1</p>
-----------------------------------	---	--


<p>LEFT AND RIGHT ACCESS DOORS LOCK CHECK</p>	 <p>T7425AG -UN-28NOV90</p> <p>Insert ignition key into lock and turn 180° clockwise to lock.</p> <p>Turn key 180° counterclockwise to unlock.</p> <p>Does lock turn easily and lock door and cap in position?</p> <p>Are all parts free of any visible damage?</p>	<p>YES: Go to next check.</p> <p>NO: Inspect. Repair.</p> <p style="text-align: right;">-- --1/1</p>
--	--	--

Operational Checkout Procedure

FUEL CAP LOCK CHECK



T7351AH -UN-22AUG90



T7425AF -UN-04DEC90

Turn lock cover to expose lock.

Insert ignition key into fuel cap lock.

Turn key 45° counterclockwise to lock fuel cap.

Does lock prevent cap from being removed?

Turn key 45° clockwise to unlock fuel cap.


Does lock turn easily to lock and unlock?

YES: Go to next check.

NO: Replace fuel cap.

--1/1

HOOD CHECK



T102128 -UN-26JUL96

A—Hood Hold-Open Rod

Unlock hood latch with ignition key.

Release latches.

Open hood.

Engage hold-open rod (A).

Does rod hold hood open?

Close hood and engage latches.

Do latches operate easily?

Do latches hold hood closed?

YES: Go to next check.

NO: Inspect. Repair.

--1/1

9005
10
28


Operational Checkout Procedure

7 ENGINE COOLING SYSTEM CHECKS

---1/1

9005
10
29

RADIATOR CAP CHECK



T6488FY -UN-19OCT88



CAUTION: Prevent possible injury. **DO NOT** remove radiator cap unless engine is cool. When engine is hot and cap is removed, hot coolant or steam will spray out causing serious burns.

Engine OFF and cool.


Remove radiator cap.

If coolant is warmer than surrounding air temperature, is a "whoosh" sound heard when cap is loosened?

Does cap have a stop position that requires it to be pushed down to remove?

Is spring (B) in good condition?

- A—Gasket
- B—Spring
- C—Seal



T7690AB -UN-23JAN92

Does cap have a good seal (C) and gasket (A)?
Is spring (B) in good condition?


YES: Go to next check.


NO: Replace radiator cap.


---1/1

Operational Checkout Procedure

9005
10
30

<p>RADIATOR INTERNAL CORE CHECK</p>	 <p>T6488FZ -UN-19OCT88</p> <p>CAUTION: Prevent personal injury, DO NOT remove radiator cap unless engine is cool. When engine is hot and cap is removed, hot coolant or steam will spray out causing serious burns.</p> <p>Raise engine access door.</p> <p>Remove radiator cap.</p> <p>Drain coolant into a clean container until core tubes are visible.</p> <p>Is radiator core free of rust, lime, or corrosion? Are passages in core clean, not plugged?</p>	<p>YES: Go to next check.</p> <p>NO: Remove and clean or replace radiator. Fill cooling system with clean coolant.</p> <p style="text-align: right;">-- -1/1</p>
--	---	--


<p>COOLANT LEVEL AND CONDITION IN RECOVERY TANK CHECKS</p>	 <p>T6488FX -19-21MAR89</p> <p>Engine OFF and cool.</p> <p>Open radiator access door.</p> <p>Inspect coolant level and coolant condition in recovery tank.</p> <p>Is coolant level between FULL and LOW marks on recovery tank?</p> <p>Is coolant clear, not oily, foamy, or rust colored?</p>	<p>YES: Go to next check.</p> <p>NO: Add or replace coolant.</p> <p style="text-align: right;">-- -1/1</p>
---	--	--


<p>COOLANT LEVEL AND CONDITION IN RADIATOR CHECKS</p>	 <p>T6488FY -UN-19OCT88</p> <p>CAUTION: Prevent possible injury. DO NOT remove radiator cap unless engine is cool. When engine is hot and cap is removed, hot coolant or steam will spray out causing serious burns.</p> <p>Engine OFF and cool.</p> <p>Remove radiator cap.</p> <p>Inspect coolant level.</p> <p>Inspect coolant condition.</p> <p>Is coolant level at bottom of fill neck on radiator?</p> <p>Is coolant clear, not oily, foamy or rust colored?</p>	<p>YES: Go to next check.</p> <p>NO: Add coolant if low. Check hose to coolant recovery tank. Flush radiator and engine if coolant is dirty or rusty. Add clean coolant. If coolant is oily check for hydraulic or engine oil leaks into cooling system. Go to Engine Repair chapter.</p> <p style="text-align: right;">-- -1/1</p>
--	---	---

Operational Checkout Procedure

9005
10
31


<p>COOLANT HOSES AND CLAMPS CHECKS</p>	<p>Are radiator and heater hoses free of twists, kinks, cracks, leaks, or wear from rubbing on adjacent parts?</p> <p>Are hose clamps tight and installed correctly?</p>	<p>YES: Go to next check.</p> <p>NO: Replace hoses as required. Install and tighten hose clamps.</p> <p style="text-align: right;">-- -1/1</p>
---	--	--

<p>FAN SHROUD AND FAN GUARD CHECKS</p>	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Check fan to fan shroud clearance.</p> <p>Is fan centered in shroud?</p> <p>Is guard free of damage?</p> <p>Are all mounting brackets and hardware tight?</p> </div> </div> <p style="margin-top: 10px;">T6488GN -UN-19OCT88</p>	<p>YES: Go to next check.</p> <p>NO: Adjust fan shroud to center fan. Repair or replace guard. Tighten loose hardware. Replace fan shroud if needed. Go to Group 0510.</p> <p style="text-align: right;">-- -1/1</p>
---	--	--


<p>WATER PUMP CHECK</p>	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>A—Weep Hole B—Seal</p> <p>Engine stopped.</p> <p>Is coolant leaking from weep hole (A)?</p> </div> </div> <p style="margin-top: 10px;">T7690AC -UN-27JAN92</p>	<p>YES: Seal (B) has failed. Replace seal or water pump. Go to Engine Repair chapter.</p> <p>NO: Go to next check.</p> <p style="text-align: right;">-- -1/1</p>
--------------------------------	--	--

Operational Checkout Procedure


9005
10
32

<p>FAN DIRECTION CHECK</p>	 <p>Is fan installed correctly with concave (cupped) side (Arrow) of fan blade towards engine?</p> <p><i>NOTE: If fan is installed backwards, about 50% of its capacity is lost.</i></p> <p>T6171CB -UN-25MAY89</p>	<p>YES: Check complete.</p> <p>NO: Install fan correctly. (See Remove and Install Fan Guard in Group 0510.)</p>
-----------------------------------	--	---

---1/1

<p>FAN BLADES CHECK</p>	 <p>Are fan blades bent or twisted?</p> <p>Are fan blades cracked or nicked?</p> <p>T7694AH -UN-03FEB92</p>	<p>YES: Replace fan.</p> <p>NO: Go to next check.</p>
--------------------------------	---	---

---1/1

<p>ENGINE HEAD GASKET SEAL CHECK</p>	 <p>Engine at normal temperature.</p> <p>Radiator full.</p> <p>Install radiator cap and tighten.</p> <p>Place end of radiator overflow hose into a container of clear water.</p> <p>Operate engine at fast idle. Load engine by holding a hydraulic function over relief.</p> <p>Look for bubbles coming from overflow tube. Do bubbles flow from tube intermittently?</p> <p>T6171AR -UN-25MAY89</p>	<p>YES: Head gasket is OK. Go to next check.</p> <p>NO: If there is a constant flow of bubbles from tube, loose or damaged cylinder head or a leaking head gasket may be indicated. Go to Engine Repair chapter.</p>
---	--	--

---1/1

Operational Checkout Procedure

<p>RADIATOR OUTSIDE AIR FLOW CHECK</p>	<p>Inspect radiator screen for mud and debris.</p> <p>Inspect radiator fins for mud and debris.</p> <p>Inspect radiator for bent or damaged fins.</p> <p>Are radiator fins free of mud, leaves, grass, and other debris?</p> <p>Are fins straight, not broken or cracked?</p>	<p>YES: Go to next check.</p> <p>NO: Clean screen. Clean outside of radiator. Straighten fins. Replace radiator if severely damaged.</p> <p style="text-align: right;">--1/1</p>
---	---	--

9005
10
33

<p>FAN BELT CHECK</p>	<p>Is fan belt free of oil or grease?</p> <p>Is inside surface of belt free of cracks or frayed edges?</p> <p>Is belt aligned with pulleys?</p>	<p>YES: Check complete.</p> <p>NO: Replace belt if oily, greasy, cracked, or otherwise damaged.</p> <p style="text-align: right;">--1/1</p>
------------------------------	---	---


⊗ AIR INTAKE SYSTEM CHECKS

--1/1

<p>AIR FILTER RESTRICTION INDICATOR AND SWITCH CHECK</p>	<p>Run engine at slow idle.</p> <p>Slowly cover air intake tube.</p> <p>Does air filter restriction indicator light in cab come ON?</p>	<p>YES: Go to next check.</p> <p>NO: Check monitor circuit fuse, air filter restriction indicator light and switch. Go to Group 9015-15.</p> <p style="text-align: right;">--1/1</p>
---	---	--

Operational Checkout Procedure

**AIR CLEANER
UNLOADER VALVE
CHECK**



T7531BF -UN-07JUN91

A—Air Cleaner Unloader Valve

Open left front access door.

Inspect air cleaner unloader valve (A).

Is unloader valve slightly open when the engine is not running?

Is rubber flexible and showing no sign of becoming hard or brittle?

Engine running.

Turn auto-idle switch off and turn engine rpm dial to fast idle.


Does unloader valve close?

YES: Go to next check.

NO: Replace unloader valve.

--1/1

**AIR CLEANER
ELEMENTS CHECK**



T7531BG -UN-07JUN91

**A—Secondary Element
B—Primary Element**

Remove air cleaner cover.

Inspect primary element (B).

Is element clean and in good condition?

Remove wing nut to remove primary element.

Inspect secondary element (A).

Is element clean and in good condition?


YES: Go to next check.

NO: Clean or replace primary element. Replace secondary element if primary element is damaged. Do not clean secondary element. Replace if dirty.


--1/1

Operational Checkout Procedure

**COLD WEATHER
STARTING AID CHECKS**



T103516 -UN-04SEP96



T7699AL -UN-03FEB92

- A—Starting Aid Solenoid
- B—Dust Cover

Raise engine access door.

Open left rear service door.

Check that starting fluid can is installed in starting aid solenoid (A).

If starting fluid can is NOT installed, check that dust cover (B) is installed.

Is starting fluid line from starting aid solenoid to air intake manifold straight—NOT kinked or broken?

Is arrow on starting aid nozzle pointing AGAINST air flow of air intake manifold?

NOTE: It may be necessary to scrape paint from nozzle to see arrow.


YES: Go to next check.

NO: Install a starting fluid can or the dust cover. Replace plastic line. Tighten nozzle until arrow is in correct position—pointing AGAINST incoming air flow.

9005
10
35

--1/1

**EXHAUST SMOKE
CHECK**



T6488GF -UN-19OCT88

Operate engine until coolant temperature gauge needle is in the "GREEN" zone before doing this check.

Run engine at fast idle.

Counter rotate tracks to put load to engine.

Observe exhaust smoke.

Is exhaust smoke dark black or blue smoke? Is exhaust smoke gray or white?

NOTE: Dark black smoke can be caused by dirty air filter or poor fuel delivery. Blue smoke can be caused by worn or damaged piston rings or cylinder liners. Gray or white smoke can be caused by a cold engine, dirty injection nozzles, or both.

YES: Go to Diagnose Engine Malfunctions, Group 9010-15.

NO: Go to next check.

--1/1

Operational Checkout Procedure

⊙ FUEL SYSTEM CHECKS

9005
10
36

--1/1

<p>FUEL TANK INTERIOR CHECK</p>	<p>IMPORTANT: Be careful not to damage fuel gauge sender float or low fuel level sending unit.</p> <p>Remove fuel cap.</p> <p>Use a flashlight to inspect bottom of fuel tank by shining light through the fuel.</p> <p>Is dirt, debris, or contamination seen in tank?</p>	<p>YES: Drain fuel, dispose of contaminated fuel properly. Remove debris, clean bottom of tank. Replace fuel filters. Check water separator.</p> <p>NO: Go to next check.</p>
--	--	---

--1/1



<p>FUEL TANK SUMP CHECK</p>	<div data-bbox="373 892 609 1102" data-label="Image"> </div> <p>A—Fuel Tank Drain Valve</p> <p>Hold a clean container under fuel tank drain valve (A).</p> <p>Remove recessed hex plug.</p> <p>Open drain valve for a few seconds and catch fuel in container.</p> <p>Check condition of fuel in container.</p> <p>Is water present or is fuel cloudy?</p> <p>T7700AA -UN-18FEB92</p>	<p>YES: Drain until clear fuel flows or drain all fuel from tank, dispose of contaminated fuel properly. Replace fuel filters, check water separator.</p> <p>NO: Go to next check.</p>
------------------------------------	--	--

--1/1

<p>PRIMARY FUEL FILTER (WATER SEPARATOR) CHECK</p>	<div data-bbox="406 1344 535 1554" data-label="Image"> </div> <p>Inspect fuel in primary fuel filter (water separator).</p> <p>Is water or other contamination present?</p> <p>T7700AB -UN-25FEB92</p>	<p>YES: Replace primary fuel filter element.</p> <p>NO: Go to next check.</p>
---	--	---

--1/1

Operational Checkout Procedure

<p>FUEL TRANSFER PUMP CHECK</p>	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  <p>T103528 -UN-04SEP96</p> </div> <div style="text-align: center;">  <p>T6493AA -UN-19OCT88</p> </div> </div> <p>A—Bleed Screw</p> <p>Open bleed screw (A) on fuel filter and operate hand primer on fuel transfer pump.</p> <p>Does fuel come out of bleed screw when hand primer is operated?</p> <p>Tighten bleed screw and again operate hand primer.</p> <p>Is resistance felt when hand primer is initially pumped but resistance decreases as system pressure increases?</p>	<p>YES: Go to next check.</p> <p>NO: Be certain fuel filter is clean. If not, replace filter and recheck fuel supply pump.</p>
--	---	--

9005
10
37

--1/1

<p>FUEL SYSTEM CHECK</p>	<p>Engine OFF.</p> <p>Disconnect fuel return hose from leak-off line.</p> <p>Connect a hose to leak-off line to route excess fuel into a container.</p> <p>Start engine and run at fast idle.</p> <p>Put engine under load by operating a hydraulic function over relief.</p> <p>Observe fuel flow from leak-off line.</p> <p>Does fuel flow from leak-off line with engine at full load?</p> <p><i>NOTE: Fuel that flows from leak-off line is excess fuel not required by the engine and flows back to the fuel tank.</i></p>	<p>YES: Operational checkout complete.</p> <p>NO: Fuel supply is restricted, check for plugged fuel filters, plugged fuel tank cap vent, restricted lines, stuck injection pump overflow valve, or a malfunctioning fuel transfer pump. Repair or replace as necessary.</p>
---------------------------------	---	---


--1/1

Operational Checkout Procedure

10 VISUAL INSPECTION

9005
10
38

--1/1


<p>VISUAL INSPECTION</p>	 <p>T6477AQ -UN-19OCT88</p> <p>Park machine on a level surface.</p> <p>Extend the bucket cylinder.</p> <p>Retract bucket cylinder.</p> <p>Lower the boom so bucket is on the ground.</p> <p>Stop the engine.</p> <p>Inspect oil lines and hydraulic components for leaks or damage.</p> <p>Are lines or components damaged or leaking?</p>	<p>YES: Replace damaged O-rings or gaskets. Tighten fittings or cap screws.</p> <p>Repair or replace bent or damaged lines.</p> <p>Repair or replace damaged components.</p> <p>NO: Operational checkout is complete.</p>
---------------------------------	---	---

--1/1

CHAPTER 3
SECTION 9010
ENGINE

BLANK

ENGINE—SECTIONAL VIEW



1—Rocker Arm Shaft
2—Cylinder Head
3—Push Rod
4—Cam Follower
5—Camshaft
6—Cylinder Block

7—Crankshaft
8—Crankshaft
Counterweight
9—Oil Pan
10—Connecting Rod
11—Liner Packing Rings

12—Cylinder Liner
13—Piston
14—Piston Pin
15—Piston Rings
16—Valve
17—Fuel Injection Nozzle

18—Valve Spring
19—Rocker Arm
20—Balancer Shafts (some
4-cylinder engines
only)

9010
05
1

L103403 -JUN-28NOV89

TX,9010,SB105 -19-06SEP96-1/1

*Theory of Operation***FAN DRIVE OPERATION**

The fan drive (C), driven by one fan belt from the engine crankshaft (D), is self adjustable. The fan belt tension adjuster (F) automatically adjusts the belt to correct tension.




T103369 -UN-29AUG96

- A—Alternator Pulley
- B—Idler Pulley
- C—Fan Pulley
- D—Crankshaft Pulley
- E—Water Pump Pulley
- F—Tension Adjuster

TX,9010,SB106 -19-06SEP96-1/1

ENGINE SPEED CONTROL SYSTEM OPERATION



T115408

The engine speed control circuits (Q) have the following control functions:

- Slow to fast idle in standard mode

- HP (high power) mode control
- E (economy) mode control
- Auto-idle mode
- Engine learning control

Continued on next page

CED,OUOE035,146 -19-11AUG98-1/2

9010
05
3

T115408 -19-27MAY98

Theory of Operation


The engine speed control components allows the operator to choose engine speeds to match operating conditions and to operate the engine as efficiently as possible.

Engine speeds from slow idle to fast idle in standard mode are selected by the engine rpm dial (A) located in the right console panel in cab. The E (economy) mode and HP (high power) mode are selected by switches located in the right console panel just above the engine rpm dial. The auto idle mode is selected by a switch located in the switch panel (B). Indicators in the monitor panel are lit to indicate when the E mode, HP mode, and auto-idle mode switches are pushed to activate the function.

- AI=Auto Idle Mode Switch
- E=Economy Mode Switch
- HP=High Power Mode Switch

Turning the engine rpm dial or pushing the AI, E, or HP mode switches sends an electrical signal to the engine and pump controller (C). The controller senses the electrical signal and then from the stored data sends an electrical signal to the engine control motor (D). The engine control motor regulates engine speed by a push-pull cable attached to the fuel injection pump lever located in the pump drive housing.


The engine speed sensor (P) (located in the pump drive housing) counts the pump drive gear teeth as the gears rotate. This senses actual engine speed. The sensing signal is sent to the engine and pump controller (C) which calculates engine speed.



T115409

T115409 -19-27MAY98

ENGINE RPM DIAL SPEED CONTROL CIRCUIT OPERATION



(E) ENGINE RPM DIAL SPEED CONTROL CIRCUIT

T115580

The function of the engine rpm dial speed control circuit (E) is to control engine speed from slow to fast idle in standard mode in response to the position of engine rpm dial (A).

As the engine rpm dial is turned to increase or decrease engine speed, the electrical signal sent from the dial to the engine and pump controller (D) changes. Then, from data stored in the controller, the controller sends an electrical signal to actuate the engine control motor (C). The control motor moves the injection pump lever by a push-pull cable to change engine speed in response to the position of the engine rpm dial. The EC (engine control) sensor (B) sends an electrical feedback signal to the controller indicating the motor's position.

The engine speed for slow idle is limited by the slow idle stop bracket. The data for slow idle position is stored in the engine and pump controller and is used to calculate the positions for auto-idle, E (economy), and HP (high power) modes. (See Engine Learning Control Circuit Operation in this group. For adjustment, see Injection Pump Fast and Slow Idle Stops Adjustment in Group 9010-20.)

The engine speed for fast idle in standard mode is controlled by data stored in the engine and pump controller. The parameter for fast idle in standard mode can be change from the factory setting within a specified range. (See Excavator Diagnostic Software Special Function—Engine Speed in Group 9025-25.)

9010
05
5

T115580 -19-27MAY98

Theory of Operation


The fast idle stop bracket on the injection pump limits the maximum engine speed for HP mode. (For

adjustment, see Injection Pump Fast and Slow Idle Stops Adjustment in Group 9010-20.).

CED,OUOE003,1053 -19-11AUG98-2/2

9010
05
6

E (ECONOMY) MODE SPEED CONTROL CIRCUIT OPERATION



9010
05
7

T115581

Ⓕ E (ECONOMY) MODE SPEED CONTROL CIRCUIT

T115581 -19-27MAY98

The function of E (economy) mode speed control circuit (F) is to operate the engine at a lower speed range when full engine power is not needed. The engine power is somewhat less but digging power is the same as in standard mode. Operating in E mode also improves fuel efficiency and reduces the noise level. The E mode function is available when dig mode is selected as the work mode. The E mode indicator is ON when the E mode switch (E) is push down to show that E mode is actuated.

NOTE: Standard mode is when the E mode and HP mode switches are OFF.


When E mode is actuated, the engine and pump controller (D) sends electrical signals to the engine

control motor (C) to run the engine in a speed range lower than standard mode. The adjustable range for engine speed is from the specified speed for E mode down to slow idle and is in proportion to the engine rpm dial position. The electrical signals to the motor are calculated from data stored in the engine and pump controller (D). The EC (engine control) sensor (B) sends an electrical feedback signal to the controller indicating the motor's position.

The parameter for engine speed in E (economy) mode can be change from the factory setting within a specified range. (See Excavator Diagnostic Software Special Function—Engine Speed Adjustment in Group 9025-25.)

Theory of Operation

HP (HIGH POWER) MODE SPEED CONTROL CIRCUIT OPERATION



9010
05
8

T115582

Ⓚ HP (HIGH POWER) MODE SPEED CONTROL CIRCUIT

The function of the HP (high power) mode speed control circuit (K) is to increase engine speed when a little more hydraulic power is needed for arm in operation. The HP mode is available when in the dig work mode. HP mode is used in the standard and E (economy) modes.

The HP mode is actuated with the following conditions:

- HP mode switch (A) is pushed down. The HP indicator is ON.

- Engine speed is approximately 1600 rpm or faster. The electrical signal from the engine rpm dial (B) to the engine and pump controller (I) indicates the engine speed.
- Arm in function is actuated. The arm in pressure sensor (D) sends an electrical signal to the engine and pump controller (I).
- The pump delivery pressure is approximately 23 440 kPa (234 bar) (3400 psi) or higher. The pump pressure sensors (E) send an electrical signal to the engine and pump controller.

T115582 -19-27MAY98

Theory of Operation


When all conditions are met, the engine and pump controller sends an electrical signal to the engine control motor to increase the engine speed. The amount of engine speed increase is somewhat controlled by the pump regulators adjustment and the

load on the engine. The maximum engine speed for HP mode is limited by the fast idle stop bracket on the injection pump. (For adjustment, see Injection Pump Fast and Slow Idle Stops Adjustment in Group 9010-20.).

CED.OUOE003.1055 -19-11AUG98-2/2

9010
05
9

AUTO-IDLE MODE SPEED CONTROL CIRCUIT OPERATION



9010
05
10

T115583

(H) AUTO-IDLE MODE SPEED CONTROL CIRCUIT

T115583 -19-27MAY98

The function of the auto-idle mode speed control circuit (H) is to automatically reduce engine speed when all dig and propel function are in neutral to reduce fuel consumption and the noise level. The AI indicator is ON when the auto-idle switch (E) is pushed to show that the auto-idle function is actuated. Pushing the switch again turns the auto-idle function off.


When auto-idle function is actuated and no electrical signal is received from the propel or dig pressure switches (F and G) for more than four seconds, the engine and pump controller (D) sends an electrical signal to the engine control motor (C). The control motor reduces the engine speed to the specified auto-idle speed. The electrical signal sent to the motor is calculated from data stored in the engine and pump

controller. The EC (engine control) sensor (B) sends an electrical feedback signal to the controller indicating the motor's position.

Actuating the propel or a dig function causes an electrical signal to be sent from the propel or dig pressure switch to the controller. The controller then sends an electrical signal to the engine control motor to increase engine speed back to the setting of engine rpm dial.

The parameter for auto-idle engine speed can be change from the factory setting within a specified range. (See Excavator Diagnostic Software Special Function—Engine Speed in Group 9025-25.)

ENGINE SPEED LEARNING CONTROL CIRCUIT OPERATION



9010
05
12

T115584

Ⓒ ENGINE SPEED LEARNING CONTROL CIRCUIT

T115584 -19-27MAY98

The function of the engine speed learning control circuit (G) is to learn the slow idle position as determined by the slow idle stop bracket on the injection pump and to store that data in the engine and pump controller (D).

When the engine learning switch (F) is pushed up to the learning position and the key switch (E) is turned on, the engine control motor (C) is driven by an electrical signal from the engine and pump controller (D). The control motor moves the injection pump lever to the slow idle position (the end of slot in slow idle stop bracket). An electrical feedback signal corresponding to the slow idle position is sent back to the engine and pump controller by the EC (engine

control) sensor (B). The slow idle position data is stored in the engine and pump controller.

The position of the engine control motor for auto-idle mode, E (economy) mode, and fast idle in standard mode is based on the slow idle position data stored in the engine and pump controller.

When the following components are repaired or replaced, or when engine speeds deviate from specification, the engine control motor adjustment and engine learning control procedure must be performed.

- Engine.
- Engine speed control cable.

Theory of Operation

- Slow idle bracket at injection pump.
- Fast idle bracket at injection pump.
- Engine control motor and sensor.
- Engine and pump controller.

(See Engine Control Motor and Sensor Adjustment and Engine Speed Learning Procedure in Group 9010-20.)

The procedure is not necessary after the replacement of batteries.

CED,OUOE003,1057 -19-11AUG98-2/2

9010
05
13

Group 10 System Operational Checks

ENGINE OPERATIONAL CHECKS

This procedure is designed so the mechanic can make a quick check of the engine using a minimum amount of diagnostic equipment. If you need additional information, read Theory of Operation, Group 9010-05.

A location will be required which is level and has adequate space to complete the driving checks.

The engine and all other major components must be at operating temperature for some checks. A tachometer is required.

Locate system check in the left column and read completely, following this sequence from left to right. Read each check completely before performing.

At the end of each check, if no problem is found, that check is complete or an additional check is needed. If problem is indicated, you will be given repair required and group location. If verification is needed, you will be given next best source of information:

Group 10 (System Operational Checks)

Group 15 (Diagnostic Information)

Group 20 (Adjustments)

Group 25 (Tests)


9010
10
1

TX,9010,SB110 -19-25MAY98-1/1

1 COOLING SYSTEM CHECKS

--1/1

COOLANT LEVEL AND CONDITION IN RECOVERY TANK CHECK



T7414AB
T7414AB -19-13DEC90

Engine stopped, radiator cool.

Inspect coolant level and condition in overflow tank.

Is coolant level between FULL and LOW marks on overflow tank?

Is coolant free of oil, foam, or rust?



YES: Go to next check.




NO: Add coolant if low. Drain and flush overflow tank and radiator, replace coolant if dirty or rusty. If coolant is oily, check for hydraulic or engine oil leaks into cooling system. Go to Group 0510 or Group 9000-04.

--1/1


System Operational Checks

9010
10
2

<p>COOLANT LEVEL AND CONDITION IN RADIATOR CHECKS</p>	 <p>T6488FY -UN-19OCT88</p>  <p>CAUTION: Prevent personal injury, DO NOT remove radiator cap unless engine is cool. When engine is hot and cap is removed, hot coolant or steam will spray out causing serious burns.</p> <p>Engine OFF.</p> <p>Engine cold.</p> <p>Remove radiator cap.</p> <p>With engine cold, is coolant level just below filler neck in radiator?</p> <p>Is coolant free of oil, foam or rust?</p>	<p>YES: Go to next check.</p> <p>NO: Add coolant if low. Flush radiator and engine if coolant is dirty or rusty. Add clean coolant. Go to Group 9000-04. If coolant is oily, check for hydraulic or engine oil leaks into cooling system. Go to Engine Repair chapter.</p> <p style="text-align: right;">-- -1/1</p>
--	--	--

<p>RADIATOR CAP CHECK</p>	 <p>T6488FY -UN-19OCT88</p>  <p>T7690AB -UN-23JAN92</p> <p>A—Gasket B—Spring C—Seal</p>  <p>CAUTION: Prevent personal injury, DO NOT remove radiator cap unless engine is cool. When engine is hot and cap is removed, hot coolant or steam will spray out causing serious burns.</p> <p>Engine stopped and cool.</p> <p>Remove radiator cap.</p> <p>If coolant is warmer than surrounding air temperature, is a "whoosh" sound heard when cap is loosened?</p> <p>Does cap have a stop position that requires it to be pushed down to remove?</p> <p>Does cap have a good seal (C) and gasket (A)?</p> <p>Is spring (B) in good condition?</p>	<p>YES: Go to next check.</p> <p>NO: Replace radiator cap.</p> <p style="text-align: right;">-- -1/1</p>
----------------------------------	---	--

System Operational Checks

<p>RADIATOR INTERNAL CORE CHECK</p>	 <p>T6488FZ -UN-19OCT88</p> <p>CAUTION: Prevent personal injury, DO NOT remove radiator cap unless engine is cool. When engine is hot and cap is removed, hot coolant or steam will spray out causing serious burns.</p> <p>Raise engine access door.</p> <p>Remove radiator cap.</p> <p>Drain coolant into a clean container until core tubes are visible.</p> <p>Is radiator core free of rust, lime, or corrosion? Are passages in core clean, not plugged?</p>	<p>YES: Go to next check.</p> <p>NO: Remove and clean or replace radiator. Fill cooling system with clean coolant. Go to Group 9000-04.</p>
<p>RADIATOR OUTSIDE AIR FLOW CHECK</p>	<p>Open engine access door.</p> <p>Open left rear access door.</p> <p>Inspect radiator screen for mud and debris.</p> <p>Are radiator fins free of mud, leaves, grass, and other debris?</p> <p>Is radiator damaged?</p>	<p>YES: Clean outside of radiator and straighten fins if bent. Replace radiator if severely damaged.</p> <p>NO: Go to next check.</p>
<p>COOLANT HOSES AND CLAMPS CHECK</p>	<p>Are radiator and heater hoses free of twists, kinks, cracks, leaks or wear from rubbing on adjacent parts?</p> <p>Are hose clamps tight and installed correctly?</p>	<p>YES: Go to next check.</p> <p>NO: Replace or untwist hoses as required. Tighten or reinstall hose clamps.</p>




9010
10
3

--1/1

--1/1


--1/1

System Operational Checks

<p>WATER PUMP CHECK</p>	 <p>T7690AC -UN-27JAN92</p> <p>A—Weep Hole B—Seal</p> <p>Engine stopped.</p> <p>Is coolant leaking from weep hole (A)?</p>	<p>YES: Seal (B) has failed. Replace seal or water pump. Go to Engine Repair chapter and Cooling System.</p> <p>NO: Go to next check.</p> <p style="text-align: right;">-- -1/1</p>
<p>ENGINE HEAD GASKET SEAL CHECK</p>	 <p>T6171AR -UN-25MAY89</p> <p>Engine at normal temperature.</p> <p>Radiator full.</p> <p>Install radiator cap and tighten.</p> <p>Place end of radiator overflow hose into a container of clear water.</p> <p>Operate engine at fast idle. Load engine by holding a hydraulic function over relief.</p> <p>Look for bubbles coming from overflow tube. Do bubbles flow from tube intermittently?</p>	<p>YES: Head gasket is OK. Go to next Check.</p> <p>NO: If there is a constant flow of bubbles from tube, loose or damaged cylinder head or a leaking head gasket may be indicated. Go to Engine Repair chapter.</p> <p style="text-align: right;">-- -1/1</p>
<p>FAN BLADES CHECK</p>	 <p>T7694AH -UN-03FEB92</p> <p>Are fan blades bent or twisted?</p> <p>Are fan blades cracked or nicked?</p>	<p>YES: Replace fan.</p> <p>NO: Go to next check.</p> <p style="text-align: right;">-- -1/1</p>


9010
10
4

System Operational Checks

<p>FAN DIRECTION CHECK</p>	 <p>T6488GB -UN-23AUG93</p> <p>Is fan installed correctly with cupped portion side (Arrow) of fan away from radiator?</p> <p><i>NOTE: If fan is installed backwards, about 50% of its capacity is lost.</i></p>	<p>YES: Go to next check.</p> <p>NO: Install fan correctly.</p>
-----------------------------------	--	---

9010
10
5

--1/1

<p>FAN SHROUD AND FAN GUARD CHECK</p>	 <p>T6488GC -UN-23AUG93</p> <p>Check clearance between fan and fan shroud.</p> <p>Is fan centered in shroud?</p> <p>Is guard free of damage?</p> <p>Are all mounting brackets and hardware tight?</p>	<p>YES: Go to next check.</p> <p>NO: Adjust fan shroud if fan is not centered. Repair or replace guard. Tighten loose hardware. Replace fan shroud if needed.</p>
--	--	---

--1/1

<p>FAN BELT CHECK</p>	<p>Is fan belt free of oil or grease?</p> <p>Is inside surface of belt free of cracks or frayed edges?</p> <p>Is belt aligned with pulleys?</p> <p><i>NOTE: Fan belt is self-adjusting.</i></p> <p>Is fan belt tightener operating to keep belt tight?</p>	<p>YES: Go to next check.</p> <p>NO: Replace fan belt if oily, greasy, cracked or otherwise damaged. Repair or replace tightener if belt is loose.</p>
------------------------------	--	--

--1/1

System Operational Checks

🔍 AIR INTAKE SYSTEM CHECKS

---1/1


AIR FILTER RESTRICTION INDICATOR AND SWITCH CHECK

Run engine at slow idle.
 Slowly cover air intake tube.
 Does air filter restriction indicator light in cab come ON?

YES: Go to next check.
NO: Check monitor circuit fuse, air filter restriction indicator light and switch. Go to Group 9015-15.

---1/1

AIR CLEANER UNLOADER VALVE CHECK



T7531BF -UN-07JUN91


A—Air Cleaner Unloader Valve

Open left front access door.
 Inspect unloader valve (A).
 Is unloader valve slightly open when the engine is not running?
 Is rubber flexible and showing no sign of becoming hard or brittle?
 Engine running.
 Turn auto-idle switch off and turn engine RPM control fully clockwise.
 Does unloader valve close?

YES: Go to next check.
NO: Replace unloader valve.



---1/1

System Operational Checks

<p>AIR CLEANER ELEMENT CHECK</p>	 <p>T7531BG -UN-07JUN91</p> <p>A—Secondary Element B—Primary Element</p> <p>Remove air cleaner cover.</p> <p>Inspect primary element (B).</p> <p>Is element clean and in good condition?</p> <p>Remove wing nut to remove primary element.</p> <p>Inspect secondary element (A). Is element clean and in good condition?</p>	<p>YES: Go to next check.</p> <p>NO: Clean or replace primary element. Replace secondary element if primary element is damaged. Do not clean secondary element. Replace if dirty.</p>
---	---	---

9010
10
7


--1/1

<p>COLD WEATHER STARTING AID CHECKS</p>	 <p>T103516 -UN-04SEP96</p>  <p>T7699AL -UN-03FEB92</p> <p>A—Starting Aid Solenoid B—Dust Cover</p> <p>Raise engine access door.</p> <p>Open left rear service door.</p> <p>Check starting fluid can holder (A).</p> <p>If starting fluid can is NOT in holder, make sure dust cover (B) is installed.</p> <p>Is starting fluid line from starting aid to air intake manifold straight—NOT kinked or broken?</p> <p>Is arrow on starting aid nozzle pointing AGAINST air flow of air intake manifold?</p> <p><i>NOTE: It may be necessary to scrape paint from nozzle to see arrow.</i></p>	<p>YES: Check complete.</p> <p>NO: Reposition starting fluid can holder, replace plastic line and tighten nozzle until arrow is in correct position—pointing AGAINST incoming air flow.</p>
--	---	---

--1/1

System Operational Checks

EXHAUST SMOKE CHECK



T6488GF -UN-19OCT88

Operate engine until coolant temperature gauge needle is in the "GREEN" zone before doing this check.

Run engine at fast idle.

Counter rotate tracks to put load to engine.

Observe exhaust smoke.

Is exhaust smoke dark black or blue smoke? Is exhaust smoke gray or white?

NOTE: Dark black smoke can be caused by dirty air filter or poor fuel delivery. Blue smoke can be caused by worn or damaged piston rings or cylinder liners. Gray or white smoke can be caused by a cold engine, dirty injection nozzles, or both.

YES: Go to Diagnose Engine Malfunctions, Group 9010-15.

NO: Go to next check.


9010
10
8

System Operational Checks


③ LUBRICATION SYSTEM CHECKS

---1/1

OIL LEVEL CHECK



T6488GH -19-23FEB89



T103525 -UN-10SEP96

- A—Level Check Switch
- B—Engine Oil Level Indicator

Engine OFF.

Remove dipstick and check oil level.

Is oil above "full" mark or below "add" mark on dipstick.

If oil level is high, check for fuel or anti-freeze. Drain a small amount of engine oil into a clear container. Watch oil in container to see if anti-freeze or water accumulates at the bottom.

If oil level is low, check for oil leaks or oil seal problems in engine.

Adjust oil level to between "add" and "full" marks on dipstick.

Key switch ON.

Push pre-operation level check switch (A).

Is green light for engine oil level indicator (B) ON?

YES: Add oil if low. Change oil and filter if too high. Go to Group 9000-04. Check oil level after a few hours operation to determine if a problem exists. Go to Diagnose Engine Malfunctions Group 9010-15.

NO: If oil level indicator light does not come ON, go to Monitor Diagnostic Information in Group 9015-15. If oil level is OK, go to next check.


9010
10
9

---1/1

System Operational Checks

9010
10
10

<p>ENGINE OIL CONDITION CHECK</p>	<p>Remove dipstick and check oil condition.</p> <p>Is oil milky or grainy?</p> <p>If oil is milky, moisture or anti-freeze may be present.</p> <p>If oil is grainy, carbon may be present.</p> <p>Carbon in oil may result when engine runs at slow idle too long.</p>	<p>YES: Change oil and filter. Check condition of oil after a few hours operation to determine if a problem exists. Go to Group 9000-04 or Diagnose Engine Malfunctions Group 9010-15.</p> <p>NO: Go to next check.</p> <p style="text-align: right;">-- -1/1</p>
--	--	---

<p>ENGINE OIL PRESSURE SWITCH AND INDICATOR CHECK</p>	<p>D—Engine Oil Pressure Indicator</p> <p>Turn key switch from OFF to ON and observe engine oil pressure indicator.</p> <p>Does indicator (D) come ON and stay ON?</p> <p>Start engine and observe engine oil pressure indicator.</p> <p>Does indicator go OFF a few seconds after engine starts?</p>  <p>T103526 -UN-09SEP96</p>	<p>YES: Go to next check.</p> <p>NO: Stop engine if engine oil pressure indicator remains ON after engine starts. Go to Group 9010-15 Diagnose Engine Malfunctions or Engine Repair chapter. If engine oil pressure indicator does not come ON, go to Group 9015-10 Monitor Circuit Diagnostic Procedures.</p> <p style="text-align: right;">-- -1/1</p>
--	--	--

System Operational Checks

4 FUEL SYSTEM CHECKS

---1/1

<p>FUEL TANK INTERIOR CHECK</p>	<p>IMPORTANT: Be careful not to damage fuel gauge sender float or low fuel level sending unit.</p> <p>Remove fuel cap.</p> <p>Use a flashlight to inspect bottom of fuel tank by shining light through the fuel.</p> <p>Is dirt, debris, or contamination seen in tank?</p>	<p>YES: Drain fuel, dispose of contaminated fuel properly. Remove debris, clean bottom of tank. Replace fuel filters. Check water separator.</p> <p>NO: Go to next check.</p>
--	--	---

9010
10
11

---1/1

<p>FUEL TANK SUMP CHECK</p>	<div data-bbox="418 892 657 1102" data-label="Image"> </div> <p>A—Drain Valve</p> <p>Hold a clean container under fuel tank drain valve (A).</p> <p>Remove recessed hex plug.</p> <p>Open drain valve for a few seconds and catch fuel in container.</p> <p>Check condition of fuel in container.</p> <p>Is water present or is fuel cloudy?</p>	<p>YES: Drain until clear fuel flows or drain all fuel from tank, dispose of contaminated fuel properly. Replace fuel filters, check water separator.</p> <p>NO: Go to next check.</p>
------------------------------------	---	--

T7700AA -UN-18FEB92



---1/1

<p>PRIMARY FUEL FILTER (WATER SEPARATOR) CHECK</p>	<div data-bbox="451 1348 576 1549" data-label="Image"> </div> <p>Inspect fuel in primary fuel filter (water separator).</p> <p>Is water or other contamination present?</p>	<p>YES: Replace primary fuel filter element.</p> <p>NO: Go to next check.</p>
---	---	---

T7700AB -UN-25FEB92

---1/1

System Operational Checks

<p>FUEL TRANSFER PUMP CHECK</p>	<div style="display: flex; justify-content: space-around;"> <div data-bbox="349 199 617 451">  <p>T103528 -UN-04SEP96</p> </div> <div data-bbox="633 199 909 451">  <p>T6493AA -UN-19OCT88</p> </div> </div> <p>A—Bleed Screw</p> <p>Open bleed screw (A) on fuel filter and operate hand primer on fuel transfer pump.</p> <p>Does fuel come out of bleed screw when hand primer is operated?</p> <p>Tighten bleed screw and again operate hand primer.</p> <p>Is resistance felt when hand primer is initially pumped and increase as system pressure increases?</p>	<p>YES: Go to next check.</p> <p>NO: Be certain fuel filter is clean. If not, replace filter and recheck fuel supply pump.</p>
--	---	--

-- -1/1

<p>FUEL SYSTEM CHECK</p>	<p>Engine OFF.</p> <p>Disconnect fuel return hose from leak-off line.</p> <p>Connect a hose to leak-off line to route excess fuel into a container.</p> <p>Start engine and run at fast idle.</p> <p>Put engine under load by operating a hydraulic function over relief.</p> <p>Observe fuel flow from leak-off line.</p> <p>Does fuel flow from leak-off line with engine at full load?</p> <p><i>NOTE: Fuel that flows from leak-off line is excess fuel not required by the engine and flows back to the fuel tank.</i></p>	<p>YES: Go to next check.</p> <p>NO: Fuel supply is restricted, check for plugged fuel filters, plugged fuel tank cap vent, restricted lines, stuck injection pump overflow valve, or a malfunctioning fuel transfer pump. Repair or replace as necessary.</p>
---------------------------------	---	--

-- -1/1


9010
10
12

System Operational Checks

6 ENGINE SPEED AND PERFORMANCE CHECKS

--1/1

ENGINE RPM DIAL CHECK



T102100 -UN-26JUL96

A—Engine RPM Dial

Start the engine.

Turn engine rpm dial (A) to the right to fast idle position.

Did engine speed increase to fast idle in standard mode?

Turn engine rpm dial to the left to slow idle position.

Did engine speed decrease to slow idle?

NOTE: To check and verify engine speeds, see procedure in Group 9010-20.


YES: Go to next check.

NO: Check engine rpm dial and harness. Go to Group 9015-15.

9010
10
13

--1/1

AUTO-IDLE SPEED CHECK



T103536 -UN-09SEP96

**A—Auto-Idle Switch
B—Auto-Idle Indicator**

Start engine.

Run engine at half speed.

Push auto-idle switch (A) on.

Does the auto-idle indicator (B) come on?

Does the engine speed decrease to auto-idle speed after about 4 seconds?

Actuate the bucket function momentarily. Does the engine speed increase immediately to the engine rpm dial setting?

Does the engine speed return to auto-idle after 4 seconds?

Push auto-Idle switch (A) again to turn it off.

Does the engine speed increase immediately to the engine rpm dial setting and the indicator go out?


YES: Go to next check.

NO: See Auto-Idle Circuit Diagnostic Procedures in Group 9015-15.


--1/1

System Operational Checks

E (ECONOMY) MODE



T103545 -UN-09SEP96



T103546 -UN-09SEP96

- A—E (Economy) Mode Switch**
- B—E (Economy) Mode Indicator**

Start engine.

Turn engine rpm dial clockwise to fast idle.

Push E mode switch (A) on.

Did you hear a decrease in engine speed?

Did the indicator light (B) come on?

Push the E mode switch again to turn it off.


Did indicator light go out and engine speed increase to fast idle?

YES: Go to next check.


NO: See engine speed controls in Group 9015-15.

---1/1

HP (HIGH POWER) MODE CHECK



T111983 -UN-27OCT97



T112183 -UN-13NOV97

- A—HP (High Power) Mode Switch**
- B—HP (High Power) Mode Indicator**

Start engine.

Run engine at fast idle.

Push HP (high power) mode switch (A) on.

Did HP (high power) mode indicator (B) come on?

Operate the arm in function over relief (arm cylinder fully extended).

Does the engine speed increase?

Push HP mode switch again to turn it off.

Does HP mode indicator go out?


YES: Go to next check.

NO: Check switch, indicator, and harness. Go to Group 9015-15.

---1/1

9010
10
14

System Operational Checks

<p>ENGINE BLOW-BY CHECK</p>	 <p>T7700AC -UN-10FEB92</p> <p>Run engine at fast idle and check blow-by tube.</p> <p>Are fumes barely visible at the blow-by tube at fast idle, with no load?</p> <p><i>NOTE: Excessive blow-by indicates that piston rings and cylinder liners do not seal off the combustion chamber. This is a comparative check that requires some experience to determine excessive blow-by.</i></p>	<p>YES: Go to next check.</p> <p>NO: If blow-by is excessive, go to Compression Pressure Test in Group 9010-25.</p>
<p>LOOSE OR WORN ENGINE PARTS</p>	<p>Run engine at slow idle.</p> <p>Move hydraulic control lever to operate a hydraulic function over relief to put engine under load.</p> <p>Does engine run smooth, no knocking or rattling noise?</p>	<p>YES: Operational Checkout complete.</p> <p>NO: Go to Abnormal Engine Noise, in Group 9010-15.</p>

9010
10
15

--1/1

--1/1

DIAGNOSE ENGINE MALFUNCTIONS

NOTE: Diagnostic charts are arranged from most probable and simplest to verify, to least likely and more difficult to verify.

Symptom	Problem	Solution
Engine Cranks But Will Not Start Or Hard To Start	No fuel	Add fuel. Bleed air.
	Wrong fuel	Use correct fuel.
	Water in fuel or water frozen in fuel line	Drain water from fuel tank trap. Inspect fuel filter for water. Change filter.
	Fuel filter plugged	Replace fuel filter. Bleed air clean fuel tank strainer.
	Debris in fuel	Drain fuel tank. Clean tank strainer. Add clean fuel.
	Air in fuel system	Check for bubbles in fuel filter and tighten connections. Bleed air.
	Fuel pump	Check fuel pump pressure. See Engine Repair chapter.
	Low battery power	Charge or install new batteries.
	Slow cranking speed (poor electrical connection)	Clean and tighten battery and starter connections. Incorrect engine oil (Cold weather).
	Wrong engine oil	Use correct oil.
	Air filter plugged	Check air filter restriction indicator and air filter elements. Clean or replace elements.
Standby fuse or relay	Replace fuse, relay or wiring. See Group 9015-10.	

9010
15
1

Diagnostic Information

Symptom	Problem	Solution
Engine Will Not Stop When Key Switch Is Turned OFF	Starter circuit isolating diode (V2) shorted	Pull power on fuse (F5) to stop engine. Replace start circuit isolation diode. See Group 9015-10.
Engine Will Not Crank When Key Switch Is Turned To Start Position	Start circuit isolation diode (V2) open	Replace start circuit isolation diode. See Group 9015-10.
	Injection pump metering valve sticking	Lightly tap injection pump housing. If engine now starts, repair metering valve. See Local Fuel Injection Pump Service Center.
	Electric shut-off	Check shut-off solenoid. See Group 9015-10. Inspect solenoid wiring and linkage. See your Local Fuel Injection Pump Service Center.
	Injection pump	Remove and test pump. See your Local Fuel Injection Pump Service Center.
	Injection nozzle(s)	Remove and test nozzles. See Engine Repair chapter.
	Starter	Replace starter.
	Worn compression rings or low compression	Check compression. Repair. See Engine Repair chapter.
	Starting ether used excessively	Remove nozzles and add small amount of oil to each cylinder. See Engine Repair chapter.
Engine Knocks, Runs Irregularly or Stops	Blown head gasket	Route tube between radiator and overflow tank into container of fluid and check for bubbles. Bubbles indicate head gasket leakage. See Engine Repair chapter.
	Air in fuel	Inspect filter for evidence of air in fuel. Tighten connections and bleed fuel system.

9010
15
2

Diagnostic Information

Symptom	Problem	Solution
	Debris in fuel	Drain fuel tank. Clean tank strainer. Add clean fuel.
	Wrong fuel	Use correct fuel.
	Water in fuel	Drain tank water trap, inspect filter element for water. Replace filters.
	Fuel filter plugged	Replace filter.
	Fuel injection pump out of time	Time injection pump. See Engine Repair chapter.
	Idle speeds adjustment too low	Adjust slow idle speed. See Group 9010-20.
	Engine overheating	Test cooling system. See Group 9010-25.
	Fuel transfer pump	Test pump pressure. See Engine Repair chapter.
	Fuel injection pump	Remove and test fuel injection pump. See your Local Fuel Injection Pump Service Center.
	Injection nozzle(s)	Remove and test nozzle(s). See Engine Repair chapter.
	Improper valve clearance	Check and adjust valve clearance. See Engine Repair chapter.
	Valve sticking or burned	Do compression pressure test. See Engine Repair chapter.
	Bent push rods	Inspect. Replace. See Engine Repair chapter.

9010
15
3

Continued on next page

TX,9010,SB112 -19-29MAY98-3/12

Diagnostic Information

Symptom	Problem	Solution
	Worn or broken compression rings or cylinder head gasket leaking	Route tube between radiator and overflow tank into a container of fluid and check for bubbles. Bubbles indicate head gasket leakage. See Engine Repair chapter. Do compression pressure test. See Engine Repair chapter.
9010 15 4 Engine Not Developing Full Power	Fuel filter plugged	Change filter. Bleed air.
	Air filter plugged	Clean or replace air cleaner elements.
	Debris in fuel	Drain fuel tank. Clean Tank strainer.
	Wrong fuel	Use correct fuel.
	Fuel tank outlet fitting plugged	Clean.
	Fast idle speed incorrect	Do Fast Idle Speed Adjustment. See Group 9010-20.
	Hydraulic system leakage	Do Hydraulic System Checks. See Group 9025-25.
	Fuel line to pump or pump return to tank restricted	Check, repair.
	Fuel pump	Do Fuel Pump Pressure Test. See Engine Repair chapter.
	Timing incorrect	Check injection pump timing. See Engine Repair chapter.
	Injection nozzles	Remove and test injection nozzles. See Engine Repair chapter.
	Low compression	Do Compression Pressure Test. See Engine Repair chapter.
	Injection pump delivery or governor	Repair pump. See your Local Fuel Injection Pump Service Center.

Continued on next page

TX.9010.SB112 -19-29MAY98-4/12

Diagnostic Information

Symptom	Problem	Solution
	Turbocharger	Do turbocharger inspection. See Engine Repair chapter.
	Valves burned, warped	Repair valves. See Engine Repair chapter.
	Cam shaft worn	Do Valve Lift Test. See Engine Repair chapter.
Engine Overheats	Coolant level low	Fill cooling system and check for leaks.
	Thermostat stuck closed or missing	Test and/or reinstall. See Group 0400 and Engine Repair chapter.
	Radiator screen plugged	Remove and clean screen.
	Radiator, oil cooler cores plugged with dirt or fins bent	Check air flow (see Group 9010-25). Clean radiator. Straighten fins.
	Air filter plugged	Clean or replace elements.
	Gauge or sender	Check gauge and sender. See Group 9015-10.
	Fan belt soaked with oil or pulleys worn excessively	Inspect, replace. See Operator's Manual or Repair Manual.
	Shroud or baffles (foam rubber) missing	Inspect. Repair or replace.
	Fan blade on backward	Reinstall. See Engine Repair chapter.
	Fan belt tension adjuster	Replace.
	Radiator cap or water in radiator	Test, replace cap.
	Hydraulic system overheating	Verify, repair. See Group 9025-25.
	Cooling system passages dirty	Flush cooling system.
	Water pump	Repair. See Engine Repair chapter.

9010
15
5

Diagnostic Information

Symptom	Problem	Solution
	Fuel injection pump timing	Check injection pump static timing. See Engine Repair chapter.
	Fuel delivery excessive	Remove and adjust fuel injection pump. See your Local Fuel Injection Pump Service Center.
Engine Stalls Easily Under Load	Engine speed sensor	Check engine speed sensor. See Group 9015-15.
	Engine and pump controller	Check engine and pump controller. See Group 9015-15.
	Wiring harness	Check wiring harness. See Group 9015-15.
	Fuel water separator filter plugged	Change water separator filter.
Engine Speed Does Not Change When Engine RPM Dial Is Rotated	Engine control motor	Check engine speed control motor. See Group 9015-15.
	Engine speed sensor	Check engine speed sensor. See Group 9015-15.
	Engine and pump controller	Check engine and pump controller. See Group 9015-15.
	Wiring harness	Check wiring harness. See Group 9015-15.
Engine Idle Speed Is Too Fast Or Slow	Linkage not adjusted	Adjust Linkage. See Group 9010-20.
	Engine and pump controller	Check engine and pump controller. See Group 9015-15.
	Engine control motor	Check engine speed control actuator solenoid. See Group 9015-15.
	Fuel injection pump	Remove and test fuel injection pump. See your Local Fuel Injection Pump Service Center.

Continued on next page

TX.9010,SB112 -19-29MAY98-6/12

9010
15
6

Diagnostic Information

Symptom	Problem	Solution
Auto-Idle Does Not Work	Wiring harness	Check wiring harness. See Group 9015-15.
	Pilot oil pressure switches (swing, Auto-Idle, and travel)	Check pilot oil pressure switches. See Group 9015-15.
	Engine control motor.	Check engine control motor. See Group 9015-15.
	Engine and pump controller	Check controller. See Group 9015-15.
Coolant Temperature Too Low	Wiring harness	Check wiring harness. See Group 9015-15.
	Thermostat stuck open	Replace thermostat. See Engine Repair chapter.
Oil In Coolant Or Coolant In Crankcase	Temperature gauge	Install new gauge or sending unit.
	Oil cooler leaking	Test, repair. See Engine Repair chapter.
	Head gasket leaking	Inspect, and replace. See Engine Repair chapter.
	Cylinder head cracked	Check, replace. See Engine Repair chapter.
Low Engine Oil Pressure	Liner packing leaking and/or cracked cylinder block	Remove pan, inspect bottom end, repair, verify and replace if necessary. See Engine Repair chapter.
	Oil level low	Fill to proper level.
	Oil filter plugged	Install new oil filter and oil.
	Oil pump intake screen plugged or loose	Clean. See Engine Repair chapter.
	Wrong grade of oil or fuel dilution	Use correct grade of oil. See Engine Repair chapter.

9010
15
7

Diagnostic Information

Symptom	Problem	Solution
	Engine Oil pressure regulating valve	Repair valve. See Engine Repair chapter.
	Internal oil passages leak and/or spray cooling jet missing	Check, repair. See Engine Repair chapter.
	Pressure pipe from oil pump leaking	Check. See Engine Repair chapter.
	Oil pump drive gear loose	Check, repair drive gear. See Engine Repair chapter.
	Oil pump gear and/or housing worn	Repair. See Engine Repair chapter.
	Excessive main or connecting rod bearing clearance	Replace main bearings or connecting rod bearings. See Engine Repair chapter.
High Engine Oil Pressure	Oil viscosity wrong (too thick)	Drain and refill with correct oil. See Section 9000, Group 04.
	Pressure regulating valve stuck or misadjusted	Verify, repair. See Engine Repair chapter.
	Piston cooling spray orifices plugged	Verify, clean. See Engine Repair chapter.
	Engine oil has anti-freeze	Verify, repair, change oil.
Engine Uses Too Much Oil	Wrong oil	Use correct oil. See Section 9000, Group 04.
	Oil level too high	Correct. Check to see if some other fluid is leaking into oil.
	Oil leaks	Check engine oil drain plug.
	Air cleaner plugged	Clean air cleaner elements or install new elements
	Crankcase breather restricted	Remove, clean. See Engine Repair chapter.

Continued on next page

TX.9010,SB112 -19-29MAY98-8/12

Diagnostic Information

Symptom	Problem	Solution
	Engine operating too hot or oil cooler water passage plugged	Test cooling system. See Group 9010-25. Test thermostat. See Engine Repair chapter.
	Main or connecting rod bearing clearance excessive	Replace main bearings or connecting rod bearings. See Engine Repair chapter.
	Pistons or liners scored	Check, repair pistons or liners. See Engine Repair chapter.
	Piston rings worn, broken or stuck	Do Compression Pressure Test. See Engine Repair chapter.
	Oil return slots in piston clogged	Clean. See Engine Repair chapter.
	Crankshaft thrust bearing worn (misaligned piston and rod)	Check piston and rod assembly. See Engine Repair chapter.
	Valve guides or valve stems worn	Check, repair. See Engine Repair chapter.
Engine Uses Too Much Fuel	Fuel system leakage	Tighten connections. See Engine Repair chapter.
	Plugged or dirty air intake	Clean air intake system.
	Wrong fuel	Use correct fuel.
	Injection pump static timing	Check, injection pump static timing. See Engine Repair chapter.
	Injection nozzles	Test, repair nozzles. See Engine Repair chapter.
Excessive Black Smoke	Wrong fuel	Use correct fuel.
	Plugged or dirty air intake or exhaust system.	Clean air intake and exhaust system.
	Injection pump static timing	Check injection pump timing. See Engine Repair chapter.

9010
15
9

Diagnostic Information

Symptom	Problem	Solution
	Over-fueling	Remove and adjust fuel injection pump. See your Local Fuel Injection Pump Service Center.
	Injection nozzle orifice plugged	Check and repair. See Engine Repair chapter.
Excessive Blue or White Smoke	Cranking speed too slow	Check batteries and connections. See Group 9015-10
	Injection pump static timing	Check injection pump timing. See Engine Repair chapter.
	Engine running too "cold"	Check thermostat. See Group 0400 and Engine Repair chapter.
	Wrong fuel	Use correct fuel.
	Liners have wear and/or piston ring stuck	Do Compression Pressure Test in Engine Repair chapter.
Detonation	Fuel injection pump static timing incorrect and/or injection pump advance faulty	Check injection pump static timing. See Engine Repair chapter.
	Ether starting aid solenoid stuck	Check and repair.
Abnormal Noise	Oil level low	Check and add oil.
	Wrong engine oil	Use correct oil.
	Engine oil diluted with fuel	Inspect engine oil. Inspect fuel pump spindle, seal and housing.
	Valve clearance excessive	Check, adjust valve. See Engine Repair chapter.
	Engine static timing incorrect	Check, adjust. See Engine Repair chapter.
	Push rods bent	Inspect, replace push rods. See Engine Repair chapter.

Continued on next page

TX,9010,SB112 -19-29MAY98-10/12

Diagnostic Information

Symptom	Problem	Solution
	Main and/or connecting rod bearing caps loose or worn	Inspect main bearing cap screws and connecting rod cap screws. See Engine Repair chapter.
	Piston scored	Replace piston. See Engine Repair chapter.
	Piston pin bushings worn	Replace pins and bushings. See Engine Repair chapter.
	Rocker arm shafts worn	Check. See Engine Repair chapter.
	Crankshaft end play excessive	Check, repair. See Engine Repair chapter.
	Balancer shafts out of time	Retime. See Engine Repair chapter.
Turbocharger Excessively Noisy or Vibrates	Bearings not lubricated	Insufficient oil pressure. Check for restricted turbocharger oil line.
	Worn bearings	Replace. See Engine Repair chapter.
	Air leak in engine, intake or exhaust manifold	Inspect and repair. See Engine Repair chapter.
	Improper clearance between turbine wheel and turbine housing	Remove exhaust elbow and air inlet hose. Inspect and repair. See Engine Repair chapter.
	Broken blades on turbine	Remove exhaust elbow and air inlet hose. Inspect and repair. See Engine Repair chapter.
Oil Dripping From Turbocharger Adapter	Damaged or worn bearings and/or worn seals	Inspect compressor and turbine wheel for damaged blades. Check for proper engine service intervals or dirt entering engine. See Engine Repair chapter.
	Excessive crankcase pressure	Check for plugged oil drain line. Clean.

9010
15
11

Diagnostic Information

Symptom

Problem

Solution

Excessive Drag In Turbocharger Rotating Members

Turbocharger oil return line carbon buildup where line passes exhaust manifold.

Remove line. Inspect and clean.

Carbon build-up behind turbine wheel caused by combustion deposits

Inspect and clean. See Engine Repair chapter.

Dirt build-up behind compressor wheel caused by air intake leaks

Inspect and repair. See Engine Repair chapter.

Bearing seizure or dirty or worn bearings caused by excessive temperature, unbalanced wheel, dirty oil, oil starvation, or insufficient lubrication.


Check for plugged air filters. See Engine Repair chapter.

TX,9010,SB112 -19-29MAY98-12/12

**JT05801 CLAMP-ON ELECTRONIC
TACHOMETER INSTALLATION****SERVICE EQUIPMENT AND TOOLS**

JT05801 Clamp-On Electronic Tachometer

1. Before installing clamp-on electronic tachometer, remove the paint from a straight section of injection line within 100 mm (4 in.) of No. 1 injection nozzle. Use emery cloth to remove the paint.
2. Install the clamp-on transducer (A). Tighten finger tight only—DO NOT overtighten.
3. Connect the red clip (+) (C) to the clamp-on transducer.
4. Connect the black clip (-) (B) to a ground connection such as the head of a cap screw or other metal part on engine.
5. Start the engine. Check for a reading on the digital readout unit (D).



A—Clamp-On Transducer
 B—Black Clip (-)
 C—Red Clip (+)
 D—Digital Readout Unit

T6813AG -UN-28FEB89

9010
20
1

CED, TX08227, 2879 -19-22APR98-1/1

*Adjustments***CHECK AND ADJUST FUEL SHUT-OFF SOLENOID LINKAGE**

SPECIFICATIONS	
Overtravel Needed Distance	3—6 mm (1/8—1/4 in.)
Ball Joint Hole-to-shut-Off Lever Hole Length	3 turns short
Fuel Shut-Off Solenoid Plunger-to-Ball Joint Torque	8 N•m (70 lb-in.)
Fuel Shut-Off Lever-to-Run Position Stop Clearance	Less than 0.025 mm (0.001 in.) with key switch ON and solenoid plunger bottomed.
Shut-Off Lever Clearance	Within 3 mm (0.125 in.) Of Stop Position Stop

SERVICE EQUIPMENT AND TOOLS
Feeler Gauge

Continued on next page

TX,05,GG2305 -19-22APR98-1/3

Adjustments

1. Disconnect ball joint (C) from fuel shut-off lever (D).
2. Turn key switch to ON. It is not necessary to start engine for this procedure.
3. Push plunger (F) into solenoid housing until the plunger bottoms. With key switch ON, solenoid hold coil is energized and will hold plunger in the run position
4. Manually pull fuel shut-off lever (D) up against the run position stop (upper stop) (H).
5. Check that hole in ball joint (C) is 3—6 mm (1/8—1/4 in.) short of aligning with hole in fuel shut-off lever.

The 3—6 mm (1/8—1/4 in.) is the amount of overtravel needed to compress the spring in the plunger to hold the shut-off lever against the run position stop when plunger is bottomed in the solenoid housing.

Overtravel Needed—Specification

Distance..... 3—6 mm (1/8—1/4 in.)

6. Adjust ball joint as necessary.

Manually pull fuel shut-off lever up against the run position stop (upper stop).

Adjust ball joint so hole is aligned with hole in shut-off lever and then turn ball joint to shorten linkage by three turns.

Ball Joint Hole-to-shut-Off Lever Hole—Specification



Length..... 3 turns short

Hold ball joint and tighten nut.

Fuel Shut-Off Solenoid Plunger-to-Ball Joint—Specification

Torque 8 N•m (70 lb-in.)

7. Turn key switch to OFF.
8. Connect ball joint to fuel shut-off lever using cap screw (B) and nut (E).



- A—Shut-Off Solenoid
- B—Cap Screw
- C—Ball Joint
- D—Fuel Shut-Off Lever
- E—Lock Nut
- F—Plunger
- G—Stop Position Stop (Lower Stop)
- H—Run Position Stop (Upper Stop)

T105518 -UN-04DEC96

T105519 -UN-04DEC96

9010
20
3

Adjustments

IMPORTANT: Failure to have the shut-off lever tight against run position stop (upper stop) can result in low engine horsepower.

9. Turn the key switch to ON.

Push plunger into solenoid housing so hold coil holds the plunger in the run position.

Check that shut-off lever is tight against run position stop using a 0.025 mm (0.001 in.) feeler gauge. If feeler gauge passes between shut-off lever and stop, shorten the linkage two more turns.

Fuel Shut-Off Lever-to-Run Position Stop—Specification

Clearance Less than 0.025 mm (0.001 in.)
with key switch ON and solenoid
plunger bottomed.

10. Turn key switch to OFF.

The spring inside the solenoid housing boot will extend the plunger to push the shut-off lever down to the stop position stop (lower stop) (G).

Check that shut-off lever is within 3 mm (0.125 in.) of stop position stop.

Shut-Off Lever—Specification

Clearance Within 3 mm (0.125 in.) Of Stop
Position Stop

9010
20
4

Adjustments

ENGINE SPEED CHECK

SPECIFICATIONS	
Engine Fast Idle in Standard Mode Speed	2180 ± 25 rpm
Engine Slow Idle Speed	900 ± 25 rpm

SERVICE EQUIPMENT AND TOOLS
JT05801 Clamp-On Electronic Tachometer

1. Connect the tachometer. (See JT05801 Clamp-On Electronic Tachometer Installation in this group.)
2. Warm engine to normal operating temperature.
3. Turn engine rpm dial to the right to check fast idle in standard mode.

Engine Fast Idle in Standard Mode—Specification

Speed..... 2180 ± 25 rpm

4. Turn engine rpm dial to the left to check slow idle.

Engine Slow Idle—Specification

Speed..... 900 ± 25 rpm

5. If not to specifications, do the Engine Speed Learning Procedure. (See procedure in this group.)

If engine speeds are still not to specification, do the Injection Pump Fast and Slow Idle Stops Adjustment. (See procedure in this group.)

9010
20
5

*Adjustments***INJECTION PUMP FAST AND SLOW IDLE STOPS ADJUSTMENT**

SPECIFICATIONS	
Engine Speed Slow Idle Stop Screw	900 ± 25 rpm
Engine Speed Fast Idle Stop Screw	2250 ± 25 rpm


SERVICE EQUIPMENT AND TOOLS
JT07294 Laptop Computer

1. Connect a tachometer or the JT07294 Laptop Computer to check engine speeds.
2. Warm engine to its normal operating temperature.
3. Stop the engine.
4. Disconnect speed control cable at the injection pump lever.
5. Start the engine.

Continued on next page

TX,9010,UU3410 -19-19MAY98-1/3

Adjustments



T103678

- A—Nut
- B—Slow Idle Stop Screw
- C—Nut
- D—Supplementary Idle Screw
- E—Nut
- F—Fast Idle Stop Screw

6. Push injection pump lever against fast idle stop screw (F). Record the engine speed.

Push injection pump lever against slow idle stop screw (B). Record the engine speed.

Engine Slow Idle Stop Screw—Specification

Speed..... 900 ± 25 rpm

Engine Fast Idle Stop Screw—Specification

Speed..... 2250 ± 25 rpm

Adjust the fast and slow idle stop screws on injection pump as needed.

7. Loosen nut (C) on the supplementary idle screw (D). Turn the screw out three turns.

8. Loosen nut (A) on the slow idle stop screw (B)

9. Hold injection pump lever against the slow idle stop screw.

Adjust the slow idle stop screw to obtain an engine speed that is 30—40 rpm less than the slow idle specification.

Hold screw and tighten nut.

10. Turn the supplementary idle screw in to increase engine speed to the slow idle specification. Hold screw and tighten nut.

9010
20
7

T103678 -UN-16SEP96

Adjustments

For example, to obtain the 900 rpm slow idle speed, turn the slow idle stop screw (B) out to get approximately 865 rpm. Hold screw and tighten the nut. Then turn the supplementary idle screw (D) in to increase engine speed to 900 rpm. Hold screw and tighten nut.

11. Pull injection pump lever rapidly to fast idle then decelerate to slow idle. Slow idle must be to specification.

NOTE: Increasing slow idle setting a small amount, but no more than the maximum specifications, may help to reduce surging or hunting. If surging or hunting continues, repair injection pump.

12. Loosen nut (E) on fast idle stop screw (F).

Pull lever against fast idle stop screw. Turn screw in to decrease engine speed; turn screw out to increase engine speed. Hold screw and tighten nut.

NOTE: The fast idle stop screw on the injection pump serves as the stop when the HP (high power) mode is actuated.

13. Stop the engine. Connect the cable to lever.

14. Do Engine Control Motor and Sensor Adjustment and then the Engine Speed Learning Procedure. (See procedures in this group.)

Adjustments

ENGINE CONTROL MOTOR AND SENSOR ADJUSTMENT

SPECIFICATIONS

Arm-to-Engine Control Motor Shaft Cap Screw Torque	13 N•m (115 lb-in.)
--	---------------------

When the following components are repaired or replaced, or when engine speeds deviate from specification, the engine control motor and sensor adjustment and engine learning control procedure must be performed.


- Engine
- Engine speed control cable
- Engine control motor and sensor
- Engine and pump controller
- Fast and slow idle stop screws

NOTE: The engine control sensor is located inside the engine control motor housing. Sensor is serviced as an assembly with the engine control motor.

1. Check that fast and slow idle stop screws on the injection pump are adjusted to specification. (See Injection Pump Fast and Slow Idle Stops Adjustment in this group.)
2. Turn key switch to ON.

TX,9010,UU3407 -19-19MAY98-1/3

3. Turn the engine rpm dial (A) to slow idle.



A—Engine RPM Dial

T101749 -UN-27JUN96


Continued on next page

TX,9010,UU3407 -19-19MAY98-2/3

9010
20
9

Adjustments

4. Check that engine speed control cable is connected to the outer hole of engine control motor arm (B).
5. Loosen cap screw (A) in arm (B).
6. Adjust the arm on the shaft so injection pump lever just contacts the slow idle stop screw.
7. Tighten cap screw (A).



T109243

A—Cap Screw
B—Arm

T109243 -UN-24APR97

Arm-to-Engine Control Motor Shaft Cap Screw—Specification

Torque 13 N•m (115 lb-in.)

8. Do the Engine Speed Learning Procedure. (See procedure in this group.)

TX,9010,UU3407 -19-19MAY98-3/3

ENGINE SPEED LEARNING PROCEDURE

SPECIFICATIONS	
Engine Slow Idle Speed	900 ± 25 rpm
Engine Auto-Idle Speed	1200 ± 25 rpm
E (Economy) Mode Speed	1980 ± 25 rpm
Fast Idle in Standard Mode Speed	2180 ± 25 rpm

When the following components are repaired or replaced, or when engine speeds deviate from specification, the engine control motor adjustment and engine learning control procedure must be performed.

- Engine
- Engine speed control cable
- Engine control motor and sensor
- Engine and pump controller
- Fast and slow idle stop screws

1. Stop the engine.
2. Disconnect the laptop computer from the test connector.

Wait for 5 seconds.


Continued on next page

TX,9010,UU3409 -19-11AUG98-1/2

9010
20
10

Adjustments

3. Push engine learning switch (C) up to top position. The switch is a three position switch. Make sure it is in the top position.
4. Turn key switch ON. Wait 5 seconds.
5. Turn key switch OFF. Wait 5 seconds.
6. Push engine learning switch to middle position.
7. Check engine speeds.



C—Engine Learning Switch

Engine Slow Idle—Specification

Speed 900 ± 25 rpm

Engine Auto-Idle—Specification

Speed 1200 ± 25 rpm

E (Economy) Mode—Specification

Speed 1980 ± 25 rpm

Fast Idle in Standard Mode—Specification

Speed 2180 ± 25 rpm

T103674

NOTE: The laptop computer with the excavator diagnostic software can be used to change the default speeds for slow idle, auto-idle, economy mode, and fast idle in standard mode. See Excavator Diagnostics Program Special Function—Engine Speed Adjustment in Group 9025-25.

9010
20
11

T103674 -UN-11SEP96

Adjustments

COOLING SYSTEM FILL AND DEARERATION

SPECIFICATIONS

Cooling System Capacity	22 L (6 gal)
-------------------------	--------------

deerate. It will NOT deerate during normal operation. Only during warm-up and cool down cycles will the system deerate.

FREEZING TEMPERATURES

IMPORTANT: Use only permanent-type low silicate ethylene glycol base antifreeze in coolant solution. Other types of antifreeze may damage cylinder seals.

1. Start engine. Run engine until coolant reaches a warm temperature.
2. Stop engine. Allow coolant to cool.
3. Check coolant level at recovery tank.
4. If necessary, fill recovery tank to FULL mark.
5. Repeat Steps 1—4 until recovery tank coolant level is repeatedly at the same level (stabilized).

Fill cooling system with permanent-type, low silicate, ethylene glycol antifreeze (without stop-leak additive) and clean, soft water.

FILL

1. Fill the radiator to the bottom of the fill neck.
2. Fill the coolant recovery tank to the FULL mark.

Cooling System—Specification

Capacity 22 L (6 gal)

NOTE: The level of the coolant in the cooling system MUST BE repeatedly checked after all drain and refill procedures to ensure that all air is out of the system which allows the coolant level to stabilize. Check coolant level only when the engine is cold.

DEAERATION

IMPORTANT: The cooling system requires several warm-up and cool down cycles to

6. Install recovery tank and radiator caps.

9010
20
12

FUEL LINE LEAKAGE TEST

SPECIFICATIONS	
Fuel Line Leakage Test Pressure	69 kPa (0.7 bar) (10 psi)
To Prevent Fuel System Component Damage Never Exceed Maximum Pressure	103 kPa (1 bar) (15 psi)

Connections may allow air to enter the fuel system without allowing fuel to leak out. Follow this procedure to find air leaks in the system.

Disconnect fuel supply and fuel return lines at fuel tank.

Drain all fuel from system, including fuel transfer pump, fuel injection pump, and fuel filter(s).

Close end of fuel return line using a plug, cap, or a short length of hose, plug, and clamps.

IMPORTANT: Never exceed 103 kPa (1 bar) (15 psi) to prevent damage to fuel system components.

Pressurize the system to 69 kPa (0.7 bar) (10 psi) at the fuel supply line using a regulated pressure air source.

Fuel Line Leakage Test—Specification

Pressure 69 kPa (0.7 bar) (10 psi)

To Prevent Fuel System Component Damage Never Exceed Maximum—Specification

Pressure 103 kPa (1 bar) (15 psi)

Apply liquid soap and water solution to all joints and connections in the fuel system and inspect for leaks.

Repair any leaks.

Connect supply and return lines and prime system.

Start machine and let run for approximately 10 minutes.

Tests

NOTE: For engines with an in-line fuel injection pump, an internal leak path may allow air to enter the fuel system. If an internal pump leak is suspected, remove the pump and have a pressure test performed by an authorized repair station.

TX,9010,SB119 -19-11AUG98-2/2

AIR FILTER RESTRICTION INDICATOR SWITCH TEST

SPECIFICATIONS	
Air Filter Restriction Indicator Must Come On At Vacuum	6.2 kPa (62 mbar) (25 in. water)

ESSENTIAL TOOLS	
JT05652 (1/8 F NPT x 1/8 F NPT x 1/8 M NPT) Tee	
JT03246 (1/4 F NPT x 1/4 F NPT) (Parker No. 0202-4-4) Coupler	


SERVICE EQUIPMENT AND TOOLS	
(1/8 in.) Barbed Fitting	
(1/4 in.) Barbed Fitting	
0—15 kPa (0—150 mbar) (0—60 in. water) Vacuum Gauge	

1. Remove air restriction indicator switch (A).
2. Install parts as shown.
3. Start engine and slowly cover the air cleaner inlet with a piece of paper or cardboard.
4. Air filter restriction indicator (light) must come on.

Air Filter Restriction Indicator Must Come On At—Specification

Vacuum 6.2 kPa (62 mbar) (25 in. water)

5. If reading is not within specifications, install a new indicator switch.



T7350EP

- A—Switch
- B—Tee
- C—Barbed Fitting
- D—Tube
- E—Barbed Fitting
- F—Coupler
- G—Gauge

T7350EP -UN-17DEC90

TX,9010,SB120 -19-11AUG98-1/1

9010
25
2

Tests

AIR INTAKE SYSTEM LEAKAGE TEST

SPECIFICATIONS	
Air Intake System Leakage Test Pressure	14—21 kPa (0.14—0.21 bar) (2—3 psi)

OTHER MATERIAL	
T43512 U.S. Thread Lock and Sealer (Medium Strength)	
TY9473 Canadian Thread Lock and Sealer (Medium Strength)	
242 Thread Lock and Sealer (Medium Strength)	

1. Remove air cleaner cover and main filter element.
2. Put large plastic bag into and over end of main filter element as shown. Install main filter element and cover.
3. Remove plug (A) from tube between turbocharger and intake manifold.
4. Connect air pressure regulator to manifold using hose and fitting from manifold pressure tester.
5. Pressurize air intake system to 14—21 kPa (0.14—0.21 bar) (2—3 psi). If intake system cannot be pressurized, turn engine slightly to close valves.



T5906AP -UN-23FEB89



T103680 -UN-12SEP96

A—Plug

Air Intake System Leakage Test—Specification

Pressure 14—21 kPa (0.14—0.21 bar)
(2—3 psi)

6. Spray soap solution over all connections from the air cleaner to turbocharger or air intake manifold and check for leaks. Correct all leaks.
7. Apply thread lock and sealer (medium strength) to plug. Install plug into intake manifold and tighten.

9010
25
3

Tests

RADIATOR AIR FLOW TEST

SPECIFICATIONS	
Engine Speed	Fast Idle
Air Flow Meter Total Reading Equal to or Greater Than Voltage	5.10 V (typical new)

ESSENTIAL TOOLS
JT05529 Air Flow Meter

SERVICE EQUIPMENT AND TOOLS
JT07306 Analog/Digital Multimeter


1. Lower all equipment to the ground.
2. Position all levers and pedals in neutral.
3. Stop the engine.
4. Straighten any bent fins in radiator or oil cooler.

CED,OUOE003,1058 -19-12AUG98-1/4

5. Divide the surface of trash screen into 42 equal squares starting at the top.
6. Connect air flow meter to analog/digital multimeter. Set multimeter to AC volts.
7. Start engine and run it at fast idle.

Engine—Specification

Speed Fast Idle



T109269

T109269 -JUN-24APR97

Continued on next page

CED,OUOE003,1058 -19-12AUG98-2/4

9010
25
4

Tests

8. Put air flow meter against the trash screen so it is centered in a square and air flow is through meter in the direction of air flow arrow.
9. Record voltage reading for each square that is not marked out with an "X".


NOTE: Make a copy of the JT05529 Air Flow Meter Test Record shown on the following page. Use to make a record of the voltage readings and machine information.

10. Add the voltage readings. The total of readings must be equal to or greater than the specification.

**Air Flow Meter Total Reading Equal to or Greater Than—
Specification**

Voltage..... 5.10 V (typical new)

11. If readings are less than specification, clean the trash screen and external surfaces of oil cooler and radiator. Repeat test.



9010
25
5

T6080AH -UN-01NOV88

Continued on next page

CED.OUOE003,1058 -19-12AUG98-3/4

Tests

JTO5529 AIRFLOW METER TEST RECORD

DATE: _____

CUSTOMER NAME
AND ADDRESS

MACHINE MODEL NO. _____

SERIAL NO. _____

PRE-TEST INSPECTION

OK	SERV REQD		OK	SERV REQD	
<input type="checkbox"/>	<input type="checkbox"/>	Coolant Level			
<input type="checkbox"/>	<input type="checkbox"/>	Belt Tension	<input type="checkbox"/>	<input type="checkbox"/>	Correct Fan Installation
<input type="checkbox"/>	<input type="checkbox"/>	Radiator Fin Condition	<input type="checkbox"/>	<input type="checkbox"/>	Radiator Cap
<input type="checkbox"/>	<input type="checkbox"/>	Fan Tip & Shroud Condition			

1. Divide surface of trash screen into 42 equal squares starting at the top.

2. Start engine and run it at fast idle.


Engine—Specification

Speed Fast Idle

3. Put air flow meter against the trash screen so it is centered in a square and air flow is through meter in the direction of air flow arrow.

4. Record voltage reading for each square not marked out with an "X".

5. The combined total of voltage readings must be equal to or greater than specification.



T6500AK -19-21MAR89

T109269 - JUN-24APR97

9010
25
6

Tests

ENGINE POWER TEST USING TURBOCHARGER BOOST PRESSURE

SPECIFICATIONS

Engine Fast Idle Speed	2180 ± 25 rpm in standard mode
Combined Pump Engine Pulldown Speed	100 rpm approximate with arm in over relief
HP Mode Switch Position	On
Rated Engine Speed	2100 rpm
Turbocharger Boost Pressure	79—100 kPa (0.79—1.00 bar) (11.5—14.5 psi) using No. 2 fuel and no muffler
Turbocharger Boost ^a Pressure	74—93 kPa (0.73—0.93 bar) (10.7—13.5 psi) using No. 1 fuel and no muffler

^aTurbocharger boost pressure is reduced by 7% if using No. 1 fuel.

SERVICE EQUIPMENT AND TOOLS

JT05801 Clamp-On Electronic Tachometer
JT07290 Laptop Computer
JT07274G Excavator Diagnostics Program Disk
JT07273 Cable
JT07248 Turbo Boost Test Kit

OTHER MATERIAL

T43512 U.S. Thread Lock and Sealer (Medium Strength)
TY9473 Canadian Thread Lock and Sealer (Medium Strength)
242 LOCTITE [®] Thread Lock and Sealer (Medium Strength)

This procedure must only be used as a guide to determine engine condition.

1. Connect tachometer or the laptop computer with excavator diagnostics program. (See JT05801 Clamp-On Electronic Tachometer Installation in this group. For laptop computer, see procedure in Group 9025-25. Select "14 Actual engine speed" from Monitor Data Items.)

9010
25
7

Tests

2. Remove plug (A) from tube between turbocharger and intake manifold.
3. Install fitting, hose, and pressure gauge.
4. Warm engine to normal operating temperature.
5. Turn engine rpm dial to fast idle.



T103680 -UN-12SEP96

Engine Fast Idle—Specification

Speed 2180 ± 25 rpm in standard mode

6. Check combined pump engine pulldown using arm in function over relief.

Combined Pump Engine Pulldown—Specification

Speed 100 rpm approximate with arm in over relief

If combined pump engine pulldown is not approximately 100 rpm, turn the load adjusting cartridge on the pump regulators in equal amounts to obtain 100 rpm combined pump engine pulldown. (See Hydraulic Pump Regulator Test and Adjustment—Engine Pulldown in Group 9025-25.) Be sure to turn the load adjusting cartridges out to their original setting at the end of test.

7. Push the HP mode switch on. The HP mode indicator on.

HP Mode Switch—Specification

Position On

NOTE: HP mode is actuated so the injection pump lever is pushed against the fast idle stop on the injection pump as the hydraulic pressure increases. With the injection pump lever against the fast idle stop, the maximum amount of fuel is delivered to the engine.

8. Watch the engine speed and pressure.
9. Slowly actuate arm in function over relief to load the engine pulling the speed down below rated engine speed. Repeat this step at least six times.

A—Plug

9010
25
8

Tests

Rated Engine—Specification

Speed 2100 rpm

NOTE: If using the JT07248 Turbo Boost Kit, a check valve at the pressure gauge inlet traps the highest reading for boost pressure and does not decrease as the pressure decreases.

10. Record the highest pressure reading at rated engine speed. The pressure increases as the engine speed is pulled down to rated engine speed and then decreases.

Turbocharger Boost—Specification

Pressure 79—100 kPa (0.79—1.00 bar)
(11.5—14.5 psi) using No. 2 fuel
and no muffler

Turbocharged Boost¹—Specification

Pressure 74—93 kPa (0.73—0.93 bar)
(10.7—13.5 psi) using No. 1 fuel
and no muffler

IMPORTANT: Pressure gauge accuracy is very critical for this test. Do not make adjustments to injection pump fuel delivery on the machine to raise or lower boost pressure.

New engine may not develop specified boost pressure. Check after 50 hours of operation.

11. If turbocharger boost pressure is low, check the following:
 - Wrong fuel.
 - Restricted air filter elements.
 - Restricted fuel filter elements.
 - Incorrect injection pump timing.

¹Turbocharger boost pressure is reduced by 7% if using No. 1 fuel.

Tests

- Incorrect fast idle stop adjustment at injection pump for HP mode. (See Injection Pump Fast and Slow Stops Adjustment in this group.)
- Exhaust manifold leaks.
- Intake manifold leaks.
- Faulty fuel pump.
- Low compression pressure.
- Cam lobe wear (valve clearance).
- Faulty fuel injection nozzles.
- Carbon build-up in turbocharger.
- Turbocharger compressor or turbine wheel rubbing housing.

12. Remove gauge and fitting.

13. Apply thread lock and sealer (medium strength) to plug.

Tighten plug.

14. Turn the load adjusting cartridge on the pump regulators out to their setting. (See Hydraulic Pump Regulator Test and Adjustment—Engine Pulldown in this group.)

CED.TX08227,3197 -19-12AUG98-4/4

Tests

INSPECT TORSIONAL DAMPENER

SPECIFICATIONS


Torsional Dampener Radial Runout	1.50 mm (0.060 in.) maximum
Torsional Dampener Axial Runout (Wobble)	1.50 mm (0.060 in.) maximum

ESSENTIAL TOOLS

JDG820 Flywheel Turning Tool

SERVICE EQUIPMENT AND TOOLS

D17526CI Dial Indicator



RG7507 -UN-23NOV97

9010
25
11

IMPORTANT: Do not immerse the torsional dampener in cleaning solvent or any petroleum product. Rubber portion of dampener may be damaged. Never apply thrust on outer ring. Dampener is sensitive to impact damage, such as being dropped or struck with a hammer. The dampener is not repairable. Replace dampener whenever crankshaft is replaced or after major engine overhaul.


1. Grasp outer ring of torsional dampener and attempt to turn it in both directions. If rotation is felt, replace dampener. Also, if rubber is separated, partially missing, or displaced, replace dampener.

Continued on next page

CED,OUOE003,1059 -19-12AUG98-1/3

Tests

2. Check radial runout by positioning a dial indicator so probe contacts dampener OD.
3. With engine at operating temperature, rotate crankshaft using flywheel turning tool.
4. Note dial indicator reading. If radial runout exceeds specification, replace torsional dampener.



RG7508 -UN-23NOV97


Torsional Dampener—Specification

Radial Runout..... 1.50 mm (0.060 in.) maximum

9010
25
12

CED,OUOE003,1059 -19-12AUG98-2/3

5. Check axial runout (wobble) using a dial indicator. Measure axial runout at the outer edge of dampener face (A).
6. Rotate crankshaft one complete revolution using flywheel turning tool. Note total dial indicator reading. If axial runout exceeds specification, replace torsional dampener.



RG5679 -UN-31OCT97

A—Torsional Dampener Face

Torsional Dampener—Specification

Axial Runout (Wobble) 1.50 mm (0.060 in.) maximum

CED,OUOE003,1059 -19-12AUG98-3/3

BLANK

CHAPTER 4
SECTION 9015
ELECTRICAL SYSTEM

BLANK

VISUALLY INSPECT ELECTRICAL SYSTEM

Make the following visual electrical inspection prior to starting the tractor after receiving customer complaint:

1. Look for bare wires that could ground a component or short across to another component.
2. Look for missing or worn conduit. This could indicate a wire problem.
3. Look for loose or broken connectors and wires.
4. Inspect batteries for:
 - Corroded terminals
 - Loose terminals or battery posts
 - Dirty condition
 - Damp condition
 - Cracked case
 - Proper electrolyte level
5. Check alternator belt tension.
6. After machine has been shut down for five minutes inspect for overheated parts. They will often smell


like burned insulation. Put your hand on the alternator. Heat in these parts when the unit has not been operated for some time is a sure clue to charging circuit problems.

7. If your visual inspection does not indicate the possible malfunction, but your inspection does indicate that the machine can be run, turn the key switch to the IGN position. Try out the accessory circuits, indicator lights, gauge lights. How does each of these components work? Look for sparks or smoke which might indicate shorts.
8. Start machine. Check all gauges for good operation and check to see if system is charging or discharging.
9. In general, look for anything unusual.

Many electrical failures cannot be detected even if the machine is started. Therefore, a systematic and complete inspection of the electrical system is necessary.

System Information

CIRCUIT MALFUNCTIONS



SIMPLE CIRCUIT MALFUNCTIONS

T112479

A—Battery
B—Fuse

C—Switch
D—Light

E—Ground


There are four common circuit malfunctions:

1. High-Resistance Circuit.

- 2. Open Circuit.
- 3. Grounded Circuit.
- 4. Shorted Circuit.

9015
05
2

DEFINITION OF CIRCUIT MALFUNCTIONS



HIGH RESISTANCE CIRCUIT

T112473

A—Battery
B—Fuse

C—Switch
D—High Resistance

E—Light
F—Ground

A High Resistance Circuit has unwanted resistance, like a loose or corroded connection (D) that causes a voltage drop and reduces current flow.


Continued on next page

CED, TX13067,4 -19-17DEC97-1/5

9015
05
3

T112473 -19-17DEC97

System Information



OPEN CIRCUIT

T112476

A—Battery
B—Fuse

C—Switch
D—Open

E—Light
F—Ground

An Open Circuit has a broken wire (D) that prevents current from flowing in the circuit.


Continued on next page

CED, TX13067.4 -19-17DEC97-2/5

T112476 -19-17DEC97

9015
05
4

System Information



GROUNDED CIRCUIT

T112477

A—Battery
B—Fuse

C—Switch
D—Grounded Circuit

E—Light
F—Ground

A Grounded Circuit (shorted circuit) has a power wire with its insulation rubbed through contacting the

machine frame (D) providing continuity to the battery ground terminal (shorted to ground).


Continued on next page

CED, TX13067, 4 -19-17DEC97-3/5

9015
05
5

T112477 -19-17DEC97

System Information



SENSOR CIRCUIT SHORTED TO GROUND

T112583

A—Battery
B—Fuse F1

C—Switch
D—Light

E—Circuit Ground
F—Controller Ground

A sensor circuit shorted to ground has one or more sensor wires, voltage wire (J), signal wire (I) or ground

wire (H) shorted to machine ground or a grounded wire.


Continued on next page

CED, TX13067.4 -19-17DEC97-4/5

T112583 -19-22DEC97

9015
05
6

System Information



SENSOR CIRCUIT SHORTED TO POWER

T112584


- | | | | |
|--|---------------------------------------|---------------------|------------------|
| A—Battery | E—Sensor Signal Wire Shorted to Power | H—Circuit Ground | M—Battery Ground |
| B—Fuse F1 | F—Sensor Ground Wire Shorted to Power | I—Sensor | |
| C—Switch | G—Power | J—Controller | |
| D—Sensor Voltage Wire Shorted to Power | | K—Controller Ground | |
| | | L—Fuse F2 | |

A Sensor circuit shorted to power has one or more sensor wires, voltage wire (D), signal wire (E) or ground wire (F) shorted to battery voltage.

9015
05
7

T112584 -19-22DEC97

LOCATION OF CIRCUIT MALFUNCTIONS



SIMPLE CIRCUIT MALFUNCTIONS

T112479

A—Battery
B—Fuse

C—Switch
D—Light

E—Ground


In a simple electrical circuit malfunctions only occur at three locations:

1. Before the controlling switch (C).
2. Between controlling switch (C) and load (D).

3. After the load (D).

Failed components can be diagnosed as circuit malfunctions. Isolate malfunctions to determine the cause of failure.

TROUBLESHOOTING CIRCUIT MALFUNCTIONS



FINDING CIRCUIT MALFUNCTIONS

T112480

High Resistance Circuit:

1. A high resistance circuit results in slow, dim or no component operation. High resistance can be caused by loose, corroded or oily connector terminals.
2. High resistance can be caused by wire that is too small or has broken strands internally.
3. Troubleshoot a high resistance circuit by measuring voltage between the switch and load with the switch ON.
4. If voltage is low, the malfunction is between the point of measurement and the battery. Continue measuring voltage toward battery until normal voltage is found. Malfunction is between last two points of measurement.
5. If voltage is normal, the malfunction is between point of measurement and circuit ground. Continue measuring voltage toward circuit ground until low

voltage is found. Malfunction is between last two points of measurement.

Open Circuit:

1. An open circuit results in no component operation. An open circuit can be caused by broken wires, disconnected connector, blown fuse or tripped circuit breaker.
2. Troubleshoot an open circuit by replacing the fuse or resetting the circuit breaker, then measure voltage between the switch and load with the switch ON.
3. If voltage is zero, the malfunction is between the point of measurement and the battery. Continue measuring voltage toward the battery until normal voltage is found. Malfunction is between last two points of measurement.

9015
05
9


T112480 -19-17DEC97

System Information

4. If voltage is normal, the malfunction is between point of measurement and circuit ground. Continue measuring voltage toward circuit ground until zero

voltage is found. Malfunction is between last two points of measurement.

CED,TX13067,2 -19-18DEC97-2/3



GROUNDED CIRCUIT

T112481

Grounded Circuit:

1. A grounded circuit results in no component operation and the fuse blown or circuit breaker open.
2. Troubleshoot a grounded circuit by turning the switch OFF, and checking continuity to frame ground between the fuse circuit side (B) and switch (C).
3. If continuity is measured, the malfunction is


between fuse and switch. Inspect wire harness for burned areas or insulation rubbed off a wire.

4. If continuity is not measured, measure continuity to frame ground, between switch terminal (D) and component terminal (G).
5. If continuity is measured, the malfunction is between switch and component. Inspect wire harness for burned areas or insulation rubbed off a wire.

CED,TX13067,2 -19-18DEC97-3/3

T112481 -19-17DEC97

CIRCUIT SHORTED TO POWER AND CIRCUIT SHORTED TO ITSELF



CIRCUIT SHORTED TO POWER
AND
SENSOR CIRCUIT SHORTED TO ITSELF

9015
05
12

System Information

Circuit Shorted to Power:

1. Complex circuits can fail in numerous ways. Circuits can short to other circuits causing components to operate when unrelated switches are turned ON. In the example if switch S1 is ON and wires are shorted at (G) light E1 and E2 will be ON.
2. Components can operate even when all switches are OFF. In the example if wires are shorted at (E), light E2 will be ON all the time.
3. Components can operate strangely. In the example if wires are shorted at (H), fuse F1 will blow when switch S1 is turned ON. If switch S2 is turned ON, light E2 will operate normally and light E1 may be very dim, or light E1 and E2 may be dim, even if fuse F1 is blown.

Sensor Circuit Shorted to Itself:

1. Sensors are part of a controller circuit. Controllers are used to operate components like engines, transmissions or hydraulic systems. Sensors send information such as speed, pressure or temperature from the component to the controller to monitor operation of the component. If a malfunction occurs

in the component, or the sensor circuit the controller no longer receives a "normal" signal.


- "Abnormal" signals received by a controller mean part of the circuit has a malfunction.
2. Sensor circuits can fail in numerous ways. Service Codes will be generated when sensor circuits fail. Controllers may allow the component to operate normally, may allow operation in a reduced capacity such as a "limp home mode", or the controller may prevent any component operation.
 3. If a sensor circuit signal wire (N) shorts to a ground wire, a "Short to Ground" Service Code may be generated
 4. If a sensor circuit voltage wire (O) shorts to ground, a Service Code may or may not be generated, but other sensors connected to the controller will cease to work, because their supply voltage will also be shorted to ground. Erratic operation of the monitor may result.
 5. If a sensor circuit voltage wire (P) shorts to the sensor signal wire a Service Code may or may not be generated. The controller may receive a signal indicating the sensor is reading its maximum upper or lower limit.

9015
05
13

Continued on next page

CED, TX13067, 200 -19-05FEB98-2/3

System Information



SENSOR CIRCUIT SHORTED TO GROUND

T112583

Sensor Circuit Shorted to Ground:

1. If a sensor circuit ground wire shorts to a machine ground wire (H), a service code probably won't be generated. Sensor operation may be normal.
2. If a sensor signal wire shorts to a machine ground


wire (I), a Short to Ground service code may be generated.

3. If a sensor voltage wire shorts to a machine ground wire (J), a Service Code may be generated. The monitor indicator for the sensor may illuminate.

System Information

MULTIMETER

The multimeter is an auto-ranging digital display that allows very accurate readings to be taken.



T8074AA (CV)


- A—Display
- B—Voltage AC (Alternating Current)
- C—Voltage DC (Direct Current)
- D—Resistance
- E—Diode Test/Continuity
- F—Current AC (Alternating Current)
- G—Current DC (Direct Current)
- H—Voltage, Resistance, Diode/Continuity (Red Lead Input)
- I—Ground (Black Lead Input)
- J—Current/Amps (Red Lead Input)

9015
05
15

T8074AA -19-03SEP93

System Information

SEVEN STEP ELECTRICAL TEST PROCEDURE



T7719AA (CV)

T7719AA -19-05MAR92

- A—Battery Ground
- B—Battery
- C—Battery Side Of Fuse Or Circuit Breaker
- D—Fuse Or Circuit Breaker
- E—Component Side Of Fuse Or Circuit Breaker
- F—Switch
- G—Battery Side Of Component Terminal
- H—Light (Component)
- I—Ground Side Of Component Terminal
- J—Component Ground

Step 1—Switch ON	
Check battery side of circuit breaker (C) for battery voltage	Battery voltage normal. Go to Step 2.
	Low voltage, repair high resistance.
	Open circuit from battery.
Step 2—Switch OFF	
Check component side of circuit breaker for battery voltage	Battery voltage normal. Go to Step 4.
	Low voltage, repair high resistance.
	No voltage. Go to Step 3.

Continued on next page

TX,9015,MM2917B -19-01MAY95-1/2

System Information

Step 3—Switch OFF	
Check component side of circuit breaker for continuity to ground	Continuity to ground. Repair grounded circuit at or before switch.
	No continuity to ground, replace circuit breaker.
Step 4—Switch ON	
Check component side of circuit breaker for battery voltage	Battery voltage normal. Go to Step 6.
	Low voltage, repair high resistance.
	No voltage. Go to Step 5.
Step 5	
Disconnect wire at battery side of component (G). Switch ON. Check wire at (G) for battery voltage	Battery voltage, repair component.
	No voltage, repair grounded or open circuit at or after switch.
Step 6—Switch ON	
Check lead to component at (G) for battery voltage	Battery voltage normal. Go to Step 7.
	Low voltage, repair high resistance in circuit between fuse and component.
	No voltage, repair high resistance or open circuit between fuse and component.
Step 7—Switch ON	
Check ground wire of component at (I) for voltage	No voltage, good continuity to ground.
	Repair component.
	Voltage, poor continuity to ground. Repair high resistance or open ground circuit.

9015
05
17

TX,9015,MM2917B -19-01MAY95-2/2

SYSTEM FUNCTIONAL SCHEMATIC INFORMATION

SYSTEM FUNCTIONAL SCHEMATIC DIAGRAM

The System Functional Schematic is a schematic diagram of the complete machine. All harnesses are identified by letter/number designation and description—Engine and Frame Harness (W1), Cab Harness (W2) etc. Each wire is identified by color (Blk, Red/Wht, Blk/Wht etc.) All components are identified by letter/number designation, description and are represented by a schematic symbol. Component


letter/number designation, (S1 Key Switch, F21 Battery Power 40 Amp Fusible Link, etc.) will indicate that component throughout the manual. The System Functional Schematic is divided into Sections. Each section contains one or more electrical circuits. Each section is indicated by a number and circuit (SE1 Power Circuit, SE2 Starting Circuit, etc.)

NOTE: All System Functional Schematic Diagrams are shown with key switch in the off position.

CED.OUTX782.6 -19-19NOV98-1/1

System Information

READING A SYSTEM FUNCTIONAL SCHEMATIC DIAGRAM



9015
05
18

T118586

T118586 -19-23NOV98

Continued on next page

CED.OUTX782.7 -19-19NOV98-1/2

System Information

A—Continuity Chart
B—Power Wires
C—Other Routing Location Information

D—Circuit Name
E—Section Number
F—Ground Wires
G—Component Name

H—Component Identification Code
I—Component Schematic Symbol

The System Functional Schematic Diagram is made up of sections which contain one or more Subsystem Functional Schematics laid out side by side in a logical sequence of related functions. Each Subsystem is a major group of components like starting components or charging components. Each Section of the System Functional Schematic is assigned a number (E) and a name (D) that reflects that group of components. The System Functional Schematic is formatted with power supply wires (B) shown across the top of the drawing and ground wires (F) across the bottom. The schematic contains no harness or connector information.

Each electrical component is shown by a schematic symbol (I), the component name (G), and a component identification code (H). A continuity chart (A) is included for the key switch.

Other routing location information (C) is included for reference. In the example shown the Red/Wht wire also is connected to the Horn 10 Amp Fuse which is located on Section 15 of the System Functional Schematic; and the fuse identification number is F10.


The same names and identification codes are used on all machine drawings, the System Functional Schematic, the Harness Component Location Drawing and the Harness Connectors, Wires and Pin Location drawings. Components and connectors can easily be cross-referenced from one drawing to another. See Group 9015-10 for Functional Schematic and Component Location Legend.

9015
05
19

System Information

READING A HARNESS COMPONENT LOCATION DIAGRAM

T118587 -19-18MAR99



T118587

MONITOR AND RELAY HARNESS (W3) COMPONENT LOCATION

System Information

- | | | |
|--|--|---|
| <p>A—Mating Harness Connector Identification Number</p> <p>B—Mating Harness Connector Identification Name</p> <p>C—Routing Destination of Wire (Shown as Component Identification Number)</p> | <p>D—Pin Number of Harness Connector to Which Wire is Routed</p> <p>E—Wire Color</p> <p>F—Pin Number of Harness Connector</p> <p>G—Front View of Harness Connector</p> <p>H—Name of Harness</p> | <p>I—Harness Identification Number</p> |
|--|--|---|

NOTE: The same names and identification numbers are used on all machine schematic and harness electrical drawings throughout the Operation and Test Technical Manual so components can easily be cross-referenced from one drawing to another.

The component location by harness drawing is a pictorial representation that shows harness routing, component location and mating harness connector information.

The location of each component that is connected to the harness is shown and identified by its alpha-numeric identification number (J) and component name (K). In the example shown, the component is also identified by an R number (L) that is actually marked on the part.

Each connector that joins one harness to another is identified by an "X" component identification number

(A) and a name (B). An end (front) view (G) of the connector is shown. Also, a diagram view of the connector shows connector terminal number (F), wire color (E) and destination of each wire (C and D).

In the example shown, X20 Connector connects the Monitor and Relay Harness to the Cab Harness. Pin 1 (F) of the connector contains a Red/Grn wire (E), which is routed to Pin 1 (D) of the connector for K4 (C) Drive Light Relay.

NOTE: Pin numbers are location reference numbers only—they are not printed on the connector.

Each wiring harness component location is followed by individual component connector drawings. These drawings show an end (front) view and a diagram view of each connector in the harness that connects to a component.

9015
05
21


Continued on next page

TX,9015,MM2920B -19-19NOV98-2/4

System Information


A5
 MONITOR CONTROLLER
 AND DISPLAY
 (MADE UP OF X10, X11,
 AND X12)

SEE MONITOR AND RELAY
 HARNESS (W3)
 COMPONENT LOCATION
 DETAIL A



G4
 24V POWER PLUG

1	BLK
2	BRN



K1
 ALTERNATOR SHUT DOWN RELAY
 (MARKED R1)


1	RED
2	RED/YEL
3	RED
4	PLUG
5	RED/WHT

K2
 WINDSHIELD WASHER RELAY
 (MARKED R2)

1	BLU/YEL
2	YEL/BLK
3	BLU/YEL
4	PLUG
5	PUR

K3
 WORK LIGHT RELAY
 (MARKED R3)

1	RED/GRN
2	RED/WHT
3	RED/GRN
4	PLUG
5	RED/BLU



K4
 DRIVE LIGHT RELAY
 (MARKED R4)

1	RED/GRN
2	RED/BLK
3	RED/GRN
4	PLUG
5	RED

K5
 HORN RELAY
 (MARKED R5)

1	RED/WHT
2	PNK
3	RED/WHT
4	PLUG
5	RED/GRN

K9
 WINDSHIELD WIPER RELAY
 (MOTOR GROUND FOR PARK)
 (MARKED R9)

1	BLU/YEL
2	GRN/WHT
3	BLK/RED
4	PLUG
5	BLK

K10
 PROPEL AUTO IDLE RELAY
 (MARKED R10)

1	WHT/RED
2	YEL
3	WHT/BLK
4	PLUG
5	BLK

K12
 START AID RELAY
 (MARKED R12)
 (NOT USED - FIELD OPTION)

CONNECTORS FOR MONITOR AND RELAY HARNESS (W3)
 (HARNESS CONNECTORS - FRONT VIEW SHOWN)

T118588

T118588 -19-18MAR99

System Information

In the preceding example, to see the location of the Red/Grn wire in the harness connector for the K4 Drive Light Relay, refer to the Connector Diagram. This drawing shows the end (front) view of the

connector (A), the Component Identification Number (B), the Component Name (C), the Component Marked Number (if any) (E) and the wire color (D).

TX,9015,MM2920B -19-19NOV98-4/4


9015
05
23

System Information

ELECTRICAL SCHEMATIC SYMBOLS



STARTER MOTOR



MULTI-PIN CONNECTOR



ALTERNATOR



SINGLE PIN CONNECTOR



AIR CONDITIONER COMPRESSOR



SINGLE ELEMENT BULB



COMPRESSOR




DUAL ELEMENT BULB



LIQUID PUMP



INTERNAL GROUND




KEY SWITCH



SINGLE POINT GROUND



EXTERNAL GROUND



NORMALLY OPEN SWITCH

SWITCH OPERATION

| MANUAL

[PUSH

] PULL


┌ TURN

└ TOGGLE

/ PEDAL

() KEY

∨ DETENT



NORMALLY OPEN TWO WAY SWITCH



NORMALLY OPEN MOMENTARY SWITCH



NORMALLY CLOSED MOMENTARY SWITCH


T117534

T117534 -19-07OCT98


Continued on next page

TX.9015.MM2921 -19-26OCT93-1/3


System Information




RELAY




RELAY




RELAY




RELAY



ELECTRICALLY OPERATED HYDRAULIC VALVE



SOLENOID NORMALLY OPENED



SOLENOID NORMALLY CLOSED



DC MOTOR



DC STEPPING MOTOR



WIPER MOTOR




BLOWER MOTOR




SERVO MOTOR



BUZZER



HORN



ALARM



CLOCK



HOURLMETER



SPEEDOMETER GAUGE



TACHOMETER GAUGE



TEMPERATURE GAUGE



LIQUID LEVEL GAUGE

T117637

9015
05
25

T117637 -19-07OCT98


System Information



RESISTOR



VARIABLE RESISTOR



VARIABLE RESISTOR WITH SLIDE CONTACT AND OFF



ANTENNA



DIODE



ZENER DIODE



CAPACITOR



MAGNET



BATTERY




SPLICE




FUSE




CIRCUIT BREAKER




NORMALLY OPEN TEMPERATURE SWITCH



NORMALLY OPEN PRESSURE SWITCH




NORMALLY CLOSED TEMPERATURE SWITCH



NORMALLY CLOSED PRESSURE SWITCH



NORMALLY OPEN THERMOSTAT



NORMALLY CLOSED THERMOSTAT

9015
05
26

T117532

T117532 -19-23DEC98


TX.9015.MM2921 -19-26OCT93-3/3

FUSE SPECIFICATIONS

IMPORTANT: Install fuse with correct amperage rating to prevent electrical system damage from overload.

NOTE: The "marked" name in parenthesis is the fuse name shown on the fuseblock cover.

Fuse block is located behind the operators seat under a fuse block cover.



- F1—Radio and Monitor Controller Backup 5-Amp Fuse (marked Back Up)
- F2—Engine and Pump Controller 10-Amp Fuse (marked Controller)
- F3—Engine Control (EC) Motor 10-Amp Fuse (marked EC Motor)
- F4—Solenoid 5-Amp Fuse (marked Solenoid)
- F5—Power On 10-Amp Fuse (marked Pow. On)
- F6—Monitor Controller and Display 5-Amp Fuse (marked Sw. Box)
- F7—Switched Power 5-Amp Fuse (marked Option 1)
- F8—Switched Power 10-Amp Fuse (marked Option 2)
- F9—Battery Power 5-Amp Fuse (marked Option 3)
- F10—Travel Alarm 5-Amp Fuse (marked Travel)
- F11—Work and Drive Lights 20-Amp Fuse (marked Lamp)
- F12—Windshield Wiper 10-Amp Fuse (marked Wiper)
- F13—Blower Motor 20-Amp Fuse (marked Heater)
- F14—Air Conditioner Controller and Relays 5-Amp Fuse (marked Air Con)
- F15—Horn 10-Amp Fuse (marked Horn)
- F16—Radio 5-Amp Fuse (marked Radio)
- F17—Lighter 10-Amp Fuse (marked Lighter)
- F18—Dome Light 5-Amp Fuse (marked Room Lamp)
- F19—Auxiliary 10-Amp Fuse (marked Auxiliary)
- F20—Start Aid 20-Amp Fuse (marked Start Aid) (Not used)

77713AJ (CY)

T7713AJ -JUN-06MAR92

9015
10
1

System Diagrams

FUSE (BLADE-TYPE) COLOR CODES

Amperage Rating	Color
1	Black
3	Violet
4	Pink
5	Tan
7-1/2	Brown
10	Red
15	Light Blue
20	Yellow
25	Natural (White)
30	Light Green

9015
10
2

CED,TX14795,4106 -19-22NOV97-1/1

COMPONENT IDENTIFICATION TABLE

Each component (electrical device) and main connector will have an identification letter assigned to it. A number is added to the letter to separate and indicate the total components within that letter group.

Continued on next page

TX,10,111507 -19-22AUG96-1/2

System Diagrams

Identification Letter	Type	Examples
A	System, subassembly, parts group	Control units, trigger boxes, two-way radios, logic module, FNR logic module
B	Transducer for conversion of non-electrical variables to electrical and vice versa	Speed sensors, pressure sensors, pressure switches horns, sensors, pickups, limit-value sensors, pulse generators, loudspeakers, inductive pickups, probes, air-flow sensors, oil-pressure switches, temperature sensors, ignition-voltage pickups
C	Condenser, capacitor	Condensers and capacitors, general
D	Binary device, memory	Digital devices, integrated circuits, pulse counters, magnetic tape recorders
E	Various devices and equipment	Heating devices, air conditioners, light, headlights, spark plugs, ignition distributors
F	Protection device	Release mechanisms, polarity protection devices, fuses, current protection circuits
G	Power supply, generator	Batteries, generators, alternators, charging units
H	Monitor, alarm, signalling device	Audible alarms, indicator lights, turn-signal lights, brake lights, alarms, warning lights, buzzers
K	Relay	Battery relays, turn-signal relays, solenoid switches, starting relays, warning flashers
L	Inductor	Choke coils, coils, windings
M	Motor	Blower motors, fan motors, starter motors
N	Regulator, amplifier	Regulators (electronic or electromechanical), voltage stabilizers
P	Measuring instrument	Ammeter, diagnostic connectors, tachometers, fuel gauge, pressure gauges, measuring points, test points, speedometers
R	Resistor	Flame glow plugs, sheathed-element flame glow plugs, glow plugs, heating resistors, NTC resistors, PTC resistors, potentiometers, regulating resistors
S	Switch	Switches and pushbuttons, general key switch, light switch, horn switch, flasher switch
T	Transformer	Ignition coil, ignition transformer
U	Modulator, converter	DC transformers
V	Semiconductor, electron tubes	Transistors, diodes, electron tubes, rectifiers, semiconductors, thyristors, zener diodes
W	Transmission path, conductor, antenna	Antennas, shielding components, shielded conductors, cable harnesses, conductors, ground conductors
X	Terminal, plug, plug and socket connection	Terminal studs, electrical connections, connectors electrical line couplers, line connectors, sockets, plugs, terminals, plug-and-socket connections
Y	Electrically actuated mechanical device	Permanent magnets, (solenoid-operated) injection valves, electromagnetic clutches and brakes, air valves, fuel pumps, solenoids, switching valves, start valves, locking systems
Z	Electrical filter	Interference suppression filters

9015
10
3

System Diagrams

FUNCTIONAL SCHEMATIC AND COMPONENT LOCATION LEGEND

NOTE: A2—Engine and Pump Controller (SE8, W2)

A2 indicates component identification number.

Engine and Pump Controller indicates component name.

SE8 indicates section numbers of SYSTEM FUNCTIONAL SCHEMATIC where component is located.

W2 is the identification number of the COMPONENT LOCATION and HARNESS CONNECTOR (WITH WIRE AND PIN LOCATION) drawings for the component. This would indicate that the Engine and Pump Controller is connected to W2 Cab Harness.

- A1—Radio (SE14, W2)
- A2—Engine and Pump Controller (SE8, W2)
- A3—Air Conditioner Controller (SE17, W9)
- A4—Engine Mode and RPM Control Unit (SE4, W2)
- A5—Monitor Controller and Display (SE5, W3)
- A6—Quick Hitch Control Box (SE19, W2)

- B1—Air Filter Restriction Switch (SE6, W1)
- B2—Fuel Level Switch (SE6, W1)
- B3—Engine Coolant Temperature Switch (SE6, W1)
- B4—Engine Oil Pressure Switch (SE6, W1)
- B5—Hydraulic Oil Level Switch (SE6, W1)
- B6—Engine Coolant Level Switch (SE6, W1)
- B7—Engine Oil Level Switch (SE6, W1)
- B8—Fuel Level Sensor (SE6, W1)
- B9—Engine Coolant Temperature Sensor (SE4, W1)
- B10—Not Used
- B11—Not Used
- B12—Charge Air Temperature Switch (SE6, W1)
- B13—Boom Up Pressure Switch (SE7, W1)
- B14—Dig Pressure Switch (SE7, W1)
- B15—Propel Pressure Switch (SE7, W1)
- B16—Engine Speed (N) Sensor (SE8, W1)
- B17—Engine Control (EC) Sensor (Located Inside Engine Control Motor Housing) (SE7, W1)
- B18—Rear Pump Pressure Sensor (SE7, W1)
- B19—Front Pump Pressure Sensor (SE7, W1)
- B20—Arm In Pressure Sensor (SE7, W1)
- B21—Rear Pump Control Pressure Sensor (SE7, W1)
- B22—Front Pump Control Pressure Sensor (SE7, W1)
- B23—Right Speaker (SE14, W2)
- B24—Left Speaker (SE14, W2)
- B25—High Note Horn (SE15, W1)
- B26—Low Note Horn (SE15, W1)
- B27—Air Conditioner High and Low Pressure Switch (SE17, W9)
- B28—Not Used
- B29—Air Conditioner and Heater Thermistor (SE17, W9)
- B30—Hydraulic Oil Filter Restriction Switch (Model 230LCRD) (SE6, W1)
- B31—Not Used
- B32—Overload Alarm Proximity Switch (SE19, W1)
- B33—Overload Alarm Pressure Switch (SE19, W1)
- B34—Auxiliary Hydraulic Control Switch (SE18, W2)

- E1—Left Work Light (SE13, W1)
- E2—Not Used
- E3—Cab Dome Light (SE15, W2)
- E4—Monitor Controller and Display Backlight (SE5, W3)
- E5—Engine RPM Dial Backlight (SE4, W2)
- E6—Right Work Light (SE13, W1)
- E7—Left Cab Drive Light (SE13, W1)
- E8—Right Cab Drive Light (SE13, W1)
- E9—Left Rear Light (SE13, W1)
- E10—Right Rear Light (SE13, W1)

- F1—Radio and Monitor Controller Backup 5 Amp Fuse (marked Back Up) (SE6, W2)
- F2—Engine and Pump Controller 10 Amp Fuse (marked Controller) (SE9, W2)
- F3—Engine Control (EC) Motor 10 Amp Fuse (marked EC Motor) (SE9, W2)
- F4—Solenoid 5 Amp Fuse (marked Solenoid) (SE9, W2)

System Diagrams

- F5— Power On 10 Amp Fuse (marked Pow. On) (SE3, W2)
- F6—Monitor Controller and Display 5 Amp Fuse (marked Sw. Box) (SE4, W2)
- F7—Switched Power 5 Amp Fuse (marked Option 1) (SE18, W2)
- F8—Switched Power 10 Amp Fuse (marked Option 2) (SE18, W2)
- F9—Battery Power 5 Amp Fuse (marked Option 3) (SE18, W2)
- F10—Travel Alarm 5 Amp Fuse (marked Option 1) (SE18, W2)
- F11—Work and Drive Lights 20 Amp Fuse (marked Lamp) (SE13, W2)
- F12—Windshield Wiper 10 Amp Fuse (marked Wiper) (SE12, W2)
- F13—Blower Motor 20 Amp Fuse (marked Heater) (SE16, W2)
- F14—Air Conditioner Controller and Relays 5 Amp Fuse (marked Heater) (SE17, W2)
- F15—Horn 10 Amp Fuse (marked Horn) (SE15, W2)
- F16—Radio 5 Amp Fuse (marked Radio) (SE14, W2)
- F17—Lighter 10 Amp Fuse (marked Lighter) (SE15, W2)
- F18—Dome Light 5 Amp Fuse (marked Room Lamp) (SE15, W2)
- F19—Auxiliary 10 Amp Fuse (marked Auxiliary) (SE18, W2)
- F20—Start Aid 20 Amp Fuse (marked Start Aid) (SE2, W2)
- F21—Battery Power 40 Amp Fusible Link (SE1, W1)
- F22—Alternator Power 60 Amp Fusible Link (SE1, W1)
- F23—Fuel Shutoff 40 Amp Fusible Link (SE1, W1)
- F24—Quick Hitch 5 Amp Fuse (SE19, W2)

- G1—Battery (SE1, W1)
- G2—Battery (SE1, W1)
- G3—Alternator (SE3, W1)
- G4—24 Volt Power Plug (SE15, W3)
- G5—24 Volt Slave Receptacle (SE1, W1)

- H1—Dig Mode Indicator Light (SE5, W3)
- H2—Grading Mode Indicator Light (SE5, W3)
- H3—Precision Mode Indicator Light (SE5, W3)
- H4—Attachment Mode Indicator Light (SE5, W3)
- H5—High Power Mode Indicator Light (SE4, W3)
- H6—Economy Mode Indicator Light (SE4, W3)
- H7—Auto Idle Mode Indicator Light (SE4, W3)
- H8—Monitor Controller and Display Alarm (SE5, W3)
- H9—Overload Alarm (SE19, W2)
- H10—Travel Alarm (SE10, W1)
- H11—Spare Indicator Light (SE4, W3)
- H12—Hydraulic Oil Level Indicator Light (SE4, W3)
- H13—Fuel Level Indicator Light (SE4, W3)
- H14—Air Filter Restriction Indicator Light (SE4, W3)
- H15—Charge Air Temperature Indicator Light (SE4, W3)
- H16—Engine Coolant Temperature Indicator Light (SE4, W3)
- H17—Engine Oil Pressure Indicator Light (SE4, W3)
- H18—Alternator Voltage Indicator Light (SE4, W3)
- H19—Engine Oil Level Indicator Light (SE4, W3)
- H20—Engine Coolant Level Indicator Light (SE4, W3)
- H21—Hydraulic Oil Filter Restriction Indicator Light (SE5, W3)
- H22—Quick Hitch Alarm (SE19, W2)
- H23—Quick Hitch Indicator Light (SE19, W2)

- K1—Alternator Shut Down Relay (Marked R1) (SE3, W3)
- K2—Windshield Washer Relay (Marked R2) (SE11, W3)
- K3—Work Light Relay (Marked R3) (SE13, W3)
- K4—Drive Light Relay (Marked R4) (SE13, W3)
- K5—Horn Relay (Marked R5) (SE15, W3)
- K6—Windshield Wiper Relay (Motor Ground and Intermittent) (Marked R6) (SE11, W3)
- K7—Windshield Wiper Relay (Wiper Run) (Marked R7) (SE12, W3)
- K8—Windshield Wiper Relay (Hold for Park) (Marked R8) (SE12, W3)
- K9—Windshield Wiper Relay (Motor Ground for Park) (Marked R9) (SE2, W3)
- K10—Propel Auto Idle Relay (Marked R10) (SE7, W3)

9015
10
5

System Diagrams

- K11—Starter Protection Relay (Marked R11) (SE2, W3)
- K12—Start Aid Relay (Marked R12) (SE2, W3)
- K13—Starter Relay (SE2, W1)
- K14—Battery Relay (SE1, W1)
- K15—Fuel Shutoff Relay (SE3, W1)
- K16—Overload Alarm Relay (SE19, W1)
- K17—Not Used
- K18—Not Used
- K19—Not Used
- K20—Not Used
- K21—Not Used
- K22—Not Used
- K23—Not Used
- K24—Air Conditioner Blower Motor and Main Power (Low Speed) Relay (SE17, W9)
- K25—Air Conditioner Compressor Clutch Relay (SE17, W9)
- K26—Air Conditioner Blower Motor (Low Medium Speed) Relay (SE17, W9)
- K27—Air Conditioner Blower Motor (Medium Speed) Relay (SE17, W9)
- K28—Air Conditioner Blower Motor (High Speed) Relay (SE17, W9)

- M1—Starter (SE2, W1)
- M2—Engine Control (EC) Motor (SE8, W1)
- M3—Windshield Wiper Motor (SE11, W3)
- M4—Windshield Washer Motor (SE11, W1)
- M5—Heater Blower Motor (Without Air Conditioner) (SE16, W2)
- M6—Air Conditioner and Heater Blower Motor (SE17, W9)
- M7—Not Used
- M8—Not Used
- M9—Air Conditioner Internal and External Cab Air Servomotor (SE17, W9)
- M10—Air Conditioner Blower Port Change Servomotor (SE17, W9)
- M11—Air Conditioner Air Mixer Servomotor (SE17, W9)

- P1—Hour Meter (SE5, W3)
- P2—Engine Coolant Temperature Gauge (SE4, W3)
- P3—Fuel Gauge (SE4, W3)

- R1—Not Used
- R2—Heater Blower Motor Dropping Resistor Block (Without Air Conditioner) (SE16, W2)
- R3—Not Used
- R4—Engine Coolant Temperature Gauge Resistor (150 ohms) (SE5, W3)
- R5—Fuel Gauge Resistor (220 ohms) (SE5, W3)
- R6—Alternator Excitation Resistor (SE3, W2)
- R7—Not Used
- R8—Not Used
- R9—Not Used
- R10—Engine RPM Dial (SE4, W2)
- R11—Air Conditioner and Heater Blower Motor Dropping Resistor Block (SE17, W9)

- S1—Key Switch (SE1, W2)
- S2—Horn Switch (SE15, W2)
- S3—Dome Light Switch (SE15, W2)
- S4—Heater Blower Motor Switch (Without Air Conditioner) (SE16, W2)
- S5—Fluid Level Check Switch (SE5, W3)
- S6—Buzzer Stop Switch (SE5, W3)
- S7—Work Mode Selection Switch (SE5, W3)
- S8—Propel Speed Change Switch (SE5, W3)
- S9—Wiper Speed Switch (SE5, W3)
- S10—Drive and Work Light Switch (SE5, W3)
- S11—Economy (E) Mode Switch (SE4, W2)
- S12—High Power (HP) Mode Switch (SE4, W2)
- S13—Auto Idle Switch (SE5, W3)
- S14—Windshield Wiper Enable Switch (SE4, W2)
- S15—Windshield Washer Switch (SE5, W3)
- S16—Learning Switch (SE9, W2)
- S17—Travel Alarm Cancel Switch (SE10, W2)
- S18—Start Aid Switch (SE2, W2)
- S19—Power Boost Switch (SE9, W2)
- S20—Rear Lights Switch (SE13, W2)
- S21—Quick Hitch Switch (SE19, W2)
- S22—Low Idle Sense Switch
- S23—Hand Held Tool Switch

- V1—Start Aid Diode (SE2, W1)
- V2—Alternator Shut Down Relay Isolation Diode (SE3, W2) (Red/Wht and Red/Blk)

System Diagrams

- V3—Switched Power Fuse (F8) Suppression Diode (SE18, W2) (Blk and Red)
- V4—Propel Auto Idle Relay (marked R10) Isolation Diode (SE7, W2) (Wht/Blk and Yel)
- V5—Windshield Wiper Relay (marked R8) Isolation Diode (SE12, W3) (Blu/Blk and Blu/Red)
- V6—Windshield Wiper Motor Suppression Diode (SE11, W3) (Blk and LGrn/Wht)
- V7—Windshield Wiper Motor Suppression Diode (SE11, W3) (Blk and Blu/Wht)
- V8—Fuel Shutoff Solenoid Hold-In Coil Suppression Diode (SE3, W2) (Brn/Blk and Blk)
- V9—Start Relay Coil Suppression Diode (SE2, W2) (Yel/Grn and Blk/Wht)
- V10—Fuel Shutoff Solenoid Pull-In Coil Suppression Diode (SE3, W2) (Red/Blk and Blk)
- V11—Battery Relay Coil Suppression Diode (SE1, W1) (Blk and Red/Wht)
- W1—Engine and Frame Harness
- W2—Cab Harness
- W3—Monitor and Relay Harness
- W4—Radio Antenna (SE14, W2)
- W5—Battery to Frame Ground (W1)
- W6—Engine to Frame Ground (W1)
- W7—Cab to Frame Ground (W2)
- W8—Starter to Frame Ground (SE2, W1)
- W9—Air Conditioner Harness
- W10—Air Compressor and Rock Drill Harness (Model 230LCRD)
- X1—Diagnostic Connector (SE9, W2)
- X2—Learning Switch Connector (SE9, W2)
- X3—Attachment Pressure Switch Connector (SE9, W2)
- X4—Accel Connector (SE8, W2)
- X5—Optional Connector (SE18, W2)
- X6—Auxiliary Connector (SE18, W2)
- X7—Optional Right Speaker Connector (SE14, W2)
- X8—Engine and Frame Harness to Cab Harness Connector (W1, W2)
- X9—Engine and Frame Harness to Cab Harness Connector (W1, W2)
- X10—Monitor Controller and Display Connector (20-Pin) (W3)
- X11—Monitor Controller and Display Connector (16-Pin) (W3)
- X12—Monitor Controller and Display Connector (12-Pin) (W3)
- X13—Engine and Pump Controller Connector (26-Pin) (W2)
- X14—Engine and Pump Controller Connector (16-Pin) (W2)
- X15—Engine and Pump Controller Connector (22-Pin) (W2)
- X16—Air Conditioner Harness to Cab Harness Connector (SE17, W2, W9)
- X17—Air Conditioner Controller Connector (16-Pin) (SE17, W9)
- X18—Air Conditioner Controller Connector (12-Pin) (SE17, W9)
- X19—Monitor and Relay Harness to Cab Harness Connector (2-Pin) (W2, W3)
- X20—Monitor and Relay Harness to Cab Harness Connector (6-Pin) (W2, W3)
- X21—Monitor and Relay Harness to Cab Harness Connector (12-Pin) (W2, W3)
- X22—Monitor and Relay Harness to Cab Harness Connector (16-Pin) (W2, W3)
- X23—Monitor and Relay Harness to Cab Harness Connector (8-Pin) (W2, W3)
- X24—Optional Connector (W3)
- X25—Optional Connector (W3)
- X26—Engine and Frame Harness to Cab Harness Connector (W1, W2)
- X27—Auxiliary Power Terminal Strip (SE8, W1, W2)
- X28—Rear Light Switch Harness to Rear Light Harness Connector (SE13, W1)
- Y1—Air Conditioner Compressor Clutch (SE17, W1 and W9)
- Y2—Quick Hitch Solenoid (SE19, W1)
- Y3—Not Used
- Y4—Start Aid Solenoid (SE2, W1)
- Y5—Power Boost Proportional Solenoid (SE7, W1)
- Y6—Propel Speed Change Proportional Solenoid (SE8, W1)
- Y7—Fuel Shutoff Solenoid (SE3, W1)
- Y8—Speed Sense Proportional Solenoid (SE7, W1)

9015
10
7

System Diagrams

- Y9—Arm Regenerative Proportional Solenoid (SE7, W1)
- Y10—Not Used
- Y11—Hand Held Tools Solenoid

CED,OUOE012,123 -19-15MAR99-5/5

SYSTEM FUNCTIONAL SCHEMATIC SECTION LEGEND

NOTE: SE1—Power Circuit

SE1 indicates section number of System Functional Schematic where circuit is located.

Power Circuit indicates circuit name.

- SE1—Power Circuit
- SE2—Starting Circuit
- SE3—Charging and Fuel Shut-Off Circuit
- SE4—Monitor Controller and Display Circuit
- SE5—Monitor Controller and Display Circuit
- SE6—Monitor Controller and Display Circuit
- SE7—Engine and Pump Controller Circuit
- SE8—Engine and Pump Controller Circuit
- SE9—Engine and Pump Controller Circuit
- SE10—Travel Alarm Circuit
- SE11—Windshield Wiper and Washer Circuit
- SE12—Windshield Wiper and Washer Circuit
- SE13—Work and Drive Light Circuit
- SE14—Radio Circuit
- SE15—Accessory Circuit
- SE16—Heater Circuit (Machines Without Air Conditioner)
- SE17—Heater and Air Conditioner Circuit
- SE18—Optional Connector Circuit
- SE19—Overload Alarm And Quick Hitch Circuit


CED,OUOE012,144 -19-19MAR99-1/1

FOLDOUT PAGES 4-34 THRU 4-39 ARE AT REAR OF MANUAL

BLANK

System Diagrams

SYSTEM FUNCTIONAL SCHEMATIC (SE19)



9015
10
15

SE19 OVERLOAD ALARM AND QUICK HITCH CIRCUIT
SYSTEM FUNCTIONAL SCHEMATIC

T120782

T120782 -19-28OCT99


CED,OUOE012,167 -19-19MAR99-1/1

FOLDOUT PAGES 4-41 AND 4-42 ARE AT REAR OF MANUAL

BLANK

System Diagrams

X8
ENGINE AND FRAME
HARNESS TO CAB
HARNESS CONNECTOR
(FRONT VIEW SHOWN)



Y5	PIN 1	BLU/RED	7
Y8	PIN 1	RED/WHT	8
Y6	PIN 1	LGRN/BLK	9
Y9	PIN 1	BLU/ORG	10
M2	PIN 3	ORG	12
Y5	PIN 2	BLU/BLK	20
Y8	PIN 2	RED/YEL	21
Y6	PIN 2	LGRN/RED	22
Y9	PIN 2	BLU/WHT	23
M2	PIN 1	BRN/RED	24
M2	PIN 2	RED	25
M2	PIN 4	YEL	26
B16	PIN 1	BLK	36
B21	PIN 1	BLK/YEL	39
B16	PIN 1	WHT	43
B13	PIN 2	BLK/RED	57
B14	PIN 1	BLK/WHT	58
B22	PIN 3	BLU	64
B17	PIN 2	YEL/BLK	65
B19	PIN 2	RED/GRN	66
B18	PIN 2	GRN/BLK	67
B20	PIN 2	RED/BLK	68
B21	PIN 3	BLK/BLU	69

B21	PIN 2	BLK/PNK	72
B14	PIN 2	ORG/BLK	100
B13	PIN 1	ORG/BLU	101
B17	PIN 1	YEL/BLU	109
B19	PIN 1	WHT	110
B18	PIN 1	WHT/RED	111
B20	PIN 3	YEL/RED	112
B17	PIN 3	BRN/BLU	113
B19	PIN 3	RED/YEL	114
B18	PIN 3	RED/BLU	115
B20	PIN 1	BRN/WHT	116
B22	PIN 1	YEL/BLK	117
B22	PIN 2	BRN/BLU	118
B15	PIN 2	ORG	119
B4	PIN 1	WHT/RED	218
B5	PIN 2	GRN	219
B6	PIN 1	BLU	220
B7		WHT/BLK	221
B1	PIN 1	GRN/BLU	226
B2		WHT/YEL	227
B3	PIN 1	RED/BLU	228
G3	(D+)	BLU/YEL	230
B8	PIN 2	BRN	239

B9		RED/GRN	242
B12	PIN 1	BRN/YEL	245
G3	(GND)	BLK	501
K13	(e)	BLK/WHT	505
K14	(S)	RED/WHT	508
E1		RED/BLU	536
E2	(+)	RED	537
B26		RED/GRN	542
M4	PIN L	PUR	546
H10	PIN B	WHT/RED	831
H10	PIN D	WHT/BLK	833
B15	PIN 1	BLK/GRN	834
K13	(g)	YEL/GRN	835
NOT USED		BLK/RED	839
K15	(G)	RED/BLK	841
Y7	PIN 2	BRN/BLK	844
H10	PIN A	WHT	846
Y1		BLK/YEL	853

X9
ENGINE AND FRAME
HARNESS TO CAB
HARNESS POWER
CONNECTOR



K13	PIN B	WHT	1
F21		RED	2

CONNECTORS -
FRONT VIEW SHOWN


NOTE: PIN NUMBERS ARE
LOCATION REFERENCE NUMBERS
ONLY - THEY ARE NOT
PRINTED ON THE CONNECTOR

ENGINE AND FRAME HARNESS (W1) COMPONENT LOCATION

T121285

T121285 -19-28OCT99

System Diagrams



Engine and Frame Harness Component Location—Detail A

A—Y7 Fuel Shutoff Solenoid

B—W8 Starter to Frame Ground

C—M1 Starter


CED,OUOE012,191 -19-03JUN99-4/4

9015
10
19

T118688B -UN-30NOV98

System Diagrams


ENGINE AND FRAME HARNESS (W1) CONNECTORS, WIRE AND PIN LOCATION



B1
AIR FILTER RESTRICTION SWITCH

1 GRN/BLU

2 BLK



B2
FUEL LEVEL SWITCH

WHT/YEL

E1
WORK LIGHT

RED/BLU

Y1
AIR CONDITIONER
COMPRESSOR CLUTCH

BLK/YEL

B13
BOOM UP
PRESSURE SWITCH

1	ORG/BLU
2	BLK/RED



B5
HYDRAULIC OIL
LEVEL SWITCH

1	BLK
2	GRN

B8
FUEL LEVEL SENSOR

1	BLK
2	BRN



B9
ENGINE COOLANT
TEMPERATURE SENSOR

RED/GRN

F21
BATTERY POWER 40 AMP
FUSIBLE LINK


RED

F22
ALTERNATOR POWER 60 AMP
FUSIBLE LINK

WHT (1.5 MM)

F23
FUEL SHUTOFF 40 AMP
FUSIBLE LINK

WHT (2 MM)



B3
ENGINE COOLANT
TEMPERATURE SWITCH


1	RED/BLU
2	BLK

B4
ENGINE OIL
PRESSURE SWITCH

1	WHT/RED
2	BLK

B12
CHARGE AIR
TEMPERATURE SWITCH

1	BRN/YEL
2	BLK



B6
ENGINE COOLANT LEVEL SWITCH

1	BLU
2	BLK



B7
ENGINE OIL LEVEL SWITCH

WHT/BLK



B14
DIG PRESSURE SWITCH

1	BLK/WHT
2	ORG/BLK

B15
PROPEL PRESSURE SWITCH

1	BLK/GRN
2	ORG

B16
ENGINE SPEED (N) SENSOR

1	WHT
2	BLK

CONNECTORS FOR ENGINE AND FRAME HARNESS (W1)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)


T118102

Continued on next page

CED, TX02661, 241 -19-04NOV98-1/4


T118102 -19-24NOV98

System Diagrams



B17
ENGINE CONTROL (EC) SENSOR

1	YEL/BLU
2	YEL/BLK
3	BRN/BLU




B18
REAR PUMP
PRESSURE SENSOR

1	WHT/RED
2	GRN/BLK
3	RED/BLU

B19
FRONT PUMP
PRESSURE SENSOR

1	WHT
2	RED/GRN
3	RED/YEL



B20
ARM IN
PRESSURE SENSOR


1	YEL/RED
2	RED/BLK
3	BRN/WHT

B21
REAR PUMP CONTROL
PRESSURE SENSOR

1	BLK/YEL
2	BLK/BLU
3	BLK/PNK

B22
FRONT PUMP CONTROL
PRESSURE SENSOR

1	YEL/BLK
2	BLU
3	BRN/BLU



B25
HIGH NOTE HORN

RED/GRN

B26
LOW NOTE HORN

RED/GRN



E1
WORK LIGHT


RED/BLU

E2
DRIVE LIGHT

+ RED
- BLK

Y1
AIR CONDITIONER COMPRESSOR CLUTCH

BLK/YEL




G3
ALTERNATOR

B+ WHT (1.5MM)


D+ BLU/YEL

E BLK



H10
TRAVEL ALARM

A WHT
B WHT/RED
C WHT/BLK
D BLK




K13
STARTER RELAY

B WHT (1.5MM)
G BLK
e BLK/WHT
g YEL/GRN

K15
FUEL SHUTOFF RELAY

B WHT (2MM)
G RED/BLK
e BLK
g BLK/WHT



K14
BATTERY RELAY

S RED/WHT

E BLK


CONNECTORS FOR ENGINE AND FRAME HARNESS (W1)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)

T118103

9015
10
21


T118103 -19-17NOV98

System Diagrams




M1
STARTER

1	BLK
---	-----




X9
ENGINE AND FRAME HARNESS
TO CAB HARNESS
POWER CONNECTOR

1	WHT
2	RED




Y7
FUEL SHUTOFF SOLENOID

1	RED/BLK
2	BRN/BLK
3	BLK



M2
ENGINE CONTROL (EC) MOTOR

1	BRN/RED
2	RED
3	ORG
4	YEL




Y5
POWER BOOST
PROPORTIONAL SOLENOID

1	BLU/RED
2	BLU/BLK



W6
ENGINE TO FRAME GROUND

1	BLK
---	-----




M4
WINDSHIELD WASHER MOTOR

LB	BLK
L	PUR

Y6
PROPEL SPEED
CHANGE PROPORTIONAL SOLENOID

1	LGRN/BLK
2	LGRN/RED



V11
BATTERY RELAY COIL
SUPPRESSION DIODE

A	BLK
K	RED/WHT

Y8
SPEED SENSE
PROPORTIONAL SOLENOID

1	RED/WHT
2	RED/YEL

Y9
ARM REGENERATIVE
PROPORTIONAL SOLENOID

1	BLU/ORG
2	BLU/WHT

CONNECTORS FOR ENGINE AND FRAME HARNESS (W1)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)

T118104


T118104 -19-17NOV98

Continued on next page

CED, TX02661,241 -19-04NOV98-3/4


System Diagrams

X26
REAR LIGHT SWITCH
HARNESS TO REAR LIGHT
HARNESS CONNECTOR




1	WHT
2	BLK

E9
LEFT REAR LIGHT
CONNECTOR




1	BLK
2	WHT

E7
LEFT CAB DRIVE
LIGHT CONNECTOR




1	BLK
2	WHT

E10
RIGHT REAR LIGHT
CONNECTOR




1	BLK
2	WHT

E8
RIGHT CAB DRIVE
LIGHT CONNECTOR



1	BLK
2	WHT

G5
24-VOLT SLAVE
RECEPTACLE CONNECTOR



1	RED
2	GROUND STRAP (SILVER)

CONNECTORS FOR ENGINE AND FRAME HARNESS (W1)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)

T120784

9015
10
23


T120784 -19-28OCT99

FOLDOUT PAGES 4-49 THRU 4-51 ARE AT REAR OF MANUAL

System Diagrams


T120801 -19-28OCT99

H9
OVERLOAD ALARM
SWITCH CONNECTOR




1	BLK
2	WHT

S20
REAR LIGHTS
SWITCH CONNECTOR



A	BLK
B	WHT

X26
REAR LIGHT SWITCH
HARNESS TO REAR LIGHT
HARNESS CONNECTOR



1	WHT
2	BLK


CONNECTORS FOR CAB HARNESS (W2)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)

T120801

System Diagrams

CAB HARNESS (W2) COMPONENT LOCATION—DETAIL B (FUSE BLOCK)

- F1 RADIO AND MONITOR CONTROLLER BACKUP 5-AMP FUSE (MARKED BACKUP)
- F2 ENGINE AND PUMP CONTROLLER 10-AMP FUSE (MARKED CONTROLLER)
- F3 ENGINE CONTROL (EC) MOTOR 10-AMP FUSE (MARKED E.C. MOTOR)
- F4 SOLENOID 5-AMP FUSE (MARKED SOLENOID)
- F5 POWER ON 10-AMP FUSE (MARKED POW. ON)
- F6 MONITOR CONTROLLER AND DISPLAY 5-AMP FUSE (MARKED SW. BOX)
- F7 SWITCHED POWER 5-AMP FUSE (MARKED OPTION 1)
- F8 SWITCHED POWER 10-AMP FUSE (MARKED OPTION 2)
- F9 BATTERY POWER 5-AMP FUSE (MARKED OPTION 3)
- F10 TRAVEL ALARM 5-AMP FUSE (MARKED TRAVEL)



- F11 WORK AND DRIVE LIGHTS 20-AMP FUSE (MARKED LAMP)
- F12 WINDSHIELD WIPER 10-AMP FUSE (MARKED HEATER)
- F13 BLOWER MOTOR 20-AMP FUSE (MARKED HEATER)
- F14 AIR CONDITIONER CONTROLLER AND RELAYS 5-AMP FUSE (MARKED AIR CON)
- F15 HORN 10-AMP FUSE (MARKED HORN)
- F16 RADIO 5-AMP FUSE (MARKED RADIO)
- F17 LIGHTER 10-AMP FUSE (MARKED LIGHTER)
- F18 DOME LIGHT 5-AMP FUSE (MARKED ROOM LAMP)
- F19 AUXILIARY 10-AMP FUSE (MARKED AUXILIARY)
- F20 START AID 20-AMP FUSE (MARKED START AID)

NOTE: MARKED NAME IN PARENTHESIS INDICATES NAME ON FUSE BOX COVER

CAB HARNESS COMPONENT LOCATION (DETAIL B)(FUSE BLOCK)

T120799

T120799 -19-28OCT99

CED.OUTX782.1 -19-17NOV98-1/1

9015
10
28

System Diagrams

CAB HARNESS (W2) CONNECTORS, WIRE AND PIN LOCATION

A1
 RADIO
 INCLUDES:
 B24 LEFT SPEAKER
 W4 RADIO ANTENNA

1	2	0	3	4
5	6	7	8	9

1	LGRN/YEL
2	RED
3	BRN/RED
4	PLUG
5	LGRN/RED
6	LGRN/BLK
7	PLUG
8	BLK
9	GRN/RED
10	RED

A2
 ENGINE PUMP
 AND CONTROLLER
 INCLUDES:
 X13, X14, X15

NOTE: PIN NUMBERS ARE
 LOCATION REFERENCE NUMBERS
 ONLY - THEY ARE NOT
 PRINTED ON THE CONNECTOR

A1	A2	A3	A4	A5	A6	A7	A8	A9	A10	A11	A12	A13
A14	A15	A16	A17	A18	A19	A20	A21	A22	A23	A24	A25	A26

X13
 ENGINE AND PUMP CONTROLLER
 CONNECTOR (26-PIN)

A1	BRN
A2	PLUG
A3	PLUG
A4	PLUG
A5	PLUG
A6	PLUG
A7	BLU/RED
A8	RED/WHT
A9	LGRN/BLK
A10	BLU/ORG
A11	BLK
A12	ORG
A13	BRN/WHT

A14	BLK
A15	PLUG
A16	PLUG
A17	PLUG
A18	PLUG
A19	PLUG
A20	BLU/BLK
A21	RED/YEL
A22	LGRN/RED
A23	BLU/WHT
A24	BRN/RED
A25	RED
A26	YEL

B1	B2	B3	B4	B5	B6	B7	B8
B9	B10	B11	B12	B13	B14	B15	B16

X14
 ENGINE AND PUMP CONTROLLER
 CONNECTOR (16-PIN)

B1	PLUG
B2	GRN
B3	PLUG
B4	WHT/PUR
B5	WHT/GRN
B6	BLK
B7	BRN/BLK
B8	BLK/GRN
B9	BLK/YEL
B10	GRN/RED
B11	ORG/BLU
B12	BLK/RED
B13	WHT
B14	PLUG
B15	RED/BLU
B16	BLK/BLU

D1	D2	D3	D4	D5	D6	D7	D8	D9	D10	D11
D12	D13	D14	D15	D16	D17	D18	D19	D20	D21	D22

X15
 ENGINE AND PUMP CONTROLLER
 CONNECTOR (22-PIN)

D1	BRN/YEL
D2	BRN/YEL
D3	GRY/BLU
D4	GRY/RED
D5	WHT
D6	ORG/BLK
D7	BLK/RED
D8	BLK/WHT
D9	WHT/BLK
D10	YEL/GRN
D11	PLUG

D12	BLK
D13	BLK
D14	BLU
D15	YEL/BLK
D16	RED/GRN
D17	GRN/BLK
D18	RED/BLK
D19	BLK/BLU
D20	WHT/BLU
D21	WHT/RED
D22	BLK/PNK

CONNECTORS FOR CAB HARNESS (W2)
 (HARNESS CONNECTORS - FRONT VIEW SHOWN)

T118464

Continued on next page


CED, TX02661, 244 -19-04NOV98-1/6

9015
 10
 29


T118464 -19-17NOV98

System Diagrams

A4
ENGINE MODE AND RPM CONTROL UNIT
INCLUDES:
E5 ENGINE RPM DIAL BACKLIGHT
R10 ENGINE RPM DIAL
S11 ECONOMY (E) MODE SWITCH
S12 HIGH POWER (HP) MODE SWITCH




1	YEL/BLU
2	YEL/WHT
3	YEL/RED
4	YEL/WHT
5	BLK/YEL
6	WHT/RED
7	BLK/PNK
8	RED
9	BLK
10	PLUG



B23
RIGHT SPEAKER
(SAME AS X7)


-	LGRN/BLK
+	LGRN/WHT

B24
LEFT SPEAKER
SEE A1 RADIO



E5
ENGINE SPEED DIAL BACKLIGHT
SEE A4 ENGINE SPEED CONTROL UNIT

FUSE BLOCK



F1
RADIO AND MONITOR CONTROLLER
5 AMP FUSE

1	GRN/RED
11	RED

F2
ENGINE AND PUMP CONTROLLER
10 AMP FUSE

2	BRN/YEL
11	RED

F3
ENGINE CONTROL (EC) MOTOR
10 AMP FUSE

3	BRN/WHT
11	RED

F4
SOLENOID
5 AMP FUSE

4	BRN
12	WHT (5 MM)

F5
POWER ON
10 AMP FUSE

5	BRN/BLK
12	RED/BLK

F6
MONITOR CONTROLLER AND DISPLAY
5 AMP FUSE

6	YEL/GRN
14	WHT (5 MM)

F7
SWITCHED POWER
5 AMP FUSE

7	WHT/RED
14	WHT (5 MM)

F8
SWITCHED POWER
10 AMP FUSE

8	RED/YEL
14	WHT (5 MM)

CONNECTORS FOR CAB HARNESS (W2)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)

T118465

Continued on next page

CED,TX02661,244 -19-04NOV98-2/6

T118465 -19-14DEC98

System Diagrams

F9
BATTERY POWER
5 AMP
FUSE

9	WHT
15	RED

F10
TRAVEL
ALARM
5 AMP
FUSE

10	WHT/RED
16	WHT (5 MM)

F11
WORK AND
DRIVE LIGHTS
20 AMP
FUSE

22	RED/GRN
17	WHT (5 MM)

F12
WINDSHIELD
WIPER
10 AMP
FUSE

23	BLU/YEL
17	WHT (5 MM)

F13
BLOWER MOTOR
20 AMP
FUSE

24	BRN
17	WHT (5 MM)

F14
AIR CONDITONER
CONTROLLER AND RELAYS
5 AMP
FUSE

25	WHT/YEL
18	WHT (5 MM)

F15
HORN
10 AMP
FUSES

26	RED/WHT
19	RED/WHT

F16
RADIO
5 AMP
FUSE

27	BRN/RED
19	RED/WHT

F17
LIGHTER
10 AMP
FUSE

28	BRN
19	RED/WHT

F18
DOME LIGHT
5 AMP
FUSE

29	RED/WHT
20	RED/WHT

F19
AUXILIARY
10 AMP
FUSE


30	RED
20	RED/WHT

F20
START AID
20 AMP
FUSE

31	RED/BLU
21	WHT

M5
HEATER BLOWER MOTOR
(WITHOUT AIR CONDITIONER)
SEE S4 HEATER BLOWER
MOTOR SWITCH

R2
HEATER BLOWER MOTOR
DROPPING RESISTOR BLOCK
WITHOUT AIR CONDITIONER)
SEE S4 HEATER BLOWER
MOTOR SWITCH




R6
ALTERNATOR
EXCITATION RESISTOR

1	RED/WHT
2	BLU/YEL


X6
AUXILIARY CONNECTOR

+	RED
-	BLK



S1
KEY SWITCH

1	RED
2	PLUG
3	PLUG
4	RED/WHT
5	RED/BLK
6	BLK/WHT



S2
HORN SWITCH

1	PNK
2	BLK

S19
POWER BOOST SWITCH

S	WHT/GRN
GND	BLK

CONNECTORS FOR CAB HARNESS (W2)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)


T120787

9015
10
31

T120787 -19-28OCT99

System Diagrams

S3
DOME LIGHT SWITCH
SEE E3 CAB DOME LIGHT




S4
HEATER BLOWER MOTOR SWITCH
(WITHOUT AIR CONDITIONER)
INCLUDES:
M5 HEATER BLOWER MOTOR
R2 HEATER BLOWER MOTOR DROPPING RESISTOR BLOCK
(WITHOUT AIR CONDITIONER)

-	BLK
+	BRN

S11
ECONOMY (E) MODE SWITCH


S12
HIGH POWER (HP) MODE SWITCH

SEE A4 ENGINE SPEED CONTROL UNIT




S14
WINDSHIELD WIPER ENABLE SWITCH

1	PNK
2	BLK




S16
LEARNING SWITCH

1	WHT/GRN
2	BLK
3	PLUG
4	PLUG
5	PLUG
6	PLUG



S17
TRAVEL ALARM CANCEL SWITCH

1	WHT
2	BLK



V1
START AID DIODE
(NOT USED - FIELD OPTION)

A	BLK
K	BLK/RED

V2
ALTERNATOR SHUT DOWN RELAY ISOLATION DIODE

A	RED/BLK
K	RED/WHT

V3
AUXILIARY POWER FUSE (F19) SUPPRESSION DIODE

A	BLK
K	RED

V4
PROPEL AUTO IDLE RELAY ISOLATION DIODE

A	YEL
K	WHT/BLK

V8
FUEL SHUTOFF SOLENOID HOLD-IN COIL SUPPRESSION DIODE

A	BLK
K	BRN/BLK

V9
START RELAY COIL SUPPRESSION DIODE

A	YEL/GRN
K	BLK/WHT

V10
FUEL SHUTOFF SOLENOID PULL-IN COIL SUPPRESSION DIODE

A	BLK
K	RED/BLK

W4
RADIO ANTENNA
SEE A1 RADIO




W7
CAB TO FRAME GROUND
BLK

CONNECTORS FOR CAB HARNESS (W2)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)

T118493

T118493 -19-06JAN99

System Diagrams



X1
DIAGNOSTIC CONNECTOR


1	BLK/BLU
2	BLK
3	BLK/GRN
4	RED/BLU

X2
LEARNING SWITCH CONNECTOR
SEE S16 LEARNING SWITCH



X3
ATTACHMENT PRESSURE
SWITCH CONNECTOR

1	GRN
2	GRN/RED
3	YEL/GRN
4	PLUG
5	PLUG
6	PLUG
7	PLUG
8	PLUG
9	PLUG
10	BLK




X4
ACCEL CONNECTOR

1	BLK/PNK
2	WHT/BLU
3	YEL/GRN
4	PLUG

X4
ACCEL CONNECTOR
(OTHER HALF)

1	BLK/PNK
2	BLK/PNK
3	PLUG
4	PLUG



X5
OPTIONAL CONNECTOR

1	WHT/RED
2	RED/YEL
3	WHT
4	RED
5	RED/BLU
6	BLK

X7
OPTIONAL RIGHT SPEAKER
CONNECTOR

SEE B23 RIGHT SPEAKER
CONNECTOR

X13
ENGINE AND PUMP CONTROLLER
CONNECTOR
(26-PIN)

X14
ENGINE AND PUMP CONTROLLER
CONNECTOR
(16-PIN)

X15
ENGINE AND PUMP CONTROLLER
CONNECTOR
(22-PIN)

SEE A2 ENGINE AND PUMP
CONTROLLER

CONNECTORS FOR CAB HARNESS (W2)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)


T118494

9015
10
33

T118494 -19-17NOV98


System Diagrams

K16
OVERLOAD ALARM
RELAY CONNECTOR




1	RED/BRN
2	BLU
3	NOT USED
4	BRN
5	BLK

B31
HYDRAULIC OIL
TEMPERATURE SWITCH
CONNECTOR




1	YEL
2	RED

B30
HYDRAULIC OIL
FILTER RESTRICTION
SWITCH CONNECTOR




1	YEL
---	-----

B32
OVERLOAD ALARM
PROXIMITY SWITCH
CONNECTOR




1	BLU
2	BLK
3	BRN

B33
OVERLOAD ALARM
PRESSURE SWITCH
CONNECTOR




1	BLU
2	NOT USED
3	BRN
4	BLK

E1
LEFT WORK
LIGHT CONNECTOR



1	BLK
2	WHT

E6
RIGHT WORK
LIGHT CONNECTOR



1	BLK
2	WHT

CONNECTORS FOR ENGINE AND FRAME HARNESS (W1)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)

T120783


T120783 -19-28OCT99

9015
10
34

FOLDOUT PAGE 4-60 IS AT REAR OF MANUAL

System Diagrams

MONITOR AND RELAY HARNESS (W3) COMPONENT LOCATION—DETAIL A (MONITOR CONTROLLER CONNECTORS)



MONITOR AND RELAY HARNESS (W3) COMPONENT LOCATION
(DETAIL A - MONITOR CONTROLLER CONNECTORS)

T120786


T120786 -19-28OCT99

CED,TX02661,246 -19-04NOV98-1/1

9015
10
36

System Diagrams

MONITOR AND RELAY HARNESS (W3) COMPONENT LOCATION—DETAIL B (MONITOR CONTROLLER INDICATORS)



9015
10
37

MONITOR AND RELAY HARNESS (W3) COMPONENT LOCATION (DETAIL B - MONITOR CONTROLLER INDICATORS)

T120576

CE0,OUOE012,152 -19-19MAR99-1/1


T120576 -19-28OCT99

System Diagrams

MONITOR AND RELAY HARNESS (W3) CONNECTORS, WIRE AND PIN LOCATION


A5
MONITOR CONTROLLER
AND DISPLAY
(MADE UP OF X10, X11,
AND X12)

SEE MONITOR AND RELAY
HARNESS (W3)
COMPONENT LOCATION
DETAIL A



G4
24V POWER PLUG

1	BLK
2	BRN



K1
ALTERNATOR SHUT DOWN RELAY
(MARKED R1)

1	RED
2	RED/YEL
3	RED
4	PLUG
5	RED/WHT

K2
WINDSHIELD WASHER RELAY
(MARKED R2)

1	BLU/YEL
2	YEL/BLK
3	BLU/YEL
4	PLUG
5	PUR

K3
WORK LIGHT RELAY
(MARKED R3)

1	RED/GRN
2	RED/WHT
3	RED/GRN
4	PLUG
5	RED/BLU

K4
DRIVE LIGHT RELAY
(MARKED R4)

1	RED/GRN
2	RED/BLK
3	RED/GRN
4	PLUG
5	RED

K5
HORN RELAY
(MARKED R5)

1	RED/WHT
2	PNK
3	RED/WHT
4	PLUG
5	RED/GRN

K6
WINDSHIELD WIPER RELAY
(MOTOR GROUND AND INTERMITTENT)
(MARKED R6)

1	BLU/YEL
2	BLU/GRN
3	LGRN/WHT
4	BLU/BLK
5	BLK

K7
WINDSHIELD WIPER RELAY
(WIPER RUN)
(MARKED R7)

1	BLU/YEL
2	BRN/WHT
3	BLU/WHT
4	BLK/RED
5	BLU/YEL

K8
WINDSHIELD WIPER RELAY
(HOLD FOR PARK)
(MARKED R8)

1	BLU/YEL
2	BRN/WHT
3	BLU/RED
4	PLUG
5	BRN/WHT

K9
WINDSHIELD WIPER RELAY
(MOTOR GROUND FOR PARK)
(MARKED R9)

1	BLU/YEL
2	GRN/WHT
3	BLK/RED
4	PLUG
5	BLK

K10
PROPEL AUTO IDLE RELAY
(MARKED R10)

1	WHT/RED
2	YEL
3	WHT/BLK
4	PLUG
5	BLK

K11
STARTER PROTECTION RELAY
(MARKED R11)

1	RED
2	RED/YEL
3	YEL/GRN
4	BLK
5	PLUG

K12
START AID RELAY
(MARKED R12)
(NOT USED - FIELD OPTION)

CONNECTORS FOR MONITOR AND RELAY HARNESS (W3)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)

T118352

Continued on next page

CED.OUOE012,153 -19-19MAR99-1/2


T118352 -19-17NOV98

System Diagrams




M3
WINDSHIELD WIPER MOTOR

E	LGRN/WHT
L	BLU/WHT
S	BLU/BLK
B	BLU/YEL



X25
OPTIONAL CONNECTOR
WHT/BLK



V5
WINDSHIELD WIPER RELAY
ISOLATION DIODE


A	BLU/RED
K	BLU/BLK

V6
WINDSHIELD WIPER MOTOR
SUPPRESSION DIODE

A	BLK
K	LGRN/WHT

V7
WINDSHIELD WIPER MOTOR
SUPPRESSION DIODE

A	BLK
K	BLU/WHT



X24
OPTIONAL CONNECTOR

1	GRN/BLK
2	GRY

CONNECTORS FOR MONITOR AND RELAY HARNESS (W3)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)

T118497

9015
10
39

T118497 -19-17NOV98

System Diagrams

**AIR CONDITIONER HARNESS (W9)
COMPONENT LOCATION—SEE GROUP
9031-15**

CED, TX02661,249 -19-04NOV98-1/1

**AIR CONDITIONER HARNESS (W9)
CONNECTORS, WIRE AND PIN LOCATION—
SEE GROUP 9031-15**

CED, TX02661,250 -19-04NOV98-1/1

9015
10
40

Group 15 Sub-System Diagnostics

POWER CIRCUIT OPERATIONAL INFORMATION

The following conditions must be met for the circuits to function:

With key switch S1 OFF, voltage must be present at the following:

- Battery positive terminals
- Key switch S1 terminal BAT
- Battery relay K14 terminal B
- Radio and monitor controller backup 5-amp fuse F1
- Engine and pump controller 10-amp fuse F2
- Engine control (EC) motor 10-amp fuse F3
- Battery power 5-amp fuse F9
- Battery power 40-amp fusible link F21
- Alternator shut down relay K1 terminals 1 and 3
- Starter protection relay K11 terminal 1

With key switch S1 in ACC position, voltage must be present at the following:

- Key switch S1 terminal ACC
- Horn 10-amp fuse F15
- Radio 5-amp fuse F16
- Lighter 10-amp fuse F17

- Dome light 5-amp fuse F18
- Auxiliary 10-amp fuse F19

With key switch S1 ON, voltage must be present at the following:

- Alternator excitation resistor R6
- Key switch S1 terminal M
- Battery relay K14 terminal S and A
- Alternator power 60-amp fusible link F22
- Starter motor terminal C
- Solenoid 5-amp fuse F4
- Power On 10-amp fuse F5
- Monitor controller and display 5-amp fuse F6
- Switched power 5-amp fuse F7
- Switched power 10-amp fuse F8
- Travel alarm 5-amp fuse F10
- Work and drive lights 20-amp fuse F11
- Windshield wiper 10-amp fuse F12
- Blower motor 20-amp fuse F13
- Air conditioner controller and relays 5-amp fuse F14
- Start Aid 20-amp fuse F20
- Fuel shutoff 40-amp fusible link F23

9015
15
1

*Sub-System Diagnostics***POWER CIRCUIT THEORY OF OPERATION**

The power circuit includes batteries, key switch, battery relay, battery relay fuse, battery relay diode and all other fuses.

With key switch OFF, battery power is available at terminal BAT of key switch S1, terminals 1 and 3 of alternator shut down relay K1, terminal 1 of starter protection relay K11, and through battery power 40-amp fusible link F21 to terminal B of battery relay K14. Battery power is also applied to radio and monitor controller backup 5-amp fuse F1, engine and pump controller 10-amp fuse F2, and engine control (EC) motor 10-amp fuse F3 and battery power 5 amp fuse F9.

With key switch turned to ACC, battery power is available at horn 10-amp fuse F15, lighter 10-amp fuse

F17, dome light 5-amp fuse F18, auxiliary 10-amp fuse F19 and radio 5-amp fuse F16.

With key switch turned to ON, battery relay K14 is energized by power from key switch S1 terminal M to battery relay terminal S. Operating power from terminal A of the battery relay is applied to starter motor M1 terminal B, fuel shutoff 40-amp fusible link F23, and through alternator power 60-amp fusible link F22 to fuses F4, F6, F7, F8, F10, F11, F12, F13, F14 and F20. Operating power is also applied from key switch S1 terminal M to alternator excitation resistor R6 and power on 10-amp fuse F5.

Connection to an external battery source is provided by 24-volt slave receptacle G5.

CED,OUOE012,129 -19-15MAR99-1/1

FOLDOUT PAGE 4-68 IS AT REAR OF MANUAL

Sub-System Diagnostics


❶ POWER CIRCUIT DIAGNOSTIC PROCEDURES

IMPORTANT: Do not disconnect electrical connectors while the engine is running. Damage to Engine and Pump Controller or other components may result. Disconnect connectors only when instructed during a test or check.

---1/1

9015
15
4

**BATTERY (G1, G2)
VOLTAGE CHECK**



T7487AF -UN-20MAR91

Measure battery voltage by connecting a voltmeter to (-) negative battery terminal grounded to frame and (+) positive battery terminal connected to machine harness.


Is 24 to 28 volts measured?

YES: Batteries are OK. Go to next check.

NO: Batteries are undercharged. Charge batteries.

---1/1

**BATTERY POWER 40
AMP FUSIBLE LINK (F21)
CHECK**



T109319 -UN-28APR97

Disconnect fusible link from battery relay.

Connect ohmmeter to both ends of fusible link.

Is continuity measured?


YES: Fusible link is OK. Check wiring harness.

NO: Fusible link has failed. Replace fusible link.

---1/1

Sub-System Diagnostics

**KEY SWITCH (S1)
CHECK**



T8357AK -UN-09NOV94

- 1—B Terminal
- 2—G1 Terminal
- 3—G2 Terminal
- 4—ACC Terminal
- 5—M Terminal
- 6—ST Terminal


Remove harness from key switch.

Turn key switch to ACC.

Is continuity measured between key switch terminals 1 and 4?

YES: Go to next step.

NO: Key switch has failed if continuity is not measured or continuity is measured between other terminals. Replace.



T8357AL -UN-09NOV94

- 1—B Terminal
- 2—G1 Terminal
- 3—G2 Terminal
- 4—ACC Terminal
- 5—M Terminal
- 6—ST Terminal

Remove harness from key switch.


Turn key switch ON.

Is continuity measured between key switch terminals 1 and 4, and terminals 1 and 5?

YES: Go to next step.

NO: Key switch has failed if continuity is not measured or continuity is measured between other terminals. Replace.

9015
15
5



T8357AM -UN-02DEC98

- 1—B Terminal
- 2—G1 Terminal
- 3—G2 Terminal
- 4—ACC Terminal
- 5—M Terminal
- 6—ST Terminal

Remove harness from key switch.


Turn key switch to START.


Is continuity measured between key switch terminals 1 and 5, and terminals 1 and 6?

YES: Key switch is OK.

NO: Key switch has failed if continuity is not measured or continuity is measured between other terminals. Replace.


Sub-System Diagnostics

<p>BATTERY RELAY (K14) CHECK</p>	 <p>T8182AK(CV) T8182AK -UN-03MAR94</p> <p>Disconnect harness from relay.</p> <p>Connect 24 volts to small terminal S and ground small terminal E.</p> <p>Does relay click?</p> <p>Connect ohmmeter to large terminals A and B.</p> <p>Is continuity measured?</p>	<p>YES: Relay is OK. Check wiring harness.</p> <p>NO: Relay has failed. Replace relay.</p> <p style="text-align: right;">-- -1/1</p>
---	--	--

<p>9015 15 6</p> <p>BATTERY RELAY COIL SUPPRESSION DIODE (V11) CHECK</p>	<p><i>NOTE: A diode can fail in two modes, either shorted or open. Continuity will be measured in one direction only in a serviceable diode. Use "diode checking mode" on meter when checking continuity.</i></p>  <p>T118385 T118385 -UN-21NOV98</p> <p>Remove diode from connector.</p> <p>Connect an ohmmeter to diode terminals.</p> <p>Is continuity measured?</p> <p>Reverse ohmmeter probes.</p> <p>Is continuity measured?</p>	<p>YES: If continuity is measured in both checks, diode has failed in a shorted mode. Replace.</p> <p>NO: If continuity is NOT measured in either check, diode has failed in an open mode. Replace.</p> <p>NO: If continuity is measured in one check and not the other, diode is OK.</p> <p style="text-align: right;">-- -1/1</p>
---	--	--

Sub-System Diagnostics

FUSE CHECK



T7468AF -UN-14MAR91

Remove cover from fuse block.

Turn key switch ON.

Connect black (-) probe of multimeter to screw head (ground) in console.

Set multimeter to measure 24 volts.

Connect multimeter red (+) probe to the outside slot in each fuse.

Is 24 volts measured on each fuse?

YES: Fuse is OK

NO: Replace fuse.

9015
15
7

*Sub-System Diagnostics***CHARGING CIRCUIT OPERATIONAL INFORMATION**

The following conditions must be met for the circuit to function:

- Key switch ON
- Voltage present at alternator G3 terminals B+ and D+
- Engine running

CED,OUOE012,12 -19-26OCT98-1/1

CHARGING CIRCUIT THEORY OF OPERATION

The charging circuit includes batteries, key switch, alternator shut down relay, alternator excitation resistor, alternator shutdown relay and isolation diode, monitor controller and display.

With key switch S1 ON, battery power is applied through alternator power 60-amp fusible link F22 to terminal B+ of alternator G3. Alternator excitation power is applied from key switch S3 terminal M through alternator shut down relay isolation diode V2 and alternator excitation resistor R6 to alternator terminal D+. The excitation voltage is monitored by controller and display monitor A5 at terminal 42.

With the engine running and the charging circuit functioning properly, the voltage at alternator terminal D+ is greater than 10 volts, therefore, alternator voltage indicator light H18 and monitor controller and display alarm H8 are off. Output current from alternator terminal B charges the batteries as needed and provides power to the machine circuits. If the voltage

at alternator terminal D+ drops below 6 volts, as a result of a charging circuit failure or the engine not running, the monitor controller will turn on the alternator voltage indicator light and sound the display alarm.


Once the monitor controller senses that the engine is running (voltage at alternator terminal D+ is greater than 10 volts), monitor controller and display terminal 18 is grounded. This provides a ground path for alternator shutdown relay K1, energizing the relay. With relay K1 energized, battery power is applied through contacts 3 and 5 to alternator excitation resistor R6. This ensures that power to the alternator excitation circuit (and the alternator voltage output) is maintained as long as the engine is running, even if the key switch is turned to OFF or ACC momentarily.

Isolation diode V2 isolates the battery power at terminal 5 of relay K1 from the key switch ON power circuits.

CED,OUOE012,28 -19-02NOV98-1/1

Sub-System Diagnostics

CHARGING CIRCUIT SCHEMATIC



9015
15
9


T120579

CHARGING CIRCUIT

T120579 -19-28OCT99

Sub-System Diagnostics

ALTERNATOR THEORY OF OPERATION



T118584

T118584 -19-21NOV98

- | | | | |
|-------------------|----------------------|----------------------------------|-------------------|
| A—Alternator | G—D+ Terminal | L—External Ground Terminal | O—Battery |
| B—Internal Ground | H—B+ Terminal | M—Rotor | P—Key Switch |
| C—Negative Diodes | I—Noise Filter | N—Alternator Excitation Resistor | Q—Display Monitor |
| D—Exciter Diodes | J—Excitation Winding | R—Brushes | S—Sense Circuit |
| E—Stator Windings | K—Regulator | | |
| F—Positive Diodes | | | |

The alternator has three basic stages for proper operation. The operating principles are as follows.

PRE-EXCITATION STAGE

When key switch (P) is turned to ON, battery power flows through the alternator excitation resistor (N) to terminal D+ (G) on alternator, excitation winding (J), through regulator (K) and to internal ground (B).

EXCITATION STAGE

During alternator start (as the engine speeds up from 0 to idle) current supplied by the alternator excitation

resistor to the field coil of the rotor produces a magnetic field which induces current in the three-phase winding of the stator (E). The alternator reaches cut-in RPM when the induced current is large enough to produce voltage equal to the battery voltage plus 1.0 volt. At this time, some current from the stator is rectified by the exciter diodes (D) (producing battery voltage at the B+ terminal (G) and is supplied to the carbon brushes and slip rings of the excitation winding, strengthening the magnetic field in the excitation winding. This in turn will increase the stator voltage. This will occur continuously until the alternator (A) is fully excited and the alternator regulated voltage is reached.

Continued on next page

CED,OUOE012,13 -19-27OCT98-1/2

9015
15
10

Sub-System Diagnostics

NORMAL OPERATION

The alternating current induced in the stator winding (E) is rectified by the positive and negative diodes (F and C) and delivered to the battery and current consuming accessories. The currents in the stator winding (E) are constantly changing magnitude and direction. However, current flowing to the battery and accessories always maintains the same direction. This is because no matter what position the rotor (M) is in, all the diodes are simultaneously involved in the

process of rectification. The regulator (K) measures the B+ voltage (H) and compares it to an internal reference. When the B+ voltage (H) starts to rise above the reference voltage, the regulator (K) switches off the field current. When the B voltage (H) starts to fall below the reference voltage the regulator (K) switches on the field current. The regulator (K) switches the field on and off several thousand times a second in response to the current load placed on the alternator output and the engine RPM.

9015
15
11

CED,OUOE012,13 -19-27OCT98-2/2


🔧 CHARGING CIRCUIT DIAGNOSTIC PROCEDURES

IMPORTANT: Do not disconnect electrical connectors while the engine is running. Damage to Engine and Pump Controller or other components may result. Disconnect connectors only when instructed during a test or check.

NOTE: For a problem that cannot be identified using the diagnostic procedures, check the wiring harnesses and diodes in the circuits for shorts and opens.

--1/1

**ALTERNATOR (G3)
OUTPUT CHECK**



T6569AZ -UN-23AUG93

Key switch OFF.

With voltmeter connected from battery (+) terminal to vehicle ground, measure and record battery voltage. 24 - 25.5 volts is normal.

Start and run engine at 1500 rpm, and check battery voltage.



Does battery voltage increase to 27.4 - 28.4 volts?

YES: Alternator is OK.


NO: Repair alternator.

--1/1

Sub-System Diagnostics

<p>ALTERNATOR VOLTAGE INDICATOR LIGHT (H18) CHECK</p>	 <p>B+—Alternator Output D+—Alternator Excitation</p> <p>Turn key switch ON.</p> <p>Engine OFF.</p> <p>Is alternator voltage indicator light on?</p> <p>T8322AC -UN-10OCT94</p>	<p>YES: Go to next step.</p> <p>NO: Go to next check.</p>
<p>9015 15 12</p>	 <p>Start engine.</p> <p>Does alternator voltage indicator light go off.</p> <p>T6768CR -UN-18OCT88</p>	<p>YES: Alternator voltage indicator light and harness are OK.</p> <p>NO: Check alternator harness for short circuit between alternator and monitor controller. Also check alternator output.</p>

-- -1/1


<p>ALTERNATOR VOLTAGE INDICATOR LIGHT HARNESS CHECK</p>	 <p>T118386 T118386 -UN-21NOV98</p> <p>Key switch OFF.</p> <p>Disconnect 20-pin harness connector from monitor controller and display.</p> <p>Measure continuity from alternator terminal D+ to pin 42 in harness side of 20-pin monitor controller and display connector.</p> <p>Is continuity measured?</p>	<p>YES: Check indicator lamp.</p> <p>NO: Harness has failed. Repair.</p>
--	--	--

-- -1/1

Sub-System Diagnostics

**ALTERNATOR SHUT
DOWN RELAY
ISOLATION DIODE (V2)
CHECK**

NOTE: A diode can fail in two modes, either shorted or open. Continuity will be measured in one direction only in a serviceable diode. Use "diode checking mode" on meter when checking continuity.



T118385
T118385 -UN-21NOV98

Remove diode from connector.

Connect an ohmmeter to diode terminals.

Is continuity measured?

Reverse ohmmeter probes.

Is continuity measured?

YES: If continuity is measured in both checks, diode has failed in a shorted mode. Replace.


NO: If continuity is NOT measured in either check diode has failed in an open mode. Replace.

NO: If continuity is measured in one check and not the other, diode is OK.

--1/1

9015
15
13

**ALTERNATOR POWER
60 AMP FUSIBLE LINK
(F22) CHECK**



T109319 -UN-28APR97

Disconnect fusible link from battery relay.

Connect ohmmeter to both ends of fusible link.

Is continuity measured?


YES: Fusible link is OK. Check wiring harness.

NO: Fusible link has failed. Replace fusible link.

--1/1

Sub-System Diagnostics

**ALTERNATOR SHUT
DOWN RELAY (K1)
CHECK**



T7447BG -19-14JAN91

- 1—24 Volt Terminal
- 2—Ground Terminal
- 3—Relay Common
- 4—Relay Normally Closed
- 5—Relay Normal Open

Disconnect harness from relay.

Connect 24 volts to relay terminal 1 and ground terminal 2.

Does relay click?

Connect ohmmeter to terminals 3 and 5.

Does ohmmeter read continuity?

YES: Relay is OK.

NO: Relay has failed.
Replace.

9015
15
14

*Sub-System Diagnostics***STARTING AND FUEL SHUTOFF CIRCUIT OPERATIONAL INFORMATION**

The following conditions must be met for the circuit to function:

Key switch in START and voltage present at the following:

- Starter relay K13 terminal B
- Fuel shutoff relay K15 terminal B
- Starter M1 terminal C
- Fuel shutoff solenoid Y7 hold-in coil terminal

9015
15
15

CED,OUOE012,127 -19-15MAR99-1/1

STARTING AND FUEL SHUTOFF CIRCUIT THEORY OF OPERATION

When key switch S1 is moved to START, power is applied from key switch terminal ST to terminal e of starter relay K13 and terminal g of fuel shutoff relay K15, energizing both relays. (The ground path for the starter relay coil is provided through terminals 3 and 4 of de-energized starter protection relay K11). Battery power from alternator power fusible link F22 is applied from terminals B and G of energized starter relay K13 to starter M1 solenoid terminal C, energizing the solenoid. This applies battery voltage at starter terminal B (from battery relay K14) to the motor winding, and the starter motor starts cranking the engine.

At the same time, power from fuel shutoff fusible link F23 is applied through terminals B and G of the energized fuel shutoff relay to the pull-in coil of fuel shutoff solenoid Y7, opening the fuel valve. Power from power on 10-amp fuse F5 at the hold-in coil of the fuel shutoff solenoid keeps the fuel valve open after the key switch is returned to ON.

When the engine is running and the alternator is producing output voltage, starter protection relay K11

is energized by ground applied to terminal 2 of the relay from pin 18 of monitor controller and display A5. This prevents the starter motor from being activated if the key switch is moved to START while the engine is running, by removing the ground path for starter relay K13.

When star aid switch S18 is pressed, start aid relay K12 is energized by ground applied to terminal 2. With relay K12 energized, power from start aid fuse F20 is applied to start aid solenoid Y4 through the energized relay contacts, energizing the start aid solenoid. Start aid solenoid diode V1 limits the voltage spikes generated by the solenoid coil when it is de-energized.

Start relay coil suppression diode V9 limits the voltage spikes generated by the starter relay coil when the relay de-energizes.

Fuel shutoff solenoid pull-in and hold-in coil suppression diodes V10 and V8 limit the voltage spikes generated by the solenoid coils when they are de-energized.

CED,OUOE012,126 -19-15MAR99-1/1



FOLDOUT PAGE 4-81 IS AT REAR OF MANUAL

Sub-System Diagnostics

1 STARTING CIRCUIT DIAGNOSTIC PROCEDURES

IMPORTANT: Do not disconnect electrical connectors while the engine is running. Damage to Engine and Pump Controller or other components may result. Disconnect connectors only when instructed during a test or check.




---1/1

<p>KEY SWITCH (S1) CHECK</p>	 <p>T8357AL -UN-09NOV94</p> <p>1—B Terminal 2—G1 Terminal 3—G2 Terminal 4—ACC Terminal 5—M Terminal 6—ST Terminal</p> <p>Remove harness from key switch.</p> <p>Turn key switch to ON.</p> <p>Is continuity measured between terminals 1 and 4, and 1 and 5?</p>	<p>YES: Go to next step.</p> <p>NO: Key switch has failed. Replace.</p>
	 <p>T8357AM -UN-02DEC98</p> <p>1—B Terminal 2—G1 Terminal 3—G2 Terminal 4—ACC Terminal 5—M Terminal 6—ST Terminal</p> <p>Remove harness from key switch.</p> <p>Turn key switch to START.</p> <p>Is continuity measured between terminals 1 and 5, and 1 and 6?</p>	<p>YES: Key switch is OK.</p> <p>NO: Key switch has failed. Replace.</p>

---1/1

9015
15
17

Sub-System Diagnostics


<p>STARTER (M1) SOLENOID CHECK</p>	 <p>T118428 T118428 -UN-21NOV98</p> <p>⚠ CAUTION: Starter will crank engine if metal strap is NOT disconnected from motor.</p> <p>Disconnect metal strap from starter motor large terminal.</p> <p>Connect battery voltage to solenoid small terminal.</p> <p>Ground metal strap from solenoid with heavy gauge wire.</p> <p>Does solenoid click?</p>	<p>YES: Solenoid is OK. Check wiring harness.</p> <p>NO: Repair or replace starter solenoid.</p> <p style="text-align: right;">-- -1/1</p>
<p>STARTER (M1) MOTOR CHECK</p>	 <p>T6534BJ -UN-07JAN97</p> <p>Disconnect metal strap from starter motor large terminal.</p> <p>Connect a heavy gauge wire from battery positive cable to starter motor terminal.</p> <p>Does starter motor turn, but NOT crank engine.</p>	<p>YES: Starter motor is OK. Check wiring harness.</p> <p>NO: Repair or replace starter.</p> <p style="text-align: right;">-- -1/1</p>
<p>STARTER RELAY (K13) CHECK</p>	 <p>T7466AD -UN-14MAR91</p> <p>Disconnect harness from relay. Connect 24 volts to small terminal e and ground small terminal g. Measure continuity between large terminals B and G.</p> <p>Is continuity measured?</p>	<p>YES: Relay is OK. Check wiring harness.</p> <p>NO: Relay has failed. Replace relay.</p> <p style="text-align: right;">-- -1/1</p>

9015
15
18

Sub-System Diagnostics

START RELAY COIL SUPPRESSION DIODE (V9) CHECK

NOTE: A diode can fail in two modes, either shorted or open. Continuity will be measured in one direction only in a serviceable diode. Use "diode checking mode" on meter when checking continuity.



T118385
T118385 -UN-21NOV98

Remove diode from connector.

Connect an ohmmeter to diode terminals.

Is continuity measured?

Reverse ohmmeter probes.

Is continuity measured?

YES: If continuity is measured in both checks, diode has failed in a shorted mode. Replace.


NO: If continuity is NOT measured in either check, diode has failed in an open mode. Replace.

NO: If continuity is measured in one check and not the other, diode is OK.

--1/1

9015
15
19

BATTERY RELAY (K14) CHECK



T8182AK (CV)
T8182AK -UN-03MAR94

S—Relay Coil +24 Volt Terminal
E—Relay Coil Ground Terminal
B—Relay Battery Input Terminal
A—Relay Battery Output Terminal

Disconnect harness from relay. Connect 24 volts to small terminal S and ground small terminal E. Measure continuity between large terminals A and B.


Is continuity measured?

YES: Relay is OK. Check wiring harness.

NO: Relay has failed. Replace relay.

--1/1

ALTERNATOR POWER 60 AMP FUSIBLE LINK (F22) CHECK



T109319 -UN-28APR97

Disconnect fusible link from battery relay.

Connect ohmmeter to both ends of fusible link. Measure continuity between terminals.

Is continuity measured?


YES: Fusible link is OK. Check wiring harness.

NO: Fusible link has failed. Replace fusible link.

--1/1

Sub-System Diagnostics

STARTER PROTECTION RELAY (K11) CHECK



T7447BG -19-14JAN91

- 1—24 Volt Terminal
- 2—Ground Terminal
- 3—Relay Common
- 4—Relay Normally Closed
- 5—Relay Normally Open

Disconnect harness from starter protection relay.

Connect ohmmeter to terminals 3 and 4.

Does ohmmeter read continuity?

Connect 24 volts to relay terminal 1 and ground terminal 2.

Does relay "click"?

Connect ohmmeter to terminals 3 and 5.


Does ohmmeter read continuity?

YES: Relay is OK.

NO: Relay has failed. Replace.

--1/1

FUEL SHUTOFF SOLENOID (Y7) CHECK



T118387

T118387 -UN-21NOV98

Disconnect harness from fuel shutoff solenoid.

Connect 24 volts to solenoid terminals 1 and 2, and ground terminal 3, then remove power from terminal 2.

Does solenoid "click" and pull injection pump shutoff lever back, and remain in the energized position after power is removed from terminal 2?

YES: Solenoid is OK.

NO: Solenoid has failed. Replace.


--1/1

9015
15
20

Sub-System Diagnostics

FUEL SHUT-OFF SOLENOID HOLD-IN COIL SUPPRESSION DIODE (V8) AND FUEL SHUT-OFF SOLENOID PULL-IN COIL SUPPRESSION DIODE (V10) CHECK

NOTE: A diode can fail in two modes, either shorted or open. Continuity will be measured in one direction only in a serviceable diode. Use "diode checking mode" on meter when checking continuity.



T118385
T118385 -UN-21NOV98

Remove diode from connector.

Connect an ohmmeter to diode terminals.

Is continuity measured?

Reverse ohmmeter probes.

Is continuity measured?

YES: If continuity is measured in both checks, diode has failed in a shorted mode. Replace.


NO: If continuity is NOT measured in either check, diode has failed in an open mode. Replace.

NO: If continuity is measured in one check and not the other, diode is OK.

--1/1

9015
15
21

START-AID SOLENOID (Y4) CHECK



T111034
T111034 -UN-21AUG97

IMPORTANT: DO NOT start engine with start aid can removed from solenoid. Dust can enter the engine, seriously damaging the engine.

Disconnect harness from start-aid solenoid.

Remove ether can from start-aid

Connect 24 volts to solenoid terminal No. 1 and ground terminal No. 2.

Does solenoid click?

Reconnect harness.

Replace ether can.


YES: Solenoid is OK. Go to next check.

NO: Solenoid has failed. Replace.

--1/1

Sub-System Diagnostics

**START AID RELAY (K12)
CHECK**



T7447BG -19-14JAN91

- 1—24 Volt Terminal
- 2—Ground Terminal
- 3—Relay Common
- 4—Relay Normally Closed
- 5—Relay Normally Open

Disconnect harness from start aid relay.

Connect ohmmeter to terminals 3 and 5.

Does ohmmeter read open?

Connect 24 volts to relay terminal 1 and ground terminal 2.

Does relay "click"?

Connect ohmmeter to terminals 3 and 5.

Does ohmmeter read continuity?


YES: Relay is OK. Check switch and harness.

NO: Relay has failed. Replace.

--1/1

**START AID COIL
SUPPRESSION DIODE
(V1) CHECK**

NOTE: A diode can fail in two modes, either shorted or open. Continuity will be measured in one direction only in a serviceable diode. Use "diode checking mode" on meter when checking continuity.



T118385

T118385 -UN-21NOV98

Remove diode from connector.

Connect an ohmmeter to diode terminals.

Is continuity measured?

Reverse ohmmeter probes.

Is continuity measured?

YES: If continuity is measured in both checks, diode has failed in a shorted mode. Replace.

NO: If continuity is NOT measured in either check, diode has failed in an open mode. Replace.

NO: If continuity is measured in one check and not the other, diode is OK.

--1/1

9015
15
22

*Sub-System Diagnostics***WINDSHIELD WIPER AND WASHER CIRCUIT
OPERATIONAL INFORMATION**

The following conditions must be met for the circuit to function:

- Upper windshield in closed position with latch fully engaged.
- Key switch ON.

CED,OUOE012,8 -19-21OCT98-1/1

9015
15
23

*Sub-System Diagnostics***WINDSHIELD WIPER AND WASHER CIRCUIT THEORY OF OPERATION**

The windshield wiper and washer circuit has four modes of operation: windshield wiper ON (continuous), windshield wiper INT (intermittent), windshield wiper OFF (park), and windshield wash. The operation of the windshield wiper and washer circuit is controlled by signals from the monitor controller and the state of the wiper motor internal position status switch.

WINDSHIELD WIPER CONTINUOUS OPERATION

When wiper speed switch S9 is placed in the ON position, windshield wiper relays K6 (motor ground and intermittent), K7 (wiper run), and K8 (hold for park) are energized by grounds at terminals 26 and 27 of monitor controller and display A5. Windshield wiper relay K9 (motor ground for park) is de-energized by an open at terminal 24 of the monitor controller and display.

Power for windshield wiper motor M3 is supplied from windshield wiper 10-amp fuse F12 through contacts 3 and 5 of energized wiper run relay K7 to terminal L of the wiper motor. Terminal E of the wiper motor is connected to frame ground through contacts 3 and 5 of relay K6, and the wiper motor runs. The wiper motor drives a Pittman arm assembly which moves the wiper blade back and forth across the windshield.

Windshield wiper motor suppression diodes V6 and V7 protect the circuit components from voltage transients generated by the wiper motor.

WINDSHIELD WIPER INTERMITTENT OPERATION

When wiper speed switch S9 is placed in the INT position, monitor controller and display A5 grounds

terminals 27 and 28, and windshield wiper motor M3 is started in the same manner as described for continuous operation. After 1 to 2 seconds, the ground at terminal 28 of the monitor controller and display is removed by the controller, causing motor ground and intermittent relay K6 to de-energize. However, ground to wiper motor terminal E is now provided from wiper motor terminal S through contacts 3 and 4 of de-energized relay K6, and the wiper motor continues to run.

When the wiper motor reaches the intermittent stop position (wiper blade at right side of window), terminal S (which is applied to wiper motor terminal E through contacts 3 and 4 of de-energized relay K6) is switched from ground to +24 volts (from motor terminal B) by the wiper motor internal switch. With +24 volts now at both wiper motor terminals, E and L, the motor stops running. After a few seconds, the cycle is repeated by another 1 to 2 second ground pulse from terminal 28 of the monitor controller and display.

WINDSHIELD WIPER PARK OPERATION

When wiper speed switch S9 is turned to the OFF position, monitor controller and display A5 grounds terminal 24, energizing motor ground for park relay K9, and opens terminals 26, 27, and 28. If the wiper motor is running (not in the intermittent stop position), ground from terminal S of the wiper motor (applied through relay K8 contacts 3 and 5) keeps windshield wiper relays K7 (wiper run) and K8 (hold for park) energized. The ground from terminal S is also supplied through the de-energized contacts of motor ground and intermittent relay K6 to wiper motor terminal E, and the wiper motor continues running.

Continued on next page

CED,OUOE012,7 -19-21OCT98-1/2

Sub-System Diagnostics

When windshield wiper motor M3 reaches the intermittent stop position, wiper motor terminal S is switched from ground to +24 volts by the wiper motor internal switch. The +24 volts is applied to wiper motor terminal E, and also reverse biases windshield wiper relay isolation diode V5, causing windshield wiper relays K7 (wiper run) and K8 (hold for park) to be de-energized. Ground is now applied through contacts 5 and 3 of energized relay K9 and contacts 3 and 4 of de-energized relay K7 to wiper motor terminal L. With +24 volts on wiper motor terminal E and ground on wiper motor terminal L, the motor runs backwards until a cam in the Pittman arm assembly causes the wiper to be driven off the right side of the windshield into the park position on the windshield frame. When the wiper motor reaches the park position, motor terminal S is

grounded by the motor internal switch, and the motor stops.

WINDSHIELD WASHER OPERATION

When windshield washer switch S15 is pressed, windshield washer relay K2 is energized by a ground at terminal 24 of monitor controller and display A5. Power is applied to windshield washer motor M4 from windshield wiper 10-amp fuse F12 through contacts 3 and 5 of energized relay K2. The motor drives the windshield washer pump, to spray fluid from the windshield washer fluid reservoir onto the windshield. When the switch is released, ground is removed from terminal 24 of monitor controller and display A5, and the washer motor stops.

9015
15
25

FOLDOUT PAGE 4-91 IS AT REAR OF MANUAL

Sub-System Diagnostics

① WINDSHIELD WIPER AND WASHER CIRCUIT DIAGNOSTIC PROCEDURES

IMPORTANT: Do not disconnect electrical connectors while the engine is running. Damage to Monitor Controller or other components may result. Disconnect connectors only when instructed during a test or check.

NOTE: If windshield wiper does not operate, first check the latch on the upper right corner of the windshield. The windshield must be all the way down and the right latch must be secured to contact the windshield wiper enable switch, which allows the wiper to operate.

Before troubleshooting the circuits, clean all terminals in the monitor controller and harness connectors using a non-conductive lubricating contact cleaner, then try the circuit operation again before proceeding. TY16324 Contact Cleaner can be used.

9015
15
27


--1/1


<p>WINDSHIELD WIPER 10 AMP FUSE (F12) CHECK</p>	<p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK.</p> <p>NO: Replace Fuse. If fuse blows again, check for short.</p>
--	--	--

--1/1

Sub-System Diagnostics

9015
15
28


<p>WINDSHIELD WIPER MOTOR (M3) RUN AND INTERMITTENT STOP CHECK</p>	 <p>T118388 T118388 -UN-21NOV98</p> <p>Disconnect harness from windshield wiper motor.</p> <p>Connect wiper motor connector terminal E to connector terminal S.</p> <p>Connect +24 volts to wiper motor connector terminal L.</p> <p>If the windshield wiper was in the park position, did it operate for one sweep, then stop in the intermittent stop position?</p> <p>Connect wiper motor connector terminal E to ground (while still connected to S).</p> <p>Does windshield wiper operate?</p> <p>Remove ground from terminal E.</p> <p>Does windshield wiper continue operating until wiper blade reaches intermittent park position, then stop?</p>	<p>YES: Check harness, wiper relays and monitor controller.</p> <p>NO: Replace windshield wiper motor.</p> <p style="text-align: right;">-- -1/1</p>
---	--	--

<p>WINDSHIELD WIPER MOTOR (M3) PARK CIRCUIT CHECK</p>	 <p>T118388 T118388 -UN-21NOV98</p> <p>With key switch ON, move windshield wiper switch to INT.</p> <p>When wiper stops in intermittent stop position, turn key switch OFF, then turn windshield wiper switch OFF.</p> <p>Disconnect harness from windshield wiper motor.</p> <p>Connect wiper motor connector terminal L to connector terminal B.</p> <p>Connect +24 volts to wiper motor connector terminal E.</p> <p>Ground wiper motor connector terminal S.</p> <p>Does wiper motor operate until wiper blade reaches park position?</p>	<p>YES: Check harness, wiper relays and monitor controller.</p> <p>NO: Replace windshield wiper motor.</p> <p style="text-align: right;">-- -1/1</p>
--	---	--

Sub-System Diagnostics

WINDSHIELD WIPER MOTOR SUPPRESSION DIODE (V6, V7) CHECK

NOTE: A diode can fail in two modes, either shorted or open. Continuity will be measured in one direction only in a serviceable diode.



T118385
T118385 -UN-21NOV98

The windshield wiper diodes are located inside right console lower cover.

Remove diodes from connectors.

Connect an ohmmeter to diode terminals.

Is continuity measured?

Reverse ohmmeter probes.

Is continuity measured?

Install diodes in connectors.

YES: If continuity is measured in both checks, diode has failed in a shorted mode. Replace.


NO: If continuity is NOT measured in either check, diode has failed in an open mode. Replace.

NO: If continuity is measured in one check and not the other, diode is OK. Check wiring harness and monitor controller

--1/1

9015
15
29

WINDSHIELD WIPER RELAY (MOTOR GROUND AND INTERMITTENT) (K6), WINDSHIELD WIPER RELAY (WIPER RUN) (K7), WINDSHIELD WIPER RELAY (HOLD FOR PARK) (K8) AND WINDSHIELD WIPER RELAY (MOTOR GROUND FOR PARK) (K9) CHECK



T7447BG -19-14JAN91

- 1—24-Volt Terminal
- 2—Ground Terminal
- 3—Relay Common
- 4—Relay Normal Closed
- 5—Relay Normal Open

Disconnect relay from harness.

Connect ohmmeter to relay terminals 3 and 4.

Does ohmmeter read continuity?

Connect 24 volts to relay terminal 1 and ground terminal 2.

Does relay "click"?

With 24 volts still connected to terminal 1, connect ohmmeter to terminals 3 and 5.

Does ohmmeter read continuity?


YES: Relay is OK.

NO: Relay has failed. Replace.

--1/1

Sub-System Diagnostics

WINDSHIELD WASHER RELAY (K2) CHECK



T7447BG -19-14JAN91

- 1—24-Volt Terminal
- 2—Ground Terminal
- 3—Relay Common
- 4—Relay Normal Closed
- 5—Relay Normal Open

Disconnect relay from harness.

Connect ohmmeter to relay terminals 3 and 4.

Does ohmmeter read continuity?

Connect 24 volts to relay terminal 1 and ground terminal 2.

Does relay "click"?

With 24 volts still connected to terminal 1 connect ohmmeter to terminals 3 and 5.


Does ohmmeter read continuity?

YES: Relay is OK.

NO: Relay has failed. Replace.

--1/1

WINDSHIELD WASHER MOTOR (M4) CHECK



T7395EG -UN-15OCT90

Disconnect harness from windshield washer motor.

Connect 24 volts to BLUE wire terminal in washer motor connector.

Ground BLUE/BLACK wire terminal in washer motor connector.

Does windshield washer motor operate?

YES: Check wiring harness and monitor controller.

NO: Replace windshield washer motor.

--1/1

WINDSHIELD WIPER ENABLE SWITCH (S14) CHECK

Slide upper windshield up.

Remove windshield wiper enable switch retaining plate located in upper right hand corner of cab.

Connect ohmmeter across pins 1 and 2 of the switch and actuate the switch.

Is continuity measured when switch is actuated and no continuity when switch is not actuated?

YES: Windshield wiper enable switch is OK.

NO: Check wiring harness and monitor controller.

--1/1

9015
15
30

Sub-System Diagnostics

<p>WINDSHIELD WIPER ENABLE SWITCH (S14) HARNESS CHECK</p>	<p>Slide upper windshield up.</p> <p>Remove windshield wiper enable switch retaining plate located in upper right hand corner of cab.</p> <p>Using an ohmmeter, measure resistance of harness wire from enable switch pin 1 to pin 6 of monitor controller 12-pin connector, and from enable switch pin 2 to ground.</p> <p>Is continuity measured in both checks?</p>	<p>YES: Windshield wiper enable switch harness is OK.</p> <p>NO: Check monitor controller.</p> <p style="text-align: right;">-- -1/1</p>
--	--	--

9015
15
31

*Sub-System Diagnostics***WORK AND DRIVE LIGHT CIRCUIT OPERATIONAL INFORMATION**

In order for the work and drive light circuits to function, the key switch must be in the ACC or ON position.

CED.OUOE012,134 -19-16MAR99-1/1

WORK AND DRIVE LIGHT CIRCUIT THEORY OF OPERATION

When the key switch is in the ON or ACC position, power is applied from work and drive light 10-amp fuse F11 to terminals 1 and 3 of work and drive light relays K3 and K4.

When drive and work light switch S10 is moved to position 1, drive light relay K4 is energized by ground applied to relay terminal 2 from terminal 19 of monitor and controller display A5. With the drive light relay energized, power is applied through relay terminals 3 and 5 to drive light E2, and cab lights E7 and E8.

Power from the drive light relay is also applied to terminal 41 of monitor controller and display A5, terminal 8 of engine mode and speed control unit A4, and the ILLUM terminal of radio A1 for panel illumination.

When the light switch is moved to position 2, terminal 20 of the monitor controller and display is also

grounded (terminal 19 remains grounded), energizing work light relay K3 as well. With the work light relay energized, power is applied through relay terminals 3 and 5 to work lights E1 and E6.


Relays K3 and K4 also apply power to pins 5 (work light) and 4 (drive light) of optional connector X5 to provide for connection of additional lights.

When the key switch is in the ON or ACC position, power is also applied from auxiliary power fuse F19 through terminal 3 of terminal strip X27, to rear light switch S20. When switch S20 is On, power is applied to left and right rear lights E9 and E10. The ground path for the rear lights is provided through X27 terminal 5 to cab ground.

CED.OUOE012,135 -19-16MAR99-1/1

Sub-System Diagnostics

WORK AND DRIVE LIGHT CIRCUIT SCHEMATIC



9015
15
33

WORK AND DRIVE LIGHT CIRCUIT

Work and Drive Light Circuit

T120581

T120581 -19-28OCT99

CED.OUOE012,189 -19-27MAY99-1/1

Sub-System Diagnostics

1 WORK AND DRIVE LIGHT CIRCUIT DIAGNOSTIC PROCEDURES

IMPORTANT: Do not disconnect electrical connectors while the engine is running. Damage to Engine and Pump Controller or other components may result. Disconnect connectors only when instructed during a test or check.

NOTE: Before troubleshooting the circuits, clean all terminals in the monitor controller and harness connectors using a non-conductive lubricating contact cleaner, then try the circuit operation again before proceeding. TY16324 Contact Cleaner can be used.

---1/1

9015
15
34


WORK AND DRIVE LIGHTS 20 AMP FUSE (F11) CHECK

Remove fuse block cover.
Remove fuse from fuse block.
Using ohmmeter, check fuse for continuity.
Is continuity measured?

YES: Fuse is OK.
NO: Replace Fuse. If fuse blows again, check for short.

---1/1

DRIVE LIGHT RELAY (K4) CHECK



T7447BG -19-14JAN91

- 1—24 Volt Terminal
- 2—Ground Terminal
- 3—Relay Common
- 4—Relay Normally Closed
- 5—Relay Normally Open


Disconnect harness from relay.
Connect ohmmeter to terminals 3 and 5.
Does ohmmeter read open?
Connect 24 volts to relay terminal 1 and ground terminal 2.
Does relay "click"?
With 24 volts still connected to terminal 1, connect ohmmeter to terminals 3 and 5.
Does ohmmeter read continuity?

YES: Relay is OK.
NO: Relay has failed. Replace.

---1/1

Sub-System Diagnostics

WORK LIGHT RELAY (K3) CHECK



T7447BG -19-14JAN91

- 1—24-Volt Terminal
- 2—Ground Terminal
- 3—Relay Common
- 4—Relay Normally Closed
- 5—Relay Normally Open

Disconnect harness from relay.

Connect ohmmeter to terminals 3 and 5.

Does ohmmeter read open?

Connect 24 volts to relay terminal 1 and ground terminal 2.

Does relay 'click'?

With 24 volts still connected to terminal 1, connect ohmmeter to terminals 3 and 5.

Does ohmmeter read continuity?


YES: Relay is OK.

NO: Relay has failed. Replace.

--1/1

9015
15
35

DRIVE LIGHTS (E2, E7, E8) CIRCUIT CHECK



T118361

T118361 -UN-21NOV98

Disconnect 16-pin harness connector from monitor controller and display panel.

Ground harness connector pin 19.


Do drive light E2 and left and right cab lights E7 and E8 operate with key switch in ACC position?

YES: Light switch on monitor controller and display panel has failed. Replace.

NO: Check light bulbs, wire harness and drive light relay.


--1/1

Sub-System Diagnostics

<p>WORK LIGHTS (E1) CIRCUIT CHECK</p>	 <p>T118360 T118360 -UN-21NOV98</p> <p>Disconnect 16-pin harness connector from monitor controller and display panel.</p> <p>Ground harness connector pin 20.</p> <p>Do work lights E1 and E6 operate with key switch in ACC position?</p>	<p>YES: Light switch on monitor controller and display panel has failed. Replace.</p> <p>NO: Check light bulbs, wire harness, and work light relay.</p>
--	--	---

9015
15
36

-- -1/1

<p>REAR LIGHTS (E9, E10) CIRCUIT CHECK</p>	<p>Remove fuse block cover.</p> <p>Remove fuse F19 from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK. Go to next step.</p> <p>NO: Replace Fuse. If fuse blows again, check circuit for short.</p>
	 <p>Disconnect harness connector from rear lights switch S20.</p> <p>Connect ohmmeter across switch connector pins.</p> <p>Does ohmmeter read open with switch Off, and continuity with switch On?</p> <p>T112437 T112437 -UN-05DEC97</p>	<p>YES: Light switch is OK. Check light bulbs and wire harness</p> <p>NO: Switch has failed. Replace.</p>

-- -1/1

*Sub-System Diagnostics***ACCESSORY CIRCUITS OPERATIONAL INFORMATION**

In order for the circuits to function, the key switch must be in the ACC or ON position.

CED,OUOE012,21 -19-31OCT98-1/1

ACCESSORY CIRCUITS THEORY OF OPERATION

The accessory circuits include the horns (B25, B26), the cab dome light (E3), and the 24-volt power plug (G4).

Power from horn 10-amp fuse F15 is applied to terminal 1 and 3 of horn relay K5. When horn switch S2 is pressed, the closed contacts of the switch apply ground to terminal 2 of the horn relay, and the relay is energized. With the relay is energized, power is applied from relay terminal 5 to high and low note horns B25 and B26, sounding the horns.

Power from dome light 5-amp fuse F18 is applied to dome light switch S3. When the switch is turned ON, power is applied to cab dome light E3, turning the light on.

Power from lighter 10-amp fuse F17 is applied to 24-volt power plug G4.


CED,OUOE012,22 -19-31OCT98-1/1

9015
15
37

Sub-System Diagnostics

ACCESSORY CIRCUITS SCHEMATIC

9015
15
38



ACCESSORY CIRCUIT

T117936

T117936 -19-18NOV98

CED,OUOE012,23 -19-31OCT98-1/1

Sub-System Diagnostics

① ACCESSORY CIRCUITS DIAGNOSTIC PROCEDURES

IMPORTANT: Do not disconnect electrical connectors while the engine is running. Damage to Engine and Pump Controller or other components may result. Disconnect connectors only when instructed during a test or check.

--1/1

<p>HORN 10 AMP FUSE (F15) CHECK</p>	<p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK.</p> <p>NO: Replace Fuse. If fuse blows again, check for short.</p>
--	--	--

9015
15
39

--1/1

<p>DOMELIGHT 5 AMP FUSE (F18) CHECK</p>	<p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK.</p> <p>NO: Replace Fuse. If fuse blows again, check for short.</p>
--	--	--


--1/1

<p>LIGHTER 10 AMP FUSE (F17) CHECK</p>	<p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK.</p> <p>NO: Replace Fuse. If fuse blows again, check for short.</p>
---	--	--

--1/1

Sub-System Diagnostics

**HORN RELAY (K5)
CHECK**



T7447BG -19-14JAN91

- 1—24-Volt Terminal
- 2—Ground Terminal
- 3—Relay Common
- 4—Relay Normally Closed
- 5—Relay Normally Open

Disconnect harness from relay.

Connect ohmmeter to terminals 3 and 4.

Does ohmmeter read continuity?

Connect 24 volts to relay terminal 1 and ground terminal 2.

Does relay "click"?

With 24 volts still connected to terminal 1, connect ohmmeter to terminals 3 and 5.

Does ohmmeter read continuity?

YES: Relay is OK.

NO: Relay has failed. Replace.

--1/1

**HORN SWITCH (S2)
CHECK**



T108586 -UN-31MAR97

Remove bottom cover from left arm rest.

Disconnect wire harness from horn switch.

Connect ohmmeter to both wires (pink and black) and push horn button.

Does ohmmeter read continuity?


YES: Horn switch OK. Check wiring harness and horns.

NO: Replace switch.

--1/1

9015
15
40

Sub-System Diagnostics


<p>HIGH NOTE HORN (B25) AND LOW NOTE HORN (B26) CHECK</p>	 <p>T7469AF -UN-11MAR91</p> <p>Disconnect wire harness from horns.</p> <p>Connect 24 volts to one terminal of either horn and connect other horn terminal to ground.</p> <p>Does horn sound?</p> <p>Repeat check on other horn.</p>	<p>YES: Check wire harness.</p> <p>NO: Replace horn.</p> <p style="text-align: right;">-- 1/1</p>
--	--	---

<p>QUICK HITCH CIRCUIT OPERATIONAL INFORMATION</p> <p>In order for the circuit to function, the key switch must be in the ACC or ON position.</p> <p style="text-align: right;">CED,OUOE012,131 -19-15MAR99-1/1</p>	<p>9015 15 41</p>
--	---------------------------

<p>QUICK HITCH CIRCUIT THEORY OF OPERATION</p> <p>With the key switch in the ON or ACC position, power is applied from auxiliary fuse F19 to quick hitch fuse F24 via terminal 2 of auxiliary terminal strip X27. When quick hitch switch S21 is moved to the UNLATCH (closed) position, power from fuse F24 is applied through the switch to solenoid Y2, energizing the solenoid. With the switch in the UNLATCH position, power is also applied from to warning light H23 and audible alarm H22.</p> <p style="text-align: right;">CED,OUOE012,132 -19-15MAR99-1/1</p>
--

Sub-System Diagnostics

QUICK HITCH CIRCUIT SCHEMATIC



QUICK HITCH CIRCUIT

Quick Hitch Circuit

T120642

T120642 -19-28OCT99

CED.OUOE012.133 -19-15MAR99-1/1

1 QUICK HITCH CIRCUIT DIAGNOSTIC PROCEDURES

---1/1

1a AUXILIARY 10 AMP FUSE (F19) CHECK

- Remove fuse block cover.
- Remove fuse from fuse block.
- Using ohmmeter, check fuse for continuity.
- Is continuity measured?


YES: Fuse is OK.

NO: Replace Fuse. If fuse blows again, check for short.

---1/1

Sub-System Diagnostics

1b QUICK HITCH CONTROL BOX (A6) CHECK



T112437
T112437 -UN-05DEC97

Position boom so implement is resting on ground.
Turn key Switch OFF
Remove harness connector from hitch solenoid.
connect voltmeter to pins 1 and 2 of harness connector.
Turn key switch ON.

CAUTION: Do not move control box switch to UNLATCH position unless implement or quick hitch is resting on ground.

Move control box switch to UNLATCH position.
Does voltmeter read 24 volts?
Does hitch indicator light come on?
Does hitch warning alarm sound?
Move control box switch to LATCH position


YES: Control box is OK.
Go to next check.

NO: Repair or replace control box.

--1/1

9015
15
43

1c HITCH SOLENOID (Y2) CHECK



T111034
T111034 -UN-21AUG97

Disconnect harness from hitch solenoid.
Connect 24 volts to solenoid terminal No. 1 and ground terminal No. 2.
Does solenoid click?
Reconnect harness.

YES: Solenoid is OK.

NO: Solenoid has failed.
Replace.

--1/1

HEATER CIRCUIT (MACHINES WITHOUT AIR CONDITIONER)

See Group 9031.

Sub-System Diagnostics

**HEATER CIRCUIT (MACHINES WITH AIR
CONDITIONER)**

See Group 9031.

CED,OUOE012,44 -19-10NOV98-1/1

9015
15
44

Sub-System Diagnostics

MONITOR CONTROLLER AND DISPLAY CIRCUIT SPECIFICATIONS

Fuel Sending Unit—Specification

Resistance 10 +0 -4 Ohms With Fuel Gauge Reading Full

Fuel Sending Unit—Specification

Resistance 38 ± 5 Ohms With Fuel Gauge Reading Half

Fuel Sending Unit—Specification

Resistance 90 +10 -0 Ohms With Fuel Gage Reading Empty

Fuel Level Switch Closes At—Specification

Level 112 mm (4.4 in.) Fuel In Tank Or Less (30.3—37.9 L) (8—10 Gal)

Engine Oil Pressure Switch Opens At—Specification

Level Above 172 kPa (1.72 bar) (24.9 psi)

Engine Oil Pressure Switch Closes At—Specification

Level Below 103 kPa (1.03 bar) (14.9 psi)

Engine Coolant Temperature Switch Closes On—Specification

Increasing Temperature..... 110°C ± 3°C (230°F ± 37°F) Maximum

Engine Coolant Temperature Switch Opens On—Specification

Decreasing Temperature 95°C (203°F) Minimum

Alternator Charge Light Illuminates At Alternator Excitation

Field Output—Specification

Voltage 10 ± 1.5 Volts Or Less

Alternator Charge Light Goes Out At Alternator Excitation Field Output—Specification

Voltage 13 ± 1.5 Volts Or More

Air Filter Restriction Switch Closes At—Specification

Vacuum 6.23 kPa ± 1.25 kPa
 Vacuum 1.84 ± 0.36 in Hg
 Vacuum 25 ± 2.3 in. water

Coolant Temperature Gauge Needle Position At—Specification

Temperature 60°C (140°F) Beginning Of Green Area (Cold)
 Temperature 104°C (219°F) End Of Green Area (Cold)
 Temperature 110°C (230°F) Beginning Of Red Area (Hot)
 Temperature 135°C (275°F) End Of Red Area (Hot)

Engine Coolant Temperature Sensor—Specification

Resistance 63 Ohms At 60°C (140°F)
 Resistance 14 Ohms At 104°C (219°F)
 Resistance 15 Ohms At 110°C (230°F)
 Resistance 3 Ohms At 135°C (275°F)

Charge Air Temperature Switch Closes At—Specification

Temperature 100°C (212°F)

9015
15
45

Sub-System Diagnostics

Hydraulic Filter Restriction Switch Closes At—Specification

Vacuum..... 6.23 kPa \pm 1.25 kPa
Vacuum..... 1.84 \pm 0.36 in Hg
Vacuum..... 25 \pm 2.3 in. water

CED,OUOE012,25 -19-09MAR99-2/2

**MONITOR CONTROLLER AND DISPLAY
CIRCUIT OPERATIONAL INFORMATION**

The key switch must ON for the circuit to function.

CED,OUOE012,26 -19-31OCT98-1/1

9015
15
46

*Sub-System Diagnostics***MONITOR CONTROLLER AND DISPLAY CIRCUIT THEORY OF OPERATION**

The monitor controller and display (A5) contains gauges and indicators, sensor inputs, and switches. The gauges and indicators display the status of machine systems and control switches. The sensor inputs are used by the monitor controller to monitor the status of the machine systems, and the switches are used to control or select machine functions by providing control signal outputs to other machine systems. The illumination of the indicators and the status of control signal outputs are controlled by logic circuits and drivers in the monitor controller in response to the sensor inputs and control switch settings.

Operating power to controller and display is applied from monitor controller and display fuse F5 to terminals 39 and 40. Cab frame ground is applied to terminal 37. Backup power for the controller logic circuits is applied from radio and monitor controller fuse F1 to monitor controller terminal 39.

HOURLY METER AND GAUGES

Operating power for the hourmeter is applied from fuse F5 to controller terminal 29, and the controller monitors the alternator excitation field at terminal 42. When the engine is running and the alternator excitation field voltage is greater than 11.5 volts, the hourmeter operates.

The engine coolant temperature and fuel level gauges (P2 and P3) are controlled by coolant temperature and fuel level senders B9 and B8, which provide a variable resistance to ground for the gauges.

Temperature sender B9 is applied to controller terminal 47, and fuel level sender B8 is applied to terminal 46.

STATUS INDICATORS

When the key switch is turned to ON, the monitor controller and display performs a lamp check by illuminating all the status indicators. After 2 - 3 seconds the lamp check mode ends, and indicator lamp illumination is controlled by the sensor inputs.

AIR FILTER RESTRICTION INDICATOR LIGHT (H14)

The air filter restriction switch (B1) is a normally open switch that closes to machine ground when a restriction is sensed with the engine running. The machine ground is applied to controller terminal 3, causing the indicator to illuminate.

FUEL LEVEL INDICATOR LIGHT (H13)

The fuel level switch (B2) is normally open when fuel is in the tank, and closes to machine ground when the fuel level is below 112 mm (4.4 in.). The machine ground is applied to controller terminal 2, causing the indicator to illuminate.

ENGINE COOLANT TEMPERATURE INDICATOR LIGHT (H16)

The engine coolant temperature switch (B3) is a normally open switch that closes to machine ground when the coolant temperature exceeds $105 \pm 5^{\circ}\text{C}$ ($221 \pm 35^{\circ}\text{F}$). The machine ground is applied to controller terminal 1, causing the indicator to illuminate.

ENGINE OIL PRESSURE INDICATOR (H17)

The engine oil pressure switch (B4) is normally closed and opens with the engine running. When the oil pressure falls below 39 kPa (.039 bar) (5.7 psi) the switch closes to machine ground. The machine ground is applied to controller terminal 10, causing the indicator to illuminate.

9015
15
47

*Sub-System Diagnostics***HYDRAULIC OIL LEVEL INDICATOR (H12)**

Hydraulic oil level switch (B5) is a normally open switch, held closed when the oil level is adequate. The machine ground is applied to controller terminal 9. The monitor controller only checks the status of terminal 9 when the fluid level switch (S5) is pressed. If ground is present when the switch is pressed, the indicator illuminates.

ENGINE COOLANT LEVEL INDICATOR (H20)

Engine coolant level switch (B6) is a normally open switch, held closed when the coolant level is adequate. The machine ground is applied to controller terminal 8. The monitor controller only checks the status of terminal 8 when the fluid level switch (S5) is pressed. If ground is present when the switch is pressed, the indicator illuminates.

ENGINE OIL LEVEL INDICATOR (H19)

Engine oil level switch (B7) is a normally open switch, held closed with adequate oil level. The machine ground is applied to controller terminal 7. The monitor controller only checks the status of terminal 7 when the fluid level switch (S5) is pressed. If ground is present when the switch is pressed, the indicator illuminates.

ALTERNATOR VOLTAGE INDICATOR (H18)

The alternator voltage indicator is controlled by the alternator excitation field voltage monitored by the controller at terminal 42. When the alternator excitation field voltage drops below 10 ± 1.5 volts the indicator illuminates. When the alternator excitation field voltage goes above 13 ± 1.5 volts the indicator goes out.

CHARGE AIR TEMPERATURE INDICATOR (H15)

Charge air temperature switch (B12) is a normally open switch that closes to machine ground when the charge air temperature exceeds 100°C (212°F). The machine ground is applied to controller terminal 44, causing the indicator to illuminate.

HYDRAULIC OIL FILTER RESTRICTION INDICATOR (H21)

The hydraulic oil filter restriction switch (B30) is a normally open switch that closes to machine ground when the differential pressure in the hydraulic oil filter exceeds 15 psi. The machine ground is applied through switch B31 to controller pin 43, causing the indicator to illuminate.

MONITOR CONTROLLER AND DISPLAY ALARM (H8)

The monitor controller and display alarm sounds when the engine oil pressure is low, or the engine coolant overheats. When the buzzer stop switch (S6) is pressed and released, the buzzer stops sounding and the buzzer function is automatically reset for the engine coolant overheat function. The buzzer cannot be turned off when the oil pressure is low.

The buzzer is reset by turning the key switch to OFF. The buzzer will not sound more than once for the same problem unless it has been reset.

CONTROL SWITCHES AND INDICATORS**WIPER SPEED SWITCH (S9)**

The wiper speed switch is used to select intermittent or continuous windshield wiper operation. The monitor controller provides ground switched outputs to the windshield wiper circuit from controller terminals 24, 26, 27, and 28 based on the setting of the wiper speed switch. If the windshield is open, a ground from windshield wiper enable switch S14 is allied to monitor controller terminal 6, disabling the wiper speed switch.

WINDSHIELD WASHER SWITCH (S15)

When the windshield washer switch is pressed, the monitor controller provides a ground switched output to the windshield washer circuit from controller terminal 25.

*Sub-System Diagnostics***DRIVE AND WORK LIGHT SWITCH (10)**

The drive and work light switch provides ground switched outputs to the light circuits. When the switch is moved to position 1, controller terminal 19 (drive light) is grounded. When the switch is moved to position 2, controller terminals 19 and 20 (work light) are grounded.

WORK MODE SELECTION SWITCH (S7)

The work mode selection switch selects the machine operating modes (dig, grading, precision, or attachment). Each time the switch is pressed the mode selection is stepped to the next mode and the corresponding mode indicator (H1, H2, H3 or H4) is illuminated. The monitor controller provides different combinations of ground switched outputs to the engine and pump controller depending on the mode selected. The outputs are applied to mode 1 and mode 2 monitor controller terminals 21 and 22.

PROPEL SPEED CHANGE SWITCH (S8)

The propel speed change switch selects slow or fast operating speed. When the switch is moved to fast speed, the monitor controller speed selection output to the engine controller at terminal 17 is grounded.

AUTO IDLE (A/I) SWITCH (S13)

When the auto idle (A/I) switch is pressed, the A/I indicator illuminates and the monitor controller provides a ground output to the engine motor and pump controller from terminal 13.

ENGINE MODE AND RPM CONTROL UNIT (A4)**ECONOMY (E) MODE SWITCH (S11)**

When the economy (E) mode switch is pressed, a ground is applied from engine mode and RPM control unit terminal 2 to monitor controller terminal 35, causing the economy mode to be selected. With the economy mode selected, the monitor controller illuminates the economy mode indicator light (H6), and provides an output signal to the engine and pump controller from terminal 15. Ground for the mode switch is applied to engine mode and RPM control unit terminal 1.

HIGH POWER (HP) MODE SWITCH (S12)

When the high power (HP) mode switch is pressed, a ground is applied from engine mode and RPM control unit terminal 4 to monitor controller terminal 34, causing the high power mode to be selected. With the high power mode selected, the monitor controller illuminates the high power mode indicator light (H5), and provides an output signal to the engine and pump controller from terminal 23. Ground for the mode switch is applied to engine mode and RPM control unit terminal 3.

ENGINE RPM DIAL (R10)

The engine RPM dial provides a variable voltage to engine and pump controller terminal D21 from engine mode and RPM control unit terminal 6 based on the setting of the RPM dial. Power for the RPM dial is applied across engine mode and RPM control unit terminals 5 and 7.

9015
15
49

FOLDOUT PAGE 4-115 IS AT REAR OF MANUAL

Sub-System Diagnostics

🔧 MONITOR CONTROLLER AND DISPLAY CIRCUIT DIAGNOSTIC PROCEDURES

IMPORTANT: Do not disconnect electrical connectors while the engine is running. Damage to Engine and Pump Controller or other components may result. Disconnect connectors only when instructed during a test or check.


NOTE: Before troubleshooting the circuits, clean all terminals in the monitor controller and harness connectors using a non-conductive lubricating contact cleaner, then try the circuit operation again before proceeding. TY16324 Contact Cleaner can be used.

---1/1

<p>MONITOR CONTROLLER AND DISPLAY 5 AMP FUSE (F6) CHECK</p>	<p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK.</p> <p>NO: Replace Fuse. If fuse blows again, check for short.</p>
--	--	--

9015
15
51


---1/1

<p>MONITOR CONTROLLER AND DISPLAY (A5) HARNESS POWER CHECK</p>	<div style="text-align: center;">  </div> <p>T118378 T118378 -UN-21NOV98</p> <p>Turn key switch OFF.</p> <p>Disconnect 20-pin harness connector from monitor controller and display.</p> <p>Measure voltage on pins 30, 39 and 40 of harness connector.</p> <p>Is 24 volts measured?</p>	<p>YES: Go to next check.</p> <p>NO: Repair harness.</p>
---	--	--

---1/1

Sub-System Diagnostics

**MONITOR CONTROLLER
AND DISPLAY (A5)
HARNESS GROUND
CHECK**



T118378

T118378 -UN-21NOV98

Turn key switch OFF.

Disconnect 20-pin harness connector from monitor controller and display.

Measure continuity from pin 37 of harness connector to cab frame.

Is continuity measured?

YES: Monitor controller has failed. Replace.

NO: Repair wiring harness.

--1/1

**ECONOMY MODE
INDICATOR LIGHT (H6)
CHECK**

With key switch ON and economy mode OFF, push economy (E) mode switch.

Does switch stay down and economy mode indicator light come ON?

Push economy (E) mode switch again.

Does switch return to original position and indicator go OFF?

YES: Indicator and switch are OK.


NO: Go to next check.

--1/1

9015
15
52

Sub-System Diagnostics

ECONOMY (E) MODE SWITCH (S11) CHECK



T118513

T118513 -UN-21NOV98

Turn key switch OFF.

Disconnect engine rpm dial board connector.

Connect ohmmeter between pins 1 and 2 of dial board connector

Measure continuity with economy (E) mode switch in OFF and ON positions.

Does ohmmeter read open with switch in OFF position, and continuity with switch in ON position?

Reconnect engine rpm dial board connector.


YES: Switch is OK. Go to next check.

NO: Switch has failed. Replace.

--1/1

9015
15
53

ECONOMY (E) MODE SWITCH (S11) HARNESS CHECK



T118512

T118512 -UN-21NOV98

Turn key switch OFF.

Disconnect 20-pin harness connector from monitor controller and display.

Connect ohmmeter between pins 35 and 38 of harness connector

Measure continuity with economy (E) mode switch in OFF and ON positions.

Does ohmmeter read open with switch in OFF position, and continuity with switch in ON position?


YES: Indicator lamp or controller has failed. Replace.

NO: Harness has failed. Repair.


--1/1

Sub-System Diagnostics

<p>HIGH POWER MODE INDICATOR LIGHT (H5) CHECK</p>	<p>With key switch ON and high power mode OFF, push high power (HP) mode switch.</p> <p>Does switch stay down and high power mode indicator light come ON?</p> <p>Push high power (HP) mode switch again.</p> <p>Does switch return to original position and indicator go OFF?</p>	<p>YES: Indicator and switch are OK.</p> <p>NO: Go to next check.</p> <p style="text-align: right;">---1/1</p>
--	--	--

<p>9015 15 54</p> <p>HIGH POWER (HP) MODE SWITCH (S12) CHECK</p>	<div style="text-align: center;">  </div> <p>T118515 T118515 -UN-21NOV98</p> <p>Turn key switch OFF.</p> <p>Disconnect engine rpm dial board connector.</p> <p>Connect ohmmeter between pins 3 and 4 of dial board connector</p> <p>Measure continuity with high power (HP) mode switch in OFF and ON positions.</p> <p>Does ohmmeter read open with switch in OFF position, and continuity with switch in ON position?</p> <p>Reconnect engine rpm dial board connector.</p>	<p>YES: Switch is OK. Go to next check.</p> <p>NO: Switch has failed. Replace.</p> <p style="text-align: right;">---1/1</p>
---	---	---

Sub-System Diagnostics

<p>HIGH POWER (HP) MODE SWITCH (S12) HARNESS CHECK</p>	<div style="text-align: center;">  </div> <p>T118514 T118514 -UN-21NOV98</p> <p>Turn key switch OFF.</p> <p>Disconnect 20-pin harness connector from monitor controller and display.</p> <p>Connect ohmmeter between pins 34 and 38 of harness connector</p> <p>Measure continuity with high power (HP) mode switch in OFF and ON positions.</p> <p>Does ohmmeter read open with switch in OFF position, and continuity with switch in ON position?</p>	<p>YES: Indicator lamp or controller has failed. Replace.</p> <p>NO: Harness has failed. Repair.</p>
---	---	--

9015
15
55

--1/1

<p>WORK MODE SELECTION SWITCH (S7), DIG MODE INDICATOR LIGHT (H1), GRADING MODE INDICATOR LIGHT (H2), PRECISION MODE INDICATOR LIGHT (H3) AND ATTACHMENT MODE INDICATOR LIGHT (H4) CHECK</p>	<p>Turn key switch ON.</p> <p>Push WORKMODE switch several times to cycle through all work mode selections (dig, grading precision, attachments).</p> <p>Does mode selection change when switch is pressed?</p> <p>Does each mode indicator come ON as mode is selected?</p>	<p>YES: Switch and indicators are OK.</p> <p>NO: If modes do not change, switch or monitor controller has failed. Repair or replace.</p> <p>Replace indicator lamp that does not come ON.</p>
---	--	---


--1/1

<p>AUTO IDLE SWITCH (S13) AND AUTO IDLE MODE INDICATOR LIGHT (H7) CHECK</p>	<p>Turn key switch ON.</p> <p>Push auto idle (A/I) switch.</p> <p>Does auto idle (A/I) indicator come ON?</p> <p>Push auto idle (A/I) again.</p> <p>Does auto idle (A/I) indicator go OFF?</p>	<p>YES: Switch and indicator are OK</p> <p>NO: Check indicator lamp. If lamp is OK, switch or controller has failed. Replace.</p>
--	--	---


--1/1

Sub-System Diagnostics

ALTERNATOR VOLTAGE INDICATOR LIGHT (H18) CHECK



T8322AC -UN-10OCT94



T6768CR -UN-18OCT88

B+—Battery Terminal
D+—Excitation Terminal

IMPORTANT: DO NOT start engine with jumper attached to alternator.

Key switch ON.

Engine OFF.

Disconnect wire from alternator terminal D+. Connect wire to ground.

Is alternator voltage indicator light ON?

YES: Go to next check.

NO: Check wiring harness.

Remove ground from alternator wire and reconnect to alternator terminal D+.

Start engine.

Does alternator voltage indicator light go OFF?


YES: Indicator light is OK.

NO: Check wiring harness.

9015
15
56

Sub-System Diagnostics

ENGINE COOLANT LEVEL INDICATOR LIGHT (H2O) CHECK



T7469AK -UN-14MAR91

Check coolant level in overflow recovery tank. Be sure level is between FULL and LOW marks.


Turn key switch ON.

Observe coolant level indicator.

Does indicator come ON, then go OFF 2—3 seconds later?

YES: Indicator is OK. Go to next step.

NO: Check indicator lamp.



T102542

T102542 -UN-29AUG96

A—Fluid Level Check Switch

Push fluid level check switch.

Does coolant level indicator come ON?


YES: Engine coolant level switch is OK.

NO: Go to next check.

9015
15
57

--1/1

ENGINE COOLANT LEVEL SWITCH (B6) CHECK



T7469AL -UN-14MAR91

Disconnect harness from engine coolant level switch.

Connect a jumper wire between harness connector pins.

Turn key switch ON.

Push fluid level check switch.

Does coolant indicator come ON?


YES: Engine coolant level switch has failed. Replace.

NO: Check wiring harness.

--1/1

Sub-System Diagnostics

ENGINE OIL LEVEL INDICATOR LIGHT (H19) CHECK



T7469AM -UN-11MAR91

T101681 -UN-29AUG96

Check oil level in engine pan, be sure level is between FULL and ADD marks on dip stick.


Turn key switch ON.

Observe engine oil level indicator.

Does indicator come ON then go OFF 2—3 seconds later?

YES: Indicator is OK. Go to next step.

NO: Check indicator lamp.



T102542

T102542 -UN-29AUG96

A—Fluid Level Check Switch

Push fluid level check switch.

Does engine oil level indicator come ON?


YES: Engine oil level switch is OK.

NO: Go to next check.

9015
15
58

Sub-System Diagnostics

ENGINE OIL LEVEL SWITCH (B7) CHECK



T7470AH -UN-11MAR91

Disconnect harness from engine oil level switch.

Connect a jumper wire to ground.

Turn key switch ON.

Push fluid level check switch.

Does engine oil level indicator come ON?

YES: Engine oil level switch has failed. Replace.


NO: Check wiring harness.

---1/1

9015
15
59

Sub-System Diagnostics

HYDRAULIC OIL LEVEL INDICATOR LIGHT (H12) CHECK



T7470AI -UN-11MAR91

T101683 -UN-29AUG96

Check oil level in hydraulic reservoir. Be sure level is between red lines on sight gauge.


Turn key switch ON.

Observe hydraulic oil level indicator.

Does indicator come ON then go OFF 2—3 seconds later?

YES: Indicator is OK. Go to next step.

NO: Check indicator lamp.



T102542

T102542 -UN-29AUG96

A—Fluid Level Check Switch

Push fluid level check switch.


Does hydraulic oil level indicator come ON

YES: Hydraulic oil level switch is OK.

NO: Go to next check.


9015
15
60

Sub-System Diagnostics


<p>HYDRAULIC OIL LEVEL SWITCH (B5) CHECK</p>	 <p>T7470AJ -UN-05MAR91</p> <p>Disconnect harness from hydraulic oil level switch.</p> <p>Connect a jumper wire between harness connector pins.</p> <p>Turn key switch ON.</p> <p>Push fluid level check switch.</p> <p>Does hydraulic oil level indicator come ON?</p>	<p>YES: Hydraulic oil level switch has failed. Replace.</p> <p>NO: Check wiring harness.</p> <p style="text-align: right;">--1/1</p>
---	--	--


<p>HYDRAULIC OIL FILTER RESTRICTION INDICATOR LIGHT (H21) CHECK</p>	<p>Turn key switch ON.</p> <p>Observe hydraulic oil filter restriction indicator.</p> <p>Does indicator come ON when key switch is turned ON, then go OFF 2—3 seconds later?</p>	<p>YES: Indicator is OK. Go to next check.</p> <p>NO: If indicator does not come ON, check indicator lamp.</p> <p>If indicator does not go OFF, go to next check.</p> <p style="text-align: right;">--1/1</p>
--	--	---


9015
15
61


<p>HYDRAULIC OIL FILTER RESTRICTION SWITCH (B30) CHECK</p>	 <p>T118382 T118382 -UN-21NOV98</p> <p>Disconnect two harness leads from hydraulic oil filter restriction switch.</p> <p>If indicator was ON, did it go OFF with leads disconnected and key switch ON?</p> <p>If indicator was OFF, connect two harness leads together.</p> <p>Does indicator come ON?</p>	<p>YES: Hydraulic oil filter restriction switch has failed. Replace.</p> <p>NO: Check harness.</p> <p style="text-align: right;">--1/1</p>
---	--	--

Sub-System Diagnostics


<p>ENGINE COOLANT TEMPERATURE INDICATOR LIGHT (H16) CHECK</p>	 <p>T101686 -UN-29AUG96</p> <p>With engine cool, turn key switch ON.</p> <p>Observe engine temperature indicator.</p> <p>Does indicator come ON when key switch is turned ON, then go OFF 2—3 seconds later?</p>	<p>YES: Indicator is OK. Go to next check.</p> <p>NO: If indicator does not come ON, check indicator lamp.</p> <p>If indicator does not go OFF, go to next check.</p> <p style="text-align: right;">-- -1/1</p>
--	---	---

<p>9015 15 62</p> <p>ENGINE COOLANT TEMPERATURE SWITCH (B3) CHECK</p>	 <p>T7470AM -UN-05MAR91</p> <p>Disconnect harness from engine coolant temperature switch.</p> <p>If engine coolant temperature indicator was ON, did it go OFF with harness disconnected and key switch ON?</p> <p>If indicator was OFF, connect a jumper wire between harness connector pins.</p> <p>Does indicator come ON when key switch is ON?</p>	<p>YES: Engine coolant temperature switch has failed. Replace.</p> <p>NO: Check harness.</p> <p style="text-align: right;">-- -1/1</p>
--	--	--

<p>CHARGE AIR TEMPERATURE INDICATOR LIGHT (H15) CHECK</p>	 <p>T107672 T113692 -UN-24FEB98</p> <p>Turn key switch ON.</p> <p>Observe charge air temperature indicator.</p> <p>Does indicator come ON when key switch is turned ON, then go OFF 2—3 seconds later?</p>	<p>YES: Indicator is OK. Go to next check.</p> <p>NO: If indicator does not come ON, check indicator lamp.</p> <p>If indicator does not go OFF, go to next check.</p> <p style="text-align: right;">-- -1/1</p>
--	---	---

<p>CHARGE AIR TEMPERATURE SWITCH (B12) CHECK</p>	 <p>T7470AM -UN-05MAR91</p> <p>Disconnect harness from charge air temperature switch.</p> <p>If indicator was ON, did it go OFF with harness disconnected and key switch ON?</p> <p>If indicator was OFF, connect a jumper wire between harness connector pins.</p> <p>Does indicator come ON when key switch is ON?</p>	<p>YES: Charge air temperature switch has failed. Replace.</p> <p>NO: Check harness.</p> <p style="text-align: right;">-- -1/1</p>
---	---	--


Sub-System Diagnostics

<p>ENGINE OIL PRESSURE INDICATOR LIGHT (H17) CHECK</p>	 <p>T101684 -UN-29AUG96</p> <p>Disconnect harness from engine oil pressure switch.</p> <p>Turn key switch ON and observe engine oil pressure indicator.</p> <p>Does indicator come ON when key switch is turned ON, then go OFF 2—3 seconds later?</p>	<p>YES: Indicator is OK. Go to next check.</p> <p>NO: If indicator does not come ON, check indicator lamp.</p> <p>If indicator does not go OFF, check harness for short.</p> <p style="text-align: right;">-- 1/1</p>
<p>ENGINE OIL PRESSURE SWITCH (B4) CHECK</p>	<p>Connect harness to engine oil pressure switch.</p> <p>Does indicator come ON with key switch ON?</p> <hr/> <p>Start engine.</p> <p>Observe engine oil pressure indicator.</p> <p>Does indicator go OFF?</p>	<p>YES: Go to next step.</p> <p>NO: Check harness for open. If harness is OK, replace switch.</p> <hr/> <p>YES: Engine oil pressure switch is OK.</p> <p>NO: Engine oil pressure switch has failed. Replace.</p> <p style="text-align: right;">-- 1/1</p>
<p>AIR FILTER RESTRICTION INDICATOR LIGHT (H14) CHECK</p>	<p>Turn key switch ON.</p> <p>Observe air filter restriction indicator.</p> <p>Does indicator come ON when key switch is turned ON, then go OFF 2—3 seconds later?</p>	<p>YES: Indicator is OK. Go to next check.</p> <p>NO: If indicator does not come ON, check indicator lamp.</p> <p>If indicator does not go OFF, go to next check.</p> <p style="text-align: right;">-- 1/1</p>

9015
15
63

Sub-System Diagnostics

AIR FILTER RESTRICTION SWITCH (B1) CHECK



T118382
T118382 -UN-21NOV98

Disconnect two harness leads from air filter restriction switch.

If indicator was ON, did it go OFF with leads disconnected and key switch ON?

If indicator was OFF, connect two harness leads together.

Does indicator come ON when key switch is ON?


YES: Air filter restriction switch has failed. Replace.

NO: Check harness.

--1/1

9015
15
64

FUEL GAUGE (P3) CHECK



T118389 -UN-30NOV98

Disconnect 20-pin harness connector from monitor display and controller connector.

Connect 24 volts to 20-pin monitor display and controller terminal 30.

Then ground terminal 46.

Does gauge needle point to "E" with 24 volts applied to terminal 30, and "F" with terminal 46 grounded?


YES: Gauge and gauge resistor are OK. Go to fuel level sender (B8) check.

NO: Go to next check.

--1/1

Sub-System Diagnostics

**FUEL GAUGE RESISTOR
(220 OHMS) (R5) CHECK**



T118391

T118391 -UN-21NOV98

NOTE: Check fuel gauge before checking resistor. Resistor is located on bottom of monitor controller panel. Access resistor by removing bottom cover from monitor controller panel.

Connect ohmmeter to resistor terminals.

Does ohmmeter read about 220 ohms?


YES: Gauge has failed.
Replace.

NO: Resistor has failed.
Replace.

--1/1

9015
15
65

**FUEL LEVEL SENSOR
(B8) CHECK**



T7472AE -UN-11MAR91

T7472AD -UN-11MAR91

NOTE: Check fuel gauge before checking sender.

Disconnect harness from fuel level sender.

Observe fuel gauge.

Does gauge needle go to "E"?

Connect jumper wire between harness connector pins.

Does gauge needle go to "F"?

YES: Sender has failed.
Replace.


NO: Check harness.

--1/1


Sub-System Diagnostics

<p>FUEL LEVEL INDICATOR LIGHT (H13) CHECK</p>	<p>With adequate fuel in tank, turn key switch ON.</p> <p>Observe fuel level indicator.</p> <p>Does indicator come ON when key switch is turned ON, then go OFF 2—3 seconds later?</p>	<p>YES: Indicator is OK. Go to next check.</p> <p>NO: If indicator does not come ON, check indicator lamp.</p> <p>If indicator does not go OFF, go to next check.</p> <p style="text-align: right;">-- -1/1</p>
--	--	---

<p>FUEL LEVEL SWITCH (B2) CHECK</p>	<p>Disconnect harness from fuel level switch.</p> <p>If indicator was ON, did it go OFF with harness disconnected and key switch ON?</p> <p>If indicator was OFF, connect a jumper wire between harness connector pins.</p> <p>Does indicator come ON when key switch is ON?</p>	<p>YES: Fuel level switch has failed. Replace.</p> <p>NO: Check harness.</p> <p style="text-align: right;">-- -1/1</p>
--	--	--


<p>ENGINE COOLANT TEMPERATURE GAUGE (P2) CHECK</p>	<div style="text-align: center;">  <p>T118390 T118390 -UN-21NOV98</p> </div> <p>Disconnect 20-pin harness connector from monitor display and controller connector.</p> <p>Connect 24 volts to 20-pin monitor display and controller terminal 30.</p> <p>Then ground terminal 47.</p> <p>Does gauge needle point to "C" with 24 volts applied to terminal 30, and "H" with terminal 47 grounded?</p>	<p>YES: Gauge and gauge resistor are OK. Go to engine coolant temperature sender (B9) check.</p> <p>YES: Go to next check.</p> <p style="text-align: right;">-- -1/1</p>
---	---	--

Sub-System Diagnostics

<p>ENGINE COOLANT TEMPERATURE GAUGE RESISTOR (150 OHMS) (R4) CHECK</p>	 <p>T118391 T118391 -UN-21NOV98</p> <p><i>NOTE: Check engine coolant temperature gauge before checking resistor. Resistor is located on bottom of the monitor controller panel. Access resistor by removing bottom cover from monitor controller panel.</i></p> <p>Connect ohmmeter to resistor terminals.</p> <p>Does ohmmeter read about 220 ohms?</p>	<p>YES: Gauge has failed. Replace.</p> <p>NO: Gauge resistor has failed. Replace.</p>
---	--	---

9015
15
67

--1/1

<p>ENGINE COOLANT TEMPERATURE SENSOR (B9) CHECK</p>	 <p><i>NOTE: Check engine coolant temperature gauge before checking resistor.</i></p> <p>Disconnect harness from temperature sender.</p> <p>Connect ohmmeter to sender and ground.</p> <p>Start engine and observe ohmmeter.</p> <p>Does ohmmeter reading decrease as engine becomes warmer?</p> <p>T8359AJ -UN-10NOV94</p>	<p>YES: Sender is OK. Check harness.</p> <p>NO: Sender has failed. Replace.</p>
--	---	---

--1/1

*Sub-System Diagnostics***ENGINE AND PUMP CONTROLLER CIRCUIT
OPERATIONAL INFORMATION**

The following conditions must be met for the circuit to function:

Key switch ON and voltage present at the following:

- Engine and pump controller connector terminals B7, D1, D2, A1, and A13
- Relay K10 terminal 1

9015
15
68

CED,TX14795,4140 -19-12AUG98-1/1

*Sub-System Diagnostics***ENGINE AND PUMP CONTROLLER CIRCUIT THEORY OF OPERATION**

The engine and pump controller (EPC) A2 monitors and controls engine speed and all digging functions, propel functions, hydraulic pump functions, and pilot functions.

The EPC applies service codes from EPC terminals B8, B15, and B16 to diagnostic connector X1 for analysis of hydraulic and electrical systems by the diagnostic computer.

ENGINE CONTROL CIRCUITS**ENGINE SPEED CONTROL**

The engine speed control circuits monitor and adjust the engine speed to match the operating modes selected. The engine and pump controller (EPC) monitors the engine speed via signals from the engine speed sensor (B16) applied to EPC terminals B6 and B13. The EPC controls the engine speed by sending rotation control signals to the engine control (EC) motor (M2) from terminals A12, A24, A25, and A26. The EC motor is mechanically linked to the engine throttle linkage. As the motor rotates, the engine throttle linkage is moved, changing the engine speed. The engine control (EC) sensor (B17) provides a signal to EPC at terminal D15 indicating the amount of EC motor rotation.

When the engine is started, the dig hydraulic work mode is selected by logic circuit in the monitor controller. Each time work mode select switch is pushed a different work mode is selected (Dig, Grading, Precision, and Attachment).

Operating mode selection signals from the monitor controller and display are applied to EPC terminals B11, D3, D4, D5, and D6. The combination of signals instructs the EPC which mode has been selected.

When an operating mode is changed, the EPC causes the EC motor to rotate, changing the engine speed. When the engine speed matches the requirement for the mode selected, the EC motor stops rotating and the engine speed remains constant. If another mode is selected, the process is repeated until the engine speed has changed to match the new mode speed requirement.

AUTO A/I IDLE MODE

An RPM dial is provided to vary engine speed to any speed between slow idle and fast idle if E or HP modes do not provide a speed adequate to the job. Each time the engine is started, the EPC automatically activates the idle mode to run the engine at the engine rpm dial setting.

When the auto idle mode is activated by the auto idle switch, a signal from the monitor controller is applied to EPC terminal D6 informing the EPC that auto idle is selected. With auto idle selected, mode switches E and HP control engine speed during machine operation. However, if a hydraulic function is not used for more than 4 seconds, the EPC automatically reduces the engine speed to auto idle.

LEARNING SWITCH (S16)

If the engine and pump controller or EC sensor is changed, the EPC learning sequence must be activated the next time engine is started. The learning switch activates the EPC learning sequence by applying a ground to EPC terminal B5. When the switch is activated, the slow idle engine speed is registered in the EPC memory. After maximum power engine speed is stored in EPC memory, the EPC calculates the economy mode (E) speed as a percentage of the slow idle speed.

9015
15
69

*Sub-System Diagnostics***HYDRAULIC CONTROL CIRCUITS**

The hydraulic control circuits consist of pressure sensors and switches, proportional control solenoids, and power boost switch. The EPC utilizes input signals from the pressure sensors and switches to monitor the machine hydraulic functions. It then controls the propel speed, relief valve pressure, pump swash, and arm regenerative functions by sending control signals to the

propel speed, power boost, speed sense, and arm regenerative proportional solenoids.

These circuits control the hydraulic functions of the machine at the same time the EPC is controlling engine speed to provide maximum machine quickness and productivity for the load conditions and operating mode selected.

CED,OUOE012,33 -19-05NOV98-2/2

9015
15
70

FOLDOUT PAGE 4-136 IS AT REAR OF MANUAL

Sub-System Diagnostics

1 ENGINE AND PUMP CONTROLLER CIRCUIT DIAGNOSTIC PROCEDURES

IMPORTANT: Do not disconnect electrical connectors while the engine is running. Damage to Engine and Pump Controller or other components may result. Disconnect connectors only when instructed during a test or check.

NOTE: Before troubleshooting the circuits, clean all terminals in the engine and pump controller, and harness connectors using a non-conductive lubricating contact cleaner, then try the circuit operation again before proceeding. TY16324 Contact Cleaner can be used.

---1/1

9015
15
72

<p>ENGINE AND PUMP CONTROLLER 10 AMP FUSE (F2) CHECK</p>	<p>Turn key switch OFF.</p> <p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK. Check wiring harness</p> <p>NO: Replace Fuse. If fuse blows again, check for short.</p>
---	--	---

---1/1

<p>POWER ON FUSE 10 AMP (F5) CHECK</p>	<p>Turn key switch OFF.</p> <p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK. Check wiring harness</p> <p>NO: Replace Fuse. If fuse blows again, check for short.</p>
---	--	---


---1/1

<p>ENGINE CONTROL (EC) MOTOR 10 AMP FUSE (F3) CHECK</p>	<p>Turn key switch OFF.</p> <p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK. Check wire from fuse to monitor controller connector D, pins 1 and 2. If OK, go to next check.</p> <p>NO: Replace Fuse. If fuse blows again, check for short.</p>
--	--	---

---1/1

Sub-System Diagnostics


<p>SOLENOID 5 AMP FUSE (F4) CHECK</p>	<p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK. Check wiring harness</p> <p>NO: Replace Fuse. If fuse blows again, check for short.</p> <p style="text-align: right;">--1/1</p>
--	--	---

<p>ENGINE CONTROL (EC) MOTOR (M2) CHECK</p>	<div style="text-align: center;">  </div> <p>T118380 T118380 -UN-21NOV98</p> <p>Disconnect harness from EC motor.</p> <p>Measure resistance between pin 1 and pin 3, and between pin 2 and pin 4.</p> <p>Does ohmmeter read approximately the same resistance for both measurements?</p>	<p>YES: EC motor is OK. Go to next check.</p> <p>NO: Motor has failed. Replace.</p> <p style="text-align: right;">--1/1</p>
--	--	---

9015
15
73

Sub-System Diagnostics

ENGINE CONTROL (EC) MOTOR (M2) HARNESS CHECK



T118393 -UN-30NOV98

Disconnect harness from EC motor.

Disconnect 26-pin connector A from engine and pump controller.

Measure continuity from pin 1 in EC motor connector to pin 24 in connector A.

Measure continuity from pin 2 in EC motor connector to pin 25 in connector A.

Measure continuity from pin 3 in EC motor connector to pin 12 in connector A.

Measure continuity from pin 4 in EC motor connector to pin 26 in connector A.


Does ohmmeter read approximately the same resistance in all 4 measurements?

YES: EC motor harness is OK. Go to next check.

NO: Repair open wire.

--1/1

ENGINE CONTROL (EC) SENSOR (B17) CHECK



T118392

T118392 -UN-21NOV98

1—Positive Terminal

2—Sense Terminal

3—Negative Terminal

Disconnect harness from EC sensor.

Measure resistance of sensor from connector pin 1 to pin 3, and pin 1 to Pin 2.

Does ohmmeter read 2000 ± 400 ohms from pin 1 to pin 3 and something less than that from pin 1 to pin 2?

YES: EC Sensor is OK. Go to next check.


NO: Sensor has failed. Replace.

--1/1

9015
15
74

Sub-System Diagnostics

ENGINE CONTROL (EC) SENSOR (B17) HARNESS CHECK



T118488
T118488 -UN-21NOV98

- 1—Positive Terminal
- 2—Sense Terminal
- 3—Negative Terminal

Turn key switch OFF.

Disconnect harness from EC sensor.


Turn key switch ON.

Measure voltage between pin 1 and pin 3 of EC sensor harness connector.

Is 5 volts measured?

YES: Go to next step.

NO: Harness has failed. Repair.



T118379 -19-30NOV98

- 1—Positive Terminal
- 2—Sense Terminal
- 3—Negative Terminal

Turn key switch OFF.

Disconnect harness from EC sensor.

Connect jumper wire between sensor harness connector pins 1 and 2.

Disconnect 22-pin connector D and 16-pin connector B from engine and pump controller.

Measure continuity between pin 9 of connector B and pin 15 of connector D.


Is continuity measured?

YES: Harness is OK.

NO: Harness has failed. Repair.


9015
15
75

Sub-System Diagnostics

<p>ENGINE SPEED (N) SENSOR (B16) CHECK</p>	 <p>T7502BM -UN-01APR91</p> <p>Turn key switch OFF.</p> <p>Disconnect harness from engine speed sensor.</p> <p>Measure resistance across speed sensor connector pins 1 and 2.</p> <p>Does ohmmeter read 810 ± 240 ohms?</p> <p>Start engine.</p> <p>Measure AC voltage at speed sensor terminals. Increase engine speed.</p> <p>Does AC voltage increase as engine speed increases?</p>	<p>YES: Sensor is OK. Go to next check.</p> <p>NO: Sensor has failed. Replace.</p>
---	---	--

-- -1/1


9015
15
76

<p>ENGINE SPEED (N) SENSOR (B16) HARNESS CHECK</p>	 <p>T118373</p> <p>T118373 -19-30NOV98</p> <p>Turn key switch OFF.</p> <p>Disconnect harness from engine speed sensor.</p> <p>Disconnect 16-pin connector B from engine and pump controller.</p> <p>Measure continuity between pins 6 and 13 of connector B.</p> <p>Does ohmmeter read open?</p> <p>Connect jumper wire between sensor harness connector pins 1 and 2.</p> <p>Is continuity measured?</p>	<p>YES: Harness is OK.</p> <p>NO: Harness has failed. Repair.</p>
---	--	---

-- -1/1

Sub-System Diagnostics

**ECONOMY (E) MODE
OUTPUT TO ENGINE
AND PUMP
CONTROLLER HARNESS
CHECK**



T118394

T118394 -19-30NOV98

Disconnect 16-pin harness connector from monitor controller and display, and 22-pin harness connector D from engine and pump controller.

Measure continuity between pin 15 of monitor controller harness connector and pin 5 of engine and pump controller harness connector D.

Is continuity measured?


YES: Harness wire is OK.

NO: Harness wire is open. Repair.

--1/1

9015
15
77

**HIGH POWER (HP)
MODE OUTPUT TO
ENGINE AND PUMP
CONTROLLER HARNESS
CHECK**



T118376

T118376 -19-30NOV98

Disconnect 16-pin harness connector from monitor controller and display, and 16-pin harness connector B from engine and pump controller.

Measure continuity between pin 23 of monitor controller harness connector and pin 11 of engine and pump controller harness connector B.

Is continuity measured?


YES: Harness wire is OK.

NO: Harness wire is open. Repair.

--1/1

Sub-System Diagnostics

MODE 1 OUTPUT TO ENGINE AND PUMP CONTROLLER HARNESS CHECK



T118395

T118395 -19-30NOV98

Disconnect 16-pin harness connector from monitor controller and display, and 22-pin harness connector D from engine and pump controller.

Measure continuity between pin 21 of monitor controller harness connector and pin 3 of engine and pump controller harness connector D.


Is continuity measured?

YES: Harness wire is OK.
Go to next check.

NO: Harness wire is open. Repair.

---1/1

MODE 2 OUTPUT TO ENGINE AND PUMP CONTROLLER HARNESS CHECK



T118396

T118396 -19-30NOV98

Disconnect 16-pin harness connector from monitor controller and display, and 22-pin harness connector D from engine and pump controller.

Measure continuity between pin 22 of monitor controller harness connector and pin 4 of engine and pump controller harness connector D.

Is continuity measured?

YES: Harness wire is OK.


NO: Harness wire is open. Repair.

---1/1

9015
15
78

Sub-System Diagnostics

**AUTO IDLE TO SYSTEM
CONTROLLER HARNESS
CHECK**



T118381

T118381 -19-21NOV98

Disconnect 16-pin harness connector from monitor controller, and 22-pin harness connector D from engine and pump controller.

Measure continuity between pin 13 of monitor controller harness connector and pin 6 of engine and pump controller harness connector D.

Is continuity measured?


YES: Harness wire is OK.

NO: Harness wire is open. Repair.

--1/1

9015
15
79

**ENGINE RPM DIAL (R10)
CHECK**



T118383

T118383 -UN-17MAR99

Disconnect harness connector from engine mode and rpm control unit.

Measure resistance from engine mode and RPM control unit terminal 5 to terminal 7, and from terminal 5 to terminal 6.

Is 5000 ± 500 ohms measured from terminal 5 to terminal 7, and less than that from terminal 5 to terminal 6?


YES: Engine RPM dial is OK. Go to next check.

NO: Engine RPM dial has failed. Replace.

--1/1

Sub-System Diagnostics

**ENGINE RPM DIAL (R10)
HARNESS CHECK**



T118397
T118397 -19-30NOV98

Disconnect 16-pin harness connector B and 22-pin harness connector D from engine and pump controller.

Disconnect harness connector from engine mode and RPM control unit A4.

Measure continuity from pin 5 of engine mode and RPM control unit harness connector to pin 9 of engine and pump controller harness connector B.

Measure continuity from pin 7 of engine mode and RPM control unit harness connector to pin 22 of engine and pump controller harness connector D.

Measure continuity from pin 6 of engine mode and RPM control unit harness connector to pin 21 of engine and pump controller harness connector D.

Is continuity measured?

YES: Engine rpm dial harness is OK.


NO: Harness had failed. Repair.

9015
15
80

Sub-System Diagnostics

POWER BOOST SWITCH (S19) CHECK

CONTROLLER-B



T118538

T118538 -19-21NOV98

Turn key switch OFF.

Disconnect 16-pin harness connector B from engine and pump controller.


Connect ohmmeter from pin 4 of harness connector B to ground.

Press power boost switch.

Does ohmmeter read continuity when switch is pressed?

YES: Switch and harness are OK.

NO: Go to next step.



T118486

T118486 -UN-21NOV98

Remove right console bottom cover.

NOTE: Do not disconnect wires other than power boost wires.

Disconnect two leads from power boost switch.

Connect ohmmeter to both leads from switch.

Press switch button.

Does ohmmeter read continuity?


YES: Switch is OK. Check harness wiring.

NO: Switch has failed. Replace.

9015
15
81

Sub-System Diagnostics

**ARM IN PRESSURE
SENSOR (B20)
HARNESS CHECK**



T118372

T118372 -UN-21NOV98

- 1—Positive Terminal
- 2—Sense Terminal
- 3—Negative Terminal

Turn key switch OFF.

Disconnect harness from arm in pressure sensor.


Connect voltmeter to sensor harness connector pin 1 and ground.

Turn key switch ON.

Does voltmeter read 5 volts?

YES: Harness wire is OK.
Go to next step.

NO: Wire or engine and
pump controller has
failed. Repair.



T118371

T118371 -UN-21NOV98

- 1—Positive Terminal
- 2—Sense Terminal
- 3—Negative Terminal

Turn key switch OFF.

Connect ohmmeter to sensor harness connector pin 3 and ground.


Does ohmmeter read continuity?

YES: Harness wire is OK.
Go to next step.

NO: Wire has failed.
Repair.

9015
15
82

Sub-System Diagnostics



T118358

T118358 -19-21NOV98

Install jumper between sensor harness connector pins 1 and 2.

Disconnect 22-pin connector D and 16-pin connector B from engine and pump controller.

Measure continuity between pin 9 of harness connector B and pin 18 of harness connector D.

Is continuity measured?

YES: Wire harness is OK. Go to next check.

NO: Wire from pin 18 of connector D to pin 2 of sensor harness connector has failed. Repair.

9015
15
83

--2/2

ARM IN PRESSURE SENSOR (B20) CHECK

Install pump control test harness JT07353 in series with wiring harness and sensor.

Connect voltmeter to test harness jacks.

With engine running, pilot control lever forward, and hydraulic functions in neutral, observe voltage.

Is voltage between 0.5 and 0.7 volts?

Actuate arm in to achieve hydraulic function over relief.

Does voltage increase to between 3.3 and 3.5 volts with hydraulic function over relief?


YES: Sensor is OK. Engine and pump controller may have failed.

NO: Sensor has failed. Replace.

--1/1

Sub-System Diagnostics

REAR PUMP CONTROL PRESSURE SENSOR (B21) AND FRONT CONTROL PRESSURE SENSOR (B22) HARNESS CHECK



T118372

T118372 -UN-21NOV98

- 1—Positive Terminal
- 2—Sense Terminal
- 3—Negative Terminal

Turn key switch OFF.

Disconnect wiring harness connector from front (B22) or rear (B21) pump control pressure sensor.


Connect voltmeter to sensor harness connector pin 1 and ground.

Turn key switch ON.

Does voltmeter read 5 volts?

YES: Harness wire is OK.
Go to next step.

NO: Wire or engine and pump controller has failed. Repair.



T118371

T118371 -UN-21NOV98

- 1—Positive Terminal
- 2—Sense Terminal
- 3—Negative Terminal

Turn key switch OFF.

Connect ohmmeter to sensor harness connector pin 3 and ground.


Does ohmmeter read continuity?

YES: Harness wire is OK.
Go to next step.

NO: Wire has failed.
Repair.

9015
15
84

Sub-System Diagnostics



T118359

T118359 -19-21NOV98

Install jumper between sensor harness connector pins 1 and 2.

Disconnect 22-pin connector D and 16-pin connector B from engine and pump controller.

Measure continuity between pin 9 of harness connector B and pin 19 of harness connector D (for front pressure sensor), or pin 14 of harness connector D (for rear pressure sensor) .

Is continuity measured?

YES: Wire harness is OK. Go to next check.

NO: Wire from connector D to sensor harness connector pin 2 has failed. Repair.

9015
15
85

--2/2

REAR PUMP CONTROL PRESSURE SENSOR (B21) AND FRONT CONTROL PRESSURE SENSOR (B22) CHECK

Install pump control test harness JT07353 in series with wiring harness and sensor.

Connect voltmeter to test harness jacks.

With engine running, pilot control lever forward, and hydraulic functions in neutral, observe voltmeter.

Is voltage 0.5 - 0.7 volts?

Slowly actuate boom up (for front pressure sensor B22) or left track (for rear pressure sensor B21) until motion just begins.

Does voltage increase to 3.3 - 3.5 volts when pilot controller reaches full activation?


YES: Sensor is OK. Engine and pump controller may have failed.

NO: Sensor has failed. Replace.

--1/1

Sub-System Diagnostics

REAR PUMP PRESSURE SENSOR (B18) AND FRONT PUMP PRESSURE SENSOR (B19) SENSOR HARNESS CHECK



T118369

T118369 -UN-21NOV98

- 1—Positive Terminal
- 2—Sense Terminal
- 3—Negative Terminal

Turn key switch OFF.

Disconnect wiring harness connector from front (B19) or rear (B18) pump pressure sensor.


Connect voltmeter to sensor harness connector pin 1 and ground.

Turn key switch ON.

Does voltmeter read 5 volts?

YES: Harness wire is OK. Go to next step.

NO: Wire or engine and pump controller has failed. Repair.



T118368

T118368 -UN-21NOV98

- 1—Positive Terminal
- 2—Sense Terminal
- 3—Negative Terminal

Turn key switch OFF.

Connect ohmmeter to sensor harness connector pin 3 and ground.


Does ohmmeter read continuity?

YES: Harness wire is OK. Go to next step.

NO: Wire has failed. Repair.

9015
15
86

Sub-System Diagnostics



T118370

T118370 -19-21NOV98

- 1—Positive Terminal
- 2—Sense Terminal
- 3—Negative Terminal

Install jumper between sensor harness connector pins 1 and 2.

Disconnect 22-pin connector D and 16-pin connector B from engine and pump controller.

Measure continuity between pin 9 of harness connector B and pin 16 of harness connector D (for front pressure sensor), or pin 17 of harness connector D (for rear pressure sensor) .

Is continuity measured?

YES: Wire harness is OK. Go to next check.

NO: Wire from connector D to sensor harness connector pin 2 has failed. Repair.

9015
15
87

--2/2

REAR PUMP PRESSURE SENSOR (B18) AND FRONT PUMP PRESSURE SENSOR (B19) CHECK

Install pump pressure sensor test harness JT07354 in series with wiring harness and sensor.

Connect voltmeter to test harness jacks.

With engine running, pilot control lever forward, and hydraulic functions in neutral, observe voltmeter.

Is voltage 0.5 - 0.7 volts?

Actuate arm in to achieve hydraulic function over relief.




Does voltage increase to 3.3 - 3.5 volts with hydraulic function over relief?

YES: Sensor is OK. Engine and pump controller may have failed.

NO: Sensor has failed. Replace.


--1/1

Sub-System Diagnostics

<p>BOOM UP PRESSURE SWITCH (B13) CHECK</p>	 <p>T112437 T112437 -UN-05DEC97</p> <p>Turn key switch OFF.</p> <p>Disconnect wiring harness at boom up pressure switch.</p> <p>Connect ohmmeter to pins 1 and 2 of pressure switch connector.</p> <p>With engine running and pilot control lever forward, actuate boom up lever.</p> <p>Is continuity measured when boom up lever is actuated?</p>	<p>YES: Pressure switch is OK. Check switch harness. If harness is OK, engine and pump controller may have failed.</p> <p>NO: Boom up pressure switch has failed. Replace.</p> <p style="text-align: right;">-- -1/1</p>
<p>DIG PRESSURE SWITCH (B14) CHECK</p>	 <p>T112437 T112437 -UN-05DEC97</p> <p>Turn key switch OFF.</p> <p>Disconnect wiring harness at dig pressure switch.</p> <p>Connect ohmmeter to pins 1 and 2 of pressure switch connector.</p> <p>With engine running and pilot control lever forward, slowly actuate arm in lever while observing ohmmeter.</p> <p>Is continuity measured as arm in lever is actuated?</p>	<p>YES: Pressure switch is OK. Check switch harness. If harness is OK, engine and pump controller may have failed.</p> <p>NO: Dig pressure switch has failed. Replace.</p> <p style="text-align: right;">-- -1/1</p>
<p>PROPEL PRESSURE SWITCH (B15) CHECK</p>	 <p>T112437 T112437 -UN-05DEC97</p> <p>Turn key switch OFF.</p> <p>Disconnect wiring harness at propel pressure switch.</p> <p>Connect ohmmeter to pins 1 and 2 of pressure switch connector.</p> <p>With engine running and pilot control lever forward, slowly actuate propel lever while observing ohmmeter.</p> <p>Is continuity measured as propel lever is actuated and track begins to move?</p>	<p>YES: Pressure switch is OK. Check for continuity from harness connector pin 1 to ground. If OK, go to next check.</p> <p>NO: Propel pressure switch has failed. Replace.</p> <p style="text-align: right;">-- -1/1</p>

9015
15
88

Sub-System Diagnostics

<p>PROPEL AUTO IDLE RELAY (K10) CHECK</p>	 <p>T7447BG -19-14JAN91</p> <p>1—24-Volt Terminal 2—Ground Terminal 3—Relay Common 4—Relay Normally Closed 5—Relay Normally Open</p> <p>Disconnect relay from harness.</p> <p>Connect ohmmeter to relay terminals 3 and 4.</p> <p>Does ohmmeter read continuity?</p> <p>Connect 24 volts to relay terminal 1, and ground terminal 2.</p> <p>Does relay “click”?</p> <p>With 24 volts still connected to terminal 1, connect ohmmeter to terminals 3 and 5.</p> <p>Does ohmmeter read continuity?</p>	<p>YES: Relay is OK.</p> <p>NO: Relay has failed. Replace.</p>
--	---	--

9015
15
89


--1/1

<p>TRAVEL ALARM 5 AMP FUSE (F10) CHECK</p>	<p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK. Go to next check.</p> <p>NO: Replace Fuse. If fuse blows again, check for short.</p>
---	--	--

--1/1

Sub-System Diagnostics

PROPEL AUTO IDLE RELAY (K10) HARNESS CHECK



T118561

T118561 -UN-21NOV98

Turn key switch OFF.

Remove harness connector from relay

With ohmmeter measure continuity from relay harness connector pin 5 to ground.

Is continuity measured?


Connect voltmeter from relay harness connector pin 1 to ground.

Turn key switch to ON and measure voltage at pin 1.

Is 24 volts measured?

YES: Wire are OK. Go to next step.

NO: Wire has failed. Repair.



T118362

T118362 -UN-21NOV98

- 1—24-Volt Terminal
- 2—Ground Terminal
- 3—Relay Common
- 4—Relay Normally Closed
- 5—Relay Normally Open

Turn key switch OFF.

Disconnect wiring harness at propel pressure switch.

NOTE: Use "diode checking mode" on meter when checking this reading.

Connect an ohmmeter to relay harness connector pin 2 and pressure switch connector pin 1.

Measure resistance, then reverse ohmmeter probes and measure resistance again.


Does resistance read approximately 500 ohms in one direction, and open in the other direction?

YES: Wire and isolation diode V4 are OK. Go to next step.

NO: Check wire for open. If OK, go to diode V4 check.

9015
15
90

Sub-System Diagnostics



T102860 -UN-12AUG96

- 1—24-Volt Terminal
- 2—Ground Terminal
- 3—Relay Common 5 Volts To D9
- 4—Relay Normally Closed
- 5—Relay Normally Open To Ground

Connect voltmeter to relay harness connector pin 3 and ground.

Turn key switch ON.

Does voltmeter read 5 volts.

YES: Harness is OK.


NO: Harness or engine and pump controller has failed. Repair or replace.

--2/2

9015
15
91

PROPEL AUTO IDLE RELAY ISOLATION DIODE (V4) CHECK

NOTE: A diode can fail in two modes, either shorted or open. Continuity will be measured in one direction only in a serviceable diode. Use "diode checking mode" on meter when checking continuity.



T118385
T118385 -UN-21NOV98

Remove diode from connector.

Connect an ohmmeter to diode terminals.

Is continuity measured?

Reverse ohmmeter probes.

Is continuity measured?



YES: If continuity is measured in both checks, diode has failed in a shorted mode. Replace.

NO: If continuity is NOT measured in either check, diode has failed in an open mode. Replace.

NO: If continuity is measured in one check and not the other, diode is OK.

--1/1

Sub-System Diagnostics

<p>PROPEL SPEED CHANGE PROPORTIONAL SOLENOID (Y6) CHECK</p>	 <p>T7491AC (CV) T7491AC -UN-08APR91</p> <p>Turn key switch OFF.</p> <p>Remove wire clip from bottom of solenoid harness connector.</p> <p>Disconnect harness from solenoid.</p> <p>Connect ohmmeter to solenoid terminals.</p> <p>Does ohmmeter read approximately 24 ohms?</p>	<p>YES: Solenoid is OK. Go to next check.</p> <p>NO: Solenoid has failed. Replace.</p> <p style="text-align: right;">-- -1/1</p>
<p>9015 15 92</p> <p>PROPEL SPEED CHANGE PROPORTIONAL SOLENOID (Y6) HARNESS CHECK</p>	<p>Turn key switch OFF.</p> <p>Install proportional solenoid test harness JT07352 in series with wiring harness and sense solenoid.</p> <p>Connect voltmeter to test harness jacks.</p> <p>Start engine and while observing voltmeter, drive machine at full propel speed until fast speed kicks in.</p> <p>Does voltmeter read approximately 6 volts in slow speed, and 12 volts in fast speed?</p>	<p>YES: Harness and engine and pump controller are OK.</p> <p>NO: Harness or engine and pump controller has failed. Repair or replace.</p> <p style="text-align: right;">-- -1/1</p>
<p>ARM REGENERATIVE PROPORTIONAL SOLENOID (Y9) CHECK</p>	 <p>T7491AC (CV) T7491AC -UN-08APR91</p> <p>Turn key switch OFF.</p> <p>Remove wire clip from bottom of solenoid harness connector.</p> <p>Disconnect harness from solenoid.</p> <p>Connect ohmmeter to solenoid terminals.</p> <p>Does ohmmeter read approximately 24 ohms?</p>	<p>YES: Solenoid is OK. Go to next check.</p> <p>NO: Solenoid has failed. Replace.</p> <p style="text-align: right;">-- -1/1</p>

Sub-System Diagnostics

<p>ARM REGENERATIVE PROPORTIONAL SOLENOID (Y9) HARNESS CHECK</p>	<p>Turn key switch OFF.</p> <p>Install proportional solenoid test harness JT07352 in series with wiring harness and sense solenoid.</p> <p>Connect voltmeter to test harness jacks.</p> <p>Start engine and move arm all the way out and boom down.</p> <p>Adjust idle to slow (voltmeter reading approximately 7 volts).</p> <p>Move boom up and arm in at the same time.</p> <p>Does voltmeter read higher voltage (approximately 9 volts) while boom and arm are moving?</p>	<p>YES: Harness and engine and pump controller are OK.</p> <p>NO: Harness or engine and pump controller has failed. Repair or replace.</p>
---	---	--

9015
15
93

--1/1


<p>POWER BOOST PROPORTIONAL SOLENOID (Y5) CHECK</p>	<div data-bbox="414 882 641 1144" data-label="Image"> </div> <p>Turn key switch OFF.</p> <p>Remove wire clip from bottom of solenoid harness connector.</p> <p>Disconnect harness from solenoid.</p> <p>Connect ohmmeter to solenoid terminals.</p> <p>Does ohmmeter read approximately 24 ohms?</p>	<p>YES: Solenoid is OK. Go to next check.</p> <p>NO: Solenoid has failed. Replace.</p>
--	--	--

--1/1


<p>POWER BOOST PROPORTIONAL SOLENOID (Y5) HARNESS CHECK</p>	<p>Turn key switch OFF.</p> <p>Install proportional solenoid test harness JT07352 in series with wiring harness and sense solenoid.</p> <p>Connect voltmeter to test harness jacks.</p> <p>Start engine and observe voltmeter while pressing power boost switch.</p> <p>Does voltmeter read approximately 5 volts when switch is not pressed, and approximately 9 volts when switch is pressed?</p> <p>Hold power boost switch pressed.</p> <p>Does the voltage drop to 5 volts after approximately 8 seconds?</p>	<p>YES: Harness and engine and pump controller are OK.</p> <p>NO: Harness or engine and pump controller has failed. Repair or replace.</p>
--	--	--

--1/1

Sub-System Diagnostics

<p>SPEED SENSE PROPORTIONAL SOLENOID (Y8) CHECK</p>	 <p>T7491AC (CV) T7491AC -UN-08APR91</p> <p>Turn key switch OFF.</p> <p>Remove wire clip from bottom of solenoid harness connector.</p> <p>Disconnect harness from solenoid.</p> <p>Connect ohmmeter to solenoid terminals.</p> <p>Does ohmmeter read approximately 24 ohms?</p>	<p>YES: Solenoid is OK. Go to next check.</p> <p>NO: Solenoid has failed. Replace.</p> <p style="text-align: right;">---1/1</p>
--	--	---

<p>9015 15 94</p> <p>SPEED SENSE PROPORTIONAL SOLENOID (Y8) HARNESS CHECK</p>	<p>Turn key switch OFF.</p> <p>Install proportional solenoid test harness JT07352 in series with wiring harness and sense solenoid.</p> <p>Connect voltmeter to test harness jacks.</p> <p>Start engine, set auto idle mode to OFF, and set engine idle to medium speed so that voltmeter reads approximately 5.5 volts (RPM dial set at first bar after mid range).</p> <p>Bottom arm in to load engine.</p> <p>Does voltmeter read approximately 7 volts with arm bottomed in?</p>	<p>YES: Harness and engine and pump controller are OK.</p> <p>NO: Harness or engine and pump controller has failed. Repair or replace.</p> <p style="text-align: right;">---1/1</p>
--	--	---

<p>LEARNING SWITCH (S16) CHECK</p>	 <p>T118558 T118558 -19-21NOV98</p> <p>Turn key switch OFF.</p> <p>Disconnect 16-pin connector B from engine and pump controller.</p> <p>Turn switch to ON.</p> <p>Measure continuity from pins 5 of connector B to ground.</p> <p>Is continuity measured?</p>	<p>YES: Switch and harness are OK.</p> <p>NO: Switch or harness has failed. Check and repair or replace.</p> <p style="text-align: right;">---1/1</p>
---	--	---

*Sub-System Diagnostics***TRAVEL ALARM CIRCUIT OPERATIONAL INFORMATION**

The following conditions must be met for the circuit to function:

- Key switch ON
- Voltage present at travel alarm 5-amp fuse F10

CED,OUOE012,137 -19-16MAR99-1/1

TRAVEL ALARM CIRCUIT THEORY OF OPERATION

The travel alarm circuit contains: travel alarm fuse F10, travel alarm H10, travel alarm cancel switch S17, and propel pilot pressure switch B15. Operating voltage for the travel alarm is applied from fuse F10 to travel alarm terminal B. When the propel levers are moved to forward or reverse positions, propel pressure switch


B15 senses pilot pressure and closes. With the switch closed ground is applied to terminal C of the travel alarm, activating the alarm. After the travel alarm has sounded for 10 seconds, the travel alarm cancel switch may be pushed to turn the alarm off by grounding alarm terminal A.

CED,OUOE012,37 -19-05NOV98-1/1

9015
15
95

Sub-System Diagnostics

TRAVEL ALARM CIRCUIT SCHEMATIC



TRAVEL ALARM CIRCUIT

T117932

T117932 -19-30NOV98

CED,OUOE012,38 -19-05NOV98-1/1

9015
15
96

Sub-System Diagnostics

① TRAVEL ALARM CIRCUIT DIAGNOSTIC PROCEDURES

IMPORTANT: Do not disconnect electrical connectors while the engine is running. Damage to Engine and Pump Controller or other components may result. Disconnect connectors only when instructed during a test or check.

NOTE: Before troubleshooting the circuits, clean all terminals in the engine and pump controller and harness connectors using a non-conductive lubricating contact cleaner, then try circuit operation again before proceeding. TY16324 John Deere Contact Cleaner can be used.

--1/1


<p>TRAVEL ALARM 5 AMP FUSE (F10) CHECK</p>	<p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK. Go to next check.</p> <p>NO: Replace Fuse. If fuse blows again, check for short.</p>
---	--	--

9015
15
97

--1/1

Sub-System Diagnostics

**TRAVEL ALARM (H10)
HARNESS CHECK**



T118563

T118563 -UN-21NOV98

Turn key switch OFF.

Disconnect harness connector from travel alarm.


Connect voltmeter to harness connector pin B and ground.

Turn key switch ON.

Is 24 volts measured?

YES: Go to next step.

NO: Harness has failed.
Repair.



T118562

T118562 -UN-21NOV98

Turn key switch OFF.


Disconnect harness connector from propel pressure switch.

Connect ohmmeter from travel alarm harness connector pin C to propel pressure switch harness connector pin 1.

Is continuity measured?

YES: Go to next step.

NO: Harness has failed.
Repair.



T118564

T118564 -UN-21NOV98

Connect ohmmeter from travel alarm harness connector pin D to ground.


Is continuity measured?


YES: Harness is OK. Go to next check.

NO: Harness has failed.
Repair.

9015
15
98

Sub-System Diagnostics

<p>TRAVEL ALARM (H10) CHECK</p>	 <p>With harness connector disconnected, connect 24 volts to travel alarm terminal B, and ground terminal C.</p> <p>Does alarm sound?</p> <p>T8037BB -UN-30JUN93</p>	<p>YES: Alarm is OK.</p> <p>NO: Alarm has failed. Replace.</p> <p style="text-align: right;">--1/1</p>
--	---	--

<p>TRAVEL ALARM CANCEL SWITCH (S17) CHECK</p>	 <p>T118559 T118559 -UN-21NOV98</p> <p>Turn key switch OFF.</p> <p>Disconnect harness connector from travel alarm.</p> <p>Connect ohmmeter from travel alarm harness connector pin A to ground.</p> <p>Push travel alarm cancel switch.</p> <p>Is continuity measured when switch is pressed?</p>	<p>YES: Switch and harness are OK.</p> <p>NO: Switch or harness has failed. Repair or replace.</p> <p style="text-align: right;">--1/1</p>
--	---	--

9015
15
99

*Sub-System Diagnostics***OVERLOAD ALARM CIRCUIT OPERATIONAL INFORMATION**

The following conditions must be met for the circuit to function:

- Key switch ON
- Voltage present at auxiliary power 10-amp fuse F19

CED,OUOE012,136 -19-16MAR99-1/1

OVERLOAD ALARM CIRCUIT THEORY OF OPERATION


The overload alarm circuit contains: proximity switch B32, pressure switch B33, relay K16, and alarm H9.

Operating voltage for the overload alarm circuit is applied from fuse F19, through terminal strip X27, terminal 1 to the overload alarm power terminal, terminal 30 of relay K16, and terminal 1 of the proximity switch. When the boom is positioned on either side of the machine, proximity switch B32 closes and energizes relay K16 by applying +24 volts to relay terminal 85. With relay K16 energized, +24 volts is applied from terminal 87 to pressure switch B33, enabling the pressure switch. If the boom cylinder hydraulic pressure exceeds 3780 psi, (230LCR) or 2400 psi (230LCRD) switch B33 closes, activating the alarm, by applying ground to the overload alarm ground terminal.

CED,OUOE012,138 -19-16MAR99-1/1

Sub-System Diagnostics

OVERLOAD ALARM CIRCUIT SCHEMATIC



T120668

OVERLOAD ALARM CIRCUIT

Overload Alarm Circuit Schematic

9015
15
101

T120668 -19-28OCT99

CED,OUOE012,140 -19-17MAR99-1/1

① OVERLOAD ALARM CIRCUIT DIAGNOSTIC PROCEDURES

--1/1

<p>AUXILIARY 10 AMP FUSE (F19) CHECK</p>	<p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK.</p> <p>NO: Replace Fuse. If fuse blows again, check for short.</p>
---	--	--

--1/1


Sub-System Diagnostics

<p>OVERLOAD ALARM (H9) CHECK</p>	<p>Turn key switch OFF.</p> <p>Jumper alarm ground terminal (BLK wire) to cab ground.</p> <p>Turn key switch ON.</p> <p>Does alarm sound?</p> <p>Turn key switch OFF.</p>	<p>YES: Alarm is OK. Go to next check.</p> <p>NO: Replace alarm.</p> <p style="text-align: right;">-- -1/1</p>
---	---	--

<p>9015 15 102</p> <p>OVERLOAD ALARM PROXIMITY SWITCH (B32) CHECK</p>	<div data-bbox="381 688 587 829" data-label="Diagram"> </div> <p>T120671 T120671 -UN-25MAR99</p> <p>Operate excavator to position boom to either side of excavator.</p> <p>Turn key switch OFF.</p> <p>Remove harness connector from proximity switch.</p> <p>Connect ohmmeter to terminals 1 and 2 of switch connector.</p> <p>Does ohmmeter read continuity?</p>	<p>YES: Switch is OK. Go to next check.</p> <p>NO: Switch has failed. Replace.</p> <p style="text-align: right;">-- -1/1</p>
--	---	--

<p>OVERLOAD ALARM RELAY (K16) CHECK</p>	<div data-bbox="381 1138 609 1327" data-label="Diagram"> </div> <p>T7447BG -19-14JAN91</p> <p>Disconnect harness from overload alarm relay.</p> <p>Connect ohmmeter to relay terminals 30 and 87.</p> <p>Does ohmmeter read open?</p> <p>Connect 24 volts to relay terminal 85 and ground terminal 86.</p> <p>Does relay "click"?</p> <p>Connect ohmmeter to terminals 30 and 87.</p> <p>Does ohmmeter read continuity?</p>	<p>YES: Relay is OK. Go to next check.</p> <p>NO: Relay has failed. Replace.</p> <p style="text-align: right;">-- -1/1</p>
--	--	--

Sub-System Diagnostics

<p>OVERLOAD ALARM HARNESS CHECK</p>	 <p>T120685 T120685 -UN-25MAR99</p> <p>Disconnect harness from overload alarm pressure switch</p> <p>With boom positioned at either side of excavator, turn key switch ON.</p> <p>With voltmeter, measure voltage at pressure switch harness connector pin 3.</p> <p>Is 24 volts measured?</p>	<p>YES: Go to next step.</p> <p>NO: Check wire harness.</p>
	<p>Turn key switch OFF.</p> <p>Connect jumper wire across pressure switch harness connector pins 1 and 4.</p> <p>Turn key switch ON.</p> <p>Does overload alarm sound?</p>	<p>YES: Pressure switch has failed. Replace.</p> <p>NO: Harness has failed. Replace.</p>

9015
15
103

BATTERY OPERATION

SPECIFICATIONS	
Percent Charged For Stabilized Open Circuit Voltage 12.6 Volts or More	100%
Percent Charged For Stabilized Open Circuit Voltage 12.4 Volts	75%
Percent Charged For Stabilized Open Circuit Voltage 12.2 Volts	50%
Percent Charged For Stabilized Open Circuit Voltage 12.0	25%
Percent Charged For Stabilized Open Circuit Voltage 11.7 or Less	0%

A battery is a device for converting chemical energy to electrical energy. It is not a storage tank for electricity, but stores electrical energy in chemical form.

Because of the constant chemical to electrical change (self-discharge, discharge, or charge), the battery has a limited life. Proper care (cleaning, adding water, charging) will extend the life of the battery.

The battery is made up of positive plates, negative plates, separators, plate straps, and chemical solution (electrolyte). The electrolyte is a solution of sulfuric acid and water. Sulfuric acid is not lost during overcharging; therefore, if the liquid solution is low, only water should be added.

In a fully charged battery, the positive plate is lead peroxide (PBQ2), the negative plate is 'spongy' lead (Pb), and the electrolyte solution is about 1.270 times heavier than water. The amount that the solution is heavier than water is called specific gravity.

All batteries will self discharge at a rate of .001 specific gravity point per 24 hour period at a constant 85 °F. The discharge rate increases as temperature increases and decreases as temperature decreases. If the machine is not used for a period of time, the batteries must be maintained or stored in a cool place.

Wipe batteries with a damp cloth. If terminals are corroded, use a stiff brush and wash with an ammonia solution. After washing, flush battery and compartment with clear water. Keep caps in place when cleaning and charging.

Batteries should be maintained at an open circuit voltage of 12.40 volts or greater. To determine open circuit voltage use the following chart.

CHECK OPEN CIRCUIT VOLTAGE FOR STATE OF CHARGE

NOTE: Stabilize voltage by turning on high beams 15 Amp load for 15 seconds.

**Percent Charged For Stabilized Open Circuit Voltage—
Specification**

12.6 Volts or More.....	100%
12.4 Volts.....	75%
12.2 Volts.....	50%
12.0.....	25%
11.7 or Less.....	0%

9015
20
1

References

BATTERY SPECIFICATIONS

Battery Voltage—Specification

Volts..... 12 Volts

Cold Cranking Power—Specification

Amps..... 1100 amps at -18°C (0°F)

Reserve Capacity—Specification

Minutes 400 minutes at 25 amps

Fully Charged Electrolyte Specific Gravity—Specification

Specific Gravity..... 1.265—1.280

9015
20
2

CED,TX14795,4148 -19-13AUG98-1/1

References

DIAGNOSE BATTERY MALFUNCTIONS

Symptom	Problem	Solution
Battery Using Too Much Water	Shorted battery cell	Check battery state of charge. (See Procedure for Testing Batteries.)
	High ambient temperature	Add distilled water.
	Cracked battery case	Check battery hold down clamps. Replace battery.
	Regulator	Do Alternator Output Check. (See Charging Circuit Operational Checks.)
Cracked Battery Case	Battery hold down clamp too tight, too loose or missing	Install new battery. Install hold down clamps correctly.
	Frozen battery	Keep electrolyte at correct level and battery fully charged during cold weather.
Low Battery Output	Low water level	See Battery Using Too Much Water and Cracked Battery Case symptoms.
	Dirty or wet battery top, causing discharge	Clean battery top. Recharge battery.
	Corroded or loose battery cable ends	Clean and tighten cable end clamps. Recharge battery.
	Broken or loose battery posts	Wiggle posts by hand. If posts are loose or will turn, replace battery.
	Loose fan/alternator belt or worn pulleys	Inspect belt or pulley. Adjust or replace as necessary.

9015
20
3

References

**CHECK BATTERY ELECTROLYTE LEVEL
AND TERMINALS**

CAUTION: Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove grounded (-) battery clamp first and replace it last.

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:

1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.


If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 10—15 minutes. Get medical attention immediately.

If acid is swallowed:

1. Drink large amounts of water or milk.
2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
3. Get medical attention immediately.

1. Remove hold-down clamps.
2. Remove battery covers.




TS203 -UN-23AUG88


References

IMPORTANT: During freezing weather, batteries must be charged after water is added to prevent battery freezing. Charge battery using a battery charger or by running the engine.

3. Fill each cell to within specified range with distilled water. DO NOT overfill.



Single Level Fill Tube Application



Dual Level Fill Tube Application

- A—Battery Post
- B—Fill Tube
- C—Electrolyte Level Range

T6996DB -UN-10FEB89

9015
20
5

T6996DA -UN-10FEB89

TX,16,UU3540 -19-01SEP95-2/2

References

PROCEDURE FOR TESTING BATTERIES**1. VISUAL CHECK**

- a. Check for damage such as cracked or broken case and electrolyte leakage.

If damage is seen, replace battery.

- b. Check electrolyte level. (See procedure in this group.)

If low, add distilled water to specified level and charge battery.

- c. Check terminals for corrosion.

If corroded, clean using a wire brush or battery post cleaner such as JT05838 Battery Post/Clamp Cleaner.

- d. Check posts for looseness.

If posts are loose, replace battery.

2. HYDROMETER TEST

- a. Check specific gravity with a hydrometer or battery tester such as JT05460 Coolant/Battery Tester.

- b. Record specific gravity reading for each cell.

- c. If high and low readings vary LESS than 0.050 and average specific gravity is between 1.225 and 1.280, battery is fully charged, go to LOAD TEST.

- d. If high and low readings vary LESS than 0.050 and average specific gravity is LESS than 1.225, charge battery and repeat test. If average specific gravity is still LESS than 1.225, replace both batteries.

- e. If high and low readings vary MORE than 0.050, charge battery and repeat test. If high and low readings still vary MORE than 0.050, replace both batteries.

3. LOAD TEST

- a. Check battery capacity with a load tester such as JT05832 Battery Load Tester. Follow tester manufacturer's instructions for proper load test procedures.

- b. If one battery fails load test, replace both batteries.

References


USING BOOSTER BATTERIES—24 VOLT SYSTEM

Before boost starting, machine must be properly shut down and secured to prevent unexpected machine movement when engine starts.

CAUTION: An explosive gas is produced while batteries are in use or being charged. Keep flames or sparks away from the battery area. Make sure the batteries are charged in a well ventilated area.

IMPORTANT: The machine electrical system is a 24-volt negative (-) ground. Connect two 12-volt booster batteries together in series as shown for 24 volts.

1. Connect one end of the positive cable to the positive terminal of machine batteries (A) and the other end to the positive terminal of booster batteries (B).
2. Connect one end of the negative cable to the negative terminal of booster batteries. Then connect the other end of negative cable to the machine frame as far away from the machine batteries as possible.
3. Start the engine.
4. Immediately after starting the engine, disconnect the end of negative cable from the machine frame first. Then disconnect the other end of negative cable from the negative terminal of booster batteries.
5. Disconnect the positive cable from the booster batteries and machine batteries.



T6713AH1 (CV)

Two Battery Application

A—Machine Batteries
B—Booster Batteries

9015
20
7

T6713AH1 -JUN-24OCT91

References

REPLACING BATTERIES

SPECIFICATIONS	
Cold Cranking Amps at -18°C (0°F) amps	1100 Amps
Minutes Reserve Capacity at 25 amps Reserve Capacity	400 Minutes

Your machine is equipped with a negative (-) ground electrical system. It uses two 12-volt batteries. If one of the two batteries fails, both batteries must be replaced. Use only batteries meeting following specifications.

Cold Cranking Amps at -18°C (0°F)—Specification

Amps..... 1100 amps

Minutes Reserve Capacity at 25 amps—Specification

Reserve Capacity 400 Minutes

CEDEX, TX14795, 4153 -19-25JUN96-1/1

9015
20
8

References

ADDING 12 OR 24 VOLT ACCESSORIES

IMPORTANT: This machine has a 24-volt electrical system. Installing 12-volt accessories without addition of 24-volt to 12-volt converter may cause battery failure.

When possible, use 24-volt accessories. If 12-volt accessories are added, use a 24-volt to 12-volt converter. Converters are available from your authorized dealer. (See the Industrial Equipment Attachment Guide.)

Converter capacity requirements depend on the load of the accessories installed. Follow electronic dealer and manufacturer's recommendations to determine the capacity of the converter required and its installation requirements.

The following precautions must be followed when adding electrical and/or electronic devices:

1. DO NOT mount 24 volt-to-12 volt converters in the cab. Converters should be mounted as close to the battery as possible. Converters supplied through Deere parts system provide installation instructions outlining proper installation procedures and location.
2. DO NOT mount electrical devices directly in front of system controller (between controller and seat). Mounting above the controller on shelf behind seat is acceptable.
3. DO NOT mount electrical devices within 6 inches of existing harnesses.
4. Isolate the case of the electrical device from the vehicle or cab frame. The ground for the device

should be through a separate ground wire to the converter (if equipped) or starter ground stud.

5. Twist the power and the ground wires from the device together and run as close to the vehicle frame as possible. Twisting the wires helps to cancel any radio frequency fields that form around the wire.
6. Use of shielded wire reduces radio frequency fields even more. Twist power and ground wire together as above. Ground shield to frame at power source end and metal case of device at the opposite end. If device does not have a metal case, ground shield on device end to frame.
7. DO NOT run the device from the electronic device in parallel with the existing harnesses. DO NOT band wires to vehicle harnesses.
8. Install noise filters on positive end of all electronic devices. Noise filter should be located as close to the device as possible. Filters can be purchased at local electronic stores.
9. Mount antennas as far away from the engine and pump controller as possible. It is best not to mount antennas on the cab at all. Best locations are at the back of the unit on the counterweight or sheet metal above the batteries.

IMPORTANT: DO NOT connect an accessory to one battery. Connecting a 12-volt accessory to one battery will cause one battery to overcharge, and the other battery to undercharge, causing battery failure.

9015
20
9


References

CHANGING TRAVEL ALARM VOLUME

IMPORTANT: It may be necessary to adjust travel alarm volume to meet local regulations.

NOTE: Alarm removed from machine for clarity of photograph.

Move switch (B) to adjust volume of travel alarm. The alarm can be set at HIGH, MED (medium), or LOW volume.



T109427B -UN-07MAY97

B—Switch
H—High Level
L—Low Level
M—Medium Level

9015
20
10

CED,TX14795,4155 -19-25JUN96-1/1

*References***PROPORTIONAL SOLENOID TEST HARNESS**

Test harness JT07352 is used to check proportional solenoid Y5, Y6, Y8, and Y9 circuits.

CED,OUOE012,45 -19-23NOV98-1/1

PUMP CONTROL TEST HARNESS

Test harness JT07353 is used to check arm in and pump control pressure sensors B20, B21, and B22.

CED,OUOE012,46 -19-23NOV98-1/1

9015
20
11**PUMP PRESSURE SENSOR TEST HARNESS**

Test harness JT07354 is used to check front and rear pump pressure sensors B18 and B19.


CED,OUOE012,47 -19-24NOV98-1/1

BLANK

CHAPTER 5
SECTION 9020
POWER TRAIN

BLANK

TRACK ADJUSTER OPERATION



T7827AJ (CV)

(L) TRACK ADJUSTER

The track adjuster (L) is supported by the track frame (A). Shock loads on the track and front idler (F) are absorbed by the track recoil spring (C).


To tighten the track, pump grease (I) into fitting (K) to force the piston (E) out. As it presses against the yoke

(G), the track becomes tighter. Loosen adapter (J), NOT the fitting (K) to release grease to loosen track. Grease will escape through a small passage that is concealed by nut (B).

9020
05
1
T7827AJ -19-28OCT92

Theory of Operation

PROPEL GEARBOX OPERATION



(S) PROPEL GEARBOX

T109167

The propel gearbox (S) is a triple reduction planetary drive. The gearbox is interchangeable from the right to the left side of machine. The propel motor (A) is

connected to and turns the input shaft (first planet sun gear) (J).

Continued on next page

TX.9025.GG2611 -19-19MAY98-1/2

T109167 -19-18APR97

9020
05
2

Theory of Operation

Rotary motion is transferred from the input shaft to the sprocket (P) by the three planetary gear sets that mesh with the ring gear (D). As the input shaft is rotated it turns the first planet gears (M). The gears rotate against the ring gear causing the first planet carrier (I) to rotate. The first planet carrier is connected to the second planet sun gear (H) which is in mesh with and rotates the second planet gears (N). As the second planet gears rotate against the ring gear they turn the second planet carrier (G). The second planet carrier is connected to the third planet sun gear (F).

The third planet sun gear rotate the third planet gears (O). The third planet carrier (E) is fixed to the housing (R) and does not rotate so the rotation of the third planet gears is transferred to the ring gear. Because the ring gear and sprocket (P) are fasten to the drum (Q) they all rotate together driving the track chain to move the machine.

A replaceable thrust pad (K) is used in the cover (L) to hold the input shaft in position.

TX,9025,GG2611 -19-19MAY98-2/2

9020
05
3

DIAGNOSE UNDERCARRIAGE COMPONENTS MALFUNCTIONS

NOTE: Diagnose malfunction charts are arranged from most probable and simplest to verify, to least likely and most difficult to verify.

Symptom	Problem	Solution
Noisy or Loose Track Chain	Incorrect track tension adjustment	Adjust track sag. (See Group 9020-20.)
	Loose shoes	Remove loose shoes to clean material from between shoe and link. Install shoes and tighten cap screws to specified torque. (See Group 0130.)
	Grease leaking from track adjuster seals or relief valve	Inspect between second and third roller, at base of relief valve, and at hole in side of relief valve for leakage. Replace seals or relief valve. (See Group 0130.)
Tight Track Chain	Material packing in sprocket	Adjust track sag with material packed in sprocket. (See Group 9020-20.)
	Track sag less than specification	Adjust track sag. (See Group 9020-20.)
Frequent Track Chain Sag Adjustment Required	Grease leaking from track adjuster seals or relief valve	Inspect between second and third roller, at base of relief valve, and at hole in side of relief valve for leakage. Replace seals or relief valve. (See Group 0130.)
Excessive Oil Leakage From Idlers and Rollers	Loose plug, worn or damaged O-ring, or metal faced seal	Repair roller or idler. (See Group 0130.)
Bent Track Shoes	Excessive grouser wear	Measure grouser height. (See procedure in this group.) Rebuild grousers or replace shoes.

9020
15
1

Diagnostic Information

Symptom	Problem	Solution
	Loose track shoes	Remove loose shoes to clean material from between shoe and link. Install shoes and tighten cap screws to specified torque. (See Group 0130.)
	Excessive high speed operation on rough and rocky terrain	Slow propel speed on rough and rocky terrain.
"Popping" of Track	High propel loads in reverse	High propel loads in reverse can cause the recoil spring to retract allowing sprocket to slip in chain.
	Material packed in sprocket	Material filling sprocket teeth can cause sprocket tooth to bushing impact.
Cracked Track Link	Excessive high speed operation on rough and rocky terrain	Slow propel speed on rough and rocky terrain.
	Track shoes too wide for ground conditions	Use the narrowest shoes possible for required flotation.
Chipped Link Rails	Repeated high impacts with roller tread on flanges caused by a loose or snaky track, or using shoes that are too wide	Adjust track chain sag. (See Group 9020-20.)
		Check track chain pitch. (See procedure in this group.)
		Use the narrowest shoes possible for required flotation.
Individual Undercarriage Component Wear	See Undercarriage Appraisal Manual SP326	Rebuild components using weld. Repair or replace components.

TX,9020,GG2642 -19-25APR97-2/2

Diagnostic Information

MEASURE TRACK CHAIN BUSHING WEAR

SPECIFICATIONS	
Track Chain Bushing OD	59.0 mm (2.32 in.) new
Track Chain Bushing OD	54.0 mm (2.13 in.) minimum used

SERVICE EQUIPMENT AND TOOLS
D17524C1 ^a 100 mm Caliper
^a Tools are available in a kit such as the JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.



T82865 -UN-08NOV88

Minimum used is the maximum allowable wear for turning pins and bushings.

Measure bushing outer diameter at the two worn places using a caliper such as the D17524C1 100 mm Caliper from JT05518A Undercarriage Inspection Service Tool Kit.

Track Chain Bushing—Specification

OD 59.0 mm (2.32 in.) new
 OD 54.0 mm (2.13 in.) minimum used

NOTE: See *Undercarriage Appraisal Manual SP326* for additional information.


9020
15
3

Diagnostic Information

MEASURE TRACK CHAIN LINK WEAR

SPECIFICATIONS	
Track Chain Link Height	105.0 mm (4.13 in.) new
Track Chain Link Height	98.0 mm (3.86 in.) minimum used

SERVICE EQUIPMENT AND TOOLS	
JT05521 ^a Depth Gauge (200 mm Ruler)	
JT05534 ^a Right Angle Attachment	
D05231ST ^a 300 mm Ruler	
^a Tools are available in a kit such as the JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.	



T82864 -UN-08NOV88

Minimum used is the maximum allowable wear for rebuilding links.

Measure height of several links to find an average using a depth gauge such as the JT05521 200 mm Ruler, JT05534 Right Angle Attachment, and D05231ST 300 mm Ruler from JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.

Track Chain Link—Specification

Height 105.0 mm (4.13 in.) new
 Height 98.0 mm (3.86 in.) minimum used


NOTE: See Undercarriage Appraisal Manual SP326 for additional information.

Diagnostic Information

MEASURE TRACK CHAIN PITCH

SPECIFICATIONS	
Track Chain Pitch	762.0 mm (30.00 in.) new
Track Chain Pitch	780.0 mm (30.71 in.) maximum used

SERVICE EQUIPMENT AND TOOLS	
JT05520 ^a Metric Tape Measure	
^a Tools are available in a kit such as the JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.	



Maximum used is the maximum allowable wear for turning pins and bushings.

1. Remove slack by putting a wooden block between sprocket and chain; then slowly move machine in reverse to tighten chain.
2. Measure pitch across several four-link sections as shown, except section on either side of master pin, to find average chain wear. Use a tape measure such as the JT05520 Metric Tape from JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.

Track Chain—Specification

Pitch.....	762.0 mm (30.00 in.) new
Pitch.....	780.0 mm (30.71 in.) maximum used


NOTE: See *Undercarriage Appraisal Manual SP326* for additional information.

T6813AL -JUN-29JAN98

9020
15
5

Diagnostic Information

**MEASURE TRACK SHOE GROUSER WEAR
(SERIAL NO. —599999)**



T82859 -JUN-08NOV088

SPECIFICATIONS	
Track Shoe Grouser Height	26.0 mm (1.02 in.) new
Track Shoe Grouser Height	15.0 mm (0.59 in.) minimum used

SERVICE EQUIPMENT AND TOOLS
JT05521 Depth Gauge (200 mm Ruler)
JT05534 Right Angle Attachment
D05231ST Ruler (300 mm)
JT05518A Undercarriage Inspection Service Tool Kit
JT05523 Undercarriage Inspection Service Tool Kit

Minimum used is the maximum allowable wear for rebuilding grouser bars with weld.

Measure grouser height of several track shoes to find an average using a depth gauge such as the JT05521 200 mm Ruler, JT05534 Right Angle Attachment, and D05231ST 300 mm Ruler from JT05518A or JT0552 Undercarriage Inspection Service Tool Kit.

Track Shoe Grouser—Specification

Height 26.0 mm (1.02 in.) new
 Height 15.0 mm (0.59 in.) minimum used

TX,9020,GG2683 -19-14AUG98-1/1


9020
15
6

Diagnostic Information

**MEASURE TRACK SHOE GROUSER WEAR
(SERIAL NO. 600000—)**

SPECIFICATIONS	
Track Shoe Grouser Height	25.5 mm (1.00 in.) new
Track Shoe Grouser Height	15.0 mm (0.59 in.) minimum used

SERVICE EQUIPMENT AND TOOLS
JT05521 Depth Gauge (200 mm Ruler)
JT05534 Right Angle Attachment
D05231ST Ruler (300 mm)
JT05518A Undercarriage Inspection Service Tool Kit
JT05523 Undercarriage Inspection Service Tool Kit



T82859 -UN-08NOV88

Minimum used is the maximum allowable wear for rebuilding grouser bars with weld.

Measure grouser height of several track shoes to find an average using a depth gauge such as the JT05521 200 mm Ruler, JT05534 Right Angle Attachment, and D05231ST 300 mm Ruler from JT05518A or JT0552 Undercarriage Inspection Service Tool Kit.

Track Shoe Grouser—Specification

Height 25.5 mm (1.00 in.) new
 Height 15.0 mm (0.59 in.) minimum used


9020
15
7

Diagnostic Information

MEASURE TRACK ROLLER WEAR

SPECIFICATIONS	
Track Roller Tread OD	155.0 mm (6.10 in.) new
Track Roller Tread OD	149.0 mm (5.87 in.) minimum used

SERVICE EQUIPMENT AND TOOLS
JT05519 ^a Special Roller Caliper
^a Tools are available in a kit such as the JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.



T87973 -UN-08NOV88

Minimum used is the maximum allowable wear for rebuilding roller tread.

Under some conditions roller wear can be uneven. If wear is uneven, rollers may be interchanged to even out the wear.

Measure roller tread diameter using a caliper such as the JT05519 Special Roller Caliper from JT05518A or JT05523 Undercarriage Inspection Service Tool Kit Undercarriage Inspection Service Tool Kit.

Track Roller Tread—Specification

OD	155.0 mm (6.10 in.) new
OD	149.0 mm (5.87 in.) minimum used

NOTE: See Undercarriage Appraisal Manual SP326 for additional information.

9020
15
8

Diagnostic Information

MEASURE TRACK CARRIER ROLLER WEAR

SPECIFICATIONS

Track Carrier Roller Tread OD	120.0 mm (4.72 in.) new
Track Carrier Roller Tread OD	110.0 mm (4.33 in.) minimum used



SERVICE EQUIPMENT AND TOOLS

JT05519^a Special Roller Caliper

^aTools are available in a kit such as the JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.

Used minimum tread diameter is the maximum allowable wear for rebuilding wear surface.

Measure roller tread diameter using a caliper such as the JT05519 Special Roller Caliper from JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.

Track Carrier Roller Tread—Specification

OD	120.0 mm (4.72 in.) new
OD	110.0 mm (4.33 in.) minimum used

NOTE: See Undercarriage Appraisal Manual SP326 for additional information.

T6813AQ -JUN-29JAN98

9020
15
9

Diagnostic Information

MEASURE FRONT IDLER WEAR

SPECIFICATIONS	
Front Idler Flange Height	19.0 mm (0.75 in.) new
Front Idler Flange Height	23.0 mm (0.91 in.) maximum used

SERVICE EQUIPMENT AND TOOLS	
JT05521 ^a Depth Gauge (200 mm Ruler)	
JT05534 ^a Right Angle Attachment	
D05231ST ^a 300 mm Ruler	
^a Tools are available in a kit such as the JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.	



T87972 -UN-08NOV88

Maximum used flange height is the maximum allowable height of flange for rebuilding wear surface.

Measure height of flange using a depth gauge such as the JT05521 200 mm Ruler, JT05534 Right Angle Attachment, and D05231ST 300 mm Ruler from JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.

Front Idler Flange—Specification

Height 19.0 mm (0.75 in.) new
 Height 23.0 mm (0.91 in.) maximum used

NOTE: See Undercarriage Appraisal Manual SP326 for additional information.

Diagnostic Information

MEASURE SWING BEARING WEAR

SPECIFICATIONS	
Swing Bearing Play	1.3 mm (0.051 in.) or less new
Swing Bearing Play	4.3 mm (0.169 in.) maximum

SERVICE EQUIPMENT AND TOOLS	
D17526CI Dial Indicator	
D17525CI Magnetic Base with Adjustable Arm	

CAUTION: Stay clear of moving parts. Position dial indicator so it can be seen while operator can see you.

NOTE: Two people are needed to do the measurement. One to operate the machine and one to take the readings.



1. Check that swing bearing to main frame cap screws are tight. (See Group 4350.)

Check that bearing is lubricated with the specified grease. (See Track Adjuster, Working Tool Pivot, Swing Bearing, and Swing Bearing Gear Grease in General Information Section.)



Check that bearing rotation is smooth and without noise.

2. Install the dial indicator with needle point contacting bottom face of swing bearing outer race.
3. Move boom and arm to position shown with bucket off the ground.
4. Turn dial indicator to zero.
5. Lower boom to raise front idlers off the ground approximately 500 mm (20 in.)
6. Record dial indicator reading.

If reading is more than maximum allowable, check for steel ball and spacer wear. Repair or replace swing bearing as needed. (See Group 4350.)



T7886AI CV



T7886AJ CV

T7886AI -UN-23NOV/92

9020
15
11

T7886AJ -UN-23NOV/92

Diagnostic Information

Swing Bearing—Specification

Play 1.3 mm (0.051 in.) or less new
Play..... 4.3 mm (0.169 in.) maximum

TX,9020,GG2639 -19-13AUG98-2/2


9020
15
12

ADJUST TRACK SAG

SPECIFICATIONS	
Machine Weight	23 773 kg (52 410 lb) approximate
Track Sag	300—335 mm (11-13/16—13-3/16 in.)
Nut and Valve Assembly Torque	147 N•m (108 lb-ft)

ESSENTIAL TOOLS
Grease Gun

OTHER MATERIAL
TY2098 U.S. Multi-Purpose Grease



T6876FG -UN-06DEC88

9020
20
1

1. Swing upperstructure to side. Lower boom to raise track off the ground.

Keep the angle between boom and arm at 90—110° with the round side of bucket on the ground.

⚠ CAUTION: Prevent possible injury from unexpected machine movement. Put blocks or shop stands under machine frame to support machine while measuring track sag.

The approximate weight of machine is 23 773 kg (52 410 lb).

Machine—Specification

Weight..... 23 773 kg (52 410 lb)
approximate


2. Put blocks or shop stands under the machine to support machine.
3. Slowly turn the track forward for two revolutions and then in reverse for two revolutions. Stop the track while moving in reverse direction so all track sag is at the bottom.

Adjustments

- 4. Measure track sag (A) at middle track roller from the bottom of tack frame to the top surface of track shoe.

Track—Specification

Sag 300—335 mm
(11-13/16—13-3/16 in.)



TC457DL -UN-23FEB89

A—Track Sag

Continued on next page

TX,9020,GG2638 -19-29MAY98-2/3

9020
20
2

Adjustments

CAUTION: High pressure grease in track adjuster cylinder. Do not remove grease fitting or nut and valve assembly to release grease.

IMPORTANT: Prevent possible damage to track components. Do not use the grease fitting on track adjuster cylinder for lubrication. Use this grease fitting only for track sag adjustment.

5. To decrease track sag, add multi-purpose grease to track adjuster cylinder through grease fitting (A) located in access hole (D) in track frame. Use a grease gun with a maximum capacity of 68 950 kPa (690 bar) (10 000 psi).



To increase track sag, loosen nut and valve assembly (B) one turn to release grease from track adjuster cylinder through bleed hole (C) in rod.

Tighten nut and valve assembly when track sag is correct.

Nut and Valve Assembly—Specification

Torque 147 N•m (108 lb-ft)

NOTE: If piston in track adjuster cylinder does not move, remove the cylinder to make repairs. (See *Remove and Install Track Adjuster in Group 0130.*)



- A—Grease Fitting
- B—Nut and Valve Assembly
- C—Bleed Hole
- D—Access Hole

T7396DZ -UN-28NOV90

T7869AQ -UN-22OCT92


9020
20
3

CHAPTER 6
SECTION 9025
HYDRAULIC SYSTEM

BLANK

Group 05 Theory of Operation

HYDRAULIC SYSTEM DIAGRAM



9025
05
1


T116659

T116659 -19-24AUG98

TX,9025,GG2604 -19-19MAY98-1/1

Theory of Operation

PILOT PUMP OPERATION



(K) PILOT PUMP

The pilot pump (K) is a fixed-displacement, external gear pump. The pilot pump is attached to the pump drive gearbox just to the rear of the rear pump. The pump is driven through a gear train by the rear pump.

The inlet port (J) is connected by a suction line to the suction line for the front and rear pumps. The outlet



port (I) is connected to the pilot pressure regulating valve and pilot filter. The outlet is also connected by a tube and passages in pump housing to the small end of the front and rear pump servo piston and the pump regulators.

T112516 -19-17DEC97

TX,9025,GG2283 -19-22APR98-1/1

Theory of Operation

PILOT PRESSURE REGULATING VALVE AND FILTER OPERATION



T102044

- A—Plug
- B—Regulated Pilot Oil To Pilot Shutoff Valve
- C—Return Oil to Hydraulic Oil Tank
- D—Regulated Pilot Oil to Control Valve
- E—Pilot Pressure Regulating Valve
- F—Pilot Oil From Pilot Pump
- G—Pilot Filter and Bypass Valve
- H—Shim

- I—Spring
- J—Pilot Pressure Regulating Valve Spool
- K—Orifice
- L—Pilot Oil From Pilot Filter

The pilot filter and pilot pressure regulating valve are incorporated into one assembly.

The pilot filter (G) consists of a filter element and a bypass valve. The bypass valve senses the differential pressure between the inlet side and outlet side of the filter element. During normal operation, the bypass valve is held closed by a spring and pilot oil flows through the filter element and out to the pilot pressure regulating valve. If the filter element becomes plugged, pressure on the inlet side increases forcing the bypass valve open. Pilot oil now bypasses the filter element and unfiltered oil flows to the pilot pressure regulating valve.



The pilot pressure regulating valve (E) is a bypass flow regulating valve and is used to regulate the pilot oil pressure in the pilot oil circuit. Pilot oil flows through the orifice (K) to the end of the pilot pressure regulating valve spool (J). When the pressure in the pilot circuit increases to the pressure setting of the spring (I), the spool is pushed right against the spring. Regulated pilot oil flows to the pilot shutoff valve (B) and the control valve (D). Oil not needed to maintain the pressure in the pilot circuit flows to the hydraulic oil tank as return oil (C).

T102044 -JUN-01AUG96

9025
05
3

Theory of Operation

PILOT SHUT-OFF VALVE OPERATION



T101854

T101854 -19-06MAY98

Continued on next page

TX.9025.GG2284 -19-19MAY98-1/2

Theory of Operation

The pilot shut-off valve is a manual-operated, two-position, three-way rotary valve. The shut-off valve is rotated by pushing or pulling the pilot shut-off lever. The valve is located under the cab.


In the on (G) position, shut-off lever is pushed forward to the unlocked position, pilot oil flows to inlet ports of the pilot controllers, propel pilot controller, and solenoid valve manifold. Return oil from the controllers flows to the shut-off valve and then through the solenoid valve manifold and back to the hydraulic oil tank.

In the off (L) position, shut-off lever is pulled rearward to the locked position, pilot oil to the controllers and solenoid valve manifold is blocked and the pilot oil now flows to the flow regulator valve (H). Pilot oil that flows to the flow regulator when shut-off valve is locked is part of the warm-up circuit. The inlet ports for the controllers are open to hydraulic oil tank through the shut-off valve and solenoid valve manifold.

TX.9025,GG2284 -19-19MAY98-2/2

9025
05
5

PILOT CONTROLLER OPERATION—NEUTRAL



T111390

(P) PILOT CONTROLLER - NEUTRAL

Two hand-operated pilot controllers (right and left) are used to control the dig functions. Each controller assembly contains four valve assemblies, one for each direction of each function.

The pilot controller consists of the plunger (D), sleeve (F), spring guide (C), retainer (N), spool (B), piston (A), balance spring (G), shims (O), and return spring (H). The spools are select fitted to the bores in the housing. The quantity of shims for each balance spring and spool assembly has been determined at the


factory for correct operation of the controller. The balance and return springs used in ports 1 and 3 are different than the balance and return springs used in ports 2 and 4. The port numbers are stamped on the housing.

In neutral (P), the spool is pushed up by the return spring to block oil from the pilot pump (K) to control valve (J) pilot cap. With the spool up, the passage to the control valve pilot cap is connected to the hydraulic oil tank (I).

T111390 -19-06MAY98

TX,9025,GG2285 -19-22APR98-1/1

PILOT CONTROLLER OPERATION—METERING AND FULL STROKE



T7350CK

(N) PILOT CONTROLLER – METERING

To meter a function, the lever (E) is moved slightly. This moves the plunger (D) and spring guide (C) against the balance spring (G) which moves the spool (B) down. The spool blocks the hydraulic oil tank (reservoir) passage (I) and opens the passage from the pilot pump (K) to control valve (J) pilot cap.

Pilot oil (L) also acts on piston (A) in the spool, moving the spool up against the balance spring which closes the passage to the control valve pilot cap. This maintains pressure in the control valve pilot cap passage according to the force on the balance spring

by the plunger. As the lever is moved further, the plunger applies more force to the balance spring and the pressure to control valve pilot cap again increases to balance the spool.



When the lever (E) is moved to full stroke, the plunger (D) movement is transmitted directly to the spool (B). This forces the spool down connecting the passage from pilot pump (K) with the passage to the control valve (J) pilot cap. Oil pressure to the control valve pilot cap now equals pilot circuit pressure.

T7350CK -19-06MA Y98

9025
05
7

Theory of Operation

PROPEL PILOT CONTROLLER OPERATION



(L) PILOT OIL
 (M) RETURN OIL

T108942

(N) PROPEL PILOT CONTROLLER - FULL STROKE

T108942 -19-06MAY98

Continued on next page

TX.9025.GG2606 -19-29MAY98-1/2

Theory of Operation

One pilot controller is used to control the propel functions. The controller contains four valve assemblies, one for each direction of travel for each track.

The pilot controller consists of the cam and pedal (E), plunger (D), sleeve (F), spring guide (C), spool (A), balance spring (G), and return spring (H).

In neutral, the spool is pushed up by the return spring to block pilot oil from the pilot shutoff valve (J). With the spool up, the passage to the control valve pilot cap (K) is connected to the hydraulic oil tank (I) by the passage through the spool (A).


When the pedal is pushed to move the machine, the cam (E) pushes the plunger and spring guide down against the return spring and balance spring. The

balance spring pushes the spool down. As the spool is pushed down the passage from the control valve pilot cap to the hydraulic oil tank (I) is closed and then is opened to the pilot oil from pilot shutoff valve. When the pilot oil pressure to the control valve pilot cap is equal to the force applied by the balance spring the spool moves up trapping the oil to the pilot cap.

When the pedal and cam is moved to full stroke, the plunger is pushed down further by the balance spring opening the passage through the spool more to the pilot oil. When pressure to the control valve pilot cap is equal to the force applied by the balance spring, the spool moves up until it contacts the plunger. The plunger holds the spool down so the passage through spool remains open to pilot oil. Oil pressure to the control valve pilot cap now equals pilot oil pressure.

Theory of Operation

PILOT CONTROLLER OPERATION OF CONTROL VALVE



Ⓒ PILOT OPERATION OF MAIN CONTROL VALVE






The pilot controllers (A) are connected to the control valve (C) by pilot control hoses through the flow regulator valve. When the pilot controller is actuated, pilot oil (E) from the pilot pump (D) is routed to the control valve pilot cap. In this illustration, the bucket section (B) is actuated. Return oil (F) from the control

valve pilot cap is routed through the pilot controller to the hydraulic oil tank.

The pilot hoses for the propel pilot controller are not connected to the flow regulator valve but are connected directly to the control valve pilot caps.

Theory of Operation

FLOW REGULATOR VALVE OPERATION



(R) FLOW REGULATOR VALVE

T104746

T104746 -19-23APR97

Continued on next page

TX.9025.GG2290 -19-29MAY98-1/2

9025
05
12

Theory of Operation

NOTE: *The cross section of flow regulator valve shown in the illustration is in the boom up pilot circuit.*

The pilot lines for boom, arm, bucket, and swing functions are connected through the flow regulator to the pilot caps on the control valve. The pilot lines for propel function are connected directly to the pilot caps.

The flow regulator valve (R) is a manifold containing similar flow regulator valve spools (J) in the arm out and boom up pilot circuits. Check valves (E) are also included in the warm-up oil passage (O) for arm in, arm out, boom down, and boom up pilot circuits; no check valves are used in the bucket and swing pilot circuits. Each valve spool contains an orifice plate (K) and springs. The size of the orifice is 2.5 mm (0.098 in.).

When the boom up or arm out (M) function is actuated, pilot oil from the pilot controller (A) flows through the spool into the bottom spring chamber and through the orifice plate (K) to the pilot cap (D). As the pressure increases the spool pushes upward allowing pilot oil to flow unrestricted to the pilot cap to move the control valve spool. The spool acts as a check valve (I). Return oil from the opposite end of control valve spool flows from the pilot cap and through the manifold to the pilot controller.

When the boom down or arm in (N) function is actuated, the pilot oil to move the control valve spool flows from the pilot controller through the manifold to the pilot cap. Return oil from the opposite end of control valve spool flows from the pilot cap to the manifold and through the orifice plate (K) in the spool (J). As the return pressure increases, the spool is pushed down in proportion to the pressure increase regulating the return oil flow to provide precise movement of a function. From here, oil flows to the pilot controller.


WARM-UP CIRCUIT OPERATION:

When the pilot shut-off valve is in the OFF position and the engine is running, pilot oil flows from the pilot shut-off valve (F) to the flow regulator valve manifold. The oil is heated as it flows through a restriction at the inlet to manifold. The warm-up oil from pilot shut-off valve (L) flows through the warm-up oil passage (O) past the check valves (E) and out to the left and right pilot controllers and top pilot caps to warm the pilot circuit. At the pilot controllers, the warm-up oil flows through the pilot controllers, out the return port, through the pilot shut-off valve to the solenoid valve manifold, and then to the hydraulic oil tank. At the pilot caps, warm-up oil flows through orifices into a return passage in the pilot caps and then to the hydraulic oil tank.

9025
05
13

Theory of Operation

HYDRAULIC PUMP AND DRIVE GEARBOX OPERATION



9025
05
14

T102053

Continued on next page

TX.05.GG2150 -19-18MAY98-1/2

T102053 -19-06AUG98

Theory of Operation

The front pump (B), rear pump (C) and pilot pump (F) are driven by the engine at engine speed through a pump drive gearbox (G). The rear pump drive shaft (H) as well as driving the rear pump also serves as the


drive shaft for the pump drive gearbox. The rear pump drive shaft is connected to the engine flywheel through a dampener drive (flex coupling).

TX,05,GG2150 -19-18MAY98-2/2

9025
05
15

Theory of Operation

HYDRAULIC PUMP OPERATION



9025
05
16

T102060

(N) FRONT AND REAR HYDRAULIC PUMPS

Continued on next page

TX.05.GG2151 -19-29MAY98-1/2

T102060 -19-06AUG96

Theory of Operation

The front and rear hydraulic pumps (N) are variable displacement, bent-axis, piston type pump. Two identical pumps are used to generate oil flow in the hydraulic system. The pump can vary from minimum displacement to maximum displacement depending on hydraulic demand of the system.

A regulator (G) is attached to the top of housing (H) for each pump. A pilot oil signal to the regulator moves a piston which then directs pilot oil to the servo piston (K) which moves the valve plate (L) and cylinder block (M) changing the pump displacement. The feedback link (F), connected to the valve plate, also moves providing a mechanical feedback to the remote control sleeve in the regulator. The remote control sleeve blocks the flow of pilot oil to the servo piston and also traps the oil at both ends of the servo piston stopping its movement.

The front and rear pumps and pilot pump are driven at engine speed through a pump drive gearbox. The rear pump drive shaft (D) as well as driving the rear pump

also serves as the drive shaft for the pump drive gearbox. The drive shafts drive the cylinder blocks (M) through the center shafts (I). The cylinder block is positioned at an angle to the drive shaft. As the cylinder block and drive shaft rotate, the pistons (J) move in and out of their bores because of the angle. The pistons which are moving out of their bores draw oil from the hydraulic oil tank through a pump inlet port and ports in the valve plate (L). The pistons which are moving back into their bores push oil through ports in the valve plate out the front and rear discharge ports (A and C) and to the control valve.


The pump displacement, or flow rate, is varied by changing the angle of the cylinder block with respect to the drive shaft. Increasing the angle increases the distance that each piston travels into and out of the bore which increases displacement. Decreasing the angle reduces the distance that each piston travels into and out of the bore which decreases displacement.

9025
05
17

TX,05,GG2151 -19-29MAY98-2/2

Theory of Operation

HYDRAULIC PUMP REGULATOR COMPONENT OPERATION



(N) PUMP REGULATOR COMPONENTS

The pump regulators are mounted on the top of the hydraulic pump housing. The major pump regulator components (N) are the flow adjusting cartridge (A), maximum flow (displacement) adjusting screw (B), remote control sleeve (C), remote control spool (D), piston (E), minimum flow (displacement) adjusting screw (F), load adjusting screw (inner spring) (engine pull down at high pressure) (G), load adjusting cartridge (outer spring) (engine pull down at medium pressure) (H), inner spring (I), outer spring (J), load

sleeve (K), load spool (L), and load piston (M). Each regulator controls the flow of pilot oil to the large end of its servo piston using the spools and sleeves.

The remote control spool (D) is moved by a reduced pilot oil control signal from front and rear pump control valve. There is a pump control valve located in the left and right control valves. The control signal acts on the end of the piston (E) to control the position of remote control spool against the spring.

9025
05
18

T101949

T101949 -19-23APR97

Continued on next page

TX,05,GG2148 -19-19MAY98-1/2

Theory of Operation

The load spool (L) is moved by the load piston (M) against the springs to decrease pump flow (displacement) and avoid overloading the engine when main system pressure becomes too high. At lower system pressures the spool is moved against only the outer spring (J). At higher pressures, the spool contacts and is moved against the inner spring (I) as

well as the outer spring. The pump supply oil pressure is sensed on one shoulder of the load piston and the pump supply oil pressure from the other pump is sensed on the other shoulder. The end of the load piston receives a reduced pilot oil control signal from the speed sensing solenoid valve when the actual engine speed pulls down to the target engine speed.


TX,05,GG2148 -19-19MAY98-2/2

9025
05
19

Theory of Operation

HYDRAULIC PUMP REGULATOR OPERATION

- (27) PILOT OIL
- (28) REDUCED PILOT OIL
- (29) REAR PUMP SUPPLY OIL
- (30) FRONT PUMP SUPPLY OIL
- (31) CONTROL VALVE NEUTRAL PASSAGE OIL
- (32) TRAPPED OIL
- (33) RETURN OR PRESSURE FREE OIL



(34) REGULATOR OPERATION

T108968

T108968 -19-29MAY97

Continued on next page

TX.05.GG2152 -19-20MAY98-1/2

Theory of Operation

The function of pump regulators is to control the flow of pilot oil to and from the servo piston large end (4) in response to reduced pilot oil control signals from the front and rear pump control valves (3) and supply oil pressure signals from the front and rear pumps (22 and 20). Pump displacement (flow) is changed by sending pilot oil to or releasing pilot oil from the servo piston large end.

Pilot oil from the pilot pump (18) flows through drilled passages in the pump housing to the small end of servo pistons and to the pilot oil inlet (8) at each regulator. Pilot oil pressure is maintained at the small end of servo pistons and at the inlet of both regulators.

The reduced pilot oil (28) control signal from the front or rear pump control valve is sensed by the piston (7) through hoses from control valve to a port at the top of its respective regulator.

The pump supply oil (29 and 30) from front and rear pumps is sensed through drilled passages in the pump housing to the pump pressure inlets (12) in each regulator.

The control signal from the speed sensing solenoid valve is sensed through a hose to the speed sense signal port (13) at the rear pump regulator and then by a steel line to the front pump regulator.


TX,05,GG2152 -19-20MAY98-2/2

9025
05
21

Theory of Operation

HYDRAULIC PUMP REGULATOR INCREASING, MAXIMUM, AND DECREASING OPERATION

- (27) PILOT OIL
- (28) REDUCED PILOT OIL
- (29) REAR PUMP SUPPLY OIL
- (30) FRONT PUMP SUPPLY OIL
- (31) CONTROL VALVE NEUTRAL PASSAGE OIL
- (32) RETURN OR PRESSURE FREE OIL



(33) PUMP FLOW INCREASING

T108969

Continued on next page

TX.05.GG2153 -19-29MAY98-1/2

T108969 -19-24APR97

*Theory of Operation***INCREASING FLOW (DISPLACEMENT)**

When a function is actuated, the reduced pilot oil (28) control signal from the pump control valve (3) to the piston (7) increases. The control signal pushes the piston and remote control spool (5) to the left against the spring until the spring force and control signal pressure are equal. Movement of spool opens a path from the large end of servo piston to return in the pump housing (14). Pilot oil on the small end of servo piston pushes the piston down increasing pump angle which increases the displacement (flow). The servo piston movement is transmitted to the remote control sleeve (6) and load sleeve (9) by the feedback link (15). The sleeves move left until the path to return is closed. The oil at the large end of servo piston is now trapped holding the pump at the displacement (flow rate) that is proportional to the pressure of the pump control valve control signal.

MAXIMUM FLOW (DISPLACEMENT)

When the pilot controller lever is actuated to full stroke, the reduced pilot oil (28) control signal from the pump control valve (3) to the piston (7) increases to its maximum. The control signal pushes the piston and remote control spool to the left until the spool contacts the maximum flow adjusting screw. Movement of spool opens a path from the large end of servo piston to return in pump housing (14). Pilot oil on the small end of servo piston pushes the piston down increasing pump displacement (flow). The servo piston is

transmitted to the remote control sleeve (6) and load sleeve (9) by the feedback link (15). The sleeves move left until the path to return is closed. The oil at the large end of servo piston is now trapped holding the pump at maximum displacement (flow rate) that is proportional to the pressure of the pump control valve control signal.

DECREASING FLOW (DISPLACEMENT)


As the function is returned towards neutral, the reduced pilot oil (28) control signal sensed at the piston (7) also decreases. The spring pushes the remote control spool and piston to the right. Movement of the spool opens a path for pilot oil (27) to flow to the servo piston large end (4). The pilot oil pressure applied to the servo piston large end pushes the piston up against the pressure applied to the small end decreasing pump flow. The piston and remote control spool continues to be pushed to the right until spring force again equals the reduced pilot oil control pressure or until the spool contacts the piston (7) cylinder when function is returned to neutral. As the pump displacement decreases, the movement is transmitted to the remote control sleeve (6) and load sleeve (9) by the feedback link (15). The sleeves move right until the path for pilot oil is closed. The oil at the large end of servo piston is now trapped holding the pump at the displacement (flow rate) that is proportional to the pressure of the pump control valve control signal.

9025
05
23

Theory of Operation

HYDRAULIC PUMP REGULATOR SUMMATION AND SPEED SENSING OPERATION

- (27) PILOT OIL
- (28) REDUCED PILOT OIL
- (29) REAR PUMP SUPPLY OIL
- (30) FRONT PUMP SUPPLY OIL
- (31) CONTROL VALVE NEUTRAL PASSAGE OIL
- (32) RETURN OR PRESSURE FREE OIL



(33) PUMP FLOW INCREASING

T108969

T108969 -19-24APR97

Continued on next page

TX.05.GG2205 -19-20MAY98-1/2

Theory of Operation

Summation (flow rate control by monitoring both pump pressures)—The pump supply oil pressure (load) for each pump is sensed at the load piston (11) through the pump pressure inlets (12) at its regulator and at the regulator of other pump. The average pressure on the load piston is applied through the load spool (10) to the inner and outer springs. The springs are adjusted against the average pressure so the flow rate of the pumps are approximately equal and each pump uses approximately half the engine output. If the load on either pump increases, the average pressure on the load pistons shift the load spools against the springs opening a path for pilot oil to the servo pistons. The flow rate of both pumps decreases so the load on the pumps does not exceed the engine output. Also engine output is not exceeded even if one pump is loaded relatively high while the other pump stays relatively low.



Speed Sensing—When the actual engine speed, measured by engine speed sensor, is pulled down to the target engine speed, as determined by engine rpm dial position, the speed sensing solenoid valve coil is energized by an electrical signal from the engine and pump controller. The pilot oil control signal is sent to the end of load piston at the speed sense signal port (13) in the front and rear pump regulators. The pilot oil control signal along with the pump supply oil pressure shift the load spools against the springs opening a path for pilot oil to the large end of servo pistons to decrease the pump angle. The flow rate of both pumps decreases so the load on the engine decreases and the actual engine speed can increase. (See Engine Speed Sensing Control Circuit Operation in this group.)

TX,05,GG2205 -19-20MAY98-2/2

9025
05
25

Theory of Operation

PROPORTIONAL SOLENOID VALVE MANIFOLD OPERATION



T109045

S SOLENOID VALVE MANIFOLD

T109045 -19-21MAY97

Continued on next page

TX.9025.GG2609 -19-20MAY98-1/2

Theory of Operation

The solenoid valve manifold (S) is mounted on the right control valve. The manifold serves as the central distribution point for pilot oil (Q) to the arm regenerative (M), speed sensing (N), propel speed change (O), and power boost (P) solenoid valves, the front (B) and rear (F) pump control valves, and the swing motor park brake release valve (E). Pilot oil flows to the manifold when the pilot shutoff valve (A) is in unlock position, shutoff lever forward.

Return oil (R) from the pilot shutoff valve (D), propel flow control valve (C), bucket flow control valve (K), and the solenoid valves, when solenoid valves are de-energized, flows through the manifold to the hydraulic oil tank (G).





The identification letters shown on the hydraulic schematic are on the manifold housing next to the ports.

TX,9025,GG2609 -19-20MAY98-2/2

9025
05
27

Theory of Operation

PROPORTIONAL SOLENOID VALVE OPERATION



T109046

(N) ENERGIZED
(R) PROPORTIONAL SOLENOID VALVE

T109046 -19-23APR97

Continued on next page

TX.9025.GG2095 -19-20MAY98-1/2

9025
05
28

Theory of Operation

The arm regenerative (SC) (B), speed sense (SD) (C), propel speed change (SI) (D) and power boost (SG) (E) solenoid valve are proportional solenoid valve (R) type. The solenoid valve is activated by an electrical signal from the engine and pump controller (EPC). The electrical signal is a DC voltage that is turned on and off to form a pulse width modulated signal. The solenoid (I) reacts to the “average” voltage to create a magnetic force to shift the spool (F) left against a spring. The reduced pilot oil control signal sent to the valve function (L) depends on how long the electrical signal is on versus on how long it is off. The reduced pilot oil control signal is in proportion to the electrical signal to the solenoid.

When de-energized (G), the spool is pushed to the right by a spring. The valve function port is connected to the hydraulic oil tank (J) port.

When energized (N), the magnetic force shifts the spool left against the spring. Pilot oil (O) flows past the spool flange and out the valve function port as a reduced pilot oil (P) control signal. Because the flange on the right is larger than the flange on the left, the spool is pushed to the right against the magnetic force

as the control signal to the valve function increases. When the control signal becomes equal to or greater than the magnetic force, the spool is pushed to the right closing the passage stopping the pressure increase. The reduced pilot oil control signal to the valve function is trapped. The spool is moving constantly to maintain the control signal in response to the electrical signal to the solenoid.

For circuit operation of arm regenerative solenoid valve, see Arm Regenerative Valve Operation in this group.

For circuit operation of speed sense solenoid valve, see Engine Speed Sense Control Circuit Operation in this group.


For circuit operation of propel speed change solenoid valve, see Propel Speed Change Circuit Operation in this group.

For circuit operation of power boost solenoid valve, see Power Boost Control Circuit Operation in this group.

9025
05
29

TX.9025,GG2095 -19-20MAY98-2/2

ENGINE SPEED SENSING CONTROL CIRCUIT OPERATION



(G) ENGINE SPEED SENSING CONTROL CIRCUIT

T103218

The function of engine speed sensing control circuit (G) is to reduce the hydraulic load on the engine if it exceeds the output torque of the engine.

The speed sensing solenoid valve (F) coil is energized by an electrical signal from the engine and pump controller (B) when the actual engine speed, as sensed by the engine speed sensor (C), is pulled down to the target engine speed. The target engine


speed is a function of the engine and pump controller and is selected when the engine rpm dial (A) is turned to the desired actual engine speed.

The pilot oil control signal is sent to the end of the load piston in the front and rear pump regulators (D and E) which then operate to reduce pump flow. (See Hydraulic Pump Regulator Operation in this group.)

TX,05,GG2201 -19-20MAY98-1/1

T103218 -19-07SEP96

CONTROL VALVE OPERATION



9025
05
32

T120891

Left Front

Continued on next page

TX.05.GG2154 -19-20MAY98-1/4

T120891 -UN-27MAY99

Theory of Operation

- | | | | |
|--|---|--|---|
| 1—Left Control Valve (5-Spool) | 64—Arm II Valve | 75—Arm Out Circuit Relief and Anti-Cavitation Valve | 81—Propel Flow Control Valve |
| 2—Right Control Valve (4-Spool) | 65—Boom I Valve and Boom Regenerative Valve | 76—Plug | 82—Propel Power and Neutral Passage Check Valves (Lift Checks) |
| 56—System Relief Valve Isolation Check Valve | 66—Boom Reduced Leakage Valve | 77—Swing Lift Check Valve | 83—Rear Pump Control Valve |
| 57—System Relief Valve and Power Boost | 67—Bucket Valve | 78—Arm I Power and Neutral Passage Check Valves (Lift Checks), and Restriction Orifice | 84—Filter and Orifice for Pilot Pressure to Rear Pump Control Valve |
| 58—Dig Pressure Switch | 68—Right Propel Valve | 79—Boom II Power Passage Check Valve (Lift Check) | 84A—Check Valve and Orifice for Propel Flow Control Valve |
| 59—Flow Combiner Valve Circuit Check Valve | 69—Left Propel Valve | 80—Auxiliary Power Passage Check Valve (Lift Check) | |
| 60—System Relief Valve Isolation Check Valve | 70—Auxiliary Valve | | |
| 61—Propel Pressure Switch | 71—Boom II Valve | | |
| 62—Filter—Pilot Pressure Inlet | 71A—Propel-Boom Down Selector Valve | | |
| 63—Solenoid Valve Manifold | 72—Arm I Valve | | |
| | 73—Swing Valve | | |
| | 74—Arm Reduced Leakage Valve | | |

The control valve consists of two monoblock valve housings called the left control valve (1) and right control valve (2). The control valves are mounted back-to-back to connect the interconnected oil passages through ports in the mounting faces. The left control valve is a 5-spool section valve consisting of left propel (69), auxiliary (70), boom II (71), arm I (72), and swing (73). The right control valve is a 4-spool section valve consisting of right propel (68), bucket (67), boom I (65), and arm II (64). Each spool is selectively fitted to its bore in the housings. The spools are moved by pilot oil controlled by the pilot controllers located in the cab.

For the location of all valves used in the control valve, see the three illustrations labeled Left Front, Right Rear, and Bottom and the legends. Also see the Control Valve Circuit Schematic for location of components.

All valves are accessible from the outside of control valve by removing a plug, cover, or the pilot caps. For line connections to the control valves, see Control Valve Component and Line Identification in Group 9025-15. The solenoid valve manifold is also located on the right control valve.


The control valve is an open-center valve. Each valve section controls the flow rate and direction for its hydraulic circuit. The rear (83) and front (98) pump control valves, located in neutral passage of the left (1) and right (2) control valves, are used to send a control signal to the front and rear pump regulators when a function is actuated. (See Pump Control Valve Operation in this group.) Two pressure switches (58 and 61) located on the front of the control valve are closed to send an electrical signal to the engine and pump controller when a dig or propel function is actuated.

9025
05
33

Continued on next page

TX,05,GG2154 -19-20MAY98-2/4

Theory of Operation



9025
05
34

T109052

Right Rear


T109052 -UN-15APR97

- | | | | |
|---|--|--|---|
| <p>1—Left Control Valve (5-Spool)</p> <p>2—Right Control Valve (4-Spool)</p> <p>57—System Relief Valve and Power Boost</p> <p>63—Solenoid Valve Manifold</p> <p>64—Arm II Valve</p> <p>65—Boom I Valve and Boom Regenerative Valve</p> <p>66—Boom Reduced Leakage Valve</p> <p>67—Bucket Valve</p> <p>68—Right Propel Valve</p> <p>69—Left Propel Valve</p> | <p>70—Auxiliary Valve</p> <p>71—Boom II Valve</p> <p>72—Arm I Valve</p> <p>73—Swing Valve</p> <p>85—Arm Regenerative Valve</p> <p>86—Arm II to Arm I Neutral Passage Check Valve</p> <p>87—Boom Up Circuit Relief Valve</p> <p>88—Bucket Dump Circuit Relief Valve</p> <p>89—Power Boost Solenoid Valve</p> <p>90—Propel Speed Change Solenoid Valve</p> | <p>91—Speed Sensing Solenoid Valve</p> <p>92—Arm Regenerative Solenoid Valve</p> <p>93—Flow Combiner Valve</p> <p>94—Bucket Flow Control Valve Pilot Valve A and B, and Poppet Valve</p> <p>95—Bucket Check Valve (Lift Check)</p> <p>96—Boom I Power and Neutral Passage Check Valves (Lift Checks)</p> | <p>97—Right Control Valve to Arm I Power Passage Check Valves and Restriction Orifice</p> <p>98—Front Pump Control Valve</p> <p>99—Filter and Orifice for Pilot Pressure to Front Pump Control Valve</p> <p>105—Oil Cooler Bypass Valve</p> |
|---|--|--|---|

Continued on next page

TX.05.GG2154 -19-20MAY98-3/4

Theory of Operation



T120890

Bottom

- 1—Left Control Valve (5-Spool)
- 2—Right Control Valve (4-Spool)
- 64—Arm II Valve
- 65—Boom I Valve
- 67—Bucket Valve
- 68—Right Propel Valve
- 69—Left Propel Valve

- 70—Auxiliary Valve
- 71—Boom II Valve
- 72—Arm I Valve
- 73—Swing Valve
- 94—Bucket Flow Control Valve
- 100—Arm Regenerative Circuit Check Valve

- 101—Boom Down Circuit Relief and Anti-Cavitation Valve
- 102—Bucket Curl Circuit Relief and Anti-Cavitation Valve
- 103—Plug

- 104—Arm In Circuit Relief and Anti-Cavitation Valve


T120890 -JUN-27MAY99

9025
05
35

TX,05,GG2154 -19-20MAY98-4/4

Theory of Operation

CONTROL VALVE CIRCUIT SCHEMATIC



(105) CONTROL VALVE CIRCUITS

T109055

Continued on next page

TX.9025.GG2610 -19-20MAY98-1/2

T109055 -UN-16APR97

9025
05
36


Theory of Operation

- | | | | |
|--|--|--|--|
| 1—Left Control Valve (5-Spool) | 73—Swing Valve | 83—Rear Pump Control Valve | 97—Right Control Valve to Arm I Power Passage Check Valves and Restriction Orifice |
| 2—Right Control Valve (4-Spool) | 74—Arm Reduced Leakage Valve | 85—Arm Regenerative Valve | 98—Front Pump Control Valve |
| 56—System Relief Valve Isolation Check Valve | 75—Arm Out Circuit Relief and Anti-Cavitation Valve | 86—Arm II Neutral Passage to Arm I Power Passage Check Valve | 100—Arm Regenerative Circuit Check Valve |
| 57—System Relief Valve and Power Boost | 76—Plug | 87—Boom Up Circuit Relief Valve | 101—Boom Down Circuit Relief and Anti-Cavitation Valve |
| 59—Flow Combiner Valve Circuit Check Valve | 77—Swing Lift Check Valve | 88—Bucket Dump Circuit Relief Valve | 102—Bucket Curl Circuit Relief and Anti-Cavitation Valve |
| 60—System Relief Valve Isolation Check Valve | 78—Arm I Power and Neutral Passage Check Valves (Lift Checks), and Restriction Orifice | 93—Flow Combiner Valve | 103—Plug |
| 64—Arm II Valve | 79—Boom II Power Passage Check Valve (Lift Check) | 94—Bucket Flow Control Valve Pilot Valve A and B, and Poppet Valve | 104—Arm In Circuit Relief and Anti-Cavitation Valve |
| 65—Boom I Valve and Boom Regenerative Valve | 80—Auxiliary Power Passage Check Valve (Lift Check) | 95—Bucket Check Valve (Lift Check) | 105—Control Valve Circuits |
| 66—Boom Reduced Leakage Valve | 81—Propel Flow Control Valve | 96—Boom I Power and Neutral Passage Check Valves (Lift Checks) | |
| 67—Bucket Valve | 82—Propel Power and Neutral Passage Check Valves (Lift Checks) | | |
| 68—Right Propel Valve | | | |
| 69—Left Propel Valve | | | |
| 70—Auxiliary Valve | | | |
| 71—Boom II Valve | | | |
| 71A—Propel-Boom Down Selector Valve | | | |
| 72—Arm I Valve | | | |

9025
05
37

Theory of Operation

CONTROL VALVE PILOT PRESSURE SIGNAL PASSAGE OPERATION



9025
05
38

T103077

Continued on next page

TX.05.GG2192 -19-20MAY98-1/2

T103077 -19-07SEP96

Theory of Operation

Pilot oil from the pilot pump (M) flows to the control valve and through the orifices (D) into the propel pilot pressure signal passage (G) and dig pilot pressure signal passage (H). The oil in the propel pilot pressure signal passage flows to the propel pressure switch (E), the propel-boom down selector valve (R), past the top end of the right (I) and left (W) propel valve spools, and then to the return passage (X). The oil in the dig pilot pressure signal passage flows to the dig pressure switch (C), the propel flow control valve (T), flow combiner valve (F), past the top end of bucket (J), boom I (K), arm II (L), swing (P), arm I (Q), boom II (S), and auxiliary (U) valve spools, and then to the

return passage (V). The flow of oil through the orifices causes a pressure drop; the pressure of oil downstream of each orifice is less than the pressure upstream of the orifices. None of the switches or valves in the signal passages are actuated.


When a function is actuated, the valve spools shift blocking the flow of oil through the signal passage. The oil pressure upstream of the valve spool increases to approximately the pressure setting of pilot pressure regulating valve and actuates the switch and valves in that signal passage.

TX,05,GG2192 -19-20MAY98-2/2

9025
05
39

Theory of Operation

CONTROL VALVE NEUTRAL AND POWER PASSAGES OPERATION



② NEUTRAL AND POWER PASSAGES

T101397

T101397 -19-07SEP96

Continued on next page

TX.05.GG2191 -19-20MAY98-1/2

Theory of Operation

Supply oil from the front pump (M) flows to the right control valve. Supply oil from the rear pump (O) flows to the left control valve. When all functions are in neutral supply oil flows through the neutral passages


(C and P), through the pump control valves (K and X), and into the return passage (D). Power passages (N) in the left and right control valves are used to route supply oil for the combined operation of functions.

TX,05,GG2191 -19-20MAY98-2/2

9025
05
41

Theory of Operation

SYSTEM RELIEF AND POWER BOOST VALVE OPERATION



T102821

T102821 -19-23APR97


The function of system relief and power boost valve (R) is to limit the main hydraulic system operating pressure. The system relief and power boost valve is a pilot-operated, poppet-type relief valve with a piston (E).

When the pump supply oil in the power passage (L) pressure exceeds the relief valve setting, pilot poppet (H) is pushed off its seat letting oil behind main poppet (J) flow to the return passage (K). A pressure difference is created across the main poppet because

oil flows out faster than oil can flow through the orifice in poppet. The main poppet is pushed open to relieve pressure oil to the return passage.

For power boost operation (N), pilot oil (P) from the power boost solenoid valve pushes the piston (E) down increasing the pressure setting of the pilot poppet spring (G). The main hydraulic system can now operate at a higher operating pressure for approximately 8 seconds.

POWER BOOST CONTROL CIRCUIT OPERATION



(E) POWER BOOST CONTROL CIRCUIT

T109063

The function of power boost control circuit (E) is to temporarily increase the main hydraulic system operating pressure by increasing the system relief valve pressure.


When the power boost switch (A) is pushed the engine and pump controller (B) sends an electrical signal to

energize the power boost solenoid valve (D) coil. The pilot oil pressure signal pushes the piston in the system relief valve (C) down increasing the pressure setting. The main hydraulic system can now operate at a higher operating pressure for approximately 8 seconds.

T109063 -19-29APR97


9025
05
43

CIRCUIT RELIEF VALVE OPERATION



(P) RELIEF OPERATION

(Q) ANTICAVITATION OPERATION



(R) CIRCUIT RELIEF - ANTICAVITATION VALVE

IT4579

IT4579 -19-03NOV/97




At pressures below the circuit relief setting the main poppet (J) remains closed. In relief operation (P), the relief valve opens in three steps. In the first step, the pilot poppet (E) is opened. Flow restriction through the hollow piston (B) causes the pressure in the cavity behind the main poppet to decrease. In the second step of relief operation the piston seats against the pilot poppet (E). This further reduces oil flow into the cavity and greatly decreases the pressure against the back side of main poppet. The main poppet opens in the third step of relief operation.

During anti-cavitation operation (Q) the check valve (D) retracts to allow oil to flow from the return passage into the work circuit. During normal operation the operating oil pressure (L) on the inner shoulder holds the check valve against its seat. This pressure decreases as pressure in the work circuit decreases. The return oil pressure (N) on the outer shoulder moves the check valve, main poppet, and piston against the springs to open the valve.

TX,05,GG2146 -19-10JUL96-1/1

Theory of Operation

PUMP CONTROL VALVE OPERATION



Q PUMP CONTROL VALVES


T102920

T102920 -19-12AUG96

Continued on next page

TX.05.GG2178 -19-08JUN98-1/2

Theory of Operation



T116656

T116656 -19-24AUG98

9025
05
47

A pump control valve (Q) is located at the downstream end of the control valve neutral passage (H) in the left and right control valves. The function of pump control valve is to send a regulated pilot oil control signal to the front and rear pump regulators to change pump flow in response to the actuation of control valve spools.

Control Valve Spools in Neutral:

When all control valve spools are in neutral the neutral passage through the control valve is not restricted and full flow from the pump flows through the neutral passage and flow sense spool (G) to the control valve return passage (E). Full flow causes the flow sense spool to move to the right against the flow sense spring (F) decreasing the pressure setting of the relief valve spring (D). The relief valve spool is pushed open to direct pilot oil to the hydraulic oil tank (I) decreasing the control signal to the pump regulator (K).


Control Valve Spool Actuated:

When a single or combine functions are actuated the control valve spool shifts decreasing flow through the neutral passage and flow sense spool. As flow through the flow sense spool decreases, the spool is shifted to the left by the flow sense spring increasing the pressure setting on the relief valve spring. The relief valve spool shifts more closed decreasing pilot oil flow to the hydraulic oil tank and increasing the control signal to the pump regulator which causes pump flow to increase. (See Hydraulic Pump Regulator Operation in this group.)

In addition, the control signal to pump regulators is sensed by the pump control pressure sensors (L) sending an electrical signal to the engine and pump controller for the propel speed change function. (See Propel Motor Speed Change Circuit Operation in this group.)

Theory of Operation

FLOW COMBINER VALVE OPERATION



Pilot oil from the pilot pump (C) flows through the orifice (L), into the dig pilot pressure signal passage (G), past each dig function valve spool, and then to the return circuit. The flow combiner valve (D), propel flow control valve (M), and the swing motor park brake release valve (K) are connected to the signal passage between the orifice and spools.

When one or more dig functions are actuated, pilot oil flow through the signal passage to return is blocked by a valve spool (arm II valve shown) (O). The pressure in the blocked portion of the signal passage increases shifting the flow combiner, propel flow control, and swing park brake release valve spools.


Supply oil from the front pump (P) now flows through the flow combiner valve to the left propel valve (E) as

well as the right propel valve to ensure that the machine does not mistrack during combined propel and dig function operations. The flow combiner check valve (N) prevents back flow past the flow combiner valve. The left propel valve does not receive supply oil from the rear pump (Q) except through the propel flow control valve if the upstream pressure is higher than the pressure in the flow combiner circuit.

The dig and propel pressure switches are actuated to send an electrical signal to engine and pump controller when the propel and dig functions are actuated.

When just the propel function is actuated, the left propel valve is supplied with oil from the rear pump and the right propel valve is supplied with oil from the front pump.

Theory of Operation




9025
05
49

T109074 -19-23APR97

T109074

TX.05.GG2179 -19-08JUN98-2/2

ARM REGENERATIVE VALVE OPERATION



(H) ARM REGENERATIVE VALVE

9025
05
50

T102962

T102962 -19-17AUG96


The arm regenerative valve (H) is used to improve arm controllability and prevent arm cylinder (A) cavitation during arm IN operation by combining the return oil from arm cylinder rod end with the pump supply oil to the arm cylinder head end.

Under the following operating conditions: low rear pump delivery pressure, high pilot pressure to the pilot cap for arm in, and boom up actuated, gravity can pull the arm in faster than the pump can supply oil to the arm cylinder head end. The operating conditions are sensed by the rear pump pressure sensor (I), arm in pressure sensor (K), and boom up pressure switch (L). The pressure switch and sensors send electrical signals to the engine and pump controller (M). The

engine and pump controller sends an electrical signal to the arm regenerative solenoid valve (D) to energizes the coil. The solenoid valve then sends a pressure signal to the arm regenerative valve spool (E) to shift it blocking the passage to return. The return oil from the rod end of arm cylinder now flows through the arm regenerative circuit check valve (C) and then to the head end of arm cylinder with the pump supply oil. Return oil not used flows through the orifice (J) to the return passage.

There are five check valves located in the passages to the arm I valve to prevent back flow through the control valve. For arm in function, return and supply oil flows through the arm I valve only.

Theory of Operation



T102986


(N) ARM REGENERATIVE VALVE CIRCUIT

T102986 -19-17AUG96

9025
05
51

TX,05,GG2185 -19-08JUN98-2/2

BOOM AND ARM REDUCED LEAKAGE VALVES OPERATION



T115414

(G) BOOM REDUCED LEAKAGE VALVE

Reduced leakage valves (G) are used in the boom head end circuit and arm rod end circuit. The function of a reduced leakage valve is to reduce cylinder drift by stopping leakage from the cylinder back through the control valve.

When the control valve is in neutral, the oil pressure generated in the boom cylinder head end or arm cylinder rod end by the load on the cylinders is applied to the top (spring end) of check valve poppet (E) through the pilot valve (F). The poppet is held closed against the seat in housing trapping the oil from the cylinder at the work port.

When boom down or arm in function is actuated, the pilot pressure signal (C) from the pilot controller also


shifts the pilot valve (F). The oil pressure from the cylinder is blocked by the pilot valve. The oil pressure at the top (spring end) of check valve poppet can now flow through the pilot valve to the warm-up passage in the pilot caps and then to the hydraulic oil tank. The oil pressure from the cylinder pushes the poppet off its seat opening the passage for oil to flow into the control valve return passage. The poppet is pushed off its seat because the OD of upper land at the head end of poppet is slightly larger than the lower land.

The boom manual lower screw (H) is used to lower the boom if the engine should stop with the boom in the raised position. (See Lower Boom With Engine Stopped in Group 9025-25.)

T115414 -19-27MAY98

Theory of Operation

BUCKET FLOW CONTROL VALVE OPERATION



(M) BUCKET FLOW CONTROL VALVE

T103012

T103012 -19-20AUG96

Continued on next page

TX.05.GG2187 -19-20MAY98-1/2

9025
05
54

Theory of Operation

The bucket flow control valve (M) restricts oil flow to the bucket cylinder in the combined operations of bucket, arm in, and boom up to ensure supply oil flow goes to the higher-loaded boom function to raise the boom.

When arm in function is actuated the pilot pressure also shifts pilot valve A (E). If boom up function is


actuated the pilot pressure also flows through pilot valve A to shift pilot valve B (I) closing the passage from the poppet valve (G). The pressure on the back side of the poppet valve increases closing the poppet valve causing a restriction for supply oil flow through the poppet valve to the bucket valve (H).

TX,05,GG2187 -19-20MAY98-2/2

9025
05
55

Theory of Operation

PROPEL FLOW CONTROL VALVE OPERATION



(K) PROPEL FLOW CONTROL VALVE

T103020

The propel flow control valve (K) is used to reduce shock loads from the power passage (G). The shock loads are caused by the operation of dig functions upstream of the left propel valve (B).

The propel flow control valve is located in the power passage to the left propel control valve.

When a dig function (H) is actuated while propelling, the pilot pressure signal also flows through the orifice

in the orifice and check valve (A) assembly to gradually shift the propel flow control valve spool (D). The gradual shift of spool slowly restricts the flow of supply oil to the left propel valve reducing any shock loads.


The pilot pressure signal is released quickly through the check valve when all dig functions are returned to neutral. The propel flow control valve spool is shifted quickly to the open position by the spring.

T103020 -19-16AUG96

TX,05,GG2188 -19-20MAY98-1/1

Theory of Operation

PROPEL-BOOM DOWN SELECTOR VALVE OPERATION



T103034

Ⓘ PROPEL-BOOM DOWN SELECTOR VALVE

The function of propel-boom down selector valve (I) is to route the pilot controller pressure signal (F) to shift the boom II valve (A) also when the combined propel and boom down functions are actuated.

When just the boom down function is actuated, the pilot controller pressure signal (F) flows to the pilot cap to shift the boom I valve only. Pilot oil to the boom II valve is blocked by the propel-boom down selector valve spool (C). Front pump supply oil flows through the right propel valve (E) neutral passage to the boom I valve and out to the rod end of boom cylinders. Return oil from the head end flows through the boom I valve to return.

However, in a propel and boom down combined operations front pump supply oil is blocked by the right propel valve (E) and does not flow to the boom I valve (B). To get supply oil to the rod end of boom cylinders, the boom II valve (A) is shifted to route rear pump (H) supply oil to the cylinders. When the right propel valve (E) is actuated, the propel pilot pressure signal (D) increases shifting the propel-boom down selector valve spool (C). The pilot controller pressure signal can now flow through the selector valve and shift the boom II valve.

The return oil from the head end of boom cylinders still flows through the boom I valve to return.


T103034 -19-15AUG96

9025
05
57

TX,05,GG2189 -19-08JUN98-1/1

Theory of Operation

BOOM REGENERATIVE VALVE OPERATION



(H) BOOM REGENERATIVE VALVE

T109129

The function of boom regenerative valve (H) during boom down operation is to combine the return oil flow from head end of boom cylinders (G) with the pump supply oil to the rod end to prevent cavitation.

During boom down operation, if pump supply oil pressure is lower than the return oil pressure from the

head end the return oil pushes the boom regenerative valve poppet (C) open and flows to the rod end. Return oil not used flows through the boom regenerative valve orifice (D) to the return passage.


The boom I neutral passage check valve (E) prevents back flow through the control valve.

TX,05,GG2190 -19-20MAY98-1/1

T109129 -19-12MAY97

Theory of Operation

PROPEL AND ARM IN COMBINED OPERATION



9025
05
59

T116658

T116658 -19-24AUG98

Continued on next page

CED.OUOE035,132 -19-20MAY98-1/2

Theory of Operation

Actuating the propel and arm in functions in combined operation (S) shifts the left (R) and right (J) propel valves and the arm II (K) and arm I (P) valves. With the valves shifted, pilot oil flow through the dig pilot pressure signal passage (G) is blocked by the arm II valve causing the pilot oil pressure in the passage to increase. The increased pressure shifts the flow combiner valve (C), propel flow control valve (B), and swing park brake release valve (D).

Supply oil from the front pump (N) flows through the right propel valve (J) to turn the right propel motor (I) as well as through the flow combiner valve (C) and left


propel valve (R) to turn the left propel motor (A). Because one pump is used to supply oil to both propel motors, the machine can propel straight even when the arm in function is actuated in combined operation with the propel function. The check valve (H) prevents back flow through the flow combiner valve.

Supply oil from the rear pump (O) flows through the arm I valve (P) to move the arm cylinder (Q). Supply oil from the rear pump can flow through the check valve and propel flow control valve (B) if upstream pressure is higher than pressure in the flow combiner valve passage.

CED,OUOE035,132 -19-20MAY98-2/2

Theory of Operation

SWING AND BOOM UP COMBINED OPERATION



ⓐ SWING AND BOOM UP COMBINED

T113344

9025
05
61

T113344 -19-17FEB98

Theory of Operation

Actuating the swing and boom up in combined operation (J) shifts the swing valve (E), boom I valve (B), and boom II valve (I).

Pressure oil from the front pump (F) flows through the power passage (A) and boom I valve and out to the boom cylinders (C) to raise the boom. At the same time pressure oil from the rear pump (G) flows through the swing valve (E) and out to the swing motor to swing the upperstructure.


Pressure oil not used by the swing function flows through the power passage (D) and boom II valve (I). The pressure oil combines with the pressure oil from the front pump and flows to the boom cylinders. The boom is raised by combined oil flow from the front and rear pumps.

CED, TX08227, 2991 -19-09FEB98-2/2

9025
05
62

Theory of Operation

SWING GEARBOX OPERATION



(N) SWING GEARBOX

T103086

9025
05
63

T103086 -19-07SEP96

Continued on next page

TX.05.GG2193 -19-20MAY98-1/2

Theory of Operation

The swing gearbox (N) is a double reduction planetary drive type gearbox. The swing motor (A) is mounted on the swing gearbox and encloses the top side of gearbox. The output pinion (G) is in mesh with swing gear. Swing motor rotational speed is reduced by the double reduction planetary gear set.


The first planet sun gear (L) is connected to motor output shaft and is located between a retaining ring and thrust washer. The first planet gears (B) rotate around roller bearings on shafts in the first planet carrier (M). Rotation of the first planet carrier causes the second planet sun gear (J) to rotate. The second

planet sun gear is located between thrust washers. Second planet gears (C) rotate around shafts in the second planet carrier (I). The second planet carrier is connected to the output pinion (G) and this causes the output pinion to rotate.

The pinion rotates in two spherical roller bearings (D and H). Downward movement of pinion is prevented by a retaining ring seated against upper bearing. Upward movement is prevented by second sun pinion. Oil seal (F) prevents oil from leaking out of swing gearbox and keeps grease from coming in.

TX,05,GG2193 -19-20MAY98-2/2

SWING MOTOR OPERATION



(R) SWING MOTOR

T103087

The swing motor (R) consists of the rotating group, park brake, and cover (D). The cover contains the swing crossover relief valves (F), make-up check valves and inlet and outlet ports. The valve plate (E) is

held in position by dowel pins in the cover. The swing motor is a fixed displacement, axial piston, fixed position thrust plate (O) motor. It is bidirectional so the upperstructure can swing in both directions.

9025
05
65

T103087 -19-12SEP96

Theory of Operation

The rotating group consists of a cylinder block (A) with nine pistons and slippers (P). The cylinder block is connected to the output shaft (M). Each piston is connected to a slipper by a ball joint. Slippers slide on the inclined thrust plate (O) forcing the cylinder block to turn. Retainer (L) holds the slippers on the thrust plate and the retainer itself is held against the slippers by force pins (J) and spring (C).

Oil from swing control valve is routed through cover (D), valve plate (E), and port (B) to the pistons.

In operation, high pressure supply oil enters the cylinder bores through ports forcing pistons down against inclined thrust plate. The slippers slide down the inclined thrust plate causing the rotating group to turn. The output shaft is turned by the cylinder block. Swing speed varies depending on the amount of supply oil delivered by the pump through the control valve.


During the second half of motor's revolution, low pressure oil is discharged as pistons slide back up the

inclined thrust plate. To reverse rotation, oil flow is reversed. A small amount of supply oil flows through the center of each piston to ball joint and to face of slipper for lubrication.

The motor is internally lubricated from leakage inside the motor. Lubrication oil is routed up through the cover to the hydraulic oil tank.

The swing motor park brake is spring applied and hydraulically released. The plates in the brake pack (I) are connected to the housing. The disks are connected to and rotate with the cylinder block. When the pilot controllers are in neutral, pilot oil is blocked from the piston (H) by the swing park brake release valve (Q). The brake springs squeeze the plates and disks together to prevent the upperstructure from swinging. The swing park brake is released when the swing, boom, arm, or bucket function is actuated.

SWING MOTOR CROSSOVER RELIEF VALVE OPERATION



(J) SWING MOTOR CROSSOVER RELIEF VALVE

T103106

The function of swing crossover relief valve (J) is to relieve the high pressure generated in the swing circuit when starting or stopping the swing operation. The oil pressure in the swing circuit becomes high because of the inertia of the upperstructure to starting and stopping.

When the oil pressure in port (I) increases to the valve pressure setting, the relief poppet (H) is pushed off its


seat to relieve pressure oil to return. The pressure is also sensed in the chamber (E) through the orifice (G). The opening of the relief poppet is further dampened by the action of the piston (C), spring guide (B), and spring (A). Oil from the spring (A) chamber is release through the orifices in the spring guide and piston to the return passage (D). The relief poppet is pushed back to the right by the spring (F) and the pressure in the chamber.

T103106 -19-20AUG96

9025
05
67

Theory of Operation

SWING MOTOR MAKE-UP VALVE OPERATION



9025
05
68

T103116

T103116 -19-20AUG96


While stopping the swing function the control valve spools go to neutral and the lines to inlet ports (D) at the swing motor are blocked at the control valve. Because of the inertia of the upperstructure the oil pressure in one side of the swing motor becomes high. For a few seconds the motor acts like a pump. The relief poppet in the crossover relief valve opens to relieve the high pressure oil to the make-up oil port (B).

pressure on the other side of the motor until cavitation starts. When cavitation starts the make-up poppet (C) is pushed open by the return oil in the make-up oil port. The return oil flows in and prevents cavitation. The make-up oil port is connected to the return passage in the control valve. The return oil pressure is maintained by the restriction valve located downstream of the oil cooler.


Because the lines to the motor are blocked the continued rotation of the upperstructure lowers the

Theory of Operation

SWING MOTOR PARK BRAKE RELEASE VALVE OPERATION



I PARK BRAKE RELEASED




SWING MOTOR
PARK BRAKE
RELEASE VALVE
SPOOL (F)

PILOT OIL
PRESSURE (D)

DIG PILOT
PRESSURE
SIGNAL (A)

PISTON (B)

(K) BRAKE
PACK



J PARK BRAKE APPLIED

L SWING MOTOR PARK BRAKE RELEASE VALVE

T109165

Continued on next page

TX.05.GG2197 -19-20MAY98-1/2

9025
05
69

T109165 -19-21APR97

Theory of Operation

The function of swing motor park brake release valve (L) is to route pilot oil pressure (D) to the piston releasing the brake pack when a dig or swing function is actuated.

Park Brake Released (I):

When a swing or dig function is actuated, the flow of pilot oil through dig pilot pressure signal passage in the control valve is blocked by a valve spool (H). The dig pilot pressure signal (A) increases and shifts the swing motor park brake release valve spool (F). Pilot pressure oil (D) from the solenoid valve manifold flows through the spool to piston (B) chamber. The pilot pressure oil pushes the piston up against the spring releasing the brake pack (K). The upperstructure is now free to turn.

Park Brake Applied (J):


When the valve spool (H) is returned to neutral, pilot

oil flows through the dig pilot pressure signal passage to the return passage causing the pressure signal to decrease. The release valve spool (F) is shifted by the spring blocking the flow of pilot oil pressure to the piston (B) chamber. The oil in the piston chamber flows through the orifice (C) to return as the springs push the piston down applying the park brake. The oil is metered through the orifice to slow engagement to ensure that park brake is only fully applied after the upperstructure has stopped. The orifice and check valve is located in the swing motor housing adjacent to the swing motor park brake release valve.

Pilot oil pressure (D) is maintained at the release valve spool (F) as long as the pilot shutoff valve is ON. The circuit for pilot oil pressure is from the pilot pump (E), through the pilot shutoff valve, solenoid valve manifold, and then to the release valve spool.

Theory of Operation

ROTARY MANIFOLD OPERATION



T109474

The rotary manifold (J) is a 360° rotary joint. It allows oil to flow to and from the propel motors without twisting hoses when the upperstructure is rotated.

The inner spindle is connected to the upperstructure and the housing is connected to the undercarriage. The housing rotates about the spindle during swing operation.

Oil flows into and through the spindle to passages in the housing, and then out of the housing to the propel motors. Sealing rings stop oil from leaking between the spindle and housing into adjacent passages.


TX,05,GG2171 -19-20MAY98-1/1

T109474 -19-23JUN98

9025
05
71

Theory of Operation

PROPEL MOTOR OPERATION



PROPEL MOTOR

TXC7499AA

T7499AA -19-23APR97

Continued on next page

TX.05.GG2167 -19-20MAY98-1/2

Theory of Operation

The propel motor (S) is a variable-displacement, bent-axis, axial-piston type motor that includes the brake valve housing and propel park brake. The counterbalance valve, crossover relief valves, park brake release shuttle valve, pressure reducing valve, servo piston shuttle valve, and the servo piston (O) are integral components of the brake valve housing. The speed selector valve spool is located in the servo piston.

The servo piston (O) controls the angle of rotor (N), pistons (M) and center shaft (E) with respect to the

drive shaft (G). As the angle is changed the motor displacement changes which changes propel motor speed.


Supply oil flows through the valve plate (B) to half of the pistons (M) in the rotor (N). The oil forces the pistons to slide down the cylinder block bores transferring the force to the drive shaft (G) turning the drive shaft. As the cylinder block and drive shaft rotate, half of the pistons move out of their bores while the remaining pistons in the other half of the cylinder block move back in their bores to discharge oil to return.

TX,05,GG2167 -19-20MAY98-2/2

9025
05
73

Theory of Operation

PROPEL MOTOR SLOW SPEED OPERATION



T102854

T102854 -19-06MAY98

The servo piston (D) is connected by a link (C) to the valve plate (A). When servo piston is extended or retracted by supply oil pressure the angle of the rotary group (B) changes and the propel speed changes accordingly.


When propel speed is set to slow speed the bottom of speed selector valve spool (F) is open to return through the propel speed change solenoid valve. The spool (F) is pushed down by the spring (G). (For operation of propel speed change solenoid valve, see Proportional Solenoid Valve Operation in this group. For circuit operation, see Propel Motor Speed Change Circuit Operation in this group.)

Supply oil from motor port (J) is now applied to both chamber "A" (I) and chamber "B" (L) at the same time. Supply oil pressure in chamber "B" acts on a larger area than the supply oil pressure in chamber "A" causing the servo piston to move upward increasing rotary group swash angle. As the swash angle increases, the stroke of each piston is increased resulting in slower revolution of the propel motor for slower propel speed. (See Propel Motor Fast Speed Operation in this group.)

TX,05,GG2168 -19-20MAY98-1/1

Theory of Operation

PROPEL MOTOR FAST SPEED OPERATION



T102855 -19-06MAY98


9025
05
75

In fast speed the pilot oil (N), from the propel speed change solenoid valve (K), is higher than spring force and spool (F) is pushed up. The oil in chamber "B" is routed to return through motor case drain (H). Supply oil (M) from the motor port (J) is applied to chamber "A", servo piston (D) moves down to reduce rotary group (B) swash angle. With reduced swash angle the piston stroke is reduced which increases rotary group turning speed that increases propel speed.

NOTE: For operation of propel speed change solenoid valve, see Proportional Solenoid Valve Operation in this group. For circuit operation, see Propel Motor Speed Change Circuit Operation in this group.

Theory of Operation

PROPEL MOTOR SPEED CHANGE CIRCUIT OPERATION



(P) PROPEL SPEED CHANGE CIRCUIT

T109188

T109188 -19-23APR97

Continued on next page

TX.05.GG2200 -19-20MAY98-1/2

Theory of Operation

When the propel speed switch (A) is in slow speed, the propel speed change solenoid valve (N) coil is de-energized. The speed selector valve spools (E) are open to return through the solenoid valve. The propel motors (D and F) are at maximum displacement causing the machine to travel at slow speed.

The propel speed goes to fast with the following operating conditions:

- Propel speed switch is at fast speed.
- Propel pressure switch (H) in closed.
- Dig pressure switch (G) is open.
- Electrical signal for front (J) and rear (C) pump

control pressure sensors increases because pilot oil control signals from front and rear pump control valves are increasing.


- Rear and front pump pressure sensors (K) are sensing low supply oil delivery pressure.

When the electrical signals are received at the engine and pump controller (O), the controller sends an electrical signal to energize the solenoid valve (N) coil. The pilot oil pressure signal shifts the speed change valve spool (E) causing the motor to go to minimum displacement and the machine to travel at fast speed. (See Propel Motor Fast Speed Operation in this group.)

TX,05,GG2200 -19-20MAY98-2/2

9025
05
77

PROPEL MOTOR PARK BRAKE VALVE HOUSING OPERATION



9025
05
78

© PROPEL MOTOR PARK BRAKE VALVE

T109195

The propel motor park brake valve (G) housing contains the park brake release shuttle valve (A), park brake pressure reducing valve (B), crossover relief

valve (C), check valves (D), counterbalance valve (E), servo piston shuttle valve (F) and servo piston.

Theory of Operation

Park brake release shuttle valve (A) routes supply oil from the pressurized motor port through a groove in the counterbalance valve (E), to the park brake pressure reducing valve (B), and then to the park brake piston to release the park brake.

Park brake pressure reducing valve (B) reduces the supply oil pressure routed to the park brake to prevent sudden brake application.

Crossover relief valves (C) protect the motor circuit from pressure spikes.

Check valves (D) ensure smooth starts and stops, and prevent motor cavitation by working together with the counterbalance valve (E).

Counterbalance valve (E) is used for smooth starting and stopping and helps prevent overrunning of the motor when traveling down a slope.


Servo piston shuttle valve (F) routes supply oil from the pressurized motor port to the servo piston. (For operation of servo piston and speed selector valve, see Propel Motor Slow Speed Operation and Propel Motor Fast Speed Operation in this group.)

TX,9025,GG2612 -19-20MAY98-2/2

9025
05
79

Theory of Operation

PROPEL MOTOR PARK BRAKE RELEASE CIRCUIT OPERATION



(K) PROPEL MOTOR PARK BRAKE RELEASE

T109202

Continued on next page

TX.9025.GG2613 -19-20MAY98-1/2

T109202 -19-18APR97

9025
05
80

Theory of Operation

Propel park brake is spring applied and hydraulically released type brake. Brake is applied by a disk spring (B) whenever the propel control valve spools are in neutral. The plates in the brake pack (D) are connected to the motor housing. The disks are connected to and rotate with the drive shaft (E). The disk spring pushes against the piston to squeeze the plates and disks together to keep the machine from moving.

When the propel pilot controllers are actuated the propel valve spools route supply oil to the bottom work port of propel motor for forward travel or the top work port for reverse travel. The supply oil flows into the chamber (J) at the end of counterbalance valve (G). At the same time supply oil moves the park brake release shuttle valve (H) to route supply oil to the park brake pressure reducing valve (A) but is blocked by the counterbalance valve. When supply oil pressure increases enough to shift the counterbalance valve, supply oil flows through the groove (I) to the park

brake pressure reducing valve. The pressure reducing valve operates to reduce the supply oil pressure. Reduced pressure oil flows to the brake piston (C) to move it against the disk spring (B) force and releases the park brake. Oil not used to release the park brake flows through the orifice in the reducing valve spool and into the propel motor housing (F).


When propel pilot controllers are returned to neutral, supply oil is blocked by the valve spools and the propel motor work ports are open to the control valve return passage. The counterbalance valve (G) returns to its neutral position causing the machine to slow and then stop (dynamic braking). The pressure reducing valve (A) is shifted by its spring. The disk spring (B) pushing against the brake piston (C) forces the oil to flow through the orifice in the reducing valve and into the propel motor housing (F). The delay caused by the oil flowing through the orifice is enough to slow engagement to ensure that park brake is only fully applied after the machine has stopped.

TX,9025,GG2613 -19-20MAY98-2/2

9025
05
81

Theory of Operation

PROPEL MOTOR COUNTERBALANCE VALVE OPERATION



Ⓚ COUNTERBALANCE VALVE -- PROPELLING

T109206

T109206 -19-23APR97

Continued on next page

TX.9025.GG2614 -19-20MAY98-1/2

9025
05
82

Theory of Operation

When the propel valve spools in the main control valve are in neutral position, counterbalance valve (J) is held in the center position by springs (B) on both ends of counterbalance valve. Both propel motor oil lines are connected to the control valve return passage. Oil in each motor is trapped by check valves (C and F) and counterbalance valve (J) holding the motors stationary. The park brake release circuit is also routed to return and the brake spring hold the brake on.

When the propel pilot controller is moved to forward position, supply oil is routed from the propel valves in the control valve to bottom work port (G). If propel pilot controller is moved to reverse position, supply oil would be routed to top work port (A).

In forward direction, supply oil enters bottom work port (G), flows around counterbalance valve to check valve (F). Check valve opens and oil flows into the motor.

Return oil from the motor is blocked by check valve (C) and counterbalance valve (J). This, along with the motor's resistance to turning, causes pressure in bottom work port (G) to increase. The increasing pressure is also sensed at the end of counterbalance valve through orifice (H). As pressure increases, the spool is pushed upward against the spring force. As spool moves up, oil from the motor flows past notches in the counterbalance valve to the top work port (A) and the propel motors start to turn. Supply oil is also routed to the park brake release circuit (I) to release the park brake. (For park brake release circuit operation, see Propel Motor Park Brake Release Circuit Operation in this group.)

When the propel pilot controller is returned to neutral position, the oil in both work ports (A and G) is routed

to control valve return passage. Both check valves will seat and counterbalance valve will center trapping oil in the motor to prevent rotation. Oil will also flow back through the brake passage to the motor housing and the park brake will engage after the propel motor stops rotating. At the same time, the shock pressure caused by the inertia force of the motor stopping is released through the crossover relief valves (D and E). Check valves (C and F) have a make-up function to prevent cavitation in the motor.

When traveling down a hill, the weight of the machine may begin to overrun the propel motors. This would cause faster travel than desired and cause cavitation at the inlet side of motors. As pressure decreases in the inlet passage of the motor, the pressure holding the counterbalance valve also decreases. Spring (B) force moves the counterbalance valve down thus restricting return flow from the motor slowing motor rotation. This is called "dynamic braking".


During normal operation supply oil from the control valve is routed past the counterbalance valve and check valve to the motor. Supply oil is also routed to the crossover relief valves (D and E). The crossover relief valves are direct acting relief valves with a cushion sleeve. Supply oil is sensed on the end of poppet of one relief valve. Oil also pushes the sleeve up on the other relief valve to help keep its poppet closed.

During relief operation oil pressure overcomes spring force pushing the poppet off its seat. Pressure oil is relieved from the passage that is pressurized to the passage that is at return pressure bypassing the motor.

9025
05
83

Theory of Operation

CYLINDER OPERATION



Ⓡ BUCKET CYLINDER

T109208

The boom, arm, and bucket cylinders are similar in design. The bucket cylinder (R) is illustrated. The rod guide (Q) is fastened to the cylinder barrel with cap screws and is fitted with a wear guide (F) held in place by a snap ring (G). A buffer ring (E), U-cup seal (D), backup ring (C), and wiper seal (B) are used in the rod guide. A snap ring (A) is used to help hold wiper seal in place. The U-cup seal (D) is protected against high pressure by the buffer ring (E) and stops the small amount of oil which may pass by the buffer ring.


The piston (H) is a slip fit on the cylinder rod (P) and is retained with a nut (M). A set screw (L) prevents loosening of the nut. The piston is fitted with a cap seal (K), wear rings (J), and buffer rings (I).

Boom, bucket and arm cylinders have a cushion (N) in front of the piston to provide cushioning action in cylinder extension. As the cylinder nears the end of stroke the cushion enters a bore in the rod guide. The remaining return oil ahead of piston must flow through a small clearance between the cushion and rod guide. Only the arm cylinder is cushioned in retraction. The end of the rod enters a bore in the head end of the cylinder. The remaining return oil ahead of the piston and nut must flow through this small clearance as the cylinder bottoms out in this direction.

T109208 -19-21APR97

Theory of Operation

RETURN FILTER OPERATION



T101917

The filter element (A) is located in a chamber inside the hydraulic oil tank. O-rings are used at each end of the filter element to prevent leakage. A spring holds the filter element on its seat.

Return oil from the oil cooler (D) and the control valve (E) flow through the filter element from the outside to the center. Filtered oil flows out the bottom of filter into the hydraulic oil tank.

A bypass valve (B) is located at the top of the filter. The valve opens to protect the filter element against

pressure surges in the return circuit and allows a path for return oil if the filter element becomes plugged. During bypass operation, oil flows into the chamber faster than it can flow through the filter element causing the pressure to increase. The higher pressure forces the bypass valve open allowing oil to flow down the center of the filter element and into the hydraulic oil tank. The bypass valve closes when the pressure decreases below the pressure setting of the bypass valve.


TX,05,GG2147 -19-10JUL96-1/1

T101917 -JUN-11JUL96

9025
05
85

Theory of Operation

BOOM CYLINDER CONTROLLED LOAD LOWERING VALVE OPERATION



- (A) PILOT VALVE
- (B) METERING VALVE
- (C) CIRCUIT RELIEF VALVE
- (D) POPPET VALVE

- (E) SUPPLY OIL
- (F) TRAPPED OIL
- (G) RETURN OIL
- (H) PILOT OIL

① BOOM CYLINDER CONTROLLED LOAD LOWERING VALVE

T120994

T120994 -19-27MAY99

Continued on next page

CED.OUOE020.75 -19-26MAY99-1/2

Theory of Operation

Boom cylinder controlled load lowering valves are used in the boom circuit. The function of the boom cylinder controlled load lowering valve is to prevent the boom from falling by maintaining pressure in the circuit in case of a rupture.

Pressure oil from head end of the boom cylinder flows through pilot valve (1). The oil flows to the spring end of poppet valve (2), closing the passage of oil from the

boom cylinder to sump. In the down position, pilot oil moves pilot valve (1) against spring force closing off oil flow from the boom cylinder to spring end of poppet valve (2). Oil flowing from the boom cylinder to the plunger side of poppet valve (2) overcomes the spring force and allows oil to flow through valve (3) and back to sump. Valve (3) is metered open from pilot pressure applied by pilot valve (1).


CED,OUOE020,75 -19-26MAY99-2/2

9025
05
87

Theory of Operation

AUXILIARY HYDRAULICS OPERATION

- TRAPPED OIL
- RETURN OR PRESSURE FREE OIL
- PILOT OIL



9025
05
88

T121560

T121560 -19-11OCT99

Continued on next page

CED.OUOE020.76 -19-03JUN99-1/2

Theory of Operation

The auxiliary hydraulic circuit is used to power the hydraulic clamp on the model (250LCR), the rock drill attachment on the model (250LCRD) and the hose reel on both models. The auxiliary lines use screw-together couplers to attach the attachment hoses. The couplers can be connected under pressure.

The hydraulic clamp requires two-way hydraulic flow. A foot pedal located in the cab is used to control the two-way movement of the hydraulic clamp by varying the foot pedal either up or down. The foot pedal auxiliary pilot controller is connected directly to both ends of the auxiliary spool. The auxiliary spool controls the amount of and direction of pilot oil to the auxiliary spool, which in turn controls the oil flow and the clamp cylinder.

The rock drill (Type II machine) requires flow in only one direction. A switch located on the control panel inside the cab activates a solenoid valve which directs pilot pressure to the top of the main auxiliary spool. This shifts the spool to direct pressure oil to the

attachment plumbing. The return circuit is a low pressure only circuit and returns directly to the return line just before it enters the reservoir. The rock drill return oil does not go through the oil cooler circuit.

The hydraulics for the hose reel is activated by a micro switch located behind the cab. Turning the micro switch to the ON position will energize a solenoid and allow pilot oil to flow to the check valve and then to the flow regulator. The flow regulator is located next to the micro switch and contains a lever so that the operator can control the amount of oil sent to the hose reel. At the same time, oil is flowing through the pressure reducing valve to deswash the front pump so it will disable the main valves (Arm, Boom, Proper, and Bucket) by not providing oil flow to them.

The system also controls the flow volume of oil to the rock drill, hydraulic clamp and hose reel by reducing the pump regulation pressure with a pressure reducing valve. This controls the stroke of the pump to provide only the amount of oil needed by the attachments.

Theory of Operation

HYDRAULIC SYSTEM CIRCUIT SYMBOLS

These are ISO and ANSI standard hydraulic symbols for use in reading circuit diagrams.

Pumps		Valves			
HYDRAULIC PUMP FIXED DISPLACEMENT UNIDIRECTIONAL		CHECK		PRESSURE COMPENSATED	
VARIABLE DISPLACEMENT UNIDIRECTIONAL		ON-OFF (MANUAL SHUT-OFF)		SOLENOID, SINGLE WINDING	
Motors and Cylinders		PRESSURE RELIEF		REVERSING MOTOR	
HYDRAULIC MOTOR FIXED DISPLACEMENT UNIDIRECTIONAL		PRESSURE REDUCING		PILOT PRESSURE REMOTE SUPPLY	
VARIABLE DISPLACEMENT UNIDIRECTIONAL		FLOW CONTROL ADJUSTABLE - NON-COMPENSATED		INTERNAL SUPPLY	
CYLINDER SINGLE ACTING		FLOW CONTROL ADJUSTABLE (TEMPERATURE AND PRESSURE COMPENSATED)		Lines	
CYLINDER DOUBLE ACTING		TWO POSITION TWO CONNECTION		LINE, WORKING (MAIN)	
SINGLE END ROD		TWO POSITION THREE CONNECTION		LINE, PILOT (FOR CONTROL)	
DOUBLE END ROD		TWO POSITION FOUR CONNECTION		LINE, LIQUID DRAIN	
ADJUSTABLE CUSHION ADVANCE ONLY		THREE POSITION FOUR CONNECTION		HYDRAULIC FLOW, DIRECTION OF PNEUMATIC	
DIFFERENTIAL PISTON		TWO POSITION IN TRANSITION		LINES CROSSING	
Miscellaneous Units		Methods of Operation		LINES JOINING	
ELECTRIC MOTOR		SPRING		LINE WITH FIXED RESTRICTION	
ACCUMULATOR, SPRING LOADED		MANUAL		LINE, FLEXIBLE	
ACCUMULATOR, GAS CHARGED		PUSH BUTTON		STATION, TESTING, MEASURE- MENT OR POWER TAKE-OFF	
HEATER		PUSH-PULL LEVER		TEMPERATURE CAUSE OR EFFECT	
COOLER		PEDAL OR TREADLE		RESERVOIR VENTED PRESSURIZED	
TEMPERATURE CONTROLLER		MECHANICAL		LINE, TO RESERVOIR ABOVE FLUID LEVEL	
FILTER STRAINER		DETENT		BELOW FLUID LEVEL	
PRESSURE SWITCH					
PRESSURE INDICATOR					
TEMPERATURE INDICATOR					
DIRECTION OF SHAFT ROTATION ASSUME ARROW ON NEAR SIDE OF SHAFT.					

TS700 -19-28SEP89

FOLDOUT PAGES 6-87 THRU 6-89 ARE AT REAR OF MANUAL

DIAGNOSTIC PROCEDURE

Follow the six basic steps below to carry out troubleshooting efficiently.

1. Know the system.

Study the machine technical manual. Understand the system and circuits. Use schematics, component location drawings, and theory of operation for each circuit and circuit components to better understand how the system, circuits and components work.

2. Ask the operator.

What type of work was the machine doing when the trouble was noticed?

Did the trouble start suddenly or has it been getting worse?

Did the machine have any previous problems? If so, which parts were repaired?

3. Inspect the machine.

Check all daily maintenance points. (See the operators manual. Check batteries, fuses, fusible link, and electrical connections.

4. Perform Operational Checkout.

Check all systems and functions on the machine. Use the helpful diagnostic information in the checkout to pinpoint the possible cause of the problem.

5. Perform troubleshooting.

Connect the laptop computer with excavator diagnostic software, if available. The self-diagnosing function lists any fault codes and gives corrective action information.

Before starting any troubleshooting first check battery voltage, fusible link, and fuses.

Go to test groups to check pressures and voltages. Make sure adjustment are correct.

6. Trace a cause.

Before reaching a conclusion, check the most probable and simplest to verify. Use the flow charts and symptom, problem, solution charts to help identify probable problem components.

Make a plan for appropriate repair to avoid other malfunctions.

Diagnostic Information

DIAGNOSE ELECTRONIC AND CONTROL VALVE COMPONENT MALFUNCTIONS

	Engine Control Motor (EC Motor)	Engine Control Sensor (EC Sensor)	Engine rpm Dial
Operational Function	Move fuel injection pump lever.	Senses position of EC motor	Signal to EC motor to set target engine speed.
Control Problem	Fuel injection pump lever does not move	Loss of EC motor position sensing.	Speed does not change when dial is turned.
Machine Symptoms	Turning engine rpm dial does not increase or decrease engine speed.	Engine speeds slower than speed selected by engine rpm dial and E mode switch. Cannot control speed.	Speed is held at 1600 rpm. (Auto-idle function operates and engine stops by turning key switch off.)
Laptop Computer with Excavator Diagnostic Software Self-Diagnostic Functions	—	01 Fault code is displayed	07 Fault code is displayed.
Laptop Computer with Excavator Diagnostic Software Monitoring Function	—	Monitor No. 2, EC angle. Typical voltage for slow idle is 2.5 volts.	Monitor No. 13, Target Engine Speed.
Harness Check	Install JT07065 Test Harness. Check for control signal.	Install JT07066 Test Harness. Typical voltage for slow idle is 2.5 volts.	—
Note	Engine stopped by fuel shut-off solenoid. If solenoid fails, engine turns over but does not start.	If EC sensor has failed, engine learning control does not work.	—
Description of Operation	See Engine Speed Control System Operation in Group 9010-05.	See Engine Speed Learning Control Circuit Operation in Group 9010-05.	See Engine RPM Dial Speed Control Circuit Operation in Group 9010-05.

Continued on next page

TX,15,GG2238 -19-13AUG98-1/10

Diagnostic Information

	Pump Control Pressure Sensor	Pump Pressure Sensor	Engine Speed Sensor (N Sensor)
Operational Function	Senses pump control valve pressure in control valve to control propel motor speed change	Senses front and rear pump delivery pressure.	Senses actual engine speed for the speed sensing system.
Control Problems	No sensor output signal. No control signal to propel speed change solenoid valve.	Loss of propel speed control and HP (high power) mode.	Speed sensing system does not function.
Machine Symptoms	Propel motor operates at slow speed when propel speed switch is turned to fast speed.	Propel speed does not increase when propel speed switch in fast speed (rabbit). HP mode does not work.	Does not affect machine operation except speed sensing.
Laptop Computer with Excavator Diagnostic Software Self-Diagnostic Functions	04 and 05 Fault codes are displayed.	02 and 03 Fault codes are displayed.	—
Laptop Computer with Excavator Diagnostic Software Monitoring Function	Monitor No. 1 and 6, Front and rear pump control pressure.	—	Monitor No. 14, Actual engine speed.
Harness Check	—	—	—
Notes	At slow idle with functions in neutral typical pressure is 1725—1930 kPa (17—19 bar) (250—280 psi). A lower pressure may be an open circuit. A higher pressure may be a short circuit.	During combined operation, arm speed is slow if malfunction is at sensor for rear pump.	—
Description of Operation	See Propel Motor Speed Change Circuit Operation in Group 9025-05.	See Propel Motor Speed Change Circuit Operation in Group 9025-05 or HP (High Power) Mode Speed Control Circuit Operation in Group 9010-05.	—

9025
15
3

Continued on next page

TX,15,GG2238 -19-13AUG98-2/10

Diagnostic Information

	Power Boost Solenoid Valve (SG)	Speed Sensing Solenoid Valve (SD)	Arm Regenerative Solenoid Valve (SC)
Operational Function	Sends a pilot pressure signal to temporary increase system relief valve pressure setting.	Sends a pilot pressure signal to load piston in pump regulators to reduce pump flow.	Sends a pilot pressure signal to shift the arm regenerative valve.
Control Problems	No pressure signal sent to system relief valve. System relief valve pressure setting does not increase.	No pressure signal sent to load piston in pump regulators.	No pressure signal sent to shift arm regenerative valve.
Machine Symptoms	Digging or lifting force does not increase.	Torque required to drive pumps exceed engine output power. Engine speed can decrease below rated speed.	During arm in operation, there is arm cylinder cavitation and controllability becomes less.
Laptop Computer with Excavator Diagnostic Software Self-Diagnostic Functions	—	—	—
Laptop Computer with Excavator Diagnostic Software Monitoring Function	Monitor No. 12, Power boost control pressure.	Monitor No. 11, Speed sense control pressure.	Monitor No. 9, Arm regenerative control pressure.
Harness Check	Install JT07062 Test Harness. Check that indicator light is on.	Install JT07062 Test Harness. Check that indicator light is on.	Install JT07062 Test Harness. Check that indicator light is on.
Notes	If indicator light is off, check wiring harness.	If indicator light is off, check wiring harness.	If indicator light is off, check wiring harness.
Description of Operation	See Power Boost Control Circuit Operation in Group 9025-25.	See Engine Speed Sensing Control Circuit Operation in Group 9025-25.	See Arm Regenerative Valve Operation in Group 9025-05.

Continued on next page

TX,15,GG2238 -19-13AUG98-3/10

9025
15
4

Diagnostic Information

	Propel Speed Change Solenoid Valve (SI)	Propel Pressure Switch	Dig Pressure Switch
Operational Function	Sends a pilot pressure signal to shift speed selector valve spool in propel motors.	Senses when propel function is actuated.	Senses when a dig function is actuated.
Control Problems	No pressure signal sent to shift speed selector valve spool.	No electrical signal sent to engine and pump controller.	No electrical signal sent to engine and pump controller.
Machine Symptoms	Travel speed does not increase when propel speed switch is turned to fast speed (rabbit).	Engine speed does not increase from auto-idle speed when propel function actuated. Propel speed does not increase with propel speed switch in fast speed (rabbit). Travel alarm does not sound.	Engine speed does not increase from auto-idle speed when a dig function actuated.
Laptop Computer with Excavator Diagnostic Software Self-Diagnostic Functions	—	—	—
Laptop Computer with Excavator Diagnostic Software Monitoring Function	Monitor No. 10, Propel motor control pressure.	Monitor No. 20, Pressure switch.	Monitor No. 20, Pressure switch.
Harness Check	Install JT07062 Test Harness. Check that indicator light is on.	—	—
Notes	If indicator light is off, check wiring harness. Also check switches and sensors in propel motor speed change circuit.	Located at the front of right control valve.	Located at the front of left control valve.
Description of Operation	See Propel Motor Speed Change Circuit Operation in Group 9025-05.	See Propel Motor Speed Change Circuit Operation in Group 9025-05 or Auto-Idle Mode Speed Control Circuit Operation in Group 9010-05.	See Auto-Idle Mode Speed Control Circuit Operation in Group 9010-05.

9025
15
5

Continued on next page

TX,15,GG2238 -19-13AUG98-4/10

Diagnostic Information

	Boom Up Pressure Switch	Arm In Pressure Sensor	Learning Switch
Operational Function	Senses boom up pilot pressure signal.	Senses arm in pilot pressure signal.	To start engine speed learning function.
Control Problems	No electrical signal sent to engine and pump controller.	No electrical signal sent to engine and pump controller.	Engine speed learning function does not operate.
Machine Symptoms	No regenerative function during boom up and arm in.	HP (high power) mode does not function. Arm speed slow when leveling.	For an open circuit, engine speed control system operates normally. Engine speed learning control cannot be actuated. For a short circuit, learning control is actuated when key switch is turned ON.
Laptop Computer with Excavator Diagnostic Software Self-Diagnostic Functions	—	06 Service Code is displayed	—
Laptop Computer with Excavator Diagnostic Software Monitoring Function	Monitor No. 20, Pressure switch.	Monitor No. 5, Arm Roll-In Pilot Pressure.	Monitor No. 28, Engine learning control.
Harness Check	—	—	—
Notes	Switch needed for arm regenerative operation.	Sensor needed for HP mode and arm regenerative operation.	—
Description of Operation	See Arm Regenerative Valve Operation in Group 9025-05.	See Arm Regenerative Valve Operation in Group 9025-05 and HP (High Power) Mode Speed Control Circuit Operation in Group 9010-05.	See Engine Speed Learning Control Circuit Operation in Group 9010-05.

Continued on next page

TX,15,GG2238 -19-13AUG98-5/10

9025
15
6

Diagnostic Information

	Power Boost Switch	HP (High Power) Mode Switch	E (Economy) Mode Switch
Operational Function	To actuate the power boost function.	To actuate the HP mode function.	To actuate the E mode function
Control Problems	For open circuit, no electrical signal to engine and pump controller. For short circuit, operates for 8 seconds when key switch turned on, but then becomes inoperative.	No electrical signal to engine and pump controller. For short circuit, electrical signal to engine and pump controller at all times.	For open circuit, no electrical signal to engine and pump controller. For short circuit, electrical signal to engine and pump controller at all times.
Machine Symptoms	Digging or lifting force does not increase.	For open circuit, engine speed does not increase when hydraulic pressure increases to specified pressure. For short circuit, engine speed increases even with switch off (up).	For open circuit, engine speed does not decrease from fast idle. For short circuit, engine speed does not increase to fast idle.
Laptop Computer with Excavator Diagnostic Software Self-Diagnostic Functions	—	—	—
Laptop Computer with Excavator Diagnostic Software Monitoring Function	Monitor No. 25, Power boost switch	Monitor No. 24, HP mode switch.	Monitor No. 22, E mode switch.
Harness Check	—	—	—
Notes	Power boost function operates for 8 seconds after switch is pushed.	HP indicator light on when switch is on (down).	E indicator light on when switch is on (down).
Description of Operation	See Power Boost Control Circuit Operation in Group 9025-25.	See HP (High Power) Mode Speed Circuit Operation in Group 9010-05.	See E (Economy) Mode Speed Control Circuit Operation in Group 9010-05.

9025
15
7

Continued on next page

TX,15,GG2238 -19-13AUG98-6/10

Diagnostic Information

	Propel Speed Switch	Engine and Pump Controller (EPC)	Front and Rear Pump Control Valve
Operational Function	To change propel speed.	To control engine speed, pump and valve operations.	To send a regulated pilot pressure signal to pump regulators in responds to the flow rate through neutral passages in control valve.
Control Problems	No electrical signal sent to engine and pump controller.	Problems may differ depending on the malfunction.	Pressure signal to regulator does not increase when a function is actuated. Pump stays at minimum flow.
Machine Symptoms	For open circuit, propel speed stays at slow speed when switch is turned to fast speed (rabbit).	Problems listed indicate malfunction in EPC. With key switch on, EC motor does not go to start position; engine starts and run at slow idle. Engine speed does not change. Pump stays at minimum, all functions are slow.	For rear pump control valve: left propel cycle time slow, swing also slow; cycle time for bucket, boom or arm almost normal. For front pump control valve: bucket cycle time very slow, boom not raised when leveling, right propel cycle time slow; cycle time for boom, arm, or swing almost normal.
Laptop Computer with Excavator Diagnostic Software Self-Diagnostic Functions	—	—	—
Laptop Computer with Excavator Diagnostic Software Monitoring Function	Monitor No. 26, Propel speed switch.	—	Monitor No. 1, Front pump control pressure and No. 6, Rear pump control pressure.
Harness Check	—	—	—
Notes	Check switches and sensors in propel speed control circuit.	Check fuses before replacing EPC.	—
Description of Operation	See Propel Motor Speed Change Circuit Operation in Group 9025-05.	See Engine and Pump Controller Circuit Theory of Operation in Group 9015-15.	See Pump Control Valve Operation in Group 9025-05.

Continued on next page

TX,15,GG2238 -19-13AUG98-7/10

9025
15
8

Diagnostic Information

	Flow Combiner Valve	Arm I Power Passage Check Valve and Restriction Orifice	Arm I Neutral Passage Check Valve and Restriction Orifice
Operational Function	To supply oil to left and right propel spools during combined operation of dig and propel functions.	—	—
Control Problems	Sticking or stuck spool. Oil is insufficient or not supplied to left propel spool.	Oil from left control valve power passage insufficient or not supplied to arm I spool.	Oil from right control valve neutral passage insufficient or not supplied to arm I spool.
Machine Symptoms	While traveling straight, machine mistracks when swing is actuated.	Arm speed slow when leveling.	When check valve is stuck closed or orifice clogged, arm speed is slow when leveling
Laptop Computer with Excavator Diagnostic Software Self-Diagnostic Functions	—	—	—
Laptop Computer with Excavator Diagnostic Software Monitoring Function	—	—	—
Harness Check	—	—	—
Notes	—	—	—
Description of Operation	See Flow Combiner Valve Operation in Group 9025-05.	See Control Valve Circuit Schematic in Group 9025-05.	See Control Valve Circuit Schematic in Group 9025-05.

9025
15
9

Continued on next page

TX,15,GG2238 -19-13AUG98-8/10

Diagnostic Information

	Arm Regenerative Valve	Propel Flow Control Valve	Propel-Boom Down Selector Valve
Operational Function	To route oil from rod end to head end of cylinder during arm in when shifted by arm regenerative solenoid valve.	To reduce shock load created by going from propel operation to combined operation of propel and dig by gradually restricting oil flow from power passage.	To ensure boom down force during combined operation of propel and boom down.
Control Problems	No pressure signal from arm regenerative solenoid valve to shift arm regenerative valve spool. Valve spool is sticking or stuck.	Oil flow not restricted because spool is stuck or no pressure signal to shift propel flow control valve spool.	Boom II spool not shifted during combined operation of propel and boom down. Boom II spool is shifted during just boom down operation.
Machine Symptoms	During arm in, there is arm cylinder cavitation and controllability becomes less.	When stuck closed, shocks felt when changing from propel to combined propel and dig operation. When stuck open, no boom up when combined with propel down a slope or with bucket loading.	When stuck closed: boom down speed is fast, swing speed slow at full stroke during combined swing and boom down operation.
Laptop Computer with Excavator Diagnostic Software Self-Diagnostic Functions	—	—	—
Laptop Computer with Excavator Diagnostic Software Monitoring Function	—	—	—
Harness Check	—	—	—
Notes	—	—	—
Description of Operation	See Arm Regenerative Valve Operation in Group 9025-05.	See Propel Flow Control Valve Operation in Group 9025-05.	See Propel-Boom Down Selector Valve Operation in Group 9025-05.

Continued on next page

TX,15,GG2238 -19-13AUG98-9/10

9025
15
10

Diagnostic Information

	Arm Reduced Leakage Valve	Boom Reduced Leakage Valve	Boom Regenerative Valve
Operational Function	To prevent arm in drift caused by leakage from the cylinder back through control valve.	To prevent boom down drift caused by leakage from the cylinders back through control valve.	To route return oil from head end to rod end of boom cylinder to prevent cavitation when lowering.
Control Problems	Sticking or stuck check valve or pilot valve. No pilot pressure signal to shift pilot spool.	Sticking or stuck check valve or pilot valve. No pilot pressure signal to shift pilot spool.	Sticking or stuck check valve.
Machine Symptoms	Arm drifts down. Arm in speed is slow or jerky if check valve sticking or does not open.	Boom drifts down. Boom down speed is slow or jerky if check valve sticking or does not open.	Boom lower speed becomes slow with check valve stuck closed. Cannot raise tracks off the ground using boom down with check valve stuck open.
Laptop Computer with Excavator Diagnostic Software Self-Diagnostic Functions	—	—	—
Laptop Computer with Excavator Diagnostic Software Monitoring Function	—	—	—
Harness Check	—	—	—
Notes	—	—	—
Description of Operation	See Boom and Arm Reduced Leakage Valve Operation in Group 9025-05.	See Boom and Arm Reduced Leakage Valve Operation in Group 9025-05.	See Boom Regenerative Valve Operation in Group 9025-05.

	Bucket Flow Control Valve
Operational Function	To restrict oil flow to bucket circuit in combined operation of bucket, arm in, and boom up to ensure oil flows to higher-loaded boom function to raise boom.
Control Problems	Pilot valves and poppet valve sticking or stuck.
Machine Symptoms	Bucket speed is slow if poppet valve is stuck closed. Boom is not raised in combined operation with poppet valve stuck open or pilot valves are stuck open keeping the poppet valve open.
Laptop Computer with Excavator Diagnostic Software Self-Diagnostic Functions	—
Laptop Computer with Excavator Diagnostic Software Monitoring Function	—
Harness Check	—
Notes	—
Description of Operation	See Bucket Flow Control Valve Operation in Group 9025-05.

9025
15
11

Diagnostic Information

DIAGNOSE HYDRAULIC SYSTEM MALFUNCTIONS

NOTE: Diagnose malfunction charts are arranged from most probable and simplest to verify, to least likely and most difficult to verify.

Symptom	Problem	Solution
All Hydraulic Functions Slow	Low oil level	Check oil level in hydraulic oil tank.
	Cold hydraulic oil	Heat hydraulic oil.
	Oil viscosity too heavy	Use the recommended oil. (See General Information Section.)
	Slow engine speed	Check engine fast and slow idle stop adjustment at injection pump. Do Engine Control Motor and Sensor Adjustment and Engine Speed Learning Procedure. See Group 9010-20.
	Air leak in pump suction line	Check for air bubbles in oil. Tighten clamps, replace O-rings.
	Pilot circuit malfunction	See Diagnose Pilot Circuit Malfunctions. See Group 9025-15.
	Restricted pump suction screen	Clean pump suction screen. See Group 3360.
	Front and rear pump regulators	Adjust pump regulators. See Group 9025-20.
	Worn pumps	Check flow rate using propel cycle times. Do Hydraulic Pump Flow Test. See Group 9025-25.
	System relief valve setting too low or malfunctioning	Check system relief valve setting. See Group 9025-25. Inspect. See Group 3360.
Circuit relief valve setting too low or malfunctioning	Check circuit relief valve setting. See Group 9025-25. Inspect. See Group 3360.	

Continued on next page

TX,15,GG2162 -19-13AUG98-1/3

Diagnostic Information

Symptom	Problem	Solution
	Low pilot oil pressure	Check pilot pressure regulating valve. See Group 9025-25.
	Front and rear pump control valves	Check pressure. See Group 9025-25. Inspect. See Group 3360.
Hydraulic Oil Overheats	Low oil level	Check oil level in hydraulic oil tank.
	Plugged oil cooler	Test air flow through oil cooler.
	Oil viscosity too light	Use recommended oil. See General Information Section.
	Return filter plugged	Replace filter. See Group 3360.
	System relief valve malfunction	Test system relief valve. See Group 9025-25.
	Oil cooler bypass valve stuck open	Repair or replace. See Group 3360.
	Restriction valve stuck closed	Repair or replace. See Group 3360.
	Fan belt slipping	Check for worn belt. Check tension adjuster. See Remove and Install Fan Belt in Group 0510.
	Pump stuck at maximum displacement	Check flow rate using propel cycle times. Do hydraulic pump flow test. See Group 9025-25.
No Hydraulic Functions	Pilot shutoff lever in LOCK position (rearward)	Push shutoff lever to UNLOCK position (forward).
	No oil	Check oil level in hydraulic oil tank.
	Pump drive failure	Check pump drive coupling. See Group 3360.
	Restricted pump suction screen	Clean pump suction screen. See Group 3360.
Poor Combined Operation	Dig or propel pressure switch	Check pressure switches. Check wiring harness. See Group 9015-15. See harness test in Group 9025-25.

9025
15
13

Diagnostic Information

Symptom	Problem	Solution
	Engine and pump controller	Check engine and pump controller. See Group 9015-15.
	Pilot controller	Check pilot pressure at control valve. See Group 9025-25.
	Pilot pressure regulating valve	Check pilot pressure regulating valve pressure setting. See Group 9025-25.
	Check valves and flow control valves in control valve	Inspect valves. See Group 3360.

TX,15,GG2162 -19-13AUG98-3/3

9025
15
14

Diagnostic Information

DIAGNOSE PILOT CIRCUIT MALFUNCTIONS

NOTE: Diagnose malfunction charts are arranged from most probable and simplest to verify, to least likely and most difficult to verify.

Symptom	Problem	Solution
All Functions Cannot Be Operated	Pilot shutoff lever in LOCK position (rearward)	Push shutoff lever to UNLOCK position (forward).
	Pilot pressure regulating valve stuck open	Test pilot pressure regulating valve. See Group 9025-25. Inspect. See Group 3360.
	Pilot pump failure	Remove and inspect pilot pump. See Group 3360.
Function Does Not Stop When Control Lever Released	Control valve spool stuck	Manually move spool to check for sticking. See Group 3360.
	Pilot controller	Check for sticking spool. See Group 3360.
Some Functions Cannot Be Operated, All Others Are Normal	Pilot cap	Inspect for leakage at pilot cap. See Group 3360.
	Pilot controller or hoses to function that cannot be operated	Check pilot controller hoses or pilot controller. See Group 3360.
	Flow regulator valve	Check for stuck spools or check valves. See Group 3360.
	Control valve spool stuck.	Manually move spool to check for sticking. See Group 3360.
All Functions Slow	Pilot filter plugged	Replace pilot filter.
	Low pilot system pressure	Check pilot pressure regulating valve pressure setting. See Group 9025-25.
	Restriction in pilot shut-off valve	Check pilot shut-off lever position. See Group 9025-20.

9025
15
15

Diagnostic Information

Symptom	Problem	Solution
Function Moves In Opposite Direction	Pilot control hoses connected backwards	Check installation of pilot control hoses. See Group 9025-15.

TX,15,GG2163 -19-13AUG98-2/2

9025
15
16

Diagnostic Information

DIAGNOSE DIG CIRCUIT MALFUNCTIONS

NOTE: Diagnose malfunction charts are arranged from most probable and simplest to verify, to least likely and most difficult to verify.

Symptom	Problem	Solution
All Dig Functions Slow or No Power	Hydraulic system malfunction	See Diagnose Hydraulic System Malfunctions. See Group 9025-15.
	Pilot circuit malfunction	See Diagnose Pilot Circuit Malfunctions. See Group 9025-15.
	Front or rear pump regulator	Do Hydraulic Pump Regulator Adjustments. See Group 9025-25.
	System relief valve	Test system relief valve. See Group 9025-25.
	Front or rear pump control valve	Check pressure. See Group 9025-25. Inspect. See Group 3360.
	Hydraulic pumps	Check pumps using cycle time. Do Hydraulic Pump Flow Test. See Group 9025-25.
Some Dig Functions Slow (Not All)	Pilot circuit malfunction	See Diagnose Pilot Circuit Malfunctions. See Group 9025-15.
	Control valve leakage	Check dig functions for drift. See Group 9025-25.
	Cylinder leakage	Test cylinder for leakage. See Group 9025-25.
	Circuit relief valve	Test circuit relief valves. See Group 9025-25.
	Valve spool sticking	Manually move spool to check for sticking. See Group 3360.
	Front and rear pump control valves	Check pressure. See Group 9025-25. Inspect. See Group 3360.

9025
15
17

Diagnostic Information

Symptom	Problem	Solution
Load Drifts Down When Control Valve Is In Neutral Position	Cylinder leakage	Test cylinder for leakage. See Group 9025-25.
	Circuit relief valve	Test circuit relief valves. See Group 9025-25.
	Reduced leakage valve for boom down and arm in	Inspect reduced leakage valve. See Group 3360
	Boom manual lower screw loose	Tighten screw to specification. See Group 9025-25
	Control valve leakage	Inspect control valve. See Group 3360.
Load Falls When Control Valve Is Actuated To Raise Load With Engine Running At Slow Idle	Lift check valve leakage	Inspect lift check valve in control valve. See Group 3360.
Function Moves in Opposite Direction	Pilot control hoses connected backwards	Check installation of pilot control hoses. See Group 9025-15.

9025
15
18

Diagnostic Information

DIAGNOSE SWING CIRCUIT MALFUNCTIONS

NOTE: Diagnose malfunction charts are arranged from most probable and simplest to verify, to least likely and most difficult to verify.

Symptom	Problem	Solution
Swing Speed Slow In Both Directions	Low pilot system pressure	All other functions are slow. See Diagnose Pilot Circuit Malfunctions. See Group 9025-15.
	Crossover relief valve	Test crossover relief valve pressure. See Group 9025-25.
	Swing valve leakage	Inspect swing valve. See Group 3360.
	Swing motor leakage	Test swing motor for leakage. See Group 9025-25.
	Swing park brake	Check pilot pressure to swing brake release valve. See Group 9025-25.
	Worn rear pump	Check left track cycle time. It will be slow if rear pump is worn. See Group 9025-25.
Swing Speed Slow or Does Not Operate In One Direction	Pilot circuit malfunction	See Diagnose Pilot Circuit Malfunctions. See Group 9025-15.
	Swing make-up valve leakage	Inspect make-up valves. See Group 3360.
	Swing crossover relief valve malfunction	Test swing crossover relief valves. See Group 9025-25.
Upperstructure Drift With Swing Valve In Neutral	Swing park brake	Inspect swing park brake. See Group 3360.
	Swing crossover relief valve leakage	Test swing crossover relief valves. See Group 9025-25.
	Swing make-up check valve leakage	Inspect make-up valves. See Group 3360.

9025
15
19

Diagnostic Information

Symptom	Problem	Solution
Swing Function Does Not Operate	Swing motor leakage	Test swing motor for leakage. See Group 9025-25.
	Pilot circuit malfunction	See Diagnose Pilot Circuit Malfunctions. See Group 9025-15.
	Swing brake release valve malfunction	Inspect swing brake release valve. See Group 3360.
	Swing valve spool stuck	Manually move spool to check for sticking. See Group 3360.
	Mechanical failure of swing motor or gearbox	Disassemble components to determine cause of failure. See Groups 4350 and 4360.

TX,15,GG2165 -19-13AUG98-2/2

9025
15
20

Diagnostic Information

DIAGNOSE PROPEL SYSTEM MALFUNCTIONS

Symptom	Problem	Solution
Propel Park Brakes Do Not Apply	Pressure reducing valve stuck, oil not released from piston cavity	Remove valve and clean or replace. See Group 0260.
	Propel park brake	Remove and repair brake. See Group 0260.
Track Will Not Move In One Direction	Pilot Circuit malfunction	See Diagnose Pilot Circuit Malfunctions. See Group 9025-15.
	Propel crossover relief valve	Do Crossover Relief Valve Test and Adjustment. See Group 9020-25.
	Propel control valve spool stuck	Manually move spool to check for sticking. See Group 3360.
	Counterbalance valve spool stuck	Inspect counterbalance valve. See Group 0260.
	Shuttle valve in brake valve assembly not seating	Inspect shuttle valve. See Group 0260.
	Rotary manifold leakage	Inspect rotary manifold. See Group 0260.
Track Will Not Move In Either Direction	Pilot Circuit Malfunction	See Diagnose Pilot Circuit Malfunctions. See Group 9025-15.
	Crossover relief valve	Do Crossover Relief Valve Test and Adjustment. See Group 9025-25.
	Propel pilot controller	Inspect propel pilot controller. See Group 3360.
	Propel valve spool	Manually move spool to check for sticking. See Group 3360.
	Counterbalance valve spools stuck	Inspect counterbalance valve. See Group 0260.
	Mechanical failure of propel motor or gearbox	Disassemble components to determine cause of failure. See Groups 0250 and 0260.

9025
15
21

Diagnostic Information

Symptom	Problem	Solution
Excavator Mistracks at All Speeds In Both Directions	Rotary manifold leakage	Inspect rotary manifold. See Group 0260.
	Track sag adjustment	Adjust track sag. See Group 9020-20.
	Propel pilot controller malfunction	Inspect propel pilot controller. See Group 3360.
	Propel motor crossover relief valve malfunction	Do Crossover Relief Valve Test and Adjustment. See 9020-25.
	Brake valve shuttle valve or servo piston shuttle valve seat leakage.	Inspect check valve and seat. See Group 0260.
	Leakage in motor	Check tracking while descending a hill. If tracking is within specification when descending a hill, but not when on the level or going up hill, motor leakage is indicated. Do Propel Motor Leakage Test. See Group 9020-25.
	Rotary manifold leakage	Inspect rotary manifold. See Group 0260.
Slow Propel Speed or Low Power	Front and rear pump regulators	Do pump regulators adjustment. See Group 9025-25.
	Track sag adjustment	Adjust track sag. See Adjust Track Sag in Group 9020-20.
	Propel motor crossover relief valve	Do Crossover Relief Valve Test and Adjustment. See Group 9020-25.
	Propel brake not releasing	Inspect propel brake. See Group 0260.
	Propel motor	Do Propel Motor Operating Leakage Test. See Group 9020-25.
	Rotary manifold leakage	Inspect rotary manifold. See Group 0260.

Continued on next page

TX,15,GG2235 -19-13AUG98-2/3

Diagnostic Information

Symptom	Problem	Solution
	Low pump flow	Check propel cycle times. Do Hydraulic Pump Flow Test. See Group 9025-25.
	Engine performance low	Test engine performance. See Group 9010-25.
Combined Propel and Dig Functions Slow or No Power	Flow combiner valve	Check for sticking or stuck valve spool. See Group 3360.
	Propel-boom down selector valve	Check for sticking or stuck valve spool. See Group 3360.
Propel Is “Jerky”	Track sag too tight or too loose	Adjust track sag. See Adjust Track Sag in Group 9020-20.
	No oil or low oil level in rollers	Fill with correct oil. See General Information Section.
	Brake valve shuttle valve or servo piston shuttle valve seat leakage.	Inspect shuttle valve seat. See Group 0260.
	Propel park brake leakage	Inspect propel park brake piston. See Group 0260.
	Mechanical failure in propel motor or gearbox	Inspect motor and gearbox. See Groups 0250 and 0260.
	Deformed track frame	See Undercarriage Appraisal Manual SP326. Repair or replace components.
	Excavator Will Not Hold Back and Park Brakes Engage and Disengage When Traveling Down an Incline	Counterbalance valve spool stuck
Excavator Will Not Turn Smoothly In One Direction or Park Brake Grabs	Counterbalance valve spool stuck	Inspect counterbalance valve spool. See Group 0260.

9025
15
23

Diagnostic Information

CONTROL LEVER PATTERN CONVERSION

To change your machine pilot control levers from the standard pattern to a John Deere pattern:

1. Lower bucket to the ground.
2. Turn key switch to OFF to stop engine.

CAUTION: High pressure release of oil from pressurized system can cause serious burns or penetrating injury. The hydraulic oil tank is pressurized. Loosen vent plug to release air pressure.

3. Loosen vent plug (K) to release air pressure from hydraulic oil tank.
4. Open door on storage compartment behind cab.
5. Remove cover above flow regulator valve.

NOTE: Do not use manufacturer's identification tags or markings on line ends to identify lines for this conversion procedure. The conversion must be done on the front (cab side) of flow regulator valve.

6. Switch hoses in an X pattern.


Switch hose (A) with hose (C).

Switch hose (B) with hose (D).


CAUTION: Prevent injury from unexpected control lever function. Install new decals on control consoles.

7. Install new black on yellow decals for John Deere pattern on control consoles near the base of control levers. The decals are enclosed in Operator's Manual package. Additional decals are available through parts.

When changing back to the standard pattern, install new black on white decals.



T109340 -UN-29APR97




T102684

- A—Hose
- B—Hose
- C—Hose
- D—Hose
- K—Vent Plug

T102684 -UN-07AUG96

9025
15
24

CONTROL VALVE LINE IDENTIFICATION—LEFT FRONT



9025
15
26

T109233

Left Front

T109233 -UN-07MAY97

Continued on next page

TX,9025,GG2628 -19-20MAY98-1/2


Diagnostic Information

- | | | | |
|---|--|--|---|
| 1—Left Control Valve (5-Spool) | 10—Return to Hydraulic Tank | 18—Arm In Pilot From Left Pilot Controller—SAE Pattern | 27—To Swing Motor Rear Port—Right Swing |
| 2—Right Control Valve (4-Spool) | 11—Return From Pilot Shut-Off Valve | 19—Boom Down Pilot From Right Pilot Controller—SAE Pattern | 28—To Arm Cylinder Rod End—Arm Out |
| 3—To Rear Pump Control Valve Pressure Sensor and Rear Pump Regulator | 12—Pilot Pressure To Swing Motor Park Brake Release Valve Top Port | 20—Bucket Load Pilot From Right Pilot Controller | 29—To Arm Cylinder Head End—Arm In |
| 4—Pilot Pressure Signal To Propel Flow Control Valve | 13—Return From Bucket Flow Control Valve To Solenoid Valve Manifold | 21—Right Propel Reverse Pilot From Propel Pilot Controller | 30—Left Propel Forward To Rotary Manifold Left Front Port |
| 5—To Rear Pump Control Valve | 14—Return From Propel Flow Control Valve To Solenoid Valve Manifold | 22—Swing Right Pilot From Left Pilot Controller | 31—Left Propel Reverse To Rotary Manifold Left Rear Port |
| 6—Inlet Flow From Front Pump | 15—Pilot Pressure From Pilot Shut-Off Valve to Solenoid Valve Manifold | 23—Left Propel Reverse Pilot From Propel Pilot Controller | |
| 7—Pilot Pressure Signal To Swing Motor Park Brake Release Valve—Bottom Port | 16—Pilot Pressure to Front Pump Control Valve | 24—To Swing Motor Make-Up Oil Port | |
| 8—Pilot Pressure From Pilot Pressure Regulating Valve | 17—Arm In Pilot To Bucket Flow Control Valve—Front Bottom Port | 25—To Hydraulic Oil Cooler | |
| 9—Power Boost Solenoid Valve to System Relief Valve | | 26—To Swing Motor Front Port—Left Swing | |

9025
15
27

Diagnostic Information

CONTROL VALVE LINE IDENTIFICATION—RIGHT REAR



9025
15
28

T109234

Right Rear

T109234 -UN-25APR97

Continued on next page

TX,9025,GG2629 -19-08JUN98-1/2


Diagnostic Information

- | | | | |
|---|--|---|---|
| 1—Left Control Valve (5-Spool) | 16—Pilot Pressure to Front Pump Control Valve | 32—To Propel Motor Speed Change Valve | 41—To Boom Cylinder Rod End—Boom Down |
| 2—Right Control Valve (4-Spool) | 17—Arm In Pilot To Bucket Flow Control Valve—Front Bottom Port | 33—Speed Sensing Solenoid Valve To Front and Rear Pump Regulator Speed Sensing Port | 42—Pilot Pressure From Boom Up Pilot Cap To Bucket Flow Control Valve |
| 5—To Rear Pump Control Valve | 18—Arm In Pilot From Left Pilot Controller—SAE Pattern | 34—Arm Regenerative Solenoid Valve To Arm Regenerative Valve | 43—Return To Hydraulic Oil Tank |
| 7—To Swing Motor Park Brake Release Valve—Bottom Port | 19—Boom Down Pilot From Right Pilot Controller—SAE Pattern | 35—Supply Oil From Front Pump | 44—Supply Oil From Rear Pump |
| 9—Power Boost Solenoid Valve to System Relief Valve | 20—Bucket Curl Pilot From Right Pilot Controller | 36—Right Propel Forward To Rotary Manifold Right Front Port | 45—To Front Pump Control Valve Pressure Sensor and Front Pump Regulator |
| 10—Return to Hydraulic Tank | 21—Right Propel Reverse Pilot From Propel Pilot Controller | 37—Right Propel Reverse To Rotary Manifold Right Rear Port | 46—Return From Front Pump Control Valve and Warm-Up Circuit To Hydraulic Oil Tank |
| 11—Return From Pilot Shut-Off Valve | 22—Swing Right Pilot From Left Pilot Controller | 38—To Bucket Cylinder Rod End—Bucket Dump | |
| 12—Pilot Pressure Signal To Swing Motor Park Brake Release Valve—Top Port | 23—Left Propel Reverse Pilot From Propel Pilot Controller | 39—To Bucket Cylinder Head End—Bucket Curl | |
| 13—Return From Bucket Flow Control Valve To Solenoid Valve Manifold | 24—To Swing Motor Make-Up Oil Port | 40—To Boom Cylinder Head End—Boom Up | |
| 14—Return From Propel Flow Control Valve To Solenoid Valve Manifold | 25—To Hydraulic Oil Cooler | | |

9025
15
29

Diagnostic Information

CONTROL VALVE LINE IDENTIFICATION—BOTTOM



T109235

Bottom


- | | | | |
|--|--|---|--|
| <p>13—Return From Bucket Flow Control Valve To Solenoid Valve Manifold</p> <p>17—Arm In Pilot To Bucket Flow Control Valve—Front Bottom Port</p> <p>37—Right Propel Reverse To Rotary Manifold Right Rear Port</p> <p>39—To Bucket Cylinder Head End—Bucket Curl</p> | <p>41—To Boom Cylinder Rod End—Boom Down</p> <p>42—Bucket Flow Control Valve Front Top Port To Right Side Boom Up Pilot Cap</p> <p>47—Arm II To Arm I Pilot—Arm Out</p> <p>48—Arm Out Pilot From Left Pilot Controller—SAE Pattern</p> <p>49—Swing Left Pilot From Left Pilot Controller</p> | <p>50—Bucket Dump Pilot From Right Pilot Controller</p> <p>51—Boom Up Pilot From Right Pilot Controller—SAE Pattern</p> <p>52—Boom II To Boom I Pilot—Boom Up</p> <p>53—Right Propel Forward Pilot From Propel Pilot Controller</p> | <p>54—Left Propel Forward Pilot From Propel Pilot Controller</p> <p>55—To Hydraulic Oil Tank—Return From Rear Pump Control Valve</p> |
|--|--|---|--|

T109235 -UN-08MAY97

TX,9025,GG2630 -19-21APR97-1/1

Diagnostic Information

CONTROL VALVE COMPONENT IDENTIFICATION—LEFT FRONT



Left Front

T109048

T109048 -UN-15APR97

Continued on next page

TX,9025,GG2625 -19-20MAY98-1/2

9025
15
32


Diagnostic Information

- | | | | |
|---|---|--|---|
| 1—Left Control Valve
(5-Spool) | 64—Arm II Valve | 75—Arm Out Circuit Relief
and Anti-Cavitation
Valve | 81—Propel Flow Control
Valve |
| 2—Right Control Valve
(4-Spool) | 65—Boom I Valve and
Boom Regenerative
Valve | 76—Plug | 82—Propel Power and
Neutral Passage
Check Valves (Lift
Checks) |
| 56—System Relief Valve
Isolation Check Valve | 66—Boom Reduced
Leakage Valve | 77—Swing Lift Check Valve | 83—Rear Pump Control
Valve |
| 57—System Relief Valve
and Power Boost | 67—Bucket Valve | 78—Arm I Power and
Neutral Passage
Check Valves (Lift
Checks), and
Restriction Orifice | 84—Filter and Orifice for
Pilot Pressure to Rear
Pump Control Valve |
| 58—Dig Pressure Switch | 68—Right Propel Valve | 79—Boom II Power
Passage Check Valve
(Lift Check) | 84A—Check Valve and
Orifice for Propel
Flow Control Valve |
| 59—Flow Combiner Valve
Circuit Check Valve | 69—Left Propel Valve | 80—Auxiliary Power
Passage Check Valve
(Lift Check) | |
| 60—System Relief Valve
Isolation Check Valve | 70—Auxiliary Valve | | |
| 61—Propel Pressure
Switch | 71—Boom II Valve | | |
| 62—Pilot Pressure Inlet
Filter | 71A—Propel-Boom Down
Selector Valve | | |
| 63—Solenoid Valve
Manifold | 72—Arm I Valve | | |
| | 73—Swing Valve | | |
| | 74—Arm Reduced Leakage
Valve | | |

TX,9025,GG2625 -19-20MAY98-2/2

9025
15
33

CONTROL VALVE COMPONENT IDENTIFICATION—RIGHT REAR



9025
15
34

T120888

Right Rear

Continued on next page

TX,9025.GG2626 -19-21APR97-1/2

T120888 -JUN-27MAY99

Diagnostic Information


- | | | | |
|---|---|---|---|
| 1—Left Control Valve
(5-Spool) | 69—Left Propel Valve | 90—Propel Speed Change
Solenoid Valve | 97—Arm II Power and
Neutral Passage
Check Valves and
Restriction Orifice |
| 2—Right Control Valve
(4-Spool) | 70—Auxiliary Valve | 91—Speed Sensing
Solenoid Valve | 98—Front Pump Control
Valve |
| 57—System Relief Valve
and Power Boost | 71—Boom II Valve | 92—Arm Regenerative
Solenoid Valve | 99—Filter and Orifice for
Pilot Pressure to Front
Pump Control Valve |
| 63—Solenoid Valve
Manifold | 72—Arm I Valve | 93—Flow Combiner Valve | 105—Oil Cooler Bypass
Valve |
| 64—Arm II Valve | 73—Swing Valve | 94—Bucket Flow Control
Valve | |
| 65—Boom I Valve and
Boom Regenerative
Valve | 85—Arm Regenerative
Valve | 95—Bucket Check Valve
(Lift Check) | |
| 66—Boom Reduced
Leakage Valve | 86—Arm II to Arm I Neutral
Passage Check Valve | 96—Boom I Power and
Neutral Passage
Check Valves (Lift
Checks) | |
| 67—Bucket Valve | 87—Boom Up Circuit Relief
Valve | | |
| 68—Right Propel Valve | 88—Bucket Dump Circuit
Relief Valve | | |
| | 89—Power Boost Solenoid
Valve | | |

TX,9025,GG2626 -19-21APR97-2/2

9025
15
35

Diagnostic Information

CONTROL VALVE COMPONENT IDENTIFICATION—BOTTOM



Bottom

- | | | | |
|--|---|---|--|
| <p>1—Left Control Valve (5-Spool)
 2—Right Control Valve (4-Spool)
 64—Arm II Valve
 65—Boom I Valve
 67—Bucket Valve
 68—Right Propel Valve
 69—Left Propel Valve</p> | <p>70—Auxiliary Valve
 71—Boom II Valve
 72—Arm I Valve
 73—Swing Valve
 94—Bucket Flow Control Valve
 100—Arm Regenerative Circuit Check Valve</p> | <p>101—Boom Down Circuit Relief and Anti-Cavitation Valve
 102—Bucket Load Circuit Relief and Anti-Cavitation Valve
 103—Plug</p> | <p>104—Arm In Circuit Relief and Anti-Cavitation Valve</p> |
|--|---|---|--|

9025
15
36

T109053


T109053 -UN-15APR97

TX,9025,GG2627 -19-20MAY98-1/1

FOLDOUT PAGES 6-124 THRU 6-129 ARE AT REAR OF MANUAL

BLANK

PILOT SHUT-OFF VALVE LINKAGE ADJUSTMENT



T7660AL

A—Pilot Shut-Off Lever
B—Rod

C—Pilot Shut-Off Valve
D—Lever

E—Cap Screw

SPECIFICATIONS	
Pilot Shut-Off Valve Lever-to-Cap Screw Head Clearance	1.5 ± 0.5 mm (0.06 ± 0.02 in.)

1. Stop engine.
2. Remove cover underneath operator's station.
3. Push pilot shut-off lever (A) forward to the ON position. Check that lever is against the front stop.
4. Adjust ball joints on rod (B) to get the specified clearance between valve lever (D) and head of cap screw (E).

Pilot Shut-Off Valve Lever-to-Cap Screw Head—Specification

Clearance..... 1.5 ± 0.5 mm (0.06 ± 0.02 in.)

5. Pull pilot shut-off lever to the OFF position. Check that lever is against the rear stop.

CAUTION: Machine may move if adjustment is incorrect. Before checking pilot shut-off lever adjustment, make sure the area around machine is clear.

6. Start the engine. Run engine at slow idle. Actuate the hydraulic functions. Hydraulic functions must not move with the pilot shut-off lever in the OFF position. If hydraulic function move, repeat adjustment procedure.

T7660AL -19-06DEC91


9025
20
1

LAPTOP COMPUTER GENERAL DESCRIPTION

The JT07274G Excavator Diagnostics Program Disk is designed to run on a laptop computer, such as JT07294 Computer Kit, with the following minimal hardware requirements:

- 486 Processor
- 16 megs of RAM
- WINDOWS® 95 or
- WINDOWS NT™
- Standard RS232 Serial Port

The laptop computer is connected to the John Deere excavator by the JT07273 Cable with a standard RS232 connector fitted with a filter to accommodate the voltage levels of the engine and pump controller.



T102900 -19-29AUG96

T102900

*WINDOWS is a trademark of MICROSOFT CORPORATION.
NT is a trademark of MICROSOFT CORPORATION.*

CED, TX08227, 2893 -19-22APR98-1/1

9025
25
1

EXCAVATOR DIAGNOSTICS PROGRAM—OVERVIEW


The JT07274G Excavator Diagnostics Program Disk is to be used to monitor information available from the Engine and Pump Controller (EPC) on the John Deere excavator.

In general, the functions provided for John Deere excavators include:

- Identification of Excavator.
- Displaying of Diagnostic Service Codes and Corrective Actions.
- Monitoring Data.
- Adjustment of Parameters.
- On-Line Help.

CED, TX08227, 2894 -19-22APR98-1/1

EXCAVATOR DIAGNOSTICS PROGRAM—INSTALL



9025
25
2

T102901

Continued on next page

TX.9025.CR94 -19-22APR98-1/5

T102901 -19-04SEP96

Tests

The complete excavator diagnostics program is contained on a single floppy disk. The program requires approximately twelve megabytes upon installation. Installation of the program or software updates is best accomplished using the following procedure:

*NOTE: The latest version of the excavator diagnostics program now contains a list of supported excavator models in the About John Deere window. To check the list of excavator models supported, click on the **About** button on the Toolbar or the **Help** drop down menu on the Menu Bar and then click on **About John Deere**.*

1. Insert floppy disk in floppy disk drive.
2. Connect floppy disk drive to the computer. As needed, connect an external power source to floppy disk drive.

NOTE: If floppy disk drive is not connected when the computer is first "booted" (turned on) the

*floppy disk drive (e:) may not be recognized. To "reboot", push **Ctrl** and **Alt** and **Delete** at the same time or push and hold both left and right mouse buttons down for 10 seconds*

3. Turn the computer on. This is done on the recommended computer by pushing function **Fn** and **ON** at the same time.
4. Adjust brightness of screen. Push **Fn** and **F4** or **F5** on computer.
5. Using the mouse, push the **Start** button at the lower left corner of screen.

NOTE: The mouse is a short post located below the space bar. Push the post in direction you want the cursor to move. Click the buttons on the left of the mouse when cursor is in desired location. The tip of the cursor must be on the menu button for menu to open.

Continued on next page


TX,9025,CR94 -19-22APR98-2/5

9025
25
3

Tests

6. From the **Start** menu, click on **Run**.

*NOTE: To use the Windows 95 Add/Remove Programs feature, click on **Settings** in the **Start** menu, then **Control Panel, Add/Rem... Programs**, and then follow the instruction in each window as they are displayed.*



T102902


T102902 -19-29AUG96

Continued on next page

TX,9025,CR94 -19-22APR98-3/5

9025
25
4

Tests



7. Type **e:** and then a \ (backslash) in the **Run** dialog window. Then type **setup** (or use the Browse button to find and select “setup” from the floppy disk and then select **Open**). See illustration for an example.

*NOTE: Some computers use **a:** as the floppy disk drive. Repeat previous step with **a:** instead of **e:** if computer doesn't recognize the floppy disk drive.*

8. Once the dialog window contains the correct drive and file name, click on the **OK** button.

NOTE: Your computer will remember which drive a disk is loaded on the last time it was done. Therefore pushing the enter key may be all that is required after a disk has been loaded the first time.

9. Setup prompts you with a welcome dialog window that describes the program and lets you continue or exit

Click **NEXT**

9025
25
5

Continued on next page

TX,9025,CR94 -19-22APR98-4/5

Tests

- Click **Next** to select default location for software placement or click **Browse** to select desired location.

Congratulations! The program is now installed.



T102904


T102904 -19-29AUG96

TX,9025,CR94 -19-22APR98-5/5

9025
25
6

Tests

EXCAVATOR DIAGNOSTICS PROGRAM—UNINSTALL



An Uninstall feature has been created for your convenience to efficiently remove the program from your computer. Click on **Start, Programs, John Deere App Group**, and then **Uninstall Shield** which is below the Excavator Diagnostics menu. Follow on-screen instructions.

NOTE: If John Deere App Group window is open, just click on Uninstall Shield.

TX,9025,CR100 -19-22APR98-1/1

EXCAVATOR DIAGNOSTICS PROGRAM—STARTING

The John Deere Excavator Diagnostics Software program is started using the **Excavator Diagnostics** icon on the desktop. Also, can be started from the **John Deere App Group** in the **Programs** menu. The **Excavator Diagnostics** icon is automatically put on the desktop when the program is loaded.



T102905

Continued on next page

TX,9025,GG2670 -19-22APR98-1/5

T107199 -19-11FEB97

9025
25
7

T102905 -19-06SEP96

Tests



T109483

NOTE: To install the **Excavator Diagnostics** icon if not on the desktop, use the following procedure:

1. Click on **Start** using the right mouse button.
2. Click **Open** using the left mouse button.
3. Double click on **Programs** in Start Menu window using the left mouse button.
4. Double click on **John Deere App Group** icon using the left mouse button.
5. Put the mouse pointer on the **Excavator Diagnostics** icon.
6. Click and hold the right mouse button down

and then drag the icon to an empty area on the desktop using the mouse. Release the mouse button when icon is on the desktop.

7. Click on **Create Shortcut(s) Here** using the left mouse button.
 8. Using the left mouse button, click on the X in the upper right corner of each open window to close it.
1. Double click on **Excavator Diagnostics** icon to start program from the desktop (also can click once on the icon and then press the Enter key).

Tests


For starting from the Programs menu:

- a. Click on **Start** button in lower left corner of screen.
- b. Click on **Programs** in Start menu.
- c. Click on **John Deere App Group** in the Programs menu.

d. Click on **Excavator Diagnostics**.

- 2. The John Deere Main Menu screen opens. The menu screen is the gateway to the excavator diagnostic program.

TX,9025,GG2670 -19-22APR98-3/5



T109495

T109495 -19-14MAY97
9025
25
9

- 3. The first time the excavator diagnostics program is used on the laptop computer, a communication port must be selected.

- a. Click on the **Setup** button on the Toolbar or on the **Connection** drop down menu on the Menu Bar and then click on **Setup**.

*NOTE: If the Toolbar is not displayed, click on the **View** drop menu and then click on **Toolbar**. Also click on **Status Bar** if not displayed at bottom of window.*


- b. When the **Communication Setup** window opens, click on the communication port your computer needs for communication with the excavator. Most computers use Comm 1.

- c. Using the left mouse button, click on the X in the upper right corner of **Communication Setup** window to close it.

Continued on next page

TX,9025,GG2670 -19-22APR98-4/5

Tests



T109499 -19-14MAY97

T109499

4. Click on the **Connect** button on the Toolbar or on the **Connection** drop down menu on the Menu Bar and then click on **Connect**.

*NOTE: If the Toolbar is not displayed, click on the **View** drop menu and then click on **Toolbar**. Also click on **Status Bar** if not displayed at bottom of window.*


5. The John Deere Model window opens displaying the Model number. Confirm the model number and then click on **OK** or press Enter to continue.
6. When the connection is made, the Toolbar button for **Connect** becomes gray and the **Disconnect**, **Codes**, and **Monitor** buttons become black.

The current mode for the software is listed in the middle of the Status Bar and the model number to the right. The modes are Main Mode and Service Mode.

The **Disconnect** button on the Toolbar will disconnect the communication with the excavator being diagnosed, no further communication can be performed by the software.

TX,9025,GG2670 -19-22APR98-5/5

EXCAVATOR DIAGNOSTICS PROGRAM FEATURE—SERVICE CODES



1. Click on the **Codes** button on Toolbar or on the **Features** drop down menu on the Menu Bar and then click on **Service Codes**. (See Excavator Diagnostics Program List of Service Codes in this group.)

The first group of service codes shown is the **Service Codes-History**. If there are any codes found, the option to clear the Service Codes-History

is selectable and not grayed out. Service Codes-History are requested only once from the engine and pump controller.

2. After Service Codes-History have been cleared, the **Service Codes-Current** are displayed and updated periodically—at least 4 samples per minute. Click on a specific service code to get Corrective Action window to display diagnostic advice.

T111267 -19-02SEP97

9025
25
11

Tests

3. If communication is interrupted, such as the key switch being turned off by mistake during service code reading, the **Communication Interruption!** window will display. Click **OK** or press Enter to disconnect. Then turn the key switch back on and click on the **Connect** button or on the **Connection** drop down menu on the Menu Bar and then click on **Connect** to continue.

T102910




T102910 -19-29AUG96

TX,9025,GG2672 -19-22APR98-2/2

Tests

EXCAVATOR DIAGNOSTICS PROGRAM FEATURE—MONITOR DATA



1. Click on the **Monitor** button on Toolbar or on the **Features** drop down menu on the Menu Bar and then click on **Monitor Data** to open the **Data Item Selection** window. (See Excavator Diagnostic Software Monitor Data Items in this group.)
2. Double click (or click once and press the Enter key) on a data item and its ID number appears in the Data Item Selected box at the Graph Position that is highlighted on the left of the screen. The up and

down cursor keys and the Enter key also works for selecting data items.

After your first choice has been made, the next Graph Position is highlighted and allows you to make your second choice. You may choose a data item for each of the four Graph Positions.

3. After choices have been made, click **OK** to view data in graph form in the **Monitor Data** window.


T111272 -19-02SEP97

9025
25
13

Continued on next page

TX,9025,GG2673 -19-22APR98-1/3

Tests



T102911

Position 4 is undefined.

T102911 -19-29AUG96


- To change a data item in the **Monitor Data** window, click **Select Items** to toggle back to **Data Item Selection** window.

Then highlight the Graph Position by clicking on it or use the tab key and then select a data item as before.

- The data items are polled at about 4 samples per second. You can "freeze" the data by clicking on **Freeze** button. When you click **Unfreeze**, data reading will resume. When highlighted, you can also press the Enter key to toggle between **Freeze** and **Unfreeze**. To highlight a button, press the tab key to highlight the button desired.

TX,9025,GG2673 -19-22APR98-2/3

- If communication is interrupted, such as the key switch being turned off by mistake while reading data, the **Communication Interruption!** window will display. Turn the key switch back on and then click **Retry** or press Enter to continue. When communication is again established, the Monitor Data window opens to its last settings.



T103375


T103375 -19-29AUG96

TX,9025,GG2673 -19-22APR98-3/3

9025
25
14

Tests

EXCAVATOR DIAGNOSTICS PROGRAM FEATURE—SAVING MONITOR DATA



T109321

9025
25
15

T109321 -19-28APR97

1. You can save a copy of “frozen” data to a disk following these steps:
 - a. Click on the application to make it the active window.
 - b. Press **Alt** and the **PrtScn** keys.
 - c. Click on **Start, Programs, Accessories,** and then **Paint.**
 - d. When **Paint** opens, paste “frozen” data by pressing **Control** and the **V** keys.
 - e. Click on **Edit** and then on **Copy To.**
 - f. Type in a File name, select a drive to Save in and then click on **Save.**
2. The saved file may be opened and printed in either a paint or page layout program.

EXCAVATOR DIAGNOSTICS PROGRAM SPECIAL FUNCTION—ENGINE SPEED ADJUSTMENT

Special Function allows you to adjust the following engine speed factory settings parameters: (For factory settings, see Excavator Diagnostics Program Special Function—Engine Speed Factory Settings Parameters in this group.)

- Slow idle (RPM)
- Economy (RPM)
- Fast idle (RPM)
- Auto idle (RPM)
- Attachment (RPM)

Attachment (RPM) is used to adjust the engine speed for an attachment connected to the machine's hydraulic system that requires a specified pump flow rate. When in Attachment Mode and the proper pressure switch and wiring harness are installed, the engine speed changes to the adjusted speed when the attachment is actuated.

See the Engine Speed to Pump Flow Rate Chart in this group for the engine speed to get the specified pump flow rate.

To change a parameter, the excavator must be in Service Mode. Follow the steps below for placing the excavator in service mode and adjusting parameters.

*NOTE: If computer is currently connected, click on the **Disconnect** button on the Toolbar or on the **Connection** drop down menu on the Menu Bar and then click on **Disconnect**.*

1. Turn the key switch off.
2. Connect the laptop computer cable to the diagnostic test port.

Continued on next page

TX,9025,GG2862 -19-22APR98-1/4

Tests


3. Push the learning switch (C) up to the top position and wait for 10 seconds.
4. Turn the key switch on.
5. Click on the **Connect** button on the Toolbar or on the **Connection** drop down menu on the Menu Bar and then click on **Connect**.

The John Deere Model window opens displaying the Model number. Confirm the model number and then click on **OK** or press Enter to continue.

6. The **Warning Service Mode** window opens warning that excavator is in Service Mode. Click **OK**.

NOTE: Service Mode and machine model number is displayed in the Status Bar at bottom of window.

In Service mode, the Service Codes and Monitor Data cannot be accessed.



T103674

C—Learning Switch


T103674 -UN-11SEP96

Continued on next page

TX.9025,GG2862 -19-22APR98-2/4

9025
25
17

Tests



T111739 -19-14OCT97

- Click on the **Adjust** button on the Toolbar or on the **Features** drop down menu on the Menu Bar and then click on **Special Function** to open the **Special Function** window.

The Special Function window allows the user to select the Adjustable Parameters for adjustment and view the values under Learning Data Display.

- Use the cursor keys to move the highlight to the parameter you wish to change then press **Enter** to bring up the Parameter Change screen.


The Parameter Change window contains:

- Parameter (to be changed)
- Adjustable Range
- Initial (deviation from factory set rpm)
- Minimum Adjusting Deviation
- Current (deviation from factory setting)
- Adjustment (were change is made)

Continued on next page

TX,9025,GG2862 -19-22APR98-3/4

Tests



T103378

T103378 -19-29AUG96

9. Use the up and down cursor keys on keyboard to change the value which appears in the Adjustment box.

NOTE: Clicking on the up and down arrows next to box will also change the value.

10. Press the Enter key or click **OK** and the **Adjustment was made as follows:** window opens. Confirm the value and then press the Enter key or click **OK** button to return to the Adjustable Parameters.

NOTE: Only one parameter can be change at a time. Repeat procedure from Adjustable Parameters to adjust additional parameters.

11. Click on **Exit** to close the **Special Function** window.

12. Click on **Disconnect** Toolbar button.

13. Turn the key switch off.

14. Push learning switch down to the center position and wait 10 seconds.

NOTE: Check the Status Bar at bottom of window that computer is in Main Mode after connecting.

15. Start the engine and then check the adjusted parameter using a tachometer

9025
25
19

Tests

**EXCAVATOR DIAGNOSTICS PROGRAM—
SERVICE CODES LIST**

LIST OF SERVICE CODES		
Service Code	Trouble	Corrective Action
01	EC sensor failure	1. Press Clear. 2. Check harness. 3. Replace the EC sensor.
02	Front pump delivery pressure sensor failure.	1. Press Clear. 2. Check harness. 3. Replace the pump delivery pressure sensor.
03	Rear pump delivery pressure sensor failure	1. Press Clear. 2. Check harness. 3. Replace the pump delivery pressure sensor.
04	Front pump control pressure sensor failure	1. Press Clear. 2. Check harness. 3. Replace the pump control pressure sensor.
05	Rear pump control pressure sensor failure	1. Press Clear. 2. Check harness. 3. Replace the pump control pressure sensor.
06	Arm Roll-in pilot pressure sensor failure	1. Press Clear. 2. Check harness. 3. Replace the arm in pilot pressure sensor.
07	Engine rpm dial failure	1. Press Clear. 2. Check harness 3. Replace the engine rpm dial.

TX,9025,GG2643 -19-22APR98-1/1

Tests

**EXCAVATOR DIAGNOSTICS PROGRAM—
MONITOR DATA ITEMS**

NOTE: This chart lists engine and pump controller dynamic data items that can be monitored by the excavator diagnostics program.

230LCR EXCAVATOR MONITOR DATA ITEMS			
Item	Display List	Units	Description
1	Front pump control pressure	psi	Pilot signal from the front pump control valve to pump regulator
2	EC angle	V	Feedback signal from the engine control sensor to the engine and pump controller
3	Front pump delivery pressure	psi	Pump supply pressure at front pump outlet.
4	Rear pump delivery pressure	psi	Pump supply pressure at rear pump outlet.
5	Arm in pilot pressure	psi	Pilot pressure from pilot controller to control valve pilot cap. Pressure measured at flow regulator valve.
6	Rear pump control pressure	psi	Pilot signal from rear pump control valve to pump regulator.
8	RPM dial angle	V	Electrical signal from engine rpm dial.
9	Arm regenerative control pressure	psi	Pilot pressure from arm regenerative solenoid valve to arm regenerative valve in left control valve. A calculated pressure, not actual pressure.
10	Propel motor control pressure	psi	Pilot pressure from propel speed change solenoid valve to speed selector valve in propel motors. A calculated pressure, not actual pressure.
11	Speed sense control pressure	psi	Pilot pressure from speed sense solenoid valve to front and rear pump regulators. A calculated pressure, not actual pressure.
12	Power boost control pressure	psi	Pilot pressure from power boost solenoid valve to the piston in the system relief valve. This is a calculated pressure, not the actual pressure.
13	Target engine speed	rpm	Set by engine rpm dial. Target speed for engine pull down when under load. (Approximately 150 rpm difference from engine speed under no load.)
14	Actual engine speed	rpm	Engine speed sensed by engine speed sensor. Sensor is located in the pump drive gearbox adjacent to front pump.
15	EC motor position	steps	Electrical signal from engine and pump controller to engine control motor.
20	Pressure switch	Boom Up, Dig, Propel	Electrical signal from pressure switches to engine and pump controller when function is actuated. Boom up is located on flow regulator valve. Dig and propel are located on control valve.
21	Selected work mode switch	Dig, Grading, Precision, Attachment	Signal from control module to engine and pump controller for selected work mode.
22	E mode switch	On, Off	Signal from control module to engine and pump controller for preset engine speed.
23	Auto-idle switch	On, Off	Signal from control module to engine and pump controller to actuate auto-idle function.
24	HP mode switch	On, Off	Signal from control module to engine and pump controller to actuate High power mode.
25	Power boost switch	On, Off	Signal from power boost switch, in right control lever, to engine and pump controller to actuate power boost function.
26	Selected propel speed switch	Fast, Slow	Signal from control module to engine and pump controller to change propel speed.
27	Key switch	On, Off	Signal from key switch to engine and pump controller.
28	Engine learning control	Done, Undone, Interruption	Engine and pump controller has to be originally matched to each machine. See engine learning procedure.
29	Attachment mode pressure switch	On, Off	Signal to engine and pump controller when attachment mode is active.

9025
25
21

**EXCAVATOR DIAGNOSTICS PROGRAM
SPECIAL FUNCTION—ENGINE SPEED
FACTORY SETTINGS PARAMETERS**

SPECIFICATIONS	
Engine Slow Idle Speed	900 ± 25 rpm
Engine Auto Idle Speed	1200 ± 25 rpm
Engine E (Economy) Mode Speed	1980 ± 25 rpm
Engine Fast Idle in Standard Mode Speed	2180 ± 25 rpm
Engine Attachment Mode Speed	(As specified by supplier)

The factory settings for engine speeds can be changed using the excavator diagnostic program special function. (See Excavator Diagnostics Program Special Function—Engine Speed Adjustment in this group.)

Engine Slow Idle—Specification

Speed 900 ± 25 rpm

Engine Auto Idle—Specification

Speed 1200 ± 25 rpm

Engine E (Economy) Mode—Specification

Speed 1980 ± 25 rpm

Engine Fast Idle in Standard Mode—Specification

Speed 2180 ± 25 rpm

Engine Attachment Mode—Specification

Speed (As specified by supplier)

NOTE: For the engine speed to get a specified pump flow rate, see Engine Speed to Pump Flow Rate Chart in this group.

9025
25
22

Tests

ENGINE SPEED TO PUMP FLOW RATE CHART

SPECIFICATIONS	
230LC Excavator Pump ^a Flow Rate to Engine Speed	132 L/min (35 gpm) at 1390 rpm and 14 479 kPa (145 bar) (2100 psi)
230LC Excavator Pump ^a Flow Rate to Engine Speed	151 L/min (40 gpm) at 1580 rpm and 14 479 kPa (145 bar) (2100 psi)
230LC Excavator Pump Flow Rate to Engine Speed	170 L/min (45 gpm) at 1790 rpm and 14 479 kPa (145 bar) (2100 psi)
230LC Excavator Pump Flow Rate to Engine Speed	189 L/min (50 gpm) at 2010 rpm and 14 479 kPa (145 bar) (2100 psi)
230LC Excavator Pump Flow Rate to Engine Speed	204 L/min (54 gpm) at 2175 rpm and 14 479 kPa (145 bar) (2100 psi)
^a For engine speeds below the adjustable range, operate in Dig Mode and turn the engine rpm dial to obtain the desired engine speed.	

The adjustable range is a (minus) -500 to 200 rpm for Attachment in Attachment Mode. The minimum adjusting deviation is 10 rpm.

230LC Excavator Pump¹—Specification

Flow Rate to Engine Speed 132 L/min (35 gpm)
at 1390 rpm and
14 479 kPa (145 bar) (2100 psi)

Flow Rate to Engine Speed 151 L/min (40 gpm)
at 1580 rpm and
14 479 kPa (145 bar) (2100 psi)

¹For engine speeds below the adjustable range, operate in Dig Mode and turn the engine rpm dial to obtain the desired engine speed.

Continued on next page

CED,OUOE003,1074 -19-13AUG98-1/2

9025
25
23

Tests

230LC Excavator Pump—Specification

Flow Rate to Engine Speed	170 L/min (45 gpm)
	at 1790 rpm and
	14 479 kPa (145 bar) (2100 psi)
Flow Rate to Engine Speed	189 L/min (50 gpm)
	at 2010 rpm and
	14 479 kPa (145 bar) (2100 psi)
Flow Rate to Engine Speed	204 L/min (54 gpm)
	at 2175 rpm and
	14 479 kPa (145 bar) (2100 psi)

For engine speeds below the adjustable range, operate in Dig Mode and turn the engine rpm dial to obtain the desired engine speed.

For adjustment procedure, see Excavator Diagnostics Program Special Function—Engine Speed Adjustment in this group.

CED,OUOE003,1074 -19-13AUG98-2/2

9025
25
24

Tests

**EXCAVATOR DIAGNOSTICS PROGRAM
TROUBLESHOOTING**

Most software problems can be solved by the following:

1. Questions:
 - Is the key switch on the excavator turned on?
 - Are the connectors push in all of the way?
 - Is the software connected? If communication is broken momentarily between the computer and the engine and pump controller?
 - Is the program in the Main Mode or Service Mode? The program will tell you the current mode in the Status Bar at the bottom of window. If it is not in one of these modes you need to click on **Connection** and **Connect**.
2. Turn key switch **Off**. Wait for 10 seconds.
3. Turn key switch **ON**.


NOTE: Disconnect and Connect does NOT mean to unplug and plug in computer cable.

4. Click on **Disconnect** and **Connect** under the **Connection** menu.
5. Try again.

9025
25
25

TX,9025,CR103 -19-22APR98-1/1

READING SERVICE CODES WITHOUT EXCAVATOR DIAGNOSTICS PROGRAM



9025
25
26

T113360

T113360 -19-13FEB98

With practice the self-diagnostic service codes can be read by counting the flashes of the Service Code Indicator Light (LED) (B) in the engine and pump controller (A).

Read the LED in the engine and pump controller several times to make sure the correct service code is read.

1. Lower the bucket to the ground. Stop the engine.
2. Remove the rear console cover from behind the operator's seat. Remove the bracket that is over the engine and pump controller.
3. Install a jumper wire (D) into the two top terminals of the diagnostic port (C).

4. Turn the key switch ON.

The LED comes ON steady for several seconds and then goes OFF.

5. For an existing service code, the LED starts a flashing sequence of 1 second ON, 1 second OFF intervals. After the last ON in a sequence, the LED remains OFF for approximately 3 seconds and then repeats the flashing sequence.

Count the number of times LED is ON in a sequence for the service code number.

Example, for a service code "03 Rear pump delivery pressure sensor failure," the LED flashes ON three times in each sequence.

Tests

For more than one, the LED will have a flashing sequence for each existing service code with an approximate 3 second interval between each sequence. The flashing sequence continues as long as the key switch in ON and jumper wire is installed.


NOTE: If no service codes exist or trouble is beyond the scope of self-diagnosing function, the LED is ON for several seconds then goes OFF and remains OFF.

With key switch ON but no jumper wire installed in the diagnostic port, the LED comes ON for several seconds, goes OFF, and then starts a steady one seconds ON, one seconds OFF flashing sequence.

6. Turn the key switch OFF.
7. Remove jumper wire from diagnostic port.
8. Make necessary repairs.
9. Use the following procedure to clear existing service codes:
 - a. Install jumper wire into the top two terminals of diagnostic port.
 - b. Turn the key switch ON.
 - c. Remove jumper wire from diagnostic port.
 - d. Wait for two second.
 - e. Install jumper wire into the top two terminals of diagnostic port.
 - f. Check for service codes. The LED is ON for several seconds then goes OFF and remains OFF if all necessary repairs were made.
 - g. Turn the key switch OFF
 - h. Remove jumper wire from diagnostic port.

9025
25
27

ENGINE AND PUMP CONTROLLER FUNCTIONS



30 ENGINE AND PUMP CONTROLLER FUNCTION

9025
25
28

Tests

The engine and pump controller (EPC) is used to control machine operation. Electronic input signals from the engine rpm dial (4), sensors (9—13), and

switches (1—3, 5—7, and 14—16) are sent to the controller.


TX,9025,GG2603 -19-21MAY98-2/2

JT05801 CLAMP-ON ELECTRONIC TACHOMETER INSTALLATION

SERVICE EQUIPMENT AND TOOLS

JT05801 Clamp-On Electronic Tachometer

1. Before installing clamp-on electronic tachometer, remove the paint from a straight section of injection line within 100 mm (4 in.) of No. 1 injection nozzle. Use emery cloth to remove the paint.
2. Install the clamp-on transducer (A). Tighten finger tight only—DO NOT overtighten.
3. Connect the red clip (+) (C) to the clamp-on transducer.
4. Connect the black clip (-) (B) to a ground connection such as the head of a cap screw or other metal part on engine.
5. Start the engine. Check for a reading on the digital readout unit (D).



- A—Clamp-On Transducer
- B—Black Clip (-)
- C—Red Clip (+)
- D—Digital Readout Unit

T6813AG -UN-28FEB89

9025
25
29

CED, TX08227, 2879 -19-11NOV97-1/1


Tests

JT05800 DIGITAL THERMOMETER INSTALLATION

SERVICE EQUIPMENT AND TOOLS

JT05800 Digital Thermometer

1. Fasten temperature probe (A) to a bare metal hydraulic line using a tie band.
2. Wrap temperature probe and line with a shop towel.



A—Temperature Probe
 B—Cable
 C—JT05800 Digital Thermometer

T6808CE -UN-28FEB89

CED,TX08227,2895 -19-19NOV97-1/1

JT02156A DIGITAL PRESSURE AND TEMPERATURE ANALYZER INSTALLATION


SERVICE EQUIPMENT AND TOOLS

JT02156A Digital Pressure and Temperature Analyzer

Use the digital pressure and temperature analyzer (A), and transducers (B) in place of analog gauges and a separate temperature reader.

Transducers are temperature sensitive. Allow transducer to warm to system temperature. After transducer is warmed and no pressure applied, push sensor zero button for one second to set the true zero point.

When using for different pressures, turn selector to OFF for two seconds and then to the pressure range. Readings are inaccurate if proper range for transducer is not used.



A—Digital Pressure and Temperature Analyzer
 B—3400 kPa (35 bar) (500 psi) Transducer
 —34 000 kPa (350 bar) (5000 psi) Transducer
 —70 000 kPa (700 bar) (10000 psi) Transducer

T8543AI -UN-25AUG95

CED,TX08227,2896 -19-19NOV97-1/1


Tests

HYDRAULIC PUMP START-UP PROCEDURE

IMPORTANT: Hydraulic pump will be damaged if not filled with oil before starting engine. Procedure must be performed whenever a new hydraulic pump is installed or oil has been drained from the pump or hydraulic oil tank.

Procedure is to ensure the pumps are filled with oil and air is bled from suction side of pumps to prevent cavitation.

1. Add oil until it is between marks on hydraulic oil tank sight glass. (See Hydraulic Oil in Group 9000-04.)
2. Remove air bleed plugs (C) from the top of pump regulators to allow housing to fill with oil from the hydraulic tank and to let air escape.
3. When pump housing is full of oil, install plugs.
4. Check oil level in hydraulic tank. Add oil as necessary. Tighten hydraulic oil tank cap. Tighten vent plug.
5. Start engine and run at slow idle. Slowly raise boom to full height and then lower to pressurize hydraulic oil tank.
6. Purge air from the hydraulic system by slowly operating each function through three cycles. Air in pilot circuits are purged automatically.



C—Air Bleed Plugs

T101875 -JUN-15JUL96

9025
25
31

Tests

SWING MOTOR START-UP PROCEDURE


IMPORTANT: Swing motor will be damaged if not filled with oil before operating swing function. Procedure must be performed whenever a new swing motor is installed or oil has been drained from the motor.

Procedure is to ensure the swing motor is filled with oil.

1. Disconnect swing motor drain line (A).
2. Fill motor with hydraulic oil through drain port until oil reaches the level of drain port. (See Hydraulic Oil in Group 9000-04.)

NOTE: Air must be allowed to escape from the swing motor while filling.

3. Connect drain line.



A—Swing Motor Drain Line

T7670AE -UN-11DEC91


TX,25,GG2227 -19-13AUG98-1/1

Tests

SWING GEARBOX START-UP PROCEDURE

IMPORTANT: Swing gearbox will be damaged if not filled with oil before operating swing function. Procedure must be performed whenever a new swing gearbox is installed or oil has been drained from the gearbox.

1. Check that drain line (A) plug is installed.
2. Remove fill cap (B). Add oil. (See Swing Gearbox, Propel Gearbox and Pump Gearbox Oils in Group 9000-04.)
3. Install fill cap. Check oil level on dipstick.



A—Swing Gearbox Drain Line
B—Fill Cap

T102305 -JUN-30JUL96

9025
25
33

TX,25,GG2228 -19-13AUG98-1/1

Tests


PROPEL MOTOR START-UP PROCEDURE

ESSENTIAL TOOLS

JT03221 (Parker No. 03CP—8) Plug

IMPORTANT: Propel motor will be damaged if not filled with oil before starting engine. Procedure must be performed whenever a new propel motor is installed or oil has been drained from the motor.

1. Disconnect motor drain line (A). Install plug.
2. Fill motor with hydraulic oil until oil reaches the top of the drain port. (See Hydraulic Oil in Group 9000-04.) Use a funnel with suitable diameter neck to allow air to escape while filling.
3. Connect drain line.



T7660BG

A—Propel Motor Drain Line

T7660BG -UN-11DEC91


TX,25,GG2229 -19-08JUN98-1/1

HYDRAULIC OIL FILTER INSPECTION PROCEDURE

1. Pour oil out of filter to inspect for water contamination.
2. Use an oil filter cutting tool to cut top off filter.
3. Remove element and inspect for metal particles and debris in bottom of filter can.

Excessive amounts of brass and steel particles can indicate a failed hydraulic pump or a pump failure in process.

A rubber type of material can indicate cylinder packing failure.



IT4633 -UN-19JAN90

TX,25,GG2231 -19-28AUG96-1/1

Tests

HYDRAULIC OIL CLEANUP PROCEDURE USING PORTABLE FILTER CADDY

SPECIFICATIONS	
Hydraulic Oil Tank Capacity	148 L (39 gal) approximate
Hydraulic Oil Tank Filtering Time	13 minutes approximate
Hydraulic System Capacity	270 L (71 gal) approximate
Hydraulic System Filtering Time	43 minutes approximate

SERVICE EQUIPMENT AND TOOLS
Portable Filter Caddy
3658 mm (12 ft) x 3/4 in. ID 100R1 Hose with 3/4 M NPT Ends (2 used)
Quick Disconnect Fittings
Suction Wand
Discharge Wand

1. Install new return filter elements.

NOTE: For a failure that creates a lot of debris, remove access cover from hydraulic tank. Drain hydraulic tank. Connect filter caddy suction line to drain port. Add a minimum of 19 L (5 gal) of oil to hydraulic oil tank. Operate filter caddy and wash out the hydraulic oil tank.

IMPORTANT: The minimum ID for a connector is 1/2 in. to prevent cavitation of filter caddy pump.

2. Put filter caddy suction and discharge wands into hydraulic oil tank filler hole so ends are as far apart as possible to obtain a thorough cleaning of oil.
3. Start the filter caddy. Check to be sure oil is flowing through the filters.

Operate filter caddy until all the oil in hydraulic oil tank has been circulated through the filter a minimum of four times.

Hydraulic Oil Tank—Specification

Capacity	148 L (39 gal) approximate
Filtering Time	13 minutes approximate

NOTE: Filtering time for hydraulic oil tank is 0.089 minute x number of liters (0.33 minutes x number of gallons).

4. Leave filter caddy operating for the next step.
5. Start the engine and run it at fast idle.

IMPORTANT: For the most effective results, cleaning procedure must start with the smallest capacity circuit then proceed to the next larger capacity circuit.

6. Starting with the smallest capacity circuit, operate each function through a complete cycle.

Repeat procedure until the total system capacity has circulated through filter caddy seven times. Each function must go through a minimum of three complete cycles for a thorough cleaning of oil.

Hydraulic System—Specification

Capacity	270 L (71 gal) approximate
Filtering Time	43 minutes approximate

NOTE: Filtering time for complete hydraulic system is 0.158 minute x number of liters (0.6 minute x number of gallons). Filtering time for machines with auxiliary hydraulic functions must be increased because system capacity is larger.

7. Stop the engine. Remove the filter caddy.
8. Install new return filter elements.
9. Check oil level in hydraulic tank, add oil if necessary. (See Hydraulic Oil in Group 9000-04.)

9025
25
35

HYDRAULIC SYSTEM WARM-UP PROCEDURE

SPECIFICATIONS	
Hydraulic System Warm-Up Oil Temperature	50 ± 5°C (120 ± 10°F)

SERVICE EQUIPMENT AND TOOLS
JT05800 Digital Thermometer

IMPORTANT: If the machine temperature is below -18 degrees C (0°F), start the engine with the speed control in the idle position. If the unit has been prepared for arctic operation with the MIL-L-46167 hydraulic oil, the suction strainer in the hydraulic tank should also have been changed to the coarser strainer for use in arctic conditions. Failure to do this could cause the hydraulic pump to cavitate which can cause pump failure. Operate engine at idle speed for at least 10 minutes before increasing the speed to half. Cover the radiator and oil cooler debris screens to restrict the air flow for faster warmup.

Below -18°C (0°F) an extended warm-up period may be necessary. Hydraulic function will move slowly and lubrication of parts may not be adequate with cold oil. Do not attempt normal machine operation until hydraulic functions move at or close to normal cycle times.

Hydraulic System Warm-Up Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

Operate functions slowly and avoid sudden movements until engine and hydraulic oils are thoroughly warmed. Operate a function by moving it a short distance in each direction. Continue operating the function increasing the distance traveled in each cycle until full stroke is reached.

For faster warm-up, restrict air flow through oil cooler using cardboard or other similar material. Use correct viscosity oil to minimize warm-up period. (See Hydraulic Oil in Group 9000-04.)

1. Connect digital thermometer. Install temperature probe on hydraulic oil tank-to-pump inlet line. (See JT05800 Digital Thermometer Installation in this group.)



CAUTION: Avoid possible serious injury from machine movement during warm-up procedure. Clear the area of all bystanders before doing the warm-up procedure.

2. Clear the area of all bystanders to allow for machine movement.
3. Start engine. Run engine at 1/2 speed for approximately 5 minutes before operating any functions. Do not run engine at fast or slow idle.
4. Check that work mode is in Dig Mode and power mode is in Standard Mode (no buttons pushed down, indicator lights off). Push auto-idle switch to turn off auto-idle function (auto-idle indicator off).
5. Slowly turn upperstructure so boom is to the side.



CAUTION: Avoid possible serious injury from machine sliding backwards. Keep angle between boom and arm at 90—110°

6. Keeping the angle between boom and arm at 90—110°, lower boom to raise one track off the ground.
7. Operate propel function for approximately 5 minute.
8. Once oil temperature is above -18°C (0°F), increase engine speed to fast idle.

9025
25
36

Tests

IMPORTANT: Holding a function over relief for more than 10 seconds can cause damage from hot spots in the control valve.

9. Operate the propel function (side with track off the ground). Also operate the bucket curl function over

relief for 10 seconds and then stop for 5 seconds. Repeat the cycle until oil is heated to specifications.

10. Stop periodically and operate all hydraulic functions to distribute the heated oil.

TX,25,GG2232 -19-13AUG98-2/2

**LOWER BOOM WITH ENGINE STOPPED
(USING BOOM CYLINDER LOAD LOWERING
VALVE)**

When an engine stops during operation, the boom cannot be lowered using the pilot controller because there is no pilot pressure oil to move the boom valve spool or to unlatch the boom load lowering valves.

Continued on next page

CED,OUOEBAS,6 -19-24JAN00-1/2


9025
25
37

Tests




CAUTION: To avoid injury from escaping fluid under pressure, never loosen boom manual lower needle valve more than 4 turns from closed position as valve may come out of housing. Tighten valve and nut before applying pressure.

Prevent possible injury from unexpected machine movement. Clear all persons from the area before lowering the boom with the engine stopped.



X9811 -UN-23AUG88

1. Check that the area is clear of all persons before lowering boom.
2. Loosen jam nut on relief valve (A). Back off relief valve set screw, counting number of turns, until boom starts to lower slowly.
3. After bucket is on ground, reset relief valve (A) by turning set screw clockwise the same number of turns noted in step 2 and lock jam nut.



T127542

A—Relief Valve
B—Boom Cylinder

T127542 -UN-19JAN00

CED.OUOEBAS,6 -19-24JAN00-2/2

9025
25
38

Tests

**LOWER BOOM WITH ENGINE STOPPED
(WHEN NOT EQUIPPED WITH BOOM
CYLINDER LOAD LOWERING VALVE)**

SPECIFICATIONS	
Boom Manual Lower Screw Torque	6.9 N•m (60 lb-in.)
Boom Manual Lower Screw-to-Housing Nut Torque	13 N•m (115 lb-in.)

SERVICE EQUIPMENT AND TOOLS
4 mm Hex Key Wrench
13 mm Combination Wrench

When an engine stops during operation, the boom cannot be lowered using the pilot controller because there is no pilot pressure oil to move the boom valve spool.

1. Remove the control valve access cover.

CAUTION: To avoid injury from escaping fluid under pressure, never loosen screw more than two turns as screw may come out. Tighten screw and nut before applying pressure.



Prevent possible injury from unexpected machine movement. Clear all persons from the area before lowering the boom with the engine stopped.

2. Loosen the small nut (B) on the boom reduced leakage valve housing (C).

Slowly loosen boom manual lower screw (A) 1/2 turn using a 4 mm hex key wrench. The boom will start to lower.

The boom lowering speed can be increased somewhat by loosening screw an additional 1-1/2 turns. Never loosen screw more than two turns.

3. After bucket is lowered to the ground, tighten the screw to specification, and then the nut.



Boom Manual Lower Screw

- A—Boom Manual Lower Screw
- B—Small Nut
- C—Boom Reduced Leakage Valve Housing

X9811 -UN-23AUG88

9025
25
39

T102664 -UN-07AUG96

Tests

Boom Manual Lower Screw—Specification

Torque 6.9 N•m (60 lb-in.)

Boom Manual Lower Screw-to-Housing Nut—Specification

Torque 13 N•m (115 lb-in.)

CED,OUOEBAS,9 -19-25JAN00-2/2

9025
25
40

ARM REGENERATIVE PROPORTIONAL SOLENOID VALVE (SC) HARNESS TEST

ESSENTIAL TOOLS

JT07062 Test Harness



The purpose of harness test is to check continuity in wiring harness to the arm regenerative solenoid valve (A) coil and there is a electrical signal from engine and pump controller.

NOTE: Pressure reading shown on the laptop computer for "9 Arm regenerative control pressure" is a calculated pressure from the electrical signal in the engine and pump controller. A typical reading is 399.3 psi while operating the boom up and arm in functions in combined operation with engine speed at 1200 rpm or less. The reading indicates that the rear pump pressure sensor, arm in pressure sensor, and boom up pressure switch are OK and a electrical signal is generated. When all functions are in neutral, a typical reading of 170.4 psi is displayed at fast or slow idle. The reading can vary from machine to machine. What to look for is that there is a reading and it increases when arm in regenerative function is actuated. (For circuit operation, see Arm Regenerative Valve Operation in Group 9025-05.)

The arm in regenerative function does not operate in Grading and Precision Work Modes.

IMPORTANT: Disconnecting electrical connectors while engine is running or with key switch on can damage engine and pump controller or other electrical components.

1. Stop engine. Turn key switch to OFF.
2. Remove wire clip. Wiggle connector half and pull apart; do not pull on wiring leads.
3. Install test harness in series with wiring harness and arm regenerative solenoid valve (A).



T103345

- A—Arm Regenerative Solenoid Valve (SC)
- B—Speed Sensing Solenoid Valve (SD)
- C—Propel Speed Change Solenoid (SI)
- D—Power Boost Solenoid Valve (SG)

T7486AL -JUN-19MAR91

T103345 -JUN-28AUG96

Tests

4. Turn key switch to ON but do not start engine.

Indicator light must come ON indicating there is continuity in the wiring harness and there is a signal from engine and pump controller.

5. Start engine.

6. Actuate boom up function and then arm in function.

Indicator light must be ON and the brightness must increase slightly.

If light goes OUT or brightness does not increase, check wiring harnesses, solenoid coil, rear pump pressure sensor, arm in pilot pressure sensor, and boom up pressure switch. (See procedure in Group 9015-15.)

TX,25,GG2220 -19-21MAY98-2/2

9025
25
41

SPEED SENSING SOLENOID VALVE (SD) HARNESS TEST

ESSENTIAL TOOLS

JT07062 Test Harness



The purpose of test is to check continuity in wiring harness to the speed sensing solenoid valve (B) coil and there is a electrical signal from engine and pump controller.

NOTE: Pressure reading shown on the laptop computer for "11 Speed sense control pressure" is a calculated pressure from the electrical signal in the engine and pump controller. When all functions are in neutral, a typical reading of 532.8 psi is displayed at slow idle and 0 psi is displayed at fast idle. Run the engine at approximately 1700 rpm so the reading is less than 100 psi. Then actuate arm in to bottom the function. The pressure reading will increase momentarily and then return to its original reading. The readings indicates that the engine speed sensor is OK and a electrical signal is generated. (For circuit operation, see Engine Speed Sensing Control Circuit Operation in Group 9025-05.)

IMPORTANT: Disconnecting electrical connectors while engine is running or with key switch on can damage engine and pump controller or other electrical components.

1. Stop engine. Turn key switch to OFF.
2. Remove wire clip. Wiggle connector half and pull apart; do not pull on wiring leads.
3. Install test harness in series with wiring harness and speed sensing solenoid valve (B).
4. Turn key switch to ON but do not start engine.

Indicator light must come ON indicating there is continuity in the wiring harness and there is a signal from engine and pump controller.



- A—Arm Regenerative Solenoid Valve (SC)
- B—Speed Sensing Solenoid Valve (SD)
- C—Propel Speed Change Solenoid (SI)
- D—Power Boost Solenoid Valve (SG)

T7486AL -JUN-19MARG91

T103345 -JUN-28AUG96

9025
25
42

Tests

5. Start engine.
6. Actuate arm in function over relief to load the engine.

Indicator light must be ON.

If indicator light goes OUT, check wiring harnesses, solenoid coil, engine rpm dial, and engine speed sensor. (See procedure in Group 9015-15.)

TX,25,GG2221 -19-01JUN98-2/2

9025
25
43

PROPEL SPEED CHANGE PROPORTIONAL SOLENOID VALVE (SI) HARNESS TEST

ESSENTIAL TOOLS

JT07062 Test Harness



The purpose of test is to check continuity in wiring harness to the propel speed change solenoid valve (C) coil and there is a signal from engine and pump controller.

NOTE: Pressure reading shown on the laptop computer for "10 Propel motor control pressure" is a calculated pressure from the electrical signal in the engine and pump controller. A typical reading of 65.9 psi is displayed when propel function is in neutral or propelling in slow speed. A typical reading of 426 psi is displayed when propelling in fast speed with no other function actuated. The readings indicates that the propel speed switch, propel and dig pressure switches, front and rear pump control pressure sensors, and front and rear pump pressure sensors are OK and a electrical signal is generated. (For circuit operation, see Propel Motor Speed Change Circuit Operation in Group 9025-05.)

IMPORTANT: Disconnecting electrical connectors while engine is running or with key switch on can damage engine and pump controller or other electrical components.

1. Stop engine. Turn key switch to OFF.
2. Remove wire clip. Wiggle connector half and pull apart; do not pull on wiring leads.
3. Install test harness in series with wiring harness and propel speed change solenoid valve (C).
4. Turn key switch to ON but do not start engine.
5. Turn propel speed switch to fast speed (rabbit).

Turn propel speed switch to slow speed propel (turtle).



T103345

- A—Arm Regenerative Solenoid Valve (SC)
- B—Speed Sensing Solenoid Valve (SD)
- C—Propel Speed Change Solenoid (SI)
- D—Power Boost Solenoid Valve (SG)

T7486AL -JUN-19MAR91

T103345 -JUN-28AUG96

Tests

Indicator light must be ON indicating there is continuity in the wiring harness and there is a signal from engine and pump controller.

6. Start engine.
7. Actuate propel function.
8. Turn propel speed switch to fast speed (rabbit).

The brightness of indicator light must increase slightly while propelling in fast speed.

If light goes OUT or brightness does not increase, check wiring harnesses, solenoid coil, propel pressure switch, pump pressure, and pump control valve pressure sensors. (See procedure in Group 9015-15.)

NOTE: No dig functions can be actuated. The dig pressure switch must be OFF so it does not send an electrical signal to engine and pump controller.

TX,25,GG2219 -19-01JUN98-2/2

9025
25
45

POWER BOOST PROPORTIONAL SOLENOID VALVE (SG) HARNESS TEST



ESSENTIAL TOOLS

JT07062 Test Harness

The purpose of test is to check continuity in the wiring harness to the power boost solenoid valve (D) coil and there is a signal from the engine and pump controller.

NOTE: Pressure reading shown on the laptop computer for "12 Power boost control pressure" is a calculated pressure from the electrical signal in the engine and pump controller. A typical reading of 426 psi is displayed when power boost switch on the right control lever is pushed. A reading of 0 psi is displayed when the switch is not pushed. The readings indicates that the power boost switch is OK and a electrical signal is generated. (For circuit operation, see Power Boost Control Circuit Operation in Group 9025-05.)

The power boost solenoid valve is also actuated in Precision Work Mode when boom up function is actuated.



T103345

- A—Arm Regenerative Solenoid Valve (SC)
- B—Speed Sensing Solenoid Valve (SD)
- C—Propel Speed Change Solenoid (SI)
- D—Power Boost Solenoid Valve (SG)

IMPORTANT: Disconnecting electrical connectors while engine is running or with key switch on can damage engine and pump controller or other electrical components.

1. Stop engine. Turn key switch to OFF.
2. Remove wire clip. Wiggle connector half and pull apart; do not pull on wiring leads.
3. Install test harness in series with wiring harness and power boost solenoid valve (D).
4. Turn key switch to ON but do not start engine.

Indicator light must come ON indicating there is continuity in the wiring harness and there is a signal from engine and pump controller.

T7486AL -JUN-19MAR91

T103345 -JUN-28AUG96

Tests

5. Push the power boost switch on the right control lever.

The brightness of indicator light must increase slightly.

If light goes OUT or brightness does not increase slightly, check wiring harnesses, solenoid coil, and power boost switch. (See procedure in Group 9015-15.)

TX,9025,GG2713 -19-01JUN98-2/2

9025
25
47

Tests

ENGINE CONTROL SENSOR (EC SENSOR) HARNESS TEST

SPECIFICATIONS	
Engine Control (EC) Sensor Resistance	2000 ± 400 ohms between ground and power terminals
Fast Idle in Standard Mode Voltage	3.3—3.7 volts typical
E (Economy) Mode Voltage	3.0—3.3 volts typical
Auto-Idle Mode Voltage	2.7—2.9 volts typical
Slow Idle Voltage	2.5—2.7 volts typical
HP (High Power) Mode With Arm In Function Over Relief Voltage	Fast idle in standard mode voltage plus 0.1 volt or more typical

ESSENTIAL TOOLS
JT07066 Test Harness


SERVICE EQUIPMENT AND TOOLS
JT07306 Analog/Digital Multimeter

The purpose of test is to check continuity in engine control sensor (EC sensor) wiring harness and there is a signal from the engine and pump controller (EPC).

NOTE: The reading displayed on the laptop computer for "2 EC angle" is the feedback signal from the engine control sensor to the engine and pump controller. See the specification chart above for typical readings for fast idle, slow idle, E mode, HP mode, and auto-idle mode. The readings can vary from machine to machine. What to look for is that the readings change when the engine rpm dial is turned, and the E mode, HP mode, or auto-idle mode is actuated. The readings indicates engine control sensor is OK. (For circuit operation, see Engine Speed Control System Operation in Group 9010-05.)


IMPORTANT: Disconnecting electrical connectors while engine is running or with key switch on can damage engine and pump controller or other electrical components.

1. Stop engine. Turn key switch to OFF.




T7482AH (CV)

T7482AH -UN-19MAR91



T7486AB -UN-19MAR91



T106991

T106991 -UN-07FEB97

- A—Ground Terminal
- B—Signal Terminal
- C—Power Terminal
- D—Engine Control Motor
- E—Engine Control Sensor Wiring Harness
- F—Engine Control Motor Wiring Harness

9025
25
48

IMPORTANT: Retainer tab on male half of wiring harness connector halves must be pushed down before pulling halves apart. Never pull on wiring leads

2. Push retainer tab down then pull connector halves apart.
3. Measure resistance between the ground (A) and power (C) terminals of EC sensor. If resistance is to specification, go to next step. If resistance is not as specified, replace EC sensor.

Engine Control (EC) Sensor—Specification

Resistance 2000 ± 400 ohms between ground and power terminals

NOTE: EC sensor is on the inside of EC motor housing.

4. When using a volt meter, install test harness in series with wiring harness for EC sensor (E). Connect volt meter.

When using the laptop computer with excavator diagnostics program, select “2 EC angle” from the Monitor Data Items. (See the installation procedure in this group.)

5. Turn the engine rpm dial to the slow idle position.
6. Turn key switch ON. EC motor (D) goes to the slow idle position.
7. Turn engine rpm dial to fast idle, push E mode switch, push auto-idle switch then wait 4 seconds, and then turn engine rpm dial to slow idle. EC motor must move to each position. Record voltage reading for each mode.

Fast Idle in Standard Mode—Specification

Voltage 3.3—3.7 volts typical

E (Economy) Mode—Specification

Voltage 3.0—3.3 volts typical

9025
25
49

Tests

Auto-Idle Mode—Specification

Voltage..... 2.7—2.9 volts typical

Slow Idle—Specification

Voltage..... 2.5—2.7 volts typical

For HP (high power) mode, run engine at fast idle, push HP mode switch, and then actuate arm in function over relief. Record voltage reading.

HP (High Power) Mode With Arm In Function Over Relief—Specification

Voltage..... Fast idle in standard mode
voltage plus 0.1 volt or more
typical

TX,9025,GG2710 -19-13AUG98-3/3

9025
25
50

ENGINE CONTROL MOTOR (EC MOTOR) HARNESS TESTS

ESSENTIAL TOOLS

JT07065 Test Harness

The purpose of test is to check continuity of EC motor wiring harness (F) and there is a signal from engine and pump controller (EPC).



NOTE: The laptop computer with excavator diagnostics program can be used to check the electrical signal from the engine and pump controller to the engine control motor. Select "15 EC motor position" from Monitor Data Items. Typical readings are 72—76 steps at slow idle to 525—550 steps at fast idle. The readings can vary from machine to machine. What to look for is that the readings change when the engine rpm dial is turned, and the E mode, HP mode, or auto-idle mode is actuated.

IMPORTANT: Disconnecting electrical connectors while engine is running or with key switch on can damage engine and pump controller or other electrical components.

1. Stop engine. Turn key switch to OFF.

IMPORTANT: Retainer tab on male half of wiring harness connector halves must be pushed down before pulling halves apart. Never pull on wiring leads.

2. Push retainer tab down then pull connector halves apart.
3. Install test harness in series with the engine control motor wiring harness (F).
4. Turn key switch to ON.
5. While observing test indicator lights,
 - a. Turn engine rpm dial from slow idle to fast idle,



T106991

D—Engine Control Motor
E—Engine Control Sensor Wiring Harness
F—Engine Control Motor Wiring Harness

T7486AD -UN-19MAR91

T106991 -UN-07FEB97

9025
25
51

Tests

- b. Push E mode switch,
- c. Push auto-idle switch; wait approximately 4 seconds,
- d. And then turn engine rpm dial to slow idle.

EC motor (D) must move the speed control linkage to each position. Indicators must be ON and change randomly from bright to dim or dim to bright as engine rpm dial and switches are pushed to indicate there is continuity in the wiring harness and there is a signal from the engine and pump controller (EPC).

If one indicator is OFF, check continuity in that circuit. If both indicators are OFF, check the wiring harness and relay. (See procedure in Group 9015-15.)

TX,25,GG2223 -19-13AUG98-2/2

9025
25
52

Tests

MISCELLANEOUS COMPONENT HARNESS TEST


ESSENTIAL TOOLS

JT07067 Test Harness

The purpose of tests are to check continuity in miscellaneous circuits and wiring harnesses when a volt meter is not available.

IMPORTANT: Disconnecting electrical connectors while engine is running or with key switch on can damage engine and pump controller or other electrical components.

Retainer tab on male half of wiring harness connector halves must be pushed down before pulling halves apart. Never pull on wiring leads.



A—Bullet Connector
 B—Harness
 C—Eyelet
 D—Bullet Connector
 E—Indicator Light

1. Test harness may be used as a probe light. Indicator light (E) comes ON when connector (A) contacts 24 volts while eyelet (C) or bullet connector (D) is grounded.
2. Test harness may also be connected in series with components using bullet connectors (A and D). When circuit is energized, indicator light (E) comes ON.

NOTE: Indicator light will not come ON if test harness is connected to the ground side of a component.

3. Energize circuit being tested.
4. Observe indicator light (E). If light come ON, the fuses, wiring harness, and switches to accessory have continuity to the battery.

T7486AG -UN-19MAR91


9025
25
53

TX,25,GG2224 -19-22APR98-1/1

Tests


CYCLE TIME TEST

SPECIFICATIONS	
Hydraulic Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine Speed	Fast Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Boom Up Cycle Time	3.1 ± 0.3 sec
Boom Down Cycle Time	2.5 ± 0.3 sec
Arm In Cycle Time	3.9 ± 0.3 sec
Arm Out Cycle Time	2.6 ± 0.3 sec
Bucket Load Cycle Time	4.1 ± 0.3 sec
Bucket Dump Cycle Time	2.5 ± 0.3 sec
Swing—Check Left and Right Cycle Time	14.4 ± 1.0 sec for three revolutions from a running start
Fast Speed Propel—Check Forward and Reverse Cycle Time	13.4 ± 1.0 sec for 20 m (65 ft) from a running start
Slow Speed Propel—Check Forward and Reverse Cycle Time	20.6 ± 2.0 sec for 20 m (65 ft) from a running start
Slow Speed Propel With Track Raised—Check Forward and Reverse Cycle Time	29.9 ± 2.0 sec for three revolutions from a running start




T7918AO (CY)

Boom Position



T7918AP (CY)

Arm, Bucket, Swing and Propel Position



Propel 3-Revolution Position

SERVICE EQUIPMENT AND TOOLS	
JT05800 Digital Thermometer	
Stop Watch	

Test is used as an indication of overall engine and hydraulic system performance. A slow cycle time is an indication of a leaky or malfunctioning hydraulic system component or a weak engine.

Continued on next page

TX,9025,GG2645 -19-21MAY98-1/3

T7918AO -UN-11JAN93

T7918AP -UN-11JAN93

T7160AL -UN-03JAN90

9025
25
54

Tests

1. Adjust track sag to specifications. (See procedure in Group 9020-20.)
2. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
3. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Hydraulic Oil—Specification

Temperature $50 \pm 5^\circ\text{C}$ ($120 \pm 10^\circ\text{F}$)

4. Move machine to position shown for each test. Run machine at specifications.

Engine—Specification

Speed Fast Idle

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off

HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification

Position Off

5. Actuate control valve to full stroke for each function. Record the cycle time for each function.

Boom Up—Specification


Cycle Time..... 3.1 ± 0.3 sec

Boom Down—Specification

Cycle Time..... 2.5 ± 0.3 sec


Arm In—Specification

Cycle Time..... 3.9 ± 0.3 sec




T7918AO (CV)

Boom Position



T7918AP (CV)

Arm, Bucket, Swing and Propel Position



Propel 3-Revolution Position

T7918AO -UN-11JAN93

T7918AP -UN-11JAN93

T7160AL -UN-03JAN90

9025
25
55

Tests

Arm Out—Specification

Cycle Time..... 2.6 ± 0.3 sec

Bucket Load—Specification

Cycle Time..... 4.1 ± 0.3 sec

Bucket Dump—Specification

Cycle Time..... 2.5 ± 0.3 sec

Swing—Check Left and Right—Specification

Cycle Time..... 14.4 ± 1.0 sec for three
 revolutions from a running start

Fast Speed Propel—Check Forward and Reverse—Specification

Cycle Time..... 13.4 ± 1.0 sec for 20 m (65 ft)
 from a running start

Slow Speed Propel—Check Forward and Reverse—Specification

Cycle Time..... 20.6 ± 2.0 sec for 20 m (65 ft)
 from a running start


**Slow Speed Propel With Track Raised—Check Forward and
 Reverse—Specification**

Cycle Time..... 29.9 ± 2.0 sec for three
 revolutions from a running start

9025
 25
 56

Tests

SWING DYNAMIC BRAKING TEST



SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine Speed in Standard Mode	Fast Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
After 90° (1/4 turn) Swing, Upperstructure Must Stop After Releasing Control Lever Within Distance	45° (1/8 turn)

SERVICE EQUIPMENT AND TOOLS
JT05800 Digital Thermometer

1. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
2. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

CAUTION: Check that area is clear and large enough to swing upperstructure with arm and bucket extended. Machine must be on level ground.

3. Turn upperstructure so boom is to the front
4. Extend the arm and bucket. Lower boom so bucket is approximately 900 mm (3 ft) above the ground.
5. Operate machine at specifications.

Engine—Specification

Speed in Standard Mode Fast Idle

Work Mode Selector—Specification

Position Dig Mode

9025
25
57

Tests

E Mode Switch—Specification

Position..... Off

HP Mode Switch—Specification

Position..... Off

Auto-Idle Switch—Specification

Position..... Off

6. Actuate the swing control lever to full stroke. Swing 90° (1/4 turn) and then release control lever.

Upperstructure must come to a stop within 45° (1/8 turn) after releasing control lever.

After 90° (1/4 turn) Swing, Upperstructure Must Stop After Releasing Control Lever Within—Specification

Distance..... 45° (1/8 turn)

Repeat procedure in the opposite direction.

If upperstructure does not stop within 45° (1/8 turn), check the following:

- Swing motor leakage. (See procedure in this group.)
- Swing motor crossover relief valves. (See procedure in this group.)
- Inspect swing valve spool. (See procedure in Group 3360.)

NOTE: The swing park brake does not stop the upperstructure. The engagement of swing park brake is delayed several seconds because hydraulic oil is released from the piston cavity through an orifice to return.

9025
25
58

Tests

**PILOT PRESSURE REGULATING VALVE
TEST AND ADJUSTMENT**

SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine in Standard Mode Speed	Fast Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Pilot System Pressure	3925 + 980 - 490 kPa (39.2 + 9.8 - 4.9 bar) (570 + 140 - 70 psi)
Per 0.25 mm (0.010 in.) Shim Approximate Change Pressure	78 kPa (0.75 bar) (11 psi)
Per 0.5 mm (0.020 in.) Shim Approximate Change Pressure	157 kPa (1.57 bar) (23 psi)
Per 1.0 mm (0.040 in.) Shim Approximate Change Pressure	304 kPa (3.04 bar) (44 psi)
Plug-to-Pilot Pressure Regulating Housing Torque	25 N•m (215 lb-in.)

ESSENTIAL TOOLS
202862 (3/4-16 M 37° x 3/4-16 F 37° Sw x 7/16-20 M 37°) Tee
TH108328 Adapter
6 mm Hex Key Wrench

SERVICE EQUIPMENT AND TOOLS
Gauge 7000 kPa (70 bar) (1000 psi)
JT05800 Digital Thermometer
JT02156A Digital Pressure and Temperature Analyzer

Purpose of test is to ensure there is enough pilot pressure to operate all the pilot system functions and to adjust the pressure as necessary. The pilot pressure regulating valve is used to regulate the pilot system pressure.

Continued on next page

TX,9025,GG2646 -19-08JUN98-1/6

9025
25
59

Tests


NOTE: The laptop computer with the excavator diagnostic software can be used to make a quick check of the pilot system pressure using the arm in function. Connect the computer and select "5 Arm roll-in pilot pressure" from monitor data menu. Run engine at fast idle and then actuate arm in function over relief. The pressure reading displayed is from the arm in pressure sensor located in the flow regulator valve.

Before making any adjustments, check the pilot pressure at the pilot pump using a pressure gauge.

1. Stop the engine.

TX,9025,GG2646 -19-08JUN98-2/6

2. Loosen vent plug (K) to release the air pressure in hydraulic oil tank.



K—Vent Plug

T109340 -UN-29APR97

Continued on next page

TX,9025,GG2646 -19-08JUN98-3/6

Tests

3. Disconnect pilot filter inlet line (D) at pilot filter. Install tee (B) and gauge (C).

Pressure can also be checked at the test port in fitting at outlet port of pilot pump (F). Install adapter (G) and gauge (C).

NOTE: Because the plug is installed dry at the factory, the plug can be difficult to remove.

4. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)

5. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

6. Run machine at specifications. Record pressure reading for pilot pressure regulating valve (A).

Engine in Standard Mode—Specification

Speed Fast Idle

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off

HP Mode Switch—Specification


Position Off

Auto-Idle Switch—Specification


Position Off

Pilot System—Specification

Pressure 3925 + 980 - 490 kPa
 (39.2 + 9.8 - 4.9 bar)
 (570 + 140 - 70 psi)



T103346



T109473

- A—Pilot Pressure Regulating Valve
- B—Tee Fitting
- C—Gauge
- D—Pilot Filter Inlet Line
- E—Pilot Pump
- G—Adapter

T103346 -UN-11SEP96

T109473 -UN-12MAY97

9025
25
61

Tests

Per 0.25 mm (0.010 in.) Shim Approximate Change—Specification

Pressure 78 kPa (0.75 bar) (11 psi)

Per 0.5 mm (0.020 in.) Shim Approximate Change—Specification

Pressure 157 kPa (1.57 bar) (23 psi)

Per 1.0 mm (0.040 in.) Shim Approximate Change—Specification

Pressure 304 kPa (3.04 bar) (44 psi)


TX_9025.GG2646 -19-08JUN98-5/6

7. As necessary, remove plug for pilot pressure regulating valve (A). Add shims (E) to increase pressure; remove shims to decrease pressure.

8. Tighten plug.

Plug-to-Pilot Pressure Regulating Housing—Specification

Torque 25 N•m (215 lb-in.)



A—Pilot Pressure Regulating Valve
E—Shims

T103347 -UN-11SEP96

TX_9025.GG2646 -19-08JUN98-6/6

9025
25
62

Tests

VALVE SPOOL ACTUATING PILOT PRESSURE TEST

SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine Speed in Standard Mode	Slow Idle and Fast Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Valve Spool Actuating Pressure	3335—3920 kPa (33.3—39.2 bar) (485—570 psi)

ESSENTIAL TOOLS
203836 (9/16-18 M 37° x 9/16-18 Sw 37° x 7/16-20 M 37°) Tee

SERVICE EQUIPMENT AND TOOLS
Gauge 7000 kPa (70 bar) (1000 psi)
JT05800 Digital Thermometer


Purpose of test is to ensure that the pilot pressure to the valve spools is enough to shift the spools.

1. Stop engine.

9025
25
63

TX,9025,GG2647 -19-08JUN98-1/4

2. Loosen vent plug (K) to release the air pressure in hydraulic oil tank.




K—Vent Plug

Continued on next page

TX,9025,GG2647 -19-08JUN98-2/4

Tests

3. Disconnect a pilot line (A) at pilot cap fitting. Install tee (B) and pressure gauge (C).
4. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
5. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)



T101596

- A—Pilot Line
- B—Tee Fitting
- C—Gauge

T101596 -JUN-18JUN96

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

6. Start and run engine at specification.

Engine—Specification

Speed in Standard Mode Slow Idle and Fast Idle

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off

HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification

Position Off

Valve Spool Actuating—Specification

Pressure 3335—3920 kPa (33.3—39.2 bar)
(485—570 psi)

NOTE: *Spool actuating pressure can be checked for each function by installing the tee and gauge in that pilot line and then actuating that function.*

7. Actuate the function being checked to full stroke.

If valve spool actuating pressure is not to specification, check pilot system pressure. (See Pilot Pressure Regulating Valve Test and Adjustment in this group.)

9025
25
64

Tests

If pilot system pressure is to specification, then check pilot pressure at the pilot shutoff valve, pilot controllers, and flow regulator

TX,9025,GG2647 -19-08JUN98-4/4

9025
25
65

Tests

**SYSTEM RELIEF AND POWER BOOST
VALVE TEST AND ADJUSTMENT**

SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine in Standard Mode Speed	Fast Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
System Relief Valve Pressure	34 325 + 1960 - 0 kPa (343 + 19.6 - 0 bar) (4980 + 285 - 0 psi)
System Relief Valve Pressure	5295 kPa (53.0 bar) (770 psi) approximate change per 1/4 turn of second adjusting plug
Power Boost Pressure	36 285 + 1960 - 980 kPa (362.9 + 19.6 - 9.8 bar) (5265 + 285 - 140 psi)
Power Boost Pressure	7110 kPa (71.1 bar) (1030 psi) approximate change per 1/4 turn of first adjusting plug
32 mm Nut Torque	78—88 N•m (58—65 lb-ft)
27 mm Nut Torque	59—68 N•m (43—51 lb-ft)

ESSENTIAL TOOLS	
TH108328 Adapter (2 used)	
XPD34BTX (1/8 x 7/16-20 F 37°) Male Quick Coupler	

SERVICE EQUIPMENT AND TOOLS	
JT07290 Laptop Computer	
JT07274G Excavator Diagnostics Program Disk	
JT07273 Cable	
JT02156A Digital Pressure and Temperature Analyzer	
JT02160 Transducer 70 000 kPa (700 bar) (10 000 psi)	
Gauge 70 000 kPa (700 bar) (10 000 psi)	
JT05800 Digital Thermometer	
6 mm Hex Key Wrench	
15, 17, 19, 27 and 32 mm Combination Wrenches	


The purpose of the system relief valve is to limit the maximum pressure in the hydraulic system. The valve is checked and adjusted to protect components from damage cause by excessive pressures.

Continued on next page

TX.9025.GG2648 -19-08JUN98-1/5

Tests

1. Connect the laptop computer. (See the installation procedure in this group.)
 - a. Start the engine.
 - b. Select "3 Front pump delivery pressure" and "4 Rear pump delivery pressure" from the Monitor Data menu.



T102900

Continued on next page

TX,9025,GG2648 -19-08JUN98-2/5


T102900 -19-29AUG96

9025
25
67

Tests

If laptop computer is not available, use the digital pressure and temperature analyzer, and transducers or gauges.

- a. Stop the engine.
- b. Loosen vent plug (K) to release the air pressure in hydraulic oil tank.
- c. Install adapter (A) and male quick coupler to test port on front pump (C) or rear pump (B). Connect the analyzer and transducers or gauges.



T109340 -UN-29APR97

- 2. Install the temperature probe on the hydraulic oil tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
- 3. Raise and lower boom to pressurize hydraulic oil tank.
- 4. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

- 5. Run machine at specification.

Engine in Standard Mode—Specification

Speed Fast Idle

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off


HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification

Position Off

- 6. Actuate the arm in function over relief.



T101614

- A—Adapter
- B—Rear Pump
- C—Front Pump
- K—Vent Plug

T101614 -UN-18JUN96

9025
25
68

Tests

Record the pressure reading for the system relief valve.

System Relief Valve—Specification

Pressure 34 325 + 1960 - 0 kPa
 (343 + 19.6 - 0 bar)
 (4980 + 285 - 0 psi)

Pressure 5295 kPa (53.0 bar) (770 psi)
 approximate change per 1/4 turn
 of second adjusting plug

7. Actuate the bucket curl function over relief and then push the power boost button on the right control lever.

Record the pressure reading for power boost.

Power Boost—Specification

Pressure 36 285 + 1960 - 980 kPa
 (362.9 + 19.6 - 9.8 bar)
 (5265 + 285 - 140 psi)

Pressure 7110 kPa (71.1 bar) (1030 psi)
 approximate change per 1/4 turn
 of first adjusting plug

8. Adjust the power boost and system relief valve pressures as needed using the following steps.

9025
25
69

Continued on next page

TX,9025,GG2648 -19-08JUN98-4/5

Tests

9. Disconnect pilot line from elbow in system relief valve (D) so adjustment can be made without twisting power boost pilot line. Connect pilot line before starting engine and applying pressure.

10. Loosen 27 mm nut (F).

11. Turn first adjusting plug (E) in until piston (I) is against bottom of bore in second adjusting plug (G). Tighten nut. Connect pilot line.

12. Loosen 32 mm nut (H).

13. Start engine. Actuate the arm in function over relief.

14. Turn second adjusting plug in to increase pressure; turn adjusting plug out to decrease pressure to get specified pressure for power boost.

Hold adjusting plug and tighten 32 mm nut.

32 mm Nut—Specification

Torque 78—88 N•m (58—65 lb-ft)

15. Loosen 27 mm nut (F).

16. Actuate the arm in function over relief.


17. Turn first adjusting plug (E) out to decrease pressure to get specified pressure for system relief valve.

Hold adjusting plug and tighten 27 mm nut.

27 mm Nut—Specification

Torque 59—68 N•m (43—51 lb-ft)

18. Check the pressures again.



T101616

- D—System Relief Valve
- E—First Adjusting Plug
- F—27 mm Nut
- G—Second Adjusting Plug
- H—32 mm Nut
- I—Piston

T101616 -UN-18JUN96

TX,9025,GG2648 -19-08JUN98-5/5

Tests

CIRCUIT RELIEF VALVE TEST AND ADJUSTMENT

SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine in Standard Mode Speed	Slow Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Boom Up (Head End) Pressure	37 265 + 980 - 0 kPa (375 + 9.8 - 0 bar) (5405 + 140 - 0 psi)
Arm In (Head End) Pressure	37 265 + 980 - 0 kPa (375 + 9.8 - 0 bar) (5405 + 140 - 0 psi)
Bucket Dump (Rod End) Pressure	37 265 + 980 - 0 kPa (375 + 9.8 - 0 bar) (5405 + 140 - 0 psi)
Boom Down (Rod End) Pressure	37 265 + 980 - 0 kPa (375 + 9.8 - 0 bar) (5405 + 140 - 0 psi)
Arm Out (Rod End) Pressure	39 225 + 980 - 0 kPa (390 + 9.8 - 0 bar) (5690 + 140 - 0 psi)
Bucket Curl (Head End) Pressure	39 225 + 980 - 0 kPa (390 + 9.8 - 0 bar) (5690 + 140 - 0 psi)
Circuit Relief Valve Pressure	5295 kPa (53 bar) (770 psi) approximate change per 1/4 turn of adjusting screw

ESSENTIAL TOOLS	
TH108328 Adapter (2 used)	
XPD34BTX (1/8 x 7/16-20 F 37°) Male Quick Coupler	

9025
25
71

Continued on next page

TX,9025,GG2649 -19-08JUN98-1/7


Tests

SERVICE EQUIPMENT AND TOOLS

JT07290 Laptop Computer
JT07274G Excavator Diagnostics Program Disk
JT07273 Cable
JT02156A Digital Pressure and Temperature Analyzer
JT02160 Transducer 70 000 kPa (700 bar) (10 000 psi)
Gauge 70 000 kPa (700 bar) (10 000 psi)
JT05800 Digital Thermometer
6 mm Hex Key Wrench
17 mm Combination Wrench

TX,9025,GG2649 -19-08JUN98-2/7

1. Connect the laptop computer. (See the installation procedure in this group.)
 - a. Start the engine.
 - b. Select "3 Front pump delivery pressure" and "4 Rear pump delivery pressure" from the Monitor Data menu.



T102900

Continued on next page


T102900 -19-29AUG96

TX,9025,GG2649 -19-08JUN98-3/7

Tests

If laptop computer is not available, use the digital pressure and temperature analyzer, and transducers, or gauges.

- a. Stop the engine.
- b. Loosen vent plug (K) to release the air pressure in hydraulic oil tank.
- c. Install adapter (A) and male quick coupler to test port on front pump (C) or rear pump (B). Connect the analyzer and transducers or gauges.



T109340 -UN-29APR97

2. Install the temperature probe on the hydraulic oil tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
3. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

4. Extend the cylinder to check a head end circuit relief valve; retract the cylinder to check a rod end circuit relief valve.
5. Run machine at specifications.

Engine in Standard Mode—Specification

Speed Slow Idle

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification


Position Off

HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification

Position Off




T101614

- A—Adapter
- B—Rear Pump
- C—Front Pump
- K—Vent Plug

T101614 -UN-18JUN96

9025
25
73

Tests



T109335 -UN-29APR97

T109335

- D—System Relief Valve
- K—Boom Up Circuit Relief Valve
- L—Bucket Dump Circuit Relief Valve
- M—Boom Down Circuit Relief Valve
- N—Bucket Curl Circuit Relief Valve

6. Actuate function over relief for circuit relief valve (K, L, M, and O) being checked.


NOTE: Actuating the power boost function increases the system relief pressure enough to check and adjust the dig function circuit relief valves except arm out and bucket curl. For arm out and bucket curl circuit relief valves the second adjusting plug for system relief valve is turned in 1/4 turn to increase the pressure setting above the circuit relief valves.

7. Actuate the power boost function.

8. Record the pressure reading.

Boom Up (Head End)—Specification

Pressure..... 37 265 + 980 - 0 kPa
 (375 + 9.8 - 0 bar)
 (5405 + 140 - 0 psi)



T109336 -UN-29APR97

T109336

- O—Arm In Circuit Relief Valve

Arm In (Head End)—Specification

Pressure..... 37 265 + 980 - 0 kPa
 (375 + 9.8 - 0 bar)
 (5405 + 140 - 0 psi)

Bucket Dump (Rod End)—Specification


Pressure..... 37 265 + 980 - 0 kPa
 (375 + 9.8 - 0 bar)
 (5405 + 140 - 0 psi)

Boom Down (Rod End)—Specification

Pressure..... 37 265 + 980 - 0 kPa
 (375 + 9.8 - 0 bar)
 (5405 + 140 - 0 psi)


9025
25
74

Tests



T109334

T109334 -UN-29APR97



T109336

T109336 -UN-29APR97

9. For arm out (J) and bucket curl (N) circuit relief valves, turn the second adjusting plug (G) for system relief valve (D) in 1/4 turn to increase the pressure setting.

10. Actuate the function over relief for circuit relief valve being checked.

Record the pressure reading.

Arm Out (Rod End)—Specification


Pressure 39 225 + 980 - 0 kPa
 (390 + 9.8 - 0 bar)
 (5690 + 140 - 0 psi)

Bucket Curl (Head End)—Specification

Pressure 39 225 + 980 - 0 kPa
 (390 + 9.8 - 0 bar)
 (5690 + 140 - 0 psi)

Circuit Relief Valve—Specification

Pressure 5295 kPa (53 bar) (770 psi)
 approximate change per 1/4 turn
 of adjusting screw



T101616

T101616 -UN-18JUN96

- D—System Relief Valve
- E—First Adjusting Plug
- F—27 mm Nut
- G—Second Adjusting Plug
- H—32 mm Nut
- I—Piston
- J—Arm Out Circuit Relief Valve
- M—Boom Down Circuit Relief Valve
- N—Bucket Curl Circuit Relief Valve
- O—Arm In Circuit Relief Valve

9025
25
75

Tests

NOTE: If pressure reading fluctuates increase engine speed slightly.

11. Adjust the circuit relief valve as needed. Turn adjusting screw IN to increase pressure setting; turn adjusting screw out to decrease pressure setting. Hold screw and tighten nut.
12. Turn second adjusting plug (G) for system relief valve (D) out 1/4 turn. Hold plug and tighten 32 mm nut (H).

TX,9025,GG2649 -19-08JUN98-7/7

9025
25
76

Tests

SWING MOTOR CROSSOVER RELIEF VALVE TEST AND ADJUSTMENT

SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine in Standard Mode Speed	Slow Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Crossover Relief Valve Pressure	32 360 + 1960 - 0 kPa (323.6 + 19.6 - 0 bar) (4695 + 285 - 0 psi)
Crossover Relief Valve Pressure	2940 kPa (29.4 bar) (430 psi) approximate change per 1/4 turn of adjusting plug


ESSENTIAL TOOLS
TH108328 Adapter
XPD34BTX (1/8 x 7/16-20 F 37°) Male Quick Coupler

SERVICE EQUIPMENT AND TOOLS
JT07290 Laptop Computer
JT07274G Excavator Diagnostics Program Disk
JT07273 Cable
JT02156A Digital Pressure and Temperature Analyzer
JT02160 Transducer 70 000 kPa (700 bar) (10 000 psi)
Gauge 70 000 kPa (700 bar) (10 000 psi)
JT05800 Digital Thermometer
8 mm Hex Key Wrench
32 and 36 mm Combination Wrench
17 mm Combination Wrench

9025
25
77

TX,9025,GG2650 -19-28APR97-1/5

1. Connect the laptop computer. (See the installation procedure in this group.)
 - a. Start the engine.
 - b. Select "4 Rear pump delivery pressure" from the Monitor Data menu.



T102900

T102900 -19-29AUG96


Continued on next page

TX,9025,GG2650 -19-28APR97-2/5

Tests

If laptop computer is not available, use the digital pressure and temperature analyzer, and transducer, or a gauge.

- a. Stop the engine.
- b. Loosen vent plug (K) to release the air pressure in hydraulic oil tank.
- c. Install adapter (A) and male quick coupler to test port on rear pump (B). Connect the analyzer and transducers or gauges.



T109340 -UN-29APR97

2. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
3. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

4. Raise and lower boom to pressurize hydraulic tank.
5. Run machine at specifications.

Engine in Standard Mode—Specification

Speed Slow Idle

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off


HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification

Position Off

6. Operate the swing function at stall. To stall swing function, put bucket against an immovable object or in a trench then actuate the control lever to full stroke.



T101715

A—Adapter
B—Rear Pump
K—Vent Plug

T101715 -UN-20JUN96

9025
25
78

Tests

Record the pressure reading.


Repeat procedure for the opposite direction. Record the pressure reading.

Crossover Relief Valve—Specification

Pressure 32 360 + 1960 - 0 kPa
 (323.6 + 19.6 - 0 bar)
 (4695 + 285 - 0 psi)
 Pressure 2940 kPa (29.4 bar) (430 psi)
 approximate change per 1/4 turn
 of adjusting plug

TX,9025,GG2650 -19-28APR97-4/5

7. Adjust the crossover relief valves (C or D) for left or right swing as needed. Loosen nut (E). Turn adjusting plug (F) in to increase pressure setting; turn adjusting plug out to decrease pressure setting.



T101716

- C—Right Swing Crossover Relief Valve
- D—Left Swing Crossover Relief Valve
- E—Nut
- F—Adjusting Plug

T101716 -UN-20JUN96

9025
25
79

TX,9025,GG2650 -19-28APR97-5/5

Tests

PROPEL MOTOR CROSSOVER RELIEF VALVE TEST AND ADJUSTMENT


SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine in Standard Mode Speed	Fast Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Crossover Relief Valve Pressure	34 324 + 1960 - 0 kPa (343.2 + 19.6 - 0 bar) (4980 + 285 - 0 psi)
Crossover Relief Valve Pressure	2940 kPa (29.4 bar) (430 psi) approximate change per 1/4 turn of adjusting screw

ESSENTIAL TOOLS
TH108328 Adapter (2 used)
XPD34BTX (1/8 x 7/16-20 F 37°) Male Quick Coupler

SERVICE EQUIPMENT AND TOOLS
JT07290 Laptop Computer
JT07274G Excavator Diagnostics Program Disk
JT07273 Cable
JT02156A Digital Pressure and Temperature Analyzer
JT02160 Transducer 70 000 kPa (700 bar) (10 000 psi)
Gauge 70 000 kPa (700 bar) (10 000 psi)
JT05800 Digital Thermometer
85 mm (3-3/8 in.) OD Pin or Length of Round Bar Stock (2 used)
6 mm Hex Key Wrench
19 mm Combination Wrench

TX,9025,GG2651 -19-28APR97-1/5

1. Connect the laptop computer. (See the installation procedure in this group.)
 - a. Start the engine.
 - b. Select "3 Front pump delivery pressure" and "4 Rear pump delivery pressure" from the Monitor Data menu.



T102900

T102900 -19-29AUG96

Continued on next page


TX,9025,GG2651 -19-28APR97-2/5

9025
25
80

Tests

If laptop computer is not available, use the digital pressure and temperature analyzer, and transducers, or gauges.

- a. Stop the engine.
- b. Loosen vent plug (K) to release the air pressure in hydraulic oil tank.
- c. Install adapter (A) and male quick coupler to test port on front pump (C) and rear pump (B). Connect the analyzer and transducers or gauges.




T109340 -UN-29APR97

2. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
3. Raise and lower boom to pressurize hydraulic oil tank.
4. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)



T101614

- A—Adapter
- B—Rear Pump
- C—Front Pump
- K—Vent Plug

T101614 -UN-18JUN96

9025
25
81

Continued on next page

TX,9025,GG2651 -19-28APR97-3/5

Tests

5. Install pins or round bar stock (D) between the sprockets and track frame to stall both propel motors.

6. Run machine at specifications.

Engine in Standard Mode—Specification

Speed Fast Idle

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off

HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification

Position Off

NOTE: Actuating the power boost function increases the system relief pressure enough to check and adjust the propel motor crossover relief valves.

7. Slowly push propel pedal, for propel motor being stalled, to full travel in the direction for the crossover relief valve being checked.


Push the power boost button on the right control lever.

Record the pressure reading.

Crossover Relief Valve—Specification

Pressure 34 324 + 1960 - 0 kPa
 (343.2 + 19.6 - 0 bar)
 (4980 + 285 - 0 psi)

Pressure 2940 kPa (29.4 bar) (430 psi)
 approximate change per 1/4 turn
 of adjusting screw



D—Round Bar Stock

T101856 -UN-02JUL96


9025
25
82

Continued on next page

TX,9025,GG2651 -19-28APR97-4/5

Tests

8. Adjust the crossover relief valves (E and F) as needed. Turn adjusting screw in to increase the pressure setting; turn adjusting screw out to decrease pressure.
9. Repeat procedure for the other crossover relief valves.



T101857

T101857 -UN-02JUL96

E—Forward Crossover Relief Valve
F—Reverse Crossover Relief Valve

TX,9025,GG2651 -19-28APR97-5/5

9025
 25
 83

Tests

**PROPORTIONAL SOLENOID VALVE TEST
AND ADJUSTMENT**

SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine in Standard Mode Speed	Fast Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Position	Off
Propel Speed Switch Position	Fast Speed
Arm Regenerative (SC) Pressure	Laptop computer reading ± 196 kPa (1.96 bar) (28 psi)
Speed Sensing (SD) Pressure	Laptop computer reading ± 196 kPa (1.96 bar) (28 psi)
Propel Speed Change (SI) Pressure	Laptop computer reading ± 196 kPa (1.96 bar) (28 psi)
Power Boost (SG) Pressure	Laptop computer reading ± 196 kPa (1.96 bar) (28 psi)
Proportional Solenoid Valve Pressure	98 kPa (0.98 bar) (14 psi) approximate change per 1/4 turn of adjusting screw
End of Adjusting Screw to Nut Must Not Exceed Length	4 mm (0.157 in.)
Adjusting Screw-to-Housing Nut Torque	8.8 N•m (78 lb-in.)

ESSENTIAL TOOLS	
JT03464 (1/4 M BSPP ORB x 7/16-20 M 37° x M14-1.5 M 45°) Tee (for the steel line)	
JT03001 (7/16-20 M 37° x 7/16-20 F 37° x 7/16-20 M 37°) (Parker No. 063T-4-4) Tee	

SERVICE EQUIPMENT AND TOOLS	
JT02156A Digital Pressure and Temperature Analyzer	
JT02162 Transducer 35 000 kPa (350 bar) (5000 psi)	
Gauge 7000 kPa (70 bar) (1000 psi)	
JT07290 Laptop Computer	
JT07274G Excavator Diagnostics Program Disk	
JT07273 Cable	
JT05800 Digital Thermometer	
4 mm Hex Key Wrench	
13 mm Combination Wrench	

Continued on next page

TX,9025,GG2121 -19-21MAY98-1/6


Tests

Procedure is to check that the hydraulic pressure output for the proportional solenoid valves are within the specified pressure range of the pressure shown on the laptop computer. The pressure shown on computer is a calculated pressure from the electrical signal from the engine and pump controller (EPC).

TX,9025,GG2121 -19-21MAY98-2/6

1. Stop the engine.

Loosen vent plug (K) to release the air pressure in hydraulic oil tank.



T109340 -UN-29APR97

K—Vent Plug

9025
25
85


Continued on next page

TX,9025,GG2121 -19-21MAY98-3/6

Tests

NOTE: Proportional solenoid valve output pressure must be measured using a pressure gauge. The pressure shown on laptop computer is calculated from an electrical signal from the engine and pump controller and does not change as the solenoid valve adjustment is made.

2. Disconnect the line (D, E, F, or G) at solenoid valve manifold (A) for solenoid valve (H) being checked. Install test connection (B and C). For steel line (D) from the arm regenerative solenoid valve (SC) use the JT03464 Tee. Use the JT03001 Tee for the others. Install the digital pressure and temperature analyzer, and transducer, or a gauge (C).
3. Connect the laptop computer.
4. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
5. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)



T101708

- A—Solenoid Valve Manifold
- B—JT03464 Tee or JT03001 Tee
- C—Gauge
- D—Arm Regenerative Solenoid Valve (SC) Line
- E—Speed Sensing Solenoid Valve (SD) Line
- F—Propel Speed Change Solenoid Valve (SI) Line
- G—Power Boost Solenoid Valve (SG) Line
- H—Solenoid Valve (4 used)

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

6. Run the machine at specification. To check each solenoid valve, operate the machine as follows and then record the pressure reading from gauge and laptop computer:

Engine in Standard Mode—Specification

Speed Fast Idle

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off

HP Mode Switch—Specification

Position Off

9025
25
86

Tests

Auto-Idle—Specification

Position Off

Propel Speed Switch—Specification

Position Fast Speed

Arm Regenerative (SC)—Specification

Pressure Laptop computer reading
 ± 196 kPa (1.96 bar) (28 psi)

Speed Sensing (SD)—Specification

Pressure Laptop computer reading
 ± 196 kPa (1.96 bar) (28 psi)

Propel Speed Change (SI)—Specification

Pressure Laptop computer reading
 ± 196 kPa (1.96 bar) (28 psi)

Power Boost (SG)—Specification

Pressure Laptop computer reading
 ± 196 kPa (1.96 bar) (28 psi)

- For arm regenerative solenoid valve (SC), operate boom up and arm in functions in combined operation.
- For speed sensing solenoid valve (SD), operate arm in function over relief and boom up function to load the engine.
- For propel speed change solenoid valve (SI), drive the machine at fast speed propel.
- For power boost solenoid valve (SG), push and release power boost button on right control lever.

7. Compare pressure readings from the gauge and laptop computer. The pressure reading from gauge must be within the specified range of calculated pressure reading on the computer.

9025
25
87

Continued on next page

TX,9025,GG2121 -19-21MAY98-5/6

Tests

8. Adjust the solenoid valve (H) as needed. Turn adjusting screw (I) IN to increase pressure setting; turn adjusting screw out to decrease pressure setting. Hold screw and tighten nut (J).

- Make a mark on the end of adjusting screw for the original position of screw. Do not mark on threads of screw.

IMPORTANT: Turning adjusting screw out too far may cause oil leakage because the O-ring has come off its seat. The length from end of adjusting screw to nut must not exceed 4 mm (0.157 in.).

- Loosen nut just enough so adjusting screw can be turned. Turn adjusting screw in to increase pressure; turn adjusting screw out to decrease pressure.

Proportional Solenoid Valve—Specification

Pressure 98 kPa (0.98 bar) (14 psi)
 approximate change per 1/4 turn
 of adjusting screw

End of Adjusting Screw to Nut Must Not Exceed—Specification


Length..... 4 mm (0.157 in.)

- Hold adjusting screw and then tighten nut.

Adjusting Screw-to-Housing Nut—Specification

Torque 8.8 N•m (78 lb-in.)

- Check the pressure again.



T101709

H—Solenoid Valve
 I—Adjusting Screw
 J—Nut

T101709 -JUN-20JUN96

9025
 25
 88

Tests

PUMP CONTROL VALVE TEST

SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine in Standard Mode Speed	Slow and Fast Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Typical Front or Rear Pump Control Valve Pilot Oil Control Signal Pressure	1655—1930 kPa (16.5—19.3 bar) (240—280 psi) at slow idle with all functions in neutral
Typical Front or Rear Pump Control Valve Pilot Oil Control Signal Pressure	1035—1520 kPa (10.3—15.2 bar) (150—220 psi) at fast idle with all functions in neutral
Typical Front or Rear Pump Control Valve Pilot Oil Control Signal Pressure	3310—3515 kPa (33.1—35.2 bar) (480—510 psi) at slow idle with arm in function over relief
Typical Front or Rear Pump Control Valve Pilot Oil Control Signal Pressure	3380—3585 kPa (33.8—35.9 bar) (490—520 psi) at fast idle with arm in function over relief

ESSENTIAL TOOLS
JT03001 (7/16-20 M 37° x 7/16-20 M 37° x 7/16-20 F 37°) (Parker No. 063T-4-4) Tee (2 used)
XPD34BTX (1/8 x 7/16-20 F 37°) Male Quick Coupler

SERVICE EQUIPMENT AND TOOLS
JT07290 Laptop Computer
JT07274G Excavator Diagnostics Program Disk
JT07273 Cable
JT02156A Digital Pressure and Temperature Analyzer
JT02162 Transducer 35 000 kPa (350 bar) (5000 psi)
Gauge 7000 kPa (70 bar) (1000 psi) (2 used)
JT05800 Digital Thermometer
8 mm Hex Key Wrench
22 mm Combination Wrench

9025
25
89

Continued on next page


TX,9025,GG2652 -19-21MAY98-1/6

Tests

The function of pump control valves is to send a regulated pilot oil control signal to its respective pump regulator to change pump flow in response to the actuation of control valve spools. (See Pump Control Valve Operation in Group 9025-05.) The purpose of test is to check that the regulated pilot oil control signal increases as a function is actuated and decreases when function is returned to neutral by monitoring the front and rear pump control pressure sensor readings. The valves are adjusted at the factory and there should never be any need for an adjustment in the field.

TX,9025,GG2652 -19-21MAY98-2/6

1. Connect the laptop computer. (See the installation procedure in this group.)
 - a. Start the engine.
 - b. Select "1 Front pump control pressure" and "6 Rear pump control pressure" from the Monitor Data menu.



T102900

Continued on next page


T102900 -19-29AUG96

TX,9025,GG2652 -19-21MAY98-3/6

Tests

If laptop computer is not available, use the digital pressure and temperature analyzer, and transducers, or gauges.

- a. Stop the engine.
- b. Loosen vent plug (K) to release the air pressure in hydraulic oil tank.
- c. Install tees (C) and male quick couplers in line with pump control valve pilot lines at rear (A) and front (B) pump regulators. Connect the analyzer and transducers or gauges (D).



T109340 -UN-29APR97

2. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
3. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

4. Run machine as specified.

Engine in Standard Mode—Specification

Speed Slow and Fast Idle

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off


HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification

Position Off

5. Run engine at slow idle with all functions in neutral. Record pressure readings.



- A—Pump Control Valve Pilot Line
- B—Pump Regulator
- C—Tee Fitting
- D—Gauge
- K—Vent Plug

T103348 -UN-11SEP96

9025
25
91

Tests

**Typical Front or Rear Pump Control Valve Pilot Oil Control Signal—
Specification**

Pressure 1655—1930 kPa (16.5—19.3 bar)
(240—280 psi) at slow idle with
all functions in neutral

6. Run engine at fast idle with all functions in neutral.
Record pressure readings.

**Typical Front or Rear Pump Control Valve Pilot Oil Control
Signal—Specification**

Pressure 1035—1520 kPa (10.3—15.2 bar)
(150—220 psi) at fast idle with all
functions in neutral

7. Run engine at slow idle. Actuate arm in function over
relief. Record pressure readings.

**Typical Front or Rear Pump Control Valve Pilot Oil Control
Signal—Specification**

Pressure 3310—3515 kPa (33.1—35.2 bar)
(480—510 psi) at slow idle with
arm in function over relief

8. Run engine at fast idle. Actuate arm in function over
relief. Record pressure readings.

**Typical Front or Rear Pump Control Valve Pilot Oil Control
Signal—Specification**

Pressure 3380—3585 kPa (33.8—35.9 bar)
(490—520 psi) at fast idle with
arm in function over relief

Continued on next page


TX,9025,GG2652 -19-21MAY98-5/6

9025
25
92

Tests


9. A pressure reading not in the ranges given can be an indication of contamination or sticking spools in the front (F) or rear (H) pump control valve. Before making any adjustments, check the front and rear pump control valve pressure sensors and the operation of remote control spool in front and rear pump regulators.

Turn the adjusting screw in to increase pressure reading; turn adjusting screw out to decrease pressure reading.



T103491

T103491 -UN-13SEP96



T103492






T103492 -UN-13SEP96

- E—Right Control Valve
- F—Front Pump Control Valve
- G—Left Control Valve
- H—Rear Pump Control Valve

9025
25
93

Tests

HYDRAULIC PUMP REGULATOR ADJUSTMENTS



T115420

- A—13 mm Nut
- B—Maximum Flow Adjusting Screw
- C—Flow Adjusting Cartridge (Track Cycle Time)
- D—30 mm Nut
- E—Minimum Flow Adjusting Screw

- F—17 mm Nut
- G—13 mm Nut
- H—Load Adjusting Screw (Inner Spring) (Engine Pulldown at High Pressure)

- I—Load Adjusting Cartridge (Outer Spring) (Engine Pulldown at Medium Pressure)
- J—30 mm Nut

Continued on next page

TX,9025,GG2653 -19-21MAY98-1/3

T115420 -JUN-27MAY98

Tests

SPECIFICATIONS	
Regulator Maximum Flow Adjusting Screw Turn	1/4 turn IN decreases maximum pump flow rate approximately 11.75 L/min (3.11 gpm)
Regulator Flow Adjusting Cartridge (Track Cycle Time) Turn	1/4 turn IN decreases pump flow rate approximately 23.5 L/min (6.23 gpm)
Regulator Minimum Flow Adjusting Screw Turn	1/4 turn IN increases minimum pump flow rate approximately 14.1 L/min (3.68 gpm)
Regulator Load Adjusting Screw (Inner Spring) (Engine Pulldown at High Pressure) Turn	1/4 turn IN increases pump flow rate approximately 5.67 L/min (1.51 gpm)
Regulator Load Adjusting Cartridge (Outer Spring) (Engine Pulldown at Medium Pressure) Turn	1/4 turn IN increases pump flow rate approximately 23.5 L/min (6.23 gpm)

The pumps are driven at engine speed.

IMPORTANT: Random adjustment will cause engine and hydraulic systems malfunctions. See Pump Regulator Tests and Adjustment for Minimum Flow, Maximum Flow and Engine Pulldown in this group.

Maximum Flow Adjusting Screw (B):

Turning adjusting screw IN decreases maximum pump flow rate.

Regulator Maximum Flow Adjusting Screw—Specification

Turn..... 1/4 turn IN decreases maximum pump flow rate approximately 11.75 L/min (3.11 gpm)

Do not turn adjusting screw in more than two turns. Tighten nut (A) after adjustment. Maximum flow adjusting screw must not be turned out to try to increase pump flow rate except after the adjustment of flow adjusting cartridge (C). For adjustment, see Hydraulic Pump Regulator Test and Adjustment—Maximum Flow in this group.

Flow Adjusting Cartridge (Track Cycle Time) (C):

Turning adjusting cartridge IN decreases pump flow rate.

Regulator Flow Adjusting Cartridge (Track Cycle Time)—Specification

Turn..... 1/4 turn IN decreases pump flow rate approximately 23.5 L/min (6.23 gpm)

Do not turn adjusting cartridge more than one turn. Tighten nut (D) after adjustment. When flow adjusting cartridge (C) is turned in or out the maximum flow rate for the pump also changes. To maintain the pump's maximum flow rate, turn maximum flow adjusting screw (B) out twice as much as flow adjusting cartridge (C) is turned in; turn maximum flow adjusting screw (B) in twice as much as flow adjusting cartridge (C) is turned out.

For adjustment, see Hydraulic Pump Regulator Test and Adjustment—Maximum Flow in this group.

Minimum Flow Adjusting Screw (E):

Turning adjusting screw IN increases minimum flow rate.

Regulator Minimum Flow Adjusting Screw—Specification

Turn..... 1/4 turn IN increases minimum pump flow rate approximately 14.1 L/min (3.68 gpm)

For adjustment, see Hydraulic Pump Regulator Test and Adjustment—Minimum Flow in this group.

Do not turn adjusting more than two turns. Tighten nut (F) after adjustment.

Load Adjusting Screw (Inner Spring) (Engine Pulldown at High Pressure) (H):

Turning load adjusting screw IN increases flow rate.

9025
25
95

Tests

Regulator Load Adjusting Screw (Inner Spring) (Engine Pulldown at High Pressure)—Specification

Turn..... 1/4 turn IN increases pump flow rate approximately 5.67 L/min (1.51 gpm)

Do not turn adjusting screw more than one turn. Tighten nut (G) after adjustment.

For adjustment, see Hydraulic Pump Regulator Test and Adjustment—Engine Pulldown in this group.

Load Adjusting Cartridge (Outer Spring) (Engine Pulldown at Medium Pressure) (I):

Turning adjusting cartridge IN increases flow rate.

Regulator Load Adjusting Cartridge (Outer Spring) (Engine Pulldown at Medium Pressure)—Specification

Turn..... 1/4 turn IN increases pump flow rate approximately 23.5 L/min (6.23 gpm)

Do not turn adjusting cartridge more than one turn. Tighten nut (J) after adjustment.

For adjustment, see Hydraulic Pump Regulator Test and Adjustment—Engine Pulldown in this group.

TX,9025,GG2653 -19-21MAY98-3/3

9025
25
96

Tests

HYDRAULIC PUMP REGULATOR TEST AND ADJUSTMENT—MINIMUM FLOW

SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine Speed in Standard Mode	Fast Idle
Work Mode Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Propel Speed Switch Position	Slow Speed (Turtle)
Slow Speed Propel With Track Raised Cycle Time	33 ± 5 sec for one revolution from a running start with pump control valve pilot line disconnect

ESSENTIAL TOOLS
7/16-20 M 37° (Parker No. 03CP-4) Plug (2 used)

SERVICE EQUIPMENT AND TOOLS
JT05800 Digital Thermometer
Stop Watch
17 mm Combination Wrench
Flat Blade Screwdriver

The purpose of check is to test and adjust the minimum flow rate of pumps using the cycle time for propel as an indicator of pump flow rate.

1. Adjust the track sag for both tracks to specification. (See procedure in Group 9020-20.)
2. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
3. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification


Temperature 50 ± 5°C (120 ± 10°F)

4. Stop the engine.

9025
25
97

Tests

5. Loosen vent plug (K) to release the air pressure in hydraulic oil tank.



K—Vent Plug

Continued on next page

TX,9025,GG2655 -19-08JUN98-2/4

9025
25
98

Tests

6. Disconnect pump control valve pilot lines at rear pump regulator (A) and front pump regulator (B). Install plug (C) in lines. Leave the fittings on regulator open. Lay a shop towel over the fittings.

7. Run machine as specified.

Engine—Specification

Speed in Standard Mode Fast Idle

Work Mode—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off

HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification


Position Off

Propel Speed Switch—Specification

Position Slow Speed (Turtle)

8. Raise the left track off ground for rear pump or the right track for front pump.

9. Actuate propel function to full speed. Record the cycle time for one revolution.



T103501

- A—Rear Pump Regulator
- B—Front Pump Regulator
- C—Plugs

T103501 -UN-11SEP96

9025
25
99

Continued on next page

TX,9025,GG2655 -19-08JUN98-3/4

Tests


10. Adjust the minimum flow adjusting screw (E) as needed to obtain the specified cycle time. Turn screw in to decrease the cycle time (the minimum flow rate increases), turn screw out to increase the cycle time (the minimum flow rate decreases). Hold the screw and tighten the nut (F).

Slow Speed Propel With Track Raised—Specification

Cycle Time..... 33 ± 5 sec for one revolution from
a running start with pump control
valve pilot line disconnect

11. Repeat procedure for other pump.

Adjust regulators so cycle times are the same.



T103502

E—Minimum Flow Adjusting Screw
F—17 mm Nut

T103502 -UN-24AUG98

TX.9025.GG2655 -19-08JUN98-4/4

9025
25
100

Tests

HYDRAULIC PUMP REGULATOR TEST AND ADJUSTMENT—MAXIMUM FLOW

SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine in Standard Mode Speed	Fast Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Propel Speed Switch Position	Slow Speed (Turtle)
Track Raised—3 Revolutions From a Running Start Cycle Time	29.9 ± 2.0 sec.

SERVICE EQUIPMENT AND TOOLS
JT05800 Digital Thermometer
Stop Watch
17, 22, and 32 mm Combination Wrenches
Flat Blade Screwdriver

Purpose of check is to test and adjust the maximum flow rate of pumps so the cycle times (travel speed) for left and right propel are approximately the same.

1. Adjust track sag for both tracks to specification. (See procedure in Group 9020-20.).
2. Install temperature probe on the hydraulic oil tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
3. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

4. Run machine as specified.

Engine in Standard Mode—Specification

Speed Fast Idle

Work Mode Selector—Specification

Position Dig Mode

9025
25
101

Tests

E Mode Switch—Specification

Position..... Off

HP Mode Switch—Specification

Position..... Off

Auto-Idle Switch—Specification

Position..... Off

Propel Speed Switch—Specification

Position..... Slow Speed (Turtle)

5. Raise the left track off ground for rear pump or the right track for front pump.
6. Actuate propel function to full speed. Record cycle time for three revolutions.

Repeat procedure for the other pump.

Continued on next page

TX,9025.GG2656 -19-08JUN98-2/3

9025
25
102

Tests


7. Adjust flow adjusting cartridge (C) on front and rear pump regulators so cycle times are within the specification and are the same.

Track Raised—3 Revolutions From a Running Start—Specification

Cycle Time..... 29.9 ± 2.0 sec.

Loosen 30 mm nut (D). Turn flow adjusting cartridge (C) in to decrease the cycle time; turn flow adjusting cartridge out to increase the cycle time. Never turn flow adjusting cartridge more than one turn. Tighten 30 mm nut after adjustment.

When flow adjusting cartridge (C) is turned in or out the maximum flow rate for the pump also changes. To maintain the pump's maximum flow rate, turn maximum flow adjusting screw (B) out twice as much as flow adjusting cartridge (C) is turned in; turn maximum flow adjusting screw (B) in twice as much as flow adjusting cartridge (C) is turned out.



- A—13 mm Nut
- B—Maximum Flow Adjusting Screw
- C—Flow Adjusting Cartridge (Track Cycle Time)
- D—30 mm Nut

9025
25
103

Tests

HYDRAULIC PUMP REGULATOR TEST AND ADJUSTMENT—ENGINE PULLDOWN

SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine Fast Idle in Standard Mode Speed	2180—2205 rpm
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Propel Speed Switch Position	Slow Speed (Turtle)
Load Adjusting Cartridge (Outer Spring)—Combined Pump Engine Pulldown Speed	2070—2080 rpm at 17 235 kPa (172 bar) (2500 psi) with tracks stalled
Load Adjusting Screw (Inner Spring)—Combined Pump Engine Pulldown Speed	2070—2080 rpm at 24 130 kPa (240 bar) (3500 psi) with tracks stalled
System Relief Valve Pressure	34 325 + 1960 - 980 kPa (343 + 19.6 - 9.8 bar) (4980 + 285 - 0 psi)

ESSENTIAL TOOLS
TH108328 Adapter (2 used)
XPD34BTX (1/8 x 7/16-20 F 37°) Male Quick Coupler

SERVICE EQUIPMENT AND TOOLS
JT07290 Laptop Computer
JT07274G Excavator Diagnostics Program Disk
JT07273 Cable
JT02156A Digital Pressure and Temperature Analyzer
JT02160 Transducer 70 000 kPa (700 bar) (10 000 psi)
Gauge 70 000 kPa (700 bar) (10 000 psi)
JT05800 Digital Thermometer
JT05801 Clamp-On Electronic Tachometer
85 mm (3-3/8 in.) OD Pin or Length of Round Bar Stock (2 used)
Flat Blade Screwdriver
13, 17, 19, 27, 30 and 32 mm Combination Wrenches

Continued on next page


TX,9025,GG2661 -19-06MAY97-1/14

9025
25
104

Tests

IMPORTANT: In this procedure the pump regulators are adjusted to load the engine to rated speed so all available engine horsepower is used. Prior to performing this adjustment, proper engine performance with number two diesel fuel must be verified. The fast idle speed must be adjusted to specifications.

Pump regulators are sensitive to adjust.



1. Connect the laptop computer. (See the installation procedure in this group.)
 - a. Start the engine.
 - b. Select "3 Front pump delivery pressure" and "4 Rear pump delivery pressure" from the Monitor Data menu.

Continued on next page


TX,9025,GG2661 -19-06MAY97-2/14

9025
25
105

Tests

If laptop computer with excavator diagnostics program is not available, use the digital pressure and temperature analyzer, and transducer, or a gauges.

- a. Stop the engine.
- b. Loosen vent plug (K) to release the air pressure in hydraulic oil tank.
- c. Install adapters (A) and male quick coupler to test ports in rear (B) and front (C) pumps. Connect the analyzer and transducer or gauges.



T109340 -UN-29APR97

- 2. Install the temperature probe on the hydraulic oil tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
- 3. Install the electronic tachometer. (See JT05801 Clamp-On Electronic Tachometer Installation in this group.)
- 4. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

- 5. Check that fast idle is 2180—2205 rpm. Adjust as needed before continuing test. Record the fast idle speed.

Engine Fast Idle in Standard Mode—Specification

Speed 2180—2205 rpm

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification


Position Off

HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification

Position Off



T101614

- A—Adapter
- B—Rear Pump
- C—Front Pump
- K—Vent Plug

T101614 -UN-18JUN96

9025
25
106

Tests


Propel Speed Switch—Specification

Position Slow Speed (Turtle)

TX,9025,GG2661 -19-06MAY97-4/14

NOTE: Procedure is written using the propel functions operated over relief. Procedure will also work using dig functions over relief. Front pump—right propel or bucket function. Rear pump—left propel or swing function. Both front and rear pumps—both propel functions or arm in function.

6. Install two 85 mm (3-3/8 in.) OD pins or round bar stock between both sprockets and track frame to stall the propel motors.



T101856

D—Pin or Round Bar Stock

T101856 -UN-02JUL96

Continued on next page

TX,9025,GG2661 -19-06MAY97-5/14


9025
25
107

Tests

**7. Adjust the Load Adjusting Cartridge (Outer Spring)
(Engine Pulldown at Medium Pressure) (L):**

NOTE: The load adjusting screw (K) and load adjusting cartridge (L) are located on the end of regulator towards the engine.

- a. Loosen 13 mm nut (J) on both regulators.
- b. Turn load adjusting screws (K) out 1-1/2 turns. Tighten nuts.
- c. Loosen 30 mm nuts (M) on both regulators.
- d. Turn load adjusting cartridges (L) out 1-1/4 turns. Leave nuts loose.



T103527

T103527 -JUN-18SEP96

- J—13 mm Nut
- K—Load Adjusting Screw
- L—Load Adjusting Cartridge
- M—30 mm Nut

Continued on next page

TX,9025,GG2661 -19-06MAY97-6/14

9025
25
108


Tests

e. Adjust system relief valve (D):

- Run engine at fast idle.
- Actuate and hold both propel functions over relief.
- Loosen 32 mm nut (H). Turn second adjusting plug (G) out to obtain 17 235 kPa (172 bar) (2500 psi). Tighten nut.

f. Run engine at fast idle.

g. Actuate and hold both propel functions over relief.



T101616

- D—System Relief Valve
- E—First Adjusting Plug
- F—27 mm Nut
- G—Second Adjusting Plug
- H—32 mm Nut
- I—Piston

T101616 -UN-18JUN96

9025
25
109

Continued on next page

TX,9025,GG2661 -19-06MAY97-7/14

Tests

NOTE: Initial procedure is to adjust the load adjusting cartridges (L) to match the two pumps before making the final adjustment to get the combined pump engine pulldown at medium pressure.

Hydraulic pressure increases as the load adjusting cartridges are turned in because the pump flow is increasing.

- h. Turn the load adjusting cartridge (L) on front pump regulator in until engine speed just starts to decrease. Then, slowly turn the load adjusting cartridge out and in to verify the exact point where engine speed starts to decrease (0—10 rpm).
- i. Turn the load adjusting cartridge (L) on rear pump regulator in until engine speed just starts to decrease. Then, slowly turn the load adjusting cartridge out and in to verify the exact point where engine speed starts to decrease (0—10 rpm).
- j. Release both propel functions.


NOTE: To avoid heating the oil excessively, only operate the propel functions over relief to check the pulldown after each adjustment of cartridge.

- k. Turn both load adjusting cartridges (L) in equal amounts. Start with 1/4 turn.
- l. Actuate and hold both propel functions over relief to check that engine pulldown speed is 2070—2080 rpm. Record the rpm reading. Release propel functions.

Load Adjusting Cartridge (Outer Spring)—Combined Pump Engine Pulldown—Specification

Speed 2070—2080 rpm at 17 235 kPa
(172 bar) (2500 psi)
with tracks stalled

- m. Hold the cartridge and tighten large nut on both regulators.



T103527

- J—13 mm Nut
- K—Load Adjusting Screw
- L—Load Adjusting Cartridge
- M—30 mm Nut

T103527 -JUN-18SEP96

9025
25
110

Tests

IMPORTANT: If the load adjusting cartridge are not turned in equal amounts, the engine speed will pulldown to the specified rpm but the pump flow rates will not be equal and the machine will mistrack.

n. Check the adjustments:

- Run the engine at fast idle.
- Actuate and hold right propel function over relief. Record rpm reading. Release propel function.
- Actuate and hold left propel function over relief. Record rpm reading. Release propel function.
- The rpm reading for front and rear pumps must be within 10 rpm of each other to prevent machine from mistracking.

Continued on next page


TX,9025,GG2661 -19-06MAY97-9/14

9025
25
111

Tests

**8. Adjust the Load Adjusting Screw (Inner Spring)
(Engine Pulldown at High Pressure):**

- a. Adjust the system relief valve (D):
 - Run engine at fast idle.
 - Actuate and hold both propel functions over relief.
 - Loosen 32 mm nut (H). Turn second adjusting plug (G) in to obtain Tighten nut.
- b. Run engine at fast idle.
- c. Actuate and hold both propel functions over relief.



T101616

- D—System Relief Valve
- E—First Adjusting Plug
- F—27 mm Nut
- G—Second Adjusting Plug
- H—32 mm Nut
- I—Piston

T101616 -JUN-18JUN96

9025
25
112

Continued on next page

TX,9025,GG2661 -19-06MAY97-10/14

Tests

NOTE: Initial procedure is to adjust the load adjusting screws (K) to match the two pumps before making the final adjustment to get the combined pump engine pulldown at high pressure.

- d. Turn load adjusting screw (K) on front pump regulator in until engine speed just starts to decrease. Then, slowly turn load adjusting screw out and in to verify the exact point where the engine speed just starts to decrease (0—10 rpm).
- e. Turn load adjusting screw (K) on rear pump regulator in until engine speed just starts to decrease. Then, slowly turn load adjusting screw out and in to verify the exact point where the engine speed just starts to decrease (0—10 rpm).
- f. Release both propel functions.


NOTE: To avoid heating the oil excessively, only operate the propel function over relief to check the pulldown after each adjustment of screws

- g. Turn both load adjusting screws in equal amounts. Start with 1/4 turn.
- h. Actuate and hold both propel functions over relief to check that engine pulldown speed is 2070—2080 rpm.

Load Adjusting Screw (Inner Spring)—Combined Pump Engine Pulldown—Specification

Speed 2070—2080 rpm at 24 130 kPa
(240 bar) (3500 psi)
with tracks stalled

- i. Hold the load adjusting screw and tighten nut on both regulators.



T103527

- J—13 mm Nut
- K—Load Adjusting Screw (Inner Spring)
- L—Load Adjusting Cartridge (Outer Spring)
- M—30 mm Nut

T103527 -UN-18SEP96

9025
25
113

Continued on next page

TX,9025,GG2661 -19-06MAY97-11/14


Tests

j. Adjust the system relief valve (D) to operating pressure:

- Run the engine at fast idle.
- Actuate and hold both propel functions over relief.
- Loosen 32 mm nut (H). Turn second adjusting plug (G) in to obtain specified pressure. Tighten nut.

System Relief Valve—Specification

Pressure 34 325 + 1960 - 980 kPa
 (343 + 19.6 - 9.8 bar)
 (4980 + 285 - 0 psi)



T101616

- D—System Relief Valve
- E—First Adjusting Plug
- F—27 mm Nut
- G—Second Adjusting Plug
- H—32 mm Nut
- I—Piston

T101616 -JUN-18JUN96

Continued on next page

TX,9025,GG2661 -19-06MAY97-12/14


9025
25
114

Tests

k. Check the adjustments:

- Actuate and hold right propel function over relief. Engine pulldown must not go below 2080 rpm. If it does, turn front pump load adjusting cartridge (L) out until pulldown is 2080—2100 rpm. Record rpm reading. Release propel function.
- Actuate and hold left propel function over relief. Engine pulldown must not go below 2080 rpm. If it does, turn rear pump load adjusting cartridge (L) out until pulldown is 2080—2100 rpm. Record rpm reading. Release propel function.
- The pulldown rpm reading for front and rear pumps must be within 10 rpm of each other to prevent machine from mistracking.

l. Make final pump regulator adjustments by observing how straight the machine tracks under load.



T103527

T103527 -UN-18SEP96

- J—13 mm Nut
- K—Load Adjusting Screw (Inner Spring)
- L—Load Adjusting Cartridge (Outer Spring)
- M—30 mm Nut

9025
25
115


Continued on next page

TX,9025,GG2661 -19-06MAY97-13/14

Tests

9. Do the Final Tracking Checks:

- a. Propel machine forward on a flat area of naturally compacted soil and then on a slope of naturally compacted soil.
- b. If machine mistracks to the left on the flat area, turn the load adjusting cartridge (L) on the front pump regulator out to slow the right track.
- c. If the machine mistracks to the right under load on the slope, turn the load adjusting screw (K) on the rear pump regulator out to slow the left track.
- d. If the machine mistracks to the left under load on the slope, turn the load adjusting screw (K) on the front pump regulator out to slow the right track.



T103527

T103527 -UN-18SEP96

- J—13 mm Nut
- K—Load Adjusting Screw (Inner Spring)
- L—Load Adjusting Cartridge (Outer Spring)
- M—30 mm Nut

TX,9025,GG2661 -19-06MAY97-14/14

9025
25
116

Tests

HYDRAULIC PUMP FLOW TEST

SPECIFICATIONS	
Engine in Standard Mode Speed	2000 ± 10 rpm
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Oil Temperature	50 ± 5°C (120 ± 10°F)
One New Pump Flow Rate	193 ± 4 L/min (51 ± 1 gpm) typical at 13 790 kPa (138 bar) (2000 psi) and 2000 ± 10 rpm
One New Pump Flow Rate	155 ± 4 L/min (41 ± 1 gpm) typical at 20 685 kPa (207 bar) (3000 psi) and 2000 ± 10 rpm
One Used Pump Flow Rate	162 ± 15 L/min (43 ± 4 gpm) minimum at 13 790 kPa (138 bar) (2000 psi) and 2000 ± 10 rpm
One Used Pump Flow Rate	128 ± 15 L/min (34 ± 4 gpm) minimum at 20 685 kPa (207 bar) (3000 psi) and 2000 ± 10 rpm

ESSENTIAL TOOLS
TH108328 Adapter (2 used)
TH108325 (1 M BSPP ORB x —16 M ORFS) Elbow
JT03410 (SAE Code 62 Split Flange High Pressure 1 SF x 1-5/16-12 M 37°) 90° Flange Fitting (2 used)
JT03452 Split Flange Connector Plate Kit
202862 (3/4-16 M 37° x 3/4-16 F 37° Sw x 7/16-20 M 37°) Tee (2 used)
JT05484 (7/16-20 F 37°) (Parker No. 06CP-4) Cap (2 used)

SERVICE EQUIPMENT AND TOOLS
Flow Meter
JT07290 Laptop Computer
JT07274G Excavator Diagnostics Program Disk
JT07273 Cable
Gauge 70 000 kPa (700 bar) (10 000 psi) (2 used)
JT05800 Digital Thermometer
JT05801 Clamp-On Electronic Tachometer


9025
25
117

Tests

Test is used to determine pump condition and should be performed only if a comparison of actual machine cycle times to specified cycle times indicates low pump flow.

TX.9025.GG2662 -19-08JUN98-2/5


1. Stop the engine.
2. Loosen vent plug (K) to release the air pressure in hydraulic oil tank.

**K—Vent Plug**

Continued on next page

TX.9025.GG2662 -19-08JUN98-3/5

Tests



T103554

A—Pilot Pressure Inlet Line
 B—202862 Tee (2 used)
 C—JT05484 Cap
 D—Test Port

E—Pump Control Valve Pilot Lines
 F—Front and Rear Pump Regulator Valves
 G—TH108328 Adapter

H—TH108325 Elbow
 I—Return Manifold
 J—Bulkhead
 K—Front Pump Outlet Port
 L—Rear Pump Outlet Port

M—JT03410 90° Flange Fitting

3. Connect the flow meter using 90° flange fitting (M). If available, connect a flow meter to front (K) and rear (L) pumps.

Connect the return hose from flow meter to the return manifold (I). Install plates, from the split flange connector plate kit, on end of hoses to control valve.

To monitor pump delivery pressure, use the pressure gauge on flow meter, or install adapters (G) and gauges to test ports (D) in pump housing, or use the laptop computer.

4. Disconnect pilot pressure inlet line (A) at pilot filter. Install tees (B). Connect pilot pressure inlet line to tee.

Tests

Disconnect the two pump control valve pilot lines (E) at bulkhead (J) on hydraulic oil tank. Connect the pilot lines to the tees installed at pilot filter. Install caps (C) on fittings at bulkhead.

NOTE: Pilot pressure is routed to the pump regulator valves so the pumps operate at maximum displacement.

5. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
6. Install the tachometer. (See JT05801 Clamp-On Electronic Tachometer Installation in this group.)
7. Check that the flow meter loading valve is open.
8. Operate the machine at specification.

Engine in Standard Mode—Specification

Speed..... 2000 ± 10 rpm

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off

HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification

Position Off

9. Heat the hydraulic oil to the specified temperature by closing flow meter loading valve to increase pressure to 20 685 kPa (207 bar) (3000 psi).

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

10. Adjust the flow meter loading valve to obtain the specified test pressures. Adjust engine speed to specified rpm. Record pump flow at each pressure.

If pump flow in low, repair or replace pump.

One New Pump—Specification

Flow Rate..... 193 ± 4 L/min (51 ± 1 gpm)
 typical at 13 790 kPa (138 bar)
 (2000 psi) and 2000 ± 10 rpm
 Flow Rate..... 155 ± 4 L/min (41 ± 1 gpm)
 typical at 20 685 kPa (207 bar)
 (3000 psi) and 2000 ± 10 rpm

One Used Pump—Specification

Flow Rate..... 162 ± 15 L/min (43 ± 4 gpm)
 minimum at 13 790 kPa
 (138 bar) (2000 psi) and
 2000 ± 10 rpm
 Flow Rate..... 128 ± 15 L/min (34 ± 4 gpm)
 minimum at 20 685 kPa
 (207 bar) (3000 psi) and
 2000 ± 10 rpm

9025
25
120

Tests

PILOT PUMP FLOW TEST

SPECIFICATIONS	
Oil Temperature	50 ± 6°C (120 ± 10°F)
Engine in Standard Mode Speed	2000 rpm
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Pilot Pump Flow Rate	25.0 L/min (6.6 gpm) at 3925 kPa (39 bar) (570 psi) and 2000 rpm

SERVICE EQUIPMENT AND TOOLS
Flow Meter
JT05800 Digital Thermometer
JT05801 Clamp-On Electronic Tachometer


Test will determine the condition of pilot pump. The pump is driven at engine speed. Inspect pilot filter and suction screen for indications of hydraulic system problems.

TX,9025,GG2663 -19-08JUN98-1/4

9025
25
121

1. Stop the engine.

Loosen vent plug (K) to release the air pressure in hydraulic oil tank.



K—Vent Plug

Continued on next page

TX,9025,GG2663 -19-08JUN98-2/4

Tests

2. Connect flow meter in series with pilot pressure inlet line (A) at pilot filter (B).

Open the flow meter loading valve.

3. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
4. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification


Temperature 50 ± 6°C (120 ± 10°F)

NOTE: The pilot pressure regulating valve will regulate pump discharge pressure. It is not necessary to load the pump using flow meter loading valve.

5. Run engine at test specifications. Record flow meter reading.

If pressure is low, check the pilot pressure regulating valve.

If flow is low, check inlet hose to pump for restriction. If there is no restriction, replace pump.



T103571

A—Pilot Pressure Inlet Line
B—Pilot Filter

T103571 -UN-11SEP96

Engine in Standard Mode—Specification

Speed 2000 rpm

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off

HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification

Position Off

9025
25
122

Tests

Pilot Pump—Specification

Flow Rate 25.0 L/min (6.6 gpm) at 3925 kPa
(39 bar) (570 psi) and 2000 rpm

TX,9025,GG2663 -19-08JUN98-4/4

9025
25
123

Tests

PROPEL SYSTEM TRACKING TEST

SPECIFICATIONS	
Engine in Standard Mode Speed	Fast Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Oil Temperature	50 ± 5°C (120 ± 10°F)
Mistrack at 20 m (65 ft) Distance	200 mm (7-7/8 in.) or less

SERVICE EQUIPMENT AND TOOLS
Tape Measure
JT05800 Digital Thermometer
JT02156A Digital Pressure and Temperature Analyzer

Test is used to check the overall condition of the propel system from the hydraulic pumps to the propel motors.

1. Lay out a course on a hard flat surface that is 20 m (65 ft) in length plus an additional 3—5 m (10—15 ft) at each end for acceleration and deceleration. Mark a straight line the length of course.
2. Adjust the track sag so both sides are equal and within specification before doing test. (See Adjust Track Sag in Group 9020-20.)

Engine in Standard Mode—Specification

Speed Fast Idle

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off

HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification

Position Off

9025
25
124

Tests

3. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
4. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

5. Lower the boom so bucket is approximately 300—500 mm (12—20 in.) off the ground with the arm retracted and the bucket curled.
6. Start propelling with the machine at the end of course and the tracks aligned with the straight line. Actuate the propel pilot controller to full stroke.

TX,9025,GG2664 -19-08JUN98-2/3

9025
25
125


7. Measure the amount of mistrack from the straight line to the track at the 20 m (65 ft) mark. The amount of mistrack has a tendency to be less if done on a concrete surface.

Mistrack at 20 m (65 ft)—Specification

Distance..... 200 mm (7-7/8 in.) or less

Turn the upperstructure 180 degrees and repeat procedure for reverse propel.

T6998AS (CY)



T6998AS -UN-23MAR89

TX,9025,GG2664 -19-08JUN98-3/3

Tests

CYLINDER DRIFT TEST—BOOM, ARM, AND BUCKET

SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10°F)
Engine in Standard Mode Speed	Off
Arm Length	2.96 (9 ft 9 in.)
Bucket Capacity	1.0 m ³ (1.38 yd ³)
Bucket Load Weight	1315 kg (2900 lb)
Arm Cylinder Length	50 mm (2.00 in.) approximate extension
Bucket Cylinder Length	50 mm (2.00 in.) approximate retraction
Boom Cylinder Height	Bucket pivot pin at the same height as boom-to-main frame pin
Engine Speed	Off
Arm Cylinder Drift	20 mm (13/16 in.) maximum allowable for 5 minutes
Bucket Cylinder Drift	20 mm (13/16 in.) maximum allowable for 5 minutes
Boom Cylinder Drift	20 mm (13/16 in.) maximum allowable for 5 minutes
Bottom of Bucket to Ground Drift	150 mm (6 in.) maximum allowable for 5 minutes

SERVICE EQUIPMENT AND TOOLS	
JT05800 Digital Thermometer	
Tape Measure	

Procedure is used to check the leakage past the cylinder piston seals, control valve spools, circuit relief valves, boom reduced leakage valve, and arm reduced leakage valve.

1. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
2. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification

Temperature 50 ± 5°C (120 ± 10°F)

9025
25
126

Tests

Engine in Standard Mode—Specification

Speed Off

3. Fill the bucket to get the specified bucket load with the standard arm and bucket.

Arm—Specification

Length..... 2.96 (9 ft 9 in.)

Bucket—Specification

Capacity..... 1.0 m³ (1.38 yd³)

Bucket Load—Specification

Weight..... 1315 kg (2900 lb)

Continued on next page

TX,9025,GG2665 -19-09MAY97-2/3

9025
25
127

Tests

- Position arm cylinder so rod is extended the specified length from the retracted position.


Arm Cylinder—Specification

Length..... 50 mm (2.00 in.) approximate extension

- Position bucket cylinder so rod is retracted the specified length from the extended position.

Bucket Cylinder—Specification

Length..... 50 mm (2.00 in.) approximate retraction



T6904AG -UN-06DEC88

- Position the boom cylinders so bucket pivot pin is at the same height as the boom-to-main frame pin.

Boom Cylinder—Specification

Height Bucket pivot pin at the same height as boom-to-main frame pin

- Stop the engine.

Engine—Specification

Speed Off

- After 5 minutes, measure the amount of movement for boom, arm and bucket cylinders and from bottom of bucket to the ground.

Arm Cylinder—Specification

Drift 20 mm (13/16 in.) maximum allowable for 5 minutes

Bucket Cylinder—Specification

Drift 20 mm (13/16 in.) maximum allowable for 5 minutes

Boom Cylinder—Specification

Drift 20 mm (13/16 in.) maximum allowable for 5 minutes

Bottom of Bucket to Ground—Specification

Drift 150 mm (6 in.) maximum allowable for 5 minutes

9025
25
128

Tests

SWING MOTOR LEAKAGE TEST

SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10° F)
Engine in Standard Mode Speed	Fast Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Swing Motor Leakage	0.2—1.0 L/min (0.05—0.26 gpm) new acceptable while swinging
Swing Motor Leakage	2 L/min (0.53 gpm) used maximum acceptable while swinging
Swing Motor Leakage	8 L/min (2.2 gpm) new acceptable while stalled
Swing Motor Leakage	16 L/min (4.2 gpm) used maximum acceptable while stalled

ESSENTIAL TOOLS
JT03023 (9/16-18 F 37°) (Parker No. 06CP-6) Cap

SERVICE EQUIPMENT AND TOOLS
JT05800 Digital Thermometer
Calibrated Container

The purpose of test is to check the efficiency of swing motor. Leakage can occur between the cylinder block and valve plate and the slippers and swash plate when parts are worn or damaged. The motor must be checked in more than one position in order to check all pistons and the circumference of valve plate and cylinder block.

1. Install the temperature probe on the hydraulic tank-to-pump suction line. (See JT05800 Digital Thermometer Installation in this group.)
2. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification


Temperature 50 ± 5°C (120 ± 10° F)

3. Stop the engine.

9025
25
129

Tests

4. Loosen vent plug (K) to release the air pressure in hydraulic oil tank.



K—Vent Plug

Continued on next page

TX,9025,GG2666 -19-08JUN98-2/4

9025
25
130

Tests

5. Disconnect drain line (A) from return manifold. Install a cap on elbow. Put drain line in a calibrated container.

CAUTION: To avoid personnel injury, clear area of all bystanders before doing test. Slowly swing through one complete revolution to ensure that the area is clear of objects before doing test.

6. Raise and lower boom to pressurize hydraulic oil tank.

7. Operate swing function for one minute. Compare amount of leakage to specifications. Repeat for swing in opposite direction.

Engine in Standard Mode—Specification

Speed Fast Idle

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off

HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification


Position Off

Swing Motor—Specification

Leakage 0.2—1.0 L/min (0.05—0.26 gpm)
new acceptable while swinging

Leakage 2 L/min (0.53 gpm) used
maximum acceptable while swinging

8. Operate swing function at stall for one minute. Put the bucket against an immovable object or in a trench then hold swing control lever fully actuated to stall swing function. Compare the amount of leakage to specifications.



T101868

A—Swing Motor Drain Line
B—Cap

T101868 -JUN-10JUL96

9025
25
131

Tests

Swing Motor—Specification

Leakage 8 L/min (2.2 gpm) new
 acceptable while stalled

Leakage 16 L/min (4.2 gpm) used
 maximum acceptable while
 stalled

Repeat procedure by stalling the motor in several position
 and then take an average of the readings.

Repeat procedure in the opposite direction.

9. If leakage is greater than the maximum specified,
 repair or replace swing motor.

10. Connect drain line to return manifold.

TX,9025.GG2666 -19-08JUN98-4/4

9025
 25
 132

Tests

PROPEL MOTOR LEAKAGE TEST

SPECIFICATIONS	
Oil Temperature	50 ± 5°C (120 ± 10° F)
Engine in Standard Mode Speed	Fast Idle
Work Mode Selector Position	Dig Mode
E Mode Switch Position	Off
HP Mode Switch Position	Off
Auto-Idle Switch Position	Off
Propel Speed Switch Position	Slow Speed (Turtle)
Propel Motor Leakage	1.5—2.0 L/min (0.4—0.53 gpm) new acceptable while propelling with track raised
Propel Motor Leakage	3.4 L/min (0.80 gpm) used maximum acceptable while propelling with track raised
Propel Motor Leakage	1.5—4.8 L/min (0.40—1.20 gpm) new acceptable while stalled
Propel Motor Leakage	5.2 L/min (1.40 gpm) used maximum acceptable while stalled

ESSENTIAL TOOLS	
JT03025 (3/4-16 F 37°) (Parker No. 06CP—8) Cap	
JT03221 (3/4-16 M 37°) (Parker No. 03CP—8) Plug	

SERVICE EQUIPMENT AND TOOLS	
JT05800 Digital Thermometer	
Calibrated Container	
85 mm (3-3/8 in.) OD Pin or Round Bar Stock (2 used)	

1. Stop the engine.
2. Heat hydraulic oil to the specified temperature. (See Hydraulic System Warm-Up Procedure in this group.)

Oil—Specification


Temperature 50 ± 5°C (120 ± 10° F)

3. Stop the engine.

9025
25
133

Tests

4. Loosen vent plug (K) to release the air pressure in hydraulic oil tank.



K—Vent Plug

Continued on next page

TX,9025,GG2667 -19-09MAY97-2/5

9025
25
134

Tests

5. Disconnect the drain line (A) at return manifold. Put line in a calibrated container (D). Install a cap (B) on the open fitting (C).
6. Raise track off the ground for side being checked.
7. Run machine at specifications.

Engine in Standard Mode—Specification

Speed Fast Idle

Work Mode Selector—Specification

Position Dig Mode

E Mode Switch—Specification

Position Off

HP Mode Switch—Specification

Position Off

Auto-Idle Switch—Specification

Position Off

Propel Speed Switch—Specification

Position Slow Speed (Turtle)

8. For propel motor being checked, actuate propel forward function at full speed for one minute. Record amount of leakage. Repeat procedure for reverse.


If leakage is more than specification, repair or replace motor.

Propel Motor—Specification


Leakage 1.5—2.0 L/min (0.4—0.53 gpm)
new acceptable while propelling
with track raised

Leakage 3.4 L/min (0.80 gpm) used
maximum acceptable while
propelling with track raised

If leakage is substantially more in one direction than the other, a seal in the rotary manifold may be leaking. To isolate leakage to the propel motor or rotary manifold, check leakage at the propel motor.



T7660BE



- A—Propel Motor Drain Line
- B—Cap
- C—Fitting
- D—Calibrated Container

T7660BE -UN-11DEC91

T6876FG -UN-06DEC88

9025
25
135

Tests


9. To check propel motor for leakage at stall, install pins or round bar stock (D) between the sprockets and track frame.

Propel Motor—Specification

Leakage	1.5—4.8 L/min (0.40—1.20 gpm) new acceptable while stalled
Leakage	5.2 L/min (1.40 gpm) used maximum acceptable while stalled

Actuate propel pedal for function being checked to full stroke for one minute. Record the amount of leakage. Repeat procedure by stalling the motor in several positions and then take an average of readings.

Repeat procedure for the opposite direction.




A—Pin or Round Bar Stock

T101856 -UN-02JUL96

TX,9025,GG2667 -19-09MAY97-4/5

10. To check leakage at the propel motor, disconnect drain line (A) at propel motor. Install JT03221 Plug in the line. Connect a line to fitting on motor. Put line in a calibrated container.

Repeat Steps 7 and 8. If leakage is more than specification, repair or replace motor. If leakage is within specification, repair or replace rotary manifold.



A—Propel Motor Drain Line

T7915BB -UN-11JAN93

TX,9025,GG2667 -19-09MAY97-5/5

Tests

**BOOM CYLINDER CONTROLLED LOAD
LOWERING VALVE TEST**

SPECIFICATIONS

Circuit Relief Pressure	5400 psi
-------------------------	----------

SERVICE EQUIPMENT AND TOOLS

Gauge 70000 kPa (700 bar) (10000 psi)
AT126362 T-fitting


Test is used to measure circuit relief pressure at the load lowering valves.

Continued on next page

CED,OUOE020,73 -19-26MAY99-1/2

9025
25
137

Tests



T121085

T121085 -UN-27MAY99

9025
25
138

- A—Pressure Port
- B—Pilot Hose
- C—Pressure Relief Valve
Adjusting Screw and
Jam Nut

1. Connect a pressure gauge and T-fitting between both load lowering valves at pressure port (A).
2. Place a heavy load on the bucket.
3. Extend the boom arm all the way out.
4. Disconnect and plug pilot hose (B).
5. Move boom lever to the down position to force the load lowering valve over relief.
6. Record the relief pressure reading.
7. If circuit relief pressure is below specifications, the circuit relief valves need to be reset.
 - a. Loosen the jam nut (C) on the circuit relief valve.
 - b. Turn adjusting screw (C) in to increase circuit relief pressure.
 - c. Hold adjusting screw and then tighten the jam nut.
8. Check the pressure setting again.


Circuit Relief—Specification

Pressure..... 37232 kPa (372 bar) (5400 psi)

Tests

HOSE REEL TEST

Connect a pressure gauge between both hoses of the hose reel. Turn the micro switch located behind the cab to the ON position and set the flow regulator to maximum flow. The pressure at the gauge should be 2000 psi. If the pressure is lower than 2000 psi.



T121689

A—Male Hose End
B—Female Hose End

CED,OUOE020,77 -19-04JUN99-1/1

9025
25
139

CHAPTER 7

SECTION 9031

AIR CONDITIONING SYSTEM

BLANK

Group 05 Theory of Operation

PROPER REFRIGERANT HANDLING

The U.S. Environmental Protection Agency prohibits discharge of any refrigerant into the atmosphere, and requires that refrigerant be recovered using the approved recovery equipment.

IMPORTANT: To meet government standards relating to the use of refrigerants, R134a is used in the air conditioning system. Because it does not contain chlorine, R134a is not detrimental to the ozone in the atmosphere. However, it is illegal to discharge any refrigerant into the atmosphere.

It must be recovered using the appropriate recovery stations.

IMPORTANT: Use correct refrigerant recovery, recycling and charging stations. **DO NOT** mix refrigerants, hoses, fittings, components or refrigerant oils.

Recovery, recycling and charging stations for R12 and R134a refrigerants **MUST NOT** be interchanged. Systems containing R12 refrigerant use a different oil than systems using R134a. Certain seals are not compatible with both types of refrigerants.

TX,9031,UU3135 -19-13AUG96-1/1

R134A REFRIGERANT CAUTIONS



CAUTION: DO NOT allow liquid refrigerant to contact eyes or skin. Liquid refrigerant will freeze eyes or skin on contact. Wear goggles, gloves and protective clothing.

If liquid refrigerant contacts eyes or skin, **DO NOT** rub the area. Splash large amounts of **COOL** water on affected area. Go to a physician or hospital immediately for treatment.

DO NOT allow refrigerant to contact open flames or very hot surfaces such as electric welding arc, electric heating element and lighted smoking materials.

DO NOT heat refrigerant over 52°C (125°F) in a closed container. Heated refrigerant will develop high pressure which can burst the container.

Keep refrigerant containers away from heat sources. Store refrigerant in a cool place.

DO NOT handle damp refrigerant container with your bare hands. Skin may freeze to container. Wear gloves.

If skin freezes to container, pour **COOL** water over container to free the skin. Go to a physician or hospital immediately for treatment.


(R12 ONLY) Refrigerant exposed to high temperature forms phosgene gas. Inhaling toxic phosgene gas may result in serious illness or death. Phosgene gas has an odor like new mown hay or green corn. If you inhale phosgene gas, go to a physician or hospital immediately for treatment.

9031
05
1

TX,9031,UU3136 -19-13AUG96-1/1

Theory of Operation

REFRIGERANT THEORY OF OPERATION



T118692

T118692 -19-30NOV98

- | | | | |
|--|---------------------|-----------------------------|----------------------------------|
| A—B27 A/C High and Low Pressure Switch | E—Condenser | J—Expansion Valve | N—M6 A/C and Heater Blower Motor |
| B—Receiver/Dryer | F—High Pressure Gas | K—Not Used | |
| C—High Pressure Liquid | G—Compressor | L—Low Pressure Liquid | |
| D—Engine Fan | H—Low Pressure Gas | M—B29 A/C Heater Thermistor | |
| | I—Evaporator | | |

The compressor (G) draws low pressure gas (H) from the evaporator (I) and compresses it into high pressure gas (F). This causes the temperature of the refrigerant to rise higher than that of the outside air.

High pressure gas leaves the compressor and is sensed by the high pressure part of the B27 A/C high and low pressure switch (A). The switch monitors refrigerant pressure. If the pressure becomes too high, the switch will open and stop the compressor, interrupting the cycle.

As the high pressure gas flows through the condenser (E), heat is removed and transferred to the outside air being drawn through the condenser core by the

condenser fan (D). Cooling the refrigerant causes it to condense and it leaves the condenser as a high pressure liquid (C). The high pressure liquid flows into the receiver-dryer (B) where moisture and contaminants (acid, solids, etc.) are removed. The receiver-dryer also acts as a reservoir for refrigerant.

The refrigerant flows from the receiver-dryer to the expansion valve (J) and is sensed by the low pressure part of the B27 A/C high and lower pressure switch (A). The switch monitors refrigerant pressure. If the pressure becomes too low from refrigerant loss, the switch will open and stop the compressor, interrupting the cycle.

9031
05
2

Theory of Operation

The actual cooling and drying of cab air takes place at the evaporator. Flow of the high pressure liquid refrigerant is controlled by the expansion valve. The expansion valve causes the temperature and pressure of the refrigerant to drop, where it becomes a low pressure liquid (L). The expansion valve is a valve that uses a variable orifice to control the flow of high pressure liquid refrigerant into the evaporator to maintain a constant pressure and temperature.

The M6 A/C and heater blower motor (N) pulls a mixture of warm cab and outside air through the evaporator where it is cooled by the refrigerant. The heat absorbed by the evaporator causes the refrigerant to vaporize into a low pressure gas.

A freeze control switch (M) senses temperature of the evaporator coil through a refrigerant filled capillary

tube. The switch closes when the evaporator is above the switch setting and opens when the evaporator is cooled to the switch setting. The switch has a low temperature setting that prevents the evaporator from becoming cold enough to freeze moisture that condenses on the coil.

The B28 A/C and heater thermistor senses temperature of the evaporator coil through a refrigerant filled capillary tube.

The moisture, from the warm air, is condensed as it contacts the cool evaporator coil during the cooling process and is drained away through drain tubes connected to the drain pan under the evaporator. With the cab air cooled and dehumidified, the refrigerant cycle is complete.

TX,9031,UU3137 -19-13AUG96-2/2

HEATER AND AIR CONDITIONER CIRCUIT OPERATIONAL INFORMATION

The following conditions must exist for air conditioning circuit to function:

- Key switch ON
- Machine running
- Air conditioning switch turned ON
- Any of the four blower motor On speeds selected on air conditioner controller

9031
05
3

TX,9031,UU3138 -19-13AUG96-1/1

*Theory of Operation***HEATER AND AIR CONDITIONER CIRCUIT THEORY OF OPERATION**

Power flows from the A/C Controller and Relays 5 amp Fuse to the air conditioner controller and energizes the following relays:

- A/C compressor clutch relay (K25)
- A/C blower motor (medium low speed) relay (K26)
- A/C blower motor (medium speed) relay (K27)
- A/C blower motor (high speed) relay (K28)
- A/C blower motor and main power (low speed) relay (K24)

Power from the blower motor 20 amp fuse is applied to terminal 1 of the A/C compressor clutch relay (K25).

Power from the 20 amp fuse also goes through the A/C blower motor and main power (low speed) relay to operate the A/C and heater blower motor (M6).

The air conditioner controller (A3) operates the blower motor in four different speeds:

- Low speed
- Medium low speed
- Medium speed
- High speed

When any of the first three speeds is selected, power flows through the dropping resistor block (R11) and then to the blower motor. When the high speed is

selected, the resistor block is bypassed and the blower motor operates at maximum speed.

With air conditioning switch turned ON in the air conditioner controller, power flows to the A/C high and low pressure switch (B27). The switch (B27) contains both a low pressure switch and a high pressure switch. With low pressure switch closed, power flows through high pressure switch. With high pressure switch closed, power flows through the A/C compressor clutch relay (K25) to operate the A/C compressor clutch (Y1).

The low pressure switch opens if the air conditioning system loses its refrigerant charge. The switch opens to stop current flow to the compressor, which prevents compressor engagement.

The high pressure switch protects the system from high pressure. If a malfunction or line restriction causes the high pressure to increase above the setting of the switch, will open to stop current flow to the compressor clutch.

The A/C and heater thermistor (B29) is used to sense the temperature in the evaporator core. When the temperature in the evaporator core raises, the blower thermistor senses the warmer temperature and the air conditioner controller applies voltage to the compressor.

FOLDOUT PAGE 7-5 IS AT REAR OF MANUAL

*Theory of Operation***HEATER CIRCUIT (MACHINES WITHOUT AIR CONDITIONER) OPERATIONAL INFORMATION**

The key switch must be in the ACC or On position for the heater circuit to function.

CED,OUTX782,3 -19-18NOV98-1/1

HEATER CIRCUIT (MACHINES WITHOUT AIR CONDITIONER) THEORY OF OPERATION

Power from the F13 Blower Motor 20 amp Fuse is applied to the plus (+) terminal of the S4 Heater Blower Motor Switch. On machines equipped with air conditioner, power is also applied to the X16 Air Conditioner Harness to Cab Harness Connector.


Power from the blower motor switch is applied through R2 Heater Blower Motor Dropping Resistor Block. The resistor block applies different voltages to the motor, depending on the blower speed selected. For low speed, power is applied through the maximum resistance, resulting in the lowest voltage. For high speed, the resistors are bypassed and full voltage is applied to the motor. Motor ground is applied to the minus (-) motor terminal.

CED,OUTX782,4 -19-18NOV98-1/1

9031
05
6

Theory of Operation

HEATER CIRCUIT (MACHINES WITHOUT AIR CONDITIONER) FUNCTIONAL SCHEMATIC



9031
05
7

HEATER CIRCUIT (MACHINES WITHOUT AIR CONDITIONER)

T117937

T117937 -19-18NOV98

CED, TX02661, 251 -19-04NOV98-1/1

Theory of Operation

RECEIVER/DRYER OPERATION


The receiver/dryer is a reservoir to store excess liquid refrigerant in the system. Excess refrigerant is required for two reasons:

Outside air temperature and humidity have an effect on the minimum quantity of refrigerant required in the system for the air conditioner to operate at maximum efficiency. The higher the temperature and humidity, the more refrigerant required in the system. More refrigerant is required due to the expansion valve opening farther allowing more refrigerant into the low pressure side of the system.

Refrigerant hoses allow a small amount of refrigerant to migrate through their walls. Extra refrigerant stored in the system allows for a longer period of time before additional refrigerant is needed.


The receiver/dryer also contains two filters (E) and desiccant (F) between the filters. The filters remove solid materials which could be generated by a compressor failure, debris left in the system due to improper service procedures, or particles caused by corrosion of metal parts due to moisture and acids in the system (also caused by improper service procedures).

Desiccant is used to absorb moisture. If too much moisture gets into the system, the desiccant may not be able to absorb it all. When moisture is combined with refrigerant oil, a sludge is formed. This sludge does not permit moving parts to be adequately lubricated. When moisture is combined with refrigerant, hydrofluoric and hydrochloric acids are formed. These acids are very corrosive to metal surfaces and leakage will eventually develop. If the air conditioning system is left open for a period of time or if the plugs are removed from the receiver/dryer, the desiccant will also absorb moisture from the air. The receiver/dryer contains a color moisture indicator. (Blue) indicates dryer is dry. (Pink) indicates moisture in the desiccant. Evacuating the system will not remove moisture from the desiccant. You must replace the receiver/dryer.



T8104AE (CV)

T8104AE -UN-19OCT93



T8104AF (CV)

T8104AF -UN-10JAN94

- A—Inlet Port
- B—Sight Glass
- C—Outlet Port
- D—Pickup Tube
- E—Filter
- F—Desiccant
- G—Strainer
- H—Spring
- I—Receiver/Dryer
- J—Wet/Dry Indicator

9031
05
8

Theory of Operation

A sight glass is installed in the receiver/dryer outlet port. If the refrigerant level is low, a steady stream of gas bubbles will be present in the liquid flowing from the receiver/dryer. These gas bubbles can be seen in the sight glass and are an indication that the system needs charging. However, bubbles may be present when the compressor clutch first engages but must disappear after a few seconds. If the sight glass is clear, the system either has a sufficient charge or is completely discharged.

TX,9031,UU3144 -19-13AUG96-2/2

COMPRESSOR RELIEF VALVE OPERATION

The compressor relief valve is a direct acting pressure limiting valve. If a malfunction in the system occurs that would cause high pressure, such as a restricted line, the valve will open near 4137 kPa (41.4 bar) (600 psi) and remain open until pressure drops to below the valve setting.

If the relief valve opens, a loud popping noise will be heard. Some oil may also be lost from the system. Correct any condition that would cause the valve to open.

TX,9031,UU3146 -19-13AUG96-1/1

TEMPERATURE CONTROL

Temperature control is adjusted by the position of the heater temperature switch in the cab. This switch is mechanically connected to the water valve at the base of the heater core. Turning the heater temperature switch towards maximum and/or towards off opens and closes the water valve controlling engine coolant flow through the heater core, thus controlling the temperature inside the cab.

In certain conditions when the air conditioning switch is turned on and the blower switch is in low position, the cab temperature may still be too cool. It may be necessary to blend heat with cooling to get a comfortable cab temperature.

TX,9031,UU3147 -19-13AUG96-1/1

9031
05
9

Group 10 System Operational Checks

AIR CONDITIONING OPERATIONAL CHECKS

This procedure is designed so the mechanic can make a quick check of the system using a minimum amount of diagnostic equipment. If you need additional information, read Theory of Operation (Group 9031-05).

The engine or other major components must be at operating temperature for some checks.

Locate system check in the left column and read completely, following this sequence from left to right. Read each check completely before performing.

At the end of each check, if no problem is found, that check is complete. When a problem is indicated,

additional checks or repair information will be given. The technical manual group number required for repair will be given. If verification is needed, you will be given next best source of information:

Group: 10 (System Operational Checks)

Group: 15 (Diagnostic Information)

Group: 20 (Adjustments)

Group: 25 (Tests)

TX.9031.UU3148 -19-13AUG96-1/1

① VISUAL INSPECTION OF COMPONENTS

9031
10
1

--1/1

<p>ALL LINES AND HOSES</p>	<p>Engine OFF.</p> <p>Inspect all lines and hoses.</p> <p>Are lines and hoses straight, NOT kinked or worn from rubbing on other machine parts or "weather checked"?</p> <p>Are hose and line connections clean NOT showing signs of leakage, such as oil or dust accumulation at fittings?</p> <p>All hose and line clamps must be in place and tight. Clamps must have rubber inserts or cushions in place to prevent clamps from crushing or wearing into hoses or lines?</p>	<p>YES: Check complete.</p> <p>NO: Reposition hoses or lines and tighten or replace clamps. Tighten fittings or replace O-rings in fittings. Replace hoses or lines as required.</p>
-----------------------------------	--	--

--1/1

System Operational Checks

<p>CONDENSER CHECK</p>	<p>Engine OFF.</p> <p>Inspect condenser cores.</p> <p>Is condenser core free of dirt or debris?</p> <p>Does condenser show signs of leakage, dust accumulation or oily areas?</p> <p>Are condenser fins straight, not bent or damaged?</p> <p>Inspect engine fan.</p> <p>Are fan blades in good condition, not worn, bent, broken or missing?</p>	<p>YES: Check complete.</p> <p>NO: Clean, repair or replace condenser core. Replace engine fan.</p> <p style="text-align: right;">-- -1/1</p>
-------------------------------	---	---

<p>EVAPORATOR CORE CHECK</p>	<p>Engine OFF.</p> <p>Inspect core.</p> <p>Are fins straight?</p> <p>Is evaporator core free of dirt and debris?</p>	<p>YES: Check complete.</p> <p>NO: Repair, replace or clean evaporator.</p> <p style="text-align: right;">-- -1/1</p>
-------------------------------------	--	---

<p>AIR CONDITIONER COMPRESSOR CHECK</p>	<p>Engine OFF.</p> <p>Inspect compressor.</p> <p>Is compressor drive belt tight? Is belt in good condition? Is belt tightening strap straight?</p> <p>Is compressor belt pulley in good condition?</p> <p>Are compressor to bracket and bracket to engine mounting cap screws tight?</p> <p>Is compressor pulley aligned with engine pulley?</p> <p>Are electrical connections to compressor clutch clean and tight? Is wiring to compressor in good condition?</p>	<p>YES: Go to next check.</p> <p>NO: Repair or replace components as required.</p> <p style="text-align: right;">-- -1/1</p>
--	---	--


9031
10
2

System Operational Checks

<p>CAB DOOR AND WINDOW SEALS CHECK</p>	<p>Open and close door and windows. Inspect seals.</p> <p>Do door and windows contact seals evenly?</p> <p>Are seals in position and in good condition?</p>	<p>YES: Check complete.</p> <p>NO: Adjust door and windows to close against seals properly. Replace seals as necessary.</p> <p style="text-align: right;">-- -1/1</p>
---	---	---


SYSTEM OPERATING CHECKS

-- -1/1


<p>BLOWER MOTOR CHECK</p>	 <p>T103130 T103130 -19-29AUG96</p> <p>Engine OFF. Key switch ON.</p> <p>Press blower motor switch to select each of the four speeds.</p> <p>Does fan operate in four speeds?</p> <p>Does air exit from ducts?</p>	<p>YES: Check complete.</p> <p>NO: See Circuit Checks in Group 9031-10. Check wiring harness.</p> <p style="text-align: right;">-- -1/1</p>
----------------------------------	--	---

9031
10
3

System Operational Checks

<p>HEATER</p>	 <p>T103130 T103130 -19-29AUG96</p> <p>Start engine and allow to warm several minutes.</p> <p>Press heater temperature switch to maximum heat position. Press blower switch to high speed position.</p> <p>Does warm air exit from ducts?</p>	<p>YES: Check complete.</p> <p>NO: See Circuit Checks in Group 9031-10. Check wiring harness.</p>
----------------------	--	---

-- -1/1

<p>AIR CONDITIONER (IF EQUIPPED)</p>	 <p>T103130 T103130 -19-29AUG96</p> <p>Start engine and run at fast idle.</p> <p>Press air conditioner switch to ON position.</p> <p>Press blower switch to high speed position.</p> <p>Wait for any warm air in duct system to dissipate.</p> <p>Is air from ducts cool?</p>	<p>YES: Check complete.</p> <p>NO: See Blower/Air Conditioning Circuit Checks in Group 9031-10. See Charging the system in Group 9031-20.</p>
---	---	---

-- -1/1

<p>COMPRESSOR CLUTCH CHECK</p>	<p>Engine OFF. Key switch ON. Blower switch on LOW. Air conditioner switch ON.</p> <p>Does compressor clutch "click" as switch is pushed?</p>	<p>YES: Check complete.</p> <p>NO: Replace compressor clutch.</p>
---------------------------------------	---	---

-- -1/1

9031
10
4

System Operational Checks

③ HEATER CIRCUIT CHECKS (MACHINES EQUIPPED WITH HEATER ONLY)

---1/1


③a BLOWER MOTOR 20 AMP FUSE (F13) CHECK

Remove fuse block cover.
 Remove fuse from fuse block.
 Using ohmmeter, check fuse for continuity.
 Is continuity measured?

YES: Fuse is OK.
NO: Replace fuse. If fuse blows again, check for short.

---1/1

③b HEATER BLOWER MOTOR SWITCH (S4) CHECK (MACHINES EQUIPPED WITH HEATER ONLY)



T111030 -UN-07AUG97

Disconnect wire harness from heater blower motor switch.

Connect ohmmeter to brown wire in switch connector and positive terminal of heater blower motor.

Turn heater blower motor switch to Low speed. Does ohmmeter read approximately 7.6 ohms resistance?

Turn heater blower motor switch to Medium Low speed. Does ohmmeter read approximately 3.7 ohms resistance?

Turn heater blower motor switch to Medium High speed. Does ohmmeter read approximately 1.2 ohms resistance?

Turn heater blower motor switch to High speed. Does ohmmeter read a lower resistance than 1.2 ohms?

YES: Go to next check.
NO: Replace heater blower motor switch.

---1/1

9031
 10
 5

System Operational Checks

<p>3c HEATER BLOWER MOTOR (M5) CHECK (MACHINES EQUIPPED WITH HEATER ONLY)</p>	<p>Disconnect harness from heater blower motor.</p> <p>Connect 24 volts to heater blower motor, and ground motor.</p> <p>Does heater blower motor operate?</p>	<p>YES: Heater blower motor is good. Check wiring harness.</p> <p>NO: Replace heater blower motor.</p> <p style="text-align: right;">-- -1/1</p>
--	--	--

4 HEATER AND AIR CONDITIONER CIRCUIT CHECKS




-- -1/1

<p>BLOWER MOTOR 20 AMP FUSE (F13) CHECK</p>	<p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK.</p> <p>NO: Replace fuse. If fuse blows again, check for short.</p> <p style="text-align: right;">-- -1/1</p>
--	--	--

<p>A/C CONTROLLER AND RELAYS 5 AMP FUSE (F14) CHECK</p>	<p>Remove fuse block cover.</p> <p>Remove fuse from fuse block.</p> <p>Using ohmmeter, check fuse for continuity.</p> <p>Is continuity measured?</p>	<p>YES: Fuse is OK.</p> <p>NO: Replace fuse. If fuse blows again, check for short.</p> <p style="text-align: right;">-- -1/1</p>
--	--	--

9031
10
6

System Operational Checks

<p>AIR CONDITIONER RELAY (K24, K25, K26, K27 AND K28) CHECK</p>	 <p>T118624 -UN-23NOV98</p>	<p>Disconnect harness from relay.</p> <p>Connect 24 volts to relay terminal 1 and ground terminal 2.</p> <p>Does relay click?</p> <p>Connect ohmmeter to terminals 3 and 4.</p> <p>Does ohmmeter read continuity?</p>	<p>YES: Relay is OK.</p> <p>NO: Relay has failed. Replace.</p> <p style="text-align: right;">--1/1</p>
<p>AIR CONDITIONER HIGH AND LOW PRESSURE SWITCH (B27) CHECK</p>	 <p>T101619 -19-13JUN96</p>	<p>Disconnect harness from switch.</p> <p>Check for continuity between terminals.</p> <p>Is continuity measured?</p>	<p>YES: Switch is good.</p> <p>NO: Go to High and Low Pressure Switch Test, Group 9031-25.</p> <p style="text-align: right;">--1/1</p>
<p>A/C AND HEATER BLOWER MOTOR (M6) CHECK</p>	<p>Disconnect harness from blower motor.</p> <p>Ground blk/red wire terminal in connector. Connect 24 volts to red/wht wire terminal in connector.</p> <p>Does blower motor operate in high speed?</p>	<p>YES: Blower motor is good. Check wiring harness.</p> <p>NO: Replace blower motor.</p> <p style="text-align: right;">--1/1</p>	
<p>AIR CONDITIONING COMPRESSOR CLUTCH (Y1) CHECK</p>	 <p>T6534CV -UN-19OCT88</p>	<p>Disconnect harness from clutch.</p> <p>Connect battery voltage to clutch terminal that has black/yellow wire. Ground black wire terminal.</p> <p>Does Clutch "click"?</p>	<p>YES: A/C compressor clutch coil is good. Check wiring harness.</p> <p>NO: Replace clutch coil.</p> <p style="text-align: right;">--1/1</p>

9031
10
7

DIAGNOSE AIR CONDITIONING ELECTRICAL MALFUNCTIONS

NOTE: Diagnostic charts are arranged from most probable and simplest to verify, to least likely more difficult to verify. Remember the following steps when diagnosing a problem:


- Step 1. Operational Check Out Procedure
- Step 2. Diagnostic Charts
- Step 3. Adjustments and/or Tests

Symptom	Problem	Solution
Heating System Does Not Operate	Blower motor 20 amp fuse (F13)	Replace fuse, Group 9031-10.
	Heater blower motor switch (S4)	Check heater blower motor switch, Group 9031-10.
	Heater blower motor (M5)	Check heater blower motor, Group 9031-10.
Air Conditioning System Does Not Operate	A/C controller and relays 5 amp fuse (F14)	Replace fuse.
	Blower motor 20 amp fuse (F13)	Replace fuse, Group 9031-10.
	Air conditioner relays (K24, K25, K26, K27, or K28)	Check air conditioner relays, Group 9031-10.
	A/C high and low pressure switch (B27)	Check high and low pressure switch, Group 9031-10.
	A/C and heater blower motor (M6)	Check A/C and heater blower motor, Group 9031-10.
	Compressor clutch (Y1)	Check compressor clutch, Group 9031-10.

9031
15
1

FOLDOUT PAGE 7-18 IS AT REAR OF MANUAL

Diagnostic Information



B27
AIR CONDITIONER
HIGH AND LOW
PRESSURE SWITCH

DETAIL A
EVAPORATOR CONNECTIONS

T118670

A/C Harness (W9) Component Location—Detail A

T118670 -19-24NOV98


TX,9031,GG2243 -19-12SEP96-2/2

9031
15
3

Diagnostic Information


AIR CONDITIONER HARNESS (W9) CONNECTORS, WIRE AND PIN LOCATION

A3
AIR CONDITIONER CONTROLLER
(MADE UP OF X17 AND X18)




X17
AIR CONDITIONER CONTROLLER
CONNECTOR (16-PIN)

1	YEL
2	GRN
3	WHT
4	BLU
5	YEL/BLU
6	PNK
7	PLUG
8	PLUG
9	PNK/GRN
10	RED/WHT
11	ORG
12	PLUG
13	BRN/RED
14	BLK
15	PLUG
16	GRN/WHT



X18
AIR CONDITIONER CONTROLLER
CONNECTOR (12-PIN)

1	BLK/GRN
2	RED/YEL
3	BLK/BLU
4	RED/BLU
5	GRN/RED
6	BLU/GRN
7	LGRN
8	PLUG
9	PLUG
10	PLUG
11	PLUG
12	PLUG



B27
AIR CONDITIONER
HIGH AND LOW
PRESSURE SWITCH


1	PNK
2	BRN

B29
AIR CONDITIONER
AND HEATER THERMISTOR

1	PNK/GRN
2	BRN/RED

M6
AIR CONDITIONER AND HEATER
BLOWER MOTOR

1	RED/WHT
2	BLK/RED



K24
AIR CONDITIONER BLOWER
MOTOR AND MAIN POWER
(LOW SPEED) RELAY

1	YEL
2	GRN
3	YEL (2MM)
4	RED/WHT

K25
AIR CONDITIONER
COMPRESSOR
CLUTCH RELAY

1	YEL
2	BRN
3	WHT/BLU
4	BLK/YEL

K26
AIR CONDITIONER BLOWER
MOTOR (LOW MEDIUM
SPEED) RELAY

1	YEL
2	WHT
3	WHT/RED
4	BLK

K27
AIR CONDITIONER BLOWER
MOTOR (MEDIUM SPEED)
RELAY

1	YEL
2	BLU
3	BLU/RED
4	BLK

K28
AIR CONDITIONER BLOWER
MOTOR (HIGH SPEED)
RELAY

1	YEL
2	YEL/BLU
3	BLK/RED
4	BLK

R11
AIR CONDITIONER AND HEATER
BLOWER MOTOR DROPPING
RESISTOR BLOCK

1	BLK/RED
2	BLU/RED
3	WHT/RED
4	BLK

**CONNECTORS FOR AIR CONDITIONER HARNESS (W9)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)**

T118195

Continued on next page

CED.OUTX782.5 -19-18NOV98-1/2

T118195 -19-18NOV98

Diagnostic Information



M9
AIR CONDITIONER
INTERNAL AND EXTERNAL
CAB AIR SERVO MOTOR

1	GRN/RED
2	BLU/GRN
3	
4	
5	

M10
AIR CONDITIONER
BLOWER PORT
CHANGE SERVO MOTOR

1	BLK/GRN
2	RED/YEL
3	ORG
4	LGRN
5	BRN/RED

M11
AIR CONDITIONER
AIR MIXER
SERVO MOTOR

1	BLK/BLU
2	RED/BLU
3	RED/WHT
4	GRN/WHT
5	BRN/RED


X17
AIR CONDITIONER CONTROLLER
CONNECTOR (16-PIN)

SEE A3

X18
AIR CONDITIONER CONTROLLER
CONNECTOR (12-PIN)

SEE A3

Y1
AIR CONDITIONER
COMPRESSOR CLUTCH



X16
AIR CONDITIONER
TO CAB HARNESS CONNECTOR

1	YEL
2	BLK
3	BLK/YEL POWER TO Y1
4	YEL

CONNECTORS FOR AIR CONDITIONER HARNESS (W9)
(HARNESS CONNECTORS - FRONT VIEW SHOWN)

T118196

9031
15
5

T118196 -19-18NOV98

CED.OUTX782.5 -19-18NOV98-2/2

PROPER REFRIGERANT HANDLING

The U.S. Environmental Protection Agency prohibits discharge of any refrigerant into the atmosphere, and requires that refrigerant be recovered using the approved recovery equipment.

IMPORTANT: To meet government standards relating to the use of refrigerants, R134a is used in the air conditioning system. Because it does not contain chlorine, R134a is not detrimental to the ozone in the atmosphere. However, it is illegal to discharge any refrigerant into the atmosphere.

It must be recovered using the appropriate recovery stations.

IMPORTANT: Use correct refrigerant recovery, recycling and charging stations. **DO NOT** mix refrigerants, hoses, fittings, components or refrigerant oils.

Recovery, recycling and charging stations for R12 and R134a refrigerants **MUST NOT** be interchanged. Systems containing R12 refrigerant use a different oil than systems using R134a. Certain seals are not compatible with both types of refrigerants.

TX,9031,UU3151 -19-13AUG96-1/1

R134A REFRIGERANT CAUTIONS



CAUTION: DO NOT allow liquid refrigerant to contact eyes or skin. Liquid refrigerant will freeze eyes or skin on contact. Wear goggles, gloves and protective clothing.

If liquid refrigerant contacts eyes or skin, **DO NOT** rub the area. Splash large amounts of **COOL** water on affected area. Go to a physician or hospital immediately for treatment.

DO NOT allow refrigerant to contact open flames or very hot surfaces such as electric welding arc, electric heating element and lighted smoking materials.

DO NOT heat refrigerant over 52°C (125°F) in a closed container. Heated refrigerant will develop high pressure which can burst the container.

Keep refrigerant containers away from heat sources. Store refrigerant in a cool place.

DO NOT handle damp refrigerant container with your bare hands. Skin may freeze to container. Wear gloves.

If skin freezes to container, pour **COOL** water over container to free the skin. Go to a physician or hospital immediately for treatment.

(R12 ONLY) Refrigerant exposed to high temperature forms phosgene gas. Inhaling toxic phosgene gas may result in serious illness or death. Phosgene gas has an odor like new mown hay or green corn. If you inhale phosgene gas, go to a physician or hospital immediately for treatment.

9031
20
1

TX,9031,UU3152 -19-13AUG96-1/1

Adjustments

R134A COMPRESSOR OIL CHARGE CHECK

Remove compressor if R134a leakage was detected and repaired. See Remove and install Compressor in Repair Manual.

Drain oil from the compressor and record the amount. See Compressor Oil Removal procedure in this group.

NOTE: Drain oil and save if this is a new compressor.

If the oil drained from a compressor removed from operation is very black or the amount of oil is less than 6 mL (0.2 fl oz), perform the following:

1. Remove and discard the receiver-dryer.
2. Remove, clean, but do not disassemble the expansion valve.
3. Flush the complete system with TY16134 air conditioning flushing solvent.
4. If the compressor is serviceable, pour flushing solvent in the manifold ports and internally wash out the old oil.
5. Install a new receiver-dryer.
6. Install required amount of TY22025 refrigerant oil in the compressor. (See R134a Component Oil Charge in this group.)
7. Connect all components, evacuate and charge the system.

TX,9031,UU3153 -19-13AUG96-1/1

R134A COMPRESSOR OIL REMOVAL

1. Remove compressor from machine. See Remove and Install Compressor in Repair Manual.
2. Remove inlet/outlet manifold from compressor, and clutch dust cover.
3. Drain oil into graduated container while rotating compressor shaft.
4. Record measured oil and discard oil properly.
5. Install new oil. See R134a Component Oil Charge in this Group.
6. Install compressor. See Remove and Install Compressor in Repair Manual.

TX,9031,UU3154 -19-13AUG96-1/1

Adjustments

R134A COMPONENT OIL CHARGE

SPECIFICATIONS	
New Compressor Oil Capacity	230 ± 20 mL (7.7 ± 0.7 fl oz)
Amount Of New Oil Capacity	100 mL (3.4 fl oz)
Flushed Compressor New Oil Capacity	330 ± 20 mL (11.1 ± 0.7 fl oz)
New Compressor, Drained Oil Capacity	45 mL (1.5 fl oz)
Used Compressor, Drained Oil Capacity	45 mL (1.5 fl oz)
Evaporator Oil Charge	130 mL (4.4 fl oz)
Condenser Oil Charge	65 mL (2.2 fl oz)
Receiver-Dryer Oil Charge	30 mL (1.0 fl oz)
Hoses Oil Charge	60 mL (2.0 fl oz) or 3 mL per 30 cm (0.1 fl oz per ft)
Hoses Approximate Total Length	600 cm (20 ft)

CAUTION: All new compressors are charged with a mixture of nitrogen, R134a refrigerant and TY22025 (R134a) refrigerant oil. Wear safety goggles and discharge the compressor slowly to avoid possible injury.

Compressors can be divided into three categories when determining the correct oil charge for the system.

- New compressor from parts depot
- Used compressor removed from operation
- Compressor internally washed with flushing solvent

Determining the amount of system oil charge prior to installation of compressor on a machine.

1. When the complete system, lines, and components were flushed add the correct amount of oil as described.
 - New compressor from parts depot contains the

amount of new oil of 230 ± 20 mL (7.7 ± 0.7 fl oz).

New Compressor Oil—Specification

Capacity..... 230 ± 20 mL (7.7 ± 0.7 fl oz)

System requires an additional amount of new oil of 100 mL (3.4 fl oz) of new oil.

Amount Of New Oil—Specification

Capacity..... 100 mL (3.4 fl oz)

- Used compressor removed from operation, oil drained, and flushed requires 330 ± 20 mL (11.1 ± 0.7 fl oz) of new oil.

Flushed Compressor New Oil—Specification

Capacity..... 330 ± 20 mL (11.1 ± 0.7 fl oz)

2. When the complete system was not flushed add the correct amount of oil for the compressor plus amount of oil for each component that was serviced.

- New compressor from parts depot, drain and return 45 mL (1.5 fl oz) of oil to the compressor.

New Compressor, Drained Oil—Specification

Capacity..... 45 mL (1.5 fl oz)

(See Compressor Oil Removal procedure in this group)

9031
20
3

Adjustments

- Used compressor removed from operation and oil drained, (See Compressor Oil Removal procedure in this group.) Add 45 mL (1.5 fl oz) of new oil.

Used Compressor, Drained Oil—Specification

Capacity 45 mL (1.5 fl oz)

- Used compressor removed from operation, oil drained, and flushed add 60 mL (2.0 fl oz) of new oil.

Components listed which have been removed, drained or flushed, require the removal of the compressor to determine the correct oil charge. Use the chart as a guide for adding oil to components.

Evaporator—Specification

Oil Charge..... 130 mL (4.4 fl oz)

Condenser—Specification

Oil Charge..... 65 mL (2.2 fl oz)

Receiver-Dryer—Specification

Oil Charge..... 30 mL (1.0 fl oz)

Hoses—Specification

Oil Charge..... 60 mL (2.0 fl oz) or 3 mL per
30 cm (0.1 fl oz per ft)
Approximate Total Length 600 cm (20 ft)

If any section of hose is removed and flushed or replaced, measure the length of hose and use the formula to determine the correct amount of oil to be added.



CAUTION: DO NOT leave the system or R134a compressor oil containers open. This oil easily absorbs moisture. DO NOT spill R134a compressor oil on acrylic or ABS plastic. This oil will deteriorate these materials rapidly. Identify R134a oil containers and measures to eliminate accidental mixing of different oils.

Adjustments

R134A REFRIGERANT RECOVERY, RECYCLING, AND CHARGING STATION INSTALLATION PROCEDURE

ESSENTIAL TOOLS


JT02045 R134a Refrigerant Recovery/Recycling and Charging Station
JT02046 R134a Refrigerant Recovery/Recycling and Charging Station (Alternate)
JT02050 R134a Refrigerant Recovery/Recycling and Charging Station (Alternate)

CAUTION: Do not remove high pressure relief valve (H). Air conditioning system will discharge rapidly causing possible injury.

IMPORTANT: Use correct refrigerant recovery, recycling and charging stations. **DO NOT** mix refrigerant, hoses, fittings, components or refrigerant oils.

NOTE: JT02046 and JT02050 R134a Refrigerant Recovery/Recycling and Charging Station can be substituted for the JT02045 R134a Refrigerant Recovery/Recycling and Charging Station.

1. Close both high and low pressure valves on refrigerant recovery, recycling and charging station (G).
2. Remove cap from low pressure test port (F).
3. Connect low pressure blue hose (B) from refrigerant recovery, recycling and charging station (G) to low pressure test port (F) on compressor.
4. Connect high pressure red hose (C) to high pressure quick disconnect.
5. Follow the manufacturer's instructions when using the refrigerant recovery, recycling and charging station.



- A—High Pressure Test Port
- B—Blue Hose
- C—Red Hose
- D—High Pressure Hose
- E—Low Pressure Hose
- F—Low Pressure Test Port
- G—Refrigerant Recovery/Recycling and Charging Station
- H—High Pressure Relief Valve

T118687 -UN-01DEC98

9031
20
5

Adjustments

RECOVER R134A SYSTEM

ESSENTIAL TOOLS


JT02045 R134a Refrigerant Recovery/Recycling and Charging Station
JT02046 R134a Refrigerant Recovery/Recycling and Charging Station (Alternate)
JT02050 R134a Refrigerant Recovery/Recycling and Charging Station (Alternate)

CAUTION: Do not remove high pressure relief valve (H). Air conditioning system will discharge rapidly causing possible injury.

IMPORTANT: Use correct refrigerant recovery, recycling and charging stations. DO NOT mix refrigerant, hoses, fittings, components or refrigerant oils.

NOTE: JT02046 and JT02050 recovery and charging stations can be substituted for the JT02045 station.

1. Run the air conditioning system for three minutes to help in the recovery process. Turn air conditioning system off before proceeding with recovery steps.
2. Connect refrigerant recovery, recycling and charging station. (See installation procedure in this group.)
3. Follow the manufacturer's instructions when using the refrigerant recovery, recycling and charging station.



- A—High Pressure Test Port
- B—Blue Hose
- C—Red Hose
- D—High Pressure Hose
- E—Low Pressure Hose
- F—Low Pressure Test Port
- G—Refrigerant Recovery/Recycling and Charging Station
- H—High Pressure Relief Valve

T118887 -UN-01DEC98

9031
20
6

Adjustments


EVACUATE R134A SYSTEM

SPECIFICATIONS

System Evacuation Vacuum Pressure	98 kPa (980 mbar) (29 in Hg)
If System Evacuation Vacuum Cannot Be Obtained, Test System For Leaks. Time	15 Minutes
Evacuation Time	15 minutes
Subtract Pressure For Each 300 m (1000 ft) Elevation Pressure	3.4 kPa (34 bar) (1 in. Hg)
Leak If Vacuum Decreases More Than Pressure	3.4 kPa (34 mbar) (1 in. Hg)
Evacuate System Time	For 30 min. After 98 kPa (980 mbar) (29 in. Hg) Vacuum

ESSENTIAL TOOLS

JT02045 R134a Refrigerant Recovery/Recycling and Charging Station
JT02046 R134a Refrigerant Recovery/Recycling and Charging Station (Alternate)
JT02050 R134a Refrigerant Recovery/Recycling and Charging Station (Alternate)



- A—High Pressure Test Port
- B—Blue Hose
- C—Red Hose
- D—High Pressure Hose
- E—Low Pressure Hose
- F—Low Pressure Test Port
- G—Refrigerant Recovery/Recycling and Charging Station
- H—High Pressure Relief Valve

T118687 -UN-01DEC98

CAUTION: Do not remove high pressure relief valve (H). Air conditioning system will discharge rapidly causing possible injury.

IMPORTANT: Use correct refrigerant recovery, recycling and charging stations. **DO NOT** mix refrigerant, hoses, fittings, components or refrigerant oils.

Do not run compressor while evacuating.

NOTE: JT02046 and JT02050 recovery and charging stations can be substituted for the JT02045 station.

1. Connect refrigerant recovery, recycling and charging station. (See installation procedure in this group.)
2. Open low and high pressure valves on refrigerant recovery, recycling and charging station.

9031
20
7

Adjustments

3. Follow the manufacturer's instructions and evacuate the system.

NOTE: The vacuum specifications listed are for sea level conditions.

4. Evacuate system until low pressure gauge registers 98 kPa (980 mbar) (29 in. Hg) vacuum.

Subtract 3.4 kPa (34 mbar) (1 in. Hg) from 98 kPa (980 mbar) (29 in. Hg) for each 300 m (1000 ft) elevation above sea level.

System Evacuation Vacuum—Specification

Pressure 98 kPa (980 mbar) (29 in Hg)

Subtract Pressure For Each 300 m (1000 ft) Elevation—Specification

Pressure 3.4 kPa (34 bar) (1 in. Hg)

If 98 kPa (980 mbar) (29 in. Hg) vacuum cannot be obtained in 15 minutes, test the system for leaks.

If System Evacuation Vacuum Cannot Be Obtained, Test System For Leaks.—Specification

Time..... 15 Minutes

(See Leak Testing in Group 9031-25).

Evacuation—Specification

Time..... 15 minutes

Correct any leaks.

5. When vacuum is 98 kPa (980 mbar) (29 in. Hg), close low-side and high-side valves. Turn vacuum pump off.
6. If the vacuum decreases more than 3.4 kPa (34 mbar) (1 in. Hg) in 5 minutes, there is a leak in the system.

Leak If Vacuum Decreases More Than—Specification

Pressure 3.4 kPa (34 mbar) (1 in. Hg)

7. Repair leak.
8. Start to evacuate.

9031
20
8

Adjustments

9. Open low-side and high-side valves.
10. Evacuate system for 30 minutes after 98 kPa (980 mbar) (29 in. Hg) vacuum is reached.

Evacuate System—Specification

Time..... For 30 min. After 98 kPa (980 mbar) (29 in. Hg) Vacuum

11. Close low-side and high-side valves. Stop evacuation.
12. Charge the system. (See procedure in this group.)

CED,TX14795,4341 -19-18AUG98-3/3

9031
20
9

Adjustments

CHARGE R134A SYSTEM

SPECIFICATIONS	
Pump Must Be Capable Of Pulling Vacuum	28.6 in. Hg at Sea Level
Subtract From Standard Vacuum For Each 300 m (1000 ft) Above Sea Level Vacuum	3.4 kPa (34 mbar) (1 in. Hg)
Refrigerant Added To Charge Weight	2.43 kg (5.25 lb)


ESSENTIAL TOOLS	
JT02045 R134a Refrigerant Recovery/Recycling and Charging Station	
JT02046 R134a Refrigerant Recovery/Recycling and Charging Station (Alternate)	
JT02050 R134a Refrigerant Recovery/Recycling and Charging Station (Alternate)	

CAUTION: Do not remove high pressure relief valve (H). Air conditioning system will discharge rapidly causing possible injury.

IMPORTANT: Use correct refrigerant recovery, recycling and charging stations. **DO NOT** mix refrigerant, hoses, fittings, components or refrigerant oils.

NOTE: JT02046 and JT02050 recovery and charging stations can be substituted for the JT02045 station.

1. Connect refrigerant recovery, recycling and charging station. (See installation procedure in this group.)
2. Evacuate the system. (See Evacuate Air Conditioning System, this group.)



- A—High Pressure Test Port
- B—Blue Hose
- C—Red Hose
- D—High Pressure Hose
- E—Low Pressure Hose
- F—Low Pressure Test Port
- G—Refrigerant Recovery/Recycling and Charging Station
- H—High Pressure Relief Valve

T118887 -UN-01DEC98

Continued on next page

CED,TX14795,4342 -19-04MAR98-1/2

9031
20
10

Adjustments

NOTE: Before beginning to charge air conditioning system, the following conditions must exist: Engine STOPPED, the pump must be capable of pulling at least 28.6 in. Hg vacuum (sea level). Subtract 3.4 kPa (34 mbar) (1 in. Hg) from 98 kPa (980 mbar) (29 in. Hg) for each 300 m (1000 ft) elevation above sea level.

Pump Must Be Capable Of Pulling—Specification

Vacuum 28.6 in. Hg at Sea Level

Subtract From Standard Vacuum For Each 300 m (1000 ft) Above Sea Level—Specification

Vacuum 3.4 kPa (34 mbar) (1 in. Hg)

3. Follow the manufacturers instructions and charge the system.
4. Add refrigerant until system is charged with 2.43 kg (5.25 lb).

Refrigerant Added To Charge—Specification

Weight..... 2.43 kg (5.25 lb)

5. Do air conditioner checks and tests in Groups 9031-10 and 9031-25.

9031
20
11

Adjustments

CHECK AND ADJUST COMPRESSOR BELT TENSION

SPECIFICATIONS	
Belt Deflection at 400 N (90 lb force) Deflection	19 mm (0.75 in.)
If Belt Deflection Not To Specification Cool Time	8—10 Minutes

SERVICE EQUIPMENT AND TOOLS
Belt Tension Gauge

IMPORTANT: Never over tighten belt. Over tightening may cause belt cord damage and excessive load on bearings.

1. Run engine for five minutes. Stop the engine, then immediately check tension using a belt tension gauge.
2. Measure strand tension or deflection at a point halfway between pulleys. Belt must deflect 19 mm (0.75 in.) at 400 N (90 lb force).

Belt Deflection—Specification

Deflection 19 mm (0.75 in.) at 400 N (90 lb force)

If belt deflection excessive , allow belt to cool for 8—10 minutes and try again.

If Belt Deflection Excessive—Specification

Cool..... 8—10 Minutes

IMPORTANT: Force to adjust belt must be applied to front of compressor housing only to prevent damage to compressor.

3. Loosen compressor mounting cap screws. Apply force to front of compressor housing to tighten belt. Tighten cap screws.
4. Repeat Steps 1 and 2 to check belts.

PROPER REFRIGERANT HANDLING

The U.S. Environmental Protection Agency prohibits discharge of any refrigerant into the atmosphere, and requires that refrigerant be recovered using the approved recovery equipment.

IMPORTANT: To meet government standards relating to the use of refrigerants, R134a is used in the air conditioning system. Because it does not contain chlorine, R134a is not detrimental to the ozone in the atmosphere. However, it is illegal to discharge any refrigerant into the atmosphere.

It must be recovered using the appropriate recovery stations.

IMPORTANT: Use correct refrigerant recovery, recycling and charging stations. **DO NOT** mix refrigerants, hoses, fittings, components or refrigerant oils.

Recovery, recycling and charging stations for R12 and R134a refrigerants **MUST NOT** be interchanged. Systems containing R12 refrigerant use a different oil than systems using R134a. Certain seals are not compatible with both types of refrigerants.

TX,9031,UU3151 -19-13AUG96-1/1

R134A REFRIGERANT CAUTIONS

CAUTION: DO NOT allow liquid refrigerant to contact eyes or skin. Liquid refrigerant will freeze eyes or skin on contact. Wear goggles, gloves and protective clothing.

If liquid refrigerant contacts eyes or skin, **DO NOT** rub the area. Splash large amounts of **COOL** water on affected area. Go to a physician or hospital immediately for treatment.

DO NOT allow refrigerant to contact open flames or very hot surfaces such as electric welding arc, electric heating element and lighted smoking materials.

DO NOT heat refrigerant over 52°C (125°F) in a closed container. Heated refrigerant will develop high pressure which can burst the container.

Keep refrigerant containers away from heat sources. Store refrigerant in a cool place.

DO NOT handle damp refrigerant container with your bare hands. Skin may freeze to container. Wear gloves.

If skin freezes to container, pour **COOL** water over container to free the skin. Go to a physician or hospital immediately for treatment.

(R12 ONLY) Refrigerant exposed to high temperature forms phosgene gas. Inhaling toxic phosgene gas may result in serious illness or death. Phosgene gas has an odor like new mown hay or green corn. If you inhale phosgene gas, go to a physician or hospital immediately for treatment.

9031
25
1

TX,9031,UU3152 -19-13AUG96-1/1

Tests

R134A AIR CONDITIONING SYSTEM TEST

SPECIFICATIONS	
Engine Speed	2180 rpm
Temperature Control Switch Position	Maximum Cooling
Blower Speed	High
Run Unit For At Least Time	5 Minutes

Ambient Temperature	Air Duct Temperature	Low Pressure Gauge	High Pressure Gauge
16°C (60°F)	13°C (55°F)	7—165 kPa (0.07—1.6 bar) (1—24 psi)	630—1095 kPa (6—11 bar) (90—160 psi)
21°C (70°F)	16°C (60°F)	7—180 kPa (0.07—1.8 bar) (1—26 psi)	785—1225 kPa (7.6—12 bar) (110—175 psi)
27°C (80°F)	18°C (65°F)	7—205 kPa (0.07—2.1 bar) (1—30 psi)	955—1410 kPa (9.6—14.1 bar) (140—205 psi)
32°C (90°F)	21°C (70°F)	7—240 kPa (0.07—2.4 bar) (1—35 psi)	1145—1645 kPa (11.4—16.5 bar) (165—240 psi)
38°C (100°F)	27°C (80°F)	7—280 kPa (0.07—2.7 bar) (1—40 psi)	1355—1935 kPa (13.4—19.3 bar) (195—280 psi)
43°C (110°F)	29°C (85°F)	7—330 kPa (0.07—3.3 bar) (1—48 psi)	1580—2275 kPa (15.8—22.7 bar) (230—330 psi)

ESSENTIAL TOOLS
JT02045 R134a Refrigerant Recovery/Recycling and Charging Station
JT02046 R134a Refrigerant Recovery/Recycling and Charging Station (Alternate)
JT02050 R134a Refrigerant Recovery/Recycling and Charging Station (Alternate)

IMPORTANT: Use correct refrigerant recovery, recycling and charging stations. DO NOT use refrigerant, hoses, fittings, components or refrigerant oils intended for R12 refrigerant.

1. Connect refrigerant recovery, recycling and charging station. (See installation procedure in this group.)
2. Close both low and high pressure valves on refrigerant recovery, recycling and charging station.
3. Open cab doors and windows.

9031
25
2

Tests

4. Connect low pressure blue hose (B) from refrigerant recovery, recycling and charging station (G) to low pressure test port (F) on compressor.
5. Connect high pressure red hose (D) to high pressure quick-disconnect on compressor.
6. Follow the manufacturer's instructions when using the refrigerant recovery, recycling and charging station.
7. Start engine and run at fast idle.

Engine—Specification

Speed 2180 rpm

8. Press temperature control switch at the maximum cooling position.

Temperature Control Switch—Specification

Position Maximum Cooling

9. Press blower switch at high speed position.

Blower—Specification

Speed High

10. Check sight glass in receiver-dryer for bubbles or if clean.

11. Run unit for at least 5 minutes.


Run Unit For At Least—Specification

Time 5 Minutes

12. Measure air temperature at condenser air inlet and at air ducts in air conditioning unit. Record readings.

13. Read low and high pressure gauges on refrigerant recovery, recycling and charging station. Record readings.

14. Compare pressure and temperature readings to the specifications shown.



- A—High Pressure Test Port
- B—Blue Hose
- C—Red Hose
- D—High Pressure Hose
- E—Low Pressure Hose
- F—Low Pressure Test Port
- G—Refrigerant Recovery/Recycling and Charging Station
- H—High Pressure Relief Valve

T118687 -UN-01DEC98

9031
25
3

Tests

Ambient Temperature	Air Duct Temperature	Low Pressure Gauge	High Pressure Gauge
16°C (60°F)	13°C (55°F)	7—165 kPa (0.07—1.6 bar) (1—24 psi)	630—1095 kPa (6—11 bar) (90—160 psi)
21°C (70°F)	16°C (60°F)	7—180 kPa (0.07—1.8 bar) (1—26 psi)	785—1225 kPa (7.6—12 bar) (110—175 psi)
27°C (80°F)	18°C (65°F)	7—205 kPa (0.07—2.1 bar) (1—30 psi)	955—1410 kPa (9.6—14.1 bar) (140—205 psi)
32°C (90°F)	21°C (70°F)	7—240 kPa (0.07—2.4 bar) (1—35 psi)	1145—1645 kPa (11.4—16.5 bar) (165—240 psi)
38°C (100°F)	27°C (80°F)	7—280 kPa (0.07—2.7 bar) (1—40 psi)	1355—1935 kPa (13.4—19.3 bar) (195—280 psi)
43°C (110°F)	29°C (85°F)	7—330 kPa (0.07—3.3 bar) (1—48 psi)	1580—2275 kPa (15.8—22.7 bar) (230—330 psi)

15. Use the Operating Pressure Diagnostic Chart in this group to diagnose the malfunction.

CED,OUOE003,1079 -19-19AUG98-3/3

9031
25
4

Tests

OPERATING PRESSURE DIAGNOSTIC CHART

Condition	Low Side- kPa (bar/psi)	High Side- kPa (bar/psi)	Sight Glass	Suction Line	Receiver- Drier	Liquid Line	Discharge Line	Discharge Air
Lack of Refrigerant	Very low	Very low	Clear	Slightly cool	Slightly warm	Slightly warm	Slightly warm	Warm
Loss of Refrigerant	Low	Low	Bubbles	Cool	Warm to hot	Warm	Warm to hot	Slightly cool
Lack of Refrigerant and Air in System	Normal (won't drop)	Normal	Occasional bubbles	Warm to hot	Warm	Warm	Warm	Slightly cool
Compressor Failure	High	Low	Clear	Cool	Warm	Warm	Warm	Slightly cool
Condenser Malfunction	High	High	Clear to occasional bubbles	Slightly cool to warm	Hot	Hot	Hot	Warm
Moisture in System	Normal (may drop)	Normal (may drop)	Clear	Cool	Warm	Warm	Hot	Cool to warm
Refrigerant Contaminated and Air in System	High	High	Bubbles	Warm to hot	Warm	Warm	Hot	Warm
Expansion Valve Open	High	High	Clear	Cold-sweating or frosting heavily	Warm	Warm	Hot	Slightly cool
Expansion Valve Closed	Low	Low	Clear	Cold-sweating or frosting heavily at valve outlet	Warm	Warm	Hot	Slightly cool
High Side Restriction	Low	Low	Clear	Cool	Cool or sweating or frosting	Cool or sweating or frosting	Hot to point of restriction	Slightly cool
Normal	Normal 7-500 kPa (0.07-5 bar 1-35 psi)	Normal 700-2100 kPa 7-21 bar 100-300 psi	Clear	Cool-possible light sweat	Warm	Warm	Hot	Cool-11° to 17°C (20°F to 30°F) below ambient

9031
25
5

T6609AB -19-28FEB89

Tests

HIGH AND LOW PRESSURE SWITCH TEST

SPECIFICATIONS	
Low Pressure Switch (Normally Open) Closes on Increasing Pressure	345 ± 35 kPa (3.45 ± 0.3 bar) (50 ± 5 psi)
Low Pressure Switch (Normally Open) Opens on Decreasing Pressure	173 ± 35 kPa (1.73 ± 0.3 bar) (25 ± 53 psi)
High Pressure Switch (Normally Closed) Opens on Increasing Pressure	2760 ± 138 kPa (27.6 ± 1.38 bar) (400 ± 20 psi)
High Pressure Switch (Normally Closed) Closes on Decreasing Pressure	1310 ± 138 kPa (13.11 ± 1.38 bar) (190 ± 20 psi)

SERVICE EQUIPMENT AND TOOLS
Volt-Ohm-Amp Meter
JT02051 3-Gauge Manifold w/Hose And Quick Coupler

NOTE: The line that attaches the high and low pressure switch has a valve installed to prevent discharging the air conditioning system when switch is removed. The high pressure switch is normally closed when removed from the machine. It does not open when installed in the A/C system until pressure exceeds specification.

1. Remove high and low pressure switch.
2. Connect a portable pressure source, such as a hydraulic hand pump, to high and low pressure switch.
3. Using an ohmmeter measure continuity between terminals A and B until low pressure switch pressure increases to switch closing pressure specification.

Low Pressure Switch (Normally Open)—Specification

Closes on Increasing Pressure 345 ± 35 kPa (3.45 ± 0.3 bar) (50 ± 5 psi)

Low Pressure Switch (Normally Open)—Specification

Opens on Decreasing Pressure 173 ± 35 kPa (1.73 ± 0.3 bar) (25 ± 53 psi)



T8426AE (CY)

T8426AE -UN-06MAR95

9031
25
6

Tests

4. Slowly increase pressure. Switch must have continuity until pressure increases to high pressure switch opening pressure specification.

High Pressure Switch (Normally Closed)—Specification

Opens on Increasing Pressure 2760 ± 138 kPa (27.6 ± 1.38 bar)
(400 ± 20 psi)

High Pressure Switch (Normally Closed)—Specification

Closes on Decreasing Pressure..... 1310 ± 138 kPa (13.11 ± 1.38 bar) (190 ± 20 psi)

5. The low pressure switch can also be checked when installed in air conditioning system, however, pressure is slow to increase to test specification. High test switch is not easily tested in system.

Connect an 3-gauge manifold for R134a to service fittings at compressor. Cover condenser with paper or plastic to stop air flow. Operate air conditioner on maximum cooling. Note high-side pressure when high pressure switch opens and then closes.

CED,TX14795.4346 -19-04MAR98-2/2

9031
25
7

LEAK TESTING

1. Inspect all lines, fittings, and components for oily or dusty spots. When refrigerant leaks from the system, a small amount of oil is carried out with it.
2. A soap and water solution can be sprayed on the components in the system to form bubbles at the source of the leak.
3. If a leak detector is used, move the leak detector probe under the hoses and around the connections at a rate of 25 mm (1 in.) per second.
4. Some refrigerant manufacturers add dye to refrigerant to aid in leak detection.

TX,9031,UU3168 -19-13AUG96-1/1

*Tests***REFRIGERANT HOSES AND TUBING INSPECTION**

When a component is disconnected from the system, special care should be given to inspecting hoses and tubing for moisture, grease, dirt, rust, or other foreign material. If such contamination is present in hoses, tubing, or fittings and cannot be removed by cleaning, then replace parts.

Fittings that have grease or dirt on them should be wiped clean with a cloth dampened with alcohol. Chlorinated solvents (such as trichloroethylene) are contaminants, and must not be used for cleaning.

To assist in making leak-proof joints, use a small amount of clean correct viscosity refrigerant oil on all

hose and tube connections. Dip O-rings in correct viscosity oil before assembling.

IMPORTANT: Hose used for air conditioning systems contains special barriers in its walls to prevent migration of refrigerant gas.

DO NOT use hydraulic hoses as replacement hoses in the air conditioning system. Use ONLY certified hose meeting SAE J51B requirements.

TX,9031,UU3169 -19-13AUG96-1/1

BLANK

CHAPTER 8

SECTION 9035

ARCTIC/COLD WEATHER HEATER

BLANK

**ARCTIC/COLD WEATHER HEATER
CAUTIONS**

CAUTION: Heater must be turned off while refueling.

Do not operate heater in enclosed areas where combustible fumes may be present.

Prior to operating the heater, ensure that the fuel system is intact and there are no leaks.


Extreme care should be taken to ensure a proper mixture of water and antifreeze is used in the coolant system to be heated, to prevent coolant from freezing or slushing. If the coolant becomes slushy or frozen, the heater's coolant pump cannot move the coolant causing a blockage of the circulating system. Once this occurs, pressure will build up rapidly in the heater and the coolant hose will either burst or blow off at the connection point to the heater. This situation could cause engine damage and/or personal injury.

CED,OUOE012,174 -19-14APR99-1/1

9035
05
1

Theory of Operation

ARCTIC/COLD WEATHER HEATER THEORY OF OPERATION



9035
05
2

T125363

T125363 -UN-28OCT99

Continued on next page

CED.OUOE012.175 -19-15APR99-1/2

Theory of Operation

1—Burner Motor	7—Flame Tube	13—Fuel Metering Pump	A—Combustion Air
2—Flame Sensor	8—Heat Exchanger	14—Wiring Harness	E—Exhaust
3—Combustion Chamber	9—Overheat Sensor	15—Fuse Holder	F—Fuel Supply Line
4—Control Unit	10—Water Pump	16—Battery—Power	WO—Water Outlet
5—Glow Plug	11—Exhaust	17—LED Light	WI—Water Inlet
6—Temperature Sensor	12—Battery—Ground	18—Toggle Switch	

The arctic/cold weather heater is an oil fired heater that pumps coolant from the machine engine, heats it and returns it to the engine. The heater utilizes machine 24-volt power and fuel, and operates independently of the machine engine. A temperature regulating switch in the unit regulates the coolant temperature between a low of 53°C (127°F) and a high of 85°C (185°F)

When the heater switch is turned ON, the following sequence occurs:

NOTE: If the heater fails to start the first time, it will automatically attempt a second start. If the second attempt fails, the heater will shut off completely. On the initial start up, the heater may require several start attempts to self-prime the fuel system.

- The control unit does a system check (flame sensor, temperature, safety thermal cut-out fuse and various other control unit checks).
- The water pump starts circulating the coolant.
- The combustion air blower starts.
- The glow plug begins to preheat for 20—50 seconds.
- After 20—50 seconds the fuel metering pump starts delivering fuel and the combustion air blower ramps up gradually.

Once ignition takes place, the flame sensor alerts the control unit, and the control unit shuts off the glow plug.

When started, the heater runs in the full heat mode and the temperature is monitored at the heat exchanger. When the coolant temperature reaches 72°C (162°F) the heater starts cycling up and down between levels (high, medium, low). If the coolant temperature continues to rise, the heater will automatically shut off. This occurs when the temperature reaches 85°C (185°F).



The water pump continues to circulate coolant after heater shutdown, to allow the heater to monitor coolant temperature. The heater will automatically restart when the coolant temperature drops below 68°C (154°F).

The heater continues to run as described above, until the heater switch is turned OFF.



When the heater switch is turned OFF, the fuel metering pump stops delivering fuel and the flame is extinguished. The combustion air blower and water pump continue to run for 130 seconds to cool down.

Theory of Operation

ARCTIC/COLD WEATHER HEATER WIRING DIAGRAM



T125362



Continued on next page

CED.OUOE012.177 -19-15APR99-1/2

T125362 -19-28OCT99

9035
05
4

Theory of Operation

1.1—Blower Motor
1.2—Glow Pin
1.5—Overheat Sensor

1.12—Flame Sensor
1.13—Temperature Sensor
2.1—Control Unit

2.12—Water Pump
2.2—Fuel Metering Pump
2.7—15-Amp Main Fuse

2.7.1—5-Amp Switch Fuse
5.1—Battery

CED.OUOE012,177 -19-15APR99-2/2

9035
05
5

ARCTIC/COLD WEATHER HEATER CHECKS

The following checks should be performed periodically to ensure the system is in good operating condition:

- Check coolant hoses and clamps, and make sure all valves are open.
- Maintain the proper engine coolant level and ensure that the heater is properly bled after service to or involving the cooling system.
- Visually check all fuel lines for leaks. Check fuel filter inserts and replace if necessary.
- Visually inspect all electrical lines and connections for corrosion.
- Maintain the electrical system in good condition. The heater will not start with insufficient power, and will automatically shut down if high or low voltage fluctuations occur.
- Use fuel suitable for the climate.
- Check the glow plug and replace if necessary.
- Run the heater at least once a month for at least 15 minutes.

CED,OUOE012,180 -19-16APR99-1/1

9035
10
1

**DIAGNOSE ARCTIC/COLD WEATHER
HEATER MALFUNCTIONS**

In the event of a malfunction, the following items should be checked before performing the heater diagnostic procedure:

- Fuel supply
- Fuses, electrical lines and connections.
- Battery voltage.
- Coolant flow.
- Interference in the combustion air and exhaust pipes

If combustion is sooty, check the following:

- combustion air and exhaust ducts. Clear if necessary.
- Fuel metering pump. Measure for excessive delivery, and replace if necessary.

CED,OUOE012,179 -19-16APR99-1/1

**ARCTIC/COLD WEATHER HEATER
DIAGNOSTIC PROCEDURE**

The heater system utilizes the green LED light located next to the arctic/cold weather heater switch, located on the right hand console inside the cab, to provide fault information. The light provides different illumination sequences depending on the malfunction as shown in the function and fault test chart.

Continued on next page

CED,OUOE012,181 -19-16APR99-1/3

9035
15
1

Indication	Signal													Cause	Remedy
	0	1	2	3	4	5	6	7	8	9	10	11	12		
1 Start, heating phase (trouble-free operation)														_____	_____
2 Normal operation (trouble-free operation)														_____	_____
3 Delayed shut-off, restart (heater still not shut off or in the control interval when started)														Heater still not shut off Water temperature still above the triggering point for the temperature sensor (approx. 80°C) Temperature sensor interruption	Wait until end of delayed shut-off Wait until temperature falls below the triggering point Replace temperature sensor
4 Warning: power supply (undervoltage or overvoltage)														Undervoltage Overvoltage	Charge battery Check regulator (see Pos. 11)
5 Overheat (automatic cutout)														Electric line to metering pump interrupted Insufficient cooling water Water circuit not properly bled Water pump defective	Check line Top up cooling water Bleed water circuit Replace water pump Operate safety thermal cutout switch
6 Flame sensor defective (short-circuit)														Flame sensor defective	Replace flame sensor
7 Flame out Low (flame goes out by itself in "Low" setting)														Insufficient fuel Speed of blower not reduced Vapour lock in the fuel line? Control unit defective Flame sensor fouled/ defective	Measure fuel quantity Replace partial-load resistor Re-route line Replace control unit Clean/ replace flame sensor
8 Flame out High (flame goes out by itself in "High" setting)														Insufficient fuel Vapour lock in the fuel line? Flame sensor fouled/defective	Measure fuel quantity Fuel line becomes too hot - re-route line Clean/replace fuel sensor

	Indication														Cause	Remedy
	Signal Seconds															
	0	1	2	3	4	5	6	7	8	9	10	11	12	13		
9 Glow plug defective	█	█	█	█				█	█	█	█				Glow plug fuse defective Glow plug defective Flame sensor fouled/ defective	Replace fuse Replace glow plug Clean/ replace flame sensor
10 Burner motor defective	█	█	█	█				█	█	█	█				Heater fuse defective Electric motor defective or blower blocked Flame sensor fouled/defective	Replace fuse Replace blower Clean/replace flame sensor
11 Cutout due to undervoltage	█	█	█	█				█	█	█	█				Undervoltage Corrosion on electrical connections	Charge battery, check battery Clean electrical connections
12 Cutout due to overvoltage	█	█	█	█				█	█	█	█				Overvoltage	Check regulator Connect heater to battery
13 Non-start Safety time exceeded and automatic cutout	█	█	█	█				█	█	█	█				No fuel Metering pump defective Short-circuit at metering pump No pulses at metering pump Fuel line not filled Insufficient fuel Glow plug defective Automatic cutout after 3-5 mins. Flame sensor wrongly poled Flame sensor fouled Flame sensor interruption Insufficient fuel	Replace metering pump Check plug Replace control unit Restart, check fuel line Measure fuel quantity Replace glow plug Check connection against wiring diagram Clean flame sensor Replace flame sensor Measure fuel quantity

Function and Fault Test Chart (Continued)

BLANK

CHAPTER 9
SECTION 9040
AIR COMPRESSOR

BLANK

GROUP 25 - Trouble Shooting

INTRODUCTION

Trouble shooting for a portable air compressor is an organized study by a particular problem or series of problems and a planned method of procedure for investigation and correction. The trouble shooting chart that follows includes some of the problems that an operator may encounter during the operation of a portable compressor. The chart does not attempt to list all of the troubles that may occur, not does it attempt to give all of the answers for correction of the problems. The chart does give those problems that are most apt to occur. To use the trouble shooting chart:

- A. Find the "complaint" depicted as a bold heading.
- B. Follow down that column to find the potential cause or causes. The causes are listed in order (1,2,3 etc.) to suggest an order to follow in trouble shooting.

ACTION PLAN

A. Think Before Acting

Study the problem thoroughly and ask yourself these questions:

- (1) What were the warning signals that preceded the trouble?
- (2) Has a similar trouble occurred before?
- (3) What previous maintenance work has been done?
- (4) If the compressor will still operate, is it safe to continue operating it to make further checks?

B. Do The Simplest Things First

Most troubles are simple and easily corrected. For example, most complaints are "low capacity" which may be caused by too low an engine speed or compressor "over-heats" which may be caused by low oil level. Always check the easiest and most obvious things first; following this simple rule will save time and trouble.


Note: For trouble shooting electrical problems, refer to the Wiring Diagram Schematic found in Section 9 – Parts List.

C. Double Check Before Disassembly

The source of most compressor troubles can be traced not to one component alone, but to the relationship of one component with another. Too often, a compressor can be partially disassembled in search of the cause of a certain trouble and all evidence is destroyed during disassembly. Check again to be sure an easy solution to the problem has not be overlooked.

D. Find And Correct Basic Cause

After a mechanical failure has been corrected, be sure to locate and correct the cause of the trouble so the same failure will not be repeated. A complaint of "premature breakdown" may be corrected by repairing any improper wiring connections, but something caused the defective wiring. The cause may be excessive vibration.



TROUBLE SHOOTING CHART

Bold Headings depict the COMPLAINT - Subheadings depict the CAUSE

Note: Subheadings suggest order to follow in cause of troubleshooting.

Short Air Cleaner Life:

Dirty Operating Conditions
Inadequate Element Cleaning
Defective Service Indicator
Incorrect Stopping Procedure
Wrong Air Filter Element
Oil Pump Drive Coupling

Excessive Oil In Air:

High Oil Level
Out of Level > 15 degrees
Clogged Scavenge Orifice
Scavenge Tube Blocked
Defective Scavenge Check Valve
Sep. Tank Blown Down Too Quickly
Defective Minimum Pressure Valve

Oil Seal Leak:

Contaminated Lube Oil
Blocked or Restricted Oil Lines
Malfunctioning Seal
Scored Shaft

Will Not Unload:

Leaks in Regulator Piping
Incorrect Pressure Regulator Adjustment
Malfunctioning Pressure Regulator
Malfunctioning Inlet Unloader/Butterfly Valve
Ice in Regulation Lines/Orifice

Oil In Air Cleaner:

Incorrect Stopping Procedure
Oil Pump Drive Coupling
Discharge Check Valve Faulty

Safety Valve Relieves:

Operating Pressure Too High
Leaks In Regulator Piping
Incorrect Pressure Regulator Adjustment
Malfunctioning Pressure Regulator
Malfunctioning Inlet Unloader/Butterfly Valve
Defective Safety Valve
Defective Separator Element
Ice in Regulation Lines/Orifice

Excessive Compressor Oil Temperature:

Ambient Temp. > 125°F (52°C)
Out of Level > 15 degrees
Low Oil Level
Wrong Lube Oil
Dirty Cooler
Dirty Operating Conditions
Clogged Oil Filter Elements
Loose or Broken Belts
Operating Pressure Too High
Recirculation Of Cooling Air
Malfunctioning Thermostat
Malfunctioning Tan
Defective Oil Cooler Relief Valve
Defective Minimum Pressure Valve
Blocked or Restricted Oil Lines
Airend Malfunctioning

Engine RPM Down:

Clogged Fuel Filter
Operating Pressure Too High
Incorrect Pressure Regulator Adjustment
Malfunctioning Pressure Regulator
Incorrect Linkage Adjustment
Dirty Air Filter
Malfunctioning Air Cylinder
Wrong Air Filter Element
Defective Separator Element
Ice In Regulation Lines/Orifice
Engine Malfunctioning
Airend Malfunctioning

Excessive Vibration:

Rubber Mounts Damaged
Malfunctioning Fan
Drive Coupling Defective
Engine Malfunctioning
Airend Malfunctioning

Low CFM:

Dirty Air Filter
Incorrect Linkage Adjustment
Incorrect Pressure Regulator Adjustment
Malfunctioning Pressure Regulator
Operating Pressure Too High
Malfunctioning Inlet Unloader/Butterfly Valve
Malfunctioning Air Cylinder
Defective Minimum Pressure Valve
Defective Separator Element
Wrong Air Filter Element
Ice in Regulation Lines/Orifice

Unit Shutdown:

Out of Fuel
 Compressor Oil Temp. Too High
 Engine Water Temp. Too High
 Engine Oil Pressure Too Low
 Broken Engine Fan Belt
 Loose Wire Connection
 Low Fuel Level Shutdown Switch
 Defective Discharge Air Temp. Switch
 Defective Engine Belt Break Switch
 Defective Engine Oil Pressure Switch
 Defective Shutdown Solenoid
 Malfunctioning Relay
 < 9 Volts at Shutdown Solenoid
 Blown Fuse
 Engine Malfunctioning
 Airend Malfunctioning

Won't Start/Run:

Low Battery Voltage
 <9 Volts at Shutdown Solenoid
 Blown Fuse
 Malfunctioning Start Switch
 Defective Safety Bypass Switch
 Clogged Fuel Filters
 Out of Fuel
 Compressor Oil Temp. Too High
 Engine Water Temp. Too High
 Engine Oil Pressure Too Low
 Loose Wire Connection
 Defective Discharge Air Temp. Switch
 Defective Engine Belt Break Switch
 Defective Engine Oil Pressure Switch
 Defective Shutdown Solenoid
 Malfunctioning Relay
 Engine Malfunctioning
 Airend Malfunctioning

Unit Fails To Shutdown:

Low Fuel Shutdown Switch
 Defective Discharge Air Temperature Switch
 Defective Engine Belt Break Switch
 Defective Engine Oil Pressure Switch
 Defective Shutdown Solenoid
 Malfunctioning Relay
 Defective Safety Bypass Switch

Engine Temperature Lamps Stays On:

Broken Engine Fan Belt
 Malfunctioning Circuit Board
 Defective Engine Belt Break Switch
 Ambient Temp. > 125°F (52°C)
 Dirty Operating Conditions
 Dirty Cooler
 Out of Level >15 degrees
 Operating Pressure Too High
 Recirculation of Cooling Air

Alternator Lamp Stays On:

Loose or Broken Belts
 Loose Wire Connection
 Low Battery Voltage
 Malfunctioning Alternator
 Malfunctioning Circuit Board

Engine Oil Pressure Lamp Stays On:

Low Oil Level
 Out of Level >15 degrees
 Wrong Lube Oil
 Clogged Oil Filter Elements
 Engine Malfunctioning

Alternator Lamp Stays Off:

Bulb Burned Out
 Loose Wire Connection
 Malfunctioning Circuit Board

Engine Temperature Lamps Stays Off:

Bulb Burned Out
 Loose Wire Connection
 Malfunctioning Circuit Board
 Defective Engine Belt Break Switch

Engine Oil Pressure Lamp Stays Off:

Bulb Burned Out
 Malfunctioning Circuit Board
 Defective Engine Oil Pressure Switch
 Malfunctioning Fan
 Engine Malfunctioning

BLANK


CHAPTER 10

SECTION 9045

ROCK DRILL ATTACHMENT


BLANK

CPA X-TEND



Drifter maintenance

SHANK REPLACEMENT



The CPA should be lowered in its rest position.

Loosen the 2 nuts (Pos.1).

Remove the front guide (Pos. 2) and the front box (Pos. 3)

Pull the shank (Pos. 4) out.

Check the condition of the bronze nut splines. Replace the bronze nut if damaged.

Change the flushing seals (Pos. 5,6).

Mind the orientation of the seals.

Refer to "Flushing seal replacement" chapter for the use of the mounting tool.

Check the wear of the front guide bronze bush.

maximum wear = shank diameter+1 mm (.04 in).

If out off limits, replace the bronze bush.

Inspect the contact area:

- A between the hydraulic retainer and the front lining.
- B between the shank shoulder and the hydraulic retainer.

Replace part as necessary.

Mount the shank in the drifter.


Slide the front box on the shank.

Mount the front guide.

Tighten the 2 nuts (Pos. 1) to 650 Nm (470 ft.lb).

Drifter maintenance

FLUSHING SEAL REPLACEMENT



Dismantle the flushing seals and the retainer bush, extract the faulty seals.

Mount the seal in the mounting apparatus, lips oriented towards the tool or towards the outside depending of the seal position when mounted. (fig 1).

Turning the handle of the apparatus, put the seal in position for mounting (fig 2).

If necessary correct the position of the seal.

With the apparatus bring the seal into the groove.

Mind the orientation of the seals.

Release it by turning the handle of the apparatus.

Remove the apparatus.

With a plastic rod, re-form the seal in its groove.

Tool number		Seal Diameter
Cpn	Montabert pn	
86352572	73N25	38
86352564	73N24	45 / 5N

Drifter maintenance

GUIDE RING REPLACEMENT




fig. 1

fig. 2

fig. 3

With a screwdriver remove the rush A.

With a press extract the worn bushing.

Take all necessary precautions to avoid projecting the rush.

Fig. 2

Fig. 3

Put down the ring B.

Turn the front guide round.

Slide the front guide on the ring.

Put the new bronze bushing F into position.

Put the two half-segments C into the groove.

Mount the shoulder axle G on the bushing.

Put the centering ring D into position.

Put the bushing into position with a press.

Tighten the screw E to hold all parts together.


Push it well in.

Mount a new rush A.

Item	cpn	Ref
B	86365475	77794
C	86365483	77795
D	86365467	77793
E	96717202	8861
G	86323557	59834

Drifter maintenance

ACCUMULATOR CHECK



The control of the inflation pressure or the reparation of an accumulator can be done, drifter in place on the guide rail.

Make sure that the drifter's energy supply has been cut and that the hoses are not under pressure.

Onto the inflation tool, mount a gauge corresponding to the pressure to be checked :

- LP accumulator = 10 bar gauge A.
- HP accumulator = 60 bar gauge B.

Attach the inflation tool (cpn 86490364) to the accumulator lid ;

– Make sure that the key C to unblock the inflating screw is well engaged on the screw head.

– Tighten the fixing screws D progressively so that the inflating device rests correctly on the accumulator.

- Fully tighten setting screw (E).

Connect the inflation tool to the bottle of nitrogen.

Shut the drain cock E.

Open the bottle of nitrogen and set the pressure reducer to the theoretical inflating pressure of the accumulator to be controlled.

- LP accumulator = 4 bar.
- HP accumulators = 40 bar.

When the pressure has been stabilized shut the nitrogen bottle off.

Unblock and unscrew the inflating screw C for some turns.

If the pressure indicated on the gauge falls more than 3 bar replace the accumulator diaphragm.

If the pressure is correct re-block the inflating screw.

Open the drain cock E.



Remove the inflation tool.

NB : Due to the weak pressure of the LP accumulator an accurate control is difficult.

If necessary change the diaphragm and re-inflate systematically.

Drifter maintenance

ACCUMULATOR REPAIRS



The control of the inflation pressure or the reparation of an accumulator can be done, drifter in place on the guide rail.

Make sure that the drifter's energy supply has been cut and that the hoses are not under pressure.

Unscrew the inflating screw on the accumulator to lower the residual pressure.

Using the special socket A (cpn 86493392) and a torque wrench, unscrew the accumulator lid.

Remove the faulty diaphragm.

Carefully wipe the accumulator flange to remove any traces of oil.

Mount the new diaphragm B (clean and dry). Grease the visible part of the diaphragm with silicone (ref 67714) or some other good quality lubricant.

Put a new O'ring C on the accumulator lid.

Oil the thread of the lid and block it at 1400 mN (1030 ft.lbs).

Mount a tight ring D and a new inflating screw E.

Fix the inflation tool equipped with its gauge on the accumulator lid (see Accumulator Check).

Turn off the drain cock.

Open the nitrogen bottle and set the pressure reducer to the required pressure :

- 4 bar for LP accumulator
- 40 bar for HP accumulators.

When the pressure has been stabilized, block the inflating screw at 22 mN (16 ft.lbs).

Shut the nitrogen bottle off, turn on the drain cock to relieve pressure from the tool.

Remove the inflation tool.

According to the position of the drifter, fill up the housing for the inflating screw with oil and check that there are no bubbles.


DUST COLLECTOR THEORY OF OPERATION

Looking at a drill rig with a dust collector mounted, all you see is: the pick up hood (1), the suction hose (2), and a big box mounted somewhere on the rig, and hopefully no dust. Every time a new drill rod is added, the big box will drop its contents of drill chips and dust in a plastic sack (4), or just on the ground in a neat pile via the rubber dump valve (3).

What is happening inside the dust collector?

Flushing air and drill chips enter the filter housing through the rubber hose. Inside air and chips hit a heavy steel wear plate, and the heavier chips ricochet downwards, into the cortical part (5). Air and fine dust moves upwards towards the cylindrical filter elements (6). The fine dust settles on the filter surface, the clean air passes through, and is picked up by the fan (7) (or the venturi on the pneumatic models) and expelled out of the top of the dust collector.

Every time the operator stops to add on another drill rod, suction stops so that the accumulated chips can fall down. At the same time the filter elements are cleaned by repeated air blasts from the inside. This happens automatically every time when drilling is interrupted on the hydraulic units. The pneumatically driven dust collectors are all equipped with a manual filter cleaning system.



- | | |
|---------------------------|--------------------|
| 1. Pick up hood | 2. Suction hose |
| 3. Rubber dump valve | 4. Plastic sack |
| 5. Bottom housing section | 6. Filter elements |
| 7. Fan | 8. Hydraulic Motor |

We find several components inside the dust collector whose function is vital to the dust collecting system.


B: The automatic cleaning cycle

In the dust collector the heavy chips fall to the bottom, but the fine dust collects on the filter surface. When adding on a new drill rod there is time to clean the filter elements. In the dust collectors, compressed air is used for cleaning the filters. This method gives the best cleaning results and does not destroy the filter elements with hard mechanical vibration.

The system works as follows:

As the operator stops the rock drill, the flushing air (or the hydraulic pressure) is also, shut off. In the air line or the hydraulic line there is an electric pressure switch. As the pressure drops, the switch is closed and an electric signal goes to a small control unit mounted inside the dust collector. This signal starts the cleaning cycle.

The fan creates the suction that makes the dust collector work




Cleaning cycle:

1. Pressure switch sends signal to the timer card when the rock drill is stopped.
2. Timer card activates solenoid valve N2 2 and the fan inlet is closed, which means no air passes through the filters
3. Timer card activates solenoid valve NQ 1 with a series of pulses. Altogether 10 pulses, 1 sec between them. As an option there is available Timer card with 3 sec. interval between pulses. The air blasts from the inside of the filters clean the filter surface.
4. After the ten pulses, solenoid valve N° 2 closes, the spring loaded air cylinder returns.
5. If drilling is started before the cleaning cycle is finished the built in pressure switch terminates the cleaning cycle.

C: The fan

The dust collecting system:



The fan pumps out the air from the clean side of the filters thus creating a vacuum at Point B. During drilling air speed is higher at Point A than at Point B. The difference in speed forces the air (in this case the flushing air) to move from Point A to Point B.

The air volume moved depends on the pressure difference and the flow resistance between A and B.

As explained above it is necessary that the capacity of the dust collector is somewhat higher than the volume of the flushing air coming out of the bore hole


Summing up:

1. The fan capacity and the flow resistance through the dust collector give the volume of air that will pass through the dust collector.
2. This volume must be higher than the volume of the flushing air.
3. The air speed through the suction hose must be high enough (25 ni/sec +) to prevent fallout.
4. The rig hydraulic system must be able to deliver sufficient oil volume (measured in litters/minute) and oil pressure (in Bars) to run the fan motor at the required RPM's.

Adjustment of drilling automatism

ADJUSTMENT OF DRILLING AUTOMATISMS

LOCATION OF ADJUSTING SCREWS



1) V1 Feed pressure

This valve setting is made while setting up the machine on site, to suit bit type and diameter.

Presetting can be made in a static mode prior to drilling by feeding the bit against some resistance.

Final setting is made at full percussion power while drilling in the hardest, most homogeneous competent rock encountered.

2) MP Maximum percussion pressure

It sets the drifter maximum percussion pressure when drilling with cold oil while starting up.

This factory setting **must not be altered**.

3) V2 Operating percussion pressure

It sets the drifter percussion power to a suitable level for bit size and rock hardness. The setting should be approximately :

- 120 – 130 bar (1715 – 1850 psi) for Hc 80
 - 130 – 140 bar (1850 – 2000 psi) for Hc 120
 - 140 – 160 bar (2000 – 2285 psi) for Hc 150
- depending upon the appropriate drifter power level.

4) V3 Drifter power regulation

V3 measures actual feed force by sensing both forward and return feed pressures.

The V3 adjustment sets the feed pressure limit below which the drifter power will be reduced.

This control will continue to reduce the drifter power level to a 60 bar (870 psi) preset minimum as rock resistance decreases.

5) Feed flow regulator

This flow regulator adjusts the feed maximum flow to slightly above the drill rate in the hardest rock encountered.

If the feed flow while drilling in softer rock conditions reaches the preset maximum, the resulting back pressure makes the feed force to decrease and act on V3.

This acts as both an Anti-Void and Collaring Control.

6) V4 Progressive feed control and anti-jam

V4 is an adjustable regulator which senses the pressure differential across the rotation motor and acts directly upon feed flows.

Adjustment of drilling automatisms

As drilling torque exceeds the presetting, V4 spool begins to shift to reduce the feed flows. These restricted feed flows result in lower feed force and feed motion slows down. As a second step and separate from the V4 adjustment described, V3 lowers drifter percussion pressure in response to the feed force reduction.

Far above the V4 setting, feed motion will first stop and then reverse before the bit gets stuck.


V4 setting is made just above normal drilling conditions to avoid reaction in homogeneous rock.

7) Flushing control valve

A flushing control valve will fully shift the V4 spool causing reverse feed motion when the bit is plugged. Drifter cycle operation clears the bit while the bit is retracting.

This feature is fully operative with reverse percussion drifters.

E.53734 PRESSURE GAUGES




Connect the pressure gauges with hydraulic dampers (ref. 42501) to the pulsating P1 and P2 circuits.

Connect the two other pressure gauges to the A1 and A2 feed circuits.

Adjustment of drilling automatisms

PRESETTING BEFORE DRILLING



Machine off:

12) Unlock safety nut and loosen V3 screw until the internal spring becomes free (V3 screw returns to free rotation).

13) Unlock safety nut and fully tighten V2 screw (hold V3 screw to prevent re-tightening).

14) Set the feed flow regulator 5 on position 10.

15) Remove V4 cap, and fully tighten V4 setting.

Machine running:

16) Press the bit against the rock by acting on feed lever.

17) Preset drilling feed pressure (V1 setting) to 80 – 100 bar (1140 – 1430 psi).

PRESETTING WHILE DRILLING

These settings must be carried out when oil has reached its normal operation temperature.

18) Start drilling (flushing, rotation, percussion, feed) **in homogeneous, non fractured rock** with drifter percussion control in “Auto” position.

19) Set the operating percussion pressure to – 140 – 155 bar (2000– 2215 psi) for Hc 150 (or less depending of the bit size, rod diameters, rock hardness...) by loosening V2 screw. Check the pressure on “P2” gauge.

20) By acting on V1 screw, reset feed pressure for correct coupling motion : about 1 millimeter vibration and coupling temperature less than 100° C.

Control simultaneously penetration rate and coupling temperature.

If coupling temperature is above limit although coupling vibration is correct, reduce operating percussion pressure by tightening V2 screw.

SETTING WHILE DRILLING

Adjust flow regulator on feed return A2

21) While drilling the starter rod (or the rod drilled at the highest drilling rate) progressively close the flow regulator 5 until the feed back–pressure reaches 5 bar (check the pressure on “A2” gauge).

22) Then, re–open the flow regulator 5 by 1 division.

For example : if position 6 creates 5 bar back pressure, re–open the flow regulator to position 7.

V3 drifter power regulator setting

This setting must be carried out when drilling conditions allow maximum percussion pressure and actual feed force (i.e. hard, non fractured rock, feed back pressure “A2” = 0 bar).

23) With a wrench, hold V2 screw in position.

24) Tighten V3, until percussion pressure drops (check the pressure on “P2” gauge).

25) Loosen so as to recover the initial pressure plus an additional 1/4 turn.

26) While drilling with drifter percussion control alternatively in “Auto” and “Manual” positions, verify that the percussion pressure remains the same.

27) Secure all locking nuts.

V4 – Progressive feed control setting.

28) While drilling the last rod (or the rod drilled with the highest rotation torque) **in homogeneous ground**, loosen V4 setting until the feed back pressure slightly increases (check the pressure on “A2” gauge).

29) Then re–tighten V4 setting for 1 turn.

Air flushing valve

While drilling with the drifter percussion control in “auto” position, switch off air flushing and check the drifter reverses.

Adjustment of drilling automatisms

EXCEPTIONAL ADJUSTMENTS

Reverse percussion pressure


Note : The full drifter reverse percussion pressure is only obtained when drilling in “manual” position.

The factory set pressure (130 bar – 1860 psi) can be modified by setting the stop screw A :


- e Tighten to reduce the pressure.
- e Loosen to increase.

Check the pressure on “P2” gauge.

Do not exceed 130 bar (1860 psi)



Maximum percussion pressure



For checking or setting after part replacement,


- 1)e Disconnect and plug the drifter percussion hose.
- 2)e Remove the protection cap and loosen MP maximum percussion pressure relief valve (2).
- 30) Set the maximum percussion pressure to 190 bar (2720 psi) by tightening the relief valve (2). Check the pressure on “P2” gauge.
- 31) Secure the safety nut, remount the protection cap.

Thread coupling/uncoupling adjustments

THREAD COUPLING/UNCOUPLING ADJUSTMENTS

The drifter displacement, during thread coupling/uncoupling operations, must be synchronized with the rotation speed in accordance with the thread pitch.

The drifter rotation/displacement synchronization is obtained by controlling the drifter speed by means of 2 flow limiters located on the drilling automatism block.




The flow regulator F controls the drifter forward speed.

The flow regulator R controls the drifter reverse speed.

Thread coupling synchronization

The verification of the synchronized drifter displacement/rotation is done by checking the displacement of a screwdriver placed in the shank thread.



Rest the hand holding the screwdriver on the guide.

Place the screwdriver in the thread.

Ask a helper to operate the rod changer manipulator lever in thread coupling position.

The synchronization is correct if the screwdriver remains in position (the drifter displacement corresponds exactly to the thread pitch).

If the screwdriver tends to move up or down, adjust the drifter displacement by setting the flow regulator F:

- The drifter displacement is too fast, loosen the setting F.
- The drifter displacement is too slow, tighten the setting F.

Thread uncoupling synchronization


The checking procedure is the same, but, operate the rod changer lever in thread uncoupling position and set the flow regulator R :

- Tighten the setting R if the drifter displacement is too fast,
- Loosen the setting R if the drifter displacement is too slow.

9045
GROUP 20
DIAGRAMS

CPA Electric diagram 94707 revision 02
Schéma électrique

cpk pzy k vř vmm., a si p
d ki i zuwo zlu t kpk p., as v(s i



gmy vwynti z zn w/ koi t nm w/ mji i wny
fu yb nmwal rui l nw/ wal koi t nmw


gmy kpk pz t nzu i nmki vzm w
ful yzkumkzuw

10-16

TM 5-3805-280-24-1

CPA Electric diagram 94707 revision 02
Schéma électrique

S 18



1	Avance foration	Feed forward
1+5	Avance amorçage	Feed for collaring
2	Recul dévissage	Feed backward (thread uncoupling)
2+5	Recul lent	Feed forward
3	Avance rapide	Fast feed forward
4	Recul rapide	Fast feed backward

Contact	Position						
	1	1+5	2	2+5	3	4	0
121-37			X	X	X	X	X
260-121	X	X					
122-33	X	X			X	X	X
260-122			X	X			
260-33						X	
260-37					X		
260-20		X		X			


S 17



0	Repos	Off
1	Rotation inverse + frappe	Reverse rotation + hammering


Contact	S 17		S 16				
	0	1	1	2	3	4	0
260-126				X			
260-30		X					
132-30	X						
131-125				X	X	X	X
131-132			X	X	X		X
260-131					X	X	
260-125			X				
131-29			X	X		X	X

S 16



1	Rotation	Rotation
2	Rotation inverse	Reverse rotation
3	Foration sans automatismes	Drilling without automatismes
4	Foration avec automatismes	Drilling with automatismes

S 15



0	Repos	Off
1	HP	HP
2	HP + capteur	HP + dust collector

Contact	Position		
	0	1	2
260-11			X
260-36		X	

Wiring chart

Grille numérotation filerie

	0	1	2	3	4	5	6	7	8	9
0		X	X	X	X	X	X	X	X	X
1	X	X	X	X		X	X	X	X	X
2	X	X	X		X	X				X
3	X		X	X	X	X	X	X		
4	X									
5	X	X	X	X						
12		X	X		X	X				
13		X								
26	X									

Ten's
Dizaines


Schéma électrique
Electric diagram: 94707
: 86480910

Item	CPN	Ref.	Qty	Part name	Désignation	Page
F1	86340197 86328234	66840 + 61972	1	15 Amp. fuse Fuse holder	Fusible 15 A Porte fusible	
F2	86220670 86328234	65011 +61972	1	3.15 Amp. fuse Fuse holder	Fusible 3,15 A Porte fusible	
F5	86367455	78349	1	5 Amp. fuse	Fusible 5 A	
P100	86350709	72088	1	Hourmeter	Horamètre	
S3	86300118	48557	1	Electric manipulator (hydraulic centralizer)	Manipulateur électrique (lunette)	
S4	86420924	93842	1	Electric manipulator (dust hood)	Manipulateur électrique (tête de captage)	
S10	86223674	32095	1	Emergency stop	Arrêt d'urgence	
S12	86223633	48198	1	Electric manipulator (swing cylinder)	Manipulateur électrique (vérin d'orientation)	
S14	86330859	62917	1	Electric manipulator (air flushing)	Manipulateur électrique (injection d'air)	
S15	86333804	64348	1	Electric manipulator (HP + dust collector)	Manipulateur électrique (HP + capteur de poussières)	
S16	86391935	84550	1	Electric manipulator (drilling)	Manipulateur électrique (foration)	
S17	86221785 86223682	49130 + 49634	1	Electric manipulator (Bit release) Additionnal switch	Manipulateur électrique (déblocage taillant) Contact auxiliaire	
S18	86377991	81033	1	Electric manipulator (feed)	Manipulateur électrique (avanceur)	
S20	86289931	42904	1	Selector (excavator/CPA)	Commutateur pelle/CPA	
S21	86415650	90880	1	Emergency stop	Arrêt d'urgence	
Y10				CPA oil supply valve (to be supply locally)	Alimentation CPA (non fournie)	
Y27 Y28	86390291	84100	1	Solenoid valve feed forward reverse feed	Electro-distributeur avance recul	
Y32 Y33	86476413	94547	1	Solenoid valve drifter rotation reverse rotation	Electro-distributeur rotation à gauche rotation à droite	
Y34-Y42 Y35-Y43	86476421	94548	2	Solenoid valve drifter percussion percussion without automatisms	Electro-distributeur frappe perforateur frappe sans automatismes	
Y36 Y37	86476421	94548	1	Solenoid valve fast feed forward fast reverse feed	Electro-distributeur recul rapide avance rapide	
Y38 Y39	86222007	43736	1	Solenoid valve swing cylinder swing cylinder	Electro-distributeur vérin d'orientation vérin d'orientation	
Y40	86411642	89757		Solenoid valve (hole collaring)	Electro-distributeur (amorçage)	

Item	CPN	Ref.	Qty	Part name	Désignation	Page
Y41	86355435	74209		Solenoid valve (dust collector)	Electro-distributeur (capteur de poussières)	
Y30	86355435	74209		Solenoid valve (HP)	Electro-distributeur (HP)	
Y50	86330776	62888		Solenoid valve (air flushing)	Electro-distributeur (injection d'air)	
Y100 Y101	86222007	43736	1	Solenoid valve hyd. centralizer opening hyd. centralizer closing	Electro-distributeur ouverture lunette hyd. fermeture lunette hyd	
Y150 Y151	86222007	43736	1	Solenoid valve dust hood down dust hood up	Electro-distributeur descente tête de captage montée tête de captage	
Y44	86300274	48678		Solenoid valve (collaring air)	Electro-distributeur (injection d'amorçage)	
Y45	86418431	93492		Solenoid valve (uncoupling)	Electro-distributeur (retour synchro)	
Y46	86418449	93493		Solenoid valve (coupling)	Electro-distributeur (avance synchro)	

Rod changer Electric diagram 9483N revision C

Schéma électrique



vers pupitre CPA
to CPA control box

10-20

TM 5-3805-280-24-1

Wiring chart
Grille numérotation filerie

Units / Unités


	0	1	2	3	4	5	6	7	8	9
0		●	●	●	●	●	●	●	●	●
1	●	●	●	●	●	●	●	●	●	●
2	●	●	●	●	●	●	●	●	●	●
3	●	●	●	●	●	●	●	●	●	●
4	●	●	●	●	●	●	●	●	●	●
5	●	●	●	●	●	●	●	●	●	●
6	●	●	●	●	●	●	●	●	●	●
7	●	●	●	●	●	●	●	●	●	●
8	●	●	●	●	●	●	●	●	●	●

Tens'
Dizaines

● = CPA / = Rod changer
Changeur

Schéma électrique
Electric diagram: 94831
: 86482817



Item	CPN	Ref.	Qty	Part name	Désignation	Page
Fu1	86367455	78349	1	5 Amp. fuse	Fusible 5 A	
Fu2	86367455 86397783	78349 +85927	1	5 Amp. fuse Fuse holder	Fusible 5 A Porte fusible	
Fu3	86367455	78349	1	5 Amp. fuse	Fusible 5 A	
Fu4	86367455	78349	1	5 Amp. fuse	Fusible 5 A	
M1	86481199	94726	1	Electric manipulator (rod changer)	Manipulateur électrique (changeur de barres)	
M2	86449594	94201	1	PLC	Automate programmable	
F1	86481215 86481223 86348133 86348059	94728 +94729 +70944 +70889	1 1 1 1	Knob Complete body Additional switch Additional switch	Bouton Corps complet Bloc additif Bloc additif	
S3	86322427	59402	1	Pressure switch	Manostat	
S4	86322427	59402	1	Pressure switch	Manostat	
Dt1	86482700	94816	1	Inductive switch	Détecteur de proximité	
Dt2	86482700	94816	1	Inductive switch	Détecteur de proximité	
Dt3	86482791	94828	1	Inductive switch	Détecteur de proximité	
L1	86342276 86256450	67902 +22176	1 1	Indicator Bulb	Voyant Ampoule	
R1 to R9	86482684	94814	9	Relay	Relais	
Y7 Y8	86355245	74165	1	Solenoid valve upper and lower clamps opening/closing inversion	Electro-distributeur inversion ouverture/fermeture des pinces hautes et basses	
Y13	86299492	48001	1	Solenoid valve rod thread lubrication	Electro-distributeur graissage	
Y6 Y5	86222007	43736	1	Solenoid valve clamps closing clamps opening	Electro-distributeur fermeture pinces ouverture pinces	
Y4 Y3	86222007	43736	1	Solenoid valve clamps swing towards guide clamps swing towards car- ousel	Electro-distributeur rotation des pinces vers glissière rotation des pinces vers magasin	
Y2 Y1	86222007	43736	1	Solenoid valve carousel rotation carousel rotation	Electro-distributeur rotation du magasin vérin d'orientation	



Vers changeur ou présentateur de barres. (See 094830) TO ROD CHANGER OR (Voir 094830)

CPA Hydraulic diagram 86480902 revision E
 Schéma hydraulique 94706

10-23




TM 5-3805-280-24-1

Rod changer Hydraulic diagram 86482825 94830 revision C
 Schéma hydraulique 94830


9045
GROUP 25
TROUBLESHOOTING

Too low penetration rate



to be continued on next page.

Too low penetration rate (cont'd)





Problem	Possible reasons
1) Important vibration of drifter hoses	P2 hose : Deflated or punctured HP accumulators. LP, P2 hoses : Deflated or punctured LP accumulator.
2) Overheating on drifter front part	Check : – Pressurization circuit – Air pressure reducer. – Oiler. – Feed pressure if too low.
3) Coupling sleeve overheating, important vibration level or erratic motion.	Feed pressure too low. Increase feed pressure. If unsuccessful, check : – Bit wear – Flushing (insufficient) – Rubbing of drifter cradle on guide – Feed motor if internal leak.
4) Rotation speed irregular or too low.	If rotation back to normal while drilling in manual mode, check rotation circuit relief valve setting. If still irregular while drilling in manual mode, check the drifter rotation motor for internal leak.

Troubleshooting procedure for rod changer

CHECKING OF PLC

The result of PLC auto-test and the state of each input / output can be visualized on the front panel of the PLC.



Auto-test

The "RUN" indicator must be alight when the CPA is under tension.

"ERR", "COM" and "I / O" indicators must be off.

If not, the PLC is faulty and must be replaced (be sure all fuses are OK).

Inputs / outputs

Input indicators (I0 to I13) or output indicators (O0 to O9) are alight when the corresponding input / output is active.

CHECK LIST

Follow the check list to determine if all input and output information are entering and leaving the PLC properly.

State (alight or off) of the indicators must be conform to the list. If not, check the input / output wiring and components (refer to electric diagrams 94707 and / or 94831).

Note : some other indicators should be alight or off at the same time, only consider the state of the listed one.

Prior proceeding the following tests, remove the starter rod from the guide and make sure the drifter is pulled back.

Note: If the carousel rotation is working in manual mode but not in automatic mode (rod adding or rod removing) , check the output indicators O0 or O1 are alight (depending of the carousel direction of rotation).


Troubleshooting procedure for rod changer

	Action or control position	Indicator "alight"	Indicator "Off"	Comments
1	None		I9	
2	Selector mode in rod adding position (S1)	I10	I11	
3	Selector mode in rod removing position (S2)	I11	I10	
4	Selector mode in manual position (S0)		I10 , I11	
For the following test, the selector mode will be kept in manual mode (position S0)				
5	Carousel positioned for rod adding or rod removing (rod housing in front of the opening of the rod catcher).	I8		I8 "off", check inductive switch Dt3 mounted on upper support close to the reducer.
		O7		Indicator L should be alight
6	Rod clamp arms swung into the carousel	I6		I6 "off", check inductive switch Dt1 mounted on the lower clamp support.
			I7	I7 alight, check inductive switch Dt2 mounted on the lower clamp support (close to the guide).
7	Depress M4 button (Upper and lower rod clamps opening)	I4	I5	I5 alight, check the wiring for short cut.
		O4 , O9	O5 , O6	
8	Rod clamps opened. Depress M4 button.	I4 , I13	I5 , I12	If I12 stays alight, screw in S4 pressure switch setting.
		O4 , O9	O5 , O6	
9	Depress M1 + M4 buttons (Upper rod clamp opening, lower rod clamps closing)	I4 , I5		
		O5 , O6	O9	
11	Depress M1 button (Upper and lower rod clamps closing)	I5	I4	I4 alight, check the wiring for short cut.
		O5 , O9	O4 , O6	
11	Rod clamps closed onto a rod. Depress M1 button	I5 , I12	I4 , I13	If I13 stays alight, screw in S3 pressure switch setting.
		O5 , O9	O4 , O6	
12	Move the the rod changer control lever in K1 direction (rod clamp arms swing towards the guide)	I3	I2	I2 alight, check the wiring for short cut.
		O3	O2	
13	Rod clamps arms on the guide	I7		I7 "off", check inductive switch Dt2 mounted on the lower clamp support.
			I6	I6 alight, check inductive switch Dt1 mounted on the lower clamp support (close to the guide).
14	Pull and hold the rod changer control lever in K2 direction (rod coupling)	I0	I1	I1 alight, check the wiring for short cut.
15	Push and hold the rod changer control lever in K4 direction (rod uncoupling)	I1	I0	I0 alight, check the wiring for short cut
		O8		O8 indicator is alight after 1 sec. delay.
16	Move the the rod changer control lever in K3 direction (rod clamp arms swing into the carousel)	I2	I3	I3 alight, check the wiring for short cut.
		O2	O3	

Troubleshooting procedure for rod changer


SEQUENCE DESCRIPTION

Rod adding (selector mode on S1 position)



Troubleshooting procedure for rod changer

Rod removing (selector mode on S2 position)



Troubleshooting procedure for rod changer


TIMER SETTING

The delays required for:

- allowing the opening of the upper clamp to allow re-tightening of the upper coupling before unscrewing a rod (when removing a rod), or reduced opening of the upper and lower clamps for guiding the rod during screwing in the coupling held in the centralizer (when adding a rod),
 - controlling the detection of the carousel rotation disregarding the direction of the movement,
- are set by acting on the 2 small potentiometers of the PLC.

Setting 0, adjusts the time for clamp opening in guiding position (setting range 0 to 200 millisecond).

Setting 1, adjust the delay for the detection of the carousel rotation (setting range 0 to 100 millisecond).



These settings should be re-adjusted according to the variation of the oil viscosity which in winter will reduce the speed of the movements.

TROUBLE SHOOTING HYDRAULIC DUST COLLECTOR

If your dust collector performance is inefficient though maintained daily, check the following:

1. Check suction hose for blockages. Clean any water or dirt from hose.
2. Check rubber dump valve (or plastic sack). If worn or otherwise damaged, change to a new one.
3. Check that compressor gives OIL FREE AIR at recommended pressure 7-12 bar (100- 172 PSi) for the filter cleaning.

4. Pressure indicating switch

Pressure switch is set on 3,5 bar from factory. Can be adjusted by turning screw (left = lower pressure, right = higher). See sketch...

4.1 Check function of switch by short circuiting the cables in switch. If cleaning cycle is then started, switch is faulty. Change to a new one.

4.2 If cleaning does not start when short circuiting cables, check power supply all the way up to timer card in dust collector.

4.3 Check that all cables are unbroken.

5. TIMER CARD

5.1 Lift off hydraulic fan top A) to get into the clean air chamber B).

5.2 Simulate a cleaning cycle by short circuiting pressure indicating switch as in 4. above.

5.3 Listen if solenoid valve indicates 10 cleaning pulses with 1 sec interval. If not, change solenoid A).

5.4 Check that cables between timer card and solenoid valves are not damaged.

5.5 If no faults in 5.2-5.4 are found, timer card is faulty and has to be replaced!







6. SOLENOID VALVES FOR FILTER CLEANING

6.1 If solenoid valves allow air to blow continuously, the diaphragm in valve is broken. Change!

6.2 If solenoid valves do not open, i e no air is allowed into the cleaning system, check hole B) in diaphragm C). If clogged, blow clean and refit diaphragm into solenoid valve.

If valves still not open, change the solenoid

A



7. AIR CYLINDER

7.1 If air cylinder puts the fan closer plate in closed position during drilling, the dust collector does not work. Check diaphragm C) in the 1/2" solenoid valve that controls air cylinder movements. If diaphragm is broken, change to a new one. If hole is clogged, blow clean.

7.2 Check solenoid by simulating a cleaning cycle as described in 5.2 above.

7.3 Check and clean the adjustable relief valves. **NOTE!** After refitting adjustable relief valves you must adjust them to achieve correct movements of air cylinder.

How to adjust

Open relief valve by turning 2.5 turns from closed.

7.4 Check and clean the bleed filter.

7.5 If air cylinder still is not working, change to a new one.

7.6 Check fan closer plate. Ensure that ass'y is secure and sealed against bottom plate. This is very important for perfect filter cleaning and full suction capacity.


8. If dust escapes through fan top, one or more filters are broken. **STOP DRILLING IMMEDIATELY** and check which filters are broken. Exchange broken filters for new ones.

IMPORTANT! When opening filter housing from bottom section, follow instructions given below. Also check the clean air chamber and clean away any dust which otherwise can fall down inside the clean filters. If necessary, clean filter housing and bottom section.

8.1 Check if filters- are clogged. If impossible to clean, change to new filters.


8.2 Check wear plate inside dust collector inlet.

If plate is worn out, high-speed dust will blow directly into the filters and destroy them in a very short time.




WHEN OPENING FILTER HOUSING FROM BOTTOM, ALWAYS:


**Remove
damaged
foam rubber
seal**



**Clean
carefully**



**Fit new
seal**




9. FAN

If broken filters have caused dust to blow up through the fan, this will very quickly cause unbalance.

Fan has to be dismantled immediately, cleaned and checked. If still not in balance, fan has to be replaced by a new one.

If the fan is driven while unbalanced, the hydraulic motor bearing will be affected and can lead to replacement of the complete motor unit.

**10. HYDRAULIC MOTOR**

10.1 Check that the motor gets necessary oil volume at correct working pressure

10.2 Also check that the motor is correctly connected with hydraulic hoses of recommended diameter

If points 10. 1 and 10.2 are fulfilled and the fan still is not running at 4500- 5000 rpm, there is probably an internal leakage in the motor. The motor should then be replaced

CHAPTER 11
SECTION 01
TRACKS REPAIR

BLANK

SERVICE EQUIPMENT AND TOOLS

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company.

CED,OUOE003,1220 -19-26SEP98-1/17

Special Roller Caliper. JT05519¹

To measure undercarriage component wear.

¹*Tools are available in a kit such as the JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.*

CED,OUOE003,1220 -19-26SEP98-2/17

17-1/2 and 30-Ton Puller Set

To remove brackets and bushings from track rollers and front idler.

CED,OUOE003,1220 -19-26SEP98-3/17

Rubber Stopper/Leak Detector Kit. D05361ST

To test lower track roller and front idler for oil leakage.

CED,OUOE003,1220 -19-26SEP98-4/17

8 mm Hex Key Wrench

To remove track carrier roller plug.

Continued on next page

CED,OUOE003,1220 -19-26SEP98-5/17

Track System

01
0130
2

8 mm Hex Head Wrench

To remove track carrier roller thrust washer-to-support shaft cap screws.

CED,OUOE003,1220 -19-26SEP98-6/17

Depth Gauge (200 mm Ruler) JT05521¹

To measure undercarriage components for wear.

¹Tools are available in a kit such as the JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.

CED,OUOE003,1220 -19-26SEP98-7/17

Right Angle Attachment JT05534¹

To measure undercarriage components for wear.

¹Tools are available in a kit such as the JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.

CED,OUOE003,1220 -19-26SEP98-8/17

300 mm Ruler D05231ST¹

To measure undercarriage components for wear.

¹Tools are available in a kit such as the JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.

Continued on next page

CED,OUOE003,1220 -19-26SEP98-9/17

Track System

01
0130
3

100 mm Caliper D17524C1¹

To measure undercarriage components for wear.

¹Tools are available in a kit such as the JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.

CED,OUOE003,1220 -19-26SEP98-10/17

Metric Tape Measure JT05520¹

To measure undercarriage components for wear.

¹Tools are available in a kit such as the JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.

CED,OUOE003,1220 -19-26SEP98-11/17

50-Ton Master Pin Pusher Installer D01030AA

To remove and install master pin in track chain master link.

CED,OUOE003,1220 -19-26SEP98-12/17

Grease Gun

To apply grease to adjust track sag.

Continued on next page

CED,OUOE003,1220 -19-26SEP98-13/17

Track System

01
0130
4

Service Jack 18-t (20-Ton)

To place under track recoil spring disassembly and assembly tool.

CED,OUOE003,1220 -19-26SEP98-14/17

Track Recoil Spring Disassembly and Assembly Tool ST4920¹

To compress the track recoil spring for disassembly and assembly.

¹Fabricated tool, dealer made. (See Section 99 for instructions to make tool.)

CED,OUOE003,1220 -19-26SEP98-15/17

Spacer DFT1110¹

Installed on bottom plate of ST4920 Track Recoil Spring Disassembly and Assembly Tool to protect piston from downward force during disassembly and assembly.

¹Fabricated tool, dealer made. (See Section 99 for instructions to make tool.)

CED,OUOE003,1220 -19-26SEP98-16/17

Track Recoil Spring Disassembly and Assembly Guard Tool DFT1087¹

Used with ST4920 Track Recoil Spring Disassembly and Assembly Tool.

¹Fabricated tool, dealer made. (See Section 99 for instructions to make tool.)

CED,OUOE003,1220 -19-26SEP98-17/17

Track System

01
0130
5**OTHER MATERIAL**

Number	Name	Use
PT569 (U.S.) TY6332 (Canadian)	NEVER-SEEZ® Anti-Seize Lubricant	Apply to pin, bracket bore, and shaft for carrier and lower track rollers and front idler.
TY16285 (U.S.) TY9485 (Canadian) 7649 (LOCTITE®)	Cure Primer	Cleans and cures surfaces prior to application of adhesives or sealants.
TY9375 (U.S.) TY9480 (Canadian) 592 (LOCTITE®)	Pipe Sealant	Apply to threads of plug for installation.
TY2098 (U.S.)	Multi-Purpose Grease	To provide a light seal between surfaces.
T43513 (U.S.) TY9474 (Canadian) 271 (LOCTITE®)	Thread Lock and Sealer (High Strength)	Apply to threads of sprocket mounting cap screws.
T43512 (U.S.) TY9473 (Canadian) 242 (LOCTITE®)	Thread Lock and Sealer (Medium Strength)	Apply to threads of front idler plug.

NEVER-SEEZ is a trademark of Emhart Chemical Group.
LOCTITE is a trademark of Loctite Corp.

CED,OUOE003,503 -19-14MAY98-1/1

Track System

01
0130
6**SPECIFICATIONS**

Item	Measurement	Specification
Track Roller:		
Track Roller Tread	OD	155.0 mm (6.10 in.) new
	OD	149.0 mm (5.87 in.) minimum used
Machine	Weight	23 773 kg (52,410 lb) approximate
Track Roller	Weight	38 kg (84 lb) approximate
Roller-to-Frame Cap Screw	Torque	450 N•m (335 lb-ft)
Roller Guard-to-Frame Cap Screw	Torque	450 N•m (335 lb-ft)
Oil Cavity Air Test	Pressure	110 ± 18 kPa (1.1 ± 0.3 bar) (16 ± 4 psi)
Track Carrier Roller:		
Track Carrier Roller Tread	OD	120.0 mm (4.72 in.) new
	OD	110.0 mm (4.33 in.) minimum used
Roller-to-Track Frame Cap Screw	Torque	265 N•m (195 lb-ft)
Thrust Washer-to-Support Shaft Cap Screw	Torque	64 N•m (47 lb-ft)
Track Shoe (SN —599999):		
Three Bar Grouser	Height	26.0 mm (1.02 in.) new
	Height	15.0 mm (0.59 in.) minimum used
Shoe-to-Link Cap Screw	Torque	298 N•m (220 lb-ft) plus 1/2 turn
Track Shoe (SN 600000—):		
Three Bar Grouser	Height	25.5 mm (1.00 in.) new
	Height	15.0 mm (0.59 in.) minimum used
Shoe-to-Link Cap Screw	Torque	298 N•m (220 lb-ft) plus 1/2 turn

Continued on next page

CED,OUOE003,1153 -19-18SEP98-1/3

Track System

01
0130
7

Item	Measurement	Specification
Track Chain:		
Track Chain Link	Height Height	105.0 mm (4.13 in.) new 98.0 mm (3.86 in.) minimum used
Track Chain Bushing	OD OD	59.0 mm (2.32 in.) new 54.0 mm (2.13 in.) minimum used
Track Chain	Pitch Pitch	762.0 mm (30.00 in.) new 780.0 mm (30.71 in.) maximum used
Track with 800 mm (32 in.) Shoe	Weight	1745 kg (3846 lb) approximate
Shoe-to-Link Cap Screw	Torque	298 N•m (220 lb-ft) plus 1/2 turn
Machine	Weight	23 773 kg (52,410 lb) approximate
Track	Sag	300—335 mm (11-13/16—13-3/16 in.)
Nut and Valve Assembly	Torque	147 N•m (108 lb-ft)
Sprocket:		
Sprocket	Weight	45 kg (98 lb) approximate
Sprocket Cap Screw	Torque	470 N•m (350 lb-ft)
Front Idler:		
Front Idler Flange	Height Height	19.0 mm (0.75 in.) new 23.0 mm (0.91 in.) maximum used
Front Idler with Yoke	Weight	113 kg (250 lb) approximate
Yoke-to-Bracket Cap Screw	Torque	206 N•m (152 lb-ft)
Oil Cavity Air Test	Pressure	110 ± 28 kPa (1.1 ± 0.3 bar) (16 ± 4 psi)
Track Adjuster and Recoil Spring:		
Track Adjuster Cylinder and Recoil Spring	Weight	118 kg (260 lb) approximate

Track System

01
0130
8

Item	Measurement	Specification
Track Recoil Spring Disassembly and Assembly Tool	Weight	225 kg (496 lb) approximate
Recoil Spring	Free Length Compressed Length	689 mm (27 in.) approximate 577 mm (22.7 in.)
Valve	Torque	147 N•m (110 lb-ft)
Flange-to-Cylinder Cap Screw	Torque	64 N•m (47 lb-ft)

CED,OUOE003,1153 -19-18SEP98-3/3

MEASURE TRACK ROLLER WEAR

Minimum used is the maximum allowable wear for rebuilding roller tread.

Under some conditions roller wear can be uneven. If wear is uneven, rollers may be interchanged to even out the wear.

Measure roller tread diameter using a caliper such as the JT05519 Special Roller Caliper from JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.



T87973 -UN-08NOV88

TX,01,UU3837 -19-08MAY98-1/1

Track System

CARRIER ROLLER TREAD DIAMETER

Allowable Wear—10.0 mm (0.39 in.)

Dimension	Percent Worn
120.0 mm (4.72 in.)	0
119.5 mm (4.70 in.)	5
119.0 mm (4.69 in.)	10
118.5 mm (4.67 in.)	15
118.0 mm (4.65 in.)	20
117.5 mm (4.63 in.)	25
117.0 mm (4.61 in.)	30
116.5 mm (4.59 in.)	35
116.0 mm (4.57 in.)	40
115.5 mm (4.55 in.)	45
115.0 mm (4.53 in.)	50
114.5 mm (4.51 in.)	55
114.0 mm (4.49 in.)	60
113.5 mm (4.47 in.)	65
113.0 mm (4.45 in.)	70
112.5 mm (4.43 in.)	75
112.0 mm (4.41 in.)	80
111.5 mm (4.39 in.)	85
111.0 mm (4.37 in.)	90
110.5 mm (4.35 in.)	95
110.0 mm (4.33 in.)	100
109.5 mm (4.31 in.)	105
109.0 mm (4.29 in.)	110
108.5 mm (4.27 in.)	115
108.0 mm (4.25 in.)	120



T6813AQ -JUN-29JAN98

01
0130
9

Track System

01
0130
10

REMOVE AND INSTALL TRACK ROLLER

1. Swing upperstructure 90° and lower bucket to raise track off ground. Keep angle between boom and arm 90—110° and position round side of bucket on ground.


CAUTION: Prevent possible injury from unexpected machine movement. Put shop stands under frame to support machine while removing lower track roller.

The approximate weight of machine is 23 773 kg (52,410 lb).

Machine—Specification

Weight..... 23 773 kg (52,410 lb)
approximate

2. Put shop stands under machine.




T6876FG -UN-06DEC88

TX,01,UU3838 -19-18SEP98-1/3

CAUTION: Prevent possible injury from high pressure grease. Do not remove grease fitting (A) from valve (B).

3. Loosen valve (B) one to two turns to release grease through bleed hole (C).



A—Grease Fitting
B—Valve
C—Bleed Hole

T7396DZ -UN-28NOV90

Continued on next page

TX,01,UU3838 -19-18SEP98-2/3

Track System

01
0130
11




CAUTION: The approximate weight of track roller is 38 kg (84 lb).

Track Roller—Specification

Weight..... 38 kg (84 lb) approximate

4. Attach hoist to track roller (B). Remove cap screws (A) and track roller (B).
5. Repair or replace parts where necessary. (See following procedure in this group.)
6. Install roller on track link with flat portion of bracket pointing toward undercarriage.
7. Lower excavator enough to allow cap screws (A) to be installed.
8. Tighten cap screws.



T6685TN -UN-25OCT88

A—Cap Screw (4 used)
B—Track Roller

Roller-to-Frame Cap Screw—Specification

Torque 450 N•m (335 lb-ft)

9. Install roller guard and tighten cap screws.

Roller Guard-to-Frame Cap Screw—Specification


Torque 450 N•m (335 lb-ft)

10. Adjust track sag. (See procedure in this group).

Track System

01
0130
12

DISASSEMBLE AND ASSEMBLE TRACK ROLLER



TB310AG (CV)

TB310AG -UN-27SEP94

- | | | | |
|-------------------------------|----------------|-----------------------|--------|
| A—Bracket | E—Bracket | H—Plug (2 used) (SN — | I—Axle |
| B—Roller | F—O-Ring | 599999) Plug (1 used) | |
| C—Bushing (2 used) | G—Pin (2 used) | (SN 600000—) | |
| D—Metal Face Seal
(2 used) | | | |


1. Remove plug (H) using a 6 mm hex key wrench and drain oil.
2. Remove pin (G) using a 14 mm driver.
3. Remove bracket (E) using a bearing puller attachment and adapters from puller set.
4. Remove metal face seal (D) from roller and bracket. Keep seal rings together as a matched set with seal ring faces together to protect surfaces.
5. Inspect metal face seals. (See procedure in this group.) For seals that will be reused, put a piece of cardboard between seal rings to protect seal face.
6. Remove axle (I) from roller (B).
7. Remove bushing (C) using a 2 jaw puller and adapters from puller set.
8. Replace parts as necessary.

NOTE: Only remove bushing if replacement is necessary.

IMPORTANT: Metal face seals can be reused if they are not worn or damaged. A used seal must be kept together as a set because of wear patterns on seal ring face.

Track System

01
0130
13



A—Plug (2 used) (SN — 599999) Plug (1 used) (SN 600000—)

B—Bracket (2 used)
C—Pin (2 used)
D—O-Ring (2 used)

E—Metal Face Seal (2 used)
F—Bushing (2 used)

G—Roller
H—Axle

9. Apply a thin film of oil to bushings (F). Install bushings.

10. Install O-ring (D) on axle (H).

IMPORTANT: O-rings and seat surfaces for O-rings must be clean, dry, and oil free so O-rings do not slip when roller is turning.

11. Thoroughly clean O-rings and seat surfaces in brackets (B) and in seal rings using volatile, non-petroleum base solvent and lint-free tissues.

12. Install O-ring in seal rings.

13. Install seals (E) in brackets (B) and in roller (G). Apply equal pressure with fingers at four equally spaced points on seal face. Seal must “pop” down into place so O-ring is tight against seal bore. A volatile, non-petroleum base solvent or talcum powder may be used as a lubricant.

14. Wipe finger prints and foreign material off seal ring face using clean oil and lint-free tissues. Apply a thin film of oil to each seal ring face.

15. Apply a thin layer of NEVER-SEEZ® lubricant or an equivalent to pin (C). Install pin even with the flat surface of bracket.

16. Install axle to bracket.

17. Apply NEVER-SEEZ® lubricant or equivalent to pin (C). Install pin flush with the flat surface of bracket.

18. Install axle and assembled parts to roller (G).

19. Add approximately 256 mL (8.66 fl oz) of oil. (See Track Roller, Front Idler, and Carrier Roller Oil in Group 0004).

20. Repeat procedure for other side of axle.


T8310AH -UN-21SEP94

Track System

01
0130
14

TEST TRACK ROLLER FOR OIL LEAKAGE

1. Hold the shaft and turn shell several turns to seat metal face seals.
2. Remove the hex socket plug from end of roller.
3. Install parts (A—F). Plug, adapter and connector are from a leak detector kit such as the D05361ST Rubber Stopper/Leak Detector Kit.
4. Holding plug so it is not pushed out, slowly pressurize oil cavity using air.



T109691B -UN-02JUN97

- A—Adapter, Connector and Rubber Plug
- B—Connector 1/8 M NPT x 7/16-20 M 37°
- C—Air Hose
- D—Pressure Gauge
- E—Snubber (Needle) Valve
- F—Air Pressure Regulator

Oil Cavity Air Test—Specification

Pressure 110 ± 18 kPa (1.1 ± 0.3 bar)
(16 ± 4 psi)

5. Close valve and wait for a minimum of 30 seconds. Check for oil leakage. Check gauge to see if air pressure has decreased.
6. If there is leakage, disassemble roller and replace parts as necessary.
7. Clean threads of plug using cure primer. Apply pipe sealant to threads. Install plug.

TX,01,UU3840 -19-18SEP98-1/1

MEASURE TRACK CARRIER ROLLER WEAR

Used minimum tread diameter is the maximum allowable wear for rebuilding wear surface.

Measure roller tread diameter using a caliper such as the JT05519 Special Roller Caliper from JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.



T6813AQ -UN-29JAN98

TX,01,UU3841 -19-17SEP98-1/1

Track System

CARRIER ROLLER TREAD DIAMETER

Allowable Wear—10.0 mm (0.39 in.)

Dimension	Percent Worn
150.0 mm (5.91 in.)	0
149.5 mm (5.89 in.)	5
149.0 mm (5.87 in.)	10
148.5 mm (5.85 in.)	15
148.0 mm (5.83 in.)	20
147.5 mm (5.81 in.)	25
147.0 mm (5.79 in.)	30
146.5 mm (5.77 in.)	35
146.0 mm (5.75 in.)	40
145.5 mm (5.73 in.)	45
145.0 mm (5.71 in.)	50
144.5 mm (5.69 in.)	55
144.0 mm (5.67 in.)	60
143.5 mm (5.65 in.)	65
143.0 mm (5.63 in.)	70
142.5 mm (5.61 in.)	75
142.0 mm (5.59 in.)	80
141.5 mm (5.57 in.)	85
141.0 mm (5.55 in.)	90
140.5 mm (5.53 in.)	95
140.0 mm (5.51 in.)	100
139.5 mm (5.49 in.)	105
139.0 mm (5.47 in.)	110
138.5 mm (5.45 in.)	115
138.0 mm (5.43 in.)	120



T6813AQ -JUN-29JAN98

01
0130
15


Track System

01
0130
16

REMOVE AND INSTALL TRACK CARRIER ROLLER

CAUTION: Prevent possible injury from high pressure grease. Do not remove grease fitting (A) from valve (B).

1. Loosen valve (B) one to two turns to release grease through bleed hole (C).



A—Grease Fitting
B—Valve
C—Bleed Hole

T7396DZ -UN-28NOV90

TX,01,UU3842 -19-18SEP98-1/4

2. Raise track link, using a jack, enough to permit carrier roller removal.

CAUTION: Prevent accidental lowering of track by securely supporting track before attempting service procedure.

3. Install wooden blocks between track link and frame.




T108834B -UN-02JUN97

TX,01,UU3842 -19-18SEP98-2/4

4. Remove cap screws (B) and carrier roller (A).
5. Repair or replace parts as necessary. (See following procedure in this group.)
6. Install carrier roller and tighten cap screws (B).

Roller-to-Track Frame Cap Screw—Specification

Torque 265 N•m (195 lb-ft)



T108836B -UN-03APR97

Continued on next page

TX,01,UU3842 -19-18SEP98-3/4

Track System

7. Remove wooden blocks and jack.
8. Adjust track sag. (See procedure in this group).




T108834B -UN-02JUN97

TX,01,UU3842 -19-18SEP98-4/4

01
0130
17

01
0130
18

DISASSEMBLE AND ASSEMBLE TRACK CARRIER ROLLER



T114725

A—Plug
B—Cover

C—Cap Screw (2 used)
D—Thrust Washer

E—Bushing
F—Roller

G—Metal Face Seal
H—Support

1. Remove plug (A), using an 8 mm hex key wrench, to drain oil.

2. Remove two cap screws (C) using an 8 mm hex head wrench through oil plug drain hole.

T114725 -UN-30APR98

Track System

01
0130
19

3. Remove roller (F) from support (H).

IMPORTANT: Replace entire roller assembly if bushing (E) and shaft surfaces are damaged. Bushing (E) is no longer serviceable because cover (B) cannot be removed.

4. Inspect bushing (E) and shaft on support (H).

IMPORTANT: Leaks may occur if reused seals are not kept together as a matched set.

5. Remove metal face seal (G) from roller (F) and support (H). Keep seal rings together as a matched set with faces together to protect surfaces.

6. Inspect metal face seal. (See procedure listed in this group.) Metal face seals may be reused if they are not worn or damaged.

7. Replace parts as necessary.

IMPORTANT: O-rings may slip when roller is turning if O-rings and seat surfaces are not clean, dry and oil free.

8. Thoroughly clean the O-rings and seat surfaces in roller, support, and seal bushings using a volatile, non-petroleum base solvent and lint-free tissue.

9. Install O-ring on seal rings.

NOTE: Current carrier roller metal face seals use a tapered fit. There is no longer the "pop" into place fit previously used.

A volatile, non-petroleum base solvent or talcum powder may be used as a lubricant.

10. Install one half of metal face seal into support (H).

11. Apply a thin coat of oil to the metal faces on each half of the seal. (See Track Roller, Front Idler, and Carrier Roller Oil in Group 0004.)

12. Install the other half of metal face seal on the half already in place in support (H).

13. Install roller (F) over shaft on support (H) being sure to keep cap screws (C) in alignment with holes on shaft.

14. Tighten cap screws (C).

Thrust Washer-to-Support Shaft Cap Screw—Specification

Torque..... 64 N•m (47 lb-ft)

15. Fill carrier roller with approximately 85 mL (2.9 oz) of clean oil through plug (A) hole. (See Track Roller, Front Idler, and Carrier Roller Oil in Group 0004.)

16. Clean threads of plug (B) using cure primer.

17. Apply pipe sealant to thread of plug. Install plug.


Track System

01
0130
20

INSPECT METAL FACE SEALS

1. Inspect for the following conditions to determine if seal rings (A) can be reused:

- The narrow, highly polished sealing area (E) must be in the outer half of seal ring face (D).
- Sealing area must be uniform and concentric with the ID and OD of seal ring (A).
- Sealing area must not be chipped, nicked, or scratched.



A—Seal Ring
B—Worn Area (Shaded Area)
C—Seal Ring Face
D—Outer Half of Seal Ring Face
E—Sealing Area (Dark Line)


T85079 -UN-24AUG93

TX,01,VV2870 -19-05DEC96-1/3

2. Illustration shows examples of worn seal rings (A).

I—Sealing area (D) is in inner half of seal ring face (C).

II—Sealing area (D) not concentric with ID and OD of seal ring.



A—Seal Ring
B—Worn Area (Shaded Area)
C—Inner Half of Seal Ring Face
D—Sealing Area (Dark Line)


T85080 -UN-05DEC96

Continued on next page

TX,01,VV2870 -19-05DEC96-2/3

Track System

3. Clean seals to be reused by removing all foreign material from seal rings, except seal face (A), using a scraper or a stiff bristled fiber brush.
4. Wash seal rings and O-rings using a volatile, non-petroleum base solvent to remove all oil. Thoroughly dry parts using a lint-free tissue.
5. Apply a thin film of oil to seal ring face. Put face of seal rings together and hold using tape.



A—Seal Face

01
0130
21


T82840 -UN-23FEB89

TX,01,VV2870 -19-05DEC96-3/3

MEASURE TRACK SHOE GROUSER WEAR

Minimum used is the maximum allowable wear for rebuilding grouser bars with weld.

Measure grouser height of several track shoes to find an average using a depth gauge such as the JT05521 200 mm Ruler, JT05534 Right Angle Attachment, and D05231ST 300 mm Ruler from JT05518A or JT0552 Undercarriage Inspection Service Tool Kit.



Three Bar Grouser—Specification

Height 25.5 mm (1.00 in.) new
 Height 18.0 mm (0.71 in.) minimum used

T82859 -UN-08NOV88

AG,OUOE042,35 -19-10MAR99-1/1


Track System

01
0130
22

1010 THREE BAR GROUSER HEIGHT

Allowable Wear—6.5 mm (0.26 in.)

Dimension	Percent Worn
15.5 mm (0.61 in.)	0
15.2 mm (0.60 in.)	5
14.9 mm (0.58 in.)	10
14.5 mm (0.57 in.)	15
14.2 mm (0.56 in.)	20
13.9 mm (0.55 in.)	25
13.6 mm (0.53 in.)	30
13.2 mm (0.52 in.)	35
12.9 mm (0.51 in.)	40
12.6 mm (0.50 in.)	45
12.3 mm (0.48 in.)	50
11.9 mm (0.47 in.)	55
11.6 mm (0.46 in.)	60
11.3 mm (0.44 in.)	65
11.0 mm (0.43 in.)	70
10.6 mm (0.42 in.)	75
10.3 mm (0.41 in.)	80
10.0 mm (0.39 in.)	85
9.7 mm (0.38 in.)	90
9.3 mm (0.37 in.)	95
9.0 mm (0.35 in.)	100
8.7 mm (0.34 in.)	105
8.4 mm (0.33 in.)	110
8.0 mm (0.32 in.)	115
7.7 mm (0.30 in.)	120



T6813AP -UN-29JAN98


Track System

01
0130
23

1010 FRONT IDLER FLANGE HEIGHT

Allowable Wear—3.9 mm (0.15 in.)

Dimension	Percent Worn
19.1 mm (0.75 in.)	0
19.3 mm (0.76 in.)	5
19.5 mm (0.77 in.)	10
19.7 mm (0.78 in.)	15
19.9 mm (0.78 in.)	20
20.1 mm (0.79 in.)	25
20.3 mm (0.80 in.)	30
20.5 mm (0.81 in.)	35
20.7 mm (0.81 in.)	40
20.9 mm (0.82 in.)	45
21.1 mm (0.83 in.)	50
21.2 mm (0.84 in.)	55
21.4 mm (0.84 in.)	60
21.6 mm (0.85 in.)	65
21.8 mm (0.86 in.)	70
22.0 mm (0.87 in.)	75
22.2 mm (0.87 in.)	80
22.4 mm (0.88 in.)	85
22.6 mm (0.89 in.)	90
22.8 mm (0.90 in.)	95
23.0 mm (0.91 in.)	100
23.2 mm (0.91 in.)	105
23.4 mm (0.92 in.)	110
23.6 mm (0.93 in.)	115
23.8 mm (0.94 in.)	120



T72258A -JUN-21FEB90

Track System

01
0130
24

FRONT IDLER FLANGE HEIGHT

Allowable Wear—4.0 mm (0.16 in.)

Dimension	Percent Worn
19.0 mm (0.75 in.)	0
19.2 mm (0.76 in.)	5
19.4 mm (0.76 in.)	10
19.6 mm (0.77 in.)	15
19.8 mm (0.78 in.)	20
20.0 mm (0.79 in.)	25
20.2 mm (0.80 in.)	30
20.4 mm (0.80 in.)	35
20.6 mm (0.81 in.)	40
20.8 mm (0.82 in.)	45
21.0 mm (0.83 in.)	50
21.2 mm (0.83 in.)	55
21.4 mm (0.84 in.)	60
21.6 mm (0.85 in.)	65
21.8 mm (0.86 in.)	70
22.0 mm (0.87 in.)	75
22.2 mm (0.87 in.)	80
22.4 mm (0.88 in.)	85
22.6 mm (0.89 in.)	90
22.8 mm (0.90 in.)	95
23.0 mm (0.91 in.)	100
23.2 mm (0.91 in.)	105
23.4 mm (0.92 in.)	110
23.6 mm (0.93 in.)	115
23.8 mm (0.94 in.)	120




T6813AR -UN-29JAN98

Track System

01
0130
25

REMOVE AND INSTALL TRACK SHOE


1. Remove nuts, cap screws, and shoe.
2. Apply a light coat of oil to cap screw threads and install shoe.
3. Install all track shoe nuts with rounded corners (A) against the link and chamfered edges (B) away from the link. Be sure nut is properly positioned in the link so there is full contact between the nut and the link.
4. Tighten cap screws in pattern shown.




T6657DO -UN-25OCT88

Shoe-to-Link Cap Screw—Specification

Torque 298 N•m (220 lb-ft) plus 1/2 turn



T6794AM -UN-23FEB89



T6352AH -UN-23FEB89


Track Shoe Tightening Pattern

A—Rounded Edge
B—Chamfered Edge

*Track System*01
0130
26**MEASURE TRACK CHAIN LINK WEAR**

Minimum used is the maximum allowable wear for rebuilding links.

Measure height of several links to find an average using a depth gauge such as the JT05521 200 mm Ruler, JT05534 Right Angle Attachment, and D05231ST 300 mm Ruler from JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.



T82864 -UN-08NOV88


TX,01,UU3846 -19-03APR98-1/1

Track System

230LCR/230LCRD LINK HEIGHT

Allowable Wear—7.0 mm (0.28 in.)

Dimension	Percent Worn
105.0 mm (4.13 in.)	0
104.7 mm (4.12 in.)	5
104.3 mm (4.11 in.)	10
104.0 mm (4.09 in.)	15
103.6 mm (4.08 in.)	20
103.3 mm (4.06 in.)	25
102.9 mm (4.05 in.)	30
102.6 mm (4.04 in.)	35
102.2 mm (4.02 in.)	40
101.9 mm (4.01 in.)	45
101.5 mm (4.00 in.)	50
101.2 mm (3.98 in.)	55
100.8 mm (3.97 in.)	60
100.5 mm (3.95 in.)	65
100.1 mm (3.94 in.)	70
99.8 mm (3.93 in.)	75
99.4 mm (3.91 in.)	80
99.1 mm (3.90 in.)	85
98.7 mm (3.89 in.)	90
98.4 mm (3.87 in.)	95
98.0 mm (3.86 in.)	100
97.7 mm (3.84 in.)	105
97.3 mm (3.83 in.)	110
97.0 mm (3.82 in.)	115
96.6 mm (3.80 in.)	120



T6813AO -UN-29JAN98

01
0130
27

TX,07,SB5509 -19-26SEP97-1/1

MEASURE TRACK CHAIN BUSHING WEAR

Minimum used is the maximum allowable wear for turning pins and bushings.

Measure bushing outer diameter at the two worn places using a caliper such as the D17524C1 100 mm Caliper from JT05518A Undercarriage Inspection Service Tool Kit.



T82865 -UN-08NOV88

TX,01,UU3847 -19-03APR98-1/1


Track System

01
0130
28

BUSHING OUTER DIAMETER

Allowable Wear—5.0 mm (0.20 in.)

Dimension	Percent Worn
59.0 mm (2.32 in.)	0
58.8 mm (2.31 in.)	5
58.5 mm (2.30 in.)	10
58.3 mm (2.29 in.)	15
58.0 mm (2.28 in.)	20
57.8 mm (2.27 in.)	25
57.5 mm (2.26 in.)	30
57.3 mm (2.25 in.)	35
57.0 mm (2.24 in.)	40
56.8 mm (2.23 in.)	45
56.5 mm (2.22 in.)	50
56.3 mm (2.21 in.)	55
56.0 mm (2.20 in.)	60
55.8 mm (2.19 in.)	65
55.5 mm (2.19 in.)	70
55.3 mm (2.18 in.)	75
55.0 mm (2.17 in.)	80
54.8 mm (2.16 in.)	85
54.5 mm (2.15 in.)	90
54.3 mm (2.14 in.)	95
54.0 mm (2.13 in.)	100
53.8 mm (2.12 in.)	105
53.5 mm (2.11 in.)	110
53.3 mm (2.10 in.)	115
53.0 mm (2.09 in.)	120




T6813AK -UN-29JAN98

AG,OUOE042,37 -19-10MAR99-1/1

*Track System***MEASURE TRACK CHAIN PITCH**

Maximum used is the maximum allowable wear for turning pins and bushings.

1. Remove slack by putting a wooden block between sprocket and chain; then slowly move machine in reverse to tighten chain.
2. Measure pitch across several four-link sections as shown, except section on either side of master pin, to find average chain wear. Use a tape measure such as the JT05520 Metric Tape from JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.

01
0130
29

T6813AL -JUN-29JAN98

TX,01,UU3848 -19-06MAY98-1/1


Track System

01
0130
30

PITCH 190.50 MM (7.50 IN.)

Allowable Wear—18.0 mm (0.71 in.)

Dimension	Percent Worn
762.0 mm (30.00 in.)	0
762.9 mm (30.04 in.)	5
763.8 mm (30.07 in.)	10
764.7 mm (30.11 in.)	15
765.6 mm (30.14 in.)	20
766.5 mm (30.18 in.)	25
767.4 mm (30.21 in.)	30
768.3 mm (30.25 in.)	35
769.2 mm (30.28 in.)	40
770.1 mm (30.32 in.)	45
771.0 mm (30.35 in.)	50
771.9 mm (30.39 in.)	55
772.8 mm (30.43 in.)	60
773.7 mm (30.46 in.)	65
774.6 mm (30.50 in.)	70
775.5 mm (30.53 in.)	75
776.4 mm (30.57 in.)	80
777.3 mm (30.60 in.)	85
778.2 mm (30.64 in.)	90
779.1 mm (30.67 in.)	95
780.0 mm (30.71 in.)	100
780.9 mm (30.74 in.)	105
781.8 mm (30.78 in.)	110
782.7 mm (30.81 in.)	115
783.6 mm (30.85 in.)	120



T6813AL -JUN-29JAN98


Track System

01
0130
31

REMOVE TRACK CHAIN

CAUTION: Prevent possible injury from high pressure grease. Do not remove grease fitting (A) from valve (B).

1. Loosen valve (B) one to two turns to release grease through bleed hole (C).




A—Grease Fitting
B—Valve
C—Bleed Hole

T7396DZ -JUN-28NOV90

TX,01,UU3849 -19-18SEP98-1/3

NOTE: Disconnect track chain at the end of track frame where the work is to be done.

2. Move track chain so master pin (A) is over front idler.
3. Remove snap ring (B).
4. Remove the track shoe on each side of master pin.
5. Put wooden blocks in front of idler and under chain so chain does not fall when master pin is removed.
6. Raise machine so sprocket teeth clear chain.



A—Master Pin
B—Snap Ring

T6585TH -JUN-25OCT88

Continued on next page

TX,01,UU3849 -19-18SEP98-2/3

Track System

01
0130
32

NOTE: The OD of master pin at the snap ring end is larger than the other end. The master pin OD differences shown are exaggerated.


7. Remove master pin (A) through SNAP RING SIDE of track using a 50-Ton Master Pin Pusher Installer.
8. Pry apart chain and lower end of track.
9. Remove spacers (B).

CAUTION: The approximate weight of each track with 800 mm (32 in.) shoes is 1745 kg (3846 lb).


Type I Track 800 mm (32 in.) Shoe—Specification

Weight..... 1745 kg (3846 lb) approximate

10. Slowly turn sprocket in reverse direction to remove track chain from excavator.



T7945AA (CV)



- A—Master Pin
- B—Spacer (2 used)
- C—Link
- D—Master Bushing
- E—Link
- F—Master Link
- G—Snap Ring

T7945AA -UN-23APR93

T6876BO -UN-06DEC88

Track System

INSTALL TRACK CHAIN


1. Position track chain so section on ground has pin boss on links toward rear of unit.
2. Install end of chain on sprocket and slowly turn sprocket in forward direction to pull chain across top of frame to front idler.
3. Install spacers. Pull ends of chain together.



T6557DN -UN-25OCT88

TX,01,UU3850 -19-18SEP98-1/3

4. Install master pin (A) and snap ring (B) from SNAP RING SIDE of track.
5. Lower machine.



T6555TH -UN-25OCT88

A—Master Pin
B—Snap Ring


Continued on next page

TX,01,UU3850 -19-18SEP98-2/3

Track System

01
0130
34

6. Apply a light coat of oil to cap screws threads and install shoes.
7. Install all track shoe nuts with rounded edges (A) against the link and chamfered edges (B) away from the link. Be sure nut is properly positioned in the link so there is full contact between the nut and the link.
8. Tighten cap screws in the sequence shown.




T6557DO -UN-25OCT88


Shoe-to-Link Cap Screw—Specification

Torque 298 N•m (220 lb-ft) plus 1/2 turn

9. Adjust track sag. (See procedure in this group.)



T6794AM -UN-23FEB89




T6352AH -UN-23FEB89

A—Rounded Edge
B—Chamfered Edge

Track System

01
0130
35

DISASSEMBLE AND ASSEMBLE TRACK CHAIN



T117027

A—Track Link (51 used)
B—Master Track Link
C—Master Pin
D—Snap Ring

E—Master Bushing
F—Spacer (2 used)
G—Track Link (50 used)
H—Seal (100 used)

I—Bushing (50 used)
J—Shoe (51 used)
K—Pin (50 used)

L—Chamfer Side (Bushing Side)

1. Measure track components (A—K). (See procedures in this group. For more detailed

measurements, see the SP326 Undercarriage Appraisal Manual.)

Continued on next page

AG.OUOE042.39 -19-10MAR99-1/2

T117027 -UN-09SEP98

Track System

01
0130
36

NOTE: Wear on pins and bushings does not extend over the entire surface. Turning pins and bushing is determined by the amount of wear.

2. Turn pins (C and K) and bushings (E and I). (See the manufacturer's operator manual for your track press.)
3. Clean any dust or rust from the surfaces of track link pin bores and counterbores and the ends of bushings.

4. Apply grease to the counterbore in track links, the seals, and the ends of bushings.
5. For each joint, fill the clearance between the pin OD and bushing ID with grease.
6. Install seal (H) so tapered side (L) is toward bushing.

AG,OUOE042,39 -19-10MAR99-2/2


DISASSEMBLE AND ASSEMBLE TRACK CHAIN TO REPLACE BROKEN PART

NOTE: It is not necessary to completely disassemble a chain to replace a broken part. If a track press is available, refer to the operator's manual. If a track press is not available, do the following procedure.

1. Remove track shoe from broken link assembly. Remove the track. (See procedure in this group.)

IMPORTANT: When making cuts using cutting torch, be careful not to cut or gouge good parts.

2. Cut links, bushing, and pin at points (A) to remove broken link (B).



A—Cut Locations
B—Broken Link


T5821AG -UN-26OCT88

Continued on next page

TX,01,UU3852 -19-26SEP98-1/4

Track System

3. Grind the ends of bushing (A) even with links to make it into a master bushing.




A—Bushing

01
0130
37

T5821AH -UN-26OCT88

TX,01,UU3852 -19-26SEP98-2/4

4. Burn holes through center of pin stubs (A).
5. Hold a heavy hammer (B) against the link while pin stub is being driven out.



A—Pin Stub
B—Hammer

T5821AI -UN-26OCT88

Continued on next page


TX,01,UU3852 -19-26SEP98-3/4

Track System

01
0130
38

NOTE: When new parts are ordered, have dealer assemble the new links and master bushing.

6. Install links (C and E) on master bushing (D). Check cap screw hole spacing using a track shoe.
7. Install spacers (B) into counterbore of links.
8. Install link assembly. Install the master pins (A).



- A—Master Pin
- B—Spacer
- C—Right Link
- D—Master Bushing
- E—Left Link

T5821AJ -UN-24MAY89


TX,01,UU3852 -19-26SEP98-4/4

Track System

ADJUST TRACK SAG

1. Swing upperstructure to side. Lower boom to raise track off the ground.

Keep the angle between boom and arm at 90—110° with the round side of bucket on the ground.



T6876FG -UN-06DEC88

CAUTION: Prevent possible injury from unexpected machine movement. Put blocks or shop stands under machine frame to support machine while measuring track sag.

The approximate weight of machine is 23 773 kg (52,410 lb).

Machine—Specification

Weight..... 23 773 kg (52,410 lb)
approximate

2. Put blocks or shop stands under the machine to support machine.
3. Slowly turn the track forward for two revolutions and then in reverse for two revolutions. Stop the track while moving in reverse direction so all track sag is at the bottom.

Continued on next page

TX,01,UU3853 -19-18SEP98-1/3


Track System

01
0130
40

- 4. Measure track sag (A) at middle track roller from the bottom of tack frame to the top surface of track shoe.

Track—Specification

Sag 300—335 mm
(11-13/16—13-3/16 in.)



A—Track Sag

Continued on next page

TX,01,UU3853 -19-18SEP98-2/3

Track System

01
0130
41

CAUTION: High pressure grease in track adjuster cylinder. Do not remove grease fitting or nut and valve assembly to release grease.

IMPORTANT: Prevent possible damage to track components. Do not use the grease fitting on track adjuster cylinder for lubrication. Use this grease fitting only for track sag adjustment.

5. To decrease track sag, add multi-purpose grease to track adjuster cylinder through grease fitting (A) located in access hole (D) in track frame. Use a grease gun with a maximum capacity of 68 950 kPa (690 bar) (10 000 psi).



To increase track sag, loosen nut and valve assembly (B) one turn to release grease from track adjuster cylinder through bleed hole (C) in rod.

Tighten nut and valve assembly when track sag is correct.

Nut and Valve Assembly—Specification

Torque 147 N•m (108 lb-ft)

NOTE: If piston in track adjuster cylinder does not move, remove the cylinder to make repairs. (See *Remove and Install Track Adjuster* in this group.)



- A—Grease Fitting
- B—Nut and Valve Assembly
- C—Bleed Hole
- D—Access Hole

T7396DZ -UN-28NOV90

T7869AQ -UN-22OCT92

Track System

01
0130
42

REMOVE AND INSTALL SPROCKET

IMPORTANT: Sprocket must be replaced when the tooth tips become excessively rounded, worn, or chipped to prevent excessive wear to chain. If unit is driven in one direction a majority of the time, wear will be on one side of teeth. To extend service life, change sprockets from one side of unit to the other.

1. Disconnect and remove track chain from sprocket (A). (See procedure in this group.)
2. Lift side of unit so sprocket teeth clear chain.
3. Remove cap screws (B).

CAUTION: Approximate weight of sprocket is 45 kg (98 lb).

Sprocket—Specification


Weight..... 45 kg (98 lb) approximate

4. Attach sprocket to hoist. Remove sprocket from final drive, or move sprocket to other side of machine or replace.
5. Clean threads of cap screws (B) using cure primer. Apply thread lock and sealer (high strength).
6. Install sprocket (A) and tighten cap screws (B).

Sprocket Cap Screw—Specification

Torque 470 N•m (350 lb-ft)

7. Lower machine.
8. Install track chain. (See procedure in this group.)
9. Adjust track sag. (See procedure in this group.)



T6876AL -UN-25OCT88



T6876AM -UN-25OCT88

A—Sprocket
B—Cap Screws

Track System

MEASURE FRONT IDLER WEAR

Maximum used flange height is the maximum allowable height of flange for rebuilding wear surface.

Measure height of flange using a depth gauge such as the JT05521 200 mm Ruler, JT05534 Right Angle Attachment, and D05231ST 300 mm Ruler from JT05518A or JT05523 Undercarriage Inspection Service Tool Kit.

NOTE: See Undercarriage Appraisal Manual SP326 for additional information.



T87972 -UN-08NOV88

01
0130
43

TX,01,UU3855 -19-18SEP98-1/1

Track System

01
0130
44

FRONT IDLER FLANGE HEIGHT

Allowable Wear—4.0 mm (0.16 in.)

Dimension	Percent Worn
19.0 mm (0.75 in.)	0
19.2 mm (0.76 in.)	5
19.4 mm (0.76 in.)	10
19.6 mm (0.77 in.)	15
19.8 mm (0.78 in.)	20
20.0 mm (0.79 in.)	25
20.2 mm (0.80 in.)	30
20.4 mm (0.80 in.)	35
20.6 mm (0.81 in.)	40
20.8 mm (0.82 in.)	45
21.0 mm (0.83 in.)	50
21.2 mm (0.83 in.)	55
21.4 mm (0.84 in.)	60
21.6 mm (0.85 in.)	65
21.8 mm (0.86 in.)	70
22.0 mm (0.87 in.)	75
22.2 mm (0.87 in.)	80
22.4 mm (0.88 in.)	85
22.6 mm (0.89 in.)	90
22.8 mm (0.90 in.)	95
23.0 mm (0.91 in.)	100
23.2 mm (0.91 in.)	105
23.4 mm (0.92 in.)	110
23.6 mm (0.93 in.)	115
23.8 mm (0.94 in.)	120



T6813AR -UN-29JAN98

Track System

REMOVE AND INSTALL FRONT IDLER


1. Disconnect track chain. (See procedure in this group.)
2. Slide front idler (A) forward, using pry bar.

CAUTION: The approximate weight of front idler with yoke is 113 kg (250 lb).

Front Idler with Yoke—Specification

Weight..... 113 kg (250 lb) approximate

3. Attach front idler to hoist, remove from frame, and repair or replace idler. (See procedure in this group.)
4. Install front idler and slide rearward into frame as far as possible.



A—Front Idler


T6876BU -UN-25OCT88

01
0130
45

Track System

01
0130
46

DISASSEMBLE FRONT IDLER



T102031

- | | | | |
|--------------------|------------------------------|----------------------------|----------------------|
| A—Pin (2 used) | D—Plug (2 used) | F—Metal Face Seal (2 used) | H—Axle |
| B—Bushing (2 used) | E—Bracket (Bearing) (2 used) | G—O-Ring (2 used) | I—Yoke |
| C—Idler | | | J—Cap Screw (4 used) |

1. Remove cap screws (J). Remove yoke (I).
2. Remove drain plug (D) and drain oil.

IMPORTANT: Metal face seals can be reused if they are not worn or damaged. A used seal must be kept together as a set because of wear patterns on seal ring face.

3. Remove pins (A), brackets (E), O-rings (G) and metal face seals (F).
4. Inspect metal face seals. (See procedure in this group.) Keep seal rings together as a matched set with seal ring faces together to protect surfaces.

5. Remove axle (H). Inspect axle and bushing for scoring or excessive wear.

NOTE: Remove bushings only if replacement is necessary.


6. Remove bushing using a 2-jaw puller and adapters from 17-1/2 and 30-ton puller set.
7. Replace parts as necessary.

T102031 -UN-12JUL96

Track System

01
0130
47

ASSEMBLE FRONT IDLER



- | | | | |
|--------------------|------------------------------|----------------------------|----------------------|
| A—Pin (2 used) | D—Plug (2 used) | F—Metal Face Seal (2 used) | H—Axle |
| B—Bushing (2 used) | E—Bracket (Bearing) (2 used) | G—O-Ring (2 used) | I—Yoke |
| C—Idler | | | J—Cap Screw (4 used) |

1. Apply a thin film of oil to bushings (B). Install bushings so flange is tight against shoulder of idler.
2. Install O-rings (G) on axle.
3. Apply a thin layer of NEVER-SEEZ® lubricant or an equivalent to end of axle from O-ring to end of axle and to bore in bracket (E).
4. Install axle into bracket.
5. Apply NEVER-SEEZ® lubricant or an equivalent to pin (A). Install pin.

IMPORTANT: O-rings and seat surfaces for O-rings must be clean, dry, and oil

free so O-rings do not slip when idler is turning.

6. Thoroughly clean the O-rings and seat surfaces in idler, brackets, and seal rings using volatile, non-petroleum base solvent and lint-free tissues.
 7. Install O-ring on seal rings.
- NOTE: A volatile, non-petroleum base solvent or talcum powder may be used as a lubricant.*

8. Install seals in bracket and idler. Apply equal pressure with fingers at four equally spaced points on seal face. Seal must “pop” down into place so O-ring is tight against seal bore.

Track System

01
0130
48

9. Wipe finger prints and foreign material off seal ring face using clean oil and lint-free tissues. Apply a thin film of oil to each seal face.

10. Install axle (H) into idler.

11. Repeat procedure for other side of idler.

12. Fill front idler with approximately 265 mL (8.96 oz) of oil. (See Track Roller, Front Idler and Carrier Roller Oil in Group 0004.)

13. Clean threads of drain plug (D) using cure primer.

14. Apply thread lock and sealer (medium strength) to threads of plug and install.

15. Install yoke (I). Tighten cap screws (J).

Yoke-to-Bracket Cap Screw—Specification

Torque..... 206 N•m (152 lb-ft)

TX,01,UU3858 -19-18SEP98-2/2

Track System

01
0130
49



TEST FRONT IDLER FOR OIL LEAKAGE

1. Turn the shaft several turns to seat metal face seals.
2. Remove plug (G).
3. Install parts (A—F) as shown. Plug, adapter, and connector are from a leak detector kit such as the D05361ST Rubber Stopper/Leak Detector Kit.
4. Holding plug so it is not pushed out, slowly pressurize oil cavity using air.

Oil Cavity Air Test—Specification

Pressure 110 ± 28 kPa (1.1 ± 0.3 bar)
(16 ± 4 psi)

5. Close valve and wait for a minimum of 30 seconds to check for oil leakage. Check gauge to see if air pressure has decreased.
6. If there is external leakage, disassemble idler and replace parts as necessary.
7. Check oil level in idler. If the oil level is down and there is no external leakage, check for a leak from oil cavity to interior of idler wheel.
8. Clean threads of plug using cure primer.
9. Apply thread lock and sealer (medium strength) to threads of plug. Install and tighten plug.



T109791B

- A—Plug, Adapter and Connector
- B—Connector 1/8 M NPT x 7/16-20 M 37°
- C—Hose
- D—Pressure Gauge
- E—Snubber (Needle) Valve
- F—Air Pressure Regulator
- G—Drain Plug

T109791B -UN-13JUN97

Track System

01
0130
50

REMOVE AND INSTALL TRACK ADJUSTER AND RECOIL SPRING

1. Remove track chain and front idler. (See procedures in this group.)

TX,01,UU3860 -19-18SEP98-1/3



CAUTION: Spring or rod may break if dropped while handling, transporting or disassembling. Nicks or weld craters in spring and rod assembly can cause stress concentration resulting in a weak spot. Weak spots may result in immediate or eventual failure creating a risk of personal injury. Put a heavy protective covering around spring assembly when handling, transporting, or disassembling track adjuster.

A compression tool must be used for disassembly and assembly because of the extreme preload on spring.



T6557CX -JUN-25OCT88

A—Track Adjuster

2. Slide track adjuster (A) forward, using a pry bar.

Continued on next page

TX,01,UU3860 -19-18SEP98-2/3

Track System

01
0130
51




CAUTION: The approximate weight of track adjuster cylinder and recoil spring is 118 kg (260 lb).

Track Adjuster Cylinder and Recoil Spring—Specification

Weight..... 118 kg (260 lb) approximate

3. Attach track adjuster to hoist, remove from frame, and repair or replace.



T6557CY -UN-25OCT88

TX,01,UU3860 -19-18SEP98-3/3

01
0130
52

DISASSEMBLE AND ASSEMBLE TRACK ADJUSTER AND RECOIL SPRING

CAUTION: Spring or rod may break if dropped while handling, transporting or disassembling. Nicks or weld craters in spring and rod assembly can cause stress concentration resulting in a weak spot. Weak spots may result in immediate or eventual failure creating a risk of personal injury. Put a heavy protective covering around spring assembly when handling, transporting, or disassembling track adjuster.

A compression tool must be used for disassembly and assembly because of the extreme preload on spring.

CAUTION: The approximate weight of track recoil spring disassembly and assembly tool is 225 kg (496 lb).


Track Recoil Spring Disassembly and Assembly Tool—Specification

Weight..... 225 kg (496 lb) approximate

1. Place an 18-t (20-ton) jack on bottom of ST4920 Track Recoil Spring Disassembly and Assembly Tool (A). Remove nuts (B) and top plate (C). (See Section 99 for instruction to make tool.)

NOTE: It is not necessary to remove the recoil spring to replace wear ring and U-ring packing on piston. To replace O-ring in the cylinder, remove recoil spring and rod.

2. Remove nuts (B). Remove top plate (C).



A—Recoil Spring Disassembly and Assembly Tool
B—Nuts
C—Top Plate

T6557DY -UN-25OCT88

Continued on next page

TX,01,GG2767 -19-18SEP98-1/4

Track System


01
0130
53

CAUTION: The approximate weight of track adjuster and recoil spring is 118 kg (260 lb).

Track Adjuster Cylinder and Recoil Spring—Specification

Weight..... 118 kg (260 lb) approximate

3. Connect track adjuster (B) to a hoist using a lifting strap (A).
4. Put track adjuster in assembly tool with cylinder end on DFT1110 Spacer (C). (See Section 99 For Instructions To Make Tool.)
5. Remove lifting strap.



A—Lifting Strap
B—Track Adjuster
C—DFT1110 Spacer

T7720AF -UN-28APR92

Continued on next page

TX,01,GG2767 -19-18SEP98-2/4


Track System

- 01
0130
54
6. Install DFT1087 Track Recoil Spring Disassembly and Assembly Guard Tool (F). (See Section 99 for instruction to make tool.)
 7. Install plate (A) (plate with smallest opening to allow access to nut (D)) and nuts (B) .
 8. Extend jack ram so there is enough travel to release recoil spring to the approximate free length.

Recoil Spring—Specification

Free Length 689 mm (27 in.) approximate

9. Tighten nuts (B) so plate is tight against retainer plate.
10. Remove valve (C). Remove special plug (E).



- A—Top Plate
- B—Nut (8 used)
- C—Valve
- D—Nut
- E—Special Plug
- F—DFT1087 Track Recoil Spring Disassembly and Assembly Guard Tool

T7720AG -UN-28APR92

Continued on next page

TX,01,GG2767 -19-18SEP98-3/4

Track System

01
0130
55

11. Raise upper half of guard tool (F). Tighten T-handles.
12. Operate jack to compress spring just enough so nut (D) can be removed.
13. Lower jack ram to release spring force.
14. Disassemble and assemble track adjuster cylinder. (See procedure in this group.)
15. Put track adjuster cylinder in assembly in assembly tool with cylinder end on spacer.
16. Install spacer on rod.
17. Install spring using a hoist and lifting strap.
18. Install retainer plate.
19. Install guard tool.
20. Install top plate. Install nuts.
21. Raise upper half of guard tool. Tighten T-handles.
22. Operate jack to compress spring to the compressed length.

Recoil Spring—Specification


Compressed Length 577 mm (22.7 in.)

23. Install nut (D) so hole is aligned with hole in rod.
Install special plug.

24. Tighten valve.

Valve—Specification

Torque 147 N•m (110 lb-ft)




A—Top Plate
B—Nut (8 used)
D—Nut
F—DFT1087 Track Recoil Spring Disassembly and Assembly Guard Tool

T7720AH -UN-28APR92

Track System

01
0130
56

DISASSEMBLE AND ASSEMBLE TRACK ADJUSTER CYLINDER



T102048

A—Cap Screw
B—Flange
C—Piston (Rod)
D—Wear Ring

E—U-Ring Packing
F—Snap Ring
G—Rod
H—O-Ring

I—Cylinder
J—Recoil Spring
K—Spacer
L—Retainer Plate

M—Special Plug
N—Nut
O—Valve

T102048 -UN-15JUL96

Continued on next page

TX,01,UU3862 -19-18SEP98-1/3

Track System

01
0130
57

CAUTION: Spring or rod may break if dropped while handling, transporting or disassembling. Nicks or weld craters in spring and rod assembly can cause stress concentration resulting in a weak spot. Weak spots can result in immediate or eventual failure of spring or rod creating a risk of personal injury. Put a heavy protective covering around spring assembly when handling, transporting, or disassembling.

A compression tool must be used for disassembly and assembly because of the extreme preload on spring.

NOTE: It is not necessary to remove the recoil spring to replace wear ring (D) and U-ring packing (E). To replace O-ring (H), remove recoil spring (J) and rod (G). The recoil spring is removed using the ST4920 Track Recoil Spring Disassembly and Assembly Tool. (See procedure in this group.)


1. Remove recoil spring if necessary. (See Disassemble and Assemble Track Adjuster and Recoil Spring in this group.)

Continued on next page

TX,01,UU3862 -19-18SEP98-2/3

Track System

01
0130
58



T105584

T105584 -UN-05DEC96

- | | | |
|----------------|------------------|------------|
| A—Cap Screw | D—Wear Ring | G—Rod |
| B—Flange | E—U-Ring Packing | H—O-Ring |
| C—Piston (Rod) | F—Snap Ring | I—Cylinder |

2. If necessary, remove rod (G) from cylinder (I) using a press.
3. Repair or replace parts as necessary.
4. Apply multi-purpose grease to U-ring packing (E), wear ring (D), and O-ring (H). Fill grooves inside flange (B) with grease.
5. Install U-ring packing (E) with lip towards inside of cylinder.

6. Tighten cap screws (A).

Flange-to-Rod Cap Screw—Specification

Torque..... 64 N•m (47 lb-ft)

TX,01,UU3862 -19-18SEP98-3/3

CHAPTER 12

SECTION 02

AXLES AND SUSPENSION SYSTEMS (PROPEL) REPAIR

BLANK

Group 0250

Axle Shaft, Bearings, and Reduction Gears

02
0250
1

SERVICE EQUIPMENT AND TOOLS

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company.

CED,OUOE003,506 -19-15MAY98-1/4

Propel Gearbox Nut Wrench DFT1036A¹

To remove and install propel gearbox nut.

¹*Fabricated tool, dealer made. (See Section 99 for instructions to make tool.)*

CED,OUOE003,506 -19-15MAY98-2/4

Holding Bar DFT1109¹

Used as a support guide when removing and installing propel gearbox nut.

¹*Fabricated tool, dealer made. (See Section 99 for instructions to make tool.)*

CED,OUOE003,506 -19-15MAY98-3/4

Lifting Bracket JT01748

To remove and install ring gear, drum and sprocket.

CED,OUOE003,506 -19-15MAY98-4/4

*Axle Shaft, Bearings, and Reduction Gears***OTHER MATERIAL**

Number	Name	Use
TY16285 (U.S.) TY9485 (Canadian) 7649 (LOCTITE®)	Cure Primer	Cleans and cures surface prior to application of adhesives or sealants.
T43513 (U.S.) TY9474 (Canadian) 271 (LOCTITE®)	Thread Lock and Sealer (High Strength)	Apply to threads of sprocket cap screws.
17430 (LOCTITE®) TY16021 (U.S.) TY9484 (Canadian)	High Flex Form-in-Place Gasket	Apply to mounting surface of drum.
T43514 (U.S.) TY9475 (Canadian) 277 (LOCTITE®)	Plastic Gasket	To provide a gasket-type seal between propel gearbox and cover.
TY9375 (U.S.) TY9480 (Canadian) 592 (LOCTITE®)	Pipe Sealant	Apply to threads of gearbox fill plug.

LOCTITE is a trademark of Loctite Corp.

CED,OUOE003,568 -19-19MAY98-1/1

Axle Shaft, Bearings, and Reduction Gears

SPECIFICATIONS

Item	Measurement	Specification
Propel Gearbox:		
Propel Motor and Gearbox	Weight	330 kg (728 lb) approximate
Propel Gearbox and Motor-to-Frame Cap Screw	Torque	620 N•m (460 lb-ft)
Third Planet Carrier and Gears	Weight	40 kg (88 lb) approximate
Ring Gear, Drum, and Sprocket	Weight	140 kg (310 lb)
Sprocket-to-Drum Cap Screw	Torque	470 N•m (345 lb-ft)
Ring Gear-to-Drum Cap Screw	Torque	265 N•m (195 lb-ft)
Roller Bearing Cone	Temperature	50—70°C (122—158°F)
Hub-to-Propel Motor Housing Bearing Nut	Torque	785 N•m (580 lb-ft) then tap on ring gear using a plastic hammer, turn three times right and left to seat bearing, repeat procedure
Bearing Nut-to-Hub Dowel Pin	Distance	14 mm (0.55 in.) below surface of bearing nut
Cover-to-Ring Gear Cap Screw	Torque	110 N•m (80 lb-ft)
Fill Plug	Torque	50 N•m (35 lb-ft)

CED,OUOE003,1154 -19-18SEP98-1/1

02
0250
3

TOWING THE EXCAVATOR




CAUTION: Prevent possible injury from unexpected machine movement. Block both tracks when disconnecting propel gearboxes. When propel gearboxes are disconnected, machine has no brakes and can move. The machine will roll free on a slope or while being towed.

IMPORTANT: Planetary drive shaft must be removed when towing unit to prevent damage to equipment.

1. Block tracks.
2. Drain oil from each propel gearbox. Approximate oil capacity is 6.0 L (6.5 qt).
3. Remove cover from each gearbox.

TX,02,UU3720 -19-06MAY98-1/3

4. Remove sun gear (A) from each gearbox.
5. Install cover. Fill gearbox with oil. (See Swing Gearbox and Propel Gearbox Oils in Group 0004.)



A—Sun Gear


T6879EG -JUN-06DEC88

Continued on next page

TX,02,UU3720 -19-06MAY98-2/3

Axle Shaft, Bearings, and Reduction Gears

6. Attach a tow line (A) around machine's frame as shown.



A—Tow Line


TX,02,UU3720 -19-06MAY98-3/3

T6457DV -JUN-18OCT88

02
0250
5

REMOVE AND INSTALL PROPEL GEARBOX

1. Swing upperstructure 90° and lower bucket to raise track off ground. Keep angle between boom and arm 90—110° and position round side of bucket on ground.
2. Disconnect track. (See Remove Track Chain, Group 0130.)




TX,02,UU3721 -19-18SEP98-1/3

T6876FG -JUN-06DEC88

⚠ CAUTION: Explosive release of oil from pressurized system can cause serious burns or penetrating injury. The hydraulic oil tank is pressurized.

3. Loosen vent plug (A) to relieve hydraulic pressure in hydraulic oil tank.
4. Remove propel motor cover.




A—Vent Plug

T7869AT -JUN-12NOV92

Continued on next page

TX,02,UU3721 -19-18SEP98-2/3

CAUTION: To avoid injury from escaping fluid under pressure, stop engine, and relieve the pressure in the system before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.



5. Disconnect and plug hoses (A, B, E, and F).

CAUTION: The approximate weight of propel motor and gearbox is 330 kg (728 lb).


Propel Motor and Gearbox—Specification

Weight..... 330 kg (728 lb) approximate

6. Attach propel gearbox and motor to hoist using lifting straps.

NOTE: Propel motor is removed with the gearbox because motor housing is part of gearbox. For propel motor repair, see Group 0260.

7. Remove cap screws and washers (C). Remove gearbox and motor.



Right Propel Motor Shown

8. Replace parts as necessary.

9. Install propel gearbox and motor to frame. Tighten cap screws.

Propel Gearbox and Motor-to-Frame Cap Screw—Specification

Torque 620 N•m (460 lb-ft)

10. Connect lines (A, B, E, and F).

11. Install propel motor cover.

12. Fill propel gearbox.

13. Perform propel motor start-up procedure. (See procedure in Group 0260.)


- A—Right Propel Top Port (Reverse)-to-Rotary Manifold Bottom Port
- Left Propel Bottom Port (Reverse)-to-Rotary Manifold Bottom Port
- B—Drain Port-to-Rotary Manifold Drain Port
- C—Cap Screw and Washer (14 used)
- D—Crossover Relief Valve (2 used)
- E—Right Propel Bottom Port (Forward)-to-Rotary Manifold Top Port
- Left Propel Top Port (Forward)-to-Rotary Manifold Top Port
- F—Speed Change Port-to-Rotary Manifold Port

X9811 -UN-23AUG88

T7685HI -UN-10APR92

02
0250
6

DISASSEMBLE PROPEL GEARBOX



T105593

T105593 -JUN-06DEC96

Continued on next page

TX,02,UU3672 -19-18SEP98-1/11

Axle Shaft, Bearings, and Reduction Gears

- | | | | |
|---------------------------|----------------------------|-------------------------------|----------------------------|
| 1—Third Planet Carrier | 11—Input Shaft | 21—First Planet Gear | 30—Metal Face Seal |
| 2—Third Planet Sun Gear | 12—Ring Gear | 22—Pin (3 used) | 31—Roller Bearing (2 used) |
| 3—Thrust Plate (6 used) | 13—Cap Screw (24 used) | 23—Second Planet Carrier | 32—Drum |
| 4—Second Planet Gear | 14—Thrust Pad | 24—Spring Pin (3 used) | 33—Spring Washer (16 used) |
| 5—Needle Bearing (3 used) | 15—Cover | 25—Pin (3 used) | 34—Cap Screw (16 used) |
| 6—Pin (3 used) | 16—Cap Screw (12 used) | 26—Thrust Plate (6 used) | 35—Hub |
| 7—Spring Pin (3 used) | 17—Plug (3 used) | 27—Needle Bearing (6 used) | 36—Bearing Nut |
| 8—Washer (2 used) | 18—Spring Pin (3 used) | 28—Third Planet Gear (3 used) | 37—Dowel Pin |
| 9—Second Planet Sun Gear | 19—Thrust Plate (6 used) | 29—Propel Motor | 38—Sprocket |
| 10—First Planet Carrier | 20—Needle Bearing (3 used) | | |

02
0250
9

TX,02,UU3672 -19-18SEP98-2/11




CAUTION: The approximate weight of propel motor and gearbox is 330 kg (728 lb).

Propel Motor and Gearbox—Specification

Weight..... 330 kg (728 lb) approximate

1. Remove propel gearbox.(See procedure in this group.)
2. Loosen fill plug (A).
3. Remove drain plug (C). Drain oil. Approximate capacity is 6.0 L (6.5 qt).
4. Remove cap screws (D). Remove cover.



- A—Fill Plug
- B—Level Plug
- C—Drain Plug
- D—Cap Screw (16 used)
- E—Cover

T7685HK -UN-10APR92


Continued on next page

TX,02,UU3672 -19-18SEP98-3/11

Axle Shaft, Bearings, and Reduction Gears

⚠ CAUTION: Planet gears may turn. Keep fingers away from gears.

5. Remove input shaft (B) and first planet carrier and gears (A).



T6639GK -UN-19OCT88



T7685HL -UN-10APR92

A—First Planet Carrier and Gears
B—Input Shaft

TX,02,UU3672 -19-18SEP98-4/11

⚠ CAUTION: Planet gears may turn. Keep fingers away from gears.

6. Remove second planet sun gear (B) and second planet carrier and gears (A).



T7685HM -UN-10APR92

A—Second Planet Carrier and Gears
B—Second Planet Sun Gear

Continued on next page

TX,02,UU3672 -19-18SEP98-5/11

02
0250
10

Axle Shaft, Bearings, and Reduction Gears



CAUTION: Planet gears may turn. Keep fingers away from gears.

The approximate weight of third planet carrier and gears is 40 kg (88 lb).

Third Planet Carrier and Gears—Specification

Weight..... 40 kg (88 lb) approximate

7. Remove third planet sun gear and third planet carrier and gears (A).



T6557BW -UN-19OCT88

A—Third Planet Carrier and Gears

TX,02,UU3672 -19-18SEP98-6/11

8. Push in dowel pin (B) until it completely disengages from bearing nut (A).



T7685AS -UN-19MAR92

**A—Bearing Nut
B—Dowel Pin**

Continued on next page

TX,02,UU3672 -19-18SEP98-7/11

Axle Shaft, Bearings, and Reduction Gears

9. Remove nut (C) using DFT1036A Propel Gearbox Nut Wrench (B) and DFT1109 Holding Bar (A). Fasten holding bar to ring gear. (See Section 99 for instructions to make tool.)




A—DFT1109 Holding Bar
 B—DFT1036A Propel Gearbox Nut Wrench
 C—Bearing Nut

T7685HR -UN-10APR92

TX,02,UU3672 -19-18SEP98-8/11

10. Remove hub (A).
11. Remove dowel pin (B).



A—Hub
 B—Dowel Pin

T7685HS -UN-10APR92

Continued on next page

TX,02,UU3672 -19-18SEP98-9/11

02
 0250
 12

Axle Shaft, Bearings, and Reduction Gears



CAUTION: The approximate weight of ring gear, drum, and sprocket is 140 kg (310 lb).

Ring Gear, Drum, and Sprocket—Specification


Weight..... 140 kg (310 lb)

12. Remove ring gear, drum, and sprocket (A) as an assembly using lifting brackets, such as JT01748 Lifting Brackets, lifting strap, and hoist.

Outer roller bearing (B) cone is a press fit on propel motor (C) housing.

IMPORTANT: Metal face seals can be reused if they are not worn or damaged. A used seal must be kept together as a set because of wear patterns on seal ring face.

13. Remove seal rings (E) and O-rings (D). Always keep seal rings together as a matched set with metal faces together to protect surfaces.
14. Inspect metal face seal. (See procedure in this group.) For seals that are reused, put a piece of cardboard between seal rings to protect seal ring face.
15. Remove inner roller bearing (F) cone and cups only if replacement is necessary. Bearing cone and cups are a press fit.



- A—Ring Gear, Drum, and Sprocket
- B—Outer Roller Bearing
- C—Propel Motor
- D—O-Ring (2 used)
- E—Seal Ring (2 used)
- F—Inner Roller Bearing

T7685AW -UN-19MAR92

T7685AX -UN-19MAR92


02
0250
13

Continued on next page

TX,02,UU3672 -19-18SEP98-10/11

Axle Shaft, Bearings, and Reduction Gears

16. Remove cap screws (D). Remove sprocket (C).
17. Remove cap screws (A). Remove drum (B) from ring gear (E).



T117026

- A—Cap Screw (20 used)
- B—Drum
- C—Sprocket
- D—Cap Screw (16 used)
- E—Ring Gear
- F—O-Ring

T117026 -UN-09SEP98

TX,02,UU3672 -19-18SEP98-11/11


02
0250
14

02
0250
15

INSPECT METAL FACE SEALS

1. Inspect for the following conditions to determine if seal rings (A) can be reused:

- The narrow, highly polished sealing area (E) must be in the outer half of seal ring face (D).
- Sealing area must be uniform and concentric with the ID and OD of seal ring (A).
- Sealing area must not be chipped, nicked, or scratched.



A—Seal Ring
B—Worn Area (Shaded Area)
C—Seal Ring Face
D—Outer Half of Seal Ring Face
E—Sealing Area (Dark Line)


T85079 -UN-24AUG93

TX.02.UU3673 -19-18SEP98-1/3

2. Illustration shows examples of worn seal rings (A).

I—Sealing area (D) is in inner half of seal ring face (C).

II—Sealing area (D) not concentric with ID and OD of seal ring.



A—Seal Ring
B—Wear Area (Shaded Region)
C—Inner Half of Seal Ring Face
D—Sealing Area (Dark Line)


T85080 -UN-05DEC96

Continued on next page

TX.02.UU3673 -19-18SEP98-2/3

Axle Shaft, Bearings, and Reduction Gears

3. Clean seals to be reused by removing all foreign material from seal rings, except seal face (A), using a scraper or a stiff bristled fiber brush.
4. Wash seal rings and O-rings using a non-petroleum base solvent to remove all oil. Thoroughly dry parts using a lint-free tissue.
5. Apply a thin film of oil to seal ring face. Using tape, put face of seal rings together to protect surfaces.



A—Seal Face


T82840 -UN-23FEB89

TX,02,UU3673 -19-18SEP98-3/3

DISASSEMBLE AND ASSEMBLE FIRST AND SECOND PLANET CARRIERS

NOTE: Disassembly and assembly of first and second planet carriers is the same. Keep parts for each planet carrier together.

1. Replace parts (A—G) as necessary.
2. Install thrust plates (D) so oil grooves are toward planet gear (C).



First Planet Carrier

- A—Washer
- B—Pin (3 used)
- C—Planet Gear (3 used)
- D—Thrust Plate (6 used)
- E—Needle Bearing (3 used)
- F—Spring Pin
- G—Planet Carrier

T7685HU -UN-10APR92


Continued on next page

TX,02,UU3674 -19-10DEC96-1/2

02
0250
16

Axle Shaft, Bearings, and Reduction Gears

3. Install spring pin (E) with slit (G) toward end of pin (F).



T109017

E—Spring Pin
 F—Pin
 G—Slit


T109017 -UN-17APR97

02
 0250
 17


TX,02,UU3674 -19-10DEC96-2/2

DISASSEMBLE AND ASSEMBLE THIRD PLANET CARRIER

1. Install spring pin (E) with the slit (G) towards the end of pin (F). Replace parts (A—F) as necessary.
2. Install thrust plates (D) so oil grooves are toward third planet gear (B).



T7685HV -UN-10APR92



T109017


T109017 -UN-17APR97

- A—Third Planet Carrier
- B—Third Planet Gear (3 used)
- C—Needle Bearing (6 used)
- D—Thrust Plate (6 used)
- E—Spring Pin (3 used)
- F—Pin (3 used)
- G—Slit

02
0250
18

Axle Shaft, Bearings, and Reduction Gears

ASSEMBLE PROPEL GEARBOX



TP54870

Continued on next page

TX,02,UU3676 -19-06MAY98-1/11

TP54870 -UN-08JUN97

Axle Shaft, Bearings, and Reduction Gears

- | | | | |
|---------------------------|------------------------------------|------------------------------------|---|
| 0—Propel Motor | 15—Third Planet Gear
(3 used) | 24—Needle Bearing
(3 used) | 35—Input Shaft |
| 2—Metal Face Seal | 16—Needle Bearing
(6 used) | 25—Pin (3 used) | 36—Needle Bearing
(3 used) |
| 3—Roller Bearing (2 used) | 17—Pin (3 used) | 26—Spring Pin (3 used) | 37—Cover |
| 4—Drum | 18—Spring Pin (3 used) | 27—Second Planet Sun
Gear | 39—Cap Screw and Lock
Washer (16 used) |
| 6—Cap Screw (16 used) | 19—Third Planet Sun Gear | 28—Thrust Plate (Shim)
(6 used) | 41—Plug (3 used) |
| 7—Hub | 20—Thrust Plate (Shim)
(6 used) | 29—First Planet Carrier | 43—Screw (2 used) |
| 8—Sprocket | 21—Second Planet Carrier | 30—Washer | 46—Bearing Nut |
| 9—Dowel Pin | 22—Washer | 31—First Planet Gear
(3 used) | 47—Thrust Plate (6 used) |
| 10—Lock Washer (16 used) | 23—Second Planet Gear
(3 used) | 33—Pin (3 used) | 48—Spring Pin (3 used) |
| 11—Ring Gear | | | 49—Thrust Pad |
| 12—Cap Screw (20 used) | | | |
| 13—O-Ring | | | |
| 14—Third Planet Carrier | | | |

02
0250
21

Continued on next page

TX,02,UU3676 -19-06MAY98-2/11

Axle Shaft, Bearings, and Reduction Gears

1. Install sprocket (C) on drum (B).
2. Clean threads of cap screws (A) using cure primer.
3. Apply thread lock and sealer (high strength) to threads.

Install cap screws and tighten.

Sprocket-to-Drum Cap Screw—Specification


Torque 470 N•m (345 lb-ft)

4. Clean ring gear mounting surface of drum (B).
5. Install O-ring (F).
6. Apply high flex form-in-place gasket to the mounting surface.
7. Install sprocket and drum on ring gear (E).
8. Clean threads of cap screws (D) using cure primer.
9. Apply thread lock and sealer (high strength) to threads.

Install cap screws and tighten.

Ring Gear-to-Drum Cap Screw—Specification

Torque 265 N•m (195 lb-ft)



T117026

- A—Cap Screw (20 used)
- B—Drum
- C—Sprocket
- D—Cap Screw (16 used)
- E—Ring Gear
- F—O-Ring

T117026 -UN-09SEP98

Continued on next page

TX,02,UU3676 -19-06MAY98-3/11

02
0250
22

Axle Shaft, Bearings, and Reduction Gears



CAUTION: DO NOT heat oil over 182°C (260°F). Oil fumes or oil can ignite above 193°C (380°F). Use a thermometer. **DO NOT** allow a flame or heating element to come in direct contact with the oil. Heat the oil in a well ventilated area. Plan a safe handling procedure to avoid burns.



- Heat inner roller bearing (F) cone to 50—70°C (122—158°F). Install cone tight against shoulder.

Roller Bearing Cone—Specification

Temperature 50—70°C (122—158°F)

IMPORTANT: O-ring and seat surfaces for O-ring must be clean, dry, and oil free so O-ring does not slip.


- Thoroughly clean O-ring and seat surfaces in housing, drum, and seal ring using volatile, non-petroleum base solvent and lint-free tissues.
- Install O-ring on seal ring.

NOTE: A volatile, non-petroleum base solvent or talcum powder can be used as a lubricant. Solvent must not damage the O-ring or leave an oil residue.

- Apply equal pressure with fingers at four equally spaced points on seal face. Seal must “pop” down into place so O-ring is tight against seal bore and seal ring is installed squarely.
- Wipe finger prints and foreign material off seal ring face using clean oil and lint-free tissues.
- Apply a thin film of clean oil on each seal ring face.
- Install ring gear, drum, and sprocket (A) on propel motor (C) housing.
- Heat outer roller bearing (B) cone to 50—70°C (122—158°F). Install bearing cone.

Roller Bearing Cone—Specification

Temperature 50—70°C (122—158°F)



- A—Ring Gear, Drum, and Sprocket
- B—Outer Roller Bearing
- C—Propel Motor
- D—O-Ring (2 used)
- E—Seal Ring (2 used)
- F—Inner Roller Bearing


TS227 -UN-23AUG88

T7685AX -UN-19MAR92

02
0250
23

Axle Shaft, Bearings, and Reduction Gears

18. Install hub (A). Note location of holes (B) in hub for dowel pin.



A—Hub
B—Hole Location

T7685HS -UN-10APR92

TX,02,UU3676 -19-06MAY98-5/11

19. Install nut (D) with the 0.5 mm (0.020 in.) step (E) towards hub.

Tighten nut using DFT1036A Propel Gearbox Nut Wrench (B) and DFT1109 Holding Bar (A). Fasten holding bar to ring gear. (See Section 99 for instructions to make tools.)

Hub-to-Propel Motor Housing Bearing Nut—Specification

Torque 785 N•m (580 lb-ft) then tap on ring gear using a plastic hammer, turn three times right and left to seat bearing, repeat procedure




T7978AA -UN-01APR93

T7685HR -UN-10APR92

20. Tap on ring gear using a plastic hammer. Then turn drum three times to the right and left to seat the roller bearings.

21. Repeat procedure again to be sure roller bearings are seated.



T7978AA (CV)

A—DFT1109 Holding Bar
B—DF1036A Propel Gearbox Nut Wrench
C—Ring Gear
D—Bearing Nut
E—0.5 mm (0.020 in.) Step

Continued on next page

TX,02,UU3676 -19-06MAY98-6/11


02
0250
24

Axle Shaft, Bearings, and Reduction Gears

- 22. Align hole (B) in nut with hole in hub.
- 23. Install dowel pin (A) so end is recessed below surface of bearing nut.

Bearing Nut-to-Hub Dowel Pin—Specification

Distance..... 14 mm (0.55 in.) below surface of bearing nut



T7685HT -UN-10APR92

02
0250
25

A—Dowel Pin
B—Hole

TX,02,UU3676 -19-06MAY98-7/11

- 24. Install third planet carrier (A).
- 25. Install third planet sun gear (B).



T7685HN -UN-10APR92

A—Third Planet Carrier
B—Third Planet Sun Gear

Continued on next page

TX,02,UU3676 -19-06MAY98-8/11

Axle Shaft, Bearings, and Reduction Gears

- 26. Install second planet carrier (A).
- 27. Install second planet sun gear (B).



T7685HM -UN-10APR92

A—Second Planet Carrier
B—Second Planet Sun Gear

TX,02,UU3676 -19-06MAY98-9/11

- 28. Install first planet carrier (A).
- 29. Install input shaft (B).



T7685HL -UN-10APR92

A—First Planet Carrier
B—Input Shaft

Continued on next page

TX,02,UU3676 -19-06MAY98-10/11

Axle Shaft, Bearings, and Reduction Gears

30. Clean cover and ring gear mounting surfaces using cure primer. Apply plastic gasket.

31. Install cover. Tighten cap screws.

Cover-to-Ring Gear Cap Screw—Specification

Torque 110 N•m (80 lb-ft)


32. Add gear oil to propel gearbox. Approximate capacity is 6.0 L (6.5 qt). (See Swing Gearbox and Propel Gearbox Oils in Group 0004.)

33. Clean threads of fill plug using cure primer. Apply pipe sealant.

34. Install fill plug (A). Tighten plug.

Fill Plug—Specification

Torque 50 N•m (35 lb-ft)



- A—Fill Plug
- B—Level Plug
- C—Drain Plug
- D—Cap Screw (16 used)
- E—Cover

T7685HK -JUN-10APR92

02
0250
27

02
0260
1

ESSENTIAL TOOLS

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company.

CED,OUOE003,508 -19-15MAY98-1/3

PlugJT03221 (3/4-16 M 37°) (Parker No. 03CP—8)

To seal drain line during propel motor start-up procedure.

CED,OUOE003,508 -19-15MAY98-2/3

Spanner Wrench JDG769

T7782AH -UN-19JUN92

To remove and install spanner nut.

T7782AH (CV)



CED,OUOE003,508 -19-15MAY98-3/3

SERVICE EQUIPMENT AND TOOLS

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company.

CED,OUOE003,1156 -19-18SEP98-1/9

10 mm Hex Key Wrench

To loosen propel motor fill plug.

CED,OUOE003,1156 -19-18SEP98-2/9

14 mm Hex Key Wrench

To remove and install brake valve housing cap screws.

Continued on next page

CED,OUOE003,1156 -19-18SEP98-3/9

Hydraulic System

8 mm Hex Key Wrench

To remove propel motor and brake pivot bolt.

CED,OUOE003,1156 -19-18SEP98-4/9

5 mm Hex Key Wrench

To remove servo piston shuttle and brake release shuttle seat.

CED,OUOE003,1156 -19-18SEP98-5/9

Rotary Manifold Lifting Tool¹

To remove and install rotary manifold.

¹Fabricated tool, dealer made. (See Section 99 for instructions to make tools.)

CED,OUOE003,1156 -19-18SEP98-6/9

Push-Puller (Mechanical) D01200AA

To align ports on rotary manifold to existing lines.

CED,OUOE003,1156 -19-18SEP98-7/9

Service Wrench D05242ST

To align ports on rotary manifold to existing lines.

Continued on next page

CED,OUOE003,1156 -19-18SEP98-8/9

02
0260
2

Hydraulic System

Air Test Plug JDG185

To seal port and apply air pressure to rotary manifold for pressure test.

02
0260
3

CED,OUOE003,1156 -19-18SEP98-9/9

OTHER MATERIAL

Number	Name	Use
TY16285 (U.S.) TY9485 (Canadian) 7649 (LOCTITE®)	Cure Primer	Cleans and cures surfaces prior to application of adhesives or sealants.
TY9375 (U.S.) TY9480 (Canadian) 592 (LOCTITE®)	Pipe Sealant	Apply to threads of plug.
T43513 (U.S.) TY9474 (Canadian) 271 (LOCTITE®)	Thread Lock and Sealer (High Strength)	Apply to outer surface of propel motor drive shaft seal and threads of valve plate pivot plug.
TY6347 (U.S.)	Multi-Purpose Grease	Apply to end of propel motor and brake pivot bolt.
T43512 (U.S.) TY9473 (Canadian) 242 (LOCTITE®)	Thread Lock and Sealer (Medium Strength)	Apply to servo piston shuttle and brake release shuttle seat.

LOCTITE is a trademark of Loctite Corp.

CED,OUOE003,1157 -19-18SEP98-1/1

Hydraulic System

SPECIFICATIONS

Item	Measurement	Specification
Propel Motor and Brake:		
Propel Gearbox with Motor	Weight	330 kg (730 lb) approximate
Gearbox and Motor-to-Frame Cap Screw	Torque	620 N•m (460 lb-ft)
Propel Motor Cover-to-Frame Cap Screw	Torque	180 N•m (80 lb-ft)
Link-to-Servo Piston Pivot Bolt	Torque	49 N•m (36 lb-ft)
Pivot Bolt Access Plug	Torque	15 N•m (132 lb-in.)
Roller Bearing Inner Race	Temperature	70—90°C (160—194°F)
Drive Shaft Bearing	Rolling Drag Torque	1—2 N•m (9—17 lb-in.)
Brake Valve-to-Housing Cap Screw	Torque	215 N•m (160 lb-ft)
Crossover Relief Valve Plug	Torque	540 N•m (400 lb-ft)
Counterbalance Valve Plug	Torque	215 N•m (160 lb-ft)
Check Valve Plug	Torque	235 N•m (173 lb-ft)
Brake Pressure Reducing Valve Plug	Torque	69 N•m (51 lb-ft)
Brake Release Shuttle Valve Seat	Torque	14.5 N•m (128 lb-in.)
Brake Release Shuttle Valve Plug	Torque	34 N•m (301 lb-in.)
Servo Piston Shuttle Valve Seat	Torque	14.5 N•m (128 lb-in.)
Servo Piston Shuttle Valve Plug	Torque	34 N•m (301 lb-in.)
Rotary Manifold:		
Rotary Manifold	Weight	27 kg (60 lb) approximate
Manifold-to-Frame Cap Screw	Torque	34 N•m (25 ft-lb)

Continued on next page

CED,OUOE003,1158 -19-18SEP98-1/2

Hydraulic System


Item	Measurement	Specification
Stop-to-Frame Cap Screw	Torque	40 N•m (30 lb-ft)
Rotary Manifold	Torque Torque Torque	373 N•m (275 lb-ft) first rotation 237 N•m (175 lb-ft) second rotation 170 N•m (125 lb-ft) third rotation
Cover-to-Housing Cap Screw	Torque	49 N•m (36 lb-ft)

02
0260
5

CED,OUOE003,1158 -19-18SEP98-2/2

REMOVE AND INSTALL PROPEL MOTOR AND BRAKE

1. Disconnect track. (See Remove Track Chain, Group 0130.)
2. Swing upperstructure 90° and lower bucket to raise track off ground. Keep angle between boom and arm 90—100° and position round side of bucket on ground. Put a support stand under the carriage.



T6876FG -JUN-06DEC88


Continued on next page

TX,02,UU3722 -19-18SEP98-1/4

Hydraulic System

CAUTION: Hydraulic oil tank is pressurized. Loosen vent plug to release pressure.

- Loosen vent plug (A) to release hydraulic oil tank pressure



A—Vent Plug


T6511AX -UN-18OCT88

TX,02,UU3722 -19-18SEP98-2/4

- Loosen fill plug (A) using a 10 mm hex key wrench.
- Install a clean oil collection container under propel motor gearbox.

NOTE: Approximate oil capacity of propel motor gearbox is 6.0 L (6.5 qt.)

- Remove plug (B) to drain gearbox oil.
- Clean threads of plugs using cure primer. Apply pipe sealant to threads before installing plugs.
- Remove propel motor cover cap screws.
- Remove propel motor cover.



A—Fill Plug
B—Drain Plug
C—Cap Screw
D—Cap Screw (12 used)

T7685AN -UN-19MAR92

Continued on next page

TX,02,UU3722 -19-18SEP98-3/4

Hydraulic System

CAUTION: To avoid injury from escaping fluid under pressure, stop engine, and relieve the pressure in the system before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

10. Disconnect lines (A—D).

CAUTION: The approximate weight of propel gearbox with motor is 330 kg (730 lb).

Propel Gearbox with Motor—Specification

Weight..... 330 kg (730 lb) approximate

11. Connect propel gearbox and motor to a hoist using lifting straps.
12. Using a 30 mm socket, remove propel motor-to-frame cap screws and washers (E).
13. Replace parts as necessary.
14. Install propel gearbox and motor to frame. Tighten cap screws (E).



Gearbox and Motor-to-Frame Cap Screw—Specification

Torque 620 N•m (460 lb-ft)

15. Connect lines.
16. Perform propel motor start-up procedure. (See procedure in this group.)
17. Install propel motor cover.
18. Using a 19 mm socket, tighten propel motor cover cap screws.

Propel Motor Cover-to-Frame Cap Screw—Specification

Torque 180 N•m (80 lb-ft)



- A—Pilot Oil Port-to-Rotary Manifold “P1” Port Line
- B—Bottom Port (Forward)-to-Rotary Manifold “1” or “3” Port Line
- C—Top Port (Reverse)-to-Rotary Manifold “2” or “4” Port Line
- D—Drain Port-to-Rotary Manifold “D” Port Tee
- E—Cap Screw and Washer (14 used)

X9811 -UN-23AUG88

T7685AV -UN-19MAR92


02
0260
7

Hydraulic System

**PROPEL MOTOR AND BRAKE START-UP
PROCEDURE**

IMPORTANT: Propel motor will be damaged if not filled with oil before starting engine. Procedure must be performed whenever a new propel motor is installed or oil has been drained from the motor.

1. Disconnect motor drain line (A). Install plug such as JT03221 (3/4-16 M 37°) (Parker No. 03CP—8) Plug.
2. Fill motor with hydraulic oil until oil reaches the top of the drain port. (See Hydraulic Oil in Group 0004.) Use a funnel with suitable diameter neck to allow air to escape while filling.
3. Connect drain line.



T7660BG


A—Drain Line

T7660BG -UN-11DEC91

TX,02,VV2718 -19-18SEP98-1/1

Hydraulic System

DISASSEMBLE PROPEL MOTOR AND BRAKE



02
0260
10

T103937

T103937 -JUN-23SEP96

Continued on next page

TX,02,UU3723 -19-18SEP98-1/11


Hydraulic System

1—O-Ring	12—Housing	23—Piston	34—Pressure Relief Valve
2—Disc Spring	13—Oil Seal	24—O-Ring	Spool
3—Rotor	14—Bearing Nut	25—Plunger (7 used)	35—Plug
4—Center Spring	15—Bearing	26—Cap Screw (8 used)	36—Brake Valve
5—Pin	16—Spacer	27—Servo Piston	37—Plug
6—Center Shaft	17—Bearing	28—O-Ring	38—Plate
7—Plug (2 used)	18—Spacer	29—Cap Screw (4 used)	39—Bushing
8—Link	19—Plate (5 used)	30—Cover	40—Valve Plate
9—Reamer Bolt	20—Friction Plate (4 used)	31—Piston Ring (2 used)	
10—Retaining Ring	21—Packing	32—Plug	
11—Drive Shaft	22—Packing	33—Spring	

02
0260
11

TX,02,UU3723 -19-18SEP98-2/11

- Using a 14 mm hex key wrench, remove cap screws (A). Remove brake valve housing (B). (For disassembly and assembly of brake valve, see procedure in this group.)



A—Cap Screw (8 used)
B—Brake Valve Housing

T7685HU -UN-27APR92


Continued on next page

TX,02,UU3723 -19-18SEP98-3/11


Hydraulic System

IMPORTANT: Pistons must be installed into the same bores because of wear pattern. Mark pistons and respective rotor bores for assembly.

2. Mark pistons and rotor (A) bores for assembly.
3. Remove snap ring (B). Remove rotor (A).
4. Remove spring (C) and shaft (D).
5. Remove pin from center shaft (D) if replacement is necessary.



T7685HW -UN-27APR92



T7685HX -UN-27APR92

- A—Rotor
- B—Snap Ring
- C—Spring
- D—Center Shaft

TX,02,UU3723 -19-18SEP98-4/11

IMPORTANT: Pistons must be installed into the same seats in drive shaft because of wear pattern. Mark pistons and respective gear seats for assembly.

6. Mark pistons and drive shaft so pistons (A) can be installed into the same seats at assembly. Remove pistons.



T7685HY -UN-27APR92

- A—Pistons

Continued on next page

TX,02,UU3723 -19-18SEP98-5/11

02
0260
12


Hydraulic System

7. Remove O-rings (C and D).

8. Remove disk spring (A).

9. Remove piston (E).

Check and clean brake release port (B).




T7685HZ -UN-27APR92

02
0260
13

- A—Disk Spring
- B—Brake Release Port
- C—O-Ring
- D—O-Ring
- E—Piston

TX,02,UU3723 -19-18SEP98-6/11

10. Remove parts (A—G).



T7685IA -UN-27APR92

- A—Drive Shaft
- B—Disk (4 used)
- C—Plate (5 used)
- D—O-Ring
- E—O-Ring
- F—Piston
- G—Spacer

Continued on next page


TX,02,UU3723 -19-18SEP98-7/11

Hydraulic System

11. Remove parts (A—E).

Remove spanner nut (E) using JDG769 Spanner Wrench.

Inner race of roller bearings (B and D) are a press fit on shaft.



- A—Drive Shaft
- B—Roller Bearing
- C—Spacer
- D—Roller Bearing
- E—Spanner Nut


T7685B -UN-27APR92

TX,02,UU3723 -19-18SEP98-8/11

12. Remove cap screws (B), cover (A), and O-ring (C).

13. Remove plug (F) and O-ring (E).

14. Remove pivot bolt (D) using an 8 mm hex key wrench.



- A—Cover
- B—Cap Screw (4 used)
- C—O-Ring
- D—Pivot Bolt
- E—O-Ring
- F—Plug


T7685C -UN-27APR92

Continued on next page

TX,02,UU3723 -19-18SEP98-9/11

Hydraulic System

15. Remove parts (A—E).



- A—Servo Piston
- B—Dowel Pin
- C—Plate
- D—Valve Plate and Link
- E—Pivot Plug

T7685ID -JUN-27APR92


02
0260
15

Continued on next page

TX,02,UU3723 -19-18SEP98-10/11

Hydraulic System

16. Disassemble servo piston (A—E).



- A—Plug
- B—O-Ring
- C—Spool
- D—Spring
- E—Piston Ring (2 used)


T7685IE -UN-27APR92

TX,02,UU3723 -19-18SEP98-11/11

02
0260
16

Hydraulic System

ASSEMBLE PROPEL MOTOR AND BRAKE



02
0260
18

T103098

T103098 -UN-19SEP96

Continued on next page

TX.02.VV2720 -19-18SEP98-1/11

Hydraulic System


02—Housing	19—Center Shaft	33—O-Ring	51—Pivot Bolt
04—Drive Shaft	20—Spring	34—O-Ring	53—Servo Piston
06—Roller Bearing	21—Pin	36—Brake Valve Housing	55—Piston Ring (2 used)
07—Roller Bearing	24—Disk (4 used)	38—Cap Screw (8 used)	56—Cover
08—Spacer	25—Plate (5 used)	40—Plate	57—O-Ring
09—Nut	26—Spacer	41—Pin (2 used)	58—Screw (4 used)
11—Seal	28—Piston	45—Valve	63—Plug
12—Snap Ring	29—O-Ring	46—Bushing	63A—O-Ring
14—Rotor	30—O-Ring	48—Link	64—Plug
17—Piston (7 used)	31—Disk Spring	49—Pivot Plug (2 used)	64A—O-Ring

02
0260
19

1. Apply thread lock and sealer (high strength) to outer surface of seal (11). Apply petroleum jelly to seal lips.

TX,02,VV2720 -19-18SEP98-2/11

2. Assemble servo piston (2—7).



- 2—Spring
- 3—Speed Selector Valve Spool
- 4—Plug
- 5—Orifice
- 6—Servo Piston
- 7—Plug


T103107 -UN-19SEP96

Continued on next page

TX,02,VV2720 -19-18SEP98-3/11

Hydraulic System

3. Install plate (C) so holes engage dowel pins (B).
4. Install servo piston (A).
5. Install valve plate in link. Apply thread lock and sealer (high strength) to threads of pivot plug (E). Tighten pivot plug.
6. Install valve plate and link. Align groove in link with servo piston.



T7685ID -UN-27APR92

- A—Servo Piston
- B—Dowel Pin (2 used)
- C—Plate
- D—Valve Plate and Link
- E—Pivot Plug

Continued on next page

TX,02,VV2720 -19-18SEP98-4/11

Hydraulic System

7. Apply multi-purpose grease to the end of pivot bolt (D).
8. Install pivot bolt (D), through plug hole, link and servo piston. Tighten bolt.

Link-to-Servo Piston Pivot Bolt—Specification


Torque 49 N•m (36 lb-ft)

9. Install O-ring (C)

10. Install O-ring (E) and plug (F). Tighten plug.

Pivot Bolt Access Plug—Specification

Torque 15 N•m (132 lb-in.)



- A—Cover
- B—Cap Screw
- C—O-Ring
- D—Pivot Bolt
- E—O-Ring
- F—Plug

T7685C -UN-27APR92

02
0260
21

Continued on next page

TX,02,VV2720 -19-18SEP98-5/11

Hydraulic System

CAUTION: DO NOT heat oil over 182°C (360°F). Oil fumes or oil can ignite above 193°C (380°F). Use a thermometer. DO NOT allow a flame or heating element to come in direct contact with the oil. Heat the oil in a well ventilated area. Plan a safe handling procedure to avoid burns.



11. Heat roller bearing (B) inner race to 70—90°C (160—194°F). Install on drive shaft (A).

Roller Bearing Inner Race—Specification

Temperature 70—90°C (160—194°F)

12. Install outer race of bearing (B).
13. Install roller bearing (D) outer race onto spacer (C).
14. Install spacer with outer race onto drive shaft.
15. Heat inner race of roller bearing (D) to 70—90°C (160—194°F). Install race onto drive shaft.


Roller Bearing Inner Race—Specification

Temperature 70—90°C (160—194°F)

16. Apply clean oil to threads of nut (E). Install nut (E). Tighten spanner nut (E) using JDG769 Spanner Wrench. Check rolling drag torque.

Drive Shaft Bearing—Specification

Rolling Drag Torque 1—2 N•m (9—17 lb-in.)



A—Drive Shaft
 B—Roller Bearing
 C—Spacer
 D—Roller Bearing
 E—Spanner Nut

TS227 -UN-23AUG88

T7685IB -UN-27APR92


Continued on next page

TX,02,VV2720 -19-18SEP98-6/11

02
0260
22

Hydraulic System

17. Install parts (A—G).
18. Install spacer (G) with notches towards and aligned with notches in housing.
19. Install plates (C) and disks (B) with notches aligned with notches in housing.




- A—Drive Shaft
- B—Disk (4 used)
- C—Plate (5 used)
- D—O-Ring
- E—O-Ring
- F—Piston
- G—Spacer

T7685A -UN-27APR92

02
0260
23

TX,02,VV2720 -19-18SEP98-7/11

20. Install piston (E) so notches are aligned with notches in disks, plates, and housing.
21. Install disk spring (A).
22. Install O-rings (C and D).



- A—Disk Spring
- B—Brake Release Port
- C—O-Ring
- D—O-Ring
- E—Piston

T7685HZ -UN-27APR92

Continued on next page

TX,02,VV2720 -19-18SEP98-8/11

Hydraulic System

IMPORTANT: Pistons must be installed into the same seats because of wear patterns.

23. Install pistons (A) into their original seats.



A—Pistons

T7685HY -UN-27APR92

TX,02,VV2720 -19-18SEP98-9/11


24. Install spring (C) on center shaft (D).

25. Install center shaft into rotor making sure that the pin on shaft aligns with groove in rotor.


26. Install snap ring (B).

IMPORTANT: Pistons must be installed into the same bores because of wear patterns.

27. Install rotor (A) so pistons are installed into their original bores.



T7685HX -UN-27APR92



T7685HW -UN-27APR92

A—Rotor
B—Snap Ring
C—Spring
D—Center Shaft

Continued on next page

TX,02,VV2720 -19-18SEP98-10/11


02
0260
24

Hydraulic System

28. Install brake valve (B) on housing aligning hole in valve plate with center shaft. Using a 14 mm hex key wrench, tighten cap screws (A).

Brake Valve-to-Housing Cap Screw—Specification

Torque 215 N•m (160 lb-ft)



A—Cap Screw (8 used)
B—Brake Valve


T7685HJ -UN-27APR92

02
0260
25

TX,02,VV2720 -19-18SEP98-11/11

Hydraulic System

DISASSEMBLE AND ASSEMBLE PROPEL MOTOR BRAKE VALVE HOUSING



02
0260
26

T103131

Continued on next page

TX,02,UU3724 -19-18SEP98-1/3

T103131 -UN-04DEC96

Hydraulic System

- 1A—Brake Valve Housing
- 1B—Check Valve Poppet
- 1C—Counterbalance Valve
- 07—Spring (2 used)
- 08—Spring (2 used)
- 09—Stop (2 used)
- 11—Plug (2 used)
- 12—O-Ring (2 used)

- 15—Spring (2 used)
- 17—Plug (2 used)
- 17A—O-Ring (2 used)
- 21—Crossover Relief Valve (2 used)
- 23—Pressure Reducing Valve Spool
- 24—Spring

- 25—Plug
- 25A—O-Ring
- 29—Servo Piston Shuttle and Brake Release Shuttle Ball (2 used)
- 30—Servo Piston Shuttle and Brake Release Shuttle Seat (2 used)

- 31—Plug
- 32—O-Ring
- 33—Plug (2 used)
- 33A—O-Ring (2 used)
- 35—Plug (5 used)
- 35A—O-Ring (5 used)

NOTE: Valves can be removed with propel motor on the machine.

Apply a film of clean hydraulic oil to parts before assembly.

CROSSOVER RELIEF VALVE

1. Remove crossover relief valves (21).
2. Check and adjust pressure setting. (See Propel Motor Crossover Relief Valve Test and Adjustment in Group 9025-25.)
3. Tighten crossover relief valve plug.

Crossover Relief Valve Plug—Specification

Torque..... 540 N•m (400 lb-ft)

COUNTERBALANCE VALVE

1. Remove counterbalance valves (1C, 7—9, 11, and 12).
2. Tighten plug (11).

Counterbalance Valve Plug—Specification

Torque..... 215 N•m (160 lb-ft)

CHECK VALVES

1. Remove check valves (1B, 15, and 17).
2. Tighten plug (1B).

Check Valve Plug—Specification

Torque..... 235 N•m (173 lb-ft)

BRAKE PRESSURE REDUCING VALVE

1. Remove brake pressure reducing valves (23—25).
2. Tighten plug (25).

Brake Pressure Reducing Valve Plug—Specification

Torque..... 69 N•m (51 lb-ft)

BRAKE RELEASE SHUTTLE VALVE

1. Remove brake release shuttle valves (29—32).
2. Remove seat (30) using a 5 mm hex key wrench.
3. Seat may need to be heated to break down thread lock and sealer. This can be done by inserting a steel rod into the hole and heating the rod to transfer the heat to the seat.

IMPORTANT: Oil will leak past ball if it is not seated properly.

4. Install ball (29).
5. Place ball on seat and tap ball with a hammer to obtain a tight fit between ball and seat. After installing ball insert a metal bar into the plug hole so it rests on the ball. Tap other end of bar with a hammer to obtain a tight fit between ball and housing.

02
0260
27

Hydraulic System

6. Apply thread lock and sealer (medium strength) to seat (30). Tighten seat.

Brake Release Shuttle Valve Seat—Specification

Torque..... 14.5 N•m (128 lb-in.)

7. Tighten plug.

Brake Release Shuttle Valve Plug—Specification

Torque..... 34 N•m (301 lb-in.)

SERVO PISTON SHUTTLE VALVE

1. Remove servo piston shuttle valves (29—32).
2. Remove seat (30) using a 5 mm hex key wrench.
3. Seat may need to be heated to break down thread lock and sealer. This can be done by inserting a steel rod into the hole and heating the rod to transfer the heat to the seat.

IMPORTANT: Oil will leak past ball if it is not seated properly.

4. Install ball (29).
5. Place ball on seat and tap ball with a hammer to obtain a tight fit between ball and seat. After installing ball, but before tightening seat, insert a metal bar into the plug hole so it rests on the ball. Tap other end of bar with a hammer to obtain a tight fit between ball and housing.
6. Apply thread lock and sealer (medium strength) to seat (30). Using a 5 mm hex key wrench, tighten seat.

Servo Piston Shuttle Valve Seat—Specification

Torque..... 14.5 N•m (128 lb-in.)

7. Tighten plug (31).


Servo Piston Shuttle Valve Plug—Specification

Torque..... 34 N•m (301 lb-in.)

TX,02,UU3724 -19-18SEP98-3/3

REMOVE AND INSTALL ROTARY MANIFOLD

1. Loosen vent plug to relieve hydraulic oil tank pressure.



A—Vent Plug

T7869AT -UN-12NOV92

Continued on next page

TX,02,VV2722 -19-18SEP98-1/7



02
0260
28

Hydraulic System



CAUTION: To avoid injury from escaping fluid under pressure, stop engine, and relieve the pressure in the system before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

2. Disconnect lines (A, B, E—H).
3. Remove cap screws (C) and stop (D).



T103964

- A—Left Front Port To Left Propel Top Port
- B—Right Front Port To Right Propel Top Port
- C—Cap Screw
- D—Stop
- E—Right Side Port To Propel Speed Change Solenoid Valve
- F—Right Rear To Right Propel Bottom Port
- G—Left Rear To Left Propel Bottom Port
- H—Left Side Port To Return Manifold

X9811 -UN-23AUG88

T103964 -UN-23SEP96

02
0260
29

Continued on next page

TX,02,VV2722 -19-18SEP98-2/7


Hydraulic System

CAUTION: The approximate weight of rotary manifold is 27 kg (60 lb).

Rotary Manifold—Specification


Weight..... 27 kg (60 lb) approximate

4. Attach the rotary manifold to a hoist using a lifting strap and two rotary manifold lifting tools. (See Section 99 for instructions to make tools.)



T103965 -UN-23SEP96

T103965




T7885JC -UN-27APR92

- A—To Right Propel Motor Speed Change Port
- B—To Right Propel Motor Top Port (Reverse)
- C—To Right Propel Motor Bottom Port (Forward)
- D—To Right Propel Motor Drain Port
- E—To Left Propel Motor Drain Port
- F—Port To Left Propel Motor Bottom Port (Forward)
- G—Port To Left Propel Motor Top Port (Reverse)
- H—To Left Propel Motor Speed Change Port
- I—Cap Screw

Continued on next page

TX,02,VV2722 -19-18SEP98-3/7

Hydraulic System



02
0260
32

T109207

Continued on next page

TX.02.VV2722 -19-18SEP98-4/7

T109207 -JUN-24APR97

Hydraulic System

- | | | | |
|---------------------|----------------------------|--------------------------|---------------------|
| 00—Hose (2 used) | 16A—O-Ring (2 used) | 32—Hose Clamp (2 used) | 43B—Hose |
| 01—Hose (2 used) | 21—Hose (2 used) | 35—Cap Screw (2 used) | 44A—Hose Protector |
| 04—Adapter (4 used) | 22—Adapter (2 used) | 37—Tie Band (4 used) | 44B—Hose |
| 04A—O-Ring (4 used) | 22A—O-Ring (2 used) | 38A—Hose Protector | 45—O-Ring (4 used) |
| 05—Adapter (4 used) | 23—Adapter (2 used) | 38B—Hose | 46—Adapter (2 used) |
| 05A—O-Ring (4 used) | 23A—O-Ring (2 used) | 39—O-Ring (4 used) | 47—Adapter (2 used) |
| 08—O-Ring (8 used) | 27—Rubber Bushing (2 used) | 40—Cap Screw (16 used) | 47A—O-Ring (2 used) |
| 14—Hose (2 used) | 28—Rubber Bushing 2 used) | 41—Split Flange (8 used) | |
| 15—Tee Fitting | 31—Hose Clamp (2 used) | 42A—Hose Protector | |
| 15A—O-Ring | | 42B—Hose | |
| 16—elbow (2 used) | | 43A—Hose Protector | |

5. Disconnect hoses (00, 01, and 21) from each side of rotary manifold.
6. Disconnect hoses (38B, 42B, 43B, and 44B) from top of rotary manifold.
7. Remove rotary manifold-to-mainframe cap screws. Lower rotary manifold.
8. Replace parts as necessary.

9. Raise rotary manifold into position. Tighten flange-to-mainframe cap screws.

Manifold-to-Frame Cap Screw—Specification

Torque..... 34 N•m (25 ft-lb)

10. Connect all hoses to appropriate ports.

Continued on next page

TX,02,VV2722 -19-18SEP98-5/7

02
0260
33


Hydraulic System

11. Remove lifting device. Install stop (D). Tighten cap screws (C).

Stop-to-Frame Cap Screw—Specification

Torque 40 N•m (30 lb-ft)

12. Connect lines (A, B, E—H). If ports on rotary manifold do not align with lines, lower rotary manifold and do the following steps.



T103964

- A—Left Front Port To Left Propel Top Port
- B—Right Front Port To Right Propel Top Port
- C—Cap Screw
- D—Stop
- E—Right Side Port To Propel Speed Change Solenoid Valve
- F—Right Rear To Right Propel Bottom Port
- G—Left Rear To Left Propel Bottom Port
- H—Left Side Port To Return Manifold

T103964 -UN-23SEP96

Continued on next page

TX,02,VV2722 -19-18SEP98-6/7

Hydraulic System

13. Install cap screws (O) in spindle. Clamp cap screws in a vise.
14. Install cap screw (N), washer (J), and nut (K). Install puller on rotary manifold using cap screws (L). Use an extra thin service wrench (I) such as the D05242ST Service Wrench to hold cap screw (N).
15. Rotate manifold three times using nut (K) and a torque wrench.

Rotary Manifold—Specification

Torque 373 N•m (275 lb-ft) first rotation
 Torque 237 N•m (175 lb-ft) second rotation
 Torque 170 N•m (125 lb-ft) third rotation

16. Raise rotary manifold into position against machine mainframe. Tighten cap screws.

Manifold-to-Frame Cap Screw—Specification


Torque 34 N•m (25 lb-ft)

17. Remove lifting device. Install stop. Tighten cap screws (C).

Stop-to-Frame Cap Screw—Specification

Torque 40 N•m (30 lb-ft)

18. Connect lines.



T8313AA (CV)

- I—Service Wrench
- J—Washer
- K—Nut
- L—Cap Screw (2 used)
- M—Washer (2 used)
- N—Cap Screw
- O—Cap Screw (2 used)


02
0260
35

T8313AA -UN-20SEP94

Hydraulic System

DISASSEMBLE AND ASSEMBLE ROTARY MANIFOLD

1. Mark spindle (B), housing (F), and cover (K) to aid in assembly.
2. Remove cap screws (L) and cover (K). Inspect O-ring (J) and replace if necessary.
3. Remove snap ring (I) and ring (H).
4. Carefully, remove spindle assembly (A—F) from housing (G).
5. Remove plugs in spindle to clean ports. Install plugs.
6. Remove O-ring (D), seal (C), oil seal rings (F) and bushing (E) from housing (G).



T103974

T103974 -UN-24SEP96

- A—Plug
- B—Spindle
- C—Dust Seal
- D—O-Ring
- E—Bushing
- F—Oil Seal Rings (6 used)
- G—Housing
- H—Ring
- I—Snap Ring
- J—O-Ring
- K—Cover
- L—Cap Screw

Continued on next page

TX,02,VV2723 -19-18SEP98-1/2

Hydraulic System

7. Inspect and repair as necessary. Keep hydraulic oil on all disassembled parts.
8. Install bushing (E), O-ring (D), and seal (C) in housing (G).
9. Install oil seal rings (F) into housing (G)


IMPORTANT: Avoid damage to seals when installing spindle into rotary manifold housing. Clearance between spindle and housing is approximately 0.1 mm (0.004 in.) Spindle must not be tilted when inserted into housing.

10. Carefully install spindle (B) into housing (G) so that match marks align.
11. Install ring (H) with chamfered side down and snap ring (I) with chamfered side down.)
12. Install O-ring (J) and cover (K) with cap screws (L). Tighten cap screws.

Cover-to-Housing Cap Screw—Specification

Torque 49 N•m (36 lb-ft)

T103973




- A—Plug
- B—Spindle
- C—Dust Seal
- D—O-Ring
- E—Bushing
- F—Oil Seal Ring (6 used)
- G—Housing
- H—Ring
- I—Snap Ring
- J—O-Ring
- K—Cover
- L—Cap Screw

02
0260
37

T103973 -UN-24SEP96

TX,02,VV2723 -19-18SEP98-2/2


KEY SWITCH	POSITION	B	G ₁	G ₂	ACC	M	ST
HEAT		●	●				
OFF							
ACC		●			●		
ON		●			●	●	
START		●		●		●	●



T120569

230LC SYSTEM FUNCTIONAL SCHEMATIC (1 OF 6)

CONTINUED ON NEXT PAGE




SE4 MONITOR CONTROLLER AND DISPLAY CIRCUIT SE5 MONITOR CONTROLLER AND DISPLAY CIRCUIT SE6 MONITOR CONTROLLER AND DISPLAY CIRCUIT

230LC SYSTEM FUNCTIONAL SCHEMATIC (2 OF 6)


T120570

CONTINUED ON NEXT PAGE



T117691


CONTINUED ON NEXT PAGE



T117692

230LC SYSTEM FUNCTIONAL SCHEMATIC (4 OF 6)


CONTINUED ON NEXT PAGE



CONTINUED ON NEXT PAGE

T120571

230LC SYSTEM FUNCTIONAL SCHEMATIC (5 OF 6)




SE16 HEATER CIRCUIT (MACHINES WITHOUT AIR CONDITIONER)

SE17 HEATER AND AIR CONDITIONER CIRCUIT


SE18 OPTIONAL CONNECTOR CIRCUIT

230LC SYSTEM FUNCTIONAL SCHEMATIC (6 OF 6)

T120572




T120573




ENGINE AND FRAME HARNESS (W1) COMPONENT LOCATION (CONTINUED)


T121442



T121476




X8
CAB HARNESS TO ENGINE
AND FRAME HARNESS
CONNECTOR




X13	PIN A7	BLU/RED	7
X13	PIN A8	RED/WHT	8
X13	PIN A9	LGRN/BLK	9
X13	PIN A10	BLU/DRG	10
X13	PIN A12	DRG	12
X13	PIN A20	BLU/BLK	20
X13	PIN A21	RED/YEL	21
X13	PIN A22	LGRN/RED	22
X13	PIN A23	BLU/WHT	23
X13	PIN A24	BRN/RED	24
X13	PIN A25	RED	25
X16	PIN A26	YEL	26
X14	PIN B6	BLK	36
X14	PIN B9	BLK/YEL	39
X14	PIN B13	WHT	43
X15	PIN D7	BLK/RED	57
X15	PIN D8	BLK/WHT	58
X15	PIN D14	BLU	64
X15	PIN D15	YEL/BLK	65
X15	PIN D16	RED/GRN	66
X15	PIN D17	GRN/BLK	67
X15	PIN D18	RED/BLK	68
X15	PIN D19	BLK/BLU	69

X15	PIN D22	BLK/PNK	72
X13	PIN A11	BLK	100
X13	PIN A11	BLK	101
X14	PIN B9	BLK/YEL	109
X14	PIN B9	BLK/YEL	110
X14	PIN B9	BLK/YEL	111
X14	PIN B9	BLK/YEL	112
X15	PIN D22	BLK/PNK	113
X15	PIN D22	BLK/PNK	114
X15	PIN D22	BLK/PNK	115
X15	PIN D22	BLK/PNK	116
X14	PIN B9	BLK/YEL	117
X15	PIN D22	BLK/PNK	118
X13	PIN A11	BLK	119
X22	PIN 1	WHT/RED	218
X22	PIN 2	GRN	219
X22	PIN 3	BLU	220
X22	PIN 4	WHT/BLK	221
X22	PIN 6	GRN/BLU	226
X22	PIN 7	WHT/YEL	227
X22	PIN 8	RED/BLU	228
X22	PIN 10	BLU/YEL	230
X21	PIN 1	BRN	239


X21	PIN 3	RED/GRN	242
X22	PIN 14	BRN/YEL	245
X19	PIN 2, W7	BLK	501
S1	PIN 6	BLK/WHT	505
V2	PIN K	RED/WHT	508
X20	PIN 2	RED/BLU	536
X20	PIN 3	RED	537
X21	PIN 12	RED/GRN	542
X21	PIN 2	PUR	546
F10	PIN 10		
X23	PIN 2	WHT/RED	831
V4	PIN K	WHT/BLK	833
V4	PIN K	WHT/BLK	834
V9	PIN A		
X23	PIN 5	YEL/GRN	835
W7		BLK	839
V10	PIN K	RED/BLK	841
F5	PIN 5		
X14	PIN B7	BRN/BLK	844
S17		WHT	846
X16	PIN 3	BLK/YEL	853




F11	PIN 17		
F12	PIN 17		
F13	PIN 17	WHT	1
S1	PIN 1	RED	2




F13	PIN 24	BRN	1
W7		BLK	2
X8	PIN 853	BLK/YEL	3
F14	PIN 25	WHT/YEL	4




F17	PIN 28	BRN	1
W7		BLK	2




F11	PIN 22	RED/GRN	1
X8	PIN 536	RED/BLU	2
X8	PIN 537	RED	3
S1	PIN 1	RED	4
V2	PIN K	RED/WHT	5
		PLUG	6



X8	PIN 239	BRN	1
X8	PIN 546	PUR	2
X8	PIN 242	RED/GRN	3
X15	PIN D3	GRY/BLU	4
F15	PIN 26	RED/WHT	5
X15	PIN D6	DRG/BLK	6
X15	PIN D4	GRY/RED	7
X14	PIN B12	BLK/RED	8
X14	PIN B11	DRG/BLU	9
X15	PIN D5	WHT	10
S2	PIN 1	PNK	11
X8	PIN 542	RED/GRN	12




X8	PIN 218	WHT/RED	1
X8	PIN 219	GRN	2
X8	PIN 220	BLU	3
X8	PIN 221	WHT/BLK	4
S14	PIN 1	PNK	5
X8	PIN 226	GRN/BLU	6
X8	PIN 227	WHT/YEL	7
X8	PIN 228	RED/BLU	8
A4	PIN 1	YEL/BLU	9
X8	PIN 230	BLU/YEL	10
F6	PIN 6	YEL/GRN	11
F1	PIN 1	GRN/RED	12
A4	PIN 3	YEL/RED	13
X8	PIN 245	BRN/YEL	14
F12	PIN 23	BLU/YEL	15
A4	PIN 4	YEL/WHT	16



X15	PIN D9	WHT/BLK	1
F10	PIN 10	WHT/RED	2
V4	PIN A	YEL	3
S1	PIN 1	RED	4
V9	PIN A	YEL/GRN	5
F20	PIN 31	RED/BLU	6
NOT USED		BLK/WHT	7
V1	PIN K	BLK/RED	8


CAB HARNESS (W2) COMPONENT LOCATION
(DETAIL A) (HARNESS MATING CONNECTORS - FRONT VIEW SHOWN)

NOTE: PIN NUMBERS ARE
LOCATION REFERENCE NUMBERS
ONLY - THEY ARE NOT
PRINTED ON THE CONNECTOR




NOTE: PIN NUMBERS ARE LOCATION REFERENCE NUMBERS ONLY - THEY ARE NOT PRINTED ON THE CONNECTOR

T120575




POWER CIRCUIT

T120578




STARTING AND FUEL SHUTOFF CIRCUIT

T120580




T117933

WINDSHIELD WIPER AND WASHER CIRCUIT




MONITOR CONTROLLER AND DISPLAY CIRCUIT




NOTE: <<
SYMBOL SHOWN IN SE8
INDICATES X8 ENGINE AND FRAME
HARNESS TO CAB HARNESS CONNECTOR

ENGINE AND PUMP CONTROLLER CIRCUIT


T117931



NOTE: Numbers 1 thru 12 are used on the schematic only to show the connections for pilot lines from flow regulator to left and right control valve pilot caps. Numbers not used on the machine




T120887




HYDRAULIC PUMP AND CONTROL VALVE SCHEMATIC

T121641




SWING AND PROPEL MOTOR CIRCUIT SCHEMATIC

T115418



T125365





- SWING LEFT, BOTTOM PILOT CAP
- BUCKET DUMP, BOTTOM PILOT CAP
- BOOM UP, BOTTOM PILOT CAP
- SWING RIGHT, TOP PILOT CAP
- ARM OUT, BOTTOM PILOT CAP
- BUCKET LOAD, TOP PILOT CAP
- BOOM DOWN, TOP PILOT CAP
- ARM IN, TOP PILOT CAP

	FUNCTIONS	CONTROLLER PORTS	FLOW REGULATOR VALVE PORT	
			Controller Side	Control Valve Side
R I G H T	Bucket Dump	I	H	8
	Boom Down	2	B	2
	Bucket Load	3	G	7
	Boom Up	4	A	1
		P	Pilot Shut-Off Valve P3	
		T	Pilot Shut-Off Valve T6	
L E F T	Swing Right	I	F	6
	Arm Out	2	C	3
	Swing Left	3	E	5
	Arm In	4	D	4
		P	Pilot Shut-Off Valve P2	
		T	Pilot Shut-Off Valve T5	

Note: Letters and numbers are on the housings next to the ports

PILOT SYSTEM-CONTROLLERS TO FLOW REGULATOR VALVE-SAE PATTERN

T109220




PILOT SYSTEM-CONTROLLERS TO FLOW REGULATOR VALVE-JOHN DEERE PATTERN


	FUNCTIONS	CONTROLLER PORTS	FLOW REGULATOR VALVE PORT	
			Controller Side	Control Valve Side
R I G H T	Bucket Dump	1	H	8
	Arm Out	2	C	3
	Bucket Load	3	G	7
	Arm In	4	D	4
		P	Pilot Shut-Off Valve P3	
		T	Pilot Shut-Off Valve T6	
L E F T	Swing Right	1	F	6
	Boom Down	2	B	2
	Swing Left	3	E	5
	Boom Up	4	A	1
		P	Pilot Shut-Off Valve P2	
		T	Pilot Shut-Off Valve T5	


Note: Letters and numbers are on the housings next to the ports

T109221




T125208






PRESSURE AND RETURN SYSTEM

T109226



HEATER AND AIR CONDITIONER CIRCUIT

T117938



AIR CONDITIONER HARNESS (W9) COMPONENT LOCATION

T118135

*Hydraulic System***ROTARY MANIFOLD AIR TEST**

1. Install a plug in one port.
2. Apply air pressure using JDG185 Air Test Plug and shop air pressure through the other port in that passage.
3. Listen for air leaks at ports on either side of pressurized port.




T6557 JB -JUN-01NOV88

TX,02,VV2724 -19-18SEP98-1/1

By order of the Secretary of the Army:

ERIC K. SHINSEKI
General United States Army
Chief of Staff



Official:

JOEL B. HUDSON
Administrative Assistant to the
Secretary of the Army
9930502

Distribution: To be distributed in accordance with Initial Distribution Number (IDN) 256561, requirements for TM 5-3805-280-24-1.



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM. CAREFULLY TEAR IT OUT. FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

Your mailing address

DATE SENT

Date you fill out this form

PUBLICATION NUMBER

TM 5-2350-262-34

PUBLICATION DATE

Date of TM

PUBLICATION TITLE

M9 DS/GS MAINTENANCE MANUAL

BE EXACT... PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.
2-2			
4-185	B		
B-5		1	

Fuel tank removal and installation is now a DS/GS task. Delete this task from the unit maintenance list.

There are three clamps securing air cleaner duct, not the two as shown. Suggest changing text and art to show three clamps.

Road wheel jack does not have an NSN or P/N listed and cannot be found on AMDF. Request correct NSN and P/N be furnished.

SAMPLE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBERS

JOE DOE, SFC 555-1212

SIGN HERE:

SAMPLE

FILL IN YOUR
UNIT'S ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY

PLACE
POSTAGE
HERE

TEAR ALONG PERFORATED LINE

**Commander
U.S. Army Tank-automotive and Armaments Command
ATTN: AMSTA-AC-NML
Rock Island, IL 61299-7630**

FILL IN YOUR
UNIT'S ADDRESS



FOLD BACK

DEPARTMENT OF THE ARMY

PLACE
POSTAGE
HERE

TEAR ALONG PERFORATED LINE

**Commander
U.S. Army Tank-automotive and Armaments Command
ATTN: AMSTA-AC-NML
Rock Island, IL 61299-7630**

THE METRIC SYSTEM AND EQUIVALENTS

WEIGHT MEASURE

1 Centimeter = 10 Millimeters = 0.01 Meters = 0.3937 Inches
 1 Meter = 100 Centimeters = 1000 Millimeters = 39.37 Inches
 1 Kilometer = 1000 Meters = 0.621 Miles

WEIGHTS

1 Gram = 0.001 Kilograms = 1000 Milligrams = 0.035 Ounces
 1 Kilogram = 1000 Grams = 2.2 lb.
 1 Metric Ton = 1000 Kilograms = 1 Megagram = 1.1 Short Tons

LIQUID MEASURE

1 Milliliter = 0.001 Liters = 0.0338 Fluid Ounces
 1 Liter = 1000 Milliliters = 33.82 Fluid Ounces

SQUARE MEASURE

1 Sq. Centimeter = 100 Sq. Millimeters = 0.155 Sq. Inches
 1 Sq. Meter = 10,000 Sq. Centimeters = 10.76 Sq. Feet
 1 Sq. Kilometer = 1,000,000 Sq. Meters = 0.386 Sq. Miles

CUBIC MEASURE

1 Cu. Centimeter = 1000 Cu. Millimeters = 0.06 Cu. Inches
 1 Cu. Meter = 1,000,000 Cu. Centimeters = 35.31 Cu. Feet

TEMPERATURE

$5/9(^{\circ}\text{F} - 32) = ^{\circ}\text{C}$
 212° Fahrenheit is equivalent to 100° Celsius
 90° Fahrenheit is equivalent to 32.2° Celsius
 32° Fahrenheit is equivalent to 0° Celsius
 $9/5^{\circ}\text{C} + 32 = ^{\circ}\text{F}$

APPROXIMATE CONVERSION FACTORS

TO CHANGE	TO	MULTIPLY BY
Inches	Centimeters	2.540
Feet	Meters	0.305
Yards	Meters	0.914
Miles	Kilometers	1.609
Square Inches	Square Centimeters	6.451
Square Feet	Square Meters	0.093
Square Yards	Square Meters	0.836
Square Miles	Square Kilometers	2.590
Acres	Square Hectometers	0.405
Cubic Feet	Cubic Meters	0.028
Cubic Yards	Cubic Meters	0.765
Fluid Ounces	Milliliters	29.573
its	Liters	0.473
arts	Liters	0.946
allons	Liters	3.785
Ounces	Grams	28.349
Pounds	Kilograms	0.454
Short Tons	Metric Tons	0.907
Pound-Feet	Newton-Meters	1.356
Pounds per Square Inch	Kilopascals	6.895
Miles per Gallon	Kilometers per Liter	0.425
Miles per Hour	Kilometers per Hour	1.609

TO CHANGE	TO	MULTIPLY BY
Centimeters	Inches	0.394
Meters	Feet	3.280
Meters	Yards	1.094
Kilometers	Miles	0.621
Square Centimeters	Square Inches	0.155
Square Meters	Square Feet	10.764
Square Meters	Square Yards	1.196
Square Kilometers	Square Miles	0.386
Square Hectometers	Acres	2.471
Cubic Meters	Cubic Feet	35.315
Cubic Meters	Cubic Yards	1.308
Milliliters	Fluid Ounces	0.034
Liters	Pints	2.113
Liters	Quarts	1.057
ers	Gallons	0.264
ms	Ounces	0.035
ograms	Pounds	2.205
Metric Tons	Short Tons	1.102
Newton-Meters	Pounds-Feet	0.738
Kilopascals	Pounds per Square Inch	0.145
ometers per Liter	Miles per Gallon	2.354
ometers per Hour	Miles per Hour	0.621



PIN: 077619-000