

TECHNICAL MANUAL

**UNIT, INTERMEDIATE DIRECT SUPPORT AND
INTERMEDIATE GENERAL SUPPORT MAINTENANCE MANUAL**

**DRILLING SYSTEM, WELL, ROTARY,
TRUCK MOUNTED, AIR TRANSPORTABLE,
600 FEET CAPACITY
MODEL LP-12
NSN 3820-01-246-4276**

This technical manual is an authentication of the manufacturer's commercial literature and does not conform with the format and content requirements normally associated with Army technical manuals. This technical manual does, however, contain all essential information required to operate and maintain the equipment.

Approved for public release; distribution is unlimited.

HEADQUARTERS, DEPARTMENT OF THE ARMY
8 MAY 1989

CHANGE
NO. 3

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 30 July 1995

Technical Manual

**Unit, Intermediate Direct Support and
Intermediate General Support Maintenance Manual**

**DRILLING SYSTEM, WELL, ROTARY,
TRUCK MOUNTED, AIR TRANSPORTABLE,
600 FEET CAPACITY
MODEL LP-165F299
NSN 3820-01-246-4276**

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited

TM 5-3820-256-24-6, 8 May 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages
A-9 and A-10
A-25 and A-26

Insert pages
A-9 and A-10
A-25 and A-26

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official:

JOEL B. HUDSON
*Acting Administrative Assistant to the
Secretary of the Army*
00598

DENNIS J. REIMER
*General, United States Army
Chief of Staff*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25-E, block no. 4845, requirements for TM 5-3820-256-24-6.

CHANGE
NO 2

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 26 February 1993

UNIT, INTERMEDIATE DIRECT SUPPORT AND
INTERMEDIATE GENERAL SUPPORT MAINTENANCE MANUAL

DRILLING SYSTEM, WELL, ROTARY
TRUCK MOUNTED, AIR TRANSPORTABLE,
600 FEET CAPACITY

MODEL LP-165F299
NSN 3820-01-246-4276

DISTRIBUTION STATEMENT A: Approved for public release; distribution is unlimited.

TM 5-3820-256-24-6, 8 May 1989, is changed as follows:

1. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove pages

A-9 and A-10
A-25 and A-26

Insert pages

A-9 and A-10
A-25 and A-26

2. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:

Official:

MILTON H. HAMILTON
*Administrative Assistant to the
Secretary of the Army*
03505

GORDON R. SULLIVAN
*General, United States Army
Chief of Staff*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25-E, block no. 4845, requirements for TM 5-3820-256-24-6.

CHANGE }
No. 1 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C. 10 October 1989

UNIT, INTERMEDIATE DIRECT SUPPORT AND
INTERMEDIATE GENERAL SUPPORT MAINTENANCE MANUAL

DRILLING SYSTEM, WELL, ROTARY
TRUCK MOUNTED, AIR TRANSPORTABLE,
600 FEET CAPACITY

MODEL LP-165F299
NSN 3820-01-246-4276

Approved for public release; distribution is unlimited.

TM 5-3820-256-24-6, 8 May 1989 is changed as follows.

1. Title is changed as shown above.
2. Remove and insert pages as indicated below. New or changed text material is indicated by a vertical bar in the margin. An illustration change is indicated by a miniature pointing hand.

Remove Pages

Insert Pages

C-1 and C-2

3. Retain this sheet in front of manual for reference purposes.

By Order of the Secretary of the Army:


CARL E. VUONO
General United States Army
Chief of Staff

Official:

WILLIAM J. MEEHAN, II
Brigadier General United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25A, Unit, Direct Support and General Support Maintenance requirements for Drilling Machine, Well, Combination Rotary/Percussion, Semitrailer Mounted Diesel, 1500 Ft. Model CF-15-S

WARNING**ELECTRIC POWER LINES CAN KILL**

Never raise mast or crane, or operate drill unit with less than 25 feet working clearance to any electrical power line.

Do not touch live electrical parts.

Check for buried utility lines before drilling.

WARNING

Crane and drilling operations have inherent hazards that cannot be mechanically safe guarded. Operator and maintenance personnel are required to wear hard hats and safety shoes.

Compressed air used for cleaning can create airborne particles that may enter the eyes. Pressure will not exceed 30 psig. Eye protection required.

Never operate engine in enclosed areas. Exhaust gases, particularly carbon monoxide, may build up. These gases are harmful and potentially lethal.

Cleaning solvent (PD-680, Type II) is toxic to skin, eyes and respiratory tract. Skin and eye protection required. Avoid repeated or prolonged contact. Good general ventilation is normally adequate.

Welding operations produce heat, highly toxic fumes, injurious radiation, metal slag and airborne particles. Protection equipment consisting of welding goggles with proper tinted lenses, apron or jacket, and welder's boots required. Good general ventilation is normally adequate.

Exercise care when using sharp or pointed tools to prevent injury to personnel.

Personnel will be trained in safe climbing practices. Climbing devices will be used on mast at all times. Safety climbing devices will be inspected prior to each use to insure good working order.

For Artificial Respiration, refer to FM 21-11.

WARNING

NOISE HAZARD

exist for all personnel within 15 Feet of an operating drilling unit. Personnel must wear approved ear protection equipment. Failure to do so may result in impairment or loss of hearing.

b

INTRODUCTION

1. SCOPE

This manual covers the 600 Feet Capacity Well Drilling System, Model LP-12, NSN 3820-01-246-4276. This manual consists of six volumes.

2. DRILLING SYSTEM

The Drilling System consists of three main components; a well drilling machine; a support vehicle (rig tender); and a well completion kit. Government furnished (GFE) incorporated as part of the system include a trailer mounted power unit and 3,000 gallon, collapsible, fabric water tank.

3. DRILLING MACHINE - VOLUME 1

The drilling machine is a truck mounted rotary well drilling machine consisting of a 32 foot mast, three drum drawworks assembly, rotary table, mud pump and air compressor. The components of the drilling machine are powered by the truck engine.

4. SUPPORT VEHICLE - VOLUME 2

The support vehicle is a truck mounted vehicle consisting of a 1,000 gallon water tank, hydraulically driven water pump, an electric fuel pump and fuel dispensing nozzle, a welder-generator assembly, and an electro-hydraulic crane. The support vehicle also provides a storage area for transport of drill pipe, collars, hand tools, operating and accessory equipment for the drilling machine, and the well completion equipment.

5. TRUCKS - VOLUMES 3, 4 and 5

The drilling machine and support vehicle are mounted on truck chassis of the same model. The drilling machine truck has a special design low profile cab. The truck is a diesel engine powered, 6x6 vehicle with a transfer case to transfer engine power to truck mounted components.

6. WELL COMPLETION - VOLUME 6

The well completion kit consists of equipment necessary for completion of a 600-ft. water well.

7. OPERATION INSTRUCTIONS

Refer to TM5-3820-256-10 for Operation, Preventive Maintenance and Lubrication of the Well Drilling System.

8. REPAIR PARTS

For repair parts refer to TM5-3820-256-24P, Repair Parts and Special Tools List.

9. APPENDIXES - VOLUME 6

Maintenance Allocation Chart is contained in Appendix A; Torque Requirements are contained in Appendix B.

TABLE OF CONTENTS

VOLUME I

CHAPTER 1. GENERAL DESCRIPTION

1-1 Description 1-1
1-2 Capabilities 1-1
1-3 Repair Parts 1-1
1-4 Tabulated Data..... 1-2

CHAPTER 2. 2-1

CHAPTER 3. SERVICE AND LUBRICATION

3-1 Periodic Service 3-1
3-2 Lubrication 3-4

CHAPTER 4. MAINTENANCE

4-1 Introduction 4-1
4-2 Troubleshooting..... 4-1
4-3 Maintenance of Air System..... 4-21
4-4 Maintenance of the Mud Pump Drive..... 4-32
4-5 Maintenance of the Mud Pump..... 4-38
4-6 Maintenance of the Subdrive Assembly..... 4-46
4-7 Maintenance of Air Compressor Drive 4-81
4-8 Maintenance of Water Injection System 4-101
4-9 Maintenance of Drawworks..... 4-112
4-10 Maintenance of Rotary Table Drive 4-130
4-11 Maintenance of Rotary Table Transfer Cylinder..... 4-141
4-12 Maintenance of Leveling Jacks..... 4-144
4-13 Maintenance of the Mast 4-146
4-14 Maintenance of Chain Feed Drive 4-151
4-15 Maintenance of Discharge Piping Assembly 4-159
4-16 Mast Raising Cylinder Assembly..... 4-164
4-17 Hydraulic Breakout Assembly 4-166
4-18 Maintenance of Hydraulic System 4-169
4-19 Maintenance of Winch Assembly..... 4-171
4-20 Maintenance of Frame Components..... 4-185

Approved for public release; distribution is unlimited.

TABLE OF CONTENTS - Continued

VOLUME 2

CHAPTER 1. GENERAL INFORMATION

1-1 Introduction 1-1
1-2 Tabulated Data..... 1-1

CHAPTER 2. 2-1

CHAPTER 3. WATER TANK AND PUMPING SYSTEM

Maintenance

3-3 Water Pump..... 3-4
3-4 Hydraulic Motor 3-6

CHAPTER 4. WELDER GENERATOR

Section 1. Safety Rules for Operation of Arc Welding Power Source

4-1 Introduction 4-1
4-2 General Precautions..... 4-1
4-3 Arc Welding 4-7
4-4 Standards Booklet Index..... 4-10

Section 2. Introduction

4-5 General Information and Safety..... 4-11

Sections 3 thru 5 refer to TM 5-3820-256-10

Section 6. Maintenance

4-9 Maintenance..... 4-22
4-9 Maintenance..... 4-22
4-10 Engine Maintenance..... 4-26

Section 7. Troubleshooting

4-11 Troubleshooting Chart 4-30
4-12 Booster Battery Jump Starting..... 4-33
4-13 Engine Specification Data 4-35

CHAPTER 5. CRANE

Maintenance

5-4 Lubrication and Service..... 5-9
5-5 Field Testing 5-11
5-6 Troubleshooting..... 5-12
5-7 Crane Assembly 5-13

TABLE OF CONTENTS - Continued

VOLUME 2 - Continued

CHAPTER 6. WINCH

6-2	Lubrication	6-3
6-3	Adjusting the Oil Cooled Worm Brake	6-3
6-4	Attaching Wire Rope to the Drum	6-4
6-5	Preventive Maintenance	6-5
6-6	Troubleshooting.....	6-5
6-7	Maintenance of Worm Brake.....	6-6
6-8	Winch Overhaul	6-9

CHAPTER 7. HYDRAULIC PUMP/PTO ASSEMBLY

7-1	Hydraulic Pump.....	7-1
7-2	Power Take-Off.....	7-9

CHAPTER 8. FUEL TRANSFER

8-1	Fuel Pump.....	8-1
8-2	Fuel Transfer Motor.....	8-2

TABLE OF CONTENTS - Continued

VOLUME 3

CHAPTER 1. GENERAL INFORMATION

1-1 Introduction 1-1
1-2 Component Code Numbers 1-1

CHAPTER 2. OPERATION 2-1

CHAPTER 3. MAINTENANCE

3-1 Preface 3-1
3-2 Axle - Front 3-2
3-3 Axle- Rear 3-2
3-4 Brakes 3-2
3-5 Cab 3-4
3-6 Care of Vehicle 3-4
3-7 Clutch 3-4
3-8 Electrical 3-5
3-9 Engine 3-5
3-10 Frame and Tow Hooks 3-10
3-11 Fuel and Lubricant Additives 3-10
3-12 Fuel System 3-10
3-13 Supporting Vehicle for Service 3-11
3-14 Propeller Shaft 3-11
3-15 Springs 3-11
3-16 Steering 3-12
3-17 Tires 3-13
3-18 Transmission 3-16
3-19 Wheels 3-16

CHAPTER 4. LUBRICATION

4-1 Lubrication Instructions 4-1
4-2 Specifications and Capacities 4-11

TABLE OF CONTENTS - Continued
VOLUME 4

Subject	CTS No.
GENERAL INFORMATION	Pages 4-10
GROUP 01 FRAME	4004
GROUP 02 FRONT AXLE Model FA-83 Fabco (SDA-12)	
GROUP 03 SPRINGS	
SUSPENSION ALIGNMENT	4016
SPRINGS, SHOCK ABSORBERS	4168
EQUALIZING BEAM SUSPENSION (HENDRICKSON)	4169
GROUP 04 BRAKES	
AIR BRAKES	
Air System, General Information	4154
Air Compressor	
Midland Ross EL-1300-1600	4077
Components.....	4079
Foundation Brake Group	
Cam Actuated Type (Includes Air Chambers and Manual Slack Adjusters)	4080
Reconditioning Brake Drums and Shoes.....	4082
PARKING BRAKES	
MGM Stopguard	4101
GROUP 05 STEERING	
PUMPS	
Eaton	4027
COLUMNS	4150
GROUP 06 PROPELLER SHAFT	4017
GROUP 07 EXHAUST	-----
GROUP 08 ELECTRICAL	
ALTERNATOR: IH 08142	4043
BATTERY:	
"Fleetrite" International Low Maintenance and Maintenance-Free	4111
CIRCUIT DIAGRAMS: Regular Cab.....	4341
GENERAL: Lights	4088
INSTRUMENTS.....	4140
STARTING MOTOR:	
Delco-Remy Heavy Duty	CGES-230
GROUP 09 FRONT END SHEET METAL (See Group 16)	-----
GROUP 10 LUBRICATION	4033

TABLE OF CONTENTS - Continued
VOLUME 4 - Continued

GROUP 11 CLUTCH

CLUTCH ASSEMBLY

Code 11369..... 4195

CLUTCH LINKAGE

S-Series 4050

TABLE OF CONTENTS - Continued
VOLUME 5

Subject	CTS No.
GROUP 12 ENGINE	
DIESEL ENGINE	
Diagnostic Manual DT/DTI 466.....	CGES-240-4
DT/DTI Engine	
Service Manual	CGES-185-3
Injection Pump (Robert Bosch Model MW) and Nozzles.....	CGES-375
Turbocharger.....	4104
COOLING SYSTEM	4181
 GROUP 13 TRANSMISSION	
CM5952D SPICER 5-SPEED	
 GROUP 14 REAR AXLES	
TANDEM RA-355	4044
 GROUP 15 FUEL TANKS	

 GROUP 16 BODY CAB/COWL	
CAB.....	4065
Repair Instructions Using Fiber Glass Material	4049
Air Conditioning/Heating Systems Basic Theory and General Application.....	4194
WINDSHIELD WIPER/WASHERS	
Windshield Wiper (Electric)	4056
Windshield Wiper/Washer.....	4061
 GROUP 17 WHEELS, RIMS AND TIRES	
4148	

TABLE OF CONTENTS

VOLUME 6

Subject	CTS No.	
CHAPTER 1. GENERAL INFORMATION		
1-1 Introduction	1-1	
1-2 Definitions	1-1	
CHAPTER 2. LOGGING WELLS		
2-4 Troubleshooting.....	2-7	
2-5 Maintenance.....	2-9	
2-6 Interpretation of Electrical Logs	2-9	
CHAPTER 3. WELL CASING		3-1
CHAPTER 4. WATER PRODUCTION		
4-1 Submersible Pump	4-1	
4-2 Water Production	4-7	
4-4 Troubleshooting.....	4-13	
Appendix A Maintenance Allocation Chart.....	A-1	
Appendix B Torque Requirements.....	B-1	

LIST OF ILLUSTRATIONS - Volume 1

Figure		Page
3-1	Lubrication Chart.....	3-5
4-1	Air Compressor Diagrams	4-19
4-2	Controlair Valve	4-22
4-3	Adjustment Set-Up.....	4-24
4-4	Pilotair Valve	4-26
4-4A	Air Line Conditioner Unit	4-29
4-5	Mud Pump Drive Assembly.....	4-33
4-6	Clutch Plate Wear Limits	4-36
4-7	Mud Pump Drive Clutch.....	4-36
4-8	Mud Pump	4-39
4-9	Subdrive Assembly, Major Components.....	4-47
4-10	Subdrive Assembly, Exploded View	4-50
4-11	Power Take-Off.....	4-54
4-12	Hydraulic Pump	4-61
4-13	Hydraulic Pump Control	4-64
4-14	Cylinder Block Kit.....	4-66
4-15	Pump Flow Adjustment	4-67
4-16	Hydraulic Gear Pump.....	4-68
4-17	Body Pore Measurement.....	4-69
4-18	Pump Gears.....	4-70
4-19	Displacement Pump.....	4-72
4-19A	Driveshaft	4-82
4-20	Shaft Seal Assembly.....	4-83
4-21	Air Compressor Drive Clutch.....	4-86
4-21A	Oil Filter.....	4-88
4-21B	Hydraulic Cooling Fan Motor	4-89
4-21C	Thermostatic Bypass Valve.....	4-90
4-21D	Air Compressor Air Filter.....	4-92
4-21E	Inlet Throttle Assembly	4-93
4-21F	Air/Oil Separator	4-95
4-21G	Force Feed Lubricator.....	4-99
4-21H	Lubricator Assembly.....	4-100
4-22	Water Injection Pump	4-103
4-22A	Foam Pulse Pump	4-106
4-22B	Water Injection Drive Motor	4-107
4-23	Bevel Gear Box Assembly	4-113
4-24	Third Drum.....	4-116
4-25	Third Drum Clutch.....	4-118
4-26	Hoisting and Auxiliary Drum.....	4-121
4-27	Hoisting and Auxiliary Drum Clutch.....	4-123
4-28	Rotorseal	4-126
4-28A	Drum Brakes.....	4-127
4-28B	Third Drum Clutch Control	4-129

LIST OF ILLUSTRATIONS - Volume 1 (Contd)

Figure		Page
4-29	Fixed Displacement Motor	4-131
4-30	Motor Manifold Valve Assembly	4-136
4-30A	Rotary Table Transmission	4-139
4-30B	Rotary Table Sliding Base	4-142
4-31	Rotary Table Transfer Cylinder	4-143
4-32	Hydraulic Leveling Jack	4-145
4-33	Crown Block Assembly	4-147
4-34	Chain Feed Sprocket	4-149
4-34A	Chain Pulldown Assembly	4-150
4-35	Service Tools	4-151
4-36	Chain Feed Drive Motor	4-153
4-37	Pulldown Transmission	4-156
4-37A	Pulldown Transmission Control	4-160
4-38	Shear Relief Valve	4-161
4-39	Discharge Ball Valve	4-163
4-40	Mast Raising Cylinder	4-165
4-40A	Breakout Tong Assembly	4-167
4-41	Breakout Cylinder	4-168
4-42	Hydraulic Piping	4-168.1
4-43	Hydraulic Oil Filter	4-170
4-44	Winch Assembly	4-172
4-45	Winch Motor	4-176
4-45A	Timing the Winch Motor	4-177
4-46	Power Take-Off, Winch	4-179
4-47	Winch Pump	4-181
4-48	Drill Platform Assembly	4-186

LIST OF TABLES - Volume 1

Table		Page
1-1	Tabulated Data	1-2
3-1	Periodic Services	3-1
4-1	Troubleshooting	4-1
4-2	Air Compressor Troubleshooting	4-17
4-3	Clearance Limits	4-45

LIST OF ILLUSTRATIONS - Volume 2

Figure	Title	Page
3-4	Water Pump, Exploded View	3-5
3-5	Water System Hydraulic Motor	3-7
4-7	Brush Replacement.....	4-24
4-8	Engine Speed Adjustments	4-25
4-9	Air Cleaner.....	4-27
4-10	Checking Valve Clearance	4-28
4-11	Cylinder Head Tightening Sequence	4-29
4-12	Circuit Diagram For Automatic Idle Control Circuit Board PCi	4-36
4-13	Circuit Diagram For Voltage Regulator Circuit Board PC2.....	4-37
5-4	Crane and Hydraulics Lubrication.....	5-10
5-5	Troubleshooting Chart.....	5-12
5-6	Crane Winch Motor.....	5-13
5-7	Crane Winch, Exploded View.....	5-15
5-8	Crane Winch Motor.....	5-19
5-9	Extension Boom Assembly.....	5-22
5-10	Main Boom Assembly	5-24
5-11	Main and Extension Cylinders	5-27
5-12	Rod Seal Installation	5-28
5-13	Control Valve	5-29
5-14	Turret and Crane Base.....	5-33
5-15	Hydraulic Diagram, Crane.....	5-35
5-16	Electrical Schematic, Crane	5-36
6-1	Attaching Wire Rope.....	6-4
6-2	Worm Brake	6-7
6-3	Adjustment Adapter	6-8
6-4	Winch, Exploded View	6-10
7-1	Check Valve Tool.....	7-2
7-2	Seal Removal Tool	7-3
7-3	Special Steel Sleeve	7-3
7-4	Hydraulic Pump	7-5
8-1	Fuel Transfer Pump and Motor	8-3

LIST OF TABLES - Volume 2

Table	Title	Page
4-1	Engine Maintenance Chart.....	4-26
4-2	Engine Torque Values.....	4-30
4-3	Troubleshooting.....	4-31
6-1	Specifications.....	6-2
6-2	Troubleshooting.....	6-5

LIST OF ILLUSTRATIONS - Volume 3

Figure	Title	Page
3-1	Deleted	
3-2	Steering Column Clamp or Yoke Bolt.....	3-13
3-3	Circumferential Tread Channeling.....	3-15
3-4	Disc Wheel Tightening Sequence	3-17

LIST OF TABLES - Volume 3

Table	Title	Page
2-1	Air Restriction Gauge Troubleshooting.....	2-14
2-2	Starting Aid Chart	2-17
3-1	Engine Maintenance Schedule Chart	3-7
3-2	Belt Tension Chart	3-10
3-3	U-Bolt Nut Chart	3-12
3-4	Steering Bolts Chart.....	3-13

CHAPTER 1

GENERAL INFORMATION

1-1. INTRODUCTION

1-1.1 Scope. This manual volume covers operations performed following the drilling of a water well. Information is arranged as follows:

Chapter 1 - General Information

Chapter 2 - Logging Wells

Chapter 3 - Well Casing

Chapter 4 - Water Production

1-1.2 Requirements. Instructions in this manual are used in conjunction with the following equipment:

- a. Electric Logging System, p/n 149F923 (CAGE 21363). This equipment is used following drilling to determine the types and locations of formations in the well borehole.
- b. Kit, Well Completion, p/n 165F004 (CAGE 21363), NSN 3820-01-178-4981. This kit contains components necessary to complete a water well to a depth of 600 feet, and for water production. Components of the kit are listed in Department of the Army Supply Catalog, SC 3820-97-CL-E.
- c. Well Sounder, p/n 149F924 (CAGE 21363). This instrument is used to determine water levels.
- d. Dart Valve Bailer, p/n 149F917 (CAGE 21363). This equipment is used to remove accumulations of sand or mud from well.

1-2 DEFINITIONS

1-2.1 Casing. Pipe constructed of PVC material used to form a 'wall' for a well.

1-2.2 Draw-Down. The distance water recedes from static (standing) level to pumping level.

1-2.3 Overburden. A soft ground formation above a rock layer.

CHAPTER 2

All information in chapter 2 is contained in TM 5-3820-256-10.

2-1/(2-2 Blank)

2-4 TROUBLESHOOTING

2-4.1 Introduction. A "test set" is provided so that you can check the instrument's operation independent of the cable assembly. If the instrument reads the correct value for the test set, then the instrument itself is functioning properly and the trouble is somewhere other than in the electronics of the instrument. To use the test set, plug it into the instrument as described under "Test Set", paragraph 2-1.5, then follow the operating instructions in paragraph 2-2. The electrode selector switch must be in one of the normal logging positions.

2-4.2 Checking Batteries. With the test set plugged into the instrument, turn the function switch to the CAL position and try to calibrate the instrument:

1. If the instrument can be calibrated, then turn the function switch to CUR and check the current by throwing the current switch; if the current flowing is less than 8 ma. (full scale on meter = 25 ma.) then the complete set of six, 9 volt batteries should be replaced.
2. If the instrument cannot be calibrated, the complete set of six, 9 volt batteries should be replaced. (Figure 2-1 A).

NOTE

Refer to battery voltage checking procedure to check the batteries with a voltmeter.

2-4.3 Troubleshooting Procedures. Commonly encountered troubles are listed below along with the corrective procedures.

1. Unable to Calibrate Instrument: Most often caused by insufficient or no current flowing in the ground circuit.
 - a. Check conditions of batteries, replace if necessary.
 - b. Check all lines and plugs for bad connections.
 - c. Sometimes insufficient current is the result of high resistance at the steel surface current electrode. If the galvanometer shows less than 9 ma. and it cannot be increased by rotating the cal adjust knob, then the contact resistance at the steel stake is too high. Reduce the resistance by driving it deeper or pour water around it or double stake until an excess of 8 ma. can be obtained.

If at least 8 ma. cannot be obtained, the ground circuit is too highly resistive (a situation encountered in areas having a thick cover of dry sand or where there is frost on the ground) and obtaining a log in these situations requires the use of the lateral arrangement of electrodes with the CUR wires connected to the well casing.

2. Fluctuation SP: Galvanometer needle fluctuates uncontrollably when function switch is in the log position.

- a. Check surface potential reference (lead oxide flag) to make sure it is buried in moist soil and that the wire from it is not frayed or broken.
 - b. If SP fluctuates badly, stray ground potentials are the cause; this is a situation encountered in highly industrialized areas. To remedy this situation, use the lateral arrangement of electrodes.
3. Unable to Zero the Meter with Self-Potential Potentiometer:
- a. Be sure you have tried reversing the SP polarity switch. To zero the galvanometer the injected voltage must be of proper polarity. Note that the polarity of the SP may change during the logging.
 - b. Check the voltage of the 1 1/2 volt "C" battery. Replace it if necessary.
4. No Meter Response to Self-Potential Potentiometer:
- a. Check all plug-in connections and surface lines, in particular, the potential surface line where it is connected to the lead flag.
 - b. Check the SP shut-off switch. Occasionally if the instrument has not been used for some time, this switch may have become stuck in the off position (depressed). Pushing the button up and down with your finger a couple of times will release the switch.
5. Meter Deflection with no Connections to Instrument:
- a. This condition will be present when water has entered the current switch thereby maintaining an electrical connection within the switch without the switch being activated. When this happens, the switch needs only to be dried with the application of some heat to the switch. Should this happen frequently, a rubber boot should be installed on the switch.
 - b. NOTE: Although this condition is not normal, if proper calibration and operation of the unit can be effected with the test set, then the instrument will operate properly when the current switch is activated.

2-4.4 Battery Voltage Check Using a Voltmeter

NOTE

The following checks are made with the test set connected.

- a. Single 9 Volt Battery: With voltmeter function switch at +DC volts and range switch at full scale reading closest to, but no lower than 10 volts, connect Red (+) lead to positive terminal (male) and Black (-) lead to the opposite (female) terminal of the battery. Record this open circuit voltage. Place function switch in CUR or CAL mode, energize the current switch, and record the battery voltage under load. The voltage should remain at or slightly below the open circuit voltage. If the voltage should continue to change value when the current switch is energized, the battery is defective (weak) and should be replaced.

- b. Five 9 Volt Batteries: With function switch at +DC volts and range switch at full scale reading closest to, but not lower than 50 volts, connect Red (+) lead to exposed positive terminal (male) and Black (-) lead to exposed negative terminal (female) of battery string. Record this open circuit voltage.

Place function switch in CUR or CAL mode, energize the current switch, and record the battery voltage under load.

The voltage should remain at or slightly below the open circuit voltage. If the level should continue to change value when the current switch is energized, the batteries are defective and should be replaced.

All five batteries should be replaced if any are defective.

Although a transistor radio battery (Leclanche' type) will work satisfactorily under most conditions, the alkaline type (Mallory MN 1604 or equivalent) should be installed when the unit is used in adverse weather conditions of cold ambient temperatures as they exhibit better voltage-current characteristics.

2-5 MAINTENANCE

2-5.1 Introduction. Of first importance is that all plugs, panel connections, etc., be kept clean and dry. Moisture on the panel plugs or cable plug can cause current leakage and result in improper operation of the gear. The same is true of the cable and reel. Upon pulling the cable out of the well make sure it is wiped clean.

2-5.2 Maintenance of Resistively Instrument

- a. The only maintenance other than cleaning required is the changing of batteries. The test set will tell you when the 9 volt batteries need replacement. The 1 1/2 volt cell should be replaced every two months. Access to the batteries is by lifting the instrument panel. The battery box will be seen in the bottom of the case (see figure 2-1A).
- b. In operating the instrument, care should be exercised so that the Ohmmeter and Self-Potential Potentiometer dials are not slammed against their zero stops. When turned all the way counterclockwise, they both should read exactly zero. If they do not, loosen the two set screws set 90° apart with the small hex wrench which is taped onto the potentiometers. Reset the knob to zero.

2-5.3 Maintenance of Cable and Reel. In handling the cable, care must be exercised so that damage to the insulation will not occur. The cable should always be wiped clean and when storing, it should be kept in a dry place until such time that the cable is judged to be thoroughly dry.

2-6 INTERPRETATION OF ELECTRICAL LOGS

2-6.1 Preparation of the Log

- a. Basic to a proper interpretation of the electrical log data is the preparation of the graphical log. Any suitable graph paper may be used.

- b. In preparing the log, the 0.25 foot reading, normal, arrangement should be plotted at the depth as read from the marked cable and the 2.5 ft readings about one foot above this point. This is because the cable markings have been measured from the current electrode. For the lateral arrangement, the values are plotted just as is the case for the normal arrangement. If the 10 ft normal is used, its reading should be plotted about 5 ft above the marked cable reading.

2-6.2 Significance of 0.25 ft Spacing. The reading obtained with the 0.25 ft spacing is heavily influenced by the fluid in the well bore and hence it reads only some fraction of the formation resistivity. However, the short spacing enables you to see changes in resistivity with greater detail. With this electrode spacing, formations having a thickness of about 6 inches or greater can be detected. Because of this ability to see small detail, the 0.25 ft curve should be used to "pick" formation boundaries.

2-6.3 Significance of 2.5 ft Spacing. The 2.5 ft electrode spacing provides you with very nearly the true formation resistivity for wells having diameters up to about 16 inches and for formations thicker than about 5 ft. For larger diameter wells or thinner formations, the measured resistivity will depart somewhat from the true. For qualitative interpretation this departure is not significant. Because the 2.5 ft curve provides you with the formation resistivity, it is used to identify the type of material penetrated.

2-6.4 Significance of the Lateral Log. The lateral log obtained with the equipment is made by a combination of either the 0.25 or 2.5 ft electrode with the 10 ft. electrode. Because the 10 ft electrode is at a distance fairly large compared with either of the other two, the interpretation is essentially the same as for the normal log after using the appropriate correction factors.

- a. For the 0.25 lateral log, the meter factor is 1.025.
- b. For the 2.50 lateral log, the meter factor is 13.33.

2-6.5 Interpretation of Resistivity Values.

- a. In interpreting the resistivity values obtained, clays and shales will be low resistive and sands, gravels, sandstones and limestones will be high resistive. Igneous and metamorphic rocks (such as granites and gneisses) will most generally be extremely high resistive.
- b. The exact range of numerical values will depend upon the:
 - 1. Type of earth material making up the formation.
 - 2. Degree of cementation of the formation.
 - 3. Water quality of the formation water.
 - 4. Porosity of the formation.
 - 5. Diameter of the well bore.
 - 6. Resistivity of the fluid in the well bore.

- c. In interpretation, the unknowns will generally be 1, 2, 3 and 4. Granular materials will be high resistive compared to fines such as silt and clay; crystalline materials (such as limestone or granite) will be high resistive compared to the granular materials.
- d. The quality of the formation water will greatly affect the measured resistivity.

In general, the resistivity of a formation will vary in an inverse proportion to the total dissolved solids. For example, all other conditions remaining the same, if the total solid content increases, the formation resistivity will decrease. Hence a clean sand filled with salty water may actually be extremely low resistive.

- e. Porosity of the formation also has an effect on the resistivity. It is not as pronounced as the effect from water quality. In the logging of chemical precipitates, such as limestone, changes in porosity may enable you to detect the water producing zones. Increased porosity will lower the formation resistivity and hence in such material a low resistive zone (where no shale is present) is indicative of increased porosity. This is then indicative of possible water production.
- f. The exact range of values for clean sand, gravel, or sandstone is something which you learn by experience in your own particular area. In the midwest United States, clean sand and gravel generally exhibit resistivity values in the range of from 350 to 1000 ohmft. The lower values apply to formations having water quality in the range of 300 to 400 ppm total solids and the upper values apply for formation waters having 100 to 150 ppm total solids. The above remarks are, of course, very general and are included for guidance only.

2-6.6 Selecting Formation Contact. In "picking" the formation boundaries, the 0.25 ft curve should be used wherever possible. The inflection point (the point midway between changes in curvature of the resistivity curve) of the resistivity curve is used to mark the contact between different formations.

2-6.7 Correlation by Electrical Logs.

- a. A useful application of the electrical logs is in correlating formation thickness' and depths from one well to another. For example, two wells within a few feet of each other invariably will give identical electrical logs. When the wells are farther apart, the correlation will still be recognizable and the changes which do occur, as for example thickening or thinning of beds, are exactly the information needed to guide further exploration.
- b. Correlation is commonly possible to considerable distances in bedrock formation, in the order of thousands of feet. Because of the variable nature of unconsolidated glacial and alluvial deposits, do not expect such distances except in special cases of a single, widespread type of deposit.

2-6.8 The Effect of Metal on the Resistivity Log.

- a. Because metal is such a good conductor, its presence in the zone of measurement, as for example air lines which have dropped to the bottom of the well, will cause a major decrease in the resistivity and make the log unusable, in so far as determining formation type. This effect, however, may be used to locate such steel in the well.

- b. In making the log, the bottom of the well casing will be detected when the probe enters it. The effect on the curves will be that both fall off to extremely low values, 5 to 20 ohmft, and then remain fairly constant. Where the casing is seated into very low resistive shale, it may be rather difficult to determine the exact position of the casing by this method.

2-6.9 The SP Curve.

- a. The spontaneous potentials measured in a borehole are of great value in deep oil wells where saline waters are encountered. For these situations the SP curve exhibits a great deal of character and can be related to relative changes in formation permeability.
- b. When logging in fresh water horizons, the SP curve will usually be featureless and provide little or no useful information.

CHAPTER 3

All information in Chapter 3 is contained in TM 5-3820-256-10.

3-1/(3-2 Blank)

CHAPTER 4
WATER PRODUCTION

4-1 SUBMERSIBLE PUMP

4-1.1 Setting the Pump.

- a. Check to see that the end of the drop hose is cut square. Use a sharp knife or hacksaw to cut the hose if required.
- b. Install the hose coupling into the end of the drop hose. (Refer to figure 4-1).

NOTE

If insertion of the coupling is difficult, a small slit (maximum 1 inch) may be made in the end of the hose. DO NOT use any form of lubrication on hose or coupling.

- c. Push the hose fully on shank of coupling. The end of coupling may be tapped lightly on a wood surface if necessary.
- d. Use a sharp knife and cut away about 6 inches of the cable ridge from the hose. File any upstanding part of the ridge until flush with hose cover.

NOTE

The coupling clamp contains a grooved portion on the inside. The grooved portion should be located toward the coupling.

- e. Assemble the coupling clamp onto hose and install the screws. Tighten the screws evenly then, using a torque wrench, tighten screws to 4.4 ft.-lbs.

NOTE

The clamp halves may not close completely. A maximum gap of 1/32 inch is acceptable. If halves close completely before screws are tight, loosen screws and reposition clamp higher on coupling taper.

- f. Install nipple in check valve, then check valve to hose coupling. Attach hose assembly to submersible pump.
- g. Loosen both nuts of the hose elevator clamp and move the swing bolt aside. Position the clamp half with the lifting loop to the side of drop hose opposite the cable ridge.
- h. Close the hose elevator clamp on hose and reposition swing bolt. Tighten both nuts finger tight. Be sure the hose is square and centered in the clamp.




Figure 4-1. Setting the Pump

- i. Tighten both nuts equally to a torque of 40 ft.-lbs., ensuring clamp faces remain parallel.
- j. Attach the auxiliary drum line to the hose elevator clamp. Operate the auxiliary drum to lift the hose, with attached submersible pump.
- k. Position the pump motor upright on a block of wood and maneuver the pump directly above the motor.
- l. Slowly lower the pump, guiding by hand until the pump coupling is over the motor shaft. Rotate the pump to line up coupling slots with key in motor shaft.
- m. Slowly lower the pump until very close to contact with motor then install screws and lockwashers.

NOTE

The hardware attaching pump to motor is stainless steel. No other material may be substituted.

- n. Check that pump and motor are properly aligned and tighten screws.
- o. Follow instructions in paragraph 4-1.2 and splice power cable to motor leads.
- p. Attach the power cable to the submersible pump using the cable guard and cable clamp.
- q. Position the pump and motor over the hole and slowly lower the pump into the hole until hose elevator clamp is resting atop casing.
- r. Install the wellhead roller above the well with the hose positioned over the roller. Refer to figure 4-2.
- s. Anchor the wellhead roller to the rig using anchor chains or cable.
- t. Using the crane of the support vehicle, pick up the roll of drop hose and position such that the hose lays across the truck cab. Slowly back the support vehicle away from the hole, unrolling hose along ground, 50 feet or more.
- u. Attach another hose elevator clamp (refer to steps g. through i.) and anchor the clamp to the front of support vehicle.
- v. Roll the power cable out along the drop hose. Attach the cable to the hose using cable straps as shown in figure 4-3. Straps should be inserted at 6 ft. intervals. Allow slack in cable between straps, as in figure 4-3, to allow for extension of drop hose under service. The cable should be approximately 2% longer than hose length.
- w. Reverse the support vehicle enough to raise clamp at well sufficiently for clamp to be removed.
- x. Slowly drive support vehicle toward well, lowering pump and motor into well. When vehicle is near wellhead roller, stop and re-install hose elevator clamp at




Figure 4-2. Installing Submersible Pump and Motor




Figure 4-3. Strapping Cable to Hose

top of well, then move vehicle forward enough to support the pump and motor with clamp at well.

- y. Remove the hose elevator clamp at support vehicle and reverse vehicle, unrolling more hose as needed. Attach power cable and anchor hose to support vehicle as before.
- z. Repeat above procedure as many times as necessary to lower the pump and motor to 4 to 5 feet from bottom of the well.
- aa. Assemble a clamp to hose at top of well casing, relieve tension on clamp at support vehicle, then cut drop hose squarely with a sharp knife or hacksaw 10 to 12 inches above clamp at well. (Refer to figure 4-4).
- ab. Install the hose coupling in hose and assemble coupling clamp in the same manner as other hose end. (Refer to steps a. through e.) ac. Unroll power cable to length necessary to reach starter panel and cut power cable. Insert power cable through the smaller hole in well seal.
- ad. Assemble nipples to elbow and insert one nipple through well seal. Connect the nipple to hose with pipe coupling. Install gate valve on other nipple.
- ae. Attach the auxiliary drum line to the elbow and lift assembly to raise clamp from atop well casing. Remove clamp from hose.




Figure 4-4. Sealing Well


- af. Lower the assembly into the well, guiding the well seal into the casing. Tighten the screws on the well seal to compress and expand the seal's rubber center. Remove auxiliary line.

4-1.2 Splicing Submersible Cable. Use the following steps to splice the power cable to submersible motor cable. An illustrated example follows each narrative step.


NOTE

When power cable and motor leads are not the same size, select connector for larger size cable. Strands of copper wire should be used together with smaller cable to fill connector.

- a. Cut motor lead and power cable so that ends will butt squarely. Thoroughly clean cable jacket for 4 inches beyond dimension (A) with non conductive abrasive cloth from cable splicing kit.




- b. Remove cable jackets for distance (A), plus one half connector length. Do not cut into cable insulation. If jacket is bonded to insulation, do not remove, and treat it as insulation. Remove cable insulation and strand shielding from end of conductors for 1/2 inch plus one-half length of connector. Do not nick conductor.



- c. Pencil (taper) insulation for distance (B) and smooth with non-conductive abrasive cloth from splice kit.




- d. Join conductors using crimp connector. Clean entire area of prepared splice by wiping with a solvent saturated cloth from kit.



CAUTION

Area must be absolutely dry and free of all solvent residue (especially in conductor strands) before applying any tapes.


- e. Fill any connector indents with small pieces of semi-conducting tape. Tightly level wind tape across connector area, overlapping 1/16 inch onto each edge of the penciled insulation. Form smooth concentric buildup, as shown.



- f. Tightly half-lap splicing tape across connector area, building up to dimension (D) with a smooth taper along distance (C), reaching maximum diameter over penciled insulation.

NOTE

Highly stretch and exactly half-lap tape to produce a void-free, uniform buildup.



- g. Tightly half-lap two layers of vinyl plastic electrical tape over entire splice, extending for one (1) inch onto each cable jacket.



4-2 WATER PRODUCTION

4-2.1 Pump Starter Panel. (Figure 4-5)

- a. Attach starter panel to panel stands, using screws, lockwashers and nuts that are stored on panel standfoot.
- b. Stabilize the panel by placing sandbags on the stand feet or by driving stakes into the ground at holes in stand feet.
- c. Turn the door locking screws one-half turn to disengage door locks. Open panel door.
- d. Cut outer insulation back on pump cable about twelve inches. Strip insulation

on each lead to expose approximately 3/4 inch of wire.

- e. Insert the pump leads through the hole in bottom of panel.
- f. Connect the leads as follows: black to T1, red to T2, yellow to T3, and green to ground.
- g. Strip away approximately six inches of outer insulation from power source cable and strip away approximately 3/4 inch of insulation from each lead.
- h. Insert the power source cable through hole in side of panel and connect leads at Line 1, Line 2, Line 3 and Ground.
- i. Close panel door and turn door locking screws to engage door locks.




Figure 4-5. Starter Panel Installation

- e. Allow concrete to cure, then remove forms.

4-4 TROUBLESHOOTING

4-4.1 Table 4-1 describes some problems which may occur with the submersible pump, with their possible cause, procedure for checking, and method for correction.

Table 4-1. Troubleshooting

CAUSE OF TROUBLE	CHECKING PROCEDURE	CORRECTION
FUSES BLOW WHEN MOTOR STARTS		
A. Incorrect voltage	Using a voltmeter check the line terminals. Voltage must be within plus or minus 10% of nominal.	Check power source if voltage is incorrect.
B. Incorrect fuses	Check fuses for recommended size and check for loose, dirty or corroded connections in the fuse receptacle.	Replace with proper fuses.
C. Defective pressure switch	Check voltage at contact points. Improper contact of switch points can cause voltage less than line voltage.	Replace pressure switch or clean points.
D. Control box malfunction	Check wiring against diagram in control box. Check for loose connections. Control box-motor	Correct wrong wiring circuits. Press prong connectors to assure
1. Wrong connections	must match and be same as supply voltage.	contact. Correct short circuit.
2. Defective relay	Check relay coil with ohmmeter. No movement of needle, if capacitor is good, indicates defective relay point contact.	Replace relay.
3. Defective capacitor	Check resistance across capacitor terminals with ohmmeter. Ohmmeter needle should jump at once when contact is made then move up slowly. An open capacitor or no current to the capacitor is indicated when no movement occurs. A shorted capacitor will not give resistance reading.	Replace capacitor.
E. Bound pump	Locked rotor conditions can result from misalignment between pump	Sand bound pump can sometimes be corrected

Table 4-1. Troubleshooting Cont'd.

CAUSE OF TROUBLE	CHECKING PROCEDURE	CORRECTION
E. Bound Pump - con't.	and motor caused by wedging in a crooked well or rough handling at installation. Locked rotor readings can also indicate a sand bound pump. Amp readings 3 to 6 times higher than normal will be indicated.	by temporarily reversing black and red leads in control box then returning to normal. If pump does not rotate freely it must be pulled and cleaned or realigned and the well condition corrected.
F. Defective cable or motor wind- ind	Attach one ohmmeter lead to the drop pipe or well casing and touch the other lead to each motor lead. If the needle moves appreciably a ground is indicated in either the motor or the drop cable.	The pump must be pulled and the cable disconnected and inspected. Damaged cable should be correctly spliced or replaced. If cable is good, the motor winding is grounded.
1. Shorted or open	Disconnect motor leads from control box, note length and size of drop cable and use ohmmeter to check resistance. Low ohms may indicate shorted motor winding. High resistance (no movement of needle) can mean an open circuit in winding or broken but not exposed lead cable conductor.	The pump must be pulled and motor or drop cable repaired or replaced.
MOTOR DOES NOT START -- FUSES DO NOT BLOW		
A. No power	Check fuses or circuit breaker.	Replace fuses or reset breaker.
B. Defective pressure switch	Check voltage across pressure switch with contact closed. If voltage drop is equal to line voltage the switch is not making contact.	Clean contact points or replace switch.
C. Defective wiring	Check for loose or corroded connections. Check motor lead terminals with voltmeter for power.	Correct faulty wiring or connections.
PUMP RUNS BUT DELIVERS LITTLE OR NO WATER		
A. Air locked pump	Pump can be heard running but no water noise is detected.	Normal delivery may resume if pump is started and stopped at one minute intervals.

Table 4-1. Troubleshooting Cont'd.

CAUSE OF TROUBLE	CHECKING PROCEDURE	CORRECTION
B. Low water level in well	Water delivery good on start up but diminishes. Pump capacity too great for well production. Pump may be set in sand.	Throttle pump delivery through restricting valve. Lower pump setting if depth of well is adequate.
C. Pump rotation wrong	Lower water delivery or low pressure may indicate pump operating in wrong direction.	Rotation can be corrected by properly connecting 10 3-wire units or by interchanging two leads of 30 units.
D. Check valve stuck or installed improperly	No water will be delivered if valve is installed with flow arrow in wrong direction.	Valve must be reversed.
	If drop pipe is screwed into the pump check valve too deeply it may be jammed in the closed position.	Cut off a portion of the threads on the drop pipe.
E. Leak in drop pipe	Although water is being supplied to tank the pump may not deliver sufficient pressure to shut off the system. The "on" portion of the cycle increases.	Raise pipe, check for leak and replace damaged section.
F. Pump screen blocked	Restricted flow may indicate a clogged intake screen on pump. Pump may be installed in mud or sand.	Clean screen and reset at less depth. It may be necessary to clean well.
G. Worn pump	Symptoms of worn pump are similar to those of drop pipe leak or low water level in well. pressure switch setting, if pump shuts off worn parts may be at fault. Sand is usually present in tank.	Pull pump and replace worn impellers, casing Reduce or other close fitting parts.
H. Loose or broken motor shaft	No water will be delivered if coupling between motor and pump shaft is loose or if a jammed pump has caused the motor shaft to shear off.	Check for damaged shafts if coupling is loose and replace worn or defective units.

Table 4-1. Troubleshooting Cont'd.

CAUSE OF TROUBLE	CHECKING PROCEDURE	CORRECTION
PUMP KEEPS RUNNING		
A. Pressure switch	Switch points may be "welded" in closed position.	Clean points or replace switch.
B. Low level well	Pump may exceed well capacity. Shut off pump, recover. Check static level from well head.	Throttle pump output wait for well to or reset pump to lower level. Do not lower if sand may clog pump.
C. Leak in system	Check pipe one unit at a time for leak.	Replace damaged section.
D. Worn pump	Abrasives in water may indicate wear. Reduce pressure setting of switch until pump shuts off. If pressure is insufficient unit must be replaced.	Pull pump and replace.
PUMP STARTS TOO OFTEN		
A. Pressure switch	Check setting on pressure switch and examine for defects.	Reset limit or replace switch.
B. Leak in system	Tank may be leaking air above water level. Delivery pipe into house or hiddle lines.	Repair or replace tank or pipes.
C. Check valve	Damaged or defective check valve will not hold pressure.	Remove and replace if defective.
D. Air supply (waterlogged tank)	Check air volume control or snifter valve for improper operation.	Clean or replace. Drain and recharge tank.

APPENDIX A

MAINTENANCE ALLOCATION CHART

SECTION I

INTRODUCTION

A-1 General

- a. This section provides a general explanation of all maintenance and repair functions authorized at various maintenance categories.
- b. The Maintenance Allocation Chart (MAC) in section II designates overall authority and responsibility for the performance of maintenance functions on the identified end item or component. The application of the maintenance functions to the end item or component will be consistent with the capacities and capabilities of the designated maintenance categories.
- c. Section III lists the tools and test equipment (both special tools and common tool sets) required for each maintenance function as referenced from section II.
- d. Section IV contains supplemental instructions and explanatory notes for a particular maintenance function.

A-2 Maintenance functions. Maintenance functions will be limited to and defined as follows:

- a. Inspect. To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination (e. g., by sight, sound, or feel).
- b. Test. To verify serviceability by measuring the mechanical, pneumatic, hydraulic, or electrical characteristics of an item and comparing those characteristics with prescribed standards.
- c. Service. Operations required periodically to keep an item in proper operating condition, i. e., to clean (includes decontaminate, when required), to preserve, to drain, to paint, or to replenish fuel, lubricants, chemical fluids, or gases.
- d. Adjust. To maintain or regulate, within prescribed limits, by bringing into proper or exact position, or by setting the operating characteristics to specified parameters.
- e. Align. To adjust specified variable elements of an item to bring about optimum or desired performance.
- f. Calibrate. To determine and cause corrections to be made or to be adjusted on instruments or test, measuring, and diagnostic equipments used in precision measurement. Consists of comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.

- g. Remove/Install. To remove and install the same item when required to perform service or other maintenance functions. Install may be the act of emplacing, seating, or fixing into position a spare, repair part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.
- h. Replace. To remove an unserviceable item and install a serviceable counterpart in its place. "Replace" is authorized by the MAC and is shown as the 3d position code of the SMR code.
- i. Repair. The application of maintenance services, including fault location/troubleshooting, removal/installation, and disassembly/assembly procedures, and maintenance actions to identify troubles and restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.
- j. Overhaul. That maintenance effort (service/action) prescribed to restore an item to a completely serviceable/operational condition as required by maintenance standards in appropriate technical publications (i. e., DMWR). Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like new condition.
- k. Rebuild. Consists of those services/actions necessary for the restoration of unserviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of material maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (hours/miles, etc.) considered in classifying Army equipment/components.

A-3 Explanation of Columns in the MAC, Section II

- a. Column 1, Group Number. Column 1 lists functions group code numbers, the purpose of which is to identify maintenance significant components, assemblies, subassemblies, and modules with the next higher assembly. End item group number shall be "00".
- b. Column 2, Component/Assembly. Column 2 contains the names of components, assemblies, subassemblies, and modules for which maintenance is authorized.
- c. Column 3, Maintenance Function. Column 3 lists the functions to be performed on the item listed in Column 2. (For detailed explanation of these functions, see paragraph A-2.)
- d. Column 4, Maintenance Category. Column 4 specifies, by the listing of a work time figure in the appropriate subcolumn(s), the category of maintenance authorized to perform the function listed in Column 3. This figure represents the active time required to perform that maintenance function at the indicated category of maintenance. If the number or complexity of the tasks within the listed maintenance function vary at different maintenance categories, appropriate work time figures will be shown for each category. The work time figure represents the average time required to restore an item (assembly, subassembly, component, module, end item, or system) to a serviceable condition under typical field operating conditions. This time includes preparation time (including any necessary disassembly/assembly time), troubleshooting/fault location time, and quality assurance/quality control time in addition to the time required to perform the specific

tasks identified for the maintenance functions authorized in the maintenance allocation chart. The symbol designations for the various maintenance categories are as follows:

- C Operator or crew
- O Organizational maintenance
- F Direct Support Maintenance
- H General Support Maintenance
- D Depot maintenance/Specialized Repair Activity (SRA)

e. Column 5, Tools and Equipment. Column 5 specifies, by code, those common tool sets (not individual tools) and special tools, TMDE, and support equipment required to perform the designated function.

f. Column 6, Remarks. This column shall, when applicable, contain a letter code, in alphabetic order, which shall be keyed to the remarks contained in Section IV.

A-4 Explanation of Columns in Tool and Test Equipment Requirements, Section III.

a. Column 1, Reference Code. The tool and test equipment reference code correlates with a code used in the MAC, Section II, Column 5.

b. Column 2, Maintenance Category. The lowest category of maintenance authorized to use the tool or test equipment.

c. Column 3, Nomenclature. Name or identification of the tool or test equipment.

d. Column 4, National Stock Number. The national stock number of the tool or test equipment.

e. Column 5, Tool Number. The manufacturer's part number.

A-5 Explanation of Columns in Remarks, Section IV

a. Column 1, Reference Code. The code recorded in column 6, Section II.

b. Column 2, Remarks. This column lists information pertinent to the maintenance function being performed as indicated in the MAC, Section II.

SECTION II. MAINTENANCE ALLOCATION CHART
FOR
DRILLING SYSEM, WELL, ROTARY,
TRUCK MOUNTED, AIR TRANSPORTABLE,
600 FEET CAPACITY

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
00 01	Well Drilling System Well Drilling Rig	Repair Inspect Service Replace Repair	14.4 9.0 2.8 10.6	0.1 46.2 72.4	112.0 141.0	202.5	80.0		
0101	Lighting, Mast	Inspect Replace Repair	0.1 4.0 6.0						
0102	Piping Assy, Discharge	Inspect Replace Repair	0.1 0.1 0.1	1.5 1.5					
010201	Valve, Shear Relief	Replace Repair	0.5 0.1	1.0					
010202	Valve, Ball	Replace Repair	1.5 0.5						
0103	Mast Assy	Inspect Service Replace Repair	1.0 0.6		15.0 13.0	8.0		1,5,6	A,B
010301	Block Assy, Crown	Inspect Replace Repair	0.2 2.0 2.0						
010302	Sprocket Assy, Chain Feed	Inspect Replace Repair	0.2 2.0 1.0						
010303	Pulldown Assy, Chain	Inspect Replace Repair	0.2 2.0 1.5						
0104	Cylinder, Mast Raising	Inspect Service Replace Repair	0.1 0.1 1.5		3.0			1,5,6	B
0105	Drive Assy, Mud Pump	Inspect Service Replace Repair	0.1 0.2		2.0 5.0 3.0 2.0	1.0		1,5,6	B,C
010501	Clutch	Inspect Service Replace Repair	0.2 0.2		2.0 18.0			1,5,6,9,10	B,C
0106	Mud Pump Assy	Inspect Service Replace Repair	8.0 0.5 0.5		8.0	2.0	5.0	1,5,6	

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
010701	Compressor Assy, Air	Replace			3.0				
01070101	Seal Assy, Shaft	Repair				2.0	5.0		
01070102	Clutch Assy	Inspect	0.2		3.0				
01070103	Compressor, Air	Replace				2.0			
010702	Oil Cooler Assy	Repair			3.0				
01070201	Filter, Oil	Replace			3.0				
01070202	Motor, Hydraulic	Repair		1.0					
01070203	Valve, Thermostatic Bypass	Inspect	0.1						
010703	Air Cleaner Assy	Replace		1.0					
010704	Separator Assy, Air/Oil	Repair	0.2		0.5				
0108	Sub Drive Assy	Inspect	0.2						
010801	Driveshaft, Drive	Replace			2.0				
010802	Driveshaft, Mud Pump	Repair		1.0					
010803	Power Take-Off Assy	Inspect	0.1						
		Service	0.2						
		Replace			6.0				B, C
		Repair		5.0	10.0	20.0		1,5,6	
		Inspect	0.1						
		Service	0.2						B
		Replace		1.0					
		Repair		1.5					
		Inspect	0.1						
		Service	0.2						B
		Replace		1.0					
		Repair		1.5					
		Service	0.3						
		Adjust			0.3				
		Replace			2.0				
		Repair			10.0				

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
010804	Pump, Hydraulic Gear	Inspect Replace	0.1		1.0			1.5,6	
010805	Pump, Displacement	Repair Inspect Replace	0.1		3.0	4.0			
010806	Pump, Hydraulic	Repair Inspect Replace	0.1		2.5	10.0			
0109	Drawworks	Repair Inspect Service	0.8			6.0			
010901	Driveshaft	Replace Inspect Service	1.5		4.0				B
010902	Bevel Gear Box Assy	Repair Inspect Service	0.1	35.0	30.0	20.0			B
010903	Brake Assy, Hoist/Aux	Replace Inspect Service	0.2			4.0			C
01090301	Band, Brake	Repair Inspect Adjust	0.1		0.5				
010904	Brake Assy, Third Drum	Replace Inspect Adjust	0.2		1.5				
01090401	Band, Brake	Repair Replace Repair	0.1		1.0				
010905	Control, Third Drum Clutch	Inspect Adjust Replace	0.1	0.5	1.0				
010906	Drum Assy, Hoist & Aux	Repair Inspect Replace	0.2		1.0				
01090601	Rotorseal Assy	Repair Replace	0.2		2.0				
01090602	Clutch Assy	Repair Replace Repair	0.2		3.0				
				0.5	1.0				
					2.5				
					2.0				

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
010907	Third Drum Assy	Inspect Replace	0.2		2.0				
01090701	Clutch Assy	Repair Replace			3.0				
0110	Piping Assy, Hydraulic	Repair Inspect	0.5		2.5				
011001	Filter Assy, Hyd. Oil	Replace Repair		1.0	3.0			1,5,6	
011002	Valve, Relief	Inspect Replace	0.1	0.5	2.0				
011003	Valve, Flow Control	Repair Replace			0.5	1.0			
0111	Injection Assy, Water & Foam	Repair Inspect	0.5			1.0			
011101	Motor, Hydraulic	Service Replace	0.5		4.0			1,5,6	
011102	Pump, Water Injection	Repair Inspect	0.5		6.0	8.0			
011103	Pump, Pulse Foam	Replace Inspect	0.2		1.0	8.0			C
0112	Lubricator Assy	Service Replace	0.5		2.0				
011201	Lubricator	Repair Inspect	0.2	2.0	1.5			1,5,6	
01120101	Pump Assy	Service Adjust	0.2		2.5	4.0			C
01120102	Drive Assy	Repair Replace	0.2	0.5	4.0				
0113	Tong Assy, Breakout	Repair Inspect	0.1		2.5	1.0			
0114	Breakout Assy, Hydraulic	Replace Inspect	1.0					1,5,6	
		Repair	0.2	1.5					
		Repair		2.0		1.0		1,5,6	

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
011401	Cylinder, Hydraulic	Inspect	0.1						
		Replace		1.0					
		Repair				1.0			
0115	Drive Assy, Rotary Table	Inspect	0.2						B, C
		Service	0.5						
		Replace			4.0				
		Repair		2.0		20.0		1,5,6	
011501	Linkage Assy, Shift	Inspect	0.1						
		Adjust		0.5					
		Replace		1.0					
011501	Motor, Fixed Displacement	Inspect	0.2						
		Replace			1.0				
		Repair				10.0			
011503	Transmission, Rot. Table	Inspect	0.2						C
		Service	0.5						
		Replace			1.0				
		Repair				10.0			
011504	Driveshaft	Inspect	0.1						
		Service	0.2						B
		Replace		1.0					
		Repair		1.0					
0116	Deflector, Dust	Inspect	0.1						
		Replace	0.5						
		Repair	0.5					1,5,6	
0117	Cylinder, Table Transfer	Inspect	0.1						
		Replace		1.0					
		Repair				1.5		1,5,6	
0118	Table Assy, Rotary	Inspect	0.2						
		Service	0.5						B, C
		Replace		3.0					
		Repair					10.0	1,5,6	
0119	Base Assy, Rotary Table	Inspect	0.3						
		Replace		2.0					
		Repair		2.0				1,5,6	
0120	Control Assy, Pulldown Trans.	Inspect	0.2						
		Adjust		0.4					
		Replace		0.5					
		Repair		0.5				1,5,6	
0121	Drive Assy, Chain Feed	Inspect	0.4						
		Service	0.5						B, C
		Replace			5.0				
		Repair			3.0	16.0		1,5,6	

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
012101	Motor, Hydraulic	Inspect Replace	0.1		1.5				
012102	Transmission, Pulldown	Repair Inspect Service	0.2 0.5			6.0			C
0122	Panel Assy, Instrument	Replace Repair	0.1		1.5	10.0			
012201	Panel , Compartment	Inspect Replace Repair	0.1		3.0 5.0			1,5,6	
0123	Air Piping Assy	Inspect Service Replace	03 03						
012301	Valve, Controlair	Repair Inspect Replace	0.1	0.5				1,5,6	
012302	Valve, Pilotair	Repair Inspect Replace	0.1	05	1.0				
012303	Unit, Air Line Condition	Repair Inspect Replace	0.2		1.0 2.0				
01230301	Filter, Air Line	Repair Replace		0.3 0.3					
01230302	Regulator, Air	Replace Repair		0.3 0.3					
01230303	Lubricator, Air Line	Adjust Replace Repair		0.2 0.3 0.3					
0124	Control Throttle	Inspect Adjust Replace Repair	0.2		0.2 1.0 0.5			1,5,6	
0125	Lighting Assy, Frame	Inspect Replace Repair	0.1	1.0				15,6	
0126	Mud Flap Assy	Inspect Replace Repair	0.1 0.5 0.5		2.0			1,5,6	

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
0127	Platform Assy, Drill's	Inspect Replace	0.1 0.3						
0128	Jacks & Mtg. Assy	Repair Inspect Replace	0.3 0.2						
012801	Jack, Front Hydraulic	Repair Inspect Replace		1.5		6.0		1,5,6	
012802	Jack, Rear Hydraulic	Repair Inspect Replace	0.1 0.1	0.5		1.5			
0129	Frame Assy, Drill	Repair Inspect Replace				1.5			
0130	Winch Amy, Front Mtd.	Repair Inspect Service Replace	0.4 0.1 0.5			6.0		1,5,6	D E C
0131	Motor, Hydraulic, Winch	Repair Inspect Replace		4.0	4.0			1,5,6	
0132	Valve Amy, Control	Repair Inspect Replace	0.1 0.1		0.5	2.0		1,5,6	
0133	Power Take-Off	Repair Replace			1.0			1,5,6	
0134	Pump, Hydraulic, Winch	Repair Inspect Replace			1.0	2.0		1,5,6	
0135	Jack, Hand, 20 Ton	Repair Inspect Service	0.1 0.1			2.0		1,5,6	
0136	Hand Tools Assembly	Replace		0.1					C
0137	Operating Equipment	Repair		0.1					K
0138	Accessory Kit	Repair		0.1					K
013801	Hoisting Plugs	Repair		05				1	K
0139	Life-Lie, Self Retracting	Inspect Replace Repair	0.1	0.2					L

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
02	Truck, Rig	Inspect Service Replace Repair	5.5 3.1	0.1					
0201	Cab/Body Group	Inspect Replace Repair	0.1		35.7 22.5	91.7 74.0	21.0 83.0		
020101	Cab Trim, Exterior	Inspect Replace Repair	0.1				10.0 6.0		
020102	Cab Trim, Interior	Inspect Replace Repair	0.1			1.0 1.0		1,5,6	
020103	Windshield Wiper Assy	Inspect Replace Repair	0.1			1.0 1.0		1,5,6	
020104	Heater/Defroster Connections	Inspect Replace Repair	0.2 1.0			1.0		1,5,6	
0202	Seat Assy, Driver	Inspect Replace Repair	0.1	1.0		1.5		1,5,6	
0203	Brake Pedal Assy	Inspect Replace Repair	0.1			1.0		1,5,6	
0204	Clutch Pedal Assy	Inspect Adjust Replace Repair	0.1			0.5 1.0			
0205	Accelerator Pedal Assy	Inspect Replace Repair	0.1			0.5 1.0			
0206	Shift Lever Assy	Inspect Replace Repair	0.1			0.5 1.0			
0207	Steering Group Service	Inspect Replace Repair	0.2 0.5			1.0			B
0208	Electrical Components, Cab	Inspect Replace Repair	0.2			4.0 2.0		1,5,6,33, 34,52	
0209	Steering Gear	Inspect Service Replace Repair	0.2 0.1			2.5 1.5		1,5,6	
0210	Engine Cover Assy	Inspect Replace Repair	0.2			2.5	4.0	1,5,6,45, 46,47	C
				2.0 1.0				1,5,6	

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
0211	Exhaust System	Inspect Replace Repair	0.1	1.5 1.0				1,2	
0212	Radiator	Inspect Test Service Replace Repair	0.2 0.3		0.5 3.0			1,5,6,49, 50,51	
021201	Hoses	Inspect Replace	0.1	0.3					
0213	Steering Pump	Inspect Service Replace Repair	0.1 0.1	1.5	3.0			1,5,6	C
0214	Alternator Assy	Inspect Test Replace Repair	0.1	1.0	0.5 2.0			1,5,6,7,8	F
021401	Belts	Inspect Adjust Replace	0.1	0.2 0.4					
0215	Starting Motor Assy	Inspect Test Replace Repair	0.1	1.5	0.5 3.0			1,5,6,7,8	
021501	Solenoid, Starter	Inspect Test Replace	0.1	0.5 1.0					,5,6
0216	Engine Assy, Diesel	Inspect Service Replace Repair	0.2 0.5		10.0 15.0	25.0			C
021601	Air Cleaner Assy	Inspect Service Replace Repair	0.2 0.2	0.5 1.0				1,5,6	
021602	Turbocharger	Replace Repair			1.5 2.0			1,5,6	
021603	Fuel Lines & Filter	Inspect Replace Repair	0.2	1.5 1.5				1,5,6	
021604	Injection Pump, Fuel	Inspect Test Calibrate Replace Repair	0.2			2.0 2.0 2.0	4.0	1,5,6, F 26 thru 32	
021605	Governor	Inspect Replace Repair	0.1		2.5	4.0		1,5,6	

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
021606	Air Compressor	Inspect Replace	0.1		3.0 2.5			1,5,6	
021607	Water Pump	Inspect Replace Repair	0.1		3.0 1.5			1,5,6	
021608	Oil Cooler 6 Filter	Inspect Replace Repair	0.1	1.0	2.0			1,5,6	
021609	Fuel Filter a Mounting	Inspect Replace Repair	0.1	1.0 1.0				1,5,6	
021610	Manifolds, Intake a Ex- haust	Inspect Replace Repair	0.1		2.0 1.0			1,5,6	
021611	Pan, Oil	Inspect Replace Repair		0.1	4.0 1.0			1,5,6	
021612	Oil Pump Assy	Replace Repair			4.0 1.0			1,5,6	
021613	Cover, Engine Front	Inspect Replace Repair	0.1		3.0 1.0			1,5,6	
021614	Cylinder Head Group	Inspect Replace Repair	0.1		2.0 4.0			1,5,6,13, 14,15,38	
021615	Camshaft Group	Replace Repair				2.0 1.5		1,5,6,16	
021616	Piston & Conn. Rod	Replace Repair				2.0 4.0		1,5,6 & 17 thru 23, 38	
021617	Crankshaft Group	Replace Repair				5.0 3.5		1,5,6,24, 25,39	
021618	Crankcase Group	Replace Repair				2.0 5.0		1,5,6	
0217	Transmission	Inspect Service Replace Repair	0.2 0.2		6.0				C
0218	Driveshaft, Transfer Case	Inspect Service Replace Repair	0.1 0.2			16.0		1,5,6	B
				1.0 1.0				1,5,6	

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
0219	Driveshaft, Front Axle	Inspect Service Replace Repair	0.1 0.2						B 1,5,6
0220	Transfer Case	Inspect Service Replace Repair	0.1 0.1		5.0		10.0	1,5,6	C
0221	Clutch Assy	Replace Repair			4.2 1.0			1,5,6	
0222	Brake Chambers, Air	Inspect Replace Repair	0.1		1.0 2.5			1,5,6	G
0223	Hub & Drum, Front	Replace Repair		1.0 1.0	1.0			1,5,6	
022301	Hub, Wheel	Replace Repair		1.0 1.0					
022302	Drum, Brake	Replace Repair			1.0				
0224	Hub & Drum, Rear	Replace Repair		2.0 1.0	1.0			1,5,6	
022401	Hub, Wheel	Replace Repair		1.0 1.0					
022402	Drum Brake	Replace Repair		1.0	1.0				
0225	Brake Assy, Front	Replace Repair		2.0 1.0				1,5,6	
0226	Brake Assy, Rear	Replace Repair		2.0 1.0				1,5,6	
0227	Driveshaft, Rear Axle	Inspect Service Replace Repair	0.1 0.2		1.0 1.0				B 1,5,6
0228	Driveshaft, Interaxle	Inspect Service Replace Repair	0.1 0.2		1.0 1.0			1,5,6	B
0229	Rear Axle Group	Replace Repair			7.0 8.0			1,5,6	
022901	Front Rear Axle	Inspect Service Replace Repair	0.1 0.1		7.0 4.0			1,5,6	C

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
022902	Rear Rear Axle	Inspect Service Replace Repair	0.1 0.1		7.0 4.0			1,5,6	C
0230	Front Axle Assy	Inspect Service Adjust Replace Repair	0.1 0.1		1.5 5.0 2.5			1,5,6	B

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
03	Rig Tender Vehicle	Inspect	3.5						
		Service	4.5						
		Replace	0.6	6.9	37.25	17.5			
0301	Crane Assy	Repair	1.0	5.4	34.0	80.0			
		Inspect	0.1						E
		Service	0.2						A,B
		Replace			8.0				
030101	Boom Assy, Extension	Repair			10.0	15.0		1,5,6	
		Inspect	0.2						
		Service	0.2						B
		Replace			1.5				
030102	Boom Assy, Main	Repair			2.0				
		Inspect	0.2						B
		Service	0.2						
		Replace			2.0				
03010201	Cylinder. Extension	Repair			2.0	1.0			
		Inspect	0.2						
		Replace			1.0				
030103	Turret Assy, Crane	Repair				1.0			
		Inspect	0.1						
		Replace				6.0			
03010301	Cylinder, Main	Repair				4.0			
		Inspect	0.1						B
		Service	0.1						
		Replace			1.0				
03010302	Motor, Hydraulic	Repair				2.0			
		Inspect	0.1						
		Replace			1.0				
03010303	Winch Assy, Crane	Repair				6.0			
		Inspect	0.1						E
		Service	0.2						C
		Replace			1.0				
030104	Base Assy, Crane	Repair			2.0				
		Inspect	0.1						
		Service	0.2						A,B
		Replace				2.0			
03010401	Control Valve	Repair		0.1		6.0			
		Inspect							
		Replace			3.0				
03010402	Motor, Hydraulic	Repair				1.0			
		Inspect	0.1						
		Replace			1.0				
030105	Control Assy, Remote	Repair				6.0			
		Inspect	0.1						
		Replace	0.1						
0302	Welder/Generator	Repair		0.5					
		Inspect	0.1						H
		Service	0.5						
		Replace		1.0					
		Repair		1.5	1.5	2.0		1,5,6	J

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
030201	Panel, Front	Inspect Replace	0.1		1.0				
030202	Generator Assy	Repair Replace			1.5 1.5			1,5,6	
030203	Engine, Diesel	Repair Inspect Service	0.1 0.2		1.0	3.0		1,5,6	
03020301	Air Cleaner	Replace Repair Inspect Service	0.1 0.5		2.5 1.0	3.0		1,5,6	H G
03020302	Alternator	Replace Repair Inspect Test Replace		1.0 1.0 0.1 1.0 0.5				1,5,6	
03020303	Exhaust Group	Repair Inspect Replace	0.1		2.0			1,5,6	F
03020304	Starting Motor	Repair Inspect Test Replace	0.1	0.5 0.2 0.1				1,5,6	
03020305	Injection Pump	Replace Repair			2.0 2.0			1,5,6	
03020306	Cylinder Head & Valves	Adjust Replace Repair			0.5	2.0		1,5,6	
03020307	Camshaft	Replace Repair				2.0 2.0		1,5,6	
03020308	Piston & Connecting Rod	Replace Repair				1.0 2.5		1,5,6	
03020309	Crankshaft	Replace Repair				3.0 1.0		1,5,6	
0303	Flood Light Assy	Replace Repair		0.3 0.2					
0304	Cabinet Assy								
030401	Fuel Transfer Pump	Inspect Replace Repair	0.1		1.0 1.5			1,5,6	
030402	Nozzle, Fuel	Inspect Replace Repair	0.1 0.5 1.0					1,5,6	
030403	Heating Torch Assy	Inspect Replace Repair	0.1	1.0 1.0				1,5,6	

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
0305	Water Pump Assy	Inspect Replace	0.1		1.5				
030501	Water Pump	Repair Inspect Replace	0.1		1.5	4.5			
030502	Hydraulic Motor	Repair Inspect Replace	0.1		3.0			1,5,6	
0306	Reservoir Assy, Hydraulic	Repair Inspect Service	0.1 0.2				2.0	1,5,6	
030601	Valve Assy, Control	Replace Inspect Replace	0.2	1.0	1.0			1,5,6	
030602	Filter Assy	Repair Replace		0.1 1.0			1.5	1,5,6	
0307	Winch Assy	Inspect Service Replace	0.1 0.1		1.0				E C
030701	Winch	Repair Inspect Service	0.1 0.1		1.0	1.0		1,5,6	
030702	Motor, Hydraulic	Replace Inspect Replace	0.1		2.0	1.0			
0308	Pump/PTO Assy	Repair Inspect Replace	0.1			6.0			
030801	Hydraulic Pump	Repair Inspect Replace	0.1		1.5	4.0			
030802	Power Take-Off	Repair Replace Repair			0.75 1.0	2.0 2.0		1,5,6 1,5,6	

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
04	Truck, Rig Tender	Inspect Service	5.3 3.1	0.1					
		Replace		35.7	91.7	21.0			
		Repair		22.5	74.0	83.0			
0401	Front Sheet Metal Group	Inspect	0.1						
		Replace			2.0				
		Repair			1.0			1,5,6	
0402	Cab Group	Inspect	0.1						
		Replace				10.0			
		Repair				6.0		1,5,6	
040201	Door Assy	Inspect	0.1						
		Replace			1.0				
		Repair			1.0			1,5,6	
040202	Fan, Defroster	Inspect	0.1						
		Replace		0.5					
		Repair		0.5				1,5,6	
040203	Windshield Wiper/Washer	Inspect	0.2						
		Service	0.2						
		Replace		1.0					
		Repair		1.0				1,5,6	
040204	Heater Assy	Inspect	0.1						
		Replace			2.0				
		Repair			1.5			1,5,6	
040205	Seat Assy, Driver	Inspect	0.1						
		Replace		1.0					
		Repair			1.0			1,5,6	
0403	Brake Pedal Assy	Inspect	0.1						
		Replace			0.5				
		Repair			1.0				
0404	Clutch Pedal Assy	Inspect	0.1						
		Adjust		0.2					
		Replace		0.5					
		Repair		1.0					
0405	Accelerator Pedal Assy	Inspect	0.1						
		Replace		0.5					
		Repair		1.0					
0406	Shift Lever Assy	Inspect	0.1						
		Replace		0.5					
		Repair		1.0					
0407	Steering Group	Inspect	0.2						
		Service	0.5						
		Replace			4.0				
		Repair			2.0			1,5,6,33, 34,52	B
0408	Electrical Components, Cab	Inspect	0.2						
		Replace			2.5				
		Repair			1.5			1,5,6	
0409	Steering Gear	Inspect	0.2						
		Service	0.1						
		Replace			2.5				
		Repair					4.0	1,5,6,45, 46,47	C

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
0410	Exhaust System	Inspect Replace	0.1	1.5					
0411	Radiator	Repair Inspect Test	0.2	1.0				1,2	
		Service	0.3		0.5				
041101	Hoses	Replace Repair		3.0	3.0			1,5,6	
0412	Steering Pump	Inspect Service Replace	0.1 0.1	0.3					C
		Repair		1.5	3.0			1,5,6,49, 50,51	
0413	Alternator Assy	Inspect Test	0.1		0.5				
		Replace		1.0					
041301	Belts	Repair Inspect	0.1		2.0			1,5,6,7,8	F
		Adjust		0.2					
0414	Starting Motor Assy	Replace Inspect Test	0.1	0.4					
		Replace		1.5	0.5				
041401	Solenoid, Starter	Repair Inspect Test	0.1		3.0			1,5,6,7,8	
		Replace		0.5					
0415	Engine Assy, Diesel	Inspect Service	0.2 0.5	1.0					C
		Replace			10.0				
041501	Air Cleaner Assy	Repair Inspect Service	0.2 0.2	2.0	15.0	25.0			
		Replace		0.5					
041502	Turbocharger	Repair		1.0				1,5,6	
		Replace			1.5				
041103	Fuel Lines & Filter	Repair			3.0			1,5,6	
		Inspect	0.2						
		Replace		1.5					
041504	Injection Pump, Fuel	Repair Inspect	0.2	1.5				1,5,6	
		Test				2.0			
		Calibrate				2.0			
		Replace			2.0				
		Repair				4.0		1,5,6, & 26 thru 32	
041505	Governor	Inspect Replace Repair	0.1		2.5		4.0	1,5,6	

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
041506	Air Compressor	Inspect Replace Repair	0.1		3.0 2.5			1,5,6	
041507	Water Pump	Inspect Replace Repair	0.1		3.0 1.5			1,5,6	
041508	Oil Cooler & Filter	Inspect Replace Repair	0.1	1.0 2.0				1,5,6	
041509	Fuel Filter & Mounting	Inspect Replace Repair	0.1	1.0 1.0				1,5,6	
0411510	Manifolds, Intake & Exhaust	Inspect Replace Repair	0.1		2.0 1.0			1,5,6	
041511	Pan, Oil	Inspect Replace Repair	0.1		4.0 1.0			1,5,6	
041512	Oil Pump Assy	Replace Repair			4.0 1.0			1,5,6	
041513	Cover, Engine Front	Inspect Replace Repair	0.1		3.0 1.0			1,5,6	
041514	Cylinder Head Group	Inspect Replace Repair	0.1		2.0 4.0			1,5,6,13, 14,15,38	
041515	Camshaft Group	Replace Repair				2.0 1.5		1,5,6,16	
041516	Piston & Conn. Rod	Replace Repair				2.0 4.0		1,5,6 & 17, thru 23,38	
041517	Crankshaft Group	Replace Repair				5.0 3.5		1,5,6,24, 25,39	
041518	Crankcase Group	Replace Repair				2.0 5.0		1,5,6	
0416	Transmission	Inspect Service Replace Repair	0.2 0.2			6.0 16.0		1,5,6	C
0417	Driveshaft, Transfer Case	Inspect Service Replace Repair	0.1 0.2					1,5,6	B
0418	Driveshaft, Front Axle	Inspect Service Replace Repair	0.1 0.2	1.0 1.0				1,5,6	B

(1) Group Number	(2) Component/ Assembly	(3) Maintenance Function	(4) Maintenance Category					(5) Tools and Equipment	(6) Remarks
			C	O	F	H	D		
0419	Transfer Case	Inspect Service Replace Repair	0.1 0.1		5.0		10.0	1,5,6	C
0420	Clutch Assy	Replace Repair			4.2 1.0			1,5,6	
0421	Brake Chambers, Air	Inspect Replace Repair	0.1		1.0 2.5			1,5,6	G
0422	Hub & Drum, Front	Replace Repair		1.0 1.0				1,5,6	
042201	Hub, Wheel	Replace Repair		1.0 1.0					
042202	Drum, Brake	Replace Repair		1.0					
0423	Hub & Drum, Rear	Replace Repair		2.0 1.0				1,5,6	
042301	Hub, Wheel	Replace Repair		1.0 1.0					
042302	Drum Brake	Replace Repair		1.0					
0424	Brake Assy, Front	Replace Repair		2.0 1.0				1,5,6	
0425	Brake Assy, Rear	Replace Repair		2.0 1.0				1,5,6	
0426	Driveshaft, Rear Axle	Inspect Service Replace Repair	0.1 0.2		1.0 1.0			1,5,6	B
0427	Driveshaft, Interaxle	Inspect Service Replace Repair	0.1 0.2		1.0 1.0			1,5,6	B
0428	Rear Axle Group	Replace Repair			7.0 8.0			1,5,6	
042801	Front Rear Axle	Inspect Service Replace	0.1 0.1		7.0			1,5,6	C
042802	Rear Rear Axle	Repair Inspect Service Replace Repair			4.0			1,5,6	
0429	Front Axle Assy	Inspect Service Adjust Replace Repair	0.1 0.1		7.0 4.0			1,5,6	C
					1.5 5.0 2.5			1,5,6	B

**SECTION III. TOOL AND TEST EQUIPMENT REQUIREMENTS
FOR
DRILLING SYSTEM, WELL, ROTARY,
TRUCK MOUNTED, AIR TRANSPORTABLE,
600 FEET CAPACITY**

(1) Tool or Test Equipment Ref Code	(2) Maintenance Category	(3) Nomenclature	(4) National/ NATO Stock Number	(5) Tool Number
1	0	TOOL KIT, GENERAL MECHANICS: AUTOMOTIVE	5180-00-177-7033	
2	0	SHOP EQUIPMENT, AUTO MAINT, 2ND ECHELON, COMMON #1	4910-00-754-0654	
3	0	SHOP EQUIPMENT, AUTO MAINT, 2ND ECHELON, COMMON #1, LESS POWER	4910-00-754-0653	
4	0	SHOP EQUIPMENT, AUTO MAINT, 2ND ECHELON, COMMON #2, LESS POWER	4910-00-754-0650	
5	F	SHOP EQUIPMENT, AUTO MAINT AND REPAIR: FLD. MAINT., BASIC	4910-00-754-0705	
6	F	SHOP EQUIPMENT, AUTO MAINT AND REPAIR: FLD. MAINT., SUPPLEMENTAL	4910-00-754-0706	
7	F	SHOP EQUIPMENT, FUEL AND ELECTRIC MAINT. AND REPAIR, FIELD MAINTENANCE	4910-00-754-0714	
8	F	SHOP EQUIPMENT, FUEL AND ELECTRIC MAINT. AND REPAIR, FIELD MAINTENANCE, SUPPLEMENTAL, NO. 1	4910-01-028-9849	
9	0	PULLER ASSY, MUD PUMP LINER		(21363) F-942
10	0	PULLER ASSY, MUD PUMP VALVE SEAT		(21363) F-908
11	F	NOZZLE SLEEVE PULLER ADAPTER		SE-2587
12	F	NOZZLE SLEEVE INSTALLING TOOL		SE-2534
13	F	VALVE GUIDE REMOVER		SE-1722
14	F	VALVE GUIDE INSTALLER		SE-1943
15	F	VALVE SPRING TESTER		SE-2241
16	H	CAMSHAFT BEARING SERVICE SET		SE-2893
17	H	UNIVERSAL WET SLEEVE PULLER		SE-2536
18	H	PISTON RING COMPRESSOR		SE-1680
19	H	PISTON GROOVE WEAR GAUGE PINS		J-29511
20	H	PISTON RING CLEARANCE FIXTURE		SE-2206
21	H	COUNTER BORE DEPTH GAUGE		SE-2515
22	H	COUNTER BORING TOOL		SE-2514
23	H	OIL LEAK DETECTOR		SE-1632

(1) Tool or Test Equipment Ref Code	(2) Maintenance Category	(3) Nomenclature	(4) National/ NATO Stock Number	(5) Tool Number
24	H	LIFTING SLING		SE-2722
25	H	PULLER (FOR THREE-HOLE VIBRATION DAMPER)		SE-1368
26	H	EXCESS FUEL DEVICE SUPPORT BAR		SE-2755
27	H	PRESSURE TEST KIT		SE-2239
28	H	TORQUE CAM ANGLE GAUGE		SE-2755
29	H	TORQUE CAM FULCRUM SUPPORT BLOCK		SE-2755
30	H	NOZZLE TEST PUMP		SE-2002
31	H	NOZZLE TUBE ASSEMBLY		SE-2004-13
32	H	90 DEGREE ADAPTER		SE-2757
33	F	TORQUE INDICATOR WRENCH (100-600 lb.-ft.)		SE-2189
34	F	TORQUE INDICATOR WRENCH (0-150 lb.-ft.)		SE-2221
35	F	EQUALIZER BEAM BUSHING SERVICE SET H		SE-2725
36	F	TORQUE INDICATOR WRENCH (0-100 lb.-ft.)		SE-2005
37	F	VALVE CAGE TOOL		SE-2613
38	H	PISTON INSTALLER		SE-4006
39	H	DIAL INDICATOR SET		SE-1848
40	F	TORQUE INDICATOR WRENCH (in. lbs.)		SE-1919
41	F	RACK PISTON ARBOR TOOL		SE-2277
42	F	ADJUSTER PLUG SPANNER WRENCH		SE-2279
43	F	REMOVER AND INSTALLER, ADJUSTER PLUG BEARING		SE-2280
44	F	INSTALLER, OIL, SEAL, ADJUSTER PLUG		SE-2281
45	H	INSTALLER, PITMAN SHAFT NEEDLE BEARING		SE-2817
46	H	REMOVER, PITMAN SHAFT NEEDLE BEARING		SE-2818
47	H	INSTALLER, PITMAN SHAFT OIL SEAL		SE-2819
48	F	POWER STEERING SYSTEM ANALYZER		SE-2780

(1) Tool or Test Equipment Ref Code	(2) Maintenance Category	(3) Nomenclature	(4) National/ NATO Stock Number	(5) Tool Number
49	F	POWER STEERING PUMP RETAINER RING SPANNER WRENCH		SE-2838
50	F	POWER STEERING PUMP SHAFT OIL SEAL REMOVER		SE-2839
51	F	POWER STEERING PUMP SHAFT OIL SEAL INSTALLER		SE-2840
52	F	PULLER		SE-1821

SECTION IV. REMARKS

REFERENCE CODE	REMARKS
A	Lubricate all hinge points.
B	Lubricate grease fittings.
C	Fill with appropriate lubricant
D	Repair of frames will be in accordance with TB9-2300-247-40.
E	Service/Inspection of Winch/Hoist wire cables will be in accordance with TB9-43-0142 and TB9-0352.
F	Repair of Alternator/Generator will be in accordance with TM9-2920-225-34.
G	Inspection of brake lines will be in accordance with TB9-230-405-14.
H	Fill fuel reservoir with diesel fuel.
J	Repair of batteries will be in accordance with TM9-6140-200-14 and DA Pamphlet 750-34.
K	Repair by replacing components.
L	Repair is at Special Repair Activity (SRA). SRA is the manufacturer.

APPENDIX B. TORQUE REQUIREMENTS

Grade 5 Socket and Hexagon Head Capscrews

SIZE	TENSILE STRENGTH (Min. PSI)	PROOF LOAD (PSI)	CLAMP LOAD P(lb)	TORQUE DRY K=0.20
				lb-in
4-40	120,000	85,000	380	8
4-48	120,000	85,000	420	9
6-32	120,000	85,000	580	16
6-40	120,000	85,000	640	18
8-32	120,000	85,000	900	30
8-36	120,000	85,000	940	31
10-24	120,000	85,000	1,120	43
10-32	120,000	85,000	1,285	49
1/4 - 20	120,000	85,000	2,020	96
1/4 - 28	120,000	85,000	2,320	120
				lb-ft
5/16-18	120,000	85,000	3,340	17
5/16-24	120,000	85,000	3,700	19
3/8-16	120,000	85,000	4,940	30
3/8-24	120,000	85,000	5,600	35
7/16-14	120,000	85,000	6,800	50
7/16-20	120,000	85,000	7,550	55
1/2-13	120,000	85,000	9,050	75
1/2-20	120,000	85,000	10,700	90
9/16-12	120,000	85,000	11,600	110
9/16-18	120,000	85,000	12,950	120
5/8-11	120,000	85,000	14,400	150
5/8-18	120,000	85,000	16,950	180
3/4-10	120,000	85,000	21,300	260
3/4-16	120,000	85,000	23,800	300
7/8-9	115,000	78,000	27,000	400
7/8-14	115,000	78,000	29,800	440
1-8	115,000	78,000	35,500	580
1-12	115,000	78,000	38,800	640
1 1/18-7	105,000	74,000	42,300	800
1 1/8-12	105,000	74,000	47,300	880
1 1/4-7	105,000	74,000	53,300	1,120
1 1/4-12	105,000	74,000	59,600	1,240
1 3/8-6	105,000	74,000	64,100	1,460
1 3/8-12	105,000	74,000	73,000	1,680
1 1/2-6	105,000	74,000	78,000	1,940
1 1/2-12	105,000	74,000	87,700	2,200

APPENDIX C**EXPENDABLE/DURABLE SUPPLIES AND MATERIALS LIST****Section I. INTRODUCTION****C-1. SCOPE**

This appendix lists expendable supplies and materials you will need to operate and maintain the Well Drilling System. This listing is for informational purposes only and is not authority to requisition the listed items. These items are authorized to you by CTA 50-970, Expendable Durable Items (Except Medical, Class V, Repair Parts, and Heraldic Items), or CTA 8-100, Army Medical Department Expendable/ Durable Items.

C-2. EXPLANATION OF COLUMNS

a. Column (1) Item number. This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the material (e.g., "Use cleaning compound, item 5, App. D").

b. Column (2) Level. This column identifies the lowest level of maintenance that requires the listed item.

C - Operator / Crew

O - Unit Maintenance

F - Direct Support Maintenance

H - General Support Maintenance

c. Column (3) National Stock Number. This is the National stock number assigned to the item; use it to request or requisition the item.

d. Column (4) Description. Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the Federal Supply Code for Manufacturer (FSCM) in parentheses followed by the part number.

e. Column (5) Unit of Measure (U/M). Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

Change 1 C-1

Section II. EXPENDABLE / DURABLE SUPPLIES AND MATERIALS LIST

(1) Item Number	(2) Level	(3) National Stock Number	(4) Description	(5) U/M
1	O		COMPOUND, JOINT (29204) 949-002-15	LB
2	O		GAA (MIL-G-10924C)	LB
3	O		GO-85/140 (MIL-L-2105G) SAE 30	GAL.
4	O		GO-85/140 (MIL-L-2105C) SAE 50-60	GAL.
5	O		MOBIL RARUS SHC 924 (19135)	GAL.
6	O		MOBIL RARUS SHC 926 (19135)	GAL.
7	O		LUBRICATING OIL (MIL-L-2104D) OE/HDO 10, 20, 30, 40	GAL.
8	O		GO-80/90 (MIL-L-2105C) OE/HDO 10, 30	GAL.
9	O		GO-85/140 (MI L-L-2105C) OE/HDO 10, 30	GAL.
10	O		LUBRICATING OIL (MIL-L-2104D) OE/HDO 15/40	GAL.
11	O		LUBRICATING OIL (MIL-L-2104C) OE/HDO 10, 15/40	GAL.
12	O	9150-00-142-	ROCK DRILL OIL 9320	GAL.
13	O		GO-85/140 (MIL-L-2105C) SAE 140 EP	GAL.
14	O		GRAPHITE, COLLOIDAL (MI L-L-2431B)	GAL.
15	O		LUBRICATING OIL, OEA (MI L-L-46167A)	GAL.

By Order of the Secretary of the Army:

CARL E. VUONO
General, United States Army
Chief of Staff

Official:

WILLIAM J. MEEHAN, II
Brigadier General, United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25A, Unit and Intermediate Direct Support and Intermediate General Support Maintenance requirements for Drilling Machine, Well, Combination Rotary/Percussion, Semitrailer Mounted, Diesel, 1500 Ft. Model CF-15-S

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN...JOT DOWN THE
DOPE ABOUT IT ON THIS FORM.
CAREFULLY TEAR IT OUT, FOLD IT
AND DROP IT IN THE MAIL.

SOMETHING WRONG WITH PUBLICATION

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT PIN-POINT WHERE IT IS

PAGE
NO.

PARA-
GRAPH

FIGURE
NO.

TABLE
NO.

IN THIS SPACE, TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT.

PRINTED NAME, GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

The Metric System and Equivalents

Linear Measure

1 centimeter = 10 millimeters = .39 inch
 1 decimeter = 10 centimeters = 3.94 inches
 1 meter = 10 decimeters = 39.37 inches
 1 dekameter = 10 meters = 32.8 feet
 1 hectometer = 10 dekameters = 328.08 feet
 1 kilometer = 10 hectometers = 3,280.8 feet

Weights

1 centigram = 10 milligrams = .15 grain
 1 decigram = 10 centigrams = 1.54 grains
 1 gram = 10 decigrams = .035 ounce
 1 decagram = 10 grams = .35 ounce
 1 hectogram = 10 decagrams = 3.52 ounces
 1 kilogram = 10 hectograms = 2.2 pounds
 1 quintal = 100 kilograms = 220.46 pounds
 1 metric ton = 10 quintals = 1.1 short tons

Liquid Measure

1 centiliter = 10 milliliters = .34 fl. ounce
 1 deciliter = 10 centiliters = 3.38 fl. ounces
 1 liter = 10 deciliters = 33.81 fl. ounces
 1 dekaliter = 10 liters = 2.64 gallons
 1 hectoliter = 10 dekaliters = 26.42 gallons
 1 kiloliter = 10 hectoliters = 264.18 gallons

Square Measure

1 sq. centimeter = 100 sq. millimeters = .155 sq. inch
 1 sq. decimeter = 100 sq. centimeters = 15.5 sq. inches
 1 sq. meter (centare) = 100 sq. decimeters = 10.76 sq. feet
 1 sq. dekameter (are) = 100 sq. meters = 1,076.4 sq. feet
 1 sq. hectometer (hectare) = 100 sq. dekameters = 2.47 acres
 1 sq. kilometer = 100 sq. hectometers = .386 sq. mile

Cubic Measure

1 cu. centimeter = 1000 cu. millimeters = .06 cu. inch
 1 cu. decimeter = 1000 cu. centimeters = 61.02 cu. inches
 1 cu. meter = 1000 cu. decimeters = 35.31 cu. feet

Approximate Conversion Factors

<i>To change</i>	<i>To</i>	<i>Multiply by</i>	<i>To change</i>	<i>To</i>	<i>Multiply by</i>
inches	centimeters	2.540	ounce-inches	Newton-meters	.007062
feet	meters	.305	centimeters	inches	.394
yards	meters	.914	meters	feet	3.280
miles	kilometers	1.609	meters	yards	1.094
square inches	square centimeters	6.451	kilometers	miles	.621
square feet	square meters	.093	square centimeters	square inches	.155
square yards	square meters	.836	square meters	square feet	10.764
square miles	square kilometers	2.590	square meters	square yards	1.196
acres	square hectometers	.405	square kilometers	square miles	.386
cubic feet	cubic meters	.028	square hectometers	acres	2.471
cubic yards	cubic meters	.765	cubic meters	cubic feet	35.315
fluid ounces	milliliters	29.573	cubic meters	cubic yards	1.308
pints	liters	.473	milliliters	fluid ounces	.034
quarts	liters	.946	liters	pints	2.113
gallons	liters	3.785	liters	quarts	1.057
ounces	grams	28.349	liters	gallons	.264
pounds	kilograms	.454	grams	ounces	.035
short tons	metric tons	.907	kilograms	pounds	2.205
pound-feet	Newton-meters	1.356	metric tons	short tons	1.102
pound-inches	Newton-meters	.11296			

Temperature (Exact)

°F	Fahrenheit temperature	5/9 (after subtracting 32)	Celsius temperature	°C
----	---------------------------	-------------------------------	------------------------	----

