

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

OPERATOR'S MANUAL
TRUCK, LIFT, FORK, ELECTRIC
SOLID RUBBER TIRES
4000 POUND CAPACITY
ARMY MODEL MHE-196
BAKER MODEL FTD-040-EE
FSN 3930-709-6342, 100 IN. LIFT
FSN 3930-709-6341, 130 IN. LIFT
FSN 3930-709-6358, 144 IN. LIFT

This copy is a reprint which includes current pages
from Change 3.

HEADQUARTERS, DEPARTMENT OF THE ARMY

FEBRUARY 1965

SAFETY PRECAUTIONS

Before Operation

When servicing battery, do not smoke or use flame in the vicinity. Batteries generate hydrogen, a highly explosive gas.

Avoid contact with the battery electrolyte. If the solution comes in contact with the skin, rinse the area. Immediately with clean water to avoid skin burns.

Check equipment logbook for record of proper servicing and maintenance.

Check the operating area to be sure it is clear of personnel and obstructions.

During Operation

Be alert for other workers to be sure they are not in the way of the load or the moving truck.

Be sure there is sufficient clearance overhead and on each side of the truck.

Always travel with the mast tilted back and with forks raised just high enough to clear any uneven floor conditions.

Avoid sudden starting and stopping of the truck. Reduce speed when making a turn.

Face in the direction of travel.

Know the rated capacity of the truck and do not overload it. Never pick up a load until certain it can be carried safely.

Make sure the load is steady before lifting it and keep the load against the carriage backrest.

When transporting bulky loads, travel in reverse. Always descend ramps in reverse when carrying a load.

When unloading a heavy elevated load, position the load directly over the unloading spot, as low as possible, before tilting the mast forward.

Be very careful when high-tiering.

Do not butt loads with the forks or with the rear of the truck.

Report any evidence of faulty truck performance.

After Operation

Make sure forks are lowered to the ground and handbrake is engaged firmly.

If truck is parked on an incline, block at least two wheels in the event of handbrake failure.

Appendix II of this change is effective 1 July 1973
Changes in force: C 3

Change }
No. 3 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D.C., 9 May 1972

Operator's Manual
TRUCK, LIFT, FORK; SOLID RUBBER TIRES; 4,000 LB.
CAPACITY; ARMY MODEL MHE-196, BAKER MODEL FTD-040-EE
FSN 3930-709-6342, 100-IN. LIFT; FSN 3930-709-6341,
130-IN. LIFT; FSN 3930-709-6358, 144-IN. LIFT

TM 10-3930-257-10, 16 February 1965, is changed as follows:

Page 3. Paragraph 4 is superseded.

4. Reporting of Errors

You can improve this manual by calling attention to errors and by recommending improvements, using DA

Form 2028 (Recommended Changes to Publications) or by a letter, and mail direct to Commanding General, US Army Mobility Equipment Command, ATTN: AMSME-MPP, 4300 Goodfellow Boulevard, St. Louis, MO. 63120. A reply will be furnished direct to you.

Page 19. Appendix II is superseded.

APPENDIX II
ITEMS TROOP INSTALLED OR AUTHORIZED
(Effective 1 July 1973)
Section I. INTRODUCTION

1. Scope

This appendix lists items which are required by the operator for operation of the truck.

is a list of items in alphabetical sequence which at the discretion of the unit commander may accompany the truck. These items are NOT SUBJECT TO TURN-IN with the truck when evacuated.

2. General

The Items Troop Installed or Authorized List, Section II,

*This change supersedes C 1, 25 March 1968 and C 2, 25 August 1969.

Section II. ITEMS TROOP INSTALLED OR AUTHORIZED LIST
(Effective 1 July 1973)

Federal Stock Number	Description	Unit of Meas	Qty Auth
7510-889-3494	BINDER, looseleaf	EA	1
7520-559-9618	CASE, Maintenance and Operation Manuals	EA	1
4210-889-2222	EXTINGUISHER, Fire	EA	1

By Order of the Secretary of the Army:

Official:

VERNE L. BOWERS,
Major General, United States Army,
The Adjutant General

W. C. WESTMORELAND,
General, United States Army,
Chief of Staff

Distribution:

To be distributed in accordance with DA Form 12-25A (qty rqr block No. 893) Operator maintenance requirements for Warehouse Equipment.

TECHNICAL MANUAL }
 No. 10-3930-257-10 }

HEADQUARTERS
 DEPARTMENT OF THE ARMY
 WASHINGTON, D. C., 16 February 1965

**Operator's Manual
 TRUCK LIFT, FORK, ELECTRIC
 SOLID RUBBER TIRES
 4000-POUND CAPACITY
 ARMY MODEL MHE-196
 BAKER MODEL FTD-040-EE
 FSN 3930-709-6342 (100-IN. LIFT)
 FSN 3930-709-6341 (130-IN. LIFT)
 FSN 3930-709-6358 (144-IN. LIFT)**

		Paragraph	Page
CHAPTER	1. INTRODUCTION		
Section	I. General		
	Scope -----	1	3
	Appendixes -----	2	3
	Forms, records, and reports -----	3	3
	Recommended changes -----	4	3
	Orientation -----	5	3
	II. Description and Data		
	Description -----	6	3
	Tabulated data -----	7	4
	Difference in models -----	8	6
CHAPTER	2. OPERATING INSTRUCTIONS		
Section	I. Service Upon Receipt of Truck		
	General -----	9	7
	Responsibilities -----	10	7
	II. Controls and Instruments		
	General -----	11	7
	Controls -----	12	7
	Instruments -----	13	9
	III. Operation Under Usual Conditions		
	General -----	14	9
	Driving the truck -----	15	9
	Picking up the load -----	16	9
	Depositing the load -----	17	10
	Stopping the truck -----	18	10
	IV. Operation of Equipment Used in Conjunction With the Truck		
	General -----	19	11
	Operating the extinguisher -----	20	11
CHAPTER	3. MAINTENANCE INSTRUCTIONS		
Section	I. Special Tools and Equipment		
	Special tools -----	21	12
	Equipment -----	22	12

		Paragraph	Page
	II. Lubrication		
	General-----	23	12
	Operator responsibilities -----	24	12
	III. Preventive Maintenance Services Under Usual Conditions		
	General-----	25	12
	Daily preventive maintenance services-----	26	12
	IV. Preventive Maintenance Services Under Unusual Conditions		
	General-----	27	15
	Operation in extreme heat-----	28	15
	Operation in extreme cold-----	29	15
	Operation in sandy terrain -----	30	15
	Operation in tropical areas -----	31	15
	V. Troubleshooting		
	Definition-----	32	15
	Operator responsibilities -----	33	15
CHAPTER	4. DEMOLITION OF TRUCK		
	General-----	34	16
	Demolition to render the forklift truck inoperative -----	35	16
	Demolition by explosives or weapons fire -----	36	16
	Other demolition methods -----	37	16
	Training-----	38	16
APPENDIX	I. REFERENCES -----		17
	II. BASIC ISSUE ITEMS LIST AND MAINTENANCE AND OPERATING SUPPLIES -----		19

CHAPTER 1 INTRODUCTION

Section I. GENERAL

1. Scope

a. This manual is for the use of personnel responsible for the operation and operator maintenance of the truck, lift, fork, electric, solid rubber tires, 4,000-pound capacity, Baker model FTD-040-EE, Army model MHE-196, Federal stock number 3930-709-6342 for 100-inch lift, Federal stock number 3930-709-6341 for 130-inch lift, and Federal stock number 3930-709-6358 for 144-inch lift, procured under Contract Numbers DSA-4-019092-MP302 and DSA-4-020841-MP302.

b. It provides the operator with the necessary instructions to operate the truck and to perform his required maintenance services. These maintenance services have been assigned to the operator within the limits of the daily preventive maintenance services (para. 26).

2. Appendixes

Appendix I contains a list of publications applicable to this manual. Appendix II contains the list of basic issue items and maintenance and operating supplies authorized the operator of this equipment. The maintenance allocation chart is listed in TM 10-3930-257-20.

3. Forms, Records, and Reports

The forms, records, and reports applicable to the operation and operator maintenance of this truck are listed and described in TM-38-750.

4. Recommended Changes

The direct reporting of errors, omissions, and recommendations for improving this manual by the individual user is authorized and encouraged. DA Form 2028 (Recommended Changes to DA Publication) will be used for reporting these improvements. This form will be completed in triplicate using pencil, pen or typewriter. The original and one copy will be forwarded direct to Commanding General, U. S. Army Mobility Equipment Center, ATTN: SMOME-MMP, P.O. Drawer 58, St. Louis, Mo. 63166.

5. Orientation

Throughout this manual, the use of the terms *right*, *left*, *front*, and *rear*, indicates directions from the viewpoint of the operator sitting in the seat of the truck.


Section II. DESCRIPTION AND DATA

6. Description

Army model MHE-196 (Baker model FTD-040-EE, type EE, spark inclosed) is a nontactical forklift truck designed for warehouse operation. This truck (figs. 1 and 2) can be used to load, transport, unload and stack loads weighing as much as 4,000 pounds at a load center of 24 inches. (The load center is measured from

the heel of the forks.) The model FTD-040-EE truck (Federal stock No. 3930-709-6342) is designed to lift loads to a height of 100 inches. The model FTD-040-EE truck (Federal stock No. 3930-709-6341) is designed to lift loads to a height of 1K inches. The model FTD-040-EE truck (Federal stock No. 3930-709-6358) is designed to lift loads to a height of 144 inches.

AGO 7554A



- | | | |
|-------------|------------------|------------------|
| 1 Mast | 3 Wheel, drive | 5 Forks, load |
| 2 Headlight | 4 Cylinder, lift | 6 Backrest, load |

Figure 1. Truck, three-quarter front view.

7.

a. Capacities.

Differential-----11 pt
 Hydraulic system -----7 ½ gal
 Power steering pump-----1 qt.

b. Dimensions and Weight.

(1) FSN-3930-709-6342.

Ground clearance (at mast center)-----3 in.
 Height (overall):
 With uprights extended
 (less back rest)-----123 in.
 With uprights retracted -----68 in.

Length:

Overall-----119 ½ in.
 Forks-----40 in.

Weight w/battery-----7700 lb.
 Weight w/o battery-----5300 lb.

Width-----42 in.

Wheel load (empty):


Drive-----1550 lb
 Steer-----2300 lb

(2) FSN-3930-709-6341.

Ground clearance (at mast center)-----3 in.

Height (overall):

With uprights extended
 (less back rest)-----150 in.
 With uprights retracted -----89 in.



- 1 Guard, overhead 2 Headlight 3 Counter weight 4 Stoplight-taillight

Figure 2. Truck, three-quarter rear view.

Length:

Overall-----119 ½ in.
 Forks -----40 in.
 Weight w/battery-----7700 lb
 Weight w/o battery -----5300 lb
 Width -----42 in.

Wheel load (empty):

Drive -----1550 lb
 Steer -----2300 lb

(3) FSN-709-6358.i

Ground clearance (at mast center)----- 3 in.

Height (overall):

With uprights extended
 (less back rest)----- 177 in.
 With uprights retracted ----- 91 in.

Length:

Overall ----- 119 ½ in.
 Forks ----- 40 in.

AGO 7554A

Weight w/battery-----7700 lb
 Weight w/o battery -----5300 lb
 Width -----42 in.
 Wheel load (empty):
 Drive -----1550 lb
 Steer -----2300 lb
c. Performance.
 Aisle width (minimum)
 (carrying 48 in. cube):
 Intersecting -----74 in.
 Right angle stacking -----142 in.
 Gradeability (maximum load) -----15%
 Hoist speed (empty) -----48 ft/min
 Hoist speed (maximum load)-----29 ft/min

Lift height (maximum):
 FSN 3930-709-6342-----100 in.
 FSN 3930-709-6341-----130 in.
 FSN 3930-709-6358-----144 in.
 Load capacity at 24-inch load center -----4,000 lb
 Maximum speed (empty):
 Forward-----5.2 mph
 Reverse -----5.2 mph
 Maximum speed (loaded):
 Forward-----5.0 mph
 Reverse -----5.0 mph
 Number of speed steps:
 Forward-----5
 Reverse -----5

Tilt limitation:
 Backward----- 10°
 Forward----- 3°
 Turning radius (no load):
 Inside----- 5 ½ in.
 Outside ----- 78 ½ in.
d. Tires.
 Type----- Solid rubber
 Number:
 Drive----- 2
 Steer----- 2
 Size:
 Drive----- 18x7x12 1/2
 Steer----- 14x4 1/2x8

8. Difference in Models

This manual covers the Baker model FTD-040-EE forklift truck of which there are three different lift heights. FSN 3930-709-6342 truck is equipped with a mast column assembly allowing an operator to lift a load to 100 inches only. FSN 3930-709-6341 truck is equipped with a mast column assembly allowing an operator to lift a load to 130 inches only. FSN 3930-709-6358 truck is equipped with a mast column assembly allowing an operator to lift a load to 144 inches only.

CHAPTER 2 OPERATING INSTRUCTIONS

Section I. SERVICE UPON RECEIPT OF TRUCK

9. General

When a new or used truck is received by an organization, it must be serviced to prepare it for operation.

10. Responsibilities

The services performed upon receipt of the truck

are the responsibility of the using organization and will be performed by organizational maintenance personnel. When battery requirements are determined, refer to TM 10-3930-257-35 for installation of battery positioning parts. The operator will assist in these services when directed to do so by the commanding officer.

Section II. CONTROLS AND INSTRUMENTS

11. General

This section furnishes the operator with illustrations and sufficient information concerning the location and the use of the various controls and instruments to properly operate the truck.

12. Controls

a. Operator's Seat. As the operator places his weight on the operator's seat (1, fig. 3), a switch is closed activating the travel motor and power steering pump motor circuits. Simultaneously, the travel motor brake is released. As the driver removes his weight from the seat, the motor brake is engaged and the circuits of the travel motor and power steering pump motor are opened.

b. Horn Button. The horn button (4) is located in the center of the steering handwheel. Depress the button to sound horn.

c. Parking Brake Lever. The parking brake lever (5) is located to the left of the operator's seat in front of the cowl. Pull up on the lever to apply the brake and hold the truck in a stationary position. Move the lever downward to release brake.

d. Steering Handwheel. The steering handwheel (3) controls the direction of travel of the truck.

Turn the handwheel to the right (clockwise) to move the truck to the right; turn the handwheel to the left (counterclockwise) to move the truck to the left.


e. Accelerator Pedal. The accelerator pedal (10) is located on the floor plate, convenient to the operator's right foot. Depression of the accelerator pedal either rapidly or slowly will cause the truck to move in the direction selected at the speed and acceleration desired by the operator. Release the pressure on the pedal to slow the speed of the truck.

f. Light Switch. The light switch (6) is located on the lower right side of the instrument case. Push the light switch up to turn on the headlight and taillight. Push the light switch down to turn off the headlight and taillight.

g. Lift Control Lever. The lift control lever (12) is located on the cowl to the right of the operator's seat. Move the lever to the rear to lift the forks. Move the lever forward to lower the forks.

h. Tilt Control Lever. The tilt control lever (11) is located directly to the right of the lift control lever. Move the tilt control lever forward to tilt the forks forward. Move the lever backward to tilt the forks backward.

i. Direction Control Lever. The direction



- | | | | | | |
|---|---------------------------|---|---------------------|----|--------------------|
| 1 | Operator's seat | 5 | Parking brake lever | 9 | Brake pedal |
| 2 | Directional control lever | 6 | Light switch | 10 | Accelerator pedal |
| 3 | Steering handwheel | 7 | Hourmeter | 11 | Tilt control lever |
| 4 | Horn button | 8 | Seat adjuster | 12 | Lift control lever |

Figure 3. Controls and instruments.

control lever (2) is located on the right side of the steering column. This lever provides three position control of the truck-forward, off, and reverse. Move the lever forward for forward travel, move the lever to the center position for off, and move the lever backward for reverse travel. Leave the lever in the OFF position when the truck is parked. The directional control lever may be used for either forward or reverse torque braking. Move the direction control lever in the opposite position you are traveling. The truck will come to almost a complete stop before going in the opposite direction. Depress the accelerator pedal if more severe torque braking is required.

j. *Brake Pedal.* The brake pedal (9) is located on the floor immediately to the right of the steering column. Depress the brake pedal to stop the truck and

simultaneously illuminate the stoplight.

k. *Seat Adjuster.* The seat adjuster (8) is located on the lower left side of the operator's seat. Move the adjuster lever toward the seat and move the seat forward or backward as desired. Release the adjuster lever when seat is in position.

13. Instruments

The hourmeter (7) is the only instrument used on this truck. It is located on the upper-most part of the instrument case. This meter operates only when the truck is in motion. The figure (extreme right center) records 10ths of an hour. The small indicator (upper right) visibly turns when the meter is recording.

Section III. OPERATION UNDER USUAL CONDITIONS

14. General

A person selected to operate this forklift truck must be an experienced operator of materials handling equipment or heavy-duty equipment. In addition, each operator must undergo a thorough training program to acquaint him with the specific operating characteristics of this truck.

15. Driving the Truck

a. Perform the daily preventive maintenance services required by paragraph 26 and figure 5.

b. Before boarding truck, put the direction control lever (para. 12*i*) in the center (OFF) position.

c. Mount truck and take position in operator's seat (para. 12*a*).

d. Depress brake pedal (para. 12*j*) with right foot, and simultaneously release parking brake lever (para. 12*c*) with left hand.

e. Move the lift control level (para. 12*g*) gradually to the rear to raise the forks to normal traveling position (8 to 10 inches above working surface).

f. Move the tilt control level (para. 12*h*) backward and tilt the forks backward.

g. Move the direction control lever (para. 12*i*) from the center (OFF) position to forward or reverse position, depending on desired direction.

h. Place foot on the accelerator pedal and gradually depress the accelerator pedal until truck begins to travel. Continue to depress the accelerator pedal until safe operating speed is attained. If the truck fails to move, report this to the proper authority.

16. Picking Up the Load

a. Approach the load squarely and halt the truck. Move the tilt control lever (para. 12*h*) forward and bring the mast assembly to the vertical position. Raise or lower the forks to the proper height to pick up the load.

b. Move the truck forward until the forks are positioned under the load. Make certain the forks are fully inserted in the pallet or under the load.

c. Apply the parking brake to prevent the truck from shifting position during the lifting operation.

d. Move the direction control lever (para. 12*i*) to the center (OFF) position.

e. Move the lift control level (para. 12*g*) to the rear and raise the load approximately 12 inches above

ground level. Release the lift control lever. Move the tilt control lever backward to tilt the forks backward. Release the tilt control lever.

f. Move the direction control lever (para. 12*i*) from the center (OFF) position for the desired direction of travel.

g. Release the parking brake lever, depress the accelerator pedal, and move the load to the desired location.

17. Depositing the Load

a. Depositing the Load on a Tiered Stack.

- (1) Move the lift control lever to the rear until the load reaches the desired height above the tier.
- (2) Drive the truck forward until the load is above its resting place.
- (3) Pull up on the parking brake lever to apply the parking brake.
- (4) Move the direction control lever to the center (OFF) position. Move the tilt control lever forward and tilt the forks forward until the load is aligned with the tier.
- (5) Move the lift control lever forward and carefully lower the load into position on the tier. Continue to lower the forks until they can be easily withdrawn from the pallet.
- (6) Move the direction control lever to the reverse position. Release the parking brake lever, and slowly back the truck away from the tiered stack until the forks are clear.
- (7) Move the lift control lever forward to lower the forks into normal traveling position (8 to 10 inches above surface).

b. Depositing the Load in a Storage Area.

- (1) Carefully drive up to the position at which the load is to be deposited. Depress the brake pedal to halt the truck.
- (2) Apply the parking brake, and move the direction control lever to the center (OFF) position.
- (3) Move the tilt control lever forward and bring the mast assembly to the vertical position.
- (4) Move the lift control lever forward and carefully lower the load to the ground. Continue to lower the forks until they can be easily withdrawn from under the load.
- (5) Place the direction control lever in the reverse position. Release the parking brake lever, and slowly back the truck away from the deposited load.

18. Stopping the Truck

- a. Remove foot from the accelerator pedal.
- b. Apply gradual pressure on the brake pedal to bring the truck to a safe smooth stop. Avoid sudden stops.
- c. Apply the parking brake. Move the direction control lever to the center (OFF) position.
- d. Move the tilt control lever forward to bring the mast to the vertical position.
- e. Move the lift control lever forward and lower the forks to the ground.
- f. As the operator removes his weight from the seat, the travel motor brake is applied and the seat switch is opened thereby cutting off current to the power steering pump motor and travel motor.
- g. Every 8 hours or after a day's work with the truck, the operator must have the battery charged overnight for efficient operation of the forklift truck the following day.

Section IV. OPERATION OF EQUIPMENT USED IN CONJUNCTION WITH THE TRUCK

19. General

This section contains instructions for operating the portable fire extinguisher (fig. 4) that is supplied with the truck.


20. Operating the Extinguisher

a. Disconnect the clamp that secures the extinguisher to its mounting bracket, swing the clamp open, and remove the extinguisher.

b. Hold the extinguisher upright and raise the large locking handle (2) to break the seal.

c. Aim the nozzle at the base of the fire and depress the small operating lever with the thumb.

d. Direct the discharge at the base of the fire with a side-to-side sweeping motion.



1 Gage 2 Handle 3 Cylinder

Figure 4. Portable fire extinguishers.

**CHAPTER 3
MAINTENANCE INSTRUCTIONS**

Section I. SPECIAL TOOLS AND EQUIPMENT

21. Special Tools

There are no special tools necessary for the operation or operator maintenance of this truck.

22. Equipment

The items of equipment supplied with this truck are listed in the basic issue item list (app. II).

Section II. LUBRICATION

23. General

The lubrication of this truck is the responsibility of the using organization and will be performed by organizational personnel.

24. Operator Responsibilities

The operator will be alert to detect signs of vehicle malfunctioning from lack of lubrication. He will report these conditions immediately to the proper authority.

**Section III. PREVENTIVE MAINTENANCE SERVICES
UNDER USUAL CONDITIONS**

25. General

To insure that the truck is ready for operation at all times, it must be inspected systematically, so that defects may be discovered and corrected before they result in serious damage or failure. The necessary preventive maintenance services to be performed are listed and described in paragraph 27. The item numbers indicate the sequence of minimum inspection requirements. Defects discovered during operation of the truck will be noted for future correction, to be made as soon as operation has ceased. Stop operation immediately if a deficiency is noted during operation

which would damage the equipment if operation were continued. All deficiencies and shortcomings will be recorded with the corrective action taken on DA Form 2404 at the earliest possible opportunity.

26. Daily Preventive Maintenance Services

This paragraph contains an illustrated tabulated listing of preventive maintenance services which must be performed by the operator. Refer to figure 5 for the daily preventive maintenance services.


PREVENTIVE MAINTENANCE SERVICES

DAILY

TM10-3930-257-10

BAKER MODEL FTD-040-EE
ARMY MODEL MHE 196

FORK LIFT TRUCK



ITEM	LUBRICATE IN ACCORDANCE WITH CURRENT LUBRICATION ORDER	PAR REF
1	TIRES. Check for cuts. Remove embedded foreign material. (Weekly)	
2	BRAKE MASTER CYLINDER. Check for leaks.	
3	HYDRAULIC OIL TANK. Check oil level, fill as required. Reference L.O. (Weekly)	
4	POWER STEERING RESERVOIR. Check lines and reservoir for leaks.	
5	BATTERY. Check for cracks and leaks. Add fluid as needed.	
6	BRAKE PEDAL. Check for strong pressure when brake pedal is applied.	
7	HORN. Check operation.	
8	CONTROLS AND INSTRUMENT. Check controls for proper operation. Controls should operate freely without binding. Hourmeter indicates total hours of operation.	
9	FIRE EXTINGUISHER. Inspect for broken seal and correct charge.	

MEC 3930-257-10/5 (1)

Figure 5. Daily preventive maintenance services.

ITEM		PAR REF
10	TILT CYLINDERS. Check for leaks	
11	HANDBRAKE. Check operation.	
12	DRIVE AXLE. Check for leaks. (Weekly)	
13	LIFT CHAIN. Check for cracked, broken or excessively worn links. (Weekly)	
14	LIFT CYLINDER. Check for leaks.	
15	LIGHTS. Check for defective lamp or lamp unit.	

MEC 3930-257-10/5 (2)

Figure 5-Continued.

Section IV. PREVENTIVE MAINTENANCE SERVICES UNDER UNUSUAL CONDITIONS

27. General

When the truck is operated under unusual conditions, extra care must be taken to maintain the truck in good operating condition. Certain additional services must be performed, and some of the regular preventive maintenance services must be performed more often.

28. Operation in Extreme Heat

Check the battery electrolyte level more often, maintaining the level 3/8 inch above the plates. Have the specific gravity of the electrolyte checked more often.

29. Operation in Extreme Cold

a. Shelter. Store the truck in a heated building or in a shelter, if possible. If a shelter is not available, park the truck with the front end facing into the wind and

cover the truck with tarpaulin.

b. Electrical System. Have the specific gravity of the battery electrolyte checked more often.

30. Operation in Sandy Terrain

a. Be sure to remove sand from axles, wheels, steering spindles, and brake assemblies.

b. Protect the lift and tilt mechanisms from sand. During sandstorms, cover exposed parts of the lift and tilt cylinder piston rods.

31. Operation in Tropical Areas

In tropical areas, corrosive action will take place almost immediately where paint is chipped or scratched from the truck. Inspect the truck often for signs of defective paint, and report this condition to the proper authority.

Section V. TROUBLESHOOTING

32. Definition

Troubleshooting is the process of locating and correcting malfunctions that may occur under normal operating conditions, and it is the responsibility of the using organization.

33. Operator Responsibilities

The operator will report to the proper authority any deficiencies noted before, during, or after operation. Report any strange noises or abnormal operation immediately and as accurately as possible.

CHAPTER 4 DEMOLITION OF TRUCK

34. General

When capture or abandonment of the forklift truck to an enemy is imminent, the responsible unit commander must make the decision either to destroy the equipment or to render it inoperative. Based on this decision, orders are issued which cover the desired extent of destruction. Whatever method of demolition is employed, it is essential to destroy the same vital parts of all forklift trucks and all corresponding repair parts.

35. Demolition to Render the Forklift Truck Inoperative

a. *Demolition by Mechanical Means.* Use sledge hammers, crowbars, axes, picks, or any other heavy tools which may be available to destroy the following:

- (1) Contactors.
- (2) Battery.
- (3) Hydraulic motor, traveling motor, and steering motor.

Note. The above steps are minimum requirements for this method.

- (4) Steering column.
- (5) Pumps.

b. *Demolition by Misuse.* Pour sand in the oil reservoir and operate the forklift truck until failure occurs.

36. Demolition by Explosives or Weapons Fire

a. *Explosives.* Place as many of the following charges as the situation permits and detonate them simultaneously with detonating cord and a suitable detonator.

- (1) One ½ -lb charge on lift cylinder.
- (2) One ½ -lb charge inside of each drive wheel.
- (3) One ½ -lb charge inside of each steering wheel.

Note. The above are minimum requirements for this method.

- (4) One ½ -lb charge inside of control panel.
- (5) One ½ -lb charge on hydraulic oil pump and motor.
- (6) One ½ -lb charge on the differential.
- (7) Two ½ -lb charges on traveling motor.
- (8) One ½ -lb charge on power steering pump and motor.
- (9) Two ½ -lb charges inside of battery compartment.

b. *Weapons Fire.* Fire on the forklift truck with the heaviest practical weapons available.

37. Other Demolition Methods

a. *Burning.* Pack rags, clothing, or canvas, under, around, and inside the forklift truck. Saturate this packing with gasoline, oil, or diesel fuel and ignite.

b. *Submersion.* Totally submerge the forklift truck in a body of water to provide water damage and concealment. Salt water will damage metal parts more than fresh water.

38. Training

All operators should receive thorough training in the destruction of the forklift truck. Refer to FM 5-25. Simulated destruction, using all of the methods listed above, should be included in the operator training program. It must be emphasized in training, that demolition operations are usually necessitated by critical situations when time available for carrying out destruction is limited. For this reason, it is necessary that operators be thoroughly familiar with all methods of destruction of equipment, and be able to carry out demolition instructions without reference to this or any other manual.

AGO 7554A

GPO 806-099

APPENDIX I REFERENCES

1. Dictionaries of Terms and Abbreviations

AR 320-5 Dictionary of United States Army Terms
AR 320-50 Authorized Abbreviations and Brevity Codes

2. Fire Protection

SB 5-111 Supply of DA Approved Fire Extinguishers to Army Troop Users
TM 5-687 Repair and Utilities; Fire Protection Equipment and Appliances; Inspections, Operations, and Preventive Maintenance

3. Lubrication

LO 10-3930-257-20 Truck, Lift, Fork, Electric, Solid Rubber Tires, 4000-Pound Capacity, Army Model MHE-196, Baker Model FTD-040-EE, FSN 3930-709-6342 (100-in. lift), FSN 3930-709-6341 (130-in. lift), FSN 3930-709-6358 (144-in. lift)

4. Painting

TM 9-213 Painting Instructions for Field Use

5. Preventive Maintenance

AR 750-5 Organization, Policies, and Responsibilities for Maintenance Operation
TB ENG 347 Winterization Techniques for Engineer Equipment
TM 5-764 Electric Motor and Generator Repair
TM 9-207 Operation and Maintenance of Army Materiel in Extreme Cold Weather (0° to -65° F.)
TM 9-6140-200-15 Operation and Organizational, Field and Depot Maintenance; Storage Batteries, Lead-Acid Type
TM 38-750 Army Equipment Record Procedures

6. Publication Indexes

DA Pam 108-1 Index of Army Motion Pictures, Film Strips, Slides, Tapes, and Phono-Recordings
DA Pam 310-1 Index of Administrative Publications
DA Pam 310-2 Index of Blank Forms
DA Pam 310-3 Index of Training Publication
DA Pam 310-4 Index of Technical Manuals, Technical Bulletins, Supply Manuals (Types 4, 6, 7, 8, and 9) Supply Bulletins, Lubrication Orders, and Modification Work Orders
DA Pam 310-5 Index of Graphic Training Aids and Devices
DA Pam 310-25 Index of Supply Manuals-Corps of Engineers

7. Radio Interference Suppression

TM 11-483 Radio Interference Suppression

AGO 7554A

8. Shipment and Limited Storage

AR 743-505
TM 9-200
TM 38-230

Limited Storage of Corps of Engineers Mechanical Equipment
General Packaging Instructions for Ordnance General Supply
Preservation, Packaging, and Packing of Military Supplies and Equipment

9. Supply Publications

FSC C9100-1L
TM 10-3930-257-20P

Fuels, Lubricants, Oils, and Waxes
Organizational Maintenance Repair Parts and Special Tool Lists: Truck, Lift,
Fork, Electric, Solid Rubber Tires, 4000-Pound Capacity, Army Model MHE-
196, Baker Model FTD-040-EE

10. Training Aids

AR 600-55
FM 5-25
FM 21-5
FM 21-6
FM 21-30
TM 21-300

Motor Vehicle Driver Selection, Testing, and Licensing
Explosives and Demolitions
Military Training Management
Techniques of Military Instruction
Military Symbols
Driver Selection and Training (Wheeled Vehicles)

**APPENDIX II
BASIC ISSUE ITEMS LIST AND MAINTENANCE
AND OPERATING SUPPLIES**

Section I. INTRODUCTION

1. General

Section II lists the accessories, tools, and publications required in operator maintenance and operation initially issued with, or authorized for the Army model MHE-196 forklift truck. Section III lists the maintenance and operating supplies required for initial operation.

2. Explanation of Columns Contained in Section II

a. *Source Codes.* The information provided in each column is as follows:

- (1) *Materiel.* This column lists the basic materiel code number of the supply service assigned responsibility for the part. Those spaces left blank denote supply responsibility of the preparing agency. General Engineer supply parts are identified in the description column. Other basic materiel code numbers are-
5-Engineer Materiel
10-Quartermaster Materiel
- (2) *Source.* The selection status and source of supply for each part are indicated by one of the following code symbols:
 - (a) P-applied to high mortality repair parts which are stocked in or supplied from the supply service depot system, and authorized for use at indicated maintenance level.
 - (b) P1-applied to repair parts which are low mortality parts, stocked in or supplied from supply service depots, and authorized for installation at indicated maintenance level.
 - (c) M-applied to repair parts which are not procured or stocked but are to be

manufactured at indicated maintenance level.

- (d) X2-applied to repair parts which are not stocked. The indicated maintenance level requiring such repair parts will attempt to obtain them through cannibalization, if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.
- (3) *Maintenance.* The lowest maintenance level authorized to use, stock, install, or manufacture the part is indicated by the following code symbols:
O-Organizational Maintenance
- (4) *Recoverability.* Repair parts and/or tool and equipment items that are recoverable are indicated by one of the following code symbols:
 - (a) R-applied to repair parts and assemblies which are economically repairable at direct and general support activities and are normally furnished by supply on an exchange basis.
 - (b) T-applied to high-dollar value recoverable repair parts which are subject to special handling and are issued on an exchange basis. Such repair parts are normally repaired or overhauled at depot maintenance facilities.
 - (c) U-applied to repair parts specifically selected for salvage by reclamation units because of precious metal content, critical materials, high-dollar value reusable casing, castings, and the like.

AGO 7554A

Note. When no code is shown in the recoverability column, the part is considered expendable.

b. Federal Stock Numbers. When a Federal stock number is available for a part, it will be shown in this column, and used for requisitioning purposes.

c. Description.

(1) The item name and a brief description of the part are shown.

(2) A five-digit Federal supply code for manufacturers and/or other supply services is shown in parentheses followed by the manufacturer's part number. This number will be used for requisitioning purposes when no Federal stock number is indicated in the Federal stock number column. *Example:* (08645) 86453.

(3) The letters "GE" shown in parentheses immediately following the description, indicates General Engineer supply responsibility for the part.

d. Unit of Issue. Where no abbreviation is shown in this column, the unit of issue is "each."

e. Quantity Issued With Equipment. This column lists the quantities of repair parts, accessories, tools, or publications that are initially issued with each item of equipment. Those indicated by an asterisk are to be requisitioned through normal supply channels as required.

f. Illustrations. This column is subdivided into two columns which provide the following information:

(1) *Figure number.* Provides the identifying number of the illustration.

(2) *Item number.* Provides the referenced number for the parts shown in the illustration.

3. Index to Federal Supply Code for Manufacturers

05415-Baker Industrial Truck Division of Otis Elevator Co, Cleveland, Ohio

4. Explanation of Columns Contained in Section III

a. Item. This column contains numerical sequenced item numbers, assigned to each component application, to facilitate reference.

b. Component Application. This column identifies the component application of each maintenance or operating supply item.

c. Source of Supply. This column lists the basic materiel code number of the supply service assigned responsibility of the preparing agency. Other basic materiel code numbers are

9-Ordnance Materiel

10-Quartermaster Materiel

d. Federal Stock Number. When a Federal stock number is available, it will be shown in this column and used for requisitioning purposes.

e. Description. The item and a brief description are shown.

f. Quantity Required for Initial Operation. This column lists the quantity of each maintenance or operating supply item required for initial operation of the equipment.

g. Quantity Required for 8 Hours Operation. Quantities listed represent the estimated requirements for an average 8 hours of operation.

h. Notes. This column contains informative notes keyed to data appearing in the preceding column.

Section II. BASIC ISSUE ITEM LIST

Source code				Federal stock No.	Description	Unit of issue	Quantity authorized	Illustration		
Supply service	Source	Maintenance	Recoverability					Quantity issued w/equipment	Figure No.	Item No.
10	P1	O	---	7520-559-9618	Case, maintenance and operational manuals	ea	1	1		
5	X2	O	---	4210-893-1092	Extinguisher, fire	ea	1	1		
10	X2	O		Fork Assembly (05415)700EA1	ea	2	2		
10	X2	O		Fork Retainer (05415) 299NFH1	ea	2	2		
10	X2	O		Headlight Assembly (05415)424MBP3	ea	1	1		
10	X2	O		Knob, directional control (81487)9203W7	ea	1	1		
10	X2	O		Battery Angles (05415)180MBA1	ea	2	2		
10	X2	O		Bar (05415)299NEG1	ea	1	1		
10	X2	O		Rollers (05415)465MCG1	ea	12	12		
10	X2	O		Angles (05415)288Y7255	ea	2	2		
10	X2	O		Flat Washer (96906)MS27183-15	ea	4	4		
10	X2	O		Lock Washer (96906)MS35338-27	ea	4	4		
10	X2	O		Screw cap, hexagon head 3/8 in. 16 by 1 3/4 in. (96906)MS35291-65	ea	4	4		
10	x2	O		Screw cap, hexagon head, 3/8 in. 16 by 3/4 in.	ea	4	4		
					PUBLICATIONS					
					TM 10-3930-255-10.					
					REPAIR PARTS					
					None authorized for operator maintenance.					
					SPECIAL TOOLS					
					None authorized for operator maintenance.					
10			7510-889-3494	EQUIPMENT LOG BOOK Consisting of the following DA Forms: 2408, 2408-1, 2408-2, 2408-3, 2408-5, 2408-6, 2408-7 2408-8, 2408-10, and 2408-11.					

Section III. MAINTENANCE AND OPERATING SUPPLIES

Item	Component application	Source of supply	Federal stock No.	Description	Quantity required for initial operation	Quantity required for 8 hours operation	Notes
1	90 MAINTENANCE AND OPERATING SUPPLIES DIFFERENTIAL AND GEARBOX.			LUBRICATING OIL, GEAR: 5 gal pail as follows:			(1) See current LO for grade application and replenishment intervals. (2) Use oil as prescribed in item 3.
		10	9150-577-5844	GO 90	3 1/2 pt.	(1)	
		10	9150-257-5440	GOS	3 1/2 pt.	(1)	

Item	Component application	Source of supply	Federal stock No.	Description	Quantity required for initial operation	Quantity required for 8 hours operation	Notes
2	BRAKE MASTER CYLINDER.			HYDRAULIC FLUID AUTOMOTIVE: 1 qt. can.			
		10	9150-190-0933	HB	(1)	(1)	
3	HYDRAULIC OIL RESERVOIR.			LUBRICATING OIL, ENGINE:			
		10	9150-265-9428	OE 10 5 gal pail	18 qt	(1)	
		10	9150-242-7603	OES 5 gal pail	18 qt	(1)	
4	OIL CAN POINTS (2).			LUBRICATING OIL, ENGINE (2).			
5	LUBRICATIONS FITTINGS.			GREASE AUTOMOTIVE AND ARTILLERY.	(1)		
		10	9150-190-0904	GAA, 1 lb can			

By Order of the Secretary of the Army

HAROLD K. JOHNSON,
General, United States Army
Chief of Staff.

Official:

J.C. LAMBERT,
Major General, United States Army,
The Adjutant General.

Distribution:

Active Army:

USASA (1)	PG (2)
DCSLOG (1)	Instl (2)
CNGB (1)	QM Fld Maint Shops (2)
CAR (1)	Units org under fol TOE: (2 copies each)
CofEngrs (6)	3-117
CofSptS (1)	5-279
Dir of Trans (1)	5-500
CC-E (1)	8-187
USCONARC (2)	9-197
ARADCOM (2)	9-367
ARADCOM Rgn (2)	10-37
OS Maj Comd (3)	10-337
LOGCOMD (1)	10-407
USAMC (12)	10-417
USAMOCOM (2)	10-445
USAWECOM (5)	10-447
USAMICOM (5)	10-467
USAMUCOM (5)	10-500 (EA, ED, EE, EG)
USAECOM (5)	11-128
USASMC (1)	12-512
MDW (1)	29-51
Armies (5)	29-53
NLABS (4)	29-56
USAMEC (46)	29-57
Svc Colleges (2)	29-105
Br Svc Sch (2) except USAQMS (10)	29-107
USAQMTC (4)	31-105
Mbl Equip Man Fld Ofc (Ft Lee) (2)	31-106
USMA (1)	55-260
Army Depot (4)	55-457
POE (2)	55-458
USA Tml Comd (2)	55-500 (BE, JC)
Army Tml (2)	57
Arsenals (2)	57-100

NG: *State AG* (3)

USAR: None

For explanation of abbreviations used, see AR 320-50.

*U.S. GOVERNMENT PRINTING OFFICE: 1993 0 - 342-421 (63267)

AGO 7554A

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

PUBLICATION DATE

PUBLICATION TITLE

BE EXACT... PIN-POINT WHERE IT IS

PAGE NO.

PARA-GRAPH

FIGURE NO.

TABLE NO.

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2
1 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

