
TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE MANUAL



TRUCK, CONTAINER HANDLER
ROUGH TERRAIN, 50,000 LB CAPACITY
DED, PT, NSN 3930-01-082-3758
WITH TOPHANDLER(S)

TABLE OF CONTENTS
PAGE i

EQUIPMENT DESCRIPTION PAGE 1-3

PMCS PAGE 2-5

TROUBLESHOOTING
PAGE 2-29

ORGANIZATIONAL MAINTENANCE PAGE 2-145

MAINTENANCE ALLOCATION CHART PAGE B-1

> MANUFACTURED ITEMS PAGE D-1

> > INDEX PAGE INDEX-1

HEADQUARTERS, DEPARTMENT OF THE ARMY

JUNE 1981

DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited.

SUMMARY OF WARNINGS (Sheet 1 of 2)

WARNING

If you sustain any injuries, no matter how slight, follow the first aid procedures outlined in FM 21-11.

WARNING

CARBON MONOXIDE (EXHAUST GAS) CAN KILL YOU

Carbon monoxide is without color or smell, but can kill you. Breathing air with carbon monoxide produces symptoms of headache, dizziness, loss of muscular control, a sleepy feeling, and coma. Brain damage or death can result from heavy exposure. Carbon monoxide occurs in the exhaust fumes of fuel-burning heaters and internal combustion engines. Carbon monoxide can become dangerously concentrated under conditions of no air movement. Precautions must be followed to insure crew safety when the personnel heater, main or auxiliary engine of any vehicle is operated for any purpose.

- 1. DO NOT operate personnel heater or engine of vehicle in a closed place unless the place is well-ventilated.
- 2. DO NOT idle engine for long periods.
- 3. DO NOT drive any vehicle with inspection plates, cover plates, or engine compartment doors removed unless necessary for maintenance purpose.
- 4. BE ALERT at all times during vehicle operation for exhaust odors and exposure symptoms. If either is present, IMMEDIATELY VENTILATE personnel compartment. If symptoms persist, remove affected person to fresh air; keep warm; DO NOT PERMIT PHYSICAL EXERCISE; if necessary, give artificial respiration.
 - FOR ARTIFICIAL RESPIRATION, REFER TO FM 21-11.
- 5. BE AWARE: the field protective mask for nuclear-biological-chemical (NBC) protection will not protect you from carbon monoxide poisoning.

THE BEST DEFENSE AGAINST CARBON MONOXIDE POISONING IS GOOD VENTILATION.

WARNING

Use caution when removing radiator filler cap. Steam can cause injury. Do not allow inhibitor to contact skin or eyes. It contains alkali.

Clear area of personnel, obstructions before activating vehicle.

Brake system is under pressure. Relieve pressure before loosening lines. Stop vehicle on level ground. Apply parking brake and shut off engine. Pump brake pedal several times until no pressure remains. This will relieve pressure in brake lines.

Hydraulic system is under pressure. Release pressure by lowering mast and moving hydraulic levers. Remove oil filler cap slowly. Release hydraulic pressure before loosening hydraulic lines.

Use extreme caution when installing jacking device. Do not let jack, beam, or engine slip. Serious injury could result.

Use solvents only in well ventilated areas. Fumes may be dangerous.

WARNING

Do not smoke or have open flames or sparks around fuel lines.

Do not smoke or have open flame or sparks near batteries. Sparks can cause battery gases to explode.

Be careful when working around an engine that is running. Do not touch hot exhaust system components.

Wear face shield and protective clothing to prevent injury when using pressure air or water. Use 30 psi (207 kPa) maximum for cleaning.

Be certain ether starting aid cannister is removed from vehicle before shipment or storage.

Be careful not to drip electrolyte on you or equipment. If electrolyte spills on you, splash affected areas with water to flush electrolyte. Get medical attention at once.

When jacking, be sure the vehicle is on level ground. Put blocks in front of and behind each wheel so vehicle does not move.

Stand behind vehicle when inflating tires. Use self-attaching air chuck.

End

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D.C., 31 May 2006

ORGANIZATIONAL MAINTENANCE MANUAL

TRUCK, CONTAINER HANDLER: ROUGH TERRAIN 50,000 LB CAPACITY, DED, PT NSN 3930-01-082-3758 WITH TOPHANDLER(S)

TM 10-3930-641-20, 26 June 1981, is changed as follows:

- 1. Remove old pages and insert new pages as indicated below.
- 2. New or changed material is indicated by a vertical bar in the margin of the page and by a vertical bar adjacent to the TA number.

Remove Pages	Insert Pages		
2-5 through 2-24	2-5 through 2-24		
	2-24.1 through 2-24.11		
2-74 through 2-78	2-74 through 2-78		
B-1 through B-28	B-1 through B-28 B-29 through B-32		
C-1 through C-4	C-1 through C-4		
2028-2	2028		
Cover	Cover/Pin		

3. File this change sheet in front of the publication for reference purposes

DISTRIBUTION STATEMENT A – Approved for public release; distribution is unlimited.

TM 10-3930-641-20

C2

By Order of the Secretary of the Army:

PETER J. SCHOOMAKER General, United States Army Chief of Staff

Official:

JOYCE E. MORROW Administrative Assistant to the Secretary of the Army 0606903

DISTRIBUTION: To be distributed in accordance with the initial distribution requirements for IDN: 252285, requirements for TM 10-3930-641-20.

CHANGE

No. 1

HEADQUARTERS DEPARTMENT OF THE ARMY WASHINGTON, D.C., 18 July 1989

ORGANIZATIONAL MAINTENANCE MANUAL

TRUCK, CONTAINER HANDLER: ROUGH TERRAIN 50,000 LB CAPACITY, DED, PT NSN 3930-01-082-3758 WITH TOPHANDLER(S)

TM 10-3930-641-20, 26 June 1981, is changed as follows:

- 1. Remove old pages and insert new pages as indicated below.
- 2. New or changed material is indicated by a vertical bar in the margin of the page and by a vertical bar adjacent to the TA number.

Remove pages	Insert pages
ii(ii Blank)	i/(ii Blank)
1-1 and 1-2	1-1 and 1-2
2-3 and 2-4	2-3 and 2-4
2-11 and 2-12	2-11 and 2-12
2-23 and 2-24	2-23 and 2-24
2-391 and 2-392	2-391 and 2-392
None	2-398.1 through 2-398.11/(2-398.12 Blank)
2-513 and 2-514	2-513 and 2-514
A-1 and A-2	A-1 and A-2
B-17 through B-20	B-17 through B-20
B-25 and B-26	B-25 and B-26
INDEX-5 and INDEX-6	INDEX-5 and INDEX-6

3. File this change sheet in front of the publication for reference purposes.

Bv	Order	of	the	Secretary	of	the	Army:

CARL E. VUONO General, United States Army Chief of Staff

Official:

WILLIAM J. MEEHAN II Brigadier General, United States Army The Adjutant General

Distribution:

To be distributed in accordance with D.A Form 12-25F, Unit maintenance requirements for Truck, Container Handler, 50,000 LB capacity, Rough Terrain.

LIST OF EFFECTIVE PAGES

NOTE

A vertical line in the outer margins of the page indicates the portion of text effected by the change. Changes to illustrations are indicated by miniature pointing hands. Change to wiring diagrams is indicated by shaded areas.

Dates of issue for original and change pages are:

Original - 26 June 1981. C1 18 July 1981, C2 31 May 2006

TOTAL NUMBER OF PAGES FOR FRONT AND REAR MATTER IS 31 AND TOTAL NUMBER OF CHAPTERS IS 10 CONSISTING OF THE FOLLOWING:

Page No.	Change No.	Page No.	Change No.
Cover/Pin	2	DA Form 2028 Sample	2
a and b	0	DA Form 2028 (three)	2
A and B	2	Back Cover/PIN Number	0
i/(ii Blank)	1	Foldouts	0
1-1 and 1-2	1		
1-3 thru 1-28	0		
2-1 thru 2-4	0		
2-5 thru 2-24	2		
2-24.1 thru 2-24.12	2		
2-25 thru 2-4-73	0		
4-27 thru 2-79	2		
2-80 thru 2-398	0		
2-398.1 thru 2-398.11/			
(2-398.12 Blank))	1		
2-399 thru 2-515	0		
A-1 and A-2	1		
B-1 thru B-28	2		
C-1 thru C-4	2		
D-1 thru D-9/(D-10 Blank)	0		
E-1 and E-2	0		
Index-1 thru Index-7	0		
Authentication Page	0		

TECHNICAL MANUAL NO.10-3930-641-20 HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 26 June 1981

ORGANIZATIONAL MAINTENANCE MANUAL

TRUCK, CONTAINER HANDLER: ROUGH TERRAIN 50,000 LB CAPACITY, DED PT NSN 3930-01-082-3758 WITH TOPHANDLER(S)

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and *Blank Forms*), or DA Form 2028-2, located in the back of this manual, direct to: Commander, U.S. Army Tank-Automotive Command, ATTN: AMSTA-MB, Warren, MI 48397-5000. A reply will be furnished to you.

	Page		Page
CHAPTER 1	INTRODUCTION	APPENDIX A	REFERENCES
Section I II	General Information	В	MAINTENANCE ALLOCATION CHART B-1
III	Technical Principles of Operation 1-10	Section I	Introduction
CHAPTER 2	ORGANIZATIONAL MAINTENANCE INSTRUCTIONS	III IV	Tool and Test Equipment Requirements B-26 Remarks
Section I	Repair Parts, Special Tools and TMDE 2-2 Service Upon Receipt 2-3	APPENDIX C	EXPENDABLE SUPPLIES AND MATERIALS
III	Preventive Maintenance Checks and	ъ	
IV	Services	D	ILLUSTRATED LIST OF MANUFACTURED ITEMS
V VI	Maintenance	Е	TORQUE LIMITS E-1
VII	Preparation for Storage or Shipment 2-513	INDEX	

CHAPTER 1

Section I. GENERAL INFORMATION

SCOPE

This manual is for your use in performing organizational maintenance of the Rough Terrain Container Handler (RTCH).

MAINTENANCE FORMS, RECORDS AND REPORTS

Maintenance forms, records, and reports which are to be used by maintenance personnel at all maintenance levels are listed in and prescribed by DA Pam 738-750, The Army Maintenance Management System (TAMMS).

DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE

Refer to TM 750-244-3, Procedures for Destruction of Equipment to Prevent Enemy Use.

REPORTING OF EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR)

EIR can and must be submitted by anyone who is aware of an unsatisfactory condition with the equipment design or use. It is not necessary to show a new design or list a better way to perform a procedure, just simply tell why the design is unfavorable or why a procedure is difficult. EIR may be submitted on SF 368 (Quality Deficiency Report). Mail directly to Commander, U.S. Army Tank-Automotive Command, Warren, MI 48397-5000, ATTN: AMSTA-QRD. We'll send you a reply.

WARRANTY INFORMATION

The Rough Terrain Container Handler is warranted by Caterpillar Tractor Co. for 15 months or 1500 hours of operation, whichever comes first. Warranty starts on the date found on DA Form 2408-9 in the log book. Report all defects in material or workmanship to your supervisor, who will take appropriate action.

PREPARATION FOR STORAGE OR SHIPMENT

Refer to Chapter 2, Section VII of this manual for requirements for storage or shipment, including administrative storage.

1-2

Section II. EQUIPMENT DESCRIPTION AND DATA

EQUIPMENT PURPOSE, CAPABILITIES AND FEATURES

(Sheet 1 of 1)

PURPOSE

- 1. Handles ISO (International Standards Organization) designation 1A or IC cargo containers or Sealand Containers.
- 2. Handles and stacks containers.

- 3. Loads and unloads flatbed trailers and rail cars.
- 4. Makes over-the-shore landings.

CAPABILITIES AND FEATURES


- 1. Operates over rough terrain including beaches, snow, mud and cross country.
- 2. Fords up to 60 inches (152 cm) of salt water.
- 3. Comes with a 20 ft (6.1 m) tophandler and may also have a 35 ft (10.6 m) or 40 ft (12.2 m) tophandler.

- 4. Raises, lowers, tilts forward or backward, sideshifts or sidetilts a container load.
- 5. Lifts a load from 12 in. (30 cm) below ground level to 118 in. (300 cm) above ground level (measured to bottom of container)
- 6. Articulated (bends in center) for easy load handling.

LOCATION AND DESCRIPTION OF MAJOR COMPONENTS

- 1. RADIATOR For cooling system. Grille faces rear.
- 2. UPPER ENGINE ACCESS PANELS Two on each side. Hinged for easy access.
- 3. HOOD Two-piece, can be removed.
- 4. OPERATOR'S CAB Equipped with rollover protective structure (ROPS).
- 5. AUXILIARY HEADLIGHT One on each side of cab.
- 6. LIGHTS High beam and low beam on each side of cab.

- 7. TILT CYLINDER One on each side. Tilts the mast forward and backward.
- 8. MAST Moves to position the contair w,
- 9. FORKS Mount and secure the tophandlers.
- 10. FRONT WHEELS, AXLES AND FINAL DRIVES.
- 11. STEERING CYLINDER One on each side.
- 12. HITCH Articulated for easy steering maneuverability.



TA 098558


Go on to Sheet 2

(Sheet 2 of 3)

- 13. HYDRAULIC TANK (SEE p. 1-4) On right side of vehicle or FUEL TANK On left side of vehicle.
- 14. REAR WHEELS, FINAL DRIVES AND AXLES.
- 15. LOWER ENGINE ACCESS PANE LS one on each side of engine. Remove for access.

- 19. LIFT CYLINDER Raises and lowers the mast.
- 20. SIDE SHIFT CYLINDER Shifts forks and tophandler to the side.
- 21. SIDE TILT CYLINDER Rotates forks and tophandler.

- 16. BATTERY BOX Two batteries cm each side of vehicle.
- 17. COUNTERWEIGHT Provides stability when handling load.
- 18. TOWING PINTLE For towing operations.



TA 098559


Go on to Sheet 3

22. CONTAINER LOCK CYLINDER -


1 on 20 ft (6 m) tophandler,

2 on 35 ft (10.7 m) and 40 ft (12 m) tophandler.

Rotates locks to secure container to tophandler.



20 FI TOPHANDLER



35 FT OR 40 FT TOPHANDLER

TA 098580

End

PERFORMANCE DATA (Sheet 1 of 3)

ENGINE Model	
Engine low idle speed (foot off accelerator) 700 rpm	
Engine high idle speed (accelerator held to floor) 2320 rpm Engine operating range Full	
Ignition Type	
Bore	
Stroke	
Displacement	
Compression ratio	
Firing order	
Fuel Diesel No.2 Weight 3200 lbs(1450 kg)	

HYDRAULIC SYSTEM
Type Closed with vacuum relief
Pump Single stage
Type/Output
Relief valve setting
Operating pressur e
Weight
Cylinders
Lift (bore x stroke)
Tilt (bore x stroke)
Sideshift (bore x stroke) 6'' x 24"
Sidetilt (bore x stroke) 6" x 6.5"
Brakes All wheel disc
Type Full hydraulic oil bath disc
Braking surface
Pump type Gear
Output
Relief valve setting
Weight

PERFORMANCE DATA (CONT)

(Sheet 2 of 3)

Steering	Center point frame articulation
Type	
Steering angle (each direction)	
Pump type	
Output	l0l gpm @ 1000 psi
Operating pressure	
	$\dots \dots $
Electrical	
Batteries	Lead-acid
Type	8D
Voltage (nominal)	
Alternator	Integral regulator
Type	Solid state
	50A

Transmission and Powertrain		
Type	Power shift	planetary
Transmission reduction ratio		
	Forward	Reverse
First	. 5.6049	4.9043
Second	. 3.1429	2.7500
Third	. 1.7751	1.5532
Fourth	. 1.0000	0.8750
Weight	1756 lbs	(796 Kg)
Transfer case reduction ratio		
Input		. 1.0256
Output	. .	1.1795
Weight	1080 lbs	(490 Kg)
Final drive reduction ratio		. 5.0526
Bevel gear reduction ratio		3.7500
Axle oscillation		
Front		Fixed
Rear	. 	±13°

PERFORMANCE DATA (CONT)

(Sheet 3 of 3)

Size. 35/65-R33 With rated load 14.5 mph 14 Inflation pressure Without rated load 18.5 mph 19 Front 70 psi Rear 40 psi Towing 5 mph for 10 miles m	
Size. 35/65-R33 With rated load 14.5 mph 14.5 mph 14.5 mph 14.5 mph 14.5 mph 15 mph 16 mph	everse
Inflation pressureWithout rated load	9.9 mph
Front	0.4 mph
Rear	•
	aximum
Weight (tire and rim)	
Maximum fording depth*	
Maximum side slope*	15°
General Maximum breakover angle*	
Shipping weight Maximum approach angle*	
Operational weight	
Without container handler 103,230 1bs (46,830 Kg) Maximum ground clearance*	16"
With 20'container handler 107,030 1bs(48,550 Kg) Curb circle clearance	70'
With 35' container handler 112,3501bs (50,960 Kg) Tilt cycling time (each direction)*	seconds
With 40'container handler 113,160 lbs (51,330 Kg) Lifting capacity	00 Kg)
*Tophandler raised 1 footFull 1	ack tilt

REFILL CAPACITIES (Approximate)

COMPARTMENT OR SYSTEM		U.S. MEASURE	METRIC MEASURE
Engine Crankcase		11 gal.	42 liters
Hydraulic Tank		78 gal.	295 liters
Transmission		17.5 gal.	66 liters
Differential and Final Drives	Front	27 gal.	102 liters
	Rear	27 ml.	102 liters
Cooling System		28 gal.	106 liters
Fuel Tank		165 gal.	625 liters

Section III. TECHNICAL PRINCIPLES OF OPERATION

This section contains a functional description of operation of these vehicle systems:

Engine lubrication systeim

Cooling system

Fuel system

Air inlet and exhaust system

Electrical system

Drive system

Brake system

Steering system

Mast hydraulic system

Transmission hydraulic system

The purpose of this section is to provide enough information to allow a maintenance technician to do the job properly.


ENGINE LUBRICATION SYSTEM DESCRIPTION

(Sheet 1 of 1)

Engine lubrication system consists ofl

- 1. Oil pan
- 2. Oil pump
- 3. Oil cooler
- 4. Oil filters
- 5. Oil cooler bypass valve
- 6. Oil filter bypass valve
- 7. Oil lines and passages
- 1. OIL PAN. Seals the bottom of the engine and functions as a reservoir for storing engine lubricating oil. A plug is provided in the bottom for draining engine oil.
- 2. OIL PUMP. A gear-type driven by a gear on the engine crank-shaft. The pump's function is to supply the engine lubrication system with oil flow. Oil is pulled from the oil pan and sent to the oil cooler.
- 3. OIL COOLER. Reduces the temperature of the engine lubricating oil by transferring the heat of the oil to the engine cooling system.
- 4. OIL FILTERS. Remove foreign particles from the engine lubrieating oil.

- 5. OIL COOLER BYPASS VALVE. Provides immediate lubrication to the engine when the engine is cold. The valve also provides for continuous lubrication if the oil cooler has a restriction in it.
- 6. OIL FILTER BYPASS VALVE. Provides immediate lubrication to the engine, for a few seconds, when the engine is started cold. The valve also provides the engine with continuous lubrication when the filters are plugged.
- 7. OIL LINES AND PASSAGES. Provide the lubrication system with a means of oil flow.




COOLING SYSTEM DESCRIPTION (Sheet 1 of 2)

Cooling system components are:

- 1. Radiator
- 2. Water temperature regulators
- 3. Radiator bypass lines
- 4. Water pump
- 5. Fan
- 6. Engine oil cooler
- 7. Transmission oil cooler
- 1. RADIATOR. The radiator is a sealed pressure type radiator. Coolant flows through the inside of the core and is cooled by the inside of the core and is cooled by the action of air flowing through the outside of the core and around the fins.
- 2. WATER TEMPERATURE REGULATORS. Control the temperature of the coolant by restricting the amount of coolant flow to the radiator. When the engine is cold, the regulators will stop the flow of coolant to the radiator and allow the coolant to recirculate in the cylinder block until it is warm. When the coolant is warm enough the regulators will begin to open, allowing it to flow through the radiator. When the engine is completely warmed up the regulators will allow a full flow of coolant through the radiator to maintain the engine operating temperature.

- 3. RADIATOR BYPASS LINES. Allow the coolant to circulate through the engine block, without going to the radiator.
- 4. WATER PUMP. Pumps the coolant through the cooling system.
- 5. FAN. Draws air through the radiator core to remove heat from the coolant.
- 6. ENGINE OIL COOLER. Cools the engine oil.
- 7. TRANSMISSION OIL COOLER. Cools the transmission oil.



TA 098566

End


(Sheet 1 of 2)

FUEL SYSTEM DESCRIPTION

The direct injection fuel system consists of:

- 1. Fuel tank
- 2. Primary fuel filter
- 3. Transfer pump
- 4. Priming pump
- 5. Secondary fuel filter
- 6. Injection pump
- 7. Injection nozzles
- 8. Governor
- 9. Fuel lines
- 10. Ether starting aid
- 1. FUEL TANK. Located next to the cab on the left side of the vehicle. The capacity of the tank is 165 gal. (625 liters). The tank has a drain valve and drain plug at the bottom and a filler screen and cap at the top.
- 2. PRIMARY FUEL FILTER. Filters all fuel coming from the fuel tank before the fuel enters the transfer pump.
- TRANSFER PUMP. Sends the fuel to the priming pump, secondary filter and the injection pump.

- 4. PRIMING PUMP. Used to prime fuel system on initial startup or after changing fuel filters. The priming pump also removes air from the fuel system.
- 5. SECONDARY FUEL FILTER. A final filter before fuel enters injection pump.
- 6. INJECTION PUMP. Provides the injection nozzles with a metered, high pressure charge of fuel at a precise time.
- 7. INJECTION NOZZLES. Spray the metered amount of fuel from the injection pump into the cylinder for combustion.
- 8. GOVERNOR. Controls the amount of fuel needed to keep the desired engine speed. The governor is controlled by the accelerator pedal.
- 9. FUEL LINES. Carry fuel from the tank to various components of the fuel system and provide return routes for unused fuel.
- 10. ETHER STARTING AID. Delivers a measured amount of ether into the turbocharger inlet for ease in cold weather starting. The ether is stored under pressure in a cylinder and the amount to be sprayed into the inlet is controlled by an electrically activated valve.



TA 098564

End

1-15


AIR INLET AND EXHAUST SYSTEM DESCRIPTION

(Sheet 1 of 1)

Air inlet and exhaust system components are:

- 1. Air cleaner
- 2. Turbocharger
- 3. Inlet manifold
- 4. Cylinder heads
- 5 Exhaust manifolds
- 6. Exhaust pipe and muffler
- 1. AIR CLEANER. A dual element, dry type. Outside air is drawn through the filter elements by a vacuum created in the turbocharger. When one, or both, of the elements get clogged, a "high vacuum" switch in the air cleaner housing turns on the PLUGGED AIR FILTER indicator on the instrument panel.
- 2. TURBOCHARGER. Pulls in the clean air from the air cleaner and compresses it. The turbocharger is driven by the engine exhaust gases; the exhaust gases turn the turbine wheel, which causes the compressor wheel to turn. The compressed air then goes to the inlet manifold of the engine.
- 3. INLET MANIFOLD. The system of passages inside the engine used to guide the compressed air to the cylinders.
- 4. CYLINDER HEADS. Contain the valves and valve system components which control the flow of inlet air and exhaust gases into and out of the cylinder during engine operation.

- 5. EXHAUST MANIFOLDS. Carry the exhaust gases from the cylinders to the turbocharger.
- 6. MUFFLER AND EXHAUST PIPE. Reduces engine noise and carries exhaust gases away from engine compartment.




TA 098890

End

The major components of the electrical system are:

- 1. Engine stop solenoid
- 2. Batteries (4)
- 3. Left hand instrument panel
- 4. Right hand instrument panel
- 5. Container lock indicator panel
- 6. Ether aid solenoid
- 7. Starting motor
- Starter solenoid
- 9. Engine relay panel
- 10. Main disconnect switch
- 11. Alternator
- 12. Wiring harness.
- 1. ENGINE STOP SOLENOID. Closes the fuel supply to the fuel injection pump when the POWER switch is turned to OFF which stops the engine.
- 2. BATTERIES (4). Two sets of 12-volt batteries, one set on each side of the engine near the radiator, are connected in a seriesparallel arrangement to provide 24 volts dc to the vehicle electrical system.

- LEFT HAND INSTRUMENT PANEL. Contains lights which illuminate to provide visual indication of vehicle operating cxmditicm. Also contains light switches, service meter, wiper/washer switch and fuses.
- 4. RIGHT HAND INSTRUMENT PANEL. Contains gages to indicate vehicle operating conditions. Also contaks POWER switch and fuses.
- 5. CONTAINER LOCK INDICATOR PANEL. contains lights which indicate top handler locked/unlocked condition.
- 6. ETHER AID SOLENOID. Opens to allow ether to enter the turbocharger outlet when the START AID switch is pushed during cold weather starting. The ether aid solenoid will not adivate if temperature is above 80°F (26.7°C).
- 7. STARTING MOTOR. Used to turn the engine fast enough to get the engine running. It is activated only when the starter solenoid contacts are closed.
- 8. STARTER SOLENOID. Engages the starter pinion with the flywheel ring gear and closes the starting motor circuit. This happens only when the POWER, switch is turned to START and the transmission is in NEUTRAL.
- 9. ENGINE RELAY PANEL. Contains engine harness connectors, engine relays, diodes and circuit breakers in one easily accessed location.



12. WIRING HARNESSES (NOT SHOWN)

TA 098802

Go on to Sheet 3


(Sheet 3 of 3)

- 10. MAIN DISCONNECT SWITCH. Disconnects the batteries from the rest of the electrical system.
- 11. ALTERNATOR. Makes electricity for the chargng circuit. A built-in voltage regulator controls the electrical output to keep the batteries at full charge.
- 12. WIRING HARNESS. Provide a patch for current flow from the batteries through the various components of the electrical system. (Not called out on illustration.)

DRIVE SYSTEM DESCRIPTION (Sheet 1 of 2)

Drive system transfers power from the engine to drive the wheels and consists of:

- 1. Diesel engine
- 2. Torque converter
- 3. Upper drive shaft
- 4. Input transfer gears
- 5. Transmission
- 6. Output transfer gears
- 7. Drive shafts
- 8. Bearing cage
- 9. Differential
- 10. Final drive



TA 098561

Go on to Sheet 2

DRIVE SYSTEM DESCRIPTION (CONT)

(Sheet 2 of 2)


- DIESEL ENGINE. Provides mechanical power necessary for drive train. Power is transmitted from engine flywheel to torque, converter.
- 2. TORQUE CONVERTER. Connects the engine power to the drive train, similar to a mechanical clutch.
- 3. UPPER DRIVE SHAFT. Transmits power from torque converter to the input transfer gears.
- 4. INPUT TRANSFER GEARS. A system of gears which provides a speed reduction between torque converter and transmission, The output gear of the transfer gears turns the input shaft of the transmissioil.
- 5. TRANSMISSION. A hydraulically activated (automatic) type. The transmission has four speed ranges FORWARD and four speed ranges in REVERSE. Both speed and direction are manually selected.
- 6. OUTPUT TRANSFER GEARS. A system of gears at the output side of the transmission which transmits power from the transmission to the drive shafts.

- 7. DRIVE SHAFTS (3). A means of transmitting power from:
 - (A) Output transfer gears to the rear differential.
 - (B) Output transfer gears to the bearing cage.
 - (C) Bearing cage to the front differential.
- 8. BEARING CAGE. Supports the extra universal joint and drive shafts required for articulated steering. Also, it transmits power between drive shafts (2) and (3).
- 9. DIFFERENTIAL. A gear arrangement that connects and divides the power from the drive shaft to the axle shafts. Dividing the power causes the outside wheel to turn faster than the inside when making a turn. This vehicle is equipped with a front and rear differential; both function in the same manner.
- 10. FINAL DRIVE. A gear arrangement that causes the last speed reduction and torque increase in the power train. Input power for the final drive is from the axle shaft and the output is the road wheel. There are four final drives on this vehicle, one for each wheel.

BRAKE SYSTEM DESCRIPTION (Sheet 1 of 2)

Brake system consists of:

- 1. Hydraulic pump (small section)
- 2. Accumulator charging valve
- 3. Accumulator
- 4. Brake control valve
- 5. Transmission neutralizer control valve
- 6 Service brakes
- 7. Emergency and parking brake
- 8. Emergency and parking brake control valve
- 1. HYDRAULIC PUMP (Smaller Section). Positive displacement, gear-type. Pump driven by the engine, supplies oil to operate brake and implement pilot oil systems. Oil is pumped from hydraulic tank to accumulator charging valve for distribution to the two systems.
- 2. ACCUMULATOR CHARGING VALVE. Distributes flow of oil, from pump, to brake and implement pilot control systems. Contains a check valve and a pressure relief valve. Check valve keeps pressure in accumulator in a constant range of 1950 PSI (137.1 kg/cm²) maximum to 1450 PSI (101.9 kg/cm²) minimum. Pressure relief valve controls maximum oil pressure in accumulater if accumulator charging valve malfunctions.
- 3. ACCUMULATOR. A cylinder which stores pressurized hydraulic oil for brake system. A part in accumulator allows oil to go to brake control valve when either brake pedal is pushed.



- 4. BRAKE CONTROL VALVE. Regulates amount of high pressure oil from the accumulator required to obtain a specific pressure at the wheel brakes. Specific-pressure required is determined by position of either brake pedal.
- 5. TRANSMISSION NEUTRALIZER CONTROL VALVE. Causes transmission to shift into neutral when left brake pedal is pushed. This provides for full engine power to hydraulic system.
- 6. SERVICE BRAKES (4). Oil activated, disc-type. Pushing either brake pedal sends pressurized oil from brake control valve to push against discs and plates in the brake housing, causing friction. This friction causes wheels to turn slower or stop.

TA 098566

Go on to Sheet 2

7. EMERGENCY AND PARKING BRAKE. (See page 1-22) A spring activated, disc-type. Brake is mounted on the output transfer case. When activated, it prevents output transfer gears from turning. Brake is released by high pressure accumulator oil.

NOTE


If, due to a malfunction in accumulator charging circuit, pressure drops below 700 PSI (49.2 kg/cm²), the brake will automaticxdly be activated.


8. EMERGENCY AND PARKING BRAKE CONTROL VALVE. Controls oil flow from accumulator to emergency and parking brake. Valve is manually activated by the operator. Pulling out on parking brake control knob, on right side of steering column, causes brake to be applied. Pushing in cm knob causes brake to release.

Steering system can be divided into three groups: steering group, pilot group, and supplemental steering group.

A. STEERING GROUP COMPONENTS

- 1. HYDRAULIC PUMP (Larger Section). A gear-type, driven by the engine. The pump is used to supply hydraulic oil to the steering system. The oil is pulled from the hydraulic tank and pumped to the diverter valve.
- ⁹. STEERING CONTROL VALVE. Directs the high pressure oil to one of the two steering cylinders depending on which direction the steering wheel is turned. The control valve is hydraulically activated by the neutralizer valves.
- 3. STEERING CYLINDERS (2). Are activated by high pressure hydraulic oil from the control valve. When a left turn is being made, the right steering cylinder is activated; when a right turn is being made, the left cylinder is activated.
- 4. HYDRAULIC TANK. The storage reservoir for all of the hydraulic oil used in the machine except for the transmission and torque converter. An inlet strainer provides filtering when adding or replacing oil to the tank. Also, a filter is built into the tank for filtering all of the oil returning from the hydraulic system.





6. NEUTRALIZER VALVES (2) Stop the flow of pilot oil to the steering control valve at the end of a complete turn in either direction. This stops the steering action before the machine turns against the frame stops. The valves are normally open, allowing flow through them.
TA 098585

Go on to Sheet 2

B. SUPPLEMENTAL STEERING COMPONENTS (See page 1-24)

The supplemental steering system has two purposes:

To give an oil supply for the steering system if there is a failure of the primary system or if the engine stops when the machine is moving.

To add oil to the primary oil flow when the engine rpm is less than 1170 to 1300 rpm and the machine is moving.

7. SUPPLEMENTAL STEERING PUMP. A ground driven, geartype pump. Ground driven means that the pump turns as long as

the machine moves. The pump gets its power from the output transfer gears of the transmission. Its function is to supply oil to the steering system when there is a failure of the primary pump or when the engine stops and the machine is still moving. It also adds oil to the primary oil flow when the engine is turning at less than 1170 to 1300 rpm and the machine is moving.

- 8. DIVERTER VALVE. Senses the pressure and controls the flow direction of the oil from the primary and supplemental pumps.
- 9. FLOW SWITCH. Warns the operator of a failure of the primary pump or lines.

HYDRAULIC SYSTEM DESCRIPTION


(Sheet 1 of 2)

High pressure mast hydraulic system consists of:

- 1. Hydraulic tank
- 2. Hydraulic pump
- 3. Control valve
- 4. Lift cylinder
- 5. Tilt cylinders
- 6. Side shift cylinder
- 7. Side tilt cylinder
- 8. Container lock cylinders

Oil flows from hydraulic tank (1) to hydratdic pump (2) then to control valve (3). The control levers are moved to let oil go through the control valve to lift cylinder (4), tilt cylinders (5), side shift cylinder (6), side tilt cylinder (7) or container lock cylinders (8). Oil returns from the cylinders through the control valve and back to the tank.

- 1. HYDRAULIC TANK. The storage reservoir for all of the hydraulic oil used in the machine except for the transmission and torque converter. Equipped with an inlet strainer for filtering oil when added. A filter is built into the tank for filtering oil returning from the hydraulic system.
- 2. HYDRAULIC PUMP. A gear-type, driven by the engine. Supplies oil to the control valve for distribution to the hydraulic system.
- 3. CONTROL VALVE. Directs high pressure oil to hydraulic cylinders, depending on the position of hydraulic control lever.




Contains an oil pressure relief valve to return extra oil pressure back to the hydrau!ic tank when the mast is fully tilted, fully raised, fully shifted or fully rotated.


- 4. LIFT CYLINDER. A ram-type cylinder which moves up by hydraulic oil pressure and moves down by gravity. The extended part of the cylinder is completely filled with oil.
- 5. TILT CYLINDERS (2). Double acting cylinders which extend by hydraulic pressure and retract by hydraulic pressure. Control the forward-backward tilt angle of the mast.

 TA 098567

Go on to Sheet 2

- 6. SIDE SHIFT CYLINDER. A double acting cylinder which comtrols the side shift of the forks and tophandler with respect to the center line of the vehicle.
- 7. SIDE TILT CYLINDER. A double acting cylinder which rotates the forks and tophandler.
- 8. CONTAINER LOCK CYLINDERS. One on 20 ft tophandler and two on 35 ft and 40 ft tophandlers. Extend to lock the tophandler to the container.





35 & 40 FT TOPHANDLER

TA 098510

End


TRANSMISSION HYDRAULIC SYSTEM DESCRIPTION

(Sheet 1 of 1)

Transmission hydraulic system consists of:

- 1 Oil reservok
- 2. Oil filter
- 3. Magnetic screen
- 4. Oil pump
- 5. Oil cooler
- 6. Connecting lines
- 1. OIL RESERVOIR. The lower portion of the output transfer gear case serves as a reservoir for the transfer gear and transmission. A drain plug is located in the bottom of the case for draining transmission system oil.
- 2. OIL FILTER. Removes debris from the hydraulic oil. The filter is located in the compartment behind the cab.
- 3. MAGNETIC SCREEN. Removes metal particles and other debris before the oil goes to the oil pump. The screen is fastened to the output transfer gear case.
- 4. OIL PUMP. A gear-type pump, driven by the engine. Oil is pulled from the reservoir, through the magnetic screen and pumped to the oil filter.

- 5. OIL COOLER. Removes heat from the transmission system hydraulic oil. High temperature oil comes from the torque converter and passes through the oil cooler. The heat of the oil is transferred to the engine cooling system and the cooler oil returns to the transmission.
- 6. CONNECTING LINES. Carry oil to and from the oil filter and oil cooler.



End

CHAPTER 2

ORGANIZATIONAL MAINTENANCE INSTRUCTIONS

Page	Page
Section I. Repair Parts, Special Tools, TMDE and Support Equipment	Engine Maintenance Instructions
II. Service Upon Receipt	Instructions
III. Preventive Maintenance Checks and Services	Brake System Maintenance Instructions
IV. Troubleshooting2-29Symptoms Index2-30Troubleshooting2-34Electrical System Troubleshooting2-49	Body Accessory Items Maintenance Instructions
V. Maintenance	Section VI. Radio Interference Suppression 2-505
Cleaning 2-150	VII. Preparation for Storage or Shipment 2-508

Section I. REPAIR PARTS, SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT

COMMON TOOLS AND EQUIPMENT

For authorized common took and equipment, refer to the Modified Table of Organization and Equipment (MTOE) applicable to your unit.

SPECIAL TOOLS, TMDE AND SUPPORT EQUIPMENT

Refer to TM 10-3930-641-20P for special tools and TMDE you will need in maintaining the vehicle. No support equipment is required.

REPAIR PARTS

Repair parts are listed and illustrated in the repair parts and special tools list, TM 10-3930-641-20P, covering organizational maintenance for this equipment.

Section II. SERVICE UPON RECEIPT

INSPECTING AND SERVICING PRESERVED VEHICLES

Do the following if the vehicle you receive has been stored:

- 1. Remove any tape or seals installed to protect openings.
- 2. Remove the covering from over the windshield, windows, rear view mirrors, and lights.
- 3. Remove the covering from the operator's seat.
- 4. Remove the plastic covering from the instrument panel and steering column.
- 5. Fill the fuel tank. Refer to TM 10-3930-641-10.
- 6. Check tire pressure and inflate to the right pressure. See page 2-397.
- 7. Check coolant in the radiator. The radiator is filled with antifreeze and water. Drain coolant and refill. See page 2-214.
- 8. Wipe preservative from all exposed metal surfaces.
- 9. Check for damage.
- 10. Clean all exterior surfaces. Touch up paint scratches.
- 11. Do the before operation (B) preventive maintenance checks and services. Refer to TM 10-3930-641-10.
- 12. Do the lubrication specified in LO 10-3930-641-12.
- 13. Check batteries for charge. See page 2-268.
- 14. Make sure the vehicle is ready for operation. Then remove all warning tags.

INSPECTING AND SERVICING NON-PRESERVED VEHICLES

- 1. Do the before operation (B) preventive maintenance checks and services. See TM10-3930-641-10.
- 2. Do the lubrication specified in LO 10-3930-641-12.
- 3. Report any deficiencies or damage in accordance with DA Pam 738-750. Report to Commander, U.S. Army Tank-Automotive Command, Warren, MI 48397-5000, ATTN: AMSTA-M.
- 4. Check tires, fill fuel tanks and check coolant.

INSTALLATION

Depending on the way the vehicle was shipped, components may have been removed. Install as required.

Component

Mast Contact Direct Support
Rollover protective structure (ROPS)
Exhaust pipe
Cab

Section III. PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)

OVERVIEW (Sheet 1 of 1)

To make sure that the RTCH is ready for operation at all times, it must be systematically inspected and serviced. The following pages include your Organizational PMCS Introduction and Organizational PMCS.

(Sheet 1 of 9)

GENERAL

- 1. To ensure that the RTCH is ready for operation at all times, it must be lubricated and inspected on a regular basis so that defects may be found before they result in serious damage, equipment failure, or injury to personnel.
- 2. The KEY in this PMCS Introduction lists the types, amounts, and temperature ranges of the lubricants required for specified intervals.
- 3. Lubrication Charts at the end of this PMCS Introduction show all lubrication points for the RTCH.
- 4. Organizational PMCS contains systematic instructions on lubrications, inspections, adjustments, and corrections to be performed by Organizational Maintenance to keep the RTCH in good operating condition and ready for its primary mission.

EXPLANATION OF TABLE ENTRIES

1. <u>Item Number (Item No.) Column</u>. Numbers in this column are for reference. When completing DA Form 2404 or DA Form 5988-E (*Equipment Inspection and Maintenance Worksheet*), include the item number for the check/service indicating a fault. Item numbers also appear in the order you must perform checks and services for the interval listed.

NOTE: If both an hours and calendar interval are provided, perform check or service at whichever interval comes first.

- 2. <u>Interval Column</u>. This column tells you when you must perform the procedure in the procedure column. Intervals are based on hours or calender dates.
 - a. Hours procedures must be done at the hour interval listed.
 - b. Semiannual procedures must be done twice each year
 - c. Annual procedures must be done once each year.
 - d. Biennial procedures must be done once every two years.
 - e. *Triennial* procedures must be done once every three years.
- 3. Man-Hours Column. This column indicates man-hours required to complete prescribed lubrication service.
- 4. <u>Item to Check/Service Column</u>. This column identifies the item to be checked or serviced.
- NOTE: The WARNINGs and CAUTIONs appearing in your PMCS table should always be observed. WARNINGs and CAUTIONs appear before applicable procedures. These WARNINGs and CAUTIONs must be observed to prevent serious injury to yourself and others or to prevent your equipment from being damaged.
- 5. **Procedure Column.** This column gives the procedure you must perform to check or service the item listed in the Item to Check/Service column, to know if the equipment is ready or available for its intended mission or for operation. You must perform the procedure at the time stated in the interval column.
- 6. Not Fully Mission Capable If: Column. Information in this column tells you what fault will keep your equipment from being capable of performing its primary mission. If you perform check/service procedures that show faults listed in this column, the equipment is not mission-capable. Follow standard operating procedures for maintaining the equipment or reporting equipment failure.

ORGANIZATIONAL PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) INTRODUCTION - CONT

(Sheet 2 of 9)

GENERAL LUBRICATION PROCEDURES

- NOTE 1: Lubrication instructions in LO 10-3930-641-12 have been superseded: Operator Maintenance level lubrication is contained in PMCS in TM 10-3930-641-10. Organizational Maintenance level lubrication is contained in this PMCS.
- NOTE 2: Lubrication instructions contained in this PMCS are mandatory.
- NOTE 3: Dashed leader lines used in illustrations of lubrication points indicate that lubrication is required on both sides of the equipment.
- 1. Recommended intervals are based on normal conditions of operation, temperature, and humidity. When operating under extreme conditions, such as high or low temperatures or exposure to sand or dust, lubricants should always be changed more frequently. Lubricants that have become contaminated must be changed regardless of interval. When in doubt, notify your supervisor.

WARNING: When servicing this machine, performing maintenance, or disposing of materials such as engine coolant, hydraulic oil, lubricants, battery acids or batteries, and CARC paint, consult your unit/local hazardous waste disposal center or safety office for local regulatory guidance. If further information is needed, please contact The Army Environmental Hotline at 1-800-872-3845.

- 2. Ensure that all fluids drained as a result of lubrication or maintenance are collected in a suitable container and disposed of in accordance with local policy and ordinances. Clean up any spills immediately.
- 3. Keep all lubricants in a closed container and store in a clean, dry place away from extreme heat. Keep container covers clean and do not allow dust, dirt, or other foreign material to mix with lubricants. Keep all lubrication equipment clean and ready for use.
- 4. Maintain a good record of all lubrication performed and report any problem noted during lubrication. Refer to DA PAM 750-8 for maintenance forms and procedures to record and report any findings.

WARNING: Solvent cleaning compound MIL-PRF-680 Type III is an environmentally compliant and low toxic material. However, it may be irritating to the eyes and skin. Use protective gloves and goggles. Use in well-ventilated areas. Keep away from open flames and other sources of ignition. Failure to do so may result in injury or death to personnel.

- 5. Keep all external parts of equipment not requiring lubrication free of lubricants. Before lubrication, wipe lubrication fittings with a clean rag (Item 16, Appendix C) and solvent cleaning compound (Item 17, Appendix C). After lubrication, wipe off excess oil or grease to prevent accumulation of foreign matter.
- 6. Refer to FM 9-207 for lubrication instructions in cold weather.
- 7. Engine, transmission, and hydraulic system oil filters shall be changed when:
 - a. they are known to be contaminated or clogged;
 - b. at prescribed hardtime intervals.
- 8. For equipment under manufacturer's warranty, hardtime oil service intervals shall be followed. Intervals shall be shortened if lubricants are known to be contaminated or if operation is under adverse conditions (e.g., longer-than-usual operating hours, extended idling periods, or extreme dust).

ORGANIZATIONAL PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) INTRODUCTION - CONT

(Sheet 3 of 9)

GENERAL PMCS PROCEDURES

- 1. Always perform PMCS in the same order so it gets to be a habit. Once you've had some practice, you'll spot anything wrong in a hurry. If any deficiency is discovered, perform the appropriate troubleshooting task in Section IV of Chapter 2 of this manual. If any component or system is not serviceable, or if the given service does not correct the deficiency, notify your supervisor.
- 2. Before performing preventive maintenance, read all the checks required for the applicable interval and prepare all tools needed to make all checks. Have several clean rags (Item 16, Appendix C) handy. Perform ALL inspections at the applicable interval.
 - a. **Keep It Clean.** Dirt, grease, oil, and debris get in the way and may cover up a serious problem. Clean as you work and as needed. Use detergent (Item 18, Appendix C) and water when you clean.
 - b. **Rust and Corrosion.** Check metal parts for rust and corrosion. If any bare metal or corrosion exists, clean and apply a light coat of lubricating oil (Item 8, Appendix C). Report it to your supervisor.
 - c. **Bolts, Nuts, and Screws.** Check bolts, nuts, and screws for obvious looseness, missing, bent or broken condition. Look for chipped paint, bare metal, or rust around bolt heads. If you find one you think is loose, tighten it.
 - d. Welds. Look for loose or chipped paint, rust, or gaps where parts are welded together. If you find a bad weld, report it to your supervisor.
 - e. **Electric Wires and Connectors.** Look for cracked or broken insulation, bare wires, and loose or broken connectors. Tighten loose connectors and ensure that the wires are in good condition.
 - f. **Fluid Hoses and Lines.** Look for wear, damage, and signs of leaks. Ensure that clamps and fittings are tight. Wet spots indicate leaks, but a stain around a fitting or connector can also mean a leak. If a leak comes from a loose fitting or connector, tighten it. If something is broken or worn out, correct it if authorized by the Maintenance Allocation Chart (Appendix B). If not authorized, notify your supervisor.
 - g. **Fluid Leakage.** It is necessary for you to know how fluid leakage affects the status of your machine. The following are definitions of the types/classes of leakage you need to know to be able to determine the status of your machine. Learn and be familiar with them, and remember when in doubt, notify your supervisor.—

Leakage Definitions for Organizational PMCS

Class I Seepage of fluid (as indicated by wetness or discoloration) not great enough to form drops.

Class II Leakage of fluid great enough to form drops, but not enough to cause drops to drip from

item being checked/inspected.

Class III Leakage of fluid great enough to form drops that fall from item being checked/inspected.

CAUTION: Operation is allowable with Class I and Class II leakage. WHEN IN DOUBT, NOTIFY YOUR SUPERVISOR. When operating with Class I or Class II leaks, check fluid levels more frequently. Class III leaks must be reported immediately to your supervisor. Failure to do this will result in damage to machine and/or components.

Go to Page 4

ORGANIZATIONAL PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) INTRODUCTION - CONT

(Sheet 4 of 9)

PMCS INITIAL SETUP

1. **General.** This paragraph lists tools, materials, and personnel required for PMCS and lubrication.

2. Tools (Appendix B).

- a. General mechanic's tool kit
- b. Common no. 1 shop set
- c. Supplemental no. 1 shop set
- d. Drain tool, hydraulic tank (pipe nipple, P/N 6B3156)

3. Materials (Appendix C).

- a. Antifreeze
- b. Cleaning compound, solvent, Type III
- c. Coating compound
- d. Detergent, general purpose
- e. Distilled-deionized water
- f. Grease, GAA
- g. Lubricating oil, OE/HDO-10
- h. Lubricating oil, OE/HDO-10/30
- i. Lubricating oil, OE/HDO-15/40
- j. Lubricating oil, OE, HDO-30
- k. Lubricating oil, OEA
- l. Lubricating oil, GO 80/90
- m. Lubricating oil, GO 75
- n. Rag, wiping
- o. Sodium bicarbonate, technical

4. Personnel.

- a. Driver/Operator
- b. Organizational Maintenance Mechanic

ORGANIZATIONAL PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) INTRODUCTION - CONT (S

(Sheet 5 of 9)

- **KEY** -

		EXPEC.	TED TEMPERATU	JRES*	
LUBRICANT/ COMPONENT	REFILL CAPACITY	+6°F to +122°F (-14°C to +50°C)	-4°F to +50°F (-20°C to +10°C)	-25°F to +32°F (-4°C to 0°C)	INTERVALS
OE/HDO Lubricating Oil, ICE, Tactical			1	1	H - Hours S - Semiannual
OEA Lubricating Oil, ICE, Arctic					A - Annual B - Biennial
Engine Crankcase	11 Gal. (41.6 L)		See Chart A		T - Triennial
Transmission	24 Gal. (90.8 L)		See Chart B		
Hydraulic System	130 Gal. (492.1 L)		See Chart C		-
GO Lubricating Oil, Gear, Multipur- pose					
Front and Rear Differentials and Final Drives	27 Gal. (102.2 L) Each		See Chart D		
GAA Grease, Automotive and Artillery	As Required		All Temperatures		
Upper (Transmission) Drive Shaft					-
Lower Drive Shaft					
Drive Shaft Support Bearing					
Frame Pivot Bearings					
ANTIFREEZE Ethylene Glycol, Inhibited, Heavy- Duty					
Engine Radiator	28 Gal. (106 L) System Capacity		All Temperatures		
* For arctic operation, refer to FM 9	D-207.	<u> </u>			

(Sheet 6 of 9)

Table 1. CHART A—ENGINE CRANKCASE

						EXPECTED TEMPERATURES														
	°F	-70	-60	-50	-40	-30	-20	-10	0	+10	+20	+30	+40	+50	+60	+70	+80	+90	+100	+120
Lubricant	°C	-57	-51	-46	-40	-34	-29	-23	-18	-12	-7	-1	+4	+10	+16	+21	+27	+32	+38	+49
OE/HDO		ricati tical	ng O	il, IC	Ε,															
OEA		Lubricating Oil, ICE, Arctic																		
OE/HDO 10W/30									_											
OE/HDO 15W/40																				
OEA			-																	

Table 2. CHART B—TRANSMISSION

						E	ΧP	ECT	ΓED	TE	MF	PER	ΑT	UR	ES					
	°F	-70	-60	-50	-40	-30	-20	-10	0	+10	+20	+30	+40	+50	+60	+70	+80	+90	+100	+120
Lubricant	°C	-57	-51	-46	-40	-34	-29	-23	-18	-12	-7	-1	+4	+10	+16	+21	+27	+32	+38	+49
OE/HDO		oricat tical	ing O	il, IC	Ε,															
OEA		Lubricating Oil, ICE, Arctic																		
OE/HDO 30																				
OE/HDO 10*																				
OEA *			_																	
*If OEA lubricant is required to meet the low expected-temperature range, OEA lubricant is to be used in lieu of OE/HDO 10 lubricant for all expected temperatures where OE/HDO 10 is specified																				

(Sheet 7 of 9)


Table 3. CHART C—HYDRAULIC SYSTEM

		EXPECTED TEMPERATURES																		
	°F	-70	-60	-50	-40	-30	-20	-10	0	+10	+20	+30	+40	+50	+60	+70	+80	+90	+100	+120
Lubricant	°C	-57	-51	-46	-40	-34	-29	-23	-18	-12	-7	-1	+4	+10	+16	+21	+27	+32	+38	+49
OE/HDO Lubricating Oil, ICE, Tactical																				
OEA		Lubricating Oil, ICE, Arctic																		
OE/HDO 30														_						
OE/HDO 10								_												
OEA *			_																	
*If OEA lubricant is required to meet the low expected-temperature range, OEA lubricant is to be used in lieu of OE/HDO 10 lubricant for all expected temperatures where OE/HDO 10 is specified.																				

Table 4. CHART D—FRONT AND REAR DIFFERENTIALS AND FINAL DRIVES

Tability Company		90 +100 +120
C 37 31 40 40 34 23 23 10 12 7 1 14 110 110 121 121 132 1	nt	
GO Lubricating Oil, Gear	C -57 -51 -40 -40 -34 -29 -25 -16 -12 -7 -1 +4 +10 +16 +21 +	32 +38 +49
	Lubricating Oil, Gear	
GO 80/90 GO 75		

ORGANIZATIONAL PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) INTRODUCTION - CONT (Sheet 8 of 9)



ORGANIZATIONAL PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) INTRODUCTION - CONT (Sheet 9 of 9)

Lubricant Lubricant Interval Interval Transmission OE/ 1000 1000 Transmission Breather Oil Dipstick HDO Replace or or and Fill Semiannual Semiannual Transmission 1000 250 OE/ Engine OII HDO Drain Dipstick and or or Semiannual Semiannual Fill Transmission 1000 9999 Magnetic Screen or Clean Semiannual Upper(Transmission) GAA 250 Engine Oil Filters 1000 Drive Shaft or or Replace **DETAIL A** Universal Joints Semiannual Semiannual Lubricate Fittings (2 Places) 500 Transmission Oil Filter Semiannual Replace 500 Brake Hydraulic System Primary Fuel Filter Oil Filter Clean Semiannual Replace

End

This Page Intentionally Left Blank.

(Sheet 1 of 30)

NOT FULLY MISSION CAPABLE IF:				LOCATION		
Review all WARNINGS, CAUTIONS, and NOTEs before performing Organizational PMCS on the RTCH. Ualless otherwise indicated, perform PMCS with machine parked on level ground, parking brake applied, transmission in N (Neutral), container handler forks lowered to the ground, engine shut down, and wheels blocked. Perform Operator PMCS prior to or in conjunction with Organizational PMCS if: a. There is a delay between daily operation of the machine and Organizational PMCS. b. The regular operator is not assisting. If leakage is detected during performance of PMCS, further investigation is required to determine location and cause of leak. a. Inspect fan drive belts and alternator belt for worn, frayed, or cracked condition. Replace belts if worn, frayed, or cracked. (See pages 2-229 and 2-252.) b. Check belt tension. Adjust belt tension to 9/16-13/16 in. (1.4-2.0 cm) deflection, with 25 lb (11.5 kg) pressure on belt midway between pulleys. (See pages 2-229 and 2-252.)		INTERVAL	MAN-HOURS	CHECK/	PROCEDURE	
Go on to Sheet 2	1			Engine V-Belts	 Review all WARNINGS, CAUTIONS, and NOTI RTCH. Unless otherwise indicated, perform PMCS with matransmission in N (Neutral), container handler forks blocked. Perform Operator PMCS prior to or in conjunction a. There is a delay between daily operation of the b. The regular operator is not assisting. If leakage is detected during performance of PMCS tion and cause of leak. a. Inspect fan drive belts and alternator belt for worn, frayed, or cracked condition. Replace belts if worn, frayed, or cracked. (See pages 2-229 and 2-252.) b. Check belt tension. Adjust belt tension to 9/16-13/16 in. (1.4-2.0 cm) deflection, with 25 lb (11.5 kg) pressure on belt midway between pulleys. 	Es before performing Organizational PMCS on the achine parked on level ground, parking brake applied, s lowered to the ground, engine shut down, and wheels with Organizational PMCS if: machine and Organizational PMCS.

(Sheet 2 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
	250 Hours or Semiannual	MAN-HOURS 1.0 Hours	SERVICE Engine Oil and Filters	NO	CAPABLE IF: DTE ucity is 11 gal. (41.6 L).
					Go on to Sheet 3

(Sheet 3 of 30)

			LOCATION ITEM TO		
ITEM NO.	INTERVAL	MAN-HOURS	CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
3	250 Hours or Semiannual		Fuel System	DO NOT perform fuel system checks, inspections.	NING or maintenance while smoking or near fire, flames, or
				sparks. Fuel may ignite, causing injury or death to	personnel or damage to machine.
				Personnel must wear fuel-resistant gloves when exposed skin and change fuel-soaked clothing.	handling fuels. If exposed to fuel, promptly wash
				With engine at low idle, check for fuel system leaks and damage to the following components:	Any fuel leaks are evident.
				a. Fuel lines. Replace as needed. (See page 2-173.)	
				b. Fuel injection lines. (See page 2-170.)	
				c. Fuel transfer pump. Replace if necessary. (See page 2-177.)	
				d. Fuel priming pump. Replace if necessary. (See page 2-179.)	
4	250 Hours or Semiannual		Turbocharger	a. Inspect turbocharger air lines (seal and gaskets) for leaks. If leaks and damage are evident, notify Direct Support Maintenance.	
				b. Inspect turbocharger oil lines for leaks. If leaks and damage are evident, notify Direct Support Maintenance.	Class III oil leaks are evident.
					Go on to Sheet 4

(Sheet 4 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
5	250 Hours or Semiannual		Ether Starting Aid	Ether fuel is extremely flammable and toxic. DO No ventilated area away from heat, open flames, or spar skin and eyes and avoid breathing ether fumes. If immediately with large quantities of clean water for ately if ether is inhaled or causes eye irritation. Failur death to personnel.	OT smoke and make sure you are in a well-rks. Wear eye protection. Avoid contact with fluid enters or fumes irritate the eyes, wash 15 minutes. Seek medical attention immedi-
				Replace ether canister as needed. Inspect ether lines and fittings. Replace as necessary. (See page 2-189.)	
6	250 Hours or Semiannual		Engine Air Cleaner	 • If NBC exposure is suspected, personnel wearing protect Consult your NBC Officer or NBC NCO for appropriat • NBC contaminated filters must be handled using adequate personnel. • For more information, refer to: FM 3-3, Chemical and NBC Decontamination; FM 3-7, NBC Field Handbook ance. • Primary air cleaner element must be replaced after six of cleaned six times. • Secondary element must be replaced after cleaning or PLUGGED FILTER indicator remains on after cleaning Clean primary air cleaner element. Replace secondary air cleaner element if necessary. (See page 2-198.) 	ctive equipment must handle all air cleaner media. te handling or disposal procedures. tate precautions and must be disposed of by trained and Biological Contamination Avoidance; FM 3-5, ok; and FM 3-3-1, Nuclear Contamination Avoid- Eleanings, or once each year, even if it has not been replacing primary element for the 3rd time, or if

(Sheet 5 of 30)


			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
7	250 Hours or Semiannual		Exhaust System		the touch, unless engine has been allowed to st burns. Failure to follow this warning may
				a. With engine cool, inspect muffler for evidence of leaks and damage. Replace if necessary. (See page 2-211.)	
				b. Inspect exhaust pipe for evidence of leaks and damage. Replace if necessary. (See page 2-211.)	
				c. Inspect for loose, missing, or damaged exhaust manifold taperlock studs. Notify Direct Support Maintenance if any of these conditions exist.	
8	250 Hours or		Cooling Sys-	WAR	NING
	Semiannual		tem		the touch, unless engine has been allowed to st burns. Failure to follow this warning may
				a. Inspect radiator hoses and coolant lines for leaks and damage. Replace as necessary. (See page 2-247.)	Class III coolant leaks are evident.
				b. Inspect water pump for leaks and proper functioning. Replace if necessary. (See page 2-225.)	Class III coolant leaks are evident.
					Go on to Sheet 6

(Sheet 6 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
9	250 Hours or		Batteries	 To avoid injury, eye protection and acid-resistant gloves must be worn when working arour DO NOT smoke, use open flame, make sparks or create other ignition sources around batteri tery is giving off gases, it can explode and cause injury to personnel. Remove all jewelry such tags, watches, and bracelets. If jewelry or a tool contacts a battery terminal, a direct short winstant heating or electric shock, damage to equipment, and injury to personnel. Sulfuric acid contained in batteries can cause serious burns. If battery corrosion or electrolyte tact with skin, eyes or clothing, take immediate action to stop the corrosive burning effects. Falous these procedures may result in injury or death to personnel. 	
	Semiannual				
				 low these procedures may result in injury or death DO NOT use compressed air to clean batteries. Us 	•
				Perform complete battery service. (See page 2-272.)	1
10	250 Hours or Semiannual		Transmission	a. Inspect transmission oil lines for leaks and damage. If leaks or damage are noted, notify Direct Support Maintenance.	Class III oil leaks are evident.
				b. Inspect transmission control linkage for damage. Replace if necessary. (See page 2-407).	
				c. Adjust linkage if necessary. (See page 2-407.)	
					Go on to Sheet 7

(Sheet 7 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
11	250 Hours or Semiannual	0.2 Hours	Rear Differen-	Check oil level at level plugs (1) of front and rear differentials. Oil must be level with bottom of plug opening. Add gear lubricating oil (Item 5 or 6, Appendix C) as necessary. (See page 2-392.)	




Go on to Sheet 8

422-0048

(Sheet 8 of 30)

ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
12	250 Hours or Semiannual	0.4 Hours	Front and Rear Final Drives	To ensure an accurate reading, fill plug must be tion), as shown. Check oil level at fill plug (2), at each end of front and rear axles. Oil must be level with bottom of fill plug opening. Add gear lubricating oil (Item 5 or 6, Appendix C) as necessary. (See page 2-392.)	horizontal to axle (3 o'clock or 9 o'clock posi-



Go on to Sheet 9

(Sheet 9 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
13	250 Hours or Semiannual		Service Brakes	a. Test service brakes for proper functioning. (See Operator PMCS in TM 10-3930-641-10.)	
				WAR	NING
				Brake system is under hydraulic pressure. Pressure machine on level ground. Apply parking brake a times until no pressure remains. Failure to reliev to personnel.	
				b. Park machine on level ground, with parking brake applied, transmission in N (Neutral), container handler forks lowered to the ground, engine shut down, and wheels blocked. Relieve brake system hydraulic pressure as follows: Pump brake pedal several times until no pressure remains.	
				c. Inspect brake control valve, accumulator, transmission neutralizer valve, brake lines, and hoses for leaks and damage. If leaks or damage are evident, notify Direct Support Maintenance.	Class III oil leaks are evident.
				d. Adjust service brake pedal and control linkage as required. (See pages 2-369 and 2-366.)	
					Go on to Sheet 10

(Sheet 10 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
14	250 Hours or Semiannual		Parking Brakes	a. Test parking brake and indicator light for proper functioning. (See Operator PMCS in TM 10-3930-641-10.)	
				WAR	NING
				machine on level ground. Apply parking brake a	ure must be relieved before loosening lines. Stop and shut down engine. Pump brake pedal several e pressure as indicated may cause injury or death
				b. Park machine on level ground, with parking brake applied, transmission in N (Neutral), container handler forks lowered to the ground, engine shut down, and wheels blocked. Relieve brake system hydraulic pressure by pumping brake pedal several times until no pressure remains.	
				c. Inspect parking brake control valve and brake lines for leaks and damage. If leaks or damage are evident, notify Direct Support Maintenance.	Class III oil leaks are evident.
				d. Adjust parking brake linkage as required. (See page 2-358.)	
					Go on to Sheet 11

(Sheet 11 of 30)

ITEM NO.	INTERVAL	MAN-HOURS	LOCATION ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:		
				WARNING			
				Improper or misuse of inflation equipment can reinflation equipment properly could cause injury			
15	250 Hours or Semiannual		Tires	Gage all tires for correct inflation pressure and add air as required. (See page 2-397.)			
				Front: 70 psi (480 kPa)			
				Rear: 40 psi (275 kPa)			
16	250 Hours or Semiannual		Steering System	a. Inspect steering control valve and right and left neutralizer valves for leaks and damage. (See page 1-24.) If leaks or damage are evident, notify Direct Support Maintenance.	Class III oil leaks are evident.		
				b. Inspect steering system hydraulic lines and cylinders for leaks and damage. If leaks or damage are evident, notify Direct Support Maintenance.			
				WAR	NING		
				Steering system is under hydraulic pressure. Pres tank filler cap. Stop machine on level ground. A steering wheel in both directions several times. Finjury or death to personnel.	apply parking brake and shut down engine. Turn		
				c. Perform steering system tests:			
				(1) Check for air and foreign material in hydraulic oil. (See page 2-417.)			
				(2) Test steering time. (See page 2-417.)			
				(3) Test steering slip. (See page 2-417.)			
					Go on to Sheet 12		

(Sheet 12 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
17	250 Hours or Semiannual		Mast Hydrau-	WAR	NING
	Semiannuai		lic Cylinders, Lines, and Fit- tings	Hydraulic system is under pressure. Pressure n system line. Stop machine on level ground. Appl hydraulic control levers through all positions. Fainjury or death to personnel.	
				a. Inspect lift cylinder and lift cylinder lines and fit- tings for leaks and damage. Ensure lines are properly supported and there is no evidence of rubbing or chafing. Notify Direct Support Main- tenance of any leaks or damage found.	Class III oil leaks are evident.
				b. Inspect tilt cylinders and tilt cylinder lines and fittings for leaks and damage. Ensure lines are properly supported and there is no evidence of rubbing or chafing. Notify Direct Support Maintenance of any leaks or damage found.	Class III oil leaks are evident.
				c. Inspect side tilt cylinder and side tilt cylinder lines and fittings for leaks and damage. Ensure lines are properly supported and there is no evidence of rubbing or chafing. Notify Direct Support Maintenance of any leaks or damage found.	Class III oil leaks are evident.
				d. Inspect side shift cylinder and side shift cylinder lines and fittings for leaks and damage. Ensure lines are properly supported and there is no evidence of rubbing or chafing. Notify Direct Support Maintenance of any leaks or damage found.	Class III oil leaks are evident.
					Go on to Sheet 13

(Sheet 13 of 30)

			LOCATION			
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MIS CAPABLE IF	
18	250 Hours or Semiannual		Hydraulic System Pumps and Valves	a. Inspect hydraulic pump for leaks and damage. Notify Direct Support Maintenance of any leaks or damage found.	Class III oil leaks are evident.	
				b. Inspect supplemental hydraulic pump for leaks and damage. Notify Direct Support Maintenance of any leaks or damage found.	Class III oil leaks are evident.	
				c. Inspect hydraulic control valve, accumulator charging valve, and relief valves for leaks and damage. Notify Direct Support Maintenance of any leaks or damage found.	Class III oil leaks are evident.	
19	250 Hours or Semiannual		Mast and Rollers	Inspect mast and rollers for wear and damage.		
20	250 Hours or Semiannual		Lift Chains	Inspect lift chains for wear and damage. If worn or damaged, or if tension on lift chains is not equal, notify Direct Support Maintenance.		
21	250 Hours or Semiannual		Tophandlers (20 Ft, 35 Ft, and 40 Ft)	Inspect tophandlers, tophandler cylinders, hoses, lines, and fittings for leaks and damage. Notify Direct Support Maintenance of any leaks or damage found.	Class III oil leaks are evident.	
22	500 Hours or Semiannual		Engine Supports	Inspect front and rear engine supports for cracks and other damage.		
						Go on to Sheet 14

(Sheet 14 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
23	500 Hours or		Fuel Tank	WARN	ling
	Semiannual			DO NOT perform fuel system checks, inspections, or sparks. Fuel may ignite, causing injury or death to perform the performance of the perform	
				 Personnel must wear fuel-resistant gloves when he exposed skin and change fuel-soaked clothing. 	nandling fuels. If exposed to fuel, promptly wash
				a. Remove, disassemble, clean, assemble, and install fuel tank filler cap and screen. (See page 2-195.)	
				b. Drain water and sediment from fuel tank. (See page 2-193.)	
24	500 Hours or Semiannual		Coolant Filter	Replace coolant filter. (See page 2-244.)	
25	500 Hours or Semiannual	0.3 Hours	Transmission Oil Filter	Replace transmission oil filter element. (See page 2-402.)	
26	500 Hours or	0.5 Hours	Hydraulic Sys-	WARN	IING
	Semiannual		tem and Brake Hydraulic Sys- tem Filters	Hydraulic system is under pressure. Pressure mu system line. Stop machine on level ground. Apply hydraulic control levers through all positions. Fai injury or death to personnel.	parking brake and shut down engine. Cycle all
				a. Replace two hydraulic tank filter elements. (See page 2-487.)	
				b. Replace brake hydraulic system filter element. (See page 2-490.)	
					Go on to Sheet 15

(Sheet 15 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
27	500 Hours or Semiannual	0.3 Hours	Steering Sys- tem Oil Filter Strainer	Remove, clean, and reinstall strainer. (See page 2-421.)	
28	500 Hours or Semiannual		Mast	Check tightness of mast mounting bolts. Proper torque is 1,000 lb-ft (1,356 Nm).	
29	500 Hours or Semiannual		Forks	Check mounting of forks.	
30	500 Hours or Semiannual		Tilt Cylinders	a. Test tilt cylinders for proper extension: Tilt mast as far as possible and watch that tilt cylinders stop at the same time. If they do not stop at the same time, notify Direct Support Maintenance.	
				b. Perform drift test of tilt cylinders. (See page 2-493.) If results are not within specification, notify Direct Support Maintenance.	
31	1,000 Hours or Semiannual		Engine Crank- case and Fumes Dis- posal Assem- bly Breathers	Clean breathers. (See page 2-158.)	
					Go on to Sheet 16


(Sheet 16 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
32	1,000 Hours or Semiannual	0.5 Hours	Transmission	Perform complete transmission service. (See page 2-402.)	
				a. Drain oil from transmission.	
				b. Clean magnetic strainer.	
				c. Replace transmission and torque converter breathers.	
				d. Replace oil filter element.	
				e. Refill transmission with lubricating oil (Item 7, 7.1, or 8, Appendix C) until level is between LOW and FULL marks on dipstick.	
					Go on to Sheet 17

2-21


(Sheet 17 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
33	1,000 Hours or Semiannual	0.2 Hours	Upper (Transmission) Drive Shaft Universal Joints	 a. Lower rear of front crankcase guard. (See page 2-483.) b. Inspect shaft and universal joints for wear and damage. Replace if necessary. (See page 2-377.) c. Lubricate two fittings with GAA grease (Item 3 or 4, Appendix C). 	




(Sheet 18 of 30)

ITEM NO.	INTERVAL	MAN-HOURS	LOCATION ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
34	1,000 Hours or Semiannual	0.1 Hours	Drive Shaft Support Bear- ing	a. Inspect bearing cage for leaks. (See page 2-380.)b. Lubricate one fitting on drive shaft support bearing with GAA grease (Item 3 or 4, Appendix C).	




(Sheet 19 of 30)

		1	LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
35	1,000 Hours or Semiannual		Frame Upper and Lower Pivot Bearings	Lubricate one fitting on each pivot with GAA grease (Item 3 or 4, Appendix C).	








(Sheet 20 of 30)

ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
36	1,000 Hours or Semiannual		Rollover Protective Structure (ROPS)	a. Remove covers (3) from both sides of ROPS (4).	
				 b. Tighten two 1-in. bolts (5) on each side to 640 ± 80 lb-ft (868 ± 108 Nm). c. Tighten eight 1-1/8-in. bolts (6) on each side to 800 ± 100 lb-ft (1085 ± 136 Nm). 	
				d. Reinstall covers (3) on both sides of ROPS (4).	




(Sheet 21 of 30)

			LOCATION		-
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
37	Semiannual		Fuel System	WARNING	
				 DO NOT perform fuel system checks, inspections or maintenance while smoking or near fire, flames sparks. Fuel may ignite, causing injury or death to personnel or damage to machine. 	
	Personnel must wear fuel-resistant gloves when handling fuels. If exposed exposed skin and change fuel-soaked clothing.			handling fuels. If exposed to fuel, promptly wash	
a. Clean primary fuel filter element. Inspect gasket and replace as necessary. (See page 2-183.)					
				NO	TE
				Secondary fuel filter must be replaced semiannua with engine running at high idle.	ally OR when fuel pressure gage is in RED zone
				b. Replace secondary fuel filter. (See page 2-186.)	
38	1,000 Hours or Annual		Exhaust System Dust Ejector	Remove and clean dust ejector. Inspect and replace any component of dust ejector that is damaged. (See page 2-198.)	
					Go on to Sheet 22

(Sheet 22 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
39	2,000 Hours or Annual		Vibration Damper Pulley	Inspect damper. Marks (7) on damper hub and ring should aline. If not, replace damper. (See page 2-155.)	




40	2,000 Hours or Annual	Engine Valve Lash	Notify Direct Support Maintenance to adjust engine valve lash.

(Sheet 23 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
NO. 41	2,000 Hours or Annual	1.0 Hours	Front and Rear Differentials and Final Drives		TE
					Go on to Sheet 24


(Sheet 24 of 30)

ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
42	2,000 Hours or Annual	0.5 Hours	Lower Drive Shaft	a. With rear of front crankcase guard lowered, inspect rear portion of drive shaft and universal joints for wear and damage. Replace if necessary. (See page 2-380.)	
				b. Lubricate two fittings on rear portion of drive shaft with GAA grease (Item 3 or 4, Appendix C).	




(Sheet 25 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
42 (CONT)	2,000 Hours or Annual	0.5 Hours	Lower Drive Shaft	c. Inspect center portion of drive shaft and universal joints for wear and damage. Replace if necessary. (See page 2-380.)	
				d. Lubricate two fittings on center portion of drive shaft with GAA grease (Item 3 or 4, Appendix C).	



(Sheet 26 of 30)

ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
42 (CONT)	2,000 Hours or Annual	0.5 Hours	Lower Drive Shaft	e. Inspect front portion of drive shaft and universal joints for wear and damage. Replace if necessary. (See page 2-380.)	
				f. Lubricate one fitting on front portion of drive shaft with GAA grease (Item 3 or 4, Appendix C). Lubricate second fitting on front drive shaft spline with GAA grease.	



(Sheet 27 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
43	2,000 Hours or	1.0 Hours	Hydraulic Sys-	WARI	NING
	Annual		tem	Hydraulic system is under pressure. Pressure m system line. Stop machine on level ground. Apply hydraulic control levers through all positions. Fainjury or death to personnel.	y parking brake and shut down engine. Cycle all
				a. Park machine on level ground, with parking brake applied, transmission in N (Neutral), container handler forks lowered to the ground, engine shut down, and wheels blocked. Relieve hydraulic system pressure by moving all hydraulic controls through all positions.	
				b. Unlock and raise floor plate.	
				c. Slowly remove filler cap. Inspect cap gasket and replace if damaged.	
				WARI	NING
				Solvent cleaning compound MIL-PRF-680 Typ- toxic material. However, it may be irritating to the gles. Use in well-ventilated areas. Keep away fi Failure to follow this warning may cause injury of	ne eyes and skin. Use protective gloves and gog- rom open flames and other sources of ignition.
				d. Remove retaining ring and filler screen from hydraulic tank. Wash screen in clean solvent cleaning compound (Item 17, Appendix C).	
					Go on to Sheet 28

(Sheet 28 of 30)

			LOCATION		
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
43 (CONT)	2,000 Hours or Annual	1.0 Hours	Hydraulic System	e. Install filler screen in hydraulic tank and secure with retaining ring.	
				f. Remove drain plug from underside of hydraulic tank. Clean drain plug in solvent cleaning compound.	
				NO	TE
				Hydraulic system capaci	ity is 130 gal. (492.1 L).
				g. Place a container under hydraulic tank drain opening.	
				h. Install drain tool (pipe nipple) in drain opening to open internal drain valve. Allow all oil to drain from hydraulic tank.	
				i. Remove drain tool and install drain plug.	
				j. Replace two hydraulic tank filter elements. (See page 2-487.)	
				k. Replace brake hydraulic system filter element. (See page 2-490.)	
				1. Perform panel test to ensure LOW HYD OIL indicator is functioning. (See Operator PMCS in TM 10-3930-641-10.)	
					Go on to Sheet 29

(Sheet 29 of 30)

			LOCATION			
ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:	
43 (CONT)	2,000 Hours or Annual	1.0 Hours	Hydraulic System	NOTE		
				Do not star	t engine.	
				m. Turn power switch to ON position. LOW HYD OIL indicator should come on.		
				n. With power switch still on, begin filling hydraulic tank with oil (Item 7, 7.1, or 8, Appendix C).		
				o. LOW HYD OIL indicator should turn off when oil level goes above ADD COLD mark in sight gage.		
				p. Turn power switch to OFF position.		
				q. Continue to add oil until level is at FULL COLD mark or completely fills sight gage.		
				r. Install filler cap.		
				s. Start engine, raise container handler forks, and tilt them back and forth several times. (See TM 10-3930-641-10.)		
				t. Lower container handler forks to the ground and apply parking brake. (See TM 10-3930-641-10.)		
				u. Oil must be free of bubbles. If bubbles are present, inspect suction lines hoses and clamps.		
				v. Shut down engine. (See TM 10-3930-641-10.)		
					Go on to Sheet 30	

(Sheet 30 of 30)

ITEM NO.	INTERVAL	MAN-HOURS	ITEM TO CHECK/ SERVICE	PROCEDURE	NOT FULLY MISSION CAPABLE IF:
43	2,000 Hours or	1.0 Hours	Hydraulic Sys-	w. Tighten clamps if loose and replace hoses if dam-	CAI ABLE II.
(CONT)	Annual	1.0 110018	tem	aged.	
44	2,000 Hours or Annual		Front and Rear Frames	Inspect front and rear frames for damage, misalinement, cracks, or broken welds. Notify Direct Support Maintenance of any problem found.	
45	4,000 Hours or	0.5 Hours	Cooling Sys-	WAR	NING
	Biennial		tem	 DO NOT service cooling system unless engine has been allowed to cool down. This is a pressurized cooling system and escaping steam or hot coolant will cause serious burns. DO NOT remove cooling system radiator cap when engine is hot. Allow engine to cool down. Loosen cap to first stop and let any pressure out of cooling system, then remove cap. Failure to follow this warning may cause serious burns. Wear effective eye, glove, and skin protection when handling coolants. Failure to follow this warning may cause injury to personnel. Change antifreeze solution in radiator and replace coolant filter. (See page 2-215.) 	
46	Triennial		Seat Belt	Replace seat belt that is more than three years old, as indicated on manufacturer's tag on belt.	End
					End

LOCATION/ITEM	ACTION	REMARKS
1. Starting cable	Be sure main disconnect switch and POWER switch are off and keys removed before you connect slave cable to your vehicle. Connect to emergency starting (slave) receptacle.	EMERGENCY STARTING (SLAVE) RECEPTACLE
2. Engine	Start.	See TM 10-3930-641-10.
	NOTE	
	To use the emergency starting receptacle, use jumper cable with a plug to mate with receptacle. Connect external stating source first, then insert plug into receptacle of vehicle to be started. After engine starts, remove plug from receptacle.	TA 098889 End


LOCATION/ITEM	ACTION	REMARKS
	Po manually release parking brake, do the following:	
1. Wheels	Block. This will keep the vehicle from rolling vhen parking brake is released.	
2. Shipping link (1) at bottom of articulated (steering) joint, left side of vehicle.	Connect to front and rear frames. (See page 2-27.)	3
3. Capscrews (2, 3, 4) on cover of parking/emergency brake. Parking brake is mounted on front of transmission housing.	Remove from storage holes in cover.	2 4
4. Capscrews	a. Install capscrews in forcing holes (5, 6, 7) in cover of emergency/parking brake.	
	b. Tighten until there is solid resistance.	5
	After repairs have been made and before operating the vehicle, disconnect shipping link (1), remove capscrews from forcing holes. Install capscrews in storage holes.	7 TA 098576 End

LOCATION/ITEM	ACTION	REMARKS
	Install shipping link between front and rear frames to keep vehicle in straight-ahead position when vehicle is being: a. Lifted. b. Transported. c. Serviced near its center.	Do not tow with shipping link installed.
INSTALLATION Shipping link	a. POSITION between frames.	
Storage Shipping link	b. SECURE with pins and cotter pins.a. REMOVE from frames.b. SECURE to retaining plates with pins.	
		TA 098577
	I	End

TOWING (Sheet 1 of 1)

WARNING

Never use a tow line. Always use a medium duty tow bar. (See MS500048.)



NOTE

Tow with engine running to control operable steering and brakes.


Do not tow vehicle faster than 5 MPH (8 km/hr) or farther than 10 miles (16 km).

- 1. Put tension on tow bar and check that couplings are attached properly.
- 2. You must be in the vehicle to steer it while it is being towed.
- 3. If you think there is an engine or transmission failure, tell direct support. They will have to remove the axle shafts and the transmission input drive shaft before towing.

WARNING

There is no emergency brake if all four axle shafts or front and rear drive shafts are removed.

- 4. Install capscrews in forcing holes (1, 2, 3). Tighten until there is solid resistance.
- 5. Reverse steering cylinder hoses on one cylinder only, so steering cylinders can move freely.
- 6. Inspect the vehicle for powertrain damage. If there is damage, remove all four axle shafts.



TA 098578

End

Section IV. TROUBLESHOOTING

The symptoms index for organizational maintenance starts on page 2-30. It lists the malfunctions (symptoms), tests or inspections and corrective actions that the organization can ordinarily perform. It also lists the malfunctions which have to be referred to higher maintenance levels.

The troubleshooting table starts on page 2-34. In an emergency where immediate corrective action must be taken to operate the vehicle, you may have to perform actions which are ordinarily beyond your responsibility.

Bear in mind that it is not possible to list all the malfunctions which might develop. If you have a problem that is not included in the table, notify your supervisor.

SYMPTOMS INDEX (Sheet 1 of 4)

NOTE

Before you begin troubleshooting, be sure you have performed all applicable operating checks.

	Troubleshooting Procedure Page
BRAKE SYSTEM	
Brakes are slow to stop vehicle	2-34
Brakes do not release	2-34
Brakes do not stop vehicle	2-34
Brakes release slowly	2-35
Emergency brake doesn't disengage	2-35
Emergency brake doesn't work	2-35
Transmission doesn't disengage when left brake pedal is pushed	2-35
ENGINE	
Alternator indicator light comes on - alternator is not charging	2-36
Alternator is noisy	2-36
Black orgraysmoke from exhaust	2-36
Coolant in lube oil	2-36
Engine cranks, but will not start or is hard to start	2-37
Engine does not develop full power	2-37

SYMPTOMS INDEX (CONT) (Sheet 2 of 4)

	Troubleshooting Procedure Page
ENGINE (CONT)	
Engine knocks	2-38
Engineoverheats	2-38
Engine misfires or runs rough	2-39
Engine stalls at lowRPM	2-39
Engine will not crank when ignition switch is in start position	2-39
Exhaust smoke is hot and thick	2-40
Low engine oil pressure	2-40
Oil in cooling system	2-40
Starting motor does not turn over	2-41
Sudden large increase in fuel use	2-41
Unusual engine vibrations	2-41
White or blue smoke from exhaust	2-42
HYDRAULIC SYSTEM	
"Bouncy" action or no movement of hydraulic system when trying to lift a load	2-42
Carriage will not lower correctly	2-42
Hydraulic system will not hold a load	2-42

SYMPTOMS INDEX (CONT) (Sheet 3 of 4)

	Troubleshooting Procedure Page
HYDRAULIC SYSTEM (CONT)	
Hydraulic system won't lift load	2-43
Lift or tilt do not hold position with hydraulic control levers in neutral	2-43
Mast tilts too slowly	. 2-43
Noisy hydraulic pump	. 2-43
Oil temperature too high-hydraulic oil temperature needle is in red area	. 2-44
TORQUE CONVERTER	
Torque converter overheats - needle of torque converter oil temperature gage is in red area	. 2-44
TRANSFER CASES ANDDRIVELINE COMPONENTS	
Final drive is locked	. 2-45
Front or rear differentials inoperative	. 2-45
Noisy transfer gears	. 2-45
System loses oil	. 2-45
TRANSMISSION	
Back-up warning alarm does not sound when transmission selection lever is put in reverse	. 2-46
Transmission doesn't work when speed selection lever is placedin any speed	. 2-46
Transmission oil indicator light comes on duringoperation	. 2-46

	Troubleshooting Procedure Page
TRANSMISSION (CONT)	
Transmission overheats - torque converter oil temperature gage is in red area	2-46
Transmission will not shift from one direction to another	2-47
Transmission will not shift from one speed to another	2-47
Transmission speed ranges engage very suddenly	2-47
Transmission shifts slowly	2-47
Warning alarm horn does not sound when transmission direction selection lever is moved from neutral while engine is running and parking brake is on	2-47
Transmission does network in any forward or reverse speeds	2-48
Vehicle moves when selection lever is in neutral	2-48
STEERING SYSTEM	
Steering wheel can still be tumed when vehicle is at full turn	2-48
Steering wheel is hard to turn	2-48
Vehicle doesn't turn when steering wheel is tumed	2-48
ELECTRICAL SYSTEM	2-49

TROUBLESHOOTING

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

BRAKE SYSTEM

1. BRAKES ARE SLOW TO STOP VEHICLE

- Step 1. Check brake pedal travel.

 Adjust pedal travel. (See page 2-369.)
- Step 2. Inspect for leaking lines or fittings. Tighten/replace.
- Step 3. Inspect lines for kinks.
 Straighten or replace.

BRAKES DO NOT RELEASE

Inspect brake control linkage for binding.

Replace/adjust. (See page 2-353.)

3. BRAKES DO NOT STOP VEHICLE

- Step 1. Inspect hydraulic reservoir fluid level.
 Add fluid. (See LO 10-3930-641-12.)
- Step 2. Inspect brake pedal travel.

 Adjust pedal travel. (See page 2-369.)
- Step 3. Inspect brake linkage.
 Adjust. (See page 2-366.)
- Step 4. Inspect brake lines for kinks. Straighten or replace.

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

BRAKE SYSTEM (CONT)

4. BRAKES RELEASE SLOWLY

Step 1. Inspect brake control linkage adjustment. Adjust linkage. (See page 2-366.)

Step 2. Check lines for restrictions, Clean lines.

5. EMERGENCY PARKING BRAKE DOESN'T DISENGAGE

Step 1. Inspect lines for restrictions. Clean lines.

Step 2. Inspect for loose fittings.

Tighten fittings.

Step 3. Inspect control valve linkage for proper adjustment. Adjust linkage. (See page 2-358.)

6. EMERGENCY PARKING BRAKE DOESN'T WORK

Inspect parking brake control valve linkage for adjustment or defective parts. Adjust/replace. (See page 2-358.)

7. TRANSMISSION DOES NOT DISENGAGE WHEN LEFT BRAKE PEDAL IS PUSHED

Inspect adjustment of brake control linkage. Adjust. (See page 2-366.)

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

ENGINE

- 1. ALTERNATOR INDICATOR LIGHT COMES ON ALTERNATOR IS NOT CHARGING
 - Step 1. Inspect drive belt.

 Adjust/replace. (See page 2-252.)
 - Step 2. Check battery connections. Clean/tighten. (See page 2-272.)
- 2. ALTERNATOR IS NOISY
 - Step 1. Inspect drive belt for damage or wear. Replace. (See page 2-252.)
 - Step 2. Inspect alternator drive pulley keyway.

 Replace drive pulley if keyway is worn and pulley is loose. (See page 2-252.)
 - Step 3. Check alinement of pulley and drive belt. Aline. (See page 2-252.)
- 3. BLACK OR GRAY SMOKE FROM EXHAUST

Inspect cleaner for obstructions. Service. (See page 2-198.)

4. COOLANT IN LUBE OIL
Inspect engine oil cooler.
Notify direct support.

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

ENGINE (CONT)

5. ENGINE CRANKS BUT WILL NOT START OR IS HARD TO START

Step 1. Inspect fuel level.

Add fuel. (See page 2-193.)

Step 2. Inspect fuel filters.

Clean/replace. (See pages 2-183 and 2-186.)

Step 3. Check for bad quality fuel. (Drain small amount and visually check for particles.)

Replace fuel. (See page 2-193.)

Replace fuel filter element. (See pages 2-183 and 2-186.)

Step 4. Check exhaust for white smoke.

Use ether as required.

Check ether system for proper operation.

6. ENGINE DOES NOT DEVELOP FULL POWER

Step 1. See if quality of fuel is bad. (Drain small amount and visually check for particles.)

Replace fuel. (See page 2-193.)

Replace fuel filter element. (See pages 2-183 and 2-186.)

Step 2. Inspect for restriction of air inlet filter.

Replace air filter elements. (See page 2-198.)

Step 3. Inspect for low fuel pressure.

Check fuel filters - clean/replace. (See pages 2-183 and 2-186.)

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

ENGINE (CONT)

7. ENGINE KNOCKS

See if fuel quality is bad. (Drain small amount and check for particles.)

Replace fuel. (See page 2-193.)

Replace fuel filter elements. (See pages 2-183 and 2-186.)

8. ENGINE OVERHEATS

- Step 1. Check coolant level. Coolant level should be within 1/2" of bottom of fill pipe. Add coolant. (See page 2-215.)
- Step 2. Inspect radiator core for debris. Clean radiator core.
- Step 3. Inspect engine oil level.

 Add oil to specified level. (See page 2-152.)
- Step 4. Inspect radiator pressure cap for defects. Replace cap.
- Step 5. Inspect transmission oil level.

 Add oil if necessary. (See page 2-402.)
- Step 6. Determine if the vehicle is being continuously overloaded.

 Direct operator not to exceed rated load capacity.

NOTE

RTCH is rated to carry 50,000 lb. load. Do not exceed capacity.

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

ENGINE (CONT)

9. ENGINE MISFIRES OR RUNS ROUGH

- Step 1. Inspect fuel level.

 Add fuel. (See page 2-193.)
- Step 2. Check exhaust for white smoke. Use ether as required.
- Step 3. Inspect fuel lines between fuel tank and fuel transfer pump for crimps, leaks, and bends. Replace fuel lines. (See page 2-173.)
- Step 4. Check fuel pressure.

 Replace fuel filter (secondary). (See page 2-186.)

 Clean primary fuel filter. (See page 2-183.)

10. ENGINE STALLS AT LOW RPM

Inspect fuel lines between fuel tank and fuel transfer pump for crimps, leaks, and bends. Replace fuel lines. (See page 2-173.)

11. ENGINE WILL NOT CRANK WHEN IGNITION SWITCH IS IN START POSITION

- Step 1. Inspect main disconnect switch.

 Turn to ON position. (See TM 10-3930-641-10.)
- Step 2. Inspect batteries.

 Charge/replace. (See page 2-277.)
- Step 3. Inspect starting motor for damage. Replace. (See page 2-258.)

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

ENGINE (CONT)

12. EXHAUST SMOKE IS HOT AND THICK

Step 1. Check for restrictions in exhaust system. Remove restrictions.

Step 2. Inspect air filter elements. Replace. (See page 2-198.)

13. LOW ENGINE OIL PRESSURE

Step 1. Check oil level.

Add oil if necessary. (See page 2-152.)

Step 2. Inspect engine oil filter elements. Replace. (See page 2-152.)

Step 3. Inspect engine oil cooler.
Notify direct support.

14. OIL IN COOLING SYSTEM

Step 1. Inspect engine oil cooler for defects. Notify direct support.

Step 2. Inspect transmission oil cooler for defects. Notify direct support.

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

ENGINE (CONT)

15. STARTING MOTOR DOES NOT TURN OVER

- Step 1. Inspect batteries.

 Recharge/replace. (See page 2-277.)
- Step 2. Inspect battery connections. Clean and tighten.
- Step 3. Check electrical starting circuit. (See page 2-74.)
- Step 4. Test solenoid.

 Replace. (See page 2-261.)
- Step 5. Inspect starting motor.

 Replace. (See page 2-258.)

16. SUDDEN LARGE INCREASE IN FUEL USE

Inspect fuel lines and fittings for leaks.

Replace. (See page 2-173.)

17. UNUSUAL ENGINE VIBRATIONS

- Step 1. Test fan assembly for fan blade out of balance.
 - Remove fan belts (see page 2-229) and operate engine at speed that had vibration. If there is no vibration, replace fan assembly. (See page 2-236.)
- Step 2. Check fan drive pulley for loose capscrews. Tighten capscrevw. (See page 2-155.)

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

ENGINE (CONT)

18. WHITE OR BLUE SMOKE FROM EXHAUST

Step 1. Inspect for engine oil past specified level.

Drain engine oil to specified level.

Step 2. Excessive oil consumption caused by engine running rough or misfiring.

Inspect air cleaner for obstructions.

Service. (See page 2-198.)

HYDRAULIC SYSTEM

1. BOUNCY ACTION OR NO MOVEMENT OF HYDRAULIC SYSTEM WHEN TRYING TO LIFT A LOAD

Test for air in hydraulic system.

Bleed air from system by using bleed screw at top of lift cylinder. (See page 2-496.)

2. CARRIAGE WILL NOT LOWER CORRECTLY

- Step 1. Inspect mast sliding blocks, rollers, and chains for correct lubrication. Lubricate components as necessary. (See LO 10-3930-641-12.)
- Step 2. Inspect lift line for restrictions. Clean/replace.
- Step 3. Check control linkage for proper adjustment. (See page 2-497.)

3. HYDRAULIC SYSTEM WILL NOT HOLD A LOAD

Inspect lines and fittings for leaks. Tighten.

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

HYDRAULIC SYSTEM (CONT)

4. HYDRAULIC SYSTEM WILL NOT LIFT LOAD

- Step 1. Inspect lines and fittings for leaks. Replace/tighten.
- Step 2. Inspect mast sliding blocks, rollers, and chains for correct lubrication. Lubricate components as necessary. (See LO 10-3930-641-12.)
- Step 3. Check control linkage for proper adjustment. (See page 2-502.)

5. LIFT OR TILT CYLINDERS DO NOT HOLD POSITION WITH HYDRAULIC CONTROL LEVERS IN NEUTRAL CONDITION

Inspect lines and fittings for leaks. Tighten.

6. MAST TILTS TOO SLOWLY

- Step 1. Inspect tilt cylinder packing nut for tightness.

 Loosen nut.
- Step 2. Check control linkage for proper adjustment. (See page 2-497.)

7. NOISY HYDRAULIC PUMP

Step 1. Inspect oil level.

Add oil. (See LO 10-3930-641-12.)

Step 2. Inspect filter for dirt.

Replace filter. (See page 2-487.)

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

HYDRAULIC SYSTEM (CONT)

8. OIL TEMPERATURE TOO HIGH - HYDRAULIC OIL TEMPERATURE NEEDLE IS IN RED AREA

Step 1. Inspect oil level.

Add oil. (See LO 10-3930-641-12.)

- Step 2. Inspect hydraulic oil cooler core for debris.
 Clean core.
- Step 3. Inspect oil lines for restrictions.

 Clean oil lines.
- Step 4. Decide if system has been continuously overloaded.

NOTE

RTCH is rated to carry 50,000 lb. loads. Do not exceed capacity.

TORQUE CONVERTER

TORQUE CONVERTER OVERHEATS - NEEDLE OF TORQUE CONVERTER OIL TEMPERATURE GAGE IS IN RED AREA

Step 1. Check transmission oil level.

Add oil. (See LO 10-3930-641-12.)

Step 2. Check coolant level in engine radiator.

Fill to 1/2" below bottom of fill pipe. (See page 2-214.)

Step 3. See if vehicle has been operated continuously at overload capacity.

NOTE

RTCH has rated load capacity of 50,000 lb. Tell operator not to exceed rated load capacity.

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

TRANSFER CASES AND DRIVE LINE COMPONENTS

1. FINAL DRIVE IS LOCKED

Inspect oil levels.

Add oil. (See LO 10-3930-641-12.) Replace breather if plugged. (See page 2-392.)

2. FRONT OR REAR DIFFERENTIALS IN OPERATIVE

Inspect oil levels.

Add oil. (See LO 10-3930-641-12.) Replace breather if plugged. (See page 2-392.)

3. NOISY TRANSFER GEARS

Step 1. Check transmission oil.

Add oil. (See LO 10-3930-641-12.)

Step 2. Inspect main drive shaft universal points.

Tighten capscrews. (See page 2-377.)

4. SYSTEM LOSES OIL

Step 1. Check drain plug.
Tighten/replace.

Step 2. Inspect all lines and fittings. Tighten/replace.

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

TRANSMISSION

- 1. BACKUP WARNING ALARM DOES NOT SOUND WHEN TRANSMISSION SELECTION LEVER IS PUT IN REVERSE.
 - Step 1. Inspect direction control linkage for defects or incorrect adjustment.

Replace defective parts. (See page 2-412.) Adjust linkage. (See page 2-407.)

- Step 2. Test warning switch. (See page 2-334.) Replace.
- Step 3. Test backup warning alarm. (See page 2-334.) Replace.
- 2. TRANSMISSION DOESN'T WORK WHEN SPEED SELECTION LEVER IS PLACED IN ANY SPEED.
 - Step 1. Inspect transmission oil level.
 Add oil. (See LO 10-3930-641-12.)
 - Step 2. Inspect speed control linkage for incorrect adjustment and broken or defective parts. Replace broken or defective parts. (See page 2-412.)

 Adjust linkage. (See page 2-407.)
- 3. TRANSMISSION OIL INDICATOR LIGHT COMES ON DURING OPERATION
 - Step 1. Inspect oil filter.

Replace oil filter element. (See page 2-402.)

- Step 2. Check transmission oil. (See page 2-402.)
- 4. TRANSMISSION OVERHEATS TORQUE CONVERTER OIL TEMPERATURE GAGE NEEDLE IS IN RED AREA.
 - Step 1. Inspect transmission oil level.

Add oil. (See LO 10-3930-641-12.)

Step 2. Inspect magnetic strainer in output transfer gear case. Clean. (See page 2-403.)

TROUBLESHOOTING (CONT)

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

TRANSMISSION (CONT)

5. TRANSMISSION WILL NOT SHIFT FROM ONE DIRECTION TO ANOTHER

Inspect direction control linkage for incorrect adjustment and broken or defective. parts. Replace defective parts. (See page 2-412.)

Adjust linkage. (See page 2-407.)

6. TRANSMISSION WILL NOT SHIFT FROM ONE SPEED TO ANOTHER

Inspect speed control linkage for incorrect adjustment and broken or defective parts. Replace broken or defective parts. (See page 2-412.)

Adjust linkage. (See page 2-407.)

7. TRANSMISSION SHIFTS ROUGHLY - SPEED RANGES ENGAGE VERY SUDDENLY

Inspect adjustment of control linkages.

Adjust. (See page 2-407.)

8. TRANSMISSION SHIFTS SLOWLY

Inspection transmission oil level.

Add oil. (See LO 10-3930-641-12.)

- 9. WARNING ALARM DOES NOT SOUND WHEN TRANSMISSION DIRECTION SELECTION LEVER IS MOVED FROM NEUTRAL WHILE ENGINE IS RUNNING AND PARKING BRAKE IS ON
 - Step 1. Inspect direction control linkage for incorrect adjustment or defects.

Adjust linkage. (See page 2-407.)

Replace defective parts. (See page 2-412.)

Step 2. Test warning switch. (See page 2-334.)

Replace warning switch.

Step 3. Test backup warning alarm. (See page 2-334.) Replace alarm.

TROUBLESHOOTING (CONT)

MALFUNCTION

TEST OR INSPECTION CORRECTIVE ACTION

TRANSMISSION (CONT)

10. TRANSMISSION DOES NOT WORK IN ANY FORWARD SPEED OR ANY REVERSE SPEED

Step 1. Inspect adjustmerit of direction control linkage. Adjust. (see page 2-407.)

Step 2. Inspect oil pump.

Replace. Notify Direct Support.

11. VEHICLE MOVES WHEN SELECTION LEVER IS IN NEUTRAL

Inspect direction control linkage for correct adjustment or damaged parts. Replace damaged parts. (See page 2-412.)

Adjust linkage. (See page 2-407.)

STEERING SYSTEM

1. STEERING WHEEL CAN STILL BE TURNED WHEN VEHICLE IS AT FULL TURN

Inspect adjustment of striker assembly for neutralizer valve.

Notify direct support.

2. STEERING WHEEL IS HARD TO TURN

- Step 1. Allow hydraulic oil to warm up to normal operating temperatures.
- Step 2. Inspect lines of hand metering unit for restrictions.

Clean/replace lines.

3. VEHICLE DOESN'T TURN WHEN STEERING WHEEL IS TURNED

Step 1. Check shipping link.

Disconnect shipping link. (See page 2-27.)

Step 2. Inspect hydraulic oil reservoir.

Add oil. (See LO 10-3930-641-12.)

Step 3. Check steering lines for restriction.

Clean lines.

Step 4. Inspect steering pump for damage.

Notify Direct Support.

ELECTRICAL SYSTEM TROUBLESHOOTING

GENERAL

This section contains troubleshooting information for isolating most electrical problems to an individual circuit and in most cases to an individual component. Replacement of the component is, in most cases, referenced to another section unless only basic knowledge is required to perform the task.


This manual cannot cover all possible problems, however, the most likely to occur ue mentioned. In general, a switch or sending unit is more likely to be defective than a gage or indicator. The least likely cause of a problem would be in the wires or harnesses.

TROUBLESHOOTING


To use the QUICK GUIDE (pages 2-71 through 2-73): determine which system, engine, alternator, etc., the PROBLEM occurs in, then go down list of PROBLEMS until problem is found. Refer to page under REFERENCE column. Read QUESTION for each STEP. If answer to QUESTION is YES, go to STEP number shown under YES; if answer is NO, go to STEP number shown under NO.

GENERAL


All needed electrical testing can be done using a multimeter. This section shows how to use a multimeter for finding the causes of electrical problems which may develop in the vehicle. The TS-352 B/U, the AN/URM-105, and the Simpson 160 are the models you can get in organizational maintenance automotive shop sets. They all do the same job. This section shows how to set up, zero, and do testing with any of the three multimeters. The ohms scale is used for continuity, shorts, and resistance testing. AC/DC voltages can also be measured using the multimeter.







AN/URM-105




SIMPSON 160

TA 098579 Go on to Sheet 2

(Sheet 2 of 8)

OHMS SCALE

USING THE OHMS SCALE



The ohms (Ω) scale is used to make tests for continuity, shorts, and resistance.

NOTE

Proper operation of electrical components depends upon proper grounding. In all troubleshooting procedures of devices which depend on screws or physical contact for their electrical ground (lamp sockets, sending units, batteries, etc), use a jumper wire from the device to the truck frame to check grounding.


The multimeter must be set up and zeroed before making these tests. Perform the following steps for the multimeter you are using.

AN/URM-105

- A Set selector switch (1) to X1 ohms position.
- B Now zero the meter. Touch the two probes (2) together while turning ohms adj knob (3) until needle (4) is over 0 on the top scale.
- C If needle will not zero, replace the batteries. If needle still will not zero after replacing the batteries, turn in the multimeter for repair.

TA 098580

USING THE OHMS SCALE (CONT)



TS-352 B/U


- A Set RANGE switch (1) to RX1.
- B Put black (-) lead (2) into the OHMS -DC \pm AC jack.
- C Put red (+) lead (3) in the upper left OHMS jack.
- D Turn FUNCTION switch (4) to OHMS.
- E Touch the two probes (5) together.

SIMPSON 160

- A Set selector switch (1) on RX1.
- B Put black (-) lead (2) in COM-jack.
- C Put red (+) lead (3) in + jack.
- D Set polarity reversing switch (4) on +DC.
- E Touch the two probes (5) together.


- F Zero meter by turning the OHMS ZERO ADJ (6) knob until needle (7) is over 0 on top scale.
- G If needle will not zero, replace the batteries. If needle still will not zero after replacing the batteries, turn in the multimeter for repair.

- F Zero meter by turning the OHMS ZERO ADJ (6) knob until needle (7) is over 0 on top scale.
- G If needle will not zero, replace the batteries. If needle still will not zero after replacing the batteries, turn in the multimeter for repair.



TA 098581

TESTING FOR CONTINUITY



Continuity tests are made to check for breaks in a circuit, such as the switch, light bulb, or electrical cable as shown. To make a continuity check, do the following steps:

A Set up and zero the multimeter.



Failure to do the following step can damage the multimeter.

- B Disconnect the circuit being tested. To be safe, disconnect the battery ground strap.
- C Connect the meter probes to both terminals of the circuit being tested. (The AN/ URM-105 is illustrated, but the probes are connected to the circuit the same way with all three multimeters.)
- D Observe needle movement.

If the needle swings to the far right over the 0 on the top scale, the circuit has continuity.

If the needle doesn't move, the circuit is open (broken).

If the needle jumps or flickers, there is a loose connection in the circuit being tested.

TA 098582

TESTING FOR SHORT CIRCUITS

A short or short circuit occurs when two circuits that should not be connected have contact with each other. A short also occurs when a circuit that should not touch ground has contact with ground. To check for shorts, do the following steps:

A Set up and zero the multimeter.




Failure to do the following step can damage the multimeter.

- B Disconnect the circuit being tested. To be safe, disconnect the battery ground strap.
- C Connect one probe to one circuit and the other probe to the other circuit or ground (if checking for a short to ground). The examp~e shows a check to see if wire A is shorted to wire B in the wiring harness.
- D Observe needle movement.

If the needle swings to the far right over the 0 on the top scale, the circuits are short circuited.

If the needle doesn't move, the circuits are not short circuited.

If needle jumps or flickers, the circuits are intermittently short circuited.



TA 098583

MEASURING RESISTANCE

To measure resistance, do the following steps:

A Setup and zero the multimeter.

CAUTION

Failure to do the following step can damage the rnultimeter.

B Disconnect the circuit being tested. To be safe, disconnect the battery ground strap.


NOTE

Zero the meter every time you change ranges.

- C If the test calls for an ohms range different than RX1 or Xl, set the selector switch to that range (like RX10 or X10).
- D Connect the probes across the circuit or item to be measured. The example shows measuring the resistance of one wire in a three-wire cable.

E Read the meter. If the meter switch is on the RXI or XI range, the reading is taken directly from the top scale. If the meter switch is on a different range, multiply the reading on the scale according to the table below.


OHMS SWITCH SETTING	SCALE
Xl or RX1	Read number on scale
X10 or RX10	Multiply reading by 10
X100 or RX100	Multiply reading by 100
X1K or RX1K	Multiply reading by 1000
X10K or RX10K	Multiply reading by 10,000




TA 098584


DC VOLTS SCALE

USING THE DC VOLTS SCALE



AN/URM-105





SETTING UP THE METER

Before using the multimeter to measure DC volts, do the following steps pertaining to the multimeter you have.

AN/URM-105

Set meter switch to DC volts range. (To measure 24 volts DC, set switch on 100 DC VOLTS range.)

TS-352 B/U

A Set FUNCTION switch (1) to DIRECT.

B Put black lead (2) in OHMS-DC/±AC jack.

C To measure 24 volts DC, plug red lead (3) into 50V jack on left side of meter. (If measuring less than 10 volts DC, use 10V jack. If measuring less than 2.5 volts DC, use 2.5V jack.)

SIMPSON 160

A Connect black lead (1) to COM-jack.

B Connect red lead (2) to + jack.

C To measure volts DC, set selector switch (3) to VDC 50 position. (If measuring less than 10 volts DC, set selector switch to VDC 10 position. If measuring less than 2.5 volts DC, set selector switch to VDC 2.5 position.)

D Set polarity reversing switch (4) to +DC.

TA 098585

(Sheet 8 of 8)

DC VOLTS SCALE (CONT)

MEASURING DC VOLTS


To measure DC voltage, do the following steps:

A Set up and zero multimeter.

CAUTION

If you are unsure of the voltage to be measured on the vehicle, always start on the highest range. This will protect the meter.

- B Connect the red probe to the positive (+) side of the circuit and the black probe to the negative (-) side. The example shows 24 volts DC being measured across the batteries.
- C Read the meter. If the needle moves off scale to the left, reverse the probes on the circuit.



NOTE

The following examples show how to read all three multimeters.

AN/URM-105

Read the DC volts scale for the range at which the selector switch is set.

SWITCH SETTING	SCALE
1000 DC VOLTS	0-10 (and multiply by 100)
100 DC VOLTS	0-10 (and multiply by 10)
10 DC VOLTS	0-10
1 DC VOLT	0-10 (and divide by 10)

TS-352 B/U

Read the DC volts scale for the range at which the red lead is plugged.

RANGE	SCALE
50V	0-5 (and multiply by 10)
10V	0-10 (and multiply by 4)
2. 5V	0-2.5

SIMPSON 160

Read the DC volts scale for the range at which the selector switch is set.

SWITCH SETTING	SCALE	
VDC 50	0-50	
VDC 10	0-10	TA 098586
VDC 2.5	0-25 (and divide by 10)	End

CODES, ABBREVIATIONS AND SYMBOLS

(Sheet 1 of 3)

COLOR CODE


Wire and connector colors are shown according to the following color code:

Abbreviation	Color	Abbreviation	Color
R	Red	GY	Gray
W	White	PR	Purple
O	Orange	BR	Brown
Y	Yellow	DK G	Dark Green
T	Tan	DK BL	Dark Blue
PK	Pink	LT G	Light Green
BK	Black	LT BL	Light Blue
G	Green		-

Two colors separated by a slash mark indicate a wire with a stripe - for example, R/LT G is a red wire with a light green stripe. Note the correct codes for colors often confused:

BK is black, BL is blue, PK is pink, PR is purple.

SYMBOLS




TA 098587

CODES AND ABBREVIATIONS (CONT)

(Sheet 2 of 3)

WIRE HARNESS CONNECTORS

Harnesses are connected together by molded multiple-bullet connectors, some of which are color-coded for easy identification. On these schematics, connector color and location are shown as follows:




Connector locations: (see page 2-60, sheet 3)

LHIP - Behind LH instrument panel
RHIP - Behind RH instrument panel
Rear of cab - Behind cover below rear window
RH side of cab - Behind cover below RH window
Engine panel - Behind right rear wheel and engine access panel
Near Trans. - Under trap doors behind cab
Front Corm. - On loader frame
Rear Corm. - Behind radiator
Service Center - Behind service center doors

TA 098588

CODES AND ABBREVIATIONS (CONT)

(Sheet 3 of 3)



HARNESS CONNECTOR LOCATIONS

TA 098589

End

2-60

WIRE LIST (Sheet 1 of 5)

All wires are 16 gage (AWG) except those listed below. If uncertain of a wire gage, look down the column designated COLOR until you find the color code for your wire. If under the. FROM / TO columns, your wire is not listed, use 16 gage wire, otherwise use gage size as listed under column AWG.

WIR COLOR	E AWG	FROM	ТО
BK BK BK BK	14 18 18 18	Ceiling heater blower motor VOLTMETER - term GRD ALTERNATOR indicator POWER switch - term GRD	Ground ALTERNATOR indicator Panel light RHIP PANEL TEST switch - term 5
BR/BK	18	LOW HYD OIL LEVEL indicator	LOW ENGINE OIL LEVEL indicator
BR/BK	18	LOW ENGINE OIL LEVEL indicator	HIGH FUEL LEVEL indicator
DK BL	12	DK G connector at LHIP (for FLOOD LIGHTS)	BK connector at rear of cab DK G connector at rear of cab
DK BL	12	BK connector at rear of cab	

WIRE LIST (CONT) (Sheet 2 of 5)

COLOR	E AWG	FROM	ТО
G	14	Ceiling heater blower switch (MED SPD)	Ceiling heater blower motor
GY	18	Splice near voltmeter in RHIP harness	Lamp sockets on all gage lights (five wires total)
LT BL LT BL LT BL	14 14 14	Fuse 6 RHIP DK G connector at RHIP Ceiling heater switch (LOW SPD)	DK G connector at RHIP Cab floor heater blower motor Ceiling heater blower motor
LT G LT G	14 14	Splice in front harness Splice in front harness	LH warning horn RH warning horn

WIRE LIST (CONT) (Sheet 3 of 5)

WIR	RE		
COLOR	AWG	FROM	То
O	10	Alternator-term+	Main power relay (2 separate wires required)
O	10	Main power relay	60-amp circuit breaker (2 separate wires required)
0	10	60-amp circuit breaker	Panel fuse holder no. 5 in LHIP and to splice in cab
			harness (NOTE: 2 separate wires are required, but
			they are spliced together in cab harness, see schematic)
O	12	Splice in cab harness	Fuse holder no. 9 in RHIP
O	12	Fuse holder no. 9 in RHIP	Fuse holder no. 8 in RHIP
0	12	Fuse holder no. 8 in RHIP	Fuse holder no. 7 in RHIP
0	12	Fuse holder no. 7 in RHIP	Fuse holder no. 6 in RHIP
0	12	Fuse holder no. 5 in LHIP	Fuse holder no. 4 in LHIP
0	12	Fuse holder no. 4 in LHIP	Fuse holder no. 3 in LHIP
Ö	12	Fuse holder no. 3 in LHIP	Fuse holder no. 2 in LHIP
Ō	12	Fuse holder no. 2 in LHIP	Fuse holder no. 1 in LHIP
Ŏ	14	Main power relay	15-amp circuit breaker
ŏ	14	Ceiling heater switch (HI SPD)	Ceiling heater blower motor

WIRE LIST (CONT) (Sheet 4 of 5)

WIR COLOR	E AWG	FROM	ТО
D	0	Main manner relact	Startar valou
R	8	Main power relay	Starter relay Starter solenoid - term BATT (2 sepmate wires required)
R	10	Main power relay	
R	10	Alternator - term + (Pos)	Radio interference capacitor on alternator
R	10	Operator warning horn - term where PR/Y wire connects	Radio interference capacitor on operator warning horn (behind driver's seat)
R	10	Ceiling heater fan switch - term where R wires connect	Radio interference capacitor on heater housing
R	10	Capacitor on ceiling heater housing	Ground on heater housing
R	10	Windshield wiper switch - term B (inserted between term B and O wire)	Radio interference capacitor mounted on LHIP housing
R	12	Splice into LT BL wire ilear heater switch	Radio interference capacitor on heater housing
W	10	Starter relay	Starter solenoid - term SOL
W	18	Indicator light sockets on LHIP	Diode board assembly on LHIP (NOTE: 13 separator wires required)

WIRE LIST (CONT) (Sheet 5 of 5)

WIR	RE AWG	FROM	ТО
Y	12	DK G connector at LHIP	Loose connector coming from B connector at rear of cab (Wire comes from AUX switch on LHIP and can be used to power external source with 24 vdc)
Y/BK	14	15-amp circuit breaker on engine relay panel	Ceiling heater switch
Y/BR	18	Fuse holder no. 1 in LHIP	All indicator lamp sockets in LHIP (NOTE: from NO COOLANT FLOW indicator lamp socket to DK G connector is 16 gage Y/BR wire)
Y/BR	18	Fuse holder no. 9 in RHIP	All gages in RHIP

WIRE AND HARNESS TESTING


(Sheet 1 of 1)

Because of the numerous wires, harnesses and connectors which interconnect components in this system, tracing of individual wires is left up to you. Use the mini-schematic diagram accompanying each PROBLEM to determine the wire color, termination and connector locations. Use the schematic illustrations at the rear of this manual to determine pin and socket locations and overall view. Also, see WIRE LIST, page 2-61.

TIPS

Shorts usually are determined by a light, etc. remaining ON when it should be OFF. After determining that the switch is working properly, do the following:

- a. Reconnect wire at switch (1).
- b. Unplug connector at next connection (2). If light goes out, short is between (1) and (2). If light remains ON, reconnect (2) and disconnect (3) etc. until last connector. If light remains ON, short is between last connector (3) and lamp socket.



c. If short cannot be repaired, notify Direct Support to replace harness unless you are authorized to do so.

TA 098590

End

DIODE TESTING (Sheet 1 of 2)

This task covers: Testing diodes for shorts or opens.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

Multimeter Diode Page 2-71

Equipment Condition

Item removed from equipment

Special Tools Personnel Required


None One mechanic


References General Safety Instructions

None

DIODE TESTING (CONT) (Sheet 2 of 2)

LOCATION/ITEM	ACTION	REMARKS
Multimeter	a. Set up, using RX10 scale, and zero.	
	b. Connect meter probes across diode.	Observe reading.
	c. Reverse probes.	Again observe reading.
		Good diode will have lower (near zero) reading in one direction and a higher (near infinity) in the other direction. Replace diode assembly if both readings are low or both are high.
		En





- 1. Rear harness to engine harness connector (BLACK)
- 2. Rear harness to engine harness connector (RED)
- 3. Rear harness to engine harness connector (DARK BLUE)
- 4. Alternator relay
- 5. Plug-in diode assembly #3
- 6. Engine stop relay
- 7. Starter relay
- 8. Warning horn relay

- 9. Plug-in diode assembly #4
- 10. Start interlock relay
- 11. Main power relay
- 12. 15-amp circuit breaker
- 13. 60-amp circuit breaker
- 14. 8-amp circuit breaker
- 15. Rear wiring harness
- 16. Engine relay panel

ELECTRICAL TROUBLESHOOTING QUICK GUIDE

(Sheet 1 of 3)

ITEM	PROBLEM	REFERENCE
ENGINE	1. WILL NOT CRANK	See page 2-74.
	2. CRANKS SLOWLY	See page 2-80.
	3. CRANKS, BUT WILL NOT START	See page 2-81.
ALTERNATOR	4. CHARGES TOO MUCH OR NOT ENOUGH	See ALTERNATOR TESTING/ ADJUSTING, page 2-255.
STARTING AID	5. COLD WEATHER STARTING AID DOES NOT WORK	See page 2-86.
CAB	6. NO POWER TO INDICATOR LIGHTS, SERVICE LIGHTS, ETC.	See page 2-90.
HEATERS	7. FLOOR HEATER BLOWER MOTOR DOES NOT WORK	See page 2-92.
	8. CEILING HEATER/DEFROSTER BLOWER MOTOR DOES NOT WORK	See page 2-94.
HORNS	9. FRONT WARNING HORNS DO NOT WORK	See page 2-95.
	10. OPERATOR AUDIBLE WARNING HORN DOES NOT' WORK	See page 2-96.

ELECTRICAL TROUBLESHOOTING QUICK GUIDE (CONT)

(Sheet 2 of 3)

ITEM	PROBLEM	REFERENCE
INDICATOR LIGHTS	11. ONE DOES NOT WORK	See page 2-97.
	12. ALL DO NOT WORK	See page 2-98.
	13. PRESTART AND ALTERNATOR REMAIN ON AFTER ENGINE STARTS	See page 2-101.
	14. HI FUEL LEVER REMAINS ON	See page 2-104.
	15. LOW HYD OIL LEVEL REMAINS ON	See page 2-106.
	16. LOW ENG OIL LEVEL REMAINS ON	See page 2-108.
	17. LOW FUEL LEVEL REMAINS ON	See page 2-110.
	18. IMPLEMENT, TRANS, AIR OR PILOT REMAINS ON	See page 2-112.
	19. NO COOLANT FLOW REMAINS ON	See page 2-114.
	20. SUPP STER REMAINS ON	See page 2-117.
	21. HI TEMP HYD OIL REMAINS ON	See page 2-118.

ELECTRICAL TROUBLESHOOTING QUICK GUIDE (CONT)

(Sheet 3 of 3)

ITEM	PROBLEM	REFERENCE
INDICATOR LIGHTS (CONT)	22. LOW PRESS BRAKE REMAINS ON	See page 2-120.
	23. PARK BRAKE ON REMAINS ON	See page 2-122.
	24. CONTAINER LOCK LIGHTS DO NOT WORK	See page 2-124.
SERVICE LIGHTS	25. TAIL/PANEL, HEAD, FLOOD OR AUX FLOOD LIGHTS DO NOT WORK	See page 2-126.
	26. STOP LIGHTS DO NOT WORK	See page 2-133.
	27. DOME LIGHT DOES NOT WORK	See page 2-136.
GAGES	28. DO NOT WORK	See page 2-138.
SERVICE METER	29. DOES NOT WORK	See page 2-141.
ALARM	30. BACKUP ALARM DOES NOT WORK WHEN TRANSMISSION SELECTOR IS IN REVERSE	See page 2-143.
	31. BACKUP ALARM WORKS WHEN TRANSMISSION SELECTOR IS IN FORWARD OR NEUTRAL	See BACK UP ALARM SWITCH TESTING/ADJUSTMENT, page 2-334.

PROBLEM NO. 1 (Sheet 1 of 6)

ENGINE WILL NOT CRANK

Batteries fully charged. See page 2-269.

Cables good and installed correctly. See page 2-279.

Connectors clean and tight on posts.

Gages, lights, etc. work with POWER switch in ON position (see NOTE A).

NOTE A: If gages, lights, etc. do not work, see PROBLEM 6.

TROUBLESHOOT STARTING CIRCUIT

For battery power to turn the starting motor in this system, five switches must be closed.

Three of these are magnetic switches that are electrically activated:


- A. Starter solenoid located on the starting motor.
- B. Starter relay located on the engine relay panel. See page 2-60.
- C. Start interlock relay located on the engine relay panel. See page 2-60.

The other two are manually activated switches:

- D. Main disconnect located near engine relay panel.
- E. POWER key switch at START position located on right-hand instrument panel.

The main disconnect switch (D) should always be closed except when working on the starting system components. The POWER switch (E) connects battery power to the starting circuit to energize the coil on the starter relay (B). However, the coil can only be energized if the current can flow to ground. The start interlock relay (C) provides the ground path as long as it is closed. (NOTE: This relay is normally closed and opens when the alternator starts up. This prevents the starter relay from closing if the power switch is accidentally turned to START while the engine is running.) When the coil on the starter relay (B) is energized, power goes from the battery to the start solenoid (A), which closes the circuit to the starting motor.

PROBLEM NO. 1 (CONT) (Sheet 2 of 6)



PROBLEM NO. 1 (CONT) (Sheet 3 of 6)

- NOTE 1: When testing for voltage, negative lead from your multimeter should be to ground (machine frame). See page 2-56.
- NOTE 2: An assistant is required to turn and hold POWER switch in the START position.
- NOTE 3: Start engine to ensure that repair/replacement has solved problem.

		ANSWER		
STEP	QUESTION OR INSTRUCTION	YES	NO	REMARKS
1	Turn main disconnect switch to ON. Turn POWER switch to START. Test for voltage present (NOTES 1 and 2) at terminal BAT terminal where R/T wire connects to POWER switch. Is battery voltage present?	3	2	See page 2-305.
2	Replace/repair R/T wire from POWER switch to main power relay.			Use same gage and color wire removed.
3	Turn main disconnect switch to ON. Turn POWER switch to START. Test for voltage present (NOTES 1 and 2) at terminal S where W wire connects to POWER switch. Is battery voltage present?	5	4	See page 2-70.
4	Turn main disconnect switch to OFF. Replace POWER switch (NOTE 3).	_	_	See page 2-305.
5	Turn main disconnect switch to ON. Turn POWER switch to START. Test for voltage present at terminal on starter relay (7, page 2-70) where W wire connects. Is battery voltage present?	7	6	See page 2-70.
6	Replace/repair W wire from starter relay to POWER switch.			Use same gage and color wire removed.
		_	_	

PROBLEM NO. 1 (CONT) (Sheet 4 of 6)

	ANSWER			
STEP	QUESTION OR INSTRUCTION	YES	NO	REMARKS
7	Turn main disconnect switch to OFF. Turn POWER switch to OFF. Disconnect B/W wire from starter relay and start interlock relay (10, page 2-70). Test B/W wire for continuity. Is there continuity?	9	8	See page 2-70.
8	Replace/repair B/W wire from starter relay to start interlock.	_	_	Use same gage and color wire removed.
9	Turn main disconnect switch to ON. Test start interlock relay (10, page 2-70) terminal (from which B/W wire was removed) for continuity to ground. Reconnect B/W wire. Is there continuity?	11	10	See page 2-70.
10	Replace/repair B wire from start interlock to ground.	_		Use same gage and color wire removed.
11	Turn POWER switch to ON. Test for voltage present at terminal on start interlock relay (10, page 2-70) where LT BL wire connects. Is battery voltage present?	12	13	See page 2-70
12	Replace/repair LT BL wire from start interlock to alternator.		_	Use same gage and color wire removed.
13	Place a jumper between B/W wire and ground and attempt to crank engine. Does engine crank?	14	15	
14	Replace start interlock relay (10, page 2-70). Turn POWER switch to OFF.	_	_	If problem still exists, replace/repair BK ground wire from start interlock relay terminal 4 to connector at warning horn relay (8, page 2-70) mounting screw.

PROBLEM NO. 1 (CONT) (Sheet 5 of 6)

		ANSWER		-
STEP	QUESTION OR INSTRUCTION	YES	NO	REMARKS
15	Test for voltage present at large terminal on starter relay (7, page 2-70) where R wire connects. Is battery voltage present?	17	16	See page 2-70.
16	Repair/replace R wire from starter relay (7) to main power relay (11, page 2-70).	_	_	R wire must be 8-gage.
17	Turn POWER switch to START. Test for battery voltage at starter solenoid. Is battery voltage present at starter solenoid terminal:	_	_	
	a SOL - where 10 gage W wire connects?	17B	20	
	b Where solenoid connects to starting motor frame?	19	18	
18	Replace starter solenoid.	_		See page 2-261.
19	Replace starting motor. Turn main disconnect switch to OFF.			See page 2-261.
20	Test W wire between starter solenoid and starter relay for continuity with W wire isolated. Is there continuity?	22	21	
21	Repair/replace W10-gage wire from starter relay to starter solenoid. Main disconnect switch OFF. Does problem still exist?	22	end	W wire must be 10-gage.
22	Replace starter relay. Turn main disconnect switch to OFF.			See page 2-337.

PROBLEM NO. 2 (Sheet 1 of 1)

ENGINE

CRANKS SLOWLY

- 1. Test voltage potential onalfour batteries, see page 2-269.
- 2. If batteries are good, check battery cables for proper size, freedom from corrosion and proper installation, see page 2-279.
- 3. If batteries are fully charged, battery cables and connectors are good, and all mechanical systems work properly, inform Direct Support to test starting motor current draw.

NOTE

If ambient temperature is below 32°F (0°C) check that engine oil and diesel fuel ratings ue correct. If cold weather starting aid is being used and everything else is proper, see PROBLEM 5.

PROBLEM NO. 3 (Sheet 1 of 4)

ENGINE

CRANKS, BUT WILL NOT START

TROUBLESHOOT ENGINE STOP CIRCUIT

NOTE

This engine must crank fast enough to obtain heat of compression for ignition. If cranking speed is slow, see PROBLEM 2.

ENGINE STOP CIRCUIT CURRENT ENG ENG STOP STOP RELAY SOLENOID CIRCUIT BREAKER DK BL (8 AMP) ENG PNL CURRENT 24 V (TO POWER SWITCH TERM BATT) FROM Y/O CURRENT $\hat{24V}$ (FROM POWER SWITCH TERM IGN. WHEN IN ON OR START POSITION.)

PROBLEM NO. 3 (CONT) (Sheet 2 of 4)

NOTE 1: When testing for voltage, negative lead from your multimeter should be to ground (machine frame, etc.). See page 2-56. NOTE 2: Always replace a wire with the same size (gage). NOTE 3: Start engine after repair/replacement to ensure problem is solved.

STEP	QUESTION OR INSTRUCTION	ANS' YES	WER NO	REMARKS
	Gain access to right side of engine.			
1	Place transmission gear selector in reverse. With POWER switch in ON position does back-up alarm sound?	3	2	If YES, main power relay circuit is working.
2	See PROBLEM 6, page 2-90.	_	_	
3	Turn POWER switch to ON. Test for voltage present (NOTE 1) at engine stop relay (6, page 2-70) terminals. Is battery voltage present at terminal:			0 5 2
	a. 1 - Where BR wire connects?	4	3(b)	
	b. 3 - Where R wire connects?	3 <u>C</u>	10	4 4 131
	c. 5 - Where O wire connects?	3 <u>(d</u>)	11	Y/O BR
	d. 4 - Where Y/O wire connects?	12	13	ENGINE STOP RELAY
4	Is battery voltage present at engine stop solenoid terminal where BR wire connects?	7	5	Stop solenoid is located at governor on top of engine. TA 098598

PROBLEM NO. 3 (CONT) (Sheet 3 of 4)

STEP	QUESTION OR INSTRUCTION	ANS' YES	WER NO	REMARKS
5	Make sure DK BL connector (3, page 2-70) is properly seated and recheck for voltage present at engine stop solenoid. Is battery voltage now present at BR wire terminal?	_	6	If YES, engine should start. Hit does not, go to step 7.
6	16 gage BR wire from stop relay to solenoid is open. NOTES 2 and 3.	_	_	See page 2-53.
7	Is battery voltage present at BK ground wire terminal on engine stop solenoid?	9	8	
8	Turn POWER switch to OFF. Notify direct support to replace engine stop solenoid. NOTE 3.	-	_	
9	Repair/replace 16 gage BK ground wire from solenoid to ground. NOTE 3.			Wire grounds at fuel filter mounting bracket screw.
10	16 gage R, wire from 8 amp. Circuit breaker (14, page 2-70) to engine stop relay is open. Repair or replace wire. NOTE 3.			Co on to Short

STEP	QUESTION OR INSTRUCTION	ANSV YES	VER NO	REMARKS
11	16 gage O wire from main power relay (11, page 2-70) to engine stop relay is open. Repair or replace wire. NOTE 3.	_	_	
12	16 gage Y/O wire from engine stop relay to plug-in diode assembly No. 3 (5, page 2-70) is open. Repair or replace wire. NOTE 3.	_	_	
13	Replace engine stop relay. POWER switch OFF. NOTE 3.	_	_	

PROBLEM NO. 4		(Sheet 1 of 1)
ALTERNATOR	CHARGES TOO MUCH OR NOT ENOUGH	

See ALTERNATOR TESTING/ADJUSTING, page 2-255.

PROBLEM NO. 5 (Sheet 1 of 4)

COLD WEATHER STARTING AID


DOES NOT WORK

Engine cold (see NOTE). POWER switch ON or START.

NOTE

COOLANT TEMPERATURE MUST BE BELOW 80°F (26.7°C) TO CLOSE SWITCH!

The starting aid circuit receives its power from fuse 8. When the START AID switch is closed current flows from the fuse, through the switch, through the solenoid, through the deactivating switch and to ground. The deactivating switch must be closed. This switch opens (see NOTE above) when coolant temperature is above 100° F (37.8° C), deactivating the starting aid circuit. The diode protects the START AID switch from arcing due to induced solenoid high current.



PROBLEM NO. 5 (CONT) (Sheet 2 of 4)

NOTE: Voltage is checked to ground, see page 2-56.

STEP	QUESTION OR INSTRUCTION	ANSV YES	VER NO	REMARKS
	Remove engine left rear access doors.			
1	Is fuse 8 good? If indicator lamps come on when PANEL 7 switch is ON, fuse 8 is good.	ΓEST 3	2	Second fuse from right in RHIP.
2	Replace 10 amp fuse no. 8.			DEACTIVATING SWITCH
3	Have an assistant push START AID switch button while you listen for clicking at ether aid solenoid. Is clicking present?	4	7	PR
4	With START AID switch closed, is battery voltage present at PR wire on deactivating switch?	5	6	
5	Replace deactivating switch.		_	See page 2-315.

TA 098600

PROBLEM NO. 5 (CONT) (Sheet 3 of 4)

STEP	QUESTION OR INSTRUCTION	ANSV YES	WER NO	REMARKS
6	16 gage PR wire from ether aid solenoid to deactivating switch is open.	-	_	See page 2-53.
7	Is battery voltage present at ether aid solenoid terminals? One or both?	8	9	
8	Replace ether aid solenoid.			See page 2-337.
9	Gain access to back of RHIP. Is battery voltage present at START AID switch where O wire connects?	11	10	
10	16 gage O wire from PANEL TEST switch to START AID switch is open, repair/replace.			
11	Is battery voltage present at START AID switch where PR wire connects?	13	12	

PROBLEM NO. 5 (CONT)	(Sheet 4 of 4)
----------------------	----------------

STEP	QUESTION OR INSTRUCTION	ANS ^V YES	WER NO	REMARKS
12	Replace START AID switch.	_	_	See page 2-315.
13	16 gage PR wire from START AID switch to ether aid solenoid is open.	_	_	See page 2-53.

PROBLEM NO. 6 (Sheet 1 of 2)

CAB

NO POWER TO INDICATOR LIGHTS, SERVICE LIGHTS, ETC.

Engine starts. Batteries fully charged. Ceiling heater blower works.

All power to the cab, except for the ignition-start circuits, comes from the main power relay (11, page 2-70). The main power relay coil is energized by the ignition circuit which receives its power from the 8 amp circuit breaker connected directly to positive side of batteries. Go to step 1.

MAIN POWER CIRCUIT TO FUSES LHIP PK/Y 24 V 24V FROM IGNITION CIRCUIT **FROM** PK/W LHIP BAT LT BL REAR **NEAR XMSN** OF CAB **SPLICES** 60 AMP DK G CB REAR OF CAB DK G RHIP TO 15 AMP CB TO ENG STOP RELAY TERM #5 TO FUSES TO ALTERNATOR TERM + TO 8 AMP RHIP CBTA 098601 TO STARTER AND IGN RELAY Go on to Sheet 2 CIRCUIT

PROBLEM NO. 6 (CONT) (Sheet 2 of 2)

STEP	QUESTION OR INSTRUCTION	ANSV YES	<u>VER</u> No	REMARKS
	POWER switch ON			
	Gain access to engine relay panel.			
1	Is battery voltage present at 60 amp. circuit breaker (13, page 2-70) input terminal ① ?	2	5	
2	Is battery voltage present at output terminal ②?	4	3	
3	Replace 60 amp circuit breaker.	_	_	
4	10 gage O wire(s) from 60 amp. circuit breaker to splices in cab harness is open. See WIRE and HARNESS TESTING, page 2-66.	_	_	O 60 AMP CIRCUIT BREAKER
5	10 gage O wire (O) from main power relay to 60-amp circuit breaker is open.			See page 2-53.

TA 098602

End

PROBLEM NO. 7 (Sheet 1 of 2)

HEATERS


FLOOR HEATER BLOWER MOTOR DOES NOT WORK

POWER switch ON

The floor heater fan is controlled by a switch with a built-in indicator lamp. This lamp should be a 5D19 Bulb. If this bulb is burned out, it is possible that a 12 volt bulb was installed by mistake.

The floor heater receives its power from fuse 6, first fuse from left in Right Hand Instrument Panel.

FLOOR HEATER CIRCUIT



TA 098603

PROBLEM NO. 7 (CONT) (Sheet 2 of 2)

STEP	QUESTION OR INSTRUCTION	ANSWER YES NO	REMARKS	
1	Is fuse no. 6 good?	3 2		
2	Replace fuse no. 6.			
3	Is battery voltage present at heater switch termimd where LT BL wire connects?	4 5	See page 2-57.	
4	Replace heater switch.		See page 2-315.	
5	LT BL wire from fuse 6 to switch is open.		See page 2-53.	

PROBLEM NO. 8 (Sheet 1 of 1)


HEATERS

CEILING HEATER/DEFROSTER BLOWER MOTOR DOES NOT WORK

POWER switch ON

Blower motor receives its power from 15 amp circuit breaker on engine relay panel If warning horn does not work, 15 amp circuit breaker is bad. If warning horn works, problem is probably at heater switch. (See page 2-315.)

CIRCUIT



PROBLEM NO. 9 (Sheet 1 of 1)


HORNS

FRONT WARNING HORN(S) DO NOT WORK

POWER switch ON. All other systems work.

The front warning horns get their power from fuse no. 7. If back horns do not work, problem is at fuse or within wiring (LT G) from fuse 7 to horns. If one horn does not work, problem is at horn or wiring from splice from front harness to horn. (Refer to page 2-327.)

FRONT WARNING HORN(S) CIRCUIT



TA 098605

End

PROBLEM NO. 10 (Sheet 1 of 1)

HORNS


OPERATOR AUDIBLE WARNING HORN DOES NOT WORK

POWER switch ON. PANEL TEST switch ON.

TEST LOW ENGINE OIL PRESSURE SWITCH IF VOLTAGE IS PRESENT AT HORN

When the PANEL TEST switch is closed, circuit flows from PANEL TEST switch, through warning horn relay coil, through low engine oil pressure switch to ground. (See page 2-327.)

OPERATOR WARNING HORN CIRCUIT



TA 098606

End

PROBLEM NO. 11	(Sheet 1 of 1)
----------------	----------------

INDICATOR LIGHTS

ONE WILL NOT COME ON WHEN PANEL TEST SWITCH IS ON

STEP	QUESTION OR INSTRUCTION	ANS' YES	WER NO	REMARKS
1	Test bulb for continuity, (page 2-53). Is bulb good?	2	*	*Replace bulb (24 volt only).
2	Check condition of socket and if bulb is seating correctly. Is socket good?	3	*	*Repair or replace socket, see page 2-305.
3	Gain access to rear of instrument panel. Are the wire terminals properly connected and tight? (NOTE A).	4	*	*Make proper.
4	Test individual diode for light which will not come on. Is diode good?	6	5	See diode test procedure, page 2-67.
5	Individual diodes are not serviceable, replace diode board assembly.			See page 2-337.
6	18 gage W wire from diode to lamp socket is open, repair or replace wire.	_	_	

^{*}For LOW PRESS BRAKE indicator, test flasher for continuity, see page 2-53. Replace flasher if defective.

PROBLEM NO. 12 (Sheet 1 of 3)

INDICATOR LIGHTS

ALL DO NOT WORK


POWER switch ON. PANEL TEST switch ON. Service lights (HEAD, FLOOD, etc.) work (see NOTE A).

NOTE A: If the service lights do not work, see PROBLEM 6, page 2-90.

TROUBLESHOOT PANEL TEST CIRCUIT

This circuit provides a means of testing the indicator lamps, service meter, and operator audible warning horn before the engine is started. Diodes are used to isolate the individual circuits from each other, yet allow one switch to test all circuits simultaneously.

PANEL TEST CIRCUIT



TA 098607

(Sheet 2 of 3) PROBLEM NO. 12 (CONT)

NOTE 1: When testing for voltage, negative lead from your multimeter should be to ground (machine frame, etc.). See page 2-57.

NOTE 2: Always replace a wire with the same size (gage).

NOTE 3: After repair/replacement, turn POWER and PANEL TEST switches to ON to ensure problem is solved.

STEP	QUESTION OR INSTRUCTION	ANSW YES	YER. NO	REMARKS
	Reach under each instrument panel and make sure harness connectors are properly seated.	_	_	Total of eight (8) connectors.
1	Place PANEL TEST switch in down, OFF, position. With POWER switch in ON position, are PRESTART and ALTERNATOR indicators lit?	6	2	
2	Is no. 1 fuse (below TAIL/PANEL switch) good?	4	3	
3	Replace fuse (10 amp). NOTE 3.	_	_	
4	Gain access to rear of Left Hand Instrument PANEL (LHIP). Is voltage present (NOTE 1) at each lamp socket and at fuse-holder where Y/BR wire connects?	6	5	Wire color at PRESTART sockets is BR/B.
5	Correct opening in 18 gage Y/BR wire from lamp sockets to no. 1 fuseholder. NOTES 2 and 3.	_		
6	Gain access to rear of Right Hand Instrument Panel. Is voltage present at PANEL TEST switch terminal 4 where BK/Y wire connects?	7	10	

PROBLEM NO. 12 (CONT) (Sheet 3 of 3)

STEP	QUESTION OR INSTRUCTION	ANSV YES	WER NO	REMARKS
7	Place PANEL TEST switch in up, ON, position. Is voltage present at PANEL TEST switch terminal 5 where BK ground wire connects?	9	8	
8	Turn POWER switch to OFF. Replace PANEL TEST switch. NOTE 3.		_	See page 2-315.
9	B ground wire from PANEL TEST switch to cab ground is open. Repair/replace. NOTES 2 and 3.	_	_	
10	Is voltage present at diode board assembly (LHIP) terminal where BK/Y wire connects?	11	12	
11	16 gage BK/Y wire from diode board assembly to PANEL TEST switch is open. NOTES 2 and 3.		_	See page 2-53.
12	Replace diode board assembly. NOTE 3.	_	_	See page 2-337.

PROBLEM NO. 13 (Sheet 1 of 3)


INDICATOR LIGHTS

ALTERNATOR, LOW ENG OIL LEVEL, LOW HYD OIL LEVEL AND HI FUEL LEVEL INIXCATORS REMAIN ON AFTER ENGINE STARTS. (PRESTART INDICATORS)

VOLTS meter indicates normal charge.

These four circuits operate only before the engine is started. They obtain their power from the alternator relay which is supposed to open the circuits when alternator output starts up.

ALTERNATOR RELAY CIRCUIT



(Sheet 2 of 3) PROBLEM NO. 13 (CONT)

NOTE A: Voltage is checked to ground, see page 2-56. NOTE B: After replacement, START engine to ensure problem is solved.

STEP	QUESTION OR INSTRUCTION	ANSV YES	VER No	REMARKS
1	Engine running. Parking Brake ON. Remove engine lower right access covers. Test for voltage (NOTE A) present at terminal no. 5 where LT BL wire connects on alternator relay (4, page 2-70). Is voltage present? (12 volts DC).	2	3	TEST 5 2 BR/BK HERE 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
2	Replace alternator relay. POWER switch OFF.			See page 2-352. NOTE B.
3	WARNING Do not get any part of your body, clothing or test equipment near the alternator drive belts. Test for voltage present at terminal R where LT BL wire connects on alternator. Is voltage present?	5	4	12 volts DC should be present.
4	Replace alternator. POWER switch OFF.		_	See page 2-252. NOTE B. TA 098609 Go on to Sheet 3

PROBLEM NO. 13 (CONT)	(Sheet 3 of 3)
PROBLEM NO. 15 (CONT)	(Bricet o or o)

STEP	QUESTION OR INSTRUCTION	ANSWER YES NO	REMARKS
5	Test for open in LT 13L wire from alternator to alternator relay.		See page 2-53.

PROBLEM NO. 14 (Sheet 1 of 2)


INDICATOR LIGHTS

HI FUEL LEVEL INDICATOR REMAINS ON

Engine not running. Fuel level LOW. POWER switch ON.

This circuit uses a normally-open (N.O.) magnetic float switch which will be closed if the fuel level in the tank is sufficient for a 10-hour wmrk day. Power to the circuit is supplied by the alternator relay terminal 2 when the POWER switch is in the ON position. The circuit is deactivated after the engine starts.

HIGH FUEL LEVEL INDICATOR CIRCUIT



TA 098610

PROBLEM NO. 14 (CONT) (Sheet 2 of 2)

NOTE A: After replacement, turn POWER switch to ON to ensure problem is solved.

STEP	QUESTION OR INSTRUCTION	ANSV YES	VER NO	REMARKS
1	Disconnect O/BK wire at upper fuel level switch on fuel tank. Prevent wire terminal from touching ground. Does indicator light remain ON?	5	2	
2	Turn POWER switch to OFF. Remove fuel level switch, (see page 2-315). Is float defective or incorrectly installed?	3	4	
3	Install correctly or repair/replace float, install switch, connect O/B wire and turn POWER switch to ON. Does indicator light remain ON?	4	_	See page 2-315.
4	Replace fuel level switch. POWER switch OFF. NOTE A.	_		See page 2-315.
5	Test for short in O/BK wire from switch to indicator lamp socket. See WIRE and HARNESS TESTING.	_	_	See page 2-66.

PROBLEM NO. 15 (Sheet 1 of 2)


INDICATOR LIGHTS (PRE START)

LOW HYD OIL LEVEL REMAINS ON

Engine not running. Hydraulic tank oil level normal (check sight gage on side of tank). POWER switch ON.

This circuit uses a normally-dosed (N. C.) magnetic float switch which is open when the float is pushed up by sufficient oil in the tank. Power to the circuit is supplied from the alternator relay terminal 2 when the POWER switch is turned to ON. The circuit is deactivated after the engine starts.

LOW HYDRAULIC OIL LEVEL CIRCUIT



TA 098611

PROBLEM NO. 15 (CONT) (Sheet 2 of 2)

NOTE A: After replacement, turn POWER switch to ON to ensure problem is solved.

STEP	QUESTION OR INSTRUCTION	ANS' YES	WER NO	REMARKS
1	Disconnect DK G/W wire at hydraulic level switch on hydraulic tank. Prevent wire terminal from touching ground. Does indicator light remain ON?	5	2	
2	Turn POWER switch to OFF. Remove hydraulic oil level switch, (see page 2-3 15). Is float defective or incorrectly installed?	3	4	
3	Install correctly or repair/replace float, install switch connect DK G/W wire and turn POWER switch to ON Does indicator light remain ON?	4	-	See page 2-315.
4	Replace hydraulic oil level switch. POWER switch OFF. NOTE A.	_	_	See page 2-315.
5	Test for short in DK G/W wire from switch to indicator lamp socket. See WIRE and HARNESS TESTING.		_	See page 2-66.

PROBLEM NO. 16

(Sheet 1 of 2)


INDICATOR LIGHTS (PRESTART)

LOW ENG OIL LEVEL INDICATOR REMAINS ON

Engine not running. Engine oil level normal. (See page 2-152.) POWER switch ON.

This circuit uses a normally-closed (N. C.) magnetic float switch which will be closed if the oil level in the engine oil pan is too low. Power to the circuit is supplied by the alternator relay terminal 2 when the POWER switch is in the ON position. The circuit is deactivated after the engine starts.

LOW ENGINE OIL LEVEL INDICATOR CIRCUIT



TA 098612

PROBLEM NO. 16 (CONT) (Sheet 2 of 2)

NOTE A: After replacement, turn POWER switch to ON to ensure problem is solved.

STEP	QUESTION OR INSTRUCTION	ANS' YES	WER NO	REMARKS
1	Disconnect DK BL/W wire at engine oil level switch on oil pan. Prevent wire terminal from touching ground. Does indicator light remain ON?	5	2	
2	Turn POWER switch to OFF. Remove engine oil level switch, see page 2-315. Is float defective or incorrectly installed?	3	4	
3	Install correctly or repair/replace float, install switch, connect DK BL/W wire and turn POWER switch to ON. Does indicator light remain ON?	4	_	See page 2-315.
4	Replace engine oil level switch. POWER switch OFF. NOTE A.			See page 2-315.
5	Test for short in DK BL/W wire from switch to indicator lamp socket. See WIRE and HARNESS TESTING.	_	_	See page 2-66.

PROBLEM NO. 17 (Sheet 1 of 2)


INDICATOR LIGHTS

LOW FUEL LEVEL INDICATOR REMAINS ON

POWER switch ON. Fuel tank has 16.5 gals. or more fuel in it.

This circuit uses a normally-closed (N.C.) magnetic float switch which will be open when fuel level is above 10% (16.5 gals.) of tank capacity. The circuit receives its power from the no. 1 fuse (first fuse from left in Left Hand Instrument Panel (LHIP)). POWER switch ON. Engine running or not.

LOW FUEL LEVEL INDICATOR CIRCUIT



TA 098613

PROBLEM NO. 17 (CONT) (Sheet 2 of 2)

NOTE A: After replacement, turn POWER switch to ON to ensure problem is solved.

STEP	QUESTION OR INSTRUCTION	ANS' YES	<u>WER</u> NO	REMARKS
1	Disconnect PR/W wire at low fuel level switch on fuel tank. Prevent wire terminal from touching ground. Does indicator light remain ON?	5	2	Switch is at lower side of tank.
2	Turn POWER switch to OFF. Remove low fuel level switch, see page 2-315. Is float defective or incorrectly installed?	3	4	
3	Install correctly or repair/replace float, install switch, connect PR/W wire and turn POWER switch to ON. Does indicator light remain ON?	4	_	See page 2-315.
4	Replace fuel level switch, POWER switch OFF. NOTE A.			See page 2-315.
5	Test for short in PR/W wire from switch to indicator lamp socket. See WIRE and HARNESS TESTING.	_	_	See page 2-66.

(Sheet 1 of 2) PROBLEM NO. 18

INDICATOR LIGHTS (PLUGGED FILTER)


IMPLEMENT, TRANS, AIR OR PILOT INDICATOR REMAINS ON AFTER CHANGING CORRESPONDING FILTER

POWER switch ON. Engine not running.

The individual circuits for these four indicators are identical except for the color of the wire from the lamp socket to the switch. All four circuits receive their power from the no. 1 fuse (first fuse from left in Left Hand Instrument Panel (LHIP)) when the POWER switch is ON.

All switches are normally-open type switches which ciose if filter pressure drop becomes excessive.

TYPICAL FILTER INDICATOR CIRCUIT



TA 098614

PROBLEM NO. 18 (CONT)	(Sheet 2 of 2)
-----------------------	----------------

	Switch NOTE C: IMPLEMENT TRANS AIR PILOT (BRAKE)	Filter Air f	ilter elbow	c tank servicat serv	ce center behind cab. vice center behind cab. ce center behind cab.
STEP	QUESTION OR INSTRUCTION		ANSV YES	/ER NO	REMARKS
1	POWER switch ON Disconnect wire (NOTE A, Sheet 1) at switch for indicator remains ON. Prevent wire terminal from touching ground.	r that	_	_	For switch locations, see NOTE C above. Go to step 2.
2	Does indicator light remain ON?		4	3	
3	Replace switch. POWER switch OFF. NOTE D.		_	_	See page 2-305.
4	Test for short in wire (NOTE A, Sheet 1) from switch to indicater socket. See WIRE and HARNESS TESTING.	-	_	_	See page 2-66.

NOTE D: After replacement, turn POWER switch to ON to ensure problem is solved.

End

PROBLEM NO. 19 (Sheet 1 of 3)

INDICATOR LIGHTS

NO COOLANT FLOW REMAINS ON

Engine running. WATER TEMP gage shows NORMAL temperature. POWER switch is ON.


NOTE

The warning horn behind the operator's seat will be sounding, however, the problem is not in that circuit.

TROUBLESHOOT COOLANT FLOW CIRCUIT

This circuit uses a normally closed paddle switch which opens when coolant flows against the paddle. When the switch closes, the indicator light comes on and the horn blows.

NO COOLANT INDICATOR CIRCUIT



PROBLEM NO. 19 (CONT) (Sheet 2 of 3)

NOTE I: DO NOT allow wire temindto touch ground(machine frame, etc.).

NOTE 2: START engine after replacement/repair to ensure problem is solved and reconnect PR/Y wire at warning horn relay if disconnected.

STEP	QUESTION OR INSTRUCTION	ANS' YES	WER NO	REMARKS
	Gain access to left rear and right front of engine. If the horn is blowing go to Step 1; if not, go to Step 2.			
1	Disconnect PR/Y wire from warning horn relay (8, page 2-70)			This will deactivate horn.
2	CAUTION Make sure PARKING brake is engaged and transmission selector is in NEUTRAL. Disconnect GY/BK wire at coolant flow switch. (NOTE 1) START engine. Did NO COOLANT FLOW indicator light go off?	3	4	ENGINE OIL COOLER COOLANT FLOW SWITCH
3	Turn POWER switch to OFF. Replace coolant flow switch. NOTE 2.	_	_	See page 2-315. TA 09861 Go on to Sheet

PROBLEM NO. 19 (CONT)	(Sheet 3 of 3)
-----------------------	----------------

STEP	QUESTION OR INSTRUCTION	ANSWER YES NO	REMARKS	
4	Turn POWER switch to OFF. Reconnect GY/BK wire at coolant flow switch. GY/BK wire from coolant flow switch is shorted, see WIRE and HARNESS TESTING, page 2-66.		NOTE 2.	

PROBLEM NO. 20 (Sheeet 1 of 1)

INDICATOR LIGHTS

SUPP STER REMAINS ON

POWER switch ON. Engine running. Normal steering system operating.


This circuit uses a normally closed paddle-type flow switch which opens when normal steering system flow occurs. When flow stops (supplemental steering takes over) the switch closes, lighting the SUPP STER lamp.

NOTE

Make sure arrow on switch points in direction of flow (away from main steering pump).

To troubleshoot: turn POWER switch to OFF, disconnect W/DK BL wire at flow switch and then START engine. If light goes out, replace flow switch, page 2-315. If light remains on, W/DK BL 16 gage wire is shorted between switch and lamp socket. See WIRE and HARNESS TESTING, page 2-66.

SUPP STER INDICATOR CIRCUIT



TA 098617

End

PROBLEM NO. 21

(Sheet 1 of 2)

INDICATOR LIGHTS


HI TEMP HYD OIL REMAINS ON AFTER HYDRAULIC OIL TEMPERATURE IS BELOW 190°F (87.8°C) (NOTE A)

POWER switch ON.

NOTE A: Lower a thermometer into the hydraulic oil tank. If hydraulic oil temperature is below 190°F (87.8°C), go to Step 1. If temperature is above 190°F (87.8°C) but below 215°F (101.7°C) wait until temperature comes down below 190°F (87.8°C), and then go to Step 1. If temperature is above 215°F (101.7°C), problem is in hydraulic system; notify Direct Support.

This circuit uses a normally open temperature switch which closes when oil temperature in hydraulic tank exceeds 215°F (101.7°C). The switch opens where oil temperature drops below 190°F (87.8°C).

HIGH TEMPERATURE HYDRAULIC OIL CIRCUIT



TA 098618

PROBLEM NO. 21 (CONT) (Sheet 2 of 2)

STEP	QUESTION OR INSTRUCTION	ANS' YES	WER NO	REMARKS
	POWER switch ON.			
1	Disconnect W/BR wire at high temperature hydraulic oil swit Do not let it touch ground. Did HI TEMP HYD OIL light go OFF?	tch. 2	3	HYD TANK
2	Turn POWER switch to OFF. Replace temperature switch. See page 2-315.	_	-	
3	16 gage W/BR wire from switch is shorted. See WIRE and HARNESS TESTING, page 2-66.	_		W/BR HI TEMP HYD OIL
				SWITCH

TA 098619

End

PROBLEM NO. 22 (Sheet 1 of 2)

INDICATOR LIGHTS

LOW PRESS BRAKE REMAINS ON


Engine running. Oil level in hydraulic tank is normal. Machine stops normally.

NOTE

The warning horn behind the operator's seat will be sounding, however, the problem is not in that circuit.

For circuit description, see Sheet 2.

LOW PRESS BRAKE INDICATOR CIRCUIT



PROBLEM NO. 22 (CONT) (Sheet 2 of 2)

This circuit uses a normally closed pressure switch which opens when accumulator output pressure is about 1,100 psi (7585 kPa). If the pressure drops to $1,000 \pm 100$ psi (6900 \pm 69 kPa) the switch closes and the LOW PRESS BRAKE light comes or I as well as the operator warning horn. The flasher causes the light to flash on and off.

TO TROUBLESHOOT: Disconnect W/O wire from brake pressure switch (do not allow it to touch ground). With engine running; if LOW PRESS BRAKE light is now OFF, replace brake pressure switch, (see page 2-315). If light remains ON, W/O, 16 gage wire between switch and lamp socket is shorted. See WIRE and HARNESS TESTING, page 2-66.

PROBLEM NO. 22 (Sheet 1 of 2)

INDICATOR LIGHTS

PARK BRAKE ON - REMAINS ON


Engine running. Parking brake released. Hydraulic oil level normal. Accumulator pressure normal. Machine moves in forward and in reverse normally.

NOTE

The warning horn behind the operator's seat will be sounding, however, the problem is not in that circuit.

For circuit description, go to Sheet 2.

PARKING BRAKE ON INDICATOR CIRCUIT



TA 098621

PROBLEM NO. 23 (CONT) (Sheet 2 of 2)

This circuit uses a nomally closed pressure switch which opens when accumulator output pressure is about 1,100 psi (7585 kPa). The switch closes if parking brake release pressure falls below 900-1100 psi (6210-7585 kPa). This causes the PARK BRAKE ON light to come on and provides a path for the warning horn relay circuit, causing the horn to blow if the transmission is in FORWARD or REVERSE.

The transmission setting is sensed by a microswitch cm the transmission interlock mechanism.

TO TROUBLESHOOT: Disconnect W/R wire from brake pressure switch (do not allow it to touch ground). With engine running; if PARK BRAKE ON light is now OFF, replace parking brake pressure switch, (see page 2-315). If light remains ON, W/R 16 gage wire between switch and lamp socket is shorted. See WIRE and HARNESS TESTING, page 2-66.

PROBLEM NO. 24 (Sheet 1 of 2)

INDICATOR LIGHTS (CONTAINER LOCK INSTRUMENT PANEL, CLIP)


CONTAINER LOCK LIGHTS DO NOT WORK

POWER switch ON.

- NOTE A: The container lock light panel lights receive their power from fuse 5 in LHIP. This same fuse powers the dome light circuit, therefore, if the dome light works the fuse and wiring to the BLACK connector at RH side of cab are good. Problem is either in CLIP or wiring from BLACK connector to CLIP.
- NOTE B: If only one lamp does not light when lens is pressed, problem is in bulb, socket or related wiring within panel.
- NOTE C: If only one lamp does not light when in normal operation (see OPERATOR'S CONTROLS AND INDICATORS), problem is either in limit switch on container handler or in associated wiring. See TM 10-3930-641-10.

CONTAINER LOCK INDICATOR CIRCUIT (See Sheet 2)

PROBLEM NO. 24 (CONT) (Sheet 2 of 2)



End

2-125

PROBLEM NO. 25		(Sheet 1 of 7)
SERVICE LIGHTS	25 a. TAIL, Sheet 4 25 b. PANEL, Sheet 5 25 c. HEAD, Sheet 6 25 d. FLOOD, Sheet 6 25 e. AUX FLOOD, Sheet 7	

A general procedure can be used to troubleshoot most of the service lights. This procedure is as follows:

- 1. Read the circuit description for the particular faulty light(s) while referring to the mini-circuit diagram below the description. If all of the service lights do not work, see PROBLEM 6.
- 2. Use the following generalized tabular logic tree to isolate the problem (see Sheet 2).
- NOTE A: All lamps are 24 volts.
- NOTE B: Voltage checks are negative to ground. See page 2-57.
- NOTE C. Continuity checks are made with item removed from system. See page 2-53.
- NOTE D: If only one lamp will not come on, go to Step 8.
- NOTE E: HEAD LIGHTS get power from a 15 amp circuit breaker rather than a fuse. Go to Step 3.
- NOTE F: Fuse numbers are from left to right starting at LHIP.
- NOTE G: Always replace or repair a wire with same size (gage). See WIRE LIST, page 2-61.

PROBLEM NO. 25 (CONT) (Sheet 2 of 7)

STEP	QUESTION OR INSTRUCTION	ANSV YES	VER NO	REMARKS
	Make sure DK G wire harness connector behind LHIP is completely connected.			
1	Check fuse (NOTES E and F). Is fuse good?	3	2	Use continuity test. NOTE C.
2	Replace fuse (use 10 amp fuse only).	_	_	If new fuse blows, go to Step 3.
3	Gain access to rear of LHIP. Is voltage present (NOTE B) at switch terminal where PR wire connects?	5	4	
4	Repair/replace 16 gage PR wire from fuseholder to switch. NOTE G.	_		
5	Is voltage present at other wire on switch when switch is turned ON?	1 7	6	
6	Turn POWER switch OFF. Replace switch.	_	_	See page 2-305.

PROBLEM NO. 25 (CONT)	(Sheet 3 of 7)
-----------------------	----------------

STEP	QUESTION OR INSTRUCTION	ANS' YES	WER NO	REMARKS
	POWER switch and faulty LIGHT switch(s) ON.			
7	Is battery voltage present at lamp terminal where wire from switch connects?	8	9	
8	Replace lamp.	_	_	
9	Wire from switch to lamp is open. See WIRE AND HARNITESTING.	ESS —		See page 2-66.

PROBLEM NO. 25 (CONT) (Sheet 4 of 7)

25 a. When the TAIL/PANEL LIGHT switch is closed, current flows from fuse 3, through the switch and through the tail lamps to ground. Current also flows to the panel light circuit, therefore, if panel lights and gages work, the problem is either at the tail lamps or in the GY wire between the DK BL connector at Right Hand Instrument Panel (RHIP) and the tail lamps.


If only Right Hand (RH) tail lamp is out test bulb and check ground. If only Left Hand (LH) tail lamp is out test bulb, check ground and GY wire from RH tail lamp.

If panel lights do not come on, problem is either at fuse (see NOTE) or switch or in wiring from fuse to Left Hand Instrument Panel (LHIP) panel lamp.

NOTE

If auxiliary flood lights work, problem is not at fuse.

TAIL LIGHT CIRCUIT




TA 098623

PROBLEM NO. 25 (CONT) (Sheet 5 of 7)

25 b. When the TAIL/PANEL LIGHT switch is closed, current flows from fuse 3, through the switch and through a.) LHIP panel lamp to ground, b.) through each gage lamp to ground and c.) through RHIP panel lamp to ground. Current also flows through the tail light circuit, therefore, if only tail lights work, the problem is in the ground circuit - check cab ground first. If the tail lights and LHIP panel light works, the problem is in the GY wire or connections between the RHIP panel light and the DK BL connector at RHIP - check for proper seating of connector first.

If only one lamp is out, check bulb and then wiring to its socket (NOTE: Gage lamps are each grounded to the case of the gage, which in turn is grounded by way of BK wires).




TA 098624


PROBLEM NO. 25 (CONT) (Sheet 6 of 7)

25 c. The HEAD LAMPS obtain their power from a 15 amp automatic-resetting circuit breaker rather than from a fuse. Current flo ws from the circuit breaker, through the switch, and through the lamps to ground. If only one lamp is out, problem is in the lamp or interconnecting wiring.

HEAD LIGHT CIRCUIT



25 d. When the FLOOD LIGHT switch is closed, current flows from fuse 2, through all four (front and rear) flood lamps to ground. If only the front work or only the rear work, switch and fuse are good. See diagram below.




PROBLEM NO. 25 (CONT) (Sheet 7 of 7)

25 e. The auxiliary flood lights are mounted on top of the cab. When the AUX FLOOD switch is closed, current flows from fuse 3 through the switch through the auxiliary flood lamps to ground.

NOTE

If PANEL/TAIL LIGHTS work, fuse 3 is good.

AUX FLOOD LIGHT CIRCUIT



TA 098626

End

PROBLEM NO. 26 (Sheet 1 of 3)

SERVICE LIGHTS

STOP LIGHT(S) DO NOT WORK


POWER switch ON. Brake pedal pressed. Indicator lights come ON when PANEL TEST switch is ON (see NOTE).

NOTE

Brake light switch receives its power from same circuit that feeds the panel test lights. If all indicator lights do not come on, see PROBLEM 12. If all indicator lights do come on, problem is between yellow connector and lamps or in the lamps.

This circuit uses a normally open pressure switch which closes when brake pedal (left or right) is pressed.

STOP LIGHT CIRCUIT



TA 098627

PROBLEM NO. 26 (CONT) (Sheet 2 of 3)

NOTE: Battery voltage is checked to ground (see page 2-57).

STEP	QUESTION OR INSTRUCTION	ANS' YES	WER NO	REMARKS
1	Service brake ACTIVATED. Is battery voltage present at stop light switch terminal where Y/BR wire connects? See NOTE.	3	2	Stop light switch is on brake valve.
2	16 gage Y/BR wire from switch to yellow connector near transmission is open. Repair/replace wire. See page 2-54.	_		
3	Is battery voltage present at stop light switch terminal where T wire connects?	5	4	
4	Replace stop light switch.	_		See page 2-315.

PROBLEM NO. 26 (CONT) (Sheet 3 of 3)

STEP	QUESTION OR INSTRUCTION	ANS YES	WER NO	REMARKS
5	Is battery voltage present at RH stop light where T wire connects?	7	6	
6	16 gage T wire from stop light switch to RH stop lamp is open. Repair or replace wire.			See page 2-54.
7	Replace both stop lamps.	_	_	See page 2-291.

PROBLEM NO. 27 (Sheet 1 of 2)

SERVICE LIGHTS


DOME LIGHT DOES NOT WORK

POWER switch ON. Remaining lights work.

TROUBLESHOOT DOME LIGHT CIRCUIT

The DOME light receives its power from fuse 5. Fuse 5 also supplies power to the Container Lock Instrument Panel (CLIP) lights. If the CLIP iights work problem is not in fuse or wiring to B connector at RH side of cab, go to Step 1.

DOME LIGHT CIRCUIT



TA 098628

PROBLEM NO. 27 (CONT) (Sheet 2 of 2)

NOTE: Voltage is checked to ground, see page 2-57.

STEP	QUESTION OR INSTRUCTION OR BOTH	ANSV YES		REMARKS
1	Is fuse 5 good?	3	2	Right most fuse in LHIP.
2	Replace 10 amp. fuse.	_	_	
3	Is bulb burned out?	4	5	
4	Replace 24 volt bulb.	_	_	
5	Is battery voltage present at T wire where it connects to lamp assembly?	6	7	
6	Replace DOME lamp assembly.	_	_	
'7	Test T, 16 gage wire from dome lamp to fuseholder 5. See page 2-53.	_	_	

PROBLEM NO. 28		(Sheet 1 of 3)
GAGES	DO NOT WORK	

Engine running and at nomal operating temperature.

The gages receive power from fuse 9 (rightmost fuse in RHIP). If all the gages do not work, check fuse 9 first. If fuse is good, repair/replace Y/BR wire from fuseholder 9 to VOLTS gage.


In case of suspected pressure or temperature gage malfunction, test circuit as follows: Remove wire from corresponding sender, with the POWER switch ON, and note the gage reading. Then momentarily ground the wire to machine frame and note gage reading. If gage and associated wiring are good, results should be:

Gage	Gage Indication With Wire Disconnected	Gage Indication With Wire Grounded
Engine Coolant Temp.	Low	High
Converter Temp.	Low	High
Engine Oil Pressure	High	Low
Engine Fuel Pressure	High	Low

Senders are probably more likely to fail than the gages themselves.


PROBLEM NO. 28 (CONT) (Sheet 2 of 3)

FUSE 9 POWER SCHEMATIC



PROBLEM NO. 28 (CONT) (Sheet 3 of 3)

SENDING UNITS



TA 098630

End

2-140

PROBLEM NO. 29 (Sheet 1 of 2)


SERVICE METER

DOES NOT WORK

All other gages, lights, etc. work.

The service meter can receive its power from two sources: a. From fuse 1 when the engine is running or b. From fuse 8 when the PANEL TEST switch is closed. If service meter does not work only when PANEL TEST switch is on, replace PANEL TEST switch.

SERVICE METER CIRCUIT



PROBLEM NO. 29 (CONT) (Sheet 2 of 2)

NOTE 1: If service meter works (allow 1-2 minutes for warm up) when PANEL TEST switch is ON (POWER switch ON, engine not running) trouble is in alternator relay or associated wiring. Go to Step 5.

NOTE 2: Voltage is checked to ground, see page 2-57.

STEP	QUESTION OR INSTRUCTION	ANSV YES	WER NO		REMARKS
1	Gain access to rear of LHIP. START engine. Is battery voltage present at hourmeter where O/LT BL wire connects.	2		See page 2-305.	
2	Is BK wire properly grounded?	4	3		
3	Repair/replace 16 gage BK wire.	_	_		
4	Replace service meter. POWER switch OFF.	_	_	See page 2-305.	LT BL
5	Turn POWER switch to OFF. Place transmission selector in FORWARD or REVERSE. Does operator warning horn work?	7	6		5 2 BR/BK
6	Gain access to engine relay panel. START engine. Is battery voltage present at alternator relay (4, page 2-70) terminal 3, where O/LT BL wire connects?	7	8		BK OUT DI
7	O/LT BL 16 gage wire from Y connector near transmission t service meter is open.	.co —	_	See page 2-53.	Y/BR O/LT BL ALT. RELAY
8	Replace alternator relay. POWER switch OFF.	-	_	See page 2-337.	TA 098632

End **2-142**

PROBLEM NO. 30 (Sheet 1 of 2)

ALARM

BACKUP ALARM DOES NOT WORK


POWER switch ON. TRANSMISSION GEAR SELECTOR in REVERSE. Ceiling heater blower motor works (see NOTE).

NOTE

If ceiling blower motor does not work, problem is at 15 amp. Circuit Breaker (CB) or associated wiring.


The backup alarm receives its power from 15 amp. CB (12, page 2-70). POWER switch must be ON to energize main power relay connecting battery voltage to the 15 amp. CB.

Placing transmission selector in reverse closes micro-switch on the transmission interlock, which sounds the backup alarm.



PROBLEM NO. 30 (CONT) (Sheet 2 of 2)

STEP	QUESTION OR INSTRUCTION	ANSV YES		REMARKS
	POWER switch ON. TRANS. selector in REVERSE.			
1	Is battery voltage present at backup alarm where DK $\mbox{G/R}$ wire connects?	2	3	
2	Replace backup alarm.	_	_	See page 2-329.
3	Is battery voltage present at backup alarm switch where DK GR/R wire connects?	4	5	Switch is on transmission interlock mechanism.
4	16 gage DK G/R wire from backup alarm to switch is open.	_	_	See page 2-53.
5	Is battery voltage present where R wire connects?	7	6	
6	16 gage R wire from switch to 15 amp CB is open. Repair/replace wire with same gage wire.	_	_	
7	See BACKUP ALARM SWITCH TESTING/ADJUSTMENT, page 2-334.	_		TRANS.



End

2-144

Section V. MAINTENANCE

This section contains:

a. Servicing	f. Repair or replacement
b. Inspection	g. Reassembly
c. Removal	h. Installation
d. Disassembly	i. Adjustment

e. Cleaning j. Test

Instructions for organizational maintenance personnel as allocated by the Maintenance Allocation Chart.

GENERAL MAINTENANCE PRACTICES

(Sheet 1 of 1)

General maintenance practices are given in this section. This information will not be repeated in any other part of this manual.

SAFETY

Safety is always the most important consideration when working on this vehicle. Understand completely the job to be done and use common sense. Don't just do the job. Do it safely. Shipping link must be installed before any maintenance.

REMOVING PARTS

Always respect the weight of a part. Use a hoist whenever necessary. Don't lift heavy parts by hand. A hoist and adjustable lifting beam or sling are needed to remove most parts. The length of chain or cable from the hoist to the part being lifted should be parallel and should be positioned directly over the center of the part. Never leave a part hoisted in mid-air.

Always use blocking to support the part that has been hoisted. If you cannot remove a part, check to see that all capscrews and attached hardware have been removed. Check to see if any parts are in the way of the part being hoisted.

CLEANING

Keep all dirt out of parts. The vehicle will perform better. Seals, filters, and covers are used in this vehicle to keep it clean. They must be kept in good shape to help the vehicle run well.

Clean and look at all parts when removing parts. Make sure all holes and passages are clean and open. After cleaning parts, be sure to cover them with a clean cloth, paper, or other clean material. Make sure the part is clean when it is installed.

Always clean around air lines, hydraulic lines, or covers before removing them. Plug, tape, or put caps on holes and openings to keep dirt out.

DISASSEMBLY AND ASSEMBLY

Always put together or take apart one part at a time. Do not work on two parts at the same time. Be sure to make all adjustments. Always check your work when you are finished. Make sure everything is done.

Check the adjustments for the last time by operating the vehicle. If all adjustments are correct, the vehicle is ready to go back to work.

End

REPAIR AND REPLACEMENT PROCEDURES

(Sheet 1 of 3)

HARDWARE AND THREADED PARTS

Install helical thread inserts when inside threads in castings are not able to withstand desired torque.

Replace capscrews, nuts, studs, washers, spacers, and small common hardware if missing or damaged in any way. Repair minor thread damage by cleaning out the threads using a tap or die.

Replace all damaged or missing lubrication fittings.

BELTS, WIRING, HOSES AND LINES

Replace belts, hoses, clamps, electrical wiring, electrical switches, circuit breakers, and fuel lines if they are broken, split or inoperative.

INSTRUMENTS AND GAGES

Replace defective or broken instruments and gages.

BALL AND ROLLER BEARINGS

Anti-friction bearings must be handled in a special way. To keep out dirt and abrasives, cover the bearings as soon as they are removed.

Wash bearings in a non-flammable cleaning solution. Knock out packed lubricant inside by tapping the bearing against a wooden block. Wash bearings again. Cover bearings with clean material, and set them down to dry.

Then coat bearings with oil. Wrap them in clean paper.

Make sure the chamfered side of the bearing faces the shoulder when installing bearings against shoulders. Before pressing bearings into place, lubricate them and all metal surfaces they contact. Put pressure only on the part of the bearing that directly contacts the mating part.

Always use the proper tools and fixtures for removing and installing bearings. Special tools and fixtures that are needed are listed in the manual.

Bearings do not usually need to be removed. Remove bearings only if it is necessary.

SLEEVE BEARINGS

Do not remove a sleeve bearing unless it is damaged, very worn, or loose in its bore. If you must remove a sleeve bearing, press it out.

When pressing or driving, put pressure right in line with the bore. Use a bearing driver or a bar with a smooth flat end to drive a bearing. Never use a hammer.

If there are oil holes, make sure they are alined.

GASKETS

Always replace used gaskets with new gaskets. Never use the same gasket twice. Make sure the gasket holes match up with holes in the mating part.

If gasket must be made, make sure to cut holes to match up with the mating part. Use material that is the right type and thickness.

Serious damage to the machine can happen if any holes on the part are blocked by the gasket.

LIP TYPE SEALS

Lip seals are usually used to seal oil or grease. To seal in oil, the lip is usually put facing toward oil to be sealed. To seal grease, the lip usually faces away from grease.

Seals should not be removed. Only remove seals to get at other parts or if the seal is damaged or worn.

Leaking oil or grease usually means that a seal is damaged and needs to be replaced. Replace leaking seals so that bearings don't overheat. If seal is removed, replace with new seal.

Soak new rawhide seals in warm oil for one-half hour before using them, if possible. Put in wiper edge seal with wiper edge turned in direction recommended. When putting seals in place, use shims around shafts and shoulders.

REPAIR AND REPLACEMENT PROCEDURES (CONT)

(Sheet 3 of 3)

PACKINGS

Packing seals and O-rings (preformed packings) should always be replaced if they are removed from the mated part. To prevent leaks, put a coating of the lubricant being sealed on seals before putting them on the part.

GEARS

Always use the tools listed in the manual to work on gears. Always watch for damaged or worn teeth on gears.

Burs and rough spots should be removed with a honing stone or crocus cloth before putting gear in place. Lubricate mating surfaces before pressing gears on shafts.

SHAFTS

If a shaft does not come out easily, check that all nuts and capscrews have been removed. See if other parts are in the way before using force.

Shafts fitted to tapered splines should be very tight. If shafts are not tight, disassemble and check tapered splines. Discard parts that are worn. Make sure tapered splines are clean, dry, and free of burs before putting them in place. Press mating parts together tightly.

Clean off rust compound from all machined surfaces of new parts.

PARTS REPLACEMENT

Replace worn, damaged, or defective parts with new parts.

CLEANING (Sheet 1 of 1)

PARTS PROTECTION

Before cleaning, protect rubber items (hoses, boots, electrical insulation) from cleaning solutions. Protect them with a grease-proof barrier material. Remove the rubber part if it cannot be protected.

CLEANING PROCESS

Any cleaning method may be used as long as it does not damage a part. Cleaning is necessary so that parts can be checked. Rusted paint areas must be stripped to bare metal before repainting.

RUST OR CORROSION REMOVAL

Rust and corrosion can be removed with a wire brush, abrasive cloth, sand blasting, vapor blasting, or rust remover. Use buffing or a crocus cloth on highly polished parts that are rusted.

BEARINGS

Remove shields and seals from bearings before cleaning. Bearings with permanent shields and seals must not be cleaned in solution.

Clean open bearings by soaking them in a petroleum cleaning solution item 2 Appendix C. Never use a solution with chlorine in it.

Bearings should stand and dry. Do not use compressed air to dry. Do not spin bearings while they are drying.

ENGINE MAINTENANCE INSTRUCTIONS

This section covers removal and installation of the following engine components for Organizational Maintenance personnel:

- a. Pulley and vibration damperb. Engine crankcase breatherc. Oil filter linesd. Engine oil filterse. Valve covers

- f. Tachometer drive

Also instructions for engine lubrication and oil filter replacement.

(Sheet 1 of 1) LIST OF TASKS

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1	Engine lubrication.	2-152	2-38, 2-40
2	Pulley and vibration damper removal/installation.	2-155	2-41
3	Engine crankcase breather and fumes disposal assembly service.	2-158	None
4	Oil filter lines and oil filler assembly removal/installation.	2-161	None
5	Valve covers removal/installation.	2-165	None
6	Tachometer drive removal/installation.	2-167	None

ENGINE LUBRICATION (Sheet 1 of 3)

This task covers: Draining and refilling crankcase with oil. Replacing engine oil filters.

INITIAL SETUP

 Test Equipment
 Materials/Parts
 Troubleshooting Reference

 None
 Oil per LO 10-3930-641-12
 Pages 2-38, 2-40

 Oil filters
 Equipment Condition

 Suitable oil container, capable of holding 11 gallons (42 liters) of waste oil.
 Equipment Condition

 Engine OFF. Parking brake control OUT.
 Power switch OFF. Vehicle level.

 Shipping link installed

Special Tools Personnel Required

Strap wrench Two mechanics

References General Safety Instructions

LO 10-3930-641-12

Use caution when draining oil. Hot oil causes burns.

Engine crankcase breather service, page 2-158

Engine starting and stopping, TM 10-3930-641-10

PMCS, page 2-5

Shipping link removal/installation, page 2-471.

Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
1. Drain hose	Move to position outside crankcase guard.	
2. Drain valve (1)	a. Open.b. Drain oil into suitable container.c. Close.	
3. Drain hose	Place inside crankcase guard.	
4. Crankcase breathers	Check for clogging.	See ENGINE CRANKCASE BREATHER SERVICE, page 2-158.
		TA 098635
		Go onto Sheet 3

	LOCATION/ITEM	ACTION	REMARKS
5.	Oil filters	 a. Using strap wrench, remove two and discard. b. Clean filter mounting bases. Be sure old gaskets are completely removed. c. Apply film of clean engine oil to gaskets on new filters. d. Install filters snugly; hand tighten. NOTE One person should be in cab, while one person checks for leaks. 	ENGINE OIL FILL
6.	LOW ENG OIL indicator on operator's indicator panel	Test by turning POWER switch ON. Indicator should come ON.	
7.	Engine crankcase	Fill.	See LO 10-3930-641-12.
8.	Engine	Start and run at low idle.	
9.	Oil filter bases	Check for leaks	
10.	Oil level dipstick	Check oil level.	Oil level should be between LOW and FULL marks on LOW IDLE side of dipstick. If not, add oil.
11	. LOW ENG OIL indicator on operator's indicator panel	Should be off.	
12.	. Engine	Shut down.	TA 098636 End

PULLEY AND VIBRATION DAMPER REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Removal and installation of front engine pulley and vibration damper.

Materials/Parts Troubleshooting Reference Test Equipment

Page 2-41 None None

Equipment Condition

Engine OFF and cooled.

Parking brake control OUT.

Shipping link installed.

Personnel Required Special Tools Hood removed.

Two mechanics Guide bolt, 5/8-18 x 7

> References **General Safety Instructions**

PMCS, page 2-5 If engine is not completely cooled, parts may be hot. Handle carefully.

Torque limits chart, page E-1

Main disconnect switch OFF. Alternator belt adjustment, page 2-254

Shipping link removal/installation, page 2-471.

Hood removal/installation, page 2-452

TM 10-3930-641-20

PULLEY AND VIBRATION DAMPER REMOVAL/INSTALLATION (CONT)

(Sheet 2 of 3)

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		ADJUSTMENT NUTS
1. Fan drive belts	Remove from pulley (1). See page 2-229.	
2. Belt adjustment nut	a. Loosen mounting bolts (2).	
	b. Loosen adjustment nuts enough to remove belt.	
3. Alternator belt (3)	Remove.	
4. Capscrews (4)	Remove four from pulley.	
5. Pulley (1)	Remove.	If marks aline, install pulley and belts. If marks are not alined, replace vibration damper.
6. Vibration damper (6)	a. Check marks (5) for alinement.	6 5
		TA 098637 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
6. Vibration damper (cont) INSTALLATION	 b. Remove one capscrew (7). Install guide bolt 5/8-18 x 7, shown at (A). c. Remove five remaining capscrews (7). d. Remove damper (6). NOTE Adapter may come off with damper. e. Remove adapter from damper. 	Impact wrench may be used.
1. Vibration damper (6) and adapter NOTE	a. Position on crankshaft.b. Install five capscrews (7) and tighten.	
Install adapter first.	c. Remove guide bolt (A).	į į
instant daspeer inst.	d. Install sixth capscrew (7)	See TORQUE LIMITS CHART, page E-1.
2. Pulley (1)	Position on front of engine.	
3. CapsCrews (4)	Install four cap screws and tighten.	See TORQUE LIMITS CHART, page E-1.
4. Alternator belt (3)	Install and adjust. Tighten adjustment nuts (2). See page 2-254.	See ALTERNATOR BELT ADJUSTMENT, page 2-254.
5. Fan drive belts	Install. See page 2-229.	
		TA 098638 End

ENGINE CRANKCASE BREATHER AND FUMES DISPOSAL ASSEMBLY SERVICE

(Sheet 1 of 3)

This task covers: Removal, cleaning, and installation of crankcase breathers and fumes disposal assembly.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None Non-flammable cleaning solvent, item 2 None

Appendix C Gasket

O-ring

Equipment Condition

Engine OFF and cooled.

Mast lowered. Parking brake control OUT.

Side panel open.

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

PMCS, page 2-5

Handle lines and breathers carefully. Parts and oil may be hot. They can cause burns.

Main disconnect switch OFF.

	Lamzoni	DELICA DAG
LOCATION/ITEM	ACTION	REMARKS
1. Hose clamps (1)	Loosen.	
2. Hose (2) (fumes disposal group)	Remove.	2
3. Breather clamps (3)	Loosen.	
4. Breathers (4)	a. Remove breathers (4).	The second secon
	WARNING	
	Use solvents only in well ventilated areas. Fumes may be dangerous.	
	b. Wash breathers (4) in clean, non-flammable solvent.	4 4
	c. Allow breathers to dry.	3 3
	d. Replace O-ring inside breather.	TA 098639
	1	Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
4. Breathers (4) (cont)	e. Install.	
5. Breather clamps (3)	Position and tighten.	
6. Hose (2) (fumes disposal group)7. Capscrews (6), nuts (5) and washers securing brackets (8)	Check for damage. Replace if necessary. Remove.	5
8. Fumes disposal group (9 and 10)	Remove.	7
9. Fumes disposal group (9 and 10) and brackets (8)	Place in position and secure with capscrews (6), nuts (5) and washers.	6 50 7
10. Hose clamps (1)	Position and tighten.	10 8
		TA172221
		End

OIL FILTER LINE AND OIL FILLER ASSEMBLY REMOVAL/INSTALLATION

(Sheet 1 of 4)

This task covers: Removal and installation of engine oil filter lines and oil filler assembly.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None None

Equipment Condition

Engine OFF and cooled.

Access panels open.

Special Tools Personnel Required

None One mechanic

References General Safety Instructions


Torque limits chart, page E-1

Use caution in handling lines. Hot oil causes burns.

Protect parts of vehicle from oil spillage. Catch line oil in small pan or bucket.

Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL OIL FILTER LINE		
1. Hose nut (9)	Loosen four at oil filter end of each line.	
2. Clips and straps	Remove from frame and hoses.	
3. Hose nut (9)	Loosen at oil cooler end.	
4. Hose assembly (11), (12)	Remove.	
INSTALLATION		
1. Hose assembly (11), (12)	Position in vehicle.	
2. Hose nut (9)	Tighten four at oil cooler end.	See TORQUE LIMITS CHART, page E-1.
3. Clips and straps	Install on hoses and frame.	
4. Hose nut (9)	Tighten four at oil filter end.	See TORQUE LIMITS CHART, page E-1.
		Go on to Sheet 3



- 1. Capscrew
- 2. Support
- 3. Capscrew
- 4. Washer
- 5. Nut
- 6. Gasket
- 7. Capscrew
- 8. Flange
- 9. Capscrew
- 10. Washer
- 11. Hose Assembly
- 12. Hose Assembly
- 13. Seal
- 14. Adapter

TA 098640

LOCATION/ITEM	ACTION	REMARKS
OIL FILLER ASSEMBLY REMOVAL		1 2
1. Plug (1)	Remove.	2 3
2. Capscrews (5, 8, 11), washers (3) and nuts (2)	Remove.	4 5 3
3. Brackets (4) and (6)	Remove.	
4. Filler assembly (7)	Remove.	
5. Preformed packing (9)	Replace.	10
INSTALLATION		
1. Filler assembly (7) and brackets (6)	Place in position.	
2. Capscrews (9) and (5) and washers (3)	Install.	9————
3. Bracket (4)	Position on oil filler assembly (7) and dipstick tube.	
4. Bracket (4)	Secure with capscrew (11), nut (2) and washer (3).	3
5. Plug (1)	Install.	8
		TA 098641
		End

VALVE COVERS REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Replacement of engine valve covers.

INITIAL SETUP

Test Equipment Materials/Parts <u>Troubleshooting</u> Reference

None Gasket None

Non-flammable cleaning solvent, item 2 Appendix C

item 2 Appendix C Equipment Condition

Access panel open.

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

None Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Clamps (1) and (2) on breather tube connections.	Loosen. See page 2-158, Engine crankcase breather service. NOTE Step No. 1 is not necessary for right side.	5 2 3
2. Capscrews (3)3. Valve cover (5)	Remove. Remove.	
4. Breather tubes (6)	Remove four clips (7).	
5. Gasket (4)	Remove and discard. Clean gasket mating surface with cleaning solvent.	
INSTALLATION		5 -1 -4
1. Gasket (new)	Install.	9
2. Valve cover (5)	Place in position.	
3. Breather tubes (6)	a. Position tubes on engine.	
	b. Install clips (7).	70-30-60
4. Capscrews (3)	Torque in sequence to 13-23 lb. ft. (18-31 N•m).	TA 098642
5. Clamps (1) and (2)	Install and tighten.	End

TACHOMETER DRIVE REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal and installation of the tachometer drive.

INITIAL SETUP

Troubleshooting Reference Materials/Parts Test Equipment

None O-ring None

Equipment Condition

Engine stopped.

Personnel Required Special Tools

One mechanic None

> References **General Safety Instructions**

Steering wheel tagged "DO NOT OPERATE." None

Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Two capscrews (4), washers (5, and retainers (6)	Remove from fuel transfer pump body.	
2. Tachometer drive (3)	Remove.	2
3. O-ring seal (7)	Remove.	3 50-5
INSTALLATION		
1. O-ring seal (7)	Replace.	<u></u>
2. Tachometer drive (3)	Place in position on fuel transfer pump body.	1. Cap
3. Capscrews (4), washers (5) and retainers (6)	Install.	2. Washer 3. Tachometer drive 4. Capscrew 5. Lockwasher 6. Retainer 7. O-ring seal
		TA 098 64 3
		End

FUEL SYSTEM MAINTENANCE INSTRUCTIONS

This section covers removal and installation of these fuel system components for Organizational Maintenance personnel:

- a. Fuel injection linesb. Fuel linesc. Ether starting aid assemblyd. Fuel transfer pumpe. Fuel priming pumpf. Fuel filters

Fuel priming procedure Filter servicing instructions Service fuel tank Clean fuel tank filler and cap

(Sheet 1 of 1) LIST OF TASKS

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1	Fuel injection lines removal/installation.	2-170	None
2	Fuel lines and fittings removal/installation.	2-173	2-39, 2-41
3	Fuel transfer pump removal/installation.	2-177	None
4	Fuel priming pump removal/installation.	2-179	None
5	Priming the fuel system.	2-181	None
6	Primary fuel filter service.	2-183	2-37, 2-39
7	Secondary fuel air filter service.	2-186	2-37, 2-39
8	Ether starting aid removal/installation.	2-189	None
9	Fuel tank service.	2-193	2-37, 2-39
10	Clean fuel tank filler and cap and screen.	2-195	None

FUEL INJECTION LINES REMOVAL AND INSTALLATION

(Sheet 1 of 3)

This task covers: Removing and installing fuel injection lines.

None Tags None

Plugs

Equipment Condition

Engine shut down.

Hood removed.

Muffler removed.

<u>Special Tools</u> Personnel Required

5P144 Socket One mechanic

References General Safety Instructions

Hood removal, see page 2-452 Main disconnect switch OFF.

Muffler removal, see page 2-211 Do not smoke or have open flames or sparks around fuel or lines. Fuel may catch

PMCS, page 2-5 fire and cause burns.

Priming the fuel system, page 2-181 (Remove air from fuel system)

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. CapsCrews (1) that secure injection lines to support bracket	Remove.	3——————————————————————————————————————
2. Fuel injection lines (2)	Remove lines as an assembly, and change bad line(s) at bench. a. Tag to identify location on pumps and lines. b. Disconnect from pumps. c. Plug or cap lines and pumps to keep fuel system clean. d. Disconnect lines from valve cover base adapters (3).	
3. Injection lines (2)	e. Plug or cap adapters and lines. Remove. CAUTION Do not use bent or kinked injection lines.	TA 098644 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION	CAUTION	
1. Fuel injection lines (2)	If new lines are used for replacement, then remove identification tags from lines. Tags can cause wear on injection lines.a. Must be clean and dry.b. Position on engine and connect to correct injection pumps and valve cover base adapter(s).	
	c. Tighten nuts on lines to torque of 25-35 lb. ft. (34-48 N•m).	
2. Capscrews (1) that secure injection lines to support bracket	Install.	
3. Fuel system	Remove air by operating the priming pump.	See page 2-181.
		End

FUEL LINES AND FITTINGS REMOVAL/INSTALLATION

(Sheet 1 of 4)

This task covers: Removal and installation of fuel lines and fittings.

rest Equipment waterials/raits rroubleshooting Referen	Test Equipment	Materials/Parts	Troubleshooting Reference
--	----------------	-----------------	---------------------------

Preformed packings Pages 2-39, 2-41 None

Gaskets

Equipment Condition

Engine OFF and cooled

Access doors open

Personnel Required Special Tools

One mechanic None

> References **General Safety Instructions**

TORQUE LIMITS CHART, page E-1

Do not smoke or have open flames or sparks around fuel or lines. Fuel may catch fire and cause burns. PMCS, page 2-5

Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
	NOTE	
REMOVAL	The following procedures apply to any of the fuel lines and fittings.	
Connector nuts	Loosen at both ends of fuel line.	Connector nuts are at each end of each hose or tube assembly.
Lines/hoses	Remove.	
. Elbow nuts	Loosen.	Elbow nuts hold elbows tight to the base; they are screwed in.
. Elbows	Remove.	
. Preformed packings	Remove where installed.	
INSTALLATION		
. Preformed packings	a. Coat lightly with fuel oil.	
	b. Install.	
		Go on to Sho

FUEL LINES AND FITTINGS REMOVAL/INSTALLATION (CONT)


12. Connector

(Sheet 3 of 4)

1.	Elbow	14. Capscrew
2.	Preformed packing	15. Washer
	Washer	16. Nut
4.	Capscrew	17. Capscrew
5.	Fuel filter base cover	18. Washer
6.	Capscrew	19. Nut
	Washer	20. Bracket
8.	Elbow	21. Capscrew
9.	Gasket	22. Bracket
10.	Adapter	23. Adapter
	Preformed packing	24. Elbow
	Hose assembly	25. Pipe plug
	Fuel filter bracket	26. Hose assembly
	assembly	27. Connector

т.	Comicción	IW. COINICCEOI
	Seal	Seal
2.	Strap	13. Connector
3.	Hose assembly	14. Tube assembly
4.	Hose assembly	15. Union
5.	Connector	16. Tube assembly
6.	Tube assembly	17. Sleeve
	Clip	18. Bolt
8.	BoÎt	19. Tube assembly
9.	Lockwasher	20. Tube assembly
0.	Tube assembly	21. Connector
1.	Tube assembly	22. Tube assembly
	· ·	23. Clip

1. Connector



LOCATION/ITEM	ACTION	REMARKS
2. Elbows	Install.	
3. Elbow nuts	Tighten.	See TORQUE LIMITS CHART, page E-1.
4. Lines/hoses	Install.	
5. Connector nuts	Tighten.	See TORQUE LIMITS CHART, page E-1.
PUMP OVERFLOW LINE		
1. Capscrew (1), washer (2), and clip (3)	Remove.	5
2. Overflow line (4)	Slip off nipple (5) and replace.	
3. Capscrew (1), washer (2), and clip (3)	Install.	1 2 3
		TA 09864
		Er

FUEL TRANSFER PUMP REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Replacement of fuel transfer pump.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Gasket None

O-ring seal

Equipment Condition

Engine OFF

Access door open.

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

PMCS, page 2-5 Main disconnect switch OFF

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Fuel lines (1) and (3) 2. Two bolts that hold fuel transfer pump to injection pump rear plate 3. Fuel transfer pump	Disconnect from fuel transfer pump (2). Remove. Remove. NOTE Replace gasket and O-ring seal.	NOTE
INSTALLATION		Lift transfer pump up evenly to ease removal.
1. Gasket and fuel transfer pump (2)	a. Install new gasket and O-ring seal.	
	b. Place in position and rotate pump to align gears.	
2. Fuel lines (1) and (3)	Install.	
3. Two capscrews	Install.	
		TA 098647
		End

FUEL PRIMING PUMP REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Replacement of fuel priming pump.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Gasket None

Equipment Condition

Engine shut down

Access door open

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

PMCS, page 2-5 Main disconnect switch OFF

Do not smoke or have open flames or sparks around fuel or lines. Fuel may catch fire and cause burns.

	I OCATION (ITEM)	ACITION	DEMARKS
	LOCATION/ITEM	ACTION	REMARKS
1 Two	REMOVAL a canscrews (2) and (4) and two	Remove. See page 2-182 for location.	4——
	co capscrews (2) and (4) and two shers (1) and (3)		3——————————————————————————————————————
2. Prir	ning pump (5)	Remove.	
3. Gas	ket (6)	Discard and replace with new gasket.	
	INSTALLATION		2
			l a
1. Prir	ning pump (5) and gasket (6)	Place in position.	1————
2. Two was	o capscrews (2) and (4) and two shers (1) and (3)	Install.	1. Lockwasher 2. Capscrew
			2. Capscrew 3. Lockwasher 4. Capscrew 5. Priming pump 6. Gasket
			(0)
			End

(Sheet 1 of 2) PRIMING THE FUEL SYSTEM

This task covers: Using the fuel priming pump to prime the fuel system.

INITIAL SETUP

Troubleshooting Reference Materials/Parts Test Equipment

None None None

Equipment Condition

Engine shut down

Shipping link installed

Rear access door open

Special Tools Personnel Required

Two mechanics None

> References **General Safety Instructions**

Main disconnect switch OFF Shipping link removal/installation, page 2-471

Do not make or have open flames or sparks around fuel or lines. Fuel may catch fire and cause burns.

LOCATION/ITEM	ACTION	REMARKS
1. Priming pump	Unlock (turn handle counterclockwise ½ turn) and pump until you feel resistance.	
2. Priming pump	Lock pump (turn handle clockwise until it locks).	
3. Engine	Start and check system for leaks.	
		TA 09864
		Er

2-182

FUEL FILTER SERVICE - PRIMARY

(Sheet 1 of 3)

This task covers: Removing and cleaning or replacing the primary fuel filter element.

Test Equipment	Materials/Parts	Troubleshooting Reference

None	Gasket	Pages 2-37, 2-39
110110	ausiee	

Element

Equipment Condition

Dry cleaning solvent, item 2 Appendix $\,C\,$ Engine shut down

Access door open

Personnel Required Special Tools

One mechanic None

> References **General Safety Instructions**

Main disconnect switch OFF Priming the fuel system, page 2-181

Do not smoke or have open flames around fuel or lines. Fuel may catch fire and cause PMCS, page 2-5

burns.

gine running at high idle (accelerator held to floor), shut down vehicle and wash fuel filter. 1. Mounting nut (1) (Left rear of engine below air cleaner) See page 2-182 for location. gine running at high idle (accelerator held to floor), shut down vehicle and wash fuel filter. Loosen. 4. Bas 5. Valv 6. Lock 7. Eler 8. Reta 9. Reta 10. Spri 11. Gas	ket e assembly e ve assembly k ring ment assembly
b. Wash in clean, nonflammable solvent, item 2, Appendix C. c. Dry, using low pressure air (30 psi max.). 5. Gasket (11) Discard and replace with new gasket. 6. parts (4, 5, 8, 9, 10) Remove if required. 7. Case assembly (12) Clean in solvent, item 2, Appendix C.	ainer ang

(Sheet 3 of 3)

LOCATION/ITEM	ACTION	REMARKS
8. Parts (4, 5, 8, 9, 10)	Install if removed.	
9. Element (7)	Install in case assembly and secure with lock ring (6).	
10. New gasket (11)	Install.	
11. Case assembly (12)	Install.	
	NOTE	
	When changing the primary fuel filter is the only function being performed, the fuel pump must be primed before engine is started. Prime the pump while tightening the nut (1). See page 2-181.	
12. Nut (1)	Tighten.	
13. Engine	a. Start.	
	b. Check for fuel filter leaks.	
	c. Shut down.	
		End

FUEL FILTER SERVICE - SECONDARY

(Sheet 1 of 3)

This task covers: Replacing the secondary fuel filter.

Troubleshooting Reference Materials/Parts Test Equipment

None Dry cleaning solvent, item 2 Pages 2-37, 2-39

Appendix C

Equipment Condition

Engine shut down

Access door open

Personnel Required Special Tools

Strap wrench One mechanic

> References **General Safety Instructions**

Torque limits chart, page E-1 Main disconnect switch OFF

Do not smoke or have open flames around fuel or lines. Fuel may catch fire and cause Priming the fuel system, page 2-181 PMCS, page 2-5

burns.

(Sheet 2 of 3)

NOTE Change filter element when fuel pressure gage reads in RED area — engine running at high idle (accelerator held to floor). a. Remove, using strap wrench. b. Discard filter.	
	TA 098651 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
2. Base assembly (1)	a. Clean.b. Be sure all of old gasket is removed.	2
	NOTE Replace stud (3) if necessary.	
3. Gasket (5)	a. Lubricate with diesel fuel.b. Install.	<u></u>
	NOTE Fill new filter with clean, fresh fuel. This will	
4. Filter (4)	save time when priming the fuel system. a. Install.	4
	b. Tighten until gasket contacts base.c. Tighten ½ to ¾ turn more.	
5. Priming pump	Prime fuel system. See page 2-181.	 Base assembly Base Stud Filter Gasket TA 098652 End

ETHER STARTING AID REMOVAL/INSTALLATION

(Sheet 1 of 4)

This task covers: Replacement of ether starting aid components.

INITIAL SETUP

<u>Test Equipment</u> <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None None None

Equipment Condition

Engine shut down

Right side access panel open

Special Tools Personnel Required

None One mechanic


References General Safety Instructions

PMCS, page 2-5 Main disconnect switch OFF

Do not smoke or have open flames or sparks around fuel or lines. Fuel may catch fire and cause burns.


ETHER STARTING AID REMOVAL/INSTALLATION (CONT)

(Sheet 2 of 4)



- 2. Tube
 3. Capscrew
 4. Washer
 5. Clip

- 6. Grommet 7. Tube assembly
- 8. Tube
- 9. Capscrew 10. Connector
- 11. Sleeve
- 12. Nut
- 13. Capscrew 14. Washer
- 15. Valve assembly 16. Bracket
- 17. Clamp
- 18. Canister



LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
	NOTE	
	Remove parts only as needed for repair or replacement.	
1. Ether canister (18)	Remove if installed.	
2. Atomizer assembly (1)	Unscrew from intake manifold.	
3. Tubes (2), (7), and (8)	a. Remove by removing mounting hardware and clips.	
	b. Unscrew or disconnect as required	
4. Valve assembly (15)	a. Disconnect and tag wires.	
	b. Disconnect tube at connector (10).	
	c. Remove capscrews (13) and washers 14).	
5. Clamp (17)	Remove capscrews (3) and washers (14).	
6. Bracket (16)	Can be removed by removing remaining capscrews.	
		Go on to Sheet 4

(Sheet 4 of 4)

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION		
1. Bracket (16)	Install if removed.	
2. Clamp (17)	a. Install.	
	b. Install capscrews (3) and washers (14).	
3. Valve assembly (15)	a. Install.	
	b. Secure with capscrews (13) and washers (14).	
	c. Connect tube at connector (10).	
	d. Connect wires.	
4. Tubes (2), (7) and (8)	a. Install — screw in or connect.	
	b. Install mounting hardware and clips.	
5. Atomizer assembly (1)	Screw into intake manifold.	
6. Canister (18)	Install.	
		End

FUEL TANK SERVICE (Sheet 1 of 2)

This task covers: Fuel tank service.

INITIAL SETUP

Materials/Parts Test Equipment Troubleshooting Reference

None Container to catch sediment and moisture Pages 2-37, 2-39

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

> References **General Safety Instructions**

PMCS, page 2-5 Main disconnect switch OFF

Do not smoke or have open flames or sparks around fuel or lines. Fuel may catch fire and cause burns. Fuel system description, page 1-14

LOCATION/ITEM	ACTION	REMARKS
1. Drain valve on fuel tank	a. Place suitable container under drain valve.	
	Do not remove drain plug instead of opening drain valve.	DRAIN VALVE DRAIN
	b. Open.	PLUG
	c. Allow sediment and moisture to drain.	
	d. Close. WARNING	
	Do not smoke while adding fuel. Fumes from fuel are flammable.	
2. Fuel cap	a. Remove.	
•	b. Fill tank with DF-2 fuel oil.	
	c. Install cap.	

CLEAN FUEL TANK FILLER CAP AND SCREEN

(Sheet 1 of 2)

This task covers: Removing, inspecting, cleaning and installing the fuel tank filler cap and strainer screen.

INITIAL SETUP

Troubleshooting Reference Materials/Parts Test Equipment

None Solvent, item 2, Appendix C None

Diesel fuel, item 14, Appendix C

Equipment Condition Gasket

Engine stopped

Personnel Required Special Tools

One mechanic None

> References **General Safety Instructions**

Main disconnect switch OFF PMCS, page 2-8

Do not smoke or have open flames or sparks around fuel or lines. Fuel may catch fire and cause burns. Fuel system description, page 1-14.

LOCATION/ITEM	ACTION	REMARKS
1. Filler cap	 a. Remove. b. Disassemble. (1) Remove capscrew (1). (2) Remove gasket (2), baffle (3), two elements (4) and gasket (5). c. Wash cap and element in solvent. d. Squeeze element dry. e. Lightly oil element with diesel fuel. f. Assemble filler cap. (1) Put elements (4), gasket (2 and baffle (3) in place. (2) Fasten with capscrew (1). g. Replace gasket (5) if worn. 	FILLER CAP CAP 5
 Retaining ring and screen Screen, retaining ring, and filler cap 	a. Remove.b. Wash screen in solvent.Install.	SCREEN TA 098894

AIR INTAKE SYSTEM MAINTENANCE INSTRUCTIONS

This section includes organizational maintenance procedures for the air intake system as follows:

Air cleaner replacement Air cleaner and dust ejector service

(Sheet 1 of 1) LIST OF TASKS

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1	Air cleaner and dust ejector service.	2-198	2-36, 2-37, 2-40, 2-42
2	Air cleaner housing and elbow removal/installation.	2-206	None
3	Service air cleaner/precleaned.	2-208	2-36, 2-37, 2-40, 2-42

AIR CLEANER AND DUST EJECTOR SERVICE

(Sheet 1 of 8)

This task covers: Cleaning air filter housing, air filter elements, and dust ejector.

Removal Cleaning

Replacement Installation

INITIAL SETUP

Troubleshooting Reference Materials/Parts Test Equipment

Pages 2-36, 2-37, 2-40, 2-42 Non-sudsing detergent, item 18, Appendix C None

Tape, item 11, Appendix C

Equipment Condition Secondary filter element

Gasket

Engine OFF and cooled.

Lint-free cloth, item 16, Appendix C

Front hood removed

Access door open (behind cab)

Personnel Required Special Tools

One mechanic Air nozzle

> References **General Safety Instructions**

TORQUE LIMITS CHART, page E-1

PMCS, page 2-5

Hood removal/installation, page 2-452.


Be careful not to allow dust into engine. Dust will damage fuel injection unit.

Main disconnect switch OFF.

- 1. Pre-cleaner assembly
- 2. Nut
- 3. Screw

- Screw
 Body assembly
 Hood assembly
 Dust ejector assembly
 Clamp
 Hose
 Tube assembly

- 10. Nut 11. Adapter 12. Capscrew 13. Washer
- 14. Locknut
- 15. Gasket
- 15. Gasket
 16. Air cleaner assembly
 17. Cover assembly
 18. Gasket
 19. Primary element
 20. Secondary element
 21. Rod assembly
 22. Housing



TA 098656

Go on to Sheet 3

(Sheet 3 of 8)

LOCATION/ITEM	ACTION	REMARKS
DISASSEMBLY/CLEANING		See PMCS, page 2-5 for service interval.
1. Rod assembly (21)	Loosen.	
2. Cover assembly (17)	Remove. Wipe clean with cloth, or wash in water and non-sudsing detergent.	
3. Primary element (19)	Remove.	
	Do not reuse secondary element. Loose particles could damage fuel injection unit.	
4. Secondary element (20)	Remove locknuts (14) and washers (13) from studs. Then remove secondary element.	
5. Air inlet opening (in housing 22)	Cover with tape.	
6. Screw (3)	Loosen at hood assembly (5).	5
7. Hood assembly (5)	Remove. Wipe clean with cloth, or wash in water and non-sudsing detergent.	3 — TA 098657
		Go on to Sheet 4

LOCATION/ITEM	ACTION	REMARKS
8. Body assembly (4)	Wipe clean with cloth, or wash in water and non-sudsing detergent.	4—
9. Dust ejector (6)	a. Loosen clamps (7).	3—
	b. Remove hose (8).	Replace if defective. 2
	c. Remove nuts (10).	
	d. Remove tube (9).	
	e. Clean tube and hose with air (30 psi max.) or water.	7
10. Gasket (15)	a. Inspect. If damaged:	7
	b. Remove capscrews (12) and washers (13).	
	c. Remove housing (22).	\\\
	d. Replace gasket (15).	10
	e. Clean housing (22) with cloth or wash in non-sudsing detergent.	11-01-01-0
	f. Position housing (22) on manifold.	
	g. Install capscrews (12) and washers (13).	See TORQUE LIMITS CHART, page E-1.
		Go onto Sheet 5

LOCATION/ITEM	ACTION	REMARKS
LOCATION/ITEM 11. Housing (22) CLEANING ELEMENT	Do not wash housing with water or clean with pressure air when it is on manifold. Dirt particles could be forced into engine. Wipe clean with cloth. WARNING Wear face shield and protective clothing to	——————————————————————————————————————
	prevent injury when using pressure air or water. Use 30 psi maximum for cleaning. CAUTION Do not bump or tap element to clean. Do not use element with damaged pleats, gaskets, or seals. Discard damaged elements.	12 13 14 20
	NOTE Use pressure air, pressure water, or detergent as necessary to clean primary element. Replace primary element after six cleanings or yearly.	15 TA 09889 Go on to Sheet 0

LOCATION/ITEM	ACTION	REMARKS
CLEANING ELEMENT		
1. Pressure air	a. Direct pressure air along length of inside pleats and along length of outside pleats of element (19).	
	b. Again direct air along inside pleats.	
	c. Inspect element for cleanliness, rips, or tears.	
2. Pressure water	a. Direct pressure water [40 psi (280 kPa) maximum] along length of inside pleats and along length of outside pleats of element (19).	
	b. Again direct water along inside pleats.	
	c. Allow to dry.	
	d. Inspect element for cleanliness, rips, or tears.	
3. Detergent	a. Wash element in warm water and non- sudsing household detergent.	
	b. Rinse well with clean water.	
	c. Allow to dry.	
	d. Inspect element for cleanliness, rips, or tears.	
		Go onto Sheet 7

LOCATION/ITEM	ACTION	REMARKS
4. Light bulb ASSEMBLY	Insert into element when dry. If light shows through rips or tears, discard element. If light does not show through, reuse element.	7 8 6
	Desition between muffler and pre-cleaner	
1. Dust ejector (6)	Position between muffler and pre-cleaner.	9
2. Nuts (10)	Install.	
3. Hose (8)	Install.	
J. 11036 (0)		
4. Clamps (7)	Tighten.	
5. Hood assembly (5)	Install.	5
6. Screw (3)	Tighten.	3——
7. Air inlet opening	Remove tape.	1—
7. An infet opening	remove tape.	4
		3
		7 TA 098896
		Go on to Sheet 8

LOCATION/ITEM	ACTION	REMARKS
8. Secondary element (20)	Install with washers (13) and locknuts (14).	18
9. Primary element (19)	Install.	14 13 12
10. Cover (17)	Install.	17
11. Rod assembly (21)	Tighten.	20
12. POWER switch	Turn ON.	15 22 21 16
13. Engine	Start	PLUGGED FILTER AIR indicator should remain OFF.
14. Engine	Stop.	
15. POWER switch	Turn OFF.	
		TA 098895
	I	End

AIR CLEANER HOUSING AND ELBOW REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal and installation of air cleaner housing and elbow.

INITIAL SETUP

Test Equipment Troubleshooting Reference

None None None

Equipment Condition

Precleaner removed.

Hood removed.

Engine OFF.

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Torque Limits Chart, page E-1 Main disconnect switch OFF.

Air Cleaner Service, page 2-198

Hood removal/installation, page 2-454.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Wire assembly	Disconnect from air cleaner sensing unit (1).	
2. Clamps (2)	Loosen.	3 2
3. Capscrews (3)	Remove.	
	NOTE	
	Weight of air cleaner housing and elbow is 50 lb (23 kg).	
4. Air cleaner housing and elbow	Remove as a unit.	If disassembly is required, see Air Cleaner Service, page 2-198.
INSTALLATION		
1. Air cleaner housing and elbow	Position in engine compartment.	
2. Capscrews (3)	Install.	See TORQUE LIMITS CHART, page E-1.
3. Clamps (2)	Tighten.	
4. Wire assembly	Connect to air cleaner sensing unit (1).	та 098658 End

SERVICE AIR CLEANER/PRECLEANER

(Sheet 1 of 2)

This task covers:

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Lint-free cloth, item 16, Appendix C Pages 2-36, 2-37, 2-40, 2-42

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

PMCS, page 2-5 Main disconnect switch OFF.

(Sheet 2 of 2)

2-209

LOCATION/ITEM	ACTION	REMARKS
Rain cap and screen	 a. Remove. b. Clean rain cap, screen and precleaner housing if dirty. Use a clean rag. c. Reinstall. 	RAIN CAP PRECLEANER
		TA 09865 En

EXHAUST SYSTEM MAINTENANCE INSTRUCTIONS

This section covers removal and installation of these exhaust system components for Organizational Maintenance personnel:

- a. Muffler
- b. Exhaust pipe

LIST OF TASKS (Sheet 1 of 1)

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1	Exhaust pipe and muffler removal/installation.	2-211	None
		1	End

EXHAUST PIPE AND MUFFLER REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Removal and installation of exhaust pipe and muffler.

INITIAL	SETUP
---------	--------------

Special Tools

<u>Test Equipment</u> <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

Personnel Required

References

None None None

Equipment Condition

Engine OFF and cooled.

Hoods removed.

Left side access cover open.

One much sub-

Hoist One mechanic

General Safety Instructions

Air cleaner and dust ejector removed.

TORQUE LIMITS CHART, page E-1 Handle pipe and muffler carefully. Hot parts burn.

PMCS, page 2-5

Hood removal/installation, page 2-454.

Air cleaner and dust ejector service, page 2-198.

Main disconnect switch OFF.

Go on to Sheet 2

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Hood	Remove.	See page 2-454.
2. Clamp (1)	Remove.	
3. Exhaust pipe (2)	Remove.	5
4. Clamp (3)	Loosen.	7
5. Hoist	NOTE Weight of muffler is 165 lb. (75 kg). Be prepared for that weight when capscrews are removed.	3
6. Capscrews (4) and nuts	Remove from elbow support.	
7. Muffler (5)	Remove.	
		TA 098660
		Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
8. Clamp (6)	Loosen.	
9. Elbow (7)	Remove.	Replace parts as necessary.
INSTALLATION		
1. Elbow (7)	Install.	
2. Clamp (6)	Tighten and torque to 18 ±5 lb. ft (24 ±7 N $^{\bullet}$ m).	
3. Muffler (5)	Position in engine compartment.	
4. Capscrews (4)	Install and tighten.	See TORQUE LIMITS CHART, page E-1.
5. Clamp (3)	Tighten and torque to 18 ±5 lb. ft. (24 ±7 N $^{\bullet}$ m).	
6. Exhaust pipe (2)	Install.	
7. Clamp (1)	Tighten and torque to 18 ±5 lb. ft. (24 ±7 N $^{\bullet}$ m).	
8. Hood	Install.	See page 2-454.
9. Air cleaner and dust ejector.	Install	See page 2-198.
		Enc

COOLING SYSTEM MAINTENANCE INSTRUCTIONS

This section covers removal and installation of these cooling system components for Organizational Maintenance personnel:

a. Water pump b. Fan

e. Hoses, lines and fittings f. Fan belts

c. Fan drive mechanism

g. Water temperature regulators (thermostats) h. Coolant filter

d. Fan belt tightener (tensioner)

Also instructions for draining and refilling the cooling system.

LIST OF TASKS

(Sheet 1 of 1)

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1 2 3 4 5 6 7 8	Coolant replacement. Water temperature regulators (thermostats) removal/installation. Water temperature regulators testing. Water pump removal/installation. Fan belt set removal/installation. Fan belt tightener (tensioner) removal/installation. Fan assembly removal/installation. Fan drive mechanism removal/installation. Radiator rear guard removal/repair/installation.	2-215 2-218 2-223 2-225 2-229 2-231 2-233 2-236 2-242	2-38 None None None 2-41 None 2-41 2-41 None
10 11 12	Coolant filter base assembly removal/installation Hoses, lines and fittings removal/installation. Fan guards removal/installation.	2-244 2-247 2-249	None None None

COOLANT REPLACEMENT (Sheet 1 of 3)

This task covers: Draining and refilling cooling system with coolant.

INITIAL SETUP

Test Equipment	Materials/Parts	Troubleshooting Reference
None	Antifreeze solution per MIL-A-46155 (28 gal.), item 1, Appendix C	Page 2-38
		Equipment Condition
		Engine turned off and cooled.
		Left rear access panel open.
Special Tools	Personnel Required	
None	One mechanic	
	References	General Safety Instructions
	TM 750-254	Open radiator cap slowly to allow steam to escape.
		Be careful. Steam burns.
		Avoid contact with coolant.
		The alkaline solution can harm skin and eyes.
		Main disconnect switch OFF.

Go on to Sheet 2

LOCATION/ITEM	ACTION	REMARKS
Antifreeze	Mix antifreeze solution to lowest expected temperature.	MIL-A-46153.
DRAIN SYSTEM		
1. Drain valve (1)	Open and drain coolant into suitable container.	Be sure cooling system drain hose (2) is through hole in crankcase guard.
2. Precharge element (coolant filter canister) FILL SYSTEM	Remove. (See page 2-244.)	
1. Antifreeze	Add to fill radiator.	
2. Engine	Start and run with radiator cap (3) off to remove air bubbles from system.	
3. Precharge element (coolant filter canister)	Replace. (See page 2-244.)	TA 098661
		Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
3. Radiator cap (3)	a. Install.	
	b. Operate engine for 5 minutes.	
	c. Let engine cool.	
	d. Recheck level of antifreeze.	
		En

WATER TEMPERATURE REGULATORS REMOVAL/INSTALLATION

(Sheet 1 of 5)

This task covers: Replacement of water temperature regulators (thermostats).

INITIAL SETUP

Test Equipment Materials/Parts <u>Troubleshooting</u> Reference

None Lip seals (2) None

Equipment Condition

Coolant drained to below level of water

temperature regulators.

Special Tools Personnel Required

Seal driver One mechanic

References General Safety Instructions

Let engine cool.

Coolant replacement, page 2-215 Main disconnect switch OFF.

(Sheet 2 of 5)

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Coolant	Drain to level below water temperature regulators.	
2. Elbow (1)	a. Remove capscrews and elbow.	
	b. Remove dipstick for filter.	3
3. Two hose clamps (2)	Loosen.	
4. Hose	Slide up on tube assembly.	
5. Cover assembly (3)	Remove.	
6. Water temperature regulator	Remove from left cylinder head.	5
7. Lip seal	Discard.	
		TA 098662
		Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
8. Two bolts (4)	Remove.	6
9. Tube assembly (5)	Turn away from cover assembly for water temperature regulator.	4
10. Two clamps (6)	Loosen.	
11. Hose	Slide up on tube assembly.	5
12. Cover assembly (7)	Remove.	
13. Water temperature regulator	Remove from right cylinder head.	7
14. Lip seal	Discard.	
		TA 098663
		Go on to Sheet 4

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION		
1. New lip seals	Install using a seal driver	Seal should make contact with counterbore. Lip of seal away from regulator.
2. Right water temperature regulator	Install.	
3. Cover assembly (7)	Install.	
4. Hose	Slide into position on cover assembly.	
5. Clamps (6)	Tighten.	
6. Tube assembly (5)	Connect to cover assembly.	
		6
		7
		5
		TA 098664
		Go on to Sheet 5

LOCATION/ITEM	ACTION	REMARKS
7. New water temperature regulator	Install.	
8. Cover assembly (3)	Install.	5-7
9. Hose	Slide into position on cover assembly.	2
10. Clamps (2)	Tighten.	
11. Elbow (1)	Install.	3
12. Cooling system	Fill	See page 2-215.
		TA 098665
		End

WATER TEMPERATURE REGULATOR TESTING

(Sheet 1 of 2)

This task covers: Test of water temperature regulators (thermostats).

INITIAL SETUP

Materials/Parts Troubleshooting Reference Test Equipment

Pan of water None Thermometer

Source of heat

Equipment Condition Two bricks

Temperature regulators removed from machine.

Personnel Required Special Tools

One mechanic None

> References **General Safety Instructions**

Main disconnect switch OFF. Water temperature regulators removal/installation, page 2-218.

LOCATION/ITEM	ACTION	REMARKS
TEST		
1. Temperature regulator (1)	Suspend in pan of water.	2
2. Thermometer (2)	Suspend in pan of water.	
3. Water	Heat to 197°F (92°C).	1
	NOTE	
	Regulator should begin to open at this point.	
4. Water	Heat until boiling.	Constant Constant
	NOTE	
	Regulator should open all the way. If it doesn't, discard the regulator and replace it.	
		TA 098666
		End

WATER PUMP REMOVAL/INSTALLATION

(Sheet 1 of 4)

This task covers: Replacement of water pump.

INITIAL SETUP

Troubleshooting Reference Test Equipment Materials/Parts

None None None

Equipment Condition

Coolant drained from system.

Panel over water pump removed, left side of vehicle.

Fan assembly and guard may be removed

if necessary.

Engine OFF and cooled.

Personnel Required **Special Tools**

One mechanic None

> References General Safety Instructions

Engine must be cool. PMCS, page 2-5

Coolant replacement, page 2-215

Fan removal/installation, page 2-233

Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		This will permit belt tightener to move away from water pump.
1. Vee belt set	Remove (see page 2-229).	
2. Heater hose (2 each) (1)	Tag and disconnect from housing assembly.	
3. Clips holding hoses to water cooler	Disconnect from valve assembly.	2
4. Housing assembly	Disconnect hose going from housing assembly to inlet elbow on radiator.	3
5. Housing assembly capscrews (2)	Remove.	
	NOTE Be sure all capscrews are removed.	4
6. Housing assembly (3)	Remove.	
7. Four capscrews (4) at outlet side	Remove.	TA 098667 Go on to Sheet 3

WATER PUMP REMOVAL/INSTALLATION (CONT)

LOCATION/ITEM	ACTION	REMARKS
8. Nuts (5) 9. Grease line and clip at fan drive 10. Water pump INSTALLATION 1. Water pump (6) 2. Nuts (5)	Remove from behind water pump. NOTE Be aware of capscrew in seven o'clock position. It is difficult to remove. Remove. Remove. Put in position. Install.	5
3. Four capscrews (4) at outlet side	Install.	TA 098668 Go on to Sheet 4

2-227

LOCATION/ITEM	ACTION	REMARKS
4. Housing assembly (3)	Install.	
5. Capscrews (2) to hold it	Install.	$(((\circ)))$
6. Hose going from water pump to inlet elbow on radiator	Install.	
7. Grease line and clip	Install.	1
8. Heater hose (1)	Connect.	3
9. Heater hose clips	Install on cooler.	
10. Vee belt set for fan	Install.	See page 2-229.
11. Panel assembly over water pump	Install. The panel is located on the left side of vehicle.	
12. Cooling system	Fill with coolant.	See page 2-215.
		TA 098669
		End

FAN BELT SET REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Replacement of fan belt set.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None One fan belt set (three belts) Page 2-41

Equipment Condition

Access panel open.

Special Tools Personnel Required

Pry bar One mechanic

<u>References</u> General Safety Instructions

PMCS, page 2-5 Main disconnect switch OFF.

(Sheet 2 of 2)

LOCATION/ITEM	ACTION	REMARKS
1. Fan belt tightener (1)	Use pry bar (insert at point A) to put pressure on top of fan belt tightener, moving tightener down, and remove fan belt set (2).	When replacing worn or damaged fan belts, the entire set of 3 must be replaced at the same time. See TM 750-254.
1. Fan belt tightener (1)	Put pressure on top of fan belt tightener and put on new fan belt set (2).	TA 098671

2-230

FAN BELT TIGHTENER REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Fan belt tightener replacement.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None None

Equipment Condition

Engine shut down.

Special Tools Personnel Required

Pry bar One mechanic

References General Safety Instructions

LO 10-3930-641-12 Main disconnect switch OFF.

Fan belt removal/installation, page 2-229

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1 Three fan belts	Remove.	
 Cotter pin and pin (3), spring (1) 	Remove. WARNING	
3. Plate, washer and capscrew (2)	Spring tension may be present. Remove.	2
4. Fan belt tightener (4)	Remove.	
INSTALLATION 1. Fan belt tightener (4)	Put in position on fan drive bracket and install	
2. Spring (1), pin and cotter pin (3)	plate, washer, and capscrew. Install.	4
3. Three belts	Install.	See page 2-229.
4. Fan belt tightener	Grease.	See LO 10-3930-641-12. TA 098672 End

FAN ASSEMBLY REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Replacement of fan assembly.

INITIAL SETUP

<u>Test Equipment</u> <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None O-ring seal Page 2-41

Equipment Condition

Engine turned OFF.

Special Tools Personnel Required

Hoist One mechanic

Suitable container

<u>References</u> <u>General Safety Instructions</u>

Fan guards removal/installation, page 2-249

Use hoist to lift assembly.

Work only on cool engine.

Main disconnect switch OFF.

REMOVAL 1. Rear hood Remove. See page 2-454.	
2. Cooling system Drain coolant from cooling system to below level of tube assemblies. (See page 2-215.)	2
3. Channel assembly (1) a. Mark channel position.	
b. Remove.	
4. Tube assemblies (2) Remove from radiator top tank.	
5. Fan guards (3) Remove.	
CAUTION	
Guard will drop when last bolt is removed.	
NOTE	
	· · · · · · · · · · · · · · · · · · ·
Mark guards right/left, upper/lower. Weight of fan assembl	y is 95 lbs.
6. Fan belts (7) Remove.	5
7. Hoist Fasten to fan assembly (4).	
8. Nuts and bolts (5) Remove from adapter (6).	
9. Fan assembly a. Remove.	4
CAUTION	
Don't let fan hit radiator.	6
	7 (
b. Discard O-ring seal on fan drive bearing.	Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION		4
1. New o-ring seal	Install on fan drive bearing.	
2. Hoist	a. Fasten to fan drive assembly.	6
	b. Position fan assembly (4).	
3. Nuts and capscrews (5)	a. Install to hold fan assembly (4) and adapter (6) in position.	CAUTION
	b. Lubricate assembly.	Do not let fan assembly (4) touch hydraulic oil cook core assembly. Contact can cause damage.
4. Fan belts (7)	Install.	tore assembly. Contact can cause damage.
5. Fan guards (3)	Install.	1
6. Tube assemblies (2)	Install to radiator tank top. Use new gaskets.	
7. Channel assembly (1)	Install.	3
8. Cooling system	Fill with coolant to correct level.	See page 2-215.
9. Rear hood	Install.	See page 2-454.
		End

FAN DRIVE MECHANISM REMOVAL/INSTALLATION

(Sheet 1 of 6)

This task covers: Replacement of fan drive mechanism.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Preformed packing Page 2-41

Equipment Condition

Rear hood removed. Fan assembly removed. Fan guards removed.

Special Tools Personnel Required

Hoist One mechanic

References General Safety Instructions

Hood removal, page 2-454. Main disconnect switch OFF.

Fan guards removal/installation, page 2-249. Fan assembly removal/installation, page 2-233.

Fan belt tightener removal/installation, page 2-231.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL	CAUTION	
1. Channel assembly.	In course of disassembly fan assembly will be rested against hydraulic oil cooler core. Place carefully so as not to damage core. a. Mark channel position. b. Remove from above fan assembly.	Fan assembly weight is 95 lbs. (43 kg)
2. Fan guards	Remove.	
3. Hoist	Fasten to fan assembly (1).	
4. Fan drive capscrews (4)	Remove.	
5. Fan assembly	Remove.	3
6. Three belts (2)	Remove from fan drive.	
7. Spring (6)	Disconnect.	4
8. Belt tightener cotter pin (3)	Remove.	TA 098675
		Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
9. Hub assernbly retainer and two capscrews (5)	Remove	
10. Hub assembly (5)	Remove, holding pulley (7) in position.	5
	NOTE	
	Use gear puller if required (caution must be taken not to damage shaft if puller is used).	
11. Pullar (7)		9 10 5 S 11 8
11. Pulley (7)	Remove.	
12. Spacer (8)	Remove from fan drive bracket.	
13. Preformed packings, bearings (9), spacer (10) and seal (11)	Remove from hub (5).	
14. Belt tightener	Remove.	See page 2-231. TA 098898 Go on to Sheet 4

(Sheet 4 of 6)

LOCATION/ITEM	ACTION	REMARKS
15. Fan drive bracket grease line (12)	a. Remove clip.b. Disconnect grease line.	13 14
16. Fan drive bracket bolts (13)	Remove.	
17. Fan drive bracket (14) INSTALLATION	Remove.	"12
1. Fan drive bracket (14) and bracket bolts (13)	Install.	
2. Grease line (12)	a. Connect grease line,	
	b. Attach clip.	
3. Fan belt tightener	Install.	See page 2-231.
		TA 098677
		Go on to Sheet 5

LOCATION/ITEM	ACTION	REMARKS
4. Seal (11)	Install in hub, lip toward the outside.	
5. Small bearing (9)	Install in hub.	
6. Spacer (10)	Install on fan drive bracket with chamfer toward radiator.	B B
7. Pulley (7)	Install on fan drive bracket.	5 W PR
8. Inner bearing (9) and hub (5)	Install, holding pulley in position.	
9. Spacer (10), outer bearing (9) and preformed packings	Install.	
10. Hub assembly retainer and two capscrews (5)	Install using loctite.	
11. Belt tightener spring (6)	Install, using pin and cotter pin.	
12. Three belts (2)	Install on fan drive pulley.	
13. Fan assembly (1)	Hoist into position and install.	
14. Three capscrews	Install.	TA 098678
	!	Go on to Sheet 6

LOCATION/ITEM	ACTION	REMARKS
15. Fan guards	Install.	See page 2-249.
16. Channel assembly	Install and observe marking.	
17. Fan drive mechaism	Grease.	See LO 10-3930-641-12.
18. Fan belt tightener	Grease.	See LO 10-3930-641-12. LUBE FAN
19. Rear hood	Install.	See page 2-454. LUBE BELT TIGHTENER DRIVE TA 098899

RADIATOR REAR GUARD REMOVAL, REPAIR AND INSTALLATION

(Sheet 1 of 2)

This task covers: Removal, repair and installation of the radiator rear guard

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None None None

Equipment Condition

Engine OFF.

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

TM 9-450 Main disconnect switch OFF.

RADIATOR REAR GUARD REMOVAL, REPAIR AND INSTALLATION (CONT)

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Capscrew (4), washer (5), spacer (6), and nut (2) 2. Rear guard section (3), (1) REPAIR 1. Rear guard section (3), (1)	Remove. Remove. Straighten bent louvers or frame. Reweld any broken welds.	
1. Rear guard section (3), (1) 2. Capscrew (4), washer (5), spacer (6), and nut (2)	Position. Install.	TA 098679 End

COOLANT FILTER BASE ASSEMBLY REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Replacement of coolant filter base assembly.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None Coolant filter None

Equipment Condition

Engine OFF and cooled. Right access panel open.

Drain coolant below level of lowest hose

opening.

Special Tools Personnel Reauired


None One mechanic

References General Safety Instructions

Drain coolant. See page 2-216. Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Coolant filter canister (11)	Remove by unscrewing counterclockwise with strap wrench.	
2. Inlet (3), outlet (3)	a. Disconnect lines at fittings (2).	
	b. Tag for identification.	
	c. Cap lines.	
3. Two capscrews (12), washers (13) and nuts (14)	Remove from bracket.	
INSTALLATION		
1. Two capscrews (12), washers and nuts (14)	Install in bracket.	
2. Inlet (3), outlet (3)	Connect lines at fittings (2).	
3. Coolant filter canister (11)	Install.	
	a. Wet gasket with coolant.	
	b. Screw canister clockwise onto base. Tighten with strap wrench.	
4. Coolant level	Check and fill as required.	See page 2-216.
		Go on to Sheet 3

- 1. Valve assernbly
- 2. Elbow
- 3. Hose assembly
- 4. Strap
- 5. Elbow
- 6. Connector
- 7. Pipe plug
- 8. Base assembly
- 9. Stud
- 10. Base
- 11. Precharge element
- 12. Capscrew
- 13. Washer
- 14. Nut



TA 098680

End

HOSES, LINES AND FITTINGS REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Replacement of hoses, lines and fittings.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Gasket None

Hose

Equipment Condition

Engine OFF and cooled.

Special Tools Personnel Reauired

None One mechanic

References General Safety Instructions

PMCS, page 2-5 Main disconnect switch OFF.

(Sheet 2 of 2)

LOCATION/ITEM	ACTION	REMARKS
· Cooling system	Drain.	See page 2-216.
2. Hose, line or fitting.	Replace as required.	See page 1-12 and TM 10-3930-641-20P for parts location and identification.
3. Hose, line or fitting gasket	If gasket is on unit, always replace.	Old gasket is deformed and will not form satisfactor seal.
4. Cooling system	Fill cooling system with coolant.	See page 2-216.

FAN GUARDS REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal/instalation of the fan guards.

INITIAL SETUP

Test, Equipment Materials/Parts <u>Troubleshooting Reference</u>

None None None

Equipment Condition

Engine OFF.

Rear hood removed.

Left, and right access panel removed.

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Main disconnect switch OFF.

Hood removal/installation, page 2-454.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Capwscrews (1) 2. Fan guards (2)	Remove.	2
2. Fan guards (2) INSTALLATION 1. Fan guards (2)	Place in position.	
2. CapScrews (1)	Install.	
		TA 0986 Er

ENGINE ELECTRICAL COMPONENTS MAINTENANCE

This section covers removal and installation of the following engine electrical components:

- a. Alternator
- b. Starting motor
- c. Starting solenoid
- d. Engine oil pressure sending unit
- e. Engine water temperature sending unit

LIST OF TASKS (Sheet 1 of 1)

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1	Alternator removal/installation.	2-252	2-102
2	Alternator testing/adjusting.	2-255	2-85
3	Stating motor removal/installation.	2-258	2-79
4	stating solenoid removd/installation/ adjustment.	2-261	2-79
5	Engine oil pressure sending unit removal/installation.	2-264	2-140
6	Engine water temperature sending unit removal/installation.	2-266	2-140
			End

ALTERNATOR REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Removal and installation of alternator.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None Page 2-102

Equipment Condition

Right rear lower side access cover removed.

Special Tools Personnel Reauired

None One mechanic

References General Safety Instructions

Torque Limits Chart, Page E-1.

Turn main disconnect switch to OFF to

avoid shocks.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Wires (1) 2. Nuts (2) 3. Belt (3)	Mark three wires for location and disconnect. (Only ground wire is shown at right.) Loosen. Remove.	TO GROUND 2
4. Capscrew (4)	Loosen. CAUTION Hold alternator to keep it from falling.	CRANKSHAFT
5. CapScrews (5) 6. Alternator (6) INSTALLATION	Remove. Remove.	PULLEY
1. Alternator	Position on mounting bracket.	
2. Capscrews (5)	Install. Tighten finger tight.	TA eesse 2 Go on to Sh eet 3

LOCATION/ITEM	ACTION	REMARKS
3. Capscrew (4)	Install and tighten to 49-63 lb. ft. (66-85 N•m).	
4. Belt (3)	a. Install.	
	b. Adjust by moving nuts (2) and block (7) along alternator adjustment rod (8).	Belt should deflect no more than 9/16 to 13/16 when 25 lbs. of pressure is applied midway along top of belt.
5. Capscrews (5)	Tighten to 21-27 lb. ft. (28-37 N•m).	
6. Nuts (2)	Tighten to 105-115 lb. ft. (142-156 N•m).	
7. Wires (1)	Connect. Be sure to attach in locations marked in Item 1.	Tighten output terminal to 9-11 lb. ft. (12-15 N.m).
		End

ALTERNATOR TESTING/ADJUSTMENT (Sheet 1 of 3)

This task covers: Alternator voltage adjustment and operation tests.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

Multimeter None Page 2-85

Equipment Condition

Lower right engine access cover removed. Upper right rear engine access cover open.

Special Tools Personnel Required

One mechanic Torque wrench

References

Battery testing, page 2-269.

Battery cable removal, repair and installation, page Ž-279.

Operator's cab instrument checks, $TM\ 10-3930-641-10$.

General Safety Instructions

Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
TESTING	NOTE	
	Before testing alternator for malfunction, be sure the following conditions are met:	
	a. Battery is at 75% charge (1.240 Sp. Ga.).	See Battery Testing, page 2-270.
	b. Proper size battery cables are installed, free from corrosion and properly connected.	See Battery Cable Removal, Repair, and InstaHatim, page 2-282.
	c. Leads, junctions, switches and panel instruments work properly.	See Operator Cab Instrument Checks, TM 10-3930 - 641-10.
	d. Alternator belt is properly adjusted and not overly worn.	
1. Pulley nut (1)	Check torque. Tighten to 70-80 lb. ft. (95-109 N•m).	
		TA 098683
	1	Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
2. Alternator wires	 a. Tum main disconnect to ON. b. Connect multimeter positive lead to terminal marked + where orange wires connect. Check voltage output to ground. 	b. Voltage should be 26-30 volts (28 V ideal).
	c. Conned multimekr positive lead to terminal R where light blue wire connects.	c. Voltage should be 12 volts.
ADJUSTMENT 1. Access plate	Remove.	ADJUSTMENT KNOB
2. Adjustment knob	H alternator Chmges too much or too little, turn adjustment knob with screwdriver.	
	1	
		TA 098684
	I	I / \ End

STARTING MOTOR REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Removal and installation of starting motor.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Starting motor Pages 2-39, 2-79

Equipment Condition

Front hood and right side access cover

removed.

Special Tools Personnel Required

Hoist One mechanic

References <u>General Safety Instructions</u>

Torque Limits Chart, page E-1. Main disconnect switch OFF.

Hood removal/installation, page 2-454.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Panel (1)	a. Tag and disconnect three wiring harnesses from back side of panel.b. Remove four screws, Iockwashers, and nuts (2) which hold panel (1) to frame.	
 Capscrew, washer, and nut. Capscrew Capscrews (4) 	c. Move panel (1) aside. Remove from clip (3) Remove capscrew and upper clamp from oil filler tube (6).	HARNESS CONNECTORS 2
4. Capscrews (4)5. Oil filler tube (6) and gasket	Remove.	A CO
6. Motor and solenoid wires (7), (8)	Loosen three capscrews (9). Mark for location and disconnect. CAUTION Weight of starting motor is 75 lb. (34 kg). Be yepared to hold motor when capscrews are ?emoved.	
7. Capscrews (9)	Loosen three capscrews (9).	
8. Motor	Attach lifting sling.	8 TA 098685 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
9. Capscrews (9)	Remove. Remove top capscrew last.	
10. Starting motor	Lift out of vehicle.	
INSTALLATION		
1. Starting motor	Position motor at flywheel housing.	
2. Capscrews (9)	Install and tighten three capscrews. Start top capscrew first.	See Torque Limits Chart, page E-1.
3. Motor and solenoid wires (7), (8)	Connect. Be sure to reconnect them in the positions marked before they were disconnected.	Tighten terminal nuts to 16-30 lb. in. (2-3.5 N•m).
4. Oil filler tube (6) and gasket	Position at side of engine.	
.5. Capscrews (4)	Install and tighten two screws.	See Torque Limits Chart, page E-1.
6. Capscrew and upper clamp	Install.	See Torque Limits Chart, page E-1.
7. Capscrew, washer, and nut	Install in clip (3).	
8. Panel (1)	a. Position on frame.	
	b. Install four capscre ws, washers and nuts (2) holding panel to frame.	Black - Top
	c. Connect wiring harnesses to back.	Red - Center Dark Blue - Lower

STARTING SOLENOID REMOVAL/INSTALLATION/ADJUSTMENT

(Sheet 1 of 3)

This task covers: Removal, installation, and adjustment of starting solenoid.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None. None Page 2-79

Equipment condition

Engine shut down.

Right lower access cover removed.

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Torque Limits Chart, page E-1. Turn main disconnect switch to OFF to

prevent shocks.

(Sheet 2 of 3)

LOCAT	ΓΙΟΝ/ITEM	ACTION	REMARKS
 Solenoid wires Connector (1) Capscrews (2) Solenoid (3) 	MOVAL	Mark for location and disconnect. Remove two nuts and remove connector. Remove four capscrews which hold solenoid to starting motor. Remove.	2 6
 Solenoid (3) Capscrews (2) Pinion (4) 		Position on starting motor. Install and tighten four capscrews. Adjust clearance. NOTE Do not install connector (1). a. Connect a battery positive lead to terminal (5), marked SW. b. Connect a ground to terminal (6).	See TORQUE LIMITS CHART, page E-1. 8 0.36 IN. 9.14 mm TA 098686 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
3. Pinion(4)(Cont)	c. Connect a wire from solenoid terminal marked MOTOR to ground terminal (6).	Pinion (4) will move to crank position and stay there until battery is disconnected.
	d. Push pinion toward starting motor to eliminate free movement.	
	e. Remove plug (7) and turn nut (8) to adjust pinion clearance.	Pinion clearance (Dimension A) should be 0.36 in. (9.14 mm).
	f. Install plug.	
	g. Release pinion.	
	h. Disconnect battery and test wires.	
4. Connector(1)	Install with two nuts.	
5. Solenoid wires	Connect. Be sure to reconnect them in the positions marked before they were disconnected.	

ENGINE OIL PRESSURE SENDING UNIT REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Replacement of engine oil pressure sending unit.

INITIAL SETUP

Materials/Parts Troubleshooting Reference Test Equipment

Engine oil pressure sending limit. Page 2-140 None

Thread sealant, item 10, Appendix C.

Equipment Condition

Engine OFF.

Personnel Required **Special Tools**

One mechanic None

> References General Safety Instructions

Operator's cab instrument checks, TM 10-3930-641-10. Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Sending unit (3)	Locate. Behind engine relay panel and directly above engine oil filler tube.	
2. Terminal (1)	Disconnect.	
3. Sending unit (3)	Remove and discard.	
4. Elbow fitting (2)	Remove from sending unit.	ENGINE RELAY
INSTALLATION	NOTE Use thread sealant on threads.	PANEL
1. Elbow fitting (2)	Install on engine. Open end up.	TO CYLINDER
2. Sending unit (3)	Install on elbow fitting.	BLOCK
3. Terminal (1)	Install.	HARNESS End

ENGINE WATER TEMPERATURE SENDING UNIT REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Replacement of engine water temperature sending unit.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None One engine water temperature sending unit. Page 2-140

Equipment Condition

Radiator drained to below level of sending

unit.

Left rear access panel open.

Special Tools Personnel Reauired

None One mechanic

References General Safety Instructions

Coolant replacement, page 2-215. Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Sending unit.	Locate on left cylinder head.	
2. Terminals (1)	Disconnect.	VALVE
3. Water temperature sending unit	Remove.	WATER
	NOTE	SENDER
	Radiator must be drained below center line of fan.	WATER PUMP
		B/L BL
INSTALLATION		
1. Water temperature sending unit	Position.	
2. Sending unit	Install in engine block.	
3. Terminals (1)	Connect.	TA 098688
		End

BATTERY MAINTENANCE INSTRUCTIONS

This section includes procedures for maintaining the battery and battery cables:

- a. Testing
- b. Service
- c. Battery removal and installation
- d. Battery cable removal, repair and installation

LIST OF TASKS

(Sheet 1 of 1)

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1 2 3	Battery testing. Battery service. Battery removal/installation.	2-269 2-272 2-277	2-80 2-80 2-80
4	Battery cable removal, repair and installation.	2-279	2-80
			End

BATTERY TESTING (Sheet 1 of 3)

This task covers: a. Testing specific gravity of battery with Battery/Coolant Tester.

b. Testing battery charge with multimeter.

INITIAL SETUP

Test Equipment Materials/Parts <u>Troubleshooting Reference</u>

Battery/Coolant Tester None Page 2-80

Multimeter

Equipment Condition

Engine OFF.

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Battery removal/installation, page 2-277. TM 9-6140-200-14

Be careful not to splash electrolyte on you or equipment. Do not smoke or have open flame or sparks near battery. Wear safety goggles and gloves.

Main disconnect switch OFF.

	LOCATION/ITEM	ACTION	REMARKS
	SPECIFIC GRAVITY TEST	NOTE	
•		Battery/Coolant Tester automatically adjusts for temperature. Test battery before adding water. Make separate test for each battery cell.	
1. F	ill plug	Remove. WARNING	
		Be careful not to drip electrolyte on you or equipment. If electrolyte spills on you, flood affected areas with water to flush electrolyte. Get medical attention at once.	
		Do not smoke or have open flame or sparks near batteries. Sparks can cause battery gases to explode.	
2. B	attery	Use tester dipstick to draw a few drops of electrolyte.	
3. E	attery/coolant tester	a. Place electrolyte in measm-ing window of tester.	
		b. Point tester at a bright light, ard laok through eyepiece lens.	
			Go on to Sheet 3

BATTERY TESTING (CONT)	(Sheet 3 of 3)
------------------------	----------------

LOCATION/ITEM	ACTION	REMARKS
3. Battery coolant tester (cont)	c. Read scale where light and shadow meet.	Reading must be between 1.280 and 1.225 (1.225 and 1.180 tropical electrolyte). If not,
		a. In field, charge battery. See TM 9-6140-200-14.
		b. In garrison, replace battery with fully charged battery. See battery removal and installation, page 2-277.
MULTIMETER TEST		
Multimeter	Follow instructions on multimeter cover for test.	May be used to test battery. See TM 9-6140-200-14.
		End

BATTERY SERVICE (Sheet 1 of 5)

This task covers: Cleaning, checking, filling battery.

INITIAL SETUP

Test Equipment Materials/Parts <u>Troubleshooting</u> Reference

Battery/Coolant tester Distilled water, item 15, Appendix C Page 2-80

6630-00-105-1418 Baking soda, item 19, Appendix C
Coating compound 8030-00-145-0151 or

equivalent, item 10, Appendix C GAA grease, item 4, Appendix C

Engine OFF

Special Tools Personnel Required

Terminal clamp puller
Terminal cleaning tool

One mechanic

References General Safety Instructions

TM 9-6140-200-14 Be careful not to splash electrolyte on you

or equipment.

Do not smoke or have open flame or sparks near battery.

Wear safety goggles and gloves when

servicing battery.

Equipment Condition

Main disconnect switch OFF.

Go on to Sheet 2

BATTERY SERVICE (CONT) (Sheet 2 of 5)

LOCATION/ITEM	ACTION	REMARKS
	Do not splash electrolyte on you or equipment. Injury or damage will result. If you spill electrolyte, flood affected area with water to flush electrolyte. Get immediate medical attention. Do not smoke or have sp~ks or open flame near batteries. Battery gases could explode,	
1. Battery box cover	Open.	
	Use small, open end wrenches to loosen terminal nuts. Large crescent wrenches may slip and damage battery or nuts. Do not pry off terminals or twist to remove. Terminal or posts may be damaged. Use clamp puller.	
2. Battery terminals	a. Loosen terminal nuts.b. Use clamp puller to remove terminals.c. Use terminal cleaning tool to clean terminals and posts.	NOTE Remove negative terminal first.
		Go onto Sheet 3

LOCATION/ITEM	ACTION	REMARKS
3. Battery holddown (2)	 a. Remove nuts (1). b. Remove holddown (2). c. Clean well with wire brush. d. Soak in tub of water mixed with 1/2 pound soda to each gallon of water. e. Rinse with clean water and dry. f. Paint with coating compound. 	1 4 2 5
4. Battery (3)	 a. Check to be sure fill plugs (4) are tight. b. Remove battery from box to clean. See page 2-277. c. Use soda/water solution to clean top of battery and battery box. d. Rinse well and dry. e. Install battery. 	
5. Fill plugs (4)	 a. Remove and check water level. b. Test battery specific gravity. WARNING Add distilled water only. Do not add electrolyte, except in a battery shop. c. Add distilled water to level of ring if necessary. 	See BATTERY TESTS, page 2-269.
	d. Install fill plugs.	Go on to Sheet 4

BATTERY SERVICE (CON	(Sheet 4 of 5)
----------------------	----------------

LOCATION/ITEM	ACTION	REMARKS
6. Cables	Check for damage. Replace if necessary.	See battery cable removal and installation, page 2-279.
7. Battery holddown (2)	a. Position on battery top. CAUTION Do not overtighten nuts (1). Battery case may crack. b. Install and tighten nuts (1).	
8. Battery terminals (5)	Be sure polmity (+ and -) connection is correct. Alternator may be darnaged if terminals are reversed. Do not use hammer to install terminals. a. Install terminals (5).	
	b. Using smali, open end wrenches, tighten terminal nuts. CAUTION Do not pull hard on terminals or twist with pliers.	NOTE Install negative terminal last.
		Go on to Sheet

BATTERY SERVICE (CONT)

(Sheet 5 of 5)

LOCATION/ITEM	ACTION	REMARKS
8. Battery terminals (cont)	 c. Check cable connections: Grip cable at terminal. Twist gently. Lift up. Push down. If terminal moves, tighten nut. d. Cover terminals with light coat of GAA grease, 1/32 to 1/8 in. (1 to 3 mm) thick. Wipe off extra grease. 	
9. Battery box cover	Close.	
3. Dattery box tover	Close.	
		End

BATTERY REMCIVALWW3TALLATION

(Sheet 1 of 2)

This task covers: Removal and installation of battery.

INITIAL SETUP

Materials/Parts Troubleshooting Reference Test Equipment

Page 2-80 GAA grease None

Baking soda, item 19, Appendix C

Coating compound, item 10, Appendix C

Equipment Condition

Engine OFF.

Personnel Required Special Tools

Terminal clamp puller One mechanic

> References **General Safety Instructions**

Do not splash electrolyte on you or equip-TM 9-6140-200-14

ment. If electrolyte spills on you, flood affected area with water to flush electrolyte. Get medical attention at once. Do not smoke or have open flame or sparks near battery. Sparks can cause battery gases to explode.

Main disconnect switch OFF.

Go onto Sheet 2

LOCATION/ITEM	ACTION	REMARKS
REMOVAL	NOTE	
	See TM 9-6140-200-14 for instructions on when to replace battery.	
1. Battery box cover	Open.	
2. Battery terminals (1)	Remove.	See battery service, page 2-272.
3. Battery holddown (2)	Remove.	See battery service, page 2-272.
4. Battery (3) INSTALLATION	Lift battery carefully. Do not hit side of battery box. Case could crack. Remove and send to Direct Support Maintenance for repair.	
1. Battery (3)	Install.	
2. Battery holddown (2)	Install.	See battery service, page 2-272.
3. Battery terminals (1)	Install.	See battery service, page 2-272.
4. Battery box cover.	Close.	TA 098690 End

BATTERY CABLE REMOVAL, REPAIR, AND INSTALLATION

(Sheet 1 of 5)

This task covers: Removal, repair, and installation of battery cables/terminals.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None GAA grease Page 2-80

Equipment Condition

Battery box cover open

Special Tools Personnel Required

Terminal clamp puller Crimping tool Terminal cleaning tool One mechanic

References General Safety Instructions

None

Remove negative battery terminals first,
and install them last to prevent completed battery circuits. Do not put
tools on battery top. You may damage
battery or short across posts and get

shocks.

Main disconnect switch OFF.

Go on to Sheet 2

LOCATION/ITEM	ACTION	REMARKS
REMOVAL	Use exact size wrenches to loosen terminal nuts. Large crescent wrenches may slip and darnage battery or nuts.	NEGATIVE (-) POSITIVE (+)
	Do not pry terminals off posts. Use clamp puller so that posts are not damaged.	
	1 2 VIEW A-A ROTATED 96	4 TO SOLENOID 18 10 14 11 12 17 17 17 17 17 17 17 17 17 17 17 17 17
		15 STARTING MOTOR
	, - w	TA 098691 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
	CAUTION Remove negative terminals first.	
1. Battery terminals (1, 2,3,4)	a. Loosen battery terminal clamp nuts (5).b. Use terminal clamp puller to remove clamps from posts.	When terminals (2, 3) are removed, cable (6) may be removed from vehicle.
	c. If you are replacing battery terrninaks only, pull or cut them from cables. Clean cable ends, and reinstall.	Temoved from verifice.
	d. If you are replacing terminals and cables, pull or cut battery terminals from cables (7, 8), and goon to step 2.	
2. Terminals (9, 10,11,12, 13)	a. Remove nuts which hold terminals to studs.	
	b. Remove terminals from studs.	Cable (14) may be removed from vehicle when terminals (10, 11, 13) are removed.
	c. If you are replacing only terminals, pull or cut lug terminals from cables, and reinstall.	(10, 11, 13) are removed.
	d. If you are replacing cables, pull or cut terminals from cables, and go on to step 3.	
		Go on to Sheet 4

LOCATION/ITEM	ACTION	REMAI	RKS
3. Cables (6, 7,8, 14)	 a. Slide cables (7, 8) through grommet (18). b. Remove cables (7, 8) from clips (15, 16, 17). c. Remove from vehicle 		
REPAIR/INSTALLATION			
1. Cables (6, 7,8, 14)	a. Cut new cables.	Cable Number	Length
	b. Slide cables (7, 8) through grommet	6	7.25 in. (18.4 cm)
	(18).	7	58 in. (147 cm)
	c. Install cables (7, 8) into clips (15, 16, 17).	8	74 in. (188 cm)
2. Terminals (9, 10, 11, 12, 13)	Install on cables, and crimp tight.	14	15 in. (38 cm)
3. Battery terminals (1, 2,3,4)	a. Install on cables, and crimp tight.		
	Be sure polarity (+ and -) connection is correct. Alemator may be damaged if terminals axe reversed. Do not hammer terminals onto posts. Posts and terminals will be damaged.		Go on to Sheet 5

LOCATION/ITEM	ACTION	REMARKS
3. Battery terminals 1,2,3,4)(cont)	b. Use temimd cleaning tool to clean posts, and install battery terminals to posts. c. Tighten terminal clamps with clamp nuts (5). CAUTION Do not pull hard on terminals or twist with pliers. Posts and terminals will be damaged. d. Check terminal connections by gently lifting and twisting. If terminals move, tighten nuts (5). e. Cover terminals with light coat of GAA grease - 1/32 to 1/8 in. (1-3 mm).	
		En

VEHICLE LIGHTING SYSTEMS MAINTENANCE INSTRUCTIONS

This section includes procedures for replacing and repairing vehicle lights:

- a. All headlight sealed unit
- b. Headlight/front flood
- c. Backup light
- d. Stop and tail lamp
- e. ROPS (auxiliary) flood lights

LIST OF TASKS (Sheet 1 of 1)

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1	Headlight and backup light sealed lamp units removal/installation.	2-285	2-126
2	Headlight body removal/installation.	2-287	2-126
3	Cab dome light bulb removal/installation.	2-289	2-126
4	Combination stop and tail lamp removal/installation.	2-291	2-126, 2-135
5	Combination stop and tail lamp bulb replacement.	2-293	2-126
6	ROPS (auxiliary) lights removal/installation	2-295	2-126
			End

HEAD LIGHT AND BACKUP LIGHT SEALED LAMP UNITS REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Replacing the sealed unit of the head light assembly and backup light.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Head light sealed unit Page 2-126

Equipment Condition

Engine shut down

S-ecial Tools Personnel Required

None One mechanic

References General Safety Instructions

Head light body removal/installation, page 2-287 Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Screws (4) and moldings (2)	Loosen screws and remove moldings.	2
2. Rubber ring (1) under molding	Remove.	2
3. Sealed unit (3)	Disconnect, remove, and discard.	3
INSTALLATION		
1. Sealed unit (3)	Insert in body assembly and connect.	4
2. Ring (1) under molding.	Install.	
3. Molding (2) and screw (4)	Reassemble. Install molding with sharp curved side toward middle o: ring.	
		TA 098692
		End

2-286

HEADLIGHT BODY REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Replacement of headlight body.

INITIAL SETUP

Materials/Parts Troubleshooting Reference Test Equipment

Page 2-126 None Headlight body

Equipment Condition

Engine shut down

Front warning horn removed, page 2-327

Main disconnect switch OFF

Personnel Reauired **Special Tools**

One mechanic None

> References **General Safety Instructions**

Sealed lamp unit removal/installation, page

2-285.

Warning horn removal/installation, page 2-327.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Warning horn	Remove.	See page 2-327.
2. Wire (3)	Disconnect.	
3. Nut, inside spacer, lockwasher (1)	Remove.	1
4. Headlight body (2) and outside spacer	Remove.	2
INSTALLATION 1. Outside spacer	Install on headlight mounting stud flat side towards light.	3 3 2
2. Headlight (2)	Place in bracket.	
3. Nut, spacer, lockwasher (1)	Install with flat side of spacer towards lockwasher.	FRAME
4. Wire (3)	Connect.	
5. Warning horn	Install.	See page 2-327.
		TA 098693
	1	End

CAB DOME LIGHT BULB REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal/installation of cab dome light bulb.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Cab dome light Page 2-90

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

None Main disconnect switch OFF

(Sheet 2 of 2)

LOCATION/ITEM	ACTION	REMARKS
1. Capscrews (4) 2. Lens (3) 3. Bulb (2) INSTALLATION 1. Bulb (2) 2. Lens (3) 3. Capscrews (4)	Remove. Remove. Insert. Place in position. Install.	
		4
		TA 09875
		En

COMBINATION STOP AND TAIL LAMP REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Replacement of combination stop and tail lamp assembly.

INITIAL SETUP

<u>Test Equipment</u> <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Combination stop and tail lamp assembly Pages 2-126, 2-135

Equipment Condition

Engine shut down

Radiator guard lower section removed

Main disconnect switch OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Headlight sealed unit removal/installation, page 2-285

Radiator rear guard removal/installation, page 2-242

Go on to Sheet 2

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		2
1. Terminils (1) and wires	Loosen terminal screws. Tag and disconnect wires.	
2. Nuts and lockwashers (2)	Remove.	
3. Lamp assembly	Remove.	1
INSTALLATION		
1. Lamp assembly	Hold in place.	
2. Nut and lockwasher (2)	Install.	
3. Terminals (1)	Reconnect wires.	
		TA 098695
		End

COMBINATION STOP AND TAIL LAMP - BULB REPLACEMENT

(Sheet 1 of 2)

This task covers: Replacing a burned out bulb in the stop and tail lmp assembly.

INITIAL SETUP

Test. Equipment Materials/Parts Troubleshooting Reference

None Bulb Page 2-126

Equipment Condition

Engine shut down

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

None Main disconnect switch in OFF

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Screws (1)	Loosen.	
2. Door assembly (2)	Remove.	
3. Bulb (3)	Remove by pushing and turning. Discard.	
INSTALLATION		
1. New bulb (3)	Install.	
2. Door assembly (2)	Install. NOTE Door assembly only goes in one way when both screws are installed.	
3. Screws (1)	Tighten.	
		TA 096696 End

ROPS (AUXILIARY) LIGHT REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal/installation of the ROPS (auxiliary) lights.

INITIAL SETUP

<u>Test Equipment</u> <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Light assembly Page 2-126

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Sealed lamp unit removal, see page 2-285 Main disconnect switch is OFF

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		₽ P
1. Wire assembly (1)	Remove.	2
2. Nut (2)	Remove nut (2), washer, spacer and body assembly.	
3. Capscrews, washers and nuts (3	Remove (if necessary).	
4. Capscrews (4)	Remove (if necessary).	
INSTALLATION		
1. Capscrews (4)	Install (if removed).	4
2. Capscrews, washers and nuts (3)	Install.	
3. Nut (2)	Install nut, washer, spacer and body assembly.	
4. Wire assembley (1)	Install.	
		TA 098697
		End

VEHICLE ELECTRICAL COMPONENTS MAINTENANCE INSTRUCTIONS

This section includes procedures for removing and installing:

- a. Main disconnect switch
- b. Container lock indicator panel c. Instrument panels d. Switches

- e. Oil level switch

- f. Radio interference suppression components g. Backup wining alarm and switch h. Vehicle horns

- i. Relays, solenoids, circuit breaker, diodes and switches and repairing wiring harnesses

LIST OF TASKS (Sheet 1 of 1)

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
			-
1	Container lock indicator panel removal/ installation	2-298	2-124
9	Main disconnect switch removal/installation	2-300	2-74
3	Container lock indicator disassembly/assembly	2-302	2-125
4	Instrument panels removal, disassembly,	2-305	2-113, 2-127
	assembly, installation		-,
5	Switch removal/installation	2-315	2-87, 2-89
$\overset{\circ}{6}$	Oil level switch removal/installation	2-317	2-138
7	Radio interference suppression components removal/installation	2-319	None
8	Front warning horn removal/installation	2-327	2-95
9	Backup warning alarm and switch removal/ installation	2-329	2-143
10	Vehicle horns removal/installation	2-332	2-95
11	Backup alarm/start interlock switch testing/ adjustment	2-334	2-73, 2-144
12	Relay, solenoid, circuit breaker, diode and switch removal/installation	2-337	2-88, 2-97
13	Wiring harness repair	2-340	2-66

CONTAINER LOCK INDICATOR PANEL REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal/installation of container lock indicator panel.

INITIAL SETUP

Test Equipment Troubleshooting Reference

None Container lock indicator panel Page 2-124

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Container lock indicator disassembly/assembly, Main disconnect switch OFF page 2-302

	LOCATION/ITEM	ACTION	REMARKS
1. 2.	REMOVAL Capscrews and washers (1) Container lock indicator assembly (2) INSTALLATION Container lock indicator assembly (2)	Remove. Remove. Locate on floor heater housing. Install.	
			TA 098698 End

MAIN DISCONNECT SWITCH REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal and installation of the main disconnect switch.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Main disconnect switch Page 2-74

Equipment Condition

Engine OFF

Special Tools Personnel Reauired

Battery terminal puller One mechanic

<u>References</u> General Safety Instructions

Battery service, page 2-272 Batteries disconnected, see page 2-272

TM 10-3930-641-10

	LOCATION/ITEM	ACTION	REMARKS
	REMOVAL	WARNING	
		Disconnect negative (black) cable from battery at each battery box.	
1.	Key (1)	Turn to OFF and remove.	1 2 3 7 4 5
2.	Nuts (5), washers (4) and three cables (6)	Remove after tagging the three cables for location.	
3.	Nut (2) and washer (3)	Remove.	
4.	Switch (7)	Remove from the mounting plate.	6
	INSTALLATION		
1.	Switch (7)	Position through the mounting plate.	
2.	Washer (3) and nut (2)	Install and tighten.	Torque to 20 lb. ft. (27 N•m).
3.	Three cables (6), washers (4) and nuts (5)	Install and tighten.	Torque to 40 lb. ft. (54 N•m).
4.	Key (1)	Install.	NOTE
5.	Battery cables	Connect.	Connect negative terminals last. _{TA 098699} End

CONTAINER LOCK INDICATOR DISASSEMBLY/ASSEMBLY

(Sheet 1 of 3)

This task covers: Disassembly/assembly of container lock indicator.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

As required Page 2-125 None

Equipment Condition

Engine OFF

Container lock indicator panel

removed

Personnel Required Special Tools

One mechanic None

> References **General Safety Instmctions**

Container lock indicator panel removal/installation, page 2-298 None

DISASSEMBLY 1. Capscrews (1) and cover (2) 2. Mounting cap screw (3) and washer (4) 3. Screws and wires a. Tag wires (for reassembly) and remove. b. Pull wires through grommet in plate.			
5. Bulbs (6) Remove. 6 5	 Mounting cap screw (3) and washer (4) Screws and wires Bulb covers (5) 	Remove. a. Tag wires (for reassembly) and remove. b. Pull wires through grommet in plate. Remove.	4 6 5

LOCATION/ITEM	ACTION	REMARKS
LOCATION/ITEM ASSEMBLY 1. Wires and screws 2. Washer (4) and mounting capscrew (3) 3. Cover (2) and capscrews (1) 4. Bulbs (6)	ACTION Pull wires through grommet and install. Install. Install.	REMARKS 2 1 1 1 1 1 1 1 1 1 1 1 1
5. Bulb covers (5)	Install.	
		6 5
		TA 098701
		End

INSTRUMENT PANELS REMOVAL, DISASSEMBLY, ASSEMBLY, INSTALLATION

(Sheet 1 of 10)

This task covers: Replacement of instrument panels and components.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None As needed Pages 2-113, 2-127

Equipment Condition

Engine OFF

Special Tools Personnel Reauired

None One mechanic

References General Safety Instructions

LOCATION/ITEM	ACTION	REMARKS
REMOVAL	NOTE	1
	Follow the same procedure for either instrument panel.	
1. Four screws (1)	Remove from panel (2) and pull out panel.	
2. Harness (4)	Disconnect at connectors (3). Remove panel.	2 (1 Dec 2) (2 Dec 2)
3. Capacitor	Remove from capscrew in lower right hand comer behind left instrument panel.	
DISASSEMBLY		
1. Fuseholder (7)	Remove as follows:	
a. Two wires (8)	a. Disconnect from terminal (5).	
b. Nut (6)	b. Loosen and remove.	3 4
	NOTE	
	The slot in the nut must line up with the side terminal of fuseholder.	8 5
c. Fuseholder (7)	c. Remove through front of panel.	TA 098702
		Go on to Sheet 3

(Sheet 3 of 10)

LOCATION/ITEM	ACTION	REMARKS
2. Power switch (11)	Remove as follows:	
a. Ring (9)	a. Remove.	9
b. Wires (10)	b. Identify and disconnect.	
c. Switch (11)	c. Remove from back of panel.	
3. Starting aid switch (14)	Remove as follows:	
a. Rubber cap (12)	a. Turn in a counterclockwise direction to loosen and remove.	
b. Nut (13)	b. Remove.	
		10
		12 13 14 11 TA 098703
		Go on to Sheet 4

LOCATION/ITEM	ACTION	REMARKS
3. c. Two wires (15)	c. Remove from switch (14) and identify.	
d. Switch (14)	d. Remove from back of panel.	
4. Gages (all) (20)	Remove as follows:	16
a. Lamp socket (16)	a. Remove from gage.	19 15 17
b. Two wires (19)	b. Remove and identify.	22 24 22 22 22 23 24 22 22 23 24 22 22 23 24 22 22 22 23 24 22 22 22 23 24 22 22 23 24 22 22 23 24 22 22 23 24 22 22 23 24 22 23 24 22 22 23 24 22 22 23 24 22 22 23 24 22 22 23 24 22 22 23 24 22 22 23 24 22 22 23 24 22 22 23 24 22 22 24 22 22 24 22 22 24 22 22 24 24
c. Two nuts (17) that fasten gage to retainer (18)	c. Remove. Remove retainer (18).	
d Gage (20)	d. Remove through front of panel.	18
5. Toggle switches	Remove as follows:	21
a. Nut (22) and rubber boot (21)	a. Use a wrench on nut (22) and remove.	
		20 TA 098704 Go on to Sheet 5

LOCATION/ITEM	ACTION	REMARKS
5. b. Wires (23)	b. Disconnect and identify.	With the
c. Switch (24)	c. Remove from back of panel.	27 25
6. Indicator lights	Remove as follows:	28
a. Wires (25)	a. Disconnect and identify.	
b. Nut (27) and lockwasher (26)	b. Remove.	
c. Indicator light (28)	c. Remove through front of panel.	
7. Washer/wiper switch	Remove as follows:	29
a. Knob (29)	a. Pull from switch.	30
b. Locknut and nut (30)	b. Remove from switch.	
		TA 098705 Go on to Sheet 6

LOCATION/ITEM	ACTION	REMARKS
8. c. Wires (32)	c. Remove from switch and identify.	
d. Switch (31)	d. Remove from back of panel.	32
ASSEMBLY		31
1. Washer/wiper switch (1)	Install as follows:	
a. Switch (1)	a. Put through rear of panel with flat part of shaft toward the TOP of the panel.	
b. Nut and locknut (2)	b. Install.	11. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1.
c. Knob (3)	c. Install by pushing on to shaft.	Just 1
d. Wires (32)	d. Install.	6
2. Indicator lights	Install as follows:	
a. Indicator socket (4)	a. Install through front of panel.	
b. Lockwasher (5) and nut (6)	b. Install on indicator.	4
c. Two wires	c. Connect.	TA 098900
		Go on to Sheet 7

LOCATION/ITEM	ACTION	REMARKS
3. Toggle switches (7)	Install as follows:	
a. Switch (7)	a. Install from back of panel.	
b. Boot (8) and nut	b. Install.	
	NOTE	8
	The groove in the switch must lineup with the tab in the panel.	9
c. Two wires (9)	c. Connect to the terminals.	12
4. Gages (all) (10)	Install as follows:	
a. Gage (10)	a. Install through front of panel.	-/ 4/10
b. Retainer (11)	b. Install and fasten to gage with two lock-washers and two nuts.	
c. Wires (12)	c. Connect.	
d. Lamp socket (13)	d. Install in gage.	TA 098700 Go on to Sheet 8

LOCATION/ITEM	ACTION	REMARKS
5. Stinting aid switch	Install as follows:	
a. Switch (15)	a. Install through back of panel.	
b. Nut (16) and cap (17)	b. Install on switch (15).	
c. Two wires (14)	c. Connect to back of switch (15).	The state of the s
6. Ignition switch (19)	Install as follows:	
a. Switch (19)	a. Install through tab (20) and put switch through back of panel.	16 17 15
b. Ring (18)	b. Install on switch and hand-tighten.	
c. Three wires	c. Connect.	19
		18 POWER TA 098707 Go on to Sheet 9

LOCATION/ITEM	ACTION	REMARKS
7. Fuseholder (23)	Install as follows:	
a. Seal (22)	a. Install on fuseholder (23).	
b. Fuseholder (23	b. Install through front of the panel.	
c. Nut (24)	c. Install on fuseholder.	22 23
	NOTE	
	The slot in the nut (24) must lineup with the side termimd of the fuseholder.	
d. Wires (21)	d. Connect.	-24
		21 _{TA 098708}
		Go on to Sheet 10

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION		27 26
1. Harness (26)	Connect to connectors (27).	
2. Capacitor	Connect to lower right hand corner of left panel behind wiper switch using nut and capscrew. See page 2-320.	
3. Panel (28)	Install, using four screws (21).	
		21
		28
		TA 098709

SWITCH REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Replacement of all switches.

INITIAL SETUP

Test Equipment Troubleshooting Reference

None Switch Pages 2-87, 2-89

Equipment Condition

System drained to below level of switch

Main disconnect switch OFF.

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Engine oil pressure sending unit removal/installation, page 2-264.

Engine water temperature sending unit removal/installation, page 2-266.

Instrument panels removal, disassembly, assembly, installation, page 2-305.

Go on to Sheet 2

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Terminals	Mark for identification.	1 2
2. Nuts and lockwashers holding terminals in place on the switch (1)	Remove.	
3. Fastening capscrews (2) holding switch in place.	Remove (or unscrew switch, depending on type).	
4. Switch (1)	Remove.	
INSTALLATION		
1. Switch (1)	Place in position on machine.	TYPICAL SWITCH
2. Fastening capscrews (2) to hold switch in place	Install.	
3. Terminals	Place in position.	
4. Nuts and lockwashers	Install.	TA 098901
		End

OIL LEVEL SWITCH REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal and installation of oil level switch.

INITIAL SETUP

<u>Test Equipment</u> <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Switch Page 2-138

Gasket

Equipment Condition

Engine oil is to be drained

Main disconnect switch OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Engine oil pressure sending unit removal/installation, page 2-264

Switch removal/installation, page 2-315

LO 10-3930-641-12

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		OIL LEVEL SWITCH
1. Terminal wire	Remove from end of switch.	
2. Oil level switch	Remove. (Unscrew from oil pan.)	
INSTALLATION		
1. Oil level switch	Install with a new gasket.	
2. Terminal wire	Install on end of switch.	OIL LEVEL SWITCH TERMINAL RIGHT SIDE OF OIL PAN
		TA 098710 End

RADIO INTERFERENCE SUPPRESSION COMPONENTS REMOVAL/INSTALLATION

(Sheet 1 of 8)

This task covers: Removal and installation of radio interference suppression components.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None As needed None

Equipment Condition

Engine OFF


Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Radio interference suppression, Main disconnect switch OFF

page 2-510.



TA 098711 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
REMOVAL	NOTE Determine where the wire is routed and make	2 HEATER GP RED TERMINAL
	note.	PAN SWITCH
	The shield wire may be in a harness. If so, it will be necessary to-cut the wrapping to remove it. Make sure it gets rewrapped when it is installed.	CONSOLE
1. Electrical terminals (1)	Remove.	7 OVERHEAD HEATER
2. Shield wire (2), (6)	Remove.	
		1
		PLATFORM TO ROPS TA 098902
		Go onto Sheet 4

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION	NOTE Determine where the wire is routed and make note. The shield wire may be in a harness. If so, it will be necessary to cut the wrapping to remove it. Make sure it gets rewrapped when it is installed.	2 HEATER GP RED TERMINAL PAN SWITCH 5 CONSOLE OVERHEAD HEATER
1. Shield wire	Route wire in the original way.	
2. Electrical connectors	Install.	1
		PLATFORM TO ROPS TA 098903
		Go on to Sheet 5

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Bonding strap	Locate.	STARTER
2. Terminals (1)	Remove.	ENGINE TO FRAME
3. Bonding strap	Remove.	BÖNDING STRAP
		TA 098904 Go on to Sheet 6

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION 1. Bonding strap	Locate on mounting holes.	STARTER
2. Terminals (1)	Install.	BONDING STRAP
		ENGINE TO FRAME
		TA 098905 Go on to Sheet 7

		
LOCATION/ITEM	ACTION	REMARKS
REMOVAL		1 2
1. Capacitor (1)	Locate.	
2. Wire (2)	Remove.	3 TYPICAL CAPACITOR
3. Fastener (3)	Remove.	TERMINAL ORANGE
		WINDOW WIPERS TA 098712
4. Capacitor	Remove.	Go on to Sheet 8

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION 1. Capacitor (1)	Locate on mounting holes.	
2. Fasteners (3)	Install.	TYPICAL CAPACITOR
3. Wire (2)	Install.	POSITIVE TERMINAL 2 ALTERNATOR End

FRONT WARNING HORN REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal and installation of either front warning horn.

INITIAL SETUP

Test Equipment Materials/Parts <u>Troubleshooting Reference</u>

None None Page 2-95

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		LIGHTS
1. Wires (1)	Tag wires for identification and disconnect.	
2. Capscrews, nuts and washers (2)	Remove.	
3. Horn (3)	Remove.	
INSTALLATION		3
1. Horn (3)	Locate on mounting hole.	2
2. Capscrews, nuts and washers (2)	Install.	
3. Wires (1)	Connect to horn.	
		TA 098713
		End

BACKUP WARNING ALARM AND SWITCH REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Removal and installation of backup warning alarm and switch.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None Page 2-143

Equipment Condition

Radiator rear guard lower section

removed

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Radiator rear guard removal/installation, page 2-242

Backup alarm/start interlock switch testing/adjustment, page 2-334

LOCATION/ITEM	ACTION	REMARKS
1. Wires (2) 2. Nuts, washers and bolts (3 3. Alarm (1)	Tag and disconnect. Remove two. Remove.	
1. Alarm (1) 2. Bolts (3), washers and nuts 3. Wires (2)	Locate on mounting holes. Install. Ground wire must be under nut. Connect.	GROUND WIRE TA 098714 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
SWITCH REMOVAL		TRANSMISSION INTERLOCK SWITCH
1. Wire (1)	Unplug.	
2. Nut (2)	Remove.	
3. Switch (3)	Remove.	
SWITCH INSTALLATION		
1. Switch (3)	Place in mounting hole.	
2. Nut (2)	Install.	
3. Wire (1)	Plug in.	Adjust switch travel. See page 2-334.
		1 TA 098715 End

VEHICLE HORNS REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Replacement of vehicle horns.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None Page 2-95

Equipment Condition

Engine OFF-

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

LOGATION/ITEMA	A CITIVON I	DEMARKS
LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Capscrews (3 and 6), nut (4) and washers (2 and 7)	Remove from bracket (1).	10
2. Hex nut (9)	Remove from bracket (1).	5
3. Horn (5)	Remove.	11
4. Electrical connector (10)	Disconnect.	3
5. Ground cable (11)	Disconnect.	1 2
INSTALLATION		4 5
1. Electrical connector (10)	Connect.	9
2. Horn (5)	Install.	
3. Hex nut (10)	Install.	
4. Ground cable (11)	Connect.	6 8.7
5. Capscrews (3 and 6), washers (2 and 7) and nuts (4)	Install.	TA 098716 End

BACKUP ALARM/START INTERLOCK SWITCH TESTING/ADJUSTMENT

(Sheet 1 of 3)

This task covers: Testing and adjusting of backup alarm or start interlock micro switches.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

Multimeter None Pages 2-73, 2-144

Equipment Condition

Engine OFF

Soecial Tools Personnel Required

None One mechanic

References General Safety Instructions

LOCATION/ITEM	ACTION	REMARKS
1. Transmission interlock or backup alarm micro switch terminals	 a. Tag and disconnect both wires. b. With your multimeter set to read ohms, connect one lead to terminal (1) and connect other lead to terminal (2). 	START INTERLOCK SWITCH WIRES BACKUP ALARM SWITCH
2. Transmission gear selector	a. Place in REVERSE.b. Place in NEUTRAL.c. Place transmission selector in FORWARD.	Multimeter should read ZERO (switch closed). Multimeter should read ∞ (switch open). For start interlock switch, multimeter should read ZERO; for backup alarm switch, multimeter should read ∞.
		Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
ADJUSTMENT	Multimet.er connected as in TESTING.	1
1. Actuator jam nut (1)	Loosen.	2
2. Transmission gear selector.	Put in REVERSE.	
3. Actuator body (2)	a. Turn in or out just until ohms scale reads ZERO, switch closes.b. Turn (2) one additional turn in.	If ohms scale remains ∞ ohms, replace switch and actuator assembly. Repeat adjustment.
4. Actuator jam nut (1)	Tighten.	Go to TESTING, Step 1.
		TA 098718 End

RELAY, SOLENOID, CIRCUIT BREAKER, DIODE AND SWITCH REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Removal and installation of any relay, solenoid, circuit breaker, diode and switch.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None Pages 2-88, 2-97

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Schematics, page FO-1 Main disconnect switch OFF

(Sheet 2 of 3)

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Wires	Locate, tag and remove all wires connected to the part being replaced.	See schematics, page FO-1.
2. Nuts, bolts or screws	Remove the fastener holding the part on.	
3. Relay, solenoid, circuit breaker, diode or switch	Remove.	
		Go on to Sheet 3

(Sheet 3 of 3)

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION 1. Relay, solenoid, circuit breaker, diode or switch	Position on mounting holes.	
2. Bolts, nuts or screws	Install.	
3. Electrical wires	Install per tagging.	
		End

WIRING HARNESS REPAIR (Sheet 1 of 2)

This task covers: Repairing wiring harness.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Wire that is the correct gage Page 2-66

Equipment Condition

Harness removed from vehicle

Engine OFF

Special Tools Personnel Required

Electrical crimper One mechanic

Soldering gun

References General Safety Instructions

Electrical schematics, page FO-1 Main disconnect switch OFF

LOCATION/ITEM	ACTION	REMARKS
1. Wires	If wires of a harness are found defective they may be replaced. Sometimes it may be necessary to cut open the wrapping with a sharp knife. After replacing the wire(s) you should rewrap the group of wires with electrical tape. At this time it will be necessary to replace the connectors. See Step 2.	Do not try to replace a wire with a gage different than that of the original wire. Try to replace the wire with the same color so it will be color coded to the manual.
2. Connector	There is a large variety of connectors available. Determine which type to use from the old connector. The connector may be fastened by soldering or crimping with an electrical crimper.	If you splice wires be sure you insulate the connection with electrical tape.
		End

BRAKE SYSTEM MAINTENANCE INSTRUCTIONS

This section covers removal and installation of these brake system components for Organizational Maintenance personnel:

a. Parking brake linkageb. Brake pedal

c. Service brake linkages

Also instructions for:

- a. Adjusting parking brake linkageb. Bleeding paxking brakec. Adjusting service brake linkage

- d. Adjusting service brake pedale. Bleeding service brake

(Sheet 1 of 1) LIST OF TASKS

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1	Parking brake control linkage removal/installation.	2-343	None
2	Service brake pedals removal/installation.	2-346	None
3	Brake pedal linkages disassembly/assembly.	2-353	2-34
4	Parking brake linkage adjustment.	2-358	2-35
5	Parking brake bleeding.	2-360	None
6	Parking brake lines and fittings inspection/removal/installation.	2-363	2-34
7	Service brake control linkage adjustment.	2-366	2-34, 2-35
8	Service brake pedals adjustment.	2-369	2-34
9	Service brake system bleeding.	2-371	None
			Enc

PARKING BRAKE CONTROL LINKAGE REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Removal and installation of parking brake linkage.

INITIAL SETUP

Test Equipment Materials/Paxts Troubleshooting Reference

None As required None

Equipment Condition

Engine OFF

Wheels blocked

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

PMCS, page 2-5 Block front and rear tires

Parking brake linkage adjustment, page 2-358 Main disconnect switch OFF

LOCATION/ITEM	ACTION	REMARKS
REMOVAL	NOTE	
<u> </u>	Make sure all oil pressure is relieved from brake system before disassembly. Turn off engine and relieve pressure by pressing a brake pedal repeatedly until ail brake oil pressure is relieved.	2
1. Nut (7)	Loosen.	1 STEERING
2. Pin (9), cotter pin and clevis (8)	Remove from parking brake valve.	COLUMN
3. Cable (5)	Disengage from clevis (8).	9 8 7 BRACKET 3
4. Nuts (6)	Loosen completely.	TO PARKING BRAKE VALVE
5. Capscrew (3) and clip (2)	Remove.	
6. Knob (1), stem, cable housing (4) and cable (5)	Remove.	1. Knob 6. Nut 2. Clip 7. Nut 3. Capscrew 8. Clevis 4. Cable housing 9. Pin 5. Cable
7. Knob, stem and cable (5)	Remove from cable housing (4).	
		TA 098719
	1	Go on to Sheet 3

(Sheet 3 of 3)

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION		
8. Knob (1), stern and cable (5)	Insert in cable housing (4).	
9. Capscrew (3) and Clip (2)	Install to secure cable housing.	
10. Nuts (6)	Tighten.	
11. Pin (9), cotter pin and clevis (8)	Install.	
12. Nut (7)	a. Tighten.	
	b. Adjust cable tension.	See page 2-358.
		End

SERVICE BRAKE PEDALS REMOVAL/INSTALLATION

(Sheet 1 of 7)

This task covers: Removal and installation of service brake pedal components.

INITIAL SETUP

Test Equipment <u>Materials/Pints</u> <u>Troubleshooting</u> Reference

None Multipurpose grease, item 3, Appendix C None

Equipment Condition

Engine shut down

Vehicle parked on level surface

Special Tools Personnel Required

Seal driver One mechanic

L.eel rule

References General Safety Instructions

Service brake pedal adjustment, page 2-369

Apply parking brake and block tires before performing the procedure.


PMCS, page 2-5

before performing the procedure.

Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Two panels that cover brake pedal linkage and cables	NOTE Procedure given is for right hand brake pedal. Left hand brake pedal is the same. Remove.	PANELS
2. Twelve point capscrew (10)	Remove from back of pedal.	See Sheet 4 for illustration.
3. Pedal (11) and washer (3)	Slide off splined shaft.	
4. Spring (18)	Remove.	
		Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
5. Capscrews (13). lockwashers (14). wa;her (15), angle assembly (16)'	Remove.	
6. Cotter pin (21), two washers (15), pin (17)	Remove from lever (2) to release cable (19).	
7. Shaft (1)	Slide out of bearing (5	
8. Capscrew (22) and shaft (1)	Remove from lever (2).	
9. Large nut (6) and washer (7) on inside of pedal	Remove from bearing retainer (8).	
10. Large nut (6) and washer (7) on outside of pedal	Remove from other side of bearing retainer (8).	
		Go on to Sheet 4



- 1. Shaft
- 2. Lever
- 3. Washer
- 4. Seal
- 5. Bearing
- 6. Nut
- 7. Washer
- 8. Retainer
- 9. Spacer
- 10. Capscrew
- 11. Pedal
- 12. Bumper
- 13. Capscrew
- 14. Lockwasher
- 15. Washer
- 16. Angle assembly
- 17. Pin
- 18. Spring
- 19. Cable assembly
- 20. Cable end
- 21. Cotter pin
- 22. Capscrew 23. Pin
- 24. Washer
- 25. Capscrew 26. Clamp

TA 088721

LOCATION/ITEM	ACTION	REMARKS
11. Seals (4)	Remove and discard.	
12. Bearings (5) and spacer (9)	Remove.	
INSTALLATION		
1. Bearings (5)	a. Lubricate with multipurpose grease.	
	b. Install with spacer (9) into retainer (8).	
2. Lip type seals (4)	a. Install in retainer. Seals must contact bearings. Lips of seals must be toward outside of retainer.	Use a seal driver to install.
	b. Lubricate lips with multipurpose grease.	
3. One nut (6) and washer (7)	Install on retainer (8).	
		Go on to Sheet 6

LOCATION/ITEM	ACTION	REMARKS
4. Retainer (8)	Install into hole in frame.	
5. Other nut (6) and washer (7)	Install.	
6. Retainer assembly7. Lever (2)	 Adjust: a. Turn nuts (6) until end of retainer (8) is 0.62 in. (15.7 mm) from side of bracket (Dimension A). b. Tighten nuts (6) to 90-110 lb. ft. (121-149 N•m). a. Install on shaft (1). b. Secure with capscrew (22). c. Install assembly with washer (3) between lever and nut (6). 	7 8 6 7 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
		TA 098722 Go on to Sheet 7

LOCATION/ITEM	ACTION	REMARKS
8. Cable end (20)	Connect to lever assembly with washers (15), pin (17) and cotter pin (21).	
9. Spring (18)	Install on pin in lever assembly.	
10. Angle assembly (16)	Install against lever with two cap screws (13) and lockwashers (14) and washer (15).	
11. Pedal (11) and washer (3)	a. Install on splined shaft (1) of lever assembly so it is about 3.75 in. (95.3 mm) from floor.	
	b. Secure with capscrew (10).	
12. Brake pedal	Adjust.	See page 2-369.
13. Floor panels	Install.	
		End

BRAKE PEDAL LINKAGES DISASSEMBLY/ASSEMBLY

(Sheet 1 of 5)

This task covers: Disassembly and assembly of brake pedal linkages.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None As required Page 2-34

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Service brake pedal adjustment, page 2-369 Block front and rear tires.


PMCS, page 2-5 Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
1. Two panels that cover brake pedal linkage and cables	WARNING Make sure all pressure in brake system is re- [eased before any lines are disconnected. With engine off, pump a brake pedal repeatedly until all pressure is relieved. Remove.	PANELS
 Spring (1) Two capscrews and washers that 	Remove.	3
secure angle stop (2) 4. Angle stop (2)	Remove.	
5. Cotter pin, two washers and pin (3) that secure cable clevis	Remove.	TA 098723 Go onto Sheet 3

- Spring (shown on page 2-354)
 Angle stop
 Cotter pin, washer and pin
 Cable wire

- 5. Clevis
- 6. Pin
- 7. Nut
- 8. Nut

- 11. Nut



TA 098724

LOCATION/ITEM	ACTION	REMARKS
6. Cable wire (4)	Disconnect from clevis (5).	
7. Access door assembly over brake control valve group	Lift up and lay access door down.	
8. Pins (6) and cotter pins	Remove from clevis that secures cables to brake pedal levers.	
9. Cable wire (4)	Remove from valve group end of cable wire housing.	
10. Nuts (7) on upper cable housing (12)	Remove.	
11. Nuts (8) on middle cable housing (13)	Remove.	H
12. Capscrew (9), washer, nut and clip (10)	Remove.	
13. Nuts (11) on lower cable housing (14)	Remove.	
	NOTE	
	If only cable wire needs replacing, then follow Steps 1 thru 8, ASSEMBLY.	
	_	TA 098725
		Go on to Sheet 5

LOCATION/ITEM	ACTION	REMARKS
ASSEMBLY		
1. Lower cable housings (14)	a. Install cm bracket.	See page 2-355.
	b. Secure with nuts (11).	
2. Middle cable housings (13)	a. Install on bracket and to floor plate.	
	b. Secure with nuts (8).	
3. Capscrew (9), nut., washer and clip (10)	Install.	
4. Cable wire (4)	a. Feed through cable housings from brake control valve end.	
	b. Secure to clevis.	
	c. Secure clevis to brake levers with pins (6) and cotter pins.	
5. Upper cable housings (12)	Install and feed cable wire (4) through at same time.	
6. Cable wire (4)	a. Secure to clevis.	
	b. Secure clevis to brake pedal with cotter pin, two washers, pin (3) and spring (1).	
7. Angle stop (2)	a. Install.	
	b. Adjust against brake lever pedal so that pedal is 3.25 in. (82.6 mm) above pedal stop on floor plate.	
8. Two panels that cover brake pedal linkage and cables.	Install and secure with capscrews.	
		End

PARKING BRAKE LINKAGE ADJUSTMENT

(Sheet 1 of 2)

This task covers: Adjustment of parking brake linkage.

INITIAL	SETUP

Test Equipment Materials/Parts	Troubleshooting Reference
--------------------------------	---------------------------

None None Page 2-35

Equipment Condition

Engine OFF. Shipping link installed. Wheels blocked. Parking brake control IN

Special Tools Personnel Required

Steel rule One mechanic

References

Parking brake control linkage removal/installation, page 2-343.

PMCS, page 2-5.

Shipping link removal/installation, page 2-471.

General Safety Instructions

Park vehicle on level ground. Place blocks in front of and behind each wheel to prevent vehicle moving.

Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
1. Parking brake control	Push IN.	
2. Parking brake linkage (located beneath cab)	a. Measure distance A.	Distance should be between 6.8 and 6.9 in. (172.7 to 175.7 mm).
	b. If distance A is different from the specification:	
	Loosen nut (1).	BRACKET DISTANCE A 2
	Remove cotter pin (2).	TO PARKING BRAKE VALVE TO CAB
	Remove rod end pin (3).	PARKING BRAKI CONTROL
	Turn rod end (4) to adjust distance.	1. Nut
	Install rod end pin (3) and cotter pin (2).	2. Cotter pin 3. Pin
	Tighten nut (1).	4. Rod end
		TA 09872 End

PARKING BRAKE BLEEDING (Sheet 1 of 3)

This task covers: Bleeding air from parking brake system.

INITIAL SETUP

INITIAL SETUP		
Test Equipment	Materials/Parts	Troubleshooting Reference
None	Hydraulic oil	None
	Hoses	
	Buckets	Equipment Condition
		Parking brake control IN.
		Transmission selector lever in NEUTRAL.
Special Tools	Personnel Required	
None	One mechanic	
	References	General Safety Instructions
	LO 10-3930-641-12	Be sure vehicle is on level ground.
	Shipping link removal/installation, page 2-471.	Install shipping link.
	TM 10-3930-641-10	Place blocks in front of and behind wheels to prevent vehicle movement.
	G , 1 1 11 11 0 0 0 7 4	±

Service brake bleeding, page 2-371

LOCATION/ITEM	ACTION	REMARKS
	WARNING	
	Be sure the vehicle is on level ground. Put blocks in front of and behind each wheel so vehicle does not move.	
	NOTE	
	Check hydraulic oil level. Fill if necessary.	
1. Engine	a. Start engine.	See TM 10-3930-641-10.
	b. Wait for LOW BRAKE PRESS indicator to go OFF.	
	c. Turn engine OFF.	See TM 10-3930-641-10.
2. Parking brake control	Push in.	
3. Hose	Connect to fitting (1) on top of parking brake housing (2).	2
4. Screw valve (3)	a. Open using an open-end wrench.	
		VIEWED FROM UNDER FORWARD END, LEFT SIDE OF CAB TA 098727
	1	Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
4. Screw valve (3) (cont)	b. Allow oil to flow through hose until there are no air bubbles in oil.	
	c. Close valve.	
5. Hydraulic oil reservoir	WARNING	
	Remove reservoir cap slowly. Hydraulic system is under pressure, and cap could fly off if removed quickly.	
	Check oil level. Fill as necessary.	
6. Parking brake		See TM 10-3930-641-10.
		En

PARKING BRAKE LINES AND FITTINGS INSPECTION/REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Inspection and replacement of parking brake lines and fittings.

INITIAL SETUP

Troubleshooting Reference Materials/Parts Test Equipment

Hydraulic oil Page 2-34 None

Equipment Condition

Parking brake control IN.

Special Tools Personnel Required

One mechanic None

> References **General Safety Instructions**

Park vehicle on level ground. Install safety Torque Limits Chart, page E-1

Place blocks in front of and behind wheels PMCS, page 2-5

link.


to prevent vehicle movement.

Release brake pressure by pumping brake pedal until resistance is gone.

Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
INSPECTION		
1. Lines (3, 5,6, 12)	Check for damage, leaks and kinks.	
2. Elbows (1, 13)	Check for damage, leaks.	
3. Tee (10)	Check for damage, leaks.	
4. Preformed packing (2)	Check for damage.	
5. Coupling (7, 9)	Check for leaks, damage.	
REMOVAL/INSTALLATION		
1. Lines and fittings	Replace if damaged or leaking:	
	a. Loosen nuts on fittings.	
	b. Remove darnaged part.	
	c. Install new part.	
	d. Tighten fittings.	See Torque Limits Chart, page E-1.
		Go on to Sheet 3

PARKING BRAKE LINES AND FITTINGS INSPECTION/REMOVAL/INSTALLATION (CONT)



- 1. Elbow
- 2. Preformed packing
- 3. Hose assembly
- 4. Guard assembly
- 5. Tube assembly
- 6. Hose assembly
- 7. Coupling assembly
- 8. Sleeve
- 9. Coupling assembly
- 10. Tie
- 11. Clip
- 12. Tube assembly
- 13. Elbow

SERVICE BRAKE CONTROL LINKAGE ADJUSTMENT

(Sheet 1 of 3)

This task covers: Adjustment of service brake control linkage.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None Pages 2-34, 2-35

Equipment Condition

Engine OFF. Parking brake control OUT.

Shipping link installed.

Platform door open.

Special Tools Personnel Required

Steel rule One mechanic

References

PMCS, page 2-5

Parking brake control linkage removal/installation, page 2-343

Shipping link removal/installation, page 2-471.

General Safety Instructions

Release brake pressure by pumping brake pedal until there is no resistance.

Main disconnect switch OFF.

LOCATION/ITENI	ACTION	REMARKS
1. Rod (5) (Refer to page 2-355 for location)	a. Check distance A.	Distance A should be 4.25 m. (108.0 mm).
locations	 b. If distance A is incorrect, adjust rod length. Remove cotter pin (1) from rod end pin (2). Remove rod end pin (2). Loosen nut (3). Adjust rod length by twisting rod end (4) in or out on rod (5). Replace rod end pin (2) and cotter pin (1). Recheck distance A. 	A A A A A A A A A A A A A A A A A A A
		BRAKE CONTROL LINKAGE TA 09873 Go on to Sheet

LOCATION/ITEM	ACTION	REMARKS
2. Rod (7)	a. Check distance B.	Distance B should be 4.40 in. (111.8 mm).
	b. If distance B is incorrect, adjust rod length as described in Item lb on previous page.	
3. Nut (8)	Loosen.	
4. Capscrew (6)	Adjust so that the end just touches lever.	
5. Nut (8)	Tighten.	
6. Nut (9)	Loosen.	
7. CapsCrew (10)	Adjust so that the end just touches lever.	
8. Nut (9)	Tighten.	
	I I	

SERVICE BRAKE PEDALS ADJUSTMENT

(Sheet 1 of 2)

This task covers: Adjustment of service brake pedal travel.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None None Page 2-34

Equipment Condition

Engine OFF. Parking brake control OUT.

Special Tools Personnel Required

Steel rule One mechanic

<u>References</u> General Safety Instructions

PMCS, page 2-5

Release brake pressure by pumping brake pedal until resistance is gone.

Service brake pedals removal/installation, page 2-346 Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
1. Angle assembly (2)	Loosen two capscrews and nuts on angle assembly.	Dimension A should be 3.25 in. (82.6 mm).
2. Lever (1)	Adjust to dimension A.	1——————————————————————————————————————
3. Angle assembly (2)	Move to hold lever (1) at dimension A. Tighten capscrews and nuts on angle assembly.	A
		ADJUSTMENT OF BRAKE PEDAL TRAVEL
		TA 09873
		Enc

SERVICE BRAKE SYSTEM BLEEDING

(Sheet 1 of 5)

This task covers: Bleeding air from service brake system.

Test Equipment	Materials/Parts	Troubleshooting Reference
None	Oil; as required	None
	Hoses	
	Buckets	Equipment Condition
		As described in procedure
		Transmission selector lever in NEUTRAL

Special Tools	Personnel	Required
---------------	-----------	----------

None One mecha	None	One	mechani
----------------	------	-----	---------

References	General Safety Instructions
LO 10-3930-641-12	Be sure vehicle is on level ground.
TM 10-3930-641-10	Install shipping link
PMCS, page 2-5	Place blocks in front of and behind wheels
Parking brake beeding, page 2-360	to prevent vehicle movement.
Shipping link removal/installation,	
page 2-471.	Go on to Sheet 2

Go on to Sheet 2

LOCATION/ITEM	ACTION	REMARKS
	NOTE Be sure to keep hydraulic tank full throughout this bleeding procedure. You'll have to check oil level several times.	
1. Engine	a. Startb. Run at low idle until LOW PRESS BRAKE light goes off.	See TM 10-3930-641-10.
	c. Stop.	See TM 10-3930-641-10. See page 1-22, BRAKE SYSTEM DESCRIPTION, Step 4.
2. Brake control valve plug (1)	Open (turn counterclockwise).	See SYSTEM DESCRIPTIONS, page 1-22 for location.
3. Brake pedal	Push and hold until oil flowing from plug has no air (no bubbles).	
4. Brake control valve plug	Close.	
5. Brake pedal	Release.	
		BRAKE CONTROL VALVE
		1. Plug for removal of air
		TA 098732 Go on to Sheet 3

SERVICE BRAKE SYSTEM BLEEDING (CONT)

(Sheet 3 of 5)

LOCATION/ITEM	ACTION	REMARKS
6. Engine	a. Start.	See TM 10-3930-641-10.
	b. Run at low idle until LOW PRESS BRAKE light goes off.	
	c. Stop.	See TM 10-3930-641-10.
7. Brake pedal	Press 5 times to relieve oil pressure.	
8. Steps 6 and 7	Do two more times.	
9. Hose	Connect to air removal screw (2) at one of the wheel brakes.	
		3000
		AIR REMOVAL SCREW
		TA 098733 Go on to Sheet 4

LOCATION/ITEM	ACTION	REMARKS
10. Engine	a. Start.	See TM 10-3930-641-10.
	b. Run at low idle.	
11. Air removal screw (2)	Turn out 1/2 to 1 turn to let oil flow through hose.	
12. Brake pedal	Push several times until oil flow from the hose las no bubbles.	Flush about a half gallon of oil from the wheel brake.
13. Air removal screw (2)	Tighten.	
14. Steps 9-13	Do for remaining three wheel brakes.	
		Go on to Sheet 5

LOCATION/ITEM	ACTION	REMARKS
15. Engine	a. Start.	See TM 10-3930-641-10.
	b. Run at low idle until LOW PRESS BRAKE light goes off.	
	NOTE	
	Keep engine running.	
16. Brake pedal	a. Hold down for 20 seconds.	
	b. Release for 30 seconds.	
	c. Do steps a. and b. 3 times.	
	d. Release.	
17. Air removal screws (2)	a. Open all four at once.	Do steps 15-16-17 until oil has no bubbles.
	b. Allow oil to drain until there are no more air bubbles.	
	c. Close.	
18. Hydraulic tank	Fill with oil	See LO 10-3930-641-12.
		гJ
	ı I	End

DRIVE SHAFTS MAINTENANCE INSTRUCTIONS

This section covers removal and installation of these drive shaft components for Organizational Maintenance personnel:

- a. Upper drive shaft
- b. Lower drive shaft

LIST OF TASKS (Sheet 1 of 1)

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1	Upper drive shaft removal/installation.	2-377	None
2	Lower drive shaft removal/installation.	2-380	None
	I		En

UPPER DRIVE SHAFT REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Replacing upper drive shaft.

INITIAL	SETUP
---------	--------------

<u>Test Equipment</u> <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None None None

Equipment Condition

Install safety link.

Block wheels.

Remove front lower drive shaft.

Remove rear crankcase guard.

Special Tools Personnel Reauired

Floor jack Two mechanics

References General Safety Instructions

Lower drive shaft removal/installation, page 2-380

LO 10-3930-641-12

PMCS, page 2-5

Drive system description, page 1-20

Rear crankcase guard removal/installation, page 2-483.

Main disconnect switch OFF.

installed toward source of power.

Female portion of drive shaft should be

Go on to Sheet 2

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Four capscrews, nuts, and washers (1) on spider that faces input transfer gear 2. Center of shaft (3) 3. Four capscrews, nuts, and washers (2) on spider that faces torque converter	Remove. Support with hand or jack while doing next step. Remove.	
4. Shaft	Remove.	TA 098734 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION	NOTE	
	Use jack to support shaft.	
1. Shaft with spiders	Lift into place between torque converter and input transfer gear case.	
2. Four capscrews, nuts and washers (1) at transfer gearcase end	Install. Tighten to a torque of 90 to 110 lb. ft. (122 to 149 N·m).	
3. Four capscrews, nuts and washers (2) at torque converter end	Install. Tighten to a torque of 90 to 110 lb. ft. (122 to 149 N ·1m).	

LOWER DRIVE SHAFT REMOVAL/INSTALLATION

(Sheet 1 of 11)

This task covers: Removal and installation of lower drive shaft.

Troubleshooting Reference Materials/Parts Test Equipment

None Suitable wood blocks to support drive shaft while None

on floor jack.

Equipment Condition

Rear crankcase guard removed.

Install shipping link.

Personnel Required Special Tools

Floor jack Two mechanics

> References **General Safety Instructions**

Upper drive shaft removal /installation, Park vehicle on level ground.

page 2-377

LO 10-3930-641-10

PMCS, page 2-5

Drive system description, page 1-20

Rear crankcase guard removal/installation, page 2-483.

Pull parking brake control OUT to prevent vehicle movement.

Block wheels.

Main disconnect switch OFF.

Go on to Sheet 2

2-380

LOCATION/ITEM	ACTION	REMARKS
REMOVAL OF LOWER DRIVE SHAFT, MIDDLE PIECE 1. Four capscrews, nuts, and washers (1) on front spider facing bearing cage 2. Center of shaft	Support middle drive shaft during removal or it may fall and injure you. Two men are required for removal. Shaft weight: 86 lb. (39 kg). Remove. Support shaft with suitable jack while doing next step.	
		TA 098735 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS	3
3. Four capscrews, nuts and washers (2) on rear spider facing transfer gear case	Remove.	REAR	FRONT
4. Shaft - with spiders	Carefully remove.		
		SHAFT WITH	I SPIDERS
			TA 098736
			Go on to Sheet 4

LOCATION/ITEM	ACTION	REMARKS
REMOVAL OF LOWER DRIVE SHAFT, FRONT PIECE 1. Collar(1)	WARNING Support front drive shaft during removal or it may fall and injure you. Two men are required for removal. Shaft weight: 132 lb. (60 kg). a. Loosen. Slide to the rear.	REARWARD
		TA 098737 Go on to Sheet 5

LOWER DRIVE SHAFT REMOVAL/INSTALLATION (CONT)

LOCATION/ITEM	ACTION	REMARKS
2. Six capscrews, nuts, and washers (2)	Remove.	
3. Shaft and bearing cage (3)	a. Support shaft with suitable jack while doing next step.b. Pull shaft and bearing cage rewward, out of main frame.	FRONTWARD REARWARD TA 098738 Go on to Sheet 6

LOCATION/ITEM	ACTION	REMARKS
LOCATION/ITEM Four nuts, capscrews, and washers (4)	a. Remove. b. Remove spider and front shaft yoke assembly (5).	REMARKS
		5 TA 088

2-385

WARNING Support rear drive shaft during removal or it will fall and injure you. Two men are required for removal. Shaft weight: 55 lb. (25 kg). REMOVAL OF LOWER DRIVE SHAFT, REAR PIECE 1. Four capscrews, nuts, and washers (1) Support shaft with hands or suitable jack while doing next step. VIEW FROM UNDER MACHINE TA 088740 Go on to Sheet 8	LOCATION/ITEM	ACTION	REMARKS
doing next step. 3. Four capscrews, nuts, and washers (2) 4. Shaft with spiders Remove. Remove. VIEW FROM UNDER MACHINE TA 098740	DRIVE SHAFT, REAR PIECE 1. Four capscrews, nuts, and washers	Support rear drive shaft during removal or it will fall and injure you. Two men are required for removal. Shaft weight: 55 lb. (25 kg).	3
4. Shaft with spiders Remove.	2. Center of shaft (3)	Support shaft with hands or suitable jack while doing next step.	
TA 098740	3. Four capscrews, nuts, and washers (2)	Remove.	VIEW FROM UNDER MACHINE
	4. Shaft with spiders	Remove.	TA 000740

-	_	
LOCATION/ITEM	ACTION	REMARKS
INSTALLATION OF LOWER DRIVE SHAFT, FRONT PIECE		
1. Bearing cage and shaft (1)	a. Support shaft with a floor jack (2).	
	b. Push shaft partly into main frame.	
2. Spider and front shaft yoke (3)	a. Slide onto splined end of front shaft (4).	
	b. Aline spider with yoke of front differential.	
3. Four capscrews, nuts, and washers (5)	Install. Torque from 90 to 110 lb. ft. (122 to 149 N•m).	TA 098741
		Go on to Sheet 9

LOCATION/ITEM	ACTION	REMARKS
4. Bearing cage and shaft	Aline holes in main frame with holes in bearing cage.	6
5. Six capscrews, nuts, and washers (6)	Install.	
6. Collar (7)	Slide collar and seal forward; tighten.	
		BEARING CAGE
		TA 098742 Go on to Sheet 10

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION OF LOWER DRIVE SHAFT, MIDDLE PIECE		8
1. Shaft with spiders (8)	a. Lift into place between frames of vehicle.b. Jack or block up shaft to keep it in place.	6000
2. Four capscrews, nuts, and washers (9)	Install. Torque from 90 to 110 lb. ft. (122 to 149 N•m).	
3. Four capscrews, nuts, and washers (10)	Install. Torque from 90 to 110 lb. ft. (122 to 149 N•m).	REAR FRONT
		TA 098743 Go on to Sheet 11

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION OF LOWER DRIVE SHAFT, REAR PIECE		
1. Shaft with spiders (1)	Lift into position.	3
2. Four capscrews, nuts, and washers (2)	Install. Torque from 90 to 110 lb. ft. (122 to 149 N•m).	2
3. Four capscrews, nuts, and washers (3)	Install. Torque from 90 to 110 lb. ft. (122 to 149 N•m).	
		VIEW FROM UNDER MACHINE
		TA 098745 End

DIFFERENTIALS AND TIRE MAINTENANCE INSTRUCTIONS

T'his section covers service of these differential and tire components for Organizational Maintenance personnel:

- a. Change oil in differentials and final drive.
- b. Inspect tire pressure and add air.
- c. Tires and rims removal/installation.

LIST OF TASKS (Sheet 1 of 1)

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1	Front and rear axle /fintd drive service.	2-392	2-45
2	Tire service.	2-397	Nrone
3	Tires and rims removal.	2-398.1	None
4	Tires and rims installation.	2-398.3	None
5	Tire removal/installation.	2-398.5	None
			End

Change 1 2-391

FRONT AND REAR AXLE/FINAL DRIVE SERVICE

(Sheet 1 of 5)

This task covers: Changing oil in differentials and final drives.

INITIAL SETUP

Materials/Parts Troubleshooting Reference Test Equipment

MIL-L-2105 lubricant (27 gal. ea.) Page 2-45 None

GO 80, 27 gallons (102 liters)

(Item 5, Appendix C) **Equipment Condition**

Containers to catch waste oil Shipping link installed

Vehicle tires blocked

Special Tools Personnel Reauired

One mechanic None

> References **General Safety Instructions**

Park vehicle on level ground. LO 10-3930-641-12

PMCS, page 2-5 Lower mast.

Shipping link removal/installation, page 2-471 Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
1. Final drive drain plugs (1)	a. Position each wheel, in turn, with drain plug down.	
	b. Remove plug.	
	c. Drain oil.	O wow of
	d. Clean plugs.	
	e. Install.	
2. Differential drain plugs (2), front and rear	a. Remove.	
	b. Drain oil.	2
	c. Clean plugs.	
	d. Install.	
		TA 098746
	I	Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
3. Front differential fill plug (3)	a. Remove.	See LO 10-3930-641-12
	b. Fill differential to bottom of fill plug opening.	3
	c. Install plug.	
		TA 09874 Go on to Sheet

LOCATION/ITEM	ACTION	REMARKS
4. Rear differential oil level plug (4)	a. Remove.	
	b. Clean.	The state of the s
5. Final drive fill plugs (5)	a. Rotate each wheel so that final drive fill plug is at the horizontal center line of the wheel.	
	b. Remove fill plugs (5).	
	c. Fill rear differential slowly through fill plug opening for final drive. Fill to bottom of oil level plug opening.	5
	d. Install oil level plug (4).	See LO 10-3930-641-12.
		TA 098748 Go on to Sheet 5

LOCATION/ITEM	ACTION	REMARKS
5. Final drive fill plugs (cont)	e. Fill final drives to bottom of fill plug opening.	See LO 10-3930-641-12.
	f. Clean fill plugs.	
	g. Install.	
		End

TIRE SERVICE (Sheet 1 of 2)

This task covers: Servicing tires.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

Tire pressure gage None None

Equipment Condition

Parking brake control out

Engine OFF

Special Tools Personnel Required

Source of low pressure air, self-attaching air chucks with distant valve control.

One mechanic

References General Safety Instructions

None Stand behind tire when inflating.

 $Main\ disconnect\ switch\ OFF.$

TIRE SERVICE (CONT) (Sheet 2 of 2)

LOCATION/ITEM	ACTION	REMARKS
1. Tire pressure	a. Check with a tire pressure gage.	Tire pressure to be 70 psi (483 KPa) (front) 40 psi (276 KPa) (rear)
	WARNING	
	To prevent injury while inflating tires, stand behind tire and use a self-attaching air chuck.	
	b. Inflate if low. See page 2-400.	
2. Air	Bleed moisture from air source at the accumulator and through the air hose.	
3. Tire valve stem and self-attaching air chucks	Install chuck on valve stem (1).	
	WARNING	
	Stand behind tire when inflating. Use selfattaching air chuck.	AAN CAR
4. Tire	Inflate to:	
	70 psi (front)	
	40 psi (rear)	TA 098749 End

(Sheet 1 of 2) TIRES AND RIMS REMOVAL

This task covers: Removal of tires and rims.

INITIAL SETUP

Troubleshooting Reference Materials/Parts Test Equipment

Wooden blocks None None

Equipment Condition

Engine OFF

Parking brake ON.

Shipping link installed

Personnel Required Vehicle parked on hard level ground (preferably concrete). Special Tools

None Two mechanics

> References **General Safety Instructions**

Block wheels except one being removed. None

LOCATION/ITEM	ACTION	REMARKS
1. Blocks	Block front and back tires that are not being removed.	
2. Hydraulic jacks (1)	a. Position under front main frame.b. Lift. machine until forks of a lift truck can be positioned under tire.c. Place wood block under front axle housing to help hold machine up.	
3. Nuts (2) and washers that hold tire and rim	Remove.	2
4. Lift truck	a. Position lift truck under tire.b. Fasten tire and rim to truck.	
5. Tire and rim	Remove. Tire and rim are 3000 lb. (1361 kg).	TA501737

Change 1

2-398.2

(Sheet 1 of 2) TIRES AND RIMS INSTALLATION

This task covers: Installation of tires and rims.

INITIAL SETUP

Troubleshooting Reference Test Equipment Materials/Parts

None None As required

Equipment Condition

Engine OFF.

Parking brake ON.

Shipping link instalied.

Personnel Required Special Tools Vehicle parked on hard level ground (preferably concrete)

Two mechanics None

> References **General Safety Instructions**

Tires and rim removal, page 5-80. Block wheels except one being installed.

LOCATION/ITEM	ACTION	REMARKS
1. Tire and rim (1)	a. Fasten to forks of lift truck.b. Position tire and rim- on wheel assembly.	
2. Four nuts and washers	a. Instali to hold tire and rim to wheel assembly.b. Remove lift truck.	
3. Nuts and washers that secure tire and rim	Install. Tighten to a torque of 340-440 lb, ft. (460-596 N•m).	
4. Hydraulic jacks (2)	Lift machine and remove wood blocks from under front axle housing.	
	Lower machine to floor.	
		2
		TA501738

Change 1 2-398.4

TIRE REMOVAL/INSTALLATION (Sheet 1 of 7)

This task covers: Replacement of tire with wheel assembly on vehicle.

INITIAL SETUP

Test Equipment Materials/Parts <u>Troubleshooting Reference</u>

None Tire None.

Wooden blocks

Equipment Condition

Machine parked on hard level ground

(preferably concrete).

Safety link installed on main frames of

machine.

Special Tools Personnel Required

Sledge hammer One mechanic

Pry bars

References General Safety Instructions

Bead breaking tool kit


None

All air must be released from tire. Check

valve stem by running a piece of wire through it to make sure it is not plugged. Stand to one side of tire while inflating.

(Sheet 2 of 7)

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Blocks	Block both sides of front and rear tires that are not being serviced.	
2. Tire	Raise off ground using hydraulic jack under axle housing near tire being serviced.	If not parked on concrete, place hardwood blocks under jack.
3. Blocks	Place under axle housing. Lower hydrauiic jack.	
4. Valve stem cap (7)	Remove.	
5. Valve stem core (6)	Remove slowly using valve stem core removal tool.	
	WARNING	
	All air must be exhausted from tire. Check the valve stem by running a piece of wire through it to make sure it is not plugged.	
		Go on to Sheet 3



- Rim
 Preformed packing
- 3. Spud
 4. Airvalve assembly
- 5. Nut
- 6. Valve stem core 7. Valve stem cap

- 8. Flange
 9. Tire assembly
 10. Tire
 11. Preformed packing
 12. Flange
 13. Band
 14. Lock ring

- 15. Driver
- 16. Preformed packing 17. Spud 18. Nut
- 19. Preformed packing

TA501739

Go on to Sheet 4

2-398.7 Change 1

2-398.8

Change 1

TIRE REMOVAL/INSTALLATION (CONT)

LOCATION/ITEM	ACTION	REMARKS
6. Band (13)	Drive back far enough to remove driver (15) using a sledge hammer.	
7. Driver (15)	Remove.	
8. Lock ring (14)	Remove using hammer and pry bars.	
9. Preformed packing (11)	Remove.	
10. Bead breaking tool (A)	a. Attach to rim as shown.	
	b. Break bead and insert metal bead wedge (B).	
	c. Continue to break bead in as many places as necessary around tire.	TYPICAL TIRE REMOVAL TOOLS
11. Band (13)	Remove using pry bars.	A
12. Flange (12)	Remove.	TA501740
		Go on to Sheet 5

(Sheet 5 of 7)

LOCATION/ITEM	ACTION	REMARKS
13. Bead breaking tool (A)	a. Attach to rear of tire.	
	NOTE	
	There are only two places (180° apart) where tool (A) can be attached.	
	b. Break bead and insert metal bead wedge.	
	c. Move 180° and break second bead.	
14. Two lifting cables	Cradle tire and attach to hoist.	
15. Tire (10)	Remove.	
16. Flange (8)	Remove.	
INSTALLATION		
1. Nut (5), spud (3) and preformed packing (2)	Remove and install using new preformed packing.	
2. Flange (8)	Install.	
3. Tire (10)	Install using lifting slings and hoist.	
4. Band (13)	Insert in flange (12) and install both on tire (10).	Go on to Sheet 6

(Sheet 6 of 7)

LOCATION/ITEM	ACTION	REMARKS
5. Band (13)	Pound back far enough to expose second groove in rim.	
6. Preformed packing(11)	a. Lubricate with engine oil.b. Install in second groove making sure it does not get twisted or cut.	No.
	c. Pull band (13) gently over preformed packing.	
7. Lock ring (14)	Insert end as shown and turn 90°. Ring must be engaged in first groove all around rim.	
8. Drive (15)	Install.	
		TA501741
		Go on to Sheet 7

Change 1 2-398.10

LOCATION/ITEM	ACTION	REMARKS
	NOTE Apply a liquid detergent solution to tiont and rear bead areas on tire.	
9. Valve stem	a. Attach air chuck. WARNING Stad to one side of the - not in front d rim area - when inflating tire.	Use self-attaching type air chuck with valve core remove. After seal is made, install valve core.
	b. Inflate tire to 70 psi front, 40 psi rear.	You may have to compress tire, using chains and cable hoist, to get beads to seal.
	c. Install valve cap.	
10. Axle housing	Raise with hydraulic jack, remove wood Mocks and lower titil tire rests on ground.	
11. Shipping link	Disconnect.	
		ENI

TRANSMISSION MAINTENANCE INSTRUCTIONS

This section covers removal and installation of these transmission components for Organizational Maintenance personnel:

- a. Filter
- b. Linkage

Also instructions for servicing the transmission and adjusting the control linkage.

LISTS OF TASKS (Sheet 1 of 1)

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1	Transmission oil filler assembly removal/installation.	2-400	None
2	Transmission service.	2-402	2-44, 2-46, 2-47
3	Transmission control linkage adjustment	2-407	2-46, 2-47, 2-48
4	Transmission controls removal/installation.	2-412	2-47, 2-48

TRANSMISSION OIL FILLER ASSEMBLY REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal and installation of Transmission oil filler assembly.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

None Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
EOCATION/ITEM	ACTION	TEMAKKS
REMOVAL		2 5 6 4 7
1. Plug (15)	Remove.	
2. Capscrews (8), (9) and washers (11), (3)	Remove.	/9 /9 /9 /9 /9 /9 /9 /9 /9 /9 /9 /9 /9 /
3. Filler tube (16)	Remove with bracket (13).	3 4
4. Preformed packing (17)	Replace.	15
INSTALLATION		14
1. Filler tube (16) and bracket (13)	Place in position with preformed packing (17).	10
2. Capscrews (8) and washers (11)	Install.	
3. Capscrews (9) and washers (3)	Install.	3 13
4. Plug (15)	Install.	
		16
		17
		TA 172222
		End

TRANSMISSION SERVICE (Sheet 1 of 5)

This task covers: a. Changing transmission oil

b. Replacing filter

c. Cleaning magnetic strainer assembly

d. Replacing torque converter breathers

e. Replacing transmission breathers

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Oil per LO 10-3930-641-12
Torque converter breather Pages 2-44, 2-46, 2-47

Transmission breather Oil filter elements, two

Cover gasket Solvent

Cleaning compound, Item 2, Appendix C

Container to catch waste oil

Face shield

Protective clothing

Stiff brush

Special Tools Personnel Required

Air nozzle and source of low pressure air

Two mechanics

References General Safety Instructions

PMCS, page 2-5 Park the vehicle on level ground.

LO 10-3930-641-12 Lower mast.

Turn POWER switch to OFF.

Equipment Condition

Access doors open

Engine OFF and cooled

Hot oil and parts can cause bums. Be careful during servicing procedure not to spill

hot oil on you.

Go on to Sheet 2

2-402

LOCATION/ITEM	ACTION	REMARKS
1. Drain plug (1)	a. Remove.b. Drain oil.c. Clean drain plug and install.	
2. Magnetic strainer (2)	Do not drop or rap magnet against hard objects. Magnets will be damaged.	
	 a. Remove four capscrews and cover. b. Remove magnetic strainer. c. Wash screen and cover in clean, non-flammable solvent. WARNING When using pressure air, wear face shield and protective clothing to prevent injury. Use 30 psi maximum pressure for cleaning. d. Clean magnets with pressure air or stiff brush. 	See PMCS, page 2-5.
		TA 098751 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
 Magnetic strainer (cont) Transmission oil cooler lines (3, 4) Transmission oil filter 	e. Replace damaged magnets.f. Replace cover seal if damaged.g. Install strainer cover and four capscrews.Check for damage. Replace if necessary.NOTE	3 4
	Place pan under filter housing to prevent spillage. a. Remove filter housing drain plug (5). b. Drain oil. c. Remove filter housing (6). d. Remove and discard filter element (7). e. Clean filter housing base (8). f. Wash filter housing in clean, non-flammable solvent. WARNING When using pressure air, wear face shield and protective clothing to prevent injury. Use 30 psi maximum pressure for cleaning.	See PMCS, page 2-5. TA 098752 Go on to Sheet 4

TRWSMISSION SERVICE (CONT)

(Sheet 4 of 5)

LOCATION/ITEM	ACTION	REMARKS
4 . Transmission oil filter (cont)	g. Install new filter element in housing.	See PMCS, page 2-5.
	h. Install filter housing.	9
	i. Clean and install drain plug.	
5. Transmission breather (9), and torque converter breather (10)	a. Remove and discard.	
	b. Replace.	
		TA 098753
		Go on to Sheet 5

LOCATION/ITEM	ACTION	REMARKS
6. Transmission	Remove cap (11) and fill transmission.	See LO 10-3930-641-12.
7. Engine	Start and run at low idle.	See TM 10-3930-641-10.
8. Dipstick (12)	Use to check oil level.	Oil level should be between LOW and FULL marks on dipstick. Add oil if necessary.
9. Transmission oil filter	Check seat for leaks.	
10. Engine	Stop.	TA 098754 End

TRANSMISSION CONTROL LINKAGE ADJUSTMENT

(Sheet 1 of 5)

This task covers: Adjustment of transmission control linkage.

INITIAL SETUP

Materials/Parts Test Equipment Troubleshooting Reference

Pages 2-46, 2-47, 2-48 None None

Equipment Condition

Turn engine OFF while adjusting linkage so that vehicle does not slip into gear and move. Pull parking brake control OUT. Install shipping link.

Personnel Required Special Tools

Two mechanics None

> References **General Safety Instructions**

Main disconnect switch OFF. PMCS, page 2-5

Transmission controls removal/installation, page 2-412.

Shipping link removal/installation, page 2-471.

LOCATION/ITEM	ACTION	REMARKS
1. Stop (1)	 Check stop for proper adjustment. If stop is out of adjustment: a. Put control lever in NEUTRAL. b. Move steering column (3) forward to stored position. c. Loosen capscrews (2). d. Move stop until end just touches lever assembly (4). e. Tighten capscrews (2). 	Stop (1) must move lever (4) to NEUTRAL when steering column is in stored position.
2. Speed control linkage (Located on steering hydraulic controls. See page 2-409.)	 Adjust: a. Remove cap screws (1) and lockwashers (2). b. Loosen nut (3) from cable threads (5) and slide washer (11) and seal (10) back. c. Turn bracket (4) off threads (5). d. Lift pins (6) and yoke (7) out of slot in speed selection spool (8). 	STOP ADJUSTMENT 7 9 4 10 8 6 5 2 1 11 3 SPEED CONTROL LINKAGE TA 098755 Go on to Sheet 3

(Sheet 3 of 5)

LOCATION/ITEM	ACTION	REMARKS
2. Speed control linkage (cont)	e. Pull speed selection spool (8) out of case until it does not move.	DIRECTION CONTROL LINKAGE
	f. Hold speed selection spool (8) and install pin (6) in slot of spool. If pin cannot be installed without moving spool, loosen nut (9) to adjust yoke (7). Tighten nut (9).	
	g. Install bracket (4) on threads (5). Turn until it is even with face of transmission case.	
	h. Install capscrews (1) and lockwashers (2) into holes in transmission case.	
	i. Install seal (10), washer (11), and nut (3) against bracket (4).	SPEED CONTROL LINKAGE
		TA 0988
		Go onto Sheet

LOCATION/ITEM	ACTION	REMARKS
LOCATION/ITEM 3. Direction control linkage.	 Adjust: a. Move steering column all the way forward to stored position. Control lever will be in NEUTRAL. b. Remove capscrews (1) and lockwashers (2). 	3 1 2 7 11 9 12
	c. Loosen nut (3) from cable threads (4).d. Move washer (5) and seal (6) off threads (4).	5 6 4 8 10
	e. Remove bracket (7) from threads (4).	
	f. Lift pins (8) and yoke (9) out of slot in rod (10).	
		TA 098756 Go on to Sheet 5

LOCATION/ITEM	ACTION	REMARKS
. Direction control linkage (cent)	g. Hold rod (10) and install pin (8) into slot in rod. If pin cannot be installed without moving rod, loosen cam (11) and adjust yoke (9). Tighten cam (11).	
	h. Install bracket (7) on threads (4) until it is even with face of lock group (12).	
	i. Install capscrews (1) and lockwashers (2) into holes in lock group (12).	
	j. Install seal (6), washer (5), and nut (3). Tighten nut against bracket.	

TRANSMISSION CONTROLS REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Replacement of transmission controls.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None As required Pages 2-47, 2-48

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Transmission controls linkage adjustment, Main disconnect switch OFF. page 2-407

PMCS, page 2-5

Location, page 2-409

Go on to Sheet 2

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		TRANSMISSION——
1. Clamp (1)	Disconnect.	SHIFT LEVER
2. Four capscrews (2)	Remove.	LEVER
3. Control cable assemblies (3) and (4)	Detach.	
4. Retaining nuts (5)	Unscrew.	
5. Bracket (6)	Slide up cable.	3————
6. Pins (7)	Lift out of slots.	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\
7. Controls	Discard.	1
INSTALLATION 1. Controls 2. Control cable assemblies (3) and (4) 3. Capscrews (2) and clamp (1) 4. Control linkages	Place in position. Attach. Install. Adjust. (See page 2-407.)	5 2 7 6 5 2 TA 098757

STEERING SYSTEM MAINTENANCE INSTRUCTIONS

This section covers removal and installation of these steering system components for Organizational Maintenance personnel:

a. Steering wheel

b. Steering filter

Also instructions for steering system tests.

LIST OF TASKS (Sheet 1 of 1)

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1	Steering wheel removal/installation.	2-415	None
2	Steering system tests.	2-417	2-48
3	Steering filter service.	2-421	None
		I	End

STEERING WHEEL REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal and installation of steering wheel.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None None

Equipment Condition

Engine OFF

Special Tools Personnel Required

Steering wheel puller One mechanic

References General Safety Instructions

None Pull parking brake control OUT.

Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		2
1. Screws (1)	Remove three from center cover (2) of steering wheel (4).	3
2. Cover (2)	Remove.	
3. Nut, lockwasher, washer (3)	Remove from steering shaft.	
4. Steering wheel (4)	Install steering wheel puller (5) and remove steering wheel.	4
INSTALLATION 1. Steering wheel (4) 2. Nut, lockwasher, washer (3) 3. Cover (2)	Install. Install. Tighten nut to a torque of 34-40 lb. ft. (46-54 N•m). Install.	5
4. Screw (1)	Install three in cover.	TA 098758

STEERING SYSTEM TESTS (Sheet 1 of 4)

This task covers: Check of hydraulic oil, steering time test, and steering slip test.

INITIAL SETUP

<u>Test Equipment</u> <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

Stopwatch Container for hydraulic fluid Page 2-48

Magnet Equipment Condition

LO 10-3930-641-12

As stated in procedure

Special Tools Personnel Required

None Two mechanics

References General Safety Instructions

Transmission service, page 2-402 Remove hydraulic reservoir cap slowly. Reservoir is under pressure.

Perform operational tests in area clear of personnel and obstructions.

Go on to Sheet 2

LOCATION/ITEM	ACTION	REMARKS
HYDRAULIC OIL CHECK	Remove hydraulic reservoir cap slowly to prevent sudden release of pressure.	
1. Hydraulic oil	Measure.	
2. Hydraulic reservoir	Check hydraulic oil immediately after engine is stopped:	
	a. Take sample of oil in clear container. Check sample for air bubbles. If air bubbles are found, send vehicle to Direct Support Maintenance for further tests and repair.	
	b. Remove filter elements. Check for foreign particles in oil. Use a magnet to separate iron. If foreign particles are found, send vehicle to Direct Support Maintenance for repair.	Particles may be metal from grating parts or non-metal from damaged seals, preformed packings, etc. See transmission service, page 2-402.
		Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
STEERING TIME TEST	NOTE	
	Perform tests with vehicle on dry, hard surface and brake OFF.	
. Steering wheel	With engine at high idle, turn from stop to stop and from each stop to center.	Turning time from stop to stop must be between 2.6 and 3.0 seconds. The difference between right turn and left turn time must not be more than 0.3 seconds.
2. Brakes	With engine at high idle, push brake pedal and turn steering wheel from stop to stop.	Turning time must not increase more than 0.2 seconds from time with brake OFF.
		If vehicle steering time does not meet these specifications, send vehicle to Direct Support Maintenance for adjustments and repair.
3. Carriage	Raise.	
	1	Go on to Sheet

STEERING SYSTEM TESTS (CONT)

(Sheet 4 of 4)

LOCATION/ITEM	ACTION	REMARKS
STEERING SLIP TEST 1. Brakes	Release.	
2. Steering wheel	With engine running at low idle:	
	a. Turn through one revolution in each direction.	Steering resistance should increase when direction is changed.
	b. Turn slowly from stop to stop.	Steering should be smooth, not jerky, and should be at constant speed without irregular motion.
	c. Begin turning and release wheel.	Steering wheel should stop.
		If vehicle fails these tests, send to Direct Support Maintenance for repairs.
		Enc

STEERING FILTER SERVICE (Sheet 1 of 2)

This task covers: Steering filter service

INITIAL SETUP

<u>Test Equipment</u> <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Cleaning Compound, Item 2, Appendix C None

Clean lint-free rag, Item 16, Appendix C

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

LO 10-3930-641-12 Main disconnect switch OFF

LOCATION/ITEM	ACTION	REMARKS
1. Capscrews (1) and washers (2)	Remove.	
2. Cap (3)	Remove.	1,2 1,2 3
3. Strainer	Remove and clean in cleaning solvent. Dry with clean lint-free rag.	
4. Strainer	Install.	
5. Cap (3)	Place in position.	
6. Capscrews (1) and washers (2)	Install.	
		Too Too
		TA172223
		End

2-422

BODY ACCESSORY ITEMS MAINTENANCE INSTRUCTIONS

This section covers removal and installation of these accessory items for Organizational Maintenance personnel:

- a. Mirrors
- b. Wipersc. Cab heater and defroster

Also instructions for servicing cab air filters.

(Sheet 1 of 1) LIST OF TASKS

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1	Mirrors removal/installation.	2-424	None
2	Windshield wiper motor and linkage removal/installation.	2-426	None
3	Cab floor heater removal/installation.	2-434	None
4	Cab heater and defroster removal/installation.	2-440	None
5	Filter for cab heater removal/installation.	2-450	None
			End

MIRRORS REMOVAL/INSTALLATION (Sheet 1 of 2)

This task covers: Removing and installing the side mount mirrors.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None None None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Torque limits chart, page E-1 Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
COMPLETE ASSEMBLY		
REMOVAL	NOTE	4
	Mirror assembly will fall when six capscrews are removed.	
1. Capscrews (1)	Remove six.	
2. Mirror assembly (2:	Remove.	3
INSTALLATION		
1. Mirror assembly (2)	Put in position.	
2. Capscrews (1)	Install.	
MIRROR ONLY		
REMOVE		
1. Clip (3), capscrews, nuts, washers	Remove.	
2. Mirror (4)	Remove.]
INSTALLATION		
1. Mirror	Put in position.	
2. Clip (3), capscrews, nuts, washers	Install.	TA 098759 End

WINDSHIELD WIPER MOTOR AND LINKAGE REMOVAL/INSTALLATION

(Sheet 1 of 8)

This task covers: Replacement of windshield wiper motor and linkage.

NOTE

This procedure covers both the front and rear windshield wiper motor and linkage removal and installation.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None As needed None

Equipment Condition

Engine OFF

Special Tools Personnel Required


None One mechanic

References General Safety Instructions

Torque limits chart, page E-1 Main disconnect switch OFF.

(Sheet 2 of 8)

LOCATION/ITEM	ACTION	REMARKS
		LEGEND FOR PAGE 2-428
REMOVAL		1. Terminal
		2. Washer
		3. Capscrew
Nut (10), lockwasher (12), jam nut	Remove from wiper arm shaft.	4. Motor housing
(11), preformed packing (13), wiper		5. Spacer
arm assembly (9) and driver (14)		6. Cap 7. Shaft
		8. Blade
Cap (6) and nut behind it, spacer (5)	Remove.	9. Wiper arm assembly
and shaft (7)	Remove.	10. Nut
and shart (1)		11. Jam nut
		12. Lockwasher
		13. Preformed packing
Three nuts (24). Three retainers	Remove.	14. Driver
with seals (25), (26), (27)		15. Cover
		16. Tank
		17. Nozzle
		18. Spacer
		19. Hose
Five screws and lockwashers, panel	Remove.	20. Blade
and seal of cab dashboard		21. Wiper arm assembly
		22. Spacer
		23. Spacer 24. Nut
Fight cancerous lockwashers	Remove.	25. Retainer
Eight capscrews, lockwashers, washers and cover of cab dashboard	wemove.	26. Seal
washers and cover of cab dashboard		27. Seal
		28. Nut
		29. Stud
		30. Grommet
		Go on to Sh



Go on to Sheet 4

LOCATION/ITEM	ACTION	REMARKS
6. Four capscrews and lockwashers	Remove from steering position bracket and remove bracket.	
7. Three terminals (1)	Discomect and remove wiper motor and linkage.	
8. Washer nozzle (17) and spacer (18)	Remove. Remove hose (19) and nut from inside cab.	
		Go on to Sheet 5

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION		
1. Washer nozzle (17) and spacer 18)	Install.	
2. Nut and hose (19) from washer pump	Install on nozzle.	
3. Wiper motor and linkage	Place in position.	
4. Three terminals (1)	Connect.	
		Go on to Sheet 6

(Sheet 6 of 8)

LOCATION/ITEM	ACTION	REMARKS
5. Seal (25) in retainer (26), nut (24), and nut (28)	Install on stud.	
6. Spacer (5)	Install on wiper arm shaft (7).	
7. Cap (6)	Install on wiper arm shaft (7).	
		Go on to Sheet 7

LOCATION/ITEM	ACTION	REMARKS
8. Driver (14)	Install on wiper arm shaft.	
	Turn wiper motor ON to find correct position for wiper arm assembly. Stop motor.	
9. Wiper arm assembly (9)	Install on wiper arm shaft. Fine adjustments for the wiper arm at REST position can be made with capscrew on back of motor assembly gear box.	
10. Lockwasher (12) and nut (10)	Install on wiper arm shaft.	
11. Steering positioner bracket and rack	Install with four bolts, lockwashers and washers.	
		Go on to Sheet 8

LOCATION/ITEM	ACTION	REMARKS
12. Cab dashboard cover	Put over steering positioner bracket and install eight bolts, lockwashers, and washer to hold it.	
13. Dashboard panel and seal	Install using five screws and lockwashers.	
		E ₁

CAB FLOOR HEATER REMOVAL/INSTALLATION

(Sheet 1 of 6)

This task covers: Removal and installation of cab floor heater.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		2
1. Container lock indicator panel	Remove. (See page 2-298.)	
2. Two capscrews and washers (1), "off-on" switch plate (2)	Remove. Lift up switch plate (2).	
3. Two wires that are connected to switch	a. Put identification on them for correct installation.	
	b. Disconnect.	NII IIIAAA
4. Twelve capscrews and lockwashers that secure panels (3) and (4)	Remove three of each at heater panel (3); nine of each at hydraulic control console front panel.	4
5. Panels (3) and (4)	Remove.	TA 098762
		Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
6. Two heater hose shut-off valves (10) on engine	Turn clockwise to closed position.	
7. Inlet shut-off valve (9) at cab heater	Turn clockwise to closed position.	7 6
8. Two chunps (5)	Loosen.	5
9. Two hoses (6)	Tag for identification anckdisconnect horn heater assembly.	8
10. Two capscrews, lockwashers, and washers (7) on heater bracket	Remove.	g Inc
11. Heater assembly and bracket (8)	Remove.	TA 098763 Go on to Sheet 4

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION 1. Heater assembly and bracket (1)	Position in cab.	
2. Two capscrews, lockwashers, and washers (2)	Install in heater bracket.	
3. Two clamps (3) and two hoses (4)	a. Put loosened clamps on ends of hoses.b. Connect hoses to proper fittings on heater.c. Slide clamps up and tighten them.	
		TA 098764
		Go on to Sheet 5

LOCATION/ITEM	ACTION	REMARKS
4. Heater panel (5)	a. Position over heater.b. Pull two wires (6) through hole in top of panel.	
5. Three capscrews and lockwashers that secure heater panel	Install in panel.	EMI- 21 ME, DOMES OF STOP
6. Two wires (6) and switch plate (7)	Connect wires to correct terminals on switch.	
7. Two capscrews that secure switch plate to heater panel	Install.	
		TA 098765 Go on to Sheet 6

LOCATION/ITEM	ACTION	REMARKS
8. Hydraulic control console front panel (8)	Position in cab.	2009
9. Nine capscrews and lockwashers that secure hydraulic control console front panel	Install.	
		TA099228
		End

CAB HEATER AND DEFROSTER REMOVAL/INSTALLATION

(Sheet 1 of 10)

This task covers: Removal and installation of cab heater and filter.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None As required None

Equipment Condition

Main disconnect switch OFF

Special Tools Personnel Required

Two 1/2-13 NC forged eyebolts One mechanic

Four 5/16-18 NC forged eyebolts

Hoist References General Safety Instructions

Torque limits chart, page E-1 Vehicle engine must be off.

Battery must be disconnected.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Fourteen capscrews and washers around edges of cover (1)	Remove.	2
2. Two 1/2-13 NC forged eyebolts with nuts and washers (2)	a. Lift one side of the cover, block it securely and install eyebolt. Repeat for other eyebolt.b. Fasten hoist to eyebolts and remove cover. Cover weighs 92 lb. (42 kg).	
3. Two hose clamps and two heater hoses (3)	a. Loosen clamps.b. Disconnect hoses (4).	TA 098767 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
4. Heater temperature control knob (4)	Loosen setscrew and remove knob from control console (7).	
5. Fan speed knob (5)	Loosen setscrew and remove knob from control console (7).	5
6. Eight capscrews (6)	Remove.	6
7. Control console (7)	Lower.	
8. Wires at fan switch (5)	Disconnect. Put identification on wires for correct installation.	
		TA 098768
		Go on to Sheet 4

LOCATION/ITEM	ACTION	REMARKS
9. Circuit breaker terminal(9)	Disconnect white/blue wire at terminal. Put identification on wire for correct installation.	
10. Four nuts and washers (10) that hold heater unit to cab	Remove.	9
11. Air duct (11)	Remove.	
		TA 098769 Go on to Sheet 5

LOCATION/ITEM	ACTION	REMARKS
12. Ten nuts and washers (12) that hold heater unit to cab	Remove.	
13. Four 5/16-18NC forged eyebolts (13)	 a. Install eyebolts in top of heater unit (14). b. Attach a hoist to eyebolts as shown. c. Lift heater unit from cab. Heater unit weighs 105 lb. (47.6 kg). 	TA 098770 Go on to Sheet 6

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION 1. Four 5/16-18NC forged eyebolts (1)	 a. Install on top of heater unit (2). b. Attach a hoist to eyebolts as shown. c. Lift heater unit above Roll-Over Protective Structure (ROPS). d. Lower heater unit into position. 	TA 098771
		Go on to Sheet 7

LOCATION/ITEM	ACTION	REMARKS
2. Two clamps (3)	Slide loosened clamps over ends of heater hoses (4).	
3. Two heater hoses (4)	a. Connect hoses to fittings on heater unit.b. Slide clamps over hose and fittings and tighten clamps.	3
4. Two 1/2-13NC forged eyebolts with nuts and washers (5)	a. Install on cover (6).b. Attach hoist to eyebolts as shown.c. Lift cover above Roll-Over Protective	
	Structure (ROPS). d. Position cover on ROPS. e. Lift one side of cover, block it securely and remove eyebolt.	5
5. Cover (6)	f. Remove second eyebolt the same way. Position on ROPS.	TA 098772 Go on to Sheet 8

	LOCATION/ITEM	ACTION	REMARKS
6.	Fourteen capscrews and washers that hold cover (6) t.n ROPS.	Install.	
7.	Ten nuts and washers (7) that hold heater unit to cab	Install. Tighten nuts to a torque of 100-180 lb. in. (11 to 30 N•m).	TA 098773 Go on to Sheet 9

LOCATION/ITEM	ACTION	REMARKS
8. Airduct (8)	Position under four heater unit mounting nuts in front of cab. Side with circuit breaker (9) must face the rear of cab.	
9. Four nuts andwashers that hold air duct bracket	Install. Tighten nuts to a torque of 100-180 lb. in. (11 to 30 N•m).	
10. Circuit breaker terminal (9)	Connect white/blue wire (10).	TA 098774 Go on to Sheet 10

LOCATION/ITEM	ACTION	REMARKS
11. Fan switch (11)	Connect proper wires to proper terminals on switch.	
12. Control console (12)	Position console on roof.	12
13. Eight capscrews that hold control console to roof	Install.	
14. Fan speed and heater temperature knobs	a. Install. Tighten setscrew.b. Test for proper operation.	
		TA 098775 End

FILTER FOR CAB HEATER REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Remove, cleaning and installation of the filter for the cab heater.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None Non-sudsing detergent None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

FILTER FOR CAB HEATER REMOVAL/INSTALLATION (CONT)

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Two thumb screws (1)	Loosen.	2
2. Cover (2)	Remove.	
3. Two foam rubber filters	Remove.	
4. Eight screws (3)	Remove.	3 - 1//-4
5. Filter flange (4)	Remove.	
CLEANING		
Foam rubber filters	a. Wash in non-sudsing detergent.	
	b. Rinse in clean water.	
	c. Squeeze dry.	
		TA 098776
	1	Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION 1. Filter flange (1) 2. Eight screws (2) 3. Two foam rubber filters (3) 4. Cover 5. Two thumb screws	ACTION Position on air duct. Install. Install. Install. Tighten.	REMARKS
		TA 098777 End

BODY, CAB, AND HOOD MAINTENANCE INSTRUCTIONS

This section covers removal and installation of these body components for Organizational Maintenance personnel:

a. Hoodb. Fenders

c. seat d. Arm cushion e. Cab door and striker f. Handrails

g. Ladders h. Shipping link i. Grease linesj. Pintle hook

k. Rear bumper

Also instructions for striker adjustment.

LIST OF TASKS (Sheet 1 of 1)

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
	Harland Mark Date	0.454	N
I	Hood removal/installation.	2-454	None
2	Fenders removal/installation.	2-457	None
3	Seat removal/installation.	2-460	None
4	Seat belts removal/installation.	2-462	None
5	Arm cushion removal/installation.	2-464	None
6	Windshield wipers removal/installation.	2-466	None
7	Cab door and striker removal/installation.	2-468	None
8	Shipping link removal/installation.	2-471	None
9	Striker adjustment.	2-473	None
10	Platform handrails removal/installation.	2-475	None
11	Ladders removal/installation.	2-477	None
12	Grease lines removal/installation.	2-479	None
13	Pintle hook removal/installation.	2-481	None
14	Crankcase guard removal/installation.	2-483	None

HOOD REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Replacement of hood.

INITIAL SETUP

Test Equipment Materials/Parts <u>Troubleshooting</u> Reference

None None None

Equipment Condition

Engine OFF

Shipping link installed.

Special Tools Personnel Reauired

Hoist - 150 lbs. minimum capacity One mechanic

References General Safety Instructions

Shipping link removal/installation, Main disconnect switch OFF. page 2-471.

LOCATION/ITEM	ACTION	REMARKS
1. Four capscrews and washers that hold rear hood (1) in position	Remove.	3 2
2. Rear hood (1)	Fasten hoist and remove. NOTE Weight of hood is 96 lbs. (44 kg).	
3. Precleaned lid (2)	Remove.	
4. Rubber latch assemblies	Disconnect five from frame assembly.	
5. Front hood (3)	Fasten hoist and remove, guiding carefully over precleaner.	
	NOTE	
	Weight of hood is 124 lbs. (56 kg).	
		TA 098778
		Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION		
1. Front hood (3)	Fasten hoist and put in position.	
2. Rubber latch assemblies	Fasten to frame assembly.	
3. Precleaner lid (2)	Place in position and tighten clamp.	
4. Nuts for precleaner lid	Fasten.	
5. Hose clamp	Tighten.	
6. Rear hood (1)	Fasten hoist and put in position.	
7. Four capscrews that hold rear hood in position	Install. The two longer capscrews are installed toward the cab.	
		TA 098887
		End

FENDERS REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Removing and installing front and rear fenders.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None None

Equipment Condition

Engine OFF

Special Tools Personnel Required

Hoist One mechanic

References General Safety Instructions

Torque limits chart, page E-1 Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
1. Fender, front	Attach hoist.	
 Nuts, capscrews and washers Fender 	Remove six. a. Lift and pull away from the vehicle.	
	b. Lower to ground.	
INSTALLATION 1. Fender, front	a. Hoist into position.	
	b. Install six nuts, capscrews and washers.	
2. Nuts, capscrews and washers	Tighten.	
3. Fender, front	Remove hoist.	
		TA 098779 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Fenders, rear handrail	a. Remove six capscrews and spacers on each side.	
	b. Remove lug.	
	c. Lift fender and handrail off vehicle to ground.	
INSTALLATION		
1. Fenders, rear handrail	a. Lift fender and handrail into place.	
	b. Install lug, six capscrews, and washers.	
	c. Install grab iron.	
		End
	I	Ellu

SEAT REMOVAL/INSTALLATION (Sheet 1 of 2)

This task covers: Removal and installation of operator's seat.

INITIAL SETUP

<u>Test Equipment</u> <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None None None

Equipment Condition

Engine OFF

Special Tools Personnel Required

Hoist One mechanic

<u>References</u> General Safety Instructions

Torque limits chart, page E-1 Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Hex head capscrews (1)	Remove eight capscrews from seat platform.	
2. Seat, plate attached (2)	a. Place on its side.	
	b. Remove from cab to vehicle platform outside.	1
	c. Lower seat to the ground using hoist.	
3. Plate (2)	Remove four hex head capscrews and lockwashers.	
INSTALLATION		
1. Plate (3)	Install plate to bottom of seat with four capscrews and lockwashers.	
2. Seat, plate attached	a. Raise up to outside vehicle platform.	\\/
	b. Place seat on its side. Move into cab and arrange seat upright.	
	c. Aline eight holes.	2 12
	d. Install eight hex head capscrews (1).	TA 098780 End

SEAT BELTS REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Seat belts removal/installation

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None As required None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		
1. Nut attaching eyebolts (3) to seat brace	Remove.	
2. Eyebolts (3)	Remove.	
3. Cotter pin (2)	Remove.	SEAT
4. Seat belt (1)	Remove from eyebolt (3) and discard.	
INSTALLATION		
1. Seat belt (1)	Attach to eyebolt (3).	
2. Cotter pin (2)	Install.	
3. Eyebolt (3)	Install in seat brace using nut.	
		TA172224
		End

ARM CUSHION REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal and installation of arm cushion.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

(Sheet 2 of 2)

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Arm cushion INSTALLATION 1. Arm cushion	a. Remove capscrew (1). b. Remove cushion (2) by sliding forward to clear rod (3). Then remove cushion from cab. a. Slide cushion (2) into place and rod (3) into proper position. b. Install capscrew (1).	REMARKS
		TA 09878' End

WINDSHIELD WIPERS REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Windshield wipers removal /installation

INITIAL SETUP

Test Equipment Troubleshooting Reference

None As required None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Mounting hardware 2. Wiper blade (1) INSTALLATION 1. Wiper blade (1)	Detach from arm (2) and wiper blade (1). Remove. Position on arm (2) and secure with mounting hardware.	MOUNTING HARDWARE
		TA172225 End

CAB DOOR AND STRIKER REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Removing and installing cab door and striker.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None As required None

Equipment Condition

Engine OFF

Special Tools Personnel Required

Hoist – 150 lb. minimum lifting capacity One mechanic

References General Safety Instructions

Striker adjustment, page 2-473. Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		// ///
1. Left handrail	Remove four hex head capscrews and washers, and remove rail from platform.	
2. Door	a. Remove nut from center hinge.	
	b. Open door, so it will clear Roll-Over Protective Structure (ROPS).	
	c. Hoist door from hinges, and place it on ground.	
3. Striker	a. Remove three screws and lockwashers (1).	/ //
	b. Remove cover (2).	
	c. Remove hex head capscrews and lockwashers (6).	5
	d. Remove plate (4) and shims.	
	e. Remove nut (5) and striker assembly (3).	4—/
		TA 098782
	l l	Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION 1. Door	a. Hoist door up to hinges, and lower into hinges.b. Remove hoist, and install the nut on the center hinge.	3
2. Handrail	Install handrail with four hex head capscrews and washers.	
3. Striker	a. Install striker assembly (1) into plate (2), and install nut (3).b. Install shims (4) and plate (2) with two capscrews.	2
4. Cover	After adjustments, install cover with three capscrews and lockwashers.	For adjustments, see page 2-473.
		TA 098783 End

SHIPPING LINK REMOVAL/INSTALLATION

 $(\widehat{S}heet \ \widehat{1} \ of \ \widehat{2})$

This task covers: The removal and installation of the shipping link.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Shipping link installation and storage, page 2-27

Main disconnect switch OFF.

Go on to Sheet 2

LOCATION/ITEM	ACTION	REMARKS
		!
1. Cotter pin (1)	Remove.	
2. Retaining pin (2)	Remove.	
3. Shipping link (3)	Place in storage position.	
4. Retaining pin (2) and cotter pin (3)	Install.	
INSTALLATION		
1. Cotter pin (1) and retaining pin (2)	Remove.	
2. Shipping link (3)	Remove from storage position and fasten to retaining plates.	
3. Retaining pin (2)	Place in position.	
4. Cotter pin (1)	Install.	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$
		TA 098787

STRIKER ADJUSTMENT (Sheet 1 of 2)

This task covers: Adjusting the striker after installation.

INITIAL SETUP

<u>Test Equipment</u> Materials/Parts Troubleshooting Reference

None Shims None

Equipment Condition

Main disconnect switch OFF.

Engine OFF

Special Tools Personnel Required

None One mechanic

<u>References</u> General Safety Instructions

Cab door and striker removal/installation,

page 2-468.

CEDITION	A D. II IOMB (D) IM	(00)
STRIKER	ADJUSTMENT	(CONT)

(Sheet 2 of 2)

LOCATION/ITEM	ACTION	REMARKS
Striker and plate (2)	 a. For forward or backward adjustments, install or remove shims (1). b. For right or left adjustments, or if door is too loose or too tight, move striker plate. c. If door doesn't close or is hard to close, loosen the striker and move up or down (3). 	Adjustment is done when door is next to striker so that the point where latch and striker meet can be seen.

PLATFORM HANDRAILS REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal and installation of platform handrails.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Capscrews (3) and washers (2) 2. Handrails (4), (5), (6), (7) INSTALLATION 1. Handrails 2. Capscrews (3) and washers (2)	Remove. Remove with support block (1). Place in position with support block (1). Install.	
		та 098785 End

LADDERS REMOVAL/INSTALLATION (Sheet 1 of 2)

This task covers: Removal/installation of ladders.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None None None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Capscrews (4), (6) and washers (3), (7)	Remove.	
2. Ladders (1) and (5)	Remove from brace (2).	
INSTALLATION		
1. Ladders (1) and (5)	Place in position on brace (2).	
2. Capscrews (4), (6) and washers (3), (7)	Install.	2 3 4 5
		TA 098786 End

GREASE LINES REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal and installation of grease lines.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None Grease line assembly None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

LO 10-3930-641-12 Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
		6
1. Fittings (1)	Disconnect.	_1
2. Capscrew and washer (2)	Remove.	4
3. Clip (3)	Remove.	
4. Line (4)	Remove.	2
5. Grease fitting (5)	Remove.	\ __\
6. Connectors (6)	Remove.	
	NOTE	3
INSTALLATION	If a new line is to be used, attach grease fitting and fill line with appropriate grease (see LO 10-3930-641-12) BEFORE installation.	
1. Connector (6)	Install.	4
2. Line (4) and fitting (1)	Install on connector (6).	
3. Clip (3) and capscrew and washer (2)	Install on line (4).	6
4. Grease fitting (5)	Install on line with fitting (1).	5
	NOTE	8
	Perform Step 4 if you did not use a new line.	TA 098788 End

PINTLE HOOK REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal/installation of pintle hook.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

LOCATION/ITEM	ACTION	REMARKS
 Capscrews (1), washers and nuts (2) holding pintle hook (3) to bumper Large retaining nut (4) behind bumper Pintle hook (3) 	Remove. Remove from shaft. Remove.	RETAINING COTTER PIN
1. Pintle hook (3)	Place in position.	2
2. Large retaining nut (4) behind bumper	Install on shaft.	BUMPER REINFORCING / PLATES 1
3. Capscrews (1), washers and nuts (2)	Install.	
		TA 098886
		End

CRANKCASE GUARD REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Replacement of crankcase guards.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None None

Equipment Condition

Engine off.

Wheels blocked.

Special Tools Personnel Required

None Two mechanics

References General Safety Instructions

None Place jack under guard before loosening

capscrews.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL FRONT CRANKCASE GUARD	WARNING	
	Place jack under guard before loosening capscrews. Front guard weighs 70 pounds.	
 Capscrews that hold front crank- case guard (1). 	Loosen, and install jack.	1
2. Capscrews	Remove.	
3. Front crankcase guard (1)	Lower, using the jack.	
INSTALLATION		
1. Front crankcase guard (1)	Place in position, using jack.	
2. Capscrews	Install.	
3. Jack	Remove. Tighten capscrews.	
		TA 098884
		Go on to Sheet 3

2-484

LOCATION/ITEM	ACTION	REMARKS
REMOVAL REAR CRANKCASE GUARD	Place jack under guard before loosening capscrews. Rear guard weighs 130 pounds.	
1. Four capscrews that hold rear crank-case guards (2)	Remove.	
2. Rear crankcase guard	Remove the two rear crankcase guards.	
INSTALLATION	NOTE Weight of each guard is 70 lb. (32 kg).	
1. Rear crankcase guard (2)	Position under machine.	2
2. Capscrews	Install.	
		TA 098885
		End

HYDRAULIC LIFT COMPONENTS MAINTENANCE INSTRUCTIONS

This section covers removal and installation of these hydraulic components for Organizational Maintenance personnel:

- a. Control linkage
- b. Mast lines guard

Also instructions for servicing hydraulic filter, servicing brake hydraulic system, lift cylinder test and bleeding, tilt cylinder test, and control linkage adjustment.

LIST OF TASKS (Sheet 1 of 1)

TASK NO.	TASK	REF (PAGE)	TROUBLESHOOTING REF (PAGE)
1	Hydraulic filter - service.	2-487	2-43
2	Brake hydraulic system filter - service.	2-490	None
3	Tilt cylinder test.	2-493	2-43
4	Lift cylinder test and bleeding.	2-495	2-43
5	Controls and linkage adjustment.	2-497	2-43
6	Mast lines guard removal/installation.	2-500	None
7	Hydraulic hand control removal/installation.	2-502	None
8	Tophandler guide plate mounting bolts replacement.	2-505	None
9	Tophandler limit switch adjustment.	2-507	None
			End

HYDRAULIC FILTER – SERVICE (Sheet 1 of 3)

This task covers: Servicing hydraulic filter.

INITIAL SETUP

Test Equipment	Materials/Parts	Troubleshooting Reference
None	Filter element for implement filter (two) Solvent cleaning compound (Item 2, Appendix C) Hydraulic fluid (Item 9, Appendix C) Cover gasket	Page 2-43 Equipment Condition Fork assembly lowered Engine OFF
Special Tools None	Personnel Required One mechanic References PMCS, page 2-5	General Safety Instructions Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
1. Floor plate (1) (Right side of vehicle)	Unlock and raise.	
2. Filler cap (2)	Remove slowly to relieve pressure.	2
3. Four capscrews	Remove from implement filter cover.	
Implement filter cover (3)	Remove.	
4. Cover gasket	Inspect. Replace if damaged.	
5. Two filter elements (4)	Remove and discard.	
		3
		TA 098794 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
6. Filter screen (5)	Remove and clean in nonflammable solvent.	
7. Cover (3)	Clean in nonflammable solvent.	
8. Screen (5)	Install.	5——————————————————————————————————————
9. Two filter elements (4)	Replace.	4 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -
10. Cover and capscrews (3)	Replace.	4
11. Engine	Start. Run at low idle. Inspect for leaks.	
12. Oil level indicator (6)	Check.	FILTER ASSEMBLY
13. oil	Add if necessary.	
14. Engine	Stop.	HYBRAPIK DIL LEVEL CHI'S DIL LEVEL
15. Floor plate (1)	Close and lock.	
		TA 098795
		Oil level should be above ADD COLD mark.
		End

BRAKE HYDRAULIC SYSTEM FILTER - SERVICE

(Sheet 1 of 3)

This task covers: Servicing brake hydraulic system filter.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None Filter elements for brake hydraulic system None

Solvent cleaning compound (Item 2, Appendix C)

Pan to catch oil Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

PMCS, page 2-5 Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
1. Access doors	Open.	
2. Filter (1)	Place pan under drain plug to prevent draining oil on machine.	
3. Housing drain plug (2) Oil	Remove. Drain.	
		TA 09879 Go on to Sheet

LOCATION/ITEM	ACTION	REMARKS
4. Filter housing (3)	Remove.	
Filter element (4)	Remove and discard.	
5. Filter housing base	Clean in nonflammable solvent.	
6. Filter housing (3)	Clean in nonflammable solvent.	4——
7. Filter	Install new element (4).	
8. Housing (3)	Install.	3
Drain plug (2)	Clean and install.	
9. Housing	To tighten housing, use nut on bottom of filter housing.	
10. Access doors	Close.	
11. Hydraulic tank	Add oil to fill.	See LO 10-3930-641-12.
		TA 098797
		End

TILT CYLINDER TEST (Sheet 1 of 2)

This task covers: Drift test of tilt cylinders.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

Tape measure None Page 2-43

Watch Equipment Condition

Intermittent operation

Special Tools Personnel Required

None Two mechanics

<u>References</u> General Safety Instructions

PMCS, page 2-5 Shipping link installed.

Lift cylinder test, page 2-495 Parking brake ON.

Shipping link installation/storage, page 2-471

TILT CYLINDER TEST (CONT)

(Sheet 2 of 2)

LOCATION/ITEM	ACTION	REMARKS
1. Vehicle	Lift rated capacity load off ground.	Hydraulic oil must be at normal operating temperature (110°-120°F). Mast will be vertical.
2. Tilt cylinder	Take measurement of tilt cylinder rods from nut to cylinder housing.	MEASURE THIS DISTANCE
3. Mast	Operate to complete forward and complete reverse position several times.	
4. Mast	Put mast back to vertical position.	
5. Engine	Turn off engine. Wait 20 minutes and take another measurement of tilt cylinder rods.	
6. Tilt cylinder	If measurement changed from measurement taken in Step 2, then tilt system has drifted.	Mast must not drift more than one-half inch in 20 minutes.
		TA 098798 End

LIFT CYLINDER TEST AND AIR BLEEDING

(Sheet 1 of 2)

This task covers: Drift test of lift cylinder and bleeding of air from lift cylinder.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

Tape measure None Page 2-43

Watch Equipment Condition

Engine running, machine operable

Special Tools Personnel Required

None Two mechanics

References General Safety Instructions

Shipping link installed.

Tilt cylinder test, page 2-493

LOCATION/ITEM	ACTION	REMARKS
1. Vehicle	Put rated capacity load on forks.	
2. Hydraulic controls	Operate vehicle through normal lift and tilt cycle.	Hydraulic oil must be at normal operating temperature, (110 °-1200 F).
3. Forks	With load on forks, lift carriage so lift cylinder has hydraulic load.	Mast at 0° tilt.
4. Carriage	Measure height of carriage from ground.	Carriage must not drift more than one inch in 20 minutes.
BLEEDING AIR FROM LIFT CYLINDER		BLEED
1. Bleed screw	Loosen but do not remove.	SCREW
2. Carriage	WARNING System is under high pressure. Removing bleed screw completely will cause mast and carriage to drop suddenly. Lift approximately 2 ft. (608 mm).	
3. Air in lift cylinder	Allow to bleed through bleed screw until oil	
	comes out with no air.	
4. Bleed screw	Tighten.	
5. Mast	Lower completely.	THE TOTAL STATE OF THE STATE OF
6. Hydraulic tank	Check level and fill if necessary. (See LO 10-3930-641 -12.)	TA 172226 End

2-496

CONTROLS AND LINKAGE ADJUSTMENT

(Sheet 1 of 3)

This task covers: Adjustment of hydraulic control linkages.

INITIAL SETUP

Test Equipment Materials/Parts Troubleshooting Reference

None None Page 2-43

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Shipping link installation/storage, page 2-471 Parking brake ON.

Shipping link installed.

LOCATION/ITEM	ACTION	REMARKS
1. Cotter pin (1) and washer (2)	Remove.	
2. Pin (3)	Remove.	
3. Nut (4)	Loosen.	Slide up on cable.
4. Yoke (5)	Remove.	
5. Spool	Center. (Allow spool to slide to NEUTRAL position.)	Pull spool to end of travel and release. Push spool to end of travel and release.
6. Yoke (5)	Adjust yoke (5) until retaining pin (3) can be installed in holes without removing spool.	
7. Nut (5)	Install on threads and turn until it is flush with face of yoke.	
		Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
8. Washer (2) and cotter pin (1)	Install.	
9. Nut (5)	Tighten against bracket.	
		TA 098799 End

MAST LINES GUARD REMOVAL/INSTALLATION

(Sheet 1 of 2)

This task covers: Removal and installation of the mast lines guard.

INITIAL SETUP

<u>Test Equipment</u> <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None None None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

LOCATION/ITEM	ACTION	REMARKS
REMOVAL	NOTE	
	Use an appropriate platform to work on the mast lines guard. DO NOT climb the mast.	2 / 3
1. Capscrews (1), nuts (2) and washers (3)	Remove.	
2. Mast lines guards (4)	Remove.	
INSTALLATION		
1. Mast lines guards (4)	Place in position.	
2. Capscrews (1), nuts (2) and washers (3)	Install.	
		TA 098800 End

HYDRAULIC HAND CONTROL REMOVAL/INSTALLATION

(Sheet 1 of 3)

This task covers: Replacement of hydraulic hand controls.

INITIAL SETUP

Test Equipment Troubleshooting Reference

None As required None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

Mast lowered and tilted full forward.

Controls and linkage adjustment, page 2-497 Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL		e e
1. Capscrews, washers, three panels	Remove.	
2. Cotter pin (1) and washer (2)	Remove from clevis pin (3).	
3. Handle (4)	Remove by sliding off shaft (5).	
4. Cable assembly	Loosen at bracket assembly (7).	5——————————————————————————————————————
5. Retainer (8 & 9) and seal	Remove and save.	
6. Rod end (10)	Remove pin (11) and disconnect at valve assembly.	
7. Rod end (10)	Loosen nut (12) and unscrew rod end (10) from cable assembly.	12 10
8. Handle (4) and cable assembly	Adjust. (See page 2-497.)	6-
		TA 098792
		Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
INSTALLATION 1. Handle (4) and cable assembly 2. Rod end (10) 3. Rod end (10) 4. Retainer (8 and 9) and seal 5. Bracket assembly (7) 6. Handle (4) 7. Cotter pin (1) and washer (2) 8. Hydraulic hand control	Install. Screw onto cable assembly. Tighten, using nut (12). Install on valve assembly using pin (11). Slide onto shaft (5). Install on clevis pin (3). Adjust. (See page 2-497.)	REMARKS 12 10
		TA 098793 End

TOPHANDLER GUIDE PLATE MOUNTING BOLTS REPLACEMENT

(Sheet 1 of 2)

This task covers: Removal/installation of the tophandler guide plate mounting bolts.

INITIAL SETUP

Test Equipment <u>Materials/Parts</u> <u>Troubleshooting Reference</u>

None As required None

Equipment Condition

Engine OFF

Special Tools Personnel Required

None One mechanic

References General Safety Instructions

None Main disconnect switch OFF.

LOCATION/ITEM	ACTION	REMARKS
REMOVAL 1. Capscrews (3) and washers (2) 2. Guide plate (1) INSTALLATION 1. Guide plate (1) 2. Capscrew (3) and washer (2)	Remove. NOTE Excess pressure against the guide plate will break the head off the capscrew. It may be necessary for you to use a vise grips or similar tool to remove the rest of the capscrew. Remove. Position on tophandler. Install.	REMARKS 1 2 3
		TA 172227 End

2-506

TOPHANDLER LIMIT SWITCH ADJUSTMENT

(Sheet 1 of 3)

This task covers: Tophandler limit switch adjustment.

INITIAL SETUP

Troubleshooting Reference Materials/Parts Test Equipment

None None None

Equipment Condition

Engine running at low idle Transmission in NEUTRAL Emergency brake ON

Personnel Required Special Tools

One operator One mechanic None

References

Container lock indicator panel, TM 10-3930-641-10.

Mast controls, TM 10-3930-641-10.

General Safety Instructions

The man resetting the limit switches must be very careful while on the tophandler.

LOCATION/ITEM	ACTION	REMARKS
1. Mechanic	WARNING It is critical that the operator and mechanic understand what each is to do during this procedure. All actions, steps and hand signals must be worked out and understood beforehand. Safely position self on container handler.	LIMIT SWITCH
2. Mechanic	Signal operator to push full forward on container lock control handle.	
3. Operator	Push container lock control handle full forward. Place hands on steering wheel.	LIMIT SWITCH
4. Mechanic	Loosen jam nut (1) on capscrew (2) and back out capscrew.	LIMIT SWITCH TA 172228 Go on to Sheet 3

LOCATION/ITEM	ACTION	REMARKS
5. Operator	Signal mechanic when green indicator light on container lock control panel goes out.	2 1
6. Mechanic	Signal operator to pull full back on container lock control handle.	
7. Operator	Pull full back on container lock control handle. Place hands on steering wheel.	
8. Mechanic	Turn capscrew (2) in.	
9. Operator	Signal mechanic when red indicator light on container lock control panel comes on and stays on.	LIMIT SWITCH
10. Mechanic	Set jam nut (1) firmly in place.	
11. Procedure	Repeat for other limit switch.	
		TA 172229
		End


RADIO INTERFERENCE SUPPRESSION

(Sheet 1 of 3)


Essentially, suppression is attained by providing a low resistance path to ground for stray currents. The methods used include shielding the ignition and high frequency wires, grounding the vehicle with bonding straps, and using capacitors and resistors.

The primary components are:

Wire Shields. Some of the high voltage or frequency wires have the possibility of electrical leakage through the insulating cover. The "wire shield" is a protective covering over the wire to aid in the reduction or elimination of such leakages. These leakages, if not restrained from the radio, would cause undesirable interference.



Bonding Straps. Generally, the frame of a vehicle is used as the second wire (ground) of an electrical circuit. This ground is used for all the systems of the vehicle. The "bonding straps" ensure there is a definite ground between the major assemblies or components. This definite ground eliminates the possibilities of an erratic ground which would cause undesirable radio interference.




Bonding strap from the engine to the frame is one of a few major straps.

TA 098574

Go on to Sheet 3

 $\frac{Capacitors.}{keeps\ it\ from\ entering\ into\ the\ radio\ circuit.}$ A capacitor is an electrical absorption chamber. When installed in the proper locations, it actually absorbs stray electrical current and keeps it from entering into the radio circuit.



A capacitor that is hooked into the positive lead to a wiper motor would absorb any undesirable static from the rotating motor.

SHIPMENT

This vehicle can be shipped by sea transportation, rail, or truck and is designed for minimum disassembly before shipment. Refer to the Military Traffic Management Command's Transportability Review, TR 80-1-19A.

WARNING

Be certain ether starting aid cannister is removed from vehicle before shipment or storage. Page 2-189

Seaboard transportation
Remove exhaust pipe and seal opening Page 2-211
Shipping link installed
Rail transportation
Remove mast Notify direct support maintenance
If necessary, remove ROPS Notify direct support maintenance
Remove exhaust pipe and seal opening Page 2-211
Shipping link installed
Truck transportation
Remove mast Notify direct support maintenance
Remove ROPS Notify direct support maintenance
Remove cab Notify direct support maintenance
Remove exhaust pipe and seal opening Page 2-211
Shipping link installed

PACKING

- 1. Protect the following items by wrapping or taping:
 - Hydraulic fluid level gage
 - Steering wheel and column
 - · Instrument panels and container lock panel
 - Ž Windshield, windows and mirrors
 - Windshield wipers
 - · Headlights, taillights and auxiliary lights.
- 2. Protect steering cylinders, rotation and sideshift cylinders by applying a layer of protective coating.
- 3. Install steering lock.
- 4. Drain cooling system (page 2-216) and fill with a fresh, clean solution of 50 percent water and 50 percent antifreeze conforming to MIL-A-46153. Tag the steering wheel to indicate the temperature to which the cooling system can be subjected before damage.
- 5. Be sure the crankcase is filled with oil.

MARKING

Mark shipping containers and unboxed components in accordance with MIL-STD-129.

ARMY SHIPPING DOCUMENTS

Prepare all Army shipping documents in accordance with AR 725-50.

LOADING (RAIL TRANSPORT)

Load, brace and block the equipment in accordance with requirements of the Association of American Railroads and the following:

- 1. Inspect all flatcars before loading to see that they are in a suitable condition to safely carry the load to its destination.
- 2. Prepare flatcars for loading by removing all debris, previous blocking, nails and other obstructions. Inspect flatcars for loose or broken floor planks. Do not use damaged cars.
- 3. Refer to Association of American Railroads "Rules Governing the Loading of Commodities on Open-Top Cars."
- 4. Position the vehicle as far away from the brake wheel end of the flatcar as space permits. Allow minimum clearance of 4 inches below, 6 inches above, behind and to each side of the flatcar brake wheel.

APPENDIX A

REFERENCES

A-1. PUBLICATION INDEXES AND GENERAL REFERENCES

Indexes should be consulted frequently for latest changes or revisions of references given in this appendix and for new publications relating to material covered in this publication.

a.	Military Publication Indexes	
	Consolidated Index of Army Publication and Forms	
	Index of Graphic Training Aids and Devices	
_		
b.	General References	
	EV. 4 At 1 C. C. 11t	

A-2. FORMS

Refer to DA PAM 738-750, The Army Maintenance Management System (TAMMS), for instructions on the use of maintenance forms pertaining to the material.

A-3. OTHER PUBLICATIONS

The following publications contain information pertinent to the major item material and associated equipment,

a.	Vehicle
	Lubrication Order, Truck, Container Handler: Rough Terrain, 50,000 lb. Capacity LO 10-3930-641-12
	Operator's Manual, Truck, Container Handler: Rough Terrain, 50,000 lb. Capacity
	organizational Maintenance Repair Parts and Special Tools List for Truck, Container Handler:
	Rough Terrain, 50,000lb. Capacity
,	
b.	Camouflage

Camouflage
Color, Marking and Camouflage Painting of Military Vehicles, Construction Equipment and
Materials Handling EquipmentTB 43-0209

APPENDIX A

REFERENCES (CONT)

A-3. OTHER PUBLICATIONS (CONT)

c.	Decontamination
	Chemical, Biological, and Radiological (CBR) Decontamination
d.	General
	Basic Cold Weather Manual
	Manual for Wheeled Vehicle Driver
	Northern Operations
	Operation and Maintenance of Ordnance Material in Cold Weather (0° to-65°F)
	Procedures for Destruction of Equipment to Prevent Enemy Use
	Military Traffic Management Command's Transportability Review
е.	Maintenance and Repair
	Organizational Care, Maintenance and Repair of Pneumatic Tires and Inner Tubes
	Operator's, Organizational, Direct Support and General Support Maintenance Manual for Lead-Acid Storage Batteries TM 9-6140-200-14
	Description, Use, Bonding Techniques, and Properties of Adhesives
	Inspection, Care, Maintenance of Antifriction Bearings
	Use of Antifreeze Solutions and Cleaning Compounds in Engine Cooling Systems
	Materials Used for Cleaning, Preserving, Abrading, and Cementing Ordnance Material and Related Materials
	Including Chemicals
	Welding Theory and Application
	Non-Aeronautical Equipment Army Oil Analysis Program (AOAP)
f.	Administrative Storage
	Administrative Storage of Equipment

Section I. Maintenance Allocation Chart (MAC) Introduction

THE ARMY MAINTENANCE SYSTEM MAC

- 1. This introduction provides a general explanation of all maintenance and repair functions authorized at the two maintenance levels under the Two-Level Maintenance System concept.
- 2. The MAC immediately following this introduction designates overall authority and responsibility for the performance of maintenance functions on the identified end item or component. The application of the maintenance functions to the end item or component shall be consistent with the capacities and capabilities of the designated maintenance levels, which are shown in the MAC (Appendix B) in column (4) as:

Field - includes subcolumns:

- C Operator/Crew
- O Organizational
- F Direct Support

Sustainmant - includes subcolumns:

- H General Support
- D Depot
- 3. The tools and test equipment requirements (immediately following the MAC) list the tools and test equipment (both special tools and common tool sets) required for each maintenance function as referenced from the MAC.
- 4. The remarks (immediately following the tools and test equipment requirements) contain supplemental instructions and explanatory notes for a particular maintenance function.

MAINTENANCE FUNCTIONS

Maintenance functions are limited to and defined as follows:

- 1. **Inspect.** To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination (e.g., by sight, sound, or feel).
- 2. <u>Test.</u> To verify serviceability by measuring the mechanical, pneumatic, hydraulic, or electrical characteristics of an item and comparing those characteristics with prescribed standards on a scheduled basis, i.e., load testing of lift devices and hydrostatic testing of pressure hoses.
- 3. <u>Service</u>. Operations required periodically to keep an item in proper operating condition; e.g., to clean (includes decontaminate, when required), preserve, drain, paint, or replenish fuel, lubricants, chemical fluids, or gases.
- 4. Adjust. To maintain or regulate, within prescribed limits, by bringing into proper position, or by setting the operating characteristics to specified parameters.
- 5. <u>Align</u>. To adjust specified variable elements of an item to bring about optimum or desired performance.
- 6. <u>Calibrate.</u> To determine and cause corrections to be made or to be adjusted on instruments of test, measuring, and diagnostic equipment used in precision measurement. Calibration consists of comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.

MAINTENANCE FUNCTIONS - CONTINUED

- 7. **Remove/Install.** To remove and install the same item when required to perform service or other maintenance functions. Installation may be the act of emplacing or seating a spare, repair part, or module (component or assembly) into position in a manner to allow the proper functioning of an equipment or system.
- 8. **Replace.** To remove an unserviceable item and install a serviceable counterpart in its place. Replacement is authorized by the MAC and the assigned maintenance level is shown as the third position code of the Source, Maintenance, and Recoverability (SMR) code.
- 9. **Repair.** Repair is the application of maintenance services, including fault location/troubleshooting, removal/installation, disassembly/assembly procedures, and maintenance actions to identify troubles and restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.

NOTE

The following definitions are applicable to the "repair" maintenance function:

- Services Inspecting, testing, service, adjustment, alignment, calibration, and/or replacement.
- Fault location/troubleshooting The process of investigating and detecting the cause of equipment malfunctioning; the act of isolating a fault within a system or Unit Under Test (UUT).
- Disassembly/assembly The step-by-step breakdown (taking apart) of a spare/functional group coded item to the level of its least component, assigned an SMR code for the level of maintenance under consideration (i.e., identified as maintenance significant).
- Actions Welding, grinding, riveting, straightening, facing, machining, and/or resurfacing.
- 10. <u>Overhaul</u>. That maintenance effort (service/action) prescribed to restore an item to a completely serviceable/operational condition as required by maintenance standards in appropriate technical publications. Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like new condition.
- 11. **Rebuild.** Consists of those services/actions necessary for the restoration of unserviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of materiel maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (hours/miles, etc.) considered in classifying Army equipment/components.

EXPLANATION OF COLUMNS IN THE MAC, SECTION 1

- 1. <u>Column (1) Group Number</u>. Column (1) lists Group numbers, the purpose of which is to identify maintenance significant components, assemblies, subassemblies, and modules with the Next Higher Assembly (NHA).
- 2. <u>Column (2) Component/Assembly.</u> Column (2) contains the item names of components, assemblies, subassemblies, and modules for which maintenance is authorized.
- 3. <u>Column (3) Maintenance Function</u>. Column (3) lists the functions to be performed on the item listed in Column (2). (For a detailed explanation of these functions, refer to "Maintenance Functions" outlined above.)

B-2

EXPLANATION OF COLUMNS IN THE MAC, TABLE 1 - CONTINUED

4. Column (4) - Maintenance Level. Column (4) specifies each level of maintenance authorized to perform each function listed in column (3), by indicating work time required (expressed as manhours in whole hours or decimals) in the appropriate subcolumn. This work time figure represents the active time required to perform that maintenance function at the indicated level of maintenance. If the number or complexity of the tasks within the listed maintenance function varies at different maintenance levels, appropriate work time figures are to be shown for each level. The work time figure represents the average time required to restore an item (assembly, subassembly, component, module, end item, or system) to a serviceable condition under typical field operating conditions. This time includes preparation time (including any necessary disassembly/assembly time), troubleshooting/fault location time, and quality assurance time in addition to the time required to perform the specific tasks identified for the maintenance functions authorized in the MAC. The symbol designations for the various maintenance levels are as follows:

Field:

- C Operator/Crew Maintenance
- O Organizational
- F Direct Support Maintenance

Sustainment:

- H General Support Maintenance
- D Depot Maintenance

NOTE

The "L" maintenance level is not included in column (4) of the MAC. Functions at this level of maintenance are identified by a work time figure in the "H" column of column (4), and an associated reference code is used in the REMARKS CODE column (6). This code is keyed to the remarks, and the SRA complete repair application is explained there.

- 5. <u>Column (5) Tools and Equipment Reference Code</u>. Column (5) specifies, by code, common tool sets (not individual tools), common Test, Measurement, and Diagnostic Equipment (TMDE), special tools, special TMDE, and special support equipment required to perform the designated function. Codes are keyed to the entries in the tools and test equipment table.
- 6. Column (6) Remarks Code. When applicable, this column contains a letter code, in alphabetical order, which is keyed to the remarks table entries (Table 3).

EXPLANATION OF COLUMNS IN THE TOOLS AND TEST EQUIPMENT REQUIREMENTS, SECTION 3

- 1. <u>Column (1) Tool or Test Equipment Reference Code</u>. The tool and test equipment reference code correlates with a code used in column (5) of the MAC.
- 2. <u>Column (2) Maintenance Level</u>. The lowest level of maintenance authorized to use the tool or test equipment.
- 3. <u>Column (3) Nomenclature.</u> Name or identification of the tool or test equipment.
- 4. <u>Column (4) National Stock Number (NSN)</u>. The NSN of the tool or test equipment.
- 5. <u>Column (5) Tool Number (ICAGEC)</u>. The manufacturer's part number, model number, or type number. The manufacturer's Commercial and Government Entity Code (CAGEC) is also included.

EXPLANATION OF COLUMNS IN THE REMARKS, SECTION 4

- 1. **Column (1) Remarks Code.** The code recorded in column (6) of the MAC.
- 2. <u>Column (2) Remarks.</u> This column lists information pertinent to the maintenance function being performed as indicated in the MAC.

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER

(1)	(2)	(3)	(4) MAINTENANCE LEVEL			(5)	(6)														
			FIELD		FIELD S		AINMENT														
GROUP	COMPONENT/	MAINTENANCE	UNIT		UNIT		UNIT		UNIT		UNIT		UNIT		UNIT		DS	GS	DEPOT	TOOLS AND	REMARKS
NUMBER	COMPONENT/ ASSEMBLY	FUNCTION	C	0	F	Н	D	EQUIPMENT REF CODE	CODE												
01	ENGINE																				
0100	Engine, Assembly, Diesel	Inspect Test	0.1		1.0			3	E												
		Service		1.0				1,2	В												
		Adjust			1.0			3	F												
		Replace			32.0			3													
		Repair				125.0		4	A,D												
	Trunnions	Inspect		0.05				1,2													
		Replace			0.5			3													
		Repair			0.5			3													
	Supports	Inspect		0.05																	
		Replace			0.5			3													
0101	Block, Short	Replace				60.0		4													
		Repair				8.0		4													
	Cylinder Head Assembly	Replace Repair			8.0 8.0			3 3													
0102	Damper	Replace		4.0				1,2													
	Crankshaft	Inspect				1.0		4													
		Replace				26.0		4,13													
	Bearings, Main	Replace				8.0		4													

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)]	MAIN	(4) TENAN) ICE LE	VEL	(5)	(6)
				FIELD S		SUST	AINMENT		
GROUP	COMPONENT	MAINTENANCE	UN	IT	DS	GS	DEPOT	TOOLS AND	REMARKS
NUMBER	COMPONENT/ ASSEMBLY	FUNCTION	C	0	F	Н	D	EQUIPMENT REF CODE	CODE
01	ENGINE (CONT)								
	Seals, Oil	Replace				1.0		4,13,14	
0103	Flywheel Assembly	Replace			16.0			3	
		Repair				2.5		4	
	Flywheel Housing	Replace			11.0			3	
		Repair			2.0			3	
0104	Piston	Replace				24.0		4	
		Repair				3.0		4	
	Connecting Rod	Replace				24.0		4	
		Repair				3.0		4	
	Bearings, Connecting Rod	Replace				2.0		4	
0105	Rocker Arm Assembly	Adjust			1.5			3,7,8	
		Replace			8.0			3,7	
	Rotocoil Assembly	Replace			0.5			3	
		Repair			0.2			4	
	Valves	Replace			14.0			3	
	Camshaft	Replace				16.5		4,8	
	Timing Gears	Replace			5.5			3	
	Covers, Valve	Replace		0.5				1,2	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)]	(4 MAINTENAI			VEL	(5)	(6)
				FIELD		SUSTA	AINMENT		
CDOUD	COMPONENT	MA INTERNANCE	UN	IT	DS	GS	DEPOT	TOOLS AND	DEMARKS
GROUP NUMBER	COMPONENT/ ASSEMBLY	MAINTENANCE FUNCTION	C	0	F	Н	D	EQUIPMENT REF CODE	REMARKS CODE
01	ENGINE (CONT)								
0106	Oil Pan	Replace			5.0			3	
		Repair			1.0			3	
	Engine Oil Pump	Replace			8.0			3	
		Repair			2.0			3	
	Oil Filter	Service		0.3				1,2	В
		Replace		1.0				1,2	
	Oil Filer Bypass Valves	Replace			1.0			3	
	Oil Cooler	Replace			4.0			3	
		Repair			1.0			3	
	Breather	Inspect		0.1				1,2	
		Service		0.1				1,2	
		Replace		0.6				1,2	
	Oil Filler Assembly	Replace		2.0				1,2	
	Oil Lines and Fittings	Inspect		0.1					
		Replace		2.0				1,2	
0108	Manifold, Exhaust	Replace			3.0			3	
0109	Accessory Drive Gears and Housing	Replace Repair			10.5 8.0			3 3	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)]	MAINT	(4) TENAN) ICE LE	(5)	(6)	
				FIELD		SUST	AINMENT		
GROUP	COMPONENT/	MAINTENANCE	UN	UNIT		GS	DEPOT	TOOLS AND EQUIPMENT	REMARKS
NUMBER	ASSEMBLY	FUNCTION	C	0	F	Н	D	REF CODE	CODE
01	ENGINE (CONT)								
	Tachometer Drive	Replace		0.7				1,2	
	Adapters, Gears and Rear Accessory Drive	Replace Repair			8.5 6.0			3 3	
03	FUEL SYSTEM								
0301	Fuel Injection Nozzles	Test			1.0			3,11	
		Replace			2.5			3,6	
		Repair				1.0		4	
0302	Fuel Injection Pump	Inspect			0.2				
		Test			2.0			3	G
		Replace			4.0			3	
		Repair				10.0		4,5,7,9,10	
		Adjust				2.0		4,8,12	Н
	Fuel Pump Lines	Inspect	0.1						
		Replace		1.0				1,2	
	Transfer Pump	Replace		1.0				1,2	
		Repair			2.5			3	
	Priming Pump	Replace		0.5				1,2	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(2)	(3)]	MAINT	(4) ΓENAN) ICE LE	(5)	(6)	
			FIELD		SUST	AINMENT		
COMPONENT/	MAINTENIANCE	UN	IIT	DS	GS	DEPOT	TOOLS AND	REMARKS
ASSEMBLY	FUNCTION	C	0	F	Н	D	REF CODE	CODE
FUEL SYSTEM (CONT)								
Air Cleaner	Service		0.1				1	
	Replace		0.5				1,2	
Dust Ejector	Service		0.5				1,2	
Turbocharger	Replace			6.0			3	
	Repair				2.0		4	
Turbocharger Air Lines	Replace			1.0			3	
Turbocharger Oil Lines	Replace			1.0			3	
Fuel Tank	Inspect	0.2						
	Service		0.5				1,2	
	Replace			2.0			3	
	Repair			2.0			3	
Fuel Lines and Fittings	Inspect	0.2						
	Replace		2.0				1,2,15	
Governor	Adjust			1.0			3,8	
	Replace			2.0			3	
	Repair				3.0		4	
	COMPONENT/ ASSEMBLY FUEL SYSTEM (CONT) Air Cleaner Dust Ejector Turbocharger Turbocharger Air Lines Turbocharger Oil Lines Fuel Tank Fuel Lines and Fittings	COMPONENT/ ASSEMBLY FUEL SYSTEM (CONT) Air Cleaner Service Replace Replace Turbocharger Turbocharger Air Lines Turbocharger Oil Lines Fuel Tank Inspect Service Replace Replace	COMPONENT/ ASSEMBLY FUEL SYSTEM (CONT) Air Cleaner Service Replace Dust Ejector Turbocharger Turbocharger Air Lines Turbocharger Oil Lines Fuel Tank Inspect Replace Replace Replace Replace Replace Replace Turbocharger Oil Lines Fuel Tank Inspect Replace Replace	COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION C O FUEL SYSTEM (CONT) Air Cleaner Service Replace Replace Replace Repair Turbocharger Air Lines Turbocharger Oil Lines Fuel Tank Service Replace Replace Replace Replace Replace Replace Turbocharger Oil Lines Fuel Tank Inspect Service Replace Replace	COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION COMPONENT/ FUNCTION COMPONENT/ BAINTENANCE LONIT LONIT BAINTENANCE LONIT LON	COMPONENT/ ASSEMBLY	COMPONENT/ ASSEMBLY	COMPONENT/ ASSEMBLY

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)]	MAINT	(4) TENAN) ICE LE	(5)	(6)	
				FIELD)	SUST	AINMENT		
GROUP	COMPONENT	MAINTENIANCE	UN	UNIT DS		GS	DEPOT	TOOLS AND	DEMADIZO
NUMBER	COMPONENT/ ASSEMBLY	MAINTENANCE FUNCTION	C	0	F	Н	D	EQUIPMENT REF CODE	REMARKS CODE
03	FUEL SYSTEM (CONT)								
	Fuel Ratio Control	Adjust			0.2			3	
		Replace			0.8			3	
		Repair			1.4			3	
	Controls	Inspect	0.2					1,2	
		Adjust			1.0			3	
		Replace			1.5			3	
0309	Fuel Filters, Primary	Service		0.5				1,2	В
		Replace		0.5				1,2	
	Fuel Filter, Secondary	Service		0.5				1,2	В
		Replace		1.0				1,2	
0311	Ether Starting Aid	Service		0.2				1,2	
		Replace		2.0				1,2	
04	EXHAUST SYSTEM								
0401	Muffler and Pipes	Inspect	0.2						
		Replace		1.0				1,2	
	Fumes Disposal Assembly	Replace		1.0				1,2	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)]	MAINT	(4) ΓENAN) NCE LE	VEL	(5)	(6)
				FIELD)	SUST	AINMENT		
GROUP	COMPONENT/	MAINTENANCE	UN	IIT	DS	GS	DEPOT	TOOLS AND EQUIPMENT	REMARKS
NUMBER	ASSEMBLY	FUNCTION	C	0	F	Н	D	REF CODE	CODE
05	COOLING SYSTEM								
0501	Radiator Assembly	Inspect	0.1						
		Service		0.5				1,2	
		Replace			6.0			3	
		Repair			4.0			3	
0502	Shrouds	Replace			2.0			3	
		Repair			2.0			3	
0503	Water Temperature Regulators	Test Replace		1.0 2.0				1,2 1,2	
	Water Temperature Switch	Test Replace		1.0 2.0				1,2 1,2	
	Hose, Lines and Fittings	Inspect Replace	0.5	1.0				1,2	
0504	Water Pump Assembly	Inspect	0.1						
		Replace		3.5				1,2	
		Repair			2.0			3	
0505	Fan Assembly	Replace		2.0				1,2	
	Fan Guards	Replace		0.5				1,2	
	Belt, Drive	Inspect	0.1						
		Replace		1.0				1,2	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

	(3)	(4) MAINTENANCE LEVEL					(5)	(6)
			FIELD		SUST	AINMENT		
COMPONENT/	MAINTENANCE	UN	IIT	DS	GS	DEPOT	TOOLS AND EQUIPMENT	REMARKS
ASSEMBLY	FUNCTION	C	O	F	Н	D	REF CODE	CODE
COOLING SYSTEM (CONT)								
Fan Drive Mechanism	Replace		0.7				1,2	
	Repair			1.5			3	
Crankshaft Pulley	Replace		0.5				3	
Belt Tightener	Replace		1.0				1,2	
Auxiliary Cooler, Hydraulic Oil	Replace Repair			2.0	2.0		3 3	
Oil Lines, Hydraulic Oil Cooler	Inspect Replace		0.1	2.0			3	
Coolant Filter (Conditioner)	Replace		0.5				1,2	
ELECTRICAL SYSTEM								
Alternator	Test		0.5				1,2	I
	Replace		1.5				1,2	
	Repair				1.0		4	
	Overhaul				2.5		4	
Starting Motor	Test		0.5				1,2	I
	Replace		2.5				1,2	
	Repair				5.0		4	
	COOLING SYSTEM CONT) Fan Drive Mechanism Crankshaft Pulley Belt Tightener Auxiliary Cooler, Hydraulic Dil Lines, Hydraulic Oil Cooler Coolant Filter (Conditioner) ELECTRICAL SYSTEM Alternator	ASSEMBLY COOLING SYSTEM CONT) Fan Drive Mechanism Replace Repair Crankshaft Pulley Replace Replace Auxiliary Cooler, Hydraulic Dil Lines, Hydraulic Oil Cooler Coolant Filter (Conditioner) ELECTRICAL SYSTEM Alternator Test Replace Repair Overhaul Starting Motor Test Replace Replace Repair Overhaul	COMPONENT/ ASSEMBLY COOLING SYSTEM CONT) Fan Drive Mechanism Replace Repair Replace Replace Auxiliary Cooler, Hydraulic Dil Lines, Hydraulic Oil Cooler Coolant Filter (Conditioner) ELECTRICAL SYSTEM Alternator Starting Motor MAINTENANCE FUNCTION Replace Repair Replace	COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION COOLING SYSTEM CONT) Fan Drive Mechanism Replace Repair Crankshaft Pulley Replace Replace Auxiliary Cooler, Hydraulic Dil Lines, Hydraulic Oil Cooler Coolant Filter (Conditioner) ELECTRICAL SYSTEM Alternator Test Replace Repair Overhaul Starting Motor MAINTENANCE FUNCTION C O O O O O O O O O O O O O	COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION COOLING SYSTEM CONT) Fan Drive Mechanism Replace Repair Replace	COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION C O F H COOLING SYSTEM CONT) Fan Drive Mechanism Replace Repair Replace	MAINTENANCE FUNCTION C O F H D	COMPONENT/ ASSEMBLY

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)]	MAINT	(4) TENAN) NCE LE	(5)	(6)	
				FIELD		SUST	AINMENT		
GROUP	COMPONENT/	MAINTENANCE	UN	IIT	DS	GS	DEPOT	TOOLS AND	REMARKS
NUMBER	ASSEMBLY	FUNCTION	C	0	F	Н	D	EQUIPMENT REF CODE	CODE
06	ELECTRICAL SYSTEM (CONT)								
	Solenoid, Starting Motor	Test Replace		0.5 1.5				1,2 1,2	I
0606	Warning Controls, Engine	Inspect Test	0.1	0.5				1,2	I
		Replace		0.5				1,2	
	Solenoid, Fuel Shutoff	Test Adjust		0.2	0.2			1,2 3	I
		Replace			1.0			3	
	Engine Wiring	Test		1.5				1,2	
		Replace			3.0			3	
		Repair		2.0				1,2	
0607	Instrument Panel	Inspect	0.5						
		Replace		1.0				1,2	
		Repair		1.0				1,2	
	Service Meter	Replace		0.5				1,2	
	Container Lock Indicator	Inspect Test	0.1	0.2				1,2	I
		Replace		1.5				1,2	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)		MAIN	(4) TENAN) ICE LE	VEL	(5)	(6)
				FIELD)	SUST	AINMENT		
GROUP	COMPONENT/	MAINTENANCE	UN	IT	DS	GS	DEPOT	TOOLS AND EQUIPMENT	REMARKS
NUMBER	ASSEMBLY	FUNCTION	C	0	F	Н	D	REF CODE	CODE
06	ELECTRICAL SYSTEM (CONT)								
	Console Wiring	Replace		1.5				1,2	
		Repair		1.0				1,2	
	Start Switch	Replace		0.5				1,2	
0609	Headlights	Test		0.2				1,2	I
		Replace		0.5				1,2	
	Backup Light	Test		0.2				1,2	I
		Replace		0.5				1,2	
	Taillights	Test		0.2				1,2	I
		Replace		0.5				1,2	
	Stoplights	Test		0.2				1,2	I
		Replace		0.5				1,2	
	ROPS Lights	Test		0.2				1,2	I
		Replace		1.0				1,2	
	Cap Lights	Test		0.2				1,2	I
		Replace		0.5				1,2	
	Lamps, Sealed	Replace		0.5				1,2	I

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)]	MAINT	(4) FENAN) ICE LE	(5)	(6)	
				FIELD)	SUST	AINMENT		
GROUP	COMPONENT/	MAINTENANCE	UN	IIT	DS	GS	DEPOT	TOOLS AND EQUIPMENT	REMARKS
NUMBER	ASSEMBLY	FUNCTION	C	0	F	Н	D	REF CODE	CODE
06	ELECTRICAL SYSTEM (CONT)								
0610	Sending Unit, Oil Pressure	Test Replace		0.5 0.5				1,2 1,2	I
	Sending Unit, Engine Temperature	Test Replace		0.5 0.5				1,2 1,2	I
	Stoplight Switch	Test		0.2				1,2	I
		Replace		0.5				1,2	
0611	Horn	Test		0.2				1,2	I
		Replace		0.5				1,2	
	Horn Switch	Test		0.2				1,2	I
		Replace		0.5				1,2	
	Alarm, Backup Warning	Test Replace		0.2 0.5				1,2 1,2	I
0612	Batteries, Storage	Inspect	0.2						
		Test		0.5				1,2	I
		Service		0.5				1,2	C
		Replace		0.5				1,2	
	Battery Box	Replace		0.5				1,2	
		Repair			0.5			3	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)]	MAIN	(4) TENAN) ICE LE	VEL	(5)	(6)
				FIELD		SUST	AINMENT		
GROUP	COMPONENT/	MAINTENANCE	UN	IIT	DS	GS	DEPOT	TOOLS AND EQUIPMENT	REMARKS
NUMBER	ASSEMBLY	FUNCTION	С	0	F	Н	D	REF CODE	CODE
06	ELECTRICAL SYSTEM (CONT)								
	Battery Cables	Replace		0.3				1,2	
		Repair		0.3				1,2	
0613	Wiring Harnesses	Replace			2.5			3	
		Repair		1.0				1,2	
	Terminals and Connectors	Replace		1.0				1,2	
0615	Radio Interference Suppression	Replace		0.5				1,2	
07	TRANSMISSION								
0708	Torque Converter	Test			0.3			3	J
		Replace				6.0		4	
		Repair				12.0		4	
	Torque Converter Cooler Lines	Inspect Replace	0.1		1.5			3	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)		MAIN	(4) FENAN) ICE LE	VEL	(5)	(6)
				FIELD)	SUST	AINMENT		
GROUP	COMPONENT/	MAINTENANCE	UN	IIT	DS	GS	DEPOT	TOOLS AND EQUIPMENT	REMARKS
NUMBER	ASSEMBLY	FUNCTION	C	0	F	Н	D	REF CODE	CODE
07	TRANSMISSION (CONT)								
0710	Transmission Assembly	Service Replace		0.5	20.0			1,2 3	В
		Repair				8.0		4	
		Test			0.5			3	J
	Transmission Controls	Inspect Replace		0.2	1.5			1,2 3	
		Adjust		0.5				1,2	
	Planetary Assembly	Replace				10.0		4	
		Repair				15.0		4	
	Carrier Assembly	Replace				12.0		4	
		Repair				15.0		4	
	Input Transfer Gear Assembly	Replace Repair				2.0 10.0		4 4	
	Output Transfer Gear Assembly	Replace Repair				2.0 10.0		4 4	
0721	Pump, Transmission Oil	Replace Repair			4.0	4.0		3 4	
	Control Valve	Test			0.2			3	
		Replace				1.0		4	
		Repair				2.0		4	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)]	MAINT	(4) TENAN) ICE LE	(5)	(6)	
			FIELD)	SUSTAINMENT			
GROUP	COMPONENT/	MAINTENANCE			NIT DS		DEPOT	TOOLS AND	REMARKS
NUMBER	COMPONENT/ ASSEMBLY	FUNCTION FUNCTION	C	0	F	Н	D	EQUIPMENT REF CODE	CODE
07	TRANSMISSION (CONT)								
	Oil Filter	Service		0.3				1,2	
		Replace		0.5				1,2	
	Linkage	Service		1.0				1,2	
		Replace		1.5				1,2	
	Oil Cooler	Replace			2.4			3	
		Repair				1.0		3	
	Oil Filler Assembly	Replace		1.0				1,2	
	Oil Lines, Transmission	Inspect Replace		0.5	3.0			3	
09	PROPELLER SHAFTS								
0900	Drive Shafts	Replace		4.0				1,2	
		Repair			2.0			3	
	Universal Joint/Spider and Bearing Assembly	Replace			2.0			3	В
10	FRONT AXLE								
1000	Front Axle Assembly	Replace			5.0			3	
		Repair				4.0		4	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)	(4) MAINTENANCE LEVEL					(5)	(6)
			FIELD		SUSTAINMENT				
GROUP	COMPONENT/				DS	GS	GS DEPOT	TOOLS AND	REMARKS
NUMBER	COMPONENT/ ASSEMBLY	MAINTENANCE FUNCTION	C	0	F	Н	D	EQUIPMENT REF CODE	CODE
10	FRONT AXLE (CONT)								
1002	Differential Assembly, Front	Inspect Service		1.0 0.5				1,2	В
		Replace				8.0		4	
		Repair				4.0		4	
11	REAR AXLE								
1100	Rear Axle Assembly	Replace			5.0			3	
		Repair				4.0		4	
	Trunnion Support Assemblies	Replace Repair			5.0	3.5		3 4	
1102	Differential Assembly, Rear	Inspect Service		1.0 0.5				1,2	В
		Replace				8.0		4	
		Repair				4.0		4	
12	BRAKES								
1201	Hand Brake Assembly	Inspect		0.1				1,2	
		Replace			3.0			3	
		Repair			2.0			3	
	Brake Lines	Inspect		0.2					
		Replace			3.0			3	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)	(4) MAINTENANCE LEVEL					(5)	(6)
			FIELD			SUSTAINMENT			
CDOUD	COMPONENT	MAINTENIANCE	UNIT		T DS		DEPOT	TOOLS AND	DEM A DIZO
GROUP NUMBER	COMPONENT/ ASSEMBLY	MAINTENANCE FUNCTION	C	0	F	Н	D	EQUIPMENT REF CODE	REMARKS CODE
12	BRAKES (CONT)								
	Brake Control	Replace		2.0				1,2	
		Repair		1.0				1,2	
1202	Service Brake Assembly	Replace Repair			3.0	2.0		3 4	K
	Service Brake Linkage	Adjust		1.5				1,2	
1204	Brake Control	Replace			2.0			3	
		Repair			2.0			3	
	Accumulator	Replace			2.0			3	
		Service			1.0			3	
	Lines, Fittings, and Hoses	Inspect Replace		0.1	1.0			3	
	Hydraulic Valves	Replace			2.0			3	
		Repair			2.0			4	
1206	Mechanical Brake Pedal and Linkage	Replace Repair			1.5 2.0			3 3	
13	WHEELS								
1311	Wheel Assembly	Replace		0.8				1,2	K
	Rims	Replace			0.8			3,16,17	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)	(4) MAINTENANCE LEVEL			VEL	(5)	(6)	
				FIELD)	SUST	AINMENT		
CDOUD	COMPONENT		UNIT DS		DS	GS	DEPOT	TOOLS AND	DEM A DIZE
GROUP NUMBER	COMPONENT/ ASSEMBLY	MAINTENANCE FUNCTION	C	0	F	Н	D	EQUIPMENT REF CODE	REMARKS CODE
13	WHEELS (CONT)								
1313	Tires	Inspect	0.1						
		Service		0.5				1,2	
		Replace			2.0			3,16,17	
		Repair			1.0			3	
14	STEERING								
1401	Steering Wheel	Replace		1.0				1,2	
	Steering System	Test		0.5				1,2	L
		Service		0.5				1,2	В
		Adjust			1.0			3	
		Replace			3.0			3	
		Repair			2.0			3	
	Adjustable Steering Column	Replace Repair			3.0 2.0			3	
	Steering Valve Assembly	Replace Repair			3.0	2.0		3 4	
1402	Articulated Hitch Assembly	Service Repair		0.2	8.0			1,2	В

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)	(4) MAINTENANCE LEVEL					(5)	(6)
				FIELD)	SUST	AINMENT		
CDOUD	COMPONENT/	MAINTENANCE	UN	UNIT		GS	DEPOT	TOOLS AND	DEM A DIZE
GROUP NUMBER	COMPONENT/ ASSEMBLY	MAINTENANCE FUNCTION	C	0	F	Н	D	EQUIPMENT REF CODE	REMARKS CODE
14	STEERING (CONT)								
1410	Steering Pump	Test			1.0			3	L
		Inspect		1.0				3	
		Replace			5.0			3	
		Repair				3.0		4	
	Steering Pump, Supplemental	Test Inspect		1.0	1.0			3	L
		Replace			5.0			3	
		Repair				3.0		4	
1411	Hoses, Lines and Fittings	Inspect Replace		0.1	3.0			3	
	Steering Filter	Service		0.3				1,2	В
		Replace		0.5				1,2	
1412	Hydraulic Cylinders	Inspect	0.1						
		Replace			8.0			3	
		Repair				2.0		4	
1414	Steering System Diverter Valves	Inspect Replace		0.2	1.0			3	
		Repair				1.0		4	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)]	MAIN	(4) TENAN) ICE LE	VEL	(5)	(6)
				FIELD)	SUST	AINMENT		
CDOUD	COMPONENT	MAINTENIANCE	UN	UNIT		GS	DEPOT	TOOLS AND	DEMARKS
GROUP NUMBER	COMPONENT/ ASSEMBLY	MAINTENANCE FUNCTION	С	0	F	Н	D	EQUIPMENT REF CODE	REMARKS CODE
14	STEERING (CONT)								
	Steering Limit Valve	Inspect		0.2					
		Adjust			0.5			3	
		Replace			1.0			3	
		Repair				1.0		4	
15	FRAME AND TOWING ATTACHMENTS								
1501	Frame Assembly, Engine End	Inspect Repair		0.5		2.0		4	
	Frame Assembly, Non-Engine End	Inspect Repair		0.5		2.0		4	
	Bumper, Rear	Replace				2.0		4	
		Repair				2.0		4	
	Platform	Replace			2.0			3	
		Repair			2.0			3	
	Platform Guard	Replace		0.5				1,2	
		Repair			1.0			3	
	Ladder	Replace		0.5				1,2	
		Repair		1.0				1,2	
	Shipping Link	Replace		0.2					

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)]	MAIN	(4) FENAN) ICE LE	VEL	(5)	(6)
				FIELD)	SUST	AINMENT		
GROUP	COMPONENT/	MAINTENANCE.	UN	IT	DS	GS	DEPOT	TOOLS AND	REMARKS
NUMBER	COMPONENT/ ASSEMBLY	FUNCTION	C	0	F	Н	D	EQUIPMENT REF CODE	CODE
15	FRAME AND TOWING ATTACHMENTS (CONT)								
	Platform, Right Hand	Replace			2.0			3	
		Repair			2.0			3	
	Pintle Hook Assembly	Replace		0.5				1,2	
1502	Counterweight	Replace			1.0			3	
18	BODY, CAB, HOOD, AND HULL								
1801	Body	Repair			5.0			3	
	Cab	Repair			1.0			3	
		Replace			25.0			3	
	ROPS	Replace			1.0			3	
1802	Fender, Front	Replace		3.0				1,2	
		Repair			2.0			3	
	Fender, Rear	Inspect		0.2					
		Replace		1.5				1,2	
		Repair			2.0			3	
	Windshield	Replace			3.0			3	
	Glass	Replace			2.0			3	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)	(4) MAINTENANCE LEVEL				VEL	(5)	(6)
				FIELD)	SUST	AINMENT		
GROUP	COMPONENT/	MAINTENANCE	UN	UNIT DS		GS	DEPOT	TOOLS AND EQUIPMENT	REMARKS
NUMBER	ASSEMBLY	FUNCTION	C	О	F	Н	D	REF CODE	CODE
18	BODY, CAB, HOOD, AND HULL (CONT)								
1806	Seat	Replace		1.0				1,2	
		Repair			1.5			3	
	Arm Cushion	Replace		0.5				1,2	
	Seat Belts	Replace		0.5				1,2	
22	BODY, CHASSIS, AND ACCESSORY ITEMS								
2202	Mirrors	Inspect	0.1						
		Replace		0.2				1,2	
	Wipers	Inspect	0.1						
		Replace		1.0				1,2	
	Windshield Wiper Motor	Replace		2.0				1,2	
	Cab Heater and Defroster	Test Replace	0.2	2.0				1,2	
	Air Filter, Cab Heater	Service		0.2				1,2	
		Replace		1.2				1,2	
	Heater Lines	Replace		1.0				1,2	
		Repair		0.5				1,2	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(2)	(3)	(4) MAINTENANCE LEVEL					(5)	(6)
			FIELD)	SUST	AINMENT		
COMPONENT/	MAINTENANCE.	UNIT		DS	GS DEPOT		TOOLS AND	REMARKS
ASSEMBLY	FUNCTION	C	О	F	Н	D	REF CODE	CODE
BODY, CHASSIS, AND ACCESSORY ITEMS (CONT)								
Control Console Assembly, Heater Grease Lines	Replace Service Replace		1.5 0.2 1.0				1,2 1,2 1,2	В
HYDRAULIC SYSTEMS								
Hydraulic System	Inspect	0.1						
	Service		0.5				1,2	В
	Repair				2.0		4	
Hydraulic Pump	Test			1.0			3	J
	Replace			6.0			3	
	Repair				3.0		4	
Control Valves	Replace			4.0			3	
	Repair				5.0		4	
Controls and Linkage	Adjust		1.0				1,2	
	Replace		2.0				1,2	
	COMPONENT/ ASSEMBLY BODY, CHASSIS, AND ACCESSORY ITEMS (CONT) Control Console Assembly, Heater Grease Lines HYDRAULIC SYSTEMS Hydraulic System Hydraulic Pump Control Valves	COMPONENT/ ASSEMBLY BODY, CHASSIS, AND ACCESSORY ITEMS (CONT) Control Console Assembly, Heater Grease Lines Hydraulic System Inspect Service Replace Repair Hydraulic Pump Test Replace Repair Control Valves Replace Repair Controls and Linkage Adjust	COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION C BODY, CHASSIS, AND ACCESSORY ITEMS (CONT) Control Console Assembly, Heater Grease Lines Replace Replace HYDRAULIC SYSTEMS Hydraulic System Inspect Service Repair Fest Replace Repair Control Valves Replace Repair Control Valves Adjust	COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION C O BODY, CHASSIS, AND ACCESSORY ITEMS (CONT) Control Console Assembly, Heater Grease Lines Replace Replace HYDRAULIC SYSTEMS Hydraulic System Inspect Service Repair FIELD UNIT C O O O O O O O O O O O O O	COMPONENT/ ASSEMBLY COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION C O F BODY, CHASSIS, AND ACCESSORY ITEMS (CONT) Control Console Assembly, Heater Grease Lines Replace Replace HYDRAULIC SYSTEMS Hydraulic System Inspect Service Repair Hydraulic Pump Test Replace Repair Control Valves Replace Repair Control Valves Adjust Adjust MAINTENAN UNIT DS UNIT DS 1.5 6.0 F 1.5 0.2 Replace 0.2 Replace 0.5 Replace 4.0	COMPONENT/ ASSEMBLY	COMPONENT/ ASSEMBLY	COMPONENT/ ASSEMBLY

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)]	MAINT	(4) TENAN) ICE LE	VEL	(5)	(6)
				FIELD)	SUST	AINMENT		
GROUP	COMPONENT	MA INTENIANCE	UN	UNIT		GS	DEPOT	TOOLS AND	DEM A DIZE
NUMBER	COMPONENT/ ASSEMBLY	MAINTENANCE FUNCTION	C	0	F	Н	D	EQUIPMENT REF CODE	REMARKS CODE
24	HYDRAULIC SYSTEMS (CONT)								
2404	Tilt Cylinder	Inspect	0.1						
		Test			0.2			3	J
		Replace			1.0			3	
		Repair				8.0		4	
	Side Tilt Cylinder	Inspect	0.1						
		Test			0.2			3	J
		Replace			1.0			3	
		Repair				8.0		4	
	Side Shift Cylinder	Inspect	0.1						
		Test			0.2			3	J
		Replace			1.0			3	
		Repair				8.0		4	
2405	Mast	Inspect		0.1					
		Replace			3.0			3	
		Repair				2.0		4	
	Carriage	Inspect		0.1					
		Replace			2.0			3	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)]	MAIN	(4) FENAN) ICE LE	VEL	(5)	(6)
				FIELD)	SUST	AINMENT		
GROUP	COMPONENT/	MAINTENANCE	UNIT		DS	GS	DEPOT	TOOLS AND	REMARKS
NUMBER	COMPONENT/ ASSEMBLY	FUNCTION	C	0	F	Н	D	EQUIPMENT REF CODE	CODE
24	HYDRAULIC SYSTEMS (CONT)								
	Forks	Inspect	0.1						
		Replace			0.5			3	
	Lift Cylinder	Replace			1.0			3	
		Repair				1.0		4	
2406	Hydraulic Lines and Fittings	Inspect Replace		0.1	1.0			3	
	Hydraulic Filter	Service		0.5				1,2	В
		Replace		1.0				1,2	
2407	Hydraulic Reservoir	Inspect	0.1						
		Service		0.5				1,2	В
		Replace			2.0			3	
		Repair				3.0		3	
33	SPECIAL PURPOSE KITS								
3307	Tophandler, 20 Ft	Inspect	0.1						
		Install	0.5						
		Repair			1.5			3	

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(1)	(2)	(3)		MAIN	(4) TENAN) ICE LE	VEL	(5)	(6)		
				FIELD)	SUST	AINMENT				
GROUP	COMPONENT/	MAINTENANCE	UN	UNIT		UNIT D		GS	DEPOT	TOOLS AND EQUIPMENT	REMARKS
NUMBER	ASSEMBLY	FUNCTION	C	0	F	Н	D	REF CODE	CODE		
33	SPECIAL PURPOSE KITS (CONT)										
	Tophandler, 35 Ft	Inspect	0.1								
		Install	0.5								
		Repair			1.5	2.0		3,4			
	Tophandler, 40 Ft	Inspect	0.1								
		Install	0.5								
		Repair			1.5	2.0		3,4			
	Force Limiter	Inspect	0.1								
		Adjust			0.5			3			
		Service		0.2				1,2	В		
		Replace			1.2			3			
		Repair			1.5			3			
	Twistlock	Inspect	0.1								
		Adjust			0.7			3			
		Service		0.4				1,2			
		Replace			1.0			3	В		
	Hydraulic Cylinder, Tophandler	Replace Repair			0.5	1.0		3 4	В		

Section II. MAINTENANCE ALLOCATION CHART (MAC) FOR TRUCK, CONTAINER HANDLER (CONT)

(2)	(3)	(4) MAINTENANCE LEVEL			(5)	(6)		
			FIELD		SUST	AINMENT		
COMPONENT/ ASSEMBLY	MAINTENANCE FUNCTION	UN C	О	DS F	GS H	DEPOT D	TOOLS AND EQUIPMENT REF CODE	REMARKS CODE
SPECIAL PURPOSE KITS (CONT)								
Tophandler Guide Plate Mounting Bolts	Replace		0.2				1,2	
	ASSEMBLY SPECIAL PURPOSE KITS (CONT) Tophandler Guide Plate	ASSEMBLY FUNCTION SPECIAL PURPOSE KITS (CONT) Tophandler Guide Plate Replace	COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION C SPECIAL PURPOSE KITS (CONT) Tophandler Guide Plate Replace	COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION C O SPECIAL PURPOSE KITS (CONT) Tophandler Guide Plate Replace UNIT C O	COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION C O F SPECIAL PURPOSE KITS (CONT) Tophandler Guide Plate Replace 0.2	COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION C O F H SPECIAL PURPOSE KITS (CONT) Tophandler Guide Plate Replace UNIT DS GS H	COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION C O F H D SPECIAL PURPOSE KITS (CONT) Tophandler Guide Plate Replace UNIT DS GS DEPOT H D	COMPONENT/ ASSEMBLY MAINTENANCE FUNCTION C O F H D TOOLS AND EQUIPMENT REF CODE SPECIAL PURPOSE KITS (CONT) Tophandler Guide Plate Replace 0.2 LINIT DS GS DEPOT TOOLS AND EQUIPMENT REF CODE 1,2

Section III. TOOLS AND TEST EQUIPMENT FOR TRUCK, CONTAINER HANDLER

(1)	(2)	(3)	(4)	(5)	(6)
ITEM NO.	MAINTENANCE LEVEL	ITEM NAME	NATIONAL STOCK NUMBER	TOOL NUMBER/	CAGEC
1	0	Shop Equipment, Automotive Maintenance and Repair: Common No. 1	4910-00-754-0654	W32593	19204
2	О	Shop Equipment, Automotive Maintenance and Repair: Supplemental No. 1	4910-00-754-0653	W32867	19204
3	F	Shop Equipment, Automotive Maintenance and Repair: Wheeled Vehicles, Set B	4910-00-348-7697	T09906	19204
4	Н	Shop Equipment, Automotive Maintenance and Repair: Wheeled Vehicles, Set A	4910-00-348-7696	T09905	19204
5	F	Wrench, Injector Pump Removal	5120-01-375-5889	8S4613	11083
6	F	Extractor, Injector	5120-00-178-1267	8S2244	11083
7	F	Tool Set, Valve Lifter	5120-01-276-0528	5P7433	11083
8	F	Tool, Engine Turning	3020-01-250-1610	9S9082	11083
9	Н	Fixture, Fuel Rack Bearing		5P6217	11083
10	Н	Driver, Fuel Rack Bearing		5P6218	11083
11	F	Extractor, Fuel Nozzle Adapter	4930-01-268-7417	5P6229	11083
12	F	Pin, Timing		5P9697	11083
13	Н	Distorter, Wear Sleeve	5120-01-119-1748	5P7312	11083
14	Н	Ring, Distorter	5120-01-288-2453	5P7314	11083
15	О	Socket, Fuel Line	5120-01-124-1773	5P144	11083
16	O,F	Remover, Tire, Bead Breaker, Hydraulic	4910-00-773-9341	814D1100	994
17	O,F	Constrictor, Bead Expander	4910-00-138-1819	TC28	31989

Section IV. REMARKS FOR TRUCK, CONTAINER HANDLER

(1)	(2)
REFERENCE CODE	REMARKS
A	Complete engine gasket kit is available.
В	See Preventive Maintenance Checks and Services (PMCS) for lubrication instructions.
С	Battery maintenance instructions are provided in TM 9-6140-200-14.
D	Repair time is given with engine removed from vehicle.
Е	Test includes inlet manifold pressure check, compression check, oil pressure check, and operational check.
F	Adjustment consists of valve adjustment.
G	Fuel injection pump test consists of timing check.
Н	Fuel injection pump adjustment consists of timing adjustment and fuel rack adjustment.
I	Operational test or electrical troubleshooting as required.
J	Test consists of pressure check and performance tests.
K	Front and rear wheels, brakes, and final drives are identical.
L	Steering test consists of hydraulic pressure check.

APPENDIX C EXPENDABLE SUPPLIES AND MATERIALS LIST Section I. INTRODUCTION

SCOPE

This appendix lists expendable supplies and materials you will need to operate and maintain the Rough Terrain Container Handler. These items are authorized to you by CTA 50-970, Expendable Items (Except Medical, Class V, Repair Parts, and Heraldic Items).

EXPLANATION OF COLUMNS

- 1. <u>Column (1) Item Number</u>. This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the material (e.g., "Use cleaning compound, item 2, App. C").
- 2. Column (2) Maintenance Level. This column identifies the lowest level of maintenance that requires the listed item.
 - C Operator/Crew
 - O Organizational Maintenance
- 3. <u>Column (3) National Stock Number.</u> This is the National Stock Number (NSN) assigned to the item; use it to request or requisition the item.
- 4. **Description.** Indicates the Federal item name and, if required, a description to identify the item. The last line for each item indicates the part number followed by the Federal Supply Code for Manufacturer (FSCM) in parentheses, if applicable.
- 5. <u>U/M (Unit of Measure)</u>. Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, gal, pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST

(1)	(2)	(3)	(4)	(5)
ITEM NO.	MAINTENANCE LEVEL	NATIONAL STOCK NUMBER	DESCRIPTION	U/M
1	С		Antifreeze: Permanent Ehtylene Glycol, Inhibited, Heavy-Duty	
		6850-01-441-3218	(58536) A-A-52624 1 Gallon Can	gal
		6850-00-181-7933	(81349 MILA46153 5 Gallon Container	gal
		6850-01-441-3223	(58536) A-A-52624 55 Gallon Drum	dr
2	О	6850-00-941-5054	Cleaning Compound, Solvent, 5 gal can O-C-1889 (8138)	gal
3	С	9150-00-935-1017	GAA Grease, Auto/Artillery, 14 oz cartridge M-10924-B (81349)	ea
4	С	9150-00-190-0904	GAA Grease, Auto/Artillery, 1-3/4 lb can M-10924-C (81349)	lb
5	О		GO Lubricating Oil, Grade 80/90 MIL-PRF-2105 (81349)	
		9150-01-035-5392	1 Quart Can	qt
		9150-00-001-9395	5 Gallon Can	gal
		9150-01-035-5394	55 Gallon Drum	gal
6	О		GO Lubricating Oil, Grade 75 MIL-PRF-2105	gal
		9150-01-035-5390	1 Quart Can	qt
		9150-01-035-5391	5 Gallon Can	gal

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST (CONT)


(1)	(2)	(3)	(4)	(5)
ITEM NO.	MAINTENANCE LEVEL	NATIONAL STOCK NUMBER	DESCRIPTION	U/M
7	С		Lubricating Oil, OE/HDO-30 MIL-PRF-2104 (81349)	
		9150-00-186-6681	1 Quart Can	qt
		9150-00-188-9858	5 Gallon Can	gal
7.1	С		Lubricating Oil, OEA, Arctic MIL-PRF-46167 (81349)	
		9150-00-402-4478	1 Quart Can	qt
		9150-00-402-2372	5 Gallon Can	gal
		9150-00-491-7197	55 Gallon Drum	dr
8	С		Lubricating Oil, OE/HDO-10 MIL-PRF-2104 (81349)	
		9150-00-189-6727	1 Quart Can	qt
		9150-00-186-6668	5 Gallon Can	gal
		9150-00-191-2772	55 Gallon Drum	dr
8.1	С	9150-00-247-0481	Lubricating Oil, OE/HDO-10/30 BRAYCO413J (2R128)	qt
8.2	С		Lubricating Oil, OE/HDO-15/40 MIL-PRF-2104 (81349)	
		9150-01-152-4117	1 Quart Can	qt
		9150-01-152-4118	5 Gallon Can	gal
		9150-01-152-4119	55 Gallon Drum	dr

Section II. EXPENDABLE SUPPLIES AND MATERIALS LIST (CONT)

(1)	(2)	(3)	(4)	(5)
ITEM NO.	MAINTENANCE LEVEL	NATIONAL STOCK NUMBER	DESCRIPTION	U/M
9	0	9150-00-935-9807	OH T, Hydraulic Fluid, Petroleum Base MIL-H-6083 (81349)	qt
10	О	8030-00-145-0151	Coating Compound, Plastisol, 1 qt can A-A-59464 (58536)	qt
11	О	8135-00-551-1245	Tape, Pressure Sensitive Adhesive, 60 yd roll, 4 in wide A-A-884 (58536)	yd
12	О	8010-00-297-0560	Enamel, Alkyd, Lusterless OD, 1 gal can MPI 8-FLAT (80244)	gal
13	О	8010-00-598-5936	Enamel, Semigloss OD, 16 oz can (aerosol) MIL-E-11195 (81349)	ea
14	С	9140-00-286-5294	Fuel Oil, Diesel: DF2 ASTM D 975 (81346)	gal
15	О	6810-00-356-4936	Distilled-Deionized 6Z9250 (80063)	gal
16	С	7920-00-205-1711	Rag, Wiping: Cotton, Class 2. Grade B, 50 lb bale 7920-00-205-1711 (80244)	lb
17	С		Cleaning Compound, Solvent, Type III MIL-PRF-680 (81349)	
		6850-01-474-2318	1 Gallon Can	gal
		6850-01-474-2320	5 Gallon Can	gal
		6850-01-474-2321	55 Gallon Drum	dr
18	С	7930-00-249-8036	Detergent, General Purpose: 5 lb box 7930-00-249-8036 (80244)	lb
19	О	6810-00-264-6618	Sodium Bicarbonate, Technical: 1 lb box AA374-2 (58536)	lb

APPENDIX D ILLUSTRATED LIST OF MANUFACTURED ITEMS


MANUFACTURED HOSES



- A. Stem Assy Assembly may have nuts on the ends or may be attached with flanges. Stem Assy 's will be listed as one per end.
- B. Sleeve Assy Sleeves will be listed as one per end.
- C. Hose Hoses listed are in bulk length.

Hose Assy No.	Bulk Hose No.	Hose Length	Sleeve No. (Qty)	Stem Assy No. (Qty)
8N1467	5P0182	100.4 in. (2.6m)	3S7116 (2)	1P1219 (1) 3S8573 (1)
8N1468	5P0182	108.3 in. (2.8m)	3S7116 (2)	1P1219 (1) 5S3826 (1)


88841-28 PUMP ASSEMBLY




- 1. 5P5992 Hose, Bulk 8 in. (20 cm) Qty 1
- 2. 87883-4 Strainer Qty 1

MANUFACTURED HARNESSES

Cut wire to length. Attach terminals and connectors as shown in diagram. Check for continuity (page 2-53) and shorts (page 2-54).




2V7616 HARNESS ASSEMBLY



- 1. MS25036-153 Terminal Qty 2
- 2. 19191 Connector Qty 1
- 3. 5P5623 Bulk Wire, 16 gage 2 pieces, 8 in. (20 cm)


TA172230

5R4490 WIRE ASSEMBLY




- 1. MS25036-153 Lug Terminal – Qty 3
- 2. 2863 Terminal, Quick Disconnect - Qty 1
- 3. 5P5623 Bulk Wire. 16 gage — 2 pieces, 40 in. (100 cm)

2V4305 WIRE ASSEMBLY



- 1. 2L8074 Lug Terminal Qty 1
- 2. 412026 Terminal, Female Qty 2
- 3. 5P5623 Bulk Wire, 16 gage 18 in. (45 cm)


2V4306 WIRE ASSEMBLY



- 1. 11722 Connector Qty 1
- 2. 0200R Resistor Qty 1
- 3. 412026 Terminal, Female Qty 1
- 4. 5P5623 Bulk Wire, 16 gage 44 in. (110 cm)

TA172231

2V3020 HARNESS ASSEMBLY



- 1. 11722 Plug, Tip Qty 3
- 2. 5P1475 Terminal, Lug Qty 2
- 3. 7K4475 Pin, Shoulder Qty 2
- 4. MS25036-110 Terminal, Lug Qty 1


5. 5P5623 Bulk Wire, 16 gage – Length as follows:

1A to 1B - 43 in. (110 cm)

3A to 3B - 43 in. (110 cm)

4A to 4B – 12 in. (30 cm)

6. 5P5624 Bulk Wire, 14 gage - from 2A to 2B - 47 in. (120 cm)




- 1. 5P1475 Terminal, Lug Qty 3
- 2. 5P1477 Terminal, Lug Qty 3
- 3. 17510 Jack, Tip Qty 1
- 4. 19188A Connector Qty 1

- 5. 5P5623 Bulk Wire, 16 gage Length as follows:
 - 1A to 1B 75 in. (190 cm) 2A to 2B - 75 in. (190 cm)
 - 3A to 3B 77 in. (195 cm)
 - 4A to 4B 79 in. (200 cm)
 - 1C to 2B 41 in. (104 cm)
 - 2C to 2B 41 in. (104 cm)
 - 3C to 3B 48 in. (122 cm)


TA172233

5R4686 WIRE ASSEMBLY




- 1. 5P5632 Bulk Wire, 10 gage 6 in. (15 cm)
- 2. 2L8071 Terminal Qty 1
- 3. 2L8064 Terminal Qty 1

5R4687 WIRE ASSEMBLY




- 1. 5P5632 Bulk Wire, 10 gage 6 in. (15 cm)
- 2. 2L8049 Terminal Qty 2

5R4689 WIRE ASSEMBLY




- 1. 5P5632 Bulk Wire, 10 gage 2 pieces 8 in. (20 cm) and 14 in. (35 cm)
- 2. 5R4677 Splice Qty 1
- 3. 2L8064 Terminal Qty 1
- 4. 6N9018 Connector Qty 1
- 5. 5P5618 Terminal Qty 1

5R4688 WIRE ASSEMBLY




- 1. 5R4677 Splice Qty 1
- 2. 5P5621 Bulk Wire, 12 gage 6 in. (15 cm)
- 3. 2L8064 Terminal Qty 1

5R4690 WIRE ASSEMBLY



- 1. 2L8069 Terminal Qty 1
- 2. 5P5632 Bulk Wire, 10 gage 12 in. (30 cm)
- 3. 2L8067 Terminal Qty 1

5R4691 WIRE ASSEMBLY




- 1. 2L8067 Terminal Qty 1
- 2. 5P5632 Bulk Wire, 10 gage 8 in. (20 cm)
- 3. 228066 Terminal Qty 1

APPENDIX E TORQUE LIMITS

GENERAL TORQUE FOR CAPSCREWS AND NUTS

THREAD	DIAMETER	STANDARD TORQUE		
inches	millimeters	lb. ft.	N∙m	
Standa	rd thread		bolts and nuts with stansions are approximate).	
1/4 5/16 3/8 7/16 1/2 9/16 5/8 3/4 7/8 1 1 1/8 1 1/4 1 3/8 1 1/2	6.35 7.94 9.53 11.11 12.70 14.29 15.88 19.05 22.23 25.40 28.58 31.75 34.93 38.10	$\begin{array}{c} 9 \pm 3 \\ 18 \pm 5 \\ 32 \pm 5 \\ 50 \pm 10 \\ 75 \pm 10 \\ 110 \pm 15 \\ 15 \pm 20 \\ 265 \pm 35 \\ 420 \pm 60 \\ 640 \pm 80 \\ 800 \pm 100 \\ 1000 \pm 120 \\ 1200 \pm 150 \\ 1500 \pm 200 \\ \end{array}$	12 ± 4 25 ± 7 45 ± 7 70 ± 15 100 ± 15 150 ± 20 200 ± 25 360 ± 50 570 ± 80 875 ± 100 1100 ± 150 1350 ± 175 1600 ± 200 2000 ± 275	
		Use these torques hydraulic valve bodie	for bolts and nuts on s.	
5/16 3/8 7/16 1/2 5/8	7.94 9.53 11.11 12.70 15.88	13 ± 2 24 ± 2 39 ± 2 60 ± 3 118 ± 4	$\begin{array}{c} 20 \pm 3 \\ 35 \pm 3 \\ 50 \pm 3 \\ 80 \pm 4 \\ 160 \pm 6 \end{array}$	

GENERAL TORQUE FOR TAPERLOCK STUDS



t-a			
1/4	6.35	5 ± 2	7 ± 3
5/16	7.94	10 ± 3	15 ± 5
3/8	9.53	20 ± 3	30 ± 5
7/16	11.11	30 ± 5	40 ± 10
1/2	12.70	40 ± 5	55 ± 10
9/16	14.29	60 ± 10	80 ± 15
5/8	15.88	75 ± 10	100 ± 15
3/4	19.05	110 ± 15	150 ± 20
7/8	22.23	170 ± 20	230 ± 30
1	25.40	260 ± 30	350 ± 40
1 1/8	28.58	320 ± 30	400 ± 40
1 1/4	31.75	400 ± 40	550 ± 50
1 3/8	34.93	480 ± 40	650 ± 50
1 1/2	38.10	550 ± 50	750 ± 70
I .		1	

INDEX

Page	Page
A	
Abbreviations	Brake Control Valve
Access Panels, Engine 1-4, 1-5	Brake Hydraulic System and Implement Filters
Accumulator	Brake Hydraulic System Filter Service2-490
Air Cleaner	Brake Pedal Linkage
Air Cleaner and Dust Ejector Service2-198	Brake System
Air Cleaner Element, Primary	Brake System Maintenance
Air Cleaner Element, Secondary	Brake, Parking 1-22, 1-23
Air Cleaner Housing and Elbow	Brakes, Service 1-22, 2-17
Air Filter, Cab Heater	Breather, Crankcase
Air Inlet and Exhaust System	Breather, Torque Converter
Air Intake System Maintenance	Breather, Transmission
Alternator 1-17, 1-19, 2-71, 2-85, 2-252, 2-255	Bypass Valve, Oil Cooler
Arm Cushion	Bypass Valve, Oil Filter
Army Shipping Documents	
Axle/Final Drive Service, Front and Rear2-392	С
Axle Trunnion Bearings, Rear	
5	Cab
В	Cab Dome Light
Doolson Alarm/Start Interlegic Switch 9 224	Cab Door and Striker
Backup Alarm/Start Interlock Switch2-334 Backup Light Sealed Unit	Cab Floor Heater
Ball and Roller Bearings	Cab Maintenance
Batteries	Cable, Battery
Battery Box	Capabilities and Features
Battery Cable	Chains, Lift
Battery Maintenance	Clean Fuel Tank Filler, Cap and Screen 2-195
Battery Service	Cleaning
Battery Testing	Codes, Abbreviations and Symbols
Bearing Cage	Cold Weather Starting Aid
Bearings	Color Code
Belt Tightener	Connecting Lines
Belts, Engine	Container Lock Cylinder
Belts, Wiring, Hoses and Lines	Container Lock Indicator Panel 1-17, 2-298
Bleeding Brake System	Control Valve
Bleeding Lift Cylinder	Controls and Linkage
Body Accessory Items Maintenance2-423	Controls and Linkage, Transmission
Body, Cab, and Hood Maintenance 2-453	Coolant

Page C (cont)	Page
Coolant Filter	Drive System
Coolant Filter Base Assembly	Drive, Fan
Cooler, Transmission Oil	E
Corrosion Removal	Electrical System
Covers, Valve	Emergency and Parking Brake 1-22, 1-23 Emergency and Parking Brake
Crankcase Guard	Control Valve
Cylinder Head	Engine Access Panels, Lower
Cylinder, Side Shift	Engine Crankcase Breather Service2-158 Engine Electrical Components Maintenance
Cylinder, Steering	Engine Lubrication
D	Engine Maintenance
Damper Pulley	Engine Oil Pressure Sending Unit
Defroster	Engine Service
Prevent Enemy Use	Engine Water Temperature Sending Unit2-266 Ether Aid Solenoid
Differential	Ether Starting Aid
Diode Testing	Exhaust Pipe2-11Exhaust Pipe and Mufflers1-16, 2-211Exhaust System
Door, Cab	F
Drive Shaft Support Bearing	Fan
Drive Shafts	Fan Assembly

Page F (cont)	Page
Fan Drive Mechanism 2-236 Fan Guards 2-249 Features 1-3 Fenders 2-457 Filler, Oil 2-161 Filler Screen 2-24 Filter, Brake Hydraulic System 2-490 Filter, Cab Heater 2-450 Filter, Coolant 2-11 Filter, Hydraulic 2-487 Filter, Implement 2-24 Filter, Oil 1-11, 1-28, 2-8	Grease Lines
Filter, Transmission Oil	Headlight Sealed Lamp Units .2-285 Headlight, Auxiliary .1-4 Heater and Defroster .2-438 Heater, Cab Floor .2-434 Heaters .2-71, 2-92, 2-94 Hitch .1-4 Hood .1-4, 2-454 Hood Maintenance .2-453 Hook, Pintle .2-475 Horns .2-71, 2-95, 2-96, 2-332 Hoses and Lines .2-12 Hoses, Linesand Fittings .2-247
Fuel System	Hydraulic Filter Service
G Gages	I Indicator Lights 2-72, 2-97, 2-98, 2-101, 2-104, 2-106, 2-108, 2-110, 2-112, 2-114, 2-117, 2-118, 2-120, 2-122, 2-124 Indicator, Container Lock

Inlet Manifold	Page	Page
Inlet Manifold	I (cont)	-
Lift Chains	Inlet Manifold	Manual Release of Parking Brake
Lift Cylinder	Ladders	N
Light, Service 2-73, 2-126, 2-133, 2-136 Lights 1-4 Limit Switch, Tophandler 2-507 Lines, Hoses, Fittings 2-22 Linkage, Brake 2-366 Linkages, Controls and 2-497 Lip Type Seals 2-148 Loading 2-515 Lubrication System, Engine 1-11 M Oil Filter Bypass Valve 1-11 Oil Filter Lines 2-161 Magnetic Screen 1-28 Magnetic Strainer Assembly 2-13 Main Disconnect Switch 1-17, 1-19, 2-300 Maintenance 2-145 Maintenance Forms, Records and Reports 1-1 Maintenance, General Practices 2-146 Manifold, Exhaust 1-16	Lift Cylinder	Neutralizer Valves
Limit Switch, Tophandler .2-507 Ohms Scale .2-51 Lines, Hoses, Fittings .2-22 Oil Breathers .2-7 Linkage, Brake .2-366 Oil Cooler .1-11, 1-12, 1-28 Linkages, Controls and .2-497 Oil Cooler Bypass Valve .1-11 Lip Type Seals .2-148 Oil Filler Assembly .2-161 Loading .2-515 Oil Filter Bypass Valve .1-11, 1-28, 2-8 Lubrication System, Engine .1-11 Oil Filter Bypass Valve .1-11 M Oil Level Switch .2-317 Oil Lines and Passages .1-11 Magnetic Screen .1-28 Oil Pan .1-11 Magnetic Strainer Assembly .2-13 Oil Pump .1-11, 1-28 Main Disconnect Switch .1-17, 1-19, 2-300 Oil Reservoir .1-28 Maintenance .2-245 Oil, Hydraulic .2-24 Maintenance Forms, Records and Reports .1-1 Operator's Cab .1-4 Maintenance, General Practices .2-146 Organizational Preventive Maintenance Manifold, Exhaust .1-16 Checks and Services .2-6 <td>Light, Service 2-73, 2-126, 2-133, 2-136</td> <td>O</td>	Light, Service 2-73, 2-126, 2-133, 2-136	O
Magnetic Screen	Limit Switch, Tophandler 2-507 Lines, Hoses, Fittings 2-22 Linkage, Brake 2-366 Linkages, Controls and 2-497 Lip Type Seals 2-148 Loading 2-515 Lubrication System, Engine 1-11	Ohms Scale 2-51 Oil Breathers 2-7 Oil Cooler 1-11, 1-12, 1-28 Oil Cooler Bypass Valve 1-11 Oil Filler Assembly 2-161 Oil Filter 1-11, 1-28, 2-8 Oil Filter Bypass Valve 1-11 Oil Filter Lines 2-161
Magnetic Screen	M	
Manifold, Exhaust	Magnetic Strainer Assembly	Oil Pan
	Manifold, Exhaust	

Page	Page
P	
Packing	Reporting of Equipment Improvement Recommendations
Parts Replacement	S
Performance Data	Safety 2-146 Screen, Magnetic 1-28 Seals, Lip Type 2-148 Seat 2-460 Seat Belts 2-462 Sending Unit, Oil Pressure 2-264 Sending Unit, Water Temperature 2-266 Service Air Cleaner/Precleaner 2-208 Service Brake Control Linkage 2-366 Service Brake Pedals 2-346, 2-369 Service Brake System Bleeding 2-371 Service Brakes 1-22, 2-17 Service Lights 2-73, 2-126, 2-133, 2-136 Service Meter 2-73, 2-141 Shafts 2-149
Radiator	Shipment
Repair and Replacement Procedures2-147 Repair Parts	Equipment

Change 1

INDEX-6

Page	Page
S (cont)	
Spider Assembly	Tires and Rims Installation
Tires	Valve Covers
Tire Removal/Installation 2-398.5	Vehicle Lighting Systems Maintenance2-284 Voltage, Measuring

Page

W

Warning Alarm and Switch, Backup
Warning Horn, Front
Warranty Information
Water Hoses, Lines and Fittings
Water Pump
Water Temperature
Regulators
Water Temperature Switch
Wheels, Axles and Final Drives, Front
Wheels, Axles and Final Drives, Rear
Windshield Wiper Motor and Linkage2-426
Windshield Wipers
Wire and Harness Testing
Wire Harness Connectors
Wire List
Wiring Harness

By Order of the Secretary of the Army:

E. C. MEYER

General, United States Army

Chief of Staff

Official:

J. C. PENNINGTON Major General, United States Army The Adjutant General

Distribution:

To be distirbuted in accordance with DA FORM 12-38, Organizational Maintenance requirements for Truck, Container Handler Rough Terrian 50,000 lb capacity. (Qty rqr blk no 0314)

*U.S. GOVERNMENT PRINTING OFFICE: 1987 0 - 189-547

Use Part II (reverse) for Repair Parts and Special Tool Lists (RPSTL) and Supply Catalogs/Supply Manuals (SC/ DATE: RECOMMENDED CHANGES TO PUBLICATIONS AND Date form is filled out. **BLANK FORMS** For use of this form, see AR 310-1; the proponent agency is the US Army Adjutant General Center. TO: (Forward to proponent of publication or form) (Include ZIP Code) FROM: (Activity and location) (Include ZIP Code) Mailing address found on title block page. Your mailing address. PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS PUBLICATION/FORM NUMBER: DATE: TM X-XXXX-XXX-XXX Date of the TM. Title of TM. LINE FIGURE ITEM PAGE TABLE RECOMMENDED CHANGES AND REASON PARA-NO. GRAPH NO. NO. (Exact wording of recommended change must be given) NO. 0019 00 1 3 1 1 Step No. 2 says to secure doors open with locking bar or hooks from where to what? The bars or hooks are not identified. 0019 00 4 Step No. 19 states to remove locking bars, pins or 4 1 1 hooks from where to what? The bars, pins or hooks are not identified. Where are they stored? SAMPLE Reference to line numbers within the paragraph or subparagraph. TELEPHONE EXCHANGE/AUTOVON, PLUS EXTENSION TYPED NAME, GRADE OR TITLE SIGNATURE Doe, John, CPL 755-1313 CPL John Doe

TO: (For Code)	ward to pr	oponent o	f publication or form) (Inclu	de ZIP FROM	: (Activity and lo	cation) (Includ	DATE:		
			DADTII DEDAIS -	DTO AND ODES:	1 TOOL ::277	AND OURSE	04741 000/01/07:11	MANUALO	
PUBLICA	ATION/FO	RM NUMB		K 15 AND SPECIA	DATE:	AND SUPPLY	CATALOGS/SUPPLY TITLE:	WIANUALS	
			XX-XXX		Date of the	ne TM.	Title of TM.		
PAGE NO.	COLM NO.	LINE NO.	FEDERAL STOCK NUMBER	REFERENCE NO.	FIGURE NO.	ITEM NO.	TOTAL NO. OF MAJOR ITEMS SUPPORTED	RECOMMENDED ACTION	
* Referer			vithin the paragraph or sub	Additional blank sh	endations, or sug	gestions for im d if more space	provement of publications is needed.)	ons and	
		ADE OR T		TELEPHONE EX	CHANGE/AUTO	VON, PLUS	SIGNATURE		
Doe,	John,	CPL		755-131	3		CPL John	Doe	

RECOMMENDED CHANGES TO PUBLICATIONS AND								DATE	
For use o Army Adj	of this form jutant Gene		NK FORMS 0-1; the pro		ncy is the US	Use Part II (reverse) Special Tool Lists (R Catalogs/Supply Man	PSTL) and Supply		
TO: (Forv	ward to prop	onentof publi	cation or fo	rm) (Include Z	IP Code)	FROM: (Activity ar	nd location) (Include	ZIP Code)	
		IT/TECH PU				•			
	ck Island <i>I</i>								
Rock	Island, IL	61299-763	30						
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS									
PUBLICA [*]	TION/FORI	M NUMBER				DATE	,	TITLE	
ITEM NO.	PAGE NO.	PARA- GRAPH	LINE NO.*	FIGURE NO.	TABLE NO.			NGES AND REASON nded change mustbe given)	
I	<u> </u>]	* R	e ference to	line numb e s v	within the paragraph o	or subparagraph.		
TYPED N	AME, GRA	DE OR TITL		TELE	PHONE EXC	HANGE/AUTOVON,	SIGNATURE		
				PLUS	SEXTENSION	l			

TO: (Forward to proponent of publication or form) (Include ZIP Code)						F	FROM: (Activi	ty and lo	ocatio	n) (Include ZIP Code	DATE
		PAR	T II- REPAIR PAR	TS AND SP	ECIAL TO	OOL LI	LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS				
PUBLICA	ATION/FOF					DATE				TITLE	
PAGE NO.	COLM NO.	LINE NO.	FEDERAL S NUMBE		REFERE NO	ENCE	FIGURE NO.	ITEI NO	M).	TOTAL NO. OF MAJOR ITEMS SUPPROTED	RECOMMENDED ACTION
		PART III	- REMARKS (Any blank	general rem forms. Addi	narks or rec	comme k sheet	endations, or su ts may be used	ggestion if more s	ns for space	improvement of pub is needed.)	olications and
PART III - REMARKS (Any general remarks or recommendations, or suggestions fα improvement of publications a blank forms. Additional blank sheets may be used if m ore space is needed.)											
TYPED NAME, GRADE OR TITLE TELEPHONE EXCHANGE PLUS EXTENSION							E/AUTOVON,		SIG	NATURE	

RECOMMENDED CHANGES TO PUBLICATIONS AND								DATE	
For use o Army Adj	of this form jutant Gene		NK FORMS 0-1; the pro		ncy is the US	Use Part II (reverse) Special Tool Lists (R Catalogs/Supply Man	PSTL) and Supply		
TO: (Forv	ward to prop	onentof publi	cation or fo	rm) (Include Z	IP Code)	FROM: (Activity ar	nd location) (Include	ZIP Code)	
		IT/TECH PU				•			
	ck Island A								
Rock	Island, IL	61299-763	30						
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS									
PUBLICA [*]	TION/FORI	M NUMBER				DATE	,	TITLE	
ITEM NO.	PAGE NO.	PARA- GRAPH	LINE NO.*	FIGURE NO.	TABLE NO.			NGES AND REASON nded change mustbe given)	
I	<u> </u>]	* R	e ference to	line numb e s v	within the paragraph o	or subparagraph.		
TYPED N	AME, GRA	DE OR TITL		TELE	PHONE EXC	HANGE/AUTOVON,	SIGNATURE		
				PLUS	SEXTENSION	l			

TO: (Forward to proponent of publication or form) (Include ZIP Code)						F	FROM: (Activi	ty and lo	ocatio	n) (Include ZIP Code	DATE
		PAR	T II- REPAIR PAR	TS AND SP	ECIAL TO	OOL LI	LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS				
PUBLICA	ATION/FOF					DATE				TITLE	
PAGE NO.	COLM NO.	LINE NO.	FEDERAL S NUMBE		REFERE NO	ENCE	FIGURE NO.	ITEI NO	M).	TOTAL NO. OF MAJOR ITEMS SUPPROTED	RECOMMENDED ACTION
		PART III	- REMARKS (Any blank	general rem forms. Addi	narks or rec	comme k sheet	endations, or su ts may be used	ggestion if more s	ns for space	improvement of pub is needed.)	olications and
PART III - REMARKS (Any general remarks or recommendations, or suggestions fα improvement of publications a blank forms. Additional blank sheets may be used if m ore space is needed.)											
TYPED NAME, GRADE OR TITLE TELEPHONE EXCHANGE PLUS EXTENSION							E/AUTOVON,		SIG	NATURE	

RECOMMENDED CHANGES TO PUBLICATIONS AND								DATE	
For use o Army Adj	of this form jutant Gene		NK FORMS 0-1; the pro		ncy is the US	Use Part II (reverse) Special Tool Lists (R Catalogs/Supply Man	PSTL) and Supply		
TO: (Forv	ward to prop	onentof publi	cation or fo	rm) (Include Z	IP Code)	FROM: (Activity ar	nd location) (Include	ZIP Code)	
		IT/TECH PU				•			
	ck Island A								
Rock	Island, IL	61299-763	30						
PART I - ALL PUBLICATIONS (EXCEPT RPSTL AND SC/SM) AND BLANK FORMS									
PUBLICA [*]	TION/FORI	M NUMBER				DATE	,	TITLE	
ITEM NO.	PAGE NO.	PARA- GRAPH	LINE NO.*	FIGURE NO.	TABLE NO.			NGES AND REASON nded change mustbe given)	
I	<u> </u>]	* R	e ference to	line numb e s v	within the paragraph o	or subparagraph.		
TYPED N	AME, GRA	DE OR TITL		TELE	PHONE EXC	HANGE/AUTOVON,	SIGNATURE		
				PLUS	SEXTENSION	l			

TO: (Forward to proponent of publication or form) (Include ZIP Code)						F	FROM: (Activi	ty and lo	ocatio	n) (Include ZIP Code	DATE
		PAR	T II- REPAIR PAR	TS AND SP	ECIAL TO	OOL LI	LISTS AND SUPPLY CATALOGS/SUPPLY MANUALS				
PUBLICA	ATION/FOF					DATE				TITLE	
PAGE NO.	COLM NO.	LINE NO.	FEDERAL S NUMBE		REFERE NO	ENCE	FIGURE NO.	ITEI NO	M).	TOTAL NO. OF MAJOR ITEMS SUPPROTED	RECOMMENDED ACTION
		PART III	- REMARKS (Any blank	general rem forms. Addi	narks or rec	comme k sheet	endations, or su ts may be used	ggestion if more s	ns for space	improvement of pub is needed.)	olications and
PART III - REMARKS (Any general remarks or recommendations, or suggestions fα improvement of publications a blank forms. Additional blank sheets may be used if m ore space is needed.)											
TYPED NAME, GRADE OR TITLE TELEPHONE EXCHANGE PLUS EXTENSION							E/AUTOVON,		SIG	NATURE	

RED
WHITE
ORANGE
YELLOW
TAN
PINK
BLACK
GRAY
PURPLE
BROWN
DARK GREEN
DARK BLUE
LIGHT BLUE
BASIC COLORISTRIPE


DESCRIPTION

WIRE TERMINAL
SPLICE OR JUNCTION OF WIRES
CROSSING OF WIRES NOT CONNECTED

-- THERNAL GROUNDING OF COMPONENTS


B GY PU BR DA GR DA BL LT GR LT BL XX/XX

ROTJANNO) <---




TA0989

Electrical Schematic Diagram (Sheet 1 of 3)




Electrical Schematic Diagram (Sheet 2 of 3)




TA098906

Electrical Schematic Diagram (Sheet 3 of 3)

TM 10-3930-641-20





TA096910

Hydraulic Diagram (Sheet 2 of 2)

FO-5

PIN: 049294-000