

TM 5-4120-273-15

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

Operator, Organizational, Direct Support
General Support and Depot Maintenance Manual
AIR CONDITIONING UNITS, ELECTRIC MOTOR DRIVEN
6,000 BTU/HR VERTICAL COMPACT, 115 VOLT,
SINGLE PHASE 50/60 CYCLE (THERMO-AIR MODEL
CV-6-1-15-60) FSN 4120-935-1608
6,000 BTU/HR VERTICAL COMPACT, 208 VOLT,
THREE PHASE 400 CYCLE (THERMO-AIR MODEL
CV-6-3-08-400) FSN 4120-935-1607

This copy is a reprint which includes current
pages from Changes 1 through 3.

HEADQUARTERS, DEPARTMENT OF THE ARMY
FEBRUARY 1969

SAFETY PRECAUTIONS

BEFORE OPERATION

Disconnect air conditioner from power source before performing maintenance on components of unit.

Avoid bodily contact with liquid refrigerant and avoid inhaling refrigerant gas. Be careful that Refrigerant-22 does not contact eyes. In case of leaks, ventilate area immediately.

DURING OPERATION

Avoid bodily contact with liquid refrigerant and avoid inhaling refrigerant gas. Be careful that Refrigerant-22 does not contact eyes. In case of leaks, ventilate area immediately.

Disconnect air conditioner from power source before performing maintenance on components of unit.

AFTER OPERATION

Disconnect air conditioner from power source before performing maintenance on components of unit.

Avoid bodily contact with liquid refrigerant and avoid inhaling refrigerant gas. Be careful that Refrigerant-22 does not contact eyes. In case of leaks, ventilate area immediately.

CHANGE

NO. 4

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 1 JULY 1992

Operator, Organizational, Direct Support, General Support
and Depot Maintenance Manual

AIR CONDITIONING UNITS, ELECTRIC MOTOR DRIVEN, 6,000 BTU/HR
VERTICAL, COMPACT, 115 VOLT, SINGLE-PHASE,
50/60 HERTZ THERMO-AIR MODEL CY6-5/6-15,
NSN 4120-01-172-8841, 6,000 BTU/HR, VERTICAL, COMPACT, 208 VOLT,
THREE PHASE, 400 HERTZ, THERMO-AIR
MODEL WEVM-6000-400, NSN 4120-01-175-9730

Approved for public release; distribution is unlimited

TM 5-4120-273-15, 28 February 1969, is changed as follows:

Page 5-4 is changed as follows:

- Paragraph 5-21 b, *Releasing Refrigerant for Service*, is superseded as follows:

NOTE

In accordance with Environmental Protection Agency regulations, refrigerants cannot be discharged into the atmosphere. A recovery/recycling unit must be used whenever discharging the unit.

Operation of the recovery/recycling unit must be by AUTHORIZED PERSONNEL ONLY.

b. *Releasing Refrigerant for Service*. Connect and operate a recovery/recycling unit in accordance with the manufacturer's instructions.

- Paragraph 5-21 d, *Charging the Refrigerant System*, insert the following note:

NOTE

Whenever available, use recycled refrigerant for charging the refrigeration system.

Page C-3 is changed as follows:


- SECTION III, is changed as shown:

SECTION III. TOOLS AND TEST EQUIPMENT REQUIREMENTS

TOOL OR TEST EQUIPMENT REF CODE	MAINTENANCE CATEGORY	NOMENCLATURE	NATIONAL/NATO STOCK NUMBER	TOOL NUMBER
1	F-H	Recovery and Recycling Unit, Refrigerant	4130-01-338-2707	17500B (07295)

By Order of the Secretary of the Army:

Official:



MILTON H. HAMILTON
*Administrative Assistant to the
 Secretary of the Army*

01540

GORDON R. SULLIVAN
*General, United States Army
 Chief of Staff*

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25E, qty rqr block no. 0193.

CHANGE }
No. 3 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 27 March 1987

Operator's, Organizational, Direct Support, General Support and
Depot Maintenance Manual

AIR CONDITIONING UNITS, ELECTRIC MOTOR DRIVEN, 6,000 BTU/HR,
VERTICAL, COMPACT, 115 VOLT, SINGLE-PHASE,
50/60 HERTZ THERMO-AIR MODEL CY6-5/6-15,
NSN 4120-01-172-8841, 6,000 BTU/HR, VERTICAL, COMPACT, 208 VOLT,
THREE PHASE, 400 HERTZ, THERMO-AIR
MODEL WEVM-6000-400, NSN 4120-01-175-9730

TM 5-4120-273-15, 28 February 1969, is changed as follows:

The title is changed as shown above.

Page 1-1, paragraph 1-1d. Change address to which DA Forms 2028 are forwarded to read, "Commander, U.S. Army Troop Support Command, ATTN: AMSTR-MCTS, 4300 Goodfellow Boulevard, St. Louis, MO 63120-1798."

Page 3-4. At bottom center of page, add, "Figure 3-2 (1). Quarterly Preventive Maintenance Services."

Foldout page 1-6①. At bottom center of diagram, add "Figure 1-6(1). Wiring Diagram Model WEVM-6000-400."

Wherever text reads, "Model CV-6-1-15-60," change text to read, "Model CY6-5/6-15."

Wherever text reads, "NSN 4120-00-935-1608" or FSN 4120-00-935-1608," change text to read, "NSN 4120-01-172-8841."

Wherever text reads, "Model CV-6-3-08-400," change text to read, "Model WEVM-6000-400."

Wherever text reads, "NSN 4120-00-935-1607" or "FSN 4120-00-935-1607," change text to read, "NSN 4120-01-175-9730."

By Order of the Secretary of the Army:

JOHN A. WICKHAM, JR.
General, United States Army
Chief of Staff

Official:

R. L. DILWORTH
Brigadier General, United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25A, Operator's, Organizational, Direct Support and General Support Maintenance requirements for Air Conditioning Unit, Vertical Compact, 6000 BTU (CV-6-1-15-60: 115V, 50/60HZ, 1PH; CV-6-3-08-400: 208V, 400HZ, 3PH).

Changes in force: C 1 and C 2

TM 5-4120-273-15

C 2

CHANGE }
No. 2 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, C. C. 12 March 1975

**Operator's Organizational, Direct Support,
General Support and Depot Maintenance Manual
AIR CONDITIONING UNITS, ELECTRIC MOTOR DRIVEN, 6,000
BTU/HR, VERTICAL, COMPACT, 115 VOLT, SINGLE-PHASE,
50/60 HERTZ THERMO-AIR MODEL CV-6-1-15-60, NSN
4120-00-935-1608, 6,000 BTU/HR, VERTICAL COMPACT,
208 VOLT, THREE PHASE, 400 HERTZ, THERMO-AIR
MODEL CV-6-3-08-400
NSN 4120-00-935-1607**

TM 5-4120-273-15, 23 February 1969, is changed as follows:

The title is changed as shown above.

Page 2 of Cover. Add the following warning to the list of safety precautions.

WARNING

The burning of polyurethane foams is dangerous. Due to the chemical composition of a polyurethane foam, toxic fumes are released when it is burned or heated. If it is burned or heated indoors, such as during a welding operation in its proximity, precautions should be taken to adequately ventilate the area. An exhaust system equivalent to that of a paint spray booth should be used. Air supplied respirators, approved by the National Institute for Occupational Safety & Health or the U.S. Bureau of Mines, should be used for all welding in confined spaces and when ventilation is inadequate. Individuals who have chronic or recurrent respiratory conditions, including allergies and asthma, should not be employed in this type of environment.

By Order of the Secretary of the Army:

FRED C. WEYAND
*General, United States Army
Chief of Staff*

Official:

VERNE L. BOWERS
*Major General, United States Army
The Adjutant General*

Distribution:

To be distributed in accordance with DA Form 12-25C, (qty rqr block No. 530). Organizational maintenance requirements for Environmental Equipment: Air Conditioners, 6,000 BTU.

Change }
 No. 1 }

HEADQUARTERS
 DEPARTMENT OF THE ARMY
 Washington, D.C. 16 April 1973

**Operator, Organizational, Direct Support
 General Support and Depot Maintenance Manual**

**AIR CONDITIONING UNITS, ELECTRIC MOTOR DRIVEN:
 6000 BTU/HR; VERTICAL, COMPACT; 115 VOLT, SINGLE
 PHASE, 50/60 HERTZ (THERMO-AIR MODEL CV-6-1-15-60)
 FSN 4120-935-1608;
 6000 BTU/HR; VERTICAL, COMPACT; 208 VOLT, THREE
 PHASE, 400 HERTZ (THERMO-AIR MODEL CV-6-3-08-400)
 FSN 4120-935-1607**

TM 5-4120-273-15, 28 February 1971, is changed as follows:
Page B-1. Appendix B is superseded.

**APPENDIX B
 BASIC ISSUE ITEMS LIST AND ITEMS
 TROOP INSTALLED OR AUTHORIZED**

Section I. INTRODUCTION

B-1. Scope

This appendix lists items required by the operator for operation of the air conditioner.

B-2. General

This list is divided into the following sections:

a. *Basic Issue Items List - Section II.* Not applicable.

b. *Item Troop Installed or Authorized List - Section III.* A list of items in alphabetical sequence, which at the discretion of the unit commander may accompany the air conditioner. These items are NOT SUBJECT TO TURN-IN with the air conditioner when evacuated.

3. Explanation of Columns

The following provides an explanation of columns in the tabular list of Basic issue Items List, Section II.

and Items Troop Installed or Authorized, Section III.

a. *Source, Maintenance and Recoverability Code (SMR).* Not applicable.

b. *Federal Stock Number.* This column indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. *Description.* This column indicates the Federal item name and any additional description of the item required.

d. *Unit of Measure (U/M).* A two character alphabetic abbreviation indicating the amount or quantity of the item upon which the allowances are based, e.g., ft. ea, pr, etc.

e. *Quantity Furnished with Equipment (Blank)* Not applicable.

f. *Quantity Authorized (Items Troop Installed or Authorized).* This column indicates the quantity of the item authorized to be used with the equipment.

Section III. ITEMS TROOP INSTALLED OR AUTHORIZED LIST

(1) SMR code	(2) Federal stock number	(3) Description Ref. No. & Mfr code	(4) Unit of meas	(5) Qty auth
	7520-559-9618	CASE. Maintenance and Operation Manuals	EA	1

By Order of Secretary of the Army:

Official:

VERNE L. BOWERS

*Major General, United States Army
The Adjutant General*

CREIGHTON W. ABRAMS
*General, United States Army
Chief of Staff*

Distribution:

To be distributed in accordance with DA Form 12-25C (qty rqr block No. 530) organizational maintenance requirements for Air Conditioners, 6,000 BTU.

TECHNICAL MANUAL {
 No. 5-4120-273-15 }

HEADQUARTERS
 DEPARTMENT OF THE ARMY
 WASHINGTON, D. C., 28 February 1969

**Operator, Organizational, Direct Support
 General Support and Depot Maintenance Manual**

AIR CONDITIONING UNITS, ELECTRIC MOTOR DRIVEN

**6,000 BTU/HR VERTICAL COMPACT, 115 VOLT, SINGLE
 PHASE 50/60 CYCLE (THERMO-AIR MODEL CV-6-1-15-60)**

FSN 4120-935-1608

**6,000 BTU/HR VERTICAL COMPACT, 208 VOLT, THREE
 PHASE 400 CYCLE (THERMO-AIR MODEL CV-6-3-08-400)**

FSN 4120-935-1607

	Paragraph	Page
CHAPTER 1. INTRODUCTION		
Section I. General -----	1-1,1-2	1-1
II. Description and tabulated data -----	1-3-1-5	1-1-1-6
CHAPTER 2. INSTALLATION AND OPERATION INSTRUCTIONS		
Section I. Service upon receipt of equipment -----	2-1-2-6	2-1-2-3
II. Movement to new worksite -----	2-7,2-8	2-4,2-5
III. Controls and instrument -----	2-9,2-10	2-5
IV. Operation of equipment -----	2-11-2-19	2-7-2-9
CHAPTER 3. OPERATOR AND ORGANIZATIONAL MAINTENANCE INSTRUCTIONS		
Section I. Operator and organizational maintenance tools & equipment -----	3-1,3-2	3-1
II. Lubrication -----	3-3,3-4	3-1
III. Preventive maintenance service -----	3-5-3-7	3-1
IV. Operator's maintenance -----	3-8-3-10	3-6
V. Troubleshooting -----	3-11-3-17	3-6-3-9
VI. Housing assembly -----	3-17-3-20	3-9
VII. General organizational maintenance instructions -----	3-21-3-58	3-9-3-21
CHAPTER 4. DIRECT AND GENERAL SUPPORT AND DEPOT MAINTENANCE INSTRUCTIONS		
Section I. General -----	4-1,4-2	4-1
II. Description and tabulated data -----	4-3,4-4	4-1
CHAPTER 5. GENERAL MAINTENANCE INSTRUCTIONS		
Section I. Special tools and equipment -----	5-1-5-2	5-1
II. Troubleshooting -----	5-3-5-16	5-1,5-2
III. Removal and installation of major components or auxiliaries -----	5-17	5-2
IV. General repair instructions -----	5-18-5-23	5-3-5-5
CHAPTER 6. REPAIR INSTRUCTIONS		
Section I. Compressor -----	6-1,6-2	6-1
II. Condenser coil, evaporator coil -----	6-3-6-6	6-1
III. High pressure switch, low pressure switch, fan speed pressure switch -----	6-6-6-8	6-1,6-2
IV. Liquid line solenoid valve and equalizer solenoid valve -----	6-9,6-10	6-2
V. Pressure relief valve -----	6-11	6-3
VI. Expansion valves -----	6-12	6-3
VII. Access fittings -----	6-13	6-4
VIII. Sight glass -----	6-14,6-15	6-4
APPENDIX A. REFERENCES -----		A-1

	Paragraph	Page
APPENDIX B. BASIC ISSUE ITEMS LIST AND MAINTENANCE AND OPERATING SUPPLIES		
Section I. Introduction		B-1
II. Basic issue items		B-2
III. Maintenance and operating supplies		B-2
APPENDIX C. MAINTENANCE ALLOCATION CHART		
Section I. Introduction		C-1
II. Maintenance allocation chart		C-2
III. Special tool and special test equipment requirements		C-3
IV. Remarks		C-3
INDEX		I-1

CHAPTER 1

INTRODUCTION

Section I. GENERAL

1-1. Scope

a. These instructions are published for the use of personnel to whom the Redmanson Models CV-6-1-15-60 and CV-6-3-08-400 air conditioning units are issued. They provide information on the operating and organizational maintenance of the equipment. Also included are descriptions of main units and their function in relationship to other components.

b. Appendix A contains a list of publications applicable to this manual. Appendix B contains the list of basic issue items authorized the operator of this equipment and the list of maintenance and operating supplies required for initial operation. Appendix C contains the maintenance allocation chart.

c. Numbers in parenthesis following nomenclature callouts on illustrations indicate quantity, numbers preceding nomenclature callouts indicate preferred maintenance sequence.

d. Direct reporting of errors, omissions, and recommendations for improving this equipment

manual by the individual user is authorized and encouraged. Prepare DA Form 2028 (Recommended Changes to DA Publications) for this purpose by using pencil, pen, or typewriter, and forward direct to Commanding General, U. S. Army Mobility Equipment Command, ATTN: AMSME-MPP, 4300 Goodfellow Blvd., St. Louis, Mo. 63120.

e. Report all equipment improvement recommendations as prescribed by TM 38-750.

1-2. Record and Report Forms

a. DA Form 2258 (Depreservation Guide for Vehicles and Equipment).

b. For other record and report forms applicable to operator, crew, and organizational maintenance refer to TM 38-750.

Note. Applicable forms, excluding Standard Form 46 (United States Government Motor Vehicles Operators Identification card) which is carried by the operator, shall be kept in a canvas bag mounted on the equipment.

Section II. DESCRIPTION AND TABULATED DATA


1-3. Description

a. *General.* The air conditioner (fig. 1-1, 1-2, and 1-3) is used primarily in van type enclosures for providing filtered, conditioned, or heated air as required to maintain service conditions necessary for the efficient operation of electronic equipment and for the comfort of operating personnel housed within the specified vans. It is a completely self-contained, air cooled, electric motor driven unit designed for continuous operation with varying loads. It is equipped with internal ducting to the low side of the evaporator fan so that ventilation air and air from the chemical and biological filter unit may be supplied by the evaporator fan.

b. *Condensing Section.* The condensing section, located at the bottom of the unit, contains the her-

metically sealed compressor, condensing coil, condenser air intake opening, condenser air discharge opening, control box, junction box, thermostatic switch, power receptacle connector, condenser fan, fan motor, filter-drier, suction and discharge access fittings, solenoid valve, capacitors (model CV-6-1-15-60 only), and high pressure relief valve.

c. *Evaporator Section.* The evaporator section, located in the top of the unit, contains an evaporator coil, evaporator fan, air conditioning filter, intake and discharge grilles, evaporator coil drain pan, expansion valves, electrical heaters, sight glass, fan speed switch, high and low pressure switches, solenoid valve, expansion valve, liquid line quench valve, hot gas bypass regulator valve,




SHIPPING DIM.
LENGTH - 22
WIDTH - 22
HEIGHT - 38
WEIGHT - 191

- 1. FRONT ACCESS PANEL
- 2. CONTROL BOX
- 3. INTAKE GRILLE

- 4. DAMPER DOOR CONTROL CHAIN
- 5. DISCHARGE GRILLE


ME 4120-273-15/1-1

Figure 1-1. Air conditioner, left front three-quarter view, with shipping dimensions.



ME 4120-273-15/1-2

Figure 1-2. Air conditioner, right front three-quarter view, with sound attenuator.



- | | |
|--|--------------------------------|
| 1. OUTSIDE AIR THERMOSTAT | 9. CASING |
| 2. FAN GUARD | 10. FRESH AIR INLET SCREEN |
| 3. CB COVER | 11. POWER RECEPTACLE CONNECTOR |
| 4. FASTENER | 12. DRAIN PLUGS (4) |
| 5. LOW PRESSURE CUT-OUT SWITCH RESET BUTTON | 13. COVER FASTENING HARDWARE |
| 6. HIGH PRESSURE CUT-OUT SWITCH RESET BUTTON | 14. CANVAS CONDENSER COVER |
| 7. COVER PANEL | 15. CONDENSER COIL |
| 8. SIGHT GLASS | 16. CONDENSER SCREEN |

ME 4120-273-15/1-3

Figure 1-3. Air conditioner, right rear three-quarter view.

and a damper to regulate the amount of outdoor air entering the air conditioner.

1-4. Identification and Tabulated Data

a. Identification. The air conditioning units have 3 major identification plates. The information contained on these plates is listed below.

(1) *Air conditioner, model CV-6-3-08-400.*

(a) *Manufacturer's identification plate.*

Located on the top of the unit.

Title ----- Air conditioner, vertical,
compact, 6000 BTU/HR.
208 volts, 3 phase, 400
cycle
Part No. -----97403 13214E3400
FSN -----4120-935-1607
Manufacturer ----- Redmanson Corporation
Contract No. ----- DAAK-01-67-C-1040
Serial No. ----- 664124, 664126
664226 thru 664273
6703092 thru 6703106
6703040 thru 6703089
Weight ----- 137 lbs. (pounds)
Refrigerant ----- 22
Refrigerant charge ----- 39 oz. (ounce)

(b) *Motor identification plate.*

Manufacturer ----- Welco Industries, Inc.
Cincinnati, Ohio
H. P. ----- .5 & .063
RPM ----- 3750 & 1850 Phase 3, Cycle
400, Volts 208
Frame Size ----- 4715-21
Amps ----- 2.7
RTG ----- Cont.
Thermal Protection

(c) *Compressor identification plate.*

Manufacturer ----- Whirlpool Corporation
Evansville, Indiana
Model No. ----- WHP-422H-6-208-3
Oil charge ----- 17 oz.
Oil type ----- FED VV-L-825 Type IV
Refrigerant -----22
FLA ----- 6
LRA ----- 21
Ultimate trip ----- 7.8 amps at 71 C.
Circuit breaker ----- 475860

(2) *Air conditioner, Model CV-6-1-15-60.*

(a) *Manufacturer's identification plate.*

Located on top of the unit.

Title ----- Air conditioner, Vertical,
Compact, 6000 BTU/HR.,
115 Volts, Single Phase,
60 Cycle.
Part No. ----- 97403 13214E3500
FSN ----- 4120-935-1608
Manufacturer ----- Redmanson Corporation
Contract No. ----- DAAK01-67-C-1040
Serial No. ----- 64125, 664127
664128 thru 664225

Weight ----- 151 lbs.
Refrigerant ----- 22
Refrigerant charge ----- 39 oz.

(h) *Motor identification plate.*

Manufacturer ----- Welco Industries Inc.
Cincinnati, Ohio
H. P. ----- .40 & .05
RPM ----- 3450 & 1750 Phase 1, Cycle
60, Volts 115
Frame size ----- 4715-20
Amps ----- 4.0 & 1.3
Rating ----- Continuous

(c) *Compressor identification plate.*

Manufacturer ----- Whirlpool Corporation
Evansville, Indiana
Model No. ----- WHP-6-115-1
Oil charge ----- 17 oz.
Oil type ----- FED VV-L-825 Type IV
Refrigerant ----- 12
FLA ----- 12
LRA ----- 12
Ultimate Trip ----- 15 Amps at 71°C.
Circuit Breaker ----- 575854
Date ----- 1/12/66

b. Tabulated Data.

(1) *For model CV-6-1-15-60.*

(a) *Air conditioner.*

Manufacturer ----- Redmanson Corporation
Model ----- CV-6-1-15-60
Class ----- 1
Serial numbers ----- 664125, 664127,
664128 thru 664225
Stock No. FSN ----- 4120-935-1608
Weight ----- 151 lbs.

(b) *Compressor.*

Manufacturer ----- Whirlpool Corporation
Evansville, Indiana
Type ----- Hermetic
Model ----- WHP-622H6-115-1
Capacity ----- 6,000 BTU/HR.

(c) *Motor.*

Manufacturer ----- Welco Industries
Cincinnati, Ohio
Type ----- Open
Model ----- 4715-21

(d) *Evaporator coil.*

Manufacturer ----- Bohn Aluminum and Brass
Co.
Type ----- Copper tubes expanded
into aluminum fins.

(e) *Condenser coil.*

Manufacturer ----- Bohn Aluminum and Brass
Co.
Type ----- Copper tubes expanded into
aluminum fins.

(f) *Air filter.*

Manufacturer ----- Research products
 Type ----- Permanent

(g) *Dimensions and weight.*

Length ----- 17"
 Width ----- 17"
 Height ----- 28 1/4"
 Weight ----- 151 lbs.

(h) *Wiring diagram (schematic) 13214E-3448.* Ssee figure 1-5(1).

(i) *Base plan.* See figure 1-4.

(2) *Model CV-6-3-08-400.*

(a) *Air conditioner.*

Manufacturer ----- Redmanson Corporation
 Model ----- CV-6-3-08-400
 Class ----- 2
 Serial No. ----- 664124, 664126,
 664226 thru 664273
 6703040 thru 6703089
 6703092 thru 6703106
 FSN ----- 4120-935-1607
 Weight ----- 137 pounds

(b) *Compressor.*

Manufacturer ----- Whirlpool Corporation
 Evansville, Indiana
 Type ----- Hermetic
 Model ----- WHP422H6-208-3
 Capacity ----- 6,000 BTU/HR.

(c) *Motor.*

Manufacturer ----- Welco Industries
 Cincinnati, Ohio
 Type ----- Open
 Model ----- 4715-21

(d) *Evaporator coil.*

Manufacturer ----- Bohn Aluminum and Brass
 Co.

Type ----- Copper tubes expanded into
 aluminum fins.

(e) *Condenser coil.*

Manufacturer ----- Bohn Aluminum and Brass
 Co.
 Type ----- Copper tubes expanded into
 aluminum fins.

(f) *Air filter.*

Manufacturer ----- Research Products
 Madison, Wisconsin
 Type ----- Permanent

(g) *Dimensions and weight.*


Length ----- 17°
 Width ----- 17°
 Height ----- 28 1/4"
 Weight ----- 137 lbs.

(h) *Wiring diagram (schematic) D44527-101.* See figure 1-5(1) and 1-5(2).

(i) *Base plan.* See figure 1-4.

1-5. Difference in Models

This manual covers the Redmanson Corporation models CV-6-1-15-60 Serial No. 664125, 664127, 664128 thru 664225, and CV-6-3-08-400 Serial No. 664124, 664126 664226 thru 664273, 6703040 thru 6703089, 6703092 thru 6703106 air conditioners. The differences between the models are in the electrical systems, compressor and motors. Where differences exist, each model is covered separately in the applicable section of this manual. The single phase unit, model CV-6-1-15-60 runs on 115 volt current. The three-phase unit, model CV-6-3-08-60 has capacitors, one fan relay and no phase sequence relay. Model CV-6-3-08-400 has no capacitors, two fan relays and a phase sequence relay.



ME 4120-273-15/1-4

Figure 1-4. Base plan.

Figure 1-5 (1). Wiring diagram model CV-6-1-15-60.
(Located in back of manual)

Figure 1-6 (1). Wiring diagram model CV-6-1-15-60.
(Located in back of manual)

Figure 1-5 (2)—Continued.
(Located in back of manual)

Figure 1-6 (2)—Continued.
(Located in back of manual)

CHAPTER 2

INSTALLATION AND OPERATION INSTRUCTIONS

Section I. SERVICE UPON RECEIPT OF EQUIPMENT

2-1. Unloading the Equipment

a. Remove any blocking or tie downs that may have been used to secure the item to carrier. The air conditioner is shipped in a wood carton, the base of which is raised to provide for insertion of tongs of a forklift.

b. Use a forklift or other suitable lifting device to remove unit from carrier. If necessary, the unit may be unloaded manually.

Caution: Use care in handling to avoid damaging the air conditioner.

2-2. Unpacking the Equipment

a. *General.* Move air conditioner to installation site before removing shipping container. Cut the metal bands and remove top, end, and sides of carton, and the Kimpak covering. Remove bolts securing base of unit to carton, and lift unit from carton.

b. *Depreservation.* Prior to placing unit in operation, accomplish depreservation in accordance with instructions outlined in DA Form 2558 (Depreservation Guide of Engineer Equipment). DA Form 2258 is attached to or near the operational controls.

2-3. Inspecting and Servicing Equipment

a. Perform daily preventive maintenance service (para 3-6).

b. Perform quarterly preventive maintenance service (para 3-7).

c. Inspect entire air conditioner for signs of damage, paying particular attention to evaporator and condenser coils.

d. The air conditioner contains a full operating charge of refrigerant and compressor oil. No further service is required.

2-4. Installation of Separately Packed Components

a. *General.* The air conditioner is basically a self-contained unit, however, in certain installa-

tions it may become desirable to utilize the block-off plate with an electrical receptacle, and use a remote control box.

b. *Sound Attenuator.* The sound attenuator will provide a sound dampening effect and is mounted on the front of the air conditioner (fig. 1-2). The sound attenuator replaces the air intake and discharge grilles and air is taken in and discharged through the attenuator baffles. Air is taken in through the bottom and discharged through the top of the attenuator. Refer to figure 1-2, and install the sound attenuator as follows:

(1) Remove the intake and discharge grilles (para 3-18).

(2) Place the sound attenuator in position on the front of the unit by aligning the grille mounting holes with the attenuator mounting holes.

Note. Make sure that the notched edge of the attenuator frame matches the damper door control chain location.

(3) Install the mounting bolts.


(4) Store the grilles so as to avoid possible damage.

Caution: The use of the sound attenuator may result in reduced capacity.

2-5. Installation or Setting-Up Instructions

a. *General.* Set air conditioner in a level position to allow proper condensate draining (operation will be satisfactory with unit sitting at a slight angle (5 degrees maximum) and using one of the alternate drain connections).

b. *Locating the Unit.* The front access panel and discharge and intake grilles are removable for normal service and maintenance, and must always be unobstructed to allow sufficient air for condensing purposes. The discharge and intake openings at front of unit should be free from obstruction to permit maximum unit capacity.



NOTE: TAG AND DISCONNECT ELECTRICAL LEADS AS NECESSARY.

CONTROL PANEL:

- STEP 1 - REMOVE THERMOSTAT CONTROL KNOB BY LOOSENING SETSCREW.
- STEP 2 - REMOVE NUT FROM FAN SPEED SWITCH.
- STEP 3 - REMOVE SELECTOR SWITCH KNOB BY LOOSENING SETSCREWS.
- STEP 4 - UNSCREW ELECTRICAL CONNECTOR.
- STEP 5 - REMOVE CONTROL BOX BY REMOVING SCREWS (4).

MEC 4120-273-15/2-1 ①

Figure 2-1 (1). Control panel, block-off plate, thermostat sensing bulb and control box back panel removal and installation.

Note. Remove discharge and intake grilles and filter, if unit is to be used with ducts carrying air to and from the conditioned- space. Install grilles and filter into the duct.

Note. Remove the CB inlet cover (fig. 3-4) if a chemical and biological filter unit is to be attached to the unit.


c. Installing Unit. Bolt unit to floor or other flat surface. Refer to base plan (fig. 1-4) for dimensions. An additional fastening device (fig. 1-3) is provided on the upper rear side of the unit for additional mounting rigidity if required. Connect drain hose to drain fitting at bottom of unit to lead condensate away from unit. The units are provided with four drain plugs installed. Remove plug prior to installing the drain hose.

d. Power Sources.

(1) *Model CV-6-3-08-400.* Operates on 208 volt, 400 cycle, 3 phase power.

(2) *Model CV-6-1-15-60.* Operates on 115 volts 50/60 cycle, single phase power.

(3) *Power receptacle connector.* Receptacle is located at rear of unit above the condenser coil air inlet. Connect the proper electrical power supply source to this receptacle using a plug or receptacle alternate. Alternate electrical power connection openings are provided at both sides and front of the unit, any location may be used by interchanging the power receptacle at rear of the unit and one of the cover plates at sides or front of the



THERMOSTAT SENSING BULB:

- STEP 1 - REMOVE THERMOSTAT SENSING BULB BY REMOVING SCREW AND CLAMP.
- STEP 2 - REMOVE BACK PANEL BY REMOVING SCREWS (4) AND LOCKNUTS (4).
- STEP 3 - REMOVE THERMOSTAT BY REMOVING SCREWS (4).

MEC 4120-273-15/2-1 (2)

Figure 2-1 (2)—Continued

unit. Be sure to attach cover plate over unused location at rear of unit to prevent air from being drawn through the opening.

e. Remote Control.

(1) *General.* The control box (fig. 2-1 (1)) may be removed from the unit and used for remote control operation of the air conditioner. A block-off plate provided as an accessory must be used to replace the control box. The control box is placed


at another location, thus allowing the air conditioner to be controlled from this remote location.

(2) Remote control connection.

- (a) Disconnect power source from unit.
- (b) Refer to figure 2-1(1), 2-1(2), and 2-1(3) for installing blockoff plate.

Note. A cable must be provided connecting the new remotely located control box and the block-off plate.

2-6. Equipment Conversion (Not applicable).



BLOCK OFF PLATE:

- STEP 1 - REMOVE COVER PLATE FROM BLOCK OFF PLATE AND INSTALL ELECTRICAL CONNECTOR FROM REAR, SECURE WITH SCREWS (4).
- STEP 2 - REPLACE CONTROL BOX WITH BLOCK OFF PLATE AND SECURE WITH SCREWS (4).

MEC 4120-273-15/2-1 (3)

Figure 2-1 (3)-Continued

Section II. MOVEMENT TO NEW WORKSITE

2-7. Dismantling For Movement

a. General.

- (1) Shut off electrical power supply to air conditioner and disconnect power cable from unit.
- (2) Disconnect drain hose from unit.

Note. Disconnect all duct work and remote control cable if used with unit.

- (3) Unbolt unit from mounting surface.

b. *Short distance movement.* Use a forklift and lift unit at base.

c. *Long distance movement.* Crate the air conditioner, providing adequate protection to grilles and control box. Refer to TM 38-250 for instruc-

tion in crate fabrication. Provide suitable blocking and tie downs to prevent unit from shifting during transfer.

2-8. Reinstallation After Movement

Reinstall the air conditioner as instructed in paragraph 2-5.

Section III. CONTROLS AND INSTRUMENTS

2-9. General

This section describes, locates, illustrates, and furnishes the operator, crew or organizational maintenance personnel sufficient information about the various controls and instruments for proper operation of the air conditioner.

2-10. Controls and Instruments


a. General. The purpose of controls and instruments and their normal readings are illustrated in figure 2-2.

b. High Pressure Switch. The high pressure switch, located at the upper left rear of the unit (fig. 1-3), is designed to sense line pressure from the compressor and will cutout at 445 psig (pounds per square inch gage). When the line pressure has reduced to 400 psig, the high pressure switch can be reset by pushing the reset button in, with a pencil like object, and holding it for approximately 2 to 3 seconds. There is a hole


in the upper rear panel, covered with a thin piece of rubber material directly in front of the switch for this reason.

c. Low Pressure Switch. The low pressure switch, located at the upper left rear of the unit (fig. 1-3), is designed to sense line pressure from the compressor and will cutout at 25 psig. When the line pressure has increased to 50 psig, the low pressure switch can be reset by pushing the reset button in, with a pencil like object, and holding it for approximately 2 to 3 seconds. There is a hole in the upper rear panel, covered with a thin piece of rubber material, directly in front of the switch for this reason.

d. Liquid Line Sight Glass. The sight glass (fig. 1-3) indicates dryness of the system. Moisture in the refrigerant is shown by the indicator turning from green to yellow. A shortage of refrigerant is indicated by flash gas in the sight glass.




A. CONTROLS



B. SIGHT GLASS

NOTE: PUSH LEVER TO RESET CIRCUIT BREAKER.



C. CIRCUIT BREAKER

Figure 2-2. Controls and instruments.

Section IV. OPERATING OF EQUIPMENT

2-11. General

a. The instructions in this section are published for the information and guidance of personnel responsible for operation of the air conditioner.

b. The operator must know how to perform every operation of which the air conditioner is capable. This section gives instructions on starting, stopping and operating details of the air conditioner. Since nearly every application presents a different problem, the operator may have to vary given procedure to fit the individual job.

2-12. Starting

a. Preparation for Starting.

(1) Perform necessary daily preventive maintenance services (para 3-6).

(2) Check electrical requirements (para 2-5d).

b. Starting.

(1) Cooling operation.

(a) Position thermostat for desired temperature.

(b) Place fan speed toggle switch in desired position.

(c) Place selector switch on cool position.

(d) For cooling with 100 percent recirculated air, close damper door.

(e) For cooling with fresh makeup air, open damper door and partially close intake grille damper.

(f) For cooling with fresh makeup air drawn through chemical biological filter unit when outdoor air is contaminated, close damper door and partially close intake grille damper.

(2) Heating operation.

(a) Position thermostat for desired temperature.

(b) Place fan speed toggle switch in desired position.

(c) Place selector switch on lo-heat or hi-heat position.

(d) For heating with 100 percent recirculated air, close damper door and open intake grille damper.

(e) For heating with fresh makeup air, open damper door and partially close "intake grille damper.

(f) For heating with fresh makeup air drawn through chemical biological filter unit when outdoor air is contaminated, close damper door and partially close intake grille damper.

(3) Ventilating operation.

(a) Place selector switch in ventilate position.

(b) Place fan speed toggle switch in desired position.

(c) For ventilating operation open damper door and close intake grille damper.

Caution: If during operation of the unit the fan motor stops because of a locked rotor condition, shut off unit immediately. Do not try to restart for at least ten minutes. See paragraph 3-24 for inspection and testing.

Note. If the air conditioner fails to start, open front access panel and push reset control on circuit breaker (fig. 2-2).

2-13. Stopping

Refer to figure 2-3. Place selector switch in "OFF" position.

2-14. Operation Under Usual Conditions

a. Refer to paragraph 2-12 and start the air conditioner.

b. Refer to figure 2-3, and operate the air conditioner.

2-15. Operation in Extreme Cold

a. *General.* The air conditioner is designed to operate at a minimum low temperature of 50°F. ambient. Be sure that all thermostatic controls and dampers are in working order.

b. *Electrical System.* Make sure the electrical system is free of ice and moisture.

Caution: Do not disturb the wiring during cold weather unless absolutely necessary. Cold temperatures make wiring and insulation brittle and are easily broken.

2-16. Operation in Extreme Heat

a. *General.* The air conditioner is designed to operate satisfactorily at temperatures up to 120°F.

b. *Ventilation.* Allow sufficient room around the air conditioner for adequate air circulation.

Note. Do not restrict the flow of air at the intake and discharge openings of the unit.

2-17. Operation in Dusty or Sandy Areas

Clean the condenser coil (para 3-5c) and evaporator coil (para 3-55c) weekly or more often if necessary. Clean the air conditioning filter (para 3-9b), fresh air inlet screen and condenser screen (para 3-20) daily.




Figure 2-3. Air conditioning unit operation.

2-18. Operation in Salt Water Areas

Wash the exterior of the unit with clean, fresh water at frequent intervals. Do not damage the electrical equipment during the cleaning operation. Coat exposed metal surfaces with rust proof-

ing material. Remove corrosion and paint the exposed metal surface.

2-19. Operation at High Altitudes

The air conditioner is designed to operate without special attention at altitudes up to 5,000 feet.

CHAPTER 3
OPERATOR AND ORGANIZATIONAL MAINTENANCE
INSTRUCTIONS

**Section I. OPERATOR AND ORGANIZATIONAL
MAINTENANCE TOOLS AND EQUIPMENT**

3-1. Special Tools and Equipment

No special tools or equipment are required by the operator or organizational maintenance personnel.

3-2. Basic Issue Tools and Equipment

Tools and repair parts issued with or authorized for the air conditioner are listed in appendix B of this manual.

Section II. LUBRICATION

3-3. General Lubrication Information

All bearings are permanently lubricated.

3-4 Detailed Lubrication Information

(Not applicable)

Section III. PREVENTIVE MAINTENANCE SERVICE

3-5. General

To insure that the air conditioner is ready for operation at all times, it must be inspected systematically so that defects may be discovered and corrected before they result in serious damage or failure. The necessary preventive maintenance services to be performed are listed and described in paragraphs 3-6 and 3-7. The item numbers indicate the "sequence of minimum inspection requirements. Defects discovered during operation of the unit will be noted for further correction, to be made as soon as operation has ceased. Stop operation immediately if a deficiency is noted during operation, which would damage the equipment if operation were continued. All deficiencies and shortcomings will be recorded together with corrective action taken, on DA Form 2404 (Equipment Inspection and Maintenance Worksheet) at the earliest possible opportunity.

3-6. Daily Preventive Maintenance

This paragraph contains the illustrated tabulated listing of the preventive maintenance services which must be performed by the operator. The item numbers are listed consecutively and indicate the sequence of minimum requirements. Refer to figure 3-1 for daily preventive maintenance services.

**3-7. Quarterly Preventive Maintenance
Services**

a. This paragraph contains an illustrated tabulated listing of the preventive maintenance services which must be performed by organizational personnel at quarterly intervals. A quarterly interval is equal to 3 calendar months, or 250 hours of operation, whichever occurs first.


b. The item numbers are listed consecutively and indicate the sequence of minimum requirements. Refer to figure 3-2 for quarterly preventive maintenance services.

PREVENTIVE MAINTENANCE SERVICES DAILY

TM 5-4120-273-15

REFRIGERATION UNIT

REDMANSON MODEL CV-6-1-15-60
and CV-6-3-08-400



ITEM		PAR REF
1	AIR FILTER. Wash and dry fresh air inlet screen.	3-20
2	AIR FILTER. Clean air conditioning filter. Spray with a light coat of oil.	3-9
3	CONTROLS. Check for damage and improper operation.	3-28
4	CONDENSER SCREEN. Clean condenser screen.	3-20

ME 4120-273-15/3-1 (1)

Figure 3-1 (1). Daily preventive maintenance services.



ITEM		PAR REF
5	<p><u>SIGHT GLASS.</u> Operate unit 15 minutes and check for moisture and low refrigerant charge. Yellow indicates moisture; bubbles and milky appearance indicates low charge.</p>	3-53
	<p><u>NOTE 1. REFRIGERANT SYSTEM.</u> Inspect refrigerant hoses and tubing for signs of leakage, abrasion, tearing, kinking, etc.</p> <p><u>NOTE 2. WIRING.</u> Look for broken or loose wires or connections.</p>	5-20

PREVENTIVE MAINTENANCE SERVICES QUARTERLY

TM 5-4120-273-15

REFRIGERATION UNIT

REDMANSON MODEL CV-6-1-15-60
and CV-6-3-08-400



ITEM		PAR REF
1	AIR FILTER. Clean and dry fresh air inlet screen. Replace damaged screen.	3-20
2	SIGHT GLASS. Check for damaged or broken glass. Check for full condition of unit.	3-53
3	FAN. Tighten loose mounting. Check for damage. Replace damaged fan.	3-24

ME 4120-273-15/3-2 ①

ITEM		PAR REF
4	AIR FILTER. Clean air conditioning filter. Replace damaged filter. Spray with a light coat of oil.	3-9, 3-58
5	<u>CONTROLS</u> . Check for damage and improper operation.	3-28
6	<u>CONDENSER AND EVAPORATOR COILS</u> . Check coil fins for dust, dirt, or foreign matter. Check all tubing connections for signs of leaks or other defects.	3-55
	<p><u>NOTE 1. WIRING</u>. Look for broken or loose wires or connections.</p> <p><u>NOTE 2. REFRIGERANT SYSTEM</u>. Inspect refrigerant hoses and tubing for signs of leakage, abrasion, tearing, kinking, etc.</p>	

ME 4120-273-15/3-2 ②

Figure 3-2 (2)-Continued.

Section IV. OPERATOR'S MAINTENANCE

3-8. General

Instructions in this section are published for the information and guidance of the operator to maintain the air conditioner.

3-9. Air Filter Inspection and Service

a. Inspection.

- (1) Remove intake grille (fig. 3-5).
- (2) Remove air filter (fig. 3-3).


- (3) Inspect filter for dirt.

b. Service.

- (1) Wash filter in hot water or approved solution.
- (2) Dry with compressed air.
- (3) Spray with light coat of oil.

3-10. Panels, Grilles and Screens Inspection

Refer to figure 3-4 and 3-5 and inspect panels, grilles and screens.



ME 4120-273-15/3-3

Figure 3-3. Air filter removal and installation.

Section V. TROUBLESHOOTING


3-11. General

This section provides information useful in diagnosing and correcting unsatisfactory operation or failure of the air conditioner and its components. Each trouble symptom stated is followed by a list of probable causes. The possible remedy recommended is described opposite the probable cause.

Any trouble beyond the scope of organizational maintenance shall be reported to direct support maintenance.


3-12. Compressor Fails to Start

Probable cause	Possible remedy
Selector switch improperly set	Set switch to "COOL" position. (fig. 2-2).



ME 4120-273-15/3-4

Figure 3-4. Fresh air inlet screen, chemical and biological inlet cover, cond. fan guard, and condenser coil grille removal and installation.



ME 4120-273-15/3-5

Figure 3-5. Discharge grille, intake grille, front access panel and cover panel removal and installation.

Probably cause	Possible remedy
Circuit breaker contacts open	Reset circuit breaker (fig. 2-2).
Contacts of high or low pressure switch open	Push reset button to reset pressure switch. (fig. 1-3), hold 2-3 seconds.

3-13. Compressor Starts But Goes Out on Overload

Probable cause	Possible remedy
Condenser fan not operating	Check motor and motor leads.
Condenser coil blocked -----	Clean condenser coil (para 3-56c).

3-14. Little or no Heating Capacity

Probable cause	Possible remedy
Selector switch improperly set	Set switch to proper setting. (fig. 2-3).
Air movement over evaporator insufficient	Clean the air filter, evaporator coil (para 3-9b, and 3-55c).
Improper electrical connections	Check all heater wiring (para 5-22).

Probable cause	Possible remedy
Burned out heater element(s)	Replace heater element (s) (fig. 2-11 or 3-12).

3-15. Suction Pressure Inadequate

Probable cause	Possible remedy
Inadequate air flow across evaporator coil	Check fan for tightness on shaft. Clean evaporator coil and filter (para 3-55c and 3-9b).
Air temperature in conditioned space excessively low	Reset thermostat (fig. 2-3).

3-16. Low Suction and Discharge Pressure

Probable cause	Possible remedy
Lack of refrigerant -----	Check sight glass for appearance of flash gas. (fig. 3-14). Report low refrigerant charge to direct support maintenance.
Clogged air filter -----	Clean filter (para 3-9b).

Section VI. HOUSING ASSEMBLY

3-17. General

The air conditioner is constructed with removable aluminum panels. The front access panel provides access to the junction box, control panel, and access fittings. A discharge grille protects the evaporator and controls the direction of discharge of conditioned air. The intake grille protects the air conditioning filter and regulates the amount of air returned to the unit. The condenser coil grille and fan guard protects the condenser coil and fan. A fresh air inlet screen permits the entry of outside air and is controlled by the damper door with the control spring and chain. The cover panel covers the top of the unit.

Warning: Disconnect the air conditioner from the power source before performing any maintenance on the components of the unit.

3-18. Top Panel, Discharge Grille, Intake Grille, and Front Access Panel

a. Removal. Refer to figure 3-4 and 3-5 remove panels and grilles.

b. Inspection and Repair. Inspect for minor dents and cracked or chipped paint. Repair minor damage, repaint.

c. Installation. Refer to figures 3-4 and 3-6 to install panels and grilles.

3-19. Canvas Condenser Cover

a. Removal. Remove retaining hardware and lift off cover. Refer to figure 1-3.

b. Inspection and Repair. Inspect cover for rips or tears. Repair with waterproof tape.

c. Installation. Place cover in position and secure with retaining hardware.

3-20. Fresh Air Inlet Screen, Chemical and Biological Inlet Cover, Condenser Fan Guard and Condenser Coil Grille

a. Removal. Refer to figure 3-4 and 3-5, and remove fresh air inlet screen, CB (chemical and biological) inlet cover, condenser fan guard, and condenser coil grille.

b. Installation. Install the fresh air inlet screen, CB inlet cover, fan guard, and condenser coil grille and screen. Refer to figures 3-4 and 3-5.

Section VII. GENERAL ORGANIZATIONAL MAINTENANCE

INSTRUCTIONS

3-21. Compressor (fig. 3-6)

Test for continuity across motor windings with multimeter set on OHMS. Refer to the wiring diagrams figure 1-5 to establish points of continuity.

3-22. Evaporator Fan and Inlet Ring

a. General. Models CV-6-1-15-60 and CV-6-3-08-400 are equipped with a centrifugal inclined blade evaporator fan. The fan reduces excessive vibration and noise.

b. *Removal.* Refer to figure 3-7 and remove inlet ring and evaporator fan.

c. *Installation.* Refer to figure 3-7 and install inlet ring and evaporator fan.

3-23. Condenser Fan

a. *Removal.* Refer to figure 3-3 and remove condenser fan.

b. *Inspection.* Inspect unit for dents, cracks, bends and chipped paint.

c. *Installation.* Refer to figure 3-8, and install condenser fan.


3-24. Fan Motor

a. *Removal.* Refer to figure 3-9 and remove motor.

b. *Inspection and Testing.*

(1) Inspect for dents, cracks and broken or damaged leads.


(2) Test for continuity across windings with a multimeter set on OHMS. Refer to the wiring diagram figure 1-5 to establish points for continuity.



NOTE: TAG AND DISCONNECT ELECTRICAL LEADS, UNSOLDER AND DISCONNECT TUBING AS NECESSARY.

ME 4120-273-15/3-6

Figure 3-6. Compressor, pressure relief valve, access fittings, liquid line solenoid valve, filter-drier, removal and installation.



ME 4120-273-15/3-7

Figure 3-7. Evaporator fan, inlet ring and thermostat sensing bulb removal and installation.

c. Installation. Refer to figure 3-9 and install motor.

3-25. Capacitors (Model CV-6-1-15-60 only)

a. Removal. Refer to figure 3-10 and remove capacitors.

b. Inspection and Testing.

(1) Inspect for cracked case and broken or damaged contacts.

(2) Use a multimeter set on OHMS. Refer to wiring diagram (fig. 1-5). A full reading should be made with a steady return to zero.

c. Installation. Refer to figure 3-10 and install capacitors.

3-26. Fan Motor Relays

Note. Model CV-6-1-15-60 has one fan motor relay. Model CV-6-3-08-400 has two fan relays.

a. General. Fan motor relays are located in the top of the unit, figures 3-11 and 3-12. A fan motor relay starts the fan motor and controls the high and low speeds.

b. Removal. Refer to figures 3-11 and 3-12 and remove fan motor relay(s).

c. Inspection and Testing.


(1) Inspect for pitted or burned contacts.

(2) Test for continuity across coil with multimeter set on OHMS. Refer to wiring diagram figure 1-5 to establish relay(s).

d. Installation. Refer to figures 3-11 and 3-12 and install relay(s).

3-27. Diode Surge Protector (Model CV-6-3-08-400 only)

a. Removal. Refer to figure 3-11 and remove diode surge protector.



ME 4120-273-15/3-8

Figure 3-8. Condenser fan removal and installation.

b. Inspection. Inspect for cracked or broken case.

c. Testing. Test for continuity across protector. Refer to figure 1-5 to establish points for continuity.

d. Installation. Refer to figure 3-11 and install diode surge protector.

3-28. Control Box

a. General. The control box houses the selector switch, thermostat, and hi-lo fan speed switch. It is mounted on the junction box. The selector switch is a manually operated, five-position switch. Automatic control of both the heating and cooling cycles is provided by the thermostat. The hi-lo fan speed switch controls the fan speed. The control box may be used in a remote position by utilizing a blockoff plate and remote control cable. Refer to paragraph 2-5e(2).

b. Inspection. Inspect for loose knobs and switched.

3-29. Selector Switch

a. Removal. Refer to figure 2-1(1) and remove selector switch.

b. Testing. Test for continuity across coils using multimeter set on OHMS. Refer to wiring diagram figure 1-5 to establish points of continuity.

c. Installation. Refer to figure 2-1 and install selector switch.

3-30. Hi-lo Fan Speed Switch


a. Removal. Refer to figure 2-1 and remove fan speed switch.

b. Testing. Test for continuity. Refer to wiring diagram figure 1-5 to establish points of continuity.

c. Installation. Refer to figure 2-1 and install fan speed switch.

3-31. Thermostat

a. Removal. Refer to figure 2-1 and remove thermostat.



NOTE: TAG AND DISCONNECT ELECTRICAL LEADS AS NECESSARY.

ME 4120-273-15/3-9

Figure 3-9. Fan motor removal and installation.

b. Testing. Test for continuity using multimeter set on OHMS. Refer to wiring diagram figure 1-5 to establish points of continuity.

c. Installation. Refer to figure 2-1 and install thermostat.

3-32. Junction Box

a. Removal. Refer to figure 3-13, and remove junction box.

b. Installation. Refer to figure 3-13 and install junction box.

3-33. Fuses

a. Removal. Refer to figure 3-13 and remove fuses from holders located in junction box.

b. Inspection and Testing.

(1) Inspect for cracked or broken case.

(2) Test for continuity through fuse with multimeter set on OHMS. Refer to the wiring diagram figure 1-5 to establish points of continuity.

c. Installation. Install fuse in fuse holder. Refer to figure 3-13.

3-34. Transformer

a. Removal. Refer to figure 3-13 and remove transformer.

b. Inspection and Testing.

(1) Inspect for broken or cracked case and broken or damaged contacts.


(2) Test for continuity through both primary and secondary sides with multimeter set on OHMS. Refer to wiring diagram figure 1-5 to establish points of continuity.

c. Installation. Refer to figure 3-13 and install transformer.

3-35. Circuit Breaker

a. General. The circuit breaker protects the compressor from continuous overcurrent and short circuits. It is located in the lower right corner of the junction box. Refer to figure 2-2 for reset procedure.

b. Removal. Refer to figure 3-13 and remove the circuit breaker.



NOTE: TAG AND DISCONNECT ELECTRICAL LEADS AS NECESSARY.

ME 4120-273-15/3-10

Figure 3-10. Capacitor removal and installation.

c. Testing. Test the circuit breaker for continuity with a multimeter set on OHMS. Refer to the wiring diagram figure 1-5 for points to establish continuity.

d. Installation. Refer to figure 3-13 and install circuit breaker.

3-36. Phase Sequence Relay (Model CV-6-3-08-400 only)

a. General. The phase sequence relay prevents operation of the unit unless the phase sequence is correct and the fan and compressor motor rotate in the proper direction.

b. Removal. Refer to figure 3-13 and remove phase sequence relay.

c. Inspection and Testing.

(1) Inspect for cracked or broken casing.

(2) Test for continuity with multimeter set on OHMS. Refer to wiring diagram figure 1-5 to establish points of continuity.

d. Installation. Refer to figure 3-18 and install the phase sequence relay.

3-37. Compressor Motor Relay and Electrical Heater Relay

a. General. Both relays are located in the junction box, figure 3-13. A motor relay starts the compressor motor and a heater relay is connected to the electrical heaters.

b. Removal. Refer to figure 3-13 and remove relays.

c. Inspection and Testing.

(1) Inspect for pitted or burned contacts.

(2) Test for continuity across coil with multimeter set on OHMS. Refer to wiring diagram figure 1-5 to establish points of continuity.

d. Installation. Refer to figure 3-13, and install relays.

3-38. Rectifier

a. General. The rectifier changes alternating current to direct current.

b. Removal. Refer to figure 3-13 and remove rectifier.

c. Inspection and Testing.

(1) Inspect for cracked or broken casing and burned or damaged contacts.

(2) Test for continuity with multimeter set on OHMS. Refer to wiring diagram figure 1-5 to establish points of continuity.

d. Installation. Refer to figure 3-13, and install rectifier.

3-39. Heater Elements

a. General. The electrical resistance heaters are mounted directly behind the evaporator coil. These heaters provide the heat called for by the thermostat to maintain the required temperature of the conditioned air. The heaters provide two ranges of heating and are manually controlled by placing the selector switch in the proper position (LO-HEAT or HI-HEAT) to maintain the required temperature.

b. Removal. Refer to figure 3-11, 3-12 and remove the heater elements.

c. Inspection and Testing.


(1) Inspect for broken or damaged elements.

(2) Test for continuity across elements with multimeter set on OHMS. Refer to wiring diagram figure 1-5 to establish points of continuity.

d. Installation. Refer to figures 3-11, 3-12 and install heating elements.


3-40. High Pressure Switch

a. General. The high pressure switch prevents the compressor from operating if the head pressure exceeds 445 psig (fig. 3-14).



ME 4120-273-15/3-11

Figure 3-11. Model CV-6-3-08-400 heating element, expansion value; fan motor relay, equalizer solenoid valve, pressure regulating valve, diode surge protector, heater thermostat, removal and installation.



NOTE: TAG AND DISCONNECT ELECTRICAL LEADS, UNSOLDER AND DISCONNECT TUBING AS NECESSARY.

ME 4120-273-15/3-12

Figure 3-12. Model CV-6-1-15-60 heating element, expansion valve; fan motor relay, equalizer solenoid valve, pressure regulating valve, heater thermostat, removal and installation.

b. Inspection and Testing.

- (1) Inspect for broken or damaged leads and kinked or broken capillary tubing.
- (2) Test for continuity across switch with multimeter set on OHMS. Refer to wiring diagram figure 1-5 to establish points of continuity.

3-41. Low Pressure Switch

a. General. The low pressure switch prevents the compressor from operating if the suction pressure drops below 25 psig (fig. 3-14).


b. Inspection and Testing.

- (1) Inspect for broken or damaged leads and kinked or broken capillary tubing.
- (2) Test for continuity across switch with multimeter set on OHMS. Refer to wiring diagram figure 1-5 to establish points of continuity.

3-42. Fan Speed Pressure Switch (fig. 3-15)

- a.* Inspect for broken or damaged contacts.
- b.* Test for continuity with multimeter set on OHMS. Refer to wiring diagram figure 1-5 to establish points of continuity.

NOTE: TAG AND DISCONNECT ELECTRICAL LEADS AS NECESSARY.



ME 4120-273-15/3-13

Figure 3-13. Junction box, fuses, time delay relay, terminal board, heater relay, compressor motor relay, circuit breaker and phase sequence relay, removal and installation.


3-43. Outside Air Thermostat

a. General. The outside air thermostat is mounted to the rear housing of the air conditioner. It prevents the compressor from being started when the outside temperature is below 50°F. This prevents the unit from being operated at a time when low condensing and suction pressures will hamper system operation. (fig. 3-14).


b. Removal. Remove outside air thermostat as illustrated on figure 3-14.

c. Testing. Test the thermostat for continuity with a multimeter set on OHMS. Refer to the wiring diagram, figure 1-5 for the points to establish continuity.


d. Installation. Refer to figure 3-14 and install outside air thermostat.



A. LOW PRESSURE AND HIGH PRESSURE SWITCH



B. SIGHT GLASS.




C. OUTSIDE AIR THERMOSTAT.

NOTE: TAG AND DISCONNECT ELECTRICAL LEADS, UNSOLDER AND DISCONNECT TUBING AS NECESSARY.

ME 4120-273-15/3-14

Figure 3-14. High pressure switch, low pressure switch, sight glass and outside air thermostat, removal and installation.



NOTE: TAG AND DISCONNECT ELECTRICAL LEADS, UNSOLDER AND DISCONNECT TUBING AS NECESSARY.

MEC 4120-273-15/3-15

Figure 3-15. Fan speed pressure switch, removal and installation.

3-44. Electric Heater Thermostat

a. General. The electric heater thermostat (fig. 3-11) is a protective device which prevents the heater elements from overheating.

b. Removal. Refer to figures 3-11, 3-12 and remove electrical heater thermostat.

c. Testing. Test for continuity with multimeter set on OHMS. Refer to wiring diagram figure 1-5 to establish points of continuity.

d. Installation. Refer to figures 3-11, 3-12 and install electric heater thermostat.

3-45. Refrigerant Piping

a. Inspection. Inspect refrigerant piping for kinking, holes and unsatisfactory welding.

b. Testing.

(1) *Halide torch leak detector.* The preferred method of field testing for leaks in the refrigeration system is by using a halide torch. Operate the air conditioner (para 2-12) and pass the exploring tube slowly over all sweat fittings, mechanical couplings, and valves. If refrigerant is leaking from the system the flame of the torch will change from blue to green when the leak is small. If the leak is large, the flame will be a deep blue

with a reddish tip; or the flame may be entirely extinguished.

(2) *Soap solution method.* Operate the air conditioner (para 2-12). Brush all points of possible leakage with soap solution. Watch for bubbles. Follow a definite sequence so that all joints will be thoroughly tested. Wipe the solution from all joints and mark any spot where leakage occurs.

3-46. Liquid Line Solenoid Valve

a. General. The liquid line solenoid valve (fig. 3-6) is automatically actuated by the thermostat and controls the flow of refrigerant to the evaporator coil.

b. Inspection. Inspect for cracked or broken casing and damaged or broken terminals.

c. Testing. Test for continuity across coil with multimeter set on OHMS. Refer to wiring diagram (fig. 1-5) to establish points of continuity.

3-47. Equalizer Solenoid Valve

a. General. The equalizer solenoid valve is actuated by the ON/OFF switch and serves to equalize system pressures during shutdown, figures 3-11, 3-12.

b. Inspection. Inspect for cracked or broken casing and damaged or broken terminals.

c. Testing. Test for continuity across coil with multimeter set on OHMS. Refer to wiring diagram (fig. 1-5) to establish points of continuity.

3-48. Access Fittings

a. General. The two access fittings (suction line and discharge line) provide access to the refrigerant system figure 3-6.

b. Inspection. Inspect for cracked casing or damaged threads.

3-49. Pressure Relief Valve

a. General. Pressure relief valve (fig 3-6) is located on a tee just below the filter-drier. The pressure relief valve protects the refrigerant system from excessive pressure.

b. Inspection. Inspect for cracked or broken casing.

3-50. Pressure Regulating Valve

The evaporator pressure regulating valve (figs. 3-11, 3-12) regulate refrigerant pressure in the evaporator to prevent coil freeze up. The valve is preset to establish a minimum pressure in the evaporator of 58 psig.

3-51. Expansion Valves

A one-half ton expansion valve controls the rate of flow of liquid refrigerant into the evaporator coil during the cooling cycle of operation (fig. 3-11, 3-12). Another one-half ton expansion (fig. 3-11, 3-12) valve functions when the unit is in the bypass cycle of operation.

3-52. Filter-Drier

The filter-drier prevents the accumulation of moisture and contaminants within the refrigerant tubing. The filter-drier must be replaced each time the system is exposed to the atmosphere.

3-53. Sight Glass

a. General. The sight glass indicates the refrigerant moisture content. A shortage of refrigerant is indicated by flash gas in the sight glass (fig. 3-14).

b. Inspection. Inspect for excessive moisture in refrigerant. Excessive moisture is indicated by the changing of the color code from green to yellow.

3-54. Liquid Receiver (fig. 3-6)

Inspect for cracks or broken casing.

3-55. Evaporator Coil (fig. 3-16)

a. General. The evaporator coil is mounted on the casing directly behind the discharge grille. The coil must be removed from the air conditioner for repair or replacement. The mixture of fresh air and n-circulated air is passed through the evap-

orator coil and forced into the conditioned air space by the evaporator fan.

b. Testing. Refer to paragraph 3-45b and test with halide torch for refrigerant leaks.

c. Inspection and Cleaning.

(1) Inspect coil for bent fins, cracks or breaks. Solder any cracks and straighten bent fins with coil comb or thin nose pliers.

(2) Clean coil with low pressure compressed air.

3-56. Condenser Coil

a. General. The condenser coil, refer to figure 3-4, is mounted on the bottom rear of the casing, directly beneath the condenser fan. The coil must be removed from the air conditioner for repair or replacement. The coil is made from copper tube and aluminum fin and is of the fin-tube configuration.

b. Testing. Refer to paragraph 3-45b and test with halide torch for refrigerant leaks.

c. Inspection and Cleaning.

(1) Inspect coil for bent fins, cracks or breaks. Solder any cracks. Straighten bent fins with coil comb or thin nose pliers.


(2) Clean coil with low pressure compressed air.

3-57. Drain Tubes

a. Removal. Refer to figure 3-6 and remove drain tubes.

b. Inspection and Servicing.

(1) Inspect tubes for obstructions and loose connections.



NOTE: UNSOLDER TUBING AS NECESSARY.

MEC 4120-273-15/3-16

Figure 3-16. Evaporator coil, removal and installation.

(2) Clean tubes with low pressure, compressed air.

c. Installation. Refer to figure 3-6 and install drain tubes.

3-58. Air Filter

a. *Removal.* Refer to figure 3-3 and remove air filter.

b. *Installation.* Refer to figure 3-3 and install air filter.

CHAPTER 4
DIRECT AND GENERAL SUPPORT AND DEPOT
MAINTENANCE INSTRUCTIONS

Section I. GENERAL

4-1. scope

These instructions are published for the use of direct and general support and depot maintenance personnel maintaining the Redmanson Model CV-6-1-15-60 and CV-6-3-08-400 air conditioners. They provide information on the maintenance of the units, which is beyond the scope of tools, equipment, personnel, or supplies normally available to using organizations.

4-2. Record and Report Forms

For record and report forms applicable to direct and general support and depot maintenance, refer to TM 38-750.

Note. Applicable forms, excluding standard Form 46 which is carried by the operator, shall be kept in a canvas bag mounted on equipment.

Section II. DESCRIPTION AND TABULATED DATA

4-3. Description

A general description of the air conditioners, the location of the identification and instruction plates, and information on the differences in models are contained in the operator and organizational maintenance manual. Direct and general support and depot repair and maintenance instruction are described in appropriate sections of this manual, see paragraph 1-3.

support and depot maintenance personnel. Wiring schematics figure 1-5 and practical wiring diagram figure 1-6.

b. Capacities.

Refrigerant system ----- Refrigerant 22
 Refrigerant charge ----- .39 oz.
 Compressor crankcase ----- 17 oz. refrigerant compressor lubricating oil—FED VV-L-825 Type IV.

4-4. Tabulated Data

a. General. This paragraph contains all the overhaul data pertinent to direct and general

c. Compressor. Both air conditioner models CV-6-1-15-60 and CV-6-3-08-400 have hermetically sealed compressors. If failure occurs compressor should be replaced.

CHAPTER 5

GENERAL MAINTENANCE INSTRUCTIONS

Section I. SPECIAL TOOLS AND EQUIPMENT

5-1. Special Tools and Equipment

No special tools or equipment are required to perform field and depot maintenance on the air conditioners.

5-2. Specially Designed Tools and Equipment

No specially designed tools or equipment are required to perform field and depot maintenance on the air conditioners.

Section II. TROUBLESHOOTING

5-3. General

This section provides information useful in diagnosing and correcting unsatisfactory operation or failure of the air conditioner or any of its components. Each trouble symptom stated is followed by a list of probable causes. The possible remedy recommended is described opposite the probable cause.

5-4. Compressor Will Not Start

Probable cause	Possible remedy
Power off -----	Check relays (para 3-37) fuses (para 3-33) and wiring, (para 5-22) and circuit breaker. (para 3-35).
Thermostat set too high ----	Adjust thermostat (fig. 2-2).
Loose electrical connections or faulty wiring	Tighten connections. Check wiring and rewire if necessary (para 5-22).
Compressor motor burned out	Check and replace compressor (para 5-17) if defective.
High-low pressure switch defective	Replace high-low pressure switch (para 6-6 and 6-7) .
Thermostat defective -----	Replace thermostat (para 3-31).

5-5. Compressor Cycles Intermittently

Probable cause	Possible remedy
Low pressure switch erratic in operation	Check tubing to switch, may be clogged. Also check setting of switch. It may be too high.
Insufficient refrigerant in system	Add refrigerant (para 5-21d).

Probable cause	Possible remedy
Dirt or restriction in tubing to pressure switch	Check and clean tubing.
Faulty pressure switch ----	Repair or replace pressure switch (para 6-6 or 6-7).
Condenser capacity reduced by refrigerant over-charge accompanied by high discharge pressure	Remove excess refrigerant (para 5-21b).
Air in system -----	Evacuate system (para 5-21c) .

5-6. High Discharge Pressure

Probable cause	Possible remedy
Condenser fan inoperative	--Check condenser fan motor (para 3-24).
Too much refrigerant ----	Remove excess refrigerant (para 5-21b).
Air in system -----	Evacuate system (para 5-21c).

5-7. Low Discharge Pressure

Probable cause	Possible remedy
Suction line partially obstructed	Clean the Line.

5-8. Flooding

Probable cause	Possible remedy
Defective or improperly set expansion valve	Reset expansion valve (para 6-12c).

5-9. Low Suction Pressure

Probable cause	Possible remedy
Insufficient refrigerant in system	Add refrigerant (para 5-21d) .
Excessive superheat -----	Reset expansion valve (para 6-12c).

5-10. Compressor Noisy

Probable cause	Possible remedy
Insufficient clearance between rotating compressor parts	Replace compressor (para 5-17).
Bearings worn -----	Replace compressor (para 5-17).
Slugging due to floodback of refrigerant	Check setting of expansion valve. Check thermal bulb.

5-11. Hissing

Probable cause	Possible remedy
Insufficient refrigerant flow through expansion valves	Add refrigerant (para 5-21d).
Clogged liquid line filter -----	Clean filter (pars 3-9b).

5-12. Cold Compressor

Probable cause	Possible remedy
Liquid carrying over from evaporator or through quench valve	Check refrigerant charge and expansion valves. (para 3-51).

5-13. Cylinders and Crankcase Sweating

Probable cause	Possible remedy
Floodback -----	Check refrigerant charge and expansion valves. (pars 3-51).

5-14. High Crankcase Temperature

Probable cause	Possible remedy
Excessive superheat -----	Reset expansion valve (para 6-12c).
Liquid line filter clogged -----	Replace filter (fig. 3-3).

5-15. Little or no Heating Capacity

Probable cause	Possible remedy
Wiring and wiring harness defective	Replace wire or wiring harness (para 5-22).

5-16. System losing Cooling Capacity

If the system is losing cooling capacity, or is in some way not functioning properly, a check of system operating pressure will frequently lead to cause of malfunction. Install pressure gages on access fittings of suction and discharge lines and expose gages to system pressure. Compare gage readings with normal ranges of systems pressures listed in table 1.

Table 5-1. Normal Operating Pressures.

Return air to unit	90°F/75°F WB		80°F/67°F WB
Outdoor ambient temperature	120°F	125°F	95°F
GAGE PRESSURE			
Suction	85-95	87-97	70-80
Discharge	287-395	406-416	253-263

Section III. REMOVAL AND INSTALLATION OF MAJOR COMPONENTS OR AUXILIARIES

5-17. Compressor

a. General The sole purpose of the compressor is to raise the pressure of refrigerant gas from evaporator pressure to condensing pressure. The function of the compressor is to deliver refrigerant to the condenser at a pressure and temperature at which the condensing process can readily be accomplished. The motor/compressor is a hermetically sealed unit and is not repairable in the field. An inoperative compressor is usually due to a mechanical failure causing the compressor to freeze, control failure, or a motor burnout. If the motor/compressor is mechanically frozen or there has been a motor burnout, the compressor must be removed and replaced. When the motor of a hermetic compressor fails, high temperatures may develop within the compressor causing a breakdown of the oil and refrigerant, resulting in formation of acid, moisture, and sludge. All these are extremely corrosive and must be flushed from

the system. Repeated burnouts will occur if all of the contaminants are not removed.

b. Removal.

- (1) Remove front access panel, reference paragraph 3-18 and pullout the junction and control box, reference paragraph 3-28.
- (2) Discharge refrigerant from system reference paragraph 5-21b.
- (3) Remove condenser coil, reference paragraph 6-5.
- (4) Refer to figure 3-6 and remove compressor through rear of unit.

c. Installation.

- (1) Refer to figure 3-6 and install compressor.
- (2) Refer to paragraph 6-5 and install the condenser coil.
- (3) Evacuate and recharge the unit, reference paragraph 5-21.

(4) Install junction and control box, reference paragraph 3-28.

(5) Install front access panel, reference paragraph 3-18.

Section IV. GENERAL REPAIR INSTRUCTIONS

5-18. General

The air conditioner, after it is started, is automatic in operation. The relationship of the automatic components, controls, and instrument, is explained in the operation analysis for maintenance of the air conditioner (para 5-17). A refrigerant flow diagram (fig. 5-1) and practical wiring diagram (fig. 1-5) are included to assist in the maintenance of the electrical components, wiring harness, wire leads, and refrigerant components.

Figure 6-1. Refrigerant flow diagram
(Located in back of manual)

Warning: Disconnect the air conditioner from the power source before performing any maintenance on the components of the unit. Failure to observe this warning may result in injury to personnel and damage to the equipment.

5-19. Analysis of Operation

a. General. The type and degree of air conditioning provided by the unit is controlled by a five-position selector switch (fig. 2-3), a thermostat (fig. 2-3), and a hi-lo fan speed switch (fig. 2-3).

(1) When the selector switch is in the "OFF" position the entire circuit is dead.

(2) Placing the selector switch in the HI-HEAT position actuates the fan motor with all six heater elements being under the control of the thermostat. If the air temperature falls below the set point of the thermostat, the control contacts close energizing the evaporator contactor which supplies power to the heaters through the normally closed contacts of the evaporator heater thermostat.

(3) Moving the selector switch to the LO-HEAT position presents the same control sequence but reduces the heating capacity of the unit by supplying power to three of the heater elements only.

(4) The fan motor starts when the selector switch is placed in the "VENTILATE" position.

(5) In the "COOL" position, the fan motor is in operation and the compressor motor contac-

Warning: Avoid bodily contact with liquid refrigerant and avoid inhaling refrigerant gas. Be especially careful that the R-22 refrigerant does not contact the eyes. In case of refrigerant leaks ventilate area immediately.

tor is energized through the contacts of the thermostatic switch. The energized contactor supplies power to the compressor through the normally closed contacts of the circuit breaker and the compressor overload protector. After the fan motor and compressor have started, the operation of the refrigeration unit is controlled by the thermostat. Sensing a rise in the air temperature above the set point, the thermostat opens its contacts, de-energizing the liquid line solenoid valve. This positions the valve for cooling service. Sensing a fall in the air temperature below the set point, the contacts of the thermostat close, energizing the valve. This positions the system for the bypass service.

(6) The HI-LO fan speed switch controls the speed of the fan motor and the fans.

b. Cooling Cycle of Operation.

(1) The fan motor and compressor run continuously whether the thermostat is calling for cooling or not, when the unit is set to operate on the cooling cycle of operation. This feature provides a constant electrical load thus preventing voltage fluctuations within the system.

(2) Bypass cycle of operation. When the conditioned air temperature falls below the thermostat setting, the circuit which controls the solenoid valve is energized causing:

(a) The hot gas bypass line to flow discharge gases through the evaporator pressure regulator, bypassing a major part of the compressed refrigerant vapor directly back to the suction side of the compressor.

(b) To prevent frost from forming on the evaporator, a back pressure regulating valve is provided to prevent the suction pressure from decreasing to a pressure of 58 psig which corresponds to a temperature of 32°F.

d. *Heating Operation.* Placing the selector switch in the LO-HEAT position actuates half of the evaporator heaters mounted, in the conditioned air stream, directly behind the evaporator coil. When the selector switch is placed in the HI-HEAT position, the remaining heaters are energized, providing maximum heating capacity.

5-20. General Repair Procedures

a. If the refrigerant system must be opened for repair or replacement of parts, first discharge the

refrigerant from the system. Refer to paragraph 5-21b for instructions for discharging the system.

b. After discharging the system allow the tubing to warm to the ambient temperature before opening the system; this delay will help prevent the formation of condensation on the inside wall of the tubing. Plug or cap all openings as a part is removed to minimize the entry of dirt and moisture into the system.

c. Use a silver solder on all soldered connections. Silver solder (or equivalent) with a 50 percent silver capacity and a melting point of approximately 1,300°F. is recommended. Continually pass dry nitrogen through the tubing or connections being soldered to prevent formation of harmful copper oxides.

5-21. Servicing the Refrigerant System

a. *Testing Refrigerant System for Leaks.* Refer to paragraph 3-45b, and test refrigerant system for leaks.

b. *Releasing Refrigerant for Service.* Release refrigerant slowly to a well vented atmosphere. Adjust the release so that a vaporized discharge is made to avoid loss of refrigerant oil.

c. *Evacuating the Refrigerant System.*

(1) *General.* Opening the system to the atmosphere will cause entry of air and moisture into the system. After any servicing operation, when the system is opened, the entire system should be evacuated before a recharging with refrigerant.

(2) *Evacuation.*

(a) Connect hose assemblies of evacuation gage manifold to discharge valve access fitting and to the suction access fitting of unit, reference figure 3-6.

(b) Connect vacuum pump to center hose of gage manifold.

(c) Evacuate pump down unit to 100 microns.

(d) Break vacuum by admitting refrigerant, para 5-21d (1).

Caution: Do not use the compound gauge as an indicator for satisfactory vacuum pressure.

d. *Charging the Refrigerant System.* There are two preferred methods used to charge the refrigerant system.

(1) *Sight glass method.*

(a) Evacuate the system, paragraph 5-21.

(b) Remove cap from suction tube charging valve.

(c) Connect hose from refrigeration charging hookup loosely to suction tube charging valve. Open refrigerant drum shutoff valve

slightly to purge hose. Tighten connection at charging valve. Open shutoff valve and backseat charging valve.

(d) Refrigerant drum must be in up-right position to allow only gaseous refrigerant to enter system.

(e) Start unit.

(f) To speed up charging, set refrigerant drum in warm water. Never use a heating torch for this purpose.

(g) Observe sight glass (fig. 3-13) at the time of charging, and even though flash gas is apparent, shutoff refrigerant flow and observe sight glass for a period of 10 to 20 minutes. If at the end of this time period the sight glass is not free from the flash gas, admit a small amount of charge and observe for the same time period. Repeat this operation until sight glass is clear.

(h) Frontseat charging valves and close refrigerant drum shutoff valve. Stop the unit and disconnect manifold hoses from charging valves, install caps.

(2) *Weight method.* With this method you are charging the unit with liquid.

(a) Evacuate the system, paragraph 5-21.

(b) Connect a bottle of refrigerant-22 to discharge high side access fitting, figure 3-6.

(c) Weight refrigerant bottle.

(d) Invent charging cylinder and open valve on refrigerant bottle and allow refrigerant to flow through system.

(e) Periodically weigh bottle until it is lighter by amount needed in system, must be exact amount.

Caution: Total amount of charge must be exactly 53 oz.

5-22. Wiring Harness and Wire Leads

a. *General.* The electrical circuits in the refrigeration unit are completed by individual wire leads or by leads laced or enclosed to form a wiring harness. When testing, repairing, or replacing the individual wires or Harnesses refer to the wiring diagram (fig. 1-5).

b. *Inspection.* Inspect the wiring insulation for cracks and frayed material. Pay particular attention to the wires passing through holes in the frame or over rough edges. If inspection reveals a broken or cut wire, and the break in the wire is exposed, the wire must be repaired (d below). If the break in a wire is in a harness or inaccessible area, replace wire (e below).

c. *Testing.* Test a wire for continuity by disconnecting each end from the component or components to which it is connected. Touch the test

probes of a multimeter to each end of the wire. If continuity is not indicated, the wire is defective and must be repaired or replaced.

d. Repair. Remove the insulation on the wire to expose one-half inch of bare wire at both ends of the break. Twist bare wire together and solder the connection. Cover the repaired break with electrical tape and friction tape. Do not leave any bare wire exposed. If a terminal lug breaks off a wire, replace it, using an exact duplicate terminal lug.

e. Replacement. Replace a wire by disconnecting it from the component or components and remove the wire. Install a new wire and connect it to the component or components. If a broken wire is part of a wiring harness, disconnect the wire at

each end and tape these ends with electrical tape. Install a new wire and attach it to the outside of the wiring harness.

5-23. Tubing and Fittings

The refrigerant piping used on the air conditioning units consists of copper tubing and necessary fittings. Joints of refrigeration pipes and fittings are soldered. Inspect the piping and fittings for cracks and breaks (para 3-45b). Replace defective pipes with those of the same length, size, shape, and material. When soldering or unsoldering items such as the thermostatic expansion valves or solenoid valves, disassemble the valve and wrap valve body with a damp cloth to protect it from damage by heat.

CHAPTER 6

REPAIR INSTRUCTIONS

Section I. COMPRESSOR

6-1. General

The compressor is hermetically sealed and cannot be repaired. In case of a failure the compressor must be replaced.

6-2. Compressor

- a. *Removal.* Refer to figure 3-6.
- b. *Installation.* Refer to figure 3-6.

Section II. CONDENSER COIL, EVAPORATOR COIL

6-3. General

The evaporator and condenser coils must be removed from the air conditioner for repair and replacement.

6-4. Evaporator Coil

a. *Removal.* Remove screws (6) that hold evaporator coil to mounting bracket. Refer to figure 3-16 and remove evaporator coil.

b. *Repair.* Repair minor leaks or holes by soldering with silver solder (class 4 or 6A QQS-561) per MIL-B-7883. If damage is excessive replace evaporator coil.

c. *Installation.* Refer to figure 3-16, and install evaporator coil.

(1) Leak test the entire system. Refer to paragraph 3-45b.

(2) Evacuate the system (para 5-21c).

(3) Recharge the system (para 5-21d).

6-5. Condenser Coil

a. *Removal.*

(1) Evacuate the system, reference paragraph 5-21.

(2) Remove the (8) screws holding the condenser coil grille, reference figure 3-4. These (8) screws also hold the condenser to the frame.

(3) In order to remove the condenser coil remove 3 screws holding filter-drier bracket to shell, refer to figure 3-6.

(4) To remove these 3 screws from filter-drier bracket you have to remove the front access panel figure 3-5, remove junction box and control box, figure 3-13.

(5) Pull condenser coil, refer to figure 3-4 from unit and unsolder as required.

b. *Repair.* Repair minor leaks or holes by soldering with silver solder (class 4 or 6A QQS-561) per MIL-B-7883. If damage is excessive replace condenser coil.

c. *Installation.*

(1) Replace condenser coil.

(2) Leak test the entire system. Refer to paragraph 3-45b.

(3) Evacuate the system (para 5-21c).

(4) Recharge the system (para 5-21d).

(5) Replace screws in filter-drier bracket.

(6) Replace condenser coil grille, figure 3-4.

Section III. HIGH PRESSURE SWITCH, LOW PRESSURE SWITCH, FAN SPEED PRESSURE SWITCH

6-6. High Pressure Switch

a. *General.* The high pressure switch prevents the compressor from operating if the head pressure exceeds 445 psig.

b. *Removal.*

(1) Remove top panel, condenser fan guard, condenser fan refer to paragraph 3-18 and 3-20.

(2) Refer to figure 3-14 and remove the high pressure switch from the pressure switch mounting box.

(3) Disconnect flare nut from high pressure line connection and immediately cap to prevent refrigerant loss.

c. Installation.

(1) Refer to figure 3-14 and install the high pressure switch,

(2) Connect flare nut to high pressure connection.

(3) Install top panel, condenser fan and fan guard, refer to paragraph 3-18 and 3-20.

6-7. Low Pressure Switch

a. General. The low pressure switch prevents the compressor from operating if the suction pressure drops below 25 psig.

b. Removal.

(1) Remove top panel, condenser fan guard, condenser fan, refer to paragraph 3-18 and 3-20.

(2) Refer to figure 3-14 and remove the low pressure switch from the pressure switch mounting box.

(3) Disconnect flare nut from low pressure line connection and immediately cap to prevent refrigerant loss.

c. Installation.

(1) Refer to figure 3-14 and install the low pressure switch.

(2) Connect flare nut to low pressure connection.

(3) Install top panel, condenser fan and fan guard, refer to paragraph 3-18 and 3-20.

6-8. Fan Speed Pressure Switch

a. General. The fan speed switch changes the speed of the fan motor from low to high when the pressure reaches 410 psig.

b. Removal. Refer to figure 3-15 and remove fan speed pressure switch.

c. Installation. Refer to figure 3-15 and install fan speed pressure switch.

Section IV. LIQUID LINE SOLENOID VALVE AND EQUALIZER

SOLENOID VALVE

6-9. Liquid Line Solenoid Valve

a. General. The liquid line solenoid shuts off the flow of refrigerant to the evaporator coil when the thermostat is satisfied.

b. Removal. Slowly discharge refrigerant from system (para 5-21b). Refer to figure 3-6 and remove solenoid valves.

c. Installation. Refer to figure 3-6 and install solenoid valves.

Caution: The solenoid valves must be disassembled before disconnecting the tubing from the valve to avoid heat distortion. Refer to figure 6-1.


Caution: Solder the tubing to the body of valve before reassembling valve to avoid heat distortion (fig. 6-1).

6-10. Equalizer Solenoid Valve

a. General. The equalizer solenoid valve is actuated by the on-off switch and serves to equalize system pressures during shutdown.

b. Removal. Slowly discharge refrigerant from system (para 5-21c). Refer to figures 3-11, 3-12 and remove equalizer solenoid valve,

c. Installation. Refer to figures 3-11, 3-12 and install equalizer solenoid valve. Evacuate and recharge the refrigerant system (para 5-21c and 5-21d).



ME 4120-273-15/6-1

Figure 6-1. Solenoid valve, disassembly and assembly.

Section V. PRESSURE RELIEF VALVE

6-11. Pressure Relief Valve

a. General. The pressure relief valve protects the refrigerant system from excessive pressure.

b. Removal. Slowly discharge refrigerant from

system (para 5-21b). Refer to figure 3-6 and remove pressure relief valve.

c. Installation. Refer to figure 3-6, and install pressure relief valve. Evacuate (para 5-21c), and recharge (para 5-21d and refrigerant system).

Section VI. EXPANSION VALVES

6-12. Expansion Valves

a. General. The main expansion valve controls the flow of refrigerant to the evaporator coil during the cooling cycle of operation. The bypass expansion valve functions when the unit is in the bypass cycle of operation.

b. Removal.

(1) Remove cover panel, reference paragraph 3-18.

(2) Discharge refrigerant from system, reference paragraph 5-21c.

(3) Refer to figures 3-11 and 3-12 and remove expansion valves.

c. Adjustment.

(1) Remove side cap from expansion valve base.

Note. Make sure thermal bulb is securely fastened to suction line and the bulb is covered with rubber insulation.

(2) Turn stem clockwise for higher superheat and counterclockwise for lower superheat. One full turn is equivalent to approximately 2°F superheat. A suction gas superheat of 5°F to 10°F

out of the evaporator coil is satisfactory. A superheat of 10°F to 20°F when measuring the superheat at the thermal bulb is also satisfactory. If the

superheat does not reach the required valve when adjusted, check for dirt or other restrictions in the liquid line or expansion valve.

Section VII. ACCESS FITTINGS

6-13. Access Fittings

a. General. The access fittings provide access to the refrigerant system for service.

b. Removal.

(1) Install front access panel, reference paragraph 3-18.

(2) Slowly discharge the refrigerant charge from system (para 5-21b).

(8) Unscrew valve stem from inside access valve.

c. Installation.

(1) Install valve stem into access valve.

(2) Recharge system, reference paragraph 5-21d.

(3) Install front access panel reference paragraph 3-18.

Section VIII. SIGHT GLASS

6-14. Sight Glass

a. General. The sight glass indicates the refrigerant moisture content. When the indicator is green the refrigerant is dry. A color shading into yellow indicates that the refrigerant has become contaminated with moisture. A shortage of refrigerant is indicated by flash gas in the sight glass.

b. Removal. Refer to figure 3-14 and remove element from sight glass.

c. Installation. Refer to figure 3-14 and install new element.

6-15. Filter Drier

a. General. The filter drier prevents the accumulation of moisture and contaminant within the refrigerant system. The filter drier must be replaced each time the system is exposed to the atmosphere.

b. Removal. Slowly discharge the refrigerant charge from the system (para 5-21b). Refer to figure 3-6 and remove the filter drier.

c. Installation. Refer to figure 3-6 and install filter drier.

APPENDIX A
REFERENCES

A-1. Fire Protection

TB 5-4200-200-10
TM 5-687

Hand Portable Fire Extinguisher, approved for Army users.
Repair and Utilities: Fire Protection Equipment and Appliance: Inspection, Operations, and Preventive Maintenance.

A-2. Painting

TM 9-218

Painting Instructions for Field Use.

A-3. Preventive Maintenance

TM 5-764
TM 38-750

Electric Motor and Generator Repair.
Army Equipment Records Procedures.

A-4. Supply Publications

C9100-IL

Fuels, Lubricants, Oils and Waxes.

APPENDIX B
BASIC ISSUE ITEMS LIST AND MAINTENANCE AND
OPERATING SUPPLIES

Section I. INTRODUCTION

B-1. Scope

This appendix lists items which accompany the air conditioner or are required for installation, operation, or operator's maintenance.

B-2. General

This Basic Issue Items List is divided into the following sections:

a. Basic Issue Items-Section II. This section is a listing of accessories, repair parts, tools and publications required for operator's maintenance and operation, initially issued with, or authorized for the air conditioner.

b. Maintenance and Operating Suppl&s-Section III. This section is a listing of maintenance and operating supplies required for initial operation,

B-3. Explanation of Columns

The following provides an explanation of columns in the tabular list of basic issue items, section II:

a. Source, Maintenance, and Recoverability Codes (SMR), Column (1):

(1) Source code indicates the selection status and source for the listed item. Source codes are:

Code	Explanation
P	Applied to repair parts which are stocked in or supplied from GSA/DSA Army supply system, and authorized for use at indicated maintenance categories.
M	Applied to repair parts which are not procured or stocked but are to be manufactured at indicated maintenance categories.
A	Applied to assemblies which are not procured or stocked as such, but made up of two or more units, each of which carry individual stock numbers and descriptions and are procured and stocked and can be assembled by units at indicated maintenance categories.
X	Applied to parts and assemblies which are not procured or stocked, the mortality of which is normally below that of the applicable end

Code	Explanation
	item, and the failure of which should result in retirement of the end item from the supply system.
X1	Applied to repair parts which are not procured or stocked, the requirement for which will be supplied by use of the next higher assembly or component
X2	Applied to repair parts which are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain them through cannibalization; if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.
C	Applied to repair parts authorized for local procurements. If not obtainable from local procurement, such repair parts will be requisitioned through normal supply channels with a supporting statement of nonavailability from local procurement.
G	Applied to major assemblies that are procured with PEMA (Procurement Equipment Missile Army) funds for initial issue only to be used as exchange assemblies at DSU and GSU level or returned to depot supply level. Note. Source code is not shown on common hardware items known to be readily available in Army supply channels and through local procurement.

(2) Maintenance code indicates the lowest category of maintenance authorized to install the listed item. The maintenance level code is:

Code	Explanation
C	Operator/crew

(3) Recoverability code indicates whether unserviceable items should be returned for recovery or salvage. Items not coded are expendable. Recoverability codes are:

Code	Explanation
R	Applied to repair parts and assemblies which are economically repairable at DSU and GSU activities and are normally furnished by supply on an exchange basis.
T	Applied to high dollar value recoverable repair

Code Explanation
 parts which are subject to special handling and are issued on an exchange basis. Such repair parts are normally repaired or overhauled at depot maintenance activities.
 U Applied to repair parts specifically selected for salvage by reclamation units because of precious metal content, critical materials, high dollar value reusable casings and castings.

b. *Federal Stock Number, Column (2).* This column indicates the Federal Stock Number for the item.

c. *Description, Column (9).* This column indicates the Federal item name and any additional description required. A five-digit manufacturer's or other service code is shown in parentheses followed by the manufacturer's part number. Repair parts quantities included in kits, sets, and assemblies that differ from the actual quantity used in the specific item, are listed in parentheses following the repair part name.

d. *Unit of Issue, Column (4).* This column indicates the unit used as a basis of issue, e.g., ea, pr, ft, yd, etc.

e. *Quantity Incorporated in Unit Pack, Column (5).* This column indicates the actual quantity contained in the unit pack.

f. *Quantity Incorporated in Unit, Column (6).* This column indicates the quantity of the item used in the equipment.

g. *Quantity Furnished With Equipment, Column (7).* This column indicates the quantity of an item furnished with the equipment in excess of the quantity incorporated in the unit.

h. *Quantity Authorized, Column (8).* This column indicates the quantity of an item authorized the operator/crew to have on hand or to obtain as

required. As required items are indicated with an asterisk.

i. *Illustration, Column (9).* This column is divided as follows:

(1) *Figure number, column (9) (a).* Indicates the figure number of the illustration in which the item is shown.

(2) *Item number, column (9) (b).* Indicates the callout number used to reference the item in the illustration.

B-4. Explanation of Columns in the Tabular List of Maintenance and Operating Supplies-Section III

a. *Item, Column (1).* This column contains numerical sequence item numbers assigned to each component application to facilitate reference.

b. *Component Application, Column (2).* This column identifies the component application of each maintenance or operating supply item.

c. *Federal Stock Number, Column (3).* This column indicates the Federal Stock Number for the item and will be used for requisitioning purposes.

d. *Description, Column (4).* This column indicates the item and a brief description.

e. *Quantity Required for Initial Operation, Column (5).* This column indicates the quantity of each maintenance or operating supply item required for initial operation of the equipment.

f. *Quantity Required for 8 Hours Operation, Column (6).* This column indicates the estimated quantities required for an average eight hours of operation.

g. *Notes, Column (7).* This column indicates informative notes keyed to data appearing in a preceding column.

Section II. BASIC ISSUE ITEMS

(1) SMR Code	(2) Federal stock number	(3) Description Ref No & Mfr Code	(4) Unit of issue	(5) Qty inc in unit pack	(6) Qty inc in unit	(7) Qty furn with equip	(8) Qty auth	(9) Illustration	
								(a) Figure No.	(b) Item No.
		Group 31—Basic Issue Items Manufacturer Installed.							
PO	5220-559-9618	CASE: Maintenance and operational manuals, cotton duck, water repellent mildew resistant, MIL-B-11743B.	Ea.			1	1		
		Department of the Army operator, organizational, direct and general support and depot maintenance manual TM 5-4120-273-15.				1	1		
PO		Block off panel, D13214E3665 -----	Ea.			1	1		

(1) SMR Code	(2) Federal stock number	(3) Description Ref No & Mfr Code Useable on Code		(4) Unit of issue	(5) Qty inc in unit pack	(6) Qty inc in unit	(7) Qty furn with equip	(8) Qty auth	(9) Illustration	
									(a) Figure No.	(b) Item No.
PO		Receptacle, MS 3106R-20-4S used on 400 cycle, 208v, 3 ph. MS3106R-20-4SX used on 60 cycle, 115v, single phase.		Ea.			1	1		
PO		Sound Attenuator, D13214E3575 ----- Group 32—Basic Issue Items Troop Installed, 3200— Basic Issue Items, Troop Installed or Authorized.		Ea.			1	1		
PO	5120-223-7396	Pliers, Slip Joint, stght, nose comb, w/cutter, 8 in. lg.		Ea.				1		
PO	5120-277-9491	Screw Driver, Flat Tip: wood hdl, 1/4 in. w/glared tip, 4 in. lg.		Ea.				1		
PO	5120-240-5328	Wrench, Open End, Adjustable: sgle hd, 0.947 in. jaw opng 8 in. lg.		Ea.				1		

Section III. MAINTENANCE AND OPERATING SUPPLIES

(1) Item	(2) Component application	(3) Federal stock number	(4) Description	(5) Quantity Required //initial operation	(6) Quantity required 1/8 hrs operation	(7) Notes
1		6830-837-9927	Monochlorodifluoromethane, Technical, Type R-22, Fed. Spec. BB-F-671, 25 lb. cylinder.			
2		9150-823-7905	Lubricating oil, Refrigerant compressor, without additives, Fed. VV-L-825, Type IV, Refrigerant-22.			

APPENDIX C

MAINTENANCE ALLOCATION CHART

Section I. INTRODUCTION

C-1. General

a. This section provides a general explanation of all maintenance and repair functions authorized at various maintenance levels.

b. Section II designates overall responsibility for the performance of maintenance functions on the identified end item or component. The implementation of the maintenance functions upon the end item or component will be consistent with the assigned maintenance functions.

c. Section III lists the special tools and test equipment required for each maintenance function as referenced from Section II.

d. Section IV contains supplemental instructions, explanatory notes and/or illustrations required for a particular maintenance function.

C-2. Explanation of Columns in Section II

a. *Group Number, Column (1)*. The functional group is a numerical group set up on a functional basis. The applicable functional grouping indexes (obtained from TB 750-93-1, Functional Grouping Codes) are listed on the MAC (Maintenance Allocation Chart) in the appropriate numerical sequence. These indexes are normally set up in accordance with their function and proximity to each other.

b. *Functional Group, Column (2)*. This column contains a brief description of the components of each functional group.

c. *Maintenance Functions, Column (3)*. This column lists the various maintenance functions (A through K) and indicates the lowest maintenance category authorized to perform these functions. The symbol designations for the various maintenance categories are as follows:

C-Operator or crew
 O-Organizational maintenance
 F-Direct support maintenance
 H-General support maintenance
 D-Depot maintenance

The maintenance functions are defined as follows:

A-Inspect: To determine serviceability of an item by comparing its physical, mechanical, and electrical characteristics with established standards.

B-Test: To verify serviceability and to detect electrical or mechanical failure by use of test equipment.

C-Service: To clean, to preserve, to charge, to paint, and to add fuel, lubricants, cooling agents, and air.

D-Adjust: To rectify to the extent necessary to bring into proper operating range.

E-Align: To adjust specified variable elements of an item to bring to optimum performance.

F-Calibrate: To determine the corrections to be made in the readings of instruments or test equipment used in precise measurement. Consists of the comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared with the certified standard.

G-Install: To set up for use in an operational environment such as an emplacement, site, or vehicle.

H-Replace: To replace unserviceable items with serviceable assemblies, subassemblies, or parts.

I-Repair: To restore an item to serviceable condition. This includes, but is not limited to, inspection, cleaning, preserving, adjusting, replacing, welding, riveting, and strengthening.

J-Overhaul: To restore an item to a completely serviceable condition as prescribed by maintenance serviceability standards using the Inspect and Repair Only as Necessary (IROAN) technique.

K-Rebuild: To restore an item to a standard as nearly as possible to original or new condition in appearance, performance, and life expectancy. This is accomplished through complete disassembly of the item, inspection of

all parts or components, repair or replacement of worn or unserviceable elements (items) using original manufacturing tolerances and specifications, and subsequent reassembly of the item.

d. *Tools and Equipment, Column (4).* This column is provided for referencing by code the special tools and test equipment, (sec. HI) required to perform the maintenance functions (sec. II).

e. *Remarks, Column (5).* This column is provided for referencing by code the remarks (sec. IV) pertinent to the maintenance functions (Not Applicable).

C-3. Explanation of Columns in Section III

a. *Reference Code.* This column consists of a number and a letter separated by a dash. The number references the T and TE requirements column on the MAC. The letter represents the specific maintenance function the item is to be used with.

The letter is representative of columns A through K on the MAC.

b. *Maintenance Category.* This column shows the lowest level of maintenance authorized to use the special tool or test equipment.

c. *Nomenclature.* This column lists the name or identification of the tool or test equipment.

d. *Tool Number.* This column lists the manufacturer's code and part number, or Federal stock number of tools and test equipment.

C-4. Explanation of Columns in Section IV

a. *Reference Code.* This column consists of two letters separated by a dash, both of which are references to section II. The first letter references column 5 and the second letter references a maintenance function, column 3, A through K.

b. *Remarks.* This column lists information pertinent to the maintenance function being performed, as indicated on the MAC, section II (Not Applicable).

Section II. MAINTENANCE ALLOCATION CHART

(1) Group No.	(2) Functional group	(3) Maintenance functions											(4) Tools and equipment	(5) Remarks		
		A	B	C	D	E	F	G	H	I	J	K				
		Inspect	Test	Service	Adjust	Align	Calibrate	Install	Replace	Repair	Overhaul	Rebuild				
18	BODY, CAB HOOD, HULL															
1801	Body, Cab, Hood, Hull Assemblies: Panels and grille, fresh air screen	C	--	--	O	--	--	O	O	O						
22	BODY CHASSIS, HULL, ACCESSORY ITEMS															
2201	Canvas, Rubber or Plastic Items: Canvas, condenser cover	O	--	--	--	--	--	O	O	O						
40	ELECTRIC MOTORS and GENERATORS															
4000	Motors:															
	Motor assembly, evaporator blower	O	O	--	--	--	--	O	O	F						
	Motor assembly, condenser fan	O	O	--	--	--	--	O	O	F						
4006	Starting and Protective Devices:															
	Protectors, overload, temperature/current	O	O	--	--	--	--	O	O							
	Capacitors	O	O	--	--	--	--	O	C							
	Relays	O	O	--	--	--	--	O	O							
	Fuses	O	O	--	--	--	--	O	O							
4010	Master or Auxiliary Control Assembly:															
	Contactors, electrical	O	O	O	--	--	--	O	O							
	Control module	O	O	--	--	--	--	O	O	F						
	Transformer	O	O	--	--	--	--	O	O							
4011	Circuit Breakers:															
	Compressor, circuit breakers	--	O	--	--	--	--	--	O	O						

(1) Group No.	(2) Functional group	(3) Maintenance functions										(4) Tools and equipment	(5) Remarks		
		A	B	C	D	E	F	G	H	I	J			K	
		Inspect	Test	Service	Adjust	Align	Calibrate	Install	Replace	Repair	Overhaul			Rebuild	
4012	Switches:														
	Selector switch -----		O						O						
	Evaporator fan speed switch ---		O						O	O					
	Thermostatic switches -----		O												
	Pressure switches -----	O	O					F	F						
4212	Heating Units:														
	Heater, electrical -----	O	O					O	O						
4213	Non Rotating Rectifiers:														
	Rectifier -----	O	O					O	O						
4216	Miscellaneous Wiring and Fittings:														
	Wiring harness assemblies -----	O	O					O	O	O					
47	GAGES (NON-ELECTRICAL), WEIGHING AND MEASURING DEVICES														
4702	Gages, Mounting, Lines and Fittings:														
	Sight Glass -----	O							F						
52	REFRIGERATION AND AIR CONDITIONING COMPONENTS														
5200	Gas Compressor Assembly:														
	Compressor assembly -----	O	O	F				H	H	O					
5217	Refrigerant Piping:														
	Piping -----	O	O	F				F	F	F		F			
	Vibration eliminators -----	O	O	F				F	F	F		F			
	Valve, solenoid, liquid -----	O	O	F				F	F	F		F			
	Valve, solenoid, equalization ---	O	O	F				F	F	F		F			
	Valve, assemblies, charging -----	O						F	F	F		F			
	Head pressure control actuator w/cable -----	O	O		O			F	F	F		F			
	Strainer, suction -----	O						F	F	F		F			
	Valve, expansion -----		O		F			F	F	F		F			
	Valve, pressure relief -----	O	O					F	F	F		F			
	Valve, pressure regulating -----	O	O					F	F	F		F			
5230	Condenser:														
	Condenser, coil -----	O	O	O				F	F	F		F			
5241	Evaporator														
	Tubes, drain -----	O		O				O	O			F			
	Evaporator, coil -----	O	O	O				F	F			F			
	Receiver, liquid -----	O	O					H	H						
5245	Air Filter:														
	Filters, evaporator -----	O		O				O	O						


Section III. SPECIAL TOOL AND SPECIAL EQUIPMENT
REQUIREMENTS

Reference code	Maintenance level	Nomenclature	Tool number
		No special tools or test equipment required.	

Section IV. REMARKS

Reference code	Remarks
	Not applicable


**POWER SUPPLY
115 VOLT
SINGLE PHASE
60 CYCLE**



LEGEND		
SYMBOL	PART NUMBER	DESCRIPTION
B1	D13214E3538-1	COMPRESSOR, ROTARY, POWER DRIVEN
B2	D13214E3728-1	MOTOR, ALTERNATING CURRENT
C1, C2	C13214E3529-1	CAPACITOR
CB	C13214E3711-1	CIRCUIT BREAKER
CP GRD		CONTROL PANEL GROUND
CR	C13214E3652	RECTIFIER, SEMICONDUCTOR DEVICE
F1	MIL-F-15160	FUSE (TYPE F09A250V3A)
F2	B13211E3785	FUSE
FR GRD		FRAME GROUND
HR1-6	C13214E3561	HEATING ELEMENT
J1	MS3100R-20-4PX	CONNECTOR RECEPTACLE
J2	MS3102R-14S-6P	CONNECTOR RECEPTACLE
J3	MS3102R-16S-1P	CONNECTOR RECEPTACLE
J4	MS3102R-32-7P	CONNECTOR RECEPTACLE
J5	MS3102R-12S-3S	CONNECTOR RECEPTACLE
J6	MS3102R-12S-3SX	CONNECTOR RECEPTACLE
J7	MS3100R-16-10P	CONNECTOR RECEPTACLE
J8	C13211E8399C-28-17P	CONNECTOR RECEPTACLE
J9	MS3102R-12S-3SZ	CONNECTOR RECEPTACLE
J10	MS3102R-28-9S	CONNECTOR RECEPTACLE
JB GRD		JUNCTION BOX GROUND
K1, K2	C13214E3403	RELAY, 25 AMP
K3, K4	C13214E3524	VALVE SOLENOID
K6	C13214E0752-3	RELAY, TIME DELAY
K7	13216E7688	RELAY, FAN
K9	C13214E0752-4	RELAY, TIME DELAY
P1	MS3106R-20-4SX	CONNECTOR PLUG
P2	MS3106R-14S-6S	CONNECTOR PLUG
P3	MS3106R-16S-1S	CONNECTOR PLUG
P4	MS3106R-32-7S	CONNECTOR PLUG
P5	MS3106R-12S-3P	CONNECTOR PLUG
P6	MS3106R-12S-3PX	CONNECTOR PLUG
P7	MS3106R-16-10S	CONNECTOR PLUG
P8	MS3100R-28-17S	CONNECTOR RECEPTACLE
P9	MS3106R-12S-3PZ	CONNECTOR PLUG
P10	MS3106R-28-9P	CONNECTOR PLUG
R1	13216E3691	RESISTOR, 12 W, 30 OHMS
S/W1-3	C13211E8298	SWITCH, ROTARY
S1	C13211E8301-1	THERMOSTAT
S2	C13211E8180	THERMOSTAT
S3	B13211E8265	THERMOSTAT HEATER
S4	WITH COMPRESSOR	THERMOSTAT
S5	C13211E8404	SWITCH, HIGH PRESSURE CUTOUT
S6	C13214E3794	SWITCH, LOW PRESSURE CUTOUT
S7	MS35058-22	SWITCHES, TOGGLE, SP/ST
S8	13216E7690	SWITCH, PRESSURE CONTROL
T	D13214E3818-2	TRANSFORMER
TB1	MIL-T-55164/3A	TERMINAL BLOCK
TB2	C13214E3804	TERMINAL BLOCK
XF1	B13211E3784	FUSEHOLDER
XF2	B13214E3811	FUSEHOLDER

MEC 4120-273-15/1-5 (1)


Figure 1-5 (1). Wiring diagram model CV-8-1-15-80



MEC 4120-273-15/1-5 (2)


LEGEND		
SYMBOL	PART NO.	DESCRIPTION
B1	D13214E3538-2	COMPRESSOR, ROTARY, POWER DRIVEN
B2	D13214E3728-2	MOTOR, ALTERNATING CURRENT
CB	C13214E3787-1	CIRCUIT BREAKER
CP GRD		CONTROL PANEL GROUND
CR	C13214E3652	RECTIFIER, SEMICONDUCTOR DEVICE
CR1	13216E7689	DIODE, SURGE PROTECTOR
F1, F2	MIL-F-15160	FUSE (TYPE F09A250V2A)
F3	B13211E3785	FUSE
FR GRD		FRAME GROUND
HR1-6	C13214E3561	HEATING ELEMENT
J1	MS3100R-20-4P	CONNECTOR RECEPTACLE
J2	MS3102R-20-27P	CONNECTOR RECEPTACLE
J3	MS3102R-16S-1P	CONNECTOR RECEPTACLE
J4	MS3102R-28-12S	CONNECTOR RECEPTACLE
J5	MS3102R-12S-3S	CONNECTOR RECEPTACLE
J6	MS3102R-12S-3SX	CONNECTOR RECEPTACLE
J7	MS3100R-16S-1PW	CONNECTOR RECEPTACLE
J8	C13211E8399C28-11P	CONNECTOR RECEPTACLE
J9	MS3102R-12S-3SZ	CONNECTOR RECEPTACLE
J10	MS3102R-32-6P	CONNECTOR RECEPTACLE
JB GRD		JUNCTION BOX GROUND
K1, K2	MS24192-D1	RELAY, 25 AMP 3 PST N O
K3, K4	D13214E3524	VALVE, SOLENOID
K5	C13214E3437-1	RELAY, PHASE SEQUENCE
K6	C13214E0752-3	RELAY, TIME DELAY
K7, K8	13216E7688	RELAY, FAN
P1	MS3106R-20-4S	CONNECTOR PLUG
P2	MS3106R-20-27S	CONNECTOR PLUG
P3	MS3106R-16S-1S	CONNECTOR PLUG
P4	MS3106R-28-12P	CONNECTOR PLUG
P5	MS3106R-12S-3P	CONNECTOR PLUG
P6	MS3106R-12S-3PX	CONNECTOR PLUG
P7	MS3106R-16S-1SW	CONNECTOR PLUG
P8	MS3100R-28-11S	CONNECTOR RECEPTACLE
P9	MS3106R-12S-3PZ	CONNECTOR PLUG
P10	MS3106R-32-6S	CONNECTOR PLUG
S/W1-S/W4	C13211E8208	SWITCH, ROTARY
S1	C13211E8301-1	THERMOSTAT
S2	C13211E8130	THERMOSTAT
S3	B13211E8265	THERMOSTAT HEATER
S4	WITH COMPRESSOR	THERMOSTAT
S5	C13211E8404	SWITCH, HIGH PRESSURE CUTOUT
S6	C13214E3794	SWITCH, LOW PRESSURE CUTOUT
S7	MS35058-22	SWITCH, TOGGLE, SP/ST
S8	13216E7690	SWITCH, PRESSURE CONTROL
T	D13214E3818-1	TRANSFORMER
TB1	MIL-T-55164/3A	TERMINAL BLOCK
TB2	C13214E3804	TERMINAL BLOCK
XF1	B13211E3784	FUSEHOLDER
XF2	B13214E3811	FUSEHOLDER

Figure 1-5 (2). - Continued.



LEGEND	
SYMBOL	DESCRIPTION
B1	COMPRESSOR MOTOR
B2	FAN MOTOR
C1	CAPACITOR, FAN MOTOR, 12 UF, 370 V
C2	CAPACITOR, COMPRESSOR MOTOR, 25 UF, 370 V
CB	CIRCUIT BREAKER
CR	RECTIFIER, SEMICONDUCTOR DEVICE
F1, F2	FUSE
HR1-6	HEATING ELEMENT
K1	RELAY, COMPRESSOR
K2	RELAY, HEATER
K3	SOLENOID VALVE, LIQUID LINE
K4	SOLENOID VALVE, PRESSURE EQUALIZATION
K6	RELAY, TIME DELAY
K7	RELAY, FAN SPEED
K9	RELAY, TIME DELAY
R1	RESISTOR, 1/2 W, 30 OHMS
S/W1-S/W3	ROTARY SWITCH
S1	THERMOSTAT, TEMPERATURE CONTROLLER
S2	THERMOSTAT, OUTSIDE AIR
S3	THERMOSTAT, HEATER COMPARTMENT
S4	THERMOSTAT, COMPRESSOR MOTOR
S5	SWITCH, HIGH PRESSURE CUT-OUT
S6	SWITCH, LOW PRESSURE CUT-OUT
S7	SWITCH, FAN SPEED BYPASS
S8	SWITCH, HIGH PRESSURE FAN SPEED
T	TRANSFORMER
XF1, XF2	FUSEHOLDER


SWITCH POSITION						
	CONTACT NO.	1 HI HEAT	2 LO HEAT	3 OFF	4 VENT	5 COOL
S/W1	2 & A	CLOSED	CLOSED	OPEN	OPEN	OPEN
	2 & B	OPEN	OPEN	OPEN	OPEN	CLOSED
	1 & D	OPEN	OPEN	OPEN	OPEN	CLOSED
S/W2	2 & B	CLOSED	CLOSED	OPEN	CLOSED	CLOSED
S/W3	2 & A	CLOSED	OPEN	OPEN	OPEN	OPEN



LEGEND	
SYMBOL	DESCRIPTION
B1	COMPRESSOR MOTOR
B2	FAN MOTOR
CB	CIRCUIT BREAKER
CR	RECTIFIER, SEMICONDUCTOR DEVICE
CR1	DIODE
F1, F2, F3	FUSE
HR1-6	HEATING ELEMENT
K1	RELAY, COMPRESSOR
K2	RELAY, HEATER
K3	SOLENOID VALVE, LIQUID LINE
K4	SOLENOID VALVE, PRESSURE EQUALIZATION
K5	RELAY, PHASE SEQUENCE
K6	RELAY, TIME DELAY
K7	RELAY, FAN
K8	RELAY, FAN
S	SWITCH, ROTARY
S1	THERMOSTAT, TEMPERATURE CONTROLLER
S2	THERMOSTAT, OUTSIDE AIR
S3	THERMOSTAT, HEATER COMPARTMENT
S4	THERMOSTAT, COMPRESSOR MOTOR
S5	SWITCH, HIGH PRESSURE CUT-OUT
S6	SWITCH, LOW PRESSURE CUT-OUT
S7	SWITCH, FAN BYPASS
S8	SWITCH, HIGH PRESSURE FAN SPEED
T	TRANSFORMER
XF1, XF2	FUSEHOLDER

SWITCH POSITION						
	CONTACT NO	1 HI HEAT	2 LO HEAT	3 OFF	4 VENT	5 COOL
S/W1	2 & A	CLOSED	CLOSED	OPEN	OPEN	OPEN
	2 & B	OPEN	OPEN	OPEN	OPEN	CLOSED
	1 & D	OPEN	OPEN	OPEN	OPEN	CLOSED
S/W2	2 & B	CLOSED	CLOSED	OPEN	CLOSED	CLOSED
	1 & C	CLOSED	CLOSED	OPEN	CLOSED	CLOSED
S/W3	2 & A	CLOSED	OPEN	OPEN	OPEN	OPEN
	1 & C	CLOSED	CLOSED	OPEN	CLOSED	CLOSED
S/W4	2 & A	CLOSED	OPEN	OPEN	OPEN	OPEN
	1 & C	CLOSED	OPEN	OPEN	OPEN	OPEN

Figure 1-6 (2)-Continued.



NOTE -

1. REFRIGERANT 22 PER BB-C-310.
 150° F CONDENSING TEMPERATURE
 50° F SUCTION TEMPERATURE
 120° F MAXIMUM OUTSIDE AMBIENT
 160° F MAXIMUM RETURN AIR TEMPERATURE
 70° F MINIMUM RETURN AIR TEMPERATURE
 50° F MINIMUM AMBIENT
2. MOTOR - COMPRESSOR, ROTARY, HERMETICALLY SEALED, OIL CHARGED.

DESIGNATION	NAME	NEXT ASSEMBLY					
		D13214E3455-1	D13214E3455-2	D13214E3755-3	D13214E3755-1	D13214E3755-2	D13214E3755-4
		DRAWING NUMBER					
B1	COMPRESSOR	D13214E3538-2	D13214E3538-1	D13208E4182-2	D13208E4182-1	D13208E4182-3	D13208E4182-4
B2	FAN MOTOR	D13214E3728-2	D13214E3728-1	D13214E3728-4	D13214E3728-8	D13214E3728-7	D13211E8275-3
C	COIL, CONDENSER	D13214E3553	D13214E3553	D13214E3708	D13214E3708	D13214E3708	D13214E3708
D	FILTER-DRIER, REFRIGERANT	C13214E3557	C13214E3557	C13214E3793	C13214E3793	C13214E3793	C13214E3793
E	COIL, EVAPORATOR	D13214E3554	D13214E3554	D13214E3709	D13214E3709	D13214E3709	D13214E3709
G	GLASS, SIGHT	C13211E8218	C13211E8218	C13211E8218	C13211E8218	C13211E8218	C13211E8218
K3	VALVE, SOLENOID	C13214E3524	C13214E3524	C13214E3524	C13214E3524	C13214E3524	C13214E3524
K4	VALVE, SOLENOID	C13214E3524	C13214E3524	C13214E3524	C13214E3524	C13214E3524	C13214E3524
S5	SWITCH, HIGH PRESSURE CUTOUT	C13211E8404	C13211E8404	C13211E8404	C13211E8404	C13211E8404	C13211E8404
V1	VALVE, ACCESS FITTING	B44532-102	B44532-102	B44532-102	B44532-102	B44532-102	B44532-102
V2	REGULATOR, FLUID PRESSURE	C13214E3742	C13214E3742	C13214E3742	C13214E3742	C13214E3742	C13214E3742
V3	VALVE, PRESSURE RELIEF	B13211E8369	B13211E8369	B13211E8369	B13211E8369	B13211E8369	B13211E8369
V4	VALVE, EXPANSION	C13214E3785	C13214E3785	C13214E3785	C13214E3785	C13214E3785	C13214E3785
V5	VALVE, EXPANSION	C13214E3568-1	C13214E3568-1	C13214E3568-2	C13214E3568-2	C13214E3568-2	C13214E3568-2
S6	SWITCH, LOW PRESSURE CUTOUT	C13214E3794	C13214E3794	C13214E3794	C13214E3794	C13214E3794	C13214E3794
R	RECEIVER	C13214E3798-1	C13214E3798-1	C13214E3798-2	C13214E3798-2	C13214E3798-2	C13214E3798-2
V6	VALVE, ACCESS FITTING	B44532-101	B44532-101	B44532-101	B44532-101	B44532-101	B44532-101
S8	SWITCH, PRESSURE	C44538-101	C44538-101	C44538-101	C44538-101	C44538-101	C44538-101

Figure 5-1 Refrigerant flow diagram

INDEX

	Paragraph	Page
Access fittings - - - - -	3-48,6-13	3-19,6-4
Air filter inspection and service - - - - -	3-9	3-6
Basic issue tools and equipment - - - - -	3-2	3-1
Canvas condenser cover - - - - -	3-19	6-9
Capacitors - - - - -	3-25	3-11
Circuit breaker - - - - -	3-35	3-13
Components, installation of separately packed - - - - -	2-4	2-1
Compressor - - - - -	3-21,5-17	3-9,5-2
Compressor motor relay and electric heater relay - - - - -	3-37	3-14
Condenser coil - - - - -	3-56,6-5	3-20, 6-1
Condenser fan - - - - -	3-23	3-10
Control box - - - - -	3-28	3-12
Controls and instruments - - - - -	2-10	2-5
Daily preventive maintenance - - - - -	3-6	3-1
Data, identification and tabulated - - - - -	1-4,4-4	1-5,4-1
Description - - - - -	1-3,4-3	1-1,4-1
Differences in models - - - - -	1-6	1-6
Diode surge protector - - - - -	3-27	3-11
Dismantling for movement - - - - -	2-7	2-4
Drain tubes - - - - -	3-57	3-20
Dusty or sandy areas, operation in - - - - -	2-17	2-7
Electric heater thermostat - - - - -	3-44	3-19
Equalizer solenoid valve - - - - -	3-47,6-10	3-19,6-2
Evaporator coil - - - - -	3-55,6-4	3-20,6-1
Evaporator coil and inlet ring - - - - -	3-22	3-9
Evaporator pressure regulating valve - - - - -	3-50	3-19
Extreme cold, operation in - - - - -	2-15	2-7
Extreme heat, operation in - - - - -	2-16	2-7
Fan motor - - - - -	3-24	3-10
Fan motor relays - - - - -	3-26	3-11
Fan speed pressure switch - - - - -	3-42,6-8	3-16, 6-2
Filter drier - - - - -	6-15	6-4
Fuses - - - - -	3-33	3-13
Heater elements - - - - -	3-39	3-14
High pressure switch - - - - -	3-40	3-14
Hi-lo fan speed switch - - - - -	3-30	3-12
Housing assembly, general - - - - -	3-17	3-9
Identification and tabulated data - - - - -	1-4, 4-4	1-5 4-1
Inspecting and servicing equipment - - - - -	2-3	2-1
Installation of separately packed components - - - - -	2-4	2-1
Installation or setting-up instructions - - - - -	2-5	2-1
Junction box - - - - -	3-32	3-13
Liquid line solenoid valve - - - - -	3-46,6-9	3-19,6-2
Liquid receiver - - - - -	3-54	3-20
Low pressure switch - - - - -	3-41, 6-7	3-16,6-2
Lubrication information, general - - - - -	3-3	3-1

	Paragraph	Page
Models, difference in	1-5	1-6
Movement		
Dismantling for	2-7	2-4
Reinstallation after	2-8	2-5
operation		
Analysis of	5-19	5-3
In dusty or sandy areas	2-17	2-7
In extreme cold	2-15	2-7
In extreme heat	2-16	2-7
In high altitudes	2-19	2-9
In salt water	2-18	2-9
Under unusual conditions	2-14	2-7
Phase sequence relay	3-36	3-14
Pressure relief valve	3-49,6-11	3-19,6-3
Preventive maintenance services		
Daily	3-6	3-1
General	3-5	3-1
Quarterly	3-7	3-1
Quarterly preventive maintenance services	3-7	3-1
Record and report forms	1-2,4-2	1-1,4-1
Rectifier	3-38	3-14
Refrigerant piping	3-45	3-19
Reinstallation after movement	2-8	2-5
Repair instructions general	5-18	5-3
Salt water area, operation in	2-18	2-9
Scope	1-1,4-1	1-1,4-1
Starting	2-12	2-7
Stopping	2-13	2-7
Special tools and equipment	3-1, 5-1	3-1, 5-1
Selector switch	3-29	3-12
Sight glass	3-53,6-14	3-20, 6-4
Specially designed tools and equipment	5-2	5-1
Servicing the refrigerant system	5-21	5-4
Tabulated data and identification	1-4,4-4	1-1,4-1
Thermostat, maintenance of	3-31	3-12
Troubleshooting		
General	3-11, 5-3	3-6, 5-1
Subsequent paragraphs	3-12,5-4	3-6, 5-1
Unloading the equipment	2-1	2-1
Unpacking the equipment	2-2	2-1
Unusual condition, operation under	2-14	2-7

By Order of the Secretary of the Army:

W. C. WESTMORELAND,
General, *United States Army*,
Chief of Staff.

Official:

KENNETH G. WICKHAM,
Major General, United States Army,
The Adjutant General.

Distribution:

To be distributed in accordance with DA Form 12-25, Section III, (qty rqr block no. 530) organizational maintenance requirements for Air Conditioners, 6,000 BTU.

